



**7302 INTELLIGENT SERVICES
ACCESS MANAGER
7330 INTELLIGENT SERVICES
ACCESS MANAGER FTTN
7360 INTELLIGENT SERVICES
ACCESS MANAGER FX
RELEASE 6.2.04ng**

**CLI Command Guide For FD 100/320Gbps NT And
FX NT**

3HH-08079-FCEH-TCZZA

Issue: 01

June 2022

Nokia is committed to diversity and inclusion. We are continuously reviewing our customer documentation and consulting with standards bodies to ensure that terminology is inclusive and aligned with the industry. Our future customer documentation will be updated accordingly.

This document includes Nokia proprietary and confidential information, which may not be distributed or disclosed to any third parties without the prior written consent of Nokia.

This document is intended for use by Nokia's customers ("You"/"Your") in connection with a product purchased or licensed from any company within Nokia Group of Companies. You agree to notify Nokia of any errors you may find in this document; however, should you elect to use this document for any purpose(s) for which it is not intended, You understand and warrant that any determinations You may make or actions You may take will be based upon Your independent judgment and analysis of the content of this document.

Nokia reserves the right to make changes to this document without notice. At all times, the controlling version is the one available on Nokia's site.

No part of this document may be modified.

NO WARRANTY OF ANY KIND, EITHER EXPRESS OR IMPLIED, INCLUDING BUT NOT LIMITED TO ANY WARRANTY OF AVAILABILITY, ACCURACY, RELIABILITY, TITLE, NON-INFRINGEMENT, MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE, IS MADE IN RELATION TO THE CONTENT OF THIS DOCUMENT. IN NO EVENT WILL NOKIA BE LIABLE FOR ANY DAMAGES, INCLUDING BUT NOT LIMITED TO SPECIAL, DIRECT, INDIRECT, INCIDENTAL OR CONSEQUENTIAL OR ANY LOSSES, SUCH AS BUT NOT LIMITED TO LOSS OF PROFIT, REVENUE, BUSINESS INTERRUPTION, BUSINESS OPPORTUNITY OR DATA THAT MAY ARISE FROM THE USE OF THIS DOCUMENT OR THE INFORMATION IN IT, EVEN IN THE CASE OF ERRORS IN OR OMISSIONS FROM THIS DOCUMENT OR ITS CONTENT.

Copyright and trademark: Nokia is a registered trademark of Nokia Corporation. Other product names mentioned in this document may be trademarks of their respective owners.

© 2022 Nokia.

Contents

1- ISAM CLI	1
1.1 History	2
1.2 Preface	143
1.3 CLI Commands	144
1.4 Nodes	146
1.5 Parameters	147
1.6 Filters	150
1.7 Printers	151
1.8 Getting help	152
1.9 The CLI Prompt	153
1.10 Entering CLI Commands	154
1.11 CLI Backward Compatibility	155
1.12 Phase Out Strategy Obsolete Commands and/or Parameters	157
1.13 Command Phase Out Announcement Release	158
2- Environment Configuration Commands	159
2.1 Environment Configuration Command Tree	160
2.2 Environment Configuration Command	161
3- Alarm Configuration Commands	163
3.1 Alarm Configuration Command Tree	164
3.2 Alarm Log Configuration Command	166
3.3 Alarm Entry Configuration Command	168
3.4 Alarm Filter Configuration Command	223
3.5 Alarm Suppression Filter Configuration Command	278
3.6 Alarm Delta Log Configuration Command	280
3.7 Customizable Alarm Profile Configuration Command	282
3.8 HGU TR069 Customizable Alarm Configuration Command	287
4- Trap Configuration Commands	288
4.1 Trap Configuration Command Tree	289
4.2 Trap Definition Configuration Command	292
4.3 Trap Manager Configuration Command	295
4.4 Trap Manager Configuration Command	300
5- Equipment Configuration Commands	305
5.1 Equipment Configuration Command Tree	306
5.2 Rack Configuration Command	309
5.3 Shelf Configuration Command	310
5.4 Slot Configuration Command	312
5.5 Applique Configuration Command	315
5.6 Protection Group Configuration Command	317
5.7 Protection Element Configuration Command	318
5.8 External-link-host Configuration Commands	320
5.9 Host Shelf SFP Configuration Commands	322
5.10 SFP/XFP Diagnostics configuration Command	324
5.11 Sfp RSSI Configuration Command	327
5.12 2xE1/DS1 CLOCK configuration Command	332
5.13 2xE1/DS1 Pseudo Wire TDM Interface configuration Command	334
5.14 2xE1/DS1 Pseudo Wire TDM SFP configuration Command	336

5.15 2xE1/DS1 Framer configuration Command	339
5.16 2xE1/DS1 Line Interface Unit SFP configuration Command	343
5.17 NE Configuration Command	346
5.18 Environment Monitoring Configuration Command	347
5.19 Configure Fan Tray parameters	348
5.20 Configure Board Auto Replan feature	349
6- Gpon ONT Configuration Commands	350
6.1 Gpon ONT Configuration Command Tree	351
6.2 ONT Interface Configuration Command	354
6.3 NGPON2 Rogue Onu Prevention Configuration Commands	363
6.4 GPON GEM port performance monitoring Configuration Commands	365
6.5 ONT-SIDE TC-layer Performance Monitoring Counter Thresholds Configuration Command for ONT	367
6.6 Multicast TC-layer Performance Monitoring Command for ONT	369
6.7 Fec TC-layer Performance Monitoring Command for ONT	371
6.8 GPON port Aggregate Ethernet performance monitoring Configuration Commands	373
6.9 XGPON tc-layer port performance monitoring Configuration Commands	375
6.10 XGPON physical-layer port performance monitoring Configuration Commands	377
6.11 GPON ONT software delay activation control Configuration Commands	379
6.12 GPON ONT CPU Load Performance Monitoring Configuration Command	381
6.13 GPON ONT Memory Usage Performance Monitoring Configuration Command	383
6.14 ONT Card Configuration Command	385
6.15 ONT Software Control Configuration Command	388
6.16 GPON ONT software delay activation control Configuration Commands	390
6.17 ONT Interface Configuration Command	391
6.18 ONT GIS Configuration Command	393
6.19 ONT xgpon Configuration Command	395
7- Epon ONT Configuration Commands	397
7.1 Epon ONT Configuration Command Tree	398
7.2 EONT Interface Configuration Command	401
7.3 Epon Ont RSSI Configuration Command	405
7.4 Epon Ont Management Configuration Command	409
7.5 Epon Ont Ethernet Configuration Command	411
7.6 Epon Ont Ethernet Auto-Negotiation Configuration Command	415
7.7 Epon Ont LLID Configuration Command	419
7.8 Epon Ont RMS Configuration Command	421
7.9 EONT Software Control Configuration Command	423
8- Port Protection Configuration Commands	425
8.1 Port Protection Configuration Command Tree	426
8.2 Port Protection Configuration Command	427
9- xDSL Configuration Commands	429
9.1 xDSL Configuration Command Tree	431
9.2 xDSL Common Service Profile Configuration Command	440
9.3 xDSL Common Spectrum Profile Configuration Command	444
9.4 xDSL Artificial Noise Downstream Configuration Command	450
9.5 xDSL Spectrum Profile for ADSL/ADSL2 Configuration Command	452
9.6 xDSL Spectrum Profile for RE-ADSL2 Configuration Command	455
9.7 xDSL Spectrum Profile for ADSL2 Plus Configuration Command	457
9.8 ADSL2-plus Custom PSD shape Configuration Command	461
9.9 xDSL Spectrum Profile for VDSL Configuration Command	463
9.10 VDSL Ghs Tones Transmission Power Control Configuration Command	470
9.11 VDSL Custom PSD shape Downstream Configuration Command	472
9.12 VDSL Custom RX PSD shape Upstream Configuration Command	474

9.13 VDSL Power Back Off Configuration Command	476
9.14 xDSL Spectrum Profile for VDSL2 Configuration Command	477
9.15 VDSL2 Custom PSD shape Downstream Configuration Command	483
9.16 VDSL2 Custom PSD shape Upstream Configuration Command	485
9.17 VDSL2 Custom RX PSD shape Upstream Configuration Command	487
9.18 VDSL2 Virtual Noise Downstream Configuration Command	489
9.19 VDSL2 Virtual Noise Upstream Configuration Command	491
9.20 VDSL2 Power Back Off Configuration Command	493
9.21 xDSL DPBO Profile Configuration Command	495
9.22 xDSL DPBO Mode Independent Custom PSD Mask Configuration Command	497
9.23 xDSL DPBO Exchange PSD Mask Configuration Command	499
9.24 xDSL RTX Profile Configuration Command	501
9.25 xDSL Vectoring Profile Configuration Command	506
9.26 xDSL Sos Profile Configuration Command	509
9.27 xDSL Vectoring Control Entity Profile Configuration Command	512
9.28 xDSL Legacy UPBO Profile Configuration Command	515
9.29 xDSL Board Configuration Command	518
9.30 xDSL Board Vectoring Fallback Configuration Command	521
9.31 Xdsl Auto Port Reset Configurations	524
9.32 xDSL Vectoring Processing Board Configuration Command	526
9.33 xDSL Line Configuration Command	528
9.34 xDSL Line TCA Threshold Configuration Command	534
9.35 xDSL Per Line Override Configuration Command	537
9.36 xDSL Override Noise Psd Shape Downstream Configuration Command	544
9.37 xDSL Override Noise Psd Shape Upstream Configuration Command	546
9.38 xDSL INS Near End Configuration Command	548
9.39 xDSL INS Far End Configuration Command	550
10- Gpon xDSL Configuration Commands	552
10.1 Gpon xDSL Configuration Command Tree	553
10.2 Gpon xDSL Common Service Profile Configuration Command	556
10.3 Gpon xDSL Common Spectrum Profile Configuration Command	559
10.4 Gpon xDSL Spectrum Profile for VDSL Configuration Command	562
10.5 Gpon xDSL Spectrum Profile for VDSL2 Configuration Command	564
10.6 VDSL2 Custom PSD shape Downstream Configuration Command	567
10.7 VDSL2 Custom PSD shape Upstream Configuration Command	569
10.8 ONT VDSL2 Virtual Noise Downstream Configuration Command	571
10.9 ONT VDSL2 Virtual Noise Upstream Configuration Command	573
10.10 Gpon xDSL Line Configuration Command	575
10.11 Xdsl ONT Uni Physical Layer Configuration Command	580
10.12 Xdsl ONT Uni Layer 2 Configuration Command	583
10.13 Gpon xDSL DPBO Profile Configuration Command	585
10.14 Gpon xDSL DPBO Mode Independent Custom PSD Mask Configuration Command	587
10.15 Gpon xDSL DPBO Exchange PSD Mask Configuration Command	589
10.16 Gpon xDSL ONT Configuration Command	591
10.17 Gpon xDSL Common Rtx Profile Configuration Command	593
11- xDSL System Configuration Commands	596
11.1 xDSL System Configuration Command Tree	597
11.2 xDSL System Automatic Port Reset Configuration Command	598
12- ATM Configuration Commands	599
12.1 ATM Configuration Command Tree	600
12.2 ATM PVC Configuration Command	601
12.3 IPOA X-connect L2 interworking port Configuration Command	603
13- Interface Management Configuration Commands	605

13.1 Interface Management Configuration Command Tree	606
13.2 Network Interface Configuration Command	607
13.3 Extend Interface Configuration Command	613
13.4 Interface Alarm Configuration Command	614
13.5 Interface Sliding-Window Traffic Statistics Command	616
13.6 Cage mode configuration Command	617
14- Error Configuration Commands	619
14.1 Error Configuration Command Tree	620
14.2 Error Log Configuration Command	621
15- System Configuration Commands	622
15.1 System Configuration Command Tree	624
15.2 System Configuration Command	628
15.3 Configure system LEDs	632
15.4 System SNTP Configuration Command	633
15.5 System SNTP Server Table Configuration Command	634
15.6 System SNTP Server Table Configuration Command	635
15.7 System daylight saving time Configuration Command	636
15.8 System daylight saving time Configuration Command	637
15.9 System daylight saving time Configuration Command	638
15.10 System Loop ID Syntax Configuration Command	655
15.11 Maximum Lt Link Speed Configuration Command	658
15.12 System ONT Configuration Command	659
15.13 Epon System PM Configuration Command	661
15.14 System Synchronous Interface Timing Clock Configuration Command	662
15.15 System Clock Bits Mode Configuration Command	665
15.16 System Clock Source Priority Configuration Command	666
15.17 System Clock ToD Sources Priority Configuration Command	668
15.18 NTR PTP Configuration Command	670
15.19 NTR Clock Transmission Protocol Configuration Command	672
15.20 System Synchronous InterfaceTiming Clock Switching Mode configuration Command	674
15.21 NTR Acceptable Clock Master Configuration Command	675
15.22 PTP Slave Port DataSet Configuration Command	676
15.23 PTP Default Dataset Configuration Command	678
15.24 PTP Master Port DataSet Profile Configuration Command	680
15.25 PTP master port Configuration Commands	682
15.26 System Clock Synchronous Source port Configuration Command	685
15.27 PTP L2 port Configuration Commands	687
15.28 Clock ToD Parameters Configuration Command	689
15.29 1PPS ToD Interface Parameters Configuration Command	691
15.30 1PPS ToD Serial Parameters Configuration Command	693
15.31 ToD Holdover Specification Configuration Command	695
15.32 System Clock Synchronous Status Message Configuration Command	696
15.33 System Clock Synchronous Source port Configuration Command	699
15.34 System Clock Force Reference Configuration Command	701
15.35 SSMOut Configuration Command for synce ports	702
15.36 SSMOut Configuration Command for XDSL ports	704
15.37 T4 D-PLL Configuration Command	706
15.38 Synce Configuration Command for FELT-B ports	708
15.39 ALS State Configuration Command	710
15.40 Configure system auto-switch	711
15.41 ZTP (Zero Touch Provision) State Configuration Command	712
15.42 System Relay ID Syntax Configuration Command	713
15.43 FIPS Configuration Command	715
15.44 NT SFTP Server Configuration Command	716
15.45 NT SFTP Server Credentials Configuration Command	717

16- Security Configuration Commands	718
16.1 Security Configuration Command Tree	720
16.2 Security Banner Configuration Command	726
16.3 Operator Configuration Command	728
16.4 Profile Configuration Command	731
16.5 Default Profile Configuration Command	738
16.6 SNMP View Configuration Command	745
16.7 Security SNMP Community Configuration Command	747
16.8 Security SNMPv3 Group Configuration Command	750
16.9 Security SNMPv3 User Configuration Command	753
16.10 Security SNMPv3 User-Group Configuration Command	756
16.11 SNMP Notify View Configuration Command	758
16.12 Security SNMP Notification Profile Configuration Command	760
16.13 Security SNMP Notification Profile Filter Configuration Command	762
16.14 Security SNMP Element Manager Configuration Command	764
16.15 Security RADIUS Client Configuration Command	766
16.16 Security RADIUS Authentication Server Configuration Command	767
16.17 Security RADIUS Accounting Server Configuration Command	769
16.18 Security RADIUS Dynamic Authorization Client Configuration Command	771
16.19 Security RADIUS Policy Configuration Command	773
16.20 Security RADIUS Server Configuration Command	775
16.21 Security TACACS+ Client Configuration Command	777
16.22 Security TACACS+ Authentication Server Configuration Command	778
16.23 Security TACACS+ Authorization Server Configuration Command	780
16.24 Security TACACS+ Accounting Server Configuration Command	782
16.25 Security TACACS+ Policy Configuration Command	784
16.26 Security Tacacs+ Server Configuration Command	785
16.27 Security Domain Configuration Command	787
16.28 Security Connection Profile Configuration Command	789
16.29 Security Connection Policy Configuration Command	790
16.30 Security 802.1x PAE System Configuration Command	791
16.31 Security 802.1x Port Authentication Configuration Command	792
16.32 Security 802.1x Extension, Port Authentication Configuration Command	795
16.33 Security 802.1x Port Configuration Command	798
16.34 Security Password Policy Configuration Command	800
16.35 File Transfer Configure Command	802
16.36 file Transfer server Configure Commands	803
16.37 file Transfer server Configure Commands	805
16.38 PM File Upload Configure Command	807
16.39 5-min CDR File Upload Configure Command	810
16.40 Lawful Intercept Split Management Configuration Command	812
16.41 MAC Filter Configuration Command	813
16.42 NT slot Security Configuration Command	815
17- Secure Shell Configuration Commands	816
17.1 Secure Shell Configuration Command Tree	817
17.2 SSH Server Configuration Command	818
17.3 Secure Shell User Configuration Command	820
17.4 Secure Shell Access Configuration Command	821
17.5 Secure Shell SFTP User Configuration Command	824
18- Transaction Configuration Commands	826
18.1 Transaction Configuration Command Tree	827
18.2 Transaction Configuration Command	828
19- SYSLOG Configuration Commands	829

19.1 SYSLOG Configuration Command Tree	830
19.2 Syslog Configuration Commands	831
19.3 SYSLOG Destination Configuration command	832
19.4 SYSLOG Route Configuration Command	835
20- Software Management Configuration Commands	838
20.1 Software Management Configuration Command Tree	839
20.2 Software Replacement Mode Configuration Command	840
20.3 Software Management Overall Software Package Configuration Command	841
20.4 Database Automatic Activation Configure Command	845
21- QoS Configuration Commands	847
21.1 QoS Configuration Command Tree	849
21.2 QoS Configuration Command	856
21.3 QoS 802.1P Class-to-Queue Mapping Configuration Command	858
21.4 QoS Dsl Control Pkt Policer Configuration Command	860
21.5 QoS Nni Control Pkt Policer Configuration Command	862
21.6 QoS DSCP-to-Dot1P Alignment for L3 Forwarded Traffic Configuration Command	863
21.7 QoS Queue Profile Configuration Command	864
21.8 QoS Scheduler Node Profile Configuration Command	867
21.9 QoS CAC Profile Configuration Command	869
21.10 QoS Single Dot1P Marker Configuration Command	871
21.11 QoS Single DSCP Marker Configuration Command	872
21.12 QoS DSCP Contract Table Marker Configuration Command	873
21.13 QoS DSCP Contract Table Code-point Configuration Command For DSCP-contract	874
21.14 QoS Dot1P and DSCP Contract Table Marker Configuration Command	875
21.15 DSCP Contract Table Codepoint Configuration Command For D1p-dscp-contract	876
21.16 QoS Dot1P and Single DSCP Marker Configuration Command	877
21.17 QoS Dot1P Alignment Marker Configuration Command	878
21.18 QoS Dot1P Remark Table Marker Configuration Command	880
21.19 QoS Dot1P Remark Table Dot1p-value Configuration Command For Dot1P-Remark	881
21.20 QoS Policer Profile Configuration Command	882
21.21 QoS L2 Filter Profile Configuration Command	886
21.22 QoS L3 Filter Profile Configuration Command	888
21.23 QoS Policy Action Profile Configuration Command	891
21.24 QoS Policy Profile Configuration Command	893
21.25 QoS Session Profile Configuration Command	895
21.26 QoS Session Upstream Policy List Configuration Command	899
21.27 QoS Session Downstream Policy List Configuration Command	900
21.28 QoS Session remote Upstream Policy List Configuration Command	901
21.29 QoS Session Remote Downstream Policy List Configuration Command	902
21.30 QoS AggrQueuesConfig Profile Configuration Command	903
21.31 QoS Shaper Profile Configuration Command	912
21.32 QoS Bandwidth Profile Configuration Command	914
21.33 QoS IngressQoS Profile Configuration Command	916
21.34 QoS Rate Limit Profile Configuration Command	920
21.35 QoS DSCP to Pbit Mapping Profile Configuration Command	923
21.36 QoS DSCP to Pbit Mapping Profile Configuration Command	924
21.37 QoS DSCP to Tc Mapping Profile Configuration Command	925
21.38 QoS DSCP to Tc Mapping Profile Configuration Command	926
21.39 QoS Policer Per Tc Profile Configure	927
21.40 QoS Policer Per Tc Profile Configure	928
21.41 QoS CoS Threshold Profile Configuration Command	929
21.42 QoS Board-Level Queue and Performance Configuration Command	931
21.43 QoS Queue Threshold Crossing Alarm Configuration Command	933
21.44 QoS DSL Link Configuration Command	937
21.45 QoS LIM Queue Configuration Command	939
21.46 QoS ShdSL Link Configuration Command	941
21.47 QoS LIM Queue (SHDSL) Configuration Command	943

21.48 QoS Interface Configuration Command	945
21.49 QoS Interface Queue Configuration Command	952
21.50 QoS Interface Upstream Queue Configuration Command	956
21.51 QoS Interface Remote Downstream Queue Configuration Command	961
21.52 QoS Line Control Packets Rate Limit Configuration Command	965
21.53 P-bit Based Scheduling For SC Forwarder Cross Connect/Residential Bridge Configuration Command	967
21.54 QoS system level Up Control Packet DSCP/Pbit marking, TC mapping Configuration Command	969
21.55 QoS system level Dn Control Packet DSCP/Pbit marking, TC mapping Configuration Command	971
21.56 QoS handling of upstream protocols(ARP, PPPoE, DHCPv4/v6,ND and MLD) for DSL LT Configuration Command	973
22- VLAN Configuration Commands	974
22.1 VLAN Configuration Command Tree	975
22.2 VLAN General Configuration Command	977
22.3 Virtual MAC Configuration Command	978
22.4 VLAN Configuration Command	979
22.5 VLAN Filtering Database Configuration Command	990
22.6 VLAN Port Filtering Database Configuration Command	993
22.7 VLAN Protocol-based Configuration Command	996
22.8 Vlan Pbit Traffic Counter Configuration Command	999
22.9 Vlan Priority Regeneration Profile Configuration Command	1002
23- VLAN Tpid Configuration Commands	1004
23.1 VLAN Tpid Configuration Command Tree	1005
23.2 VLAN General Configuration Command	1006
24- Bridge Configuration Commands	1007
24.1 Bridge Configuration Command Tree	1008
24.2 Bridge General Configuration Command	1010
24.3 Bridge Port Configuration Command	1011
24.4 Bridge Port to VLAN Association Configuration Command	1018
24.5 L2 Static User Ip Address Configuration Command	1026
24.6 L2 Static User Ipv6 Address Configuration Command	1028
25- VLAN Tpid Configuration Commands	1030
25.1 VLAN Tpid Configuration Command Tree	1031
25.2 VLAN General Configuration Command	1032
26- VLAN Tpid Configuration Commands	1034
26.1 VLAN Tpid Configuration Command Tree	1035
26.2 VLAN General Configuration Command	1036
27- Li_VLAN Configuration Commands	1038
27.1 Li_VLAN Configuration Command Tree	1039
27.2 li_vlan Li Configuration Command	1040
28- ARP-RELAY Configuration Commands	1041
28.1 ARP-RELAY Configuration Command Tree	1042
28.2 Arp-Relay Statistics Configuration Command	1043
29- IGMP Configuration Commands	1046

29.1 IGMP Configuration Command Tree	1047
29.2 IGMP Channel Configuration Command	1049
29.3 IGMP Channel Permission Package Members Configuration Command	1054
29.4 IGMP Channel Preview Package Members Configuration Command	1057
29.5 IGMP Package Bitmaps Configuration Command	1060
29.6 IGMP System Configuration Command	1062
29.7 IGMP System CDR Type Configuration Command	1066
29.8 IGMP Vlan System Configuration Command	1067
29.9 IGMP Multicast Vlan Translation Command	1068
29.10 IGMP Multicast Pon Vlan Translation Command	1069
29.11 Igmp Multicast Service Context Configuration Command	1070
30- Multicast Configuration Commands	1071
30.1 Multicast Configuration Command Tree	1072
30.2 Multicast General Group Configuration Command	1074
30.3 General Multicast Package Members Configuration Command	1076
30.4 Multicast Capacity Configuration Command	1077
30.5 Multicast Channel Configuration Command	1078
30.6 Multicast Channel Package Members Configuration Command	1080
30.7 Multicast Channel Configuration Command	1081
30.8 Multicast Channel Package Members Configuration Command	1084
30.9 Multicast Ipv6 Channel Configuration Command	1085
30.10 Multicast Channel Package Members Configuration Command	1088
30.11 Multicast Monitoring Source Configuration Command	1089
30.12 Multicast Monitoring Channel Configuration Command	1090
30.13 Multicast Static Branch Configuration Command	1091
31- PPPoX-Relay Configuration Commands	1094
31.1 PPPoX-Relay Configuration Command Tree	1095
31.2 PPPoX Cross-connect Global Configuration Command	1096
31.3 PPPoX Cross-connect Engine Configuration Command	1098
31.4 PPPoX Cross-connect Engine Monitoring Configuration Command	1100
31.5 PPPCC Engine TCA Threshold Configuration Command	1101
31.6 PPPoX Cross-connect Client Port Configuration Command	1103
31.7 PPPoX Cross-connect Client Port Monitoring Configuration Command	1106
32- PPPoE Configuration Commands	1109
32.1 PPPoE Configuration Command Tree	1110
32.2 PPPoE Profile Configuration Command	1111
32.3 PPPoE Client Interface Configuration Command	1113
33- PPPoEL2STATS Configuration Commands	1116
33.1 PPPoEL2STATS Configuration Command Tree	1117
33.2 Pppoe-L2 Statistics Configuration Command	1118
34- DHCP Relay Configuration Commands	1121
34.1 DHCP Relay Configuration Command Tree	1122
34.2 DHCP Relay User Port Configuration Command	1123
34.3 DHCP v6 Relay User Port Configuration Command	1126
35- XDSL Bonding Configuration Commands	1129
35.1 XDSL Bonding Configuration Command Tree	1130
35.2 XDSL Bonding Assembly Level Configuration Command	1132
35.3 xDSL Bonding Group Profile Configuration Command	1134
35.4 xDSL Bonding Group Rtx Profile Configuration Command	1137
35.5 xDSL Bonding Configuration Command	1141

35.6 xDSL Bonding Configuration Command	1143
35.7 xDSL Bonding Board Configuration Command	1144
35.8 xDSL Bonding Board Vectoring Fallback Configuration Command	1145
36- CPE Remote Configuration Commands	1147
36.1 CPE Remote Configuration Command Tree	1148
36.2 CPE Remote Management System Configuration Commands	1149
36.3 CPE Manager Configuration Command	1150
36.4 CPE IPProxy Session Configuration Command	1151
37- SHDSL Configuration Commands	1152
37.1 SHDSL Configuration Command Tree	1153
37.2 SHDSL Span Configuration Command	1155
37.3 SHDSL Unit Configuration Command	1160
37.4 SHDSL Segment Configuration Command	1162
38- IMA Configuration Commands	1164
38.1 IMA Configuration Command Tree	1165
38.2 IMA Group Configuration Commands	1166
38.3 IMA Link Configuration Commands	1168
39- L2CP Configuration Commands	1169
39.1 L2CP Configuration Command Tree	1170
39.2 L2CP Configuration Command	1171
39.3 L2CP Session Configuration Command	1172
39.4 L2CP User Port Partition Configuration Command	1175
40- Voice Configuration Commands	1176
40.1 Voice Configuration Command Tree	1178
40.2 Voice Sip Server Configuration Commands	1191
40.3 Voice Sip Lineld Syntax Profile Configuration Commands	1195
40.4 Voice Sip User Agent Configuration Commands	1197
40.5 Sip Voice Service Gateway Configuration Commands	1203
40.6 Voice Sip User Agent Access Point Configuration Command	1210
40.7 Voice Sip Dial Plan Configuration Commands	1213
40.8 Voice Sip Dial Plan Digitmap Configuration Commands	1215
40.9 Voice Sip Termination Configuration Commands	1216
40.10 Voice Sip Termination TCA Threshold Configuration Command	1224
40.11 Voice Sip Shared Line Termination Configuration Commands	1226
40.12 Sip Voice Register Configuration Commands	1229
40.13 Voice Sip Transport Configuration Commands	1231
40.14 Voice Sip Redundancy Table Configuration Commands	1233
40.15 Voice Sip System Session Timer Configuration Commands	1239
40.16 Voice Sip DNS Server Configuration Commands	1241
40.17 Voice Sip DHCP Authentication Params Configuration Commands	1243
40.18 Voice Sip Restoration Failover/Failback Type/Mode Configuration Commands	1245
40.19 Voice Statistics Configure Command	1247
40.20 Voice Statistics Mode Configuration Command	1248
40.21 Voice Sip Isdn/Cas Termination Configuration Commands	1250
40.22 Voice Sip Isdn/Cas Termination Configuration Commands	1258
40.23 Voice Sip Manipulation Rule Configuration Commands	1267
40.24 Voice Sip Cas R2 Timer Configuration Commands	1269
40.25 Voice Sip PUID Configuration Commands	1271
40.26 Voice Sip PUID Configuration Commands	1273
40.27 Voice Sip Isdn Nsm Profile Configuration Commands	1275
40.28 Voice Sip Cas Nsm Profile Configuration Commands	1278

40.29 Voice Sip Pri User To User Profile Configuration Commands	1280
40.30 Voice Sip Isdn/Cas trunk sub-group Configuration Commands	1282
40.31 Voice Sip Physical Interface Configuration Commands	1285
40.32 Voice Sip Cas Signaling Profile Configuration Commands	1289
40.33 Central Access Point Table Configuration Commands	1292
40.34 Central Access Point Table Configuration Commands	1294
40.35 Voice Sip Cas Timer Profile Configuration Commands	1296
40.36 Network Element Table Configuration Commands	1301
40.37 Voice Sip Call Query Configuration Commands	1303
40.38 Voice Cluster Configuration Commands	1305
40.39 Voice Megaco IP Configuration Commands	1306
40.40 Voice Megaco Equipment Configuration Commands	1308
40.41 Voice Megaco Equipment Board Configuration Commands	1310
40.42 Voice Megaco Equipment Termination Configuration Commands	1312
40.43 Voice Megaco Termination Configuration Commands	1316
40.44 Voice Megaco Termination Lawful Intercept Configuration Commands	1318
40.45 Voice Megaco Equipment Secondary Termination Configuration Commands	1320
40.46 Voice Megaco Media Gateway Configuration Commands	1322
40.47 Voice Megaco Signal Gateway Configuration Commands	1333
40.48 Epon Ont Voice SIP UserAgent Configuration	1335
40.49 Epon Ont Pots Configuration Command	1338
40.50 Epon Ont Voice Common Configuration Command	1340
40.51 Epon Ont Voice media gateway Configuration Command	1343
40.52 Voice Sip LSA Server Configuration Commands	1346
40.53 Voice Sip LSA Server Configuration Commands	1348
40.54 Voice Sip LSA Server Emergency Service Configuration Commands	1351
40.55 Voice extline Configuration Commands	1353
40.56 Voice Pseudo Wire Configuration Commands	1357

41- Voice Ont Configuration Commands 1360

41.1 Voice Ont Configuration Command Tree	1362
41.2 Voice ONT Service Configuration Command	1369
41.3 Performance Monitoring configuration command for VOIP service	1374
41.4 Voice ONT POTS Configuration Command	1376
41.5 Voice ONT Voice-Port Configuration Command	1380
41.6 GPON Authentication Security Profile Configuration Command	1384
41.7 Voice ONT Secure URI profile Configuration command	1386
41.8 GPON URI Profile Configuration Command	1388
41.9 GPON Tone Pattern Profile Configuration Command	1389
41.10 GPON Tone Pattern Sequence Profile Configuration Command	1391
41.11 Tone Event Profile Configuration Command	1395
41.12 GPON Busy Tone Event Profile Configuration Command	1396
41.13 GPON First Call Wait Tone Event Profile Configuration Command	1398
41.14 GPON Second Call Wait Tone Event Profile Configuration Command	1400
41.15 GPON Third Call Wait Tone Event Profile Configuration Command	1402
41.16 GPON Fourth Call Wait Tone Event Profile Configuration Command	1404
41.17 GPON Alert Tone Event Profile Configuration Command	1406
41.18 GPON Special Dial Tone Event Profile Configuration Command	1408
41.19 GPON Special Info Tone Event Profile Configuration Command	1410
41.20 GPON Release Tone Event Profile Configuration Command	1412
41.21 GPON Congest Tone Event Profile Configuration Command	1414
41.22 GPON Confirm Tone Event Profile Configuration Command	1416
41.23 GPON Dial Tone Event Profile Configuration Command	1418
41.24 GPON Message Wait Tone Event Profile Configuration Command	1420
41.25 GPON Reorder Tone Event Profile Configuration Command	1422
41.26 GPON Ring Back Tone Event Profile Configuration Command	1424
41.27 GPON Roh Tone Event Profile Configuration Command	1426
41.28 GPON Stutter Tone Event Profile Configuration Command	1428
41.29 GPON Intrusion Tone Event Profile Configuration Command	1430

41.30 GPON Dead Tone Event Profile Configuration Command	1432
41.31 GPON First User Defined Tone Event Profile Configuration Command	1434
41.32 GPON Second User Defined Tone Event Profile Configuration Command	1436
41.33 GPON Third User Defined Tone Event Profile Configuration Command	1438
41.34 GPON Fourth User Defined Tone Event Profile Configuration Command	1440
41.35 GPON Network Dial Plan Profile Configuration Command	1442
41.36 Create a RTP profile	1444
41.37 Create a Voice Service profile	1446
41.38 Create a VOIP Application Service Profile	1449
41.39 Create a VOIP media profile	1454
41.40 GPON Ringing Pattern Profile Configuration Command	1460
41.41 GPON Ringing Pattern Sequence Profile Configuration Command	1462
41.42 GPON Ring Event Profile Configuration Command	1465
41.43 GPON VOIP Feature Access Codes Profile Configuration Command	1468
41.44 GPON Common VOIP Configuration Command	1471
41.45 GPON Voice ONT POTS Rtp PM Mode Configuration Command	1473
41.46 GPON ONT SIP Configuration Command	1475
41.47 Voice Ont SIP Agent PM Mode Configuration Command	1479
41.48 Voice Ont SIP Agent Call PM Mode Configuration Command	1481
41.49 Configure ont POT SIP	1483
41.50 Voice ONT MGC Configuration command	1487
41.51 Voice ONT MGC PM monitoring command	1491
41.52 Voice Ont Pots Call PM Mode Configuration Command	1493
42- Debug Configuration Commands	1495
42.1 Debug Configuration Command Tree	1496
42.2 Protocol Tracing Configuration Command	1497
43- Ethernet User Ports Configuration Commands	1500
43.1 Ethernet User Ports Configuration Command Tree	1501
43.2 Ethernet Line Configuration Command	1502
43.3 Ethernet Line TCA Threshold Configuration Command	1504
43.4 Ethernet Line Mau Configuration Command	1506
44- ONT Ethernet Port Configuration Command	1509
44.1 ONT Ethernet Port Configuration Command Tree	1510
44.2 ONT Ethernet Port Configuration Command	1511
44.3 ONT Ethernet Port Physical Layer Performance Monitoring Configuration Command	1515
44.4 Ethernet ONT Uni Physical Layer Configuration Command	1517
44.5 Ethernet ONT Uni Layer 2 Configuration Command	1519
44.6 L2 UNI ONT Performance Monitor Extended 32bit Configuration Command	1521
44.7 UNI Port Shutdown-Ais Configuration Commands	1523
45- Epon Ont Ethernet Configuration Command	1525
45.1 Epon Ont Ethernet Configuration Command Tree	1526
45.2 Epon Ont ethernet Configuration Command	1527
45.3 Epon Ont Flow Configuration Command	1528
45.4 Epon Ont Ethernet Multicast Vlan Configuration Command	1530
45.5 Epon Ont Ethernet Vlan Translation Configuration Command	1532
45.6 Epon Ont Ethernet Multicast Vlan Translation Configuration Command	1534
46- Efm Oam Configuration Commands	1536
46.1 Efm Oam Configuration Command Tree	1537
46.2 Efm Oam Interface ConfigurationCommand	1538
47- CFM Configuration Commands	1540

47.1 CFM Configuration Command Tree	1541
47.2 Maintenance Domain Configuration Command	1543
47.3 Maintenance Association Configuration Command	1545
47.4 Maintenance Association End Point Configuration Command	1549
47.5 MEP located on ONU UNI enabled ITU-T Y.1731 Ethernet Alarm Indication Signal(ETH-ALM) function Configuration Commands	1553
47.6 Active Remote Maintenance Association End Point Configuration Command	1555
47.7 Remote Maintenance Association End Point Configuration Command	1556
47.8 Synthetic Loss Measurement configuration Commands	1557
47.9 CFM PM-Proactive test management Command	1558
47.10 CFM PM Proactive test management Command	1559
48- Trouble-Shooting Configuration Commands	1561
48.1 Trouble-Shooting Configuration Command Tree	1562
48.2 Trouble-shooting Interface Configuration Commands	1563
49- Trouble-Shooting Pbit Counter Configuration Command	1566
49.1 Trouble-Shooting Pbit Counter Configuration Command Tree	1567
49.2 Trouble-shooting pbit counter Interface Configuration Commands	1568
50- Trouble-Shooting Pon Interface Configuration Command	1571
50.1 Trouble-Shooting Pon Interface Configuration Command Tree	1572
50.2 Trouble-shooting Pon Interface Configuration Commands	1573
50.3 Trouble-Shooting threshold Configuration Commands	1574
50.4 Trouble shooting Configuration Command	1575
51- Trouble-Shooting Color Counter Configuration Command	1577
51.1 Trouble-Shooting Color Counter Configuration Command Tree	1578
51.2 Trouble-shooting color counter Interface Configuration Commands	1579
52- IPoA/E IW Configuration Commands	1581
52.1 IPoA/E IW Configuration Command Tree	1582
52.2 IPoA/E IW Interworking Port Configuration Command	1583
52.3 IPoA/E IW Gateway Configuration Command	1585
53- LineTest Configuration Commands	1586
53.1 LineTest Configuration Command Tree	1587
53.2 Megaco LineTest Session Configuration Command	1589
53.3 Megaco LineTest Line Configuration Command	1593
53.4 MEGACO LineTest Param Configuration Command	1595
53.5 SINGLE LineTest Session Configuration Command	1600
53.6 SINGLE LineTest Line Configuration Command	1606
53.7 SINGLE LineTest Param Configuration Command	1608
54- LACP Configuration Commands	1614
54.1 LACP Configuration Command Tree	1615
54.2 LACP general configuration command	1616
54.3 LACP port configuration command	1617
54.4 LACP group configuration command	1618
54.5 LACP Group Port configuration command	1620
55- MSTP Configuration Commands	1621
55.1 MSTP Configuration Command Tree	1622
55.2 MSTP general configuration Command	1623

55.3 MSTP Instance configuration Command	1625
55.4 MSTP Vlan-Instance Mapping configuration Command	1626
55.5 MSTP Port configuration Command	1627
55.6 MSTP Port-Instance configuration Command	1629
56- Application Intelligence Configuration Commands	1631
56.1 Application Intelligence Configuration Command Tree	1632
56.2 Application configuration command	1633
56.3 AI Platform configuration command	1634
56.4 Application 'download and installation' configuration command	1636
57- NGpon2 Channel Group/Sub Channel Group Configuration Commands	1638
57.1 NGpon2 Channel Group/Sub Channel Group Configuration Command Tree	1639
57.2 NGpon2 Channel Group Configuration Command	1640
57.3 NGpon2 Channel Group Member Association Command	1642
57.4 NGpon2 Sub Channel Group Configuration Command	1643
57.5 NGpon2 Sub Channel Group Member Association Command	1646
58- Pon Configuration Commands	1647
58.1 Pon Configuration Command Tree	1648
58.2 Pon Configuration Command	1651
58.3 Pon Interface Configuration Command	1652
58.4 Pon GEM Port Performance Monitoring Configuration Command	1657
58.5 OLT-SIDE TC-layer Performance Monitoring Counter Thresholds Configuration Command for PON	1659
58.6 Multicast TC-layer Performance Monitoring Command for PON	1661
58.7 XGPON Physical-layer Performance Monitoring Command for PON	1663
58.8 XGPON Upstream FEC Performance Monitoring Command for PON	1665
58.9 XGPON TC-layer Performance Monitoring Command for PON	1667
58.10 OTDR enable Command for PON	1669
58.11 PON Utilization PM Configuration Command	1671
58.12 PON Utilization TCA Threshold Configuration Command	1673
58.13 Deactivate Ont threshold Configuration Commands	1679
58.14 Deactivate Ont threshold Configuration Commands	1681
58.15 Deactivate Ont threshold Configuration Commands	1683
58.16 Power Shedding Profile Configuration Command	1685
58.17 Voice ONT Secure URI profile Configuration command	1687
58.18 GPON Authentication Security Profile Configuration Command	1689
58.19 GPON URI Profile Configuration Command	1691
59- Uni Ont Configuration Commands	1692
59.1 Uni Ont Configuration Command Tree	1693
59.2 Uni Ont Video Configuration Command	1694
59.3 Uni Ont TC layer Ccounters Configuration Command	1696
60- CES Configuration Commands	1698
60.1 CES Configuration Command Tree	1699
60.2 CES Maintenance Profile Configuration Command	1701
60.3 CES Service Port Provisioning Configuration Command	1703
60.4 CES Service PM Mode Configuration Command	1706
60.5 CES Service Configuration Command	1708
60.6 CES Service Gem Port Configuration Command	1713
60.7 CES Service Configuration Command	1715
61- ANI ONT Configuration Commands	1717
61.1 ANI ONT Configuration Command Tree	1718

61.2 ANI ONT Thershold Configuration Command	1719
61.3 ANI ONT Video Configuration Command	1721
62- ONT HPNA Configuration Commands	1723
62.1 ONT HPNA Configuration Command Tree	1724
62.2 ONT HPNA Configuration Command	1725
62.3 ONT HPNA L2 Port Performance Monitoring Configuration Command	1728
62.4 Hpna ONT Uni Layer 2 Configuration Command	1730
63- L2UNI Configuration Commands	1732
63.1 L2UNI Configuration Command Tree	1733
63.2 L2 UNI ONT Performance Monitor Configuration Command	1734
63.3 L2 UNI ONT Performance Monitor Extended 32bit Configuration Command	1736
63.4 TC-layer Performance Monitoring Counter Thresholds Configuration Command for ONTL2UNI	1738
64- IpHost Configuration Commands	1740
64.1 IpHost Configuration Command Tree	1741
64.2 Voice Ont IP-Host Configuration Command	1742
64.3 Voice Ont IP-Host PM Mode Configuration Command	1746
65- ONT VEIP Configuration Commands	1748
65.1 ONT VEIP Configuration Command Tree	1749
65.2 ONT VEIP Configuration Command	1750
65.3 ONT VEIP Port L2 Performance Monitoring Configuration Command	1752
65.4 Veip ONT Uni Layer 2 Configuration Command	1754
65.5 L2 UNI ONT Performance Monitor Extended 32bit Configuration Command	1757
66- MoCA Configuration Commands	1759
66.1 MoCA Configuration Command Tree	1760
66.2 MoCA ONT Uni Configuration Command	1761
66.3 MoCA ONT Uni Physical Layer Configuration Command	1764
66.4 MoCA ONT Uni Layer 2 Configuration Command	1766
67- Configure NTP parameters on a specific ONT	1768
67.1 Configure NTP parameters on a specific ONT Tree	1769
67.2 Configure NTP parameters on a specific ONT	1770
68- Channel Pair Configuration Commands	1772
68.1 Channel Pair Configuration Command Tree	1773
68.2 Channel Pair Profiles Configuration Command	1775
68.3 Channel-Pair Wavelength Profile Configuration Command	1776
68.4 Channel Pair Interface Configuration Command	1778
68.5 Channel Pair XGEM Port Performance Monitoring Configuration Command	1782
68.6 OLT-SIDE TC-layer Performance Monitoring Counter Thresholds Configuration Command for channel pair	1784
68.7 Multicast TC-layer Performance Monitoring Command for channel pair	1786
68.8 NGPON2 Physical-layer Performance Monitoring Command for channel pair	1788
68.9 NGPON2 Upstream FEC Performance Monitoring Command for channel pair	1790
68.10 NGPON2 TC-layer Performance Monitoring Command for channel pair	1792
68.11 Trouble shooting Configuration Command	1794
68.12 Trouble-shooting Interface Configuration Commands	1795
68.13 Trouble shooting Configuration Command	1796
68.14 Channel Pair Utilization PM Configuration Command	1797
68.15 Channel Pair Utilization TCA Threshold Configuration Command	1799

68.16 Deactivate Ont threshold Configuration Commands	1805
68.17 Deactivate Ont threshold Configuration Commands	1807
68.18 Deactivate Ont threshold Configuration Commands	1809
68.19 Trouble-Shooting threshold Configuration Commands	1811
69- Epon Configuration Commands	1812
69.1 Epon Configuration Command Tree	1813
69.2 Epon Interface Configuration Command	1814
69.3 OTDR enable Command for PON	1818
70- Epon Profile Configuration Commands	1819
70.1 Epon Profile Configuration Command Tree	1820
70.2 Epon Filter Profile Configuration Command	1822
70.3 Epon Digit Map Profile Configuration Command	1829
70.4 Epon Alarm Control Profile Configuration Command	1830
71- Epon Profile Configuration Commands	1833
71.1 Epon Profile Configuration Command Tree	1834
71.2 OTDR enable Command for PON	1835
72- Tr069 Server Management Configuration Commands	1836
72.1 Tr069 Server Management Configuration Command Tree	1837
72.2 ONT Tr069 Configuration Command	1838
73- Snmp Agent Management Configuration Commands	1840
73.1 Snmp Agent Management Configuration Command Tree	1841
73.2 ONT Snmp-agent Configuration Command	1842
74- Distributed Router Configuration Commands	1844
74.1 Distributed Router Configuration Command Tree	1845
74.2 Drouter IP Configuration Command	1846
74.3 Inbound MPLS LSP Configuration Command	1848
74.4 Static Outbound MPLS LSP Configuration Command	1849
74.5 SDP Configuration Command	1851
75- Distributed Service Configuration Commands	1852
75.1 Distributed Service Configuration Command Tree	1853
75.2 Distributed Service Configuration Command	1854
75.3 SDP Binding Configuration Command	1856
75.4 APIPE SDP Binding Configuration Command	1857
75.5 VCL Binding Configuration Command	1858
76- BCMP Configuration Commands	1860
76.1 BCMP Configuration Command Tree	1861
76.2 BCMP system Configuration Commands	1862
77- System Level Generic Pon Config Commands	1863
77.1 System Level Generic Pon Config Command Tree	1864
77.2 Generic PON Data Path Integrity Threshold command	1866
77.3 Generic PON Utilization PM Mode Configuration Command	1867
77.4 Generic PON Utilization TCA Threshold Configuration Command	1868
77.5 System ONT Configuration Command	1874
77.6 Power Shedding Profile Configuration Command	1876

77.7 OLT GIS info Configuration Command	1878
77.8 System PONLOS Alarm Re-define Switch	1880
78- CLI Alias Configuration Command	1881
78.1 CLI Alias Configuration Command Tree	1882
78.2 CLI Alias Configuration Command	1883
79- Dhcp-Server Configuration Data	1884
79.1 Dhcp-Server Configuration Data Tree	1885
79.2 Dhcp-Server Configuration Data	1886
80- Cwmp platform Configuration Commands	1887
80.1 Cwmp platform Configuration Command Tree	1888
80.2 Cwmp Platform Configuration Commands	1889
81- NAPT aging-time configuration Command	1890
81.1 NAPT aging-time configuration Command Tree	1891
81.2 NAPT aging-time configuration Command	1892
82- E1 Configuration Commands	1893
82.1 E1 Configuration Command Tree	1894
82.2 E1 Configuration Command	1895
83- LLDPMed Configuration Commands	1897
83.1 LLDPMed Configuration Command Tree	1898
83.2 LLDPMed Configuration Command	1899
83.3 LLDP port configuration	1900
83.4 LLDP MED Local Media Policy configuration	1903
84- Dual-Parenting Configuration Commands	1906
84.1 Dual-Parenting Configuration Command Tree	1907
85- Dual-Parenting ProtGrp Configuration Commands	1908
85.1 Dual-Parenting ProtGrp Configuration Command Tree	1909
85.2 Dual-Parenting ProtGrp Configuration Command	1910
86- Dual-Parenting local-node Configuration Commands	1912
86.1 Dual-Parenting local-node Configuration Command Tree	1913
86.2 Dual-Parenting local-node Configuration Command	1914
87- Dual-Parenting peer-node Configuration Commands	1915
87.1 Dual-Parenting peer-node Configuration Command Tree	1916
87.2 Dual-Parenting peer-node Configuration Command	1917
88- Interface Management Configuration Commands	1918
88.1 Interface Management Configuration Command Tree	1919
88.2 TC-layer Performance Monitoring Command	1920
89- IPv6 Configuration Commands	1922
89.1 IPv6 Configuration Command Tree	1923
89.2 ipv6 anti-spoofing Configuration Command	1924

90- Mcast control Configuration Commands	1925
90.1 Mcast control Configuration Command Tree	1926
90.2 mcast Channel Configuration Command	1928
90.3 IGMP Channel Permission Package Members Configuration Command	1933
90.4 IGMP Channel Preview Package Members Configuration Command	1936
90.5 mcast System Configuration Command	1939
90.6 IGMP System CDR Type Configuration Command	1943
90.7 MLD Vlan System Configuration Command	1944
90.8 MLD Vlan System Configuration Command	1945
90.9 IGMP Vlan System Configuration Command	1946
90.10 IGMP Vlan System Configuration Command	1947
90.11 mcast Multicast Vlan Translation Command	1948
90.12 Multicast Pon Vlan Translation Command	1949
90.13 Multicast Service Context Configuration Command	1950
90.14 mcast Package Bitmaps Configuration Command	1951
 91- Equipment Status Commands	 1953
91.1 Equipment Status Command Tree	1954
91.2 Slot Status Command	1955
91.3 Profile Description Command	1961
91.4 Applique Status Command	1962
91.5 Shelf Summary Status Command	1966
91.6 Protection Element Status Command	1968
91.7 Protection Group Status Command	1971
91.8 External-link-host Status Commands	1974
91.9 External-link-remote Status Commands	1978
91.10 SFP/XFP Diagnostics Status Command	1981
91.11 SFP/XFP Diagnostics Status Command	1988
91.12 Sfp RSSI Configuration Command	1995
91.13 Board Temperature Status Command	1996
91.14 Board Planned Resource Command	1998
91.15 Transceiver Inventory Status Command	2000
91.16 NE Status Command	2008
91.17 Rack Status Command	2010
91.18 Shelf Status Command	2012
91.19 Power Supply Status Command	2016
 92- ONT Status Commands	 2020
92.1 ONT Status Command Tree	2022
92.2 ONT Interface Command	2025
92.3 ONT Interface Operational Status Command	2029
92.4 ONT Card Status Command	2035
92.5 ONT Software Control Status Command	2038
92.6 ONT Software Version Status Command	2039
92.7 ONT Software Download Status Command	2040
92.8 ONT Data Store Status Command	2044
92.9 ONT Optics Status Command	2046
92.10 ONT Optics History Status Command	2049
92.11 ONT Power Shedding Status Command	2053
92.12 GPON ont Olt-side on-demand Aggregate gem Current-Interval Performance Monitoring Command	2055
92.13 GPON ont Olt-side on-demand aggregate gem Previous-Interval Performance Monitoring Command	2057
92.14 GPON ont Ont-side aggregate gem Current-Interval Performance Monitoring Command	2059
92.15 GPON ont Ont-side Aggregate gem Previous-Interval Performance Monitoring Command	2061
92.16 GPON ont Olt-side Always-on Aggregate gem Current-Interval Performance Monitoring	2063

Command	
92.17 GPON Ont Olt-side Always-on Aggregate gem Previous-Interval Performance Monitoring Command	2065
92.18 Multicast TC-layer Current Interval Performance Data Status Command	2067
92.19 Multicast TC-layer Previous Interval Performance Data Status Command	2069
92.20 Fec TC-layer Current Interval Counters Command	2071
92.21 Olt-side FEC TC-layer Current Interval Counters Command	2073
92.22 ONT Software Control List Status Command	2075
92.23 GPON ont pon aggregate ethernet Current-Interval Performance Monitoring Command	2077
92.24 GPON ont pon Aggregate ethernet Previous-Interval Performance Monitoring Command	2079
92.25 GPON ont pon aggregate ethernet total Performance Monitoring Command	2082
92.26 Olt-side Physical-layer Current Interval Counters Command	2084
92.27 XGPON ONT Ont-side tc-layer Current-Interval Performance Monitoring Command	2086
92.28 XGPON ONT Ont-side tc-layer Previous-Interval Performance Monitoring Command	2088
92.29 XGPON ONT Olt-side tc-layer Current-Interval Performance Monitoring Command	2090
92.30 XGPON ONT Olt-side tc-layer Previous-Interval Performance Monitoring Command	2092
92.31 ONT Utilization Current Interval PM Command	2094
92.32 ONT Utilization Previous Interval PM Command	2096
92.33 ONT Configure File Download Status Command	2098
92.34 ONT Configure File Download Status Command	2103
92.35 ONT Config File Download Status Per Channel Group/Sub Channel Group Command	2104
92.36 ONT Index Lookup Command	2110
92.37 ONT Gis Info Command	2112
92.38 XGPON ONT Olt-side Performance Monitoring Command	2114
92.39 XGPON ONT Previous-Interval Performance Monitoring Command	2117
92.40 GPON ONT Memory Usage Current-Interval Performance Monitoring Command	2120
92.41 GPON ONT Memory Usage Previous-Interval Performance Monitoring Command	2122
92.42 GPON ONT CPU Load Current-Interval Performance Monitoring Command	2124
92.43 GPON ONT CPU Load previous-Interval Performance Monitoring Command	2126
93- ONT Ranging Status Commands	2128
93.1 ONT Ranging Status Command Tree	2129
93.2 ONT Channel-group Ranging Status Command	2130
93.3 ONT Channel-pair Ranging Status Command	2133
94- ONT Software Download Status Command	2135
94.1 ONT Software Download Status Command Tree	2136
94.2 ONT Software Download Status Per Channel Group/Sub Channel Group Command	2137
95- ONT Status Commands	2141
95.1 ONT Status Command Tree	2142
95.2 GPON ONT Status Command	2143
95.3 GPON ONT Status Command	2146
95.4 GPON ONT Status Command	2149
95.5 NGPON ONT Status Command	2152
96- Epon Ont Status Command	2156
96.1 Epon Ont Status Command Tree	2157
96.2 EONT Interface Status Command	2158
96.3 Epon Ont Optics Status Command	2163
96.4 Epon Ont LLID Status Command	2166
96.5 EONT Software Version Status Command	2168
96.6 Epon Pon Performance Statistics Command	2169
96.7 Epon Ont Current 15min Status Command	2170
96.8 Epon Ont Current 1day Status Command	2174
96.9 Epon Ont Previous 15min Status Command	2178

96.10 Epon Ont Previous 1day Status Command	2182
96.11 Epon Ont Mac Mapping Command	2186
96.12 Epon Ont Loid Mapping Command	2188
97- show tc-layer pm data	2190
97.1 show tc-layer pm data Tree	2191
97.2 show TC-layer ONT side Current Interval Performance Data Status Command	2192
97.3 show TC-layer ONT side Previous Interval Performance Data Status Command	2194
98- Protection Group Status Commands	2196
98.1 Protection Group Status Command Tree	2197
98.2 Protection Group Status Command	2198
99- Trap Status Commands	2201
99.1 Trap Status Command Tree	2202
99.2 Trap Manager Queue Status Command	2203
99.3 Trap Manager Queue Status Command	2204
100- Alarm Delta Log Status Commands	2205
100.1 Alarm Delta Log Status Command Tree	2206
100.2 Alarm Generic Delta Alarm Log Status Command	2207
100.3 Indeterminate Alarm Delta Log Status Command	2209
100.4 Warning Alarm Delta Log Status Command	2264
100.5 Minor Alarm Delta Log Status Command	2319
100.6 Major Alarm Delta Log Status Command	2374
100.7 Critical Alarm Delta Log Status Command	2429
101- query current alarms by filters	2484
101.1 query current alarms by filters Tree	2487
101.2 show current alarm by filters	2500
101.3 show current alarm by filters	2509
101.4 show current alarm by filters	2518
101.5 show current alarm by filters	2528
101.6 show current alarm by filters	2538
101.7 show current alarm by filters	2548
101.8 show current alarm by filters	2557
101.9 show current alarm by filters	2565
101.10 show current alarm by filters	2573
101.11 show current alarm by filters	2582
101.12 show current alarm by filters	2591
101.13 show current alarm by filters	2600
101.14 show current alarm by filters	2608
101.15 show current alarm by filters	2616
101.16 show current alarm by filters	2625
101.17 show current alarm by filters	2634
101.18 show current alarm by filters	2642
101.19 show current alarm by filters	2650
101.20 show current alarm by filters	2658
101.21 show current alarm by filters	2666
101.22 show current alarm by filters	2675
101.23 show current alarm by filters	2684
101.24 show current alarm by filters	2694
101.25 show current alarm by filters	2703
101.26 show current alarm by filters	2712
101.27 show current alarm by filters	2722
101.28 show current alarm by filters	2730

101.29 show current alarm by filters	2738
101.30 show current alarm by filters	2746
101.31 show current alarm by filters	2755
101.32 show current alarm by filters	2764
101.33 show current alarm by filters	2774
101.34 show current alarm by filters	2783
101.35 show current alarm by filters	2793
101.36 show current alarm by filters	2803
101.37 show current alarm by filters	2811
101.38 show current alarm by filters	2820
101.39 show current alarm by filters	2828
101.40 show current alarm by filters	2837
101.41 show current alarm by filters	2846
101.42 show current alarm by filters	2855
101.43 show current alarm by filters	2863
101.44 show current alarm by filters	2871
101.45 show current alarm by filters	2880
101.46 show current alarm by filters	2888
101.47 show current alarm by filters	2897
101.48 show current alarm by filters	2906
101.49 show current alarm by filters	2915
101.50 show current alarm by filters	2924
101.51 show current alarm by filters	2933
101.52 show current alarm by filters	2942
101.53 show current alarm by filters	2951
101.54 show current alarm by filters	2960
101.55 show current alarm by filters	2970
101.56 show current alarm by filters	2980
101.57 show current alarm by filters	2990
101.58 show current alarm by filters	3000
101.59 show current alarm by filters	3009
101.60 show current alarm by filters	3018
101.61 show current alarm by filters	3026
101.62 show current alarm by filters	3034
101.63 show current alarm by filters	3045
101.64 show current alarm by filters	3053
101.65 show current alarm by filters	3062
101.66 show current alarm by filters	3073
101.67 show current alarm by filters	3082
101.68 show current alarm by filters	3092
101.69 show current alarm by filters	3100
101.70 show current alarm by filters	3109
101.71 show current alarm by filters	3118
101.72 show current alarm by filters	3126
101.73 show current alarm by filters	3135
101.74 show current alarm by filters	3144
101.75 show current alarm by filters	3153
101.76 show current alarm by filters	3162
101.77 show current alarm by filters	3171
101.78 show current alarm by filters	3180
101.79 show current alarm by filters	3188
101.80 show current alarm by filters	3196
101.81 show current alarm by filters	3206
101.82 show current alarm by filters	3215
101.83 show current alarm by filters	3223
101.84 show current alarm by filters	3231
101.85 show current alarm by filters	3239
101.86 show current alarm by filters	3247
101.87 show current alarm by filters	3256
101.88 show current alarm by filters	3265

101.89 show current alarm by filters	3273
101.90 show current alarm by filters	3281
101.91 show current alarm by filters	3295
101.92 show current alarm by filters	3308
101.93 show current alarm by filters	3317
101.94 show current alarm by filters	3327
101.95 show current alarm by filters	3337
101.96 show current alarm by filters	3345
101.97 show current alarm by filters	3353
101.98 show current alarm by filters	3363
101.99 show current alarm by filters	3373
101.100 show current alarm by filters	3381
101.101 show current alarm by filters	3389
101.102 show current alarm by filters	3397
101.103 show current alarm by filters	3405
101.104 show current alarm by filters	3413
101.105 show current alarm by filters	3422
101.106 show current alarm by filters	3432
101.107 show current alarm by filters	3440
101.108 show current alarm by filters	3448
101.109 show current alarm by filters	3456
101.110 show current alarm by filters	3464
101.111 show current alarm by filters	3473
101.112 show current alarm by filters	3483
101.113 show current alarm by filters	3491
101.114 show current alarm by filters	3500
101.115 show current alarm by filters	3509
101.116 show current alarm by filters	3522
101.117 show current alarm by filters	3530
101.118 show current alarm by filters	3540
101.119 show current alarm by filters	3548
101.120 show current alarm by filters	3556
101.121 show current alarm by filters	3565
101.122 show current alarm by filters	3573
101.123 show current alarm by filters	3582
101.124 show current alarm by filters	3590
101.125 show current alarm by filters	3598
101.126 show current alarm by filters	3606
101.127 show current alarm by filters	3614
101.128 show current alarm by filters	3622
101.129 show current alarm by filters	3630
101.130 show current alarm by filters	3640
101.131 show current alarm by filters	3651
101.132 show current alarm by filters	3662
101.133 show current alarm by filters	3673
101.134 show current alarm by filters	3681
101.135 show current alarm by filters	3692
101.136 show current alarm by filters	3701
101.137 show current alarm by filters	3712
101.138 show current alarm by filters	3721
101.139 show current alarm by filters	3730
101.140 show current alarm by filters	3738
101.141 show current alarm by filters	3853
101.142 show current alarm by filters	3864
101.143 show current alarm by filters	3873
101.144 show current alarm by filters	3881
101.145 show current alarm by filters	3889

102- Alarm Log Status Commands

3898

102.1 Alarm Log Status Command Tree	3902
102.2 Alarm Log Status Command	3908
102.3 Equipment Alarm Log Status Command	3915
102.4 Equipment Holder Alarm Log Status Command	3919
102.5 Equipment Holder Extended Alarm Log Status Command	3923
102.6 Plug-in Unit Alarm Log Status Command	3926
102.7 ATM Alarm Log Status Command	3931
102.8 Ethernet Interface Alarm Log Status Command	3933
102.9 Software Management Alarm Log Status Command	3935
102.10 Temporal Filter Alarm Log Status Command	3938
102.11 Spatial Filter Alarm Log Status Command	3946
102.12 xDSL Common Alarm Log Status Command	3954
102.13 xDSL Near-end Alarm Log Status Command	3957
102.14 xDSL Far-end Alarm Log Status Command	3960
102.15 TCA xDSL Alarm Log Status Command	3964
102.16 Protection Group Alarm Log Status Command	3971
102.17 Vectoring Line Alarm Log Status Command	3975
102.18 Vectoring Board Alarm Log Status Command	3978
102.19 Electrical-to-Optical Conversion Alarm Log Status Command	3981
102.20 Authentication Alarm Log Status Command	3983
102.21 xDSL Bonding Alarm Log Status Command	3986
102.22 Redundancy Alarm Log Status Command	3990
102.23 Custom Alarm Log Status Command	3992
102.24 SFP Alarm Log Status Command	3998
102.25 Custom External Alarm Log Status Command	4002
102.26 SFP RSSI for NT Alarm Log Status Command	4004
102.27 PPP Cross-Connect Engine TCA Alarm Log Status Command	4009
102.28 Epon Olt Sfp RSSI Log Alarm Status Command	4011
102.29 2xE1/DS1 SFP Clock Alarm Log Status Command	4015
102.30 2xE1/DS1 SFP Framers Alarm Log Status Command	4018
102.31 Plug In Unit Extended Alarm Log Status Command	4022
102.32 SIP Server Alarm Log Status Commands	4027
102.33 SIP VSP Alarm Log Status Commands	4029
102.34 SIP Dial Plan Alarm Log Status Commands	4033
102.35 SIP User Agent Alarm Log Status Commands	4034
102.36 SIP Slot Alarm Log Status Commands	4036
102.37 SIP Termination Alarm Log Status Commands	4038
102.38 Secondary SIP Termination Alarm Log Status Command	4043
102.39 SIP Termination Alarm Log Status Commands	4047
102.40 E1/T1 Interface Alarm Log Status Commands	4051
102.41 SIP Termination Alarm Log Status Commands	4053
102.42 Pseudo Wire Alarm Log Status Command	4055
102.43 E1 Alarm Log Status Command	4057
102.44 Shdsl Alarm Log Status Command	4060
102.45 Shdsl Alarm Log Status Command	4063
102.46 Megaco Media Gateway Alarm Log Status Command	4066
102.47 Megaco Signaling Gateway Alarm Log Status Command	4068
102.48 Megaco Plug Unit Alarm Log Status Command	4069
102.49 Megaco Termination Alarm Log Status Command	4071
102.50 Secondary Megaco Termination Alarm Log Status Command	4074
102.51 Megaco Signaling Lt Alarm Log Status Command	4076
102.52 Ima-Group Alarm Log Status Command	4078
102.53 Ima-Link Alarm Log Status Command	4081
102.54 Ether-Tca Alarm Log Status Command	4084
102.55 Ether-Sfp Alarm Log Status Command	4087
102.56 Ether-Sfp Alarm Log Status Command	4090
102.57 Alarm Qos Slot Log Status Commands	4093
102.58 Ellid Alarm Status Command	4096
102.59 Alarm Qos Queue Log Status Commands	4105
102.60 Log File Transfer Server Alarm Log Status Command	4108

102.61 Log Lsm Redundancy Alarm Log Status Command	4110
102.62 Log L2 Forward Alarm Log Status Command	4112
102.63 External Device Alarm Log Status Command	4115
102.64 Multicast Source Alarm Log Status Command	4117
102.65 Vlanport Alarm Log Status Command	4119
102.66 BGP Alarm Log Status Command	4122
102.67 RIP Alarm Log Status Command	4124
102.68 LAG Alarm Log Status Command	4126
102.69 ihub-general Alarm Log Status Command	4128
102.70 VPRN Alarm Log Status Command	4131
102.71 ISIS Alarm Log Status Command	4133
102.72 Ospf Alarm Log Status Command	4135
102.73 ihub-l2forward Alarm Log Status Command	4138
102.74 Vpls Alarm Log Status Command	4141
102.75 IHUB-Eqip Alarm Log Status Command	4144
102.76 IHUB-Link Alarm Log Status Command	4147
102.77 IHUB-Tca Alarm Log Status Command	4150
102.78 LDP Alarm Log Status Command	4155
102.79 MPLS Alarm Log Status Command	4157
102.80 SDP Alarm Log Status Command	4159
102.81 IHUB IPV6 Alarm Log Status Command	4161
102.82 EPIPE Alarm Log Status Command	4163
102.83 PIM Alarm Log Status Command	4165
102.84 IHUB Lawful Intercept Alarm Log Status Command	4167
102.85 Sync Clock Alarm Log Status Command	4169
102.86 Equipment Supplemental Alarm Log Status Command	4175
102.87 Otdr Alarm Log Status Command	4177
102.88 Management Security Access Alarm Log Status Command	4183
102.89 IHUB BFD Alarm Log Status Command	4185
102.90 Application Intelligence Alarm Log Status Command	4187
102.91 ONT SNMP Alarm Log Status Command	4189
102.92 Tr069 Alarm Status Command	4191
102.93 Bulk Sync Alarm Log Status Command	4193
102.94 Protection Group Alarm Log Status Command	4195
102.95 Ont protection Alarm Log Status Command	4197
102.96 ONT General Supplemental Alarm Log Status Command	4199
102.97 SFU ONT General Supplemental Alarm Log Status Command	4203
102.98 SOHO ONT General Supplemental Alarm Log Status Command	4207
102.99 MDU ONT General Supplemental Alarm Log Status Command	4211
102.100 ONT General Supplemental 2 Alarm Log Status Command	4215
102.101 SFU ONT General Supplemental 2 Alarm Log Status Command	4218
102.102 SOHO ONT General Supplemental 2 Alarm Log Status Command	4221
102.103 MDU ONT General Supplemental 2 Alarm Log Status Command	4224
102.104 Ima-Group Alarm Log Status Command	4227
102.105 LT CFM Alarm Log Status Command	4234
102.106 IHUB CFM Alarm Log Status Command	4236
102.107 RSVP Alarm Log Status Command	4238
102.108 IPD eth-ring Alarm Log Status Command	4240
102.109 EFM-OAM Alarm Log Status Command	4242
102.110 ont loop detect Alarm Log Status Command	4244
102.111 ONT PLOAM Alarm Log Status Command	4247
102.112 SFU ONT PLOAM Alarm Log Status Command	4251
102.113 SOHO ONT PLOAM Alarm Log Status Command	4255
102.114 MDU ONT PLOAM Alarm Log Status Command	4259
102.115 ONT General Alarm Log Status Command	4263
102.116 SFU ONT General Alarm Log Status Command	4267
102.117 SOHO ONT General Alarm Log Status Command	4271
102.118 MDU ONT General Alarm Log Status Command	4275
102.119 ONT SUBSCRIBER CARD Alarm Log Status Command	4279
102.120 ONT SERVICES POTS Alarm Log Status Command	4282

102.121	ONT SERVICES LAN Alarm Log Status Command	4287
102.122	ONT TC TCA Alarm Log Status Command	4289
102.123	ONT TCA Alarm Log Status Command	4291
102.124	ONT L2 UNI Ethernet TCA Alarm Log Status Command	4293
102.125	OLT PON TC TCA Alarm Log Status Command	4295
102.126	OLT PON Utilization TCA Alarm Log Status Command	4297
102.127	OLT Channel Pair Utilization TCA Alarm Log Status Command	4301
102.128	OLT ONT TC TCA Alarm Log Status Command	4305
102.129	ONT POTS SUPPLEMENTAL Alarm Log Status Command	4307
102.130	ONT VEIP Alarm Log Status Command	4310
102.131	ONT IP HOST Alarm Log Status Command	4312
102.132	Alarm Table Alarm Log Status Command	4314
102.133	ONT VIDEO Alarm Log Status Command	4316
102.134	ONT CES Alarm Log Status Command	4318
102.135	ONT VOIP Alarm Log Status Command	4321
102.136	ONT VIDEO ANI Alarm Log Status Command	4326
102.137	ONT PWE Alarm Log Status Command	4328
102.138	ONT CESE1 Alarm Log Status Command	4331
102.139	ONT XDSL Alarm Log Status Command	4333
102.140	ONT XDSL TCA Alarm Log Status Command	4336
102.141	ONT HPNA Alarm Log Status Command	4339
102.142	ONT SIP AGENT CFG Alarm Log Status Command	4341
102.143	ONT VOIP CFG Alarm Log Status Command	4344
102.144	ONT MGC Alarm Log Status Command	4348
102.145	ONT MoCA Alarm Log Status Command	4350
102.146	ONT MoCA Threshold Crossing Alert (TCA) Alarm Log Command	4352
102.147	Auto-Switch Alarm Log Status command	4354
102.148	Channel Pair Alarm Log Status Command	4358
102.149	Channel Pair OLT TC TCA Alarm Log Status Command	4362
102.150	Ont Configuration Download Alarm Log Status Command	4364
102.151	HGU TR069 Alarm Log Status Command	4367
102.152	Equipment Holder Extended Alarm Log Status Command	4375
102.153	Ethernet Ring Alarm Log Status Command	4378
102.154	Lldpmed Alarm Log Status Command	4380
102.155	Lag group Alarm Log Status Command	4382
102.156	40GBase-KR4 fcs exceed Alarm Log Status Command	4384

103- Alarm Snap-shot Status Commands 4386

103.1	Alarm Snap-shot Status Command Tree	4390
103.2	Alarm Snapshot Status Command	4396
103.3	Alarm Snapshot Equipment Status Command	4404
103.4	Equipment Holder Alarm Log Status Command	4407
103.5	Equipment Holder Alarm Extended Log Status Command	4409
103.6	Plug-in Unit Alarm Log Status Command	4411
103.7	ATM Alarm Log Status Command	4414
103.8	Alarm Snapshot Ethernet Interface Status Command	4416
103.9	Alarm Snapshot Software Management Status Command	4417
103.10	Alarm Snapshot Temporal Filter Status Command	4419
103.11	Alarm Snapshot Spatial Filter Status Command	4423
103.12	Alarm xDSL Snapshot Status Command	4427
103.13	TCA xDSL Alarm Log Status Command	4431
103.14	OLT General Alarm Snapshot Status Command	4435
103.15	Alarm Vectoring Line Snapshot Status Command	4439
103.16	Alarm Vectoring Board Snapshot Status Command	4441
103.17	Alarm Electrical-to-Optical Conversion for Snapshot Status Command	4443
103.18	Authentication Alarms for Snapshot Status Command	4444
103.19	Alarm xDSL Bonding Snap Shot Status Command	4447
103.20	Alarm Redundancy Snapshot Status Command	4450
103.21	Alarm Custom Snapshot Status Command	4451

103.22 Alarm SFP Snapshot Status Command	4455
103.23 Alarm Custom External Snap Shot Status Command	4459
103.24 Alarm RSSI SFP Snapshot Status Command	4461
103.25 Alarm PPP Cross-Connect Engine TCA Snapshot Status Command	4466
103.26 Ellid Alarm Status Command	4468
103.27 2xE1/DS1 SFP Clock Snapshot Status Command	4475
103.28 2xE1/DS1 SFP Framer Snapshot Status Command	4478
103.29 Epon Olt Sfp RSSI Snapshot Alarm Status Command	4482
103.30 Alarm Plug In Unit Extended Snap Shot Status Command	4486
103.31 Alarm Snap-shot SIP Server Status Command	4490
103.32 Alarm Snap-shot SIP VSP Status Command	4491
103.33 Alarm Snap-shot SIP Dial Plan Status Command	4493
103.34 Alarm Snap-shot SIP User Agent Status Command	4494
103.35 Alarm Snap-shot SIP Slot Status Command	4496
103.36 Alarm Snap-shot SIP Termination Status Command	4497
103.37 Alarm Snap-shot Secondary SIP Termination Status Command	4500
103.38 Alarm Snap-shot SIP Termination Status Command	4503
103.39 Alarm Snap-shot E1/T1 interface Status Command	4506
103.40 Alarm Snap-shot SIP Termination Status Command	4508
103.41 Alarm Snap-shot Pseudo Wire Status Command	4510
103.42 Alarm Snap-shot Megaco Media Gateway Status Command	4512
103.43 Alarm Snap-shot Megaco Signaling Gateway Status Command	4513
103.44 Alarm Snap-shot Megaco Plug Unit Status Command	4514
103.45 Alarm Snap-shot Megaco Termination Status Command	4515
103.46 Alarm Snap-shot Secondary Megaco Termination Status Command	4517
103.47 Alarm Snap-shot Megaco Signaling Lt Status Command	4518
103.48 Alarm Snap-shot E1 Status Command	4520
103.49 Alarm Snap-shot Shdsl Status Command	4522
103.50 Alarm Snap-shot Shdsl Status Command	4524
103.51 Alarm Snap-shot Ima-Group Status Command	4526
103.52 Alarm Snap-shot Ima-Link Status Command	4528
103.53 Alarm Snap-shot Ether-Tca Status Command	4530
103.54 Alarm Snap-shot Ether-Sfp Status Command	4532
103.55 Alarm Snap-shot Ether-Sfp Status Command	4534
103.56 Alarm Snap-shot SIP Termination Status Command	4536
103.57 Alarm Snap-shot SIP Termination Status Command	4538
103.58 Alarm File Transfer Server Status Command	4541
103.59 Alarm Lsm Redundancy Status Command	4542
103.60 Alarm L2 Forward Status Command	4544
103.61 Alarm Snap-shot External Device Status Command	4547
103.62 Alarm Snap-shot Multicast Source Status Command	4548
103.63 Vlanport Alarm Snapshot Status Command	4550
103.64 BGP Alarm SnapShot Status Command	4553
103.65 RIP Alarm SnapShot Status Command	4555
103.66 LAG Alarm SnapShot Status Command	4556
103.67 ihub-general Alarm SnapShot Status Command	4558
103.68 VPRN Alarm SnapShot Status Command	4560
103.69 ISIS Alarm SnapShot Status Command	4562
103.70 OSPF Alarm SnapShot Status Command	4564
103.71 ihub-l2forward Alarm SnapShot Status Command	4566
103.72 VPLS Alarm SnapShot Status Command	4568
103.73 IHUB-Equip Alarm SnapShot Status Command	4570
103.74 IHUB-link Alarm SnapShot Status Command	4572
103.75 IHUB-tca Alarm SnapShot Status Command	4575
103.76 LDP Alarm SnapShot Status Command	4578
103.77 Alarm SnapShot MPLS Status Command	4580
103.78 Alarm SnapShot SDP Status Command	4582
103.79 IHUB IPV6 Alarm SnapShot Status Command	4584
103.80 Alarm SnapShot EPIPE Status Command	4586
103.81 Alarm SnapShot PIM Status Command	4587

103.82 IHUB Lawful Intercept Alarm SnapShot Status Command	4589
103.83 Sync Clock Alarm SnapShot Status Command	4591
103.84 Alarm Snapshot Equipment Supplemental Status Command	4595
103.85 Otdr Alarm SnapShot Status Command	4597
103.86 Management Security Access Alarm SnapShot Status Command	4603
103.87 IHUB BFD Alarm SnapShot Status Command	4605
103.88 Application Intelligence Alarm Snap-shot Status Command	4607
103.89 Alarm ONT SNMP Snapshot Status Command	4609
103.90 Tr069 Alarm Status Command	4611
103.91 Bulk Sync Alarm Log Status Command	4613
103.92 Protection Group Alarm Log Status Command	4615
103.93 Ont protection Alarm Snapshot Status Command	4617
103.94 ONT General Supplemental Alarm Snapshot Status Command	4619
103.95 SFU ONT General Supplemental Alarm Snapshot Status Command	4623
103.96 SOHO ONT General Supplemental Alarm Snapshot Status Command	4627
103.97 MDU ONT General Supplemental Alarm Snapshot Status Command	4631
103.98 ONT General Supplemental 2 Alarm Snapshot Status Command	4635
103.99 SFU ONT General Supplemental 2 Alarm Snapshot Status Command	4638
103.100 SOHO ONT General Supplemental 2 Alarm Snapshot Status Command	4641
103.101 MDU ONT General Supplemental 2 Alarm Snapshot Status Command	4644
103.102 LT CFM Alarm SnapShot Status Command	4647
103.103 IHUB CFM Alarm SnapShot Status Command	4649
103.104 Alarm SnapShot RSVP Status Command	4651
103.105 IPD eth-ring Alarm SnapShot Status Command	4653
103.106 EFM-OAM alarm Snap-shot Status Command	4655
103.107 ONT loop detect alarm Snap-shot Status Command	4657
103.108 ONT PLOAM Alarm Snapshot Status Command	4660
103.109 SFU ONT PLOAM Alarm Snapshot Status Command	4664
103.110 SOHO ONT PLOAM Alarm Snapshot Status Command	4668
103.111 MDU ONT PLOAM Alarm Snapshot Status Command	4672
103.112 ONT General Alarm Snapshot Status Command	4676
103.113 SFU ONT General Alarm Snapshot Status Command	4680
103.114 SOHO ONT General Alarm Snapshot Status Command	4684
103.115 MDU ONT General Alarm Snapshot Status Command	4688
103.116 Alarm SnapShot ONT SUBSCRIBER CARD Status Command	4692
103.117 Alarm SnapShot ONT SERVICES POTS Status Command	4694
103.118 Alarm SnapShot ONT SERVICES LAN Status Command	4699
103.119 ONT TCA Alarm Log Status Command	4701
103.120 Alarm SnapShot ONT TC TCA Status Command	4703
103.121 Alarm SnapShot ONT L2 UNI Ethernet TCA Status Command	4705
103.122 Alarm SnapShot OLT PON TC TCA Status Command	4707
103.123 Alarm SnapShot OLT PON Utilization TCA Status Command	4709
103.124 Alarm SnapShot OLT Channel Pair Utilization TCA Status Command	4713
103.125 Alarm SnapShot OLT ONT TC TCA Status Command	4717
103.126 Alarm SnapShot ONT POTS SUPPLEMENTAL Status Command	4719
103.127 Alarm SnapShot ONT VEIP Status Command	4722
103.128 Alarm SnapShot ONT IP HOST Status Command	4724
103.129 Alarm Table Snapshot Status Command	4726
103.130 Alarm SnapShot ONT VIDEO Status Command	4727
103.131 Alarm SnapShot ONT CES Status Command	4729
103.132 Alarm SnapShot ONT VOIP Status Command	4732
103.133 Alarm SnapShot ONT VIDEO ANI Status Command	4737
103.134 Alarm SnapShot ONT PWE Status Command	4739
103.135 Alarm SnapShot ONT CESE1 Status Command	4741
103.136 Alarm SnapShot ONT XDSL Status Command	4743
103.137 Alarm SnapShot ONT XDSL TCA Status Command	4746
103.138 Alarm SnapShot ONT HPNA Status Command	4748
103.139 Alarm SnapShot ONT SIP AGENT CFG Status Command	4750
103.140 Alarm SnapShot ONT VOIP CFG Status Command	4753
103.141 Alarm SnapShot ONT MGC Status Command	4757

103.142 Alarm Snapshot ONT MoCA Status Command	4759
103.143 ONT MoCA Threshold Crossing Alert (TCA) Alarm Snapshot Status Command . . .	4761
103.144 Auto-Switch Alarm Snapshot Status Command	4763
103.145 Ont Configuration Download Snapshot Status Command	4765
103.146 Alarm Snapshot Channel Pair OLT TC TCA Status Command	4768
103.147 Alarm Snapshot Channel Pair Status Command	4770
103.148 HGU TR069 Snapshot Status Command	4773
103.149 Equipment Holder Alarm Extended Log Status Command	4778
103.150 Ethernet Ring Alarm SnapShot Status Command	4781
103.151 Lldpmed Alarm Snapshot Status Command	4783
103.152 Alarm Snap-shot Lag-group Status Command	4785
103.153 Alarm Snap-shot 40GBase-KR4 fcs exceed Status Command	4787

104- Current Alarm Status Commands 4789

104.1 Current Alarm Status Command Tree	4793
104.2 Alarm Current Status Command	4799
104.3 Equipment Current Alarm Status Command	4807
104.4 Equipment Holder Current Alarm Status Command	4810
104.5 Equipment Holder Extended Current Alarm Status Command	4812
104.6 Plug-in Unit Current Alarm Status Command	4814
104.7 ATM Current Alarm Status Command	4817
104.8 Ethernet Interface Current Alarm Status Command	4819
104.9 Software Management Current Alarm Status Command	4820
104.10 Temporal Filter Current Alarm Status Command	4822
104.11 Spatial Filter Current Alarm Status Command	4826
104.12 xDSL Current Alarm Status Command	4830
104.13 TCA xDSL Current Alarm Status Command	4834
104.14 OLT General Current Alarm Status Command	4838
104.15 Vectoring Line Current Alarm Status Command	4842
104.16 Vectoring Board Current Alarm Status Command	4844
104.17 Electrical-to-Optical Conversion Current Alarm Status Command	4846
104.18 Authentication Current Alarm Status Command	4848
104.19 xDSL Bonding Current Alarm Status Command	4851
104.20 Redundancy Current Alarm Status Command	4854
104.21 Custom Current Alarm Status Command	4855
104.22 SFP Current Alarm Status Command	4859
104.23 Custom External Current Alarm Status Command	4863
104.24 SFP RSSI Current Alarm Status Command	4865
104.25 PPP Cross-Connect Engine TCA Current Alarm Status Command	4870
104.26 Epon Olt Sfp RSSI Current Alarm Status Command	4872
104.27 2xE1/DS1 SFP Clock Current Alarm Status Command	4876
104.28 2xE1/DS1 SFP Framer Alarm Status Command	4879
104.29 Plug In Unit Extended Current Alarm Status Command	4883
104.30 SIP Server Current Alarm Status Command	4887
104.31 SIP VSP Current Alarm Status Command	4888
104.32 SIP Dial Plan Current Alarm Status Command	4891
104.33 SIP User Agent Current Alarm Status Command	4892
104.34 SIP Slot Current Alarm Status Command	4894
104.35 SIP Termination Current Alarm Status Command	4896
104.36 Secondary SIP Termination Current Alarm Status Command	4900
104.37 SIP Termination Current Alarm Status Command	4903
104.38 E1T1 Interface Current Alarm Status Command	4906
104.39 SIP Termination Current Alarm Status Command	4908
104.40 Pseudo Wire Current Alarm Status Command	4910
104.41 Megaco Media Gateway Current Alarm Status Command	4912
104.42 Megaco Signaling Gateway Current Alarm Status Command	4914
104.43 Megaco Plugin Unit Current Alarm Status Command	4916
104.44 Megaco Termination Current Alarm Status Command	4918
104.45 Secondary Megaco Termination Current Alarm Status Command	4920

104.46 Megaco Signaling Lt Current Alarm Status Command	4922
104.47 E1Current Alarm Status Command	4924
104.48 Shdsl Current Alarm Status Command	4926
104.49 Shdsl Current Alarm Status Command	4928
104.50 Ima-Group Current Alarm Status Command	4930
104.51 Ima-Link Current Alarm Status Command	4932
104.52 Alarm Current Ether-Tca Status Command	4934
104.53 Alarm Current Ether-Sfp Status Command	4936
104.54 Alarm Current Ether-Sfp Status Command	4938
104.55 Alarm Current Qos Slot Status Command	4940
104.56 Alarm Current Qos Queue Status Command	4942
104.57 Alarm File Transfer Server Status Command	4945
104.58 Alarm LSM Redundancy Status Command	4946
104.59 Alarm L2 Forward Status Command	4948
104.60 Alarm Current External Device Status Command	4951
104.61 Multicast Source Current Alarm Status Command	4952
104.62 Vlanport Current Alarm Status Command	4954
104.63 BGP Current Alarm Status Command	4957
104.64 RIP Current Alarm Status Command	4959
104.65 LAG Current Alarm Status Command	4960
104.66 ihub-general Current Alarm Status Command	4962
104.67 VPRN Current Alarm Status Command	4964
104.68 ISIS Current Alarm Status Command	4966
104.69 Ospf Current Alarm Status Command	4968
104.70 ihub-l2forward Current Alarm Status Command	4970
104.71 VPLS Current Alarm Status Command	4972
104.72 IHUB-Equip Current Alarm Status Command	4974
104.73 ihub-link Current Alarm Status Command	4976
104.74 ihub-tca Current Alarm Status Command	4979
104.75 LDP Current Alarm Status Command	4982
104.76 MPLS Current Alarm Status Command	4984
104.77 SDP Current Alarm Status Command	4986
104.78 IHUB IPV6 Current Alarm Status Command	4988
104.79 EPIPE Current Alarm Status Command	4990
104.80 PIM Current Alarm Status Command	4991
104.81 IHUB Lawful Intercept Current Alarm Status Command	4993
104.82 Sync Clock Current Alarm Status Command	4995
104.83 Equipment Supplemental Current Alarm Status Command	4999
104.84 Otdr Current Alarm Status Command	5001
104.85 Management Security Access Current Alarm Status Command	5007
104.86 IHUB BFD Current Alarm Status Command	5009
104.87 Application Intelligence Current Alarm Status Command	5011
104.88 Tr069 Alarm Status Command	5013
104.89 ONT SNMP Current Alarm Status Command	5015
104.90 Bulk Sync Alarm Log Status Command	5017
104.91 Protection Group Alarm Log Status Command	5019
104.92 Ont protection Alarm Log Status Command	5021
104.93 ONT General Supplemental Current Alarm Status Command	5023
104.94 SFU ONT General Supplemental Current Alarm Status Command	5027
104.95 SOHO ONT General Supplemental Current Alarm Status Command	5031
104.96 MDU ONT General Supplemental Current Alarm Status Command	5035
104.97 ONT General Supplemental 2 Current Alarm Status Command	5039
104.98 SFU ONT General Supplemental 2 Current Alarm Status Command	5042
104.99 SOHO ONT General Supplemental 2 Current Alarm Status Command	5045
104.100 MDU ONT General Supplemental 2 Current Alarm Status Command	5048
104.101 Ellid Alarm Status Command	5051
104.102 Ima-Group Alarm Log Status Command	5058
104.103 Ima-Group Alarm Log Status Command	5064
104.104 Ima-Group Alarm Log Status Command	5070
104.105 Ima-Group Alarm Log Status Command	5076

104.106 Ima-Group Alarm Log Status Command	5082
104.107 LT CFM Current Alarm Status Command	5084
104.108 IHUB Eth Cfm Current Alarm Status Command	5086
104.109 RSVP Current Alarm Status Command	5088
104.110 IPD eth-ring Current Alarm Status Command	5090
104.111 EFM-OAM Current Alarm Status Command	5092
104.112 Ont loop detect Current Alarm Status Command	5094
104.113 ONT PLOAM Current Alarm Status Command	5097
104.114 SFU ONT PLOAM Current Alarm Status Command	5101
104.115 SOHO ONT PLOAM Current Alarm Status Command	5105
104.116 MDU ONT PLOAM Current Alarm Status Command	5109
104.117 ONT General Current Alarm Status Command	5113
104.118 SFU ONT General Current Alarm Status Command	5117
104.119 SOHO ONT General Current Alarm Status Command	5121
104.120 MDU ONT General Current Alarm Status Command	5125
104.121 ONT SUBSCRIBER CARD Current Alarm Status Command	5129
104.122 ONT SERVICES POTS Current Alarm Status Command	5131
104.123 ONT SERVICES LAN Current Alarm Status Command	5136
104.124 ONT TCA Current Alarm Status Command	5138
104.125 ONT TC TCA Current Alarm Status Command	5140
104.126 ONT L2 UNI Ethernet TCA Current Alarm Status Command	5142
104.127 OLT PON TC TCA Current Alarm Status Command	5144
104.128 OLT PON Utilization TCA Current Alarm Status Command	5146
104.129 OLT Channel Pair Utilization TCA Current Alarm Status Command	5150
104.130 OLT ONT TC TCA Current Alarm Status Command	5154
104.131 ONT POTS SUPPLEMENTAL Current Alarm Status Command	5156
104.132 ONT VEIP Current Alarm Status Command	5159
104.133 ONT IP HOST Current Alarm Status Command	5161
104.134 Alarm Table Current Alarm Status Command	5163
104.135 ONT VIDEO Current Alarm Status Command	5164
104.136 ONT CES Current Alarm Status Command	5166
104.137 ONT VOIP Current Alarm Status Command	5168
104.138 ONT VIDEO ANI Current Alarm Status Command	5173
104.139 ONT PWE Current Alarm Status Command	5175
104.140 ONT CESE1 Current Alarm Status Command	5177
104.141 ONT XDSL Current Alarm Status Command	5179
104.142 ONT XDSL TCA Current Alarm Status Command	5182
104.143 ONT HPNA Current Alarm Status Command	5184
104.144 ONT SIP AGENT CFG Current Alarm Status Command	5186
104.145 ONT VOIP CFG Current Alarm Status Command	5189
104.146 ONT MGC Current Alarm Status Command	5193
104.147 ONT MoCA Current Alarm Status Command	5195
104.148 ONT MoCA Threshold Crossing Alert (TCA) Current Alarm Status Command	5197
104.149 Auto-Switch Current Alarm Status Command	5199
104.150 Channel Pair Current Alarm Status Command	5201
104.151 Channel Pair OLT TC TCA Current Alarm Status Command	5204
104.152 Ont Configuration Download Current Alarm Status Command	5206
104.153 HGU TR069 Current Alarm Status Command	5209
104.154 Equipment Holder Extended Current Alarm Status Command	5214
104.155 Ethernet Ring Current Alarm Status Command	5215
104.156 LldpMed Current Alarm Status Command	5217
104.157 Lag group Current Alarm Status Command	5219
104.158 40GBase-KR4 fcs exceed Current Alarm Status Command	5221

105- ATM Status Commands

5223

105.1 ATM Status Command Tree	5224
105.2 ATM Interface Status Command	5225
105.3 PVC Status Command	5227
105.4 TC Adapter Protocol Interval Status Command	5229

105.5 TC Adapter Protocol Current Quarter Performance Data Command	5231
105.6 TC Adapter Protocol Current Day Performance Data Command	5233
105.7 TC Adapter Protocol Performance Data for Previous Quarter Intervals Command	5235
105.8 TC Adapter Protocol Performance Data for Previous Day Intervals Command	5237

106- VLAN Status Commands 5239

106.1 VLAN Status Command Tree	5240
106.2 Global VLAN Status Command	5242
106.3 Residential Bridge VLAN Summary Status Command	5243
106.4 Residential Bridge VLAN Extensive Status Command	5246
106.5 Cross-connect VLAN Status Command	5251
106.6 Stacked VLAN Status Command	5256
106.7 Stacked QoS VLAN Status Command	5258
106.8 QoS C-VLAN Status Command	5260
106.9 Layer-2 Terminated VLAN Status Command	5261
106.10 VLAN Name Mapping Status Command	5263
106.11 VLAN Filtering Database Per LIM Status Command	5264
106.12 Bridge Port Filtering Database Status Command	5268
106.13 VLAN Priority Regeneration Profile Status Command	5271
106.14 VLAN Priority Regeneration Profile Name Status Command	5274
106.15 Show Next Free ID of VLAN Priority Regeneration Profile	5277
106.16 Duplicate MAC Alarm Status Command	5278
106.17 Port Event Status Command	5282
106.18 Port Statistics for Current Quarter Status Command	5285
106.19 Port Statistics for Current Day Status Command	5288
106.20 Port Statistics for Previous Quarter Intervals Status Command	5291
106.21 Port Statistics for Previous Day Intervals Status Command	5294
106.22 VLAN Port Statistics for Current Quarter Status Command	5297
106.23 VLAN Port Statistics for Current Day Status Command	5301
106.24 VLAN Port Statistics for Previous Quarter Intervals Status Command	5305
106.25 VLAN Port Statistics for Previous Day Intervals Status Command	5309
106.26 VLAN Filtering Database Status Command	5313
106.27 P-bit Traffic Counters Status Command	5316
106.28 Current VLAN Filtering Database Status Command	5319
106.29 Accumulated Port Statistics	5321

107- QOS Status Commands 5324

107.1 QOS Status Command Tree	5326
107.2 QoS Session Profile Status Command	5328
107.3 QoS Marker Profile Status Command	5329
107.4 QoS Policer Profile Status Command	5330
107.5 QoS Queue Profile Status Command	5331
107.6 QoS Scheduler Node Profile Status Command	5332
107.7 QoS CAC Profile Status Command	5333
107.8 QoS Policy Profile Status Command	5334
107.9 QoS L2 Filter Profile Status Command	5335
107.10 QoS L3 Filter Profile Status Command	5336
107.11 QoS Policy Action Profile Status Command	5337
107.12 QoS IngressQoS Profile Status Command	5338
107.13 QoS Shaper Profile Status Command	5339
107.14 QoS Bandwidth Profile Status Command	5340
107.15 QoS Rate Limit Profile Status Command	5341
107.16 QoS DSCP to PBIT Profile Status Command	5342
107.17 QoS Policer Per Tc Profile Status Command	5343
107.18 QoS Policer Threshold Profile Status Command	5344
107.19 QoS aggrQueuesConfig Profile Status Command	5345
107.20 QoS Ingress filter Resource Usage Status Command	5346
107.21 QoS DSL Bandwidth Status Command	5348
107.22 QoS Shdsl Bandwidth Status Command	5350

107.23 QoS Ethernet Bandwidth Status Command	5352
107.24 QoS Interface Bandwidth Status Command	5354
107.25 QoS Total Buffer Overflow Statistics for Previous Quarter	5359
107.26 QoS Total Buffer Overflow Statistics for Current Quarter	5362
107.27 QoS Total Buffer Overflow Statistics for Previous Day Command	5365
107.28 QoS Total Buffer Overflow Statistics for Current Day	5368
107.29 QoS Total Buffer Overflow Statistics Total Status Command	5371
107.30 QoS Interface Buffer Overflow Statistics for Previous Quarter	5375
107.31 QoS Interface Buffer Overflow Statistics for Current Quarter	5379
107.32 QoS Fan Out Statistics for Previous Quarter	5383
107.33 QoS Fan Out Statistics for Current 15 minutes	5385
107.34 QoS Fan Out Statistics for Previous Day	5387
107.35 QoS Fan Out Statistics for Current Day	5389
107.36 QoS LT Queue Overflow Statistics for Previous Quarter	5391
107.37 QoS LT Queue Overflow Statistics for current Quarter	5393
107.38 QoS Interface Color Queue Statistics for Previous 15 minutes Quarter	5395
107.39 QoS Interface Color Queue Statistics for Current 15 minutes Quarter	5400
107.40 QoS TC2QMapping Status Command	5404
107.41 QoS Bandwidth Profile Actuals Command	5406
108- ARP-RELAY Status Commands	5408
108.1 ARP-RELAY Status Command Tree	5409
108.2 ARP-RELAY statistics Status Command	5410
108.3 ARP-RELAY summary statistics Status Command	5412
108.4 ARP-RELAY detailed statistics Status Command	5415
109- xDSL Status Commands	5419
109.1 xDSL Status Command Tree	5421
109.2 xDSL Profiles Status Command	5425
109.3 xDSL PM Interval Per Interface Status Command	5427
109.4 xDSL Operational Data Near End Line Status Command	5429
109.5 xDSL Operational Data Near End Channel Status Command	5439
109.6 xDSL Operational Data Far End Line Status Command	5441
109.7 xDSL Operational Data Far End Channel Status Command	5450
109.8 xDSL Operational Data Statistics	5452
109.9 xDSL Carrier Data Near End Status Command	5458
109.10 xDSL Carrier Data Far End Status Command	5464
109.11 xDSL Failure Status Near End Status Command	5467
109.12 xDSL Failure Status Far End Status Command	5470
109.13 xDSL Vectored Line Failure Status Command	5473
109.14 xDSL Vectoring Board Failure Status Command	5475
109.15 xDSL Counters Near End Line Current 15 Min	5477
109.16 xDSL Counters Near End Line Current Day	5480
109.17 xDSL Counters Near End Line Previous 15 Min	5483
109.18 xDSL Counters Near End Of Line Previous Day	5486
109.19 xDSL Counters Near End Channel Current 15 Min	5489
109.20 xDSL Counters Near End Channel Current Day	5491
109.21 xDSL Counters Near End Channel Previous 15 Min	5493
109.22 xDSL Counters Near End Channel Previous Day	5495
109.23 xDSL Counters Far End Line Current 15 Min	5497
109.24 xDSL Counters Far End Line Current Day	5499
109.25 xDSL Counters Far End Line Previous 15 Min	5501
109.26 xDSL Counters Far End Line Previous Day	5504
109.27 xDSL Counters Far End Channel Current 15 Min	5507
109.28 xDSL Counters Far End Channel Current Day	5509
109.29 xDSL Counters Far End Channel Previous 15 Min	5511
109.30 xDSL Counters Far End Channel Previous Day	5513
109.31 xDSL XTU-R Inventory Status Command	5515
109.32 xDSL XTU-C Inventory Status Command	5517

109.33 xDSL Board Capability Status Command	5519
109.34 xDSL Low Rate Alarm Timestamp Command	5525
109.35 xDSL Low Rate Alarm Line Bitmap Status Command	5526
109.36 xDSL Low Rate Alarm Linkup Record Data Command	5527
109.37 xDSL INS Near End Operational Data Status Command	5530
109.38 xDSL INS Near End Current 15Min Data Status Command	5532
109.39 xDSL INS Near End Current 15Min IAT Histogram	5533
109.40 xDSL INS Near End Current 15Min EINP Histogram	5534
109.41 xDSL INS Near End Current Day Data Status Command	5535
109.42 xDSL INS Near End Current Day IAT Histogram	5536
109.43 xDSL INS Near End Current Day EINP Histogram	5537
109.44 xDSL INS Near End Previous 15Min Data Status Command	5538
109.45 xDSL INS Near End Previous 15Min IAT Histogram	5539
109.46 xDSL INS Near End Previous 15Min EINP Histogram	5540
109.47 xDSL INS Near End Previous Day Data Status Command	5541
109.48 xDSL INS Near End Previous Day IAT Histogram	5542
109.49 xDSL INS Near End Previous Day EINP Histogram	5543
109.50 xDSL INS Far End Operational Data Status Command	5544
109.51 xDSL INS Far End Current 15Min Data Status Command	5546
109.52 xDSL INS Far End Current 15Min IAT Histogram	5547
109.53 xDSL INS Far End Current 15Min EINP Histogram	5548
109.54 xDSL INS Far End Current Day Data Status Command	5549
109.55 xDSL INS Far End Current Day IAT Histogram	5550
109.56 xDSL INS Far End Current Day EINP Histogram	5551
109.57 xDSL INS Far End Previous 15Min Data Status Command	5552
109.58 xDSL INS Far End Previous 15Min IAT Histogram	5553
109.59 xDSL INS Far End Previous 15Min EINP Histogram	5554
109.60 xDSL INS Far End Previous Day Status Command	5555
109.61 xDSL INS Far End Previous Day IAT Histogram	5556
109.62 xDSL INS Far End Previous Day EINP Histogram	5557
109.63 xDSL Downstream Vectoring Disturberlist Status Command	5558
109.64 xDSL Upstream Vectoring Disturberlist Status Command	5560
109.65 xDSL Downstream Vectoring Disturberlist Status Command	5562
109.66 xDSL Vectoring Carrier Data Near End Status Command	5564
109.67 xDSL Vectoring Carrier Data Far End Status Command	5567
109.68 xDSL Vectoring Processing Board Status Command	5570
109.69 xDSL Vectoring Processing Group Status Command	5573

110- Configuration Data Status Commands 5576

110.1 Configuration Data Status Command Tree	5577
110.2 xDSL Port Configuration Status Command	5578
110.3 xDSL Port ATM Configuration Status Command	5584
110.4 xDSL Port ATM Interface Configuration Status Command	5586
110.5 xDSL Port Interface Configuration Status Command	5588
110.6 xDSL IGMP Configuration Status Command	5590
110.7 xDSL Security PAE Configuration Status Command	5592
110.8 xDSL BridgePort Configuration Status Command	5595
110.9 xDSL QoS Configuration Status Command	5599
110.10 xDSL PPPoX Relay Configuration Status Command	5601
110.11 xDSL Bonding Group Configuration Status Command	5603

111- Operational Data Status Commands 5605

111.1 Operational Data Status Command Tree	5606
111.2 xDSL Port Operational Status Command	5607
111.3 xDSL BridgePort Operational Status Command	5611
111.4 xDSL Port ATM Operational Status Command	5613
111.5 xDSL Port Interface Configuration Status Command	5615
111.6 xDSL IGMP Operational Status Command	5617
111.7 xDSL Port Ip Bridge Operational Status Command	5620

111.8 xDSL QoS Operational Status Command	5622
112- Gpon xDSL Status Commands	5624
112.1 Gpon xDSL Status Command Tree	5625
112.2 Gpon xDSL Profiles Status Command	5627
112.3 Gpon xDSL PM Interval Per Interface Status Command	5628
112.4 Gpon xDSL Operational Data Near End Line Status Command	5630
112.5 Gpon xDSL Operational Data Near End Channel Status Command	5635
112.6 Gpon xDSL Operational Data Far End Line Status Command	5637
112.7 Gpon xDSL Operational Data Far End Channel Status Command	5641
112.8 Gpon xDSL Carrier Data Near End Status Command	5643
112.9 Gpon xDSL Carrier Data Far End Status Command	5648
112.10 Gpon xDSL Failure Status Near End Status Command	5651
112.11 Gpon xDSL Failure Status Far End Status Command	5654
112.12 Gpon xDSL Counters Near End Line Current 15 Min	5657
112.13 Gpon xDSL Counters Near End Line Previous 15 Min	5659
112.14 Gpon xDSL Counters Near End Channel Current 15 Min	5661
112.15 Gpon xDSL Counters Near End Channel Previous 15 Min	5663
112.16 Gpon xDSL Counters Far End Line Current 15 Min	5665
112.17 Gpon xDSL Counters Far End Line Previous 15 Min	5667
112.18 Gpon xDSL Counters Far End Channel Current 15 Min	5669
112.19 Gpon xDSL Counters Far End Channel Previous 15 Min	5671
112.20 Gpon xDSL XTU-R Inventory Status Command	5673
112.21 Gpon xDSL XTU-C Inventory Status Command	5675
113- xDSL Bonding Status Commands	5677
113.1 xDSL Bonding Status Command Tree	5678
113.2 xDSL Bonding Group Profiles Status Command	5679
113.3 xDSL Bonding Group Rtx Profiles Status Command	5681
113.4 xDSL Bonding Near End Operational Data Status Command	5683
113.5 xDSL Bonding Far End Operational Data Status Command	5685
113.6 xDSL Bonding Group Operational Data Command	5687
113.7 xDSL Bonding Link Operational Data Command	5690
113.8 xDSL Bonding Near End Failure Status Command	5692
113.9 xDSL Bonding Far End Failure Status Command	5694
113.10 xDSL Bonding Group Failure Status Command	5696
113.11 xDSL Bonding Group Summary Info Command	5698
113.12 xDSL Bonding actual PTM Initialization Mode status command	5699
114- PPPoE Status Commands	5700
114.1 PPPoE Status Command Tree	5701
114.2 PPPoE Client Emulation Status Command	5702
114.3 PPPoE Interface Status Command	5706
115- PPPoEL2 Statistics Status Commands	5709
115.1 PPPoEL2 Statistics Status Command Tree	5710
115.2 PPPoEL2 Statistics Status Command	5711
115.3 PPPoEL2 detailed Statistics Status Command	5713
115.4 PPPoEL2 On-demand Statistics Status Command	5716
116- Pon Status Commands	5719
116.1 Pon Status Command Tree	5720
116.2 PON Bit Error Status Command	5722
116.3 Aggregate Pon Gem Port Current Interval Status Command	5724
116.4 Aggregate Pon Gem Port Previous Interval Status Command	5726
116.5 Multicast TC-layer Current Interval Performance Data Status Command	5728

116.6 Multicast TC-layer Previous Interval Performance Data Status Command	5730
116.7 Pon FEC Current Interval Status Command	5732
116.8 Pon Physical LayerCurrent Interval Status Command	5734
116.9 PON XGPON tc-layer Current Interval Status Command	5736
116.10 PON XGPON TC-layer Previous Interval Performance Data Status Command	5738
116.11 PON Optics Operational Information Status Command	5740
116.12 PON Software Download Status Command	5742
116.13 PON Optics Status Command	5744
116.14 PON Diagnostic Status Command	5746
116.15 Show Pon Unprovisioned Onu Command	5748
116.16 PON Configure File Download Status Command	5750
116.17 PON Utilization Current Interval PM Command	5752
116.18 PON Utilization Current Interval Top Five ONT Downstream PM Command	5756
116.19 PON Utilization Current Interval Top Five ONT Upstream PM Command	5758
116.20 PON Utilization Previous Interval PM Command	5760
116.21 PON Utilization Previous Interval Top Five ONT Downstream PM Command	5764
116.22 PON Utilization Previous Interval Top Five ONT Upstream PM Command	5766
116.23 PON Peak Utilization Current Interval PM Command	5768
116.24 PON Peak Utilization Current Interval Top Five ONT Downstream PM Command	5770
116.25 PON Peak Utilization Current Interval Top Five ONT Upstream PM Command	5772
116.26 PON Peak Utilization Previous Interval PM Command	5774
116.27 PON Peak Utilization Previous Interval Top Five ONT Downstream PM Command	5776
116.28 PON Peak Utilization Previous Interval Top Five ONT Upstream PM Command	5778

117- Channel Pair Status Commands 5780

117.1 Channel Pair Status Command Tree	5781
117.2 Aggregate Channel Pair XGEM Ports Current Interval Status Command	5783
117.3 Aggregate Channel Pair XGEM Ports Previous Interval Status Command	5784
117.4 Multicast TC-layer Current Interval Performance Data Status Command	5786
117.5 Multicast TC-layer Previous Interval Performance Data Status Command	5788
117.6 Pon FEC Current Interval Status Command	5790
117.7 Channel Pair Physical LayerCurrent Interval Status Command	5792
117.8 Channel pair NGPON2 tc-layer Current Interval Status Command	5794
117.9 Channel Pair NGPON2 TC-layer Previous Interval Performance Data Status Command	5796
117.10 PON Optics Operational Information Status Command	5798
117.11 Channel Pair Optics Status Command	5800
117.12 NGPON2 Diagnostic Status Command	5802
117.13 Show Channel Pair Unprovisioned Onu Command	5804
117.14 Channel Pair Utilization Current Interval PM Command	5806
117.15 Channel Pair Utilization Current Interval Top Five ONT Downstream PM Command	5810
117.16 Channel Pair Utilization Current Interval Top Five ONT Upstream PM Command	5812
117.17 Channel Pair Utilization Previous Interval PM Command	5814
117.18 Channel Pair Utilization Previous Interval Top Five ONT Downstream PM Command	5818
117.19 Channel Pair Utilization Previous Interval Top Five ONT Upstream PM Command	5820
117.20 Channel Pair Peak Utilization Current Interval PM Command	5822
117.21 Channel Pair Peak Utilization Current Interval Top Five ONT Downstream PM Command	5824
117.22 Channel Pair Peak Utilization Current Interval Top Five ONT Upstream PM Command	5826
117.23 Channel Pair Peak Utilization Previous Interval PM Command	5828
117.24 Channel Pair Peak Utilization Previous Interval Top Five ONT Downstream PM Command	5830
117.25 Channel Pair Peak Utilization Previous Interval Top Five ONT Upstream PM Command	5832

118- Uni Ont Gem-port Status Commands 5834

118.1 Uni Ont Gem-port Status Command Tree	5835
118.2 Uni Gem-port Olt-side Current Interval Status Command	5836
118.3 Uni Gem-port Olt-side Previous Interval Status Command	5838
118.4 Uni Gem-port Ont-side Current Interval Status Command	5840

118.5 Uni Gem-port Ont-side Previous Interval Status Command	5842
119- CES Show Commands	5844
119.1 CES Show Command Tree	5845
119.2 CES Service Operational Information	5846
119.3 CESPW Service Current Interval Statistics Command	5848
119.4 CESPW Service Previous Interval Statistics Command	5850
119.5 Current Interval OLT side PM status Command	5852
119.6 Previous Interval OLT side PM status Command	5854
119.7 Current Interval ONT side PM status Command	5856
119.8 Previous Interval ONT side PM status Command	5858
119.9 CESUNI Current Interval PM status Command	5860
119.10 CESUNI Previous Interval PM status Command	5862
120- ANI ONT Show Commands	5864
120.1 ANI ONT Show Command Tree	5865
120.2 ANI ONT Operational-Data Status Command	5866
120.3 ANI ONT Video Status Command	5868
120.4 ANI ONT Video Stats Command	5871
121- L2UNI Show Commands	5873
121.1 L2UNI Show Command Tree	5874
121.2 Current L2UNI ONT Status Command	5875
121.3 Previous L2UNI ONT Status Command	5879
121.4 Current L2UNI ONT Status Command	5883
121.5 Previous L2UNI ONT Status Command	5887
121.6 Current L2UNI ONT Status Command	5891
121.7 Previous L2UNI ONT Status Command	5895
121.8 Show multicast subscriber monitor Command	5899
121.9 Show active group list	5901
122- HPNA Show Commands	5903
122.1 HPNA Show Command Tree	5904
122.2 Current HPNA ONT Status Command	5905
122.3 Previous L2UNI ONT Status Command	5909
123- Voice Ont IP Host Show Commands	5913
123.1 Voice Ont IP Host Show Command Tree	5914
123.2 ONT IP Host Operational Data Status Command	5915
123.3 ONT IP Host Current 15min Statistics Status Command	5918
124- MoCA Status Commands	5921
124.1 MoCA Status Command Tree	5922
124.2 MoCA ONT Uni Operational Data Status Command	5923
124.3 MoCA ONT Current PM Data Status Command	5926
124.4 MoCA ONT Historical PM Data Status Command	5928
125- Epon Status Commands	5930
125.1 Epon Status Command Tree	5931
125.2 EPON Optics Status Command	5932
125.3 Epon Profile Status Command	5936
125.4 Epon Queue Profile Status Command	5937
125.5 Epon Filter Profile Status Command	5938
125.6 Epon Digitmap Profile Status Command	5939
125.7 Epon Alarm Control Profile Status Command	5940

125.8 Epon Pon Interface Status Command	5941
125.9 Epon Pon Interface Current 15min Status Command	5942
125.10 Epon Pon Interface Current 1day Status Command	5946
125.11 Epon Pon Interface Previous 15min Status Command	5950
125.12 Epon Pon Interface Previous 15min Status Command	5951
125.13 Epon Pon Interface Previous 1Day Status Command	5955
125.14 Epon Pon Interface Previous 1Day Status Command	5956
125.15 Epon Pon Interface Information Command	5960
125.16 EPON Rogue Onu Test Result	5962
125.17 Ima-Group Alarm Log Status Command	5964
126- Interface Status Commands	5970
126.1 Interface Status Command Tree	5971
126.2 Interface Alarm Status Command	5972
126.3 Physical Interface Status Command	5974
126.4 Interface Status Command	5975
126.5 Interface Test Status Command	5986
126.6 Interface Stack Status Command	5992
126.7 Interface Extensive Status Command	6002
126.8 Interface Troubleshooting Ethernet Statistics Commands	6004
126.9 Interface Sliding-Window Traffic Statistics Command	6007
127- SNTP Status Commands	6012
127.1 SNTP Status Command Tree	6013
127.2 SNTP Status Command	6014
128- SNTP Server Commands	6015
128.1 SNTP Server Command Tree	6016
128.2 SNTP Server Status Command	6017
129- SNTP Server Commands	6018
129.1 SNTP Server Command Tree	6019
129.2 SNTP Server Status Command	6020
130- System Status Commands	6021
130.1 System Status Command Tree	6022
130.2 System Statistics Command	6023
130.3 System Licenses Status Command	6024
130.4 System License Usage Command	6029
130.5 System Clock Status Command	6031
130.6 Show syslog parameters	6033
130.7 System Memory Usage Status Command	6034
130.8 System CPU Load Status Command	6036
130.9 System Compact Flash Usage Status Command	6038
130.10 System CDE Command	6040
130.11 System CDE Extended Command	6041
130.12 System Clock Management Status Command	6042
130.13 PTP master clock device detailed information Command	6045
130.14 PTP client detailed information Command	6049
130.15 System Clock Management ToD Status Command	6051
130.16 System T4 Clock Management Status Command	6053
130.17 System Clock IEEE1588 master profile detailed info command	6056
130.18 System Clock Management IEEE1588 Status Command	6057
130.19 System Clock IEEE1588 current master detailed info Command	6059
130.20 System Clock IEEE1588 visible master detailed info Command	6063
130.21 Scaling Mode Status Command	6067

130.22 System TechSupport Status Command	6068
130.23 show system fips	6071
130.24 System Autoboot file timestamps Command	6072
131- daylight saving time Status Commands	6073
131.1 daylight saving time Status Command Tree	6074
131.2 daylight saving time Status Commands	6075
132- DST Configuration Commands	6076
132.1 DST Configuration Command Tree	6077
132.2 DST Recurring method Command	6078
133- DST Configuration Commands	6095
133.1 DST Configuration Command Tree	6096
133.2 DST Date method Command	6097
134- Transaction Status Commands	6099
134.1 Transaction Status Command Tree	6100
134.2 Transaction Log Status Command	6101
134.3 Transaction Log Entry Status Command	6103
135- Error Status Command	6104
135.1 Error Status Command Tree	6105
135.2 Error Log Status Command	6106
136- Software Status Commands	6108
136.1 Software Status Command Tree	6109
136.2 Database Status Command	6110
136.3 Disk Status Command	6112
136.4 Overall Software Package Status Command	6114
136.5 Software Management Upgrade Plan Command	6117
136.6 Software Management Upgrade Status Command	6119
136.7 Software Package Status Command	6121
136.8 File Status Command	6123
136.9 Upload/Download Status Command	6125
136.10 Upload/Download Sub-directory Status Command	6128
136.11 Software Version For ANSI Status Command	6129
136.12 Software Version For ETSI Status Command	6130
136.13 TLS CA file download Status Command	6131
136.14 Lightspan Migration Status Command	6133
136.15 lacm OAM DB save Status Command	6135
136.16 Upload/Download Sw ONTSw Status Command	6136
137- Software Load Validation Commands	6137
137.1 Software Load Validation Command Tree	6138
137.2 Overall Software Load Validation Status Command	6139
137.3 Software Load Validation Root Certificate Display Command	6141
137.4 Software Load Validation Status of SWP files Command	6142
138- CDE Status Commands	6144
138.1 CDE Status Command Tree	6145
138.2 CDE download Status Command	6146

139- IGMP Status Commands	6148
139.1 IGMP Status Command Tree	6149
139.2 IGMP System Status Command	6150
139.3 IGMP Channel Sources Status Command	6152
139.4 IGMP Channel Miscellaneous Status Command	6155
139.5 IGMP Channel Protocol Status Command	6158
139.6 IGMP package to multicast source Command	6162
139.7 IGMP Group to Package Status Command	6163
139.8 Show Multicast Source Statistics Command	6164
139.9 Show Multicast Channel Statistics Command	6166
139.10 IGMP Module Counter Status Command	6168
139.11 IGMP Module Time Status Command	6171
139.12 IGMP Module Miscellaneous Status Command	6173
139.13 IGMP System Status Command	6175
 140- Transport Status Commands	 6176
140.1 Transport Status Command Tree	6177
140.2 SNMP Protocol Statistics Command	6178
140.3 SNMP Engine Status Command	6181
140.4 System Status Command	6182
140.5 SFP status commands	6183
140.6 Interface MAU Status Command	6185
140.7 Ethernet Lt Dot3 Status Command	6190
 141- Efm Oam Status Commands	 6192
141.1 Efm Oam Status Command Tree	6193
141.2 Efm Oam Mac Statistics Command	6194
141.3 Efm Oam Pme Statistics Command	6197
141.4 Efm Oam Local Information Status Command	6199
141.5 Efm Oam Peer Information Status Command	6201
141.6 Efm Oam statistics Status Command	6204
141.7 Efm Oam loopback Status Command	6206
141.8 Efm Oam Internal Traffic generator Status Command	6208
 142- DHCP Relay Status Commands	 6210
142.1 DHCP Relay Status Command Tree	6211
142.2 DHCP Relay Port Statistics	6212
142.3 DHCP Relay Port Statistics Related To Vlan Ports	6214
142.4 DHCP Relay Port Summary Statistics Related To Vlan Ports	6216
142.5 DHCP Relay Port Detailed Statistics Related To Vlan Ports	6219
142.6 DHCP v6 Relay Port Statistics	6226
142.7 DHCP v6 Relay Port Statistics Related To Vlan Ports	6228
142.8 DHCP v6 Relay Port Summary Statistics Related To Vlan Ports	6230
142.9 DHCP v6 Relay Port Detailed Statistics Related To Vlan Ports	6233
142.10 DHCP Relay Session Status Command	6238
 143- Multicast Status Commands	 6242
143.1 Multicast Status Command Tree	6243
143.2 Multicast Active Groups Status Command	6244
143.3 Multicast Ipv6 Active Groups Status Command	6248
143.4 Multicast PON Active Groups Status Command	6252
143.5 Multicast ONT Active Groups Status Command	6256
143.6 Multicast Channel Pair Active Groups Status Command	6260
143.7 Multicast Group Membership Status Command	6264

144- CPE Management Status Commands	6268
144.1 CPE Management Status Command Tree	6269
144.2 CPE Management Show Command	6270
145- Session Status Commands	6271
145.1 Session Status Command Tree	6272
145.2 Session Status Command	6273
146- PPPoX-Relay Status Commands	6275
146.1 PPPoX-Relay Status Command Tree	6276
146.2 PPPoX CC Engine Statistics	6277
146.3 PPPoX CC Client Port Statistics	6279
146.4 PPPoX CC Engine Monitor Statistics	6282
146.5 PPPoX CC Client Port Monitor Statistics	6284
146.6 PPPoX CC Session Engine Status Command	6287
146.7 PPPoX CC Session Client Port Status Command	6290
146.8 PPPCC Engine Current 15Minute Statistics Command	6293
146.9 PPPCC Engine Current 1day Statistics Command	6295
146.10 PPPCC Engine Previous 15Minute Statistics Command	6297
146.11 PPPCC Engine Previous 1day Statistics Command	6299
147- NAT related Commands	6301
147.1 NAT related Command Tree	6302
147.2 Nat dynamic Session Status Command	6303
148- CWMP Platform Status Commands	6304
148.1 CWMP Platform Status Command Tree	6305
148.2 CWMP Platform Status Commands	6306
148.3 Cwmp Platform Status Commands	6307
149- SHDSL Status Commands	6308
149.1 SHDSL Status Command Tree	6309
149.2 SHDSL Inventory Status Command	6311
149.3 SHDSL Span Status Command	6313
149.4 SHDSL Unit Status Command	6320
149.5 SHDSL Segment Status Command	6322
149.6 SHDSL Segment Counters Current Interval Status Command	6327
149.7 SHDSL Segment Counters Current Day Status Command	6330
149.8 SHDSL Segment Counters Previous Interval Status Command	6333
149.9 SHDSL Segment Counters Previous Day Status Command	6336
149.10 SHDSL Span Current Interval Performance Data Status Command	6339
149.11 SHDSL Span Current Day Performance Data Status Command	6341
149.12 SHDSL Span Previous Interval Performance Data Status Command	6343
149.13 SHDSL Span Previous Day Performance Data Status Command	6345
150- IMA Status Commands	6347
150.1 IMA Status Command Tree	6348
150.2 IMA Group Status Command	6349
150.3 IMA Group Near-End Current Interval Performance Data Status Command	6354
150.4 IMA Group Near-End Previous Interval Performance Data Status Command	6356
150.5 IMA Group Far-End Current Interval Performance Data Status Command	6358
150.6 IMA Group Far-End Previous Interval Performance Data Status Command	6360
150.7 IMA Link Status Command	6362
150.8 IMA Link Near-End Current Interval Performance Data Status Command	6366

150.9 IMA Link Near-End Previous Interval Performance Data Status Command	6368
150.10 IMA Link Far-End Current Interval Performance Data Status Command	6370
150.11 IMA Link Far-End Previous Interval Performance Data Status Command	6372

151- Voice Status Commands 6374

151.1 Voice Status Command Tree	6376
151.2 Voice Sip Server Status Commands	6380
151.3 Voice Sip User Agent Access Point Show Commands	6382
151.4 Voice Sip User Agent related IP address information Show Commands	6384
151.5 Voice Sip Statistics System Status Command	6386
151.6 Voice Sip Statistics Perfinfo Status Command	6387
151.7 Voice Sip Termination Statistics Command for Current 15 Minutes	6389
151.8 Voice Sip Termination Statistics Command for Current Day	6393
151.9 Voice Sip Termination Statistics Command for Previous 15 Minutes	6396
151.10 Voice Sip Termination Statistics Command for Previous day	6400
151.11 Voice Sip MSAN Statistics Command	6403
151.12 Voice Sip board Statistics Command for Current one Day	6405
151.13 Voice Sip Board Statistics Command for Previous day	6409
151.14 Voice Sip Board Statistics Command for Current 15 Minutes	6413
151.15 Voice Sip Board Statistics Command for Previous 15 Minutes	6417
151.16 Voice Sip Statistics Perfinfo Status Command per board	6421
151.17 Voice Sip restoration: Redundancy Status Commands	6423
151.18 Voice Sip restoration: Redundancy Status Commands	6425
151.19 Voice Sip Redundancy Status Commands	6427
151.20 Voice Sip Termination Status Commands	6428
151.21 Voice Sip Shared Line Termination Status Commands	6431
151.22 Voice Sip Isdn/Cas Termination Status Commands	6433
151.23 Voice Sip Port State Status Commands	6436
151.24 Voice Sip SSP Profile Status Commands	6437
151.25 Voice Sip Dhcp Sip Server Status Commands	6438
151.26 Voice Sip All Port State Status Command	6441
151.27 Voice Sip Isdn/Cas Termination Status Commands	6443
151.28 Voice Sip Isdn Cas E1 Interface Status Commands	6445
151.29 Voice Sip Isdn Nsm Profile Status Commands	6447
151.30 Voice Sip Cas Nsm Profile Status Commands	6448
151.31 Voice Sip Cas Timer Profile Status Commands	6449
151.32 Voice Sip Cas Signaling Profile Status Commands	6450
151.33 Voice Sip Isdn And Cas Nsm Profile Index Status Commands	6451
151.34 Voice Sip Isdn Cas E1 Interface B channel Status Commands	6453
151.35 Voice Sip Isdn/Cas Termination Status Commands	6455
151.36 Voice Sip Isdn PUID Termination Status Commands	6458
151.37 Voice Sip Pri User To User Profile Status Commands	6460
151.38 Voice Sip Physical Interface Status Commands	6461
151.39 Voice Sip Trunk Sub-group Status Commands	6474
151.40 Voice Sip L1 Transport Statistics Commands	6476
151.41 Voice Sip NE Board Status Commands	6478
151.42 Call Query state show command	6480
151.43 Call Query result show command	6481
151.44 Voice Megaco Equipment Board Status Commands	6483
151.45 Voice Megaco Equipment Status Commands	6485
151.46 Voice Megaco Equipment Secondary Termination Status Commands	6488
151.47 Voice Megaco MGI Status Commands	6491
151.48 Voice Megaco Database Status Commands	6493
151.49 Voice Megaco IP Status Commands	6494
151.50 Voice Megaco SGI Status Commands	6495
151.51 Summary of Current Operational Parameters for ONT VoIP	6497
151.52 Summary of Call History Operational Parameters	6499
151.53 Voice ONT POTS MLT Test Status Command	6502
151.54 Voice ONT POTS PB Dialtone Test Status Command	6507

151.55 Voice ONT POTS SIP Dialtone Test Status Command	6510
151.56 Summary of Actual Operational data for ONT VoIP Config Command	6512
151.57 Voice ONT POTS Hook State Command	6517
151.58 Voice TC Olt-side Current Interval Status Command	6519
151.59 Voice TC Olt-side Previous Interval Status Command	6521
151.60 Voice TC Ont-side Current Interval Status Command	6523
151.61 Voice TC Ont-side Previous Interval Status Command	6525
151.62 GPON Voip Configuration Status Command	6527
151.63 Voice GPON POTS RTP Current Statistics Command	6530
151.64 Voice GPON POTS RTP Prev Statistics Command	6532
151.65 Current Interval PM stats of ONT MGC Agent Command	6534
151.66 Voice Gpon POTS Call Statistics Command for Current 15 Minutes	6536
151.67 Voice Gpon POTS Call Statistics Command for Previous 15 Minutes	6538
151.68 GPON Ont Sip Status Command	6540
151.69 Voice Gpon SIP Agent Statistics Command for Current 15 Minutes	6542
151.70 Voice Gpon SIP Call Statistics Command for Current 15 Minutes	6545
151.71 Voice ONT Operational data for pots line profile download status Command	6547
151.72 Voice ONT Operational data for voip client profile download status Command	6549
151.73 Voice extline Status Commands	6551
151.74 Voice pseudo wire Status Commands	6553
151.75 Voice pseudo wire udp port Commands	6555
 152- Epon Ont Status Command	 6556
152.1 Epon Ont Status Command Tree	6557
152.2 ONT Interface Status Command	6558
152.3 Epon Ont Voice media gateway Status Command	6560
152.4 Epon Ont Voice Sip UserAgent Status Command	6562
 153- Show Epon Ont Pots Command	 6564
153.1 Show Epon Ont Pots Command Tree	6565
153.2 Epon Ont Pots Information Command	6566
153.3 Epon Ont Pots Statistics Command	6569
 154- Voice LSA Server System Status Commands	 6571
154.1 Voice LSA Server System Status Command Tree	6572
154.2 Voice LSA Server System Status Commands	6573
 155- Voice LSA Server Instance Status Commands	 6574
155.1 Voice LSA Server Instance Status Command Tree	6575
155.2 Voice LSA Server Instance Status Commands	6576
 156- Voice LSA Server Emergency Status Commands	 6577
156.1 Voice LSA Server Emergency Status Command Tree	6578
156.2 Voice LSA Server System Status Commands	6579
 157- L2CP Status Commands	 6581
157.1 L2CP Status Command Tree	6582
157.2 L2CP Status Command	6583
157.3 L2CP Status Command	6585
157.4 L2CP Status Command	6587
157.5 L2CP Partition Status Command	6588
 158- Ethernet Lt Configuration Data Status Commands	 6589
158.1 Ethernet Lt Configuration Data Status Command Tree	6590
158.2 Ethernet Port Interface Configuration Status Command	6591

158.3 Ethernet IGMP Configuration Status Command	6593
158.4 Ethernet Security PAE Configuration Status Command	6596
158.5 Ethernet BridgePort Configuration Status Command	6599
158.6 Ethernet QoS Configuration Status Command	6603
159- Ethernet Status Commands	6605
159.1 Ethernet Status Command Tree	6606
159.2 Interface MAU Status Command	6608
159.3 SFP status commands	6614
159.4 Ethernet Counters Near End Line Current 15 Min	6616
159.5 Ethernet Counters Near End Line Current Day	6619
159.6 Ethernet Counters Near End Line Previous 15 Min	6622
159.7 Ethernet Counters Near End Line Previous Day	6625
159.8 Ethernet PM Interval Per Interface Status Command	6628
159.9 Ethernet Lt Dot3 Status Command	6630
159.10 Ethernet RMON Counters Status Command	6632
159.11 Ethernet Statistics Line Status Command	6636
159.12 Ethernet Ont Port Operational Status Command	6639
159.13 ONT Ethernet Port Performance Monitoring Current-Interval Status Command	6641
159.14 ONT Ethernet Port Performance Monitoring Previous-Interval Status Command	6643
159.15 Ethernet Ont Port loopback Status Command	6646
159.16 Epon Ont Ethernet Status Command	6648
159.17 Epon Ont Ethernet Port Information Command	6649
159.18 Epon Ont Ethernet Port Fdb Command	6653
159.19 Epon Ont Ethernet Status Command	6655
159.20 Epon Ont Ethernet Current 15min Status Command	6656
159.21 Epon Ont Ethernet Current 1Day Status Command	6661
159.22 Epon Ont Ethernet Previous 15min Status Command	6666
159.23 Epon Ont Ethernet Previous 1day Status Command	6671
160- Ethernet Lt Operational Data Status Commands	6676
160.1 Ethernet Lt Operational Data Status Command Tree	6677
160.2 Ethernet Port Operational Status Command	6678
160.3 Ethernet BridgePort Operational Status Command	6680
160.4 Ethernet Port Interface Operational Status Command	6682
160.5 Ethernet IGMP Operational Status Command	6684
160.6 Ethernet Port Ip Bridge Operational Status Command	6687
160.7 Ethernet QoS Opertaional Status Command	6689
161- Debug Status Commands	6691
161.1 Debug Status Command Tree	6692
161.2 SW Error Log Status Command	6693
162- Trouble-Shooting Status Commands	6694
162.1 Trouble-Shooting Status Command Tree	6695
162.2 Trouble-shooting Statistics To One Port	6696
162.3 Trouble-shooting Statistics on a Port (DSL or Ethernet) or PVC Interface	6698
162.4 Trouble-shooting Statistics To One VlanPort	6700
162.5 Summary Trouble-shooting Statistics To Vlan Ports	6702
162.6 Extensive Trouble-shooting Statistics To Vlan Ports	6705
162.7 Trouble-shooting Statistics Over Channel-pair	6709
162.8 Extensive Trouble-shooting ipv4-antispoofing Statistics To One UNI Port	6712
162.9 Trouble-shooting Statistics To One VlanPort	6714
162.10 Summary Trouble-shooting Statistics To Vlan Ports	6716
162.11 Extensive Trouble-shooting Statistics To Vlan Ports	6719
162.12 Trouble-shooting PBIT Statistics	6723
162.13 Trouble-shooting PBIT Statistics	6724

163- Trouble-Shooting Pbit Counter Commands	6727
163.1 Trouble-Shooting Pbit Counter Command Tree	6728
163.2 Trouble-shooting PBIT Statistics	6729
164- Trouble-Shooting Pon Status Commands	6732
164.1 Trouble-Shooting Pon Status Command Tree	6733
164.2 Trouble-shooting Statistics over Pon Port	6734
165- Trouble-Shooting Color Counter Commands	6737
165.1 Trouble-Shooting Color Counter Command Tree	6738
165.2 Trouble-shooting Color Statistics	6739
166- CFM Status Commands	6743
166.1 CFM Status Command Tree	6744
166.2 Maintenance Domain on NT Status Command	6746
166.3 Maintenance Association on NT Status Command	6748
166.4 Maintenance Association End Point on NT Status Command	6752
166.5 CFM Stack on NT Status Command	6756
166.6 Maintenance Association End Point CCM Database show Command	6759
166.7 Maintenance Association End Point on NT Runtime Info Command	6762
166.8 LT CFM SLM Responder Statistics Table	6766
166.9 PM proactive show	6768
166.10 Proactive CFM PM show command for the current 15 min	6769
166.11 Proactive CFM PM show command for the current 15 min	6770
166.12 Proactive CFM PM show command for the current 1 day	6775
166.13 Proactive CFM PM show command for the current 1 day	6776
166.14 Proactive CFM PM show command for the previous 15 min	6781
166.15 Proactive CFM PM show command for the previous 15 min	6782
166.16 Proactive CFM PM show command for the previous 1 day	6787
166.17 Proactive CFM PM show command for the previous 1 day	6788
166.18 Maintenance Association End Point Y1731 AIS Info Command	6793
167- IPoA/E IW Status Commands	6795
167.1 IPoA/E IW Status Command Tree	6796
167.2 IPoA/E IW Interworking Port Status Command	6797
168- LineTest Status Commands	6799
168.1 LineTest Status Command Tree	6800
168.2 Megaco LineTest Available Session Status Command	6801
168.3 Megaco LineTest Session Status Command	6802
168.4 Megaco LineTest Line Status Command	6804
168.5 Megaco LineTest Lineld ExtReport Status Command	6808
168.6 SINGLE LineTest Available Session Status Command	6814
168.7 SINGLE LineTest Session Status Command	6815
168.8 SINGLE LineTest Line Status Command	6818
168.9 SINGLE LineTest Lineld ExtReport Status Command	6822
168.10 SINGLE LineTest Chipset Data Command	6829
168.11 SINGLE LineTest Session busy port Command	6830
168.12 MELT Selftest Status Command	6832
168.13 MELT reset Status Command	6834
168.14 MELT hardware Status Command	6836
169- LACP status commands	6837
169.1 LACP status commands Tree	6838

169.2 LACP Port Status Command	6839
169.3 LACP Group Status Command	6845
169.4 LACP Member Port Status Command	6848
170- LACP status commands	6850
170.1 LACP status commands Tree	6851
170.2 LACP Group Status Command	6852
170.3 LACP Group Status Command	6854
170.4 LACP Group Status Command	6856
171- MSTP Status Commands	6858
171.1 MSTP Status Command Tree	6859
171.2 MSTP Bridge Status Command	6860
171.3 MSTP Instance Status Command	6862
171.4 MSTP Network Port Status Command	6864
171.5 MSTP Port Instance Status Command	6867
172- Application Intelligence Status Commands	6870
172.1 Application Intelligence Status Command Tree	6871
172.2 Application show command	6872
172.3 AI Platform show command	6874
172.4 Application 'download and installation' show command	6876
173- Distributed Service Status Commands	6878
173.1 Distributed Service Status Command Tree	6879
173.2 Service Access Mapping Status Command	6880
173.3 APIPE-PVC Statistics Command	6882
174- IPv6 Users Status Commands	6884
174.1 IPv6 Users Status Command Tree	6885
174.2 IPv6 Users Status Command	6886
175- Bcmp Statistics Commands	6890
175.1 Bcmp Statistics Command Tree	6891
175.2 Bcmp Statistics Command	6892
176- E1 Line Operational status Commands	6894
176.1 E1 Line Operational status Command Tree	6895
176.2 E1 line status Command	6896
176.3 E1 diagnostic status Command	6898
177- E1 Line Counters Command	6900
177.1 E1 Line Counters Command Tree	6901
177.2 E1 Current Interval Performance Data Status Command	6902
177.3 E1 Current 1 Day Performance Data Status Command	6904
177.4 E1 Previous Interval Performance Data Status Command	6906
177.5 E1 Previous 1 Day Performance Data Status Command	6908
178- Dual-Parenting Protection Group Status Commands	6910
178.1 Dual-Parenting Protection Group Status Command Tree	6911
179- Dual-Parenting Protection Group Status Commands	6912
179.1 Dual-Parenting Protection Group Status Command Tree	6913

179.2 Dual-Parenting Protection Group Status Commands	6914
180- Multicast Status Commands	6917
180.1 Multicast Status Command Tree	6918
180.2 IGMP System Status Command	6919
180.3 IGMP System Status Command	6920
180.4 IGMP Channel Sources Status Command	6922
180.5 IGMP Channel Miscellaneous Status Command	6925
180.6 IGMP Channel Protocol Status Command	6928
180.7 IGMP Module Counter Status Command	6932
180.8 IGMP Module Time Status Command	6935
180.9 IGMP Module Miscellaneous Status Command	6937
180.10 IGMP Group to Package Status Command	6939
180.11 Show Multicast Channel Statistics Command	6940
180.12 IGMP package to multicast source Command	6942
181- Security Status Commands	6943
181.1 Security Status Command Tree	6944
181.2 Operator Information Status Command	6946
181.3 Domain Status Command	6948
181.4 User Sessions Status Command	6949
181.5 Connection Profile Status Command	6956
181.6 RADIUS Authentication Server Status Command	6957
181.7 RADIUS Authentication Server Statistics Command	6959
181.8 RADIUS Accounting Server Statistics Command	6962
181.9 RADIUS Accounting Server Status Command	6965
181.10 RADIUS Dynamic Authentication Client Status Command	6966
181.11 RADIUS Next Available Index Command	6968
181.12 RADIUS Client Status Command	6969
181.13 Tacacs authentication Server Status Command	6970
181.14 TACACS Authentication Server Statistics Command	6972
181.15 Tacacs authorization Server Status Command	6975
181.16 TACACS Authorization Server Statistics Command	6977
181.17 Tacacs Accounting Server Status Command	6979
181.18 TACACS Accounting Server Statistics Command	6980
181.19 PAE Authenticator Status Command	6982
181.20 EAPOL Statistics Command	6986
181.21 Diagnostic Information Status Command	6989
181.22 Session Statistics Command	6994
181.23 PAE Port System Status Command	6997
181.24 MAC Address related EAPOL Status Command	6999
181.25 MAC Address related EAPOL Status Command	7001
181.26 MAC Address related EAPOL Status Command	7006
181.27 SSH Server Status Command	7011
181.28 SSH Server Key Generation Progress Status Command	7012
181.29 SSH Authentication Key Status Command	7013
181.30 SSH Authentication Key Generation Progress Status Command	7014
181.31 PM File Upload Status Command	7015
181.32 5-min CDR File Upload Status Command	7017
182- Alarm Management Commands	7018
182.1 Alarm Management Command Tree	7019
182.2 Alarm Management Command	7020
182.3 Snapshot Management Command	7021
182.4 Alarm Delta Log Management Command	7023
182.5 Log Management Command	7024
182.6 Alarm Filetransfer Manual Clearance Management Command	7025
182.7 Alarm Failed Login Manual Clearance Management Command	7026

183- ATM Management Commands	7027
183.1 ATM Management Command Tree	.7028
183.2 ATM Port Management Command	.7029
184- IGMP Management Commands	7031
184.1 IGMP Management Command Tree	.7032
184.2 IGMP Management Command	.7033
184.3 IGMP Multicast Sources Management Command	.7034
184.4 IGMP Multicast Channel Management Command	.7035
184.5 IGMP Multicast Channel Management Command	.7036
184.6 IGMP Slot Management Command	.7038
184.7 IGMP Join/leave Debug Management Command	.7039
184.8 IGMP Channel Management Command	.7042
185- PPPoX Management Commands	7045
185.1 PPPoX Management Command Tree	.7046
185.2 PPPoX Engine Port Management Command	.7047
186- PPPoEL2 Statistics Management Commands	7048
186.1 PPPoEL2 Statistics Management Command Tree	.7049
186.2 PPPoEL2 Statistics Management Command	.7050
187- PPPoE Management Commands	7053
187.1 PPPoE Management Command Tree	.7054
187.2 PPPoE Management Command	.7055
188- xDSL Management Commands	7058
188.1 xDSL Management Command Tree	.7059
188.2 xDSL Line Management Command	.7060
189- Gpon xDSL Management Commands	7062
189.1 Gpon xDSL Management Command Tree	.7063
189.2 Gpon xDSL Line Management Command	.7064
190- Software Management Commands	7066
190.1 Software Management Command Tree	.7067
190.2 Software Management Command	.7068
190.3 OSWP Software Management Command	.7069
190.4 Database Management Command	.7071
190.5 File Management Command	.7074
190.6 Ihub Software Management Command	.7075
190.7 IHUB Database Management Command	.7076
190.8 Iacm Software Management Command	.7077
190.9 IACM Database Management Command	.7078
190.10 CDE Management Command	.7079
190.11 TLS CA Management Command	.7080
190.12 Reborn Reformation Command	.7081
190.13 Lightspan Migration Management Command	.7082
190.14 Lightspan Migration Management Command	.7083
191- SHDSL Management Commands	7084
191.1 SHDSL Management Command Tree	.7085

191.2 SHDSL Segment Configuration Command	7086
192- Session Management Commands	7088
192.1 Session Management Command Tree	7089
192.2 Forced Disconnect Session Command	7090
193- System Management Commands	7091
193.1 System Management Command Tree	7092
193.2 SYSLOG Management command	7093
193.3 Secure Shell Server Key Regeneration Command	7094
193.4 SSH Authentication Key Generation Command	7095
193.5 PM File Upload Management Command	7096
193.6 Remove locked IP from CLI failed login sources	7097
193.7 CPU Load Management Command	7098
193.8 Techsupport management Command	7100
193.9 Techsupport Generate On Demand Command	7101
193.10 Techsupport Clear On Demand Command	7103
193.11 FIPS Command	7104
194- UDP/SSH debug Management Commands	7105
194.1 UDP/SSH debug Management Command Tree	7106
194.2 Forced Disconnect UDP/SSH debug Command	7107
195- Trouble-Shooting Management Commands	7108
195.1 Trouble-Shooting Management Command Tree	7109
195.2 Trouble-shooting Interface Management Commands	7110
196- Trouble-Shooting Management Commands	7113
196.1 Trouble-Shooting Management Command Tree	7114
196.2 Trouble-shooting Pon Interface Management Commands	7115
197- Trouble-Shooting Management Commands	7117
197.1 Trouble-Shooting Management Command Tree	7118
197.2 Trouble-shooting pbit counter Interface Management Commands	7119
198- Trouble-Shooting Management Commands	7122
198.1 Trouble-Shooting Management Command Tree	7123
198.2 Trouble-shooting color counter Interface Management Commands	7124
199- Voice Ont Management Commands	7127
199.1 Voice Ont Management Command Tree	7128
199.2 Voice Megaco Database Management Command	7130
199.3 Voice Megaco Equipment Admin Commands	7131
199.4 Voice Megaco Termination Lock Management Command	7132
199.5 Voice Megaco Secondary Termination Lock Management Command	7134
199.6 Voice Megaco Media Gateway Lock Management Command	7136
199.7 Voice Sip L1 Transport Statistics Commands	7138
199.8 Voice POTS Diagnostics Management Command	7139
199.9 Voice POTS Pull-Break Management Command	7142
199.10 Voice SIP Pull-Break Management Command	7144
199.11 GPON Voip Configuration Management Command	7146
200- MSTP Management Commands	7148

200.1 MSTP Management Command Tree	7149
200.2 MSTP Port Management Command	7150
201- Distributed Service Management Commands	7151
201.1 Distributed Service Management Command Tree	7152
201.2 APIPE-PVC Statistics Command	7153
202- Pon Management Commands	7154
202.1 Pon Management Command Tree	7155
202.2 Pon Bit Error Statistics Commands	7156
202.3 PON Rogue Test Diagnostic Command	7158
202.4 PON Utilization PM Reset Command	7160
202.5 PON Peak Utilization PM Reset Command	7162
202.6 Pon RangeNumMismatch Alarm Reset Commands	7164
202.7 Ont on Given Pon Reboot Commands	7166
203- Channel Pair Management Commands	7168
203.1 Channel Pair Management Command Tree	7169
203.2 NGPON2 Rogue Test Diagnostic Command	7170
203.3 Channel Pair Utilization PM Reset Command	7172
203.4 Channel Pair Peak Utilization PM Reset Command	7173
203.5 Pon RangeNumMismatch Alarm Reset Commands	7174
203.6 NGPON2 Rogue Ont Reboot Command	7175
204- CESUNI Management Commands	7176
204.1 CESUNI Management Command Tree	7177
204.2 CESUNI Loopback Management Command	7178
205- CFM Management Commands.	7180
205.1 CFM Management Command. Tree	7181
205.2 Unicast Loopback message Management Command	7182
205.3 CFM Multicast Loopback Management Command	7186
205.4 CFM Linktrace management command	7188
205.5 Linktrace message Management Command	7189
205.6 CFM Single Ended Synthetic Loss Measurement message Management Command	7195
205.7 Single Ended Synthetic Loss Measurement message Management Command	7196
206- Protection Group Management Commands	7199
206.1 Protection Group Management Command Tree	7200
206.2 Protection Group Switchover Management Command	7201
207- Efm Oam Management Command	7203
207.1 Efm Oam Management Command Tree	7204
207.2 Efm Oam Interface Management Command	7205
208- Epon Management Command	7207
208.1 Epon Management Command Tree	7208
208.2 Epon Ont Ethernet Reautodetect Management Command	7209
209- Iphost Management Command.	7210
209.1 Iphost Management Command. Tree	7211
209.2 Iphost ping test Management Command	7212

210- LineTest Management Commands	7215
210.1 LineTest Management Command Tree	7216
210.2 MELT reset Status Command	7217
210.3 MELT Selftest Status Command	7218
211- BER LineTest Configuration Commands	7219
211.1 BER LineTest Configuration Command Tree	7220
211.2 E1 BER test command	7221
212- Dual-Parenting Protection Group Management Commands	7223
212.1 Dual-Parenting Protection Group Management Command Tree	7224
212.2 Dual-Parenting Protection Group Management Command	7225
213- Dual-Parenting Protection Group Switchover Management Commands	7226
213.1 Dual-Parenting Protection Group Switchover Management Command Tree	7227
213.2 Dual-Parenting Protection Group Switchover Management Command	7228
214- Equipment Management Commands	7230
214.1 Equipment Management Command Tree	7231
214.2 Equipment Management Command	7232
214.3 Slot Management Command	7233
214.4 Slot Management Command	7235
215- ONT Management Command	7237
215.1 ONT Management Command Tree	7238
215.2 ONT Interface Management Command	7239
215.3 ONT Card Management Command	7241
215.4 ONT Software Control Management Command	7243
215.5 ONT Software Version Management Command	7244
215.6 ONT Data Store Management Command	7245
215.7 ONT Reboot via SN Management Command	7247
216- EONT Management Command	7248
216.1 EONT Management Command Tree	7249
216.2 Epon ONT reboot command	7250
216.3 Epon Ont Software Management Command	7251
216.4 Epon Ont LLID Loopback Command	7252
216.5 EONT Software Version Management Command	7253
217- Protection Group Management Commands	7254
217.1 Protection Group Management Command Tree	7255
217.2 Protection Group NT switchover Command	7256
218- Ethernet Management Commands	7257
218.1 Ethernet Management Command Tree	7258
218.2 Ethernet Management Command	7259
218.3 Ethernet Statistics Commands	7260
218.4 Epon Ont Ethernet Reautodetect Command	7261
218.5 Gpon Ont Ethernet loopback Command	7262
219- Bridge Management Commands	7264
219.1 Bridge Management Command Tree	7265

219.2 Learned Unicast MAC Address Management Command	7266
219.3 VLAN Management Command	7269
220- Trap Management Commands	7270
220.1 Trap Management Command Tree	7271
220.2 Trap Manager Management Command	7272
221- Interface Management commands	7273
221.1 Interface Management commands Tree	7274
221.2 Interface Troubleshooting Ethernet Statistics Commands	7275
222- DHCP Management Command	7276
222.1 DHCP Management Command Tree	7277
222.2 DHCP Relay User Port Management Command	7278
222.3 DHCP Relay User Port Management Command	7281
223- ARP-RELAY statistics Management Commands	7284
223.1 ARP-RELAY statistics Management Command Tree	7285
223.2 Arp-relay statistics Management Command	7286
224- Transport Management Commands	7289
224.1 Transport Management Command Tree	7290
224.2 IP Net-to-media Management Command	7291
225- SNTP Management Commands	7292
225.1 SNTP Management Command Tree	7293
225.2 SNTP Management Command	7294
226- Transactions Management Commands	7295
226.1 Transactions Management Command Tree	7296
226.2 Transaction Configuration Management Command	7297
227- Security Management Commands	7298
227.1 Security Management Command Tree	7299
227.2 Security 802.1x Port Authentication Management Command	7300
228- Security Management Commands	7302
228.1 Security Management Command Tree	7303
228.2 Security 802.1x Port Authentication Management Command	7304
229- Debug commands	7306
229.1 Debug commands Tree	7307
229.2 Debug commands	7308
230- Remote debug Commands	7309
230.1 Remote debug Command Tree	7310
230.2 Remote debug	7311
230.3 Remote debug ONT	7312
231- TcpDump Command	7314
231.1 TcpDump Command Tree	7315

231.2 TcpDump Command	7316
231.3 tcpdump tool	7317
231.4 tcpdump tool	7318
231.5 tcpdump tool	7319
232- Clear Commands	7320
232.1 Clear Command Tree	7321
232.2 Clear Command	7322
233- IHUB Commands	7323
234- Global And Environmental Commands	7329
234.1 History Command	7330
234.2 Echo Command	7331
234.3 Telnet Command	7332
234.4 Telnet AI Command	7333
234.5 Exec Command	7334
234.6 Sleep Command	7336
234.7 Tree Command	7337
234.8 Write Command	7338
234.9 Logout Command	7339
234.10 Help Command	7340
234.11 Info Command	7341
234.12 Exit Command	7344
234.13 Back Command	7345
234.14 Delete Command	7346
234.15 In Command	7347
234.16 Configure Command	7348
234.17 Action Command	7350
234.18 Show Command	7351
234.19 Recursive Show Command	7352
234.20 Sample Command	7353
234.21 Poll Command	7354
234.22 Debug Command	7355
234.23 Sysfil Command	7356
235- CLI Filters	7357
235.1 Count Filter	7358
235.2 Match Filter	7359
235.3 Tee Filter	7361
235.4 Tee Config Filter	7362
236- CLI Printers	7363
236.1 More	7364
236.2 No-More	7365
236.3 Discard	7366
Index	7367

1- ISAM CLI

1.1 History	1-2
1.2 Preface	1-143
1.3 CLI Commands	1-144
1.4 Nodes	1-146
1.5 Parameters	1-147
1.6 Filters	1-150
1.7 Printers	1-151
1.8 Getting help	1-152
1.9 The CLI Prompt	1-153
1.10 Entering CLI Commands	1-154
1.11 CLI Backward Compatibility	1-155
1.12 Phase Out Strategy Obsolete Commands and/or Parameters	1-157
1.13 Command Phase Out Announcement Release	1-158

1.1 History

This history section enumerates the CLI commands which are new, modified or removed between any two subsequent releases. No details are provided within this section. The command description, syntax and parameters for each new and modified command is in the Command Syntax section of the respective command in the CLI Command Guide. To know the difference between e.g R4.6 and R4.5, review the delta's of the releases R4.5.01 versus R4.5 and R4.5.02 versus R4.5.01 and R4.6 versus R4.5.02.

Command delta R6.2.04ng versus R6.2.04na

Modified Commands
configure voice sip isdn-nsm-prof (adding area code in CgPN for PRA terminating call and set TON for terminating calls)
configure voice sip termination (support Auto-answer with DTMF sending)
New Commands
configure voice sip call-query (allows the operator to manage the sip call query session)
show voice sip call-query (shows the status of call query session)
show voice sip call-query-result (shows the result of call query session)

Command delta R6.2.04na versus R6.2.04n

Modified Commands
admin voice sip l1-trans-statistics (renamed old parameter from l1-transport-statistic to l1-trans-statistics)
configure voice sip cas-timer-prof (renamed presense-fw-sig to presence-fw-sig, dely-dial-min-dur to delay-dial-min, dely-dial-max-dur to delay-dial-max, rg-recall-min-dur to reg-recall-min, rg-recall-max-dur to reg-recall-max)
configure voice sip ne-board cap-id (renamed old parameter cap to cap-id)
configure voice sip network-element cap-id (renamed old parameter cap to cap-id)
configure voice sip phys-itf (DID Channel Bank support for E1/T1 access)
configure voice sip statistics (removed parameter l1-trans-stats)
show voice sip cas-sig-prof (DID Channel Bank support for E1/T1 access)
show voice sip cas-timer-prof (DID Channel Bank support for E1/T1 access)
show voice sip l1-trans-statistics (renamed old parameter from l1-transport-statistic to l1-trans-statistics)
show voice sip ne-board (renamed old parameter cap to cap-id, network-element to ne-id)
New Commands
configure voice sip cas-sig-prof (DID Channel Bank support for E1/T1 access)
show voice sip cas-sig-prof (DID Channel Bank support for E1/T1 access)

Command delta R6.2.04n versus R6.2.04

Modified Commands

configure alarm entry (add alarm board-shelf-mismatch and softDSP co-existing with RPNI-E (norpniewithsoftdsp))
configure alarm filter filterid (updated alarm list)
configure trap manager (cleanup unused parameters)
configure trap v6manager (cleanup unused parameters)
configure voice sip lineid-syn-prof (Channel Bank support for E1/T1 access)
configure voice sip pri-cas-tksg-term (cleanup obsolete parameters)
show alarm query name (updated alarm list)
show alarm query plug-in-unit-ext (new alarm board-shelf-mismatch)
show alarm query sip-plugin-unit (new alarm for no rpni-e with soft dsp)
show voice sip pri-cas-tksg-term ()

New Commands

admin voice sip l1-trans-statistics (support cross NIAT-A LT with using centralized solution)
configure voice sip cap (support cross NIAT-A LT with using centralized solution)
configure voice sip cas-timer-prof (Channel Bank support for E1/T1 access)
configure voice sip ne-board (support cross NIAT-A LT with using centralized solution)
configure voice sip network-element (support cross NIAT-A LT with using centralized solution)
configure voice sip phys-itf (PRI support improvements)
show voice sip cas-timer-prof (Channel Bank support for E1/T1 access)
show voice sip l1-trans-statistics (support cross NIAT-A LT with using centralized solution)
show voice sip ne-board (support cross NIAT-A LT with using centralized solution)
show voice sip phys-itf (PRI support improvements)
show voice sip tksg (parameter tksg replaces tksg-ds0-status and tksg-op-data)

Removed Commands

show voice sip tksg-ds0-status (parameter tksg replaces tksg-ds0-status)
show voice sip tksg-op-data (parameter tksg replaces tksg-op-data)

Command delta R6.2.04 versus R6.2.03

Modified Commands

admin pon ber-stats (add support for up to 25G capable PON boards)
admin pon clear-alarm (add support for up to 25G capable PON boards)
admin pon diagnostic (add support for up to 25G capable PON boards)

admin pon reboot-all-ont (add support for up to 25G capable PON boards)
admin pon utilization (add support for up to 25G capable PON boards)
admin trouble-shooting pon interface (add support for up to 25G capable PON boards)
configure alarm entry (add alarm for LT backplane datalink failure ONT host IP allocation, ONT CRC error and TCA alarms)
configure alarm filter filterid (updated alarm list)
configure cfm domain association (update values for CCM interval)
configure channel-pair interface (upstream throughput improvements on XGS-PON/MPM)
configure equipment ont interface (add support for up to 25G capable PON boards)
configure interface cage (add value not-set for cage mode)
configure interface port (add support for up to 25G capable PON boards)
configure pon interface (upstream throughput improvements on XGS-PON/MPM)
configure qos interface (add support for up to 25G capable PON boards)
configure qos tca queue (add support for up to 25G capable PON boards)
configure system sync-if-timing ptp l2-ptp-port (support xfp modules for Ethernet clock interface)
configure system sync-if-timing ptp mstr-port-ds-prof (support 1588v2 multicast MAC address on FANT-F)
configure system sync-if-timing ptp slave-port-dataset (support 1588v2 multicast MAC address on FANT-F)
configure trap definition (update for Board Auto Plan feature)
configure trap manager (update for Board Auto Plan feature)
configure trouble-shooting pon statistics interface (add support for up to 25G capable PON boards)
configure trouble-shooting pon statistics threshold interface (add support for up to 25G capable PON boards)
show alarm query ellid (add support for up to 25G capable PON boards)
show alarm query epon (add support for up to 25G capable PON boards)
show alarm query name (updated alarm list)
show alarm query olt-gen (add support for up to 25G capable PON boards)
show alarm query olt-pon-tc-tca (add support for up to 25G capable PON boards)
show alarm query olt-pon-util-tca (add support for up to 25G capable PON boards)
show alarm query ont-iphost (ONT KPI improvements (OLT side))
show alarm query ont-l2uni-eth-tca (ONT KPI improvements (OLT side))
show alarm query otdr (add support for up to 25G capable PON boards)
show alarm query plug-in-unit (add alarm for LT backplane datalink failure)
show interface port (add support for up to 25G capable PON boards)
show interface stack (add support for up to 25G capable PON boards)
show interface test (add support for up to 25G capable PON boards)
show mcast pon-active-groups (add support for up to 25G capable PON boards)
show pon ber-stats (add support for up to 25G capable PON boards)

show pon cfg-download (add support for up to 25G capable PON boards)
show pon interface fec-tc-layer current-interval (add support for up to 25G capable PON boards)
show pon interface mcast-tc-layer current-interval (add support for up to 25G capable PON boards)
show pon interface mcast-tc-layer previous-interval (add support for up to 25G capable PON boards)
show pon interface phy-layer current-interval (add support for up to 25G capable PON boards)
show pon interface tc-layer current-interval (add support for up to 25G capable PON boards)
show pon interface tc-layer previous-interval (add support for up to 25G capable PON boards)
show pon interface xg-tc-layer current-interval (add support for up to 25G capable PON boards)
show pon interface xg-tc-layer previous-interval (add support for up to 25G capable PON boards)
show pon optics (add support for up to 25G capable PON boards)
show pon pon-diagnostics (add support for up to 25G capable PON boards)
show pon sfp-inventory (add support for up to 25G capable PON boards)
show pon sw-download (add support for up to 25G capable PON boards)
show pon utilization cur-intvl-top-ont-rx (add support for up to 25G capable PON boards)
show pon utilization cur-intvl-top-ont-tx (add support for up to 25G capable PON boards)
show pon utilization current-interval (add support for up to 25G capable PON boards)
show pon utilization previous-interval (add support for up to 25G capable PON boards)
show pon utilization prv-intvl-top-ont-rx (add support for up to 25G capable PON boards)
show pon utilization prv-intvl-top-ont-tx (add support for up to 25G capable PON boards)
show qos bandwidth-profile (add support for up to 25G capable PON boards)
show qos interface-bandwidth (add support for up to 25G capable PON boards)
show qos statistics color-queue current-15min (add support for up to 25G capable PON boards)
show qos statistics color-queue prev-15min (add support for up to 25G capable PON boards)
show qos statistics queue current-15min (add support for up to 25G capable PON boards)
show qos statistics queue prev-15min (add support for up to 25G capable PON boards)
show trouble-shooting pon statistics interface (add support for up to 25G capable PON boards)

New Commands

configure mcast-control mc-pon-vlan-xlate (Missing mc-pon-vlan-xlate node)
show alarm current ont-tca (ONT KPI improvements (OLT side))
show alarm log ont-tca (ONT KPI improvements (OLT side))
show alarm query ont-tca (ONT KPI improvements (OLT side))
show alarm snap-shot ont-tca (ONT KPI improvements (OLT side))
show equipment ont status twenty-five-g (add support for up to 25G capable PON boards)

Commands or commands with parameters for future use, not supported yet

admin channel-pair peak-utilization (add PON Utilization PM Counter to capture unicast microbursts)
admin pon peak-utilization (add PON Utilization PM Counter to capture unicast microbursts)

show channel-pair peak-utilization (add PON Utilization PM Counter to capture unicast microbursts)
show channel-pair peak-utilization cur-intvl-top-ont-rx (add PON Utilization PM Counter to capture unicast microbursts)
show channel-pair peak-utilization cur-intvl-top-ont-tx (add PON Utilization PM Counter to capture unicast microbursts)
show channel-pair peak-utilization current-interval (add PON Utilization PM Counter to capture unicast microbursts)
show channel-pair peak-utilization previous-interval (add PON Utilization PM Counter to capture unicast microbursts)
show channel-pair peak-utilization prv-intvl-top-ont-rx (add PON Utilization PM Counter to capture unicast microbursts)
show channel-pair peak-utilization prv-intvl-top-ont-tx (add PON Utilization PM Counter to capture unicast microbursts)
show pon peak-utilization (add PON Utilization PM Counter to capture unicast microbursts)
show pon peak-utilization cur-intvl-top-ont-rx (add PON Utilization PM Counter to capture unicast microbursts)
show pon peak-utilization cur-intvl-top-ont-tx (add PON Utilization PM Counter to capture unicast microbursts)
show pon peak-utilization current-interval (add PON Utilization PM Counter to capture unicast microbursts)
show pon peak-utilization previous-interval (add PON Utilization PM Counter to capture unicast microbursts)
show pon peak-utilization prv-intvl-top-ont-rx (add PON Utilization PM Counter to capture unicast microbursts)
show pon peak-utilization prv-intvl-top-ont-tx (add PON Utilization PM Counter to capture unicast microbursts)

Command delta R6.2.03 versus R6.2.02

Modified Commands
admin system fips (OpenSSL upgrade to 1.1.1.d. Command obsoleted on FANT-G.)
configure alarm entry (new alarms e1t1itf-recv-ais, e1t1itf-recv-los, e1t1itf-recv-rai and new alarm internal-clk-fail for FANT-G Oscillator failure)
configure alarm entry (support alarm olt-gen-ddr-fault)
configure alarm filter filterid (updated alarm list)
configure bridge port vlan-id (improve IOP with ZTE ONT)
configure equipment ont interface (support auto-match value for planned-us-rate ONT parameter for combo-PON)
configure equipment ont interface (updated default fec-up for gpon ONT on mpm)
configure equipment slot (support 40GBase-KR4)
configure interface cage (support MPM combo mode)
configure qos tca queue (removed obsolete parameter value lbackpl-lin)
configure system (support 40GBase-KR4)

configure system fips (OpenSSL upgrade to 1.1.1.d. Command obsoleted on FANT-G.)
configure system sync-if-timing ptp link-port-compensation (support FWLT-C)
configure system sync-if-timing ssmout-synce (support FWLT-C)
configure system sync-if-timing synce (support FWLT-C)
configure voice sip manipulate-rule (update mechanism to set the system under priority mode and call duration)
configure voice sip termination (update parameter definition for display-name)
configure qos interface (removed obsolete parameter value ltbackpl-lin)
show alarm query name (updated alarm list)
show alarm query sync (new alarm internal-clk-fail for FANT-G Oscillator failure)
show linetest single lineid-ext-rept (support NIAT-A SIP PRI)
show qos interface-bandwidth (removed obsolete parameter value ltbackpl-lin)
show qos statistics color-queue current-15min (removed obsolete parameter value ltbackpl-lin)
show qos statistics color-queue prev-15min (removed obsolete parameter value ltbackpl-lin)
show qos statistics queue current-15min (removed obsolete parameter value ltbackpl-lin)
show qos statistics queue prev-15min (removed obsolete parameter value ltbackpl-lin)
show system license (add license for FGUT-A upgradable GPON LT card for 10G PON evolution)
show system license-usage (add license for FGUT-A upgradable GPON LT card for 10G PON evolution)
show voice sip redundancy-node ext-redundancy-state (support NIAT-A SIP PRI)
show voice sip termination (update mechanism to set the system under priority mode and call duration)

New Commands

configure voice sip pri-cas-tksg-puid (one PRI interface to support multiple PRI groups)
configure voice sip pri-cas-tksg-term (one PRI interface to support multiple PRI groups)
configure voice sip tksg (one PRI interface to support multiple PRI groups)
configure voice sip user-to-user-prof (UUS3 Signaling convey between ISDN Q.931 and SIP)
show alarm current e1t1-interface (one PRI interface to support multiple PRI groups)
show alarm log e1t1-interface (one PRI interface to support multiple PRI groups)
show alarm snap-shot e1t1-interface (one PRI interface to support multiple PRI groups)
show system license-usage (show license usage for FGUT-A upgradable GPON LT card for 10G PON evolution)
show voice sip pri-cas-tksg-puid (one PRI interface to support multiple PRI groups)
show voice sip pri-cas-tksg-term (one PRI interface to support multiple PRI groups)
show voice sip tksg-ds0-status (one PRI interface to support multiple PRI groups)
show voice sip tksg-op-data (one PRI interface to support multiple PRI groups)
show voice sip user-to-user-prof (UUS3 Signaling convey between ISDN Q.931 and SIP)

Commands or commands with parameters for future use, not supported yet

configure equipment ont interface (show additional info on ONT status)
--

```
show ont-info (show additional info on ONT status)
```

Command delta R6.2.02 versus R6.2.01

Modified Commands
admin ethernet statistics (support backplane LT link on FELT-C)
admin interface trouble-shooting ethernet statistics (support backplane LT link on FELT-C)
admin pon (x-pon prefix is used for XGSPON ports for all boards)
admin trouble-shooting pon interface (x-pon prefix is used for XGSPON ports for all boards)
configure alarm entry (NIAT-A LT ISDN PRI SIP alarms to interop with SIP server, FELT-B 40GBase-KR4 backplane alarm. Alarm olt-gen-ddr-fault not supported yet)
configure alarm filter filterid (updated alarm list)
configure interface port (x-pon prefix is used for XGSPON ports for all boards)
configure linetest single ltparm test-name (parameter values e1-remotelb e1-ploadlb e1-locallb e1-cablelb renamed to remotelb ploadlb locallb cablelb)
configure link-agg group (support FELT-C Cross-IWF LAG)
configure pon interface (x-pon prefix is used for XGSPON ports for all boards)
configure qos interface (support backplane LT link on FELT-C)
configure qos interface (x-pon prefix is used for XGSPON ports for all boards)
configure qos tca queue (support backplane LT link on FELT-C)
configure qos tca queue (x-pon prefix is used for XGSPON ports for all boards)
configure system security ssh access (support debugkernel on FANT-G and FANT-H)
configure system sync-if-timing ptp l2-ptp-port (update for timing sync on FANT-H)
configure trouble-shooting pon statistics (x-pon prefix is used for XGSPON ports for all boards)
configure xdsl board vect-fallback rtx-profile (RTX profile index value range extended to 1024)
configure xdsl rtx-profile (RTX profile index value range extended to 1024)
show alarm query (x-pon prefix is used for XGSPON ports for all boards)
show alarm query name (updated alarm list)
show alarm query olt-gen (alarm olt-gen-ddr-fault not supported yet)
show efm-oam peer-oam-info (P2P LT 802.3ah, Ethernet in the First Mile, extension with dying gasp state)
show equipment ont status pon (x-pon prefix is added for all boards for XGSPON ports)
show equipment ont status pon (x-pon prefix is used for XGSPON ports for all boards)
show ethernet etherstats (support backplane LT link on FELT-C)
show interface (x-pon prefix is used for XGSPON ports for all boards)
show interface trouble-shooting ethernet statistics (support backplane LT link on FELT-C)
show mcast pon-active-groups (x-pon prefix is used for XGSPON ports for all boards)
show pon (x-pon prefix is used for XGSPON ports for all boards)
show pon (x-pon prefix is used for XGSPON ports for all boards)

show qos interface-bandwidth (support backplane LT link on FELT-C)
show qos interface-bandwidth (x-pon prefix is used for XGSPON ports for all boards)
show qos statistics (x-pon prefix is used for XGSPON ports for all boards)
show qos statistics color-queue current-15min (support backplane LT link on FELT-C)
show qos statistics color-queue prev-15min (support backplane LT link on FELT-C)
show qos statistics queue current-15min (support backplane LT link on FELT-C)
show qos statistics queue prev-15min (support backplane LT link on FELT-C)
show trouble-shooting pon statistics interface (x-pon prefix is used for XGSPON ports for all boards)
show xdsl vect-disturber-list downstream (alternative disturberlist reporting)

New Commands

show alarm current fcs-exceed (add FELT-B 40GBase-KR4 backplane alarm)
show alarm log fcs-exceed (add FELT-B 40GBase-KR4 backplane alarm)
show alarm query fcs-exceed (add FELT-B 40GBase-KR4 backplane alarm)
show alarm snap-shot fcs-exceed (add FELT-B 40GBase-KR4 backplane alarm)
show equipment ont status x-pon (x-pon prefix is added for all boards for XGSPON ports)
show link-agg resource board-iwf-info (support FELT-C Cross-IWF LAG)
show link-agg resource group (support FELT-C Cross-IWF LAG)
show link-agg resource iwf-group-info (support FELT-C Cross-IWF LAG)
show software-mngt upload-download-info (new command node to display actual available space in /Sw/ and /Ont/Sw/)
show system shub cpu-packet ratelimit (protect SHUB systems against DoS attacks)

Removed Commands

configure mcast channel (Note: do not use this command, is has been replaced by configure mcast chn)
--

Commands or commands with parameters for future use, not supported yet

configure equipment ont interface (auto-match value for planned-us-rate ONT parameter is not supported yet)
show linetest single lineid-ext-rept (NIAT-A SIP PRI CHT T1 not supported yet, parameters renamed)

Command delta R6.2.01 versus R6.2

Modified Commands

admin ethernet port (support PON Remote loopback control on ONT UNI, OLT part)
admin ethernet statistics (support backplane LT link on FELT-C)
admin interface trouble-shooting ethernet statistics (support backplane LT link on FELT-C)
admin system cpu-load (support ntio-1 qsf alarm)
configure alarm entry (support for Threshold Crossing Alarms)

configure alarm filter filterid (list of alarms updated)
configure bridge port (support compliance to OMCI Spec for XGS PON ONTs, support parameter value filtervlanandpbit)
configure bridge port vlan-id (support compliance to OMCI Spec for XGS PON ONTs, support parameter value usacceptframetype)
configure ethernet ont l2 pm-collect-ext (support OMCI PM and multicast status monitoring extensions)
configure l2uni ont performance-monitor pm-collect-ext (support OMCI PM and multicast status monitoring extensions)
configure qos interface (support backplane LT link on FELT-C)
configure qos tca queue (support backplane LT link on FELT-C)
configure system sync-if-timing ptp (update for timing sync on FANT-H)
configure system sync-if-timing ptp l2-ptp-port (update for timing sync on FANT-H)
configure system sync-if-timing ptp link-port-compensation (update for timing sync on FANT-H)
configure system sync-if-timing ptp ptp-domain (update for timing sync on FANT-H)
configure system sync-if-timing ptp slave-port-dataset (update for timing sync on FANT-H)
configure system sync-if-timing ptp tx-protocol (update for timing sync on FANT-H)
configure system sync-if-timing ref-order (update for timing sync on FANT-H)
configure system sync-if-timing ssm (update for timing sync on FANT-H)
configure system sync-if-timing tod-ref-order (update for timing sync on FANT-H)
configure tc-layer ont-side (support OMCI PM and multicast status monitoring extensions)
configure veip ont l2 pm-ext (support OMCI PM and multicast status monitoring extensions)
configure voice ont mgc-config (update for security profile ID and msg format in MEGACO config)
configure xdsl spectrum-profile vdsl (updated help text, a998ds35 added)
configure xdsl vce-profile (updated help text, a998ds35 added)
show alarm query ihub-link (support ntio-1 qsfm alarm)
show alarm query ihub-link (support ntio-1 qsfm alarm)
show alarm query ihub-tca (update for TR069 service mismatch adding ONT info for XGS-PON)
show alarm query name (support for Threshold Crossing Alarms)
show alarm query tr069serv (support ntio-1 qsfm alarm)
show equipment ont status pon (improved display values for XGS-PON interface under Combo mode)
show ethernet etherstats (support backplane LT link on FELT-C)
show ethernet ont loopback-info (support PON Remote loopback control on ONT UNI, OLT part)
show interface trouble-shooting ethernet statistics (support backplane LT link on FELT-C)
show l2uni ont mcast-subscriber (support OMCI PM and multicast status monitoring extensions)
show l2uni ont mcast-subscriber active-groups (support OMCI PM and multicast status monitoring extensions)
show l2uni ont mcast-subscriber general (support OMCI PM and multicast status monitoring extensions)
show l2uni ont performance-data-ext (support OMCI PM and multicast status monitoring extensions)
show l2uni ont performance-data-ext current-interval (support OMCI PM and multicast status monitoring extensions)

extensions)
show l2uni ont performance-data-ext previous-interval (support OMCI PM and multicast status monitoring extensions)
show pon ber-stats (improved display values for XGS-PON interface under Combo mode)
show pon cfg-download (improved display values for XGS-PON interface under Combo mode)
show pon sw-download (improved display values for XGS-PON interface under Combo mode)
show qos interface-bandwidth (support backplane LT link on FELT-C)
show qos statistics color-queue current-15min (support backplane LT link on FELT-C)
show qos statistics color-queue prev-15min (support backplane LT link on FELT-C)
show qos statistics queue current-15min (support backplane LT link on FELT-C)
show qos statistics queue prev-15min (support backplane LT link on FELT-C)
show system cpu-load (support ntio-1 qsfp alarm)
show system show system memory-usage (support ntio-1 qsfp alarm)
show system sync-ptp-currmaster (update for timing sync on FANT-H)
show system sync-ptp-slaveport (update for timing sync on FANT-H)
show tc-layer ont-side (support OMCI PM and multicast status monitoring extensions)
show voice ont mgc-agent statistics current-15min (support compliance to OMCI Spec for XGS PON ONTs)
show voice sip isdn-cas-cls-puid (update to show the status of every PUID)
show voice sip isdn-cas-term (update to show the status of every ISDN PRA or CAS R2 termination port)

New Commands

admin equipment applique (support applique restart via CLI)
configure system lt-link-tca-thresholds (support for Threshold Crossing Alarms)
configure system ptp (update for timing sync on FANT-H)
show software-mngt upload-download-dir (command to display the space in /Sw and /ONT/Sw)
show system lt-link-tca-thres (support for Threshold Crossing Alarms)

Command delta R62 versus R6.1.01

Modified Commands

admin pon ber-stats (parameter pon-leg removed, x-pon prefix introduced to identify the XGS-PON interface under MPM mode)
admin pon clear-alarm (parameter pon-leg removed, x-pon prefix introduced to identify the XGS-PON interface under MPM mode)
admin pon diagnostic (parameter pon-leg removed, x-pon prefix introduced to identify the XGS-PON interface under MPM mode)
admin pon utilization (parameter pon-leg removed, x-pon prefix introduced to identify the XGS-PON interface under MPM mode)
admin trouble-shooting pon interface (parameter pon-leg removed, x-pon prefix introduced to identify the

configure bridge port vlan-id (parameter value usacceptframetype not supported yet)
configure equipment diagnostics sfp (introduction of SFP1, SFP2, XFP1, XFP2 prefixes, for clean support of multi-channel PON optics)
configure equipment ont interface (L2 Bridge configuration adapted to IOP requirement)
configure equipment ont pm (command not supported yet)
configure equipment slot (added new input board types to allow pre-provisioning and introduced operational-mode parameter for PON boards that support several modes of operation)
configure equipment slot (new command to disable anti theft protection)
configure interface cage (introduced operational-mode parameter for PON boards that support several modes of operation)
configure interface cage (parameter oper-mode renamed to operational-mode)
configure interface port (parameter pon-leg removed, x-pon prefix introduced to identify the XGS-PON interface under MPM mode)
configure mcast-control system (corrected v6-src-ip-address help info)
configure pon interface (parameter pon-leg removed, x-pon prefix introduced to identify the XGS-PON interface under MPM mode)
configure qos interface (parameter pon-leg removed, x-pon prefix introduced to identify the XGS-PON interface under MPM mode)
configure qos tca queue (parameter pon-leg removed, x-pon prefix introduced to identify the XGS-PON interface under MPM mode)
configure system (update for softdsp feature)
configure system security (ISAM Copper and Fiber : RADIUS accounting for CLI operators)
configure trap manager (support anti theft protection)
configure trap v6manager (support anti theft protection)
configure trouble-shooting pon statistics interface (parameter pon-leg removed, x-pon prefix introduced to identify the XGS-PON interface under MPM mode)
configure trouble-shooting pon statistics threshold interface (parameter pon-leg removed, x-pon prefix introduced to identify the XGS-PON interface under MPM mode)
configure voice ont pots (parameters transmit-path nominal-feed-vol not supported yet)
configure voice sip isdn-cas-term (update for NIAT-A: number screening and number mapping)
show alarm query ellid (parameter pon-leg removed, x-pon prefix introduced to identify the XGS-PON interface under MPM mode)
show alarm query epon (parameter pon-leg removed, x-pon prefix introduced to identify the XGS-PON interface under MPM mode)
show alarm query olt-gen (parameter pon-leg removed, x-pon prefix introduced to identify the XGS-PON interface under MPM mode)
show alarm query olt-pon-tc-tca (parameter pon-leg removed, x-pon prefix introduced to identify the XGS-PON interface under MPM mode)
show alarm query olt-pon-util-tca (parameter pon-leg removed, x-pon prefix introduced to identify the XGS-PON interface under MPM mode)
show alarm query ont-iphost (parameter ont-ip-host-file not supported yet)
show alarm query otdr (parameter pon-leg removed, x-pon prefix introduced to identify the XGS-PON interface under MPM mode)

interface under MPM mode)
show equipment diagnostics sfp (introduction of SFP1, SFP2, XFP1, XFP2 prefixes, for clean support of multi-channel PON optics)
show equipment diagnostics sfp-threshold (introduction of SFP1, SFP2, XFP1, XFP2 prefixes, for clean support of multi-channel PON optics)
show equipment ont operational-data (show MAC learning depth and last restart reason)
show equipment ont pm (command not supported yet)
show equipment ont pm ont-side (command not supported yet)
show equipment ont pm ont-side current-interval (command not supported yet)
show equipment ont pm ont-side previous-interval (command not supported yet)
show equipment transceiver-inventory (introduction of SFP1, SFP2, XFP1, XFP2 prefixes, for clean support of multi-channel PON optics)
show interface port (parameter pon-leg removed, x-pon prefix introduced to identify the XGS-PON interface under MPM mode)
show interface stack (parameter pon-leg removed, x-pon prefix introduced to identify the XGS-PON interface under MPM mode)
show interface test (parameter pon-leg removed, x-pon prefix introduced to identify the XGS-PON interface under MPM mode)
show mcast pon-active-groups (parameter pon-leg removed, x-pon prefix introduced to identify the XGS-PON interface under MPM mode)
show pon interface fec-tc-layer current-interval (parameter pon-leg removed, x-pon prefix introduced to identify the XGS-PON interface under MPM mode)
show pon interface mcast-tc-layer current-interval (parameter pon-leg removed, x-pon prefix introduced to identify the XGS-PON interface under MPM mode)
show pon interface mcast-tc-layer previous-interval (parameter pon-leg removed, x-pon prefix introduced to identify the XGS-PON interface under MPM mode)
show pon interface phy-layer current-interval (parameter pon-leg removed, x-pon prefix introduced to identify the XGS-PON interface under MPM mode)
show pon interface tc-layer current-interval (parameter pon-leg removed, x-pon prefix introduced to identify the XGS-PON interface under MPM mode)
show pon interface tc-layer previous-interval (parameter pon-leg removed, x-pon prefix introduced to identify the XGS-PON interface under MPM mode)
show pon interface xg-tc-layer current-interval (parameter pon-leg removed, x-pon prefix introduced to identify the XGS-PON interface under MPM mode)
show pon interface xg-tc-layer previous-interval (parameter pon-leg removed, x-pon prefix introduced to identify the XGS-PON interface under MPM mode)
show pon optics (parameter pon-leg removed, x-pon prefix introduced to identify the XGS-PON interface under MPM mode)
show pon pon-diagnostics (parameter pon-leg removed, x-pon prefix introduced to identify the XGS-PON interface under MPM mode)
show pon sfp-inventory (parameter pon-leg removed, x-pon prefix introduced to identify the XGS-PON interface under MPM mode)
show pon utilization cur-intvl-top-ont-rx (parameter pon-leg removed, x-pon prefix introduced to identify the XGS-PON interface under MPM mode)

show pon utilization cur-intvl-top-ont-tx (parameter pon-leg removed, x-pon prefix introduced to identify the XGS-PON interface under MPM mode)
show pon utilization current-interval (parameter pon-leg removed, x-pon prefix introduced to identify the XGS-PON interface under MPM mode)
show pon utilization previous-interval (parameter pon-leg removed, x-pon prefix introduced to identify the XGS-PON interface under MPM mode)
show pon utilization prv-intvl-top-ont-rx (parameter pon-leg removed, x-pon prefix introduced to identify the XGS-PON interface under MPM mode)
show pon utilization prv-intvl-top-ont-tx (parameter pon-leg removed, x-pon prefix introduced to identify the XGS-PON interface under MPM mode)
show qos interface-bandwidth (parameter pon-leg removed, x-pon prefix introduced to identify the XGS-PON interface under MPM mode)
show qos statistics color-queue current-15min (parameter pon-leg removed, x-pon prefix introduced to identify the XGS-PON interface under MPM mode)
show qos statistics color-queue prev-15min (parameter pon-leg removed, x-pon prefix introduced to identify the XGS-PON interface under MPM mode)
show qos statistics queue current-15min (parameter pon-leg removed, x-pon prefix introduced to identify the XGS-PON interface under MPM mode)
show qos statistics queue prev-15min (parameter pon-leg removed, x-pon prefix introduced to identify the XGS-PON interface under MPM mode)
show trouble-shooting pon statistics interface (parameter pon-leg removed, x-pon prefix introduced to identify the XGS-PON interface under MPM mode)

New Commands

admin channel-pair reboot-all-ont (force an OLT-triggered reboot of 10G PON ONUs, individual or bulk, via standard PLOAM)
admin equipment ont sernum (force an OLT-triggered reboot of 10G PON ONUs, individual or bulk, via standard PLOAM)
admin pon reboot-all-ont (force an OLT-triggered reboot of 10G PON ONUs, individual or bulk, via standard PLOAM)
admin software-mngt iacm (PERSLOSS escalation evolution for VULA Uplinks to restore AMS connection)
admin software-mngt iacm database (PERSLOSS escalation evolution for VULA Uplinks to restore AMS connection)
admin software-mngt iacm database oam-save-protected (PERSLOSS escalation evolution for VULA Uplinks to restore AMS connection)
configure system security hash-control (encrypt password with same key across systems)
show mcast chpair-active-groups (show Multicast Channel Pair Active Groups Status)
show software-mngt oam-save-protected (PERSLOSS escalation evolution for VULA Uplinks to restore AMS connection)

Commands or commands with parameters for future use, not supported yet

admin ethernet port (command not supported yet)
configure bridge port (parameter value filtervlanandpbit not supported yet)
configure equipment replan (command not supported yet)

configure ethernet ont l2 pm-collect-ext (command not supported yet)
configure l2uni ont performance-monitor pm-collect-ext (command not supported yet)
configure veip ont l2 pm-ext (command not supported yet)
show ethernet ont loopback-info (command not supported yet)
show l2uni ont mcast-subscriber (command not supported yet)
show l2uni ont mcast-subscriber active-groups (command not supported yet)
show l2uni ont mcast-subscriber general (command not supported yet)
show l2uni ont performance-data-ext (command not supported yet)
show l2uni ont performance-data-ext current-interval (command not supported yet)
show l2uni ont performance-data-ext previous-interval (command not supported yet)

Command delta R6.1.01 versus R6.1

Modified Commands
configure alarm entry (support FPM depletion, vect-no-gain-at-initialarm and board-reset-prot)
configure alarm filter filterid (support FPM depletion, vect-no-gain-at-initialarm and board-reset-prot)
configure equipment shelf (configure shelf to work in gpon-managed-ngpon mode)
configure ethernet line mau (support electrical 100Mbps auto-negotiation capability)
configure system (FELT-B Uplink: SyncE with SSM_QL support and IEEE 1588 ToD TC)
configure system security (updated source-address parameter)
configure system sync-if-timing ptp link-port-compensation (FELT-B Uplink: SyncE with SSM_QL support and IEEE 1588 ToD TC)
configure system sync-if-timing sync (FELT-B Uplink: SyncE with SSM_QL support and IEEE 1588 ToD TC)
configure system syslog (Syslog RFC5424 support, new parameters version and time-format)
show alarm query ihub-l2forward (improved alarm logging on FANT-H)
show alarm query name (support FPM depletion alarm)
show alarm query plug-in-unit (enable board-reset-protection alarm)
show alarm query sync (FELT-B Uplink: SyncE with SSM_QL support and IEEE 1588 ToD TC)
show alarm query vect-board (support new alarm vect-no-gain-at-init)
show system syslog-file (Syslog RFC5424 support)
show voice sip isdn-cas-itf (updated display parameters)
show xdsl operational-data far-end line (new reporting of VDSL2 FDPS support by XTU-R)
New Commands
admin software-mngt ls-migration (command to support migration to Lightspan)
admin software-mngt ls-migration download server-ip (command to support migration to Lightspan)
configure mcast ipv6-chn (support a subset of IPv6 MLDv1/v2 proxying for IPv6 multicast services: UNI, Service Context and Fast Leave)

configure mcast ipv6-chn src-ipv6-addr (support a subset of IPv6 MLDv1/v2 proxying for IPv6 multicast services: UNI, Service Context and Fast Leave)
configure mcast-control (support a subset of IPv6 MLDv1/v2 proxying for IPv6 multicast services: UNI, Service Context and Fast Leave)
configure mcast-control channel (support a subset of IPv6 MLDv1/v2 proxying for IPv6 multicast services: UNI, Service Context and Fast Leave)
configure mcast-control channel fullview-packages (support a subset of IPv6 MLDv1/v2 proxying for IPv6 multicast services: UNI, Service Context and Fast Leave)
configure mcast-control channel preview-packages (support a subset of IPv6 MLDv1/v2 proxying for IPv6 multicast services: UNI, Service Context and Fast Leave)
configure mcast-control ipv4 (support a subset of IPv6 MLDv1/v2 proxying for IPv6 multicast services: UNI, Service Context and Fast Leave)
configure mcast-control ipv4 vlan (support a subset of IPv6 MLDv1/v2 proxying for IPv6 multicast services: UNI, Service Context and Fast Leave)
configure mcast-control ipv6 (support a subset of IPv6 MLDv1/v2 proxying for IPv6 multicast services: UNI, Service Context and Fast Leave)
configure mcast-control ipv6 vlan (support a subset of IPv6 MLDv1/v2 proxying for IPv6 multicast services: UNI, Service Context and Fast Leave)
configure mcast-control mc-vlan-xlate (support a subset of IPv6 MLDv1/v2 proxying for IPv6 multicast services: UNI, Service Context and Fast Leave)
configure mcast-control mcast-svc-context (support a subset of IPv6 MLDv1/v2 proxying for IPv6 multicast services: UNI, Service Context and Fast Leave)
configure mcast-control package (support a subset of IPv6 MLDv1/v2 proxying for IPv6 multicast services: UNI, Service Context and Fast Leave)
configure mcast-control system (support a subset of IPv6 MLDv1/v2 proxying for IPv6 multicast services: UNI, Service Context and Fast Leave)
configure mcast-control system cdr-type (support a subset of IPv6 MLDv1/v2 proxying for IPv6 multicast services: UNI, Service Context and Fast Leave)
configure system sync-if-timing bits-bind (FELT-B Uplink: SyncE with SSM_QL support and IEEE 1588 ToD TC)
configure system sync-if-timing ptp l2-ptp-port (FELT-B Uplink: SyncE with SSM_QL support and IEEE 1588 ToD TC)
configure voice sip cas-nsm-prof (NIAT-A: support number screening and number mapping CAS R2-SIP)
show mcast ipv6-active-groups (support a subset of IPv6 MLDv1/v2 proxying for IPv6 multicast services: UNI, Service Context and Fast Leave)
show mcast-control (support a subset of IPv6 MLDv1/v2 proxying for IPv6 multicast services: UNI, Service Context and Fast Leave)
show mcast-control channel (support a subset of IPv6 MLDv1/v2 proxying for IPv6 multicast services: UNI, Service Context and Fast Leave)
show mcast-control channel counter (support a subset of IPv6 MLDv1/v2 proxying for IPv6 multicast services: UNI, Service Context and Fast Leave)
show mcast-control channel miscellaneous (support a subset of IPv6 MLDv1/v2 proxying for IPv6 multicast services: UNI, Service Context and Fast Leave)
show mcast-control channel protocol (support a subset of IPv6 MLDv1/v2 proxying for IPv6 multicast services: UNI, Service Context and Fast Leave)

show mcast-control ipv4 (support a subset of IPv6 MLDv1/v2 proxying for IPv6 multicast services: UNI, Service Context and Fast Leave)
show mcast-control ipv4 grp-to-package (support a subset of IPv6 MLDv1/v2 proxying for IPv6 multicast services: UNI, Service Context and Fast Leave)
show mcast-control ipv4 module-mcast-channel (support a subset of IPv6 MLDv1/v2 proxying for IPv6 multicast services: UNI, Service Context and Fast Leave)
show mcast-control ipv4 package-to-src (support a subset of IPv6 MLDv1/v2 proxying for IPv6 multicast services: UNI, Service Context and Fast Leave)
show mcast-control mcast-svc-context (support a subset of IPv6 MLDv1/v2 proxying for IPv6 multicast services: UNI, Service Context and Fast Leave)
show mcast-control module (support a subset of IPv6 MLDv1/v2 proxying for IPv6 multicast services: UNI, Service Context and Fast Leave)
show mcast-control module counter (support a subset of IPv6 MLDv1/v2 proxying for IPv6 multicast services: UNI, Service Context and Fast Leave)
show mcast-control module miscellaneous (support a subset of IPv6 MLDv1/v2 proxying for IPv6 multicast services: UNI, Service Context and Fast Leave)
show mcast-control module time (support a subset of IPv6 MLDv1/v2 proxying for IPv6 multicast services: UNI, Service Context and Fast Leave)
show mcast-control system (support a subset of IPv6 MLDv1/v2 proxying for IPv6 multicast services: UNI, Service Context and Fast Leave)
show software-mngt ls-migration (command to support migration to Lightspan)
show voice sip cas-nsm-prof (NIAT-A: support number screening and number mapping CAS R2-SIP)
show voice sip e1itf-bchannel-status (ISDN-CAS: reporting of B channel status and oos reporting)

Commands or commands with parameters for future use, not supported yet

admin ethernet statistics (new parameter value lt-link not supported yet)
admin interface trouble-shooting ethernet statistics (new parameter value lt-link not supported yet)
configure equipment slot (parameter operational-mode not supported yet)
configure interface cage (cage mode not supported yet)
configure qos interface (new parameter value lbackpl-link not supported yet)
configure qos tca queue (new parameter value lbackpl-link not supported yet)
show ethernet etherstats (new parameter value lt-link not supported yet)
show interface trouble-shooting ethernet statistics (new parameter value lt-link not supported yet)
show qos interface-bandwidth (new parameter value lbackpl-link not supported yet)
show qos statistics color-queue current-15min (new parameter value lbackpl-link not supported yet)
show qos statistics color-queue prev-15min (new parameter value lbackpl-link not supported yet)
show qos statistics queue current-15min (new parameter value lbackpl-link not supported yet)
show qos statistics queue prev-15min (new parameter value lbackpl-link not supported yet)

Command delta R6.1 versus R6.0.01

Modified Commands
configure alarm entry (support lag degrade alarm)
configure alarm filter filterid (updated alarm list)
configure bridge port (FELT-B: Port mirroring improvement)
configure bridge port vlan-id (FGLT-B/NGPON2 LT: Advanced QoS remarking rules for S+C forwarders)
configure debug-trace protocol-trace (enhanced syslog messages)
configure ethernet line mau (support UTP 10G full duplex on RANT-C)
configure qos profiles session (support parameter ds-schedule-tag to support traffic classification according to the inner VLAN QoS per bridge port)
configure system max-lt-link-speed (adding 25G and 50G option in max-lt-link-speed)
configure system max-lt-link-speed (support FANT-H: parameter value one-hunderd-gb supported)
configure system port-group (support QSFP ports)
configure system security cdr-pm-file upload (update PM file upload configuration)
configure system security filetransfer server (RSA public/private-key support)
configure system security filetransfer serverv6 (RSA public/private-key support)
configure system security pmfile upload (update PM file upload configuration)
configure system security snmp user (support for secure hash algorithms)
configure system security ssh server-profile (support ECDH Key exchange algorithm)
configure system security ssh sftp-user (RSA public/private-key support)
configure system syslog destination (local syslog persistent during power cycle)
configure system syslog route (enhanced syslog messages)
configure voice lsa-server emergency-service dn (remove duplicate nt parameter value)
configure voice lsa-server instance (remove duplicate nt parameter value)
configure voice lsa-server system (remove duplicate nt parameter value)
configure voice sip isdn-cas-term (NIAT-A: number screening and number mapping DSS1-SIP)
configure voice sip user-agent-ap slot-id (remove duplicate nt parameter value)
configure xdsl vp-board (range increase of resource parameter vp-link to support up to 16 VP-LT links per VP-card)
show alarm current vect-board (range increase of display parameter vp-link-index to support up to 16 VP-LT links per VP-card)
show alarm log vect-board (range increase of display parameter vp-link-index to support up to 16 VP-LT links per VP-card)
show alarm query ihub-link (support QSFP ports)
show alarm query ihub-tca ()
show alarm query link-agg (support lag degrade alarm)
show alarm query name (support lag degrade alarm)
show alarm snap-shot (range increase of display parameter vp-link-index to support up to 16 VP-LT links per VP-card)
show qsfp-port-mode (support QSFP ports)

show security cdr-pm-file upload (update PM file upload configuration)
show system license (adding 25gbps and 50gbps option)
show system license (support FANT-H: parameter 100gbps-lt supported)
show voice sip redundancy-node ext-redundancy-state (remove duplicate nt parameter value)
show voice sip redundancy-node redundancy-state (remove duplicate nt parameter value)
show voice sip user-agent-ap (remove duplicate nt parameter value)
show xdsl vect-carrier-data far-end (range increase of display and command parameter vgr-link to support up to 16 VP-LT links per VP-card)
show xdsl vect-carrier-data near-end (range increase of display and command parameter vgr-link to support up to 16 VP-LT links per VP-card)
show xdsl vect-group (range increase of resource parameter vgr-link to support up to 16 VP-LT links per VP-card)
show xdsl vp-board (range increase of resource parameter vp-link to support up to 16 VP-LT links per VP-card)

New Commands

admin system security ssh generate-auth-key (RSA public/private-key support)
configure system nt-sftp (SFTP server for ZTP on NT)
configure system nt-sftp user-name (SFTP server for ZTP on NT)
configure voice sip isdn-nsm-prof (NIAT-A: number screening and number mapping DSS1-SIP)
show security ssh auth-key (RSA public/private-key support)
show security ssh auth-key-status (RSA public/private-key support)
show voice sip isdn-nsm-prof (NIAT-A: number screening and number mapping DSS1-SIP)
show voice sip profiles (NIAT-A: number screening and number mapping DSS1-SIP)
show voice sip ua-ip-info (get ip info values from User-agent)

Commands or commands with parameters for future use, not supported yet

configure system security mgmt-ipv4-addr (parameter mgmt-ipv4-addr not supported yet)
configure voice sip redundancy (new parameters fail-obs-timer fg-intv-503 time-thrsh-503 nbr-thrsh-503 not supported yet)
configure voice sip register (new parameter init-reg-delay not supported yet)

Command delta R6.0.01 versus R6.0

Modified Commands

admin dual-parenting (support cross-shelf Type-B protection for GPON between two ISAM FX OLTs)
admin dual-parenting protection-group switchover (support cross-shelf Type-B protection for GPON between two ISAM FX OLTs)
admin software-mngt oswp (Software Load Validation)
configure alarm entry (alarm for MELT board reset, network-power-loss and hw-fault)

configure alarm filter filterid (updated alarm list)
configure channel-group id subchannel-group id (update parameter mcatt-encrypt fot downstream multicast GEM encryption mode)
configure dual-parenting (support cross-shelf Type-B protection for GPON between two ISAM FX OLTs)
configure dual-parenting local-node (support cross-shelf Type-B protection for GPON between two ISAM FX OLTs)
configure dual-parenting peer-node (support cross-shelf Type-B protection for GPON between two ISAM FX OLTs)
configure dual-parenting protection-group (support cross-shelf Type-B protection for GPON between two ISAM FX OLTs)
configure generic-pon ont (ONT pre-provisioning using Serial Number authentication - auto unlock ONT Administrative State)
configure ipv6-antispoofing (support IPv6 anti-spoofing based on the full IPv6 address)
configure ipv6-antispoofing slot (support IPv6 anti-spoofing based on the full IPv6 address)
configure pon interface (parameter pon-leg not supported)
configure qos profiles policy-action (QoS enhancements)
configure qos profiles session (QOS enhancements)
configure software-mngt oswp (Software Load Validation)
configure system pon-ont (ONT pre-provisioning using Serial Number authentication - auto unlock ONT Administrative State)
configure system security source-address (proper selection of source-IP for FTP IPv4 and IPv6)
configure system sync-if-timing ssmout-synce (support QSFP ports)
configure system sync-if-timing synce (support QSFP ports)
configure system syslog route msg-type (Syslog improvements)
configure vlan (removed not supported parameter mac-auto-delete)
configure voice lsa-server emergency-service (support lsa server hosted at VVPS-A board)
configure voice lsa-server instance (support lsa server hosted at VVPS-A board)
configure voice lsa-server system (support lsa server hosted at VVPS-A board)
configure voice sip isdn-cas-term (support crc4 configuration for isdn-cas-term)
configure voice sip server (support SIP over TLS)
configure voice sip transport (support SIP over TLS)
configure voice sip vsp (support SIP over TLS)
configure xdsl rtx-profile (increase bonded group and RTX profiles)
configure xdsl spectrum-profile vdsl2 (support VDSL Long Range)
configure xdsl-bonding board vect-fallback (increase bonded group and RTX profiles)
configure xdsl-bonding group (increase bonded group and RTX profiles)
configure xdsl-bonding group-rtx-profile (increase bonded group and RTX profiles)
match (update match CLI filter decription)
show alarm query eqpt-holder-ext (support new alarms network-power-loss and hw-fault)

show alarm query ihub-link (improved alarm reporting QSFP)
show alarm query ihub-tca (improved alarm reporting QSFP)
show alarm query name (updated alarm list)
show alarm query plug-in-unit-ext (alarm for MELT board reset)
show dual-parenting (support cross-shelf Type-B protection for GPON between two ISAM FX OLTs)
show dual-parenting protection-group (support cross-shelf Type-B protection for GPON between two ISAM FX OLTs)
show system license (support VDSL Long Range)

New Commands

admin igmp debug version (IGMP Join/leave Debug Management)
admin software-mngt tls-cafile (support SIP over TLS)
admin system security manager release-lock-cli (login security control enhancements)
configure qos dn-ctrl-pkt (QoS enhancements)
configure qos profiles dscp-tc (QoS enhancements, support to add or delete dscp to tc profile)
configure qos profiles dscp-tc codepoint (QoS enhancements)
configure qos up-ctrl-pkt (QoS enhancements)
configure system security slot debug-usb (FANT-G Micro USB Ability to enable and disable through CLI)
show software-mngt sw-load-valid (Software Load Validation)
show software-mngt sw-load-valid file-status (Software Load Validation)
show software-mngt sw-load-valid oswp-root-certificate (Software Load Validation)
show software-mngt sw-load-valid oswp-status (Software Load Validation)
show software-mngt tls-cafile (support SIP over TLS)
tcpdump (TCPDump tool for FANT-G)
tcpdump show (TCPDump tool for FANT-G)
tcpdump start vlan (TCPDump tool for FANT-G)
tcpdump stop (TCPDump tool for FANT-G)

Removed Commands

admin bridge unicast-mac-address port (not supported command removed)
configure bridge port vlan-id eligible-to-learn (not supported command removed)

Commands or commands with parameters for future use, not supported yet

admin pon ber-stats (parameter pon-leg not supported)
admin pon clear-alarm (parameter pon-leg not supported)
admin pon diagnostic (parameter pon-leg not supported)
admin pon utilization (parameter pon-leg not supported)
admin trouble-shooting pon interface (parameter pon-leg not supported)

configure channel-pair interface (parameter onu-prov-mode not supported yet)
configure equipment ont interface (parameter template-name not supported yet)
configure equipment ont slot (parameter eth_adaptive not supported yet)
configure interface port (parameter pon-leg not supported)
configure pon interface (parameter pon-leg not supported)
configure qos interface (parameter pon-leg not supported)
configure qos tca queue (parameter pon-leg not supported)
configure system port-group (port-group not supported yet)
configure trap definition (parameter ont-prov-template not supported yet)
configure trap manager (parameter ont-prov-template not supported yet)
configure trap v6manager (parameter ont-prov-template not supported yet)
configure trouble-shooting pon statistics interface (parameter pon-leg not supported)
configure trouble-shooting pon statistics threshold interface (parameter pon-leg not supported)
show alarm query ellid (parameter pon-leg not supported)
show alarm query epon (parameter pon-leg not supported)
show alarm query olt-gen (parameter pon-leg not supported)
show alarm query olt-pon-tc-tca (parameter pon-leg not supported)
show alarm query olt-pon-util-tca (parameter pon-leg not supported)
show alarm query otdr (parameter pon-leg not supported)
show equipment shelf (display of customer serial not supported yet)
show equipment slot (display of customer serial not supported yet)
show interface port (parameter pon-leg not supported)
show interface stack (parameter pon-leg not supported)
show interface test (parameter pon-leg not supported)
show mcast pon-active-groups (parameter pon-leg not supported)
show pon interface fec-tc-layer current-interval (parameter pon-leg not supported)
show pon interface mcast-tc-layer current-interval (parameter pon-leg not supported)
show pon interface mcast-tc-layer previous-interval (parameter pon-leg not supported)
show pon interface phy-layer current-interval (parameter pon-leg not supported)
show pon interface tc-layer current-interval (parameter pon-leg not supported)
show pon interface tc-layer previous-interval (parameter pon-leg not supported)
show pon interface xg-tc-layer current-interval (parameter pon-leg not supported)
show pon interface xg-tc-layer previous-interval (parameter pon-leg not supported)
show pon optics (parameter pon-leg not supported)
show pon pon-diagnostics (parameter pon-leg not supported)
show pon sfp-inventory (parameter pon-leg not supported)
show pon utilization cur-intvl-top-ont-rx (parameter pon-leg not supported)

show pon utilization cur-intvl-top-ont-tx (parameter pon-leg not supported)
show pon utilization current-interval (parameter pon-leg not supported)
show pon utilization previous-interval (parameter pon-leg not supported)
show pon utilization prv-intvl-top-ont-rx (parameter pon-leg not supported)
show pon utilization prv-intvl-top-ont-tx (parameter pon-leg not supported)
show qos interface-bandwidth (parameter pon-leg not supported)
show qos statistics color-queue current-15min (parameter pon-leg not supported)
show qos statistics color-queue prev-15min (parameter pon-leg not supported)
show qos statistics queue current-15min (parameter pon-leg not supported)
show qos statistics queue prev-15min (parameter pon-leg not supported)
show qsfp-port-mode (qsfp-port-mode not supported yet)
show trouble-shooting pon statistics interface (parameter pon-leg not supported)

Command delta R6.0 versus R5.8.01

Modified Commands
admin equipment slot (NVPS-C: support Multi-core NT card (FANT-F and NANT-E) as server board, add virtual LT board index)
admin system techsupport (techsupport feature supported on 7302 ISAM FD)
admin xdsl-line (Auto-switching improvement)
configure alarm entry (alarms for Auto-switching improvement, PON integrity, line reinitialization TCA, Cross-LT LAG extension)
configure alarm filter filterid (updated alarm list)
configure bridge port vlan-id (UNI Support in FELT-B)
configure cfm domain association mep y1731ais (FELT-B downlink port: Link Loss Forwarding, auto shut down bridge port on MEP)
configure channel-group id (Channel Profiles, Burst Profiles and System Profile PLOAM compliance on NG-PON2 OLT)
configure equipment protection-element (NVPS-C: support Multi-core NT card (FANT-F and NANT-E) as server board, add virtual LT board index)
configure equipment slot (NVPS-C: support Multi-core NT card (FANT-F and NANT-E) as server board, add virtual LT board index)
configure linetest cluster (NVPS-C: support Multi-core NT card (FANT-F and NANT-E) as server board, updated xvps cluster range)
configure link-agg group (FELT-B redundancy 8+8, configures switchover in a cross-LT LAG)
configure mcast capacity (UNI Support in FELT-B)
configure system security operator (prompt with Warning and request for confirmation before command execution)
configure system security snmp community (NVPS-C: support Multi-core NT card (FANT-F and NANT-E) as server board, add vvpsa context)
configure system security snmp group security-level (NVPS-C: support Multi-core NT card (FANT-F and

NANT-E) as server board, add vvpsa context)
configure system security snmp manager (NVPS-C: support Multi-core NT card (FANT-F and NANT-E) as server board, add vvpsa context)
configure vlan (allow the operator to control automatic clearing of MAC entries)
configure vlan id (updated DHCPv6 behavior)
configure voice cluster (NVPS-C: support Multi-core NT card (FANT-F and NANT-E) as server board, updated xvps cluster range)
configure voice ont mgc-config (update for OMCI Spec for XGS PON ONTs)
configure voice sip isdn-cas-term (support line Hunting over multiple E1 PRI links on NIAT)
configure voice sip isdn-cas-term (updated parameter names for TermHuntingWay)
configure voice sip server (implement UDPswTCP and udp_tcp cross check function)
configure voice sip transport (implement UDPswTCP and udp_tcp cross check function)
configure xdsl board (support to configure the allowed vectoring class)
configure xdsl line tca-line-threshold (support of G.fast/VDSL line reinitialization TCA)
debug-command current-cpu-core-load (NVPS-C: support Multi-core NT card (FANT-F and NANT-E) as server board, add virtual LT board index)
debug-command current-cpu-load (NVPS-C: support Multi-core NT card (FANT-F and NANT-E) as server board, add virtual LT board index)
debug-command error-info (NVPS-C: support Multi-core NT card (FANT-F and NANT-E) as server board, add virtual LT board index)
debug-command temperature (NVPS-C: support Multi-core NT card (FANT-F and NANT-E) as server board, add virtual LT board index)
environment (environment setting to set number of lines displayed)
show alarm query auto-switch (alarms for Auto-switching improvement)
show alarm query channel-pair (PON Data Path Integrity alarm)
show alarm query custom-ext-alarm (NVPS-C: support Multi-core NT card (FANT-F and NANT-E) as server board, add virtual LT board index)
show alarm query ellid (removed not supported parameter values epon eont ellid euni, new value pon:leg not supported yet)
show alarm query epon (removed not supported parameter values epon eont ellid euni, new value pon:leg not supported yet)
show alarm query ihub-link (detailed alarm when AI link is down)
show alarm query ihub-tca (detailed alarm when AI link is down)
show alarm query megaco-media-gw (NVPS-C: support Multi-core NT card (FANT-F and NANT-E) as server board, add virtual LT board index)
show alarm query name (updated alarm list)
show alarm query ont (enabled alarm ont-gen-tod-mismatch)
show alarm query otdr (removed not supported parameter values epon eont ellid euni, new value pon:leg not supported yet)
show alarm query plug-in-unit (NVPS-C: support Multi-core NT card (FANT-F and NANT-E) as server board, add virtual LT board index)
show alarm query plug-in-unit-ext (NVPS-C: support Multi-core NT card (FANT-F and NANT-E) as

server board, add virtual LT board index)
show alarm query sfpe1t1-clock (NVPS-C: support Multi-core NT card (FANT-F and NANT-E) as server board, add virtual LT board index)
show alarm query sfpe1t1-framer (NVPS-C: support Multi-core NT card (FANT-F and NANT-E) as server board, add virtual LT board index)
show alarm query sfprssi (NVPS-C: support Multi-core NT card (FANT-F and NANT-E) as server board, add virtual LT board index)
show alarm query sip-plugin-unit (NVPS-C: support Multi-core NT card (FANT-F and NANT-E) as server board, add virtual LT board index)
show alarm query sip-user-agent (NVPS-C: support Multi-core NT card (FANT-F and NANT-E) as server board, add virtual LT board index)
show alarm query sw-mgmt (NVPS-C: support Multi-core NT card (FANT-F and NANT-E) as server board, add virtual LT board index)
show alarm query traffic-overflow (NVPS-C: support Multi-core NT card (FANT-F and NANT-E) as server board, add virtual LT board index)
show alarm query xdsl-tca (support of G.fast/VDSL line reinitialization TCA)
show equipment protection-element (NVPS-C: support Multi-core NT card (FANT-F and NANT-E) as server board, add virtual LT board index)
show equipment slot (NVPS-C: support Multi-core NT card (FANT-F and NANT-E) as server board, add virtual LT board index)
show interface port (removed not supported parameter values epon eont ellid euni, new value pon:leg mpm not supported yet)
show interface stack (removed not supported parameter values epon eont ellid euni, new value pon:leg not supported yet)
show interface test (removed not supported parameter values epon eont ellid euni, new value pon:leg not supported yet)
show link-aggr port-info (FELT-B redundancy 8+8, shows switchover in a cross-LT LAG)
show system techsupport (techsupport feature supported on 7302 ISAM FD)
show voice cluster (NVPS-C: support Multi-core NT card (FANT-F and NANT-E) as server board, updated xvps cluster range)

New Commands

admin bridge unicast-mac-address port (delete all MACs learned on bridge port from the filtering database)
configure alarm suppression filterid (configurable suppression for BDINIT/BDMISSING Alarms)
configure bridge port vlan-id eligible-to-learn (802.1x Mac Based Authentication additional requirements support)
configure bridge port vlan-id eligible-to-learn unicast-mac (802.1x Mac Based Authentication additional requirements support)
configure equipment ont interface cpu-load (performance KPI support)
configure equipment ont interface memory-usage (performance KPI support)
configure generic-pon alarmflag (enable to re-define the PONLOS for broken trunk fiber)
configure generic-pon dpinteg-threshold (PON Data Path Integrity alarm threshold)
configure interface statistics (support Sliding-Window Traffic Statistics)

configure tc-layer (GEM port network CTP performance monitoring history data)
configure tc-layer ont-side (GEM port network CTP performance monitoring history data)
configure voice sip isdn-cas-cls-puid (support line Hunting over multiple E1 PRI links on NIAT)
show alarm current link-agg (alarms for Cross-LT LAG extension)
show alarm log link-agg (alarms for Cross-LT LAG extension)
show alarm query link-agg (alarms for Cross-LT LAG extension)
show alarm snap-shot link-agg (alarms for Cross-LT LAG extension)
show alarm snap-shot olt-gen (enable olt-gen alarm display)
show equipment ont cpu-load (performance KPI support)
show equipment ont cpu-load current-interval (performance KPI support)
show equipment ont cpu-load previous-interval (performance KPI support)
show equipment ont memory-usage (performance KPI support)
show equipment ont memory-usage current-interval (performance KPI support)
show equipment ont memory-usage previous-interval (performance KPI support)
show interface statistics (support Sliding-Window Traffic Statistics)
show tc-layer (GEM port network CTP performance monitoring history data)
show tc-layer ont-side (GEM port network CTP performance monitoring history data)
show tc-layer ont-side current-interval (GEM port network CTP performance monitoring history data)
show tc-layer ont-side previous-interval (GEM port network CTP performance monitoring history data)
show voice sip isdn-cas-cls-puid (support line Hunting over multiple E1 PRI links on NIAT)
show voice sip isdn-cas-itf (support line Hunting over multiple E1 PRI links on NIAT)

Commands or commands with parameters for future use, not supported yet

admin dual-parenting (Cross-shelf Type-B protection for GPON between two ISAM FX OLTs)
admin dual-parenting protection-group switchover (Cross-shelf Type-B protection for GPON between two ISAM FX OLTs)
admin pon ber-stats (legacy parameter value leg not supported yet)
admin pon clear-alarm (legacy parameter value leg not supported yet)
admin pon diagnostic (legacy parameter value leg not supported yet)
admin pon utilization (legacy parameter value leg not supported yet)
admin software-mngt trigger-reborn (trigger reborn reformation)
admin trouble-shooting pon interface (legacy parameter value leg not supported yet)
configure dual-parenting (Cross-shelf Type-B protection for GPON between two ISAM FX OLTs)
configure dual-parenting local-node (Cross-shelf Type-B protection for GPON between two ISAM FX OLTs)
configure dual-parenting peer-node (Cross-shelf Type-B protection for GPON between two ISAM FX OLTs)
configure dual-parenting protection-group (Cross-shelf Type-B protection for GPON between two ISAM FX OLTs)

configure equipment ont interface (parameter value 1.25g not supported yet)
configure interface port (legacy parameter value leg not supported yet)
configure ipv6-antispoofing (IPv6 anti-spoofing based on the full IPv6 address)
configure ipv6-antispoofing slot (IPv6 anti-spoofing based on the full IPv6 address)
configure pon interface (legacy parameter value leg not supported yet)
configure qos interface (legacy parameter value leg not supported yet)
configure qos tca queue (legacy parameter value leg not supported yet)
configure system max-lt-link-speed (new parameter value one-hundred-gb not supported yet)
configure system sync-if-timing ptp (new parameter profile not supported yet)
configure trouble-shooting pon statistics interface (legacy parameter value leg not supported yet)
configure trouble-shooting pon statistics threshold interface (legacy parameter value leg not supported yet)
show alarm query olt-gen (legacy parameter value leg not supported yet)
show alarm query olt-pon-tc-tca (legacy parameter value leg not supported yet)
show alarm query olt-pon-util-tca (legacy parameter value leg not supported yet)
show dual-parenting (Cross-shelf Type-B protection for GPON between two ISAM FX OLTs)
show dual-parenting protection-group (Cross-shelf Type-B protection for GPON between two ISAM FX OLTs)
show mcast pon-active-groups (legacy parameter value leg not supported yet)
show pon interface fec-tc-layer current-interval (legacy parameter value leg not supported yet)
show pon interface mcast-tc-layer current-interval (legacy parameter value leg not supported yet)
show pon interface mcast-tc-layer previous-interval (legacy parameter value leg not supported yet)
show pon interface phy-layer current-interval (legacy parameter value leg not supported yet)
show pon interface tc-layer current-interval (legacy parameter value leg not supported yet)
show pon interface tc-layer previous-interval (legacy parameter value leg not supported yet)
show pon interface xg-tc-layer current-interval (legacy parameter value leg not supported yet)
show pon interface xg-tc-layer previous-interval (legacy parameter value leg not supported yet)
show pon optics (legacy parameter value leg not supported yet)
show pon pon-diagnostics (legacy parameter value leg not supported yet)
show pon sfp-inventory (legacy parameter value leg not supported yet)
show pon utilization cur-intvl-top-ont-rx (legacy parameter value leg not supported yet)
show pon utilization cur-intvl-top-ont-tx (legacy parameter value leg not supported yet)
show pon utilization current-interval (legacy parameter value leg not supported yet)
show pon utilization previous-interval (legacy parameter value leg not supported yet)
show pon utilization prv-intvl-top-ont-rx (legacy parameter value leg not supported yet)
show pon utilization prv-intvl-top-ont-tx (legacy parameter value leg not supported yet)
show qos interface-bandwidth (legacy parameter value leg not supported yet)
show qos statistics color-queue current-15min (legacy parameter value leg not supported yet)

show qos statistics color-queue prev-15min (legacy parameter value leg not supported yet)
show qos statistics queue current-15min (legacy parameter value leg not supported yet)
show qos statistics queue prev-15min (legacy parameter value leg not supported yet)
show system license (new parameter value 100gbps-lt not supported yet)
show trouble-shooting pon statistics interface (legacy parameter value leg not supported yet)

Command delta R5.8.01 versus R5.8

Modified Commands
admin system techsupport (default changed from disable to enable)
configure alarm entry (alarm raised at various degrees of flash card degradation or failure, new alarms packet-loss remote-packet-loss no-dsp-resource for SIP PRI: Enhancements (Nx64) pseudo-wire)
configure alarm filter filterid (updated alarm list)
configure channel-group id subchannel-group id (support multiple Subchannel Groups (channel partitions) per Channel Group on NG-PON2 [OLT part])
configure channel-pair interface (U-NGPON throughput improvements and testing with XGS Dual Rate N1 and N2 OLT optics)
configure pon interface (updated range for parameter tconts-per-frame)
configure qos profiles bandwidth (update DBRu parameter setting)
configure system security snmp community (DPoE and DOCSIS related parameters removed)
configure system security snmp group (DPoE and DOCSIS related parameters removed)
configure system sync-if-timing ptp default-dataset (obsolete parameter clock-identity removed)
configure system sync-if-timing ssmout-ltport (support SSM QL over 10G PON card with XGS-PON mode)
configure system syslog route msg-type (dump Syslog file support)
configure voice lsa-server emergency-service (support the standalone SIP emergency call support for PRI access)
configure voice sip isdn-cas-term (support SIP User Authentication on AKA-MD5 per RFC 3310, CAS/R2 enhancements)
configure voice sip manipulate-rule (ISAMV SIP: CAS/R2 enhancements)
configure voice sip redundancy (NIAT ISDN PRI redundancy, to enable/disable forced failover timer function, auto-srv-fo-tmr renamed to auto-srv-fo-timer)
configure voice sip termination (support SIP User Authentication on AKA-MD5 per RFC 3310)
show alarm query eqpt-supplemental (alarm raised at various degrees of flash card degradation or failure)
show alarm query ihub-link (improved filtering via alarm type)
show alarm query ihub-tca (improved filtering via alarm type)
show alarm query name (updated alarm list)
show alarm query plug-in-unit-ext (support new alarm mgnt-type-mismatch)
show system sync-ptp-client (display improvements)

New Commands

admin equipment protection-group (support NT forced switchover on FANT-F FANT-G and NANT-E)
clear sliding-win-stats (support sliding window statistics feature for uplink ports)
configure system security snmp-slot-numbering (support LT index numbering)
configure system sliding-win-stats (support sliding window statistics feature for uplink ports)
configure voice pseudo-wire (SIP PRI: Enhancements (Nx64) pseudo-wire)
show alarm current pseudo-wire (SIP PRI: Enhancements (Nx64) pseudo-wire)
show alarm log pseudo-wire (SIP PRI: Enhancements (Nx64) pseudo-wire)
show alarm snap-shot pseudo-wire (SIP PRI: Enhancements (Nx64) pseudo-wire)
show system autoboot-config (show timestamps from autoboot.tim file)
show system cf-usage (show the status of the flash card, degradation or failure)
show system sliding-win-stats (support sliding window statistics feature for uplink ports)
show test-oam (support Two-Way Active Measurement Protocol Light (TWAMP Light) responder feature)
show voice pseudo-wire (SIP PRI: Enhancements (Nx64) pseudo-wire)
show voice pseudo-wire-src-port (SIP PRI: Enhancements (Nx64) pseudo-wire)

Commands or commands with parameters for future use, not supported yet

configure channel-pair interface deact-ont-tca (alarms on number of deactivated ONUs per PON not supported yet)
configure channel-pair interface deact-ont-tca threshold-number (alarms on number of deactivated ONUs per PON not supported yet)
configure channel-pair interface deact-ont-tca threshold-percent (alarms on number of deactivated ONUs per PON not supported yet)
configure pon interface deact-ont-tca (alarms on number of deactivated ONUs per PON not supported yet)
configure pon interface deact-ont-tca threshold-number (alarms on number of deactivated ONUs per PON not supported yet)
configure pon interface deact-ont-tca threshold-percent (alarms on number of deactivated ONUs per PON not supported yet)
configure software-mngt oswp (new parameter on-schedule-time not supported yet)
configure system (new parameter arp-tca-threshold not supported yet)
show alarm query channel-pair chpr-deact (alarms on number of deactivated ONUs per PON not supported yet)
show software-mngt oswp (new display items on-schedule-time not supported yet)

Command delta R5.8 versus R5.7.01

Modified Commands

admin software-mngt database (IPv6 Management)
admin system fips (support FIPS 140-2 CAPABLE)

admin system techsupport (default for parameter doactivate changed to enable)
configure alarm entry (cleanup unsupported alarms network-power-loss, hw-fault,ont-ploam-loss-frame, sfu-ploam-loss-frame, soho-ploam-loss-frame, mdu-ploam-loss-frame, olt-gen-pon-prot-na, olt-gen-pon-prot-act. New alarm ont-ip-host-file, tod-reference-fail. Alarms on number of deactivated ONUs per PON not supported yet.)
configure alarm filter filterid (Alarm list updated)
configure bridge port (support full TPID translation FELT-B VULA uplink)
configure bridge port vlan-id (C-VLAN p-bit marking on S-VLAN tunnel Cross-Connect)
configure bridge port vlan-id (policer instance sharing across multiple VLAN Ports on the same Bridge Port with groupid)
configure channel-group id subchannel-group id (parameter cpi and extended range for scg-id to 4 not supported yet)
configure channel-pair interface (configure TCA alarms for U-NGPON: BER period and thresholds)
configure equipment slot (modified parameter capab-profile)
configure ethernet line mau (support for 2.5GBase SFP. Note: in order to support smooth migration from 1G to 2.5 cases, it is proposed to use 1000baselxfid for newly qualified(R58) optics 3FE47061AA and AB)
configure interface alarm (support alarm interface type ds1)
configure l2uni ont performance-monitor (support 64-Bit counter via standard OMCI)
configure linetest cluster ltparm test-name (SIP: add capability to initiate via CLI/AMS (SNMP) a voice call to the destination number)
configure linetest cluster ltsession (SIP: add capability to initiate via CLI/AMS (SNMP) a voice call to the destination number)
configure linetest single ltparm test-name (SIP: add capability to initiate via CLI/AMS (SNMP) a voice call to the destination number)
configure linetest single ltsession (SIP: add capability to initiate via CLI/AMS (SNMP) a voice call to the destination number)
configure pon interface (parameter pon-speed can be used to configure the planned PON speed)
configure qos interface (improvement for Qos Interface parameter)
configure qos tca (index) queue (improvement for Qos Interface parameter)
configure software-mngt database (IPv6 Management)
configure software-mngt oswp (IPv6 Management)
configure software-mngt sw-replacement-mode (ISSU (In Service Software Upgrade) of 7360 FX, leveraging on Type-B redundancy [GPON/XGS-PON])
configure system fips (support FIPS 140-2 CAPABLE)
configure system loop-id-syntax (note: ONT and OntMAC are only limited to EPON and not usable for GPON)
configure system security default-profile (allow to create a new user with lldp-med priviledge)
configure system security profile (allow to create a new user with lldp-med priviledge)
configure system security snmp community (IPv6 Management)
configure system security snmp manager (IPv6 Management)
configure system syslog destination (IPv6 Management)

configure tr069serv ont (support VEIP on 10G OLT full parity with GPON)
configure trap definition (IPv6 Management)
configure trap manager (IPv6 Management)
configure veip ont l2 (support 64-Bit counter via standard OMCI)
configure voice sip dnserver (support Voice IPv6 Management and SIP common voice package IPv6)
configure voice sip isdn-cas-term (ISAMV NIAT: SIP CAS/R2 support)
configure voice sip manipulate-rule (digit manipulation system-level rule support and migration)
configure voice sip server (support Voice IPv6 Management and SIP common voice package IPv6)
configure voice sip termination (ISAM-V SIP: capability to enable or disable Decadic Dialing per port or line)
configure voice sip user-agent (support Voice IPv6 Management and SIP common voice package IPv6)
configure voice sip user-agent-ap slot-id (support Voice IPv6 Management and SIP common voice package IPv6)
configure voice sip vsp (support Voice IPv6 Management and SIP common voice package IPv6)
show alarm query eqpt-holder-ext (cleanup unsupported alarms network-power-loss hw-fault)
show alarm query mdm-ploam (cleanup unsupported alarm mdm-ploam-loss-frame)
show alarm query name (updated supported alarm list)
show alarm query olt-gen (cleanup unsupported alarms olt-gen-pon-prot-na olt-gen-pon-prot-act, add alarms olt-gen-sfp-mism, not supported yet: olt-gen-deact-high-tca olt-gen-deact-low-tca)
show alarm query ont-ploam (cleanup unsupported alarm ont-ploam-loss-frame)
show alarm query ont-voip (support query of ont services alarms)
show alarm query sfu-ploam (cleanup unsupported alarm sfu-ploam-loss-frame)
show alarm query sync (support new alarms holdover tod-reference-fail)
show equipment transceiver-inventory (support for 2.5GBase SFP)
show ethernet mau (support for 2.5GBase SFP)
show interface alarm (support alarm interface type ds1)
show linetest cluster lineid-ext-rept (SIP: add capability to initiate via CLI/AMS (SNMP) a voice call to the destination number)
show linetest single lineid-ext-rept (SIP: add capability to initiate via CLI/AMS (SNMP) a voice call to the destination number)
show pon unprovision-onu (add actual-us-rate to show the actual upstream rate)
show qos interface-bandwidth (improvement for Qos Interface parameter)
show qos statistics color-queue current-15min (improvement for Qos Interface parameter)
show qos statistics color-queue prev-15min (improvement for Qos Interface parameter)
show qos statistics queue current-15min (improvement for Qos Interface parameter)
show qos statistics queue prev-15min (improvement for Qos Interface parameter)
show software-mngt upgrade-plan (ISSU (In Service Software Upgrade) of 7360 FX, leveraging on Type-B redundancy [GPON/XGS-PON])
show software-mngt upgrade-status (ISSU (In Service Software Upgrade) of 7360 FX, leveraging on Type-B redundancy [GPON/XGS-PON])

show system fips (support FIPS 140-2 CAPABLE)
show system license ("add ""Local Stand Alone and Emergency call"" license")
show trap manager (IPv6 Management)
show voice sip isdn-cas-term (support Voice IPv6 Management and SIP common voice package IPv6)
show voice sip redundancy-node (support Voice IPv6 Management and SIP common voice package IPv6)
show voice sip server (support Voice IPv6 Management and SIP common voice package IPv6)
show voice sip termination (support Voice IPv6 Management and SIP common voice package IPv6)

New Commands

configure ai (enabling ai commands)
configure ai application (enabling ai commands)
configure ai platform (enabling ai commands)
configure ai platform virtualplatform (enabling ai commands)
configure system security cpu-protection (protocol rate limiting for DoS protection)
configure system security filetransfer serverv6 (IPv6 Management)
configure system security mgmt-ipv6-addr (IPv6 Management)
configure system sntp server-table ipv6-address (IPv6 Management)
configure trap v6manager (IPv6 Management)
show ai (enabling ai commands)
show ai application (enabling ai commands)
show ai platform (enabling ai commands)
show ai platform-application (enabling ai commands)
show alarm query ont-ani (enabling ont-ani alarm display)
show ip (IPv6 management over iHUB)
show l2uni ont performance-data-64bit (support 64-Bit counter via standard OMCI)
show l2uni ont performance-data-64bit current-interval (support 64-Bit counter via standard OMCI)
show l2uni ont performance-data-64bit previous-interval (support 64-Bit counter via standard OMCI)
show sntp server-tablev6 (IPv6 Management)
show system security cpu-protection (protocol rate limiting for DoS protection)
show system sync-ptp-client (extend clock trace info)
show system sync-ptp-currmaster (extend clock trace info)
show system sync-ptp-inmasters (extend clock trace info)
show system sync-ptp-mstrport (extend clock trace info)
show system sync-ptp-mstrprofile (extend clock trace info)
show system sync-ptp-slaveport (extend clock trace info)
show trap v6manager (IPv6 Management)

Removed Commands

admin cable (command tree removed as DPoE not supported any more)
admin cm (command tree removed as DPoE not supported any more)
admin cmts (command tree removed as DPoE not supported any more)
admin config-file (command tree removed as DPoE not supported any more)
admin interface cable (command tree removed as DPoE not supported any more)
configure cm (command tree removed as DPoE not supported any more)
configure cmts (command tree removed as DPoE not supported any more)
configure dpoe (command tree removed as DPoE not supported any more)
show cable (command tree removed as DPoE not supported any more)
show cmts (command tree removed as DPoE not supported any more)
show config-file (command tree removed as DPoE not supported any more)
show dpoe (command tree removed as DPoE not supported any more)
show gre (command tree removed as DPoE not supported any more)
show interface cable (command tree removed as DPoE not supported any more)
show interface dpoe (command tree removed as DPoE not supported any more)
show system sync-if-timing-master (replaced by show system sync-ntp-currmaster)
show system sync-if-timing-profile (replaced by show system sync-ntp-mstrprofile)
show system sync-if-timing-ntp (replaced by show system sync-ntp-slaveport)

Commands or commands with parameters for future use, not supported yet

admin equipment ont interface (parameter optitrans-disable-time not supported yet)
configure equipment ont interface delay-act (command not supported yet)
configure equipment ont interface onu-tssi-detect (command not supported yet)
configure equipment ont pm-collect (command not supported yet)
configure equipment ont sw-ctrl delay-act (command not supported yet)
configure system sync-if-timing ssmout-ltport (parameter ng2 not supported yet)
configure voice ont pots (parameters transmit-path nominal-feed-vol not supported yet)
configure voice sip redundancy (parameter auto-srv-fo-tmr not supported yet)
show alarm query channel-pair (alarm chpr-deact-hightca and chpr-deact-lowtca not supported yet)
show alarm query mdu-sup (alarm mdu-opti-malfunc not supported yet)
show alarm query ont (alarm ont-opti-malfunc not supported yet)
show alarm query ont-iphost (parameter ont-ip-host-file not supported yet)
show alarm query plug-in-unit-ext (support new alarm mgnt-type-mismatch)
show alarm query sfu-sup (alarm sfu-opti-malfunc not supported yet)
show alarm query soho-sup (alarm soho-opti-malfunc not supported yet)
show equipment ont xg-mgmt (command not supported yet)
show equipment ont xg-mgmt ont-side (command not supported yet)
show equipment ont xg-mgmt ont-side current-interval (command not supported yet)

show equipment ont xg-mgmt ont-side previous-interval (command not supported yet)

Command delta R5.7.01 versus R5.7

Modified Commands
admin cfm mclbm (command node definition updated)
admin channel-pair diagnostic (support channel-pair for alien ONU detection on XGS-PON)
admin port-protection activate (Type-B protection support on XGS-PON)
admin system techsupport gen-on-demand (corrections in the CLI interface to support nt-b)
configure alarm entry (add CAS R2 Channel alarms, support LLDP alarms and for mismatch between actual and planned upstream rate, qsf alarm)
configure alarm filter filterid (Alarm list updated)
configure equipment slot (support for 24port xDSL)
configure ethernet ont (Power over Ethernet enhancements)
configure interface port (update port parameters display)
configure linetest single ltparm test-name (update ISAM-V NIAT-A CAS R2 specification and update input parameters for R2 loopback test)
configure linetest single ltsession (update ISAM-V NIAT-A CAS R2 specification)
configure port-protection paired-port (Type-B protection support on XGS-PON)
configure trap definition (add support for SW Upgrade Finished trap)
configure voice cluster equipment termination (ISAM-V: support per line configuration of dialed digit manipulation rules and per line configurable line signal)
configure voice sip cas-r2-timer (update ISAMv NIAT-A CAS R2 specification)
configure voice sip isdn-cas-term (ISAM-V: support per line configuration of dialed digit manipulation rules)
configure voice sip manipulate-rule (ISAM-V: support per line configuration of dialed digit manipulation rules)
configure voice sip termination (ISAM-V: support per line configuration of dialed digit manipulation rules and per line configurable line signal)
show alarm current e1-sip-termination (support CAS/R2 for NIAT-A SIP ETSI)
show alarm log e1-sip-termination (support CAS/R2 for NIAT-A SIP ETSI)
show alarm query bulk-sync (Type-B protection support on XGS-PON)
show alarm query channel-pair (support channel-pair for alien ONU detection on XGS-PON)
show alarm query mdu-gen (add alarm for mismatch between actual and planned upstream rate)
show alarm query mdu-sup (update alarm list, Power over Ethernet enhancements alarm mdu-sup-poe-over-yell supported)
show alarm query name (alarm list updated)
show alarm query ont (Power over Ethernet enhancements alarm ont-poe-overload-yell supported)
show alarm query ont-gen (add alarm for mismatch between actual and planned upstream rate)
show alarm query protection-group (Type-B protection support on XGS-PON)

show alarm query sfu-gen (add alarm for mismatch between actual and planned upstream rate)

show alarm query sfu-sup (updated alarm list, Power over Ethernet enhancements alarm sfu-sup-poe-over-yell supported)

show alarm query soho-sup (updated alarm list, Power over Ethernet enhancements alarm soho-sup-poe-over-yell supported)

show alarm snap-shot e1-sip-termination (support CAS/R2 for NIAT-A SIP ETSI)

show channel-pair diagnostic (support channel-pair for alien ONU detection on XGS-PON)

show equipment capab-profile (support for 24port xDSL)

show equipment transceiver-inventory (support new longer reach bidirectional optics)

show ethernet ont operational-data (Power over Ethernet enhancements)

show linetest single lineid-ext-rept (update ISAM-V NIAT-A CAS R2 specification and update input parameters for R2 loopback test)

show port-protection (Type-B protection support on XGS-PON)

New Commands

admin cfm mclbm domain lbm-tlv-type (add McLbm TlvType parameter for user to configure the mclbm message TLV part)

configure lldp-med (support LLDP-MED (Link Layer Discovery Protocol-Media Endpoint Discovery) phase 2 (OLT part))

configure lldp-med media-policy (support LLDP-MED (Link Layer Discovery Protocol-Media Endpoint Discovery) phase 2 (OLT part))

configure lldp-med port (support LLDP-MED (Link Layer Discovery Protocol-Media Endpoint Discovery) phase 2 (OLT part))

configure voice extline (support ISAMv SIP Analog Extension Line Service)

show alarm current cas-r2-channel (ISAM-V: SIP: R2: NIAT-A: ETSI: support cas-r2-channel alarm)

show alarm current lldpmed (support LLDP-MED (Link Layer Discovery Protocol-Media Endpoint Discovery) phase 2 (OLT part))

show alarm log cas-r2-channel (ISAM-V: SIP: R2: NIAT-A: ETSI: support cas-r2-channel alarm)

show alarm log lldpmed (support LLDP-MED (Link Layer Discovery Protocol-Media Endpoint Discovery) phase 2 (OLT part))

show alarm query lldpmed (support LLDP-MED (Link Layer Discovery Protocol-Media Endpoint Discovery) phase 2 (OLT part))

show alarm snap-shot cas-r2-channel (ISAM-V: SIP: R2: NIAT-A: ETSI: support cas-r2-channel alarm)

show alarm snap-shot lldpmed (support LLDP-MED (Link Layer Discovery Protocol-Media Endpoint Discovery) phase 2 (OLT part))

show voice extline (support ISAMv SIP Analog Extension Line Service)

Commands or commands with parameters for future use, not supported yet

configure li_vlan vlan-id (command not supported)

configure pon interface (parameter pon-speed not supported yet)

configure software-mngt sw-replacement-mode (command not supported yet)

show software-mngt upgrade-plan (command not supported yet)

```
show software-mngt upgrade-status (command not supported yet)
```

Command delta R5.7 versus R5.6.01

Modified Commands
admin system security ssh generate-key (SSH security improvements, upgrade openssl and default key pair removal)
admin trouble-shooting pbit interface (support enabling pbit counter on VLAN port level)
configure alarm entry (sip-isdnpratermination alarms replaced by e1-sip-termination, add alarm to see if CPE is not supporting 35b, alien and poe alarms not supported yet)
configure alarm filter filterid (supported alarm list updated)
configure equipment shelf (introduction of new 7362 ISAM SF-8GW product, renamed ngpon_port_reduced to ngpon-port-reduced)
configure ethernet ont (support ability to display 2.5G SFP ONT link speed)
configure interface port (port-type redefined)
configure qos profiles queue (Increase configurable queue size on fiber LTs)
configure system security ssh server-profile (SSH security improvements, upgrade openssl and default key pair removal)
configure system sync-if-timing ptp master-port (none' option removed from MasterPortProfile)
configure system sync-if-timing ptp ptp-domain (removal of the CLI cmd support of FANTG PTP port 2)
configure system sync-if-timing ptp slave-port-dataset (removal of the CLI cmd support of FANTG PTP port 2)
configure system sync-if-timing ptp tx-protocol (removal of the CLI cmd support of FANTG PTP port 2)
configure system sync-if-timing ssmout-synce (ToD sync redundancy support)
configure system sync-if-timing synce (ToD sync redundancy support)
configure trouble-shooting pbit statistics interface (support enabling pbit counter on VLAN port level)
configure voice sip isdn-cas-term (support CAS/R2 for NIAT-A SIP ETSI)
configure voice sip lineid-syn-prof (support CAS/R2 for NIAT-A SIP ETSI)
configure xdsl rtx-profile (min Impulse Noise Protection shine/rein Dn/Up with a subcarrier spacing of 8.625 KHz supported in annexC)
configure xdsl service-profile (min Impulse Noise Protection shine/rein Dn/Up with a subcarrier spacing of 8.625 KHz supported in annexC)
show interface port (updated interface port display)
show alarm (supported alarm list updated)
show alarm query name (supported alarm list updated)
show efm-oam mac-stats (improved Ethernet OAM statistic retrieval)
show equipment slot (support remote inventory for 7360 ISAM FX-8 AC redundant power units)
show equipment transceiver-inventory (new SFP types added)
show ethernet ont operational-data interface (support ability to display 2.5G SFP ONT link speed)
show iphost ont operational-data (retrieve the hostname of the snmp managed MDU)

show mcast active-groups detail (display currently joined HostIP for IGMP control channel)
show security ssh server (SSH security improvements, upgrade openssl and default key pair removal)
show snmp (add display of the boottime of the ISAM)
show system sync-if-timing tod-ref-order prio2 (ToD sync redundancy support)
show system sync-if-timing-master (removal of the CLI cmd support of FANTG PTP port 2)
show system sync-if-timing-ptp (removal of the CLI cmd support of FANTG PTP port 2)
show system sync-if-timing-tod (ToD sync redundancy support)
show voice sip isdn-cas-term (support CAS/R2 for NIAT-A SIP ETSI)
show xdsl failure-status far-end (Alarm for CPE not supporting xdsl 35b mode)

New Commands

clear qos-servicerouter (clear queue statistics on iHub ingress/egress forwarding class)
configure subscriber-mgmt (DHCP server allows allocating a fixed IP to a fixed subscriber or dynamically assigned IP)
configure system sync-if-timing tod holdover-spec (ToD sync redundancy support)
configure voice sip cas-r2-timer (support CAS/R2 for NIAT-A SIP ETSI)
remote-debug (OLT support for remote debug of 3rd party ONT via standard OMCI ME)
remote-debug ont (OLT support for remote debug of 3rd party ONT via standard OMCI ME)
show equipment ont status (single command to show ONU summary info)
show equipment ont status channel-pair (single command to show ONU summary info)
show equipment ont status pon (single command to show ONU summary info)
show security ssh server-key-status (SSH security improvements, upgrade openssl and default key pair removal)
show subscriber-mgmt (DHCP server allows allocating a fixed IP to a fixed subscriber or dynamically assigned IP)

Removed Commands

configure system sync-if-timing ptp ont-master-port (obsolete command replaced by configure system sync-if-timing ptp master-port)
show alarm current sip-isdnpratermination (support CAS/R2 for NIAT-A SIP ETSI, sip-isdnpratermination alarms not supported yet and replaced by e1-sip-termination)
show alarm log sip-isdnpratermination (support CAS/R2 for NIAT-A SIP ETSI, sip-isdnpratermination alarms not supported yet and replaced by e1-sip-termination)
show alarm snap-shot sip-isdnpratermination (support CAS/R2 for NIAT-A SIP ETSI, sip-isdnpratermination alarms not supported yet and replaced by e1-sip-termination)

Commands or commands with parameters for future use, not supported yet

admin channel-pair diagnostic (alien ONU detection on XGS-PON not supported yet)
admin port-protection activate (Type-B protection support on XGS-PON not supported yet)
admin system fips (fips not supported yet)
configure port-protection paired-port (Type-B protection support on XGS-PON not supported yet)

configure snmp-agent ont (NG-PON2 index is not supported yet)
configure system fips (fips not supported yet)
configure system security cdr-pm-file (call records not fully supported)
configure system security cdr-pm-file upload (call records not fully supported)
configure system syslog route msg-type (parameter ont-prov-status not supported yet)
configure trap definition (parameter ont-prov-status and new-ont-alm not supported yet)
configure trap manager (parameter ont-prov-status and new-ont-alm not supported yet)
configure voice ont mgc-agent (H248/Megaco on 10G Cards not supported yet)
configure voice ont service (H248/Megaco on 10G Cards not supported yet)
configure voice sip statistics (support per-node 5-min statistics)
show alarm current e1-sip-termination (support CAS/R2 for NIAT-A SIP ETSI)
show alarm log e1-sip-termination (support CAS/R2 for NIAT-A SIP ETSI)
show alarm query bulk-sync (Type-B protection support on XGS-PON not supported yet)
show alarm query channel-pair (alien ONU detection on XGS-PON not supported yet)
show alarm query mdu-sup (update alarm list, Power over Ethernet enhancements alarm mdu-sup-poe-over-yell not supported yet)
show alarm query ont (Power over Ethernet enhancements alarm ont-poe-overload-yell not supported yet)
show alarm query ont-voip (H248/Megaco on 10G Cards not supported yet)
show alarm query protection-group (Type-B protection support on XGS-PON not supported yet)
show alarm query sfu-sup (updated alarm list, Power over Ethernet enhancements alarm sfu-sup-poe-over-yell not supported yet)
show alarm query soho-sup (updated alarm list, Power over Ethernet enhancements alarm soho-sup-poe-over-yell not supported yet)
show alarm snap-shot e1-sip-termination (support CAS/R2 for NIAT-A SIP ETSI)
show channel-pair diagnostic (alien ONU display on XGS-PON not supported yet)
show port-protection (Type-B protection support on XGS-PON not supported yet)
show security cdr-pm-file (call records not fully supported)
show security cdr-pm-file upload (call records not fully supported)
show system fips (fips not supported yet)
show voice ont pots tc-layer olt-side current-interval (H248/Megaco on 10G Cards not supported yet)
show voice ont pots tc-layer olt-side previous-interval (H248/Megaco on 10G Cards not supported yet)
show voice ont pots tc-layer ont-side current-interval (H248/Megaco on 10G Cards not supported yet)
show voice ont pots tc-layer ont-side previous-interval (H248/Megaco on 10G Cards not supported yet)
show voice ont service (H248/Megaco on 10G Cards not supported yet)
show voice ont voip-vip-prof operational-data input-profile (H248/Megaco on 10G Cards not supported yet)

Command delta R5.6.01 versus R5.6

Modified Commands
admin system techsupport gen-on-demand (added range check for session ID parameter)
admin voice cluster equipment sharedline-port-id (support ISAMV-H248 NPOTS shared lines)
commands using the shelf ID (On 7360 ISAM FX, the number of shelves supported has been increased from 4 to 11. Due to this change, the autocompletion for the shelf parameter has changed (similar to the slot parameter): rack/shelf : for 1/2, auto-completion will work. For 1/1, the operator is to enter / (for shelf 1) or 0 (for shelf 10) or 1 (for shelf 11))
configure alarm entry (new alarms for ethernet ring, H248 NPOTS shared line. E1 alarms)
configure alarm filter filterid (update list of alarms)
configure channel-group id subchannel-group id (updated range parameter values)
configure cmts system (improve the Queue Management on the DPoE ONUs by allocating buffer sizes)
configure e1 line (TDM support for 8 E1 ports on the NSLT-D)
configure equipment external-link-assign (improvement to to restrict the rack/shelf of the SFP)
configure equipment shelf ("XG-PON1 ""only"" mode of operation")
configure interface port (NNI Mode Support on NDLT-G bonded lines)
configure interface port (TDM support for 8 E1 ports on the NSLT-D)
configure linetest cluster ltparm test-name (corrected test parameter description)
configure linetest cluster ltsession (corrected test parameter description)
configure linetest single ltparm test-name (support ISDN PRA loopback parameters (ISDN PRA parameters are still not supported for H.248) and corrected test parameter description)
configure linetest single ltsession (support ISDN PRA loopback parameters (ISDN PRA parameters are still not supported for H.248) and corrected test parameter description)
configure pon interface (add new authentication mode for CMCC)
configure qos profiles bandwidth (DBRu default is enable-if-supported, to improve throughput on upstream PON link, after migration the value is put at disable)
configure qos profiles queue (NNI Mode Support on NDLT-G bonded lines)
configure system (periph-mgmt-ctrl default value set to disable)
configure system security (POL: access control and dynamic VLAN assignment)
configure system security pae ext-authenticator (POL: access control and dynamic VLAN assignment)
configure system sync-if-timing ptp (removed not supported two-step TC mode)
configure trap definition (POL: access control and dynamic VLAN assignment)
configure trap manager (POL: access control and dynamic VLAN assignment)
configure vlan id (POL: access control and dynamic VLAN assignment)
configure voice cluster equipment sharedlineterm (support ISAMV-H248 NPOTS shared lines)
configure voice lsa-server emergency-service (support standalone SIP Emergency Call)
configure voice sip isdn-cas-term (ISAM Voice NIAT-A : assign SIP rules for a termination port)
show alarm query authentication (add authentication alarms)
show alarm query ellid (TDM support for 8 E1 ports on the NSLT-D)
show alarm query epon (TDM support for 8 E1 ports on the NSLT-D)
show alarm query ihub-ipv6 (update for new alarm ihub-ipv6-dup-pd-route)

show alarm query name (update list of alarms)
show alarm query otdr (TDM support for 8 E1 ports on the NSLT-D)
show alarm query sync (corrected pop-up message)
show ani ont video (VZ: Video Rx Management and Alarm Improvement)
show ani ont video-stats (VZ: Video Rx Management and Alarm Improvement)
show cable modem (improve the Queue Management on the DPoE ONUs by allocating buffer sizes)
show equipment external-link-host (improvement to to restrict the rack/shelf of the SFP)
show interface port (TDM support for 8 E1 ports on the NSLT-D)
show interface stack (TDM support for 8 E1 ports on the NSLT-D)
show interface test (TDM support for 8 E1 ports on the NSLT-D)
show linetest cluster ltline (parameter value mta-testing obsoleted due to end of MTA support)
show linetest single lineid-ext-rept (support ISDN PRA parameters (ISDN PRA parameters are still not supported for H.248))
show linetest single ltline (parameter value mta-testing obsoleted due to end of MTA support)
show pon unprovision-onu (add new field to indicate ONT type)
show voice cluster sharedlineterm (support ISAMV-H248 NPOTS shared lines)
show voice cluster termination (parameter value mta-testing obsoleted due to end of MTA support)
show voice isa-emergency (support standalone SIP Emergency Call)
show voice isa-emergency state (support standalone SIP Emergency Call)
show voice sip isdn-cas-term (ISAM Voice NIAT-A : assign SIP rules for a termination port)
show voice sip termination (parameter value mta-testing obsoleted due to end of MTA support)

New Commands

admin e1 (TDM support for 8 E1 ports on the NSLT-D)
admin e1 diagnos-test (TDM support for 8 E1 ports on the NSLT-D)
admin security mac-diag mac-addr (POL: access control and dynamic VLAN assignment)
configure system dst (support Daylight Savings Time)
configure system dst date (support Daylight Savings Time)
configure system dst recurring (support Daylight Savings Time)
show alarm current e1 (TDM support for 8 E1 ports on the NSLT-D)
show alarm current ethernet-ring (support ring with ERPS (G.8032) alarms)
show alarm current secondary-megaco-term (display alarms for shared lines)
show alarm current secondary-sip-term (display alarms for shared lines)
show alarm log e1 (TDM support for 8 E1 ports on the NSLT-D)
show alarm log ethernet-ring (support ring with ERPS (G.8032) alarms)
show alarm log secondary-megaco-term (display alarms for shared lines)
show alarm log secondary-sip-term (display alarms for shared lines)
show alarm query secondary-megaco-term (display alarms for shared lines)

show alarm query secondary-sip-term (display alarms for shared lines)
show alarm snap-shot e1 (TDM support for 8 E1 ports on the NSLT-D)
show alarm snap-shot ethernet-ring (support ring with ERPS (G.8032) alarms)
show alarm snap-shot secondary-megaco-term (display alarms for shared lines)
show alarm snap-shot secondary-sip-term (display alarms for shared lines)
show e1 diagnostest-status (TDM support for 8 E1 ports on the NSLT-D)
show e1-counters (TDM support for 8 E1 ports on the NSLT-D)
show e1-counters current-1day (TDM support for 8 E1 ports on the NSLT-D)
show e1-counters current-interval (TDM support for 8 E1 ports on the NSLT-D)
show e1-counters previous-1day (TDM support for 8 E1 ports on the NSLT-D)
show e1-counters previous-interval (TDM support for 8 E1 ports on the NSLT-D)
show gre (GRE and Routing support on tunnel)
show security pae mac-authenticator (POL: access control and dynamic VLAN assignment)
show security pae mac-diagnostics (POL: access control and dynamic VLAN assignment)
show system dst (sipport Daylight Savings Time)
show system dst date-table (sipport Daylight Savings Time)
show system dst recurring-table (sipport Daylight Savings Time)

Commands or commands with parameters for future use, not supported yet

admin port-protection activate (Type-B protection support on XGS-PON not supported yet)
configure equipment ont gis (MII Universal BB Service: Location Config Data OLT part)
configure generic-pon gis-info (MII Universal BB Service: Location Config Data OLT part)
configure port-protection paired-port (Type-B protection support on XGS-PON not supported yet)
configure system security default-profile (parameter livoice not supported)
configure system security profile (parameter livoice not supported)
configure voice cluster equipment termination li (command not supported)
show equipment ont gis (MII Universal BB Service: Location Config Data OLT part)
show equipment slot (parameters bat-a bat-b not supported yet)
show port-protection (Type-B protection support on XGS-PON not supported yet)

Command delta R5.6 versus R5.5.01

Modified Commands

admin cable modem (support DPOE show commands with IPv6 options)
admin cm uniport (support DPOE show commands with IPv6 options)
admin equipment ont interface (support User Commanded on-the-fly ONU movement)
admin equipment slot (add the restrt-cnt-per-lt counter)
admin equipment slot (add the restrt-cnt-per-lt counter)

admin system techsupport gen-on-demand (added range for techsupport session id parameter)
admin voice cluster equipment port-id (updated portid specification)
configure alarm entry (new alarm no-unpinned-free-ports and ihub-ipv6-dup-pd-route inlet tempera)
configure alarm filter filterid (updated alarm list)
configure cfm domain association (updated specification of InterfaceZeroIndex)
configure cmts ipdr-global (update DPoE Multicast and IPDR)
configure cmts serving-group (DPoE: IPv6 ICMPv6 security improvements)
configure cmts system (DPoE: Prefix Stability Enhancement)
configure equipment ont interface (support User Commanded on-the-fly ONU movement)
configure linetest cluster ltparm test-name (parameters for ISDN PRA not supported yet)
configure linetest single ltparm test-name (parameters for ISDN PRA not supported yet)
configure linetest single ltssession (new parameters isdn-pra-remotelb, isdn-pra-ploadlb, isdn-pra-locallb, isdn-pra-cablelb not supported yet)
configure pon uri-prof (add ability to modify the SIPING Server Network Address Profile (SSNAP))
configure qos interface (identify downstream scheduler reference to prevent improper input)
configure qos profiles policy-action (support NNI Inc. 2 on FELT-B)
configure system (new parameters arp-polling-inter bsnap-state bsnap-server-ip bsnap-server-port not supported yet)
configure system (support alarm generation for LEMI on RANT-A)
configure system security default-profile (update for password timeout for an operator with default-profile)
configure system security snmp manager (context ihub added)
configure system sync-if-timing ptp (update support for TOD over FANT-G)
configure system sync-if-timing ptp accept-master (update support for TOD over FANT-G)
configure system sync-if-timing ptp ptp-domain (update support for TOD over FANT-G)
configure system sync-if-timing ptp slave-port-dataset (parameter values changed from ieee1588-a ieee1588-b to ieee1588-a:1 ieee1588-b:1 ieee1588-a:2 ieee1588-b:2")
configure system sync-if-timing ptp tx-protocol (parameter values changed from ieee1588-a ieee1588-b to ieee1588-a:1 ieee1588-b:1 ieee1588-a:2 ieee1588-b:2")
configure system sync-if-timing ssmout-synce (removed obsolete value none from parameter SynceOutFaceplateNumber)
configure trap manager (support dying gasp feature in software method)
configure vlan id (improved ARP snooping and polling)
configure vlan id (support L2 DHCP relay agent on NNI interfaces in order to support autoconfiguration of a connected node in a daisy chain or ring topology)
configure voice ont uri-prof (add ability to modify the SIPING Server Network Address Profile (SSNAP))
configure voice sip vsp (support SIP INFO DTMF relay function)
configure xdsl-bonding group-assembly-time (introduce new bonding initialization strategy)
configure xdsl-bonding group-profile (introduce new bonding initialization strategy)

show alarm query eqpt-holder-ext (add 7363 ISAM MX temperature inlet alarm)
show alarm query lag (support pinning an S-VLAN to a member uplink when multiple uplinks are present in a LAG)
show alarm query name (updated alarm list)
show cable config-file (support DPOE show commands with IPv6 options)
show cable modem (support DPOE show commands with IPv6 options)
show dpoe onu (support DPOE show commands with IPv6 options)
show dpoe profile pw-class name (support DPOE show commands with IPv6 options)
show dpoe profile vpls-class name (support DPOE show commands with IPv6 options)
show dpoe profile vpn-sg name (support DPOE show commands with IPv6 options)
show dpoe service vpls ip-addr (support DPOE show commands with IPv6 options)
show dpoe service vpws ip-addr (support DPOE show commands with IPv6 options)
show interface cable (support DPOE show commands with IPv6 options)
show linetest single lineid-ext-rept (new parameters isdn-pra-remotelb, isdn-pra-ploadlb, isdn-pra-locallb, isdn-pra-cablelb not supported yet)
show linetest single lline (ISAMV: SIP NPOTs to support shared lines)
show system sync-if-timing-master (update support for TOD over FANT-G)
show system sync-if-timing-ptp (update support for TOD over FANT-G)
show trouble-shooting statistics uni-interface (improved trouble-shooting statistics display)
show voice sip termination (ISAMV: SIP NPOTs to support shared lines)
show xdsl-bonding actual-ptm-init-mode (introduce new bonding initialization strategy)
show xdsl-bonding operational-data link (introduce new bonding initialization strategy)

New Commands

admin trouble-shooting color (support NNI Inc. 2 on FELT-B)
admin trouble-shooting color interface (support NNI Inc. 2 on FELT-B)
admin voice cluster equipment port-id (updated portid specification)
admin voice cluster equipment sharedline-port-id (ISAMV: SIP NPOTs to support shared lines)
clear log (command to clear log id 99 and 100)
configure system relay-id-syntax (support L2 DHCP relay agent on NNI interfaces in order to support autoconfiguration of a connected node in a daisy chain or ring topology)
configure system sync-if-timing ptp link-port-compensation (support IEEE 1588 ToD TC on MOOC Downlink on FELT-B)
configure system sync-if-timing ptp master-port (improved PTP Master port creation with VLAN ID)
configure trouble-shooting color (support NNI Inc. 2 on FELT-B)
configure trouble-shooting color statistics (support NNI Inc. 2 on FELT-B)
configure trouble-shooting color statistics interface (support NNI Inc. 2 on FELT-B)
configure voice cluster equipment sharedlineterm (ISAMV: SIP NPOTs to support shared lines)
configure voice sip manipulate-rule (ISAMV: SIP NPOTs to support shared lines)

configure voice sip sharedline (ISAMV: SIP NPOTs to support shared lines)
show dpoe onu (support DPOE show commands with IPv6 options)
show trouble-shooting color (support NNI Inc. 2 on FELT-B)
show trouble-shooting color statistics (support NNI Inc. 2 on FELT-B)
show trouble-shooting color statistics interface (support NNI Inc. 2 on FELT-B)
show voice cluster sharedlineterm (ISAMV: SIP NPOTs to support shared lines)
show voice sip sharedline (ISAMV: SIP NPOTs to support shared lines)
show xdsl-bonding actual-ptm-init-mode (introduce new bonding initialization strategy)

Commands or commands with parameters for future use, not supported yet

configure cmts li (not supported command)
configure e1 line (TDM support for 8 E1 ports on the NSLT-D Phase 2)
configure interface port (parameter e1-line not supported yet)
configure voice cluster equipment termination li (command not supported)
configure voice lsa-server emergency-service (command not supported)
show alarm query ellid (parameter e1-line not supported yet)
show alarm query epon (parameter e1-line not supported yet)
show alarm query ihub-ipv6 (update for new alarm ihub-ipv6-dup-pd-route)
show alarm query otdr (parameter e1-line not supported yet)
show interface port (parameter e1-line not supported yet)
show interface stack (parameter e1-line not supported yet)
show interface test (parameter e1-line not supported yet)
show voice lsa-emergency (command not supported)
show voice lsa-emergency state (command not supported)

Command delta R5.5.01 versus R5.5

Modified Commands

admin equipment ont interface (allow ISAM to trigger a reboot of an ONU via proprietary PLOAM)
admin software-mngt oswp (enable activation with a default database retaining management link)
admin trouble-shooting pbit interface (updated interface index format)
configure alarm entry (ais-signal, los-signal, rai-signal replaced by new isdn- alarms. New alarms for Ethernet ring and lsa-fo-trigger. Duplicate alarm sem-ups-fail replaced by sem-ups-low-volt, new power alarms)
configure alarm filter filterid (update for alarm changes)
configure bridge port (support configurable Downstream p-bit translation behavior)
configure channel-pair interface (XGS-PON on 7360 ISAM FX including XG-PON1 and dual rate)
configure channel-pair profiles (XGS-PON on 7360 ISAM FX including XG-PON1 and dual rate)
configure equipment external-link-assign (updated index parameter values)

configure equipment ont interface (Flush MAC in LT FDB automatically when ONT is rebooted/power-cycled or when a UNI goes down)
configure equipment ont interface (XGS-PON on 7360 ISAM FX including XG-PON1 and dual rate)
configure equipment slot lt (support for ISAMV ISDN SIP on NIAT-A board)
configure system security (support for configuring the number of CLI sessions and the operator login retry policy)
configure system security domain (support for configuring the number of CLI sessions)
configure system security operator (support for configuring the number of CLI sessions)
configure trouble-shooting pbit statistics (updated interface index format)
configure voice sip lineid-syn-prof (support for ISAMV ISDN SIP on NIAT-A board)
show alarm query eqpt-holder-ext (alarm sem-ups-fail replaced by improved alarm sem-ups-low-volt, new power alarms)
show alarm query name (update for alarm changes)
show alarm query sip-termination (removed obsolete ISDN alarms)
show equipment external-link-host (updated index parameter values)
show equipment ont interface (XGS-PON on 7360 ISAM FX including XG-PON1 and dual rate (note: in this release, it will always report as unknown))
show equipment ont ng2-sw-download (Universal NG-PON: OMCI Pre-Configuration download)
show equipment ont ng2-sw-download channel-group (Universal NG-PON: OMCI Pre-Configuration download)
show system license (support ring with ERPS (G.8032) on uplinks)
show trouble-shooting pbit statistics interface (updated interface index format)
show trouble-shooting pbitstatistics vlanport (updated interface index format)

New Commands

admin software-mngt ihub database oam-save-protected (support for saving the OAM protected interface)
configure e1 (TDM support for 8 E1 ports on the NSLT-D Phase 1)
configure e1 line (TDM support for 8 E1 ports on the NSLT-D Phase 1)
configure shdsl span (TDM support for 8 E1 ports on the NSLT-D not supported yet)
configure voice sip isdn-cas-term (support for ISAMV ISDN SIP on NIAT-A board)
show alarm current sip-isdnpratermination (support for ISAMV ISDN SIP on NIAT-A board)
show alarm log sip-isdnpratermination (support for ISAMV ISDN SIP on NIAT-A board)
show alarm snap-shot sip-isdnpratermination (support for ISAMV ISDN SIP on NIAT-A board)
show e1 (TDM support for 8 E1 ports on the NSLT-D Phase 1)
show e1 line-status (TDM support for 8 E1 ports on the NSLT-D Phase 1)
show equipment ont index (CLI ONT Index Lookup Using Serial Number)
show equipment ont ng2-cfg-download (Universal NG-PON: OMCI Pre-Configuration download)
show equipment ont ng2-cfg-download channel-group (Universal NG-PON: OMCI Pre-Configuration download)
show voice sip isdn-cas-term (support for ISAMV ISDN SIP on NIAT-A board)

Commands or commands with parameters for future use, not supported yet

configure qos profiles policy-action count (multi-service support at ONT for untagged UNI)
configure qos profiles session rem-down-policy (multi-service support at ONT for untagged UNI)
configure qos profiles session rem-up-policy (multi-service support at ONT for untagged UNI)

Command delta R5.5 versus R5.4.01**Modified Commands**

admin interface cable (command description moved from obsoleted DPoE CLI guide to this guide)
configure alarm filter filterid (update for alarm changes)
configure ani ont tca-thresh (update threshold paramter)
configure cfm domain association (support for ERPS on uplinks and Fast CCM feature)
configure cfm y1731pm (no domain (domain-index) association (renamed parameter adminup to admin-up)
configure channel-group id subchannel-group id (support FWLT-A LOID ONU authentication (OLT part))
configure channel-pair interface (support Dynamic Upstream GPON/NG-PON2 CAC)
configure cm classifier name (update source and destination mask definition)
configure cm route-profile (update source and destination mask definition)
configure cm tlv-file (DPoE: Upstream data encryption on 10G PON)
configure cmts filter (update command description)
configure cmts interface (support interval based cable modem qos and service flow throughput rate)
configure cmts pon (DPoE Rogue ONU detection)
configure cmts pon (DPoE: Upstream data encryption on 10G PON)
configure cmts system (configure sending cm events to the Syslog server)
configure equipment ont interface (Configurable Rate Limiting at ONT side, OLT impact)
configure equipment shelf (update mode to support 7362 ISAM DF-16GW)
configure equipment slot (ISAMv and 7363 ISAM MX: support Local Standalone SIP Server)
configure pon interface (support Dynamic Upstream GPON/NG-PON2 CAC)
configure qos profiles bandwidth (DBA Performance Improvement: DBRu enabled)
configure system sync-if-timing synce (update for NRNT-A CCR check)
configure trap definition (support Dynamic Upstream GPON/NG-PON2 CAC)
configure trap manager (support Dynamic Upstream GPON/NG-PON2 CAC and Zero-touch provisioning)
configure vlan id (add new command for protocol aware of DHCP/PPPOE)
configure voice cluster equipment termination (update Impedance Index)
configure voice sip server (ISAMv and 7363 ISAM MX: support Local Standalone SIP Server)
configure voice sip termination (update Impedance Index)

configure voice sip user-agent (ISAMv and 7363 ISAM MX: support Local Standalone SIP Server)
configure voice sip user-agent-ap slot-id (ISAMv and 7363 ISAM MX: support Local Standalone SIP Server)
configure voice sip vsp (CVP: support Multiple SSP per CDE profile)
configure xdsl ont line (support VDSL2 parameter configuration and reporting over OMCI)
configure xdsl ont rtx-profile (support VDSL2 parameter configuration and reporting over OMCI)
configure xdsl ont spectrum-profile vdsl (support VDSL2 parameter configuration and reporting over OMCI)
show alarm query channel-pair (support Dynamic Upstream GPON/NG-PON2 CAC: support ranging mismatch)
show alarm query name (update for alarm changes)
show alarm query olt-gen (support Dynamic Upstream GPON/NG-PON2 CAC: show and clear ranging mismatch alarm)
show alarm query sip-plugin-unit (not supported parameter value dhcp-unreach removed)
show alarm query traffic-overflow (NT board type added)
show dpoe olt (command description moved from obsoleted DPoE CLI guide to this guide)
show dpoe onu (command description moved from obsoleted DPoE CLI guide to this guide)
show interface cable (command description moved from obsoleted DPoE CLI guide to this guide)
show interface dpoe (command description moved from obsoleted DPoE CLI guide to this guide)
show qos interface-bandwidth (support Dynamic Upstream GPON/NG-PON2 CAC)
show system license (ISAM Voice SIP CVP Multiple Voice Service Gateway Licensing)
show voice sip statistics termination current-15min (ISAMv SIP CVP : support additional PM counters at PORT level)
show voice sip statistics termination previous-15min (ISAMv SIP CVP : support additional PM counters at PORT level)
show xdsl ont operational-data far-end line (support VDSL2 parameter configuration and reporting over OMCI)
show xdsl ont operational-data near-end line (support VDSL2 parameter configuration and reporting over OMCI)

New Commands

admin cable modem (DPoE Rogue ONU detection)
admin channel-pair clear-alarm (support Dynamic Upstream GPON/NG-PON2 CAC)
admin cm uniport auto-nego (command description moved from obsoleted DPoE CLI guide to this guide)
admin cmts add-cm-event mac-addr (command description moved from obsoleted DPoE CLI guide to this guide)
admin cmts del-cm-event mac-addr (command description moved from obsoleted DPoE CLI guide to this guide)
admin cmts rogue-onu detection (DPoE Rogue ONU detection)
admin cmts security generate-key (DPoE: Upstream data encryption on 10G PON)
admin cmts vpls (command description moved from obsoleted DPoE CLI guide to this guide)

admin cmts vpls update vpn-id (command description moved from obsoleted DPoE CLI guide to this guide)
admin interface cable (command description moved from obsoleted DPoE CLI guide to this guide)
admin pon clear-alarm (support Dynamic Upstream GPON/NG-PON2 CAC)
configure cfm domain association mep active-remote-mep (support for ERPS on uplinks and Fast CCM feature)
configure system zero-touch-provision (support Zero-touch provisioning)
configure voice lsa-server (ISAMv and 7363 ISAM MX: support Local Standalone SIP Server)
configure voice lsa-server instance (ISAMv and 7363 ISAM MX: support Local Standalone SIP Server)
configure voice lsa-server system (ISAMv and 7363 ISAM MX: support Local Standalone SIP Server)
show alarm current sip-user-agent (ISAMv and 7363 ISAM MX: support Local Standalone SIP Server)
show alarm current uplink-ether-sfp (new ethernet SFP alarm)
show alarm log sip-user-agent (ISAMv and 7363 ISAM MX: support Local Standalone SIP Server)
show alarm log uplink-ether-sfp (new ethernet SFP alarm)
show alarm query sip-user-agent (ISAMv and 7363 ISAM MX: support Local Standalone SIP Server)
show alarm query uplink-ether-sfp (support for ethernet uplink SFP alarm)
show alarm snap-shot sip-user-agent (ISAMv and 7363 ISAM MX: support Local Standalone SIP Server)
show alarm snap-shot uplink-ether-sfp (new ethernet SFP alarm)
show cable config-file (command description moved from obsoleted DPoE CLI guide to this guide)
show cable flap-list (command description moved from obsoleted DPoE CLI guide to this guide)
show cable modem cable (command description moved from obsoleted DPoE CLI guide to this guide)
show cmts cm-event-ctrl (command description moved from obsoleted DPoE CLI guide to this guide)
show cmts ipdr (command description moved from obsoleted DPoE CLI guide to this guide)
show cmts ipdr status session (command description moved from obsoleted DPoE CLI guide to this guide)
show cmts mcast (command description moved from obsoleted DPoE CLI guide to this guide)
show cmts mcast gsf id (DPoE multicast display improvements)
show cmts mcast session slot (DPoE multicast display improvements)
show cmts rogue-onu (DPoE Rogue ONU detection)
show cmts security (DPoE: Upstream data encryption on 10G PON)
show cmts vpls (command description moved from obsoleted DPoE CLI guide to this guide)
show cmts vpls update (command description moved from obsoleted DPoE CLI guide to this guide)
show dpoe olt (command description moved from obsoleted DPoE CLI guide to this guide)
show dpoe onu (command description moved from obsoleted DPoE CLI guide to this guide)
show dpoe profile acl grp-id (command description moved from obsoleted DPoE CLI guide to this guide)
show dpoe profile pw-class name (command description moved from obsoleted DPoE CLI guide to this guide)
show dpoe profile vpls-class name (command description moved from obsoleted DPoE CLI guide to this guide)

show dpoe profile vpn-sg name (command description moved from obsoleted DPoE CLI guide to this guide)
show dpoe service v-vpls vpn-id (command description moved from obsoleted DPoE CLI guide to this guide)
show dpoe service vpls ip-addr (command description moved from obsoleted DPoE CLI guide to this guide)
show dpoe service vpws ip-addr (command description moved from obsoleted DPoE CLI guide to this guide)
show interface dpoe (command description moved from obsoleted DPoE CLI guide to this guide)
show voice lsa-instance (ISAMv and 7363 ISAM MX: support Local Standalone SIP Server)
show voice lsa-instance state (ISAMv and 7363 ISAM MX: support Local Standalone SIP Server)
show voice lsa-system (ISAMv and 7363 ISAM MX: support Local Standalone SIP Server)
show voice lsa-system state (ISAMv and 7363 ISAM MX: support Local Standalone SIP Server)
show voice sip all (CVP: support Multiple SSP per CDE profile)
show voice sip dhcpsipserver (CVP: support Multiple SSP per CDE profile)
show voice sip sspprofile (CVP: support Multiple SSP per CDE profile)

Commands or commands with parameters for future use, not supported yet

configure qos interface (parameter ds-schedule-tag not supported yet)
configure shdsl span (TDM support for 8 E1 ports on the NSLT-D not supported yet)
configure voice sip isdn-cas-term (new command to configure an ISDN termination)
configure voice sip lineid-syn-prof (parameter isdn-syntax not supported yet)
show alarm query sip-termination (E1 interface alarms ais-signal los-signal rai-signal npt supported yet)
show equipment ont index (CLI ONT Index Lookup Using SN)
show equipment ont ng2-cfg-download (NGPON2 OMCI Pre-Configuration-OLT part)
show equipment ont ng2-cfg-download channel-group (NGPON2 OMCI Pre-Configuration-OLT part)
show equipment ont ng2-sw-download (NGPON2 OMCI Pre-Configuration-OLT part)
show equipment ont ng2-sw-download channel-group (NGPON2 OMCI Pre-Configuration-OLT part)
show qos statistics color-queue (PON UNI extension)
show qos statistics color-queue current-15min (PON UNI extension)
show qos statistics color-queue prev-15min (PON UNI extension)
show voice sip isdn-cas-term (new command to show an ISDN termination)

Command delta R5.4.01 versus R5.4

Modified Commands

admin bridge learned-unicast-mac unicast-mac-address (SIP Voice Support on NG-PON2 (OLT Part))
admin dhcp-relay port-stats (SIP Voice Support on NG-PON2 (OLT Part))
admin equipment ont interface (support for Equipment Protection via Wavelength Mobility on NG-PON2 and add new alarm when dhcpd client can not get ip address)

admin iphost ping dest-ip (SIP Voice Support on NG-PON2 (OLT Part))
admin linetest single-if-index melt-reset (MELT improvements)
admin linetest single-if-index melt-selftest (MELT improvements)
admin security ext-authenticator (SIP Voice Support on NG-PON2 (OLT Part))
admin voice ont pots diagnostics (SIP Voice Support on NG-PON2 (OLT Part))
admin voice ont pots pb-dial-tone (SIP Voice Support on NG-PON2 (OLT Part))
admin voice ont pots sip-dial-tone sip-phone-number (SIP Voice Support on NG-PON2 (OLT Part))
admin voice ont voip-config (SIP Voice Support on NG-PON2 (OLT Part))
configure alarm entry (support for Equipment Protection via Wavelength Mobility on NG-PON2 and add new alarm when dhcpd client can not get ip address)
configure alarm filter filterid (support for Equipment Protection via Wavelength Mobility on NG-PON2)
configure bridge port (SIP Voice Support on NG-PON2 (OLT Part))
configure cfm domain association (Introduction of Maintenance Point on PON LTs : virtual UNI/Bridge port [segment B] on FGLT-B/FWLT-A)
configure cfm domain association (SIP Voice Support on NG-PON2 (OLT Part))
configure cfm domain association mep (SIP Voice Support on NG-PON2 (OLT Part))
configure cm classifier (command parameters marked as optional)
configure cm cm-static (command parameters marked as optional)
configure cm gen-ext (command parameters marked as optional)
configure cm ipv6-classif-pf (command parameters marked as optional)
configure cm oam (command parameters marked as optional)
configure cm route-profile (command parameters marked as optional)
configure cm service-flow (command parameters marked as optional)
configure cm sf-collection (command parameters marked as optional)
configure cm tlv-file (command parameters marked as optional)
configure cm uni-collection (command parameters marked as optional)
configure cm uniprofile (command parameters marked as optional)
configure cmts allowonu (command parameters marked as optional)
configure cmts bundle (command parameters marked as optional)
configure cmts cm-event (command parameters marked as optional)
configure cmts filter (command parameters marked as optional)
configure cmts ipdr (command parameters marked as optional)
configure cmts mesp (command parameters marked as optional)
configure cmts sav (command parameters marked as optional)
configure cmts serving-group (DPoE Multicast Support)
configure cmts serving-group (command parameters marked as optional)
configure cmts ssd (command parameters marked as optional)
configure cmts system (improvement to release CPE IP after ONU reset)

configure cmts vpls-class (command parameters marked as optional)
configure cmts vpn-sg (command parameters marked as optional)
configure dhcp-relay port-stats (SIP Voice Support on NG-PON2 (OLT Part))
configure equipment ont interface (update mobility support for Equipment Protection feature to configure protection channelpair)
configure equipment ont slot (GPON/NG-PON2 NNI feature extension : support for 64 IGMP signaling channels)
configure ethernet line mau (add new mau type 10gbasex)
configure igmp system (add support for unconfigured SSM multicast)
configure interface port (SIP Voice Support on NG-PON2 (OLT Part))
configure iphost ont (SIP Voice Support on NG-PON2 (OLT Part))
configure linetest cluster ltparm test-name (ISAMV SIP Forced ringing test update)
configure linetest single ltparm test-name (support GR909 draw and break dial tone delay)
configure linetest single ltssession (new parameter force-measure to force the MELT measurement even if the SLIC hardware fails)
configure linetest single ltssession session-cmd ownerid timeout-period line-num type-high force-ring-subscrib (ISAMV SIP Forced ringing test update)
configure mcast static branch (SIP Voice Support on NG-PON2 (OLT Part))
configure qos interface (SIP Voice Support on NG-PON2 (OLT Part))
configure qos tca queue (SIP Voice Support on NG-PON2 (OLT Part))
configure system security pae authenticator (SIP Voice Support on NG-PON2 (OLT Part))
configure system security pae ext-authenticator (SIP Voice Support on NG-PON2 (OLT Part))
configure system security pae port (SIP Voice Support on NG-PON2 (OLT Part))
configure system security ssh access (support debugkernel on FANT-G)
configure system security ssh user (improved handling of parameter key)
configure trap definition (support for Equipment Protection via Wavelength Mobility on NG-PON2)
configure trap manager (support for Equipment Protection via Wavelength Mobility on NG-PON2)
configure vlan pbit-statistics port (SIP Voice Support on NG-PON2 (OLT Part))
configure vlan port-protocol (SIP Voice Support on NG-PON2 (OLT Part))
configure vlan unicast-mac vlan-id (SIP Voice Support on NG-PON2 (OLT Part))
configure vlan vlan-port unicast-mac (SIP Voice Support on NG-PON2 (OLT Part))
configure voice ont pots (SIP Voice Support on NG-PON2 (OLT Part))
configure voice ont pots-call (SIP Voice Support on NG-PON2 (OLT Part))
configure voice ont pots-rtp (SIP Voice Support on NG-PON2 (OLT Part))
configure voice ont sip-agent (SIP Voice Support on NG-PON2 (OLT Part))
configure voice ont sip-call (SIP Voice Support on NG-PON2 (OLT Part))
configure voice ont sip-config (SIP Voice Support on NG-PON2 (OLT Part))
configure voice ont voice-port (SIP Voice Support on NG-PON2 (OLT Part))
configure voice ont voice-sip-port (SIP Voice Support on NG-PON2 (OLT Part))

configure voice ont voip-config (SIP Voice Support on NG-PON2 (OLT Part))
configure voice sip statistics stats-config (update for PM counters at port level)
configure xdsl ont spectrum-profile vdsl (enable configuration of annex b 997e bandplan)
show alarm query ai (add new alarm when dhcpd client can not get ip address)
show alarm query ellid (SIP Voice Support on NG-PON2 (OLT Part))
show alarm query epon (SIP Voice Support on NG-PON2 (OLT Part))
show alarm query l2forward (SIP Voice Support on NG-PON2 (OLT Part))
show alarm query name (support for Equipment Protection via Wavelength Mobility on NG-PON2)
show alarm query ont-iphost (SIP Voice Support on NG-PON2 (OLT Part))
show alarm query ont-mgc (SIP Voice Support on NG-PON2 (OLT Part))
show alarm query ont-sip-agent-cfg (SIP Voice Support on NG-PON2 (OLT Part))
show alarm query ont-voip-cfg (SIP Voice Support on NG-PON2 (OLT Part))
show alarm query otdr (SIP Voice Support on NG-PON2 (OLT Part))
show alarm query plug-in-unit-ext (board-hw-issue is changed to melt-hw-issue in the alarm plug-in-unit-ext table)
show alarm query qos-queue (SIP Voice Support on NG-PON2 (OLT Part))
show alarm query vlanport (SIP Voice Support on NG-PON2 (OLT Part))
show arp-relay-stats (SIP Voice Support on NG-PON2 (OLT Part))
show cfm stack (SIP Voice Support on NG-PON2 (OLT Part))
show dhcp-relay port-stats (SIP Voice Support on NG-PON2 (OLT Part))
show dhcp-relay v6-port-stats (SIP Voice Support on NG-PON2 (OLT Part))
show equipment ont ranging-status channel-group (support for Equipment Protection via Wavelength Mobility on NG-PON2)
show equipment ont ranging-status channel-pair (support for Equipment Protection via Wavelength Mobility on NG-PON2)
show interface port (SIP Voice Support on NG-PON2 (OLT Part))
show interface stack (SIP Voice Support on NG-PON2 (OLT Part))
show interface test (SIP Voice Support on NG-PON2 (OLT Part))
show iphost ont operational-data (SIP Voice Support on NG-PON2 (OLT Part))
show iphost ont statistics current-15min (SIP Voice Support on NG-PON2 (OLT Part))
show ipv6 users (SIP Voice Support on NG-PON2 (OLT Part))
show linetest single lineid-ext-rept (support GR909 draw and break dial tone delay)
show linetest single melt-reset (MELT improvements)
show linetest single melt-selftest (MELT improvements)
show linetest single melt-selftest hw-status (MELT improvements)
show linetest single melt-selftest self-test-status (MELT improvements)
show pppoe12-stats (SIP Voice Support on NG-PON2 (OLT Part))
show qos interface-bandwidth (SIP Voice Support on NG-PON2 (OLT Part))
show qos statistics queue current-15min (SIP Voice Support on NG-PON2 (OLT Part))

show qos statistics queue prev-15min (SIP Voice Support on NG-PON2 (OLT Part))
show security pae authenticator (SIP Voice Support on NG-PON2 (OLT Part))
show security pae diagnostics (SIP Voice Support on NG-PON2 (OLT Part))
show security pae eapol-stats (SIP Voice Support on NG-PON2 (OLT Part))
show security pae port-details (SIP Voice Support on NG-PON2 (OLT Part))
show security pae session-stats (SIP Voice Support on NG-PON2 (OLT Part))
show system license (update for the number of fclt-b boards configured as vula/uplink mode)
show system techsupport (on demand tech support file generation for datapath troubleshooting legacy Fiber LTs)
show trouble-shooting statistics uni-interface (SIP Voice Support on NG-PON2 (OLT Part))
show trouble-shooting statistics vlanport bridgeport-id (SIP Voice Support on NG-PON2 (OLT Part))
show vlan bridge-port-fdb (SIP Voice Support on NG-PON2 (OLT Part))
show vlan cross-connect (SIP Voice Support on NG-PON2 (OLT Part))
show vlan current-15min-stats (SIP Voice Support on NG-PON2 (OLT Part))
show vlan current-day-stats (SIP Voice Support on NG-PON2 (OLT Part))
show vlan dup-mac-alarm (SIP Voice Support on NG-PON2 (OLT Part))
show vlan pbit-statistics port (SIP Voice Support on NG-PON2 (OLT Part))
show vlan port-15min-stats (SIP Voice Support on NG-PON2 (OLT Part))
show vlan port-accumu-stats (SIP Voice Support on NG-PON2 (OLT Part))
show vlan port-curr-15min-stats (SIP Voice Support on NG-PON2 (OLT Part))
show vlan port-curr-day-stats (SIP Voice Support on NG-PON2 (OLT Part))
show vlan port-event (SIP Voice Support on NG-PON2 (OLT Part))
show vlan port-prev-day-stats (SIP Voice Support on NG-PON2 (OLT Part))
show vlan previous-15min-stats (SIP Voice Support on NG-PON2 (OLT Part))
show vlan residential-bridge extensive (SIP Voice Support on NG-PON2 (OLT Part))
show vlan residential-bridge summary (SIP Voice Support on NG-PON2 (OLT Part))
show vlan vlan-day-stats (SIP Voice Support on NG-PON2 (OLT Part))
show vlan vmac-bridge-port-fdb (SIP Voice Support on NG-PON2 (OLT Part))
show voice ont call-hist (SIP Voice Support on NG-PON2 (OLT Part))
show voice ont pots diagnostics (SIP Voice Support on NG-PON2 (OLT Part))
show voice ont pots hookstate (SIP Voice Support on NG-PON2 (OLT Part))
show voice ont pots operational-data (SIP Voice Support on NG-PON2 (OLT Part))
show voice ont pots pb-dial-tone (SIP Voice Support on NG-PON2 (OLT Part))
show voice ont pots sip-dial-tone (SIP Voice Support on NG-PON2 (OLT Part))
show voice ont pots-call statistics current-15min (SIP Voice Support on NG-PON2 (OLT Part))
show voice ont pots-rtp statistics current-15min (SIP Voice Support on NG-PON2 (OLT Part))
show voice ont sip-agent statistics current-15min (SIP Voice Support on NG-PON2 (OLT Part))
show voice ont sip-call statistics current-15min (SIP Voice Support on NG-PON2 (OLT Part))

show voice ont sip-config operational-data (SIP Voice Support on NG-PON2 (OLT Part))
show voice ont voip-config operational-data (SIP Voice Support on NG-PON2 (OLT Part))
show voice ont voip-pip-prof operational-data input-profile (SIP Voice Support on NG-PON2 (OLT Part))
show voice sip port-state (updated status information on POTS lines)
show voice sip pots port status (updated output to shows the port state of SIP terminations)
show voice sip statistics board cur-15min (updated output to show the SIP statistics)
show voice sip statistics board prev-15min (updated output to show the SIP statistics)
show voice sip statistics termination (update for PM counters at port level)
show xdsl operational-data line (new reporting of XDSL line initialization state)
tools perform cfm dual-tag mep domain association (Introduction of Maintenance Point on PON LTs : virtual UNI/Bridge port [segment B] on FGLT-B/FWLT-A)

New Commands

admin linetest single melt-reset (MELT improvements)
admin linetest single melt-selftest (MELT improvements)
admin system techsupport clear-on-demand session (on demand tech support file generation for datapath troubleshooting legacy Fiber LTs)
admin system techsupport gen-on-demand (on demand tech support file generation for datapath troubleshooting legacy Fiber LTs)
configure cmts mcast (DPoE Multicast Support)
configure cmts mcast dgsc (DPoE Multicast Support)
configure cmts mcast group-config (DPoE Multicast Support)
configure cmts mcast group-qos-config (DPoE Multicast Support)
configure cwmp plt (support NAPT and DHCP in redundant mode)
configure dhcp-server (support NAPT and DHCP in redundant mode)
configure nat (support NAPT and DHCP in redundant mode)
show alarm current ont-protection (support for Equipment Protection via Wavelength Mobility on NG-PON2)
show alarm log ont-protection (support for Equipment Protection via Wavelength Mobility on NG-PON2)
show alarm query ont-protection (support for Equipment Protection via Wavelength Mobility on NG-PON2)
show alarm snap-shot ont-protection (support for Equipment Protection via Wavelength Mobility on NG-PON2)
show cmts mcast gsf (DPoE Multicast Support (see the DPoE CLI guide))
show cmts mcast session (DPoE Multicast Support (see the DPoE CLI guide))
show cwmp (support NAPT and DHCP in redundant mode)
show cwmp plt (support NAPT and DHCP in redundant mode)
show linetest single hw-status (MELT improvements)
show linetest single melt-reset (MELT improvements)

show linetest single melt-selftest (MELT improvements)
show nat session (support NAPT and DHCP in redundant mode)
show system sync-if-timing-master (show the detailed information of current PTP master SyncE/SSM-QL Out)

Command delta R5.4 versus R5.3.01

Modified Commands
admin equipment slot (command tree display lined up with actual overrule parameter)
admin security ext-authenticator (support 802.1x on NGPON2 LT)
admin trouble-shooting interface (corrected command description clear-statistics)
admin trouble-shooting pbit interface (corrected command description clear-statistics)
admin trouble-shooting pon interface (corrected command description clear-statistics)
admin voice ont pots diagnostics (improvement for MLT diagnostics test result)
configure alarm entry (new alarms for CLI login failure alarm, Queue Load monitoring)
configure alarm filter filterid (update alarm list)
configure bridge port vlan-id (FELT-B VULA uplink Lightweight TPID support)
configure cfm domain association mep (support of AIS on ONT UNI (OLT part))
configure cm (DPoE command description moved from DPoE CLI command guide to this guide)
configure cmts bundle (New parameter to specify the default serving group in a bundle)
configure cmts l2vpn (update l2vpn CLI help/man info)
configure cmts pon (add support for Type 4 10G EPON optics module with turbo speed mode)
configure cmts pw-class name (updated MTU size range and default value)
configure cmts system (DHCP Lease Query support)
configure cmts vpls-class name (updated MTU size range and default value)
configure equipment diagnostics sfp (support for Next generation NT (FANT-G))
configure equipment rssiprof (support for Next generation NT (FANT-G))
configure equipment rssiprof (support for temperature alarm attributes in SFP RSSI profile)
configure equipment shelf (support no-extended-slots shelf mode)
configure qos interface (update RANT-A/SRNT-E-cac-profile)
configure qos tca queue (support Queue Load monitoring and TCA alarm)
configure system security pae authenticator (support 802.1x on NGPON2 LT)
configure system security pae ext-authenticator (support 802.1x on NGPON2 LT)
configure system security pae port (support 802.1x on NGPON2 LT)
configure system security ssh sftp-user (default parameters defined)
configure vlan id (DHCP/PPPoE made fully transparent when no add or replace options in tag)
configure xdsl board (support Legacy profile for optimized upstream vectoring)
configure xdsl line (support to force vectored lines in fallback mode)

configure xdsl vect-profile (support Legacy profile for optimized upstream vectoring)
show alarm current ont (renamed tod-out-sync to ont-gen-tod-out-sync to line up with config command)
show alarm current qos-queue (support Queue Load monitoring and TCA alarm)
show alarm log qos-queue (support Queue Load monitoring and TCA alarm)
show alarm query ihub-link (support for Next generation NT (FANT-G))
show alarm query ihub-tca (support for Next generation NT (FANT-G))
show alarm query name (new alarms added)
show alarm query qos-queue (support Queue Load monitoring and TCA alarm)
show cable modem (add support for Type 4 10G EPON optics module with turbo speed mode)
show dpoe onu (add support for Type 4 10G EPON optics module with turbo speed mode)
show equipment diagnostics sfp (support for Next generation NT (FANT-G))
show equipment diagnostics sfp-threshold (support for Next generation NT (FANT-G))
show equipment transceiver-inventory (support for Next generation NT (FANT-G))
show qos statistics buffer-overflow (support Queue Load monitoring and TCA alarm)
show qos statistics lt-cos (support Queue Load monitoring and TCA alarm)
show qos statistics queue (support Queue Load monitoring and TCA alarm)
show security pae mac-address (support 802.1x on NGPON2 LT)
show system license (add support for VULA)
show trouble-shooting statistics vlanport bridgeport-id (FELT-B VULA uplink Lightweight TPID support)
show xdsl profiles (support Legacy profile for optimized upstream vectoring)

New Commands

admin system techsupport (manage techsupport information (to determine Root Cause of Fiber LT Resets))
configure bridge port vlan-tpid0 (FELT-B VULA uplink Lightweight TPID support)
configure bridge port vlan-tpid1 (FELT-B VULA uplink Lightweight TPID support)
configure cfm domain association mep y1731ais (support of AIS on ONT UNI (OLT part))
configure ethernet ont cfm (support of AIS on ONT UNI (OLT part))
configure system scalingmode (support for Next generation NT (FANT-G))
configure vlan tpid (FELT-B VULA uplink Lightweight TPID support)
configure xdsl leg-upbo-profile (support Legacy profile for optimized upstream vectoring)
show cfm mep-y1731ais-info (support of AIS on ONT UNI (OLT part))
show cfm mep-y1731ais-info domain (support of AIS on ONT UNI (OLT part))
show system ipv6-prefix-mgmt (added cpu filter ipv6 cli hook)
show system scalingmode (support for Next generation NT (FANT-G))
show system techsupport (manage techsupport information (to determine Root Cause of Fiber LT Resets))

Commands or commands with parameters for future use, not supported yet

configure cfm domain association (parameter mhf-location not supported yet)
configure link-aggr group (new parameter value l2-l3-hybrid-model not supported yet)
configure qos profiles aggrqueuesconfig (restricted command for future use)
configure voice sip termination (new parameter telc-clip-mode not supported yet)
show alarm current eqpt-psu (restricted command for future use)
show alarm log eqpt-psu (restricted command for future use)
show alarm query eqpt-holder-ext (parameters water-seepage-in-box and sealed-box-open restricted use)
show alarm query eqpt-psu (restricted command for future use)
show alarm query ont-lan (new parameter ont-svc-enet-poos not supported yet)
show alarm query ont-pots (new parameter ont-svc-pots-poos not supported yet)
show alarm snap-shot eqpt-psu (restricted command for future use)
show equipment power-supply (restricted command for future use)
show qos profile-usage aggrqueuesconfig (restricted command for future use)

Command delta R5.3.01 versus R5.3

Modified Commands
admin efm-oam interface (EFM OAM remote loopback enhancement, support loopback timeout and parser action configuration)
configure alarm entry (new alarms for Home Gateway Unit (HGU), Alarm notification Failover/Failback, DHCP unreachable, low disk space and IEEE1588 hybrid fail)
configure alarm filter filterid (new alarms added in alarm filter command)
configure cfm domain association (CFM parameter bridge-port extended to support the NG-PON2 numbering scheme)
configure cfm domain association mep (CFM parameter location extended to support the NG-PON2 numbering scheme)
configure cmts (DPoE command description for configure cmts has been moved from the dedicated DPoE CLI command guide to this guide)
configure efm-oam interface (not supported parameters removed)
configure qos interface (support scheduler mode for GPON packets per service)
configure qos profiles shaper (traffic rate limiting per GEM port with CIR support)
configure system sync-if-timing ptp (support IEEE1588 hybrid mode)
configure system sync-if-timing tod-ref-order (support IEEE1588 hybrid mode)
configure vlan id (support actual line rate for DHCPv6)
configure voice cluster equipment termination (update command to enable the voice service per line)
configure xdsl board (vplt-autodiscovery option enable-both-lnk1-lnk2 is not supported yet)
configure xdsl line (support for VDSL2 g993-2-35b)
configure xdsl ont spectrum-profile vdsl2 (VDSL2 Custom PSD shape configuration over OMCI for G-010V-P and G-010V-Q)
configure xdsl spectrum-profile (support for VDSL2 g993-2-35b)

configure xdsl spectrum-profile vdsl (parameter values for VectNadnPlan : b998ade17ds30us35 b998e17ds30us35 b998ade17ds35 b998e17ds35 not supported yet)
configure xdsl spectrum-profile vdsl (removed unused parameter values b998ade17ds30us35 b998e17ds30us35)
configure xdsl vce-profile (parameter values for VectNadnPlan : b998ade17ds30us35 b998e17ds30us35 b998ade17ds35 b998e17ds35 not supported yet)
configure xdsl vce-profile (parameter vce-max-vect-freq not supported yet)
configure xdsl vce-profile (removed unused parameter values b998ade17ds30us35 b998e17ds30us35)
show alarm query mgt-sec-access (improved translation of alarm name of mgmt-sec-access)
show alarm query name (update to support new alarms)
show alarm query sw-mgmt (alarm added for low diskpace)
show efm-oam loopback-info (EFM OAM remote loopback enhancement to retrieve the remote loopback remaining timeout value.)
show system license (support for VDSL2 g993-2-35b)
show xdsl vect-group (support for VDSL2 g993-2-35b)

New Commands

configure alarm hgu-tr069-cust (configuration of Home Gateway Unit (HGU) customized alarms)
configure xdsl ont spectrum-profile vdsl2 cust-psd-pt-down (VDSL2 Custom PSD shape configuration over OMCI for G-010V-P and G-010V-Q)
configure xdsl ont spectrum-profile vdsl2 cust-psd-pt-up (VDSL2 Custom PSD shape configuration over OMCI for G-010V-P and G-010V-Q)
show alarm current hgu-tr069 (show alarms for Home Gateway Unit (HGU) customized)
show alarm current mdu-sup2 (new alarm for RSSI TCA function)
show alarm current ont-ani (new alarm for RSSI TCA function)
show alarm current sfu-sup2 (new alarm for RSSI TCA function)
show alarm current soho-sup2 (new alarm for RSSI TCA function)
show alarm log hgu-tr069 (show alarms for Home Gateway Unit (HGU) customized)
show alarm log mdu-sup2 (new alarm for RSSI TCA function)
show alarm log ont-ani (new alarm for RSSI TCA function)
show alarm log sfu-sup2 (new alarm for RSSI TCA function)
show alarm log soho-sup2 (new alarm for RSSI TCA function)
show alarm query hgu-tr069 (show alarms for Home Gateway Unit (HGU) customized)
show alarm snap-shot hgu-tr069 (show alarms for Home Gateway Unit (HGU) customized)
show alarm snap-shot mdu-sup2 (new alarm for RSSI TCA function)
show alarm snap-shot ont-ani (new alarm for RSSI TCA function)
show alarm snap-shot sfu-sup2 (new alarm for RSSI TCA function)
show alarm snap-shot soho-sup2 (new alarm for RSSI TCA function)

Commands or commands with parameters for future use, not supported yet

configure xdsl ont rtx-profile (VDSL2 parameter configuration and reporting over OMCI not supported yet)
configure xdsl ont line (VDSL2 parameter configuration and reporting over OMCI not supported yet)
show xdsl ont operational-data near-end line (VDSL2 parameter configuration and reporting over OMCI not supported yet)
show xdsl ont operational-data far-end line (VDSL2 parameter configuration and reporting over OMCI not supported yet)

Removed Commands

configure ai (removal of not supported commands for application intelligence)

Command delta R5.3 versus R5.2.01

Modified Commands

admin trouble-shooting interface (Business/Pre-Aggregation P2P LT variant (FELT-B) - Application limited to VULA uplink)
configure alarm entry (new alarms for HGU configuration, NGPON2 CMAC Loss of OMCI channel, channelpair and CF error)
configure alarm filter filterid (new alarms added)
configure bridge port (removed invalid values 4092 and 4096 from available range of vlanIds)
configure bridge port vlan-id (Business/Pre-Aggregation P2P LT variant (FELT-B) - Application limited to VULA uplink)
configure cfm domain association (removed invalid values 4092 and 4096 from available range of vlanIds)
configure cmts l2vpn (no option is not applicable for l2vpn and removed)
configure equipment diagnostics (no option is not applicable for diagnostics and removed)
configure equipment sfpe1t1 (no option is not applicable for sfpe1t1 and removed)
configure equipment slot (support text based dump and restore)
configure ethernet line (Business/Pre-Aggregation P2P LT variant (FELT-B) - Application limited to VULA uplink)
configure ethernet line mau (Business/Pre-Aggregation P2P LT variant (FELT-B) - Application limited to VULA uplink)
configure ethernet line tca-line-threshold (Business/Pre-Aggregation P2P LT variant (FELT-B) - Application limited to VULA uplink)
configure ipoa/e-iw gateway (removed invalid values 4092 and 4096 from available range of vlanIds)
configure linetest cluster ltsession (parameter value force-ring-subscrib not supported yet)
configure linetest single ltsession (parameter value force-ring-subscrib not supported yet)
configure pon (Allow GPON ONUs to range in the presence of Alien ONUs)
configure ppox-relay cross-connect client-port (removed invalid values 4092 and 4096 from available range of vlanIds)
configure ppox-relay cross-connect engine (removed invalid values 4092 and 4096 from available range of vlanIds)

configure qos (DEI support on NELT-B for color aware queuing and policing)
configure qos interface (Business/Pre-Aggregation P2P LT variant (FELT-B) - Application limited to VULA uplink)
configure qos profiles ingress-qos (Business/Pre-Aggregation P2P LT variant (FELT-B) - Application limited to VULA uplink)
configure qos profiles policer (Business/Pre-Aggregation P2P LT variant (FELT-B) - Application limited to VULA uplink)
configure qos profiles session (Business/Pre-Aggregation P2P LT variant (FELT-B) - Application limited to VULA uplink)
configure qos tca queue (Business/Pre-Aggregation P2P LT variant (FELT-B) - Application limited to VULA uplink)
configure system security default-profile (restrict access rights for AI config commands)
configure system security filetransfer server (support text based dump and restore of Core 0)
configure system security operator (request to verify Current Password before accepting the change password for existing operators)
configure system security profile (restrict access rights for AI config commands)
configure system security radius acc-server (support text based dump and restore of Core 0)
configure system security radius auth-server (support text based dump and restore of Core 0)
configure system security radius dyn-auth-client (support text based dump and restore of Core 0)
configure system security snmp community (add docsis to SNMP context)
configure system security snmp group (add docsis to SNMP context)
configure system security ssh sftp-user (support text based dump and restore of Core 0)
configure system security tacacs acc-server (support text based dump and restore of Core 0)
configure system security tacacs authen-server (support text based dump and restore of Core 0)
configure system security tacacs author-server (support text based dump and restore of Core 0)
configure trouble-shooting statistics interface (Business/Pre-Aggregation P2P LT variant (FELT-B) - Application limited to VULA uplink)
configure vlan id (removed invalid values 4092 and 4096 from available range of vlanIds)
configure vlan unicast-mac (removed invalid values 4092 and 4096 from available range of vlanIds)
configure voice cluster equipment board planned-type (support nvps-c Voice Megaco Equipment Board)
configure voice cluster equipment termination (support enabling H.248 DSL voice service configuration per line)
configure voice cluster ip (porting MDU DHCP for 7363 ISAM MX and 7367 ISAM SX)
configure voice cluster media-gateway (porting MDU DHCP for 7363 ISAM MX and 7367 ISAM SX)
configure voice cluster signal-gateway (ISAMV H.248 obsolete no option removed for Prim/sec/tert/quat ASP IP)
configure voice sip register register-uri (extend the multiple VAG up to 16 VAG on 7363 MX-6/7302 ISAM-V)
configure voice sip transport provider-name udp admin-status (extend the multiple VAG up to 16 VAG on 7363 MX-6/7302 ISAM-V)
configure voice sip user-agent (extend the multiple VAG up to 16 VAG on 7363 MX-6/7302 ISAM-V)

configure voice sip user-agent-ap (extend the multiple VAG up to 16 VAG on 7363 MX-6/7302 ISAM-V)
configure voice sip vsp admin-status (extend the multiple VAG up to 16 VAG on 7363 MX-6/7302 ISAM-V)
configure voice sip vsp domain-name (extend the multiple VAG up to 16 VAG on 7363 MX-6/7302 ISAM-V)
configure xdsl board vect-fallback (support SOS for VDSL2 on vectoring boards)
configure xdsl line (support SOS for VDSL2 on vectoring boards)
configure xdsl service-profile (support SOS for VDSL2 on vectoring boards)
show vlan dup-mac-alarm (removed invalid values 4092 and 4096 from available range of vlanIds)
show vlan fdb-board (removed invalid values 4092 and 4096 from available range of vlanIds)
show equipment ont utilization current-interval (completion of PON Utilization and Threshold for FWLT-A)
show equipment ont utilization previous-interval (completion of PON Utilization and Threshold for FWLT-A)
show mcast pon-active-groups (completion of PON Utilization and Threshold for FWLT-A)
show pon optics (completion of PON Utilization and Threshold for FWLT-A)
show pon pon-diagnostics (completion of PON Utilization and Threshold for FWLT-A)
show qos interface-bandwidth (Business/Pre-Aggregation P2P LT variant (FELT-B) - Application limited to VULA uplink)
show qos statistics queue current-15min (Business/Pre-Aggregation P2P LT variant (FELT-B) - Application limited to VULA uplink)
show qos statistics queue prev-15min (Business/Pre-Aggregation P2P LT variant (FELT-B) - Application limited to VULA uplink)
show system license (add G.FAST and vdsl2-35b-mode licenses)
show xdsl counters far-end line current-interval/current-1day (support SOS for VDSL2 on vectoring boards)
show xdsl counters far-end line previous-interval/previous-1day (support SOS for VDSL2 on vectoring boards)
show xdsl counters near-end line current-interval/current-1day (support SOS for VDSL2 on vectoring boards)
show xdsl counters near-end line previous-interval/previous-1day (support SOS for VDSL2 on vectoring boards)
show xdsl operational-data far-end line (support SOS for VDSL2 on vectoring boards)
show xdsl operational-data near-end line (support SOS for VDSL2 on vectoring boards)
show xdsl profiles (support SOS for VDSL2 on vectoring boards)

New Commands

admin channel-pair utilization (completion of PON Utilization and Threshold for FWLT-A)
admin config-file (support text based dump and restore of Core 0)
admin config-file activate (support text based dump and restore of Core 0)
admin config-file delete (support text based dump and restore of Core 0)

admin config-file download (support text based dump and restore of Core 0)
admin config-file rename (support text based dump and restore of Core 0)
admin config-file save (support text based dump and restore of Core 0)
admin config-file upload (support text based dump and restore of Core 0)
configure channel-pair interface utilization (completion of PON Utilization and Threshold for FWLT-A)
configure channel-pair interface utilization threshold (completion of PON Utilization and Threshold for FWLT-A)
configure cmts ipdr (add IPDR for measurement of traffic data of users)
configure cmts ipdr-global (add IPDR for measurement of traffic data of users)
configure qos profiles cos-threshold (Business/Pre-Aggregation P2P LT variant (FELT-B) - Application limited to VULA uplink)
configure qos upstr-prot-dsl (enabling QoS handling of upstream protocol for DSL LTs)
configure xdsl sos-profile (support SOS for VDSL2 on vectoring boards)
show alarm current olt-chpr-util-tca (completion of PON Utilization and Threshold for FWLT-A)
show alarm log olt-chpr-util-tca (completion of PON Utilization and Threshold for FWLT-A)
show alarm query (new command tree to add coverage of active alarms information)
show alarm snap-shot olt-chpr-util-tca (completion of PON Utilization and Threshold for FWLT-A)
show channel-pair utilization (completion of PON Utilization and Threshold for FWLT-A)
show channel-pair utilization cur-intvl-top-ont-rx (completion of PON Utilization and Threshold for FWLT-A)
show channel-pair utilization cur-intvl-top-ont-tx (completion of PON Utilization and Threshold for FWLT-A)
show channel-pair utilization current-interval (completion of PON Utilization and Threshold for FWLT-A)
show channel-pair utilization previous-interval (completion of PON Utilization and Threshold for FWLT-A)
show channel-pair utilization prv-intvl-top-ont-rx (completion of PON Utilization and Threshold for FWLT-A)
show channel-pair utilization prv-intvl-top-ont-tx (completion of PON Utilization and Threshold for FWLT-A)
show config-file (support text based dump and restore of Core 0)
show equipment ont software-download (new command to get software-download status of ng2 ONTs per channel-group and subchannel-group basis)
show equipment ont software-download channel-group (new command to get software-download status of ng2 ONTs per channel-group and subchannel-group basis)
show qos bandwidth-profile (new command to report actual QoS bandwidth profile values)
show qos profile-usage cos-threshold (Business/Pre-Aggregation P2P LT variant (FELT-B) - Application limited to VULA uplink)
tee-config (support text based dump and restore of Core 0)

Commands or commands with parameters for future use, not supported yet

configure cfm domain association mep (new parameter equipment not supported yet)

configure linetest cluster ltparm test-name (parameter value bat-imped-discard replaced by force-ring-subscrib)
configure linetest single ltparm test-name (parameter value bat-imped-discard replaced by force-ring-subscrib)
configure system external-leds (command to configure and store system leds status)
configure xdsl board (vpllt-autodiscovery option enable-both-lnk1-lnk2 is not supported yet)
configure xdsl line (parameter g993-2-35b not supported yet)
configure xdsl spectrum-profile (parameter g993-2-35b not supported yet)
configure xdsl spectrum-profile vdsl (parameter values for VectNadnPlan : b998ade17ds30us35 b998e17ds30us35 b998ade17ds35 b998e17ds35 not supported yet)
configure xdsl vce-profile (parameter values for VectNadnPlan : b998ade17ds30us35 b998e17ds30us35 b998ade17ds35 b998e17ds35 not supported yet)
configure xdsl vce-profile (parameter vce-max-vect-freq not supported yet)
show cfm stack (new parameter equipment not supported yet)
show linetest cluster lineid-ext-rept (not used parameter renamed for later use)
show linetest single lineid-ext-rept (not used parameter renamed for later use)
show system license (parameter value vplus not supported)
show xdsl vect-group (extend show vect-group with own2 entry)

Command delta R5.2.01 versus R5.2

Modified Commands
configure alarm entry (add GPON CFM alarm to report ais on CFI interface)
configure alarm entry (support GNSS ToD, SSM-QL from GPON-LT to ONU)
configure alarm filter filterid (add GPON CFM alarm to report ais on CFI interface)
configure alarm filter filterid (support GNSS ToD, SSM-QL from GPON-LT to ONU)
configure cfm domain association (ETH CFM Configurable LTM messages forwarding)
configure cfm domain association (support dual tagged CFM messages when configured for C-VLAN CC)
configure cmts system (enable system switch to turn on/off RIP snooping and change RIP timeout)
configure interface port (IF-MIB counters for POTS (SIP controlled) line interfaces)
configure linetest single ltparm test-name (configure whether termination ringer is detected)
configure linetest single ltssession (updating line test parameters for zener, adding iltf-term-ringer and collective test for NBLT)
configure qos profiles session (OLT configuration for ONT policer)
configure system loop-id-syntax (support S-VLAN in PPPoE and DHCP tag for S+C CC)
configure system security (TACACS+ Operator CLI phase 2 : authentication and authorization)
configure system security operator (option %i added to the prompt configuration to show the system id in the operator prompt)
configure system security pmfile upload (obsolete parameters upload-username and upload-password)

removed)
configure system security profile (option %i added to the prompt configuration to show the system id in the operator profile prompt)
configure system security snmp user (strong encryption for SNMPv3)
configure system security ssh user (range of ssh user key extended from 725 to 1200)
configure system security tacacs (TACACS+ Operator CLI phase 2 : authentication and authorization)
configure system security tacacs policy servers (TACACS+ Operator CLI phase 2 : authentication and authorization)
configure system sync-if-timing ptp default-dataset (support two source type GNSS ToD, SSM-QL from GPON-LT to ONU)
configure system sync-if-timing ptp slave-port-dataset (support ToD configurable time delay compensation)
configure system sync-if-timing ssmout-ltport ssmout-enable (support GNSS ToD, SSM-QL from GPON-LT to ONU)
configure system sync-if-timing tod (support GNSS ToD, SSM-QL from GPON-LT to ONU)
configure system sync-if-timing tod (support ToD configurable leap second handling)
configure system sync-if-timing tod-ref-order (support two source type GNSS ToD, SSM-QL from GPON-LT to ONU)
configure voice sip termination (enlarge accessontimeout maximum value to 900 sec. Change default value to 900 sec.)
configure xdsl spectrum-profile vdsl pbo (updated behaviour of default parametervalue for param-a and param-b, no option removed)
configure xdsl spectrum-profile vdsl2 pbo (updated behaviour of default parametervalue for param-a and param-b, no option removed)
environment prompt (option %i added to the description of the prompt configuration to show the system id in the session prompt)
show cfm ma-config-data domain association (ETH CFM Configurable LTM messages forwarding)
show cfm ma-config-data domain association (support dual tagged CFM messages when configured for C-VLAN CC)
show equipment ont ranging-status channel-group (fix to display ONTs with index larger than 128)
show interface availability (IF-MIB counters for POTS (SIP controlled) line interfaces)
show interface port (IF-MIB counters for POTS (SIP controlled) line interfaces)
show interface stack (IF-MIB counters for POTS (SIP controlled) line interfaces)
show interface test (IF-MIB counters for POTS (SIP controlled) line interfaces)
show linetest single lineid-ext-rept (add linetest to show whether termination ringer is detected)

New Commands

configure alias (DPoE command to create, modify, remove and retrieve alias CLI)
configure qos profiles policer-per-tc (OLT configuration for ONT policer)
configure qos profiles policer-per-tc tc-policer (OLT configuration for ONT policer)
configure system security tacacs authen-server router-instance (TACACS+ Operator CLI phase 2 : authentication and authorization)

configure system security tacacs author-server router-instance (TACACS+ Operator CLI phase 2 : authentication and authorization)
show qos profile-usage policer-per-tc (OLT configuration for ONT policer)
show security tacacs (TACACS+ Operator CLI phase 2 : authentication and authorization)
show security tacacs acc-server (TACACS+ Operator CLI phase 2 : authentication and authorization)
show security tacacs acc-server state (TACACS+ Operator CLI phase 2 : authentication and authorization)
show security tacacs acc-server statistics (TACACS+ Operator CLI phase 2 : authentication and authorization)
show security tacacs authen-server (TACACS+ Operator CLI phase 2 : authentication and authorization)
show security tacacs authen-server state (TACACS+ Operator CLI phase 2 : authentication and authorization)
show security tacacs authen-server statistics (TACACS+ Operator CLI phase 2 : authentication and authorization)
show security tacacs author-server (TACACS+ Operator CLI phase 2 : authentication and authorization)
show security tacacs author-server state (TACACS+ Operator CLI phase 2 : authentication and authorization)
show security tacacs author-server statistics (TACACS+ Operator CLI phase 2 : authentication and authorization)
show voice sip port-state (SIP (CVP) : support call states in compliance with 163TR26)

Commands or commands with parameters for future use, not supported yet

configure ethernet line (parameter uplink not supported yet)
configure ethernet line mau (parameter value 10gbasesr not supported yet)
configure qos interface (parameter value ltuplink not supported yet)
configure qos profiles cos-threshold (parameter cos-threshold not supported yet)
configure qos profiles ingress-qos (parameters PolTCMask_0-7 not supported yet)
configure qos profiles policer (parameter cos-threshold, peak-info-rate peak-burst-size not supported yet)
configure qos profiles session (parameter ing-outer-marker outer-marking not supported yet)
configure qos tca queue (parameter value ltuplink not supported yet)
configure xdsl board (vplt-autodiscovery option enable-both-lnk1-lnk2 is not supported yet)
configure xdsl line (parameter g993-2-35b not supported yet)
configure xdsl spectrum-profile (parameter g993-2-35b not supported yet)
configure xdsl spectrum-profile vdsl (parameter values for VectNadnPlan : b998ade17ds30us35 b998e17ds30us35 b998ade17ds35 b998e17ds35 not supported yet)
configure xdsl vce-profile (parameter values for VectNadnPlan : b998ade17ds30us35 b998e17ds30us35 b998ade17ds35 b998e17ds35 not supported yet)
configure xdsl vce-profile (parameter vce-max-vect-freq not supported yet)
show qos interface-bandwidth (parameter value ltuplink not supported yet)
show qos profile-usage cos-threshold (parameter cos-threshold not supported yet)
show qos statistics queue current-15min (parameter value ltuplink not supported yet)

show qos statistics queue prev-15min (parameter value ltuplink not supported yet)
show system license (parameter value vplus not supported)
show xdsl vect-group (extend show vect-group with own2 entry)

Command delta R5.2 versus R5.1.01

Modified Commands
admin arp-relay-stats (NG-PON2 support, ARP/PPPoE/VLAN GPON 2 parameter types merged into common interface type)
admin bridge learned-unicast-mac unicast-mac-address (NG-PON2 support)
admin ces ont line (NG-PON2 support)
admin dhcp-relay port-stats (NG-PON2 support)
admin dhcp-relay v6-port-stats (NG-PON2 support)
admin equipment ont data-store (NG-PON2 support)
admin equipment ont interface (NG-PON2 support)
admin equipment ont slot (NG-PON2 support)
admin igmp channel (NG-PON2 support)
admin ont-xdsl-line (NG-PON2 support)
admin pon diagnostic (Detection of ALIEN ONU on GPON)
admin pppoe-client emulation client-id (NG-PON2 support)
admin pppoel2-stats (NG-PON2 support)
admin trouble-shooting interface (NG-PON2 support)
admin trouble-shooting pbit interface (NG-PON2 support)
configure alarm entry (automatic port reset)
configure alarm entry (updating alarm list for PON, OMCI preconfiguration, alien ONU detection. PON utilization, SLID identification, NG-PON2)
configure alarm filter (automatic port reset)
configure alarm filter filterid (updating alarm list for PON, OMCI preconfiguration, alien ONU detection. PON utilization, SLID identification, NG-PON2)
configure ani ont tca-thresh (NG-PON2 support)
configure ani ont video (NG-PON2 support)
configure arp-relay statistics (NG-PON2 support, ARP/PPPoE/VLAN GPON 2 parameter types merged into common interface type)
configure bridge port (NG-PON2 support)
configure bridge port vlan-id (control protocol awareness per C-VLAN range for S-VLAN cross-connect to MS)
configure ces ont line (NG-PON2 support)
configure cfm domain association (NG-PON2 support)
configure cfm domain association mep (support of AIS on ONT UNI (OLT part))

configure cmt cm-static (modified support for DHCP, DHCP Relay not supported any more on DPOE)
configure cmts bundle (modified support for DHCP, DHCP Relay not supported any more on DPOE)
configure cmts diag (not allowed 'no' option removed from command)
configure cmts log-level (not allowed 'no' option removed from command)
configure cmts subscriber-def (not allowed 'no' option removed from command)
configure dhcp-relay port-stats (NG-PON2 support)
configure dhcp-relay v6-port-stats (NG-PON2 support)
configure equipment diagnostics sfp ('no sfp' command removed)
configure equipment ont interface (CPE/ONT Configuration over OMCI)
configure equipment ont loop (NG-PON2 support)
configure equipment ont slot (NG-PON2 support)
configure equipment ont slot (parameter types merged into common interface type)
configure equipment ont sw-ctrl (CPE/ONT Configuration over OMCI)
configure equipment rssiprof (RSSI support on NT ports in FD)
configure equipment shelf (remove the obsolete unlock parameter)
configure ethernet ont (NG-PON2 support)
configure hpna ont (NG-PON2 support)
configure igmp channel (NG-PON2 support)
configure interface alarm (NG-PON2 support)
configure interface port (NG-PON2 support)
configure l2uni ont performance-monitor (NG-PON2 support)
configure l2uni ont tc-layer-threshold (NG-PON2 support)
configure linetest single ltparm test-name (corrected unit for ringer test)
configure mcast static branch src-ip-addr (NG-PON2 support)
configure moca ont (NG-PON2 support)
configure ntp ont (NG-PON2 support)
configure pon interface (implementation of PON ID Maintenance feature per G.984.3 Amd 3 Annex C)
configure pon pwrbrst-mode (restructure pon command tree)
configure pppoe-client interface client-id (NG-PON2 support)
configure pppoe2 statistics (NG-PON2 support)
configure qos interface (NG-PON2 support)
configure qos profiles cac (restructure pon command tree)
configure qos tca queue (NG-PON2 support)
configure system loop-id-syntax (add new NG-PON2 system loop id)
configure system pon-ont (selective behavior for ONT Service Continuity Relative to SW Planning)
configure system security (move oper-policy-prio to security node)
configure system security ssh access (fix to close specific ports)

configure trouble-shooting pbit statistics interface (NG-PON2 support)
configure trouble-shooting statistics interface (NG-PON2 support)
configure uni ont tc-layer (NG-PON2 support)
configure uni ont video (NG-PON2 support)
configure veip ont (NG-PON2 support)
configure vlan pbit-statistics port min-dot1p (NG-PON2 support)
configure vlan port-protocol protocol-group (NG-PON2 support)
configure vlan unicast-mac vlan-id (NG-PON2 support)
configure vlan vlan-port unicast-mac (NG-PON2 support)
configure voice sip dialplan (updates for SIP (CVP) Multiple Voice Access Gateway, support multiple providers)
configure voice sip redundancy (updates for SIP (CVP) Multiple Voice Access Gateway, support multiple providers)
configure voice sip register (updates for SIP (CVP) Multiple Voice Access Gateway, support multiple providers)
configure voice sip server (updates for SIP (CVP) Multiple Voice Access Gateway, support multiple providers)
configure voice sip termination (updates for SIP (CVP) Multiple Voice Access Gateway, support multiple providers and End_User controlled act/deact of Call Waiting)
configure voice sip transport (updates for SIP (CVP) Multiple Voice Access Gateway, support multiple providers)
configure voice sip user-agent (updates for SIP (CVP) Multiple Voice Access Gateway, support multiple providers)
configure voice sip vsp domain-name (updates for SIP (CVP) Multiple Voice Access Gateway, support multiple providers)
configure xdsl ont interface (NG-PON2 support)
configure xdsl ont line (NG-PON2 support)
configure xdsl vce-profile (vectoring init time improvements : historical P-coder)
show alarm current table (CPE/ONT Configuration over OMCI)
show alarm current xdsl-tca (automatic port reset)
show alarm delta-log (CPE/ONT Configuration over OMCI)
show alarm log table (CPE/ONT Configuration over OMCI)
show alarm log xdsl-tca (automatic port reset)
show alarm snap-shot xdsl-tca tca (automatic port reset)
show alarm snapshot table (CPE/ONT Configuration over OMCI)
show ani ont operational-data (NG-PON2 support)
show ani ont video (NG-PON2 support)
show ani ont video-stats (NG-PON2 support)
show arp-relay-stats (NG-PON2 support, ARP/PPPoE/VLAN GPON 2 parameter types merged into common interface type)
show ces ont line port current-interval (NG-PON2 support)

show ces ont line port previous-interval (NG-PON2 support)
show cfm stack (NG-PON2 support)
show config-data-port bridge-port (corrected CLI tree display)
show config-data-port igmp (NG-PON2 support)
show config-data-port igmp (corrected CLI tree display)
show config-data-port interface-port (corrected CLI tree display)
show config-data-port qos (corrected CLI tree display)
show config-data-port security-pae (corrected CLI tree display)
show dhcp-relay port-stats (NG-PON2 support)
show dhcp-relay session (NG-PON2 support)
show dhcp-relay v6-port-stats (NG-PON2 support)
show equipment ont data-store (NG-PON2 support)
show equipment ont ethernet current-interval (NG-PON2 support)
show equipment ont ethernet previous-interval (NG-PON2 support)
show equipment ont ethernet total (NG-PON2 support)
show equipment ont fec-tc-layer olt-side current-interval (NG-PON2 support)
show equipment ont fec-tc-layer ont-side current-interval (NG-PON2 support)
show equipment ont interface (CPE/ONT Configuration over OMCI)
show equipment ont interface (NG-PON2 support)
show equipment ont mcast-tc-layer ont-side current-interval (NG-PON2 support)
show equipment ont mcast-tc-layer ont-side previous-interval (NG-PON2 support)
show equipment ont operational-data (NG-PON2 support)
show equipment ont optics (NG-PON2 support)
show equipment ont optics-history (NG-PON2 support)
show equipment ont phy-layer olt-side current-interval (NG-PON2 support)
show equipment ont pwr-shed (NG-PON2 support)
show equipment ont slot (NG-PON2 support)
show equipment ont sw-download (CPE/ONT Configuration over OMCI)
show equipment ont sw-download (NG-PON2 support)
show equipment ont tc-layer olt-side current-interval (NG-PON2 support)
show equipment ont tc-layer olt-side previous-interval (NG-PON2 support)
show equipment ont tc-layer olt-side-on-demand current-interval (NG-PON2 support)
show equipment ont tc-layer olt-side-on-demand previous-interval (NG-PON2 support)
show equipment ont tc-layer ont-side current-interval (NG-PON2 support)
show equipment ont tc-layer ont-side previous-interval (NG-PON2 support)
show equipment ont xg-tc-layer olt-side current-interval (NG-PON2 support)
show equipment ont xg-tc-layer olt-side previous-interval (NG-PON2 support)

show equipment ont xg-tc-layer ont-side current-interval (NG-PON2 support)
show equipment ont xg-tc-layer ont-side previous-interval (NG-PON2 support)
show ethernet ont operational-data (NG-PON2 support)
show ethernet ont port current-interval (NG-PON2 support)
show ethernet ont port previous-interval (NG-PON2 support)
show hpna ont performance-data current-interval (NG-PON2 support)
show hpna ont performance-data previous-interval (NG-PON2 support)
show igmp channel counter (NG-PON2 support)
show igmp channel miscellaneous (NG-PON2 support)
show igmp channel protocol (NG-PON2 support)
show interface alarm (NG-PON2 support)
show interface port (NG-PON2 support)
show interface stack (NG-PON2 support)
show interface test (NG-PON2 support)
show ipv6 users (NG-PON2 support)
show l2uni ont performance-data current-interval (NG-PON2 support)
show l2uni ont performance-data previous-interval (NG-PON2 support)
show linetest cluster lineid-ext-rept (corrected unit for ringer test)
show mcast active-groups (NG-PON2 support)
show mcast grp-membership (NG-PON2 support)
show mcast ont-active-groups (NG-PON2 support)
show mcast pon-active-groups (NG-PON2 support)
show moca ont operational-data (NG-PON2 support)
show moca ont performance-data current-interval (NG-PON2 support)
show moca ont performance-data previous-interval (NG-PON2 support)
show oper-data-port bridge-port (corrected CLI tree display)
show oper-data-port ethernet (corrected CLI tree display)
show oper-data-port igmp (NG-PON2 support)
show oper-data-port igmp (corrected CLI tree display)
show oper-data-port interface-port (corrected CLI tree display)
show oper-data-port ip-bridge-port (corrected CLI tree display)
show oper-data-port qos (corrected CLI tree display)
show pon diagnostic (Detection of ALIEN ONU on GPON)
show pppoe-client emulation (NG-PON2 support)
show pppoe-client session (NG-PON2 support)
show pppoel2-stats (NG-PON2 support)
show qos interface-bandwidth (NG-PON2 support)

show qos statistics queue current-15min (NG-PON2 support)
show qos statistics queue prev-15min (NG-PON2 support)
show security pae diagnostic (eap-logoff-cnt display updated)
show system cde-bitmap (displays the activated CDE Capabilities (256 bits))
show trouble-shooting pbit statistics interface (NG-PON2 support)
show trouble-shooting statistics interface (NG-PON2 support)
show trouble-shooting statistics uni-interface (NG-PON2 support)
show uni ont tc-layer olt-side current-interval (NG-PON2 support)
show uni ont tc-layer olt-side previous-interval (NG-PON2 support)
show uni ont tc-layer ont-side current-interval (NG-PON2 support)
show uni ont tc-layer ont-side previous-interval (NG-PON2 support)
show vlan bridge-port-fdb (NG-PON2 support)
show vlan cross-connect (NG-PON2 support)
show vlan current-15min-stats (NG-PON2 support)
show vlan current-day-stats (NG-PON2 support)
show vlan dup-mac-alarm (NG-PON2 support)
show vlan pbit-statistics port (NG-PON2 support)
show vlan port-15min-stats (NG-PON2 support)
show vlan port-accumu-stats (NG-PON2 support)
show vlan port-curr-15min-stats (NG-PON2 support)
show vlan port-curr-day-stats (NG-PON2 support)
show vlan port-event (NG-PON2 support)
show vlan port-prev-day-stats (NG-PON2 support)
show vlan previous-15min-stats (NG-PON2 support)
show vlan residential-bridge extensive (NG-PON2 support)
show vlan residential-bridge summary (NG-PON2 support)
show vlan vlan-day-stats (NG-PON2 support)
show vlan vmac-bridge-port-fdb (NG-PON2 support)
show voice cluster signal-gateway (show IP address and port info when showing list of MGC/ASP)
show voice ont pots-call statistics prev-15min (NG-PON2 support)
show voice ont pots-rtp statistics prev-15min (NG-PON2 support)
show voice sip redundancy-node (updates for SIP (CVP) Multiple Voice Access Gateway, support multiple providers)
show xdsl config-data-port atm-pvc (corrected CLI tree display)
show xdsl config-data-port bonding-group (corrected CLI tree display)
show xdsl config-data-port bridge-port (corrected CLI tree display)
show xdsl config-data-port igmp (corrected CLI tree display)
show xdsl config-data-port interface-atm-pvc (corrected CLI tree display)

show xdsl config-data-port interface-port (corrected CLI tree display)
show xdsl config-data-port pppox-relay (corrected CLI tree display)
show xdsl config-data-port qos (corrected CLI tree display)
show xdsl config-data-port security-pae (corrected CLI tree display)
show xdsl config-data-port xdsl (corrected CLI tree display)
show xdsl ont carrier-data far-end (NG-PON2 support)
show xdsl ont carrier-data near-end (NG-PON2 support)
show xdsl ont counters far-end channel current-interval (support of G.997.1 Line PM counter LOS Second, NG-PON2 support)
show xdsl ont counters far-end channel previous-interval (support of G.997.1 Line PM counter LOS Second, NG-PON2 support)
show xdsl ont counters far-end line current-interval (support of G.997.1 Line PM counter LOS Second, NG-PON2 support)
show xdsl ont counters far-end line previous-interval (support of G.997.1 Line PM counter LOS Second, NG-PON2 support)
show xdsl ont counters near-end channel current-interval (support of G.997.1 Line PM counter LOS Second, NG-PON2 support)
show xdsl ont counters near-end channel previous-interval (support of G.997.1 Line PM counter LOS Second, NG-PON2 support)
show xdsl ont counters near-end line current-interval (support of G.997.1 Line PM counter LOS Second, NG-PON2 support)
show xdsl ont counters near-end line previous-interval (support of G.997.1 Line PM counter LOS Second, NG-PON2 support)
show xdsl ont cpe-tuc-inventory (NG-PON2 support)
show xdsl ont cpe-tur-inventory (NG-PON2 support)
show xdsl ont failure-status far-end (NG-PON2 support)
show xdsl ont failure-status near-end (NG-PON2 support)
show xdsl ont operational-data far-end channel (NG-PON2 support)
show xdsl ont operational-data far-end line (NG-PON2 support)
show xdsl ont operational-data near-end channel (NG-PON2 support)
show xdsl ont operational-data near-end line (NG-PON2 support)
show xdsl ont xdsl-int (NG-PON2 support)
show xdsl oper-data-port atm-pvc (corrected CLI tree display)
show xdsl oper-data-port bridge-port (corrected CLI tree display)
show xdsl oper-data-port igmp (NG-PON2 support)
show xdsl oper-data-port igmp (corrected CLI tree display)
show xdsl oper-data-port interface-port (corrected CLI tree display)
show xdsl oper-data-port ip-bridge-port (corrected CLI tree display)
show xdsl oper-data-port qos (corrected CLI tree display)
show xdsl oper-data-port xdsl (corrected CLI tree display)

show xdsl operational-data line (automatic port reset)
--

New Commands

admin channel-pair (NG-PON2 support)
admin channel-pair diagnostic (NG-PON2 support)
admin pon utilization (manage PON Utilization and Threshold)
admin software-mnngt config-file (text based full system configuration dump in DPoE scope)
configure channel-group (NG-PON2 support)
configure channel-group id (NG-PON2 support)
configure channel-group id no channel-pair ()
configure channel-group id subchannel-group (NG-PON2 support)
configure channel-group id subchannel-group id (NG-PON2 support)
configure channel-group id subchannel-group id channel-pair (NG-PON2 support)
configure channel-pair (NG-PON2 support)
configure channel-pair interface (NG-PON2 support)
configure channel-pair interface fec-tc-layer (NG-PON2 support)
configure channel-pair interface mcast-tc-layer (NG-PON2 support)
configure channel-pair interface phy-layer (NG-PON2 support)
configure channel-pair interface tc-layer (NG-PON2 support)
configure channel-pair interface tc-layer-threshold (NG-PON2 support)
configure channel-pair interface troubleshooting (NG-PON2 support)
configure channel-pair interface troubleshooting threshold (NG-PON2 support)
configure channel-pair interface xg-tc-layer (NG-PON2 support)
configure channel-pair profiles (NG-PON2 support)
configure channel-pair profiles wavelength-prof (NG-PON2 support)
configure channel-pair troubleshooting (NG-PON2 support)
configure cm ipv6-classif-pf (static command support for icmpv4/v6 classifier)
configure generic-pon (manage PON Utilization and Threshold)
configure generic-pon ont slid-mode (restructure pon command tree)
configure generic-pon power-shed-prof profile-name (restructure pon command tree)
configure generic-pon utilization (manage PON Utilization and Threshold)
configure generic-pon utilization threshold (manage PON Utilization and Threshold)
configure pon interface utilization (manage PON Utilization and Threshold)
configure pon interface utilization threshold (manage PON Utilization and Threshold)
configure system security tacacs (implementation of TACACS+)
configure system security tacacs acc-server router-instance (implementation of TACACS+)
configure system security tacacs policy (implementation of TACACS+)
configure system security tacacs policy servers (implementation of TACACS+)

configure xdsl board auto-port-reset (automatic port reset)
configure xdsl system (automatic port reset)
configure xdsl system auto-port-reset (automatic port reset)
show alarm current channel-pair (NG-PON2 support)
show alarm current olt-chpair-tc-tca (manage PON Utilization and Threshold)
show alarm current olt-pon-util-tca (manage PON Utilization and Threshold)
show alarm current ont-cfg-dld (CPE/ONT Configuration over OMCI)
show alarm log channel-pair (NG-PON2 support)
show alarm log olt-chpair-tc-tca (manage PON Utilization and Threshold)
show alarm log olt-pon-util-tca (manage PON Utilization and Threshold)
show alarm log ont-cfg-dld (CPE/ONT Configuration over OMCI)
show alarm snap-shot channel-pair (NG-PON2 support)
show alarm snap-shot olt-chpair-tc-tca (manage PON Utilization and Threshold)
show alarm snap-shot olt-pon-util-tca (manage PON Utilization and Threshold)
show alarm snap-shot ont-cfg-dld (CPE/ONT Configuration over OMCI)
show channel-pair (NG-PON2 support)
show channel-pair diagnostics (NG-PON2 support)
show channel-pair fec-tc-layer (NG-PON2 support)
show channel-pair fec-tc-layer current-interval (NG-PON2 support)
show channel-pair mcast-tc-layer (NG-PON2 support)
show channel-pair mcast-tc-layer current-interval (NG-PON2 support)
show channel-pair mcast-tc-layer previous-interval (NG-PON2 support)
show channel-pair optics (NG-PON2 support)
show channel-pair phy-layer (NG-PON2 support)
show channel-pair phy-layer current-interval (NG-PON2 support)
show channel-pair sfp-inventory (NG-PON2 support)
show channel-pair tc-layer (NG-PON2 support)
show channel-pair tc-layer current-interval (NG-PON2 support)
show channel-pair tc-layer previous-interval (NG-PON2 support)
show channel-pair unprovision-onu (NG-PON2 support)
show channel-pair xg-tc-layer current-interval (NG-PON2 support)
show channel-pair xg-tc-layer previous-interval (NG-PON2 support)
show channel-pair xg-tc-layer (NG-PON2 support)
show equipment diagnostics sfp-threshold (RSSI support on NT ports in FD)
show equipment ont cfg-download (CPE/ONT Configuration over OMCI)
show equipment ont ranging-status (NG-PON2 support)
show equipment ont ranging-status channel-group (NG-PON2 support)

show equipment ont ranging-status channel-pair (NG-PON2 support)
show equipment ont utilization (manage PON Utilization and Threshold)
show equipment ont utilization current-interval (manage PON Utilization and Threshold)
show equipment ont utilization previous-interval (manage PON Utilization and Threshold)
show pon cfg-download (CPE/ONT Configuration over OMCI)
show pon utilization (manage PON Utilization and Threshold)
show pon utilization cur-intvl-top-ont-rx (manage PON Utilization and Threshold)
show pon utilization cur-intvl-top-ont-tx (manage PON Utilization and Threshold)
show pon utilization current-interval (manage PON Utilization and Threshold)
show pon utilization previous-interval (manage PON Utilization and Threshold)
show pon utilization prv-intvl-top-ont-rx (manage PON Utilization and Threshold)
show pon utilization prv-intvl-top-ont-tx (manage PON Utilization and Threshold)
show system cde-bitmap-extended (displays the activated CDE Capabilities (256 bits))
show trouble-shooting pbitstatistics (NG-PON2 support)
show trouble-shooting pbitstatistics vlanport (NG-PON2 support)
show trouble-shooting statistics channel-pair (NG-PON2 support)
show trouble-shooting statistics vlanport (NG-PON2 support)
show trouble-shooting statistics vlanport bridgeport-id (NG-PON2 support)
show trouble-shooting statistics vlanport bridgeport-id vlan-id (NG-PON2 support)
show trouble-shooting statistics vlanport bridgeport-id vlan-id extensive (NG-PON2 support)
show trouble-shooting statistics vlanport bridgeport-id vlan-id summary (NG-PON2 support)

Removed Commands

admin cmts cm static-l2migr (modified support for DHCP, DHCP Relay not supported any more on DPOE)
configure cmts vcm-oam (modified support for DHCP, DHCP Relay not supported any more on DPOE)
show cmts l2migr status (modified support for DHCP, DHCP Relay not supported any more on DPOE)

Commands or commands with parameters for future use, not supported yet

configure l2cp session (RFC6320+ VDSL bonding to mainstream)
configure linetest cluster ltsession (H248 POTS: Porting MDU specific enhancements diagnosis-caller diagnosis-callee)
configure linetest single ltparm test-name (increase line test parameters for NBLT ROH test zener-res zener-volt)
configure vlan id (transparent behavior DHCP option 82 handling (replaced when already inserted by CPE), Access Loop Encapsulation support for DHCPv6 not supported yet (parameters pppoe-l2-encaps, dhcp-l2-encaps, dhcpv6-l2-encaps l2-encaps1 pppoer-vlanaware and dhcpr-vlanaware))
show l2cp session-status (RFC6320+ VDSL bonding to mainstream)
show linetest single lineid-ext-rept (increase line test parameters for NBLT ROH test)

Command delta R5.1.01 versus R5.1

Modified Commands

admin pppoe-client emulation client-id (ARP/PPPoE/VLAN parameter types merged into common interface type)
admin pppoel2-stats client-id (ARP/PPPoE/VLAN parameter types merged into common interface type)
configure pppoe-client interface client-id (ARP/PPPoE/VLAN parameter types merged into common interface type)
configure pppoel2-stats (ARP/PPPoE/VLAN parameter types merged into common interface type)
show pppoe-client emulation (ARP/PPPoE/VLAN parameter types merged into common interface type)
show pppoe-client session (ARP/PPPoE/VLAN parameter types merged into common interface type)
show pppoel2-stats (ARP/PPPoE/VLAN parameter types merged into common interface type)
configure mcast chn (improved configuration of a multicast channel using the "chn" keyword)
configure qos profiles ingress-qos (parameter value 'not-used' added for NibbleMask)
configure vlan id (adding parameters for Access Loop Encapsulation in PPPoE IA and DHCP relay and parameters pppoer-vlanaware and dhcpr-vlanaware for S+C VLAN CC with 3 VLANs)
configure voice cluster equipment board (support NVPS-C Redundancy)
show voice ont pots operational-data detail (adding VOIP Line Status support (OLT part))
configure xdsl-bonding board r/s/s vect-fallback (bonding fall-back configuration for vectoring)
show xdsl-bonding operational-data group (bonding fall-back configuration for vectoring)
configure equipment ont interface (support for N:P connect mode for ontBridgeMapMode)
configure voice ont (improved retrieval of toneset profile)
config vlan id (closing feature gaps between FGLT-B and FGLT-A)
configure qos profiles policer (closing feature gaps between FGLT-B and FGLT-A)
configure pppox-relay cross-connect (closing feature gaps between FGLT-B and FGLT-A)
show voice ont pots operational-data (add new values to VOIP Voice Server Status in OLT)
admin cmts add-cm-event (VCM Event Improvement)
admin cmts del-cm-event (VCM Event Improvement)
show cmts cm-event-ctrl (VCM Event Improvement)

New Commands

configure cm route_profile (add configure cm route-profile cli in core 0)
configure pppoe-client interface (ARP/PPPoE/VLAN GPON 2 parameter types merged into common interface type)
configure xdsl-bonding board (adding bonding vectoring fallback)
configure xdsl-bonding board vect-fallback (adding bonding vectoring fallback)

New Parameters or Parameter Values NOT supported yet

configure alarm entry (alarms hpr-com-fail,chpr-tx-fail,chpr-unprov-ont,chpr-prov-mismatch,chpr-loss-sig,chpr-diagnostic,chpr-loid-conflict,chpr-loid-pv

not supported yet)

configure alarm filter filterid(alarms

hpr-com-fail,chpr-tx-fail,chpr-unprov-ont,chpr-prov-mismatch,chpr-loss-sig,chpr-diagnostic,chpr-loid-conflict,chpr-loid-pv

not supported yet)

Command delta R5.1 versus R5.0.01

Modified Commands

configure cfm domain association mep (supporting LM originator and historical counters for past measurements on VDSL LTs)

configure cfm y1731pm domain association (supporting LM originator and historical counters for past measurements on VDSL LTs)

configure equipment shelf (adding mode that supports NT-B slot that can be used as LT slot)

show equipment shelf (adding mode that supports NT-B slot that can be used as LT slot)

configure linetest cluster ltparm test-name (adding megaco testtypes, GR909 faults testing, fixing dial tone delay)

configure linetest cluster ltsession (adding megaco testtypes, GR909 faults testing, fixing dial tone delay)

show linetest cluster lineid-ext-rept (adding megaco testtypes, GR909 faults testing, fixing dial tone delay)

configure qos dsl-ctrl-pkt-policer (adding option to disable policing of RIP/ARP traffic on data plane in upstream)

configure system (adding support for voice image selection)

configure vlan id (removed obsoleted parameters broadcast-frames and secure-forwarding)

configure voice cluster media-gateway (updating supported MGC types)

configure voice cluster equipment termination (updating supported termination for 270duratelsplitter and 2703splitter)

configure voice sip termination (updating supported termination for 270duratelsplitter and 2703splitter)

show system license (lining up license key counters for TL1 and CLI)

show xdsl config-data-port igmp (remove PON identifiers from the res-ids)

show voice ont pots operational-data detail (adding additional field line-state)

show interface port (updated description of last-chg-opr-stat)

configure equipment applique (adding support for FNIO-A)

show equipment applique (adding support for FNIO-A)

configure equipment rssiprof (difference in ranges provided for parameters tx-pwr and rx-pwr)

configure ethernet ont (configurable behaviour for Ethernet port on PONLOS)

configure veip ont (configurable behaviour for Ethernet port on PONLOS)

configure xdsl ont spectrum-profile (removing unsupported operational modes)

admin voice cluster media-gateway (adding support for Single Node Standalone SOS operation, adding failover to ESA MGC alarm type)

configure alarm entry (adding failover to ESA MGC alarm type)

configure alarm filter filterid (adding failover to ESA MGC alarm type)

New Commands
show equipment planned-resource (showing the actual values of configured hardware resources on boards)
configure qos pbit-scheduling (configuring the p-bit behavior of the S+C vlan forwarding model in both upstream and downstream direction)
configure xdsl-bonding board (adding bonding vectoring fallback for future use)
configure xdsl-bonding board vect-fallback (adding bonding vectoring fallback for future use)
show mcast ont-active-groups (shows the list of active multicast streams per user interface on a particular ONT)
show mcast pon-active-groups (shows the list of active multicast streams per user interface on a particular PON)
admin cmts (adding MEF2.0 CLI nodes on FANT-F core0)
configure cmts mesp (adding MEF2.0 CLI nodes on FANT-F core0)
configure cmts pw-class (adding MEF2.0 CLI nodes on FANT-F core0)
configure cmts vpls-class (adding MEF2.0 CLI nodes on FANT-F core0)
configure cmts vpn-sg (adding MEF2.0 CLI nodes on FANT-F core0)
show cmts (adding MEF2.0 CLI nodes on FANT-F core0)
configure service pw-template (BGP auto-discovery and signaling support for VPLS and EPIPE services)
show dpoe profile (add DPOE CLI node: profile)
show dpoe service (add DPOE CLI node: service)

New commands NOT supported yet
admin channel-pair (changes for channel-pair related commands supporting NGPON2)
admin channel-pair diagnostic (changes for channel-pair related commands supporting NGPON2)
configure channel-group (changes for channel-pair related commands supporting NGPON2)
configure channel-group id (changes for channel-pair related commands supporting NGPON2)
configure channel-group id channel-pair (changes for channel-pair related commands supporting NGPON2)
configure channel-group id subchannel-group (changes for channel-pair related commands supporting NGPON2)
configure channel-group id subchannel-group id (changes for channel-pair related commands supporting NGPON2)
configure channel-group id subchannel-group id channel-pair (changes for channel-pair related commands supporting NGPON2)
configure channel-pair (changes for channel-pair related commands supporting NGPON2)
configure channel-pair interface (changes for channel-pair related commands supporting NGPON2)
configure channel-pair interface fec-tc-layer (changes for channel-pair related commands supporting NGPON2)
configure channel-pair interface mcast-tc-layer (changes for channel-pair related commands supporting NGPON2)
configure channel-pair interface phy-layer (changes for channel-pair related commands supporting NGPON2)

NGPON2)
configure channel-pair interface tc-layer (changes for channel-pair related commands supporting NGPON2)
configure channel-pair interface xg-tc-layer (changes for channel-pair related commands supporting NGPON2)
configure channel-pair profiles (changes for channel-pair related commands supporting NGPON2)
configure channel-pair profiles wavelength-prof (changes for channel-pair related commands supporting NGPON2)
show channel-pair (changes for channel-pair related commands supporting NGPON2)
show channel-pair interface (changes for channel-pair related commands supporting NGPON2)
show channel-pair interface fec-tc-layer (changes for channel-pair related commands supporting NGPON2)
show channel-pair interface fec-tc-layer current-interval (changes for channel-pair related commands supporting NGPON2)
show channel-pair interface mcast-tc-layer (changes for channel-pair related commands supporting NGPON2)
show channel-pair interface mcast-tc-layer current-interval (changes for channel-pair related commands supporting NGPON2)
show channel-pair interface mcast-tc-layer previous-interval (changes for channel-pair related commands supporting NGPON2)
show channel-pair interface phy-layer (changes for channel-pair related commands supporting NGPON2)
show channel-pair interface phy-layer current-interval (changes for channel-pair related commands supporting NGPON2)
show channel-pair interface tc-layer (changes for channel-pair related commands supporting NGPON2)
show channel-pair interface tc-layer current-interval (changes for channel-pair related commands supporting NGPON2)
show channel-pair interface tc-layer previous-interval (changes for channel-pair related commands supporting NGPON2)
show channel-pair interface xg-tc-layer (changes for channel-pair related commands supporting NGPON2)
show channel-pair interface xg-tc-layer current-interval (changes for channel-pair related commands supporting NGPON2)
show channel-pair interface xg-tc-layer previous-interval (changes for channel-pair related commands supporting NGPON2)
show channel-pair sfp-inventory (changes for channel-pair related commands supporting NGPON2)

New parameter values for NGPON2 NOT supported yet

admin equipment ont data-store (changes to enable planning, creating and managing NGPON2 interfaces)
admin equipment ont interface (changes to enable planning, creating and managing NGPON2 interfaces)
configure ani ont tca-thresh (changes for commands supporting NGPON2)
configure ani ont video (changes for commands supporting NGPON2)
configure equipment ont interface (changes for commands supporting NGPON2)
configure equipment ont loop (changes for commands supporting NGPON2)

configure interface alarm (changes for commands supporting NGPON2)
configure interface port (changes for commands supporting NGPON2)
configure ntp ont (changes for commands supporting NGPON2)
configure qos interface (changes for commands supporting NGPON2)
configure qos tca queue (changes for commands supporting NGPON2)
configure xdsl ont interface (changes for commands supporting NGPON2)
show ani ont operational-data (changes for commands supporting NGPON2)
show ani ont video (changes for commands supporting NGPON2)
show ani ont video-stats (changes for commands supporting NGPON2)
show equipment ont data-store (changes for commands supporting NGPON2)
show equipment ont ethernet current-interval (changes for commands supporting NGPON2)
show equipment ont ethernet previous-interval (changes for commands supporting NGPON2)
show equipment ont ethernet total (changes for commands supporting NGPON2)
show equipment ont fec-tc-layer olt-side current-interval (changes for commands supporting NGPON2)
show equipment ont fec-tc-layer ont-side current-interval (changes for commands supporting NGPON2)
show equipment ont interface (changes for commands supporting NGPON2)
show equipment ont mcast-tc-layer ont-side current-interval (changes for commands supporting NGPON2)
show equipment ont mcast-tc-layer ont-side previous-interval (changes for commands supporting NGPON2)
show equipment ont operational-data (changes for commands supporting NGPON2)
show equipment ont optics (changes for commands supporting NGPON2)
show equipment ont optics-history (changes for commands supporting NGPON2)
show equipment ont phy-layer olt-side current-interval (changes for commands supporting NGPON2)
show equipment ont pwr-shed (changes for commands supporting NGPON2)
show equipment ont sw-download (changes for commands supporting NGPON2)
show equipment ont tc-layer olt-side current-interval (changes for commands supporting NGPON2)
show equipment ont tc-layer olt-side previous-interval (changes for commands supporting NGPON2)
show equipment ont tc-layer olt-side-on-demand current-interval (changes for commands supporting NGPON2)
show equipment ont tc-layer olt-side-on-demand previous-interval (changes for commands supporting NGPON2)
show equipment ont tc-layer ont-side current-interval (changes for commands supporting NGPON2)
show equipment ont tc-layer ont-side previous-interval (changes for commands supporting NGPON2)
show equipment ont xg-tc-layer olt-side current-interval (changes for commands supporting NGPON2)
show equipment ont xg-tc-layer olt-side previous-interval (changes for commands supporting NGPON2)
show equipment ont xg-tc-layer ont-side current-interval (changes for commands supporting NGPON2)
show equipment ont xg-tc-layer ont-side previous-interval (changes for commands supporting NGPON2)
show interface alarm (changes for commands supporting NGPON2)

show interface port (changes for commands supporting NGPON2, updated description of last-chg-opr-stat)
show interface stack (changes for commands supporting NGPON2)
show interface test (changes for commands supporting NGPON2)
show qos interface-bandwidth (changes for commands supporting NGPON2)
show qos statistics queue current-15min (changes for commands supporting NGPON2)
show qos statistics queue prev-15min (changes for commands supporting NGPON2)

Command delta R5.0.01 versus R5.0

Modified Commands
configure voice cluster media-gateway (new parameter quat-mgc-ip and quat-mgc-udp for IMS Geo Redundancy)
configure voice cluster signal-gateway (new parameter quat-asp-ip and quat-sctp-port for IMS Geo Redundancy)
configure voice sip user-agent-ap slot-id (adding support for NTIO board)
show voice sip redundancy-node ext-redundancy-state (adding support for NTIO board)
show voice sip redundancy-node redundancy-state (adding support for NTIO board)
show voice sip user-agent-ap (adding support for NTIO board)
configure alarm entry (updating alarm list with new alarms, adding power alarms introduced for 7363 ISAM MX and 7367 ISAM SX)
configure alarm filter filterid (updating alarm list with new alarms)
show alarm delta-log indeterminate (updating alarm list with new alarms)
show alarm delta-log warning (updating alarm list with new alarms)
show alarm delta-log minor (updating alarm list with new alarms)
show alarm delta-log major (updating alarm list with new alarms)
show alarm delta-log critical (updating alarm list with new alarms)
configure ethernet line mau (adding supported mau types)
configure qos profiles policer (updating policer profile ranges for MEF certification and MEF Policer rate calculation to include only L2 bytes)
configure vlan id (adding new parameter 'cvlan4095passthru' to forward c-vid 4095 transparently)
show qos statistics buffer-overflow current-1day (removal of obsolete parameter values for 'slotindex')
show vlan bridge-port-fdb (enabling retrieval of mac-addresses learned on uplink lt)
show vlan fdb-board (improved display of dup mac alarm)
show vlan dup-mac-alarm (improved display of dup mac alarm)
configure system security login-banner (expanding Logon banner to 2048 characters)
configure system loop-id-syntax (adding 'LzNVID' as keyword to construct the system loop ID)
show xdsl counters near-end line previous-interval (adding a timestamp to each PM interval, specifying the date and time of the start of the PM interval)
show xdsl counters near-end line previous-day (adding a timestamp to each PM interval, specifying the

date and time of the start of the PM interval)
show xdsl counters near-end channel previous-interval (adding a timestamp to each PM interval, specifying the date and time of the start of the PM interval)
show xdsl counters near-end channel previous-day (adding a timestamp to each PM interval, specifying the date and time of the start of the PM interval)
show xdsl counters far-end line previous-interval (adding a timestamp to each PM interval, specifying the date and time of the start of the PM interval)
show xdsl counters far-end line previous-day (adding a timestamp to each PM interval, specifying the date and time of the start of the PM interval)
show xdsl counters far-end channel previous-interval (adding a timestamp to each PM interval, specifying the date and time of the start of the PM interval)
show xdsl counters far-end channel previous-day (adding a timestamp to each PM interval, specifying the date and time of the start of the PM interval)
show xdsl imp-noise-sensor near-end previous-interval (adding a timestamp to each PM interval, specifying the date and time of the start of the PM interval)
show xdsl imp-noise-sensor far-end previous-interval (adding a timestamp to each PM interval, specifying the date and time of the start of the PM interval)
show shdsl segment-counters previous-15min (adding a timestamp to each PM interval, specifying the date and time of the start of the PM interval)
show shdsl segment-counters previous-1day (adding a timestamp to each PM interval, specifying the date and time of the start of the PM interval)
show shdsl span-counters previous-15min (adding a timestamp to each PM interval, specifying the date and time of the start of the PM interval)
show shdsl span-counters previous-1day (adding a timestamp to each PM interval, specifying the date and time of the start of the PM interval)
configure cmts system (DPoE : removed 'no' for parameter 'system')
configure voice ont mgc-config (improvement to attach sec-uri profile to the mgc-config when using the profile name)
configure voice ont service (increasing parameter length for 'user-name')
show voice ont call-hist (improvement to only allow valid value between 1 and 32)
configure eth-cfm (adding on-demand and proactive performance monitoring compliant with Y.1731 on IHUB system)
show eth-cfm (adding on-demand and proactive performance monitoring compliant with Y.1731 on IHUB system)
show eth-ring (adding RPL owner functionality for G.8032 ERPS on IHUB system)

New Commands

configure cfm y1731pm (adding on-demand and proactive performance monitoring compliant with Y.1731)
configure cfm y1731pm domain association (adding on-demand and proactive performance monitoring compliant with Y.1731)
show cfm y1731pm (adding on-demand and proactive performance monitoring compliant with Y.1731)
show cfm y1731pm curr-15min-stats (adding on-demand and proactive performance monitoring compliant with Y.1731)

show cfm y1731pm curr-15min-stats domain (adding on-demand and proactive performance monitoring compliant with Y.1731)
show cfm y1731pm curr-day-stats (adding on-demand and proactive performance monitoring compliant with Y.1731)
show cfm y1731pm curr-day-stats domain (adding on-demand and proactive performance monitoring compliant with Y.1731)
show cfm y1731pm prev-15min-stats (adding on-demand and proactive performance monitoring compliant with Y.1731)
show cfm y1731pm prev-15min-stats domain (adding on-demand and proactive performance monitoring compliant with Y.1731)
show cfm y1731pm prev-day-stats (adding on-demand and proactive performance monitoring compliant with Y.1731)
show cfm y1731pm prev-day-stats domain (adding on-demand and proactive performance monitoring compliant with Y.1731)
admin interface cable (DPoE : adding support more counters and statistics for ONU)
admin trouble-shooting pbit interface (upstream summary and extensive troubleshooting counters per TC)
configure trouble-shooting pbit (upstream summary and extensive troubleshooting counters per TC)
configure trouble-shooting pbit statistics (upstream summary and extensive troubleshooting counters per TC)
configure trouble-shooting pbit statistics interface (upstream summary and extensive troubleshooting counters per TC)
show trouble-shooting pbit statistics interface (Upstream summary and extensive troubleshooting counters per TC)
configure cmts cm-event-ctrl (DPoE : vCM event improvement)
configure system sync-if-timing ptp (adding TimeOfDay functionality, adding parameter 'transport-mode')
configure system sync-if-timing ptp mstr-port-ds-prof (adding TimeOfDay functionality)
configure system sync-if-timing ptp ont-master-port (adding TimeOfDay functionality)
configure system sync-if-timing ptp default-dataset (adding TimeOfDay functionality)
configure system sync-if-timing ptp slave-port-dataset (adding TimeOfDay functionality)
configure system sync-if-timing tod (adding TimeOfDay functionality)
configure system sync-if-timing tod interface (adding TimeOfDay functionality)
configure system sync-if-timing tod serial-param (adding TimeOfDay functionality)
configure system sync-if-timing tod-ref-order (adding TimeOfDay functionality)
show system sync-if-timing-profile (adding TimeOfDay functionality)
show system sync-if-timing-tod (adding TimeOfDay functionality)
configure eth-ring revert-time (adding RPL owner functionality for G.8032 ERPS on IHUB system)
configure eth-ring rpl-node (adding RPL owner functionality for G.8032 ERPS on IHUB system)
configure qos-servicerouter system ingress-storm-ctrl (adding rate-limiting of Broadcast/DLF/Unknown Multicats on IHUB system)
configure qos-servicerouter system egress-storm-ctrl (adding rate-limiting of Broadcast/DLF/Unknown Multicats on IHUB system)

configure service storm-ctrl (adding rate-limiting of Broadcast/DLF/Unknown Multicats on IHUB system)
show qos-servicerouter system ingress-storm-ctrl (adding rate-limiting of Broadcast/DLF/Unknown Multicats on IHUB system)
show qos-servicerouter system egress-storm-ctrl (adding rate-limiting of Broadcast/DLF/Unknown Multicats on IHUB system)

Removed Commands or Commands with removed parameters

configure system sync-if-timing ptp packet-mode (packtet-mode has been replaced by transport-mode)
configure system clock-mgmt (obsolete command, replaced by 'configure system sync-if-timing')

Command delta R5.0 versus R4.6.02

Modified Commands
configure alarm entry (OLT support SIPPING Alarms, ONTalarms, removal of obsolete alarms)
configure cfm domain association mep (support Y.1731 SLM Originator and LM responder on CATAN based VDSL LT's)
show system license (support Y.1731 SLM Originator and LM responder on CATAN based VDSL LT's)
show cfm mep-config-data domain (support Y.1731 SLM Originator and LM responder on CATAN based VDSL LT's)
configure ethernet line tca-line-threshold (extend TCA on Eth Phy PM traffic counters)
configure qos interface (allow vlanport on DSL/ETH interface)
configure qos tca queue (allow vlanport on DSL/ETH interface)
show interface port (improved display parameters as an extension of the interface MIB for the efm interface according to RFC2863)
show qos interface-bandwidth (allow vlanport on DSL/ETH interface)
show qos statistics queue current-15min (allow vlanport on DSL/ETH interface)
show qos statistics queue prev-15min (allow vlanport on DSL/ETH interface)
configure qos profiles policer (the use of 'discard' value for GreenAction is disabled)
configure system security filetransfer server (improved security for operator password)
configure system security pmfile upload (improved security for operator password)
configure system security radius acc-server (name) router-instance (improved security for operator password)
configure system security radius auth-server (name) router-instance (improved security for operator password)
configure system security radius dyn-auth-client (name) router-instance (improved security for operator password)
show xdsl config-data-port pppox-relay (improved response speed)
show xdsl vect-carrier-data far-end (improved value range)
show xdsl vect-carrier-data near-end (improved value range)
configure linetest single ltssession (adding SIP NBLT session busy-overwrite parameter :

"busy-overwrite")
configure system clock-mgmt (clock input failure derived from AIS)
configure vlan id (updated description of parameter 'new-broadcast')
configure voice sip termination (improved security for operator password)
configure voice sip termination (add line signal on remote answer parameter : "linesig-remanswer")
configure voice sip termination (add test access parameters : "testaccessstate", "busyoverwrite" and "accessontimeout")
configure voice sip termination (add line identification parameter (pani-header): "line-id")
configure voice sip digitmap (size of parameter "rule" increased to 100 bytes)
show alarm current ether=tca (extend TCA on Eth Phy PM traffic counters)
show alarm snap-shot ether=tca (extend TCA on Eth Phy PM traffic counters)
show alarm log ether=tca (extend TCA on Eth Phy PM traffic counters)
show config-data-port security-pae (add missing PON types)
show oper-data-port ip-bridge-port (add missing PON types)
configure equipment ont interface (improved security for operator password)
configure pon auth-sec-prof (improved security for operator password)
configure voice ont auth-sec-prof (improved security for operator password)
configure voice ont service (add support for SIPPING Server as a configuration method)
configure voice ont service (improved security for operator password)
configure voice ont voice-sip-port (improved security for operator password)
configure equipment ont interface (decouple ONT SW Planning and Delay Activation)
configure equipment ont interface (support RF programmable filter options for I-241W-T)
configure equipment ont slot (add MoCA support)
show alarm current ont-pots (OLT support SIPPING Alarms)
show alarm snapshot ont-pots (OLT support SIPPING Alarms)
show alarm log ont-pots (OLT support SIPPING Alarms)
show alarm delta-log ont-pots (OLT support SIPPING Alarms)
show alarm current ont-voip (OLT support SIPPING Alarms)
show alarm snapshot ont-voip (OLT support SIPPING Alarms)
show alarm log ont-voip (OLT support SIPPING Alarms)
show alarm delta-log ont-voip (OLT support SIPPING Alarms)
show equipment ont sw-download (decouple ONT SW Planning and Delay Activation)
configure equipment ont sw-ctrl (decouple ONT SW Planning and Delay Activation)
configure system sync-if-timing (clock input failure derived from AIS)
show equipment ont ethernet current-interval (64bit rolling counter for Total/Multicast/Broadcast)
show equipment ont ethernet previous-interval (64bit rolling counter for Total/Multicast/Broadcast)
show ces ont service pseudo-wire currentinterval (OLT support for B-0404G-B new PM and loopback alarms)

show ces ont service pseudo-wire previousinterval (OLT support for B-0404G-B new PM and loopback alarms)
show alarm current ont-ces (OLT support for B-0404G-B new PM and loopback alarms)
show alarm snap-shot ont-ces (OLT support for B-0404G-B new PM and loopback alarms)
show alarm log ont-ces (OLT support for B-0404G-B new PM and loopback alarms)
show alarm delta-log ont-ces (OLT support for B-0404G-B new PM and loopback alarms)
show alarm current ont-pwe (OLT support for B-0404G-B new PM and loopback alarms)
show alarm snap-shot ont-pwe (OLT support for B-0404G-B new PM and loopback alarms)
show alarm log ont-pwe (OLT support for B-0404G-B new PM and loopback alarms)
show alarm delta-log ont-pwe (OLT support for B-0404G-B new PM and loopback alarms)
configure port ethernet (suppress obsolete alarm with new parameter suppress-link-state-alarm : see IHUB interface guide for details)

New Commands

show alarm current mdu-sup (differentiation between ONT alarm types)
show alarm current sfu-sup (differentiation between ONT alarm types)
show alarm current soho-sup (differentiation between ONT alarm types)
show alarm log mdu-sup (differentiation between ONT alarm types)
show alarm log sfu-sup (differentiation between ONT alarm types)
show alarm log soho-sup (differentiation between ONT alarm types)
show alarm snap-shot mdu-sup (differentiation between ONT alarm types)
show alarm snap-shot sfu-sup (differentiation between ONT alarm types)
show alarm snap-shot soho-sup (differentiation between ONT alarm types)
admin cfm single-ended-slm (support Y.1731 SLM Originator and LM responder on CATAN based VDSL LT's)
admin cfm single-ended-slm domain association mep target-mac (support Y.1731 SLM Originator and LM responder on CATAN based VDSL LT's)
configure alarm filter filterid (CLI coverage of TL1 Alarm Filter)
show alarm current spatial (add spatial filter alarm)
show alarm current temporal (add temporal filter alarm)
show alarm log spatial (add spatial filter alarm)
show alarm log temporal (add temporal filter alarm)
show alarm snap-shot spatial (add spatial filter alarm)
show alarm snap-shot temporal (add temporal filter alarm)
configure voice cluster equipment termination tca (Voice QoS threshold TCA (drop rate, jitter, loop delay))
show qos resource-usage (QOS resource usage status (NELT-B HighCap UNI increment))
show qos resource-usage ingress-hw-filter (QOS resource usage status (NELT-B HighCap UNI increment))
admin cm (enable DPoE node on core0)

admin iphost (Support Ping from ONT-OLT part)
admin iphost ping dest-ip (Support Ping from ONT-OLT part)
configure cm uni-collection (add BHN support for DPoE)
configure cm uniprofile (add BHN support for DPoE)
configure cmts cmts-event-ctrl (DPoE data path redundancy)
configure cmts ssd (enable DPoE SSD node on core0)
configure moca (add MoCA support)
configure moca ont cust-info (add MoCA support)
configure moca ont l2 pm (add MoCA support)
configure moca ont phy pm (add MoCA support)
show alarm current ont-moca (add MoCA support)
show alarm current ont-moca-tca (add MoCA support)
show alarm log ont-moca (add MoCA support)
show alarm log ont-moca-tca (add MoCA support)
show alarm snap-shot ont-moca (add MoCA support)
show alarm snap-shot ont-moca-tca (add MoCA support)
show moca (add MoCA support)
show moca ont (add MoCA support)
show moca ont operational-data (add MoCA support)
show moca ont performance-data (add MoCA support)
show moca ont performance-data current-interval (add MoCA support)
show moca ont performance-data previous-interval (add MoCA support)
show equipment ont ethernet total (64bit rolling counter for Total/Multicast/Broadcast)
show voice ont voip-pip-prof (OLT support SIPPING Alarms,added to allow monitoring of the download status for each POTS line)
show voice ont voip-pip-prof operational-data (OLT support SIPPING Alarms)
show voice ont voip-pip-prof operational-data input-profile (OLT support SIPPING Alarms)
show voice ont voip-vip-prof (OLT support SIPPING Alarms,added to allow monitoring of the download status for the VoIP client)
show voice ont voip-vip-prof operational-data (OLT support SIPPING Alarms)
show voice ont voip-vip-prof operational-data input-profile (OLT support SIPPING Alarms)

New commands NOT supported yet

configure system auto-switch (Auto-switching between ATMoADSL and PTMoVDSL)
show alarm current auto-switch (Auto-switching between ATMoADSL and PTMoVDSL)
show alarm log auto-switch (Auto-switching between ATMoADSL and PTMoVDSL)
show alarm snap-shot auto-switch (Auto-switching between ATMoADSL and PTMoVDSL)
configure alarm entry auto-switch-status (Auto-switching between ATMoADSL and PTMoVDSL)

configure alarm filter auto-switch-status (Auto-switching between ATMoADSL and PTMoVDSL)
show alarm delta-log auto-switch-status (Auto-switching between ATMoADSL and PTMoVDSL)
show alarm current table auto-switch (Auto-switching between ATMoADSL and PTMoVDSL)
show alarm log table auto-switch (Auto-switching between ATMoADSL and PTMoVDSL)
show alarm snap-shot table auto-switch (Auto-switching between ATMoADSL and PTMoVDSL)
show equipment planned-resource

Removed Commands or Commands with removed parameters

configure bridge port (removal of obsolete parameters old-tag accept-frame-type)
configure vlan (removal of obsolete parameter pvid-usage)
configure vlan id (removal of obsolete parameters pppoe-relay circuit-id remote-id)

Command delta R4.6.02 versus R4.6.01

Modified Commands

show xdsl vect-carrier-data far-end (improved display of sampling rate)
show xdsl vect-carrier-data near-end (improved display of sampling rate)
configure xdsl-bonding group (2-pair VDSL2 PTM bonding in combination with G.inp)
show xdsl-bonding operational-data group (2-pair VDSL2 PTM bonding in combination with G.inp)
configure system sync-if-timing ref-order (Synchronisation Redundancy for BITS/SyncE/IEEE1588 parameter value "ieee1588" replaced by "ieee1588-a" or "ieee1588-b", restrictions removed)
configure system sync-if-timing ssm-order (Synchronisation Redundancy for BITS/SyncE/IEEE1588 parameter value "ieee1588" replaced by "ieee1588-a" or "ieee1588-b", restrictions removed)
configure system sync-if-timing ptp ptp-domain (Synchronisation Redundancy for BITS/SyncE/IEEE1588 parameter value "ieee1588" replaced by "ieee1588-a" or "ieee1588-b", restrictions removed)
show system sync-if-timing (Synchronisation Redundancy for BITS/SyncE/IEEE1588 parameter value "ieee1588" replaced by "ieee1588-a" or "ieee1588-b", restrictions removed)
configure alarm entry (new alarms for several features)
configure voice ont ring-seq-prof (improvement to configure ring sequence using strings for pattern1)
configure voice ont tone-seq-profile (improvement to configure tone sequence using strings for pattern1)

New Commands

configure xdsl-bonding [no] group-rtx-profile (2-pair VDSL2 PTM bonding in combination with G.inp)
show xdsl-bonding group-rtx-profiles (2-pair VDSL2 PTM bonding in combination with G.inp)
configure cmts cmcert (adding security features for DPoE system)
configure cmts eae-excluded-onu (adding security features for DPoE system)
configure cmts cmts-event (DOCSIS Event Framework phase 2)
configure cmts physical-entity (provides additional DOCSIS OLT MIBs)
configure eth-ring (supporting Ethernet Ring (G.8032))

show eth-ring (supporting Ethernet Ring (G.8032))
show alarm current eth-ring (supporting Ethernet Ring (G.8032))
show alarm log eth-ring (supporting Ethernet Ring (G.8032))
show alarm snapshot eth-ring (supporting Ethernet Ring (G.8032))
configure ethernet ont l2 (redesign cli commands for ont uni (ethernet) l2 threshold crossing alerts)
configure ethernet ont phy (redesign cli commands for ont uni (ethernet) l2 threshold crossing alerts)
configure hpna ont l2 (redesign cli commands for ont uni (hpna) l2 threshold crossing alerts)
configure veip ont l2 (redesign cli commands for ont uni (veip) l2 threshold crossing alerts)
configure xdsl ont line l2 (redesign cli commands for ont uni (xdsl) l2 threshold crossing alerts)
configure xdsl ont line phy (cli commands for ont uni (xdsl) layer threshold crossing alerts)
show interface cable (DPoE DOCSIS Provisioning Framework)

Changed commands NOT supported yet

show alarm current mdu-sup (alarm for future use)
show alarm current sfu-sup (alarm for future use)
show alarm current soho-sup (alarm for future use)
show alarm log mdu-sup (alarm for future use)
show alarm log sfu-sup (alarm for future use)
show alarm log soho-sup (alarm for future use)
show alarm snap-shot mdu-sup (alarm for future use)
show alarm snap-shot sfu-sup (alarm for future use)
show alarm snap-shot soho-sup (alarm for future use)

Command delta R4.6.01 versus R4.6

Modified Commands

show dhcp-relay port-stats vlan (improved response on SLT platform)
show dhcp-relay v6-port-stats vlan (improved response on SLT platform)
show vlan port-15min-stats (improved parameter range display)
show vlan port-prev-day-stats (improved parameter range display)
show vlan previous-15min-stats (improved parameter range display)
show vlan vlan-day-stats (improved parameter range display)
configure alarm entry (support new alarms for different features, improved alarm mechanism specification)
configure alarm log-sev-level (improved alarm mechanism specification)
configure alarm shub entry (improved alarm mechanism specification)
configure trap manager (improved alarm mechanism specification)
show alarm log table (improved alarm mechanism specification)

show alarm current table (improved alarm mechanism specification)
show alarm snap-shot table (improved alarm mechanism specification)
configure bridge port (support bp and vp for uplink port)
configure cfm domain association (ONT CFM SW enhancements)
configure cfm domain association mep (support Y.1731 DM responder)
show cfm mep-config-data domain association mep (support Y.1731 DM responder)
configure system security pmfile upload (automatic PM collection)
admin system security pmfile upload (automatic PM collection)
show equipment shelf detail (retrieve serial Number, ICS and variant of the shelf)
show equipment transceiver-inventory (Report B+/C+ type for GPON SFPs)
show security pmfile upload (automatic PM collection)
show pppoel2-stats vlan (improved response on SLT platform)
configure ces ont service service-nbr (CES SAToP support at ONT)
configure epon profiles filter (EPON CCL profile dimension expanded to 8192)
show epon profiles-usage filter (EPON CCL profile dimension expanded to 8192)
configure voice ont service (XML download over OMCI)
configure cmts vcm-oam (DPoE DOCSIS Provisioning Framework)
configure pon sec-uri-profile (improved profile specification)
configure tr069serv ont (improved profile specification)
configure voice ont mgc-config (improved profile specification)
configure voice ont ringing-profile (improved profile specification)
configure voice ont sec-uri-profile (improved profile specification)
configure voice ont sip-config (improved profile specification)
configure voice ont voice-serv-prof (improved profile specification)
configure voice ont voip-app-service (improved profile specification)
configure voice ont voip-config (improved profile specification)
configure voice ont voip-media-prof (improved profile specification)
configure voice ont tone-event-prof alert-tone (improved profile specification)
configure voice ont tone-event-prof busy-tone (improved profile specification)
configure voice ont tone-event-prof callwait1-tone (improved profile specification)
configure voice ont tone-event-prof callwait2-tone (improved profile specification)
configure voice ont tone-event-prof callwait3-tone (improved profile specification)
configure voice ont tone-event-prof callwait4-tone (improved profile specification)
configure voice ont tone-event-prof confirm-tone (improved profile specification)
configure voice ont tone-event-prof congest-tone (improved profile specification)
configure voice ont tone-event-prof dead-tone (improved profile specification)
configure voice ont tone-event-prof dial-tone (improved profile specification)

configure voice ont tone-event-prof intrusion-tone (improved profile specification)
configure voice ont tone-event-prof msg-wait-tone (improved profile specification)
configure voice ont tone-event-prof release-tone (improved profile specification)
configure voice ont tone-event-prof reorder-tone (improved profile specification)
configure voice ont tone-event-prof ringback-tone (improved profile specification)
configure voice ont tone-event-prof roh-tone (improved profile specification)
configure voice ont tone-event-prof special-dial-tone (improved profile specification)
configure voice ont tone-event-prof special-info-tone (improved profile specification)
configure voice ont tone-event-prof stutter-tone (improved profile specification)
configure voice ont tone-event-prof userdef1-tone (improved profile specification)
configure voice ont tone-event-prof userdef2-tone (improved profile specification)
configure voice ont tone-event-prof userdef3-tone (improved profile specification)
configure voice ont tone-event-prof userdef4-tone (improved profile specification)
configure voice ont voice-port (improved profile specification)
configure voice ont voice-sip-port (improved profile specification)
configure voice ont ringing-profile name (improved setting of ringing profile attributes)

New Commands

admin ethernet statistics (support RMON counters on NELT-B interfaces)
show ethernet etherstats (support RMON counters on NELT-B interfaces)
show cfm slm-responder-stats (SLM Responder on CATAN VDSL LT and NELT-B UNI)
show cfm slm-responder-stats domain (SLM Responder on CATAN VDSL LT and NELT-B UNI)
show vlan port-accumu-stats (support display of accumulate statistics on the bridge port)
show alarm current ihub-tca (support IHUB Threshold Crossing Alert)
show alarm log ihub-tca (support IHUB Threshold Crossing Alert)
show alarm snap-shot ihub-tca (support IHUB Threshold Crossing Alert)
configure cm classifier (DPoE commands for Service Flow provisioning)
configure cm cm-static (DPoE commands for Service Flow provisioning)
configure cm gen-ext (DPoE commands for Service Flow provisioning)
configure cm oam (DPoE commands for Service Flow provisioning)
configure cm service-flow (DPoE commands for Service Flow provisioning)
configure cm sf-collection (DPoE commands for Service Flow provisioning)
configure cm tlv-file (DPoE commands for Service Flow provisioning)
show alarm current ont-ces (CLI support for GPON alarms phase 2)
show alarm current ont-cese1 (CLI support for GPON alarms phase 2)
show alarm current ont-hpna (CLI support for GPON alarms phase 2)
show alarm current ont-mgc (CLI support for GPON alarms phase 2)
show alarm current ont-pwe (CLI support for GPON alarms phase 2)

show alarm current ont-sip-agent-cfg (CLI support for GPON alarms phase 2)
show alarm current ont-video (CLI support for GPON alarms phase 2)
show alarm current ont-video-ani (CLI support for GPON alarms phase 2)
show alarm current ont-voip (CLI support for GPON alarms phase 2)
show alarm current ont-voip-cfg (CLI support for GPON alarms phase 2)
show alarm current ont-xdsl (CLI support for GPON alarms phase 2)
show alarm current ont-xdsl-tca (CLI support for GPON alarms phase 2)
show alarm log ont-ces (CLI support for GPON alarms phase 2)
show alarm log ont-cese1 (CLI support for GPON alarms phase 2)
show alarm log ont-hpna (CLI support for GPON alarms phase 2)
show alarm log ont-mgc (CLI support for GPON alarms phase 2)
show alarm log ont-pwe (CLI support for GPON alarms phase 2)
show alarm log ont-sip-agent-cfg (CLI support for GPON alarms phase 2)
show alarm log ont-video (CLI support for GPON alarms phase 2)
show alarm log ont-video-ani (CLI support for GPON alarms phase 2)
show alarm log ont-voip (CLI support for GPON alarms phase 2)
show alarm log ont-voip-cfg (CLI support for GPON alarms phase 2)
show alarm log ont-xdsl (CLI support for GPON alarms phase 2)
show alarm log ont-xdsl-tca (CLI support for GPON alarms phase 2)
show alarm snap-shot ont-ces (CLI support for GPON alarms phase 2)
show alarm snap-shot ont-cese1 (CLI support for GPON alarms phase 2)
show alarm snap-shot ont-hpna (CLI support for GPON alarms phase 2)
show alarm snap-shot ont-mgc (CLI support for GPON alarms phase 2)
show alarm snap-shot ont-pwe (CLI support for GPON alarms phase 2)
show alarm snap-shot ont-sip-agent-cfg (CLI support for GPON alarms phase 2)
show alarm snap-shot ont-video (CLI support for GPON alarms phase 2)
show alarm snap-shot ont-video-ani (CLI support for GPON alarms phase 2)
show alarm snap-shot ont-voip (CLI support for GPON alarms phase 2)
show alarm snap-shot ont-voip-cfg (CLI support for GPON alarms phase 2)
show alarm snap-shot ont-xdsl (CLI support for GPON alarms phase 2)
show alarm snap-shot ont-xdsl-tca (CLI support for GPON alarms phase 2)
show pon unprovision-onu (CLI support for GPON alarms phase 2)
show system sync-if-timing-ptp (Synchronisation Redundancy for BITS/SyncE/IEEE1588)

Removed Commands or Commands with removed parameters

show alarm current ont-loopdetect-mis (removal of obsolete command)
show alarm log ont-loopdetect-mis (removal of obsolete command)
show alarm snap-shot ont-loopdetect-mis (removal of obsolete command)

configure system snmp manager (improved usage of SNMPv3, dpoe parameter removed)
--

New Commands NOT supported yet

configure xdsl-bonding [no] group-rtx-profile (2-pair VDSL2 PTM bonding in combination with G.inp)
show xdsl-bonding group-rtx-profiles (2-pair VDSL2 PTM bonding in combination with G.inp)
configure equipment ont interface phy-layer (for future use, support XGPON)
configure equipment ont interface xg-tc-layer (for future use, support XGPON)
configure pon interface phy-layer (for future use, support XGPON)
configure pon interface fec-tc-layer (for future use, support XGPON)
configure pon interface xg-tc-layer (for future use, support XGPON)
show equipment ont fec-tc-layer olt-side (for future use, support XGPON)
show equipment ont fec-tc-layer olt-side current-intervalfor future use, support XGPON)
show equipment ont phy-layerfor future use, support XGPON)
show equipment ont phy-layer olt-sidefor future use, support XGPON)
show equipment ont phy-layer olt-side current-intervalfor future use, support XGPON)
show equipment ont xg-tc-layerfor future use, support XGPON)
show equipment ont xg-tc-layer olt-sidefor future use, support XGPON)
show equipment ont xg-tc-layer olt-side current-intervalfor future use, support XGPON)
show equipment ont xg-tc-layer olt-side previous-intervalfor future use, support XGPON)
show equipment ont xg-tc-layer ont-sidefor future use, support XGPON)
show equipment ont xg-tc-layer ont-side current-intervalfor future use, support XGPON)
show equipment ont xg-tc-layer ont-side previous-intervalfor future use, support XGPON)
show pon interface fec-tc-layerfor future use, support XGPON)
show pon interface fec-tc-layer current-intervalfor future use, support XGPON)
show pon interface phy-layerfor future use, support XGPON)
show pon interface phy-layer current-intervalfor future use, support XGPON)
show pon interface xg-tc-layerfor future use, support XGPON)
show pon interface xg-tc-layer current-interval for future use, support XGPON)
show pon interface xg-tc-layer previous-interval for future use, support XGPON)
show alarm current mdu (alarm for future use)
show alarm current mdu-gen (alarm for future use)
show alarm current mdu-ploam (alarm for future use)
show alarm current sfu (alarm for future use)
show alarm current sfu-gen (alarm for future use)
show alarm current sfu-ploam (alarm for future use)
show alarm current soho (alarm for future use)
show alarm current soho-gen (alarm for future use)
show alarm current soho-ploam (alarm for future use)

show alarm log mdu (alarm for future use)
show alarm log mdu-gen (alarm for future use)
show alarm log mdu-ploam (alarm for future use)
show alarm log sfu (alarm for future use)
show alarm log sfu-gen (alarm for future use)
show alarm log sfu-ploam (alarm for future use)
show alarm log soho (alarm for future use)
show alarm log soho-gen (alarm for future use)
show alarm log soho-ploam (alarm for future use)
show alarm snap-shot mdu (alarm for future use)
show alarm snap-shot mdu-gen (alarm for future use)
show alarm snap-shot mdu-ploam (alarm for future use)
show alarm snap-shot sfu (alarm for future use)
show alarm snap-shot sfu-gen (alarm for future use)
show alarm snap-shot sfu-ploam (alarm for future use)
show alarm snap-shot soho (alarm for future use)
show alarm snap-shot soho-gen (alarm for future use)
show alarm snap-shot soho-ploam (alarm for future use)

Commands with new parameters or parameter values that are NOT supported yet (commands remain backward compatible with previous releases)

configure xdsl line (new parameter "auto-switch" to switch between ATMoADSL and PTMoVDSL)
configure xdsl-bonding group (2-pair VDSL2 PTM bonding in combination with G.inp)
show xdsl-bonding operational-data group (2-pair VDSL2 PTM bonding in combination with G.inp)
configure equipment ont interface fec-tc-layer (for future use, support XGPON)
configure pon interface (for future use, support XGPON)

Commands with new parameters or parameter values with LIMITED support. (commands are NOT backward compatible with previous releases. Note : configure maximum only one IEEE1588 clock source. In duplex NT mode, this clock source can be configured on either NT-A or NT-B, independently of which one is the active one. The NT that has the clock source configured will pass on the signal to its peer NT)

configure system sync-if-timing ref-order (Synchronisation Redundancy for BITS/SyncE/IEEE1588 parameter value "ieee1588" replaced by "ieee1588-a" or "ieee1588-b")
configure system sync-if-timing ssm-order (Synchronisation Redundancy for BITS/SyncE/IEEE1588 parameter value "ieee1588" replaced by "ieee1588-a" or "ieee1588-b")
configure system sync-if-timing ptp ptp-domain (Synchronisation Redundancy for BITS/SyncE/IEEE1588 parameter value "ieee1588" replaced by "ieee1588-a" or "ieee1588-b")

Command delta R4.6 versus R4.5.02

Modified Commands
configure bridge port [no] vlan-id (implement dedicated downstream voice queue, for VOIP services on both VOIP and VEIP UNI's)
configure cfm domain association [no] mep (Y.1731 SLM Responder on CATAN based VDSL LT's and NELT-B UNI)
configure cfm domain association [no] name (improvement : [no] command removed)
configure equipment sfpe1t1 framer (removal of obsolete loopback parameters)
configure mcast static [no] branch (GPON static Multicast per ONT, add AID for GPON vlan port)
configure qos profiles [no] bandwidth (support for MEF qualification MIB Impact)
configure qos profiles [no] l3-filter (support L3 ACLs in an IPv6 context)
configure system (PPPoE / DHCP customer-id configuration at system level)
configure system pon-ont (SN bundle with LOID or SLID)
configure system security snmp [no] community (DOCSIS Provisioning Framework)
configure system security snmp [no] group (DOCSIS Provisioning Framework)
configure system security snmp [no] manager (DOCSIS Provisioning Framework)
configure voice sip redundancy (Configurable DNS Selection Algorithm)
configure xdsl [no] service-profile (increase the number of service profiles to 1024)
configure xdsl line [no] service-profile (increase the number of service profiles to 1024)
configure xdsl board vect-fallback [no] service-profile (increase the number of service profiles to 1024)
show system license (MPLS ring with sub 50 ms switchover)
show cfm mep-configdata domain (Y.1731 SLM Responder on CATAN based VDSL LT's and NELT-B UNI)
show cfm mep-info domain (improvement : displays each field of a CCM packet)
configure bridge port (Support for Multiple LLID on EPON ONU for DPoE)
configure system (Support for Multiple LLID on EPON ONU for DPoE)
configure qos (Support for Multiple LLID on EPON ONU for DPoE)
configure vlan (Support for Multiple LLID on EPON ONU for DPoE)
configure arp-relay (Support for Multiple LLID on EPON ONU for DPoE)
configure qos interface ellid (Support for Multiple LLID on EPON ONU for DPoE)
configure alarm entry (new alarms for several features)
configure epon profiles [no] filter (improvement : [no] value added for classfandv and classac)
configure equipment eont [no] interface (support for Multiple LLID for ISAM EPON QoS and Forwarding Model)
configure equipment eont interface management (support for Multiple LLID for ISAM EPON QoS and Forwarding Model)
configure equipment ont [no] interface (SN bundle with LOID or SLID and DSCP to pbit alignment for PPPoE frames on GPON LT)
configure system syslog (DOCSIS Provisioning Framework)
configure uni ont video (RF Video service timer configuration)
show equipment ont interface (SN bundle with LOID or SLID)

show epon interface information (OLT supports new MIB interface towards OSS)
show equipment eont llid (support for Multiple LLID on EPON ONU for DPoE)
configure equipment eont interface llid (support for Multiple LLID on EPON ONU for DPoE)
configure ethernet eont port (support for Multiple LLID for ISAM EPON QoS and Forwarding Model)
configure voice ont mgc-config (improvement : parameters "pri-mgcuri-profid" and "sec-mgcuri-profid" changed to required parameters)

Removed Commands or Commands with removed parameters

configure equipment sfpe1t1 global (removal of obsolete loopback commands)
configure alarm entry (removal of obsolete alarms lt-problem and applique-problem)

New Commands

configure cfm slm (Y.1731 SLM Responder on CATAN based VDSL LT's and NELT-B UNI)
show ethernet dot3stats (ether-like counters on NELT-B, replaces show transport ether-ifdot3lt)
show ethernet mau (replaces "show transport ether-ifmault" for NELT-B MAU operational data)
show ethernet sfp (replaces "show transport ether-ifsfp" for NELT-B SFP inventory data)
configure cmts (DPoE DOCSIS Provisioning Framework)
configure cmts [no] allowonu (DPoE DOCSIS Provisioning Framework)
configure cmts [no] bundle (DPoE DOCSIS Provisioning Framework)
configure cmts [no] cert (DPoE DOCSIS Provisioning Framework)
configure cmts [no] class (DPoE DOCSIS Provisioning Framework)
configure cmts [no] cm-event (DPoE DOCSIS Provisioning Framework)
configure cmts [no] diag (DPoE DOCSIS Provisioning Framework)
configure cmts [no] filter (DPoE DOCSIS Provisioning Framework)
configure cmts [no] interface (DPoE DOCSIS Provisioning Framework)
configure cmts [no] l2vpn (DPoE DOCSIS Provisioning Framework)
configure cmts [no] log-level (DPoE DOCSIS Provisioning Framework)
configure cmts [no] oosp (DPoE DOCSIS Provisioning Framework)
configure cmts [no] pon (DPoE DOCSIS Provisioning Framework)
configure cmts [no] sav (DPoE DOCSIS Provisioning Framework)
configure cmts [no] serving-group (DPoE DOCSIS Provisioning Framework)
configure cmts [no] subscriber-def (DPoE DOCSIS Provisioning Framework)
configure cmts [no] system (DPoE DOCSIS Provisioning Framework)
configure cmts [no] vcm-oam (DPoE DOCSIS Provisioning Framework)
configure cmts [no] x509 (DPoE DOCSIS Provisioning Framework)
configure dpoe plt [no] adminstate (DPoE DOCSIS Provisioning Framework)
show cable (DPoE DOCSIS Provisioning Framework)
show dpoe (DPoE DOCSIS Provisioning Framework)

show dpoe plt (DPoE DOCSIS Provisioning Framework)
show dpoe olt (DPoE DOCSIS Provisioning Framework)
show dpoe onu (DPoE DOCSIS Provisioning Framework)
show interface dpoe (DPoE DOCSIS Provisioning Framework)
configure equipment ont loop (OLT support loop detection and alarm function)
show alarm current ont-loopdetect (OLT support loop detection and alarm function)
show alarm current ont-loopdetect-mis (OLT support loop detection and alarm function)
show alarm log ont-loopdetect (OLT support loop detection and alarm function)
show alarm log ont-loopdetect-mis (OLT support loop detection and alarm function)
show alarm snap-shot ont-loopdetect (OLT support loop detection and alarm function)
show alarm snap-shot ont-loopdetect-mis (OLT support loop detection and alarm function)
configure trouble-shooting pon statistics threshold [no interval (GPON OLT PM counter)
configure trouble-shooting pon statistics threshold interface (GPON OLT PM counter)
show alarm current olt-ont-tc-tca (CLI support for GPON alarms)
show alarm current alarm-table (CLI support for GPON alarms)
show alarm current olt-pon-tc-tca (CLI support for GPON alarms)
show alarm current ont-card (CLI support for GPON alarms)
show alarm current ont-gen (CLI support for GPON alarms)
show alarm current ont-iphost (CLI support for GPON alarms)
show alarm current ont-l2uni-eth-tca (CLI support for GPON alarms)
show alarm current ont-lan (CLI support for GPON alarms)
show alarm current ont-ploam (CLI support for GPON alarms)
show alarm current ont-pots (CLI support for GPON alarms)
show alarm current ont-pots-supplemental (CLI support for GPON alarms)
show alarm current rsvp (CLI support for GPON alarms)
show alarm current ont-tc-tca (CLI support for GPON alarms)
show alarm current ont-veip (CLI support for GPON alarms)
show alarm log olt-ont-tc-tca (CLI support for GPON alarms)
show alarm log alarm-table (CLI support for GPON alarms)
show alarm log olt-pon-tc-tca (CLI support for GPON alarms)
show alarm log ont-card (CLI support for GPON alarms)
show alarm log ont-gen (CLI support for GPON alarms)
show alarm log ont-iphost (CLI support for GPON alarms)
show alarm log ont-l2uni-eth-tca (CLI support for GPON alarms)
show alarm log ont-lan (CLI support for GPON alarms)
show alarm log ont-ploam (CLI support for GPON alarms)
show alarm log ont-pots (CLI support for GPON alarms)

show alarm log ont-pots-supplemental (CLI support for GPON alarms)
show alarm log rsvp (CLI support for GPON alarms)
show alarm log ont-tc-tca (CLI support for GPON alarms)
show alarm log ont-veip (CLI support for GPON alarms)
show alarm snap-shot olt-ont-tc-tca (CLI support for GPON alarms)
show alarm snap-shot alarm-table (CLI support for GPON alarms)
show alarm snap-shot olt-pon-tc-tca (CLI support for GPON alarms)
show alarm snap-shot ont-card (CLI support for GPON alarms)
show alarm snap-shot ont-gen (CLI support for GPON alarms)
show alarm snap-shot ont-iphost (CLI support for GPON alarms)
show alarm snap-shot ont-l2uni-eth-tca (CLI support for GPON alarms)
show alarm snap-shot ont-lan (CLI support for GPON alarms)
show alarm snap-shot ont-ploam (CLI support for GPON alarms)
show alarm snap-shot ont-pots (CLI support for GPON alarms)
show alarm snap-shot ont-pots-supplemental (CLI support for GPON alarms)
show alarm snap-shot rsvp (CLI support for GPON alarms)
show alarm snap-shot ont-tc-tca (CLI support for GPON alarms)
show alarm snap-shot ont-veip (CLI support for GPON alarms)
show equipment eont loid-mapping (OLT supports new MIB interface towards OSS)
show equipment eont mac-mapping (OLT supports new MIB interface towards OSS)

New Commands not supported yet

configure xdsl-bonding [no] group-rtx-profile (2-pair VDSL2 PTM bonding in combination with G.inp)
show xdsl-bonding group-rtx-profiles (2-pair VDSL2 PTM bonding in combination with G.inp)

Commands with new parameters or parameter values that are NOT supported yet (commands remain backward compatible with previous releases)

configure xdsl line (new parameter "auto-switch" to switch between ATMoADSL and PTMoVDSL)
configure xdsl-bonding group (2-pair VDSL2 PTM bonding in combination with G.inp)

Command delta R4.5.02 versus R4.5.01

Modified Commands

configure alarm entry (support new alarms for different features)
configure bridge port vlan-id (MAC learning control per vlanport on GPON LT)
configure cfm domain association (CFM Enhancement to support CCM messages)
configure cfm domain association mep (CFM Enhancement to support CCM messages)
show cfm mep-config-data domain (CFM Enhancement to support CCM messages)

show cfm ma-config-data domain (CFM Enhancement to support CCM messages)
configure qos interface upstream-queue (Traffic Rate Limiting per GEM port)
configure qos profiles marker [no] d1p-alignment (support for multiple DSCP to pbit mapping profiles)
configure voice sip [no] termination (ANSI E911 Emergency Call features for SIP)
configure xdsl board (vectoring functionality on NRCD-C REM controller board, Cross-DSLAM vectoring)
configure xdsl vp-board (vectoring functionality on NRCD-C REM controller board, Cross-DSLAM vectoring)
Show alarm log vect-board (vectoring functionality on NRCD-C REM controller board, Cross-DSLAM vectoring)
Show alarm current vect-board (vectoring functionality on NRCD-C REM controller board, Cross-DSLAM vectoring)
Show alarm snap-shot vect-board (vectoring functionality on NRCD-C REM controller board, Cross-DSLAM vectoring)
show xdsl vp-board (vectoring functionality on NRCD-C REM controller board, Cross-DSLAM vectoring)
Show xdsl vect-group (vectoring functionality on NRCD-C REM controller board, Cross-DSLAM vectoring)
Show xdsl failure-status vect-board (vectoring functionality on NRCD-C REM controller board, Cross-DSLAM vectoring)
configure xdsl board vect-fallback (allows fallback mode for configuration not feasible,Cross-DSLAM Vectoring)
show xdsl vect-carrier-data far-end (Cross-DSLAM full vectoring support)
show xdsl vect-carrier-data near-end (Cross-DSLAM full vectoring support)
configure ani ont rssi-profile (ONU RSSI support, only FX-7360 for FANT-F NGLT-A/C FGLT-A)
configure equipment [no] rssiprof (ONU RSSI support, only FX-7360 for FANT-F NGLT-A/C FGLT-A)
configure pon interface (GPON OLT G.988 amd1 compliant ONU LOID authentication)
configure voice ont pots (POTS related VOIP PM feature in VEIP mode)
configure voice ont pots-rtp (POTS related VOIP PM feature in VEIP mode)
configure voice ont pots-call (POTS related VOIP PM feature in VEIP mode)
show voice ont call-hist (POTS related VOIP PM feature in VEIP mode)
show voice ont pots operational-data (POTS related VOIP PM feature in VEIP mode)
show voice ont pots-rtp statistics current-15min (POTS related VOIP PM feature in VEIP mode)
show voice ont pots-call statistics current-15min (POTS related VOIP PM feature in VEIP mode)

Removed Commands or Commands with removed parameters

show system license cci-enabled-mep (replaced by "show system license eth-oam-adv-mon")
show interface port (obsolete parameter value "ethernet" is not applicable in this context)
show interface stack (obsolete parameter value "ethernet" is not applicable in this context)
show interface test (obsolete parameter value "ethernet" is not applicable in this context)

New Commands
admin interface trouble-shooting ethernet statistics (troubleshooting counters on the FD-REM link)
show interface trouble-shooting ethernet statistics (troubleshooting counters on the FD-REM link)
configure cfm domain association remote-mep (CFM Enhancement to support CCM messages)
show alarm current cfm (CFM Enhancement to support CCM messages)
show alarm log cfm (CFM Enhancement to support CCM messages)
show alarm snap-shot cfm (CFM Enhancement to support CCM messages)
show cfm ccm-database (CFM Enhancement to support CCM messages)
show cfm ccm-database domain (CFM Enhancement to support CCM messages)
show cfm mep-info domain (CFM Enhancement to support CCM messages)
show alarm current efm-oam (DSL/ETH LT 802.3ah Critical Event Notification support)
show alarm log efm-oam (DSL/ETH LT 802.3ah Critical Event Notification support)
show alarm snap-shot efm-oam (DSL/ETH LT 802.3ah Critical Event Notification support)
configure pppox-relay cross-connect engine (troubleshooting improvement for PPP Relay with MAC concentration)
show alarm current pppcc-engine-tca (troubleshooting improvement for PPP Relay with MAC concentration)
show alarm log pppcc-engine-tca (troubleshooting improvement for PPP Relay with MAC concentration)
show alarm snap-shot pppcc-engine-tca (troubleshooting improvement for PPP Relay with MAC concentration)
show pppox-relay cross-connect trouble-shooting-cntrs engine curr-15min-stats (troubleshooting improvement for PPP Relay with MAC concentration)
show pppox-relay cross-connect trouble-shooting-cntrs engine curr-1day-stats (troubleshooting improvement for PPP Relay with MAC concentration)
show pppox-relay cross-connect trouble-shooting-cntrs engine prev-15min-stats (troubleshooting improvement for PPP Relay with MAC concentration)
show pppox-relay cross-connect trouble-shooting-cntrs engine prev-1day-stats (troubleshooting improvement for PPP Relay with MAC concentration)
configure qos profiles [no] dscp-pbit (support for multiple DSCP to pbit mapping profiles)
configure qos profiles codepoint (support for multiple DSCP to pbit mapping profiles)
show qos profile-usage dscp-pbit (support for multiple DSCP to pbit mapping profiles)
show system license eth-oam-adv-mon (replaces "show system license cci-enabled-mep")
show voice ont pots-call statistics prev-15min (POTS related VOIP PM feature in VEIP mode)
show voice ont pots-rtp statistics prev-15min (POTS related VOIP PM feature in VEIP mode)
Commands with new parameters or parameter values that are NOT supported yet (commands remain backward compatible with previous releases)
configure xdsl line (new parameter "auto-switch" to switch between ATMoADSL and PTMoVDSL)

Command delta R4.5.01 versus R4.5

Modified Commands

configure alarm entry (new parameter values allowed)
configure bridge [no] port (regeneration profile selection by name)
configure debug-trace [no] protocol-trace (Protocol tracing on NGLT-A/C)
configure equipment eont [no] interface (to configure ONT TPID)
configure equipment eont interface [no] llid (to configure the name of the protocol profile to be mapped on ellid)
configure equipment eont interface llid rate-limit-prof (to configure profile name to be associated)
configure equipment ont [no] slot (commands for NNI feature)
configure igmp [no] channel (to configure IGMP Message rate per IGMP control channel)
configure voice cluster equipment [no] termination (Allows to configure the codec type used at TDM side. Change for feature support ISDN G.711 A-law and u-law terminals)
configure voice sip [no] dialplan (change for feature Digitmap minimum match)
configure voice sip [no] termination (change for feature Hotline (FDC-I) and Warmline (FDC-T) subscriber control by IMS NOTIFY and call waiting, call transfer, call hold, call conference)
configure voice sip redundancy (change for feature Foreground Monitoring Enhancement)
configure voice sip user-agent-ap slot-id (change for feature DHCP Option 82)
configure voice sip vsp (change for feature Subscribe and DHCP Option 82 and Fax/Modem negotiation)
configure voice sip system session-timer (Change for feature Session Timer Refresher)
configure xdsl board (extended with auto-discovery functionality, vectoring processing board in controller slot)
configure xdsl spectrum-profile vdsl2 (New UPBO method or Alternative Electrical Length Estimation Mode)
configure xdsl vp-board vp-link (nbr of vectored lines per vectoring processing board increased, vp-board in controller slot)
configure xdsl [no] vect-profile (introducing new parameters in the vect-profile to configure crosstalk cancellation from legacy lines into G.vector lines in downstream)
show config-data-port bridge-port (for regeneration profile selection)
show system license (adding a new license counter, vectoring-legacy, for the introduction of crosstalk cancellation from legacy lines into G.vector lines in downstream)
show voice sip termination (Show Voice SIP Termination Status)
show xdsl config-data-port bridge-port (for regeneration profile selection)
show xdsl failure-status vect-board (vectoring processing board in controller slot)
show xdsl vect-disturber-list downstream (nbr of vectored lines per vectoring processing board increased, disturber-list parameter modified)
show xdsl vp-board (nbr of vectored lines per vectoring processing board increased, vp-board in controller slot)

Removed Commands

none

New Commands

configure qos nni-ctrl-pkt-policer (to configure OBC policer for NNI port)
configure qos profiles [no] rate-limit (IPv6 protocol policer per LLID on FX 10G/EPON)
configure system auto-laser-shutdown (Configurable ALS)
show alarm current efm-oam (new alarm)
show alarm current ellid (new alarm)
show alarm current eth-cfm (new alarm)
show alarm log efm-oam (new alarm)
show alarm log ellid (new alarm)
show alarm log eth-cfm (new alarm)
show alarm snap-shot efm-oam (new alarm)
show alarm snap-shot ellid (new alarm)
show alarm snap-shot eth-cfm (new alarm)
show qos profile-usage rate-limit (show IPv6 protocol policer)
show vlan prio-regen-name (show regeneration profile selection by name)
show vlan prio-regen-next (show next regeneration profile selection)
show voice sip redundancy-node ext-redundancy-state (change for feature Autonomous fail-over indication)
show xdsl vect-disturber-list upstream (nbr of vectored lines per vectoring processing board increased, disturber-list parameter modified)
show xdsl vect-group (cross-dslam vectoring, vp-board in controller slot)

Commands with new parameters or parameter values that are NOT supported yet (commands remain backward compatible with previous releases)

configure qos profiles marker [no] d1p-alignment

New Commands that are NOT supported yet

configure qos profiles [no] dscp-pbit

configure qos profiles dscp-pbit codepoint

show qos profile-usage dscp-pbit-prof

Command delta R4.5 versus R4.4.02

Modified Commands

configure alarm entry (to configure alarms on E1/DS1 SFP)

configure epon [no] interface ('no interface' possibility added)

configure equipment eont [no] interface (DPoE Link OAM, added parameter alarm-profile and Upmode dpoe)

configure equipment eont [no] sw-ctrl (DPoE Link OAM)

configure equipment eont interface [no] port (adding a parameter to enable/disable the shutdown action of an ONU port ico loopback detection)

configure ethernet eont port [no] filter (parameter type for dot1p modified)
configure ethernet line mau (to configure autoneg capabilities)
configure linetest single ltparm test-name (values for MELT added)
configure linetest single ltsession (Increase test parameters for MELT)
configure voice sip [no] termination (to match CDE splitters schematic change)
show linetest single lineid-ext-rept (Increase test parameters for MELT)
show xdsl vp-board (new display elements)

Removed Commands

admin alarm (removed parameter clr-shub-config-loss)
--

New Commands

admin alarm (new parameter names)
admin display-config (displays the complete ihub configuration)
admin pppoe-client emulation client-id (to start or stop the PPPoE emulation of a specific interface on a PPPoE client)
configure epon alarm [no] flag (to configure the EPON alarm state definition in compliance with the latest CTC specification 2 and 3.0)
configure epon profiles [no] ontalarm (to configure selective ONU alarm reporting on the OLT)
configure equipment ont interface ethernet (New node ethernet has been introduced to enable/disable PON Aggregate Ethernet Performance Monitoring)
configure equipment sfpe1t1 (to configure the E1 service on E1/DS1 SFP)
configure pppoe-client (to configure the emulation interface on a PPPoE client port)
show alarm current eolt-ont-tca (to show DPoE alarms)
show alarm current eont-phyoam (to show DPoE alarms)
show alarm current eont-services-lan (to show DPoE alarms)
show alarm current eont-sw-dl (to show DPoE alarms)
show alarm current epon (to show DPoE alarms)
show alarm current olt-gen (to show DPoE alarms)
show alarm current sfpe1t1-clock (to show the alarm on E1/DS1 SFP)
show alarm current sfpe1t1-framer (to show the alarm on E1/DS1 SFP)
show alarm log epon (to show DPoE alarms)
show alarm log olt-gen (to show DPoE alarms)
show alarm log sfpe1t1-clock (to show the alarm on E1/DS1 SFP)
show alarm log sfpe1t1-framer (to show the alarm on E1/DS1 SFP)
show epon profiles-usage ontalarm (to retrieve the configured ONU alarm control bitmap on the OLT)
show epon unprovision-onu (to show DPoE alarms)
show equipment ont ethernet current-interval (to retrieve ONT-side Ethernet current interval PM data)
show equipment ont ethernet previous-interval (to retrieve ONT-side Ethernet previous interval PM data)

show linetest single busy-status (to show test parameters for MELT)
show linetest single chipsetdata-for-slot (to show test parameters for MELT)
show pppoe-client (to retrieve the emulation details of PPPoE client interface)
show xdsl vect-disturber-list downstream (this command will replace "show xdsl vect-disturbers")

Commands with new parameters or parameter values that are NOT supported yet (commands remain backward compatible with previous releases)

admin efm-oam interface (traffgen-action parameter added)
configure efm-oam interface (new parameters for ethernet traffgen added)
configure equipment [no] rssiprof (new parameter types added for warnings and alarms)
configure equipment eont interface [no] llid (loop-back parameter added)
configure voice cluster equipment termination (parameter values for impedance added)
configure voice sip system session-timer (status enable-uas added)
configure voice sip vsp (subscribe parameters added, reneg-ct-mode value added)
configure xdsl board (vplt-autodiscover parameter added)
configure xdsl [no] vect-profile (introducing new parameters in the vect-profile to configure crosstalk cancellation from legacy lines into G.vector lines in downstream)
show system license (adding a new license counter, vectoring-legacy, for the introduction of crosstalk cancellation from legacy lines into G.vector lines in downstream)
show xdsl vect-carrier-data far-end (disturberline parameter type changed)
show xdsl vect-carrier-data near-end (disturberline parameter type changed)

New Commands that are NOT supported yet

configure equipment eont interface port [no]auto-adv-abili
configure qos profiles [no] rate-limit
configure system lldp
show alarm current ellid
show alarm current eoltrssi
show alarm log eoltrssi
show alarm snap-shot eoltrssi
show alarm snap-shot sfpe1t1-clock
show alarm snap-shot sfpe1t1-framer
show efm-oam int-traff-gen
show qos profile-usage rate-limit
show system lldp
show xdsl vect-disturber-list
show xdsl vect-disturber-list upstream
show xdsl vect-group

Command delta R4.4.02 versus R4.4

Modified Commands
configure epon interface (10G-EPON LT)
configure qos interface epon ext-cac (10G-EPON LT)
configure qos profiles scheduler-node ext-shaper (10G-EPON LT)
configure equipment eont interface (10G-EPON LT)
configure qos interface ellid upstream-queue 255 ext-bw (10G-EPON LT)
configure ethernet line (AUTO-SENSING fiber speed support for NELT-B)
Info configure ethernet line (AUTO-SENSING fiber speed support for NELT-B)
configure system epon (Rogue ONU discovery)
configure epon interface (Rogue ONU discovery)
show epon optics curidlepwr (Rogue ONU discovery)
configure voice ont service voip-index (SFU and MDU Voice XML file downloading over OMCI)
configure voice ont voip-media-prof (SFU and MDU Voice XML file downloading over OMCI)
configure xdsl board vect-fallback (Fall back configuration for vectoring)
configure alarm entry index (FR Fixing)
configure l2cp user-port partition-id (FR Fixing)
configure linetest single ltsession (FR Fixing)
configure system security snmp community host-address (SNMP relay from core0 to AI platform)
configure system security snmp group security-level (SNMP relay from core0 to AI platform)
show l2cp partition (FR Fixing)
show efm-oam oam-stats (OAM remote loopback in NELT-B)
configure qos interface eont ingress-profile (OAM support for downstream queuing and scheduling per SFU)
configure vlan id (Stacked iBridge)
Info configure vlan id (Stacked iBridge)
configure equipment fan-tray (SW support for ISAM FX intelligent fan)
configure equipment rack (SW support for ISAM FX intelligent fan)
configure port-protection port paired-port (FR Fixing)
show port-protection port (FR Fixing)
configure epon profiles (FR Fixing)
configure ethernet eont port (FR Fixing)
configure pon interface (FR Fixing)
New Commands
admin efm-oam (OAM remote Loopback support for NELT-B)
admin efm-oam interface interface loopback-action (OAM remote Loopback support for NELT-B)

admin epon (Rogue ONU discovery)
admin epon diagnostic (Rogue ONU discovery)
configure equipment eont interface rms (10G-EPON LT, Support of CU EPON C1 OAM)
show efm-oam loopback-info (OAM remote Loopback support for NELT-B)
show epon rogue (OAM remote Loopback support for NELT-B)
configure ai application (Application Intelligence Evolution)
configure ai platform (Application Intelligence Evolution)
configure ai platform xxx application (Application Intelligence Evolution)
show alarm log ai (Application Intelligence Evolution)
show alarm snap-shot ai (Application Intelligence Evolution)
show alarm current ai (Application Intelligence Evolution)
show ai application (Application Intelligence Evolution)
show ai platform (Application Intelligence Evolution)
show ai platform-application (Application Intelligence Evolution)
telnet-ai (Application Intelligence Evolution)

Removed Commands

configure port-protection primary-port paired-port (FR Fixing)
show pon protection (FR Fixing)
show port-protection primary-port (FR Fixing)

Command delta R4.4 versus R4.3.02

Modified Commands

configure qos interface (GEM port sharing, OMCI for remote MDU mgmt, GPON:CVLAN translation)
admin arp-relay-stats (OMCI for remote MDU management)
admin bridge learned-unicast-mac (OMCI for remote MDU management)
admin dhcp-relay port-stats (OMCI for remote MDU management)
admin dhcp-relay v6-port-stats (OMCI for remote MDU management)
admin igmp channel (OMCI for remote MDU management)
admin security ext-authenticator (OMCI for remote MDU management)
admin trouble-shooting interface (OMCI for remote MDU management)
configure arp-relay (OMCI for remote MDU management)
configure cfm domain (OMCI for remote MDU management, 2p VDSL2 bonding with vectoring in SLV)
configure cfm domain association (OMCI for remote MDU management)
configure dhcp-relay port-stats (OMCI for remote MDU management)
configure dhcp-relay v6-port-stats (OMCI for remote MDU management)
configure igmp (OMCI for remote MDU management)

configure interface port (OMCI for remote MDU management)
configure iphost (OMCI for remote MDU management)
configure pppox-relay cross-connect (OMCI for remote MDU management)
configure qos tca (OMCI for remote MDU management)
configure system security pae authenticator (OMCI for remote MDU management)
configure system security pae ext-authenticator (OMCI for remote MDU management)
configure system security pae port (OMCI for remote MDU management)
configure system sync-if-timing ssmout-ltport (OMCI for remote MDU management)
configure trouble-shooting statistics (OMCI for remote MDU management)
configure vlan port-protocol protocol-group (OMCI for remote MDU management)
configure vlan pbit-statistics (OMCI for remote MDU management)

Modified Commands

show igmp channel protocol (OMCI for remote MDU management)
show interface port (OMCI for remote MDU management, ATM Pseudowire)
show interface stack (OMCI for remote MDU management)
show interface test (OMCI for remote MDU management, ATM Pseudowire)
show iphost ont operational-data (OMCI for remote MDU management)
show iphost ont statistics current-15min (OMCI for remote MDU management)
show ipv6 users (OMCI for remote MDU management)
show mcast active-groups (OMCI for remote MDU management)
show mcast grp-membership (OMCI for remote MDU management)
show oper-data-port (OMCI for remote MDU management)
show pppox-relay cross-connect monitor-statistics client-port (OMCI for remote MDU management)
show pppox-relay cross-connect session client-port (OMCI for remote MDU management)
show pppox-relay cross-connect statistics client-port (OMCI for remote MDU management)
show qos interface-bandwidth (OMCI for remote MDU management)
show qos statistics queue current-15min (OMCI for remote MDU management)
show qos statistics queue prev-15min (OMCI for remote MDU management)
show security pae authenticator (OMCI for remote MDU management)
show security pae diagnostics (OMCI for remote MDU management)
show security pae eapol-stats (OMCI for remote MDU management)
show security pae port-details (OMCI for remote MDU management)
show security pae session-stats (OMCI for remote MDU management)
show vlan bridge-port-fdb (OMCI for remote MDU management)
show vlan cross-connect (OMCI for remote MDU management)
show vlan dup-mac-alarm (OMCI for remote MDU management)

Modified Commands
show vlan residential-bridge extensive (OMCI for remote MDU management)
show vlan residential-bridge summary (OMCI for remote MDU management)
show vlan vmac-bridge-port-fdb (OMCI for remote MDU management)
show xdsl config-data-port atm-pvc (OMCI for remote MDU management, ATM Pseudowire)
show xdsl oper-data-port igmp (OMCI for remote MDU management, ATM Pseudowire)
show trouble-shooting statistics interface (OMCI for remote MDU management, 2p VDSL2 bonding with vectoring in SLV)
show trouble-shooting statistics uni-interface (OMCI for remote MDU management, 2p VDSL2 bonding with vectoring in SLV)
configure bridge (OMCI for remote MDU management, SC VLAN and CVLAN attachment on untagged frames)
configure atm (ATM Pseudowire)
configure voice sip (ISAM-V SIP : Warmline)
configure voice sip vsp (ISAM-V SIP : Warmline)
configure equipment ont interface (OMCI for remote MDU management, GEM port sharing cross, GPON:CVLAN translation)
configure equipment ont slot (Support HPNA ONT)
configure alarm entry (2p VDSL2 bonding with vectoring in SLV)
configure qos interface upstream-queue (GPON:CVLAN translation)
configure xdsl-bonding gropu-profile (2p VDSL2 bonding with vectoring in SLV)
configure xdsl vect-profile (Vectoring feature extension)
configure vlan (GPON:CVLAN translation)
admin pon diagnostic (ONT Detection Enhancements)
show vlan current-15min-stats (EPON support extended, OMCI for remote MDU management)
show vlan current-day-stats (EPON support extended, OMCI for remote MDU management)
show vlan previous-15min-stats (EPON support extended, OMCI for remote MDU management)
show vlan vlan-day-stats (EPON support extended, OMCI for remote MDU management)
configure ethernet ont (ME extension for PoE management)

Modified Commands
configure cfm (Minor Bug Fixing)
configure interface alarm (Minor Bug Fixing)
configure linetest cluster ltparm test-name (Minor Bug Fixing)
configure linetest single ltparm test-name (CI Drop)
configure qos profiles (10G EPON)
configure trap (Minor Bug Fixing)
configure trap definition (Minor Bug Fixing)
configure syatem max-lt-link-speed (Minor Bug Fixing)

configure vlan unicast-mac vlan-id (OMCI for remote MDU management)
configure vlan vlan-port unicast-mac (OMCI for remote MDU management)
configure voice cluster equipment termination (OMCI for remote MDU management)
show arp-relay-stats (OMCI for remote MDU management)
show cfm stack (OMCI for remote MDU management)
show config-data-port (OMCI for remote MDU management)
show dhcp-relay session (OMCI for remote MDU management)
show dhcp-relay v6-port-stats (OMCI for remote MDU management)
show dhcp-relay port-stats (OMCI for remote MDU management)
show igmp channel counter (OMCI for remote MDU management)
show igmp channel miscellaneous (OMCI for remote MDU management)
show vlan port-15min-stats (OMCI for remote MDU management)
show vlan port-curr-15min-stats (OMCI for remote MDU management)
show vlan port-curr-day-stats (OMCI for remote MDU management)
show vlan port-event (OMCI for remote MDU management)
show vlan port-prev-day-stats (OMCI for remote MDU management)
configure system security snmp community host-address Minor Bug Fixing)

New Commands

admin cfm (CFM Application enhancement)
admin cfm ltm (CFM Application enhancement)
admin cfm ltm domain (CFM Application enhancement)
admin cfm mclbm (CFM Application enhancement)
admin cfm mclbm domain (CFM Application enhancement)
admin cfm uclbm domain (CFM Application enhancement)
configure port-protection (PON Redundancy for GPON Linecards)
show port-protection (PON Redundancy for GPON Linecards)
configure snmp-agent ont read-community write-community iphc-vlan (OMCI for remote MDU management)
configure dist-router (ATM Pseudowire)
configure dist-router mpls (ATM Pseudowire)
configure dist-service (ATM Pseudowire)
admin dist-service (ATM Pseudowire)
admin dist-service statistics (ATM Pseudowire)
admin dist-service statistics apipe-pvc (ATM Pseudowire)
show dist-service (ATM Pseudowire)
show dist-service statistics (ATM Pseudowire)
show dist-service statistics apipe-pvc (ATM Pseudowire)

show dist-service accessport-svc (ATM Pseudowire)
configure igmp mc-pon-vlan-xlate nrvlan ponvlan (Multicast Cross VLAN translation on FX)
configure bridge port vlan-id static-user ipv6-address (IPv6 anti-spoofing on FD and FX)
configure hpna (Support HPNA ONT)
configure hpna ont (Support HPNA ONT)
configure hpna ont port (Support HPNA ONT)
configure equipment eont interface (FX: RSSI support on NTandNTIO uplink port)
show epon interface (FX: RSSI support on NTandNTIO uplink port, EPON support extended)

New Commands

show epon interface current-15min (FX: RSSI support on NTandNTIO uplink port, EPON support extended)
show epon interface current-1day (FX: RSSI support on NTandNTIO uplink port, EPON support extended)
show epon interface previous-15min (FX: RSSI support on NTandNTIO uplink port, EPON support extended)
show epon interface previous-15min interval-num (FX: RSSI support on NTandNTIO uplink port, EPON support extended)
show epon interface previous-1day (FX: RSSI support on NTandNTIO uplink port, EPON support extended)
show epon interface previous-1day (pon-idx) interval-num (FX: RSSI support on NTandNTIO uplink port, EPON support extended)
show equipment eont tc-layer (FX: RSSI support on NTandNTIO uplink port, EPON support extended)
show equipment eont tc-layer current-15min (FX: RSSI support on NTandNTIO uplink port, EPON support extended)
show equipment eont tc-layer current-1day (FX: RSSI support on NTandNTIO uplink port, EPON support extended)
show equipment eont tc-layer previous-15min (FX: RSSI support on NTandNTIO uplink port, EPON support extended)
show equipment eont tc-layer previous-15min interval-num (FX: RSSI support on NTandNTIO uplink port, EPON support extended)
show equipment eont tc-layer previous-1day (FX: RSSI support on NTandNTIO uplink port, EPON support extended)
show equipment eont tc-layer previous-1day interval-num (FX: RSSI support on NTandNTIO uplink port, EPON support extended)
show equipment rssiprof (FX: RSSI support on NTandNTIO uplink port, EPON support extended)
show ethernet eont tc-layer current-15min (FX: RSSI support on NTandNTIO uplink port, EPON support extended)
show ethernet eont tc-layer current-1day (FX: RSSI support on NTandNTIO uplink port, EPON support extended)
show ethernet eont tc-layer previous-15min (FX: RSSI support on NTandNTIO uplink port, EPON support extended)
show ethernet eont tc-layer previous-15min interval-num (FX: RSSI support on NTandNTIO uplink port, EPON support extended)

show ethernet eont tc-layer previous-1day (FX: RSSI support on NTandNTIO uplink port, EPON support extended)
show ethernet eont tc-layer previous-1day interval-num (FX: RSSI support on NTandNTIO uplink port, EPON support extended)
configure equipment diagnostics sfp rssi-prof-id (VEIP and VEIP associated TR069MgtServer support)
configure pon auth-sec-prof (VEIP and VEIP associated TR069MgtServer support)
configure pon sec-uri-profile (VEIP and VEIP associated TR069MgtServer support)
configure pon uri-prof (VEIP and VEIP associated TR069MgtServer support)

New Commands

admin port-protection activate (Pon Redundancy)
configure bcmp (FX EPON features MIB readiness)
configure bcmp system (FX EPON features MIB readiness)
configure equipment rssiprof (RSSI CLI development)
configure eth-cfm (Core-0 changes for CFM in IHUB)
configure voice sip statistics (10G EPON)
configure voice sip statistics stats-config (10G EPON)
show alarm current ont (CI Drop)
show alarm current ontsnmp (CI Drop)
show alarm current sfrssi (CI Drop)
show alarm log ontsnmp (CI Drop)
show alarm log sfrssi (CI Drop)
show alarm snap-shot ontsnmp (CI Drop)
show alarm snap-shot sfrssi (CI Drop)
show bcmp (FX EPON features MIB readiness)
show bcmp counters (FX EPON features MIB readiness)
show eth-cfm (Core-0 changes for CFM in IHUB)
configure bridge port vlan-id static-user ipv6-address (IPv6 anti-spoofing on FD and FX)
show hpna (Support HPNA ONT)
show hpna ont (Support HPNA ONT)
show hpna ont performance-data (Support HPNA ONT)
show hpna ont performance-data current-interval (Support HPNA ONT)
show hpna ont performance-data previous-interval interval-nbr (Support HPNA ONT)
oam

New Commands

configure tr069serv (VEIP and VEIP associated TR069MgtServer support)
configure tr069serv ont securi-prof (VEIP and VEIP associated TR069MgtServer support)
show alarm current tr069serv (VEIP and VEIP associated TR069MgtServer support)

show alarm log tr069serv (VEIP and VEIP associated TR069MgtServer support)
show alarm snap-shot tr069serv (VEIP and VEIP associated TR069MgtServer support)
show pon pon-diagnostics (Rogue ONT Detection Enhancements)
show ethernet eont port fdb (EPON support extended)
show voice eont pots information (EPON support extended)
show voice eont pots statistics (EPON support extended)

Removed Commands

admin pon protection (AnytoAny Pon Redundancy)
configure pon interface protection secpon (AnytoAny Pon Redundancy)
show alarm current psc (DR6 Feature)
show alarm log psc (DR6 Feature)
show alarm snap-shot psc (DR6 Feature)

Command delta R4.3.02 and R4.3.01 versus R4.3

Modified Commands

configure alarm entry (Board Level Vectoring and System Level Vectoring alarms, Embedded OTDR on GPON LT)
configure alarm entry (BL Vectoring SL Vectoring)
configure xdsl line (BL Vectoring SL Vectoring)
configure xdsl board (BL Vectoring SL Vectoring)
show alarm log xdsl near-end (BL Vectoring SL Vectoring)
show alarm current xdsl (BL Vectoring SL Vectoring)
show alarm snap-shot xdsl (BL Vectoring SL Vectoring)
show alarm log (BL Vectoring SL Vectoring)
show alarm current (BL Vectoring SL Vectoring)
show alarm snap-shot (BL Vectoring SL Vectoring)
show alarm delta-log (BL Vectoring SL Vectoring)
show system license (BL Vectoring SL Vectoring)
show xdsl profiles (BL Vectoring SL Vectoring)
show xdsl operational-data near-end line (BL Vectoring SL Vectoring)
show xdsl carrier-data near-end (BL Vectoring SL Vectoring)
show xdsl carrier-data far-end (BL Vectoring SL Vectoring)
show xdsl failure-status far-end (BL Vectoring SL Vectoring)
show xdsl failure-status near-end (BL Vectoring SL Vectoring)
show xdsl counters near-end line current-interval (BL Vectoring SL Vectoring)
show xdsl counters near-end line current-1day (BL Vectoring SL Vectoring)

show xdsl counters near-end line previous-interval (BL Vectoring SL Vectoring)
show xdsl counters near-end line previous-1day (BL Vectoring SL Vectoring)
configure qos interface (Support for Ethernet DS and US queues on the ONT,GPON VLAN port level queues for upstream - OLT part)
configure qos interface upstream-queue (GPON VLAN port level queues for upstream)
configure qos tca queue (GPON VLAN port level queues for upstream)
configure voice cluster equipment (Configurable line gain and line impedance)
configure voice sip termination (Configurable line gain and line impedance)
show qos interface-bandwidth (GPON VLAN port level queues for upstream)
show qos statistics queue current-15min (GPON VLAN port level queues for upstream)
show qos statistics queue prev-15min (GPON VLAN port level queues for upstream)
configure equipment ont interface (GPON ONU LOID Authentication)
configure pon interface (GPON ONU LOID Authentication)
configure system security filetransfer (TFTP transfer blksize configurable)
configure xdsl overrule-data (Config of interleaver mem. split VDSL2)
configure xdsl service-profile (Config of interleaver mem. split VDSL2)
configure xdsl-bonding group-profile (enabling 8 port bonding in iSAM)
configure equipment ont (Support 24 POTS lines per POTS slot in FX/FD Platform)
configure voice ont pots (Support 24 POTS lines per POTS slot in FX/FD Platform)
configure voice ont voice-port (Support 24 POTS lines per POTS slot in FX/FD Platform)
configure voice ont pots-rtp (Support 24 POTS lines per POTS slot in FX/FD Platform)
configure voice ont voice-sip-port (Support 24 POTS lines per POTS slot in FX/FD Platform)
configure voice ont pots-call (Support 24 POTS lines per POTS slot in FX/FD Platform)
show equipment ont slot (Support 24 POTS lines per POTS slot in FX/FD Platform)
show voice ont call-hist (Support 24 POTS lines per POTS slot in FX/FD Platform)
show voice ont pots diagnostics (Support 24 POTS lines per POTS slot in FX/FD Platform)
show voice ont pots pb-dial-tone (Support 24 POTS lines per POTS slot in FX/FD Platform)
show voice ont pots sip-dial-tone (Support 24 POTS lines per POTS slot in FX/FD Platform)
show voice ont pots operational-data (Support 24 POTS lines per POTS slot in FX/FD Platform)
show voice ont pots hookstate (Support 24 POTS lines per POTS slot in FX/FD Platform)
show voice ont pots-rtp statistics current-15min (Support 24 POTS lines per POTS slot in FX/FD Platform)
show voice ont pots-call statistics current-15min (Support 24 POTS lines per POTS slot in FX/FD Platform)
admin voice ont pots diagnostics (Support 24 POTS lines per POTS slot in FX/FD Platform)
admin voice ont pots pb-dial-tone (Support 24 POTS lines per POTS slot in FX/FD Platform)
admin voice ont pots sip-dial-tone (Support 24 POTS lines per POTS slot in FX/FD Platform)
configure qos profile policer (CCL on NELT-B NNI and Extend EBS range to improve TCP goodput)
show alarm log otdr (Embedded OTDR on GPON LT)

show alarm snap-shot otdr (Embedded OTDR on GPON LT)
show alarm current otdr (Embedded OTDR on GPON LT)
configure pon interface otdr (Embedded OTDR on GPON LT)
configure system loop-id-syntax (GPON support)

New Commands

admin equipment eont (Full CLI for EPON)
admin equipment eont interface (Full CLI for EPON)
admin equipment eont llid (Full CLI for EPON)
admin equipment eont sw-version (Full CLI for EPON)
admin equipment eont swdw (Full CLI for EPON)
admin ethernet (Full CLI for EPON)
admin ethernet eont (Full CLI for EPON)
admin ethernet eont port (Full CLI for EPON)
configure epon (Full CLI for EPON)
configure epon interface (Full CLI for EPON)
configure epon interface otdr (Full CLI for EPON)
configure epon profiles (Full CLI for EPON)
configure epon profiles digitmap (Full CLI for EPON)
configure epon profiles filters (Full CLI for EPON)
configure equipment eont (Full CLI for EPON)
configure equipment eont interface (Full CLI for EPON)
configure equipment eont sw-ctrl (Full CLI for EPON)
configure equipment eont interface llid (Full CLI for EPON)
configure equipment eont interface management (Full CLI for EPON)
configure equipment eont interface port (Full CLI for EPON)
configure equipment eont interface rssi (Full CLI for EPON)
configure ethernet eont (Full CLI for EPON)
configure ethernet eont port (Full CLI for EPON)
configure ethernet eont port filter (Full CLI for EPON)
configure ethernet eont port mcastvlan (Full CLI for EPON)
configure ethernet eont port snoopmcastvlan (Full CLI for EPON)
configure ethernet eont port uservlan (Full CLI for EPON)
configure system epon pm-collect (Full CLI for EPON)
configure voice eont (Full CLI for EPON)
configure voice eont comm-para (Full CLI for EPON)
configure voice eont media-gateway (Full CLI for EPON)
configure voice eont pots (Full CLI for EPON)

configure voice eont sip-useragent (Full CLI for EPON)
--

show epon (Full CLI for EPON)

show epon interface (Full CLI for EPON)

show epon interface current-15min (Full CLI for EPON)

show epon interface current-1day (Full CLI for EPON)
--

show epon interface previous-15min (Full CLI for EPON)
--

show epon interface previous-15min interval-num (Full CLI for EPON)

show epon interface previous-1day (Full CLI for EPON)

show epon interface previous-1day interval-num (Full CLI for EPON)
--

show epon optics (Full CLI for EPON)

show epon profiles-usage (Full CLI for EPON)
--

show epon profiles-usage digitmap (Full CLI for EPON)

show epon profiles-usage filter (Full CLI for EPON)

show epon profiles-usage queue (Full CLI for EPON)
--

show equipment eont (Full CLI for EPON)

show equipment eont interface (Full CLI for EPON)

show equipment eont llid (Full CLI for EPON)
--

show equipment eont optics (Full CLI for EPON)
--

show equipment eont sw-version (Full CLI for EPON)
--

show equipment eont tc-layer (Full CLI for EPON)
--

show equipment eont tc-layer current-15min (Full CLI for EPON)
--

show equipment eont tc-layer current-1day (Full CLI for EPON)

show equipment eont tc-layer previous-15min (Full CLI for EPON)

show equipment eont tc-layer previous-15min interval-num (Full CLI for EPON)
--

show equipment eont tc-layer previous-1day (Full CLI for EPON)
--

show equipment eont tc-layer previous-1day interval-num (Full CLI for EPON)

show ethernet eont (Full CLI for EPON)
--

show ethernet eont port (Full CLI for EPON)

show ethernet eont tc-layer (Full CLI for EPON)

show ethernet eont tc-layer current-15min (Full CLI for EPON)

show ethernet eont tc-layer current-1day (Full CLI for EPON)
--

show ethernet eont tc-layer previous-15min (Full CLI for EPON)
--

show ethernet eont tc-layer previous-15min interval-num (Full CLI for EPON)

show ethernet eont tc-layer previous-1day (Full CLI for EPON)

show ethernet eont tc-layer previous-1day interval-num (Full CLI for EPON)
--

show voice eont (Full CLI for EPON)

show voice eont media-gateway (Full CLI for EPON)
show voice eont operdata (Full CLI for EPON)
show voice eont pots (Full CLI for EPON)
show voice eont sip-useragent (Full CLI for EPON)
show voice sip statistics board (SIP statistics)
show voice sip statistics board current-15min (SIP statistics)
show voice sip statistics board current-1day (SIP statistics)
show voice sip statistics board prev-15min (SIP statistics)
show voice sip statistics board prev-1day (SIP statistics)
show voice sip statistics board-perfinfo (SIP statistics)
show xdsl co-inventory (Parameter Alignment with G.997.1)
show alarm log vect-line (BL Vectoring SL Vectoring)
show alarm current vect-line (BL Vectoring SL Vectoring)
show alarm snap-shot vect-line (BL Vectoring SL Vectoring)
show alarm log vect-board (SL Vectoring)
show alarm current vect-board (SL Vectoring)
show alarm snap-shot vect-board (SL Vectoring)
configure xdsl vect-profile (BL Vectoring SL Vectoring)
configure xdsl vce-profile (BL Vectoring SL Vectoring)
configure xdsl vp-board vp-link (SL Vectoring)
show xdsl vp-board vp-link (SL Vectoring)
show xdsl vect-disturbers max-reported-dist (BL Vectoring SL Vectoring)
show xdsl vect-carrier-data near-end disturber (BL Vectoring SL Vectoring)
show xdsl vect-carrier-data far-end disturber (BL Vectoring SL Vectoring)
show xdsl failure-status vect-board (SL Vectoring)
show xdsl failure-status vect-line-near-end (BL Vectoring SL Vectoring)

Removed Commands

show qos pcc-rules fwd-port (Resource Admission Control feature)

Command delta R4.3 versus R4.2.03

Modified Commands

configure alarm entry (Login logout and target deletion traps)

configure igmp channel (support IPTV usr with PPPoE and IPoE simultaneously, GPON IOP for IGMP CAC and access-rights)

configure igmp system (configurable to discard upstream non-IGMPv3 packets, GPON IOP for IGMP CAC and access-rights)

configure mcast chn (GPON IOP for IGMP CAC and access-rights)

configure pon interface (PON 40km ranging window and ONT differential)
configure qos interface (GPON UNI scheduling/shaping based on queue parameters)
configure qos interface queue (GPON UNI scheduling/shaping based on queue parameters)
configure qos interface upstream-queue (upstream policing and queue config)
configure qos profiles policer (GPON LT color-aware trTCM)
configure qos profiles ingress-qos (GPON LT color-aware trTCM)
configure qos profiles scheduler-node (downstream UNI rate shaping to include multicast traffic)
configure qos profiles shaper (GPON UNI scheduling/shaping based on queue parameters)
configure system sync-if-timing (Full SSM on SyncE)
configure system sync-if-timing ssm (Full SSM on SyncE)
configure trap manager (Login logout and target deletion traps)
configure trap definition (Login logout and target deletion traps)
configure voice ont pots (Dual SIP Stack/ client supporting)
show system license (License counter for Green DSL L2 Mode)

New Commands

admin alarm clear-alarm filetransfer ip-address (manually clear filetransfer alarm)
admin alarm clear-alarm login-failure ip-address (login logout Trap management)
admin system security pmfile upload (SIP: Collect statistics via FTP)
configure igmp mc-vlan-xlate (GPON IOP for IGMP CAC and access-rights)
configure igmp mcast-svc-context (GPON IOP for IGMP CAC and access-rights)
configure qos ctrl-pkt-policer (Upstream policing per protocol)
configure qos profiles marker dot1p-remark (GPON LT color-aware trTCM)
configure qos profiles marker dot1p-remark dot1p-value (GPON LT color-aware trTCM)
configure system user-user-hairpin (U2U Hairpin feature)
configure system security pmfile upload (SIP: Collect statistics via FTP)
configure system snmp server-table (NTP and multiple xNTP servers support)
configure system snmp server-table ip-address (NTP and multiple xNTP servers support)
configure system sync-if-timing ssmout-ltport (Full SSM on SyncE)
configure system sync-if-timing ssmout-synce (Full SSM on SyncE)
configure system sync-if-timing t4-out-config (Full SSM on SyncE)
configure system time ntp (NTP and multiple xNTP servers support)
configure voice sip dhcp-authent-para (CLI support for configured DHCP parameters)
show alarm current mgmt-sec-access (login logout Trap management)
show alarm current sip-dial-plan (SIP Restoration)
show alarm current sip-server (SIP Restoration)
show alarm current sip-user-agent (SIP Restoration)
show alarm current sip-vsp (SIP Restoration)

show alarm log mgmt-sec-access (login logout Trap management)
show alarm log sip-dial-plan (SIP Restoration)
show alarm log sip-server (SIP Restoration)
show alarm log sip-vsp (SIP Restoration)
show alarm snap-shot mgmt-sec-access (login logout Trap management)
show alarm snap-shot sip-dial-plan (SIP Restoration)
show alarm snap-shot sip-server (SIP Restoration)
show alarm snap-shot sip-vsp (SIP Restoration)
show equipment transceiver-inventory (Digital Diagnostics for SFP XFP modules)
show igmp mcast-svc-context (GPON IOP for IGMP CAC and access-rights)
show security pmfile upload (SIP: Collect statistics via FTP)
show sntp server-table (NTP and multiple xNTP servers support)
show system ntp (NTP and multiple xNTP servers support)
show system sync-if-timing-t4 (Full SSM on SyncE)
show system user-user-hairpin (U2U Hairpin feature)
show trouble-shooting statistics uni-interface (IP anti-spoofing statistics)
show voice ont pots hookstate (Dual SIP Stack/ client supporting)
show voice sip redundancy-node (SIP Restoration)
show voice sip redundancy-node redundancy-cmd (SIP Restoration)
show voice sip redundancy-node redundancy-state (SIP Restoration)

Removed Commands

configure system security domain ip-pool (removal of DR6ed features)
configure system security domain user (removal of DR6ed features)
configure voice sip termination local-loop (SIP Restoration)
configure xdsl line local-loop (removal of DR6d features)
show alarm current llu-relay (removal of DR6d features)
show alarm current sip-user-agent (SIP Restoration)
show alarm log llu-relay (removal of DR6ed features)
show alarm log sip-user-agent (SIP Restoration)
show alarm snap-shot llu-relay (removal of DR6ed features)
show alarm snap-shot sip-user-agent (SIP Restoration)

Command delta R4.2.03 versus R4.2.02

Modified Commands

configure xdsl-bonding group-profile (Configuration of 8 port board level bonding)
configure voice ont ring-seq-prof (minor bug fixing)

show vlan current and previous stats commands (minor bug fixing)
show vlan port current and previous stats commands (minor bug fixing)
show vlan vlan-day-stats (minor bug fixing)

Command delta R4.2.02 versus R4.2

Modified Commands
configure igmp (Multicast channel selection by vlan-id)
configure igmp system (Multicast channel selection by vlan-id)
configure shdsl span (CTC support with SHDSL proxy)
configure system syslog (DomLead Ral Transport (GPON))
show igmp grp-to-package (Multicast channel selection by vlan-id)
show igmp module-mcast-channel (Multicast channel selection by vlan-id)
configure linetest cluster ltparm (ISAM-V H248 CLI enhancement)
configure linetest cluster ltssession (ISAM-V H248 CLI enhancement)
configure linetest single ltparm (ISAM-V H248 CLI enhancement)
configure linetest single ltssession (ISAM-V H248 CLI enhancement)
show linetest cluster lineid-ext-rept (Config externalCDEparameter)
show linetest single lineid-ext-rept (Config externalCDEparameter)
configure cfm domain association (Jitter, Latency, RT performance report- CFM)
configure cfm domain association mep (Jitter, Latency, RT performance report- CFM)
show cfm stack (Jitter, Latency, RT performance report- CFM)
configure equipment ont interface (OMCIv2)
configure xdsl ont line (OMCIv2)
configure equipment ont slot (OLT/OMCI/ONT support for TR-69)
configure xdsl ont service (minor problem solving)
show arp-relay-stats vlan (minor problem solving)
New Commands
show ipv6 users (IPv6 on FD)
configure mcast chn (Multicast channel selection by vlan-id)
configure mcast monitor (Multicast channel selection by vlan-id)
admin igmp mcast-chn (Multicast channel selection by vlan-id)
show xdsl-bonding operational-data link (Transport B-Fast)
configure xdsl ont dpbo-profile (MDU : VDSL enhancements)
configure xdsl ont dpbo-profile micpsd-pt-down (MDU : VDSL enhancements)
configure xdsl ont dpbo-profile epsd-pt-down (MDU : VDSL enhancements)
configure xdsl ont interface dpbo-profile (MDU : VDSL enhancements)

configure veip (OLT/OMCI/ONT support for TR-69)
configure veip ont domain-name (OLT/OMCI/ONT support for TR-69)
configure veip port pm-collect (OLT/OMCI/ONT support for TR-69)
admin voice ont voip-config (OMCIv2)
configure equipment ont interface fec-tc-layer (OMCIv2)
configure iphost (OMCIv2)
configure iphost ont (OMCIv2)
configure iphost ont performance-monitor (OMCIv2)
configure voice ont auth-sec-prof (OMCIv2)
configure voice ont feat-acccode-prof (OMCIv2)
configure voice ont mgc-config (OMCIv2)
configure voice ont nwdial-plan-prof (OMCIv2)
configure voice ont ring-seg-prof (OMCIv2)
configure voice ont ring-seq-prof (OMCIv2)
configure voice ont ringing-profile (OMCIv2)
configure voice ont rtp-profile (OMCIv2)
configure voice ont sec-uri-profile (OMCIv2)
configure voice ont sip-config (OMCIv2)
configure voice ont tone-event-prof (OMCIv2)
configure voice ont tone-seg-profile (OMCIv2)
configure voice ont tone-seq-profile (OMCIv2)
configure voice ont uri-prof (OMCIv2)
configure voice ont voice-serv-prof (OMCIv2)
configure voice ont voice-sip-port (OMCIv2)
configure voice ont voip-app-service (OMCIv2)
configure voice ont voip-config (OMCIv2)
configure voice ont voip-media-prof (OMCIv2)
configure voice ont mgc-agent (OMCIv2)
configure voice ont pots-call (OMCIv2)
configure voice ont pots-rtp (OMCIv2)
configure voice ont sip-agent (OMCIv2)
configure voice ont sip-call (OMCIv2)
configure voice ont tone-event-prof (OMCIv2)
configure voice ont tone-event-prof busy-tone (OMCIv2)
configure voice ont tone-event-prof callwait1-tone (OMCIv2)
configure voice ont tone-event-prof callwait2-tone (OMCIv2)

configure voice ont tone-event-prof callwait3-tone (OMCIv2)

configure voice ont tone-event-prof callwait4-tone (OMCIv2)

configure voice ont tone-event-prof confirm-tone (OMCIv2)

configure voice ont tone-event-prof congest-tone (OMCIv2)

configure voice ont tone-event-prof dead-tone (OMCIv2)
--

configure voice ont tone-event-prof dial-tone (OMCIv2)
--

configure voice ont tone-event-prof intrusion-tone (OMCIv2)

configure voice ont tone-event-prof msg-wait-tone (OMCIv2)
--

configure voice ont tone-event-prof release-tone (OMCIv2)

configure voice ont tone-event-prof reorder-tone (OMCIv2)

configure voice ont tone-event-prof ringback-tone (OMCIv2)
--

configure voice ont tone-event-prof roh-tone (OMCIv2)

configure voice ont tone-event-prof special-dial-tone (OMCIv2)
--

configure voice ont tone-event-prof special-info-tone (OMCIv2)
--

configure voice ont tone-event-prof stutter-tone (OMCIv2)

configure voice ont tone-event-prof userdef1-tone (OMCIv2)
--

configure voice ont tone-event-prof userdef2-tone (OMCIv2)
--

configure voice ont tone-event-prof userdef3-tone (OMCIv2)
--

configure voice ont tone-event-prof userdef4-tone (OMCIv2)
--

configure voice ont voice-port custinfo (OMCIv2)
--

show equipment ont fec-tc-layer (OMCIv2)
--

show equipment ont fec-tc-layer ont-side (OMCIv2)

show equipment ont fec-tc-layer ont-side current-interval (OMCIv2)
--

show iphost (OMCIv2)

show iphost ont (OMCIv2)

show iphost ont operational-data (OMCIv2)

show iphost ont statistics (OMCIv2)

show iphost ont statistics current-15min (OMCIv2)

show iphost ont statistics prev-15min (OMCIv2)
--

show voice ont mgc-agent (OMCIv2)

show voice ont mgc-agent statistics (OMCIv2)
--

show voice ont mgc-agent statistics current-15min (OMCIv2)
--

show voice ont mgc-agent statistics previous-15min (OMCIv2)

show voice ont pots operational-data (OMCIv2)

show voice ont pots-call (OMCIv2)

show voice ont pots-call statistics (OMCIv2)
--

show voice ont pots-call statistics current-15min (OMCIv2)
--

show voice ont pots-call statistics prev-15min (OMCIv2)
show voice ont pots-rtp (OMCIv2)
show voice ont pots-rtp statistics (OMCIv2)
show voice ont pots-rtp statistics current-15min (OMCIv2)
show voice ont pots-rtp statistics prev-15min (OMCIv2)
show voice ont sip-agent (OMCIv2)
show voice ont sip-agent statistics (OMCIv2)
show voice ont sip-agent statistics current-15min (OMCIv2)
show voice ont sip-agent statistics prev-15min (OMCIv2)
show voice ont sip-call (OMCIv2)
show voice ont sip-call statistics (OMCIv2)
show voice ont sip-call statistics current-15min (OMCIv2)
show voice ont sip-call statistics prev-15min (OMCIv2)
show voice ont sip-config (OMCIv2)
show voice ont sip-config operational-data (OMCIv2)
show voice ont voip-config (OMCIv2)
show voice ont voip-config operational-data (OMCIv2)

Command delta R4.2 versus R4.0.10

Modified Commands
admin equipment slot (NRNT-A; mini-ISAM NT)
admin shdsl-seg unit-id (SHDSL evolution on NSLT-b)
admin system cpu-load (NRNT-A; mini-ISAM NT)
configure alarm entry (IPv6 on HC-L3 NT)
configure debug-trace protocol-trace (IPv6 Protocol Aware CC with DHCPv6 on FD)
configure equipment slot (NANT-E CLI/TL1 Adaptation)
configure ethernet line (FD 36p Ethernet LT (NELT-B))
configure igmp channel (GPON support)
configure interface port (FD 36p Ethernet LT (NELT-B))
configure qos profiles l2-filter (IPv6 Protocol Aware CC with DHCPv6 on FD)
configure qos profiles policer (FD 36p Ethernet LT (NELT-B))
configure qos profiles queue (FD 36p Ethernet LT (NELT-B))
configure qos tc-map-dot1p (FD 36p Ethernet LT (NELT-B))
configure qos tca queue (GPON support)
configure shdsl segment unit-id (SHDSL evolution on NSLT-b)
configure shdsl span (SHDSL evolution on NSLT-b)
configure shdsl unit unit-id (SHDSL evolution on NSLT-b)

configure system max-lt-link-speed (NANT-E CLI/TL1 Adaptation)
configure system security profile (Lawful Intercept)
configure system security domain (Full CLI support)
configure system security default-profile (Lawful Intercept)
configure system security snmp group security-level (Lawful Intercept)
configure system security snmp map-user-group (Lawful Intercept)
configure system sync-if-timing (NRNT-A; mini-ISAM NT)
configure system sync-if-timing ssm (minor problem solving)
configure system sync-if-timing synce (NRNT-A; mini-ISAM NT)
configure system syslog route msg-type (Lawful Intercept)
configure trap manager (Reliable Trap management)
configure trap definition (Reliable Trap management)
configure vlan id (IPv6 Protocol Aware CC with DHCPv6 on FD)
configure vlan port-protocol (IPv6 Protocol Aware CC with DHCPv6 on FD)
configure voice sip termination (ISAM-V)
configure voice sip lineid-syn-prof (ISAM-V)
configure voice sip vsp (ISAM-V)
configure xdsl overrule-data (standard ARQ for ADSL2 (+)and VDSL2)
configure xdsl service-profile (SRA for VDSL2)
configure xdsl line (standard ARQ for ADSL2 (+)and VDSL2)
configure xdsl line tca-line-threshold (standard ARQ for ADSL2 (+)and VDSL2)
configure xdsl-bonding group-profile (8p PTM VDSL2 bonding on FD)
show equipment slot (NANT-E CLI/TL1 Adaptation)
show equipment temperature (NRNT-A; mini-ISAM NT)
show interface port (FD 36p Ethernet LT (NELT-B))
show interface stack (FD 36p Ethernet LT (NELT-B))
show interface test (FD 36p Ethernet LT (NELT-B))
show qos interface-bandwidth (GPON support)
show qos statistics queue current-15min (GPON support)
show qos statistics queue prev-15min (GPON support)
show shdsl inventory (SHDSL evolution on NSLT-b)
show shdsl segment-counters current-15min (SHDSL evolution on NSLT-b)
show shdsl segment-counters current-1day (SHDSL evolution on NSLT-b)
show shdsl segment-counters previous-15min (SHDSL evolution on NSLT-b)
show shdsl segment-counters previous-1day (SHDSL evolution on NSLT-b)
show shdsl segment-status (SHDSL evolution on NSLT-b)
show shdsl unit-status (SHDSL evolution on NSLT-b)

show system cpu-load (NRNT-A; mini-ISAM NT)
show system license (NANT-E CLI/TL1 Adaptation)
show system memory-usage (NRNT-A; mini-ISAM NT)
show trouble-shooting statistics interface (PT Counters)
show vlan residential-bridge extensive (FD 36p Ethernet LT (NELT-B))
show vlan residential-bridge summary (FD 36p Ethernet LT (NELT-B))
show voice sip statistics call (ISAM-V)

New Commands

admin ces (Full CLI support)
admin ces ont (Full CLI support)
admin ces ont line (Full CLI support)
admin dhcp-relay v6-port-stats (IPv6 Protocol Aware CC with DHCPv6 on FD)
admin equipment ont (Full CLI support)
admin equipment ont data-store (Full CLI support)
admin equipment ont interface (Full CLI support)
admin equipment ont slot (Full CLI support)
admin equipment ont sw-ctrl (Full CLI support)
admin equipment ont sw-version (Full CLI support)
admin ont-xdsl-line (Full CLI support)
admin pon (Full CLI support)
admin pon ber-stats (Full CLI support)
admin voice (Full CLI support)
admin voice ont (Full CLI support)
admin voice ont pots (Full CLI support)
admin voice ont pots diagnostics mode (Full CLI support)
admin voice ont pots pb-dial-tone slow-pull-timer (Full CLI support)
admin voice ont pots sip-dial-tone sip-phone-number (Full CLI support)
configure ani (Full CLI support)
configure ani ont (Full CLI support)
configure ani ont tca-thresh (Full CLI support)
configure ani ont video (Full CLI support)

configure ces (Full CLI support)
configure ces ont (Full CLI support)
configure ces ont profile (Full CLI support)
configure ces ont service service-nbr (Full CLI support)
configure ces ont line mode (Full CLI support)

configure ces ont line port pm-collect (Full CLI support)
configure ces ont service service-nbr tc-layer (Full CLI support)
configure ces ont service service-nbr pseudo-wire (Full CLI support)
configure dhcp-relay v6-port-stats (IPv6 Protocol Aware CC with DHCPv6 on FD)
configure equipment ont (Full CLI support)
configure equipment ont interface (Full CLI support)
configure equipment ont slot (Full CLI support)
configure equipment ont sw-ctrl (Full CLI support)
configure equipment ont interface tc-layer-threshold (Full CLI support)
configure ethernet line mau (FD 36p Ethernet LT (NELT-B))
configure ethernet ont cust-info (Full CLI support)
configure ethernet ont port pm-collect (Full CLI support)
configure l2uni (Full CLI support)
configure l2uni ont (Full CLI support)
configure l2uni ont performance-monitor (Full CLI support)
configure l2uni ont tc-layer-threshold dropped-frames-up (Full CLI support)
configure linetest (ISAM-V H248 : CLI enhancements)
configure linetest cluster (ISAM-V H248 : CLI enhancements)
configure linetest cluster ltline (ISAM-V H248 : CLI enhancements)
configure linetest cluster ltparm (ISAM-V H248 : CLI enhancements)
configure linetest cluster ltsession (ISAM-V H248 : CLI enhancements)
configure linetest single (ISAM-V H248 : CLI enhancements)
configure linetest single ltline lineid (ISAM-V H248 : CLI enhancements)
configure linetest single ltparm tst-type (ISAM-V H248 : CLI enhancements)
configure linetest single ltsession session-cmd (ISAM-V H248 : CLI enhancements)
configure link-agg (FD 36p Ethernet LT (NELT-B))
configure link-agg general priority (FD 36p Ethernet LT (NELT-B))
configure link-agg group load-sharing-policy (FD 36p Ethernet LT (NELT-B))
configure link-agg group port (FD 36p Ethernet LT (NELT-B))
configure link-agg port passive-lacp (FD 36p Ethernet LT (NELT-B))
configure mcast static (FD 36p Ethernet LT (NELT-B))
configure mcast static branch (FD 36p Ethernet LT (NELT-B))
configure ntp (Full CLI support)
configure ntp ont (Full CLI support)
configure pon (Full CLI support)
configure pon power-shed-prof (Full CLI support)
configure pon interface label (Full CLI support)

configure pon interface tc-layer pm-collect (Full CLI support)
configure pon interface tc-layer-threshold (Full CLI support)
configure system pon-ont slid-mode (Full CLI support)
configure system security li separate (Full CLI support)
configure uni (Full CLI support)
configure uni ont (Full CLI support)
configure uni ont tc-layer pm-collect (Full CLI support)
configure uni ont video pwr-override (Full CLI support)
configure voice ont (Full CLI support)
configure voice ont service (Full CLI support)
configure voice ont pots custinfo (Full CLI support)
configure voice ont tc-layer pm-collect (Full CLI support)
configure xdsl rtx-profile rtx-profile (Full CLI support)
configure xdsl ont (Full CLI support)
configure xdsl ont service-profile (Full CLI support)
configure xdsl ont spectrum-profile (Full CLI support)
configure xdsl ont line service-profile (Full CLI support)
configure xdsl ont spectrum-profile vdsl vdsl-band-plan (Full CLI support)
configure xdsl ont spectrum-profile vdsl2 max-agpowlev-down (Full CLI support)
configure xstp (FD 36p Ethernet LT (NELT-B))
configure xstp instance (FD 36p Ethernet LT (NELT-B))
configure xstp general enable-stp (FD 36p Ethernet LT (NELT-B))
configure xstp instance associate-vlan (FD 36p Ethernet LT (NELT-B))
configure xstp port priority (FD 36p Ethernet LT (NELT-B))
configure xstp port-instance instance (FD 36p Ethernet LT (NELT-B))
mrinfo (PIM-SSM on HC-L3 NT)
mstat (PIM-SSM on HC-L3 NT)
mtrace (PIM-SSM on HC-L3 NT)
show alarm current ihub-ipv6 (IPv6 on HC-L3 NT)
show alarm current pim (PIM-SSM on HC-L3 NT)
show alarm current sip-user-agent (minor problem solving)
show alarm log ihub-ipv6 (IPv6 on HC-L3 NT)
show alarm log pim (PIM-SSM on HC-L3 NT)
show alarm log sip-user-agent (minor problem solving)
show alarm snap-shot ihub-ipv6 (IPv6 on HC-L3 NT)
show alarm snap-shot pim (PIM-SSM on HC-L3 NT)
show alarm snap-shot sip-user-agent (minor problem solving)

show ani (Full CLI support)
show ani ont (Full CLI support)
show ani ont operational-data (Full CLI support)
show ani ont video (Full CLI support)
show ani ont video-stats (Full CLI support)
show ces (Full CLI support)
show ces ont (Full CLI support)

show ces ont line (Full CLI support)
show ces ont line port (Full CLI support)
show ces ont line port current-interval (Full CLI support)
show ces ont line port previous-interval interval-nbr (Full CLI support)
show ces ont service (Full CLI support)
show ces ont service operational-data (Full CLI support)
show ces ont service pseudo-wire (Full CLI support)
show ces ont service pseudo-wire current-interval (Full CLI support)
show ces ont service pseudo-wire previous-interval interval-nbr (Full CLI support)
show ces ont service tc-layer (Full CLI support)
show ces ont service tc-layer olt-side (Full CLI support)
show ces ont service tc-layer olt-side current-interval (Full CLI support)
show ces ont service tc-layer olt-side previous-interval interval-nbr (Full CLI support)
show ces ont service tc-layer ont-side (Full CLI support)
show ces ont service tc-layer ont-side current-interval (Full CLI support)
show ces ont service tc-layer ont-side previous-interval interval-nbr (Full CLI support)
show dhcp-relay v6-port-stats (IPv6 Protocol Aware CC with DHCPv6 on FD)
show dhcp-relay v6-port-stats vlan (IPv6 Protocol Aware CC with DHCPv6 on FD)
show dhcp-relay v6-port-stats vlan v6extensive (IPv6 Protocol Aware CC with DHCPv6 on FD)
show dhcp-relay v6-port-stats vlan v6summary (IPv6 Protocol Aware CC with DHCPv6 on FD)
show equipment ont (Full CLI support)
show equipment ont data-store (Full CLI support)
show equipment ont interface (Full CLI support)

show equipment ont operational-data (Full CLI support)
show equipment ont optics (Full CLI support)
show equipment ont optics-history (Full CLI support)
show equipment ont pwr-shed (Full CLI support)
show equipment ont slot (Full CLI support)
show equipment ont sw-ctrl (Full CLI support)

show equipment ont sw-download (Full CLI support)
show equipment ont sw-version (Full CLI support)
show equipment ont tc-layer (Full CLI support)
show equipment ont tc-layer olt-side (Full CLI support)
show equipment ont tc-layer olt-side current-interval (Full CLI support)
show equipment ont tc-layer olt-side previous-interval (Full CLI support)
show equipment ont tc-layer olt-side-on-demand (Full CLI support)
show equipment ont tc-layer olt-side-on-demand current-interval (Full CLI support)
show equipment ont tc-layer olt-side-on-demand previous-interval (Full CLI support)
show equipment ont tc-layer ont-side (Full CLI support)
show equipment ont tc-layer ont-side current-interval (Full CLI support)
show equipment ont tc-layer ont-side previous-interval interval-num (Full CLI support)
show ethernet ont (Full CLI support)
show ethernet ont operational-data (Full CLI support)
show ethernet ont port (Full CLI support)
show ethernet ont port current-interval (Full CLI support)
show ethernet ont port previous-interval interval-num (Full CLI support)
show ethernet statistics (FD 36p Ethernet LT (NELT-B))
show ethernet statistics line (FD 36p Ethernet LT (NELT-B))
show l2uni (Full CLI support)
show l2uni ont (Full CLI support)
show l2uni ont performance-data (Full CLI support)
show l2uni ont performance-data current-interval (Full CLI support)
show l2uni ont performance-data previous-interval interval-nbr (Full CLI support)
show linetest (ISAM-V H248 : CLI enhancements)
show linetest cluster (ISAM-V H248 : CLI enhancements)
show linetest cluster avail-sess (ISAM-V H248 : CLI enhancements)
show linetest cluster lineid-ext-rept lineid (ISAM-V H248 : CLI enhancements)
show linetest cluster ltline lineid (ISAM-V H248 : CLI enhancements)
show linetest cluster ltsession (ISAM-V H248 : CLI enhancements)
show linetest single (ISAM-V H248 : CLI enhancements)
show linetest single avail-sess (ISAM-V H248 : CLI enhancements)
show linetest single lineid-ext-rept lineid (ISAM-V H248 : CLI enhancements)
show linetest single ltline lineid (ISAM-V H248 : CLI enhancements)
show linetest single ltsession (ISAM-V H248 : CLI enhancements)
show link-agg (FD 36p Ethernet LT (NELT-B))
show link-agg group-info (FD 36p Ethernet LT (NELT-B))

show link-agg member-port port (FD 36p Ethernet LT (NELT-B))
show link-agg port-info (FD 36p Ethernet LT (NELT-B))
show pon (Full CLI support)
show pon ber-stats ont-num (Full CLI support)
show pon interface (Full CLI support)
show pon interface tc-layer (Full CLI support)
show pon interface tc-layer current-interval (Full CLI support)
show pon interface tc-layer previous-interval interval-nbr (Full CLI support)
show pon optics (Full CLI support)
show pon sfp-inventory (Full CLI support)
show pon sw-download (Full CLI support)
show pppoel2-stats (Porting FTTU)
show pppoel2-stats vlan (Porting FTTU)
show pppoel2-stats vlan extensive (Porting FTTU)
show pppoel2-stats vlan summary (Porting FTTU)
show qos pcc-rules fwd-port (Full CLI support)
show trouble-shooting pon (PT Counters)
show trouble-shooting pon statistics (PT Counters)
show trouble-shooting pon statistics interface (PT Counters)
show uni (Full CLI support)
show uni ont (Full CLI support)
show uni ont tc-layer (Full CLI support)
show uni ont tc-layer olt-side (Full CLI support)
show uni ont tc-layer olt-side current-interval (Full CLI support)
show uni ont tc-layer olt-side previous-interval (Full CLI support)
show uni ont tc-layer ont-side (Full CLI support)
show uni ont tc-layer ont-side current-interval (Full CLI support)
show uni ont tc-layer ont-side previous-interval (Full CLI support)
show voice ont (Full CLI support)
show voice ont call-hist call-hist-num (Full CLI support)
show voice ont pots (Full CLI support)
show voice ont pots diagnostics (Full CLI support)
show voice ont pots pb-dial-tone (Full CLI support)
show voice ont pots sip-dial-tone (Full CLI support)
show voice ont pots tc-layer (Full CLI support)
show voice ont pots tc-layer olt-side (Full CLI support)
show voice ont pots tc-layer olt-side current-interval (Full CLI support)

show voice ont pots tc-layer olt-side previous-interval interval-nbr (Full CLI support)
show voice ont pots tc-layer ont-side (Full CLI support)
show voice ont pots tc-layer ont-side current-interval (Full CLI support)
show voice ont pots tc-layer ont-side previous-interval interval-nbr (Full CLI support)
show voice ont service (Full CLI support)
show xdsl ont (Full CLI support)
show xdsl ont carrier-data (Full CLI support)
show xdsl ont carrier-data far-end (Full CLI support)
show xdsl ont carrier-data near-end (Full CLI support)
show xdsl ont counters (Full CLI support)
show xdsl ont counters far-end (Full CLI support)
show xdsl ont counters far-end channel (Full CLI support)
show xdsl ont counters far-end channel current-interval (Full CLI support)
show xdsl ont counters far-end channel previous-interval interval-no (Full CLI support)
show xdsl ont counters far-end line (Full CLI support)
show xdsl ont counters far-end line current-interval (Full CLI support)
show xdsl ont counters far-end line previous-interval interval-no (Full CLI support)
show xdsl ont counters near-end (Full CLI support)
show xdsl ont counters near-end channel (Full CLI support)
show xdsl ont counters near-end channel current-interval (Full CLI support)
show xdsl ont counters near-end channel previous-interval interval-no (Full CLI support)
show xdsl ont counters near-end line (Full CLI support)
show xdsl ont counters near-end line current-interval (Full CLI support)
show xdsl ont counters near-end line previous-interval interval-no (Full CLI support)
show xdsl ont cpe-tuc-inventory (Full CLI support)
show xdsl ont cpe-tur-inventory (Full CLI support)
show xdsl ont failure-status (Full CLI support)
show xdsl ont failure-status far-end (Full CLI support)
show xdsl ont failure-status near-end (Full CLI support)
show xdsl ont operational-data (Full CLI support)
show xdsl ont operational-data far-end (Full CLI support)
show xdsl ont operational-data far-end channel (Full CLI support)
show xdsl ont operational-data far-end line (Full CLI support)
show xdsl ont operational-data near-end (Full CLI support)
show xdsl ont operational-data near-end channel (Full CLI support)
show xdsl ont operational-data near-end line (Full CLI support)
show xdsl ont profiles (Full CLI support)

show xdsl ont xdsl-int (Full CLI support)
show xstp (FD 36p Ethernet LT (NELT-B))
show xstp bridge (FD 36p Ethernet LT (NELT-B))
show xstp instance (FD 36p Ethernet LT (NELT-B))
show xstp port (FD 36p Ethernet LT (NELT-B))
show xstp port-instance instance (FD 36p Ethernet LT (NELT-B))

Removed Commands

configure mcast src (Fixed multicast VLAN per IGMP channel)
configure mcast src packagemember (Fixed multicast VLAN per IGMP channel)
show bridge port-to-atm-pvc (ISAM-V H248 : CLI enhancements)

Command delta R4.2 versus R4.1.02

Modified Commands

admin arp-relay-stats (GPON support)
admin bridge learned-unicast-mac unicast-mac-address (GPON support)
admin dhcp-relay port-stats (GPON support)
admin equipment slot (NRNT-A; mini-ISAM NT)
admin igmp channel (GPON support)
admin security ext-authenticator (GPON support)
admin system cpu-load (NRNT-A; mini-ISAM NT)
admin trouble-shooting interface (GPON support)
configure alarm entry (IPv6 on HC-L3 NT)
configure arp-relay statistics (GPON support)
configure bridge port (GPON support)
configure debug-trace protocol-trace (IPv6 Protocol Aware CC with DHCPv6 on FD)
configure dhcp-relay port-stats (GPON support)
configure equipment slot (NANT-E CLI/TL1 Adaptation)
configure ethernet line (FD 36p Ethernet LT (NELT-B))
configure igmp channel (GPON support)
configure igmp system (GPON support)
configure interface port (FD 36p Ethernet LT (NELT-B))
configure pppox-relay cross-connect client-port (GPON support)
configure qos dsl-port (GPON support)
configure qos interface (GPON support)
configure qos interface queue (GPON support)
configure qos profiles cac (GPON support)

configure qos profiles l2-filter (IPv6 Protocol Aware CC with DHCPv6 on FD)
configure qos profiles policer (FD 36p Ethernet LT (NELT-B))
configure qos profiles queue (FD 36p Ethernet LT (NELT-B))
configure qos profiles shaper (GPON support)
configure qos shdsl-port (GPON support)
configure qos tc-map-dot1p (FD 36p Ethernet LT (NELT-B))
configure qos tca queue (GPON support)
configure system (Full CLI support)

configure system loop-id-syntax (GPON support)
configure system max-lt-link-speed (NANT-E CLI/TL1 Adaptation)
configure system security profile (Lawful Intercept)
configure system security domain (Full CLI support)
configure system security default-profile (Lawful Intercept)
configure system security pae authenticator (GPON support)
configure system security pae ext-authenticator (GPON support)
configure system security pae port (GPON support)
configure system security radius (GPON support)
configure system security snmp group security-level (Lawful Intercept)
configure system security snmp map-user-group (Lawful Intercept)
configure system security ssh access (GPON support)
configure system sync-if-timing ssm (NRNT-A; mini-ISAM NT)
configure system sync-if-timing synce (NRNT-A; mini-ISAM NT)
configure system syslog destination (GPON support)
configure system syslog route (GPON support)
configure trap manager (GPON support)
configure trap definition (GPON support)
configure trouble-shooting statistics interface (GPON support)
configure vlan id (IPv6 Protocol Aware CC with DHCPv6 on FD)
configure vlan port-protocol protocol-group (IPv6 Protocol Aware CC with DHCPv6 on FD)
configure vlan unicast-mac vlan-id (GPON support)
configure vlan vlan-port unicast-mac (GPON support)
configure vlan pbit-statistics port min-dot1p (GPON support)
configure voice sip termination (ISAM-V)
configure voice sip lineid-syn-prof (ISAM-V)
configure voice sip vsp (ISAM-V)
configure xdsl overrule-data (standard ARQ for ADSL2 (+)and VDSL2)
configure xdsl service-profile (SRA for VDSL2)

configure xdsl line (standard ARQ for ADSL2 (+)and VDSL2)
configure xdsl line tca-line-threshold (standard ARQ for ADSL2 (+)and VDSL2)
configure xdsl-bonding group-profile (8p PTM VDSL2 bonding on FD)
show arp-relay-stats (GPON support)
show config-data-port igmp (GPON support)
show config-data-port qos scheduler-profile (GPON support)
show dhcp-relay port-stats (GPON support)
show dhcp-relay session (GPON support)
show equipment slot (NANT-E CLI/TL1 Adaptation)
show equipment temperature (NRNT-A; mini-ISAM NT)
show igmp channel counter (GPON support)
show igmp channel miscellaneous (GPON support)
show igmp channel protocol (GPON support)
show interface stack (FD 36p Ethernet LT (NELT-B))
show interface port (FD 36p Ethernet LT (NELT-B))
show interface stack (FD 36p Ethernet LT (NELT-B))
show interface test (FD 36p Ethernet LT (NELT-B))
show mcast active-groups (GPON support)
show mcast grp-membership (GPON support)
show oper-data-port igmp (GPON support)
show pppox-relay cross-connect monitor-statistics client-port (GPON support)
show pppox-relay cross-connect session client-port (GPON support)
show pppox-relay cross-connect statistics client-port (GPON support)
show qos statistics buffer-overflow current-1day (NRNT-A; mini-ISAM NT)
show qos statistics queue current-15min (GPON support)
show qos statistics queue prev-15min (GPON support)
show security pae authenticator (GPON support)
show security pae diagnostics (GPON support)
show security pae eapol-stats (GPON support)
show security pae port-details (GPON support)
show security pae session-stats (GPON support)
show system cpu-load (NRNT-A; mini-ISAM NT)
show system license (NANT-E CLI/TL1 Adaptation)
show system memory-usage (NRNT-A; mini-ISAM NT)
show trouble-shooting statistics interface (GPON support)
show vlan bridge-port-fdb (GPON support)
show vlan cross-connect (GPON support)

show vlan current-15min-stats (GPON support)
show vlan current-day-stats (GPON support)
show vlan dup-mac-alarm (GPON support)
show vlan pbit-statistics port (GPON support)
show vlan port-15min-stats (GPON support)
show vlan port-curr-15min-stats (GPON support)
show vlan port-curr-day-stats (GPON support)
show vlan port-event (GPON support)
show vlan port-prev-day-stats (GPON support)
show vlan previous-15min-stats (GPON support)
show vlan residential-bridge extensive (FD 36p Ethernet LT (NELT-B))
show vlan residential-bridge summary (FD 36p Ethernet LT (NELT-B))
show vlan vlan-day-stats (GPON support)
show vlan vmac-bridge-port-fdb (GPON support)
show voice sip statistics call interval
show xdsl config-data-port qos scheduler-profile (GPON support)
show xdsl oper-data-port igmp (GPON support)

New Commands

admin ces (Full CLI support)
admin ces ont (Full CLI support)
admin ces ont line (Full CLI support)
admin dhcp-relay v6-port-stats (IPv6 Protocol Aware CC with DHCPv6 on FD)
admin equipment ont (Full CLI support)
admin equipment ont data-store (Full CLI support)
admin equipment ont interface (Full CLI support)
admin equipment ont slot (Full CLI support)
admin equipment ont sw-ctrl (Full CLI support)
admin equipment ont sw-version (Full CLI support)
admin ont-xdsl-line loop-diagnostic (Full CLI support)
admin pon (Full CLI support)
admin pon ber-stats (Full CLI support)
admin voice (Full CLI support)
admin voice ont (Full CLI support)
admin voice ont pots (Full CLI support)
admin voice ont pots diagnostics mode (Full CLI support)
admin voice ont pots pb-dial-tone slow-pull-timer (Full CLI support)

admin voice ont pots sip-dial-tone sip-phone-number (Full CLI support)
configure ani (Full CLI support)
configure ani ont (Full CLI support)
configure ani ont tca-thresh tca-thresh lower-optical-th (Full CLI support)
configure ani ont video (Full CLI support)
configure ces (Full CLI support)
configure ces ont (Full CLI support)
configure ces ont profile (Full CLI support)
configure ces ont service (Full CLI support)
configure ces ont line mode (Full CLI support)
configure ces ont line port pm-collect (Full CLI support)
configure ces ont service service-nbr (Full CLI support)
configure dhcp-relay v6-port-stats (IPv6 Protocol Aware CC with DHCPv6 on FD)
configure equipment ont (Full CLI support)
configure equipment ont interface (Full CLI support)
configure equipment ont interface tc-layer-threshold (Full CLI support)
configure equipment ont slot (Full CLI support)
configure equipment ont sw-ctrl (Full CLI support)
configure equipment ont interface tc-layer (Full CLI support)
configure ethernet line mau (FD 36p Ethernet LT (NELT-B))
configure ethernet ont cust-info (Full CLI support)
configure ethernet ont port pm-collect (Full CLI support)
configure l2uni (Full CLI support)
configure l2uni ont (Full CLI support)
configure l2uni ont performance-monitor pm-collect (Full CLI support)
configure l2uni ont tc-layer-threshold dropped-frames-up (Full CLI support)
configure linetest (ISAM-V H248 : CLI enhancements)
configure linetest cluster (ISAM-V H248 : CLI enhancements)
configure linetest cluster ltparm (ISAM-V H248 : CLI enhancements)
configure linetest cluster ltline (ISAM-V H248 : CLI enhancements)
configure linetest cluster ltparm (ISAM-V H248 : CLI enhancements)
configure linetest cluster ltsession (ISAM-V H248 : CLI enhancements)
configure linetest single (ISAM-V H248 : CLI enhancements)
configure linetest single ltline (ISAM-V H248 : CLI enhancements)
configure linetest single ltparm tst-type (ISAM-V H248 : CLI enhancements)
configure linetest single ltsession session-cmd (ISAM-V H248 : CLI enhancements)
configure link-aggr (FD 36p Ethernet LT (NELT-B))

configure link-agg general priority (FD 36p Ethernet LT (NELT-B))
configure link-agg group load-sharing-policy max-active-port (FD 36p Ethernet LT (NELT-B))
configure link-agg group port (FD 36p Ethernet LT (NELT-B))
configure link-agg port passive-lacp (FD 36p Ethernet LT (NELT-B))
configure mcast monitor (GPON support)
configure mcast monitor src (GPON support)
configure mcast static (FD 36p Ethernet LT (NELT-B))
configure mcast static branch (FD 36p Ethernet LT (NELT-B))
configure ntp (Full CLI support)
configure ntp ont (Full CLI support)
configure pon (Full CLI support)
configure pon power-shed-prof (Full CLI support)
configure pon interface label (Full CLI support)
configure pon interface tc-layer pm-collect (Full CLI support)
configure pon interface tc-layer-threshold (Full CLI support)
configure qos interface upstream-queue (GPON support)
configure qos profiles bandwidth (GPON support)
configure qos profiles ingress-qos (GPON support)
configure qos profiles scheduler-node (GPON support)
configure system pon-ont slid-mode (Full CLI support)
configure system security li separate (Lawful Intercept)
configure uni (Full CLI support)
configure uni ont (Full CLI support)
configure uni ont tc-layer (Full CLI support)
configure uni ont video pwr-override (Full CLI support)
configure voice ont (Full CLI support)
configure voice ont service (Full CLI support)
configure voice ont pots custinfo (Full CLI support)
configure voice ont tc-layer pm-collect (Full CLI support)
configure xdsl rtx-profile rtx-profile (standard ARQ for ADSL2 (+)and VDSL2)
configure xdsl ont (Full CLI support)
configure xdsl ont service-profile (Full CLI support)
configure xdsl ont spectrum-profile (Full CLI support)
configure xdsl ont line service-profile (Full CLI support)
configure xdsl ont spectrum-profile vdsl (Full CLI support)
configure xdsl ont spectrum-profile vdsl2 (Full CLI support)

configure xstp (FD 36p Ethernet LT (NELT-B))
configure xstp instance (FD 36p Ethernet LT (NELT-B))
configure xstp general enable-stp (FD 36p Ethernet LT (NELT-B))
configure xstp instance associate-vlan (FD 36p Ethernet LT (NELT-B))
configure xstp port priority (FD 36p Ethernet LT (NELT-B))
configure xstp port-instance instance (FD 36p Ethernet LT (NELT-B))
mrinfo (PIM-SSM on HC-L3 NT)
mstat (PIM-SSM on HC-L3 NT)
mtrace (PIM-SSM on HC-L3 NT)
show alarm current eqpt-supplemental (GPON support)
show alarm current ihub-ipv6 (IPv6 on HC-L3 NT)
show alarm current mcsrc (GPON support)
show alarm current pim (PIM-SSM on HC-L3 NT)
show alarm current sip-user-agent (minor problem solving)
show alarm current vlanport (GPON support)
show alarm log eqpt-supplemental (GPON support)
show alarm log ihub-ipv6 (IPv6 on HC-L3 NT)
show alarm log mcsrc (GPON support)
show alarm log pim (PIM-SSM on HC-L3 NT)
show alarm log sip-user-agent (minor problem solving)
show alarm log vlanport (GPON support)
show alarm snap-shot eqpt-supplemental (GPON support)
show alarm snap-shot ihub-ipv6 (IPv6 on HC-L3 NT)
show alarm snap-shot mcsrc (GPON support)
show alarm snap-shot pim (PIM-SSM on HC-L3 NT)
show alarm snap-shot sip-user-agent (minor problem solving)
show alarm snap-shot vlanport (GPON support)
show ani (Full CLI support)
show ani ont (Full CLI support)
show ani ont operational-data (Full CLI support)
show ani ont video (Full CLI support)
show ani ont video-stats (Full CLI support)
show ces (Full CLI support)
show ces ont (Full CLI support)
show ces ont line (Full CLI support)
show ces ont line port (Full CLI support)
show ces ont line port current-interval (Full CLI support)

show ces ont line port previous-interval interval-nbr (Full CLI support)
show ces ont service (Full CLI support)
show ces ont service operational-data (Full CLI support)
show ces ont service pseudo-wire (Full CLI support)
show ces ont service pseudo-wire current-interval (Full CLI support)
show ces ont service pseudo-wire previous-interval interval-nbr (Full CLI support)
show ces ont service tc-layer (Full CLI support)
show ces ont service tc-layer olt-side (Full CLI support)
show ces ont service tc-layer olt-side current-interval (Full CLI support)
show ces ont service tc-layer olt-side previous-interval interval-nbr (Full CLI support)
show ces ont service tc-layer ont-side (Full CLI support)
show ces ont service tc-layer ont-side current-interval (Full CLI support)
show ces ont service tc-layer ont-side previous-interval (Full CLI support)
show dhcp-relay v6-port-stats (IPv6 Protocol Aware CC with DHCPv6 on FD)
show dhcp-relay v6-port-stats vlan (IPv6 Protocol Aware CC with DHCPv6 on FD)
show dhcp-relay v6-port-stats vlan v6extensive (IPv6 Protocol Aware CC with DHCPv6 on FD)
show dhcp-relay v6-port-stats vlan v6summary (IPv6 Protocol Aware CC with DHCPv6 on FD)
show equipment ont (Full CLI support)
show equipment ont data-store (Full CLI support)
show equipment ont interface (Full CLI support)
show equipment ont operational-data (Full CLI support)
show equipment ont optics (Full CLI support)
show equipment ont optics-history (Full CLI support)
show equipment ont pwr-shed (Full CLI support)
show equipment ont slot (Full CLI support)
show equipment ont sw-ctrl (Full CLI support)
show equipment ont sw-download (Full CLI support)
show equipment ont sw-version (Full CLI support)
show equipment ont tc-layer (Full CLI support)
show equipment ont tc-layer olt-side (Full CLI support)
show equipment ont tc-layer olt-side current-interval (Full CLI support)
show equipment ont tc-layer olt-side previous-interval interval-num (Full CLI support)
show equipment ont tc-layer olt-side-on-demand (Full CLI support)
show equipment ont tc-layer olt-side-on-demand current-interval (Full CLI support)
show equipment ont tc-layer olt-side-on-demand previous-interval interval-num (Full CLI support)
show equipment ont tc-layer ont-side (Full CLI support)
show equipment ont tc-layer ont-side current-interval (Full CLI support)

show equipment ont tc-layer ont-side previous-interval (Full CLI support)
show ethernet ont (Full CLI support)
show ethernet ont operational-data (Full CLI support)
show ethernet ont port (Full CLI support)
show ethernet ont port current-interval (Full CLI support)
show ethernet ont port previous-interval interval-num (Full CLI support)
show ethernet statistics (FD 36p Ethernet LT (NELT-B))
show ethernet statistics line (FD 36p Ethernet LT (NELT-B))
show l2uni (Full CLI support)
show l2uni ont (Full CLI support)
show l2uni ont performance-data (Full CLI support)
show l2uni ont performance-data current-interval (Full CLI support)
show l2uni ont performance-data previous-interval interval-nbr (Full CLI support)
show linetest (ISAM-V H248 : CLI enhancements)
show linetest cluster (ISAM-V H248 : CLI enhancements)
show linetest cluster avail-sess (ISAM-V H248 : CLI enhancements)
show linetest cluster lineid-ext-rept lineid (ISAM-V H248 : CLI enhancements)
show linetest cluster ltline lineid (ISAM-V H248 : CLI enhancements)
show linetest cluster ltsession (ISAM-V H248 : CLI enhancements)
show linetest single (ISAM-V H248 : CLI enhancements)
show linetest single avail-sess (ISAM-V H248 : CLI enhancements)
show linetest single lineid-ext-rept lineid (ISAM-V H248 : CLI enhancements)
show linetest single ltline lineid (ISAM-V H248 : CLI enhancements)
show linetest single ltsession (ISAM-V H248 : CLI enhancements)
show link-agg (FD 36p Ethernet LT (NELT-B))
show link-agg group-info (FD 36p Ethernet LT (NELT-B))
show link-agg member-port port (FD 36p Ethernet LT (NELT-B))
show link-agg port-info (FD 36p Ethernet LT (NELT-B))
show pon (Full CLI support)
show pon ber-stats ont-num (Full CLI support)
show pon interface (Full CLI support)
show pon interface tc-layer (Full CLI support)
show pon interface tc-layer current-interval (Full CLI support)
show pon interface tc-layer previous-interval interval-nbr (Full CLI support)
show pon optics (Full CLI support)
show pon sfp-inventory (Full CLI support)

show pon sw-download (Full CLI support)
show pppoel2-stats (Porting FTTU)
show pppoel2-stats vlan (Porting FTTU)
show pppoel2-stats vlan extensive (Porting FTTU)
show pppoel2-stats vlan summary (Porting FTTU)
show qos interface-bandwidth (GPON support)
show qos pcc-rules fwd-port rule (Full CLI support)
show qos profile-usage bandwidth (GPON support)
show qos profile-usage ingress-qos (GPON support)
show qos profile-usage scheduler-node (GPON support)
show qos statistics lt-queue (GPON support)
show qos statistics lt-queue current-15min (GPON support)
show qos statistics lt-queue prev-15min (GPON support)
show qos tc-to-qmap (GPON support)
show trouble-shooting pon (PT Counters)
show trouble-shooting pon statistics (PT Counters)
show trouble-shooting pon statistics interface (PT Counters)
show uni (Full CLI support)
show uni ont (Full CLI support)
show uni ont tc-layer (Full CLI support)
show uni ont tc-layer olt-side (Full CLI support)
show uni ont tc-layer olt-side current-interval (Full CLI support)
show uni ont tc-layer olt-side previous-interval interval-nbr (Full CLI support)
show uni ont tc-layer ont-side (Full CLI support)
show uni ont tc-layer ont-side current-interval (Full CLI support)
show uni ont tc-layer ont-side previous-interval (Full CLI support)
show vlan fdb-board vlan-id (GPON support)
show voice ont (Full CLI support)
show voice ont call-hist call-hist-num (Full CLI support)
show voice ont pots (Full CLI support)
show voice ont pots diagnostics (Full CLI support)
show voice ont pots pb-dial-tone (Full CLI support)
show voice ont pots sip-dial-tone (Full CLI support)
show voice ont pots tc-layer (Full CLI support)
show voice ont pots tc-layer olt-side (Full CLI support)
show voice ont pots tc-layer olt-side current-interval (Full CLI support)

show voice ont pots tc-layer olt-side previous-interval interval-nbr (Full CLI support)
show voice ont pots tc-layer ont-side (Full CLI support)
show voice ont pots tc-layer ont-side current-interval (Full CLI support)
show voice ont pots tc-layer ont-side previous-interval interval-nbr (Full CLI support)
show voice ont service (Full CLI support)
show xdsl ont (Full CLI support)
show xdsl ont carrier-data (Full CLI support)
show xdsl ont carrier-data far-end (Full CLI support)
show xdsl ont carrier-data near-end (Full CLI support)
show xdsl ont counters (Full CLI support)
show xdsl ont counters far-end (Full CLI support)
show xdsl ont counters far-end channel (Full CLI support)
show xdsl ont counters far-end channel current-interval (Full CLI support)
show xdsl ont counters far-end channel previous-interval interval-no (Full CLI support)
show xdsl ont counters far-end line (Full CLI support)
show xdsl ont counters far-end line current-interval (Full CLI support)
show xdsl ont counters far-end line previous-interval interval-no (Full CLI support)
show xdsl ont counters near-end (Full CLI support)
show xdsl ont counters near-end channel (Full CLI support)
show xdsl ont counters near-end channel current-interval (Full CLI support)
show xdsl ont counters near-end channel previous-interval interval-no (Full CLI support)
show xdsl ont counters near-end line (Full CLI support)
show xdsl ont counters near-end line current-interval (Full CLI support)
show xdsl ont counters near-end line previous-interval interval-no (Full CLI support)
show xdsl ont cpe-tuc-inventory (Full CLI support)
show xdsl ont cpe-tur-inventory (Full CLI support)
show xdsl ont failure-status (Full CLI support)
show xdsl ont failure-status far-end (Full CLI support)
show xdsl ont failure-status near-end (Full CLI support)
show xdsl ont operational-data (Full CLI support)
show xdsl ont operational-data far-end (Full CLI support)
show xdsl ont operational-data far-end channel (Full CLI support)
show xdsl ont operational-data far-end line (Full CLI support)
show xdsl ont operational-data near-end (Full CLI support)
show xdsl ont operational-data near-end channel (Full CLI support)
show xdsl ont operational-data near-end line (Full CLI support)
show xdsl ont profiles (Full CLI support)

show xdsl ont xdsl-int (Full CLI support)
show xstp (FD 36p Ethernet LT (NELT-B))
show xstp bridge (FD 36p Ethernet LT (NELT-B))
show xstp instance (FD 36p Ethernet LT (NELT-B))
show xstp port (FD 36p Ethernet LT (NELT-B))
show xstp port-instance (FD 36p Ethernet LT (NELT-B))

Removed Commands

configure mcast src (Fixed multicast VLAN per IGMP channel)
configure mcast src packagemember (Fixed multicast VLAN per IGMP channel)
configure qos profiles scheduler (GPON support)
show qos profile-usage scheduler (GPON support)
show vlan fdb mac ((GPON support)
show bridge port-to-atm-pvc (ISAM-V H248:CLI enhancements)

1.2 Preface

Scope

This user guide describes the Command Line Interface (CLI) commands supported by the Nokia 7302 ISAM, 7330 ISAM FTTN and 7360 ISAM. These commands are used for installation, configuration, management and troubleshooting.

User Profile

The guide is intended for operating personnel (sometimes called craft persons).

The CLI Structure

The ISAM CLI is a command-driven interface accessible via telnet or via the craft terminal.

The CLI can be used to configure and manage ISAM equipment.

1.3 CLI Commands

Command Types

The commands of the CLI language can be divided into two groups: global and environmental commands.

Global commands (such as the **logout** command) can be entered in any context and have the same effect in each context.

Environmental commands (such as the **info** command) can only be entered in some contexts (for example, the **info** command cannot be used in the **show** node) and have a different effect in each context. The purpose of the command (for example, showing the configuration) is the same but the implementation or the generated output is different.

Some commands are also implicit. For example, when you enter only the node name **configure system security snmp community fden**, you run an implicit command that changes your context to the specified node and that creates this node if it did not previously exist.

The available commands are discussed in a separate chapter.

Access Rights

Not every operator can execute every command.

Access to commands is granted via the operator profile.

It is possible that an operator can execute a given command in one context and not in another.

Options and Parameters

Commands can have options and parameters.

Options are special parameters that are context insensitive. For example, you can enter the option **detail** after **info** in any context.

Options must be given at the end of the command preceeding the filter and printer specifications.

Different look and feel for IHUB CLI commands

A multi-core system exists of two CLI parsers. This can result in a different behavior and sometimes a different look and feel, depending on the CLI parser which is handling the command.

This section lists the most important differences in "behavior / look and feel" for the CLI commands listed in the different IHUB CLI guides, compared to the CLI commands listed in this document, and compared to the description of ISAM CLI in the subsections of this chapter.

Command Completion:
command can complete with a root command iso the IHUB command if the characters before the completion are similar to the characters of the root command
no command completion for combined types (e.g. nt-a:sfp:1)
no command completion for parameter alternatives
command completion can cease to work when entering a range

Ranges:
a range allows only decimal numeric values
command execution with numerical ranges will fail when a context change occurred
commands which contain a valid range syntax (no context change), are executed without displaying the different individual commands
Prompt:
dynamic resource-id is not displayed in the prompt
Online Help:
global command <help> not supported for IHUB commands : use <?> or <TAB>
online help not scaled down (not restrictive) depending the installed equipment practice
no online help for combined types
General:
global command <back> returns to the context from which the current level was entered
keystroke <insert> not supported
Info Command:
info command must be executed from within a node, it cannot take an argument
info configure detail command will fetch all the configurations from the IHUB context, irrespective of operator access rights
the output format option "xml" is not applicable, only a textual (=hierarchical) output is supported
Show Command:
the output is tailored depending on the provided parameters
Absolute path:
Cli commands can be executed in any context by specifying the full path from the CLI root. The command may or may not change the current context, depending on whether or not it is a leaf command
IACM command execution after executing "exit" :
IACM command execution can cease to work when the command was entered after executing the "exit" command from within an IHUB context, for which the parent node has both: IACM and IHUB children nodes
Tree Command:
When a tree command is executed in a node who has both :IACM and IHUB subnodes, the indentation in the tree structure gets lost for the IHUB related subnodes

1.4 Nodes

Node Definition

A command definition tree, further abbreviated to "command tree" is a structure of nested command nodes from which CLI commands can be derived. A command node consists of a node name and zero or more resource identifiers. The resource identifiers behave like parameters, but identify a particular resource. For example, **public** in **configure system security snmp community public** is an unnamed resource identifier of the node **community**.

One such command node identifies a context. A CLI command can be derived from a command tree starting from the root node, but a command with the same meaning and impact can also be derived from a lower level node or subnode. The following are examples of equivalent commands:

- **info configure system security snmp community public** in any node.
- **info system security snmp community public** in node **configure**
- **info security snmp community public** in node **configure system**
- **info snmp community public** in node **configure system security**
- **info community public** in node **configure system security snmp**
- **info** in node **configure system security snmp community public**

The root node is the highest level. Directly below the root node are important command nodes such as **configure** and **show**.

Node Creation

A dynamic node is a sub-node of the **configure** node that corresponds to a configurable resource that an operator can create.

An operator can create a dynamic node by navigating to it. The system will automatically create the node. The operator can configure its prompt in such a way that it shows if the operator navigated to an existing or a new node. The ability to create nodes is limited by the access rights of the user.

It is also possible that the system creates additional subnodes in other nodes, for example, in the **show** node due to the creation of a new dynamic node in the **configure** node.

Node Deletion

A dynamic node can be deleted by placing **no** in front of the node name. For example, **configure system security snmp no community public** deletes the specified node and all its subnodes. The ability to delete nodes is limited by the access rights of the operator.

Resource Attributes

The value of resource attributes can be changed by entering the name of the resource attribute followed by the new value. For example, **password plain:secret** sets the value of the resource attribute named **password** to the plain text string **secret**.

Resource attributes can be set to their default value by entering **no** followed by the name of the resource attribute. For example, **no password** sets the value of the resource attribute named **password** to the default value (no password required).

1.5 Parameters

Named and Unnamed Parameters

Parameters are characterised by a name and a type.

Parameters can be named or unnamed.

Named parameters are entered as two tokens: a keyword and a value (for example, **password plain:secret**). Some commands (such as **info**) require only the keyword.

Only the value token is entered for unnamed parameters (for example, **public** in the node name **community public**).

Most options and first resource identifiers are unnamed.

Parameters can be entered in any order. Only unnamed keys must be entered directly after the node name.

Parameter Types

Parameter values belong to a parameter type. Parameter types limit the parameter values to strings that the system can understand.

Parameter types consists of 1 to N fields with separators in between. Each field belongs to a basic type. The separator is in most cases a colon : or a slash /.

The name of parameter types always starts with an uppercase character and can contain an optional domain name. The domain name is separated from the parameter name by ::.

The sequence in which the fields appear can differ in case one of the fields belongs to an enumeration type. For example, if provided some possible values for the parameter type **ExtendedFileName** (the first field is an enumeration field with possible values **file** and **ftp**, *host-name*, *user-name*, *password* and *local-file* are also fields):

- **file:** *local-file*
- **ftp:** *host-name @ user-name : password / local-file*

Parameter types are built by combining 1 to N basic types.

Basic Types

Basic types can be divided in two groups: fixed length basic types and variable length basic types.

Examples of variable length basic types are:

- integers
- printable strings (representing operator chosen names or descriptions)
- SNMP object identifiers
- binary strings

The length of a variable length basic type is in most cases limited. The definition of logical length depends on the basic type: number of characters for printable strings, number of bytes for binary strings, and number of numbers in the object identifier for SNMP object identifiers.

Examples of fixed length basic types are:

- ip-address
- fixed-length printable strings
- enumeration types (limited list of allowed strings)

Basic Type Formatting Rules

Integers can be entered in a decimal format. Large integers can be abbreviated as follows:

- *decimal-number* **k** which is equal to *decimal-number* ***1000** (For example: **3k** is equal to **3000**)
- *decimal-number* **M** which is equal to *decimal-number* ***1000000**
- *decimal-number* **G** which is equal to *decimal-number* ***1000000000**

Binary strings must be entered as: *hex-byte* : *hex-byte* :...: *hex-byte*. *hex-byte* is a number between 0 and 255 in hexadecimal format (all lowercase). For example, **3f:23:ff:b2** is a valid binary string.

Object identifiers and ipv4-addresses must be entered as: *decimal-number* . *decimal-number* *decimal-number*. For example, **128.17.32.45** is a valid object identifier.

The values of all fields may be placed within double quotes. A field separator can never be placed within double quotes. For example, **"1"/"1"** is a valid shelf identifier, but **"1/1"** is not a valid shelf identifier.

A field value can contain multiple double quotes. For example, **"hallo world"** is equivalent to **hallo** " **world** or to **"hallo"** " **world"**.

Printable strings must be placed within double quotes if they contain special characters: double quote **"**, a backslash ****, a question mark **?**, a cross **#**, a space, a tab, a carriage return, or a new line.

The backslash **** is the escape character. The double quote **"** and backslash **** characters must be preceded by the escape character. The **\char** is equivalent to *char* with the following exceptions:

- **\r** : carriage-return
- **\t** : tab
- **\n** : new-line

In some cases it is possible that a command is ambiguous. For example, **info operator detail** can be interpreted in two ways: list the configuration of the operator with the name **detail** or list the configuration of all operators in detail.

The ambiguity is solved by the parser in the following way: if the string contains quotes, it is interpreted as a printable string, otherwise it is interpreted as a keyword. For example, **info operator "detail"** lists the configuration of the operator with the name **detail** and **info operator detail** lists the configuration of all operators in detail.

Syntax Check

The system verifies if each typed character is syntactically correct.

In case the system detects a syntax error, it will position the cursor at the offending character and beep.

This can give strange effects if you are entering characters in the 'insert mode': the invalid characters will shift to the right and any newly entered character will be inserted in front of the faulty characters.

To avoid this strange effect, it is recommended to work in the (default) overwrite mode.

Command Repetition

Values of parameters may contain decimal, hexadecimal or character ranges. These ranges indicate that the concerned command must be repeated a number of times with the different values as specified in the range.

Decimal ranges are entered as [*d*: *start*...*end*] in which *start* and *end* are integers. Example of a decimal range: **lt:1/1/[4...16]**

Hexadecimal ranges are entered as [*h*: *start*...*end*] in which *start* and *end* are hexadecimal numbers. *start* and *end* values may not contain uppercase characters and the number of characters of the first *start* value determines the number of characters to be entered for the following values in the range. Example of a hexadecimal range:

03:06:ff:[h:aa...bd]

Character ranges are entered as [*c*: *start...end*] in which *start* and *end* are characters. *start* and *end* value must belong to the same character class: digit, lowercase or uppercase. Special characters are not allowed. Example of a character range : **operator[c:a...f]**

Ranging is not supported for float values

Ranges have following restrictions:

- One command may only contain 1 range.
- The default range type is decimal. It will be used if the type is not explicitly mentioned with '**d**:', '**h**:' or '**c**:'.
- Subranges can be separated with a comma. For example: **[d:17...19,32,60...62]** will be replaced consecutively with the values 17, 18, 19, 32, 60, 61 and 62.
- Ranges between quotes are not expanded.
- Command completion may refuse to work once a range is entered.
- Execution of command repetition will stop once an iteration in the range fails.

The system sometimes restricts which range type may be used: the system only allows a decimal range where a decimal number can be entered or a hexadecimal range where a hexadecimal number can be entered. It even imposes that the range replaces completely the number. Example: **1[2...3]** is invalid, **[12...13]** must be entered instead. Also the *start* and *end* of the range must fall in the allowed range for the number. Only text strings may contain all types of ranges.

The way the system handles a range depends on the command.

- Some commands can handle ranges directly. Repeating the command will be done internally. The command will then behave for the operator as a normal command..
- For the other commands, the system will execute the command *end* - *start* + 1 times in which the specified range is each time replaced by a number out of the range. Each expanded command is shown to the operator. Commands that normally change the context, don't do this in this case. The command repetition can be stopped via an interrupt.
- Range commands in combination with help "?" character always show the complete list of available parameters and subnodes and do not suppress subnodes in case of the existing nodes.

Obsolete and Replaced Parameters

Parameters can become obsolete or parameters are substituted by new parameters. See the definition and strategy in section 1.11 CLI Backward Compatibility.

1.6 Filters

The language provides filters to manipulate the output of commands.

For list of available filters, please refer to command description of section "CLI Filters".

Filters can be specified in case the command generates output. They are separated from the basic command with a pipe character |.

The user can specify a sequence of filters as in following example: **info | match exact:1/1 | count lines**.

1.7 Printers

The language provides printers to allow the user to decide how the output must be printed on his terminal.

The available printers are discussed in detail in a separate chapter.

Printers can be specified in case the command generates output. They are separated from the basic command with a pipe character |.

The user can specify maximum one printer as in following example: **info | match exact:1/1 | more**

The default printer can be specified for the CLI session or the operator.

1.8 Getting help

The user can get help in two ways.

The first is using the **help** command. This gives an extensive explanation on the command.

The user can also enter a question-mark **?** at each position in the command. He will then get a short explanation on what he can enter at this position in the command.

For example: **configure system security operator ?** gives following output:

```
<Sec::OperatorName> : the name of the operator [a-z0-9] (1<=x<=11)
```

This has the following meaning:

- **Sec::OperatorName** is the name of the parameter type. This indicates that the user must enter a parameter value.
- **:** indicates that the concerned object is an optional parameter. Mandatory parameters are indicated with **!**, obsolete parameters and obsolete nodes with **X**, regular nodes with **+**, commands with **-**
- **the name of the operator** explains how the parameter will be interpreted by the system.
- **[a-z0-9]** indicates that the value may consist of the lower-case alphanumeric characters, the ASCII characters **a** till **z** and **0** till **9**.
- **(1<=x<=11)** indicates that the name must consist of at least 1 character and maximum 11 characters.

1.9 The CLI Prompt

The prompt can be configured by the user. The prompt can be specified for the session, for an operator or for an operator profile. If no specific prompt is specified for the session, the prompt specified for the operator is taken and the prompt specified for the operator profile is taken if no prompt is specified for the operator.

The prompt can be composed with following components :

- **%n** : the name of the current operator.
- **%s** : the current numbering scheme (**typ|leg|pos**).
- **%i** : the current system id.
- **%t** : the current timestamp.
- **%!** : the current history number.
- **% num d** : the current context.
 - *num* is the maximum number of components (starting from the last) that are shown (default is all).
 - each component will be separated from the next one with a >.
 - a > is also added in front of the first component.
- **%%** : a %
- **%c** : # if the current node was an existing node or \$ if it is newly created.
- any other character is just added to the prompt as is.

The default prompt is "**%s:%n%d%c**"

The system will add a > at the end of each empty prompt or each prompt that consists purely out of white-space

The ISAM CLI prompt configuration supports adding one or more components starting with the "%" escape character. This behavior is extended with the use of the "\$" as an escape character. The system behavior is the same as when using the "%" escape character.

For example: an occurrence of "\$n" is replaced with the name of the current operator.

For backward compatibility, the "\$" character must be used exclusively without the "%" character. As soon as the "%" character is used in the string, all occurrences of the "\$" character will be considered as a literal and will not be replaced with the component it refers to.

The following command already exists, except that the prompt value uses "%" instead of "\$". The usage of "\$" is now also supported:

configure system security operator abcd prompt \$h:\$3d:\$n:\$c:\$i:\$!:\$s:\$

Instead of "%", "\$" is accepted as an escape character. "%" continues to be supported for backward compatibility.

Example:

leg:abcd>configure>system>security>operator>abcd# prompt \$h:\$3d:\$n:\$c

System_id:>security>operator>abcd:abcd:#

If at least one "%" is present in the prompt, the priority will be given to "%" and "\$" will be treated as a literal.

Example:

leg:abcd>security>operator>abcd:abcd:#prompt \$h:%3d:%s:%n:%

\$h:\$3d:\$s:abcd:#

Reverting to all "\$":

\$h:\$3d:\$s:abcd:#prompt \$h:\$3d:\$s:\$n:\$c

System_id:>security>operator>abcd:leg:abcd:#

1.10 Entering CLI Commands

Following key strokes are treated in a special way while entering commands:

- *arrow-left* : move the cursor one position to the left.
- *arrow-right* : move the cursor one position to the right.
- *arrow-up* : get the previous stored command (round-robin, starts with the last stored command).
- *arrow-down* : get the next stored command (round-robin, starts with the oldest stored command).
- *insert* : toggle between insert and overwrite mode.
- *backspace* : delete the character before the cursor and move the cursor one position to the left.
- *delete* : delete the character under the cursor.
- *control-c* : interrupt the current command or clear the current entered string on a telnet or SSH terminal.
- *control-a* : move the cursor to the beginning of the line.
- *control-p* : get the previous stored command (round-robin, starts with the last stored command).
- *control-n* : get the next stored command (round-robin, starts with the oldest stored command).
- *control-k* : delete all characters starting from the position of the cursor.
- *control-u* : delete all entered characters.
- *control-w* : delete one word before the cursor.
- *control-x* : interrupt the current command or clear the current entered string on the craft terminal.
- *control-l* : clear screen.
- *tab* : trigger command completion.
- *space* : terminate a token and trigger command completion, unless it is placed between double quotes.
- *#* : treat all following commands as comment, unless they are placed between double quotes.
- *?* : trigger online-help, unless it is placed between double quotes.

Entering a tab triggers command completion.

The system will try to expand the existing entered string until an ambiguity is found. If there is no ambiguity, a space will be added behind the token.

Entering a space behind an entered string has - for keywords - the same effect as the tab.

For example: entering **c** followed by a tab in the root node will expand to **configure**.

For example: entering **c** followed by a space in the root node will expand to **configure**.

For example: entering **configure system security operator admin pr** followed by a tab will expand to **configure system security operator admin pro** because there is still an ambiguity here between **prompt** and **profile**.

1.11 CLI Backward Compatibility

Strategy

ISAM has provided a Command Line Interface since the beginning. With each new Software Release, new features are added and as a consequence also the CLI commands need to evolve.

New features often result in new commands or extension of existing commands.

Strategy with respect to Configuration Commands

When new features become available, commands and parameters will be affected. The objective of the strategy is that existing configuration scripts will not be broken, i.e. they can still be used without throwing errors.

New commands can be defined that are an add-on to the existing set of commands. Existing commands may need to be expanded or they may be replaced by a new command. Old commands may become useless and will be obsolete.

When existing commands are expanded, new parameters may need to be added on to a command, existing parameters may need to be extended or parameters may be replaced by a new parameter. Exceptionally, parameters become useless and will be obsolete.

Notice that obsolete commands and parameters will not be maintained for new features; moreover, eventually, in due time, in the scope of a major SW release, an obsolete command and/or parameter will actually be removed from the CLI Command Tree. See chapter 'Phase out strategy obsolete commands and/or parameters'.

Backward Compatibility support for configuration commands.

Configuration commands shall remain backwards compatible. A command may become obsolete because either it is no longer useful or it needs to be replaced by a new command.

At the node level there are two ways:

- Obsolete command
 - A command becomes obsolete when the corresponding functionality is removed from the system. In order to avoid that configuration scripts from previous software releases break, the command is not removed. Rather, executing the command will have no effect and the command will never appear in the output of an info command.
- Obsolete and Replaced command
 - A command may get replaced by a new one. This may occur when the corresponding functionality is modified or expanded. In order to avoid that configuration scripts from previous software releases break, the command is not removed. Rather, the command is defined as 'obsolete and replaced'. This means that the command is still valid and can still be executed but it will never appear in the output of an info command.

Backward Compatibility support for Configuration Commands parameters.

Configuration commands shall remain backwards compatible. A way to accomplish this is by allowing parameters of the command to evolve. A parameter becomes obsolete because either it is no longer useful or it needs to be replaced by a new parameter.

- Obsolete parameter
 - A parameter becomes obsolete when the corresponding functionality is no longer supported by the system. In order to avoid that configuration scripts from previous software releases break, the parameter is not removed. Rather, entering the parameter will have no effect and the parameter will never appear in the output of an info command.

- Obsolete and Replaced parameter
 - A parameter may get replaced by a new one. This may occur when the corresponding functionality is modified or extended. In order to avoid that configuration scripts from previous software releases break, the parameter is not removed. Rather, the parameter is defined as 'obsolete and replaced'. This means that the parameter is still valid and can still be executed but it will never appear in the output of an info command. The replacing parameter will appear in the output of an info command and supports the modified or extended functionality.

Strategy with respect to Show Commands

The output of any show command is available in various formats. Formatting of the output may change over time. XML type of output is formalized. Writers of CLI scripts are encouraged to use the XML format, as this output is ignorant of any formatting.

The information displayed may change as a result of new features. The goal is to add new parameters to the existing display output without modifying the current parameters. In exceptional cases the latter cannot be guaranteed.

1.12 Phase Out Strategy Obsolete Commands and/or Parameters

This chapter describes the phase out strategy that will be followed for obsolete commands and/or obsolete parameters.

Announcement Release

The announcement release is the release in which we announce to the customer that a defined set of "impacted" CLI commands will phase-out in the phase-out release. The announcement release is independent from the release in which the commands and/or parameters became 'obsolete'. The "impacted" CLI commands are the commands which are obsolete or the commands which contain obsolete parameters.

See chapter 'Command Phase Out Announcement Release' for the list of "impacted" CLI commands.

Phase Out Release

This is the future release in which the listed announced "impacted" commands are **removed (obsolete command) or modified (obsolete parameter)**. From this release onwards, obsolete commands and/or parameters are no longer supported. The obsolete commands will be indicated as removed in the history section of the CLI user guide. The commands with obsolete parameters will be indicated as modified commands in the history section of the CLI user guide.

The phase-out release is at least the release succeeding the announcement release.

Customer Impact

- List of impacted commands (See chapter 'Command Phase Out Announcement Release') should carefully be checked in the CLI Command Guide chapter Announcement Release. The obsolete commands and/or obsolete parameters are indicated in the command tree by the prefix **X**.
- The customer should determine the phase-out release.
- Any OSS systems and/or scripts using CLI commands should be checked and updated if required.
- Once the command is phased-out, the normal error reporting will be applicable.

1.13 Command Phase Out Announcement Release

This section gives a list of all the impacted CLI commands which will phase out in the phase-out release. See previous chapter 'phase out strategy obsolete commands and/or parameters' for more info about the phase-out release'. The listed CLI commands are commands which are obsolete or commands which contain obsolete parameters.

Not supported commands/parameters from a later release onwards
configure cm (IMPORTANT: All DPoE related commands will be moved to a separate CLI guide)
configure bridge port vlan-id (parameter network-vlan is replaced by l2fwder-vlan and vlan-scope)
configure l2cp (end of support for ANCP/L2CP)
configure pon interface power-shed-prof (command will be replaced by 'configure generic-pon power-shed-prof')
configure qos profiles cac cac-type pon-cac (command will be replaced by 'configure qos profiles cac cac-type generic-pon-cac')
configure system pon-ont (command will be replaced by 'configure generic-pon ont' and 'configure pon pwrbrst-mode')
show l2cp (end of support for ANCP/L2CP)
configure transport ip default-ttl (obsolete and replaced by "configure system management default-ttl")
configure equipment sfpe1t1 framer (removal of obsolete loopback commands)
show qos dsl-bandwidth (will be replaced by "show qos interface-bandwidth")
show qos shdsl-bandwidth (will be replaced by "show qos interface-bandwidth")
show qos ethernet-bandwidth (will be replaced by "show qos interface-bandwidth")
show transport ether-ifmault (will be replaced by "show ethernet mau")
show transport ether-ifsfp1t (will be replaced by "show ethernet sfp")
show transport ether-ifdot3lt (will be replaced by "show ethernet dot3stats")
configure atm [no]ip-cross-connect (obsolete and replaced by "configure ipoa/e-iw")
configure vlan (parameters "pvid-usage" "pppoe-relay" "circuit-id" "remoted-id" will be deleted)
configure vlan (parameter "broadcast-frames" is replaced by "new-broadcast" and will be deleted)
configure vlan (parameter "secure-forwarding" is replaced by "new-secure-fwd" and will be deleted)
configure bridge (obsolete parameter "accept-frame-type" will be deleted)
configure bridge (parameter "old-tag" is replaced by "tag" and will be deleted)
configure xdsl ont line pm-collect pm (is replaced by "configure xdsl ont line l2 pm enable")
configure xdsl ont line pm-collect tca (is replaced by "configure xdsl ont line l2 tca enable")
configure hpna ont port pm-collect (is replaced by "configure hpna ont l2 pm")
configure veip ont port pm-collect (is replaced by "configure veip ont l2 pm")
configure ethernet ont port pm-collect (is replaced by "configure ethernet ont phy pm")

2- Environment Configuration Commands

2.1 Environment Configuration Command Tree	2-160
2.2 Environment Configuration Command	2-161

2.1 Environment Configuration Command Tree

Description

This chapter gives an overview of nodes that are handled by "Environment Configuration Commands".

Command Tree

----environment

- [no] prompt
- [no] terminal-timeout
- [no] print
- [no] screen-length
- [no] inhibit-alarms
- [no] mode

2.2 Environment Configuration Command

Command Description

This command allows the operator to manage the session-specific parameters. These parameters are only valid for a specific session and are lost when the user logs out.

The default values for **prompt** and **print** can be found in **configure system security operator** operator-name.

The default value for **terminal-timeout** can be found in **configure system security profile** profile-name.

terminal-timeout: A value of 0 equals an infinite timeout value (i.e. the terminal will never time out).

The prompt can be composed with following components :

- **%n** : the name of the current operator.
- **%s** : the current numbering scheme (**typ|leg|pos**).
- **%i** : the current system id.
- **%t** : the current system time.
- **%!** : the current history number.
- **% num d** : the current context.
 - num is the maximum number of components (starting from the last) that are shown (default is all).
 - each component will be separated from the next one with a >.
 - a > is also added in front of the first component.
- **%%** : a %
- **%c** : # if the current node was an existing node or \$ if it is newly created.
- **%h** : the current system id.
- any other character is just added to the prompt as is.

Next to %, ISAM supports the use of the \$ as an escape character. The system behavior is the same as when using the % escape character, e.g. an occurrence of \$n is replaced with the name of the current operator. For backward compatibility, the \$ character must be used exclusively without the % character. As soon as the % character is used in the string, all occurrences of the \$ character will be considered as a literal and will not be replaced with the component it refers to.

User Level

The command can be accessed by operators with all privileges, and executed by operators with all privileges.

Command Syntax

The command has the following syntax:

```
> environment [ no prompt | prompt <Sec::Prompt> ] [ no terminal-timeout | terminal-timeout
<Sec::EnvInactivityTimeout> ] [ no print | print <Sec::EnvMore> ] [ no screen-length | screen-length
<Sec::ScreenLength> ] [ [ no ] inhibit-alarms ] [ no mode | mode <Cli::Mode> ]
```

Command Parameters

Table 2.2-2 "Environment Configuration Command" Command Parameters

Parameter	Type	Description
[no] prompt	Parameter type: <Sec::Prompt>	optional parameter with default

2 Environment Configuration Commands

Parameter	Type	Description
	Format: - a specification of the prompt - length: x<=31	value: "" the specification of the prompt
[no] terminal-timeout	Parameter type: <Sec::EnvInactivityTimeout> Format: (default timeout : <Sec::InactivityTimeout>) Possible values: - default : the default inactivity timeout - timeout : specify the inactivity timeout Field type <Sec::InactivityTimeout> - specify the inactivity timeout of the terminal - unit: minutes - range: [0...120]	optional parameter with default value: "timeout : 30" specify the inactivity timeout of the terminal
[no] print	Parameter type: <Sec::EnvMore> Format: (more no-more default) Possible values: - more : the output is passed via the more filter - no-more : the output is put directly on the terminal - default : use the method as specified by the profile	optional parameter with default value: "default" specifies the way the output is printed on the terminal
[no] screen-length	Parameter type: <Sec::ScreenLength> Format: - specifies the number of lines to be printed on the terminal for paging. value 0 disables the configuration - range: [0,2...10000]	optional parameter with default value: "0" specifies the number of lines to be printed on the terminal for paging
[no] inhibit-alarms	Parameter type: boolean	optional parameter disables the alarm reporting in the current session
[no] mode	Parameter type: <Cli::Mode> Format: (batch interactive) Possible values: - batch : non-interactive mode intended for scripting tools - interactive : interactive mode intended for human operators	optional parameter with default value: "interactive" the mode in which the CLI handles command input

3- Alarm Configuration Commands

3.1 Alarm Configuration Command Tree	3-164
3.2 Alarm Log Configuration Command	3-166
3.3 Alarm Entry Configuration Command	3-168
3.4 Alarm Filter Configuration Command	3-223
3.5 Alarm Suppression Filter Configuration Command	3-278
3.6 Alarm Delta Log Configuration Command	3-280
3.7 Customizable Alarm Profile Configuration Command	3-282
3.8 HGU TR069 Customizable Alarm Configuration Command	3-287

3.1 Alarm Configuration Command Tree

Description

This chapter gives an overview of nodes that are handled by "Alarm Configuration Commands".

Command Tree

- configure**
 - alarm**
 - log-sev-level
 - log-full-action
 - non-itf-rep-sev-level
 - entry**
 - **(index)**
 - [no] severity
 - [no] service-affecting
 - [no] reporting
 - [no] logging
 - filter**
 - **(fltr-type)**
 - **filterid**
 - alarmid
 - [no] status
 - [no] threshold
 - [no] window
 - suppression**
 - **filterid**
 - interface
 - alarmid
 - [no] status
 - [no] threshold
 - delta-log**
 - indet-log-full-action
 - warn-log-full-action
 - minor-log-full-action
 - major-log-full-action
 - crit-log-full-act
 - [no] custom-profile**
 - **(name)**
 - [no] mnemonic1
 - [no] description1
 - [no] visible1
 - [no] audible1
 - [no] polarity1
 - [no] severity1
 - [no] mnemonic2
 - [no] description2
 - [no] visible2
 - [no] audible2
 - [no] polarity2
 - [no] severity2
 - [no] mnemonic3

- [no] description3
- [no] visible3
- [no] audible3
- [no] polarity3
- [no] severity3
- [no] mnemonic4
- [no] description4
- [no] visible4
- [no] audible4
- [no] polarity4
- [no] severity4
- [no] mnemonic5
- [no] description5
- [no] visible5
- [no] audible5
- [no] polarity5
- [no] severity5
- [no] hguir069-cust
- (alarm-id)
- description

3.2 Alarm Log Configuration Command

Command Description

This command allows the operator to maintain a log that contains all alarm state changes by enabling the logging mode and setting the severity level equal to or higher than the severity level that the operator is interested in.

User Level

The command can be accessed by operators with alarm privileges, and executed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> configure alarm log-sev-level <Alarm::alarmSeverityReport> log-full-action <Alarm::alarmLogFullAction>
non-itf-rep-sev-level <Alarm::alarmSeverityReport>
```

Command Parameters

Table 3.2-2 "Alarm Log Configuration Command" Command Parameters

Parameter	Type	Description
log-sev-level	Parameter type: <Alarm::alarmSeverityReport> Format: (indeterminate warning minor major critical) Possible values: - indeterminate : not a definite known severity level - warning : just to inform as a warning - minor : not service affecting - major : service affecting - critical : service breaking	<i>optional parameter</i> set the lowest severity level to log alarms
log-full-action	Parameter type: <Alarm::alarmLogFullAction> Format: (wrap halt) Possible values: - wrap : older log records are overwritten by recent ones - halt : logging is stopped until the log buffer is reset	<i>optional parameter</i> set the action if log buffer is full
non-itf-rep-sev-level	Parameter type: <Alarm::alarmSeverityReport> Format: (indeterminate warning minor major	<i>optional parameter</i> set minimum severity level to report non itf alarms

Parameter	Type	Description
	critical) Possible values: - indeterminate : not a definite known severity level - warning : just to inform as a warning - minor : not service affecting - major : service affecting - critical : service breaking	

3.3 Alarm Entry Configuration Command

Command Description

This command allows the operator to manage local alarm entries.

User Level

The command can be accessed by operators with alarm privileges, and executed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> configure alarm entry (index) [ no severity | severity <Alarm::alarmSeverity> ] [ [ no ] service-affecting ] [ [ no ] reporting ] [ [ no ] logging ]
```

Command Parameters

Table 3.3-1 "Alarm Entry Configuration Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: (all xtca-ne-es xtca-ne-ses xtca-ne-uas xtca-ne-day-es xtca-ne-day-ses xtca-ne-day-uas xtca-fe-es xtca-fe-ses xtca-fe-uas xtca-fe-day-es xtca-fe-day-ses xtca-fe-day-uas xtca-leftrs xtca-day-leftrs xtca-fe-leftrs xtca-fe-day-leftrs xtca-auto-port-reset xtca-reinit xtca-day-reinit xdsl-ne-los xdsl-ne-lof xdsl-ne-lom xdsl-ne-ese xdsl-act-cfg-error xdsl-act-not-feas	alarm type

Resource Identifier	Type	Description
	xds1-up-br-reach xds1-ne-ncd xds1-ne-lcd xds1-fe-los xds1-fe-lof xds1-fe-lpr xds1-fe-lol xds1-fe-lom xds1-fe-ese xds1-fe-upbo-vio xds1-fe-cpe-pol xds1-tpstc-mis xds1-act-comm xds1-act-modem xds1-do-br-reach xds1-fe-ncd xds1-fe-lcd xds1-frtx-init-fail xds1-vect-dle xds1-fe-mis-peer-35b vectline-xtc-var-vict vectline-xtc-var-dist vectline-corp-errf vect-cpe-cap-mismatch vectline-conf_notfeas vect-vp-lt-mismatch vect-inv-qsf vect-vp-lt-fail vect-no-gain-at-init sw-rollback db-rollback xvps-inv-dbase inv-cde-file miss-cde-file cde-hash-error low-disk-space cell-discard-up cell-discard-down persist-data-loss mac-conflict vmac-full snmp-comm-lost preferred-mode timing-reference nt-disk-95%full shub-loc cf-error back-pnl-inv ihub-conf-loss rack-power rack-fan-unit1 rack-fan-unit2 shelf-mismatch shelf-missing shelf-install-missing door ac-power-fail	

3 Alarm Configuration Commands

Resource Identifier	Type	Description
	board-mismatch	
	waiting-for-sw	
	temp-exceeded	
	backplane-data-failure	
	temp-shutdown	
	board-missing	
	board-instl-missing	
	board-init	
	board-reset-prot	
	sem-power-fail	
	sem-ups-fail	
	board-reset-cf	
	vlan-assign-fail	
	vsa-info-invalid	
	auth-mac-conflict	
	user-pwd-fault	
	up-plan-bitrate	
	up-min-bitrate	
	up-config-not-feas	
	down-plan-bitrate	
	down-min-bitrate	
	down-config-not-feas	
	non-bonding-cpe	
	multiple-cpes	
	register	
	group-incomplete	
	host-sfp-los	
	host-sfp-tx-fail	
	host-sfp-not-prst	
	host-sfp-inv-id	
	host-sfp-ctrl-fail	
	host-sfp-rmtlt	
	host-sfp-mismatch	
	host-sfp-incompt	
	exp-sfp-los	
	exp-sfp-tx-fail	
	exp-sfp-not-prst	
	exp-sfp-inv-id	
	exp-sfp-ctrl-fail	
	exp-sfp-1-los	
	exp-sfp-2-los	
	ext-qsfv-invld	
	tx-power-high-alarm	
	tx-power-low-alarm	
	rx-power-high-alarm	
	rx-power-low-alarm	
	tx-biascur-high-alarm	
	tx-biascur-low-alarm	
	volt-high-alarm	
	volt-low-alarm	
	temp-high-alarm	
	temp-low-alarm	
	tx-power-high-warn	
	tx-power-low-warn	
	rx-power-high-warn	
	rx-power-low-warn	
	tx-biascur-high-warn	

Resource Identifier	Type	Description
	tx-biascur-low-warn volt-high-warn volt-low-warn temp-high-warn temp-low-warn onu-unprovisioned signal-loss bitrate-high opmodule-mismatch key-fail-one-churn key-fail-three-churn oam-discov-fail report-timeout total-packets-exceed arp-packets-exceed dhcp-packets-exceed igmp-packets-exceed pppoe-packets-exceed nd-packets-exceed icmpv6-packets-exceed mld-packets-exceed dhcpv6-packets-exceed cfm-packets-exceed dsx1-serdes-fail dsx1-tributary1-fail dsx1-tributary2-fail dsx1-los-fail dsx1-ais-sync dsx1-lof-sync dsx1-los-sync dsx1-deg-fail dsx1-rei-from-liu dsx1-rdi-from-liu dsx1-crc6-from-liu dsx1-crc4-from-liu dsx1-crc4-th-from-liu dsx1-ais-from-liu dsx1-los-from-liu dsx1-lof-from-liu dsx1-lomf-from-liu dsx1-rei-from-iwf dsx1-rdi-from-iwf dsx1-crc6-from-iwf dsx1-crc4-from-iwf dsx1-crc4-th-from-iwf dsx1-ais-from-iwf dsx1-los-from-iwf dsx1-lof-from-iwf dsx1-lomf-from-iwf pppce-trans-15min-tca pppce-sess-15min-tca pppce-trans-1day-tca pppce-sess-1day-tca custom1 custom2 custom3 custom4	

3 Alarm Configuration Commands

Resource Identifier	Type	Description
	custom5	
	he-custom1	
	he-custom2	
	he-custom3	
	he-custom4	
	he-custom5	
	he-custom6	
	custom6	
	custom7	
	custom8	
	custom9	
	custom10	
	custom11	
	custom12	
	custom13	
	custom14	
	custom15	
	custom16	
	custom17	
	loss-swo-cap	
	ping-check-fail	
	der-temp1	
	der-temp2	
	der-temp3	
	der-temp4	
	der-temp5	
	der-temp6	
	der-temp7	
	der-temp8	
	der-temp9	
	der-temp10	
	der-temp11	
	der-temp12	
	der-temp13	
	der-temp14	
	der-temp15	
	der-temp16	
	der-temp17	
	der-temp18	
	der-temp19	
	der-temp20	
	der-temp21	
	der-temp22	
	der-temp23	
	der-temp24	
	der-temp25	
	der-temp26	
	der-temp27	
	der-temp28	
	der-temp29	
	der-temp30	
	der-temp31	
	der-spa1	
	der-spa2	
	der-spa3	
	der-spa4	
	der-spa5	

Resource Identifier	Type	Description
	der-spa6	
	der-spa7	
	der-spa8	
	der-spa9	
	der-spa10	
	der-spa11	
	der-spa12	
	der-spa13	
	der-spa14	
	der-spa15	
	der-spa16	
	der-spa17	
	der-spa18	
	der-spa19	
	der-spa20	
	der-spa21	
	der-spa22	
	der-spa23	
	der-spa24	
	der-spa25	
	der-spa26	
	der-spa27	
	der-spa28	
	der-spa29	
	der-spa30	
	der-spa31	
	apsf-alarm	
	custextalarm1	
	custextalarm2	
	custextalarm3	
	custextalarm4	
	custextalarm5	
	pluginfan	
	plugin-dc-a	
	plugin-dc-b	
	plugin-dg	
	ntr-a-loss	
	ntr-b-loss	
	xvps-conf-loss	
	mac-entry-nofree	
	fibre-conn-mismatch	
	link-cap-mismatch	
	eqpt-cap-mismatch	
	ctrl-dnld-failure	
	melt-hw-issue	
	melt-board-reset	
	board-shelf-mismatch	
	mgnt-type-mismatch	
	fileserv-unavail	
	shdsl-n-loopback	
	shdsl-c-loopback	
	shdsl-conferr	
	shdsl-atm-lcd	
	shdsl-lpr	
	shdsl-secu-err	
	shdsl-dev-fault	
	shdsl-atm-ncd	

3 Alarm Configuration Commands

Resource Identifier	Type	Description
	shdsl-n-losw	
	shdsl-c-losw	
	shdsl-n-aten	
	shdsl-c-aten	
	shdsl-n-snr	
	shdsl-c-snr	
	shdsl-n-dccont	
	shdsl-c-dccont	
	shdsl-c-actfail	
	e1-fe-rai	
	e1-ne-rai	
	e1-fe-ais	
	e1-ne-ais	
	e1-lof	
	e1-los	
	e1-loopback	
	ima-grp-fe-su	
	ima-grp-fe-cfg	
	ima-grp-ne-cfg	
	ima-grp-fe-nl	
	ima-grp-ne-nl	
	ima-grp-fe-blk	
	ima-lnk-lif	
	ima-lnk-lods	
	ima-lnk-misc	
	ima-lnk-rfi	
	ima-lnk-fault	
	ima-lnk-txblk	
	ima-lnk-rxblk	
	bad-digitmap	
	dhcp-unreach	
	dhcp-no-srv	
	dhcp-inv-srv	
	norpniewithsoftdsp	
	unknown-sub	
	ground-key	
	port-hightemp	
	port-jbfltca	
	reg-domainname	
	reg-auth	
	reg-timeout	
	reg-srvfailresp	
	inv-domainname	
	inv-auth	
	inv-timeout	
	inv-srvfailresp	
	subs-srvfailresp	
	subs-domainname	
	subs-auth	
	subs-refreshfail	
	subs-inittimeout	
	emergency-call	
	e1sip-reg-domainname	
	e1sip-reg-auth	
	e1sip-reg-timeout	
	e1sip-reg-srvfailresp	
	e1sip-inv-domainname	

Resource Identifier	Type	Description
	e1sip-inv-auth e1sip-inv-timeout e1sip-inv-srvfailresp e1sip-emergency-call e1itf-ais-signal e1itf-los-signal e1itf-rai-signal e1sip-misconfig-mgc10 e1sip-nsmprf-missed e1t1itf-recv-ais e1t1itf-recv-los e1t1itf-recv-rai transport-mismatch dns-lookup-failure none-dns-srv no-dns-srv none-srv no-srv reg-srv-unreach proxy-srv-unreach dhcp-srv-unreach fo-trigger fb-trigger du-trigger ssp-missing dns-pool-exceed lsa-fo-trigger reg-domainname-sec reg-auth-sec reg-timeout-sec reg-srvfailresp-sec inv-domainname-sec inv-auth-sec inv-timeout-sec inv-srvfailresp-sec subs-srvfailresp-sec subs-domainname-sec subs-auth-sec subs-refreshfail-sec subs-inittimeout-sec emergency-call-sec fanout up-overflow upobc-overflow dwobc-overflow dw-overflow lwpri-overflow queue-drop queue-load queue-peak-usage mgc-unreachable failover-to-esamgc sgc-unreachable lcard-unreach-srvcard lcard-type-mismatch meg-unknown-sub meg-ground-key	

3 Alarm Configuration Commands

Resource Identifier	Type	Description
	meg-high-temp meg-act-fail meg-over-current line-showering low-qos-packetloss low-qos-jitter low-qos-delay sig-brd-persist-loss sig-brd-disk-full sig-brd-db-rollback mg-overload meg-unknown-sub-sec line-showering-sec loss-env-mon etca-los etca-fcs etca-day-los etca-day-fcs etca-rx-octets etca-tx-octets etca-day-rx-octets etca-day-tx-octets user-sfp-los user-sfp-tx-fail user-sfp-not-prst user-sfp-inv-id user-sfp-t-exceed user-sfp-mismatch uplink-sfp-los uplink-sfp-tx-fail uplink-sfp-not-prst uplink-sfp-inv-id uplink-sfp-t-exceed uplink-sfp-mismatch loss-lsmswp-cap inv-xvps-pair-data network-power-loss hw-fault bat-miss bat-fail bat-low bat-a-fail bat-b-fail ac-vol-out-range network-power-loss-b sem-ac-power-fail sem-ups-low-volt dc-a-fail dc-b-fail plan-power-mismatch water-seepage-in-box sealed-box-open dc-a-vol-out-range dc-b-vol-out-range inlet-temp-major inlet-temp-critical psu-fail-crit	

Resource Identifier	Type	Description
	psu-a-fail-presence psu-a-fail-vin-ac-nok psu-a-fail-vin-uv psu-a-fail-vin-ov psu-a-fail-vout-uv psu-a-fail-vout-ov psu-a-fail-iout-oc psu-a-fail-overtemp psu-b-fail-presence psu-b-fail-vin-ac-nok psu-b-fail-vin-uv psu-b-fail-vin-ov psu-b-fail-vout-uv psu-b-fail-vout-ov psu-b-fail-iout-oc psu-b-fail-overtemp synce-fail bits-fail bits-output-shutoff ieee1588-fail gnss-fail ieee1588-hybrid-fail signal-loss signal-efd esmc-loss bits-output-exceed ql-input-exceed holdover lti tod-reference-fail internal-clk-fail bgp-peer-down bgp-routes-mid-limit isis-adjacency-down isis-adjacency-reject isis-instance-down ospf-lsa-limit ospf-lsa-mid-limit ospf-neighbor-down ospf-instance-down ospf3-lsa-limit ospf3-lsa-mid-limit ospf3-neighbor-down ospf3-instance-down rip-instance-down lag-down lagsubgrp-thresh-reach lagsubgrp-switch-fail no-unpinned-free-ports general-arp-limit gen-switch-out-of-res ipv6-nc-limit dhcp-session-oor ihub-fdb-limit ihub-mac-limit l2fw-stp-exception l2fw-stp-root-guard	

3 Alarm Configuration Commands

Resource Identifier	Type	Description
	vprn-routes-limit vprn-ipv6-routes-limit dhcpv6-lease-limit dhcpv4-lease-limit vpls-mfib-limit ihub-ipv6-dad-own ihub-ipv6-dad ihub-ipv6-dup-pd-route vpls-duplicate-mac vpls-fdb-limit vpls-self-duplic-mac vpls-sdp-self-dup-mac link-down link-lagport-add-fail link-conf-mismatch ihub-peer-comm ihub-sw-fail ihub-hw-fail ihub-link-fail ihub-proc-overload ihub-out-of-mem ntp-comm-lost ldp-instance-down ldp-session-down mpls-instance-down mpls-lsp-down mpls-lsp-path-down sdp-instance-down sdp-binding-down epipe-instance-down lldpmed-portcfg-mis lldpmed-mediapl-mis vlanport-svc-mismatch mcsrc-stream-lost eqptsupl-syslog-upload eqptsupl-ontsw-dnload cf-75%used cf-90%used olt-gen-pon-com-fail olt-gen-tx-fail olt-gen-unprov-ont olt-gen-pon-eqpt-prov olt-gen-pon-loss-sig olt-gen-pon-diagnostic olt-gen-loid-conflict olt-gen-loid-pwderr olt-gen-pon-alien-test olt-gen-alien-detect olt-gen-rng-mism olt-gen-sfp-mism olt-gen-deact-hightca olt-gen-deact-lowtca olt-gen-dp-integ olt-gen-ddr-fault olt-pon-tc-err-frag-tc olt-ont-tc-err-frag-tc ont-ploam-loss-sig	

Resource Identifier	Type	Description
	ont-ploam-loss-ack	
	ont-ploam-loss-cd	
	ont-ploam-phy-eqpt-err	
	ont-ploam-startup-fail	
	ont-ploam-sig-degrade	
	ont-ploam-disabled	
	ont-ploam-err-msg	
	ont-ploam-inactive	
	ont-ploam-sig-fail	
	ont-ploam-dying-gasp	
	ont-ploam-deact-fail	
	ont-ploam-oam	
	ont-ploam-win-drift	
	ont-ploam-rdi	
	ont-ploam-loss-ks	
	ont-ploam-pwr-burst	
	ont-ploam-roq-disa	
	ont-ploam-diff-reach	
	ont-ploam-looc	
	sfu-ploam-loss-sig	
	sfu-ploam-loss-ack	
	sfu-ploam-loss-cd	
	sfu-ploam-phy-eqpt-err	
	sfu-ploam-startup-fail	
	sfu-ploam-sig-degrade	
	sfu-ploam-disabled	
	sfu-ploam-err-msg	
	sfu-ploam-inactive	
	sfu-ploam-sig-fail	
	sfu-ploam-dying-gasp	
	sfu-ploam-deact-fail	
	sfu-ploam-oam	
	sfu-ploam-win-drift	
	sfu-ploam-rdi	
	sfu-ploam-loss-ks	
	sfu-ploam-pwr-burst	
	sfu-ploam-roq-disa	
	sfu-ploam-diff-reach	
	sfu-ploam-looc	
	soho-ploam-loss-sig	
	soho-ploam-loss-ack	
	soho-ploam-loss-cd	
	soho-ploam-phy-eqpt-er	
	soho-ploam-startup-fai	
	soho-ploam-sig-degrade	
	soho-ploam-disabled	
	soho-ploam-err-msg	
	soho-ploam-inactive	
	soho-ploam-sig-fail	
	soho-ploam-dying-gasp	
	soho-ploam-deact-fail	
	soho-ploam-oam	
	soho-ploam-win-drift	
	soho-ploam-rdi	
	soho-ploam-loss-ks	
	soho-ploam-pwr-burst	
	soho-ploam-roq-disa	

3 Alarm Configuration Commands

Resource Identifier	Type	Description
	soho-ploam-diff-reach	
	soho-ploam-looc	
	mdu-ploam-loss-sig	
	mdu-ploam-loss-ack	
	mdu-ploam-loss-cd	
	mdu-ploam-phy-eqpt-err	
	mdu-ploam-startup-fail	
	mdu-ploam-sig-degrade	
	mdu-ploam-disabled	
	mdu-ploam-err-msg	
	mdu-ploam-inactive	
	mdu-ploam-sig-fail	
	mdu-ploam-dying-gasp	
	mdu-ploam-deact-fail	
	mdu-ploam-oam	
	mdu-ploam-win-drift	
	mdu-ploam-rdi	
	mdu-ploam-loss-ks	
	mdu-ploam-pwr-burst	
	mdu-ploam-roq-disa	
	mdu-ploam-diff-reach	
	mdu-ploam-looc	
	ont-hpna-ser-mis	
	ont-hpna-los-sig	
	ont-moca-svc-mis	
	ont-moca-link-los	
	ont-moca-min-bw	
	ont-moca-tca-rx-err-fr	
	ont-sipa-reg-nm-fail	
	ont-sipa-reg-rec-fail	
	ont-sipa-reg-con-fail	
	ont-sipa-reg-val-fail	
	ont-sipa-reg-mis	
	ont-vcd-cfg-nm-fail	
	ont-vcd-cfg-rech-fail	
	ont-vcd-cfg-conn-fail	
	ont-vcd-cfg-vali-fail	
	ont-vcd-cfg-auth-fail	
	ont-vcd-cfg-resp-tmout	
	ont-vcd-cfg-resp-err	
	ont-vcd-cfg-file-err	
	ont-vcd-sub-nm-fail	
	ont-vcd-sub-rech-fail	
	ont-vcd-sub-conn-fail	
	ont-vcd-sub-vali-fail	
	ont-vcd-sub-auth-fail	
	ont-vcd-sub-resp-tmout	
	ont-vcd-sub-resp-err	
	ont-vcd-reb-requ	
	ont-vcd-mis	
	ont-mgc-mis	
	ont-mgc-timeout	
	ont-sip-reg-dns	
	ont-sip-reg-fail	
	ont-sip-reg-timeout	
	ont-sip-reg-err-resps	
	ont-sip-inv-dns	

Resource Identifier	Type	Description
	ont-sip-inv-auth ont-sip-inv-timeout ont-sip-inv-err ont-svc-pots-subs-refr ont-svc-pots-not-refr ont-svc-pots-icfg-err ont-veip-mismatch ont-ip-host-mismatch ont-ip-host-file ont-ip-host-ip-alloc olt-pon-up-bw-tca olt-pon-down-bw-tca ont-gen-omci-fail ont-gen-eqpt-selftest ont-gen-ac-pwr-fail ont-gen-bat-missing ont-gen-bat-low ont-gen-bat-fail ont-gen-phys-intrusion ont-gen-sw-dnload-f ont-gen-sw-dnload-p ont-gen-sw-act-fail ont-gen-eqpt-vers-mis ont-gen-sw-vers-mis ont-gen-us-rate-mis ont-gen-mdu-env1 ont-gen-mdu-env2 ont-gen-mdu-env3 ont-gen-nw-time-err ont-gen-opt-sig-high ont-gen-opt-sig-low ont-gen-eqpt-prov-sa ont-gen-eqpt-prov-nsa pon-t-txmcutilhi pon-t-txmcutilmd pon-t-txmcutillo pon-t-txtotutilhi pon-t-txtotutilmd pon-t-txtotutillo pon-t-rxtotutilhi pon-t-rxtotutilmd pon-t-rxtotutillo pon-t-dbacongperiodhi pon-t-dbacongperiodmd pon-t-dbacongperiodlo pon-t-txucdropfrmhi pon-t-txucdropfrmmd pon-t-txucdropfrmlo pon-t-txmcdropfrmhi pon-t-txmcdropfrmmd pon-t-txmcdropfrmlo pon-t-txbcdropfrmhi pon-t-txbcdropfrmmd pon-t-txbcdropfrmlo pon-t-rxtotdropfrmhi pon-t-rxtotdropfrmmd pon-t-rxtotdropfrmlo	

3 Alarm Configuration Commands

Resource Identifier	Type	Description
	chpr-t-txmcutilhi chpr-t-txmcutilmd chpr-t-txmcutillo chpr-t-txtotutilhi chpr-t-txtotutilmd chpr-t-txtotutillo chpr-t-rxtotutilhi chpr-t-rxtotutilmd chpr-t-rxtotutillo chpr-t-dbacongperiodhi chpr-t-dbacongperiodmd chpr-t-dbacongperiodlo chpr-t-txucdropfrmhi chpr-t-txucdropfrmmd chpr-t-txucdropfrmlo chpr-t-txmcdropfrmhi chpr-t-txmcdropfrmmd chpr-t-txmcdropfrmlo chpr-t-txbcdropfrmhi chpr-t-txbcdropfrmmd chpr-t-txbcdropfrmlo chpr-t-rxtotdropfrmhi chpr-t-rxtotdropfrmmd chpr-t-rxtotdropfrmlo sfu-gen-omci-fail sfu-gen-eqpt-selftest sfu-gen-ac-pwr-fail sfu-gen-bat-missing sfu-gen-bat-low sfu-gen-bat-fail sfu-gen-sw-dnload-f sfu-gen-sw-dnload-p sfu-gen-sw-act-fail sfu-gen-eqpt-vers-mis sfu-gen-sw-vers-mis sfu-gen-us-rate-mis sfu-gen-tune-fail sfu-gen-nw-time-err sfu-gen-opt-sig-high sfu-gen-opt-sig-low sfu-gen-eqpt-prov-sa sfu-gen-eqpt-prov-nsa soho-gen-omci-fail soho-gen-eqpt-selftest soho-gen-ac-pwr-fail soho-gen-bat-missing soho-gen-bat-low soho-gen-bat-fail soho-gen-sw-dnload-f soho-gen-sw-dnload-p soho-gen-sw-act-fail soho-gen-eqpt-vers-mis soho-gen-sw-vers-mis soho-gen-us-rate-mis soho-gen-tune-fail soho-gen-nw-time-err soho-gen-opt-sig-high	

Resource Identifier	Type	Description
	soho-gen-opt-sig-low	
	soho-gen-eqpt-prov-sa	
	soho-gen-eqpt-prov-nsa	
	mdu-gen-omci-fail	
	mdu-gen-eqpt-selftest	
	mdu-gen-ac-pwr-fail	
	mdu-gen-bat-missing	
	mdu-gen-bat-low	
	mdu-gen-bat-fail	
	mdu-gen-phys-intrusion	
	mdu-gen-sw-dnload-f	
	mdu-gen-sw-dnload-p	
	mdu-gen-sw-act-fail	
	mdu-gen-eqpt-vers-mis	
	mdu-gen-sw-vers-mis	
	mdu-gen-us-rate-mis	
	mdu-gen-tune-fail	
	mdu-gen-mdm-env1	
	mdu-gen-mdm-env2	
	mdu-gen-mdm-env3	
	mdu-gen-nw-time-err	
	mdu-gen-opt-sig-high	
	mdu-gen-opt-sig-low	
	mdu-gen-eqpt-prov-sa	
	mdu-gen-eqpt-prov-nsa	
	ont-gen-sw-dnload-file	
	ont-gen-fan-fail	
	ont-gen-high-temp	
	ont-gen-high-temp-ex	
	ont-gen-emergency-call	
	ont-gen-sw-version	
	ont-poe-exceed-max	
	ont-poe-overload-yell	
	ont-opti-malfunc	
	ont-gen-cfgdld-fail	
	ont-gen-rssi-mis	
	ont-gen-tx-pwr-low	
	ont-gen-temp-high	
	ont-gen-volt-high	
	ont-gen-bias-high	
	ont-loopdetect-mis	
	ont-olt-rx-pw-lo	
	ont-olt-rx-pw-hig	
	ont-olt-rx-pw-warnlo	
	ont-olt-rx-pw-warnhig	
	ont-gen-tod-out-sync	
	ont-gen-tune-fail	
	hgu-tr069-param-fail	
	ont-gen-tod-mismatch	
	sfu-sup-sw-file-error	
	sfu-sup-fan-failure	
	sfu-sup-temp-high-warn	
	sfu-sup-temp-shutoff	
	sfu-sup-emergency-call	
	sfu-sup-swverctrl-err	
	sfu-sup-poe-exceed-max	
	sfu-sup-poe-over-yell	

3 Alarm Configuration Commands

Resource Identifier	Type	Description
	sfu-opti-malfunc	
	sfu-sup-cfg-dnld-fail	
	sfu-sup-rssi-cfg-mism	
	sfu-sup-sfp-tx-low	
	sfu-sup-sfp-temp-high	
	sfu-sup-sfp-volt-high	
	sfu-sup-sfp-bias-high	
	sfu-sup-ld-cfg-mism	
	sfu-sup-olt-rx-low	
	sfu-sup-olt-rx-high	
	sfu-sup-olt-rx-lo-warn	
	sfu-sup-olt-rx-hi-warn	
	sfu-sup-tod-out-sync	
	sfu-sup-ont-tune-fail	
	sfu-tr069-parm-fail	
	sfu-sup-tod-mismatch	
	soho-sup-sw-file-error	
	soho-sup-fan-failure	
	soho-sup-temp-high-war	
	soho-sup-temp-shutoff	
	soho-sup-emergency-cal	
	soho-sup-swverctrl-err	
	soho-sup-poe-exceed-ma	
	soho-sup-poe-over-yell	
	soho-opti-malfunc	
	soho-sup-cfg-dnld-fail	
	soho-sup-rssi-cfg-mism	
	soho-sup-sfp-tx-low	
	soho-sup-sfp-temp-high	
	soho-sup-sfp-volt-high	
	soho-sup-sfp-bias-high	
	soho-sup-ld-cfg-mism	
	soho-sup-olt-rx-low	
	soho-sup-olt-rx-high	
	soho-sup-olt-rx-lo-war	
	soho-sup-olt-rx-hi-war	
	soho-sup-tod-out-sync	
	soho-sup-ont-tune-fail	
	soho-tr069-parm-fail	
	soho-sup-tod-mismatch	
	mdu-sup-sw-file-error	
	mdu-sup-fan-failure	
	mdu-sup-temp-high-warn	
	mdu-sup-temp-shutoff	
	mdu-sup-emergency-call	
	mdu-sup-swverctrl-err	
	mdu-sup-poe-exceed-max	
	mdu-sup-poe-over-yell	
	mdu-opti-malfunc	
	mdu-sup-cfg-dnld-fail	
	mdu-sup-rssi-cfg-mism	
	mdu-sup-sfp-tx-low	
	mdu-sup-sfp-temp-high	
	mdu-sup-sfp-volt-high	
	mdu-sup-sfp-bias-high	
	mdu-sup-ld-cfg-mism	
	mdu-sup-olt-rx-low	

Resource Identifier	Type	Description
	mdu-sup-olt-rx-high mdu-sup-olt-rx-lo-warn mdu-sup-olt-rx-hi-warn mdu-sup-tod-out-sync mdu-sup-ont-tune-fail mdu-tr069-parm-fail mdu-sup-tod-mismatch ont-sbscr-lim-missing ont-sbscr-lim-type-mis ont-sbscr-lim-removal ont-sbscr-lim-fail ont-sbscr-lim-svc-mis ont-sbscr-lim-port-mis ont-svc-video-conf-mis ont-svc-video-pw-high ont-svc-video-pw-low ont-svc-pots-svc-mis ont-svc-pots-rtcp-lost ont-svc-pots-icnf-subs ont-svc-pots-icnf-ntfy ont-svc-pots-icnf-http ont-svc-pots-sip-reg ont-svc-pots-sip-inv ont-svc-pots-sip-subsc ont-svc-pots-sip-mt-tc ont-svc-pots-pk-los-tc ont-svc-pots-jitter-tc ont-svc-pots-subs-dns ont-svc-pots-subs-tcp ont-svc-pots-subs-tls ont-svc-pots-subs-auth ont-svc-pots-subs-to ont-svc-pots-subs-err ont-svc-pots-not-to ont-svc-pots-notref-to ont-svc-pots-not-mal ont-svc-pots-not-rej ont-svc-pots-http-dns ont-svc-pots-http-tcp ont-svc-pots-http-tls ont-svc-pots-http-auth ont-svc-pots-http-to ont-svc-pots-http-err ont-svc-pots-http-mal ont-svc-pots-insuff ont-svc-pots-poos ont-svc-lan-mismatch ont-svc-lan-loss-sig ont-svc-enet-poos ont-svc-ces-ds1-mis ont-svc-ces-ds1-los ont-svc-ces-ds1-lof ont-svc-ces-ds1-rair ont-svc-ces-ds1-ais ont-svc-ces-ds1-lnlpbk ont-svc-ces-ds1-tmlpbk ont-svc-ces-e1-mis	

3 Alarm Configuration Commands

Resource Identifier	Type	Description
	ont-svc-ces-e1-los	
	ont-svc-ces-e1-lof	
	ont-svc-ces-e1-rair	
	ont-svc-ces-e1-ais	
	ont-svc-voip-cnf-file	
	ont-svc-voip-svc-mis	
	ont-svc-voip-gw-comm	
	ont-svc-voip-dhcp-fail	
	ont-svc-voip-icnf-subs	
	ont-svc-voip-icnf-ntfy	
	ont-svc-voip-icnf-http	
	ont-svc-voip-dhcp-to	
	ont-svc-voip-dhcp-mal	
	ont-svc-voip-dhcp-noad	
	ont-svc-voip-dhcp-leas	
	ont-svc-voip-subs-dns	
	ont-svc-voip-subs-tcp	
	ont-svc-voip-subs-tls	
	ont-svc-voip-subs-auth	
	ont-svc-voip-subs-to	
	ont-svc-voip-subs-err	
	ont-svc-voip-not-to	
	ont-svc-voip-notref-to	
	ont-svc-voip-not-mal	
	ont-svc-voip-not-rej	
	ont-svc-voip-http-dns	
	ont-svc-voip-http-tcp	
	ont-svc-voip-http-tls	
	ont-svc-voip-http-auth	
	ont-svc-voip-http-to	
	ont-svc-voip-http-err	
	ont-svc-voip-http-mal	
	ont-svc-voip-subs-refr	
	ont-svc-voip-not-refr	
	ont-svc-voip-icfg-err	
	ont-svc-v-ani-conf-mis	
	ont-svc-v-ani-loss-sig	
	ont-svc-v-ani-lv-high	
	ont-svc-v-ani-lv-low	
	ont-svc-pwe-mismatch	
	ont-svc-pwe-reordr-lof	
	ont-svc-pwe-jitt-buf-o	
	ont-svc-pwe-jitt-buf-u	
	ont-svc-pwe-malf-frms	
	ont-svc-pwe-late-frms	
	ont-svc-pwe-link-loss	
	ont-svc-pwe-arp-fail	
	ont-svc-xdsl-mismatch	
	ont-svc-xdsl-ne-lof	
	ont-svc-xdsl-ne-los	
	ont-svc-xdsl-ne-line	
	ont-svc-xdsl-ne-lol	
	ont-svc-xdsl-fe-lof	
	ont-svc-xdsl-fe-los	
	ont-svc-xdsl-fe-lop	
	ont-svc-xdsl-cnf-err	
	ont-svc-xdsl-ne-es-tc	

Resource Identifier	Type	Description
	ont-svc-xdsl-ne-ses-tc ont-svc-xdsl-ne-uas-tc ont-svc-xdsl-fe-es-tc ont-svc-xdsl-fe-ses-tc ont-svc-xdsl-fe-uas-tc ont-tc-rx-los-frag-tc ont-tc-tx-los-frag-tc ont-tc-bad-gem-hd-tc ont-uni-ds-drp-d-fr-tc ont-uni-up-drp-d-fr-tc ont-uni-ds-crc-fr-tc ont-uni-up-crc-fr-tc ont-cpu-util-tca ont-mem-util-tca pim-neighbor-down pim-max-mcroutes li-traffic-disabled li-bandwidth-limit li-out-of-res otdr-cap-mismatch login-successful login-failure cfm-defrdiccm cfm-defmacstatus cfm-defremoteccm cfm-deferrorccm cfm-defxconccm cfm-defais bfd-session-down bfd-max-resource bfd-stale-entry tca-outputbw tca-inputbw tca-rxcrcalign tca-txcrcalign tca-txcollisions tca-outputhighbw tca-outputmedbw tca-outputlowbw tca-inputhighbw tca-inputmediumbw tca-inputlowbw eth-cfm-defrdiccm eth-cfm-defmacstatus eth-cfm-defremoteccm eth-cfm-deferrorccm eth-cfm-defxconccm rsvp-neighbor-down rsvp-instance-down eth-ring-path-block ai-platform-down ai-appl-install-fail ip-assign-fail ont-tr069-serv-mis ont-snmp-mis bsf-dhcpv4 bsf-dhcpv6	

3 Alarm Configuration Commands

Resource Identifier	Type	Description
	bsf-pon	
	bsf-vbridge	
	bsf-qos	
	bsf-igmp	
	bsf-lxfwd	
	prot-not-available	
	prot-switchover-fail	
	efm-oam-cpelinkfault	
	efm-oam-cpedyinggasp	
	efm-oam-cpecrevt	
	ont-loopdetect	
	almr-tbl-overflow	
	auto-switch-status	
	auswqueuefullatm	
	auswbkpfailatm	
	auswrecfgfailatm	
	auswdataunatm	
	auswqueuefulptm	
	auswbkpfailptm	
	auswrecfgfailptm	
	auswdataunptm	
	auswbakpfailatm	
	chpr-com-fail	
	chpr-tx-fail	
	chpr-unprov-ont	
	chpr-prov-mismatch	
	chpr-loss-sig	
	chpr-diagnostic	
	chpr-loid-conflict	
	chpr-loid-pwd-err	
	chpr-stk-laser-dis	
	chpr-sfp-mismatch	
	chpr-rng-mismatch	
	chpr-alien-test	
	chpr-alien-detect	
	chpr-deact-hightca	
	chpr-deact-lowtca	
	chpr-dp-integ	
	olt-chpr-tc-err-frag	
	olt-chpr-up-bw-tca	
	olt-chpr-down-bw-tca	
	cfg-dld-fail	
	cfg-act-fail	
	cfg-dld-ip	
	cfg-ver-mismatch	
	cfg-file-missing	
	cfg-verctrl-err	
	cfg-not-supported	
	ont-prot-not-available	
	ont-gen-temp-low	
	ont-gen-volt-low	
	ont-gen-tx-pwr-high	
	ont-gen-bias-low	
	ont-gen-rx-hwarn	
	ont-gen-rx-lwarn	
	ont-gen-tx-hwarn	
	ont-gen-tx-lwarn	

Resource Identifier	Type	Description
	ont-gen-temp-hwarn	
	ont-gen-temp-lwarn	
	ont-gen-volt-hwarn	
	ont-gen-volt-lwarn	
	ont-gen-bias-hwarn	
	ont-gen-bias-lwarn	
	sfu-sup2-temp-low	
	sfu-sup2-volt-low	
	sfu-sup2-tx-high	
	sfu-sup2-bias-low	
	sfu-sup2-rx-hwarn	
	sfu-sup2-rx-lwarn	
	sfu-sup2-tx-hwarn	
	sfu-sup2-tx-lwarn	
	sfu-sup2-temp-hwarn	
	sfu-sup2-temp-lwarn	
	sfu-sup2-volt-hwarn	
	sfu-sup2-volt-lwarn	
	sfu-sup2-bias-hwarn	
	sfu-sup2-bias-lwarn	
	soho-sup2-temp-low	
	soho-sup2-volt-low	
	soho-sup2-tx-high	
	soho-sup2-bias-low	
	soho-sup2-rx-hwarn	
	soho-sup2-rx-lwarn	
	soho-sup2-tx-hwarn	
	soho-sup2-tx-lwarn	
	soho-sup2-temp-hwarn	
	soho-sup2-temp-lwarn	
	soho-sup2-volt-hwarn	
	soho-sup2-volt-lwarn	
	soho-sup2-bias-hwarn	
	soho-sup2-bias-lwarn	
	mdu-sup2-temp-low	
	mdu-sup2-volt-low	
	mdu-sup2-tx-high	
	mdu-sup2-bias-low	
	mdu-sup2-rx-hwarn	
	mdu-sup2-rx-lwarn	
	mdu-sup2-tx-hwarn	
	mdu-sup2-tx-lwarn	
	mdu-sup2-temp-hwarn	
	mdu-sup2-temp-lwarn	
	mdu-sup2-volt-hwarn	
	mdu-sup2-volt-lwarn	
	mdu-sup2-bias-hwarn	
	mdu-sup2-bias-lwarn	
	cust-alm1	
	cust-alm2	
	cust-alm3	
	cust-alm4	
	cust-alm5	
	cust-alm6	
	cust-alm7	
	cust-alm8	
	cust-alm9	

3 Alarm Configuration Commands

Resource Identifier	Type	Description
	cust-alm10 cust-alm11 cust-alm12 cust-alm13 cust-alm14 cust-alm15 cust-alm16 cust-alm17 cust-alm18 cust-alm19 cust-alm20 cust-alm21 cust-alm22 cust-alm23 cust-alm24 cust-alm25 cust-alm26 cust-alm27 cust-alm28 cust-alm29 cust-alm30 cust-alm31 ethernet-ring-pthfwst ethernet-ring-fop-to ethernet-ring-fop-pm fpm-depletion exp-seizureack exp-disconack exp-forcerelack packet-loss remote-packet-loss no-dsp-resource la-down la-standby-na la-switch-fail la-degrade melt-board-reset board-shelf-mismatch fcs-thresh-exceed) Possible values: - all : all alarms for query - xtca-ne-es : errored seconds in 15 min - xtca-ne-ses : severely errored seconds in 15 min - xtca-ne-uas : unavailable seconds in 15 min - xtca-ne-day-es : errored seconds in 1 day - xtca-ne-day-ses : severely errored seconds in 1 day - xtca-ne-day-uas : unavailable seconds in 1 day - xtca-fe-es : errored seconds in 15 min - xtca-fe-ses : severely errored secs in 15 min - xtca-fe-uas : unavailable seconds in 15 min - xtca-fe-day-es : errored seconds in 1 day - xtca-fe-day-ses : severely errored secs in 1 day - xtca-fe-day-uas : unavailable seconds in 1 day - xtca-leftrs : low error free throughput seconds in 15 min - xtca-day-leftrs : low error free throughput seconds in 1 day - xtca-fe-leftrs : far end low error free throughput seconds in 15 min	

Resource Identifier	Type	Description
	- xtca-fe-day-leftrs : far end low error free throughput seconds in 1 day - xtca-auto-port-reset : auto-port-resets in 1 week - xtca-reinit : Reinitialization seconds in 15 min - xtca-day-reinit : Reinitialization seconds in 1 day - xdsl-ne-los : loss of signal - xdsl-ne-lof : loss of frame - xdsl-ne-lom : loss of margin - xdsl-ne-ese : excessive severe errors - xdsl-act-cfg-error : line configuration data cannot be used - xdsl-act-not-feas : line capacity not enough to setup requested profile - xdsl-up-br-reach : planned bitrate not reached after initialization - xdsl-ne-ncd : no cell delineation - xdsl-ne-lcd : loss of cell delineation - xdsl-fe-los : loss of signal - xdsl-fe-lof : loss of frame - xdsl-fe-lpr : loss of power - xdsl-fe-lol : loss of link - xdsl-fe-lom : loss of margin - xdsl-fe-ese : excessive severe errors - xdsl-fe-upbo-vio : upbo violation - xdsl-fe-cpe-pol : activation failure cpe policing - xdsl-tpstc-mis : mismatch between the configured tps-tc mode and the mode supported by the connected cpe - xdsl-act-comm : init not successful due to communications problem - xdsl-act-modem : no peer modem detected - xdsl-do-br-reach : planned bitrate not reached after init - xdsl-fe-ncd : no cell delineation - xdsl-fe-lcd : loss of cell delineation - xdsl-frtx-init-fail : init not successful due to forced rtx - xdsl-vect-dle : vectoring disorderly leaving event - xdsl-fe-mis-peer-35b : VDSL2 35b opmode mismatch between XTU-C and XTU-R - vectline-xtc-var-vict : excessive victim crosstalk coefficients variation - vectline-xtc-var-dist : excessive disturber crosstalk coefficients variation - vectline-corp-errf : corrupted or missing errorf-samples - vect-cpe-cap-mismatch : not allowed Vectoring CPE connected - vectline-conf_notfeas : vect line configuration not feasible - vect-vp-lt-mismatch : actual vp-lt connection(s) do not match expected vp-lt connection(s) or vp-lt connection lost - vect-inv-qsf : qsf has no valid Nokia ID - vect-vp-lt-fail : vp-lt connection not operational - vect-no-gain-at-init : Lines cannot train in gain-at-init mode - sw-rollback : non active oswp,db cannot be operational - will rollback - db-rollback : selected oswp,db cannot be operational - will rollback - xvps-inv-dbase : invalid xvps dbase - inv-cde-file : invalid xvps cde file - miss-cde-file : missing cde profile	

3 Alarm Configuration Commands

Resource Identifier	Type	Description
	- cde-hash-error : cde profile hash error - low-disk-space : insufficient space for Sw storage - cell-discard-up : cell discarded in the upstream direction - cell-discard-down : cell discarded in the downstream direction - persist-data-loss : all data lost after restart - system not configured - mac-conflict : duplicate mac address on the bridge port - vmac-full : virtual mac address is full on the bridge port - sntp-comm-lost : sntp server not responding - preferred-mode : preferred mode not available - timing-reference : timing reference failure - nt-disk-95%full : nt disk 95% full - shub-loc : communication lost with shub - cf-error : compact flash access error - back-pnl-inv : BackPanel-type Invalid - ihub-conf-loss : iHub configuration loss - recent changes lost - rack-power : power fuse broken - rack-fan-unit1 : fan unit rack 1 failing - rack-fan-unit2 : fan unit rack 2 failing - shelf-mismatch : shelf type different from planned type - shelf-missing : detected shelf no longer detected - shelf-install-missing : shelf planned but not installed - door : open cabinet door - ac-power-fail : external power failure - shelf shutdown in 15 minutes - board-mismatch : board inserted different from planned - waiting-for-sw : not able to download all the applicable sw files - temp-exceeded : temperature threshold exceeded on the board - backplane-data-failure: lt port on backplane data failure - temp-shutdown : board powered down itself - too high temperature - board-missing : board detected after planning - now missing - board-instl-missing : board never detected after planning - board-init : board initialisation failure - board-reset-prot : number of resets exceeded - sem-power-fail : SEM external power failure - sem-ups-fail : SEM external power supply failure - board-reset-cf : board reset and/or communication failure - vlan-assign-fail : failure to assign VLAN for a user session - vsa-info-invalid : radius fail to assign a valid vsa to a user session - auth-mac-conflict : failure to check mac conflict for a user session - user-pwd-fault : failure to check user or password of a user session - up-plan-bitrate : upstream bitrate is above min and below planned - up-min-bitrate : upstream bitrate is below min bitrate - up-config-not-feas : upstream bitrate is not enough to set up config group - down-plan-bitrate : downstream bitrate is above min and below planned	

Resource Identifier	Type	Description
	- down-min-bitrate : downstream bitrate is below min bitrate - down-config-not-feas : downstream bitrate is not enough to set up config group - non-bonding-cpe : no bonding cpe modem is connected - multiple-cpes : bonding group has multiple cpe modems connected - register : bonding group discovery or aggregation register failure - group-incomplete : bonding group is incomplete - host-sfp-los : loss of signal - host-sfp-tx-fail : Tx failure - host-sfp-not-prst : not present - host-sfp-inv-id : no valid Nokia ID - host-sfp-ctrl-fail : control failure - host-sfp-rmtlt : unexpected remote plug-in - host-sfp-mismatch : assignment does not match reported rack/shelf/slot - host-sfp-incompt : incompatible shelf type detected - exp-sfp-los : expansion side loss of signal - exp-sfp-tx-fail : Tx failure - exp-sfp-not-prst : not present - exp-sfp-inv-id : no valid Nokia ID - exp-sfp-ctrl-fail : control failure - exp-sfp-1-los : expansion side sfp1 loss of signal - exp-sfp-2-los : expansion side sfp2 loss of signal - ext-qsfps-invld : Invalid Nokia ID - tx-power-high-alarm : tx power more than alarm range - tx-power-low-alarm : tx power less than alarm range - rx-power-high-alarm : rx power more than alarm range - rx-power-low-alarm : rx power less than alarm range - tx-biascur-high-alarm : tx bias current high alarm - tx-biascur-low-alarm : tx bias current low alarm - volt-high-alarm : voltage high alarm - volt-low-alarm : voltage low alarm - temp-high-alarm : temperature high alarm - temp-low-alarm : temperature low alarm - tx-power-high-warn : tx power more than warn range - tx-power-low-warn : tx power less than warn range - rx-power-high-warn : rx power more than warn range - rx-power-low-warn : rx power less than warn range - tx-biascur-high-warn : tx bias current high warn - tx-biascur-low-warn : tx bias current low warn - volt-high-warn : voltage high warn - volt-low-warn : voltage low warn - temp-high-warn : temperature high warn - temp-low-warn : temperature low warn - onu-unprovisioned : unprovisioned ont - signal-loss : pon loss of signal - bitrate-high : the error bit rate high at pon interface - opmodule-mismatch : the optical module mismatched at pon interface - key-fail-one-churn : key exchange failure during one churning time - key-fail-three-churn : key exchange failure during three churning time - oam-discov-fail : extend oam discovery failure - report-timeout : report timeout detecting	

3 Alarm Configuration Commands

Resource Identifier	Type	Description
	- total-packets-exceed : total amount of protocol packets exceed threshold - arp-packets-exceed : protocol arp packets exceed threshold - dhcp-packets-exceed : protocol dhcp packets exceed threshold - igmp-packets-exceed : protocol igmp packets exceed threshold - pppoe-packets-exceed : protocol pppoe packets exceed threshold - nd-packets-exceed : protocol nd packets exceed threshold - icmpv6-packets-exceed : protocol icmpv6 packets exceed threshold - mld-packets-exceed : protocol mld packets exceed threshold - dhcpv6-packets-exceed : protocol dhcpv6 packets exceed threshold - cfm-packets-exceed : protocol cfm packets exceed threshold - dsx1-serdes-fail : SERDES clock alarm failure - dsx1-tributary1-fail : The tributary 1 clock is not present - dsx1-tributary2-fail : The tributary 2 clock is not present - dsx1-los-fail : All the selected tribs in Loss of Signal - dsx1-ais-sync : Alarm Indication signal on the tributary selected as sync source - dsx1-lof-sync : Loss of Framing on the tributary selected as sync source - dsx1-los-sync : Loss of signal on the tributary selected as sync source - dsx1-deg-fail : Signal degrade Alarm - dsx1-rei-from-liu : Remote Error Indication alarm from LIU - dsx1-rdi-from-liu : Remote Defect Alarm from LIU - dsx1-crc6-from-liu : Cyclic Redundancy check-6 alarm from LIU - dsx1-crc4-from-liu : Cyclic Redundancy check-4 alarm from LIU - dsx1-crc4-th-from-liu : Cyclic Redundancy check-4 threshold alarm from LIU - dsx1-ais-from-liu : Alarm Indication Signal alarm from LIU - dsx1-los-from-liu : Loss of signal alarm from LIU - dsx1-lof-from-liu : Loss of framing alarm from LIU - dsx1-lomf-from-liu : Loss of Multi-frame alarm from LIU - dsx1-rei-from-iwf : Remote Error Indication alarm from IWF - dsx1-rdi-from-iwf : Remote Defect Alarm from IWF - dsx1-crc6-from-iwf : Cyclic Redundancy check-6 alarm from IWF - dsx1-crc4-from-iwf : Cyclic Redundancy check-4 alarm from IWF - dsx1-crc4-th-from-iwf : Cyclic Redundancy check-4 threshold alarm from IWF - dsx1-ais-from-iwf : Alarm Indication Signal alarm from IWF - dsx1-los-from-iwf : Loss of signal alarm from IWF - dsx1-lof-from-iwf : Loss of framing alarm from IWF - dsx1-lomf-from-iwf : Loss of Multi-frame alarm from IWF	

Resource Identifier	Type	Description
	- pppce-trans-15min-tca : 15 minutes transaction timeout count exceeds configured TCA - pppce-sess-15min-tca : 15 minutes session timeout count exceeds configured TCA - pppce-trans-1day-tca : 1day transaction timeout count exceeds configured TCA - pppce-sess-1day-tca : 1day session timeout count exceeds configured TCA - custom1 : customizable alarm 1 - custom2 : customizable alarm 2 - custom3 : customizable alarm 3 - custom4 : customizable alarm 4 - custom5 : customizable alarm 5 - he-custom1 : host expansion customizable alarm 1 - he-custom2 : host expansion customizable alarm 2 - he-custom3 : host expansion customizable alarm 3 - he-custom4 : host expansion customizable alarm 4 - he-custom5 : host expansion customizable alarm 5 - he-custom6 : host expansion customizable alarm 6 - custom6 : customizable alarm 6 - custom7 : customizable alarm 7 - custom8 : customizable alarm 8 - custom9 : customizable alarm 9 - custom10 : customizable alarm 10 - custom11 : customizable alarm 11 - custom12 : customizable alarm 12 - custom13 : customizable alarm 13 - custom14 : customizable alarm 14 - custom15 : customizable alarm 15 - custom16 : customizable alarm 16 - custom17 : customizable alarm 17 - loss-swo-cap : switch over capability in a redundant system - ping-check-fail : ping check in a redundant system - der-temp1 : Derived Alarm for Temporal Filter 1 - der-temp2 : Derived Alarm for Temporal Filter 2 - der-temp3 : Derived Alarm for Temporal Filter 3 - der-temp4 : Derived Alarm for Temporal Filter 4 - der-temp5 : Derived Alarm for Temporal Filter 5 - der-temp6 : Derived Alarm for Temporal Filter 6 - der-temp7 : Derived Alarm for Temporal Filter 7 - der-temp8 : Derived Alarm for Temporal Filter 8 - der-temp9 : Derived Alarm for Temporal Filter 9 - der-temp10 : Derived Alarm for Temporal Filter 10 - der-temp11 : Derived Alarm for Temporal Filter 11 - der-temp12 : Derived Alarm for Temporal Filter 12 - der-temp13 : Derived Alarm for Temporal Filter 13 - der-temp14 : Derived Alarm for Temporal Filter 14 - der-temp15 : Derived Alarm for Temporal Filter 15 - der-temp16 : Derived Alarm for Temporal Filter 16 - der-temp17 : Derived Alarm for Temporal Filter 17 - der-temp18 : Derived Alarm for Temporal Filter 18 - der-temp19 : Derived Alarm for Temporal Filter 19 - der-temp20 : Derived Alarm for Temporal Filter 20 - der-temp21 : Derived Alarm for Temporal Filter 21 - der-temp22 : Derived Alarm for Temporal Filter 22 - der-temp23 : Derived Alarm for Temporal Filter 23 - der-temp24 : Derived Alarm for Temporal Filter 24	

3 Alarm Configuration Commands

Resource Identifier	Type	Description
	- der-temp25 : Derived Alarm for Temporal Filter 25 - der-temp26 : Derived Alarm for Temporal Filter 26 - der-temp27 : Derived Alarm for Temporal Filter 27 - der-temp28 : Derived Alarm for Temporal Filter 28 - der-temp29 : Derived Alarm for Temporal Filter 29 - der-temp30 : Derived Alarm for Temporal Filter 30 - der-temp31 : Derived Alarm for Temporal Filter 31 - der-spa1 : Derived Alarm for Spatial Filter 1 - der-spa2 : Derived Alarm for Spatial Filter 2 - der-spa3 : Derived Alarm for Spatial Filter 3 - der-spa4 : Derived Alarm for Spatial Filter 4 - der-spa5 : Derived Alarm for Spatial Filter 5 - der-spa6 : Derived Alarm for Spatial Filter 6 - der-spa7 : Derived Alarm for Spatial Filter 7 - der-spa8 : Derived Alarm for Spatial Filter 8 - der-spa9 : Derived Alarm for Spatial Filter 9 - der-spa10 : Derived Alarm for Spatial Filter 10 - der-spa11 : Derived Alarm for Spatial Filter 11 - der-spa12 : Derived Alarm for Spatial Filter 12 - der-spa13 : Derived Alarm for Spatial Filter 13 - der-spa14 : Derived Alarm for Spatial Filter 14 - der-spa15 : Derived Alarm for Spatial Filter 15 - der-spa16 : Derived Alarm for Spatial Filter 16 - der-spa17 : Derived Alarm for Spatial Filter 17 - der-spa18 : Derived Alarm for Spatial Filter 18 - der-spa19 : Derived Alarm for Spatial Filter 19 - der-spa20 : Derived Alarm for Spatial Filter 20 - der-spa21 : Derived Alarm for Spatial Filter 21 - der-spa22 : Derived Alarm for Spatial Filter 22 - der-spa23 : Derived Alarm for Spatial Filter 23 - der-spa24 : Derived Alarm for Spatial Filter 24 - der-spa25 : Derived Alarm for Spatial Filter 25 - der-spa26 : Derived Alarm for Spatial Filter 26 - der-spa27 : Derived Alarm for Spatial Filter 27 - der-spa28 : Derived Alarm for Spatial Filter 28 - der-spa29 : Derived Alarm for Spatial Filter 29 - der-spa30 : Derived Alarm for Spatial Filter 30 - der-spa31 : Derived Alarm for Spatial Filter 31 - apsf-alarm : Applique Power Supply Failure - custextalarm1 : Customizable External Alarm Number 1 - custextalarm2 : Customizable External Alarm Number 2 - custextalarm3 : Customizable External Alarm Number 3 - custextalarm4 : Customizable External Alarm Number 4 - custextalarm5 : Customizable External Alarm Number 5 - pluginfan : REM Fan Alarm - plugin-dc-a : REM DC A Alarm - plugin-dc-b : REM DC B Alarm - plugin-dg : Dying Gasp Alarm - ntr-a-loss : NTR-A signal is not available - ntr-b-loss : NTR-B signal is not available - xvps-conf-loss : xvps configuration loss - mac-entry-nofree : no free mac entry in the mac table on It board - fibre-conn-mismatch : REM Fibre Connection Mismatch Alarm - link-cap-mismatch : Link speed capability mismatch - eqpt-cap-mismatch : Link equipment capability mismatch	

Resource Identifier	Type	Description
	- ctrl-dnld-failure : Controller card download failure - melt-hw-issue : MELT hardware issue - melt-board-reset : MELT board reset - board-shelf-mismatch : board type and shelf type mismatch - mgnt-type-mismatch : Board management type mismatch - fileserv-unavail : file transfer Server unavailable or file transfer failed - shdsl-n-loopback : loopback active at the network side - shdsl-c-loopback : loopback active at the customer side - shdsl-conferr : configuration error - shdsl-atm-lcd : loss of atm cell delineation - shdsl-lpr : loss of power at stu-r - shdsl-secu-err : unable to disable stu-r access - shdsl-dev-fault : device fault - shdsl-atm-ncd : no atm cell delineation - shdsl-n-losw : loss of sync word at the network side on each pair - shdsl-c-losw : loss of sync word at the customer side on each pair - shdsl-n-aten : loop attenuation alarm at the network side on each pair - shdsl-c-aten : loop attenuation alarm at the customer side on each pair - shdsl-n-snr : snr margin alarm at the network side each pair - shdsl-c-snr : snr margin alarm at the customer side on each pair - shdsl-n-dccont : dc continuity fault at the network side on each pair - shdsl-c-dccont : dc continuity fault at the customer side on each pair - shdsl-c-actfail : activation failure at the customer side on each pair - e1-fe-rai : Receiving Remote Alarm Indication - e1-ne-rai : Transmitting Remote Alarm Indication - e1-fe-ais : Receiving Alarm Indication Signal - e1-ne-ais : Transmitting Alarm Indication Signal - e1-lof : E1 Loss of frame - e1-los : E1 Loss of Signal - e1-loopback : E1 facility in loopback - ima-grp-fe-su : far-end starting up - ima-grp-fe-cfg : far-end failed configuration - ima-grp-ne-cfg : near-end failed configuration - ima-grp-fe-nl : insufficient number of links at far-end - ima-grp-ne-nl : insufficient number of links at near-end - ima-grp-fe-blk : far-end is blocked - ima-lnk-lif : loss of ima frame - ima-lnk-lods : link out of delay synchronization - ima-lnk-misc : link misconnect - ima-lnk-rfi : link remote failure indication - ima-lnk-fault : fault in link facility - ima-lnk-txblk : transmit blocked due to far-end - ima-lnk-rxblk : receive blocked due to far-end - bad-digitmap : Configured digitmap is unusable - dhcp-unreach : The DHCP server is unreachable - dhcp-no-srv : The address in DHCP reply is NULL - dhcp-inv-srv : The address in DHCP reply is invalid - norpniewithsoftdsp : do not plan / plug-in RPNI-E board	

3 Alarm Configuration Commands

Resource Identifier	Type	Description
	with SoftDsp SW image - unknown-sub : subscriber exist in the POLT, but not in the appl server - ground-key : Return current to the ground - port-hightemp : Temperature threshold on user port exceeded. - port-jbfltca : JB fill level threshold on user port exceeded. - reg-domainname : Registration failure (resolving domain name). - reg-auth : Registration failure (authentication). - reg-timeout : Registration failure (message timeout). - reg-srvfailresp : Registration failure (failure response from server). - inv-domainname : Invitation failure (resolving domain name). - inv-auth : Invitation failure (authentication). - inv-timeout : Invitation failure (message timeout). - inv-srvfailresp : Invitation failure (failure response from server). - subs-srvfailresp : Subscribe failure (failure response from server). - subs-domainname : Subscribe failure (resolving domain name). - subs-auth : Subscribe failure (authentication). - subs-refreshfail : Subscribe failure (refresh failure). - subs-inittimeout : Subscribe failure (initial REQ timeout). - emergency-call : Emergency call for SIP POTS is ongoing. - e1sip-reg-domainname : E1 sip termination registration failure (resolving domain name). - e1sip-reg-auth : E1 sip termination registration failure (authentication). - e1sip-reg-timeout : E1 sip termination registration failure (message timeout). - e1sip-reg-srvfailresp : E1 sip termination registration failure (failure response from server). - e1sip-inv-domainname : E1 sip termination invitation failure (resolving domain name). - e1sip-inv-auth : E1 sip termination invitation failure (authentication). - e1sip-inv-timeout : E1 sip termination invitation failure (message timeout). - e1sip-inv-srvfailresp : E1 sip invitation failure (failure response from server). - e1sip-emergency-call : Emergency call for ISDN PRA/CAS R2 is ongoing. - e1itf-ais-signal : Alarm Indication Signal detected at E1 interface. - e1itf-los-signal : Loss Of Signal detected at E1 interface. - e1itf-rai-signal : Remote Alarm Indication detected at E1 interface. - e1sip-misconfig-mgc10 : Configuration not conform with the core network entity. - e1sip-nsmprf-missed : The SIP termination requires a NSM profile. - e1t1itf-recv-ais : Alarm Indication Signal received at interface. - e1t1itf-recv-los : Loss Of Signal received at interface.	

Resource Identifier	Type	Description
	- e1t1itf-recv-rai : Remote Alarm Indication received at interface. - transport-mismatch : Transport protocol mismatch - dns-lookup-failure : Dns look up failure - none-dns-srv : No reply for all DNS serverd - no-dns-srv : No DNS servers configured - none-srv : No reply for all SIP First Hops - no-srv : No SIP First Hop configured - reg-srv-unreach : All SIP register servers are unreachable - proxy-srv-unreach : All SIP proxy servers are unreachable - dhcp-srv-unreach : The DHCP server is unreachable on this board - fo-trigger : Fail Over Triggered - fb-trigger : Fail Back Triggered - du-trigger : Deliberate Update Triggered - ssp-missing : SSP Missing in CDE - dns-pool-exceed : Number of different SG associated DNS pools exceed - lsa-fo-trigger : SIP voice service degraded - fail-over to LSA server - reg-domainname-sec : Registration failure (resolving domain name). - reg-auth-sec : Registration failure (authentication). - reg-timeout-sec : Registration failure (message timeout). - reg-srvfailresp-sec : Registration failure (failure response from server). - inv-domainname-sec : Invitation failure (resolving domain name). - inv-auth-sec : Invitation failure (authentication). - inv-timeout-sec : Invitation failure (message timeout). - inv-srvfailresp-sec : Invitation failure (failure response from server). - subs-srvfailresp-sec : Subscribe failure (failure response from server). - subs-domainname-sec : Subscribe failure (resolving domain name). - subs-auth-sec : Subscribe failure (authentication). - subs-refreshfail-sec : Subscribe failure (refresh failure). - subs-inittimeout-sec : Subscribe failure (initial REQ timeout). - emergency-call-sec : Emergency call for Secondary Termination is ongoing. - fanout : Lt load overflow - up-overflow : Upstream load overflow - upobc-overflow : Upstream load to OBC overflow - dwobc-overflow : Downstream load to OBC overflow - dw-overflow : Downstream load overflow - lwpri-overflow : The number of BE and CL pkts dropped exceed threshold - queue-drop : The number of pkts dropped by queue exceeds threshold - queue-load : The queue load exceeds threshold - queue-peak-usage : The queue peak usage exceeds threshold - mgc-unreachable : loss of contact with the media gateway controller - failover-to-esamgc : failover to esa mgc	

3 Alarm Configuration Commands

Resource Identifier	Type	Description
	- sgc-unreachable : loss of contac with signaling gateway controller - lcard-unreach-srvcard : line card unreachable with server card - lcard-type-mismatch : associate board of wrong type - meg-unknown-sub : the megaco subscriber is unknown - meg-ground-key : voice port ground key - meg-high-temp : voice port high temperature - meg-act-fail : the first link layer for isdn subscriber activation failure - meg-over-current : voice port over current - line-showering : line showering - low-qos-packetloss : the total packet loss has exceeded the configured threshold - low-qos-jitter : the rtp jitter has exceeded the configured threshold - low-qos-delay : the rtp delay has exceeded the configured threshold - sig-brd-persist-loss : voice signaling board persistent data loss - sig-brd-disk-full : voice signaling board disk 90% full - sig-brd-db-rollback : voice signaling board db rollback - mg-overload : mg overload - meg-unknown-sub-sec : The Megaco subscriber exists in voice signaling board but not in media gateway controller. - line-showering-sec : A subscriber line exceeds 20 off-hook / on-hook events / minute. - loss-env-mon : env-monitor box lost or not alive - etca-los : loss of signal errors in 15 min - etca-fcs : frame check sequence errors in 15 min - etca-day-los : loss of signal errors in 1 day - etca-day-fcs : frame check sequence errors in 1 day - etca-rx-octets : received octets in 15 min - etca-tx-octets : transmitted octets in 15 min - etca-day-rx-octets : received octets in 1 day - etca-day-tx-octets : transmitted octets in 1 day - user-sfp-los : user sfp loss of signal - user-sfp-tx-fail : user sfp tx failure - user-sfp-not-prst : user sfp not detected - user-sfp-inv-id : user sfp invalid id - user-sfp-t-exceed : user sfp temperature exceed - user-sfp-mismatch : user sfp mismatch the configured type - uplink-sfp-los : uplink sfp loss of signal - uplink-sfp-tx-fail : uplink sfp tx failure - uplink-sfp-not-prst : uplink sfp not detected - uplink-sfp-inv-id : uplink sfp invalid id - uplink-sfp-t-exceed : uplink sfp temperature exceed - uplink-sfp-mismatch : uplink sfp mismatch the configured type - loss-lsmwp-cap : lsm redundancy - inv-xvps-pair-data : invalid xvps pair redundancy data - network-power-loss : Loss of Network Power - hw-fault : Hardware Failure - bat-miss : Power Source Battery Missing - bat-fail : Power Source Battery Failure - bat-low : Power Source Battery Charge LOW - bat-a-fail : Power Source BAT-A Fail	

Resource Identifier	Type	Description
	- bat-b-fail : Power Source BAT-B Fail - ac-vol-out-range : AC Input Voltage Value Out of Range - network-power-loss-b : Loss of Network Power B - sem-ac-power-fail : External AC power supply failure - sem-ups-low-volt : External power supply low voltage - dc-a-fail : Local DC A power failure - dc-b-fail : Local DC B power failure - plan-power-mismatch : Planned and detected power mode mismatch - water-seepage-in-box : Detected water seepage in enclosure - sealed-box-open : Sealed box open detected - dc-a-vol-out-range : DC A Input Voltage Value Out of Range - dc-b-vol-out-range : DC B Input Voltage Value Out of Range - inlet-temp-major : The inlet temperature has exceeded a major level - inlet-temp-critical : The inlet temperature has exceeded a critical level - psu-fail-crit : Power Supply failure - psu-a-fail-presence : Power Supply A is not present - psu-a-fail-vin-ac-nok : Power Supply A has Vin AC fault - psu-a-fail-vin-uv : Power Supply A has Vin undervoltage - psu-a-fail-vin-ov : Power Supply A has Vin overvoltage - psu-a-fail-vout-uv : Power Supply A has Vout undervoltage - psu-a-fail-vout-ov : Power Supply A has Vout overvoltage - psu-a-fail-iout-oc : Power Supply A has Iout overcurrent - psu-a-fail-overtemp : Power Supply A has over temperature - psu-b-fail-presence : Power Supply B is not present - psu-b-fail-vin-ac-nok : Power Supply B has Vin AC fault - psu-b-fail-vin-uv : Power Supply B has Vin undervoltage - psu-b-fail-vin-ov : Power Supply B has Vin overvoltage - psu-b-fail-vout-uv : Power Supply B has Vout undervoltage - psu-b-fail-vout-ov : Power Supply B has Vout overvoltage - psu-b-fail-iout-oc : Power Supply B has Iout overcurrent - psu-b-fail-overtemp : Power Supply B has over temperature - synce-fail : synce clock source failure - bits-fail : bits clock source failure - bits-output-shutoff : bits output failure - ieee1588-fail : ieee1588 clock source failure - gnss-fail : gnss clock source failure - ieee1588-hybrid-fail : ieee1588 hybrid tod source failure - signal-loss : synce or bits clock signal loss - signal-efd : synce or bits clock signal exceed frequency deviation - esmc-loss : clock source loss SSM information - bits-output-exceed : exceed bits output threshold - ql-input-exceed : exceed input clock source threshold - holdover : clock system is in the holdover - lti : all clock source failed - tod-reference-fail : Timing ToD Reference failed - internal-clk-fail : Internal CLK failed	

3 Alarm Configuration Commands

Resource Identifier	Type	Description
	- bgp-peer-down : peer operational state is down - bgp-routes-mid-limit : 90% of max nbr of routes BGP can learn from a peer is reached - isis-adjacency-down : isis adjacency is down - isis-adjacency-reject : isis adjacency is rejected - isis-instance-down : isis instance is down or not - ospf-lsa-limit : limit of received LSA's is reached - ospf-lsa-mid-limit : 90% of limit of received LSA's is reached - ospf-neighbor-down : OSPF neighbour is down - ospf-instance-down : OSPF instance is down or not - ospf3-lsa-limit : limit of received OSPFv3 LSAs is reached - ospf3-lsa-mid-limit : 90% of limit of received OSPFv3 LSAs is reached - ospf3-neighbor-down : OSPFv3 neighbour is down - ospf3-instance-down : OSPFv3 instance is down or not - rip-instance-down : rip instance down - lag-down : lag down - lagsubgrp-thresh-reach: lag subgroup threshold reached - lagsubgrp-switch-fail : lag subgroup switchover failed - no-unpinned-free-ports: No free ports available for unpinned traffic - general-arp-limit : arp limit exceeded - gen-switch-out-of-res : failure due to lack of resources on switch - ipv6-nc-limit : ipv6 neighbor cache limit exceeded - dhcp-session-oor : dhcp session out of resources - ihub-fdb-limit : layer 2 fdb limit reached - ihub-mac-limit : layer 2 mac limit reached - l2fw-stp-exception : STP exception condition is present in the SAP - l2fw-stp-root-guard : STP root guard violation is present - vprn-routes-limit : limit of ip is reached - vprn-ipv6-routes-limit: limit of ipv6 is reached - dhcpv6-lease-limit : limit of dhcpv6 leases is reached - dhcpv4-lease-limit : limit of dhcpv4 leases is reached - vpls-mfib-limit : limit of fib table is reached - ihub-ipv6-dad-own : duplicate IPV6 address is detected for IP address allotted to system - ihub-ipv6-dad : duplicate IPV6 address is detected for a user's IP address - ihub-ipv6-dup-pd-route: ipv6 duplicate pd detected - vpls-duplicate-mac : duplicate mac address is detected - vpls-fdb-limit : limit of fdb table is reached - vpls-self-duplic-mac : duplicate of a system owned mac address detected on a sap - vpls-sdp-self-dup-mac : duplicate of a system owned mac address detected on a sdp binding - link-down : link is down - link-lagport-add-fail : failure to add port to LAG - link-conf-mismatch : SFP+plugin-types does not match the planned speed and/or auto-negotiation for the port - ihub-peer-comm : ihub peer to peer communication failure - ihub-sw-fail : IHUB s/w error - ihub-hw-fail : IHUB h/w error - ihub-link-fail : IHUB link failure - ihub-proc-overload : IHUB processor exceeded	

Resource Identifier	Type	Description
	- ihub-out-of-mem : IHUB processor out of memory - ntp-comm-lost : No response is received from the NTP servers - ldp-instance-down : ldp instance down - ldp-session-down : ldp session down - mpls-instance-down : mpls instance down - mpls-lsp-down : lsp down - mpls-lsp-path-down : lsp path down - sdp-instance-down : sdp instance down - sdp-binding-down : sdp binding down - epipe-instance-down : epipe instance down - lldpmed-portcfg-mis : config request failure for lldpmed portconfig - lldpmed-mediapl-mis : config request failure for lldpmed mediapolicy - vlanport-svc-mismatch : config request failure for the provisioned vlanport - mcsrc-stream-lost : multicast video stream lost - eqptsupl-syslog-upload: upload of log file to remote server failure - eqptsupl-ontsw-dnload : ont sw download in progress - cf-75%used : Compact flash exceeds 75% of life expectancy - cf-90%used : Compact flash exceeds 90% of life expectancy - olt-gen-pon-com-fail : pon communication failure on olt - olt-gen-tx-fail : transmitter failure on olt - olt-gen-unprov-ont : unprovisioned ont on pon - olt-gen-pon-eqpt-prov : mismatch btw equipment and provisioning pon attributes - olt-gen-pon-loss-sig : pon loss of signal - olt-gen-pon-diagnostic: pon diagnostic test active - olt-gen-loid-conflict : loid conflict ont on pon - olt-gen-loid-pwderr : loid password error ont on pon - olt-gen-pon-alien-test: pon alien diagnostic test active - olt-gen-alien-detect : pon alien detect active - olt-gen-rng-mism : pon ranging mismatch active - olt-gen-sfp-mism : pon sfp mismatch active - olt-gen-deact-hightca : deactivated ont hightca threshold crossed - olt-gen-deact-lowtca : deactivated ont lowtca threshold crossed - olt-gen-dp-integ : pon data path integrity failure - olt-gen-ddr-fault : pon failure due to ddr fault - olt-pon-tc-err-frag-tc: pon errored fragments threshold crossed - olt-ont-tc-err-frag-tc: ont errored fragments threshold crossed - ont-ploam-loss-sig : loss of signal at ont - ont-ploam-loss-ack : loss of acknowledge from ont - ont-ploam-loss-cd : loss of channel delineation of ont - ont-ploam-phy-eqpt-err: physical equipment error of ont - ont-ploam-startup-fail: startup failure in ranging of ont - ont-ploam-sig-degrade : signal degrade from ont - ont-ploam-disabled : ont disabled alarm - ont-ploam-err-msg : error message from ont - ont-ploam-inactive : inactive ont	

3 Alarm Configuration Commands

Resource Identifier	Type	Description
	- ont-ploam-sig-fail : signal fail alarm from ont - ont-ploam-dying-gasp : dying gasp alarm from ont - ont-ploam-deact-fail : deactive failure of ont - ont-ploam-oam : loss of ploam for ont - ont-ploam-win-drift : drift of window alarm - ont-ploam-rdi : remote defect indication alarm - ont-ploam-loss-ks : loss of key synchronization alarm - ont-ploam-pwr-burst : power bursts on ont - ont-ploam-roq-disa : ont rogue disabled - ont-ploam-diff-reach : ont differential reach exceeded - ont-ploam-looc : Loss of OMCI channel due to persistent MIC failure - sfu-ploam-loss-sig : SFU ONT - loss of signal at ont - sfu-ploam-loss-ack : SFU ONT - loss of acknowledge from ont - sfu-ploam-loss-cd : SFU ONT - loss of channel delineation of ont - sfu-ploam-phy-eqpt-err: SFU ONT - physical equipment error of ont - sfu-ploam-startup-fail: SFU ONT - startup failure in ranging of ont - sfu-ploam-sig-degrade : SFU ONT - signal degrade from ont - sfu-ploam-disabled : SFU ONT - ont disabled alarm - sfu-ploam-err-msg : SFU ONT - error message from ont - sfu-ploam-inactive : SFU ONT - inactive ont - sfu-ploam-sig-fail : SFU ONT - signal fail alarm from ont - sfu-ploam-dying-gasp : SFU ONT - dying gasp alarm from ont - sfu-ploam-deact-fail : SFU ONT - deactive failure of ont - sfu-ploam-oam : SFU ONT - loss of ploam for ont - sfu-ploam-win-drift : SFU ONT - drift of window alarm - sfu-ploam-rdi : SFU ONT - remote defect indication alarm - sfu-ploam-loss-ks : SFU ONT - loss of key synchronization alarm - sfu-ploam-pwr-burst : SFU ONT - power bursts on ont - sfu-ploam-roq-disa : SFU ONT - ont rogue disabled - sfu-ploam-diff-reach : SFU ONT - ont differential reach exceeded - sfu-ploam-looc : SFU ONT - Loss of OMCI channel due to persistent MIC failure - soho-ploam-loss-sig : SOHO ONT - loss of signal at ont - soho-ploam-loss-ack : SOHO ONT - loss of acknowledge from ont - soho-ploam-loss-cd : SOHO ONT - loss of channel delineation of ont - soho-ploam-phy-eqpt-er: SOHO ONT - physical equipment error of ont - soho-ploam-startup-fai: SOHO ONT - startup failure in ranging of ont - soho-ploam-sig-degrade: SOHO ONT - signal degrade from ont - soho-ploam-disabled : SOHO ONT - ont disabled alarm - soho-ploam-err-msg : SOHO ONT - error message from ont - soho-ploam-inactive : SOHO ONT - inactive ont - soho-ploam-sig-fail : SOHO ONT - signal fail alarm from	

Resource Identifier	Type	Description
	ont - soho-ploam-dying-gasp : SOHO ONT - dying gasp alarm from ont - soho-ploam-deact-fail : SOHO ONT - deactive failure of ont - soho-ploam-oam : SOHO ONT - loss of ploam for ont - soho-ploam-win-drift : SOHO ONT - drift of window alarm - soho-ploam-rdi : SOHO ONT - remote defect indication alarm - soho-ploam-loss-ks : SOHO ONT - loss of key synchronization alarm - soho-ploam-pwr-burst : SOHO ONT - power bursts on ont - soho-ploam-roq-disa : SOHO ONT - ont rogue disabled - soho-ploam-diff-reach : SOHO ONT - ont differential reach exceeded - soho-ploam-looc : SOHO ONT - Loss of OMCI channel due to persistent MIC failure - mdu-ploam-loss-sig : MDU ONT - loss of signal at ont - mdu-ploam-loss-ack : MDU ONT - loss of acknowledge from ont - mdu-ploam-loss-cd : MDU ONT - loss of channel delineation of ont - mdu-ploam-phy-eqpt-err: MDU ONT - physical equipment error of ont - mdu-ploam-startup-fail: MDU ONT - startup failure in ranging of ont - mdu-ploam-sig-degrade : MDU ONT - signal degrade from ont - mdu-ploam-disabled : MDU ONT - ont disabled alarm - mdu-ploam-err-msg : MDU ONT - error message from ont - mdu-ploam-inactive : MDU ONT - inactive ont - mdu-ploam-sig-fail : MDU ONT - signal fail alarm from ont - mdu-ploam-dying-gasp : MDU ONT - dying gasp alarm from ont - mdu-ploam-deact-fail : MDU ONT - deactive failure of ont - mdu-ploam-oam : MDU ONT - loss of ploam for ont - mdu-ploam-win-drift : MDU ONT - drift of window alarm - mdu-ploam-rdi : MDU ONT - remote defect indication alarm - mdu-ploam-loss-ks : MDU ONT - loss of key synchronization alarm - mdu-ploam-pwr-burst : MDU ONT - power bursts on ont - mdu-ploam-roq-disa : MDU ONT - ont rogue disabled - mdu-ploam-diff-reach : MDU ONT - ont differential reach exceeded - mdu-ploam-looc : MDU ONT - Loss of OMCI channel due to persistent MIC failure - ont-hpna-ser-mis : hpna ont service mismatch - ont-hpna-los-sig : hpna loss of link - ont-moca-svc-mis : moca ont service mismatch - ont-moca-link-los : moca loss of link - ont-moca-min-bw : moca bw between nodes less than minimum bw - ont-moca-tca-rx-err-fr: moca rx errored frames threshold crossed	

3 Alarm Configuration Commands

Resource Identifier	Type	Description
	- ont-sipa-reg-nm-fail : sipua registration name failed - ont-sipa-reg-rec-fail : sipua register reach failed - ont-sipa-reg-con-fail : sipua register connect failed - ont-sipa-reg-val-fail : sipua register validation failed - ont-sipa-reg-mis : sipua register mismatch - ont-vcd-cfg-nm-fail : vcd config name failed - ont-vcd-cfg-rech-fail : vcd config reach failed - ont-vcd-cfg-conn-fail : vcd config connect failed - ont-vcd-cfg-vali-fail : vcd config validation failed - ont-vcd-cfg-auth-fail : vcd config authentication failed - ont-vcd-cfg-resp-tmout: vcd config response timeout - ont-vcd-cfg-resp-err : vcd config response error - ont-vcd-cfg-file-err : vcd config file error - ont-vcd-sub-nm-fail : vcd subscription name failed - ont-vcd-sub-rech-fail : vcd subscription reach failed - ont-vcd-sub-conn-fail : vcd subscription connect failed - ont-vcd-sub-vali-fail : vcd subscription validation failed - ont-vcd-sub-auth-fail : vcd subscription authentication failed - ont-vcd-sub-resp-tmout: vcd subscription response timeout - ont-vcd-sub-resp-err : vcd subscription response error - ont-vcd-reb-requ : vcd reboot request - ont-vcd-mis : vcd mismatch - ont-mgc-mis : ont mgc mismatch - ont-mgc-timeout : ont mgc timeout - ont-sip-reg-dns : ont services pots sip registration failed (resolving domain name) - ont-sip-reg-fail : ont services pots sip registration authentication failed - ont-sip-reg-timeout : ont services pots sip registration timeout - ont-sip-reg-err-resps : ont services pots sip registration response error - ont-sip-inv-dns : ont services pots sip invitation failed (resolving domain name) - ont-sip-inv-auth : ont services pots sip invitation authentication failed - ont-sip-inv-timeout : ont services pots sip invitation timeout - ont-sip-inv-err : ont services pots sip invitation response error - ont-svc-pots-subs-refr: ont services pots iconfig subscription could not be refreshed - ont-svc-pots-not-refr : ont services pots iconfig notification could not be refreshed - ont-svc-pots-icfg-err : ont services pots service failed due to an unmapped iconfig error - ont-veip-mismatch : ont veip mismatch - ont-ip-host-mismatch : ont ip host mismatch - ont-ip-host-file : ont ip host file unavailable - ont-ip-host-ip-alloc : ont ip host IP allocation failure - olt-pon-up-bw-tca : OLT PON upstream bandwidth TCA - olt-pon-down-bw-tca : OLT PON downstream bandwidth TCA - ont-gen-omci-fail : loss of communication - ont-gen-eqpt-selftest : ont self-test failure - ont-gen-ac-pwr-fail : ac power failure on ont	

Resource Identifier	Type	Description
	- ont-gen-bat-missing : battery missing - ont-gen-bat-low : battery low - ont-gen-bat-fail : battery failure - ont-gen-phys-intrusion: physical intrusion - ont-gen-sw-dnload-f : ont sw download failure - ont-gen-sw-dnload-p : ont sw download in progress - ont-gen-sw-act-fail : ont sw activation failure - ont-gen-eqpt-vers-mis : ont equipment version mismatch - ont-gen-sw-vers-mis : ont sw version mismatch - ont-gen-us-rate-mis : ont upstream rate mismatch - ont-gen-mdu-env1 : mdu environmental alarm#1 - ont-gen-mdu-env2 : mdu environmental alarm#2 - ont-gen-mdu-env3 : mdu environmental alarm#3 - ont-gen-nw-time-err : network timing protocol error - ont-gen-opt-sig-high : optical signal level too high - ont-gen-opt-sig-low : optical signal level too low - ont-gen-eqpt-prov-sa : service affecting mismatch btw equipment and provisioning attributes - ont-gen-eqpt-prov-nsa : non service affecting mismatch btw equipment and provisioning attributes - pon-t-txmcutilhi : pon utilization tx (downstream) multicast high threshold crossed - pon-t-txmcutilmd : pon utilization tx (downstream) multicast medium threshold crossed - pon-t-txmcutillo : pon utilization tx (downstream) multicast low threshold crossed - pon-t-txtotutilhi : pon utilization tx (downstream) total high threshold crossed - pon-t-txtotutilmd : pon utilization tx (downstream) total medium threshold crossed - pon-t-txtotutillo : pon utilization tx (downstream) total low threshold crossed - pon-t-rxtotutilhi : pon utilization rx (upstream) total high threshold crossed - pon-t-rxtotutilmd : pon utilization rx (upstream) total medium threshold crossed - pon-t-rxtotutillo : pon utilization rx (upstream) total low threshold crossed - pon-t-dbacongperiodhi : pon utilization rx (upstream) dbacongperiod high threshold crossed - pon-t-dbacongperiodmd : pon utilization rx (upstream) dbacongperiod medium threshold crossed - pon-t-dbacongperiodlo : pon utilization rx (upstream) dbacongperiod low threshold crossed - pon-t-txucdropfrmhi : pon utilization tx (downstream) unicast drop frame high threshold crossed - pon-t-txucdropfrmmd : pon utilization tx (downstream) unicast drop frame medium threshold crossed - pon-t-txucdropfrmlo : pon utilization tx (downstream) unicast drop frame low threshold crossed - pon-t-txmcdropfrmhi : pon utilization tx (downstream) multicast drop frame high threshold crossed - pon-t-txmcdropfrmmd : pon utilization tx (downstream) multicast drop frame medium threshold crossed - pon-t-txmcdropfrmlo : pon utilization tx (downstream) multicast drop frame low threshold crossed - pon-t-txbcdropfrmhi : pon utilization tx (downstream)	

3 Alarm Configuration Commands

Resource Identifier	Type	Description
	broadcast drop frame high threshold crossed - pon-t-txbcdropfrmmd : pon utilization tx (downstream) broadcast drop frame medium threshold crossed - pon-t-txbcdropfrmlo : pon utilization tx (downstream) broadcast drop frame low threshold crossed - pon-t-rxtotdropfrmhi : pon utilization rx (upstream) total drop frame high threshold crossed - pon-t-rxtotdropfrmmd : pon utilization rx (upstream) total drop frame medium threshold crossed - pon-t-rxtotdropfrmlo : pon utilization rx (upstream) total drop frame low threshold crossed - chpr-t-txmcutilhi : channel-pair utilization tx (downstream) multicast high threshold crossed - chpr-t-txmcutilmd : channel-pair utilization tx (downstream) multicast medium threshold crossed - chpr-t-txmcutillo : channel-pair utilization tx (downstream) multicast low threshold crossed - chpr-t-txtotutilhi : channel-pair utilization tx (downstream) total high threshold crossed - chpr-t-txtotutilmd : channel-pair utilization tx (downstream) total medium threshold crossed - chpr-t-txtotutillo : channel-pair utilization tx (downstream) total low threshold crossed - chpr-t-rxtotutilhi : channel-pair utilization rx (upstream) total high threshold crossed - chpr-t-rxtotutilmd : channel-pair utilization rx (upstream) total medium threshold crossed - chpr-t-rxtotutillo : channel-pair utilization rx (upstream) total low threshold crossed - chpr-t-dbacongperiodhi: channel-pair utilization rx (upstream) dbacongperiod high threshold crossed - chpr-t-dbacongperiodmd: channel-pair utilization rx (upstream) dbacongperiod medium threshold crossed - chpr-t-dbacongperiodlo: channel-pair utilization rx (upstream) dbacongperiod low threshold crossed - chpr-t-txucdropfrmhi : channel-pair utilization tx (downstream) unicast drop frame high threshold crossed - chpr-t-txucdropfrmmd : channel-pair utilization tx (downstream) unicast drop frame medium threshold crossed - chpr-t-txucdropfrmlo : channel-pair utilization tx (downstream) unicast drop frame low threshold crossed - chpr-t-txmcdropfrmhi : channel-pair utilization tx (downstream) multicast drop frame high threshold crossed - chpr-t-txmcdropfrmmd : channel-pair utilization tx (downstream) multicast drop frame medium threshold crossed - chpr-t-txmcdropfrmlo : channel-pair utilization tx (downstream) multicast drop frame low threshold crossed - chpr-t-txbcdropfrmhi : channel-pair utilization tx (downstream) broadcast drop frame high threshold crossed - chpr-t-txbcdropfrmmd : channel-pair utilization tx (downstream) broadcast drop frame medium threshold crossed - chpr-t-txbcdropfrmlo : channel-pair utilization tx (downstream) broadcast drop frame low threshold crossed - chpr-t-rxtotdropfrmhi : channel-pair utilization rx (upstream) total drop frame high threshold crossed	

Resource Identifier	Type	Description
	- chpr-t-rxtotdropfrmmd : channel-pair utilization rx (upstream) total drop frame medium threshold crossed - chpr-t-rxtotdropfrmlo : channel-pair utilization rx (upstream) total drop frame low threshold crossed - sfu-gen-omci-fail : SFU ONT - loss of communication - sfu-gen-eqpt-selftest : SFU ONT - ont self-test failure - sfu-gen-ac-pwr-fail : SFU ONT - ac power failure on ont - sfu-gen-bat-missing : SFU ONT - battery missing - sfu-gen-bat-low : SFU ONT - battery low - sfu-gen-bat-fail : SFU ONT - battery failure - sfu-gen-sw-dnload-f : SFU ONT - ont sw download failure - sfu-gen-sw-dnload-p : SFU ONT - ont sw download in progress - sfu-gen-sw-act-fail : SFU ONT - ont sw activation failure - sfu-gen-eqpt-vers-mis : SFU ONT - ont equipment version mismatch - sfu-gen-sw-vers-mis : SFU ONT - ont sw version mismatch - sfu-gen-us-rate-mis : SFU ONT - ont upstream rate mismatch - sfu-gen-tune-fail : SFU ONT - ont has failed to tune to Target-ChnlPair - sfu-gen-nw-time-err : SFU ONT - network timing protocol error - sfu-gen-opt-sig-high : SFU ONT - optical signal level too high - sfu-gen-opt-sig-low : SFU ONT - optical signal level too low - sfu-gen-eqpt-prov-sa : SFU ONT - service affecting mismatch btw equipment and provisioning attributes - sfu-gen-eqpt-prov-nsa : SFU ONT - non service affecting mismatch btw equipment and provisioning attributes - soho-gen-omci-fail : SOHO ONT - loss of communication - soho-gen-eqpt-selftest : SOHO ONT - ont self-test failure - soho-gen-ac-pwr-fail : SOHO ONT - ac power failure on ont - soho-gen-bat-missing : SOHO ONT - battery missing - soho-gen-bat-low : SOHO ONT - battery low - soho-gen-bat-fail : SOHO ONT - battery failure - soho-gen-sw-dnload-f : SOHO ONT - ont sw download failure - soho-gen-sw-dnload-p : SOHO ONT - ont sw download in progress - soho-gen-sw-act-fail : SOHO ONT - ont sw activation failure - soho-gen-eqpt-vers-mis : SOHO ONT - ont equipment version mismatch - soho-gen-sw-vers-mis : SOHO ONT - ont sw version mismatch - soho-gen-us-rate-mis : SOHO ONT - ont upstream rate mismatch - soho-gen-tune-fail : SOHO ONT - ont has failed to tune to Target-ChnlPair - soho-gen-nw-time-err : SOHO ONT - network timing protocol error - soho-gen-opt-sig-high : SOHO ONT - optical signal level too high	

3 Alarm Configuration Commands

Resource Identifier	Type	Description
	- soho-gen-opt-sig-low : SOHO ONT - optical signal level too low - soho-gen-eqpt-prov-sa : SOHO ONT - service affecting mismatch btw equipment and provisioning attributes - soho-gen-eqpt-prov-nsa: SOHO ONT - non service affecting mismatch btw equipment and provisioning attributes - mdu-gen-omci-fail : MDU ONT - loss of communication - mdu-gen-eqpt-selftest : MDU ONT - ont self-test failure - mdu-gen-ac-pwr-fail : MDU ONT - ac power failure on ont - mdu-gen-bat-missing : MDU ONT - battery missing - mdu-gen-bat-low : MDU ONT - battery low - mdu-gen-bat-fail : MDU ONT - battery failure - mdu-gen-phys-intrusion: MDU ONT - physical intrusion - mdu-gen-sw-dnload-f : MDU ONT - ont sw download failure - mdu-gen-sw-dnload-p : MDU ONT - ont sw download in progress - mdu-gen-sw-act-fail : MDU ONT - ont sw activation failure - mdu-gen-eqpt-vers-mis : MDU ONT - ont equipment version mismatch - mdu-gen-sw-vers-mis : MDU ONT - ont sw version mismatch - mdu-gen-us-rate-mis : MDU ONT - ont upstream rate mismatch - mdu-gen-tune-fail : MDU ONT - ont has failed to tune to Target-ChnlPair - mdu-gen-mdu-env1 : MDU ONT - mdu environmental alarm#1 - mdu-gen-mdu-env2 : MDU ONT - mdu environmental alarm#2 - mdu-gen-mdu-env3 : MDU ONT - mdu environmental alarm#3 - mdu-gen-nw-time-err : MDU ONT - network timing protocol error - mdu-gen-opt-sig-high : MDU ONT - optical signal level too high - mdu-gen-opt-sig-low : MDU ONT - optical signal level too low - mdu-gen-eqpt-prov-sa : MDU ONT - service affecting mismatch btw equipment and provisioning attributes - mdu-gen-eqpt-prov-nsa : MDU ONT - non service affecting mismatch btw equipment and provisioning attributes - ont-gen-sw-dnload-file: ont sw download file missing - ont-gen-fan-fail : ont fan failure - ont-gen-high-temp : ont high temperature - ont-gen-high-temp-ex : ont excessive high temperature - ont-gen-emergency-call: ont emergency call - ont-gen-sw-version : ont sw version control error - ont-poe-exceed-max : ont poe exceed max - ont-poe-overload-yell : ONU is nearing its maximum ability to supply the power - ont-opti-malfunc : malfunction of ONT's optical transceiver	

Resource Identifier	Type	Description
	- ont-gen-cfgdld-fail : download of voice xml file to ont failed - ont-gen-rssi-mis : ONU RSSI configuration mismatch - ont-gen-tx-pwr-low : ONU SFP Tx Power is lower than configured Alarm low threshold - ont-gen-temp-high : ONU SFP Temperature is higher than configured Alarm high threshold - ont-gen-volt-high : ONU SFP Voltage is higher than configured Alarm high threshold - ont-gen-bias-high : ONU SFP Bias is higher than configured Alarm high threshold - ont-loopdetect-mis : ont loop detect mismatch - ont-olt-rx-pw-lo : olt side receive power from ont low - ont-olt-rx-pw-hig : olt side receive power from ont high - ont-olt-rx-pw-warnlo : olt side receive power from ont low warning - ont-olt-rx-pw-warnhig : olt side receive power from ont high warning - ont-gen-tod-out-sync : ONU TOD is out-sync with OLT - ont-gen-tune-fail : ONU has failed to tune to Target-ChnlPair - hgu-tr069-param-fail : hgu tr069 parameters mismatch - ont-gen-tod-mismatch : ONU TOD MISMATCH - sfu-sup-sw-file-error : SFU ONT - Software file has error or is missing - sfu-sup-fan-failure : SFU ONT - Fan failure - sfu-sup-temp-high-warn: SFU ONT - High temperature warning - sfu-sup-temp-shutoff : SFU ONT - Service disabled due to excessive temperature - sfu-sup-emergency-call: SFU ONT - Emergency call active - sfu-sup-swverctrl-err : SFU ONT - Software version control error - sfu-sup-poe-exceed-max: SFU ONT - Configured PoE feeding exceeds ONT maximum - sfu-sup-poe-over-yell : SFU ONT - ONU is nearing its maximum ability to supply the power - sfu-opti-malfunc : SFU ONT - Malfunction of ONT's optical transceiver - sfu-sup-cfg-dnld-fail : SFU ONT - Download of voice xml file to ONT failed - sfu-sup-rssi-cfg-mism : SFU ONT - RSSI configuration mismatch - sfu-sup-sfp-tx-low : SFU ONT - SFP Tx Power below configured low-level alarm threshold - sfu-sup-sfp-temp-high : SFU ONT - SFP Temperature above configured high-level alarm threshold - sfu-sup-sfp-volt-high : SFU ONT - SFP Voltage above configured high-level alarm threshold - sfu-sup-sfp-bias-high : SFU ONT - SFP Bias above configured high-level alarm threshold - sfu-sup-ld-cfg-mism : SFU ONT - Loop detection configuration mismatch - sfu-sup-olt-rx-low : SFU ONT - OLT Rx power below receiver operating range - sfu-sup-olt-rx-high : SFU ONT - OLT Rx power above receiver operating range	

3 Alarm Configuration Commands

Resource Identifier	Type	Description
	- sfu-sup-olt-rx-lo-warn: SFU ONT - OLT Rx power below low-level warning threshold - sfu-sup-olt-rx-hi-warn: SFU ONT - OLT Rx power above high-level warning threshold - sfu-sup-tod-out-sync : SFU ONT - ONU TOD is out-sync with OLT - sfu-sup-ont-tune-fail : SFU ONT - ONU has failed to tune to Target-ChnlPair - sfu-tr069-param-fail : SFU ONT - hgu tr069 parameters mismatch - sfu-sup-tod-mismatch : SFU ONT - ONU TOD MISMATCH - soho-sup-sw-file-error: SOHO ONT - Software file has error or is missing - soho-sup-fan-failure : SOHO ONT - Fan failure - soho-sup-temp-high-war: SOHO ONT - High temperature warning - soho-sup-temp-shutoff : SOHO ONT - Service disabled due to excessive temperature - soho-sup-emergency-cal: SOHO ONT - Emergency call active - soho-sup-swverctrl-err: SOHO ONT - Software version control error - soho-sup-poe-exceed-ma: SOHO ONT - Configured PoE feeding exceeds ONT maximum - soho-sup-poe-over-yell: SOHO ONT - ONU is nearing its maximum ability to supply the power - soho-opti-malfunc : SOHO ONT - Malfunction of ONT's optical transceiver - soho-sup-cfg-dnld-fail: SOHO ONT - Download of voice xml file to ONT failed - soho-sup-rssi-cfg-mism: SOHO ONT - RSSI configuration mismatch - soho-sup-sfp-tx-low : SOHO ONT - SFP Tx Power below configured low-level alarm threshold - soho-sup-sfp-temp-high: SOHO ONT - SFP Temperature above configured high-level alarm threshold - soho-sup-sfp-volt-high: SOHO ONT - SFP Voltage above configured high-level alarm threshold - soho-sup-sfp-bias-high: SOHO ONT - SFP Bias above configured high-level alarm threshold - soho-sup-ld-cfg-mism : SOHO ONT - Loop detection configuration mismatch - soho-sup-olt-rx-low : SOHO ONT - OLT Rx power below receiver operating range - soho-sup-olt-rx-high : SOHO ONT - OLT Rx power above receiver operating range - soho-sup-olt-rx-lo-war: SOHO ONT - OLT Rx power below low-level warning threshold - soho-sup-olt-rx-hi-war: SOHO ONT - OLT Rx power above high-level warning threshold - soho-sup-tod-out-sync : SOHO ONT - ONU TOD is out-sync with OLT - soho-sup-ont-tune-fail: SOHO ONT - ONU has failed to tune to Target-ChnlPair - soho-tr069-param-fail : SOHO ONT - hgu tr069 parameters mismatch	

Resource Identifier	Type	Description
	- soho-sup-tod-mismatch : SOHO ONT - ONU TOD MISMATCH - mdu-sup-sw-file-error : MDU ONT - Software file has error or is missing - mdu-sup-fan-failure : MDU ONT - Fan failure - mdu-sup-temp-high-warn: MDU ONT - High temperature warning - mdu-sup-temp-shutoff : MDU ONT - Service disabled due to excessive temperature - mdu-sup-emergency-call: MDU ONT - Emergency call active - mdu-sup-swverctrl-err : MDU ONT - Software version control error - mdu-sup-poe-exceed-max: MDU ONT - Configured PoE feeding exceeds ONT maximum - mdu-sup-poe-over-yell : MDU ONT - ONU is nearing its maximum ability to supply the power - mdu-opti-malfunc : MDU ONT - Malfunction of ONT's optical transceiver - mdu-sup-cfg-dnld-fail : MDU ONT - Download of voice xml file to ONT failed - mdu-sup-rssi-cfg-mism : MDU ONT - RSSI configuration mismatch - mdu-sup-sfp-tx-low : MDU ONT - SFP Tx Power below configured low-level alarm threshold - mdu-sup-sfp-temp-high : MDU ONT - SFP Temperature above configured high-level alarm threshold - mdu-sup-sfp-volt-high : MDU ONT - SFP Voltage above configured high-level alarm threshold - mdu-sup-sfp-bias-high : MDU ONT - SFP Bias above configured high-level alarm threshold - mdu-sup-ld-cfg-mism : MDU ONT - Loop detection configuration mismatch - mdu-sup-olt-rx-low : MDU ONT - OLT Rx power below receiver operating range - mdu-sup-olt-rx-high : MDU ONT - OLT Rx power above receiver operating range - mdu-sup-olt-rx-lo-warn: MDU ONT - OLT Rx power below low-level warning threshold - mdu-sup-olt-rx-hi-warn: MDU ONT - OLT Rx power above high-level warning threshold - mdu-sup-tod-out-sync : MDU ONT - ONU TOD is out-sync with OLT - mdu-sup-ont-tune-fail : MDU ONT - ONU has failed to tune to Target-ChnlPair - mdu-tr069-parm-fail : MDU ONT - hgu tr069 parameters mismatch - mdu-sup-tod-mismatch : MDU ONT - ONU TOD MISMATCH - ont-sbscr-lim-missing : provisioned ont card missing - ont-sbscr-lim-type-mis: wrong type plug-in ont card - ont-sbscr-lim-removal : improper removal ont card - ont-sbscr-lim-fail : ont card failure - ont-sbscr-lim-svc-mis : ont service mismatch for provisioned onu card - ont-sbscr-lim-port-mis: port mismatch btw actual and planned ont card	

3 Alarm Configuration Commands

Resource Identifier	Type	Description
	- ont-svc-video-conf-mis: config request failure for video service - ont-svc-video-pw-high : high power level for rf video signal - ont-svc-video-pw-low : low power level for rf video signal - ont-svc-pots-svc-mis : ont service mismatch for provisioned pots - ont-svc-pots-rtcp-lost: pots realtime transport control protocol stream lost - ont-svc-pots-icnf-subs: pots line iconfig subscription failure - ont-svc-pots-icnf-ntfy: pots line iconfig notify failure - ont-svc-pots-icnf-http: pots line iconfig http failure - ont-svc-pots-sip-reg : pots line sip registration failure - ont-svc-pots-sip-inv : pots line sip invite request failure - ont-svc-pots-sip-subsc: pots line sip subscribe failure - ont-svc-pots-sip-mt-tc: pots line sip message timeout threshold crossed - ont-svc-pots-pk-los-tc: pots line rtp bearer packets loss threshold crossed - ont-svc-pots-jitter-tc: pots line rtp jitter threshold crossed - ont-svc-pots-subs-dns : pots line iconfig subscription failed (DNS) - ont-svc-pots-subs-tcp : pots line iconfig subscription failed (TCP) - ont-svc-pots-subs-tls : pots line iconfig subscription failed (TLS) - ont-svc-pots-subs-auth: pots line iconfig subscription failed authentication - ont-svc-pots-subs-to : pots line iconfig subscription failed (timeout) - ont-svc-pots-subs-err : pots line iconfig subscription response error - ont-svc-pots-not-to : pots line iconfig notification failed (timeout) - ont-svc-pots-notref-to: pots line iconfig notification refresh failed - ont-svc-pots-not-mal : pots line iconfig notification failed (malformed) - ont-svc-pots-not-rej : pots line iconfig notification rejected - ont-svc-pots-http-dns : pots line iconfig doc retrieval failed (DNS) - ont-svc-pots-http-tcp : pots line iconfig doc retrieval failed (TCP) - ont-svc-pots-http-tls : pots line iconfig doc retrieval failed (TLS) - ont-svc-pots-http-auth: pots line iconfig doc retrieval failed (authentication) - ont-svc-pots-http-to : pots line iconfig doc retrieval failed (timeout) - ont-svc-pots-http-err : pots line iconfig doc retrieval response error - ont-svc-pots-http-mal : pots line iconfig doc retrieval failed (malformed) - ont-svc-pots-insuff : pots line iconfig service failed (insufficient data) - ont-svc-pots-poos : pots ports out of service	

Resource Identifier	Type	Description
	- ont-svc-lan-mismatch : ont service mismatch for lan - ont-svc-lan-loss-sig : loss of signal on an ethernet port interface - ont-svc-enet-poos : Ethernet Ports out of Service - ont-svc-ces-ds1-mis : ont service mismatch for provisioned ces ds1 - ont-svc-ces-ds1-los : loss of signal at ds1 interface - ont-svc-ces-ds1-lof : loss of frame at ds1 interface - ont-svc-ces-ds1-rair : receiving rai at ds1 interface - ont-svc-ces-ds1-ais : receiving ais at ds1 interface - ont-svc-ces-ds1-lnlpbk: receiving line loopback at ds1 interface - ont-svc-ces-ds1-tmlpbk: receiving terminal loopback at ds1 interface - ont-svc-ces-e1-mis : ont service mismatch for provisioned ces e1 - ont-svc-ces-e1-los : loss of signal at e1 interface - ont-svc-ces-e1-lof : loss of frame at e1 interface - ont-svc-ces-e1-rair : receiving rai at e1 interface - ont-svc-ces-e1-ais : receiving ais at e1 interface - ont-svc-voip-cnf-file : voice configuration file error - ont-svc-voip-svc-mis : service mismatch for provisioned client service - ont-svc-voip-gw-comm : voice gateway communication failure - ont-svc-voip-dhcp-fail: voice dhcp server failure - ont-svc-voip-icnf-subs: voice iconfig subscription failure - ont-svc-voip-icnf-ntfy: voice iconfig notify failure - ont-svc-voip-icnf-http: voice iconfig http failure - ont-svc-voip-dhcp-to : DHCP server retransmissions timed out - ont-svc-voip-dhcp-mal : DHCP response was malformed - ont-svc-voip-dhcp-noad: DHCP server failed to issue the required parameters - ont-svc-voip-dhcp-leas: DHCP Server failure due to problem in lease renewal - ont-svc-voip-subs-dns : iConfig Subscription failure due to DNS problem - ont-svc-voip-subs-tcp : iConfig Subscription failure due to TCP socket problem - ont-svc-voip-subs-tls : iConfig Subscription failure due to TLS session problem - ont-svc-voip-subs-auth: iConfig Subscription failure due to authentication error - ont-svc-voip-subs-to : iConfig Subscription failure due to retransmission timeout - ont-svc-voip-subs-err : iConfig Subscription failure due to response error - ont-svc-voip-not-to : iConfig Notify response timeout for new subscription - ont-svc-voip-notref-to: iConfig Notify response timeout for subscription refresh - ont-svc-voip-not-mal : iConfig Notify response is malformed - ont-svc-voip-not-rej : iConfig subscription request rejected by configuration server - ont-svc-voip-http-dns : VOIP client can't retrieve config	

3 Alarm Configuration Commands

Resource Identifier	Type	Description
	doc due to DNS problem - ont-svc-voip-http-tcp : VOIP client can't retrieve config doc due to TCP socket problem - ont-svc-voip-http-tls : VOIP client can't retrieve config doc due to TLS session problem - ont-svc-voip-http-auth: VOIP client can't retrieve config doc due to auth error - ont-svc-voip-http-to : VOIP client can't retrieve config doc due to re-tx timeout - ont-svc-voip-http-err : VOIP client can't retrieve config doc due to response error - ont-svc-voip-http-mal : iConfig configuration document is malformed - ont-svc-voip-subs-refr: iConfig Subscription refresh error - ont-svc-voip-not-refr : iConfig Notify response for refresh subscribe failed - ont-svc-voip-icfg-err : iConfig Configuration Error - ont-svc-v-ani-conf-mis: config request failure for video ani service - ont-svc-v-ani-loss-sig: video loss of signal on ani - ont-svc-v-ani-lv-high : high video optical signal level - ont-svc-v-ani-lv-low : low video optical signal level - ont-svc-pwe-mismatch : service mismatch for provisioned pseudowire - ont-svc-pwe-reordr-lof: pseudowire reordering and loss of frame - ont-svc-pwe-jitt-buf-o: pseudowire jitter buffer overrun - ont-svc-pwe-jitt-buf-u: pseudowire jitter buffer underrun - ont-svc-pwe-malf-frms : pseudowire malformed frames - ont-svc-pwe-late-frms : pseudowire late frames - ont-svc-pwe-link-loss : pseudowire link loss - ont-svc-pwe-arp-fail : pseudowire arp failure - ont-svc-xdsl-mismatch : service mismatch for provisioned xdsl - ont-svc-xdsl-ne-lof : near end loss of frame - ont-svc-xdsl-ne-los : near end loss of signal - ont-svc-xdsl-ne-line : near end line init - ont-svc-xdsl-ne-lol : near end loss of link - ont-svc-xdsl-fe-lof : far end loss of frame - ont-svc-xdsl-fe-los : far end loss of signal - ont-svc-xdsl-fe-lop : far end loss of power - ont-svc-xdsl-cnfr-err : xdsl provisioning error - ont-svc-xdsl-ne-es-tc : near end errored seconds threshold crossed - ont-svc-xdsl-ne-ses-tc: near end severe errored seconds threshold crossed - ont-svc-xdsl-ne-uas-tc: ear end unavailable seconds threshold crossed - ont-svc-xdsl-fe-es-tc : far end errored seconds threshold crossed - ont-svc-xdsl-fe-ses-tc: far end severe errored seconds threshold crossed - ont-svc-xdsl-fe-uas-tc: far end unavailable seconds threshold crossed - ont-tc-rx-los-frag-tc : rx loss of gem fragments threshold crossed - ont-tc-tx-los-frag-tc : tx loss of gem fragments threshold	

Resource Identifier	Type	Description
	- crossed - ont-tc-bad-gem-hd-tc : bad gem header threshold crossed - ont-uni-ds-drpd-fr-tc : downstream l2 dropped frames threshold crossed - ont-uni-up-drpd-fr-tc : upstream l2 dropped frames threshold crossed - ont-uni-ds-crc-fr-tc : downstream l2 rx crc error frames threshold crossed - ont-uni-up-crc-fr-tc : upstream l2 rx crc error frames threshold crossed - ont-cpu-util-tca : ONT CPU utilization threshold crossed - ont-mem-util-tca : ONT memory utilization threshold crossed - pim-neighbor-down : pim neighbor down - pim-max-mcroutes : maximum routes reached - li-traffic-disabled : lawful interception of traffic disabled - li-bandwidth-limit : lawful intercept reached bandwidth limit - li-out-of-res : lawful intercept out of resources - otdr-cap-mismatch : otdr capability mismatch - login-successful : successful login via management access - login-failure : invalid login via management access has crossed the threshold limit - cfm-defrdiccm : rdi bit in ccm received - cfm-defmacstatus : ccm mac error status - cfm-defremoteccm : missing ccm from mep - cfm-deferrorccm : invalid ccm received - cfm-defxconccm : unexpected ccm received - cfm-defais : ethernet ais received - bfd-session-down : bfd session down - bfd-max-resource : bfd maximum resources reached - bfd-stale-entry : bfd stale entry present - tca-outputbw : tca output bandwidth - tca-inputbw : tca input bandwidth - tca-rxcrcalign : tca rxrc align errors - tca-txcrcalign : tca txrc align errors - tca-txcollisions : tca tx collision errors - tca-outputhighbw : tca output high bandwidth - tca-outputmedbw : tca output medium bandwidth - tca-outputlowbw : tca output low bandwidth - tca-inputhighbw : tca input high bandwidth - tca-inputmediumbw : tca input medium bandwidth - tca-inputlowbw : tca input low bandwidth - eth-cfm-defrdiccm : rdi bit in ccm received - eth-cfm-defmacstatus : ccm mac error status - eth-cfm-defremoteccm : missing ccm from mep - eth-cfm-deferrorccm : invalid ccm received - eth-cfm-defxconccm : unexpected ccm received - rsvp-neighbor-down : rsvp neighbor down - rsvp-instance-down : rsvp instance down - eth-ring-path-block : eth ring path block - ai-platform-down : Application Intelligence Platform down - ai-appl-install-fail : Application installation failure - ip-assign-fail : Dhcp assigned address failure - ont-tr069-serv-mis : ont tr069 server config mismatch - ont-snmp-mis : ont snmp agent config mismatch - bsf-dhcpv4 : bulksync failed for dhcpv4	

3 Alarm Configuration Commands

Resource Identifier	Type	Description
	- bsf-dhcpv6 : bulksync failed for dhcpv6 - bsf-pon : bulksync failed for pon - bsf-vbridge : bulksync failed for vlan-bridge - bsf-qos : bulksync failed for qos - bsf-igmp : bulksync failed for igmp - bsf-lxfwd : bulksync failed for lxfwd - prot-not-available : no protection not available - prot-switchover-fail : port switch over failed - efm-oam-cpelinkfault : EFM-OAM CPE link fault - efm-oam-cpedyinggasp : EFM-OAM CPE dying gasp - efm-oam-cpecrevt : EFM-OAM CPE critical event - ont-loopdetect : ont loop detect - alrm-tbl-overflow : alarm table has overflowed - auto-switch-status : auto-switch status - auswqueuefullatm : auto-switch queue Full for ATM - auswbkpfailatm : auto-switch config data backup failed for ATM - auswrecfgfailatm : auto-switch fallback reconfiguration failed for ATM - auswdataunatm : auto-switch backup config data unavailable for ATM - auswqueuefulptm : auto-switch queue Full for PTM - auswbkpfailptm : auto-switch config data backup failed for PTM - auswrecfgfailptm : auto-switch fallback reconfiguration failed for PTM - auswdataunptm : auto-switch backup config data unavailable for PTM - auswbakpfailatm : auto-switch backup fail for ATM - chpr-com-fail : channel pair communication failure on olt - chpr-tx-fail : transmitter failure on channel pair - chpr-unprov-ont : unprovisioned ont on channel pair - chpr-prov-mismatch : mismatch btw equipment and provisioning pon attributes - chpr-loss-sig : channel pair loss of signal - chpr-diagnostic : channel pair diagnostic test active - chpr-loid-conflict : loid conflict ont on channel pair - chpr-loid-pwd-err : loid password error ont on channel pair - chpr-stk-laser-dis : stuck laser disabled on channel pair - chpr-sfp-mismatch : channel pair sfp mismatch - chpr-rng-mismatch : channel pair ranging mismatch - chpr-alien-test : channel pair alien diagnostic test active - chpr-alien-detect : channel pair alien detect active - chpr-deact-hightca : channel pair deactivated ont hightca threshold crossed - chpr-deact-lowtca : channel pair deactivated ont lowtca threshold crossed - chpr-dp-integ : channel pair data path integrity failure - olt-chpr-tc-err-frag : channelpair errored fragments threshold crossed - olt-chpr-up-bw-tca : OLT CHANNELPAIR upstream bandwidth TCA - olt-chpr-down-bw-tca : OLT CHANNELPAIR downstream bandwidth TCA - cfg-dld-fail : download of configure file to ont failed - cfg-act-fail : activate the passive config file failed - cfg-dld-ip : ont configure file download in progress	

Resource Identifier	Type	Description
	- cfg-ver-mismatch : the planned configure file does not match the active configure file - cfg-file-missing : ont configure file missing or has an error - cfg-verctrl-err : ont configure file version control error - cfg-not-supported : ont not support the configure file download function - ont-prot-not-available: ONT/ONU protection not available - ont-gen-temp-low : ONU SFP temperature is lower than configured Alarm low threshold - ont-gen-volt-low : ONU SFP Voltage is lower than configured Alarm low threshold - ont-gen-tx-pwr-high : ONU SFP Tx power is higher than configured Alarm high threshold - ont-gen-bias-low : ONU SFP bias is lower than configured Alarm low threshold - ont-gen-rx-hwarn : ONU SFP Rx power is higher than warn threshold - ont-gen-rx-lwarn : ONU SFP Rx power is lower than warn threshold - ont-gen-tx-hwarn : ONU SFP Tx power is higher than warn threshold - ont-gen-tx-lwarn : ONU SFP Tx power is lower than warn threshold - ont-gen-temp-hwarn : ONU SFP temperature is higher than warn threshold - ont-gen-temp-lwarn : ONU SFP temperature is lower than warn threshold - ont-gen-volt-hwarn : ONU SFP Voltage is higher than warn threshold - ont-gen-volt-lwarn : ONU SFP Voltage is lower than warn threshold - ont-gen-bias-hwarn : ONU SFP bias is higher than warn threshold - ont-gen-bias-lwarn : ONU SFP bias is lower than warn threshold - sfu-sup2-temp-low : SFU ONT - SFP temperature is lower than configured Alarm low threshold - sfu-sup2-volt-low : SFU ONT - SFP Voltage is lower than configured Alarm low threshold - sfu-sup2-tx-high : SFU ONT - SFP tx power is higher than configured Alarm high threshold - sfu-sup2-bias-low : SFU ONT - SFP bias is lower than configured Alarm low threshold - sfu-sup2-rx-hwarn : SFU ONT - SFP rx power is higher than configured warn threshold - sfu-sup2-rx-lwarn : SFU ONT - SFP rx power is lower than configured warn threshold - sfu-sup2-tx-hwarn : SFU ONT - SFP tx power is higher than configured warn threshold - sfu-sup2-tx-lwarn : SFU ONT - SFP tx power is lower than configured warn threshold - sfu-sup2-temp-hwarn : SFU ONT - SFP temperature is higher than configured warn threshold - sfu-sup2-temp-lwarn : SFU ONT - SFP temperature is lower than configured warn threshold - sfu-sup2-volt-hwarn : SFU ONT - SFP Voltage is higher than configured warn threshold	

3 Alarm Configuration Commands

Resource Identifier	Type	Description
	- sfu-sup2-volt-lwarn : SFU ONT - SFP Voltage is lower than configured warn threshold - sfu-sup2-bias-hwarn : SFU ONT - SFP bias is higher than configured warn threshold - sfu-sup2-bias-lwarn : SFU ONT - SFP bias is lower than configured warn threshold - soho-sup2-temp-low : SOHO ONT - SFP temperature is lower than configured Alarm low threshold - soho-sup2-volt-low : SOHO ONT - SFP Voltage is lower than configured Alarm low threshold - soho-sup2-tx-high : SOHO ONT - SFP tx power is higher than configured Alarm low threshold - soho-sup2-bias-low : SOHO ONT - SFP bias is lower than configured Alarm low threshold - soho-sup2-rx-hwarn : SOHO ONT - SFP rx power is higher than warn threshold - soho-sup2-rx-lwarn : SOHO ONT - SFP rx power is lower than warn threshold - soho-sup2-tx-hwarn : SOHO ONT - SFP tx power is higher than warn threshold - soho-sup2-tx-lwarn : SOHO ONT - SFP tx power is lower than warn threshold - soho-sup2-temp-hwarn : SOHO ONT - SFP temperature is higher than warn threshold - soho-sup2-temp-lwarn : SOHO ONT - SFP temperature is lower than warn threshold - soho-sup2-volt-hwarn : SOHO ONT - SFP Voltage is higher than warn threshold - soho-sup2-volt-lwarn : SOHO ONT - SFP Voltage is lower than warn threshold - soho-sup2-bias-hwarn : SOHO ONT - SFP bias is higher than warn threshold - soho-sup2-bias-lwarn : SOHO ONT - SFP bias is lower than warn threshold - mdu-sup2-temp-low : MDU ONT - SFP temperature is lower than configured alarm low threshold - mdu-sup2-volt-low : MDU ONT - SFP Voltage is lower than configured alarm low threshold - mdu-sup2-tx-high : MDU ONT - SFP tx power is higher than configured alarm low threshold - mdu-sup2-bias-low : MDU ONT - SFP bias is lower than configured alarm low threshold - mdu-sup2-rx-hwarn : MDU ONT - SFP rx power is higher than warn threshold - mdu-sup2-rx-lwarn : MDU ONT - SFP rx power is lower than warn threshold - mdu-sup2-tx-hwarn : MDU ONT - SFP tx power is higher than warn threshold - mdu-sup2-tx-lwarn : MDU ONT - SFP tx power is lower than warn threshold - mdu-sup2-temp-hwarn : MDU ONT - SFP temperature is higher than warn threshold - mdu-sup2-temp-lwarn : MDU ONT - SFP temperature is lower than warn threshold - mdu-sup2-volt-hwarn : MDU ONT - SFP voltage is higher than warn threshold - mdu-sup2-volt-lwarn : MDU ONT - SFP voltage is lower than warn threshold	

Resource Identifier	Type	Description
	than warn threshold - mdu-sup2-bias-hwarn : MDU ONT - SFP bias is higher than warn threshold - mdu-sup2-bias-lwarn : MDU ONT - SFP bias is lower than warn threshold - cust-alm1 : customizable alarm 1 - cust-alm2 : customizable alarm 2 - cust-alm3 : customizable alarm 3 - cust-alm4 : customizable alarm 4 - cust-alm5 : customizable alarm 5 - cust-alm6 : customizable alarm 6 - cust-alm7 : customizable alarm 7 - cust-alm8 : customizable alarm 8 - cust-alm9 : customizable alarm 9 - cust-alm10 : customizable alarm 10 - cust-alm11 : customizable alarm 11 - cust-alm12 : customizable alarm 12 - cust-alm13 : customizable alarm 13 - cust-alm14 : customizable alarm 14 - cust-alm15 : customizable alarm 15 - cust-alm16 : customizable alarm 16 - cust-alm17 : customizable alarm 17 - cust-alm18 : customizable alarm 18 - cust-alm19 : customizable alarm 19 - cust-alm20 : customizable alarm 20 - cust-alm21 : customizable alarm 21 - cust-alm22 : customizable alarm 22 - cust-alm23 : customizable alarm 23 - cust-alm24 : customizable alarm 24 - cust-alm25 : customizable alarm 25 - cust-alm26 : customizable alarm 26 - cust-alm27 : customizable alarm 27 - cust-alm28 : customizable alarm 28 - cust-alm29 : customizable alarm 29 - cust-alm30 : customizable alarm 30 - cust-alm31 : customizable alarm 31 - ethernet-ring-pthfwst : ethernet ring path forward state - ethernet-ring-fop-to : ethernet ring fop-to failure of protocol timeout - ethernet-ring-fop-pm : ethernet ring fop-pm failure of protocol provision mismatch - fpm-depletion : failsafe fpm depletion - exp-seizureack : Channel was blocked due to failure in the reception of the SEIZURE ACK signal - exp-disconack : Channel was blocked due to failure in the reception of the DISCONNECTION ACK signal - exp-forcerelack : Channel was blocked due to failure in the reception of the BACKWARD DISCONNECTION ACK signal - packet-loss : Pseudo Wire entered the Packet loss state - remote-packet-loss : Remote Packet loss detected - no-dsp-resource : DSP resource allocation failed - la-down : Link aggregation group link-status is down - la-standby-na : Cross-lt lag on standby slot part is not available - la-switch-fail : Cross-lt lag fail to do switchover - la-degrade : Link aggregation group degrade	

3 Alarm Configuration Commands

Resource Identifier	Type	Description
	- melt-board-reset : MELT board reset - board-shelf-mismatch : board type and shelf type mismatch - fcs-thresh-exceed : FCS counter threshold exceeded	

Table 3.3-2 "Alarm Entry Configuration Command" Command Parameters

Parameter	Type	Description
[no] severity	Parameter type: <Alarm::alarmSeverity> Format: (indeterminate warning minor major critical ignore) Possible values: - indeterminate : not a definite known severity level - warning : just to inform as a warning - minor : not service affecting - major : service affecting - critical : service breaking - ignore : alarm is not processed by the system	<i>optional parameter with default value: "minor"</i> assign a severity level to this alarm
[no] service-affecting	Parameter type: boolean	<i>optional parameter</i> make this alarm service affecting
[no] reporting	Parameter type: boolean	<i>optional parameter</i> enable reporting of this alarm
[no] logging	Parameter type: boolean	<i>optional parameter</i> enable logging of this alarm

Command Output

Table 3.3-3 "Alarm Entry Configuration Command" Display parameters

Specific Information		
name	Type	Description
category	Parameter type: <Alarm::category> (communications qos processing-error equipment environmental) Possible values: - communications : communications related alarms - qos : QoS related alarms - processing-error : processing failure related alarms - equipment : equipment related alarms - environmental : environmental related alarms	category of an alarm <i>This element is always shown.</i>

3.4 Alarm Filter Configuration Command

Command Description

This command allows the operator to configure Alarm filter parameters.

User Level

The command can be accessed by operators with alarm privileges, and executed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> configure alarm filter (fltr-type) filterid <Alarm::fltrId> [ alarmid <Alarm::alarmIndexExt> ] [ no status | status <Alarm::fltrStatus> ] [ no threshold | threshold <Alarm::fltrThreshold> ] [ no window | window <Alarm::fltrWindow> ]
```

Command Parameters

Table 3.4-1 "Alarm Filter Configuration Command" Resource Parameters

Resource Identifier	Type	Description
(fltr-type)	Format: (temporal spatial) Possible values: - temporal : the temporal alarm filter - spatial : the spatial alarm filter	the type of the considered alarm filter
filterid	Parameter type: <Alarm::fltrId> Format: - unique filter number - range: [1...31]	unique filter number

Table 3.4-2 "Alarm Filter Configuration Command" Command Parameters

Parameter	Type	Description
alarmid	Parameter type: <Alarm::alarmIndexExt> Format: (all xtca-ne-es xtca-ne-ses xtca-ne-uas xtca-ne-day-es xtca-ne-day-ses xtca-ne-day-uas xtca-fe-es xtca-fe-ses xtca-fe-uas xtca-fe-day-es	<i>optional parameter</i> alarmType

3 Alarm Configuration Commands

Parameter	Type	Description
	xtca-fe-day-ses xtca-fe-day-uas xtca-leftrs xtca-day-leftrs xtca-fe-leftrs xtca-fe-day-leftrs xtca-auto-port-reset xtca-reinit xtca-day-reinit xdsl-ne-los xdsl-ne-lof xdsl-ne-lom xdsl-ne-ese xdsl-act-cfg-error xdsl-act-not-feas xdsl-up-br-reach xdsl-ne-ncd xdsl-ne-lcd xdsl-fe-los xdsl-fe-lof xdsl-fe-lpr xdsl-fe-lol xdsl-fe-lom xdsl-fe-ese xdsl-fe-upbo-vio xdsl-fe-cpe-pol xdsl-tpstc-mis xdsl-act-comm xdsl-act-modem xdsl-do-br-reach xdsl-fe-ncd xdsl-fe-lcd xdsl-frtx-init-fail xdsl-vect-dle xdsl-fe-mis-peer-35b vectline-xtc-var-vict vectline-xtc-var-dist vectline-corp-errf vect-cpe-cap-mismatch vectline-conf_notfeas vect-vp-lt-mismatch vect-inv-qsfp vect-vp-lt-fail vect-no-gain-at-init sw-rollback db-rollback xvps-inv-dbase inv-cde-file miss-cde-file cde-hash-error low-disk-space cell-discard-up cell-discard-down persist-data-loss mac-conflict vmac-full snntp-comm-lost	

Parameter	Type	Description
	<pre> preferred-mode timing-reference nt-disk-95%full shub-loc cf-error back-pnl-inv ihub-conf-loss rack-power rack-fan-unit1 rack-fan-unit2 shelf-mismatch shelf-missing shelf-install-missing door ac-power-fail board-mismatch waiting-for-sw temp-exceeded backplane-data-failure temp-shutdown board-missing board-instl-missing board-init board-reset-prot sem-power-fail sem-ups-fail board-reset-cf vlan-assign-fail vsa-info-invalid auth-mac-conflict user-pwd-fault up-plan-bitrate up-min-bitrate up-config-not-feas down-plan-bitrate down-min-bitrate down-config-not-feas non-bonding-cpe multiple-cpes register group-incomplete host-sfp-los host-sfp-tx-fail host-sfp-not-prst host-sfp-inv-id host-sfp-ctrl-fail host-sfp-rmtlt host-sfp-mismatch host-sfp-incompt exp-sfp-los exp-sfp-tx-fail exp-sfp-not-prst exp-sfp-inv-id exp-sfp-ctrl-fail exp-sfp-1-los exp-sfp-2-los ext-qsfp-invld </pre>	

3 Alarm Configuration Commands

Parameter	Type	Description
	tx-power-high-alarm tx-power-low-alarm rx-power-high-alarm rx-power-low-alarm tx-biascur-high-alarm tx-biascur-low-alarm volt-high-alarm volt-low-alarm temp-high-alarm temp-low-alarm tx-power-high-warn tx-power-low-warn rx-power-high-warn rx-power-low-warn tx-biascur-high-warn tx-biascur-low-warn volt-high-warn volt-low-warn temp-high-warn temp-low-warn onu-unprovisioned signal-loss bitrate-high opmodule-mismatch key-fail-one-churn key-fail-three-churn oam-discov-fail report-timeout total-packets-exceed arp-packets-exceed dhcp-packets-exceed igmp-packets-exceed pppoe-packets-exceed nd-packets-exceed icmpv6-packets-exceed mld-packets-exceed dhcpv6-packets-exceed cfm-packets-exceed dsx1-serdes-fail dsx1-tributary1-fail dsx1-tributary2-fail dsx1-los-fail dsx1-ais-sync dsx1-lof-sync dsx1-los-sync dsx1-deg-fail dsx1-rei-from-liu dsx1-rdi-from-liu dsx1-crc6-from-liu dsx1-crc4-from-liu dsx1-crc4-th-from-liu dsx1-ais-from-liu dsx1-los-from-liu dsx1-lof-from-liu dsx1-lomf-from-liu dsx1-rei-from-iwf dsx1-rdi-from-iwf	

Parameter	Type	Description
	dsx1-crc6-from-iwf	
	dsx1-crc4-from-iwf	
	dsx1-crc4-th-from-iwf	
	dsx1-ais-from-iwf	
	dsx1-los-from-iwf	
	dsx1-lof-from-iwf	
	dsx1-lomf-from-iwf	
	pppce-trans-15min-tca	
	pppce-sess-15min-tca	
	pppce-trans-1day-tca	
	pppce-sess-1day-tca	
	custom1	
	custom2	
	custom3	
	custom4	
	custom5	
	he-custom1	
	he-custom2	
	he-custom3	
	he-custom4	
	he-custom5	
	he-custom6	
	custom6	
	custom7	
	custom8	
	custom9	
	custom10	
	custom11	
	custom12	
	custom13	
	custom14	
	custom15	
	custom16	
	custom17	
	loss-swo-cap	
	ping-check-fail	
	der-temp1	
	der-temp2	
	der-temp3	
	der-temp4	
	der-temp5	
	der-temp6	
	der-temp7	
	der-temp8	
	der-temp9	
	der-temp10	
	der-temp11	
	der-temp12	
	der-temp13	
	der-temp14	
	der-temp15	
	der-temp16	
	der-temp17	
	der-temp18	
	der-temp19	
	der-temp20	
	der-temp21	

3 Alarm Configuration Commands

Parameter	Type	Description
	der-temp22 der-temp23 der-temp24 der-temp25 der-temp26 der-temp27 der-temp28 der-temp29 der-temp30 der-temp31 der-spa1 der-spa2 der-spa3 der-spa4 der-spa5 der-spa6 der-spa7 der-spa8 der-spa9 der-spa10 der-spa11 der-spa12 der-spa13 der-spa14 der-spa15 der-spa16 der-spa17 der-spa18 der-spa19 der-spa20 der-spa21 der-spa22 der-spa23 der-spa24 der-spa25 der-spa26 der-spa27 der-spa28 der-spa29 der-spa30 der-spa31 apsf-alarm custextalarm1 custextalarm2 custextalarm3 custextalarm4 custextalarm5 pluginfan plugin-dc-a plugin-dc-b plugin-dg ntr-a-loss ntr-b-loss xvps-conf-loss mac-entry-nofree fibre-conn-mismatch link-cap-mismatch	

Parameter	Type	Description
	eqpt-cap-mismatch ctrl-dnld-failure melt-hw-issue melt-board-reset board-shelf-mismatch mgnt-type-mismatch fileserv-unavail shdsl-n-loopback shdsl-c-loopback shdsl-conferr shdsl-atm-lcd shdsl-lpr shdsl-secu-err shdsl-dev-fault shdsl-atm-ncd shdsl-n-losw shdsl-c-losw shdsl-n-aten shdsl-c-aten shdsl-n-snr shdsl-c-snr shdsl-n-dccont shdsl-c-dccont shdsl-c-actfail e1-fe-rai e1-ne-rai e1-fe-ais e1-ne-ais e1-lof e1-los e1-loopback ima-grp-fe-su ima-grp-fe-cfg ima-grp-ne-cfg ima-grp-fe-nl ima-grp-ne-nl ima-grp-fe-blk ima-lnk-lif ima-lnk-lods ima-lnk-misc ima-lnk-rfi ima-lnk-fault ima-lnk-txblk ima-lnk-rxblk bad-digitmap dhcp-unreach dhcp-no-srv dhcp-inv-srv norpniewithsoftdsp unknown-sub ground-key port-hightemp port-jbfltca reg-domainname reg-auth reg-timeout reg-srvfailresp	

3 Alarm Configuration Commands

Parameter	Type	Description
	inv-domainname inv-auth inv-timeout inv-srvfailresp subs-srvfailresp subs-domainname subs-auth subs-refreshfail subs-inittimeout emergency-call e1sip-reg-domainname e1sip-reg-auth e1sip-reg-timeout e1sip-reg-srvfailresp e1sip-inv-domainname e1sip-inv-auth e1sip-inv-timeout e1sip-inv-srvfailresp e1sip-emergency-call e1itf-ais-signal e1itf-los-signal e1itf-rai-signal e1sip-misconfig-mgc10 e1sip-nsmprf-missed e1t1itf-recv-ais e1t1itf-recv-los e1t1itf-recv-rai transport-mismatch dns-lookup-failure none-dns-srv no-dns-srv none-srv no-srv reg-srv-unreach proxy-srv-unreach dhcp-srv-unreach fo-trigger fb-trigger du-trigger ssp-missing dns-pool-exceed lsa-fo-trigger reg-domainname-sec reg-auth-sec reg-timeout-sec reg-srvfailresp-sec inv-domainname-sec inv-auth-sec inv-timeout-sec inv-srvfailresp-sec subs-srvfailresp-sec subs-domainname-sec subs-auth-sec subs-refreshfail-sec subs-inittimeout-sec emergency-call-sec fanout	

Parameter	Type	Description
	up-overflow upobc-overflow dwobc-overflow dw-overflow lwpri-overflow queue-drop queue-load queue-peak-usage mgc-unreachable failover-to-esamgc sgc-unreachable lcard-unreach-srvcard lcard-type-mismatch meg-unknown-sub meg-ground-key meg-high-temp meg-act-fail meg-over-current line-showering low-qos-packetloss low-qos-jitter low-qos-delay sig-brd-persist-loss sig-brd-disk-full sig-brd-db-rollback mg-overload meg-unknown-sub-sec line-showering-sec loss-env-mon etca-los etca-fcs etca-day-los etca-day-fcs etca-rx-octets etca-tx-octets etca-day-rx-octets etca-day-tx-octets user-sfp-los user-sfp-tx-fail user-sfp-not-prst user-sfp-inv-id user-sfp-t-exceed user-sfp-mismatch uplink-sfp-los uplink-sfp-tx-fail uplink-sfp-not-prst uplink-sfp-inv-id uplink-sfp-t-exceed uplink-sfp-mismatch loss-lmswp-cap inv-xvps-pair-data network-power-loss hw-fault bat-miss bat-fail bat-low bat-a-fail	

3 Alarm Configuration Commands

Parameter	Type	Description
	bat-b-fail ac-vol-out-range network-power-loss-b sem-ac-power-fail sem-ups-low-volt dc-a-fail dc-b-fail plan-power-mismatch water-seepage-in-box sealed-box-open dc-a-vol-out-range dc-b-vol-out-range inlet-temp-major inlet-temp-critical psu-fail-crit psu-a-fail-presence psu-a-fail-vin-ac-nok psu-a-fail-vin-uv psu-a-fail-vin-ov psu-a-fail-vout-uv psu-a-fail-vout-ov psu-a-fail-iout-oc psu-a-fail-overtemp psu-b-fail-presence psu-b-fail-vin-ac-nok psu-b-fail-vin-uv psu-b-fail-vin-ov psu-b-fail-vout-uv psu-b-fail-vout-ov psu-b-fail-iout-oc psu-b-fail-overtemp synce-fail bits-fail bits-output-shutoff ieee1588-fail gnss-fail ieee1588-hybrid-fail signal-loss signal-efd esmc-loss bits-output-exceed ql-input-exceed holdover lti tod-reference-fail internal-clk-fail bgp-peer-down bgp-routes-mid-limit isis-adjacency-down isis-adjacency-reject isis-instance-down ospf-lsa-limit ospf-lsa-mid-limit ospf-neighbor-down ospf-instance-down ospf3-lsa-limit ospf3-lsa-mid-limit	

Parameter	Type	Description
	ospf3-neighbor-down ospf3-instance-down rip-instance-down lag-down lagsubgrp-thresh-reach lagsubgrp-switch-fail no-unpinned-free-ports general-arp-limit gen-switch-out-of-res ipv6-nc-limit dhcp-session-oor ihub-fdb-limit ihub-mac-limit l2fw-stp-exception l2fw-stp-root-guard vprn-routes-limit vprn-ipv6-routes-limit dhcpv6-lease-limit dhcpv4-lease-limit vpls-mfib-limit ihub-ipv6-dad-own ihub-ipv6-dad ihub-ipv6-dup-pd-route vpls-duplicate-mac vpls-fdb-limit vpls-self-duplic-mac vpls-sdp-self-dup-mac link-down link-lagport-add-fail link-conf-mismatch ihub-peer-comm ihub-sw-fail ihub-hw-fail ihub-link-fail ihub-proc-overload ihub-out-of-mem ntp-comm-lost ldp-instance-down ldp-session-down mpls-instance-down mpls-lsp-down mpls-lsp-path-down sdp-instance-down sdp-binding-down epipe-instance-down lldpmed-portcfg-mis lldpmed-mediapl-mis vlanport-svc-mismatch mcsrc-stream-lost eqptsupl-syslog-upload eqptsupl-ontsw-dnload cf-75%used cf-90%used olt-gen-pon-com-fail olt-gen-tx-fail olt-gen-unprov-ont olt-gen-pon-eqpt-prov	

3 Alarm Configuration Commands

Parameter	Type	Description
	olt-gen-pon-loss-sig olt-gen-pon-diagnostic olt-gen-loid-conflict olt-gen-loid-pwderr olt-gen-pon-alien-test olt-gen-alien-detect olt-gen-rng-mism olt-gen-sfp-mism olt-gen-deact-hightca olt-gen-deact-lowtca olt-gen-dp-integ olt-gen-ddr-fault olt-pon-tc-err-frag-tc olt-ont-tc-err-frag-tc ont-ploam-loss-sig ont-ploam-loss-ack ont-ploam-loss-cd ont-ploam-phy-eqpt-err ont-ploam-startup-fail ont-ploam-sig-degrade ont-ploam-disabled ont-ploam-err-msg ont-ploam-inactive ont-ploam-sig-fail ont-ploam-dying-gasp ont-ploam-deact-fail ont-ploam-oam ont-ploam-win-drift ont-ploam-rdi ont-ploam-loss-ks ont-ploam-pwr-burst ont-ploam-rog-disa ont-ploam-diff-reach ont-ploam-looc sfu-ploam-loss-sig sfu-ploam-loss-ack sfu-ploam-loss-cd sfu-ploam-phy-eqpt-err sfu-ploam-startup-fail sfu-ploam-sig-degrade sfu-ploam-disabled sfu-ploam-err-msg sfu-ploam-inactive sfu-ploam-sig-fail sfu-ploam-dying-gasp sfu-ploam-deact-fail sfu-ploam-oam sfu-ploam-win-drift sfu-ploam-rdi sfu-ploam-loss-ks sfu-ploam-pwr-burst sfu-ploam-rog-disa sfu-ploam-diff-reach sfu-ploam-looc soho-ploam-loss-sig soho-ploam-loss-ack soho-ploam-loss-cd	

Parameter	Type	Description
	soho-ploam-phy-eqpt-er	
	soho-ploam-startup-fai	
	soho-ploam-sig-degrade	
	soho-ploam-disabled	
	soho-ploam-err-msg	
	soho-ploam-inactive	
	soho-ploam-sig-fail	
	soho-ploam-dying-gasp	
	soho-ploam-deact-fail	
	soho-ploam-oam	
	soho-ploam-win-drift	
	soho-ploam-rdi	
	soho-ploam-loss-ks	
	soho-ploam-pwr-burst	
	soho-ploam-roq-disa	
	soho-ploam-diff-reach	
	soho-ploam-looc	
	mdu-ploam-loss-sig	
	mdu-ploam-loss-ack	
	mdu-ploam-loss-cd	
	mdu-ploam-phy-eqpt-err	
	mdu-ploam-startup-fail	
	mdu-ploam-sig-degrade	
	mdu-ploam-disabled	
	mdu-ploam-err-msg	
	mdu-ploam-inactive	
	mdu-ploam-sig-fail	
	mdu-ploam-dying-gasp	
	mdu-ploam-deact-fail	
	mdu-ploam-oam	
	mdu-ploam-win-drift	
	mdu-ploam-rdi	
	mdu-ploam-loss-ks	
	mdu-ploam-pwr-burst	
	mdu-ploam-roq-disa	
	mdu-ploam-diff-reach	
	mdu-ploam-looc	
	ont-hpna-ser-mis	
	ont-hpna-los-sig	
	ont-moca-svc-mis	
	ont-moca-link-los	
	ont-moca-min-bw	
	ont-moca-tca-rx-err-fr	
	ont-sipa-reg-nm-fail	
	ont-sipa-reg-rec-fail	
	ont-sipa-reg-con-fail	
	ont-sipa-reg-val-fail	
	ont-sipa-reg-mis	
	ont-vcd-cfg-nm-fail	
	ont-vcd-cfg-rech-fail	
	ont-vcd-cfg-conn-fail	
	ont-vcd-cfg-vali-fail	
	ont-vcd-cfg-auth-fail	
	ont-vcd-cfg-resp-tmout	
	ont-vcd-cfg-resp-err	
	ont-vcd-cfg-file-err	
	ont-vcd-sub-nm-fail	

3 Alarm Configuration Commands

Parameter	Type	Description
	ont-vcd-sub-rech-fail ont-vcd-sub-conn-fail ont-vcd-sub-vali-fail ont-vcd-sub-auth-fail ont-vcd-sub-resp-tmout ont-vcd-sub-resp-err ont-vcd-reb-requ ont-vcd-mis ont-mgc-mis ont-mgc-timeout ont-sip-reg-dns ont-sip-reg-fail ont-sip-reg-timeout ont-sip-reg-err-resps ont-sip-inv-dns ont-sip-inv-auth ont-sip-inv-timeout ont-sip-inv-err ont-svc-pots-subs-refr ont-svc-pots-not-refr ont-svc-pots-icfg-err ont-veip-mismatch ont-ip-host-mismatch ont-ip-host-file ont-ip-host-ip-alloc olt-pon-up-bw-tca olt-pon-down-bw-tca ont-gen-omci-fail ont-gen-eqpt-selftest ont-gen-ac-pwr-fail ont-gen-bat-missing ont-gen-bat-low ont-gen-bat-fail ont-gen-phys-intrusion ont-gen-sw-dnload-f ont-gen-sw-dnload-p ont-gen-sw-act-fail ont-gen-eqpt-vers-mis ont-gen-sw-vers-mis ont-gen-us-rate-mis ont-gen-mdu-env1 ont-gen-mdu-env2 ont-gen-mdu-env3 ont-gen-nw-time-err ont-gen-opt-sig-high ont-gen-opt-sig-low ont-gen-eqpt-prov-sa ont-gen-eqpt-prov-nsa pon-t-txmcutilhi pon-t-txmcutilmd pon-t-txmcutillo pon-t-txtotutilhi pon-t-txtotutilmd pon-t-txtotutillo pon-t-rxtotutilhi pon-t-rxtotutilmd pon-t-rxtotutillo	

Parameter	Type	Description
	pon-t-dbacongperiodhi pon-t-dbacongperiodmd pon-t-dbacongperiodlo pon-t-txucdropfrmhi pon-t-txucdropfrmmd pon-t-txucdropfrmlo pon-t-txmcdropfrmhi pon-t-txmcdropfrmmd pon-t-txmcdropfrmlo pon-t-txbcdropfrmhi pon-t-txbcdropfrmmd pon-t-txbcdropfrmlo pon-t-rxtotdropfrmhi pon-t-rxtotdropfrmmd pon-t-rxtotdropfrmlo chpr-t-txmcutilhi chpr-t-txmcutilmd chpr-t-txmcutillo chpr-t-txtotutilhi chpr-t-txtotutilmd chpr-t-txtotutillo chpr-t-rxtotutilhi chpr-t-rxtotutilmd chpr-t-rxtotutillo chpr-t-dbacongperiodhi chpr-t-dbacongperiodmd chpr-t-dbacongperiodlo chpr-t-txucdropfrmhi chpr-t-txucdropfrmmd chpr-t-txucdropfrmlo chpr-t-txmcdropfrmhi chpr-t-txmcdropfrmmd chpr-t-txmcdropfrmlo chpr-t-txbcdropfrmhi chpr-t-txbcdropfrmmd chpr-t-txbcdropfrmlo chpr-t-rxtotdropfrmhi chpr-t-rxtotdropfrmmd chpr-t-rxtotdropfrmlo sfu-gen-omci-fail sfu-gen-eqpt-selftest sfu-gen-ac-pwr-fail sfu-gen-bat-missing sfu-gen-bat-low sfu-gen-bat-fail sfu-gen-sw-dnload-f sfu-gen-sw-dnload-p sfu-gen-sw-act-fail sfu-gen-eqpt-vers-mis sfu-gen-sw-vers-mis sfu-gen-us-rate-mis sfu-gen-tune-fail sfu-gen-nw-time-err sfu-gen-opt-sig-high sfu-gen-opt-sig-low sfu-gen-eqpt-prov-sa sfu-gen-eqpt-prov-nsa	

3 Alarm Configuration Commands

Parameter	Type	Description
	soho-gen-omci-fail soho-gen-eqpt-selftest soho-gen-ac-pwr-fail soho-gen-bat-missing soho-gen-bat-low soho-gen-bat-fail soho-gen-sw-dnload-f soho-gen-sw-dnload-p soho-gen-sw-act-fail soho-gen-eqpt-vers-mis soho-gen-sw-vers-mis soho-gen-us-rate-mis soho-gen-tune-fail soho-gen-nw-time-err soho-gen-opt-sig-high soho-gen-opt-sig-low soho-gen-eqpt-prov-sa soho-gen-eqpt-prov-nsa mdu-gen-omci-fail mdu-gen-eqpt-selftest mdu-gen-ac-pwr-fail mdu-gen-bat-missing mdu-gen-bat-low mdu-gen-bat-fail mdu-gen-phys-intrusion mdu-gen-sw-dnload-f mdu-gen-sw-dnload-p mdu-gen-sw-act-fail mdu-gen-eqpt-vers-mis mdu-gen-sw-vers-mis mdu-gen-us-rate-mis mdu-gen-tune-fail mdu-gen-mdu-env1 mdu-gen-mdu-env2 mdu-gen-mdu-env3 mdu-gen-nw-time-err mdu-gen-opt-sig-high mdu-gen-opt-sig-low mdu-gen-eqpt-prov-sa mdu-gen-eqpt-prov-nsa ont-gen-sw-dnload-file ont-gen-fan-fail ont-gen-high-temp ont-gen-high-temp-ex ont-gen-emergency-call ont-gen-sw-version ont-poe-exceed-max ont-poe-overload-yell ont-opti-malfunc ont-gen-cfgdld-fail ont-gen-rssi-mis ont-gen-tx-pwr-low ont-gen-temp-high ont-gen-volt-high ont-gen-bias-high ont-loopdetect-mis ont-olt-rx-pw-lo	

Parameter	Type	Description
	ont-olt-rx-pw-hig ont-olt-rx-pw-warnlo ont-olt-rx-pw-warnhig ont-gen-tod-out-sync ont-gen-tune-fail hgu-tr069-parm-fail ont-gen-tod-mismatch sfu-sup-sw-file-error sfu-sup-fan-failure sfu-sup-temp-high-warn sfu-sup-temp-shutoff sfu-sup-emergency-call sfu-sup-swverctrl-err sfu-sup-poe-exceed-max sfu-sup-poe-over-yell sfu-opti-malfunc sfu-sup-cfg-dnld-fail sfu-sup-rssi-cfg-mism sfu-sup-sfp-tx-low sfu-sup-sfp-temp-high sfu-sup-sfp-volt-high sfu-sup-sfp-bias-high sfu-sup-ld-cfg-mism sfu-sup-olt-rx-low sfu-sup-olt-rx-high sfu-sup-olt-rx-lo-warn sfu-sup-olt-rx-hi-warn sfu-sup-tod-out-sync sfu-sup-ont-tune-fail sfu-tr069-parm-fail sfu-sup-tod-mismatch soho-sup-sw-file-error soho-sup-fan-failure soho-sup-temp-high-war soho-sup-temp-shutoff soho-sup-emergency-cal soho-sup-swverctrl-err soho-sup-poe-exceed-ma soho-sup-poe-over-yell soho-opti-malfunc soho-sup-cfg-dnld-fail soho-sup-rssi-cfg-mism soho-sup-sfp-tx-low soho-sup-sfp-temp-high soho-sup-sfp-volt-high soho-sup-sfp-bias-high soho-sup-ld-cfg-mism soho-sup-olt-rx-low soho-sup-olt-rx-high soho-sup-olt-rx-lo-war soho-sup-olt-rx-hi-war soho-sup-tod-out-sync soho-sup-ont-tune-fail soho-tr069-parm-fail soho-sup-tod-mismatch mdu-sup-sw-file-error mdu-sup-fan-failure	

3 Alarm Configuration Commands

Parameter	Type	Description
	mdu-sup-temp-high-warn mdu-sup-temp-shutoff mdu-sup-emergency-call mdu-sup-swverctrl-err mdu-sup-poe-exceed-max mdu-sup-poe-over-yell mdu-opti-malfunc mdu-sup-cfg-dnld-fail mdu-sup-rssi-cfg-mism mdu-sup-sfp-tx-low mdu-sup-sfp-temp-high mdu-sup-sfp-volt-high mdu-sup-sfp-bias-high mdu-sup-ld-cfg-mism mdu-sup-olt-rx-low mdu-sup-olt-rx-high mdu-sup-olt-rx-lo-warn mdu-sup-olt-rx-hi-warn mdu-sup-tod-out-sync mdu-sup-ont-tune-fail mdu-tr069-parm-fail mdu-sup-tod-mismatch ont-sbscr-lim-missing ont-sbscr-lim-type-mis ont-sbscr-lim-removal ont-sbscr-lim-fail ont-sbscr-lim-svc-mis ont-sbscr-lim-port-mis ont-svc-video-conf-mis ont-svc-video-pw-high ont-svc-video-pw-low ont-svc-pots-svc-mis ont-svc-pots-rtcp-lost ont-svc-pots-icnf-subs ont-svc-pots-icnf-ntfy ont-svc-pots-icnf-http ont-svc-pots-sip-reg ont-svc-pots-sip-inv ont-svc-pots-sip-subsc ont-svc-pots-sip-mt-tc ont-svc-pots-pk-los-tc ont-svc-pots-jitter-tc ont-svc-pots-subs-dns ont-svc-pots-subs-tcp ont-svc-pots-subs-tls ont-svc-pots-subs-auth ont-svc-pots-subs-to ont-svc-pots-subs-err ont-svc-pots-not-to ont-svc-pots-notref-to ont-svc-pots-not-mal ont-svc-pots-not-rej ont-svc-pots-http-dns ont-svc-pots-http-tcp ont-svc-pots-http-tls ont-svc-pots-http-auth ont-svc-pots-http-to	

Parameter	Type	Description
	ont-svc-pots-http-err ont-svc-pots-http-mal ont-svc-pots-insuff ont-svc-pots-poos ont-svc-lan-mismatch ont-svc-lan-loss-sig ont-svc-enet-poos ont-svc-ces-ds1-mis ont-svc-ces-ds1-los ont-svc-ces-ds1-lof ont-svc-ces-ds1-rair ont-svc-ces-ds1-ais ont-svc-ces-ds1-lnlpbk ont-svc-ces-ds1-tmlpbk ont-svc-ces-e1-mis ont-svc-ces-e1-los ont-svc-ces-e1-lof ont-svc-ces-e1-rair ont-svc-ces-e1-ais ont-svc-voip-cnf-file ont-svc-voip-svc-mis ont-svc-voip-gw-comm ont-svc-voip-dhcp-fail ont-svc-voip-icnf-sub ont-svc-voip-icnf-ntfy ont-svc-voip-icnf-http ont-svc-voip-dhcp-to ont-svc-voip-dhcp-mal ont-svc-voip-dhcp-noad ont-svc-voip-dhcp-leas ont-svc-voip-sub-dns ont-svc-voip-sub-tcp ont-svc-voip-sub-tls ont-svc-voip-sub-auth ont-svc-voip-sub-to ont-svc-voip-sub-err ont-svc-voip-not-to ont-svc-voip-notref-to ont-svc-voip-not-mal ont-svc-voip-not-rej ont-svc-voip-http-dns ont-svc-voip-http-tcp ont-svc-voip-http-tls ont-svc-voip-http-auth ont-svc-voip-http-to ont-svc-voip-http-err ont-svc-voip-http-mal ont-svc-voip-sub-refr ont-svc-voip-not-refr ont-svc-voip-icfg-err ont-svc-v-ani-conf-mis ont-svc-v-ani-loss-sig ont-svc-v-ani-lv-high ont-svc-v-ani-lv-low ont-svc-pwe-mismatch ont-svc-pwe-reordr-lof ont-svc-pwe-jitt-buf-o	

3 Alarm Configuration Commands

Parameter	Type	Description
	ont-svc-pwe-jitt-buf-u ont-svc-pwe-malf-frms ont-svc-pwe-late-frms ont-svc-pwe-link-loss ont-svc-pwe-arp-fail ont-svc-xdsl-mismatch ont-svc-xdsl-ne-lof ont-svc-xdsl-ne-los ont-svc-xdsl-ne-line ont-svc-xdsl-ne-lol ont-svc-xdsl-fe-lof ont-svc-xdsl-fe-los ont-svc-xdsl-fe-lop ont-svc-xdsl-cnfr-err ont-svc-xdsl-ne-es-tc ont-svc-xdsl-ne-ses-tc ont-svc-xdsl-ne-uas-tc ont-svc-xdsl-fe-es-tc ont-svc-xdsl-fe-ses-tc ont-svc-xdsl-fe-uas-tc ont-tc-rx-los-frag-tc ont-tc-tx-los-frag-tc ont-tc-bad-gem-hd-tc ont-uni-ds-drpdr-fr-tc ont-uni-up-drpdr-fr-tc ont-uni-ds-crc-fr-tc ont-uni-up-crc-fr-tc ont-cpu-util-tca ont-mem-util-tca pim-neighbor-down pim-max-mcroutes li-traffic-disabled li-bandwidth-limit li-out-of-res otdr-cap-mismatch login-successful login-failure cfm-defrdiccm cfm-defmacstatus cfm-defremoteccm cfm-deferrorccm cfm-defxconccm cfm-defais bfd-session-down bfd-max-resource bfd-stale-entry tca-outputbw tca-inputbw tca-rxcrcalign tca-txcrcalign tca-txcollisions tca-outpuhighbw tca-outputmedbw tca-outputlowbw tca-inpuhighbw tca-inputmediumbw tca-inputlowbw	

Parameter	Type	Description
	eth-cfm-defrdiccm eth-cfm-defmacstatus eth-cfm-defremoteccm eth-cfm-deferrorccm eth-cfm-defxconccm rsvp-neighbor-down rsvp-instance-down eth-ring-path-block ai-platform-down ai-appl-install-fail ip-assign-fail ont-tr069-serv-mis ont-snmp-mis bsf-dhcpv4 bsf-dhcpv6 bsf-pon bsf-vbridge bsf-qos bsf-igmp bsf-lxfwd prot-not-available prot-switchover-fail efm-oam-cpelinkfault efm-oam-cpedyinggasp efm-oam-cpecrevt ont-loopdetect alarm-tbl-overflow auto-switch-status auswqueuefullatm auswbkpfailatm auswrecfgfailatm auswdataunatm auswqueuefulptm auswbkpfailptm auswrecfgfailptm auswdataunptm auswbakpfailatm chpr-com-fail chpr-tx-fail chpr-unprov-ont chpr-prov-mismatch chpr-loss-sig chpr-diagnostic chpr-loid-conflict chpr-loid-pwd-err chpr-stk-laser-dis chpr-sfp-mismatch chpr-rng-mismatch chpr-alien-test chpr-alien-detect chpr-deact-hightca chpr-deact-lowtca chpr-dp-integ olt-chpr-tc-err-frag olt-chpr-up-bw-tca olt-chpr-down-bw-tca cfg-dld-fail	

3 Alarm Configuration Commands

Parameter	Type	Description
	cfg-act-fail cfg-dld-ip cfg-ver-mismatch cfg-file-missing cfg-verctrl-err cfg-not-supported ont-prot-not-available ont-gen-temp-low ont-gen-volt-low ont-gen-tx-pwr-high ont-gen-bias-low ont-gen-rx-hwarn ont-gen-rx-lwarn ont-gen-tx-hwarn ont-gen-tx-lwarn ont-gen-temp-hwarn ont-gen-temp-lwarn ont-gen-volt-hwarn ont-gen-volt-lwarn ont-gen-bias-hwarn ont-gen-bias-lwarn sfu-sup2-temp-low sfu-sup2-volt-low sfu-sup2-tx-high sfu-sup2-bias-low sfu-sup2-rx-hwarn sfu-sup2-rx-lwarn sfu-sup2-tx-hwarn sfu-sup2-tx-lwarn sfu-sup2-temp-hwarn sfu-sup2-temp-lwarn sfu-sup2-volt-hwarn sfu-sup2-volt-lwarn sfu-sup2-bias-hwarn sfu-sup2-bias-lwarn soho-sup2-temp-low soho-sup2-volt-low soho-sup2-tx-high soho-sup2-bias-low soho-sup2-rx-hwarn soho-sup2-rx-lwarn soho-sup2-tx-hwarn soho-sup2-tx-lwarn soho-sup2-temp-hwarn soho-sup2-temp-lwarn soho-sup2-volt-hwarn soho-sup2-volt-lwarn soho-sup2-bias-hwarn soho-sup2-bias-lwarn mdu-sup2-temp-low mdu-sup2-volt-low mdu-sup2-tx-high mdu-sup2-bias-low mdu-sup2-rx-hwarn mdu-sup2-rx-lwarn mdu-sup2-tx-hwarn mdu-sup2-tx-lwarn	

Parameter	Type	Description
	mdu-sup2-temp-hwarn mdu-sup2-temp-lwarn mdu-sup2-volt-hwarn mdu-sup2-volt-lwarn mdu-sup2-bias-hwarn mdu-sup2-bias-lwarn cust-alm1 cust-alm2 cust-alm3 cust-alm4 cust-alm5 cust-alm6 cust-alm7 cust-alm8 cust-alm9 cust-alm10 cust-alm11 cust-alm12 cust-alm13 cust-alm14 cust-alm15 cust-alm16 cust-alm17 cust-alm18 cust-alm19 cust-alm20 cust-alm21 cust-alm22 cust-alm23 cust-alm24 cust-alm25 cust-alm26 cust-alm27 cust-alm28 cust-alm29 cust-alm30 cust-alm31 ethernet-ring-pthfwt ethernet-ring-fop-to ethernet-ring-fop-pm fpm-depletion exp-seizureack exp-disconack exp-forcerelack packet-loss remote-packet-loss no-dsp-resource la-down la-standby-na la-switch-fail la-degrade melt-board-reset board-shelf-mismatch fcs-thresh-exceed) Possible values: - all : all alarms for query - xtca-ne-es : errored seconds in 15 min	

3 Alarm Configuration Commands

Parameter	Type	Description
	- xtca-ne-ses : severely errored seconds in 15 min - xtca-ne-uas : unavailable seconds in 15 min - xtca-ne-day-es : errored seconds in 1 day - xtca-ne-day-ses : severely errored seconds in 1 day - xtca-ne-day-uas : unavailable seconds in 1 day - xtca-fe-es : errored seconds in 15 min - xtca-fe-ses : severely errored secs in 15 min - xtca-fe-uas : unavailable seconds in 15 min - xtca-fe-day-es : errored seconds in 1 day - xtca-fe-day-ses : severely errored secs in 1 day - xtca-fe-day-uas : unavailable seconds in 1 day - xtca-leftrs : low error free throughput seconds in 15 min - xtca-day-leftrs : low error free throughput seconds in 1 day - xtca-fe-leftrs : far end low error free throughput seconds in 15 min - xtca-fe-day-leftrs : far end low error free throughput seconds in 1 day - xtca-auto-port-reset : auto-port-resets in 1 week - xtca-reinit : Reinitialization seconds in 15 min - xtca-day-reinit : Reinitialization seconds in 1 day - xdsl-ne-los : loss of signal - xdsl-ne-lof : loss of frame - xdsl-ne-lom : loss of margin - xdsl-ne-ese : excessive severe errors - xdsl-act-cfg-error : line configuration data cannot be used - xdsl-act-not-feas : line capacity not enough to setup requested profile - xdsl-up-br-reach : planned bitrate not reached after initialization - xdsl-ne-ncd : no cell delineation - xdsl-ne-lcd : loss of cell delineation - xdsl-fe-los : loss of signal - xdsl-fe-lof : loss of frame - xdsl-fe-lpr : loss of power - xdsl-fe-lol : loss of link - xdsl-fe-lom : loss of margin - xdsl-fe-ese : excessive severe errors - xdsl-fe-upbo-vio : upbo violation - xdsl-fe-cpe-pol : activation failure cpe policing - xdsl-tpstc-mis : mismatch between the configured tps-tc mode and the mode supported by the connected cpe - xdsl-act-comm : init not successful due to communications problem - xdsl-act-modem : no peer modem detected - xdsl-do-br-reach : planned bitrate not reached after init - xdsl-fe-ncd : no cell delineation - xdsl-fe-lcd : loss of cell delineation - xdsl-frtx-init-fail : init not successful due to forced rtx - xdsl-vect-dle : vectoring disorderly leaving event - xdsl-fe-mis-peer-35b : VDSL2 35b opmode mismatch between XTU-C and XTU-R - vectline-xtc-var-vict : excessive victim crosstalk coefficients variation - vectline-xtc-var-dist : excessive disturber crosstalk coefficients variation - vectline-corp-errf : corrupted or missing errorf-samples - vect-cpe-cap-mismatch : not allowed Vectoring CPE	

Parameter	Type	Description
	connected - vectline-conf_notfeas : vect line configuration not feasible - vect-vp-lt-mismatch : actual vp-lt connection(s) do not match expected vp-lt connection(s) or vp-lt connection lost - vect-inv-qsfp : qsfp has no valid Nokia ID - vect-vp-lt-fail : vp-lt connection not operational - vect-no-gain-at-init : Lines cannot train in gain-at-init mode - sw-rollback : non active oswp,db cannot be operational - will rollback - db-rollback : selected oswp,db cannot be operational - will rollback - xvps-inv-dbase : invalid xvps dbase - inv-cde-file : invalid xvps cde file - miss-cde-file : missing cde profile - cde-hash-error : cde profile hash error - low-disk-space : insufficient space for Sw storage - cell-discard-up : cell discarded in the upstream direction - cell-discard-down : cell discarded in the downstream direction - persist-data-loss : all data lost after restart - system not configured - mac-conflict : duplicate mac address on the bridge port - vmac-full : virtual mac address is full on the bridge port - sntp-comm-lost : sntp server not responding - preferred-mode : preferred mode not available - timing-reference : timing reference failure - nt-disk-95%full : nt disk 95% full - shub-loc : communication lost with shub - cf-error : compact flash access error - back-pnl-inv : BackPanel-type Invalid - ihub-conf-loss : iHub configuration loss - recent changes lost - rack-power : power fuse broken - rack-fan-unit1 : fan unit rack 1 failing - rack-fan-unit2 : fan unit rack 2 failing - shelf-mismatch : shelf type different from planned type - shelf-missing : detected shelf no longer detected - shelf-install-missing : shelf planned but not installed - door : open cabinet door - ac-power-fail : external power failure - shelf shutdown in 15 minutes - board-mismatch : board inserted different from planned - waiting-for-sw : not able to download all the applicable sw files - temp-exceeded : temperature threshold exceeded on the board - backplane-data-failure: lt port on backplane data failure - temp-shutdown : board powered down itself - too high temperature - board-missing : board detected after planning - now missing - board-instl-missing : board never detected after planning - board-init : board initialisation failure - board-reset-prot : number of resets exceeded - sem-power-fail : SEM external power failure - sem-ups-fail : SEM external power supply failure	

3 Alarm Configuration Commands

Parameter	Type	Description
	- board-reset-cf : board reset and/or communication failure - vlan-assign-fail : failure to assign VLAN for a user session - vsa-info-invalid : radius fail to assign a valid vsa to a user session - auth-mac-conflict : failure to check mac conflict for a user session - user-pwd-fault : failure to check user or password of a user session - up-plan-bitrate : upstream bitrate is above min and below planned - up-min-bitrate : upstream bitrate is below min bitrate - up-config-not-feas : upstream bitrate is not enough to set up config group - down-plan-bitrate : downstream bitrate is above min and below planned - down-min-bitrate : downstream bitrate is below min bitrate - down-config-not-feas : downstream bitrate is not enough to set up config group - non-bonding-cpe : no bonding cpe modem is connected - multiple-cpes : bonding group has multiple cpe modems connected - register : bonding group discovery or aggregation register failure - group-incomplete : bonding group is incomplete - host-sfp-los : loss of signal - host-sfp-tx-fail : Tx failure - host-sfp-not-prst : not present - host-sfp-inv-id : no valid Nokia ID - host-sfp-ctrl-fail : control failure - host-sfp-rmtlt : unexpected remote plug-in - host-sfp-mismatch : assignment does not match reported rack/shelf/slot - host-sfp-incompt : incompatible shelf type detected - exp-sfp-los : expansion side loss of signal - exp-sfp-tx-fail : Tx failure - exp-sfp-not-prst : not present - exp-sfp-inv-id : no valid Nokia ID - exp-sfp-ctrl-fail : control failure - exp-sfp-1-los : expansion side sfp1 loss of signal - exp-sfp-2-los : expansion side sfp2 loss of signal - ext-qsfp-invld : Invalid Nokia ID - tx-power-high-alarm : tx power more than alarm range - tx-power-low-alarm : tx power less than alarm range - rx-power-high-alarm : rx power more than alarm range - rx-power-low-alarm : rx power less than alarm range - tx-biascur-high-alarm : tx bias current high alarm - tx-biascur-low-alarm : tx bias current low alarm - volt-high-alarm : voltage high alarm - volt-low-alarm : voltage low alarm - temp-high-alarm : temperature high alarm - temp-low-alarm : temperature low alarm - tx-power-high-warn : tx power more than warn range - tx-power-low-warn : tx power less than warn range - rx-power-high-warn : rx power more than warn range - rx-power-low-warn : rx power less than warn range - tx-biascur-high-warn : tx bias current high warn - tx-biascur-low-warn : tx bias current low warn	

Parameter	Type	Description
	- volt-high-warn : voltage high warn - volt-low-warn : voltage low warn - temp-high-warn : temperature high warn - temp-low-warn : temperature low warn - onu-unprovisioned : unprovisioned ont - signal-loss : pon loss of signal - bitrate-high : the error bit rate high at pon interface - opmodule-mismatch : the optical module mismatched at pon interface - key-fail-one-churn : key exchange failure during one churning time - key-fail-three-churn : key exchange failure during three churning time - oam-discov-fail : extend oam discovery failure - report-timeout : report timeout detecting - total-packets-exceed : total amount of protocol packets exceed threshold - arp-packets-exceed : protocol arp packets exceed threshold - dhcp-packets-exceed : protocol dhcp packets exceed threshold - igmp-packets-exceed : protocol igmp packets exceed threshold - pppoe-packets-exceed : protocol pppoe packets exceed threshold - nd-packets-exceed : protocol nd packets exceed threshold - icmpv6-packets-exceed : protocol icmpv6 packets exceed threshold - mld-packets-exceed : protocol mld packets exceed threshold - dhcpv6-packets-exceed : protocol dhcpv6 packets exceed threshold - cfm-packets-exceed : protocol cfm packets exceed threshold - dsx1-serdes-fail : SERDES clock alarm failure - dsx1-tributary1-fail : The tributary 1 clock is not present - dsx1-tributary2-fail : The tributary 2 clock is not present - dsx1-los-fail : All the selected tribs in Loss of Signal - dsx1-ais-sync : Alarm Indication signal on the tributary selected as sync source - dsx1-lof-sync : Loss of Framing on the tributary selected as sync source - dsx1-los-sync : Loss of signal on the tributary selected as sync source - dsx1-deg-fail : Signal degrade Alarm - dsx1-rei-from-liu : Remote Error Indication alarm from LIU - dsx1-rdi-from-liu : Remote Defect Alarm from LIU - dsx1-crc6-from-liu : Cyclic Redundancy check-6 alarm from LIU - dsx1-crc4-from-liu : Cyclic Redundancy check-4 alarm from LIU - dsx1-crc4-th-from-liu : Cyclic Redundancy check-4 threshold alarm from LIU - dsx1-ais-from-liu : Alarm Indication Signal alarm from LIU - dsx1-los-from-liu : Loss of signal alarm from LIU - dsx1-lof-from-liu : Loss of framing alarm from LIU	

3 Alarm Configuration Commands

Parameter	Type	Description
	- dsx1-lomf-from-liu : Loss of Multi-frame alarm from LIU - dsx1-rei-from-iwf : Remote Error Indication alarm from IWF - dsx1-rdi-from-iwf : Remote Defect Alarm from IWF - dsx1-crc6-from-iwf : Cyclic Redundancy check-6 alarm from IWF - dsx1-crc4-from-iwf : Cyclic Redundancy check-4 alarm from IWF - dsx1-crc4-th-from-iwf : Cyclic Redundancy check-4 threshold alarm from IWF - dsx1-ais-from-iwf : Alarm Indication Signal alarm from IWF - dsx1-los-from-iwf : Loss of signal alarm from IWF - dsx1-lof-from-iwf : Loss of framing alarm from IWF - dsx1-lomf-from-iwf : Loss of Multi-frame alarm from IWF - pppce-trans-15min-tca : 15 minutes transaction timeout count exceeds configured TCA - pppce-sess-15min-tca : 15 minutes session timeout count exceeds configured TCA - pppce-trans-1day-tca : 1day transaction timeout count exceeds configured TCA - pppce-sess-1day-tca : 1day session timeout count exceeds configured TCA - custom1 : customizable alarm 1 - custom2 : customizable alarm 2 - custom3 : customizable alarm 3 - custom4 : customizable alarm 4 - custom5 : customizable alarm 5 - he-custom1 : host expansion customizable alarm 1 - he-custom2 : host expansion customizable alarm 2 - he-custom3 : host expansion customizable alarm 3 - he-custom4 : host expansion customizable alarm 4 - he-custom5 : host expansion customizable alarm 5 - he-custom6 : host expansion customizable alarm 6 - custom6 : customizable alarm 6 - custom7 : customizable alarm 7 - custom8 : customizable alarm 8 - custom9 : customizable alarm 9 - custom10 : customizable alarm 10 - custom11 : customizable alarm 11 - custom12 : customizable alarm 12 - custom13 : customizable alarm 13 - custom14 : customizable alarm 14 - custom15 : customizable alarm 15 - custom16 : customizable alarm 16 - custom17 : customizable alarm 17 - loss-swo-cap : switch over capability in a redundant system - ping-check-fail : ping check in a redundant system - der-temp1 : Derived Alarm for Temporal Filter 1 - der-temp2 : Derived Alarm for Temporal Filter 2 - der-temp3 : Derived Alarm for Temporal Filter 3 - der-temp4 : Derived Alarm for Temporal Filter 4 - der-temp5 : Derived Alarm for Temporal Filter 5 - der-temp6 : Derived Alarm for Temporal Filter 6 - der-temp7 : Derived Alarm for Temporal Filter 7 - der-temp8 : Derived Alarm for Temporal Filter 8 - der-temp9 : Derived Alarm for Temporal Filter 9	

Parameter	Type	Description
	- der-temp10 : Derived Alarm for Temporal Filter 10 - der-temp11 : Derived Alarm for Temporal Filter 11 - der-temp12 : Derived Alarm for Temporal Filter 12 - der-temp13 : Derived Alarm for Temporal Filter 13 - der-temp14 : Derived Alarm for Temporal Filter 14 - der-temp15 : Derived Alarm for Temporal Filter 15 - der-temp16 : Derived Alarm for Temporal Filter 16 - der-temp17 : Derived Alarm for Temporal Filter 17 - der-temp18 : Derived Alarm for Temporal Filter 18 - der-temp19 : Derived Alarm for Temporal Filter 19 - der-temp20 : Derived Alarm for Temporal Filter 20 - der-temp21 : Derived Alarm for Temporal Filter 21 - der-temp22 : Derived Alarm for Temporal Filter 22 - der-temp23 : Derived Alarm for Temporal Filter 23 - der-temp24 : Derived Alarm for Temporal Filter 24 - der-temp25 : Derived Alarm for Temporal Filter 25 - der-temp26 : Derived Alarm for Temporal Filter 26 - der-temp27 : Derived Alarm for Temporal Filter 27 - der-temp28 : Derived Alarm for Temporal Filter 28 - der-temp29 : Derived Alarm for Temporal Filter 29 - der-temp30 : Derived Alarm for Temporal Filter 30 - der-temp31 : Derived Alarm for Temporal Filter 31 - der-spa1 : Derived Alarm for Spatial Filter 1 - der-spa2 : Derived Alarm for Spatial Filter 2 - der-spa3 : Derived Alarm for Spatial Filter 3 - der-spa4 : Derived Alarm for Spatial Filter 4 - der-spa5 : Derived Alarm for Spatial Filter 5 - der-spa6 : Derived Alarm for Spatial Filter 6 - der-spa7 : Derived Alarm for Spatial Filter 7 - der-spa8 : Derived Alarm for Spatial Filter 8 - der-spa9 : Derived Alarm for Spatial Filter 9 - der-spa10 : Derived Alarm for Spatial Filter 10 - der-spa11 : Derived Alarm for Spatial Filter 11 - der-spa12 : Derived Alarm for Spatial Filter 12 - der-spa13 : Derived Alarm for Spatial Filter 13 - der-spa14 : Derived Alarm for Spatial Filter 14 - der-spa15 : Derived Alarm for Spatial Filter 15 - der-spa16 : Derived Alarm for Spatial Filter 16 - der-spa17 : Derived Alarm for Spatial Filter 17 - der-spa18 : Derived Alarm for Spatial Filter 18 - der-spa19 : Derived Alarm for Spatial Filter 19 - der-spa20 : Derived Alarm for Spatial Filter 20 - der-spa21 : Derived Alarm for Spatial Filter 21 - der-spa22 : Derived Alarm for Spatial Filter 22 - der-spa23 : Derived Alarm for Spatial Filter 23 - der-spa24 : Derived Alarm for Spatial Filter 24 - der-spa25 : Derived Alarm for Spatial Filter 25 - der-spa26 : Derived Alarm for Spatial Filter 26 - der-spa27 : Derived Alarm for Spatial Filter 27 - der-spa28 : Derived Alarm for Spatial Filter 28 - der-spa29 : Derived Alarm for Spatial Filter 29 - der-spa30 : Derived Alarm for Spatial Filter 30 - der-spa31 : Derived Alarm for Spatial Filter 31 - apsf-alarm : Applique Power Supply Failure - custextalarm1 : Customizable External Alarm Number 1 - custextalarm2 : Customizable External Alarm Number 2 - custextalarm3 : Customizable External Alarm Number 3	

3 Alarm Configuration Commands

Parameter	Type	Description
	- custextalarm4 : Customizable External Alarm Number 4 - custextalarm5 : Customizable External Alarm Number 5 - pluginfan : REM Fan Alarm - plugin-dc-a : REM DC A Alarm - plugin-dc-b : REM DC B Alarm - plugin-dg : Dying Gasp Alarm - ntr-a-loss : NTR-A signal is not available - ntr-b-loss : NTR-B signal is not available - xvps-conf-loss : xvps configuration loss - mac-entry-nofree : no free mac entry in the mac table on lt board - fibre-conn-mismatch : REM Fibre Connection Mismatch Alarm - link-cap-mismatch : Link speed capability mismatch - eqpt-cap-mismatch : Link equipment capability mismatch - ctrl-dnld-failure : Controller card download failure - melt-hw-issue : MELT hardware issue - melt-board-reset : MELT board reset - board-shelf-mismatch : board type and shelf type mismatch - mgnt-type-mismatch : Board management type mismatch - fileserv-unavail : file transfer Server unavailable or file transfer failed - shdsl-n-loopback : loopback active at the network side - shdsl-c-loopback : loopback active at the customer side - shdsl-conferr : configuration error - shdsl-atm-lcd : loss of atm cell delineation - shdsl-lpr : loss of power at stu-r - shdsl-secu-err : unable to disable stu-r access - shdsl-dev-fault : device fault - shdsl-atm-ncd : no atm cell delineation - shdsl-n-losw : loss of sync word at the network side on each pair - shdsl-c-losw : loss of sync word at the customer side on each pair - shdsl-n-aten : loop attenuation alarm at the network side on each pair - shdsl-c-aten : loop attenuation alarm at the customer side on each pair - shdsl-n-snr : snr margin alarm at the network side each pair - shdsl-c-snr : snr margin alarm at the customer side on each pair - shdsl-n-dccont : dc continuity fault at the network side on each pair - shdsl-c-dccont : dc continuity fault at the customer side on each pair - shdsl-c-actfail : activation failure at the customer side on each pair - e1-fe-rai : Receiving Remote Alarm Indication - e1-ne-rai : Transmitting Remote Alarm Indication - e1-fe-ais : Receiving Alarm Indication Signal - e1-ne-ais : Transmitting Alarm Indication Signal - e1-lof : E1 Loss of frame - e1-los : E1 Loss of Signal - e1-loopback : E1 facility in loopback - ima-grp-fe-su : far-end starting up - ima-grp-fe-cfg : far-end failed configuration - ima-grp-ne-cfg : near-end failed configuration	

Parameter	Type	Description
	- ima-grp-fe-nl : insufficient number of links at far-end - ima-grp-ne-nl : insufficient number of links at near-end - ima-grp-fe-blk : far-end is blocked - ima-lnk-lif : loss of ima frame - ima-lnk-lods : link out of delay synchronization - ima-lnk-misc : link misconnect - ima-lnk-rfi : link remote failure indication - ima-lnk-fault : fault in link facility - ima-lnk-txblk : transmit blocked due to far-end - ima-lnk-rxblk : receive blocked due to far-end - bad-digitmap : Configured digitmap is unusable - dhcp-unreach : The DHCP server is unreachable - dhcp-no-srv : The address in DHCP reply is NULL - dhcp-inv-srv : The address in DHCP reply is invalid - norpniewithsoftdsp : do not plan / plug-in RPNI-E board with SoftDsp SW image - unknown-sub : subscriber exist in the POLT, but not in the appl server - ground-key : Return current to the ground - port-hightemp : Temperature threshold on user port exceeded. - port-jbfltca : JB fill level threshold on user port exceeded. - reg-domainname : Registration failure (resolving domain name). - reg-auth : Registration failure (authentication). - reg-timeout : Registration failure (message timeout). - reg-srvfailresp : Registration failure (failure response from server). - inv-domainname : Invitation failure (resolving domain name). - inv-auth : Invitation failure (authentication). - inv-timeout : Invitation failure (message timeout). - inv-srvfailresp : Invitation failure (failure response from server). - subs-srvfailresp : Subscribe failure (failure response from server). - subs-domainname : Subscribe failure (resolving domain name). - subs-auth : Subscribe failure (authentication). - subs-refreshfail : Subscribe failure (refresh failure). - subs-inittimeout : Subscribe failure (initial REQ timeout). - emergency-call : Emergency call for SIP POTS is ongoing. - e1sip-reg-domainname : E1 sip termination registration failure (resolving domain name). - e1sip-reg-auth : E1 sip termination registration failure (authentication). - e1sip-reg-timeout : E1 sip termination registration failure (message timeout). - e1sip-reg-srvfailresp : E1 sip termination registration failure (failure response from server). - e1sip-inv-domainname : E1 sip termination invitation failure (resolving domain name). - e1sip-inv-auth : E1 sip termination invitation failure (authentication). - e1sip-inv-timeout : E1 sip termination invitation failure (message timeout). - e1sip-inv-srvfailresp : E1 sip invitation failure (failure	

3 Alarm Configuration Commands

Parameter	Type	Description
	response from server). - e1sip-emergency-call : Emergency call for ISDN PRA/CAS R2 is ongoing. - e1itf-ais-signal : Alarm Indication Signal detected at E1 interface. - e1itf-los-signal : Loss Of Signal detected at E1 interface. - e1itf-rai-signal : Remote Alarm Indication detected at E1 interface. - e1sip-misconfig-mgc10 : Configuration not conform with the core network entity. - e1sip-nsmprf-missed : The SIP termination requires a NSM profile. - e1t1itf-recv-ais : Alarm Indication Signal received at interface. - e1t1itf-recv-los : Loss Of Signal received at interface. - e1t1itf-recv-rai : Remote Alarm Indication received at interface. - transport-mismatch : Transport protocol mismatch - dns-lookup-failure : Dns look up failure - none-dns-srv : No reply for all DNS serverd - no-dns-srv : No DNS servers configured - none-srv : No reply for all SIP First Hops - no-srv : No SIP First Hop configured - reg-srv-unreach : All SIP register servers are unreachable - proxy-srv-unreach : All SIP proxy servers are unreachable - dhcp-srv-unreach : The DHCP server is unreachable on this board - fo-trigger : Fail Over Triggered - fb-trigger : Fail Back Triggered - du-trigger : Deliberate Update Triggered - ssp-missing : SSP Missing in CDE - dns-pool-exceed : Number of different SG associated DNS pools exceed - lsa-fo-trigger : SIP voice service degraded - fail-over to LSA server - reg-domainname-sec : Registration failure (resolving domain name). - reg-auth-sec : Registration failure (authentication). - reg-timeout-sec : Registration failure (message timeout). - reg-srvfailresp-sec : Registration failure (failure response from server). - inv-domainname-sec : Invitation failure (resolving domain name). - inv-auth-sec : Invitation failure (authentication). - inv-timeout-sec : Invitation failure (message timeout). - inv-srvfailresp-sec : Invitation failure (failure response from server). - subs-srvfailresp-sec : Subscribe failure (failure response from server). - subs-domainname-sec : Subscribe failure (resolving domain name). - subs-auth-sec : Subscribe failure (authentication). - subs-refreshfail-sec : Subscribe failure (refresh failure). - subs-inittimeout-sec : Subscribe failure (initial REQ timeout). - emergency-call-sec : Emergency call for Secondary Termination is ongoing.	

Parameter	Type	Description
	- fanout : Lt load overflow - up-overflow : Upstream load overflow - upobc-overflow : Upstream load to OBC overflow - dwobc-overflow : Downstream load to OBC overflow - dw-overflow : Downstream load overflow - lwpri-overflow : The number of BE and CL pkts dropped exceed threshold - queue-drop : The number of pkts dropped by queue exceeds threshold - queue-load : The queue load exceeds threshold - queue-peak-usage : The queue peak usage exceeds threshold - mgc-unreachable : loss of contact with the media gateway controller - failover-to-esamgc : failover to esa mgc - sgc-unreachable : loss of contac with signaling gateway controller - lcard-unreach-srvcard : line card unreachable with server card - lcard-type-mismatch : associate board of wrong type - meg-unknown-sub : the megaco subscriber is unknown - meg-ground-key : voice port ground key - meg-high-temp : voice port high temperature - meg-act-fail : the first link layer for isdn subscriber activation failure - meg-over-current : voice port over current - line-showering : line showering - low-qos-packetloss : the total packet loss has exceeded the configured threshold - low-qos-jitter : the rtp jitter has exceeded the configured threshold - low-qos-delay : the rtp delay has exceeded the configured threshold - sig-brd-persist-loss : voice signaling board persistent data loss - sig-brd-disk-full : voice signaling board disk 90% full - sig-brd-db-rollback : voice signaling board db rollback - mg-overload : mg overload - meg-unknown-sub-sec : The Megaco subscriber exists in voice signaling board but not in media gateway controller. - line-showering-sec : A subscriber line exceeds 20 off-hook / on-hook events / minute. - loss-env-mon : env-monitor box lost or not alive - etca-los : loss of signal errors in 15 min - etca-fcs : frame check sequence errors in 15 min - etca-day-los : loss of signal errors in 1 day - etca-day-fcs : frame check sequence errors in 1 day - etca-rx-octets : received octets in 15 min - etca-tx-octets : transmitted octets in 15 min - etca-day-rx-octets : received octets in 1 day - etca-day-tx-octets : transmitted octets in 1 day - user-sfp-los : user sfp loss of signal - user-sfp-tx-fail : user sfp tx failure - user-sfp-not-prst : user sfp not detected - user-sfp-inv-id : user sfp invalid id - user-sfp-t-exceed : user sfp temperature exceed - user-sfp-mismatch : user sfp mismatch the configured type	

3 Alarm Configuration Commands

Parameter	Type	Description
	- uplink-sfp-los : uplink sfp loss of signal - uplink-sfp-tx-fail : uplink sfp tx failure - uplink-sfp-not-prst : uplink sfp not detected - uplink-sfp-inv-id : uplink sfp invalid id - uplink-sfp-t-exceed : uplink sfp temperature exceed - uplink-sfp-mismatch : uplink sfp mismatch the configured type - loss-lmswp-cap : lsm redundancy - inv-xvps-pair-data : invalid xvps pair redundancy data - network-power-loss : Loss of Network Power - hw-fault : Hardware Failure - bat-miss : Power Source Battery Missing - bat-fail : Power Source Battery Failure - bat-low : Power Source Battery Charge LOW - bat-a-fail : Power Source BAT-A Fail - bat-b-fail : Power Source BAT-B Fail - ac-vol-out-range : AC Input Voltage Value Out of Range - network-power-loss-b : Loss of Network Power B - sem-ac-power-fail : External AC power supply failure - sem-ups-low-volt : External power supply low voltage - dc-a-fail : Local DC A power failure - dc-b-fail : Local DC B power failure - plan-power-mismatch : Planned and detected power mode mismatch - water-seepage-in-box : Detected water seepage in enclosure - sealed-box-open : Sealed box open detected - dc-a-vol-out-range : DC A Input Voltage Value Out of Range - dc-b-vol-out-range : DC B Input Voltage Value Out of Range - inlet-temp-major : The inlet temperature has exceeded a major level - inlet-temp-critical : The inlet temperature has exceeded a critical level - psu-fail-crit : Power Supply failure - psu-a-fail-presence : Power Supply A is not present - psu-a-fail-vin-ac-nok : Power Supply A has Vin AC fault - psu-a-fail-vin-uv : Power Supply A has Vin undervoltage - psu-a-fail-vin-ov : Power Supply A has Vin overvoltage - psu-a-fail-vout-uv : Power Supply A has Vout undervoltage - psu-a-fail-vout-ov : Power Supply A has Vout overvoltage - psu-a-fail-iout-oc : Power Supply A has Iout overcurrent - psu-a-fail-ovtemp : Power Supply A has over temperature - psu-b-fail-presence : Power Supply B is not present - psu-b-fail-vin-ac-nok : Power Supply B has Vin AC fault - psu-b-fail-vin-uv : Power Supply B has Vin undervoltage - psu-b-fail-vin-ov : Power Supply B has Vin overvoltage - psu-b-fail-vout-uv : Power Supply B has Vout undervoltage - psu-b-fail-vout-ov : Power Supply B has Vout overvoltage - psu-b-fail-iout-oc : Power Supply B has Iout overcurrent - psu-b-fail-ovtemp : Power Supply B has over temperature - synce-fail : synce clock source failure	

Parameter	Type	Description
	- bits-fail : bits clock source failure - bits-output-shutoff : bits output failure - ieee1588-fail : ieee1588 clock source failure - gnss-fail : gnss clock source failure - ieee1588-hybrid-fail : ieee1588 hybrid tod source failure - signal-loss : synce or bits clock signal loss - signal-efd : synce or bits clock signal exceed frequency deviation - esmc-loss : clock source loss SSM infomation - bits-output-exceed : exceed bits output threshold - ql-input-exceed : exceed input clock source threshold - holdover : clock system is in the holdover - lti : all clock source failed - tod-reference-fail : Timing ToD Reference failed - internal-clk-fail : Internal CLK failed - bgp-peer-down : peer operational state is down - bgp-routes-mid-limit : 90% of max nbr of routes BGP can learn from a peer is reached - isis-adjacency-down : isis adjacency is down - isis-adjacency-reject : isis adjacency is rejected - isis-instance-down : isis instance is down or not - ospf-lsa-limit : limit of received LSA's is reached - ospf-lsa-mid-limit : 90% of limit of received LSA's is reached - ospf-neighbor-down : OSPF neighbour is down - ospf-instance-down : OSPF instance is down or not - ospf3-lsa-limit : limit of received OSPFv3 LSAs is reached - ospf3-lsa-mid-limit : 90% of limit of received OSPFv3 LSAs is reached - ospf3-neighbor-down : OSPFv3 neighbour is down - ospf3-instance-down : OSPFv3 instance is down or not - rip-instance-down : rip instance down - lag-down : lag down - lagsubgrp-thresh-reach: lag subgroup threshold reached - lagsubgrp-switch-fail : lag subgroup switchover failed - no-unpinned-free-ports: No free ports available for unpinned traffic - general-arp-limit : arp limit exceeded - gen-switch-out-of-res : failure due to lack of resources on switch - ipv6-nc-limit : ipv6 neighbor cache limit exceeded - dhcp-session-oor : dhcp session out of resources - ihub-fdb-limit : layer 2 fdb limit reached - ihub-mac-limit : layer 2 mac limit reached - l2fw-stp-exception : STP exception condition is present in the SAP - l2fw-stp-root-guard : STP root guard violation is present - vprn-routes-limit : limit of ip is reached - vprn-ipv6-routes-limit: limit of ipv6 is reached - dhcpv6-lease-limit : limit of dhcpv6 leases is reached - dhcpv4-lease-limit : limit of dhcpv4 leases is reached - vpls-mfib-limit : limit of fib table is reached - ihub-ipv6-dad-own : duplicate IPV6 address is detected for IP address allotted to system - ihub-ipv6-dad : duplicate IPV6 address is detected for a user's IP address - ihub-ipv6-dup-pd-route: ipv6 duplicate pd detected	

3 Alarm Configuration Commands

Parameter	Type	Description
	- vpls-duplicate-mac : duplicate mac address is detected - vpls-fdb-limit : limit of fdb table is reached - vpls-self-duplic-mac : duplicate of a system owned mac address detected on a sap - vpls-sdp-self-dup-mac : duplicate of a system owned mac address detected on a sdp binding - link-down : link is down - link-lagport-add-fail : failure to add port to LAG - link-conf-mismatch : SFP+plugin-types does not match the planned speed and/or auto-negotiation for the port - ihub-peer-comm : ihub peer to peer communication failure - ihub-sw-fail : IHUB s/w error - ihub-hw-fail : IHUB h/w error - ihub-link-fail : IHUB link failure - ihub-proc-overload : IHUB processor exceeded - ihub-out-of-mem : IHUB processor out of memory - ntp-comm-lost : No response is received from the NTP servers - ldp-instance-down : ldp instance down - ldp-session-down : ldp session down - mpls-instance-down : mpls instance down - mpls-lsp-down : lsp down - mpls-lsp-path-down : lsp path down - sdp-instance-down : sdp instance down - sdp-binding-down : sdp binding down - epipe-instance-down : epipe instance down - lldpmed-portcfg-mis : config request failure for lldpmed portconfig - lldpmed-mediapl-mis : config request failure for lldpmed mediapolicy - vlanport-svc-mismatch : config request failure for the provisioned vlanport - mcsrc-stream-lost : multicast video stream lost - eqptsupl-syslog-upload: upload of log file to remote server failure - eqptsupl-ontsw-dnload : ont sw download in progress - cf-75%used : Compact flash exceeds 75% of life expectancy - cf-90%used : Compact flash exceeds 90% of life expectancy - olt-gen-pon-com-fail : pon communication failure on olt - olt-gen-tx-fail : transmitter failure on olt - olt-gen-unprov-ont : unprovisioned ont on pon - olt-gen-pon-eqpt-prov : mismatch btw equipment and provisioning pon attributes - olt-gen-pon-loss-sig : pon loss of signal - olt-gen-pon-diagnostic: pon diagnostic test active - olt-gen-loid-conflict : loid conflict ont on pon - olt-gen-loid-pwderr : loid password error ont on pon - olt-gen-pon-alien-test: pon alien diagnostic test active - olt-gen-alien-detect : pon alien detect active - olt-gen-rng-mism : pon ranging mismatch active - olt-gen-sfp-mism : pon sfp mismatch active - olt-gen-deact-hightca : deactivated ont hightca threshold crossed - olt-gen-deact-lowtca : deactivated ont lowtca threshold crossed	

Parameter	Type	Description
	- olt-gen-dp-integ : pon data path integrity failure - olt-gen-ddr-fault : pon failure due to ddr fault - olt-pon-tc-err-frag-tc: pon errored fragments threshold crossed - olt-ont-tc-err-frag-tc: ont errored fragments threshold crossed - ont-ploam-loss-sig : loss of signal at ont - ont-ploam-loss-ack : loss of acknowledge from ont - ont-ploam-loss-cd : loss of channel delineation of ont - ont-ploam-phy-eqpt-err: physical equipment error of ont - ont-ploam-startup-fail: startup failure in ranging of ont - ont-ploam-sig-degrade : signal degrade from ont - ont-ploam-disabled : ont disabled alarm - ont-ploam-err-msg : error message from ont - ont-ploam-inactive : inactive ont - ont-ploam-sig-fail : signal fail alarm from ont - ont-ploam-dying-gasp : dying gasp alarm from ont - ont-ploam-deact-fail : deactive failure of ont - ont-ploam-oam : loss of ploam for ont - ont-ploam-win-drift : drift of window alarm - ont-ploam-rdi : remote defect indication alarm - ont-ploam-loss-ks : loss of key synchronization alarm - ont-ploam-pwr-burst : power bursts on ont - ont-ploam-rog-disa : ont rogue disabled - ont-ploam-diff-reach : ont differential reach exceeded - ont-ploam-looc : Loss of OMCI channel due to persistent MIC failure - sfu-ploam-loss-sig : SFU ONT - loss of signal at ont - sfu-ploam-loss-ack : SFU ONT - loss of acknowledge from ont - sfu-ploam-loss-cd : SFU ONT - loss of channel delineation of ont - sfu-ploam-phy-eqpt-err: SFU ONT - physical equipment error of ont - sfu-ploam-startup-fail: SFU ONT - startup failure in ranging of ont - sfu-ploam-sig-degrade : SFU ONT - signal degrade from ont - sfu-ploam-disabled : SFU ONT - ont disabled alarm - sfu-ploam-err-msg : SFU ONT - error message from ont - sfu-ploam-inactive : SFU ONT - inactive ont - sfu-ploam-sig-fail : SFU ONT - signal fail alarm from ont - sfu-ploam-dying-gasp : SFU ONT - dying gasp alarm from ont - sfu-ploam-deact-fail : SFU ONT - deactive failure of ont - sfu-ploam-oam : SFU ONT - loss of ploam for ont - sfu-ploam-win-drift : SFU ONT - drift of window alarm - sfu-ploam-rdi : SFU ONT - remote defect indication alarm - sfu-ploam-loss-ks : SFU ONT - loss of key synchronization alarm - sfu-ploam-pwr-burst : SFU ONT - power bursts on ont - sfu-ploam-rog-disa : SFU ONT - ont rogue disabled - sfu-ploam-diff-reach : SFU ONT - ont differential reach exceeded - sfu-ploam-looc : SFU ONT - Loss of OMCI channel due to persistent MIC failure - soho-ploam-loss-sig : SOHO ONT - loss of signal at ont	

3 Alarm Configuration Commands

Parameter	Type	Description
	- soho-ploam-loss-ack : SOHO ONT - loss of acknowledge from ont - soho-ploam-loss-cd : SOHO ONT - loss of channel delineation of ont - soho-ploam-phy-eqpt-er: SOHO ONT - physical equipment error of ont - soho-ploam-startup-fai: SOHO ONT - startup failure in ranging of ont - soho-ploam-sig-degrade: SOHO ONT - signal degrade from ont - soho-ploam-disabled : SOHO ONT - ont disabled alarm - soho-ploam-err-msg : SOHO ONT - error message from ont - soho-ploam-inactive : SOHO ONT - inactive ont - soho-ploam-sig-fail : SOHO ONT - signal fail alarm from ont - soho-ploam-dying-gasp : SOHO ONT - dying gasp alarm from ont - soho-ploam-deact-fail : SOHO ONT - deactive failure of ont - soho-ploam-oam : SOHO ONT - loss of ploam for ont - soho-ploam-win-drift : SOHO ONT - drift of window alarm - soho-ploam-rdi : SOHO ONT - remote defect indication alarm - soho-ploam-loss-ks : SOHO ONT - loss of key synchronization alarm - soho-ploam-pwr-burst : SOHO ONT - power bursts on ont - soho-ploam-rog-disa : SOHO ONT - ont rogue disabled - soho-ploam-diff-reach : SOHO ONT - ont differential reach exceeded - soho-ploam-looc : SOHO ONT - Loss of OMCI channel due to persistent MIC failure - mdu-ploam-loss-sig : MDU ONT - loss of signal at ont - mdu-ploam-loss-ack : MDU ONT - loss of acknowledge from ont - mdu-ploam-loss-cd : MDU ONT - loss of channel delineation of ont - mdu-ploam-phy-eqpt-err: MDU ONT - physical equipment error of ont - mdu-ploam-startup-fail: MDU ONT - startup failure in ranging of ont - mdu-ploam-sig-degrade : MDU ONT - signal degrade from ont - mdu-ploam-disabled : MDU ONT - ont disabled alarm - mdu-ploam-err-msg : MDU ONT - error message from ont - mdu-ploam-inactive : MDU ONT - inactive ont - mdu-ploam-sig-fail : MDU ONT - signal fail alarm from ont - mdu-ploam-dying-gasp : MDU ONT - dying gasp alarm from ont - mdu-ploam-deact-fail : MDU ONT - deactive failure of ont - mdu-ploam-oam : MDU ONT - loss of ploam for ont - mdu-ploam-win-drift : MDU ONT - drift of window alarm - mdu-ploam-rdi : MDU ONT - remote defect indication alarm - mdu-ploam-loss-ks : MDU ONT - loss of key	

Parameter	Type	Description
	synchronization alarm - mdu-ploam-pwr-burst : MDU ONT - power bursts on ont - mdu-ploam-roq-disa : MDU ONT - ont rogue disabled - mdu-ploam-diff-reach : MDU ONT - ont differential reach exceeded - mdu-ploam-looc : MDU ONT - Loss of OMCI channel due to persistent MIC failure - ont-hpna-ser-mis : hpna ont service mismatch - ont-hpna-los-sig : hpna loss of link - ont-moca-svc-mis : moca ont service mismatch - ont-moca-link-los : moca loss of link - ont-moca-min-bw : moca bw between nodes less than minimum bw - ont-moca-tca-rx-err-fr: moca rx errored frames threshold crossed - ont-sipa-reg-nm-fail : sipua registration name failed - ont-sipa-reg-rec-fail : sipua register reach failed - ont-sipa-reg-con-fail : sipua register connect failed - ont-sipa-reg-val-fail : sipua register validation failed - ont-sipa-reg-mis : sipua register mismatch - ont-vcd-cfg-nm-fail : vcd config name failed - ont-vcd-cfg-rech-fail : vcd config reach failed - ont-vcd-cfg-conn-fail : vcd config connect failed - ont-vcd-cfg-vali-fail : vcd config validation failed - ont-vcd-cfg-auth-fail : vcd config authentication failed - ont-vcd-cfg-resp-tmout: vcd config response timeout - ont-vcd-cfg-resp-err : vcd config response error - ont-vcd-cfg-file-err : vcd config file error - ont-vcd-sub-nm-fail : vcd subscription name failed - ont-vcd-sub-rech-fail : vcd subscription reach failed - ont-vcd-sub-conn-fail : vcd subscription connect failed - ont-vcd-sub-vali-fail : vcd subscription validation failed - ont-vcd-sub-auth-fail : vcd subscription authentication failed - ont-vcd-sub-resp-tmout: vcd subscription response timeout - ont-vcd-sub-resp-err : vcd subscription response error - ont-vcd-reb-requ : vcd reboot request - ont-vcd-mis : vcd mismatch - ont-mgc-mis : ont mgc mismatch - ont-mgc-timeout : ont mgc timeout - ont-sip-reg-dns : ont services pots sip registration failed (resolving domain name) - ont-sip-reg-fail : ont services pots sip registration authentication failed - ont-sip-reg-timeout : ont services pots sip registration timeout - ont-sip-reg-err-resps : ont services pots sip registration response error - ont-sip-inv-dns : ont services pots sip invitation failed (resolving domain name) - ont-sip-inv-auth : ont services pots sip invitation authentication failed - ont-sip-inv-timeout : ont services pots sip invitation timeout - ont-sip-inv-err : ont services pots sip invitation response error - ont-svc-pots-subs-refr: ont services pots iconfig	

3 Alarm Configuration Commands

Parameter	Type	Description
	- subscription could not be refreshed - ont-svc-pots-not-refr : ont services pots iconfig notification could not be refreshed - ont-svc-pots-icfg-err : ont services pots service failed due to an unmapped iconfig error - ont-veip-mismatch : ont veip mismatch - ont-ip-host-mismatch : ont ip host mismatch - ont-ip-host-file : ont ip host file unavailable - ont-ip-host-ip-alloc : ont ip host IP allocation failure - olt-pon-up-bw-tca : OLT PON upstream bandwidth TCA - olt-pon-down-bw-tca : OLT PON downstream bandwidth TCA - ont-gen-omci-fail : loss of communication - ont-gen-eqpt-selftest : ont self-test failure - ont-gen-ac-pwr-fail : ac power failure on ont - ont-gen-bat-missing : battery missing - ont-gen-bat-low : battery low - ont-gen-bat-fail : battery failure - ont-gen-phys-intrusion: physical intrusion - ont-gen-sw-dnload-f : ont sw download failure - ont-gen-sw-dnload-p : ont sw download in progress - ont-gen-sw-act-fail : ont sw activation failure - ont-gen-eqpt-vers-mis : ont equipment version mismatch - ont-gen-sw-vers-mis : ont sw version mismatch - ont-gen-us-rate-mis : ont upstream rate mismatch - ont-gen-mdu-env1 : mdu environmental alarm#1 - ont-gen-mdu-env2 : mdu environmental alarm#2 - ont-gen-mdu-env3 : mdu environmental alarm#3 - ont-gen-nw-time-err : network timing protocol error - ont-gen-opt-sig-high : optical signal level too high - ont-gen-opt-sig-low : optical signal level too low - ont-gen-eqpt-prov-sa : service affecting mismatch btw equipment and provisioning attributes - ont-gen-eqpt-prov-nsa : non service affecting mismatch btw equipment and provisioning attributes - pon-t-txmcutilhi : pon utilization tx (downstream) multicast high threshold crossed - pon-t-txmcutilmd : pon utilization tx (downstream) multicast medium threshold crossed - pon-t-txmcutillo : pon utilization tx (downstream) multicast low threshold crossed - pon-t-txtotutilhi : pon utilization tx (downstream) total high threshold crossed - pon-t-txtotutilmd : pon utilization tx (downstream) total medium threshold crossed - pon-t-txtotutillo : pon utilization tx (downstream) total low threshold crossed - pon-t-rxtotutilhi : pon utilization rx (upstream) total high threshold crossed - pon-t-rxtotutilmd : pon utilization rx (upstream) total medium threshold crossed - pon-t-rxtotutillo : pon utilization rx (upstream) total low threshold crossed - pon-t-dbacongperiodhi : pon utilization rx (upstream) dbacongperiod high threshold crossed - pon-t-dbacongperiodmd : pon utilization rx (upstream) dbacongperiod medium threshold crossed	

Parameter	Type	Description
	- pon-t-dbacongperiodlo : pon utilization rx (upstream) dbacongperiod low threshold crossed - pon-t-txucdropfrmhi : pon utilization tx (downstream) unicast drop frame high threshold crossed - pon-t-txucdropfrmmd : pon utilization tx (downstream) unicast drop frame medium threshold crossed - pon-t-txucdropfrmlo : pon utilization tx (downstream) unicast drop frame low threshold crossed - pon-t-txmcdropfrmhi : pon utilization tx (downstream) multicast drop frame high threshold crossed - pon-t-txmcdropfrmmd : pon utilization tx (downstream) multicast drop frame medium threshold crossed - pon-t-txmcdropfrmlo : pon utilization tx (downstream) multicast drop frame low threshold crossed - pon-t-txbcdropfrmhi : pon utilization tx (downstream) broadcast drop frame high threshold crossed - pon-t-txbcdropfrmmd : pon utilization tx (downstream) broadcast drop frame medium threshold crossed - pon-t-txbcdropfrmlo : pon utilization tx (downstream) broadcast drop frame low threshold crossed - pon-t-rxtotdropfrmhi : pon utilization rx (upstream) total drop frame high threshold crossed - pon-t-rxtotdropfrmmd : pon utilization rx (upstream) total drop frame medium threshold crossed - pon-t-rxtotdropfrmlo : pon utilization rx (upstream) total drop frame low threshold crossed - chpr-t-txmcutilhi : channel-pair utilization tx (downstream) multicast high threshold crossed - chpr-t-txmcutilmd : channel-pair utilization tx (downstream) multicast medium threshold crossed - chpr-t-txmcutillo : channel-pair utilization tx (downstream) multicast low threshold crossed - chpr-t-txtotutilhi : channel-pair utilization tx (downstream) total high threshold crossed - chpr-t-txtotutilmd : channel-pair utilization tx (downstream) total medium threshold crossed - chpr-t-txtotutillo : channel-pair utilization tx (downstream) total low threshold crossed - chpr-t-rxtotutilhi : channel-pair utilization rx (upstream) total high threshold crossed - chpr-t-rxtotutilmd : channel-pair utilization rx (upstream) total medium threshold crossed - chpr-t-rxtotutillo : channel-pair utilization rx (upstream) total low threshold crossed - chpr-t-dbacongperiodhi: channel-pair utilization rx (upstream) dbacongperiod high threshold crossed - chpr-t-dbacongperiodmd: channel-pair utilization rx (upstream) dbacongperiod medium threshold crossed - chpr-t-dbacongperiodlo: channel-pair utilization rx (upstream) dbacongperiod low threshold crossed - chpr-t-txucdropfrmhi : channel-pair utilization tx (downstream) unicast drop frame high threshold crossed - chpr-t-txucdropfrmmd : channel-pair utilization tx (downstream) unicast drop frame medium threshold crossed - chpr-t-txucdropfrmlo : channel-pair utilization tx (downstream) unicast drop frame low threshold crossed - chpr-t-txmcdropfrmhi : channel-pair utilization tx	

3 Alarm Configuration Commands

Parameter	Type	Description
	(downstream) multicast drop frame high threshold crossed - chpr-t-txmcdropfrmmd : channel-pair utilization tx (downstream) multicast drop frame medium threshold crossed - chpr-t-txmcdropfrmlo : channel-pair utilization tx (downstream) multicast drop frame low threshold crossed - chpr-t-txbcdropfrmhi : channel-pair utilization tx (downstream) broadcast drop frame high threshold crossed - chpr-t-txbcdropfrmmd : channel-pair utilization tx (downstream) broadcast drop frame medium threshold crossed - chpr-t-txbcdropfrmlo : channel-pair utilization tx (downstream) broadcast drop frame low threshold crossed - chpr-t-rxtotdropfrmhi : channel-pair utilization rx (upstream) total drop frame high threshold crossed - chpr-t-rxtotdropfrmmd : channel-pair utilization rx (upstream) total drop frame medium threshold crossed - chpr-t-rxtotdropfrmlo : channel-pair utilization rx (upstream) total drop frame low threshold crossed - sfu-gen-omci-fail : SFU ONT - loss of communication - sfu-gen-eqpt-selftest : SFU ONT - ont self-test failure - sfu-gen-ac-pwr-fail : SFU ONT - ac power failure on ont - sfu-gen-bat-missing : SFU ONT - battery missing - sfu-gen-bat-low : SFU ONT - battery low - sfu-gen-bat-fail : SFU ONT - battery failure - sfu-gen-sw-dnload-f : SFU ONT - ont sw download failure - sfu-gen-sw-dnload-p : SFU ONT - ont sw download in progress - sfu-gen-sw-act-fail : SFU ONT - ont sw activation failure - sfu-gen-eqpt-vers-mis : SFU ONT - ont equipment version mismatch - sfu-gen-sw-vers-mis : SFU ONT - ont sw version mismatch - sfu-gen-us-rate-mis : SFU ONT - ont upstream rate mismatch - sfu-gen-tune-fail : SFU ONT - ont has failed to tune to Target-ChnlPair - sfu-gen-nw-time-err : SFU ONT - network timing protocol error - sfu-gen-opt-sig-high : SFU ONT - optical signal level too high - sfu-gen-opt-sig-low : SFU ONT - optical signal level too low - sfu-gen-eqpt-prov-sa : SFU ONT - service affecting mismatch btw equipment and provisioning attributes - sfu-gen-eqpt-prov-nsa : SFU ONT - non service affecting mismatch btw equipment and provisioning attributes - soho-gen-omci-fail : SOHO ONT - loss of communication - soho-gen-eqpt-selftest : SOHO ONT - ont self-test failure - soho-gen-ac-pwr-fail : SOHO ONT - ac power failure on ont - soho-gen-bat-missing : SOHO ONT - battery missing - soho-gen-bat-low : SOHO ONT - battery low - soho-gen-bat-fail : SOHO ONT - battery failure - soho-gen-sw-dnload-f : SOHO ONT - ont sw download failure - soho-gen-sw-dnload-p : SOHO ONT - ont sw download in	

Parameter	Type	Description
	- progress - soho-gen-sw-act-fail : SOHO ONT - ont sw activation failure - soho-gen-eqpt-vers-mis: SOHO ONT - ont equipment version mismatch - soho-gen-sw-vers-mis : SOHO ONT - ont sw version mismatch - soho-gen-us-rate-mis : SOHO ONT - ont upstream rate mismatch - soho-gen-tune-fail : SOHO ONT - ont has failed to tune to Target-ChnlPair - soho-gen-nw-time-err : SOHO ONT - network timing protocol error - soho-gen-opt-sig-high : SOHO ONT - optical signal level too high - soho-gen-opt-sig-low : SOHO ONT - optical signal level too low - soho-gen-eqpt-prov-sa : SOHO ONT - service affecting mismatch btw equipment and provisioning attributes - soho-gen-eqpt-prov-nsa: SOHO ONT - non service affecting mismatch btw equipment and provisioning attributes - mdu-gen-omci-fail : MDU ONT - loss of communication - mdu-gen-eqpt-selftest : MDU ONT - ont self-test failure - mdu-gen-ac-pwr-fail : MDU ONT - ac power failure on ont - mdu-gen-bat-missing : MDU ONT - battery missing - mdu-gen-bat-low : MDU ONT - battery low - mdu-gen-bat-fail : MDU ONT - battery failure - mdu-gen-phys-intrusion: MDU ONT - physical intrusion - mdu-gen-sw-dnload-f : MDU ONT - ont sw download failure - mdu-gen-sw-dnload-p : MDU ONT - ont sw download in progress - mdu-gen-sw-act-fail : MDU ONT - ont sw activation failure - mdu-gen-eqpt-vers-mis : MDU ONT - ont equipment version mismatch - mdu-gen-sw-vers-mis : MDU ONT - ont sw version mismatch - mdu-gen-us-rate-mis : MDU ONT - ont upstream rate mismatch - mdu-gen-tune-fail : MDU ONT - ont has failed to tune to Target-ChnlPair - mdu-gen-mdu-env1 : MDU ONT - mdu environmental alarm#1 - mdu-gen-mdu-env2 : MDU ONT - mdu environmental alarm#2 - mdu-gen-mdu-env3 : MDU ONT - mdu environmental alarm#3 - mdu-gen-nw-time-err : MDU ONT - network timing protocol error - mdu-gen-opt-sig-high : MDU ONT - optical signal level too high - mdu-gen-opt-sig-low : MDU ONT - optical signal level too low - mdu-gen-eqpt-prov-sa : MDU ONT - service affecting	

3 Alarm Configuration Commands

Parameter	Type	Description
	mismatch btw equipment and provisioning attributes - mdu-gen-eqpt-prov-nsa : MDU ONT - non service affecting mismatch btw equipment and provisioning attributes - ont-gen-sw-dnload-file: ont sw download file missing - ont-gen-fan-fail : ont fan failure - ont-gen-high-temp : ont high temperature - ont-gen-high-temp-ex : ont excessive high temperature - ont-gen-emergency-call: ont emergency call - ont-gen-sw-version : ont sw version control error - ont-poe-exceed-max : ont poe exceed max - ont-poe-overload-yell : ONU is nearing its maximum ability to supply the power - ont-opti-malfunc : malfunction of ONT's optical transceiver - ont-gen-cfgdld-fail : download of voice xml file to ont failed - ont-gen-rssi-mis : ONU RSSI configuration mismatch - ont-gen-tx-pwr-low : ONU SFP Tx Power is lower than configured Alarm low threshold - ont-gen-temp-high : ONU SFP Temperature is higher than configured Alarm high threshold - ont-gen-volt-high : ONU SFP Voltage is higher than configured Alarm high threshold - ont-gen-bias-high : ONU SFP Bias is higher than configured Alarm high threshold - ont-loopdetect-mis : ont loop detect mismatch - ont-olt-rx-pw-lo : olt side receive power from ont low - ont-olt-rx-pw-hig : olt side receive power from ont high - ont-olt-rx-pw-warnlo : olt side receive power from ont low warning - ont-olt-rx-pw-warnhig : olt side receive power from ont high warning - ont-gen-tod-out-sync : ONU TOD is out-sync with OLT - ont-gen-tune-fail : ONU has failed to tune to Target-ChnlPair - hgu-tr069-param-fail : hgu tr069 parameters mismatch - ont-gen-tod-mismatch : ONU TOD MISMATCH - sfu-sup-sw-file-error : SFU ONT - Software file has error or is missing - sfu-sup-fan-failure : SFU ONT - Fan failure - sfu-sup-temp-high-warn: SFU ONT - High temperature warning - sfu-sup-temp-shutoff : SFU ONT - Service disabled due to excessive temperature - sfu-sup-emergency-call: SFU ONT - Emergency call active - sfu-sup-swverctrl-err : SFU ONT - Software version control error - sfu-sup-poe-exceed-max: SFU ONT - Configured PoE feeding exceeds ONT maximum - sfu-sup-poe-over-yell : SFU ONT - ONU is nearing its maximum ability to supply the power - sfu-opti-malfunc : SFU ONT - Malfunction of ONT's optical transceiver - sfu-sup-cfg-dnld-fail : SFU ONT - Download of voice xml file to ONT failed - sfu-sup-rssi-cfg-mism : SFU ONT - RSSI configuration	

Parameter	Type	Description
	mismatch - sfu-sup-sfp-tx-low : SFU ONT - SFP Tx Power below configured low-level alarm threshold - sfu-sup-sfp-temp-high : SFU ONT - SFP Temperature above configured high-level alarm threshold - sfu-sup-sfp-volt-high : SFU ONT - SFP Voltage above configured high-level alarm threshold - sfu-sup-sfp-bias-high : SFU ONT - SFP Bias above configured high-level alarm threshold - sfu-sup-ld-cfg-mism : SFU ONT - Loop detection configuration mismatch - sfu-sup-olt-rx-low : SFU ONT - OLT Rx power below receiver operating range - sfu-sup-olt-rx-high : SFU ONT - OLT Rx power above receiver operating range - sfu-sup-olt-rx-lo-warn: SFU ONT - OLT Rx power below low-level warning threshold - sfu-sup-olt-rx-hi-warn: SFU ONT - OLT Rx power above high-level warning threshold - sfu-sup-tod-out-sync : SFU ONT - ONU TOD is out-sync with OLT - sfu-sup-ont-tune-fail : SFU ONT - ONU has failed to tune to Target-ChnlPair - sfu-tr069-param-fail : SFU ONT - hgu tr069 parameters mismatch - sfu-sup-tod-mismatch : SFU ONT - ONU TOD MISMATCH - soho-sup-sw-file-error: SOHO ONT - Software file has error or is missing - soho-sup-fan-failure : SOHO ONT - Fan failure - soho-sup-temp-high-war: SOHO ONT - High temperature warning - soho-sup-temp-shutoff : SOHO ONT - Service disabled due to excessive temperature - soho-sup-emergency-cal: SOHO ONT - Emergency call active - soho-sup-swverctrl-err: SOHO ONT - Software version control error - soho-sup-poe-exceed-ma: SOHO ONT - Configured PoE feeding exceeds ONT maximum - soho-sup-poe-over-yell: SOHO ONT - ONU is nearing its maximum ability to supply the power - soho-opti-malfunc : SOHO ONT - Malfunction of ONT's optical transceiver - soho-sup-cfg-dnld-fail: SOHO ONT - Download of voice xml file to ONT failed - soho-sup-rssi-cfg-mism: SOHO ONT - RSSI configuration mismatch - soho-sup-sfp-tx-low : SOHO ONT - SFP Tx Power below configured low-level alarm threshold - soho-sup-sfp-temp-high: SOHO ONT - SFP Temperature above configured high-level alarm threshold - soho-sup-sfp-volt-high: SOHO ONT - SFP Voltage above configured high-level alarm threshold - soho-sup-sfp-bias-high: SOHO ONT - SFP Bias above configured high-level alarm threshold - soho-sup-ld-cfg-mism : SOHO ONT - Loop detection	

3 Alarm Configuration Commands

Parameter	Type	Description
	- configuration mismatch - soho-sup-olt-rx-low : SOHO ONT - OLT Rx power below receiver operating range - soho-sup-olt-rx-high : SOHO ONT - OLT Rx power above receiver operating range - soho-sup-olt-rx-lo-war: SOHO ONT - OLT Rx power below low-level warning threshold - soho-sup-olt-rx-hi-war: SOHO ONT - OLT Rx power above high-level warning threshold - soho-sup-tod-out-sync : SOHO ONT - ONU TOD is out-sync with OLT - soho-sup-ont-tune-fail: SOHO ONT - ONU has failed to tune to Target-ChnlPair - soho-tr069-param-fail : SOHO ONT - hgu tr069 parameters mismatch - soho-sup-tod-mismatch : SOHO ONT - ONU TOD MISMATCH - mdu-sup-sw-file-error : MDU ONT - Software file has error or is missing - mdu-sup-fan-failure : MDU ONT - Fan failure - mdu-sup-temp-high-warn: MDU ONT - High temperature warning - mdu-sup-temp-shutoff : MDU ONT - Service disabled due to excessive temperature - mdu-sup-emergency-call: MDU ONT - Emergency call active - mdu-sup-swverctrl-err : MDU ONT - Software version control error - mdu-sup-poe-exceed-max: MDU ONT - Configured PoE feeding exceeds ONT maximum - mdu-sup-poe-over-yell : MDU ONT - ONU is nearing its maximum ability to supply the power - mdu-opti-malfunc : MDU ONT - Malfunction of ONT's optical transceiver - mdu-sup-cfg-dnld-fail : MDU ONT - Download of voice xml file to ONT failed - mdu-sup-rssi-cfg-mism : MDU ONT - RSSI configuration mismatch - mdu-sup-sfp-tx-low : MDU ONT - SFP Tx Power below configured low-level alarm threshold - mdu-sup-sfp-temp-high : MDU ONT - SFP Temperature above configured high-level alarm threshold - mdu-sup-sfp-volt-high : MDU ONT - SFP Voltage above configured high-level alarm threshold - mdu-sup-sfp-bias-high : MDU ONT - SFP Bias above configured high-level alarm threshold - mdu-sup-ld-cfg-mism : MDU ONT - Loop detection configuration mismatch - mdu-sup-olt-rx-low : MDU ONT - OLT Rx power below receiver operating range - mdu-sup-olt-rx-high : MDU ONT - OLT Rx power above receiver operating range - mdu-sup-olt-rx-lo-warn: MDU ONT - OLT Rx power below low-level warning threshold - mdu-sup-olt-rx-hi-warn: MDU ONT - OLT Rx power above high-level warning threshold - mdu-sup-tod-out-sync : MDU ONT - ONU TOD is	

Parameter	Type	Description
	out-sync with OLT - mdu-sup-ont-tune-fail : MDU ONT - ONU has failed to tune to Target-ChnlPair - mdu-tr069-param-fail : MDU ONT - hgu tr069 parameters mismatch - mdu-sup-tod-mismatch : MDU ONT - ONU TOD MISMATCH - ont-sbscr-lim-missing : provisioned ont card missing - ont-sbscr-lim-type-mis: wrong type plug-in ont card - ont-sbscr-lim-removal : improper removal ont card - ont-sbscr-lim-fail : ont card failure - ont-sbscr-lim-svc-mis : ont service mismatch for provisioned onu card - ont-sbscr-lim-port-mis: port mismatch btw actual and planned ont card - ont-svc-video-conf-mis: config request failure for video service - ont-svc-video-pw-high : high power level for rf video signal - ont-svc-video-pw-low : low power level for rf video signal - ont-svc-pots-svc-mis : ont service mismatch for provisioned pots - ont-svc-pots-rtcp-lost: pots realtime transport control protocol stream lost - ont-svc-pots-icnf-subs: pots line iconfig subscription failure - ont-svc-pots-icnf-ntfy: pots line iconfig notify failure - ont-svc-pots-icnf-http: pots line iconfig http failure - ont-svc-pots-sip-reg : pots line sip registration failure - ont-svc-pots-sip-inv : pots line sip invite request failure - ont-svc-pots-sip-subsc: pots line sip subscribe failure - ont-svc-pots-sip-mt-tc: pots line sip message timeout threshold crossed - ont-svc-pots-pk-los-tc: pots line rtp bearer packets loss threshold crossed - ont-svc-pots-jitter-tc: pots line rtp jitter threshold crossed - ont-svc-pots-subs-dns : pots line iconfig subscription failed (DNS) - ont-svc-pots-subs-tcp : pots line iconfig subscription failed (TCP) - ont-svc-pots-subs-tls : pots line iconfig subscription failed (TLS) - ont-svc-pots-subs-auth: pots line iconfig subscription failed authentication - ont-svc-pots-subs-to : pots line iconfig subscription failed (timeout) - ont-svc-pots-subs-err : pots line iconfig subscription response error - ont-svc-pots-not-to : pots line iconfig notification failed (timeout) - ont-svc-pots-notref-to: pots line iconfig notification refresh failed - ont-svc-pots-not-mal : pots line iconfig notification failed (malformed) - ont-svc-pots-not-rej : pots line iconfig notification rejected - ont-svc-pots-http-dns : pots line iconfig doc retrieval failed (DNS)	

3 Alarm Configuration Commands

Parameter	Type	Description
	- ont-svc-pots-http-tcp : pots line iconfig doc retrieval failed (TCP) - ont-svc-pots-http-tls : pots line iconfig doc retrieval failed (TLS) - ont-svc-pots-http-auth: pots line iconfig doc retrieval failed (authentication) - ont-svc-pots-http-to : pots line iconfig doc retrieval failed (timeout) - ont-svc-pots-http-err : pots line iconfig doc retrieval response error - ont-svc-pots-http-mal : pots line iconfig doc retrieval failed (malformed) - ont-svc-pots-insuff : pots line iconfig service failed (insufficient data) - ont-svc-pots-poos : pots ports out of service - ont-svc-lan-mismatch : ont service mismatch for lan - ont-svc-lan-loss-sig : loss of signal on an ethernet port interface - ont-svc-enet-poos : Ethernet Ports out of Service - ont-svc-ces-ds1-mis : ont service mismatch for provisioned ces ds1 - ont-svc-ces-ds1-los : loss of signal at ds1 interface - ont-svc-ces-ds1-lof : loss of frame at ds1 interface - ont-svc-ces-ds1-rair : receiving rai at ds1 interface - ont-svc-ces-ds1-ais : receiving ais at ds1 interface - ont-svc-ces-ds1-lnlpbk: receiving line loopback at ds1 interface - ont-svc-ces-ds1-tmlpbk: receiving terminal loopback at ds1 interface - ont-svc-ces-e1-mis : ont service mismatch for provisioned ces e1 - ont-svc-ces-e1-los : loss of signal at e1 interface - ont-svc-ces-e1-lof : loss of frame at e1 interface - ont-svc-ces-e1-rair : receiving rai at e1 interface - ont-svc-ces-e1-ais : receiving ais at e1 interface - ont-svc-voip-cnf-file : voice configuration file error - ont-svc-voip-svc-mis : service mismatch for provisioned client service - ont-svc-voip-gw-comm : voice gateway communication failure - ont-svc-voip-dhcp-fail: voice dhcp server failure - ont-svc-voip-icnf-sub: voice iconfig subscription failure - ont-svc-voip-icnf-ntfy: voice iconfig notify failure - ont-svc-voip-icnf-http: voice iconfig http failure - ont-svc-voip-dhcp-to : DHCP server retransmissions timed out - ont-svc-voip-dhcp-mal : DHCP response was malformed - ont-svc-voip-dhcp-noad: DHCP server failed to issue the required parameters - ont-svc-voip-dhcp-leas: DHCP Server failure due to problem in lease renewal - ont-svc-voip-sub-dns : iConfig Subscription failure due to DNS problem - ont-svc-voip-sub-tcp : iConfig Subscription failure due to TCP socket problem - ont-svc-voip-sub-tls : iConfig Subscription failure due to TLS session problem	

Parameter	Type	Description
	- ont-svc-voip-subs-auth: iConfig Subscription failure due to authentication error - ont-svc-voip-subs-to : iConfig Subscription failure due to retransmission timeout - ont-svc-voip-subs-err : iConfig Subscription failure due to response error - ont-svc-voip-not-to : iConfig Notify response timeout for new subscription - ont-svc-voip-notref-to: iConfig Notify response timeout for subscription refresh - ont-svc-voip-not-mal : iConfig Notify response is malformed - ont-svc-voip-not-rej : iConfig subscription request rejected by configuration server - ont-svc-voip-http-dns : VOIP client can't retrieve config doc due to DNS problem - ont-svc-voip-http-tcp : VOIP client can't retrieve config doc due to TCP socket problem - ont-svc-voip-http-tls : VOIP client can't retrieve config doc due to TLS session problem - ont-svc-voip-http-auth: VOIP client can't retrieve config doc due to auth error - ont-svc-voip-http-to : VOIP client can't retrieve config doc due to re-tx timeout - ont-svc-voip-http-err : VOIP client can't retrieve config doc due to response error - ont-svc-voip-http-mal : iConfig configuration document is malformed - ont-svc-voip-subs-refr: iConfig Subscription refresh error - ont-svc-voip-not-refr : iConfig Notify response for refresh subscribe failed - ont-svc-voip-icfg-err : iConfig Configuration Error - ont-svc-v-ani-conf-mis: config request failure for video ani service - ont-svc-v-ani-loss-sig: video loss of signal on ani - ont-svc-v-ani-lv-high : high video optical signal level - ont-svc-v-ani-lv-low : low video optical signal level - ont-svc-pwe-mismatch : service mismatch for provisioned pseudowire - ont-svc-pwe-reordr-lof: pseudowire reordering and loss of frame - ont-svc-pwe-jitt-buf-o: pseudowire jitter buffer overrun - ont-svc-pwe-jitt-buf-u: pseudowire jitter buffer underrun - ont-svc-pwe-malf-frms : pseudowire malformed frames - ont-svc-pwe-late-frms : pseudowire late frames - ont-svc-pwe-link-loss : pseudowire link loss - ont-svc-pwe-arp-fail : pseudowire arp failure - ont-svc-xdsl-mismatch : service mismatch for provisioned xdsl - ont-svc-xdsl-ne-lof : near end loss of frame - ont-svc-xdsl-ne-los : near end loss of signal - ont-svc-xdsl-ne-line : near end line init - ont-svc-xdsl-ne-lol : near end loss of link - ont-svc-xdsl-fe-lof : far end loss of frame - ont-svc-xdsl-fe-los : far end loss of signal - ont-svc-xdsl-fe-lop : far end loss of power - ont-svc-xdsl-cnfg-err : xdsl provisioning error	

3 Alarm Configuration Commands

Parameter	Type	Description
	- ont-svc-xdsl-ne-es-tc : near end errored seconds threshold crossed - ont-svc-xdsl-ne-ses-tc: near end severe errored seconds threshold crossed - ont-svc-xdsl-ne-uas-tc: ear end unavailable seconds threshold crossed - ont-svc-xdsl-fe-es-tc : far end errored seconds threshold crossed - ont-svc-xdsl-fe-ses-tc: far end severe errored seconds threshold crossed - ont-svc-xdsl-fe-uas-tc: far end unavailable seconds threshold crossed - ont-tc-rx-los-frag-tc : rx loss of gem fragments threshold crossed - ont-tc-tx-los-frag-tc : tx loss of gem fragments threshold crossed - ont-tc-bad-gem-hd-tc : bad gem header threshold crossed - ont-uni-ds-drp-d-fr-tc : downstream l2 dropped frames threshold crossed - ont-uni-up-drp-d-fr-tc : upstream l2 dropped frames threshold crossed - ont-uni-ds-crc-fr-tc : downstream l2 rx crc error frames threshold crossed - ont-uni-up-crc-fr-tc : upstream l2 rx crc error frames threshold crossed - ont-cpu-util-tca : ONT CPU utilization threshold crossed - ont-mem-util-tca : ONT memory utilization threshold crossed - pim-neighbor-down : pim neighbor down - pim-max-mcroutes : maximum routes reached - li-traffic-disabled : lawful interception of traffic disabled - li-bandwidth-limit : lawful intercept reached bandwidth limit - li-out-of-res : lawful intercept out of resources - otdr-cap-mismatch : otdr capability mismatch - login-successful : successful login via management access - login-failure : invalid login via management access has crossed the threshold limit - cfm-defrdiccm : rdi bit in ccm received - cfm-defmacstatus : ccm mac error status - cfm-defremoteccm : missing ccm from mep - cfm-deferrorccm : invalid ccm received - cfm-defxconccm : unexpected ccm received - cfm-defais : ethernet ais received - bfd-session-down : bfd session down - bfd-max-resource : bfd maximum resources reached - bfd-stale-entry : bfd stale entry present - tca-outputbw : tca output bandwidth - tca-inputbw : tca input bandwidth - tca-rxcrcalign : tca rxrc align errors - tca-txcrcalign : tca txrc align errors - tca-txcollisions : tca tx collision errors - tca-outputhighbw : tca output high bandwidth - tca-outputmedbw : tca output medium bandwidth - tca-outputlowbw : tca output low bandwidth - tca-inputhighbw : tca input high bandwidth - tca-inputmediumbw : tca input medium bandwidth	

Parameter	Type	Description
	- tca-inputlowbw : tca input low bandwidth - eth-cfm-defrdiccm : rdi bit in ccm received - eth-cfm-defmacstatus : ccm mac error status - eth-cfm-defremoteccm : missing ccm from mep - eth-cfm-deferrorccm : invalid ccm received - eth-cfm-defxconccm : unexpected ccm received - rsvp-neighbor-down : rsvp neighbor down - rsvp-instance-down : rsvp instance down - eth-ring-path-block : eth ring path block - ai-platform-down : Application Intelligence Platform down - ai-appl-install-fail : Application installation failure - ip-assign-fail : Dhcp assigned address failure - ont-tr069-serv-mis : ont tr069 server config mismatch - ont-snmp-mis : ont snmp agent config mismatch - bsf-dhcpv4 : bulksync failed for dhcpv4 - bsf-dhcpv6 : bulksync failed for dhcpv6 - bsf-pon : bulksync failed for pon - bsf-vbridge : bulksync failed for vlan-bridge - bsf-qos : bulksync failed for qos - bsf-igmp : bulksync failed for igmp - bsf-lxfwd : bulksync failed for lxfwd - prot-not-available : no protection not available - prot-switchover-fail : port switch over failed - efm-oam-cpelinkfault : EFM-OAM CPE link fault - efm-oam-cpedyinggasp : EFM-OAM CPE dying gasp - efm-oam-cpecrevt : EFM-OAM CPE critical event - ont-loopdetect : ont loop detect - alm-tbl-overflow : alarm table has overflowed - auto-switch-status : auto-switch status - auswqueuefullatm : auto-switch queue Full for ATM - auswbkpfailatm : auto-switch config data backup failed for ATM - auswrecfgfailatm : auto-switch fallback reconfiguration failed for ATM - auswdataunatm : auto-switch backup config data unavailable for ATM - auswqueuefulptm : auto-switch queue Full for PTM - auswbkpfailptm : auto-switch config data backup failed for PTM - auswrecfgfailptm : auto-switch fallback reconfiguration failed for PTM - auswdataunptm : auto-switch backup config data unavailable for PTM - auswbakpfailatm : auto-switch backup fail for ATM - chpr-com-fail : channel pair communication failure on olt - chpr-tx-fail : transmitter failure on channel pair - chpr-unprov-ont : unprovisioned ont on channel pair - chpr-prov-mismatch : mismatch btw equipment and provisioning pon attributes - chpr-loss-sig : channel pair loss of signal - chpr-diagnostic : channel pair diagnostic test active - chpr-loid-conflict : loid conflict ont on channel pair - chpr-loid-pwd-err : loid password error ont on channel pair - chpr-stk-laser-dis : stuck laser disabled on channel pair - chpr-sfp-mismatch : channel pair sfp mismatch - chpr-rng-mismatch : channel pair ranging mismatch - chpr-alien-test : channel pair alien diagnostic test active	

3 Alarm Configuration Commands

Parameter	Type	Description
	- chpr-alien-detect : channel pair alien detect active - chpr-deact-hightca : channel pair deactivated ont hightca threshold crossed - chpr-deact-lowtca : channel pair deactivated ont lowtca threshold crossed - chpr-dp-integ : channel pair data path integrity failure - olt-chpr-tc-err-frag : channelpair errored fragments threshold crossed - olt-chpr-up-bw-tca : OLT CHANNELPAIR upstream bandwidth TCA - olt-chpr-down-bw-tca : OLT CHANNELPAIR downstream bandwidth TCA - cfg-dld-fail : download of configure file to ont failed - cfg-act-fail : activate the passive config file failed - cfg-dld-ip : ont configure file download in progress - cfg-ver-mismatch : the planned configure file does not match the active configure file - cfg-file-missing : ont configure file missing or has an error - cfg-verctrl-err : ont configure file version control error - cfg-not-supported : ont not support the configure file download function - ont-prot-not-available: ONT/ONU protection not available - ont-gen-temp-low : ONU SFP temperature is lower than configured Alarm low threshold - ont-gen-volt-low : ONU SFP Voltage is lower than configured Alarm low threshold - ont-gen-tx-pwr-high : ONU SFP Tx power is higher than configured Alarm high threshold - ont-gen-bias-low : ONU SFP bias is lower than configured Alarm low threshold - ont-gen-rx-hwarn : ONU SFP Rx power is higher than warn threshold - ont-gen-rx-lwarn : ONU SFP Rx power is lower than warn threshold - ont-gen-tx-hwarn : ONU SFP Tx power is higher than warn threshold - ont-gen-tx-lwarn : ONU SFP Tx power is lower than warn threshold - ont-gen-temp-hwarn : ONU SFP temperature is higher than warn threshold - ont-gen-temp-lwarn : ONU SFP temperature is lower than warn threshold - ont-gen-volt-hwarn : ONU SFP Voltage is higher than warn threshold - ont-gen-volt-lwarn : ONU SFP Voltage is lower than warn threshold - ont-gen-bias-hwarn : ONU SFP bias is higher than warn threshold - ont-gen-bias-lwarn : ONU SFP bias is lower than warn threshold - sfu-sup2-temp-low : SFU ONT - SFP temperature is lower than configured Alarm low threshold - sfu-sup2-volt-low : SFU ONT - SFP Voltage is lower than configured Alarm low threshold - sfu-sup2-tx-high : SFU ONT - SFP tx power is higher than configured Alarm high threshold - sfu-sup2-bias-low : SFU ONT - SFP bias is lower than	

Parameter	Type	Description
	configured Alarm low threshold - sfu-sup2-rx-hwarn : SFU ONT - SFP rx power is higher than configured warn threshold - sfu-sup2-rx-lwarn : SFU ONT - SFP rx power is lower than configured warn threshold - sfu-sup2-tx-hwarn : SFU ONT - SFP tx power is higher than configured warn threshold - sfu-sup2-tx-lwarn : SFU ONT - SFP tx power is lower than configured warn threshold - sfu-sup2-temp-hwarn : SFU ONT - SFP temperature is higher than configured warn threshold - sfu-sup2-temp-lwarn : SFU ONT - SFP temperature is lower than configured warn threshold - sfu-sup2-volt-hwarn : SFU ONT - SFP Voltage is higher than configured warn threshold - sfu-sup2-volt-lwarn : SFU ONT - SFP Voltage is lower than configured warn threshold - sfu-sup2-bias-hwarn : SFU ONT - SFP bias is higher than configured warn threshold - sfu-sup2-bias-lwarn : SFU ONT - SFP bias is lower than configured warn threshold - soho-sup2-temp-low : SOHO ONT - SFP temperature is lower than configured Alarm low threshold - soho-sup2-volt-low : SOHO ONT - SFP Voltage is lower than configured Alarm low threshold - soho-sup2-tx-high : SOHO ONT - SFP tx power is higher than configured Alarm low threshold - soho-sup2-bias-low : SOHO ONT - SFP bias is lower than configured Alarm low threshold - soho-sup2-rx-hwarn : SOHO ONT - SFP rx power is higher than warn threshold - soho-sup2-rx-lwarn : SOHO ONT - SFP rx power is lower than warn threshold - soho-sup2-tx-hwarn : SOHO ONT - SFP tx power is higher than warn threshold - soho-sup2-tx-lwarn : SOHO ONT - SFP tx power is lower than warn threshold - soho-sup2-temp-hwarn : SOHO ONT - SFP temperature is higher than warn threshold - soho-sup2-temp-lwarn : SOHO ONT - SFP temperature is lower than warn threshold - soho-sup2-volt-hwarn : SOHO ONT - SFP Voltage is higher than warn threshold - soho-sup2-volt-lwarn : SOHO ONT - SFP Voltage is lower than warn threshold - soho-sup2-bias-hwarn : SOHO ONT - SFP bias is higher than warn threshold - soho-sup2-bias-lwarn : SOHO ONT - SFP bias is lower than warn threshold - mdu-sup2-temp-low : MDU ONT - SFP temperature is lower than configured alarm low threshold - mdu-sup2-volt-low : MDU ONT - SFP Voltage is lower than configured alarm low threshold - mdu-sup2-tx-high : MDU ONT - SFP tx power is higher than configured alarm low threshold - mdu-sup2-bias-low : MDU ONT - SFP bias is lower than configured alarm low threshold	

3 Alarm Configuration Commands

Parameter	Type	Description
	- mdu-sup2-rx-hwarn : MDU ONT - SFP rx power is higher than warn threshold - mdu-sup2-rx-lwarn : MDU ONT - SFP rx power is lower than warn threshold - mdu-sup2-tx-hwarn : MDU ONT - SFP tx power is higher than warn threshold - mdu-sup2-tx-lwarn : MDU ONT - SFP tx power is lower than warn threshold - mdu-sup2-temp-hwarn : MDU ONT - SFP temperature is higher than warn threshold - mdu-sup2-temp-lwarn : MDU ONT - SFP temperature is lower than warn threshold - mdu-sup2-volt-hwarn : MDU ONT - SFP voltage is higher than warn threshold - mdu-sup2-volt-lwarn : MDU ONT - SFP voltage is lower than warn threshold - mdu-sup2-bias-hwarn : MDU ONT - SFP bias is higher than warn threshold - mdu-sup2-bias-lwarn : MDU ONT - SFP bias is lower than warn threshold - cust-alm1 : customizable alarm 1 - cust-alm2 : customizable alarm 2 - cust-alm3 : customizable alarm 3 - cust-alm4 : customizable alarm 4 - cust-alm5 : customizable alarm 5 - cust-alm6 : customizable alarm 6 - cust-alm7 : customizable alarm 7 - cust-alm8 : customizable alarm 8 - cust-alm9 : customizable alarm 9 - cust-alm10 : customizable alarm 10 - cust-alm11 : customizable alarm 11 - cust-alm12 : customizable alarm 12 - cust-alm13 : customizable alarm 13 - cust-alm14 : customizable alarm 14 - cust-alm15 : customizable alarm 15 - cust-alm16 : customizable alarm 16 - cust-alm17 : customizable alarm 17 - cust-alm18 : customizable alarm 18 - cust-alm19 : customizable alarm 19 - cust-alm20 : customizable alarm 20 - cust-alm21 : customizable alarm 21 - cust-alm22 : customizable alarm 22 - cust-alm23 : customizable alarm 23 - cust-alm24 : customizable alarm 24 - cust-alm25 : customizable alarm 25 - cust-alm26 : customizable alarm 26 - cust-alm27 : customizable alarm 27 - cust-alm28 : customizable alarm 28 - cust-alm29 : customizable alarm 29 - cust-alm30 : customizable alarm 30 - cust-alm31 : customizable alarm 31 - ethernet-ring-pthfwst : ethernet ring path forward state - ethernet-ring-fop-to : ethernet ring fop-to failure of protocol timeout - ethernet-ring-fop-pm : ethernet ring fop-pm failure of protocol provision mismatch - fpm-depletion : failsafe fpm depletion	

Parameter	Type	Description
	- exp-seizureack : Channel was blocked due to failure in the reception of the SEIZURE ACK signal - exp-disconack : Channel was blocked due to failure in the reception of the DISCONNECTION ACK signal - exp-forcerelack : Channel was blocked due to failure in the reception of the BACKWARD DISCONNECTION ACK signal - packet-loss : Pseudo Wire entered the Packet loss state - remote-packet-loss : Remote Packet loss detected - no-dsp-resource : DSP resource allocation failed - la-down : Link aggregation group link-status is down - la-standby-na : Cross-lt lag on standby slot part is not available - la-switch-fail : Cross-lt lag fail to do switchover - la-degrade : Link aggregation group degrade - melt-board-reset : MELT board reset - board-shelf-mismatch : board type and shelf type mismatch - fcs-thresh-exceed : FCS counter threshold exceeded	
[no] status	Parameter type: <Alarm::fltrStatus> Format: (not-used used) Possible values: - not-used : deactivate the configured alarm filter - used : activate the configured alarm filter	<i>optional parameter with default value: "not-used"</i> filter status
[no] threshold	Parameter type: <Alarm::fltrThreshold> Format: - the threshold value of the considered alarm filter - range: [2...65535]	<i>optional parameter with default value: "2"</i> the threshold value of the considered alarm filter
[no] window	Parameter type: <Alarm::fltrWindow> Format: - the duration of the filter window in seconds - range: [1...65535]	<i>optional parameter with default value: "60"</i> the duration of the filter window, only applicable for temporal type

3.5 Alarm Suppression Filter Configuration Command

Command Description

This command allows the operator to configure Suppression Alarm filter parameters.

Without valid interface and alarmid, suppression filter cannot be activated.

User Level

The command can be accessed by operators with alarm privileges, and executed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> configure alarm suppression filterid <Alarm::suppressionfltrId> [ interface <Alarm::suppressionFilterIndex> ] [
alarmid <Alarm::suppressionalarmIndex> ] [ no status | status <Alarm::fltrStatus> ] [ no threshold | threshold
<Alarm::suppressionfltrThreshold> ]
```

Command Parameters

Table 3.5-1 "Alarm Suppression Filter Configuration Command" Resource Parameters

Resource Identifier	Type	Description
filterid	Parameter type: <Alarm::suppressionfltrId> Format: - unique filter number - range: [1...32]	the id of the considered alarm suppression filter

Table 3.5-2 "Alarm Suppression Filter Configuration Command" Command Parameters

Parameter	Type	Description
interface	Parameter type: <Alarm::suppressionFilterIndex> Format: lt : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> Possible values: - lt : lt-slot Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number	<i>optional parameter</i> suppression filter interface
alarmid	Parameter type: <Alarm::suppressionalarmIndex> Format: (board-missing	<i>optional parameter</i> alarmType

Parameter	Type	Description
	board-init) Possible values: - board-missing : board detected after planning - now missing - board-init : board initialisation failure	
[no] status	Parameter type: <Alarm::fltrStatus> Format: (not-used used) Possible values: - not-used : deactivate the configured alarm filter - used : activate the configured alarm filter	<i>optional parameter with default value: "not-used"</i> filter status
[no] threshold	Parameter type: <Alarm::suppressionfltrThreshold> Format: - the threshold value of the considered alarm filter - range: [1...100]	<i>optional parameter with default value: "1"</i> the threshold value of the considered alarm filter

3.6 Alarm Delta Log Configuration Command

Command Description

This command allows the operator to configure the action of the system when the alarm log buffer is full.

If the action is set to wrap, older log records are overwritten by recent records. If the action is set to halt, logging is stopped until the log buffer is reset.

User Level

The command can be accessed by operators with alarm privileges, and executed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> configure alarm delta-log [ indet-log-full-action <Alarm::alarmDeltaLogFullAction> ] [ warn-log-full-action <Alarm::alarmDeltaLogFullAction> ] [ minor-log-full-action <Alarm::alarmDeltaLogFullAction> ] [ major-log-full-action <Alarm::alarmDeltaLogFullAction> ] [ crit-log-full-act <Alarm::alarmDeltaLogFullAction> ]
```

Command Parameters

Table 3.6-2 "Alarm Delta Log Configuration Command" Command Parameters

Parameter	Type	Description
indet-log-full-action	Parameter type: <Alarm::alarmDeltaLogFullAction> Format: (wrap halt) Possible values: - wrap : wrap around when log is full - halt : halt logging when log is full	<i>optional parameter</i> set the action when indeterminate log buffer is full
warn-log-full-action	Parameter type: <Alarm::alarmDeltaLogFullAction> Format: (wrap halt) Possible values: - wrap : wrap around when log is full - halt : halt logging when log is full	<i>optional parameter</i> set the action when warn delta log buffer is full
minor-log-full-action	Parameter type: <Alarm::alarmDeltaLogFullAction> Format: (wrap halt) Possible values: - wrap : wrap around when log is full - halt : halt logging when log is full	<i>optional parameter</i> set the action when minor delta log buffer is full
major-log-full-action	Parameter type: <Alarm::alarmDeltaLogFullAction> Format: (wrap	<i>optional parameter</i> set action when major delta log buffer is full

Parameter	Type	Description
	halt) Possible values: - wrap : wrap around when log is full - halt : halt logging when log is full	
crit-log-full-act	Parameter type: <Alarm::alarmDeltaLogFullAction> Format: (wrap halt) Possible values: - wrap : wrap around when log is full - halt : halt logging when log is full	<i>optional parameter</i> set action when critical delta log buffer is full

3.7 Customizable Alarm Profile Configuration Command

Command Description

This command allows the operator to configure the external alarm profile. The profile is made to be assigned to a remote LT board. The profile reflects a configuration of external alarms parameters that corresponds to a certain environment where the remote board is located (in an outdoor cabinet, basement cabinet, ...). The use of a profile avoids the need to specify the parameters for each remote board separately. The alarm profile groups all five external alarms parameters. The profile contains a description/meaning of each alarm, as well as an indication that tells us whether or not any alarm outputs are to be triggered if the corresponding external input alarm is raised. On top of these parameters, a mnemonic (short for the description), the polarity and the severity are configurable. Note: The Severity parameters of custom alarm profile i.e (severity1,severity2,severity3,severity4,severity5) are supported for only FD-REM not other shelves.

User Level

The command can be accessed by operators with alarm privileges, and executed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> configure alarm ( no custom-profile (name) ) | ( custom-profile (name) [ no mnemonic1 | mnemonic1
<Alarm::AlarmMnemonic> ] [ no description1 | description1 <Alarm::AlarmDescription> ] [ no visible1 | visible1
<Alarm::VisibleOutput> ] [ no audible1 | audible1 <Alarm::AudibleOutput> ] [ no polarity1 | polarity1
<Alarm::InversePolarity> ] [ no severity1 | severity1 <Alarm::AlarmSeverity> ] [ no mnemonic2 | mnemonic2
<Alarm::AlarmMnemonic> ] [ no description2 | description2 <Alarm::AlarmDescription> ] [ no visible2 | visible2
<Alarm::VisibleOutput> ] [ no audible2 | audible2 <Alarm::AudibleOutput> ] [ no polarity2 | polarity2
<Alarm::InversePolarity> ] [ no severity2 | severity2 <Alarm::AlarmSeverity> ] [ no mnemonic3 | mnemonic3
<Alarm::AlarmMnemonic> ] [ no description3 | description3 <Alarm::AlarmDescription> ] [ no visible3 | visible3
<Alarm::VisibleOutput> ] [ no audible3 | audible3 <Alarm::AudibleOutput> ] [ no polarity3 | polarity3
<Alarm::InversePolarity> ] [ no severity3 | severity3 <Alarm::AlarmSeverity> ] [ no mnemonic4 | mnemonic4
<Alarm::AlarmMnemonic> ] [ no description4 | description4 <Alarm::AlarmDescription> ] [ no visible4 | visible4
<Alarm::VisibleOutput> ] [ no audible4 | audible4 <Alarm::AudibleOutput> ] [ no polarity4 | polarity4
<Alarm::InversePolarity> ] [ no severity4 | severity4 <Alarm::AlarmSeverity> ] [ no mnemonic5 | mnemonic5
<Alarm::AlarmMnemonic> ] [ no description5 | description5 <Alarm::AlarmDescription> ] [ no visible5 | visible5
<Alarm::VisibleOutput> ] [ no audible5 | audible5 <Alarm::AudibleOutput> ] [ no polarity5 | polarity5
<Alarm::InversePolarity> ] [ no severity5 | severity5 <Alarm::AlarmSeverity> ] )
```

Command Parameters

Table 3.7-1 "Customizable Alarm Profile Configuration Command" Resource Parameters

Resource Identifier	Type	Description
(name)	Format: - a profile name	custom profile name

Resource Identifier	Type	Description
	- range: [a-zA-Z0-9-_.] - length: 1<=x<=32	

Table 3.7-2 "Customizable Alarm Profile Configuration Command" Command Parameters

Parameter	Type	Description
[no] mnemonic1	Parameter type: <Alarm::AlarmMnemonic> Format: - an octet string defining mnemonic of external alarm - range: [A-Z] - length: x<=16	<i>optional parameter with default value: "UNDEF"</i> mnemonic identifying the customizable external alarm 1
[no] description1	Parameter type: <Alarm::AlarmDescription> Format: - an octet string defining description of external alarm - length: x<=40	<i>optional parameter with default value: "Undefined"</i> description of the customizable external alarm 1
[no] visible1	Parameter type: <Alarm::VisibleOutput> Format: (enable disable) Possible values: - enable : external alarm output is visible - disable : external alarm output is non-visible	<i>optional parameter with default value: "disable"</i> trigger a visible alarm for external alarm 1
[no] audible1	Parameter type: <Alarm::AudibleOutput> Format: (enable disable) Possible values: - enable : external alarm output is audible - disable : external alarm output is non-audible	<i>optional parameter with default value: "disable"</i> trigger a audible alarm for external alarm 1
[no] polarity1	Parameter type: <Alarm::InversePolarity> Format: (normal inverse) Possible values: - normal : alarm polarity is normal - inverse : alarm polarity is inverse	<i>optional parameter with default value: "normal"</i> alarm polarity is normal or inverse for external alarm 1
[no] severity1	Parameter type: <Alarm::AlarmSeverity> Format: (indeterminate warning minor major critical) Possible values: - indeterminate : alarm severity is indeterminate - warning : alarm severity is warning - minor : alarm severity is minor - major : alarm severity is major - critical : alarm severity is critical	<i>optional parameter with default value: "major"</i> severity level of external alarm 1
[no] mnemonic2	Parameter type: <Alarm::AlarmMnemonic> Format: - an octet string defining mnemonic of external alarm - range: [A-Z] - length: x<=16	<i>optional parameter with default value: "UNDEF"</i> mnemonic identifying the customizable external alarm 2
[no] description2	Parameter type: <Alarm::AlarmDescription> Format: - an octet string defining description of external alarm - length: x<=40	<i>optional parameter with default value: "Undefined"</i> description of the customizable external alarm 2

3 Alarm Configuration Commands

Parameter	Type	Description
[no] visible2	Parameter type: <Alarm::VisibleOutput> Format: (enable disable) Possible values: - enable : external alarm output is visible - disable : external alarm output is non-visible	<i>optional parameter with default value: "disable"</i> trigger a visible alarm for external alarm 2
[no] audible2	Parameter type: <Alarm::AudibleOutput> Format: (enable disable) Possible values: - enable : external alarm output is audible - disable : external alarm output is non-audible	<i>optional parameter with default value: "disable"</i> trigger a audible alarm for external alarm 2
[no] polarity2	Parameter type: <Alarm::InversePolarity> Format: (normal inverse) Possible values: - normal : alarm polarity is normal - inverse : alarm polarity is inverse	<i>optional parameter with default value: "normal"</i> alarm polarity is normal or inverse for external alarm 2
[no] severity2	Parameter type: <Alarm::AlarmSeverity> Format: (indeterminate warning minor major critical) Possible values: - indeterminate : alarm severity is indeterminate - warning : alarm severity is warning - minor : alarm severity is minor - major : alarm severity is major - critical : alarm severity is critical	<i>optional parameter with default value: "major"</i> severity level of external alarm 2
[no] mnemonic3	Parameter type: <Alarm::AlarmMnemonic> Format: - an octet string defining mnemonic of external alarm - range: [A-Z] - length: x<=16	<i>optional parameter with default value: "UNDEF"</i> mnemonic identifying the customizable external alarm 3
[no] description3	Parameter type: <Alarm::AlarmDescription> Format: - an octet string defining description of external alarm - length: x<=40	<i>optional parameter with default value: "Undefined"</i> description of the customizable external alarm 3
[no] visible3	Parameter type: <Alarm::VisibleOutput> Format: (enable disable) Possible values: - enable : external alarm output is visible - disable : external alarm output is non-visible	<i>optional parameter with default value: "disable"</i> trigger a visible alarm for external alarm 3
[no] audible3	Parameter type: <Alarm::AudibleOutput> Format: (enable disable) Possible values: - enable : external alarm output is audible - disable : external alarm output is non-audible	<i>optional parameter with default value: "disable"</i> trigger a audible alarm for external alarm 3

Parameter	Type	Description
[no] polarity3	Parameter type: <Alarm::InversePolarity> Format: (normal inverse) Possible values: - normal : alarm polarity is normal - inverse : alarm polarity is inverse	<i>optional parameter with default value: "normal"</i> alarm polarity is normal or inverse for external alarm 3
[no] severity3	Parameter type: <Alarm::AlarmSeverity> Format: (indeterminate warning minor major critical) Possible values: - indeterminate : alarm severity is indeterminate - warning : alarm severity is warning - minor : alarm severity is minor - major : alarm severity is major - critical : alarm severity is critical	<i>optional parameter with default value: "major"</i> severity level of external alarm 3
[no] mnemonic4	Parameter type: <Alarm::AlarmMnemonic> Format: - an octet string defining mnemonic of external alarm - range: [A-Z] - length: x<=16	<i>optional parameter with default value: "UNDEF"</i> mnemonic identifying the customizable external alarm 4
[no] description4	Parameter type: <Alarm::AlarmDescription> Format: - an octet string defining description of external alarm - length: x<=40	<i>optional parameter with default value: "Undefined"</i> description of the customizable external alarm 4
[no] visible4	Parameter type: <Alarm::VisibleOutput> Format: (enable disable) Possible values: - enable : external alarm output is visible - disable : external alarm output is non-visible	<i>optional parameter with default value: "disable"</i> trigger a visible alarm for external alarm 4
[no] audible4	Parameter type: <Alarm::AudibleOutput> Format: (enable disable) Possible values: - enable : external alarm output is audible - disable : external alarm output is non-audible	<i>optional parameter with default value: "disable"</i> trigger a audible alarm for external alarm 4
[no] polarity4	Parameter type: <Alarm::InversePolarity> Format: (normal inverse) Possible values: - normal : alarm polarity is normal - inverse : alarm polarity is inverse	<i>optional parameter with default value: "normal"</i> alarm polarity is normal or inverse for external alarm 4
[no] severity4	Parameter type: <Alarm::AlarmSeverity> Format: (indeterminate warning minor major critical)	<i>optional parameter with default value: "major"</i> severity level of external alarm 4

3 Alarm Configuration Commands

Parameter	Type	Description
	Possible values: - indeterminate : alarm severity is indeterminate - warning : alarm severity is warning - minor : alarm severity is minor - major : alarm severity is major - critical : alarm severity is critical	
[no] mnemonic5	Parameter type: <Alarm::AlarmMnemonic> Format: - an octet string defining mnemonic of external alarm - range: [A-Z] - length: x<=16	<i>optional parameter with default value: "UNDEF"</i> mnemonic identifying the customizable external alarm 5
[no] description5	Parameter type: <Alarm::AlarmDescription> Format: - an octet string defining description of external alarm - length: x<=40	<i>optional parameter with default value: "Undefined"</i> description of the customizable external alarm 5
[no] visible5	Parameter type: <Alarm::VisibleOutput> Format: (enable disable) Possible values: - enable : external alarm output is visible - disable : external alarm output is non-visible	<i>optional parameter with default value: "disable"</i> trigger a visible alarm for external alarm 5
[no] audible5	Parameter type: <Alarm::AudibleOutput> Format: (enable disable) Possible values: - enable : external alarm output is audible - disable : external alarm output is non-audible	<i>optional parameter with default value: "disable"</i> trigger a audible alarm for external alarm 5
[no] polarity5	Parameter type: <Alarm::InversePolarity> Format: (normal inverse) Possible values: - normal : alarm polarity is normal - inverse : alarm polarity is inverse	<i>optional parameter with default value: "normal"</i> alarm polarity is normal or inverse for external alarm 5
[no] severity5	Parameter type: <Alarm::AlarmSeverity> Format: (indeterminate warning minor major critical) Possible values: - indeterminate : alarm severity is indeterminate - warning : alarm severity is warning - minor : alarm severity is minor - major : alarm severity is major - critical : alarm severity is critical	<i>optional parameter with default value: "major"</i> severity level of external alarm 5

3.8 HGU TR069 Customizable Alarm Configuration Command

Command Description

This command allows the operator to configure the HGU TR069 customizable alarms.

User Level

The command can be accessed by operators with alarm privileges, and executed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> configure alarm ( no hgu069-cust (alarm-id) ) | ( hgu069-cust (alarm-id) description <GPON::CustAlmDesc> )
```

Command Parameters

Table 3.8-1 "HGU TR069 Customizable Alarm Configuration Command" Resource Parameters

Resource Identifier	Type	Description
(alarm-id)	Format: - HGU TR069 customizable alarm Id - range: [1...31]	HGU TR069 customizable alarm Id

Table 3.8-2 "HGU TR069 Customizable Alarm Configuration Command" Command Parameters

Parameter	Type	Description
description	Parameter type: <GPON::CustAlmDesc> Format: - alarm description - length: 1<=x<=64	<i>mandatory parameter</i> alarm description

4- Trap Configuration Commands

4.1 Trap Configuration Command Tree	4-289
4.2 Trap Definition Configuration Command	4-292
4.3 Trap Manager Configuration Command	4-295
4.4 Trap Manager Configuration Command	4-300

4.1 Trap Configuration Command Tree

Description

This chapter gives an overview of nodes that are handled by "Trap Configuration Commands".

Command Tree

```

----configure
  ----trap
    ----definition
      - (name)
      - priority
    ----[no] manager
      - (address)
      - [no] priority
      - [no] cold-start-trap
      - [no] link-down-trap
      - [no] link-up-trap
      - [no] auth-fail-trap
      - [no] change-trap
      - [no] line-test-trap
      - [no] init-started-trap
      - [no] lic-key-chg-occr
      - [no] topology-chg
      - [no] selt-state-chg
      - [no] dhcp-sess-pre
      - [no] alarm-chg-trap
      - [no] phys-line-trap
      - [no] eqpt-change-trap
      - [no] success-set-trap
      - [no] other-alarm-trap
      - [no] warning-trap
      - [no] minor-trap
      - [no] major-trap
      - [no] critical-trap
      - [no] redundancy-trap
      - [no] eqpt-prot-trap
      - [no] craft-login-trap
      - [no] restart-trap
      - [no] ntr-trap
      - [no] rad-srvr-fail
      - [no] login-occr-trap
      - [no] logout-occr-trap
      - [no] trapmgr-chg-trap
      - [no] mst-genral
      - [no] mst-error
      - [no] mst-protocol-mig
      - [no] mst-inv-bpdu-rx
      - [no] mst-reg-conf-chg
      - [no] dying-gasp
      - [no] alrm-chg-occur
      - [no] mac-auth-fail

```

4 Trap Configuration Commands

- [no] new-ont-alm
- [no] ont-prov-status
- [no] outofsync
- [no] actual-cp-changed
- [no] register-node
- [no] avail-bw-changed
- [no] login-occr6-trap
- [no] logout-occr6-trap
- [no] trapmgr-chg6-trap
- [no] ont-prov-template
- [no] auto-replan-board
- [no] max-per-window
- [no] window-size
- [no] max-queue-size
- [no] min-interval
- [no] min-severity
- [no] v6manager
- (ipv6address)
- [no] priority
- [no] cold-start-trap
- [no] link-down-trap
- [no] link-up-trap
- [no] auth-fail-trap
- [no] change-trap
- [no] line-test-trap
- [no] init-started-trap
- [no] lic-key-chg-occr
- [no] topology-chg
- [no] selt-state-chg
- [no] dhcp-sess-pre
- [no] alarm-chg-trap
- [no] phys-line-trap
- [no] eqpt-change-trap
- [no] success-set-trap
- [no] other-alarm-trap
- [no] warning-trap
- [no] minor-trap
- [no] major-trap
- [no] critical-trap
- [no] redundancy-trap
- [no] eqpt-prot-trap
- [no] craft-login-trap
- [no] restart-trap
- [no] ntr-trap
- [no] rad-srvr-fail
- [no] login-occr-trap
- [no] logout-occr-trap
- [no] trapmgr-chg-trap
- [no] mst-genral
- [no] mst-error
- [no] mst-protocol-mig
- [no] mst-inv-bpdu-rx
- [no] mst-reg-conf-chg
- [no] dying-gasp
- [no] actual-cp-changed
- [no] register-node
- [no] avail-bw-changed
- [no] alrm-chg-occur

- [no] mac-auth-fail
- [no] outofsync
- [no] new-ont-alm
- [no] ont-prov-status
- [no] login-occr6-trap
- [no] logout-occr6-trap
- [no] trapmgr-chg6-trap
- [no] ont-prov-template
- [no] max-per-window
- [no] window-size
- [no] max-queue-size
- [no] min-interval
- [no] min-severity

4.2 Trap Definition Configuration Command

Command Description

This command allows the operator to define the priority of a given trap.

User Level

The command can be accessed by operators with alarm privileges, and executed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> configure trap definition (name) [ priority <Trap::Priority> ]
```

Command Parameters

Table 4.2-1 "Trap Definition Configuration Command" Resource Parameters

Resource Identifier	Type	Description
(name)	Format: (cold-start link-down link-up auth-failure change-occured line-test-report init-started lic-key-chg-occr topology-chg selt-state-chg dhcp-sess-pre radius-server-failure login-occured logout-occured trapmgr-chg-occr mst-genral mst-error mst-protocol-mig mst-inv-bpdu-rx mst-reg-conf-chg alrm-change-occured out-of-sync actual-cp-changed avail-bw-changed mac-auth-failure new-ont-alm ont-prov-status	the name of the trap

Resource Identifier	Type	Description
	sw-upgrade-finished login-occuredv6 logout-occuredv6 trapmgr-chg-occrv6 ont-prov-template auto-replan-board) Possible values: - cold-start : the node is reinitializing - link-down : one of the communication links of the node has failed - link-up : one of the communication links of the node became operational - auth-failure : authentication failure - change-occured : a configuration or operational change occurred - line-test-report : line test result available - init-started : the node is initializing, IP connectivity is established - lic-key-chg-occr : the number of license keys changed - topology-chg : topology changed (scope of cluster management) - selt-state-chg : selt test finished and results available - dhcp-sess-pre : dhcp session preempted - radius-server-failure : radius server failed - login-occured : login occurred - logout-occured : logout occurred - trapmgr-chg-occr : trap manager change occurred - mst-genral : mstp general events - mst-error : mstp error events - mst-protocol-mig : mstp port protocol migration - mst-inv-bpdu-rx : mstp invalid packet received - mst-reg-conf-chg : mstp region configuration change - alrm-change-occured : alarm change occurred - out-of-sync : trap is out of sync - actual-cp-changed : actual channelpair changed trap - avail-bw-changed : available bandwidth changed trap - mac-auth-failure : mac auth failure trap - new-ont-alrm : new ont alarm trap - ont-prov-status : ont auto provision status trap - sw-upgrade-finished : Board software upgrade finished trap - login-occuredv6 : login occurred - logout-occuredv6 : logout occurred - trapmgr-chg-occrv6 : trap manager change occurred - ont-prov-template : ont auto provision template trap - auto-replan-board : automatic board re-planning trap	

Table 4.2-2 "Trap Definition Configuration Command" Command Parameters

Parameter	Type	Description
priority	Parameter type: <Trap::Priority> Format: (urgent high medium low) Possible values: - urgent : urgent - needs to be informed immediately	<i>optional parameter</i> the trap priority

4 Trap Configuration Commands

Parameter	Type	Description
	- high : high priority trap - medium : medium priority trap - low : low priority trap	

4.3 Trap Manager Configuration Command

Command Description

This command allows the operator to configure an SNMP manager, which will receive traps when an event occurs in the system.

The SNMP manager can easily be flooded by events if something happens to the system. This command allows the operator to specify which traps the manager is interested in (trap filtering) and how the traps must be distributed in time (trap shaping).

Traps that cannot be delivered will be dropped.

The Following traps will be sent as a part of changeOccuredTrap alarm-chg-trap, phys-line-trap, eqpt-change-trap, success-set-trap, other-alarm-trap, warning-trap, minor-trap, major-trap, critical-trap, redundancy-trap, eqpt-prot-trap, craft-login-trap, restart-trap, ntr-trap.

User Level

The command can be accessed by operators with alarm privileges, and executed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> configure trap ( no manager (address) ) | ( manager (address) [ no priority | priority <Trap::Priority> ] [ [ no ] cold-start-trap ] [ [ no ] link-down-trap ] [ [ no ] link-up-trap ] [ [ no ] auth-fail-trap ] [ [ no ] change-trap ] [ [ no ] line-test-trap ] [ [ no ] init-started-trap ] [ [ no ] lic-key-chg-occr ] [ [ no ] topology-chg ] [ [ no ] self-state-chg ] [ [ no ] dhcp-sess-pre ] [ [ no ] alarm-chg-trap ] [ [ no ] phys-line-trap ] [ [ no ] eqpt-change-trap ] [ [ no ] success-set-trap ] [ [ no ] other-alarm-trap ] [ [ no ] warning-trap ] [ [ no ] minor-trap ] [ [ no ] major-trap ] [ [ no ] critical-trap ] [ [ no ] redundancy-trap ] [ [ no ] eqpt-prot-trap ] [ [ no ] craft-login-trap ] [ [ no ] restart-trap ] [ [ no ] ntr-trap ] [ [ no ] rad-srvr-fail ] [ [ no ] login-occr-trap ] [ [ no ] logout-occr-trap ] [ [ no ] trapmgr-chg-trap ] [ [ no ] mst-genral ] [ [ no ] mst-error ] [ [ no ] mst-protocol-mig ] [ [ no ] mst-inv-bpdu-rx ] [ [ no ] mst-reg-conf-chg ] [ [ no ] dying-gasp ] [ [ no ] alrm-chg-occur ] [ [ no ] mac-auth-fail ] [ [ no ] new-ont-alm ] [ [ no ] ont-prov-status ] [ [ no ] outofsync ] [ [ no ] actual-cp-changed ] [ [ no ] register-node ] [ [ no ] avail-bw-changed ] [ [ no ] login-occr6-trap ] [ [ no ] logout-occr6-trap ] [ [ no ] trapmgr-chg6-trap ] [ [ no ] ont-prov-template ] [ [ no ] auto-replan-board ] [ no max-per-window | max-per-window <Trap::WindowCount> ] [ no window-size | window-size <Trap::WindowSize> ] [ no max-queue-size | max-queue-size <Trap::QueueSize> ] [ no min-interval | min-interval <Trap::Interval> ] [ no min-severity | min-severity <Alarm::alarmSeverityReport> ] )
```

Command Parameters

Table 4.3-1 "Trap Manager Configuration Command" Resource Parameters

Resource Identifier	Type	Description
(address)	Format: <Ip::V4Address> : <Trap::Port> Field type <Ip::V4Address> - IPv4-address Field type <Trap::Port> - trap port number	the address of the manager

4 Trap Configuration Commands

Resource Identifier	Type	Description
	- range: [1...65535]	

Table 4.3-2 "Trap Manager Configuration Command" Command Parameters

Parameter	Type	Description
[no] priority	Parameter type: <Trap::Priority> Format: (urgent high medium low) Possible values: - urgent : urgent - needs to be informed immediately - high : high priority trap - medium : medium priority trap - low : low priority trap	<i>optional parameter with default value: "medium"</i> lowest priority a trap should have to be reported
[no] cold-start-trap	Parameter type: boolean	<i>optional parameter</i> enable sending cold start trap
[no] link-down-trap	Parameter type: boolean	<i>optional parameter</i> enable sending link down trap
[no] link-up-trap	Parameter type: boolean	<i>optional parameter</i> enable sending of link up trap
[no] auth-fail-trap	Parameter type: boolean	<i>optional parameter</i> enable sending authentication failure trap
[no] change-trap	Parameter type: boolean	<i>optional parameter</i> enable sending of change occurred trap
[no] line-test-trap	Parameter type: boolean	<i>optional parameter</i> enable line test report trap
[no] init-started-trap	Parameter type: boolean	<i>optional parameter</i> enable sending init started trap
[no] lic-key-chg-occr	Parameter type: boolean	<i>optional parameter</i> enable sending licence key changed occurred trap
[no] topology-chg	Parameter type: boolean	<i>optional parameter</i> enable sending topology changed occurred trap
[no] selt-state-chg	Parameter type: boolean	<i>optional parameter</i> enable sending selt state change trap
[no] dhcp-sess-pre	Parameter type: boolean	<i>optional parameter</i> enable sending DHCP session preempted trap
[no] alarm-chg-trap	Parameter type: boolean	<i>optional parameter</i> enable snd nbr alm chg(part of changeOccurredTrap)
[no] phys-line-trap	Parameter type: boolean	<i>optional parameter</i> enable snd phys line chg(part of changeOccurredTrap)
[no] eqpt-change-trap	Parameter type: boolean	<i>optional parameter</i> enable snd eqpt nbr chg(part of changeOccurredTrap)
[no] success-set-trap	Parameter type: boolean	<i>optional parameter</i> enable snd nbr of sets chg(part of changeOccurredTrap)
[no] other-alarm-trap	Parameter type: boolean	<i>optional parameter</i> enable snd nbr indeterminate

4 Trap Configuration Commands

Parameter	Type	Description
		chg(part of changeOccurredTrap)
[no] warning-trap	Parameter type: boolean	<i>optional parameter</i> enable snd nbr warning chg(part of changeOccurredTrap)
[no] minor-trap	Parameter type: boolean	<i>optional parameter</i> enable snd nbr minor chg(part of changeOccurredTrap)
[no] major-trap	Parameter type: boolean	<i>optional parameter</i> enable snd nbr major chg(part of changeOccurredTrap)
[no] critical-trap	Parameter type: boolean	<i>optional parameter</i> enable snd nbr critical chg(part of changeOccurredTrap)
[no] redundancy-trap	Parameter type: boolean	<i>optional parameter</i> enable snd nbr redundancy chg(part of changeOccurredTrap)
[no] eqpt-prot-trap	Parameter type: boolean	<i>optional parameter</i> enable snd nbr eqpt prot chg(part of changeOccurredTrap)
[no] craft-login-trap	Parameter type: boolean	<i>optional parameter</i> enable snd craft login chg(part of changeOccurredTrap)
[no] restart-trap	Parameter type: boolean	<i>optional parameter</i> enable restart trap(part of changeOccurredTrap)
[no] ntr-trap	Parameter type: boolean	<i>optional parameter</i> enable ntr changes trap(part of changeOccurredTrap)
[no] rad-srvr-fail	Parameter type: boolean	<i>optional parameter</i> enable sending radius server failure trap
[no] login-occr-trap	Parameter type: boolean	<i>optional parameter</i> enable sending login occurred trap
[no] logout-occr-trap	Parameter type: boolean	<i>optional parameter</i> enable sending logout occurred trap
[no] trapmngtr-chg-trap	Parameter type: boolean	<i>optional parameter</i> enable sending trap manager change occurred trap
[no] mst-genral	Parameter type: boolean	<i>optional parameter</i>
[no] mst-error	Parameter type: boolean	<i>optional parameter</i> enable mstp error events trap
[no] mst-protocol-mig	Parameter type: boolean	<i>optional parameter</i> enable mstp port protocol migration trap
[no] mst-inv-bpdu-rx	Parameter type: boolean	<i>optional parameter</i> enable mstp invalid packet received trap
[no] mst-reg-conf-chg	Parameter type: boolean	<i>optional parameter</i> enable mstp region configuration change trap
[no] dying-gasp	Parameter type: boolean	<i>optional parameter</i> enable dying gasp trap
[no] alrm-chg-occur	Parameter type: boolean	<i>optional parameter</i> enable alarm change occurred trap
[no] mac-auth-fail	Parameter type: boolean	<i>optional parameter</i> enable sending mac auth failure

4 Trap Configuration Commands

Parameter	Type	Description
		trap
[no] new-ont-alm	Parameter type: boolean	<i>optional parameter</i> enable new ont alarm trap
[no] ont-prov-status	Parameter type: boolean	<i>optional parameter</i> enable ont auto provision status trap
[no] outofsync	Parameter type: boolean	<i>optional parameter</i> enable outOfSync trap
[no] actual-cp-changed	Parameter type: boolean	<i>optional parameter</i> enable actual channelpair changed trap
[no] register-node	Parameter type: boolean	<i>optional parameter</i> enable register node trap
[no] avail-bw-changed	Parameter type: boolean	<i>optional parameter</i> enable available bandwidth changed trap
[no] login-occr6-trap	Parameter type: boolean	<i>optional parameter</i> enable sending Ipv6 login occurred trap
[no] logout-occr6-trap	Parameter type: boolean	<i>optional parameter</i> enable sending Ipv6 logout occurred trap
[no] trapmgr-chg6-trap	Parameter type: boolean	<i>optional parameter</i> enable sending Ipv6 trap manager change occurred trap
[no] ont-prov-template	Parameter type: boolean	<i>optional parameter</i> enable ont auto provision template trap
[no] auto-replan-board	Parameter type: boolean	<i>optional parameter</i> enable auto board replan trap
[no] max-per-window	Parameter type: <Trap::WindowCount> Format: - maximum allowed number of traps per window - unit: traps - range: [1...20]	<i>optional parameter with default value: 2</i> maximum allowed number of traps per window
[no] window-size	Parameter type: <Trap::WindowSize> Format: - the size of a time window for traps - unit: s - range: [0...3600]	<i>optional parameter with default value: 60</i> the size of a time window for traps in seconds
[no] max-queue-size	Parameter type: <Trap::QueueSize> Format: - maximum number of traps that can be queued - unit: traps - range: [1...20]	<i>optional parameter with default value: 10</i> maximum number of traps that can be queued
[no] min-interval	Parameter type: <Trap::Interval> Format: - minimum time interval between two traps - unit: s - range: [0...3600]	<i>optional parameter with default value: 30</i> the minimum time between two traps
[no] min-severity	Parameter type: <Alarm::alarmSeverityReport> Format: (indeterminate warning minor major critical)	<i>optional parameter with default value: "major"</i> lowest severity an alarm must have, to be reported

Parameter	Type	Description
	Possible values: - indeterminate : not a definite known severity level - warning : just to inform as a warning - minor : not service affecting - major : service affecting - critical : service breaking	

4.4 Trap Manager Configuration Command

Command Description

This command allows the operator to configure an SNMP manager, which will receive traps when an event occurs in the system.

The SNMP manager can easily be flooded by events if something happens to the system. This command allows the operator to specify which traps the manager is interested in (trap filtering) and how the traps must be distributed in time (trap shaping).

Traps that cannot be delivered will be dropped.

The Following traps will be sent as a part of changeOccuredTrap alarm-chg-trap, phys-line-trap, eqpt-change-trap, success-set-trap, other-alarm-trap, warning-trap, minor-trap, major-trap, critical-trap, redundancy-trap, eqpt-prot-trap, craft-login-trap, restart-trap, ntr-trap.

User Level

The command can be accessed by operators with alarm privileges, and executed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> configure trap ( no v6manager (ipv6address) ) | ( v6manager (ipv6address) [ no priority | priority <Trap::Priority>
] [ [ no ] cold-start-trap ] [ [ no ] link-down-trap ] [ [ no ] link-up-trap ] [ [ no ] auth-fail-trap ] [ [ no ] change-trap ]
[ [ no ] line-test-trap ] [ [ no ] init-started-trap ] [ [ no ] lic-key-chg-occr ] [ [ no ] topology-chg ] [ [ no ]
self-state-chg ] [ [ no ] dhcp-sess-pre ] [ [ no ] alarm-chg-trap ] [ [ no ] phys-line-trap ] [ [ no ] eqpt-change-trap ] [ [
no ] success-set-trap ] [ [ no ] other-alarm-trap ] [ [ no ] warning-trap ] [ [ no ] minor-trap ] [ [ no ] major-trap ] [ [
no ] critical-trap ] [ [ no ] redundancy-trap ] [ [ no ] eqpt-prot-trap ] [ [ no ] craft-login-trap ] [ [ no ] restart-trap ] [ [
no ] ntr-trap ] [ [ no ] rad-srvr-fail ] [ [ no ] login-occr-trap ] [ [ no ] logout-occr-trap ] [ [ no ] trapmgr-chg-trap ] [
[ no ] mst-genral ] [ [ no ] mst-error ] [ [ no ] mst-protocol-mig ] [ [ no ] mst-inv-bpdu-rx ] [ [ no ] mst-reg-conf-chg
] [ [ no ] dying-gasp ] [ [ no ] actual-cp-changed ] [ [ no ] register-node ] [ [ no ] avail-bw-changed ] [ [ no ]
almr-chg-occur ] [ [ no ] mac-auth-fail ] [ [ no ] outofsync ] [ [ no ] new-ont-almr ] [ [ no ] ont-prov-status ] [ [ no ]
login-occr6-trap ] [ [ no ] logout-occr6-trap ] [ [ no ] trapmgr-chg6-trap ] [ [ no ] ont-prov-template ] [ no
max-per-window | max-per-window <Trap::WindowCount> ] [ no window-size | window-size
<Trap::WindowSize> ] [ no max-queue-size | max-queue-size <Trap::QueueSize> ] [ no min-interval | min-interval
<Trap::Interval> ] [ no min-severity | min-severity <Alarm::alarmSeverityReport> ] )
```

Command Parameters

Table 4.4-1 "Trap Manager Configuration Command" Resource Parameters

Resource Identifier	Type	Description
(ipv6address)	Format: <ipv6::Prefix> / <Trap::Port> Field type <ipv6::Prefix> - IPv6-address Field type <Trap::Port> - trap port number	the address of the manager

Resource Identifier	Type	Description
	- range: [1...65535]	

Table 4.4-2 "Trap Manager Configuration Command" Command Parameters

Parameter	Type	Description
[no] priority	Parameter type: <Trap::Priority> Format: (urgent high medium low) Possible values: - urgent : urgent - needs to be informed immediately - high : high priority trap - medium : medium priority trap - low : low priority trap	<i>optional parameter with default value: "medium"</i> lowest priority a trap should have to be reported
[no] cold-start-trap	Parameter type: boolean	<i>optional parameter</i> enable sending cold start trap
[no] link-down-trap	Parameter type: boolean	<i>optional parameter</i> enable sending link down trap
[no] link-up-trap	Parameter type: boolean	<i>optional parameter</i> enable sending of link up trap
[no] auth-fail-trap	Parameter type: boolean	<i>optional parameter</i> enable sending authentication failure trap
[no] change-trap	Parameter type: boolean	<i>optional parameter</i> enable sending of change occurred trap
[no] line-test-trap	Parameter type: boolean	<i>optional parameter</i> enable line test report trap
[no] init-started-trap	Parameter type: boolean	<i>optional parameter</i> enable sending init started trap
[no] lic-key-chg-occr	Parameter type: boolean	<i>optional parameter</i> enable sending licence key changed occurred trap
[no] topology-chg	Parameter type: boolean	<i>optional parameter</i> enable sending topology changed occurred trap
[no] selt-state-chg	Parameter type: boolean	<i>optional parameter</i> enable sending selt state change trap
[no] dhcp-sess-pre	Parameter type: boolean	<i>optional parameter</i> enable sending DHCP session preempted trap
[no] alarm-chg-trap	Parameter type: boolean	<i>optional parameter</i> enable snd nbr alm chg(part of changeOccurredTrap)
[no] phys-line-trap	Parameter type: boolean	<i>optional parameter</i> enable snd phys line chg(part of changeOccurredTrap)
[no] eqpt-change-trap	Parameter type: boolean	<i>optional parameter</i> enable snd eqpt nbr chg(part of changeOccurredTrap)
[no] success-set-trap	Parameter type: boolean	<i>optional parameter</i> enable snd nbr of sets chg(part of changeOccurredTrap)
[no] other-alarm-trap	Parameter type: boolean	<i>optional parameter</i> enable snd nbr indeterminate

4 Trap Configuration Commands

Parameter	Type	Description
		chg(part of changeOccurredTrap)
[no] warning-trap	Parameter type: boolean	<i>optional parameter</i> enable snd nbr warning chg(part of changeOccurredTrap)
[no] minor-trap	Parameter type: boolean	<i>optional parameter</i> enable snd nbr minor chg(part of changeOccurredTrap)
[no] major-trap	Parameter type: boolean	<i>optional parameter</i> enable snd nbr major chg(part of changeOccurredTrap)
[no] critical-trap	Parameter type: boolean	<i>optional parameter</i> enable snd nbr critical chg(part of changeOccurredTrap)
[no] redundancy-trap	Parameter type: boolean	<i>optional parameter</i> enable snd nbr redundancy chg(part of changeOccurredTrap)
[no] eqpt-prot-trap	Parameter type: boolean	<i>optional parameter</i> enable snd nbr eqpt prot chg(part of changeOccurredTrap)
[no] craft-login-trap	Parameter type: boolean	<i>optional parameter</i> enable snd craft login chg(part of changeOccurredTrap)
[no] restart-trap	Parameter type: boolean	<i>optional parameter</i> enable restart trap(part of changeOccurredTrap)
[no] ntr-trap	Parameter type: boolean	<i>optional parameter</i> enable ntr changes trap(part of changeOccurredTrap)
[no] rad-srvr-fail	Parameter type: boolean	<i>optional parameter</i> enable sending radius server failure trap
[no] login-occr-trap	Parameter type: boolean	<i>optional parameter</i> enable sending login occurred trap
[no] logout-occr-trap	Parameter type: boolean	<i>optional parameter</i> enable sending logout occurred trap
[no] trapmng-chg-trap	Parameter type: boolean	<i>optional parameter</i> enable sending trap manager change occurred trap
[no] mst-genral	Parameter type: boolean	<i>optional parameter</i>
[no] mst-error	Parameter type: boolean	<i>optional parameter</i> enable mstp error events trap
[no] mst-protocol-mig	Parameter type: boolean	<i>optional parameter</i> enable mstp port protocol migration trap
[no] mst-inv-bpdu-rx	Parameter type: boolean	<i>optional parameter</i> enable mstp invalid packet received trap
[no] mst-reg-conf-chg	Parameter type: boolean	<i>optional parameter</i> enable mstp region configuration change trap
[no] dying-gasp	Parameter type: boolean	<i>optional parameter</i> enable dying gasp trap
[no] actual-cp-changed	Parameter type: boolean	<i>optional parameter</i> enable actual channelpair changed trap
[no] register-node	Parameter type: boolean	<i>optional parameter</i>

4 Trap Configuration Commands

Parameter	Type	Description
		enable register node trap
[no] avail-bw-changed	Parameter type: boolean	<i>optional parameter</i> enable available bandwidth changed trap
[no] alrm-chg-occur	Parameter type: boolean	<i>optional parameter</i> enable alarm change occurred trap
[no] mac-auth-fail	Parameter type: boolean	<i>optional parameter</i> enable sending mac auth failure trap
[no] outofsync	Parameter type: boolean	<i>optional parameter</i> enable outOfSync trap
[no] new-ont-alrm	Parameter type: boolean	<i>optional parameter</i> enable new ont alarm trap
[no] ont-prov-status	Parameter type: boolean	<i>optional parameter</i> enable ont auto provision status trap
[no] login-occr6-trap	Parameter type: boolean	<i>optional parameter</i> enable sending Ipv6 login occurred trap
[no] logout-occr6-trap	Parameter type: boolean	<i>optional parameter</i> enable sending Ipv6 logout occurred trap
[no] trapmgr-chg6-trap	Parameter type: boolean	<i>optional parameter</i> enable sending Ipv6 trap manager change occurred trap
[no] ont-prov-template	Parameter type: boolean	<i>optional parameter</i> enable ont auto provision template trap
[no] max-per-window	Parameter type: <Trap::WindowCount> Format: - maximum allowed number of traps per window - unit: traps - range: [1...20]	<i>optional parameter with default value: 2</i> maximum allowed number of traps per window
[no] window-size	Parameter type: <Trap::WindowSize> Format: - the size of a time window for traps - unit: s - range: [0...3600]	<i>optional parameter with default value: 60</i> the size of a time window for traps in seconds
[no] max-queue-size	Parameter type: <Trap::QueueSize> Format: - maximum number of traps that can be queued - unit: traps - range: [1...20]	<i>optional parameter with default value: 10</i> maximum number of traps that can be queued
[no] min-interval	Parameter type: <Trap::Interval> Format: - minimum time interval between two traps - unit: s - range: [0...3600]	<i>optional parameter with default value: 30</i> the minimum time between two traps
[no] min-severity	Parameter type: <Alarm::alarmSeverityReport> Format: (indeterminate warning minor major critical) Possible values: - indeterminate : not a definite known severity level	<i>optional parameter with default value: "major"</i> lowest severity an alarm must have, to be reported

4 Trap Configuration Commands

Parameter	Type	Description
	- warning : just to inform as a warning - minor : not service affecting - major : service affecting - critical : service breaking	

5- Equipment Configuration Commands

5.1 Equipment Configuration Command Tree	5-306
5.2 Rack Configuration Command	5-309
5.3 Shelf Configuration Command	5-310
5.4 Slot Configuration Command	5-312
5.5 Applique Configuration Command	5-315
5.6 Protection Group Configuration Command	5-317
5.7 Protection Element Configuration Command	5-318
5.8 External-link-host Configuration Commands	5-320
5.9 Host Shelf SFP Configuration Commands	5-322
5.10 SFP/XFP Diagnostics configuration Command	5-324
5.11 Sfp RSSI Configuration Command	5-327
5.12 2xE1/DS1 CLOCK configuration Command	5-332
5.13 2xE1/DS1 Pseudo Wire TDM Interface configuration Command	5-334
5.14 2xE1/DS1 Pseudo Wire TDM SFP configuration Command	5-336
5.15 2xE1/DS1 Framer configuration Command	5-339
5.16 2xE1/DS1 Line Interface Unit SFP configuration Command	5-343
5.17 NE Configuration Command	5-346
5.18 Environment Monitoring Configuration Command	5-347
5.19 Configure Fan Tray parameters	5-348
5.20 Configure Board Auto Replan feature	5-349

5.1 Equipment Configuration Command Tree

Description

This chapter gives an overview of nodes that are handled by "Equipment Configuration Commands".

Command Tree

- configure**
 - equipment**
 - rack**
 - (index)
 - [no] description
 - shelf**
 - (index)
 - [no] class
 - [no] planned-type
 - [no] lock
 - X [no] extended-lt-slots
 - [no] mode
 - [no] description
 - slot**
 - (index)
 - [no] planned-type
 - [no] power-down
 - [no] unlock
 - [no] alarm-profile
 - [no] capab-profile
 - [no] board-40gkr4
 - [no] operational-mode
 - [no] dual-host-ip
 - [no] dual-host-loc
 - applique**
 - (index)
 - [no] planned-type
 - [no] applique-profile
 - protection-group**
 - (prot-group-id)
 - [no] admin-status
 - [no] eps-quenchfactor
 - protection-element**
 - (index)
 - [no] redcy-ctrl-status
 - external-link-host**
 - (faceplate-number)
 - [no] direction
 - external-link-assign**
 - (index)
 - [no] remote
 - diagnostics**
 - sfp**
 - (position)
 - [no] rssi-prof-id

```

- [no] rssi-state
----[no] rssiprof
- (index)
- name
- [no] temp-alm-low
- [no] temp-alm-high
- [no] temp-warn-low
- [no] temp-warn-high
- [no] voltage-alm-low
- [no] voltage-alm-high
- [no] voltage-warn-low
- [no] voltage-warn-high
- [no] bias-alm-low
- [no] bias-alm-high
- [no] bias-warn-low
- [no] bias-warn-high
- [no] tx-pwr-alm-low
- [no] tx-pwr-alm-high
- [no] tx-pwr-warn-low
- [no] tx-pwr-warn-high
- [no] rx-pwr-alm-low
- [no] rx-pwr-alm-high
- [no] rx-pwr-warn-low
- [no] rx-pwr-warn-high
- [no] ebias-alm-low
- [no] ebias-alm-high
- [no] ebias-warn-low
- [no] ebias-warn-high
- [no] etx-alm-low
- [no] etx-alm-high
- [no] etx-warn-low
- [no] etx-warn-high
- [no] erx-alm-low
- [no] erx-alm-high
- [no] erx-warn-low
- [no] erx-warn-high
- [no] etemp-alm-low
- [no] etemp-alm-high
- [no] etemp-warn-low
- [no] etemp-warn-high
- [no] profile-type
----sfpe1t1
----[no] clock
- (position)
- [no] clocksource
----tdmintf
- (position)
- [no] window-number
- [no] window-length
----[no] pwtadm
- (position)
- channel
- packet-length
- jitter-buff-size
- vlanid
- priority
- conseq-number
- ecid-rx

```

- ecid-tx
- source-mac
- dest-mac
- framer**
 - **(position)**
 - [no] frame-mode
 - [no] iwf-on-liu
 - [no] liu-on-liu
 - [no] pm-to-iwf
 - [no] ais-to-iwf
 - [no] rai-to-iwf
 - [no] rei-to-iwf
 - [no] pm-to-liu
 - [no] ais-to-liu
 - [no] rai-to-liu
 - [no] rei-to-liu
- liu**
 - **(position)**
 - [no] distance
 - [no] cable-impedance
- isam**
 - [no] description
- envbox**
 - [no] enable-supervise
- fan-tray**
 - fanmode
- replan**
 - boardautoreplan

5.2 Rack Configuration Command

Command Description

This command allows the operator to configure the rack. The operator can configure the following parameter:

- *description*: text that describes the location of the rack.

User Level

The command can be accessed by operators with equipment privileges, and executed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

> configure equipment rack (index) [no description | description <Description-127>]

Command Parameters

Table 5.2-1 "Rack Configuration Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: <Eqpt::RackId> Field type <Eqpt::RackId> - the rack number	the physical position of the rack

Table 5.2-2 "Rack Configuration Command" Command Parameters

Parameter	Type	Description
[no] description	Parameter type: <Description-127> Format: - description to help the operator to identify the object - length: x<=127	<i>optional parameter with default value: ""</i> any description to be used by the operator

5.3 Shelf Configuration Command

Command Description

This command allows the operator to configure the shelf. The operator can configure the following parameters:

- **class:** the classification of the shelf. The following shelf classes are supported:
 - **main-ethernet:** supports Ethernet-based traffic. Shelves in this class can contain NT and LT units. There must be at least one shelf of this class in the system.
 - **ext-ethernet:** supports Ethernet-based traffic. Shelves in this class can only contain LT units.
- **planned-type:** the type planned for this shelf. The **not-planned** parameter indicates that a shelf will not be inserted at this position.
- **lock:** locks or unlocks the shelf.
- **shelf-mode:** the shelf mode. When the shelf mode was changed successfully, the NE will reboot automatically.
- **description:** text that describes the location of the shelf.

User Level

The command can be accessed by operators with equipment privileges, and executed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

```
> configure equipment shelf (index) [ no class | class <Equipm::ShelfClass> ] [ no planned-type | planned-type
<Equipm::ShelfType> ] [ [ no ] lock ] [ [ no ] extended-lt-slots ] [ no mode | mode <Equipm::HolderMode> ] [ no
description | description <Description-127> ]
```

Command Parameters

Table 5.3-1 "Shelf Configuration Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: <Eqpt::RackId> / <Eqpt::ShelfId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number	the physical identification of the shelf

Table 5.3-2 "Shelf Configuration Command" Command Parameters

Parameter	Type	Description
[no] class	Parameter type: <Equipm::ShelfClass> Format: (main-ethernet ext-ethernet) Possible values: - main-ethernet : main shelf - supports ethernet-based traffic - ext-ethernet : extension shelf - supports ethernet-based	optional parameter with default value: "main-ethernet" the class to which the shelf belongs

Parameter	Type	Description
	traffic	
[no] planned-type	Parameter type: <Equipm::ShelfType> Format: Data driven field type Possible values are depending on the actual configuration and software. The currently allowed values can be shown with online-help.	<i>optional parameter with default value: "not-planned"</i> the planned type of the shelf
[no] lock	Parameter type: boolean	<i>optional parameter</i> the holder is locked
[no] extended-lt-slots	Parameter type: boolean	<i>obsolete parameter replaced by parameter "mode"</i> change to extended lt slots
[no] mode	Parameter type: <Equipm::HolderMode> Format: (no-extended-lt-slots extended-lt-slots no-ntb-slot no-extended-slots no-ntio-slots ngpon gpon ngpon-port-reduced gpon-mng-ngpon gpon-mng-reduced) Possible values: - no-extended-lt-slots : no extended lt slots - extended-lt-slots : change to extended lt slots - no-ntb-slot : use ntb slot as lt slot - no-extended-slots : no extended slots - no-ntio-slots : not changeable - ngpon : use universal ngpon lt (supports NG-PON2, XGS-PON and XG-PON1 currently) - gpon : use gpon lt - ngpon-port-reduced : use ngpon port reduced mode lt (supports ERPS) - gpon-mng-ngpon : use gpon managed ngpon management model - gpon-mng-reduced : use gpon managed ngpon port reduced mode lt(supports ERPS)	<i>optional parameter with default value: "no-extended-lt-slots"</i> the shelf mode, applicable to NEP and ARAM-E only
[no] description	Parameter type: <Description-127> Format: - description to help the operator to identify the object - length: x<=127	<i>optional parameter with default value: ""</i> any description to be used by the operator

5.4 Slot Configuration Command

Command Description

This command allows the operator to configure a slot.

The slot is identified by the physical slot number. The left-most slot in the shelf is number 1. The following parameters can be configured for the slot:

- **planned-type**: the unit type that will be inserted into the slot. The **not-planned** parameter indicates that a unit will not be inserted into that slot.
- **power-down**: the operator can power-up or power-down slots. This is only applicable to LSM.
- **unlock**: the operator can lock or unlock a unit. A unit in the locked state cannot be used. This attribute is only supported for the NT (the system will refuse to lock the NT of a simplex system), EXT, and a managed LSM. This attribute is not applicable to sealed remote products (7367 SX).
- **alarm-profile**: the operator can assign a customizable alarm profile to a NT or LSM board. This is applicable for all NTs and LSMs.
- **capab-profile**: This parameter only applies to LSMs, NTIOs and mini-NT NRNT-A. For BCM based LSM boards default capab-profile is "default" for Intel based LSM boards it is "8vc_default".
- **disable-key**: This Parameter should contain string between 8 and 16 characters; must contain at least one lowercase letter, one uppercase letter, one numeric digit, and one special character, but cannot contain whitespace.

User Level

The command can be accessed by operators with equipment privileges, and executed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

```
> configure equipment slot (index) [ no planned-type | planned-type <Equipm::BoardType> ] [ [ no ] power-down ]
[ [ no ] unlock ] [ no alarm-profile | alarm-profile <Equipm::AlarmProf> ] [ no capab-profile | capab-profile
<Equipm::CapabilityProfile> ] [ no board-40gkr4 | board-40gkr4 <Equipm::board40GKR4> ] [ no
operational-mode | operational-mode <Equipm::OperationalMode> ] [ no dual-host-ip | dual-host-ip
<Ip::V4Address> ] [ no dual-host-loc | dual-host-loc <Equipm::Dualhost> ]
```

Command Parameters

Table 5.4-1 "Slot Configuration Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: (lt : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> nt-a nt-b nt acu : <Eqpt::RackId> / <Eqpt::ShelfId> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::EqSlotId> ext-a : <Eqpt::RackId> / <Eqpt::ShelfId>	the physical number of the slot

Resource Identifier	Type	Description
	<pre> ext-b : <Eqpt::RackId> / <Eqpt::ShelfId> ctrl : <Eqpt::RackId> / <Eqpt::ShelfId> vlt : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::VirtualSlotId>) Possible values: - lt : lt-slot - vlt : virtual LT slot (VVPS board can only be planned at NANT-E / FANT-F) - nt-a : nt-a slot - nt-b : nt-b slot - nt : nt slot - ext-a : nt-a slot in an extension shelf - ext-b : nt-b slot in an extension shelf - acu : acu slot - ctrl : ctrl-slot Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::VirtualSlotId> - the virtual LT slot number Field type <Eqpt::EqSlotId> - the equipment slot number </pre>	

Table 5.4-2 "Slot Configuration Command" Command Parameters

Parameter	Type	Description
[no] planned-type	Parameter type: <Equipm::BoardType> Format: Data driven field type Possible values are depending on the actual configuration and software. The currently allowed values can be shown with online-help.	<i>optional parameter with default value: "not-planned"</i> type of board intended to be in this position
[no] power-down	Parameter type: boolean	<i>optional parameter</i> power down the board
[no] unlock	Parameter type: boolean	<i>optional parameter</i> unlock the board
[no] alarm-profile	Parameter type: <Equipm::AlarmProf> Format: (none name : <PrintableString-0-32>) Possible values: - none : no profile name to associate - name : profile name Field type <PrintableString-0-32> - a printable string - length: x<=32	<i>optional parameter with default value: "none"</i> customized alarm profile assigned to this board
[no] capab-profile	Parameter type: <Equipm::CapabilityProfile> Format: Data driven field type Possible values are depending on the actual configuration and software. The currently allowed values can be shown with online-help.	<i>optional parameter with default value: "not_applicable"</i> capability profile assigned to a line board
[no] board-40gkr4	Parameter type: <Equipm::board40GKR4> Format: (inherited	<i>optional parameter with default value: "inherited"</i> inherited, disable or enable board

5 Equipment Configuration Commands

Parameter	Type	Description
	disable enable) Possible values: - inherited : enable or disable 40G KR4 of the board is controlled by system level parameter - disable : the board should not work in 40GKR4 no matter the value of system level - enable : the board should work in 40GKR4 no matter the value of system level	40GKR4
[no] operational-mode	Parameter type: <Equipm::OperationalMode> Format: (not-set gpon xgs mpm-gpon-xgs dual-gpon u-ngpon twenty-five-g ng-pon2 mpm-gpon-xgpon) Possible values: - not-set : cage mode not-set - gpon : cage mode set to gpon - xgs : cage mode set to xgs - mpm-gpon-xgs : cage mode set to mpm-gpon-xgs - dual-gpon : cage mode set to dual-gpon - u-ngpon : cage mode set to u-ngpon - twenty-five-g : cage mode set to 25g - ng-pon2 : cage mode set to ng-pon2 - mpm-gpon-xgpon : cage mode set to mpm-gpon-xgpon	<i>optional parameter with default value: "not-set"</i> operation mode of the cage
[no] dual-host-ip	Parameter type: <Ip::V4Address> Format: - IPv4-address	<i>optional parameter with default value: "0.0.0.0"</i> dual host ip
[no] dual-host-loc	Parameter type: <Equipm::Dualhost> Format: (<Eqpt::MultiRackId> / <Eqpt::MultiShelfId> none) Possible values: - none : no host lsm location Field type <Eqpt::MultiRackId> - the rack number Field type <Eqpt::MultiShelfId> - the shelf number	<i>optional parameter with default value: "none"</i> dual host lsm location

5.5 Applique Configuration Command

Command Description

This command allows the operator to configure an applique.

The applique is identified by the physical slot number. The left-most slot in the shelf is number 1. The following parameter can be configured for the slot:

- planned-type: the applique type to be inserted into the slot. The **not-planned** parameter indicates that an applique will not be inserted into that slot.

User Level

The command can be accessed by operators with equipment privileges, and executed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

```
> configure equipment applique (index) [ no planned-type | planned-type <Equipm::AppliqueType> ] [ no
applique-profile | applique-profile <Equipm::CapabilityProfile> ]
```

Command Parameters

Table 5.5-1 "Applique Configuration Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: (iont : <Eqpt::RackId> / <Eqpt::ShelfId> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::AppliqueSlotId> lp : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::LtAppliqueSlotId> ntio-1 ntio-2) Possible values: - iont : an nt applique slot - lp : an lt applique slot - ntio-1 : an nt applique slot in a single or multiple-ntio-shelf - ntio-2 : an nt applique slot in a multiple-ntio-shelf Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::AppliqueSlotId> - the applique slot number Field type <Eqpt::LtAppliqueSlotId> - the LT Applique slot number	the physical number of the applique

Table 5.5-2 "Applique Configuration Command" Command Parameters

Parameter	Type	Description
[no] planned-type	Parameter type: <Equipm::AppliqueType> Format: Data driven field type Possible values are depending on the actual configuration and software. The currently allowed values can be shown with online-help.	<i>optional parameter with default value: "not-planned"</i> type of applique intended to be in this position
[no] applique-profile	Parameter type: <Equipm::CapabilityProfile> Format: Data driven field type Possible values are depending on the actual configuration and software. The currently allowed values can be shown with online-help.	<i>optional parameter with default value: "not_applicable"</i> capability profile assigned to the applique board

5.6 Protection Group Configuration Command

Command Description

This command allows the operator to configure a protection group.

The protection group is identified by the eqptProtGroupId attribute (index). The value 1 is reserved for extension chain protection group which is always present and cannot be deleted.

The protection group(s) are created implicitly by the system as part of the default configuration. Use "show equipment protection-group" to display the valid protection group identifier(s). Note that the default admin-status for protection-group 1 at system level is locked where it is always unlocked at cli level.

User Level

The command can be accessed by operators with equipment privileges, and executed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

```
> configure equipment protection-group (prot-group-id) [ no admin-status | admin-status
<Equipm::PortGroupAdminStatus> ] [ no eps-quenchfactor | eps-quenchfactor <Equipm::TimeTicks> ]
```

Command Parameters

Table 5.6-1 "Protection Group Configuration Command" Resource Parameters

Resource Identifier	Type	Description
(prot-group-id)	Format: - index of protection group - range: [1...109]	Index in eqpt Prot Group Table

Table 5.6-2 "Protection Group Configuration Command" Command Parameters

Parameter	Type	Description
[no] admin-status	Parameter type: <Equipm::PortGroupAdminStatus> Format: (unlock lock) Possible values: - unlock : unlock - lock : lock	<i>optional parameter with default value: "unlock"</i> changes the administrative-status to lock or unlock
[no] eps-quenchfactor	Parameter type: <Equipm::TimeTicks> Format: - timer value for quench mechanish - unit: 1/100 sec	<i>optional parameter with default value: "1440000"</i> timervalue of quenching mechanism(unit: 1/100sec), 0 is valid value

5.7 Protection Element Configuration Command

Command Description

This command allows the operator to configure a protection element.

The protection group is identified by the `eqptProtGroupId` attribute. The value 1 to 9 are reserved for the extension chain protection group which are always present and cannot be deleted. Group 1 corresponding with NT 1+1 group, and Group 2-9 corresponding with possible 8 LT 1+1 groups.

The `redcy-ctrl-status` parameter is used to force a switchover between elements of a protection group or to keep one of the elements active. The **forced-active** parameter indicates that the NTA or NTB slot or LT slot is configured as active.

User Level

The command can be accessed by operators with equipment privileges, and executed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

```
> configure equipment protection-element (index) [ no redcy-ctrl-status | redcy-ctrl-status
<Equipm::ProtElementRedcyCtrlStatus> ]
```

Command Parameters

Table 5.7-1 "Protection Element Configuration Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: (lt : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> nt-a nt-b <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::EqSlotId> vlt : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::VirtualSlotId>) Possible values: - lt : lt-slot - vlt : virtual LT slot (VVPS board can only be planned at NANT-E / FANT-F) - nt-a : nt-a slot - nt-b : nt-b slot Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::VirtualSlotId>	Index in eqpt Prot Element Table

Resource Identifier	Type	Description
	- the virtual LT slot number Field type <Eqpt::EqSlotId> - the equipment slot number	

Table 5.7-2 "Protection Element Configuration Command" Command Parameters

Parameter	Type	Description
[no] redcy-ctrl-status	Parameter type: <Equipm::ProtElementRedcyCtrlStatus> Format: (normal forced_active) Possible values: - normal : enables redundancy (active or standby) - forced_active : forces the element to be active	<i>optional parameter with default value: "normal"</i> changes the redundancy control status

5.8 External-link-host Configuration Commands

Command Description

This command allows the operator to configure the traffic direction of the configurable external-links on the host expansion card. The configurable parameters are:

- **direction:** The traffic direction. Two directions are supported:
 - **network (default):** the direction is configured to allow the traffic from the network
 - **remote-lt :** the direction is configured to allow the traffic to the remote line termination card

User Level

The command can be accessed by operators with equipment privileges, and executed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

```
> configure equipment external-link-host (faceplate-number) [ no direction | direction
<Equipm::ExternalLinkConfigType> ]
```

Command Parameters

Table 5.8-1 "External-link-host Configuration Commands" Resource Parameters

Resource Identifier	Type	Description
(faceplate-number)	Format: (<Eqpt::ExtLinkConfigurableDeviceIndex> nt : sfp : <Eqpt::ExtLinkHostPortIndex> ntio-1 : sfp : <Eqpt::ExtLinkHostPortIndex> ntio-2 : sfp : <Eqpt::ExtLinkHostPortIndex>) Possible values: - nt : nt-slot - ntio-1 : an nt applique slot in a single or multiple-ntio-shelf - ntio-2 : an nt applique slot in a multiple-ntio-shelf Possible values: - sfp : SFP port - xfp : XFP port Field type <Eqpt::ExtLinkHostPortIndex> - host port number Field type <Eqpt::ExtLinkConfigurableDeviceIndex> - the faceplate number of the configurable external link	the faceplate number of the configurable external-link

Table 5.8-2 "External-link-host Configuration Commands" Command Parameters

Parameter	Type	Description
[no] direction	Parameter type: <Equipm::ExternalLinkConfigType> Format: (network	<i>optional parameter with default value: "network"</i> the external-link traffic direction

Parameter	Type	Description
	remote-lt) Possible values: - network : the connection direction is from the network - remote-lt : the connection direction is to the remote line termination card	

5.9 Host Shelf SFP Configuration Commands

Command Description

This command allows the operator to configure the association between a host shelf SFP/XFP and a remote LT.

User Level

The command can be accessed by operators with equipment privileges, and executed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

```
> configure equipment external-link-assign (index) [ no remote | remote <Equipm::ExpansionSlotIndex> ]
```

Command Parameters

Table 5.9-1 "Host Shelf SFP Configuration Commands" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: (<Eqpt::ExtSfpFaceplateType> nt : sfp : <Eqpt::ExtSfpFaceplateType> nt : xfp : <Eqpt::ExtSfpFaceplateType> lt : <Eqpt::HostRackId> / <Eqpt::HostShelfId> / <Eqpt::LtExtSlotId> / <Eqpt::ExtSfpFaceplateType> ntio-1 : sfp : <Eqpt::ExtSfpFaceplateType> ntio-1 : xfp : <Eqpt::ExtSfpFaceplateType> ntio-2 : sfp : <Eqpt::ExtSfpFaceplateType> ntio-2 : xfp : <Eqpt::ExtSfpFaceplateType>) Possible values: - nt : active nt slot - lt : lt-slot - ntio-1 : an nt applique slot in a single or multiple-ntio-shelf - ntio-2 : an nt applique slot in a multiple-ntio-shelf Field type <Eqpt::HostRackId> - the rack number Field type <Eqpt::HostShelfId> - the shelf number Field type <Eqpt::LtExtSlotId> - the LT slot number Possible values: - sfp : SFP port - xfp : XFP port Field type <Eqpt::ExtSfpFaceplateType> - The faceplate on which remote LT is connected	the physical sfp or xfp cage position

Table 5.9-2 "Host Shelf SFP Configuration Commands" Command Parameters

Parameter	Type	Description
[no] remote	Parameter type: <Equipm::ExpansionSlotIndex> Format: <Eqpt::ExpRack> / <Eqpt::ExpShelf> / <Eqpt::ExpSlot> Field type <Eqpt::ExpRack> - the physical number of the expansion rack, 0 stands for no remote Field type <Eqpt::ExpShelf> - physical nbr of expansion shelf within expansion rack, 0 stands for no remote Field type <Eqpt::ExpSlot> - the physical number of the slot within expansion shelf, 0 stands for no remote	<i>optional parameter with default value: "0/0/0"</i> the expansion shelf LSM

5.10 SFP/XFP Diagnostics configuration Command

Command Description

This command allows the operator to configure RSSI profile on SFP/XFP:

- The slot index of the sfp
- The number of the sfp cage
- The index of rssi profile which would be configured on SFP/XFP.

User Level

The command can be accessed by operators with equipment privileges, and executed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

```
> configure equipment diagnostics sfp (position) [ no rssi-prof-id | rssi-prof-id <Eqpt::RssiProfileIndex> ] [ no rssi-state | rssi-state <Eqpt::RssiState> ]
```

Command Parameters

Table 5.10-1 "SFP/XFP Diagnostics configuration Command" Resource Parameters

Resource Identifier	Type	Description
(position)	Format: (acu : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SfpCageNumber> iont : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SfpCageNumber> remote-sfp : <Eqpt::ExpRack> / <Eqpt::ExpShelf> : sfp : <Eqpt::SfpCageNumber> remote-sfp : <Eqpt::ExpRack> / <Eqpt::ExpShelf> : xfp : <Eqpt::SfpCageNumber> remote-sfp : <Eqpt::ExpRack> / <Eqpt::ExpShelf> : qsfp : <Eqpt::SfpCageNumber> remote-sfp : <Eqpt::ExpRack> / <Eqpt::ExpShelf> : cfp : <Eqpt::SfpCageNumber> remote-sfp : <Eqpt::ExpRack> / <Eqpt::ExpShelf> : sfp1 : <Eqpt::SfpCageNumber> remote-sfp : <Eqpt::ExpRack> / <Eqpt::ExpShelf> : sfp2 : <Eqpt::SfpCageNumber> remote-sfp : <Eqpt::ExpRack> / <Eqpt::ExpShelf> : xfp1 : <Eqpt::SfpCageNumber> remote-sfp : <Eqpt::ExpRack> / <Eqpt::ExpShelf> : xfp2 : <Eqpt::SfpCageNumber> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::EqSlotId> / <Eqpt::SfpCageNumber> nt : sfp : <Eqpt::SfpCageNumber>	the physical sfp cage position

Resource Identifier	Type	Description
	nt : xfp : <Eqpt::SfpCageNumber> nt : qsf : <Eqpt::SfpCageNumber> nt : cfp : <Eqpt::SfpCageNumber> nt : sfp1 : <Eqpt::SfpCageNumber> nt : sfp2 : <Eqpt::SfpCageNumber> nt : xfp1 : <Eqpt::SfpCageNumber> nt : xfp2 : <Eqpt::SfpCageNumber> lt : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> : sfp : <Eqpt::SfpCageNumber> lt : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> : xfp : <Eqpt::SfpCageNumber> lt : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> : qsf : <Eqpt::SfpCageNumber> lt : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> : cfp : <Eqpt::SfpCageNumber> lt : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> : sfp1 : <Eqpt::SfpCageNumber> lt : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> : sfp2 : <Eqpt::SfpCageNumber> lt : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> : xfp1 : <Eqpt::SfpCageNumber> lt : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> : xfp2 : <Eqpt::SfpCageNumber> ntio-1 : sfp : <Eqpt::SfpCageNumber> ntio-1 : xfp : <Eqpt::SfpCageNumber> ntio-1 : qsf : <Eqpt::SfpCageNumber> ntio-1 : cfp : <Eqpt::SfpCageNumber> ntio-1 : sfp1 : <Eqpt::SfpCageNumber> ntio-1 : sfp2 : <Eqpt::SfpCageNumber> ntio-1 : xfp1 : <Eqpt::SfpCageNumber> ntio-1 : xfp2 : <Eqpt::SfpCageNumber> ntio-2 : sfp : <Eqpt::SfpCageNumber> ntio-2 : xfp : <Eqpt::SfpCageNumber> ntio-2 : qsf : <Eqpt::SfpCageNumber> ntio-2 : cfp : <Eqpt::SfpCageNumber> ntio-2 : sfp1 : <Eqpt::SfpCageNumber> ntio-2 : sfp2 : <Eqpt::SfpCageNumber> ntio-2 : xfp1 : <Eqpt::SfpCageNumber> ntio-2 : xfp2 : <Eqpt::SfpCageNumber> nt-a : sfp : <Eqpt::SfpCageNumber> nt-a : xfp : <Eqpt::SfpCageNumber> nt-a : qsf : <Eqpt::SfpCageNumber> nt-a : cfp : <Eqpt::SfpCageNumber> nt-a : sfp1 : <Eqpt::SfpCageNumber> nt-a : sfp2 : <Eqpt::SfpCageNumber> nt-a : xfp1 : <Eqpt::SfpCageNumber> nt-a : xfp2 : <Eqpt::SfpCageNumber> nt-b : sfp : <Eqpt::SfpCageNumber> nt-b : xfp : <Eqpt::SfpCageNumber> nt-b : qsf : <Eqpt::SfpCageNumber> nt-b : cfp : <Eqpt::SfpCageNumber> nt-b : sfp1 : <Eqpt::SfpCageNumber> nt-b : sfp2 : <Eqpt::SfpCageNumber> nt-b : xfp1 : <Eqpt::SfpCageNumber> nt-b : xfp2 : <Eqpt::SfpCageNumber>) Possible values: - acu : acu slot	

5 Equipment Configuration Commands

Resource Identifier	Type	Description
	- iot : an nt applique slot - remote-sfp : remote sfp - nt : active nt slot - lt : lt-slot - ntio-1 : an nt applique slot in a single or multiple-ntio-shelf - ntio-2 : an nt applique slot in a multiple-ntio-shelf - nt-a : nt-a slot - nt-b : nt-b slot Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ExpRack> - the physical number of the expansion rack, 0 stands for no remote Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::ExpShelf> - physical nbr of expansion shelf within expansion rack, 0 stands for no remote Field type <Eqpt::EqSlotId> - the equipment slot number Field type <Eqpt::SlotId> - the LT slot number Possible values: - sfp : SFP port - xfp : XFP port - qsfp : QSFP port - cfp : CFP4 port - sfp1 : SFP port 1 - sfp2 : SFP port 2 - xfp1 : XFP port 1 - xfp2 : XFP port 2 Field type <Eqpt::SfpCageNumber> - the SFP cage number - range: [0...2304]	

Table 5.10-2 "SFP/XFP Diagnostics configuration Command" Command Parameters

Parameter	Type	Description
[no] rssi-prof-id	Parameter type: <Eqpt::RssiProfileIndex> Format: - an unique index value for the rssi profile(1-200:userdefined,65535:automode) - range: [1...200,65535]	<i>optional parameter with default value: "65535"</i> an unique index of the rssi profile(1-200)
[no] rssi-state	Parameter type: <Eqpt::RssiState> Format: (enable disable) Possible values: - enable : enable rssi functionality - disable : disable rssi functionality	<i>optional parameter with default value: "disable"</i> to enable or disable the rssi functionality of sfp for uplink ports

5.11 Sfp RSSI Configuration Command

Command Description

This command allows the operator to create and configure the RSSI parameters on SFPs.

User Level

The command can be accessed by operators with equipment privileges, and executed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

```
> configure equipment ( no rssiprof (index) ) | ( rssiprof (index) name <Eqpt::DisplayString> [ no temp-alm-low |
temp-alm-low <Eqpt::TcaTemp> ] [ no temp-alm-high | temp-alm-high <Eqpt::TcaTemp> ] [ no temp-warn-low |
temp-warn-low <Eqpt::TcaTemp> ] [ no temp-warn-high | temp-warn-high <Eqpt::TcaTemp> ] [ no
voltage-alm-low | voltage-alm-low <Eqpt::TcaVoltage> ] [ no voltage-alm-high | voltage-alm-high
<Eqpt::TcaVoltage> ] [ no voltage-warn-low | voltage-warn-low <Eqpt::TcaVoltage> ] [ no voltage-warn-high |
voltage-warn-high <Eqpt::TcaVoltage> ] [ no bias-alm-low | bias-alm-low <Eqpt::TcaBias> ] [ no bias-alm-high |
bias-alm-high <Eqpt::TcaBias> ] [ no bias-warn-low | bias-warn-low <Eqpt::TcaBias> ] [ no bias-warn-high |
bias-warn-high <Eqpt::TcaBias> ] [ no tx-pwr-alm-low | tx-pwr-alm-low <Eqpt::TcaTxPwr> ] [ no
tx-pwr-alm-high | tx-pwr-alm-high <Eqpt::TcaTxPwr> ] [ no tx-pwr-warn-low | tx-pwr-warn-low
<Eqpt::TcaTxPwr> ] [ no tx-pwr-warn-high | tx-pwr-warn-high <Eqpt::TcaTxPwr> ] [ no rx-pwr-alm-low |
rx-pwr-alm-low <Eqpt::TcaRxPwr> ] [ no rx-pwr-alm-high | rx-pwr-alm-high <Eqpt::TcaRxPwr> ] [ no
rx-pwr-warn-low | rx-pwr-warn-low <Eqpt::TcaRxPwr> ] [ no rx-pwr-warn-high | rx-pwr-warn-high
<Eqpt::TcaRxPwr> ] [ no ebias-alm-low | ebias-alm-low <Eqpt::TcaBias> ] [ no ebias-alm-high | ebias-alm-high
<Eqpt::TcaBias> ] [ no ebias-warn-low | ebias-warn-low <Eqpt::TcaBias> ] [ no ebias-warn-high | ebias-warn-high
<Eqpt::TcaBias> ] [ no etx-alm-low | etx-alm-low <Eqpt::TcaTxPwr> ] [ no etx-alm-high | etx-alm-high
<Eqpt::TcaTxPwr> ] [ no etx-warn-low | etx-warn-low <Eqpt::TcaTxPwr> ] [ no etx-warn-high | etx-warn-high
<Eqpt::TcaTxPwr> ] [ no erx-alm-low | erx-alm-low <Eqpt::TcaRxPwr> ] [ no erx-alm-high | erx-alm-high
<Eqpt::TcaRxPwr> ] [ no erx-warn-low | erx-warn-low <Eqpt::TcaRxPwr> ] [ no erx-warn-high | erx-warn-high
<Eqpt::TcaRxPwr> ] [ no etemp-alm-low | etemp-alm-low <Eqpt::TcaTemp> ] [ no etemp-alm-high |
etemp-alm-high <Eqpt::TcaTemp> ] [ no etemp-warn-low | etemp-warn-low <Eqpt::TcaTemp> ] [ no
etemp-warn-high | etemp-warn-high <Eqpt::TcaTemp> ] [ no profile-type | profile-type <Eqpt::RssiProfileType> ] )
```

Command Parameters

Table 5.11-1 "Sfp RSSI Configuration Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - an unique index value for the rssi profile(1-200) - range: [1...200]	an unique index of the rssi profile(1-200)

Table 5.11-2 "Sfp RSSI Configuration Command" Command Parameters

Parameter	Type	Description
name	Parameter type: <Eqpt::DisplayString> Format:	<i>mandatory parameter</i> A unique profile name

5 Equipment Configuration Commands

Parameter	Type	Description
	- string to identify the rssi profile - length: 1<=x<=16	
[no] temp-alm-low	Parameter type: <Eqpt::TcaTemp> Format: - temperature of SFP - unit: degree C - range: [-128...128]	<i>optional parameter with default value: "0"</i> alarm low threshold for temperature
[no] temp-alm-high	Parameter type: <Eqpt::TcaTemp> Format: - temperature of SFP - unit: degree C - range: [-128...128]	<i>optional parameter with default value: "0"</i> alarm high threshold for temperature
[no] temp-warn-low	Parameter type: <Eqpt::TcaTemp> Format: - temperature of SFP - unit: degree C - range: [-128...128]	<i>optional parameter with default value: "0"</i> warn low threshold for temperature
[no] temp-warn-high	Parameter type: <Eqpt::TcaTemp> Format: - temperature of SFP - unit: degree C - range: [-128...128]	<i>optional parameter with default value: "0"</i> warn high threshold for temperature
[no] voltage-alm-low	Parameter type: <Eqpt::TcaVoltage> Format: - voltage of SFP - unit: volts - range: [0...6.55]	<i>optional parameter with default value: "0"</i> alarm low threshold for Voltage
[no] voltage-alm-high	Parameter type: <Eqpt::TcaVoltage> Format: - voltage of SFP - unit: volts - range: [0...6.55]	<i>optional parameter with default value: "0"</i> alarm high threshold for Voltage
[no] voltage-warn-low	Parameter type: <Eqpt::TcaVoltage> Format: - voltage of SFP - unit: volts - range: [0...6.55]	<i>optional parameter with default value: "0"</i> warn low threshold for Voltage
[no] voltage-warn-high	Parameter type: <Eqpt::TcaVoltage> Format: - voltage of SFP - unit: volts - range: [0...6.55]	<i>optional parameter with default value: "0"</i> warn high threshold for Voltage
[no] bias-alm-low	Parameter type: <Eqpt::TcaBias> Format: - bias of SFP - unit: mA - range: [0...262]	<i>optional parameter with default value: "0"</i> alarm low threshold for bias
[no] bias-alm-high	Parameter type: <Eqpt::TcaBias> Format: - bias of SFP - unit: mA - range: [0...262]	<i>optional parameter with default value: "0"</i> alarm high threshold for bias
[no] bias-warn-low	Parameter type: <Eqpt::TcaBias> Format: - bias of SFP - unit: mA - range: [0...262]	<i>optional parameter with default value: "0"</i> warn low threshold for bias

Parameter	Type	Description
[no] bias-warn-high	Parameter type: <Eqpt::TcaBias> Format: - bias of SFP - unit: mA - range: [0...262]	<i>optional parameter with default value: "0"</i> warn high threshold for bias
[no] tx-pwr-alm-low	Parameter type: <Eqpt::TcaTxPwr> Format: <Eqpt::TcaTxPwr> Field type <Eqpt::TcaTxPwr> - power of SFP - unit: dbm - range: [-63.5...63.5]	<i>optional parameter with default value: "0"</i> alarm low threshold for Tx power
[no] tx-pwr-alm-high	Parameter type: <Eqpt::TcaTxPwr> Format: <Eqpt::TcaTxPwr> Field type <Eqpt::TcaTxPwr> - power of SFP - unit: dbm - range: [-63.5...63.5]	<i>optional parameter with default value: "0"</i> alarm high threshold for Tx power
[no] tx-pwr-warn-low	Parameter type: <Eqpt::TcaTxPwr> Format: <Eqpt::TcaTxPwr> Field type <Eqpt::TcaTxPwr> - power of SFP - unit: dbm - range: [-63.5...63.5]	<i>optional parameter with default value: "0"</i> warn low threshold for Tx power
[no] tx-pwr-warn-high	Parameter type: <Eqpt::TcaTxPwr> Format: <Eqpt::TcaTxPwr> Field type <Eqpt::TcaTxPwr> - power of SFP - unit: dbm - range: [-63.5...63.5]	<i>optional parameter with default value: "0"</i> warn high threshold for Tx power
[no] rx-pwr-alm-low	Parameter type: <Eqpt::TcaRxPwr> Format: <Eqpt::TcaRxPwr> Field type <Eqpt::TcaRxPwr> - power of SFP - unit: dbm - range: [-127...8.2]	<i>optional parameter with default value: "0"</i> alarm low threshold for Rx power
[no] rx-pwr-alm-high	Parameter type: <Eqpt::TcaRxPwr> Format: <Eqpt::TcaRxPwr> Field type <Eqpt::TcaRxPwr> - power of SFP - unit: dbm - range: [-127...8.2]	<i>optional parameter with default value: "0"</i> alarm high threshold for Rx power
[no] rx-pwr-warn-low	Parameter type: <Eqpt::TcaRxPwr> Format: <Eqpt::TcaRxPwr> Field type <Eqpt::TcaRxPwr> - power of SFP - unit: dbm - range: [-127...8.2]	<i>optional parameter with default value: "0"</i> warn low threshold for Rx power
[no] rx-pwr-warn-high	Parameter type: <Eqpt::TcaRxPwr> Format: <Eqpt::TcaRxPwr>	<i>optional parameter with default value: "0"</i> warn high threshold for Rx power

5 Equipment Configuration Commands

Parameter	Type	Description
	Field type <Eqpt::TcaRxPwr> - power of SFP - unit: dbm - range: [-127...8.2]	
[no] ebias-alm-low	Parameter type: <Eqpt::TcaBias> Format: - bias of SFP - unit: mA - range: [0...262]	<i>optional parameter with default value: "0"</i> alarm low threshold for ext bias
[no] ebias-alm-high	Parameter type: <Eqpt::TcaBias> Format: - bias of SFP - unit: mA - range: [0...262]	<i>optional parameter with default value: "0"</i> alarm high threshold for ext bias
[no] ebias-warn-low	Parameter type: <Eqpt::TcaBias> Format: - bias of SFP - unit: mA - range: [0...262]	<i>optional parameter with default value: "0"</i> warn low threshold for ext bias
[no] ebias-warn-high	Parameter type: <Eqpt::TcaBias> Format: - bias of SFP - unit: mA - range: [0...262]	<i>optional parameter with default value: "0"</i> warn high threshold for ext bias
[no] etx-alm-low	Parameter type: <Eqpt::TcaTxPwr> Format: <Eqpt::TcaTxPwr> Field type <Eqpt::TcaTxPwr> - power of SFP - unit: dbm - range: [-63.5...63.5]	<i>optional parameter with default value: "0"</i> alarm low threshold for ext Tx power
[no] etx-alm-high	Parameter type: <Eqpt::TcaTxPwr> Format: <Eqpt::TcaTxPwr> Field type <Eqpt::TcaTxPwr> - power of SFP - unit: dbm - range: [-63.5...63.5]	<i>optional parameter with default value: "0"</i> alarm high threshold for ext Tx power
[no] etx-warn-low	Parameter type: <Eqpt::TcaTxPwr> Format: <Eqpt::TcaTxPwr> Field type <Eqpt::TcaTxPwr> - power of SFP - unit: dbm - range: [-63.5...63.5]	<i>optional parameter with default value: "0"</i> warn low threshold for ext Tx power
[no] etx-warn-high	Parameter type: <Eqpt::TcaTxPwr> Format: <Eqpt::TcaTxPwr> Field type <Eqpt::TcaTxPwr> - power of SFP - unit: dbm - range: [-63.5...63.5]	<i>optional parameter with default value: "0"</i> warn high threshold for ext Tx power
[no] erx-alm-low	Parameter type: <Eqpt::TcaRxPwr> Format: <Eqpt::TcaRxPwr> Field type <Eqpt::TcaRxPwr> - power of SFP	<i>optional parameter with default value: "0"</i> alarm low threshold for ext Rx power

Parameter	Type	Description
	- unit: dbm - range: [-127...8.2]	
[no] erx-alm-high	Parameter type: <Eqpt::TcaRxPwr> Format: <Eqpt::TcaRxPwr> Field type <Eqpt::TcaRxPwr> - power of SFP - unit: dbm - range: [-127...8.2]	<i>optional parameter with default value: "0"</i> alarm high threshold for ext Rx power
[no] erx-warn-low	Parameter type: <Eqpt::TcaRxPwr> Format: <Eqpt::TcaRxPwr> Field type <Eqpt::TcaRxPwr> - power of SFP - unit: dbm - range: [-127...8.2]	<i>optional parameter with default value: "0"</i> warn low threshold for ext Rx power
[no] erx-warn-high	Parameter type: <Eqpt::TcaRxPwr> Format: <Eqpt::TcaRxPwr> Field type <Eqpt::TcaRxPwr> - power of SFP - unit: dbm - range: [-127...8.2]	<i>optional parameter with default value: "0"</i> warn high threshold for ext Rx power
[no] etemp-alm-low	Parameter type: <Eqpt::TcaTemp> Format: - temperature of SFP - unit: degree C - range: [-128...128]	<i>optional parameter with default value: "0"</i> alarm low threshold for temperature on network lane
[no] etemp-alm-high	Parameter type: <Eqpt::TcaTemp> Format: - temperature of SFP - unit: degree C - range: [-128...128]	<i>optional parameter with default value: "0"</i> alarm high threshold for temperature on network lane
[no] etemp-warn-low	Parameter type: <Eqpt::TcaTemp> Format: - temperature of SFP - unit: degree C - range: [-128...128]	<i>optional parameter with default value: "0"</i> warn low threshold for temperature on network lane
[no] etemp-warn-high	Parameter type: <Eqpt::TcaTemp> Format: - temperature of SFP - unit: degree C - range: [-128...128]	<i>optional parameter with default value: "0"</i> warn high threshold for temperature on network lane
[no] profile-type	Parameter type: <Eqpt::RssiProfileType> Format: (olt ont) Possible values: - olt : This profile is for OLT usage - ont : This profile is for ONT usage	<i>optional parameter with default value: "olt"</i> determine if this RSSI Profile is for OLT or ONT

5.12 2xE1/DS1 CLOCK configuration Command

Command Description

This command allows the operator to configure clock source on the 2xE1/DS1 sfp:

User Level

The command can be accessed by operators with equipment privileges, and executed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

```
> configure equipment sfpe1t1 ( no clock (position) ) | ( clock (position) [ no clocksource | clocksource
<Eqpt::ClockSource> ] )
```

Command Parameters

Table 5.12-1 "2xE1/DS1 CLOCK configuration Command" Resource Parameters

Resource Identifier	Type	Description
(position)	Format: (acu : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::E1dsx1SfpCageNumber> iont : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::E1dsx1SfpCageNumber> remote-sfp : <Eqpt::ExpRack> / <Eqpt::ExpShelf> : <Eqpt::E1dsx1SfpCageNumber> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::EqSlotId> / <Eqpt::E1dsx1SfpCageNumber> nt : sfp : <Eqpt::E1dsx1SfpCageNumber> nt : xfp : <Eqpt::E1dsx1SfpCageNumber> lt : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::E1dsx1SfpCageNumber> ntio-1 : sfp : <Eqpt::E1dsx1SfpCageNumber> ntio-1 : xfp : <Eqpt::E1dsx1SfpCageNumber> ntio-2 : sfp : <Eqpt::E1dsx1SfpCageNumber> ntio-2 : xfp : <Eqpt::E1dsx1SfpCageNumber> nt-a : sfp : <Eqpt::E1dsx1SfpCageNumber> nt-a : xfp : <Eqpt::E1dsx1SfpCageNumber> nt-b : sfp : <Eqpt::E1dsx1SfpCageNumber> nt-b : xfp : <Eqpt::E1dsx1SfpCageNumber>) Possible values: - acu : acu slot - iont : an nt applique slot - remote-sfp : remote sfp - nt : active nt slot - lt : lt-slot	the physical sfp cage position

Resource Identifier	Type	Description
	- ntio-1 : an nt applique slot in a single or multiple-ntio-shelf - ntio-2 : an nt applique slot in a multiple-ntio-shelf - nt-a : nt-a slot - nt-b : nt-b slot Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ExpRack> - the physical number of the expansion rack, 0 stands for no remote Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::ExpShelf> - physical nbr of expansion shelf within expansion rack, 0 stands for no remote Field type <Eqpt::EqSlotId> - the equipment slot number Field type <Eqpt::SlotId> - the LT slot number Possible values: - sfp : SFP port - xfp : XFP port Field type <Eqpt::E1dsx1SfpCageNumber> - the SFP cage number range NELT-B [1,3..35], NCNC-B/C/D [2..7], RELT-A/B [1,3..15]	

Table 5.12-2 "2xE1/DS1 CLOCK configuration Command" Command Parameters

Parameter	Type	Description
[no] clocksource	Parameter type: <Eqpt::ClockSource> Format: <pre>(tributary1 tributary2 serdes)</pre> Possible values: - tributary1 : clock source is from tributary 1 - tributary2 : clock source is from tributary 2 - serdes : clock source is from serdes	<i>optional parameter with default value: "serdes"</i> Clock source can be tributary1 or tributary2 or serdes

5.13 2xE1/DS1 Pseudo Wire TDM Interface configuration Command

Command Description

This command allows the operator to configure PWTDM interface parameters on the 2xE1/DS1 sfp:

User Level

The command can be accessed by operators with equipment privileges, and executed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

```
> configure equipment sfpe1t1 tdmintf (position) [ no window-number | window-number <Eqpt::WindowNumber>
] [ no window-length | window-length <Eqpt::Windowlength> ]
```

Command Parameters

Table 5.13-1 "2xE1/DS1 Pseudo Wire TDM Interface configuration Command" Resource Parameters

Resource Identifier	Type	Description
(position)	Format: (acu : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::E1dsx1SfpCageNumber> iont : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::E1dsx1SfpCageNumber> remote-sfp : <Eqpt::ExpRack> / <Eqpt::ExpShelf> : <Eqpt::E1dsx1SfpCageNumber> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::EqSlotId> / <Eqpt::E1dsx1SfpCageNumber> nt : sfp : <Eqpt::E1dsx1SfpCageNumber> nt : xfp : <Eqpt::E1dsx1SfpCageNumber> lt : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::E1dsx1SfpCageNumber> ntio-1 : sfp : <Eqpt::E1dsx1SfpCageNumber> ntio-1 : xfp : <Eqpt::E1dsx1SfpCageNumber> ntio-2 : sfp : <Eqpt::E1dsx1SfpCageNumber> ntio-2 : xfp : <Eqpt::E1dsx1SfpCageNumber> nt-a : sfp : <Eqpt::E1dsx1SfpCageNumber> nt-a : xfp : <Eqpt::E1dsx1SfpCageNumber> nt-b : sfp : <Eqpt::E1dsx1SfpCageNumber> nt-b : xfp : <Eqpt::E1dsx1SfpCageNumber>) Possible values: - acu : acu slot	the physical sfp cage position

Resource Identifier	Type	Description
	- iont : an nt applique slot - remote-sfp : remote sfp - nt : active nt slot - lt : lt-slot - ntio-1 : an nt applique slot in a single or multiple-ntio-shelf - ntio-2 : an nt applique slot in a multiple-ntio-shelf - nt-a : nt-a slot - nt-b : nt-b slot Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ExpRack> - the physical number of the expansion rack, 0 stands for no remote Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::ExpShelf> - physical nbr of expansion shelf within expansion rack, 0 stands for no remote Field type <Eqpt::EqSlotId> - the equipment slot number Field type <Eqpt::SlotId> - the LT slot number Possible values: - sfp : SFP port - xfp : XFP port Field type <Eqpt::E1dsx1SfpCageNumber> - the SFP cage number range NELT-B [1,3..35], NCNC-B/C/D [2..7], RELT-A/B [1,3..15]	

Table 5.13-2 "2xE1/DS1 Pseudo Wire TDM Interface configuration Command" Command Parameters

Parameter	Type	Description
[no] window-number	Parameter type: <Eqpt::WindowNumber> Format: - window-number range - range: [0...255]	<i>optional parameter with default value: "20"</i> window number can be configured from 0 to 255, selecting value 0 sets default value
[no] window-length	Parameter type: <Eqpt::Windowlength> Format: - window-length range - range: [0...255]	<i>optional parameter with default value: "10"</i> window number can be configured from 0 to 255, selecting value 0 sets default value, units multiple of 10 milliseconds

5.14 2xE1/DS1 Pseudo Wire TDM SFP configuration Command

Command Description

This command allows the operator to configure pseudowire TDM parameters on the 2xE1/DS1 sfp:

User Level

The command can be accessed by operators with equipment privileges, and executed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

```
> configure equipment sfpe1t1 ( no pwtdm (position) ) | ( pwtdm (position) channel <Eqpt::Channel> packet-length
<Eqpt::Packetlength> jitter-buff-size <Eqpt::JitBufSize> vlanid <Eqpt::VlanId> priority <Eqpt::Priority>
conseq-number <Eqpt::ConseqNo> ecid-rx <Eqpt::ECID> ecid-tx <Eqpt::ECID> source-mac
<Eqpt::PhysicalAddress> dest-mac <Eqpt::PhysicalAddress> )
```

Command Parameters

Table 5.14-1 "2xE1/DS1 Pseudo Wire TDM SFP configuration Command" Resource Parameters

Resource Identifier	Type	Description
(position)	Format: (acu : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::E1dsx1SfpCageNumber> : <Eqpt::TributaryIndex> iont : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::E1dsx1SfpCageNumber> : <Eqpt::TributaryIndex> remote-sfp : <Eqpt::ExpRack> / <Eqpt::ExpShelf> : <Eqpt::E1dsx1SfpCageNumber> : <Eqpt::TributaryIndex> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::EqSlotId> / <Eqpt::E1dsx1SfpCageNumber> : <Eqpt::TributaryIndex> nt : sfp : <Eqpt::E1dsx1SfpCageNumber> : <Eqpt::TributaryIndex> nt : xfp : <Eqpt::E1dsx1SfpCageNumber> : <Eqpt::TributaryIndex> lt : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::E1dsx1SfpCageNumber> : <Eqpt::TributaryIndex> ntio-1 : sfp : <Eqpt::E1dsx1SfpCageNumber> : <Eqpt::TributaryIndex> ntio-1 : xfp : <Eqpt::E1dsx1SfpCageNumber> : <Eqpt::TributaryIndex> ntio-2 : sfp : <Eqpt::E1dsx1SfpCageNumber> : <Eqpt::TributaryIndex> ntio-2 : xfp : <Eqpt::E1dsx1SfpCageNumber> :	the physical sfp cage position

Resource Identifier	Type	Description
	<Eqpt::TributaryIndex> nt-a : sfp : <Eqpt::E1dsx1SfpCageNumber> : <Eqpt::TributaryIndex> nt-a : xfp : <Eqpt::E1dsx1SfpCageNumber> : <Eqpt::TributaryIndex> nt-b : sfp : <Eqpt::E1dsx1SfpCageNumber> : <Eqpt::TributaryIndex> nt-b : xfp : <Eqpt::E1dsx1SfpCageNumber> : <Eqpt::TributaryIndex>) Possible values: - acu : acu slot - iont : an nt applique slot - remote-sfp : remote sfp - nt : active nt slot - lt : lt-slot - ntio-1 : an nt applique slot in a single or multiple-ntio-shelf - ntio-2 : an nt applique slot in a multiple-ntio-shelf - nt-a : nt-a slot - nt-b : nt-b slot Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ExpRack> - the physical number of the expansion rack, 0 stands for no remote Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::ExpShelf> - physical nbr of expansion shelf within expansion rack, 0 stands for no remote Field type <Eqpt::EqSlotId> - the equipment slot number Field type <Eqpt::SlotId> - the LT slot number Possible values: - sfp : SFP port - xfp : XFP port Field type <Eqpt::E1dsx1SfpCageNumber> - the SFP cage number range NELT-B [1,3..35], NCNC-B/C/D [2..7], RELT-A/B [1,3..15] Field type <Eqpt::TributaryIndex> - tributary index - range: [1...3]	

Table 5.14-2 "2xE1/DS1 Pseudo Wire TDM SFP configuration Command" Command Parameters

Parameter	Type	Description
channel	Parameter type: <Eqpt::Channel> Format: (close open) Possible values: - close : close channel - open : open channel	<i>mandatory parameter</i> open or close the channel
packet-length	Parameter type: <Eqpt::Packetlength> Format: - packet length range - range: [0...16382]	<i>mandatory parameter</i> packet length can be configured from 0 to 16382, packet length for MEF8 is 256 bytes
jitter-buff-size	Parameter type: <Eqpt::JitBufSize>	<i>mandatory parameter</i>

5 Equipment Configuration Commands

Parameter	Type	Description
	Format: - jitter buffer size - range: [0...1023]	jitter buffer size can be configured from 0 to 1023, units in number of MEF8 packets
vlanid	Parameter type: <Eqpt::VlanId> Format: - vlan index - range: [0...4095]	<i>mandatory parameter</i> vlan id can be configured from 0 to 4095
priority	Parameter type: <Eqpt::Priority> Format: - priority range 0 to 7 - range: [0...7]	<i>mandatory parameter</i> 802.1p priority range 0 to 7
conseq-number	Parameter type: <Eqpt::ConseqNo> Format: - consequence range 0 to 7, 0: no control, 1-6: number of packets out of sequence - range: [0...7]	<i>mandatory parameter</i> consequence number range 0 to 7
ecid-rx	Parameter type: <Eqpt::ECID> Format: - Emulated circuit identifier range 0 to 1048575 - range: [0...1048575]	<i>mandatory parameter</i> receive emulated circuit identifier range 0 to 1048575
ecid-tx	Parameter type: <Eqpt::ECID> Format: - Emulated circuit identifier range 0 to 1048575 - range: [0...1048575]	<i>mandatory parameter</i> transmit emulated circuit identifier range 0 to 1048575
source-mac	Parameter type: <Eqpt::PhysicalAddress> Format: - media dependent physical address - length: 6	<i>mandatory parameter</i> source mac address
dest-mac	Parameter type: <Eqpt::PhysicalAddress> Format: - media dependent physical address - length: 6	<i>mandatory parameter</i> destination mac address

5.15 2xE1/DS1 Framer configuration Command

Command Description

This command allows the operator to configure Framer parameters on the 2xE1/DS1 sfp:

User Level

The command can be accessed by operators with equipment privileges, and executed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

```
> configure equipment sfpe1t1 framer (position) [ no frame-mode | frame-mode <Eqpt::Framemode> ] [ no
iwf-on-liu | iwf-on-liu <Eqpt::IwfOnLiu> ] [ no liu-on-liu | liu-on-liu <Eqpt::LiuOnliu> ] [ no pm-to-iwf |
pm-to-iwf <Eqpt::PmTowi> ] [ no ais-to-iwf | ais-to-iwf <Eqpt::AisTowi> ] [ no rai-to-iwf | rai-to-iwf
<Eqpt::RaiTowi> ] [ no rei-to-iwf | rei-to-iwf <Eqpt::ReiTowi> ] [ no pm-to-liu | pm-to-liu <Eqpt::PmToliu> ] [
no ais-to-liu | ais-to-liu <Eqpt::AisToliu> ] [ no rai-to-liu | rai-to-liu <Eqpt::RaiToliu> ] [ no rei-to-liu | rei-to-liu
<Eqpt::ReiToliu> ]
```

Command Parameters

Table 5.15-1 "2xE1/DS1 Framer configuration Command" Resource Parameters

Resource Identifier	Type	Description
(position)	Format: (acu : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::E1dsx1SfpCageNumber> : <Eqpt::TributaryIndex> iont : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::E1dsx1SfpCageNumber> : <Eqpt::TributaryIndex> remote-sfp : <Eqpt::ExpRack> / <Eqpt::ExpShelf> : <Eqpt::E1dsx1SfpCageNumber> : <Eqpt::TributaryIndex> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::EqSlotId> / <Eqpt::E1dsx1SfpCageNumber> : <Eqpt::TributaryIndex> nt : sfp : <Eqpt::E1dsx1SfpCageNumber> : <Eqpt::TributaryIndex> nt : xfp : <Eqpt::E1dsx1SfpCageNumber> : <Eqpt::TributaryIndex> lt : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::E1dsx1SfpCageNumber> : <Eqpt::TributaryIndex> ntio-1 : sfp : <Eqpt::E1dsx1SfpCageNumber> : <Eqpt::TributaryIndex> ntio-1 : xfp : <Eqpt::E1dsx1SfpCageNumber> : <Eqpt::TributaryIndex> ntio-2 : sfp : <Eqpt::E1dsx1SfpCageNumber> : <Eqpt::TributaryIndex> ntio-2 : xfp : <Eqpt::E1dsx1SfpCageNumber> : <Eqpt::TributaryIndex>	the physical sfp cage position

5 Equipment Configuration Commands

Resource Identifier	Type	Description
	<pre> nt-a : sfp : <Eqpt::E1dsx1SfpCageNumber> : <Eqpt::TributaryIndex> nt-a : xfp : <Eqpt::E1dsx1SfpCageNumber> : <Eqpt::TributaryIndex> nt-b : sfp : <Eqpt::E1dsx1SfpCageNumber> : <Eqpt::TributaryIndex> nt-b : xfp : <Eqpt::E1dsx1SfpCageNumber> : <Eqpt::TributaryIndex>) Possible values: - acu : acu slot - iont : an nt applique slot - remote-sfp : remote sfp - nt : active nt slot - lt : lt-slot - ntio-1 : an nt applique slot in a single or multiple-ntio-shelf - ntio-2 : an nt applique slot in a multiple-ntio-shelf - nt-a : nt-a slot - nt-b : nt-b slot Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ExpRack> - the physical number of the expansion rack, 0 stands for no remote Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::ExpShelf> - physical nbr of expansion shelf within expansion rack, 0 stands for no remote Field type <Eqpt::EqSlotId> - the equipment slot number Field type <Eqpt::SlotId> - the LT slot number Possible values: - sfp : SFP port - xfp : XFP port Field type <Eqpt::E1dsx1SfpCageNumber> - the SFP cage number range NELT-B [1,3..35], NCNC-B/C/D [2..7], RELT-A/B [1,3..15] Field type <Eqpt::TributaryIndex> - tributary index - range: [1...3] </pre>	

Table 5.15-2 "2xE1/DS1 Framer configuration Command" Command Parameters

Parameter	Type	Description
[no] frame-mode	Parameter type: <Eqpt::Framermode> Format: (framed unframed) Possible values: - framed : selects framed tdm packet - unframed : selects unframed tdm packet	<i>optional parameter with default value: "unframed"</i> select line framing mode
[no] iwf-on-liu	Parameter type: <Eqpt::IwfOnLiu> Format: (enable disable) Possible values: - enable : enable loop towards iwf on liu	<i>optional parameter with default value: "disable"</i> enable loop towards iwf on liu

Parameter	Type	Description
	- disable : disable loop towards iwf on liu	
[no] liu-on-liu	Parameter type: <Eqpt::LiuOnliu> Format: (enable disable) Possible values: - enable : enable loop towards liu on liu - disable : disable loop towards liu on liu	<i>optional parameter with default value: "disable"</i> enable loop towards liu on liu
[no] pm-to-iwf	Parameter type: <Eqpt::PmToiwf> Format: (enable disable) Possible values: - enable : enable performance monitoring towards iwf - disable : disable performance monitoring towards iwf	<i>optional parameter with default value: "disable"</i> enable performance monitoring towards iwf
[no] ais-to-iwf	Parameter type: <Eqpt::AisToiwf> Format: (enable disable) Possible values: - enable : enable ais towards iwf - disable : disable ais towards iwf	<i>optional parameter with default value: "disable"</i> enable ais alarm towards iwf
[no] rai-to-iwf	Parameter type: <Eqpt::RaiToiwf> Format: (enable disable) Possible values: - enable : enable rai towards iwf - disable : disable rai towards iwf	<i>optional parameter with default value: "disable"</i> enable rai alarm towards iwf
[no] rei-to-iwf	Parameter type: <Eqpt::ReiToiwf> Format: (enable disable) Possible values: - enable : enable rei towards iwf - disable : disable rei towards iwf	<i>optional parameter with default value: "disable"</i> enable rei alarm towards iwf
[no] pm-to-liu	Parameter type: <Eqpt::PmToliu> Format: (enable disable) Possible values: - enable : enable performance monitoring towards liu - disable : disable performance monitoring towards liu	<i>optional parameter with default value: "disable"</i> enable performance monitoring towards liu
[no] ais-to-liu	Parameter type: <Eqpt::AisToliu> Format: (enable disable) Possible values: - enable : enable ais towards liu - disable : disable ais towards liu	<i>optional parameter with default value: "disable"</i> enable ais alarm towards liu
[no] rai-to-liu	Parameter type: <Eqpt::RaiToliu> Format: (enable disable) Possible values: - enable : enable rai towards liu - disable : disable rai towards liu	<i>optional parameter with default value: "disable"</i> enable rai alarm towards liu

5 Equipment Configuration Commands

Parameter	Type	Description
[no] rei-to-liu	Parameter type: <Eqpt::ReiToliu> Format: (enable disable) Possible values: - enable : enable rei towards liu - disable : disable rei towards liu	<i>optional parameter with default value: "disable"</i> enable rei alarm towards liu

5.16 2xE1/DS1 Line Interface Unit SFP configuration Command

Command Description

This command allows the operator to configure distance and cable impedance on the 2xE1/DS1 sfp:

User Level

The command can be accessed by operators with equipment privileges, and executed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

```
> configure equipment sfpe1t1 liu (position) [ no distance | distance <Eqpt::distance> ] [ no cable-impedance |
cable-impedance <Eqpt::CableImpedance> ]
```

Command Parameters

Table 5.16-1 "2xE1/DS1 Line Interface Unit SFP configuration Command" Resource Parameters

Resource Identifier	Type	Description
(position)	Format: (acu : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::E1dsx1SfpCageNumber> : <Eqpt::TributaryIndex> iont : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::E1dsx1SfpCageNumber> : <Eqpt::TributaryIndex> remote-sfp : <Eqpt::ExpRack> / <Eqpt::ExpShelf> : <Eqpt::E1dsx1SfpCageNumber> : <Eqpt::TributaryIndex> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::EqSlotId> / <Eqpt::E1dsx1SfpCageNumber> : <Eqpt::TributaryIndex> nt : sfp : <Eqpt::E1dsx1SfpCageNumber> : <Eqpt::TributaryIndex> nt : xfp : <Eqpt::E1dsx1SfpCageNumber> : <Eqpt::TributaryIndex> lt : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::E1dsx1SfpCageNumber> : <Eqpt::TributaryIndex> ntio-1 : sfp : <Eqpt::E1dsx1SfpCageNumber> : <Eqpt::TributaryIndex> ntio-1 : xfp : <Eqpt::E1dsx1SfpCageNumber> : <Eqpt::TributaryIndex> ntio-2 : sfp : <Eqpt::E1dsx1SfpCageNumber> : <Eqpt::TributaryIndex> ntio-2 : xfp : <Eqpt::E1dsx1SfpCageNumber> : <Eqpt::TributaryIndex> nt-a : sfp : <Eqpt::E1dsx1SfpCageNumber> :	the physical sfp cage position

5 Equipment Configuration Commands

Resource Identifier	Type	Description
	<Eqpt::TributaryIndex> nt-a : xfp : <Eqpt::E1dsx1SfpCageNumber> : <Eqpt::TributaryIndex> nt-b : sfp : <Eqpt::E1dsx1SfpCageNumber> : <Eqpt::TributaryIndex> nt-b : xfp : <Eqpt::E1dsx1SfpCageNumber> : <Eqpt::TributaryIndex>) Possible values: - acu : acu slot - iont : an nt applique slot - remote-sfp : remote sfp - nt : active nt slot - lt : lt-slot - ntio-1 : an nt applique slot in a single or multiple-ntio-shelf - ntio-2 : an nt applique slot in a multiple-ntio-shelf - nt-a : nt-a slot - nt-b : nt-b slot Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ExpRack> - the physical number of the expansion rack, 0 stands for no remote Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::ExpShelf> - physical nbr of expansion shelf within expansion rack, 0 stands for no remote Field type <Eqpt::EqSlotId> - the equipment slot number Field type <Eqpt::SlotId> - the LT slot number Possible values: - sfp : SFP port - xfp : XFP port Field type <Eqpt::E1dsx1SfpCageNumber> - the SFP cage number range NELT-B [1,3..35], NCNC-B/C/D [2..7], RELT-A/B [1,3..15] Field type <Eqpt::TributaryIndex> - tributary index - range: [1...3]	

Table 5.16-2 "2xE1/DS1 Line Interface Unit SFP configuration Command" Command Parameters

Parameter	Type	Description
[no] distance	Parameter type: <Eqpt::distance> Format: (shorthaul longhaul) Possible values: - shorthaul : distance shorthaul - longhaul : distance longhaul	<i>optional parameter with default value: "shorthaul"</i> distance can be configured as shorthaul or longhaul
[no] cable-impedance	Parameter type: <Eqpt::CableImpedance> Format: (75ohms 120ohms) Possible values: - 75ohms : cable impedance 75 ohms - 120ohms : cable impedance 120 ohms	<i>optional parameter with default value: "120ohms"</i> cable impedance can be configured 75ohms or 120ohms

5.17 NE Configuration Command

Command Description

This command allows the operator to configure the NE. The operator can configure the following parameter:

- *description: text that describes the location of the ISAM.*

User Level

The command can be accessed by operators with equipment privileges, and executed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

> configure equipment isam [no description | description <Description-127>]

Command Parameters

Table 5.17-2 "NE Configuration Command" Command Parameters

Parameter	Type	Description
[no] description	Parameter type: <Description-127> Format: - description to help the operator to identify the object - length: x<=127	<i>optional parameter with default value: ""</i> any description to be used by the operator

5.18 Environment Monitoring Configuration Command

Command Description

This command allows the operator to configure environment monitoring status to enable/disable the data relay from an external monitor box connected on the NTIO board of ISAM to the monitor server. The operator can configure the following parameters:

- *enable-supervise: enable relay of environment monitoring from an external monitor box.*

User Level

The command can be accessed by operators with equipment privileges, and executed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

> configure equipment envbox [[no] enable-supervise]

Command Parameters

Table 5.18-2 "Environment Monitoring Configuration Command" Command Parameters

Parameter	Type	Description
[no] enable-supervise	Parameter type: boolean	<i>optional parameter</i> enable environment monitoring relay

5.19 Configure Fan Tray parameters

Command Description

This command allows the operator to configure the fan tray parameter fanmode.

The fanmode determines the applied speed of the fan trays.

On 7302 ISAM, 7330 ISAM FTTN and 7360 ISAM the fanmode is effective only if intelligent fan packs are installed. Traditional fan packs (A-fans) do not support speed change, the 'classic' mode applies.

On 7363 MX intelligent fan packs are by default present. The "classic mode" will change the fan speed, but based on ambient temperature only.

User Level

The command can be accessed by operators with equipment privileges, and executed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

```
> configure equipment fan-tray [ fanmode <Eqpt::FanMode> ]
```

Command Parameters

Table 5.19-2 "Configure Fan Tray parameters" Command Parameters

Parameter	Type	Description
fanmode	Parameter type: <Eqpt::FanMode> Format: (auto eco protect classic) Possible values: - auto : runs in average mode; fan speeds determined by predefined thermal margins - eco : runs in 'green' mode; minimal thermal margins - protect : runs in protected mode; wider thermal settings wrt auto - classic : fixed fan speed; no SW control	<i>optional parameter</i> Fan Tray mode

5.20 Configure Board Auto Replan feature

Command Description

Parameter indicates whether the system is configured to allow an LT slot to be automatically re-planned into a new slot value upon LT hardware migration. Enabling this feature makes sure that a new compatible LT inserted into an already configured slot becomes operational automatically, without loss of the original configuration database and without requiring any (re-)configuration action. This only applies to certain board replacement scenarios and for a subset of (from/to) LT types.

By default, the field is set to false (value 2) i.e. the slot will not be automatically re-planned when the new LT is inserted. When the feature is enabled by the operator, the value is set to True (value 1).

User Level

The command can be accessed by operators with equipment privileges, and executed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

```
> configure equipment replan [ boardautoreplan <Eqpt::BoardAutoReplan> ]
```

Command Parameters

Table 5.20-2 "Configure Board Auto Replan feature" Command Parameters

Parameter	Type	Description
boardautoreplan	Parameter type: <Eqpt::BoardAutoReplan> Format: (enable disable) Possible values: - enable : enable board auto replan functionality - disable : disable board auto replan functionality	<i>optional parameter</i> Set the Board Auto Replan feature

6- Gpon ONT Configuration Commands

6.1 Gpon ONT Configuration Command Tree	6-351
6.2 ONT Interface Configuration Command	6-354
6.3 NGPON2 Rogue Onu Prevention Configuration Commands	6-363
6.4 GPON GEM port performance monitoring Configuration Commands	6-365
6.5 ONT-SIDE TC-layer Performance Monitoring Counter Thresholds Configuration Command for ONT	6-367
6.6 Multicast TC-layer Performance Monitoring Command for ONT	6-369
6.7 Fec TC-layer Performance Monitoring Command for ONT	6-371
6.8 GPON port Aggregate Ethernet performance monitoring Configuration Commands	6-373
6.9 XGPON tc-layer port performance monitoring Configuration Commands	6-375
6.10 XGPON physical-layer port performance monitoring Configuration Commands	6-377
6.11 GPON ONT software delay activation control Configuration Commands	6-379
6.12 GPON ONT CPU Load Performance Monitoring Configuration Command	6-381
6.13 GPON ONT Memory Usage Performance Monitoring Configuration Command	6-383
6.14 ONT Card Configuration Command	6-385
6.15 ONT Software Control Configuration Command	6-388
6.16 GPON ONT software delay activation control Configuration Commands	6-390
6.17 ONT Interface Configuration Command	6-391
6.18 ONT GIS Configuration Command	6-393
6.19 ONT xgpon Configuration Command	6-395

6.1 Gpon ONT Configuration Command Tree

Description

This chapter gives an overview of nodes that are handled by "Gpon ONT Configuration Commands".

Command Tree

```

----configure
  ----equipment
    ----ont
      ----[no] interface
        - (ont-idx)
        - [no] battery-bkup
        - [no] berint
        - [no] desc1
        - [no] desc2
        - [no] provversion
        - [no] sernum
        - subslocid
        - sw-ver-pland
        - [no] fec-up
        - [no] bridge-map-mode
        - [no] pwr-shed-prof-id
        - [no] ont-enable
        - [no] p2p-enable
        - [no] optics-hist
        - [no] sw-dnload-version
        - [no] plnd-var
        - [no] rf-filter
        - [no] us-police-mode
        - [no] enable-aes
        - [no] voip-allowed
        - [no] iphc-allowed
        - [no] slid-visibility
        - [no] log-auth-id
        - [no] log-auth-pwd
        - [no] cvlantrans-mode
        - [no] sn-bundle-ctrl
        - [no] pland-cfgfile1
        - [no] pland-cfgfile2
        - [no] dnload-cfgfile1
        - [no] dnload-cfgfile2
        - [no] us-tcpolice-mode
        - [no] planned-us-rate
        - admin-state
        - [no] oltdscppbitalign
        - [no] pref-channel-pair
        - [no] prot-channel-pair
        - [no] alt-pref-ch-pair
        - [no] ratelimit-us-dhcp
        - [no] ratelimit-us-arp
        - [no] flush-mac

```

- [no] template-name
- [no] evtocd
- [no] vtfd
- onu-tssi-detect**
 - [no] poll-interval
 - [no] poll-cnt
 - [no] alm-ctrl
- tc-layer**
 - [no] olt-pm-collect
 - [no] od-pm-collect
 - [no] ont-pm-collect
- tc-layer-threshold**
 - [no] lost-frags-down
 - [no] lost-frags-up
 - [no] bad-headers-down
- mcast-tc-layer**
 - [no] ont-pm-collect
- fec-tc-layer**
 - [no] olt-pm-collect
 - [no] ont-pm-collect
- ethernet**
 - [no] ont-pm-collect
- xg-tc-layer**
 - [no] olt-pm-collect
 - [no] ont-pm-collect
- phy-layer**
 - [no] olt-pm-collect
- delay-act**
 - [no] at
- cpu-load**
 - [no] ont-pm-collect
- memory-usage**
 - [no] ont-pm-collect
- [no] slot**
 - **(ont-slot-idx)**
 - planned-card-type
 - plndnumdataports
 - plndnumvoiceports
 - [no] port-type
 - [no] transp-mode-rem
 - [no] no-mcast-control
 - [no] admin-state
- [no] sw-ctrl**
 - **(sw-ctrl-id)**
 - hw-version
 - [no] ont-variant
 - [no] plnd-sw-version
 - [no] plnd-sw-ver-conf
 - [no] sw-dwload-ver
 - [no] pland-cfgfile1
 - [no] pland-cfgfile2
 - [no] dnload-cfgfile1
 - [no] dnload-cfgfile2
- delay-act**
 - [no] at
- loop**
 - **(ont-idx)**
 - [no] loop-detect
 - [no] loop-portautosht

```
----gis
- (ont-idx)
- [no] olt-location
----pm-collect
- (ont-idx)
- [no] xg-pm-collect
```

6.2 ONT Interface Configuration Command

Command Description

This command allows the operator to create and configure the ONT parameters.

provversion - when '' is set, it detects ONT hardware version on board and is updated accordingly.*

sernum - User can only set it when admin state is down and admin-state cannot be changed to up with default sernum (ALCL:00000000). The First 4 bytes form the vendorid and the last 8 bytes form the serial no.

sw-ver-pland - The special string of 'AUTO' is used to indicate that if this ONT's hardware version (eqpt-ver-num in 'show ont interface command) and planned variant (plnd-var) has a matching entry created using 'configure equipment ont sw-ctrl', then the plnd-sw-version from the gponOntSwVerCtlTable table will be downloaded to the ONT. The special string of 'UNPLANNED' is used to avoid any download. The special string of 'DISABLED' is used not to control onu sw version, and not report mismatch alarm. The special string of 'DELAYACTIVATE' is used for non-immediate activation.

subslocid - 0 to 12 (36 for ngpon2/xgs/25g) ASCII character string or 0 to 24 (72 for ngpon2/xgs/25g) HEX string depending on slidmode.

sw-dnload-version - The special string of 'AUTO' is used to indicate that if this ONT's hardware version (eqpt-ver-num in 'show equipment ont interface command) and planned variant (plnd-var) has a matching entry created using 'configure equipment ont sw-ctrl', then the plnd-sw-version from the gponOntSwVerCtlTable table will be downloaded to the ONT. The special string of 'DISABLED' is used to indicate this feature as blocked. If sw-ver-pland is set to 'DISABLED', sw-dnload-version can only be 'DISABLED'.

NOTE: In order to change power-shed-profile, provversion, sernum, fec-up, us-police-mode, us_tcpolice-mode, log-auth-id and log-auth-pwd parameters, the ONT state must be in Out-of-Service. If not specified, the values of the above parameters stay unchanged.

admin-state - cannot be modified in the same command execution with any other parameter and vice versa. If not specified, the value of this parameter stays unchanged.

User Level

The command can be accessed by operators with equipment privileges, and executed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

```
> configure equipment ont ( no interface (ont-idx) ) | ( interface (ont-idx) [ no battery-bkup | battery-bkup
<Gpon::BatteryBkup> ] [ no berint | berint <Gpon::BertInterval> ] [ no desc1 | desc1 <Gpon::Desc> ] [ no desc2 |
desc2 <Gpon::Desc> ] [ no provversion | provversion <Gpon::ProvVersion> ] [ no sernum | sernum
<Gpon::SerNum> ] [ subslocid <Gpon::SubsLocId> ] sw-ver-pland <Gpon::SwVerPlnd> [ no fec-up | fec-up
<Gpon::FecUp> ] [ no bridge-map-mode | bridge-map-mode <Gpon::BridgeMapMode> ] [ no pwr-shed-prof-id |
pwr-shed-prof-id <Gpon::PwrShedProfIndex> ] [ no ont-enable | ont-enable <Gpon::OntEnable> ] [ no p2p-enable |
p2p-enable <Gpon::P2PEnable> ] [ no optics-hist | optics-hist <Gpon::OpticsHist> ] [ no sw-dnload-version |
sw-dnload-version <Gpon::SwVerDn> ] [ no plnd-var | plnd-var <Gpon::PlndVar> ] [ no rf-filter | rf-filter
<Gpon::RfFilter> ] [ no us-police-mode | us-police-mode <Gpon::UsPoliceMode> ] [ no enable-aes | enable-aes
<Gpon::EnableAES> ] [ no voip-allowed | voip-allowed <Gpon::VoipAllowed> ] [ no iphc-allowed | iphc-allowed
<Gpon::IphcAllowed> ] [ no slid-visibility | slid-visibility <Gpon::SlidAvailabilityStatus> ] [ no log-auth-id |
log-auth-id <Gpon::LogAuthId> ] [ no log-auth-pwd | log-auth-pwd <Security::Password6> ] [ no cvlantrans-mode
```

```

| cvlantrans-mode <Gpon::CVlanTransMode> ] [ no sn-bundle-ctrl | sn-bundle-ctrl <Gpon::SnBundleCtrl> ] [ no
pland-cfgfile1 | pland-cfgfile1 <Gpon::CfgFileName> ] [ no pland-cfgfile2 | pland-cfgfile2 <Gpon::CfgFileName>
] [ no dnload-cfgfile1 | dnload-cfgfile1 <Gpon::CfgFileName> ] [ no dnload-cfgfile2 | dnload-cfgfile2
<Gpon::CfgFileName> ] [ no us-tcpolice-mode | us-tcpolice-mode <Gpon::UsTcPoliceMode> ] [ no
planned-us-rate | planned-us-rate <Gpon::PlannedUsRate> ] [ admin-state <Gpon::ItfAdminStatus> ] [ no
oltdscppbitalign | oltdscppbitalign <Gpon::OltDscppbitalign> ] [ no pref-channel-pair | pref-channel-pair
<Ng2::PreferredChannelPairIndex> ] [ no prot-channel-pair | prot-channel-pair <Ng2::PreferredChannelPairIndex>
] [ no alt-pref-ch-pair | alt-pref-ch-pair <Ng2::PreferredChannelPairIndex> ] [ no ratelimit-us-dhcp |
ratelimit-us-dhcp <Gpon::RateLimitUsDhcp> ] [ no ratelimit-us-arp | ratelimit-us-arp <Gpon::RateLimitUsArp> ] [
no flush-mac | flush-mac <Gpon::FlushMac> ] [ no template-name | template-name
<Gpon::OnuProvTemplateName> ] [ no evtocd | evtocd <Gpon::Evtocd> ] [ no vtfd | vtfd <Gpon::Vtfd> ] )

```

Command Parameters

Table 6.2-1 "ONT Interface Configuration Command" Resource Parameters

Resource Identifier	Type	Description
(ont-idx)	Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> ng2 : <Ng2::ChannelGroup> / <Ng2::SubchannelGroup> / <Ng2::OntId>) Possible values: - ng2 : ngpon2 style identification Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Ng2::ChannelGroup> - channel group number Field type <Ng2::SubchannelGroup> - subchannel group number Field type <Eqpt::OntId> - the ONT identifier Field type <Ng2::OntId> - the ONT identifier	ONT index

Table 6.2-2 "ONT Interface Configuration Command" Command Parameters

Parameter	Type	Description
[no] battery-bkup	Parameter type: <Gpon::BatteryBkup> Format: (disable enable) Possible values: - disable : ONT is not equipped with battery backup - enable : ONT is equipped with battery backup	<i>optional parameter with default value: "disable"</i> battery backup
[no] berint	Parameter type: <Gpon::BertInterval> Format: - BER Interval - range: [8000...100000]	<i>optional parameter with default value: "8000"</i> accumulation interval (in number of downstream frames) for ONU BER calculation
[no] desc1	Parameter type: <Gpon::Desc> Format:	<i>optional parameter with default value: ""</i>

6 Gpon ONT Configuration Commands

Parameter	Type	Description
	- desc - length: x<=64	free-form textual field for user to describe the ONT
[no] desc2	Parameter type: <Gpon::Desc> Format: - desc - length: x<=64	<i>optional parameter with default value: ""</i> free-form textual field for user to describe the ONT
[no] provversion	Parameter type: <Gpon::ProvVersion> Format: - provisioned version number - length: x<=14	<i>optional parameter with default value: ""</i> the provisioned version number
[no] sernum	Parameter type: <Gpon::SerNum> Format: <Gpon::VendorId> : <Gpon::SerialNo> Field type <Gpon::VendorId> - vendor id - 4 ASCII characters - range: [a-zA-Z0-9] - length: 4 Field type <Gpon::SerialNo> - serial num - 8 ASCII characters - range: [a-fA-F0-9] - length: 8	<i>optional parameter with default value: "ALCL : 00000000"</i> the provisioned serial number
subslcid	Parameter type: <Gpon::SubsLocId> Format: - subsloc id, 0 to 12 (36 for ngpon2/xgs/25g) ASCII character string or 0 to 24 (72 for ngpon2/xgs/25g) HEX string depending on slidmode - length: x<=72	<i>optional parameter</i> subscriber location id (SLID)
sw-ver-pland	Parameter type: <Gpon::SwVerPlnd> Format: (auto unplanned disabled delayactivate <Gpon::SwVerPlnd>) Possible values: - auto : download sw to onu using the sw-ctrl version - unplanned : avoid any download related action, but report mismatch alarm - disabled : not to control onu sw version, and not report mismatch alarm - delayactivate : for non-immediate activation Field type <Gpon::SwVerPlnd> - ont sw version - length: 1<=x<=14	<i>mandatory parameter</i> planned ONT software version number. If sw-dnload-version is set to disabled, sw-ver-pland cannot be set to delayactivate.
[no] fec-up	Parameter type: <Gpon::FecUp> Format: (disable enable recommended) Possible values: - disable : Disable use of FEC in Upstream direction - enable : Enable use of FEC in Upstream direction - recommended : Automatically set based on planned ONT technology: gpon=disable,ngpon=enable,auto-match=enable	<i>optional parameter with default value: "gpon : disable,ngpon : enable,auto-match : enable"</i> enable/disable use of FEC in Upstream direction
[no] bridge-map-mode	Parameter type: <Gpon::BridgeMapMode> Format: (1-mp-bridge-map-filter	<i>optional parameter with default value: "1-mp-bridge-map-filter"</i> ont bridge map mode

Parameter	Type	Description
	n-p-bridge-map-filter n-mp-bridge-map-filter) Possible values: - 1-mp-bridge-map-filter: 1:MP bridge map mode - n-p-bridge-map-filter : N:P bridge map mode - n-mp-bridge-map-filter: N:MP bridge map mode	
[no] pwr-shed-prof-id	Parameter type: <Gpon::PwrShedProfIndex> Format: (none <Gpon::PwrShedProfIndex>) Possible values: - none : no profile to associate Field type <Gpon::PwrShedProfIndex> - a pwr shed profile index value - range: [0...50]	<i>optional parameter with default value: "none"</i> power shed profile id
[no] ont-enable	Parameter type: <Gpon::OntEnable> Format: (auto disable enable) Possible values: - auto : OLT automatically decided on proper action - disable : ONT is Manually Disabled - enable : ONT is Manually Enabled	<i>optional parameter with default value: "auto"</i> ONT disabling decision for rogue ONTs
[no] p2p-enable	Parameter type: <Gpon::P2PEnable> Format: (disable enable) Possible values: - disable : Disable Port-to-port traffic exchange - enable : Enable Port-to-port traffic exchange	<i>optional parameter with default value: "disable"</i> <i>The parameter is not visible during modification.</i> allow port-to-port traffic exchange between ethernet UNIs on the same ONT
[no] optics-hist	Parameter type: <Gpon::OpticsHist> Format: (disable enable) Possible values: - disable : Disable daily optical supervision measurements collection - enable : Enable daily optical supervision measurements collection	<i>optional parameter with default value: "disable"</i> daily optical supervision measurements collection
[no] sw-dnload-version	Parameter type: <Gpon::SwVerDn> Format: (auto disabled <Gpon::SwVerDn>) Possible values: - auto : download sw to onu using the sw-ctrl version - disabled : indicate this feature is blocked. If sw-ver-pland is set to disabled, sw-dnload-version can only be disabled Field type <Gpon::SwVerDn> - ont sw version - length: 1<=x<=14	<i>optional parameter with default value: "DISABLED"</i> standby ONT software version number to be downloaded. If sw-ver-pland is set to delayactivate, sw-dnload-version cannot be set to disabled.
[no] plnd-var	Parameter type: <Gpon::PlndVar> Format: - planned variant of the ONT hardware version - length: x<=80	<i>optional parameter with default value: ""</i> planned variant of the ONT hardware version. Use DO for Data-only ONTs, SIP for SIP

6 Gpon ONT Configuration Commands

Parameter	Type	Description
		ONTs,H.248 for MEGACO ONTs
[no] rf-filter	Parameter type: <Gpon::RfFilter> Format: (pass-none pass-low pass-low-high pass-low-middle) Possible values: - pass-none : Pass Nothing - pass-low : Pass only Low Band - pass-low-high : Pass Low and High Band - pass-low-middle : Pass Low and Middle Band	<i>optional parameter with default value: "pass-low-high"</i> filter settings for RF video
[no] us-police-mode	Parameter type: <Gpon::UsPoliceMode> Format: (local network remote) Possible values: - local : local at OLT - network : remote at OLT obsolete alternative replaced by remote - remote : remote at ONT	<i>optional parameter with default value: "local"</i> upstream police mode
[no] enable-aes	Parameter type: <Gpon::EnableAES> Format: (disable enable) Possible values: - disable : disable downstream AES encryption - enable : enable downstream AES encryption	<i>optional parameter with default value: "disable"</i> downstream AES encryption for all unicast (X)GEM ports pertaining to the ONT
[no] voip-allowed	Parameter type: <Gpon::VoipAllowed> Format: (disable enable iphost veip) Possible values: - disable : disable voip support on ONT - enable : enable voip support on ONT - iphost : enable voip support on ONT using iphost - veip : enable voip support on ONT using veip	<i>optional parameter with default value: "disable"</i> <i>The parameter is not visible during modification.</i> voip support on ONT
[no] iphc-allowed	Parameter type: <Gpon::IphcAllowed> Format: (disable enable) Possible values: - disable : disable iphc support on ONT - enable : enable iphc support on ONT	<i>optional parameter with default value: "disable"</i> <i>The parameter is not visible during modification.</i> iphc support on ONT
[no] slid-visibility	Parameter type: <Gpon::SlidAvailabilityStatus> Format: (disabled enabled-slid-on enabled-all) Possible values: - disabled : no access using http or telnet - enabled-slid-on : read-only access using http or telnet - enabled-all : read-write access using http or telnet	<i>optional parameter with default value: "disabled"</i> <i>The parameter is not visible during creation.</i> slid visibility of the interface

Parameter	Type	Description
[no] log-auth-id	Parameter type: <Gpon::LogAuthId> Format: - ont logical id - length: x<=24	<i>optional parameter with default value: ""</i> the logical id for the ont
[no] log-auth-pwd	Parameter type: <Security::Password6> Format: (prompt plain : <Security::PlainPassword6>) Possible values: - prompt : prompts the operator for a password - plain : the password in plain text Field type <Security::PlainPassword6> - ont password - length: x<=12	<i>optional parameter with default value: "plain : "</i> the password for the ont
[no] cvlantrans-mode	Parameter type: <Gpon::CVlanTransMode> Format: (remote local) Possible values: - remote : cvlan translate remote - local : cvlan translate local	<i>optional parameter with default value: "remote"</i> cvlan translation settings for all traffic except the configured multicast traffic
[no] sn-bundle-ctrl	Parameter type: <Gpon::SnBundleCtrl> Format: (unbundle bundle auto) Possible values: - unbundle : no bundle behavior for sn with loid/sluid - bundle : manual bundling of sn with loid/sluid - auto : automatically bundle the sn with loid/sluid when a new sn is learned	<i>optional parameter with default value: "unbundle"</i> sn bundling behavior associated with slid/loid
[no] pland-cfgfile1	Parameter type: <Gpon::CfgFileName> Format: (auto <Gpon::CfgFileName>) Possible values: - auto : download configure file to onu using the sw-ctrl version Field type <Gpon::CfgFileName> - ont configure file version - length: 1<=x<=14	<i>optional parameter with default value: "DISABLED"</i> indicate the cfgfile1 version to be planned
[no] pland-cfgfile2	Parameter type: <Gpon::CfgFileName> Format: (auto <Gpon::CfgFileName>) Possible values: - auto : download configure file to onu using the sw-ctrl version Field type <Gpon::CfgFileName> - ont configure file version - length: 1<=x<=14	<i>optional parameter with default value: "DISABLED"</i> indicate the cfgfile2 version to be planned
[no] dnload-cfgfile1	Parameter type: <Gpon::CfgFileName> Format: (auto <Gpon::CfgFileName>) Possible values: - auto : download configure file to onu using the sw-ctrl	<i>optional parameter with default value: "DISABLED"</i> indicate the cfgfile1 version to be downloaded

6 Gpon ONT Configuration Commands

Parameter	Type	Description
	version Field type <Gpon::CfgFileName> - ont configure file version - length: 1<=x<=14	
[no] dnload-cfgfile2	Parameter type: <Gpon::CfgFileName> Format: (auto <Gpon::CfgFileName>) Possible values: - auto : download configure file to onu using the sw-ctrl version Field type <Gpon::CfgFileName> - ont configure file version - length: 1<=x<=14	<i>optional parameter with default value: "DISABLED"</i> indicate the cfgfile2 version to be downloaded
[no] us-tcpolice-mode	Parameter type: <Gpon::UsTcPoliceMode> Format: (local remote) Possible values: - local : local at OLT - remote : remote at ONT	<i>optional parameter with default value: "local"</i> upstream tc(gemport) police mode
[no] planned-us-rate	Parameter type: <Gpon::PlannedUsRate> Format: (nominal-line-rate 2.5g 10g 1.25g auto-match 25g) Possible values: - nominal-line-rate : ont inherits upstream rate from nominal line rate(default) - 2.5g : 2.5 GBit/sec - 10g : 10 GBit/sec - 1.25g : 1.25 GBit/sec - auto-match : upstream rate is detected when onu activates - 25g : 25 GBit/sec	<i>optional parameter with default value: "nominal-line-rate,cde : auto-match"</i> planned upstream rate
admin-state	Parameter type: <Gpon::ItfAdminStatus> Format: (up down) Possible values: - up : set the admin-state to up - down : set the admin-state to down	<i>optional parameter</i> <i>The parameter is not visible during creation.</i> administrative status of the interface
[no] oltdscppbitalign	Parameter type: <Gpon::OltDscpPbitAlign> Format: (disable enable) Possible values: - disable : OLT will not do dscp-to-pbit alignment - enable : OLT will do dscp-to-pbit alignment	<i>optional parameter with default value: "disable"</i> if OLT need perform DSCP to Pbit alignment for this ONU, when the DSCP to Pbit alignment is configured on the vlan port
[no] pref-channel-pair	Parameter type: <Ng2::PreferredChannelPairIndex> Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::ChannelPairId> none) Possible values:	<i>optional parameter with default value: "none"</i> preferred channel pair in case of ngpon2 ont

Parameter	Type	Description
	- none : lt board not specified Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::ChannelPairId> - the channel pair identifier	
[no] prot-channel-pair	Parameter type: <Ng2::PreferredChannelPairIndex> Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::ChannelPairId> none) Possible values: - none : lt board not specified Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::ChannelPairId> - the channel pair identifier	<i>optional parameter with default value: "none"</i> protecting channel pair in case of ngpon2 ont
[no] alt-pref-ch-pair	Parameter type: <Ng2::PreferredChannelPairIndex> Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::ChannelPairId> none) Possible values: - none : lt board not specified Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::ChannelPairId> - the channel pair identifier	<i>optional parameter with default value: "none"</i> alternative preferred channel pair in case of ngpon2 ont
[no] ratelimit-us-dhcp	Parameter type: <Gpon::RateLimitUsDhcp> Format: - ratelimit upstream DHCP packets, 0 - Disabled, 1..16 - Enabled (Packets Per Second limit) - range: [0...16]	<i>optional parameter with default value: "10"</i> upstream rate limit for DHCP packets, unit is pps which means packets per second
[no] ratelimit-us-arp	Parameter type: <Gpon::RateLimitUsArp> Format: - ratelimit upstream ARP packets, 0 - Disabled, 1..16 - Enabled (Packets Per Second limit) - range: [0...16]	<i>optional parameter with default value: "10"</i> upstream rate limit for ARP packets, unit is pps which means packets per second
[no] flush-mac	Parameter type: <Gpon::FlushMac> Format: (disable enable) Possible values: - disable : the MAC will not be flushed when UNIs go down - enable : the MAC will be flushed when UNIs go down	<i>optional parameter with default value: "disable"</i> flush MAC decision for UNIs of this ONT
[no] template-name	Parameter type: <Gpon::OnuProvTemplateName>	<i>optional parameter with default</i>

6 Gpon ONT Configuration Commands

Parameter	Type	Description
	Format: - Template name to be used for ONU auto provisioning - range: [a-zA-Z0-9-_ - length: x<=20	<i>value: "DEFAULT"</i> Name of the Template to be used for ONU auto-provisioning
[no] evtocd	Parameter type: <Gpon::Evtocd> Format: (disable enable) Possible values: - disable : Disable ME Extended VLAN tagging operation configuration data - enable : Enable ME Extended VLAN tagging operation configuration data	<i>optional parameter with default value: "enable"</i> ME Evtocd control
[no] vtfd	Parameter type: <Gpon::Vtfd> Format: (disable enable) Possible values: - disable : Disable ME VLAN tagging filter data - enable : Enable ME VLAN tagging filter data	<i>optional parameter with default value: "enable"</i> ME Vtfd control

Command Output

Table 6.2-3 "ONT Interface Configuration Command" Display parameters

Specific Information		
name	Type	Description
oper-state	Parameter type: <If::ifOperStatus> (up down testing unknown dormant no-value) Possible values: - up : up,traffic can pass - down : down,no traffic is passing - testing : testing,no traffic is passing - unknown : unknown - dormant : dormant,no traffic is passing - no-value : no entry in the table	operational state of the interface <i>This element is always shown.</i>
pwr-shed-prof-name	Parameter type: <Gpon::IgnoredPrintableString> - ignored printable string	power shed profile name <i>This element is always shown.</i>

6.3 NGPON2 Rogue Onu Prevention Configuration Commands

Command Description

This command allows the operator to configure following rogue onu prevention paramters.

- Parameters that controls rogue onu optical transceiver abnormal declaration
- Parameters that enable or disable reporting of rogue onu optical transceiver abnormal alarm

User Level

The command can be accessed by operators with equipment privileges, and executed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

```
> configure equipment ont interface (ont-idx) onu-tssi-detect [ no poll-interval | poll-interval
<Gpon::RogOnuPollInter> ] [ no poll-cnt | poll-cnt <Gpon::RogOnuPollCnt> ] [ no alm-ctrl | alm-ctrl
<Gpon::RogOnuAlmCtl> ]
```

Command Parameters

Table 6.3-1 "NGPON2 Rogue Onu Prevention Configuration Commands" Resource Parameters

Resource Identifier	Type	Description
(ont-idx)	Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> ng2 : <Ng2::ChannelGroup> / <Ng2::SubchannelGroup> / <Ng2::OntId>) Possible values: - ng2 : ngpon2 style identification Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Ng2::ChannelGroup> - channel group number Field type <Ng2::SubchannelGroup> - subchannel group number Field type <Eqpt::OntId>	ONT index

Resource Identifier	Type	Description
	- the ONT identifier Field type <Ng2::OntId> - the ONT identifier	

Table 6.3-2 "NGPON2 Rogue Onu Prevention Configuration Commands" Command Parameters

Parameter	Type	Description
[no] poll-interval	Parameter type: <Gpon::RogOnuPollInter> Format: (nopoll <Gpon::RogOnuPollInter>) Possible values: - nopoll : polling is not used Field type <Gpon::RogOnuPollInter> - interval of polling optical transceiver at the ONT(0 : polling is not used) - unit: millisec - range: [20...60000,0]	<i>optional parameter with default value: "20"</i> interval of polling optical transceiver at the ONT
[no] poll-cnt	Parameter type: <Gpon::RogOnuPollCnt> Format: - the number of consecutive polling, which results in abnormality, for declaring the optical transceiver as abnormal - range: [1...250]	<i>optional parameter with default value: "150"</i> number of consecutive polling, which results in abnormality, for declaring the optical transceiver as abnormal
[no] alm-ctrl	Parameter type: <Gpon::RogOnuAlmCtl> Format: (enable disable) Possible values: - enable : enable TSSI alarm - disable : disable TSSI alarm	<i>optional parameter with default value: "enable"</i> enabling or disable alarm for rouge ONU

6.4 GPON GEM port performance monitoring Configuration Commands

Command Description

This command allows the operator to enable the following GEM port performance monitoring counters.

- PM Mode of OLT-side TC-layer (GEM-based) counters
- PM Mode of OLT-side TC-layer (GEM-based) counters for errored fragments
- PM Mode of ONT-side TC-layer (GEM-based) counters

User Level

The command can be accessed by operators with equipment privileges, and executed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

```
> configure equipment ont interface (ont-idx) tc-layer [ no olt-pm-collect | olt-pm-collect
<Gpon::OntPmTcaCollect> ] [ no od-pm-collect | od-pm-collect <Gpon::OntPmCollect> ] [ no ont-pm-collect |
ont-pm-collect <Gpon::OntPmTcaCollect> ]
```

Command Parameters

Table 6.4-1 "GPON GEM port performance monitoring Configuration Commands" Resource Parameters

Resource Identifier	Type	Description
(ont-idx)	Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> ng2 : <Ng2::ChannelGroup> / <Ng2::SubchannelGroup> / <Ng2::OntId>) Possible values: - ng2 : ngpon2 style identification Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Ng2::ChannelGroup> - channel group number Field type <Ng2::SubchannelGroup>	ONT index

Resource Identifier	Type	Description
	- subchannel group number Field type <Eqpt::OntId> - the ONT identifier Field type <Ng2::OntId> - the ONT identifier	

Table 6.4-2 "GPON GEM port performance monitoring Configuration Commands" Command Parameters

Parameter	Type	Description
[no] olt-pm-collect	Parameter type: <Gpon::OntPmTcaCollect> Format: (none pm-enable tca-enable) Possible values: - none : no pm - pm-enable : enable pm - tca-enable : enable tca	<i>optional parameter with default value: "pm-enable"</i> OLT-side aggregate TC layer performance monitoring
[no] od-pm-collect	Parameter type: <Gpon::OntPmCollect> Format: (enable disable) Possible values: - enable : enable PM - disable : disable PM	<i>optional parameter with default value: "disable"</i> OLT-side on-demand aggregate TC layer performance monitoring
[no] ont-pm-collect	Parameter type: <Gpon::OntPmTcaCollect> Format: (none pm-enable tca-enable) Possible values: - none : no pm - pm-enable : enable pm - tca-enable : enable tca	<i>optional parameter with default value: "pm-enable"</i> ONT-side aggregate TC layer performance monitoring

6.5 ONT-SIDE TC-layer Performance Monitoring Counter Thresholds Configuration Command for ONT

Command Description

This command allows the operator to enable configuration of performance Monitoring counter thresholds for ONT-Side TC-layer errored fragments.

User Level

The command can be accessed by operators with equipment privileges, and executed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

```
> configure equipment ont interface (ont-idx) tc-layer-threshold [ no lost-frags-down | lost-frags-down
<Gpon::TcaThresholdValue> ] [ no lost-frags-up | lost-frags-up <Gpon::TcaThresholdValue> ] [ no
bad-headers-down | bad-headers-down <Gpon::TcaThresholdValue> ]
```

Command Parameters

Table 6.5-1 "ONT-SIDE TC-layer Performance Monitoring Counter Thresholds Configuration Command for ONT" Resource Parameters

Resource Identifier	Type	Description
(ont-idx)	Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> ng2 : <Ng2::ChannelGroup> / <Ng2::SubchannelGroup> / <Ng2::OntId>) Possible values: - ng2 : ngpon2 style identification Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Ng2::ChannelGroup> - channel group number Field type <Ng2::SubchannelGroup>	ONT index

Resource Identifier	Type	Description
	- subchannel group number Field type <Eqpt::OntId> - the ONT identifier Field type <Ng2::OntId> - the ONT identifier	

Table 6.5-2 "ONT-SIDE TC-layer Performance Monitoring Counter Thresholds Configuration Command for ONT" Command Parameters

Parameter	Type	Description
[no] lost-frags-down	Parameter type: <Gpon::TcaThresholdValue> Format: (disabled <Gpon::TcaThresholdValue>) Possible values: - disabled : threshold is disabled Field type <Gpon::TcaThresholdValue> - tc-layer tca threshold value (4294967295=disabled) - range: [0...4294967294,4294967295]	<i>optional parameter with default value: "disabled"</i> tca setting for lost gem fragments in downstream
[no] lost-frags-up	Parameter type: <Gpon::TcaThresholdValue> Format: (disabled <Gpon::TcaThresholdValue>) Possible values: - disabled : threshold is disabled Field type <Gpon::TcaThresholdValue> - tc-layer tca threshold value (4294967295=disabled) - range: [0...4294967294,4294967295]	<i>optional parameter with default value: "disabled"</i> tca setting for lost gem fragments in upstream
[no] bad-headers-down	Parameter type: <Gpon::TcaThresholdValue> Format: (disabled <Gpon::TcaThresholdValue>) Possible values: - disabled : threshold is disabled Field type <Gpon::TcaThresholdValue> - tc-layer tca threshold value (4294967295=disabled) - range: [0...4294967294,4294967295]	<i>optional parameter with default value: "disabled"</i> tca setting for bad gem headers in downstream

6.6 Multicast TC-layer Performance Monitoring Command for ONT

Command Description

This command allows the operator to enable or disable the ONT-side Multicast Port Performance Monitor collection for the ONT.

User Level

The command can be accessed by operators with equipment privileges, and executed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

```
> configure equipment ont interface (ont-idx) mcast-tc-layer [ no ont-pm-collect | ont-pm-collect
<Gpon::OntPmCollect> ]
```

Command Parameters

Table 6.6-1 "Multicast TC-layer Performance Monitoring Command for ONT" Resource Parameters

Resource Identifier	Type	Description
(ont-idx)	Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> ng2 : <Ng2::ChannelGroup> / <Ng2::SubchannelGroup> / <Ng2::OntId>) Possible values: - ng2 : ngpon2 style identification Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Ng2::ChannelGroup> - channel group number Field type <Ng2::SubchannelGroup> - subchannel group number Field type <Eqpt::OntId> - the ONT identifier Field type <Ng2::OntId>	ONT index

Resource Identifier	Type	Description
	- the ONT identifier	

Table 6.6-2 "Multicast TC-layer Performance Monitoring Command for ONT" Command Parameters

Parameter	Type	Description
[no] ont-pm-collect	Parameter type: <Gpon::OntPmCollect> Format: (enable disable) Possible values: - enable : enable PM - disable : disable PM	<i>optional parameter with default value: "disable"</i> ONT-side multicast performance monitoring

Command Output

Table 6.6-3 "Multicast TC-layer Performance Monitoring Command for ONT" Display parameters

Specific Information		
name	Type	Description
interval-no	Parameter type: <SignedInteger> - a signed integer	number of rows currently present in the gponMulticastServiceOntsideGemInterval <i>This element is always shown.</i>

6.7 Fec TC-layer Performance Monitoring Command for ONT

Command Description

This command allows the operator to enable or disable the Fec Port Performance Monitor collection for the ONT.

User Level

The command can be accessed by operators with equipment privileges, and executed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

```
> configure equipment ont interface (ont-idx) fec-tc-layer [ no olt-pm-collect | olt-pm-collect
<Gpon::OntPmCollect> ] [ no ont-pm-collect | ont-pm-collect <Gpon::OntPmCollect> ]
```

Command Parameters

Table 6.7-1 "Fec TC-layer Performance Monitoring Command for ONT" Resource Parameters

Resource Identifier	Type	Description
(ont-idx)	Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> ng2 : <Ng2::ChannelGroup> / <Ng2::SubchannelGroup> / <Ng2::OntId>) Possible values: - ng2 : ngpon2 style identification Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Ng2::ChannelGroup> - channel group number Field type <Ng2::SubchannelGroup> - subchannel group number Field type <Eqpt::OntId> - the ONT identifier Field type <Ng2::OntId> - the ONT identifier	ONT index

Table 6.7-2 "Fec TC-layer Performance Monitoring Command for ONT" Command Parameters

Parameter	Type	Description
[no] olt-pm-collect	Parameter type: <Gpon::OntPmCollect> Format: (enable disable) Possible values: - enable : enable PM - disable : disable PM	<i>optional parameter with default value: "disable"</i> OLT-side XGPON FEC performance monitoring
[no] ont-pm-collect	Parameter type: <Gpon::OntPmCollect> Format: (enable disable) Possible values: - enable : enable PM - disable : disable PM	<i>optional parameter with default value: "disable"</i> ONT-side FEC performance monitoring

Command Output

Table 6.7-3 "Fec TC-layer Performance Monitoring Command for ONT" Display parameters

Specific Information		
name	Type	Description
fec-interval-no	Parameter type: <SignedInteger> - a signed integer	number of rows currently present in the gponFecOntsideGemIntervalTable <i>This element is always shown.</i>

6.8 GPON port Aggregate Ethernet performance monitoring Configuration Commands

Command Description

This command allows the operator to enable the following PON Aggregate Ethernet performance monitoring counters.

- PM Mode of ONT-side PON Aggregate Ethernet counters

User Level

The command can be accessed by operators with equipment privileges, and executed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

```
> configure equipment ont interface (ont-idx) ethernet [ no ont-pm-collect | ont-pm-collect <Gpon::OntPmCollect> ]
```

Command Parameters

Table 6.8-1 "GPON port Aggregate Ethernet performance monitoring Configuration Commands" Resource Parameters

Resource Identifier	Type	Description
(ont-idx)	Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> ng2 : <Ng2::ChannelGroup> / <Ng2::SubchannelGroup> / <Ng2::OntId>) Possible values: - ng2 : ngpon2 style identification Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Ng2::ChannelGroup> - channel group number Field type <Ng2::SubchannelGroup> - subchannel group number Field type <Eqpt::OntId>	ONT index

Resource Identifier	Type	Description
	- the ONT identifier Field type <Ng2::OntId> - the ONT identifier	

**Table 6.8-2 "GPON port Aggregate Ethernet performance monitoring Configuration Commands"
Command Parameters**

Parameter	Type	Description
[no] ont-pm-collect	Parameter type: <Gpon::OntPmCollect> Format: (enable disable) Possible values: - enable : enable PM - disable : disable PM	<i>optional parameter with default value: "disable"</i> ONT-side PON aggregate Ethernet performance monitoring

6.9 XGPON tc-layer port performance monitoring Configuration Commands

Command Description

This command allows the operator to enable or disable XGPON TC layer performance monitoring for the ONT.

User Level

The command can be accessed by operators with equipment privileges, and executed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

```
> configure equipment ont interface (ont-idx) xg-tc-layer [ no olt-pm-collect | olt-pm-collect
<Gpon::OntPmCollect> ] [ no ont-pm-collect | ont-pm-collect <Gpon::OntPmCollect> ]
```

Command Parameters

Table 6.9-1 "XGPON tc-layer port performance monitoring Configuration Commands" Resource Parameters

Resource Identifier	Type	Description
(ont-idx)	Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> ng2 : <Ng2::ChannelGroup> / <Ng2::SubchannelGroup> / <Ng2::OntId>) Possible values: - ng2 : ngpon2 style identification Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Ng2::ChannelGroup> - channel group number Field type <Ng2::SubchannelGroup> - subchannel group number Field type <Eqpt::OntId> - the ONT identifier Field type <Ng2::OntId> - the ONT identifier	ONT index

Table 6.9-2 "XGPON tc-layer port performance monitoring Configuration Commands" Command Parameters

Parameter	Type	Description
[no] olt-pm-collect	Parameter type: <Gpon::OntPmCollect> Format: (enable disable) Possible values: - enable : enable PM - disable : disable PM	<i>optional parameter with default value: "disable"</i> OLT-side XGPON TC layer performance monitoring
[no] ont-pm-collect	Parameter type: <Gpon::OntPmCollect> Format: (enable disable) Possible values: - enable : enable PM - disable : disable PM	<i>optional parameter with default value: "disable"</i> ONT-side XGPON TC layer performance monitoring

6.10 XGPON physical-layer port performance monitoring Configuration Commands

Command Description

This command allows the operator to enable or disable the OLT-side XGPON Physical Performance Monitor collection for the ONT.

User Level

The command can be accessed by operators with equipment privileges, and executed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

```
> configure equipment ont interface (ont-idx) phy-layer [ no olt-pm-collect | olt-pm-collect <Gpon::OntPmCollect> ]
```

Command Parameters

Table 6.10-1 "XGPON physical-layer port performance monitoring Configuration Commands" Resource Parameters

Resource Identifier	Type	Description
(ont-idx)	Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> ng2 : <Ng2::ChannelGroup> / <Ng2::SubchannelGroup> / <Ng2::OntId>) Possible values: - ng2 : ngpon2 style identification Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Ng2::ChannelGroup> - channel group number Field type <Ng2::SubchannelGroup> - subchannel group number Field type <Eqpt::OntId> - the ONT identifier Field type <Ng2::OntId>	ONT index

Resource Identifier	Type	Description
	- the ONT identifier	

Table 6.10-2 "XGPON physical-layer port performance monitoring Configuration Commands"
Command Parameters

Parameter	Type	Description
[no] olt-pm-collect	Parameter type: <Gpon::OntPmCollect> Format: (enable disable) Possible values: - enable : enable PM - disable : disable PM	<i>optional parameter with default value: "disable"</i> OLT-side physical layer performance monitoring

6.11 GPON ONT software delay activation control Configuration Commands

Command Description

This command allows the operator to specify when OLT should attempt to activate ONT software.

This command is enabled only when sw-ver-pland is set as "delayactivate".

User Level

The command can be accessed by operators with equipment privileges, and executed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

```
> configure equipment ont interface (ont-idx) delay-act [ no at | at <Gpon::SwActTime> ]
```

Command Parameters

Table 6.11-1 "GPON ONT software delay activation control Configuration Commands" Resource Parameters

Resource Identifier	Type	Description
(ont-idx)	Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> ng2 : <Ng2::ChannelGroup> / <Ng2::SubchannelGroup> / <Ng2::OntId>) Possible values: - ng2 : ngpon2 style identification Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Ng2::ChannelGroup> - channel group number Field type <Ng2::SubchannelGroup> - subchannel group number Field type <Eqpt::OntId> - the ONT identifier Field type <Ng2::OntId>	ONT index

6 Gpon ONT Configuration Commands

Resource Identifier	Type	Description
	- the ONT identifier	

Table 6.11-2 "GPON ONT software delay activation control Configuration Commands" Command Parameters

Parameter	Type	Description
[no] at	Parameter type: <Gpon::SwActTime> Format: - scheduled ont sw activation time - range: [0...4294967295]	<i>optional parameter with default value: "1970-01-01 : 00 : 00"</i> schedule ONT SW specific activating time. Only if sw-ver-pland is set to delayactivate, delay-act at can be configured.

6.12 GPON ONT CPU Load Performance Monitoring Configuration Command

Command Description

This command allows the operator to enable the CPU Load Performance Monitoring PM flag for the ONT.

User Level

The command can be accessed by operators with equipment privileges, and executed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

```
> configure equipment ont interface (ont-idx) cpu-load [ no ont-pm-collect | ont-pm-collect <Gpon::OntPmCollect> ]
```

Command Parameters

Table 6.12-1 "GPON ONT CPU Load Performance Monitoring Configuration Command" Resource Parameters

Resource Identifier	Type	Description
(ont-idx)	Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> ng2 : <Ng2::ChannelGroup> / <Ng2::SubchannelGroup> / <Ng2::OntId>) Possible values: - ng2 : ngpon2 style identification Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Ng2::ChannelGroup> - channel group number Field type <Ng2::SubchannelGroup> - subchannel group number Field type <Eqpt::OntId> - the ONT identifier Field type <Ng2::OntId> - the ONT identifier	ONT index

**Table 6.12-2 "GPON ONT CPU Load Performance Monitoring Configuration Command"
Command Parameters**

Parameter	Type	Description
[no] ont-pm-collect	Parameter type: <Gpon::OntPmCollect> Format: (enable disable) Possible values: - enable : enable PM - disable : disable PM	<i>optional parameter with default value: "disable"</i> ONT-side CPU load performance monitoring

6.13 GPON ONT Memory Usage Performance Monitoring Configuration Command

Command Description

This command allows the operator to enable the Memory Usage Performance Monitoring PM flag for the ONT.

User Level

The command can be accessed by operators with equipment privileges, and executed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

```
> configure equipment ont interface (ont-idx) memory-usage [ no ont-pm-collect | ont-pm-collect
<Gpon::OntPmCollect> ]
```

Command Parameters

Table 6.13-1 "GPON ONT Memory Usage Performance Monitoring Configuration Command" Resource Parameters

Resource Identifier	Type	Description
(ont-idx)	Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> ng2 : <Ng2::ChannelGroup> / <Ng2::SubchannelGroup> / <Ng2::OntId>) Possible values: - ng2 : ngpon2 style identification Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Ng2::ChannelGroup> - channel group number Field type <Ng2::SubchannelGroup> - subchannel group number Field type <Eqpt::OntId> - the ONT identifier Field type <Ng2::OntId> - the ONT identifier	ONT index

Table 6.13-2 "GPON ONT Memory Usage Performance Monitoring Configuration Command" Command Parameters

Parameter	Type	Description
[no] ont-pm-collect	Parameter type: <Gpon::OntPmCollect> Format: (enable disable) Possible values: - enable : enable PM - disable : disable PM	<i>optional parameter with default value: "disable"</i> ONT-side Memory Usage performance monitoring

6.14 ONT Card Configuration Command

Command Description

This command allows the operator to create and configure the ONT Card parameters.

Prior to entering this command the ONT must have been already created.

User Level

The command can be accessed by operators with equipment privileges, and executed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

```
> configure equipment ont ( no slot (ont-slot-idx) ) | ( slot (ont-slot-idx) planned-card-type <Gpon::PlndCardType>
plndnumdataports <Gpon::PlndNumDataPorts> plndnumvoiceports <Gpon::PlndNumVoicePorts> [ no port-type |
port-type <Gpon::PortType> ] [ no transp-mode-rem | transp-mode-rem <Gpon::TranspMode> ] [ no
no-mcast-control | no-mcast-control <Gpon::NoMcastCtrl> ] [ no admin-state | admin-state <Gpon::AdminStatus> ]
)
```

Command Parameters

Table 6.14-1 "ONT Card Configuration Command" Resource Parameters

Resource Identifier	Type	Description
(ont-slot-idx)	Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Gpon::OntSlotId> ng2 : <Ng2::ChannelGroup> / <Ng2::SubchannelGroup> / <Ng2::OntId> / <Gpon::OntSlotId>) Possible values: - ng2 : ngpon2 style identification Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Ng2::ChannelGroup> - channel group number Field type <Ng2::SubchannelGroup> - subchannel group number Field type <Eqpt::OntId> - the ONT identifier Field type <Ng2::OntId> - the ONT identifier	identification of the ont-slot

Resource Identifier	Type	Description
	Field type <Gpon::OntSlotId> - Gpon Ont Slot - range: [1...14]	

Table 6.14-2 "ONT Card Configuration Command" Command Parameters

Parameter	Type	Description
planned-card-type	Parameter type: <Gpon::PlndCardType> Format: (ethernet 10_100base pots vdsl2pots vdsl2 ethpots video veip ds1 e1 hpna moca eth_adaptive) Possible values: - ethernet : 10/100/1000/10000 base-t - 10_100base : 10/100 base-t - pots : pots - vdsl2pots : vdsl2/pots combo - vdsl2 : vdsl2 - ethpots : ethernet/pots combo - video : video - veip : VEIP card - ds1 : ds1 - e1 : e1 - hpna : hpna - moca : moca - eth_adaptive : Self-adaptive between PPTP Ethernet and VEIP	<i>mandatory parameter</i> <i>The parameter is not visible during modification.</i> planned card type
plndnumdataports	Parameter type: <Gpon::PlndNumDataPorts> Format: - planned number of data ports - range: [0...16]	<i>mandatory parameter</i> planned number of data ports
plndnumvoiceports	Parameter type: <Gpon::PlndNumVoicePorts> Format: - planned number of voice ports - range: [0...24]	<i>mandatory parameter</i> planned number of voice ports
[no] port-type	Parameter type: <Gpon::PortType> Format: (uni nni) Possible values: - uni : uni interface - nni : nni interface	<i>optional parameter with default value: "uni"</i> <i>The parameter is not visible during modification.</i> port type of the line card
[no] transp-mode-rem	Parameter type: <Gpon::TranspMode> Format: (disable enable) Possible values: - disable : disable transparent	<i>optional parameter with default value: "disable"</i> <i>The parameter is not visible during modification.</i> transparent mode of the line card

Parameter	Type	Description
	- enable : enable transparent	
[no] no-mcast-control	Parameter type: <Gpon::NoMcastCtrl> Format: (disable enable) Possible values: - disable : disable igmp NoMcastCtrl - enable : enable igmp NoMcastCtrl	<i>optional parameter with default value: "disable"</i> <i>The parameter is not visible during modification.</i> used to control whether the mcast related OMCI message should be sent to ONT
[no] admin-state	Parameter type: <Gpon::AdminStatus> Format: (down up) Possible values: - down : set the admin-state to down - up : set the admin-state to up	<i>optional parameter with default value: "up"</i> administrative status of the interface

6.15 ONT Software Control Configuration Command

Command Description

This command creates an association between an ONT hardware version/variant and an ONT software version (download and planned).

*hw-version - has the same meaning as the eqpt-ver-num parameter supported by 'show equipment ont interface' command. Special character * (asterisk) may be provided in the string which means that the * character (and all subsequent character positions) are considered to be automatic 'matches' for values in same character positions of eqpt-ver-num parameter.*

ont-variant - has the same meaning as the plnd-var in 'configure equipment ont interface' command

Note: Combination of hw-version and ont-variant must be unique.

plnd-sw-version - has the same meaning as the 'auto-sw-plnd-ver parameter supported by 'show equipment ont interface' command.

sw-dwload-ver - has the same meaning as the 'auto-sw-dld-ver parameter supported by 'show equipment ont interface' command.

User Level

The command can be accessed by operators with equipment privileges, and executed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

```
> configure equipment ont ( no sw-ctrl (sw-ctrl-id) ) | ( sw-ctrl (sw-ctrl-id) hw-version <Gpon::SwVer> [ no
ont-variant | ont-variant <Gpon::PlndVar> ] [ no plnd-sw-version | plnd-sw-version <Gpon::SwVer> ] [ no
plnd-sw-ver-conf | plnd-sw-ver-conf <Gpon::SwVer> ] [ no sw-dwload-ver | sw-dwload-ver <Gpon::SwVer> ] [ no
pland-cfgfile1 | pland-cfgfile1 <Gpon::CfgFile> ] [ no pland-cfgfile2 | pland-cfgfile2 <Gpon::CfgFile> ] [ no
dnload-cfgfile1 | dnload-cfgfile1 <Gpon::CfgFile> ] [ no dnload-cfgfile2 | dnload-cfgfile2 <Gpon::CfgFile> ] )
```

Command Parameters

Table 6.15-1 "ONT Software Control Configuration Command" Resource Parameters

Resource Identifier	Type	Description
(sw-ctrl-id)	Format: - ont sw ctrl id - range: [1...250]	software control id

Table 6.15-2 "ONT Software Control Configuration Command" Command Parameters

Parameter	Type	Description
hw-version	Parameter type: <Gpon::SwVer>	mandatory parameter

Parameter	Type	Description
	Format: - ont sw version - length: 1<=x<=14	<i>The parameter is not visible during modification.</i> ONT hardware version
[no] ont-variant	Parameter type: <Gpon::PlndVar> Format: - planned variant of the ONT hardware version - length: x<=80	<i>optional parameter with default value: ""</i> <i>The parameter is not visible during modification.</i> planned variant of the ONT hardware version. Use DO for Data-only ONTs, SIP for SIP ONTs, H.248 for MEGACO ONTs
[no] plnd-sw-version	Parameter type: <Gpon::SwVer> Format: - ont sw version - length: 1<=x<=14	<i>optional parameter with default value: "UNPLANNED"</i> planned ONT software version number. If sw-dwload-ver is set to disabled, plnd-sw-version cannot be set to delayactivate.
[no] plnd-sw-ver-conf	Parameter type: <Gpon::SwVer> Format: - ont sw version - length: 1<=x<=14	<i>optional parameter with default value: "UNPLANNED"</i> software planned version confirmation
[no] sw-dwload-ver	Parameter type: <Gpon::SwVer> Format: - ont sw version - length: 1<=x<=14	<i>optional parameter with default value: "DISABLED"</i> software download version. If plnd-sw-version is set to delayactivate, sw-dwload-ver cannot be set to disabled.
[no] pland-cfgfile1	Parameter type: <Gpon::CfgFile> Format: - ont configure file version - length: 1<=x<=14	<i>optional parameter with default value: "DISABLED"</i> indicate the cfgfile1 version to be planned
[no] pland-cfgfile2	Parameter type: <Gpon::CfgFile> Format: - ont configure file version - length: 1<=x<=14	<i>optional parameter with default value: "DISABLED"</i> indicate the cfgfile2 version to be planned
[no] dnload-cfgfile1	Parameter type: <Gpon::CfgFile> Format: - ont configure file version - length: 1<=x<=14	<i>optional parameter with default value: "DISABLED"</i> indicate the cfgfile1 version to be downloaded
[no] dnload-cfgfile2	Parameter type: <Gpon::CfgFile> Format: - ont configure file version - length: 1<=x<=14	<i>optional parameter with default value: "DISABLED"</i> indicate the cfgfile2 version to be planned

6.16 GPON ONT software delay activation control Configuration Commands

Command Description

This command allows the operator to specify when OLT should attempt to activate ONT software.

This command is enabled only when sw-ver-pland is set as "delayactivate".

User Level

The command can be accessed by operators with equipment privileges, and executed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

```
> configure equipment ont sw-ctrl (sw-ctrl-id) delay-act [ no at | at <Gpon::SwActTime> ]
```

Command Parameters

Table 6.16-1 "GPON ONT software delay activation control Configuration Commands" Resource Parameters

Resource Identifier	Type	Description
(sw-ctrl-id)	Format: - ont sw ctrl id - range: [1...250]	software control id

Table 6.16-2 "GPON ONT software delay activation control Configuration Commands" Command Parameters

Parameter	Type	Description
[no] at	Parameter type: <Gpon::SwActTime> Format: - scheduled ont sw activation time - range: [0...4294967295]	<i>optional parameter with default value: "1970-01-01 : 00 : 00"</i> schedule ONT SW specific activating time. Only if sw-ver-pland is set to delayactivate, delay-act at can be configured.

6.17 ONT Interface Configuration Command

Command Description

This command allows the operator to create and configure the ONT parameters.

loop-detect - when default value no-control is set, OLT won't care about ONT loop detect, when disable is set, ONT won't detect loop, when enable is set, ONT will loop detect

loop-portautoshtutoff - when default value enable is set, if ONT detect loop, it will autoly shut down the port, when disable is set, ONT won't auto shutdown

User Level

The command can be accessed by operators with equipment privileges, and executed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

```
> configure equipment ont loop (ont-idx) [ no loop-detect | loop-detect <Gpon::LoopDetectAdmin> ] [ no loop-portautoshtutoff | loop-portautoshtutoff <Gpon::LoopDetectAutoShut> ]
```

Command Parameters

Table 6.17-1 "ONT Interface Configuration Command" Resource Parameters

Resource Identifier	Type	Description
(ont-idx)	Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> ng2 : <Ng2::ChannelGroup> / <Ng2::SubchannelGroup> / <Ng2::OntId>) Possible values: - ng2 : ngpon2 style identification Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Ng2::ChannelGroup> - channel group number Field type <Ng2::SubchannelGroup> - subchannel group number Field type <Eqpt::OntId> - the ONT identifier Field type <Ng2::OntId>	ONT index

6 Gpon ONT Configuration Commands

Resource Identifier	Type	Description
	- the ONT identifier	

Table 6.17-2 "ONT Interface Configuration Command" Command Parameters

Parameter	Type	Description
[no] loop-detect	Parameter type: <Gpon::LoopDetectAdmin> Format: (no-control disable enable) Possible values: - no-control : loop detect no control - disable : loop detect disable - enable : loop detect enable	<i>optional parameter with default value: "no-control"</i> loop detect admin state settings for this ONT
[no] loop-portautoshut	Parameter type: <Gpon::LoopDetectAutoShut> Format: (disable enable) Possible values: - disable : loop detect disable - enable : loop detect enable	<i>optional parameter with default value: "enable"</i> loop detect auto shutoff settings for this ONT

6.18 ONT GIS Configuration Command

Command Description

This command allows the operator to configure the ONT GIS parameters.

olt-location - when default value disable is set, OLT won't care about ONT GIS info, when enable is set, OLT would provision OLT's location to ONT

User Level

The command can be accessed by operators with equipment privileges, and executed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

```
> configure equipment ont gis (ont-idx) [ no olt-location | olt-location <Gpon::OltLocation> ]
```

Command Parameters

Table 6.18-1 "ONT GIS Configuration Command" Resource Parameters

Resource Identifier	Type	Description
(ont-idx)	Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> ng2 : <Ng2::ChannelGroup> / <Ng2::SubchannelGroup> / <Ng2::OntId>) Possible values: - ng2 : ngpon2 style identification Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Ng2::ChannelGroup> - channel group number Field type <Ng2::SubchannelGroup> - subchannel group number Field type <Eqpt::OntId> - the ONT identifier Field type <Ng2::OntId> - the ONT identifier	ONT index

Table 6.18-2 "ONT GIS Configuration Command" Command Parameters

6 Gpon ONT Configuration Commands

Parameter	Type	Description
[no] olt-location	Parameter type: <Gpon::OltLocation> Format: (disable enable) Possible values: - disable : the OLT GIS info will not be used - enable : the OLT GIS info will be used	<i>optional parameter with default value: "disable"</i> GIS settings for this ONT

6.19 ONT xgpon Configuration Command

Command Description

This command allows the operator to configure the ONT,parameters,enable/disable Performance monitors.

User Level

The command can be accessed by operators with equipment privileges, and executed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

```
> configure equipment ont pm-collect (ont-idx) [ no xg-pm-collect | xg-pm-collect <Gpon::OntPmCollect> ]
```

Command Parameters

Table 6.19-1 "ONT xgpon Configuration Command" Resource Parameters

Resource Identifier	Type	Description
(ont-idx)	Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> ng2 : <Ng2::ChannelGroup> / <Ng2::SubchannelGroup> / <Ng2::OntId>) Possible values: - ng2 : ngpon2 style identification Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Ng2::ChannelGroup> - channel group number Field type <Ng2::SubchannelGroup> - subchannel group number Field type <Eqpt::OntId> - the ONT identifier Field type <Ng2::OntId> - the ONT identifier	ONT index

Table 6.19-2 "ONT xgpon Configuration Command" Command Parameters

Parameter	Type	Description
[no] xg-pm-collect	Parameter type: <Gpon::OntPmCollect> Format:	optional parameter with default value: "disable"

6 Gpon ONT Configuration Commands

Parameter	Type	Description
	(enable disable) Possible values: - enable : enable PM - disable : disable PM	enable/disable Performance monitors

7- Epon ONT Configuration Commands

7.1 Epon ONT Configuration Command Tree	7-398
7.2 EONT Interface Configuration Command	7-401
7.3 Epon Ont RSSI Configuration Command	7-405
7.4 Epon Ont Management Configuration Command	7-409
7.5 Epon Ont Ethernet Configuration Command	7-411
7.6 Epon Ont Ethernet Auto-Negotiation Configuration Command	7-415
7.7 Epon Ont LLID Configuration Command	7-419
7.8 Epon Ont RMS Configuration Command	7-421
7.9 EONT Software Control Configuration Command	7-423

7.1 Epon ONT Configuration Command Tree

Description

This chapter gives an overview of nodes that are handled by "Epon ONT Configuration Commands".

Command Tree

```
----configure
  ----equipment
    ----eont
      ----[no] interface
        - (epon-idx)
        - mac-addr
        - auth-id
        - auth-pwd
        - [no] sw-ver-pland
        - [no] fec
        - [no] igmp-mode
        - [no] fastleave
        - [no] macage-time
        - [no] phy-lineid
        - [no] upgrade-mode
        - [no] plnd-var
        - [no] ont-cfg-mode
        - [no] ont-type
        - [no] ont-onuidmthd
        - alarm-profile-name
        - [no] admin-state
        - [no] stpid
        - [no] llidpattern
      ----[no] rssi
        - [no] temp-alm-low
        - [no] temp-alm-high
        - [no] temp-warn-low
        - [no] temp-warn-high
        - [no] voltage-alm-low
        - [no] voltage-alm-high
        - [no] voltage-warn-low
        - [no] voltage-warn-high
        - [no] bias-alm-low
        - [no] bias-alm-high
        - [no] bias-warn-low
        - [no] bias-warn-high
        - [no] tx-pwr-alm-low
        - [no] tx-pwr-alm-high
        - [no] tx-pwr-warn-low
        - [no] tx-pwr-warn-high
        - [no] rx-pwr-alm-low
        - [no] rx-pwr-alm-high
        - [no] rx-pwr-warn-low
        - [no] rx-pwr-warn-high
      ----[no] management
```



```

- ip
- mask
- gateway
- cvlan
- [no] svlan
- [no] priority
- [no] snmpver
- trap-ip
- [no] trap-port
- [no] snmp-port
- security-name
- community-write
- community-read
----[no] port
- (uni-index)
- [no] auto-detect
- [no] vlanmode
- [no] vlanid-default
- [no] pbit-default
- [no] pause
- [no] policyup
- cir-up
- bucket-up
- exbrsize-up
- [no] policydown
- cir-dw
- pir-dw
- [no] multiconf
- [no] mac-max
- [no] multigroup-max
- [no] pm-collect
- [no] loopback
- [no] loopportshut
- [no] port-mode
----[no] auto-adv-abili
- autoneg10t
- autoneg10tfd
- autoneg100t4
- autoneg100tx
- autoneg100txfd
- autoneg100t2
- autoneg100t2fd
- autoneg1000x
- autoneg1000xfd
- autoneg1000t
- autoneg1000tfd
- fdxpause
- fdxapause
- fdxspause
- fdxbpause
- remfault1
- remfault2
- isoethernet
----[no] llid
- (llid-num)
- [no] queue-profile
- [no] churn
- [no] churn-time

```

- [no] churn-keyetime
- [no] loop-backadmin
- [no] dbapollinglevel
- rate-limit-prof
- [no] closeportasovld
- [no] rms
- [no] ip-mode
- ip
- mask
- gateway
- [no] pppoe-mode
- [no] pppoe-username
- [no] pppoe-pwd
- [no] tagged-mode
- cvlan
- [no] svlan
- [no] pbit
- [no] url
- [no] sw-ctrl
- (sw-ctrl-id)
- hw-version
- [no] ont-variant
- plnd-sw-version
- [no] upgrade-mode

7.2 EONT Interface Configuration Command

Command Description

This command allows the operator to create and configure the EONT parameters.

mac-addr - Mac address for this ONT. The parameter cannot be modified. Either mac-addr or auth-id should be configured.

auth-id - logical authentication id for this ONT. Either mac-addr or auth-id should be configured.

sw-ver-pland - The planned ONT software version number. If this software version number is different from the active version number on the ONT, a software download, activation and commit is performed. The special string of AUTO is used to indicate that if this ONT's hardware version has a matching entry created using configure equipment eont sw-ctrl, then the plnd-sw-version will be downloaded to the ONT. The special string of MANUAL is used to download ONT Software manually. Operator could use command "admin equipment eont swdw(ont-idx)". For detailed sw version, its format is like XXXXYYYYRnnmmae for current release.

plnd-var - software version variant. This attribute only valid when sw-ver-pland is auto

User Level

The command can be accessed by operators with equipment privileges, and executed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

```
> configure equipment eont ( no interface (epon-idx) ) | ( interface (epon-idx) [ mac-addr <Epon::MacAddr> ] [
auth-id <Epon::AuthId> ] [ auth-pwd <Epon::AuthPwd> ] [ no sw-ver-pland | sw-ver-pland <Epon::SwVerPlnd> ]
[ no fec | fec <Epon::FecMode> ] [ no igmp-mode | igmp-mode <Epon::IgmpMode> ] [ no fastleave | fastleave
<Epon::FastLeaveMode> ] [ no macage-time | macage-time <Epon::MacAge> ] [ no phy-lineid | phy-lineid
<Epon::PhyLineId> ] [ no upgrade-mode | upgrade-mode <Epon::UpMode> ] [ no plnd-var | plnd-var
<Epon::PlannedVariant> ] [ no ont-cfg-mode | ont-cfg-mode <Epon::OntCfgMode> ] [ no ont-type | ont-type
<epon::onttype> ] [ no ont-onuidmthd | ont-onuidmthd <Epon::OntOnuldMthd> ] [ alarm-profile-name
<Epon::EponAlrmCtrlProfileName> ] [ no admin-state | admin-state <Epon::ItfAdminStatus> ] [ no stpid | stpid
<Epon::Stpid> ] [ no llidpattern | llidpattern <Epon::Llidpattern> ] )
```

Command Parameters

Table 7.2-1 "EONT Interface Configuration Command" Resource Parameters

Resource Identifier	Type	Description
(epon-idx)	Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId>	ONT index

7 Epon ONT Configuration Commands

Resource Identifier	Type	Description
	- the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Eqpt::OntId> - the ONT identifier	

Table 7.2-2 "EONT Interface Configuration Command" Command Parameters

Parameter	Type	Description
mac-addr	Parameter type: <Epon::MacAddr> Format: - mac-address (example : 01:02:03:04:05:06) - length: 6	<i>optional parameter</i> mac address
auth-id	Parameter type: <Epon::AuthId> Format: - Authentication ID - length: 1<=x<=24	<i>optional parameter</i> logical authentication id
auth-pwd	Parameter type: <Epon::AuthPwd> Format: - Authentication password - length: 1<=x<=12	<i>optional parameter</i> logical authentication password
[no] sw-ver-pland	Parameter type: <Epon::SwVerPlnd> Format: (auto manual <Epon::SwVerPlnd>) Possible values: - auto : auto - manual : manual Field type <Epon::SwVerPlnd> - software version planned - length: 1<=x<=16	<i>optional parameter with default value: "MANUAL"</i> software version planned
[no] fec	Parameter type: <Epon::FecMode> Format: (enable disable) Possible values: - enable : enable FEC mode - disable : disable FEC mode	<i>optional parameter with default value: "disable"</i> FEC mode
[no] igmp-mode	Parameter type: <Epon::IgmpMode> Format: (snoopingmode controllablename floodingmode) Possible values: - snoopingmode : igmp snooping mode - controllablename : controllable igmp mode - floodingmode : flooding mode	<i>optional parameter with default value: "controllable IGMP mode"</i> IGMP handling mode
[no] fastleave	Parameter type: <Epon::FastLeaveMode> Format: (disable enable) Possible values: - disable : disable fastleave mode - enable : enable fastleave mode	<i>optional parameter with default value: "disable"</i> fastleave mode
[no] macage-time	Parameter type: <Epon::MacAge> Format: - MAC aging time	<i>optional parameter with default value: "287"</i> MAC aging time per ONT

Parameter	Type	Description
	- unit: secs - range: [0...287]	
[no] phy-lineid	Parameter type: <Epon::PhyLineId> Format: (enable disable) Possible values: - enable : enable to add option for DHCP/PPP partially - disable : disable to add option for DHCP/PPP partially	<i>optional parameter with default value: "disable"</i> Physical line ID
[no] upgrade-mode	Parameter type: <Epon::UpMode> Format: (none ctc tk dpoe) Possible values: - none : no software upgrade mode - ctc : CTC software upgrade mode - tk : TK software upgrade mode - dpoe : DPoE software upgrade mode	<i>optional parameter with default value: "CTC"</i> software upgrade mode
[no] plnd-var	Parameter type: <Epon::PlannedVariant> Format: - planned variant - length: 1<=x<=16	<i>optional parameter with default value: ""</i> planned variant
[no] ont-cfg-mode	Parameter type: <Epon::OntCfgMode> Format: (disable enable-alu-mode enable-cu-mode) Possible values: - disable : disable ont config save - enable-alu-mode : enable ALU ont config save mode - enable-cu-mode : enable CU ont config save mode	<i>optional parameter with default value: "disable"</i> Ont config save mode
[no] ont-type	Parameter type: <epon::onttype> Format: (auto 10gsym 10gasym 1g) Possible values: - auto : auto - 10gsym : 10gsym - 10gasym : 10gasym - 1g : 1g	<i>optional parameter with default value: "auto"</i> for CAC pre-configuration, to limit the registered ont type
[no] ont-onuidmthd	Parameter type: <Epon::OntOnuidMthd> Format: (sys mac loid) Possible values: - sys : inherit from pon - mac : fill onu id with mac@ in loop id - loid : fill onu id with loid in loop id	<i>optional parameter with default value: "sys"</i> Ont onu id method
alarm-profile-name	Parameter type: <Epon::EponAlrmCtrlProfileName> Format: - name of the Alarm Control profile - length: 1<=x<=32	<i>optional parameter</i> name of the alarm control profile

7 Epon ONT Configuration Commands

Parameter	Type	Description
[no] admin-state	Parameter type: <Epon::ItfAdminStatus> Format: (up down) Possible values: - up : set the admin-state to up - down : set the admin-state to down	<i>optional parameter with default value: "down"</i> <i>The parameter is not visible during creation.</i> administrative status of the interface
[no] stpid	Parameter type: <Epon::Stpid> Format: (88a8 8100 9100 9200) Possible values: - 88a8 : 0x88a8 - 8100 : 0x8100 - 9100 : 0x9100 - 9200 : 0x9200	<i>optional parameter with default value: "0x88a8"</i> STPID
[no] llidpattern	Parameter type: <Epon::Llidpattern> Format: (1x1 1x4 1x8 2x1 2x4) Possible values: - 1x1 : 1 LLID-group,1 LLID per group - 1x4 : 1 LLID-group,4 LLIDs per group - 1x8 : 1 LLID-group,8 LLIDs per group - 2x1 : 2 LLID-groups,1 LLID per group - 2x4 : 2 LLID-groups,4 LLIDs per group	<i>optional parameter with default value: "1x1"</i> LLID pattern

7.3 Epon Ont RSSI Configuration Command

Command Description

This command allows the operator to create and configure the EONT RSSI parameters.

User Level

The command can be accessed by operators with equipment privileges, and executed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

```
> configure equipment eont interface (epon-idx) ( no rssi ) | ( rssi [ no temp-alm-low | temp-alm-low
<Epon::TcaTemp> ] [ no temp-alm-high | temp-alm-high <Epon::TcaTemp> ] [ no temp-warn-low |
temp-warn-low <Epon::TcaTemp> ] [ no temp-warn-high | temp-warn-high <Epon::TcaTemp> ] [ no
voltage-alm-low | voltage-alm-low <Epon::TcaVoltage> ] [ no voltage-alm-high | voltage-alm-high
<Epon::TcaVoltage> ] [ no voltage-warn-low | voltage-warn-low <Epon::TcaVoltage> ] [ no voltage-warn-high |
voltage-warn-high <Epon::TcaVoltage> ] [ no bias-alm-low | bias-alm-low <Epon::TcaBias> ] [ no bias-alm-high |
bias-alm-high <Epon::TcaBias> ] [ no bias-warn-low | bias-warn-low <Epon::TcaBias> ] [ no bias-warn-high |
bias-warn-high <Epon::TcaBias> ] [ no tx-pwr-alm-low | tx-pwr-alm-low <Epon::TcaPwr> ] [ no tx-pwr-alm-high |
tx-pwr-alm-high <Epon::TcaPwr> ] [ no tx-pwr-warn-low | tx-pwr-warn-low <Epon::TcaPwr> ] [ no
tx-pwr-warn-high | tx-pwr-warn-high <Epon::TcaPwr> ] [ no rx-pwr-alm-low | rx-pwr-alm-low <Epon::TcaPwr> ]
[ no rx-pwr-alm-high | rx-pwr-alm-high <Epon::TcaPwr> ] [ no rx-pwr-warn-low | rx-pwr-warn-low
<Epon::TcaPwr> ] [ no rx-pwr-warn-high | rx-pwr-warn-high <Epon::TcaPwr> ] )
```

Command Parameters

Table 7.3-1 "Epon Ont RSSI Configuration Command" Resource Parameters

Resource Identifier	Type	Description
(epon-idx)	Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Eqpt::OntId> - the ONT identifier	ONT index

Table 7.3-2 "Epon Ont RSSI Configuration Command" Command Parameters

Parameter	Type	Description
[no] temp-alm-low	Parameter type: <Epon::TcaTemp>	optional parameter with default

7 Epon ONT Configuration Commands

Parameter	Type	Description
	Format: - temperature of eponont - unit: degree C - range: [-128...128]	<i>value: "0"</i> alarm low threshold for temperature
[no] temp-alm-high	Parameter type: <Epon::TcaTemp> Format: - temperature of eponont - unit: degree C - range: [-128...128]	<i>optional parameter with default value: "70"</i> alarm high threshold for temperature
[no] temp-warn-low	Parameter type: <Epon::TcaTemp> Format: - temperature of eponont - unit: degree C - range: [-128...128]	<i>optional parameter with default value: "0"</i> warn low threshold for temperature
[no] temp-warn-high	Parameter type: <Epon::TcaTemp> Format: - temperature of eponont - unit: degree C - range: [-128...128]	<i>optional parameter with default value: "70"</i> warn high threshold for temperature
[no] voltage-alm-low	Parameter type: <Epon::TcaVoltage> Format: - voltage of epon ont - unit: volts - range: [0...6.55]	<i>optional parameter with default value: "3.135"</i> alarm low threshold for Voltage
[no] voltage-alm-high	Parameter type: <Epon::TcaVoltage> Format: - voltage of epon ont - unit: volts - range: [0...6.55]	<i>optional parameter with default value: "3.465"</i> alarm high threshold for Voltage
[no] voltage-warn-low	Parameter type: <Epon::TcaVoltage> Format: - voltage of epon ont - unit: volts - range: [0...6.55]	<i>optional parameter with default value: "3.135"</i> warn low threshold for Voltage
[no] voltage-warn-high	Parameter type: <Epon::TcaVoltage> Format: - voltage of epon ont - unit: volts - range: [0...6.55]	<i>optional parameter with default value: "3.465"</i> warn high threshold for Voltage
[no] bias-alm-low	Parameter type: <Epon::TcaBias> Format: - bias of epon ont - unit: mA - range: [0...262]	<i>optional parameter with default value: "5"</i> alarm low threshold for bias
[no] bias-alm-high	Parameter type: <Epon::TcaBias> Format: - bias of epon ont - unit: mA - range: [0...262]	<i>optional parameter with default value: "110"</i> alarm high threshold for bias
[no] bias-warn-low	Parameter type: <Epon::TcaBias> Format: - bias of epon ont - unit: mA - range: [0...262]	<i>optional parameter with default value: "5"</i> warn low threshold for bias
[no] bias-warn-high	Parameter type: <Epon::TcaBias> Format: - bias of epon ont	<i>optional parameter with default value: "110"</i> warn high threshold for bias

Parameter	Type	Description
	- unit: mA - range: [0...262]	
[no] tx-pwr-alm-low	Parameter type: <Epon::TcaPwr> Format: <Epon::float> Field type <Epon::float> - OLT side TCA threshold - unit: dbm - range: [-40...8.2]	<i>optional parameter with default value: "-1"</i> alarm low threshold for Tx power
[no] tx-pwr-alm-high	Parameter type: <Epon::TcaPwr> Format: <Epon::float> Field type <Epon::float> - OLT side TCA threshold - unit: dbm - range: [-40...8.2]	<i>optional parameter with default value: "3.99"</i> alarm high threshold for Tx power
[no] tx-pwr-warn-low	Parameter type: <Epon::TcaPwr> Format: <Epon::float> Field type <Epon::float> - OLT side TCA threshold - unit: dbm - range: [-40...8.2]	<i>optional parameter with default value: "-1"</i> warn low threshold for Tx power
[no] tx-pwr-warn-high	Parameter type: <Epon::TcaPwr> Format: <Epon::float> Field type <Epon::float> - OLT side TCA threshold - unit: dbm - range: [-40...8.2]	<i>optional parameter with default value: "3.99"</i> warn high threshold for Tx power
[no] rx-pwr-alm-low	Parameter type: <Epon::TcaPwr> Format: <Epon::float> Field type <Epon::float> - OLT side TCA threshold - unit: dbm - range: [-40...8.2]	<i>optional parameter with default value: "-23.979"</i> alarm low threshold for Rx power
[no] rx-pwr-alm-high	Parameter type: <Epon::TcaPwr> Format: <Epon::float> Field type <Epon::float> - OLT side TCA threshold - unit: dbm - range: [-40...8.2]	<i>optional parameter with default value: "-2.999"</i> alarm high threshold for Rx power
[no] rx-pwr-warn-low	Parameter type: <Epon::TcaPwr> Format: <Epon::float> Field type <Epon::float> - OLT side TCA threshold - unit: dbm - range: [-40...8.2]	<i>optional parameter with default value: "-23.979"</i> warn low threshold for Rx power
[no] rx-pwr-warn-high	Parameter type: <Epon::TcaPwr> Format: <Epon::float> Field type <Epon::float> - OLT side TCA threshold - unit: dbm	<i>optional parameter with default value: "-2.999"</i> warn high threshold for Rx power

7 Epon ONT Configuration Commands

Parameter	Type	Description
	- range: [-40...8.2]	

7.4 Epon Ont Management Configuration Command

Command Description

This command allows the operator to create and configure the EONT Management parameters.

User Level

The command can be accessed by operators with equipment privileges, and executed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

```
> configure equipment eont interface (epon-idx) ( no management ) | ( management [ ip <Ip::V4Address> ] [ mask <Ip::V4Address> ] [ gateway <Ip::V4Address> ] cvlan <Epon::cvlan> [ no svlan | svlan <Epon::svlan> ] [ no priority | priority <Epon::Priority> ] [ no snmpver | snmpver <Epon::SnmpVersion> ] [ trap-ip <Ip::V4Address> ] [ no trap-port | trap-port <Epon::MgntPort> ] [ no snmp-port | snmp-port <Epon::MgntPort> ] [ security-name <Epon::securityname> ] [ community-write <Epon::communitystr> ] [ community-read <Epon::communitystr> ] )
```

Command Parameters

Table 7.4-1 "Epon Ont Management Configuration Command" Resource Parameters

Resource Identifier	Type	Description
(epon-idx)	Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Eqpt::OntId> - the ONT identifier	ONT index

Table 7.4-2 "Epon Ont Management Configuration Command" Command Parameters

Parameter	Type	Description
ip	Parameter type: <Ip::V4Address> Format: - IPv4-address	<i>optional parameter</i> IP address for this ONT
mask	Parameter type: <Ip::V4Address> Format:	<i>optional parameter</i> network mask for this ONT

7 Epon ONT Configuration Commands

Parameter	Type	Description
	- IPv4-address	
gateway	Parameter type: <Ip::V4Address> Format: - IPv4-address	<i>optional parameter</i> network gateway address for this ONT
cvlan	Parameter type: <Epon::cvlan> Format: - Vlan id - range: [0...4093]	<i>mandatory parameter</i> management CVLAN id for this ONT
[no] svlan	Parameter type: <Epon::svlan> Format: - Vlan id - range: [2...4093,0]	<i>optional parameter with default value: "0"</i> management SVLAN id for this ONT
[no] priority	Parameter type: <Epon::Priority> Format: - priority - range: [0...7]	<i>optional parameter with default value: "5"</i> management PBIT for this ONT
[no] snmpver	Parameter type: <Epon::SnmpVersion> Format: (v1 v2 v3) Possible values: - v1 : snmp version v1 - v2 : snmp version v2 - v3 : snmp version v3	<i>optional parameter with default value: "v2"</i> snmp version for this ONT
trap-ip	Parameter type: <Ip::V4Address> Format: - IPv4-address	<i>optional parameter</i> trap IP address for this ONT
[no] trap-port	Parameter type: <Epon::MgntPort> Format: - mgnt Port - range: [0...65535]	<i>optional parameter with default value: "162"</i> trap port for this ONT
[no] snmp-port	Parameter type: <Epon::MgntPort> Format: - mgnt Port - range: [0...65535]	<i>optional parameter with default value: "161"</i> snmp port for this ONT
security-name	Parameter type: <Epon::securityname> Format: - an octet string defining security name of EPON - length: 1<=x<=32	<i>optional parameter</i> security name for this ONT
community-write	Parameter type: <Epon::communitystr> Format: - an octet string defining community string of EPON - length: 1<=x<=32	<i>optional parameter</i> community string for write for this ONT
community-read	Parameter type: <Epon::communitystr> Format: - an octet string defining community string of EPON - length: 1<=x<=32	<i>optional parameter</i> community string for read for this ONT

7.5 Epon Ont Ethernet Configuration Command

Command Description

This command allows the operator to configure provisioning data associated with epon ont ethernet port.

User Level

The command can be accessed by operators with equipment privileges, and executed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

```
> configure equipment eont interface (epon-idx) ( no port (uni-index) ) | ( port (uni-index) [ no auto-detect |
auto-detect <Epon::AutoDetect> ] [ no vlanmode | vlanmode <Epon::VlanMode> ] [ no vlanid-default |
vlanid-default <Epon::DefaultVlanID> ] [ no pbit-default | pbit-default <Epon::DefaultPBit> ] [ no pause | pause
<Epon::PauseAdmin> ] [ no policyup | policyup <Epon::PolicyUpAdmin> ] [ cir-up <Epon::CIRUp> ] [ bucket-up
<Epon::BucketUp> ] [ exbrsize-up <Epon::ExBrSizeUp> ] [ no policydown | policydown
<Epon::PolicyDwnAdmin> ] [ cir-dw <Epon::CIRDwn> ] [ pir-dw <Epon::PIRDwn> ] [ no multiconf | multiconf
<Epon::McastCfg> ] [ no mac-max | mac-max <Epon::MacLrnLimit> ] [ no multigroup-max | multigroup-max
<Epon::MultiGroupMax> ] [ no pm-collect | pm-collect <Epon::CollectInd> ] [ no loopback | loopback
<Epon::LoopbackAdmin> ] [ no loopportshut | loopportshut <Epon::LoopShutoff> ] [ no port-mode | port-mode
<Epon::PortMode> ] )
```

Command Parameters

Table 7.5-1 "Epon Ont Ethernet Configuration Command" Resource Parameters

Resource Identifier	Type	Description
(epon-idx)	Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Eqpt::OntId> - the ONT identifier	ONT index
(uni-index)	Format: <Epon::EontSlot> / <Epon::EontPort> Field type <Epon::EontSlot> - Epon Ont Slot - range: [1...16] Field type <Epon::EontPort>	port index

Resource Identifier	Type	Description
	- Epon Ont Port - range: [1...64]	

Table 7.5-2 "Epon Ont Ethernet Configuration Command" Command Parameters

Parameter	Type	Description
[no] auto-detect	Parameter type: <Epon::AutoDetect> Format: (enable disable) Possible values: - enable : enable auto negotiation - disable : disable auto negotiation	<i>optional parameter with default value: "enable"</i> enable or disable auto negotiation
[no] vlanmode	Parameter type: <Epon::VlanMode> Format: (transparent tagged translation trunk aggregation) Possible values: - transparent : VLAN mode transparent - tagged : VLAN mode tag - translation : Vlan mode translate - trunk : Vlan trunk - aggregation : Vlan aggregation	<i>optional parameter with default value: "transparent"</i> vlan mode for ethernet port
[no] vlanid-default	Parameter type: <Epon::DefaultVlanID> Format: - default vlan id - range: [2...4092,4097]	<i>optional parameter with default value: "4097"</i> default vlan of this port
[no] pbit-default	Parameter type: <Epon::DefaultPBit> Format: - default pbit - range: [0...7]	<i>optional parameter with default value: "0"</i> default pbit of this port
[no] pause	Parameter type: <Epon::PauseAdmin> Format: (enable disable) Possible values: - enable : enable flow control - disable : disable flow control	<i>optional parameter with default value: "enable"</i> enable or disable pause
[no] policyup	Parameter type: <Epon::PolicyUpAdmin> Format: (enable disable) Possible values: - enable : enable rate limit in upstream - disable : disable rate limit in upstream	<i>optional parameter with default value: "disable"</i> enable or disable policy upstream
cir-up	Parameter type: <Epon::CIRUp> Format: - information rate - unit: kbps - range: [0...1000000]	<i>optional parameter</i> committed information rate upstream
bucket-up	Parameter type: <Epon::BucketUp> Format: - depth of the token bucket - unit: bytes - range: [2000...64000]	<i>optional parameter</i> depth of this token bucket to be tolerant of a certain burst size in upstream direction

Parameter	Type	Description
exbrsize-up	Parameter type: <Epon::ExBrSizeUp> Format: - token to permit the forwarding engine to finish the packet being sent when the CBS - unit: bytes - range: [0...2000]	<i>optional parameter</i> token to permit the forwarding engine to finish the packet being sent when CBS is exhausted in upstream direction
[no] policydown	Parameter type: <Epon::PolicyDwnAdmin> Format: (enable disable) Possible values: - enable : enable rate limit in downstream - disable : disable rate limit in downstream	<i>optional parameter with default value: "disable"</i> enable or disable policy downstream
cir-dw	Parameter type: <Epon::CIRDwn> Format: - information rate - unit: kbps - range: [0...1000000]	<i>optional parameter</i> committed information rate downstream
pir-dw	Parameter type: <Epon::PIRDwn> Format: - information rate - unit: kbps - range: [0...1000000]	<i>optional parameter</i> peak information rate downstream
[no] multiconf	Parameter type: <Epon::McastCfg> Format: (strip nostrip translation) Possible values: - strip : strip vlan tag - nostrip : do not strip vlan tag - translation : translation	<i>optional parameter with default value: "strip"</i> multicast traffic configuration on ethernet port
[no] mac-max	Parameter type: <Epon::MacLrnLimit> Format: - mac learning limit - range: [0...64]	<i>optional parameter with default value: "0"</i> max MAC number at this port
[no] multigroup-max	Parameter type: <Epon::MultiGroupMax> Format: - max multicast group - range: [CLI_EPON_MTIGRPMAX_VALUE_MIN...CLI_EPON_MTIGRPMAX_VALUE_MAX]	<i>optional parameter with default value: "16"</i> max multicast group at this port
[no] pm-collect	Parameter type: <Epon::CollectInd> Format: (enable disable) Possible values: - enable : enable PM collection - disable : disable PM collection	<i>optional parameter with default value: "disable"</i> performance monitor switch
[no] loopback	Parameter type: <Epon::LoopbackAdmin> Format: (enable disable) Possible values: - enable : enable loopback - disable : disable loopback	<i>optional parameter with default value: "disable"</i> enable or disable loopback on ethernet Port
[no] loopportshut	Parameter type: <Epon::LoopShutoff> Format:	<i>optional parameter with default value: "enable"</i>

7 Epon ONT Configuration Commands

Parameter	Type	Description
	(disable enable) Possible values: - disable : disable auto shut off - enable : enable auto shut off	enable or disable the auto shut off when loopback is detected on this ethernet port
[no] port-mode	Parameter type: <Epon::PortMode> Format: (10m-half 10m-full 100m-half 100m-full 1g) Possible values: - 10m-half : 10M Half - 10m-full : 10M Full - 100m-half : 100M Half - 100m-full : 100M Full - 1g : 1G	<i>optional parameter with default value: "100M-Full"</i> Enet port mode

7.6 Epon Ont Ethernet Auto-Negotiation Configuration Command

Command Description

This command allows the operator to configure provisioning data associated with epon ont ethernet port auto-negotiation.

User Level

The command can be accessed by operators with equipment privileges, and executed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

```
> configure equipment eont interface (epon-idx) port (uni-index) ( no auto-adv-abili ) | ( auto-adv-abili [ autoneg10t
<Epon::autoneg10t> ] [ autoneg10tfd <Epon::autoneg10tfd> ] [ autoneg100t4 <Epon::autoneg100t4> ] [
autoneg100tx <Epon::autoneg100tx> ] [ autoneg100txfd <Epon::autoneg100txfd> ] [ autoneg100t2
<Epon::autoneg100t2> ] [ autoneg100t2fd <Epon::autoneg100t2fd> ] [ autoneg1000x <Epon::autoneg1000x> ] [
autoneg1000xfd <Epon::autoneg1000xfd> ] [ autoneg1000t <Epon::autoneg1000t> ] [ autoneg1000tfd
<Epon::autoneg1000tfd> ] [ fdxpause <Epon::fdxpause> ] [ fdxapause <Epon::fdxapause> ] [ fdxspause
<Epon::fdxspause> ] [ fdxbpause <Epon::fdxbpause> ] [ remfault1 <Epon::remfault1> ] [ remfault2
<Epon::remfault2> ] [ isoethernet <Epon::isoethernet> ] )
```

Command Parameters

Table 7.6-1 "Epon Ont Ethernet Auto-Negotiation Configuration Command" Resource Parameters

Resource Identifier	Type	Description
(epon-idx)	Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Eqpt::OntId> - the ONT identifier	ONT index
(uni-index)	Format: <Epon::EontSlot> / <Epon::EontPort> Field type <Epon::EontSlot> - Epon Ont Slot	port index

Resource Identifier	Type	Description
	- range: [1...16] - Field type <Epon::EontPort> - Epon Ont Port - range: [1...64]	

Table 7.6-2 "Epon Ont Ethernet Auto-Negotiation Configuration Command" Command Parameters

Parameter	Type	Description
autoneg10t	Parameter type: <Epon::autoneg10t> Format: (yes no) Possible values: - yes : 10t supported - no : 10t not supported	<i>optional parameter</i> advertise support of 10T
autoneg10tfd	Parameter type: <Epon::autoneg10tfd> Format: (yes no) Possible values: - yes : 10tfd supported - no : 10tfd not supported	<i>optional parameter</i> advertise support of 10TFD
autoneg100t4	Parameter type: <Epon::autoneg100t4> Format: (yes no) Possible values: - yes : 100t4 supported - no : 100t4 not supported	<i>optional parameter</i> advertise support of 100T4
autoneg100tx	Parameter type: <Epon::autoneg100tx> Format: (yes no) Possible values: - yes : 100tx supported - no : 100tx not supported	<i>optional parameter</i> advertise support of 100TX
autoneg100txfd	Parameter type: <Epon::autoneg100txfd> Format: (yes no) Possible values: - yes : 100txfd supported - no : 100txfd not supported	<i>optional parameter</i> advertise support of 100TXFD
autoneg100t2	Parameter type: <Epon::autoneg100t2> Format: (yes no) Possible values: - yes : 100t2 supported - no : 100t2 not supported	<i>optional parameter</i> advertise support of 100T2
autoneg100t2fd	Parameter type: <Epon::autoneg100t2fd> Format: (yes no) Possible values: - yes : 100t2fd supported - no : 100t2fd not supported	<i>optional parameter</i> advertise support of 100T2FD

Parameter	Type	Description
autoneg1000x	Parameter type: <Epon::autoneg1000x> Format: (yes no) Possible values: - yes : 1000x supported - no : 1000x not supported	<i>optional parameter</i> advertise support of 1000X
autoneg1000xfd	Parameter type: <Epon::autoneg1000xfd> Format: (yes no) Possible values: - yes : 1000xfd supported - no : 1000xfd not supported	<i>optional parameter</i> advertise support of 1000XFD
autoneg1000t	Parameter type: <Epon::autoneg1000t> Format: (yes no) Possible values: - yes : 1000t supported - no : 1000t not supported	<i>optional parameter</i> advertise support of 1000T
autoneg1000tfd	Parameter type: <Epon::autoneg1000tfd> Format: (yes no) Possible values: - yes : 1000tfd supported - no : 1000tfd not supported	<i>optional parameter</i> advertise support of 1000TFD
fdxpause	Parameter type: <Epon::fdxpause> Format: (yes no) Possible values: - yes : fdxpause supported - no : fdxpause not supported	<i>optional parameter</i> advertise support of FdxPause
fdxapause	Parameter type: <Epon::fdxapause> Format: (yes no) Possible values: - yes : fdxapause supported - no : fdxapause not supported	<i>optional parameter</i> advertise support of FdxAPause
fdxspause	Parameter type: <Epon::fdxspause> Format: (yes no) Possible values: - yes : fdxspause supported - no : fdxspause not supported	<i>optional parameter</i> advertise support of FdxSPause
fdxbpause	Parameter type: <Epon::fdxbpause> Format: (yes no) Possible values: - yes : fdxbpause supported - no : fdxbpause not supported	<i>optional parameter</i> advertise support of FdxBPause
remfault1	Parameter type: <Epon::remfault1>	<i>optional parameter</i>

7 Epon ONT Configuration Commands

Parameter	Type	Description
	Format: (yes no) Possible values: - yes : remfault1 supported - no : remfault1 not supported	advertise support of RemFault1
remfault2	Parameter type: <Epon::remfault2> Format: (yes no) Possible values: - yes : remfault2 supported - no : remfault2 not supported	<i>optional parameter</i> advertise support of RemFault2
isoethernet	Parameter type: <Epon::isoethernet> Format: (yes no) Possible values: - yes : isoethernet supported - no : isoethernet not supported	<i>optional parameter</i> advertise support of IsoEthernet

7.7 Epon Ont LLID Configuration Command

Command Description

This command modifies provisioning data associated with epon ont llid.

Note: Multi-LLID is not supported , llid-num only support '1'.

queue-profile - queue profile ID for LLID , only 1 is supported.

User Level

The command can be accessed by operators with equipment privileges, and executed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

```
> configure equipment eont interface (epon-idx) ( no llid (llid-num) ) | ( llid (llid-num) [ no queue-profile |
queue-profile <Epon::ProfIdOne> ] [ no churn | churn <Epon::churnState> ] [ no churn-time | churn-time
<Epon::churnTime> ] [ no churn-keyextime | churn-keyextime <Epon::churnTime> ] [ no loop-backadmin |
loop-backadmin <Epon::LoopBack> ] [ no dbapollinglevel | dbapollinglevel <Epon::dba> ] rate-limit-prof
<Qos::QosRateLimitProfileNameEllid> [ no closeportasovld | closeportasovld <Epon::closePortAsOvld> ] )
```

Command Parameters

Table 7.7-1 "Epon Ont LLID Configuration Command" Resource Parameters

Resource Identifier	Type	Description
(epon-idx)	Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Eqpt::OntId> - the ONT identifier	ONT index
(llid-num)	Format: - Ont llid number,range 1 for EPON,range 1-8 for DPOE - range: [1...8]	Ont llid number, range 1 for EPON,range 1-8 for DPOE

Table 7.7-2 "Epon Ont LLID Configuration Command" Command Parameters

Parameter	Type	Description
[no] queue-profile	Parameter type: <Epon::ProfIdOne> Format:	<i>optional parameter with default value: 1L</i>

7 Epon ONT Configuration Commands

Parameter	Type	Description
	- LLID Queue Profile ID - range: [1]	Queue profile ID for LLID. Currently only 1 is supported
[no] churn	Parameter type: <Epon::churnState> Format: (enable disable) Possible values: - enable : Enable churning encryption - disable : Disable churning encryption	<i>optional parameter with default value: "disable"</i> Enable/Disable churning encryption
[no] churn-time	Parameter type: <Epon::churnTime> Format: - ONT churn time - unit: secs - range: [1...65535]	<i>optional parameter with default value: 3L</i> churning time
[no] churn-keyexptime	Parameter type: <Epon::churnTime> Format: - ONT churn time - unit: secs - range: [1...65535]	<i>optional parameter with default value: 10L</i> churning key exchanging time
[no] loop-backadmin	Parameter type: <Epon::LoopBack> Format: (enable disable) Possible values: - enable : Enable Loopback function - disable : Disable Loopback function	<i>optional parameter with default value: "disable"</i> Enable/Disable Loopback function
[no] dbapollinglevel	Parameter type: <Epon::dba> Format: - DBA polling level - range: [0...7]	<i>optional parameter with default value: 2L</i> DBA polling level
rate-limit-prof	Parameter type: <Qos::QosRateLimitProfileNameEllid> Format: (none name : <Qos::IgnoredQosProfileName>) Possible values: - none : no profile name to associated - name : enter profile name to be associated Data driven field type Possible values are depending on the actual configuration and software. The currently allowed values can be shown with online-help.	<i>mandatory parameter</i> the name of the protocol profile to be mapped on ellid. none for no ratelimit. It only used for EPON ELLID interface current.
[no] closeportasovld	Parameter type: <Epon::closePortAsOvld> Format: (enable disable) Possible values: - enable : Enable close port as overload - disable : Disable close port as overload	<i>optional parameter with default value: "disable"</i> Enable/Disable close port as protocol total rate or burst overload

7.8 Epon Ont RMS Configuration Command

Command Description

This command allows the operator to configure epon ont RMS.

User Level

The command can be accessed by operators with equipment privileges, and executed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

```
> configure equipment eont interface (epon-idx) ( no rms ) | ( rms [ no ip-mode | ip-mode <Epon::IpMode> ] [ ip
<Epon::IpAddr> ] [ mask <Epon::IpAddr> ] [ gateway <Epon::IpAddr> ] [ no pppoe-mode | pppoe-mode
<Epon::pppoeMode> ] [ no pppoe-username | pppoe-username <Epon::pppoeUsrName> ] [ no pppoe-pwd |
pppoe-pwd <Epon::pppoePwd> ] [ no tagged-mode | tagged-mode <Epon::TagMode> ] cvlan <Epon::rmsCvlan> [
no svlan | svlan <Epon::rmsSvlan> ] [ no pbit | pbit <Epon::pbit> ] [ no url | url <Epon::url> ] )
```

Command Parameters

Table 7.8-1 "Epon Ont RMS Configuration Command" Resource Parameters

Resource Identifier	Type	Description
(epon-idx)	Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Eqpt::OntId> - the ONT identifier	ONT index

Table 7.8-2 "Epon Ont RMS Configuration Command" Command Parameters

Parameter	Type	Description
[no] ip-mode	Parameter type: <Epon::IpMode> Format: (static dhcp pppoe) Possible values: - static : static mode - dhcp : dhcp mode	optional parameter with default value: "dhcp" mode to get the ip address

7 Epon ONT Configuration Commands

Parameter	Type	Description
	- pppoe : PPPoE mode	
ip	Parameter type: <Epon::IpAddr> Format: - IPv4-address	<i>optional parameter</i> ip address
mask	Parameter type: <Epon::IpAddr> Format: - IPv4-address	<i>optional parameter</i> subnet of the ip
gateway	Parameter type: <Epon::IpAddr> Format: - IPv4-address	<i>optional parameter</i> default gateway of the ip
[no] pppoe-mode	Parameter type: <Epon::pppoeMode> Format: (auto chap pap) Possible values: - auto : AUTO mode - chap : CHAP mode - pap : PAP mode	<i>optional parameter with default value: "auto"</i> PPPoE configure mode
[no] pppoe-username	Parameter type: <Epon::pppoeUsrName> Format: - user name - length: 1<=x<=32	<i>optional parameter with default value: ""</i> PPPoE user name
[no] pppoe-pwd	Parameter type: <Epon::pppoePwd> Format: - PPPoE password hidden from users - length: 1<=x<=32	<i>optional parameter with default value: ""</i> PPPoE password
[no] tagged-mode	Parameter type: <Epon::TagMode> Format: (transparent tag stacking) Possible values: - transparent : transparent mode - tag : tagged mode - stacking : stacking mode	<i>optional parameter with default value: "tag"</i> vlan tag mode
cvlan	Parameter type: <Epon::rmsCvlan> Format: - Vlan id - range: [2...4092]	<i>mandatory parameter</i> customer vlan for RMS
[no] svlan	Parameter type: <Epon::rmsSvlan> Format: - Vlan id - range: [0,2...4092]	<i>optional parameter with default value: 0L</i> Service vlan for RMS
[no] pbit	Parameter type: <Epon::pbit> Format: - DBA polling level - range: [0...7]	<i>optional parameter with default value: 7L</i> default pbit of this service is associated
[no] url	Parameter type: <Epon::url> Format: - URL - length: x<=256	<i>optional parameter with default value: ""</i> PPPoE user name

7.9 EONT Software Control Configuration Command

Command Description

This command configures an association between an ONT hardware version/variant and an ONT software version (download and planned).

Note: the combination for hw-version and ont-variant should be unique.

Note: hw-version and ont-variant could not be modified.

User Level

The command can be accessed by operators with equipment privileges, and executed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

```
> configure equipment eont ( no sw-ctrl (sw-ctrl-id) ) | ( sw-ctrl (sw-ctrl-id) hw-version <Epon::HwVer> [ no
ont-variant | ont-variant <Epon::PlndVar> ] plnd-sw-version <Epon::SwVer> [ no upgrade-mode | upgrade-mode
<Epon::UpMode> ] )
```

Command Parameters

Table 7.9-1 "EONT Software Control Configuration Command" Resource Parameters

Resource Identifier	Type	Description
(sw-ctrl-id)	Format: - eont sw ctrl id - range: [1...500]	software control id

Table 7.9-2 "EONT Software Control Configuration Command" Command Parameters

Parameter	Type	Description
hw-version	Parameter type: <Epon::HwVer> Format: - Octet String - length: 1<=x<=8	<i>mandatory parameter</i> <i>The parameter is not visible during modification.</i> EONT hardware version
[no] ont-variant	Parameter type: <Epon::PlndVar> Format: - eont sw version - length: x<=16	<i>optional parameter with default value: ""</i> <i>The parameter is not visible during modification.</i> variant of the EONT hardware version
plnd-sw-version	Parameter type: <Epon::SwVer> Format: - eont sw version	<i>mandatory parameter</i> planned EONT software version

7 Epon ONT Configuration Commands

Parameter	Type	Description
	- length: x<=16	
[no] upgrade-mode	Parameter type: <Epon::UpMode> Format: (none ctc tk dpoe) Possible values: - none : no software upgrade mode - ctc : CTC software upgrade mode - tk : TK software upgrade mode - dpoe : DPoE software upgrade mode	<i>optional parameter with default value: "ctc"</i> EONT software upgrade mode

8- *Port Protection Configuration Commands*

8.1 Port Protection Configuration Command Tree	8-426
8.2 Port Protection Configuration Command	8-427

8.1 Port Protection Configuration Command Tree

Description

This chapter gives an overview of nodes that are handled by "Port Protection Configuration Commands".

Command Tree

```
----configure
----[no] port-protection
    - (port)
    - paired-port
```

8.2 Port Protection Configuration Command

Command Description

This command allows the operator to configure a protection group on two ports which will then operate in redundancy. The system will decide which port of the two becomes active. In case of failure of one port the other port will take over. A forced switchover can also be triggered manually by the operator.

The port protection group is identified by the first port in the group that is intended to be protected. The following parameters can be configured for the protection group :

- *paired-port*: the paired port that will ensure the protection of the first one.

User Level

The command can be accessed by operators with equipment privileges, and executed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

```
> configure port-protection (port) paired-port <RedPort::PairedPortIndex>
```

Command Parameters

Table 8.2-1 "Port Protection Configuration Command" Resource Parameters

Resource Identifier	Type	Description
(port)	Format: (pon : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> chpair : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::ChannelPairId>) Possible values: - pon : pon-aid - chpair : chpair-aid Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Eqpt::ChannelPairId> - the channel pair identifier	the port identifier of the first port in the protection group

Table 8.2-2 "Port Protection Configuration Command" Command Parameters

Parameter	Type	Description
paired-port	Parameter type: <RedPort::PairedPortIndex>	mandatory parameter

8 Port Protection Configuration Commands

Parameter	Type	Description
	Format: (pon : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> chpair : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::ChannelPairId>) Possible values: - pon : pon-aid - chpair : chpair-aid Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Eqpt::ChannelPairId> - the channel pair identifier	the port identifier of the paired port in the protection group

9- xDSL Configuration Commands

9.1 xDSL Configuration Command Tree	9-431
9.2 xDSL Common Service Profile Configuration Command	9-440
9.3 xDSL Common Spectrum Profile Configuration Command	9-444
9.4 xDSL Artificial Noise Downstream Configuration Command	9-450
9.5 xDSL Spectrum Profile for ADSL/ADSL2 Configuration Command	9-452
9.6 xDSL Spectrum Profile for RE-ADSL2 Configuration Command	9-455
9.7 xDSL Spectrum Profile for ADSL2 Plus Configuration Command	9-457
9.8 ADSL2-plus Custom PSD shape Configuration Command	9-461
9.9 xDSL Spectrum Profile for VDSL Configuration Command	9-463
9.10 VDSL Ghs Tones Transmission Power Control Configuration Command	9-470
9.11 VDSL Custom PSD shape Downstream Configuration Command	9-472
9.12 VDSL Custom RX PSD shape Upstream Configuration Command	9-474
9.13 VDSL Power Back Off Configuration Command	9-476
9.14 xDSL Spectrum Profile for VDSL2 Configuration Command	9-477
9.15 VDSL2 Custom PSD shape Downstream Configuration Command	9-483
9.16 VDSL2 Custom PSD shape Upstream Configuration Command	9-485
9.17 VDSL2 Custom RX PSD shape Upstream Configuration Command	9-487
9.18 VDSL2 Virtual Noise Downstream Configuration Command	9-489
9.19 VDSL2 Virtual Noise Upstream Configuration Command	9-491
9.20 VDSL2 Power Back Off Configuration Command	9-493
9.21 xDSL DPBO Profile Configuration Command	9-495
9.22 xDSL DPBO Mode Independent Custom PSD Mask Configuration Command	9-497
9.23 xDSL DPBO Exchange PSD Mask Configuration Command	9-499
9.24 xDSL RTX Profile Configuration Command	9-501
9.25 xDSL Vectoring Profile Configuration Command	9-506
9.26 xDSL Sos Profile Configuration Command	9-509
9.27 xDSL Vectoring Control Entity Profile Configuration Command	9-512
9.28 xDSL Legacy UPBO Profile Configuration Command	9-515
9.29 xDSL Board Configuration Command	9-518
9.30 xDSL Board Vectoring Fallback Configuration	9-521

Command	
9.31 Xdsl Auto Port Reset Configurations	9-524
9.32 xDSL Vectoring Processing Board Configuration Command	9-526
9.33 xDSL Line Configuration Command	9-528
9.34 xDSL Line TCA Threshold Configuration Command	9-534
9.35 xDSL Per Line Overrule Configuration Command	9-537
9.36 xDSL Overrule Noise Psd Shape Downstream Configuration Command	9-544
9.37 xDSL Overrule Noise Psd Shape Upstream Configuration Command	9-546
9.38 xDSL INS Near End Configuration Command	9-548
9.39 xDSL INS Far End Configuration Command	9-550

9.1 xDSL Configuration Command Tree

Description

This chapter gives an overview of nodes that are handled by "xDSL Configuration Commands".

Command Tree

```

----configure
----xdsl
----[no] service-profile
    - (index)
    - name
    X (scope)
    - version
    - [no] ra-mode-down
    - [no] ra-mode-up
    - [no] min-bitrate-down
    - [no] min-bitrate-up
    - [no] sos-minbitrate-dn
    - [no] sos-minbitrate-up
    - [no] plan-bitrate-down
    - [no] plan-bitrate-up
    - [no] max-bitrate-down
    - [no] max-bitrate-up
    - [no] max-delay-down
    - [no] max-delay-up
    - [no] max-delay-var-dn
    - [no] max-delay-var-up
    - [no] memory-down
    - [no] imp-noise-prot-dn
    - [no] imp-noise-prot-up
    - [no] inp8-dn
    - [no] inp8-up
    - [no] inp-wo-erasure-dn
    - [no] inp-wo-erasure-up
    - [no] min-l2-br-down
    - [no] active
----[no] spectrum-profile
    - (index)
    - name
    X (scope)
    - version
    - [no] dis-ansi-t1413
    - [no] dis-etsi-dts
    - [no] dis-g992-1-a
    - [no] dis-g992-1-b
    - [no] dis-g992-2-a
    - [no] dis-g992-3-a
    - [no] dis-g992-3-b
    - [no] g992-3-aj
    - [no] g992-3-l1
    - [no] g992-3-l2
  
```

- [no] g992-3-am
- [no] g992-5-a
- [no] g992-5-b
- [no] ansi-t1.424
- [no] dis-etsi-ts
- [no] itu-g993-1
- [no] ieee-802.3ah
- [no] g992-5-aj
- [no] g992-5-am
- [no] g993-2-8a
- [no] g993-2-8b
- [no] g993-2-8c
- [no] g993-2-8d
- [no] g993-2-12a
- [no] g993-2-12b
- [no] g993-2-17a
- [no] g993-2-30a
- [no] g993-2-35b
- [no] min-noise-down
- [no] min-noise-up
- [no] trgt-noise-down
- [no] trgt-noise-up
- [no] max-noise-down
- [no] max-noise-up
- [no] carrier-mask-down
- [no] carrier-mask-up
- [no] rf-band-list
- [no] power_mngnt_mode
- [no] l0-time
- [no] l2-time
- [no] l2-agpow-red-tx
- [no] modification
- [no] active
- [no] rau-noise-down
- [no] rau-noise-up
- [no] rau-time-down
- [no] rau-time-up
- [no] rad-noise-down
- [no] rad-noise-up
- [no] rad-time-down
- [no] rad-time-up
- [no] l2-agpow-to-red-tx
- artificial-noise-down**
 - **(psd-point)**
 - [no] frequency
 - [no] psd
- adsl-adsl2**
 - X [no] proprietary-feat
 - [no] propr-feat-value
 - [no] max-agpowlev-down
 - [no] max-agpowlev-up
 - [no] max-psd-down
 - [no] max-psd-up
 - [no] pbo-mode-up
 - [no] max-recv-power-up
 - [no] psd-mask-up
- re-adsl**
 - X [no] proprietary-feat

- [no] propr-feat-value
- [no] max-agpowlev-down
- [no] max-agpowlev-up
- [no] max-psd-down
- [no] max-psd-up
- [no] pbo-mode-up
- [no] max-recv-power-up

----adsl2-plus

- X [no] proprietary-feat
- [no] propr-feat-value
- [no] max-agpowlev-down
- [no] max-agpowlev-up
- [no] max-psd-down
- [no] max-psd-up
- [no] psd-shape-down
- [no] pbo-mode-up
- [no] max-recv-power-up
- [no] psd-mask-up

----cust-psd-pt-down

- (psd-point)
- [no] frequency
- [no] psd

----vdsl

- X [no] proprietary-feat
- [no] propr-feat-value
- [no] vdsl-band-plan
- [no] optional-band
- [no] optional-endfreq
- [no] adsl-band
- [no] max-agpowlev-down
- [no] max-agpowlev-up
- [no] psd-shape-down
- [no] psd-shape-up
- X [no] pbo-mode-down
- [no] pbo-mode
- [no] rx-psd-shape-up
- [no] ghstones-pwr-mode
- [no] max-band
- [no] max-freq
- [no] m-psd-level-down
- [no] m-psd-level-up
- [no] psd-pbo-par-a-up
- [no] psd-pbo-par-b-up
- [no] cust-psd-sc-down
- [no] cust-psd-ty-down
- [no] cust-rx-psd-sc-up
- [no] cust-rx-psd-ty-up
- [no] opt-startfreq

----ghstone-set-pwr-ctrl

- [no] a43
- [no] b43
- [no] a43c
- [no] v43

----cust-psd-pt-down

- (psd-point)
- [no] frequency
- [no] psd

----cust-rx-psd-pt-up

- **(psd-point)**
- [no] frequency
- [no] psd
- pbo**
- **(band)**
- param-a
- param-b
- vdsl2**
- X** [no] proprietary-feat
- [no] propr-feat-value
- [no] max-agpowlev-down
- [no] max-agpowlev-up
- [no] psd-shape-down
- [no] cs-psd-shape-dn
- [no] cs-psd-shape-up
- [no] psd-shape-up
- [no] rx-psd-shape-up
- [no] psd-pbo-e-len-up
- [no] m-psd-level-down
- [no] m-psd-level-up
- [no] psd-pbo-par-a-up
- [no] psd-pbo-par-b-up
- [no] v-noise-snr-down
- [no] v-noise-snr-up
- [no] v-noise-psd-down
- [no] v-noise-psd-up
- [no] cust-psd-sc-down
- [no] cust-psd-ty-down
- [no] cust-psd-sc-up
- [no] cust-psd-ty-up
- [no] cust-rx-psd-sc-up
- [no] cust-rx-psd-ty-up
- [no] upbo-aele-mode
- [no] upboaele-min-thrs
- [no] short-loop-lr
- [no] medium-loop-lr
- [no] long-loop-lr
- cust-psd-pt-down**
- **(psd-point)**
- [no] frequency
- [no] psd
- cust-psd-pt-up**
- **(psd-point)**
- [no] frequency
- [no] psd
- cust-rx-psd-pt-up**
- **(psd-point)**
- [no] frequency
- [no] psd
- v-noise-psd-pt-down**
- **(psd-point)**
- [no] frequency
- [no] psd
- v-noise-psd-pt-up**
- **(psd-point)**
- [no] frequency
- [no] psd
- pbo**
- **(band)**

```

        - [no] equal-fext
        - param-a
        - param-b
----[no] dpbo-profile
- (index)
- name
- [no] es-elect-length
- [no] es-cable-model-a
- [no] es-cable-model-b
- [no] es-cable-model-c
- [no] min-usable-signal
- [no] min-frequency
- [no] max-frequency
- [no] rs-elect-length
- [no] muf-control
- [no] offset
- [no] modification
- [no] active
----micpsd-pt-down
- (psd-point)
- [no] frequency
- [no] psd
----epsd-pt-down
- (psd-point)
- [no] frequency
- [no] psd
----[no] rtx-profile
- (index)
- name
- version
- [no] rtx-mode-dn
- [no] rtx-mode-up
- [no] min-exp-thrpt-dn
- [no] min-exp-thrpt-up
- [no] plan-exp-thrpt-dn
- [no] plan-exp-thrpt-up
- [no] max-exp-thrpt-dn
- [no] max-exp-thrpt-up
- [no] max-net-rate-dn
- [no] max-net-rate-up
- [no] min-delay-dn
- [no] min-delay-up
- [no] max-delay-dn
- [no] max-delay-up
- [no] min-inp-shine-dn
- [no] min-inp-shine-up
- [no] min-inp-rein-dn
- [no] min-inp-rein-up
- [no] min-inp8-shine-dn
- [no] min-inp8-shine-up
- [no] min-inp8-rein-dn
- [no] min-inp8-rein-up
- [no] int-arr-time-dn
- [no] int-arr-time-up
- [no] shine-ratio-dn
- [no] shine-ratio-up
- [no] leftr-thresh-dn
- [no] leftr-thresh-up

```

- [no] modification
- [no] active
- [no] vect-profile
 - (index)
 - name
 - version
 - [no] fext-cancel-up
 - [no] fext-cancel-dn
 - [no] leg-can-dn-m1
 - [no] leg-can-dn-m2
 - [no] dis-gvect-cpe
 - [no] gvecfriend-cpe
 - [no] gvecfriend-dn-cpe
 - [no] legacy-cpe
 - [no] band-control-up
 - [no] band-control-dn
 - [no] vect-leav-thresh
 - [no] vect-feat-bitmap
 - [no] legacy-upbo
 - [no] modification
 - [no] active
- [no] sos-profile
 - (index)
 - name
 - version
 - [no] sos-time-down
 - [no] sos-time-up
 - [no] sos-ntones-down
 - [no] sos-ntones-up
 - [no] sos-crc-down
 - [no] sos-crc-up
 - [no] max-sos-down
 - [no] max-sos-up
 - [no] snrmoffset-roc-dn
 - [no] snrmoffset-roc-up
 - [no] min-inp-roc-down
 - [no] min-inp-roc-up
 - [no] roc-mode-down
 - [no] roc-mode-up
 - [no] modification
 - [no] active
- [no] vce-profile
 - (index)
 - name
 - version
 - [no] vce-gain-mode
 - [no] vce-join-timeout
 - [no] vce-min-par-join
 - [no] vce-hist-pcoder
 - [no] vce-band-plan
 - [no] vce-max-vect-freq
 - [no] modification
 - [no] active
- [no] leg-upbo-profile
 - (index)
 - name
 - version
 - [no] pbo-mode

- [no] rx-psd-shape-up
- [no] psd-pbo-e-len-up
- [no] equal-fext
- [no] psd-pbo-par-a-up
- [no] psd-pbo-par-b-up
- [no] modification
- [no] active

----board

- **(board-index)**
- [no] dpbo-profile
- [no] vce-profile
- [no] vplt-autodiscover
- [no] vce-capacity-mode
- [no] leg-upbo-profile
- [no] vect-class

----vect-fallback

- [no] fb-vplt-com-fail
- [no] fb-cpe-cap-mism
- [no] fb-conf-not-feas
- [no] spectrum-profile
- [no] service-profile
- [no] dpbo-profile
- [no] rtx-profile
- [no] sos-profile

----auto-port-reset

- [no] max-retry-attempt
- [no] reset-interval
- [no] reset-threshold

----vp-board

- **(board-index)**
- **vp-link**
- [no] lt-expect

----line

- **(if-index)**
- [no] service-profile
- [no] spectrum-profile
- [no] dpbo-profile
- [no] rtx-profile
- [no] vect-profile
- [no] sos-profile
- [no] ansi-t1413
- [no] etsi-dts
- [no] g992-1-a
- [no] g992-1-b
- [no] g992-2-a
- [no] g992-3-a
- [no] g992-3-b
- [no] g992-3-aj
- [no] g992-3-l1
- [no] g992-3-l2
- [no] g992-3-am
- [no] g992-5-a
- [no] g992-5-b
- [no] ansi-t1.424
- [no] etsi-ts
- [no] itu-g993-1
- [no] ieee-802.3ah
- [no] g992-5-aj

- [no] g992-5-am
- [no] g993-2-8a
- [no] g993-2-8b
- [no] g993-2-8c
- [no] g993-2-8d
- [no] g993-2-12a
- [no] g993-2-12b
- [no] g993-2-17a
- [no] g993-2-30a
- [no] g993-2-35b
- [no] carrier-data-mode
- [no] admin-up
- X bonding-mode
- [no] transfer-mode
- [no] imp-noise-sensor
- [no] vect-qln-mode
- [no] auto-switch
- [no] vect-fallback
- tca-line-threshold
- [no] enable
- [no] es-nearend
- [no] ses-nearend
- [no] uas-nearend
- [no] leftr-nearend
- [no] leftr-day-nearend
- [no] es-day-nearend
- [no] ses-day-nearend
- [no] uas-day-nearend
- [no] es-farend
- [no] ses-farend
- [no] uas-farend
- [no] es-day-farend
- [no] ses-day-farend
- [no] uas-day-farend
- [no] leftr-farend
- [no] leftr-day-farend
- [no] reinit
- [no] reinit-day
- [no] override-data
- (if-index)
- [no] max-bitrate-down
- [no] max-bitrate-up
- [no] max-delay-down
- [no] max-delay-up
- [no] imp-noise-prot-dn
- [no] imp-noise-prot-up
- [no] trgt-noise-down
- [no] trgt-noise-up
- [no] max-psd-down
- [no] max-psd-up
- [no] carrier-mask-down
- [no] carrier-mask-up
- [no] noise-psd-mode-dn
- [no] noise-psd-mode-up
- [no] rtx-mode-dn
- [no] rtx-mode-up
- [no] max-net-rate-dn
- [no] max-net-rate-up


```

- [no] max-exp-thrpt-dn
- [no] max-exp-thrpt-up
- [no] min-inp-shine-dn
- [no] min-inp-shine-up
- [no] min-inp-rein-dn
- [no] min-inp-rein-up
- [no] min-delay-dn
- [no] min-delay-up
- [no] rtx-max-delay-dn
- [no] rtx-max-delay-up
- [no] shine-ratio-dn
- [no] shine-ratio-up
- [no] leftr-thresh-dn
- [no] leftr-thresh-up
- [no] memory-down
- [no] modification
- [no] active
----noise-psd-pt-down
- (psd-point)
- [no] frequency
- [no] psd
----noise-psd-pt-up
- (psd-point)
- [no] frequency
- [no] psd
----imp-noise-sensor
----near-end
- (if-index)
- [no] inm-mode
- [no] inm-eq-inp-mode
- [no] ins-sensitivity
- [no] inm-cluster-cont
- [no] inm-iat-offset
- [no] inm-iat-step
----far-end
- (if-index)
- [no] inm-mode
- [no] inm-eq-inp-mode
- [no] ins-sensitivity
- [no] inm-cluster-cont
- [no] inm-iat-offset
- [no] inm-iat-step

```

9.2 xDSL Common Service Profile Configuration Command

Command Description

This command allows the operator to manage the DSL service profile. The service profile groups all parameters on DSL service level (data rates, Rate Adaption mode, delay, ...). The service parameters are common for all DSL flavors.

DESCRIPTION FOR THE COMMAND PARAMETER-SCOPE: The combination scope+profile must be unique. Typically local-profile must be used especially when configuring via CLI. Use of network-profile is depreciated. The network-profile was foreseen to allow management agents to define network-wide unique profiles, independent of what local profiles may have been created.

DESCRIPTION FOR THE COMMAND PARAMETER max-delay-down and max-delay-up: The delay is expressed in milliseconds. Range: 1 to 63 ms in steps of 1 ms with 1 as special value. The value 1 is used to specify that fast or pseudo fast latency (i.e. no interleaving).

User Level

The command can be accessed by operators with xdsl privileges, and executed by operators with xdsl privileges.

Command Syntax

The command has the following syntax:

```
> configure xdsl ( no service-profile (index) ) | ( service-profile (index) name <AsamProfileName> [ (scope) ] [
version <SignedInteger> ] [ no ra-mode-down | ra-mode-down <Xdsl::RAModeDownType> ] [ no ra-mode-up |
ra-mode-up <Xdsl::RAModeUpType> ] [ no min-bitrate-down | min-bitrate-down <Xdsl::BitRate> ] [ no
min-bitrate-up | min-bitrate-up <Xdsl::BitRate> ] [ no sos-minbitrate-dn | sos-minbitrate-dn <Xdsl::BitRate> ] [ no
sos-minbitrate-up | sos-minbitrate-up <Xdsl::BitRate> ] [ no plan-bitrate-down | plan-bitrate-down <Xdsl::BitRate>
] [ no plan-bitrate-up | plan-bitrate-up <Xdsl::BitRate> ] [ no max-bitrate-down | max-bitrate-down
<Xdsl::BitRate> ] [ no max-bitrate-up | max-bitrate-up <Xdsl::BitRate> ] [ no max-delay-down | max-delay-down
<Xdsl::InterleavingDelay> ] [ no max-delay-up | max-delay-up <Xdsl::InterleavingDelay> ] [ no max-delay-var-dn
| max-delay-var-dn <Xdsl::VariationDelay> ] [ no max-delay-var-up | max-delay-var-up <Xdsl::VariationDelay> ]
[ no memory-down | memory-down <Xdsl::DownstreamMemory> ] [ no imp-noise-prot-dn | imp-noise-prot-dn
<Xdsl::ImpNoiseProtection> ] [ no imp-noise-prot-up | imp-noise-prot-up <Xdsl::ImpNoiseProtection> ] [ no
inp8-dn | inp8-dn <Xdsl::ImpNoiseProtection> ] [ no inp8-up | inp8-up <Xdsl::ImpNoiseProtection> ] [ [ no ]
inp-wo-erasure-dn ] [ [ no ] inp-wo-erasure-up ] [ no min-l2-br-down | min-l2-br-down <Xdsl::BitRate> ] [ [ no ]
active ] )
```

Command Parameters

Table 9.2-1 "xDSL Common Service Profile Configuration Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - a profile index value - range: [1...1024]	index of the profile

Table 9.2-2 "xDSL Common Service Profile Configuration Command" Command Parameters

Parameter	Type	Description
name	Parameter type: <AsamProfileName> Format: - a profile name - range: [a-zA-Z0-9-_.] - length: 1<=x<=32	<i>mandatory parameter</i> profile name
(scope)	Format: local-profile Possible values: - local-profile : the local profile	<i>obsolete parameter that will be ignored</i> scope of the profile
version	Parameter type: <SignedInteger> Format: - a signed integer	<i>optional parameter</i> version maintained by manager, usually 1 for new profile
[no] ra-mode-down	Parameter type: <Xdsl::RAModeDownType> Format: (operator-ctrl automatic dynamic sos-dynamic) Possible values: - operator-ctrl : operator controlled rate adaptive mode in downstream - automatic : automatic rate adaptive mode at startup in downstream - dynamic : dynamic rate adaptive mode at startup and at showtime in downstream - sos-dynamic : dynamic rate adaptive mode with SOS in downstream	<i>optional parameter with default value: "automatic"</i> rate adaptation mode for down stream
[no] ra-mode-up	Parameter type: <Xdsl::RAModeUpType> Format: (operator-ctrl automatic dynamic sos-dynamic) Possible values: - operator-ctrl : operator controlled rate adaptive mode in upstream - automatic : automatic rate adaptive mode at startup in upstream - dynamic : dynamic rate adaptive mode at startup and at showtime in upstream - sos-dynamic : dynamic rate adaptive mode with SOS in upstream	<i>optional parameter with default value: "automatic"</i> rate adaptation mode for up stream
[no] min-bitrate-down	Parameter type: <Xdsl::BitRate> Format: - a bit rate value - unit: kbps - range: [0...2147483647]	<i>optional parameter with default value: 1024</i> minimum downstream bit rate to be maintained
[no] min-bitrate-up	Parameter type: <Xdsl::BitRate> Format: - a bit rate value - unit: kbps - range: [0...2147483647]	<i>optional parameter with default value: 64</i> minimum upstream bit rate to be maintained
[no] sos-minbitrate-dn	Parameter type: <Xdsl::BitRate> Format: - a bit rate value	<i>optional parameter with default value: 64</i> minimum net data rate required

9 xDSL Configuration Commands

Parameter	Type	Description
	- unit: kbps - range: [0...2147483647]	for a valid SOS request in downstream
[no] sos-minbitrate-up	Parameter type: <Xdsl::BitRate> Format: - a bit rate value - unit: kbps - range: [0...2147483647]	<i>optional parameter with default value: 64</i> minimum net data rate required for a valid SOS request in upstream
[no] plan-bitrate-down	Parameter type: <Xdsl::BitRate> Format: - a bit rate value - unit: kbps - range: [0...2147483647]	<i>optional parameter with default value: 1536</i> planned bitrate in downstream
[no] plan-bitrate-up	Parameter type: <Xdsl::BitRate> Format: - a bit rate value - unit: kbps - range: [0...2147483647]	<i>optional parameter with default value: 128</i> planned bitrate in upstream
[no] max-bitrate-down	Parameter type: <Xdsl::BitRate> Format: - a bit rate value - unit: kbps - range: [0...2147483647]	<i>optional parameter with default value: 6144</i> maximum bitrate in downstream
[no] max-bitrate-up	Parameter type: <Xdsl::BitRate> Format: - a bit rate value - unit: kbps - range: [0...2147483647]	<i>optional parameter with default value: 640</i> maximum bitrate in upstream
[no] max-delay-down	Parameter type: <Xdsl::InterleavingDelay> Format: - a delay time period - unit: msec - range: [1...63]	<i>optional parameter with default value: 16</i> maximum delay for interleaving function in downstream
[no] max-delay-up	Parameter type: <Xdsl::InterleavingDelay> Format: - a delay time period - unit: msec - range: [1...63]	<i>optional parameter with default value: 16</i> maximum delay for interleaving function in upstream
[no] max-delay-var-dn	Parameter type: <Xdsl::VariationDelay> Format: - a delay time period - unit: 1/10msec - range: [1...255]	<i>optional parameter with default value: 255</i> maximum delay variation in downstream
[no] max-delay-var-up	Parameter type: <Xdsl::VariationDelay> Format: - a delay time period - unit: 1/10msec - range: [1...255]	<i>optional parameter with default value: 255</i> maximum delay variation in upstream
[no] memory-down	Parameter type: <Xdsl::DownstreamMemory> Format: - configurable downstream memory - unit: 1/100 - range: [0...100,255]	<i>optional parameter with default value: 255</i> configurable memory for downstream. Value 0-100 express the % of memory to be allocated to the downstream direction and special value 255 means the vendor discretionary algorithm shall be used.
[no] imp-noise-prot-dn	Parameter type: <Xdsl::ImpNoiseProtection>	<i>optional parameter with default</i>

Parameter	Type	Description
	Format: - minimum impulse noise protection - unit: 1/10 symbols - range: [0...160]	<i>value: 0</i> minimum impulse noise protection in downstream
[no] imp-noise-prot-up	Parameter type: <Xdsl::ImpNoiseProtection> Format: - minimum impulse noise protection - unit: 1/10 symbols - range: [0...160]	<i>optional parameter with default value: 0</i> minimum impulse noise protection in upstream
[no] inp8-dn	Parameter type: <Xdsl::ImpNoiseProtection> Format: - minimum impulse noise protection - unit: 1/10 symbols - range: [0...160]	<i>optional parameter with default value: 0</i> minimum impulse noise protection in downstream with a subcarrier spacing of 8.6250kHz
[no] inp8-up	Parameter type: <Xdsl::ImpNoiseProtection> Format: - minimum impulse noise protection - unit: 1/10 symbols - range: [0...160]	<i>optional parameter with default value: 0</i> minimum impulse noise protection in upstream with a subcarrier spacing of 8.6250kHz
[no] inp-wo-erasure-dn	Parameter type: boolean	<i>optional parameter</i> min-inp even without erasure detection in downstream
[no] inp-wo-erasure-up	Parameter type: boolean	<i>optional parameter</i> min-inp even without erasure detection in upstream
[no] min-l2-br-down	Parameter type: <Xdsl::BitRate> Format: - a bit rate value - unit: kbps - range: [0...2147483647]	<i>optional parameter with default value: 128</i> minimum downstream bitrate to be maintained during L2
[no] active	Parameter type: boolean	<i>optional parameter</i> <i>The parameter is not visible during creation.</i> to activate the profile

9.3 xDSL Common Spectrum Profile Configuration Command

Command Description

This command allows the operator to manage the DSL spectrum profile. The spectrum profiles groups all parameters on DSL on physical level. These parameters are mainly related to the environmental conditions of the line (spectrum management).

The Spectrum Configuration profile contains parameters which have a common value for all DSL flavors (Common) and parameters which have a specific value depending on the DSL flavor used (ADSL1/2, READSL2, ADSL2Plus, VDSL, VDSL2).

The specific values depending on the DSL flavor can be configured via:

- `configure xdsl spectrum-profile adsl-adsl2`
- `configure xdsl spectrum-profile re-adsl`
- `configure xdsl spectrum-profile adsl2-plus`
- `configure xdsl spectrum-profile vdsl`
- `configure xdsl spectrum-profile vdsl2`

The actual selected operating mode determines which set of DSL specific parameters is used. In case a common parameter is not supported for a specific DSL flavor, this parameter will be ignored for that flavor.

When all the DSL specific flavors are configured the complete profile has to be activated.

DESCRIPTION FOR THE COMMAND PARAMETER-SCOPE: The combination scope+profile must be unique. Typically local-profile must be used especially when configuring via CLI. Use of network-profile is depreciated. The network-profile was foreseen to allow management agents to define network-wide unique profiles, independent of what local profiles may have been created.

User Level

The command can be accessed by operators with `xdsl` privileges, and executed by operators with `xdsl` privileges.

Command Syntax

The command has the following syntax:

```
> configure xdsl ( no spectrum-profile (index) ) | ( spectrum-profile (index) name <AsamProfileName> [ (scope) ] [
version <SignedInteger> ] [ [ no ] dis-ansi-t1413 ] [ [ no ] dis-etsi-dts ] [ [ no ] dis-g992-1-a ] [ [ no ] dis-g992-1-b ]
[ [ no ] dis-g992-2-a ] [ [ no ] dis-g992-3-a ] [ [ no ] dis-g992-3-b ] [ [ no ] g992-3-aj ] [ [ no ] g992-3-l1 ] [ [ no ]
g992-3-l2 ] [ [ no ] g992-3-am ] [ [ no ] g992-5-a ] [ [ no ] g992-5-b ] [ [ no ] ansi-t1.424 ] [ [ no ] dis-etsi-ts ] [ [ no ]
itu-g993-1 ] [ [ no ] ieee-802.3ah ] [ [ no ] g992-5-aj ] [ [ no ] g992-5-am ] [ [ no ] g993-2-8a ] [ [ no ] g993-2-8b ]
[ [ no ] g993-2-8c ] [ [ no ] g993-2-8d ] [ [ no ] g993-2-12a ] [ [ no ] g993-2-12b ] [ [ no ] g993-2-17a ] [ [ no ]
g993-2-30a ] [ [ no ] g993-2-35b ] [ no min-noise-down | min-noise-down <Xdsl::NoiseMargin> ] [ no
min-noise-up | min-noise-up <Xdsl::NoiseMargin> ] [ no trgt-noise-down | trgt-noise-down <Xdsl::NoiseMargin> ]
[ no trgt-noise-up | trgt-noise-up <Xdsl::NoiseMargin> ] [ no max-noise-down | max-noise-down
<Xdsl::NoiseMarginPlus> ] [ no max-noise-up | max-noise-up <Xdsl::NoiseMarginPlus> ] [ no carrier-mask-down
| carrier-mask-down <Xdsl::CarrierMaskDown> ] [ no carrier-mask-up | carrier-mask-up <Xdsl::CarrierMaskUp> ]
[ no rf-band-list | rf-band-list <Xdsl::RFBandOrNotUsed> ] [ no power_mgnt_mode | power_mgnt_mode
<Xdsl::LinePowerMgtMode> ] [ no l0-time | l0-time <Xdsl::LineL0Time> ] [ no l2-time | l2-time
```

```
<Xdsl::LineL2Time> ] [ no l2-agpow-red-tx | l2-agpow-red-tx <Xdsl::LineL2Atrp> ] [ no modification |
modification <Xdsl::ModifyStatus> ] [ [ no ] active ] [ no rau-noise-down | rau-noise-down <Xdsl::NoiseMargin> ]
[ no rau-noise-up | rau-noise-up <Xdsl::NoiseMargin> ] [ no rau-time-down | rau-time-down <Xdsl::RaTime> ] [
no rau-time-up | rau-time-up <Xdsl::RaTime> ] [ no rad-noise-down | rad-noise-down <Xdsl::NoiseMargin> ] [ no
rad-noise-up | rad-noise-up <Xdsl::NoiseMargin> ] [ no rad-time-down | rad-time-down <Xdsl::RaTime> ] [ no
rad-time-up | rad-time-up <Xdsl::RaTime> ] [ no l2-agpw-to-red-tx | l2-agpw-to-red-tx <Xdsl::LineL2AtrpT> ] )
```

Command Parameters

Table 9.3-1 "xDSL Common Spectrum Profile Configuration Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - a profile index value - range: [1...256]	index of the profile.

Table 9.3-2 "xDSL Common Spectrum Profile Configuration Command" Command Parameters

Parameter	Type	Description
name	Parameter type: <AsamProfileName> Format: - a profile name - range: [a-zA-Z0-9-_.] - length: 1<=x<=32	<i>mandatory parameter</i> profile name
(scope)	Format: local-profile Possible values: - local-profile : the local profile	<i>obsolete parameter that will be ignored</i> scope of the profile
version	Parameter type: <SignedInteger> Format: - a signed integer	<i>optional parameter</i> version maintained by manager, usually 1 for new profile
[no] dis-ansi-t1413	Parameter type: boolean	<i>optional parameter</i> disable ANSI T1.413-1998
[no] dis-etsi-dts	Parameter type: boolean	<i>optional parameter</i> disable ETSI DTS/TM06006
[no] dis-g992-1-a	Parameter type: boolean	<i>optional parameter</i> disable G.992.1 POTS non-overlapped spectrum
[no] dis-g992-1-b	Parameter type: boolean	<i>optional parameter</i> disable G.992.1 ISDN non-overlapped spectrum
[no] dis-g992-2-a	Parameter type: boolean	<i>optional parameter</i> disable G.992.2 POTS non-overlapped spectrum
[no] dis-g992-3-a	Parameter type: boolean	<i>optional parameter</i> disable G.992.3 POTS non-overlapped spectrum
[no] dis-g992-3-b	Parameter type: boolean	<i>optional parameter</i> disable G.992.3 ISDN non-overlapped spectrum
[no] g992-3-aj	Parameter type: boolean	<i>optional parameter</i> G.992.3 all digital mode non-overlapped spectrum
[no] g992-3-l1	Parameter type: boolean	<i>optional parameter</i> G.992.3 POTS non-overlapped spectrum US mask 1
[no] g992-3-l2	Parameter type: boolean	<i>optional parameter</i>

9 xDSL Configuration Commands

Parameter	Type	Description
		G.992.3 POTS non-overlapped spectrum US mask 2
[no] g992-3-am	Parameter type: boolean	<i>optional parameter</i> G.992.3 extended POTS with non-overlapped spectrum
[no] g992-5-a	Parameter type: boolean	<i>optional parameter</i> G.992.5 POTS non-overlapped spectrum
[no] g992-5-b	Parameter type: boolean	<i>optional parameter</i> G.992.5 ISDN non-overlapped spectrum
[no] ansi-t1.424	Parameter type: boolean	<i>optional parameter</i> ANSI T1.424
[no] dis-etsi-ts	Parameter type: boolean	<i>optional parameter</i> disable ETSI TS
[no] itu-g993-1	Parameter type: boolean	<i>optional parameter</i> ITU G993-1
[no] ieee-802.3ah	Parameter type: boolean	<i>optional parameter</i> IEEE 802.3ah
[no] g992-5-aj	Parameter type: boolean	<i>optional parameter</i> G.992.5 all digital mode non-overlapped spectrum
[no] g992-5-am	Parameter type: boolean	<i>optional parameter</i> G.992.5 extended POTS non-overlapped spectrum
[no] g993-2-8a	Parameter type: boolean	<i>optional parameter</i> G.993.2_8A VDSL-2 with profile 8A
[no] g993-2-8b	Parameter type: boolean	<i>optional parameter</i> G.993.2_8B VDSL-2 with profile 8B
[no] g993-2-8c	Parameter type: boolean	<i>optional parameter</i> G.993.2_8C VDSL-2 with profile 8C
[no] g993-2-8d	Parameter type: boolean	<i>optional parameter</i> G.993.2_8D VDSL-2 with profile 8D
[no] g993-2-12a	Parameter type: boolean	<i>optional parameter</i> G.993.2_12A VDSL-2 with profile 12A
[no] g993-2-12b	Parameter type: boolean	<i>optional parameter</i> G.993.2_12B VDSL-2 with profile 12B
[no] g993-2-17a	Parameter type: boolean	<i>optional parameter</i> G.993.2_17A VDSL-2 with profile 17A
[no] g993-2-30a	Parameter type: boolean	<i>optional parameter</i> G.993.2_30A VDSL-2 with profile 30A
[no] g993-2-35b	Parameter type: boolean	<i>optional parameter</i> G.993.2_35B VDSL-2 with profile 35B
[no] min-noise-down	Parameter type: <Xdsl::NoiseMargin> Format: - a noise margin value - unit: 0.1 dB - range: [0...310]	<i>optional parameter with default value: 0</i> minimum noise margin in downstream

[illegible]

9 xDSL Configuration Commands

Parameter	Type	Description
	Possible values: - none : l2 or l3 not supported - l2 : only l2 supported - l3 : only l3 supported - l2-l3 : l2 and l3 supported	
[no] l0-time	Parameter type: <Xdsl::LineL0Time> Format: - min time in a state before transiting into another - unit: sec - range: [0...1800]	<i>optional parameter with default value: 255</i> min time between exit from and entry in l2 state
[no] l2-time	Parameter type: <Xdsl::LineL2Time> Format: - min time in a state before transiting into another - unit: sec - range: [0...1800]	<i>optional parameter with default value: 60</i> min time between entry in l2 and first power trim
[no] l2-agpow-red-tx	Parameter type: <Xdsl::LineL2Atp> Format: - the maximum aggregate transmit power reduction - unit: dB - range: [0...31]	<i>optional parameter with default value: 3</i> the maximum aggregate transmit power reduction for l2
[no] modification	Parameter type: <Xdsl::ModifyStatus> Format: (start cancel complete) Possible values: - start : to start modifying the profile - cancel : to cancel the modifications done - complete : to complete the modifications	<i>optional parameter with default value: "complete"</i> to modify the profile
[no] active	Parameter type: boolean	<i>optional parameter</i> The parameter is not visible during creation. to activate the profile
[no] rau-noise-down	Parameter type: <Xdsl::NoiseMargin> Format: - a noise margin value - unit: 0.1 dB - range: [0...310]	<i>optional parameter with default value: 70</i> downstream upshift noise margin for rate adaptation
[no] rau-noise-up	Parameter type: <Xdsl::NoiseMargin> Format: - a noise margin value - unit: 0.1 dB - range: [0...310]	<i>optional parameter with default value: 70</i> upstream upshift noise margin for rate adaptation
[no] rau-time-down	Parameter type: <Xdsl::RaTime> Format: - a data rate value - unit: sec - range: [0...16383]	<i>optional parameter with default value: 300</i> downstream minimum upshift rate adaptation interval
[no] rau-time-up	Parameter type: <Xdsl::RaTime> Format: - a data rate value - unit: sec - range: [0...16383]	<i>optional parameter with default value: 300</i> upstream minimum upshift rate adaptation interval
[no] rad-noise-down	Parameter type: <Xdsl::NoiseMargin> Format: - a noise margin value - unit: 0.1 dB	<i>optional parameter with default value: 20</i> downstream downshift noise margin for rate adaptation

Parameter	Type	Description
	- range: [0...310]	
[no] rad-noise-up	Parameter type: <Xdsl::NoiseMargin> Format: - a noise margin value - unit: 0.1 dB - range: [0...310]	<i>optional parameter with default value: 20</i> upstream downshift noise margin for rate adaptation
[no] rad-time-down	Parameter type: <Xdsl::RaTime> Format: - a data rate value - unit: sec - range: [0...16383]	<i>optional parameter with default value: 30</i> downstream minimum downshift rate adaptation interval
[no] rad-time-up	Parameter type: <Xdsl::RaTime> Format: - a data rate value - unit: sec - range: [0...16383]	<i>optional parameter with default value: 30</i> upstream minimum downshift rate adaptation interval
[no] l2-agpw-to-red-tx	Parameter type: <Xdsl::LineL2AtprT> Format: - the total maximum aggregate transmit power reduction - unit: dB - range: [0...31]	<i>optional parameter with default value: 31</i> total maximum aggregate transmit power reduction for L2

9.4 xDSL Artificial Noise Downstream Configuration Command

Command Description

This command allows the operator to configure artificial noise in Downstream

This command allows to specify the transmitter-referred artificial noise level to be used as additional noise source at the downstream transmitter.

Artificial Noise PSD points are defined in the range -140dBm/Hz..-40 dBm/Hz. These values must be manually converted to the range 0..200 using the formula $-2 \times (40 + \text{PSD level})$.

A special value (-167,5 dBm/Hz) (entered value: 255) states no artificial noise has to be applied.

When all break points are set to default values (frequency 0, psd 0), the psd shape is cleared. To clear the entire shape at once, set the first two breakpoints to default values. When any other breakpoint is set to default values, all points following it will also be set to the default values.

When defining a PSD shape, a minimum of 2 PSD points should be specified. The successive PSD points must have increasing ($>/=$) frequencies. It is allowed that for two successive PSD points, different PSD levels are defined at a same frequency (brickwall).

User Level

The command can be accessed by operators with xdsl privileges, and executed by operators with xdsl privileges.

Command Syntax

The command has the following syntax:

```
> configure xdsl spectrum-profile (index) artificial-noise-down (psd-point) [ no frequency | frequency
<Xdsl::CustFreq> ] [ no psd | psd <Xdsl::CustPsd> ]
```

Command Parameters

Table 9.4-1 "xDSL Artificial Noise Downstream Configuration Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - a profile index value - range: [1...256]	index of the profile.
(psd-point)	Format: - psd point - range: [1...32]	psd-point

Table 9.4-2 "xDSL Artificial Noise Downstream Configuration Command" Command Parameters

Parameter	Type	Description
[no] frequency	Parameter type: <Xdsl::CustFreq> Format:	optional parameter with default value: 0

Parameter	Type	Description
	- frequency - unit: khz - range: [0...35324]	psd frequency
[no] psd	Parameter type: <Xdsl::CustPsd> Format: - psd level - unit: -2*(40+PSD level in dBm/Hz) - range: [0...200,255]	<i>optional parameter with default value: 0</i> psd level

9.5 xDSL Spectrum Profile for ADSL/ADSL2 Configuration Command

Command Description

This command allows the operator to manage the ADSL and ADSL2 specific part of the DSL spectrum profile. The spectrum profiles groups all parameters on DSL on physical level. These parameters are mainly related to the environmental conditions of the line (spectrum management).

The Spectrum Configuration Profile contains parameters which have a common value for all DSL flavors (Common) and parameters which have a specific value depending on the DSL flavor used (ADSL1/2, READSL2, ADSL2Plus, VDSL).

This chapter contains the ADSL-ADSL2 flavor specific parameters.

Note: the activation of the profile has to be done via configure xdsl spectrum-profile.

User Level

The command can be accessed by operators with xdsl privileges, and executed by operators with xdsl privileges.

Command Syntax

The command has the following syntax:

```
> configure xdsl spectrum-profile (index) adsl-adsl2 [ [ no ] proprietary-feat ] [ no propr-feat-value |
propr-feat-value <Xdsl::ProprFeatValue> ] [ no max-agpowlev-down | max-agpowlev-down <Xdsl::PowerLevel> ]
[ no max-agpowlev-up | max-agpowlev-up <Xdsl::PowerLevel> ] [ no max-psd-down | max-psd-down
<Xdsl::Adsl2PowerSpectralDensityDown> ] [ no max-psd-up | max-psd-up
<Xdsl::Adsl2PowerSpectralDensityUp> ] [ no pbo-mode-up ] [ no max-recv-power-up | max-recv-power-up
<Xdsl::RxPowerLevel> ] [ no psd-mask-up | psd-mask-up <Xdsl::Adsl2PsdMaskUp> ]
```

Command Parameters

Table 9.5-1 "xDSL Spectrum Profile for ADSL/ADSL2 Configuration Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - a profile index value - range: [1...256]	index of the profile.

Table 9.5-2 "xDSL Spectrum Profile for ADSL/ADSL2 Configuration Command" Command Parameters

Parameter	Type	Description
[no] proprietary-feat	Parameter type: boolean	<i>obsolete parameter that will be ignored</i> enable proprietary features of the modem

Parameter	Type	Description
[no] propr-feat-value	Parameter type: <Xdsl::ProprFeatValue> Format: - Proprietary feature - range: [0...4294967295]	<i>optional parameter with default value: 1</i> proprietary feature
[no] max-agpowlev-down	Parameter type: <Xdsl::PowerLevel> Format: - a power level value - unit: 1/10 * dBm - range: [0...255]	<i>optional parameter with default value: 255</i> maximum aggregate power allowed in downstream
[no] max-agpowlev-up	Parameter type: <Xdsl::PowerLevel> Format: - a power level value - unit: 1/10 * dBm - range: [0...255]	<i>optional parameter with default value: 255</i> maximum aggregate power allowed in upstream
[no] max-psd-down	Parameter type: <Xdsl::Adsl2PowerSpectralDensityDown> Format: - a power spectral density value - unit: 1/10 * dBm/Hz - range: [-600...-400]	<i>optional parameter with default value: -400</i> maximum power spectral density allowed in downstream
[no] max-psd-up	Parameter type: <Xdsl::Adsl2PowerSpectralDensityUp> Format: - a power spectral density value - unit: 1/10 * dBm/Hz - range: [-600...-380]	<i>optional parameter with default value: -380</i> maximum power spectral density allowed in upstream
[no] pbo-mode-up	Parameter type: boolean	<i>optional parameter</i> upstream power backoff mode ON
[no] max-recv-power-up	Parameter type: <Xdsl::RxPowerLevel> Format: - a received power level value - unit: 1/10 * dBm - range: [-255...255]	<i>optional parameter with default value: 255</i> the maximum receive power allowed in upstream
[no] psd-mask-up	Parameter type: <Xdsl::Adsl2PsdMaskUp> Format: (default adlu32-eu32 adlu36-eu36 adlu40-eu40 adlu44-eu44 adlu48-eu48 adlu52-eu52 adlu56-eu56 adlu60-eu60 adlu64-eu64) Possible values: - default : the default mask which is equivalent to adlu56-eu56 - adlu32-eu32 : mask eu-32 for annex-m and adlu-32 for annex-j - adlu36-eu36 : mask eu-36 for annex-m and adlu-36 for annex-j - adlu40-eu40 : mask eu-40 for annex-m and adlu-40 for annex-j - adlu44-eu44 : mask eu-44 for annex-m and adlu-44 for annex-j - adlu48-eu48 : mask eu-48 for annex-m and adlu-48 for annex-j	<i>optional parameter with default value: "default"</i> power spectral density mask in upstream

9 xDSL Configuration Commands

Parameter	Type	Description
	- adlu52-eu52 : mask eu-52 for annex-m and adlu-52 for annex-j - adlu56-eu56 : mask eu-56 for annex-m and adlu-56 for annex-j - adlu60-eu60 : mask eu-60 for annex-m and adlu-60 for annex-j - adlu64-eu64 : mask eu-64 for annex-m and adlu-64 for annex-j	

9.6 xDSL Spectrum Profile for RE-ADSL2 Configuration Command

Command Description

This command allows the operator to manage the Reach Extended ADSL2 specific part of the DSL spectrum profile. The spectrum profiles groups all parameters on DSL on physical level. These parameters are mainly related to the environmental conditions of the line (spectrum management).

The Spectrum Configuration profile contains parameters which have a common value for all DSL flavors (Common) and parameters which have a specific value depending on the DSL flavor used (ADSL1/2, READSL2, ADSL2Plus, VDSL).

This chapter contains the Reach Extended DSL2 flavor specific parameters.

Note: the activation of the profile has to be done via configure xdsl spectrum-profile.

User Level

The command can be accessed by operators with xdsl privileges, and executed by operators with xdsl privileges.

Command Syntax

The command has the following syntax:

```
> configure xdsl spectrum-profile (index) re-adsl [ [ no ] proprietary-feat ] [ no propr-feat-value | propr-feat-value
<Xdsl::ProprFeatValue> ] [ no max-agpowlev-down | max-agpowlev-down <Xdsl::PowerLevel> ] [ no
max-agpowlev-up | max-agpowlev-up <Xdsl::PowerLevel> ] [ no max-psd-down | max-psd-down
<Xdsl::ReAdsl2PowerSpectralDensityDown> ] [ no max-psd-up | max-psd-up
<Xdsl::ReAdsl2PowerSpectralDensityUp> ] [ [ no ] pbo-mode-up ] [ no max-recv-power-up | max-recv-power-up
<Xdsl::RxPowerLevel> ]
```

Command Parameters

Table 9.6-1 "xDSL Spectrum Profile for RE-ADSL2 Configuration Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - a profile index value - range: [1...256]	index of the profile.

Table 9.6-2 "xDSL Spectrum Profile for RE-ADSL2 Configuration Command" Command Parameters

Parameter	Type	Description
[no] proprietary-feat	Parameter type: boolean	<i>obsolete parameter that will be ignored</i> enable proprietary features of the modem

9 xDSL Configuration Commands

Parameter	Type	Description
[no] propr-feat-value	Parameter type: <Xdsl::ProprFeatValue> Format: - Proprietary feature - range: [0...4294967295]	<i>optional parameter with default value: 1</i> proprietary feature
[no] max-agpowlev-down	Parameter type: <Xdsl::PowerLevel> Format: - a power level value - unit: 1/10 * dBm - range: [0...255]	<i>optional parameter with default value: 255</i> maximum aggregate power allowed in downstream
[no] max-agpowlev-up	Parameter type: <Xdsl::PowerLevel> Format: - a power level value - unit: 1/10 * dBm - range: [0...255]	<i>optional parameter with default value: 255</i> maximum aggregate power allowed in upstream
[no] max-psd-down	Parameter type: <Xdsl::ReAdsl2PowerSpectralDensityDown> Format: - a power spectral density value - unit: 1/10 * dBm/Hz - range: [-600...-370]	<i>optional parameter with default value: -370</i> maximum power spectral density allowed in downstream
[no] max-psd-up	Parameter type: <Xdsl::ReAdsl2PowerSpectralDensityUp> Format: - a power spectral density value - unit: 1/10 * dBm/Hz - range: [-600...-329]	<i>optional parameter with default value: -329</i> maximum power spectral density allowed in upstream
[no] pbo-mode-up	Parameter type: boolean	<i>optional parameter</i> upstream power backoff mode ON
[no] max-recv-power-up	Parameter type: <Xdsl::RxPowerLevel> Format: - a received power level value - unit: 1/10 * dBm - range: [-255...255]	<i>optional parameter with default value: 255</i> the maximum receive power allowed in upstream

9.7 xDSL Spectrum Profile for ADSL2 Plus Configuration Command

Command Description

This command allows the operator to manage the ADSL2-plus specific part of the DSL spectrum profile. The spectrum profiles groups all parameters on DSL on physical level. These parameters are mainly related to the environmental conditions of the line (spectrum management).

The Spectrum Configuration profile contains parameters which have a common value for all DSL flavors (Common) and parameters which have a specific value depending on the DSL flavor used (ADSL1/2, READSL2, ADSL2Plus, VDSL).

This chapter contains the ADSL2-plus flavor specific parameters.

Note: the activation of the profile has to be done via configure xdsl spectrum-profile.

User Level

The command can be accessed by operators with xdsl privileges, and executed by operators with xdsl privileges.

Command Syntax

The command has the following syntax:

```
> configure xdsl spectrum-profile (index) adsl2-plus [ [ no ] proprietary-feat ] [ no propr-feat-value |
propr-feat-value <Xdsl::ProprFeatValue> ] [ no max-agpowlev-down | max-agpowlev-down <Xdsl::PowerLevel> ]
[ no max-agpowlev-up | max-agpowlev-up <Xdsl::PowerLevel> ] [ no max-psd-down | max-psd-down
<Xdsl::Adsl2PlusPowerSpectralDensityDown> ] [ no max-psd-up | max-psd-up
<Xdsl::Adsl2PlusPowerSpectralDensityUp> ] [ no psd-shape-down | psd-shape-down
<Xdsl::Adsl2PlusPsdShapeDown> ] [ [ no ] pbo-mode-up ] [ no max-recv-power-up | max-recv-power-up
<Xdsl::RxPowerLevel> ] [ no psd-mask-up | psd-mask-up <Xdsl::Adsl2PlusPsdMaskUp> ]
```

Command Parameters

Table 9.7-1 "xDSL Spectrum Profile for ADSL2 Plus Configuration Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - a profile index value - range: [1...256]	index of the profile.

Table 9.7-2 "xDSL Spectrum Profile for ADSL2 Plus Configuration Command" Command Parameters

Parameter	Type	Description
[no] proprietary-feat	Parameter type: boolean	obsolete parameter that will be ignored enable proprietary features of the

9 xDSL Configuration Commands

Parameter	Type	Description
		modem
[no] propr-feat-value	Parameter type: <Xdsl::ProprFeatValue> Format: - Proprietary feature - range: [0...4294967295]	<i>optional parameter with default value: 1</i> proprietary feature
[no] max-agpowlev-down	Parameter type: <Xdsl::PowerLevel> Format: - a power level value - unit: 1/10 * dBm - range: [0...255]	<i>optional parameter with default value: 255</i> maximum aggregate power allowed in downstream
[no] max-agpowlev-up	Parameter type: <Xdsl::PowerLevel> Format: - a power level value - unit: 1/10 * dBm - range: [0...255]	<i>optional parameter with default value: 255</i> maximum aggregate power allowed in upstream
[no] max-psd-down	Parameter type: <Xdsl::Adsl2PlusPowerSpectralDensityDown> Format: - a power spectral density value - unit: 1/10 * dBm/Hz - range: [-600...-400]	<i>optional parameter with default value: -400</i> maximum power spectral density allowed in downstream
[no] max-psd-up	Parameter type: <Xdsl::Adsl2PlusPowerSpectralDensityUp> Format: - a power spectral density value - unit: 1/10 * dBm/Hz - range: [-600...-380]	<i>optional parameter with default value: -380</i> maximum power spectral density allowed in upstream
[no] psd-shape-down	Parameter type: <Xdsl::Adsl2PlusPsdShapeDown> Format: (custom-psd-down std-psd-down ca100-psd-down ca110-psd-down ca120-psd-down ca130-psd-down ca140-psd-down ca150-psd-down ca160-psd-down ca170-psd-down ca180-psd-down ca190-psd-down ca200-psd-down ca210-psd-down ca220-psd-down ca230-psd-down ca240-psd-down ca250-psd-down ca260-psd-down ca270-psd-down ca280-psd-down cust-psd-down : <Xdsl::Adsl2PlusCustPsdShape>) Possible values: - cust-psd-down : custom psd shape in downstream in octet string format - custom-psd-down : custom psd shape in downstream - std-psd-down : standard psd mask downstream - ca100-psd-down : psd mask downstream with cut-off 100 - ca110-psd-down : psd mask downstream with cut-off 110	<i>optional parameter with default value: "std-psd-down"</i> power spectral density shape in downstream

Parameter	Type	Description
	- ca120-psd-down : psd mask downstream with cut-off 120 - ca130-psd-down : psd mask downstream with cut-off 130 - ca140-psd-down : psd mask downstream with cut-off 140 - ca150-psd-down : psd mask downstream with cut-off 150 - ca160-psd-down : psd mask downstream with cut-off 160 - ca170-psd-down : psd mask downstream with cut-off 170 - ca180-psd-down : psd mask downstream with cut-off 180 - ca190-psd-down : psd mask downstream with cut-off 190 - ca200-psd-down : psd mask downstream with cut-off 200 - ca210-psd-down : psd mask downstream with cut-off 210 - ca220-psd-down : psd mask downstream with cut-off 220 - ca230-psd-down : psd mask downstream with cut-off 230 - ca240-psd-down : psd mask downstream with cut-off 240 - ca250-psd-down : psd mask downstream with cut-off 250 - ca260-psd-down : psd mask downstream with cut-off 260 - ca270-psd-down : psd mask downstream with cut-off 270 - ca280-psd-down : psd mask downstream with cut-off 280 Field type <Xdsl::Adsl2PlusCustPsdShape> - an octet string defining custom psd shape - length: $x \leq 61$	
[no] pbo-mode-up	Parameter type: boolean	<i>optional parameter</i> upstream power backoff mode ON
[no] max-recv-power-up	Parameter type: <Xdsl::RxPowerLevel> Format: - a received power level value - unit: $1/10 * \text{dBm}$ - range: [-255...255]	<i>optional parameter with default value: 255</i> the maximum receive power allowed in upstream
[no] psd-mask-up	Parameter type: <Xdsl::Adsl2PlusPsdMaskUp> Format: (default adlu32-eu32 adlu36-eu36 adlu40-eu40 adlu44-eu44 adlu48-eu48 adlu52-eu52 adlu56-eu56 adlu60-eu60 adlu64-eu64) Possible values: - default : the default mask which is equivalent to adlu56-eu56 - adlu32-eu32 : mask eu-32 for annex-m and adlu-32 for annex-j - adlu36-eu36 : mask eu-36 for annex-m and adlu-36 for annex-j - adlu40-eu40 : mask eu-40 for annex-m and adlu-40 for annex-j - adlu44-eu44 : mask eu-44 for annex-m and adlu-44 for annex-j - adlu48-eu48 : mask eu-48 for annex-m and adlu-48 for annex-j - adlu52-eu52 : mask eu-52 for annex-m and adlu-52 for annex-j - adlu56-eu56 : mask eu-56 for annex-m and adlu-56 for annex-j	<i>optional parameter with default value: "default"</i> power spectral density mask in upstream

9 xDSL Configuration Commands

Parameter	Type	Description
	- adlu60-eu60 : mask eu-60 for annex-m and adlu-60 for annex-j - adlu64-eu64 : mask eu-64 for annex-m and adlu-64 for annex-j	

9.8 ADSL2-plus Custom PSD shape Configuration Command

Command Description

This command allows the operator to configure the ADSL2-plus custom psd shape in downstream direction.

It helps operator to enter the custom psd shape in a user-friendly way. Instead of entering octets the operator can enter numbers corresponding to frequency and psd.

When all break points are set to default values (frequency 0, psd 0), the psd shape is cleared. To clear the entire shape at once, set the first two breakpoints to default values. When any other breakpoint is set to default values, all points following it will also be set to the default values.

When defining a PSD shape, a minimum of 2 PSD points should be specified. The successive PSD points must have increasing ($\geq$) frequencies. It is allowed that for two successive PSD points, different PSD levels are defined at a same frequency (brickwall).

User Level

The command can be accessed by operators with xdsl privileges, and executed by operators with xdsl privileges.

Command Syntax

The command has the following syntax:

```
> configure xdsl spectrum-profile (index) adsl2-plus cust-psd-pt-down (psd-point) [ no frequency | frequency
<Xdsl::CustFrqAdsl2> ] [ no psd | psd <Xdsl::PsdLevel> ]
```

Command Parameters

Table 9.8-1 "ADSL2-plus Custom PSD shape Configuration Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - a profile index value - range: [1...256]	index of the profile.
(psd-point)	Format: - psd point - range: [1...20]	psd point

Table 9.8-2 "ADSL2-plus Custom PSD shape Configuration Command" Command Parameters

Parameter	Type	Description
[no] frequency	Parameter type: <Xdsl::CustFrqAdsl2> Format: - frequency - unit: khz - range: [0...2208]	optional parameter with default value: 0 psd frequency
[no] psd	Parameter type: <Xdsl::PsdLevel>	optional parameter with default

9 xDSL Configuration Commands

Parameter	Type	Description
	Format: - psd level - unit: -0.5 * (PSD level in dBm/Hz) - range: [0...255]	<i>value: 0</i> psd level

9.9 xDSL Spectrum Profile for VDSL Configuration Command

Command Description

This command allows the operator to manage the VDSL specific part of the DSL spectrum profile. The spectrum profiles groups all parameters on DSL on physical level. These parameters are mainly related to the environmental conditions of the line (spectrum management).

The Spectrum Configuration profile contains parameters which have a common value for all DSL flavors (Common) and parameters which have a specific value depending on the DSL flavor used (ADSL1/2, READSL2, ADSL2Plus, VDSL).

This chapter contains the VDSL flavor specific parameters.

Note: the activation of the profile has to be done via `configure xdsl spectrum-profile`. The configured `cust-psd-sc-down/cust-psd-ty-down`, `cust-rx-psd-sc-up/ cust-rx-psd-ty-up` are ignored by the system after activation of the profile if no corresponding breakpoints are configured before the activation.

User Level

The command can be accessed by operators with `xdsl` privileges, and executed by operators with `xdsl` privileges.

Command Syntax

The command has the following syntax:

```
> configure xdsl spectrum-profile (index) vdsl [ [ no ] proprietary-feat ] [ no propr-feat-value | propr-feat-value
<Xdsl::ProprFeatValue> ] [ no vdsl-band-plan | vdsl-band-plan <Xdsl::VdslBandPlan> ] [ no optional-band |
optional-band <Xdsl::OptionalBandUsage> ] [ no optional-endfreq | optional-endfreq
<Xdsl::OptionalBandEndFreq> ] [ no adsl-band | adsl-band <Xdsl::AdslBandUsage> ] [ no max-agpowlev-down |
max-agpowlev-down <Xdsl::VdslPowerLevel> ] [ no max-agpowlev-up | max-agpowlev-up
<Xdsl::VdslPowerLevel> ] [ no psd-shape-down | psd-shape-down <Xdsl::VdslPsdShapeDown> ] [ no
psd-shape-up | psd-shape-up <Xdsl::VdslPsdShapeUp> ] [ [ no ] pbo-mode-down ] [ no pbo-mode | pbo-mode
<Xdsl::PboModeVdsl> ] [ no rx-psd-shape-up | rx-psd-shape-up <Xdsl::RxVdslPsdShapeUp> ] [ no
ghstones-pwr-mode | ghstones-pwr-mode <Xdsl::GhsTonesTxPwr> ] [ no max-band | max-band
<Xdsl::VdslMaxBandNum> ] [ no max-freq | max-freq <Xdsl::VdslMaxFrequency> ] [ no m-psd-level-down |
m-psd-level-down <Xdsl::MaxPsdDown> ] [ no m-psd-level-up | m-psd-level-up <Xdsl::MaxPsdUp> ] [ no
psd-pbo-par-a-up | psd-pbo-par-a-up <Xdsl::ABParamType> ] [ no psd-pbo-par-b-up | psd-pbo-par-b-up
<Xdsl::ABParamType> ] [ no cust-psd-sc-down | cust-psd-sc-down <Xdsl::PsdScaleBit> ] [ no cust-psd-ty-down |
cust-psd-ty-down <Xdsl::PsdTypeBit> ] [ no cust-rx-psd-sc-up | cust-rx-psd-sc-up <Xdsl::PsdScaleBit> ] [ no
cust-rx-psd-ty-up | cust-rx-psd-ty-up <Xdsl::PsdTypeBit> ] [ no opt-startfreq | opt-startfreq
<Xdsl::OptionalBandStartFreq> ]
```

Command Parameters

Table 9.9-1 "xDSL Spectrum Profile for VDSL Configuration Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - a profile index value - range: [1...256]	index of the profile.

Table 9.9-2 "xDSL Spectrum Profile for VDSL Configuration Command" Command Parameters

Parameter	Type	Description
[no] proprietary-feat	Parameter type: boolean	<i>obsolete parameter that will be ignored</i> enable proprietary features of the modem
[no] propr-feat-value	Parameter type: <Xdsl::ProprFeatValue> Format: - Proprietary feature - range: [0...4294967295]	<i>optional parameter with default value: 1</i> proprietary feature
[no] vdsl-band-plan	Parameter type: <Xdsl::VdslBandPlan> Format: (band-plan-a4 band-plan-a3 band-plan-a2 band-plan-b4 band-plan-b3 band-plan-b2 band-plan-c4 band-plan-c3 band-plan-c2 annex-a annex-b-998e annex-b-997e annex-b-998ade b998ade17ds35 b998e17ds35 a998ds35 annex-b-hpe annex-c) Possible values: - band-plan-a4 : 4 bands of frequency 998 (ITU-T) - band-plan-a3 : 3 bands of frequency 998 - band-plan-a2 : 2 bands of frequency 998 - band-plan-b4 : 4 bands of frequency 997 (ITU-T) - band-plan-b3 : 3 bands of frequency 997 - band-plan-b2 : 2 bands of frequency 997 - band-plan-c4 : 4 bands of specified frequency - band-plan-c3 : 3 bands of specified frequency - band-plan-c2 : 2 bands of specified frequency - annex-a : ITU-T G.993.2 VDSL2 Annex A (extended) band plan - annex-b-998e : ITU-T G.993.2 VDSL2 Annex B band plan type 998E17 - annex-b-997e : ITU-T G.993.2 VDSL2 Annex B band plan type 997E17 - annex-b-998ade : ITU-T G.993.2 VDSL2 Annex B band plan type 998ADE17 - b998ade17ds35 : ITU-T G.993.2 VDSL2 Annex B band plan type 998ADE35 - b998e17ds35 : ITU-T G.993.2 VDSL2 Annex B band plan type 998E35 - a998ds35 : ITU-T G.993.2 VDSL2 Annex A band plan	<i>optional parameter with default value: "band-plan-a4"</i> the VDSL band plan

Parameter	Type	Description
	type 998ds35 - annex-b-hpe : ITU-T G.993.2 VDSL2 Annex B band plan type HPE - annex-c : ITU-T G.993.2 VDSL2 Annex C band plan	
[no] optional-band	Parameter type: <Xdsl::OptionalBandUsage> Format: (off up down) Possible values: - off : usage of optional band is not allowed - up : optional band can be used for upstream - down : optional band can be used for downstream	<i>optional parameter with default value: "off"</i> optional band Usage
[no] optional-endfreq	Parameter type: <Xdsl::OptionalBandEndFreq> Format: - an end frequency of the VDSL optional band - unit: KHz - range: [0,138...552]	<i>optional parameter with default value: 0</i> optional band end frequency
[no] adsl-band	Parameter type: <Xdsl::AdslBandUsage> Format: (allow-adsl excl-adsl excl-adsl2plus excl-adsl-upto : <Xdsl::AdslBandEndFreq>) Possible values: - allow-adsl : usage of adsl spectrum is allowed - excl-adsl : usage of adsl spectrum is not allowed - excl-adsl2plus : usage of adsl2plus spectrum is not allowed - excl-adsl-upto : usage of adsl spectrum with end frequency Field type <Xdsl::AdslBandEndFreq> - end frequency of the ADSL band - unit: KHz - range: [276...2208]	<i>optional parameter with default value: "excl-adsl"</i> adsl band Usage
[no] max-agpowlev-down	Parameter type: <Xdsl::VdslPowerLevel> Format: - a power level value - unit: 1/10 * dBm - range: [-310...255]	<i>optional parameter with default value: 255</i> max power allowed on the line in downstream
[no] max-agpowlev-up	Parameter type: <Xdsl::VdslPowerLevel> Format: - a power level value - unit: 1/10 * dBm - range: [-310...255]	<i>optional parameter with default value: 255</i> max power allowed on the line in upstream
[no] psd-shape-down	Parameter type: <Xdsl::VdslPsdShapeDown> Format: (custom-psd-down ansi-fft-ex-m1 ansi-fft-ex-m2 ansi-fft-cab-m1 ansi-fft-cab-m2 etsi-p-ex-p1-m1 etsi-p-ex-p1-m2 etsi-p-ex-p2-m1 etsi-p-ex-p2-m2 etsi-p-cab-m1 etsi-p-cab-m2 ansi-fft-m1-adsl	<i>optional parameter with default value: "etsi-p-cab-m1"</i> power spectral density shape in downstream

9 xDSL Configuration Commands

Parameter	Type	Description
	ansi-fft-m2-adsl ansi-fft-m1-adsl-2plus ansi-fft-m2-adsl-2plus etsi-p-x-m1-adsl etsi-p-x-m2-adsl etsi-p-m1-adsl-2plus etsi-p-m2-adsl-2plus cust-psd-down : <Xdsl::VdslCustPsdShapeDwnStream>) Possible values: - cust-psd-down : custom psd shape in downstream in octet string format - custom-psd-down : custom psd shape in downstream - ansi-fft-ex-m1 : ANSI standard spectral density in downstream - ansi-fft-ex-m2 : ANSI standard spectral density in downstream - ansi-fft-cab-m1 : ANSI standard spectral density in downstream - ansi-fft-cab-m2 : ANSI standard spectral density in downstream - etsi-p-ex-p1-m1 : ETSI standard spectral density in downstream - etsi-p-ex-p1-m2 : ETSI standard spectral density in downstream - etsi-p-ex-p2-m1 : ETSI standard spectral density in downstream - etsi-p-ex-p2-m2 : ETSI standard spectral density in downstream - etsi-p-cab-m1 : ETSI standard spectral density in downstream - etsi-p-cab-m2 : ETSI standard spectral density in downstream - ansi-fft-m1-adsl : ANSI standard spectral density in downstream - ansi-fft-m2-adsl : ANSI standard spectral density in downstream - ansi-fft-m1-adsl-2plus: ANSI standard spectral density in downstream - ansi-fft-m2-adsl-2plus: ANSI standard spectral density in downstream - etsi-p-x-m1-adsl : ETSI standard spectral density in downstream - etsi-p-x-m2-adsl : ETSI standard spectral density in downstream - etsi-p-m1-adsl-2plus : ETSI standard spectral density in downstream - etsi-p-m2-adsl-2plus : ETSI standard spectral density in downstream Field type <Xdsl::VdslCustPsdShapeDwnStream> - an octet string defining custom psd shape - length: x<=97	
[no] psd-shape-up	Parameter type: <Xdsl::VdslPsdShapeUp> Format: (ansi-fft-ex-m1 ansi-fft-ex-m2 ansi-fft-cab-m1 ansi-fft-cab-m2	<i>optional parameter with default value: "etsi-p-m1"</i> power spectral density shape in upstream

Parameter	Type	Description
	etsi-p-m1 etsi-p-m2) Possible values: - ansi-fft-ex-m1 : ANSI standard spectral density in upstream - ansi-fft-ex-m2 : ANSI standard spectral density in upstream - ansi-fft-cab-m1 : ANSI standard spectral density in upstream - ansi-fft-cab-m2 : ANSI standard spectral density in upstream - etsi-p-m1 : ETSI standard spectral density in upstream - etsi-p-m2 : ETSI standard spectral density in upstream	
[no] pbo-mode-down	Parameter type: boolean	<i>obsolete parameter replaced by parameter "pbo-mode"</i> upstream power backoff mode OFF
[no] pbo-mode	Parameter type: <Xdsl::PboModeVdsl> Format: (pbo-mode-down pbo-mode-up pbo-up-pol-sd pbo-up-pol-us0 pbo-up-pol-pass) Possible values: - pbo-mode-down : upstream power backoff mode OFF - pbo-mode-up : upstream power backoff mode ON - pbo-up-pol-sd : pbo mode ON policing shutdown - pbo-up-pol-us0 : pbo mode ON policing US0 only - pbo-up-pol-pass : pbo mode ON policing passive	<i>optional parameter with default value: "pbo-mode-up"</i> upstream power backoff mode
[no] rx-psd-shape-up	Parameter type: <Xdsl::RxVdslPsdShapeUp> Format: (custom-rx-psd-up ansi-a ansi-f ansi-custom-ex ansi-custom-cab etsi-a etsi-b etsi-c etsi-d etsi-e etsi-f etsi-custom-ex etsi-custom-cab ab-param cust-rx-psd-up : <Xdsl::VdslCustPsdShape>) Possible values: - cust-rx-psd-up : custom receive psd in upstream in octet string format - custom-rx-psd-up : custom receive psd in upstream - ansi-a : ansi standard spectral density shape in upstream - ansi-f : ansi standard spectral density shape in upstream - ansi-custom-ex : ansi custom spectral density shape in upstream - ansi-custom-cab : ansi custom spectral density shape in upstream	<i>optional parameter with default value: "etsi-a"</i> the reference RX PSD shape for upstream

9 xDSL Configuration Commands

Parameter	Type	Description
	- etsi-a : etsi standard spectral density shape in upstream - etsi-b : etsi standard spectral density shape in upstream - etsi-c : etsi standard spectral density shape in upstream - etsi-d : etsi standard spectral density shape in upstream - etsi-e : etsi standard spectral density shape in upstream - etsi-f : etsi standard spectral density shape in upstream - etsi-custom-ex : etsi custom spectral density shape in upstream - etsi-custom-cab : etsi custom standard spectral density shape in upstream - ab-param : ABParameter spectral density shape in upstream Field type <Xdsl::VdslCustPsdShape> - an octet string defining custom psd shape - length: x<=61	
[no] ghstones-pwr-mode	Parameter type: <Xdsl::GhsTonesTxPwr> Format: (standard auto per-tone-set) Possible values: - standard : the max power as per G994.1 standard definition - auto : the max Tx power level is derived from psd-shape-down - per-tone-set : choose from the tone sets	<i>optional parameter with default value: "standard"</i> the Tx power control of the G.hs tones
[no] max-band	Parameter type: <Xdsl::VdslMaxBandNum> Format: (unrestricted <Xdsl::VdslMaxBandNum>) Possible values: - unrestricted : unrestricted bands Field type <Xdsl::VdslMaxBandNum> - number of upstream and downstream bands - range: [0,2...8]	<i>optional parameter with default value: "unrestricted"</i> max number of bands to be used from specified band plan
[no] max-freq	Parameter type: <Xdsl::VdslMaxFrequency> Format: (ulimited <Xdsl::VdslMaxFrequency>) Possible values: - ulimited : unlimited frequency Field type <Xdsl::VdslMaxFrequency> - maximum frequency that can be used during showtime - unit: KHz - range: [1104...35324]	<i>optional parameter with default value: "ulimited"</i> max frequency that can be used during showtime
[no] m-psd-level-down	Parameter type: <Xdsl::MaxPsdDown> Format: (no-constraint <Xdsl::MaxPsdLevelType>) Possible values: - no-constraint : no constraint on psd level Field type <Xdsl::MaxPsdLevelType> - Max psd level - unit: 1/10 * dBm/Hz - range: [-955...0]	<i>optional parameter with default value: "no-constraint"</i> max PSD level for downstream
[no] m-psd-level-up	Parameter type: <Xdsl::MaxPsdUp> Format: (no-constraint	<i>optional parameter with default value: "no-constraint"</i> max PSD level for upstream

Parameter	Type	Description
	<Xdsl::MaxPsdLevelType>) Possible values: - no-constraint : no constraint on psd level Field type <Xdsl::MaxPsdLevelType> - Max psd level - unit: 1/10 * dBm/Hz - range: [-955...0]	
[no] psd-pbo-par-a-up	Parameter type: <Xdsl::ABParamType> Format: - binary string - length: 10	<i>optional parameter with default value: "0f : a0 : 12 : 7a : 15 : 18 : 15 : 18 : 15 : 18"</i> parmtr A val for each band to compute PSD ref for US PBO
[no] psd-pbo-par-b-up	Parameter type: <Xdsl::ABParamType> Format: - binary string - length: 10	<i>optional parameter with default value: "00 : 00 : 07 : b9 : 06 : 29 : 04 : 35 : 03 : af"</i> parmtr B val for each band to compute PSD ref for US PBO
[no] cust-psd-sc-down	Parameter type: <Xdsl::PsdScaleBit> Format: (linear logarithmic) Possible values: - linear : linear scale - logarithmic : logarithmic scale	<i>optional parameter with default value: "linear"</i> psd scale
[no] cust-psd-ty-down	Parameter type: <Xdsl::PsdTypeBit> Format: (mask template) Possible values: - mask : PSD mask - template : PSD template	<i>optional parameter with default value: "mask"</i> psd type
[no] cust-rx-psd-sc-up	Parameter type: <Xdsl::PsdScaleBit> Format: (linear logarithmic) Possible values: - linear : linear scale - logarithmic : logarithmic scale	<i>optional parameter with default value: "linear"</i> psd scale
[no] cust-rx-psd-ty-up	Parameter type: <Xdsl::PsdTypeBit> Format: (mask template) Possible values: - mask : PSD mask - template : PSD template	<i>optional parameter with default value: "mask"</i> psd type
[no] opt-startfreq	Parameter type: <Xdsl::OptionalBandStartFreq> Format: - a start frequency of the VDSL optional band - unit: KHz - range: [0...138]	<i>optional parameter with default value: 0</i> optional band start frequency

9.10 VDSL Ghs Tones Transmission Power Control Configuration Command

Command Description

This command allows the operator to configure transmission power of the G.hs tones in VDSL environment. G.hs is intended to be a robust mechanism for activating a multiplicity of xDSL. Activation of regional standards or legacy devices can be handled by implicit (escape) or explicit (non-standard facilities) mechanisms.

The parameters defined are used for control of the transmission power. There are various tone sets defined for the control of the transmission power, viz., A43, B43, A43C and V43. The power of each tone of the set shall be equivalent to the given PSD value integrated in a total bandwidth of 4.3125 kHz

User Level

The command can be accessed by operators with xdsl privileges, and executed by operators with xdsl privileges.

Command Syntax

The command has the following syntax:

```
> configure xdsl spectrum-profile (index) vdsl ghstone-set-pwr-ctrl [ no a43 | a43 <Xdsl::GhsTonesTxPwrCtrl> ] [
no b43 | b43 <Xdsl::GhsTonesTxPwrCtrl> ] [ no a43c | a43c <Xdsl::GhsTonesTxPwrCtrl> ] [ no v43 | v43
<Xdsl::GhsTonesTxPwrCtrl> ]
```

Command Parameters

Table 9.10-1 "VDSL Ghs Tones Transmission Power Control Configuration Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - a profile index value - range: [1...256]	index of the profile.

Table 9.10-2 "VDSL Ghs Tones Transmission Power Control Configuration Command" Command Parameters

Parameter	Type	Description
[no] a43	Parameter type: <Xdsl::GhsTonesTxPwrCtrl> Format: (standard auto manual : <Xdsl::GhsTonesTxPwrLvl>) Possible values: - standard : the max power as per G994.1 standard definition - auto : the max Tx power level is derived from psd-shape-down - manual : custom max Tx power level	<i>optional parameter with default value: "standard"</i> power control of the ghstones for tones set a43

Parameter	Type	Description
	Field type <Xdsl::GhsTonesTxPwrLvl> - power of each DS tone - unit: 1/2 * dBm/Hz - range: [-198...-80]	
[no] b43	Parameter type: <Xdsl::GhsTonesTxPwrCtrl> Format: (standard auto manual : <Xdsl::GhsTonesTxPwrLvl>) Possible values: - standard : the max power as per G994.1 standard definition - auto : the max Tx power level is derived from psd-shape-down - manual : custom max Tx power level Field type <Xdsl::GhsTonesTxPwrLvl> - power of each DS tone - unit: 1/2 * dBm/Hz - range: [-198...-80]	<i>optional parameter with default value: "standard"</i> power control of the ghs tones for tones set b43
[no] a43c	Parameter type: <Xdsl::GhsTonesTxPwrCtrl> Format: (standard auto manual : <Xdsl::GhsTonesTxPwrLvl>) Possible values: - standard : the max power as per G994.1 standard definition - auto : the max Tx power level is derived from psd-shape-down - manual : custom max Tx power level Field type <Xdsl::GhsTonesTxPwrLvl> - power of each DS tone - unit: 1/2 * dBm/Hz - range: [-198...-80]	<i>optional parameter with default value: "standard"</i> power control of the ghs tones for tones set a43c
[no] v43	Parameter type: <Xdsl::GhsTonesTxPwrCtrl> Format: (standard auto manual : <Xdsl::GhsTonesTxPwrLvl>) Possible values: - standard : the max power as per G994.1 standard definition - auto : the max Tx power level is derived from psd-shape-down - manual : custom max Tx power level Field type <Xdsl::GhsTonesTxPwrLvl> - power of each DS tone - unit: 1/2 * dBm/Hz - range: [-198...-80]	<i>optional parameter with default value: "standard"</i> power control of the ghs tones for tones set v43

9.11 VDSL Custom PSD shape Downstream Configuration Command

Command Description

This command allows the operator to configure the VDSL custom psd shape in downstream direction.

It helps operator to enter the custom psd shape in a user-friendly way. Instead of entering octets the operator can enter numbers corresponding to frequency and psd.

When all break points are set to default values (frequency 0, psd 0), the psd shape is cleared. To clear the entire shape at once, set the first two breakpoints to default values. Using this method, the frequency scale and the psd shape type will also be reset to the default value. When any other breakpoint is set to default values, all points following it will also be set to the default values.

When defining a PSD shape, a minimum of 2 PSD points should be specified. The successive PSD points must have increasing ($>/=$) frequencies. It is allowed that for two successive PSD points, different PSD levels are defined at a same frequency (brickwall).

User Level

The command can be accessed by operators with xdsl privileges, and executed by operators with xdsl privileges.

Command Syntax

The command has the following syntax:

```
> configure xdsl spectrum-profile (index) vdsl cust-psd-pt-down (psd-point) [ no frequency | frequency
<Xdsl::CustFreq> ] [ no psd | psd <Xdsl::PsdLevel> ]
```

Command Parameters

Table 9.11-1 "VDSL Custom PSD shape Downstream Configuration Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - a profile index value - range: [1...256]	index of the profile.
(psd-point)	Format: - psd point - range: [1...32]	psd point

Table 9.11-2 "VDSL Custom PSD shape Downstream Configuration Command" Command Parameters

Parameter	Type	Description
[no] frequency	Parameter type: <Xdsl::CustFreq> Format: - frequency	optional parameter with default value: 0 psd frequency

Parameter	Type	Description
	- unit: khz - range: [0...35324]	
[no] psd	Parameter type: <Xdsl::PsdLevel> Format: - psd level - unit: -0.5 * (PSD level in dBm/Hz) - range: [0...255]	<i>optional parameter with default value: 0</i> psd level

9.12 VDSL Custom RX PSD shape Upstream Configuration Command

Command Description

This command allows the operator to configure the VDSL custom rx-psd shape in upstream direction.

It helps operator to enter the custom psd shape in a user-friendly way. Instead of entering octets the operator can enter numbers corresponding to frequency and psd.

When all break points are set to default values (frequency 0, psd 0), the psd shape is cleared. To clear the entire shape at once, set the first two breakpoints to default values. Using this method, the frequency scale and the psd shape type will also be reset to the default value. When any other breakpoint is set to default values, all points following it will also be set to the default values.

When defining a PSD shape, a minimum of 2 PSD points should be specified. The successive PSD points must have increasing ($>/=$) frequencies. It is allowed that for two successive PSD points, different PSD levels are defined at a same frequency (brickwall).

User Level

The command can be accessed by operators with xdsl privileges, and executed by operators with xdsl privileges.

Command Syntax

The command has the following syntax:

```
> configure xdsl spectrum-profile (index) vdsl cust-rx-psd-pt-up (psd-point) [ no frequency | frequency
<Xdsl::CustFreq> ] [ no psd | psd <Xdsl::PsdLevel> ]
```

Command Parameters

Table 9.12-1 "VDSL Custom RX PSD shape Upstream Configuration Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - a profile index value - range: [1...256]	index of the profile.
(psd-point)	Format: - psd point - range: [1...20]	psd point

Table 9.12-2 "VDSL Custom RX PSD shape Upstream Configuration Command" Command Parameters

Parameter	Type	Description
[no] frequency	Parameter type: <Xdsl::CustFreq> Format: - frequency	optional parameter with default value: 0 psd frequency

Parameter	Type	Description
	- unit: khz - range: [0...35324]	
[no] psd	Parameter type: <Xdsl::PsdLevel> Format: - psd level - unit: -0.5 * (PSD level in dBm/Hz) - range: [0...255]	<i>optional parameter with default value: 0</i> psd level

9.13 VDSL Power Back Off Configuration Command

Command Description

This command can be used to specify the power back off parameters for each upstream band.

Parameter A and B can be used for computing the PSD reference for US PBO for each band (including optional band). The range of parameter A for each band is 40..80.95 dBm/Hz in steps of 0.01 dBm/Hz. And the range of parameter B is 0..40.95 dBm/Hz in steps of 0.01 dBm/Hz.

User Level

The command can be accessed by operators with xdsl privileges, and executed by operators with xdsl privileges.

Command Syntax

The command has the following syntax:

```
> configure xdsl spectrum-profile (index) vdsl pbo (band) [ param-a <Xdsl::PboParamA> ] [ param-b <Xdsl::PboParamB> ]
```

Command Parameters

Table 9.13-1 "VDSL Power Back Off Configuration Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - a profile index value - range: [1...256]	index of the profile.
(band)	Format: - equal fext band - range: [1...5]	band index

Table 9.13-2 "VDSL Power Back Off Configuration Command" Command Parameters

Parameter	Type	Description
param-a	Parameter type: <Xdsl::PboParamA> Format: - pbo param A - unit: 0.01 dBm/Hz - range: [4000...8095]	<i>optional parameter</i> parameter A value
param-b	Parameter type: <Xdsl::PboParamB> Format: - pbo param B - unit: 0.01 dBm/Hz - range: [0...4095]	<i>optional parameter</i> parameter B value

9.14 xDSL Spectrum Profile for VDSL2

Configuration Command

Command Description

This command allows the operator to manage the VDSL2 specific part of the DSL spectrum profile. The spectrum profiles groups all parameters on DSL on physical level. These parameters are mainly related to the environmental conditions of the line (spectrum management).

The Spectrum Configuration profile contains parameters which have a common value for all DSL flavors (Common) and parameters which have a specific value depending on the DSL flavor used (ADSL1/2, READSL2, ADSL2Plus, VDSL, VDSL2).

This chapter contains the VDSL2 flavor specific parameters.

Note: the activation of the profile has to be done via `configure xdsl spectrum-profile`. The configured `cust-psd-sc-down/cust-psd-ty-down`, `cust-psd-sc-up/cust-psd-ty-up`, `cust-rx-psd-sc-up/cust-rx-psd-ty-up` are ignored by the system after activation of the profile if no corresponding breakpoints are configured before the activation.

User Level

The command can be accessed by operators with `xdsl` privileges, and executed by operators with `xdsl` privileges.

Command Syntax

The command has the following syntax:

```
> configure xdsl spectrum-profile (index) vdsl2 [ [ no ] proprietary-feat ] [ no propr-feat-value | propr-feat-value
<Xdsl::ProprFeatValue> ] [ no max-agpowlev-down | max-agpowlev-down <Xdsl::VdslPowerLevel> ] [ no
max-agpowlev-up | max-agpowlev-up <Xdsl::VdslPowerLevel> ] [ no psd-shape-down | psd-shape-down
<Xdsl::Vdsl2PsdShapeDown> ] [ no cs-psd-shape-dn | cs-psd-shape-dn <Xdsl::VdslCustPsdShapeDownStream> ] [
no cs-psd-shape-up | cs-psd-shape-up <Xdsl::Vdsl2CustPsdShape> ] [ no psd-shape-up | psd-shape-up
<Xdsl::Vdsl2PsdShapeUp> ] [ no rx-psd-shape-up | rx-psd-shape-up <Xdsl::RxVdsl2PsdShapeUp> ] [ no
psd-pbo-e-len-up | psd-pbo-e-len-up <Xdsl::PsdPboElectrLength> ] [ no m-psd-level-down | m-psd-level-down
<Xdsl::MaxPsdDown> ] [ no m-psd-level-up | m-psd-level-up <Xdsl::MaxPsdUp> ] [ no psd-pbo-par-a-up |
psd-pbo-par-a-up <Xdsl::ABParamType> ] [ no psd-pbo-par-b-up | psd-pbo-par-b-up <Xdsl::ABParamType> ] [ no
v-noise-snr-down | v-noise-snr-down <Xdsl::SnrmMode> ] [ no v-noise-snr-up | v-noise-snr-up
<Xdsl::SnrmModeUp> ] [ no v-noise-psd-down | v-noise-psd-down <Xdsl::VirtualNoisePsdDownType> ] [ no
v-noise-psd-up | v-noise-psd-up <Xdsl::VirtualNoisePsdUpType> ] [ no cust-psd-sc-down | cust-psd-sc-down
<Xdsl::PsdScaleBit> ] [ no cust-psd-ty-down | cust-psd-ty-down <Xdsl::PsdTypeBit> ] [ no cust-psd-sc-up |
cust-psd-sc-up <Xdsl::PsdScaleBit> ] [ no cust-psd-ty-up | cust-psd-ty-up <Xdsl::PsdTypeBit> ] [ no
cust-rx-psd-sc-up | cust-rx-psd-sc-up <Xdsl::PsdScaleBit> ] [ no cust-rx-psd-ty-up | cust-rx-psd-ty-up
<Xdsl::PsdTypeBit> ] [ no upbo-aele-mode | upbo-aele-mode <Xdsl::UpboAeleMode> ] [ no upboaele-min-thrs |
upboaele-min-thrs <Xdsl::UpboAeleMinThresh> ] [ [ no ] short-loop-lr ] [ [ no ] medium-loop-lr ] [ [ no ]
long-loop-lr ]
```

Command Parameters

Table 9.14-1 "xDSL Spectrum Profile for VDSL2 Configuration Command" Resource Parameters

9 xDSL Configuration Commands

Resource Identifier	Type	Description
(index)	Format: - a profile index value - range: [1...256]	index of the profile.

Table 9.14-2 "xDSL Spectrum Profile for VDSL2 Configuration Command" Command Parameters

Parameter	Type	Description
[no] proprietary-feat	Parameter type: boolean	<i>obsolete parameter that will be ignored</i> enable proprietary features of the modem
[no] propr-feat-value	Parameter type: <Xdsl::ProprFeatValue> Format: - Proprietary feature - range: [0...4294967295]	<i>optional parameter with default value: 1</i> proprietary feature
[no] max-agpowlev-down	Parameter type: <Xdsl::VdslPowerLevel> Format: - a power level value - unit: 1/10 * dBm - range: [-310...255]	<i>optional parameter with default value: 255</i> maximum power allowed on the line in downstream
[no] max-agpowlev-up	Parameter type: <Xdsl::VdslPowerLevel> Format: - a power level value - unit: 1/10 * dBm - range: [-310...255]	<i>optional parameter with default value: 255</i> maximum power allowed on the line in upstream
[no] psd-shape-down	Parameter type: <Xdsl::Vdsl2PsdShapeDown> Format: (cust-psd-down regiona-psd-down regionbm1-psd-down regionbm2-psd-down regionc-psd-down custom-psd-down : <Xdsl::VdslCustPsdShapeDwnStream>) Possible values: - custom-psd-down : custom psd shape in downstream in octet string format - cust-psd-down : custom psd shape in downstream - regiona-psd-down : Region A spectral density in downstream - regionbm1-psd-down : Region BM1 spectral density in downstream - regionbm2-psd-down : Region BM2 spectral density in downstream - regionc-psd-down : RegionC spectral density in downstream Field type <Xdsl::VdslCustPsdShapeDwnStream> - an octet string defining custom psd shape - length: x<=97	<i>optional parameter with default value: "regionbm1-psd-down"</i> power spectral density shape in downstream
[no] cs-psd-shape-dn	Parameter type: <Xdsl::VdslCustPsdShapeDwnStream> Format: - an octet string defining custom psd shape - length: x<=97	<i>optional parameter with default value: ""</i> (deprecated)power spectral density shape in downstream
[no] cs-psd-shape-up	Parameter type: <Xdsl::Vdsl2CustPsdShape> Format: - an octet string defining custom psd shape - length: x<=61	<i>optional parameter with default value: ""</i> (deprecated)power spectral density shape in upstream
[no] psd-shape-up	Parameter type: <Xdsl::Vdsl2PsdShapeUp>	<i>optional parameter with default</i>

Parameter	Type	Description
	Format: (regiona-psd-up regionbm1-psd-up regionbm2-psd-up regionc-psd-up custom-psd-up) Possible values: - custom-psd-up : custom psd shape in upstream - regiona-psd-up : Region A spectral density in upstream - regionbm1-psd-up : Region BM1 spectral density in upstream - regionbm2-psd-up : Region BM2 spectral density in upstream - regionc-psd-up : RegionC spectral density in upstream	<i>value: "regionbm1-psd-up"</i> power spectral density shape in upstream
[no] rx-psd-shape-up	Parameter type: <Xdsl::RxVdsl2PsdShapeUp> Format: (custom-rx-psd-up ansi-a ansi-f ansi-custom-ex ansi-custom-cab etsi-a etsi-b etsi-c etsi-d etsi-e etsi-f etsi-custom-ex etsi-custom-cab ab-param equal-fext cust-rx-psd-up : <Xdsl::VdslCustPsdShape>) Possible values: - cust-rx-psd-up : custom receive psd in upstream - custom-rx-psd-up : custom receive psd in upstream - ansi-a : ansi standard spectral density shape in upstream - ansi-f : ansi standard spectral density shape in upstream - ansi-custom-ex : ansi custom spectral density shape in upstream - ansi-custom-cab : ansi custom spectral density shape in upstream - etsi-a : etsi standard spectral density shape in upstream - etsi-b : etsi standard spectral density shape in upstream - etsi-c : etsi standard spectral density shape in upstream - etsi-d : etsi standard spectral density shape in upstream - etsi-e : etsi standard spectral density shape in upstream - etsi-f : etsi standard spectral density shape in upstream - etsi-custom-ex : etsi custom spectral density shape in upstream - etsi-custom-cab : etsi custom standard spectral density shape in upstream - ab-param : ABParameter spectral density shape in upstream - equal-fext : equal fext in upstream Field type <Xdsl::VdslCustPsdShape> - an octet string defining custom psd shape - length: x<=61	<i>optional parameter with default value: "etsi-a"</i> the reference RX PSD shape for upstream

9 xDSL Configuration Commands

Parameter	Type	Description
[no] psd-pbo-e-len-up	Parameter type: <Xdsl::PsdPboElectrLength> Format: (estimated <Xdsl::PsdPboLength>) Possible values: - estimated : estimated electrical length Field type <Xdsl::PsdPboLength> - electrical parameter AB range - unit: 1/2 * dB - range: [0...255]	<i>optional parameter with default value: "estimated"</i> the electrical length to be used with the AB parameters
[no] m-psd-level-down	Parameter type: <Xdsl::MaxPsdDown> Format: (no-constraint <Xdsl::MaxPsdLevelType>) Possible values: - no-constraint : no constraint on psd level Field type <Xdsl::MaxPsdLevelType> - Max psd level - unit: 1/10 * dBm/Hz - range: [-955...0]	<i>optional parameter with default value: "no-constraint"</i> maximum PSD level for downstream
[no] m-psd-level-up	Parameter type: <Xdsl::MaxPsdUp> Format: (no-constraint <Xdsl::MaxPsdLevelType>) Possible values: - no-constraint : no constraint on psd level Field type <Xdsl::MaxPsdLevelType> - Max psd level - unit: 1/10 * dBm/Hz - range: [-955...0]	<i>optional parameter with default value: "no-constraint"</i> maximum PSD level for upstream
[no] psd-pbo-par-a-up	Parameter type: <Xdsl::ABParamType> Format: - binary string - length: 10	<i>optional parameter with default value: "0f : a0 : 12 : 7a : 15 : 18 : 15 : 18 : 15 : 18"</i> par A value for computing the PSD reference for US PBO
[no] psd-pbo-par-b-up	Parameter type: <Xdsl::ABParamType> Format: - binary string - length: 10	<i>optional parameter with default value: "00 : 00 : 07 : b9 : 06 : 29 : 04 : 35 : 03 : af"</i> par B value for computing the PSD reference for US PBO
[no] v-noise-snr-down	Parameter type: <Xdsl::SnrmMode> Format: (mode-1 mode-2 mode-3) Possible values: - mode-1 : virtual noise disabled - mode-2 : Tx referred virtual noise enabled - mode-3 : Rx referred virtual noise enabled(not supported)	<i>optional parameter with default value: "mode-1"</i> downstream mode of virtual noise SNR margin
[no] v-noise-snr-up	Parameter type: <Xdsl::SnrmModeUp> Format: (mode-1 mode-2 mode-3) Possible values: - mode-1 : virtual noise disabled - mode-2 : Tx referred virtual noise enabled	<i>optional parameter with default value: "mode-1"</i> upstream mode of virtual noise SNR Margin

Parameter	Type	Description
	- mode-3 : Rx referred virtual noise enabled	
[no] v-noise-psd-down	Parameter type: <Xdsl::VirtualNoisePsdDownType> Format: - binary string - length: x<=97	<i>optional parameter with default value: ""</i> (deprecated)virtual noise level for determining the SNR margin in downstream bands
[no] v-noise-psd-up	Parameter type: <Xdsl::VirtualNoisePsdUpType> Format: - binary string - length: x<=49	<i>optional parameter with default value: ""</i> (deprecated)virtual noise level for determining the SNR margin in upstream bands
[no] cust-psd-sc-down	Parameter type: <Xdsl::PsdScaleBit> Format: (linear logarithmic) Possible values: - linear : linear scale - logarithmic : logarithmic scale	<i>optional parameter with default value: "linear"</i> psd scale
[no] cust-psd-ty-down	Parameter type: <Xdsl::PsdTypeBit> Format: (mask template) Possible values: - mask : PSD mask - template : PSD template	<i>optional parameter with default value: "mask"</i> psd type
[no] cust-psd-sc-up	Parameter type: <Xdsl::PsdScaleBit> Format: (linear logarithmic) Possible values: - linear : linear scale - logarithmic : logarithmic scale	<i>optional parameter with default value: "linear"</i> psd scale
[no] cust-psd-ty-up	Parameter type: <Xdsl::PsdTypeBit> Format: (mask template) Possible values: - mask : PSD mask - template : PSD template	<i>optional parameter with default value: "mask"</i> psd type
[no] cust-rx-psd-sc-up	Parameter type: <Xdsl::PsdScaleBit> Format: (linear logarithmic) Possible values: - linear : linear scale - logarithmic : logarithmic scale	<i>optional parameter with default value: "linear"</i> psd scale
[no] cust-rx-psd-ty-up	Parameter type: <Xdsl::PsdTypeBit> Format: (mask template) Possible values: - mask : PSD mask - template : PSD template	<i>optional parameter with default value: "mask"</i> psd type
[no] upbo-aele-mode	Parameter type: <Xdsl::UpboAeleMode> Format: - the electrical length estimation mode to be used in Aele Method	<i>optional parameter with default value: 0</i> the electrical length estimation mode to be used in the

9 xDSL Configuration Commands

Parameter	Type	Description
	- range: [0...3]	Alternative Electrical Length Method
[no] upboaele-min-thrs	Parameter type: <Xdsl::UpboAeleMinThresh> Format: - the electrical length minimum threshold to be used in AeLe Method - unit: percent - range: [0...15]	<i>optional parameter with default value: 10</i> the electrical length minimum threshold value to be used in the Alternative Electrical Length Method
[no] short-loop-lr	Parameter type: boolean	<i>optional parameter</i> enable vdsl2 lr short loop operation
[no] medium-loop-lr	Parameter type: boolean	<i>optional parameter</i> enable vdsl2 lr medium loop operation
[no] long-loop-lr	Parameter type: boolean	<i>optional parameter</i> enable vdsl2 lr long loop operation

9.15 VDSL2 Custom PSD shape Downstream Configuration Command

Command Description

This command allows the operator to configure the VDSL2 custom psd shape in downstream direction.

It helps operator to enter the custom psd shape in a user-friendly way. Instead of entering octets the operator can enter numbers corresponding to frequency and psd.

When all break points are set to default values (frequency 0, psd 0), the psd shape is cleared. To clear the entire shape at once, set the first two breakpoints to default values. Using this method, the frequency scale and the psd shape type will also be reset to the default value. When any other breakpoint is set to default values, all points following it will also be set to the default values.

When defining a PSD shape, a minimum of 2 PSD points should be specified. The successive PSD points must have increasing ($\geq$) frequencies. It is allowed that for two successive PSD points, different PSD levels are defined at a same frequency (brickwall).

User Level

The command can be accessed by operators with xdsl privileges, and executed by operators with xdsl privileges.

Command Syntax

The command has the following syntax:

```
> configure xdsl spectrum-profile (index) vdsl2 cust-psd-pt-down (psd-point) [ no frequency | frequency
<Xdsl::CustFreq> ] [ no psd | psd <Xdsl::PsdLevel> ]
```

Command Parameters

Table 9.15-1 "VDSL2 Custom PSD shape Downstream Configuration Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - a profile index value - range: [1...256]	index of the profile.
(psd-point)	Format: - psd point - range: [1...32]	psd point

Table 9.15-2 "VDSL2 Custom PSD shape Downstream Configuration Command" Command Parameters

Parameter	Type	Description
[no] frequency	Parameter type: <Xdsl::CustFreq> Format: - frequency	optional parameter with default value: 0 psd frequency

9 xDSL Configuration Commands

Parameter	Type	Description
	- unit: khz - range: [0...35324]	
[no] psd	Parameter type: <Xdsl::PsdLevel> Format: - psd level - unit: -0.5 * (PSD level in dBm/Hz) - range: [0...255]	<i>optional parameter with default value: 0</i> psd level

9.16 VDSL2 Custom PSD shape Upstream Configuration Command

Command Description

This command allows the operator to configure the VDSL2 custom psd shape in downstream direction.

It helps operator to enter the custom psd shape in a user-friendly way. Instead of entering octets the operator can enter numbers corresponding to frequency and psd.

When all break points are set to default values (frequency 0, psd 0), the psd shape is cleared. To clear the entire shape at once, set the first two breakpoints to default values. Using this method, the frequency scale and the psd shape type will also be reset to the default value. When any other breakpoint is set to default values, all points following it will also be set to the default values.

When defining a PSD shape, a minimum of 2 PSD points should be specified. The successive PSD points must have increasing ($>/=$) frequencies. It is allowed that for two successive PSD points, different PSD levels are defined at a same frequency (brickwall).

User Level

The command can be accessed by operators with xdsl privileges, and executed by operators with xdsl privileges.

Command Syntax

The command has the following syntax:

```
> configure xdsl spectrum-profile (index) vdsl2 cust-psd-pt-up (psd-point) [ no frequency | frequency
<Xdsl::CustFreq> ] [ no psd | psd <Xdsl::PsdLevel> ]
```

Command Parameters

Table 9.16-1 "VDSL2 Custom PSD shape Upstream Configuration Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - a profile index value - range: [1...256]	index of the profile.
(psd-point)	Format: - psd point - range: [1...20]	psd point

Table 9.16-2 "VDSL2 Custom PSD shape Upstream Configuration Command" Command Parameters

Parameter	Type	Description
[no] frequency	Parameter type: <Xdsl::CustFreq> Format: - frequency	optional parameter with default value: 0 psd frequency

9 xDSL Configuration Commands

Parameter	Type	Description
	- unit: khz - range: [0...35324]	
[no] psd	Parameter type: <Xdsl::PsdLevel> Format: - psd level - unit: -0.5 * (PSD level in dBm/Hz) - range: [0...255]	<i>optional parameter with default value: 0</i> psd level

9.17 VDSL2 Custom RX PSD shape Upstream Configuration Command

Command Description

This command allows the operator to configure the VDSL2 custom rx-psd shape in upstream direction.

It helps operator to enter the custom psd shape in a user-friendly way. Instead of entering octets the operator can enter numbers corresponding to frequency and psd.

When all break points are set to default values (frequency 0, psd 0), the psd shape is cleared. To clear the entire shape at once, set the first two breakpoints to default values. Using this method, the frequency scale and the psd shape type will also be reset to the default value. When any other breakpoint is set to default values, all points following it will also be set to the default values.

When defining a PSD shape, a minimum of 2 PSD points should be specified. The successive PSD points must have increasing ($\geq$) frequencies. It is allowed that for two successive PSD points, different PSD levels are defined at a same frequency (brickwall).

User Level

The command can be accessed by operators with xdsl privileges, and executed by operators with xdsl privileges.

Command Syntax

The command has the following syntax:

```
> configure xdsl spectrum-profile (index) vdsl2 cust-rx-psd-pt-up (psd-point) [ no frequency | frequency
<Xdsl::CustFreq> ] [ no psd | psd <Xdsl::PsdLevel> ]
```

Command Parameters

Table 9.17-1 "VDSL2 Custom RX PSD shape Upstream Configuration Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - a profile index value - range: [1...256]	index of the profile.
(psd-point)	Format: - psd point - range: [1...20]	psd point

Table 9.17-2 "VDSL2 Custom RX PSD shape Upstream Configuration Command" Command Parameters

Parameter	Type	Description
[no] frequency	Parameter type: <Xdsl::CustFreq> Format: - frequency	optional parameter with default value: 0 psd frequency

9 xDSL Configuration Commands

Parameter	Type	Description
	- unit: khz - range: [0...35324]	
[no] psd	Parameter type: <Xdsl::PsdLevel> Format: - psd level - unit: -0.5 * (PSD level in dBm/Hz) - range: [0...255]	<i>optional parameter with default value: 0</i> psd level

9.18 VDSL2 Virtual Noise Downstream Configuration Command

Command Description

This command allows the operator to configure VDSL2 virtual noise in downstream direction.

It helps operator to enter the virtual noise in a user-friendly way. Instead of entering octets, as was the case with the earlier command, the operator can enter numbers corresponding to frequency and psd.

When all break points are set to default values (frequency 0, psd 0), the psd shape is cleared. To clear the entire shape at once, set the first two breakpoints to default values. When any other breakpoint is set to default values, all points following it will also be set to the default values.

When defining a PSD shape, a minimum of 2 PSD points should be specified. The successive PSD points must have increasing ($\geq$) frequencies. It is allowed that for two successive PSD points, different PSD levels are defined at a same frequency (brickwall).

User Level

The command can be accessed by operators with xdsl privileges, and executed by operators with xdsl privileges.

Command Syntax

The command has the following syntax:

```
> configure xdsl spectrum-profile (index) vdsl2 v-noise-psd-pt-down (psd-point) [ no frequency | frequency <Xdsl::CustFreq> ] [ no psd | psd <Xdsl::CustPsdVdsl2VtNoise> ]
```

Command Parameters

Table 9.18-1 "VDSL2 Virtual Noise Downstream Configuration Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - a profile index value - range: [1...256]	index of the profile.
(psd-point)	Format: - psd point - range: [1...32]	psd point

Table 9.18-2 "VDSL2 Virtual Noise Downstream Configuration Command" Command Parameters

Parameter	Type	Description
[no] frequency	Parameter type: <Xdsl::CustFreq> Format: - frequency - unit: khz - range: [0...35324]	optional parameter with default value: 0 psd frequency
[no] psd	Parameter type: <Xdsl::CustPsdVdsl2VtNoise>	optional parameter with default

9 xDSL Configuration Commands

Parameter	Type	Description
	Format: - psd level - unit: -2*(40+PSD level in dBm/Hz) - range: [0...200,255]	value: 0 psd level

9.19 VDSL2 Virtual Noise Upstream Configuration Command

Command Description

This command allows the operator to configure VDSL2 virtual noise in upstream direction.

It helps operator to enter the custom psd shape in a user-friendly way. Instead of entering octets, as was the case with the earlier command, the operator can enter numbers corresponding to frequency and psd.

When all break points are set to default values (frequency 0, psd 0), the psd shape is cleared. To clear the entire shape at once, set the first two breakpoints to default values. When any other breakpoint is set to default values, all points following it will also be set to the default values.

When defining a PSD shape, a minimum of 2 PSD points should be specified. The successive PSD points must have increasing ($\geq$) frequencies. It is allowed that for two successive PSD points, different PSD levels are defined at a same frequency (brickwall).

User Level

The command can be accessed by operators with xdsl privileges, and executed by operators with xdsl privileges.

Command Syntax

The command has the following syntax:

```
> configure xdsl spectrum-profile (index) vdsl2 v-noise-psd-pt-up (psd-point) [ no frequency | frequency
<Xdsl::CustFreq> ] [ no psd | psd <Xdsl::CustPsdVdsl2VtNoise> ]
```

Command Parameters

Table 9.19-1 "VDSL2 Virtual Noise Upstream Configuration Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - a profile index value - range: [1...256]	index of the profile.
(psd-point)	Format: - psd level - range: [1...16]	psd point

Table 9.19-2 "VDSL2 Virtual Noise Upstream Configuration Command" Command Parameters

Parameter	Type	Description
[no] frequency	Parameter type: <Xdsl::CustFreq> Format: - frequency - unit: khz - range: [0...35324]	optional parameter with default value: 0 psd frequency
[no] psd	Parameter type: <Xdsl::CustPsdVdsl2VtNoise>	optional parameter with default

9 xDSL Configuration Commands

Parameter	Type	Description
	Format: - psd level - unit: $-2 \times (40 + \text{PSD level in dBm/Hz})$ - range: [0...200,255]	<i>value: 0</i> psd level

9.20 VDSL2 Power Back Off Configuration Command

Command Description

This command can be used to specify the power back off parameters for each upstream band.

The equal FEXT reference electrical length parameter value for each band (including optional band) can be used for computing the PSD reference for US equal FEXT PBO. The range of this parameter for each band is 1.8 dB to 63 dB in steps of 0.1 dB. The special value 0 dB indicates that the modem has to use dedicated mechanism to optimally apply the equal FEXT without providing any manual setting for this parameter. The special value 1.8 dB disables equal FEXT UPBO in the respective upstream band.

Parameter A and B can be used for computing the PSD reference for US PBO for each band (including optional band). The range of parameter A for each band is 40..80.95 dBm/Hz in steps of 0.01 dBm/Hz. And the range of parameter B is 0..40.95 dBm/Hz in steps of 0.01 dBm/Hz.

User Level

The command can be accessed by operators with xdsl privileges, and executed by operators with xdsl privileges.

Command Syntax

The command has the following syntax:

```
> configure xdsl spectrum-profile (index) vdsl2 pbo (band) [ no equal-fext | equal-fext
<Xdsl::EqualFextUpstreamParam> ] [ param-a <Xdsl::PboParamA> ] [ param-b <Xdsl::PboParamB> ]
```

Command Parameters

Table 9.20-1 "VDSL2 Power Back Off Configuration Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - a profile index value - range: [1...256]	index of the profile.
(band)	Format: - equal fext band - range: [1...5]	band index

Table 9.20-2 "VDSL2 Power Back Off Configuration Command" Command Parameters

Parameter	Type	Description
[no] equal-fext	Parameter type: <Xdsl::EqualFextUpstreamParam> Format: - pbo equal fext upstream - unit: 0.1 dB - range: [0,18...630]	<i>optional parameter with default value: 0L</i> equal fext upstream param
param-a	Parameter type: <Xdsl::PboParamA> Format:	<i>optional parameter</i> parameter A value

9 xDSL Configuration Commands

Parameter	Type	Description
	- pbo param A - unit: 0.01 dBm/Hz - range: [4000...8095]	
param-b	Parameter type: <Xdsl::PboParamB> Format: - pbo param B - unit: 0.01 dBm/Hz - range: [0...4095]	<i>optional parameter</i> parameter B value

9.21 xDSL DPBO Profile Configuration Command

Command Description

Downstream power back off profile to configure the modem for a physical line.

User Level

The command can be accessed by operators with xdsl privileges, and executed by operators with xdsl privileges.

Command Syntax

The command has the following syntax:

```
> configure xdsl ( no dpbo-profile (index) ) | ( dpbo-profile (index) name <AsamProfileName> [ no es-elect-length
| es-elect-length <Xdsl::ElectricalLength> ] [ no es-cable-model-a | es-cable-model-a <Xdsl::CableModelA> ] [ no
es-cable-model-b | es-cable-model-b <Xdsl::CableModelB> ] [ no es-cable-model-c | es-cable-model-c
<Xdsl::CableModelC> ] [ no min-usable-signal | min-usable-signal <Xdsl::MinUsableSignalLevel> ] [ no
min-frequency | min-frequency <Xdsl::MinFrequency> ] [ no max-frequency | max-frequency
<Xdsl::MaxFrequency> ] [ no rs-elect-length | rs-elect-length <Xdsl::RemoteSideElectricalLength> ] [ no
muf-control | muf-control <Xdsl::MaxUsableFrequencyControl> ] [ no offset | offset <Xdsl::DpboOffset> ] [ no
modification | modification <Xdsl::ModifyStatus> ] [ [ no ] active ] )
```

Command Parameters

Table 9.21-1 "xDSL DPBO Profile Configuration Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - a profile index value - range: [1...50]	index of profile

Table 9.21-2 "xDSL DPBO Profile Configuration Command" Command Parameters

Parameter	Type	Description
name	Parameter type: <AsamProfileName> Format: - a profile name - range: [a-zA-Z0-9-_.] - length: 1<=x<=32	<i>mandatory parameter</i> name of profile
[no] es-elect-length	Parameter type: <Xdsl::ElectricalLength> Format: - electrical length (1/10 * electrical-length) - unit: 0.1 dB - range: [0...2559]	<i>optional parameter with default value: 0L</i> exchange side electrical length
[no] es-cable-model-a	Parameter type: <Xdsl::CableModelA> Format: - cable model param (2 [^] -8 * cable-model) - unit: 2 [^] -8 - range: [-256...384]	<i>optional parameter with default value: 0L</i> cable model a
[no] es-cable-model-b	Parameter type: <Xdsl::CableModelB>	<i>optional parameter with default</i>

9 xDSL Configuration Commands

Parameter	Type	Description
	Format: - cable model param ($2^{-8} * \text{cable-model}$) - unit: $2^{-8} \text{ Hz}^{-0.5}$ - range: [-256...384]	<i>value: 0L</i> cable model b
[no] es-cable-model-c	Parameter type: <Xdsl::CableModelC> Format: - cable model param ($2^{-8} * \text{cable-model}$) - unit: 2^{-8} Hz^{-1} - range: [-256...384]	<i>optional parameter with default value: 0L</i> cable model c
[no] min-usable-signal	Parameter type: <Xdsl::MinUsableSignalLevel> Format: - minimum usable signal ($1/10 * \text{min-usable-signal}$) - unit: 0.1 dB - range: [-1400...0]	<i>optional parameter with default value: -1275L</i> minimal usable signal level
[no] min-frequency	Parameter type: <Xdsl::MinFrequency> Format: - minimum frequency - unit: kHz - range: [0...35324]	<i>optional parameter with default value: 0L</i> min frequency
[no] max-frequency	Parameter type: <Xdsl::MaxFrequency> Format: - maximum frequency - unit: kHz - range: [0...35324]	<i>optional parameter with default value: 30000L</i> max frequency
[no] rs-elect-length	Parameter type: <Xdsl::RemoteSideElectricalLength> Format: - remote side electrical length ($1/100 * \text{rs-elect-length}$) - unit: 0.01 dB - range: [0...25599]	<i>optional parameter with default value: 0L</i> remote side electrical length
[no] muf-control	Parameter type: <Xdsl::MaxUsableFrequencyControl> Format: - maximum usable frequency ($1/10 * \text{muf-control}$) - unit: 0.1 dB - range: [0...2559,3000]	<i>optional parameter with default value: 3000L</i> maximal usable frequency
[no] offset	Parameter type: <Xdsl::DpboOffset> Format: - dpbo offset ($1/10 * \text{offset}$) - unit: 0.1 dB - range: [-2560...2559]	<i>optional parameter with default value: 0L</i> offset
[no] modification	Parameter type: <Xdsl::ModifyStatus> Format: (start cancel complete) Possible values: - start : to start modifying the profile - cancel : to cancel the modifications done - complete : to complete the modifications	<i>optional parameter with default value: "complete"</i> modify the profile
[no] active	Parameter type: boolean	<i>optional parameter</i> to activate the profile

9.22 xDSL DPBO Mode Independent Custom PSD Mask Configuration Command

Command Description

This command specifies PSD breakpoints of DPBO Mode Independent Custom PSD Mask. A number of 2 to 32 PSD breakpoints can be specified. This parameter matches the PSDMASKds parameter described in ITU-T G.997.1 This set of breakpoints may contain two subsets :

The first sub-set defines the DPBO Custom PSD Mask. It matches the DPBOPSDMASKds parameter described in ITU-T G.997.1 The second sub-set (if any), defines the DPBO Minimum Override Mask. It matches the DPBOLFO parameter described in ITU-T G.997.1 The successive PSD points of each sub-set must have increasing ($\geq$) frequencies. It is allowed that for two successive PSD points, different PSD levels are defined at a same frequency (brickwall).

The second sub-set starts at the first breakpoint whose frequency is lower than the frequency of the previous breakpoint.

Only PSD values within the standard range from -95 to 0 dBm/Hz are guaranteed.

When all break points are set to default values (frequency 0, psd 0), the psd shape is cleared. To clear the entire shape at once, set the first two breakpoints to default values. When any other breakpoint is set to default values, all points following it will also be set to the default values.

User Level

The command can be accessed by operators with xdsl privileges, and executed by operators with xdsl privileges.

Command Syntax

The command has the following syntax:

```
> configure xdsl dpbo-profile (index) micpsd-pt-down (psd-point) [ no frequency | frequency
<Xdsl::DpboFrequency> ] [ no psd | psd <Xdsl::DpboCustomPsd> ]
```

Command Parameters

Table 9.22-1 "xDSL DPBO Mode Independent Custom PSD Mask Configuration Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - a profile index value - range: [1...50]	index of profile
(psd-point)	Format: - psd point - range: [1...32]	psd point

Table 9.22-2 "xDSL DPBO Mode Independent Custom PSD Mask Configuration Command" Command Parameters

9 xDSL Configuration Commands

Parameter	Type	Description
[no] frequency	Parameter type: <Xdsl::DpboFrequency> Format: - frequency - unit: khz - range: [0...35324]	<i>optional parameter with default value: 0L</i> psd frequency
[no] psd	Parameter type: <Xdsl::DpboCustomPsd> Format: - psd level (-0.1 * PSD-level) - unit: -0.1*dBm/Hz - range: [0...1275]	<i>optional parameter with default value: 0L</i> psd level

9.23 xDSL DPBO Exchange PSD Mask Configuration Command

Command Description

This command specifies the Assumed Exchange PSD mask to be protected by the DPBO shaping mechanism at the remote flexibility point. This parameter matches the DPBOEPSD parameter described in ITU-T G.997.1. A number of 2 to 16 PSD points can be specified. The successive PSD points must have increasing ($\geq$) frequencies. It is allowed that for two successive PSD points, different PSD levels are defined at a same frequency (brickwall).

Only PSD values within the standard range from -95 to 0 dBm/Hz are guaranteed.

When all break points are set to default values (frequency 0, psd 0), the psd shape is cleared. To clear the entire shape at once, set the first two breakpoints to default values. When any other breakpoint is set to default values, all points following it will also be set to the default values.

User Level

The command can be accessed by operators with `xdsl` privileges, and executed by operators with `xdsl` privileges.

Command Syntax

The command has the following syntax:

```
> configure xsdl dpbo-profile (index) epsd-pt-down (psd-point) [ no frequency | frequency <Xdsl::DpboFrequency> ] [ no psd | psd <Xdsl::DpboExchangePsd> ]
```

Command Parameters

Table 9.23-1 "xDSL DPBO Exchange PSD Mask Configuration Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - a profile index value - range: [1...50]	index of profile
(psd-point)	Format: - psd point - range: [1...16]	psd point

Table 9.23-2 "xDSL DPBO Exchange PSD Mask Configuration Command" Command Parameters

Parameter	Type	Description
[no] frequency	Parameter type: <Xdsl::DpboFrequency> Format: - frequency - unit: khz - range: [0...35324]	optional parameter with default value: 0L psd frequency
[no] psd	Parameter type: <Xdsl::DpboExchangePsd> Format: - psd level (-0.1 * PSD-level)	optional parameter with default value: 0L psd level

9 xDSL Configuration Commands

Parameter	Type	Description
	- unit: -0.1*dBm/Hz - range: [0...1275]	

9.24 xDSL RTX Profile Configuration Command

Command Description

This command allows the operator to configure the RTX profile which can be used to configure the modem for a physical Line

RTX downstream/upstream parameters will have effect, only when the retransmission feature in downstream/upstream is not "forbidden" on the line

User Level

The command can be accessed by operators with xdsl privileges, and executed by operators with xdsl privileges.

Command Syntax

The command has the following syntax:

```
> configure xdsl ( no rtx-profile (index) ) | ( rtx-profile (index) name <AsamProfileName> [ version
<SignedInteger> ] [ no rtx-mode-dn | rtx-mode-dn <Xdsl::RtxMode> ] [ no rtx-mode-up | rtx-mode-up
<Xdsl::RtxMode> ] [ no min-exp-thrpt-dn | min-exp-thrpt-dn <Xdsl::BitRate> ] [ no min-exp-thrpt-up |
min-exp-thrpt-up <Xdsl::BitRate> ] [ no plan-exp-thrpt-dn | plan-exp-thrpt-dn <Xdsl::BitRate> ] [ no
plan-exp-thrpt-up | plan-exp-thrpt-up <Xdsl::BitRate> ] [ no max-exp-thrpt-dn | max-exp-thrpt-dn <Xdsl::BitRate>
] [ no max-exp-thrpt-up | max-exp-thrpt-up <Xdsl::BitRate> ] [ no max-net-rate-dn | max-net-rate-dn
<Xdsl::BitRate> ] [ no max-net-rate-up | max-net-rate-up <Xdsl::BitRate> ] [ no min-delay-dn | min-delay-dn
<Xdsl::RtxMinDelay> ] [ no min-delay-up | min-delay-up <Xdsl::RtxMinDelay> ] [ no max-delay-dn |
max-delay-dn <Xdsl::RtxMaxDelay> ] [ no max-delay-up | max-delay-up <Xdsl::RtxMaxDelay> ] [ no
min-inp-shine-dn | min-inp-shine-dn <Xdsl::ShineImpNoiseProtection> ] [ no min-inp-shine-up | min-inp-shine-up
<Xdsl::ShineImpNoiseProtection> ] [ no min-inp-rein-dn | min-inp-rein-dn <Xdsl::ReinImpNoiseProtection> ] [ no
min-inp-rein-up | min-inp-rein-up <Xdsl::ReinImpNoiseProtection> ] [ no min-inp8-shine-dn | min-inp8-shine-dn
<Xdsl::ShineImpNoiseProtection8> ] [ no min-inp8-shine-up | min-inp8-shine-up
<Xdsl::ShineImpNoiseProtection8> ] [ no min-inp8-rein-dn | min-inp8-rein-dn <Xdsl::ReinImpNoiseProtection8> ]
[ no min-inp8-rein-up | min-inp8-rein-up <Xdsl::ReinImpNoiseProtection8> ] [ no int-arr-time-dn | int-arr-time-dn
<Xdsl::RtxInterArrivalTime> ] [ no int-arr-time-up | int-arr-time-up <Xdsl::RtxInterArrivalTime> ] [ no
shine-ratio-dn | shine-ratio-dn <Xdsl::RtxShineRatio> ] [ no shine-ratio-up | shine-ratio-up <Xdsl::RtxShineRatio>
] [ no leftr-thresh-dn | leftr-thresh-dn <Xdsl::RtxLeftrThreshold> ] [ no leftr-thresh-up | leftr-thresh-up
<Xdsl::RtxLeftrThreshold> ] [ no modification | modification <Xdsl::RtxModifyStatus> ] [ [ no ] active ] )
```

Command Parameters

Table 9.24-1 "xDSL RTX Profile Configuration Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - a profile index value - range: [1...1024]	index of the profile

Table 9.24-2 "xDSL RTX Profile Configuration Command" Command Parameters

Parameter	Type	Description
name	Parameter type: <AsamProfileName>	mandatory parameter

9 xDSL Configuration Commands

Parameter	Type	Description
	Format: - a profile name - range: [a-zA-Z0-9-_.] - length: 1<=x<=32	profile name
version	Parameter type: <SignedInteger> Format: - a signed integer	<i>optional parameter</i> version maintained by manager, usually 1 for new profile
[no] rtx-mode-dn	Parameter type: <Xdsl::RtxMode> Format: (forbidden preferred forced testmode) Possible values: - forbidden : retransmission forbidden in down/upstream - preferred : retransmission preferred in down/upstream - forced : retransmission forced in down/upstream - testmode : retransmission testmode in down/upstream	<i>optional parameter with default value: "preferred"</i> retransmission mode in downstream
[no] rtx-mode-up	Parameter type: <Xdsl::RtxMode> Format: (forbidden preferred forced testmode) Possible values: - forbidden : retransmission forbidden in down/upstream - preferred : retransmission preferred in down/upstream - forced : retransmission forced in down/upstream - testmode : retransmission testmode in down/upstream	<i>optional parameter with default value: "preferred"</i> retransmission mode in upstream
[no] min-exp-thrpt-dn	Parameter type: <Xdsl::BitRate> Format: - a bit rate value - unit: kbps - range: [0...2147483647]	<i>optional parameter with default value: 64</i> minimum expected throughput for downstream direction
[no] min-exp-thrpt-up	Parameter type: <Xdsl::BitRate> Format: - a bit rate value - unit: kbps - range: [0...2147483647]	<i>optional parameter with default value: 64</i> minimum expected throughput for upstream direction
[no] plan-exp-thrpt-dn	Parameter type: <Xdsl::BitRate> Format: - a bit rate value - unit: kbps - range: [0...2147483647]	<i>optional parameter with default value: 128</i> planned expected throughput for downstream direction
[no] plan-exp-thrpt-up	Parameter type: <Xdsl::BitRate> Format: - a bit rate value - unit: kbps - range: [0...2147483647]	<i>optional parameter with default value: 128</i> planned expected throughput for upstream direction
[no] max-exp-thrpt-dn	Parameter type: <Xdsl::BitRate> Format: - a bit rate value - unit: kbps - range: [0...2147483647]	<i>optional parameter with default value: 262143</i> maximum expected throughput for downstream direction
[no] max-exp-thrpt-up	Parameter type: <Xdsl::BitRate> Format: - a bit rate value	<i>optional parameter with default value: 262143</i> maximum expected throughput

Parameter	Type	Description
	- unit: kbps - range: [0...2147483647]	for upstream direction
[no] max-net-rate-dn	Parameter type: <Xdsl::BitRate> Format: - a bit rate value - unit: kbps - range: [0...2147483647]	<i>optional parameter with default value: 262143</i> maximum net data rate for downstream direction
[no] max-net-rate-up	Parameter type: <Xdsl::BitRate> Format: - a bit rate value - unit: kbps - range: [0...2147483647]	<i>optional parameter with default value: 262143</i> maximum net data rate for upstream direction
[no] min-delay-dn	Parameter type: <Xdsl::RtxMinDelay> Format: - a delay time period - unit: msec - range: [0...63]	<i>optional parameter with default value: 0</i> minimum instantaneous delay allowed (due to the effect of retransmission) for downstream direction
[no] min-delay-up	Parameter type: <Xdsl::RtxMinDelay> Format: - a delay time period - unit: msec - range: [0...63]	<i>optional parameter with default value: 0</i> minimum instantaneous delay allowed (due to the effect of retransmission) for upstream direction
[no] max-delay-dn	Parameter type: <Xdsl::RtxMaxDelay> Format: - a delay time period - unit: msec - range: [2...63]	<i>optional parameter with default value: 12</i> maximum instantaneous delay allowed (due to the effect of retransmission) for downstream direction Special value 0 means no delay bounds
[no] max-delay-up	Parameter type: <Xdsl::RtxMaxDelay> Format: - a delay time period - unit: msec - range: [2...63]	<i>optional parameter with default value: 12</i> maximum instantaneous delay allowed (due to the effect of retransmission) for upstream direction Special value 0 means no delay bounds
[no] min-inp-shine-dn	Parameter type: <Xdsl::ShineImpNoiseProtection> Format: - minimum impulse noise protection - unit: DMT symbols - range: [0...63]	<i>optional parameter with default value: 8</i> minimum impulse noise protection against shine for downstream direction
[no] min-inp-shine-up	Parameter type: <Xdsl::ShineImpNoiseProtection> Format: - minimum impulse noise protection - unit: DMT symbols - range: [0...63]	<i>optional parameter with default value: 8</i> minimum impulse noise protection against shine for upstream direction
[no] min-inp-rein-dn	Parameter type: <Xdsl::ReinImpNoiseProtection> Format: - minimum impulse noise protection - unit: DMT symbols - range: [0...7]	<i>optional parameter with default value: 0</i> minimum impulse noise protection against rein for downstream direction
[no] min-inp-rein-up	Parameter type: <Xdsl::ReinImpNoiseProtection> Format: - minimum impulse noise protection - unit: DMT symbols	<i>optional parameter with default value: 0</i> minimum impulse noise protection against rein for

9 xDSL Configuration Commands

Parameter	Type	Description
	- range: [0...7]	upstream direction
[no] min-inp8-shine-dn	Parameter type: <Xdsl::ShineImpNoiseProtection8> Format: - minimum impulse noise protection for 8.625 khz tone spacing - unit: DMT symbols - range: [0...127]	<i>optional parameter with default value: 16</i> minimum impulse noise protection against shine for downstream direction for 8.625 khz tone spacing
[no] min-inp8-shine-up	Parameter type: <Xdsl::ShineImpNoiseProtection8> Format: - minimum impulse noise protection for 8.625 khz tone spacing - unit: DMT symbols - range: [0...127]	<i>optional parameter with default value: 16</i> minimum impulse noise protection against shine for upstream direction for 8.625 khz tone spacing
[no] min-inp8-rein-dn	Parameter type: <Xdsl::ReinImpNoiseProtection8> Format: - minimum impulse noise protection for 8.625 khz tone spacing - unit: DMT symbols - range: [0...13]	<i>optional parameter with default value: 0</i> minimum impulse noise protection against rein for downstream direction for 8.625 khz tone spacing
[no] min-inp8-rein-up	Parameter type: <Xdsl::ReinImpNoiseProtection8> Format: - minimum impulse noise protection for 8.625 khz tone spacing - unit: DMT symbols - range: [0...13]	<i>optional parameter with default value: 0</i> minimum impulse noise protection against rein for upstream direction for 8.625 khz tone spacing
[no] int-arr-time-dn	Parameter type: <Xdsl::RtxInterArrivalTime> Format: (derivedfrom100hz derivedfrom120hz) Possible values: - derivedfrom100hz : inter-arrival time derived from 100hz - derivedfrom120hz : inter-arrival time derived from 120hz	<i>optional parameter with default value: "derivedfrom100hz"</i> assumed inter-arrival time for rein protection for downstream direction
[no] int-arr-time-up	Parameter type: <Xdsl::RtxInterArrivalTime> Format: (derivedfrom100hz derivedfrom120hz) Possible values: - derivedfrom100hz : inter-arrival time derived from 100hz - derivedfrom120hz : inter-arrival time derived from 120hz	<i>optional parameter with default value: "derivedfrom100hz"</i> assumed inter-arrival time for rein protection for upstream direction
[no] shine-ratio-dn	Parameter type: <Xdsl::RtxShineRatio> Format: - shine ratio - unit: 1/1000 - range: [0...100]	<i>optional parameter with default value: 10</i> shine ratio for downstream direction
[no] shine-ratio-up	Parameter type: <Xdsl::RtxShineRatio> Format: - shine ratio - unit: 1/1000 - range: [0...100]	<i>optional parameter with default value: 10</i> shine ratio for upstream direction
[no] leftr-thresh-dn	Parameter type: <Xdsl::RtxLeftrThreshold> Format: - near-end defect threshold - unit: 1/100 - range: [0,1...99]	<i>optional parameter with default value: 0</i> threshold for declaring a near-end defect in downstream direction
[no] leftr-thresh-up	Parameter type: <Xdsl::RtxLeftrThreshold> Format: - near-end defect threshold	<i>optional parameter with default value: 0</i> threshold for declaring a near-end

Parameter	Type	Description
	- unit: 1/100 - range: [0,1...99]	defect in upstream direction
[no] modification	Parameter type: <Xdsl::RtxModifyStatus> Format: (start cancel complete) Possible values: - start : enable profile modifications - cancel : stop profile modifications and cancel the changes done - complete : activate the changes and disable profile modifications (other than name, version)	<i>optional parameter with default value: "complete"</i> profile modification status of an already created profile
[no] active	Parameter type: boolean	<i>optional parameter</i> to activate the profile

9.25 xDSL Vectoring Profile Configuration Command

Command Description

This command allows the operator to configure the vectoring profile which can be used for far end crosstalk cancellation. The profile contains vectoring related parameters of the modem.

band-control-up/dn : are the values pairs of begin- and end-subcarriers. Maximum 8 bands can be specified. The successive subcarriers must have increasing ($>/=$) values. Spectrum bands can be controlled per direction. When a specified spectrum band overlaps both directions, the actual band control will be restricted to the configured bandplan for the specified direction.

By default, the whole spectrum shall be used for crosstalk cancellation.

User Level

The command can be accessed by operators with xdsl privileges, and executed by operators with xdsl privileges.

Command Syntax

The command has the following syntax:

```
> configure xdsl ( no vect-profile (index) ) | ( vect-profile (index) name <AsamProfileName> [ version
<SignedInteger> ] [ no fext-cancel-up | fext-cancel-up <Xdsl::VectEnable> ] [ no fext-cancel-dn | fext-cancel-dn
<Xdsl::VectEnable> ] [ [ no ] leg-can-dn-m1 ] [ [ no ] leg-can-dn-m2 ] [ [ no ] dis-gvect-cpe ] [ [ no ]
gvecfriend-cpe ] [ [ no ] gvecfriend-dn-cpe ] [ [ no ] legacy-cpe ] [ no band-control-up | band-control-up
<Xdsl::VectBandControl> ] [ no band-control-dn | band-control-dn <Xdsl::VectBandControl> ] [ no
vect-leav-thresh | vect-leav-thresh <Xdsl::VectLeavThresh> ] [ no vect-feat-bitmap | vect-feat-bitmap
<Xdsl::VectFeatValue> ] [ [ no ] legacy-upbo ] [ no modification | modification <Xdsl::RtxModifyStatus> ] [ [ no ]
active ] )
```

Command Parameters

Table 9.25-1 "xDSL Vectoring Profile Configuration Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - a profile index value - range: [1...25]	index of the profile

Table 9.25-2 "xDSL Vectoring Profile Configuration Command" Command Parameters

Parameter	Type	Description
name	Parameter type: <AsamProfileName> Format: - a profile name - range: [a-zA-Z0-9-_.] - length: 1<=x<=32	<i>mandatory parameter</i> profile name
version	Parameter type: <SignedInteger>	<i>optional parameter</i>

Parameter	Type	Description
	Format: - a signed integer	version maintained by manager, usually 1 for new profile
[no] fext-cancel-up	Parameter type: <Xdsl::VectEnable> Format: (enable disable full-disable) Possible values: - enable : enable vectoring gain and protection of other vectored lines - disable : disable vectoring gain and enable protection of other vectored lines - full-disable : disable vectoring gain and protection of other vectored lines	<i>optional parameter with default value: "enable"</i> enable/disable far end xtalk cancellation in upstream direction
[no] fext-cancel-dn	Parameter type: <Xdsl::VectEnable> Format: (enable disable full-disable) Possible values: - enable : enable vectoring gain and protection of other vectored lines - disable : disable vectoring gain and enable protection of other vectored lines - full-disable : disable vectoring gain and protection of other vectored lines	<i>optional parameter with default value: "enable"</i> enable/disable far end xtalk cancellation in downstream direction
[no] leg-can-dn-m1	Parameter type: boolean	<i>optional parameter</i> enable method 1
[no] leg-can-dn-m2	Parameter type: boolean	<i>optional parameter</i> enable method 2, cannot be enabled without first enabling method 1
[no] dis-gvect-cpe	Parameter type: boolean	<i>optional parameter</i> disable g.vector capable cpe type
[no] gvecfriend-cpe	Parameter type: boolean	<i>optional parameter</i> full vector friendly cpe type (dn/up)
[no] gvecfriend-dn-cpe	Parameter type: boolean	<i>optional parameter</i> vector friendly cpe type downstream
[no] legacy-cpe	Parameter type: boolean	<i>optional parameter</i> legacy cpe type
[no] band-control-up	Parameter type: <Xdsl::VectBandControl> Format: - specify as start1:stop1:start2:stop2... with max 8 pairs of start:stop subcarriers, incrementing values within the range[0...8191] (variable string) - length: x<=16	<i>optional parameter with default value: ""</i> defines the upstream spectrum in which xtalk cancellation is not allowed
[no] band-control-dn	Parameter type: <Xdsl::VectBandControl> Format: - specify as start1:stop1:start2:stop2... with max 8 pairs of start:stop subcarriers, incrementing values within the range[0...8191] (variable string) - length: x<=16	<i>optional parameter with default value: ""</i> defines the downstream spectrum in which xtalk cancellation is not allowed
[no] vect-leav-thresh	Parameter type: <Xdsl::VectLeavThresh> Format: - specify the disorderly leaving threshold	<i>optional parameter with default value: "8"</i> the time between observed loss of

9 xDSL Configuration Commands

Parameter	Type	Description
	- unit: DMT symbols - range: [0...40000]	US signal and forced cutoff of the DS signal, expressed in DMT symbols
[no] vect-feat-bitmap	Parameter type: <Xdsl::VectFeatValue> Format: - vectoring features - range: [0...4294967295]	<i>optional parameter with default value: 0</i> enable or disable specific vectoring features at line level
[no] legacy-upbo	Parameter type: boolean	<i>optional parameter</i> LegacyUpboProfile usage is allowed when legacy CPE is detected on vectoring line
[no] modification	Parameter type: <Xdsl::RtxModifyStatus> Format: (start cancel complete) Possible values: - start : enable profile modifications - cancel : stop profile modifications and cancel the changes done - complete : activate the changes and disable profile modifications (other than name, version)	<i>optional parameter with default value: "complete"</i> profile modification status of an already created profile
[no] active	Parameter type: boolean	<i>optional parameter</i> to activate the profile

9.26 xDSL Sos Profile Configuration Command

Command Description

This command allows the operator to configure the SOS profile, which can be used to configure the modem for a physical line.

User Level

The command can be accessed by operators with *xdsl* privileges, and executed by operators with *xdsl* privileges.

Command Syntax

The command has the following syntax:

```
> configure xsdl ( no sos-profile (index) ) | ( sos-profile (index) name <AsamProfileName> [ version
<SignedInteger> ] [ no sos-time-down | sos-time-down <Xdsl::XdslSosTime> ] [ no sos-time-up | sos-time-up
<Xdsl::XdslSosTime> ] [ no sos-ntones-down | sos-ntones-down <Xdsl::SosTones> ] [ no sos-ntones-up |
sos-ntones-up <Xdsl::SosTones> ] [ no sos-crc-down | sos-crc-down <Xdsl::SosCRC> ] [ no sos-crc-up | sos-crc-up
<Xdsl::SosCRC> ] [ no max-sos-down | max-sos-down <Xdsl::MaxSOS> ] [ no max-sos-up | max-sos-up
<Xdsl::MaxSOS> ] [ no snrmoffset-roc-dn | snrmoffset-roc-dn <Xdsl::SosSnrmRoc> ] [ no snrmoffset-roc-up |
snrmoffset-roc-up <Xdsl::SosSnrmRoc> ] [ no min-inp-roc-down | min-inp-roc-down <Xdsl::SosMinInpRoc> ] [
no min-inp-roc-up | min-inp-roc-up <Xdsl::SosMinInpRoc> ] [ no roc-mode-down | roc-mode-down
<Xdsl::RocMode> ] [ no roc-mode-up | roc-mode-up <Xdsl::RocMode> ] [ no modification | modification
<Xdsl::ModifyStatus> ] [ [ no ] active ] )
```

Command Parameters

Table 9.26-1 "xDSL Sos Profile Configuration Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - a profile index value - range: [1...25]	index of the profile

Table 9.26-2 "xDSL Sos Profile Configuration Command" Command Parameters

Parameter	Type	Description
name	Parameter type: <AsamProfileName> Format: - a profile name - range: [a-zA-Z0-9-_.] - length: 1<=x<=32	<i>mandatory parameter</i> profile name
version	Parameter type: <SignedInteger> Format: - a signed integer	<i>optional parameter</i> version maintained by manager, usually 1 for new profile
[no] sos-time-down	Parameter type: <Xdsl::XdslSosTime> Format: - Time window after which SOS is triggered. - unit: 64ms - range: [0...255]	<i>optional parameter with default value: 0</i> Time window after which SOS is triggered for the downstream direction. Special value '0'

9 xDSL Configuration Commands

Parameter	Type	Description
		indicates SOS triggering criteria is disabled and it is vendor discretionary
[no] sos-time-up	Parameter type: <Xdsl::XdslSosTime> Format: - Time window after which SOS is triggered. - unit: 64ms - range: [0...255]	<i>optional parameter with default value: 0</i> Time window after which SOS is triggered for the upstream direction. Special value '0' indicates SOS triggering criteria is disabled and it is vendor discretionary
[no] sos-ntones-down	Parameter type: <Xdsl::SosTones> Format: - Minimum percentage of tones that must be degraded persistently across sos time - unit: percent - range: [0...100]	<i>optional parameter with default value: 0</i> Minimum percentage of tones in downstream that must be degraded persistently across sos-time-down
[no] sos-ntones-up	Parameter type: <Xdsl::SosTones> Format: - Minimum percentage of tones that must be degraded persistently across sos time - unit: percent - range: [0...100]	<i>optional parameter with default value: 0</i> Minimum percentage of tones in upstream that must be degraded persistently across sos-time-up
[no] sos-crc-down	Parameter type: <Xdsl::SosCRC> Format: - Minimum number of normalized CRC anomalies received within the timeframe of sos time - unit: 0.02 - range: [1...65535]	<i>optional parameter with default value: 1</i> Minimum number of normalized CRC anomalies received in downstream within the timeframe of sos-time-down
[no] sos-crc-up	Parameter type: <Xdsl::SosCRC> Format: - Minimum number of normalized CRC anomalies received within the timeframe of sos time - unit: 0.02 - range: [1...65535]	<i>optional parameter with default value: 1</i> Minimum number of normalized CRC anomalies received in upstream within the timeframe of sos-time-up
[no] max-sos-down	Parameter type: <Xdsl::MaxSOS> Format: - Maximum number of times a successful SOS may be performed with in 120 seconds interval. - unit: times - range: [0...15]	<i>optional parameter with default value: 0</i> Maximum number of times a successful SOS in downstream may be performed with in 120 seconds interval. Special value '0' specifies no max limit.
[no] max-sos-up	Parameter type: <Xdsl::MaxSOS> Format: - Maximum number of times a successful SOS may be performed with in 120 seconds interval. - unit: times - range: [0...15]	<i>optional parameter with default value: 0</i> Maximum number of times a successful SOS in upstream may be performed with in 120 seconds interval. Special value '0' specifies no max limit.
[no] snrmoffset-roc-dn	Parameter type: <Xdsl::SosSnrmRoc> Format: - SNR margin offset for ROC channel. - unit: 1/10dB - range: [0...310]	<i>optional parameter with default value: 0</i> SNR margin offset for ROC channel in downstream
[no] snrmoffset-roc-up	Parameter type: <Xdsl::SosSnrmRoc> Format: - SNR margin offset for ROC channel.	<i>optional parameter with default value: 0</i> SNR margin offset for ROC

Parameter	Type	Description
	- unit: 1/10dB - range: [0...310]	channel in upstream
[no] min-inp-roc-down	Parameter type: <Xdsl::SosMinInpRoc> Format: - Minimum Impulse Noise Protection to apply on the ROC channel. - unit: DMT symbols - range: [0...8]	<i>optional parameter with default value: 4</i> Minimum Impulse Noise Protection to apply on the ROC channel in downstream
[no] min-inp-roc-up	Parameter type: <Xdsl::SosMinInpRoc> Format: - Minimum Impulse Noise Protection to apply on the ROC channel. - unit: DMT symbols - range: [0...8]	<i>optional parameter with default value: 4</i> Minimum Impulse Noise Protection to apply on the ROC channel in upstream
[no] roc-mode-down	Parameter type: <Xdsl::RocMode> Format: (allowed forbidden) Possible values: - allowed : ROC channel is allowed to be used for SOS mechanism - forbidden : ROC channel is forbidden to be used for SOS mechanism	<i>optional parameter with default value: "allowed"</i> Robust Overhead Channel (ROC) in downstream is allowed/forbidden to be used for SOS
[no] roc-mode-up	Parameter type: <Xdsl::RocMode> Format: (allowed forbidden) Possible values: - allowed : ROC channel is allowed to be used for SOS mechanism - forbidden : ROC channel is forbidden to be used for SOS mechanism	<i>optional parameter with default value: "allowed"</i> Robust Overhead Channel (ROC) in upstream is allowed/forbidden to be used for SOS
[no] modification	Parameter type: <Xdsl::ModifyStatus> Format: (start cancel complete) Possible values: - start : to start modifying the profile - cancel : to cancel the modifications done - complete : to complete the modifications	<i>optional parameter with default value: "complete"</i> to modify the profile
[no] active	Parameter type: boolean	<i>optional parameter</i> to activate the profile

9.27 xDSL Vectoring Control Entity Profile Configuration Command

Command Description

This command allows the operator to configure the vectoring control entity profile. The profile contains vectoring processing related parameters.

vce-min-par-join: Specifies the supported amount of lines for a group joining, with the intention to avoid impact on active lines. The system should reserve room to guarantee that at least the specified number of lines can join in parallel. At the moment multiple lines are joining, this is achieved by not canceling the same number of disturbers which normally could be canceled in the system.

vce-band-plan: The bandplan needs to cover the widest bandplan up to the highest possible frequency that could be configured via the spectrum profiles to the individual vectored lines. The goal is to force same upstream and downstream band edges for all lines controlled by the vector control entity, except for differences in US0 frequency limits (TypeA, TypeB, TypeM). When changing this parameter, all lines connected to this vectoring control entity need to be re-initialized.

User Level

The command can be accessed by operators with xdsl privileges, and executed by operators with xdsl privileges.

Command Syntax

The command has the following syntax:

```
> configure xdsl ( no vce-profile (index) ) | ( vce-profile (index) name <AsamProfileName> [ version
<SignedInteger> ] [ no vce-gain-mode | vce-gain-mode <Xdsl::VectGainAchievedMode> ] [ no vce-join-timeout |
vce-join-timeout <Xdsl::VectJoinTime> ] [ no vce-min-par-join | vce-min-par-join <Xdsl::VectMinParallelJoins> ]
[ no vce-hist-pcoder | vce-hist-pcoder <Xdsl::VectHistPrePostCoder> ] [ no vce-band-plan | vce-band-plan
<Xdsl::VectBandPlan> ] [ no vce-max-vect-freq | vce-max-vect-freq <Xdsl::MaxVectFrequencyMode> ] [ no
modification | modification <Xdsl::RtxModifyStatus> ] [ [ no ] active ] )
```

Command Parameters

Table 9.27-1 "xDSL Vectoring Control Entity Profile Configuration Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - a profile index value - range: [1...25]	index of the profile

Table 9.27-2 "xDSL Vectoring Control Entity Profile Configuration Command" Command Parameters

Parameter	Type	Description
name	Parameter type: <AsamProfileName> Format:	mandatory parameter profile name

Parameter	Type	Description
	- a profile name - range: [a-zA-Z0-9-_.] - length: 1<=x<=32	
version	Parameter type: <SignedInteger> Format: - a signed integer	<i>optional parameter</i> version maintained by manager, usually 1 for new profile
[no] vce-gain-mode	Parameter type: <Xdsl::VectGainAchievedMode> Format: (at-init after-reset during-showtime) Possible values: - at-init : gain achieved at init - after-reset : gain achieved in showtime only after board reset, in all other cases gain achieved at init - during-showtime : gain achieved during showtime (tracking)	<i>optional parameter with default value: "at-init"</i> vectoring control entity gain achieved mode
[no] vce-join-timeout	Parameter type: <Xdsl::VectJoinTime> Format: (auto <Xdsl::VectJoinTimeout>) Possible values: - auto : waiting time selected by the system Field type <Xdsl::VectJoinTimeout> - specify the queuing time - unit: sec - range: [0,1...40]	<i>optional parameter with default value: "15"</i> vectoring control entity join timeout
[no] vce-min-par-join	Parameter type: <Xdsl::VectMinParallelJoins> Format: (not-specified <Xdsl::VectParallelJoins>) Possible values: - not-specified : amount of lines for group joining is not specified Field type <Xdsl::VectParallelJoins> - specify the supported amount of lines for a group joining - unit: lines - range: [1...48]	<i>optional parameter with default value: "8"</i> vectoring control entity min parallel joinings
[no] vce-hist-pcoder	Parameter type: <Xdsl::VectHistPrePostCoder> Format: (disable enable1-2 enable2) Possible values: - disable : historical pre-/postcoder disabled - enable1-2 : historical pre-/postcoder enabled in phase1-2 - enable2 : historical pre-/postcoder enabled in phase2	<i>optional parameter with default value: "disable"</i> vectoring control entity historical pre/post coder
[no] vce-band-plan	Parameter type: <Xdsl::VectBandPlan> Format: (annex-a annex-b-997e annex-b-998e annex-b-998ade b998ade17ds35 b998e17ds35 a998ds35 annex-b-hpe)	<i>optional parameter with default value: "annex-b-998ade"</i> vectoring control entity band plan

9 xDSL Configuration Commands

Parameter	Type	Description
	Possible values: - annex-a : ITU-T G.993.2 VDSL2 Annex A (extended) band plan - annex-b-997e : ITU-T G.993.2 VDSL2 Annex B band plan type 997E17 - annex-b-998e : ITU-T G.993.2 VDSL2 Annex B band plan type 998E17 - annex-b-998ade : ITU-T G.993.2 VDSL2 Annex B band plan type 998ADE17 - b998ade17ds35 : ITU-T G.993.2 VDSL2 Annex B band plan type 998ADE35 - b998e17ds35 : ITU-T G.993.2 VDSL2 Annex B band plan type 998E35 - a998ds35 : ITU-T G.993.2 VDSL2 Annex A band plan type 998ds35 - annex-b-hpe : ITU-T G.993.2 VDSL2 Annex B band plan type HPE	
[no] vce-max-vect-freq	Parameter type: <Xdsl::MaxVectFrequencyMode> Format: (max17mhzvectoring max35mhzvectoring) Possible values: - max17mhzvectoring : Vectoring until maximum 17MHz - max35mhzvectoring : Vectoring until maximum 35MHz	<i>optional parameter with default value: "max17mhzvectoring"</i> vectoring control entity maximum vectoring frequency
[no] modification	Parameter type: <Xdsl::RtxModifyStatus> Format: (start cancel complete) Possible values: - start : enable profile modifications - cancel : stop profile modifications and cancel the changes done - complete : activate the changes and disable profile modifications (other than name, version)	<i>optional parameter with default value: "complete"</i> profile modification status of an already created profile
[no] active	Parameter type: boolean	<i>optional parameter to activate the profile</i>

9.28 xDSL Legacy UPBO Profile Configuration

Command

Command Description

This command allows the operator to configure the legacy UPBO profile which can be used to optimize the upstream performance of vectored lines adjacent to non-vectored or ZTV vectored lines with legacy VDSL2 CPE connected. The profile contains upstream power back-off related parameters of the modem used on the line of the legacy modem. This command allows the operator to configure the legacy UPBO profile which can be used to optimize the upstream performance of vectored lines. The profile contains upstream power back-off related parameters of the mode.

User Level

The command can be accessed by operators with xdsl privileges, and executed by operators with xdsl privileges.

Command Syntax

The command has the following syntax:

```
> configure xdsl ( no leg-upbo-profile (index) ) | ( leg-upbo-profile (index) name <AsamProfileName> [ version
<SignedInteger> ] [ no pbo-mode | pbo-mode <Xdsl::PboModeVdsl> ] [ no rx-psd-shape-up | rx-psd-shape-up
<Xdsl::RxVdsl2PsdShape> ] [ no psd-pbo-e-len-up | psd-pbo-e-len-up <Xdsl::PsdPboElectrLength> ] [ no
equal-fext | equal-fext <Xdsl::EqualFextParam> ] [ no psd-pbo-par-a-up | psd-pbo-par-a-up <Xdsl::ABParamType>
] [ no psd-pbo-par-b-up | psd-pbo-par-b-up <Xdsl::ABParamType> ] [ no modification | modification
<Xdsl::ProfileModifyStatus> ] [ [ no ] active ] )
```

Command Parameters

Table 9.28-1 "xDSL Legacy UPBO Profile Configuration Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - a profile index value - range: [1...4]	index of the profile

Table 9.28-2 "xDSL Legacy UPBO Profile Configuration Command" Command Parameters

Parameter	Type	Description
name	Parameter type: <AsamProfileName> Format: - a profile name - range: [a-zA-Z0-9-_.] - length: 1<=x<=32	mandatory parameter profile name
version	Parameter type: <SignedInteger> Format: - a signed integer	optional parameter version maintained by manager, usually default value is 1 for new profile
[no] pbo-mode	Parameter type: <Xdsl::PboModeVdsl>	optional parameter with default

9 xDSL Configuration Commands

Parameter	Type	Description
	Format: (pbo-mode-down pbo-mode-up pbo-up-pol-sd pbo-up-pol-us0 pbo-up-pol-pass) Possible values: - pbo-mode-down : upstream power backoff mode OFF - pbo-mode-up : upstream power backoff mode ON - pbo-up-pol-sd : pbo mode ON policing shutdown - pbo-up-pol-us0 : pbo mode ON policing US0 only - pbo-up-pol-pass : pbo mode ON policing passive	<i>value: "pbo-mode-up"</i> upstream power backoff mode
[no] rx-psd-shape-up	Parameter type: <Xdsl::RxVdsl2PsdShape> Format: (ab-param equal-fext) Possible values: - ab-param : AB parameter spectral density shape in upstream - equal-fext : equal fext in upstream	<i>optional parameter with default value: "ab-param"</i> the reference RX PSD shape for upstream
[no] psd-pbo-e-len-up	Parameter type: <Xdsl::PsdPboElectrLength> Format: (estimated <Xdsl::PsdPboLength>) Possible values: - estimated : estimated electrical length Field type <Xdsl::PsdPboLength> - electrical parameter AB range - unit: 1/2 * dB - range: [0...255]	<i>optional parameter with default value: "estimated"</i> the electrical length to be used with the AB parameters
[no] equal-fext	Parameter type: <Xdsl::EqualFextParam> Format: - binary string - length: 10	<i>optional parameter with default value: "00 : 00 : 00 : 00 : 00 : 00 : 00 : 00 : 00 : 00"</i> equal fext upstream param
[no] psd-pbo-par-a-up	Parameter type: <Xdsl::ABParamType> Format: - binary string - length: 10	<i>optional parameter with default value: "0f : a0 : 12 : 7a : 15 : 18 : 15 : 18 : 15 : 18"</i> param A value for computing the PSD reference for US PBO
[no] psd-pbo-par-b-up	Parameter type: <Xdsl::ABParamType> Format: - binary string - length: 10	<i>optional parameter with default value: "00 : 00 : 07 : b9 : 06 : 29 : 04 : 35 : 03 : af"</i> param B value for computing the PSD reference for US PBO
[no] modification	Parameter type: <Xdsl::ProfileModifyStatus> Format: (start cancel complete) Possible values: - start : enable profile modifications - cancel : stop profile modifications and cancel the changes done - complete : activate the changes and disable profile modifications (other than name, version)	<i>optional parameter with default value: "complete"</i> profile modification status of an already created profile
[no] active	Parameter type: boolean	<i>optional parameter to activate the profile</i>

9.29 xDSL Board Configuration Command

Command Description

This command allows the operator to configure xdsl parameters related with a specific board.

An already existing Downstream-Power-Back-Off(DPBO)-profile can be attached to a board.

All lines on this board will use this DPBO-profile unless a line-specific DPBO-profile is configured.

To deconfigure the DPBO-profile, it has to be put to 0.

An already existing Vectoring-Control-Entity(VCE)-profile can be attached to a Board-Level-Vectoring(BLV)-LT or to a System-Level-Vectoring(SLV)-VP board. The VCE-profile is applicable for vectoring cancellation of all the physical lines which can be vectored by the board. Note that a physical line can only be vectored if also a vectoring profile has been assigned to the line and vectoring is enabled.

The auto detect functions of the LT-VP connection can be enabled or disabled on SLV LT boards and VP boards.

The vce-capacity-mode is specific for 7363 systems. It only applies to VP boards, not to LT boards.

User Level

The command can be accessed by operators with xdsl privileges, and executed by operators with xdsl privileges.

Command Syntax

The command has the following syntax:

```
> configure xdsl board (board-index) [ no dpbo-profile | dpbo-profile <Xdsl::LineDpboProfile> ] [ no vce-profile |
vce-profile <Xdsl::BoardVceProfile> ] [ no vplt-autodiscover | vplt-autodiscover <Xdsl::autoDiscoverState> ] [ no
vce-capacity-mode | vce-capacity-mode <Xdsl::vceCapacityMode> ] [ no leg-upbo-profile | leg-upbo-profile
<Xdsl::BoardLegacyUpboProfile> ] [ no vect-class | vect-class <Xdsl::BoardVectClass> ]
```

Command Parameters

Table 9.29-1 "xDSL Board Configuration Command" Resource Parameters

Resource Identifier	Type	Description
(board-index)	Format: (ctrl : <Eqpt::RackId> / <Eqpt::ShelfId> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId>) Possible values: - ctrl : ctrl-slot Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number	board index

Table 9.29-2 "xDSL Board Configuration Command" Command Parameters

Parameter	Type	Description
[no] dpbo-profile	Parameter type: <Xdsl::LineDpboProfile> Format: (none <Xdsl::DpboProfilePointer> name : <PrintableString>) Possible values: - none : no profile to associate - name : profile name Field type <Xdsl::DpboProfilePointer> - profile index - range: [0...50] Field type <PrintableString> - printable string	<i>optional parameter with default value: "none"</i> dpbo profile index
[no] vce-profile	Parameter type: <Xdsl::BoardVceProfile> Format: (none <Xdsl::VceProfilePointer> name : <PrintableString>) Possible values: - none : no profile to associate - name : profile name Field type <Xdsl::VceProfilePointer> - profile index - range: [0...25] Field type <PrintableString> - printable string	<i>optional parameter with default value: "none"</i> vdsl2 vce profile index
[no] vplt-autodiscover	Parameter type: <Xdsl::autoDiscoverState> Format: (disable enable enable-both-lnk1-lnk2) Possible values: - disable : disable auto discovery - enable : enable auto discovery - enable-both-lnk1-lnk2 : enable auto discovery on both LT links	<i>optional parameter with default value: "disable"</i> enable or disable the VPLT auto discovery function
[no] vce-capacity-mode	Parameter type: <Xdsl::vceCapacityMode> Format: (normal extended) Possible values: - normal : de-activate the extended vectoring capacity OR indicates normal behavior for boards which do not support extended vectoring capacity - extended : activate the extended vectoring capacity	<i>optional parameter with default value: "normal"</i> activate/de-activate extended vectoring capacity mode
[no] leg-upbo-profile	Parameter type: <Xdsl::BoardLegacyUpboProfile> Format: (none <Xdsl::LegacyUpboProfilePointer> name : <PrintableString>) Possible values: - none : no profile to associate - name : profile name Field type <Xdsl::LegacyUpboProfilePointer> - a profile index value - range: [0...4] Field type <PrintableString>	<i>optional parameter with default value: "none"</i> Legacy Upbo profile index/name

Parameter	Type	Description
[no] vect-class	- printable string Parameter type: <Xdsl::BoardVectClass> Format: - vectoring class configured as a number from 0 to 3. The default value 0 means that the vectoring class parameter is not configured or not applicable. - range: [0...3]	<i>optional parameter with default value: "0"</i> set the vectoring class for VP

Command Output

Table 9.29-3 "xDSL Board Configuration Command" Display parameters

Specific Information		
name	Type	Description
dpbo-profile-name	Parameter type: <Xdsl::IgnoredPrintableString> - ignored printable string	name of the dpbo profile <i>This element is only shown in detail mode.</i>
vce-profile-name	Parameter type: <Xdsl::IgnoredPrintableString> - ignored printable string	name of the vectoring control entity profile <i>This element is only shown in detail mode.</i>
leg-upbo-profile-name	Parameter type: <Xdsl::IgnoredPrintableString> - ignored printable string	name of the legacy upbo profile <i>This element is only shown in detail mode.</i>

9.30 xDSL Board Vectoring Fallback Configuration Command

Command Description

This command allows the operator to configure per board the profile selection in case the line enters the vectoring fallback mode.

User Level

The command can be accessed by operators with xdsl privileges, and executed by operators with xdsl privileges.

Command Syntax

The command has the following syntax:

```
> configure xdsl board (board-index) vect-fallback [ [ no ] fb-vplt-com-fail ] [ [ no ] fb-cpe-cap-mism ] [ [ no ] fb-conf-not-feas ] [ no spectrum-profile | spectrum-profile <Xdsl::VectFbSpectrumProfile> ] [ no service-profile | service-profile <Xdsl::VectFbServiceProfile> ] [ no dpbo-profile | dpbo-profile <Xdsl::VectFbDpboProfile> ] [ no rtx-profile | rtx-profile <Xdsl::VectFbRtxProfile> ] [ no sos-profile | sos-profile <Xdsl::VectFbSosProfile> ]
```

Command Parameters

Table 9.30-1 "xDSL Board Vectoring Fallback Configuration Command" Resource Parameters

Resource Identifier	Type	Description
(board-index)	Format: (ctrl : <Eqpt::RackId> / <Eqpt::ShelfId> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId>) Possible values: - ctrl : ctrl-slot Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number	board index

Table 9.30-2 "xDSL Board Vectoring Fallback Configuration Command" Command Parameters

Parameter	Type	Description
[no] fb-vplt-com-fail	Parameter type: boolean	<i>optional parameter</i> allow fallback mode for vplt communication failure
[no] fb-cpe-cap-mism	Parameter type: boolean	<i>optional parameter</i> allow fallback mode for cpe capability mismatch
[no] fb-conf-not-feas	Parameter type: boolean	<i>optional parameter</i> allow fallback mode for

9 xDSL Configuration Commands

Parameter	Type	Description
[no] spectrum-profile	Parameter type: <Xdsl::VectFbSpectrumProfile> Format: (line-level <Xdsl::VectFbSpectrumProfilePointer> name : <PrintableString>) Possible values: - line-level : use the original line spectrum profile in fallback mode - name : profile name Field type <Xdsl::VectFbSpectrumProfilePointer> - a profile index value - range: [1...256] Field type <PrintableString> - printable string	configuration not feasible <i>optional parameter with default value: "line-level"</i> spectrum profile index
[no] service-profile	Parameter type: <Xdsl::VectFbServiceProfile> Format: (line-level <Xdsl::VectFbServiceProfilePointer> name : <PrintableString>) Possible values: - line-level : use the original line service profile in fallback mode - name : profile name Field type <Xdsl::VectFbServiceProfilePointer> - a profile index value - range: [1...1024] Field type <PrintableString> - printable string	<i>optional parameter with default value: "line-level"</i> service profile index
[no] dpbo-profile	Parameter type: <Xdsl::VectFbDpboProfile> Format: (none line-level <Xdsl::VectFbDpboProfilePointer> name : <PrintableString>) Possible values: - none : no fallback profile to associate - line-level : use the original line dpbo profile in fallback mode - name : profile name Field type <Xdsl::VectFbDpboProfilePointer> - a profile index value - range: [0...50] Field type <PrintableString> - printable string	<i>optional parameter with default value: "line-level"</i> dpbo profile index
[no] rtx-profile	Parameter type: <Xdsl::VectFbRtxProfile> Format: (none line-level <Xdsl::VectFbRtxProfilePointer> name : <PrintableString>) Possible values: - none : no fallback profile to associate - line-level : use the original line rtx profile in fallback mode - name : profile name Field type <Xdsl::VectFbRtxProfilePointer> - a profile index value	<i>optional parameter with default value: "line-level"</i> rtx profile index

Parameter	Type	Description
	- range: [0...1024] Field type <PrintableString> - printable string	
[no] sos-profile	Parameter type: <Xdsl::VectFbSosProfile> Format: (none line-level <Xdsl::VectFbSosProfilePointer> name : <PrintableString>) Possible values: - none : no fallback profile to associate - line-level : use the original line SOS profile in fallback mode - name : profile name Field type <Xdsl::VectFbSosProfilePointer> - a profile index value - range: [0...25] Field type <PrintableString> - printable string	<i>optional parameter with default value: "line-level"</i> sos profile index

Command Output

Table 9.30-3 "xDSL Board Vectoring Fallback Configuration Command" Display parameters

Specific Information		
name	Type	Description
spectrum-profile-name	Parameter type: <Xdsl::IgnoredPrintableString> - ignored printable string	name of the spectrum profile <i>This element is only shown in detail mode.</i>
service-profile-name	Parameter type: <Xdsl::IgnoredPrintableString> - ignored printable string	name of the service profile <i>This element is only shown in detail mode.</i>
dpbo-profile-name	Parameter type: <Xdsl::IgnoredPrintableString> - ignored printable string	name of the dpbo profile <i>This element is only shown in detail mode.</i>
rtx-profile-name	Parameter type: <Xdsl::IgnoredPrintableString> - ignored printable string	name of the rtx profile <i>This element is only shown in detail mode.</i>
sos-profile-name	Parameter type: <Xdsl::IgnoredPrintableString> - ignored printable string	name of the SOS profile <i>This element is only shown in detail mode.</i>

9.31 Xdsl Auto Port Reset Configurations

Command Description

This command allows the operator to configure xdsl parameters related to Automatic Port Reset.

Modification of the parameter values is not allowed when the feature is enabled.

User Level

The command can be accessed by operators with xdsl privileges, and executed by operators with xdsl privileges.

Command Syntax

The command has the following syntax:

```
> configure xdsl board (board-index) auto-port-reset [ no max-retry-attempt | max-retry-attempt <Xdsl::maxRetry>
] [ no reset-interval | reset-interval <Xdsl::IntervalTime> ] [ no reset-threshold | reset-threshold
<Xdsl::ThresholdTotal> ]
```

Command Parameters

Table 9.31-1 "Xdsl Auto Port Reset Configurations" Resource Parameters

Resource Identifier	Type	Description
(board-index)	Format: (ctrl : <Eqpt::RackId> / <Eqpt::ShelfId> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId>) Possible values: - ctrl : ctrl-slot Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number	board index

Table 9.31-2 "Xdsl Auto Port Reset Configurations" Command Parameters

Parameter	Type	Description
[no] max-retry-attempt	Parameter type: <Xdsl::maxRetry> Format: - maximum reset count for continuous automatic reset attempts - range: [1...5]	<i>optional parameter with default value: "2"</i> max number of continuous automatic port reset attempts
[no] reset-interval	Parameter type: <Xdsl::IntervalTime> Format: - unit for time in terms of 1 min - unit: min - range: [1...1440]	<i>optional parameter with default value: "3"</i> wait time between two consecutive resets
[no] reset-threshold	Parameter type: <Xdsl::ThresholdTotal>	<i>optional parameter with default</i>

Parameter	Type	Description
	Format: - maximum number of total auto-port-resets - range: [1...100]	<i>value: "20"</i> threshold for the automatic port reset attempts

9.32 xDSL Vectoring Processing Board Configuration Command

Command Description

This command allows the operator to configure which LTs should be connected to the vp-board. The lines on these LTs are expected to be vectored.

Configuring the links between a vp-board and its LTs is only allowed as long as the VPLT auto discovery feature is disabled for the vp-board.

Configuring is not allowed for 7363 systems.

User Level

The command can be accessed by operators with xdsl privileges, and executed by operators with xdsl privileges.

Command Syntax

The command has the following syntax:

```
> configure xdsl vp-board (board-index) vp-link <Xdsl::VectVpLink> [ no lt-expect | lt-expect <Xdsl::LsmBoardOrZero> ]
```

Command Parameters

Table 9.32-1 "xDSL Vectoring Processing Board Configuration Command" Resource Parameters

Resource Identifier	Type	Description
(board-index)	Format: (ctrl : <Eqpt::RackId> / <Eqpt::ShelfId> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId>) Possible values: - ctrl : ctrl-slot Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number	vp board index
vp-link	Parameter type: <Xdsl::VectVpLink> Format: - specifies the vp-link or the soft-link on the vp-board - range: [1...16]	the link on the vp board

Table 9.32-2 "xDSL Vectoring Processing Board Configuration Command" Command Parameters

Parameter	Type	Description
[no] lt-expect	Parameter type: <Xdsl::LsmBoardOrZero> Format:	optional parameter with default value: "none"

Parameter	Type	Description
	(<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> none) Possible values: - none : lt board not specified Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number	expected lt board slot index

9.33 xDSL Line Configuration Command

Command Description

This command allows the operator to configure the xDSL line. One should associate a spectrum, a service, a downstream power backoff and a retransmission profile to the line.

In case the operator wants to have VDSL2 crosstalk cancellation, a non-null xDSL Vectoring profile should be associated to a VDSL2 line. Any vectoring profile assigned to a line running in ADSLx mode will be ignored. The vectoring license counter is incremented when a xDSL Vectoring profile is assigned to an installed xdsl line, independent of its running mode ADSLx or VDSLx.

The operator can restrict a line to come up in specific ADSLx/VDSLx opmodes using opmode mask option in spectrum-profile.

Note: VDSL2 Vectoring Control Engine parameters should be configured via a vce-profile. The vce-profile is applicable for VDSL2 vectoring cancellation of all the physical lines which can be vectored by the board to which the vce-profile has been attached.

User Level

The command can be accessed by operators with xdsl privileges, and executed by operators with xdsl privileges.

Command Syntax

The command has the following syntax:

```
> configure xdsl line (if-index) [ no service-profile | service-profile <Xdsl::LineServiceProfile> ] [ no
spectrum-profile | spectrum-profile <Xdsl::LineSpectrumProfile> ] [ no dpbo-profile | dpbo-profile
<Xdsl::LineDpboProfile> ] [ no rtx-profile | rtx-profile <Xdsl::LineRtxProfile> ] [ no vect-profile | vect-profile
<Xdsl::LineVectProfile> ] [ no sos-profile | sos-profile <Xdsl::LineSosProfile> ] [ [ no ] ansi-t1413 ] [ [ no ]
etsi-dts ] [ [ no ] g992-1-a ] [ [ no ] g992-1-b ] [ [ no ] g992-2-a ] [ [ no ] g992-3-a ] [ [ no ] g992-3-b ] [ [ no ]
g992-3-aj ] [ [ no ] g992-3-l1 ] [ [ no ] g992-3-l2 ] [ [ no ] g992-3-am ] [ [ no ] g992-5-a ] [ [ no ] g992-5-b ] [ [ no ]
ansi-t1.424 ] [ [ no ] etsi-ts ] [ [ no ] itu-g993-1 ] [ [ no ] ieee-802.3ah ] [ [ no ] g992-5-aj ] [ [ no ] g992-5-am ] [ [
no ] g993-2-8a ] [ [ no ] g993-2-8b ] [ [ no ] g993-2-8c ] [ [ no ] g993-2-8d ] [ [ no ] g993-2-12a ] [ [ no ]
g993-2-12b ] [ [ no ] g993-2-17a ] [ [ no ] g993-2-30a ] [ [ no ] g993-2-35b ] [ no carrier-data-mode |
carrier-data-mode <Xdsl::CarrierDataMode> ] [ [ no ] admin-up ] [ bonding-mode <Xdsl::BondingMode> ] [ no
transfer-mode | transfer-mode <Xdsl::TpsTcMode> ] [ [ no ] imp-noise-sensor ] [ no vect-qln-mode | vect-qln-mode
<Xdsl::QLNmode> ] [ [ no ] auto-switch ] [ no vect-fallback | vect-fallback <Xdsl::LineFallbackMode> ]
```

Command Parameters

Table 9.33-1 "xDSL Line Configuration Command" Resource Parameters

Resource Identifier	Type	Description
(if-index)	Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number	interface index of the line

Resource Identifier	Type	Description
	Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number	

Table 9.33-2 "xDSL Line Configuration Command" Command Parameters

Parameter	Type	Description
[no] service-profile	Parameter type: <Xdsl::LineServiceProfile> Format: (none <Xdsl::SrvcProfilePointer> name : <PrintableString>) Possible values: - none : no profile to associate - name : profile name Field type <Xdsl::SrvcProfilePointer> - profile index - range: [0...1024] Field type <PrintableString> - printable string	<i>optional parameter with default value: "none"</i> ADSLx/VDSLx service profile to be configured on this line
[no] spectrum-profile	Parameter type: <Xdsl::LineSpectrumProfile> Format: (none <Xdsl::ProfilePointer> name : <PrintableString>) Possible values: - none : no profile to associate - name : profile name Field type <Xdsl::ProfilePointer> - profile index - range: [0...256] Field type <PrintableString> - printable string	<i>optional parameter with default value: "none"</i> ADSLx/VDSLx spectrum profile to be configured on this line
[no] dpbo-profile	Parameter type: <Xdsl::LineDpboProfile> Format: (none <Xdsl::DpboProfilePointer> name : <PrintableString>) Possible values: - none : no profile to associate - name : profile name Field type <Xdsl::DpboProfilePointer> - profile index - range: [0...50] Field type <PrintableString> - printable string	<i>optional parameter with default value: "none"</i> ADSLx/VDSLx dpbo profile to be configured on this line
[no] rtx-profile	Parameter type: <Xdsl::LineRtxProfile> Format: (none <Xdsl::RtxProfilePointer> name : <PrintableString>) Possible values: - none : no profile to associate - name : profile name Field type <Xdsl::RtxProfilePointer> - profile index - range: [0...1024]	<i>optional parameter with default value: "none"</i> ADSLx/VDSLx rtx profile to be configured on this line.

9 xDSL Configuration Commands

Parameter	Type	Description
	Field type <PrintableString> - printable string	
[no] vect-profile	Parameter type: <Xdsl::LineVectProfile> Format: (none <Xdsl::VectProfilePointer> name : <PrintableString>) Possible values: - none : no profile to associate - name : profile name Field type <Xdsl::VectProfilePointer> - profile index - range: [0...25] Field type <PrintableString> - printable string	<i>optional parameter with default value: "none"</i> VDSL2 vectoring profile to be configured on this line.
[no] sos-profile	Parameter type: <Xdsl::LineSosProfile> Format: (none <Xdsl::SosProfilePointer> name : <PrintableString>) Possible values: - none : no profile to associate - name : profile name Field type <Xdsl::SosProfilePointer> - profile index - range: [0...25] Field type <PrintableString> - printable string	<i>optional parameter with default value: "none"</i> sos profile to be configured on this line
[no] ansi-t1413	Parameter type: boolean	<i>optional parameter</i> ANSI T1.413-1998
[no] etsi-dts	Parameter type: boolean	<i>optional parameter</i> ETSI DTS/TM06006
[no] g992-1-a	Parameter type: boolean	<i>optional parameter</i> G.992.1 POTS non-overlapped spectrum
[no] g992-1-b	Parameter type: boolean	<i>optional parameter</i> G.992.1 ISDN non-overlapped spectrum
[no] g992-2-a	Parameter type: boolean	<i>optional parameter</i> G.992.2 POTS non-overlapped spectrum
[no] g992-3-a	Parameter type: boolean	<i>optional parameter</i> G.992.3 POTS non-overlapped spectrum
[no] g992-3-b	Parameter type: boolean	<i>optional parameter</i> G.992.3 ISDN non-overlapped spectrum
[no] g992-3-aj	Parameter type: boolean	<i>optional parameter</i> G.992.3 all digital mode non-overlapped spectrum
[no] g992-3-l1	Parameter type: boolean	<i>optional parameter</i> G.992.3 POTS non-overlapped spectrum US mask 1
[no] g992-3-l2	Parameter type: boolean	<i>optional parameter</i> G.992.3 POTS non-overlapped spectrum US mask 2
[no] g992-3-am	Parameter type: boolean	<i>optional parameter</i>

Parameter	Type	Description
		G.992.3 extended POTS with non-overlapped spectrum
[no] g992-5-a	Parameter type: boolean	<i>optional parameter</i> G.992.5 POTS non-overlapped spectrum
[no] g992-5-b	Parameter type: boolean	<i>optional parameter</i> G.992.5 ISDN non-overlapped spectrum
[no] ansi-t1.424	Parameter type: boolean	<i>optional parameter</i> ANSI T1.424
[no] etsi-ts	Parameter type: boolean	<i>optional parameter</i> ETSI TS
[no] itu-g993-1	Parameter type: boolean	<i>optional parameter</i> ITU G993-1
[no] ieee-802.3ah	Parameter type: boolean	<i>optional parameter</i> IEEE 802.3ah
[no] g992-5-aj	Parameter type: boolean	<i>optional parameter</i> G.992.5 all digital mode non-overlapped spectrum
[no] g992-5-am	Parameter type: boolean	<i>optional parameter</i> G.992.5 extended POTS non-overlapped spectrum
[no] g993-2-8a	Parameter type: boolean	<i>optional parameter</i> G.993.2_8A VDSL-2 with profile 8A
[no] g993-2-8b	Parameter type: boolean	<i>optional parameter</i> G.993.2_8B VDSL-2 with profile 8B
[no] g993-2-8c	Parameter type: boolean	<i>optional parameter</i> G.993.2_8C VDSL-2 with profile 8C
[no] g993-2-8d	Parameter type: boolean	<i>optional parameter</i> G.993.2_8D VDSL-2 with profile 8D
[no] g993-2-12a	Parameter type: boolean	<i>optional parameter</i> G.993.2_12A VDSL-2 with profile 12A
[no] g993-2-12b	Parameter type: boolean	<i>optional parameter</i> G.993.2_12B VDSL-2 with profile 12B
[no] g993-2-17a	Parameter type: boolean	<i>optional parameter</i> G.993.2_17A VDSL-2 with profile 17A
[no] g993-2-30a	Parameter type: boolean	<i>optional parameter</i> G.993.2_30A VDSL-2 with profile 30A
[no] g993-2-35b	Parameter type: boolean	<i>optional parameter</i> G.993.2_35B VDSL-2 with profile 35B
[no] carrier-data-mode	Parameter type: <Xdsl::CarrierDataMode> Format: (off on on-init) Possible values: - off : disable the collection - on : enable the collection	<i>optional parameter with default value: "off"</i> carrier data measurement collection only applies to ADSLx/VDSLx. In G.fast mode the collection is fixed enabled.

9 xDSL Configuration Commands

Parameter	Type	Description
	- on-init : enable and re-initialize the line	
[no] admin-up	Parameter type: boolean	<i>optional parameter</i> set the admin-state of the line to up
bonding-mode	Parameter type: <Xdsl::BondingMode> Format: (native atm-bonding bonding) Possible values: - native : (deprecated)native mode for channel-1 - atm-bonding : (deprecated)atm bonding mode for channel-1 obsolete alternative replaced by bonding - bonding : (deprecated)bonding mode for channel-1	<i>obsolete parameter that will be ignored</i> channel-1 bonding mode
[no] transfer-mode	Parameter type: <Xdsl::TpsTcMode> Format: (atm ptm system-default) Possible values: - atm : atm mode - ptm : ptm mode - system-default : determined by the system, based on board type	<i>optional parameter with default value: "system-default"</i> tps tc mode
[no] imp-noise-sensor	Parameter type: boolean	<i>optional parameter</i> disable impulse noise monitoring on this xdsl line
[no] vect-qln-mode	Parameter type: <Xdsl::QLNmode> Format: (without-cancel with-cancel) Possible values: - without-cancel : without cancellation - with-cancel : with cancellation	<i>optional parameter with default value: "without-cancel"</i> specify the quiet line noise reporting mode
[no] auto-switch	Parameter type: boolean	<i>optional parameter</i> enable auto-switch feature on xdsl line
[no] vect-fallback	Parameter type: <Xdsl::LineFallbackMode> Format: (auto forced) Possible values: - auto : disable forced vectoring fallback on this xdsl line - forced : enable forced vectoring fallback on this xdsl line	<i>optional parameter with default value: "auto"</i> enable/disable forced vectoring fallback on this xdsl line

Command Output

Table 9.33-3 "xDSL Line Configuration Command" Display parameters

Specific Information		
name	Type	Description
service-profile-name	Parameter type: <Xdsl::IgnoredPrintableString> - ignored printable string	name of the service profile <i>This element is only shown in detail mode.</i>
spectrum-profile-name	Parameter type: <Xdsl::IgnoredPrintableString> - ignored printable string	name of the spectrum profile <i>This element is only shown in</i>

name	Type	Description
		<i>detail mode.</i>
dpbo-profile-name	Parameter type: <Xdsl::IgnoredPrintableString> - ignored printable string	name of the dpbo profile <i>This element is only shown in detail mode.</i>
rtx-profile-name	Parameter type: <Xdsl::IgnoredPrintableString> - ignored printable string	name of the rtx profile <i>This element is only shown in detail mode.</i>
vect-profile-name	Parameter type: <Xdsl::IgnoredPrintableString> - ignored printable string	name of the vectoring profile <i>This element is only shown in detail mode.</i>
override-state	Parameter type: <Xdsl::OverrideState> (not-created created-no-overrules created-overrules) Possible values: - not-created : not created - created-no-overrules : created no overrules - created-overrules : created overrules	indicates whether an override record is configured and if it are not all 'no-overrules' <i>This element is only shown in detail mode.</i>
sos-profile-name	Parameter type: <Xdsl::IgnoredPrintableString> - ignored printable string	name of the sos profile <i>This element is only shown in detail mode.</i>

9.34 xDSL Line TCA Threshold Configuration Command

Command Description

This command allows the operator to configure the Threshold Crossing Alert (TCA) thresholds. The configuration is specific per xdsl line.

User Level

The command can be accessed by operators with xdsl privileges, and executed by operators with xdsl privileges.

Command Syntax

The command has the following syntax:

```
> configure xdsl line (if-index) tca-line-threshold [ [ no ] enable ] [ no es-nearend | es-nearend
<Xdsl::IntervalTcaThreshold> ] [ no ses-nearend | ses-nearend <Xdsl::IntervalTcaThreshold> ] [ no uas-nearend |
uas-nearend <Xdsl::IntervalTcaThreshold> ] [ no leftr-nearend | leftr-nearend <Xdsl::IntervalTcaThreshold> ] [ no
leftr-day-nearend | leftr-day-nearend <Xdsl::DayTcaThreshold> ] [ no es-day-nearend | es-day-nearend
<Xdsl::DayTcaThreshold> ] [ no ses-day-nearend | ses-day-nearend <Xdsl::DayTcaThreshold> ] [ no
uas-day-nearend | uas-day-nearend <Xdsl::DayTcaThreshold> ] [ no es-farend | es-farend
<Xdsl::IntervalTcaThreshold> ] [ no ses-farend | ses-farend <Xdsl::IntervalTcaThreshold> ] [ no uas-farend |
uas-farend <Xdsl::IntervalTcaThreshold> ] [ no es-day-farend | es-day-farend <Xdsl::DayTcaThreshold> ] [ no
ses-day-farend | ses-day-farend <Xdsl::DayTcaThreshold> ] [ no uas-day-farend | uas-day-farend
<Xdsl::DayTcaThreshold> ] [ no leftr-farend | leftr-farend <Xdsl::IntervalTcaThreshold> ] [ no leftr-day-farend |
leftr-day-farend <Xdsl::DayTcaThreshold> ] [ no reinit | reinit <Xdsl::IntervalReinitTcaThreshold> ] [ no
reinit-day | reinit-day <Xdsl::IntervalDayReinitTcaThreshold> ]
```

Command Parameters

Table 9.34-1 "xDSL Line TCA Threshold Configuration Command" Resource Parameters

Resource Identifier	Type	Description
(if-index)	Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number	interface index of the line

Table 9.34-2 "xDSL Line TCA Threshold Configuration Command" Command Parameters

Parameter	Type	Description
[no] enable	Parameter type: boolean	<i>optional parameter</i> enable the reporting of TCA's for this xDSL line
[no] es-nearend	Parameter type: <Xdsl::IntervalTcaThreshold> Format: - the tca threshold for errored second, 0 - disable - range: [0...900]	<i>optional parameter with default value: 0</i> errored seconds at the near end
[no] ses-nearend	Parameter type: <Xdsl::IntervalTcaThreshold> Format: - the tca threshold for errored second, 0 - disable - range: [0...900]	<i>optional parameter with default value: 0</i> severely errored seconds at the near end
[no] uas-nearend	Parameter type: <Xdsl::IntervalTcaThreshold> Format: - the tca threshold for errored second, 0 - disable - range: [0...900]	<i>optional parameter with default value: 0</i> unavailable seconds at the near end
[no] leftr-nearend	Parameter type: <Xdsl::IntervalTcaThreshold> Format: - the tca threshold for errored second, 0 - disable - range: [0...900]	<i>optional parameter with default value: 0</i> leftr seconds at the near end
[no] leftr-day-nearend	Parameter type: <Xdsl::DayTcaThreshold> Format: - the tca threshold for a day errored second, 0 - disable - range: [0...86400]	<i>optional parameter with default value: 0</i> leftr seconds at the near end for a day
[no] es-day-nearend	Parameter type: <Xdsl::DayTcaThreshold> Format: - the tca threshold for a day errored second, 0 - disable - range: [0...86400]	<i>optional parameter with default value: 0</i> errored seconds at the near end for a day
[no] ses-day-nearend	Parameter type: <Xdsl::DayTcaThreshold> Format: - the tca threshold for a day errored second, 0 - disable - range: [0...86400]	<i>optional parameter with default value: 0</i> severely errored seconds at the near end for a day
[no] uas-day-nearend	Parameter type: <Xdsl::DayTcaThreshold> Format: - the tca threshold for a day errored second, 0 - disable - range: [0...86400]	<i>optional parameter with default value: 0</i> unavailable seconds at the near end for a day
[no] es-farend	Parameter type: <Xdsl::IntervalTcaThreshold> Format: - the tca threshold for errored second, 0 - disable - range: [0...900]	<i>optional parameter with default value: 0</i> errored seconds at the far end
[no] ses-farend	Parameter type: <Xdsl::IntervalTcaThreshold> Format: - the tca threshold for errored second, 0 - disable - range: [0...900]	<i>optional parameter with default value: 0</i> severely errored seconds at the far end
[no] uas-farend	Parameter type: <Xdsl::IntervalTcaThreshold> Format: - the tca threshold for errored second, 0 - disable - range: [0...900]	<i>optional parameter with default value: 0</i> unavailable seconds at the far end
[no] es-day-farend	Parameter type: <Xdsl::DayTcaThreshold> Format: - the tca threshold for a day errored second, 0 - disable - range: [0...86400]	<i>optional parameter with default value: 0</i> errored seconds at the far end for a day
[no] ses-day-farend	Parameter type: <Xdsl::DayTcaThreshold> Format: - the tca threshold for a day errored second, 0 - disable - range: [0...86400]	<i>optional parameter with default value: 0</i> severely errored seconds at the far end for a day
[no] uas-day-farend	Parameter type: <Xdsl::DayTcaThreshold> Format:	<i>optional parameter with default value: 0</i>

9 xDSL Configuration Commands

Parameter	Type	Description
	- the tca threshold for a day errored second, 0 - disable - range: [0...86400]	unavailable seconds at the far end for a day
[no] leftr-farend	Parameter type: <Xdsl::IntervalTcaThreshold> Format: - the tca threshold for errored second, 0 - disable - range: [0...900]	<i>optional parameter with default value: 0</i> leftr seconds at the far end
[no] leftr-day-farend	Parameter type: <Xdsl::DayTcaThreshold> Format: - the tca threshold for a day errored second, 0 - disable - range: [0...86400]	<i>optional parameter with default value: 0</i> leftr seconds at the far end for a day
[no] reinit	Parameter type: <Xdsl::IntervalReinitTcaThreshold> Format: - a tca threshold for reinit - range: [0...2147483647]	<i>optional parameter with default value: 0</i> reinit threshold for 15 min interval
[no] reinit-day	Parameter type: <Xdsl::IntervalDayReinitTcaThreshold> Format: - a tca threshold for reinit - range: [0...2147483647]	<i>optional parameter with default value: 0</i> reinit threshold for 1 day interval

9.35 xDSL Per Line Override Configuration

Command

Command Description

This command allows the operator to manage part of the DSL OverrideData. The OverrideData parameters give the ability to the operator to override per-line parameters defined in service/spectrum / retransmission profiles.

RTX downstream/upstream parameters will be overruled when the retransmission feature in downstream/upstream is different from "forbidden" value on the line. As long as the RTX downstream/upstream feature has not been enabled, the other RTX downstream/upstream parameters will have no effect on the line.

User Level

The command can be accessed by operators with xdsl privileges, and executed by operators with xdsl privileges.

Command Syntax

The command has the following syntax:

```
> configure xdsl ( no override-data (if-index) ) | ( override-data (if-index) [ no max-bitrate-down |
max-bitrate-down <Xdsl::OverrideBitRate> ] [ no max-bitrate-up | max-bitrate-up <Xdsl::OverrideBitRate> ] [ no
max-delay-down | max-delay-down <Xdsl::OverrideInterleavingDelay> ] [ no max-delay-up | max-delay-up
<Xdsl::OverrideInterleavingDelay> ] [ no imp-noise-prot-dn | imp-noise-prot-dn
<Xdsl::OverrideImpNoiseProtection> ] [ no imp-noise-prot-up | imp-noise-prot-up
<Xdsl::OverrideImpNoiseProtection> ] [ no trgt-noise-down | trgt-noise-down
<Xdsl::OverrideTargetNoiseMargin> ] [ no trgt-noise-up | trgt-noise-up <Xdsl::OverrideTargetNoiseMargin> ] [ no
max-psd-down | max-psd-down <Xdsl::OverridePsdLevel> ] [ no max-psd-up | max-psd-up
<Xdsl::OverridePsdLevel> ] [ no carrier-mask-down | carrier-mask-down <Xdsl::OverrideCarrierMaskDown> ] [
no carrier-mask-up | carrier-mask-up <Xdsl::OverrideCarrierMaskUp> ] [ no noise-psd-mode-dn |
noise-psd-mode-dn <Xdsl::OverrideNoiseModeDown> ] [ no noise-psd-mode-up | noise-psd-mode-up
<Xdsl::OverrideNoiseModeUp> ] [ no rtx-mode-dn | rtx-mode-dn <Xdsl::RtxOverrideMode> ] [ no rtx-mode-up |
rtx-mode-up <Xdsl::RtxOverrideMode> ] [ no max-net-rate-dn | max-net-rate-dn <Xdsl::RtxRate> ] [ no
max-net-rate-up | max-net-rate-up <Xdsl::RtxRate> ] [ no max-exp-thrpt-dn | max-exp-thrpt-dn <Xdsl::RtxRate> ] [
no max-exp-thrpt-up | max-exp-thrpt-up <Xdsl::RtxRate> ] [ no min-inp-shine-dn | min-inp-shine-dn
<Xdsl::RtxShineImpNoiseProtection> ] [ no min-inp-shine-up | min-inp-shine-up
<Xdsl::RtxShineImpNoiseProtection> ] [ no min-inp-rein-dn | min-inp-rein-dn
<Xdsl::RtxReinImpNoiseProtection> ] [ no min-inp-rein-up | min-inp-rein-up <Xdsl::RtxReinImpNoiseProtection>
] [ no min-delay-dn | min-delay-dn <Xdsl::RtxOverrideMinDelay> ] [ no min-delay-up | min-delay-up
<Xdsl::RtxOverrideMinDelay> ] [ no rtx-max-delay-dn | rtx-max-delay-dn <Xdsl::RtxOverrideMaxDelay> ] [ no
rtx-max-delay-up | rtx-max-delay-up <Xdsl::RtxOverrideMaxDelay> ] [ no shine-ratio-dn | shine-ratio-dn
<Xdsl::RtxOverrideShineRatio> ] [ no shine-ratio-up | shine-ratio-up <Xdsl::RtxOverrideShineRatio> ] [ no
lefr-thresh-dn | lefr-thresh-dn <Xdsl::RtxOverrideLeftThreshold> ] [ no lefr-thresh-up | lefr-thresh-up
<Xdsl::RtxOverrideLeftThreshold> ] [ no memory-down | memory-down <Xdsl::OverrideMemoryDownstream> ]
[ no modification | modification <Xdsl::ModifyStatus> ] [ [ no ] active ] )
```

Command Parameters

Table 9.35-1 "xDSL Per Line Override Configuration Command" Resource Parameters

Resource Identifier	Type	Description
(if-index)	Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number	interface index of the port

Table 9.35-2 "xDSL Per Line Override Configuration Command" Command Parameters

Parameter	Type	Description
[no] max-bitrate-down	Parameter type: <Xdsl::OverrideBitRate> Format: (no-override <Xdsl::OverrideBitRate>) Possible values: - no-override : no override Field type <Xdsl::OverrideBitRate> - bitrate - unit: kbit/s - range: [0...2147483647]	optional parameter with default value: "no-override" maximum bitrate down
[no] max-bitrate-up	Parameter type: <Xdsl::OverrideBitRate> Format: (no-override <Xdsl::OverrideBitRate>) Possible values: - no-override : no override Field type <Xdsl::OverrideBitRate> - bitrate - unit: kbit/s - range: [0...2147483647]	optional parameter with default value: "no-override" maximum bitrate up
[no] max-delay-down	Parameter type: <Xdsl::OverrideInterleavingDelay> Format: (no-override <Xdsl::OverrideInterleavingDelay>) Possible values: - no-override : no override Field type <Xdsl::OverrideInterleavingDelay> - maximum interleaving delay - unit: ms - range: [1...63]	optional parameter with default value: "no-override" maximum interleaving delay down
[no] max-delay-up	Parameter type: <Xdsl::OverrideInterleavingDelay> Format: (no-override <Xdsl::OverrideInterleavingDelay>) Possible values: - no-override : no override Field type <Xdsl::OverrideInterleavingDelay> - maximum interleaving delay - unit: ms - range: [1...63]	optional parameter with default value: "no-override" maximum interleaving delay up
[no] imp-noise-prot-dn	Parameter type: <Xdsl::OverrideImpNoiseProtection>	optional parameter with default

Parameter	Type	Description
	Format: (no-override <Xdsl::OverrideImpNoiseProtection>) Possible values: - no-override : no override Field type <Xdsl::OverrideImpNoiseProtection> - minimum impulse noise protection - unit: 0.1 symbols - range: [0...160]	<i>value: "no-override"</i> minimum impulse noise protection down
[no] imp-noise-prot-up	Parameter type: <Xdsl::OverrideImpNoiseProtection> Format: (no-override <Xdsl::OverrideImpNoiseProtection>) Possible values: - no-override : no override Field type <Xdsl::OverrideImpNoiseProtection> - minimum impulse noise protection - unit: 0.1 symbols - range: [0...160]	<i>optional parameter with default value: "no-override"</i> minimum impulse noise protection up
[no] trgt-noise-down	Parameter type: <Xdsl::OverrideTargetNoiseMargin> Format: (no-override <Xdsl::OverrideTargetNoiseMargin>) Possible values: - no-override : no override Field type <Xdsl::OverrideTargetNoiseMargin> - target noise margin - unit: dB / 10 - range: [0...310]	<i>optional parameter with default value: "no-override"</i> target noise margin down
[no] trgt-noise-up	Parameter type: <Xdsl::OverrideTargetNoiseMargin> Format: (no-override <Xdsl::OverrideTargetNoiseMargin>) Possible values: - no-override : no override Field type <Xdsl::OverrideTargetNoiseMargin> - target noise margin - unit: dB / 10 - range: [0...310]	<i>optional parameter with default value: "no-override"</i> target noise margin up
[no] max-psd-down	Parameter type: <Xdsl::OverridePsdLevel> Format: (no-override no-constraint <Xdsl::OverridePsdLevel>) Possible values: - no-override : no override - no-constraint : no override Field type <Xdsl::OverridePsdLevel> - override psd level - unit: dBm/Hz * 1/10 - range: [-955...0]	<i>optional parameter with default value: "no-override"</i> maximum psd level down
[no] max-psd-up	Parameter type: <Xdsl::OverridePsdLevel> Format: (no-override no-constraint <Xdsl::OverridePsdLevel>) Possible values:	<i>optional parameter with default value: "no-override"</i> maximum psd level up

9 xDSL Configuration Commands

Parameter	Type	Description
	- no-override : no override - no-constraint : no override Field type <Xdsl::OverridePsdLevel> - override psd level - unit: dBm/Hz * 1/10 - range: [-955...0]	
[no] carrier-mask-down	Parameter type: <Xdsl::OverrideCarrierMaskDown> Format: (no-override <Xdsl::OverrideCarrierMaskDown>) Possible values: - no-override : no override Field type <Xdsl::OverrideCarrierMaskDown> - override carrier mask down - length: 64	optional parameter with default value: "no-override" override carrier mask down
[no] carrier-mask-up	Parameter type: <Xdsl::OverrideCarrierMaskUp> Format: (no-override <Xdsl::OverrideCarrierMaskUp>) Possible values: - no-override : no override Field type <Xdsl::OverrideCarrierMaskUp> - override carrier mask up - length: 8	optional parameter with default value: "no-override" override carrier mask up
[no] noise-psd-mode-dn	Parameter type: <Xdsl::OverrideNoiseModeDown> Format: (no-override virtual artificial) Possible values: - no-override : no override - virtual : override Tx referred virtual noise - artificial : override artificial noise	optional parameter with default value: "no-override" noise override mode
[no] noise-psd-mode-up	Parameter type: <Xdsl::OverrideNoiseModeUp> Format: (no-override virtual virtual-rx) Possible values: - no-override : no override - virtual : override Tx referred virtual noise - virtual-rx : override Rx referred virtual noise	optional parameter with default value: "no-override" noise override mode
[no] rtx-mode-dn	Parameter type: <Xdsl::RtxOverrideMode> Format: (forbidden preferred forced testmode nooverride) Possible values: - forbidden : retransmission forbidden in down/upstream - preferred : retransmission preferred in down/upstream - forced : retransmission forced in down/upstream - testmode : retransmission testmode in down/upstream - nooverride : retransmission nooverride in down/upstream	optional parameter with default value: "nooverride" override retransmission mode in downstream on lines
[no] rtx-mode-up	Parameter type: <Xdsl::RtxOverrideMode> Format: (forbidden preferred forced testmode nooverride) Possible values: - forbidden : retransmission forbidden in down/upstream - preferred : retransmission preferred in down/upstream - forced : retransmission forced in down/upstream - testmode : retransmission testmode in down/upstream - nooverride : retransmission nooverride in down/upstream	optional parameter with default value: "nooverride" override retransmission mode in downstream on lines

Parameter	Type	Description
	(forbidden preferred forced testmode nooverrule) Possible values: - forbidden : retransmission forbidden in down/upstream - preferred : retransmission preferred in down/upstream - forced : retransmission forced in down/upstream - testmode : retransmission testmode in down/upstream - nooverrule : retransmission nooverrule in down/upstream	overrule retransmission mode in upstream on lines
[no] max-net-rate-dn	Parameter type: <Xdsl::RtxRate> Format: - a data rate value - unit: kbit/s - range: [-1,0...2147483647]	<i>optional parameter with default value: -1</i> overrule maximum net data rate for downstream direction, special value -1 means the rtxprofile parameter will not be overruled
[no] max-net-rate-up	Parameter type: <Xdsl::RtxRate> Format: - a data rate value - unit: kbit/s - range: [-1,0...2147483647]	<i>optional parameter with default value: -1</i> overrule maximum net data rate for upstream direction, special value -1 means the rtxprofile parameter will not be overruled
[no] max-exp-thrpt-dn	Parameter type: <Xdsl::RtxRate> Format: - a data rate value - unit: kbit/s - range: [-1,0...2147483647]	<i>optional parameter with default value: -1</i> overrule maximum expected throughput for downstream direction, special value -1 means the rtxprofile parameter will not be overruled
[no] max-exp-thrpt-up	Parameter type: <Xdsl::RtxRate> Format: - a data rate value - unit: kbit/s - range: [-1,0...2147483647]	<i>optional parameter with default value: -1</i> overrule maximum expected throughput for upstream direction, special value -1 means the rtxprofile parameter will not be overruled
[no] min-inp-shine-dn	Parameter type: <Xdsl::RtxShineImpNoiseProtection> Format: - minimum impulse noise protection - unit: DMT symbols - range: [-1,0...63]	<i>optional parameter with default value: -1</i> overrule minimum impulse noise protection against shine for downstream direction, special value -1 means the rtxprofile parameter will not be overruled
[no] min-inp-shine-up	Parameter type: <Xdsl::RtxShineImpNoiseProtection> Format: - minimum impulse noise protection - unit: DMT symbols - range: [-1,0...63]	<i>optional parameter with default value: -1</i> overrule minimum impulse noise protection against shine for upstream direction, special value -1 means the rtxprofile parameter will not be overruled
[no] min-inp-rein-dn	Parameter type: <Xdsl::RtxReinImpNoiseProtection> Format: - minimum impulse noise protection - unit: DMT symbols - range: [-1,0...7]	<i>optional parameter with default value: -1</i> overrule minimum impulse noise protection against rein for downstream direction, special value -1 means the rtxprofile

9 xDSL Configuration Commands

Parameter	Type	Description
		parameter will not be overruled
[no] min-inp-rein-up	Parameter type: <Xdsl::RtxReinImpNoiseProtection> Format: - minimum impulse noise protection - unit: DMT symbols - range: [-1,0...7]	<i>optional parameter with default value: -1</i> overrule minimum impulse noise protection against rein for upstream direction, special value -1 means the rtxprofile parameter will not be overruled
[no] min-delay-dn	Parameter type: <Xdsl::RtxOverruleMinDelay> Format: - a delay time period - unit: msec - range: [-1,0...63]	<i>optional parameter with default value: -1</i> overrule minimum instantaneous delay allowed (due to the effect of retransmission) for downstream direction, special value -1 means the rtxprofile parameter will not be overruled
[no] min-delay-up	Parameter type: <Xdsl::RtxOverruleMinDelay> Format: - a delay time period - unit: msec - range: [-1,0...63]	<i>optional parameter with default value: -1</i> overrule minimum instantaneous delay allowed (due to the effect of retransmission) for upstream direction, special value -1 means the rtxprofile parameter will not be overruled
[no] rtx-max-delay-dn	Parameter type: <Xdsl::RtxOverruleMaxDelay> Format: - a delay time period - unit: msec - range: [-1,2...63]	<i>optional parameter with default value: -1</i> overrule maximum instantaneous delay allowed (due to the effect of retransmission) for downstream direction, special value -1 means the rtxprofile parameter will not be overruled
[no] rtx-max-delay-up	Parameter type: <Xdsl::RtxOverruleMaxDelay> Format: - a delay time period - unit: msec - range: [-1,2...63]	<i>optional parameter with default value: -1</i> overrule maximum instantaneous delay allowed (due to the effect of retransmission) for upstream direction, special value -1 means the rtxprofile parameter will not be overruled
[no] shine-ratio-dn	Parameter type: <Xdsl::RtxOverruleShineRatio> Format: - shine ratio - unit: 1/1000 - range: [-1,0...100]	<i>optional parameter with default value: -1</i> overrule shine ratio for downstream direction, special value -1 means the rtxprofile parameter will not be overruled
[no] shine-ratio-up	Parameter type: <Xdsl::RtxOverruleShineRatio> Format: - shine ratio - unit: 1/1000 - range: [-1,0...100]	<i>optional parameter with default value: -1</i> overrule shine ratio for upstream direction, special value -1 means the rtxprofile parameter will not be overruled
[no] leftr-thresh-dn	Parameter type: <Xdsl::RtxOverruleLeftrThreshold> Format: - near-end defect threshold - unit: 1/100 - range: [-1,0,1...99]	<i>optional parameter with default value: -1</i> overrule threshold for declaring a near-end defect in downstream direction, special value -1 means

Parameter	Type	Description
		the rtxprofile parameter will not be overruled
[no] leftr-thresh-up	Parameter type: <Xdsl::RtxOverrideLeftThreshold> Format: - near-end defect threshold - unit: 1/100 - range: [-1,0,1...99]	<i>optional parameter with default value: -1</i> override threshold for declaring a far-end defect in upstream direction, special value -1 means the rtxprofile parameter will not be overruled
[no] memory-down	Parameter type: <Xdsl::OverrideMemoryDownstream> Format: - override the configured interleaver memory downstream - unit: 1/100 - range: [-1,255,0...100]	<i>optional parameter with default value: -1</i> override configurable downstream memory
[no] modification	Parameter type: <Xdsl::ModifyStatus> Format: (start cancel complete) Possible values: - start : to start modifying the profile - cancel : to cancel the modifications done - complete : to complete the modifications	<i>optional parameter with default value: "complete"</i> modify the profile
[no] active	Parameter type: boolean	<i>optional parameter</i> <i>The parameter is not visible during creation.</i> to activate the profile

9.36 xDSL Override Noise Psd Shape Downstream Configuration Command

Command Description

This command allows the operator to configure the virtual/artificial noise in downstream direction.

It helps operator to enter the virtual/artificial noise psd shape in a user-friendly way. The operator can enter numbers corresponding to frequency and psd level.

The downstream override noise PSD shape overrides the downstream virtual or artificial noise PSD shape configured in the profile, according to the setting of noise-psd-mode-dn

- *no-override:override noise PSD is ignored*
- *virtual:override noise PSD overrides the virtual noise PSD in the profile.*

In case no override noise PSD is specified (empty), v-noise-snr-down is set to mode-1, otherwise v-noise-snr-down is set to mode-2.

- *artificial: override noise PSD overrides the artificial noise PSD in the profile*

When all the (needed) parameters are configured, the complete Override Data has to be activated.

When all break points are set to default values (frequency 0, psd 0), the psd shape is cleared. To clear the entire shape at once, set the first two breakpoints to default values. Using this method, the psd shape mode will also be reset to the default value. When any other breakpoint is set to default values, all points following it will also be set to the default values.

When defining a PSD shape, a minimum of 2 PSD points should be specified. The successive PSD points must have increasing ($>/=$) frequencies. It is allowed that for two successive PSD points, different PSD levels are defined at a same frequency (brickwall).

User Level

The command can be accessed by operators with xdsl privileges, and executed by operators with xdsl privileges.

Command Syntax

The command has the following syntax:

```
> configure xdsl override-data (if-index) noise-psd-pt-down (psd-point) [ no frequency | frequency
<Xdsl::CustFreq> ] [ no psd | psd <Xdsl::CustPsd> ]
```

Command Parameters

Table 9.36-1 "xDSL Override Noise Psd Shape Downstream Configuration Command" Resource Parameters

Resource Identifier	Type	Description
(if-index)	Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId>	interface index of the port

Resource Identifier	Type	Description
	Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number	
(psd-point)	Format: - psd point - range: [1...32]	psd point

Table 9.36-2 "xDSL Override Noise Psd Shape Downstream Configuration Command" Command Parameters

Parameter	Type	Description
[no] frequency	Parameter type: <Xdsl::CustFreq> Format: - frequency - unit: khz - range: [0...35324]	<i>optional parameter with default value: 0L</i> psd frequency
[no] psd	Parameter type: <Xdsl::CustPsd> Format: - psd level - unit: $-2 \times (40 + \text{PSD level in dBm/Hz})$ - range: [0...200,255]	<i>optional parameter with default value: 0L</i> psd level

9.37 xDSL Override Noise Psd Shape Upstream Configuration Command

Command Description

This command allows the operator to configure the virtual noise in upstream direction.

It helps operator to enter the virtual noise psd shape in a user-friendly way. The operator can enter numbers corresponding to frequency and psd level.

When all the (needed) parameters are configured, the complete Override Data has to be activated.

When all break points are set to default values (frequency 0, psd 0), the psd shape is cleared. To clear the entire shape at once, set the first two breakpoints to default values. Using this method, the psd shape mode will also be reset to the default value. When any other breakpoint is set to default values, all points following it will also be set to the default values.

When defining a PSD shape, a minimum of 2 PSD points should be specified. The successive PSD points must have increasing ($\geq$) frequencies. It is allowed that for two successive PSD points, different PSD levels are defined at a same frequency (brickwall).

The upstream override noise PSD shape overrides the upstream virtual or artificial noise PSD shape configured in the profile, according to the setting of noise-psd-mode-up:

- *no-override:override noise PSD is ignored.*
- *virtual:override noise PSD overrides the virtual noise PSD in the profile. In case no override noise PSD is specified (empty), v-noise-snr-up is set to mode-1, otherwise v-noise-snr-up is set to mode-2.*
- *virtual-rx:override noise PSD overrides the virtual noise PSD in the profile. In case no override noise PSD is specified (empty), v-noise-snr-up is set to mode-1, otherwise v-noise-snr-up is set to mode-3.*

User Level

The command can be accessed by operators with xdsl privileges, and executed by operators with xdsl privileges.

Command Syntax

The command has the following syntax:

```
> configure xdsl override-data (if-index) noise-psd-pt-up (psd-point) [ no frequency | frequency <Xdsl::CustFreq> ]
[ no psd | psd <Xdsl::CustPsd> ]
```

Command Parameters

Table 9.37-1 "xDSL Override Noise Psd Shape Upstream Configuration Command" Resource Parameters

Resource Identifier	Type	Description
(if-index)	Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> Field type <Eqpt::RackId>	interface index of the port

Resource Identifier	Type	Description
	- the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number	
(psd-point)	Format: - psd point - range: [1...16]	psd point

Table 9.37-2 "xDSL Override Noise Psd Shape Upstream Configuration Command" Command Parameters

Parameter	Type	Description
[no] frequency	Parameter type: <Xdsl::CustFreq> Format: - frequency - unit: khz - range: [0...35324]	<i>optional parameter with default value: 0L</i> psd frequency
[no] psd	Parameter type: <Xdsl::CustPsd> Format: - psd level - unit: $-2 \times (40 + \text{PSD level in dBm/Hz})$ - range: [0...200,255]	<i>optional parameter with default value: 0L</i> psd level

9.38 xDSL INS Near End Configuration Command

Command Description

This command allows the operator to configure the Impulse-Noise-Sensor parameters for the near-end side.

The InmMode must be enabled first to be able to start monitoring. To stop monitoring on the line this InmMode must be disabled.

User Level

The command can be accessed by operators with xdsl privileges, and executed by operators with xdsl privileges.

Command Syntax

The command has the following syntax:

```
> configure xdsl imp-noise-sensor near-end (if-index) [ no inm-mode | inm-mode <Xdsl::InmMode> ] [ no inm-eq-inp-mode | inm-eq-inp-mode <Xdsl::InmEquivInpMode> ] [ no ins-sensitivity | ins-sensitivity <Xdsl::InsSensitivity> ] [ no inm-cluster-cont | inm-cluster-cont <Xdsl::ClusterContinuation> ] [ no inm-iat-offset | inm-iat-offset <Xdsl::InterArrivalTimeOffset> ] [ no inm-iat-step | inm-iat-step <Xdsl::InterArrivalTimeStep> ]
```

Command Parameters

Table 9.38-1 "xDSL INS Near End Configuration Command" Resource Parameters

Resource Identifier	Type	Description
(if-index)	Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number	interface index of the port

Table 9.38-2 "xDSL INS Near End Configuration Command" Command Parameters

Parameter	Type	Description
[no] inm-mode	Parameter type: <Xdsl::InmMode> Format: (disable enable) Possible values: - disable : disable impulse noise monitoring stats collection - enable : enable impulse noise monitoring stats collection	optional parameter with default value: "disable" enable upstr impulse noise monitoring stats collection
[no] inm-eq-inp-mode	Parameter type: <Xdsl::InmEquivInpMode> Format:	optional parameter with default value: "mode-0"

Parameter	Type	Description
	(mode-0 mode-1 mode-2 mode-3) Possible values: - mode-0 : impulse length - mode-1 : cluster length - mode-2 : sum of impulse length in cluster - mode-3 : gap compensated impulse length in cluster	equivalent INP mode used for the construction of the INM equivalent INP histograms
[no] ins-sensitivity	Parameter type: <Xdsl::InsSensitivity> Format: - impulse noise sensitivity - unit: dB / 10 - range: [-128...127]	<i>optional parameter with default value: 0L</i> upstream impulse noise sensor sensitivity
[no] inm-cluster-cont	Parameter type: <Xdsl::ClusterContinuation> Format: (disabled <Xdsl::ClusterContinuation>) Possible values: - disabled : disable cluster continuation Field type <Xdsl::ClusterContinuation> - impulse noise cluster continuation - unit: DMT Symbol - range: [0...64]	<i>optional parameter with default value: "disabled"</i> upstream impulse noise cluster continuation
[no] inm-iat-offset	Parameter type: <Xdsl::InterArrivalTimeOffset> Format: - inter arrival time offset - unit: DMT Symbol - range: [3...511]	<i>optional parameter with default value: 3L</i> interval offset of upstr inter-arrival time histograms
[no] inm-iat-step	Parameter type: <Xdsl::InterArrivalTimeStep> Format: - inter arrival time step - range: [0...7]	<i>optional parameter with default value: 0L</i> interval width of upstr inter-arrival time histograms

9.39 xDSL INS Far End Configuration Command

Command Description

This command allows the operator to configure the Impulse-Noise-Sensor parameters for the far-end side.

The InmMode must be enabled first to be able to start monitoring. To stop monitoring on the line this InmMode must be disabled.

User Level

The command can be accessed by operators with xdsl privileges, and executed by operators with xdsl privileges.

Command Syntax

The command has the following syntax:

```
> configure xdsl imp-noise-sensor far-end (if-index) [ no inm-mode | inm-mode <Xdsl::InmMode> ] [ no
inm-eq-inp-mode | inm-eq-inp-mode <Xdsl::InmEquivInpMode> ] [ no ins-sensitivity | ins-sensitivity
<Xdsl::InsSensitivity> ] [ no inm-cluster-cont | inm-cluster-cont <Xdsl::ClusterContinuation> ] [ no inm-iat-offset |
inm-iat-offset <Xdsl::InterArrivalTimeOffset> ] [ no inm-iat-step | inm-iat-step <Xdsl::InterArrivalTimeStep> ]
```

Command Parameters

Table 9.39-1 "xDSL INS Far End Configuration Command" Resource Parameters

Resource Identifier	Type	Description
(if-index)	Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number	interface index of the port

Table 9.39-2 "xDSL INS Far End Configuration Command" Command Parameters

Parameter	Type	Description
[no] inm-mode	Parameter type: <Xdsl::InmMode> Format: (disable enable) Possible values: - disable : disable impulse noise monitoring stats collection - enable : enable impulse noise monitoring stats collection	optional parameter with default value: "disable" enable downstr impulse noise monitoring stats collection
[no] inm-eq-inp-mode	Parameter type: <Xdsl::InmEquivInpMode> Format:	optional parameter with default value: "mode-0"

Parameter	Type	Description
	(mode-0 mode-1 mode-2 mode-3) Possible values: - mode-0 : impulse length - mode-1 : cluster length - mode-2 : sum of impulse length in cluster - mode-3 : gap compensated impulse length in cluster	equivalent INP mode used for the construction of the INM equivalent INP histograms
[no] ins-sensitivity	Parameter type: <Xdsl::InsSensitivity> Format: - impulse noise sensitivity - unit: dB / 10 - range: [-128...127]	<i>optional parameter with default value: 0L</i> downstream impulse noise sensor sensitivity
[no] inm-cluster-cont	Parameter type: <Xdsl::ClusterContinuation> Format: (disabled <Xdsl::ClusterContinuation>) Possible values: - disabled : disable cluster continuation Field type <Xdsl::ClusterContinuation> - impulse noise cluster continuation - unit: DMT Symbol - range: [0...64]	<i>optional parameter with default value: "disabled"</i> downstream impulse noise cluster continuation
[no] inm-iat-offset	Parameter type: <Xdsl::InterArrivalTimeOffset> Format: - inter arrival time offset - unit: DMT Symbol - range: [3...511]	<i>optional parameter with default value: 3L</i> interval offset of dwnstr inter-arrival time histograms
[no] inm-iat-step	Parameter type: <Xdsl::InterArrivalTimeStep> Format: - inter arrival time step - range: [0...7]	<i>optional parameter with default value: 0L</i> interval width of dwnstr inter-arrival time histograms

10- Gpon xDSL Configuration Commands

10.1 Gpon xDSL Configuration Command Tree	10-553
10.2 Gpon xDSL Common Service Profile Configuration Command	10-556
10.3 Gpon xDSL Common Spectrum Profile Configuration Command	10-559
10.4 Gpon xDSL Spectrum Profile for VDSL Configuration Command	10-562
10.5 Gpon xDSL Spectrum Profile for VDSL2 Configuration Command	10-564
10.6 VDSL2 Custom PSD shape Downstream Configuration Command	10-567
10.7 VDSL2 Custom PSD shape Upstream Configuration Command	10-569
10.8 ONT VDSL2 Virtual Noise Downstream Configuration Command	10-571
10.9 ONT VDSL2 Virtual Noise Upstream Configuration Command	10-573
10.10 Gpon xDSL Line Configuration Command	10-575
10.11 Xdsl ONT Uni Physical Layer Configuration Command	10-580
10.12 Xdsl ONT Uni Layer 2 Configuration Command	10-583
10.13 Gpon xDSL DPBO Profile Configuration Command	10-585
10.14 Gpon xDSL DPBO Mode Independent Custom PSD Mask Configuration Command	10-587
10.15 Gpon xDSL DPBO Exchange PSD Mask Configuration Command	10-589
10.16 Gpon xDSL ONT Configuration Command	10-591
10.17 Gpon xDSL Common Rtx Profile Configuration Command	10-593

10.1 Gpon xDSL Configuration Command Tree

Description

This chapter gives an overview of nodes that are handled by "Gpon xDSL Configuration Commands".

Command Tree

```

----configure
  ----xdsl
    ----ont
      ----[no] service-profile
        - (index)
        - name
        - [no] ra-mode-down
        - [no] ra-mode-up
        - [no] min-bitrate-down
        - [no] min-bitrate-up
        - [no] max-bitrate-down
        - [no] max-bitrate-up
        - [no] max-delay-down
        - [no] max-delay-up
        - [no] imp-noise-prot-dn
        - [no] imp-noise-prot-up
        - [no] active
      ----[no] spectrum-profile
        - (index)
        - name
        - [no] g992-1-a
        - [no] g992-5-a
        - [no] dis-g993-2-8c
        - [no] dis-g993-2-12b
        - [no] dis-g993-2-17a
        - [no] dis-g993-2-30a
        - [no] min-noise-down
        - [no] min-noise-up
        - [no] trgt-noise-down
        - [no] trgt-noise-up
        - [no] max-noise-down
        - [no] max-noise-up
        - [no] rf-band-list
        - [no] active
      ----vdsl
        - [no] vdsl-band-plan
        - [no] pbo-mode
        - [no] adsl-band
      ----vdsl2
        - [no] max-agpowlev-down
        - [no] psd-shape-down
        - [no] psd-pbo-e-len-up
        - [no] m-psd-level-down
        - [no] m-psd-level-up
        - [no] psd-pbo-par-a-up

```

- [no] psd-pbo-par-b-up
- [no] v-noise-snr-down
- [no] v-noise-snr-up
- [no] cust-psd-sc-down
- [no] cust-psd-ty-down
- [no] cust-psd-sc-up
- [no] cust-psd-ty-up
- cust-psd-pt-down**
 - **(psd-point)**
 - [no] frequency
 - [no] psd
- cust-psd-pt-up**
 - **(psd-point)**
 - [no] frequency
 - [no] psd
- v-noise-psd-pt-down**
 - **(psd-point)**
 - [no] frequency
 - [no] psd
- v-noise-psd-pt-up**
 - **(psd-point)**
 - [no] frequency
 - [no] psd
- line**
 - **(if-index)**
 - [no] service-profile
 - [no] spectrum-profile
 - [no] dpbo-profile
 - [no] up-rtx-profile
 - [no] down-rtx-profile
 - [no] g993-2-8c
 - [no] g993-2-12b
 - [no] g993-2-17a
 - [no] g993-2-30a
 - [no] transfer-mode
 - [no] carrier-data-mode
 - [no] pm-collect
 - [no] pwr-shed-override
 - [no] admin-state
- phy**
 - [no] pm
 - [no] tca
 - [no] ne-err-secs
 - [no] ne-sev-err-secs
 - [no] ne-unavail-secs
 - [no] fe-err-secs
 - [no] fe-sev-err-secs
 - [no] fe-unavail-secs
- l2**
 - [no] pm
 - [no] tca
 - [no] dropped-frames-up
 - [no] dropped-frames-dn
- [no] dpbo-profile**
 - **(index)**
 - name
 - [no] es-elect-length
 - [no] es-cable-model-a
 - [no] es-cable-model-b

```

- [no] es-cable-model-c
- [no] min-usable-signal
- [no] min-frequency
- [no] max-frequency
- [no] active
----micpsd-pt-down
- (psd-point)
- [no] frequency
- [no] psd
----epsd-pt-down
- (psd-point)
- [no] frequency
- [no] psd
----interface
- (if-index)
- [no] dpbo-profile
----[no] rtx-profile
- (index)
- name
- version
- [no] rtx-mode
- [no] min-exp-thrpt
- [no] max-exp-thrpt
- [no] max-net-rate
- [no] min-delay
- [no] max-delay
- [no] min-inp-shine
- [no] min-inp-rein
- [no] int-arr-time
- [no] shine-ratio
- [no] leftr-thresh
- [no] active

```

10.2 Gpon xDSL Common Service Profile Configuration Command

Command Description

This command allows the operator to manage the xDSL service profile.

NOTE: This command can be used only with profiles having LOCAL scope. Once a profile has been activated, no more edits are allowed.

WARNING: Service profiles not activated within 15 minutes of creation will be deleted.

DESCRIPTION FOR THE COMMAND PARAMETERS max-delay-down and max-delay-up: The delay is expressed in milliseconds. Range: 1 to 63 ms in steps of 1 ms with 1 as special value. The value 1 is used to specify that fast or pseudo fast latency (i.e. no interleaving).

User Level

The command can be accessed by operators with xdsl privileges, and executed by operators with xdsl privileges.

Command Syntax

The command has the following syntax:

```
> configure xdsl ont ( no service-profile (index) ) | ( service-profile (index) name <AsamProfileName> [ no
ra-mode-down | ra-mode-down <Gpon::RAModeType> ] [ no ra-mode-up | ra-mode-up <Gpon::RAModeType> ] [
no min-bitrate-down | min-bitrate-down <Xdsl::BitRate> ] [ no min-bitrate-up | min-bitrate-up <Xdsl::BitRate> ] [
no max-bitrate-down | max-bitrate-down <Xdsl::BitRate> ] [ no max-bitrate-up | max-bitrate-up <Xdsl::BitRate> ]
[ no max-delay-down | max-delay-down <Xdsl::InterleavingDelay> ] [ no max-delay-up | max-delay-up
<Xdsl::InterleavingDelay> ] [ no imp-noise-prot-dn | imp-noise-prot-dn <Xdsl::ImpNoiseProtection> ] [ no
imp-noise-prot-up | imp-noise-prot-up <Xdsl::ImpNoiseProtection> ] [ [ no ] active ] )
```

Command Parameters

Table 10.2-1 "Gpon xDSL Common Service Profile Configuration Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - a profile index value - range: [1...256]	index of the profile

Table 10.2-2 "Gpon xDSL Common Service Profile Configuration Command" Command Parameters

Parameter	Type	Description
name	Parameter type: <AsamProfileName> Format: - a profile name - range: [a-zA-Z0-9-_.] - length: 1<=x<=32	mandatory parameter profile name

Parameter	Type	Description
[no] ra-mode-down	Parameter type: <Gpon::RAModeType> Format: (operator-ctrlld automatic) Possible values: - operator-ctrlld : operator controlled rate adaptive mode in downstream - automatic : automatic rate adaptive mode at startup in downstream	<i>optional parameter with default value: "automatic"</i> rate adaptation mode for down stream
[no] ra-mode-up	Parameter type: <Gpon::RAModeType> Format: (operator-ctrlld automatic) Possible values: - operator-ctrlld : operator controlled rate adaptive mode in downstream - automatic : automatic rate adaptive mode at startup in downstream	<i>optional parameter with default value: "automatic"</i> rate adaptation mode for up stream
[no] min-bitrate-down	Parameter type: <Xdsl::BitRate> Format: - a bit rate value - unit: kbps - range: [0...2147483647]	<i>optional parameter with default value: 1024</i> minimum downstream bit rate to be maintained
[no] min-bitrate-up	Parameter type: <Xdsl::BitRate> Format: - a bit rate value - unit: kbps - range: [0...2147483647]	<i>optional parameter with default value: 64</i> minimum upstream bit rate to be maintained
[no] max-bitrate-down	Parameter type: <Xdsl::BitRate> Format: - a bit rate value - unit: kbps - range: [0...2147483647]	<i>optional parameter with default value: 6144</i> maximum bitrate in downstream
[no] max-bitrate-up	Parameter type: <Xdsl::BitRate> Format: - a bit rate value - unit: kbps - range: [0...2147483647]	<i>optional parameter with default value: 640</i> maximum bitrate in upstream
[no] max-delay-down	Parameter type: <Xdsl::InterleavingDelay> Format: - a delay time period - unit: msec - range: [1...63]	<i>optional parameter with default value: 16</i> maximum delay for interleaving function in downstream
[no] max-delay-up	Parameter type: <Xdsl::InterleavingDelay> Format: - a delay time period - unit: msec - range: [1...63]	<i>optional parameter with default value: 16</i> maximum delay for interleaving function in upstream
[no] imp-noise-prot-dn	Parameter type: <Xdsl::ImpNoiseProtection> Format: - minimum impulse noise protection - unit: 1/10 symbols - range: [0...160]	<i>optional parameter with default value: 0</i> minimum impulse noise protection in downstream
[no] imp-noise-prot-up	Parameter type: <Xdsl::ImpNoiseProtection> Format: - minimum impulse noise protection - unit: 1/10 symbols	<i>optional parameter with default value: 0</i> minimum impulse noise protection in upstream

Parameter	Type	Description
	- range: [0...160]	
[no] active	Parameter type: boolean	<i>optional parameter</i> <i>The parameter is not visible during creation.</i> to activate the profile

Command Output

Table 10.2-3 "Gpon xDSL Common Service Profile Configuration Command" Display parameters

Specific Information		
name	Type	Description
scope	Parameter type: <Xdsl::AsamProfileScope> local-profile Possible values: - local-profile : the local profile	scope of the profile <i>This element is only shown in detail mode.</i>
version	Parameter type: <SignedInteger> - a signed integer	version maintained by manager. only allowed value is 1 and cannot be incremented. <i>This element is only shown in detail mode.</i>
ref-count	Parameter type: <AsamProfileRefCount> - number of entities using this particular profile - range: [0...65535]	Indicates the number of entities using this profile. If the reference count is greater than 0, then this profile is 'in use', and may NOT be deleted. If the value is 0, then this profile is 'not in use', and can be deleted. <i>This element is only shown in detail mode.</i>

10.3 Gpon xDSL Common Spectrum Profile Configuration Command

Command Description

This command allows the operator to manage the xDSL spectrum profile. The spectrum profiles groups all parameters on xDSL on physical level. These parameters are mainly related to the environmental conditions of the line (spectrum management).

The Spectrum Configuration profile contains parameters which have a common value for all DSL flavors (Common) and parameters which have a specific value depending on the xDSL flavor used (VDSL,VDSL2).

The specific values depending on the xDSL flavor can be configured via:

- `configure xdsl spectrum-profile vdsl`
- `configure xdsl spectrum-profile vdsl2`

The actual selected operating mode determines which set of xDSL specific parameters is used. In case a common parameter is not supported for a specific xDSL flavor, this parameter will be ignored for that flavor.

When all the xDSL specific flavors are configure the complete profile has to be activated.

NOTE: This command can be used only with profiles having LOCAL scope. Once a profile has been activated, no more edits are allowed.

User Level

The command can be accessed by operators with `xdsl` privileges, and executed by operators with `xdsl` privileges.

Command Syntax

The command has the following syntax:

```
> configure xdsl ont ( no spectrum-profile (index) ) | ( spectrum-profile (index) name <AsamProfileName> [ [ no ]
g992-1-a ] [ [ no ] g992-5-a ] [ [ no ] dis-g993-2-8c ] [ [ no ] dis-g993-2-12b ] [ [ no ] dis-g993-2-17a ] [ [ no ]
dis-g993-2-30a ] [ no min-noise-down | min-noise-down <Xdsl::NoiseMargin> ] [ no min-noise-up | min-noise-up
<Xdsl::NoiseMargin> ] [ no trgt-noise-down | trgt-noise-down <Xdsl::NoiseMargin> ] [ no trgt-noise-up |
trgt-noise-up <Xdsl::NoiseMargin> ] [ no max-noise-down | max-noise-down <Xdsl::NoiseMarginPlus> ] [ no
max-noise-up | max-noise-up <Xdsl::NoiseMarginPlus> ] [ no rf-band-list | rf-band-list <Gpon::RFBand> ] [ [ no ]
active ] )
```

Command Parameters

Table 10.3-1 "Gpon xDSL Common Spectrum Profile Configuration Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - a profile index value - range: [1...256]	index of the profile.

Table 10.3-2 "Gpon xDSL Common Spectrum Profile Configuration Command" Command Parameters

Parameter	Type	Description
name	Parameter type: <AsamProfileName> Format: - a profile name - range: [a-zA-Z0-9-_.] - length: 1<=x<=32	<i>mandatory parameter</i> profile name
[no] g992-1-a	Parameter type: boolean	<i>optional parameter</i> G.992.1 POTS non-overlapped spectrum
[no] g992-5-a	Parameter type: boolean	<i>optional parameter</i> G.992.5 POTS non-overlapped spectrum
[no] dis-g993-2-8c	Parameter type: boolean	<i>optional parameter</i> disable G.993.2_8C VDSL-2 with profile 8C
[no] dis-g993-2-12b	Parameter type: boolean	<i>optional parameter</i> disable G.993.2_12B VDSL-2 with profile 12B
[no] dis-g993-2-17a	Parameter type: boolean	<i>optional parameter</i> disable G.993.2_17A VDSL-2 with profile 17A
[no] dis-g993-2-30a	Parameter type: boolean	<i>optional parameter</i> disable G.993.2_30A VDSL-2 with profile 30A
[no] min-noise-down	Parameter type: <Xdsl::NoiseMargin> Format: - a noise margin value - unit: 0.1 dB - range: [0...310]	<i>optional parameter with default value: 0</i> minimum noise margin in downstream
[no] min-noise-up	Parameter type: <Xdsl::NoiseMargin> Format: - a noise margin value - unit: 0.1 dB - range: [0...310]	<i>optional parameter with default value: 0</i> minimum noise margin in upstream
[no] trgt-noise-down	Parameter type: <Xdsl::NoiseMargin> Format: - a noise margin value - unit: 0.1 dB - range: [0...310]	<i>optional parameter with default value: 60</i> target noise margin in downstream
[no] trgt-noise-up	Parameter type: <Xdsl::NoiseMargin> Format: - a noise margin value - unit: 0.1 dB - range: [0...310]	<i>optional parameter with default value: 60</i> target noise margin in upstream
[no] max-noise-down	Parameter type: <Xdsl::NoiseMarginPlus> Format: - a normal noise margin value plus special value - unit: 0.1 dB - range: [0...310,511]	<i>optional parameter with default value: 511</i> maximum noise margin in downstream
[no] max-noise-up	Parameter type: <Xdsl::NoiseMarginPlus> Format: - a normal noise margin value plus special value - unit: 0.1 dB - range: [0...310,511]	<i>optional parameter with default value: 511</i> maximum noise margin in upstream
[no] rf-band-list	Parameter type: <Gpon::RFBand>	<i>optional parameter with default</i>

Parameter	Type	Description
	Format: - a variable length octet string defining rf band list - length: x<=80	value: "07 : 08 : 07 : D0 : 19 : 0D : AC : 0F : A0 : 19 : 1B : 58 : 1C : 84 : 19 : 27 : 74 : 27 : A6 : 19 : 36 : B0 : 38 : 0E : 19 : 46 : 94 : 46 : F8 : 19 : 52 : 08 : 53 : CA : 19 : 61 : 3A : 61 : 9E : 19 : 6D : 60 : 74 : 04 : 19" list of RF bands
[no] active	Parameter type: boolean	optional parameter The parameter is not visible during creation. to activate the profile

Command Output

Table 10.3-3 "Gpon xDSL Common Spectrum Profile Configuration Command" Display parameters

Specific Information		
name	Type	Description
scope	Parameter type: <Xdsl::AsamProfileScope> local-profile Possible values: - local-profile : the local profile	scope of the profile <i>This element is only shown in detail mode.</i>
version	Parameter type: <SignedInteger> - a signed integer	version maintained by manager <i>This element is only shown in detail mode.</i>
ref-count	Parameter type: <AsamProfileRefCount> - number of entities using this particular profile - range: [0...65535]	Indicates the number of entities using this profile. If the reference count is greater than 0, then this profile is 'in use', and may NOT be deleted. If the value is 0, then this profile is 'not in use', and can be deleted. <i>This element is only shown in detail mode.</i>

10.4 Gpon xDSL Spectrum Profile for VDSL Configuration Command

Command Description

This command allows the operator to manage the VDSL specific part of the DSL spectrum profile. The spectrum profiles groups all parameters on DSL on physical level. These parameters are mainly related to the environmental conditions of the line (spectrum management).

The Spectrum Configuration profile contains parameters which have a common value for all DSL flavors (Common) and parameters which have a specific value depending on the DSL flavor used (VDSL).

This chapter contains the VDSL flavor specific parameters.

Note: the activation of the profile has to be done via configure xdsl spectrum-profile.

User Level

The command can be accessed by operators with xdsl privileges, and executed by operators with xdsl privileges.

Command Syntax

The command has the following syntax:

```
> configure xdsl ont spectrum-profile (index) vdsl [ no vdsl-band-plan | vdsl-band-plan <Gpon::VdslBandPlan> ] [
no pbo-mode | pbo-mode <Gpon::PboModeVdsl> ] [ no adsl-band | adsl-band <Gpon::AdslBandUsage> ]
```

Command Parameters

Table 10.4-1 "Gpon xDSL Spectrum Profile for VDSL Configuration Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - a profile index value - range: [1...256]	index of the profile.

Table 10.4-2 "Gpon xDSL Spectrum Profile for VDSL Configuration Command" Command Parameters

Parameter	Type	Description
[no] vdsl-band-plan	Parameter type: <Gpon::VdslBandPlan> Format: (annex-a annex-b-997e annex-b-998e annex-b-998ade) Possible values: - annex-a : ITU-T G.993.2 VDSL2 Annex A (extended) band plan	<i>optional parameter with default value: "annex-a"</i> the VDSL band plan

Parameter	Type	Description
	- annex-b-997e : ITU-T G.993.2 VDSL2 Annex B band plan type 997E17 - annex-b-998e : ITU-T G.993.2 VDSL2 Annex B band plan type 998E17 - annex-b-998ade : ITU-T G.993.2 VDSL2 Annex B band plan type 998ADE17	
[no] pbo-mode	Parameter type: <Gpon::PboModeVdsl> Format: (pbo-mode-down pbo-mode-up) Possible values: - pbo-mode-down : upstream power backoff mode OFF - pbo-mode-up : upstream power backoff mode ON	<i>optional parameter with default value: "pbo-mode-up"</i> upstream power backoff mode
[no] adsl-band	Parameter type: <Gpon::AdslBandUsage> Format: (allow-adsl excl-adsl excl-adsl2plus excl-cust-adsl) Possible values: - allow-adsl : usage of adsl spectrum (25kHz..1.1mhz) is allowed - excl-adsl : usage of adsl spectrum (25kHz..1.1mhz) is not allowed - excl-adsl2plus : usage of adsl2plus spectrum (25kHz..2.2mhz) is not allowed - excl-cust-adsl : usage of adsl spectrum (25kHz..640kHz) is not allowed	<i>optional parameter with default value: "excl-adsl"</i> adsl band Usage

10.5 Gpon xDSL Spectrum Profile for VDSL2 Configuration Command

Command Description

This command allows the operator to manage the VDSL2 specific part of the xDSL spectrum profile. The spectrum profiles groups all parameters on xDSL on physical level. These parameters are mainly related to the environmental conditions of the line (spectrum management).

The Spectrum Configuration profile contains parameters which have a common value for all DSL flavors (Common) and parameters which have a specific value depending on the xDSL flavor used (VDSL, VDSL2).

This chapter contains the VDSL2 flavor specific parameters.

Note: the activation of the profile has to be done via `configure xdsl spectrum-profile`.

User Level

The command can be accessed by operators with `xdsl` privileges, and executed by operators with `xdsl` privileges.

Command Syntax

The command has the following syntax:

```
> configure xdsl ont spectrum-profile (index) vdsl2 [ no max-agpowlev-down | max-agpowlev-down
<Gpon::VdslPowerLevel> ] [ no psd-shape-down | psd-shape-down <Gpon::Vdsl2PsdShapeDown> ] [ no
psd-pbo-e-len-up | psd-pbo-e-len-up <Xdsl::PsdPboElectrLength> ] [ no m-psd-level-down | m-psd-level-down
<Gpon::MaxPsdLevel> ] [ no m-psd-level-up | m-psd-level-up <Gpon::MaxPsdLevel> ] [ no psd-pbo-par-a-up |
psd-pbo-par-a-up <Xdsl::ABParamType> ] [ no psd-pbo-par-b-up | psd-pbo-par-b-up <Xdsl::ABParamType> ] [ no
v-noise-snr-down | v-noise-snr-down <Xdsl::SnrmMode> ] [ no v-noise-snr-up | v-noise-snr-up
<Xdsl::SnrmModeUp> ] [ no cust-psd-sc-down | cust-psd-sc-down <Xdsl::PsdScaleBit> ] [ no cust-psd-ty-down |
cust-psd-ty-down <Xdsl::PsdTypeBit> ] [ no cust-psd-sc-up | cust-psd-sc-up <Xdsl::PsdScaleBit> ] [ no
cust-psd-ty-up | cust-psd-ty-up <Xdsl::PsdTypeBit> ]
```

Command Parameters

Table 10.5-1 "Gpon xDSL Spectrum Profile for VDSL2 Configuration Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - a profile index value - range: [1...256]	index of the profile.

Table 10.5-2 "Gpon xDSL Spectrum Profile for VDSL2 Configuration Command" Command Parameters

Parameter	Type	Description
[no] max-agpowlev-down	Parameter type: <Gpon::VdslPowerLevel> Format:	optional parameter with default value: 255

Parameter	Type	Description
	- a power level value - unit: 1/10 * dBm - range: [0...255]	maximum power allowed on the line in downstream
[no] psd-shape-down	Parameter type: <Gpon::Vdsl2PsdShapeDown> Format: (regiona-psd-down regionbm2-psd-down) Possible values: - regiona-psd-down : Region A spectral density in downstream - regionbm2-psd-down : Region BM2 spectral density in downstream	optional parameter with default value: "regiona-psd-down" power spectral density shape in downstream
[no] psd-pbo-e-len-up	Parameter type: <Xdsl::PsdPboElectrLength> Format: (estimated <Xdsl::PsdPboLength>) Possible values: - estimated : estimated electrical length Field type <Xdsl::PsdPboLength> - electrical parameter AB range - unit: 1/2 * dB - range: [0...255]	optional parameter with default value: "estimated" the electrical length to be used with the AB parameters
[no] m-psd-level-down	Parameter type: <Gpon::MaxPsdLevel> Format: - Max psd level - unit: 1/10 * dBm/Hz - range: [-600...-300]	optional parameter with default value: "-300" maximum PSD level for downstream
[no] m-psd-level-up	Parameter type: <Gpon::MaxPsdLevel> Format: - Max psd level - unit: 1/10 * dBm/Hz - range: [-600...-300]	optional parameter with default value: "-300" maximum PSD level for upstream
[no] psd-pbo-par-a-up	Parameter type: <Xdsl::ABParamType> Format: - binary string - length: 10	optional parameter with default value: "00 : 00 : 11 : 46 : 11 : 46 : 11 : 46 : 00 : 00" par A value for computing the PSD reference for US PBO
[no] psd-pbo-par-b-up	Parameter type: <Xdsl::ABParamType> Format: - binary string - length: 10	optional parameter with default value: "00 : 00 : 03 : 3c : 03 : 3c : 03 : 3c : 00 : 00" par B value for computing the PSD reference for US PBO
[no] v-noise-snr-down	Parameter type: <Xdsl::SnrmMode> Format: (mode-1 mode-2 mode-3) Possible values: - mode-1 : virtual noise disabled - mode-2 : Tx referred virtual noise enabled - mode-3 : Rx referred virtual noise enabled(not supported)	optional parameter with default value: "mode-1" downstream mode of virtual noise SNR margin
[no] v-noise-snr-up	Parameter type: <Xdsl::SnrmModeUp> Format: (mode-1 mode-2 mode-3) Possible values:	optional parameter with default value: "mode-1" upstream mode of virtual noise SNR Margin

10 Gpon xDSL Configuration Commands

Parameter	Type	Description
	- mode-1 : virtual noise disabled - mode-2 : Tx referred virtual noise enabled - mode-3 : Rx referred virtual noise enabled	
[no] cust-psd-sc-down	Parameter type: <Xdsl::PsdScaleBit> Format: (linear logarithmic) Possible values: - linear : linear scale - logarithmic : logarithmic scale	optional parameter with default value: "linear" psd scale
[no] cust-psd-ty-down	Parameter type: <Xdsl::PsdTypeBit> Format: (mask template) Possible values: - mask : PSD mask - template : PSD template	optional parameter with default value: "mask" psd type
[no] cust-psd-sc-up	Parameter type: <Xdsl::PsdScaleBit> Format: (linear logarithmic) Possible values: - linear : linear scale - logarithmic : logarithmic scale	optional parameter with default value: "linear" psd scale
[no] cust-psd-ty-up	Parameter type: <Xdsl::PsdTypeBit> Format: (mask template) Possible values: - mask : PSD mask - template : PSD template	optional parameter with default value: "mask" psd type

Command Output

Table 10.5-3 "Gpon xDSL Spectrum Profile for VDSL2 Configuration Command" Display parameters

Specific Information		
name	Type	Description
rx-psd-shape-up	Parameter type: <Gpon::RxVdsl2PsdShapeUp> ab-param Possible values: - ab-param : ABParameter spectral density shape in upstream	the reference RX PSD shape for upstream <i>This element is only shown in detail mode.</i>

10.6 VDSL2 Custom PSD shape Downstream Configuration Command

Command Description

This command allows the operator to configure the VDSL2 custom psd shape in downstream direction.

It helps operator to enter the custom psd shape in a user-friendly way. Instead of entering octets the operator can enter numbers corresponding to frequency and psd.

When all break points are set to default values (frequency 0, psd 0), the psd shape is cleared. To clear the entire shape at once, set the first two breakpoints to default values. Using this method, the frequency scale and the psd shape type will also be reset to the default value. When any other breakpoint is set to default values, all points following it will also be set to the default values.

When defining a PSD shape, a minimum of 2 PSD points should be specified. The successive PSD points must have increasing ($>/=$) frequencies. It is allowed that for two successive PSD points, different PSD levels are defined at a same frequency (brickwall).

User Level

The command can be accessed by operators with xdsl privileges, and executed by operators with xdsl privileges.

Command Syntax

The command has the following syntax:

```
> configure xdsl ont spectrum-profile (index) vdsl2 cust-psd-pt-down (psd-point) [ no frequency | frequency
<Xdsl::CustFreq> ] [ no psd | psd <Xdsl::PsdLevel> ]
```

Command Parameters

Table 10.6-1 "VDSL2 Custom PSD shape Downstream Configuration Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - a profile index value - range: [1...256]	index of the profile.
(psd-point)	Format: - psd point - range: [1...32]	psd point

Table 10.6-2 "VDSL2 Custom PSD shape Downstream Configuration Command" Command Parameters

Parameter	Type	Description
[no] frequency	Parameter type: <Xdsl::CustFreq> Format: - frequency	optional parameter with default value: 0 psd frequency

10 Gpon xDSL Configuration Commands

Parameter	Type	Description
	- unit: khz - range: [0...35324]	
[no] psd	Parameter type: <Xdsl::PsdLevel> Format: - psd level - unit: -0.5 * (PSD level in dBm/Hz) - range: [0...255]	<i>optional parameter with default value: 0</i> psd level

10.7 VDSL2 Custom PSD shape Upstream Configuration Command

Command Description

This command allows the operator to configure the VDSL2 custom psd shape in downstream direction.

It helps operator to enter the custom psd shape in a user-friendly way. Instead of entering octets the operator can enter numbers corresponding to frequency and psd.

When all break points are set to default values (frequency 0, psd 0), the psd shape is cleared. To clear the entire shape at once, set the first two breakpoints to default values. Using this method, the frequency scale and the psd shape type will also be reset to the default value. When any other breakpoint is set to default values, all points following it will also be set to the default values.

When defining a PSD shape, a minimum of 2 PSD points should be specified. The successive PSD points must have increasing ($>/=$) frequencies. It is allowed that for two successive PSD points, different PSD levels are defined at a same frequency (brickwall).

User Level

The command can be accessed by operators with xdsl privileges, and executed by operators with xdsl privileges.

Command Syntax

The command has the following syntax:

```
> configure xdsl ont spectrum-profile (index) vdsl2 cust-psd-pt-up (psd-point) [ no frequency | frequency
<Xdsl::CustFreq> ] [ no psd | psd <Xdsl::PsdLevel> ]
```

Command Parameters

Table 10.7-1 "VDSL2 Custom PSD shape Upstream Configuration Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - a profile index value - range: [1...256]	index of the profile.
(psd-point)	Format: - psd point - range: [1...20]	psd point

Table 10.7-2 "VDSL2 Custom PSD shape Upstream Configuration Command" Command Parameters

Parameter	Type	Description
[no] frequency	Parameter type: <Xdsl::CustFreq> Format: - frequency	optional parameter with default value: 0 psd frequency

10 Gpon xDSL Configuration Commands

Parameter	Type	Description
	- unit: khz - range: [0...35324]	
[no] psd	Parameter type: <Xdsl::PsdLevel> Format: - psd level - unit: -0.5 * (PSD level in dBm/Hz) - range: [0...255]	<i>optional parameter with default value: 0</i> psd level

10.8 ONT VDSL2 Virtual Noise Downstream Configuration Command

Command Description

This command allows the operator to configure ONT VDSL2 virtual noise in downstream direction.

It helps operator to enter the virtual noise in a user-friendly way. Instead of entering octets, as was the case with the earlier command, the operator can enter numbers corresponding to frequency and psd.

When all break points are set to default values (frequency 0, psd 0), the psd shape is cleared. To clear the entire shape at once, set the first two breakpoints to default values. When any other breakpoint is set to default values, all points following it will also be set to the default values.

When defining a PSD shape, a minimum of 2 PSD points should be specified. The successive PSD points must have increasing ($\geq$) frequencies. It is allowed that for two successive PSD points, different PSD levels are defined at a same frequency (brickwall).

User Level

The command can be accessed by operators with xdsl privileges, and executed by operators with xdsl privileges.

Command Syntax

The command has the following syntax:

```
> configure xdsl ont spectrum-profile (index) vdsl2 v-noise-psd-pt-down (psd-point) [ no frequency | frequency <Xdsl::CustFreq> ] [ no psd | psd <Xdsl::CustPsdVdsl2VtNoise> ]
```

Command Parameters

Table 10.8-1 "ONT VDSL2 Virtual Noise Downstream Configuration Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - a profile index value - range: [1...256]	index of the profile.
(psd-point)	Format: - psd point - range: [1...32]	psd point

Table 10.8-2 "ONT VDSL2 Virtual Noise Downstream Configuration Command" Command Parameters

Parameter	Type	Description
[no] frequency	Parameter type: <Xdsl::CustFreq> Format: - frequency - unit: khz	optional parameter with default value: 0 psd frequency

10 Gpon xDSL Configuration Commands

Parameter	Type	Description
	- range: [0...35324]	
[no] psd	Parameter type: <Xdsl::CustPsdVdsl2VtNoise> Format: - psd level - unit: -2*(40+PSD level in dBm/Hz) - range: [0...200,255]	<i>optional parameter with default value: 0</i> psd level

10.9 ONT VDSL2 Virtual Noise Upstream Configuration Command

Command Description

This command allows the operator to configure ONT VDSL2 virtual noise in upstream direction.

It helps operator to enter the custom psd shape in a user-friendly way. Instead of entering octets, as was the case with the earlier command, the operator can enter numbers corresponding to frequency and psd.

When all break points are set to default values (frequency 0, psd 0), the psd shape is cleared. To clear the entire shape at once, set the first two breakpoints to default values. When any other breakpoint is set to default values, all points following it will also be set to the default values.

When defining a PSD shape, a minimum of 2 PSD points should be specified. The successive PSD points must have increasing ($>/=$) frequencies. It is allowed that for two successive PSD points, different PSD levels are defined at a same frequency (brickwall).

User Level

The command can be accessed by operators with xdsl privileges, and executed by operators with xdsl privileges.

Command Syntax

The command has the following syntax:

```
> configure xdsl ont spectrum-profile (index) vdsl2 v-noise-psd-pt-up (psd-point) [ no frequency | frequency <Xdsl::CustFreq> ] [ no psd | psd <Xdsl::CustPsdVdsl2VtNoise> ]
```

Command Parameters

Table 10.9-1 "ONT VDSL2 Virtual Noise Upstream Configuration Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - a profile index value - range: [1...256]	index of the profile.
(psd-point)	Format: - psd level - range: [1...16]	psd point

Table 10.9-2 "ONT VDSL2 Virtual Noise Upstream Configuration Command" Command Parameters

Parameter	Type	Description
[no] frequency	Parameter type: <Xdsl::CustFreq> Format: - frequency - unit: khz	optional parameter with default value: 0 psd frequency

10 Gpon xDSL Configuration Commands

Parameter	Type	Description
	- range: [0...35324]	
[no] psd	Parameter type: <Xdsl::CustPsdVdsl2VtNoise> Format: - psd level - unit: -2*(40+PSD level in dBm/Hz) - range: [0...200,255]	<i>optional parameter with default value: 0</i> psd level

10.10 Gpon xDSL Line Configuration Command

Command Description

This command allows the operator to configure the xDSL pon line.

For the configuration one should associate a spectrum and a service profile to the line. The op-mode controls the operational modes allowed on the line. It can be used to disable an operational mode that is enabled in the spectrum profile but is not allowed on the line. It uses the same bitmap coding as op-mode in the xDSL spectrum-profile. '0' is used as special value to indicate that all the modes supported by the line are allowed.

The modes which are not supported by the line must be disabled.

An operational mode is allowed on the line when it is enabled in the op-mode of the line configuration and the op-mode in the xDSL spectrum-profile.

To deconfigure a line the service-profile and spectrum-profile has to be put to 0.

User Level

The command can be accessed by operators with xdsl privileges, and executed by operators with xdsl privileges.

Command Syntax

The command has the following syntax:

```
> configure xdsl ont line (if-index) [ no service-profile | service-profile <Gpon::LineServiceProfile> ] [ no
spectrum-profile | spectrum-profile <Xdsl::OntLineSpectrumProfile> ] [ no dpbo-profile | dpbo-profile
<Xdsl::OntLineDpboProfile> ] [ no up-rtx-profile | up-rtx-profile <Xdsl::OntLineRtxProfile> ] [ no
down-rtx-profile | down-rtx-profile <Xdsl::OntLineRtxProfile> ] [ [ no ] g993-2-8c ] [ [ no ] g993-2-12b ] [ [ no ]
g993-2-17a ] [ [ no ] g993-2-30a ] [ no transfer-mode | transfer-mode <Gpon::TpsTcMode> ] [ no
carrier-data-mode | carrier-data-mode <Gpon::CarrierDataMode> ] [ no pm-collect | pm-collect
<Gpon::OntPmTcaCollect> ] [ [ no ] pwr-shed-override ] [ no admin-state | admin-state <Gpon::ItfAdminStatus> ]
```

Command Parameters

Table 10.10-1 "Gpon xDSL Line Configuration Command" Resource Parameters

Resource Identifier	Type	Description
(if-index)	Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Gpon::OntSlotId> / <Gpon::OntPortId> ng2 : <Ng2::ChannelGroup> / <Ng2::SubchannelGroup> / <Ng2::OntId> / <Gpon::OntSlotId> / <Gpon::OntPortId>) Possible values: - ng2 : ngpon2 style identification Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId>	interface index of the port

10 Gpon xDSL Configuration Commands

Resource Identifier	Type	Description
	- the LT slot number - Field type <Eqpt::PonId> - the PON identifier - Field type <Ng2::ChannelGroup> - channel group number - Field type <Ng2::SubchannelGroup> - subchannel group number - Field type <Eqpt::OntId> - the ONT identifier - Field type <Ng2::OntId> - the ONT identifier - Field type <Gpon::OntSlotId> - Gpon Ont Slot - range: [1...14] - Field type <Gpon::OntPortId> - Gpon Ont Port - range: [1...16]	

Table 10.10-2 "Gpon xDSL Line Configuration Command" Command Parameters

Parameter	Type	Description
[no] service-profile	Parameter type: <Gpon::LineServiceProfile> Format: (none <Gpon::SrvcProfilePointer> name : <PrintableString>) Possible values: - none : no profile to associate - name : profile name Field type <Gpon::SrvcProfilePointer> - profile index - range: [0...256] Field type <PrintableString> - printable string	<i>optional parameter with default value: "none"</i> service profile to be configured on this port
[no] spectrum-profile	Parameter type: <Xdsl::OntLineSpectrumProfile> Format: (none <Xdsl::ProfilePointer> name : <PrintableString>) Possible values: - none : no profile to associate - name : profile name Field type <Xdsl::ProfilePointer> - profile index - range: [0...256] Data driven field type Possible values are depending on the actual configuration and software. The currently allowed values can be shown with online-help.	<i>optional parameter with default value: "none"</i> spectrum profile to be configured on this port
[no] dpbo-profile	Parameter type: <Xdsl::OntLineDpboProfile> Format: (none <Xdsl::DpboProfilePointer> name : <PrintableString>) Possible values: - none : no profile to associate - name : profile name Field type <Xdsl::DpboProfilePointer>	<i>optional parameter with default value: "none"</i> dpbo profile to be configured on this port

Parameter	Type	Description
	- profile index - range: [0...50] Data driven field type Possible values are depending on the actual configuration and software. The currently allowed values can be shown with online-help.	
[no] up-rtx-profile	Parameter type: <Xdsl::OntLineRtxProfile> Format: (none <Xdsl::RtxProfilePointer> name : <PrintableString>) Possible values: - none : no profile to associate - name : profile name Field type <Xdsl::RtxProfilePointer> - profile index - range: [0...1024] Data driven field type Possible values are depending on the actual configuration and software. The currently allowed values can be shown with online-help.	<i>optional parameter with default value: "none"</i> Rtx profile to be configured upstream on this port
[no] down-rtx-profile	Parameter type: <Xdsl::OntLineRtxProfile> Format: (none <Xdsl::RtxProfilePointer> name : <PrintableString>) Possible values: - none : no profile to associate - name : profile name Field type <Xdsl::RtxProfilePointer> - profile index - range: [0...1024] Data driven field type Possible values are depending on the actual configuration and software. The currently allowed values can be shown with online-help.	<i>optional parameter with default value: "none"</i> Rtx profile to be configured downstream on this port
[no] g993-2-8c	Parameter type: boolean	<i>optional parameter</i> G.993.2_8C VDSL-2 with profile 8C
[no] g993-2-12b	Parameter type: boolean	<i>optional parameter</i> G.993.2_12B VDSL-2 with profile 12B
[no] g993-2-17a	Parameter type: boolean	<i>optional parameter</i> G.993.2_17A VDSL-2 with profile 17A
[no] g993-2-30a	Parameter type: boolean	<i>optional parameter</i> G.993.2_30A VDSL-2 with profile 30A
[no] transfer-mode	Parameter type: <Gpon::TpsTcMode> Format: ptm Possible values: - ptm : ptm mode	<i>optional parameter with default value: "ptm"</i> tps tc mode
[no] carrier-data-mode	Parameter type: <Gpon::CarrierDataMode> Format: (off on	<i>optional parameter with default value: "off"</i> carrier data measurement collection

10 Gpon xDSL Configuration Commands

Parameter	Type	Description
	on-init fail) Possible values: - off : disable the collection - on : enable the collection - on-init : enable and re-initialize the line - fail : failed to enable - do not use	
[no] pm-collect	Parameter type: <Gpon::OntPmTcaCollect> Format: (none pm-enable tca-enable) Possible values: - none : no pm - pm-enable : enable pm - tca-enable : enable tca	<i>optional parameter with default value: "none"</i> physical layer performance monitoring and tca enable
[no] pwr-shed-override	Parameter type: boolean	<i>optional parameter</i> port excluded from DSL class power shedding
[no] admin-state	Parameter type: <Gpon::ItfAdminStatus> Format: (up down) Possible values: - up : set the admin-state to up - down : set the admin-state to down	<i>optional parameter with default value: "down"</i> <i>The parameter is not visible during creation.</i> administrative status of the interface

Command Output

Table 10.10-3 "Gpon xDSL Line Configuration Command" Display parameters

Specific Information		
name	Type	Description
oper-state	Parameter type: <Itf::ifOperStatus> (up down testing unknown dormant no-value) Possible values: - up : up,traffic can pass - down : down,no traffic is passing - testing : testing,no traffic is passing - unknown : unknown - dormant : dormant,no traffic is passing - no-value : no entry in the table	the operational state of the interface <i>This element is always shown.</i>
service-profile-name	Parameter type: <Xdsl::IgnoredPrintableString> - ignored printable string	name of the service profile <i>This element is always shown.</i>
spectrum-profile-name	Parameter type: <Xdsl::IgnoredPrintableString> - ignored printable string	name of the spectrum profile <i>This element is always shown.</i>
up-rtx-profile-name	Parameter type: <Xdsl::IgnoredPrintableString> - ignored printable string	name of the Rtx profile in upstream <i>This element is always shown.</i>
down-rtx-profile-name	Parameter type: <Xdsl::IgnoredPrintableString> - ignored printable string	name of the Rtx profile in downstream <i>This element is always shown.</i>

10.11 Xdsl ONT Uni Physical Layer Configuration Command

Command Description

This command allows the operator to provision performance monitoring and threshold crossing alerts for an Xdsl ONT physical layer UNI.

User Level

The command can be accessed by operators with xdsl privileges, and executed by operators with xdsl privileges.

Command Syntax

The command has the following syntax:

```
> configure xdsl ont line (if-index) phy [ no pm | pm <Gpon::OntPmCollect> ] [ no tca | tca
<Gpon::OntPmCollect> ] [ no ne-err-secs | ne-err-secs <Gpon::ErroredSecondsThreshold> ] [ no ne-sev-err-secs |
ne-sev-err-secs <Gpon::ErroredSecondsThreshold> ] [ no ne-unavail-secs | ne-unavail-secs
<Gpon::ErroredSecondsThreshold> ] [ no fe-err-secs | fe-err-secs <Gpon::ErroredSecondsThreshold> ] [ no
fe-sev-err-secs | fe-sev-err-secs <Gpon::ErroredSecondsThreshold> ] [ no fe-unavail-secs | fe-unavail-secs
<Gpon::ErroredSecondsThreshold> ]
```

Command Parameters

Table 10.11-1 "Xdsl ONT Uni Physical Layer Configuration Command" Resource Parameters

Resource Identifier	Type	Description
(if-index)	Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Gpon::OntSlotId> / <Gpon::OntPortId> ng2 : <Ng2::ChannelGroup> / <Ng2::SubchannelGroup> / <Ng2::OntId> / <Gpon::OntSlotId> / <Gpon::OntPortId>) Possible values: - ng2 : ngpon2 style identification Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Ng2::ChannelGroup> - channel group number Field type <Ng2::SubchannelGroup> - subchannel group number	interface index of the port

Resource Identifier	Type	Description
	Field type <Eqpt::OntId> - the ONT identifier Field type <Ng2::OntId> - the ONT identifier Field type <Gpon::OntSlotId> - Gpon Ont Slot - range: [1...14] Field type <Gpon::OntPortId> - Gpon Ont Port - range: [1...16]	

Table 10.11-2 "Xdsl ONT Uni Physical Layer Configuration Command" Command Parameters

Parameter	Type	Description
[no] pm	Parameter type: <Gpon::OntPmCollect> Format: (enable disable) Possible values: - enable : enable PM - disable : disable PM	<i>optional parameter with default value: "disable"</i> physical layer pm collection
[no] tca	Parameter type: <Gpon::OntPmCollect> Format: (enable disable) Possible values: - enable : enable PM - disable : disable PM	<i>optional parameter with default value: "disable"</i> physical layer threshold crossing alerts
[no] ne-err-secs	Parameter type: <Gpon::ErroredSecondsThreshold> Format: (disable <Gpon::ErroredSecondsThreshold>) Possible values: - disable : disable tca Field type <Gpon::ErroredSecondsThreshold> - error count threshold (0-900) - range: [0...900]	<i>optional parameter with default value: "disable"</i> near end errored seconds threshold
[no] ne-sev-err-secs	Parameter type: <Gpon::ErroredSecondsThreshold> Format: (disable <Gpon::ErroredSecondsThreshold>) Possible values: - disable : disable tca Field type <Gpon::ErroredSecondsThreshold> - error count threshold (0-900) - range: [0...900]	<i>optional parameter with default value: "disable"</i> near end severely errored seconds threshold
[no] ne-unavail-secs	Parameter type: <Gpon::ErroredSecondsThreshold> Format: (disable <Gpon::ErroredSecondsThreshold>) Possible values: - disable : disable tca Field type <Gpon::ErroredSecondsThreshold> - error count threshold (0-900) - range: [0...900]	<i>optional parameter with default value: "disable"</i> near end unavailable seconds threshold
[no] fe-err-secs	Parameter type: <Gpon::ErroredSecondsThreshold> Format: (disable	<i>optional parameter with default value: "disable"</i> far end errored seconds threshold

10 Gpon xDSL Configuration Commands

Parameter	Type	Description
	<Gpon::ErroredSecondsThreshold>) Possible values: - disable : disable tca Field type <Gpon::ErroredSecondsThreshold> - error count threshold (0-900) - range: [0...900]	
[no] fe-sev-err-secs	Parameter type: <Gpon::ErroredSecondsThreshold> Format: (disable <Gpon::ErroredSecondsThreshold>) Possible values: - disable : disable tca Field type <Gpon::ErroredSecondsThreshold> - error count threshold (0-900) - range: [0...900]	<i>optional parameter with default value: "disable"</i> far end severely errored seconds threshold
[no] fe-unavail-secs	Parameter type: <Gpon::ErroredSecondsThreshold> Format: (disable <Gpon::ErroredSecondsThreshold>) Possible values: - disable : disable tca Field type <Gpon::ErroredSecondsThreshold> - error count threshold (0-900) - range: [0...900]	<i>optional parameter with default value: "disable"</i> far end unavailable seconds threshold

10.12 Xdsl ONT Uni Layer 2 Configuration

Command

Command Description

This command allows the operator to provision performance monitoring and threshold crossing alerts for a Xdsl ONT layer 2 UNI.

User Level

The command can be accessed by operators with xdsl privileges, and executed by operators with xdsl privileges.

Command Syntax

The command has the following syntax:

```
> configure xdsl ont line (if-index) l2 [ no pm | pm <Gpon::OntPmCollect> ] [ no tca | tca <Gpon::OntPmCollect> ]
[ no dropped-frames-up | dropped-frames-up <Gpon::ErrorCountThreshold> ] [ no dropped-frames-dn |
dropped-frames-dn <Gpon::ErrorCountThreshold> ]
```

Command Parameters

Table 10.12-1 "Xdsl ONT Uni Layer 2 Configuration Command" Resource Parameters

Resource Identifier	Type	Description
(if-index)	Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Gpon::OntSlotId> / <Gpon::OntPortId> ng2 : <Ng2::ChannelGroup> / <Ng2::SubchannelGroup> / <Ng2::OntId> / <Gpon::OntSlotId> / <Gpon::OntPortId>) Possible values: - ng2 : ngpon2 style identification Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Ng2::ChannelGroup> - channel group number Field type <Ng2::SubchannelGroup> - subchannel group number Field type <Eqpt::OntId> - the ONT identifier Field type <Ng2::OntId>	interface index of the port

10 Gpon xDSL Configuration Commands

Resource Identifier	Type	Description
	- the ONT identifier Field type <Gpon::OntSlotId> - Gpon Ont Slot - range: [1...14] Field type <Gpon::OntPortId> - Gpon Ont Port - range: [1...16]	

Table 10.12-2 "Xdsl ONT Uni Layer 2 Configuration Command" Command Parameters

Parameter	Type	Description
[no] pm	Parameter type: <Gpon::OntPmCollect> Format: (enable disable) Possible values: - enable : enable PM - disable : disable PM	<i>optional parameter with default value: "disable"</i> l2 pm collection
[no] tca	Parameter type: <Gpon::OntPmCollect> Format: (enable disable) Possible values: - enable : enable PM - disable : disable PM	<i>optional parameter with default value: "disable"</i> l2 threshold crossing alerts
[no] dropped-frames-up	Parameter type: <Gpon::ErrorCountThreshold> Format: (disable <Gpon::ErrorCountThreshold>) Possible values: - disable : disable tca Field type <Gpon::ErrorCountThreshold> - error count threshold (0-4294967295) - range: [0...4294967295]	<i>optional parameter with default value: "disable"</i> incoming (upstream) dropped frames threshold
[no] dropped-frames-dn	Parameter type: <Gpon::ErrorCountThreshold> Format: (disable <Gpon::ErrorCountThreshold>) Possible values: - disable : disable tca Field type <Gpon::ErrorCountThreshold> - error count threshold (0-4294967295) - range: [0...4294967295]	<i>optional parameter with default value: "disable"</i> outgoing (downstream) dropped frames threshold

10.13 Gpon xDSL DPBO Profile Configuration Command

Command Description

Downstream power back off profile to configure the modem for a physical Gpon line.

User Level

The command can be accessed by operators with xdsl privileges, and executed by operators with xdsl privileges.

Command Syntax

The command has the following syntax:

```
> configure xdsl ont ( no dpbo-profile (index) ) | ( dpbo-profile (index) name <AsamProfileName> [ no
es-elect-length | es-elect-length <Gpon::ElectricalLength> ] [ no es-cable-model-a | es-cable-model-a
<Gpon::CableModel> ] [ no es-cable-model-b | es-cable-model-b <Gpon::CableModel> ] [ no es-cable-model-c |
es-cable-model-c <Gpon::CableModel> ] [ no min-usable-signal | min-usable-signal
<Gpon::MinUsableSignalLevel> ] [ no min-frequency | min-frequency <Gpon::MinFrequency> ] [ no
max-frequency | max-frequency <Gpon::MaxFrequency> ] [ [ no ] active ] )
```

Command Parameters

Table 10.13-1 "Gpon xDSL DPBO Profile Configuration Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - a profile index value - range: [1...50]	index of profile

Table 10.13-2 "Gpon xDSL DPBO Profile Configuration Command" Command Parameters

Parameter	Type	Description
name	Parameter type: <AsamProfileName> Format: - a profile name - range: [a-zA-Z0-9-_.] - length: 1<=x<=32	<i>mandatory parameter</i> <i>The parameter is not visible during modification.</i> name of profile
[no] es-elect-length	Parameter type: <Gpon::ElectricalLength> Format: - electrical length (1/10 * electrical-length) - unit: 0.1 dB - range: [0...2555]	<i>optional parameter with default value: 0L</i> exchange side electrical length
[no] es-cable-model-a	Parameter type: <Gpon::CableModel> Format: - cable model param (2 ⁸ * cable-model) - unit: 2 ⁸ - range: [-256...384]	<i>optional parameter with default value: 0L</i> cable model a

10 Gpon xDSL Configuration Commands

Parameter	Type	Description
[no] es-cable-model-b	Parameter type: <Gpon::CableModel> Format: - cable model param ($2^8 * \text{cable-model}$) - unit: 2^8 - range: [-256...384]	<i>optional parameter with default value: 0L</i> cable model b
[no] es-cable-model-c	Parameter type: <Gpon::CableModel> Format: - cable model param ($2^8 * \text{cable-model}$) - unit: 2^8 - range: [-256...384]	<i>optional parameter with default value: 0L</i> cable model c
[no] min-usable-signal	Parameter type: <Gpon::MinUsableSignalLevel> Format: - minimum usable signal ($1/10 * \text{min-usable-signal}$) - unit: 0.1 dB - range: [-1275...0]	<i>optional parameter with default value: -1275L</i> minimal usable signal level
[no] min-frequency	Parameter type: <Gpon::MinFrequency> Format: - minimum frequency - unit: kHz - range: [0...8832]	<i>optional parameter with default value: 0L</i> min frequency
[no] max-frequency	Parameter type: <Gpon::MaxFrequency> Format: - maximum frequency - unit: kHz - range: [138...30000]	<i>optional parameter with default value: 30000L</i> max frequency
[no] active	Parameter type: boolean	<i>optional parameter to activate the profile</i>

10.14 Gpon xDSL DPBO Mode Independent Custom PSD Mask Configuration Command

Command Description

This command specifies PSD breakpoints of DPBO Mode Independent Custom PSD Mask. A number of 2 to 32 PSD breakpoints can be specified. This parameter matches the PSDMASKds parameter described in ITU-T G.997.1 This set of breakpoints may contain two subsets :

The first sub-set defines the DPBO Custom PSD Mask. It matches the DPBOPSDMASKds parameter described in ITU-T G.997.1 The second sub-set (if any), defines the DPBO Minimum Override Mask. It matches the DPBOLFO parameter described in ITU-T G.997.1 The successive PSD points of each sub-set must have increasing ($\geq$) frequencies. It is allowed that for two successive PSD points, different PSD levels are defined at a same frequency (brickwall).

The second sub-set starts at the first breakpoint whose frequency is lower than the frequency of the previous breakpoint.

When all break points are set to default values (frequency 0, psd 0), the psd shape is cleared. To clear the entire shape at once, set the first two breakpoints to default values. When any other breakpoint is set to default values, all points following it will also be set to the default values.

User Level

The command can be accessed by operators with xdsl privileges, and executed by operators with xdsl privileges.

Command Syntax

The command has the following syntax:

```
> configure xdsl ont dpbo-profile (index) micpsd-pt-down (psd-point) [ no frequency | frequency
<Xdsl::DpboFrequency> ] [ no psd | psd <Gpon::DpboCustomPsd> ]
```

Command Parameters

Table 10.14-1 "Gpon xDSL DPBO Mode Independent Custom PSD Mask Configuration Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - a profile index value - range: [1...50]	index of profile
(psd-point)	Format: - psd point - range: [1...32]	psd point

Table 10.14-2 "Gpon xDSL DPBO Mode Independent Custom PSD Mask Configuration Command" Command Parameters

10 Gpon xDSL Configuration Commands

Parameter	Type	Description
[no] frequency	Parameter type: <Xdsl::DpboFrequency> Format: - frequency - unit: khz - range: [0...35324]	<i>optional parameter with default value: 0L</i> psd frequency
[no] psd	Parameter type: <Gpon::DpboCustomPsd> Format: - psd level (-10 * PSD-level) - unit: -10*dBm/Hz - range: [0...950]	<i>optional parameter with default value: 0L</i> psd level

10.15 Gpon xDSL DPBO Exchange PSD Mask Configuration Command

Command Description

This command specifies the Assumed Exchange PSD mask to be protected by the DPBO shaping mechanism at the remote flexibility point. This parameter matches the DPBOEPSD parameter described in ITU-T G.997.1. A number of 2 to 16 PSD points can be specified. The successive PSD points must have increasing ($\geq$) frequencies. It is allowed that for two successive PSD points, different PSD levels are defined at a same frequency (brickwall).

Only PSD values within the standard range from -95 to 0 dBm/Hz are guaranteed.

When all break points are set to default values (frequency 0, psd 0), the psd shape is cleared. To clear the entire shape at once, set the first two breakpoints to default values. When any other breakpoint is set to default values, all points following it will also be set to the default values.

User Level

The command can be accessed by operators with xdsl privileges, and executed by operators with xdsl privileges.

Command Syntax

The command has the following syntax:

```
> configure xdsl ont dpbo-profile (index) epsd-pt-down (psd-point) [ no frequency | frequency
<Xdsl::DpboFrequency> ] [ no psd | psd <Gpon::DpboCustomPsd> ]
```

Command Parameters

Table 10.15-1 "Gpon xDSL DPBO Exchange PSD Mask Configuration Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - a profile index value - range: [1...50]	index of profile
(psd-point)	Format: - psd point - range: [1...16]	psd point

Table 10.15-2 "Gpon xDSL DPBO Exchange PSD Mask Configuration Command" Command Parameters

Parameter	Type	Description
[no] frequency	Parameter type: <Xdsl::DpboFrequency> Format: - frequency - unit: khz - range: [0...35324]	optional parameter with default value: 0L psd frequency
[no] psd	Parameter type: <Gpon::DpboCustomPsd>	optional parameter with default

10 Gpon xDSL Configuration Commands

Parameter	Type	Description
	Format: - psd level (-10 * PSD-level) - unit: -10*dBm/Hz - range: [0...950]	value: 0L psd level

10.16 Gpon xDSL ONT Configuration Command

Command Description

This command allows the operator to configure xdsl parameters at the GPON ONT Level.

An already existing Downstream-Power-Back-Off(DPBO)-profile can be attached to the GPON ONT.

All ports on this ont will use this DPBO-profile unless a line-specific DPBO-profile is configured.

To deconfigure the DPBO-profile, it has to be put to 0.

User Level

The command can be accessed by operators with xdsl privileges, and executed by operators with xdsl privileges.

Command Syntax

The command has the following syntax:

```
> configure xdsl ont interface (if-index) [ no dpbo-profile | dpbo-profile <Xdsl::LineDpboProfile> ]
```

Command Parameters

Table 10.16-1 "Gpon xDSL ONT Configuration Command" Resource Parameters

Resource Identifier	Type	Description
(if-index)	Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> ng2 : <Ng2::ChannelGroup> / <Ng2::SubchannelGroup> / <Ng2::OntId>) Possible values: - ng2 : ngpon2 style identification Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Ng2::ChannelGroup> - channel group number Field type <Ng2::SubchannelGroup> - subchannel group number Field type <Eqpt::OntId> - the ONT identifier Field type <Ng2::OntId> - the ONT identifier	identification of the port

Table 10.16-2 "Gpon xDSL ONT Configuration Command" Command Parameters

10 Gpon xDSL Configuration Commands

Parameter	Type	Description
[no] dpbo-profile	Parameter type: <Xdsl::LineDpboProfile> Format: (none <Xdsl::DpboProfilePointer> name : <PrintableString>) Possible values: - none : no profile to associate - name : profile name Field type <Xdsl::DpboProfilePointer> - profile index - range: [0...50] Field type <PrintableString> - printable string	<i>optional parameter with default value: "none"</i> dpbo profile index

10.17 Gpon xDSL Common Rtx Profile Configuration Command

Command Description

This command allows the operator to manage the xDSL rtx profile.

NOTE: This command can be used only with profiles having LOCAL scope. Once a profile has been activated, no more edits are allowed.

WARNING: Rtx profiles not activated within 15 minutes of creation will be deleted.

User Level

The command can be accessed by operators with xdsl privileges, and executed by operators with xdsl privileges.

Command Syntax

The command has the following syntax:

```
> configure xdsl ont ( no rtx-profile (index) ) | ( rtx-profile (index) name <AsamProfileName> [ version
<SignedInteger> ] [ no rtx-mode | rtx-mode <Xdsl::GRtxMode> ] [ no min-exp-thrpt | min-exp-thrpt
<Xdsl::BitRate> ] [ no max-exp-thrpt | max-exp-thrpt <Xdsl::BitRate> ] [ no max-net-rate | max-net-rate
<Xdsl::BitRate> ] [ no min-delay | min-delay <Xdsl::RtxMinDelay> ] [ no max-delay | max-delay
<Xdsl::RtxMaxDelay> ] [ no min-inp-shine | min-inp-shine <Xdsl::ShineImpNoiseProtection> ] [ no min-inp-rein |
min-inp-rein <Xdsl::ReinImpNoiseProtection> ] [ no int-arr-time | int-arr-time <Xdsl::RtxInterArrivalTime> ] [ no
shine-ratio | shine-ratio <Xdsl::RtxShineRatio> ] [ no leftr-thresh | leftr-thresh <Xdsl::RtxLeftrThreshold> ] [ no ]
active ] )
```

Command Parameters

Table 10.17-1 "Gpon xDSL Common Rtx Profile Configuration Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - a profile index value - range: [1...1024]	index of the profile

Table 10.17-2 "Gpon xDSL Common Rtx Profile Configuration Command" Command Parameters

Parameter	Type	Description
name	Parameter type: <AsamProfileName> Format: - a profile name - range: [a-zA-Z0-9-_.] - length: 1<=x<=32	mandatory parameter profile name
version	Parameter type: <SignedInteger> Format: - a signed integer	optional parameter version maintained by manager, usually 1 for new profile
[no] rtx-mode	Parameter type: <Xdsl::GRtxMode>	optional parameter with default

10 Gpon xDSL Configuration Commands

Parameter	Type	Description
	Format: (forbidden preferred forced testmode) Possible values: - forbidden : retransmission forbidden in down/upstream - preferred : retransmission preferred in down/upstream - forced : retransmission forced in down/upstream - testmode : retransmission testmode in down/upstream	<i>value: "preferred"</i> retransmission mode
[no] min-exp-thrpt	Parameter type: <Xdsl::BitRate> Format: - a bit rate value - unit: kbps - range: [0...2147483647]	<i>optional parameter with default value: 64</i> minimum expected throughput for downstream/upstream direction
[no] max-exp-thrpt	Parameter type: <Xdsl::BitRate> Format: - a bit rate value - unit: kbps - range: [0...2147483647]	<i>optional parameter with default value: 262143</i> maximum expected throughput for downstream/upstream direction
[no] max-net-rate	Parameter type: <Xdsl::BitRate> Format: - a bit rate value - unit: kbps - range: [0...2147483647]	<i>optional parameter with default value: 262143</i> maximum net data rate for downstream/upstream direction
[no] min-delay	Parameter type: <Xdsl::RtxMinDelay> Format: - a delay time period - unit: msec - range: [0...63]	<i>optional parameter with default value: 0</i> minimum instantaneous delay allowed (due to the effect of retransmission) for downstream/upstream direction
[no] max-delay	Parameter type: <Xdsl::RtxMaxDelay> Format: - a delay time period - unit: msec - range: [2...63]	<i>optional parameter with default value: 12</i> maximum instantaneous delay allowed (due to the effect of retransmission) for downstream direction
[no] min-inp-shine	Parameter type: <Xdsl::ShineImpNoiseProtection> Format: - minimum impulse noise protection - unit: DMT symbols - range: [0...63]	<i>optional parameter with default value: 8</i> minimum impulse noise protection against shine for downstream/upstream direction
[no] min-inp-rein	Parameter type: <Xdsl::ReinImpNoiseProtection> Format: - minimum impulse noise protection - unit: DMT symbols - range: [0...7]	<i>optional parameter with default value: 0</i> minimum impulse noise protection against rein for downstream/upstream direction
[no] int-arr-time	Parameter type: <Xdsl::RtxInterArrivalTime> Format: (derivedfrom100hz derivedfrom120hz) Possible values: - derivedfrom100hz : inter-arrival time derived from 100hz - derivedfrom120hz : inter-arrival time derived from 120hz	<i>optional parameter with default value: "derivedfrom100hz"</i> assumed inter-arrival time for rein protection for downstream/upstream direction
[no] shine-ratio	Parameter type: <Xdsl::RtxShineRatio> Format: - shine ratio	<i>optional parameter with default value: 10</i> shine ratio for

Parameter	Type	Description
	- unit: 1/1000 - range: [0...100]	downstream/upstream direction
[no] leftr-thresh	Parameter type: <Xdsl::RtxLeftrThreshold> Format: - near-end defect threshold - unit: 1/100 - range: [0,1...99]	<i>optional parameter with default value: 0</i> threshold for declaring a near-end defect in downstream/upstream direction
[no] active	Parameter type: boolean	<i>optional parameter</i> to activate the profile

Command Output

Table 10.17-3 "Gpon xDSL Common Rtx Profile Configuration Command" Display parameters

Specific Information		
name	Type	Description
ref-count	Parameter type: <AsamProfileRefCount> - number of entities using this particular profile - range: [0...65535]	Indicates the number of entities using this profile. If the reference count is greater than 0, then this profile is 'in use', and may NOT be deleted. If the value is 0, then this profile is 'not in use', and can be deleted. <i>This element is only shown in detail mode.</i>

11- xDSL System Configuration Commands

11.1 xDSL System Configuration Command Tree	11-597
11.2 xDSL System Automatic Port Reset Configuration Command	11-598

11.1 xDSL System Configuration Command Tree

Description

This chapter gives an overview of nodes that are handled by "xDSL System Configuration Commands".

Command Tree

```
----configure
  ----xdsl
    ----system
      ----auto-port-reset
        - [no] enable
```

11.2 xDSL System Automatic Port Reset Configuration Command

Command Description

This command allows the operator to enable auto-port-reset feature at system-level.

User Level

The command can be accessed by operators with xdsl privileges, and executed by operators with xdsl privileges.

Command Syntax

The command has the following syntax:

```
> configure xdsl system auto-port-reset [ [ no ] enable ]
```

Command Parameters

Table 11.2-2 "xDSL System Automatic Port Reset Configuration Command" Command Parameters

Parameter	Type	Description
[no] enable	Parameter type: boolean	<i>optional parameter</i> enable auto-port-reset

12- ATM Configuration Commands

12.1 ATM Configuration Command Tree	12-600
12.2 ATM PVC Configuration Command	12-601
12.3 IPOA X-connect L2 interworking port Configuration Command	12-603

12.1 ATM Configuration Command Tree

Description

This chapter gives an overview of nodes that are handled by "ATM Configuration Commands".

Command Tree

```
----configure
  ----atm
    ----[no] pvc
      - (port-index)
      - [no] admin-down
      - [no] aal5-encap-type
    ----X [no] ip-cross-connect
      - (interworking-port)
      - cpe
      - next-hop
```

12.2 ATM PVC Configuration Command

Command Description

This command allows the operator to configure an ATM PVC.

The admin status allows or disallows traffic on the PVC.

The encapsulation type configures the way higher-layer traffic is encapsulated in the AAL5 container.

The LLC Encapsulation method allows the multiplexing of multiple protocols over a single ATM VC. The protocol type of each PDU is identified by a prefixed IEEE 802.2 LLC header.

In the VC Multiplexing method, each ATM VC carries PDUs of exactly one protocol type. When multiple protocols must be transported, there is a separate VC for each protocol type.

Use of the encapsulations:

- *llc-snap and vc-mux-bridged-8023 can be used for cross-connects, ibridge, PPPoE, and IPoE*
- *llc-snap-routed and vc-mux-routed can be used for IPoA*
- *llc-nlpid and vc-mux-pppoa can be used for PPPoA*
- *none can be used for ATM pseudowire*

It is also possible to automatically detect the used encapsulation type on the link.

- *automatic:ip is used for auto-detection between llc-snap, vc-mux-bridged-8023, llc-snap-routed, and vc-mux-routed; ipoe and ipoa dataframes are accepted;*
- *automatic:ppp is used for auto-detection between llc-snap, vc-mux-bridged-8023, llc-nlpid, and vc-mux-pppoa; pppoa and pppoe dataframes are accepted;*
- *automatic:pppoa is used for auto-detection between llc-nlpid and vc-mux-pppoa, only pppoa dataframes are accepted;*
- *automatic:ipoe-ppp is used for auto-detection between llc-snap, vc-mux-bridged-8023, llc-nlpid and vc-mux-pppoa; ipoe, pppoa and pppoe dataframes are accepted;*

The only encapsulation type supported on L2 LTs is llc-snap.

User Level

The command can be accessed by operators with atm privileges, and executed by operators with atm privileges.

Command Syntax

The command has the following syntax:

```
> configure atm ( no pvc (port-index) ) | ( pvc (port-index) [ [ no ] admin-down ] [ no aal5-encap-type | aal5-encap-type <Atm::VccEncapType> ] )
```

Command Parameters

Table 12.2-1 "ATM PVC Configuration Command" Resource Parameters

Resource Identifier	Type	Description
(port-index)	Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> /	the atm static Interface with vpi and vci

Resource Identifier	Type	Description
	<Eqpt::PortId> : <Eqpt::VpiMandatoryId> : <Eqpt::VciMandatoryId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number Field type <Eqpt::VpiMandatoryId> - atm VPI Field type <Eqpt::VciMandatoryId> - atm VCI	

Table 12.2-2 "ATM PVC Configuration Command" Command Parameters

Parameter	Type	Description
[no] admin-down	Parameter type: boolean	<i>optional parameter</i> disable traffic flow
[no] aal5-encap-type	Parameter type: <Atm::VccEncapType> Format: (llc-snap llc-snap-routed llc-nlpid vc-mux-bridged-8023 vc-mux-routed vc-mux-pppoa none automatic : ip automatic : ppp automatic : pppoa automatic : ipoe-ppp) Possible values: - llc-snap : logical link control encapsulation bridged protocol - llc-snap-routed : logical link control encapsulation routed protocol - llc-nlpid : logical link control encapsulation pppoa protocol - vc-mux-bridged-8023 : virtual channel multiplex bridged protocol - vc-mux-routed : virtual channel multiplex routed protocol - vc-mux-pppoa : virtual channel multiplex pppoa protocol - automatic : automatic detection of encapsulation type - none : no encapsulation type Possible values: - ip : autodetection of the used ip encapsulation - ppp : autodetection of the used ppp encapsulation - pppoa : autodetection of the used pppoa encapsulation - ipoe-ppp : autodetection of the used ip or ppp encapsulation	<i>optional parameter with default value: "llc-snap"</i> <i>The parameter is not visible during modification.</i> encapsulation method for traffic in an AAL5 container

12.3 IPOA X-connect L2 interworking port Configuration Command

Command Description

Obsolete command, replaced by configure ipoa/e-iw.

This command allows the operator to configure the parameter on the IPOA X-connect L2 interworking port level

User Level

The command can be accessed by operators with atm privileges, and executed by operators with atm privileges.

Command Syntax

The command has the following syntax:

```
> configure atm ( no ip-cross-connect (interworking-port) ) | ( ip-cross-connect (interworking-port) [ cpe
<Ip::V4AddressHex> ] next-hop <Ip::V4AddressHex> )
```

Obsolete command, replaced by configure ipoa/e-iw.

Command Parameters

Table 12.3-1 "IPOA X-connect L2 interworking port Configuration Command" Resource Parameters

Resource Identifier	Type	Description
(interworking-port)	Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::VpiId> : <Eqpt::VciId> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId>) Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number Field type <Eqpt::VpiId> - atm VPI Field type <Eqpt::VciId> - atm VCI	index of rack/shelf/slot/port user-bridgeport

Table 12.3-2 "IPOA X-connect L2 interworking port Configuration Command" Command Parameters

12 ATM Configuration Commands

Parameter	Type	Description
cpe	Parameter type: <Ip::V4AddressHex> Format: - IPv4-address	<i>optional parameter</i> IP address for cpe
next-hop	Parameter type: <Ip::V4AddressHex> Format: - IPv4-address	<i>mandatory parameter</i> IP address for next hop

13- Interface Management Configuration Commands

13.1 Interface Management Configuration Command Tree	13-606
13.2 Network Interface Configuration Command	13-607
13.3 Extend Interface Configuration Command	13-613
13.4 Interface Alarm Configuration Command	13-614
13.5 Interface Sliding-Window Traffic Statistics Command	13-616
13.6 Cage mode configuration Command	13-617

13.1 Interface Management Configuration

Command Tree

Description

This chapter gives an overview of nodes that are handled by "Interface Management Configuration Commands".

Command Tree

```
----configure
  ----interface
    ----port
      - (port)
      - [no] admin-up
      X [no] link-state-trap
      - [no] link-updown-trap
      - [no] user
      - [no] severity
      - [no] port-type
    ----atm-pvc
      - (pvc-index)
      - [no] customer-id
    ----alarm
      - (index)
      - [no] default-severity
    ----statistics
      - (port)
      - [no] sliding-win-stats
    ----cage
      - (position)
      - operational-mode
```


13.2 Network Interface Configuration Command

Command Description

This command allows the operator to configure interface management parameters.

User Level

The command can be accessed by operators with equipment privileges, and executed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

```
> configure interface port (port) [ [ no ] admin-up ] [ no link-state-trap | link-state-trap <Itf::ifLinkUpDownTrap> ]
[ [ no ] link-updown-trap ] [ no user | user <Itf::asamIfExtCustomerId> ] [ no severity | severity
<Itf::asamIfExtAlmReportingSeverity> ] [ no port-type | port-type <Itf::asamIfPortType> ]
```

Command Parameters

Table 13.2-1 "Network Interface Configuration Command" Resource Parameters

Resource Identifier	Type	Description
(port)	Format: (xdsl-line : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> voicefxs : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> vlan-port:ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / <Eqpt::Ng2OntSlotId> / <Eqpt::Ng2OntPortId> : <Eqpt::UnstackedVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::VpiId> : <Eqpt::VciId> : <Eqpt::UnstackedVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::UnstackedVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::VpiId> : <Eqpt::VciId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan-port:ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / <Eqpt::Ng2OntSlotId> / <Eqpt::Ng2OntPortId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> ethernet-line : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId>	the interface index

13 Interface Management Configuration Commands

Resource Identifier	Type	Description
	atm-bonding : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> bonding : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> ip-gateway : <Eqpt::VrfId> ip-line : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::VpiId> : <Eqpt::VciId> ip-line : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> shdsl-line : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> e1-line : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> ima-group : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> ip-line : vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::VpiId> : <Eqpt::VciId> : <Eqpt::UnstackedVlan> ip-line : vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::UnstackedVlan> ip-line : vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::VpiId> : <Eqpt::VciId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> ip-line : vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / voip : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / vuni : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / voip : <Eqpt::UnstackedVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / vuni : <Eqpt::UnstackedVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> / <Eqpt::OntPortId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> / <Eqpt::OntPortId> : <Eqpt::UnstackedVlan> pon : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> ont : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> uni : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> / <Eqpt::OntPortId> voip : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> /	

Resource Identifier	Type	Description
	<pre> <Eqpt::LLId> : <Eqpt::UnstackedVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::LLId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> la-group : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> epon : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> eont : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> ellid : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::LLId> euni : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::EontSlotId> / <Eqpt::EontPortId> chpair : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::ChannelPairId> chgroup : <Eqpt::ChannelGroupId> subchgroup : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> ont.ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> uni.ng2 : <Eqpt::ChannelGroupId> / <Eqpt::Ng2OntId> / <Eqpt::Ng2OntSlotId> / <Eqpt::Ng2OntPortId> uni.ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / vuni voip.ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> vlan-port.ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / vuni : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan-port.ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / vuni : <Eqpt::UnstackedVlan> x-pon : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::XPonId> 25g-pon : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::M25GPonId>) Possible values: - xdsl-line : a static xdsl line interface - ethernet-line : a static ethernet line interface - atm-bonding : atm bonding obsolete alternative replaced by bonding - bonding : bonding - ip-gateway : ip user gateway interface - ip-line : ip line interface - shdsl-line : a shdsl line interface - e1-line : a e1 line interface - ima-group : an ima group interface - vlan-port : vlan port - vlan-port.ng2 : ngpon2 vlan port - pon : pon - x-pon : xgs pon - 25g-pon : 25g pon - chpair : channel pair - chgroup : channelgroup - subchgroup : subchannelgroup </pre>	

13 Interface Management Configuration Commands

Resource Identifier	Type	Description
	- ont : ont - ont:ng2 : ngpon2 ONT style identification - uni : uni - uni:ng2 : ngpon2 UNI style identification - voip : voip - voip:ng2 : voip - epon : epon - eont : epon ont - ellid : epon logical link - euni : euni - la-group : link aggregation group - voicefxs : voicefxs Possible values: - vlan : vlan port Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number Field type <Eqpt::VpiId> - atm VPI Field type <Eqpt::Vcild> - atm VCI Field type <Eqpt::PonId> - the PON identifier Field type <Eqpt::XPonId> - the XGS PON identifier Field type <Eqpt::M25GPonId> - the 25G PON identifier Field type <Eqpt::OntId> - the ONT identifier Field type <Eqpt::ChannelPairId> - the channel pair identifier Field type <Eqpt::ChannelGroupId> - the channel group identifier Field type <Eqpt::SubChannelGroupId> - the subchannel group identifier Field type <Eqpt::Ng2OntId> - the NG2 ONT identifier Possible values: - voip : virtual uni identifier obsolete alternative replaced by vuni - vuni : virtual uni identifier Possible values: - vuni : virtual NGPON2 uni identifier Field type <Eqpt::OntSlotId> - the ONT SLOT identifier Field type <Eqpt::OntPortId> - the ONT PORT identifier Field type <Eqpt::Ng2OntSlotId> - the NGPON2 ONT SLOT identifier Field type <Eqpt::Ng2OntPortId> - the NGPON2 ONT PORT identifier Field type <Eqpt::EontSlotId>	

Resource Identifier	Type	Description
	- Epon Ont Slot Field type <Eqpt::EontPortId> - Epon Ont Port Field type <Eqpt::LLId> - the LLID identifier, range 1 for EPON, range 1-8 for DPOE Possible values: - stacked : stacked vlan identity Field type <Eqpt::UnstackedVlan> - unstacked vlan id Field type <Eqpt::SVlan> - service vlan id Field type <Eqpt::CVlan> - customer vlan id Field type <Eqpt::Vrflid> - VRF id	

Table 13.2-2 "Network Interface Configuration Command" Command Parameters

Parameter	Type	Description
[no] admin-up	Parameter type: boolean	<i>optional parameter</i> admin status is up (read-only for voicefxs interface)
[no] link-state-trap	Parameter type: <Itf::ifLinkUpDownTrap> Format: (enable disable no-value) Possible values: - enable : enable link-up/link-down traps - disable : disable link-up/link-down traps - no-value : no valid value	<i>obsolete parameter replaced by parameter "link-updown-trap"</i> indicates if link-up/link-down traps should be generated
[no] link-updown-trap	Parameter type: boolean	<i>optional parameter</i> enable link-up/link-down traps
[no] user	Parameter type: <Itf::asamIfExtCustomerId> Format: - a string identifying the customer or user - length: x<=64	<i>optional parameter with default value: "available"</i> description of the user connected to this interface.
[no] severity	Parameter type: <Itf::asamIfExtAlmReportingSeverity> Format: (indeterminate warning minor major critical no-alarms default no-value) Possible values: - indeterminate : not a definite known severity - warning : just to inform as a warning - minor : not service affecting - major : service affecting - critical : service breaking - no-alarms : do not report alarm - default : take default as specified via Interface Alarm Configuration command - no-value : no entry in the table	<i>optional parameter with default value: "default"</i> set minimum severity for alarm to be reported, If ima is the only interface for which this parameter is not supported
[no] port-type	Parameter type: <Itf::asamIfPortType>	<i>optional parameter with default</i>

13 Interface Management Configuration Commands

Parameter	Type	Description
	Format: (uni nni hc-uni uplink) Possible values: - uni : uni port type - nni : nni port type - hc-uni : hicap uni port type - uplink : uplink port type	<i>value: "uni"</i> the whole network service model based on this interface

13.3 Extend Interface Configuration Command

Command Description

This command allows the operator to configure extended interface management parameters.

User Level

The command can be accessed by operators with equipment privileges, and executed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

```
> configure interface atm-pvc (pvc-index) [ no customer-id | customer-id <Itf::asamIfExtCustomerId> ]
```

Command Parameters

Table 13.3-1 "Extend Interface Configuration Command" Resource Parameters

Resource Identifier	Type	Description
(pvc-index)	Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::VpiId> : <Eqpt::VciId> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId>) Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number Field type <Eqpt::VpiId> - atm VPI Field type <Eqpt::VciId> - atm VCI	the ATM PVC interface index

Table 13.3-2 "Extend Interface Configuration Command" Command Parameters

Parameter	Type	Description
[no] customer-id	Parameter type: <Itf::asamIfExtCustomerId> Format: - a string identifying the customer or user - length: x<=64	<i>optional parameter with default value: "available"</i> Config the customerId per PVC

13.4 Interface Alarm Configuration Command

Command Description

This command allows the operator to configure the default severity for an alarm on this type of interface.

User Level

The command can be accessed by operators with equipment privileges, and executed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

```
> configure interface alarm (index) [ no default-severity | default-severity
<Itf::asamIfExtAlmReportingSeverityDefault> ]
```

Command Parameters

Table 13.4-1 "Interface Alarm Configuration Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: (xdsl-line ethernet-line shdsl-line voicefxs pon chpair chgroup subchgroup ont uni epon eont euni ellid lag ds1) Possible values: - xdsl-line : xdsl line - ethernet-line : ethernet line - shdsl-line : shdsl line - voicefxs : voicefxs - pon : pon interface - chpair : channelpair interface - chgroup : channelgroup interface - subchgroup : subchannelgroup interface - ont : ont interface	index of the IANA ifType

Resource Identifier	Type	Description
	- uni : uni interface - epon : epon interface - eont : epon ont interface - euni : epon uni interface - ellid : epon llid interface - lag : link aggregation group - ds1 : ds1 interface	

Table 13.4-2 "Interface Alarm Configuration Command" Command Parameters

Parameter	Type	Description
[no] default-severity	Parameter <Itf::asamIfExtAlmReportingSeverityDefault> Format: (indeterminate warning minor major critical) Possible values: - indeterminate : not a definite known severity - warning : just to inform as a warning - minor : not service affecting - major : service affecting - critical : service breaking	type: optional parameter with default value: "major" default severity to be reported

13.5 Interface Sliding-Window Traffic Statistics Command

Command Description

This command allows the operator to configure sliding-window traffic statistics on related interface.

User Level

The command can be accessed by operators with equipment privileges, and executed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

```
> configure interface statistics (port) [ no sliding-win-stats | sliding-win-stats <Itf::ifStatsEnable> ]
```

Command Parameters

Table 13.5-1 "Interface Sliding-Window Traffic Statistics Command" Resource Parameters

Resource Identifier	Type	Description
(port)	Format: chpair : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::ChannelPairId> Possible values: - chpair : channelpair Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::ChannelPairId> - the channel pair identifier	the interface index

Table 13.5-2 "Interface Sliding-Window Traffic Statistics Command" Command Parameters

Parameter	Type	Description
[no] sliding-win-stats	Parameter type: <Itf::ifStatsEnable> Format: (enable disable) Possible values: - enable : enable sliding-window traffic statistics - disable : disable sliding-window traffic statistics	<i>optional parameter with default value: "disable"</i> indicates if sliding-window traffic statistics be enabled

13.6 Cage mode configuration Command

Command Description

This command allows the operator to configure SLOT cage mode:

- The slot index of the cage
- The number of the sfp cage
- The index of rssi profile which would be configured on cage.

User Level

The command can be accessed by operators with equipment privileges, and executed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

```
> configure interface cage (position) [ operational-mode <Eqpt::AsamCageMode> ]
```

Command Parameters

Table 13.6-1 "Cage mode configuration Command" Resource Parameters

Resource Identifier	Type	Description
(position)	Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::AsamCageIndex> lt : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> : cage : <Eqpt::AsamCageIndex>) Possible values: - lt : lt-slot Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Possible values: - cage : cage operation mode Field type <Eqpt::AsamCageIndex> - the cage number - range: [1...16]	the physical cage position

Table 13.6-2 "Cage mode configuration Command" Command Parameters

Parameter	Type	Description
operational-mode	Parameter type: <Eqpt::AsamCageMode> Format: (not-set	<i>optional parameter</i> oper-mode of the cage

13 Interface Management Configuration Commands

Parameter	Type	Description
	gpon xgs mpm-gpon-xgs dual-gpon u-ngpon twenty-five-g ng-pon2 mpm-gpon-xgpon) Possible values: - not-set : cage mode set to not set - gpon : cage mode set to gpon - xgs : cage mode set to xgs - mpm-gpon-xgs : cage mode set to mpm-gpon-xgs - dual-gpon : cage mode set to dual-gpon - u-ngpon : cage mode set to u-ngpon - twenty-five-g : cage mode set to twentyfiveg - ng-pon2 : cage mode set to ng-pon2 - mpm-gpon-xgpon : cage mode set to mpm-gpon-xgpon	

14- Error Configuration Commands

14.1 Error Configuration Command Tree	14-620
14.2 Error Log Configuration Command	14-621

14.1 Error Configuration Command Tree

Description

This chapter gives an overview of nodes that are handled by "Error Configuration Commands".

Command Tree

```
----configure
  ----error
    - [no] log-full-action
```

14.2 Error Log Configuration Command

Command Description

This command allows the operator to configure parameters related to the error log.

User Level

The command can be accessed by operators with alarm privileges, and executed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> configure error [ no log-full-action | log-full-action <Error::errorLogFullAction> ]
```

Command Parameters

Table 14.2-2 "Error Log Configuration Command" Command Parameters

Parameter	Type	Description
[no] log-full-action	Parameter type: <Error::errorLogFullAction> Format: (wrap halt) Possible values: - wrap : older log records are overwritten by recent ones - halt : logging is stopped until the log buffer is reset	<i>optional parameter with default value: "wrap"</i> set the action when error log buffer is full

15- System Configuration Commands

15.1 System Configuration Command Tree	15-624
15.2 System Configuration Command	15-628
15.3 Configure system LEDs	15-632
15.4 System SNTP Configuration Command	15-633
15.5 System SNTP Server Table Configuration Command	15-634
15.6 System SNTP Server Table Configuration Command	15-635
15.7 System daylight saving time Configuration Command	15-636
15.8 System daylight saving time Configuration Command	15-637
15.9 System daylight saving time Configuration Command	15-638
15.10 System Loop ID Syntax Configuration Command	15-655
15.11 Maximum Lt Link Speed Configuration Command	15-658
15.12 System ONT Configuration Command	15-659
15.13 Epon System PM Configuration Command	15-661
15.14 System Synchronous Interface Timing Clock Configuration Command	15-662
15.15 System Clock Bits Mode Configuration Command	15-665
15.16 System Clock Source Priority Configuration Command	15-666
15.17 System Clock ToD Sources Priority Configuration Command	15-668
15.18 NTR PTP Configuration Command	15-670
15.19 NTR Clock Transmission Protocol Configuration Command	15-672
15.20 System Synchronous InterfaceTiming Clock Switching Mode configuration Command	15-674
15.21 NTR Acceptable Clock Master Configuration Command	15-675
15.22 PTP Slave Port DataSet Configuration Command	15-676
15.23 PTP Default Dataset Configuration Command	15-678
15.24 PTP Master Port DataSet Profile Configuration Command	15-680
15.25 PTP master port Configuration Commands	15-682
15.26 System Clock Synchronous Source port Configuration Command	15-685
15.27 PTP L2 port Configuration Commands	15-687
15.28 Clock ToD Parameters Configuration Command	15-689
15.29 1PPS ToD Interface Parameters Configuration Command	15-691
15.30 1PPS ToD Serial Parameters Configuration Command	15-693
15.31 ToD Holdover Specification Configuration Command	15-695
15.32 System Clock Synchronous Status Message Configuration Command	15-696
15.33 System Clock Synchronous Source port Configuration Command	15-699
15.34 System Clock Force Reference Configuration Command	15-701
15.35 SSMOut Configuration Command for synce ports	15-702
15.36 SSMOut Configuration Command for XDSL ports	15-704
15.37 T4 D-PLL Configuration Command	15-706

15.38 SyncE Configuration Command for FELT-B ports	15-708
15.39 ALS State Configuration Command	15-710
15.40 Configure system auto-switch	15-711
15.41 ZTP (Zero Touch Provision) State Configuration Command	15-712
15.42 System Relay ID Syntax Configuration Command	15-713
15.43 FIPS Configuration Command	15-715
15.44 NT SFTP Server Configuration Command	15-716
15.45 NT SFTP Server Credentials Configuration Command	15-717

15.1 System Configuration Command Tree

Description

This chapter gives an overview of nodes that are handled by "System Configuration Commands".

Command Tree

```
----configure
  ----system
    - [no] id
    - name
    - location
    - [no] access-oper-id
    - [no] system-40gkr4
    - contact-person
    - [no] en-snmp-auth-trap
    - nt-intercon-vlan
    - [no] periph-mgnt-vlan
    - internal-nw-vlan
    - [no] periph-mgnt-ctrl
    - system-mac
    - [no] port-num-in-proto
    - [no] ont-trc-dbg-vlan
    - [no] ntr-ssmout-vlan
    - [no] ntr-ptp-vlan
    - [no] customer-id
    - [no] voiceoswp
    - [no] scalingmode
    - [no] arp-polling-inter
    - [no] bsnap-state
    - bsnap-server-ip
    - bsnap-server-port
    - [no] arp-tca-threshold
  ----external-leds
    - [no] status
  ----sntp
    - server-ip-addr
    - [no] server-port
    - [no] polling-rate
    - [no] enable
    - [no] timezone-offset
  ----server-table
    ----[no] ip-address
      - (ip-addr)
      - [no] port
      - priority
    ----[no] ipv6-address
      - (ip-addr)
      - [no] port
      - priority
  ----dst
    - [no] enable
```

```

----[no] date
- timezone-offset
- start-time
- end-time
- [no] offset
----[no] recurring
- timezone-offset
- start-time
- end-time
- [no] offset
----loop-id-syntax
- [no] atm-based-dsl
- [no] efm-based-dsl
- [no] efm-based-pon
- [no] efm-based-epon
- [no] efm-based-ngpon2
----max-lt-link-speed
- [no] link-speed
----X pon-ont
- [no] slid-mode
- [no] pwrbrst-mode
- [no] sn-bundle-timer
- [no] sw-ver-mis-block
- [no] sn-autounlock
----epon
- [no] pm-collect
- [no] onuidmthd
- [no] rogueadmin
----sync-if-timing
- [no] revert
- [no] wait-time
- [no] output-ql-thresh
- [no] ssmout-en-bits
- [no] ssmout-ceiling
- [no] ais-sensitivity
----bits
- (interface-type)
----ref-order
- (index)
- (priority)
----tod-ref-order
- (index)
- (priority)
----ptp
- [no] transport-mode
- [no] dynamic-update
- [no] tc-step-mode
- [no] max-steps-removed
- [no] profile
----tx-protocol
- (index)
- [no] ip-addr
- [no] gateway-addr
- [no] vlan
----ptp-domain
- (index)
- [no] domain
----accept-master
- (index)

```

- [no] ip-addr
- [no] priority1
- [no] priority2
- slave-port-dataset**
 - **(index)**
 - [no] delay-mechanism
 - [no] delay-interval
 - [no] compensation
 - [no] sync-interval
 - [no] announce-interval
 - [no] multicast-mac
- default-dataset**
 - **(index)**
 - [no] priority1
 - [no] priority2
 - [no] clock-class
 - [no] clock-accuracy
 - [no] domain
- [no] mstr-port-ds-prof**
 - **(name)**
 - [no] delay-mechanism
 - [no] step-mode
 - [no] announce-interval
 - [no] sync-interval
 - [no] delay-interval
 - [no] multicast-mac
- [no] master-port**
 - **(port-idx)**
 - [no] admin-state
 - [no] mstr-port-ds-prof
 - [no] vlan-id
 - [no] pbit
 - [no] compensation
- link-port-compensation**
 - **(port)**
 - [no] compensation
- [no] l2-ptp-port**
 - **(port-idx)**
 - [no] admin-state
 - [no] priority
 - [no] vlan-id
 - [no] multi-address
- tod**
 - format
 - leapsecond
 - leapsecond-adjust-val
 - leapsecond-adjust-date
- interface**
 - **(index)**
 - [no] direction
 - [no] admin-state
 - [no] cable-comp
- serial-param**
 - **(index)**
 - [no] baud-rate
 - [no] data-bit
 - [no] stop-bit
 - [no] parity
- holdover-spec**

- [no] duration
- [no] clockclass
- ssm**
 - **(index)**
 - [no] ssmenable
 - [no] default-ql
 - [no] target-ql
- synce**
 - **(index)**
 - (port)
- force-reference**
 - (force-reference)
- ssmout-synce**
 - **(index)**
 - [no] ssmout-enable
- [no] ssmout-ltport**
 - **(index)**
 - [no] ssmout-enable
- t4-out-config**
 - [no] t4-mode
 - [no] t4-damping-factor
 - [no] t4-jitter-bw
 - [no] t4-prio-ref1
 - [no] t4-prio-ref2
- bits-bind**
 - [no] bits-a-bind
 - [no] bits-b-bind
- auto-laser-shutdown**
 - [no] action
- auto-switch**
 - [no] xdsl-atm-ptm
 - [no] xdsl-stepup-delay
- zero-touch-provision**
 - [no] action
- relay-id-syntax**
 - [no] atm-based-dsl
 - [no] efm-based-dsl
- X fips**
 - (enable)
- nt-sftp**
 - [no] write-enable
- [no] user-name**
 - **(name)**
 - password

15.2 System Configuration Command

Command Description

This command displays the ID that represents the SID (System ID) of the NE and is used to identify the NE in TL1 messages. The System ID may only include letters, digits, and hyphens, and must be unique for each NE in a managed network. The name is an administratively assigned name for this managed node. By convention, this is the node's fully qualified domain name. The accessOperatorID is an identifier randomly generated by Nokia and assigned to an operator. The Customer Dependent Engineering features are enabled based on the accessOperatorID. The location is the physical location of this node. The textual identification of the contact person for this managed node, together with information on how to contact this person, is given by contact-person.

The snmp-auth-traps indicates whether the SNMP agent process is permitted to generate authentication-failure traps. The ether-shape-rate indicates the Ethernet frame shaping rate in kb/s.

The system-mac is used to configure the system MAC address in ISAM. The systemMacAddr is the MAC address of the LANX interface on the NT board. The lanxBASEMacAddr is the first MAC address of the consecutive MAC addresses used by the LANX. The lanxRangeMac is the number of MAC addresses supported in LANX.

User Level

The command can be accessed by operators with security privileges, and executed by operators with security privileges.

Command Syntax

The command has the following syntax:

```
> configure system [ no id | id <Sys::systemId> ] name <Transport::sysName> location <Transport::sysLocation> [
no access-oper-id | access-oper-id <Sys::accessOperatorId> ] [ no system-40gkr4 | system-40gkr4
<Sys::sys40GKR4> ] contact-person <Transport::sysContact> [ [ no ] en-snmpp-auth-trap ] nt-intercon-vlan
<Ihub::StackingVlanId> [ no periph-mgmt-vlan | periph-mgmt-vlan <Sys::PortVlanId> ] internal-nw-vlan
<Ihub::InternalNwVlanId> [ no periph-mgmt-ctrl | periph-mgmt-ctrl <Sys::PeriphMgmtCtrl> ] system-mac
<Sys::systemMac> [ no port-num-in-proto | port-num-in-proto <Sys::PortNumberInprotocol> ] [ no
ont-trc-dbg-vlan | ont-trc-dbg-vlan <Vlan::TrcDbgVlan> ] [ no ntr-ssmout-vlan | ntr-ssmout-vlan
<Ntr::SSMOutVlanId> ] [ no ntr-ptp-vlan | ntr-ptp-vlan <Vlan::EthPtpVlan> ] [ no customer-id | customer-id
<Sys::sysCustomerId> ] [ no voiceoswp | voiceoswp <Sys::sysVoiceOswp> ] [ no scalingmode | scalingmode
<Sys::sysScalingMode> ] [ no arp-polling-inter | arp-polling-inter <Sys::arpPollingInterval> ] [ no bsnap-state |
bsnap-state <Sys::bsnapState> ] bsnap-server-ip <Ip::V4Address> bsnap-server-port <Sys::portNumber> [ no
arp-tca-threshold | arp-tca-threshold <Sys::arpTcaThreshold> ]
```

Command Parameters

Table 15.2-2 "System Configuration Command" Command Parameters

Parameter	Type	Description
[no] id	Parameter type: <Sys::systemId> Format: - system ID - range: printable string (no white-spaces) - length: x<=64	optional parameter with default value: "" the system ID of the NE

Parameter	Type	Description
name	Parameter type: <Transport::sysName> Format: - a printable string - length: x<=255	<i>optional parameter</i> fully-qualified domain name of the system
location	Parameter type: <Transport::sysLocation> Format: - a printable string - length: x<=255	<i>optional parameter</i> location of this system
[no] access-oper-id	Parameter type: <Sys::accessOperatorId> Format: - unique access operator id, to activate a system reset is needed - range: [0...65535]	<i>optional parameter with default value: 0</i> unique access operator id assigned by Nokia, to activate a system reset is needed
[no] system-40gkr4	Parameter type: <Sys::sys40GKR4> Format: (disable enable) Possible values: - disable : System 40GKR4 is disabled - enable : System 40GKR4 is enabled	<i>optional parameter with default value: "disable"</i> enable or disable system 40GKR4
contact-person	Parameter type: <Transport::sysContact> Format: - a printable string - length: x<=255	<i>optional parameter</i> info about the contact person for this system
[no] en-snmp-auth-trap	Parameter type: boolean	<i>optional parameter</i> enable the generation of authentication-failure traps
nt-intercon-vlan	Parameter type: <Ihub::StackingVlanId> Format: - the vlan-id used for stacked Broadcom switching devices of NT - range: [1...4093]	<i>optional parameter</i> the value of the nt-interconnect vlan
[no] periph-mgnt-vlan	Parameter type: <Sys::PortVlanId> Format: - vlan id - range: [0...4093]	<i>optional parameter with default value: 0</i> configure the peripheral management vlan
internal-nw-vlan	Parameter type: <Ihub::InternalNwVlanId> Format: - the vlan-id for internal handling of packets on network ports - range: [1...4093]	<i>optional parameter</i> the value of the internal network vlan
[no] periph-mgnt-ctrl	Parameter type: <Sys::PeriphMgntCtrl> Format: (enable disable) Possible values: - enable : activate the peripheral management functionality - disable : deactivate the peripheral management functionality	<i>optional parameter with default value: "disable"</i> configure the peripheral management service
system-mac	Parameter type: <Sys::systemMac> Format: <Sys::MacAddr> / <Sys::LanxMacAddr> / <Sys::Range> Field type <Sys::MacAddr> - a mac-address (example : 01:02:03:04:05:06) - length: 6 Field type <Sys::LanxMacAddr> - a lanx-mac-address (example : 01:02:03:04:05:06)	<i>optional parameter</i> sys mac addr in sysMacAddr/lanxBaseMacAddr/lanxRan

15 System Configuration Commands

Parameter	Type	Description
	- length: 6 - Field type <Sys::Range> - range of the shub - range: [0...65535]	
[no] port-num-in-protocol	Parameter type: <Sys::PortNumberInprotocol> Format: (log-slot-num position-based type-based legacy-num) Possible values: - log-slot-num : a system defined, predetermined and unique number - position-based : flat-numbering independent of slot-type - type-based : flat-numbering per slot-type(tl1-like) - legacy-num : numbering used since the early days(position-based-like)	<i>optional parameter with default value: "log-slot-num"</i> numbering scheme for the Line ID field (all protocols)
[no] ont-trc-dbg-vlan	Parameter type: <Vlan::TrcDbgVlan> Format: (none <Vlan::TrcDbgVlan>) Possible values: - none : no trace and debug vlan-id Field type <Vlan::TrcDbgVlan> - vlan id - range: [1...4093]	<i>optional parameter with default value: "none"</i> ONT trace and debug vlan
[no] ntr-ssmout-vlan	Parameter type: <Ntr::SSMOutVlanId> Format: - ssm out vlan id - range: [1...4093]	<i>optional parameter with default value: 4088</i> ssm out vlan id
[no] ntr-ntp-vlan	Parameter type: <Vlan::EthPtpVlan> Format: (none <Vlan::EthPtpVlan>) Possible values: - none : no vlan Field type <Vlan::EthPtpVlan> - vlan id - range: [1...4093]	<i>optional parameter with default value: "none"</i> ntp vlan id
[no] customer-id	Parameter type: <Sys::sysCustomerId> Format: - a printable string identifying the customer or user - length: x<=64	<i>optional parameter with default value: "available"</i> the customer-id assigned in system level
[no] voiceoswp	Parameter type: <Sys::sysVoiceOswp> Format: (novoice h248 sip sip-softdsp h248-softdsp) Possible values: - novoice : no voice software - h248 : h248 software - sip : sip software - sip-softdsp : sip softdsp software - h248-softdsp : h248 softdsp software	<i>optional parameter with default value: "novoice"</i> the voice software when system startup
[no] scalingmode	Parameter type: <Sys::sysScalingMode>	<i>optional parameter with default</i>

Parameter	Type	Description
	Format: (l2plus l3plus_host l3plus_lpm) Possible values: - l2plus : l2plus-Mode with L2 FDB table - l3plus_host : l3plus_host-Mode with L3 host/ARP table - l3plus_lpm : l3plus_lpm-Mode with L3 LPM/route table	<i>value: "l2plus"</i> the scalingmode, the new scalingmode takes effect after rebooting
[no] arp-polling-inter	Parameter type: <Sys::arpPollingInterval> Format: - polling interval - unit: sec - range: [120...1096]	<i>optional parameter with default value: "120"</i> configure ARP polling interval
[no] bsnap-state	Parameter type: <Sys::bsnapState> Format: (enable disable) Possible values: - enable : enable BSNAP trace - disable : disable BSNAP trace	<i>optional parameter with default value: "disabled"</i> enable or disable BSNAP
bsnap-server-ip	Parameter type: <Ip::V4Address> Format: - IPv4-address	<i>optional parameter</i> configure BSNAP server ip
bsnap-server-port	Parameter type: <Sys::portNumber> Format: - index number - range: [0...65535]	<i>optional parameter</i> configure BSNAP server port
[no] arp-tca-threshold	Parameter type: <Sys::arpTcaThreshold> Format: - tca threshold - range: [0...1000]	<i>optional parameter with default value: "10"</i> configure ARP tca threshold

15.3 Configure system LEDs

Command Description

This command can be used to switch on/off (enable/disable) all the external LEDs of the system.

This CLI command is only supported on some equipment practices.

On equipments where this CLI command is supported, the returned status will reflect the configuration that has been made. On other equipments, the status 'enabled' is always returned

User Level

The command can be accessed by operators with all privileges, and executed by operators with all privileges.

Command Syntax

The command has the following syntax:

> configure system external-leds [no status | status <Sys::ExternalLedsStatusType>]

Command Parameters

Table 15.3-2 "Configure system LEDs" Command Parameters

Parameter	Type	Description
[no] status	Parameter type: <Sys::ExternalLedsStatusType> Format: (disable enable) Possible values: - disable : disable external LEDs - enable : enable external LEDs	optional parameter with default value: "enable" configure the status of the external LEDs

15.4 System SNTP Configuration Command

Command Description

This command allows the operator to configure the SNTP and its related parameters.

User Level

The command can be accessed by operators with security privileges, and executed by operators with security privileges.

Command Syntax

The command has the following syntax:

```
> configure system sntp [ server-ip-addr <Ip::V4Address> ] [ no server-port | server-port <Sys::portNumber> ] [ no polling-rate | polling-rate <Sys::pollingRate> ] [ [ no ] enable ] [ no timezone-offset | timezone-offset <Sys::timeZoneOffset> ]
```

Command Parameters

Table 15.4-2 "System SNTP Configuration Command" Command Parameters

Parameter	Type	Description
server-ip-addr	Parameter type: <Ip::V4Address> Format: - IPv4-address	<i>optional parameter</i> configure the ip address of the sntp server
[no] server-port	Parameter type: <Sys::portNumber> Format: - index number - range: [0...65535]	<i>optional parameter with default value: 123</i> configure the port number of the sntp server
[no] polling-rate	Parameter type: <Sys::pollingRate> Format: - polling rate in second - unit: seconds - range: [60...864000]	<i>optional parameter with default value: 3600</i> configure polling rate for the sntp agent
[no] enable	Parameter type: boolean	<i>optional parameter</i> sntp application in the NE is enabled
[no] timezone-offset	Parameter type: <Sys::timeZoneOffset> Format: - specify the offset for timezone from GMT/UTC - unit: minutes - range: [-780...840]	<i>optional parameter with default value: 0</i> set the offset of the local timezone from GMT/UTC

15.5 System SNTP Server Table Configuration Command

Command Description

This command allows the operator to configure SNTP Server Table and its related parameters.

User Level

The command can be accessed by operators with security privileges, and executed by operators with security privileges.

Command Syntax

The command has the following syntax:

```
> configure system sntp server-table ( no ip-address (ip-addr) ) | ( ip-address (ip-addr) [ no port | port <Sys::ServerPortNumber> ] [ priority <Sys::priority> ] )
```

Command Parameters

Table 15.5-1 "System SNTP Server Table Configuration Command" Resource Parameters

Resource Identifier	Type	Description
(ip-addr)	Format: - IPv4-address	configure the ip-address of the sntp server

Table 15.5-2 "System SNTP Server Table Configuration Command" Command Parameters

Parameter	Type	Description
[no] port	Parameter type: <Sys::ServerPortNumber> Format: - port number - range: [0...65535]	<i>optional parameter with default value: 123</i> configure the port number of the sntp server
priority	Parameter type: <Sys::priority> Format: - sntp server priority(1 - high) [1...6] for ipv6 management supported boards,[1...3] for others	<i>optional parameter</i> configure the priority number of the sntp server

15.6 System SNTP Server Table Configuration Command

Command Description

This command allows the operator to configure SNTP Server Table and its related parameters.

User Level

The command can be accessed by operators with security privileges, and executed by operators with security privileges.

Command Syntax

The command has the following syntax:

```
> configure system sntp server-table ( no ipv6-address (ip-addr) ) | ( ipv6-address (ip-addr) [ no port | port <Sys::ServerPortNumber> ] [ priority <Sys::priority> ] )
```

Command Parameters

Table 15.6-1 "System SNTP Server Table Configuration Command" Resource Parameters

Resource Identifier	Type	Description
(ip-addr)	Format: - IPv6-address	configure the ipv6-address of the sntp server

Table 15.6-2 "System SNTP Server Table Configuration Command" Command Parameters

Parameter	Type	Description
[no] port	Parameter type: <Sys::ServerPortNumber> Format: - port number - range: [0...65535]	<i>optional parameter with default value: 123</i> configure the port number of the sntp server
priority	Parameter type: <Sys::priority> Format: - sntp server priority(1 - high) [1...6] for ipv6 management supported boards,[1...3] for others	<i>optional parameter</i> configure the priority number of the sntp server

15.7 System daylight saving time Configuration Command

Command Description

This command allows the operator to configure the daylight saving time and its related parameters.

User Level

The command can be accessed by operators with security privileges, and executed by operators with security privileges.

Command Syntax

The command has the following syntax:

```
> configure system dst [ [ no ] enable ]
```

Command Parameters

Table 15.7-2 "System daylight saving time Configuration Command" Command Parameters

Parameter	Type	Description
[no] enable	Parameter type: boolean	<i>optional parameter</i> daylight saving time application in the NE is enabled

15.8 System daylight saving time Configuration Command

Command Description

This command allows the operator to configure the daylight saving time start/end time with the corresponding specified days every year.

User Level

The command can be accessed by operators with security privileges, and executed by operators with security privileges.

Command Syntax

The command has the following syntax:

```
> configure system dst ( no date timezone-offset <Sys::timeZoneOffsetDst> ) | ( date timezone-offset
<Sys::timeZoneOffsetDst> start-time <Sys::GaugeTimeInSecs> end-time <Sys::GaugeTimeInSecs> [ no offset |
offset <Sys::DstAdjustment> ] )
```

Command Parameters

Table 15.8-1 "System daylight saving time Configuration Command" Resource Parameters

Resource Identifier	Type	Description
timezone-offset	Parameter type: <Sys::timeZoneOffsetDst> Format: - specify the offset for timezone from GMT/UTC - range: [-780...840]	configure the timezone of daylight saving time

Table 15.8-2 "System daylight saving time Configuration Command" Command Parameters

Parameter	Type	Description
start-time	Parameter type: <Sys::GaugeTimeInSecs> Format: - the time (yyyy-mm-dd:hour:minutes:secs)	<i>mandatory parameter</i> configure start time of daylight saving time
end-time	Parameter type: <Sys::GaugeTimeInSecs> Format: - the time (yyyy-mm-dd:hour:minutes:secs)	<i>mandatory parameter</i> configure end time of daylight saving time
[no] offset	Parameter type: <Sys::DstAdjustment> Format: - The number of minutes that will be adjusted to the time - unit: minutes - range: [0...60]	<i>optional parameter with default value: 60</i> configure offset of daylight saving time

15.9 System daylight saving time Configuration Command

Command Description

This command allows the operator to configure the daylight saving time start/end time with the specified week and weekday repeatedly.

User Level

The command can be accessed by operators with security privileges, and executed by operators with security privileges.

Command Syntax

The command has the following syntax:

```
> configure system dst ( no recurring timezone-offset <Sys::timeZoneOffsetDst> ) | ( recurring timezone-offset
<Sys::timeZoneOffsetDst> start-time <Sys::DSTRecurring> end-time <Sys::DSTRecurring> [ no offset | offset
<Sys::DstAdjustment> ] )
```

Command Parameters

Table 15.9-1 "System daylight saving time Configuration Command" Resource Parameters

Resource Identifier	Type	Description
timezone-offset	Parameter type: <Sys::timeZoneOffsetDst> Format: - specify the offset for timezone from GMT/UTC - range: [-780...840]	configure the timezone of daylight saving time

Table 15.9-2 "System daylight saving time Configuration Command" Command Parameters

Parameter	Type	Description
start-time	Parameter type: <Sys::DSTRecurring> Format: (jan - first - sun : <Sys::DSThour> : <Sys::DSTmin> jan - first - mon : <Sys::DSThour> : <Sys::DSTmin> jan - first - tues : <Sys::DSThour> : <Sys::DSTmin> jan - first - wed : <Sys::DSThour> : <Sys::DSTmin> jan - first - thur : <Sys::DSThour> : <Sys::DSTmin> jan - first - fri : <Sys::DSThour> : <Sys::DSTmin> jan - first - sat : <Sys::DSThour> : <Sys::DSTmin> jan - second - sun : <Sys::DSThour> : <Sys::DSTmin> jan - second - mon : <Sys::DSThour> : <Sys::DSTmin> jan - second - tues : <Sys::DSThour> : <Sys::DSTmin> jan - second - wed : <Sys::DSThour> : <Sys::DSTmin> jan - second - thur : <Sys::DSThour> : <Sys::DSTmin> jan - second - fri : <Sys::DSThour> : <Sys::DSTmin>	<i>mandatory parameter</i> configure start time of daylight saving time

Parameter	Type	Description
	jan - second - sat : <Sys::DSThour> : <Sys::DSTmin> jan - third - sun : <Sys::DSThour> : <Sys::DSTmin> jan - third - mon : <Sys::DSThour> : <Sys::DSTmin> jan - third - tues : <Sys::DSThour> : <Sys::DSTmin> jan - third - wed : <Sys::DSThour> : <Sys::DSTmin> jan - third - thur : <Sys::DSThour> : <Sys::DSTmin> jan - third - fri : <Sys::DSThour> : <Sys::DSTmin> jan - third - sat : <Sys::DSThour> : <Sys::DSTmin> jan - fourth - sun : <Sys::DSThour> : <Sys::DSTmin> jan - fourth - mon : <Sys::DSThour> : <Sys::DSTmin> jan - fourth - tues : <Sys::DSThour> : <Sys::DSTmin> jan - fourth - wed : <Sys::DSThour> : <Sys::DSTmin> jan - fourth - thur : <Sys::DSThour> : <Sys::DSTmin> jan - fourth - fri : <Sys::DSThour> : <Sys::DSTmin> jan - fourth - sat : <Sys::DSThour> : <Sys::DSTmin> jan - last - sun : <Sys::DSThour> : <Sys::DSTmin> jan - last - mon : <Sys::DSThour> : <Sys::DSTmin> jan - last - tues : <Sys::DSThour> : <Sys::DSTmin> jan - last - wed : <Sys::DSThour> : <Sys::DSTmin> jan - last - thur : <Sys::DSThour> : <Sys::DSTmin> jan - last - fri : <Sys::DSThour> : <Sys::DSTmin> jan - last - sat : <Sys::DSThour> : <Sys::DSTmin> feb - first - sun : <Sys::DSThour> : <Sys::DSTmin> feb - first - mon : <Sys::DSThour> : <Sys::DSTmin> feb - first - tues : <Sys::DSThour> : <Sys::DSTmin> feb - first - wed : <Sys::DSThour> : <Sys::DSTmin> feb - first - thur : <Sys::DSThour> : <Sys::DSTmin> feb - first - fri : <Sys::DSThour> : <Sys::DSTmin> feb - first - sat : <Sys::DSThour> : <Sys::DSTmin> feb - second - sun : <Sys::DSThour> : <Sys::DSTmin> feb - second - mon : <Sys::DSThour> : <Sys::DSTmin> feb - second - tues : <Sys::DSThour> : <Sys::DSTmin> feb - second - wed : <Sys::DSThour> : <Sys::DSTmin> feb - second - thur : <Sys::DSThour> : <Sys::DSTmin> feb - second - fri : <Sys::DSThour> : <Sys::DSTmin> feb - second - sat : <Sys::DSThour> : <Sys::DSTmin> feb - third - sun : <Sys::DSThour> : <Sys::DSTmin> feb - third - mon : <Sys::DSThour> : <Sys::DSTmin> feb - third - tues : <Sys::DSThour> : <Sys::DSTmin> feb - third - wed : <Sys::DSThour> : <Sys::DSTmin> feb - third - thur : <Sys::DSThour> : <Sys::DSTmin> feb - third - fri : <Sys::DSThour> : <Sys::DSTmin> feb - third - sat : <Sys::DSThour> : <Sys::DSTmin> feb - fourth - sun : <Sys::DSThour> : <Sys::DSTmin> feb - fourth - mon : <Sys::DSThour> : <Sys::DSTmin> feb - fourth - tues : <Sys::DSThour> : <Sys::DSTmin> feb - fourth - wed : <Sys::DSThour> : <Sys::DSTmin> feb - fourth - thur : <Sys::DSThour> : <Sys::DSTmin> feb - fourth - fri : <Sys::DSThour> : <Sys::DSTmin> feb - fourth - sat : <Sys::DSThour> : <Sys::DSTmin> feb - last - sun : <Sys::DSThour> : <Sys::DSTmin> feb - last - mon : <Sys::DSThour> : <Sys::DSTmin> feb - last - tues : <Sys::DSThour> : <Sys::DSTmin> feb - last - wed : <Sys::DSThour> : <Sys::DSTmin> feb - last - thur : <Sys::DSThour> : <Sys::DSTmin> feb - last - fri : <Sys::DSThour> : <Sys::DSTmin> feb - last - sat : <Sys::DSThour> : <Sys::DSTmin>	

15 System Configuration Commands

Parameter	Type	Description
	mar - first - sun : <Sys::DSThour> : <Sys::DSTmin> mar - first - mon : <Sys::DSThour> : <Sys::DSTmin> mar - first - tues : <Sys::DSThour> : <Sys::DSTmin> mar - first - wed : <Sys::DSThour> : <Sys::DSTmin> mar - first - thur : <Sys::DSThour> : <Sys::DSTmin> mar - first - fri : <Sys::DSThour> : <Sys::DSTmin> mar - first - sat : <Sys::DSThour> : <Sys::DSTmin> mar - second - sun : <Sys::DSThour> : <Sys::DSTmin> mar - second - mon : <Sys::DSThour> : <Sys::DSTmin> mar - second - tues : <Sys::DSThour> : <Sys::DSTmin> mar - second - wed : <Sys::DSThour> : <Sys::DSTmin> mar - second - thur : <Sys::DSThour> : <Sys::DSTmin> mar - second - fri : <Sys::DSThour> : <Sys::DSTmin> mar - second - sat : <Sys::DSThour> : <Sys::DSTmin> mar - third - sun : <Sys::DSThour> : <Sys::DSTmin> mar - third - mon : <Sys::DSThour> : <Sys::DSTmin> mar - third - tues : <Sys::DSThour> : <Sys::DSTmin> mar - third - wed : <Sys::DSThour> : <Sys::DSTmin> mar - third - thur : <Sys::DSThour> : <Sys::DSTmin> mar - third - fri : <Sys::DSThour> : <Sys::DSTmin> mar - third - sat : <Sys::DSThour> : <Sys::DSTmin> mar - fourth - sun : <Sys::DSThour> : <Sys::DSTmin> mar - fourth - mon : <Sys::DSThour> : <Sys::DSTmin> mar - fourth - tues : <Sys::DSThour> : <Sys::DSTmin> mar - fourth - wed : <Sys::DSThour> : <Sys::DSTmin> mar - fourth - thur : <Sys::DSThour> : <Sys::DSTmin> mar - fourth - fri : <Sys::DSThour> : <Sys::DSTmin> mar - fourth - sat : <Sys::DSThour> : <Sys::DSTmin> mar - last - sun : <Sys::DSThour> : <Sys::DSTmin> mar - last - mon : <Sys::DSThour> : <Sys::DSTmin> mar - last - tues : <Sys::DSThour> : <Sys::DSTmin> mar - last - wed : <Sys::DSThour> : <Sys::DSTmin> mar - last - thur : <Sys::DSThour> : <Sys::DSTmin> mar - last - fri : <Sys::DSThour> : <Sys::DSTmin> mar - last - sat : <Sys::DSThour> : <Sys::DSTmin> apr - first - sun : <Sys::DSThour> : <Sys::DSTmin> apr - first - mon : <Sys::DSThour> : <Sys::DSTmin> apr - first - tues : <Sys::DSThour> : <Sys::DSTmin> apr - first - wed : <Sys::DSThour> : <Sys::DSTmin> apr - first - thur : <Sys::DSThour> : <Sys::DSTmin> apr - first - fri : <Sys::DSThour> : <Sys::DSTmin> apr - first - sat : <Sys::DSThour> : <Sys::DSTmin> apr - second - sun : <Sys::DSThour> : <Sys::DSTmin> apr - second - mon : <Sys::DSThour> : <Sys::DSTmin> apr - second - tues : <Sys::DSThour> : <Sys::DSTmin> apr - second - wed : <Sys::DSThour> : <Sys::DSTmin> apr - second - thur : <Sys::DSThour> : <Sys::DSTmin> apr - second - fri : <Sys::DSThour> : <Sys::DSTmin> apr - second - sat : <Sys::DSThour> : <Sys::DSTmin> apr - third - sun : <Sys::DSThour> : <Sys::DSTmin> apr - third - mon : <Sys::DSThour> : <Sys::DSTmin> apr - third - tues : <Sys::DSThour> : <Sys::DSTmin> apr - third - wed : <Sys::DSThour> : <Sys::DSTmin> apr - third - thur : <Sys::DSThour> : <Sys::DSTmin> apr - third - fri : <Sys::DSThour> : <Sys::DSTmin> apr - third - sat : <Sys::DSThour> : <Sys::DSTmin> apr - fourth - sun : <Sys::DSThour> : <Sys::DSTmin>	

Parameter	Type	Description
	apr - fourth - mon : <Sys::DSThour> : <Sys::DSTmin> apr - fourth - tues : <Sys::DSThour> : <Sys::DSTmin> apr - fourth - wed : <Sys::DSThour> : <Sys::DSTmin> apr - fourth - thur : <Sys::DSThour> : <Sys::DSTmin> apr - fourth - fri : <Sys::DSThour> : <Sys::DSTmin> apr - fourth - sat : <Sys::DSThour> : <Sys::DSTmin> apr - last - sun : <Sys::DSThour> : <Sys::DSTmin> apr - last - mon : <Sys::DSThour> : <Sys::DSTmin> apr - last - tues : <Sys::DSThour> : <Sys::DSTmin> apr - last - wed : <Sys::DSThour> : <Sys::DSTmin> apr - last - thur : <Sys::DSThour> : <Sys::DSTmin> apr - last - fri : <Sys::DSThour> : <Sys::DSTmin> apr - last - sat : <Sys::DSThour> : <Sys::DSTmin> may - first - sun : <Sys::DSThour> : <Sys::DSTmin> may - first - mon : <Sys::DSThour> : <Sys::DSTmin> may - first - tues : <Sys::DSThour> : <Sys::DSTmin> may - first - wed : <Sys::DSThour> : <Sys::DSTmin> may - first - thur : <Sys::DSThour> : <Sys::DSTmin> may - first - fri : <Sys::DSThour> : <Sys::DSTmin> may - first - sat : <Sys::DSThour> : <Sys::DSTmin> may - second - sun : <Sys::DSThour> : <Sys::DSTmin> may - second - mon : <Sys::DSThour> : <Sys::DSTmin> may - second - tues : <Sys::DSThour> : <Sys::DSTmin> may - second - wed : <Sys::DSThour> : <Sys::DSTmin> may - second - thur : <Sys::DSThour> : <Sys::DSTmin> may - second - fri : <Sys::DSThour> : <Sys::DSTmin> may - second - sat : <Sys::DSThour> : <Sys::DSTmin> may - third - sun : <Sys::DSThour> : <Sys::DSTmin> may - third - mon : <Sys::DSThour> : <Sys::DSTmin> may - third - tues : <Sys::DSThour> : <Sys::DSTmin> may - third - wed : <Sys::DSThour> : <Sys::DSTmin> may - third - thur : <Sys::DSThour> : <Sys::DSTmin> may - third - fri : <Sys::DSThour> : <Sys::DSTmin> may - third - sat : <Sys::DSThour> : <Sys::DSTmin> may - fourth - sun : <Sys::DSThour> : <Sys::DSTmin> may - fourth - mon : <Sys::DSThour> : <Sys::DSTmin> may - fourth - tues : <Sys::DSThour> : <Sys::DSTmin> may - fourth - wed : <Sys::DSThour> : <Sys::DSTmin> may - fourth - thur : <Sys::DSThour> : <Sys::DSTmin> may - fourth - fri : <Sys::DSThour> : <Sys::DSTmin> may - fourth - sat : <Sys::DSThour> : <Sys::DSTmin> may - last - sun : <Sys::DSThour> : <Sys::DSTmin> may - last - mon : <Sys::DSThour> : <Sys::DSTmin> may - last - tues : <Sys::DSThour> : <Sys::DSTmin> may - last - wed : <Sys::DSThour> : <Sys::DSTmin> may - last - thur : <Sys::DSThour> : <Sys::DSTmin> may - last - fri : <Sys::DSThour> : <Sys::DSTmin> may - last - sat : <Sys::DSThour> : <Sys::DSTmin> jun - first - sun : <Sys::DSThour> : <Sys::DSTmin> jun - first - mon : <Sys::DSThour> : <Sys::DSTmin> jun - first - tues : <Sys::DSThour> : <Sys::DSTmin> jun - first - wed : <Sys::DSThour> : <Sys::DSTmin> jun - first - thur : <Sys::DSThour> : <Sys::DSTmin> jun - first - fri : <Sys::DSThour> : <Sys::DSTmin> jun - first - sat : <Sys::DSThour> : <Sys::DSTmin> jun - second - sun : <Sys::DSThour> : <Sys::DSTmin> jun - second - mon : <Sys::DSThour> : <Sys::DSTmin>	

15 System Configuration Commands

Parameter	Type	Description
	jun - second - tues : <Sys::DSThour> : <Sys::DSTmin> jun - second - wed : <Sys::DSThour> : <Sys::DSTmin> jun - second - thur : <Sys::DSThour> : <Sys::DSTmin> jun - second - fri : <Sys::DSThour> : <Sys::DSTmin> jun - second - sat : <Sys::DSThour> : <Sys::DSTmin> jun - third - sun : <Sys::DSThour> : <Sys::DSTmin> jun - third - mon : <Sys::DSThour> : <Sys::DSTmin> jun - third - tues : <Sys::DSThour> : <Sys::DSTmin> jun - third - wed : <Sys::DSThour> : <Sys::DSTmin> jun - third - thur : <Sys::DSThour> : <Sys::DSTmin> jun - third - fri : <Sys::DSThour> : <Sys::DSTmin> jun - third - sat : <Sys::DSThour> : <Sys::DSTmin> jun - fourth - sun : <Sys::DSThour> : <Sys::DSTmin> jun - fourth - mon : <Sys::DSThour> : <Sys::DSTmin> jun - fourth - tues : <Sys::DSThour> : <Sys::DSTmin> jun - fourth - wed : <Sys::DSThour> : <Sys::DSTmin> jun - fourth - thur : <Sys::DSThour> : <Sys::DSTmin> jun - fourth - fri : <Sys::DSThour> : <Sys::DSTmin> jun - fourth - sat : <Sys::DSThour> : <Sys::DSTmin> jun - last - sun : <Sys::DSThour> : <Sys::DSTmin> jun - last - mon : <Sys::DSThour> : <Sys::DSTmin> jun - last - tues : <Sys::DSThour> : <Sys::DSTmin> jun - last - wed : <Sys::DSThour> : <Sys::DSTmin> jun - last - thur : <Sys::DSThour> : <Sys::DSTmin> jun - last - fri : <Sys::DSThour> : <Sys::DSTmin> jun - last - sat : <Sys::DSThour> : <Sys::DSTmin> jul - first - sun : <Sys::DSThour> : <Sys::DSTmin> jul - first - mon : <Sys::DSThour> : <Sys::DSTmin> jul - first - tues : <Sys::DSThour> : <Sys::DSTmin> jul - first - wed : <Sys::DSThour> : <Sys::DSTmin> jul - first - thur : <Sys::DSThour> : <Sys::DSTmin> jul - first - fri : <Sys::DSThour> : <Sys::DSTmin> jul - first - sat : <Sys::DSThour> : <Sys::DSTmin> jul - second - sun : <Sys::DSThour> : <Sys::DSTmin> jul - second - mon : <Sys::DSThour> : <Sys::DSTmin> jul - second - tues : <Sys::DSThour> : <Sys::DSTmin> jul - second - wed : <Sys::DSThour> : <Sys::DSTmin> jul - second - thur : <Sys::DSThour> : <Sys::DSTmin> jul - second - fri : <Sys::DSThour> : <Sys::DSTmin> jul - second - sat : <Sys::DSThour> : <Sys::DSTmin> jul - third - sun : <Sys::DSThour> : <Sys::DSTmin> jul - third - mon : <Sys::DSThour> : <Sys::DSTmin> jul - third - tues : <Sys::DSThour> : <Sys::DSTmin> jul - third - wed : <Sys::DSThour> : <Sys::DSTmin> jul - third - thur : <Sys::DSThour> : <Sys::DSTmin> jul - third - fri : <Sys::DSThour> : <Sys::DSTmin> jul - third - sat : <Sys::DSThour> : <Sys::DSTmin> jul - fourth - sun : <Sys::DSThour> : <Sys::DSTmin> jul - fourth - mon : <Sys::DSThour> : <Sys::DSTmin> jul - fourth - tues : <Sys::DSThour> : <Sys::DSTmin> jul - fourth - wed : <Sys::DSThour> : <Sys::DSTmin> jul - fourth - thur : <Sys::DSThour> : <Sys::DSTmin> jul - fourth - fri : <Sys::DSThour> : <Sys::DSTmin> jul - fourth - sat : <Sys::DSThour> : <Sys::DSTmin> jul - last - sun : <Sys::DSThour> : <Sys::DSTmin> jul - last - mon : <Sys::DSThour> : <Sys::DSTmin> jul - last - tues : <Sys::DSThour> : <Sys::DSTmin>	

Parameter	Type	Description
	- jul - last - wed : <Sys::DSThour> : <Sys::DSTmin> - jul - last - thur : <Sys::DSThour> : <Sys::DSTmin> - jul - last - fri : <Sys::DSThour> : <Sys::DSTmin> - jul - last - sat : <Sys::DSThour> : <Sys::DSTmin> - aug - first - sun : <Sys::DSThour> : <Sys::DSTmin> - aug - first - mon : <Sys::DSThour> : <Sys::DSTmin> - aug - first - tues : <Sys::DSThour> : <Sys::DSTmin> - aug - first - wed : <Sys::DSThour> : <Sys::DSTmin> - aug - first - thur : <Sys::DSThour> : <Sys::DSTmin> - aug - first - fri : <Sys::DSThour> : <Sys::DSTmin> - aug - first - sat : <Sys::DSThour> : <Sys::DSTmin> - aug - second - sun : <Sys::DSThour> : <Sys::DSTmin> - aug - second - mon : <Sys::DSThour> : <Sys::DSTmin> - aug - second - tues : <Sys::DSThour> : <Sys::DSTmin> - aug - second - wed : <Sys::DSThour> : <Sys::DSTmin> - aug - second - thur : <Sys::DSThour> : <Sys::DSTmin> - aug - second - fri : <Sys::DSThour> : <Sys::DSTmin> - aug - second - sat : <Sys::DSThour> : <Sys::DSTmin> - aug - third - sun : <Sys::DSThour> : <Sys::DSTmin> - aug - third - mon : <Sys::DSThour> : <Sys::DSTmin> - aug - third - tues : <Sys::DSThour> : <Sys::DSTmin> - aug - third - wed : <Sys::DSThour> : <Sys::DSTmin> - aug - third - thur : <Sys::DSThour> : <Sys::DSTmin> - aug - third - fri : <Sys::DSThour> : <Sys::DSTmin> - aug - third - sat : <Sys::DSThour> : <Sys::DSTmin> - aug - fourth - sun : <Sys::DSThour> : <Sys::DSTmin> - aug - fourth - mon : <Sys::DSThour> : <Sys::DSTmin> - aug - fourth - tues : <Sys::DSThour> : <Sys::DSTmin> - aug - fourth - wed : <Sys::DSThour> : <Sys::DSTmin> - aug - fourth - thur : <Sys::DSThour> : <Sys::DSTmin> - aug - fourth - fri : <Sys::DSThour> : <Sys::DSTmin> - aug - fourth - sat : <Sys::DSThour> : <Sys::DSTmin> - aug - last - sun : <Sys::DSThour> : <Sys::DSTmin> - aug - last - mon : <Sys::DSThour> : <Sys::DSTmin> - aug - last - tues : <Sys::DSThour> : <Sys::DSTmin> - aug - last - wed : <Sys::DSThour> : <Sys::DSTmin> - aug - last - thur : <Sys::DSThour> : <Sys::DSTmin> - aug - last - fri : <Sys::DSThour> : <Sys::DSTmin> - aug - last - sat : <Sys::DSThour> : <Sys::DSTmin> - sep - first - sun : <Sys::DSThour> : <Sys::DSTmin> - sep - first - mon : <Sys::DSThour> : <Sys::DSTmin> - sep - first - tues : <Sys::DSThour> : <Sys::DSTmin> - sep - first - wed : <Sys::DSThour> : <Sys::DSTmin> - sep - first - thur : <Sys::DSThour> : <Sys::DSTmin> - sep - first - fri : <Sys::DSThour> : <Sys::DSTmin> - sep - first - sat : <Sys::DSThour> : <Sys::DSTmin> - sep - second - sun : <Sys::DSThour> : <Sys::DSTmin> - sep - second - mon : <Sys::DSThour> : <Sys::DSTmin> - sep - second - tues : <Sys::DSThour> : <Sys::DSTmin> - sep - second - wed : <Sys::DSThour> : <Sys::DSTmin> - sep - second - thur : <Sys::DSThour> : <Sys::DSTmin> - sep - second - fri : <Sys::DSThour> : <Sys::DSTmin> - sep - second - sat : <Sys::DSThour> : <Sys::DSTmin> - sep - third - sun : <Sys::DSThour> : <Sys::DSTmin> - sep - third - mon : <Sys::DSThour> : <Sys::DSTmin> - sep - third - tues : <Sys::DSThour> : <Sys::DSTmin> - sep - third - wed : <Sys::DSThour> : <Sys::DSTmin>	

15 System Configuration Commands

Parameter	Type	Description
	sep - third - thur : <Sys::DSThour> : <Sys::DSTmin> sep - third - fri : <Sys::DSThour> : <Sys::DSTmin> sep - third - sat : <Sys::DSThour> : <Sys::DSTmin> sep - fourth - sun : <Sys::DSThour> : <Sys::DSTmin> sep - fourth - mon : <Sys::DSThour> : <Sys::DSTmin> sep - fourth - tues : <Sys::DSThour> : <Sys::DSTmin> sep - fourth - wed : <Sys::DSThour> : <Sys::DSTmin> sep - fourth - thur : <Sys::DSThour> : <Sys::DSTmin> sep - fourth - fri : <Sys::DSThour> : <Sys::DSTmin> sep - fourth - sat : <Sys::DSThour> : <Sys::DSTmin> sep - last - sun : <Sys::DSThour> : <Sys::DSTmin> sep - last - mon : <Sys::DSThour> : <Sys::DSTmin> sep - last - tues : <Sys::DSThour> : <Sys::DSTmin> sep - last - wed : <Sys::DSThour> : <Sys::DSTmin> sep - last - thur : <Sys::DSThour> : <Sys::DSTmin> sep - last - fri : <Sys::DSThour> : <Sys::DSTmin> sep - last - sat : <Sys::DSThour> : <Sys::DSTmin> oct - first - sun : <Sys::DSThour> : <Sys::DSTmin> oct - first - mon : <Sys::DSThour> : <Sys::DSTmin> oct - first - tues : <Sys::DSThour> : <Sys::DSTmin> oct - first - wed : <Sys::DSThour> : <Sys::DSTmin> oct - first - thur : <Sys::DSThour> : <Sys::DSTmin> oct - first - fri : <Sys::DSThour> : <Sys::DSTmin> oct - first - sat : <Sys::DSThour> : <Sys::DSTmin> oct - second - sun : <Sys::DSThour> : <Sys::DSTmin> oct - second - mon : <Sys::DSThour> : <Sys::DSTmin> oct - second - tues : <Sys::DSThour> : <Sys::DSTmin> oct - second - wed : <Sys::DSThour> : <Sys::DSTmin> oct - second - thur : <Sys::DSThour> : <Sys::DSTmin> oct - second - fri : <Sys::DSThour> : <Sys::DSTmin> oct - second - sat : <Sys::DSThour> : <Sys::DSTmin> oct - third - sun : <Sys::DSThour> : <Sys::DSTmin> oct - third - mon : <Sys::DSThour> : <Sys::DSTmin> oct - third - tues : <Sys::DSThour> : <Sys::DSTmin> oct - third - wed : <Sys::DSThour> : <Sys::DSTmin> oct - third - thur : <Sys::DSThour> : <Sys::DSTmin> oct - third - fri : <Sys::DSThour> : <Sys::DSTmin> oct - third - sat : <Sys::DSThour> : <Sys::DSTmin> oct - fourth - sun : <Sys::DSThour> : <Sys::DSTmin> oct - fourth - mon : <Sys::DSThour> : <Sys::DSTmin> oct - fourth - tues : <Sys::DSThour> : <Sys::DSTmin> oct - fourth - wed : <Sys::DSThour> : <Sys::DSTmin> oct - fourth - thur : <Sys::DSThour> : <Sys::DSTmin> oct - fourth - fri : <Sys::DSThour> : <Sys::DSTmin> oct - fourth - sat : <Sys::DSThour> : <Sys::DSTmin> oct - last - sun : <Sys::DSThour> : <Sys::DSTmin> oct - last - mon : <Sys::DSThour> : <Sys::DSTmin> oct - last - tues : <Sys::DSThour> : <Sys::DSTmin> oct - last - wed : <Sys::DSThour> : <Sys::DSTmin> oct - last - thur : <Sys::DSThour> : <Sys::DSTmin> oct - last - fri : <Sys::DSThour> : <Sys::DSTmin> oct - last - sat : <Sys::DSThour> : <Sys::DSTmin> nov - first - sun : <Sys::DSThour> : <Sys::DSTmin> nov - first - mon : <Sys::DSThour> : <Sys::DSTmin> nov - first - tues : <Sys::DSThour> : <Sys::DSTmin> nov - first - wed : <Sys::DSThour> : <Sys::DSTmin> nov - first - thur : <Sys::DSThour> : <Sys::DSTmin>	

Parameter	Type	Description
	nov - first - fri : <Sys::DSThour> : <Sys::DSTmin> nov - first - sat : <Sys::DSThour> : <Sys::DSTmin> nov - second - sun : <Sys::DSThour> : <Sys::DSTmin> nov - second - mon : <Sys::DSThour> : <Sys::DSTmin> nov - second - tues : <Sys::DSThour> : <Sys::DSTmin> nov - second - wed : <Sys::DSThour> : <Sys::DSTmin> nov - second - thur : <Sys::DSThour> : <Sys::DSTmin> nov - second - fri : <Sys::DSThour> : <Sys::DSTmin> nov - second - sat : <Sys::DSThour> : <Sys::DSTmin> nov - third - sun : <Sys::DSThour> : <Sys::DSTmin> nov - third - mon : <Sys::DSThour> : <Sys::DSTmin> nov - third - tues : <Sys::DSThour> : <Sys::DSTmin> nov - third - wed : <Sys::DSThour> : <Sys::DSTmin> nov - third - thur : <Sys::DSThour> : <Sys::DSTmin> nov - third - fri : <Sys::DSThour> : <Sys::DSTmin> nov - third - sat : <Sys::DSThour> : <Sys::DSTmin> nov - fourth - sun : <Sys::DSThour> : <Sys::DSTmin> nov - fourth - mon : <Sys::DSThour> : <Sys::DSTmin> nov - fourth - tues : <Sys::DSThour> : <Sys::DSTmin> nov - fourth - wed : <Sys::DSThour> : <Sys::DSTmin> nov - fourth - thur : <Sys::DSThour> : <Sys::DSTmin> nov - fourth - fri : <Sys::DSThour> : <Sys::DSTmin> nov - fourth - sat : <Sys::DSThour> : <Sys::DSTmin> nov - last - sun : <Sys::DSThour> : <Sys::DSTmin> nov - last - mon : <Sys::DSThour> : <Sys::DSTmin> nov - last - tues : <Sys::DSThour> : <Sys::DSTmin> nov - last - wed : <Sys::DSThour> : <Sys::DSTmin> nov - last - thur : <Sys::DSThour> : <Sys::DSTmin> nov - last - fri : <Sys::DSThour> : <Sys::DSTmin> nov - last - sat : <Sys::DSThour> : <Sys::DSTmin> dec - first - sun : <Sys::DSThour> : <Sys::DSTmin> dec - first - mon : <Sys::DSThour> : <Sys::DSTmin> dec - first - tues : <Sys::DSThour> : <Sys::DSTmin> dec - first - wed : <Sys::DSThour> : <Sys::DSTmin> dec - first - thur : <Sys::DSThour> : <Sys::DSTmin> dec - first - fri : <Sys::DSThour> : <Sys::DSTmin> dec - first - sat : <Sys::DSThour> : <Sys::DSTmin> dec - second - sun : <Sys::DSThour> : <Sys::DSTmin> dec - second - mon : <Sys::DSThour> : <Sys::DSTmin> dec - second - tues : <Sys::DSThour> : <Sys::DSTmin> dec - second - wed : <Sys::DSThour> : <Sys::DSTmin> dec - second - thur : <Sys::DSThour> : <Sys::DSTmin> dec - second - fri : <Sys::DSThour> : <Sys::DSTmin> dec - second - sat : <Sys::DSThour> : <Sys::DSTmin> dec - third - sun : <Sys::DSThour> : <Sys::DSTmin> dec - third - mon : <Sys::DSThour> : <Sys::DSTmin> dec - third - tues : <Sys::DSThour> : <Sys::DSTmin> dec - third - wed : <Sys::DSThour> : <Sys::DSTmin> dec - third - thur : <Sys::DSThour> : <Sys::DSTmin> dec - third - fri : <Sys::DSThour> : <Sys::DSTmin> dec - third - sat : <Sys::DSThour> : <Sys::DSTmin> dec - fourth - sun : <Sys::DSThour> : <Sys::DSTmin> dec - fourth - mon : <Sys::DSThour> : <Sys::DSTmin> dec - fourth - tues : <Sys::DSThour> : <Sys::DSTmin> dec - fourth - wed : <Sys::DSThour> : <Sys::DSTmin> dec - fourth - thur : <Sys::DSThour> : <Sys::DSTmin> dec - fourth - fri : <Sys::DSThour> : <Sys::DSTmin>	

15 System Configuration Commands

Parameter	Type	Description
	<pre> dec - fourth - sat : <Sys::DSThour> : <Sys::DSTmin> dec - last - sun : <Sys::DSThour> : <Sys::DSTmin> dec - last - mon : <Sys::DSThour> : <Sys::DSTmin> dec - last - tues : <Sys::DSThour> : <Sys::DSTmin> dec - last - wed : <Sys::DSThour> : <Sys::DSTmin> dec - last - thur : <Sys::DSThour> : <Sys::DSTmin> dec - last - fri : <Sys::DSThour> : <Sys::DSTmin> dec - last - sat : <Sys::DSThour> : <Sys::DSTmin>) Possible values: - jan : january - feb : february - mar : march - apr : april - may : may - jun : june - jul : july - aug : august - sep : september - oct : october - nov : november - dec : december Possible values: - first : first week of the month - second : second week of the month - third : third week of the month - fourth : fourth week of the month - last : last week of the month Possible values: - sun : sunday - mon : monday - tues : tuesday - wed : wednesday - thur : thursday - fri : friday - sat : saturday Field type <Sys::DSThour> - hour - range: [0...23] Field type <Sys::DSTmin> - minutes - unit: minutes - range: [0...59] </pre>	
end-time	<pre> Parameter type: <Sys::DSTRecurring> Format: (jan - first - sun : <Sys::DSThour> : <Sys::DSTmin> jan - first - mon : <Sys::DSThour> : <Sys::DSTmin> jan - first - tues : <Sys::DSThour> : <Sys::DSTmin> jan - first - wed : <Sys::DSThour> : <Sys::DSTmin> jan - first - thur : <Sys::DSThour> : <Sys::DSTmin> jan - first - fri : <Sys::DSThour> : <Sys::DSTmin> jan - first - sat : <Sys::DSThour> : <Sys::DSTmin> jan - second - sun : <Sys::DSThour> : <Sys::DSTmin> jan - second - mon : <Sys::DSThour> : <Sys::DSTmin> jan - second - tues : <Sys::DSThour> : <Sys::DSTmin> jan - second - wed : <Sys::DSThour> : <Sys::DSTmin> jan - second - thur : <Sys::DSThour> : <Sys::DSTmin> jan - second - fri : <Sys::DSThour> : <Sys::DSTmin> </pre>	<i>mandatory parameter</i> configure end time of daylight saving time

Parameter	Type	Description
	jan - second - sat : <Sys::DSThour> : <Sys::DSTmin> jan - third - sun : <Sys::DSThour> : <Sys::DSTmin> jan - third - mon : <Sys::DSThour> : <Sys::DSTmin> jan - third - tues : <Sys::DSThour> : <Sys::DSTmin> jan - third - wed : <Sys::DSThour> : <Sys::DSTmin> jan - third - thur : <Sys::DSThour> : <Sys::DSTmin> jan - third - fri : <Sys::DSThour> : <Sys::DSTmin> jan - third - sat : <Sys::DSThour> : <Sys::DSTmin> jan - fourth - sun : <Sys::DSThour> : <Sys::DSTmin> jan - fourth - mon : <Sys::DSThour> : <Sys::DSTmin> jan - fourth - tues : <Sys::DSThour> : <Sys::DSTmin> jan - fourth - wed : <Sys::DSThour> : <Sys::DSTmin> jan - fourth - thur : <Sys::DSThour> : <Sys::DSTmin> jan - fourth - fri : <Sys::DSThour> : <Sys::DSTmin> jan - fourth - sat : <Sys::DSThour> : <Sys::DSTmin> jan - last - sun : <Sys::DSThour> : <Sys::DSTmin> jan - last - mon : <Sys::DSThour> : <Sys::DSTmin> jan - last - tues : <Sys::DSThour> : <Sys::DSTmin> jan - last - wed : <Sys::DSThour> : <Sys::DSTmin> jan - last - thur : <Sys::DSThour> : <Sys::DSTmin> jan - last - fri : <Sys::DSThour> : <Sys::DSTmin> jan - last - sat : <Sys::DSThour> : <Sys::DSTmin> feb - first - sun : <Sys::DSThour> : <Sys::DSTmin> feb - first - mon : <Sys::DSThour> : <Sys::DSTmin> feb - first - tues : <Sys::DSThour> : <Sys::DSTmin> feb - first - wed : <Sys::DSThour> : <Sys::DSTmin> feb - first - thur : <Sys::DSThour> : <Sys::DSTmin> feb - first - fri : <Sys::DSThour> : <Sys::DSTmin> feb - first - sat : <Sys::DSThour> : <Sys::DSTmin> feb - second - sun : <Sys::DSThour> : <Sys::DSTmin> feb - second - mon : <Sys::DSThour> : <Sys::DSTmin> feb - second - tues : <Sys::DSThour> : <Sys::DSTmin> feb - second - wed : <Sys::DSThour> : <Sys::DSTmin> feb - second - thur : <Sys::DSThour> : <Sys::DSTmin> feb - second - fri : <Sys::DSThour> : <Sys::DSTmin> feb - second - sat : <Sys::DSThour> : <Sys::DSTmin> feb - third - sun : <Sys::DSThour> : <Sys::DSTmin> feb - third - mon : <Sys::DSThour> : <Sys::DSTmin> feb - third - tues : <Sys::DSThour> : <Sys::DSTmin> feb - third - wed : <Sys::DSThour> : <Sys::DSTmin> feb - third - thur : <Sys::DSThour> : <Sys::DSTmin> feb - third - fri : <Sys::DSThour> : <Sys::DSTmin> feb - third - sat : <Sys::DSThour> : <Sys::DSTmin> feb - fourth - sun : <Sys::DSThour> : <Sys::DSTmin> feb - fourth - mon : <Sys::DSThour> : <Sys::DSTmin> feb - fourth - tues : <Sys::DSThour> : <Sys::DSTmin> feb - fourth - wed : <Sys::DSThour> : <Sys::DSTmin> feb - fourth - thur : <Sys::DSThour> : <Sys::DSTmin> feb - fourth - fri : <Sys::DSThour> : <Sys::DSTmin> feb - fourth - sat : <Sys::DSThour> : <Sys::DSTmin> feb - last - sun : <Sys::DSThour> : <Sys::DSTmin> feb - last - mon : <Sys::DSThour> : <Sys::DSTmin> feb - last - tues : <Sys::DSThour> : <Sys::DSTmin> feb - last - wed : <Sys::DSThour> : <Sys::DSTmin> feb - last - thur : <Sys::DSThour> : <Sys::DSTmin> feb - last - fri : <Sys::DSThour> : <Sys::DSTmin> feb - last - sat : <Sys::DSThour> : <Sys::DSTmin>	

15 System Configuration Commands

Parameter	Type	Description
	mar - first - sun : <Sys::DSThour> : <Sys::DSTmin> mar - first - mon : <Sys::DSThour> : <Sys::DSTmin> mar - first - tues : <Sys::DSThour> : <Sys::DSTmin> mar - first - wed : <Sys::DSThour> : <Sys::DSTmin> mar - first - thur : <Sys::DSThour> : <Sys::DSTmin> mar - first - fri : <Sys::DSThour> : <Sys::DSTmin> mar - first - sat : <Sys::DSThour> : <Sys::DSTmin> mar - second - sun : <Sys::DSThour> : <Sys::DSTmin> mar - second - mon : <Sys::DSThour> : <Sys::DSTmin> mar - second - tues : <Sys::DSThour> : <Sys::DSTmin> mar - second - wed : <Sys::DSThour> : <Sys::DSTmin> mar - second - thur : <Sys::DSThour> : <Sys::DSTmin> mar - second - fri : <Sys::DSThour> : <Sys::DSTmin> mar - second - sat : <Sys::DSThour> : <Sys::DSTmin> mar - third - sun : <Sys::DSThour> : <Sys::DSTmin> mar - third - mon : <Sys::DSThour> : <Sys::DSTmin> mar - third - tues : <Sys::DSThour> : <Sys::DSTmin> mar - third - wed : <Sys::DSThour> : <Sys::DSTmin> mar - third - thur : <Sys::DSThour> : <Sys::DSTmin> mar - third - fri : <Sys::DSThour> : <Sys::DSTmin> mar - third - sat : <Sys::DSThour> : <Sys::DSTmin> mar - fourth - sun : <Sys::DSThour> : <Sys::DSTmin> mar - fourth - mon : <Sys::DSThour> : <Sys::DSTmin> mar - fourth - tues : <Sys::DSThour> : <Sys::DSTmin> mar - fourth - wed : <Sys::DSThour> : <Sys::DSTmin> mar - fourth - thur : <Sys::DSThour> : <Sys::DSTmin> mar - fourth - fri : <Sys::DSThour> : <Sys::DSTmin> mar - fourth - sat : <Sys::DSThour> : <Sys::DSTmin> mar - last - sun : <Sys::DSThour> : <Sys::DSTmin> mar - last - mon : <Sys::DSThour> : <Sys::DSTmin> mar - last - tues : <Sys::DSThour> : <Sys::DSTmin> mar - last - wed : <Sys::DSThour> : <Sys::DSTmin> mar - last - thur : <Sys::DSThour> : <Sys::DSTmin> mar - last - fri : <Sys::DSThour> : <Sys::DSTmin> mar - last - sat : <Sys::DSThour> : <Sys::DSTmin> apr - first - sun : <Sys::DSThour> : <Sys::DSTmin> apr - first - mon : <Sys::DSThour> : <Sys::DSTmin> apr - first - tues : <Sys::DSThour> : <Sys::DSTmin> apr - first - wed : <Sys::DSThour> : <Sys::DSTmin> apr - first - thur : <Sys::DSThour> : <Sys::DSTmin> apr - first - fri : <Sys::DSThour> : <Sys::DSTmin> apr - first - sat : <Sys::DSThour> : <Sys::DSTmin> apr - second - sun : <Sys::DSThour> : <Sys::DSTmin> apr - second - mon : <Sys::DSThour> : <Sys::DSTmin> apr - second - tues : <Sys::DSThour> : <Sys::DSTmin> apr - second - wed : <Sys::DSThour> : <Sys::DSTmin> apr - second - thur : <Sys::DSThour> : <Sys::DSTmin> apr - second - fri : <Sys::DSThour> : <Sys::DSTmin> apr - second - sat : <Sys::DSThour> : <Sys::DSTmin> apr - third - sun : <Sys::DSThour> : <Sys::DSTmin> apr - third - mon : <Sys::DSThour> : <Sys::DSTmin> apr - third - tues : <Sys::DSThour> : <Sys::DSTmin> apr - third - wed : <Sys::DSThour> : <Sys::DSTmin> apr - third - thur : <Sys::DSThour> : <Sys::DSTmin> apr - third - fri : <Sys::DSThour> : <Sys::DSTmin> apr - third - sat : <Sys::DSThour> : <Sys::DSTmin> apr - fourth - sun : <Sys::DSThour> : <Sys::DSTmin>	

Parameter	Type	Description
	apr - fourth - mon : <Sys::DSThour> : <Sys::DSTmin> apr - fourth - tues : <Sys::DSThour> : <Sys::DSTmin> apr - fourth - wed : <Sys::DSThour> : <Sys::DSTmin> apr - fourth - thur : <Sys::DSThour> : <Sys::DSTmin> apr - fourth - fri : <Sys::DSThour> : <Sys::DSTmin> apr - fourth - sat : <Sys::DSThour> : <Sys::DSTmin> apr - last - sun : <Sys::DSThour> : <Sys::DSTmin> apr - last - mon : <Sys::DSThour> : <Sys::DSTmin> apr - last - tues : <Sys::DSThour> : <Sys::DSTmin> apr - last - wed : <Sys::DSThour> : <Sys::DSTmin> apr - last - thur : <Sys::DSThour> : <Sys::DSTmin> apr - last - fri : <Sys::DSThour> : <Sys::DSTmin> apr - last - sat : <Sys::DSThour> : <Sys::DSTmin> may - first - sun : <Sys::DSThour> : <Sys::DSTmin> may - first - mon : <Sys::DSThour> : <Sys::DSTmin> may - first - tues : <Sys::DSThour> : <Sys::DSTmin> may - first - wed : <Sys::DSThour> : <Sys::DSTmin> may - first - thur : <Sys::DSThour> : <Sys::DSTmin> may - first - fri : <Sys::DSThour> : <Sys::DSTmin> may - first - sat : <Sys::DSThour> : <Sys::DSTmin> may - second - sun : <Sys::DSThour> : <Sys::DSTmin> may - second - mon : <Sys::DSThour> : <Sys::DSTmin> may - second - tues : <Sys::DSThour> : <Sys::DSTmin> may - second - wed : <Sys::DSThour> : <Sys::DSTmin> may - second - thur : <Sys::DSThour> : <Sys::DSTmin> may - second - fri : <Sys::DSThour> : <Sys::DSTmin> may - second - sat : <Sys::DSThour> : <Sys::DSTmin> may - third - sun : <Sys::DSThour> : <Sys::DSTmin> may - third - mon : <Sys::DSThour> : <Sys::DSTmin> may - third - tues : <Sys::DSThour> : <Sys::DSTmin> may - third - wed : <Sys::DSThour> : <Sys::DSTmin> may - third - thur : <Sys::DSThour> : <Sys::DSTmin> may - third - fri : <Sys::DSThour> : <Sys::DSTmin> may - third - sat : <Sys::DSThour> : <Sys::DSTmin> may - fourth - sun : <Sys::DSThour> : <Sys::DSTmin> may - fourth - mon : <Sys::DSThour> : <Sys::DSTmin> may - fourth - tues : <Sys::DSThour> : <Sys::DSTmin> may - fourth - wed : <Sys::DSThour> : <Sys::DSTmin> may - fourth - thur : <Sys::DSThour> : <Sys::DSTmin> may - fourth - fri : <Sys::DSThour> : <Sys::DSTmin> may - fourth - sat : <Sys::DSThour> : <Sys::DSTmin> may - last - sun : <Sys::DSThour> : <Sys::DSTmin> may - last - mon : <Sys::DSThour> : <Sys::DSTmin> may - last - tues : <Sys::DSThour> : <Sys::DSTmin> may - last - wed : <Sys::DSThour> : <Sys::DSTmin> may - last - thur : <Sys::DSThour> : <Sys::DSTmin> may - last - fri : <Sys::DSThour> : <Sys::DSTmin> may - last - sat : <Sys::DSThour> : <Sys::DSTmin> jun - first - sun : <Sys::DSThour> : <Sys::DSTmin> jun - first - mon : <Sys::DSThour> : <Sys::DSTmin> jun - first - tues : <Sys::DSThour> : <Sys::DSTmin> jun - first - wed : <Sys::DSThour> : <Sys::DSTmin> jun - first - thur : <Sys::DSThour> : <Sys::DSTmin> jun - first - fri : <Sys::DSThour> : <Sys::DSTmin> jun - first - sat : <Sys::DSThour> : <Sys::DSTmin> jun - second - sun : <Sys::DSThour> : <Sys::DSTmin> jun - second - mon : <Sys::DSThour> : <Sys::DSTmin>	

15 System Configuration Commands

Parameter	Type	Description
	jun - second - tues : <Sys::DSThour> : <Sys::DSTmin> jun - second - wed : <Sys::DSThour> : <Sys::DSTmin> jun - second - thur : <Sys::DSThour> : <Sys::DSTmin> jun - second - fri : <Sys::DSThour> : <Sys::DSTmin> jun - second - sat : <Sys::DSThour> : <Sys::DSTmin> jun - third - sun : <Sys::DSThour> : <Sys::DSTmin> jun - third - mon : <Sys::DSThour> : <Sys::DSTmin> jun - third - tues : <Sys::DSThour> : <Sys::DSTmin> jun - third - wed : <Sys::DSThour> : <Sys::DSTmin> jun - third - thur : <Sys::DSThour> : <Sys::DSTmin> jun - third - fri : <Sys::DSThour> : <Sys::DSTmin> jun - third - sat : <Sys::DSThour> : <Sys::DSTmin> jun - fourth - sun : <Sys::DSThour> : <Sys::DSTmin> jun - fourth - mon : <Sys::DSThour> : <Sys::DSTmin> jun - fourth - tues : <Sys::DSThour> : <Sys::DSTmin> jun - fourth - wed : <Sys::DSThour> : <Sys::DSTmin> jun - fourth - thur : <Sys::DSThour> : <Sys::DSTmin> jun - fourth - fri : <Sys::DSThour> : <Sys::DSTmin> jun - fourth - sat : <Sys::DSThour> : <Sys::DSTmin> jun - last - sun : <Sys::DSThour> : <Sys::DSTmin> jun - last - mon : <Sys::DSThour> : <Sys::DSTmin> jun - last - tues : <Sys::DSThour> : <Sys::DSTmin> jun - last - wed : <Sys::DSThour> : <Sys::DSTmin> jun - last - thur : <Sys::DSThour> : <Sys::DSTmin> jun - last - fri : <Sys::DSThour> : <Sys::DSTmin> jun - last - sat : <Sys::DSThour> : <Sys::DSTmin> jul - first - sun : <Sys::DSThour> : <Sys::DSTmin> jul - first - mon : <Sys::DSThour> : <Sys::DSTmin> jul - first - tues : <Sys::DSThour> : <Sys::DSTmin> jul - first - wed : <Sys::DSThour> : <Sys::DSTmin> jul - first - thur : <Sys::DSThour> : <Sys::DSTmin> jul - first - fri : <Sys::DSThour> : <Sys::DSTmin> jul - first - sat : <Sys::DSThour> : <Sys::DSTmin> jul - second - sun : <Sys::DSThour> : <Sys::DSTmin> jul - second - mon : <Sys::DSThour> : <Sys::DSTmin> jul - second - tues : <Sys::DSThour> : <Sys::DSTmin> jul - second - wed : <Sys::DSThour> : <Sys::DSTmin> jul - second - thur : <Sys::DSThour> : <Sys::DSTmin> jul - second - fri : <Sys::DSThour> : <Sys::DSTmin> jul - second - sat : <Sys::DSThour> : <Sys::DSTmin> jul - third - sun : <Sys::DSThour> : <Sys::DSTmin> jul - third - mon : <Sys::DSThour> : <Sys::DSTmin> jul - third - tues : <Sys::DSThour> : <Sys::DSTmin> jul - third - wed : <Sys::DSThour> : <Sys::DSTmin> jul - third - thur : <Sys::DSThour> : <Sys::DSTmin> jul - third - fri : <Sys::DSThour> : <Sys::DSTmin> jul - third - sat : <Sys::DSThour> : <Sys::DSTmin> jul - fourth - sun : <Sys::DSThour> : <Sys::DSTmin> jul - fourth - mon : <Sys::DSThour> : <Sys::DSTmin> jul - fourth - tues : <Sys::DSThour> : <Sys::DSTmin> jul - fourth - wed : <Sys::DSThour> : <Sys::DSTmin> jul - fourth - thur : <Sys::DSThour> : <Sys::DSTmin> jul - fourth - fri : <Sys::DSThour> : <Sys::DSTmin> jul - fourth - sat : <Sys::DSThour> : <Sys::DSTmin> jul - last - sun : <Sys::DSThour> : <Sys::DSTmin> jul - last - mon : <Sys::DSThour> : <Sys::DSTmin> jul - last - tues : <Sys::DSThour> : <Sys::DSTmin>	

Parameter	Type	Description
	- jul - last - wed : <Sys::DSThour> : <Sys::DSTmin> - jul - last - thur : <Sys::DSThour> : <Sys::DSTmin> - jul - last - fri : <Sys::DSThour> : <Sys::DSTmin> - jul - last - sat : <Sys::DSThour> : <Sys::DSTmin> - aug - first - sun : <Sys::DSThour> : <Sys::DSTmin> - aug - first - mon : <Sys::DSThour> : <Sys::DSTmin> - aug - first - tues : <Sys::DSThour> : <Sys::DSTmin> - aug - first - wed : <Sys::DSThour> : <Sys::DSTmin> - aug - first - thur : <Sys::DSThour> : <Sys::DSTmin> - aug - first - fri : <Sys::DSThour> : <Sys::DSTmin> - aug - first - sat : <Sys::DSThour> : <Sys::DSTmin> - aug - second - sun : <Sys::DSThour> : <Sys::DSTmin> - aug - second - mon : <Sys::DSThour> : <Sys::DSTmin> - aug - second - tues : <Sys::DSThour> : <Sys::DSTmin> - aug - second - wed : <Sys::DSThour> : <Sys::DSTmin> - aug - second - thur : <Sys::DSThour> : <Sys::DSTmin> - aug - second - fri : <Sys::DSThour> : <Sys::DSTmin> - aug - second - sat : <Sys::DSThour> : <Sys::DSTmin> - aug - third - sun : <Sys::DSThour> : <Sys::DSTmin> - aug - third - mon : <Sys::DSThour> : <Sys::DSTmin> - aug - third - tues : <Sys::DSThour> : <Sys::DSTmin> - aug - third - wed : <Sys::DSThour> : <Sys::DSTmin> - aug - third - thur : <Sys::DSThour> : <Sys::DSTmin> - aug - third - fri : <Sys::DSThour> : <Sys::DSTmin> - aug - third - sat : <Sys::DSThour> : <Sys::DSTmin> - aug - fourth - sun : <Sys::DSThour> : <Sys::DSTmin> - aug - fourth - mon : <Sys::DSThour> : <Sys::DSTmin> - aug - fourth - tues : <Sys::DSThour> : <Sys::DSTmin> - aug - fourth - wed : <Sys::DSThour> : <Sys::DSTmin> - aug - fourth - thur : <Sys::DSThour> : <Sys::DSTmin> - aug - fourth - fri : <Sys::DSThour> : <Sys::DSTmin> - aug - fourth - sat : <Sys::DSThour> : <Sys::DSTmin> - aug - last - sun : <Sys::DSThour> : <Sys::DSTmin> - aug - last - mon : <Sys::DSThour> : <Sys::DSTmin> - aug - last - tues : <Sys::DSThour> : <Sys::DSTmin> - aug - last - wed : <Sys::DSThour> : <Sys::DSTmin> - aug - last - thur : <Sys::DSThour> : <Sys::DSTmin> - aug - last - fri : <Sys::DSThour> : <Sys::DSTmin> - aug - last - sat : <Sys::DSThour> : <Sys::DSTmin> - sep - first - sun : <Sys::DSThour> : <Sys::DSTmin> - sep - first - mon : <Sys::DSThour> : <Sys::DSTmin> - sep - first - tues : <Sys::DSThour> : <Sys::DSTmin> - sep - first - wed : <Sys::DSThour> : <Sys::DSTmin> - sep - first - thur : <Sys::DSThour> : <Sys::DSTmin> - sep - first - fri : <Sys::DSThour> : <Sys::DSTmin> - sep - first - sat : <Sys::DSThour> : <Sys::DSTmin> - sep - second - sun : <Sys::DSThour> : <Sys::DSTmin> - sep - second - mon : <Sys::DSThour> : <Sys::DSTmin> - sep - second - tues : <Sys::DSThour> : <Sys::DSTmin> - sep - second - wed : <Sys::DSThour> : <Sys::DSTmin> - sep - second - thur : <Sys::DSThour> : <Sys::DSTmin> - sep - second - fri : <Sys::DSThour> : <Sys::DSTmin> - sep - second - sat : <Sys::DSThour> : <Sys::DSTmin> - sep - third - sun : <Sys::DSThour> : <Sys::DSTmin> - sep - third - mon : <Sys::DSThour> : <Sys::DSTmin> - sep - third - tues : <Sys::DSThour> : <Sys::DSTmin> - sep - third - wed : <Sys::DSThour> : <Sys::DSTmin>	

15 System Configuration Commands

Parameter	Type	Description
	sep - third - thur : <Sys::DSThour> : <Sys::DSTmin> sep - third - fri : <Sys::DSThour> : <Sys::DSTmin> sep - third - sat : <Sys::DSThour> : <Sys::DSTmin> sep - fourth - sun : <Sys::DSThour> : <Sys::DSTmin> sep - fourth - mon : <Sys::DSThour> : <Sys::DSTmin> sep - fourth - tues : <Sys::DSThour> : <Sys::DSTmin> sep - fourth - wed : <Sys::DSThour> : <Sys::DSTmin> sep - fourth - thur : <Sys::DSThour> : <Sys::DSTmin> sep - fourth - fri : <Sys::DSThour> : <Sys::DSTmin> sep - fourth - sat : <Sys::DSThour> : <Sys::DSTmin> sep - last - sun : <Sys::DSThour> : <Sys::DSTmin> sep - last - mon : <Sys::DSThour> : <Sys::DSTmin> sep - last - tues : <Sys::DSThour> : <Sys::DSTmin> sep - last - wed : <Sys::DSThour> : <Sys::DSTmin> sep - last - thur : <Sys::DSThour> : <Sys::DSTmin> sep - last - fri : <Sys::DSThour> : <Sys::DSTmin> sep - last - sat : <Sys::DSThour> : <Sys::DSTmin> oct - first - sun : <Sys::DSThour> : <Sys::DSTmin> oct - first - mon : <Sys::DSThour> : <Sys::DSTmin> oct - first - tues : <Sys::DSThour> : <Sys::DSTmin> oct - first - wed : <Sys::DSThour> : <Sys::DSTmin> oct - first - thur : <Sys::DSThour> : <Sys::DSTmin> oct - first - fri : <Sys::DSThour> : <Sys::DSTmin> oct - first - sat : <Sys::DSThour> : <Sys::DSTmin> oct - second - sun : <Sys::DSThour> : <Sys::DSTmin> oct - second - mon : <Sys::DSThour> : <Sys::DSTmin> oct - second - tues : <Sys::DSThour> : <Sys::DSTmin> oct - second - wed : <Sys::DSThour> : <Sys::DSTmin> oct - second - thur : <Sys::DSThour> : <Sys::DSTmin> oct - second - fri : <Sys::DSThour> : <Sys::DSTmin> oct - second - sat : <Sys::DSThour> : <Sys::DSTmin> oct - third - sun : <Sys::DSThour> : <Sys::DSTmin> oct - third - mon : <Sys::DSThour> : <Sys::DSTmin> oct - third - tues : <Sys::DSThour> : <Sys::DSTmin> oct - third - wed : <Sys::DSThour> : <Sys::DSTmin> oct - third - thur : <Sys::DSThour> : <Sys::DSTmin> oct - third - fri : <Sys::DSThour> : <Sys::DSTmin> oct - third - sat : <Sys::DSThour> : <Sys::DSTmin> oct - fourth - sun : <Sys::DSThour> : <Sys::DSTmin> oct - fourth - mon : <Sys::DSThour> : <Sys::DSTmin> oct - fourth - tues : <Sys::DSThour> : <Sys::DSTmin> oct - fourth - wed : <Sys::DSThour> : <Sys::DSTmin> oct - fourth - thur : <Sys::DSThour> : <Sys::DSTmin> oct - fourth - fri : <Sys::DSThour> : <Sys::DSTmin> oct - fourth - sat : <Sys::DSThour> : <Sys::DSTmin> oct - last - sun : <Sys::DSThour> : <Sys::DSTmin> oct - last - mon : <Sys::DSThour> : <Sys::DSTmin> oct - last - tues : <Sys::DSThour> : <Sys::DSTmin> oct - last - wed : <Sys::DSThour> : <Sys::DSTmin> oct - last - thur : <Sys::DSThour> : <Sys::DSTmin> oct - last - fri : <Sys::DSThour> : <Sys::DSTmin> oct - last - sat : <Sys::DSThour> : <Sys::DSTmin> nov - first - sun : <Sys::DSThour> : <Sys::DSTmin> nov - first - mon : <Sys::DSThour> : <Sys::DSTmin> nov - first - tues : <Sys::DSThour> : <Sys::DSTmin> nov - first - wed : <Sys::DSThour> : <Sys::DSTmin> nov - first - thur : <Sys::DSThour> : <Sys::DSTmin>	

Parameter	Type	Description
	nov - first - fri : <Sys::DSThour> : <Sys::DSTmin> nov - first - sat : <Sys::DSThour> : <Sys::DSTmin> nov - second - sun : <Sys::DSThour> : <Sys::DSTmin> nov - second - mon : <Sys::DSThour> : <Sys::DSTmin> nov - second - tues : <Sys::DSThour> : <Sys::DSTmin> nov - second - wed : <Sys::DSThour> : <Sys::DSTmin> nov - second - thur : <Sys::DSThour> : <Sys::DSTmin> nov - second - fri : <Sys::DSThour> : <Sys::DSTmin> nov - second - sat : <Sys::DSThour> : <Sys::DSTmin> nov - third - sun : <Sys::DSThour> : <Sys::DSTmin> nov - third - mon : <Sys::DSThour> : <Sys::DSTmin> nov - third - tues : <Sys::DSThour> : <Sys::DSTmin> nov - third - wed : <Sys::DSThour> : <Sys::DSTmin> nov - third - thur : <Sys::DSThour> : <Sys::DSTmin> nov - third - fri : <Sys::DSThour> : <Sys::DSTmin> nov - third - sat : <Sys::DSThour> : <Sys::DSTmin> nov - fourth - sun : <Sys::DSThour> : <Sys::DSTmin> nov - fourth - mon : <Sys::DSThour> : <Sys::DSTmin> nov - fourth - tues : <Sys::DSThour> : <Sys::DSTmin> nov - fourth - wed : <Sys::DSThour> : <Sys::DSTmin> nov - fourth - thur : <Sys::DSThour> : <Sys::DSTmin> nov - fourth - fri : <Sys::DSThour> : <Sys::DSTmin> nov - fourth - sat : <Sys::DSThour> : <Sys::DSTmin> nov - last - sun : <Sys::DSThour> : <Sys::DSTmin> nov - last - mon : <Sys::DSThour> : <Sys::DSTmin> nov - last - tues : <Sys::DSThour> : <Sys::DSTmin> nov - last - wed : <Sys::DSThour> : <Sys::DSTmin> nov - last - thur : <Sys::DSThour> : <Sys::DSTmin> nov - last - fri : <Sys::DSThour> : <Sys::DSTmin> nov - last - sat : <Sys::DSThour> : <Sys::DSTmin> dec - first - sun : <Sys::DSThour> : <Sys::DSTmin> dec - first - mon : <Sys::DSThour> : <Sys::DSTmin> dec - first - tues : <Sys::DSThour> : <Sys::DSTmin> dec - first - wed : <Sys::DSThour> : <Sys::DSTmin> dec - first - thur : <Sys::DSThour> : <Sys::DSTmin> dec - first - fri : <Sys::DSThour> : <Sys::DSTmin> dec - first - sat : <Sys::DSThour> : <Sys::DSTmin> dec - second - sun : <Sys::DSThour> : <Sys::DSTmin> dec - second - mon : <Sys::DSThour> : <Sys::DSTmin> dec - second - tues : <Sys::DSThour> : <Sys::DSTmin> dec - second - wed : <Sys::DSThour> : <Sys::DSTmin> dec - second - thur : <Sys::DSThour> : <Sys::DSTmin> dec - second - fri : <Sys::DSThour> : <Sys::DSTmin> dec - second - sat : <Sys::DSThour> : <Sys::DSTmin> dec - third - sun : <Sys::DSThour> : <Sys::DSTmin> dec - third - mon : <Sys::DSThour> : <Sys::DSTmin> dec - third - tues : <Sys::DSThour> : <Sys::DSTmin> dec - third - wed : <Sys::DSThour> : <Sys::DSTmin> dec - third - thur : <Sys::DSThour> : <Sys::DSTmin> dec - third - fri : <Sys::DSThour> : <Sys::DSTmin> dec - third - sat : <Sys::DSThour> : <Sys::DSTmin> dec - fourth - sun : <Sys::DSThour> : <Sys::DSTmin> dec - fourth - mon : <Sys::DSThour> : <Sys::DSTmin> dec - fourth - tues : <Sys::DSThour> : <Sys::DSTmin> dec - fourth - wed : <Sys::DSThour> : <Sys::DSTmin> dec - fourth - thur : <Sys::DSThour> : <Sys::DSTmin> dec - fourth - fri : <Sys::DSThour> : <Sys::DSTmin>	

15 System Configuration Commands

Parameter	Type	Description
	<pre>dec - fourth - sat : <Sys::DSThour> : <Sys::DSTmin> dec - last - sun : <Sys::DSThour> : <Sys::DSTmin> dec - last - mon : <Sys::DSThour> : <Sys::DSTmin> dec - last - tues : <Sys::DSThour> : <Sys::DSTmin> dec - last - wed : <Sys::DSThour> : <Sys::DSTmin> dec - last - thur : <Sys::DSThour> : <Sys::DSTmin> dec - last - fri : <Sys::DSThour> : <Sys::DSTmin> dec - last - sat : <Sys::DSThour> : <Sys::DSTmin>)</pre> Possible values: - jan : january - feb : february - mar : march - apr : april - may : may - jun : june - jul : july - aug : august - sep : september - oct : october - nov : november - dec : december Possible values: - first : first week of the month - second : second week of the month - third : third week of the month - fourth : fourth week of the month - last : last week of the month Possible values: - sun : sunday - mon : monday - tues : tuesday - wed : wednesday - thur : thursday - fri : friday - sat : saturday Field type <Sys::DSThour> - hour - range: [0...23] Field type <Sys::DSTmin> - minutes - unit: minutes - range: [0...59]	
[no] offset	Parameter type: <Sys::DstAdjustment> Format: - The number of minutes that will be adjusted to the time - unit: minutes - range: [0...60]	<i>optional parameter with default value: 60</i> configure offset of daylight saving time

15.10 System Loop ID Syntax Configuration

Command

Command Description

This command allows the operator to configure the system loop ID syntax. For atm-based-dsl, default value is "Access_Node_ID atm Rack/Frame/Slot/Port:VPI.VCI". For efm-based-dsl, default value is "Access_Node_ID eth Rack/Frame/Slot/Port". For efm-based-pon, default value is "Access_Node_ID eth Rack/Frame/Slot/Port/ONU/OnuSlt/UNI". For efm-based-epon, default value is "Bras Access_Node_ID/Rack/Frame/Slot/Subslot/Port/ONT Oft". For efm-based-ngpon2, default value is "Access_Node_ID eth ng2:Channelgroup/Subchannelgroup/ONU/OnuSlt/UNI". For NT-port, default value is "Access_Node_ID nt Ntslot/PrtType/Port".

The system loop ID syntax is a concatenation of keywords, separators and free text strings.

The operator can use the following predefined keywords to construct the system loop ID :

- **Bras** to specify the Bras identifier.
- **Access_Node_ID** to specify the system id.
- **Rack** to specify the rack number.
- **Frame** to specify the shelf number.
- **Slot** to specify the slot number.
- **Subslot** to specify the slot number in ONT. Subslot is only supported for EPON.
- **ShSlt** to specify the slot number without leading zero.
- **Port** to specify the port number.
- **ShPrt** to specify the port number without leading zero.
- **VPI** to specify the vpi.
- **VCI** to specify the vci.
- **Q-VID** to specify the vlan identifier.
- **LzQVID** to specify the vlan identifier with leading zero.
- **DUVID** to specify that user untagged vlan identifier is not added in string.
- **U-VID** to specify that user untagged vlan identifier is not added in string. When it is the last keyword and the value is null, it removes all non-keywords before it.
- **I-VID** to specify the user side inner vlan identifier.
- **ONT** to specify the ONT id which connecting to OLT. Here using the ONUs MAC as id. it is represented with 12 ASCII characters. ONT is only supported for EPON.
- **ONU** to specify the number of the ONU without leading zero.
- **LzOnu** to specify the number of the ONU with leading zero.
- **OnuSlt** to specify the slot number on the ONU without leading zero.
- **UNI** to specify the number of UNI on the ONU without leading zero.
- **N-VID** to specify the network VLAN identifier.
- **LzNVID** to specify the network VLAN identifier with leading zeros (should not be used on GPON/EPON, neither for ANCP).
- **LzSVID** to specify the network S-VLAN identifier in S+C VLAN forwarding model with leading zeros (should not be used on GPON/EPON, neither for ANCP).
- **Oft** to specify the ONU format. It is a string.
- **OnuSN** to specify the ONU with the serial number.
- **NzOnuSN** to specify the ONU with the serial number without leading zeros.
- **OnuLD** to specify the ONU with logical authentication ID.
- **OntMAC** to specify the ONU with the MAC address. OntMAC is only supported for EPON.
- **Channelgroup** to specify the multi-wavelength optical feeder fiber.
- **Subchannelgroup** to specify the administrative domain within a channelgroup.
- **S-MAC** to specify the system MAC address.
- **Ntslot** to specify the nt slot.

- *PrtType* to specify the nt port type.

Note : the ONT and ONU related keywords are relevant only for the pon and epon syntax.

Note : according to Broadband Forum TR-156, the ONT always adds a VLAN tag before sending the traffic to the OLT. In such case, the OLT not longer knows if traffic arrived at the ONT untagged or tagged. Therefore for GPON, the keywords "DUVID" and "U-VID" will have the same behavior as "Q-VID".

User Level

The command can be accessed by operators with security privileges, and executed by operators with security privileges.

Command Syntax

The command has the following syntax:

```
> configure system loop-id-syntax [ no atm-based-dsl | atm-based-dsl <PrintableString-0-80> ] [ no efm-based-dsl | efm-based-dsl <PrintableString-0-80> ] [ no efm-based-pon | efm-based-pon <PrintableString-0-80> ] [ no efm-based-epon | efm-based-epon <PrintableString-0-80> ] [ no efm-based-ngpon2 | efm-based-ngpon2 <PrintableString-0-80> ]
```

Command Parameters

Table 15.10-2 "System Loop ID Syntax Configuration Command" Command Parameters

Parameter	Type	Description
[no] atm-based-dsl	Parameter type: <PrintableString-0-80> Format: - a printable string - length: x<=80	<i>optional parameter with default value: "Access_Node_ID atm Rack/Frame/Slot/Port : VPI.VCI"</i> define the syntax of loop Id for atm based dsl lines
[no] efm-based-dsl	Parameter type: <PrintableString-0-80> Format: - a printable string - length: x<=80	<i>optional parameter with default value: "Access_Node_ID eth Rack/Frame/Slot/Port"</i> defines the syntax of loop Id for efm based dsl lines
[no] efm-based-pon	Parameter type: <PrintableString-0-80> Format: - a printable string - length: x<=80	<i>optional parameter with default value: "Access_Node_ID eth Rack/Frame/Slot/Port/ONU/Onuslot/UNID"</i> defines the syntax of loop Id for efm based pon lines
[no] efm-based-epon	Parameter type: <PrintableString-0-80> Format: - a printable string - length: x<=80	<i>optional parameter with default value: "Bras Access_Node_ID/Rack/Frame/Slot/Subslot/ONT/ONTid"</i> defines the syntax of loop Id for efm based epon lines, suggest OntMAC for dpoe
[no] efm-based-ngpon2	Parameter type: <PrintableString-0-80> Format: - a printable string - length: x<=80	<i>optional parameter with default value: "Access_Node_ID eth ng2 : Channelgroup/Subchannelgroup/ONU/CPEgroup"</i> defines the syntax of loop Id for efm based ngpon2 lines

15.11 Maximum Lt Link Speed Configuration Command

Command Description

This command allows the operator to configure the maximum lt link speed.

Note: maxltlinkspeed value 20Gb is not supported on NANT-E, this is only supported on FANT-F.

User Level

The command can be accessed by operators with equipment privileges, and executed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

```
> configure system max-lt-link-speed [ no link-speed | link-speed <Sys::MaxLtLinkSpeed> ]
```

Command Parameters

Table 15.11-2 "Maximum Lt Link Speed Configuration Command" Command Parameters

Parameter	Type	Description
[no] link-speed	Parameter type: <Sys::MaxLtLinkSpeed> Format: (one-gb twodotfive-gb ten-gb twenty-gb twentyfive-gb forty-gb fifty-gb one-hundred-gb) Possible values: - one-gb : enables max 1 Gbps lt link speed - twodotfive-gb : enables max 2.5 Gbps lt link speed - ten-gb : enables max 10 Gbps lt link speed - twenty-gb : enables max 20 Gbps lt link speed - twentyfive-gb : enables max 25 Gbps lt link speed - forty-gb : enables max 40 Gbps lt link speed - fifty-gb : enables max 50 Gbps lt link speed - one-hundred-gb : enables max 100 Gbps lt link speed	<i>optional parameter with default value: "one-gb"</i> the maximum lt link speed

15.12 System ONT Configuration Command

Command Description

Obsolete command, replaced by `configure generic-pon ont`, `configure pon pwrbrst-mode`.

This command is to configure the specific ONT and PON related parameters.

User Level

The command can be accessed by operators with equipment privileges, and executed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

```
> configure system pon-ont [ no slid-mode | slid-mode <Gpon::SlidMode> ] [ no pwrbrst-mode | pwrbrst-mode
<Gpon::PowerBurstMode> ] [ no sn-bundle-timer | sn-bundle-timer <Gpon::SnBundleTimer> ] [ no
sw-ver-mis-block | sw-ver-mis-block <Gpon::SwVerMisBlock> ] [ no sn-autounlock | sn-autounlock
<Gpon::OntAuthMode> ]
```

Obsolete command, replaced by `configure generic-pon ont`, `configure pon pwrbrst-mode`.

Command Parameters

Table 15.12-2 "System ONT Configuration Command" Command Parameters

Parameter	Type	Description
[no] slid-mode	Parameter type: <Gpon::SlidMode> Format: (ascii hexa-dec) Possible values: - ascii : ascii interpretation for subscriber location - hexa-dec : hexadecimal mode interpretation for subscriber location	<i>optional parameter with default value: "ascii"</i> display interpretation for subscriber location id
[no] pwrbrst-mode	Parameter type: <Gpon::PowerBurstMode> Format: (disable enable) Possible values: - disable : disable power burst detection mode - enable : enable power burst detection mode	<i>optional parameter with default value: "disable"</i> power burst detection mode for pon
[no] sn-bundle-timer	Parameter type: <Gpon::SnBundleTimer> Format: - the system timer for auto bundling sn - unit: hour - range: [1...72]	<i>optional parameter with default value: 24L</i> the system timer for bundling sn with loid/slid when ont is in auto-bundle mode
[no] sw-ver-mis-block	Parameter type: <Gpon::SwVerMisBlock> Format:	<i>optional parameter with default value: "enable"</i>

15 System Configuration Commands

Parameter	Type	Description
	(enable disable) Possible values: - enable : block the user traffic when ont version mismatch - disable : do not block the user traffic when ont version mismatch	the control behavior of user traffic block when ont version mismatch
[no] sn-autounlock	Parameter type: <Gpon::OntAuthMode> Format: (disable enable) Possible values: - disable : disable unlock ONT automatically after ONT authenticated - enable : enable unlock ONT automatically after ONT authenticated	<i>optional parameter with default value: "disable"</i> unlock ONT automatically after ONT authenticated

15.13 Epon System PM Configuration Command

Command Description

This command allows the operator to enable or disable the global pm collection.

User Level

The command can be accessed by operators with equipment privileges, and executed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

```
> configure system epon [ no pm-collect | pm-collect <epon::pmcollect> ] [ no onuidmthd | onuidmthd
<epon::accessloophonuidmthd> ] [ no rogueadmin | rogueadmin <epon::rogueonuadmin> ]
```

Command Parameters

Table 15.13-2 "Epon System PM Configuration Command" Command Parameters

Parameter	Type	Description
[no] pm-collect	Parameter type: <epon::pmcollect> Format: (enable disable) Possible values: - enable : PM collection enabled - disable : PM collection disabled	<i>optional parameter with default value: "disable"</i> enable or disable the global pm collection
[no] onuidmthd	Parameter type: <epon::accessloophonuidmthd> Format: (mac loid) Possible values: - mac : fill onu id with mac@ - loid : fill onu id with loid	<i>optional parameter with default value: "mac"</i> access loop onu id method
[no] rogueadmin	Parameter type: <epon::rogueonuadmin> Format: (autodisable manualdisable) Possible values: - autodisable : auto disable rogue onu - manualdisable : manual disable rogue onu	<i>optional parameter with default value: "manualdisable"</i> choose auto or manual disable a rogue onu

15.14 System Synchronous Interface Timing Clock Configuration Command

Command Description

This command allows the operator to configure all the Clock Synchronization (NTR) characteristics of the ISAM node.

The underlying commands and parameters are applicable for the NT's supporting Enhanced Clock Management.

User Level

The command can be accessed by operators with equipment privileges, and executed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

```
> configure system sync-if-timing [ [ no ] revert ] [ no wait-time | wait-time <Sys::SysClkWaitTime> ] [ no output-ql-thresh | output-ql-thresh <Ntr::SysClkSrcQL> ] [ [ no ] ssmout-en-bits ] [ no ssmout-ceiling | ssmout-ceiling <Ntr::DefSysClkSrcQL> ] [ no ais-sensitivity | ais-sensitivity <Sys::SysClkAisSensitivity> ]
```

Command Parameters

Table 15.14-2 "System Synchronous Interface Timing Clock Configuration Command" Command Parameters

Parameter	Type	Description
[no] revert	Parameter type: boolean	<i>optional parameter</i> configure system clock to revertive or non-revertive. As a limitation non-revertive mode is not supported in duplex NTs.
[no] wait-time	Parameter type: <Sys::SysClkWaitTime> Format: - time to wait a clock source become eligible - unit: seconds - range: [0...720]	<i>optional parameter with default value: 10</i> configure time to wait on the reference switchover
[no] output-ql-thresh	Parameter type: <Ntr::SysClkSrcQL> Format: (clk-ql-stu clk-ql-prs clk-ql-prc clk-ql-inv3 clk-ql-ssu-a-tnc clk-ql-ssu-a clk-ql-tnc	<i>optional parameter with default value: "clk-ql-dnu-dus"</i> configure system threshold of BITS output QL

Parameter	Type	Description
	clk-ql-inv5 clk-ql-inv6 clk-ql-st2 clk-ql-ssu-b clk-ql-inv9 clk-ql-st3 clk-ql-sec clk-ql-smc clk-ql-st3e clk-ql-prov clk-ql-dnu-dus clk-ql-dnu clk-ql-dus) Possible values: - clk-ql-stu : Synchronized-Traceability Unknown - clk-ql-prs : Primary Reference Source - clk-ql-prc : Primary Reference Clock - clk-ql-inv3 : Quality Level unallocated - clk-ql-ssu-a-tnc : Traced to Sync Supply Unit-A/Transmit Node Clock - clk-ql-ssu-a : Traced to Sync Supply Unit-A(ETSI) - clk-ql-tnc : Traced to Transmit Node Clock(ANSI) - clk-ql-inv5 : Quality Level unallocated - clk-ql-inv6 : Quality Level unallocated - clk-ql-st2 : Traceable to Stratum 2 - clk-ql-ssu-b : Traced to Sync Supply Unit-B - clk-ql-inv9 : Quality Level unallocated - clk-ql-st3 : Traceable to Stratum 3 - clk-ql-sec : Traceable to SDH Equipment Clock - clk-ql-smc : Traceable to SONET Clock SelfTimed - clk-ql-st3e : Traceable to Stratum 3E - clk-ql-prov : Operator Provisioned - clk-ql-dnu-dus : Signal should not be used for sync - clk-ql-dnu : Signal should not be used for sync(ETSI) - clk-ql-dus : Signal should not be used for sync(ANSI)	
[no] ssmout-en-bits	Parameter type: boolean	<i>optional parameter</i> enable ssm-out bits mode
[no] ssmout-ceiling	Parameter type: <Ntr::DefSysClkSrcQL> Format: (clk-ql-stu clk-ql-prs clk-ql-prc clk-ql-inv3 clk-ql-ssu-a-tnc clk-ql-ssu-a clk-ql-tnc clk-ql-inv5 clk-ql-inv6 clk-ql-st2 clk-ql-ssu-b clk-ql-inv9 clk-ql-st3 clk-ql-sec clk-ql-smc clk-ql-st3e clk-ql-prov clk-ql-dnu-dus	<i>optional parameter with default value: "clk-ql-sys-def"</i> configure system threshold of BITS and Sync output QL

15 System Configuration Commands

Parameter	Type	Description
	clk-ql-dnu clk-ql-dus clk-ql-sys-def) Possible values: - clk-ql-stu : Synchronized-Traceability Unknown - clk-ql-prs : Primary Reference Source - clk-ql-prc : Primary Reference Clock - clk-ql-inv3 : Quality Level unallocated - clk-ql-ssu-a-tnc : Traced to Sync Supply Unit-A/Transmit Node Clock - clk-ql-ssu-a : Traced to Sync Supply Unit-A(ETSI) - clk-ql-tnc : Traced to Transmit Node Clock(ANSI) - clk-ql-inv5 : Quality Level unallocated - clk-ql-inv6 : Quality Level unallocated - clk-ql-st2 : Traceable to Stratum 2 - clk-ql-ssu-b : Traced to Sync Supply Unit-B - clk-ql-inv9 : Quality Level unallocated - clk-ql-st3 : Traceable to Stratum 3 - clk-ql-sec : Traceable to SDH Equipment Clock - clk-ql-smc : Traceable to SONET Clock SelfTimed - clk-ql-st3e : Traceable to Stratum 3E - clk-ql-prov : Operator Provisioned - clk-ql-dnu-dus : Signal should not be used for sync - clk-ql-dnu : Signal should not be used for sync(ETSI) - clk-ql-dus : Signal should not be used for sync(ANSI) - clk-ql-sys-def : System default value based on region type	
[no] ais-sensitivity	Parameter type: <Sys::SysClkAisSensitivity> Format: (enable disable) Possible values: - enable : enable AIS sensitivity as BITS failure detection - disable : disable AIS sensitivity as BITS failure detection	<i>optional parameter with default value: "disable"</i> configure the system to use AIS detection as BITS input failure

15.15 System Clock Bits Mode Configuration Command

Command Description

This command allows the operator to configure the clock bits mode. This command allow the operator to configure the BITS clock source based on the Network Timing Reference used as a BITS source. The operator can configure the values: E1, Ds1, 2048Khz or autoselect. When "autoselect" is configured, the system takes the default values:

- *ds1 for NTs with CLOCK capability=T1.*
- *e1 for NTs with CLOCK capability=E1.*

User Level

The command can be accessed by operators with equipment privileges, and executed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

```
> configure system sync-if-timing bits [ (interface-type) ]
```

Command Parameters

Table 15.15-2 "System Clock Bits Mode Configuration Command" Command Parameters

Parameter	Type	Description
(interface-type)	Format: (e1 ds1 khz2048 autoselect) Possible values: - e1 : select E1 Source - ds1 : select DS1 Source - khz2048 : select 2048KHz Source - autoselect : autoselect Source	<i>optional parameter</i> select the external clock type E1 or DS1 or 2048Khz

15.16 System Clock Source Priority Configuration Command

Command Description

This command allows the operator to configure the clock source priority.

User Level

The command can be accessed by operators with equipment privileges, and executed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

```
> configure system sync-if-timing ref-order (index) [ (priority) ]
```

Command Parameters

Table 15.16-1 "System Clock Source Priority Configuration Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: (prio1 prio2) Possible values: - prio1 : configure primary clock source - prio2 : configure secondary clock source	clock priority index

Table 15.16-2 "System Clock Source Priority Configuration Command" Command Parameters

Parameter	Type	Description
(priority)	Format: (bits-a bits-b synce-1 synce-2 ieee1588 ieee1588-a ieee1588-b none) Possible values: - bits-a : select BITS-A for this priority - bits-b : select BITS-B for this priority - synce-1 : select SyncE reference 1 for this priority - synce-2 : select SyncE reference 2 for this priority - ieee1588 : select IEEE 1588 clock for this priority - ieee1588-a : select IEEE 1588-A clock for this priority	<i>optional parameter</i> frequency clock priority selection

Parameter	Type	Description
	- ieee1588-b : select IEEE 1588-B clock for this priority - none : remove clock source for this priority	

15.17 System Clock ToD Sources Priority Configuration Command

Command Description

This command allows the operator to configure the priority of the ToD sources.

User Level

The command can be accessed by operators with equipment privileges, and executed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

```
> configure system sync-if-timing tod-ref-order (index) [ (priority) ]
```

Command Parameters

Table 15.17-1 "System Clock ToD Sources Priority Configuration Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: (prio1 prio2) Possible values: - prio1 : configure primary tod source - prio2 : configure secondary tod source	ToD clock priority index

Table 15.17-2 "System Clock ToD Sources Priority Configuration Command" Command Parameters

Parameter	Type	Description
(priority)	Format: (ieee1588-a ieee1588 ieee1588-b gnss-a gnss-b none) Possible values: - ieee1588-a : select IEEE 1588-A clock for this ToD priority - ieee1588 : select IEEE 1588 clock for this ToD priority - ieee1588-b : select IEEE 1588-B clock for this ToD priority - gnss-a : select GNSS-A clock for this ToD priority - gnss-b : select GNSS-B clock for this ToD priority	<i>optional parameter</i> ToD clock priority selection

Parameter	Type	Description
	- none : remove clock source for this ToD priority	

15.18 NTR PTP Configuration Command

Command Description

This node is meant to configure all parameters related to clock synchronization based on the IEEE1588 PTP protocol

User Level

The command can be accessed by operators with equipment privileges, and executed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

```
> configure system sync-if-timing ptp [ no transport-mode | transport-mode <Sys::SysClkPtpTransportMode> ] [ no
dynamic-update | dynamic-update <Sys::SysClkPtpDynamicUpdate> ] [ no tc-step-mode | tc-step-mode
<Ntr::PtpTCModeFormat> ] [ no max-steps-removed | max-steps-removed <Ntr::MaxStepsRemoved> ] [ no profile
| profile <Ntr::PtpProfileFormat> ]
```

Command Parameters

Table 15.18-2 "NTR PTP Configuration Command" Command Parameters

Parameter	Type	Description
[no] transport-mode	Parameter type: <Sys::SysClkPtpTransportMode> Format: (ucast-over-udp ucast-mcast-over-udp mcast-over-enet) Possible values: - ucast-over-udp : PTP frames are embedded in UDP packets - ucast-mcast-over-udp : PTP frames are embedded in UDP packets - mcast-over-enet : PTP frames are embedded in Ethernet packets	<i>optional parameter with default value: "mcast-over-enet"</i> protocol used to transport the PTP frames
[no] dynamic-update	Parameter type: <Sys::SysClkPtpDynamicUpdate> Format: (disable enable) Possible values: - disable : don't use dynamic extraction - enable : use dynamically extracted information	<i>optional parameter with default value: "disable"</i> specify if dynamic extraction of dataset information is activated
[no] tc-step-mode	Parameter type: <Ntr::PtpTCModeFormat> Format: (disable one-step-enable) Possible values: - disable : disable TC mode	<i>optional parameter with default value: "disable"</i> define the step mode of PTP TC

Parameter	Type	Description
	- one-step-enable : enable one-step TC	
[no] max-steps-removed	Parameter type: <Ntr::MaxStepsRemoved> Format: - the max value of stepsRemoved for BMCA - range: [0...255]	<i>optional parameter with default value: "255"</i> configure the max value of stepsRemoved for BMCA
[no] profile	Parameter type: <Ntr::PtpProfileFormat> Format: (custom-profile g8265-1-profile g8275-1-profile ccsa-profile) Possible values: - custom-profile : system with custom profile - g8265-1-profile : select the itu-t G8265.1 standard profile - g8275-1-profile : select the itu-t G8275.1 standard profile - ccsa-profile : select the CCSA standard profile	<i>optional parameter with default value: "custom-profile"</i> configure the system ptp profile and update the related ptp configurations to the standard specified default value. (Note: FANT-H does not support custom-profile)

15.19 NTR Clock Transmission Protocol Configuration Command

Command Description

This command is used to configure the transmission protocol for the IEEE1588 clock sources

User Level

The command can be accessed by operators with equipment privileges, and executed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

```
> configure system sync-if-timing ptp tx-protocol (index) [ no ip-addr | ip-addr <Ip::V4Address> ] [ no gateway-addr | gateway-addr <Ip::AddressAndIpMaskFull> ] [ no vlan | vlan <Sys::PortVlanId> ]
```

Command Parameters

Table 15.19-1 "NTR Clock Transmission Protocol Configuration Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: (ieee1588-a ieee1588-b ieee1588-a:1 ieee1588-b:1 ieee1588) Possible values: - ieee1588-a : ieee1588 port 1 on nt-a excluding FANT-G NT type - ieee1588-b : ieee1588 port 1 on nt-b excluding FANT-G NT type - ieee1588-a:1 : ieee1588 port 1 on nt-a of FANT-G - ieee1588-b:1 : ieee1588 port 1 on nt-b of FANT-G - ieee1588 : ieee1588 port on nt of FANT-H	ieee1588 clock index

Table 15.19-2 "NTR Clock Transmission Protocol Configuration Command" Command Parameters

Parameter	Type	Description
[no] ip-addr	Parameter type: <Ip::V4Address> Format: - IPv4-address	<i>optional parameter with default value: "0.0.0.0"</i> ip-address of the ToPSync PHY Port
[no] gateway-addr	Parameter type: <Ip::AddressAndIpMaskFull> Format:	<i>optional parameter with default value: "0.0.0.0/0"</i>

Parameter	Type	Description
	<Ip::V4Address> / <Ip::PrefixLengthFull> Field type <Ip::V4Address> - IPv4-address Field type <Ip::PrefixLengthFull> - IP address prefix length - range: [0...32]	default gateway towards the GrandMaster clock if outside the slave subnet
[no] vlan	Parameter type: <Sys::PortVlanId> Format: - vlan id - range: [0...4093]	<i>optional parameter with default value: 0</i> PTP port vlan

15.20 System Synchronous InterfaceTiming Clock Switching Mode configuration Command

Command Description

This command is used to configure the PTP domain Value (decimal) definition

User Level

The command can be accessed by operators with equipment privileges, and executed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

> configure system sync-if-timing ptp ptp-domain (index) [no domain | domain <Ntr::PtpDomain>]

Command Parameters

Table 15.20-1 "System Synchronous InterfaceTiming Clock Switching Mode configuration Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: (ieee1588-a ieee1588-b ieee1588-a:1 ieee1588-b:1 ieee1588) Possible values: - ieee1588-a : ieee1588 port on nt-a excluding FANT-G NT type - ieee1588-b : ieee1588 port on nt-b excluding FANT-G NT type - ieee1588-a:1 : ieee1588 port 1 on nt-a of FANT-G - ieee1588-b:1 : ieee1588 port 1 on nt-b of FANT-G - ieee1588 : ieee1588 port on nt of FNAT-H	ieee1588 clock index

Table 15.20-2 "System Synchronous InterfaceTiming Clock Switching Mode configuration Command" Command Parameters

Parameter	Type	Description
[no] domain	Parameter type: <Ntr::PtpDomain> Format: - ptp domain - range: [0...255]	<i>optional parameter with default value: 0</i> ptp domain

15.21 NTR Acceptable Clock Master Configuration Command

Command Description

This command is used to configure the list of clock masters that are deemed to be acceptable

User Level

The command can be accessed by operators with equipment privileges, and executed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

```
> configure system sync-if-timing ptp accept-master (index) [ no ip-addr | ip-addr <Ip::V4Address> ] [ no priority1 | priority1 <Ntr::Priority> ] [ no priority2 | priority2 <Ntr::Priority> ]
```

Command Parameters

Table 15.21-1 "NTR Acceptable Clock Master Configuration Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of the acceptable clock master, Index mapping to 1588 port: n1, 2, 3: FANT-G ieee1588a:1; FANT-F ieee1588a; n4, 5, 6: FANT-G ieee1588b:1; FANT-F ieee1588b; - range: [1...6]	index of the acceptable clock master

Table 15.21-2 "NTR Acceptable Clock Master Configuration Command" Command Parameters

Parameter	Type	Description
[no] ip-addr	Parameter type: <Ip::V4Address> Format: - IPv4-address	<i>optional parameter with default value: "0.0.0.0"</i> ip-address of the acceptable master
[no] priority1	Parameter type: <Ntr::Priority> Format: - priority of the acceptable master - range: [0...255]	<i>optional parameter with default value: 128</i> priority one of the acceptable master
[no] priority2	Parameter type: <Ntr::Priority> Format: - priority of the acceptable master - range: [0...255]	<i>optional parameter with default value: 128</i> configure finer grained ordering among other equivalent ieee 1588 clock sources

15.22 PTP Slave Port DataSet Configuration Command

Command Description

This command is used to configure the DataSet parameters of the PTP port for clock synchronization

User Level

The command can be accessed by operators with equipment privileges, and executed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

```
> configure system sync-if-timing ptp slave-port-dataset (index) [ no delay-mechanism | delay-mechanism
<Sys::SysClkPtpDataSetDelayMech> ] [ no delay-interval | delay-interval <Sys::SysClkPtpDataSetDelayInt> ] [ no
compensation | compensation <Sys::SysClkPtpDataSetCompensation> ] [ no sync-interval | sync-interval
<Sys::SysClkPtpDataSetSyncIntervalInt> ] [ no announce-interval | announce-interval
<Sys::SysClkPtpDataSetAnnounceInt> ] [ no multicast-mac | multicast-mac <Sys::MultiAddr> ]
```

Command Parameters

Table 15.22-1 "PTP Slave Port DataSet Configuration Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: (ieee1588-a ieee1588-b ieee1588-a:1 ieee1588-b:1 ieee1588) Possible values: - ieee1588-a : ieee1588 port on nt-a excluding FANT-G NT type - ieee1588-b : ieee1588 port on nt-b excluding FANT-G NT type - ieee1588-a:1 : ieee1588 port 1 on nt-a of FANT-G - ieee1588-b:1 : ieee1588 port 1 on nt-b of FANT-G - ieee1588 : ieee1588 port on nt of FNAT-H	determine which IEEE1588 slave PTP device will be configured

Table 15.22-2 "PTP Slave Port DataSet Configuration Command" Command Parameters

Parameter	Type	Description
[no] delay-mechanism	Parameter type: <Sys::SysClkPtpDataSetDelayMech> Format: e2e Possible values:	<i>optional parameter with default value: "e2e"</i> specify which kind of delay mechanism must be used for PTP

Parameter	Type	Description
	- e2e : delay computation mechanism used is E2E	communication
[no] delay-interval	Parameter type: <Sys::SysClkPtpDataSetDelayInt> Format: - interval between -7 to 4 - range: [-7...4]	<i>optional parameter with default value: 0</i> end-to-end delay
[no] compensation	Parameter type: <Sys::SysClkPtpDataSetCompensation> Format: - compensation centered on 0 - unit: nanosecond - range: [-100000...100000]	<i>optional parameter with default value: 0</i> define the PTP packet transport delay compensation
[no] sync-interval	Parameter type: <Sys::SysClkPtpDataSetSyncIntervalInt> Format: - interval between -8 to 4 - range: [-8...4]	<i>optional parameter with default value: -4</i> end-to-end sync interval
[no] announce-interval	Parameter type: <Sys::SysClkPtpDataSetAnnounceInt> Format: - interval centered on 0 - range: [-4...4]	<i>optional parameter with default value: -3</i> announce interval
[no] multicast-mac	Parameter type: <Sys::MultiAddr> Format: - a mac-address (example : 01:1B:19:00:00:00) - length: 6	<i>optional parameter with default value: "01 : 1B : 19 : 00 : 00 : 00"</i> a multicast mac-address for a PTP port (range: 01:1B:19:00:00:00, 01:80:C2:00:00:0E)

15.23 PTP Default Dataset Configuration Command

Command Description

This command is used to configure the default DataSet parameters of the ToD clock sources

User Level

The command can be accessed by operators with equipment privileges, and executed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

```
> configure system sync-if-timing ptp default-dataset (index) [ no priority1 | priority1 <Ntr::Priority> ] [ no
priority2 | priority2 <Ntr::Priority> ] [ no clock-class | clock-class <Sys::SysClkPtpClockQuality> ] [ no
clock-accuracy | clock-accuracy <Sys::SysClkPtpClockQuality> ] [ no domain | domain <Ntr::PtpDomain> ]
```

Command Parameters

Table 15.23-1 "PTP Default Dataset Configuration Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: (ieee1588-a ieee1588-b gnss-a gnss-b local) Possible values: - ieee1588-a : IEEE 1588-A ToD source - ieee1588-b : IEEE 1588-B ToD source - gnss-a : GNSS-A ToD source - gnss-b : GNSS-B ToD source - local : local ToD source	determine which default DataSet must be configured among the ToD sources

Table 15.23-2 "PTP Default Dataset Configuration Command" Command Parameters

Parameter	Type	Description
[no] priority1	Parameter type: <Ntr::Priority> Format: - priority of the acceptable master - range: [0...255]	<i>optional parameter with default value: 128</i> configure the priority1 for the default DataSet
[no] priority2	Parameter type: <Ntr::Priority> Format: - priority of the acceptable master - range: [0...255]	<i>optional parameter with default value: 128</i> configure the priority2 for the default DataSet
[no] clock-class	Parameter type: <Sys::SysClkPtpClockQuality> Format: - clock quality of the PTP source	<i>optional parameter with default value: 248</i> configure the clock class value

Parameter	Type	Description
	- range: [0...255]	for the default DataSet
[no] clock-accuracy	Parameter type: <Sys::SysClkPtpClockQuality> Format: - clock quality of the PTP source - range: [0...255]	<i>optional parameter with default value: 255</i> configure the clock accuracy value for the default DataSet
[no] domain	Parameter type: <Ntr::PtpDomain> Format: - ptp domain - range: [0...255]	<i>optional parameter with default value: 0</i> configure the PTP domain value for the default DataSet

15.24 PTP Master Port DataSet Profile Configuration Command

Command Description

This command is used to create and configure the profiles of the PTP Master Port DataSet for clock synchronization

User Level

The command can be accessed by operators with equipment privileges, and executed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

```
> configure system sync-if-timing ptp ( no mstr-port-ds-prof (name) ) | ( mstr-port-ds-prof (name) [ no
delay-mechanism | delay-mechanism <Sys::SysClkPtpDataSetDelayMech> ] [ no step-mode | step-mode
<Sys::SysClkPtpStepMode> ] [ no announce-interval | announce-interval <Sys::SysClkPtpDataSetAnnounceInt> ] [
no sync-interval | sync-interval <Sys::SysClkPtpDataSetSyncIntervalInt> ] [ no delay-interval | delay-interval
<Sys::SysClkPtpDataSetDelayInt> ] [ no multicast-mac | multicast-mac <Sys::MultiAddr> ] )
```

Command Parameters

Table 15.24-1 "PTP Master Port DataSet Profile Configuration Command" Resource Parameters

Resource Identifier	Type	Description
(name)	Format: - a profile name - range: [a-zA-Z0-9-_.] - length: 1<=x<=32	name for the profile of the PTP Master Port DataSet

Table 15.24-2 "PTP Master Port DataSet Profile Configuration Command" Command Parameters

Parameter	Type	Description
[no] delay-mechanism	Parameter type: <Sys::SysClkPtpDataSetDelayMech> Format: e2e Possible values: - e2e : delay computation mechanism used is E2E	<i>optional parameter with default value: "e2e"</i> specify which kind of delay mechanism must be used for PTP communication
[no] step-mode	Parameter type: <Sys::SysClkPtpStepMode> Format: (one-step two-step) Possible values: - one-step : - two-step :	<i>optional parameter with default value: "one-step"</i> specify the working mode of PTP stack by defining the mechanism to send the timestamp
[no] announce-interval	Parameter type: <Sys::SysClkPtpDataSetAnnounceInt>	<i>optional parameter with default</i>

Parameter	Type	Description
	Format: - interval centered on 0 - range: [-4...4]	<i>value: -3</i> specify the time between successive PTP announce messages in log2
[no] sync-interval	Parameter type: <Sys::SysClkPtpDataSetSyncIntervalInt> Format: - interval between -8 to 4 - range: [-8...4]	<i>optional parameter with default value: -4</i> specify the time between successive PTP sync messages in log2
[no] delay-interval	Parameter type: <Sys::SysClkPtpDataSetDelayInt> Format: - interval between -7 to 4 - range: [-7...4]	<i>optional parameter with default value: 0</i> end-to-end delay
[no] multicast-mac	Parameter type: <Sys::MultiAddr> Format: - a mac-address (example : 01:1B:19:00:00:00) - length: 6	<i>optional parameter with default value: "01 : 1B : 19 : 00 : 00 : 00"</i> a multicast mac-address for a PTP port (range: 01:1B:19:00:00:00, 01:80:C2:00:00:0E)

Command Output

Table 15.24-3 "PTP Master Port DataSet Profile Configuration Command" Display parameters

Specific Information		
name	Type	Description
ref-count	Parameter type: <AsamProfileRefCount> - number of entities using this particular profile - range: [0...65535]	show if the profile is attached to a PTP master port or not <i>This element is always shown.</i>

15.25 PTP master port Configuration Commands

Command Description

This command is used to configure the PTP master port parameters of an interface for ToD

User Level

The command can be accessed by operators with equipment privileges, and executed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

```
> configure system sync-if-timing ptp ( no master-port (port-idx) ) | ( master-port (port-idx) [ no admin-state |
admin-state <Ptp::AdminStatus> ] [ no mstr-port-ds-prof | mstr-port-ds-prof <Ptp::MasterPortProfile> ] [ no vlan-id
| vlan-id <Vlan::PtpVlan> ] [ no pbit | pbit <Ptp::MasterPortPbit> ] [ no compensation | compensation
<Sys::SysMasterClkPortCompensation> ] )
```

Command Parameters

Table 15.25-1 "PTP master port Configuration Commands" Resource Parameters

Resource Identifier	Type	Description
(port-idx)	Format: (vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::VpiId> : <Eqpt::VciId> : <Eqpt::UnstackedVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::UnstackedVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::VpiId> : <Eqpt::VciId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / voip : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / vuni : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / voip : <Eqpt::UnstackedVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / vuni : <Eqpt::UnstackedVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> /	the dataport to configure as PTP master port

Resource Identifier	Type	Description
	<code><Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> /</code> <code><Eqpt::OntSlotId> / <Eqpt::OntPortId> : stacked :</code> <code><Eqpt::SVlan> : <Eqpt::CVlan></code> <code> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> /</code> <code><Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> /</code> <code><Eqpt::OntSlotId> / <Eqpt::OntPortId> :</code> <code><Eqpt::UnstackedVlan></code> <code> uni : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> /</code> <code><Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> /</code> <code><Eqpt::OntPortId></code> <code> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> /</code> <code><Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> /</code> <code><Eqpt::LLId> : <Eqpt::UnstackedVlan></code> <code> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> /</code> <code><Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> /</code> <code><Eqpt::LLId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan></code> <code> uni.ng2 : <Eqpt::ChannelGroupId> /</code> <code><Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> /</code> <code><Eqpt::Ng2OntSlotId> / <Eqpt::Ng2OntPortId></code> <code> uni.ng2 : <Eqpt::ChannelGroupId> /</code> <code><Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / vuni)</code> Possible values: - vlan-port : vlan port - uni : uni - uni.ng2 : ngpon2 UNI style identification Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number Field type <Eqpt::VpiId> - atm VPI Field type <Eqpt::VciId> - atm VCI Field type <Eqpt::PonId> - the PON identifier Field type <Eqpt::OntId> - the ONT identifier Field type <Eqpt::ChannelGroupId> - the channel group identifier Field type <Eqpt::SubChannelGroupId> - the subchannel group identifier Field type <Eqpt::Ng2OntId> - the NG2 ONT identifier Possible values: - voip : virtual uni identifier obsolete alternative replaced by vuni - vuni : virtual uni identifier Possible values: - vuni : virtual NGPON2 uni identifier Field type <Eqpt::OntSlotId> - the ONT SLOT identifier Field type <Eqpt::OntPortId> - the ONT PORT identifier	

Resource Identifier	Type	Description
	Field type <Eqpt::Ng2OntSlotId> - the NGPON2 ONT SLOT identifier Field type <Eqpt::Ng2OntPortId> - the NGPON2 ONT PORT identifier Field type <Eqpt::LLId> - the LLID identifier, range 1 for EPON, range 1-8 for DPOE Possible values: - stacked : stacked vlan identity Field type <Eqpt::UnstackedVlan> - unstacked vlan id Field type <Eqpt::SVlan> - service vlan id Field type <Eqpt::CVlan> - customer vlan id	

Table 15.25-2 "PTP master port Configuration Commands" Command Parameters

Parameter	Type	Description
[no] admin-state	Parameter type: <Ptp::AdminStatus> Format: (down up) Possible values: - down : disable the PTP traffic on the ONT dataport - up : enable the PTP traffic on the ONT dataport	<i>optional parameter with default value: "down"</i> determine if the PTP traffic towards the end-user should be enabled or not
[no] mstr-port-ds-prof	Parameter type: <Ptp::MasterPortProfile> Format: name : <PrintableString-0-32> Possible values: - name : profile name Field type <PrintableString-0-32> - a printable string - length: x<=32	<i>optional parameter with default value: "name : default"</i> master port PTP dataset profile to be attached to PTP master port
[no] vlan-id	Parameter type: <Vlan::PtpVlan> Format: (untagged <Vlan::PtpVlan>) Possible values: - untagged : PTP packets are untagged Field type <Vlan::PtpVlan> - vlan id - range: [0...4095]	<i>optional parameter with default value: "4097"</i> specify the vlan for tagging the PTP packets at the end-user side. Only for ONT(uni) and not applicable for LT(vlan-port)
[no] pbit	Parameter type: <Ptp::MasterPortPbit> Format: - pbit - range: [0...7]	<i>optional parameter with default value: "0"</i> specify the priority of the PTP packets at the end-user side
[no] compensation	Parameter type: <Sys::SysMasterClkPortCompensation> Format: - compensation centered on 0 - unit: nanosecond - range: [-50000...50000]	<i>optional parameter with default value: 0</i> define the PTP packet transport delay compensation for PTP master port

15.26 System Clock Synchronous Source port Configuration Command

Command Description

This command allows the operator to configure the compensation of the specified PTP link port.

User Level

The command can be accessed by operators with equipment privileges, and executed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

```
> configure system sync-if-timing ptp link-port-compensation (port) [ no compensation | compensation
<Sys::SysClkPtpLinkPortCompensation> ]
```

Command Parameters

Table 15.26-1 "System Clock Synchronous Source port Configuration Command" Resource Parameters

Resource Identifier	Type	Description
(port)	Format: (ntio-1 : sfp : <ClkSys::FaceplateNumber> ntio-1 : xfp : <ClkSys::FaceplateNumber> ntio-2 : sfp : <ClkSys::FaceplateNumber> ntio-2 : xfp : <ClkSys::FaceplateNumber> nt-a : xfp : <ClkSys::FaceplateNumber> nt-a : qsfp : <ClkSys::FaceplateNumber> nt-b : xfp : <ClkSys::FaceplateNumber> nt-b : qsfp : <ClkSys::FaceplateNumber> nt : sfp : <ClkSys::FaceplateNumber> nt : xfp : <ClkSys::FaceplateNumber> lt : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <ClkSys::FaceplateNumber>) Possible values: - ntio-1 : an nt applique slot in a single or multiple-ntio-shelf - ntio-2 : an nt applique slot in a multiple-ntio-shelf - nt-a : nt-a slot - nt-b : nt-b slot - nt : active nt slot - lt : lt slot Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId>	port number supporting PTP source

15 System Configuration Commands

Resource Identifier	Type	Description
	- the shelf number Field type <Eqpt::SlotId> - the LT slot number Possible values: - nosfp : no SFP/XFP port - sfp : SFP port - xfp : XFP port - qsfp : QSFP port Field type <ClkSys::FaceplateNumber> - host SFP faceplate number	

Table 15.26-2 "System Clock Synchronous Source port Configuration Command" Command Parameters

Parameter	Type	Description
[no] compensation	Parameter type: <Sys::SysClkPtpLinkPortCompensation> Format: - compensation centered on 0 - unit: nanosecond - range: [-100000...100000]	<i>optional parameter with default value: 0</i> ptp link port compensation

15.27 PTP L2 port Configuration Commands

Command Description

This command is used to configure the PTP L2 port parameters of an interface for clock

User Level

The command can be accessed by operators with equipment privileges, and executed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

```
> configure system sync-if-timing ptp ( no l2-ptp-port (port-idx) ) | ( l2-ptp-port (port-idx) [ no admin-state |
admin-state <Sys::PtpAdminState> ] [ no priority | priority <Ntr::Priority> ] [ no vlan-id | vlan-id
<Vlan::PtpVlanId> ] [ no multi-address | multi-address <Sys::MultiAddr> ] )
```

Command Parameters

Table 15.27-1 "PTP L2 port Configuration Commands" Resource Parameters

Resource Identifier	Type	Description
(port-idx)	Format: (lt : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> nt-a : xfp : <Itf::FacePlateIndex> nt-a : qsfp : <Itf::FacePlateIndex> nt-b : xfp : <Itf::FacePlateIndex> nt-b : qsfp : <Itf::FacePlateIndex> ntio-1 : xfp : <Itf::FacePlateIndex>) Possible values: - lt : lt slot - nt-a : nt-a slot - nt-b : nt-b slot - ntio-1 : an nt applique slot in a single or multiple-ntio-shelf Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number Possible values: - xfp : xfp port - qsfp : qsfp port Field type <Itf::FacePlateIndex> - the faceplate port number	the dataport to configure as PTP master port

Table 15.27-2 "PTP L2 port Configuration Commands" Command Parameters

Parameter	Type	Description
[no] admin-state	Parameter type: <Sys::PtpAdminState> Format: (enable disable) Possible values: - enable : enable the path connectivity check protection at group level - disable : disable the path connectivity check protection at group level	<i>optional parameter with default value: "disable"</i> determine if the ptp port should be enabled or not
[no] priority	Parameter type: <Ntr::Priority> Format: - priority of the acceptable master - range: [0...255]	<i>optional parameter with default value: "128"</i> specifies local priority of the PTP port
[no] vlan-id	Parameter type: <Vlan::PtpVlanId> Format: (untagged <Vlan::PtpVlanId>) Possible values: - untagged : PTP packets are untagged Field type <Vlan::PtpVlanId> - vlan id - range: [1...4095]	<i>optional parameter with default value: "untagged"</i> specify the vlan for tagging the PTP packets at ptp port
[no] multi-address	Parameter type: <Sys::MultiAddr> Format: - a mac-address (example : 01:1B:19:00:00:00) - length: 6	<i>optional parameter with default value: "01 : 1B : 19 : 00 : 00 : 00"</i> a multicast mac-address for a PTP port (range: 01:1B:19:00:00:00,01:80:C2:00:00:0E)

15.28 Clock ToD Parameters Configuration Command

Command Description

This command is used to configure the ToD parameters for Clock synchronization

User Level

The command can be accessed by operators with equipment privileges, and executed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

```
> configure system sync-if-timing tod [ format <Sys::SysClkToDFormat> ] [ leapsecond
<Sys::SysClkToDLeapSecond> ] [ leapsecond-adjust-val <Sys::SysClkToDLeapSecondAdjustValue> ] [
leapsecond-adjust-date <Sys::SysClkToDLeapSecondAdjustDate> ]
```

Command Parameters

Table 15.28-2 "Clock ToD Parameters Configuration Command" Command Parameters

Parameter	Type	Description
format	Parameter type: <Sys::SysClkToDFormat> Format: (gps-cmcc nmea0183-gpzda nmea0183-gprmc test) Possible values: - gps-cmcc : 1PPS format is gps-cmcc - nmea0183-gpzda : 1PPS format is nmea0183-gpzda - nmea0183-gprmc : 1PPS format is nmea0183-gprmc - test : 1PPS format is the test format	<i>optional parameter</i> define the format of the ToD information
leapsecond	Parameter type: <Sys::SysClkToDLeapSecond> Format: - leap second 0 to 255 - range: [0...255]	<i>optional parameter</i> offset of the UTC time and TAI time
leapsecond-adjust-val	Parameter type: <Sys::SysClkToDLeapSecondAdjustValue> Format: - leap second adjustment value:-1,0,1 - range: [-1...1]	<i>optional parameter</i> define the leap second adjustment value which is released by BIPM
leapsecond-adjust-date	Parameter type: <Sys::SysClkToDLeapSecondAdjustDate> Format: - leap second adjustment date, format:yyyy-mm-dd	<i>optional parameter</i> define the leap second adjustment date and the format of the date is yyyy-mm-dd

15.29 1PPS ToD Interface Parameters Configuration Command

Command Description

This command is used to configure the 1PPS ToD interface parameters

User Level

The command can be accessed by operators with equipment privileges, and executed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

```
> configure system sync-if-timing tod interface (index) [ no direction | direction <Sys::SysClk1ppsDirection> ] [ no
admin-state | admin-state <Sys::ItfAdminState> ] [ no cable-comp | cable-comp
<Sys::SycClk1ppsCableCompensation> ]
```

Command Parameters

Table 15.29-1 "1PPS ToD Interface Parameters Configuration Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: (rj45-a rj45-b sma-a sma-b) Possible values: - rj45-a : the external 1PPS ToD interface is the rj45-a port - rj45-b : the external 1PPS ToD interface is the rj45-b port - sma-a : the external 1PPS interface is the sma-a port - sma-b : the external 1PPS interface is the sma-b port	define the 1PPS interface to configure

Table 15.29-2 "1PPS ToD Interface Parameters Configuration Command" Command Parameters

Parameter	Type	Description
[no] direction	Parameter type: <Sys::SysClk1ppsDirection> Format: (input output) Possible values: - input : the 1PPS ToD signal is an input signal to the system - output : the 1PPS ToD signal is an output signal from the system	optional parameter with default value: "output" direction of the 1pps ToD signal
[no] admin-state	Parameter type: <Sys::ItfAdminState> Format:	optional parameter with default value: "down"

15 System Configuration Commands

Parameter	Type	Description
	(down up) Possible values: - down : the interface is not used to transmit the 1pps ToD signal - up : the interface may be used to transmit the 1pps ToD signal	administrative state of the 1PPS interface
[no] cable-comp	Parameter type: <Sys::SycClk1ppsCableCompensation> Format: - cable-compensate value of a 1PPS ToD signal - unit: nanosecond - range: [0...10000]	<i>optional parameter with default value: "0"</i> cable compensation value of the 1pps interface

Command Output

Table 15.29-3 "1PPS ToD Interface Parameters Configuration Command" Display parameters

Specific Information		
name	Type	Description
signal-status	Parameter type: <Sys::SycClk1ppsSignalStatus> (valid invalid) Possible values: - valid : the 1pps signal is valid - invalid : the 1pps signal is not valid	status of the 1pps signal on the interface <i>This element is only shown in detail mode.</i>

15.30 1PPS ToD Serial Parameters Configuration Command

Command Description

This command is used to configure the 1PPS ToD serial parameters

User Level

The command can be accessed by operators with equipment privileges, and executed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

```
> configure system sync-if-timing tod serial-param (index) [ no baud-rate | baud-rate
<Sys::SysClk1ppsSerialBaudRate> ] [ no data-bit | data-bit <Sys::SysClk1ppsSerialDataBit> ] [ no stop-bit |
stop-bit <Sys::SysClk1ppsSerialStopBit> ] [ no parity | parity <Sys::SysClk1ppsSerialParity> ]
```

Command Parameters

Table 15.30-1 "1PPS ToD Serial Parameters Configuration Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: (rj45-a rj45-b) Possible values: - rj45-a : the 1PPS serial port is the rj45-a port - rj45-b : the 1PPS serial port is the rj45-b port	define the 1PPS serial interface to configure

Table 15.30-2 "1PPS ToD Serial Parameters Configuration Command" Command Parameters

Parameter	Type	Description
[no] baud-rate	Parameter type: <Sys::SysClk1ppsSerialBaudRate> Format: (4800 9600 19200 38400) Possible values: - 4800 : the baud rate of the 1PPS serial port is set to 4800 bits/sec - 9600 : the baud rate of the 1PPS serial port is set to 9600 bits/sec - 19200 : the baud rate of the 1PPS serial port is set to 19200 bits/sec - 38400 : the baud rate of the 1PPS serial port is set to 38400	<i>optional parameter with default value: 4800</i> specify the baudrate of the serial 1PPS port

15 System Configuration Commands

Parameter	Type	Description
[no] data-bit	bits/sec Parameter type: <Sys::SysClk1ppsSerialDatabit> Format: (7 8) Possible values: - 7 : the data bit of the 1PPS serial port is 7 - 8 : the data bit of the 1PPS serial port is 8	<i>optional parameter with default value: 8</i> specify the data bit of the 1PPS serial port
[no] stop-bit	Parameter type: <Sys::SysClk1ppsSerialStopBit> Format: (1 2) Possible values: - 1 : the data bit of the 1PPS serial port is 1 - 2 : the data bit of the 1PPS serial port is 2	<i>optional parameter with default value: 1</i> specify the stop bit of the 1PPS serial port
[no] parity	Parameter type: <Sys::SysClk1ppsSerialParity> Format: (odd even none) Possible values: - odd : the parity of the 1PPS serial port is odd - even : the parity of the 1PPS serial port is even - none : the parity of the 1PPS serial port is none	<i>optional parameter with default value: "none"</i> specify the parity of the 1PPS serial port

15.31 ToD Holdover Specification Configuration Command

Command Description

This command is used to configure the ToD Holdover Specification parameters

User Level

The command can be accessed by operators with equipment privileges, and executed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

```
> configure system sync-if-timing tod holdover-spec [ no duration | duration
<Sys::SysClkTodHoldoverSpecDuration> ] [ no clockclass | clockclass
<Sys::SysClkTodHoldoverSpecClockClass> ]
```

Command Parameters

Table 15.31-2 "ToD Holdover Specification Configuration Command" Command Parameters

Parameter	Type	Description
[no] duration	Parameter type: <Sys::SysClkTodHoldoverSpecDuration> Format: - duration 0 to 2880,unit:minute - range: [0...2880]	<i>optional parameter with default value: 0</i> specify the duration of Tod Holdover Specification
[no] clockclass	Parameter type: <Sys::SysClkTodHoldoverSpecClockClass> Format: - clock class 0 to 255 - range: [0...255]	<i>optional parameter with default value: 135</i> specify the clock class of Tod Holdover Specification

15.32 System Clock Synchronous Status Message Configuration Command

Command Description

This command allows the operator to configure the support of synchronous status message (SSM) for the configured clock source.

Note: When the default-ql is unconfigured, the system resets the default QL value as clk-ql-stu or clk-ql-prc based on the bits mode.All QL Values are applicable to both ETSI/ANSI unless the difference specified in CLI help.

User Level

The command can be accessed by operators with equipment privileges, and executed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

```
> configure system sync-if-timing ssm (index) [ [ no ] ssmenable ] [ no default-ql | default-ql <Ntr::SysClkSrcQLDef> ] [ no target-ql | target-ql <Ntr::SysClkSrcQL> ]
```

Command Parameters

Table 15.32-1 "System Clock Synchronous Status Message Configuration Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: (bits-a bits-b synce-1 synce-2 ieee1588-a ieee1588-b ieee1588) Possible values: - bits-a : configure SSM for bits-a - bits-b : configure SSM for bits-b - synce-1 : configure SSM for SyncE reference 1 - synce-2 : configure SSM for SyncE reference 2 - ieee1588-a : configure SSM for ieee1588-a - ieee1588-b : configure SSM for ieee1588-b - ieee1588 : configure SSM for ieee1588	clock synchronous status message index

Table 15.32-2 "System Clock Synchronous Status Message Configuration Command" Command Parameters

Parameter	Type	Description
[no] ssmenable	Parameter type: boolean	<i>optional parameter</i> enable ssm
[no] default-ql	Parameter type: <Ntr::SysClkSrcQLDef> Format: (clk-ql-stu clk-ql-prs clk-ql-prc clk-ql-inv3 clk-ql-ssu-a-tnc clk-ql-ssu-a clk-ql-tnc clk-ql-inv5 clk-ql-inv6 clk-ql-st2 clk-ql-ssu-b clk-ql-inv9 clk-ql-st3 clk-ql-sec clk-ql-smc clk-ql-st3e clk-ql-prov clk-ql-dnu-dus clk-ql-dnu clk-ql-dus clk-ql-default) Possible values: - clk-ql-stu : Synchronized-Traceability Unknown - clk-ql-prs : Primary Reference Source - clk-ql-prc : Primary Reference Clock - clk-ql-inv3 : Quality Level unallocated - clk-ql-ssu-a-tnc : Traced to Sync Supply Unit-A/Transmit Node Clock - clk-ql-ssu-a : Traced to Sync Supply Unit-A(ETSI) - clk-ql-tnc : Traced to Transmit Node Clock(ANSI) - clk-ql-inv5 : Quality Level unallocated - clk-ql-inv6 : Quality Level unallocated - clk-ql-st2 : Traceable to Stratum 2 - clk-ql-ssu-b : Traced to Sync Supply Unit-B - clk-ql-inv9 : Quality Level unallocated - clk-ql-st3 : Traceable to Stratum 3 - clk-ql-sec : Traceable to SDH Equipment Clock - clk-ql-smc : Traceable to SONET Clock SelfTimed - clk-ql-st3e : Traceable to Stratum 3E - clk-ql-prov : Operator Provisioned - clk-ql-dnu-dus : Signal should not be used for sync - clk-ql-dnu : Signal should not be used for sync(ETSI) - clk-ql-dus : Signal should not be used for sync(ANSI) - clk-ql-default : Special identifier for SSM QL default	<i>optional parameter with default value: "clk-ql-default"</i> default QL of clock source,for ETSI is clk-ql-prc and for ANSI is clk-ql-stu
[no] target-ql	Parameter type: <Ntr::SysClkSrcQL> Format: (clk-ql-stu clk-ql-prs clk-ql-prc clk-ql-inv3 clk-ql-ssu-a-tnc clk-ql-ssu-a clk-ql-tnc	<i>optional parameter with default value: "clk-ql-dnu-dus"</i> target QL of the clock source

15 System Configuration Commands

Parameter	Type	Description
	clk-ql-inv5 clk-ql-inv6 clk-ql-st2 clk-ql-ssu-b clk-ql-inv9 clk-ql-st3 clk-ql-sec clk-ql-smc clk-ql-st3e clk-ql-prov clk-ql-dnu-dus clk-ql-dnu clk-ql-dus) Possible values: - clk-ql-stu : Synchronized-Traceability Unknown - clk-ql-prs : Primary Reference Source - clk-ql-prc : Primary Reference Clock - clk-ql-inv3 : Quality Level unallocated - clk-ql-ssu-a-tnc : Traced to Sync Supply Unit-A/Transmit Node Clock - clk-ql-ssu-a : Traced to Sync Supply Unit-A(ETSI) - clk-ql-tnc : Traced to Transmit Node Clock(ANSI) - clk-ql-inv5 : Quality Level unallocated - clk-ql-inv6 : Quality Level unallocated - clk-ql-st2 : Traceable to Stratum 2 - clk-ql-ssu-b : Traced to Sync Supply Unit-B - clk-ql-inv9 : Quality Level unallocated - clk-ql-st3 : Traceable to Stratum 3 - clk-ql-sec : Traceable to SDH Equipment Clock - clk-ql-smc : Traceable to SONET Clock SelfTimed - clk-ql-st3e : Traceable to Stratum 3E - clk-ql-prov : Operator Provisioned - clk-ql-dnu-dus : Signal should not be used for sync - clk-ql-dnu : Signal should not be used for sync(ETSI) - clk-ql-dus : Signal should not be used for sync(ANSI)	

15.33 System Clock Synchronous Source port Configuration Command

Command Description

This command allows the operator to configure the binding of the syncE reference to the physical port which provides the clock source for synchronous Ethernet.

User Level

The command can be accessed by operators with equipment privileges, and executed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

```
> configure system sync-if-timing syncE (index) [ (port) ]
```

Command Parameters

Table 15.33-1 "System Clock Synchronous Source port Configuration Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: (syncE-1 syncE-2) Possible values: - syncE-1 : configure port for SyncE reference 1 - syncE-2 : configure port for SyncE reference 2	reference number of the port

Table 15.33-2 "System Clock Synchronous Source port Configuration Command" Command Parameters

Parameter	Type	Description
(port)	Format: (ntio-1 : sfp : <ClkSys::FaceplateNumber> ntio-1 : xfp : <ClkSys::FaceplateNumber> ntio-2 : sfp : <ClkSys::FaceplateNumber> ntio-2 : xfp : <ClkSys::FaceplateNumber> nt-a : xfp : <ClkSys::FaceplateNumber> nt-a : cfp : <ClkSys::FaceplateNumber> nt-a : qsfp : <ClkSys::FaceplateNumber> nt-b : xfp : <ClkSys::FaceplateNumber> nt-b : cfp : <ClkSys::FaceplateNumber> nt-b : qsfp : <ClkSys::FaceplateNumber> nt : sfp : <ClkSys::FaceplateNumber> nt : xfp : <ClkSys::FaceplateNumber>	<i>optional parameter</i> port number supporting syncE clock source

15 System Configuration Commands

Parameter	Type	Description
	nt : cfp : <ClkSys::FaceplateNumber> nt : qsfp : <ClkSys::FaceplateNumber> none lt : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <ClkSys::FaceplateNumber>) Possible values: - ntio-1 : an nt applique slot in a single or multiple-ntio-shelf - ntio-2 : an nt applique slot in a multiple-ntio-shelf - nt-a : nt-a slot - nt-b : nt-b slot - nt : active nt slot - lt : lt slot - none : no port Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Possible values: - nosfp : no SFP/XFP/CFP/QSFP port - sfp : SFP port - xfp : XFP port - cfp : CFP port - qsfp : QSFP port Field type <ClkSys::FaceplateNumber> - host SFP faceplate number	

15.34 System Clock Force Reference Configuration Command

Command Description

This command allows the operator to manually select the clock source. Note that the operator must release the manual clock selection ([none]) to restore the automatic (external) clock source selection.

User Level

The command can be accessed by operators with equipment privileges, and executed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

```
> configure system sync-if-timing force-reference [ (force-reference) ]
```

Command Parameters

Table 15.34-2 "System Clock Force Reference Configuration Command" Command Parameters

Parameter	Type	Description
(force-reference)	Format: (local none) Possible values: - local : select hold over clock - none : select autonomous clock selection	<i>optional parameter</i> manually force system clock source

15.35 SSMOut Configuration Command for synce ports

Command Description

This command allows the operator to enable or disable SSMout for synce ports. This command is applicable to NT's supporting enhanced clock management

User Level

The command can be accessed by operators with equipment privileges, and executed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

```
> configure system sync-if-timing ssmout-synce (index) [ [ no ] ssmout-enable ]
```

Command Parameters

Table 15.35-1 "SSMOut Configuration Command for synce ports" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: (ntio-1 : sfp : <ClkSys::SsmOutFaceplateNumber> ntio-1 : xfp : <ClkSys::SsmOutFaceplateNumber> ntio-2 : sfp : <ClkSys::SsmOutFaceplateNumber> ntio-2 : xfp : <ClkSys::SsmOutFaceplateNumber> nt-a : sfp : <ClkSys::SsmOutFaceplateNumber> nt-a : xfp : <ClkSys::SsmOutFaceplateNumber> nt-a : cfp : <ClkSys::SsmOutFaceplateNumber> nt-a : qsfp : <ClkSys::SsmOutFaceplateNumber> nt-b : sfp : <ClkSys::SsmOutFaceplateNumber> nt-b : xfp : <ClkSys::SsmOutFaceplateNumber> nt-b : cfp : <ClkSys::SsmOutFaceplateNumber> nt-b : qsfp : <ClkSys::SsmOutFaceplateNumber> nt : sfp : <ClkSys::SsmOutFaceplateNumber>) Possible values: - ntio-1 : an nt applique slot in a single or multiple-ntio-shelf - ntio-2 : an nt applique slot in a multiple-ntio-shelf - nt-a : nt-a slot - nt-b : nt-b slot - nt : active nt slot Possible values: - nosfp : no SFP/XFP/CFP/QSFP port - sfp : SFP port - xfp : XFP port	xdsl port supporting synce clock source

Resource Identifier	Type	Description
	- cfp : CFP4 port - qsfp : QSFP port Field type <ClkSys::SsmOutFaceplateNumber> - host SFP faceplate number	

Table 15.35-2 "SSMOut Configuration Command for synce ports" Command Parameters

Parameter	Type	Description
[no] ssmout-enable	Parameter type: boolean	<i>optional parameter</i> enable ssm-out for synce port

15.36 SSMOut Configuration Command for XDSL ports

Command Description

This command allows the operator to enable or disable SSMout for xDSL ports. This command is applicable to NT's supporting enhanced clock management

User Level

The command can be accessed by operators with equipment privileges, and executed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

```
> configure system sync-if-timing ( no ssmout-ltport (index) ) | ( ssmout-ltport (index) [ [ no ] ssmout-enable ] )
```

Command Parameters

Table 15.36-1 "SSMOut Configuration Command for XDSL ports" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::Vpild> : <Eqpt::VciId> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> / <Eqpt::OntPortId> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / voip <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / vuni <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::LLId> ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / <Eqpt::Ng2OntSlotId> / <Eqpt::Ng2OntPortId> ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / vuni) Possible values: - ng2 : ngpon2 style identification Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId>	xdsl port supporting synce clock source

Resource Identifier	Type	Description
	- the shelf number - Field type <Eqpt::SlotId> - the LT slot number - Field type <Eqpt::PortId> - the port number - Field type <Eqpt::VpiId> - atm VPI - Field type <Eqpt::VciId> - atm VCI - Field type <Eqpt::PonId> - the PON identifier - Field type <Eqpt::OntId> - the ONT identifier - Field type <Eqpt::ChannelGroupId> - the channel group identifier - Field type <Eqpt::SubChannelGroupId> - the subchannel group identifier - Field type <Eqpt::Ng2OntId> - the NG2 ONT identifier - Possible values: - voip : virtual uni identifier - obsolete alternative replaced by vuni - vuni : virtual uni identifier - Possible values: - vuni : virtual NGPON2 uni identifier - Field type <Eqpt::OntSlotId> - the ONT SLOT identifier - Field type <Eqpt::OntPortId> - the ONT PORT identifier - Field type <Eqpt::Ng2OntSlotId> - the NGPON2 ONT SLOT identifier - Field type <Eqpt::Ng2OntPortId> - the NGPON2 ONT PORT identifier - Field type <Eqpt::LLId> - the LLID identifier, range 1 for EPON, range 1-8 for DPOE	

Table 15.36-2 "SSMOut Configuration Command for XDSL ports" Command Parameters

Parameter	Type	Description
[no] ssmout-enable	Parameter type: boolean	<i>optional parameter</i> enable ssm-out for dsl port

15.37 T4 D-PLL Configuration Command

Command Description

This command allows the operator to configure the T4 D-PLL parameters. Note: In standard mode, T4 parameters are optional. The possible combinations are: 1. t4mode = standard, t4-prio-ref1 = none, t4-prio-ref2 = none 2. t4mode = synce-transfer, t4-prio-ref1 and t4-prio-ref2 can be synce-1, synce-2 or none 3. t4mode = synce-split, t4-prio-ref1 and t4-prio-ref2 can be synce-1, synce-2 or none For t4-jitter-bw, the allowed values are 18, 35, 70, 560

User Level

The command can be accessed by operators with equipment privileges, and executed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

```
> configure system sync-if-timing t4-out-config [ no t4-mode | t4-mode <Ntr::T4Mode> ] [ no t4-damping-factor |
t4-damping-factor <Ntr::T4DampingFactor> ] [ no t4-jitter-bw | t4-jitter-bw <Ntr::T4JitterBw> ] [ no t4-prio-ref1 |
t4-prio-ref1 <Ntr::T4PrioRef> ] [ no t4-prio-ref2 | t4-prio-ref2 <Ntr::T4PrioRef> ]
```

Command Parameters

Table 15.37-2 "T4 D-PLL Configuration Command" Command Parameters

Parameter	Type	Description
[no] t4-mode	Parameter type: <Ntr::T4Mode> Format: (standard synce-transfer synce-split) Possible values: - standard : standard configuration - synce-transfer : synce-transfer t4 mode - synce-split : synce-split t4 mode	optional parameter with default value: "standard" standard t4 mode
[no] t4-damping-factor	Parameter type: <Ntr::T4DampingFactor> Format: (factor-1.2-db factor-2.5-db factor-5.0-db factor-10.0-db factor-20.0-db) Possible values: - factor-1.2-db : 1.2 db damping factor - factor-2.5-db : 2.5 db damping factor - factor-5.0-db : 5.0 db damping factor - factor-10.0-db : 10.0 db damping factor - factor-20.0-db : 20.0 db damping factor	optional parameter with default value: "factor-5.0-db" t4 d-pll damping factor

Parameter	Type	Description
[no] t4-jitter-bw	Parameter type: <Ntr::T4JitterBw> Format: - jitter bandwidth - range: [0...1024]	<i>optional parameter with default value: 18</i> t4 jitter bandwidth filter
[no] t4-prio-ref1	Parameter type: <Ntr::T4PrioRef> Format: (none local synce-1 synce-2 assysclk) Possible values: - none : no clock is specified for this priority - local : This option cannot be configured - synce-1 : 1st SyncE clock is specified for this priority - synce-2 : 2nd SyncE clock is specified for this priority - assysclk : This option cannot be configured	<i>optional parameter with default value: "none"</i> synce reference 1
[no] t4-prio-ref2	Parameter type: <Ntr::T4PrioRef> Format: (none local synce-1 synce-2 assysclk) Possible values: - none : no clock is specified for this priority - local : This option cannot be configured - synce-1 : 1st SyncE clock is specified for this priority - synce-2 : 2nd SyncE clock is specified for this priority - assysclk : This option cannot be configured	<i>optional parameter with default value: "none"</i> synce reference 2

15.38 SyncE Configuration Command for FELT-B ports

Command Description

This command allows the operator to enable or disable SyncE for FELT-B ports. This command is applicable to NT's supporting enhanced clock management

User Level

The command can be accessed by operators with equipment privileges, and executed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

```
> configure system sync-if-timing bits-bind [ no bits-a-bind | bits-a-bind <Sys::LtSlotIndexOrZero> ] [ no bits-b-bind | bits-b-bind <Sys::LtSlotIndexOrZero> ]
```

Command Parameters

Table 15.38-2 "SyncE Configuration Command for FELT-B ports" Command Parameters

Parameter	Type	Description
[no] bits-a-bind	Parameter type: <Sys::LtSlotIndexOrZero> Format: (lt : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> none) Possible values: - lt : LT slot - none : No LT is specified Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number	<i>optional parameter with default value: "none"</i> config ethernet LT outputs BITS-OUT to NTA BITS-IN
[no] bits-b-bind	Parameter type: <Sys::LtSlotIndexOrZero> Format: (lt : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> none) Possible values: - lt : LT slot - none : No LT is specified Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId>	<i>optional parameter with default value: "none"</i> config ethernet LT outputs BITS-OUT to NTB BITS-IN

Parameter	Type	Description
	- the shelf number Field type <Eqpt::SlotId> - the LT slot number	

15.39 ALS State Configuration Command

Command Description

This command allows the operator to enable or disable the system wide ALS state.

User Level

The command can be accessed by operators with security privileges, and executed by operators with security privileges.

Command Syntax

The command has the following syntax:

> configure system auto-laser-shutdown [no action | action <Sys::AlsState>]

Command Parameters

Table 15.39-2 "ALS State Configuration Command" Command Parameters

Parameter	Type	Description
[no] action	Parameter type: <Sys::AlsState> Format: (enable disable) Possible values: - enable : enable ALS state - disable : disable ALS state	optional parameter with default value: "enable" system wide ALS handling state

15.40 Configure system auto-switch

Command Description

This command allows the operator to configure system-wide auto-switching parameters.

User Level

The command can be accessed by operators with security privileges, and executed by operators with security privileges.

Command Syntax

The command has the following syntax:

```
> configure system auto-switch [ [ no ] xdsl-atm-ptm ] [ no xdsl-stepup-delay | xdsl-stepup-delay
<Sys::AutoSwitchDelayTime> ]
```

Command Parameters

Table 15.40-2 "Configure system auto-switch" Command Parameters

Parameter	Type	Description
[no] xdsl-atm-ptm	Parameter type: boolean	<i>optional parameter</i> enable system-wide auto-switching between ATM and PTM on XDSL ports.
[no] xdsl-stepup-delay	Parameter type: <Sys::AutoSwitchDelayTime> Format: - delay time in seconds - unit: seconds - range: [0...65535]	<i>optional parameter with default value: 3600</i> auto-switching step up delay time (seconds) for PTM service(s).

15.41 ZTP (Zero Touch Provision) State Configuration Command

Command Description

This command allows the operator to enable or disable the system wide ZTP state. In unsupported ISAM it returns the default value "disable" when read. If ZTP state is set to enable then Zero Touch Provision will be started from next ISAM / NT reset. Not supported for HOT RESET

User Level

The command can be accessed by operators with security privileges, and executed by operators with security privileges.

Command Syntax

The command has the following syntax:

```
> configure system zero-touch-provision [ no action | action <Sys::Boolean> ]
```

Command Parameters

Table 15.41-2 "ZTP (Zero Touch Provision) State Configuration Command" Command Parameters

Parameter	Type	Description
[no] action	Parameter type: <Sys::Boolean> Format: (enable disable) Possible values: - enable : enable ZTP state - disable : disable ZTP state	<i>optional parameter with default value: "disable"</i> system wide ZTP handling state. If set to enable the Zero Touch Provision will start from next reset of ISAM / NT

15.42 System Relay ID Syntax Configuration

Command

Command Description

This command allows the operator to configure the system relay ID syntax. For atm-based-dsl, default value is "S-MAC Rack/Frame/Slot/Port:VPI.VCI". For efm-based-dsl, default value is "S-MAC Rack/Frame/Slot/Port". For nt-port, default value is "S-MAC Ntslot/PrtType/Port".

The system relay ID syntax is a concatenation of keywords, separators and free text strings.

The operator can use the following predefined keywords to construct the system relay ID :

- **S-MAC** to specify the system MAC address.
- **Rack** to specify the rack number.
- **Frame** to specify the shelf number.
- **Slot** to specify the slot number.
- **Port** to specify the port number.
- **VPI** to specify the vpi.
- **VCI** to specify the vci.
- **Ntslot** to specify the nt slot.
- **PrtType** to specify the nt port type.

User Level

The command can be accessed by operators with security privileges, and executed by operators with security privileges.

Command Syntax

The command has the following syntax:

```
> configure system relay-id-syntax [ no atm-based-dsl | atm-based-dsl <PrintableString-0-80> ] [ no efm-based-dsl | efm-based-dsl <PrintableString-0-80> ]
```

Command Parameters

Table 15.42-2 "System Relay ID Syntax Configuration Command" Command Parameters

Parameter	Type	Description
[no] atm-based-dsl	Parameter type: <PrintableString-0-80> Format: - a printable string - length: x<=80	optional parameter with default value: "S-MAC Rack/Frame/Slot/Port : VPI.VCI" define the syntax of relay Id for atm based dsl lines
[no] efm-based-dsl	Parameter type: <PrintableString-0-80> Format: - a printable string - length: x<=80	optional parameter with default value: "S-MAC Rack/Frame/Slot/Port" defines the syntax of relay Id for

15 System Configuration Commands

Parameter	Type	Description
		efm based dsl lines

15.43 FIPS Configuration Command

Command Description

Obsolete command.

User Level

The command can be accessed by operators with security privileges, and executed by operators with security privileges.

Command Syntax

The command has the following syntax:

> configure system fips [(enable)]

Obsolete command.

Command Parameters

Table 15.43-2 "FIPS Configuration Command" Command Parameters

Parameter	Type	Description
(enable)	Format: (disable enable) Possible values: - disable : Disable FIPS - enable : Enable FIPS	<i>optional parameter</i> Enable FIPS in the system

15.44 NT SFTP Server Configuration Command

Command Description

This command allows the operator to configure NT SFTP server credentials and access rights to var/cmd/nt_sftp folder.

User Level

The command can be accessed by operators with security privileges, and executed by operators with security privileges.

Command Syntax

The command has the following syntax:

> configure system nt-sftp [[no] write-enable]

Command Parameters

Table 15.44-2 "NT SFTP Server Configuration Command" Command Parameters

Parameter	Type	Description
[no] write-enable	Parameter type: boolean	<i>optional parameter</i> enable write permissions to var/cmd/nt_sftp folder

15.45 NT SFTP Server Credentials Configuration Command

Command Description

This command allows the operator to configure NT SFTP server credentials.

User Level

The command can be accessed by operators with security privileges, and executed by operators with security privileges.

Command Syntax

The command has the following syntax:

```
> configure system nt-sftp ( no user-name (name) ) | ( user-name (name) password <Sys::NtSftpServerPassword> )
```

Command Parameters

Table 15.45-1 "NT SFTP Server Credentials Configuration Command" Resource Parameters

Resource Identifier	Type	Description
(name)	Format: - the username used to access the file server - length: 1<=x<=32	username used to access NT SFTP server

Table 15.45-2 "NT SFTP Server Credentials Configuration Command" Command Parameters

Parameter	Type	Description
password	Parameter type: <Sys::NtSftpServerPassword> Format: (prompt plain : <Sys::PlainPassword> encrypted : <Sys::EncryptedPassword>) Possible values: - prompt : prompts the operator for a password - plain : the password in plain text - encrypted : the encrypted password Field type <Sys::PlainPassword> - the password used to access the file server - length: 1<=x<=32 Field type <Sys::EncryptedPassword> - password string exposed to users - length: 8<=x<=68	<i>mandatory parameter</i> password used to access NT SFTP server

16- Security Configuration Commands

16.1 Security Configuration Command Tree	16-720
16.2 Security Banner Configuration Command	16-726
16.3 Operator Configuration Command	16-728
16.4 Profile Configuration Command	16-731
16.5 Default Profile Configuration Command	16-738
16.6 SNMP View Configuration Command	16-745
16.7 Security SNMP Community Configuration Command	16-747
16.8 Security SNMPv3 Group Configuration Command	16-750
16.9 Security SNMPv3 User Configuration Command	16-753
16.10 Security SNMPv3 User-Group Configuration Command	16-756
16.11 SNMP Notify View Configuration Command	16-758
16.12 Security SNMP Notification Profile Configuration Command	16-760
16.13 Security SNMP Notification Profile Filter Configuration Command	16-762
16.14 Security SNMP Element Manager Configuration Command	16-764
16.15 Security RADIUS Client Configuration Command	16-766
16.16 Security RADIUS Authentication Server Configuration Command	16-767
16.17 Security RADIUS Accounting Server Configuration Command	16-769
16.18 Security RADIUS Dynamic Authorization Client Configuration Command	16-771
16.19 Security RADIUS Policy Configuration Command	16-773
16.20 Security RADIUS Server Configuration Command	16-775
16.21 Security TACACS+ Client Configuration Command	16-777
16.22 Security TACACS+ Authentication Server Configuration Command	16-778
16.23 Security TACACS+ Authorization Server Configuration Command	16-780
16.24 Security TACACS+ Accounting Server Configuration Command	16-782
16.25 Security TACACS+ Policy Configuration Command	16-784
16.26 Security Tacacs+ Server Configuration Command	16-785
16.27 Security Domain Configuration Command	16-787
16.28 Security Connection Profile Configuration Command	16-789
16.29 Security Connection Policy Configuration Command	16-790
16.30 Security 802.1x PAE System Configuration Command	16-791
16.31 Security 802.1x Port Authentication Configuration Command	16-792
16.32 Security 802.1x Extension, Port Authentication Configuration Command	16-795
16.33 Security 802.1x Port Configuration Command	16-798
16.34 Security Password Policy Configuration Command	16-800
16.35 File Transfer Configure Command	16-802
16.36 file Transfer server Configure Commands	16-803
16.37 file Transfer server Configure Commands	16-805

16.38 PM File Upload Configure Command	16-807
16.39 5-min CDR File Upload Configure Command	16-810
16.40 Lawful Intercept Split Management Configuration Command	16-812
16.41 MAC Filter Configuration Command	16-813
16.42 NT slot Security Configuration Command	16-815

16.1 Security Configuration Command Tree

Description

This chapter gives an overview of nodes that are handled by "Security Configuration Commands".

Command Tree

```
----configure
  ----system
    ----security
      - [no] oper-policy-prio
      - [no] login-banner
      - [no] welcome-banner
      - [no] login-setting
      - [no] cli-session
      - [no] unauth-fwd
      - [no] src-mac-check
    ----[no] operator
      - (name)
      - profile
      - password
      - [no] bgn-time
      - [no] end-time
      - [no] prompt
      - [no] description
      - [no] more
      - [no] confirm-prompt
    ----[no] profile
      - (name)
      - [no] prompt
      - [no] password-timeout
      - [no] terminal-timeout
      - [no] slot-numbering
      - [no] description
      - [no] aaa
      - [no] atm
      - [no] alarm
      - [no] dhcp
      - [no] equipment
      - [no] igmp
      - [no] ip
      - [no] pppoe
      - [no] qos
      - [no] software-mngt
      - [no] transport
      - [no] vlan
      - [no] xdsl
      - [no] sip
      - [no] megaco
      - [no] lacp
      - [no] mstp
      - [no] security
```

```

- [no] service
- [no] debug
- [no] debug-mirror
- [no] filter
- [no] link
- [no] log
- [no] oam
- [no] liadmin
- [no] liuser
- [no] drouter
- [no] ai
- [no] livoice
- [no] lldpmed
----default-profile
- [no] prompt
X password-timeout
- [no] terminal-timeout
- [no] slot-numbering
- [no] description
- [no] aaa
- [no] atm
- [no] alarm
- [no] dhcp
- [no] equipment
- [no] igmp
- [no] ip
- [no] pppoe
- [no] qos
- [no] software-mngt
- [no] transport
- [no] vlan
- [no] xdsl
- [no] sip
- [no] megaco
- [no] lacp
- [no] mstp
- [no] security
- [no] service
- [no] debug
- [no] debug-mirror
- [no] filter
- [no] link
- [no] log
- [no] oam
- [no] liadmin
- [no] liuser
- [no] drouter
- [no] ai
- [no] livoice
- [no] lldpmed
----snmp
----[no] view
- (notify-view)
- subtree
- type
----[no] community
- (name)
- host-address

```

- [no] context
- [no] privilege
- [no] read-view
- [no] write-view
- [no] notify-view
- [no] **group**
 - **(name)**
 - **security-level**
 - **context**
 - [no] read-view
 - [no] write-view
 - [no] notify-view
- [no] **user**
 - **(name)**
 - [no] authentication
 - [no] privacy
 - [no] public
- [no] **map-user-group**
 - **(name)**
 - group-name
- [no] **notify-view**
 - **(notify-view)**
 - **subtree**
 - type
- [no] **notify-profile**
 - **(name)**
 - snmp-version
- [no] **filter**
 - notify-view
- [no] **manager**
 - **(name)**
 - destination
 - notify-profile
 - [no] nt
 - [no] shub
 - [no] ihub
 - [no] epon
 - [no] xvps1
 - [no] xvps2
 - [no] xvps3
 - [no] xvps4
 - [no] xvps5
 - [no] xvps6
 - [no] xvps7
 - [no] xvps8
 - [no] vvpsa
- radius**
 - [no] auth-super-user
 - [no] operator-policy
 - [no] aut-s-unreach-act
- [no] **auth-server**
 - **(name)**
 - **router-instance**
 - ip-address
 - [no] port
 - secret
 - [no] retry-limit
 - [no] timeout-limit
 - [no] admin-down

```

- [no] dead-interval
----[no] acc-server
- (name)
- router-instance
- ip-address
- [no] port
- secret
- [no] retry-limit
- [no] timeout-limit
- [no] admin-down
- [no] dead-interval
----[no] dyn-auth-client
- (name)
- router-instance
- ip-address
- secret
- [no] admin-down
----[no] policy
- (name)
- nas-id
- nas-ip-address
- [no] keep-domain-name
- [no] disable-accnt-msg
- [no] acc-interval
- [no] disable-eap
----[no] servers
- (index)
- auth-server
- auth-router-inst
- [no] acc-server
- [no] acc-router-inst
- priority
----tacacs
- [no] auth-super-user
- [no] operator-policy
----[no] authen-server
- (name)
- router-instance
- ip-address
- [no] port
- secret
- [no] timeout-limit
- [no] admin-down
- [no] dead-interval
----[no] author-server
- (name)
- router-instance
- ip-address
- [no] port
- secret
- [no] timeout-limit
- [no] admin-down
- [no] dead-interval
----[no] acc-server
- (name)
- router-instance
- ip-address
- [no] port
- secret

```

- [no] timeout-limit
- [no] admin-down
- [no] dead-interval
- [no] policy
 - (name)
 - [no] servers
 - (index)
 - [no] authen-server
 - [no] author-server
 - [no] acc-server
 - priority
- [no] domain
 - (name)
 - [no] vlan-id
 - [no] primary-dns
 - [no] second-dns
 - [no] primary-nbns
 - [no] second-nbns
 - [no] sess-timeout
 - [no] qos-policy
 - authenticator
 - [no] admin-down
- [no] conn-profile
 - (name)
 - version
 - [no] reject-no-domain
 - [no] reject-inv-domain
 - domain-name
- [no] conn-policy
 - conn-profile-name
- pae
 - [no] port-access
 - authenticator
 - (port)
 - [no] controlled-port
 - [no] quiet-period
 - [no] tx-period
 - [no] supp-timeout
 - [no] server-timeout
 - [no] max-req
 - [no] re-auth-enabled
 - [no] re-auth-period
 - ext-authenticator
 - (port)
 - [no] authentication
 - [no] init-authreq-off
 - [no] handshake
 - [no] handshake-period
 - [no] mac-auth
 - [no] mab-auth
 - [no] dyn-vlan-assign
- port
 - (port)
 - [no] initialize
- password
 - min-length
 - min-num-numeric-char
 - min-num-special-char
 - [no] mixed-case

```

----filetransfer
- [no] protocol
- [no] tftp-rollovr
----[no] server
- (serverid)
- user-name
- [no] password
- [no] auth-type
- [no] key-type
----[no] serverv6
- (serveridv6)
- user-name
- [no] password
- [no] auth-type
- [no] key-type
----pmfile
----[no] upload
- (upload-index)
- pri-server-addr
- upload-path
- interval-type
- [no] auto-upload
- [no] retry-num
- [no] max-delay
- [no] cdr-max-delay
- [no] cdr-max-timeout
----X cdr-pm-file
----X [no] upload
- (upload-index)
- pri-server-addr
- upload-path
- retry-num
- max-delay
- timeout
----li
- [no] separate
----peripheral-mgnt
----mac-filter
- (index-num)
- [no] filter
----slot
- (index)
- [no] debug-usb

```

16.2 Security Banner Configuration Command

Command Description

This command allows the operator to configure the login banner and the welcome banner.

There is a limit to the number of characters that can be entered in a single CLI command. For lengthy banners, Nokia recommends that the operator enter separate commands to configure the login banner and the welcome banner.

User Level

The command can be accessed by operators with security privileges, and executed by operators with security privileges.

Command Syntax

The command has the following syntax:

```
> configure system security [ no oper-policy-prio | oper-policy-prio <Aaa::AaaPolicyPriority> ] [ no login-banner |
login-banner <Sec::Banner> ] [ no welcome-banner | welcome-banner <Sec::Banner> ] [ no login-setting |
login-setting <Sec::LoginSetting> ] [ no cli-session | cli-session <Sec::CliSessionLimit> ] [ [ no ] unauth-fwd ] [ [
no ] src-mac-check ]
```

Command Parameters

Table 16.2-2 "Security Banner Configuration Command" Command Parameters

Parameter	Type	Description
[no] oper-policy-prio	Parameter type: <Aaa::AaaPolicyPriority> Format: (rrn rrt ttt rrr ttr) Possible values: - rrn : authentication and authorization using Radius without remote accounting - rrt : authentication and authorization using Radius while accounting using TACACS+ - ttt : authentication, authorization and accounting using TACACS+ - rrr : authentication, authorization and accounting using RADIUS - ttr : authentication and authorization using TACACS+ and accounting using RADIUS	<i>optional parameter with default value: "rrn"</i> aaa policy priority for operator
[no] login-banner	Parameter type: <Sec::Banner> Format: - a banner to be shown to the operator Note: up to 2048 length of banner is only supported on FANT-(F,G,H),	<i>optional parameter with default value: ""</i> banner to be shown before the operator enters its name

Parameter	Type	Description
	CFNT-(A,B,C), 480 for other NT. If using special and functional characters like pound, reversed slash,space, the whole banner must be in the quotation marks. Quotation marks and reversed slash is not counted in length. A reversed slash followed by 'r' combined with reversed slash followed by 'n' is used to change line. - length: x<=2048	
[no] welcome-banner	Parameter type: <Sec::Banner> Format: - a banner to be shown to the operator Note: up to 2048 length of banner is only supported on FANT-(F,G,H), CFNT-(A,B,C), 480 for other NT. If using special and functional characters like pound, reversed slash,space, the whole banner must be in the quotation marks. Quotation marks and reversed slash is not counted in length. A reversed slash followed by 'r' combined with reversed slash followed by 'n' is used to change line. - length: x<=2048	<i>optional parameter with default value: ""</i> the banner to be shown when the operator logged in
[no] login-setting	Parameter type: <Sec::LoginSetting> Format: <Sec::LoginAttempt> : <Sec::LockoutDuration> Field type <Sec::LoginAttempt> - the number of failed login attempts - range: [0...10] Field type <Sec::LockoutDuration> - configure duration for lockout, the unit is minute - range: [0...1440]	<i>optional parameter with default value: "0 : 0"</i> Configure both login attempt and lockout duration.
[no] cli-session	Parameter type: <Sec::CliSessionLimit> Format: - the max number that user can login by telnet or ssh - range: [1...10]	<i>optional parameter with default value: "10"</i> the limited session that the operator logged in by telnet or ssh
[no] unauth-fwd	Parameter type: boolean	<i>optional parameter</i> enable 802.1x un-authentication forward
[no] src-mac-check	Parameter type: boolean	<i>optional parameter</i> enable source mac check

16.3 Operator Configuration Command

Command Description

This command allows the operator to specify an operator instance.

After this instance is created, an operator can log in to the system with the specified name and password.

Operators have a profile that determines most of the operator properties. The operator profile must be created before the operator can be created.

The operator profile is assigned when the operator is created. The profile cannot be changed afterward. If the operator wants to change the profile, the operator must first delete the operator and then recreate it.

*The default values for **prompt** can be found in **configure system security profile** profile-name.*

The following rules apply to a plain text password.

- *The password must consist of a minimum of six and a maximum of 20 printable characters.*
- *The password must contain at least one non-alphanumeric character.*
- *A new password must be different from the last three passwords.*

*Never specify a new password using the **encrypted** option. You could mistakenly enter any hexadecimal string that is not necessarily linked to a password, and it is almost impossible to calculate a password from an encrypted string. The encrypted method of specifying passwords is only intended to restore an existing configuration.*

An operator must enter a new password when logging in for the first time after another operator has changed his or her password.

There is no separate command to change a password. An operator must change the password in the operator's operator node.

The prompt can be composed with following components :

- **%n** : the name of the current operator.
- **%s** : the current numbering scheme (**typ|leg|pos**).
- **%i** : the current system id.
- **%t** : the current system time.
- **%!** : the current history number.
- **% num d** : the current context.
 - *num is the maximum number of components (starting from the last) that are shown (default is all).*
 - *each component will be separated from the next one with a >.*
 - *a > is also added in front of the first component.*
- **%%** : a %
- **%c** : # if the current node was an existing node or \$ if it is newly created.
- **%h** : the current system id.
- *any other character is just added to the prompt as is.*

***confirm-prompt** feature for the operator will be disabled by default. If the feature is disabled, warning prompt wont be displayed to the operator. Operator can enable/disable this feature using this parameter.*

Next to %, ISAM supports the use of the \$ as an escape character. The system behavior is the same as when using the % escape character, e.g. an occurrence of \$n is replaced with the name of the current operator. For backward compatibility, the \$ character must be used exclusively without the % character. As soon as the % character is used in the string, all occurrences of the \$ character will be considered as a literal and will not be replaced with the component it refers to.

User Level

The command can be accessed by operators with *all,admin* privileges.

The last operator with security write permissions cannot be deleted.

An operator can be deleted when still logged in. The operator instance is only removed after the operator has logged out or is logged out by the system.

Operators without security read or write permissions cannot see other operators.

Operators without security write permissions cannot create, delete, or modify another operator, but they can enter the commands to perform these actions. However, these commands always fail when executed.

Command Syntax

The command has the following syntax:

```
> configure system security ( no operator (name) ) | ( operator (name) profile <Sec::ProfileName> password
<Sec::OperatorPassword> [ no bgn-time | bgn-time <Sys::GaugeTimeInSecs> ] [ no end-time | end-time
<Sys::GaugeTimeInSecs> ] [ no prompt | prompt <Sec::Prompt> ] [ no description | description
<Sec::OperatorDesc> ] [ [ no ] more ] [ [ no ] confirm-prompt ] )
```

Command Parameters

Table 16.3-1 "Operator Configuration Command" Resource Parameters

Resource Identifier	Type	Description
(name)	Format: - the name of an operator - range: [a-z0-9+] - length: 1<=x<=11	the name of the operator

Table 16.3-2 "Operator Configuration Command" Command Parameters

Parameter	Type	Description
profile	Parameter type: <Sec::ProfileName> Format: - the name of an operator profile - range: [a-z0-9] - length: 1<=x<=11	<i>mandatory parameter</i> The parameter is not visible during modification. the name of an operator profile
password	Parameter type: <Sec::OperatorPassword> Format: (prompt plain : <Sec::OperatorPlainPassword> encrypted : <Sec::EncryptedPassword>) Possible values: - prompt : prompts the operator for a password - plain : the password in plain text - encrypted : the hashed password Field type <Sec::OperatorPlainPassword> - the password in plain text is placed in double quotes when # ? [or] is used.\n In double quotes, backslash is regared as escape, and it is used to escape control character, quotation mark, and itself. - length: 6<=x<=20 Field type <Sec::EncryptedPassword> - the encrypted password of length either 20 or 68 only	<i>mandatory parameter</i> the password needed to log in
[no] bgn-time	Parameter type: <Sys::GaugeTimeInSecs> Format: - the time (yyyy-mm-dd:hour:minutes:secs)	<i>optional parameter with default value:</i> "1970-01-01 : 00 : 00 : 00"

16 Security Configuration Commands

Parameter	Type	Description
		the start of the valid time of operator, range:[1970-01-01:00:00:00,2035-12-31
[no] end-time	Parameter type: <Sys::GaugeTimeInSecs> Format: - the time (yyyy-mm-dd:hour:minutes:secs)	<i>optional parameter with default value: "2035-12-31 : 23 : 59 : 59"</i> the end of the valid time of operator, range:[1970-01-01:00:00:00,2035-12-31
[no] prompt	Parameter type: <Sec::Prompt> Format: - a specification of the prompt - length: x<=31	<i>optional parameter with default value: ""</i> the specification of the prompt
[no] description	Parameter type: <Sec::OperatorDesc> Format: - any description to be used by the operator - length: x<=31	<i>optional parameter with default value: ""</i> any description to be used by the operator
[no] more	Parameter type: boolean	<i>optional parameter</i> the output is passed via the more filter
[no] confirm-prompt	Parameter type: boolean	<i>optional parameter</i> confirmation prompt will be enabled

16.4 Profile Configuration Command

Command Description

This command allows the operator to specify an operator profile.

The operator profile determines most of the operator properties.

An operator profile is typically used to limit the commands that a group of operators can execute to those for which they have the necessary skills and for which they are responsible.

*Any change of the attribute slot-numbering will only take effect for new CLI sessions. The slot-numbering of an active CLI session will never be changed. The actual slot-numbering used for a session can be made visible with the command **show sessions***

terminal-timeout: A value of 0 equals an infinite timeout value (i.e. the terminal will never time out).

The prompt can be composed with following components :

- **%n** : the name of the current operator.
- **%s** : the current numbering scheme (**typ|leg|pos**).
- **%i** : the current system id.
- **%t** : the current system time.
- **%!** : the current history number.
- **% num d** : the current context.
 - num is the maximum number of components (starting from the last) that are shown (default is all).
 - each component will be separated from the next one with a >.
 - a > is also added in front of the first component.
- **%%** : a %
- **%c** : # if the current node was an existing node or \$ if it is newly created.
- **%h** : the current system id.
- any other character is just added to the prompt as is.

Next to %, ISAM supports the use of the \$ as an escape character. The system behavior is the same as when using the % escape character, e.g. an occurrence of \$n is replaced with the name of the current operator. For backward compatibility, the \$ character must be used exclusively without the % character. As soon as the % character is used in the string, all occurrences of the \$ character will be considered as a literal and will not be replaced with the component it refers to.

User Level

The command can be accessed by operators with all,admin privileges.

The last operator with security write permissions cannot be deleted.

The permissions of a profile cannot be changed as long as one operator belongs to the profile.

Operators without security read or write permissions cannot see other operator profiles.

Command Syntax

The command has the following syntax:

```
> configure system security ( no profile (name) ) | ( profile (name) [ no prompt | prompt <Sec::Prompt> ] [ no
password-timeout | password-timeout <Sec::PasswordTimeout> ] [ no terminal-timeout | terminal-timeout
<Sec::InactivityTimeout> ] [ no slot-numbering | slot-numbering <Sec::SlotDesc> ] [ no description | description
```

```

<Sec::ProfileDesc> ] [ no aaa | aaa <Sec::Aaa> ] [ no atm | atm <Sec::Atm> ] [ no alarm | alarm <Sec::Alarm> ] [
no dhcp | dhcp <Sec::Dhcp> ] [ no equipment | equipment <Sec::Equipment> ] [ no igmp | igmp <Sec::Igmp> ] [ no
ip | ip <Sec::Ip> ] [ no pppoe | pppoe <Sec::Pppoe> ] [ no qos | qos <Sec::Qos> ] [ no software-mngt |
software-mngt <Sec::Sw> ] [ no transport | transport <Sec::Transport> ] [ no vlan | vlan <Sec::Vlan> ] [ no xdsl |
xdsl <Sec::Xdsl> ] [ no sip | sip <Sec::Sip> ] [ no megaco | megaco <Sec::Megaco> ] [ no lacp | lacp <Sec::Lacp> ]
[ no mstp | mstp <Sec::Mstp> ] [ no security | security <Sec::Security> ] [ no service | service <Sec::Service> ] [ no
debug | debug <Sec::Debug> ] [ no debug-mirror | debug-mirror <Sec::DebugMirror> ] [ no filter | filter
<Sec::Filter> ] [ no link | link <Sec::Link> ] [ no log | log <Sec::Log> ] [ no oam | oam <Sec::Oam> ] [ no liadmin |
liadmin <Sec::Liadmin> ] [ no liuser | liuser <Sec::Liuser> ] [ no drouter | drouter <Sec::Drouter> ] [ no ai | ai
<Sec::Ai> ] [ no lvoice | lvoice <Sec::Lvoice> ] [ no lldpmed | lldpmed <Sec::LldpMed> ] )

```

Command Parameters

Table 16.4-1 "Profile Configuration Command" Resource Parameters

Resource Identifier	Type	Description
(name)	Format: - the name of an operator profile - range: [a-z0-9] - length: 1<=x<=11	the name of the profile

Table 16.4-2 "Profile Configuration Command" Command Parameters

Parameter	Type	Description
[no] prompt	Parameter type: <Sec::Prompt> Format: - a specification of the prompt - length: x<=31	<i>optional parameter with default value: "\"%s : %n%d%c \""</i> the specification of the prompt
[no] password-timeout	Parameter type: <Sec::PasswordTimeout> Format: - the maximum time a password may be unchanged - unit: days - range: [0...365]	<i>optional parameter with default value: 0</i> the maximum time a password may be unchanged
[no] terminal-timeout	Parameter type: <Sec::InactivityTimeout> Format: - specify the inactivity timeout of the terminal - unit: minutes - range: [0...120]	<i>optional parameter with default value: 30</i> specify the inactivity timeout of the terminal
[no] slot-numbering	Parameter type: <Sec::SlotDesc> Format: (type-based position-based legacy-based) Possible values: - type-based : flat-numbering per slot-type (tl1-like) - position-based : flat-numbering independent of slot-type - legacy-based : numbering used since the early days (position-based-like)	<i>optional parameter with default value: "legacy-based"</i> slot numbering scheme to be used by the operator
[no] description	Parameter type: <Sec::ProfileDesc> Format: - any description to be used by the operator - length: x<=31	<i>optional parameter with default value: ""</i> any description to be used by the operator
[no] aaa	Parameter type: <Sec::Aaa> Format: (write read none) Possible values:	<i>optional parameter with default value: "none"</i> the access rights to AAA related commands

Parameter	Type	Description
	- write : write and read access - read : read access - none : no access	
[no] atm	Parameter type: <Sec::Atm> Format: (write read none) Possible values: - write : write and read access - read : read access - none : no access	<i>optional parameter with default value: "none"</i> the access rights to ATM related commands
[no] alarm	Parameter type: <Sec::Alarm> Format: (write read none) Possible values: - write : write and read access - read : read access - none : no access	<i>optional parameter with default value: "none"</i> the access rights to alarm related commands
[no] dhcp	Parameter type: <Sec::Dhcp> Format: (write read none) Possible values: - write : write and read access - read : read access - none : no access	<i>optional parameter with default value: "none"</i> the access rights to DHCP related commands
[no] equipment	Parameter type: <Sec::Equipment> Format: (write read none) Possible values: - write : write and read access - read : read access - none : no access	<i>optional parameter with default value: "none"</i> the access rights to equipment related commands
[no] igmp	Parameter type: <Sec::Igmp> Format: (write read none) Possible values: - write : write and read access - read : read access - none : no access	<i>optional parameter with default value: "none"</i> the access rights to IGMP related commands
[no] ip	Parameter type: <Sec::Ip> Format: (write read none) Possible values: - write : write and read access - read : read access - none : no access	<i>optional parameter with default value: "none"</i> the access rights to IP related commands

16 Security Configuration Commands

Parameter	Type	Description
[no] pppoe	Parameter type: <Sec::Pppoe> Format: (write read none) Possible values: - write : write and read access - read : read access - none : no access	<i>optional parameter with default value: "none"</i> the access rights to PPPOE related commands
[no] qos	Parameter type: <Sec::Qos> Format: (write read none) Possible values: - write : write and read access - read : read access - none : no access	<i>optional parameter with default value: "none"</i> the access rights to qos related commands
[no] software-mngt	Parameter type: <Sec::Sw> Format: (write read none) Possible values: - write : write and read access - read : read access - none : no access	<i>optional parameter with default value: "none"</i> access rights to software management related commands
[no] transport	Parameter type: <Sec::Transport> Format: (write read none) Possible values: - write : write and read access - read : read access - none : no access	<i>optional parameter with default value: "none"</i> the access rights to transport related commands
[no] vlan	Parameter type: <Sec::Vlan> Format: (write read none) Possible values: - write : write and read access - read : read access - none : no access	<i>optional parameter with default value: "none"</i> the access rights to VLAN related commands
[no] xdsl	Parameter type: <Sec::Xdsl> Format: (write read none) Possible values: - write : write and read access - read : read access - none : no access	<i>optional parameter with default value: "none"</i> the access rights to xDSL related commands
[no] sip	Parameter type: <Sec::Sip> Format: (write	<i>optional parameter with default value: "none"</i> the access rights to sip related

Parameter	Type	Description
	read none) Possible values: - write : write and read access - read : read access - none : no access	commands
[no] megaco	Parameter type: <Sec::Megaco> Format: (write read none) Possible values: - write : write and read access - read : read access - none : no access	<i>optional parameter with default value: "none"</i> the access rights to megaco related commands
[no] lacp	Parameter type: <Sec::Lacp> Format: (write read none) Possible values: - write : write and read access - read : read access - none : no access	<i>optional parameter with default value: "none"</i> the access rights to lacp related commands
[no] mstp	Parameter type: <Sec::Mstp> Format: (write read none) Possible values: - write : write and read access - read : read access - none : no access	<i>optional parameter with default value: "none"</i> the access rights to mstp related commands
[no] security	Parameter type: <Sec::Security> Format: (write read none) Possible values: - write : write and read access - read : read access - none : no access	<i>optional parameter with default value: "none"</i> the access rights to security related commands
[no] service	Parameter type: <Sec::Service> Format: (write read none) Possible values: - write : write and read access - read : read access - none : no access	<i>optional parameter with default value: "none"</i> the access rights to service and base router related commands
[no] debug	Parameter type: <Sec::Debug> Format: (write read none) Possible values:	<i>optional parameter with default value: "none"</i> the access rights to debug related commands

16 Security Configuration Commands

Parameter	Type	Description
	- write : write and read access - read : read access - none : no access	
[no] debug-mirror	Parameter type: <Sec::DebugMirror> Format: (write read none) Possible values: - write : write and read access - read : read access - none : no access	<i>optional parameter with default value: "none"</i> the access rights to debug-mirror related commands
[no] filter	Parameter type: <Sec::Filter> Format: (write read none) Possible values: - write : write and read access - read : read access - none : no access	<i>optional parameter with default value: "none"</i> the access rights to filter related commands
[no] link	Parameter type: <Sec::Link> Format: (write read none) Possible values: - write : write and read access - read : read access - none : no access	<i>optional parameter with default value: "none"</i> the access rights to link related commands
[no] log	Parameter type: <Sec::Log> Format: (write read none) Possible values: - write : write and read access - read : read access - none : no access	<i>optional parameter with default value: "none"</i> the access rights to log related commands
[no] oam	Parameter type: <Sec::Oam> Format: (write read none) Possible values: - write : write and read access - read : read access - none : no access	<i>optional parameter with default value: "none"</i> the access rights to OAM related commands
[no] liadmin	Parameter type: <Sec::Liadmin> Format: (write read none) Possible values: - write : write and read access - read : read access - none : no access	<i>optional parameter with default value: "none"</i> the access rights to Lawful Intercept admin related commands

Parameter	Type	Description
[no] liuser	Parameter type: <Sec::Liuser> Format: (write read none) Possible values: - write : write and read access - read : read access - none : no access	<i>optional parameter with default value: "none"</i> the access rights to Lawful Intercept session related commands
[no] drouter	Parameter type: <Sec::Drouter> Format: (write read none) Possible values: - write : write and read access - read : read access - none : no access	<i>optional parameter with default value: "none"</i> the access rights to Drouter related commands
[no] ai	Parameter type: <Sec::Ai> Format: (write read none) Possible values: - write : write and read access - read : read access - none : no access	<i>optional parameter with default value: "none"</i> the access rights to AI related commands
[no] livoice	Parameter type: <Sec::Livoice> Format: (write read none) Possible values: - write : write and read access - read : read access - none : no access	<i>optional parameter with default value: "none"</i> the access rights to Lawful Intercept voice related commands
[no] lldpmed	Parameter type: <Sec::LldpMed> Format: (write read none) Possible values: - write : write and read access - read : read access - none : no access	<i>optional parameter with default value: "none"</i> the access rights to LLDP-MED related commands

16.5 Default Profile Configuration Command

Command Description

This command allows the superuser to specify a default operator profile. The default profile is used when an operator is authenticated via a RADIUS server but the RADIUS server does not support vendor-specific attributes.

The default profile determines most of the operator properties.

The prompt can be composed with following components :

- **%n** : the name of the current operator.
- **%s** : the current numbering scheme (**typ|leg|pos**).
- **%i** : the current system id.
- **%t** : the current system time.
- **%!** : the current history number.
- **% num d** : the current context.
 - num is the maximum number of components (starting from the last) that are shown (default is all).
 - each component will be separated from the next one with a >.
 - a > is also added in front of the first component.
- **%%** : a %
- **%c** : # if the current node was an existing node or \$ if it is newly created.
- **%h** : the current system id.
- any other character is just added to the prompt as is.

Next to %, ISAM supports the use of the \$ as an escape character. The system behavior is the same as when using the % escape character, e.g. an occurrence of \$n is replaced with the name of the current operator. For backward compatibility, the \$ character must be used exclusively without the % character. As soon as the % character is used in the string, all occurrences of the \$ character will be considered as a literal and will not be replaced with the component it refers to.

User Level

The command can be accessed by operators with all,admin privileges.

Operators without security read or write permissions cannot see the default profile.

Command Syntax

The command has the following syntax:

```
> configure system security default-profile [ no prompt | prompt <Sec::Prompt> ] [ password-timeout
<Sec::PasswordTimeout> ] [ no terminal-timeout | terminal-timeout <Sec::InactivityTimeout> ] [ no
slot-numbering | slot-numbering <Sec::SlotDesc> ] [ no description | description <Sec::ProfileDesc> ] [ no aaa | aaa
<Sec::Aaa> ] [ no atm | atm <Sec::Atm> ] [ no alarm | alarm <Sec::Alarm> ] [ no dhcp | dhcp <Sec::Dhcp> ] [ no
equipment | equipment <Sec::Equipment> ] [ no igmp | igmp <Sec::Igmp> ] [ no ip | ip <Sec::Ip> ] [ no pppoe |
pppoe <Sec::Pppoe> ] [ no qos | qos <Sec::Qos> ] [ no software-mngt | software-mngt <Sec::Sw> ] [ no transport |
transport <Sec::Transport> ] [ no vlan | vlan <Sec::Vlan> ] [ no xdsl | xdsl <Sec::Xdsl> ] [ no sip | sip <Sec::Sip> ]
[ no megaco | megaco <Sec::Megaco> ] [ no lacp | lacp <Sec::Lacp> ] [ no mstp | mstp <Sec::Mstp> ] [ no security |
security <Sec::Security> ] [ no service | service <Sec::Service> ] [ no debug | debug <Sec::Debug> ] [ no
debug-mirror | debug-mirror <Sec::DebugMirror> ] [ no filter | filter <Sec::Filter> ] [ no link | link <Sec::Link> ] [
no log | log <Sec::Log> ] [ no oam | oam <Sec::Oam> ] [ no liadmin | liadmin <Sec::Liadmin> ] [ no liuser | liuser
<Sec::Liuser> ] [ no drouter | drouter <Sec::Drouter> ] [ no ai | ai <Sec::Ai> ] [ no livoice | livoice <Sec::Livoice> ]
[ no lldpmed | lldpmed <Sec::LldpMed> ]
```

Command Parameters

Table 16.5-2 "Default Profile Configuration Command" Command Parameters

Parameter	Type	Description
[no] prompt	Parameter type: <Sec::Prompt> Format: - a specification of the prompt - length: x<=31	<i>optional parameter with default value: "\"%s : %n%d%c \""</i> the specification of the prompt
password-timeout	Parameter type: <Sec::PasswordTimeout> Format: - the maximum time a password may be unchanged - unit: days - range: [0...365]	<i>obsolete parameter that will be ignored</i> the maximum time a password may be unchanged
[no] terminal-timeout	Parameter type: <Sec::InactivityTimeout> Format: - specify the inactivity timeout of the terminal - unit: minutes - range: [0...120]	<i>optional parameter with default value: 0</i> the maximum time a terminal may be inactive
[no] slot-numbering	Parameter type: <Sec::SlotDesc> Format: (type-based position-based legacy-based) Possible values: - type-based : flat-numbering per slot-type (tl1-like) - position-based : flat-numbering independent of slot-type - legacy-based : numbering used since the early days (position-based-like)	<i>optional parameter with default value: "legacy-based"</i> slot description to be used by the operator
[no] description	Parameter type: <Sec::ProfileDesc> Format: - any description to be used by the operator - length: x<=31	<i>optional parameter with default value: ""</i> any description to be used by the operator
[no] aaa	Parameter type: <Sec::Aaa> Format: (write read none) Possible values: - write : write and read access - read : read access - none : no access	<i>optional parameter with default value: "read"</i> the access rights to AAA related commands
[no] atm	Parameter type: <Sec::Atm> Format: (write read none) Possible values: - write : write and read access - read : read access - none : no access	<i>optional parameter with default value: "write"</i> the access rights to ATM related commands
[no] alarm	Parameter type: <Sec::Alarm> Format: (write read none) Possible values:	<i>optional parameter with default value: "write"</i> the access rights to alarm related commands

16 Security Configuration Commands

Parameter	Type	Description
	- write : write and read access - read : read access - none : no access	
[no] dhcp	Parameter type: <Sec::Dhcp> Format: (write read none) Possible values: - write : write and read access - read : read access - none : no access	<i>optional parameter with default value: "write"</i> the access rights to DHCP related commands
[no] equipment	Parameter type: <Sec::Equipment> Format: (write read none) Possible values: - write : write and read access - read : read access - none : no access	<i>optional parameter with default value: "write"</i> the access rights to equipment related commands
[no] igmp	Parameter type: <Sec::Igmp> Format: (write read none) Possible values: - write : write and read access - read : read access - none : no access	<i>optional parameter with default value: "write"</i> the access rights to IGMP related commands
[no] ip	Parameter type: <Sec::Ip> Format: (write read none) Possible values: - write : write and read access - read : read access - none : no access	<i>optional parameter with default value: "write"</i> the access rights to IP related commands
[no] pppoe	Parameter type: <Sec::Pppoe> Format: (write read none) Possible values: - write : write and read access - read : read access - none : no access	<i>optional parameter with default value: "write"</i> the access rights to PPOE related commands
[no] qos	Parameter type: <Sec::Qos> Format: (write read none) Possible values: - write : write and read access - read : read access - none : no access	<i>optional parameter with default value: "write"</i> the access rights to qos related commands

Parameter	Type	Description
[no] software-mngt	Parameter type: <Sec::Sw> Format: (write read none) Possible values: - write : write and read access - read : read access - none : no access	<i>optional parameter with default value: "write"</i> access rights to software management related commands
[no] transport	Parameter type: <Sec::Transport> Format: (write read none) Possible values: - write : write and read access - read : read access - none : no access	<i>optional parameter with default value: "write"</i> the access rights to transport related commands
[no] vlan	Parameter type: <Sec::Vlan> Format: (write read none) Possible values: - write : write and read access - read : read access - none : no access	<i>optional parameter with default value: "write"</i> the access rights to VLAN related commands
[no] xdsl	Parameter type: <Sec::Xdsl> Format: (write read none) Possible values: - write : write and read access - read : read access - none : no access	<i>optional parameter with default value: "write"</i> the access rights to xDSL related commands
[no] sip	Parameter type: <Sec::Sip> Format: (write read none) Possible values: - write : write and read access - read : read access - none : no access	<i>optional parameter with default value: "write"</i> the access rights to sip related commands
[no] megaco	Parameter type: <Sec::Megaco> Format: (write read none) Possible values: - write : write and read access - read : read access - none : no access	<i>optional parameter with default value: "write"</i> the access rights to megaco related commands
[no] lacp	Parameter type: <Sec::Lacp> Format: (write	<i>optional parameter with default value: "write"</i> the access rights to lacp related

16 Security Configuration Commands

Parameter	Type	Description
	read none) Possible values: - write : write and read access - read : read access - none : no access	commands
[no] mstp	Parameter type: <Sec::Mstp> Format: (write read none) Possible values: - write : write and read access - read : read access - none : no access	<i>optional parameter with default value: "write"</i> the access rights to mstp related commands
[no] security	Parameter type: <Sec::Security> Format: (write read none) Possible values: - write : write and read access - read : read access - none : no access	<i>optional parameter with default value: "none"</i> the access rights to security related commands
[no] service	Parameter type: <Sec::Service> Format: (write read none) Possible values: - write : write and read access - read : read access - none : no access	<i>optional parameter with default value: "write"</i> the access rights to service related commands
[no] debug	Parameter type: <Sec::Debug> Format: (write read none) Possible values: - write : write and read access - read : read access - none : no access	<i>optional parameter with default value: "write"</i> the access rights to debug related commands
[no] debug-mirror	Parameter type: <Sec::DebugMirror> Format: (write read none) Possible values: - write : write and read access - read : read access - none : no access	<i>optional parameter with default value: "write"</i> the access rights to debug-mirror related commands
[no] filter	Parameter type: <Sec::Filter> Format: (write read none) Possible values:	<i>optional parameter with default value: "write"</i> the access rights to filter related commands

Parameter	Type	Description
	- write : write and read access - read : read access - none : no access	
[no] link	Parameter type: <Sec::Link> Format: (write read none) Possible values: - write : write and read access - read : read access - none : no access	<i>optional parameter with default value: "write"</i> the access rights to link related commands
[no] log	Parameter type: <Sec::Log> Format: (write read none) Possible values: - write : write and read access - read : read access - none : no access	<i>optional parameter with default value: "write"</i> the access rights to log related commands
[no] oam	Parameter type: <Sec::Oam> Format: (write read none) Possible values: - write : write and read access - read : read access - none : no access	<i>optional parameter with default value: "write"</i> the access rights to OAM related commands
[no] liadmin	Parameter type: <Sec::Liadmin> Format: (write read none) Possible values: - write : write and read access - read : read access - none : no access	<i>optional parameter with default value: "write"</i> the access rights to Lawful Intercept admin related commands
[no] liuser	Parameter type: <Sec::Liuser> Format: (write read none) Possible values: - write : write and read access - read : read access - none : no access	<i>optional parameter with default value: "write"</i> the access rights to Lawful Intercept Session related commands
[no] drouter	Parameter type: <Sec::Drouter> Format: (write read none) Possible values: - write : write and read access - read : read access - none : no access	<i>optional parameter with default value: "write"</i> the access rights to Drouter related commands

16 Security Configuration Commands

Parameter	Type	Description
[no] ai	Parameter type: <Sec::Ai> Format: (write read none) Possible values: - write : write and read access - read : read access - none : no access	<i>optional parameter with default value: "write"</i> the access rights to AI related commands
[no] livoice	Parameter type: <Sec::Livoice> Format: (write read none) Possible values: - write : write and read access - read : read access - none : no access	<i>optional parameter with default value: "write"</i> the access rights to Lawful Intercept voice related commands
[no] lldpmed	Parameter type: <Sec::LldpMed> Format: (write read none) Possible values: - write : write and read access - read : read access - none : no access	<i>optional parameter with default value: "write"</i> the access rights to LLDP-MED related commands

16.6 SNMP View Configuration Command

Command Description

This command allows the operator to configure a view.

User Level

The command can be accessed by operators with security privileges, and executed by operators with security privileges.

A subtree is identified by an object ID, which is a sequence of numbers (example: 1.3.6.1.6.3.12.1.3). This sequence uniquely identifies a node or a leaf in the MIB tree.

The same subtree can also be addressed using symbolic MIB names (example: snmpTargetParamsTable).

Combinations of symbolic names and numbers are also possible: 1.3.6.1.6.3.12.1.3.1.7.97.97.97 can be written as snmpTargetParamsTable.1.7.97.97.97 or as snmpTargetParamsRowStatus.97.97.97, ...

For each number, we can indicate that it may be ignored when comparing it with MIB elements, by adding an asterisk after the number (example: snmpTargetParamsRowStatus.97.97.97). Because the number is ignored anyway, we recommend replacing it with a 0. For example, snmpTargetParamsRowStatus.97.0*.97. 0* can be abbreviated as *. So, the recommended representation is snmpTargetParamsRowStatus.97.*.97.*

The system stores a view entry based on the view name and the object ID: snmpTargetParamsRowStatus.97.0.97 and snmpTargetParamsRowStatus.97.97*.97 are stored in two different locations, but match the same MIB elements. A consequence of this strategy is that snmpTargetParamsRowStatus.97.97*.97 and snmpTargetParamsRowStatus.97.97.97 can not exist at the same time.*

The most specific filter element takes precedence in the case where more than one filter element matches the same MIB element.

Clarification regarding 'entry-status': If a failure occurs during the configuration of an SNMP view, please check if the view was created and if the corresponding entry-status is valid. If not, please delete and re-create the entire SNMP view.

Command Syntax

The command has the following syntax:

```
> configure system security snmp ( no view (notify-view) subtree <Snmp::ViewSubtree> ) | ( view (notify-view) subtree <Snmp::ViewSubtree> type <Snmp::FilterType> )
```

Command Parameters

Table 16.6-1 "SNMP View Configuration Command" Resource Parameters

Resource Identifier	Type	Description
(notify-view)	Format: - the name of a view - length: x<=32	the name of the view
subtree	Parameter type: <Snmp::ViewSubtree> Format:	the subtree

Resource Identifier	Type	Description
	<Snmplib::ViewSubtree> Field type <Snmplib::ViewSubtree> - specification of view subtree. Eg(vacmAccessTable.*.7)	

Table 16.6-2 "SNMP View Configuration Command" Command Parameters

Parameter	Type	Description
type	Parameter type: <Snmplib::FilterType> Format: (include exclude) Possible values: - include : include the matching varbinds - exclude : exclude the matching varbinds	<i>mandatory parameter</i> the filter type

Command Output

Table 16.6-3 "SNMP View Configuration Command" Display parameters

Specific Information		
name	Type	Description
entry-status	Parameter type: <Transport::WaitRowStatusVacmFilter> (valid corrupted corrupted) Possible values: - valid : SNMP view configuration is ok - corrupted : SNMP view configuration is not operational(not-in-service) - corrupted : SNMP view configuration is not operational(not-ready)	the status of an SNMP view <i>This element is only shown in detail mode.</i>

16.7 Security SNMP Community Configuration Command

Command Description

This command allows the operator to configure community names.

An existing community can not be modified.

SNMP uses community names as a kind of password without user name to verify if a request may be executed.

The community name is configured for an IP range which is specified by IP address and subnet netmask. Different IP addresses with same netmask may represent for same IP range. For example, both 108.79.136.20/24 and 108.79.136.21/24 represent for IP range from 108.79.136.1 to 108.79.136.255.

User Level

The command can be accessed by operators with security privileges, and executed by operators with security privileges.

There must be at least one community with read-write privileges.

Command Syntax

The command has the following syntax:

```
> configure system security snmp ( no community (name) host-address <Ip::IpXAddressAndIpMaskFull> ) | (
community (name) host-address <Ip::IpXAddressAndIpMaskFull> [ no context | context <Transport::Context> ] [
no privilege | privilege <Snmp::CommunityPrivilege> ] [ no read-view | read-view <Snmp::ViewName> ] [ no
write-view | write-view <Snmp::ViewName> ] [ no notify-view | notify-view <Snmp::ViewName> ] )
```

Command Parameters

Table 16.7-1 "Security SNMP Community Configuration Command" Resource Parameters

Resource Identifier	Type	Description
(name)	Format: - the community name The name in plain text is placed in double quotes when # ? [or] is used. In double quotes, backslash is regarded as escape, and it is used to escape control character, quotation mark, and itself. - length: x<=32	the name of the community
host-address	Parameter type: <Ip::IpXAddressAndIpMaskFull> Format: (<Ip::V4Address> / <Ip::PrefixLengthFull> ipv6 : <Ip::V6Prefix> / <Ip::V6PrefixLength>) Possible values: - ipv6 : ipv6-address Field type <Ip::V4Address> - IPv4-address	the ipv4/6 address and mask as prefix length

Resource Identifier	Type	Description
	Field type <Ip::PrefixLengthFull> - IP address prefix length - range: [0...32] Field type <Ip::V6Prefix> - IPv6-address Field type <Ip::V6PrefixLength> - prefix length of IPv6-address - range: [0...128]	

Table 16.7-2 "Security SNMP Community Configuration Command" Command Parameters

Parameter	Type	Description
[no] context	Parameter type: <Transport::Context> Format: (nt shub epon xvps1 xvps2 xvps3 xvps4 xvps5 xvps6 xvps7 xvps8 ihub ai_nt_1 ai_nta_1 ai_ntb_1 vvpsa) Possible values: - nt : nt context - shub : shub context - epon : epon context - xvps1 : xvps1 context - xvps2 : xvps2 context - xvps3 : xvps3 context - xvps4 : xvps4 context - xvps5 : xvps5 context - xvps6 : xvps6 context - xvps7 : xvps7 context - xvps8 : xvps8 context - ihub : ihub context - ai_nt_1 : ai nt context - ai_nta_1 : ai nta context - ai_ntb_1 : ai ntb context - vvpsa : vvpsa context	<i>optional parameter with default value: "nt"</i> the context allowed for this community
[no] privilege	Parameter type: <Snmp::CommunityPrivilege> Format: (read-only read-write write-only) Possible values: - read-only : only read privileges - read-write : read and write privileges - write-only : only write privileges	<i>optional parameter with default value: "read-write"</i> the access privileges we have when we use this community
[no] read-view	Parameter type: <Snmp::ViewName> Format:	<i>optional parameter with default value: "everything"</i>

Parameter	Type	Description
	- the name of a view - length: x<=32	the name of the view to be used for read accesses
[no] write-view	Parameter type: <Snmplib::ViewName> Format: - the name of a view - length: x<=32	<i>optional parameter with default value: "everything"</i> the name of the view to be used for write accesses
[no] notify-view	Parameter type: <Snmplib::ViewName> Format: - the name of a view - length: x<=32	<i>optional parameter with default value: "everything"</i> the name of the view to filter notifications

16.8 Security SNMPv3 Group Configuration

Command

Command Description

This command allows the operator to configure an SNMPv3 Group.

Clarification regarding 'entry-status': If a failure occurs during the configuration of an SNMPv3 Group, please check if the group was created and if the corresponding entry-status is valid. If not, please delete and re-create the entire SNMPv3 Group.

User Level

The command can be accessed by operators with security privileges, and executed by operators with security privileges.

Command Syntax

The command has the following syntax:

```
> configure system security snmp ( no group (name) security-level <Snmpp::SecurityLevel> context
<Snmpp::Context> ) | ( group (name) security-level <Snmpp::SecurityLevel> context <Snmpp::Context> [ no
read-view | read-view <Snmpp::AssociatedViewName> ] [ no write-view | write-view
<Snmpp::AssociatedViewName> ] [ no notify-view | notify-view <Snmpp::AssociatedViewName> ] )
```

Command Parameters

Table 16.8-1 "Security SNMPv3 Group Configuration Command" Resource Parameters

Resource Identifier	Type	Description
(name)	Format: - name of the snmpv3 group The name in plain text is placed in double quotes when # ? [or] is used. In double quotes, backslash is regarded as escape, and it is used to escape control character, quotation mark, and itself. - length: 1<=x<=32	name of snmpV3 group
security-level	Parameter type: <Snmpp::SecurityLevel> Format: (none authentication privacy-and-auth) Possible values: - none : no authentication and no privacy - authentication : authentication without privacy - privacy-and-auth : authentication and privacy	security level for the group
context	Parameter type: <Snmpp::Context> Format: (single : nt	context for the group

Resource Identifier	Type	Description
	single : shub single : epon single : xvps1 single : xvps2 single : xvps3 single : xvps4 single : xvps5 single : xvps6 single : xvps7 single : xvps8 single : ihub single : ai_nt_1 single : ai_nta_1 single : ai_ntb_1 single : vvpsa all) Possible values: - single : grant access to a specific context - all : grant access to all contexts Possible values: - nt : the nt context - shub : the shub context - epon : the epon context - xvps1 : the xvps1 context - xvps2 : the xvps2 context - xvps3 : the xvps3 context - xvps4 : the xvps4 context - xvps5 : the xvps5 context - xvps6 : the xvps6 context - xvps7 : the xvps7 context - xvps8 : the xvps8 context - ihub : the ihub context - ai_nt_1 : the ai nt context 1 - ai_nta_1 : the ai nt-a context 1 - ai_ntb_1 : the ai nt-b context 1 - vvpsa : the vvpsa context - : any context	

Table 16.8-2 "Security SNMPv3 Group Configuration Command" Command Parameters

Parameter	Type	Description
[no] read-view	Parameter type: <Snmp::AssociatedViewName> Format: - the name of a view - length: x<=32	<i>optional parameter with default value: "everything"</i> the name of the view to be used for read accesses
[no] write-view	Parameter type: <Snmp::AssociatedViewName> Format: - the name of a view - length: x<=32	<i>optional parameter with default value: "everything"</i> the name of the view used for write accesses
[no] notify-view	Parameter type: <Snmp::AssociatedViewName> Format: - the name of a view - length: x<=32	<i>optional parameter with default value: "everything"</i> the name of the view to filter notifications

Command Output

Table 16.8-3 "Security SNMPv3 Group Configuration Command" Display parameters

16 Security Configuration Commands

Specific Information		
name	Type	Description
entry-status	Parameter type: <Transport::WaitRowStatusconfigGroup> (valid corrupted corrupted) Possible values: - valid : SNMPv3 group configuration is ok - corrupted : SNMPv3 group configuration is not operational(not-in-service) - corrupted : SNMPv3 group configuration is not operational(not-ready)	the status of an SNMPv3 group <i>This element is only shown in detail mode.</i>

16.9 Security SNMPv3 User Configuration

Command

Command Description

This command allows the operator to configure an SNMPv3 user.

Clarification regarding 'entry-status': If a failure occurs during the configuration of an SNMPv3 user, please check if the user was created and if the corresponding entry-status is valid. If not, please delete and re-create the entire SNMPv3 user.

User Level

The command can be accessed by operators with security privileges, and executed by operators with security privileges.

Command Syntax

The command has the following syntax:

```
> configure system security snmp ( no user (name) ) | ( user (name) [ no authentication | authentication
<Snmpp::AuthType> ] [ no privacy | privacy <Snmpp::PrivacyType> ] [ no public | public <Snmpp::Identifier> ] )
```

Command Parameters

Table 16.9-1 "Security SNMPv3 User Configuration Command" Resource Parameters

Resource Identifier	Type	Description
(name)	Format: - snmpv3 user name\n The name in plain text is placed in double quotes when # ? [or] is used.\n In double quotes, backslash is regarded as escape, and it is used to escape control character, quotation mark, and itself. - length: 1<=x<=32	name of the user

Table 16.9-2 "Security SNMPv3 User Configuration Command" Command Parameters

Parameter	Type	Description
[no] authentication	Parameter type: <Snmpp::AuthType> Format: (none md5 : prompt sha1 : prompt sha256 : prompt sha512 : prompt md5 : plain : <Sec::UsmPlainPassword> sha1 : plain : <Sec::UsmPlainPassword> sha256 : plain : <Sec::UsmPlainPassword> sha512 : plain : <Sec::UsmPlainPassword>	<i>optional parameter with default value: "none"</i> authentication for the user

Parameter	Type	Description
	md5 : encrypted : <Snmp::AuthEncryptedKey> sha1 : encrypted : <Snmp::AuthEncryptedKey> sha256 : encrypted : <Snmp::AuthEncryptedKey> sha512 : encrypted : <Snmp::AuthEncryptedKey>) Possible values: - none : no authentication - md5 : md5 based authentication - sha1 : sha1 based authentication - sha256 : sha256 based authentication - sha512 : sha512 based authentication Possible values: - prompt : prompts the operator to enter a password - plain : enter the password in plain text - encrypted : enter the encrypted password Field type <Sec::UsmPlainPassword> - the password in plain text is placed in double quotes when # or ? is used - length: 8<=x<=20 Field type <Snmp::AuthEncryptedKey> - an encrypted password - length: 16<=x<=64	
[no] privacy	Parameter type: <Snmp::PrivacyType> Format: (none des : prompt aes-128 : prompt des : plain : <Sec::UsmPlainPassword> aes-128 : plain : <Sec::UsmPlainPassword> des : encrypted : <Snmp::PrivacyEncryptedKey> aes-128 : encrypted : <Snmp::PrivacyEncryptedKey>) Possible values: - none : no privacy required - des : des based privacy - aes-128 : aes-128 based privacy Possible values: - prompt : prompts the operator for a password - plain : enter the password in plain text - encrypted : enter the encrypted password Field type <Sec::UsmPlainPassword> - the password in plain text is placed in double quotes when # or ? is used - length: 8<=x<=20 Field type <Snmp::PrivacyEncryptedKey> - an encrypted privacy password - length: 16	<i>optional parameter with default value: "none"</i> snmp privacy type
[no] public	Parameter type: <Snmp::Identifier> Format: - a hexadecimal identifier - length: 1<=x<=32	<i>optional parameter with default value: ""</i> identifier used by scenarios to change security keys

Command Output

Table 16.9-3 "Security SNMPv3 User Configuration Command" Display parameters

Specific Information		
name	Type	Description
entry-status	Parameter type: <Transport::WaitRowStatusSnmpUser>	the status of an SNMPv3 user

name	Type	Description
	(valid corrupted corrupted) Possible values: - valid : SNMPv3 user configuration is ok - corrupted : SNMPv3 user configuration is not operational(not-in-service) - corrupted : SNMPv3 user configuration is not operational(not-ready)	<i>This element is only shown in detail mode.</i>

16.10 Security SNMPv3 User-Group Configuration Command

Command Description

This command allows the operator to map an SNMPv3 user to an SNMPv3 group.

Clarification regarding 'entry-status': If a failure occurs during the configuration of mapping an SNMPv3 user to SNMPv3 user-group, please check if the mapping was done and if the corresponding entry-status is valid. If not, please delete and re-create the entire configuration of mapping an SNMPv3 user to SNMPv3 user-group.

User Level

The command can be accessed by operators with security privileges, and executed by operators with security privileges.

Command Syntax

The command has the following syntax:

```
> configure system security snmp ( no map-user-group (name) ) | ( map-user-group (name) group-name
<Snmpr::AssociatedGroupName> )
```

Command Parameters

Table 16.10-1 "Security SNMPv3 User-Group Configuration Command" Resource Parameters

Resource Identifier	Type	Description
(name)	Format: - snmpv3 user name The name in plain text is placed in double quotes when # ? [or] is used. In double quotes, backslash is regarded as escape, and it is used to escape control character, quotation mark, and itself. - length: 1<=x<=32	name of the snmpV3 user

Table 16.10-2 "Security SNMPv3 User-Group Configuration Command" Command Parameters

Parameter	Type	Description
group-name	Parameter type: <Snmpr::AssociatedGroupName> Format: - name of the snmpv3 group - length: 1<=x<=32	<i>mandatory parameter</i> name of the snmpV3 group

Command Output

Table 16.10-3 "Security SNMPv3 User-Group Configuration Command" Display parameters

Specific Information

name	Type	Description
entry-status	Parameter type: <Transport::WaitRowStatusMapUser> (valid corrupted corrupted) Possible values: - valid : mapping SNMPv3 user to SNMPv3 group configuration is ok - corrupted : mapping SNMPv3 user to SNMPv3 group configuration is not operational(not-in-service) - corrupted : mapping SNMPv3 user to SNMPv3 group configuration is not operational(not-ready)	the status of mapping an SNMPv3 user to an SNMPv3 group <i>This element is only shown in detail mode.</i>

16.11 SNMP Notify View Configuration Command

Command Description

This command allows the operator to configure a Notify View.

User Level

The command can be accessed by operators with security privileges, and executed by operators with security privileges.

A subtree is identified by an object ID, which is a sequence of numbers (example: 1.3.6.1.6.3.12.1.3). This sequence uniquely identifies a node or a leaf in the MIB tree.

The same subtree can also be addressed using symbolic MIB names (example: snmpTargetParamsTable).

Combinations of symbolic names and numbers are also possible: 1.3.6.1.6.3.12.1.3.1.7.97.97.97 can be written as snmpTargetParamsTable.1.7.97.97.97 or as snmpTargetParamsRowStatus.97.97.97, ...

For each number, we can indicate that it may be ignored when comparing it with MIB elements, by adding an asterisk after the number (example: snmpTargetParamsRowStatus.97.97.97). Because the number is ignored anyway, we recommend replacing it with a 0. For example, snmpTargetParamsRowStatus.97.0*.97. 0* can be abbreviated as *. So, the recommended representation is snmpTargetParamsRowStatus.97.*.97.*

The system stores a view entry based on the view name and the object ID: snmpTargetParamsRowStatus.97.0.97 and snmpTargetParamsRowStatus.97.97*.97 are stored in two different locations, but match the same MIB elements. A consequence of this strategy is that snmpTargetParamsRowStatus.97.97*.97 and snmpTargetParamsRowStatus.97.97.97 can not exist at the same time.*

The most specific filter element takes precedence in the case where more than one filter element matches the same MIB element.

Clarification regarding 'entry-status': If a failure occurs during the configuration of a Notify View, please check if the view was created and if the corresponding entry-status is valid. If not, please delete and re-create the entire Notify View.

Command Syntax

The command has the following syntax:

```
> configure system security snmp ( no notify-view (notify-view) subtree <Snmp::ViewSubtree> ) | ( notify-view (notify-view) subtree <Snmp::ViewSubtree> type <Snmp::FilterType> )
```

Command Parameters

Table 16.11-1 "SNMP Notify View Configuration Command" Resource Parameters

Resource Identifier	Type	Description
(notify-view)	Format: - the name of a view - length: x<=32	the name of the notify view
subtree	Parameter type: <Snmp::ViewSubtree> Format:	the subtree

Resource Identifier	Type	Description
	<Snmplib::ViewSubtree> Field type <Snmplib::ViewSubtree> - specification of view subtree. Eg(vacmAccessTable.*.7)	

Table 16.11-2 "SNMP Notify View Configuration Command" Command Parameters

Parameter	Type	Description
type	Parameter type: <Snmplib::FilterType> Format: (include exclude) Possible values: - include : include the matching varbinds - exclude : exclude the matching varbinds	<i>mandatory parameter</i> the filter type

Command Output

Table 16.11-3 "SNMP Notify View Configuration Command" Display parameters

Specific Information		
name	Type	Description
entry-status	Parameter type: <Transport::WaitRowStatusNotifyFilter> (valid corrupted corrupted) Possible values: - valid : SNMP Notify View configuration is ok - corrupted : SNMP notify view configuration is not operational(not-in-service) - corrupted : SNMP notify view configuration is not operational(not-ready)	the status of an SNMP notify view <i>This element is only shown in detail mode.</i>

16.12 Security SNMP Notification Profile Configuration Command

Command Description

This command allows the operator to configure a notification profile.

Clarification regarding 'entry-status': If a failure occurs during the configuration of the SNMP notification profile, please check if the profile was created and if the corresponding entry-status is valid. If not, please delete and re-create the entire SNMP notification profile.

User Level

The command can be accessed by operators with security privileges, and executed by operators with security privileges.

Command Syntax

The command has the following syntax:

```
> configure system security snmp ( no notify-profile (name) ) | ( notify-profile (name) snmp-version
<Snmp::SnmpVersion> )
```

Command Parameters

Table 16.12-1 "Security SNMP Notification Profile Configuration Command" Resource Parameters

Resource Identifier	Type	Description
(name)	Format: - notification-profile name - length: 1<=x<=32	name of the notification profile

Table 16.12-2 "Security SNMP Notification Profile Configuration Command" Command Parameters

Parameter	Type	Description
snmp-version	Parameter type: <Snmp::SnmpVersion> Format: (v1 : <Snmp::CommunityString> v2 : <Snmp::CommunityString> v3 : <Snmp::SecurityName> : none v3 : <Snmp::SecurityName> : authentication v3 : <Snmp::SecurityName> : privacy-and-auth) Possible values: - v1 : SNMP version1 - v2 : SNMP version2 - v3 : SNMP version3 Field type <Snmp::CommunityString> - community string	<i>mandatory parameter</i> <i>The parameter is not visible during modification.</i> snmp-version of the profile

Parameter	Type	Description
	- length: 1<=x<=32 Field type <Snmp::SecurityName> - snmpv3 user name - length: 1<=x<=32 Possible values: - none : no authentication and no privacy - authentication : authentication only - privacy-and-auth : authentication and privacy	

Command Output

Table 16.12-3 "Security SNMP Notification Profile Configuration Command" Display parameters

Specific Information		
name	Type	Description
entry-status	Parameter type: <Transport::WaitRowStatusProfile> (valid corrupted corrupted) Possible values: - valid : notification profile configuration is ok - corrupted : notification profile configuration is not operational(not-in-service) - corrupted : notification profile configuration is not operational(not-ready)	the status of notification profile <i>This element is only shown in detail mode.</i>

16.13 Security SNMP Notification Profile Filter Configuration Command

Command Description

This command allows the operator to configure a filter for a notification profile.

Clarification regarding 'entry-status': If a failure occurs during the configuration of a filter for SNMP notification profile, please check if the filter was created and if the corresponding entry-status is valid. If not, please delete and re-create the entire notification profile filter.

User Level

The command can be accessed by operators with security privileges, and executed by operators with security privileges.

Command Syntax

The command has the following syntax:

```
> configure system security snmp notify-profile (name) ( no filter ) | ( filter notify-view <Snmp::ViewName> )
```

Command Parameters

Table 16.13-1 "Security SNMP Notification Profile Filter Configuration Command" Resource Parameters

Resource Identifier	Type	Description
(name)	Format: - notification-profile name - length: 1<=x<=32	name of the notification profile

Table 16.13-2 "Security SNMP Notification Profile Filter Configuration Command" Command Parameters

Parameter	Type	Description
notify-view	Parameter type: <Snmp::ViewName> Format: - the name of a view - length: x<=32	<i>mandatory parameter</i> view to be accessed

Command Output

Table 16.13-3 "Security SNMP Notification Profile Filter Configuration Command" Display parameters

Specific Information		
name	Type	Description
entry-status	Parameter type: <Transport::WaitRowStatusNotifyView>	the status of notification profile

name	Type	Description
	(valid corrupted corrupted) Possible values: - valid : notification profile filter configuration is ok - corrupted : notification profile filter configuration is not operational(not-in-service) - corrupted : notification profile filter configuration is not operational(not-ready)	filter <i>This element is only shown in detail mode.</i>

16.14 Security SNMP Element Manager Configuration Command

Command Description

This command allows the operator to configure an Element Manager using a Profile.

Clarification regarding 'entry-status': If a failure occurs during the configuration of the SNMP element manager, please check if the element manager was created and if the corresponding entry-status is valid. If not, please delete and re-create the entire SNMP element manager.

User Level

The command can be accessed by operators with security privileges, and executed by operators with security privileges.

Command Syntax

The command has the following syntax:

```
> configure system security snmp ( no manager (name) ) | ( manager (name) destination <Snmpp::Address>
notify-profile <Snmpp::NotifyProfile> [ [ no ] nt ] [ [ no ] shub ] [ [ no ] ihub ] [ [ no ] epon ] [ [ no ] xvps1 ] [ [ no ]
xvps2 ] [ [ no ] xvps3 ] [ [ no ] xvps4 ] [ [ no ] xvps5 ] [ [ no ] xvps6 ] [ [ no ] xvps7 ] [ [ no ] xvps8 ] [ [ no ] vvpsa
] )
```

Command Parameters

Table 16.14-1 "Security SNMP Element Manager Configuration Command" Resource Parameters

Resource Identifier	Type	Description
(name)	Format: - element manager name - length: 1<=x<=32	name of the element manager

Table 16.14-2 "Security SNMP Element Manager Configuration Command" Command Parameters

Parameter	Type	Description
destination	Parameter type: <Snmpp::Address> Format: (<Snmpp::IpAddress> : <Snmpp::AddressPort> ipv6 : <Snmpp::Ipv6Address> / <Snmpp::AddressPort>) Possible values: - ipv6 : ipv6-address Field type <Snmpp::IpAddress> - ip-address for the manager Field type <Snmpp::Ipv6Address> - ipv6-address for the manager Field type <Snmpp::AddressPort> - port number for the manager	<i>mandatory parameter</i> <i>The parameter is not visible during modification.</i> destination address of the element manager

Parameter	Type	Description
	- range: [1...65535]	
notify-profile	Parameter type: <Snmp::NotifyProfile> Format: - notification-profile name - length: 1<=x<=32	<i>mandatory parameter</i> name of the notification profile
[no] nt	Parameter type: boolean	<i>optional parameter</i> enable storing in nt
[no] shub	Parameter type: boolean	<i>optional parameter</i> enable storing in shub
[no] ihub	Parameter type: boolean	<i>optional parameter</i> enable storing in ihub
[no] epon	Parameter type: boolean	<i>optional parameter</i> enable storing in epon
[no] xvps1	Parameter type: boolean	<i>optional parameter</i> enable storing in xvps1
[no] xvps2	Parameter type: boolean	<i>optional parameter</i> enable storing in xvps2
[no] xvps3	Parameter type: boolean	<i>optional parameter</i> enable storing in xvps3
[no] xvps4	Parameter type: boolean	<i>optional parameter</i> enable storing in xvps4
[no] xvps5	Parameter type: boolean	<i>optional parameter</i> enable storing in xvps5
[no] xvps6	Parameter type: boolean	<i>optional parameter</i> enable storing in xvps6
[no] xvps7	Parameter type: boolean	<i>optional parameter</i> enable storing in xvps7
[no] xvps8	Parameter type: boolean	<i>optional parameter</i> enable storing in xvps8
[no] vvpsa	Parameter type: boolean	<i>optional parameter</i> enable storing in vvpsa

Command Output

Table 16.14-3 "Security SNMP Element Manager Configuration Command" Display parameters

Specific Information		
name	Type	Description
entry-status	Parameter type: <Transport::WaitRowStatusconfigManger> (valid corrupted corrupted) Possible values: - valid : SNMPv3 element manager configuration is ok - corrupted : SNMPv3 element manager configuration is not operational(not-in-service) - corrupted : SNMPv3 element manager configuration is not operational(not-ready)	the status of an SNMP Element Manager <i>This element is only shown in detail mode.</i>

16.15 Security RADIUS Client Configuration

Command

Command Description

This command allows to configure generic parameters for when a Radius Client is used. More details can be found in the description per parameter.

User Level

The command can be accessed by operators with aaa privileges, and executed by operators with aaa privileges.

Command Syntax

The command has the following syntax:

```
> configure system security radius [ [ no ] auth-super-user ] [ no operator-policy | operator-policy <Aaa::RadiusPolicyName> ] [ no aut-s-unreach-act | aut-s-unreach-act <Aaa::RadiusAuthServUnreachAction> ]
```

Command Parameters

Table 16.15-2 "Security RADIUS Client Configuration Command" Command Parameters

Parameter	Type	Description
[no] auth-super-user	Parameter type: boolean	<i>optional parameter</i> enable superuser RADIUS Authentication
[no] operator-policy	Parameter type: <Aaa::RadiusPolicyName> Format: (none name : <Aaa::IgnoredRadiusPolicyName>) Possible values: - none : no profile name to associate - name : enter profile name to be associated Field type <Aaa::IgnoredRadiusPolicyName> - name of the RADIUS policy - length: 1<=x<=64	<i>optional parameter with default value: "none"</i> operator RADIUS policy name
[no] aut-s-unreach-act	Parameter type: <Aaa::RadiusAuthServUnreachAction> Format: (reject-all accept-all) Possible values: - reject-all : All session requests are rejected - accept-all : All session requests are accepted	<i>optional parameter with default value: "reject-all"</i> action to be taken for 802.1x users when authentication server is unreachable

16.16 Security RADIUS Authentication Server Configuration Command

Command Description

This command allows the operator to configure the RADIUS authentication servers. The conceptual table lists the RADIUS authentication servers with their configurable parameters. If an entry (server) must be deleted, it must not be associated with any RADIUS policy. If an entry is associated with a policy, the deletion is not allowed.

Note: the products from the ISAM 7362, 7363 and 7367 family support only vrf-index=0.

User Level

The command can be accessed by operators with aaa privileges, and executed by operators with aaa privileges.

Command Syntax

The command has the following syntax:

```
> configure system security radius ( no auth-server (name) router-instance <Ihub::Router> ) | ( auth-server (name)
router-instance <Ihub::Router> ip-address <Aaa::InetAddress> [ no port | port <Aaa::InetPortNumber> ] secret
<Security::Password3> [ no retry-limit | retry-limit <Aaa::RadiusRetryLimit> ] [ no timeout-limit | timeout-limit
<Aaa::RadiusTimeout> ] [ [ no ] admin-down ] [ no dead-interval | dead-interval <Aaa::RadiusDeadInterval> ] )
```

Command Parameters

Table 16.16-1 "Security RADIUS Authentication Server Configuration Command" Resource Parameters

Resource Identifier	Type	Description
(name)	Format: - name of the RADIUS auth server - length: 1<=x<=64	name of RADIUS authentication server
router-instance	Parameter type: <Ihub::Router> Format: (base <Ihub::Router>) Possible values: - base : base router Field type <Ihub::Router> - vprn service-id - range: [1...2147483647]	router to which this auth server belongs

Table 16.16-2 "Security RADIUS Authentication Server Configuration Command" Command Parameters

Parameter	Type	Description
ip-address	Parameter type: <Aaa::InetAddress> Format:	mandatory parameter IP address of RADIUS

16 Security Configuration Commands

Parameter	Type	Description
	- IPv4-address	authentication server
[no] port	Parameter type: <Aaa::InetPortNumber> Format: - the port number that is used to communicate with an AAA server - range: [0...65535]	<i>optional parameter with default value: 1812</i> UDP port to which RADIUS auth messages should be sent
secret	Parameter type: <Security::Password3> Format: (prompt plain : <Security::PlainPassword3> encrypted : <Security::EncryptedPasswordx>) Possible values: - prompt : prompts the operator for a password - plain : the password in plain text - encrypted : the encrypted password Field type <Security::PlainPassword3> - password string hidden from users - length: 6<=x<=64 Field type <Security::EncryptedPasswordx> - password string exposed to users - length: 8<=x<=64	<i>mandatory parameter</i> secret string used between RADIUS server and client
[no] retry-limit	Parameter type: <Aaa::RadiusRetryLimit> Format: - radius retry limit - range: [0...100]	<i>optional parameter with default value: 3</i> no of times RADIUS server be tried before giving up
[no] timeout-limit	Parameter type: <Aaa::RadiusTimeout> Format: - radius timeout - unit: sec - range: [1...60]	<i>optional parameter with default value: 3</i> time in sec between retransmission to RADIUS server
[no] admin-down	Parameter type: boolean	<i>optional parameter</i> administrative state down
[no] dead-interval	Parameter type: <Aaa::RadiusDeadInterval> Format: - radius dead interval - unit: sec - range: [0...3600]	<i>optional parameter with default value: 600</i> no of sec before setting oper state to unknown from down

16.17 Security RADIUS Accounting Server Configuration Command

Command Description

This command allows the operator to configure the RADIUS accounting servers. The conceptual table lists the RADIUS accounting servers with their configurable parameters. If an entry (server) must be deleted, it must not be associated with any RADIUS policy. If an entry is associated with a policy, the deletion is not allowed.

Note: the products from the ISAM 7362, 7363 and 7367 family support only vrf-index=0.

User Level

The command can be accessed by operators with aaa privileges, and executed by operators with aaa privileges.

Command Syntax

The command has the following syntax:

```
> configure system security radius ( no acc-server (name) router-instance <Ihub::Router> ) | ( acc-server (name)
router-instance <Ihub::Router> ip-address <Aaa::InetAddress> [ no port | port <Aaa::InetPortNumber> ] secret
<Security::Password3> [ no retry-limit | retry-limit <Aaa::RadiusRetryLimit> ] [ no timeout-limit | timeout-limit
<Aaa::RadiusTimeout> ] [ [ no ] admin-down ] [ no dead-interval | dead-interval <Aaa::RadiusDeadInterval> ] )
```

Command Parameters

Table 16.17-1 "Security RADIUS Accounting Server Configuration Command" Resource Parameters

Resource Identifier	Type	Description
(name)	Format: - name of the RADIUS accounting server - length: 1<=x<=64	name of the RADIUS accounting server
router-instance	Parameter type: <Ihub::Router> Format: (base <Ihub::Router>) Possible values: - base : base router Field type <Ihub::Router> - vprn service-id - range: [1...2147483647]	router to which the RADIUS Acc Server belongs

Table 16.17-2 "Security RADIUS Accounting Server Configuration Command" Command Parameters

Parameter	Type	Description
ip-address	Parameter type: <Aaa::InetAddress> Format:	mandatory parameter IP address of RADIUS

16 Security Configuration Commands

Parameter	Type	Description
	- IPv4-address	accounting server
[no] port	Parameter type: <Aaa::InetPortNumber> Format: - the port number that is used to communicate with an AAA server - range: [0...65535]	<i>optional parameter with default value: 1813</i> UDP port to which RADIUS accounting messages be sent
secret	Parameter type: <Security::Password3> Format: (prompt plain : <Security::PlainPassword3> encrypted : <Security::EncryptedPasswordx>) Possible values: - prompt : prompts the operator for a password - plain : the password in plain text - encrypted : the encrypted password Field type <Security::PlainPassword3> - password string hidden from users - length: 6<=x<=64 Field type <Security::EncryptedPasswordx> - password string exposed to users - length: 8<=x<=64	<i>mandatory parameter</i> secret string used between RADIUS server and client
[no] retry-limit	Parameter type: <Aaa::RadiusRetryLimit> Format: - radius retry limit - range: [0...100]	<i>optional parameter with default value: 10</i> no of times RADIUS server be tried before giving up
[no] timeout-limit	Parameter type: <Aaa::RadiusTimeout> Format: - radius timeout - unit: sec - range: [1...60]	<i>optional parameter with default value: 15</i> time in sec between retransmission to RADIUS server
[no] admin-down	Parameter type: boolean	<i>optional parameter</i> administrative state down
[no] dead-interval	Parameter type: <Aaa::RadiusDeadInterval> Format: - radius dead interval - unit: sec - range: [0...3600]	<i>optional parameter with default value: 600</i> no of sec before setting oper state to unknown from down

16.18 Security RADIUS Dynamic Authorization Client Configuration Command

Command Description

This command allows the operator to configure the RADIUS Dynamic Authorization Clients. The conceptual table lists the RADIUS Dynamic Authorization Clients with their configurable parameters.

Note: the products from the ISAM 7362, 7363 and 7367 family support only vrf-index=0.

User Level

The command can be accessed by operators with aaa privileges, and executed by operators with aaa privileges.

Command Syntax

The command has the following syntax:

```
> configure system security radius ( no dyn-auth-client (name) router-instance <Ihub::Router> ) | ( dyn-auth-client
(name) router-instance <Ihub::Router> ip-address <Aaa::InetAddress> secret <Security::Password3> [ [ no ]
admin-down ] )
```

Command Parameters

Table 16.18-1 "Security RADIUS Dynamic Authorization Client Configuration Command" Resource Parameters

Resource Identifier	Type	Description
(name)	Format: - name of dynamic auth client name - length: 1<=x<=64	name of the RADIUS Dynamic Authorization client
router-instance	Parameter type: <Ihub::Router> Format: (base <Ihub::Router>) Possible values: - base : base router Field type <Ihub::Router> - vprn service-id - range: [1...2147483647]	router to which the RADIUS Dyn Auth Client belongs

Table 16.18-2 "Security RADIUS Dynamic Authorization Client Configuration Command" Command Parameters

Parameter	Type	Description
ip-address	Parameter type: <Aaa::InetAddress> Format: - IPv4-address	<i>mandatory parameter</i> IP address of RADIUS authentication server
secret	Parameter type: <Security::Password3>	<i>mandatory parameter</i>

16 Security Configuration Commands

Parameter	Type	Description
	Format: (prompt plain : <Security::PlainPassword3> encrypted : <Security::EncryptedPasswordx>) Possible values: - prompt : prompts the operator for a password - plain : the password in plain text - encrypted : the encrypted password Field type <Security::PlainPassword3> - password string hidden from users - length: 6<=x<=64 Field type <Security::EncryptedPasswordx> - password string exposed to users - length: 8<=x<=64	secret string used between RADIUS server and client
[no] admin-down	Parameter type: boolean	<i>optional parameter</i> administrative state down

16.19 Security RADIUS Policy Configuration

Command

Command Description

This command allows the operator to configure RADIUS policies. The conceptual table lists the RADIUS policies with the parameters that apply globally for each RADIUS policy. An entry in this table (policy) can be deleted only if it is not associated with any of the domains. If this entry is deleted, the corresponding entry in the RADIUS server is also deleted.

User Level

The command can be accessed by operators with aaa privileges, and executed by operators with aaa privileges.

Command Syntax

The command has the following syntax:

```
> configure system security radius ( no policy (name) ) | ( policy (name) nas-id <Aaa::NasId> nas-ip-address
<Aaa::InetAddress> [ [ no ] keep-domain-name ] [ [ no ] disable-accnt-msg ] [ no acc-interval | acc-interval
<Aaa::AccInt> ] [ [ no ] disable-eap ] )
```

Command Parameters

Table 16.19-1 "Security RADIUS Policy Configuration Command" Resource Parameters

Resource Identifier	Type	Description
(name)	Format: - name of the radius policy - length: 1<=x<=64	name of the RADIUS policy

Table 16.19-2 "Security RADIUS Policy Configuration Command" Command Parameters

Parameter	Type	Description
nas-id	Parameter type: <Aaa::NasId> Format: - a binary string of min 0 and max 64 - length: x<=64	<i>mandatory parameter</i> NAS-Identifier used in messages towards Radius servers
nas-ip-address	Parameter type: <Aaa::InetAddress> Format: - IPv4-address	<i>mandatory parameter</i> NAS-IP-Address used in messages towards Radius servers
[no] keep-domain-name	Parameter type: boolean	<i>optional parameter</i> don't strip domain name when sending to RADIUS server
[no] disable-accnt-msg	Parameter type: boolean	<i>optional parameter</i> disable
[no] acc-interval	Parameter type: <Aaa::AccInt> Format: - radius accnt interval	<i>optional parameter with default value: 0</i> Interim Accounting Interval in

16 Security Configuration Commands

Parameter	Type	Description
	- unit: sec - range: [0,60...2147483647]	seconds
[no] disable-eap	Parameter type: boolean	<i>optional parameter</i> disable

16.20 Security RADIUS Server Configuration

Command

Command Description

This command allows the operator to configure RADIUS servers. The conceptual table lists the set of RADIUS servers with the parameters of each set. The servers that are placed in a set using this table must first be defined in the RADIUS Authenticaion and Accounting server configuration commands. The value returned by the RADIUS server is used by the management station as the value for the index when a new entry in this table is created.

It is always mandatory to configure acc-server along with acc-router-inst and auth-server with auth-router-inst, otherwise the configuration will not succeed.

User Level

The command can be accessed by operators with aaa privileges, and executed by operators with aaa privileges.

Command Syntax

The command has the following syntax:

```
> configure system security radius policy (name) ( no servers (index) ) | ( servers (index) auth-server
<Aaa::RadAuthServer> auth-router-inst <Ihub::Router> [ no acc-server | acc-server <Aaa::RadAccServer> ] [ no
acc-router-inst | acc-router-inst <Ihub::IgnoredRouter> ] priority <Aaa::Priority> )
```

Command Parameters

Table 16.20-1 "Security RADIUS Server Configuration Command" Resource Parameters

Resource Identifier	Type	Description
(name)	Format: - name of the radius policy - length: 1<=x<=64	name of the RADIUS policy
(index)	Format: - unique nbr identifying a set within a RADIUS profile. - range: [1...2]	index of RADIUS profile

Table 16.20-2 "Security RADIUS Server Configuration Command" Command Parameters

Parameter	Type	Description
auth-server	Parameter type: <Aaa::RadAuthServer> Format: name : <Aaa::RadAuthServerName> Possible values: - name : use a radius server for authentication Field type <Aaa::RadAuthServerName> - name of the RADIUS auth server - length: 1<=x<=64	mandatory parameter the radius authentication server
auth-router-inst	Parameter type: <Ihub::Router>	mandatory parameter

16 Security Configuration Commands

Parameter	Type	Description
	Format: (base <Ihub::Router>) Possible values: - base : base router Field type <Ihub::Router> - vprn service-id - range: [1...2147483647]	router index to which the RADIUS auth server belongs
[no] acc-server	Parameter type: <Aaa::RadAccServer> Format: (none name : <Aaa::RadAccServerName>) Possible values: - none : no radius server for accounting - name : use a radius server for accounting Field type <Aaa::RadAccServerName> - name of the RADIUS accounting server - length: 1<=x<=64	<i>optional parameter with default value: "none"</i> the radius accounting server, input together with acc-router-inst
[no] acc-router-inst	Parameter type: <Ihub::IgnoredRouter> Format: (base <Ihub::Router>) Possible values: - base : base router Field type <Ihub::Router> - vprn service-id - range: [1...2147483647]	<i>optional parameter with default value: "base"</i> router index to which the RADIUS accounting server belongs, input together with acc-server
priority	Parameter type: <Aaa::Priority> Format: - priority of the server set - range: [1...256]	<i>mandatory parameter</i> priority of the set of RADIUS servers

16.21 Security TACACS+ Client Configuration

Command

Command Description

This command allows to configure generic parameters for when a TACACS+ Client is used. More details can be found in the description per parameter.

User Level

The command can be accessed by operators with aaa privileges, and executed by operators with aaa privileges.

Command Syntax

The command has the following syntax:

```
> configure system security tacacs [ [ no ] auth-super-user ] [ no operator-policy | operator-policy <Aaa::TacacsPolicyName> ]
```

Command Parameters

Table 16.21-2 "Security TACACS+ Client Configuration Command" Command Parameters

Parameter	Type	Description
[no] auth-super-user	Parameter type: boolean	<i>optional parameter</i> enable superuser TACACS+ Authentication
[no] operator-policy	Parameter type: <Aaa::TacacsPolicyName> Format: (none name : <Aaa::IgnoredTacacsPolicyName>) Possible values: - none : no profile name to associate - name : enter profile name to be associated Field type <Aaa::IgnoredTacacsPolicyName> - name of the tacacs+ policy - length: 1<=x<=64	<i>optional parameter with default value: "none"</i> operator TACACS+ policy name

16.22 Security TACACS+ Authentication Server Configuration Command

Command Description

This command allows the operator to configure the TACACS+ authentication servers. The conceptual table lists the TACACS+ authentication servers with their configurable parameters. If an entry (server) must be deleted, it must not be associated with any TACACS+ policy. If an entry is associated with a policy, the deletion is not allowed.

Note: the products from the ISAM 7360, 7363 and 7367 family support only vrf-index=0.

User Level

The command can be accessed by operators with aaa privileges, and executed by operators with aaa privileges.

Command Syntax

The command has the following syntax:

```
> configure system security tacacs ( no authen-server (name) router-instance <Ihub::baseRouter> ) | ( authen-server (name) router-instance <Ihub::baseRouter> ip-address <Aaa::InetAddress> [ no port | port <Aaa::InetPortNumber> ] secret <Security::Password3> [ no timeout-limit | timeout-limit <Aaa::TacacsTimeout> ] [ [ no ] admin-down ] [ no dead-interval | dead-interval <Aaa::TacacsDeadInterval> ] )
```

Command Parameters

Table 16.22-1 "Security TACACS+ Authentication Server Configuration Command" Resource Parameters

Resource Identifier	Type	Description
(name)	Format: - name of the TACACS+ authentication server - length: 1<=x<=64	name of TACACS+ authentication server
router-instance	Parameter type: <Ihub::baseRouter> Format: base Possible values: - base : base router	router to which this auth server belongs

Table 16.22-2 "Security TACACS+ Authentication Server Configuration Command" Command Parameters

Parameter	Type	Description
ip-address	Parameter type: <Aaa::InetAddress> Format: - IPv4-address	mandatory parameter IP address of TACACS+ authentication server
[no] port	Parameter type: <Aaa::InetPortNumber> Format:	optional parameter with default value: 49

Parameter	Type	Description
	- the port number that is used to communicate with an AAA server - range: [0...65535]	TCP port for TACACS+ authentication
secret	Parameter type: <Security::Password3> Format: (prompt plain : <Security::PlainPassword3> encrypted : <Security::EncryptedPasswordx>) Possible values: - prompt : prompts the operator for a password - plain : the password in plain text - encrypted : the encrypted password Field type <Security::PlainPassword3> - password string hidden from users - length: 6<=x<=64 Field type <Security::EncryptedPasswordx> - password string exposed to users - length: 8<=x<=64	<i>mandatory parameter</i> secret string used between TACACS+ server and client
[no] timeout-limit	Parameter type: <Aaa::TacacsTimeout> Format: - tacacs timeout - range: [1...60]	<i>optional parameter with default value: 5</i> time in sec between retransmission to TACACS+ server
[no] admin-down	Parameter type: boolean	<i>optional parameter</i> administrative state down
[no] dead-interval	Parameter type: <Aaa::TacacsDeadInterval> Format: - tacacs dead interval - range: [0...3600]	<i>optional parameter with default value: 600</i> no of sec before setting oper state to unknown from down

16.23 Security TACACS+ Authorization Server Configuration Command

Command Description

This command allows the operator to configure the TACACS+ authorization servers. The conceptual table lists the TACACS+ authorization servers with their configurable parameters. If an entry (server) must be deleted, it must not be associated with any TACACS+ policy. If an entry is associated with a policy, the deletion is not allowed.

Note: the products from the ISAM 7360, 7363 and 7367 family support only vrf-index=0.

User Level

The command can be accessed by operators with aaa privileges, and executed by operators with aaa privileges.

Command Syntax

The command has the following syntax:

```
> configure system security tacacs ( no author-server (name) router-instance <Ihub::baseRouter> ) | ( author-server (name) router-instance <Ihub::baseRouter> ip-address <Aaa::InetAddress> [ no port | port <Aaa::InetPortNumber> ] secret <Security::Password3> [ no timeout-limit | timeout-limit <Aaa::TacacsTimeout> ] [ [ no ] admin-down ] [ no dead-interval | dead-interval <Aaa::TacacsDeadInterval> ] )
```

Command Parameters

Table 16.23-1 "Security TACACS+ Authorization Server Configuration Command" Resource Parameters

Resource Identifier	Type	Description
(name)	Format: - name of the TACACS+ authorization server - length: 1<=x<=64	name of TACACS+ authorization server
router-instance	Parameter type: <Ihub::baseRouter> Format: base Possible values: - base : base router	router to which this auth server belongs

Table 16.23-2 "Security TACACS+ Authorization Server Configuration Command" Command Parameters

Parameter	Type	Description
ip-address	Parameter type: <Aaa::InetAddress> Format: - IPv4-address	mandatory parameter IP address of TACACS+ authorization server
[no] port	Parameter type: <Aaa::InetPortNumber> Format: - the port number that is used to communicate with an AAA	optional parameter with default value: 49 TCP port for TACACS+

Parameter	Type	Description
	server - range: [0...65535]	authorization
secret	Parameter type: <Security::Password3> Format: (prompt plain : <Security::PlainPassword3> encrypted : <Security::EncryptedPasswordx>) Possible values: - prompt : prompts the operator for a password - plain : the password in plain text - encrypted : the encrypted password Field type <Security::PlainPassword3> - password string hidden from users - length: 6<=x<=64 Field type <Security::EncryptedPasswordx> - password string exposed to users - length: 8<=x<=64	<i>mandatory parameter</i> secret string used between TACACS+ server and client
[no] timeout-limit	Parameter type: <Aaa::TacacsTimeout> Format: - tacacs timeout - range: [1...60]	<i>optional parameter with default value: 5</i> time in sec between retransmission to TACACS+ server
[no] admin-down	Parameter type: boolean	<i>optional parameter</i> administrative state down
[no] dead-interval	Parameter type: <Aaa::TacacsDeadInterval> Format: - tacacs dead interval - range: [0...3600]	<i>optional parameter with default value: 600</i> no of sec before setting oper state to unknown from down

16.24 Security TACACS+ Accounting Server Configuration Command

Command Description

This command allows the operator to configure the TACACS+ accounting servers. The conceptual table lists the TACACS+ accounting servers with their configurable parameters. If an entry (server) must be deleted, it must not be associated with any TACACS+ policy. If an entry is associated with a policy, the deletion is not allowed.

Note: the products from the ISAM 7360,7363 and 7367 family support only vrf-index=0.

User Level

The command can be accessed by operators with aaa privileges, and executed by operators with aaa privileges.

Command Syntax

The command has the following syntax:

```
> configure system security tacacs ( no acc-server (name) router-instance <Ihub::baseRouter> ) | ( acc-server (name) router-instance <Ihub::baseRouter> ip-address <Aaa::InetAddress> [ no port | port <Aaa::InetPortNumber> ] secret <Security::Password3> [ no timeout-limit | timeout-limit <Aaa::TacacsTimeout> ] [ [ no ] admin-down ] [ no dead-interval | dead-interval <Aaa::TacacsDeadInterval> ] )
```

Command Parameters

Table 16.24-1 "Security TACACS+ Accounting Server Configuration Command" Resource Parameters

Resource Identifier	Type	Description
(name)	Format: - name of the TACACS+ accounting server - length: 1<=x<=64	name of the TACACS+ accounting server
router-instance	Parameter type: <Ihub::baseRouter> Format: base Possible values: - base : base router	router to which the TACACS+ Acc Server belongs

Table 16.24-2 "Security TACACS+ Accounting Server Configuration Command" Command Parameters

Parameter	Type	Description
ip-address	Parameter type: <Aaa::InetAddress> Format: - IPv4-address	mandatory parameter IP address of TACACS+ accounting server
[no] port	Parameter type: <Aaa::InetPortNumber> Format: - the port number that is used to communicate with an AAA	optional parameter with default value: 49 TCP port for TACACS+

Parameter	Type	Description
	server - range: [0...65535]	accounting
secret	Parameter type: <Security::Password3> Format: (prompt plain : <Security::PlainPassword3> encrypted : <Security::EncryptedPasswordx>) Possible values: - prompt : prompts the operator for a password - plain : the password in plain text - encrypted : the encrypted password Field type <Security::PlainPassword3> - password string hidden from users - length: 6<=x<=64 Field type <Security::EncryptedPasswordx> - password string exposed to users - length: 8<=x<=64	<i>mandatory parameter</i> secret string used between TACACS+ server and client
[no] timeout-limit	Parameter type: <Aaa::TacacsTimeout> Format: - tacacs timeout - range: [1...60]	<i>optional parameter with default value: 5</i> time in sec between retransmission to TACACS+ server
[no] admin-down	Parameter type: boolean	<i>optional parameter</i> administrative state down
[no] dead-interval	Parameter type: <Aaa::TacacsDeadInterval> Format: - tacacs dead interval - range: [0...3600]	<i>optional parameter with default value: 600</i> no of sec before setting oper state to unknown from down

16.25 Security TACACS+ Policy Configuration

Command

Command Description

This command allows the operator to configure TACACS+ policies. The conceptual table lists the TACACS+ policies with the parameters that apply globally for each TACACS+ policy. An entry in this table (policy) can be deleted only if it is not associated with any of the domains. If this entry is deleted, the corresponding entry in the TACACS+ server is also deleted.

User Level

The command can be accessed by operators with aaa privileges, and executed by operators with aaa privileges.

Command Syntax

The command has the following syntax:

> configure system security tacacs (no policy (name)) | (policy (name))

Command Parameters

Table 16.25-1 "Security TACACS+ Policy Configuration Command" Resource Parameters

Resource Identifier	Type	Description
(name)	Format: - name of the tacacs+ policy - length: 1<=x<=64	name of the Tacacs+ policy

16.26 Security Tacacs+ Server Configuration

Command

Command Description

This command allows the operator to configure Tacacs+ servers. The conceptual table lists the set of Tacacs+ servers with the parameters of each set. The servers that are placed in a set using this table must first be defined in the Tacacs+ Authenticaion and Accounting server configuration commands. The value returned by the Tacacs+ server is used by the management station as the value for the index when a new entry in this table is created.

It is always mandatory to configure acc-server along with acc-router-inst and auth-server with auth-router-inst, otherwise the configuration will not succeed.

User Level

The command can be accessed by operators with aaa privileges, and executed by operators with aaa privileges.

Command Syntax

The command has the following syntax:

```
> configure system security tacacs policy (name) ( no servers (index) ) | ( servers (index) [ no authen-server |
authen-server <Aaa::TacAuthenServer> ] [ no author-server | author-server <Aaa::TacAuthorServer> ] [ no
acc-server | acc-server <Aaa::TacAccServer> ] priority <Aaa::Priority> )
```

Command Parameters

Table 16.26-1 "Security Tacacs+ Server Configuration Command" Resource Parameters

Resource Identifier	Type	Description
(name)	Format: - name of the tacacs+ policy - length: 1<=x<=64	name of the Tacacs+ policy
(index)	Format: - unique nbr identifying a set within a TACACS+ profile. - range: [1...2]	index of Tacacs+ profile

Table 16.26-2 "Security Tacacs+ Server Configuration Command" Command Parameters

Parameter	Type	Description
[no] authen-server	Parameter type: <Aaa::TacAuthenServer> Format: (none name : <Aaa::TacAuthenServerName>) Possible values: - none : no tacacs+ server for authentication - name : use a tacacs+ server for authentication Field type <Aaa::TacAuthenServerName> - name of the TACACS+ authentication server	optional parameter with default value: "none" the Tacacs+ authentication server

16 Security Configuration Commands

Parameter	Type	Description
[no] author-server	- length: 1<=x<=64 Parameter type: <Aaa::TacAuthorServer> Format: (none name : <Aaa::TacAuthorServerName>) Possible values: - none : no tacacs+ server for authorization - name : use a tacacs+ server for authorization Field type <Aaa::TacAuthorServerName> - name of the TACACS+ authorization server - length: 1<=x<=64	<i>optional parameter with default value: "none"</i> the Tacacs+ authorization server
[no] acc-server	Parameter type: <Aaa::TacAccServer> Format: (none name : <Aaa::TacAccServerName>) Possible values: - none : no TACACS+ server for accounting - name : use a TACACS+ server for accounting Field type <Aaa::TacAccServerName> - name of the TACACS+ accounting server - length: 1<=x<=64	<i>optional parameter with default value: "none"</i> the tacacs+ accounting server
priority	Parameter type: <Aaa::Priority> Format: - priority of the server set - range: [1...256]	<i>mandatory parameter</i> priority of the set of Tacacs+ servers

16.27 Security Domain Configuration Command

Command Description

This command allows the operator to configure the domain.

User Level

The command can be accessed by operators with aaa privileges, and executed by operators with aaa privileges.

Command Syntax

The command has the following syntax:

```
> configure system security ( no domain (name) ) | ( domain (name) [ no vlan-id | vlan-id
<Vlan::VlanIndexOrZero> ] [ no primary-dns | primary-dns <Aaa::InetAddress> ] [ no second-dns | second-dns
<Aaa::InetAddress> ] [ no primary-nbns | primary-nbns <Aaa::InetAddress> ] [ no second-nbns | second-nbns
<Aaa::InetAddress> ] [ no sess-timeout | sess-timeout <Aaa::DomainSessionTimeout> ] [ no qos-policy |
qos-policy <Aaa::QosProfileName> ] authenticator <Aaa::IHUBAuthenticator> [ [ no ] admin-down ] )
```

Command Parameters

Table 16.27-1 "Security Domain Configuration Command" Resource Parameters

Resource Identifier	Type	Description
(name)	Format: - name of the domain - length: 1<=x<=64	name of the domain

Table 16.27-2 "Security Domain Configuration Command" Command Parameters

Parameter	Type	Description
[no] vlan-id	Parameter type: <Vlan::VlanIndexOrZero> Format: - vlan id - range: [0...4092]	<i>optional parameter with default value: 0</i> a vlan id
[no] primary-dns	Parameter type: <Aaa::InetAddress> Format: - IPv4-address	<i>optional parameter with default value: "0.0.0.0"</i> IP address of primary DNS server
[no] second-dns	Parameter type: <Aaa::InetAddress> Format: - IPv4-address	<i>optional parameter with default value: "0.0.0.0"</i> IP address of secondary DNS server
[no] primary-nbns	Parameter type: <Aaa::InetAddress> Format: - IPv4-address	<i>optional parameter with default value: "0.0.0.0"</i> IP address of primary NBNS server
[no] second-nbns	Parameter type: <Aaa::InetAddress> Format: - IPv4-address	<i>optional parameter with default value: "0.0.0.0"</i> IP address of secondary NBNS server

16 Security Configuration Commands

Parameter	Type	Description
[no] sess-timeout	Parameter type: <Aaa::DomainSessionTimeout> Format: - maximum lifetime of a session - unit: sec - range: [0,600...2147483647]	<i>optional parameter with default value: 0</i> maximum lifetime of a session
[no] qos-policy	Parameter type: <Aaa::QosProfileName> Format: (none name : <Aaa::IgnoredQosProfileName>) Possible values: - none : no profile name to associate - name : enter profile name to be associated Field type <Aaa::IgnoredQosProfileName> - name of the QoS profile - length: 1<=x<=64	<i>optional parameter with default value: "none"</i> name of the QoS policy to be applied to this domain
authenticator	Parameter type: <Aaa::IHUBAuthenticator> Format: radius : <Aaa::RadPolicyName> Possible values: - radius : authenticator type is RADIUS Field type <Aaa::RadPolicyName> - name of the radius policy - length: 1<=x<=64	<i>mandatory parameter</i> type of authenticator
[no] admin-down	Parameter type: boolean	<i>optional parameter</i> administrative state down

16.28 Security Connection Profile Configuration Command

Command Description

This command allows the operator to configure the connection profile parameters.

User Level

The command can be accessed by operators with aaa privileges, and executed by operators with aaa privileges.

Command Syntax

The command has the following syntax:

```
> configure system security ( no conn-profile (name) ) | ( conn-profile (name) version <SignedInteger> [ [ no ] reject-no-domain ] [ [ no ] reject-inv-domain ] domain-name <Aaa::DomainName> )
```

Command Parameters

Table 16.28-1 "Security Connection Profile Configuration Command" Resource Parameters

Resource Identifier	Type	Description
(name)	Format: - a profile name - range: [a-zA-Z0-9-_.] - length: 1<=x<=32	name of connection profile

Table 16.28-2 "Security Connection Profile Configuration Command" Command Parameters

Parameter	Type	Description
version	Parameter type: <SignedInteger> Format: - a signed integer	<i>mandatory parameter</i> version number to be associated to the Profile
[no] reject-no-domain	Parameter type: boolean	<i>optional parameter</i> reject user session auth if no domain
[no] reject-inv-domain	Parameter type: boolean	<i>optional parameter</i> reject user session auth if invalid domain
domain-name	Parameter type: <Aaa::DomainName> Format: - name of the domain - length: 1<=x<=64	<i>mandatory parameter</i> name of the domain

16.29 Security Connection Policy Configuration Command

Command Description

This command allows the operator to configure a connection policy associated with the specified policy. The operator should specify the index that indicates which connection policy to apply and the profile-index, which provides the connection profile associated with this policy.

User Level

The command can be accessed by operators with aaa privileges, and executed by operators with aaa privileges.

Command Syntax

The command has the following syntax:

```
> configure system security ( no conn-policy ) | ( conn-policy conn-profile-name <AsamProfileName> )
```

Command Parameters

Table 16.29-2 "Security Connection Policy Configuration Command" Command Parameters

Parameter	Type	Description
conn-profile-name	Parameter type: <AsamProfileName> Format: - a profile name - range: [a-zA-Z0-9-_.] - length: 1<=x<=32	<i>mandatory parameter</i> connection profile associated with this policy

16.30 Security 802.1x PAE System Configuration Command

Command Description

This command allows the operator to configure the administrative enable and disable state for port access control and local authentication in a system.

User Level

The command can be accessed by operators with aaa privileges, and executed by operators with aaa privileges.

Command Syntax

The command has the following syntax:

```
> configure system security pae [ [ no ] port-access ]
```

Command Parameters

Table 16.30-2 "Security 802.1x PAE System Configuration Command" Command Parameters

Parameter	Type	Description
[no] port-access	Parameter type: boolean	<i>optional parameter</i> enable port access control

16.31 Security 802.1x Port Authentication Configuration Command

Command Description

This command allows the operator to configure security 802.1x port authentication.

This command is valid for user ports. If the user port resides on a board that does not support user authentication, this command will fail.

User Level

The command can be accessed by operators with aaa privileges, and executed by operators with aaa privileges.

Command Syntax

The command has the following syntax:

```
> configure system security pae authenticator (port) [ no controlled-port | controlled-port
<Aaa::PaeControlledPortControl> ] [ no quiet-period | quiet-period <Aaa::paeQuitTime> ] [ no tx-period | tx-period
<Aaa::paeTime> ] [ no supp-timeout | supp-timeout <Aaa::paeTime> ] [ no server-timeout | server-timeout
<Aaa::paeTime> ] [ no max-req | max-req <Aaa::paeMaxReq> ] [ [ no ] re-auth-enabled ] [ no re-auth-period |
re-auth-period <Aaa::paeReauthPeriod> ]
```

Command Parameters

Table 16.31-1 "Security 802.1x Port Authentication Configuration Command" Resource Parameters

Resource Identifier	Type	Description
(port)	Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::VpId> : <Eqpt::VcId> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> / <Eqpt::OntPortId> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / voip <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / vuni <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::LLId> ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / <Eqpt::Ng2OntSlotId> / <Eqpt::Ng2OntPortId> ng2 : <Eqpt::ChannelGroupId> /	identification of the port or virtual channel

Resource Identifier	Type	Description
	<Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / vuni) Possible values: - ng2 : ngpon2 style identification Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number Field type <Eqpt::VpiId> - atm VPI Field type <Eqpt::VciId> - atm VCI Field type <Eqpt::ChannelGroupId> - the channel group identifier Field type <Eqpt::SubChannelGroupId> - the subchannel group identifier Field type <Eqpt::PonId> - the PON identifier Field type <Eqpt::OntId> - the ONT identifier Field type <Eqpt::Ng2OntId> - the NG2 ONT identifier Possible values: - voip : virtual uni identifier obsolete alternative replaced by vuni - vuni : virtual uni identifier Possible values: - vuni : virtual NGPON2 uni identifier Field type <Eqpt::OntSlotId> - the ONT SLOT identifier Field type <Eqpt::OntPortId> - the ONT PORT identifier Field type <Eqpt::Ng2OntSlotId> - the NGPON2 ONT SLOT identifier Field type <Eqpt::Ng2OntPortId> - the NGPON2 ONT PORT identifier Field type <Eqpt::LLId> - the LLID identifier, range 1 for EPON, range 1-8 for DPOE	

Table 16.31-2 "Security 802.1x Port Authentication Configuration Command" Command Parameters

Parameter	Type	Description
[no] controlled-port	Parameter type: <Aaa::PaeControlledPortControl> Format: (force-unauthorized auto force-authorized) Possible values: - force-unauthorized : force unauthorized control - auto : automatic control - force-authorized : force authorized control	<i>optional parameter with default value: "auto"</i> current value of the controlled Port
[no] quiet-period	Parameter type: <Aaa::paeQuietTime> Format: - quietPeriod	<i>optional parameter with default value: 60</i> quietPeriod constant currently

16 Security Configuration Commands

Parameter	Type	Description
	- unit: sec - range: [0...65535]	used, value in seconds
[no] tx-period	Parameter type: <Aaa::paeTime> Format: - authentication time - unit: sec - range: [1...65535]	<i>optional parameter with default value: 30</i> txPeriod constant currently used, value in seconds
[no] supp-timeout	Parameter type: <Aaa::paeTime> Format: - authentication time - unit: sec - range: [1...65535]	<i>optional parameter with default value: 30</i> suppTimeout constant currently used, value in seconds
[no] server-timeout	Parameter type: <Aaa::paeTime> Format: - authentication time - unit: sec - range: [1...65535]	<i>optional parameter with default value: 30</i> serverTimeout constant currently used, value in seconds
[no] max-req	Parameter type: <Aaa::paeMaxReq> Format: - max number of requests - range: [1...10]	<i>optional parameter with default value: 2</i> maxReq constant currently used
[no] re-auth-enabled	Parameter type: boolean	<i>optional parameter</i> enable re-authentication
[no] re-auth-period	Parameter type: <Aaa::paeReauthPeriod> Format: - re-authentication Period - unit: sec - range: [1...65535]	<i>optional parameter with default value: 3600</i> the actual re-authentication period, value in seconds

16.32 Security 802.1x Extension, Port Authentication Configuration Command

Command Description

This command allows the operator to configure the security 802.1x extension port authentication.

User Level

The command can be accessed by operators with aaa privileges, and executed by operators with aaa privileges.

Command Syntax

The command has the following syntax:

```
> configure system security pae ext-authenticator (port) [ [ no ] authentication ] [ [ no ] init-authreq-off ] [ [ no ] handshake ] [ no handshake-period | handshake-period <Aaa::PortHandShakePeriod> ] [ [ no ] mac-auth ] [ [ no ] mab-auth ] [ [ no ] dyn-vlan-assign ]
```

Command Parameters

Table 16.32-1 "Security 802.1x Extension, Port Authentication Configuration Command" Resource Parameters

Resource Identifier	Type	Description
(port)	Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::VpiId> : <Eqpt::VciId> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> / <Eqpt::OntPortId> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / voip <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / vuni <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::LLId> ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / <Eqpt::Ng2OntSlotId> / <Eqpt::Ng2OntPortId> ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / vuni) Possible values: - ng2 : ngpon2 style identification Field type <Eqpt::RackId> - the rack number	identification of the port or virtual channel

Resource Identifier	Type	Description
	Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number Field type <Eqpt::VpId> - atm VPI Field type <Eqpt::VciId> - atm VCI Field type <Eqpt::ChannelGroupId> - the channel group identifier Field type <Eqpt::SubChannelGroupId> - the subchannel group identifier Field type <Eqpt::PonId> - the PON identifier Field type <Eqpt::OntId> - the ONT identifier Field type <Eqpt::Ng2OntId> - the NG2 ONT identifier Possible values: - voip : virtual uni identifier obsolete alternative replaced by vuni - vuni : virtual uni identifier Possible values: - vuni : virtual NGPON2 uni identifier Field type <Eqpt::OntSlotId> - the ONT SLOT identifier Field type <Eqpt::OntPortId> - the ONT PORT identifier Field type <Eqpt::Ng2OntSlotId> - the NGPON2 ONT SLOT identifier Field type <Eqpt::Ng2OntPortId> - the NGPON2 ONT PORT identifier Field type <Eqpt::LLId> - the LLID identifier, range 1 for EPON, range 1-8 for DPOE	

Table 16.32-2 "Security 802.1x Extension, Port Authentication Configuration Command" Command Parameters

Parameter	Type	Description
[no] authentication	Parameter type: boolean	<i>optional parameter</i> enable 802.1x authentication
[no] init-authreq-off	Parameter type: boolean	<i>optional parameter</i> disable initiate authentication request to supplicant
[no] handshake	Parameter type: boolean	<i>optional parameter</i> enable handshake for this port
[no] handshake-period	Parameter type: <Aaa::PortHandShakePeriod> Format: - handshake time interval - unit: sec - range: [5...90]	<i>optional parameter with default value: 15</i> specify the handshake time interval, value in seconds
[no] mac-auth	Parameter type: boolean	<i>optional parameter</i> enable 802.1x mac authentication
[no] mab-auth	Parameter type: boolean	<i>optional parameter</i> enable 802.1x mac authentication bypass

Parameter	Type	Description
[no] dyn-vlan-assign	Parameter type: boolean	<i>optional parameter</i> enable 802.1x dynamic vlan assignment

16.33 Security 802.1x Port Configuration Command

Command Description

This command allows the operator to configure the security 802.1x port.

User Level

The command can be accessed by operators with aaa privileges, and executed by operators with aaa privileges.

Command Syntax

The command has the following syntax:

```
> configure system security pae port (port) [ [ no ] initialize ]
```

Command Parameters

Table 16.33-1 "Security 802.1x Port Configuration Command" Resource Parameters

Resource Identifier	Type	Description
(port)	Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::VpiId> : <Eqpt::VciId> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> / <Eqpt::OntPortId> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / voip <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / vuni <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::LLId> ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / <Eqpt::Ng2OntSlotId> / <Eqpt::Ng2OntPortId> ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / vuni) Possible values: - ng2 : ngpon2 style identification Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number	identification of the port or virtual channel

Resource Identifier	Type	Description
	Field type <Eqpt::Vpild> - atm VPI Field type <Eqpt::VciId> - atm VCI Field type <Eqpt::ChannelGroupId> - the channel group identifier Field type <Eqpt::SubChannelGroupId> - the subchannel group identifier Field type <Eqpt::PonId> - the PON identifier Field type <Eqpt::OntId> - the ONT identifier Field type <Eqpt::Ng2OntId> - the NG2 ONT identifier Possible values: - voip : virtual uni identifier obsolete alternative replaced by vuni - vuni : virtual uni identifier Possible values: - vuni : virtual NGPON2 uni identifier Field type <Eqpt::OntSlotId> - the ONT SLOT identifier Field type <Eqpt::OntPortId> - the ONT PORT identifier Field type <Eqpt::Ng2OntSlotId> - the NGPON2 ONT SLOT identifier Field type <Eqpt::Ng2OntPortId> - the NGPON2 ONT PORT identifier Field type <Eqpt::LLId> - the LLID identifier, range 1 for EPON, range 1-8 for DPOE	

Table 16.33-2 "Security 802.1x Port Configuration Command" Command Parameters

Parameter	Type	Description
[no] initialize	Parameter type: boolean	<i>optional parameter</i> initialize this port

16.34 Security Password Policy Configuration

Command

Command Description

This command allows the operator to configure the password policy.

There is no separate command to change a password. An operator must change the password in the operator's operator node by the local admin.

User Level

The command can be accessed by operators with security,all privileges, and executed by operators with security privileges.

Command Syntax

The command has the following syntax:

```
> configure system security password [ min-length <Sec::PwdLength> ] [ min-num-numeric-char
<Sec::PwdNumChars> ] [ min-num-special-char <Sec::PwdSpeChars> ] [ no mixed-case | mixed-case
<Sec::MixCase> ]
```

Command Parameters

Table 16.34-2 "Security Password Policy Configuration Command" Command Parameters

Parameter	Type	Description
min-length	Parameter type: <Sec::PwdLength> Format: - the minimum length of the password - unit: characters - range: [6...20]	<i>optional parameter</i> the minimum length of the password
min-num-numeric-char	Parameter type: <Sec::PwdNumChars> Format: - minimum number of numerical characters - unit: characters - range: [0...19]	<i>optional parameter</i> minimum number of numerical characters
min-num-special-char	Parameter type: <Sec::PwdSpeChars> Format: - minimum number of special character - unit: characters - range: [1...20]	<i>optional parameter</i> minimum number of special character
[no] mixed-case	Parameter type: <Sec::MixCase> Format: (mandatory not-mandatory) Possible values:	<i>optional parameter with default value: "not-mandatory"</i> both upper and lower case characters must be present

Parameter	Type	Description
	- mandatory : both upper and lower case characters must be present - not-mandatory : both upper and lower case characters not mandatory	

16.35 File Transfer Configure Command

Command Description

This command configure file transfer states and attributes.

User Level

The command can be accessed by operators with security privileges, and executed by operators with security privileges.

Command Syntax

The command has the following syntax:

```
> configure system security filetransfer [ no protocol | protocol <SwMngt::FileTransferProtocolType> ] [ no
tftp-rollovr | tftp-rollovr <SwMngt::FileTransferRolloverType> ]
```

Command Parameters

Table 16.35-2 "File Transfer Configure Command" Command Parameters

Parameter	Type	Description
[no] protocol	Parameter type: <SwMngt::FileTransferProtocolType> Format: (tftp ftp sftp) Possible values: - tftp : the tftp protocol is selected for file transfer - ftp : the ftp protocol is selected for file transfer - sftp : the sftp protocol is selected for file transfer	<i>optional parameter with default value: "tftp"</i> the protocol that is to be used for file transfer
[no] tftp-rollovr	Parameter type: <SwMngt::FileTransferRolloverType> Format: - TFTP Block Number - range: [0...1]	<i>optional parameter with default value: 0</i> The value with which TFTP Block number rollover will happen

16.36 file Transfer server Configure Commands

Command Description

This command configures file transfer server states and attributes.

If the auth-type value is password based, then password value length needs to be 1 to 32 characters. if the auth-type value is publickey based, then key-type parameter value needs to be either dsa2048 or rsa2048.

Default value for password is applicable only for public key based authentication.

User Level

The command can be accessed by operators with security privileges, and executed by operators with security privileges.

Command Syntax

The command has the following syntax:

```
> configure system security filetransfer ( no server (serverid) ) | ( server (serverid) user-name
<SwMngt::UserName> [ no password | password <Security::Password1> ] [ no auth-type | auth-type
<SwMngt::ServerAuthType> ] [ no key-type | key-type <SwMngt::ServerKeyType> ] )
```

Command Parameters

Table 16.36-1 "file Transfer server Configure Commands" Resource Parameters

Resource Identifier	Type	Description
(serverid)	Format: - IPv4-address	(IP address) of the file transfer server

Table 16.36-2 "file Transfer server Configure Commands" Command Parameters

Parameter	Type	Description
user-name	Parameter type: <SwMngt::UserName> Format: - the username used to access the file server - length: x<=32	<i>mandatory parameter</i> the username used to access the file server
[no] password	Parameter type: <Security::Password1> Format: (prompt plain : <Security::PlainPassword1> encrypted : <Security::EncryptedPasswordx>) Possible values: - prompt : prompts the operator for a password - plain : the password in plain text - encrypted : the encrypted password Field type <Security::PlainPassword1> - the password used to access the file server - length: 1<=x<=32 Field type <Security::EncryptedPasswordx>	<i>optional parameter with default value: "plain : "</i> the password used to access the file server

16 Security Configuration Commands

Parameter	Type	Description
	- password string exposed to users - length: 8<=x<=64	
[no] auth-type	Parameter type: <SwMngt::ServerAuthType> Format: (password-based publickey-based) Possible values: - password-based : password based authentication - publickey-based : public key based authentication	<i>optional parameter with default value: "password-based"</i> sftp server authentication type
[no] key-type	Parameter type: <SwMngt::ServerKeyType> Format: (none dsa2048 rsa2048) Possible values: - none : no key - dsa2048 : dsa 2048 bit key-pair - rsa2048 : rsa 2048 bit key-pair	<i>optional parameter with default value: "none"</i> sftp server authentication key type

16.37 file Transfer server Configure Commands

Command Description

This command configures file transfer server states and attributes.

If the auth-type value is password based, then password value length needs to be 1 to 32 characters. if the auth-type value is publickey based, then key-type parameter value needs to be either dsa2048 or rsa2048.

Default value for password is applicable only for public key based authentication.

User Level

The command can be accessed by operators with security privileges, and executed by operators with security privileges.

Command Syntax

The command has the following syntax:

```
> configure system security filetransfer ( no serverv6 (serveridv6) ) | ( serverv6 (serveridv6) user-name
<SwMngt::UserName> [ no password | password <Security::Password1> ] [ no auth-type | auth-type
<SwMngt::ServerAuthType> ] [ no key-type | key-type <SwMngt::ServerKeyType> ] )
```

Command Parameters

Table 16.37-1 "file Transfer server Configure Commands" Resource Parameters

Resource Identifier	Type	Description
(serveridv6)	Format: - IPv6-address	(IPv6 address) of the file transfer server

Table 16.37-2 "file Transfer server Configure Commands" Command Parameters

Parameter	Type	Description
user-name	Parameter type: <SwMngt::UserName> Format: - the username used to access the file server - length: x<=32	<i>mandatory parameter</i> the username used to access the file server
[no] password	Parameter type: <Security::Password1> Format: (prompt plain : <Security::PlainPassword1> encrypted : <Security::EncryptedPasswordx>) Possible values: - prompt : prompts the operator for a password - plain : the password in plain text - encrypted : the encrypted password Field type <Security::PlainPassword1> - the password used to access the file server - length: 1<=x<=32 Field type <Security::EncryptedPasswordx>	<i>optional parameter with default value: "plain : "</i> the password used to access the file server

16 Security Configuration Commands

Parameter	Type	Description
	- password string exposed to users - length: 8<=x<=64	
[no] auth-type	Parameter type: <SwMngt::ServerAuthType> Format: (password-based publickey-based) Possible values: - password-based : password based authentication - publickey-based : public key based authentication	<i>optional parameter with default value: "password-based"</i> sftp server authentication type
[no] key-type	Parameter type: <SwMngt::ServerKeyType> Format: (none dsa2048 rsa2048) Possible values: - none : no key - dsa2048 : dsa 2048 bit key-pair - rsa2048 : rsa 2048 bit key-pair	<i>optional parameter with default value: "none"</i> sftp server authentication key type

16.38 PM File Upload Configure Command

Command Description

This command configures PM file upload related parameters

User Level

The command can be accessed by operators with security privileges, and executed by operators with security privileges.

Command Syntax

The command has the following syntax:

```
> configure system security pmfile ( no upload (upload-index) ) | ( upload (upload-index) pri-server-addr
<SwMngt::pmFileUploadPrimaryServerAddr> upload-path <SwMngt::pmFileUploadPath> interval-type
<SwMngt::pmFileUploadIntervalType> [ no auto-upload | auto-upload <SwMngt::pmFileAutoUpload> ] [ no
retry-num | retry-num <SwMngt::pmFileUploadRetryNum> ] [ no max-delay | max-delay
<SwMngt::pmFileUploadMaxDelay> ] [ no cdr-max-delay | cdr-max-delay
<SwMngt::pmFileUploadCDRMaxDelay> ] [ no cdr-max-timeout | cdr-max-timeout
<SwMngt::pmFileUploadCDRTimeout> ] )
```

Command Parameters

Table 16.38-1 "PM File Upload Configure Command" Resource Parameters

Resource Identifier	Type	Description
(upload-index)	Format: - the unique internal identifier of PM file upload entry (1-VOICE, 2-DSL, 3-CDR) 1) 1-VOICE / 2-DSL : To enable the VoIP / DSL performance monitoring counter reporting by means of PM file upload. The configuration of an entry in this table enables the VoIP / DSL PM counter reporting by means of PM file upload. Autonomous PM upload needs explicitly to be enabled/disabled. Manual PM file upload becomes automatically enabled when creating an entry with identifier 1-VOICE or 2-DSL. 2) 3-CDR : To enable the VoIP 5-min interval statistics counters and CDR data reporting by means of PM file upload. Autonomous CDR data PM file upload becomes automatically enabled when creating an entry with identifier 3-CDR. Manual PM file upload is not supported. - range: [1...3]	the unique internal identifier of PM file upload entry (1-VOICE, 2-DSL, 3-CDR) 1) 1-VOICE / 2-DSL : To enable the VoIP / DSL performance monitoring counter reporting by means of PM file upload. The configuration of an entry in this table enables the VoIP / DSL PM counter reporting by means of PM file upload. Autonomous PM upload needs explicitly to be enabled/disabled. Manual PM file upload becomes automatically enabled when creating an entry with identifier 1-VOICE or 2-DSL. 2) 3-CDR : To enable the VoIP 5-min interval statistics counters and CDR data reporting by means of PM file upload. Autonomous CDR data PM file upload becomes automatically

Resource Identifier	Type	Description
		enabled when creating an entry with identifier 3-CDR. Manual PM file upload is not supported.

Table 16.38-2 "PM File Upload Configure Command" Command Parameters

Parameter	Type	Description
pri-server-addr	Parameter <SwMngt::pmFileUploadPrimaryServerAddr> Format: - IPv4-address type:	<i>mandatory parameter</i> IP address of the primary SFTP file server
upload-path	Parameter type: <SwMngt::pmFileUploadPath> Format: - The path to be addressed for PM / CDR Data file upload. The directory to be specified is the sub-directory below the root directory (the first or top-most directory in a hierarchy). The name of the sub-directory is not allowed to start with '/'. It must end with a '/'. The sub-directory is a mandatory input. The system does not assume any default sub-directory name. - length: x<=127	<i>mandatory parameter</i> The path to be addressed for PM / CDR Data file upload. The directory to be specified is the sub-directory below the root directory (the first or top-most directory in a hierarchy). The name of the sub-directory is not allowed to start with '/'. It must end with a '/'. The sub-directory is a mandatory input. The system does not assume any default sub-directory name.
interval-type	Parameter type: <SwMngt::pmFileUploadIntervalType> Format: (15-min 24-hour 5-min) Possible values: - 15-min : PM counters collected based on the 15-min interval - 24-hour : PM counters collected based on the 1-day interval - 5-min : PM counters collected based on the 5-min interval	<i>mandatory parameter</i> The type of interval to be used to transfer the PM counters. In case it concerns PM file upload entry for 1-VOICE or 2-DSL, the interval-type parameter can only be configured to 15-min or 24-hour. In case it concerns PM file upload entry for 3-CDR, the interval-type parameter can only be configured to 5-min.
[no] auto-upload	Parameter type: <SwMngt::pmFileAutoUpload> Format: (enable disable) Possible values: - enable : PM file transfer auto upload enabled - disable : PM file transfer auto upload disabled	<i>optional parameter with default value: "disable"</i> Allows to configure whether the auto upload of the PM file is enabled or disabled. This parameter is only applicable to the PM file upload entry for 1-VOICE or 2-DSL.
[no] retry-num	Parameter type: <SwMngt::pmFileUploadRetryNum> Format: - In case it concerns PM file upload entry for 1-VOICE or 2-DSL : The number of PM file upload retries in case the initial PM file upload failed. All retries will be done within the same interval as the interval in which the initial PM file upload failed. The several retries will be randomly spread over this interval. In case it concerns PM file upload entry for 3-CDR : The number of CDR Data file upload retries in case the initial CDR Data file upload failed. All retries will be done within the same 5-min interval as the 5-min interval in which the initial CDR Data file upload failed. The several retries will be randomly spread over this 5-min interval. - range: [0...5]	<i>optional parameter with default value: "3"</i> In case it concerns PM file upload entry for 1-VOICE or 2-DSL : The number of PM file upload retries in case the initial PM file upload failed. All retries will be done within the same interval as the interval in which the initial PM file upload failed. The several retries will be randomly spread over this interval. In case it concerns PM file upload entry for 3-CDR : The number of CDR Data file upload

Parameter	Type	Description
		retries in case the initial CDR Data file upload failed. All retries will be done within the same 5-min interval as the 5-min interval in which the initial CDR Data file upload failed. The several retries will be randomly spread over this 5-min interval.
[no] max-delay	Parameter type: <SwMngt::pmFileUploadMaxDelay> Format: - The maximum delay period, expressed in seconds, for PM file upload after PM data file ready (maximum 120 seconds after interval expiry). The system will randomly calculate a delay time within the configured maximum delay period. This parameter is only applicable to the PM file upload entry for 1-VOICE or 2-DSL. - unit: seconds - range: [0...400]	<i>optional parameter with default value: "400"</i> The maximum delay period, expressed in seconds, for PM file upload after PM data file ready (maximum 120 seconds after interval expiry). The system will randomly calculate a delay time within the configured maximum delay period. This parameter is only applicable to the PM file upload entry for 1-VOICE or 2-DSL.
[no] cdr-max-delay	Parameter type: <SwMngt::pmFileUploadCDRMaxDelay> Format: - The maximum delay period, expressed in seconds, for CDR Data file upload after CDR data file ready. The system will randomly calculate a delay time within the configured maximum delay period. This parameter is only applicable to the PM file upload entry for 3-CDR - unit: seconds - range: [0...240]	<i>optional parameter with default value: "240"</i> The maximum delay period, expressed in seconds, for CDR Data file upload after CDR data file ready. The system will randomly calculate a delay time within the configured maximum delay period. This parameter is only applicable to the PM file upload entry for 3-CDR.
[no] cdr-max-timeout	Parameter type: <SwMngt::pmFileUploadCDRTimeout> Format: - The maximum time (expressed in hours) to store the not-uploaded files at the system disk (NT). This parameter is only applicable to the PM file upload entry for 3-CDR. - unit: hour - range: [0...72]	<i>optional parameter with default value: "24"</i> The maximum time (expressed in hours) to store the not-uploaded files at the system disk (NT). This parameter is only applicable to the PM file upload entry for 3-CDR.

16.39 5-min CDR File Upload Configure Command

Command Description

Obsolete command.

User Level

The command can be accessed by operators with security privileges, and executed by operators with security privileges.

Command Syntax

The command has the following syntax:

```
> configure system security cdr-pm-file ( no upload (upload-index) ) | ( upload (upload-index) pri-server-addr
<SwMngt::pmFileUploadPrimaryServerAddr>      upload-path      <SwMngt::pmFileUploadPath>      retry-num
<SwMngt::pmFileUploadRetryNum>                max-delay        <SwMngt::cdrFileUploadMaxDelay>        timeout
<SwMngt::pmFileUploadTimeout> )
```

Obsolete command.

Command Parameters

Table 16.39-1 "5-min CDR File Upload Configure Command" Resource Parameters

Resource Identifier	Type	Description
(upload-index)	Format: - the unique internal identifier of PM file upload entry (1-VOICE) - range: [1]	the unique internal identifier of 5-min CDR file upload entry

Table 16.39-2 "5-min CDR File Upload Configure Command" Command Parameters

Parameter	Type	Description
pri-server-addr	Parameter type: <SwMngt::pmFileUploadPrimaryServerAddr> Format: - IPv4-address	<i>mandatory parameter</i> IP address of the primary SFTP file server
upload-path	Parameter type: <SwMngt::pmFileUploadPath> Format: - The path to be addressed for PM / CDR Data file upload. The directory to be specified is the sub-directory below the root directory (the first or top-most directory in a hierarchy). The name of the sub-directory is not allowed to start with '/'. It must end with a '/'. The sub-directory is a mandatory input. The system does not assume any default sub-directory name. - length: x<=127	<i>mandatory parameter</i> the path to be addressed for 5-min CDR file upload, must not start with '/' but must end with a '/'
retry-num	Parameter type: <SwMngt::pmFileUploadRetryNum> Format:	<i>mandatory parameter</i> the number of PM file upload

Parameter	Type	Description
	- In case it concerns PM file upload entry for 1-VOICE or 2-DSL : The number of PM file upload retries in case the initial PM file upload failed. All retries will be done within the same interval as the interval in which the initial PM file upload failed. The several retries will be randomly spread over this interval. In case it concerns PM file upload entry for 3-CDR : The number of CDR Data file upload retries in case the initial CDR Data file upload failed. All retries will be done within the same 5-min interval as the 5-min interval in which the initial CDR Data file upload failed. The several retries will be randomly spread over this 5-min interval. - range: [0...5]	retries in case the initial 5-min CDR file upload failed
max-delay	Parameter type: <SwMngt::cdrFileUploadMaxDelay> Format: - The maximum delay period, expressed in seconds, for CDR Data file upload after CDR data file ready. The system will randomly calculate a delay time within the configured maximum delay period. This parameter is only applicable to the PM file upload entry for 3-CDR - unit: seconds - range: [0...240]	<i>mandatory parameter</i> the max delay period expressed in seconds for 5-min CDR file upload after data file ready
timeout	Parameter type: <SwMngt::pmFileUploadTimeout> Format: - The maximum time (expressed in hours) to store the not-uploaded files at the system disk (NT). This parameter is only applicable to the PM file upload entry for 3-CDR. - unit: hour - range: [0...72]	<i>mandatory parameter</i> The Max time to store the not-uploaded files on NT

16.40 Lawful Intercept Split Management Configuration Command

Command Description

When li separate is enabled:

- only CLI operators with li-admin access right can grant other operators LI access.
- only CLI operators with li-admin access right can view who has LI access.

When li separate is disabled:

- any operator with security access right can can grant other operators LI access

Before enabling, make sure that at least one CLI operator is existing with li-admin access righth

User Level

The command can be accessed by operators with security privileges, and executed by operators with security privileges.

Command Syntax

The command has the following syntax:

```
> configure system security li [ [ no ] separate ]
```

Command Parameters

Table 16.40-2 "Lawful Intercept Split Management Configuration Command" Command Parameters

Parameter	Type	Description
[no] separate	Parameter type: boolean	<i>optional parameter</i> enable split management

16.41 MAC Filter Configuration Command

Command Description

By using this command, upstream traffic from any peripheral attached to the management port on the system will be filtered at mac level.

The filter is implemented using a white-list of 20 MAC ranges, with each begin and end MAC address having the same OUI. (Original manufacturer Unique Identifier, covering the 3 most significant bytes)

On the NRCD-B the filter is a filter on the destination mac address of the frames received over this port.

On other cards/systems, such as the NRCD-C and the 7363 ISAM MX, 7367 ISAM SX-16F the filter is a filter on the source mac address of the frames received over this port.

Mac Ranges need to be specified as next possibilities

- range xx:xx:xx:xx:xx:XX-xx:xx:xx:xx:xx:YY where YY-XX < 32
- range xx:xx:xx:xx:xx:00-xx:xx:xx:xx:xx:ff
- range xx:xx:xx:xx:00:00-xx:xx:xx:xx:ff:ff
- range xx:xx:xx:00:00:00-xx:xx:xx:ff:ff:ff

User Level

The command can be accessed by operators with security privileges, and executed by operators with security privileges.

Command Syntax

The command has the following syntax:

```
> configure system security peripheral-mgmt mac-filter (index-num) [ no filter | filter <Sys::PeriphMacFilter> ]
```

Command Parameters

Table 16.41-1 "MAC Filter Configuration Command" Resource Parameters

Resource Identifier	Type	Description
(index-num)	Format: - Filter rule number - range: [1...20]	filter number

Table 16.41-2 "MAC Filter Configuration Command" Command Parameters

Parameter	Type	Description
[no] filter	Parameter type: <Sys::PeriphMacFilter> Format: (any - any <Sys::MacAddr> - <Sys::MacAddr>) Possible values: - any : any MAC address Field type <Sys::MacAddr>	optional parameter with default value: "00 : 00 : 00 : 00 : 00 : 00-00 : 00 : 00 : 00 : 00 : 00" specifies to MAC addresses to be matched with the packet

16 Security Configuration Commands

Parameter	Type	Description
	- a mac-address (example : 01:02:03:04:05:06) - length: 6 Possible values: - any : any MAC address Field type <Sys::MacAddr> - a mac-address (example : 01:02:03:04:05:06) - length: 6	

16.42 NT slot Security Configuration Command

Command Description

This command allows the operator to configure NT slot related security parameters.

User Level

The command can be accessed by operators with security privileges, and executed by operators with security privileges.

Command Syntax

The command has the following syntax:

```
> configure system security slot (index) [ [ no ] debug-usb ]
```

Command Parameters

Table 16.42-1 "NT slot Security Configuration Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: (nt-a nt-b) Possible values: - nt-a : nt-a slot - nt-b : nt-b slot	NT slot index

Table 16.42-2 "NT slot Security Configuration Command" Command Parameters

Parameter	Type	Description
[no] debug-usb	Parameter type: boolean	<i>optional parameter</i> enable microusb port

17- Secure Shell Configuration Commands

17.1 Secure Shell Configuration Command Tree	17-817
17.2 SSH Server Configuration Command	17-818
17.3 Secure Shell User Configuration Command	17-820
17.4 Secure Shell Access Configuration Command	17-821
17.5 Secure Shell SFTP User Configuration Command	17-824

17.1 Secure Shell Configuration Command Tree

Description

This chapter gives an overview of nodes that are handled by "Secure Shell Configuration Commands".

Command Tree

```

----configure
  ----system
    ----security
      ----ssh
        ----server-profile
          - [no] server-retries
          - [no] idle-timeout
          - [no] dis-hmac-sha-1
          - [no] dis-hmac-sha-1-96
          - [no] dis-hmac-sha2-256
          - [no] dis-hmac-sha2-512
          - [no] dis-hmac-md5
          - [no] dis-hmac-md5-96
          - [no] dis-aes
          - [no] dis-des-3
          - [no] dis-blowfish
          - [no] dis-des-56
          - [no] dis-cast-128-cbc
          - [no] dis-arcfour
          - [no] dis-aes-192-cbc
          - [no] dis-aes-256-cbc
          - [no] dis-aes-128-ctr
          - [no] dis-aes-192-ctr
          - [no] dis-aes-256-ctr
          - [no] dis-dh-grp1-sha1
          - [no] dis-dh-grp14-sha1
          - [no] dis-ecdh-nistp256
          - server-host-key
        ----[no] user
          - (name)
          - [no] key
        ----access
          - [no] protocol
          - [no] cli
          - [no] tl1
          - [no] debug
          - [no] debugkernel
        ----sftp-user
          - (username)
          - [no] password
          - [no] auth-type
          - [no] key-type

```

17.2 SSH Server Configuration Command

Command Description

This command configures the SSH Server parameters like maximum number of server retries, idle timeout, authentication algorithm, encryption algorithm, key-exchange and host key to be used.

At least one encryption, authentication, key-exchange and host key algorithm should be enabled for a successful establishment of SSH connection. By default, all the algorithms are enabled.

Any Change to the server-profile parameters will result in to restart of the SSH server internally and the SSH server will not be available for few seconds. Until the SSH server is ready, the system will neither be able to process SSH requests nor will provide updated server details when queried.

The modification done via this command has no impact on the current sessions instead it will be taken into effect from the next session onwards.

User Level

The command can be accessed by operators with security privileges, and executed by operators with security privileges.

Command Syntax

The command has the following syntax:

```
> configure system security ssh server-profile [ no server-retries | server-retries <SSH::ServerRetries> ] [ no
idle-timeout | idle-timeout <SSH::ServerIdleTimeOut> ] [ [ no ] dis-hmac-sha-1 ] [ [ no ] dis-hmac-sha-1-96 ] [ [ no ]
dis-hmac-sha2-256 ] [ [ no ] dis-hmac-sha2-512 ] [ [ no ] dis-hmac-md5 ] [ [ no ] dis-hmac-md5-96 ] [ [ no ]
dis-aes ] [ [ no ] dis-des-3 ] [ [ no ] dis-blowfish ] [ [ no ] dis-des-56 ] [ [ no ] dis-cast-128-cbc ] [ [ no ] dis-arcfour ]
[ [ no ] dis-aes-192-cbc ] [ [ no ] dis-aes-256-cbc ] [ [ no ] dis-aes-128-ctr ] [ [ no ] dis-aes-192-ctr ] [ [ no ]
dis-aes-256-ctr ] [ [ no ] dis-dh-grp1-sha1 ] [ [ no ] dis-dh-grp14-sha1 ] [ [ no ] dis-ecdh-nistp256 ] [
server-host-key <SSH::ServerHostKey> ]
```

Command Parameters

Table 17.2-2 "SSH Server Configuration Command" Command Parameters

Parameter	Type	Description
[no] server-retries	Parameter type: <SSH::ServerRetries> Format: - maximum number of attempts can be tried - range: [1...3]	<i>optional parameter with default value: 3</i> maximum number of attempts can be tried
[no] idle-timeout	Parameter type: <SSH::ServerIdleTimeOut> Format: - maximum idle time allowed - unit: sec - range: [0...1800]	<i>optional parameter with default value: 1800</i> maximum idle time allowed
[no] dis-hmac-sha-1	Parameter type: boolean	<i>optional parameter</i> disable hmac-sha-1 authentication

Parameter	Type	Description
[no] dis-hmac-sha-1-96	Parameter type: boolean	<i>optional parameter</i> disable hmac-sha-1-96 authentication
[no] dis-hmac-sha2-256	Parameter type: boolean	<i>optional parameter</i> disable hmac-sha2-256 authentication
[no] dis-hmac-sha2-512	Parameter type: boolean	<i>optional parameter</i> disable hmac-sha2-512 authentication
[no] dis-hmac-md5	Parameter type: boolean	<i>optional parameter</i> disable hmac-md5 authentication
[no] dis-hmac-md5-96	Parameter type: boolean	<i>optional parameter</i> disable hmac-md5-96 authentication
[no] dis-aes	Parameter type: boolean	<i>optional parameter</i> disable aes-128-cbc encryption
[no] dis-des-3	Parameter type: boolean	<i>optional parameter</i> disable 3des encryption
[no] dis-blowfish	Parameter type: boolean	<i>optional parameter</i> disable blowfish encryption
[no] dis-des-56	Parameter type: boolean	<i>optional parameter</i> disable des-56 encryption
[no] dis-cast-128-cbc	Parameter type: boolean	<i>optional parameter</i> disable cast-128-cbc encryption
[no] dis-arcfour	Parameter type: boolean	<i>optional parameter</i> disable arcfour encryption
[no] dis-aes-192-cbc	Parameter type: boolean	<i>optional parameter</i> disable aes-192-cbc encryption
[no] dis-aes-256-cbc	Parameter type: boolean	<i>optional parameter</i> disable aes-256-cbc encryption
[no] dis-aes-128-ctr	Parameter type: boolean	<i>optional parameter</i> disable aes-128-ctr encryption
[no] dis-aes-192-ctr	Parameter type: boolean	<i>optional parameter</i> disable aes-192-ctr encryption
[no] dis-aes-256-ctr	Parameter type: boolean	<i>optional parameter</i> disable aes-256-ctr encryption
[no] dis-dh-grp1-sha1	Parameter type: boolean	<i>optional parameter</i> disable dh-grp1-sha1 kex algorithm
[no] dis-dh-grp14-sha1	Parameter type: boolean	<i>optional parameter</i> disable dh-grp14-sha1 kex algorithm
[no] dis-ecdh-nistp256	Parameter type: boolean	<i>optional parameter</i> disable ecdh-sha2-nistp256 kex algorithm
server-host-key	Parameter type: <SSH::ServerHostKey> Format: (dsa rsa dsa1024 rsa1024) Possible values: - dsa : dsa 2048 bit key-pair - rsa : rsa 2048 bit key-pair - dsa1024 : dsa 1024 bit key-pair - rsa1024 : rsa 1024 bit key-pair	<i>optional parameter</i> specifies the host key algorithm to be used by server

17.3 Secure Shell User Configuration Command

Command Description

This command is used to configure a client (user, operator) who is authorised to manage the system in a secure way and choosing the public key authentication (as opposed to password authentication)method. A maximum of 10 such users can be configured. As parameters, the command requires a client user name and the corresponding public key. The public key is generated by the user using e.g. ssh-keygen (Unix), PuTTYgen (PC), etc.

User Level

The command can be accessed by operators with security privileges, and executed by operators with security privileges.

Command Syntax

The command has the following syntax:

> configure system security ssh (no user (name)) | (user (name) [no key | key <SSH::SshClientPublicKey>])

Command Parameters

Table 17.3-1 "Secure Shell User Configuration Command" Resource Parameters

Resource Identifier	Type	Description
(name)	Format: - unique index to the table - length: 1<=x<=11	unique index to the table

Table 17.3-2 "Secure Shell User Configuration Command" Command Parameters

Parameter	Type	Description
[no] key	Parameter type: <SSH::SshClientPublicKey> Format: - user public key to be stored - length: x<=1200	<i>optional parameter with default value: ""</i> public string of the client

17.4 Secure Shell Access Configuration Command

Command Description

This command allows the operator to enable and disable the remote management access channels like TL1, CLI and debug.

This command allows also configuration of file transfer protocol.

Options for cli

1. *ssh - enables only CLI/SSH and disables CLI/TELNET*
2. *telnet - enables only CLI/TELNET and disables CLI/SSH and SFTP*
3. *telnet-ssh - enables both CLI/SSH and CLI/TELNET*

Options for file transfer protocol

1. *ftp - enables the FTP application*
2. *sftp - enables the SFTP application*
3. *tftp - enables the TFTP application*

Options for tl1

1. *none - disable TL1/SSH, TL1/Telnet, and TL1/UDP*
2. *ssh - enables only TL1/SSH*
3. *telnet - enables only TL1/Telnet*
4. *udp - enables only TL1/UDP*
5. *udp-ssh - enables both TL1/UDP and TL1/SSH*
6. *udp-telnet - enables both TL1/UDP and TL1/Telnet*
7. *ssh-telnet - enables both TL1/SSH and TL1/Telnet*
8. *udp-ssh-telnet - enables TL1/UDP, TL1/SSH, and TL1/Telnet*

Options for debug (ssh/udp-ssh only applicable for FD 100/320Gbps NT and FX NT)

1. *none - disable debug/UDP and debug/SSH*
2. *udp - enable debug/UDP*
3. *ssh - enable debug/SSH*
4. *udp-ssh - enable debug/UDP and debug/SSH*

Options for debugkernel (only applicable on 7367 ISAM SX/DX ,7363 ISAM MX, FANT-G)

1. *none - disable debugkernel/SSH*
2. *ssh - enable debugkernel/SSH*

User Level

The command can be accessed by operators with security privileges, and executed by operators with security privileges.

Command Syntax

The command has the following syntax:

```
> configure system security ssh access [ no protocol | protocol <SwMngt::FileTransferProtocolType> ] [ no cli | cli
<SSH::ChannelCLISSH> ] [ no tl1 | tl1 <SSH::ChannelTL1SSH> ] [ no debug | debug
<SSH::ChannelDebugUDP> ] [ no debugkernel | debugkernel <SSH::ChannelKernelDebug> ]
```

Command Parameters

Table 17.4-2 "Secure Shell Access Configuration Command" Command Parameters

Parameter	Type	Description
[no] protocol	Parameter type: <SwMngt::FileTransferProtocolType> Format: (tftp ftp sftp) Possible values: - tftp : the tftp protocol is selected for file transfer - ftp : the ftp protocol is selected for file transfer - sftp : the sftp protocol is selected for file transfer	<i>optional parameter with default value: "tftp"</i> the protocol that is to be used for file transfer
[no] cli	Parameter type: <SSH::ChannelCLISSH> Format: (ssh telnet telnet-ssh) Possible values: - ssh : enable only cli over ssh - telnet : enable only cli over telnet - telnet-ssh : enable both cli over ssh and telnet	<i>optional parameter with default value: "telnet-ssh"</i> enable/disable cli over ssh or telnet
[no] tl1	Parameter type: <SSH::ChannelTL1SSH> Format: (none ssh telnet udp udp-ssh udp-telnet ssh-telnet udp-ssh-telnet) Possible values: - none : disable tl1 over ssh/telnet/udp - ssh : enable only tl1 over ssh - telnet : enable only tl1 over telnet - udp : enable only tl1 over udp - udp-ssh : enable both tl1 over ssh and udp - udp-telnet : enable both tl1 over udp and telnet - ssh-telnet : enable both tl1 over ssh and telnet - udp-ssh-telnet : enable tl1 over udp, ssh and telnet	<i>optional parameter with default value: "udp-ssh-telnet"</i> enable/disable tl1 over ssh, telnet, or udp
[no] debug	Parameter type: <SSH::ChannelDebugUDP> Format: (none ssh udp udp-ssh) Possible values: - none : disable debug ports - ssh : enable debug over ssh - udp : enable debug over udp - udp-ssh : enable debug over udp and ssh	<i>optional parameter with default value: "udp"</i> enable/disable debug
[no] debugkernel	Parameter type: <SSH::ChannelKernelDebug> Format: (none ssh)	<i>optional parameter with default value: "none"</i> enable/disable debug of kernel

Parameter	Type	Description
	Possible values: - none : disable debug - ssh : enable debug over ssh	

17.5 Secure Shell SFTP User Configuration

Command

Command Description

The system acts as an SFTP client towards an external SFTP server. This command allows the operator to configure the user name, password, auth-type and auth-key-type, the system should use towards the external SFTP server.

User Level

The command can be accessed by operators with security privileges, and executed by operators with security privileges.

Command Syntax

The command has the following syntax:

```
> configure system security ssh sftp-user [ (username) ] [ no password | password <SSH::SftpPassword> ] [ no auth-type | auth-type <SwMngt::ServerAuthType> ] [ no key-type | key-type <SwMngt::ServerKeyType> ]
```

Command Parameters

Table 17.5-2 "Secure Shell SFTP User Configuration Command" Command Parameters

Parameter	Type	Description
(username)	Format: - specifies sftp user name to be used - length: x<=32	optional parameter user name used when ISAM acts as SFTP client
[no] password	Parameter type: <SSH::SftpPassword> Format: (prompt plain : <SSH::SftpPassword> encrypted : <SSH::SftpEncryptedPassword>) Possible values: - prompt : prompts the operator for a password - plain : the password in plain text - encrypted : the encrypted password Field type <SSH::SftpPassword> - sftp password - length: 6<=x<=32 Field type <SSH::SftpEncryptedPassword> - sftp encrypted password - length: 23<=x<=95	optional parameter with default value: "encrypted : " password used when ISAM acts as SFTP client
[no] auth-type	Parameter type: <SwMngt::ServerAuthType> Format: (password-based publickey-based)	optional parameter with default value: "password-based" authentication type used when ISAM acts as SFTP client

Parameter	Type	Description
	Possible values: - password-based : password based authentication - publickey-based : public key based authentication	
[no] key-type	Parameter type: <SwMngt::ServerKeyType> Format: (none dsa2048 rsa2048) Possible values: - none : no key - dsa2048 : dsa 2048 bit key-pair - rsa2048 : rsa 2048 bit key-pair	<i>optional parameter with default value: "none"</i> authentication key type used when ISAM acts as SFTP client

18- Transaction Configuration Commands

18.1 Transaction Configuration Command Tree	18-827
18.2 Transaction Configuration Command	18-828

18.1 Transaction Configuration Command Tree

Description

This chapter gives an overview of nodes that are handled by "Transaction Configuration Commands".

Command Tree

```
----configure
  ----system
    ----transaction
      - [no] time-out-value
      - log-full-action
```

18.2 Transaction Configuration Command

Command Description

This command allows the operator to configure transaction parameters.

User Level

The command can be accessed by operators with alarm privileges, and executed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> configure system transaction [ no time-out-value | time-out-value <Trans::TimeoutValue> ] [ log-full-action <Trans::logFullaction> ]
```

Command Parameters

Table 18.2-2 "Transaction Configuration Command" Command Parameters

Parameter	Type	Description
[no] time-out-value	Parameter type: <Trans::TimeoutValue> Format: (indefinite <Trans::TimeoutValue>) Possible values: - indefinite : indefinite timeout value Field type <Trans::TimeoutValue> - timeout of the transaction - unit: 1/100 sec - range: [6000...360000]	<i>optional parameter with default value: 6000</i> set the timeout for transaction
log-full-action	Parameter type: <Trans::logFullaction> Format: (wrap halt) Possible values: - wrap : older log records are overwritten by recent ones - halt : logging is stopped until the log buffer is reset	<i>optional parameter</i> set action to be taken when the log is full

19- SYSLOG Configuration Commands

19.1 SYSLOG Configuration Command Tree	19-830
19.2 Syslog Configuration Commands	19-831
19.3 SYSLOG Destination Configuration command	19-832
19.4 SYSLOG Route Configuration Command	19-835

19.1 SYSLOG Configuration Command Tree

Description

This chapter gives an overview of nodes that are handled by "SYSLOG Configuration Commands".

Command Tree

```
----configure
  ----system
    ----syslog
      - [no] version
      - [no] time-format
      ----[no] destination
        - (name)
        - type
        - [no] disable
        - [no] upload-rotate
        - [no] persist-enable
        - [no] persist-timer
      ----[no] route
        - (name)
        - msg-type
        - facility
        - [no] syslog-vlan
        - [no] emergency
        - [no] alert
        - [no] critical
        - [no] error
        - [no] warning
        - [no] notice
        - [no] information
        - [no] debug
```


19.2 Syslog Configuration Commands

Command Description

Version parameter allows the operator to configure the syslog RFC version to be used. by default rfc3164 will be used, Change in the RFC version clears syslog counters, queues and files.

Timeformat parameter allows the operator to configure the timestamp format to be used for rfc5424 syslog version. By default timewithoutzone (yyyy-mm-ddThr:min:sec.secfracZ) format will be used. If Syslog version is configured as rfc3164, then mm-dd:hrs:mins:secs format will be used by default.

User Level

The command can be accessed by operators with security privileges, and executed by operators with security privileges.

Command Syntax

The command has the following syntax:

```
> configure system syslog [ no version | version <Syslog::Version> ] [ no time-format | time-format <Syslog::TimeFormat> ]
```

Command Parameters

Table 19.2-2 "Syslog Configuration Commands" Command Parameters

Parameter	Type	Description
[no] version	Parameter type: <Syslog::Version> Format: (rfc3164 rfc5424) Possible values: - rfc3164 : rfc3164 is selected for syslog version - rfc5424 : rfc5424 is selected for syslog version	<i>optional parameter with default value: "rfc3164"</i> the RFC version that is to be used for Syslog. Change in the RFC version clears syslog counters, queues and files
[no] time-format	Parameter type: <Syslog::TimeFormat> Format: (timewithoutzone timewithzone) Possible values: - timewithoutzone : timewithoutzone(yyyy-mm-ddThr:min:sec.secfracZ) format is selected - timewithzone : timewithzone(yyyy-mm-ddThr:min:sec.secfrac(+/-)hh:mm) format is selected	<i>optional parameter with default value: "timewithoutzone"</i> the TimeStamp Format is to be used for rfc5424 Syslog version

19.3 SYSLOG Destination Configuration command

Command Description

This command allows the operator to configure a syslog destination. Log messages can be sent to a file or, for rotated files, to a file on a designated upload server (file:), a remote server (udp:), all logged in CLI-users (all-cli) or all logged in TL1-users (all-tl1) or both (all-users).

User Level

The command can be accessed by operators with security privileges, and executed by operators with security privileges.

Command Syntax

The command has the following syntax:

```
> configure system syslog ( no destination (name) ) | ( destination (name) type <Sys::ServerType> [ [ no ] disable ]
[ [ no ] upload-rotate ] [ [ no ] persist-enable ] [ no persist-timer | persist-timer <Sys::PersistTimer> ] )
```

Command Parameters

Table 19.3-1 "SYSLOG Destination Configuration command" Resource Parameters

Resource Identifier	Type	Description
(name)	Format: - a profile name - range: [a-zA-Z0-9-_.] - length: 1<=x<=32	name of the syslog destination

Table 19.3-2 "SYSLOG Destination Configuration command" Command Parameters

Parameter	Type	Description
type	Parameter type: <Sys::ServerType> Format: (file : <Sys::ServName> : <Sys::FileSize> remote-file : <Ip::V4Address> : <Sys::UploadPathName> : <Sys::ServName> : <Sys::FileSize> udp : <Ip::V4Address> : <Sys::NetworkPort> : unlimited udp : <Ip::V4Address> : <Sys::NetworkPort> : <SYS::MaxRate> all-cli all-tl1 all-users udp6 : <ipv6::Prefix> / <Sys::NetworkPort> : unlimited udp6 : <ipv6::Prefix> / <Sys::NetworkPort> : <SYS::MaxRate> remote-file6 : <ipv6::Prefix> / <Sys::UploadPathName> : <Sys::ServName> : <Sys::FileSize>) Possible values: - file : file in which logs to be stored	mandatory parameter destination type

Parameter	Type	Description
	- remote-file : remote file in which logs to be stored - udp : log messages to the destination - all-cli : cli users terminal logging - all-tl1 : tl1 users terminal logging - all-users : all cli and tl1 users - udp6 : log messages to ipv6 destination - remote-file6 : remote file in which logs to be stored via v6 server Field type <Ip::V4Address> - IPv4-address Field type <ipv6::Prefix> - IPv6-address Field type <Sys::UploadPathName> - an absolute or relative path name (example : /var/log/), path name must end with slash or backslash depending on OS of TFTP server used - length: 1<=x<=64 Field type <Sys::ServName> - filename in which logs to be stored - range: [a-zA-Z0-9-_.] - length: 1<=x<=12 Field type <Sys::FileSize> - the maximum file size in bytes - range: [1...980000] Field type <Sys::NetworkPort> - the network port number - range: [1...65535] Possible values: - unlimited : transfer rate is unlimited, 0 equals unlimited Field type <SYS::MaxRate> - transfer rate - unit: messages/second - range: [1...2147483647]	
[no] disable	Parameter type: boolean	<i>optional parameter</i> disable logging to the destination
[no] upload-rotate	Parameter type: boolean	<i>optional parameter</i> enable upload of rotated files to a configured path
[no] persist-enable	Parameter type: boolean	<i>optional parameter</i> enable copy of local syslog files to flash. It is not recommended to enable this feature since the many copies to compact flash may shorten its lifetime. Recommendation is to send syslog to external server. Since copy interval is every 5 mins (default), up to last 5 mins of syslog data may be lost. When enabling this feature, syslog filename must be restricted to maximum 11 characters. Using 12 characters will lead to failures.
[no] persist-timer	Parameter type: <Sys::PersistTimer> Format: - interval at which local syslog file persistence repeats - unit: min	<i>optional parameter with default value: "5"</i> interval at which local syslog file persistence repeats, range 5 to 60

19 SYSLOG Configuration Commands

Parameter	Type	Description
	- range: [5...60]	min.

19.4 SYSLOG Route Configuration Command

Command Description

This command allows an operator to configure which messages must be sent to a given syslog destination and to assign the appropriate syslog parameters to them.

User Level

The command can be accessed by operators with security privileges, and executed by operators with security privileges.

Command Syntax

The command has the following syntax:

```
> configure system syslog ( no route (name) msg-type <Sys::MessageType> ) | ( route (name) msg-type
<Sys::MessageType> facility <Sys::LogFacility> [ no syslog-vlan | syslog-vlan <Syslog::VlanId> ] [ [ no ]
emergency ] [ [ no ] alert ] [ [ no ] critical ] [ [ no ] error ] [ [ no ] warning ] [ [ no ] notice ] [ [ no ] information ] [ [
no ] debug ] )
```

Command Parameters

Table 19.4-1 "SYSLOG Route Configuration Command" Resource Parameters

Resource Identifier	Type	Description
(name)	Format: - a profile name - range: [a-zA-Z0-9-_.] - length: 1<=x<=32	name of the destination where messages must be sent to
msg-type	Parameter type: <Sys::MessageType> Format: (all authentication cli-config-chgs tl1-config-chgs cli-msgs tl1-msgs tracing1 tracing2 tracing3 video-cdr eqpt li-config-chgs omci docsis ont-prov-status protocol tracing4 dsl)	type of the message to be routed

19 SYSLOG Configuration Commands

Resource Identifier	Type	Description
	Possible values: - all : messages of any type - authentication : authentication messages - cli-config-chgs : cli commands - tl1-config-chgs : tl1 commands - cli-msgs : cli messages - tl1-msgs : tl1 messages - tracing1 : protocol tracing messages - tracing2 : protocol tracing messages - tracing3 : protocol tracing messages - video-cdr : video cdr messages - eqpt : equipment event messages - li-config-chgs : li-config-chgs can only be logged to a destination = encrypted file - omci : OMCI events - docsis : DOCSIS events - ont-prov-status : Ont Auto Provision Status Messages - protocol : protocol message - tracing4 : protocol tracing messages - dsl : dsl event messages	

Table 19.4-2 "SYSLOG Route Configuration Command" Command Parameters

Parameter	Type	Description
facility	Parameter type: <Sys::LogFacility> Format: (kern user mail daemon auth syslog pr news uucp cron local0 local1 local2 local3 local4 local5 local6 local7) Possible values: - kern : kernel facility - user : user facility - mail : mail facility - daemon : daemon facility - auth : authentication facility - syslog : syslog facility - pr : printer facility - news : news facility - uucp : uucp facility - cron : cron facility - local0 : local0 facility - local1 : local1 facility - local2 : local2 facility	<i>mandatory parameter</i> facility to be set in the outgoing message

Parameter	Type	Description
	- local3 : local3 facility - local4 : local4 facility - local5 : local5 facility - local6 : local6 facility - local7 : local7 facility	
[no] syslog-vlan	Parameter type: <Syslog::VlanId> Format: - vlan id - range: [1...4093]	<i>optional parameter with default value: 0</i> Vlan of the syslog server valid only for tracing4 message type
[no] emergency	Parameter type: boolean	<i>optional parameter</i> pass messages of severity emergency
[no] alert	Parameter type: boolean	<i>optional parameter</i> pass messages of severity alert
[no] critical	Parameter type: boolean	<i>optional parameter</i> pass messages of severity critical
[no] error	Parameter type: boolean	<i>optional parameter</i> pass messages of severity error
[no] warning	Parameter type: boolean	<i>optional parameter</i> pass messages of severity warning
[no] notice	Parameter type: boolean	<i>optional parameter</i> pass messages of severity notice
[no] information	Parameter type: boolean	<i>optional parameter</i> pass messages of severity info
[no] debug	Parameter type: boolean	<i>optional parameter</i> pass messages of severity debug

20- Software Management Configuration Commands

20.1 Software Management Configuration Command Tree	20-839
20.2 Software Replacement Mode Configuration Command	20-840
20.3 Software Management Overall Software Package Configuration Command	20-841
20.4 Database Automatic Activation Configure Command	20-845

20.1 Software Management Configuration

Command Tree

Description

This chapter gives an overview of nodes that are handled by "Software Management Configuration Commands".

Command Tree

```
----configure
  ----software-mngt
    - sw-replacement-mode
  ----oswp
    - (index)
    - primary-file-server-id
    - second-file-server-id
    X download-set
    X autofetch
    - [no] activate
    - [no] auto-verify
    - [no] on-schedule-time
  ----database
    - [no] activate
    - [no] backup
    - [no] backupv6
    - [no] auto-backup-intvl
```

20.2 Software Replacement Mode Configuration Command

Command Description

This command allows the operator to change how the software is being replaced during OSWP activation.

User Level

The command can be accessed by operators with software management privileges, and executed by operators with software management privileges.

Command Syntax

The command has the following syntax:

> configure software-mngt sw-replacement-mode <SwMgmt::SwReplacementMode>

Command Parameters

Table 20.2-2 "Software Replacement Mode Configuration Command" Command Parameters

Parameter	Type	Description
sw-replacement-mode	Parameter type: <SwMgmt::SwReplacementMode> Format: (upgrade-via-active upgrade-via-standby lt-by-lt) Possible values: - upgrade-via-active : Selects mode to do software upgrade via active nt - upgrade-via-standby : Enables upgrade via Standby NT - lt-by-lt : Enables ISSU upgrade mode	<i>optional parameter</i> Defines the required mode for doing Software Replacement.

20.3 Software Management Overall Software Package Configuration Command

Introduction

The Overall Software Package (OSWP) can be in any one of the following states: operational, aborting, downloading, enabled, disabled, activated, and committed. The operator can perform such functions as download the OSWP or set of files, abort its download, or enable or disable its autofetch property. The operator can also specify primary and secondary TFTP-server IDs for downloading the database.

The operator can also configure the download set or the set of files that are needed before triggering activation.

Download a new OSWP

To download an OSWP, the system must have only one enabled/active/committed OSWP, the management channel between the system and the manager must be established, and the system must not be involved in another software download process.

The manager requests that the system download a new OSWP. The manager specifies the path name of the overall descriptor file, the TFTP-servers where the overall descriptor files are located, and the set of files the manager wants to have available on the system before activating the new OSWP.

The system downloads the overall descriptor files and stores them persistently. The system downloads the software files that are specified in the downloaded SWP descriptor files, on condition that sufficient resources are available for their persistent storage. The manager can monitor the progress of the download process with granularity.

The download process can be implicitly or explicitly interrupted. The implicit interruption can occur due to reasons such as the unavailability of enough resources to store SWP files, the system not being able to download or interpret the overall descriptor file, or the system not being able to download a selected SWP descriptor file. The explicit interruption can occur when the manager requests that the system abort the ongoing download process.

If there are no exceptions, the system has two OSWPs; the Enabled/Active/Committed OSWP and the new downloaded OSWP. The state of the new OSWP is Enabled/NotActive/UnCommitted.

If the system supports software load validation feature and auto-verify is configured for a downloading oswp, system will perform implicit digital verification of downloaded files.If the digital verification is success system will make the OSWP state as Enabled/NotActive/UnCommitted otherwise it is Disabled/NotActive/UnCommitted.Also it should be noted that If auto-verify enabled then download of feature not supported release will have limitation and will be made as disabled since it will not have Digital signature files to validate. In such cases operator has to disable auto-verify and download.

Finally, after a successful verification process, Operator has to manually cross verify the root-certificate displayed in CLI with the distributed root certificate via other channel for that package then only it is ensured that downloaded package not altered from its original source.

Abort an OSWP

The manager can abort an OSWP when the system has two OSWPs. The state of the first OSWP is Enabled/Active/Committed while the second OSWP is in one of the following three states: Enabled/NotActive/UnCommitted, Downloading/NotActive/UnCommitted, or Disabled/NotActive/UnCommitted. The management channel between the system and the manager is established and the system is not involved in any other software download process.

The manager requests that the system remove the NotActive/UnCommitted OSWP. The system removes all the persistent stored files and databases not related to the Enabled/Active/Committed OSWP. The state of the OSWP to be removed is Aborting/NotActive/UnCommitted during the complete removal operation.

After a successful abort, the system has only one OSWP. The state of this OSWP is Enabled/Active/Committed. Only files and databases related to this OSWP are stored persistently in the system.

Activate a Not-Active OSWP

To activate a not-active OSWP, the system requires two OSWPs. The state of one OSWP is Enabled/Active and the state of the second OSWP is Enabled/NotActive. The management channel between the system and the manager is established and the system is not involved in another software download process.

The manager requests that the system activates the Enabled/NotActive OSWP. In case the manager requests to activate with linked database, the system first selects an available database that is compatible with and linked to the Enabled/NotActive OSWP. In case the manager requests to activate with default database, the system creates a default database that is compatible with the Enabled/NotActive OSWP. The system then starts the activation process of the NotActive OSWP.

The activation can happen on active NT or on standby NT. Activation on standby NT is only possible in case the redundant NT board is equipped and hot standby and the NT board type supports it. In case the conditions to do the activation on standby NT are fulfilled, the system will select this option. In case these conditions are not fulfilled the system will select activation on active NT.

Finally, after the successful activation of the Not-active OSWP, the system has two OSWPs. The previous Not-active OSWP is now active, together with the selected compatible database. Also, the previous Active OSWP is still available, but NotActive. In case the activation was done on standby NT, the standby NT from before the activation will be the active NT after the activation.

Commit an OSWP

To commit an OSWP, the system requires two OSWPs. The state of the first OSWP is Enabled/Active/UnCommitted and the state of the second OSWP is Enabled/NotActive/Committed.

The manager requests that the system commit the active OSWP. The system removes all the persistent stored files and databases that do not belong to the Enabled/Active OSWP. The state of the OSWP to be committed is Enabled/Active/Committing during the complete commit operation.

Finally, after a successful commit process, the system has only one OSWP. The state of this OSWP is Enabled/Active/Committed. Only files related to this OSWP are stored persistently in the system.

Verify an OSWP

If the system supports software load validation feature Operator can perform explicit digital verification of an OSWP. To verify an OSWP, the availability state of the OSWP should be Enabled.

Finally, after a successful verification process, Operator has to manually cross verify the root-certificate displayed in CLI with the distributed root certificate via other channel for that package then only it is ensured that downloaded package not altered from its original source.

Abort Verify an OSWP

The manager can abort verify on an OSWP when the system running explicit verification on that OSWP.

Command Description

This command allows the operator to configure various OSWP attributes and parameters.

User Level

The command can be accessed by operators with software management privileges, and executed by operators with software management privileges.

Command Syntax

The command has the following syntax:

```
> configure software-mngt oswp (index) [ primary-file-server-id <SwMngt::serverIdv6> ] [ second-file-server-id
<SwMngt::serverIdv6> ] [ download-set <SwMngt::downloadSet> ] [ autofetch <SwMngt::autoFetch> ] [ no
activate | activate <SwMngt::OswpAutoAct> ] [ no auto-verify | auto-verify <SwMngt::OswpAutoVerify> ] [ no
on-schedule-time | on-schedule-time <Sys::TimeIOInMinsRef1970> ]
```

Command Parameters

Table 20.3-1 "Software Management Overall Software Package Configuration Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - id of one of the two oswps - range: [1...2]	index to the swm oswp table

Table 20.3-2 "Software Management Overall Software Package Configuration Command" Command Parameters

Parameter	Type	Description
primary-file-server-id	Parameter type: <SwMngt::serverIdv6> Format: (<Ip::V4Address> ipv6 : <Ip::InetAddressType>) Possible values: - ipv6 : Ipv6 address (only for management IPv6 supported boards) Field type <Ip::V4Address> - IPv4-address Field type <Ip::InetAddressType> - IPv6 address	<i>optional parameter</i> tftp/sftp server address for overall descriptor file
second-file-server-id	Parameter type: <SwMngt::serverIdv6> Format: (<Ip::V4Address> ipv6 : <Ip::InetAddressType>) Possible values: - ipv6 : Ipv6 address (only for management IPv6 supported boards) Field type <Ip::V4Address> - IPv4-address Field type <Ip::InetAddressType> - IPv6 address	<i>optional parameter</i> 2nd tftp/sftp server address for overall descriptor file
download-set	Parameter type: <SwMngt::downloadSet> Format: (min-set actual-set complete-set)	<i>obsolete parameter that will be ignored</i> set of files needed before triggering activation

20 Software Management Configuration Commands

Parameter	Type	Description
	Possible values: - min-set : minimum set of files needed to activate - actual-set : files applicable for the board types - complete-set : all the files	
autofetch	Parameter type: <SwMngt::autoFetch> Format: disabled Possible values: - disabled : disable autofetch feature	<i>obsolete parameter that will be ignored</i> disable autofetch feature
[no] activate	Parameter type: <SwMngt::OswpAutoAct> Format: (manually after-download on-schedule) Possible values: - manually : manually activate the OSWP - after-download : enable the automatic activation of OSWP after downloading - on-schedule : enable the automatic activation of OSWP at the time defined in on-schedule-time	<i>optional parameter with default value: "manually"</i> determines when to active an OSWP
[no] auto-verify	Parameter type: <SwMngt::OswpAutoVerify> Format: (disabled enabled) Possible values: - disabled : manually verify the OSWP - enabled : enable the automatic verification of OSWP after downloading	<i>optional parameter with default value: "disabled"</i> determines auto-verify of an OSWP after downloading
[no] on-schedule-time	Parameter type: <Sys::TimeIOInMinsRef1970> Format: - the time (yyyy-mm-dd:hour:minutes)	<i>optional parameter with default value: "1970-01-01 : 00 : 00"</i> the expected activation time of OSWP, range:[1970-01-01 00:00,2035-12-31 23:59]

20.4 Database Automatic Activation Configure Command

Command Description

This command configure database automatic activation and automatic backup states and attributes.

User Level

The command can be accessed by operators with software management privileges, and executed by operators with software management privileges.

Command Syntax

The command has the following syntax:

```
> configure software-mngt database [ no activate | activate <SwMngt::DbAutoAct> ] [ no backup | backup
<SwMngt::DbAutoBackup> ] [ no backupv6 | backupv6 <SwMngt::V6DbAutoBackup> ] [ no auto-backup-intvl |
auto-backup-intvl <SwMngt::DbAutoBackIntvl> ]
```

Command Parameters

Table 20.4-2 "Database Automatic Activation Configure Command" Command Parameters

Parameter	Type	Description
[no] activate	Parameter type: <SwMngt::DbAutoAct> Format: (after-download manually) Possible values: - after-download : enable the automatic activation of database after downloading - manually : manually activate the OSWP	<i>optional parameter with default value: "manually"</i> determines when to active database
[no] backup	Parameter type: <SwMngt::DbAutoBackup> Format: (manually activate : <Ip::V4Address> : <SwMngt::dbpath>) Possible values: - manually : manually backup of the database - activate : automatic backup of the database Field type <Ip::V4Address> - IPv4-address Field type <SwMngt::dbpath> - path for the db (example: /path_to_db) - range: [a-zA-Z0-9-_/] - length: x<=255	<i>optional parameter with default value: "manually"</i> backup destination of database
[no] backupv6	Parameter type: <SwMngt::V6DbAutoBackup> Format:	<i>optional parameter with default value: "manually"</i>

20 Software Management Configuration Commands

Parameter	Type	Description
	(manually activate : <Ip::InetAddressType> / <SwMngt::dbpath>) Possible values: - manually : manually backup of the database - activate : automatic backup of the database Field type <Ip::InetAddressType> - IPv6 address Field type <SwMngt::dbpath> - path for the db (example: /path_to_db) - range: [a-zA-Z0-9-_./] - length: x<=255	IPv6 backup destination of database
[no] auto-backup-intvl	Parameter type: <SwMngt::DbAutoBackIntvl> Format: - the interval period for automatic backup - unit: hours - range: [1...168]	<i>optional parameter with default value: 24</i> the interval period for automatic backup

21- QoS Configuration Commands

21.1 QoS Configuration Command Tree	21-849
21.2 QoS Configuration Command	21-856
21.3 QoS 802.1P Class-to-Queue Mapping Configuration Command	21-858
21.4 QoS Dsl Control Pkt Policer Configuration Command	21-860
21.5 QoS Nni Control Pkt Policer Configuration Command	21-862
21.6 QoS DSCP-to-Dot1P Alignment for L3 Forwarded Traffic Configuration Command	21-863
21.7 QoS Queue Profile Configuration Command	21-864
21.8 QoS Scheduler Node Profile Configuration Command	21-867
21.9 QoS CAC Profile Configuration Command	21-869
21.10 QoS Single Dot1P Marker Configuration Command	21-871
21.11 QoS Single DSCP Marker Configuration Command	21-872
21.12 QoS DSCP Contract Table Marker Configuration Command	21-873
21.13 QoS DSCP Contract Table Code-point Configuration Command For DSCP-contract	21-874
21.14 QoS Dot1P and DSCP Contract Table Marker Configuration Command	21-875
21.15 DSCP Contract Table Codepoint Configuration Command For D1p-dscp-contract	21-876
21.16 QoS Dot1P and Single DSCP Marker Configuration Command	21-877
21.17 QoS Dot1P Alignment Marker Configuration Command	21-878
21.18 QoS Dot1P Remark Table Marker Configuration Command	21-880
21.19 QoS Dot1P Remark Table Dot1p-value Configuration Command For Dot1P-Remark	21-881
21.20 QoS Policer Profile Configuration Command	21-882
21.21 QoS L2 Filter Profile Configuration Command	21-886
21.22 QoS L3 Filter Profile Configuration Command	21-888
21.23 QoS Policy Action Profile Configuration Command	21-891
21.24 QoS Policy Profile Configuration Command	21-893
21.25 QoS Session Profile Configuration Command	21-895
21.26 QoS Session Upstream Policy List Configuration Command	21-899
21.27 QoS Session Downstream Policy List Configuration Command	21-900
21.28 QoS Session remote Upstream Policy List Configuration Command	21-901
21.29 QoS Session Remote Downstream Policy List Configuration Command	21-902
21.30 QoS AggrQueuesConfig Profile Configuration Command	21-903
21.31 QoS Shaper Profile Configuration Command	21-912
21.32 QoS Bandwidth Profile Configuration Command	21-914
21.33 QoS IngressQoS Profile Configuration Command	21-916
21.34 QoS Rate Limit Profile Configuration Command	21-920
21.35 QoS DSCP to Pbit Mapping Profile Configuration	21-923

Command	
21.36 QoS DSCP to Pbit Mapping Profile Configuration	21-924
Command	
21.37 QoS DSCP to Tc Mapping Profile Configuration	21-925
Command	
21.38 QoS DSCP to Tc Mapping Profile Configuration	21-926
Command	
21.39 QoS Policer Per Tc Profile Configure	21-927
21.40 QoS Policer Per Tc Profile Configure	21-928
21.41 QoS CoS Threshold Profile Configuration Command	21-929
21.42 QoS Board-Level Queue and Performance	21-931
Configuration Command	
21.43 QoS Queue Threshold Crossing Alarm Configuration	21-933
Command	
21.44 QoS DSL Link Configuration Command	21-937
21.45 QoS LIM Queue Configuration Command	21-939
21.46 QoS ShdSL Link Configuration Command	21-941
21.47 QoS LIM Queue (SHDSL) Configuration Command	21-943
21.48 QoS Interface Configuration Command	21-945
21.49 QoS Interface Queue Configuration Command	21-952
21.50 QoS Interface Upstream Queue Configuration	21-956
Command	
21.51 QoS Interface Remote Downstream Queue	21-961
Configuration Command	
21.52 QoS Line Control Packets Rate Limit Configuration	21-965
Command	
21.53 P-bit Based Scheduling For SC Forwarder Cross	21-967
Connect/Residential Bridge Configuration Command	
21.54 QoS system level Up Control Packet DSCP/Pbit	21-969
marking, TC mapping Configuration Command	
21.55 QoS system level Dn Control Packet DSCP/Pbit	21-971
marking, TC mapping Configuration Command	
21.56 QoS handling of upstream protocols(ARP, PPPoE,	21-973
DHCPv4/v6,ND and MLD) for DSL LT's Configuration	
Command	

21.1 QoS Configuration Command Tree

Description

This chapter gives an overview of nodes that are handled by "QoS Configuration Commands".

Command Tree

```

----configure
  ----qos
    - [no] atm-overhead-fact
    - [no] eth-efm-fact
    - [no] enable-alignment
    - [no] cac-mode
    - [no] use-dei
    - [no] set-dei
  ----tc-map-dot1p
    - (index)
    X queue
    - tc
    - dpcolor
    - policer-color
  ----dsl-ctrl-pkt-policer
    - [no] sustained-rate
    - [no] burst-size
    - [no] protocol-ctrl
  ----nni-ctrl-pkt-policer
    - [no] sustained-rate
    - [no] burst-size
  ----dscp-map-dot1p
    - (index)
    - dot1p-value
  ----profiles
    ----[no] queue
      - (name)
      - (bac-complex-type)
      - [no] unit
    ----[no] scheduler-node
      - (name)
      - priority
      - weight
      - shaper-profile
      - [no] ext-shaper
      - [no] mcast-inc-shape
    ----[no] cac
      - (name)
      - res-voice-bandwidth
      - max-mcast-bandwidth
      - res-data-bandwidth
      - [no] cac-type
  ----marker
    ----[no] d1p
      - (name)
  
```

- default-dot1p
- [no] dscp
 - (name)
 - default-dscp
 - [no] alignment
- [no] dscp-contract
 - (name)
 - [no] alignment
- codepoint
 - (codepoint)
 - [no] dscp-value
- [no] d1p-dscp-contract
 - (name)
 - dot1p-value
 - X [no] alignment
- codepoint
 - (codepoint)
 - [no] dscp-value
- [no] d1p-dscp
 - (name)
 - default-dscp
 - default-dot1p
- [no] d1p-alignment
 - (name)
 - (alignment)
 - [no] dscp-pbit-prof
- [no] dot1p-remark
 - (name)
- dot1p-value
 - (dot1p-value)
 - [no] remark-value
- [no] policer
 - (name)
 - committed-info-rate
 - committed-burst-size
 - [no] policer-type
 - [no] excess-info-rate
 - [no] excess-burst-size
 - [no] coupling-flag
 - [no] color-mode
 - [no] green-action
 - [no] yellow-action
 - [no] red-action
 - [no] policed-size-ctrl
 - [no] peak-info-rate
 - [no] peak-burst-size
 - [no] cos-threshold
- [no] l2-filter
 - (name)
 - [no] dst-mac-addr
 - [no] src-mac-addr
 - [no] ethertype
 - [no] dot1p-priority
 - [no] canonical-format
 - [no] vlan-id
- [no] l3-filter
 - (name)
 - [no] filter-type
 - [no] dst-ip-addr

```

- [no] src-ip-addr
- [no] dst-ipv6-addr
- [no] src-ipv6-addr
- [no] min-dst-port
- [no] max-dst-port
- [no] min-src-port
- [no] max-src-port
- [no] dscp-value
- [no] protocol
----[no] policy-action
- (name)
- [no] dscp-value
- [no] dot1p-value
- [no] discard-packet
- [no] shared-policer
- [no] policer-profile
- [no] count
- [no] mirror-vlan
- [no] tc-value
----[no] policy
- (name)
- filter
- [no] precedence
- [no] policy-action
----[no] session
- (name)
- logical-flow-type
- [no] up-policer
- [no] down-policer
- [no] up-marker
- [no] ing-outer-marker
- [no] ds-schedule-tag
- [no] up-policer-per-tc
- [no] up-dscptotc-prof
- [no] dn-dscptotc-prof
- [no] up-pbittotc-prof
- [no] dn-pbittotc-prof
- [no] up-default-tc
- [no] dn-default-tc
----[no] up-policy
- (name)
----[no] down-policy
- (name)
----[no] rem-up-policy
- (name)
----[no] rem-down-policy
- (name)
----[no] aggrqueuesconfig
- (name)
- [no] q0-priority
- [no] q1-priority
- [no] q2-priority
- [no] q3-priority
- [no] q4-priority
- [no] q5-priority
- [no] q6-priority
- [no] q7-priority
- [no] q0-weight
- [no] q1-weight

```

- [no] q2-weight
- [no] q3-weight
- [no] q4-weight
- [no] q5-weight
- [no] q6-weight
- [no] q7-weight
- [no] q0-shaper-prof
- [no] q1-shaper-prof
- [no] q2-shaper-prof
- [no] q3-shaper-prof
- [no] q4-shaper-prof
- [no] q5-shaper-prof
- [no] q6-shaper-prof
- [no] q7-shaper-prof
- [no] q0-queue-prof
- [no] q1-queue-prof
- [no] q2-queue-prof
- [no] q3-queue-prof
- [no] q4-queue-prof
- [no] q5-queue-prof
- [no] q6-queue-prof
- [no] q7-queue-prof
- [no] q0-bandwidth-prof
- [no] q1-bandwidth-prof
- [no] q2-bandwidth-prof
- [no] q3-bandwidth-prof
- [no] q4-bandwidth-prof
- [no] q5-bandwidth-prof
- [no] q6-bandwidth-prof
- [no] q7-bandwidth-prof
- [no] q0-bw-sharing
- [no] q1-bw-sharing
- [no] q2-bw-sharing
- [no] q3-bw-sharing
- [no] q4-bw-sharing
- [no] q5-bw-sharing
- [no] q6-bw-sharing
- [no] q7-bw-sharing

----[no] shaper

- (name)
- committed-info-rate
- committed-burst-size
- [no] excess-info-rate
- [no] type
- [no] autoshape

----[no] bandwidth

- (name)
- committed-info-rate
- assured-info-rate
- excessive-info-rate
- [no] delay-tolerance
- [no] assu-burst-size
- [no] exce-burst-size
- [no] dbu

----[no] ingress-qos

- (name)
- [no] dot1-p0-tc
- [no] dot1-p1-tc

```

- [no] dot1-p2-tc
- [no] dot1-p3-tc
- [no] dot1-p4-tc
- [no] dot1-p5-tc
- [no] dot1-p6-tc
- [no] dot1-p7-tc
- [no] use-dei
- [no] dot1-p0-color
- [no] dot1-p1-color
- [no] dot1-p2-color
- [no] dot1-p3-color
- [no] dot1-p4-color
- [no] dot1-p5-color
- [no] dot1-p6-color
- [no] dot1-p7-color
- [no] dot1-p0-pol-tc
- [no] dot1-p1-pol-tc
- [no] dot1-p2-pol-tc
- [no] dot1-p3-pol-tc
- [no] dot1-p4-pol-tc
- [no] dot1-p5-pol-tc
- [no] dot1-p6-pol-tc
- [no] dot1-p7-pol-tc
----[no] rate-limit
- (name)
- [no] total-rate
- [no] total-burst
- [no] arp-rate
- [no] arp-burst
- [no] dhcp-rate
- [no] dhcp-burst
- [no] igmp-rate
- [no] igmp-burst
- [no] pppoe-rate
- [no] pppoe-burst
- [no] nd-rate
- [no] nd-burst
- [no] icmpv6-rate
- [no] icmpv6-burst
- [no] mld-rate
- [no] mld-burst
- [no] dhcpv6-rate
- [no] dhcpv6-burst
- [no] cfm-rate
- [no] cfm-burst
----[no] dscp-pbit
- (name)
----codepoint
- (codepoint)
- dot1p-value
----[no] dscp-tc
- (name)
----codepoint
- (codepoint)
- tc-value
----[no] policer-per-tc
- (name)
----tc-policer
- (tc)

```

```

- [no] policer
----[no] cos-threshold
- (name)
- [no] tc0-threshold
- [no] tc1-threshold
- [no] tc2-threshold
- [no] tc3-threshold
- [no] tc4-threshold
- [no] tc5-threshold
- [no] tc6-threshold
- [no] tc7-threshold
----global
- (index)
- [no] buffer-occ-thresh
- [no] queue-stats
- [no] dsload-tca
- [no] dsload-thresh
- [no] buffer-tca
- [no] up-buf-thresh
- [no] up-obc-thresh
- [no] dn-obc-thresh
- [no] dn-buf-thresh
- [no] part-buf-thresh
----tca
- (index)
- queue
- [no] tca-enable
- [no] load-thresh
- [no] dis-frame-th
- [no] qpeak-usage-th
----X dsl-port
- (index)
- [no] scheduler-profile
- cac-profile
----X queue
- (queue)
- queue-profile
----X shdsl-port
- (index)
- scheduler-profile
- cac-profile
----X queue
- (queue)
- queue-profile
----interface
- (index)
- [no] scheduler-node
- [no] ingress-profile
- [no] cac-profile
- [no] ext-cac
- [no] ds-queue-sharing
- [no] us-queue-sharing
- [no] ds-num-queue
- [no] ds-num-rem-queue
- [no] us-num-queue
- [no] queue-stats-on
- [no] autoschedule
- oper-weight
- oper-rate

```


- [no] us-vlanport-queue
- [no] dsfld-shaper-prof
- [no] bandwidth-profile
- [no] bandwidth-sharing
- [no] aggr-usq-profile
- [no] aggr-dsq-profile
- [no] gem-sharing
- [no] scheduler-mode
- [no] mc-scheduler-node
- [no] bc-scheduler-node
- [no] ds-schedule-tag
- queue**
 - **(queue)**
 - priority
 - weight
 - oper-weight
 - queue-profile
 - shaper-profile
- upstream-queue**
 - **(queue)**
 - [no] priority
 - [no] weight
 - [no] bandwidth-profile
 - [no] ext-bw
 - [no] bandwidth-sharing
 - [no] queue-profile
 - [no] shaper-profile
- ds-rem-queue**
 - **(queue)**
 - [no] priority
 - [no] weight
- [no] ctrl-pkt-policer**
 - **(protocol-id)**
 - [no] sustained-rate
 - [no] burst-size
- pbit-scheduling**
 - [no] sc-xcon-us
 - [no] sc-xcon-dn
 - [no] sc-rb-us
 - [no] sc-rb-dn
- [no] up-ctrl-pkt**
 - **(protocol-id)**
 - [no] dscp
 - [no] pbit
 - [no] tc
- [no] dn-ctrl-pkt**
 - **(protocol-id)**
 - [no] dscp
 - [no] pbit
 - [no] tc
- upstr-prot-dsl**
 - [no] enable

21.2 QoS Configuration Command

Command Description

This command allows the operator to specify global QoS parameters.

The ATM overhead factor is used to calculate ATM bandwidth required by streams for which bandwidth parameters are specified as Ethernet bandwidth. The ATM overhead factor specifies in terms of percentage what part of a given raw ATM bit rate will be available for Ethernet frames. The default value is 85%, which means a typical overhead of 15% for ATM/AAL5. QoS management will use this value to deduct the available Ethernet rate on ATM-based DSL interfaces.

The Eth EFM overhead factor is used to calculate EFM bandwidth required by streams for which bandwidth parameters are specified as Ethernet bandwidth. The Eth EFM overhead factor specifies in terms of percentage what part of a given raw EFM bit rate will be available for Ethernet frames. The default value is 97%, which means a typical overhead of 3% for EFM Encapsulation.

The enable alignment is used to enable or disable the DSCP to P-bits alignment for all the L3 forwarded traffic.

The Global CAC-mode selection switch determines whether Connection Admission Control relies on the guaranteed sync rate or the actual line rate of the physical interface.

User Level

The command can be accessed by operators with qos privileges, and executed by operators with qos privileges.

Command Syntax

The command has the following syntax:

```
> configure qos [ no atm-overhead-fact | atm-overhead-fact <Qos::AtmFactor> ] [ no eth-efm-fact | eth-efm-fact
<Qos::EthEfmFactor> ] [ [ no ] enable-alignment ] [ no cac-mode | cac-mode <Qos::CacMode> ] [ [ no ] use-dei ] [
[ no ] set-dei ]
```

Command Parameters

Table 21.2-2 "QoS Configuration Command" Command Parameters

Parameter	Type	Description
[no] atm-overhead-fact	Parameter type: <Qos::AtmFactor> Format: - over head factor introduced by atm layer - unit: % - range: [1...100]	<i>optional parameter with default value: 85</i> over head factor introduced by atm layer
[no] eth-efm-fact	Parameter type: <Qos::EthEfmFactor> Format: - value to estimate bandwidth overhead inserted by efm layer - unit: % - range: [1...100]	<i>optional parameter with default value: 97</i> value to estimate bandwidth overhead inserted by efm layer
[no] enable-alignment	Parameter type: boolean	<i>optional parameter</i> DSCP to P-bit alignment for all

Parameter	Type	Description
		forwarded L3 traffic
[no] cac-mode	Parameter type: <Qos::CacMode> Format: (nocac msr alr) Possible values: - nocac : no cac in system - msr : base on minimum synchronized rate - alr : base on actual line rate	<i>optional parameter with default value: "msr"</i> This object stores an global CAC mode selection switch
[no] use-dei	Parameter type: boolean	<i>optional parameter</i> Enable global control of DEI aware
[no] set-dei	Parameter type: boolean	<i>optional parameter</i> Enable global control of DEI remark

21.3 QoS 802.1P Class-to-Queue Mapping Configuration Command

Command Description

This command allows the operator to configure the downstream traffic class mapping table. This table defines which 802.1P codepoint is cast to which egress buffer on the L3 units.

There is a second class to the queue mapping table on the SHub/IHub, but this class is independent from the configuration perspective of this table. (See the traffic class configuration section for more information.) The second class is used mainly for upstream traffic segregation into egress buffers on the SHub/IHub.

User Level

The command can be accessed by operators with qos privileges, and executed by operators with qos privileges.

Command Syntax

The command has the following syntax:

```
> configure qos tc-map-dot1p (index) [ queue <Qos::Queues> ] [ tc <Qos::QosTrafficClass> ] [ dpcolor <Qos::Color> ] [ policer-color <Qos::PolicerColor> ]
```

Command Parameters

Table 21.3-1 "QoS 802.1P Class-to-Queue Mapping Configuration Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - value of 802.1p field - range: [0...7]	value of 802.1p field

Table 21.3-2 "QoS 802.1P Class-to-Queue Mapping Configuration Command" Command Parameters

Parameter	Type	Description
queue	Parameter type: <Qos::Queues> Format: - output dsl/gpon/epon port queue number - range: [0...7,255]	<i>obsolete parameter replaced by parameter "tc"</i> output dsl port queue number
tc	Parameter type: <Qos::QosTrafficClass> Format: - the traffic class number - range: [0...7]	<i>optional parameter</i> the traffic class number
dpcolor	Parameter type: <Qos::Color> Format: (green yellow)	<i>optional parameter</i> output discard precedence on queue

Parameter	Type	Description
	Possible values: - green : discard priority green in queue - yellow : discard priority yellow in queue	
policer-color	Parameter type: <Qos::PolicerColor> Format: (green yellow red) Possible values: - green : green color - yellow : yellow color - red : red color	<i>optional parameter</i> the frame colour for trtcm

21.4 QoS Dsl Control Pkt Policer Configuration

Command

Command Description

This command allows the operator to configure a upstream QoS Dsl Control Packet Policer. This control packet policer serves to prevent DoS attacks from subscriber premises against the control plane of the ISAM. The policing parameters that can be configured are the sustainable rate in packets/sec and the maximum burst size in packets.

Control packets arriving at a higher rate than the sustainable rate are dropped by the policer.

Control packets arriving in a longer burst than the maximum burst size are dropped by the policer.

Control packets are packets directed to the LSM itself or inserted by the LSM. The control packet protocol type depends on the applied forwarding model, and can be 802.1x, ARP, RIP, DHCP, IGMP, PPPoEDiscovery, PPP LCP, PPP control, PPP LCP termination acknowledgement. Policing is not applied on control packets inserted by the LSM.

This command allows the operator to control the DSL line level control packet policer (enable or disable) for control protocol packets that remains in the data plane. And this feature is supported only for ARP and RIP protocol.

User Level

The command can be accessed by operators with qos privileges, and executed by operators with qos privileges.

Command Syntax

The command has the following syntax:

```
> configure qos dsl-ctrl-pkt-policer [ no sustained-rate | sustained-rate <Qos::SustainedRate> ] [ no burst-size | burst-size <Qos::DslCtrlBurstSize> ] [ no protocol-ctrl | protocol-ctrl <Qos::ControlProtocolPolicerCtrl> ]
```

Command Parameters

Table 21.4-2 "QoS Dsl Control Pkt Policer Configuration Command" Command Parameters

Parameter	Type	Description
[no] sustained-rate	Parameter type: <Qos::SustainedRate> Format: - the police rate of inc user pkts in pps - range: [1...64]	optional parameter with default value: 15 max sustainable rate in packets/sec
[no] burst-size	Parameter type: <Qos::DslCtrlBurstSize> Format: - the burst size - range: [1...128]	optional parameter with default value: 10 max burst size, in packets
[no] protocol-ctrl	Parameter type: <Qos::ControlProtocolPolicerCtrl> Format: (police-arprp nopolice-arprp)	optional parameter with default value: "police-arprp" DSL control packet policer applicability for control protocol

Parameter	Type	Description
	Possible values: - police-arrip : police arp rip packets by the dsl-ctrl-policer if handled as data packet - nopolice-arrip : no police arp rip packets by the dsl-ctrl-policer if handled as data packet	packets that remain in data plane. Currently under this only ARP and RIP control packets are controlled.

21.5 QoS Nni Control Pkt Policer Configuration Command

Command Description

This command allows the operator to configure a upstream QoS Nni Control Packet Policer. This control packet policer serves to prevent DoS attacks from subscriber premises against the control plane of the ISAM. The policing parameters that can be configured are the sustainable rate in packets/sec and the maximum burst size in packets.

Control packets arriving at a higher rate than the sustainable rate are dropped by the policer.

Control packets arriving in a longer burst than the maximum burst size are dropped by the policer.

Control packets are packets directed to the LSM itself or inserted by the LSM. The control packet protocol type depends on the applied forwarding model, and can be 802.1x, ARP, RIP, DHCP, IGMP, PPPoEDiscovery, PPP LCP, PPP control, PPP LCP termination acknowledgement. Policing is not applied on control packets inserted by the LSM.

User Level

The command can be accessed by operators with qos privileges, and executed by operators with qos privileges.

Command Syntax

The command has the following syntax:

```
> configure qos nni-ctrl-pkt-policer [ no sustained-rate | sustained-rate <Qos::NniSustainedRate> ] [ no burst-size | burst-size <Qos::NniCtrlBurstSize> ]
```

Command Parameters

Table 21.5-2 "QoS Nni Control Pkt Policer Configuration Command" Command Parameters

Parameter	Type	Description
[no] sustained-rate	Parameter type: <Qos::NniSustainedRate> Format: - the police rate of inc user pkts in pps - range: [1...256]	<i>optional parameter with default value: 64</i> max sustainable rate in packets/sec
[no] burst-size	Parameter type: <Qos::NniCtrlBurstSize> Format: - the burst size - range: [1...256]	<i>optional parameter with default value: 128</i> max burst size, in packets

21.6 QoS DSCP-to-Dot1P Alignment for L3 Forwarded Traffic Configuration Command

Command Description

This command allows the operator to configure a DSCP-to-Dot1P Alignment Table for L3 forwarded traffic. This facility allows DSCP to P-bits alignment without the use of QoS session profiles via configuring a mapping table with global scope. It is only applied to traffic in interfaces with L3 forwarding.

User Level

The command can be accessed by operators with qos privileges, and executed by operators with qos privileges.

Command Syntax

The command has the following syntax:

```
> configure qos dscp-map-dot1p (index) [ dot1p-value <Qos::DscpToDot1PAlign> ]
```

Command Parameters

Table 21.6-1 "QoS DSCP-to-Dot1P Alignment for L3 Forwarded Traffic Configuration Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - the DSCP value - range: [0...63]	the DSCP value

Table 21.6-2 "QoS DSCP-to-Dot1P Alignment for L3 Forwarded Traffic Configuration Command" Command Parameters

Parameter	Type	Description
dot1p-value	Parameter type: <Qos::DscpToDot1PAlign> Format: - the DOT1P value - range: [0...7]	<i>optional parameter</i> the DOT1P value

21.7 QoS Queue Profile Configuration Command

Command Description

This command allows the operator to configure a QoS queue profile. A queue profile or buffer acceptance control (BAC) profile contains configuration information on data plane queues. BAC profiles can be used on the L3 line cards.

Minimum and Maximum Threshold value for queues are given in packets.

User Level

The command can be accessed by operators with qos privileges, and executed by operators with qos privileges.

Command Syntax

The command has the following syntax:

```
> configure qos profiles ( no queue (name) ) | ( queue (name) (bac-complex-type) [ no unit | unit <Qos::Units> ] )
```

Command Parameters

Table 21.7-1 "QoS Queue Profile Configuration Command" Resource Parameters

Resource Identifier	Type	Description
(name)	Format: - a profile name - range: [a-zA-Z0-9-_.] - length: 1<=x<=32	A unique profile name

Table 21.7-2 "QoS Queue Profile Configuration Command" Command Parameters

Parameter	Type	Description
(bac-complex-type)	Format: (tail-drop : <Qos::MaxThreshold> red : <Qos::MinThreshold> : <Qos::MaxThreshold> : <Qos::DiscardProbability> twocolour-taildrop : <Qos::MaxThreshold> : <Qos::MaxThresholdYellow> twocoloured : <Qos::MinThreshold> : <Qos::MaxThreshold> : <Qos::DiscardProbability> : <Qos::MinThresholdYellow> : <Qos::MaxThresholdYellow> : <Qos::DiscardProbYellow> gpon-tail-drop : <Qos::MinThreshold> : <Qos::MaxThreshold> threecolour-taildrop : <Qos::MaxThreshold> : <Qos::MaxThresholdYellow> : <Qos::MaxThresholdRed> threecolour-red : <Qos::MinThreshold> : <Qos::MaxThreshold> : <Qos::DiscardProbability> : <Qos::MinThresholdYellow> : <Qos::MaxThresholdYellow> : <Qos::DiscardProbYellow>	mandatory parameter buffer acceptance control algorithm

Parameter	Type	Description
	: <Qos::MinThresholdRed> : <Qos::MaxThresholdRed> : <Qos::DiscardProbRed> gpon-threecolour-red : <Qos::MinThreshold> : <Qos::MaxThreshold> : <Qos::DiscardProbability> : <Qos::MinThresholdYellow> : <Qos::MaxThresholdYellow> : <Qos::DiscardProbYellow> : <Qos::MinThresholdRed> : <Qos::MaxThresholdRed> : <Qos::DiscardProbRed> : <Qos::MinQueueSize> : <Qos::MaxQueueSize>) Possible values: - tail-drop : tail drop algorithm - red : random early detection algorithm - twocolour-taildrop : colour-aware tail drop algorithm - twocoloured : colour-aware random early detection algorithm - gpon-tail-drop : gpon tail drop algorithm - threecolour-taildrop : three colour aware tail drop algorithm - threecolour-red : three colour aware random early detection algorithm - gpon-threecolour-red : three colour aware random early detection algorithm with min and max queue sizes Field type <Qos::MinThreshold> - min threshold of green frames or min threshold of frames for RED type or min queue size for gpon-tail-drop: if unit is packet,range:[1..1048574] for gpon, [1..1398100] for non gpon,[1..681] for DSL,[1..1999] for ngvr; if unit is byte,range is [1..2147483646] for fibre bactypes,[1..1048575] for DSL bactypes,[1..3000319] for ngvr bactypes - range: [1...2147483646] Field type <Qos::MaxThreshold> - max threshold of green frames or max threshold of frames for RED type or max queue size for tail-drop/gpon-tail-drop: if unit is packet,range:[2..1048575] for gpon, [2..1398101] for non gpon,[2..682] for DSL, [2..2000] for ngvr;if unit is byte,range is [2..2147483647] for fibre bactypes, [2..1048576] for DSL bactypes; [2..3000320] for ngvr bactypes - range: [2...2147483647] Field type <Qos::DiscardProbability> - maximum discard probability of green frames - unit: % - range: [0...100] Field type <Qos::MinThresholdYellow> - min threshold for yellow frames: if unit is packet,range:[1..1048574] for gpon, [1..1398100] for non gpon,[1..681] for DSL,[1..1999] for ngvr; if unit is byte,range is [1..2147483646] for fibre bactypes,[1..1048575] for DSL bactypes,[1..3000319] for ngvr bactypes - range: [1...2147483646] Field type <Qos::MaxThresholdYellow> - max threshold for yellow frames: if unit is packet,range:[2..1048575] for gpon, [2..1398101] for non gpon,[2..682] for DSL, [2..2000] for ngvr;if unit is byte,range is [2..2147483647] for fibre bactypes,	

21 QoS Configuration Commands

Parameter	Type	Description
	[2..1048576] for DSL bactypes; [2..3000320] for ngvr bactypes - range: [2...2147483647] Field type <Qos::DiscardProbYellow> - maximum discard probability of yellow frames - unit: % - range: [0...100] Field type <Qos::MinThresholdRed> - min threshold for red frames: if unit is packet,range:[1..1048574] for gpon, [1..1398100] for non gpon,[1..681] for DSL,[1..1999] for ngvr; if unit is byte,range is [1..2147483646] for fibre bactypes,[1..1048575] for DSL bactypes,[1..3000319] for ngvr bactypes - range: [1...2147483646] Field type <Qos::MaxThresholdRed> - max threshold for red frames: if unit is packet,range:[2..1048575] for gpon, [2..1398101] for non gpon,[2..682] for DSL, [2..2000] for ngvr;if unit is byte,range is [2..2147483647] for fibre bactypes, [2..1048576] for DSL bactypes; [2..3000320] for ngvr bactypes - range: [2...2147483647] Field type <Qos::DiscardProbRed> - maximum discard probability of red frames - unit: % - range: [0...100] Field type <Qos::MinQueueSize> - minimum guaranteed queue size : if unit is packet,range:[1..1048574] for gpon, [1..1398100] for non gpon,[1..1999] for ngvr; if unit is byte,range is [1..2147483646] for fibre bactypes,[1..3000319] for ngvr bactypes - range: [1...2147483646] Field type <Qos::MaxQueueSize> - maximum queue size: if unit is packet,range:[2..1048575] for gpon, [2..1398101] for non gpon,[2..2000] for ngvr;if unit is byte,range is [2..2147483647] for fibre bactypes,[2..3000320] for ngvr bactypes - range: [2...2147483647]	
[no] unit	Parameter type: <Qos::Units> Format: (packet byte) Possible values: - packet : the unit of discard threshold is packet - byte : the unit of discard threshold is byte	<i>optional parameter with default value: "packet"</i> identify the threshold unit type

21.8 QoS Scheduler Node Profile Configuration Command

Command Description

This command allows the operator to configure a QoS scheduler node profile. The scheduler node profiles contain configuration settings for the data plane schedulers. These scheduler node profiles are applicable to downstream schedulers on the L3 line cards. The scheduler node settings on the service hub can be modified separately.

User Level

The command can be accessed by operators with qos privileges, and executed by operators with qos privileges.

Command Syntax

The command has the following syntax:

```
> configure qos profiles ( no scheduler-node (name) ) | ( scheduler-node (name) priority <Qos::QosPriority> weight
<Qos::QosWeight> shaper-profile <Qos::QosShaperProfileName> [ no ext-shaper | ext-shaper
<Qos::QosShaperProfileName> ] [ no mcast-inc-shape | mcast-inc-shape <Qos::QosMulticastInclShaping> ] )
```

Command Parameters

Table 21.8-1 "QoS Scheduler Node Profile Configuration Command" Resource Parameters

Resource Identifier	Type	Description
(name)	Format: - a profile name - range: [a-zA-Z0-9-_.] - length: 1<=x<=32	A unique profile name

Table 21.8-2 "QoS Scheduler Node Profile Configuration Command" Command Parameters

Parameter	Type	Description
priority	Parameter type: <Qos::QosPriority> Format: - relative priority - range: [1...8]	mandatory parameter relative priority of the scheduler-node
weight	Parameter type: <Qos::QosWeight> Format: - relative weight - range: [0...127]	mandatory parameter relative weight of the scheduler-node
shaper-profile	Parameter type: <Qos::QosShaperProfileName> Format: (none name : <Qos::IgnoredQosProfileName>) Possible values: - none : no profile name to associated - name : enter profile name to be associated	mandatory parameter the associated shaper profile. For EPON OLT in downstream, this profile used for LLID shaper on 1G PON bandwidth.

21 QoS Configuration Commands

Parameter	Type	Description
	Data driven field type Possible values are depending on the actual configuration and software. The currently allowed values can be shown with online-help.	
[no] ext-shaper	Parameter type: <Qos::QosShaperProfileName> Format: (none name : <Qos::IgnoredQosProfileName>) Possible values: - none : no profile name to associated - name : enter profile name to be associated Data driven field type Possible values are depending on the actual configuration and software. The currently allowed values can be shown with online-help.	<i>optional parameter with default value: "none"</i> the associated shaper profile. For EPON OLT in downstream, this profile used for LLID shaper on 10G PON bandwidth.
[no] mcast-inc-shape	Parameter type: <Qos::QosMulticastInclShaping> Format: (mcast-shap-on no-mcast-shap) Possible values: - mcast-shap-on : Downstream shaping includes Mcast - no-mcast-shap : Downstream shaping doesnot include Mcast	<i>optional parameter with default value: "false"</i> indicates whether downstream shaping includes Mcast

21.9 QoS CAC Profile Configuration Command

Command Description

This command allows the operator to configure a connection admission control (CAC) profile. CAC profiles are used primarily for multicast video admission control. CAC profiles can be attached to subscriber interfaces. The scope of a CAC profile is a DSL link (and not a PVC), regardless of the number of PVCs on a DSL link.

The system derives the line rate from the physical interfaces and calculates an estimate of the available Ethernet bandwidth using configurable overhead factors. The line rate taken into account may be the guaranteed sync rate or the actual line rate in case of DSL, based on a global configuration setting.

From this bandwidth, a part can be reserved for voice and data applications and the remaining part will be kept by the system as the available bandwidth for multicast video. Only preconfigured multicast streams are considered for CAC. Note that unicast video (regardless of whether it is premium content or generic Internet streaming video) is ignored by the CAC function.

The maximum bandwidth that video will occupy can be further confined using the maximum multicast bandwidth 'max-mcast-bandwidth' parameter.

CAC profiles are applicable to line cards, but not to SHub/IHub interfaces.

User Level

The command can be accessed by operators with qos privileges, and executed by operators with qos privileges.

Command Syntax

The command has the following syntax:

```
> configure qos profiles ( no cac (name) ) | ( cac (name) res-voice-bandwidth <Qos::BandWidthKBPS>
max-mcast-bandwidth <Qos::BandWidthKBPS> res-data-bandwidth <Qos::BandWidthKBPS> [ no cac-type |
cac-type <Qos::QosCacType> ] )
```

Command Parameters

Table 21.9-1 "QoS CAC Profile Configuration Command" Resource Parameters

Resource Identifier	Type	Description
(name)	Format: - a profile name - range: [a-zA-Z0-9-_.] - length: 1<=x<=32	A unique profile name

Table 21.9-2 "QoS CAC Profile Configuration Command" Command Parameters

Parameter	Type	Description
res-voice-bandwidth	Parameter type: <Qos::BandWidthKBPS> Format: - interface bandwidth - unit: kbps - range: [0...2147483647]	mandatory parameter reserved bandwidth for the voice services
max-mcast-bandwidth	Parameter type: <Qos::BandWidthKBPS>	mandatory parameter

21 QoS Configuration Commands

Parameter	Type	Description
	Format: - interface bandwidth - unit: kbps - range: [0...2147483647]	maximum allowed bandwidth for multicast and unicast video service
res-data-bandwidth	Parameter type: <Qos::BandWidthKBPS> Format: - interface bandwidth - unit: kbps - range: [0...2147483647]	<i>mandatory parameter</i> reserved bandwidth for all data services
[no] cac-type	Parameter type: <Qos::QosCacType> Format: (dsl-cac pon-cac generic-pon-cac) Possible values: - dsl-cac : cac profile for dsl links - pon-cac : cac profile for pon interfaces obsolete alternative replaced by generic-pon-cac - generic-pon-cac : cac profile for epon gpon and ngpon2 interfaces	<i>optional parameter with default value: "dsl-cac"</i> cac-profile type

21.10 QoS Single Dot1P Marker Configuration Command

Command Description

This command allows the operator to configure a marker for singleDot1P.

User Level

The command can be accessed by operators with qos privileges, and executed by operators with qos privileges.

Command Syntax

The command has the following syntax:

```
> configure qos profiles marker ( no d1p (name) ) | ( d1p (name) default-dot1p <Qos::ExtVlanSysPrio> )
```

Command Parameters

Table 21.10-1 "QoS Single Dot1P Marker Configuration Command" Resource Parameters

Resource Identifier	Type	Description
(name)	Format: - a profile name - range: [a-zA-Z0-9-_.] - length: 1<=x<=32	A unique profile name

Table 21.10-2 "QoS Single Dot1P Marker Configuration Command" Command Parameters

Parameter	Type	Description
default-dot1p	Parameter type: <Qos::ExtVlanSysPrio> Format: - the dot-1p bit value - range: [0...7]	<i>mandatory parameter</i> the default dot-1p bit value to be applied on all frames

21.11 QoS Single DSCP Marker Configuration Command

Command Description

This command allows the operator to configure a marker for a single DSCP.

All IP packets will be marked with the specified DSCP value. This marker type is incompatible with DSCP to P-bits alignment.

User Level

The command can be accessed by operators with qos privileges, and executed by operators with qos privileges.

Command Syntax

The command has the following syntax:

```
> configure qos profiles marker ( no dscp (name) ) | ( dscp (name) default-dscp  
<Qos::DscpToDot1PAlignmentDscpIndex> [ [ no ] alignment ] )
```

Command Parameters

Table 21.11-1 "QoS Single DSCP Marker Configuration Command" Resource Parameters

Resource Identifier	Type	Description
(name)	Format: - a profile name - range: [a-zA-Z0-9-_.] - length: 1<=x<=32	A unique profile name

Table 21.11-2 "QoS Single DSCP Marker Configuration Command" Command Parameters

Parameter	Type	Description
default-dscp	Parameter type: <Qos::DscpToDot1PAlignmentDscpIndex> Format: - the DSCP value - range: [0...63]	<i>mandatory parameter</i> the default DSCP value to be applied on all frames
[no] alignment	Parameter type: boolean	<i>optional parameter</i> enable DSCP to P-bits alignment

21.12 QoS DSCP Contract Table Marker Configuration Command

Command Description

This command allows the operator to configure a marker for a DSCP contract table. To configure the DSCP codepoints in the contract table, the command "**configure qos profiles marker dscp-contract (name) codepoint (codepoint)**" is to be used.

User Level

The command can be accessed by operators with qos privileges, and executed by operators with qos privileges.

Command Syntax

The command has the following syntax:

```
> configure qos profiles marker ( no dscp-contract (name) ) | ( dscp-contract (name) [ [ no ] alignment ] )
```

Command Parameters

Table 21.12-1 "QoS DSCP Contract Table Marker Configuration Command" Resource Parameters

Resource Identifier	Type	Description
(name)	Format: - a profile name - range: [a-zA-Z0-9-_.] - length: 1<=x<=32	A unique profile name

Table 21.12-2 "QoS DSCP Contract Table Marker Configuration Command" Command Parameters

Parameter	Type	Description
[no] alignment	Parameter type: boolean	<i>optional parameter</i> enable DSCP to P-bits alignment

21.13 QoS DSCP Contract Table Code-point Configuration Command For DSCP-contract

Command Description

*This command allows the operator to configure codepoints in the DSCP contract table. To configure a marker, use the command "**configure qos profiles marker dscp-contract (name)**".*

User Level

The command can be accessed by operators with qos privileges, and executed by operators with qos privileges.

Command Syntax

The command has the following syntax:

```
> configure qos profiles marker dscp-contract (name) codepoint (codepoint) [ no dscp-value | dscp-value <Qos::DscpToDot1PAlignmentDscpIndex> ]
```

Command Parameters

Table 21.13-1 "QoS DSCP Contract Table Code-point Configuration Command For DSCP-contract" Resource Parameters

Resource Identifier	Type	Description
(name)	Format: - a profile name - range: [a-zA-Z0-9-_.] - length: 1<=x<=32	A unique profile name
(codepoint)	Format: - the number of the DSCP codepoint - range: [0...63]	the value of the codepoint

Table 21.13-2 "QoS DSCP Contract Table Code-point Configuration Command For DSCP-contract" Command Parameters

Parameter	Type	Description
[no] dscp-value	Parameter type: <Qos::DscpToDot1PAlignmentDscpIndex> Format: - the DSCP value - range: [0...63]	<i>optional parameter with default value: 0L</i> the dscp value to be assigned to the codepoint

21.14 QoS Dot1P and DSCP Contract Table Marker Configuration Command

Command Description

This command allows the operator to configure a marker for Dot1P and a DSCP contract table. To configure the DSCP codepoints in the contract table, the command "**configure qos profiles marker d1p-dscp-contract (name) codepoint (codepoint)**" is to be used.

User Level

The command can be accessed by operators with qos privileges, and executed by operators with qos privileges.

Command Syntax

The command has the following syntax:

```
> configure qos profiles marker ( no d1p-dscp-contract (name) ) | ( d1p-dscp-contract (name) dot1p-value
<Qos::ExtVlanSysPrio> [ [ no ] alignment ] )
```

Command Parameters

Table 21.14-1 "QoS Dot1P and DSCP Contract Table Marker Configuration Command" Resource Parameters

Resource Identifier	Type	Description
(name)	Format: - a profile name - range: [a-zA-Z0-9-_.] - length: 1<=x<=32	A unique profile name

Table 21.14-2 "QoS Dot1P and DSCP Contract Table Marker Configuration Command" Command Parameters

Parameter	Type	Description
dot1p-value	Parameter type: <Qos::ExtVlanSysPrio> Format: - the dot-1p bit value - range: [0...7]	<i>mandatory parameter</i> the default dot-1p bit value to be applied on all frames
[no] alignment	Parameter type: boolean	<i>obsolete parameter that will be ignored</i> enable DSCP to P-bits alignment

21.15 DSCP Contract Table Codepoint Configuration Command For D1p-dscp-contract

Command Description

This command allows the operator to configure codepoints for a DSCP contract table. To configure a Dot1P and DSCP contract table, use the command "**configure qos profiles marker d1p-dscp-contract (name)**".

User Level

The command can be accessed by operators with qos privileges, and executed by operators with qos privileges.

Command Syntax

The command has the following syntax:

```
> configure qos profiles marker d1p-dscp-contract (name) codepoint (codepoint) [ no dscp-value | dscp-value
<Qos::DscpToDot1PAlignmentDscpIndex> ]
```

Command Parameters

Table 21.15-1 "DSCP Contract Table Codepoint Configuration Command For D1p-dscp-contract" Resource Parameters

Resource Identifier	Type	Description
(name)	Format: - a profile name - range: [a-zA-Z0-9-_.] - length: 1<=x<=32	A unique profile name
(codepoint)	Format: - the number of the DSCP codepoint - range: [0...63]	the number of the codepoint

Table 21.15-2 "DSCP Contract Table Codepoint Configuration Command For D1p-dscp-contract" Command Parameters

Parameter	Type	Description
[no] dscp-value	Parameter type: <Qos::DscpToDot1PAlignmentDscpIndex> Format: - the DSCP value - range: [0...63]	optional parameter with default value: 0L the dscp value to be assigned to the codepoint

21.16 QoS Dot1P and Single DSCP Marker Configuration Command

Command Description

This command allows the operator to configure a marker for Dot1P and single DSCP.

User Level

The command can be accessed by operators with qos privileges, and executed by operators with qos privileges.

Command Syntax

The command has the following syntax:

```
> configure qos profiles marker ( no d1p-dscp (name) ) | ( d1p-dscp (name) default-dscp
<Qos::DscpToDot1PAlignmentDscpIndex> default-dot1p <Qos::ExtVlanSysPrio> )
```

Command Parameters

Table 21.16-1 "QoS Dot1P and Single DSCP Marker Configuration Command" Resource Parameters

Resource Identifier	Type	Description
(name)	Format: - a profile name - range: [a-zA-Z0-9-_.] - length: 1<=x<=32	A unique profile name

Table 21.16-2 "QoS Dot1P and Single DSCP Marker Configuration Command" Command Parameters

Parameter	Type	Description
default-dscp	Parameter type: <Qos::DscpToDot1PAlignmentDscpIndex> Format: - the DSCP value - range: [0...63]	<i>mandatory parameter</i> the default DSCP value to be applied on all frames
default-dot1p	Parameter type: <Qos::ExtVlanSysPrio> Format: - the dot-1p bit value - range: [0...7]	<i>mandatory parameter</i> the default dot-1p bit value to be applied on all frames

21.17 QoS Dot1P Alignment Marker Configuration Command

Command Description

This command allows the operator to configure a marker for Dot1P alignment.

Default value for the global DSCP To Dot1P Alignment Table

DSCP Value	P-bit Value
0-7	0
8-15	1
16-23	2
24-31	3
32-39	4
40-47	5
48-55	6
56-63	7

User Level

The command can be accessed by operators with qos privileges, and executed by operators with qos privileges.

Command Syntax

The command has the following syntax:

```
> configure qos profiles marker ( no d1p-alignment (name) ) | ( d1p-alignment (name) (alignment) [ no  
dscp-pbit-prof | dscp-pbit-prof <Qos::QosDscpToPbitProfileName> ] )
```

Command Parameters

Table 21.17-1 "QoS Dot1P Alignment Marker Configuration Command" Resource Parameters

Resource Identifier	Type	Description
(name)	Format: - a profile name - range: [a-zA-Z0-9-_.] - length: 1<=x<=32	A unique profile name

Table 21.17-2 "QoS Dot1P Alignment Marker Configuration Command" Command Parameters

Parameter	Type	Description
(alignment)	Format:	mandatory parameter

Parameter	Type	Description
	enable Possible values: - enable : enable dot1p alignment	enable dot1p alignment
[no] dscp-pbit-prof	Parameter type: <Qos::QosDscpToPbitProfileName> Format: (none name : <Qos::IgnoredQosProfileName>) Possible values: - none : no profile name to associate - name : enter profile name to be associated Data driven field type Possible values are depending on the actual configuration and software. The currently allowed values can be shown with online-help.	<i>optional parameter with default value: "none"</i> Dscp to Pbit mapping profile name applicable on this marker

21.18 QoS Dot1P Remark Table Marker Configuration Command

Command Description

*This command allows the operator to configure a marker for a Dot1P Remark table. To configure the Dot1P Remark value in remark table, the command "**configure qos profiles marker dot1p-remark (name) dot1p-value (val) remark-value (val)**" is to be used.*

User Level

The command can be accessed by operators with qos privileges, and executed by operators with qos privileges.

Command Syntax

The command has the following syntax:

> configure qos profiles marker (no dot1p-remark (name)) | (dot1p-remark (name))

Command Parameters

Table 21.18-1 "QoS Dot1P Remark Table Marker Configuration Command" Resource Parameters

Resource Identifier	Type	Description
(name)	Format: - a profile name - range: [a-zA-Z0-9-_.] - length: 1<=x<=32	A unique profile name

21.19 QoS Dot1P Remark Table Dot1p-value Configuration Command For Dot1P-Remark

Command Description

This command allows the operator to configure remark dot1p value in the Dot1P Remark table. To configure the remark value in the Dot1P Remark table, use the command "**configure qos profiles marker dot1p-remark (name) dot1p-value (val) remark-value (val)**".

User Level

The command can be accessed by operators with qos privileges, and executed by operators with qos privileges.

Command Syntax

The command has the following syntax:

```
> configure qos profiles marker dot1p-remark (name) dot1p-value (dot1p-value) [ no remark-value | remark-value
<Qos::ExtVlanSysPrioNc> ]
```

Command Parameters

Table 21.19-1 "QoS Dot1P Remark Table Dot1p-value Configuration Command For Dot1P-Remark" Resource Parameters

Resource Identifier	Type	Description
(name)	Format: - a profile name - range: [a-zA-Z0-9-_.] - length: 1<=x<=32	A unique profile name
(dot1p-value)	Format: - the dot-1p bit value - range: [0...7]	the dot1p value

Table 21.19-2 "QoS Dot1P Remark Table Dot1p-value Configuration Command For Dot1P-Remark" Command Parameters

Parameter	Type	Description
[no] remark-value	Parameter type: <Qos::ExtVlanSysPrioNc> Format: - the remarked dot-1p bit value (8 means no change) - range: [0...8]	<i>optional parameter with default value: 8L</i> the remarked dot1p value

21.20 QoS Policer Profile Configuration Command

Command Description

This command allows the operator to configure a QoS policer profile. A QoS policer profile contains all settings related to a policer. The ISAM supports single token bucket policers, where the action upon conformance is either pass or discard.

The L3 line cards units support both upstream and downstream policing. A policer profile can be used within a QoS session profile for upstream and downstream policing.

The L2 line cards units do not support policing.

The SHub/IHub supports ingress policing, but it does not use policer profiles. See the section about the QoS Ingress Policing Configuration Command to set up ingress policing on the SHub/IHub.

User Level

The command can be accessed by operators with qos privileges, and executed by operators with qos privileges.

Command Syntax

The command has the following syntax:

```
> configure qos profiles ( no policer (name) ) | ( policer (name) committed-info-rate <Qos::CommittedInfoRate>
committed-burst-size <Qos::CommittedBurstSize> [ no policer-type | policer-type <Qos::PolicerType> ] [ no
excess-info-rate | excess-info-rate <Qos::ExcessInfoRate > ] [ no excess-burst-size | excess-burst-size
<Qos::ExcessBurstSize> ] [ no coupling-flag | coupling-flag <Qos::CouplingFlag> ] [ no color-mode | color-mode
<Qos::ColorMode> ] [ no green-action | green-action <Qos::GreenAction> ] [ no yellow-action | yellow-action
<Qos::YellowAction> ] [ no red-action | red-action <Qos::RedAction> ] [ no policed-size-ctrl | policed-size-ctrl
<Qos::PoliceFrameCtrl> ] [ no peak-info-rate | peak-info-rate <Qos::PeakInfoRate> ] [ no peak-burst-size |
peak-burst-size <Qos::PeakBurstSize> ] [ no cos-threshold | cos-threshold <Qos::QosCoSThresholdProfileName> ]
)
```

Command Parameters

Table 21.20-1 "QoS Policer Profile Configuration Command" Resource Parameters

Resource Identifier	Type	Description
(name)	Format: - a profile name - range: [a-zA-Z0-9-_.] - length: 1<=x<=32	A unique profile name

Table 21.20-2 "QoS Policer Profile Configuration Command" Command Parameters

Parameter	Type	Description
committed-info-rate	Parameter type: <Qos::CommittedInfoRate> Format: - information rate - unit: kbps - range: [0...2147483647]	<i>mandatory parameter</i> committed information rate of a policer

Parameter	Type	Description
committed-burst-size	Parameter type: <Qos::CommittedBurstSize> Format: - committed burst size of a policer - unit: bytes - range: [0...134217728]	<i>mandatory parameter</i> committed burst size of a policer
[no] policer-type	Parameter type: <Qos::PolicerType> Format: (single-token-bucket trtcm trtcmwithcosrfc2698 trtcmwithcosrfc4115) Possible values: - single-token-bucket : single token bucket - trtcm : trtcm Policer - trtcmwithcosrfc2698 : trTCMwithCoS RFC2698 policer - trtcmwithcosrfc4115 : trTCMwithCoS RFC4115 policer	<i>optional parameter with default value: "single-token-bucket"</i> The parameter is not visible during modification. the policer type
[no] excess-info-rate	Parameter type: <Qos::ExcessInfoRate > Format: - information rate - unit: kbps - range: [0...2147483647]	<i>optional parameter with default value: 0</i> excess information rate of a policer for trtcm
[no] excess-burst-size	Parameter type: <Qos::ExcessBurstSize> Format: - excess burst size of a policer - unit: bytes - range: [0...134217728]	<i>optional parameter with default value: 64</i> excess burst size of a policer for trtcm
[no] coupling-flag	Parameter type: <Qos::CouplingFlag> Format: (enable disable) Possible values: - enable : enable - disable : disable	<i>optional parameter with default value: "disable"</i> the coupling flag of a policer for trtcm
[no] color-mode	Parameter type: <Qos::ColorMode> Format: (color-blind color-aware) Possible values: - color-blind : color blind mode - color-aware : color aware mode	<i>optional parameter with default value: "color-blind"</i> the color mode of a policer for trtcm
[no] green-action	Parameter type: <Qos::GreenAction> Format: (pass remark : <Aaa::IgnoredQosProfileName> setouterdei) Possible values: - pass : pass - remark : remark - setouterdei : setOuterDEI Data driven field type Possible values are depending on the actual configuration and software. The currently allowed values can be shown with online-help.	<i>optional parameter with default value: "pass"</i> action for green packet of a policer for trtcm, marker profile for green packet
[no] yellow-action	Parameter type: <Qos::YellowAction> Format: (pass discard	<i>optional parameter with default value: "pass"</i> action for yellow packet of a policer for trtcm, marker profile

21 QoS Configuration Commands

Parameter	Type	Description
	remark : <Aaa::IgnoredQosProfileName> setouterdei) Possible values: - pass : pass - discard : discard - remark : remark - setouterdei : setOuterDEI Data driven field type Possible values are depending on the actual configuration and software. The currently allowed values can be shown with online-help.	for yellow packet
[no] red-action	Parameter type: <Qos::RedAction> Format: (pass discard remark : <Aaa::IgnoredQosProfileName> setouterdei) Possible values: - pass : pass - discard : discard - remark : remark - setouterdei : setOuterDEI Data driven field type Possible values are depending on the actual configuration and software. The currently allowed values can be shown with online-help.	<i>optional parameter with default value: "discard"</i> action for red packet of a policer for trtcm, marker profile for red packet
[no] policed-size-ctrl	Parameter type: <Qos::PoliceFrameCtrl> Format: (auto-controlled ingress-mode egress-mode rmv4b-ingress) Possible values: - auto-controlled : backward compatibility for all LTs - ingress-mode : policer working with ingress packet size - egress-mode : policer working with egress packet size - rmv4b-ingress : policer working on packet size with 4 bytes removed from ingress	<i>optional parameter with default value: "auto-controlled"</i> control for policed frame size
[no] peak-info-rate	Parameter type: <Qos::PeakInfoRate> Format: - peak information rate, for RFC2698 - unit: kbps - range: [0...2147483647]	<i>optional parameter with default value: 0</i> peak information rate of a policer for trtcm
[no] peak-burst-size	Parameter type: <Qos::PeakBurstSize> Format: - peak burst size of a policer, for RFC2698 - unit: bytes - range: [0...134217728]	<i>optional parameter with default value: 0</i> peak burst size of a policer for trtcm
[no] cos-threshold	Parameter type: <Qos::QosCoSThresholdProfileName> Format: (none name : <Qos::IgnoredQosProfileName>) Possible values: - none : no profile name to associate - name : enter profile name to be associated Data driven field type Possible values are depending on the actual configuration	<i>optional parameter with default value: "none"</i> cos threshold profile name applicable on the profile

Parameter	Type	Description
	and software. The currently allowed values can be shown with online-help.	

21.21 QoS L2 Filter Profile Configuration Command

Command Description

This command allows the operator to configure an L2 filter. The created L2 filter can be reused to build policy actions based on L2 filtering criteria, inside QoS session profiles.

User Level

The command can be accessed by operators with qos privileges, and executed by operators with qos privileges.

Command Syntax

The command has the following syntax:

```
> configure qos profiles ( no l2-filter (name) ) | ( l2-filter (name) [ no dst-mac-addr | dst-mac-addr
<Qos::MacAddrAndMask> ] [ no src-mac-addr | src-mac-addr <Qos::MacAddrAndMask> ] [ no ethertype |
ethertype <Qos::FilterEthernetType> ] [ no dot1p-priority | dot1p-priority <Qos::MatchDot1pValue> ] [ no
canonical-format | canonical-format <Qos::FilterCfi> ] [ no vlan-id | vlan-id <Qos::FilterVlanId> ] )
```

Command Parameters

Table 21.21-1 "QoS L2 Filter Profile Configuration Command" Resource Parameters

Resource Identifier	Type	Description
(name)	Format: - a profile name - range: [a-zA-Z0-9-_.] - length: 1<=x<=32	A unique profile name

Table 21.21-2 "QoS L2 Filter Profile Configuration Command" Command Parameters

Parameter	Type	Description
[no] dst-mac-addr	Parameter type: <Qos::MacAddrAndMask> Format: <Qos::MacAddress> / <Qos::MacPrefixLength> Field type <Qos::MacAddress> - a mac-address (example : 01:02:03:04:05:06) - length: 6 Field type <Qos::MacPrefixLength> - the mac address prefix length - range: [0...48]	optional parameter with default value: "00 : 00 : 00 : 00 : 00 : 00/0" destination mac address to be matched with the packet
[no] src-mac-addr	Parameter type: <Qos::MacAddrAndMask> Format: <Qos::MacAddress> / <Qos::MacPrefixLength> Field type <Qos::MacAddress> - a mac-address (example : 01:02:03:04:05:06) - length: 6 Field type <Qos::MacPrefixLength> - the mac address prefix length - range: [0...48]	optional parameter with default value: "00 : 00 : 00 : 00 : 00 : 00/0" source mac address to be matched with the packet

Parameter	Type	Description
[no] ethertype	Parameter type: <Qos::FilterEthernetType> Format: (ip x75 nbs ecma chaos x25 arp rarp appletalk snmp loopback pppoe-discovery pppoe ipv6 all <Qos::EtherType>) Possible values: - ip : ip - x75 : x75 - nbs : nbs - ecma : ecma - chaos : chaos - x25 : x25 - arp : arp - rarp : rarp - appletalk : appletalk - snmp : snmp - loopback : loopback - pppoe-discovery : pppoe-discovery - pppoe : pppoe - ipv6 : ipv6 - all : all ethtype values are considered a match Field type <Qos::EtherType> - ethertype value - range: [-1...65535]	<i>optional parameter with default value: "all"</i> ethernet type to be matched with the packet
[no] dot1p-priority	Parameter type: <Qos::MatchDot1pValue> Format: - dot1p value to be matched, -1 means match all - range: [-1...7]	<i>optional parameter with default value: -1L</i> dot1p value to be matched, -1 means match all
[no] canonical-format	Parameter type: <Qos::FilterCfi> Format: - canonical format indicator, -1 means match all - range: [-1...1]	<i>optional parameter with default value: -1L</i> canonical format indicator, -1 means match all
[no] vlan-id	Parameter type: <Qos::FilterVlanId> Format: - vlan id to be matched, -1 means match all - range: [-1...4095]	<i>optional parameter with default value: -1L</i> vlan id to be matched, -1 means match all

21.22 QoS L3 Filter Profile Configuration Command

Command Description

This command allows the operator to configure an L3 filter. The created L3 filter can be reused to build policy actions based on L3 filtering criteria, inside QoS session profiles.

DSCP mask is supported with defined L3-filter name with a prefix "DSCPMASKx_", 'x' must be 1~6, which means treat dscp-value as a last 'x' bits masking -The first 8 characters are UPPER CASE ALPHABETIC = DSCPMASK; and -The 9 character is NUMERICAL = {1, 2, 3, 4, 5, 6}; and -The 10 character is UNDERSCORE; -the remaining is configurable.

User Level

The command can be accessed by operators with qos privileges, and executed by operators with qos privileges.

Command Syntax

The command has the following syntax:

```
> configure qos profiles ( no l3-filter (name) ) | ( l3-filter (name) [ no filter-type | filter-type <Qos::L3FilterType> ]
[ no dst-ip-addr | dst-ip-addr <Ip::AddressAndMaskFull> ] [ no src-ip-addr | src-ip-addr
<Ip::AddressAndMaskFull> ] [ no dst-ipv6-addr | dst-ipv6-addr <ipv6::PrefixAndLength> ] [ no src-ipv6-addr |
src-ipv6-addr <ipv6::PrefixAndLength> ] [ no min-dst-port | min-dst-port <Qos::L4PortNumber> ] [ no
max-dst-port | max-dst-port <Qos::L4PortNumber> ] [ no min-src-port | min-src-port <Qos::L4PortNumber> ] [ no
max-src-port | max-src-port <Qos::L4PortNumber> ] [ no dscp-value | dscp-value <Qos::MatchDscpValue> ] [ no
protocol | protocol <Qos::Protocol> ] )
```

Command Parameters

Table 21.22-1 "QoS L3 Filter Profile Configuration Command" Resource Parameters

Resource Identifier	Type	Description
(name)	Format: - a profile name - range: [a-zA-Z0-9-_.] - length: 1<=x<=32	A unique profile name

Table 21.22-2 "QoS L3 Filter Profile Configuration Command" Command Parameters

Parameter	Type	Description
[no] filter-type	Parameter type: <Qos::L3FilterType> Format: (ipv4 ipv6) Possible values: - ipv4 : ipv4 - ipv6 : ipv6	optional parameter with default value: "ipv4" The parameter is not visible during modification. L3 Filter type. Indicates to what kind of ip frames (ipv4 or ipv6) the L3 filter is applicable.
[no] dst-ip-addr	Parameter type: <Ip::AddressAndMaskFull> Format: <Ip::V4Address> / <Ip::PrefixLengthFull>	optional parameter with default value: "0.0.0.0/0" destination ipv4 address to be

Parameter	Type	Description
	Field type <Ip::V4Address> - IPv4-address Field type <Ip::PrefixLengthFull> - IP address prefix length - range: [0...32]	matched with the packet. Only applicable in case filterType is equal to ipv4.
[no] src-ip-addr	Parameter type: <Ip::AddressAndMaskFull> Format: <Ip::V4Address> / <Ip::PrefixLengthFull> Field type <Ip::V4Address> - IPv4-address Field type <Ip::PrefixLengthFull> - IP address prefix length - range: [0...32]	<i>optional parameter with default value: "0.0.0.0/0"</i> source ipv4 address to be matched with the packet. Only applicable in case filterType is equal to ipv4.
[no] dst-ipv6-addr	Parameter type: <ipv6::PrefixAndLength> Format: <ipv6::Prefix> / <ipv6::PrefixLength> Field type <ipv6::Prefix> - IPv6-address Field type <ipv6::PrefixLength> - length of IPv6 address or prefix - range: [0...128]	<i>optional parameter with default value: ":::0"</i> destination ipv6 address to be matched with the packet. Only applicable in case filterType is equal to ipv6.
[no] src-ipv6-addr	Parameter type: <ipv6::PrefixAndLength> Format: <ipv6::Prefix> / <ipv6::PrefixLength> Field type <ipv6::Prefix> - IPv6-address Field type <ipv6::PrefixLength> - length of IPv6 address or prefix - range: [0...128]	<i>optional parameter with default value: ":::0"</i> source ipv6 address to be matched with the packet. Only applicable in case filterType is equal to ipv6.
[no] min-dst-port	Parameter type: <Qos::L4PortNumber> Format: - the layer-4 port number - range: [0...65535]	<i>optional parameter with default value: 0L</i> minimum value of the layer-4 destination port number
[no] max-dst-port	Parameter type: <Qos::L4PortNumber> Format: - the layer-4 port number - range: [0...65535]	<i>optional parameter with default value: 65535L</i> maximum value of the layer-4 destination port number
[no] min-src-port	Parameter type: <Qos::L4PortNumber> Format: - the layer-4 port number - range: [0...65535]	<i>optional parameter with default value: 0L</i> minimum value of the layer-4 source port number
[no] max-src-port	Parameter type: <Qos::L4PortNumber> Format: - the layer-4 port number - range: [0...65535]	<i>optional parameter with default value: 65535L</i> maximum value of the layer-4 source port number
[no] dscp-value	Parameter type: <Qos::MatchDscpValue> Format: - dscp value to be matched, -1 means match all - range: [-1...63]	<i>optional parameter with default value: -1L</i> dscp value to be matched, -1 means match all
[no] protocol	Parameter type: <Qos::Protocol> Format: (egp eigrp gre icmp icmpv6 igmp	<i>optional parameter with default value: "all"</i> protocol to be matched with the packet

21 QoS Configuration Commands

Parameter	Type	Description
	igrp ip ipinip ipv6 ipv6-frag ipv6-hopopt ipv6-nonxt ipv6-opts ipv6-route ospf-igp tcp udp rsvp all <Qos::ProtocolType>) Possible values: - egp : egp (IANA protocol number 8) - eigrp : eigrp (IANA protocol number 88) - gre : gre (IANA protocol number 47) - icmp : icmp (IANA protocol number 1) - icmpv6 : icmpv6 (IANA protocol number 58) - igmp : igmp (IANA protocol number 2) - igrp : igrp (IANA protocol number 9) - ip : ip (IANA protocol number 4) - ipinip : ipinip(protocol id should be 94) - ipv6 : ipv6 (IANA protocol number 41) - ipv6-frag : ipv6-frag (IANA protocol number 44) - ipv6-hopopt : ipv6-HOPOPT (IANA protocol number 0) - ipv6-nonxt : ipv6-NoNxt (IANA protocol number 59) - ipv6-opts : ipv6-opts (IANA protocol number 60) - ipv6-route : ipv6-route (IANA protocol number 43) - ospf-igp : ospf-igp (IANA protocol number 89) - tcp : tcp (IANA protocol number 6) - udp : udp (IANA protocol number 17) - rsvp : rsvp (IANA protocol number 46) - all : all are considered as match Field type <Qos::ProtocolType> - ip protocol value - range: [0...255]	

21.23 QoS Policy Action Profile Configuration Command

Command Description

This command allows the operator to configure a QoS policy action profile. A QoS policy action contains: discard packet, set a DSCP value, set a Dot1P value, policing with a policer, policer sharing, count attribute.

Dot1P and DSCP values are set to frames matched by the filter associated with this policy action.

The forwarding action for the frames matched by the filter can be discard or pass. The default forwarding action is pass. When the forwarding action is discard, the other policy actions in this entry will not be checked; the frame will be discarded immediately.

Policy sharing causes multiple QoS subflow with the same policy action profile to share their policer instance, in case they are set up within the same session profile in the same direction.

Count configures whether the traffic classified by filter needs to be counted. Count means enable to count the traffic classified by filter, no count means disable to count the traffic classified by the filter. Default value is no count.

User Level

The command can be accessed by operators with qos privileges, and executed by operators with qos privileges.

Command Syntax

The command has the following syntax:

```
> configure qos profiles ( no policy-action (name) ) | ( policy-action (name) [ no dscp-value | dscp-value
<Qos::SetDscpValue> ] [ no dot1p-value | dot1p-value <Qos::SetDot1pValue> ] [ [ no ] discard-packet ] [ [ no ]
shared-policer ] [ no policer-profile | policer-profile <Qos::QosPolicerProfileName> ] [ [ no ] count ] [ no
mirror-vlan | mirror-vlan <Qos::PolicyActionMirrorVlan> ] [ no tc-value | tc-value <Qos::tcvalue> ] )
```

Command Parameters

Table 21.23-1 "QoS Policy Action Profile Configuration Command" Resource Parameters

Resource Identifier	Type	Description
(name)	Format: - a profile name - range: [a-zA-Z0-9-_.] - length: 1<=x<=32	A unique profile name

Table 21.23-2 "QoS Policy Action Profile Configuration Command" Command Parameters

Parameter	Type	Description
[no] dscp-value	Parameter type: <Qos::SetDscpValue> Format: - dscp value set in a matched packet, -1 means no change - range: [-1...63]	optional parameter with default value: -1L dscp value set in a matched packet, -1 means no change

21 QoS Configuration Commands

Parameter	Type	Description
[no] dot1p-value	Parameter type: <Qos::SetDot1pValue> Format: - dot1p value set in a matched packet, -1 means no change - range: [-1...7]	<i>optional parameter with default value: -1L</i> dot1p value set in a matched packet, -1 means no change
[no] discard-packet	Parameter type: boolean	<i>optional parameter</i> discard the packet matching the policy
[no] shared-policer	Parameter type: boolean	<i>optional parameter</i> enable the sharing policer instances among subflows
[no] policer-profile	Parameter type: <Qos::QosPolicerProfileName> Format: (none name : <Qos::IgnoredQosProfileName>) Possible values: - none : no profile name to associate - name : enter profile name to be associated Data driven field type Possible values are depending on the actual configuration and software. The currently allowed values can be shown with online-help.	<i>optional parameter with default value: "none"</i> policer used to the packet matching the policy
[no] count	Parameter type: boolean	<i>optional parameter</i> enable to count traffic classified by filter
[no] mirror-vlan	Parameter type: <Qos::PolicyActionMirrorVlan> Format: - vlan id for mirror, 0 means no mirror - range: [0...4093]	<i>optional parameter with default value: 0L</i> vlan id for mirror, 0 means no mirror
[no] tc-value	Parameter type: <Qos::tcvalue> Format: - traffic class value range - range: [-1...7]	<i>optional parameter with default value: -1L</i> tc value to map the queue for matched packet, -1 means no change

21.24 QoS Policy Profile Configuration Command

Command Description

This command allows the operator to configure a QoS policy profile. A policy rule groups together a policy condition (filter) with a set of associated actions. A policy rule contains:

- Filter type (L2 filter or L3 filter)
- L2 or L3 filter
- Precedence of this policy rule
- Policy action

User Level

The command can be accessed by operators with qos privileges, and executed by operators with qos privileges.

Command Syntax

The command has the following syntax:

```
> configure qos profiles ( no policy (name) ) | ( policy (name) filter <Qos::PolicyFilter> [ no precedence |
precedence <Qos::PolicyPrecedence> ] [ no policy-action | policy-action <Qos::QosPolicyActionProfileName> ] )
```

Command Parameters

Table 21.24-1 "QoS Policy Profile Configuration Command" Resource Parameters

Resource Identifier	Type	Description
(name)	Format: - a profile name - range: [a-zA-Z0-9-_.] - length: 1<=x<=32	A unique profile name

Table 21.24-2 "QoS Policy Profile Configuration Command" Command Parameters

Parameter	Type	Description
filter	Parameter type: <Qos::PolicyFilter> Format: (l2-name : <Qos::IgnoredQosProfileName> l3-name : <Qos::IgnoredQosProfileName>) Possible values: - l2-name : refer to a l2 filter - l3-name : refer to a l3 filter Data driven field type Possible values are depending on the actual configuration and software. The currently allowed values can be shown with online-help. Data driven field type Possible values are depending on the actual configuration and software. The currently allowed values can be shown with online-help.	<i>mandatory parameter</i> the filter for the policy rule

21 QoS Configuration Commands

Parameter	Type	Description
[no] precedence	Parameter type: <Qos::PolicyPrecedence> Format: - the precedence value of the policy rule - range: [0...255]	<i>optional parameter with default value: 10L</i> precedence value of the policy rule
[no] policy-action	Parameter type: <Qos::QosPolicyActionProfileName> Format: (none name : <Qos::IgnoredQosProfileName>) Possible values: - none : no profile name to associate - name : enter profile name to be associated Data driven field type Possible values are depending on the actual configuration and software. The currently allowed values can be shown with online-help.	<i>optional parameter with default value: "none"</i> policy action profile applicable for the policy

21.25 QoS Session Profile Configuration Command

Command Description

This command allows the operator to configure the QoS session profile. The QoS session profile is the main building block for conveying user traffic contractual rights and treatment. The QoS session profile is a "macro"-profile, which consists of individual settings as well as references to smaller profiles.

A QoS session profile is composed of

- a logical flow type,
- a marker profile,
- two policer profiles for up and downstream policing,
- two lists for upstream and downstream policy conditions and actions.
- tag selection for downstream scheduler.

The logical flow type is a legacy parameter which is ignored. Any value is interpreted as "Generic", that is, the QoS session profile can be attached to any interface. If the QoS session profile contains settings that are not supported on the interface, then these are silently ignored by the system.

User Level

The command can be accessed by operators with qos privileges, and executed by operators with qos privileges.

Command Syntax

The command has the following syntax:

```
> configure qos profiles ( no session (name) ) | ( session (name) logical-flow-type <Qos::LogicalFlowType> [ no
up-policer | up-policer <Qos::QosPolicerProfileName> ] [ no down-policer | down-policer
<Qos::QosPolicerProfileName> ] [ no up-marker | up-marker <Qos::QosMarkerProfileName> ] [ no
ing-outer-marker | ing-outer-marker <Qos::QosMarkerProfileName> ] [ no ds-schedule-tag | ds-schedule-tag
<Qos::DsSchedulerProfileTag> ] [ no up-policer-per-tc | up-policer-per-tc <Qos::QosPolicerPerTCProfileName> ]
[ no up-dscptotc-prof | up-dscptotc-prof <Qos::QosDscpToTcProfileName> ] [ no dn-dscptotc-prof |
dn-dscptotc-prof <Qos::QosDscpToTcProfileName> ] [ no up-pbittotc-prof | up-pbittotc-prof
<Qos::QosPbitToTcProfileName> ] [ no dn-pbittotc-prof | dn-pbittotc-prof <Qos::QosPbitToTcProfileName> ] [ no
up-default-tc | up-default-tc <Qos::tcvalue> ] [ no dn-default-tc | dn-default-tc <Qos::tcvalue> ] )
```

Command Parameters

Table 21.25-1 "QoS Session Profile Configuration Command" Resource Parameters

Resource Identifier	Type	Description
(name)	Format: - a profile name - range: [a-zA-Z0-9-_.] - length: 1<=x<=32	A unique profile name

Table 21.25-2 "QoS Session Profile Configuration Command" Command Parameters

Parameter	Type	Description
logical-flow-type	Parameter type: <Qos::LogicalFlowType>	mandatory parameter

21 QoS Configuration Commands

Parameter	Type	Description
	Format: (generic pvc dot-1x-session pvc-vlan-combination ppp-session ip-session ipoe-vlan-cc pppoe-vlan-cc ipoa-cc pppoa-cc ipoe-ibridge pppoe-ibridge pppoa-relay pppoe-relay ipoe-ip-aware-bridge ipoa-ip-aware-bridge ipoa) Possible values: - generic : any defined logical flow - pvc : all frames on a pvc - dot-1x-session : frames on a pvc except ppp frames - pvc-vlan-combination : frames on dot-1D port with the same vlan-id - ppp-session : all frames on a ppp session - ip-session : all frames in an IP session or interface - ipoe-vlan-cc : all ipoe frames in a vlan cc interface - pppoe-vlan-cc : all pppoe frames in a vlan cc interface - ipoa-cc : all ipoa frames in a ipoa cc interface(replaced by ipoa) - pppoa-cc : all pppoa frames in a pppoa cc interface - ipoe-ibridge : all ipoe frames in i-bridge interface - pppoe-ibridge : all pppoe frames in i-bridge interface - pppoa-relay : pppoa frames in pppoa relay interface - pppoe-relay : all pppoe frames in pppoe relay - ipoe-ip-aware-bridge : ipoe frames in ip aware bridge interface - ipoa-ip-aware-bridge : all ipoa frames in ip aware bridge interface(replaced by ipoa) - ipoa : all ipoa frames in a ipoa interface	a traffic stream up on which policy to be made. Important note: this mandatory parameter is depreciated. No distinction is made any more between the different flow types : independent on what is configured, generic is used.
[no] up-policer	Parameter type: <Qos::QosPolicerProfileName> Format: (none name : <Qos::IgnoredQosProfileName>) Possible values: - none : no profile name to associate - name : enter profile name to be associated Data driven field type Possible values are depending on the actual configuration and software. The currently allowed values can be shown with online-help.	<i>optional parameter with default value: "none"</i> policer profile name applicable on this session upstream
[no] down-policer	Parameter type: <Qos::QosPolicerProfileName> Format: (none name : <Qos::IgnoredQosProfileName>) Possible values: - none : no profile name to associate	<i>optional parameter with default value: "none"</i> policer profile applicable on this session downstream

Parameter	Type	Description
	- name : enter profile name to be associated Data driven field type Possible values are depending on the actual configuration and software. The currently allowed values can be shown with online-help.	
[no] up-marker	Parameter type: <Qos::QosMarkerProfileName> Format: (none name : <Qos::IgnoredQosProfileName>) Possible values: - none : no profile name to associate - name : enter profile name to be associated Data driven field type Possible values are depending on the actual configuration and software. The currently allowed values can be shown with online-help.	<i>optional parameter with default value: "none"</i> marker profile name applicable on this session upstream
[no] ing-outer-marker	Parameter type: <Qos::QosMarkerProfileName> Format: (none name : <Qos::IgnoredQosProfileName>) Possible values: - none : no profile name to associate - name : enter profile name to be associated Data driven field type Possible values are depending on the actual configuration and software. The currently allowed values can be shown with online-help.	<i>optional parameter with default value: "none"</i> outer marker profile name applicable on this session ingress
[no] ds-schedule-tag	Parameter type: <Qos::DsSchedulerProfileTag> Format: (system-default cvlantag svlantag) Possible values: - system-default : system default behavior: always the egress outer tag used. - cvlantag : Select downstream scheduler based on the c-vlan. - svlantag : Select downstream scheduler based on the s-vlan.	<i>optional parameter with default value: "system-default"</i> specifies downstream scheduler tag
[no] up-policer-per-tc	Parameter type: <Qos::QosPolicerPerTCProfileName> Format: (none name : <Qos::IgnoredQosProfileName>) Possible values: - none : no profile name to associate - name : enter profile name to be associated Data driven field type Possible values are depending on the actual configuration and software. The currently allowed values can be shown with online-help.	<i>optional parameter with default value: "none"</i> policer-per-tc profile name applicable on this session upstream
[no] up-dscptotc-prof	Parameter type: <Qos::QosDscpToTcProfileName> Format: (none name : <Qos::IgnoredQosProfileName>) Possible values: - none : no profile name to associate - name : enter profile name to be associated	<i>optional parameter with default value: "none"</i> dscp to tc qos profile name applicable on this session in upstream

21 QoS Configuration Commands

Parameter	Type	Description
	Data driven field type Possible values are depending on the actual configuration and software. The currently allowed values can be shown with online-help.	
[no] dn-dscptotc-prof	Parameter type: <Qos::QosDscpToTcProfileName> Format: (none name : <Qos::IgnoredQosProfileName>) Possible values: - none : no profile name to associate - name : enter profile name to be associated Data driven field type Possible values are depending on the actual configuration and software. The currently allowed values can be shown with online-help.	<i>optional parameter with default value: "none"</i> dscp to tc qos profile name applicable on this session in downstream
[no] up-pbittotc-prof	Parameter type: <Qos::QosPbitToTcProfileName> Format: (none name : <Qos::IgnoredQosProfileName>) Possible values: - none : no profile name to associate - name : enter profile name to be associated Data driven field type Possible values are depending on the actual configuration and software. The currently allowed values can be shown with online-help.	<i>optional parameter with default value: "none"</i> pbit to tc qos profile name applicable on this session in upstream
[no] dn-pbittotc-prof	Parameter type: <Qos::QosPbitToTcProfileName> Format: (none name : <Qos::IgnoredQosProfileName>) Possible values: - none : no profile name to associate - name : enter profile name to be associated Data driven field type Possible values are depending on the actual configuration and software. The currently allowed values can be shown with online-help.	<i>optional parameter with default value: "none"</i> pbit to tc qos profile name applicable on this session in downstream
[no] up-default-tc	Parameter type: <Qos::tcvalue> Format: - traffic class value range - range: [-1...7]	<i>optional parameter with default value: -1L</i> tc mapping for non ip packet applicable on this session in upstream
[no] dn-default-tc	Parameter type: <Qos::tcvalue> Format: - traffic class value range - range: [-1...7]	<i>optional parameter with default value: -1L</i> tc mapping for non ip packet applicable on this session in downstream

21.26 QoS Session Upstream Policy List Configuration Command

Command Description

This command allows the operator to configure a list of upstream policies in a QoS session profile. However the number of these policy rules are hardware dependent.

User Level

The command can be accessed by operators with qos privileges, and executed by operators with qos privileges.

Command Syntax

The command has the following syntax:

```
> configure qos profiles session (name) ( no up-policy (name) ) | ( up-policy (name) )
```

Command Parameters

Table 21.26-1 "QoS Session Upstream Policy List Configuration Command" Resource Parameters

Resource Identifier	Type	Description
(name)	Format: - a profile name - range: [a-zA-Z0-9-_.] - length: 1<=x<=32	A unique profile name
(name)	Format: - a profile name - range: [a-zA-Z0-9-_.] - length: 1<=x<=32	policy profile name applicable

21.27 QoS Session Downstream Policy List Configuration Command

Command Description

This command allows the operator to configure a list of downstream policies in a QoS session profile. However the number of these policy rules are hardware dependent.

User Level

The command can be accessed by operators with qos privileges, and executed by operators with qos privileges.

Command Syntax

The command has the following syntax:

> configure qos profiles session (name) (no down-policy (name)) | (down-policy (name))

Command Parameters

Table 21.27-1 "QoS Session Downstream Policy List Configuration Command" Resource Parameters

Resource Identifier	Type	Description
(name)	Format: - a profile name - range: [a-zA-Z0-9-_.] - length: 1<=x<=32	A unique profile name
(name)	Format: - a profile name - range: [a-zA-Z0-9-_.] - length: 1<=x<=32	policy profile name applicable

21.28 QoS Session remote Upstream Policy List Configuration Command

Command Description

This command allows the operator to configure a list of remote side upstream policies in a QoS session profile.

User Level

The command can be accessed by operators with qos privileges, and executed by operators with qos privileges.

Command Syntax

The command has the following syntax:

```
> configure qos profiles session (name) ( no rem-up-policy (name) ) | ( rem-up-policy (name) )
```

Command Parameters

Table 21.28-1 "QoS Session remote Upstream Policy List Configuration Command" Resource Parameters

Resource Identifier	Type	Description
(name)	Format: - a profile name - range: [a-zA-Z0-9-_.] - length: 1<=x<=32	A unique profile name
(name)	Format: - a profile name - range: [a-zA-Z0-9-_.] - length: 1<=x<=32	policy profile name applicable

21.29 QoS Session Remote Downstream Policy List Configuration Command

Command Description

This command allows the operator to configure a list of remote side downstream policies in a QoS session profile.

User Level

The command can be accessed by operators with qos privileges, and executed by operators with qos privileges.

Command Syntax

The command has the following syntax:

> configure qos profiles session (name) (no rem-down-policy (name)) | (rem-down-policy (name))

Command Parameters

Table 21.29-1 "QoS Session Remote Downstream Policy List Configuration Command" Resource Parameters

Resource Identifier	Type	Description
(name)	Format: - a profile name - range: [a-zA-Z0-9-_.] - length: 1<=x<=32	A unique profile name
(name)	Format: - a profile name - range: [a-zA-Z0-9-_.] - length: 1<=x<=32	policy profile name applicable

21.30 QoS AggrQueuesConfig Profile Configuration Command

Command Description

This command allows the operator to configure a QoS AggrQueuesConfig profile. The AggrQueuesConfig Profile table stores the attributes of 8 queues of one UNI. These AggrQueuesConfig profiles are applicable to qos interface for UNI Upstream and Downstream.

User Level

The command can be accessed by operators with qos privileges, and executed by operators with qos privileges.

Command Syntax

The command has the following syntax:

```
> configure qos profiles ( no aggrqueuesconfig (name) ) | ( aggrqueuesconfig (name) [ no q0-priority | q0-priority
<Qos::Qpriority_0> ] [ no q1-priority | q1-priority <Qos::Qpriority_1> ] [ no q2-priority | q2-priority
<Qos::Qpriority_2> ] [ no q3-priority | q3-priority <Qos::Qpriority_3> ] [ no q4-priority | q4-priority
<Qos::Qpriority_4> ] [ no q5-priority | q5-priority <Qos::Qpriority_5> ] [ no q6-priority | q6-priority
<Qos::Qpriority_6> ] [ no q7-priority | q7-priority <Qos::Qpriority_7> ] [ no q0-weight | q0-weight
<Qos::QosWeight> ] [ no q1-weight | q1-weight <Qos::QosWeight> ] [ no q2-weight | q2-weight
<Qos::QosWeight> ] [ no q3-weight | q3-weight <Qos::QosWeight> ] [ no q4-weight | q4-weight
<Qos::QosWeight> ] [ no q5-weight | q5-weight <Qos::QosWeight> ] [ no q6-weight | q6-weight
<Qos::QosWeight> ] [ no q7-weight | q7-weight <Qos::QosWeight> ] [ no q0-shaper-prof | q0-shaper-prof
<Qos::QosShaperProfileName> ] [ no q1-shaper-prof | q1-shaper-prof <Qos::QosShaperProfileName> ] [ no
q2-shaper-prof | q2-shaper-prof <Qos::QosShaperProfileName> ] [ no q3-shaper-prof | q3-shaper-prof
<Qos::QosShaperProfileName> ] [ no q4-shaper-prof | q4-shaper-prof <Qos::QosShaperProfileName> ] [ no
q5-shaper-prof | q5-shaper-prof <Qos::QosShaperProfileName> ] [ no q6-shaper-prof | q6-shaper-prof
<Qos::QosShaperProfileName> ] [ no q7-shaper-prof | q7-shaper-prof <Qos::QosShaperProfileName> ] [ no
q0-queue-prof | q0-queue-prof <Qos::QosQueueProfName> ] [ no q1-queue-prof | q1-queue-prof
<Qos::QosQueueProfName> ] [ no q2-queue-prof | q2-queue-prof <Qos::QosQueueProfName> ] [ no
q3-queue-prof | q3-queue-prof <Qos::QosQueueProfName> ] [ no q4-queue-prof | q4-queue-prof
<Qos::QosQueueProfName> ] [ no q5-queue-prof | q5-queue-prof <Qos::QosQueueProfName> ] [ no
q6-queue-prof | q6-queue-prof <Qos::QosQueueProfName> ] [ no q7-queue-prof | q7-queue-prof
<Qos::QosQueueProfName> ] [ no q0-bandwidth-prof | q0-bandwidth-prof <Qos::QosBandwidthProfileName> ] [
no q1-bandwidth-prof | q1-bandwidth-prof <Qos::QosBandwidthProfileName> ] [ no q2-bandwidth-prof |
q2-bandwidth-prof <Qos::QosBandwidthProfileName> ] [ no q3-bandwidth-prof | q3-bandwidth-prof
<Qos::QosBandwidthProfileName> ] [ no q4-bandwidth-prof | q4-bandwidth-prof
<Qos::QosBandwidthProfileName> ] [ no q5-bandwidth-prof | q5-bandwidth-prof
<Qos::QosBandwidthProfileName> ] [ no q6-bandwidth-prof | q6-bandwidth-prof
<Qos::QosBandwidthProfileName> ] [ no q7-bandwidth-prof | q7-bandwidth-prof
<Qos::QosBandwidthProfileName> ] [ no q0-bw-sharing | q0-bw-sharing <Qos::BandwidthSharing_0> ] [ no
q1-bw-sharing | q1-bw-sharing <Qos::BandwidthSharing_1> ] [ no q2-bw-sharing | q2-bw-sharing
<Qos::BandwidthSharing_2> ] [ no q3-bw-sharing | q3-bw-sharing <Qos::BandwidthSharing_3> ] [ no
q4-bw-sharing | q4-bw-sharing <Qos::BandwidthSharing_4> ] [ no q5-bw-sharing | q5-bw-sharing
<Qos::BandwidthSharing_5> ] [ no q6-bw-sharing | q6-bw-sharing <Qos::BandwidthSharing_6> ] [ no
q7-bw-sharing | q7-bw-sharing <Qos::BandwidthSharing_7> ] )
```

Command Parameters

Table 21.30-1 "QoS AggrQueuesConfig Profile Configuration Command" Resource Parameters

Resource Identifier	Type	Description
(name)	Format: - a profile name - range: [a-zA-Z0-9-_.] - length: 1<=x<=32	A unique profile name

Table 21.30-2 "QoS AggrQueuesConfig Profile Configuration Command" Command Parameters

Parameter	Type	Description
[no] q0-priority	Parameter type: <Qos::Qpriority_0> Format: - priority corresponding to queue 0 - range: [1...8]	<i>optional parameter with default value: 1</i> priority corresponding to queue 0
[no] q1-priority	Parameter type: <Qos::Qpriority_1> Format: - priority corresponding to queue 1 - range: [1...8]	<i>optional parameter with default value: 1</i> priority corresponding to queue 1
[no] q2-priority	Parameter type: <Qos::Qpriority_2> Format: - priority corresponding to queue 2 - range: [1...8]	<i>optional parameter with default value: 1</i> priority corresponding to queue 2
[no] q3-priority	Parameter type: <Qos::Qpriority_3> Format: - priority corresponding to queue 3 - range: [1...8]	<i>optional parameter with default value: 1</i> priority corresponding to queue 3
[no] q4-priority	Parameter type: <Qos::Qpriority_4> Format: - priority corresponding to queue 4 - range: [1...8]	<i>optional parameter with default value: 1</i> priority corresponding to queue 4
[no] q5-priority	Parameter type: <Qos::Qpriority_5> Format: - priority corresponding to queue 5 - range: [1...8]	<i>optional parameter with default value: 1</i> priority corresponding to queue 5
[no] q6-priority	Parameter type: <Qos::Qpriority_6> Format: - priority corresponding to queue 6 - range: [1...8]	<i>optional parameter with default value: 1</i> priority corresponding to queue 6
[no] q7-priority	Parameter type: <Qos::Qpriority_7> Format: - priority corresponding to queue 7 - range: [1...8]	<i>optional parameter with default value: 1</i> priority corresponding to queue 7
[no] q0-weight	Parameter type: <Qos::QosWeight> Format: - relative weight - range: [0...127]	<i>optional parameter with default value: 1</i> relative weight of the queue 0
[no] q1-weight	Parameter type: <Qos::QosWeight> Format: - relative weight - range: [0...127]	<i>optional parameter with default value: 1</i> relative weight of the queue 1
[no] q2-weight	Parameter type: <Qos::QosWeight> Format: - relative weight - range: [0...127]	<i>optional parameter with default value: 1</i> relative weight of the queue 2
[no] q3-weight	Parameter type: <Qos::QosWeight>	<i>optional parameter with default</i>

Parameter	Type	Description
	Format: - relative weight - range: [0...127]	<i>value: 1</i> relative weight of the queue 3
[no] q4-weight	Parameter type: <Qos::QosWeight> Format: - relative weight - range: [0...127]	<i>optional parameter with default value: 1</i> relative weight of the queue 4
[no] q5-weight	Parameter type: <Qos::QosWeight> Format: - relative weight - range: [0...127]	<i>optional parameter with default value: 1</i> relative weight of the queue 5
[no] q6-weight	Parameter type: <Qos::QosWeight> Format: - relative weight - range: [0...127]	<i>optional parameter with default value: 1</i> relative weight of the queue 6
[no] q7-weight	Parameter type: <Qos::QosWeight> Format: - relative weight - range: [0...127]	<i>optional parameter with default value: 1</i> relative weight of the queue 7
[no] q0-shaper-prof	Parameter type: <Qos::QosShaperProfileName> Format: (none name : <Qos::IgnoredQosProfileName>) Possible values: - none : no profile name to associated - name : enter profile name to be associated Data driven field type Possible values are depending on the actual configuration and software. The currently allowed values can be shown with online-help.	<i>optional parameter with default value: "none"</i> the associated queue 0 shaper profile.
[no] q1-shaper-prof	Parameter type: <Qos::QosShaperProfileName> Format: (none name : <Qos::IgnoredQosProfileName>) Possible values: - none : no profile name to associated - name : enter profile name to be associated Data driven field type Possible values are depending on the actual configuration and software. The currently allowed values can be shown with online-help.	<i>optional parameter with default value: "none"</i> the associated queue 1 shaper profile.
[no] q2-shaper-prof	Parameter type: <Qos::QosShaperProfileName> Format: (none name : <Qos::IgnoredQosProfileName>) Possible values: - none : no profile name to associated - name : enter profile name to be associated Data driven field type Possible values are depending on the actual configuration and software. The currently allowed values can be shown with online-help.	<i>optional parameter with default value: "none"</i> the associated queue 2 shaper profile.
[no] q3-shaper-prof	Parameter type: <Qos::QosShaperProfileName> Format: (none name : <Qos::IgnoredQosProfileName>) Possible values:	<i>optional parameter with default value: "none"</i> the associated queue 3 shaper profile.

21 QoS Configuration Commands

Parameter	Type	Description
	- none : no profile name to associated - name : enter profile name to be associated Data driven field type Possible values are depending on the actual configuration and software. The currently allowed values can be shown with online-help.	
[no] q4-shaper-prof	Parameter type: <Qos::QosShaperProfileName> Format: (none name : <Qos::IgnoredQosProfileName>) Possible values: - none : no profile name to associated - name : enter profile name to be associated Data driven field type Possible values are depending on the actual configuration and software. The currently allowed values can be shown with online-help.	<i>optional parameter with default value: "none"</i> the associated queue 4 shaper profile.
[no] q5-shaper-prof	Parameter type: <Qos::QosShaperProfileName> Format: (none name : <Qos::IgnoredQosProfileName>) Possible values: - none : no profile name to associated - name : enter profile name to be associated Data driven field type Possible values are depending on the actual configuration and software. The currently allowed values can be shown with online-help.	<i>optional parameter with default value: "none"</i> the associated queue 5 shaper profile.
[no] q6-shaper-prof	Parameter type: <Qos::QosShaperProfileName> Format: (none name : <Qos::IgnoredQosProfileName>) Possible values: - none : no profile name to associated - name : enter profile name to be associated Data driven field type Possible values are depending on the actual configuration and software. The currently allowed values can be shown with online-help.	<i>optional parameter with default value: "none"</i> the associated queue 6 shaper profile.
[no] q7-shaper-prof	Parameter type: <Qos::QosShaperProfileName> Format: (none name : <Qos::IgnoredQosProfileName>) Possible values: - none : no profile name to associated - name : enter profile name to be associated Data driven field type Possible values are depending on the actual configuration and software. The currently allowed values can be shown with online-help.	<i>optional parameter with default value: "none"</i> the associated queue 7 shaper profile.
[no] q0-queue-prof	Parameter type: <Qos::QosQueueProfName> Format: (none name : <Qos::IgnoredQosProfileName>) Possible values: - none : no profile name to associated - name : enter profile name to be associated	<i>optional parameter with default value: "none"</i> name of the queue 0 queue profile

Parameter	Type	Description
	Data driven field type Possible values are depending on the actual configuration and software. The currently allowed values can be shown with online-help.	
[no] q1-queue-prof	Parameter type: <Qos::QosQueueProfName> Format: (none name : <Qos::IgnoredQosProfileName>) Possible values: - none : no profile name to associated - name : enter profile name to be associated Data driven field type Possible values are depending on the actual configuration and software. The currently allowed values can be shown with online-help.	<i>optional parameter with default value: "none"</i> name of the queue 1 queue profile
[no] q2-queue-prof	Parameter type: <Qos::QosQueueProfName> Format: (none name : <Qos::IgnoredQosProfileName>) Possible values: - none : no profile name to associated - name : enter profile name to be associated Data driven field type Possible values are depending on the actual configuration and software. The currently allowed values can be shown with online-help.	<i>optional parameter with default value: "none"</i> name of the queue 2 queue profile
[no] q3-queue-prof	Parameter type: <Qos::QosQueueProfName> Format: (none name : <Qos::IgnoredQosProfileName>) Possible values: - none : no profile name to associated - name : enter profile name to be associated Data driven field type Possible values are depending on the actual configuration and software. The currently allowed values can be shown with online-help.	<i>optional parameter with default value: "none"</i> name of the queue 3 queue profile
[no] q4-queue-prof	Parameter type: <Qos::QosQueueProfName> Format: (none name : <Qos::IgnoredQosProfileName>) Possible values: - none : no profile name to associated - name : enter profile name to be associated Data driven field type Possible values are depending on the actual configuration and software. The currently allowed values can be shown with online-help.	<i>optional parameter with default value: "none"</i> name of the queue 4 queue profile
[no] q5-queue-prof	Parameter type: <Qos::QosQueueProfName> Format: (none name : <Qos::IgnoredQosProfileName>) Possible values: - none : no profile name to associated - name : enter profile name to be associated Data driven field type Possible values are depending on the actual configuration and software.	<i>optional parameter with default value: "none"</i> name of the queue 5 queue profile

21 QoS Configuration Commands

Parameter	Type	Description
	and software. The currently allowed values can be shown with online-help.	
[no] q6-queue-prof	Parameter type: <Qos::QosQueueProfName> Format: (none name : <Qos::IgnoredQosProfileName>) Possible values: - none : no profile name to associated - name : enter profile name to be associated Data driven field type Possible values are depending on the actual configuration and software. The currently allowed values can be shown with online-help.	<i>optional parameter with default value: "none"</i> name of the queue 6 queue profile
[no] q7-queue-prof	Parameter type: <Qos::QosQueueProfName> Format: (none name : <Qos::IgnoredQosProfileName>) Possible values: - none : no profile name to associated - name : enter profile name to be associated Data driven field type Possible values are depending on the actual configuration and software. The currently allowed values can be shown with online-help.	<i>optional parameter with default value: "none"</i> name of the queue 7 queue profile
[no] q0-bandwidth-prof	Parameter type: <Qos::QosBandwidthProfileName> Format: (name : <Qos::IgnoredQosProfileName> none) Possible values: - none : no profile name to associate - name : enter profile name to be associated Data driven field type Possible values are depending on the actual configuration and software. The currently allowed values can be shown with online-help.	<i>optional parameter with default value: "none"</i> the name of the queue 0 bandwidth profile.
[no] q1-bandwidth-prof	Parameter type: <Qos::QosBandwidthProfileName> Format: (name : <Qos::IgnoredQosProfileName> none) Possible values: - none : no profile name to associate - name : enter profile name to be associated Data driven field type Possible values are depending on the actual configuration and software. The currently allowed values can be shown with online-help.	<i>optional parameter with default value: "none"</i> the name of the queue 1 bandwidth profile.
[no] q2-bandwidth-prof	Parameter type: <Qos::QosBandwidthProfileName> Format: (name : <Qos::IgnoredQosProfileName> none) Possible values: - none : no profile name to associate - name : enter profile name to be associated Data driven field type Possible values are depending on the actual configuration and software. The currently allowed values can be shown with online-help.	<i>optional parameter with default value: "none"</i> the name of the queue 2 bandwidth profile.

Parameter	Type	Description
[no] q3-bandwidth-prof	Parameter type: <Qos::QosBandwidthProfileName> Format: (name : <Qos::IgnoredQosProfileName> none) Possible values: - none : no profile name to associate - name : enter profile name to be associated Data driven field type Possible values are depending on the actual configuration and software. The currently allowed values can be shown with online-help.	<i>optional parameter with default value: "none"</i> the name of the queue 3 bandwidth profile.
[no] q4-bandwidth-prof	Parameter type: <Qos::QosBandwidthProfileName> Format: (name : <Qos::IgnoredQosProfileName> none) Possible values: - none : no profile name to associate - name : enter profile name to be associated Data driven field type Possible values are depending on the actual configuration and software. The currently allowed values can be shown with online-help.	<i>optional parameter with default value: "none"</i> the name of the queue 4 bandwidth profile.
[no] q5-bandwidth-prof	Parameter type: <Qos::QosBandwidthProfileName> Format: (name : <Qos::IgnoredQosProfileName> none) Possible values: - none : no profile name to associate - name : enter profile name to be associated Data driven field type Possible values are depending on the actual configuration and software. The currently allowed values can be shown with online-help.	<i>optional parameter with default value: "none"</i> the name of the queue 5 bandwidth profile.
[no] q6-bandwidth-prof	Parameter type: <Qos::QosBandwidthProfileName> Format: (name : <Qos::IgnoredQosProfileName> none) Possible values: - none : no profile name to associate - name : enter profile name to be associated Data driven field type Possible values are depending on the actual configuration and software. The currently allowed values can be shown with online-help.	<i>optional parameter with default value: "none"</i> the name of the queue 6 bandwidth profile.
[no] q7-bandwidth-prof	Parameter type: <Qos::QosBandwidthProfileName> Format: (name : <Qos::IgnoredQosProfileName> none) Possible values: - none : no profile name to associate - name : enter profile name to be associated Data driven field type Possible values are depending on the actual configuration and software. The currently allowed values can be shown with online-help.	<i>optional parameter with default value: "none"</i> the name of the queue 7 bandwidth profile.
[no] q0-bw-sharing	Parameter type: <Qos::BandwidthSharing_0> Format:	<i>optional parameter with default value: "no-sharing"</i>

21 QoS Configuration Commands

Parameter	Type	Description
	(no-sharing uni-sharing ont-sharing) Possible values: - no-sharing : disable bandwidth sharing - uni-sharing : enable BW or TCONT sharing on a single UNI - ont-sharing : enable BW or TCONT sharing on across UNIs of an ONT	enable or disable queue 0 bandwidth sharing
[no] q1-bw-sharing	Parameter type: <Qos::BandwidthSharing_1> Format: (no-sharing uni-sharing ont-sharing) Possible values: - no-sharing : disable bandwidth sharing - uni-sharing : enable BW or TCONT sharing on a single UNI - ont-sharing : enable BW or TCONT sharing on across UNIs of an ONT	<i>optional parameter with default value: "no-sharing"</i> enable or disable queue 1 bandwidth sharing
[no] q2-bw-sharing	Parameter type: <Qos::BandwidthSharing_2> Format: (no-sharing uni-sharing ont-sharing) Possible values: - no-sharing : disable bandwidth sharing - uni-sharing : enable BW or TCONT sharing on a single UNI - ont-sharing : enable BW or TCONT sharing on across UNIs of an ONT	<i>optional parameter with default value: "no-sharing"</i> enable or disable queue 2 bandwidth sharing
[no] q3-bw-sharing	Parameter type: <Qos::BandwidthSharing_3> Format: (no-sharing uni-sharing ont-sharing) Possible values: - no-sharing : disable bandwidth sharing - uni-sharing : enable BW or TCONT sharing on a single UNI - ont-sharing : enable BW or TCONT sharing on across UNIs of an ONT	<i>optional parameter with default value: "no-sharing"</i> enable or disable queue 3 bandwidth sharing
[no] q4-bw-sharing	Parameter type: <Qos::BandwidthSharing_4> Format: (no-sharing uni-sharing ont-sharing) Possible values: - no-sharing : disable bandwidth sharing - uni-sharing : enable BW or TCONT sharing on a single UNI - ont-sharing : enable BW or TCONT sharing on across UNIs of an ONT	<i>optional parameter with default value: "no-sharing"</i> enable or disable queue 4 bandwidth sharing
[no] q5-bw-sharing	Parameter type: <Qos::BandwidthSharing_5> Format: (no-sharing uni-sharing	<i>optional parameter with default value: "no-sharing"</i> enable or disable queue 5 bandwidth sharing

Parameter	Type	Description
	ont-sharing) Possible values: - no-sharing : disable bandwidth sharing - uni-sharing : enable BW or TCONT sharing on a single UNI - ont-sharing : enable BW or TCONT sharing on across UNIs of an ONT	
[no] q6-bw-sharing	Parameter type: <Qos::BandwidthSharing_6> Format: (no-sharing uni-sharing ont-sharing) Possible values: - no-sharing : disable bandwidth sharing - uni-sharing : enable BW or TCONT sharing on a single UNI - ont-sharing : enable BW or TCONT sharing on across UNIs of an ONT	<i>optional parameter with default value: "no-sharing"</i> enable or disable queue 6 bandwidth sharing
[no] q7-bw-sharing	Parameter type: <Qos::BandwidthSharing_7> Format: (no-sharing uni-sharing ont-sharing) Possible values: - no-sharing : disable bandwidth sharing - uni-sharing : enable BW or TCONT sharing on a single UNI - ont-sharing : enable BW or TCONT sharing on across UNIs of an ONT	<i>optional parameter with default value: "no-sharing"</i> enable or disable queue 7 bandwidth sharing

21.31 QoS Shaper Profile Configuration Command

Command Description

This command allows the operator to configure a QoS shaper profile. A QoS shaper profile contains all settings related to a shaper. The ISAM supports single token bucket shapers. EIR is only applicable if shaper type is singleTokenBucketGpon. CBS is applicable only if the shaper type is singleTokenBucket.

The L2+ line cards support shaping on queue.

1. GPON supports EIR and CIR. If CBS is non-zero for GPON; CLI will return an error.
2. DSL doesn't support EIR. So if user enters non-zero for EIR for DSL; CLI will return an error.

User Level

The command can be accessed by operators with qos privileges, and executed by operators with qos privileges.

Command Syntax

The command has the following syntax:

```
> configure qos profiles ( no shaper (name) ) | ( shaper (name) committed-info-rate
<Qos::ShaperCommittedInfoRate> committed-burst-size <Qos::ShaperCommittedBurstSizeNew> [ no
excess-info-rate | excess-info-rate <Qos::ShaperExcessiveInfoRate> ] [ no type | type <Qos::ShaperType> ] [ no
autoshape | autoshape <Qos::AutoShape> ] )
```

Command Parameters

Table 21.31-1 "QoS Shaper Profile Configuration Command" Resource Parameters

Resource Identifier	Type	Description
(name)	Format: - a profile name - range: [a-zA-Z0-9-_.] - length: 1<=x<=32	A unique profile name

Table 21.31-2 "QoS Shaper Profile Configuration Command" Command Parameters

Parameter	Type	Description
committed-info-rate	Parameter type: <Qos::ShaperCommittedInfoRate> Format: - committed information rate of a shaper - unit: kbps - range: [0...2147483647]	<i>mandatory parameter</i> committed information rate of a shaper
committed-burst-size	Parameter type: <Qos::ShaperCommittedBurstSizeNew> Format: - committed burst size of shaper - unit: byte - range: [0,64...2147483647]	<i>mandatory parameter</i> committed burst size of shaper
[no] excess-info-rate	Parameter type: <Qos::ShaperExcessiveInfoRate> Format:	<i>optional parameter with default value: 0</i>

Parameter	Type	Description
	- excessive information rate of a shaper - unit: kbps - range: [0...2147483647]	excessive information rate of shaper
[no] type	Parameter type: <Qos::ShaperType> Format: (singletokenbucket singletokenbucketgpon onetokentworate twotokenbuckettworate) Possible values: - singletokenbucket : single Token Bucket - singletokenbucketgpon : single Token Bucket for GPON - onetokentworate : single Token Two Rate Bucket - twotokenbuckettworate : two Token Two Rate Bucket	<i>optional parameter with default value: "singletokenbucket"</i> the shaper profile type
[no] autoshape	Parameter type: <Qos::AutoShape> Format: (autoshape-on no-autoshape-on) Possible values: - autoshape-on : enable shaping based on queue parameters - no-autoshape-on : disable shaping based on queue parameters	<i>optional parameter with default value: "no-autoshape-on"</i> enable or disable automatic shaping

21.32 QoS Bandwidth Profile Configuration Command

Command Description

This command allows the operator to configure a QoS Bandwidth profile. A QoS Bandwidth profile contains upstream rate enforcement information for frames to which this profile is applied.

User Level

The command can be accessed by operators with qos privileges, and executed by operators with qos privileges.

Command Syntax

The command has the following syntax:

```
> configure qos profiles ( no bandwidth (name) ) | ( bandwidth (name) committed-info-rate
<Qos::BwCommittedInfoRate> assured-info-rate <Qos::BwAssuredInfoRate> excessive-info-rate
<Qos::BwExcessiveInfoRate> [ no delay-tolerance | delay-tolerance <Qos::DelayTolerance> ] [ no assu-burst-size |
assu-burst-size <Qos::BwAssuredBurstSize> ] [ no exce-burst-size | exce-burst-size <Qos::BwExcessiveBurstSize>
] [ no dbu | dbu <Qos::BwDBRu> ] )
```

Command Parameters

Table 21.32-1 "QoS Bandwidth Profile Configuration Command" Resource Parameters

Resource Identifier	Type	Description
(name)	Format: - a profile name - range: [a-zA-Z0-9-_.] - length: 1<=x<=32	A unique profile name

Table 21.32-2 "QoS Bandwidth Profile Configuration Command" Command Parameters

Parameter	Type	Description
committed-info-rate	Parameter type: <Qos::BwCommittedInfoRate> Format: - committed information rate - unit: kbps - range: [0...25000000]	<i>mandatory parameter</i> committed information rate
assured-info-rate	Parameter type: <Qos::BwAssuredInfoRate> Format: - assured information rate - unit: kbps - range: [0...25000000]	<i>mandatory parameter</i> assured information rate
excessive-info-rate	Parameter type: <Qos::BwExcessiveInfoRate> Format: - excessive information rate - unit: kbps	<i>mandatory parameter</i> excessive information rate

Parameter	Type	Description
	- range: [0...25000000]	
[no] delay-tolerance	Parameter type: <Qos::DelayTolerance> Format: - delay tolerance - range: [1...240]	<i>optional parameter with default value: "1"</i> delay tolerance
[no] assu-burst-size	Parameter type: <Qos::BwAssuredBurstSize> Format: - assured burst size only for EPON - unit: kB - range: [1...256]	<i>optional parameter with default value: 256L</i> assured burst size only for EPON
[no] exce-burst-size	Parameter type: <Qos::BwExcessiveBurstSize> Format: - excessive burst size only for EPON - unit: kB - range: [1...256]	<i>optional parameter with default value: 256L</i> excessive burst size only for EPON
[no] dbRu	Parameter type: <Qos::BwDBRu> Format: (enable disable enable-if-supported) Possible values: - enable : enable use of DBRu - disable : disable use of DBRu - enable-if-supported : enable DBRu if supported	<i>optional parameter with default value: "enable-if-supported"</i> DBRu enable

21.33 QoS IngressQoS Profile Configuration

Command

Command Description

This command allows the operator to configure a QoS Ingress profile. The IngressQoS Profile table stores the pbit to TC mappings that can be used by a L2 Forwarder in the upstream and downstream directions.

User Level

The command can be accessed by operators with qos privileges, and executed by operators with qos privileges.

Command Syntax

The command has the following syntax:

```
> configure qos profiles ( no ingress-qos (name) ) | ( ingress-qos (name) [ no dot1-p0-tc | dot1-p0-tc
<Qos::TCMask_0> ] [ no dot1-p1-tc | dot1-p1-tc <Qos::TCMask_1> ] [ no dot1-p2-tc | dot1-p2-tc
<Qos::TCMask_2> ] [ no dot1-p3-tc | dot1-p3-tc <Qos::TCMask_3> ] [ no dot1-p4-tc | dot1-p4-tc
<Qos::TCMask_4> ] [ no dot1-p5-tc | dot1-p5-tc <Qos::TCMask_5> ] [ no dot1-p6-tc | dot1-p6-tc
<Qos::TCMask_6> ] [ no dot1-p7-tc | dot1-p7-tc <Qos::TCMask_7> ] [ [ no ] use-dei ] [ no dot1-p0-color |
dot1-p0-color <Qos::NibbleMask_0> ] [ no dot1-p1-color | dot1-p1-color <Qos::NibbleMask_1> ] [ no
dot1-p2-color | dot1-p2-color <Qos::NibbleMask_2> ] [ no dot1-p3-color | dot1-p3-color <Qos::NibbleMask_3> ] [
no dot1-p4-color | dot1-p4-color <Qos::NibbleMask_4> ] [ no dot1-p5-color | dot1-p5-color <Qos::NibbleMask_5>
] [ no dot1-p6-color | dot1-p6-color <Qos::NibbleMask_6> ] [ no dot1-p7-color | dot1-p7-color
<Qos::NibbleMask_7> ] [ no dot1-p0-pol-tc | dot1-p0-pol-tc <Qos::PolTCMask_0> ] [ no dot1-p1-pol-tc |
dot1-p1-pol-tc <Qos::PolTCMask_1> ] [ no dot1-p2-pol-tc | dot1-p2-pol-tc <Qos::PolTCMask_2> ] [ no
dot1-p3-pol-tc | dot1-p3-pol-tc <Qos::PolTCMask_3> ] [ no dot1-p4-pol-tc | dot1-p4-pol-tc <Qos::PolTCMask_4>
] [ no dot1-p5-pol-tc | dot1-p5-pol-tc <Qos::PolTCMask_5> ] [ no dot1-p6-pol-tc | dot1-p6-pol-tc
<Qos::PolTCMask_6> ] [ no dot1-p7-pol-tc | dot1-p7-pol-tc <Qos::PolTCMask_7> ] )
```

Command Parameters

Table 21.33-1 "QoS IngressQoS Profile Configuration Command" Resource Parameters

Resource Identifier	Type	Description
(name)	Format: - a profile name - range: [a-zA-Z0-9-_.] - length: 1<=x<=32	A unique profile name

Table 21.33-2 "QoS IngressQoS Profile Configuration Command" Command Parameters

Parameter	Type	Description
[no] dot1-p0-tc	Parameter type: <Qos::TCMask_0> Format: - traffic class corresponding to pbit0 - range: [0...7,15]	optional parameter with default value: 15 traffic class corresponding to pbit0
[no] dot1-p1-tc	Parameter type: <Qos::TCMask_1>	optional parameter with default

Parameter	Type	Description
	Format: - traffic class corresponding to pbit1 - range: [0...7,15]	<i>value: 15</i> traffic class corresponding to pbit1
[no] dot1-p2-tc	Parameter type: <Qos::TCMask_2> Format: - traffic class corresponding to pbit2 - range: [0...7,15]	<i>optional parameter with default value: 15</i> traffic class corresponding to pbit2
[no] dot1-p3-tc	Parameter type: <Qos::TCMask_3> Format: - traffic class corresponding to pbit3 - range: [0...7,15]	<i>optional parameter with default value: 15</i> traffic class corresponding to pbit3
[no] dot1-p4-tc	Parameter type: <Qos::TCMask_4> Format: - traffic class corresponding to pbit4 - range: [0...7,15]	<i>optional parameter with default value: 15</i> traffic class corresponding to pbit4
[no] dot1-p5-tc	Parameter type: <Qos::TCMask_5> Format: - traffic class corresponding to pbit5 - range: [0...7,15]	<i>optional parameter with default value: 15</i> traffic class corresponding to pbit5
[no] dot1-p6-tc	Parameter type: <Qos::TCMask_6> Format: - traffic class corresponding to pbit6 - range: [0...7,15]	<i>optional parameter with default value: 15</i> traffic class corresponding to pbit6
[no] dot1-p7-tc	Parameter type: <Qos::TCMask_7> Format: - traffic class corresponding to pbit7 - range: [0...7,15]	<i>optional parameter with default value: 15</i> traffic class corresponding to pbit7
[no] use-dei	Parameter type: boolean	<i>optional parameter</i> enable use of DEI bit
[no] dot1-p0-color	Parameter type: <Qos::NibbleMask_0> Format: (green yellow red not-used) Possible values: - green : green color - yellow : yellow color - red : red color - not-used : pbit not in use	<i>optional parameter with default value: "green"</i> ingress color corresponding to pbit0
[no] dot1-p1-color	Parameter type: <Qos::NibbleMask_1> Format: (green yellow red not-used) Possible values: - green : green color - yellow : yellow color - red : red color - not-used : pbit not in use	<i>optional parameter with default value: "green"</i> ingress color corresponding to pbit1
[no] dot1-p2-color	Parameter type: <Qos::NibbleMask_2> Format: (green yellow red not-used)	<i>optional parameter with default value: "green"</i> ingress color corresponding to pbit2

21 QoS Configuration Commands

Parameter	Type	Description
	Possible values: - green : green color - yellow : yellow color - red : red color - not-used : pbit not in use	
[no] dot1-p3-color	Parameter type: <Qos::NibbleMask_3> Format: (green yellow red not-used) Possible values: - green : green color - yellow : yellow color - red : red color - not-used : pbit not in use	<i>optional parameter with default value: "green"</i> ingress color corresponding to pbit3
[no] dot1-p4-color	Parameter type: <Qos::NibbleMask_4> Format: (green yellow red not-used) Possible values: - green : green color - yellow : yellow color - red : red color - not-used : pbit not in use	<i>optional parameter with default value: "green"</i> ingress color corresponding to pbit4
[no] dot1-p5-color	Parameter type: <Qos::NibbleMask_5> Format: (green yellow red not-used) Possible values: - green : green color - yellow : yellow color - red : red color - not-used : pbit not in use	<i>optional parameter with default value: "green"</i> ingress color corresponding to pbit5
[no] dot1-p6-color	Parameter type: <Qos::NibbleMask_6> Format: (green yellow red not-used) Possible values: - green : green color - yellow : yellow color - red : red color - not-used : pbit not in use	<i>optional parameter with default value: "green"</i> ingress color corresponding to pbit6
[no] dot1-p7-color	Parameter type: <Qos::NibbleMask_7> Format: (green yellow red not-used) Possible values: - green : green color	<i>optional parameter with default value: "green"</i> ingress color corresponding to pbit7

Parameter	Type	Description
	- yellow : yellow color - red : red color - not-used : pbit not in use	
[no] dot1-p0-pol-tc	Parameter type: <Qos::PolTCMask_0> Format: - policing traffic class corresponding to pbit0 - range: [0...7,15]	<i>optional parameter with default value: 15</i> policing traffic class corresponding to pbit0
[no] dot1-p1-pol-tc	Parameter type: <Qos::PolTCMask_1> Format: - policing traffic class corresponding to pbit1 - range: [0...7,15]	<i>optional parameter with default value: 15</i> policing traffic class corresponding to pbit1
[no] dot1-p2-pol-tc	Parameter type: <Qos::PolTCMask_2> Format: - policing traffic class corresponding to pbit2 - range: [0...7,15]	<i>optional parameter with default value: 15</i> policing traffic class corresponding to pbit2
[no] dot1-p3-pol-tc	Parameter type: <Qos::PolTCMask_3> Format: - policing traffic class corresponding to pbit3 - range: [0...7,15]	<i>optional parameter with default value: 15</i> policing traffic class corresponding to pbit3
[no] dot1-p4-pol-tc	Parameter type: <Qos::PolTCMask_4> Format: - policing traffic class corresponding to pbit4 - range: [0...7,15]	<i>optional parameter with default value: 15</i> policing traffic class corresponding to pbit4
[no] dot1-p5-pol-tc	Parameter type: <Qos::PolTCMask_5> Format: - policing traffic class corresponding to pbit5 - range: [0...7,15]	<i>optional parameter with default value: 15</i> policing traffic class corresponding to pbit5
[no] dot1-p6-pol-tc	Parameter type: <Qos::PolTCMask_6> Format: - policing traffic class corresponding to pbit6 - range: [0...7,15]	<i>optional parameter with default value: 15</i> policing traffic class corresponding to pbit6
[no] dot1-p7-pol-tc	Parameter type: <Qos::PolTCMask_7> Format: - policing traffic class corresponding to pbit7 - range: [0...7,15]	<i>optional parameter with default value: 15</i> policing traffic class corresponding to pbit7

21.34 QoS Rate Limit Profile Configuration

Command

Command Description

This command allows the operator to configure a QoS rate limit profile. A QoS rate limit profile contains all rate limit values related to different protocols, or total protocol values

Total protocol ratelimit value and supported protocol ratelimit value

User Level

The command can be accessed by operators with qos privileges, and executed by operators with qos privileges.

Command Syntax

The command has the following syntax:

```
> configure qos profiles ( no rate-limit (name) ) | ( rate-limit (name) [ no total-rate | total-rate
<Qos::RateLimitTotalRate> ] [ no total-burst | total-burst <Qos::RateLimitTotalBurst> ] [ no arp-rate | arp-rate
<Qos::RateLimitProtocolRate> ] [ no arp-burst | arp-burst <Qos::RateLimitProtocolBurst> ] [ no dhcp-rate |
dhcp-rate <Qos::RateLimitProtocolRate> ] [ no dhcp-burst | dhcp-burst <Qos::RateLimitProtocolBurst> ] [ no
igmp-rate | igmp-rate <Qos::RateLimitProtocolRate> ] [ no igmp-burst | igmp-burst
<Qos::RateLimitProtocolBurst> ] [ no pppoe-rate | pppoe-rate <Qos::RateLimitProtocolRate> ] [ no pppoe-burst |
pppoe-burst <Qos::RateLimitProtocolBurst> ] [ no nd-rate | nd-rate <Qos::RateLimitProtocolRate> ] [ no nd-burst |
nd-burst <Qos::RateLimitProtocolBurst> ] [ no icmpv6-rate | icmpv6-rate <Qos::RateLimitProtocolRate> ] [ no
icmpv6-burst | icmpv6-burst <Qos::RateLimitProtocolBurst> ] [ no mld-rate | mld-rate
<Qos::RateLimitProtocolRate> ] [ no mld-burst | mld-burst <Qos::RateLimitProtocolBurst> ] [ no dhcpv6-rate |
dhcpv6-rate <Qos::RateLimitProtocolRate> ] [ no dhcpv6-burst | dhcpv6-burst <Qos::RateLimitProtocolBurst> ] [
no cfm-rate | cfm-rate <Qos::RateLimitProtocolRate> ] [ no cfm-burst | cfm-burst <Qos::RateLimitProtocolBurst> ]
)
```

Command Parameters

Table 21.34-1 "QoS Rate Limit Profile Configuration Command" Resource Parameters

Resource Identifier	Type	Description
(name)	Format: - a profile name - range: [a-zA-Z0-9-_.] - length: 1<=x<=32	A unique profile name

Table 21.34-2 "QoS Rate Limit Profile Configuration Command" Command Parameters

Parameter	Type	Description
[no] total-rate	Parameter type: <Qos::RateLimitTotalRate> Format: - protocol rate limit total rate - unit: pps	<i>optional parameter with default value: 0</i> committed total rate limit value

Parameter	Type	Description
	- range: [0...254]	
[no] total-burst	Parameter type: <Qos::RateLimitTotalBurst> Format: - protocol rate limit total burst - unit: pps - range: [0...254]	<i>optional parameter with default value: 0</i> committed total rate limit burst value
[no] arp-rate	Parameter type: <Qos::RateLimitProtocolRate> Format: - protocol rate limit value - unit: pps - range: [0...254]	<i>optional parameter with default value: 0</i> ARP rate limit value
[no] arp-burst	Parameter type: <Qos::RateLimitProtocolBurst> Format: - protocol rate limit burst - unit: pps - range: [0...254]	<i>optional parameter with default value: 0</i> ARP burst value
[no] dhcp-rate	Parameter type: <Qos::RateLimitProtocolRate> Format: - protocol rate limit value - unit: pps - range: [0...254]	<i>optional parameter with default value: 0</i> DHCP rate limit value
[no] dhcp-burst	Parameter type: <Qos::RateLimitProtocolBurst> Format: - protocol rate limit burst - unit: pps - range: [0...254]	<i>optional parameter with default value: 0</i> DHCP burst value
[no] igmp-rate	Parameter type: <Qos::RateLimitProtocolRate> Format: - protocol rate limit value - unit: pps - range: [0...254]	<i>optional parameter with default value: 0</i> IGMP rate limit value
[no] igmp-burst	Parameter type: <Qos::RateLimitProtocolBurst> Format: - protocol rate limit burst - unit: pps - range: [0...254]	<i>optional parameter with default value: 0</i> IGMP burst value
[no] pppoe-rate	Parameter type: <Qos::RateLimitProtocolRate> Format: - protocol rate limit value - unit: pps - range: [0...254]	<i>optional parameter with default value: 0</i> PPPoE rate limit value
[no] pppoe-burst	Parameter type: <Qos::RateLimitProtocolBurst> Format: - protocol rate limit burst - unit: pps - range: [0...254]	<i>optional parameter with default value: 0</i> PPPoE burst value
[no] nd-rate	Parameter type: <Qos::RateLimitProtocolRate> Format: - protocol rate limit value - unit: pps - range: [0...254]	<i>optional parameter with default value: 0</i> Nd rate limit value
[no] nd-burst	Parameter type: <Qos::RateLimitProtocolBurst> Format: - protocol rate limit burst - unit: pps - range: [0...254]	<i>optional parameter with default value: 0</i> Nd burst value
[no] icmpv6-rate	Parameter type: <Qos::RateLimitProtocolRate>	<i>optional parameter with default</i>

21 QoS Configuration Commands

Parameter	Type	Description
	Format: - protocol rate limit value - unit: pps - range: [0...254]	<i>value: 0</i> ICMP V6 rate limit value
[no] icmpv6-burst	Parameter type: <Qos::RateLimitProtocolBurst> Format: - protocol rate limit burst - unit: pps - range: [0...254]	<i>optional parameter with default value: 0</i> ICMP V6 burst value
[no] mld-rate	Parameter type: <Qos::RateLimitProtocolRate> Format: - protocol rate limit value - unit: pps - range: [0...254]	<i>optional parameter with default value: 0</i> MLD rate limit value
[no] mld-burst	Parameter type: <Qos::RateLimitProtocolBurst> Format: - protocol rate limit burst - unit: pps - range: [0...254]	<i>optional parameter with default value: 0</i> MLD burst value
[no] dhcpv6-rate	Parameter type: <Qos::RateLimitProtocolRate> Format: - protocol rate limit value - unit: pps - range: [0...254]	<i>optional parameter with default value: 0</i> DHCP V6 rate limit value
[no] dhcpv6-burst	Parameter type: <Qos::RateLimitProtocolBurst> Format: - protocol rate limit burst - unit: pps - range: [0...254]	<i>optional parameter with default value: 0</i> DHCP v6 burst value
[no] cfm-rate	Parameter type: <Qos::RateLimitProtocolRate> Format: - protocol rate limit value - unit: pps - range: [0...254]	<i>optional parameter with default value: 0</i> CFM rate limit value
[no] cfm-burst	Parameter type: <Qos::RateLimitProtocolBurst> Format: - protocol rate limit burst - unit: pps - range: [0...254]	<i>optional parameter with default value: 0</i> CFM burst value

21.35 QoS DSCP to Pbit Mapping Profile Configuration Command

Command Description

This command allows the operator to configure a QoS DSCP to Pbit mapping profile. To configure the DSCP codepoints in the DSCP to dot1p mapping, the command "**configure qos profiles dscp-pbit (name) codepoint (codepoint) (value)**" is to be used.

User Level

The command can be accessed by operators with qos privileges, and executed by operators with qos privileges.

Command Syntax

The command has the following syntax:

```
> configure qos profiles ( no dscp-pbit (name) ) | ( dscp-pbit (name) )
```

Command Parameters

Table 21.35-1 "QoS DSCP to Pbit Mapping Profile Configuration Command" Resource Parameters

Resource Identifier	Type	Description
(name)	Format: - a profile name - range: [a-zA-Z0-9-_.] - length: 1<=x<=32	A unique profile name

21.36 QoS DSCP to Pbit Mapping Profile Configuration Command

Command Description

This command allows the operator to configure a QoS DSCP to Pbit mapping profile. To configure the DSCP codepoints in the DSCP to dot1p mapping, the command "**configure qos profiles dscp-pbit (name) codepoint (codepoint) (value)**" is to be used.

User Level

The command can be accessed by operators with qos privileges, and executed by operators with qos privileges.

Command Syntax

The command has the following syntax:

```
> configure qos profiles dscp-pbit (name) codepoint (codepoint) [ dot1p-value <Qos::DscpToDot1PAlign> ]
```

Command Parameters

Table 21.36-1 "QoS DSCP to Pbit Mapping Profile Configuration Command" Resource Parameters

Resource Identifier	Type	Description
(name)	Format: - a profile name - range: [a-zA-Z0-9-_.] - length: 1<=x<=32	A unique profile name
(codepoint)	Format: - the number of the DSCP codepoint - range: [0...63]	the value of the codepoint

Table 21.36-2 "QoS DSCP to Pbit Mapping Profile Configuration Command" Command Parameters

Parameter	Type	Description
dot1p-value	Parameter type: <Qos::DscpToDot1PAlign> Format: - the DOT1P value - range: [0...7]	<i>optional parameter</i> the dot1p value to be assigned to the dscp codepoint

21.37 QoS DSCP to Tc Mapping Profile Configuration Command

Command Description

*This command allows the operator to configure a QoS DSCP to Tc mapping profile. To configure the DSCP codepoints in the DSCP to tc mapping, the command "**configure qos profiles dscp-tc (name) codepoint (codepoint) (value)**" is to be used.*

User Level

The command can be accessed by operators with qos privileges, and executed by operators with qos privileges.

Command Syntax

The command has the following syntax:

```
> configure qos profiles ( no dscp-tc (name) ) | ( dscp-tc (name) )
```

Command Parameters

Table 21.37-1 "QoS DSCP to Tc Mapping Profile Configuration Command" Resource Parameters

Resource Identifier	Type	Description
(name)	Format: - a profile name - range: [a-zA-Z0-9-_.] - length: 1<=x<=32	A unique profile name

21.38 QoS DSCP to Tc Mapping Profile Configuration Command

Command Description

*This command allows the operator to configure a QoS DSCP to Tc mapping profile. To configure the DSCP codepoints in the DSCP to tc mapping, the command "**configure qos profiles dscp-tc (name) codepoint (codepoint) (value)**" is to be used.*

User Level

The command can be accessed by operators with qos privileges, and executed by operators with qos privileges.

Command Syntax

The command has the following syntax:

```
> configure qos profiles dscp-tc (name) codepoint (codepoint) [ tc-value <Qos::DscpToTcAlign> ]
```

Command Parameters

Table 21.38-1 "QoS DSCP to Tc Mapping Profile Configuration Command" Resource Parameters

Resource Identifier	Type	Description
(name)	Format: - a profile name - range: [a-zA-Z0-9-_.] - length: 1<=x<=32	A unique profile name
(codepoint)	Format: - the number of the DSCP codepoint - range: [0...63]	the value of the codepoint

Table 21.38-2 "QoS DSCP to Tc Mapping Profile Configuration Command" Command Parameters

Parameter	Type	Description
tc-value	Parameter type: <Qos::DscpToTcAlign> Format: - the Tc value - range: [0...7]	<i>optional parameter</i> the tc value to be assigned to the dscp codepoint

21.39 QoS Policer Per Tc Profile Configure

Command Description

This command allows the operator to configure policer per tc profile. .

User Level

The command can be accessed by operators with qos privileges, and executed by operators with qos privileges.

Command Syntax

The command has the following syntax:

> configure qos profiles (no policer-per-tc (name)) | (policer-per-tc (name))

Command Parameters

Table 21.39-1 "QoS Policer Per Tc Profile Configure" Resource Parameters

Resource Identifier	Type	Description
(name)	Format: - a profile name - range: [a-zA-Z0-9-_.] - length: 1<=x<=32	A unique profile name

21.40 QoS Policer Per Tc Profile Configure

Command Description

This command allows the operator to configure policer per tc profile. .

User Level

The command can be accessed by operators with qos privileges, and executed by operators with qos privileges.

Command Syntax

The command has the following syntax:

```
> configure qos profiles policer-per-tc (name) tc-policer (tc) [ no policer | policer <Qos::QosPolicerProfileName> ]
```

Command Parameters

Table 21.40-1 "QoS Policer Per Tc Profile Configure" Resource Parameters

Resource Identifier	Type	Description
(name)	Format: - a profile name - range: [a-zA-Z0-9-_.] - length: 1<=x<=32	A unique profile name
(tc)	Format: - the number of the TC index - range: [0...7]	the value of the tc index

Table 21.40-2 "QoS Policer Per Tc Profile Configure" Command Parameters

Parameter	Type	Description
[no] policer	Parameter type: <Qos::QosPolicerProfileName> Format: (none name : <Qos::IgnoredQosProfileName>) Possible values: - none : no profile name to associate - name : enter profile name to be associated Data driven field type Possible values are depending on the actual configuration and software. The currently allowed values can be shown with online-help.	<i>optional parameter with default value: "none"</i> the value of the tc

21.41 QoS CoS Threshold Profile Configuration Command

Command Description

This command allows the operator to configure a QoS CoS threshold profile. A QoS CoS threshold profile contains all settings related to a policer threshold.

User Level

The command can be accessed by operators with qos privileges, and executed by operators with qos privileges.

Command Syntax

The command has the following syntax:

```
> configure qos profiles ( no cos-threshold (name) ) | ( cos-threshold (name) [ no tc0-threshold | tc0-threshold
<Qos::tcThreshold> ] [ no tc1-threshold | tc1-threshold <Qos::tcThreshold> ] [ no tc2-threshold | tc2-threshold
<Qos::tcThreshold> ] [ no tc3-threshold | tc3-threshold <Qos::tcThreshold> ] [ no tc4-threshold | tc4-threshold
<Qos::tcThreshold> ] [ no tc5-threshold | tc5-threshold <Qos::tcThreshold> ] [ no tc6-threshold | tc6-threshold
<Qos::tcThreshold> ] [ no tc7-threshold | tc7-threshold <Qos::tcThreshold> ] )
```

Command Parameters

Table 21.41-1 "QoS CoS Threshold Profile Configuration Command" Resource Parameters

Resource Identifier	Type	Description
(name)	Format: - a profile name - range: [a-zA-Z0-9-_.] - length: 1<=x<=32	A unique profile name

Table 21.41-2 "QoS CoS Threshold Profile Configuration Command" Command Parameters

Parameter	Type	Description
[no] tc0-threshold	Parameter type: <Qos::tcThreshold> Format: - Percentage of the QoS Thresh - range: [0...100]	<i>optional parameter with default value: 0</i> tc0 threshold, unit: percent
[no] tc1-threshold	Parameter type: <Qos::tcThreshold> Format: - Percentage of the QoS Thresh - range: [0...100]	<i>optional parameter with default value: 0</i> tc1 threshold, unit: percent
[no] tc2-threshold	Parameter type: <Qos::tcThreshold> Format: - Percentage of the QoS Thresh - range: [0...100]	<i>optional parameter with default value: 0</i> tc2 threshold, unit: percent
[no] tc3-threshold	Parameter type: <Qos::tcThreshold> Format:	<i>optional parameter with default value: 0</i>

21 QoS Configuration Commands

Parameter	Type	Description
	- Percentage of the QoS Thresh - range: [0...100]	tc3 threshold, unit: percent
[no] tc4-threshold	Parameter type: <Qos::tcThreshold> Format: - Percentage of the QoS Thresh - range: [0...100]	<i>optional parameter with default value: 0</i> tc4 threshold, unit: percent
[no] tc5-threshold	Parameter type: <Qos::tcThreshold> Format: - Percentage of the QoS Thresh - range: [0...100]	<i>optional parameter with default value: 0</i> tc5 threshold, unit: percent
[no] tc6-threshold	Parameter type: <Qos::tcThreshold> Format: - Percentage of the QoS Thresh - range: [0...100]	<i>optional parameter with default value: 0</i> tc6 threshold, unit: percent
[no] tc7-threshold	Parameter type: <Qos::tcThreshold> Format: - Percentage of the QoS Thresh - range: [0...100]	<i>optional parameter with default value: 0</i> tc7 threshold, unit: percent

21.42 QoS Board-Level Queue and Performance Configuration Command

Command Description

This command allows the operator to configure various parameters related to board-level traffic load and packet loss.

User Level

The command can be accessed by operators with qos privileges, and executed by operators with qos privileges.

Command Syntax

The command has the following syntax:

```
> configure qos global (index) [ no buffer-occ-thresh | buffer-occ-thresh <Qos::PercentThresh> ] [ [ no ]
queue-stats ] [ [ no ] dsload-tca ] [ no dsload-thresh | dsload-thresh <Qos::PercentThresh> ] [ [ no ] buffer-tca ] [ no
up-buf-thresh | up-buf-thresh <Qos::UpAggrBufOvflwTcaTh> ] [ no up-obc-thresh | up-obc-thresh
<Qos::UpObcAggrBufOvflwTcaTh> ] [ no dn-obc-thresh | dn-obc-thresh <Qos::DnObcAggrBufOvflwTcaTh> ] [
no dn-buf-thresh | dn-buf-thresh <Qos::DnUcAggrBufOvflwTcaTh> ] [ no part-buf-thresh | part-buf-thresh
<Qos::PartBufThresh> ]
```

Command Parameters

Table 21.42-1 "QoS Board-Level Queue and Performance Configuration Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: (lt : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::EqSlotId>) Possible values: - lt : lt-slot Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::EqSlotId> - the equipment slot number	the physical number of the slot

Table 21.42-2 "QoS Board-Level Queue and Performance Configuration Command" Command Parameters

Parameter	Type	Description
[no] buffer-occ-thresh	Parameter type: <Qos::PercentThresh> Format:	<i>optional parameter with default value: 0</i>

21 QoS Configuration Commands

Parameter	Type	Description
	- Percentage of the QoS Thresh - range: [0...100]	the ratio of occupied data buffer entries to the LT global data buffer size, above which the partial buffer threshold alarm will be triggered.(only applicable to low priority traffic i.e. BE and CL)
[no] queue-stats	Parameter type: boolean	<i>optional parameter</i> enable or disable generation of queue statistics
[no] dsload-tca	Parameter type: boolean	<i>optional parameter</i> enable or disable the threshold crossing alarm associated to card-level load of downstream traffic
[no] dsload-thresh	Parameter type: <Qos::PercentThresh> Format: - Percentage of the QoS Thresh - range: [0...100]	<i>optional parameter with default value: 0</i> Percentage of LT fan-out load above which the alarm will be triggered.
[no] buffer-tca	Parameter type: boolean	<i>optional parameter</i> enable the threshold crossover alarm of aggregation buffer overflow
[no] up-buf-thresh	Parameter type: <Qos::UpAggrBufOvflwTcaTh> Format: - Qos thresh - range: [0...2147483647]	<i>optional parameter with default value: 0</i> the threshold of upstream aggregation buffer overflow TCA.
[no] up-obc-thresh	Parameter type: <Qos::UpObcAggrBufOvflwTcaTh> Format: - Qos thresh - range: [0...2147483647]	<i>optional parameter with default value: 0</i> The threshold of OBC-directed upstream aggregation buffer overflow TCA.
[no] dn-obc-thresh	Parameter type: <Qos::DnObcAggrBufOvflwTcaTh> Format: - Qos thresh - range: [0...2147483647]	<i>optional parameter with default value: 0</i> The threshold of downstream OBC-directed aggregation buffer overflow TCA.
[no] dn-buf-thresh	Parameter type: <Qos::DnUcAggrBufOvflwTcaTh> Format: - Qos thresh - range: [0...2147483647]	<i>optional parameter with default value: 0</i> The threshold of downstream data aggregation buffer overflow TCA.
[no] part-buf-thresh	Parameter type: <Qos::PartBufThresh> Format: - threshold of dropped lower class packets of global buffer. range: [0...18446744073709551615]	<i>optional parameter with default value: "0"</i> The threshold of dropped lower class packets of global buffer occupancy threshold overflow TCA.

21.43 QoS Queue Threshold Crossing Alarm Configuration Command

Command Description

This command allows the operator to configure various parameters related to subscriber interface and queue level traffic load and packet loss.

Load per physical line is calculated by matching the total number of bytes transmitted versus the capacity of the interface in the relevant measurement epoch. Load per queue is measured in terms of the contribution to the interface level load of traffic passed in a certain queue.

Threshold crossing alarms can be specified for the load and packet loss parameters per line and per traffic class.

This feature can be useful to detect network anomalies by watching over packet discard or load level in high-priority traffic classes.

User Level

The command can be accessed by operators with qos privileges, and executed by operators with qos privileges.

Command Syntax

The command has the following syntax:

```
> configure qos tca (index) queue <Qos::TcaQueues> [ [ no ] tca-enable ] [ no load-thresh | load-thresh <Qos::PercentThresh> ] [ no dis-frame-th | dis-frame-th <Qos::QosQueueStatsDiscFramesTcaThreshold> ] [ no qpeak-usage-th | qpeak-usage-th <Qos::PercentThresh> ]
```

Command Parameters

Table 21.43-1 "QoS Queue Threshold Crossing Alarm Configuration Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> / <Eqpt::OntPortId> pon : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> ont : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / voip <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / vuni	physical port or lag port of a dsl link

Resource Identifier	Type	Description
	ellid : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::LLId> epon : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> eont : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> / <Eqpt::OntPortId> : <Eqpt::UnstackedVlan> vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> / <Eqpt::OntPortId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / voip : <Eqpt::UnstackedVlan> vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / vuni : <Eqpt::UnstackedVlan> vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / voip : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / vuni : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::UnstackedVlan> vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> chpair : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::ChannelPairId> ont.ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> uni.ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / <Eqpt::Ng2OntSlotId> / <Eqpt::Ng2OntPortId> vlan.ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / <Eqpt::Ng2OntSlotId> / <Eqpt::Ng2OntPortId> : <Eqpt::UnstackedVlan> vlan.ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / <Eqpt::Ng2OntSlotId> / <Eqpt::Ng2OntPortId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> ltbackpl : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> uni.ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / vuni vlan.ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / vuni : <Eqpt::UnstackedVlan> vlan.ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / vuni : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> x-pon : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::XPonId> 25g-pon : <Eqpt::RackId> / <Eqpt::ShelfId> /	

Resource Identifier	Type	Description
	<Eqpt::SlotId> / <Eqpt::M25GPonId>) Possible values: - pon : pon - x-pon : xgs pon - 25g-pon : 25g pon - chpair : channel pair - ont : ont - epon : epon - eont : eont - ellid : ellid - vlan : vlan - ont:ng2 : ngpon2 ONT style identification - uni:ng2 : ngpon2 UNI style identification - vlan:ng2 : ngpon2 vlan - ltbackpl : Backplane Port on LT Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number Field type <Eqpt::PonId> - the PON identifier Field type <Eqpt::XPonId> - the XGS PON identifier Field type <Eqpt::M25GPonId> - the 25G PON identifier Field type <Eqpt::ChannelPairId> - the channel pair identifier Field type <Eqpt::ChannelGroupId> - the channel group identifier Field type <Eqpt::SubChannelGroupId> - the subchannel group identifier Field type <Eqpt::OntId> - the ONT identifier Field type <Eqpt::Ng2OntId> - the NG2 ONT identifier Field type <Eqpt::LLId> - the LLID identifier, range 1 for EPON, range 1-8 for DPOE Possible values: - voip : virtual uni identifier obsolete alternative replaced by vuni - vuni : virtual uni identifier Possible values: - vuni : virtual NGPON2 uni identifier Field type <Eqpt::OntSlotId> - the ONT SLOT identifier Field type <Eqpt::OntPortId> - the ONT PORT identifier Field type <Eqpt::Ng2OntSlotId> - the NGPON2 ONT SLOT identifier Field type <Eqpt::Ng2OntPortId> - the NGPON2 ONT PORT identifier Possible values: - stacked : stacked vlan identity	

21 QoS Configuration Commands

Resource Identifier	Type	Description
	Field type <Eqpt::UnstackedVlan> - unstacked vlan id Field type <Eqpt::SVlan> - service vlan id Field type <Eqpt::CVlan> - customer vlan id	
queue	Parameter type: <Qos::TcaQueues> Format: - output dsl/gpon/epon port queue number - range: [0...7,255]	the queue with in the scope of one dsl link of tca

Table 21.43-2 "QoS Queue Threshold Crossing Alarm Configuration Command" Command Parameters

Parameter	Type	Description
[no] tca-enable	Parameter type: boolean	<i>optional parameter</i> each queue statistic TCA of this queue
[no] load-thresh	Parameter type: <Qos::PercentThresh> Format: - Percentage of the QoS Thresh - range: [0...100]	<i>optional parameter with default value: 0</i> The threshold of queue traffic load.
[no] dis-frame-th	Parameter <Qos::QosQueueStatsDiscFramesTcaThreshold> Format: - Qos thresh - range: [0...2147483647]	type: <i>optional parameter with default value: 0</i> The threshold of discarded frames of this queue.
[no] qpeak-usage-th	Parameter type: <Qos::PercentThresh> Format: - Percentage of the QoS Thresh - range: [0...100]	<i>optional parameter with default value: 0</i> The threshold of the per queue traffic peak usage.

21.44 QoS DSL Link Configuration Command

Command Description

Obsolete command, replaced by `configure qos interface (index)`.

This command allows the operator to configure QoS settings on subscriber interfaces. For each subscriber interface the operator can apply scheduling and CAC settings.

A scheduler profile is used to configure egress scheduler settings for egress subscriber interfaces on L3 cards. A CAC profile is used to configure CAC settings for a subscriber interface.

User Level

The command can be accessed by operators with qos privileges, and executed by operators with qos privileges.

Command Syntax

The command has the following syntax:

```
> configure qos dsl-port (index) [ no scheduler-profile | scheduler-profile <Qos::SchedulerProfName> ] [
cac-profile <Qos::QosCacProfileName> ]
```

Obsolete command, replaced by `configure qos interface (index)`.

Command Parameters

Table 21.44-1 "QoS DSL Link Configuration Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number	physical port of a subscriber interface.

Table 21.44-2 "QoS DSL Link Configuration Command" Command Parameters

Parameter	Type	Description
[no] scheduler-profile	Parameter type: <Qos::SchedulerProfName> Format: name : <Qos::IgnoredQosProfileName> Possible values: - name : enter profile name to be associated Data driven field type Possible values are depending on the actual configuration	<i>optional parameter with default value: "name : CL_66"</i> name of scheduler profile to be mapped on this subscriber interface.

21 QoS Configuration Commands

Parameter	Type	Description
	and software. The currently allowed values can be shown with online-help.	
cac-profile	Parameter type: <Qos::QosCacProfileName> Format: (name : <Qos::IgnoredQosProfileName> none) Possible values: - none : no profile name to associated - name : enter profile name to be associated Data driven field type Possible values are depending on the actual configuration and software. The currently allowed values can be shown with online-help.	<i>optional parameter</i> name of cac profile to be mapped on this subscriber interface.

21.45 QoS LIM Queue Configuration Command

Command Description

Obsolete command, replaced by `configure qos interface (index) queue`.

This command allows the operator to configure a QoS Line Card queue. On the L3 line cards, each DSL interface supports four downstream buffers, which can be configured independently using buffer acceptance control (BAC) profiles.

The operator can configure downstream buffers, such that the total buffer pool is oversubscribed. However, this is not recommended because this allows QoS un-aware packet discard. If the total downstream buffer pool is over-subscribed, the system logs a warning message. Proceed with care, as this allows QoS un-aware packet discard in extreme traffic conditions.

User Level

The command can be accessed by operators with qos privileges, and executed by operators with qos privileges.

Command Syntax

The command has the following syntax:

```
> configure qos dsl-port (index) queue (queue) [ queue-profile <Qos::QosQueueProfileName> ]
```

Obsolete command, replaced by `configure qos interface (index) queue`.

Command Parameters

Table 21.45-1 "QoS LIM Queue Configuration Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number	physical port of a subscriber interface.
(queue)	Format: - output dsl/gpon/epon port queue number - range: [0...7,255]	queue in scope of 1 dsl link on a line-interface-module

Table 21.45-2 "QoS LIM Queue Configuration Command" Command Parameters

Parameter	Type	Description
queue-profile	Parameter type: <Qos::QosQueueProfileName> Format:	<i>optional parameter</i> name of the queue profile

21 QoS Configuration Commands

Parameter	Type	Description
	(none name : <Qos::IgnoredQosProfileName>) Possible values: - none : no profile name to associated - name : enter profile name to be associated Data driven field type Possible values are depending on the actual configuration and software. The currently allowed values can be shown with online-help.	

21.46 QoS ShdSL Link Configuration Command

Command Description

Obsolete command, replaced by `configure qos interface (index)`.

This command allows the operator to configure Shdsl links. For each Shdsl link the operator can apply scheduling and CAC settings.

A scheduler profile is used to configure egress scheduler settings for each egress Shdsl interface. A CAC profile is used to configure CAC settings for each Shdsl interface.

The Shdsl link table can be configured on the SMLT-H , SMLT-J and NSLT-A units.

User Level

The command can be accessed by operators with qos privileges, and executed by operators with qos privileges.

Command Syntax

The command has the following syntax:

```
> configure qos shdsl-port (index) [ scheduler-profile <Qos::QoS Scheduler Profile Name> ] [ cac-profile <Qos::QoS CAC Profile Name> ]
```

Obsolete command, replaced by `configure qos interface (index)`.

Command Parameters

Table 21.46-1 "QoS ShdSL Link Configuration Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number	physical port of a shdsl link

Table 21.46-2 "QoS ShdSL Link Configuration Command" Command Parameters

Parameter	Type	Description
scheduler-profile	Parameter type: <Qos::QoS Scheduler Profile Name> Format: (none name : <Qos::IgnoredQoS Profile Name>) Possible values: - none : no profile name to associate	<i>optional parameter</i> name of scheduler profile to be mapped on this dsl link

21 QoS Configuration Commands

Parameter	Type	Description
	- name : enter profile name to be associated Data driven field type Possible values are depending on the actual configuration and software. The currently allowed values can be shown with online-help.	
cac-profile	Parameter type: <Qos::QosCacProfileName> Format: (name : <Qos::IgnoredQosProfileName> none) Possible values: - none : no profile name to associated - name : enter profile name to be associated Data driven field type Possible values are depending on the actual configuration and software. The currently allowed values can be shown with online-help.	<i>optional parameter</i> name of cac profile to be mapped on this dsl link

21.47 QoS LIM Queue (SHDSL) Configuration Command

Command Description

Obsolete command, replaced by `configure qos interface (index) queue`.

This command allows the operator to configure a QoS Line Card queue. On the L3 line cards, each SHDSL interface supports four downstream buffers, which can be configured independently using buffer acceptance control (BAC) profiles.

The operator can configure downstream buffers, such that the total buffer pool is oversubscribed. However, this is not recommended because this allows QoS un-aware packet discard. If the total downstream buffer pool is over-subscribed, the system logs a warning message. Proceed with care, as this allows QoS un-aware packet discard in extreme traffic conditions.

User Level

The command can be accessed by operators with qos privileges, and executed by operators with qos privileges.

Command Syntax

The command has the following syntax:

```
> configure qos shdsl-port (index) queue (queue) [ queue-profile <Qos::QosQueueProfileName> ]
```

Obsolete command, replaced by `configure qos interface (index) queue`.

Command Parameters

Table 21.47-1 "QoS LIM Queue (SHDSL) Configuration Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number	physical port of a shdsl link
(queue)	Format: - output dsl/gpon/epon port queue number - range: [0...7,255]	queue in scope of 1 dsl link on a line-interface-module

Table 21.47-2 "QoS LIM Queue (SHDSL) Configuration Command" Command Parameters

21 QoS Configuration Commands

Parameter	Type	Description
queue-profile	Parameter type: <Qos::QosQueueProfileName> Format: (none name : <Qos::IgnoredQosProfileName>) Possible values: - none : no profile name to associated - name : enter profile name to be associated Data driven field type Possible values are depending on the actual configuration and software. The currently allowed values can be shown with online-help.	<i>optional parameter</i> name of the queue profile

21.48 QoS Interface Configuration Command

Command Description

This command allows the operator to configure QoS settings on a user-port Interface. A user-port Interface can be a DSL-link, an Shdsl-link, an Ethernet Line, a Link Aggregation Group or a pon, ont or uni interface. For each Interface the operator can apply scheduling and CAC and shaper settings.

A scheduler node profile is used to configure egress scheduler settings for each egress Interface. A CAC profile is used to configure CAC settings for each Interface. A shaper profile is used to configure downstream flooding shaper settings for each Interface.

User Level

The command can be accessed by operators with qos privileges, and executed by operators with qos privileges.

Command Syntax

The command has the following syntax:

```
> configure qos interface (index) [ no scheduler-node | scheduler-node <Qos::SchedulerNodeProfName> ] [ no
ingress-profile | ingress-profile <Qos::QosIngressProfileNameEOnu> ] [ no cac-profile | cac-profile
<Qos::QosCacProfileName> ] [ no ext-cac | ext-cac <Qos::QosCacProfileName> ] [ [ no ] ds-queue-sharing ] [ [ no
] us-queue-sharing ] [ no ds-num-queue | ds-num-queue <Qos::NumberOfQueues> ] [ no ds-num-rem-queue |
ds-num-rem-queue <Qos::NumberOfQueues> ] [ no us-num-queue | us-num-queue <Qos::NumberOfQueues> ] [ [
no ] queue-stats-on ] [ [ no ] autoschedule ] [ oper-weight <Qos::QosWeight> ] [ oper-rate
<Qos::ShaperExcessiveInfoRate> ] [ [ no ] us-vlanport-queue ] [ no dsfld-shaper-prof | dsfld-shaper-prof
<Qos::QosShaperProfileName> ] [ no bandwidth-profile | bandwidth-profile <Qos::QosBandwidthProfileName> ] [
no bandwidth-sharing | bandwidth-sharing <Qos::UniBandwidthSharing> ] [ no aggr-usq-profile | aggr-usq-profile
<Qos::QosAggrQueuesConfigProfileName> ] [ no aggr-dsq-profile | aggr-dsq-profile
<Qos::QosAggrQueuesConfigProfileName> ] [ no gem-sharing | gem-sharing <Qos::GemSharing> ] [ no
scheduler-mode | scheduler-mode <Qos::SchedulerMode> ] [ no mc-scheduler-node | mc-scheduler-node
<Qos::SchedulerNodeProfName> ] [ no bc-scheduler-node | bc-scheduler-node <Qos::SchedulerNodeProfName> ]
[ no ds-schedule-tag | ds-schedule-tag <Qos::DsScheduleTag> ]
```

Command Parameters

Table 21.48-1 "QoS Interface Configuration Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> / <Eqpt::OntPortId> pon : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> ont : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> /	physical port or la-group of a user-port Interface

Resource Identifier	Type	Description
	<code><Eqpt::PonId> / <Eqpt::OntId> / voip</code> <code> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> /</code> <code><Eqpt::PonId> / <Eqpt::OntId> / vuni</code> <code> ellid : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> /</code> <code><Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::LLId></code> <code> epon : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> /</code> <code><Eqpt::PonId></code> <code> eont : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> /</code> <code><Eqpt::PonId> / <Eqpt::OntId></code> <code> vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> /</code> <code><Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> /</code> <code><Eqpt::OntPortId> : <Eqpt::UnstackedVlan></code> <code> vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> /</code> <code><Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> /</code> <code><Eqpt::OntPortId> : stacked : <Eqpt::SVlan> :</code> <code><Eqpt::CVlan></code> <code> vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> /</code> <code><Eqpt::PonId> / <Eqpt::OntId> / voip :</code> <code><Eqpt::UnstackedVlan></code> <code> vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> /</code> <code><Eqpt::PonId> / <Eqpt::OntId> / vuni :</code> <code><Eqpt::UnstackedVlan></code> <code> vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> /</code> <code><Eqpt::PonId> / <Eqpt::OntId> / voip : stacked :</code> <code><Eqpt::SVlan> : <Eqpt::CVlan></code> <code> vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> /</code> <code><Eqpt::PonId> / <Eqpt::OntId> / vuni : stacked :</code> <code><Eqpt::SVlan> : <Eqpt::CVlan></code> <code> vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> /</code> <code><Eqpt::PortId> : <Eqpt::UnstackedVlan></code> <code> vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> /</code> <code><Eqpt::PortId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan></code> <code> chpair : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId></code> <code>/ <Eqpt::ChannelPairId></code> <code> ont:ng2 : <Eqpt::ChannelGroupId> /</code> <code><Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId></code> <code> uni:ng2 : <Eqpt::ChannelGroupId> /</code> <code><Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> /</code> <code><Eqpt::Ng2OntSlotId> / <Eqpt::Ng2OntPortId></code> <code> vlan:ng2 : <Eqpt::ChannelGroupId> /</code> <code><Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> /</code> <code><Eqpt::Ng2OntSlotId> / <Eqpt::Ng2OntPortId> :</code> <code><Eqpt::UnstackedVlan></code> <code> vlan:ng2 : <Eqpt::ChannelGroupId> /</code> <code><Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> /</code> <code><Eqpt::Ng2OntSlotId> / <Eqpt::Ng2OntPortId> : stacked :</code> <code><Eqpt::SVlan> : <Eqpt::CVlan></code> <code> lbackpl : <Eqpt::RackId> / <Eqpt::ShelfId> /</code> <code><Eqpt::SlotId></code> <code> uni:ng2 : <Eqpt::ChannelGroupId> /</code> <code><Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / vuni</code> <code> vlan:ng2 : <Eqpt::ChannelGroupId> /</code> <code><Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / vuni :</code> <code><Eqpt::UnstackedVlan></code> <code> vlan:ng2 : <Eqpt::ChannelGroupId> /</code> <code><Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / vuni :</code> <code>stacked : <Eqpt::SVlan> : <Eqpt::CVlan></code>	

Resource Identifier	Type	Description
	x-pon : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::XPonId> 25g-pon : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::M25GPonId>) Possible values: - pon : pon - x-pon : xgs pon - 25g-pon : 25g pon - chpair : channel pair - ont : ont - epon : epon - eont : eont - ellid : ellid - vlan : vlan - ont:ng2 : ngpon2 ONT style identification - uni:ng2 : ngpon2 UNI style identification - vlan:ng2 : ngpon2 vlan - ltbackpl : Backplane Port on LT Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number Field type <Eqpt::PonId> - the PON identifier Field type <Eqpt::XPonId> - the XGS PON identifier Field type <Eqpt::M25GPonId> - the 25G PON identifier Field type <Eqpt::ChannelPairId> - the channel pair identifier Field type <Eqpt::ChannelGroupId> - the channel group identifier Field type <Eqpt::SubChannelGroupId> - the subchannel group identifier Field type <Eqpt::OntId> - the ONT identifier Field type <Eqpt::Ng2OntId> - the NG2 ONT identifier Field type <Eqpt::LLId> - the LLID identifier, range 1 for EPON, range 1-8 for DPOE Possible values: - voip : virtual uni identifier obsolete alternative replaced by vuni - vuni : virtual uni identifier Possible values: - vuni : virtual NGPON2 uni identifier Field type <Eqpt::OntSlotId> - the ONT SLOT identifier Field type <Eqpt::OntPortId> - the ONT PORT identifier Field type <Eqpt::Ng2OntSlotId> - the NGPON2 ONT SLOT identifier Field type <Eqpt::Ng2OntPortId>	

21 QoS Configuration Commands

Resource Identifier	Type	Description
	- the NGPON2 ONT PORT identifier Possible values: - stacked : stacked vlan identity Field type <Eqpt::UnstackedVlan> - unstacked vlan id Field type <Eqpt::SVlan> - service vlan id Field type <Eqpt::CVlan> - customer vlan id	

Table 21.48-2 "QoS Interface Configuration Command" Command Parameters

Parameter	Type	Description
[no] scheduler-node	Parameter type: <Qos::SchedulerNodeProfName> Format: (none name : <Qos::IgnoredQosProfileName>) Possible values: - none : no profile name to associated - name : enter profile name to be associated Data driven field type Possible values are depending on the actual configuration and software. The currently allowed values can be shown with online-help.	<i>optional parameter with default value: "none"</i> the name of the scheduler-node profile to be mapped on this user-port Interface
[no] ingress-profile	Parameter type: <Qos::QosIngressProfileNameEOnu> Format: (none name : <Qos::IgnoredQosProfileName>) Possible values: - none : no profile name to associated - name : enter profile name to be associated Data driven field type Possible values are depending on the actual configuration and software. The currently allowed values can be shown with online-help.	<i>optional parameter with default value: "none"</i> the name of the ingress profile to be mapped on this user-port Interface. It only used for EPON ONU interface current.
[no] cac-profile	Parameter type: <Qos::QosCacProfileName> Format: (name : <Qos::IgnoredQosProfileName> none) Possible values: - none : no profile name to associated - name : enter profile name to be associated Data driven field type Possible values are depending on the actual configuration and software. The currently allowed values can be shown with online-help.	<i>optional parameter with default value: "none"</i> the name of the cac profile to be mapped on this user-port Interface. For EPON OLT in downstream, this profile used for CAC on 1G PON bandwidth.
[no] ext-cac	Parameter type: <Qos::QosCacProfileName> Format: (name : <Qos::IgnoredQosProfileName> none) Possible values: - none : no profile name to associated - name : enter profile name to be associated Data driven field type Possible values are depending on the actual configuration and software. The currently allowed values can be shown with online-help.	<i>optional parameter with default value: "none"</i> the name of the cac profile to be mapped on this user-port Interface. For EPON OLT in downstream, this profile used for CAC on 10G PON bandwidth.
[no] ds-queue-sharing	Parameter type: boolean	<i>optional parameter</i>

Parameter	Type	Description
[no] us-queue-sharing	Parameter type: boolean	enable downstream queue sharing <i>optional parameter</i> enable upstream queue sharing
[no] ds-num-queue	Parameter type: <Qos::NumberofQueues> Format: (not-applicable <Qos::NumberofQueues>) Possible values: - not-applicable : not applicable Field type <Qos::NumberofQueues> - number of queues per uni - range: [4,8,1]	<i>optional parameter with default value: 4</i> number of downstream queues per uni
[no] ds-num-rem-queue	Parameter type: <Qos::NumberofQueues> Format: (not-applicable <Qos::NumberofQueues>) Possible values: - not-applicable : not applicable Field type <Qos::NumberofQueues> - number of queues per uni - range: [4,8,1]	<i>optional parameter with default value: 0</i> number of remote downstream queues per ont
[no] us-num-queue	Parameter type: <Qos::NumberofQueues> Format: (not-applicable <Qos::NumberofQueues>) Possible values: - not-applicable : not applicable Field type <Qos::NumberofQueues> - number of queues per uni - range: [4,8,1]	<i>optional parameter with default value: 8</i> number of upstream queues per uni
[no] queue-stats-on	Parameter type: boolean	<i>optional parameter</i> enable queue stats collection for ont uni
[no] autoschedule	Parameter type: boolean	<i>optional parameter</i>
oper-weight	Parameter type: <Qos::QosWeight> Format: - relative weight - range: [0...127]	<i>optional parameter</i> operational weight of the ONT or UNI scheduler
oper-rate	Parameter type: <Qos::ShaperExcessiveInfoRate> Format: - excessive information rate of a shaper - unit: kbps - range: [0...2147483647]	<i>optional parameter</i> Operational rate limit when autoShape enabled for ONT or UNI
[no] us-vlanport-queue	Parameter type: boolean	<i>optional parameter</i> Enable Vlan Port Level Queue Configuration
[no] dsfld-shaper-prof	Parameter type: <Qos::QosShaperProfileName> Format: (none name : <Qos::IgnoredQosProfileName>) Possible values: - none : no profile name to associated - name : enter profile name to be associated Data driven field type Possible values are depending on the actual configuration and software. The currently allowed values can be shown with online-help.	<i>optional parameter with default value: "none"</i> the name of the shaper profile attached to the pon

21 QoS Configuration Commands

Parameter	Type	Description
[no] bandwidth-profile	Parameter type: <Qos::QosBandwidthProfileName> Format: (name : <Qos::IgnoredQosProfileName> none) Possible values: - none : no profile name to associate - name : enter profile name to be associated Data driven field type Possible values are depending on the actual configuration and software. The currently allowed values can be shown with online-help.	<i>optional parameter with default value: "none"</i> the name of the bandwidth profile.
[no] bandwidth-sharing	Parameter type: <Qos::UniBandwidthSharing> Format: (no-sharing ont-sharing) Possible values: - no-sharing : disable bandwidth sharing - ont-sharing : enable UNI level BW or TCONT sharing across UNIs of an ONT	<i>optional parameter with default value: "no-sharing"</i> enable or disable bandwidth sharing
[no] aggr-usq-profile	Parameter type: <Qos::QosAggrQueuesConfigProfileName> Format: (none name : <Qos::IgnoredQosProfileName>) Possible values: - none : no profile name to associated - name : enter profile name to be associated Data driven field type Possible values are depending on the actual configuration and software. The currently allowed values can be shown with online-help.	<i>optional parameter with default value: "none"</i> the name of the aggrQueuesConfig profile applied on upstream queues of an UNI.
[no] aggr-dsq-profile	Parameter type: <Qos::QosAggrQueuesConfigProfileName> Format: (none name : <Qos::IgnoredQosProfileName>) Possible values: - none : no profile name to associated - name : enter profile name to be associated Data driven field type Possible values are depending on the actual configuration and software. The currently allowed values can be shown with online-help.	<i>optional parameter with default value: "none"</i> the name of the aggrQueuesConfig profile applied on downstream queues of an UNI.
[no] gem-sharing	Parameter type: <Qos::GemSharing> Format: (enable disable not-applicable) Possible values: - enable : enable GEM sharing - disable : disable GEM sharing - not-applicable : not applicable	<i>optional parameter with default value: "disable"</i> enable or disable gem sharing
[no] scheduler-mode	Parameter type: <Qos::SchedulerMode> Format: (subscriber-hierarchy service-hierarchy service-flat) Possible values: - subscriber-hierarchy : Subscriber-based hierarchical	<i>optional parameter with default value: "subscriber-hierarchy"</i> specifies which mode is selected for scheduler

Parameter	Type	Description
	scheduling. This mode achieves subscriber fairness using a Traffic Management hierarchy of subscriber levels. - service-hierarchy : Service-based hierarchical scheduling. This mode achieves subscriber fairness using a Traffic Management hierarchy of subscriber levels, but also takes into account the service priority across all subscribers to achieve service fairness. - service-flat : Service-based scheduling across all subscribers, using a flat class-based scheduler and aggregated queues associated with the physical port (e.g. PON port).	
[no] mc-scheduler-node	Parameter type: <Qos::SchedulerNodeProfName> Format: (none name : <Qos::IgnoredQosProfileName>) Possible values: - none : no profile name to associated - name : enter profile name to be associated Data driven field type Possible values are depending on the actual configuration and software. The currently allowed values can be shown with online-help.	optional parameter with default value: "name" : Multicast_Default" the name of the scheduler-node profile to be mapped on multicast port
[no] bc-scheduler-node	Parameter type: <Qos::SchedulerNodeProfName> Format: (none name : <Qos::IgnoredQosProfileName>) Possible values: - none : no profile name to associated - name : enter profile name to be associated Data driven field type Possible values are depending on the actual configuration and software. The currently allowed values can be shown with online-help.	optional parameter with default value: "name" : Broadcast_Default" the name of the scheduler-node profile to be mapped on broadcast port
[no] ds-schedule-tag	Parameter type: <Qos::DsScheduleTag> Format: (egressoutertag cvlantag svlantag) Possible values: - egressoutertag : system default behavior: always the egress outer tag used. - cvlantag : Select downstream scheduler based on the c-vlan. - svlantag : Select downstream scheduler based on the s-vlan.	optional parameter with default value: "egressoutertag" specifies downstream scheduler reference

21.49 QoS Interface Queue Configuration

Command

Command Description

This command allows the operator to configure a QoS Line Card queue. On the L3 line cards, each user-port (DSL-Link, Shdsl-link or Ethernet Line or LA-Group) supports four downstream buffers, which can be configured independently using buffer acceptance control (BAC) profiles.

The operator can configure downstream buffers, such that the total buffer pool is oversubscribed. Please take note that this allows QoS un-aware packet discard under extreme traffic conditions. When the total downstream buffer pool is over-subscribed, the system logs a warning message.

Queue profile none only for epon, queue profile must have a name for other boards.

User Level

The command can be accessed by operators with qos privileges, and executed by operators with qos privileges.

Command Syntax

The command has the following syntax:

```
> configure qos interface (index) queue (queue) [ priority <Qos::QosPriority> ] [ weight <Qos::QosWeight> ] [
oper-weight <Qos::QosWeight> ] [ queue-profile <Qos::QosQueueProfName> ] [ shaper-profile
<Qos::QosShaperProfileName> ]
```

Command Parameters

Table 21.49-1 "QoS Interface Queue Configuration Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> / <Eqpt::OntPortId> pon : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> ont : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / voip <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / vuni ellid : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::LLId> epon : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> /	physical port or la-group of a user-port Interface

Resource Identifier	Type	Description
	<pre> <Eqpt::PonId> eont : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> / <Eqpt::OntPortId> : <Eqpt::UnstackedVlan> vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> / <Eqpt::OntPortId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / voip : <Eqpt::UnstackedVlan> vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / vuni : <Eqpt::UnstackedVlan> vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / voip : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / vuni : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::UnstackedVlan> vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> chpair : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::ChannelPairId> ont:ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> uni:ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / <Eqpt::Ng2OntSlotId> / <Eqpt::Ng2OntPortId> vlan:ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / <Eqpt::Ng2OntSlotId> / <Eqpt::Ng2OntPortId> : <Eqpt::UnstackedVlan> vlan:ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / <Eqpt::Ng2OntSlotId> / <Eqpt::Ng2OntPortId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> ltbckpl : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> uni:ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / vuni vlan:ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / vuni : <Eqpt::UnstackedVlan> vlan:ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / vuni : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> x-pon : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::XPonId> 25g-pon : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::M25GPonId>) Possible values: - pon : pon </pre>	

21 QoS Configuration Commands

Resource Identifier	Type	Description
	- x-pon : xgs pon - 25g-pon : 25g pon - chpair : channel pair - ont : ont - epon : epon - eont : eont - ellid : ellid - vlan : vlan - ont:ng2 : ngpon2 ONT style identification - uni:ng2 : ngpon2 UNI style identification - vlan:ng2 : ngpon2 vlan - ltbackpl : Backplane Port on LT - Field type <Eqpt::RackId> - the rack number - Field type <Eqpt::ShelfId> - the shelf number - Field type <Eqpt::SlotId> - the LT slot number - Field type <Eqpt::PortId> - the port number - Field type <Eqpt::PonId> - the PON identifier - Field type <Eqpt::XPonId> - the XGS PON identifier - Field type <Eqpt::M25GPonId> - the 25G PON identifier - Field type <Eqpt::ChannelPairId> - the channel pair identifier - Field type <Eqpt::ChannelGroupId> - the channel group identifier - Field type <Eqpt::SubChannelGroupId> - the subchannel group identifier - Field type <Eqpt::OntId> - the ONT identifier - Field type <Eqpt::Ng2OntId> - the NG2 ONT identifier - Field type <Eqpt::LLId> - the LLID identifier,range 1 for EPON,range 1-8 for DPOE - Possible values: - voip : virtual uni identifier - obsolete alternative replaced by vuni - vuni : virtual uni identifier - Possible values: - vuni : virtual NGPON2 uni identifier - Field type <Eqpt::OntSlotId> - the ONT SLOT identifier - Field type <Eqpt::OntPortId> - the ONT PORT identifier - Field type <Eqpt::Ng2OntSlotId> - the NGPON2 ONT SLOT identifier - Field type <Eqpt::Ng2OntPortId> - the NGPON2 ONT PORT identifier - Possible values: - stacked : stacked vlan identity - Field type <Eqpt::UnstackedVlan> - unstacked vlan id - Field type <Eqpt::SVlan>	

Resource Identifier	Type	Description
	- service vlan id Field type <Eqpt::CVlan> - customer vlan id	
(queue)	Format: - output dsl/gpon/epon port queue number - range: [0...7,255]	queue in scope of 1 user-port Interface on a line-interface-module

Table 21.49-2 "QoS Interface Queue Configuration Command" Command Parameters

Parameter	Type	Description
priority	Parameter type: <Qos::QosPriority> Format: - relative priority - range: [1...8]	<i>optional parameter</i> relative priority of the scheduler
weight	Parameter type: <Qos::QosWeight> Format: - relative weight - range: [0...127]	<i>optional parameter</i> relative weight of the scheduler
oper-weight	Parameter type: <Qos::QosWeight> Format: - relative weight - range: [0...127]	<i>optional parameter</i> relative weight of the scheduler - operational value
queue-profile	Parameter type: <Qos::QosQueueProfName> Format: (none name : <Qos::IgnoredQosProfileName>) Possible values: - none : no profile name to associated - name : enter profile name to be associated Data driven field type Possible values are depending on the actual configuration and software. The currently allowed values can be shown with online-help.	<i>optional parameter</i> name of the queue profile
shaper-profile	Parameter type: <Qos::QosShaperProfileName> Format: (none name : <Qos::IgnoredQosProfileName>) Possible values: - none : no profile name to associated - name : enter profile name to be associated Data driven field type Possible values are depending on the actual configuration and software. The currently allowed values can be shown with online-help.	<i>optional parameter</i> name of the shaper profile

21.50 QoS Interface Upstream Queue Configuration Command

Command Description

This command allows the operator to configure the upstream queues on the LIM with queue profiles

The operator can configure the upstream queue priority and upstream queue weight along with an option to enable or disable the bandwidth sharing.

User Level

The command can be accessed by operators with qos privileges, and executed by operators with qos privileges.

Command Syntax

The command has the following syntax:

```
> configure qos interface (index) upstream-queue (queue) [ no priority | priority <Qos::QosPriority> ] [ no weight |
weight <Qos::QosWeight> ] [ no bandwidth-profile | bandwidth-profile <Qos::QosBandwidthProfileName> ] [ no
ext-bw | ext-bw <Qos::QosBandwidthProfileName> ] [ no bandwidth-sharing | bandwidth-sharing
<Qos::BandwidthSharing> ] [ no queue-profile | queue-profile <Qos::QosQueueProfName> ] [ no shaper-profile |
shaper-profile <Qos::QosShaperProfileName> ]
```

Command Parameters

Table 21.50-1 "QoS Interface Upstream Queue Configuration Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> / <Eqpt::OntPortId> pon : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> ont : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / voip <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / vuni ellid : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::LLId> epon : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> eont : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> /	physical port or la-group of a user-port Interface

Resource Identifier	Type	Description
	<pre> <Eqpt::PonId> / <Eqpt::OntId> vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> / <Eqpt::OntPortId> : <Eqpt::UnstackedVlan> vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> / <Eqpt::OntPortId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / voip : <Eqpt::UnstackedVlan> vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / vuni : <Eqpt::UnstackedVlan> vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / voip : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / vuni : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::UnstackedVlan> vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> chpair : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::ChannelPairId> ont.ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> uni.ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / <Eqpt::Ng2OntSlotId> / <Eqpt::Ng2OntPortId> vlan.ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / <Eqpt::Ng2OntSlotId> / <Eqpt::Ng2OntPortId> : <Eqpt::UnstackedVlan> vlan.ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / <Eqpt::Ng2OntSlotId> / <Eqpt::Ng2OntPortId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> lbackpl : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> uni.ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / vuni vlan.ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / vuni : <Eqpt::UnstackedVlan> vlan.ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / vuni : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> x-pon : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::XPonId> 25g-pon : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::M25GPonId>) Possible values: - pon : pon - x-pon : xgs pon - 25g-pon : 25g pon </pre>	

Resource Identifier	Type	Description
	- chpair : channel pair - ont : ont - epon : epon - eont : eont - ellid : ellid - vlan : vlan - ont:ng2 : ngpon2 ONT style identification - uni:ng2 : ngpon2 UNI style identification - vlan:ng2 : ngpon2 vlan - ltbackpl : Backplane Port on LT - Field type <Eqpt::RackId> - the rack number - Field type <Eqpt::ShelfId> - the shelf number - Field type <Eqpt::SlotId> - the LT slot number - Field type <Eqpt::PortId> - the port number - Field type <Eqpt::PonId> - the PON identifier - Field type <Eqpt::XPonId> - the XGS PON identifier - Field type <Eqpt::M25GPonId> - the 25G PON identifier - Field type <Eqpt::ChannelPairId> - the channel pair identifier - Field type <Eqpt::ChannelGroupId> - the channel group identifier - Field type <Eqpt::SubChannelGroupId> - the subchannel group identifier - Field type <Eqpt::OntId> - the ONT identifier - Field type <Eqpt::Ng2OntId> - the NG2 ONT identifier - Field type <Eqpt::LLId> - the LLID identifier,range 1 for EPON,range 1-8 for DPOE - Possible values: - voip : virtual uni identifier - obsolete alternative replaced by vuni - vuni : virtual uni identifier - Possible values: - vuni : virtual NGPON2 uni identifier - Field type <Eqpt::OntSlotId> - the ONT SLOT identifier - Field type <Eqpt::OntPortId> - the ONT PORT identifier - Field type <Eqpt::Ng2OntSlotId> - the NGPON2 ONT SLOT identifier - Field type <Eqpt::Ng2OntPortId> - the NGPON2 ONT PORT identifier - Possible values: - stacked : stacked vlan identity - Field type <Eqpt::UnstackedVlan> - unstacked vlan id - Field type <Eqpt::SVlan> - service vlan id - Field type <Eqpt::CVlan>	

Resource Identifier	Type	Description
	- customer vlan id	
(queue)	Format: - output dsl/gpon/epon port queue number - range: [0...7,255]	queue in scope of 1 user-port Interface on a line-interface-module or ont uni, value 255 indicates the configuration is on the interface not on the queue

Table 21.50-2 "QoS Interface Upstream Queue Configuration Command" Command Parameters

Parameter	Type	Description
[no] priority	Parameter type: <Qos::QosPriority> Format: - relative priority - range: [1...8]	<i>optional parameter with default value: 1</i> relative priority
[no] weight	Parameter type: <Qos::QosWeight> Format: - relative weight - range: [0...127]	<i>optional parameter with default value: 1</i> relative weight
[no] bandwidth-profile	Parameter type: <Qos::QosBandwidthProfileName> Format: (name : <Qos::IgnoredQosProfileName> none) Possible values: - none : no profile name to associate - name : enter profile name to be associated Data driven field type Possible values are depending on the actual configuration and software. The currently allowed values can be shown with online-help.	<i>optional parameter with default value: "none"</i> the name of the bandwidth profile. For EPON OLT in downstream, this profile used for DBA on 1G PON bandwidth.
[no] ext-bw	Parameter type: <Qos::QosBandwidthProfileName> Format: (name : <Qos::IgnoredQosProfileName> none) Possible values: - none : no profile name to associate - name : enter profile name to be associated Data driven field type Possible values are depending on the actual configuration and software. The currently allowed values can be shown with online-help.	<i>optional parameter with default value: "none"</i> the name of the bandwidth profile. For EPON OLT in downstream, this profile used for DBA on 10G PON bandwidth.
[no] bandwidth-sharing	Parameter type: <Qos::BandwidthSharing> Format: (no-sharing uni-sharing ont-sharing vlan-port-sharing) Possible values: - no-sharing : disable shaper sharing - uni-sharing : enable BW or TCONT sharing on a single UNI - ont-sharing : enable BW or TCONT sharing on across UNIs of an ONT - vlan-port-sharing : enable BW or TCONT sharing on a vlan port	<i>optional parameter with default value: "no-sharing"</i> enable or disable shaper sharing
[no] queue-profile	Parameter type: <Qos::QosQueueProfName> Format: (none	<i>optional parameter with default value: "none"</i> name of the queue profile

21 QoS Configuration Commands

Parameter	Type	Description
	name : <Qos::IgnoredQosProfileName>) Possible values: - none : no profile name to associated - name : enter profile name to be associated Data driven field type Possible values are depending on the actual configuration and software. The currently allowed values can be shown with online-help.	
[no] shaper-profile	Parameter type: <Qos::QosShaperProfileName> Format: (none name : <Qos::IgnoredQosProfileName>) Possible values: - none : no profile name to associated - name : enter profile name to be associated Data driven field type Possible values are depending on the actual configuration and software. The currently allowed values can be shown with online-help.	<i>optional parameter with default value: "none"</i> name of the shaper profile

21.51 QoS Interface Remote Downstream Queue Configuration Command

Command Description

This command allows the operator to configure the downstream queues on the ONT.

The operator can configure the downstream queue priority and downstream queue weight at the ONT.

User Level

The command can be accessed by operators with qos privileges, and executed by operators with qos privileges.

Command Syntax

The command has the following syntax:

```
> configure qos interface (index) ds-rem-queue (queue) [ no priority | priority <Qos::QosPriority> ] [ no weight | weight <Qos::QosWeight> ]
```

Command Parameters

Table 21.51-1 "QoS Interface Remote Downstream Queue Configuration Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> / <Eqpt::OntPortId> pon : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> ont : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / voip <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / vuni ellid : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::LLId> epon : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> eont : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> /	physical port or la-group of a user-port Interface

Resource Identifier	Type	Description
	<pre> <Eqpt::OntPortId> : <Eqpt::UnstackedVlan> vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> / <Eqpt::OntPortId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / voip : <Eqpt::UnstackedVlan> vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / vuni : <Eqpt::UnstackedVlan> vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / voip : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / vuni : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::UnstackedVlan> vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> chpair : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::ChannelPairId> ont.ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> uni.ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / <Eqpt::Ng2OntSlotId> / <Eqpt::Ng2OntPortId> vlan.ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / <Eqpt::Ng2OntSlotId> / <Eqpt::Ng2OntPortId> : <Eqpt::UnstackedVlan> vlan.ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / <Eqpt::Ng2OntSlotId> / <Eqpt::Ng2OntPortId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> lbackpl : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> uni.ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / vuni vlan.ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / vuni : <Eqpt::UnstackedVlan> vlan.ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / vuni : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> x-pon : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::XPonId> 25g-pon : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::M25GPonId>) Possible values: - pon : pon - x-pon : xgs pon - 25g-pon : 25g pon - chpair : channel pair - ont : ont - epon : epon </pre>	

Resource Identifier	Type	Description
	- eont : eont - ellid : ellid - vlan : vlan - ont:ng2 : ngpon2 ONT style identification - uni:ng2 : ngpon2 UNI style identification - vlan:ng2 : ngpon2 vlan - ltbackpl : Backplane Port on LT - Field type <Eqpt::RackId> - the rack number - Field type <Eqpt::ShelfId> - the shelf number - Field type <Eqpt::SlotId> - the LT slot number - Field type <Eqpt::PortId> - the port number - Field type <Eqpt::PonId> - the PON identifier - Field type <Eqpt::XPonId> - the XGS PON identifier - Field type <Eqpt::M25GPonId> - the 25G PON identifier - Field type <Eqpt::ChannelPairId> - the channel pair identifier - Field type <Eqpt::ChannelGroupId> - the channel group identifier - Field type <Eqpt::SubChannelGroupId> - the subchannel group identifier - Field type <Eqpt::OntId> - the ONT identifier - Field type <Eqpt::Ng2OntId> - the NG2 ONT identifier - Field type <Eqpt::LLId> - the LLID identifier, range 1 for EPON, range 1-8 for DPOE - Possible values: - voip : virtual uni identifier - obsolete alternative replaced by vuni - vuni : virtual uni identifier - Possible values: - vuni : virtual NGPON2 uni identifier - Field type <Eqpt::OntSlotId> - the ONT SLOT identifier - Field type <Eqpt::OntPortId> - the ONT PORT identifier - Field type <Eqpt::Ng2OntSlotId> - the NGPON2 ONT SLOT identifier - Field type <Eqpt::Ng2OntPortId> - the NGPON2 ONT PORT identifier - Possible values: - stacked : stacked vlan identity - Field type <Eqpt::UnstackedVlan> - unstacked vlan id - Field type <Eqpt::SVlan> - service vlan id - Field type <Eqpt::CVlan> - customer vlan id	
(queue)	Format: - output dsl/gpon/epon port queue number	queue in scope of 1 user-port Interface on a

21 QoS Configuration Commands

Resource Identifier	Type	Description
	- range: [0...7,255]	line-interface-module or ont uni, value 255 indicates the configuration is on the interface not on the queue

Table 21.51-2 "QoS Interface Remote Downstream Queue Configuration Command" Command Parameters

Parameter	Type	Description
[no] priority	Parameter type: <Qos::QosPriority> Format: - relative priority - range: [1...8]	<i>optional parameter with default value: 1</i> relative priority
[no] weight	Parameter type: <Qos::QosWeight> Format: - relative weight - range: [0...127]	<i>optional parameter with default value: 10</i> relative weight

21.52 QoS Line Control Packets Rate Limit Configuration Command

Command Description

This command allows the operator to configure police rate and burst per protocol.

User Level

The command can be accessed by operators with qos privileges, and executed by operators with qos privileges.

Command Syntax

The command has the following syntax:

```
> configure qos ( no ctrl-pkt-policer (protocol-id) ) | ( ctrl-pkt-policer (protocol-id) [ no sustained-rate |
sustained-rate <Qos::SustainedRate> ] [ no burst-size | burst-size <Qos::DslCtrlBurstSize> ] )
```

Command Parameters

Table 21.52-1 "QoS Line Control Packets Rate Limit Configuration Command" Resource Parameters

Resource Identifier	Type	Description
(protocol-id)	Format: (arp igmp dhcpv4 dhcpv6 icmpv6 cfm pppox) Possible values: - arp : arp - igmp : igmp - dhcpv4 : dhcpv4 - dhcpv6 : dhcpv6 - icmpv6 : icmpv6 - cfm : cfm - pppox : pppox	protocol id for arp, igmp, dhcpv4, dhcpv6, icmpv6, cfm, pppox

Table 21.52-2 "QoS Line Control Packets Rate Limit Configuration Command" Command Parameters

Parameter	Type	Description
[no] sustained-rate	Parameter type: <Qos::SustainedRate> Format: - the police rate of inc user pkts in pps - range: [1...64]	<i>optional parameter with default value: 15</i> police the user incoming packets on all pvc's for the protocol of a

21 QoS Configuration Commands

Parameter	Type	Description
		dsl line.
[no] burst-size	Parameter type: <Qos::DslCtrlBurstSize> Format: - the burst size - range: [1...128]	<i>optional parameter with default value: 10</i> police the user incoming packets on all pvc's for the protocol of a dsl line.

21.53 P-bit Based Scheduling For SC Forwarder Cross Connect/Residential Bridge Configuration Command

Command Description

This command allows the operator to configure the P-bit based scheduling for the S+C VLAN forwarder model for Cross Connect / Residential Bridge.

User Level

The command can be accessed by operators with qos privileges, and executed by operators with qos privileges.

Command Syntax

The command has the following syntax:

```
> configure qos pbit-scheduling [ no sc-xcon-us | sc-xcon-us <Qos::PbitSched> ] [ no sc-xcon-dn | sc-xcon-dn <Qos::PbitSched> ] [ no sc-rb-us | sc-rb-us <Qos::PbitSched> ] [ no sc-rb-dn | sc-rb-dn <Qos::PbitSched> ]
```

Command Parameters

Table 21.53-2 "P-bit Based Scheduling For SC Forwarder Cross Connect/Residential Bridge Configuration Command" Command Parameters

Parameter	Type	Description
[no] sc-xcon-us	Parameter type: <Qos::PbitSched> Format: (svlanpbitbased cvlanpbitbased) Possible values: - svlanpbitbased : Upstream p-bits affecting QoS action applies to S-VLAN p-bits and C-VLAN p-bits. Downstream S-VLAN p-bits are copied to User-VLAN p-bits - cvlanpbitbased : Upstream p-bits affecting QoS action applies to S-VLAN p-bits. Downstream C-VLAN p-bits are copied to User-VLAN p-bits	<i>optional parameter with default value: "svlanpbitbased"</i> This objects configure the behavior of pbit scheduling in S+C Vlan Cross Connect in upstream direction
[no] sc-xcon-dn	Parameter type: <Qos::PbitSched> Format: (svlanpbitbased cvlanpbitbased) Possible values: - svlanpbitbased : Upstream p-bits affecting QoS action applies to S-VLAN p-bits and C-VLAN p-bits. Downstream S-VLAN p-bits are copied to User-VLAN p-bits - cvlanpbitbased : Upstream p-bits affecting QoS action	<i>optional parameter with default value: "svlanpbitbased"</i> This objects configure the behavior of pbit scheduling in S+C Vlan Cross Connect in downstream direction

21 QoS Configuration Commands

Parameter	Type	Description
	applies to S-VLAN p-bits. Downstream C-VLAN p-bits are copied to User-VLAN p-bits	
[no] sc-rb-us	Parameter type: <Qos::PbitSched> Format: (svlanpbitbased cvlanpbitbased) Possible values: - svlanpbitbased : Upstream p-bits affecting QoS action applies to S-VLAN p-bits and C-VLAN p-bits. Downstream S-VLAN p-bits are copied to User-VLAN p-bits - cvlanpbitbased : Upstream p-bits affecting QoS action applies to S-VLAN p-bits. Downstream C-VLAN p-bits are copied to User-VLAN p-bits	<i>optional parameter with default value: "svlanpbitbased"</i> This objects configure the behavior of pbit scheduling in S+C Vlan iBridge in upstream direction
[no] sc-rb-dn	Parameter type: <Qos::PbitSched> Format: (svlanpbitbased cvlanpbitbased) Possible values: - svlanpbitbased : Upstream p-bits affecting QoS action applies to S-VLAN p-bits and C-VLAN p-bits. Downstream S-VLAN p-bits are copied to User-VLAN p-bits - cvlanpbitbased : Upstream p-bits affecting QoS action applies to S-VLAN p-bits. Downstream C-VLAN p-bits are copied to User-VLAN p-bits	<i>optional parameter with default value: "cvlanpbitbased"</i> This objects configure the behavior of pbit scheduling in S+C Vlan iBridge in downstream direction

21.54 QoS system level Up Control Packet DSCP/Pbit marking, TC mapping Configuration Command

Command Description

This command allows the operator to configure QoS DSCP, Pbit marking, TC mapping for various protocols control packet in upstream direction.

User Level

The command can be accessed by operators with qos privileges, and executed by operators with qos privileges.

Command Syntax

The command has the following syntax:

```
> configure qos ( no up-ctrl-pkt (protocol-id) ) | ( up-ctrl-pkt (protocol-id) [ no dscp | dscp <Qos::dscpvalue> ] [ no pbit | pbit <Qos::pbitvalue> ] [ no tc | tc <Qos::tcvalue> ] )
```

Command Parameters

Table 21.54-1 "QoS system level Up Control Packet DSCP/Pbit marking, TC mapping Configuration Command" Resource Parameters

Resource Identifier	Type	Description
(protocol-id)	Format: (arp igmp dhcpv4 dhcpv6 icmpv6 cfm pppox lacp dot1x) Possible values: - arp : configure DSCP/Pbit marking, TC mapping for arp protocol ctrl packet - igmp : configure DSCP/Pbit marking, TC mapping for igmp protocol ctrl packet - dhcpv4 : configure DSCP/Pbit marking, TC mapping for dhcpv4 protocol ctrl packet - dhcpv6 : configure DSCP/Pbit marking, TC mapping for dhcpv6 protocol ctrl packet - icmpv6 : configure DSCP/Pbit marking, TC mapping for	protocol id for arp, igmp, dhcpv4, dhcpv6, icmpv6, cfm, pppox, lacp, dot1x

Resource Identifier	Type	Description
	icmpv6 protocol ctrl packet - cfm : configure DSCP/Pbit marking, TC mapping for cfm protocol ctrl packet - pppox : configure DSCP/Pbit marking, TC mapping for pppox protocol ctrl packet - lacp : configure DSCP/Pbit marking, TC mapping for lacp protocol ctrl packet - dot1x : configure DSCP/Pbit marking, TC mapping for dot1x protocol ctrl packet	

Table 21.54-2 "QoS system level Up Control Packet DSCP/Pbit marking, TC mapping Configuration Command" Command Parameters

Parameter	Type	Description
[no] dscp	Parameter type: <Qos::dscpvalue> Format: - dscp value range - range: [-1...63]	<i>optional parameter with default value: -1L</i> configure the dscp value
[no] pbit	Parameter type: <Qos::pbitvalue> Format: - pbit value range - range: [-1...7]	<i>optional parameter with default value: 7L</i> configure the P-bit value
[no] tc	Parameter type: <Qos::tcvalue> Format: - traffic class value range - range: [-1...7]	<i>optional parameter with default value: -1L</i> configure the traffic class value

21.55 QoS system level Dn Control Packet DSCP/Pbit marking, TC mapping Configuration Command

Command Description

This command allows the operator to configure QoS DSCP, Pbit marking, TC mapping for various protocols control packet in downstream direction.

User Level

The command can be accessed by operators with qos privileges, and executed by operators with qos privileges.

Command Syntax

The command has the following syntax:

```
> configure qos ( no dn-ctrl-pkt (protocol-id) ) | ( dn-ctrl-pkt (protocol-id) [ no dscp | dscp <Qos::dscpvalue> ] [ no pbit | pbit <Qos::pbitvalue> ] [ no tc | tc <Qos::tcvalue> ] )
```

Command Parameters

Table 21.55-1 "QoS system level Dn Control Packet DSCP/Pbit marking, TC mapping Configuration Command" Resource Parameters

Resource Identifier	Type	Description
(protocol-id)	Format: (arp igmp dhcpv4 dhcpv6 icmpv6 cfm pppox lacp dot1x) Possible values: - arp : configure DSCP/Pbit marking, TC mapping for arp protocol ctrl packet - igmp : configure DSCP/Pbit marking, TC mapping for igmp protocol ctrl packet - dhcpv4 : configure DSCP/Pbit marking, TC mapping for dhcpv4 protocol ctrl packet - dhcpv6 : configure DSCP/Pbit marking, TC mapping for dhcpv6 protocol ctrl packet - icmpv6 : configure DSCP/Pbit marking, TC mapping for	protocol id for arp, igmp, dhcpv4, dhcpv6, icmpv6, cfm, pppox, lacp, dot1x

Resource Identifier	Type	Description
	icmpv6 protocol ctrl packet - cfm : configure DSCP/Pbit marking, TC mapping for cfm protocol ctrl packet - pppox : configure DSCP/Pbit marking, TC mapping for pppox protocol ctrl packet - lacp : configure DSCP/Pbit marking, TC mapping for lacp protocol ctrl packet - dot1x : configure DSCP/Pbit marking, TC mapping for dot1x protocol ctrl packet	

Table 21.55-2 "QoS system level Dn Control Packet DSCP/Pbit marking, TC mapping Configuration Command" Command Parameters

Parameter	Type	Description
[no] dscp	Parameter type: <Qos::dscpvalue> Format: - dscp value range - range: [-1...63]	<i>optional parameter with default value: -1L</i> configure the dscp value
[no] pbit	Parameter type: <Qos::pbitvalue> Format: - pbit value range - range: [-1...7]	<i>optional parameter with default value: 7L</i> configure the P-bit value
[no] tc	Parameter type: <Qos::tcvalue> Format: - traffic class value range - range: [-1...7]	<i>optional parameter with default value: -1L</i> configure the traffic class value

21.56 QoS handling of upstream protocols(ARP, PPPoE, DHCPv4/v6,ND and MLD) for DSL LT's Configuration Command

Command Description

This command allows the operator to configure the QoS handling of upstream protocols(ARP, PPPoE, DHCPv4/v6,ND and MLD) for DSL LT's.

User Level

The command can be accessed by operators with qos privileges, and executed by operators with qos privileges.

Command Syntax

The command has the following syntax:

```
> configure qos upstr-prot-dsl [ [ no ] enable ]
```

Command Parameters

Table 21.56-2 "QoS handling of upstream protocols(ARP, PPPoE, DHCPv4/v6,ND and MLD) for DSL LT's Configuration Command" Command Parameters

Parameter	Type	Description
[no] enable	Parameter type: boolean	<i>optional parameter</i> Enable QoS handling of upstream protocols

22- VLAN Configuration Commands

22.1 VLAN Configuration Command Tree	22-975
22.2 VLAN General Configuration Command	22-977
22.3 Virtual MAC Configuration Command	22-978
22.4 VLAN Configuration Command	22-979
22.5 VLAN Filtering Database Configuration Command	22-990
22.6 VLAN Port Filtering Database Configuration Command	22-993
22.7 VLAN Protocol-based Configuration Command	22-996
22.8 Vlan Pbit Traffic Counter Configuration Command	22-999
22.9 Vlan Priority Regeneration Profile Configuration Command	22-1002

22.1 VLAN Configuration Command Tree

Description

This chapter gives an overview of nodes that are handled by "VLAN Configuration Commands".

Command Tree

```

----configure
----vlan
  - [no] broadcast-frames
  - priority-policy
  ----vmac-address-format
    - host-id
  ----[no] id
    - (vlanid)
    - [no] name
    - mode
    - [no] snmp-proxy
    - [no] priority
    - [no] vmac-translation
    - [no] vmac-dnstr-filter
    - [no] vmac-not-in-opt61
    - [no] new-broadcast
    - [no] protocol-filter
    - [no] pppoe-relay-tag
    X [no] dhcp-opt-82
    - [no] dhcp-opt82-ext
    - [no] dhcp-opt82-nni
    - [no] dhcp-opt82-uplink
    - [no] circuit-id-dhcp
    - [no] remote-id-dhcp
    - [no] relay-id-dhcp
    - [no] dhcp-linerate
    - [no] pppoe-linerate
    - [no] dhcpv6-linerate
    - [no] pppoe-l2-encaps
    - [no] dhcp-l2-encaps
    - [no] dhcpv6-l2-encaps
    - [no] l2-encaps1
    - [no] pppoer-vlanaware
    - [no] dhcpr-vlanaware
    - [no] dhcpv6r-vlanaware
    - [no] drly-srv-usr-side
    - [no] circuit-id-pppoe
    - [no] remote-id-pppoe
    - [no] new-secure-fwd
    - [no] aging-time
    - [no] l2cp-transparent
    - [no] dhcpv6-itf-id
    - [no] dhcpv6-remote-id
    - [no] dhcpv6-relay-id
    - [no] dhcpv6-trst-port
  
```

- [no] enterprise-number
- [no] icmpv6-sec-fltr
- [no] in-qos-prof-name
- [no] ipv4-mcast-ctrl
- [no] ipv6-mcast-ctrl
- [no] mac-mcast-ctrl
- [no] dis-proto-rip
- [no] proto-ntp
- [no] dis-ip-antispoof
- [no] unknown-unicast
- [no] pt2ptgem-flooding
- [no] mac-movement-ctrl
- [no] cvlan4095passthru
- [no] arp-snooping
- [no] arp-polling
- [no] arp-polling-ip
- [no] mac-unauth
- [no] unicast-mac
 - (unicast-mac)
 - vlan-id
 - forward-port
- [no] vlan-port
 - (port)
 - unicast-mac
- [no] port-protocol
 - (port)
 - protocol-group
 - vlan-id
 - priority
- pbit-statistics
 - [no] port
 - (vlan-port)
 - min-dot1p
 - max-dot1p
- [no] priority-regen
 - (profile-idx)
 - profile-name
 - [no] pbit0
 - [no] pbit1
 - [no] pbit2
 - [no] pbit3
 - [no] pbit4
 - [no] pbit5
 - [no] pbit6
 - [no] pbit7

22.2 VLAN General Configuration Command

Command Description

This command allows the operator to specify VLAN parameters that are globally applicable to VLANs:

- *broadcast-frames* : applies to VLANs of type residential bridge. when configured, broadcasting of frames is configurable on a per vlan basis, when the parameter is configured as "no broadcast-frames", downstream broadcast is disabled globally for all vlans.
- *priority-policy* : applies to VLANs of type residential bridge, cross-connect and QoS-aware. Indicates if the priority of upstream frames is selected from the vlan (pvid) or port-default. This configuration is only applicable for untagged user traffic.

User Level

The command can be accessed by operators with vlan privileges, and executed by operators with vlan privileges.

Command Syntax

The command has the following syntax:

```
> configure vlan [ [ no ] broadcast-frames ] priority-policy <Vlan::PriorityMap>
```

Command Parameters

Table 22.2-2 "VLAN General Configuration Command" Command Parameters

Parameter	Type	Description
[no] broadcast-frames	Parameter type: boolean	<i>optional parameter</i> broadcasting of frames is configurable per vlan
priority-policy	Parameter type: <Vlan::PriorityMap> Format: (vlan-specific port-default) Possible values: - vlan-specific : the priority of the vlan - port-default : the default priority of the port	<i>optional parameter</i> specifies how to deal with ethernet priority of the upstream frames

22.3 Virtual MAC Configuration Command

Command Description

This command allows the user to configure the format in which a virtual MAC address is defined.

User Level

The command can be accessed by operators with vlan privileges, and executed by operators with vlan privileges.

Command Syntax

The command has the following syntax:

```
> configure vlan vmac-address-format [ host-id <Vlan::vmacUniqueHostID> ]
```

Command Parameters

Table 22.3-2 "Virtual MAC Configuration Command" Command Parameters

Parameter	Type	Description
host-id	Parameter type: <Vlan::vmacUniqueHostID> Format: - A unique host Id within an EMAN connected to the same IP edges. Maximum supported value in GPON is 65535. - range: [1...524287]	<i>optional parameter</i> Value of vMac unique host ID.

22.4 VLAN Configuration Command

Command Description

This command allows the operator to specify a VLAN and its attributes.

The VLAN numbering space is the concatenation of a Service Provider VLAN, say S-VLAN-ID, and a Customer VLAN, say C-VLAN-ID. Remark that the S-VLAN-ID is assumed to be unique.

The VLAN-ID value "0" - which is not a valid VLAN-tag value - is used to indicate "not applicable". The value 4097 should not be used as a valid forwarding VLAN.

Following convention applies:

- S-VLAN is identified as (S-VLAN-ID, C-VLAN-ID=0)
- unstacked C-VLAN identified as (C-VLAN-ID>0)
- the S-VLAN is absent or not applicable
- C-VLAN-ID > 0. A constraint exists for VLAN 1: it is reserved as the VLAN-unaware bridge. This VLAN is managed as any other VLAN (i.e. it can be created, modified, removed) but it must be a residential bridged VLAN.
- stacked C-VLAN is identified as (S-VLAN-ID>1, C-VLAN-ID>1)
- RIP will be enabled automatically by default during the creation of VLAN.

The following combination is not allowed:pppoe-relay-tag=configurable, while circuit-id-pppoe and remote-id-pppoe are both disable or customer-id or physical-id.

The circuit-id-pppoe and remote-id-pppoe take effect when the pppoe-relay-tag is configurable.

The pppoe-l2-encaps take effect when the pppoe-relay-tag is true or configurable.

- relay-id-dhcp: This parameter is used to enable/disable relay-id for DHCPv4.

The circuit-id-dhcp, remote-id-dhcp, relay-id-dhcp, dhcp-linerate and dhcp-l2-encaps take effect when the dhcp-opt-82 is true or dhcp-opt82-ext or dhcp-opt82-nni or dhcp-opt82-uplink is enable or add-or-replace or add-or-forward.

- pppoe-l2-encaps: This controls insertion of access loop encapsulation sub-options part of PPPoE relay tag - Refer to (R-164 in TR101) - Datalink byte: ATM or Ethernet autogenerated according to actual encapsulation - Encaps 1 byte : configurable (see further down) - Encaps 2 byte : fixed as NA

- dhcp-l2-encaps: This controls insertion of access loop encapsulation sub-options part of DHCP option 82 - Refer to (R-164 in TR101) - Datalink byte: ATM or Ethernet autogenerated according to actual encapsulation - Encaps 1 byte : configurable (see further down) - Encaps 2 byte : fixed as NA

- dhcpv6-l2-encaps: This controls insertion of access loop encapsulation sub-options part of DHCPv6 relay tag - Refer to (R-164 in TR101) - Datalink byte: ATM or Ethernet autogenerated according to actual encapsulation - Encaps 1 byte : configurable (see further down) - Encaps 2 byte : fixed as NA

- l2-encaps1: This specifies the value of access loop encapsulation sub-options value 1 for DHCPv4, DHCPv6 and PPPoE protocol relay tags

- new-broadcast: applies to VLANs of type residential bridge.The configured value of this parameter has no meaning when broadcast-frames is not enabled at node level, meaning globally for all VLANs

- priority: The selection of the VLAN-based priority can apply provided the priority-policy at node-level is vlan-specific.

- vmac-translation: this configuration value has no effect in case MAC learning is disabled (mac-learn-off).

- Note that vmac-translation, vmac-dnstr-filter and vmac-not-in-opt61 parameters can be enabled only at S-VLAN

level in case of S+C-VLAN CC mode.

- *ipv6-mcast-ctrl*: This parameter is used in the following cases: - on the NGLT-A GPON line card, *ipv6-mcast-ctrl* parameter is used to allow or disallow upstream and downstream IPv6 multicast traffic - for all other line cards, in case no DHCPv6 protocol processing is performed on the line card (i.e. *new-secure-fwd*, *dhcpv6-itf-id*, *dhcpv6-remote-id* and *dhcpv6-relay-id* are all disabled), the *ipv6-mcast-ctrl* parameter is used to control upstream and downstream DHCPv6 multicast traffic

- *drly-srv-usr-side*: This parameter is to enable/disable DHCP(v4/v6) server transparency at the user side when DHCP(v4/v6) relay is enabled. This parameter can be enabled only when Secure forwarding and vMaC translation are both disabled. This parameter is supported only on CC forwarder.

- *dhcpv6-relay-id*: This parameter is used to enable/disable relay-id for DHCPv6

- *pppoer-vlanaware*: This parameter is to configure the number of VLAN tags on the user side upto which PPPoE protocol awareness should be enabled. This configuration is applicable only for S+C CC forwarder.

- *dhcpr-vlanaware*: This parameter is to configure the number of VLAN tags on the user side upto which DHCPv4 protocol awareness should be enabled. This configuration is applicable only for S+C CC forwarder.

- *dhcpv6r-vlanaware*: This parameter is to configure the number of VLAN tags on the user side upto which DHCPv6 protocol awareness should be enabled. This configuration is applicable only for S+C CC forwarder.

User Level

The command can be accessed by operators with *vlan* privileges, and executed by operators with *vlan* privileges.

Command Syntax

The command has the following syntax:

```
> configure vlan ( no id (vlanid) ) | ( id (vlanid) [ no name | name <Vlan::AdminString> ] mode
<Vlan::SystemMode> [ [ no ] sntp-proxy ] [ no priority | priority <Vlan::Priority> ] [ [ no ] vmac-translation ] [ [ no ]
vmac-dnstr-filter ] [ [ no ] vmac-not-in-opt61 ] [ no new-broadcast | new-broadcast
<Vlan::NewStaticBrdcastControl> ] [ no protocol-filter | protocol-filter <Vlan::ProtGroup> ] [ no pppoe-relay-tag |
pppoe-relay-tag <Vlan::PppoeRelayEnableR3.1> ] [ [ no ] dhcp-opt-82 ] [ no dhcp-opt82-ext | dhcp-opt82-ext
<Vlan::DhcpOption82Ext> ] [ no dhcp-opt82-nni | dhcp-opt82-nni <Vlan::Option82Nni> ] [ no dhcp-opt82-uplink |
dhcp-opt82-uplink <Vlan::Option82Uplink> ] [ no circuit-id-dhcp | circuit-id-dhcp <Vlan::CircuitIdDhcp> ] [ no
remote-id-dhcp | remote-id-dhcp <Vlan::RemoteIdDhcp> ] [ no relay-id-dhcp | relay-id-dhcp <Vlan::RelayIdDhcp>
] [ no dhcp-linerate | dhcp-linerate <Vlan::Dhcp-linerate> ] [ no pppoe-linerate | pppoe-linerate
<Vlan::Pppoe-linerate> ] [ no dhcpv6-linerate | dhcpv6-linerate <Vlan::Dhcpv6-linerate> ] [ no pppoe-l2-encaps |
pppoe-l2-encaps <Vlan::PppoeAccessEncap> ] [ no dhcp-l2-encaps | dhcp-l2-encaps <Vlan::DhcpAccessEncap> ]
[ no dhcpv6-l2-encaps | dhcpv6-l2-encaps <Vlan::Dhcpv6AccessEncap> ] [ no l2-encaps1 | l2-encaps1
<Vlan::AccessLoopEncaps1> ] [ no pppoer-vlanaware | pppoer-vlanaware <Vlan::PppoeRelayVlanAware> ] [ no
dhcpr-vlanaware | dhcpr-vlanaware <Vlan::DhcpRelayVlanAware> ] [ no dhcpv6r-vlanaware | dhcpv6r-vlanaware
<Vlan::Dhcpv6RelayVlanAware> ] [ no drly-srv-usr-side | drly-srv-usr-side <Vlan::DRlySrvAtUsrSide> ] [ no
circuit-id-pppoe | circuit-id-pppoe <Vlan::CircuitIdPppoe> ] [ no remote-id-pppoe | remote-id-pppoe
<Vlan::RemoteIdPppoe> ] [ no new-secure-fwd | new-secure-fwd <Vlan::NewSecureForward> ] [ no aging-time |
aging-time <Vlan::MacAgingTime> ] [ [ no ] l2cp-transparent ] [ no dhcpv6-itf-id | dhcpv6-itf-id
<Vlan::Dhcpv6InterfaceId> ] [ no dhcpv6-remote-id | dhcpv6-remote-id <Vlan::Dhcpv6RemoteId> ] [ no
dhcpv6-relay-id | dhcpv6-relay-id <Vlan::Dhcpv6RelayId> ] [ no dhcpv6-trst-port | dhcpv6-trst-port
<Vlan::Dhcpv6TrstPort> ] [ no enterprise-number | enterprise-number <Vlan::Enterprisenumber> ] [ [ no ]
icmpv6-sec-fltr ] [ no in-qos-prof-name | in-qos-prof-name <Qos::QosIngressProfileName> ] [ [ no ]
ipv4-mcast-ctrl ] [ [ no ] ipv6-mcast-ctrl ] [ [ no ] mac-mcast-ctrl ] [ [ no ] dis-proto-rip ] [ [ no ] proto-ntp ] [ [ no ]
dis-ip-antispoof ] [ [ no ] unknown-unicast ] [ [ no ] pt2ptgem-flooding ] [ [ no ] mac-movement-ctrl ] [ no
cvlan4095passthru | cvlan4095passthru <Vlan::cvlan4095Passthru> ] [ [ no ] arp-snooping ] [ [ no ] arp-polling ] [
no arp-polling-ip | arp-polling-ip <Ip::V4Address> ] [ [ no ] mac-unauth ] )
```

Command Parameters

Table 22.4-1 "VLAN Configuration Command" Resource Parameters

Resource Identifier	Type	Description
(vlanid)	Format: (<Network::UVlanIndex> stacked : <Network::SVlanIndex> : <Network::CVlanIndex>) Possible values: - stacked : stacked vlan identity Field type <Network::UVlanIndex> - unstacked vlan identity - range: [1...4093] Field type <Network::SVlanIndex> - service vlan identity - range: [2...4093] Field type <Network::CVlanIndex> - customer vlan identity - range: [0...4093]	VLAN id

Table 22.4-2 "VLAN Configuration Command" Command Parameters

Parameter	Type	Description
[no] name	Parameter type: <Vlan::AdminString> Format: - char string - length: x<=80	<i>optional parameter with default value: ""</i> VLAN name
mode	Parameter type: <Vlan::SystemMode> Format: (cross-connect residential-bridge qos-aware layer2-terminated mirror) Possible values: - cross-connect : crossconnect vlan - residential-bridge : residential bridge vlan - qos-aware : qos aware vlan - layer2-terminated : layer2 terminated vlan - mirror : mirror vlan	<i>mandatory parameter</i> VLAN mode
[no] sntp-proxy	Parameter type: boolean	<i>optional parameter</i> enable SNTP proxy
[no] priority	Parameter type: <Vlan::Priority> Format: - priority of ethernet frames - range: [0...7]	<i>optional parameter with default value: 0</i> default frame priority
[no] vmac-translation	Parameter type: boolean	<i>optional parameter</i> <i>The parameter is not visible during creation.</i> enable virtual Mac address translation
[no] vmac-dnstr-filter	Parameter type: boolean	<i>optional parameter</i> <i>The parameter is not visible during creation.</i> enable virtual Mac source address downstream blocking
[no] vmac-not-in-opt61	Parameter type: boolean	<i>optional parameter</i>

22 VLAN Configuration Commands

Parameter	Type	Description
		skip vmac translation in dhcp option 61 even when vmac is enabled
[no] new-broadcast	Parameter type: <Vlan::NewStaticBrdcstControl> Format: (inherit enable disable) Possible values: - inherit : for S+C VLAN: inherit from S VLAN level if existing; for S or C VLAN: inherit from default fixed system value (which is disable) - enable : new switch broadcast frames - disable : new disable broadcast frames	<i>optional parameter with default value: "inherit"</i> switch downstream broadcast frames (On GPON and L2+ LT boards, broadcast control for S+C L2 Forwarders can only be controlled at S-VLAN level, not individually at S+C-VLAN level.)
[no] protocol-filter	Parameter type: <Vlan::ProtGroup> Format: (pass-all pass-pppoe pass-ipoe pass-pppoe-ipoe pass-ipv6oe pass-pppoe-ipv6oe pass-ipoe-ipv6oe pass-pppoe-ipoe-ipv6oe) Possible values: - pass-all : pass all traffic - pass-pppoe : pass traffic of PPPoE protocol group - pass-ipoe : pass traffic of IPv4oE protocol group - pass-pppoe-ipoe : pass PPPoE and IPv4oE protocol groups - pass-ipv6oe : pass traffic of IPv6oE protocol group - pass-pppoe-ipv6oe : pass PPPoE and IPv6oE protocol groups - pass-ipoe-ipv6oe : pass IPv4oE and IPv6oE protocol groups - pass-pppoe-ipoe-ipv6oe: pass PPPoE, IPv4oE and IPv6oE protocol groups	<i>optional parameter with default value: "pass-all"</i> control protocol group filters
[no] pppoe-relay-tag	Parameter type: <Vlan::PppoeRelayEnableR3.1> Format: (true false configurable) Possible values: - true : pppoe tag with the current fixed format - false : no pppoe tag - configurable : circuit-id-pppoe and remote-id-pppoe controlling format	<i>optional parameter with default value: "false"</i> configure the format of the PPPoE relay tag
[no] dhcp-opt-82	Parameter type: boolean	<i>obsolete parameter replaced by parameter "dhcp-opt82-ext"</i> The parameter is not visible during creation. enable dhcp option 82 (relay)
[no] dhcp-opt82-ext	Parameter type: <Vlan::DhcpOption82Ext> Format: (enable disable transparent add-or-replace	<i>optional parameter with default value: "disable"</i> The parameter is not visible during creation. control of DHCP option 82

Parameter	Type	Description
	add-or-forward) Possible values: - enable : enable dhcp option 82 (relay) - disable : disable dhcp option 82 (relay) - transparent : pass dhcp option 82 transparently if sent by client (relay) - add-or-replace : add dhcp option 82 if not present or replace the dhcp option 82 if present (relay) - add-or-forward : add dhcp option 82 if not present or forward the dhcp option 82 transparently if sent by client (relay)	
[no] dhcp-opt82-nni	Parameter type: <Vlan::Option82Nni> Format: (enable disable transparent add-or-replace add-or-forward) Possible values: - enable : enable dhcp option 82 on NNI Interface(relay) - disable : disable dhcp option 82 on NNI Interface(relay) - transparent : pass dhcp option 82 transparently if sent by client on NNI Interface(relay) - add-or-replace : add dhcp option 82 if not present or replace the dhcp option 82 if present on NNI Interface(relay) - add-or-forward : add dhcp option 82 if not present or forward the dhcp option 82 transparently if sent by client on NNI Interface(relay)	<i>optional parameter with default value: "disable"</i> <i>The parameter is not visible during creation.</i> control of DHCP option 82 on NNI Interface
[no] dhcp-opt82-uplink	Parameter type: <Vlan::Option82Uplink> Format: (enable disable transparent add-or-replace add-or-forward) Possible values: - enable : enable dhcp option 82 on UPLINK Interface(relay) - disable : disable dhcp option 82 on UPLINK Interface(relay) - transparent : pass dhcp option 82 transparently if sent by client on UPLINK Interface(relay) - add-or-replace : add dhcp option 82 if not present or replace the dhcp option 82 if present on UPLINK Interface(relay) - add-or-forward : add dhcp option 82 if not present or forward the dhcp option 82 transparently if sent by client on UPLINK Interface(relay)	<i>optional parameter with default value: "disable"</i> <i>The parameter is not visible during creation.</i> control of DHCP option 82 on UPLINK Interface
[no] circuit-id-dhcp	Parameter type: <Vlan::CircuitIdDhcp> Format: (customer-id physical-id ccsa-format disable) Possible values: - customer-id : customer identity as circuit id - physical-id : physical line identity as circuit id	<i>optional parameter with default value: "disable"</i> <i>The parameter is not visible during creation.</i> configure the circuit id sub-option for DHCP option-82

22 VLAN Configuration Commands

Parameter	Type	Description
	- ccsa-format : circuit id in ccsa format - disable : no circuit id	
[no] remote-id-dhcp	Parameter type: <Vlan::RemoteIdDhcp> Format: (customer-id disable physical-id) Possible values: - customer-id : customer identity as remote id - disable : no remote id - physical-id : physical line identity as remote id	<i>optional parameter with default value: "disable"</i> <i>The parameter is not visible during creation.</i> configure the remote id sub-option for DHCP option-82
[no] relay-id-dhcp	Parameter type: <Vlan::RelayIdDhcp> Format: (relay-id disable) Possible values: - relay-id : System MAC + Physical Id as relay id - disable : no relay id	<i>optional parameter with default value: "disable"</i> <i>The parameter is not visible during creation.</i> configure the relay id sub-option for DHCP option-82
[no] dhcp-linerate	Parameter type: <Vlan::Dhcp-linerate> Format: (notadd addactuallinerate addalllineparameters) Possible values: - notadd : not add DSL linerate for DHCP - addactuallinerate : add DSL actual line up and down rate for DHCP - addalllineparameters : add all DSL line parameters for DHCP	<i>optional parameter with default value: "notadd"</i> <i>The parameter is not visible during creation.</i> configure insertion of the linerate for DHCP protocol
[no] pppoe-linerate	Parameter type: <Vlan::Pppoe-linerate> Format: (notadd addactuallinerate addalllineparameters) Possible values: - notadd : not add DSL linerate for PPPoE - addactuallinerate : add DSL actual line up and down rate for PPPoE - addalllineparameters : add all DSL line parameters for PPPoE	<i>optional parameter with default value: "notadd"</i> <i>The parameter is not visible during creation.</i> configure insertion of the linerate for PPPoE protocol (Only applicable on DSL LT boards, not on GPON LT boards. In case both GPON ports and DSL ports are configured in one VLAN, the pppoe-linerate parameter will only be applied on DSL LT boards.)
[no] dhcpv6-linerate	Parameter type: <Vlan::Dhcpv6-linerate> Format: (notadd addactuallinerate addalllineparameters) Possible values: - notadd : not add DSL linerate for DHCPv6 - addactuallinerate : add DSL actual line up and down rate for DHCPv6 - addalllineparameters : add all DSL line parameters for DHCPv6	<i>optional parameter with default value: "notadd"</i> <i>The parameter is not visible during creation.</i> configure insertion of the linerate for DHCPv6 protocol
[no] pppoe-l2-encaps	Parameter type: <Vlan::PppoeAccessEncap> Format: (notadd add)	<i>optional parameter with default value: "notadd"</i> <i>The parameter is not visible during creation.</i>

Parameter	Type	Description
	Possible values: - notadd : not add access loop encapsulation for PPPoE - add : add access loop encapsulation for PPPoE	configure insertion of access loop encapsulation sub-option for PPPoE relay tag (Only applicable on DSL and ETH LT boards, not on GPON LT boards. In case both GPON ports and DSL/ETH ports are configured in one VLAN, the pppoe-l2-encaps parameter will only be applied on DSL and ETH LT boards.)
[no] dhcp-l2-encaps	Parameter type: <Vlan::DhcpAccessEncap> Format: (notadd add) Possible values: - notadd : not add access loop encapsulation for DHCP - add : add access loop encapsulation for DHCP	<i>optional parameter with default value: "notadd"</i> <i>The parameter is not visible during creation.</i> configure insertion of access loop encapsulation sub-option for DHCP option 82 (Only applicable on DSL and ETH LT boards, not on GPON LT boards. In case both GPON ports and DSL/ETH ports are configured in one VLAN, the dhcp-l2-encaps parameter will only be applied on DSL and ETH LT boards.)
[no] dhcpv6-l2-encaps	Parameter type: <Vlan::Dhcpv6AccessEncap> Format: (notadd add) Possible values: - notadd : not add access loop encapsulation for DHCPv6 - add : add access loop encapsulation for DHCPv6	<i>optional parameter with default value: "notadd"</i> <i>The parameter is not visible during creation.</i> configure insertion of access loop encapsulation sub-option for DHCPv6 (Only applicable on DSL and ETH LT boards, not on GPON LT boards. In case both GPON ports and DSL/ETH ports are configured in one VLAN, the dhcpv6-l2-encaps parameter will only be applied on DSL and ETH LT boards.)
[no] l2-encaps1	Parameter type: <Vlan::AccessLoopEncaps1> Format: (not-applicable untagged single-tagged dual-tagged) Possible values: - not-applicable : not applicable - untagged : set untag as encapsulation1 value - single-tagged : set single-tag as encapsulation1 value - dual-tagged : set dual-tag as encapsulation1 value	<i>optional parameter with default value: "not-applicable"</i> <i>The parameter is not visible during creation.</i> configure the encapsulation 1 value of the access loop encapsulation sub-option for DHCP option 82, DHCPv6 relay tag and PPPoE relay tag
[no] pppoer-vlanaware	Parameter type: <Vlan::PppoeRelayVlanAware> Format: (upto-1-uservlan upto-2-uservlans upto-untag-uservlan system-default) Possible values: - upto-1-uservlan : user VLAN awareness for untagged and	<i>optional parameter with default value: "system-default"</i> <i>The parameter is not visible during creation.</i> configure the number of user VLANs that the PPPoE relay functionality should be aware of

22 VLAN Configuration Commands

Parameter	Type	Description
	single-tagged packets - upto-2-uservlans : user VLAN awareness for untagged, single-tagged and dual-tagged packets - upto-untag-uservlan : user VLAN awareness for only untagged packets - system-default : default user VLAN awareness depends on the forwarder type and board type	
[no] dhcpr-vlanaware	Parameter type: <Vlan::DhcpRelayVlanAware> Format: (upto-1-uservlan upto-2-uservlans upto-untag-uservlan system-default) Possible values: - upto-1-uservlan : user VLAN awareness for untagged and single-tagged packets - upto-2-uservlans : user VLAN awareness for untagged, single-tagged and dual-tagged packets - upto-untag-uservlan : user VLAN awareness for only untagged packets - system-default : default user VLAN awareness depends on the forwarder type and board type	<i>optional parameter with default value: "system-default"</i> <i>The parameter is not visible during creation.</i> configure the number of user VLANs that the DHCP relay functionality should be aware of
[no] dhcpv6r-vlanaware	Parameter type: <Vlan::Dhcpv6RelayVlanAware> Format: (upto-1-uservlan upto-2-uservlans upto-untag-uservlan system-default) Possible values: - upto-1-uservlan : user VLAN awareness for untagged and single-tagged packets - upto-2-uservlans : user VLAN awareness for untagged, single-tagged and dual-tagged packets - upto-untag-uservlan : user VLAN awareness for only untagged packets - system-default : default user VLAN awareness depends on the forwarder type and board type	<i>optional parameter with default value: "system-default"</i> <i>The parameter is not visible during creation.</i> configure the number of user VLANs that the DHCPv6 relay functionality should be aware of
[no] drly-srv-usr-side	Parameter type: <Vlan::DRlySrvAtUsrSide> Format: (enable disable) Possible values: - enable : enable DHCP(v4/v6) server transparency at the user side when DHCP(v4/v6) relay is enabled. - disable : disable DHCP(v4/v6) server transparency at the user side when DHCP(v4/v6) relay is enabled.	<i>optional parameter with default value: "disable"</i> enable DHCP(v4/v6) server transparency at the user side when DHCP(v4/v6) relay is enabled. Only applicable for CC forwarder
[no] circuit-id-pppoe	Parameter type: <Vlan::CircuitIdPppoe> Format: (disable customer-id physical-id ccsa-format) Possible values: - disable : no circuit id - customer-id : customer identity as circuit id - physical-id : physical line identity as circuit id - ccsa-format : circuit id in ccsa format	<i>optional parameter with default value: "disable"</i> <i>The parameter is not visible during creation.</i> configure the circuit id sub-option for PPPoE relay tag

Parameter	Type	Description
[no] remote-id-pppoe	Parameter type: <Vlan::RemoteIdPppoe> Format: (disable customer-id physical-id) Possible values: - disable : no remote id - customer-id : customer identity as remote id - physical-id : physical line identity as remote id	<i>optional parameter with default value: "disable"</i> <i>The parameter is not visible during creation.</i> configure the remote id sub-option for PPPoE relay tag
[no] new-secure-fw	Parameter type: <Vlan::NewSecureForward> Format: (inherit disable enable) Possible values: - inherit : inherit new-secure-forwarding - disable : disable new-secure-forwarding - enable : enable new-secure-forwarding	<i>optional parameter with default value: "inherit"</i> enable secure forwarding for the VLAN (On GPON and L2+ LT boards, secure forwarding for S+C L2 Forwarders can only be controlled at S-VLAN level, not individually at S+C-VLAN level.)
[no] aging-time	Parameter type: <Vlan::MacAgingTime> Format: - mac aging time in seconds - unit: sec - range: [-1,10...1000000]	<i>optional parameter with default value: -1</i> configure MAC aging time in seconds; in case of default, the system-level value is applicable.
[no] l2cp-transparent	Parameter type: boolean	<i>optional parameter</i> enable l2cp-transparent
[no] dhcpv6-itf-id	Parameter type: <Vlan::Dhcpv6InterfaceId> Format: (disable customer-id physical-id ccsa-format) Possible values: - disable : no interface id - customer-id : customer identity as interface id - physical-id : physical line identity as interface id - ccsa-format : interface id in ccsa format	<i>optional parameter with default value: "disable"</i> <i>The parameter is not visible during creation.</i> DHCPv6 interface id control
[no] dhcpv6-remote-id	Parameter type: <Vlan::Dhcpv6RemoteId> Format: (disable customer-id physical-id) Possible values: - disable : no interface id - customer-id : customer identity as interface id - physical-id : physical line identity as interface id	<i>optional parameter with default value: "disable"</i> <i>The parameter is not visible during creation.</i> DHCPv6 remote id control
[no] dhcpv6-relay-id	Parameter type: <Vlan::Dhcpv6RelayId> Format: (disable duid-ll) Possible values: - disable : no dhcpv6 relay-id - duid-ll : two octet network hardware type code, followed by the link-layer address	<i>optional parameter with default value: "disable"</i> <i>The parameter is not visible during creation.</i> DHCPv6 relay id control
[no] dhcpv6-trst-port	Parameter type: <Vlan::Dhcpv6TrstPort> Format: (trusted untrusted)	<i>optional parameter with default value: "untrusted"</i> <i>The parameter is not visible during creation.</i>

22 VLAN Configuration Commands

Parameter	Type	Description
	Possible values: - trusted : trusted port - untrusted : untrusted port	DHCPv6 trusted port control
[no] enterprise-number	Parameter type: <Vlan::Enterprisenumber> Format: - enterprise number - range: [1...4294967295]	<i>optional parameter with default value: "3561"</i> <i>The parameter is not visible during creation.</i> configure enterprise number for DHCPv6 protocol
[no] icmpv6-sec-fltr	Parameter type: boolean	<i>optional parameter</i> <i>The parameter is not visible during creation.</i> enable icmpv6 secure filter
[no] in-qos-prof-name	Parameter type: <Qos::QosIngressProfileName> Format: (default name : <Qos::IgnoredQosProfileName>) Possible values: - default : default profile name - name : enter profile name to be associated Data driven field type Possible values are depending on the actual configuration and software. The currently allowed values can be shown with online-help.	<i>optional parameter with default value: "default"</i> QoS ingress profile name
[no] ipv4-mcast-ctrl	Parameter type: boolean	<i>optional parameter</i> enable ipv4 multicast control: forward ipv4 multicast frames in this vlan
[no] ipv6-mcast-ctrl	Parameter type: boolean	<i>optional parameter</i> enable ipv6 multicast control: forward ipv6 multicast frames in this vlan
[no] mac-mcast-ctrl	Parameter type: boolean	<i>optional parameter</i> enable mac multicast control: forward mac multicast frames in this vlan
[no] dis-proto-rip	Parameter type: boolean	<i>optional parameter</i> disable RIP-IPv4 protocol
[no] proto-ntp	Parameter type: boolean	<i>optional parameter</i> enable ntp protocol
[no] dis-ip-antispoof	Parameter type: boolean	<i>optional parameter</i> disable IP anti-spoofing
[no] unknown-unicast	Parameter type: boolean	<i>optional parameter</i> enable unknown unicast flooding
[no] pt2ptgem-flooding	Parameter type: boolean	<i>optional parameter</i> enable flooding on unicast GEM port
[no] mac-movement-ctrl	Parameter type: boolean	<i>optional parameter</i> enable mac movement in this vlan
[no] cvlan4095passthru	Parameter type: <Vlan::cvlan4095Passthru> Format: (passthru not-applicable) Possible values: - passthru : Allow passthru of cvlan 4095 - applicable only for SVLANCC	<i>optional parameter with default value: "not-applicable"</i> enable C-VLAN 4095 tunneling behavior. Only applicable for S-VLAN CC forwarder

Parameter	Type	Description
	- not-applicable : Legacy behavior	
[no] arp-snooping	Parameter type: boolean	<i>optional parameter</i> enable arp snooping
[no] arp-polling	Parameter type: boolean	<i>optional parameter</i> enable arp polling
[no] arp-polling-ip	Parameter type: <Ip::V4Address> Format: - IPv4-address	<i>optional parameter with default value: "0.0.0.0"</i> configure ARP polling ip address
[no] mac-unauth	Parameter type: boolean	<i>optional parameter</i> enable mac unauthorized default: forward the frame to this vlan if authorization failed

22.5 VLAN Filtering Database Configuration Command

Command Description

This command allows the operator to specify entries in the Layer 2 filtering database for a specific VLAN and unicast MAC address.

This information is used by the bridge in determining how to propagate a received frame.

Use of this command is disencouraged because it will be obsoleted and replaced in the future by the VLAN Port Filtering Database Configuration command.

User Level

The command can be accessed by operators with vlan privileges, and executed by operators with vlan privileges.

Command Syntax

The command has the following syntax:

```
> configure vlan ( no unicast-mac (unicast-mac) vlan-id <Network::StackedVlan> ) | ( unicast-mac (unicast-mac)
vlan-id <Network::StackedVlan> forward-port <Itf::UserPortItf> )
```

Command Parameters

Table 22.5-1 "VLAN Filtering Database Configuration Command" Resource Parameters

Resource Identifier	Type	Description
(unicast-mac)	Format: - mac address (aa:bb:cc:a1:02:03) - unit: Byte - length: 6	unicast mac address
vlan-id	Parameter type: <Network::StackedVlan> Format: (<Network::UVlanIndex> stacked : <Network::SVlanIndex> : <Network::CVlanIndex>) Possible values: - stacked : stacked vlan identity Field type <Network::UVlanIndex> - unstacked vlan identity - range: [1...4093] Field type <Network::SVlanIndex> - service vlan identity - range: [2...4093] Field type <Network::CVlanIndex> - customer vlan identity - range: [0...4093]	network vlan id

Table 22.5-2 "VLAN Filtering Database Configuration Command" Command Parameters

Parameter	Type	Description
forward-port	Parameter type: <Itf::UserPortItf> Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::VpiId> : <Eqpt::VciId> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> / <Eqpt::OntPortId> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / voip <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / vuni <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::LLId> ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / <Eqpt::Ng2OntSlotId> / <Eqpt::Ng2OntPortId> ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / vuni) Possible values: - ng2 : ngpon2 style identification Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number Field type <Eqpt::VpiId> - atm VPI Field type <Eqpt::VciId> - atm VCI Field type <Eqpt::ChannelGroupId> - the channel group identifier Field type <Eqpt::SubChannelGroupId> - the subchannel group identifier Field type <Eqpt::PonId> - the PON identifier Field type <Eqpt::OntId> - the ONT identifier Field type <Eqpt::Ng2OntId> - the NG2 ONT identifier Possible values: - voip : virtual uni identifier obsolete alternative replaced by vuni - vuni : virtual uni identifier Possible values: - vuni : virtual NGPON2 uni identifier Field type <Eqpt::OntSlotId> - the ONT SLOT identifier Field type <Eqpt::OntPortId> - the ONT PORT identifier Field type <Eqpt::Ng2OntSlotId>	<i>mandatory parameter</i> forward bridge port

22 VLAN Configuration Commands

Parameter	Type	Description
	- the NGPON2 ONT SLOT identifier Field type <Eqpt::Ng2OntPortId> - the NGPON2 ONT PORT identifier Field type <Eqpt::LLId> - the LLID identifier,range 1 for EPON,range 1-8 for DPOE	

22.6 VLAN Port Filtering Database Configuration Command

Command Description

This command allows the operator to specify entries in the Layer 2 filtering database for a specific VLAN Port and unicast MAC address.

This information is used by the bridge in determining how to propagate a received frame.

This command will in time obsolete and replace the VLAN Filtering Database Configuration command. Already now, it must be used in case multiple vlan ports are configured on the same bridge port and attached to the same I-Bridge.

User Level

The command can be accessed by operators with vlan privileges, and executed by operators with vlan privileges.

Command Syntax

The command has the following syntax:

```
> configure vlan ( no vlan-port (port) unicast-mac <Vlan::MacAddr> ) | ( vlan-port (port) unicast-mac <Vlan::MacAddr> )
```

Command Parameters

Table 22.6-1 "VLAN Port Filtering Database Configuration Command" Resource Parameters

Resource Identifier	Type	Description
(port)	Format: (vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::VpiId> : <Eqpt::VciId> : <Eqpt::UnstackedVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::UnstackedVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::VpiId> : <Eqpt::VciId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> / <Eqpt::OntPortId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> / <Eqpt::OntPortId> :	vlan port

Resource Identifier	Type	Description
	<pre> <Eqpt::UnstackedVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / voip : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / vuni : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / voip : <Eqpt::UnstackedVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / vuni : <Eqpt::UnstackedVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::LLId> : <Eqpt::UnstackedVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::LLId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan-port:ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Ng2::OntId> / <Eqpt::Ng2OntSlotId> / <Eqpt::Ng2OntPortId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan-port:ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Ng2::OntId> / <Eqpt::Ng2OntSlotId> / <Eqpt::Ng2OntPortId> : <Eqpt::UnstackedVlan> vlan-port:ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Ng2::OntId> / vuni : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan-port:ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Ng2::OntId> / vuni : <Eqpt::UnstackedVlan>) Possible values: - vlan-port : vlan port - vlan-port:ng2 : ngpon2 vlan port Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number Field type <Eqpt::VpiId> - atm VPI Field type <Eqpt::VciId> - atm VCI Field type <Eqpt::PonId> - the PON identifier Field type <Eqpt::OntId> - the ONT identifier Field type <Eqpt::ChannelGroupId> - the channel group identifier Field type <Eqpt::SubChannelGroupId> - the subchannel group identifier Field type <Ng2::OntId> </pre>	

Resource Identifier	Type	Description
	- the ONT identifier Possible values: - voip : virtual uni identifier obsolete alternative replaced by vuni - vuni : virtual uni identifier Possible values: - vuni : virtual NGPON2 uni identifier Field type <Eqpt::OntSlotId> - the ONT SLOT identifier Field type <Eqpt::OntPortId> - the ONT PORT identifier Field type <Eqpt::Ng2OntSlotId> - the NGPON2 ONT SLOT identifier Field type <Eqpt::Ng2OntPortId> - the NGPON2 ONT PORT identifier Field type <Eqpt::LLId> - the LLID identifier, range 1 for EPON, range 1-8 for DPOE Possible values: - stacked : stacked vlan identity Field type <Eqpt::UnstackedVlan> - unstacked vlan id Field type <Eqpt::SVlan> - service vlan id Field type <Eqpt::CVlan> - customer vlan id	
unicast-mac	Parameter type: <Vlan::MacAddr> Format: - mac address (aa:bb:cc:a1:02:03) - unit: Byte - length: 6	unicast mac address

22.7 VLAN Protocol-based Configuration Command

Command Description

For protocol-based VLANs, this command allows the operator to specify how incoming traffic on a port is allocated to a particular VLAN and priority.

For Ethernet frames, the mapping to either the PPPoE or IPoE protocol is:

- protocol value 0x8863: PPPoE
- protocol value 0x8864: PPPoE
- protocol value 0x0800: IPoE
- protocol value 0x0806: IPoE
- protocol value 0x8035: IPoE

For RFC_1042 frames the mapping to either PPPoE or IPoE protocol is:

- protocol value 0x8863: PPPoE
- protocol value 0x8864: PPPoE
- protocol value 0x0800: IPoE
- protocol value 0x0806: IPoE
- protocol value 0x8035: IPoE

priority: The selection of the priority for upstream frames, in case of a protocol based vlan, is not dependent on the configuration of the priority-policy configured at node level.

User Level

The command can be accessed by operators with vlan privileges, and executed by operators with vlan privileges.

Command Syntax

The command has the following syntax:

```
> configure vlan ( no port-protocol (port) protocol-group <Vlan::GroupId> ) | ( port-protocol (port) protocol-group <Vlan::GroupId> vlan-id <Vlan::StackedVlan> priority <Vlan::Priority> )
```

Command Parameters

Table 22.7-1 "VLAN Protocol-based Configuration Command" Resource Parameters

Resource Identifier	Type	Description
(port)	Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::VpiId> : <Eqpt::VciId> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> /	identity of a port(e.g. uplink port, atm pvc, efm port, eth port, la group ...)

Resource Identifier	Type	Description
	<code><Eqpt::OntPortId></code> <code> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> /</code> <code><Eqpt::PonId> / <Eqpt::OntId> / voip</code> <code> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> /</code> <code><Eqpt::PonId> / <Eqpt::OntId> / vuni</code> <code> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> /</code> <code><Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::LLId></code> <code> ng2 : <Eqpt::ChannelGroupId> /</code> <code><Eqpt::SubChannelGroupId> / <Ng2::OntId> /</code> <code><Eqpt::Ng2OntSlotId> / <Eqpt::Ng2OntPortId></code> <code> ng2 : <Eqpt::ChannelGroupId> /</code> <code><Eqpt::SubChannelGroupId> / <Ng2::OntId> / vuni)</code> Possible values: - ng2 : ngpon2 style identification Field type <code><Eqpt::RackId></code> - the rack number Field type <code><Eqpt::ShelfId></code> - the shelf number Field type <code><Eqpt::SlotId></code> - the LT slot number Field type <code><Eqpt::PortId></code> - the port number Field type <code><Eqpt::VpiId></code> - atm VPI Field type <code><Eqpt::VcId></code> - atm VCI Field type <code><Eqpt::PonId></code> - the PON identifier Field type <code><Eqpt::ChannelGroupId></code> - the channel group identifier Field type <code><Eqpt::SubChannelGroupId></code> - the subchannel group identifier Field type <code><Eqpt::OntId></code> - the ONT identifier Field type <code><Ng2::OntId></code> - the ONT identifier Possible values: - voip : virtual uni identifier obsolete alternative replaced by vuni - vuni : virtual uni identifier Possible values: - vuni : virtual NGPON2 uni identifier Field type <code><Eqpt::OntSlotId></code> - the ONT SLOT identifier Field type <code><Eqpt::OntPortId></code> - the ONT PORT identifier Field type <code><Eqpt::Ng2OntSlotId></code> - the NGPON2 ONT SLOT identifier Field type <code><Eqpt::Ng2OntPortId></code> - the NGPON2 ONT PORT identifier Field type <code><Eqpt::LLId></code> - the LLID identifier, range 1 for EPON, range 1-8 for DPOE	
protocol-group	Parameter type: <code><Vlan::GroupId></code> Format: (pppoe ipoe ipv6oe)	protocol group

Resource Identifier	Type	Description
	Possible values: - pppoe : PPPoE - ipoe : IPv4oE - ipv6oe : IPv6oE	

Table 22.7-2 "VLAN Protocol-based Configuration Command" Command Parameters

Parameter	Type	Description
vlan-id	Parameter type: <Vlan::StackedVlan> Format: (<Vlan::UVlanIndex> stacked : <Vlan::SVlanIndex> : <Vlan::CVlanIndex>) Possible values: - stacked : stacked vlan identity Field type <Vlan::UVlanIndex> - unstacked vlan identity - range: [1...4093,4096] Field type <Vlan::SVlanIndex> - service vlan identity - range: [2...4093] Field type <Vlan::CVlanIndex> - customer vlan identity - range: [0...4093]	<i>mandatory parameter</i> protocol group vlan id
priority	Parameter type: <Vlan::Priority> Format: - priority of ethernet frames - range: [0...7]	<i>mandatory parameter</i> priority of protocol based vlan

22.8 Vlan Pbit Traffic Counter Configuration Command

Command Description

This command allows the operator to configure the p-bit traffic counter.

User Level

The command can be accessed by operators with vlan privileges, and executed by operators with vlan privileges.

Command Syntax

The command has the following syntax:

```
> configure vlan pbit-statistics ( no port (vlan-port) min-dot1p <Vlan::Dot1pMin> max-dot1p <Vlan::Dot1pMax> )
| ( port (vlan-port) min-dot1p <Vlan::Dot1pMin> max-dot1p <Vlan::Dot1pMax> )
```

Command Parameters

Table 22.8-1 "Vlan Pbit Traffic Counter Configuration Command" Resource Parameters

Resource Identifier	Type	Description
(vlan-port)	Format: (vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::VpId> : <Eqpt::VcId> : <Eqpt::UnstackedVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::UnstackedVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::VpId> : <Eqpt::VcId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> / <Eqpt::OntPortId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> / <Eqpt::OntPortId> : <Eqpt::UnstackedVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / voip : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / vuni :	vlan port

Resource Identifier	Type	Description
	<pre> stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / voip : <Eqpt::UnstackedVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / vuni : <Eqpt::UnstackedVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::LLId> : <Eqpt::UnstackedVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::LLId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan-port:ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Ng2::OntId> / <Eqpt::Ng2OntSlotId> / <Eqpt::Ng2OntPortId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan-port:ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Ng2::OntId> / <Eqpt::Ng2OntSlotId> / <Eqpt::Ng2OntPortId> : <Eqpt::UnstackedVlan> vlan-port:ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Ng2::OntId> / vuni : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan-port:ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Ng2::OntId> / vuni : <Eqpt::UnstackedVlan>) Possible values: - vlan-port : vlan port - vlan-port:ng2 : ngpon2 vlan port Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number Field type <Eqpt::VpiId> - atm VPI Field type <Eqpt::VciId> - atm VCI Field type <Eqpt::PonId> - the PON identifier Field type <Eqpt::OntId> - the ONT identifier Field type <Eqpt::ChannelGroupId> - the channel group identifier Field type <Eqpt::SubChannelGroupId> - the subchannel group identifier Field type <Ng2::OntId> - the ONT identifier Possible values: - voip : virtual uni identifier obsolete alternative replaced by vuni - vuni : virtual uni identifier Possible values: </pre>	

Resource Identifier	Type	Description
	- vuni : virtual NGPON2 uni identifier - Field type <Eqpt::OntSlotId> - the ONT SLOT identifier - Field type <Eqpt::OntPortId> - the ONT PORT identifier - Field type <Eqpt::Ng2OntSlotId> - the NGPON2 ONT SLOT identifier - Field type <Eqpt::Ng2OntPortId> - the NGPON2 ONT PORT identifier - Field type <Eqpt::LLId> - the LLID identifier, range 1 for EPON, range 1-8 for DPOE - Possible values: - stacked : stacked vlan identity - Field type <Eqpt::UnstackedVlan> - unstacked vlan id - Field type <Eqpt::SVlan> - service vlan id - Field type <Eqpt::CVlan> - customer vlan id	
min-dot1p	Parameter type: <Vlan::Dot1pMin> Format: - dot1p value range - range: [0...7]	min p-bit value
max-dot1p	Parameter type: <Vlan::Dot1pMax> Format: - dot1p value range - range: [0...7]	max p-bit value

22.9 Vlan Priority Regeneration Profile Configuration Command

Command Description

This command allows the operator to configure a custom priority regeneration profile instead of one of the 10 hard-coded profiles. The priority regeneration profile table stores the p-bit mapping rules that can be used by a L2 Forwarder in the upstream and downstream direction.

User Level

The command can be accessed by operators with `vlan` privileges, and executed by operators with `vlan` privileges.

Command Syntax

The command has the following syntax:

```
> configure vlan ( no priority-regen (profile-idx) ) | ( priority-regen (profile-idx) profile-name <AsamProfileName>
[ no pbit0 | pbit0 <Vlan::NibbleMaskRestricted_0> ] [ no pbit1 | pbit1 <Vlan::NibbleMaskRestricted_1> ] [ no
pbit2 | pbit2 <Vlan::NibbleMaskRestricted_2> ] [ no pbit3 | pbit3 <Vlan::NibbleMaskRestricted_3> ] [ no pbit4 |
pbit4 <Vlan::NibbleMaskRestricted_4> ] [ no pbit5 | pbit5 <Vlan::NibbleMaskRestricted_5> ] [ no pbit6 | pbit6
<Vlan::NibbleMaskRestricted_6> ] [ no pbit7 | pbit7 <Vlan::NibbleMaskRestricted_7> ] )
```

Command Parameters

Table 22.9-1 "Vlan Priority Regeneration Profile Configuration Command" Resource Parameters

Resource Identifier	Type	Description
(profile-idx)	Format: - a unique index value for the priority regeneration profile - range: [11...32]	A unique profile index

Table 22.9-2 "Vlan Priority Regeneration Profile Configuration Command" Command Parameters

Parameter	Type	Description
profile-name	Parameter type: <AsamProfileName> Format: - a profile name - range: [a-zA-Z0-9-_.] - length: 1<=x<=32	<i>mandatory parameter</i> A unique profile name
[no] pbit0	Parameter type: <Vlan::NibbleMaskRestricted_0> Format: - nibble mask - range: [0...8]	<i>optional parameter with default value: 8</i> pbit mapping corresponding to pbit0
[no] pbit1	Parameter type: <Vlan::NibbleMaskRestricted_1> Format: - nibble mask - range: [0...8]	<i>optional parameter with default value: 8</i> pbit mapping corresponding to pbit1
[no] pbit2	Parameter type: <Vlan::NibbleMaskRestricted_2>	<i>optional parameter with default</i>

Parameter	Type	Description
	Format: - nibble mask - range: [0...8]	<i>value: 8</i> pbit mapping corresponding to pbit2
[no] pbit3	Parameter type: <Vlan::NibbleMaskRestricted_3> Format: - nibble mask - range: [0...8]	<i>optional parameter with default value: 8</i> pbit mapping corresponding to pbit3
[no] pbit4	Parameter type: <Vlan::NibbleMaskRestricted_4> Format: - nibble mask - range: [0...8]	<i>optional parameter with default value: 8</i> pbit mapping corresponding to pbit4
[no] pbit5	Parameter type: <Vlan::NibbleMaskRestricted_5> Format: - nibble mask - range: [0...8]	<i>optional parameter with default value: 8</i> pbit mapping corresponding to pbit5
[no] pbit6	Parameter type: <Vlan::NibbleMaskRestricted_6> Format: - nibble mask - range: [0...8]	<i>optional parameter with default value: 8</i> pbit mapping corresponding to pbit6
[no] pbit7	Parameter type: <Vlan::NibbleMaskRestricted_7> Format: - nibble mask - range: [0...8]	<i>optional parameter with default value: 8</i> pbit mapping corresponding to pbit7

23- VLAN Tpid Configuration Commands

23.1 VLAN Tpid Configuration Command Tree	23-1005
23.2 VLAN General Configuration Command	23-1006

23.1 VLAN Tpid Configuration Command Tree

Description

This chapter gives an overview of nodes that are handled by "VLAN Tpid Configuration Commands".

Command Tree

```
----configure
  ----vlan
    ----[no] tpid
      - (tpid_idx)
      - value
```

23.2 VLAN General Configuration Command

Command Description

This command allows the operator to specify VLAN parameters that are globally applicable to VLANs:

- tpid : vlan tpid.

User Level

The command can be accessed by operators with vlan privileges, and executed by operators with vlan privileges.

Command Syntax

The command has the following syntax:

> configure vlan (no tpid (tpid_idx)) | (tpid (tpid_idx) value <Vlan::Tpid>)

Command Parameters

Table 23.2-1 "VLAN General Configuration Command" Resource Parameters

Resource Identifier	Type	Description
(tpid_idx)	Format: - vlan tpid index - range: [1...4]	vlan tpid

Table 23.2-2 "VLAN General Configuration Command" Command Parameters

Parameter	Type	Description
value	Parameter type: <Vlan::Tpid> Format: - vlan tpid hex string(example : 8100), scope is 600-ffff - range: [a-fA-F0-9] - length: 1<=x<=4	<i>mandatory parameter</i> This object configures system tpid

24- Bridge Configuration Commands

24.1 Bridge Configuration Command Tree	24-1008
24.2 Bridge General Configuration Command	24-1010
24.3 Bridge Port Configuration Command	24-1011
24.4 Bridge Port to VLAN Association Configuration Command	24-1018
24.5 L2 Static User Ip Address Configuration Command	24-1026
24.6 L2 Static User Ipv6 Address Configuration Command	24-1028

24.1 Bridge Configuration Command Tree

Description

This chapter gives an overview of nodes that are handled by "Bridge Configuration Commands".

Command Tree

```
----configure
----bridge
  - [no] ageing-time
  ----[no] port
    - (port)
    - [no] pvid
    - [no] default-priority
    - [no] mac-learn-off
    - [no] max-unicast-mac
    - [no] qos-profile
    - [no] prio-regen-prof
    - [no] prio-regen-name
    - [no] max-committed-mac
    - [no] mirror-mode
    - [no] mirror-vlan
    - [no] outervlancapture
    - [no] direction
    - [no] pvid-tagging-flag
    - [no] ds-pbit-mode
    - [no] default-tpid
  ----[no] vlan-id
    - (index)
    - [no] tag
    X [no] network-vlan
    - [no] l2fwder-vlan
    - [no] vlan-scope
    - [no] qos
    - [no] qos-profile
    - [no] prior-best-effort
    - [no] prior-background
    - [no] prior-spare
    - [no] prior-exc-effort
    - [no] prior-ctrl-load
    - [no] prior-less-100ms
    - [no] prior-less-10ms
    - [no] prior-nw-ctrl
    - [no] in-qos-prof-name
    - [no] max-up-qos-policy
    - [no] max-ip-antispoof
    - [no] max-unicast-mac
    - [no] max-ipv6-antisfp
    - [no] mac-learn-ctrl
    - [no] min-cvlan-id
    - [no] max-cvlan-id
    - [no] ds-dedicated-q
```

- [no] tpid
- [no] inner-pbit-remark
- [no] groupid
- [no] usacceptframetype
- [no] oltregenprofile
- static-user
 - [no] ip-address
 - (ipaddr)
 - [no] ipv6-address
 - (prefixandlength)

24.2 Bridge General Configuration Command

Command Description

This command allows the operator to specify the aging time for dynamically learned MAC addresses in the filtering database. The setting is applicable to the entire bridge.

User Level

The command can be accessed by operators with vlan privileges, and executed by operators with vlan privileges.

Command Syntax

The command has the following syntax:

```
> configure bridge [ no ageing-time | ageing-time <Vlan::AgingTime> ]
```

Command Parameters

Table 24.2-2 "Bridge General Configuration Command" Command Parameters

Parameter	Type	Description
[no] ageing-time	Parameter type: <Vlan::AgingTime> Format: - ageing time - unit: sec - range: [10...1000000]	<i>optional parameter with default value: 300</i> ageing timeout for dynamic mac entries

24.3 Bridge Port Configuration Command

Command Description

This command allows the operator to specify various parameters applicable to a specific bridge port. These parameters determine the handling of frames on the bridge port.

Priority Regeneration Profile: these profiles are predetermined. Following profiles are available:

- Profile 1: Trusted Port
- Profile 2: Best Effort
- Profile 3: Controlled Load, all priority 3 traffic
- Profile 4: Controlled Load, all priority 4 traffic
- Profile 5: Background
- Profile 6: Best Effort, Controlled Load, Voice
- Profile 7: Best Effort, Controlled Load, Voice according 802.1d Annex G
- Profile 8: Best Effort, Voice
- Profile 9: L2 VPN with 3 traffic classes
- Profile 10: L2 VPN with 4 traffic classes

Details on these profiles can be obtained using a show command.

The parameter 'acceptable-frame-type' controls the format of frames received from the users. The parameter can take either of three values,

single-tagged: This configuration allows the user to send single tagged frames. The VLAN-id of tagged frames will be verified against the configured port-vlan associations. Untagged frames and priority tagged frames will be discarded (in absence of configuration on how to handle untagged and priority tagged frames). Double tagged frames will be discarded. The configuration of this value should be completed with the configuration of:

- one or more port-vlan associations.

The configuration of this value should **not** be combined with the configuration of:

- a port default vlan, or
- a port-protocol default vlan for PPPoE, or
- a terminated PPPoE interface, or
- a port-protocol default vlan for IPoE, or
- a terminated IPoE interface.

untagged: This configuration allows the user to send untagged frames and on some types of HW also priority tagged frames. Processing untagged / priority tagged frames requires additional configuration. Such frames will be discarded in absence of such additional configuration. The configuration of the acceptable-Frame-Type to this value results also in the autonomous creation by the system of an 'IGMP channel' and of an '802.1x Port' associated to this Bridge Port. These objects are created with default values such that the corresponding function is 'disabled'. The configuration this value should be completed with the creation of:

- one or more port-vlan associations and
- a port default vlan, and/or
- a port-protocol default vlan for PPPoE, and/or
- a port-protocol default vlan for IPoE,

or instead of a port-protocol default vlan for PPPoE.

- a terminated PPPoE interface, or

or instead of a port-protocol default vlan for IPoE.

- a terminated IPoE interface.

However, note that this value is **not always strictly forced on all HW**. E.g. some type of LSMs will accept and

forward single tagged frames when the VLAN-id matches a configured port-vlan association. Other type of LSMs will always discard single tagged frame.

Note that for the multivlan feature, tagged user traffic will be sent but the "acceptable frame types" must be set to "untagged".

mixed-untagged: This value allows the user to send single tagged frames, untagged frames, and on some types of HW also priority tagged frames. The VLAN-id of single tagged frames will be verified against the configured port-vlan associations. Untagged / priority tagged frames will be processed according additional configuration. Such frames will be discarded in absence of such additional configuration. The configuration of this value should be completed with the configuration of:

- one or more port-vlan associations, **and**
- a port default vlan, and/or
- a port-protocol default vlan for PPPoE, and/or
- a port-protocol default vlan for IPoE.

default-priority: The selection of the port default-priority can apply provided the priority-policy at node level is port-default.

mac-learn-off : The configuration value has no effect in case the bridge port is used for IpoA CC and EPON boards: the system accepts all values but no mac learning will be done.

max-unicast-mac: The value 65535 indicates that there is not max mac control on vlan port.

Remark: Please note that in case the RADIUS server returns a VLAN for 802.1x authenticated ports, it is recommended to not configure a port default VLAN ID (PVID) on that user port. In any case, the VLAN ID returned by the RADIUS server may not equal the pre- configured PVID on the user port. In addition, the returned VLAN ID by the RADIUS server may not be configured as the PVID on the user port after successful 802.1x authentication.

User Level

The command can be accessed by operators with vlan privileges, and executed by operators with vlan privileges.

Command Syntax

The command has the following syntax:

```
> configure bridge ( no port (port) ) | ( port (port) [ no pvid | pvid <Network::StackedVlan> ] [ no default-priority |
default-priority <Vlan::Priority> ] [ [ no ] mac-learn-off ] [ no max-unicast-mac | max-unicast-mac
<Vlan::MaxMac> ] [ no qos-profile | qos-profile <Qos::QosSessionProfileName> ] [ no prio-regen-prof |
prio-regen-prof <Vlan::PrioRegenProfile> ] [ no prio-regen-name | prio-regen-name
<Vlan::PrioRegenProfileName> ] [ no max-committed-mac | max-committed-mac <Vlan::ComitMaxMac> ] [ no
mirror-mode | mirror-mode <Vlan::MirrorMode> ] [ no mirror-vlan | mirror-vlan <Vlan::MirrorVlan> ] [ no
outervlancapture | outervlancapture <Vlan::OuterVlan> ] [ no direction | direction
<Vlan::outerVlanCaptureDirection> ] [ no pvid-tagging-flag | pvid-tagging-flag <Vlan::PvidTaggingFlag> ] [ no
ds-pbit-mode | ds-pbit-mode <Vlan::DSPbitMode> ] [ no default-tpid | default-tpid <Vlan::Tpid> ] )
```

Command Parameters

Table 24.3-1 "Bridge Port Configuration Command" Resource Parameters

Resource Identifier	Type	Description
(port)	Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::VpId> : <Eqpt::VcId> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> /	identity of a port(e.g. uplink port, atm pvc, efm port, eth port, la group ...)

Resource Identifier	Type	Description
	<code><Eqpt::PortId></code> <code> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> /</code> <code><Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> /</code> <code><Eqpt::OntPortId></code> <code> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> /</code> <code><Eqpt::PonId> / <Eqpt::OntId> / voip</code> <code> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> /</code> <code><Eqpt::PonId> / <Eqpt::OntId> / vuni</code> <code> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> /</code> <code><Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::LLId></code> <code> ng2 : <Eqpt::ChannelGroupId> /</code> <code><Eqpt::SubChannelGroupId> / <Ng2::OntId> /</code> <code><Eqpt::Ng2OntSlotId> / <Eqpt::Ng2OntPortId></code> <code> ng2 : <Eqpt::ChannelGroupId> /</code> <code><Eqpt::SubChannelGroupId> / <Ng2::OntId> / vuni)</code> Possible values: - ng2 : ngpon2 style identification Field type <code><Eqpt::RackId></code> - the rack number Field type <code><Eqpt::ShelfId></code> - the shelf number Field type <code><Eqpt::SlotId></code> - the LT slot number Field type <code><Eqpt::PortId></code> - the port number Field type <code><Eqpt::VpiId></code> - atm VPI Field type <code><Eqpt::VciId></code> - atm VCI Field type <code><Eqpt::PonId></code> - the PON identifier Field type <code><Eqpt::ChannelGroupId></code> - the channel group identifier Field type <code><Eqpt::SubChannelGroupId></code> - the subchannel group identifier Field type <code><Eqpt::OntId></code> - the ONT identifier Field type <code><Ng2::OntId></code> - the ONT identifier Possible values: - voip : virtual uni identifier obsolete alternative replaced by vuni - vuni : virtual uni identifier Possible values: - vuni : virtual NGPON2 uni identifier Field type <code><Eqpt::OntSlotId></code> - the ONT SLOT identifier Field type <code><Eqpt::OntPortId></code> - the ONT PORT identifier Field type <code><Eqpt::Ng2OntSlotId></code> - the NGPON2 ONT SLOT identifier Field type <code><Eqpt::Ng2OntPortId></code> - the NGPON2 ONT PORT identifier Field type <code><Eqpt::LLId></code> - the LLID identifier, range 1 for EPON, range 1-8 for DPOE	

Table 24.3-2 "Bridge Port Configuration Command" Command Parameters

24 Bridge Configuration Commands

Parameter	Type	Description
[no] pvid	Parameter type: <Network::StackedVlan> Format: (<Network::UVlanIndex> stacked : <Network::SVlanIndex> : <Network::CVlanIndex>) Possible values: - stacked : stacked vlan identity Field type <Network::UVlanIndex> - unstacked vlan identity - range: [1...4093] Field type <Network::SVlanIndex> - service vlan identity - range: [2...4093] Field type <Network::CVlanIndex> - customer vlan identity - range: [0...4093]	<i>optional parameter with default value: "stacked : 0 : 4097"</i> The parameter is not visible during creation. default vlan id for untagged frames
[no] default-priority	Parameter type: <Vlan::Priority> Format: - priority of ethernet frames - range: [0...7]	<i>optional parameter with default value: 0</i> priority to be set in upstream frames
[no] mac-learn-off	Parameter type: boolean	<i>optional parameter</i> disable self learning of mac address
[no] max-unicast-mac	Parameter type: <Vlan::MaxMac> Format: - number of unicast mac addresses - range: [1...65535]	<i>optional parameter with default value: "1"</i> max uncommitted unicast mac addresses
[no] qos-profile	Parameter type: <Qos::QosSessionProfileName> Format: (none name : <Qos::IgnoredQosProfileName>) Possible values: - none : no profile name to associate - name : enter profile name to be associated Data driven field type Possible values are depending on the actual configuration and software. The currently allowed values can be shown with online-help.	<i>optional parameter with default value: "none"</i> qos profile name
[no] prio-regen-prof	Parameter type: <Vlan::PrioRegenProfile> Format: (none trusted-port best-effort cl-all-prio-3 cl-all-prio-4 background be-cl-voice be-cl-1d-voice be-voice l2-vpn-3 l2-vpn-4 11 12 13 14 15 16	<i>optional parameter with default value: "none"</i> priority regeneration profile

Parameter	Type	Description
	17 18 19 20 21 22 23 24 25 26 27 28 29 30 31 32) Possible values: - none : default value - trusted-port : trusted port - best-effort : best effort - cl-all-prio-3 : controlled load, all priority 3 traffic - cl-all-prio-4 : controlled load, all priority 4 traffic - background : background - be-cl-voice : best effort, controlled load, voice - be-cl-1d-voice : best effort, controlled load, 802.1d Annex G voice - be-voice : best effort voice - l2-vpn-3 : L2 VPN with 3 traffic classes - l2-vpn-4 : L2 VPN with 4 traffic classes - 11 : operator-defined profile - 12 : operator-defined profile - 13 : operator-defined profile - 14 : operator-defined profile - 15 : operator-defined profile - 16 : operator-defined profile - 17 : operator-defined profile - 18 : operator-defined profile - 19 : operator-defined profile - 20 : operator-defined profile - 21 : operator-defined profile - 22 : operator-defined profile - 23 : operator-defined profile - 24 : operator-defined profile - 25 : operator-defined profile - 26 : operator-defined profile - 27 : operator-defined profile - 28 : operator-defined profile - 29 : operator-defined profile - 30 : operator-defined profile - 31 : operator-defined profile - 32 : operator-defined profile	
[no] prio-regen-name	Parameter type: <Vlan::PrioRegenProfileName> Format: (none name : <Vlan::IgnoredVlanProfileName>) Possible values: - none : no profile name to associate	<i>optional parameter with default value: "none"</i> priority regeneration profile name

24 Bridge Configuration Commands

Parameter	Type	Description
	- name : enter profile name to be associated Data driven field type Possible values are depending on the actual configuration and software. The currently allowed values can be shown with online-help.	
[no] max-committed-mac	Parameter type: <Vlan::ComitMaxMac> Format: - number of unicast mac addresses - range: [0...128,65535]	<i>optional parameter with default value: "65535"</i> max committed unicast mac addresses. 65535 means the committed value is the same as max-unicast-mac
[no] mirror-mode	Parameter type: <Vlan::MirrorMode> Format: (disable overwrite-outer-vlan insert-mirror-vlan) Possible values: - disable : disable mirror vlan tag - overwrite-outer-vlan : overwrite outer vlan tag with mirror vlan tag - insert-mirror-vlan : prepend mirror vlan tag to outer vlan tag	<i>optional parameter with default value: "disable"</i> flow mirroring mode of the bridge port
[no] mirror-vlan	Parameter type: <Vlan::MirrorVlan> Format: - mirroring vlan id - range: [0...4093]	<i>optional parameter with default value: 0</i> vlan-id to be inserted into mirrored packets. This configuration value has no effect in case mirroring mode of the bridgeport is disabled (mirror-mode).
[no] outervlancapture	Parameter type: <Vlan::OuterVlan> Format: - outer vlan id - range: [0...4093]	<i>optional parameter with default value: 0</i> specify outer VLAN which has to be matched for mirroring the packets received on bridge port.
[no] direction	Parameter type: <Vlan::outerVlanCaptureDirection> Format: (ingress egress bidirection) Possible values: - ingress : enable mirroring in ingress - egress : enable mirroring in egress - bidirection : enable mirroring in both directions	<i>optional parameter with default value: "bidirection"</i> The direction on which the packets has to be captured and mirrored.
[no] pvid-tagging-flag	Parameter type: <Vlan::PvidTaggingFlag> Format: (onu olt) Possible values: - onu : pvid is handled in ONU. - olt : pvid is handled in OLT.	<i>optional parameter with default value: "onu"</i> pvid will be tagged in ONU or in OLT.
[no] ds-pbit-mode	Parameter type: <Vlan::DSPbitMode> Format: (auto translated transparency filtervlanandpbit)	<i>optional parameter with default value: "auto"</i> downstream p-bits mode

Parameter	Type	Description
	Possible values: - auto : transparency for DSL and translated for GPON - translated : for known p-bits the inverse translation is performed in downstream; unknown p-bits are forwarded unchanged in downstream - transparency : all p-bits are forwarded unchanged in downstream - filtervlanandpbit : for matched vlan and p-bit the inverse translation is performed in downstream; unmatched are discarded in downstream	
[no] default-tpid	Parameter type: <Vlan::Tpid> Format: - vlan tpid hex string(example : 8100), scope is 600-ffff - range: [a-fA-F0-9] - length: 1<=x<=4	<i>optional parameter with default value: "8100"</i> configure default outer tpid

24.4 Bridge Port to VLAN Association Configuration Command

Command Description

This command allows the operator to associate a VLAN to a bridge port and to define VLAN attributes on this port. The parameters that allow to configure the priority bits (prior-best-effort till prior-nw-ctrl) only apply in case of a qos-aware VLAN.

User Level

The command can be accessed by operators with vlan privileges, and executed by operators with vlan privileges.

Command Syntax

The command has the following syntax:

```
> configure bridge port (port) ( no vlan-id (index) ) | ( vlan-id (index) [ no tag | tag <Vlan::PortUntagStatus> ] [ no
network-vlan | network-vlan <Network::StackedVlan> ] [ no l2fwder-vlan | l2fwder-vlan <Network::StackedVlan>
] [ no vlan-scope | vlan-scope <Vlan::VlanScope> ] [ no qos | qos <Vlan::QosPolicy> ] [ no qos-profile | qos-profile
<Qos::QosSessionProfileName> ] [ [ no ] prior-best-effort ] [ [ no ] prior-background ] [ [ no ] prior-spare ] [ [ no ]
prior-exc-effort ] [ [ no ] prior-ctrl-load ] [ [ no ] prior-less-100ms ] [ [ no ] prior-less-10ms ] [ [ no ] prior-nw-ctrl ]
[ no in-qos-prof-name | in-qos-prof-name <Qos::QosIngressProfileNameForVlan> ] [ no max-up-qos-policy |
max-up-qos-policy <Vlan::MaxUpQoSPolicy> ] [ no max-ip-antispoof | max-ip-antispoof
<Vlan::MaxIpAntispoof> ] [ no max-unicast-mac | max-unicast-mac <Vlan::BridgeMaxMac> ] [ no
max-ipv6-antisfpf | max-ipv6-antisfpf <Vlan::MaxIpAntispoof> ] [ no mac-learn-ctrl | mac-learn-ctrl
<Vlan::MacLearnCtrl> ] [ no min-cvlan-id | min-cvlan-id <Vlan::MinCVlanId> ] [ no max-cvlan-id | max-cvlan-id
<Vlan::MaxCVlanId> ] [ no ds-dedicated-q | ds-dedicated-q <Vlan::DsDedicatedQueue> ] [ no tpid | tpid
<Vlan::Tpid> ] [ no inner-pbit-remark | inner-pbit-remark <Vlan::InnerPbitRemark> ] [ no groupid | groupid
<Vlan::GroupId> ] [ no usacceptframetype | usacceptframetype <Vlan::USAcceptFrameType> ] [ no
oltregenprofile | oltregenprofile <Vlan::OltRegenProfile> ] )
```

Command Parameters

Table 24.4-1 "Bridge Port to VLAN Association Configuration Command" Resource Parameters

Resource Identifier	Type	Description
(port)	Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::VpiId> : <Eqpt::VciId> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> / <Eqpt::OntPortId> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / voip <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> /	identity of a port(e.g. uplink port, atm pvc, efm port, eth port, la group ...)

Resource Identifier	Type	Description
	<Eqpt::PonId> / <Eqpt::OntId> / vuni <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::LLId> ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Ng2::OntId> / <Eqpt::Ng2OntSlotId> / <Eqpt::Ng2OntPortId> ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Ng2::OntId> / vuni) Possible values: - ng2 : ngpon2 style identification Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number Field type <Eqpt::VpId> - atm VPI Field type <Eqpt::VciId> - atm VCI Field type <Eqpt::PonId> - the PON identifier Field type <Eqpt::ChannelGroupId> - the channel group identifier Field type <Eqpt::SubChannelGroupId> - the subchannel group identifier Field type <Eqpt::OntId> - the ONT identifier Field type <Ng2::OntId> - the ONT identifier Possible values: - voip : virtual uni identifier obsolete alternative replaced by vuni - vuni : virtual uni identifier Possible values: - vuni : virtual NGPON2 uni identifier Field type <Eqpt::OntSlotId> - the ONT SLOT identifier Field type <Eqpt::OntPortId> - the ONT PORT identifier Field type <Eqpt::Ng2OntSlotId> - the NGPON2 ONT SLOT identifier Field type <Eqpt::Ng2OntPortId> - the NGPON2 ONT PORT identifier Field type <Eqpt::LLId> - the LLID identifier, range 1 for EPON, range 1-8 for DPOE	
(index)	Format: (<Vlan::UVlanIndex> stacked : <Vlan::SVlanIndexStacked> : <Vlan::CVlanIndex>) Possible values: - stacked : stacked vlan identity Field type <Vlan::UVlanIndex> - unstacked vlan identity - range: [1...4093,4096]	vlan id

Resource Identifier	Type	Description
	Field type <Vlan::SVlanIndexStacked> - service vlan identity - range: [1...4093] Field type <Vlan::CVlanIndex> - customer vlan identity - range: [0...4093]	

Table 24.4-2 "Bridge Port to VLAN Association Configuration Command" Command Parameters

Parameter	Type	Description
[no] tag	Parameter type: <Vlan::PortUntagStatus> Format: (untagged single-tagged priority-tagged) Possible values: - untagged : untagged outgoing frames - single-tagged : singletagged outgoing frames - priority-tagged : prioritytagged outgoing frames	<i>optional parameter with default value: "untagged"</i> tag control for egress port
[no] network-vlan	Parameter type: <Network::StackedVlan> Format: (<Network::UVlanIndex> stacked : <Network::SVlanIndex> : <Network::CVlanIndex>) Possible values: - stacked : stacked vlan identity Field type <Network::UVlanIndex> - unstacked vlan identity - range: [1...4093] Field type <Network::SVlanIndex> - service vlan identity - range: [2...4093] Field type <Network::CVlanIndex> - customer vlan identity - range: [0...4093]	<i>obsolete parameter replaced by parameter "l2fwder-vlan"</i> network vlan id
[no] l2fwder-vlan	Parameter type: <Network::StackedVlan> Format: (<Network::UVlanIndex> stacked : <Network::SVlanIndex> : <Network::CVlanIndex>) Possible values: - stacked : stacked vlan identity Field type <Network::UVlanIndex> - unstacked vlan identity - range: [1...4093] Field type <Network::SVlanIndex> - service vlan identity - range: [2...4093] Field type <Network::CVlanIndex> - customer vlan identity - range: [0...4093]	<i>optional parameter with default value: "stacked : 0 : 4097"</i> layer2 forwarder vlan id
[no] vlan-scope	Parameter type: <Vlan::VlanScope> Format: (network l2fwder local) Possible values: - network : network wide scope	<i>optional parameter with default value: "l2fwder"</i> the vlan scope

Parameter	Type	Description
	obsolete alternative replaced by l2fwder - l2fwder : l2 forwarder scope - local : local scope	
[no] qos	Parameter type: <Vlan::QosPolicy> Format: (priority : <Vlan::Priority> profile : none profile : trusted-port profile : best-effort profile : cl-all-prio-3 profile : cl-all-prio-4 profile : background profile : be-cl-voice profile : be-cl-1d-voice profile : be-voice profile : l2-vpn-3 profile : l2-vpn-4 profile : 11 profile : 12 profile : 13 profile : 14 profile : 15 profile : 16 profile : 17 profile : 18 profile : 19 profile : 20 profile : 21 profile : 22 profile : 23 profile : 24 profile : 25 profile : 26 profile : 27 profile : 28 profile : 29 profile : 30 profile : 31 profile : 32 prio-regen-name : none prio-regen-name : name : <Vlan::IgnoredVlanProfileName>) Possible values: - priority : fixed priority identify - profile : regeneration profile identify - prio-regen-name : priority regeneration profile name Field type <Vlan::Priority> - priority of ethernet frames - range: [0...7] Possible values: - none : default value - trusted-port : trusted port - best-effort : best effort - cl-all-prio-3 : controlled load, all priority 3 traffic - cl-all-prio-4 : controlled load, all priority 4 traffic - background : background - be-cl-voice : best effort, controlled load, voice	<i>optional parameter with default value: "profile : none"</i> the qos policy

24 Bridge Configuration Commands

Parameter	Type	Description
	- be-cl-1d-voice : best effort, controlled load, 802.1d Annex G voice - be-voice : best effort voice - l2-vpn-3 : L2 VPN with 3 traffic classes - l2-vpn-4 : L2 VPN with 4 traffic classes - 11 : operator-defined profile - 12 : operator-defined profile - 13 : operator-defined profile - 14 : operator-defined profile - 15 : operator-defined profile - 16 : operator-defined profile - 17 : operator-defined profile - 18 : operator-defined profile - 19 : operator-defined profile - 20 : operator-defined profile - 21 : operator-defined profile - 22 : operator-defined profile - 23 : operator-defined profile - 24 : operator-defined profile - 25 : operator-defined profile - 26 : operator-defined profile - 27 : operator-defined profile - 28 : operator-defined profile - 29 : operator-defined profile - 30 : operator-defined profile - 31 : operator-defined profile - 32 : operator-defined profile Possible values: - none : no profile name to associate - name : enter profile name to be associated Data driven field type Possible values are depending on the actual configuration and software. The currently allowed values can be shown with online-help.	
[no] qos-profile	Parameter type: <Qos::QosSessionProfileName> Format: <pre>(none name : <Qos::IgnoredQosProfileName>)</pre> Possible values: - none : no profile name to associate - name : enter profile name to be associated Data driven field type Possible values are depending on the actual configuration and software. The currently allowed values can be shown with online-help.	<i>optional parameter with default value: "none"</i> qos profile name
[no] prior-best-effort	Parameter type: boolean	<i>optional parameter</i> enable best effort priority (value 0)
[no] prior-background	Parameter type: boolean	<i>optional parameter</i> enable background priority (value 1)
[no] prior-spare	Parameter type: boolean	<i>optional parameter</i> enable spare priority (value 2)
[no] prior-exc-effort	Parameter type: boolean	<i>optional parameter</i> enable the excellent effort priority (value 3)
[no] prior-ctrl-load	Parameter type: boolean	<i>optional parameter</i>

Parameter	Type	Description
		enable the controlled load priority (value 4)
[no] prior-less-100ms	Parameter type: boolean	<i>optional parameter</i> enable video <100ms latency and jitter priority (value 5)
[no] prior-less-10ms	Parameter type: boolean	<i>optional parameter</i> enable video <10ms latency and jitter priority (value 6)
[no] prior-nw-ctrl	Parameter type: boolean	<i>optional parameter</i> enable the network controlled priority (value 7)
[no] in-qos-prof-name	Parameter type: <Qos::QosIngressProfileNameForVlan> Format: (default name : <Qos::IgnoredQosProfileName>) Possible values: - default : default profile name - name : enter profile name to be associated Data driven field type Possible values are depending on the actual configuration and software. The currently allowed values can be shown with online-help.	<i>optional parameter with default value: "name : Default_TC0"</i> <i>The parameter is not visible during modification.</i> a pointer to the Qos Profile that maps pbits to TCs on a VLAN port basis
[no] max-up-qos-policy	Parameter type: <Vlan::MaxUpQoSPolicy> Format: - the max number of Qos Policy numbers (ACL and CCL) on a VLAN port basis - range: [0...8]	<i>optional parameter with default value: "0"</i> the max number of Qos Policy numbers (ACL and CCL) on a VLAN port basis
[no] max-ip-antispoof	Parameter type: <Vlan::MaxIpAntispoof> Format: - the max number of IP Antispoofing on a VLAN port basis - range: [0...32,65535]	<i>optional parameter with default value: "65535"</i> the max number of IP address number in IP antispoofing and/or ARP relay
[no] max-unicast-mac	Parameter type: <Vlan::BridgeMaxMac> Format: - number of unicast mac addresses - range: [0...65535,65535]	<i>optional parameter with default value: "65535"</i> max uncommitted unicast mac addresses
[no] max-ipv6-antispf	Parameter type: <Vlan::MaxIpAntispoof> Format: - the max number of IP Antispoofing on a VLAN port basis - range: [0...32,65535]	<i>optional parameter with default value: "65535"</i> the max number of IPV6 address number in IP antispoofing and/or ARP relay
[no] mac-learn-ctrl	Parameter type: <Vlan::MacLearnCtrl> Format: - MAC addresses shall be learned 1: mac-learn is enabled 2: mac-learn is disabled 3: mac-learn is inherited from bridge port - range: [1...3]	<i>optional parameter with default value: "3"</i> MAC address learned control up(1), down(2), inherit from bridgedPort(3)
[no] min-cvlan-id	Parameter type: <Vlan::MinCVlanId> Format: - Lower boundary of CVLAN range for protocol awareness - range: [1...4095]	<i>optional parameter with default value: "1"</i> This object configures the lower boundary of CVLAN range for protocol awareness for S-VLAN cross-connect(Tunnel)
[no] max-cvlan-id	Parameter type: <Vlan::MaxCVlanId> Format: - Upper boundary of CVLAN range for protocol awareness - range: [1...4095]	<i>optional parameter with default value: "4095"</i> This object configures the upper boundary of CVLAN range for

24 Bridge Configuration Commands

Parameter	Type	Description
		protocol awareness for S-VLAN cross-connect(Tunnel)
[no] ds-dedicated-q	Parameter type: <Vlan::DsDedicatedQueue> Format: (enable disable) Possible values: - enable : enable use of downstream dedicated Q - disable : disable use of downstream dedicated Q	<i>optional parameter with default value: "disable"</i> Packets use dedicated downstream PON level queue
[no] tpid	Parameter type: <Vlan::Tpid> Format: - vlan tpid hex string(example : 8100), scope is 600-ffff - range: [a-fA-F0-9] - length: 1<=x<=4	<i>optional parameter with default value: "0"</i> This object configures vlan port tpid
[no] inner-pbit-remark	Parameter type: <Vlan::InnerPbitRemark> Format: (untouched remark) Possible values: - untouched : disable use of pbit remark in tunnel mode - remark : enable use of pbit remark in tunnel mode	<i>optional parameter with default value: "untouched"</i> Set pbit remark in tunnel mode, untouched(1), remark(2)
[no] groupid	Parameter type: <Vlan::GroupID> Format: - vlan group id to share the policer instance - range: [0...8192]	<i>optional parameter with default value: "0"</i> This object configures vlan group id to share the policer instance, 0 means no group or not sharing policer instance
[no] usacceptframetype	Parameter type: <Vlan::USAcceptFrameType> Format: (all untagandpriority untagged) Possible values: - all : the upstream rule should allow all types of Ethernet frames which received from the UNI port to pass - untagandpriority : the upstream rule should only allow untag and priority tagged Ethernet frames which received from the UNI port to pass - untagged : the upstream rule should only allow untag Ethernet frames which received from the UNI port to pass	<i>optional parameter with default value: "all"</i> This object specifies the frame types that should be forwarded or not in upstream.
[no] oltregenprofile	Parameter type: <Vlan::OltRegenProfile> Format: (disabled enabled) Possible values: - disabled : ONU will do regeneration profile in S+C tunnel mode,not on OLT side - enabled : OLT will do regeneration profile in S+C tunnel mode,not on ONU side	<i>optional parameter with default value: "disabled"</i> Set pbit regeneration profile on OLT in S+C tunnel mode, enabled(1), disabled(0)

Command Output

Table 24.4-3 "Bridge Port to VLAN Association Configuration Command" Display parameters

Specific Information		
name	Type	Description
prio-regen-name	Parameter type: <Vlan::PrioRegenProfileName>	priority regeneration profile name

name	Type	Description
	(none name : <Vlan::IgnoredVlanProfileName>) Possible values: - none : no profile name to associate - name : enter profile name to be associated Data driven field type Possible values are depending on the actual configuration and software. The currently allowed values can be shown with online-help.	<i>This element is only shown in detail mode.</i>

24.5 L2 Static User Ip Address Configuration Command

Command Description

This command allows the operator to configure the IP-address for a user interface(vlan-port) of a L2 forwarder.

User Level

The command can be accessed by operators with vlan privileges, and executed by operators with vlan privileges.

Command Syntax

The command has the following syntax:

> configure bridge port (port) vlan-id (index) static-user (no ip-address (ipaddr)) | (ip-address (ipaddr))

Command Parameters

Table 24.5-1 "L2 Static User Ip Address Configuration Command" Resource Parameters

Resource Identifier	Type	Description
(port)	Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::VpiId> : <Eqpt::VciId> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> / <Eqpt::OntPortId> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / voip <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / vuni <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::LLId> ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Ng2::OntId> / <Eqpt::Ng2OntSlotId> / <Eqpt::Ng2OntPortId> ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Ng2::OntId> / vuni) Possible values: - ng2 : ngpon2 style identification Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId>	identity of a port(e.g. uplink port, atm pvc, efm port, eth port, la group ...)

Resource Identifier	Type	Description
	- the LT slot number - Field type <Eqpt::PortId> - the port number - Field type <Eqpt::VpiId> - atm VPI - Field type <Eqpt::VciId> - atm VCI - Field type <Eqpt::PonId> - the PON identifier - Field type <Eqpt::ChannelGroupId> - the channel group identifier - Field type <Eqpt::SubChannelGroupId> - the subchannel group identifier - Field type <Eqpt::OntId> - the ONT identifier - Field type <Ng2::OntId> - the ONT identifier - Possible values: - voip : virtual uni identifier - obsolete alternative replaced by vuni - vuni : virtual uni identifier - Possible values: - vuni : virtual NGPON2 uni identifier - Field type <Eqpt::OntSlotId> - the ONT SLOT identifier - Field type <Eqpt::OntPortId> - the ONT PORT identifier - Field type <Eqpt::Ng2OntSlotId> - the NGPON2 ONT SLOT identifier - Field type <Eqpt::Ng2OntPortId> - the NGPON2 ONT PORT identifier - Field type <Eqpt::LLId> - the LLID identifier, range 1 for EPON, range 1-8 for DPOE	
(index)	Format: <pre>(<Vlan::UVlanIndex> stacked : <Vlan::SVlanIndexStacked> : <Vlan::CVlanIndex>)</pre> Possible values: - stacked : stacked vlan identity - Field type <Vlan::UVlanIndex> - unstacked vlan identity - range: [1...4093,4096] - Field type <Vlan::SVlanIndexStacked> - service vlan identity - range: [1...4093] - Field type <Vlan::CVlanIndex> - customer vlan identity - range: [0...4093]	vlan id
(ipaddr)	Format: <pre><Ip::V4Address> / <Ip::PrefixLengthArpRelay></pre> Field type <Ip::V4Address> - IPv4-address - Field type <Ip::PrefixLengthArpRelay> - IP address prefix length [23.....32] for dsl - range: [8...32]	inetaddress

24.6 L2 Static User Ipv6 Address Configuration Command

Command Description

This command allows the operator to configure the IPv6-address for a user interface(vlan-port) of a L2 forwarder.

User Level

The command can be accessed by operators with vlan privileges, and executed by operators with vlan privileges.

Command Syntax

The command has the following syntax:

```
> configure bridge port (port) vlan-id (index) static-user ( no ipv6-address (prefixandlength) ) | ( ipv6-address (prefixandlength) )
```

Command Parameters

Table 24.6-1 "L2 Static User Ipv6 Address Configuration Command" Resource Parameters

Resource Identifier	Type	Description
(port)	Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::VpId> : <Eqpt::VcId> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> / <Eqpt::OntPortId> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / voip <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / vuni <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::LLId> ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Ng2::OntId> / <Eqpt::Ng2OntSlotId> / <Eqpt::Ng2OntPortId> ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Ng2::OntId> / vuni) Possible values: - ng2 : ngpon2 style identification Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number	identity of a port(e.g. uplink port, atm pvc, efm port, eth port, la group ...)

Resource Identifier	Type	Description
	Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number Field type <Eqpt::VpiId> - atm VPI Field type <Eqpt::VciId> - atm VCI Field type <Eqpt::PonId> - the PON identifier Field type <Eqpt::ChannelGroupId> - the channel group identifier Field type <Eqpt::SubChannelGroupId> - the subchannel group identifier Field type <Eqpt::OntId> - the ONT identifier Field type <Ng2::OntId> - the ONT identifier Possible values: - voip : virtual uni identifier obsolete alternative replaced by vuni - vuni : virtual uni identifier Possible values: - vuni : virtual NGPON2 uni identifier Field type <Eqpt::OntSlotId> - the ONT SLOT identifier Field type <Eqpt::OntPortId> - the ONT PORT identifier Field type <Eqpt::Ng2OntSlotId> - the NGPON2 ONT SLOT identifier Field type <Eqpt::Ng2OntPortId> - the NGPON2 ONT PORT identifier Field type <Eqpt::LLId> - the LLID identifier, range 1 for EPON, range 1-8 for DPOE	
(index)	Format: (<Vlan::UVlanIndex> stacked : <Vlan::SVlanIndexStacked> : <Vlan::CVlanIndex>) Possible values: - stacked : stacked vlan identity Field type <Vlan::UVlanIndex> - unstacked vlan identity - range: [1...4093,4096] Field type <Vlan::SVlanIndexStacked> - service vlan identity - range: [1...4093] Field type <Vlan::CVlanIndex> - customer vlan identity - range: [0...4093]	vlan id
(prefixandlength)	Format: <ipv6::Prefix> / <ipv6::PrefixLengthLimited> Field type <ipv6::Prefix> - IPv6-address Field type <ipv6::PrefixLengthLimited> - length of IPv6 address or prefix - range: [49...64,128]	ipv6 address prefix

25- VLAN Tpid Configuration Commands

25.1 VLAN Tpid Configuration Command Tree	25-1031
25.2 VLAN General Configuration Command	25-1032

25.1 VLAN Tpid Configuration Command Tree

Description

This chapter gives an overview of nodes that are handled by "VLAN Tpid Configuration Commands".

Command Tree

```
----configure
  ----bridge
    ----port
      ----(port)
        ----vlan-tpid0
          - (num)
          - [no] tpid
```

25.2 VLAN General Configuration Command

Command Description

This command allows the operator to specify VLAN parameters that are globally applicable to VLANs:

- *tpid* : vlan tpid.

User Level

The command can be accessed by operators with vlan privileges, and executed by operators with vlan privileges.

Command Syntax

The command has the following syntax:

> configure bridge port (port) vlan-tpid0 (num) [no tpid | tpid <Vlan::Tpid>]

Command Parameters

Table 25.2-1 "VLAN General Configuration Command" Resource Parameters

Resource Identifier	Type	Description
(port)	Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::VpiId> : <Eqpt::VciId> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> / <Eqpt::OntPortId> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / voip <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / vuni <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::LLId> ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Ng2::OntId> / <Eqpt::Ng2OntSlotId> / <Eqpt::Ng2OntPortId> ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Ng2::OntId> / vuni) Possible values: - ng2 : ngpon2 style identification Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId>	identity of a port(e.g. uplink port, atm pvc, efm port, eth port, la group ...)

Resource Identifier	Type	Description
	- the port number - Field type <Eqpt::VpiId> - atm VPI - Field type <Eqpt::VciId> - atm VCI - Field type <Eqpt::PonId> - the PON identifier - Field type <Eqpt::ChannelGroupId> - the channel group identifier - Field type <Eqpt::SubChannelGroupId> - the subchannel group identifier - Field type <Eqpt::OntId> - the ONT identifier - Field type <Ng2::OntId> - the ONT identifier - Possible values: - voip : virtual uni identifier - obsolete alternative replaced by vuni - vuni : virtual uni identifier - Possible values: - vuni : virtual NGPON2 uni identifier - Field type <Eqpt::OntSlotId> - the ONT SLOT identifier - Field type <Eqpt::OntPortId> - the ONT PORT identifier - Field type <Eqpt::Ng2OntSlotId> - the NGPON2 ONT SLOT identifier - Field type <Eqpt::Ng2OntPortId> - the NGPON2 ONT PORT identifier - Field type <Eqpt::LLId> - the LLID identifier, range 1 for EPON, range 1-8 for DPOE	
(num)	Format: - the tpid number 1 - range: [0]	the value of the tpid index

Table 25.2-2 "VLAN General Configuration Command" Command Parameters

Parameter	Type	Description
[no] tpid	Parameter type: <Vlan::Tpid> Format: - vlan tpid hex string(example : 8100), scope is 600-ffff - range: [a-fA-F0-9] - length: 1<=x<=4	<i>optional parameter with default value: "8100"</i> the value of the tpid

26- VLAN Tpid Configuration Commands

26.1 VLAN Tpid Configuration Command Tree	26-1035
26.2 VLAN General Configuration Command	26-1036

26.1 VLAN Tpid Configuration Command Tree

Description

This chapter gives an overview of nodes that are handled by "VLAN Tpid Configuration Commands".

Command Tree

```
----configure
  ----bridge
    ----port
      ----(port)
        ----vlan-tpid1
          - (num)
          - [no] tpid
```

26.2 VLAN General Configuration Command

Command Description

This command allows the operator to specify VLAN parameters that are globally applicable to VLANs:

- *tpid* : vlan tpid.

User Level

The command can be accessed by operators with vlan privileges, and executed by operators with vlan privileges.

Command Syntax

The command has the following syntax:

> configure bridge port (port) vlan-tpid1 (num) [no tpid | tpid <Vlan::Tpid>]

Command Parameters

Table 26.2-1 "VLAN General Configuration Command" Resource Parameters

Resource Identifier	Type	Description
(port)	Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::VpiId> : <Eqpt::VciId> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> / <Eqpt::OntPortId> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / voip <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / vuni <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::LLId> ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Ng2::OntId> / <Eqpt::Ng2OntSlotId> / <Eqpt::Ng2OntPortId> ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Ng2::OntId> / vuni) Possible values: - ng2 : ngpon2 style identification Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId>	identity of a port(e.g. uplink port, atm pvc, efm port, eth port, la group ...)

Resource Identifier	Type	Description
	- the port number - Field type <Eqpt::VpiId> - atm VPI - Field type <Eqpt::VciId> - atm VCI - Field type <Eqpt::PonId> - the PON identifier - Field type <Eqpt::ChannelGroupId> - the channel group identifier - Field type <Eqpt::SubChannelGroupId> - the subchannel group identifier - Field type <Eqpt::OntId> - the ONT identifier - Field type <Ng2::OntId> - the ONT identifier - Possible values: - voip : virtual uni identifier - obsolete alternative replaced by vuni - vuni : virtual uni identifier - Possible values: - vuni : virtual NGPON2 uni identifier - Field type <Eqpt::OntSlotId> - the ONT SLOT identifier - Field type <Eqpt::OntPortId> - the ONT PORT identifier - Field type <Eqpt::Ng2OntSlotId> - the NGPON2 ONT SLOT identifier - Field type <Eqpt::Ng2OntPortId> - the NGPON2 ONT PORT identifier - Field type <Eqpt::LLId> - the LLID identifier, range 1 for EPON, range 1-8 for DPOE	
(num)	Format: - the number of the tpid number - range: [1]	the value of the tpid index

Table 26.2-2 "VLAN General Configuration Command" Command Parameters

Parameter	Type	Description
[no] tpid	Parameter type: <Vlan::Tpid> Format: - vlan tpid hex string(example : 8100), scope is 600-ffff - range: [a-fA-F0-9] - length: 1<=x<=4	<i>optional parameter with default value: "0"</i> the value of the tpid

27- Li_VLAN Configuration Commands

27.1 Li_VLAN Configuration Command Tree	27-1039
27.2 li_vlan Li Configuration Command	27-1040

27.1 Li_VLAN Configuration Command Tree

Description

This chapter gives an overview of nodes that are handled by "Li_VLAN Configuration Commands".

Command Tree

```
----configure
  ----li_vlan
    - vlan-id
```

27.2 li_vlan Li Configuration Command

Command Description

This command allows the operator to configure lawful interception parameters.

Note: Many system management parameters are supported but are not included in this guide as the NE uses default values.

User Level

The command can be accessed by operators with all,admin,li_user privileges, and executed by operators with all,admin,li_user privileges.

Command Syntax

The command has the following syntax:

```
> configure li_vlan vlan-id <Sec::LiVlanID>
```

Command Parameters

Table 27.2-2 "li_vlan Li Configuration Command" Command Parameters

Parameter	Type	Description
vlan-id	Parameter type: <Sec::LiVlanID> Format: - vlan-id, 0: default livlan - range: [0...4093]	<i>optional parameter</i> vlan id range [1...4093]

28- ARP-RELAY Configuration Commands

28.1 ARP-RELAY Configuration Command Tree	28-1042
28.2 Arp-Relay Statistics Configuration Command	28-1043

28.1 ARP-RELAY Configuration Command Tree

Description

This chapter gives an overview of nodes that are handled by "ARP-RELAY Configuration Commands".

Command Tree

```
----configure
  ----arp-relay
    ----[no] statistics
      - (vlan-port)
```

28.2 Arp-Relay Statistics Configuration Command

Command Description

This command allows the operator to enable/disable the detailed arp-relay statistics.

User Level

The command can be accessed by operators with ip privileges, and executed by operators with ip privileges.

Command Syntax

The command has the following syntax:

```
> configure arp-relay ( no statistics (vlan-port) ) | ( statistics (vlan-port) )
```

Command Parameters

Table 28.2-1 "Arp-Relay Statistics Configuration Command" Resource Parameters

Resource Identifier	Type	Description
(vlan-port)	Format: (vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::VpiId> : <Eqpt::VciId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::VpiId> : <Eqpt::VciId> : <Eqpt::UnstackedVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::UnstackedVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> / <Eqpt::OntPortId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> / <Eqpt::OntPortId> : <Eqpt::UnstackedVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / voip : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / vuni : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / voip : <Eqpt::UnstackedVlan>	The vlan-port interface

Resource Identifier	Type	Description
	<pre> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / vuni : <Eqpt::UnstackedVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::LLId> : <Eqpt::UnstackedVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::LLId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan-port:ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / <Eqpt::Ng2OntSlotId> / <Eqpt::Ng2OntPortId> : <Eqpt::UnstackedVlan> vlan-port:ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / <Eqpt::Ng2OntSlotId> / <Eqpt::Ng2OntPortId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan-port:ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / vuni) Possible values: - vlan-port : vlan port - vlan-port:ng2 : an NGPON2 vlan port Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number Field type <Eqpt::VpId> - atm VPI Field type <Eqpt::VciId> - atm VCI Field type <Eqpt::ChannelGroupId> - the channel group identifier Field type <Eqpt::SubChannelGroupId> - the subchannel group identifier Field type <Eqpt::PonId> - the PON identifier Field type <Eqpt::OntId> - the ONT identifier Field type <Eqpt::Ng2OntId> - the NG2 ONT identifier Possible values: - voip : virtual uni identifier obsolete alternative replaced by vuni - vuni : virtual uni identifier Possible values: - vuni : virtual NGPON2 uni identifier Field type <Eqpt::OntSlotId> - the ONT SLOT identifier Field type <Eqpt::OntPortId> - the ONT PORT identifier Field type <Eqpt::Ng2OntSlotId> - the NGPON2 ONT SLOT identifier Field type <Eqpt::Ng2OntPortId> </pre>	

Resource Identifier	Type	Description
	- the NGPON2 ONT PORT identifier Field type <Eqpt::LLId> - the LLID identifier,range 1 for EPON,range 1-8 for DPOE Possible values: - stacked : stacked vlan identity Field type <Eqpt::UnstackedVlan> - unstacked vlan id Field type <Eqpt::SVlan> - service vlan id Field type <Eqpt::CVlan> - customer vlan id	

29- IGMP Configuration Commands

29.1 IGMP Configuration Command Tree	29-1047
29.2 IGMP Channel Configuration Command	29-1049
29.3 IGMP Channel Permission Package Members Configuration Command	29-1054
29.4 IGMP Channel Preview Package Members Configuration Command	29-1057
29.5 IGMP Package Bitmaps Configuration Command	29-1060
29.6 IGMP System Configuration Command	29-1062
29.7 IGMP System CDR Type Configuration Command	29-1066
29.8 IGMP Vlan System Configuration Command	29-1067
29.9 IGMP Multicast Vlan Translation Command	29-1068
29.10 IGMP Multicast Pon Vlan Translation Command	29-1069
29.11 Igmp Multicast Service Context Configuration Command	29-1070

29.1 IGMP Configuration Command Tree

Description

This chapter gives an overview of nodes that are handled by "IGMP Configuration Commands".

Command Tree

```

----configure
  ----igmp
    ----[no] channel
      - (port)
      - [no] perm-pkg-bitmap
      - [no] max-num-group
      - [no] mode
      X (cac-disable)
      X (ip-anti-spoof-dis)
      - [no] igmp-version
      - [no] forking
      - [no] lt-ont-signaling
      - [no] mc-pbit-value
      - [no] mcast-vlan-id
      - [no] mc-vlan-xlate
      - [no] mcast-svc-context
      - [no] max-msg-rate
      ----[no] fullview-packages
        - (package)
      ----[no] preview-packages
        - (package)
    ----package
      - (index)
      - [no] name
      - [no] template-name
      - [no] template-version
    ----system
      - [no] src-ip-address
      - [no] verify-checksum
      - [no] query-interval
      - [no] max-rsp-time
      - [no] robustness
      - [no] mem-query-int
      - [no] last-memb-cnt
      - [no] last-max-resp-tim
      - [no] host-report-intv
      - [no] start
      - [no] preview-valid
      - [no] cdr-validation
      - [no] cdr-generation
      - [no] except-cdr-rate
      - [no] cdr-export
      - [no] cdr-file-aging
      - [no] cdr-polling
      - [no] user-igmp-version
  
```

- [no] netw-igmp-version
- [no] v3-max-num-rec
- [no] forking
- [no] lt-ont-signaling
- [no] vlan-selection
- [no] disc-lwr-version
- [no] uncfg-mcast-supp
- cdr-type**
 - [no] periodic
 - [no] period
 - [no] attempt-max-pview
 - [no] attempt-blackout
 - [no] attempt-no-perm
- [no] vlan**
 - **(vlan-id)**
 - netw-igmp-version
 - [no] v3-max-num-rec
- [no] mc-vlan-xlate**
 - **(nwvlan)**
 - ponvlan
- [no] mc-pon-vlan-xlate**
 - **(pon)**
 - **nwvlan**
 - ponvlan
- [no] mcast-svc-context**
 - **(name)**

29.2 IGMP Channel Configuration Command

Command Description

This command allows the operator to create and configure the IGMP channel parameters.

User Level

The command can be accessed by operators with igmp privileges, and executed by operators with igmp privileges.

Command Syntax

The command has the following syntax:

```
> configure igmp ( no channel (port) ) | ( channel (port) [ no perm-pkg-bitmap | perm-pkg-bitmap
<Igmp::PermPkgBitMap> ] [ no max-num-group | max-num-group <Igmp::ChannelMaxNumGroup> ] [ no mode |
mode <Igmp::ChannelProtocolMode> ] [ (cac-disable) ] [ (ip-anti-spoof-dis) ] [ no igmp-version | igmp-version
<Igmp::UserItfVersion> ] [ no forking | forking <Igmp::ForkingStatus> ] [ no lt-ont-signaling | lt-ont-signaling
<Igmp::ChannelLtOntSignaling> ] [ no mc-pbit-value | mc-pbit-value <Igmp::McPbitValue> ] [ no mcast-vlan-id |
mcast-vlan-id <Igmp::ProtocolMcastVlan> ] [ no mc-vlan-xlate | mc-vlan-xlate <Igmp::mcVlanXlateAdmin> ] [ no
mcast-svc-context | mcast-svc-context <Igmp::McastSvcCtxtName> ] [ no max-msg-rate | max-msg-rate
<Igmp::ChannelMaxMsgRate> ] )
```

Command Parameters

Table 29.2-1 "IGMP Channel Configuration Command" Resource Parameters

Resource Identifier	Type	Description
(port)	Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::VpiId> : <Eqpt::VciId> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::VpiId> : <Eqpt::VciId> : <Eqpt::UnstackedVlan> vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::UnstackedVlan> vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::VpiId> : <Eqpt::VciId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> / <Eqpt::OntPortId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> / <Eqpt::OntPortId> : <Eqpt::UnstackedVlan>	identification of the port, vlanport or virtual channel

Resource Identifier	Type	Description
	<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> / <Eqpt::OntPortId> vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / voip : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / vuni : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / voip : <Eqpt::UnstackedVlan> vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / vuni : <Eqpt::UnstackedVlan> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / voip <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / vuni vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::LLId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::LLId> : <Eqpt::UnstackedVlan> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::LLId> vlan:ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / <Eqpt::Ng2OntSlotId> / <Eqpt::Ng2OntPortId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan:ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / <Eqpt::Ng2OntSlotId> / <Eqpt::Ng2OntPortId> : <Eqpt::UnstackedVlan>) Possible values: - vlan : vlan port - vlan:ng2 : ngpon2 vlan port Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number Field type <Eqpt::VpiId> - atm VPI Field type <Eqpt::VcId> - atm VCI Field type <Eqpt::PonId> - the PON identifier Field type <Eqpt::ChannelGroupId> - the channel group identifier Field type <Eqpt::SubChannelGroupId> - the subchannel group identifier Field type <Eqpt::Ng2OntId>	

Resource Identifier	Type	Description
	- the NG2 ONT identifier Field type <Eqpt::OntId> - the ONT identifier Possible values: - voip : virtual uni identifier obsolete alternative replaced by vuni - vuni : virtual uni identifier Possible values: - vuni : virtual NGPON2 uni identifier Field type <Eqpt::OntSlotId> - the ONT SLOT identifier Field type <Eqpt::OntPortId> - the ONT PORT identifier Field type <Eqpt::Ng2OntSlotId> - the NGPON2 ONT SLOT identifier Field type <Eqpt::Ng2OntPortId> - the NGPON2 ONT PORT identifier Field type <Eqpt::LLId> - the LLID identifier,range 1 for EPON,range 1-8 for DPOE Possible values: - stacked : stacked vlan identity Field type <Eqpt::UnstackedVlan> - unstacked vlan id Field type <Eqpt::SVlan> - service vlan id Field type <Eqpt::CVlan> - customer vlan id	

Table 29.2-2 "IGMP Channel Configuration Command" Command Parameters

[illegible]

29 IGMP Configuration Commands

Parameter	Type	Description
	- range: [0...2048]	refer to the product information document for detail.
[no] mode	Parameter type: <Igmp::ChannelProtocolMode> Format: (ipoe pppoe) Possible values: - ipoe : IPoE mode - pppoe : PPPoE mode	<i>optional parameter with default value: "ipoe"</i> protocol mode (ipoe or pppoe)
(cac-disable)	Format: (cac-disable cac) Possible values: - cac-disable : disables bandwidth CAC for conf. streams,default=enable - cac : enables bandwidth CAC for conf. streams,default=enable	<i>obsolete parameter that will be ignored</i> bandwidth CAC for pre-configured multicast streams
(ip-anti-spoof-dis)	Format: (ip-anti-spoof-dis ip-anti-spoof) Possible values: - ip-anti-spoof-dis : disables IP@ anti-spoofing,default=enable - ip-anti-spoof : enables IP@ anti-spoofing,default=enable	<i>obsolete parameter that will be ignored</i> enables IP@ anti-spoofing on this user-interface
[no] igmp-version	Parameter type: <Igmp::UserIrfVersion> Format: (system-inherited 2 3) Possible values: - system-inherited : inherits GMQs to user version from the system level - 2 : IGMPV2 GMQs - 3 : IGMPV3 GMQs	<i>optional parameter with default value: "system-inherited"</i> version of the IGMP protocol
[no] forking	Parameter type: <Igmp::ForkingStatus> Format: (system-inherited enable disable) Possible values: - system-inherited : inherits forking status from the system level - enable : enable IGMP forking - disable : disable IGMP forking	<i>optional parameter with default value: "system-inherited"</i> forking status of the IGMP protocol
[no] lt-ont-signaling	Parameter type: <Igmp::ChannelLtOntSignaling> Format: (enabled disabled inherited) Possible values: - enabled : lt to ont signaling is enabled - disabled : lt to ont signaling is disabled - inherited : inherits lt to ont signaling from the system level	<i>optional parameter with default value: "inherited"</i> <i>The parameter is not visible during modification.</i> lt to ont signaling parameter
[no] mc-pbit-value	Parameter type: <Igmp::McPbitValue> Format: - default P-bit value to be used by the ONT on the UNI-side for downstream multicast traffic towards subscribers	<i>optional parameter with default value: 8</i> default P-bit value to be used by the ONT on the UNI-side for

Parameter	Type	Description
	- range: [0...8]	downstream multicast traffic towards subscribers
[no] mcast-vlan-id	Parameter type: <Igmp::ProtocolMcastVlan> Format: - vlan selection value - range: [0...4093]	<i>optional parameter with default value: 0</i> vlan selection for multicast channel
[no] mc-vlan-xlate	Parameter type: <Igmp::mcVlanXlateAdmin> Format: (enabled disabled) Possible values: - enabled : allow mcast vlan translation - disabled : disallow mcast vlan translation	<i>optional parameter with default value: "disabled"</i> to enable or disable mcast vlan translation
[no] mcast-svc-context	Parameter type: <Igmp::McastSvcCtxtName> Format: (name : <Qos::IgnoredQosProfileName> default) Possible values: - default : Default profile is associated - name : Name of the multicast service context profile Data driven field type Possible values are depending on the actual configuration and software. The currently allowed values can be shown with online-help.	<i>optional parameter with default value: "default"</i> Multicast Service Context Name
[no] max-msg-rate	Parameter type: <Igmp::ChannelMaxMsgRate> Format: - Maximum number of Upstream IGMP messages that can be received on this IGMP channel - unit: messages/second - range: [0...256]	<i>optional parameter with default value: 0</i> Default value 0 indicates that the value is inherited from what is set in the system wide setting using command - configure qos dsl-ctrl-pkt-policer sustained-rate [1...64] burst-size [1...128]

29.3 IGMP Channel Permission Package Members Configuration Command

Command Description

This command allows the operator to configure the IGMP channel permission package members.

User Level

The command can be accessed by operators with igmp privileges, and executed by operators with igmp privileges.

Command Syntax

The command has the following syntax:

```
> configure igmp channel (port) ( no fullview-packages (package) ) | ( fullview-packages (package) )
```

Command Parameters

Table 29.3-1 "IGMP Channel Permission Package Members Configuration Command" Resource Parameters

Resource Identifier	Type	Description
(port)	Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::VpiId> : <Eqpt::VciId> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::VpiId> : <Eqpt::VciId> : <Eqpt::UnstackedVlan> vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::UnstackedVlan> vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::VpiId> : <Eqpt::VciId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> / <Eqpt::OntPortId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> / <Eqpt::OntPortId> : <Eqpt::UnstackedVlan> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> / <Eqpt::OntPortId>	identification of the port, vlanport or virtual channel

Resource Identifier	Type	Description
	<pre> vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / voip : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / vuni : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / voip : <Eqpt::UnstackedVlan> vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / vuni : <Eqpt::UnstackedVlan> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / voip <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / vuni vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::LLId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::LLId> : <Eqpt::UnstackedVlan> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::LLId> vlan:ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / <Eqpt::Ng2OntSlotId> / <Eqpt::Ng2OntPortId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan:ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / <Eqpt::Ng2OntSlotId> / <Eqpt::Ng2OntPortId> : <Eqpt::UnstackedVlan>) Possible values: - vlan : vlan port - vlan:ng2 : ngpon2 vlan port Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number Field type <Eqpt::VpiId> - atm VPI Field type <Eqpt::VciId> - atm VCI Field type <Eqpt::PonId> - the PON identifier Field type <Eqpt::ChannelGroupId> - the channel group identifier Field type <Eqpt::SubChannelGroupId> - the subchannel group identifier Field type <Eqpt::Ng2OntId> - the NG2 ONT identifier Field type <Eqpt::OntId> - the ONT identifier </pre>	

29 IGMP Configuration Commands

Resource Identifier	Type	Description
	Possible values: - voip : virtual uni identifier obsolete alternative replaced by vuni - vuni : virtual uni identifier Possible values: - vuni : virtual NGPON2 uni identifier Field type <Eqpt::OntSlotId> - the ONT SLOT identifier Field type <Eqpt::OntPortId> - the ONT PORT identifier Field type <Eqpt::Ng2OntSlotId> - the NGPON2 ONT SLOT identifier Field type <Eqpt::Ng2OntPortId> - the NGPON2 ONT PORT identifier Field type <Eqpt::LLId> - the LLID identifier, range 1 for EPON, range 1-8 for DPOE Possible values: - stacked : stacked vlan identity Field type <Eqpt::UnstackedVlan> - unstacked vlan id Field type <Eqpt::SVlan> - service vlan id Field type <Eqpt::CVlan> - customer vlan id	
(package)	Format: - the package number - range: [1...1024]	package member

29.4 IGMP Channel Preview Package Members Configuration Command

Command Description

This command allows the operator to configure the IGMP channel preview package members.

User Level

The command can be accessed by operators with igmp privileges, and executed by operators with igmp privileges.

Command Syntax

The command has the following syntax:

```
> configure igmp channel (port) ( no preview-packages (package) ) | ( preview-packages (package) )
```

Command Parameters

Table 29.4-1 "IGMP Channel Preview Package Members Configuration Command" Resource Parameters

Resource Identifier	Type	Description
(port)	Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::VpiId> : <Eqpt::VciId> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::VpiId> : <Eqpt::VciId> : <Eqpt::UnstackedVlan> vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::UnstackedVlan> vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::VpiId> : <Eqpt::VciId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> / <Eqpt::OntPortId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> / <Eqpt::OntPortId> : <Eqpt::UnstackedVlan> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> / <Eqpt::OntPortId>	identification of the port, vlanport or virtual channel

Resource Identifier	Type	Description
	<pre> vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / voip : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / vuni : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / voip : <Eqpt::UnstackedVlan> vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / vuni : <Eqpt::UnstackedVlan> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / voip <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / vuni vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::LLId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::LLId> : <Eqpt::UnstackedVlan> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::LLId> vlan:ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / <Eqpt::Ng2OntSlotId> / <Eqpt::Ng2OntPortId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan:ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / <Eqpt::Ng2OntSlotId> / <Eqpt::Ng2OntPortId> : <Eqpt::UnstackedVlan>) Possible values: - vlan : vlan port - vlan:ng2 : ngpon2 vlan port Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number Field type <Eqpt::VpiId> - atm VPI Field type <Eqpt::VciId> - atm VCI Field type <Eqpt::PonId> - the PON identifier Field type <Eqpt::ChannelGroupId> - the channel group identifier Field type <Eqpt::SubChannelGroupId> - the subchannel group identifier Field type <Eqpt::Ng2OntId> - the NG2 ONT identifier Field type <Eqpt::OntId> - the ONT identifier </pre>	

Resource Identifier	Type	Description
	Possible values: - voip : virtual uni identifier obsolete alternative replaced by vuni - vuni : virtual uni identifier Possible values: - vuni : virtual NGPON2 uni identifier Field type <Eqpt::OntSlotId> - the ONT SLOT identifier Field type <Eqpt::OntPortId> - the ONT PORT identifier Field type <Eqpt::Ng2OntSlotId> - the NGPON2 ONT SLOT identifier Field type <Eqpt::Ng2OntPortId> - the NGPON2 ONT PORT identifier Field type <Eqpt::LLId> - the LLID identifier, range 1 for EPON, range 1-8 for DPOE Possible values: - stacked : stacked vlan identity Field type <Eqpt::UnstackedVlan> - unstacked vlan id Field type <Eqpt::SVlan> - service vlan id Field type <Eqpt::CVlan> - customer vlan id	
(package)	Format: - the package number - range: [1...1024]	package member

29.5 IGMP Package Bitmaps Configuration

Command

Command Description

This command allows the operator to configure IGMP package bitmaps. The package is intended primarily for use by a network/element manager, such as an AMS, to support multiple sets of packages in different regions.

A package is a group of zero or more multicast sources that share a common access permission. Grouping the source channels into one or more packages provides flexibility for the service provider to deliver different levels of services to the end users; for example, "Basic Package", "Middle-Tier Package", and "Premium Package".

NOTE: There is no requirement to configure the package. If the package is modified, there is no effect on the multicast source.

User Level

The command can be accessed by operators with `igmp` privileges, and executed by operators with `igmp` privileges.

Command Syntax

The command has the following syntax:

```
> configure igmp package (index) [ no name | name <Igmp::igmpPackageName> ] [ no template-name |
template-name <Igmp::igmpPackageTemplateName> ] [ no template-version | template-version
<Igmp::igmpPackageTemplateVersion> ]
```

Command Parameters

Table 29.5-1 "IGMP Package Bitmaps Configuration Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of the package - range: [1...1024]	index of the package

Table 29.5-2 "IGMP Package Bitmaps Configuration Command" Command Parameters

Parameter	Type	Description
[no] name	Parameter type: <Igmp::igmpPackageName> Format: - a printable string - length: x<=32	optional parameter with default value: "" name of the package
[no] template-name	Parameter type: <Igmp::igmpPackageTemplateName> Format: - a printable string - length: x<=32	optional parameter with default value: "" name of the service template containing this pkg
[no] template-version	Parameter type: <Igmp::igmpPackageTemplateVersion> Format: - version of the service template containing this package	optional parameter with default value: 0 version of the service template

Parameter	Type	Description
	- range: [0...65535]	containing this pkg

29.6 IGMP System Configuration Command

Command Description

This command allows the operator to configure the IGMP parameters that are globally applicable to the Node.

When Configure igmp system uncfg-mcast-supp = asmandssm this works properly if only one SSM/ASM channel per multicast destination address per vlan is distributed in the network, and if the end-users only send IGMPv3 joins for source addresses matching these distributed channels. These restrictions should be respected, else it is recommended to permit only configured SSM, i.e. Configure igmp system uncfg-mcast-supp = legacy.

If Uncfg-mcast-supp goes from AsmandSsm to Legacy, there is a transient period during a few GMI periods before full Legacy behaviour is achieved

User Level

The command can be accessed by operators with igmp privileges, and executed by operators with igmp privileges.

Command Syntax

The command has the following syntax:

```
> configure igmp system [ no src-ip-address | src-ip-address <Ip::V4Address> ] [ [ no ] verify-checksum ] [ no
query-interval | query-interval <Igmp::SystemQueryInterval> ] [ no max-rsp-time | max-rsp-time
<Igmp::SystemQueryMaxResponseTime> ] [ no robustness | robustness <Igmp::SystemRobustness> ] [ no
mem-query-int | mem-query-int <Igmp::MembQueryIntvl> ] [ no last-memb-cnt | last-memb-cnt
<Igmp::MembQueryCount> ] [ no last-max-rsp-tim | last-max-rsp-tim <Igmp::SystemLastMembMaxRespTime>
] [ no host-report-intv | host-report-intv <Igmp::SystemUnsolicitedReportIntvl> ] [ [ no ] start ] [ no preview-valid |
preview-valid <Igmp::SystemPrevalidIntval> ] [ no cdr-validation | cdr-validation
<Igmp::SystemPrecdrvalidIntval> ] [ [ no ] cdr-generation ] [ no except-cdr-rate | except-cdr-rate
<Igmp::CDRGenerationForSingles> ] [ no cdr-export | cdr-export <Igmp::CDRGenerationMethod> ] [ no
cdr-file-aging | cdr-file-aging <Igmp::CDRFileAgingTime> ] [ no cdr-polling | cdr-polling
<Igmp::CDRSystemPollingCycle> ] [ no user-igmp-version | user-igmp-version
<Igmp::igmpSystemGMQToUserSideVersion> ] [ no netw-igmp-version | netw-igmp-version
<Igmp::V3ProcessingAdminStatus> ] [ no v3-max-num-rec | v3-max-num-rec
<Igmp::V3MaxNumRecordsReport> ] [ [ no ] forking ] [ [ no ] lt-ont-signaling ] [ [ no ] vlan-selection ] [ [ no ]
disc-lwr-version ] [ no uncfg-mcast-supp | uncfg-mcast-supp <Igmp::igmpSystemUncfgMcastSupport> ]
```

Command Parameters

Table 29.6-2 "IGMP System Configuration Command" Command Parameters

Parameter	Type	Description
[no] src-ip-address	Parameter type: <Ip::V4Address> Format: - IPv4-address	optional parameter with default value: "0.0.0.0" source ip addr which is tx in every mcast IP datagram
[no] verify-checksum	Parameter type: boolean	optional parameter verification performed on Rx mcast frame
[no] query-interval	Parameter type: <Igmp::SystemQueryInterval>	optional parameter with default

Parameter	Type	Description
	Format: - interval at which general membership queries transmitted - unit: sec - range: [2...3175]	<i>value: 125</i> interval at which general membership queries transmitted
[no] max-rsp-time	Parameter type: <Igmp::SystemQueryMaxResponseTime> Format: - max query response time advertised in queries - unit: 1/10 sec - range: [1...31744]	<i>optional parameter with default value: 100</i> max query response time advertised in queries 1/10 sec
[no] robustness	Parameter type: <Igmp::SystemRobustness> Format: - tuning for the expected packet loss on a subnet - range: [1...10]	<i>optional parameter with default value: 2</i> expected pkt loss on subnet
[no] mem-query-int	Parameter type: <Igmp::MembQueryIntvl> Format: - spacing between GSQs (group-specific queries) - unit: 1/10 sec - range: [2...31744]	<i>optional parameter with default value: 10</i> minimum interval between group-specific queries
[no] last-memb-cnt	Parameter type: <Igmp::MembQueryCount> Format: - number of GSQs (group-specific queries) to be sent - range: [1...10]	<i>optional parameter with default value: 2</i> number of GSQs (group-specific queries) to be sent
[no] last-max-rsp-tim	Parameter type: <Igmp::SystemLastMembMaxRespTime> Format: - allows shorter max response time - unit: 1/10 sec - range: [1...31744]	<i>optional parameter with default value: 2</i> allows shorter max response time
[no] host-report-intv	Parameter type: <Igmp::SystemUnsolicitedReportIntvl> Format: - interval of repetitions of host's report of grp membership - unit: 1/10 sec - range: [1...255]	<i>optional parameter with default value: 10</i> interval of repetitions of host's report of grp membership
[no] start	Parameter type: boolean	<i>optional parameter</i> start Mcast app module
[no] preview-valid	Parameter type: <Igmp::SystemPrevalidIntval> Format: - time interval that confirm the preview session is valid - unit: sec - range: [1...120]	<i>optional parameter with default value: 8</i> time interval that confirm the preview session is valid
[no] cdr-validation	Parameter type: <Igmp::SystemPrecdrvalidIntval> Format: (none <Igmp::SystemPrecdrvalidIntval>) Possible values: - none : CDR generation valid immediately Field type <Igmp::SystemPrecdrvalidIntval> - minimum session time for generating a CDR - unit: sec - range: [0...120]	<i>optional parameter with default value: 2</i> minimum session time for generating a CDR
[no] cdr-generation	Parameter type: boolean	<i>optional parameter</i> start CDR generation in the system
[no] except-cdr-rate	Parameter type: <Igmp::CDRGenerationForSingles> Format: - limit the generation of CDR records - unit: min - range: [1...30]	<i>optional parameter with default value: 3</i> limit the generation of the CDR records

29 IGMP Configuration Commands

Parameter	Type	Description
[no] cdr-export	Parameter type: <Igmpp::CDRGenerationMethod> Format: (local-file-storage remote-logging) Possible values: - local-file-storage : method the cdr generated and forwarded - remote-logging : remote logging method	<i>optional parameter with default value: "local-file-storage"</i> the method the cdr is to be generated and forwarded
[no] cdr-file-aging	Parameter type: <Igmpp::CDRFileAgingTime> Format: - configure the CDR file aging time - unit: hour - range: [4...24]	<i>optional parameter with default value: 8</i> configure the CDR file aging time
[no] cdr-polling	Parameter type: <Igmpp::CDRSystemPollingCycle> Format: - configure the polling period for the CDR records, in multiples of 60 - unit: sec - range: [60...900]	<i>optional parameter with default value: 180</i> configure the polling period for the CDR records
[no] user-igmp-version	Parameter type: <Igmpp::igmpSystemGMQToUserSideVersion> Format: (2 3) Possible values: - 2 : IGMPv2 GMQs - 3 : IGMPv3 GMQs	<i>optional parameter with default value: "3"</i> version of the IGMP protocol
[no] netw-igmp-version	Parameter type: <Igmpp::V3ProcessingAdminStatus> Format: (2 3) Possible values: - 2 : IGMP version2 - 3 : IGMP version3	<i>optional parameter with default value: "3"</i> version for IGMP packet to receive/forward to n/w side
[no] v3-max-num-rec	Parameter type: <Igmpp::V3MaxNumRecordsReport> Format: - max number of records in an IGMPv3 membership report - range: [0...10]	<i>optional parameter with default value: 3</i> max num of group records in one IGMPv3 or MLDv2 report (2 exp N)
[no] forking	Parameter type: boolean	<i>optional parameter</i> enable IGMP forking in the system level
[no] lt-ont-signaling	Parameter type: boolean	<i>optional parameter</i> enables lt to ont signaling at system level
[no] vlan-selection	Parameter type: boolean	<i>optional parameter</i> enable vlan selection
[no] disc-lwr-version	Parameter type: boolean	<i>optional parameter</i> discard lower version packets
[no] uncfg-mcast-supp	Parameter type: <Igmpp::igmpSystemUncfgMcastSupport> Format: (legacy asmandssm) Possible values: - legacy : enable un-configured SSM and ASM support for GPON LTs and un-configured ASM support alone for DSL LTs - asmandssm : enable unconfigured SSM and ASM support	<i>optional parameter with default value: "legacy"</i> enable un-configured SSM/ASM support for GPON/DSL LT cards

Parameter	Type	Description
	for GPON and DSL LT cards	

29.7 IGMP System CDR Type Configuration

Command

Command Description

This command allows the operator to configure the IGMP system Call Detail Record

User Level

The command can be accessed by operators with igmp privileges, and executed by operators with igmp privileges.

Command Syntax

The command has the following syntax:

```
> configure igmp system cdr-type [ [ no ] periodic ] [ no period | period <Igmp::IntermGenCDRPeriod> ] [ [ no ] attempt-max-pview ] [ [ no ] attempt-blackout ] [ [ no ] attempt-no-perm ]
```

Command Parameters

Table 29.7-2 "IGMP System CDR Type Configuration Command" Command Parameters

Parameter	Type	Description
[no] periodic	Parameter type: boolean	<i>optional parameter</i> interim CDR records generated for fullview/preview
[no] period	Parameter type: <Igmp::IntermGenCDRPeriod> Format: - intermediate CDR generation period, in multiples of 5 - unit: min - range: [15...60]	<i>optional parameter with default value: 15</i> intermediate CDR generation period
[no] attempt-max-pview	Parameter type: boolean	<i>optional parameter</i> CDR generated when max nbr preview exceeded is true
[no] attempt-blackout	Parameter type: boolean	<i>optional parameter</i> CDR generated allowed when blackout period is active
[no] attempt-no-perm	Parameter type: boolean	<i>optional parameter</i> CDR generated to join a mcast with no access rights

29.8 IGMP Vlan System Configuration Command

Command Description

This command allows the operator to configure the IGMP parameters on a per Vlan basis.

User Level

The command can be accessed by operators with igmp privileges, and executed by operators with igmp privileges.

Command Syntax

The command has the following syntax:

```
> configure igmp ( no vlan (vlan-id) ) | ( vlan (vlan-id) netw-igmp-version <Igmp::VlanV3ProcessStatus> [ no
v3-max-num-rec | v3-max-num-rec <Igmp::V3MaxNumRecordReport> ] )
```

Command Parameters

Table 29.8-1 "IGMP Vlan System Configuration Command" Resource Parameters

Resource Identifier	Type	Description
(vlan-id)	Format: - vlan index - range: [1...4093]	index of the system vlan

Table 29.8-2 "IGMP Vlan System Configuration Command" Command Parameters

Parameter	Type	Description
netw-igmp-version	Parameter type: <Igmp::VlanV3ProcessStatus> Format: (2 3) Possible values: - 2 : IGMP version2 - 3 : IGMP version3	<i>mandatory parameter</i> IGMP version of the protocol
[no] v3-max-num-rec	Parameter type: <Igmp::V3MaxNumRecordReport> Format: - max num of group records in one IGMPv3 or MLDv2 report (2 exp N) - range: [0...10]	<i>optional parameter with default value: 3</i> max num of group records in one IGMPv3 report (2 exp N)

29.9 IGMP Multicast Vlan Translation Command

Command Description

This command allows the operator configure source-pon vlan translation.

User Level

The command can be accessed by operators with igmp privileges, and executed by operators with igmp privileges.

Command Syntax

The command has the following syntax:

```
> configure igmp ( no mc-vlan-xlate (nwvlan) ) | ( mc-vlan-xlate (nwvlan) ponvlan <Igmp::mcPonVlanId> )
```

Command Parameters

Table 29.9-1 "IGMP Multicast Vlan Translation Command" Resource Parameters

Resource Identifier	Type	Description
(nwvlan)	Format: - the multicast vlan id - range: [2...4093]	identification of the network-side virtual lan

Table 29.9-2 "IGMP Multicast Vlan Translation Command" Command Parameters

Parameter	Type	Description
ponvlan	Parameter type: <Igmp::mcPonVlanId> Format: - vlan index - range: [1...4093]	<i>mandatory parameter</i> identification of the pon-side virtual lan

29.10 IGMP Multicast Pon Vlan Translation Command

Command Description

This command allows the operator configure source-pon vlan translation on pon port.

User Level

The command can be accessed by operators with igmp privileges, and executed by operators with igmp privileges.

Command Syntax

The command has the following syntax:

```
> configure igmp ( no mc-pon-vlan-xlate (pon) nwvlan <Igmp::mcSrcVlanId> ) | ( mc-pon-vlan-xlate (pon) nwvlan <Igmp::mcSrcVlanId> ponvlan <Igmp::mcPonVlanId> )
```

Command Parameters

Table 29.10-1 "IGMP Multicast Pon Vlan Translation Command" Resource Parameters

Resource Identifier	Type	Description
(pon)	Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier	identification of the pon interface
nwvlan	Parameter type: <Igmp::mcSrcVlanId> Format: - the multicast vlan id - range: [2...4093]	identification of the network-side virtual lan

Table 29.10-2 "IGMP Multicast Pon Vlan Translation Command" Command Parameters

Parameter	Type	Description
ponvlan	Parameter type: <Igmp::mcPonVlanId> Format: - vlan index - range: [1...4093]	<i>mandatory parameter</i> identification of the pon-side virtual lan

29.11 Igmp Multicast Service Context Configuration Command

Command Description

This command allows the operator to configure multicast service context

User Level

The command can be accessed by operators with igmp privileges, and executed by operators with igmp privileges.

Command Syntax

The command has the following syntax:

> configure igmp (no mcast-svc-context (name)) | (mcast-svc-context (name))

Command Parameters

Table 29.11-1 "Igmp Multicast Service Context Configuration Command" Resource Parameters

Resource Identifier	Type	Description
(name)	Format: - a profile name - range: [a-zA-Z0-9-_.] - length: 1<=x<=32	A unique profile name for the service context

30- Multicast Configuration Commands

30.1 Multicast Configuration Command Tree	30-1072
30.2 Multicast General Group Configuration Command	30-1074
30.3 General Multicast Package Members Configuration Command	30-1076
30.4 Multicast Capacity Configuration Command	30-1077
30.5 Multicast Channel Configuration Command	30-1078
30.6 Multicast Channel Package Members Configuration Command	30-1080
30.7 Multicast Channel Configuration Command	30-1081
30.8 Multicast Channel Package Members Configuration Command	30-1084
30.9 Multicast Ipv6 Channel Configuration Command	30-1085
30.10 Multicast Channel Package Members Configuration Command	30-1088
30.11 Multicast Monitoring Source Configuration Command	30-1089
30.12 Multicast Monitoring Channel Configuration Command	30-1090
30.13 Multicast Static Branch Configuration Command	30-1091

30.1 Multicast Configuration Command Tree

Description

This chapter gives an overview of nodes that are handled by "Multicast Configuration Commands".

Command Tree

```
----configure
  ----mcast
    ----general
      - [no] fast-change
      - [no] pkg-memb-bitmap
      - [no] max-bitrate
      - [no] mean-bit-rate
      ----[no] package-member
        - (package)
    ----capacity
      - [no] max-num-group
      - [no] max-num-uncfg
      - [no] cfg-res-time
      - [no] uncfg-res-time
    ----X [no] channel
      - (grp-ip-addr)
      - src-ip-addr
      - [no] dis-fast-change
      - [no] pkg-memb-bitmap
      - [no] name
      - [no] guaranteed-serv
      - [no] peak-bit-rate
      - vlan-id
      - [no] service-name
      - [no] preview-duration
      - [no] preview-number
      - [no] preview-blackout
      ----[no] packagemember
        - (package)
    ----[no] chn
      - (grp-ip-addr)
      - src-ip-addr
      - vlan-id
      - [no] end-ip-addr
      - [no] mcast-svc-context
      - [no] dis-fast-change
      - [no] pkg-memb-bitmap
      - [no] name
      - [no] guaranteed-serv
      - [no] peak-bit-rate
      - [no] service-name
      - [no] preview-duration
      - [no] preview-number
      - [no] preview-blackout
      ----[no] packagemember
```

```

- (package)
----[no] ipv6-chn
- (grp-ipv6-addr)
- src-ipv6-addr
- vlan-id
- [no] end-ipv6-addr
- [no] mcast-svc-context
- [no] dis-fast-change
- [no] pkg-mem-bitmap
- [no] name
- [no] guaranteed-serv
- [no] peak-bit-rate
- [no] service-name
- [no] preview-duration
- [no] preview-number
- [no] preview-blackout
----[no] packagemember
- (package)
----monitor
----[no] src
- (grp-ip-addr)
- src-ip-addr
- [no] loss-duration
- [no] loss-thresh-alert
----[no] chn
- (grp-ip-addr)
- src-ip-addr
- vlan-id
- [no] loss-duration
- [no] loss-thresh-alert
----static
----[no] branch
- (grp-ip-addr)
- src-ip-addr
- port

```

30.2 Multicast General Group Configuration Command

Command Description

This command allows the operator to configure general multicast parameters.

User Level

The command can be accessed by operators with igmp privileges, and executed by operators with igmp privileges.

Command Syntax

The command has the following syntax:

```
> configure mcast general [ [ no ] fast-change ] [ no pkg-memb-bitmap | pkg-memb-bitmap
<Igmp::PkgMemBitMap> ] [ no max-bitrate | max-bitrate <Igmp::GeneralMcastMaxBitRate> ] [ no mean-bit-rate |
mean-bit-rate <Igmp::GeneralMcastMeanBitRate> ]
```

Command Parameters

Table 30.2-2 "Multicast General Group Configuration Command" Command Parameters

Parameter	Type	Description
[no] fast-change	Parameter type: boolean	<i>optional parameter</i> enable fast channel change
[no] pkg-memb-bitmap	Parameter type: <Igmpp::PkgMemBitMap> Format: - a binary string - length: 128	<i>optional parameter with default value:</i> "ff : ff :" package(s) a class D address belongs
[no] max-bitrate	Parameter type: <Igmpp::GeneralMcastMaxBitRate> Format: - reasonable max bitrate in ATM level for upstream - unit: kbps - range: [0...100000]	<i>optional parameter with default value:</i> 2500 reasonable downstream max bitrate in ATM level

Parameter	Type	Description
[no] mean-bit-rate	Parameter type: <Icmp::GeneralMcastMeanBitRate> Format: - reasonable mean bitrate in ATM level for upstream - unit: kbps - range: [0...100000]	<i>optional parameter with default value: 2500</i> reasonable downstream mean bitrate in ATM level

30.3 General Multicast Package Members Configuration Command

Command Description

This command allows the operator to configure the IGMP general multicast package members.

User Level

The command can be accessed by operators with igmp privileges, and executed by operators with igmp privileges.

Command Syntax

The command has the following syntax:

> configure mcast general (no package-member (package)) | (package-member (package))

Command Parameters

Table 30.3-1 "General Multicast Package Members Configuration Command" Resource Parameters

Resource Identifier	Type	Description
(package)	Format: - the package number - range: [1...1024]	package member

30.4 Multicast Capacity Configuration Command

Command Description

This command allows the operator to configure the multicast capacity parameters.

User Level

The command can be accessed by operators with igmp privileges, and executed by operators with igmp privileges.

Command Syntax

The command has the following syntax:

```
> configure mcast capacity [ no max-num-group | max-num-group <Igmp::McastCapacityMaxNumGroup> ] [ no
max-num-uncfg | max-num-uncfg <Igmp::McastCapacityMaxNumUnCfg> ] [ no cfg-res-time | cfg-res-time
<Igmp::multicastCapacityCfgSourceReserveTime> ] [ no uncfg-res-time | uncfg-res-time
<Igmp::multicastCapacityUnCfgSourceReserveTime> ]
```

Command Parameters

Table 30.4-2 "Multicast Capacity Configuration Command" Command Parameters

Parameter	Type	Description
[no] max-num-group	Parameter type: <Igmp::McastCapacityMaxNumGroup> Format: - no of groups the system can support in enough bandwidth (actual value depends on card capacity) - range: [0...2048]	<i>optional parameter with default value: 1024</i> max number of groups the system (per LT) supports in enough bandwidth
[no] max-num-uncfg	Parameter type: <Igmp::McastCapacityMaxNumUnCfg> Format: - no of uncfg grps,system can support in enough bandwidth (actual value depends on card capacity) - range: [0...2048]	<i>optional parameter with default value: 64</i> max number of uncfg groups the system (per LT) supports in enough bandwidth
[no] cfg-res-time	Parameter type: <Igmp::multicastCapacityCfgSourceReserveTime> Format: - time to reserve - unit: sec - range: [0...2147483647]	<i>optional parameter with default value: 125</i> time to reserve the unused guaranteed configured groups
[no] uncfg-res-time	Parameter type: <Igmp::multicastCapacityUnCfgSourceReserveTime> Format: - time to reserve - unit: sec - range: [0...2147483647]	<i>optional parameter with default value: 0</i> time to reserve the unused unconfigured groups

30.5 Multicast Channel Configuration Command

Command Description

Obsolete command, replaced by `configure mcast chn`.

This command allows the operator to configure the multicast channel.

Note:Mcast channel can not be deleted when VlanSelection is enabled.

User Level

The command can be accessed by operators with igmp privileges, and executed by operators with igmp privileges.

Command Syntax

The command has the following syntax:

```
> configure mcast ( no channel (grp-ip-addr) src-ip-addr <Ip::V4Address> ) | ( channel (grp-ip-addr) src-ip-addr
<Ip::V4Address> [ [ no ] dis-fast-change ] [ no pkg-mem-bitmap | pkg-mem-bitmap <Igmp::PkgMemBitMap> ] [
no name | name <Igmp::multicastSrcName> ] [ [ no ] guaranteed-serv ] [ no peak-bit-rate | peak-bit-rate
<Igmp::McastSrcEtherPeakBitRate> ] vlan-id <Igmp::McastSrcVLANID> [ no service-name | service-name
<Igmp::multicastSrcServiceName> ] [ no preview-duration | preview-duration
<Igmp::multicastSrcMaxPreDuration> ] [ no preview-number | preview-number
<Igmp::multicastSrcMaxPreNumber> ] [ no preview-blackout | preview-blackout
<Igmp::multicastSrcPreBlackout> ] )
```

Obsolete command, replaced by `configure mcast chn`.

Command Parameters

Table 30.5-1 "Multicast Channel Configuration Command" Resource Parameters

Resource Identifier	Type	Description
(grp-ip-addr)	Format: - multicast-address (range: 224.0.0.3....239.255.255.255, except for 224.0.0.22)	ip address identifying the multicast group
src-ip-addr	Parameter type: <Ip::V4Address> Format: - IPv4-address	ip address of the multicast server originating the multicast channel,value 0.0.0.0 means ASM(any-src-ip-addr),range:0.0.0.0....224.0.0.255

Table 30.5-2 "Multicast Channel Configuration Command" Command Parameters

Parameter	Type	Description
[no] dis-fast-change	Parameter type: boolean	<i>optional parameter</i> disable fast channel change
[no] pkg-mem-bitmap	Parameter type: <Igmpp::PkgMemBitMap> Format: - a binary string - length: 128	<i>optional parameter with default value:</i> "01 : 00 : 00 : 00 : 00 : 00 : : 00 : 00 : 00 : 00 : 00 : 00 : 00 : 00 : 00 : 00 : 00 : 00 : 00 : 00 : 00 : 00 : 00 : 00 :

Parameter	Type	Description
		00 : indicates to which package(s) a mcast channel belongs
[no] name	Parameter type: <Igmp::multicastSrcName> Format: - a printable string - length: x<=32	<i>optional parameter with default value: ""</i> name of the mcast channel
[no] guaranteed-serv	Parameter type: boolean	<i>optional parameter</i> enable guaranteed service
[no] peak-bit-rate	Parameter type: <Igmp::McastSrcEtherPeakBitRate> Format: - peak bit rate for transmit/downstream traffic - unit: kbps - range: [0...100000]	<i>optional parameter with default value: 2125</i> <i>The parameter is not visible during modification.</i> ethernet peak bit rate for downstream traffic
vlan-id	Parameter type: <Igmp::McastSrcVLANID> Format: - VLAN for this multicast source - range: [1...4093]	<i>mandatory parameter</i> <i>The parameter is not visible during modification.</i> VLAN for this multicast channel
[no] service-name	Parameter type: <Igmp::multicastSrcServiceName> Format: - a printable string - length: x<=32	<i>optional parameter with default value: ""</i> name of service or service provider of the mcast channel
[no] preview-duration	Parameter type: <Igmp::multicastSrcMaxPreDuration> Format: - reasonable max duration for each preview per mcast grp - unit: sec - range: [1...6000]	<i>optional parameter with default value: 180</i> Maximum duration for each preview per multicast channel
[no] preview-number	Parameter type: <Igmp::multicastSrcMaxPreNumber> Format: - valid max no. of previews for each preview per mcast grp - range: [1...100]	<i>optional parameter with default value: 3</i> Max number of previews for each preview per mcast group
[no] preview-blackout	Parameter type: <Igmp::multicastSrcPreBlackout> Format: - valid preview Blackout Duration time of per mcast group - unit: sec - range: [0...7200]	<i>optional parameter with default value: 0</i> Preview Blackout Duration time of per multicast channel

30.6 Multicast Channel Package Members Configuration Command

Command Description

This command allows the operator to configure the multicast channel package members.

A multicast channel can be member of maximum 20 packages or be member of all (1024) packages, any value in between will be rejected.

Using this command packages will be added or removed from/to the list of packages of which the multicast channel is currently a member.

If the multicast channel is member of all packages care must be taken when removing packages, meaning that the command will only be accepted if after execution the multicast channel will be member of 20 packages or less.

User Level

The command can be accessed by operators with igmp privileges, and executed by operators with igmp privileges.

Command Syntax

The command has the following syntax:

```
> configure mcast channel (grp-ip-addr)src-ip-addr <Ip::V4Address> ( no packagemember (package) ) | ( packagemember (package) )
```

Command Parameters

Table 30.6-1 "Multicast Channel Package Members Configuration Command" Resource Parameters

Resource Identifier	Type	Description
(grp-ip-addr)	Format: - multicast-address (range: 224.0.0.3....239.255.255.255, except for 224.0.0.22)	ip address identifying the multicast group
src-ip-addr	Parameter type: <Ip::V4Address> Format: - IPv4-address	ip address of the multicast server originating the multicast channel,value 0.0.0.0 means ASM(any-src-ip-addr),range:0.0.0.0....255.255.255.255
(package)	Format: - the package number - range: [1...1024]	package member

30.7 Multicast Channel Configuration Command

Command Description

This command allows the operator to configure the multicast channel.

Note: Mcast channel can not be deleted when VlanSelection is enabled.

User Level

The command can be accessed by operators with igmp privileges, and executed by operators with igmp privileges.

Command Syntax

The command has the following syntax:

```
> configure mcast ( no chn (grp-ip-addr) src-ip-addr <Ip::V4Address> vlan-id <Igmp::McastChannelVlan> ) | ( chn
(grp-ip-addr) src-ip-addr <Ip::V4Address> vlan-id <Igmp::McastChannelVlan> [ no end-ip-addr | end-ip-addr
<Ip::V4Address> ] [ no mcast-svc-context | mcast-svc-context <Igmp::McastSvcCtxtName> ] [ [ no ]
dis-fast-change ] [ no pkg-mem-bitmap | pkg-mem-bitmap <Igmp::PkgMemBitMap> ] [ no name | name
<Igmp::multicastSrcName> ] [ [ no ] guaranteed-serv ] [ no peak-bit-rate | peak-bit-rate
<Igmp::McastSrcEtherPeakBitRate> ] [ no service-name | service-name <Igmp::multicastSrcServiceName> ] [ no
preview-duration | preview-duration <Igmp::multicastSrcMaxPreDuration> ] [ no preview-number |
preview-number <Igmp::multicastSrcMaxPreNumber> ] [ no preview-blackout | preview-blackout
<Igmp::multicastSrcPreBlackout> ] )
```

Command Parameters

Table 30.7-1 "Multicast Channel Configuration Command" Resource Parameters

Resource Identifier	Type	Description
(grp-ip-addr)	Format: - multicast-address (range: 224.0.0.3....239.255.255.255, except for 224.0.0.22)	ip address identifying the multicast group
src-ip-addr	Parameter type: <Ip::V4Address> Format: - IPv4-address	ip address of the multicast server originating the multicast channel,value 0.0.0.0 means ASM(any-src-ip-addr),range:0.0.0.0....255.255.255.255
vlan-id	Parameter type: <Igmp::McastChannelVlan> Format: - vlan id for multicast - range: [1...4093]	vlanid of the multicast channel which is configured in it

Table 30.7-2 "Multicast Channel Configuration Command" Command Parameters

Parameter	Type	Description
[no] end-ip-addr	Parameter type: <Ip::V4Address> Format: - IPv4-address	optional parameter with default value: "0.0.0.0" The parameter is not visible during modification. end ip address of the range of

30 Multicast Configuration Commands

[illegible]

Parameter	Type	Description
	- range: [1...6000]	
[no] preview-number	Parameter type: <Icmp::multicastSrcMaxPreNumber> Format: - valid max no. of previews for each preview per mcast grp - range: [1...100]	<i>optional parameter with default value: 3</i> Max number of previews for each preview per mcast group
[no] preview-blackout	Parameter type: <Icmp::multicastSrcPreBlackout> Format: - valid preview Blackout Duration time of per mcast group - unit: sec - range: [0...7200]	<i>optional parameter with default value: 0</i> Preview Blackout Duration time of per multicast channel

30.8 Multicast Channel Package Members Configuration Command

Command Description

This command allows the operator to configure the multicast channel package members.

A multicast channel can be member of maximum 20 packages or be member of all (1024) packages, any value in between will be rejected.

Using this command packages will be added or removed from/to the list of packages of which the multicast channel is currently a member.

If the multicast channel is member of all packages care must be taken when removing packages, meaning that the command will only be accepted if after execution the multicast channel will be member of 20 packages or less.

User Level

The command can be accessed by operators with igmp privileges, and executed by operators with igmp privileges.

Command Syntax

The command has the following syntax:

```
> configure mcast chn (grp-ip-addr)src-ip-addr <Ip::V4Address>vlan-id <Igmp::McastChannelVlan> ( no
packagemember (package) ) | ( packagemember (package) )
```

Command Parameters

Table 30.8-1 "Multicast Channel Package Members Configuration Command" Resource Parameters

Resource Identifier	Type	Description
(grp-ip-addr)	Format: - multicast-address (range: 224.0.0.3....239.255.255.255, except for 224.0.0.22)	ip address identifying the multicast group
src-ip-addr	Parameter type: <Ip::V4Address> Format: - IPv4-address	ip address of the multicast server originating the multicast channel,value 0.0.0.0 means ASM(any-src-ip-addr),range:0.0.0.0....255.255.255.255
vlan-id	Parameter type: <Igmp::McastChannelVlan> Format: - vlan id for multicast - range: [1...4093]	vlanid of the multicast channel which is configured in it
(package)	Format: - the package number - range: [1...1024]	package member

30.9 Multicast Ipv6 Channel Configuration Command

Command Description

This command allows the operator to configure the multicast Ipv6 channel.

Note: Mcast channel can not be deleted when VlanSelection is enabled.

User Level

The command can be accessed by operators with igmp privileges, and executed by operators with igmp privileges.

Command Syntax

The command has the following syntax:

```
> configure mcast ( no ipv6-chn (grp-ipv6-addr) src-ipv6-addr <Igmp::IPv6Address> vlan-id
<Igmp::McastChannelVlan> ) | ( ipv6-chn (grp-ipv6-addr) src-ipv6-addr <Igmp::IPv6Address> vlan-id
<Igmp::McastChannelVlan> [ no end-ipv6-addr | end-ipv6-addr <Igmp::MulticastV6Address> ] [ no
mcast-svc-context | mcast-svc-context <Igmp::McastSvcCtxtName> ] [ [ no ] dis-fast-change ] [ no
pkg-mem-bitmap | pkg-mem-bitmap <Igmp::PkgMemBitMap> ] [ no name | name <Igmp::multicastSrcName> ] [ [
no ] guaranteed-serv ] [ no peak-bit-rate | peak-bit-rate <Igmp::McastSrcEtherPeakBitRate> ] [ no service-name |
service-name <Igmp::multicastSrcServiceName> ] [ no preview-duration | preview-duration
<Igmp::multicastSrcMaxPreDuration> ] [ no preview-number | preview-number
<Igmp::multicastSrcMaxPreNumber> ] [ no preview-blackout | preview-blackout
<Igmp::multicastSrcPreBlackout> ] )
```

Command Parameters

Table 30.9-1 "Multicast Ipv6 Channel Configuration Command" Resource Parameters

Resource Identifier	Type	Description
(grp-ipv6-addr)	Format: - multicast ipv6 address (prefix should be FF)	ipv6 address identifying the multicast group
src-ipv6-addr	Parameter type: <Igmp::IPv6Address> Format: - ipv6 address (unicast ipv6 address)	ipv6 address of the multicast server originating the multicast channel,value :: means ASM (any-src-ipv6-addr)
vlan-id	Parameter type: <Igmp::McastChannelVlan> Format: - vlan id for multicast - range: [1...4093]	vlanid of the multicast channel which is configured in it

Table 30.9-2 "Multicast Ipv6 Channel Configuration Command" Command Parameters

Parameter	Type	Description
[no] end-ipv6-addr	Parameter type: <Igmp::MulticastV6Address> Format:	optional parameter with default value: " : "

30 Multicast Configuration Commands

[illegible]

Parameter	Type	Description
	Format: - reasonable max duration for each preview per mcast grp - unit: sec - range: [1...6000]	<i>value: 180</i> Maximum duration for each preview per multicast channel
[no] preview-number	Parameter type: <Icmp::multicastSrcMaxPreNumber> Format: - valid max no. of previews for each preview per mcast grp - range: [1...100]	<i>optional parameter with default value: 3</i> Max number of previews for each preview per mcast group
[no] preview-blackout	Parameter type: <Icmp::multicastSrcPreBlackout> Format: - valid preview Blackout Duration time of per mcast group - unit: sec - range: [0...7200]	<i>optional parameter with default value: 0</i> Preview Blackout Duration time of per multicast channel

30.10 Multicast Channel Package Members Configuration Command

Command Description

This command allows the operator to configure the multicast channel package members.

A multicast channel can be member of maximum 20 packages or be member of all (1024) packages, any value in between will be rejected.

Using this command packages will be added or removed from/to the list of packages of which the multicast channel is currently a member.

If the multicast channel is member of all packages care must be taken when removing packages, meaning that the command will only be accepted if after execution the multicast channel will be member of 20 packages or less.

User Level

The command can be accessed by operators with igmp privileges, and executed by operators with igmp privileges.

Command Syntax

The command has the following syntax:

```
> configure mcast ipv6-chn (grp-ipv6-addr)src-ipv6-addr <Igmp::IPv6Address>vlan-id
<Igmp::McastChannelVlan> ( no packagemember (package) ) | ( packagemember (package) )
```

Command Parameters

Table 30.10-1 "Multicast Channel Package Members Configuration Command" Resource Parameters

Resource Identifier	Type	Description
(grp-ipv6-addr)	Format: - multicast ipv6 address (prefix should be FF)	ipv6 address identifying the multicast group
src-ipv6-addr	Parameter type: <Igmp::IPv6Address> Format: - ipv6 address (unicast ipv6 address)	ipv6 address of the multicast server originating the multicast channel,value :: means ASM (any-src-ipv6-addr)
vlan-id	Parameter type: <Igmp::McastChannelVlan> Format: - vlan id for multicast - range: [1...4093]	vlanid of the multicast channel which is configured in it
(package)	Format: - the package number - range: [1...1024]	package member

30.11 Multicast Monitoring Source Configuration Command

Command Description

This command allows the operator to configure on demand monitoring for a specified multicast stream.

User Level

The command can be accessed by operators with igmp privileges, and executed by operators with igmp privileges.

Command Syntax

The command has the following syntax:

```
> configure mcast monitor ( no src (grp-ip-addr) src-ip-addr <Ip::V4Address> ) | ( src (grp-ip-addr) src-ip-addr
<Ip::V4Address> [ no loss-duration | loss-duration <Igmp::LossDuration> ] [ no loss-thresh-alert | loss-thresh-alert
<Igmp::LossThreshold> ] )
```

Command Parameters

Table 30.11-1 "Multicast Monitoring Source Configuration Command" Resource Parameters

Resource Identifier	Type	Description
(grp-ip-addr)	Format: - multicast-address (range: 224.0.0.3....239.255.255.255, except for 224.0.0.22)	mcast src address in network-byte order(big-endian)
src-ip-addr	Parameter type: <Ip::V4Address> Format: - IPv4-address	Unicast IP address in case SSM multicast channel, value 0.0.0.0 means ASM(any-src-ip-addr)

Table 30.11-2 "Multicast Monitoring Source Configuration Command" Command Parameters

Parameter	Type	Description
[no] loss-duration	Parameter type: <Igmp::LossDuration> Format: - duration - unit: sec - range: [5...2147483647]	<i>optional parameter with default value: 15</i> set the duration to count packets
[no] loss-thresh-alert	Parameter type: <Igmp::LossThreshold> Format: - the threshold for loss of traffic alert, 0 - disable - range: [0...4294967295]	<i>optional parameter with default value: 0</i> set loss of traffic threshold, alert generated if packet count is less or equal to the threshold.

30.12 Multicast Monitoring Channel Configuration Command

Command Description

This command allows the operator to configure on demand monitoring for a specified multicast stream.

User Level

The command can be accessed by operators with igmp privileges, and executed by operators with igmp privileges.

Command Syntax

The command has the following syntax:

```
> configure mcast monitor ( no chn (grp-ip-addr) src-ip-addr <Ip::V4Address> vlan-id <Igmp::McastMonitorVlan>
) | ( chn (grp-ip-addr) src-ip-addr <Ip::V4Address> vlan-id <Igmp::McastMonitorVlan> [ no loss-duration |
loss-duration <Igmp::LossDuration> ] [ no loss-thresh-alert | loss-thresh-alert <Igmp::LossThreshold> ] )
```

Command Parameters

Table 30.12-1 "Multicast Monitoring Channel Configuration Command" Resource Parameters

Resource Identifier	Type	Description
(grp-ip-addr)	Format: - multicast-address (range: 224.0.0.3....239.255.255.255, except for 224.0.0.22)	mcast src address in network-byte order(big-endian)
src-ip-addr	Parameter type: <Ip::V4Address> Format: - IPv4-address	Unicast IP address in case SSM multicast channel, value 0.0.0.0 means ASM(any-src-ip-addr)
vlan-id	Parameter type: <Igmp::McastMonitorVlan> Format: - vlan id for multicast - range: [0...4093]	vlanid of the multicast channel. Value 0 means any VLAN ID

Table 30.12-2 "Multicast Monitoring Channel Configuration Command" Command Parameters

Parameter	Type	Description
[no] loss-duration	Parameter type: <Igmp::LossDuration> Format: - duration - unit: sec - range: [5...2147483647]	<i>optional parameter with default value: 15</i> set the duration to count packets
[no] loss-thresh-alert	Parameter type: <Igmp::LossThreshold> Format: - the threshold for loss of traffic alert, 0 - disable - range: [0...4294967295]	<i>optional parameter with default value: 0</i> set loss of traffic threshold, alert generated if packet count is less or equal to the threshold.

30.13 Multicast Static Branch Configuration

Command

Command Description

This command allow the operator to configure the static multicast branch. When at least one static multicast branch is created, the corresponding static multicast root is created.

User Level

The command can be accessed by operators with igmp privileges, and executed by operators with igmp privileges.

Command Syntax

The command has the following syntax:

```
> configure mcast static ( no branch (grp-ip-addr) src-ip-addr <Ip::V4Address> port <Itf::VlanPort> ) | ( branch (grp-ip-addr) src-ip-addr <Ip::V4Address> port <Itf::VlanPort> )
```

Command Parameters

Table 30.13-1 "Multicast Static Branch Configuration Command" Resource Parameters

Resource Identifier	Type	Description
(grp-ip-addr)	Format: - multicast-address (range: 224.0.0.3....239.255.255.255, except for 224.0.0.22)	ip address identifying the multicast group
src-ip-addr	Parameter type: <Ip::V4Address> Format: - IPv4-address	ip address of the multicast server originating the multicast channel, value 0.0.0.0 means ASM(any-src-ip-addr),range:0.0.0.0....255.255.255.255
port	Parameter type: <Itf::VlanPort> Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::VpiId> : <Eqpt::VciId> : <Eqpt::UnstackedVlan> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::UnstackedVlan> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::VpiId> : <Eqpt::VciId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> / <Eqpt::OntPortId> : <Eqpt::UnstackedVlan> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / voip :	identification of the vlanport

Resource Identifier	Type	Description
	<Eqpt::UnstackedVlan> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / vuni : <Eqpt::UnstackedVlan> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::LLId> : <Eqpt::UnstackedVlan> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> / <Eqpt::OntPortId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / voip : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / vuni : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::LLId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / <Eqpt::Ng2OntSlotId> / <Eqpt::Ng2OntPortId> : <Eqpt::UnstackedVlan> ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / <Eqpt::Ng2OntSlotId> / <Eqpt::Ng2OntPortId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / vuni) Possible values: - ng2 : ngpon2 style identification Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number Field type <Eqpt::VpiId> - atm VPI Field type <Eqpt::VciId> - atm VCI Field type <Eqpt::ChannelGroupId> - the channel group identifier Field type <Eqpt::SubChannelGroupId> - the subchannel group identifier Field type <Eqpt::PonId> - the PON identifier Field type <Eqpt::OntId> - the ONT identifier Field type <Eqpt::Ng2OntId> - the NG2 ONT identifier Possible values: - voip : virtual uni identifier obsolete alternative replaced by vuni	

Resource Identifier	Type	Description
	- vuni : virtual uni identifier - Field type <Eqpt::OntSlotId> - the ONT SLOT identifier - Field type <Eqpt::OntPortId> - the ONT PORT identifier - Possible values: - vuni : virtual NGPON2 uni identifier - Field type <Eqpt::Ng2OntSlotId> - the NGPON2 ONT SLOT identifier - Field type <Eqpt::Ng2OntPortId> - the NGPON2 ONT PORT identifier - Field type <Eqpt::LLId> - the LLID identifier,range 1 for EPON,range 1-8 for DPOE - Possible values: - stacked : stacked vlan identity - Field type <Eqpt::UnstackedVlan> - unstacked vlan id - Field type <Eqpt::SVlan> - service vlan id - Field type <Eqpt::CVlan> - customer vlan id	

31- PPPoX-Relay Configuration Commands

31.1 PPPoX-Relay Configuration Command Tree	31-1095
31.2 PPPoX Cross-connect Global Configuration Command	31-1096
31.3 PPPoX Cross-connect Engine Configuration Command	31-1098
31.4 PPPoX Cross-connect Engine Monitoring Configuration Command	31-1100
31.5 PPPCC Engine TCA Threshold Configuration Command	31-1101
31.6 PPPoX Cross-connect Client Port Configuration Command	31-1103
31.7 PPPoX Cross-connect Client Port Monitoring Configuration Command	31-1106

31.1 PPPoX-Relay Configuration Command Tree

Description

This chapter gives an overview of nodes that are handled by "PPPoX-Relay Configuration Commands".

Command Tree

```

----configure
  ----pppox-relay
    ----cross-connect
      ----global-session
        - [no] pado-timeout
        - [no] pads-timeout
        - [no] max-pad-attempts
        - [no] trans-max-age
        - [no] cc-max-age
      ----[no] engine
        - (vlan-id)
        - [no] mac-addr-conc
        - [no] dslf-iwf-tag
        - [no] max-payload-tag
        - [no] name
        - [no] lock
        - [no] service-name
      ----[no] monitor
      ----tca
        - [no] enable
        - [no] tran-ageout-15min
        - [no] sess-ageout-15min
        - [no] tran-ageout-1day
        - [no] sess-ageout-1day
      ----[no] client-port
        - (port)
        - vlan-id
        - default-priority
        - [no] max-cc
        - [no] qos-profile
      ----[no] monitor

```

31.2 PPPoX Cross-connect Global Configuration Command

Command Description

This command allows the operator to specify the system-wide configuration parameters applicable to all PPP sessions.

User Level

The command can be accessed by operators with pppoe privileges, and executed by operators with pppoe privileges.

Command Syntax

The command has the following syntax:

```
> configure pppox-relay cross-connect global-session [ no pado-timeout | pado-timeout <PPPoX::PadTimeOut> ] [
no pads-timeout | pads-timeout <PPPoX::PadTimeOut> ] [ no max-pad-attempts | max-pad-attempts
<PPPoX::PadRRetries> ] [ no trans-max-age | trans-max-age <PPPoX::TransactionMaxAge> ] [ no cc-max-age |
cc-max-age <PPPoX::CcMaxAge> ]
```

Command Parameters

Table 31.2-2 "PPPoX Cross-connect Global Configuration Command" Command Parameters

Parameter	Type	Description
[no] pado-timeout	Parameter type: <PPPoX::PadTimeOut> Format: - timeout for PAD-O PAD-S messages - unit: sec - range: [1...60]	<i>optional parameter with default value: 3</i> timeout for PAD-O message
[no] pads-timeout	Parameter type: <PPPoX::PadTimeOut> Format: - timeout for PAD-O PAD-S messages - unit: sec - range: [1...60]	<i>optional parameter with default value: 3</i> timeout for PAD-S message
[no] max-pad-attempts	Parameter type: <PPPoX::PadRRetries> Format: - maximum number of PAD-R messages - range: [1...16]	<i>optional parameter with default value: 10</i> maximum number of PAD-R messages
[no] trans-max-age	Parameter type: <PPPoX::TransactionMaxAge> Format: - maximum age of PPP transaction - unit: sec - range: [1...300]	<i>optional parameter with default value: 300</i> maximum age of PPP transaction
[no] cc-max-age	Parameter type: <PPPoX::CcMaxAge> Format:	<i>optional parameter with default value: 300</i>

Parameter	Type	Description
	- maximum age of PPP cross-connection - unit: sec - range: [10...3000]	maximum age of PPP cross connection

31.3 PPPoX Cross-connect Engine Configuration Command

Command Description

This command allows the operator to configure the PPP cross-connect engine. The PPP cross-connect engine is identified by a VLAN ID. The name is the name used to identify the PPP cross-connect engine. The lock command locks or unlocks the PPP control plane. For example, if the control plane is unlocked, no new PPP cross-connections can be established, but the existing connections remain until they are released by the PPP server or client.

User Level

The command can be accessed by operators with pppoe privileges, and executed by operators with pppoe privileges.

Command Syntax

The command has the following syntax:

```
> configure pppox-relay cross-connect ( no engine (vlan-id) ) | ( engine (vlan-id) [ [ no ] mac-addr-conc ] [ [ no ]
dslf-iwf-tag ] [ no max-payload-tag | max-payload-tag <PPPoX::MaxPayloadTag> ] [ no name | name
<PPPoX::EngineName> ] [ [ no ] lock ] [ no service-name | service-name <PPPoX::EngineName> ] )
```

Command Parameters

Table 31.3-1 "PPPoX Cross-connect Engine Configuration Command" Resource Parameters

Resource Identifier	Type	Description
(vlan-id)	Format: (<Network::UVlanIndex> stacked : <Network::SVlanIndex> : <Network::CVlanIndex>) Possible values: - stacked : stacked vlan identity Field type <Network::UVlanIndex> - unstacked vlan identity - range: [1...4093] Field type <Network::SVlanIndex> - service vlan identity - range: [2...4093] Field type <Network::CVlanIndex> - customer vlan identity - range: [0...4093]	vlan identity

Table 31.3-2 "PPPoX Cross-connect Engine Configuration Command" Command Parameters

Parameter	Type	Description
[no] mac-addr-conc	Parameter type: boolean	optional parameter

Parameter	Type	Description
		<i>The parameter is not visible during modification.</i> enable MAC address concentration
[no] dslf-iwf-tag	Parameter type: boolean	<i>optional parameter</i> insert DSLF IWF Tag into PPPoE Discovery packets
[no] max-payload-tag	Parameter type: <PPPoX::MaxPayloadTag> Format: (insert no-insert) Possible values: - insert : add tag holding the MRU to PADI and PADR messages - no-insert : donot add tag holding the MRU to PADI and PADR messages	<i>optional parameter with default value: "no-insert"</i> insert:add tag holding the MRU to PADI and PADR messages
[no] name	Parameter type: <PPPoX::EngineName> Format: - Engine Name - length: 1<=x<=32	<i>optional parameter with default value: ""</i> name to identify the engine
[no] lock	Parameter type: boolean	<i>optional parameter</i> lock control plane engine
[no] service-name	Parameter type: <PPPoX::EngineName> Format: - Engine Name - length: 1<=x<=32	<i>optional parameter with default value: ""</i> service name issued by engine in PAD-I message

31.4 PPPoX Cross-connect Engine Monitoring Configuration Command

Command Description

This command allows the operator to configure the exception event counters for the PPP cross-connect engine.

User Level

The command can be accessed by operators with pppoe privileges, and executed by operators with pppoe privileges.

Command Syntax

The command has the following syntax:

> configure pppox-relay cross-connect engine (vlan-id) (no monitor) | (monitor)

Command Parameters

Table 31.4-1 "PPPoX Cross-connect Engine Monitoring Configuration Command" Resource Parameters

Resource Identifier	Type	Description
(vlan-id)	Format: (<Network::UVlanIndex> stacked : <Network::SVlanIndex> : <Network::CVlanIndex>) Possible values: - stacked : stacked vlan identity Field type <Network::UVlanIndex> - unstacked vlan identity - range: [1...4093] Field type <Network::SVlanIndex> - service vlan identity - range: [2...4093] Field type <Network::CVlanIndex> - customer vlan identity - range: [0...4093]	vlan identity

31.5 PPPCC Engine TCA Threshold Configuration Command

Command Description

This command allows the operator to configure the Threshold Crossing Alert (TCA) thresholds. The configuration is specific per PPP CC Engine.

User Level

The command can be accessed by operators with pppoe privileges, and executed by operators with pppoe privileges.

Command Syntax

The command has the following syntax:

```
> configure pppox-relay cross-connect engine (vlan-id) tca [ [ no ] enable ] [ no tran-ageout-15min |
tran-ageout-15min <PPPoX::TcaThreshold> ] [ no sess-ageout-15min | sess-ageout-15min
<PPPoX::TcaThreshold> ] [ no tran-ageout-1day | tran-ageout-1day <PPPoX::TcaThreshold> ] [ no
sess-ageout-1day | sess-ageout-1day <PPPoX::TcaThreshold> ]
```

Command Parameters

Table 31.5-1 "PPPCC Engine TCA Threshold Configuration Command" Resource Parameters

Resource Identifier	Type	Description
(vlan-id)	Format: (<Network::UVlanIndex> stacked : <Network::SVlanIndex> : <Network::CVlanIndex>) Possible values: - stacked : stacked vlan identity Field type <Network::UVlanIndex> - unstacked vlan identity - range: [1...4093] Field type <Network::SVlanIndex> - service vlan identity - range: [2...4093] Field type <Network::CVlanIndex> - customer vlan identity - range: [0...4093]	vlan identity

Table 31.5-2 "PPPCC Engine TCA Threshold Configuration Command" Command Parameters

Parameter	Type	Description
[no] enable	Parameter type: boolean	<i>optional parameter</i> enable the reporting of TCA's for this pppcc engine

31 PPPoX-Relay Configuration Commands

Parameter	Type	Description
[no] tran-ageout-15min	Parameter type: <PPPoX::TcaThreshold> Format: - value of the tca threshold for the pppcc engine - range: [0...65535]	<i>optional parameter with default value: 0</i> configurable threshold for the transaction ageout 15min counter
[no] sess-ageout-15min	Parameter type: <PPPoX::TcaThreshold> Format: - value of the tca threshold for the pppcc engine - range: [0...65535]	<i>optional parameter with default value: 0</i> configurable threshold for the session ageout 15min counter
[no] tran-ageout-1day	Parameter type: <PPPoX::TcaThreshold> Format: - value of the tca threshold for the pppcc engine - range: [0...65535]	<i>optional parameter with default value: 0</i> configurable threshold for the transaction ageout 1day counter
[no] sess-ageout-1day	Parameter type: <PPPoX::TcaThreshold> Format: - value of the tca threshold for the pppcc engine - range: [0...65535]	<i>optional parameter with default value: 0</i> configurable threshold for the session ageout 1day counter

31.6 PPPoX Cross-connect Client Port Configuration Command

Command Description

This command allows the operator to specify the PPP cross-connect client port. When creating a client port on a vlan port, only a Cvlan may be used.

User Level

The command can be accessed by operators with pppoe privileges, and executed by operators with pppoe privileges.

Command Syntax

The command has the following syntax:

```
> configure pppox-relay cross-connect ( no client-port (port) ) | ( client-port (port) vlan-id
<Network::StackedVlanSigned> default-priority <PPPoX::DefaultPriority> [ no max-cc | max-cc
<PPPoX::MaxNumPppCc> ] [ no qos-profile | qos-profile <PPPoX::QosProfileName> ] )
```

Command Parameters

Table 31.6-1 "PPPoX Cross-connect Client Port Configuration Command" Resource Parameters

Resource Identifier	Type	Description
(port)	Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::VpiId> : <Eqpt::VciId> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::VpiId> : <Eqpt::VciId> : <Eqpt::UnstackedVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::UnstackedVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::VpiId> : <Eqpt::VciId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> / <Eqpt::OntPortId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> /	client port identification

31 PPPoX-Relay Configuration Commands

Resource Identifier	Type	Description
	<Eqpt::OntSlotId> / <Eqpt::OntPortId> : <Eqpt::UnstackedVlan> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> / <Eqpt::OntPortId> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / voip : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / vuni : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / voip : <Eqpt::UnstackedVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / vuni : <Eqpt::UnstackedVlan> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / voip <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / vuni vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::LLId> : <Eqpt::UnstackedVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::LLId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::LLId>) Possible values: - vlan-port : vlan port Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number Field type <Eqpt::VpiId> - atm VPI Field type <Eqpt::VciId> - atm VCI Field type <Eqpt::PonId> - the PON identifier Field type <Eqpt::OntId> - the ONT identifier Possible values: - voip : virtual uni identifier obsolete alternative replaced by vuni - vuni : virtual uni identifier Field type <Eqpt::OntSlotId> - the ONT SLOT identifier Field type <Eqpt::OntPortId> - the ONT PORT identifier Field type <Eqpt::LLId> - the LLID identifier,range 1 for EPON,range 1-8 for DPOE	

Resource Identifier	Type	Description
	Possible values: - stacked : stacked vlan identity Field type <Eqpt::UnstackedVlan> - unstacked vlan id Field type <Eqpt::SVlan> - service vlan id Field type <Eqpt::CVlan> - customer vlan id	

Table 31.6-2 "PPPoX Cross-connect Client Port Configuration Command" Command Parameters

Parameter	Type	Description
vlan-id	Parameter type: <Network::StackedVlanSigned> Format: (<Network::UVlanIndex> stacked : <Network::SVlanIndex> : <Network::CVlanIndex>) Possible values: - stacked : stacked vlan identity Field type <Network::UVlanIndex> - unstacked vlan identity - range: [1...4093] Field type <Network::SVlanIndex> - service vlan identity - range: [2...4093] Field type <Network::CVlanIndex> - customer vlan identity - range: [0...4093]	<i>mandatory parameter</i> <i>The parameter is not visible during modification.</i> associates client port to cc-engine
default-priority	Parameter type: <PPPoX::DefaultPriority> Format: - indicates the p-bit for the client port - range: [0...7]	<i>mandatory parameter</i> indicates the p-bit for the client port
[no] max-cc	Parameter type: <PPPoX::MaxNumPppCc> Format: - max no. of PPP cross connection on a port - range: [1...64], [9...64] = 8 with MAC concentration.	<i>optional parameter with default value: 64</i> max no. of PPP cross connection on a port
[no] qos-profile	Parameter type: <PPPoX::QosProfileName> Format: (none name : <PPPoX::IgnoredQosProfileName>) Possible values: - none : no profile name to associate - name : enter profile name to be associated Field type <PPPoX::IgnoredQosProfileName> - name of the QoS profile - length: 1<=x<=32	<i>optional parameter with default value: "none"</i> qos profile name associated with client port

31.7 PPPoX Cross-connect Client Port Monitoring Configuration Command

Command Description

This command allows the operator to configure the exception event counters for the PPP cross-connect client port.

User Level

The command can be accessed by operators with pppoe privileges, and executed by operators with pppoe privileges.

Command Syntax

The command has the following syntax:

```
> configure pppox-relay cross-connect client-port (port) ( no monitor ) | ( monitor )
```

Command Parameters

Table 31.7-1 "PPPoX Cross-connect Client Port Monitoring Configuration Command" Resource Parameters

Resource Identifier	Type	Description
(port)	Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::VpiId> : <Eqpt::VciId> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::VpiId> : <Eqpt::VciId> : <Eqpt::UnstackedVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::UnstackedVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::VpiId> : <Eqpt::VciId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> / <Eqpt::OntPortId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> / <Eqpt::OntPortId> : <Eqpt::UnstackedVlan>	client port identification

Resource Identifier	Type	Description
	<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> / <Eqpt::OntPortId> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / voip : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / vuni : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / voip : <Eqpt::UnstackedVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / vuni : <Eqpt::UnstackedVlan> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / voip <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / vuni vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::LLId> : <Eqpt::UnstackedVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::LLId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::LLId>) Possible values: - vlan-port : vlan port Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number Field type <Eqpt::VpiId> - atm VPI Field type <Eqpt::VciId> - atm VCI Field type <Eqpt::PonId> - the PON identifier Field type <Eqpt::OntId> - the ONT identifier Possible values: - voip : virtual uni identifier obsolete alternative replaced by vuni - vuni : virtual uni identifier Field type <Eqpt::OntSlotId> - the ONT SLOT identifier Field type <Eqpt::OntPortId> - the ONT PORT identifier Field type <Eqpt::LLId> - the LLID identifier,range 1 for EPON,range 1-8 for DPOE Possible values: - stacked : stacked vlan identity	

31 PPPoX-Relay Configuration Commands

Resource Identifier	Type	Description
	Field type <Eqpt::UnstackedVlan> - unstacked vlan id Field type <Eqpt::SVlan> - service vlan id Field type <Eqpt::CVlan> - customer vlan id	

32- PPPoE Configuration Commands

32.1 PPPoE Configuration Command Tree	32-1110
32.2 PPPoE Profile Configuration Command	32-1111
32.3 PPPoE Client Interface Configuration Command	32-1113

32.1 PPPoE Configuration Command Tree

Description

This chapter gives an overview of nodes that are handled by "PPPoE Configuration Commands".

Command Tree

```
----configure
  ----pppoe-client
    ----[no] ppp-profile
      - (name)
      - [no] ipversion
      - [no] authproto
      - [no] mru
    ----[no] interface
      - (ifindex)
      - client-id
      - profile-name
      - username
      - password
      - [no] mac
      - [no] pbit
```


32.2 PPPoE Profile Configuration Command

Command Description

This command allows the operator to configure PPP profile parameters.

User Level

The command can be accessed by operators with pppoe privileges, and executed by operators with pppoe privileges.

Command Syntax

The command has the following syntax:

```
> configure pppoe-client ( no ppp-profile (name) ) | ( ppp-profile (name) [ no ipversion | ipversion
<PPPoE::pppProfileIpMode> ] [ no authproto | authproto <PPPoE::pppProfileAuthenType> ] [ no mru | mru
<PPPoE::PppProfileMru> ] )
```

Command Parameters

Table 32.2-1 "PPPoE Profile Configuration Command" Resource Parameters

Resource Identifier	Type	Description
(name)	Format: - a profile name - range: [a-zA-Z0-9-_.] - length: 1<=x<=32	name of the profile

Table 32.2-2 "PPPoE Profile Configuration Command" Command Parameters

Parameter	Type	Description
[no] ipversion	Parameter type: <PPPoE::pppProfileIpMode> Format: (none ipv4 dual ipv6) Possible values: - none : without NCP phase - ipv4 : only specify ipv4 connection - dual : specify both ipv4 and ipv6 connection - ipv6 : only specify ipv6 connection	<i>optional parameter with default value: "ipv4"</i> specifying ip version during NCP phase
[no] authproto	Parameter type: <PPPoE::pppProfileAuthenType> Format: (auto pap chap) Possible values: - auto : auto selected by ONU - pap : only PAP negotiation	<i>optional parameter with default value: "auto"</i> the type of PPP authentication used

32 PPPoE Configuration Commands

Parameter	Type	Description
	- chap : only CHAP negotiation	
[no] mru	Parameter type: <PPPoE::PppProfileMru> Format: - the MRU of PPP - range: [0...65535]	<i>optional parameter with default value: 1500</i> specifying MRU of PPP

32.3 PPPoE Client Interface Configuration Command

Command Description

This command allows the operator to configure PPPoE client interface parameters.

User Level

The command can be accessed by operators with pppoe privileges, and executed by operators with pppoe privileges.

Command Syntax

The command has the following syntax:

```
> configure pppoe-client ( no interface (ifindex) client-id <PPPoE::ClientId> ) | ( interface (ifindex) client-id
<PPPoE::ClientId> profile-name <PPPoE::PppProfileName> username <PPPoE::UserName> password
<PPPoE::Password> [ no mac | mac <PPPoE::MacAddress> ] [ no pbit | pbit <PPPoE::PbitValue> ] )
```

Command Parameters

Table 32.3-1 "PPPoE Client Interface Configuration Command" Resource Parameters

Resource Identifier	Type	Description
(ifindex)	Format: (vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::VpiId> : <Eqpt::VciId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::VpiId> : <Eqpt::VciId> : <Eqpt::UnstackedVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::UnstackedVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> / <Eqpt::OntPortId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> / <Eqpt::OntPortId> : <Eqpt::UnstackedVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / voip : stacked : <Eqpt::SVlan> : <Eqpt::CVlan>	interface index of the PPPoE client port

Resource Identifier	Type	Description
	<pre> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / vuni : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / voip : <Eqpt::UnstackedVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / vuni : <Eqpt::UnstackedVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::LLId> : <Eqpt::UnstackedVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::LLId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan-port:ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / <Eqpt::Ng2OntSlotId> / <Eqpt::Ng2OntPortId> : <Eqpt::UnstackedVlan> vlan-port:ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / <Eqpt::Ng2OntSlotId> / <Eqpt::Ng2OntPortId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan-port:ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / vuni) Possible values: - vlan-port : vlan port - vlan-port:ng2 : an NGPON2 vlan port Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number Field type <Eqpt::VpId> - atm VPI Field type <Eqpt::VciId> - atm VCI Field type <Eqpt::ChannelGroupId> - the channel group identifier Field type <Eqpt::SubChannelGroupId> - the subchannel group identifier Field type <Eqpt::PonId> - the PON identifier Field type <Eqpt::OntId> - the ONT identifier Field type <Eqpt::Ng2OntId> - the NG2 ONT identifier Possible values: - voip : virtual uni identifier obsolete alternative replaced by vuni - vuni : virtual uni identifier Possible values: - vuni : virtual NGPON2 uni identifier Field type <Eqpt::OntSlotId> </pre>	

Resource Identifier	Type	Description
	- the ONT SLOT identifier Field type <Eqpt::OntPortId> - the ONT PORT identifier Field type <Eqpt::Ng2OntSlotId> - the NGPON2 ONT SLOT identifier Field type <Eqpt::Ng2OntPortId> - the NGPON2 ONT PORT identifier Field type <Eqpt::LLId> - the LLID identifier, range 1 for EPON, range 1-8 for DPOE Possible values: - stacked : stacked vlan identity Field type <Eqpt::UnstackedVlan> - unstacked vlan id Field type <Eqpt::SVlan> - service vlan id Field type <Eqpt::CVlan> - customer vlan id	
client-id	Parameter type: <PPPoE::ClientId> Format: - the PPPoE client id - range: [1]	the PPPoE client id

Table 32.3-2 "PPPoE Client Interface Configuration Command" Command Parameters

Parameter	Type	Description
profile-name	Parameter type: <PPPoE::PppProfileName> Format: name : <PPPoE::IgnoredPppProfileName> Possible values: - name : enter profile name to be associated Field type <PPPoE::IgnoredPppProfileName> - name of the PPP profile - length: 1<=x<=64	<i>mandatory parameter</i> PPP profile name
username	Parameter type: <PPPoE::UserName> Format: - user name string - length: x<=25	<i>mandatory parameter</i> user name for PPP authentication
password	Parameter type: <PPPoE::Password> Format: - password string hidden from users - length: x<=25	<i>mandatory parameter</i> password for PPP authentication
[no] mac	Parameter type: <PPPoE::MacAddress> Format: - a unicast mac-address (example : 00:01:02:03:04:05) - length: 6	<i>optional parameter with default value: "00 : 00 : 00 : 00 : 00 : 00"</i> specify the client MAC address for PPPoE frame
[no] pbit	Parameter type: <PPPoE::PbitValue> Format: - the Pbit value - range: [0...7]	<i>optional parameter with default value: 0</i> the Pbit value for PPPoE frame

33- PPPoEL2STATS Configuration Commands

33.1 PPPoEL2STATS Configuration Command Tree	33-1117
33.2 Pppoe-L2 Statistics Configuration Command	33-1118

33.1 PPPoEL2STATS Configuration Command Tree

Description

This chapter gives an overview of nodes that are handled by "PPPoEL2STATS Configuration Commands".

Command Tree

```
----configure
  ----pppoel2
    ----[no] statistics
      - (vlan-port)
```

33.2 Pppoe-L2 Statistics Configuration Command

Command Description

This command is used to enable or disable the PPPoE L2 statistics of extensive counters (on demand) on vlan-port interface.

User Level

The command can be accessed by operators with pppoe privileges, and executed by operators with pppoe privileges.

Command Syntax

The command has the following syntax:

```
> configure pppoel2 ( no statistics (vlan-port) ) | ( statistics (vlan-port) )
```

Command Parameters

Table 33.2-1 "Pppoe-L2 Statistics Configuration Command" Resource Parameters

Resource Identifier	Type	Description
(vlan-port)	Format: (vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::VpiId> : <Eqpt::VciId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::VpiId> : <Eqpt::VciId> : <Eqpt::UnstackedVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::UnstackedVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> / <Eqpt::OntPortId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> / <Eqpt::OntPortId> : <Eqpt::UnstackedVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / voip : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / vuni : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> /	The VLAN port interface type

Resource Identifier	Type	Description
	<code><Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / voip :</code> <code><Eqpt::UnstackedVlan></code> <code> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> /</code> <code><Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / vuni :</code> <code><Eqpt::UnstackedVlan></code> <code> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> /</code> <code><Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> /</code> <code><Eqpt::LLId> : <Eqpt::UnstackedVlan></code> <code> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> /</code> <code><Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> /</code> <code><Eqpt::LLId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan></code> <code> vlan-port:ng2 : <Eqpt::ChannelGroupId> /</code> <code><Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> /</code> <code><Eqpt::Ng2OntSlotId> / <Eqpt::Ng2OntPortId> :</code> <code><Eqpt::UnstackedVlan></code> <code> vlan-port:ng2 : <Eqpt::ChannelGroupId> /</code> <code><Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> /</code> <code><Eqpt::Ng2OntSlotId> / <Eqpt::Ng2OntPortId> : stacked :</code> <code><Eqpt::SVlan> : <Eqpt::CVlan></code> <code> vlan-port:ng2 : <Eqpt::ChannelGroupId> /</code> <code><Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / vuni)</code> Possible values: - vlan-port : vlan port - vlan-port:ng2 : an NGPON2 vlan port Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number Field type <Eqpt::VpiId> - atm VPI Field type <Eqpt::VciId> - atm VCI Field type <Eqpt::ChannelGroupId> - the channel group identifier Field type <Eqpt::SubChannelGroupId> - the subchannel group identifier Field type <Eqpt::PonId> - the PON identifier Field type <Eqpt::OntId> - the ONT identifier Field type <Eqpt::Ng2OntId> - the NG2 ONT identifier Possible values: - voip : virtual uni identifier obsolete alternative replaced by vuni - vuni : virtual uni identifier Possible values: - vuni : virtual NGPON2 uni identifier Field type <Eqpt::OntSlotId> - the ONT SLOT identifier Field type <Eqpt::OntPortId> - the ONT PORT identifier Field type <Eqpt::Ng2OntSlotId>	

33 PPPoEL2STATS Configuration Commands

Resource Identifier	Type	Description
	- the NGPON2 ONT SLOT identifier Field type <Eqpt::Ng2OntPortId> - the NGPON2 ONT PORT identifier Field type <Eqpt::LLId> - the LLID identifier,range 1 for EPON,range 1-8 for DPOE Possible values: - stacked : stacked vlan identity Field type <Eqpt::UnstackedVlan> - unstacked vlan id Field type <Eqpt::SVlan> - service vlan id Field type <Eqpt::CVlan> - customer vlan id	

34- DHCP Relay Configuration Commands

34.1 DHCP Relay Configuration Command Tree	34-1122
34.2 DHCP Relay User Port Configuration Command	34-1123
34.3 DHCP v6 Relay User Port Configuration Command	34-1126

34.1 DHCP Relay Configuration Command Tree

Description

This chapter gives an overview of nodes that are handled by "DHCP Relay Configuration Commands".

Command Tree

```
----configure
  ----dhcp-relay
    ----[no] port-stats
      - (vlan-port)
    ----[no] v6-port-stats
      - (vlan-port)
```

34.2 DHCP Relay User Port Configuration

Command

Command Description

This command allows the operator to configure the DHCP relay user port statistics.

User Level

The command can be accessed by operators with dhcp privileges, and executed by operators with dhcp privileges.

Command Syntax

The command has the following syntax:

```
> configure dhcp-relay ( no port-stats (vlan-port) ) | ( port-stats (vlan-port) )
```

Command Parameters

Table 34.2-1 "DHCP Relay User Port Configuration Command" Resource Parameters

Resource Identifier	Type	Description
(vlan-port)	Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::VpiId> : <Eqpt::VciId> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::VpiId> : <Eqpt::VciId> : <Eqpt::UnstackedVlan> vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::UnstackedVlan> vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::VpiId> : <Eqpt::VciId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> / <Eqpt::OntPortId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> / <Eqpt::OntPortId> : <Eqpt::UnstackedVlan> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> / <Eqpt::OntPortId> vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> /	Identification of the ip user interface or vlan port

Resource Identifier	Type	Description
	<pre> <Eqpt::PonId> / <Eqpt::OntId> / voip : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / vuni : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / voip : <Eqpt::UnstackedVlan> vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / vuni : <Eqpt::UnstackedVlan> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / voip <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / vuni vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::LLId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::LLId> : <Eqpt::UnstackedVlan> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::LLId> vlan:ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / <Eqpt::Ng2OntSlotId> / <Eqpt::Ng2OntPortId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan:ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / <Eqpt::Ng2OntSlotId> / <Eqpt::Ng2OntPortId> : <Eqpt::UnstackedVlan> vlan:ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / vuni : <Eqpt::SVlan> : <Eqpt::CVlan> vlan:ng2 : <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / vuni : <Eqpt::UnstackedVlan>) Possible values: - vlan : vlan port - vlan:ng2 : ngpon2 vlan port Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number Field type <Eqpt::VpiId> - atm VPI Field type <Eqpt::VciId> - atm VCI Field type <Eqpt::PonId> - the PON identifier Field type <Eqpt::ChannelGroupId> - the channel group identifier Field type <Eqpt::SubChannelGroupId> - the subchannel group identifier </pre>	

Resource Identifier	Type	Description
	Field type <Eqpt::Ng2OntId> - the NG2 ONT identifier Field type <Eqpt::OntId> - the ONT identifier Possible values: - voip : virtual uni identifier obsolete alternative replaced by vuni - vuni : virtual uni identifier Possible values: - vuni : virtual NGPON2 uni identifier Field type <Eqpt::OntSlotId> - the ONT SLOT identifier Field type <Eqpt::OntPortId> - the ONT PORT identifier Field type <Eqpt::Ng2OntSlotId> - the NGPON2 ONT SLOT identifier Field type <Eqpt::Ng2OntPortId> - the NGPON2 ONT PORT identifier Field type <Eqpt::LLId> - the LLID identifier, range 1 for EPON, range 1-8 for DPOE Possible values: - stacked : stacked vlan identity Field type <Eqpt::UnstackedVlan> - unstacked vlan id Field type <Eqpt::SVlan> - service vlan id Field type <Eqpt::CVlan> - customer vlan id	

34.3 DHCP v6 Relay User Port Configuration Command

Command Description

This command allows the operator to configure the DHCP v6 relay user port statistics.

User Level

The command can be accessed by operators with dhcp privileges, and executed by operators with dhcp privileges.

Command Syntax

The command has the following syntax:

```
> configure dhcp-relay ( no v6-port-stats (vlan-port) ) | ( v6-port-stats (vlan-port) )
```

Command Parameters

Table 34.3-1 "DHCP v6 Relay User Port Configuration Command" Resource Parameters

Resource Identifier	Type	Description
(vlan-port)	Format: (vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::VpiId> : <Eqpt::VciId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::VpiId> : <Eqpt::VciId> : <Eqpt::UnstackedVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::UnstackedVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> / <Eqpt::OntPortId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> / <Eqpt::OntPortId> : <Eqpt::UnstackedVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / voip : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / vuni : stacked : <Eqpt::SVlan> : <Eqpt::CVlan>	identification of vlan port

Resource Identifier	Type	Description
	<pre> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / voip : <Eqpt::UnstackedVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / vuni : <Eqpt::UnstackedVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::LLId> : <Eqpt::UnstackedVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::LLId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan-port:ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / <Eqpt::Ng2OntSlotId> / <Eqpt::Ng2OntPortId> : <Eqpt::UnstackedVlan> vlan-port:ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / <Eqpt::Ng2OntSlotId> / <Eqpt::Ng2OntPortId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan-port:ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / vuni) </pre> Possible values: - vlan-port : vlan port - vlan-port:ng2 : an NGPON2 vlan port Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number Field type <Eqpt::VpiId> - atm VPI Field type <Eqpt::VciId> - atm VCI Field type <Eqpt::ChannelGroupId> - the channel group identifier Field type <Eqpt::SubChannelGroupId> - the subchannel group identifier Field type <Eqpt::PonId> - the PON identifier Field type <Eqpt::OntId> - the ONT identifier Field type <Eqpt::Ng2OntId> - the NG2 ONT identifier Possible values: - voip : virtual uni identifier obsolete alternative replaced by vuni - vuni : virtual uni identifier Possible values: - vuni : virtual NGPON2 uni identifier Field type <Eqpt::OntSlotId> - the ONT SLOT identifier Field type <Eqpt::OntPortId> - the ONT PORT identifier	

34 DHCP Relay Configuration Commands

Resource Identifier	Type	Description
	Field type <Eqpt::Ng2OntSlotId> - the NGPON2 ONT SLOT identifier Field type <Eqpt::Ng2OntPortId> - the NGPON2 ONT PORT identifier Field type <Eqpt::LLId> - the LLID identifier,range 1 for EPON,range 1-8 for DPOE Possible values: - stacked : stacked vlan identity Field type <Eqpt::UnstackedVlan> - unstacked vlan id Field type <Eqpt::SVlan> - service vlan id Field type <Eqpt::CVlan> - customer vlan id	

35- XDSL Bonding Configuration Commands

35.1 XDSL Bonding Configuration Command Tree	35-1130
35.2 XDSL Bonding Assembly Level Configuration Command	35-1132
35.3 xDSL Bonding Group Profile Configuration Command	35-1134
35.4 xDSL Bonding Group Rtx Profile Configuration Command	35-1137
35.5 xDSL Bonding Configuration Command	35-1141
35.6 xDSL Bonding Configuration Command	35-1143
35.7 xDSL Bonding Board Configuration Command	35-1144
35.8 xDSL Bonding Board Vectoring Fallback Configuration Command	35-1145

35.1 XDSL Bonding Configuration Command Tree

Description

This chapter gives an overview of nodes that are handled by "XDSL Bonding Configuration Commands".

Command Tree

```
----configure
  ----xdsl-bonding
    - group-assembly-time
    - [no] ptm-init-mode
  ----[no] group-profile
    - (index)
    - name
    - (scope)
    - version
    - [no] min-bitrate-up
    - [no] min-bitrate-down
    - [no] plan-bitrate-up
    - [no] plan-bitrate-down
    - [no] max-bitrate-up
    - [no] max-bitrate-down
    - [no] max-delay-down
    - [no] max-delay-up
    - [no] imp-noise-prot-dn
    - [no] imp-noise-prot-up
    - [no] delay-opt-mode-ds
    - [no] grp-assembly-time
    - [no] active
  ----[no] group-rtx-profile
    - (index)
    - name
    - version
    - [no] rtx-mode-dn
    - [no] rtx-mode-up
    - [no] min-exp-thrpt-dn
    - [no] min-exp-thrpt-up
    - [no] plan-exp-thrpt-dn
    - [no] plan-exp-thrpt-up
    - [no] max-exp-thrpt-dn
    - [no] max-exp-thrpt-up
    - [no] max-net-rate-dn
    - [no] max-net-rate-up
    - [no] min-delay-dn
    - [no] min-delay-up
    - [no] max-delay-dn
    - [no] max-delay-up
    - [no] min-inp-shine-dn
    - [no] min-inp-shine-up
    - [no] min-inp-rein-dn
    - [no] min-inp-rein-up
    - [no] int-arr-time-dn
```

- [no] int-arr-time-up
- [no] shine-ratio-dn
- [no] shine-ratio-up
- [no] leftr-thresh-dn
- [no] leftr-thresh-up
- [no] active
- group**
 - **(bonding-group-idx)**
 - [no] group-profile
 - [no] group-rtx-profile
 - X [no] admin-up
 - [no] up
 - [no] link**
 - **(bonding-link-id)**
- board**
 - **(board-index)**
 - vect-fallback**
 - [no] group-profile
 - [no] group-rtx-profile

35.2 XDSL Bonding Assembly Level Configuration Command

Command Description

This node provides the system-level provisioning of the bonding group assembly timeout and PTM bonding group initialization mode.

Bonding group assembly timeout: Default value is zero ('0', represents an infinite time), and will have as consequence that the bonding group will not come up till all lines in this bonding group are up. This parameter may be overruled by the grp-assembly-time parameter on bonding group-profile level. This parameter will be ignored for PTM bonding group initialization mode2.

PTM bonding group initialization mode: Default value is mode1 (Double initialization with probe-training). When no bonding groups(ATM/PTM) are configured in the system, the new initialization mode will be effective on the system immediately. When bonding groups(ATM/PTM) are configured already in the system,the Mode switching request should be followed by an 'NT Reset' request, to make the new initialization mode effective on the system. PTM BGs, that are operational up while changing the PTM Bonding Init Mode, will stay operational up till an 'NT Reset' is requested. After execution of the 'NT Reset', these PTM BGs will retrain in the newly configured mode and hence suffer a significant service impact.

User Level

The command can be accessed by operators with xdsl privileges, and executed by operators with xdsl privileges.

Command Syntax

The command has the following syntax:

```
> configure xdsl-bonding group-assembly-time <Xdsl::SignedIntegerSEC> [ no ptm-init-mode | ptm-init-mode <Xdsl::BondingInitMode> ]
```

Command Parameters

Table 35.2-2 "XDSL Bonding Assembly Level Configuration Command" Command Parameters

Parameter	Type	Description
group-assembly-time	Parameter type: <Xdsl::SignedIntegerSEC> Format: - second - unit: sec - range: [0...65535]	<i>optional parameter</i> Max waiting period for group to become operational
[no] ptm-init-mode	Parameter type: <Xdsl::BondingInitMode> Format: (mode1 mode2) Possible values: - mode1 : Double initialization with probe-training - mode2 : Single initialization without probe-training	<i>optional parameter with default value: "mode1"</i> PTM bonding group initialization mode

35.3 xDSL Bonding Group Profile Configuration Command

Command Description

This command allows to manage the xDSL bonding group profile. A profile can be created in one step with all the necessary parameters and making it active. It can also be created in several steps by specifying a few parameters in each step and make the profile active in the last step.

DESCRIPTION FOR THE COMMAND PARAMETER-SCOPE: The combination scope+profile must be unique. Typically local-profile must be used especially when configuring via CLI. Use of network-profile is depreciated. The network-profile was foreseen to allow management agents to define network-wide unique profiles, independent of what local profiles may have been created.

The command parameters delay-opt-mode-ds and grp-assembly-time will be ignored for PTM bonding group initialization mode2.

User Level

The command can be accessed by operators with xdsl privileges, and executed by operators with xdsl privileges.

Command Syntax

The command has the following syntax:

```
> configure xdsl-bonding ( no group-profile (index) ) | ( group-profile (index) name <AsamProfileName> (scope)
version <SignedInteger> [ no min-bitrate-up | min-bitrate-up <Xdsl::BondingBitRate> ] [ no min-bitrate-down |
min-bitrate-down <Xdsl::BondingBitRate> ] [ no plan-bitrate-up | plan-bitrate-up <Xdsl::BondingBitRate> ] [ no
plan-bitrate-down | plan-bitrate-down <Xdsl::BondingBitRate> ] [ no max-bitrate-up | max-bitrate-up
<Xdsl::BondingBitRate> ] [ no max-bitrate-down | max-bitrate-down <Xdsl::BondingBitRate> ] [ no
max-delay-down | max-delay-down <Xdsl::InterleavingDelay> ] [ no max-delay-up | max-delay-up
<Xdsl::InterleavingDelay> ] [ no imp-noise-prot-dn | imp-noise-prot-dn <Xdsl::ImpNoiseProtection> ] [ no
imp-noise-prot-up | imp-noise-prot-up <Xdsl::ImpNoiseProtection> ] [ no delay-opt-mode-ds | delay-opt-mode-ds
<Xdsl::BondingGroupDelayOptimMode> ] [ no grp-assembly-time | grp-assembly-time
<Xdsl::BondingGroupProfileAssemblyTimer> ] [ [ no ] active ] )
```

Command Parameters

Table 35.3-1 "xDSL Bonding Group Profile Configuration Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - bonding group profile index - range: [1...100]	index of the profile

Table 35.3-2 "xDSL Bonding Group Profile Configuration Command" Command Parameters

Parameter	Type	Description
name	Parameter type: <AsamProfileName> Format:	mandatory parameter name of the profile

Parameter	Type	Description
	- a profile name - range: [a-zA-Z0-9-_.] - length: 1<=x<=32	
(scope)	Format: (local-profile network-profile) Possible values: - local-profile : the local profile - network-profile : the network profile	<i>mandatory parameter</i> scope of the profile
version	Parameter type: <SignedInteger> Format: - a signed integer	<i>mandatory parameter</i> version maintained by manager, usually 1 for new profile
[no] min-bitrate-up	Parameter type: <Xdsl::BondingBitRate> Format: - a bonding bit rate value - unit: kbps - range: [0...2147483647]	<i>optional parameter with default value: 64</i> minimum upstream bit rate to be maintained
[no] min-bitrate-down	Parameter type: <Xdsl::BondingBitRate> Format: - a bonding bit rate value - unit: kbps - range: [0...2147483647]	<i>optional parameter with default value: 1024</i> minimum downstream bit rate to be maintained
[no] plan-bitrate-up	Parameter type: <Xdsl::BondingBitRate> Format: - a bonding bit rate value - unit: kbps - range: [0...2147483647]	<i>optional parameter with default value: 128</i> planned bitrate in upstream
[no] plan-bitrate-down	Parameter type: <Xdsl::BondingBitRate> Format: - a bonding bit rate value - unit: kbps - range: [0...2147483647]	<i>optional parameter with default value: 1536</i> planned bitrate in downstream
[no] max-bitrate-up	Parameter type: <Xdsl::BondingBitRate> Format: - a bonding bit rate value - unit: kbps - range: [0...2147483647]	<i>optional parameter with default value: 640</i> maximum bitrate in upstream
[no] max-bitrate-down	Parameter type: <Xdsl::BondingBitRate> Format: - a bonding bit rate value - unit: kbps - range: [0...2147483647]	<i>optional parameter with default value: 6144</i> maximum bitrate in downstream
[no] max-delay-down	Parameter type: <Xdsl::InterleavingDelay> Format: - a delay time period - unit: msec - range: [1...63]	<i>optional parameter with default value: 16</i> maximum delay for interleaving function in downstream
[no] max-delay-up	Parameter type: <Xdsl::InterleavingDelay> Format: - a delay time period - unit: msec - range: [1...63]	<i>optional parameter with default value: 16</i> maximum delay for interleaving function in upstream
[no] imp-noise-prot-dn	Parameter type: <Xdsl::ImpNoiseProtection> Format: - minimum impulse noise protection - unit: 1/10 symbols - range: [0...160]	<i>optional parameter with default value: 0</i> minimum impulse noise protection in downstream

35 XDSL Bonding Configuration Commands

Parameter	Type	Description
[no] imp-noise-prot-up	Parameter type: <Xdsl::ImpNoiseProtection> Format: - minimum impulse noise protection - unit: 1/10 symbols - range: [0...160]	<i>optional parameter with default value: 0</i> minimum impulse noise protection in upstream
[no] delay-opt-mode-ds	Parameter type: <Xdsl::BondingGroupDelayOptimMode> Format: (none by-co by-cpe) Possible values: - none : no downstream delay optimization - by-co : the downstream optimization is done by the co - by-cpe : the downstream optimization is done by the cpe(option not yet supported)	<i>optional parameter with default value: "none"</i> identifies the mode of the downstream delay optimization
[no] grp-assembly-time	Parameter type: <Xdsl::BondingGroupProfileAssemblyTimer> Format: (infinity <Xdsl::BondingAssemblyTimer> use-system) Possible values: - infinity : wait forever, special value 0 - use-system : use system wide parameter, special value 65535 Field type <Xdsl::BondingAssemblyTimer> - value of the assembly timer - unit: sec - range: [1...65534]	<i>optional parameter with default value: "use-system"</i> Max waiting period for group to become operational
[no] active	Parameter type: boolean	<i>optional parameter to activate the profile</i>

35.4 xDSL Bonding Group Rtx Profile Configuration Command

Command Description

This command allows the operator to configure the bonding group RTX profile which can be used to configure the modem for each contributing physical line of the bonding group

RTX downstream/upstream parameters will have effect on lines supporting RTX, only when the retransmission feature in downstream/upstream is not "forbidden"

User Level

The command can be accessed by operators with xdsl privileges, and executed by operators with xdsl privileges.

Command Syntax

The command has the following syntax:

```
> configure xdsl-bonding ( no group-rtx-profile (index) ) | ( group-rtx-profile (index) name <AsamProfileName> [
version <SignedInteger> ] [ no rtx-mode-dn | rtx-mode-dn <Xdsl::RtxMode> ] [ no rtx-mode-up | rtx-mode-up
<Xdsl::RtxMode> ] [ no min-exp-thrpt-dn | min-exp-thrpt-dn <Xdsl::BondingBitRate> ] [ no min-exp-thrpt-up |
min-exp-thrpt-up <Xdsl::BondingBitRate> ] [ no plan-exp-thrpt-dn | plan-exp-thrpt-dn <Xdsl::BondingBitRate> ] [
no plan-exp-thrpt-up | plan-exp-thrpt-up <Xdsl::BondingBitRate> ] [ no max-exp-thrpt-dn | max-exp-thrpt-dn
<Xdsl::BondingBitRate> ] [ no max-exp-thrpt-up | max-exp-thrpt-up <Xdsl::BondingBitRate> ] [ no
max-net-rate-dn | max-net-rate-dn <Xdsl::BondingBitRate> ] [ no max-net-rate-up | max-net-rate-up
<Xdsl::BondingBitRate> ] [ no min-delay-dn | min-delay-dn <Xdsl::RtxMinDelay> ] [ no min-delay-up |
min-delay-up <Xdsl::RtxMinDelay> ] [ no max-delay-dn | max-delay-dn <Xdsl::RtxMaxDelay> ] [ no
max-delay-up | max-delay-up <Xdsl::RtxMaxDelay> ] [ no min-inp-shine-dn | min-inp-shine-dn
<Xdsl::ShineImpNoiseProtection> ] [ no min-inp-shine-up | min-inp-shine-up <Xdsl::ShineImpNoiseProtection> ]
[ no min-inp-rein-dn | min-inp-rein-dn <Xdsl::ReinImpNoiseProtection> ] [ no min-inp-rein-up | min-inp-rein-up
<Xdsl::ReinImpNoiseProtection> ] [ no int-arr-time-dn | int-arr-time-dn <Xdsl::RtxInterArrivalTime> ] [ no
int-arr-time-up | int-arr-time-up <Xdsl::RtxInterArrivalTime> ] [ no shine-ratio-dn | shine-ratio-dn
<Xdsl::RtxShineRatio> ] [ no shine-ratio-up | shine-ratio-up <Xdsl::RtxShineRatio> ] [ no leftr-thresh-dn |
leftr-thresh-dn <Xdsl::RtxLeftrThreshold> ] [ no leftr-thresh-up | leftr-thresh-up <Xdsl::RtxLeftrThreshold> ] [ [ no
active ] )
```

Command Parameters

Table 35.4-1 "xDSL Bonding Group Rtx Profile Configuration Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - a profile index value - range: [1...128]	index of the profile

Table 35.4-2 "xDSL Bonding Group Rtx Profile Configuration Command" Command Parameters

35 XDSL Bonding Configuration Commands

Parameter	Type	Description
name	Parameter type: <AsamProfileName> Format: - a profile name - range: [a-zA-Z0-9-_.] - length: 1<=x<=32	<i>mandatory parameter</i> profile name
version	Parameter type: <SignedInteger> Format: - a signed integer	<i>optional parameter</i> version maintained by manager, usually 1 for new profile
[no] rtx-mode-dn	Parameter type: <Xdsl::RtxMode> Format: (forbidden preferred forced testmode) Possible values: - forbidden : retransmission forbidden in down/upstream - preferred : retransmission preferred in down/upstream - forced : retransmission forced in down/upstream - testmode : retransmission testmode in down/upstream	<i>optional parameter with default value: "preferred"</i> retransmission mode in downstream
[no] rtx-mode-up	Parameter type: <Xdsl::RtxMode> Format: (forbidden preferred forced testmode) Possible values: - forbidden : retransmission forbidden in down/upstream - preferred : retransmission preferred in down/upstream - forced : retransmission forced in down/upstream - testmode : retransmission testmode in down/upstream	<i>optional parameter with default value: "preferred"</i> retransmission mode in upstream
[no] min-exp-thrpt-dn	Parameter type: <Xdsl::BondingBitRate> Format: - a bonding bit rate value - unit: kbps - range: [0...2147483647]	<i>optional parameter with default value: 64</i> minimum expected throughput for downstream direction
[no] min-exp-thrpt-up	Parameter type: <Xdsl::BondingBitRate> Format: - a bonding bit rate value - unit: kbps - range: [0...2147483647]	<i>optional parameter with default value: 64</i> minimum expected throughput for upstream direction
[no] plan-exp-thrpt-dn	Parameter type: <Xdsl::BondingBitRate> Format: - a bonding bit rate value - unit: kbps - range: [0...2147483647]	<i>optional parameter with default value: 128</i> planned expected throughput for downstream direction
[no] plan-exp-thrpt-up	Parameter type: <Xdsl::BondingBitRate> Format: - a bonding bit rate value - unit: kbps - range: [0...2147483647]	<i>optional parameter with default value: 128</i> planned expected throughput for upstream direction
[no] max-exp-thrpt-dn	Parameter type: <Xdsl::BondingBitRate> Format: - a bonding bit rate value - unit: kbps - range: [0...2147483647]	<i>optional parameter with default value: 2147483647</i> maximum expected throughput for downstream direction
[no] max-exp-thrpt-up	Parameter type: <Xdsl::BondingBitRate> Format:	<i>optional parameter with default value: 2147483647</i>

Parameter	Type	Description
	- a bonding bit rate value - unit: kbps - range: [0...2147483647]	maximum expected throughput for upstream direction
[no] max-net-rate-dn	Parameter type: <Xdsl::BondingBitRate> Format: - a bonding bit rate value - unit: kbps - range: [0...2147483647]	<i>optional parameter with default value: 2147483647</i> maximum net data rate for downstream direction
[no] max-net-rate-up	Parameter type: <Xdsl::BondingBitRate> Format: - a bonding bit rate value - unit: kbps - range: [0...2147483647]	<i>optional parameter with default value: 2147483647</i> maximum net data rate for upstream direction
[no] min-delay-dn	Parameter type: <Xdsl::RtxMinDelay> Format: - a delay time period - unit: msec - range: [0...63]	<i>optional parameter with default value: 0</i> minimum instantaneous delay allowed (due to the effect of retransmission) for downstream direction
[no] min-delay-up	Parameter type: <Xdsl::RtxMinDelay> Format: - a delay time period - unit: msec - range: [0...63]	<i>optional parameter with default value: 0</i> minimum instantaneous delay allowed (due to the effect of retransmission) for upstream direction
[no] max-delay-dn	Parameter type: <Xdsl::RtxMaxDelay> Format: - a delay time period - unit: msec - range: [2...63]	<i>optional parameter with default value: 12</i> maximum instantaneous delay allowed (due to the effect of retransmission) for downstream direction Special value 0 means no delay bounds
[no] max-delay-up	Parameter type: <Xdsl::RtxMaxDelay> Format: - a delay time period - unit: msec - range: [2...63]	<i>optional parameter with default value: 12</i> maximum instantaneous delay allowed (due to the effect of retransmission) for upstream direction Special value 0 means no delay bounds
[no] min-inp-shine-dn	Parameter type: <Xdsl::ShineImpNoiseProtection> Format: - minimum impulse noise protection - unit: DMT symbols - range: [0...63]	<i>optional parameter with default value: 8</i> minimum impulse noise protection against shine for downstream direction
[no] min-inp-shine-up	Parameter type: <Xdsl::ShineImpNoiseProtection> Format: - minimum impulse noise protection - unit: DMT symbols - range: [0...63]	<i>optional parameter with default value: 8</i> minimum impulse noise protection against shine for upstream direction
[no] min-inp-rein-dn	Parameter type: <Xdsl::ReinImpNoiseProtection> Format: - minimum impulse noise protection - unit: DMT symbols - range: [0...7]	<i>optional parameter with default value: 0</i> minimum impulse noise protection against rein for downstream direction
[no] min-inp-rein-up	Parameter type: <Xdsl::ReinImpNoiseProtection> Format: - minimum impulse noise protection	<i>optional parameter with default value: 0</i> minimum impulse noise

35 XDSL Bonding Configuration Commands

Parameter	Type	Description
	- unit: DMT symbols - range: [0...7]	protection against rein for upstream direction
[no] int-arr-time-dn	Parameter type: <Xdsl::RtxInterArrivalTime> Format: (derivedfrom100hz derivedfrom120hz) Possible values: - derivedfrom100hz : inter-arrival time derived from 100hz - derivedfrom120hz : inter-arrival time derived from 120hz	<i>optional parameter with default value: "derivedfrom100hz"</i> assumed inter-arrival time for rein protection for downstream direction
[no] int-arr-time-up	Parameter type: <Xdsl::RtxInterArrivalTime> Format: (derivedfrom100hz derivedfrom120hz) Possible values: - derivedfrom100hz : inter-arrival time derived from 100hz - derivedfrom120hz : inter-arrival time derived from 120hz	<i>optional parameter with default value: "derivedfrom100hz"</i> assumed inter-arrival time for rein protection for upstream direction
[no] shine-ratio-dn	Parameter type: <Xdsl::RtxShineRatio> Format: - shine ratio - unit: 1/1000 - range: [0...100]	<i>optional parameter with default value: 10</i> shine ratio for downstream direction
[no] shine-ratio-up	Parameter type: <Xdsl::RtxShineRatio> Format: - shine ratio - unit: 1/1000 - range: [0...100]	<i>optional parameter with default value: 10</i> shine ratio for upstream direction
[no] leftr-thresh-dn	Parameter type: <Xdsl::RtxLeftrThreshold> Format: - near-end defect threshold - unit: 1/100 - range: [0,1...99]	<i>optional parameter with default value: 0</i> threshold for declaring a near-end defect in downstream direction
[no] leftr-thresh-up	Parameter type: <Xdsl::RtxLeftrThreshold> Format: - near-end defect threshold - unit: 1/100 - range: [0,1...99]	<i>optional parameter with default value: 0</i> threshold for declaring a near-end defect in upstream direction
[no] active	Parameter type: boolean	<i>optional parameter</i> to activate the profile

35.5 xDSL Bonding Configuration Command

Command Description

This command allows to configure a bonding group, which consists of assigning a predefined bonding group profile and optional assigning a group rtx-profile.

Configuring bonding group will fail when a service is already configured on the secondary DSL line of the bonding group

User Level

The command can be accessed by operators with xdsl privileges, and executed by operators with xdsl privileges.

Command Syntax

The command has the following syntax:

```
> configure xdsl-bonding group (bonding-group-idx) [ no group-profile | group-profile
<Xdsl::GroupProfileIndexWithRemove> ] [ no group-rtx-profile | group-rtx-profile
<Xdsl::LineBondingRtxProfile> ] [ no ] admin-up [ [ no ] up ]
```

Command Parameters

Table 35.5-1 "xDSL Bonding Configuration Command" Resource Parameters

Resource Identifier	Type	Description
(bonding-group-idx)	Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number	a unique interface index

Table 35.5-2 "xDSL Bonding Configuration Command" Command Parameters

Parameter	Type	Description
[no] group-profile	Parameter type: <Xdsl::GroupProfileIndexWithRemove> Format: (none <Xdsl::GroupProfileIndexWithRemove> name : <PrintableString>) Possible values: - none : no profile to associate - name : profile name Field type <Xdsl::GroupProfileIndexWithRemove>	<i>optional parameter with default value: "none"</i> a valid profile index for the interface

35 XDSL Bonding Configuration Commands

Parameter	Type	Description
	- bonding group profile index - range: [0...100] - Field type <PrintableString> - printable string	
[no] group-rtx-profile	Parameter type: <Xdsl::LineBondingRtxProfile> Format: (none <Xdsl::BondingRtxProfilePointer> name : <PrintableString>) Possible values: - none : no profile to associate - name : profile name Field type <Xdsl::BondingRtxProfilePointer> - profile index - range: [0...128] - Field type <PrintableString> - printable string	<i>optional parameter with default value: "none"</i> a valid bonding group rtx profile index for the interface
[no] admin-up	Parameter type: boolean	<i>obsolete parameter replaced by parameter "up"</i> set the admin-state of the group to up
[no] up	Parameter type: boolean	<i>optional parameter</i> <i>The parameter is not visible during creation.</i> admin-state of the group to up

Command Output

Table 35.5-3 "xDSL Bonding Configuration Command" Display parameters

Specific Information		
name	Type	Description
group-profile-name	Parameter type: <Xdsl::IgnoredPrintableString> - ignored printable string	name of the group profile <i>This element is only shown in detail mode.</i>
group-rtx-profile-name	Parameter type: <Xdsl::IgnoredPrintableString> - ignored printable string	name of the bonding group rtx profile <i>This element is only shown in detail mode.</i>

35.6 xDSL Bonding Configuration Command

Command Description

This node provides the provisioning of the bonding group, which consists of adding/removing links to/from the bonding group.

User Level

The command can be accessed by operators with xdsl privileges, and executed by operators with xdsl privileges.

Command Syntax

The command has the following syntax:

```
> configure xdsl-bonding group (bonding-group-idx) ( no link (bonding-link-id) ) | ( link (bonding-link-id) )
```

Command Parameters

Table 35.6-1 "xDSL Bonding Configuration Command" Resource Parameters

Resource Identifier	Type	Description
(bonding-group-idx)	Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number	a unique interface index
(bonding-link-id)	Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number	a bonding link interface index

35.7 xDSL Bonding Board Configuration Command

Command Description

This command allows the operator to configure xdsl bonding parameters related with a specific board.

User Level

The command can be accessed by operators with xdsl privileges, and executed by operators with xdsl privileges.

Command Syntax

The command has the following syntax:

> configure xdsl-bonding board (board-index)

Command Parameters

Table 35.7-1 "xDSL Bonding Board Configuration Command" Resource Parameters

Resource Identifier	Type	Description
(board-index)	Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId>) Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number	board index

35.8 xDSL Bonding Board Vectoring Fallback Configuration Command

Command Description

This command allows the operator to configure per board the profile selection in case the bonding group enters the vectoring fallback mode.

User Level

The command can be accessed by operators with xdsl privileges, and executed by operators with xdsl privileges.

Command Syntax

The command has the following syntax:

```
> configure xdsl-bonding board (board-index) vect-fallback [ no group-profile | group-profile
<Xdsl::VectFbGroupProfileIndex> ] [ no group-rtx-profile | group-rtx-profile <Xdsl::VectFbGroupRtxProfile> ]
```

Command Parameters

Table 35.8-1 "xDSL Bonding Board Vectoring Fallback Configuration Command" Resource Parameters

Resource Identifier	Type	Description
(board-index)	Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId>) Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number	board index

Table 35.8-2 "xDSL Bonding Board Vectoring Fallback Configuration Command" Command Parameters

Parameter	Type	Description
[no] group-profile	Parameter type: <Xdsl::VectFbGroupProfileIndex> Format: (group-level <Xdsl::VectFbGroupProfilePointer> name : <PrintableString>) Possible values: - group-level : use the original group profile in fallback mode - name : profile name Field type <Xdsl::VectFbGroupProfilePointer>	<i>optional parameter with default value: "group-level"</i> a valid profile index for the interface

Parameter	Type	Description
	- bonding group profile index - range: [1...100] - Field type <PrintableString> - printable string	
[no] group-rtx-profile	Parameter type: <Xdsl::VectFbGroupRtxProfile> Format: (none group-level <Xdsl::VectFbGroupRtxProfilePointer> name : <PrintableString>) Possible values: - none : no fallback profile to associate - group-level : use the original group rtx profile in fallback mode - name : profile name Field type <Xdsl::VectFbGroupRtxProfilePointer> - a profile index value - range: [0...128] Field type <PrintableString> - printable string	<i>optional parameter with default value: "group-level"</i> a valid bonding group rtx profile index for the interface

Command Output

Table 35.8-3 "xDSL Bonding Board Vectoring Fallback Configuration Command" Display parameters

Specific Information		
name	Type	Description
group-profile-name	Parameter type: <Xdsl::IgnoredPrintableString> - ignored printable string	name of the group profile <i>This element is only shown in detail mode.</i>
group-rtx-profile-name	Parameter type: <Xdsl::IgnoredPrintableString> - ignored printable string	name of the bonding group rtx profile <i>This element is only shown in detail mode.</i>

36- CPE Remote Configuration Commands

36.1 CPE Remote Configuration Command Tree	36-1148
36.2 CPE Remote Management System Configuration Commands	36-1149
36.3 CPE Manager Configuration Command	36-1150
36.4 CPE IPProxy Session Configuration Command	36-1151

36.1 CPE Remote Configuration Command Tree

Description

This chapter gives an overview of nodes that are handled by "CPE Remote Configuration Commands".

Command Tree

```
----configure
  ----cpe-management
    - [no] proxy-mode
    X vlan-id
  ----[no] manager
    - (address)
  ----X [no] session
    - (dslport)
    - connection
```

36.2 CPE Remote Management System Configuration Commands

Command Description

This command allows to configure CPE Remote Management System;

User Level

The command can be accessed by operators with security privileges, and executed by operators with security privileges.

Command Syntax

The command has the following syntax:

```
> configure cpe-management [ no proxy-mode | proxy-mode <CpeProxy::SystemMode> ] [ vlan-id <CpeProxy::VlanIndex> ]
```

Command Parameters

Table 36.2-2 "CPE Remote Management System Configuration Commands" Command Parameters

Parameter	Type	Description
[no] proxy-mode	Parameter type: <CpeProxy::SystemMode> Format: (snmp none) Possible values: - snmp : this mode is relaying SNMP messages - none : disables the cpeproxy	<i>optional parameter with default value: "none"</i> set the CPE Proxy mode
vlan-id	Parameter type: <CpeProxy::VlanIndex> Format: - cpe ipproxy vlan number - range: [0...4093]	<i>obsolete parameter that will be ignored</i> configure the svlan number.

36.3 CPE Manager Configuration Command

Command Description

This command allows to configure a CPE manager.

User Level

The command can be accessed by operators with security privileges, and executed by operators with security privileges.

Command Syntax

The command has the following syntax:

```
> configure cpe-management ( no manager (address) ) | ( manager (address) )
```

Command Parameters

Table 36.3-1 "CPE Manager Configuration Command " Resource Parameters

Resource Identifier	Type	Description
(address)	Format: <CpeProxy::IPaddress> : <CpeProxy::PortNumber> Field type <CpeProxy::IPaddress> - IP address of CPE Management Station Field type <CpeProxy::PortNumber> - cpe management station udp port number - range: [1...65535]	the address of a CPE manager

36.4 CPE IPProxy Session Configuration Command

Command Description

Obsolete command.

User Level

The command can be accessed by operators with security privileges, and executed by operators with security privileges.

Command Syntax

The command has the following syntax:

```
> configure cpe-management ( no session (dslport) ) | ( session (dslport) connection
<CpeProxy::cpeIpProxySessionProtocolPort> )
```

Obsolete command.

Command Parameters

Table 36.4-1 "CPE IPProxy Session Configuration Command " Resource Parameters

Resource Identifier	Type	Description
(dslport)	Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number	identification of port to which the CPE is connected

Table 36.4-2 "CPE IPProxy Session Configuration Command " Command Parameters

Parameter	Type	Description
connection	Parameter type: <CpeProxy::cpeIpProxySessionProtocolPort> Format: - cpe ipproxy port number - range: [0,13410...13457]	mandatory parameter protocol port for ipproxy session.

37- SHDSL Configuration Commands

37.1 SHDSL Configuration Command Tree	37-1153
37.2 SHDSL Span Configuration Command	37-1155
37.3 SHDSL Unit Configuration Command	37-1160
37.4 SHDSL Segment Configuration Command	37-1162

37.1 SHDSL Configuration Command Tree

Description

This chapter gives an overview of nodes that are handled by "SHDSL Configuration Commands".

Command Tree

```

----configure
  ----shdsl
    ----span
      - (if-index)
      - [no] active
      - [no] admin-up
      - [no] repeaters
      - [no] op-mode
      - [no] spectral-profile
      - [no] wire-mode
      - [no] mgmt-by-stu-r
      - [no] regi-set
      - [no] min-line-rate
      - [no] max-line-rate
      - [no] margin-down-worst
      - [no] margin-down-curr
      - [no] margin-up-worst
      - [no] margin-up-curr
      - [no] probe
      - [no] tc-pam-sele
      - [no] efm-hs-sele
      - [no] bonding-rate-mode
      - [no] min-rate-link1
      - [no] max-rate-link1
      - [no] min-rate-link2
      - [no] max-rate-link2
      - [no] min-rate-link3
      - [no] max-rate-link3
      - [no] min-rate-link4
      - [no] max-rate-link4
      - [no] tc-pam-link1
      - [no] tc-pam-link2
      - [no] tc-pam-link3
      - [no] tc-pam-link4
      - [no] ctc
    ----unit
      - (if-index)
      - unit-id
      - [no] loop-attenuation
      - [no] snr-margin
      - [no] loopback-timeout
    ----segment
      - (if-index)
      - unit-id
      - side
  
```

37 SHDSL Configuration Commands

- [no] loopback
- [no] pbo-mode

37.2 SHDSL Span Configuration Command

Command Description

This command allows the operator to manage the SHDSL span profile.

The lines, which you can configure, are calculated via the next formula: $m*n + 1$

o where m is the number of pairs per modem

o where n is from 0 till $24/m - 1$

Mixing of different "wire mode" on the same LT is possible as long as the lines are not occupied yet.

User Level

The command can be accessed by operators with `xdsl` privileges, and executed by operators with `xdsl` privileges.

Command Syntax

The command has the following syntax:

```
> configure shdsl span (if-index) [ [ no ] active ] [ [ no ] admin-up ] [ no repeaters | repeaters
<Shdsl::SpanConfNumRepeaters> ] [ no op-mode | op-mode <Shdsl::SpanOperationalMode> ] [ no spectral-profile
| spectral-profile <Shdsl::SpanSpectralProfile> ] [ no wire-mode | wire-mode <Shdsl::SpanWireMode> ] [ [ no ]
mgmt-by-stu-r ] [ no regi-set | regi-set <Shdsl::SpanRegionalSetting> ] [ no min-line-rate | min-line-rate
<Shdsl::BitRate> ] [ no max-line-rate | max-line-rate <Shdsl::BitRate> ] [ no margin-down-worst |
margin-down-worst <Shdsl::NoiseMarginWC> ] [ no margin-down-curr | margin-down-curr
<Shdsl::NoiseMarginCC> ] [ no margin-up-worst | margin-up-worst <Shdsl::NoiseMarginWC> ] [ no
margin-up-curr | margin-up-curr <Shdsl::NoiseMarginCC> ] [ no probe | probe <Shdsl::SpanLineProbeEnable> ] [
no tc-pam-sele | tc-pam-sele <Shdsl::SpanTCPAMSelection> ] [ no efm-hs-sele | efm-hs-sele
<Shdsl::SpanEFMHandshakeSelection> ] [ no bonding-rate-mode | bonding-rate-mode
<Shdsl::SpanBondingRateControlMode> ] [ no min-rate-link1 | min-rate-link1 <Shdsl::BitRate> ] [ no
max-rate-link1 | max-rate-link1 <Shdsl::BitRate> ] [ no min-rate-link2 | min-rate-link2 <Shdsl::BitRate> ] [ no
max-rate-link2 | max-rate-link2 <Shdsl::BitRate> ] [ no min-rate-link3 | min-rate-link3 <Shdsl::BitRate> ] [ no
max-rate-link3 | max-rate-link3 <Shdsl::BitRate> ] [ no min-rate-link4 | min-rate-link4 <Shdsl::BitRate> ] [ no
max-rate-link4 | max-rate-link4 <Shdsl::BitRate> ] [ no tc-pam-link1 | tc-pam-link1
<Shdsl::SpanTCPAMSelection> ] [ no tc-pam-link2 | tc-pam-link2 <Shdsl::SpanTCPAMSelection> ] [ no
tc-pam-link3 | tc-pam-link3 <Shdsl::SpanTCPAMSelection> ] [ no tc-pam-link4 | tc-pam-link4
<Shdsl::SpanTCPAMSelection> ] [ no ctc | ctc <Shdsl::SpanCTCEnable> ]
```

Command Parameters

Table 37.2-1 "SHDSL Span Configuration Command" Resource Parameters

Resource Identifier	Type	Description
(if-index)	Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId>	interface index of the port

Resource Identifier	Type	Description
	- the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number	

Table 37.2-2 "SHDSL Span Configuration Command" Command Parameters

Parameter	Type	Description
[no] active	Parameter type: boolean	<i>optional parameter</i> set the span-profile active
[no] admin-up	Parameter type: boolean	<i>optional parameter</i> admin status is up
[no] repeaters	Parameter type: <Shdsl::SpanConfNumRepeaters> Format: - the number of SRUs to be configured for this span - range: [0...8]	<i>optional parameter with default value: 0</i> number of repeaters
[no] op-mode	Parameter type: <Shdsl::SpanOperationalMode> Format: (native ima efm tdm) Possible values: - native : the operational mode is native - ima : the operational mode is ima - efm : the operational mode is efm - tdm : the operational mode is tdm	<i>optional parameter with default value: "native"</i> span operational mode
[no] spectral-profile	Parameter type: <Shdsl::SpanSpectralProfile> Format: (symmetric asymmetric) Possible values: - symmetric : the spectral mode is symmetric - asymmetric : the spectral mode is asymmetric	<i>optional parameter with default value: "symmetric"</i> spectral mode
[no] wire-mode	Parameter type: <Shdsl::SpanWireMode> Format: (two-wire four-wire six-wire eight-wire) Possible values: - two-wire : the M-pair operation is one-pair - four-wire : the M-pair operation is two-pair - six-wire : the M-pair operation is three-pair - eight-wire : the M-pair operation is four-pair	<i>optional parameter with default value: "two-wire"</i> M-pair operation wire mode
[no] mgmt-by-stu-r	Parameter type: boolean	<i>optional parameter</i> enable the STU-R initiated management flow
[no] regi-set	Parameter type: <Shdsl::SpanRegionalSetting> Format: (annex-a/f annex-b/g) Possible values: - annex-a/f : Annex A/F Region 1 - annex-b/g : Annex B/G Region 2	<i>optional parameter with default value: "annex-b/g"</i> the number specifies regional setting
[no] min-line-rate	Parameter type: <Shdsl::BitRate> Format:	<i>optional parameter with default value: 192</i>

Parameter	Type	Description
	- bitrate - unit: kbits/sec	the minimum requested data rate
[no] max-line-rate	Parameter type: <Shdsl::BitRate> Format: - bitrate - unit: kbits/sec	<i>optional parameter with default value: 5696</i> the maximum requested data rate
[no] margin-down-worst	Parameter type: <Shdsl::NoiseMarginWC> Format: - a noise margin value of worst conditions - unit: db - range: [-11...10]	<i>optional parameter with default value: -11</i> target relative margin in dwnstrm for worst case noise
[no] margin-down-curr	Parameter type: <Shdsl::NoiseMarginCC> Format: - a noise margin value of current conditions - unit: db - range: [-11,0...10]	<i>optional parameter with default value: 5</i> relative margin in dwnstrm for current noise condition
[no] margin-up-worst	Parameter type: <Shdsl::NoiseMarginWC> Format: - a noise margin value of worst conditions - unit: db - range: [-11...10]	<i>optional parameter with default value: -11</i> target relative margin in upstrm for worst case noise
[no] margin-up-curr	Parameter type: <Shdsl::NoiseMarginCC> Format: - a noise margin value of current conditions - unit: db - range: [-11,0...10]	<i>optional parameter with default value: 5</i> relative margin in upstrm for current noise conditions
[no] probe	Parameter type: <Shdsl::SpanLineProbeEnable> Format: (disable enable) Possible values: - disable : disable the line probe - enable : enable the line probe	<i>optional parameter with default value: "enable"</i> the number enable/disable line probe
[no] tc-pam-sele	Parameter type: <Shdsl::SpanTCPAMSelection> Format: (auto tc-pam32 tc-pam16) Possible values: - auto : auto-tcPam selection - tc-pam32 : tcPam32 selection - tc-pam16 : tcPam16 selection	<i>optional parameter with default value: "auto"</i> the TC-PAM modulation selection for the span
[no] efm-hs-sele	Parameter type: <Shdsl::SpanEFMHandshakeSelection> Format: (auto ieee itu not-applicable) Possible values: - auto : auto select ieee/itu according to cpe - ieee : ieee 2base-tl - itu : itu-t g.991.2 ptm 64/65otc - not-applicable : not-applicable for atm/ima mode	<i>optional parameter with default value: "not-applicable"</i> the handshake mode selection for the span
[no] bonding-rate-mode	Parameter type: <Shdsl::SpanBondingRateControlMode> Format: (span-level link-level)	<i>optional parameter with default value: "span-level"</i> the bonding rate control mode on the span

37 SHDSL Configuration Commands

Parameter	Type	Description
	Possible values: - span-level : bonding rate control mode is span level - link-level : bonding rate control mode is span level	
[no] min-rate-link1	Parameter type: <Shdsl::BitRate> Format: - bitrate - unit: kbits/sec	<i>optional parameter with default value: 192</i> the minimum requested data rate of link 1
[no] max-rate-link1	Parameter type: <Shdsl::BitRate> Format: - bitrate - unit: kbits/sec	<i>optional parameter with default value: 5696</i> the maximum requested data rate of link 1
[no] min-rate-link2	Parameter type: <Shdsl::BitRate> Format: - bitrate - unit: kbits/sec	<i>optional parameter with default value: 192</i> the minimum requested data rate of link 2
[no] max-rate-link2	Parameter type: <Shdsl::BitRate> Format: - bitrate - unit: kbits/sec	<i>optional parameter with default value: 5696</i> the maximum requested data rate of link 2
[no] min-rate-link3	Parameter type: <Shdsl::BitRate> Format: - bitrate - unit: kbits/sec	<i>optional parameter with default value: 192</i> the minimum requested data rate of link 3
[no] max-rate-link3	Parameter type: <Shdsl::BitRate> Format: - bitrate - unit: kbits/sec	<i>optional parameter with default value: 5696</i> the maximum requested data rate of link 3
[no] min-rate-link4	Parameter type: <Shdsl::BitRate> Format: - bitrate - unit: kbits/sec	<i>optional parameter with default value: 192</i> the minimum requested data rate of link 4
[no] max-rate-link4	Parameter type: <Shdsl::BitRate> Format: - bitrate - unit: kbits/sec	<i>optional parameter with default value: 5696</i> the maximum requested data rate of link 4
[no] tc-pam-link1	Parameter type: <Shdsl::SpanTCPAMSelection> Format: (auto tc-pam32 tc-pam16) Possible values: - auto : auto-tcPam selection - tc-pam32 : tcPam32 selection - tc-pam16 : tcPam16 selection	<i>optional parameter with default value: "auto"</i> the TC-PAM modulation selection for the link 1
[no] tc-pam-link2	Parameter type: <Shdsl::SpanTCPAMSelection> Format: (auto tc-pam32 tc-pam16) Possible values: - auto : auto-tcPam selection - tc-pam32 : tcPam32 selection - tc-pam16 : tcPam16 selection	<i>optional parameter with default value: "auto"</i> the TC-PAM modulation selection for the link 2
[no] tc-pam-link3	Parameter type: <Shdsl::SpanTCPAMSelection> Format: (auto tc-pam32	<i>optional parameter with default value: "auto"</i> the TC-PAM modulation selection for the link 3

Parameter	Type	Description
	tc-pam16) Possible values: - auto : auto-tcPam selection - tc-pam32 : tcPam32 selection - tc-pam16 : tcPam16 selection	
[no] tc-pam-link4	Parameter type: <Shdsl::SpanTCPAMSelection> Format: (auto tc-pam32 tc-pam16) Possible values: - auto : auto-tcPam selection - tc-pam32 : tcPam32 selection - tc-pam16 : tcPam16 selection	<i>optional parameter with default value: "auto"</i> the TC-PAM modulation selection for the link 4
[no] ctc	Parameter type: <Shdsl::SpanCTCEnable> Format: (disable enable) Possible values: - disable : disable the cross-talk cancellation - enable : enable the cross-talk cancellation	<i>optional parameter with default value: "disable"</i> enable the cross-talk cancellation for the span

37.3 SHDSL Unit Configuration Command

Command Description

This command allows the operator to manage the SHDSL unit profile in one SHDSL span.

User Level

The command can be accessed by operators with xdsl privileges, and executed by operators with xdsl privileges.

Command Syntax

The command has the following syntax:

```
> configure shdsl unit (if-index) unit-id <Shdsl::UnitId> [ no loop-attenuation | loop-attenuation
<Shdsl::UnitLoopAttenThreshold> ] [ no snr-margin | snr-margin <Shdsl::UnitSnrMarginThreshold> ] [ no
loopback-timeout | loopback-timeout <Shdsl::UnitLoopbackTimeout> ]
```

Command Parameters

Table 37.3-1 "SHDSL Unit Configuration Command" Resource Parameters

Resource Identifier	Type	Description
(if-index)	Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number	interface index of the port
unit-id	Parameter type: <Shdsl::UnitId> Format: (stu-c stu-r sru-1 sru-2 sru-3 sru-4 sru-5 sru-6 sru-7 sru-8) Possible values: - stu-c : the SHDSL unit is STU-C - stu-r : the SHDSL unit is STU-R - sru-1 : the SHDSL unit is SRU-1	unit identifier in an SHDSL span

Resource Identifier	Type	Description
	- sru-2 : the SHDSL unit is SRU-2 - sru-3 : the SHDSL unit is SRU-3 - sru-4 : the SHDSL unit is SRU-4 - sru-5 : the SHDSL unit is SRU-5 - sru-6 : the SHDSL unit is SRU-6 - sru-7 : the SHDSL unit is SRU-7 - sru-8 : the SHDSL unit is SRU-8	

Table 37.3-2 "SHDSL Unit Configuration Command" Command Parameters

Parameter	Type	Description
[no] loop-attenuation	Parameter type: <Shdsl::UnitLoopAttenThreshold> Format: - a loop attenuation threshold value for an SHDSL unit - unit: db - range: [0...127]	<i>optional parameter with default value: 0</i> the loop attenuation threshold value
[no] snr-margin	Parameter type: <Shdsl::UnitSnrMarginThreshold> Format: - an SNR margin threshold value for an SHDSL unit - unit: db - range: [0...15]	<i>optional parameter with default value: 0</i> the snr margin threshold value
[no] loopback-timeout	Parameter type: <Shdsl::UnitLoopbackTimeout> Format: - a loopback timeout duration value for an SHDSL unit - unit: min - range: [0...4095]	<i>optional parameter with default value: 0</i> the loopback timeout value

37.4 SHDSL Segment Configuration Command

Command Description

This command allows the operator to manage the SHDSL segment points on either sides of an SHDSL unit.

User Level

The command can be accessed by operators with xdsl privileges, and executed by operators with xdsl privileges.

Command Syntax

The command has the following syntax:

```
> configure shdsl segment (if-index) unit-id <Shdsl::UnitId> side <Shdsl::SegmentSide> [ no loopback | loopback
<Shdsl::SegmentTermLoopbackConf> ] [ no pbo-mode | pbo-mode <Shdsl::SegmentTermPowerBackoff> ]
```

Command Parameters

Table 37.4-1 "SHDSL Segment Configuration Command" Resource Parameters

Resource Identifier	Type	Description
(if-index)	Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number	interface index of the port
unit-id	Parameter type: <Shdsl::UnitId> Format: (stu-c stu-r sru-1 sru-2 sru-3 sru-4 sru-5 sru-6 sru-7 sru-8) Possible values: - stu-c : the SHDSL unit is STU-C - stu-r : the SHDSL unit is STU-R - sru-1 : the SHDSL unit is SRU-1 - sru-2 : the SHDSL unit is SRU-2	unit identifier in an SHDSL span

Resource Identifier	Type	Description
	- sru-3 : the SHDSL unit is SRU-3 - sru-4 : the SHDSL unit is SRU-4 - sru-5 : the SHDSL unit is SRU-5 - sru-6 : the SHDSL unit is SRU-6 - sru-7 : the SHDSL unit is SRU-7 - sru-8 : the SHDSL unit is SRU-8	
side	Parameter type: <Shdsl::SegmentSide> Format: (network customer) Possible values: - network : the network side - customer : the customer side	the particular side of an SHDSL unit in an SHDSL segment

Table 37.4-2 "SHDSL Segment Configuration Command" Command Parameters

Parameter	Type	Description
[no] loopback	Parameter type: <Shdsl::SegmentTermLoopbackConf> Format: (none normal) Possible values: - none : no loopback - normal : normal loopback	<i>optional parameter with default value: "none"</i> the loopback mode for the associated side
[no] pbo-mode	Parameter type: <Shdsl::SegmentTermPowerBackoff> Format: (default selected disabled) Possible values: - default : the default mode - selected : the selected mode - disabled : disable PBO	<i>optional parameter with default value: "default"</i> the power backoff mode for the associated side

38- IMA Configuration Commands

38.1 IMA Configuration Command Tree	38-1165
38.2 IMA Group Configuration Commands	38-1166
38.3 IMA Link Configuration Commands	38-1168

38.1 IMA Configuration Command Tree

Description

This chapter gives an overview of nodes that are handled by "IMA Configuration Commands".

Command Tree

```
----configure
  ----ima
    ----group
      - (if-index)
      - [no] activate
      - [no] admin-up
      - [no] min-tx-links
      - [no] min-rx-links
      - near-end-ima-id
    ----[no] link
      - (link-if-index)
      - grp-index
```

38.2 IMA Group Configuration Commands

Command Description

This command allows the operator to manage the IMA group profile.

User Level

The command can be accessed by operators with xdsl privileges, and executed by operators with xdsl privileges.

Command Syntax

The command has the following syntax:

```
> configure ima group (if-index) [ [ no ] activate ] [ [ no ] admin-up ] [ no min-tx-links | min-tx-links
<Ima::GroupMinNumTxLinks> ] [ no min-rx-links | min-rx-links <Ima::GroupMinNumRxLinks> ] [
near-end-ima-id <Ima::GroupTxImaId> ]
```

Command Parameters

Table 38.2-1 "IMA Group Configuration Commands" Resource Parameters

Resource Identifier	Type	Description
(if-index)	Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number	interface index of the port

Table 38.2-2 "IMA Group Configuration Commands" Command Parameters

Parameter	Type	Description
[no] activate	Parameter type: boolean	<i>optional parameter</i>
[no] admin-up	Parameter type: boolean	<i>optional parameter</i> admin status is up
[no] min-tx-links	Parameter type: <Ima::GroupMinNumTxLinks> Format: - a minimum number of transmit links required to be active - range: [1...8]	<i>optional parameter with default value: 1</i> the minimum number of transmit links
[no] min-rx-links	Parameter type: <Ima::GroupMinNumRxLinks> Format: - a minimum number of receive links required to be active - range: [1...8]	<i>optional parameter with default value: 1</i> the minimum number of receive links
near-end-ima-id	Parameter type: <Ima::GroupTxImaId> Format:	<i>optional parameter</i> the imd id used by the near-end

Parameter	Type	Description
	- an imd id used by the near-end ima function - range: [0...255]	ima function

38.3 IMA Link Configuration Commands

Command Description

This command allows the operator to manage the IMA link profile.

User Level

The command can be accessed by operators with xdsl privileges, and executed by operators with xdsl privileges.

Command Syntax

The command has the following syntax:

```
> configure ima ( no link (link-if-index) ) | ( link (link-if-index) grp-index <Itf::ImaLine> )
```

Command Parameters

Table 38.3-1 "IMA Link Configuration Commands" Resource Parameters

Resource Identifier	Type	Description
(link-if-index)	Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number	interface index of the port

Table 38.3-2 "IMA Link Configuration Commands" Command Parameters

Parameter	Type	Description
grp-index	Parameter type: <Itf::ImaLine> Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number	<i>mandatory parameter</i> logical interface number assigned to this IMA grp Link

39- L2CP Configuration Commands

39.1 L2CP Configuration Command Tree	39-1170
39.2 L2CP Configuration Command	39-1171
39.3 L2CP Session Configuration Command	39-1172
39.4 L2CP User Port Partition Configuration Command	39-1175

39.1 L2CP Configuration Command Tree

Description

This chapter gives an overview of nodes that are handled by "L2CP Configuration Commands".

Command Tree

```
----configure
----l2cp
  - [no] partition-type
  ----[no] session
    - (index)
    - bras-ip-address
    - [no] gsmp-version
    - [no] gsmp-sub-version
    - [no] encap-type
    - [no] topo-discovery
    - [no] layer2-oam
    - [no] alive-timer
    - [no] port-reprt-shaper
    - [no] aggr-reprt-shaper
    - [no] tcp-retry-time
    - [no] gsmp-retry-time
    - [no] dslam-name
    - [no] partition-id
    - [no] window-size
    - [no] tcp-port
    - [no] router-instance
    - [no] sig-partition-id
  ----[no] user-port
    - (user-port)
    - partition-id
```

39.2 L2CP Configuration Command

Command Description

This command allows the operator to configure the L2CP parameters.

User Level

The command can be accessed by operators with transport privileges, and executed by operators with transport privileges.

Command Syntax

The command has the following syntax:

```
> configure l2cp [ no partition-type | partition-type <L2cp::PartitionType> ]
```

Command Parameters

Table 39.2-2 "L2CP Configuration Command" Command Parameters

Parameter	Type	Description
[no] partition-type	Parameter type: <L2cp::PartitionType> Format: (no-partition fixed-assigned) Possible values: - no-partition : no partitioning is supported - fixed-assigned : partitioning is supported	<i>optional parameter with default value: "no-partition"</i> partition type

39.3 L2CP Session Configuration Command

Command Description

This command allows the operator to configure the L2CP session parameters for a given session id.

In current version, ISAM supports L2CP only on top of TCP/IP; as result of this command, ISAM shall start a TCP connection to a BRAS identified by a configured IP address. Then depending on the setting of the GSMP Retry Timer, the ISAM shall start the GSMP Adjacency Protocol to setup a L2CP session with that BRAS.

This means:

- *if TCP Retry Timer is zero, ISAM shall not start the TCP connection. If TCP Retry Timer is not zero, ISAM shall start the setup of a TCP connection to a BRAS whose IP address must be configured too. In no way the ISAM accepts that a (unknown) BRAS tries to start a TCP connection*
- *if GSMP Retry Timer is zero, ISAM shall not start the GSMP Adjacency Protocol but instead be prepared to handle GSMP Adjacency Protocol messages from that BRAS. If GSMP Retry Timer is not zero, ISAM shall start the GSMP Adjacency Protocol in addition to being prepared to handle GSMP Adjacency Protocol messages from that BRAS*

User Level

The command can be accessed by operators with transport privileges, and executed by operators with transport privileges.

Command Syntax

The command has the following syntax:

```
> configure l2cp ( no session (index) ) | ( session (index) bras-ip-address <L2cp::InetAddress> [ no gsmp-version |
gsmp-version <L2cp::Version> ] [ no gsmp-sub-version | gsmp-sub-version <L2cp::SubVersion> ] [ no encap-type |
encap-type <L2cp::EncapType> ] [ no topo-discovery | topo-discovery <L2cp::AccessTopologyDiscovery> ] [ no
layer2-oam | layer2-oam <L2cp::Layer2OAM> ] [ no alive-timer | alive-timer <L2cp::AliveTimer> ] [ no
port-reprt-shaper | port-reprt-shaper <L2cp::ReportShaper> ] [ no aggr-reprt-shaper | aggr-reprt-shaper
<L2cp::AggrReportShaper> ] [ no tcp-retry-time | tcp-retry-time <L2cp::TcpRetryTimer> ] [ no gsmp-retry-time |
gsmp-retry-time <L2cp::GsmprRetryTimer> ] [ no dslam-name | dslam-name <L2cp::DslamName> ] [ no
partition-id | partition-id <L2cp::PartitionId2> ] [ no window-size | window-size <L2cp::WindowSize> ] [ no
tcp-port | tcp-port <L2cp::InetPortNumber> ] [ no router-instance | router-instance <Ihub::RouterVplsMgmt> ] [ [ no
] sig-partition-id ] )
```

Command Parameters

Table 39.3-1 "L2CP Session Configuration Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - identity of the l2cp session - range: [1...255]	index to the l2cp session table

Table 39.3-2 "L2CP Session Configuration Command" Command Parameters

Parameter	Type	Description
bras-ip-address	Parameter type: <L2cp::InetAddress> Format: - IPv4-address	<i>mandatory parameter</i> The parameter is not visible during modification. IPv4 address used for the L2cp session peer
[no] gsmpp-version	Parameter type: <L2cp::Version> Format: - version of the GSMP protocol - range: [3]	<i>optional parameter with default value: 3</i> The parameter is not visible during modification. version of gsmpp protocol
[no] gsmpp-sub-version	Parameter type: <L2cp::SubVersion> Format: - sub version of the GSMP protocol - range: [1...2]	<i>optional parameter with default value: 1</i> The parameter is not visible during modification. sub version of gsmpp protocol
[no] encap-type	Parameter type: <L2cp::EncapType> Format: tcp Possible values: - tcp : tcp encapsulation type	<i>optional parameter with default value: "tcp"</i> The parameter is not visible during modification. encapsulation type
[no] topo-discovery	Parameter type: <L2cp::AccessTopologyDiscovery> Format: (disabled enabled) Possible values: - disabled : no topology discovery - enabled : topology discovery	<i>optional parameter with default value: "enabled"</i> The parameter is not visible during modification. topology discovery capability
[no] layer2-oam	Parameter type: <L2cp::Layer2OAM> Format: (disabled enabled) Possible values: - disabled : no layer2 oam - enabled : layer2 oam	<i>optional parameter with default value: "enabled"</i> The parameter is not visible during modification. layer2 OAM is supported
[no] alive-timer	Parameter type: <L2cp::AliveTimer> Format: - adjacency protocol watchdog alive time - unit: 100 msec - range: [1...255]	<i>optional parameter with default value: 250</i> adjacency protocol watchdog alive time.
[no] port-reprt-shaper	Parameter type: <L2cp::ReportShaper> Format: - time between two EventReport msgs related to same port, should be >= aggr-reprt-shaper - unit: 100 msec - range: [1...255]	<i>optional parameter with default value: 10</i> The parameter is not visible during modification. time between 2 EventReport msgs on the same port, should be >= aggr-reprt-shaper
[no] aggr-reprt-shaper	Parameter type: <L2cp::AggrReportShaper> Format: - time between two EventReport msgs related to any port - unit: 10 msec - range: [1...2550]	<i>optional parameter with default value: 10</i> The parameter is not visible during modification. time between 2 EventReport msgs on any port
[no] tcp-retry-time	Parameter type: <L2cp::TcpRetryTimer> Format: - time between 2 TCP connection setup attempts. - unit: 100 msec - range: [0...255]	<i>optional parameter with default value: 10</i> time between 2 TCP connection setup attempts

39 L2CP Configuration Commands

Parameter	Type	Description
[no] gsmpp-retry-time	Parameter type: <L2cp::GsmppRetryTimer> Format: - time between 2 GSMP/L2CP connection setup attempts. - unit: 100 msec - range: [0...255]	<i>optional parameter with default value: 10</i> time between 2 GSMP/L2CP connection setup attempts
[no] dslam-name	Parameter type: <L2cp::DslamName> Format: - a mac-address (example : 01:02:03:04:05:06) - length: 6	<i>optional parameter with default value: "00 : 00 : 00 : 00 : 00 : 00"</i> <i>The parameter is not visible during modification.</i> l2cp name of the DSLAM
[no] partition-id	Parameter type: <L2cp::PartitionId2> Format: - partition id - range: [0...127]	<i>optional parameter with default value: 0</i> <i>The parameter is not visible during modification.</i> identity for this session's specific DSLAM partition
[no] window-size	Parameter type: <L2cp::WindowSize> Format: - max no.of unacknow req msgs to be transmttd in a window - range: [10]	<i>optional parameter with default value: 10</i> <i>The parameter is not visible during modification.</i> max no.of unacknow req msgs to be transmitted in a window
[no] tcp-port	Parameter type: <L2cp::InetPortNumber> Format: - tcp port number - range: [0...65535]	<i>optional parameter with default value: 6068</i> <i>The parameter is not visible during modification.</i> tcp port number of the session established to the peer.
[no] router-instance	Parameter type: <Ihub::RouterVplsMgmt> Format: (base vpls-management <Ihub::L2cpRouter>) Possible values: - base : base router - vpls-management : vpls-management router Field type <Ihub::L2cpRouter> - vprn service-id - range: [1...2147483646]	<i>optional parameter with default value: "base"</i> <i>The parameter is not visible during modification.</i> router-instance to be used to obtain connectivity to the peer.
[no] sig-partition-id	Parameter type: boolean	<i>optional parameter</i> <i>The parameter is not visible during modification.</i> indicates if partition ID is signalled

39.4 L2CP User Port Partition Configuration Command

Command Description

This command allows the operator to configure the partition id for the given user-port.

User Level

The command can be accessed by operators with transport privileges, and executed by operators with transport privileges.

Command Syntax

The command has the following syntax:

```
> configure l2cp ( no user-port (user-port) partition-id <L2cp::PartitionId> ) | ( user-port (user-port) partition-id <L2cp::PartitionId> )
```

Command Parameters

Table 39.4-1 "L2CP User Port Partition Configuration Command" Resource Parameters

Resource Identifier	Type	Description
(user-port)	Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number	interface index of the DSL port
partition-id	Parameter type: <L2cp::PartitionId> Format: - partition id - range: [1...127]	partition id

40- Voice Configuration Commands

40.1 Voice Configuration Command Tree	40-1178
40.2 Voice Sip Server Configuration Commands	40-1191
40.3 Voice Sip Linelnd Syntax Profile Configuration Commands	40-1195
40.4 Voice Sip User Agent Configuration Commands	40-1197
40.5 Sip Voice Service Gateway Configuration Commands	40-1203
40.6 Voice Sip User Agent Access Point Configuration Command	40-1210
40.7 Voice Sip Dial Plan Configuration Commands	40-1213
40.8 Voice Sip Dial Plan Digitmap Configuration Commands	40-1215
40.9 Voice Sip Termination Configuration Commands	40-1216
40.10 Voice Sip Termination TCA Threshold Configuration Command	40-1224
40.11 Voice Sip Shared Line Termination Configuration Commands	40-1226
40.12 Sip Voice Register Configuration Commands	40-1229
40.13 Voice Sip Transport Configuration Commands	40-1231
40.14 Voice Sip Redundancy Table Configuration Commands	40-1233
40.15 Voice Sip System Session Timer Configuration Commands	40-1239
40.16 Voice Sip DNS Server Configuration Commands	40-1241
40.17 Voice Sip DHCP Authentication Params Configuration Commands	40-1243
40.18 Voice Sip Restoration Failover/Failback Type/Mode Configuration Commands	40-1245
40.19 Voice Statistics Configure Command	40-1247
40.20 Voice Statistics Mode Configuration Command	40-1248
40.21 Voice Sip Isdn/Cas Termination Configuration Commands	40-1250
40.22 Voice Sip Isdn/Cas Termination Configuration Commands	40-1258
40.23 Voice Sip Manipulation Rule Configuration Commands	40-1267
40.24 Voice Sip Cas R2 Timer Configuration Commands	40-1269
40.25 Voice Sip PUID Configuration Commands	40-1271
40.26 Voice Sip PUID Configuration Commands	40-1273
40.27 Voice Sip Isdn Nsm Profile Configuration Commands	40-1275
40.28 Voice Sip Cas Nsm Profile Configuration Commands	40-1278
40.29 Voice Sip Pri User To User Profile Configuration Commands	40-1280
40.30 Voice Sip Isdn/Cas trunk sub-group Configuration Commands	40-1282
40.31 Voice Sip Physical Interface Configuration Commands	40-1285
40.32 Voice Sip Cas Signaling Profile Configuration Commands	40-1289
40.33 Central Access Point Table Configuration	40-1292

Commands	
40.34 Central Access Point Table Configuration	40-1294
Commands	
40.35 Voice Sip Cas Timer Profile Configuration	40-1296
Commands	
40.36 Network Element Table Configuration Commands	40-1301
40.37 Voice Sip Call Query Configuration Commands	40-1303
40.38 Voice Cluster Configuration Commands	40-1305
40.39 Voice Megaco IP Configuration Commands	40-1306
40.40 Voice Megaco Equipment Configuration Commands	40-1308
40.41 Voice Megaco Equipment Board Configuration	40-1310
Commands	
40.42 Voice Megaco Equipment Termination Configuration	40-1312
Commands	
40.43 Voice Megaco Termination Configuration	40-1316
Commands	
40.44 Voice Megaco Termination Lawful Intercept	40-1318
Configuration Commands	
40.45 Voice Megaco Equipment Secondary Termination	40-1320
Configuration Commands	
40.46 Voice Megaco Media Gateway Configuration	40-1322
Commands	
40.47 Voice Megaco Signal Gateway Configuration	40-1333
Commands	
40.48 Epon Ont Voice SIP UserAgent Configuration	40-1335
40.49 Epon Ont Pots Configuration Command	40-1338
40.50 Epon Ont Voice Common Configuration Command	40-1340
40.51 Epon Ont Voice media gateway Configuration	40-1343
Command	
40.52 Voice Sip LSA Server Configuration Commands	40-1346
40.53 Voice Sip LSA Server Configuration Commands	40-1348
40.54 Voice Sip LSA Server Emergency Service	40-1351
Configuration Commands	
40.55 Voice extline Configuration Commands	40-1353
40.56 Voice Pseudo Wire Configuration Commands	40-1357

40.1 Voice Configuration Command Tree

Description

This chapter gives an overview of nodes that are handled by "Voice Configuration Commands".

Command Tree

```
----configure
  ----voice
    ----sip
      ----[no] server
        - (name)
        - [no] admin-status
        - address
        - [no] port
        - [no] server-role
        - [no] priority
        - [no] weight
        - [no] site
        - [no] transproto
        - [no] dnsname-type
        - admin-domain-name
        - [no] tls-port
        - [no] tls-cafile
      ----lineid-syn-prof
        - (name)
        - [no] syntax-pattern
        - [no] pots-syntax
        - [no] isdn-syntax
        - [no] cas-r2-syntax
        - [no] cas-r1-syntax
      ----[no] user-agent
        - (name)
        - [no] ip-addr-policy
        - [no] ip-config-mode
        - [no] signal-gateway-ip
        - signal-vlan-id
        - [no] signal-dscp
        - [no] signal-pbits
        - [no] signal-link-mtu
        - [no] rtp-gateway-ip
        - [no] rtp-vlan-id
        - [no] rtp-dscp
        - [no] rtp-pbits
        - [no] rtp-link-mtu
        - [no] dhcp-optreq-list
        - [no] admin-status
        - [no] provider-name
        - [no] lsa-rtp-gw-ip
        - [no] lsa-rtp-vlan-id
        - [no] lsa-md5-realm
        - [no] lsa-md5-password
```

- [no] rtp-ipv6-gateway
- [no] rtp-ipv6-vlan-id
- [no] rtp-ipv6-dscp
- [no] rtp-ipv6-pbits
- [no] rtp-ipv6-link-mtu

----[no] vsp

- **(name)**
- domain-name
- [no] admin-status
- [no] tinfo
- [no] ta4
- [no] ttir1
- [no] t-acm-delta
- [no] access-held-time
- [no] awaiting-time
- [no] digit-send-mode
- [no] overlap-484-act
- [no] dmpm-intdgt-expid
- [no] dial-start-timer
- [no] dial-long-timer
- [no] dial-short-timer
- [no] uri-type
- [no] rfc2833-pl-type
- [no] rfc2833-process
- [no] min-data-jitter
- [no] init-data-jitter
- [no] max-data-jitter
- [no] release-mode
- [no] dyn-pt-nego-type
- [no] vbd-g711a-pl-type
- [no] vbd-g711u-pl-type
- [no] vbd-mode
- [no] warmline-dl-timer
- timer-b
- timer-f
- timer-t1
- timer-t2
- [no] reg-sub
- [no] dtmf-sip-info
- [no] sub-period
- [no] sub-head-start
- [no] t38-same-udp
- [no] dhcp-option82
- [no] sspprofile
- [no] signaling-ipmode
- [no] tls-cafile
- [no] media-ipmode

----user-agent-ap

- **(ua-name)**
- **slot-id**
- signal-ip
- [no] rtp-ip
- [no] dhcp-fqdn
- [no] dhcp-customer-id
- [no] admin-status
- [no] lsa-rtp-ip
- [no] rtp-ipv6-address

----[no] dialplan

- **(name)**
- [no] pre-activated
- [no] static-prefix
- [no] static-suffix
- [no] digitmap-mode
- [no] provider-name
- [no] digitmap**
- **(name)**
- **type**
- **rule**
- [no] access-type
- [no] termination**
- **(if-index)**
- [no] directory-number
- [no] user-name
- [no] display-name
- [no] uri
- [no] direct-uri
- [no] line-feed
- [no] md5-realm
- [no] md5-password
- [no] aka-secret-key
- [no] admin-status
- [no] clip-mode
- [no] telc-clip-mode
- [no] anti-tapping
- [no] impedance
- [no] rx-gain
- [no] tx-gain
- [no] warmline-service
- [no] linesig-remanswer
- [no] line-id
- [no] force-hold
- [no] callwait-service
- [no] callhold-service
- [no] callconf-service
- [no] calltras-service
- [no] fast-guard
- [no] clear-forward
- [no] testaccessstate
- [no] busyoverwrite
- [no] accessontimeout
- [no] provider-name
- [no] register_recall
- [no] sip-rule-set
- [no] reserved
- [no] pulse-dialing
- [no] auto-answer
- tca**
- [no] enable
- [no] high-jbfl
- [no] low-jbfl
- [no] sharedline**
- **(if-index)**
- [no] directory-number
- [no] user-name
- [no] display-name
- [no] uri

```

- [no] admin-status
- [no] clip-mode
- [no] callwait-service
- [no] callhold-service
- [no] callconf-service
- [no] calltras-service
----register
- (provider-name)
- [no] register-uri
- [no] register-intv
- [no] reg-retry-intv
- [no] reg-prev-ava-intv
- [no] reg-head-start
- [no] reg-start-min
- [no] init-reg-delay
----[no] transport
- (trans-protocol)
- provider-name
- [no] admin-status
- [no] port-rcv
- [no] tcp-idle-time
- [no] max-out-udp-size
- [no] tls-port-rcv
----redundancy
- (admin-domain-name)
- [no] support-redun
- [no] dns-purge-timer
- [no] dns-ini-retr-int
- [no] dns-max-retr-nbr
- [no] fg-monitor-method
- [no] fg-monitor-int
- [no] bg-monitor-method
- [no] bg-monitor-int
- [no] stable-obs-period
- [no] fo-hystersis
- [no] del-upd-threshold
- [no] auto-server-fo
- [no] auto-server-fb
- [no] auto-sos-fo
- [no] auto-sos-fb
- [no] rtry-after-thrsh
- [no] options-max-fwd
- [no] dns-redun-mode
- [no] fail-obs-timer
- [no] fg-intv-503
- [no] time-thrsh-503
- [no] nbr-thrsh-503
- [no] auto-srv-fo-timer
----system
----session-timer
X [no] enable
- [no] status
- [no] min-se-time
- [no] se-time
- [no] admin-status
----[no] dnsserver
- (name)
- [no] admin-status
- address

```

- [no] priority
- [no] site
- admin-domain-name
- [no] port
- [no] dhcp-authent-para
 - (ua-name)
 - secret-id
 - [no] key
 - [no] action-type
- redundancy-cmd
 - (domain-name)
 - [no] start-time
 - [no] end-time
 - fail-x-type
- statistics
 - [no] stats-5min-config
 - [no] cdr-config
- stats-config
 - [no] per-line
 - [no] per-board
 - [no] per-system
 - [no] per-call
 - [no] out-any-rsp
 - [no] out-180-rsp
 - [no] out-200-rsp
 - [no] in-any-rsp
 - [no] in-180-rsp
 - [no] in-200-rsp
- [no] isdn-cas-term
 - (if-index)
 - [no] directory-number
 - [no] user-name
 - [no] display-name
 - [no] uri
 - [no] md5-realm
 - [no] md5-password
 - [no] aka-secret-key
 - [no] admin-status
 - [no] line-id
 - [no] testaccessstate
 - [no] busyoverwrite
 - [no] accessontimeout
 - [no] provider-name
 - [no] signalling-type
 - [no] cpn-screen
 - [no] default-cpc
 - [no] restrict-acc
 - [no] hunting-way
 - [no] sip-rule-set
 - [no] cas-exch-type
 - [no] q-value
 - [no] reg-mode
 - [no] e1-hunting-way
 - [no] e1-cluster-itf
 - [no] e1-cluster-name
 - [no] isdn-nsm-profile
 - [no] cas-nsm-profile
- [no] pri-cas-tnsg-term

- **(if-index)**
- **tksg-id**
- [no] directory-number
- [no] user-name
- [no] display-name
- [no] uri
- [no] realm
- [no] password
- [no] aka-secret-key
- [no] admin-status
- [no] line-id
- [no] provider-name
- [no] ds0-hunting-way
- [no] itf-hunting-way
- [no] sip-rule-set
- [no] q-value
- [no] reg-mode
- [no] extension
- trunk-group-name
- [no] signalling-type
- [no] cas-cpn-screen
- [no] cas-default-cpc
- [no] cas-restrict-acc
- [no] cas-exch-type
- [no] isdn-nsm-profile
- [no] cas-nsm-profile
- [no] uus-profile
- [no] cas-timer-profile
- [no] manipulate-rule**
- **(rule-id)**
- [no] admin-status
- [no] rule-name
- rule
- [no] rule-type
- cas-r2-timer**
- **(if-index)**
- [no] seizure-ack
- [no] disconnect-ack
- [no] force-rel-ack
- [no] pres-fwd-sig
- [no] receipt-fwd-sig
- [no] re-answer
- [no] call-process
- [no] isdn-cas-cls-puid**
- **(name)**
- **directory-number**
- [no] user-name
- [no] uri
- [no] md5-password
- [no] aka-secret-key
- [no] display-name
- [no] pri-cas-tks-g-puid**
- **(if-index)**
- **tksg-id**
- **directory-number**
- [no] user-name
- [no] uri
- [no] password
- [no] aka-secret-key

- [no] display-name
- [no] **isdn-nsm-prof**
 - **(prof-name)**
 - [no] version-nbr
 - [no] outg-from-no-cgpn
 - [no] outg-privacy
 - [no] outg-from-pi
 - [no] inc-from-noclip
 - [no] inc-from-clip-pri
 - [no] inc-from-clip-ua
 - [no] inc-npi-to-cpn
 - [no] inc-ton-to-cpn
 - international-prefix
 - [no] national-prefix
 - country-code
 - outg-cpn-length
 - [no] inc-cgpn-add-ac
 - [no] inc-ton-to-cdpn
- [no] **cas-nsm-prof**
 - **(prof-name)**
 - [no] version-nbr
 - [no] outg-from-no-cgpn
 - international-prefix
 - [no] national-prefix
 - country-code
 - outg-cpn-length
- [no] **user-to-user-prof**
 - **(prof-name)**
 - [no] version-nbr
 - [no] service-type
 - [no] act-estab-call
 - [no] act-stable-call
 - [no] uus3-t1-timer
- [no] **tksg**
 - **(if-index)**
 - **tksg-id**
 - **interface**
 - tksg-name
 - ds0-bitmap
 - [no] admin-status
 - [no] ds0-hunting-way
- [no] **phys-itf**
 - **(if-index)**
 - [no] admin-status
 - [no] interface-type
 - [no] signalling-type
 - [no] e1-crc4frame
 - [no] t1-framemode
 - [no] t1-tx-linecode
 - [no] t1-rx-linecode
 - [no] t1-lbo-value
 - [no] blocking-bitmap
 - [no] cap-name
 - [no] cas-sig-prof
- [no] **cas-sig-prof**
 - **(prof-name)**
 - [no] version-nbr
 - [no] idle
 - [no] seize

- [no] seize-ack
- [no] answer
- [no] fw-disconnect
- [no] fw-disconnect-ack
- [no] bw-disconnect
- [no] bw-disconnect-ack
- [no] fault
- [no] block
- [no] meter
- [no] reject-call
- [no] bw-disc-reanswer
- [no] **cap**
 - **(cap)**
 - [no] cap-name
 - [no] ne-name
 - [no] mode
 - [no] location
 - [no] admin-status
 - [no] ip
 - [no] udp-port
 - [no] gateway-ip
 - [no] provider-name
- [no] **ne-board**
 - **cap-id**
 - **ne-id**
 - **board**
 - [no] admin-status
 - xhub-port
- [no] **cas-timer-prof**
 - **(prof-name)**
 - [no] version-nbr
 - appl-bitmap
 - [no] seize-ack
 - [no] clear-back-ack
 - [no] clear-fw-ack
 - [no] presence-fw-sig
 - [no] receipt-fw-sig
 - [no] re-answer
 - [no] call-process
 - [no] delay-dial-min
 - [no] delay-dial-max
 - [no] seize-state-time
 - [no] reg-recall-min
 - [no] reg-recall-max
 - [no] decadic-pulse-dur
 - [no] decadic-break-dur
 - [no] inter-digit-peri
 - [no] ring-fw
 - [no] receipt-nbr-rcvd
 - [no] meter-pulse-dur
- [no] **network-element**
 - **cap-id**
 - **ne-id**
 - ne-name
 - [no] role
 - [no] admin-status
 - [no] ip
 - [no] vlan-id
- [no] **call-query**

- (id)
- [no] timeout-period
- target-dn
- [no] remote-dn
- [no] type
- cluster
- (cluster-id)
- ip
- [no] ivps-ip
- [no] netmask
- [no] router-ip
- vlan-id
- [no] ip-mode
- [no] dhcpoption60
- [no] private-ip
- [no] private-netmask
- [no] private-vlan-id
- [no] equipment
- (equip-id)
- asam-id
- ip-address
- [no] next-hop
- [no] board
- (board-id)
- planned-type
- lanx-port
- [no] termination
- (port-id)
- [no] type
- [no] isdn-codec
- [no] switch-type
- [no] activate-type
- termination-id
- media-gateway-id
- [no] admin-status
- [no] line-feed
- [no] rx-gain
- [no] tx-gain
- [no] impedance
- [no] rtp-dscp
- [no] rtp-pbits
- [no] clip-mode
- [no] metering-type
- [no] directory-number
- [no] voice-service
- [no] reserved
- tca
- [no] tca-enable
- [no] rtp-pktloss-thres
- [no] rtp-jitter-thres
- [no] rtp-delay-thres
- [no] li
- [no] state
- src-port
- dest-ip
- dest-port
- [no] sharedlineterm
- (port-id)
- sharedlineterm-id

```

- [no] admin-status
- [no] directory-number
- [no] voice-service
----[no] media-gateway
- (media-gateway-id)
- [no] name
- [no] ip-mode
- [no] dhcption60
- [no] ip-address
- [no] netmask
- [no] udp-port
- [no] router-ip
- [no] vlan-id
- [no] mgc-type
- [no] prim-mgc-ip
- [no] mgc-id
- [no] prim-mgc-udp
- [no] sec-mgc-ip
- [no] sec-mgc-udp
- [no] tert-mgc-ip
- [no] tert-mgc-udp
- [no] quat-mgc-ip
- [no] quat-mgc-udp
- [no] esa-mgc-service
- [no] mg-mid-type
- [no] mg-domain-name
- [no] svcreason-format
- [no] mg-profile-name
- [no] admin-status
- [no] termid-type
- [no] pstn-term-format
- [no] isdn-term-format
- [no] isdn-suffix1
- [no] isdn-suffix2
- [no] max-transhandling
- [no] max-network-delay
- [no] max-retrans
- [no] red-bat-delay
- [no] release-delay
- [no] release-type
- [no] wt-rls-delay
- [no] active-heartbeat
- [no] passive-heartbeat
- [no] retrans
- [no] max-waiting-delay
- [no] prov-rpl-time
- [no] signal-dscp
- [no] signal-pbits
- [no] rtp-dscp
- [no] rtp-pbits
- [no] event-req-id
- [no] stml-stdsg-evt
- [no] al-of-evt
- [no] al-on-evt
- [no] al-of-strict-evt
- [no] al-on-strict-evt
- [no] mg-overload-evt
- [no] mg-dummy-evt

```

- [no] rfc2833-pl-type
- [no] rfc2833-process
- [no] dial-start-timer
- [no] dial-long-timer
- [no] dial-short-timer
- [no] min-data-jitter
- [no] init-data-jitter
- [no] max-data-jitter
- [no] ephe-term-prefix
- [no] ephe-term-min
- [no] ephe-term-max
- [no] **signal-gateway**
 - **(signal-gateway-id)**
 - prim-asp-ip
 - prim-sctp-port
 - [no] sec-asp-ip
 - [no] sec-sctp-port
 - [no] tert-asp-ip
 - [no] tert-sctp-port
 - [no] quat-asp-ip
 - [no] quat-sctp-port
 - ip-address
 - sgi-user-label
 - sgi-mgi
 - [no] admin-status
- eont**
 - [no] **sip-useragent**
 - **(ont-idx)**
 - [no] udp-port
 - proxy-pri-ip
 - [no] proxy-pri-port
 - proxy-sec-ip
 - [no] proxy-sec-port
 - reg-pri-ip
 - [no] reg-pri-port
 - reg-sec-ip
 - [no] reg-sec-port
 - outbound-ip
 - [no] outbound-port
 - [no] reg-intval
 - [no] heartbeat-mode
 - [no] heartbeat-cycle
 - [no] heartbeat-count
 - digit-map-prof
 - [no] **pots**
 - **(uni-idx)**
 - [no] admin-up
 - [no] user-account
 - [no] user-name
 - [no] user-pwd
 - tid-name
 - [no] **comm-para**
 - **(ont-idx)**
 - [no] ip-mode
 - ip
 - mask
 - gateway
 - [no] ppoe-mode

- [no] pppoe-username
- [no] pppoe-pwd
- [no] tagged-mode
- cvlan
- [no] svlan
- [no] pbit
- [no] t38-admin
- [no] fax
- [no] media-gateway
 - (ont-idx)
 - [no] udp-port
 - mgc-pri-ip
 - [no] mgc-pri-port
 - [no] mgc-sec-ip
 - [no] mgc-sec-port
 - [no] reg-mode
 - gw-id
 - [no] heartbeat-mode
 - [no] heartbeat-cycle
 - [no] heartbeat-count
 - tid-num
 - tid-prefix
 - tid-digit-begin
 - tid-mode
 - tid-digit-len
- lsa-server
 - [no] system
 - (name)
 - slot-id
 - country-code
 - area-code
 - [no] admin-status
 - [no] instance
 - (name)
 - slot-id
 - sign-ip
 - [no] sign-port
 - sign-vlan
 - [no] sign-gw-ip
 - [no] admin-status
 - [no] sg-name
 - [no] lsa-md5-realm
 - [no] lsa-md5-password
 - [no] emergency-service
 - dn
 - gateway-dn
 - slot-id
 - [no] name
 - [no] sg-name
 - [no] gateway-ddidn
 - [no] gateway-dn-type
 - [no] extline
 - (if-index)
 - local-ip
 - [no] gateway-ip
 - [no] ip-addr-policy
 - vlan-id
 - fxo-ip
 - fxo-port

- [no] admin-status
- [no] codec
- [no] ptime
- [no] echo-cancel
- [no] silence-suppr
- [no] impedance
- [no] rx-gain
- [no] tx-gain
- [no] dscp
- [no] pbits
- [no] pseudo-wire
- (if-index)
- channelset
- [no] ip-addr-policy
- local-ip
- dest-ip
- dest-udp-port
- [no] gateway-ip
- vlan-id
- [no] p-bits
- [no] dscp
- [no] admin-status
- [no] data-jitter
- p-time
- [no] payload-type

40.2 Voice Sip Server Configuration Commands

Command Description

This command allows the operator to manage the Voice Sip Server profile.

IPv6 is actually not supported. All references to IPv6 must be ignored since mentioned for future usage only.

User Level

The command can be accessed by operators with sip privileges, and executed by operators with sip privileges.

Command Syntax

The command has the following syntax:

```
> configure voice sip ( no server (name) ) | ( server (name) [ no admin-status | admin-status
<Sip::ServerAdminStatus> ] address <Sip::ServerAddr> [ no port | port <Sip::ServerPort> ] [ no server-role |
server-role <Sip::ServerRole> ] [ no priority | priority <Sip::ServerPriority> ] [ no weight | weight
<Sip::ServerWeight> ] [ no site | site <Sip::ServerSite> ] [ no transproto | transproto <Sip::ServerTransproto> ] [ no
dnsname-type | dnsname-type <Sip::DnsDomNameType> ] admin-domain-name <Sip::AdminDomName> [ no
tls-port | tls-port <Sip::ServerPort> ] [ no tls-cafile | tls-cafile <Sip::ServerCAFileName> ] )
```

Command Parameters

Table 40.2-1 "Voice Sip Server Configuration Commands" Resource Parameters

Resource Identifier	Type	Description
(name)	Format: - uniquely identifies this voice server - length: x<=32	uniquely identify of this voice server

Table 40.2-2 "Voice Sip Server Configuration Commands" Command Parameters

Parameter	Type	Description
[no] admin-status	Parameter type: <Sip::ServerAdminStatus> Format: (up down) Possible values: - up : unlock the sip server - down : lock the sip server	<i>optional parameter with default value: "down"</i> administrative status of this sip server
address	Parameter type: <Sip::ServerAddr> Format: (ipv4 : <Ip::V4Address> ipv6 : <Ip::V6Address> dns : <Sip::ServerAddr>) Possible values: - ipv4 : the address type of the server is IPv4 - ipv6 : the address type of the server is IPv6 - dns : the address type of the server is DNS	<i>mandatory parameter</i> The address(IPv4 or IPv6 or DNS or FQDN) of this SIP server

Parameter	Type	Description
	Field type <Ip::V4Address> - IPv4-address Field type <Ip::V6Address> - IPv6-address Field type <Sip::ServerAddr> - name of the SipServer that can be resolved to an IP address via a DNS Server - length: 7<=x<=64	
[no] port	Parameter type: <Sip::ServerPort> Format: - the SIP server port - range: [1...65534]	<i>optional parameter with default value: 5060</i> port of voice server
[no] server-role	Parameter type: <Sip::ServerRole> Format: (proxy-server registrar-server registrar-and-proxy lsa-server) Possible values: - proxy-server : proxy server - registrar-server : registrar server - registrar-and-proxy : served as a registrarServer and a proxyServer - lsa-server : served as a LSAServer	<i>optional parameter with default value: "proxy-server"</i> The role of voice application server. When redundancy is DISABLED, the operator can configure 4 different server roles, role = Proxy server, role = Registrar server, role = Proxy server AND Registrar server, role = LSA server. System will behave in accordance with configured role. When redundancy is ENABLED, the system always assume role = Proxy server AND Registrar server, irrespective of what has been configured by the operator. Thus the system always behaves according to the role = proxyAndRegistrarServer(20), and does not look at the value been configured by the operator
[no] priority	Parameter type: <Sip::ServerPriority> Format: - the SIP server priority - range: [0...65535]	<i>optional parameter with default value: 100</i> The priority of voice application server
[no] weight	Parameter type: <Sip::ServerWeight> Format: - the SIP server weight - range: [0...65535]	<i>optional parameter with default value: 100</i> The weight of voice application server
[no] site	Parameter type: <Sip::ServerSite> Format: (primary-site geo-backup-site sos-backup-site) Possible values: - primary-site : the server belongs to the GEO primary site - geo-backup-site : the server belongs to the GEO secondary site - sos-backup-site : the server belongs to the SOS secondary site	<i>optional parameter with default value: "primary-site"</i> The site of voice application server
[no] transproto	Parameter type: <Sip::ServerTransproto> Format: (udp tcp	<i>optional parameter with default value: "udp"</i> The transport protocol of voice application server

Parameter	Type	Description
	udp_tcp tls_over_tcp udp_tls tcp_tls udp_tcp_tls udp_swo_tcp) Possible values: - udp : the transport protocol used in connecting to the server is UDP - tcp : the transport protocol used in connecting to the server is TCP - udp_tcp : the transport protocol used in connecting to the server is TCP or UDP, TCP is the preferred transport protocol - tls_over_tcp : the transport protocol used in connecting to the server is TLSSoTCP - udp_tls : the transport protocol used in connecting to the server is UDP or TLSSoTCP. TLSSoTCP is the preferred transport protocol - tcp_tls : the transport protocol used in connecting to the server is TCP or TLSSoTCP. TLSSoTCP is the preferred transport protocol - udp_tcp_tls : the transport protocol used in connecting to the server is UDP, TCP or TLSSoTCP. TLSSoTCP is the preferred transport protocol. The next preferred transport protocol is TCP and finally UDP. If UDP would be used and the size of the message exceeds a configured threshold then a switch can be made to TCP - udp_swo_tcp : the transport protocol used in connecting to the server is UDP or TCP, when size of message exceeds a configured threshold will switchover to TCP	
[no] dnsname-type	Parameter type: <Sip::DnsDomNameType> Format: (none dn fqdn) Possible values: - none : If sipServerAddrType is provisioned with value ipv4 or ipv6, this object should set to none - dn : If sipServerAddrType is provisioned with value dns, it means the sipserver address is provisioned with DNS. - fqdn : If sipServerAddrType is provisioned with value dns, it means the sipserver address is provisioned with FQDN.	<i>optional parameter with default value: "none"</i> The clarification of whether a Domain Name (dn) or Fully qualified Domain Name (fqdn) was provisioned for the object sipServerAddr.
admin-domain-name	Parameter type: <Sip::AdminDomName> Format: - uniquely name of this element - length: x<=32	<i>mandatory parameter</i> The administrative domain name of the (farm of) SIP First hop(s). The administrative domain might be the VoIP Access Seeker Network or the Connectivity Serving Network.
[no] tls-port	Parameter type: <Sip::ServerPort> Format: - the SIP server port - range: [1...65534]	<i>optional parameter with default value: 5061</i> TLSSoTCP port of voice server
[no] tls-cafile	Parameter type: <Sip::ServerCAFileName> Format: - the ca file name	<i>optional parameter with default value: ""</i> The name of the Certification

40 Voice Configuration Commands

Parameter	Type	Description
	- length: x<=13	Authority (CA) file that applies when TLSoTCP used as underlying transport protocol for SIP

40.3 Voice Sip LineId Syntax Profile Configuration Commands

Command Description

This command allows the operator to manage the Voice Sip LineId Syntax profile. This command can help operator to get different types of sip termination contact-user-info: physicallineid or terminationuriordn. If the syntax is 'physicalLineId', then the system will construct a value according the syntax as specified in the next parameters (depending of the type of line being pots or isdn). In case the value is 'terminationuriordn', then the value will be taken from the corresponding parameter of the SipTermination object (chapter 38.9); the uri will be taken firstly if it is valid, otherwise the dn can be taken. The keywords apply to the profile syntax include: "Access_Node_ID", "Rack", "Frame", "Slot", "ShSlT", "Port", "ShPrt", "Channel". The sip termination contact-user-info can be learned using the show command: show voice sip termination.

User Level

The command can be accessed by operators with sip privileges, and executed by operators with sip privileges.

Command Syntax

The command has the following syntax:

```
> configure voice sip lineid-syn-prof (name) [ no syntax-pattern | syntax-pattern <SIP::LineIdSyntaxPattern> ] [ no pots-syntax | pots-syntax <SIP::PotsSyntax> ] [ no isdn-syntax | isdn-syntax <SIP::IsdnSyntax> ] [ no cas-r2-syntax | cas-r2-syntax <SIP::CasR2Syntax> ] [ no cas-r1-syntax | cas-r1-syntax <SIP::CasR1Syntax> ]
```

Command Parameters

Table 40.3-1 "Voice Sip LineId Syntax Profile Configuration Commands" Resource Parameters

Resource Identifier	Type	Description
(name)	Format: - the lineid syntax profile name, can only be profile1 - length: x<=32	uniquely identify of this lineid syntax profile, can only be profile1

Table 40.3-2 "Voice Sip LineId Syntax Profile Configuration Commands" Command Parameters

Parameter	Type	Description
[no] syntax-pattern	Parameter type: <SIP::LineIdSyntaxPattern> Format: (rregisterdialog rregister physicallineid terminationuriordn) Possible values: - rregisterdialog : random per register and dialog - rregister : random per register - physicallineid : physical line id - terminationuriordn : termination uri	optional parameter with default value: "terminationuriordn" pattern of the sip LineID Syntax

40 Voice Configuration Commands

Parameter	Type	Description
[no] pots-syntax	Parameter type: <SIP::PotsSyntax> Format: - syntax of the POTS SIP LineID - length: x<=128	<i>optional parameter with default value:</i> "a/Channel/Port/Slot/Frame/Rack/AccessID/syntax of the Pots sip LineID
[no] isdn-syntax	Parameter type: <SIP::IsdnSyntax> Format: - syntax of the ISDN SIP LineID - length: x<=128	<i>optional parameter with default value:</i> "pra/Channel/Port/Slot/Frame/Rack/AccessID/syntax of the Isdn sip LineID
[no] cas-r2-syntax	Parameter type: <SIP::CasR2Syntax> Format: - syntax of the Cas R2 SIP LineID - length: x<=128	<i>optional parameter with default value:</i> "r2/Channel/Port/Slot/Frame/Rack/AccessID/syntax of the Cas R2 sip LineID
[no] cas-r1-syntax	Parameter type: <SIP::CasR1Syntax> Format: - syntax of the Cas R1 SIP LineID - length: x<=128	<i>optional parameter with default value:</i> "r1/Channel/Port/Slot/Frame/Rack/AccessID/syntax of the Cas R1 sip LineID

40.4 Voice Sip User Agent Configuration

Commands

Command Description

This command allows the operator to manage the Voice Sip user agent profile.

DESCRIPTION FOR THE COMMAND PARAMETER ip-addr-policy:

- The parameter allows to configure the internal ip address policy of the voice node can be set to the values 'distributed' or 'centralized'.

DISTRIBUTED: Each of the voice LT boards owns (a) different IP address(es) for the signaling and media plane.

- This mode isn't applicable to NGVR and ANSI MDU equipment i.e. only applicable to ISAM FD and ISAM FX equipment.
- In case the distinct VLAN approach applies, each of the voice LT boards owns 2 IP addresses i.e. a signaling IP address and a media IP address and these are different IP addresses. It is mandatory to configure for each of the SIP User Access Points a signaling and media IP address.
- In case the shared VLAN approach applies, each of the voice LT boards owns a single IP address i.e. the signaling IP address and the media IP address are the same. It is mandatory to configure for each of the SIP User Access Points a shared signaling and media IP address.

CENTRALIZED: All voice LT boards shared the same IP address(es) for the signaling and media plane.

- ISAM FD and ISAM FX equipment: the configuration of the signaling and media IP addresses in the SIP User Agent Points is optional. If configured and the distinct VLAN approach applies, all SIP User Agent points share the same signaling IP address and all SIP User Agent Access points share the same media IP address. The signaling IP address and the media IP address are the same as configured at the xHUB. The IP address of the signaling and the IP address of the media plane are different. If configured and the shared VLAN approach applies, then all SIP User Agent Access points must be configured with the same shared signaling/media IP address.
- NGVR and ANSI MDU equipment: the configuration of the signaling and media IP address in the SIP User Agent Access Point is mandatory. In case the distinct VLAN approach applies, the signaling and media plane own a different IP address. In case the shared VLAN approach applies, the signaling and media plane share the same IP address.

DESCRIPTION FOR THE COMMAND PARAMETER ip-config-mode:

- The parameter allows to configure the configuration mode of the IP related data required by the SIP User Agent, the SIP User Agent Access Point, the SIP server and the DNS server management entities and can be set to the values 'dhcp' or 'manual'.

DHCP: The IP related data is acquired from the DHCP server.

- ISAM FD and ISAM FX equipment: this mode can only be set when (1) the parameter ip-addr-policy is configured as 'distributed' and (2) the shared signaling/media VLAN approach applies.
- NGVR and ANSI MDU equipment: this mode can only be set when the shared signaling/media VLAN approach applies.

MANUAL: The IP related data must be manually configured.

DESCRIPTION FOR THE COMMAND PARAMETER signal-gateway-ip:

- The parameter allows to configure the IPv4 or IPv6 address of the signalling IP gateway.
- ISAM FD and ISAM FX equipment: A mandatory input when the parameter ip-config-mode is configured as 'manual' and the parameter ip-addr-policy is configured as 'distributed'.
- NGVR and ANSI MDU equipment: A mandatory input when the parameter ip-config-mode is configured as

'manual'.

DESCRIPTION FOR THE COMMAND PARAMETER rtp-gateway-ip:

- *The parameter that allows to configure the IPv4 address of the media IP gateway.*
- *ISAM FD and ISAM FX equipment: A mandatory input parameter when the parameter ip-config-mode is configured as 'manual' and the parameter ip-addr-policy is configured as 'distributed' and the distinct VLAN approach applies. In case of the shared VLAN approach, the value configured for the parameter signal-gateway-ip is inherited.*
- *NGVR and ANSI MDU equipment: A mandatory input parameter when parameter ip-config-mode is configured as 'manual' and the distinct VLAN approach applies. In case of the shared VLAN approach, the value configured for the parameter signal-gateway-ip is inherited.*

DESCRIPTION FOR THE COMMAND PARAMETER rtp-link-mtu:

- *The parameter allows to configure the link mtu of the IPv4 media vlan. Only relevant in case of the distinct signaling/media VLAN approach. In case of the shared signaling/media VLAN approach, the value configured for the parameter signal-link-mtu is inherited.*

DESCRIPTION FOR THE COMMAND PARAMETER dhcp-optreq-list:

- *The parameter allows to configure the list of DHCPv4 options the SIP User Agent wants the DHCPv4 server to return in option 55.*
- *ISAM FD and ISAM FX equipment: only relevant in case the parameter ip-config-mode is configured as 'dhcp' (parameter ip-addr-policy is configured as 'distributed' and the shared signaling/media VLAN approach applies).*
- *NGVR and ANSI MDU equipment: only relevant in case the parameter ip-config-mode is configured as 'dhcp' (parameter ip-addr-policy is configured as 'centralized' and the shared signaling/media VLAN approach applies).*

DESCRIPTION FOR THE COMMAND PARAMETER lsa-md5-realm:

- *The parameter allows to configure the realm to be used for the registration of SIP terminations to the LSA server.*
- *The parameter lsa-md5-realm must be configured with the same value as configured for the parameter lsa-md5-realm of the LSA server instance.*

DESCRIPTION FOR THE COMMAND PARAMETER lsa-md5-password:

- *The parameter allows to configure the password to be used for the registration of SIP terminations to the LSA server.*
- *The parameter lsa-md5-password must be configured with the same value as configured for the parameter lsa-md5-password of the LSA server instance.*

DESCRIPTION FOR THE COMMAND PARAMETER rtp-ipv6-gateway:

- *The parameter allows to configure the IPv6 address of the media IP gateway.*
- *ISAM FD and ISAM FX equipment: A mandatory input parameter when (1) the parameter media-ipmode is configured as 'ipv6' and (2) the parameter ip-config-mode is configured as 'manual' and (3) the parameter ip-addr-policy is configured as 'distributed' and (4) the distinct VLAN approach applies. In case of the shared VLAN approach, the parameter rtp-ipv6-gateway inherits the value configured for the parameter signal-gateway-ip.*
- *NGVR and ANSI MDU equipment: A mandatory input parameter when (1) the parameter media-ipmode is configured as 'ipv6' and (2) the parameter ip-config-mode is configured as 'manual' and (3) the distinct VLAN approach applies. In case of the shared VLAN approach, the parameter rtp-IPv6-gateway inherits the value configured for the parameter signal-gateway-ip.*

DESCRIPTION FOR THE COMMAND PARAMETER rtp-ipv6-link-mtu:

- *The parameter allows to configure the link mtu of the IPv6 media vlan.*
- *This parameter is only relevant when (1) the parameter media-ipmode is configured as 'ipv6' and (2) the distinct signaling/media VLAN approach applies. In case of the shared signaling/media VLAN approach, the parameter rtp-ipv6-link-mtu inherits the value configured for the parameter signal-link-mtu.*

The parameters rtp-ipv6-gateway, rtp-ipv6-vlan-id, rtp-ipv6-dscp, rtp-ipv6-pbits, rtp-ipv6-link-mtu are defined for

future usage only and thus actually not supported. IPv6 is actually not supported. All references to IPv6 must be ignored since mentioned for future usage only.

User Level

The command can be accessed by operators with sip privileges, and executed by operators with sip privileges.

Command Syntax

The command has the following syntax:

```
> configure voice sip ( no user-agent (name) ) | ( user-agent (name) [ no ip-addr-policy | ip-addr-policy
<Sip::IpAddrPolicy> ] [ no ip-config-mode | ip-config-mode <Sip::IpConfigMode> ] [ no signal-gateway-ip |
signal-gateway-ip <Sip::UserAgentIpAddr> ] signal-vlan-id <Sip::UserAgentVlanId> [ no signal-dscp | signal-dscp
<Sip::UserAgentSignalDscp> ] [ no signal-pbits | signal-pbits <Sip::UserAgentSignalPbits> ] [ no signal-link-mtu |
signal-link-mtu <Sip::UserAgentLinkMTU> ] [ no rtp-gateway-ip | rtp-gateway-ip <Sip::UserAgentIPv4Addr> ] [
no rtp-vlan-id | rtp-vlan-id <Sip::UserAgentRtpVlanId> ] [ no rtp-dscp | rtp-dscp <Sip::UserAgentRtpDscp> ] [ no
rtp-pbits | rtp-pbits <Sip::UserAgentRtpPbits> ] [ no rtp-link-mtu | rtp-link-mtu <Sip::UserAgentLinkMTU> ] [ no
dhcp-optreq-list | dhcp-optreq-list <Sip::UserAgentDHCPOptionReqList> ] [ no admin-status | admin-status
<Sip::UserAgentAdminStatus> ] [ no provider-name | provider-name <Sip::UserAgentProviderName> ] [ no
lsa-rtp-gw-ip | lsa-rtp-gw-ip <Sip::UserAgentIPv4Addr> ] [ no lsa-rtp-vlan-id | lsa-rtp-vlan-id
<Sip::UASAVlanId> ] [ no lsa-md5-realm | lsa-md5-realm <Sip::MD5Realm> ] [ no lsa-md5-password |
lsa-md5-password <Security::Password4> ] [ no rtp-ipv6-gateway | rtp-ipv6-gateway <Sip::UserAgentIPv6Addr> ]
[ no rtp-ipv6-vlan-id | rtp-ipv6-vlan-id <Sip::UserAgentRtpVlanId> ] [ no rtp-ipv6-dscp | rtp-ipv6-dscp
<Sip::UserAgentRtpDscp> ] [ no rtp-ipv6-pbits | rtp-ipv6-pbits <Sip::UserAgentRtpPbits> ] [ no rtp-ipv6-link-mtu |
rtp-ipv6-link-mtu <Sip::UserAgentV6LinkMTU> ] )
```

Command Parameters

Table 40.4-1 "Voice Sip User Agent Configuration Commands" Resource Parameters

Resource Identifier	Type	Description
(name)	Format: - uniquely identifies the User Agent - length: 1<=x<=32	uniquely identify of this user agent

Table 40.4-2 "Voice Sip User Agent Configuration Commands" Command Parameters

Parameter	Type	Description
[no] ip-addr-policy	Parameter type: <Sip::IpAddrPolicy> Format: (distributed centralized) Possible values: - distributed : Each of the voice LT boards owns (a) different IP address(es) for the signaling and media plane. - centralized : All voice LT boards shared the same IP address(es) for the signaling and media plane.	<i>optional parameter with default value: "distributed"</i> the internal ip address policy of the voice node
[no] ip-config-mode	Parameter type: <Sip::IpConfigMode> Format: (dhcp manual) Possible values: - dhcp : The IP related data is acquired from the DHCP server. - manual : The IP related data must be manually configured.	<i>optional parameter with default value: "dhcp"</i> the configuration mode of the IP related data.

40 Voice Configuration Commands

Parameter	Type	Description
[no] signal-gateway-ip	Parameter type: <Sip::UserAgentIpAddr> Format: (ipv6 : <Ip::V6Address> <Ip::V4Address>) Possible values: - ipv6 : IPv6-address Field type <Ip::V6Address> - IPv6-address Field type <Ip::V4Address> - IPv4-address	<i>optional parameter with default value: "0.0.0.0"</i> The IPv4 or IPv6 address of the signalling IP gateway.
signal-vlan-id	Parameter type: <Sip::UserAgentVlanId> Format: - vlan id - range: [1...4093]	<i>mandatory parameter</i> the vlan id for IPv4 or IPv6 signaling traffic
[no] signal-dscp	Parameter type: <Sip::UserAgentSignalDscp> Format: - dscp mark for rtp or rtcp packets - range: [0...63]	<i>optional parameter with default value: 46</i> the dscp mark for the transmitted sip IPv4 or IPv6 signaling traffic
[no] signal-pbits	Parameter type: <Sip::UserAgentSignalPbits> Format: - the dot-1p bit value - range: [0...7]	<i>optional parameter with default value: 6</i> the 802.1p bits for the transmitted sip IPv4 or IPv6 signaling traffic
[no] signal-link-mtu	Parameter type: <Sip::UserAgentLinkMTU> Format: - minimum value: 576 for IPv4 - range: [576...1500]	<i>optional parameter with default value: 1500</i> the linkmtu for the IPv4 or IPv6 signaling vlan
[no] rtp-gateway-ip	Parameter type: <Sip::UserAgentIPv4Addr> Format: - IPv4-address	<i>optional parameter with default value: "0.0.0.0"</i> IPv4 address of the media IP gateway.
[no] rtp-vlan-id	Parameter type: <Sip::UserAgentRtpVlanId> Format: - rtp vlan id - range: [0...4093]	<i>optional parameter with default value: 0</i> vlan id for IPv4 media traffic
[no] rtp-dscp	Parameter type: <Sip::UserAgentRtpDscp> Format: - dscp mark for rtp or rtcp packets - range: [0...63]	<i>optional parameter with default value: 46</i> dscp mark for transmitted IPv4 rtp or rtcp traffic
[no] rtp-pbits	Parameter type: <Sip::UserAgentRtpPbits> Format: - the dot-1p bit value - range: [0...7]	<i>optional parameter with default value: 6</i> 802.1p bits for transmitted IPv4 rtp or rtcp traffic
[no] rtp-link-mtu	Parameter type: <Sip::UserAgentLinkMTU> Format: - minimum value: 576 for IPv4 - range: [576...1500]	<i>optional parameter with default value: 1500</i> link mtu of the IPv4 media vlan.
[no] dhcp-optreq-list	Parameter type: <Sip::UserAgentDHCPOptionReqList> Format: - the list of DHCPv4 options to be returned in option 55. - length: x<=63	<i>optional parameter with default value: "1,3,6,120"</i> the list of DHCPv4 options to be returned in option 55.
[no] admin-status	Parameter type: <Sip::UserAgentAdminStatus> Format: (up down) Possible values: - up : unlock the sip user agent - down : lock the sip user agent	<i>optional parameter with default value: "down"</i> administrative status of this sip user agent

Parameter	Type	Description
[no] provider-name	Parameter type: <Sip::UserAgentProviderName> Format: - uniquely identifies the user agent provider name - length: x<=32	<i>optional parameter with default value: "vsp1"</i> the provider name
[no] lsa-rtp-gw-ip	Parameter type: <Sip::UserAgentIPv4Addr> Format: - IPv4-address	<i>optional parameter with default value: "0.0.0.0"</i> media gateway IP address for the LSA mode
[no] lsa-rtp-vlan-id	Parameter type: <Sip::UALSAVlanId> Format: - lsa vlan id - range: [0...4093]	<i>optional parameter with default value: 0</i> media vlan ID for the LSA mode
[no] lsa-md5-realm	Parameter type: <Sip::MD5Realm> Format: - the realm identifier (Due to legacy reasons, the MD5 character string was included in the object name. Nevertheless, despite the MD5 string in the name of this object, from R5.8.x it is to be considered as a common configuration object for all authentication types that might require the configuration of an authentication realm identifier.) - length: x<=64	<i>optional parameter with default value: ""</i> realm for the registration of SIP terminations to the LSA server.
[no] lsa-md5-password	Parameter type: <Security::Password4> Format: (prompt plain : <Security::PlainPassword4>) Possible values: - prompt : prompts the operator for a password - plain : the password in plain text, may contain any printable character defined by the US-ASCII character set and that has a decimal code in the range 33 to 126, and the length should be less than or equal to 64 (Due to legacy reasons, the MD5 character string was included in the parameter name. Nevertheless, despite the MD5 string in the name of this object, from R5.8.x it is to be considered as a common configuration object for all authentication types that might require the configuration of an authentication password.) Field type <Security::PlainPassword4> - the password, may contain any printable character defined by the US-ASCII character set and that has a decimal code in the range 33 to 126, and the length should be less than or equal to 64 (Due to legacy reasons, the MD5 character string was included in the parameter name. Nevertheless, despite the MD5 string in the name of this object, from R5.8.x it is to be considered as a common configuration object for all authentication types that might require the configuration of an authentication password.) - length: x<=64	<i>optional parameter with default value: "plain : "</i> password for the registration of SIP terminations to the LSA server.
[no] rtp-ipv6-gateway	Parameter type: <Sip::UserAgentIPv6Addr> Format: - IPv6-address	<i>optional parameter with default value: " : : "</i> IPv6 address of the media IP gateway.
[no] rtp-ipv6-vlan-id	Parameter type: <Sip::UserAgentRtpVlanId> Format: - rtp vlan id - range: [0...4093]	<i>optional parameter with default value: 0</i> vlan id for IPv6 media traffic

40 Voice Configuration Commands

Parameter	Type	Description
[no] rtp-ipv6-dscp	Parameter type: <Sip::UserAgentRtpDscp> Format: - dscp mark for rtp or rtcp packets - range: [0...63]	<i>optional parameter with default value: 46</i> dscp mark for the transmitted IPv6 rtp and rtcp traffic
[no] rtp-ipv6-pbits	Parameter type: <Sip::UserAgentRtpPbits> Format: - the dot-1p bit value - range: [0...7]	<i>optional parameter with default value: 6</i> 802.1p bits for the transmitted IPv6 rtp and rtcp traffic
[no] rtp-ipv6-link-mtu	Parameter type: <Sip::UserAgentV6LinkMTU> Format: - minimum value: 1280 for IPv6 - range: [1280...1500]	<i>optional parameter with default value: 1500</i> linkmtu of the IPv6 media vlan

40.5 Sip Voice Service Gateway Configuration Commands

Command Description

This command allows the operator to configure the Voice Service Gateway.

The parameters signaling-ipmode and media-ipmode are defined for future usage only and thus actually not supported. IPv6 is actually not supported. All references to IPv6 must be ignored since mentioned for future usage only.

User Level

The command can be accessed by operators with sip privileges, and executed by operators with sip privileges.

Command Syntax

The command has the following syntax:

```
> configure voice sip ( no vsp (name) ) | ( vsp (name) domain-name <Sip::VspDomainName> [ no admin-status |
admin-status <Sip::VspAdminStatus> ] [ no tinfo | tinfo <Sip::VspTinfo> ] [ no ta4 | ta4 <Sip::VspTa4> ] [ no ttir1
| ttir1 <Sip::VspTtir1> ] [ no t-acm-delta | t-acm-delta <Sip::VspTAcmDelta> ] [ no access-held-time |
access-held-time <Sip::VSPAAccessHeldTimer> ] [ no awaiting-time | awaiting-time <Sip::VSPAawaitingTimer> ] [
no digit-send-mode | digit-send-mode <Sip::VSPDigitSendingMode> ] [ no overlap-484-act | overlap-484-act
<Sip::VSPOverlap484Action> ] [ no dmpm-intdgt-expid | dmpm-intdgt-expid <Sip::VSPDMPMIntDgtExpid> ] [
no dial-start-timer | dial-start-timer <Sip::VSPDialStartTimer> ] [ no dial-long-timer | dial-long-timer
<Sip::VSPDialLongTimer> ] [ no dial-short-timer | dial-short-timer <Sip::VSPDialShortTimer> ] [ no uri-type |
uri-type <Sip::VSPURIType> ] [ no rfc2833-pl-type | rfc2833-pl-type <Sip::VSPRfc2833PayloadType> ] [ no
rfc2833-process | rfc2833-process <Sip::VSPRfc2833Process> ] [ no min-data-jitter | min-data-jitter
<Sip::VSPDataJitter> ] [ no init-data-jitter | init-data-jitter <Sip::VSPDataJitter> ] [ no max-data-jitter |
max-data-jitter <Sip::VSPDataJitter> ] [ no release-mode | release-mode <Sip::VSPReleaseMode> ] [ no
dyn-pt-nego-type | dyn-pt-nego-type <Sip::VSPDynamicPTNegoType> ] [ no vbd-g711a-pl-type |
vbd-g711a-pl-type <Sip::VSPVbdG711APayloadType> ] [ no vbd-g711u-pl-type | vbd-g711u-pl-type
<Sip::VSPVbdG711UPayloadType> ] [ no vbd-mode | vbd-mode <Sip::VSPVbdMode> ] [ no warmline-dl-timer |
warmline-dl-timer <Sip::VSPWarmlineDelayTimer> ] [ timer-b <Sip::CommonCfgTimerB> ] [ timer-f
<Sip::CommonCfgTimerF> ] [ timer-t1 <Sip::CommonCfgTimerT1> ] [ timer-t2 <Sip::CommonCfgTimerT2> ] [
no reg-sub | reg-sub <Sip::VSPRegSubscribe> ] [ no dtmf-sip-info | dtmf-sip-info <Sip::VSPDtmfRelaySipInfo> ] [
no sub-period | sub-period <Sip::VSPSubscribePeriod> ] [ no sub-head-start | sub-head-start
<Sip::VSPSubscribeHeadStart> ] [ no t38-same-udp | t38-same-udp <Sip::VSPT38withSameUDP> ] [ no
dhcp-option82 | dhcp-option82 <Sip::DHCPOption82> ] [ no sspprofile | sspprofile <Sip::SSPProfile> ] [ no
signaling-ipmode | signaling-ipmode <Sip::VSPSignalingIpMode> ] [ no tls-cafile | tls-cafile
<Sip::VSPCAFileName> ] [ no media-ipmode | media-ipmode <Sip::VSPMediaIpMode> ] )
```

Command Parameters

Table 40.5-1 "Sip Voice Service Gateway Configuration Commands" Resource Parameters

Resource Identifier	Type	Description
(name)	Format: - uniquely identify of this SIP voice service gateway - length: x<=32	uniquely identify of this sip voice service gateway

Table 40.5-2 "Sip Voice Service Gateway Configuration Commands" Command Parameters

Parameter	Type	Description
domain-name	Parameter type: <Sip::VspDomainName> Format: - domain name of the SIP VSG - length: 1<=x<=64	<i>mandatory parameter</i> domain name of the sip VSG
[no] admin-status	Parameter type: <Sip::VspAdminStatus> Format: (up down) Possible values: - up : unlock the sip VSG - down : lock the sip VSG	<i>optional parameter with default value: "down"</i> administrative status of this sip voice service gateway
[no] tinfo	Parameter type: <Sip::VspTinfo> Format: - tinfo of this SIP voice service gateway - range: [1...3600000]	<i>optional parameter with default value: 1000</i> value of tinfo in milli-second of this sip voice service gateway, the timer to collect digits before an INVITE is sent to reduce the amount of INVITE requests sent as defined in ETSI TS 183 036 V0.10.1
[no] ta4	Parameter type: <Sip::VspTa4> Format: - Ta4 timer expire of this SIP voice service gateway - unit: millisecond - range: [1...3600000]	<i>optional parameter with default value: 4000</i> value of Ta4 timer expire in milli-second. The timer Ta4 starts on receipt of first dialed digit. If the dialed digits are not matched with digitmap, the expiry of Ta4 will trigger the sending of initial INVITE.
[no] ttir1	Parameter type: <Sip::VspTtir1> Format: - ttir1 of this SIP voice service gateway - range: [1...3600000]	<i>optional parameter with default value: 100</i> value of ttir1 in milli-second of this sip voice service gateway, in the case 'from-change' is indicated, UA has to wait for an UPDATE, the timer assures that the call can continue if the UPDATE is missing as defined in ETSI TS 183 036 V0.10.1
[no] t-acm-delta	Parameter type: <Sip::VspTAcmDelta> Format: - T-acm-delta timer expire of this SIP voice service gateway - unit: millisecond - range: [1...3600000]	<i>optional parameter with default value: 18000</i> value of T-acm-delta timer expire in milli-second. The timer T-acm-delta starts on the situation that T-interdigit timer expires and there is INVITE transaction ongoing. The system will start T-acm-delta. The expiry of T-acm-delta will end the attempt of the call establishment.
[no] access-held-time	Parameter type: <Sip::VSPAccessHeldTimer>	<i>optional parameter with default</i>

Parameter	Type	Description
	Format: - Value of access-held-timer expires which is used in the release control procedure. - unit: second - range: [1...65535]	<i>value: 600</i> this value is used in the release control procedure. it is started when receiving INVITE with No Ring and no SDP and stopped when sending 200 OK (INVITE).
[no] awaiting-time	Parameter type: <Sip::VSPAwaitingTimer> Format: - value of awaiting-timer expires which is used in the release control procedure. - unit: second - range: [1...65535]	<i>optional parameter with default value: 60</i> this value is used in the release control procedure. it is started when receiving 200 OK (Bye) with X-Service-indicator and stopped when receiving INVITE with No Ring and No SDP.
[no] digit-send-mode	Parameter type: <Sip::VSPDigitSendingMode> Format: (en-bloc overlap-invite overlap-indialog) Possible values: - en-bloc : en-block mode - overlap-invite : overlap-invite mode - overlap-indialog : overlap-indialog mode	<i>optional parameter with default value: "en-bloc"</i> digit sending mode of this sip voice service gateway
[no] overlap-484-act	Parameter type: <Sip::VSPOverlap484Action> Format: (release-call continue) Possible values: - release-call : terminate the call. - continue : continue the digit collection for the call attempt.	<i>optional parameter with default value: "release-call"</i> release call or not when 484 is received for INVITE before early dialog is established for digit sending in overlap dialing in-dialog method.
[no] dmpm-intdgt-expid	Parameter type: <Sip::VSPDMPMIntDgtExpid> Format: (send-invite release-call) Possible values: - send-invite : send out invite with the collected digits. - release-call : terminate the call.	<i>optional parameter with default value: "send-invite"</i> The action if inter-digit timer expired when digitmap partial matched.
[no] dial-start-timer	Parameter type: <Sip::VSPDialStartTimer> Format: - Dialing start timer in second - unit: second - range: [1...60]	<i>optional parameter with default value: 10</i> Default maximum waiting time in seconds for dialing the first digit
[no] dial-long-timer	Parameter type: <Sip::VSPDialLongTimer> Format: - dialing long timer in second - unit: second - range: [1...60]	<i>optional parameter with default value: 20</i> Default maximum waiting time in seconds for dialing when no matching found in the digitmap
[no] dial-short-timer	Parameter type: <Sip::VSPDialShortTimer> Format: - dialing short timer in second - unit: second - range: [1...60]	<i>optional parameter with default value: 5</i> Default maximum waiting time in seconds for dialing when matching found in the digitmap
[no] uri-type	Parameter type: <Sip::VSPURIType> Format: (sip-uri tel-uri sips-uri)	<i>optional parameter with default value: "sip-uri"</i> uri type of this sip voice service gateway

Parameter	Type	Description
	Possible values: - sip-uri : sip-uri mode - tel-uri : tel-uri mode - sips-uri : sips-uri mode	
[no] rfc2833-pl-type	Parameter type: <Sip::VSPRfc2833PayloadType> Format: - payload type of rfc2833 - range: [96...127]	<i>optional parameter with default value: 96</i> payload type of rfc2833
[no] rfc2833-process	Parameter type: <Sip::VSPRfc2833Process> Format: (audio rfc2833 both mandatory-audio) Possible values: - audio : processing procedure is audio - rfc2833 : processing procedure is rfc2833 - both : processing procedure is both - mandatory-audio : processing procedure is audio first	<i>optional parameter with default value: "audio"</i> processing procedure for the dtmf event tones
[no] min-data-jitter	Parameter type: <Sip::VSPDataJitter> Format: - data jitter buffer for calls working in rtp mode in millisecond - unit: millisecond - range: [0...200]	<i>optional parameter with default value: 50</i> minimum jitter buffer for data calls working in rtp mode
[no] init-data-jitter	Parameter type: <Sip::VSPDataJitter> Format: - data jitter buffer for calls working in rtp mode in millisecond - unit: millisecond - range: [0...200]	<i>optional parameter with default value: 50</i> initial jitter buffer for data calls working in rtp mode
[no] max-data-jitter	Parameter type: <Sip::VSPDataJitter> Format: - data jitter buffer for calls working in rtp mode in millisecond - unit: millisecond - range: [0...200]	<i>optional parameter with default value: 50</i> maximum jitter buffer for data calls working in rtp mode
[no] release-mode	Parameter type: <Sip::VSPReleaseMode> Format: (normal caller callee both) Possible values: - normal : sending BYE immediately, applicable for the normal call release procedure - caller : postpone BYE until access-held-time times out for caller, only postpone BYE in case the subscriber is caller - callee : postpone BYE until access-held-time times out for callee, only postpone BYE in case the subscriber is callee - both : postpone BYE until access-held-time times out for caller and callee, postpone BYE in case the subscriber is caller or callee	<i>optional parameter with default value: "normal"</i> send BYE immediately or not after caller/callee/both onhook
[no] dyn-pt-nego-type	Parameter type: <Sip::VSPDynamicPTNegoType> Format: (far-end asymmetric)	<i>optional parameter with default value: "far-end"</i> how to negotiate dynamic payload type

Parameter	Type	Description
	Possible values: - far-end : negotiate with supported by far-end - asymmetric : negotiate with different payload type for sending and receiving	
[no] vbd-g711a-pl-type	Parameter type: <Sip::VSPVbdG711APayloadType> Format: - dynamic payload type of Vbd G711A - range: [96...127]	<i>optional parameter with default value: 97</i> dynamic payload type of vbd g711a
[no] vbd-g711u-pl-type	Parameter type: <Sip::VSPVbdG711UPayloadType> Format: - dynamic payload type of Vbd G711U - range: [96...127]	<i>optional parameter with default value: 98</i> dynamic payload type of vbd g711u
[no] vbd-mode	Parameter type: <Sip::VSPVbdMode> Format: (autoswitch renegotiation v152fb-autoswitch v152fb-reneg) Possible values: - autoswitch : auto switch without negotiation - renegotiation : renegotiation - v152fb-autoswitch : V152. If V152 negotiation fails, act as autoswitch (ISDN and CASR2 not support this) - v152fb-reneg : V152. If V152 negotiation fails, act as renegotiation (ISDN and CASR2 not support this)	<i>optional parameter with default value: "autoswitch"</i> vbd negotiation mode
[no] warmline-dl-timer	Parameter type: <Sip::VSPWarmlineDelayTimer> Format: - warmline delay timer in second - unit: second - range: [1...60]	<i>optional parameter with default value: 4</i> warmline-delay-timer, range from 1 to 60 sec
timer-b	Parameter type: <Sip::CommonCfgTimerB> Format: - value of SIP CommonCfgTimerB for rfc4780 - unit: millisecond - range: [2000...64000]	<i>optional parameter</i> This object reflects the maximum time a SIP entity will wait to receive a response to an INVITE. The timer is started upon transmission of the initial INVITE request.
timer-f	Parameter type: <Sip::CommonCfgTimerF> Format: - value of SIP CommonCfgTimerF for rfc4780 - unit: millisecond - range: [2000...64000]	<i>optional parameter</i> This object reflects the maximum time a SIP entity will wait to receive a final response to a non-INVITE request. The timer is started upon transmission of the initial request.
timer-t1	Parameter type: <Sip::CommonCfgTimerT1> Format: - value of SIP CommonCfgTimerT1 for rfc4780 - unit: millisecond - range: [200...10000]	<i>optional parameter</i> This object reflects the T1 timer for a SIP entity. T1 is an estimate of the round-trip time (RTT) between the client and server transactions.
timer-t2	Parameter type: <Sip::CommonCfgTimerT2> Format: - value of SIP CommonCfgTimerT2 for rfc4780 - unit: millisecond - range: [200...10000]	<i>optional parameter</i> This object reflects the T2 timer for a SIP entity. T2 is the maximum retransmit interval for non-INVITE requests and INVITE responses. It is used in various parts of the protocol to

Parameter	Type	Description
		reset other Timer* objects to this value.
[no] reg-sub	Parameter type: <Sip::VSPRegSubscribe> Format: (disable enable) Possible values: - disable : do not send reg SUBSCRIBE - enable : send reg SUBSCRIBE	<i>optional parameter with default value: "disable"</i> This object indicates whether the system should send the reg SUBSCRIBE method.
[no] dtmf-sip-info	Parameter type: <Sip::VSPDtmfRelaySipInfo> Format: (disable enable) Possible values: - disable : do not send DTMF Info - enable : send DTMF Info	<i>optional parameter with default value: "disable"</i> This objects indicates whether dtmf-events will be sent on top of RFC2833 configuration also in the SIP signalling path in the message-body of SIP INFO message with content-type set to application/dtmf-relay.
[no] sub-period	Parameter type: <Sip::VSPSubscribePeriod> Format: - This object indicates subscription expiration time that the client will propose by including it in an Expires header of a SUBSCRIBE request. If this property is set to a value of zero, the client SHALL NOT refresh a subscription even if the server specifies an expiration interval. Accept value greater than or equal to 60 [0 (60..86400)] - unit: second - range: [0,60...86400]	<i>optional parameter with default value: 3600</i> This object indicates subscription expiration time that the client will propose by including it in an Expires header of a SUBSCRIBE request. If this property is set to a value of zero, the client SHALL NOT refresh a subscription even if the server specifies an expiration interval.
[no] sub-head-start	Parameter type: <Sip::VSPSubscribeHeadStart> Format: - This object indicates number of seconds prior to expiration of a subscription at which the client sends a SUBSCRIBE request to refresh the subscription. Accept value greater than or equal to 60 [0 (32..86400)] - unit: second - range: [0,32...86400]	<i>optional parameter with default value: 600</i> This object indicates number of seconds prior to expiration of a subscription at which the client sends a SUBSCRIBE request to refresh the subscription.
[no] t38-same-udp	Parameter type: <Sip::VSPT38withSameUDP> Format: (disable enable) Possible values: - disable : T38 use different port as voice - enable : T38 use same port as voice	<i>optional parameter with default value: "disable"</i> Whether T38 use same UDP port with voice,disable(1),enable(2)
[no] dhcp-option82	Parameter type: <Sip::DHCPOption82> Format: (enable disable) Possible values: - enable : enable to send option 82 in DHCP mode - disable : disable to send option 82 in DHCP mode	<i>optional parameter with default value: "disable"</i> dhcp option82 mode
[no] sspprofile	Parameter type: <Sip::SSPProfile> Format: - The name of the SIP Service Profile assigned to a voice service gateway - length: x<=64	<i>optional parameter with default value: ""</i> The name of the SIP Service Profile assigned to a VSG
[no] signaling-ipmode	Parameter type: <Sip::VSPSignalingIpMode>	<i>optional parameter with default</i>

Parameter	Type	Description
	Format: (legacy-ipv4 ipv4 ipv6) Possible values: - legacy-ipv4 : the SIP signaling path is based on IPv4 addressing, for backward compatibility of legacy CLI management interface. Only allowed when media-ipmode set as 'legacy-ipv4' - ipv4 : the SIP signaling path is based on IPv4 addressing, for changed CLI management interface. Only allowed when media-ipmode set as 'ipv4' - ipv6 : the SIP signaling path is based on IPv6 addressing, for changed CLI management interface. Only allowed when media-ipmode set as 'ipv6'	<i>value: "legacy-ipv4"</i> The variable allows the operator to specify the IP mode of the SIP signaling path.
[no] tls-cafile	Parameter type: <Sip::VSPCAFileName> Format: - the ca file name - length: x<=13	<i>optional parameter with default value: ""</i> The name of Certification Authority (CA) file configured for VSP entry.
[no] media-ipmode	Parameter type: <Sip::VSPMediaIpMode> Format: (legacy-ipv4 ipv4 ipv6) Possible values: - legacy-ipv4 : the media path is based on IPv4 addressing, for backward compatibility of legacy CLI management interface. Only allowed when signaling-ipmode set as 'legacy-ipv4' - ipv4 : the media path is based on IPv4 addressing, for changed CLI management interface. Only allowed when signaling-ipmode set as 'ipv4' - ipv6 : the media path is based on IPv6 addressing, for changed CLI management interface. Only allowed when signaling-ipmode set as 'ipv6'	<i>optional parameter with default value: "legacy-ipv4"</i> The variable allows the operator to specify the IP mode of the SIP media path.

40.6 Voice Sip User Agent Access Point Configuration Command

Command Description

This command allows the operator to configure the Voice Sip User Agent Access Point. This command depends on the Voice Sip UserAgent Configuration command. When a SIP User Agent is created/deleted, the user agent access point(s) will be created/deleted automatically according to the SIP UA ip-address-policy. The user agent access point(s) can be learned using the show command: show voice sip user-agent-ap.

The parameter rtp-ipv6-address is defined for future usage only and thus actually not supported. IPv6 is actually not supported. All references to IPv6 must be ignored since mentioned for future usage only.

User Level

The command can be accessed by operators with sip privileges, and executed by operators with sip privileges.

Command Syntax

The command has the following syntax:

```
> configure voice sip user-agent-ap (ua-name) slot-id <SIP::SlotIndex> [ signal-ip <SIP::IpAddressWithPrefix> ] [
no rtp-ip | rtp-ip <SIP::IpAddressAndMask> ] [ no dhcp-fqdn | dhcp-fqdn <Sip::UaApDHCPFQDN> ] [ no
dhcp-customer-id | dhcp-customer-id <Sip::UaApDHCPCustomerID> ] [ no admin-status | admin-status
<Sip::UaApAdminStatus> ] [ no lsa-rtp-ip | lsa-rtp-ip <SIP::IpAddressAndMask> ] [ no rtp-ipv6-address |
rtp-ipv6-address <SIP::IPv6AddressWithPrefix> ]
```

Command Parameters

Table 40.6-1 "Voice Sip User Agent Access Point Configuration Command" Resource Parameters

Resource Identifier	Type	Description
(ua-name)	Format: - uniquely identifies the User Agent - length: 1<=x<=32	uniquely identify of the user agent
slot-id	Parameter type: <SIP::SlotIndex> Format: (lt : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> nt ntio <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::EqSlotId>) Possible values: - lt : lt-slot - nt : nt-slot - ntio : ntio-slot Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId>	slot id associated with this user agent access point

Resource Identifier	Type	Description
	- the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::EqSlotId> - the equipment slot number	

Table 40.6-2 "Voice Sip User Agent Access Point Configuration Command" Command Parameters

Parameter	Type	Description
signal-ip	Parameter type: <SIP::IpAddressWithPrefix> Format: (ipv6 : <Ip::V6Address> / <Ip::V6PrefixLength> <Ip::V4Address> / <Sip::PrefixLength>) Possible values: - ipv6 : IPv6-address Field type <Ip::V6Address> - IPv6-address Field type <Ip::V4Address> - IPv4-address Field type <Ip::V6PrefixLength> - prefix length of IPv6-address - range: [0...128] Field type <Sip::PrefixLength> - prefix length of the subnet - range: [0...128]	<i>optional parameter</i> signalling ip address and prefix length of the sip user agent access point
[no] rtp-ip	Parameter type: <SIP::IpAddressAndMask> Format: <Ip::V4Address> / <Sip::PrefixLength> Field type <Ip::V4Address> - IPv4-address Field type <Sip::PrefixLength> - prefix length of the subnet - range: [0...128]	<i>optional parameter with default value: "0.0.0.0/0"</i> rtp ip address and prefix length of the sip user agent access point
[no] dhcp-fqdn	Parameter type: <Sip::UaApDHCPFQDN> Format: - the string for FQDN in Option81 When UA send out DHCP request - length: x<=255	<i>optional parameter with default value: ""</i> the FQDN in Option81 When UA send out DHCP request
[no] dhcp-customer-id	Parameter type: <Sip::UaApDHCPCustomerID> Format: - the string for Customer id in Option82 When UA send out DHCP request - length: x<=64	<i>optional parameter with default value: "Physical-ID"</i> the Customer id in Option82 When UA send out DHCP request
[no] admin-status	Parameter type: <Sip::UaApAdminStatus> Format: (up down) Possible values: - up : unlock the sip Ua AccessPoint - down : lock the sip Ua AccessPoint	<i>optional parameter with default value: "down"</i> administrative status of this sip user agent access point
[no] lsa-rtp-ip	Parameter type: <SIP::IpAddressAndMask> Format: <Ip::V4Address> / <Sip::PrefixLength> Field type <Ip::V4Address> - IPv4-address Field type <Sip::PrefixLength> - prefix length of the subnet - range: [0...128]	<i>optional parameter with default value: "0.0.0.0/0"</i> media IP address + prefix length used when connected to the LSA server

40 Voice Configuration Commands

Parameter	Type	Description
[no] rtp-ipv6-address	Parameter type: <SIP::IPv6AddressWithPrefix> Format: <Ip::V6Address> / <Ip::V6PrefixLength> Field type <Ip::V6Address> - IPv6-address Field type <Ip::V6PrefixLength> - prefix length of IPv6-address - range: [0...128]	<i>optional parameter with default value: " : : /0"</i> rtp IPv6 address and prefix length of the sip user agent access point

40.7 Voice Sip Dial Plan Configuration Commands

Command Description

This command allows the operator to manage the Voice Sip dial plan profile.

User Level

The command can be accessed by operators with sip privileges, and executed by operators with sip privileges.

Command Syntax

The command has the following syntax:

```
> configure voice sip ( no dialplan (name) ) | ( dialplan (name) [ no pre-activated | pre-activated
<Sip::DialPlanPreActivated> ] [ no static-prefix | static-prefix <Sip::DialPlanStaticPrefix> ] [ no static-suffix |
static-suffix <Sip::DialPlanStaticSuffix> ] [ no digitmap-mode | digitmap-mode <Sip::DialPlanDigitMapMode> ] [
no provider-name | provider-name <Sip::DialPlanProviderName> ] )
```

Command Parameters

Table 40.7-1 "Voice Sip Dial Plan Configuration Commands" Resource Parameters

Resource Identifier	Type	Description
(name)	Format: - uniquely identifies the dial plan - length: 1<=x<=32	unique identity of a voice sip dial plan

Table 40.7-2 "Voice Sip Dial Plan Configuration Commands" Command Parameters

Parameter	Type	Description
[no] pre-activated	Parameter type: <Sip::DialPlanPreActivated> Format: (on off) Possible values: - on : Prefix activated of dial plan is on - off : Prefix activated of dial plan is off	<i>optional parameter with default value: "off"</i> identify the status for sip dial plan prefix
[no] static-prefix	Parameter type: <Sip::DialPlanStaticPrefix> Format: - static prefix added to all valid DNs - length: x<=32	<i>optional parameter with default value: ""</i> identify static prefix(uri type + area code) added to valid DNs.If the format is 'uri type + area code',the uri type will overwrite the uri type in vsp; If the format is area code without uri type, uri type will depend on the uri type in vsp.
[no] static-suffix	Parameter type: <Sip::DialPlanStaticSuffix> Format: - static suffix added to all valid DNs	<i>optional parameter with default value: ""</i> identify static suffix(area code)

40 Voice Configuration Commands

Parameter	Type	Description
	- length: x<=32	added all valid DNs
[no] digitmap-mode	Parameter type: <Sip::DialPlanDigitMapMode> Format: (maximum minimum) Possible values: - maximum : standard match mode - minimum : system should send out INVITE immediately when an exact full match dial string is detected	<i>optional parameter with default value: "maximum"</i> identify the digit match mode for dial plan
[no] provider-name	Parameter type: <Sip::DialPlanProviderName> Format: - uniquely identifies the dial plan provider name - length: x<=32	<i>optional parameter with default value: "vsp1"</i> identify the sip dial plan provider name

40.8 Voice Sip Dial Plan Digitmap Configuration Commands

Command Description

This command allows the operator to manage the Voice Sip dialplan digitmap profile.

User Level

The command can be accessed by operators with sip privileges, and executed by operators with sip privileges.

Command Syntax

The command has the following syntax:

```
> configure voice sip ( no digitmap (name) type <Sip::DialPlanDigitmapType> rule
<Sip::DialPlanDigitmapValue> ) | ( digitmap (name) type <Sip::DialPlanDigitmapType> rule
<Sip::DialPlanDigitmapValue> [ no access-type | access-type <Sip::DialPlanDigitmapAccessType> ] )
```

Command Parameters

Table 40.8-1 "Voice Sip Dial Plan Digitmap Configuration Commands" Resource Parameters

Resource Identifier	Type	Description
(name)	Format: - uniquely identifies the dial plan - length: 1<=x<=32	identify voice application dial plan within the scope
type	Parameter type: <Sip::DialPlanDigitmapType> Format: regular Possible values: - regular : digitmap type	identify the type of sip dial plan digitmap
rule	Parameter type: <Sip::DialPlanDigitmapValue> Format: - identity the value of digitmap - length: 1<=x<=100	identify the value of sip dial plan digitmap

Table 40.8-2 "Voice Sip Dial Plan Digitmap Configuration Commands" Command Parameters

Parameter	Type	Description
[no] access-type	Parameter type: <Sip::DialPlanDigitmapAccessType> Format: allowed Possible values: - allowed : the digitmap can be used	<i>optional parameter with default value: "allowed"</i> <i>The parameter is not visible during creation.</i> The access type of digitmap

40.9 Voice Sip Termination Configuration Commands

Command Description

This command allows the operator to manage the Voice Sip termination profile.

User Level

The command can be accessed by operators with sip privileges, and executed by operators with sip privileges.

Command Syntax

The command has the following syntax:

```
> configure voice sip ( no termination (if-index) ) | ( termination (if-index) [ no directory-number |
directory-number <Sip::TermDnumber> ] [ no user-name | user-name <Sip::TermUserName> ] [ no display-name |
display-name <Sip::TermDisplayName> ] [ no uri | uri <Sip::TermUri> ] [ no direct-uri | direct-uri <Sip::TermUri>
] [ no line-feed | line-feed <Sip::TermLineCharacter> ] [ no md5-realm | md5-realm <Sip::MD5Realm> ] [ no
md5-password | md5-password <Security::Password4> ] [ no aka-secret-key | aka-secret-key
<Security::Password8> ] [ no admin-status | admin-status <Sip::TermAdminStatus> ] [ no clip-mode | clip-mode
<Sip::TermETSIClipDataMode> ] [ no telc-clip-mode | telc-clip-mode <Sip::TermTelcordiaClipDataMode> ] [ no
anti-tapping | anti-tapping <Sip::TermAntiTapping> ] [ no impedance | impedance <Sip::TermImpedance> ] [ no
rx-gain | rx-gain <Sip::TermRxGain> ] [ no tx-gain | tx-gain <Sip::TermTxGain> ] [ no warmline-service |
warmline-service <Sip::TermWarmlineService> ] [ no linesig-remanswer | linesig-remanswer
<Sip::TermLineSignalOnRemoteAnswer> ] [ no line-id | line-id <Sip::TermLineId> ] [ no force-hold | force-hold
<Sip::TermService> ] [ no callwait-service | callwait-service <Sip::TermCallwaitingService> ] [ no callhold-service
| callhold-service <Sip::TermSupplementaryService> ] [ no callconf-service | callconf-service
<Sip::TermSupplementaryService> ] [ no calltras-service | calltras-service <Sip::TermSupplementaryService> ] [
no fast-guard | fast-guard <Sip::TermFastGuardOnInvite> ] [ no clear-forward | clear-forward
<Sip::TermClearForwardOnBye> ] [ no testaccessstate | testaccessstate <Sip::TestAccessState> ] [ no
busyoverwrite | busyoverwrite <Sip::TestAccessBusyOverWrite> ] [ no accessontimeout | accessontimeout
<Sip::TestAccessonTimeout> ] [ no provider-name | provider-name <Sip::TermUserProviderName> ] [ no
register_recall | register_recall <Sip::TermRegisterRecall> ] [ no sip-rule-set | sip-rule-set
<Sip::PotsManipulationRuleSet> ] [ no reserved | reserved <Sip::TermReserved> ] [ no pulse-dialing | pulse-dialing
<Sip::TermPulseDialing> ] [ no auto-answer | auto-answer <Sip::TermAutoAnswer> ] )
```

Command Parameters

Table 40.9-1 "Voice Sip Termination Configuration Commands" Resource Parameters

Resource Identifier	Type	Description
(if-index)	Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId>	The unique internal identifier of the termination port

Resource Identifier	Type	Description
	- the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number	

Table 40.9-2 "Voice Sip Termination Configuration Commands" Command Parameters

Parameter	Type	Description
[no] directory-number	Parameter type: <Sip::TermDnumber> Format: - identify the DN of the subscriber line - length: x<=32	<i>optional parameter with default value: ""</i> identify the directory (telephone) number of the subscriber line
[no] user-name	Parameter type: <Sip::TermUserName> Format: - identify the user name for this port - length: x<=64	<i>optional parameter with default value: ""</i> identify the user name for this termination port
[no] display-name	Parameter type: <Sip::TermDisplayName> Format: - identify the display name for this port - length: x<=64	<i>optional parameter with default value: ""</i> display name for this termination port
[no] uri	Parameter type: <Sip::TermUri> Format: - SIP uri by which the user agent identifies subscriber line - length: x<=80	<i>optional parameter with default value: ""</i> sip uri by which user agent identifies subscriber line
[no] direct-uri	Parameter type: <Sip::TermUri> Format: - SIP uri by which the user agent identifies subscriber line - length: x<=80	<i>optional parameter with default value: ""</i> a call will be automatically established to this SIP-URI after an off-hook
[no] line-feed	Parameter type: <Sip::TermLineCharacter> Format: (25 40) Possible values: - 25 : the line character of this port is 25, unit: ma - 40 : the line character of this port is 40, unit: ma	<i>optional parameter with default value: "25"</i> the characteristic of the subscriber line
[no] md5-realm	Parameter type: <Sip::MD5Realm> Format: - the realm identifier (Due to legacy reasons, the MD5 character string was included in the object name. Nevertheless, despite the MD5 string in the name of this object, from R5.8.x it is to be considered as a common configuration object for all authentication types that might require the configuration of an authentication realm identifier.) - length: x<=64	<i>optional parameter with default value: ""</i> realm identifier corresponding to service gateway domain
[no] md5-password	Parameter type: <Security::Password4> Format: (prompt plain : <Security::PlainPassword4>) Possible values: - prompt : prompts the operator for a password - plain : the password in plain text, may contain any printable character defined by the US-ASCII character set and that has a decimal code in the range 33 to 126, and the length should be less than or equal to 64 (Due to legacy reasons, the MD5 character string was included in the	<i>optional parameter with default value: "plain : "</i> the password associated with the user

Parameter	Type	Description
	parameter name. Nevertheless, despite the MD5 string in the name of this object, from R5.8.x it is to be considered as a common configuration object for all authentication types that might require the configuration of an authentication password.) Field type <Security::PlainPassword4> - the password, may contain any printable character defined by the US-ASCII character set and that has a decimal code in the range 33 to 126, and the length should be less than or equal to 64 (Due to legacy reasons, the MD5 character string was included in the parameter name. Nevertheless, despite the MD5 string in the name of this object, from R5.8.x it is to be considered as a common configuration object for all authentication types that might require the configuration of an authentication password.) - length: x<=64	
[no] aka-secret-key	Parameter type: <Security::Password8> Format: (prompt plain : <Security::PlainPassword8>) Possible values: - prompt : prompts the operator for AKA shared secret key - plain : the AKA shared secret key in plain text, each character should be 0-f, and the length can only be 0 or 32 Field type <Security::PlainPassword8> - the AKA shared secret key, each character should be 0-f, and the length can only be 0 or 32 - length: x<=32	<i>optional parameter with default value: "plain : "</i> the AKA shared secret key
[no] admin-status	Parameter type: <Sip::TermAdminStatus> Format: (up down) Possible values: - up : unlock the sip termination - down : lock the sip termination	<i>optional parameter with default value: "down"</i> identify the status of this port administration
[no] clip-mode	Parameter type: <Sip::TermETSIClipDataMode> Format: (cdevalue fsk dtmf) Possible values: - cdevalue : cde configuration will be applied for etsi clip - fsk : fsk will be applied for etsi clip - dtmf : dtmf will be applied for etsi clip	<i>optional parameter with default value: "cdevalue"</i> the etsi clip data transmission protocol of this sip termination
[no] telc-clip-mode	Parameter type: <Sip::TermTelcordiaClipDataMode> Format: (cdevalue fsk) Possible values: - cdevalue : cde configuration will be applied for Telcordia clip - fsk : fsk will be applied for Telcordia clip	<i>optional parameter with default value: "cdevalue"</i> the TELCORDIA clip data transmission protocol of this sip termination
[no] anti-tapping	Parameter type: <Sip::TermAntiTapping> Format: (enable disable) Possible values:	<i>optional parameter with default value: "disable"</i> enable/disable the anti-tapping service of this sip termination

Parameter	Type	Description
	- enable : Enable Anti-Tapping service - disable : Disable Anti-Tapping service	
[no] impedance	Parameter type: <Sip::TermImpedance> Format: (default 200 220 220minisplitter 270 300 370 600 900 370minisplitter 600splitter 370nvlsasplitter 370skinnysplitter 270duratelsplitter 2703msplitter 100 150 220splitter reserv19 reserv20 reserv21) Possible values: - default : the impedance is default value - 200 : the line impedance is 200 ohm - 220 : the line impedance is 220 ohm - 220minisplitter : the line impedance is 220 ohm+ miniSplitter - 270 : the line impedance is 270 ohm - 300 : the line impedance is 300 ohm - 370 : the line impedance is 370 ohm - 600 : the line impedance is 600 ohm - 900 : the line impedance is 900 ohm - 370minisplitter : the line impedance is 370 ohm+ miniSplitter - 600splitter : the line impedance is 600 ohm+splitter - 370nvlsasplitter : the line impedance is 370 ohm+ NVLSASplitter - 370skinnysplitter : the line impedance is 370 ohm+ SkinnySplitter - 270duratelsplitter : the line impedance is 270 ohm+ DuratelSplitter - 2703msplitter : the line impedance is 270 ohm+ 3MDplitter - 100 : the line impedance is 100 ohm - 150 : the line impedance is 150 ohm - 220splitter : the line impedance is 220 ohm+ splitter - reserv19 : reserved for future use 19 - reserv20 : reserved for future use 20 - reserv21 : reserved for future use 21	<i>optional parameter with default value: "default"</i> configure the line impedance of this sip termination
[no] rx-gain	Parameter type: <Sip::TermRxGain> Format: - the line rx_gain range -14...6 - range: [-14...6]	<i>optional parameter with default value: "0"</i> configure the line rx_gain of this sip termination

Parameter	Type	Description
[no] tx-gain	Parameter type: <Sip::TermTxGain> Format: - the line tx_gain range -14...6 - range: [-14...6]	<i>optional parameter with default value: "0"</i> configure the line tx_gain of this sip termination
[no] warmline-service	Parameter type: <Sip::TermWarmlineService> Format: (disabled activated subscribed) Possible values: - disabled : When warmline-service=disabled and direct-uri is null, warmline service is controlled by SIP Service Profile. The SSP will tell whether this service is controlled by UA-Profile or the MIB disable value is applied (e.g. when the IMS core does not support the UA-profile approach). - activated : Warmline is activated - subscribed : Warmline can be subscribed by end user	<i>optional parameter with default value: "disabled"</i> warmline administrative status
[no] linesig-remanswer	Parameter type: <Sip::TermLineSignalOnRemoteAnswer> Format: (no-signal line-reversal single-meteringpulse) Possible values: - no-signal : send no signal - line-reversal : send line reversal signal - single-meteringpulse : send single metering pulse signal	<i>optional parameter with default value: "no-signal"</i> line signal on remote answer
[no] line-id	Parameter type: <Sip::TermLineId> Format: - The cli-timing (cli) and/or VBD rx-gain/tx-gain (vbdrx/vbdtx) and/or the Fax Mode (fm) and/or the Voice Activity Detection (vad) and/or the warmline delay timer (wldt) and/or the processing procedure for the dtmf event tones(2833) and/or the vbd-mode (vm) and/or the UDP port usage for T38 to voice switching (and vice versa) (udp) and/or the Pani header line ID. Format : [cli:prior cli:during];[vbdtx:(value(-14:6))];[vbdrx:(value(-14:6))];[fm:(value(1:3))];[vad:e vad:d] A semi-colon must be inserted between the configuration input strings. The configuration input must be given in lower case characters. No space allowed anywhere; no leading zero(es) allowed anywhere. In case the configuration input for one or multiple input strings must be changed, the configuration input for all other input strings must be repeated too i.e. the new configuration input for the line id parameter fully overwrites the previous configuration input. - Keyword : cli (Only applicable to CLIP ETSI standard.) Values : prior during. prior: clip-procedure is priorDT (for FSK) or priorNoLR (for DTMF). during: clip-procedure is duringRinging. In case this keyword is not found in the configuration input of the line-id parameter, the pre-provisioned value in the CDE file applies. - Keyword : vbdtx Values : range [-14:6] The '+' sign is not allowed; only the '-' sign is allowed. In case this keyword is not found in the configuration input of the line-id parameter, for a voice call, the value configured at SIP termination level applies. After switching to VBD, the hardcoded value Tx gain = 0 applies. - Keyword : vbdrx	<i>optional parameter with default value: ""</i> identify the line id for this termination port

Parameter	Type	Description
	Values : range [-14:6]\n The '+' sign is not allowed; only the '-' sign is allowed.\n In case this keyword is not found in the configuration input of the line-id parameter, for a voice call, the value configured at SIP termination level applies. After switching to VBD, the hardcoded value Rx gain = 0 applies.\n - Keyword : fm\n Values : range [1:3]\n 1 : g711vbd\n 2 : t.38-with-g711vbd-fallback-with-signaling\n 3 : t.38-with-g711vbd-fallback-without-signaling\n In case this keyword is not found in the configuration input of the line-id parameter, the pre-provisioned value in the CDE file applies.\n - Keyword : vad\n Values : e d\n e : vad is enabled (sending comfort noise packets during silent periods)\n d : vad is disabled (do not send comfort noise packets during silent periods)\n In case this keyword is not found in the configuration input of the line-id parameter, the pre-provisioned value in the CDE file applies.\n - Keyword : wldt\n Values : range [1:60] seconds\n In case this keyword is not found in the configuration input of the line-id parameter, the system wide configuration input applies.\n - Keyword : 2833\n Values : range [1:4]\n 1 : the processing procedure is audio\n 2 : the processing procedure is rfc2833\n 3 : the processing procedure is both, audio and rfc2833\n 4 : audio has priority in the processing procedure\n In case this keyword is not found in the configuration input of the line-id parameter, the system wide configuration input applies.\n - Keyword : vm\n Values: range [1:4]\n 1 : auto switch without negotiation\n 2 : renegotiation\n 3 : If V152 negotiation fails, autoswitch applies\n 4 : If V152 negotiation fails, renegotiation applies\n In case this keyword is not found in the configuration input of the line-id parameter, the system wide configuration input applies.\n - Keyword : udp\n Values : e d\n e : the same UDP port is used for Voice and T38\n d : a different UDP port is used for Voice and T38\n In case this keyword is not found in the configuration input of the line-id parameter, the system wide configuration input applies.\n - Pani header line id : \n must always appear at the end of the configuration string; The configuration input is not bounded to any format i.e. It is the responsibility of the customer to define the desired line ID format; There is no restriction on the character set being used - length: x<=63	
[no] force-hold	Parameter type: <Sip::TermService> Format: (disable enable) Possible values: - disable : field is disabled - enable : field is enabled	<i>optional parameter with default value: "disable"</i> force hold functionality
[no] callwait-service	Parameter type: <Sip::TermCallwaitingService> Format: (disabled activated subscribed) Possible values: - disabled : Callwaiting is disabled - activated : Callwaiting is activated	<i>optional parameter with default value: "disabled"</i> callwaiting administrative status

40 Voice Configuration Commands

Parameter	Type	Description
	- subscribed : Callwaiting can be subscribed by end user	
[no] callhold-service	Parameter type: <Sip::TermSupplementaryService> Format: (disabled activated) Possible values: - disabled : the service is disabled - activated : the service is activated	<i>optional parameter with default value: "disabled"</i> callhold administrative status
[no] callconf-service	Parameter type: <Sip::TermSupplementaryService> Format: (disabled activated) Possible values: - disabled : the service is disabled - activated : the service is activated	<i>optional parameter with default value: "disabled"</i> callconference administrative status
[no] calltras-service	Parameter type: <Sip::TermSupplementaryService> Format: (disabled activated) Possible values: - disabled : the service is disabled - activated : the service is activated	<i>optional parameter with default value: "disabled"</i> calltransfer administrative status
[no] fast-guard	Parameter type: <Sip::TermFastGuardOnInvite> Format: (cde-profile enabled disabled) Possible values: - cde-profile : legacy behaviour that applies CDE profile settings - enabled : enable Fast Guard on incoming INVITE - disabled : disable Fast Guard on incoming INVITE	<i>optional parameter with default value: "cde-profile"</i> fast guard administrative status
[no] clear-forward	Parameter type: <Sip::TermClearForwardOnBye> Format: (sip-service-profile enabled disabled) Possible values: - sip-service-profile : legacy behaviour that applies SSP profile settings - enabled : enable Clear Forward on Bye - disabled : disable Clear Forward on Bye	<i>optional parameter with default value: "sip-service-profile"</i> clear forward administrative status
[no] testaccessstate	Parameter type: <Sip::TestAccessState> Format: (on off) Possible values: - on : turn on TestAccessState - off : turn off TestAccessState	<i>optional parameter with default value: "off"</i> test access status
[no] busyoverwrite	Parameter type: <Sip::TestAccessBusyOverWrite> Format: (true false) Possible values: - true : enable TestAccessBusyOverWrite parameter - false : disable TestAccessBusyOverWrite parameter	<i>optional parameter with default value: "false"</i> test access busyoverwrite
[no] accessontimeout	Parameter type: <Sip::TestAccessonTimeout>	<i>optional parameter with default</i>

Parameter	Type	Description
	Format: - value of test access on expires. - unit: second - range: [0...900]	<i>value: "900"</i> time to go until test access timeout. In case test access state is off, the value will be 0. In case test access state is on, this parameter is optional with default initial value 900. The value will start counting down, until value 0 and test access state will be off again.
[no] provider-name	Parameter type: <Sip::TermUserProviderName> Format: - identify the user VSG name for this port - length: x<=32	<i>optional parameter with default value: "vsp1"</i> identify the user VSG name for this termination port
[no] register_recall	Parameter type: <Sip::TermRegisterRecall> Format: - identify the register_recall value. Format: min-max. such as: 100-300, range for min and max is [30...2000]. CDE value will work if configure \"\" or no register_recall. Any other formats are all invalid. - unit: milliseconds - length: x<=16	<i>optional parameter with default value: ""</i> overrule register_recall and on_hook_timer in CDE for this port
[no] sip-rule-set	Parameter type: <Sip::PotsManipulationRuleSet> Format: - the POTS manipulation rule set, at most 32 rule ids can be configured - length: x<=32	<i>optional parameter with default value: ""</i> identify the rules this termination can apply
[no] reserved	Parameter type: <Sip::TermReserved> Format: - reserved for future usage for this port - length: x<=32	<i>optional parameter with default value: ""</i> reserved for future usage for this port
[no] pulse-dialing	Parameter type: <Sip::TermPulseDialing> Format: (disabled enabled) Possible values: - disabled : the pulse dialing is disabled - enabled : the pulse dialing is enabled	<i>optional parameter with default value: "enabled"</i> Termination pulse dialing status
[no] auto-answer	Parameter type: <Sip::TermAutoAnswer> Format: (disable enable) Possible values: - disable : The auto-answer feature is disabled - enable : The auto-answer feature is enabled	<i>optional parameter with default value: "disable"</i> This object allows to enable the auto-answer feature for this termination

40.10 Voice Sip Termination TCA Threshold Configuration Command

Command Description

This command allows the operator to enable/disable tca or configure the high/low threshold for jitter buffer fill level of the sip termination.

User Level

The command can be accessed by operators with sip privileges, and executed by operators with sip privileges.

Command Syntax

The command has the following syntax:

```
> configure voice sip termination (if-index) tca [ [ no ] enable ] [ no high-jbfl | high-jbfl <Sip::JBFL> ] [ no low-jbfl | low-jbfl <Sip::JBFL> ]
```

Command Parameters

Table 40.10-1 "Voice Sip Termination TCA Threshold Configuration Command" Resource Parameters

Resource Identifier	Type	Description
(if-index)	Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number	The unique internal identifier of the termination port

Table 40.10-2 "Voice Sip Termination TCA Threshold Configuration Command" Command Parameters

Parameter	Type	Description
[no] enable	Parameter type: boolean	<i>optional parameter</i> Enable the reporting of tca for sip termination
[no] high-jbfl	Parameter type: <Sip::JBFL> Format: - average of jitter buffer fill level percentage for the termination - unit: percentage	<i>optional parameter with default value: 90</i> the high threshold for jitter buffer fill level. it can not be smaller than low-jbfl. 100 mean

Parameter	Type	Description
	- range: [0...100]	that this parameter shall be omitted by the system.
[no] low-jbfl	Parameter type: <Sip::JBFL> Format: - average of jitter buffer fill level percentage for the termination - unit: percentage - range: [0...100]	<i>optional parameter with default value: 80</i> the low threshold for jitter buffer fill level. it can not be bigger than high-jbfl. 0 mean that this parameter shall be omitted by the system.

40.11 Voice Sip Shared Line Termination Configuration Commands

Command Description

This command allows the operator to manage the Voice Sip shared line termination profile.

User Level

The command can be accessed by operators with sip privileges, and executed by operators with sip privileges.

Command Syntax

The command has the following syntax:

```
> configure voice sip ( no sharedline (if-index) ) | ( sharedline (if-index) [ no directory-number | directory-number
<Sip::TermDnumber> ] [ no user-name | user-name <Sip::TermUserName> ] [ no display-name | display-name
<Sip::TermUserName> ] [ no uri | uri <Sip::TermUri> ] [ no admin-status | admin-status <Sip::TermAdminStatus>
] [ no clip-mode | clip-mode <Sip::TermETSIClipDataMode> ] [ no callwait-service | callwait-service
<Sip::TermCallwaitingService> ] [ no callhold-service | callhold-service <Sip::TermSupplementaryService> ] [ no
callconf-service | callconf-service <Sip::TermSupplementaryService> ] [ no calltras-service | calltras-service
<Sip::TermSupplementaryService> ] )
```

Command Parameters

Table 40.11-1 "Voice Sip Shared Line Termination Configuration Commands" Resource Parameters

Resource Identifier	Type	Description
(if-index)	Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number	The unique internal identifier of the termination port

Table 40.11-2 "Voice Sip Shared Line Termination Configuration Commands" Command Parameters

Parameter	Type	Description
[no] directory-number	Parameter type: <Sip::TermDnumber> Format: - identify the DN of the subscriber line - length: x<=32	<i>optional parameter with default value: ""</i> identify the directory (telephone) number of the subscriber line

Parameter	Type	Description
[no] user-name	Parameter type: <Sip::TermUserName> Format: - identify the user name for this port - length: x<=64	<i>optional parameter with default value: ""</i> identify the user name for this termination port
[no] display-name	Parameter type: <Sip::TermUserName> Format: - identify the user name for this port - length: x<=64	<i>optional parameter with default value: ""</i> display name for this termination port
[no] uri	Parameter type: <Sip::TermUri> Format: - SIP uri by which the user agent identifies subscriber line - length: x<=80	<i>optional parameter with default value: ""</i> sip uri by which user agent identifies subscriber line
[no] admin-status	Parameter type: <Sip::TermAdminStatus> Format: (up down) Possible values: - up : unlock the sip termination - down : lock the sip termination	<i>optional parameter with default value: "down"</i> identify the status of this port administration
[no] clip-mode	Parameter type: <Sip::TermETSIClipDataMode> Format: (cdevalue fsk dtmf) Possible values: - cdevalue : cde configuration will be applied for etsi clip - fsk : fsk will be applied for etsi clip - dtmf : dtmf will be applied for etsi clip	<i>optional parameter with default value: "cdevalue"</i> the etsi clip data transmission protocol of this sip termination
[no] callwait-service	Parameter type: <Sip::TermCallwaitingService> Format: (disabled activated subscribed) Possible values: - disabled : Callwaiting is disabled - activated : Callwaiting is activated - subscribed : Callwaiting can be subscribed by end user	<i>optional parameter with default value: "disabled"</i> callwaiting administrative status
[no] callhold-service	Parameter type: <Sip::TermSupplementaryService> Format: (disabled activated) Possible values: - disabled : the service is disabled - activated : the service is activated	<i>optional parameter with default value: "disabled"</i> callhold administrative status
[no] callconf-service	Parameter type: <Sip::TermSupplementaryService> Format: (disabled activated) Possible values: - disabled : the service is disabled - activated : the service is activated	<i>optional parameter with default value: "disabled"</i> callconference administrative status
[no] calltras-service	Parameter type: <Sip::TermSupplementaryService> Format: (disabled activated) Possible values: - disabled : the service is disabled	<i>optional parameter with default value: "disabled"</i> calltransfer administrative status

40 Voice Configuration Commands

Parameter	Type	Description
	- activated : the service is activated	

40.12 Sip Voice Register Configuration Commands

Command Description

This command allows the operator to configure the SIP Voice Register parameters .

User Level

The command can be accessed by operators with sip privileges, and executed by operators with sip privileges.

Command Syntax

The command has the following syntax:

```
> configure voice sip register (provider-name) [ no register-uri | register-uri <Sip::RegisterUri> ] [ no register-intv |
register-intv <Sip::RegisterIntv> ] [ no reg-retry-intv | reg-retry-intv <Sip::RegisterRetryIntv> ] [ no
reg-prev-ava-intv | reg-prev-ava-intv <Sip::RegisterPrevAvaIntv> ] [ no reg-head-start | reg-head-start
<Sip::RegisterHeadStart> ] [ no reg-start-min | reg-start-min <Sip::RegisterStartMin> ] [ no init-reg-delay |
init-reg-delay <Sip::RegisterDelayInitialRegister> ]
```

Command Parameters

Table 40.12-1 "Sip Voice Register Configuration Commands" Resource Parameters

Resource Identifier	Type	Description
(provider-name)	Format: - provider name - length: x<=32	uniquely identify register provider name

Table 40.12-2 "Sip Voice Register Configuration Commands" Command Parameters

Parameter	Type	Description
[no] register-uri	Parameter type: <Sip::RegisterUri> Format: - The registration URI to be used by all SIP terminations that have a service agreement with this SIP Voice Service Gateway - length: x<=80	<i>optional parameter with default value: ""</i> The registration URI to be used by all SIP terminations that have a service agreement with this SIP Voice Service Gateway.
[no] register-intv	Parameter type: <Sip::RegisterIntv> Format: - The registration expiration time that UA will propose in the Expires header of a REGISTER request, unless the value is 0. If the value is set to 0 the UA shall not refresh a registration even if the server specifies an expiration interval. Accept value greater than or equal to 60 [0[(60..86400)] - unit: second - range: [0,60...86400]	<i>optional parameter with default value: 3600</i> The registration expiration time that UA will propose in the Expires header of a REGISTER request, unless the value is 0. If the value is set to 0 the UA shall not refresh a registration even if the server specifies an expiration interval.
[no] reg-retry-intv	Parameter type: <Sip::RegisterRetryIntv> Format: - The interval between successive registration retries after a	<i>optional parameter with default value: 60</i> The interval between successive

Parameter	Type	Description
	failed registration. The value of 0 shall disable registration retry. The valid input would be [0,30..86400] - unit: second - range: [0,30..86400]	registration retries after a failed registration. The value of 0 shall disable registration retry.
[no] reg-prev-ava-intv	Parameter type: <Sip::RegisterPrevAvaIntv> Format: - The magnitude of time interval that must be awaited before the system is allowed to initiate another register request. - unit: millisecond - range: [30...32000]	<i>optional parameter with default value: 500</i> the magnitude of time interval that must be awaited before the system is allowed to initiate another register request.
[no] reg-head-start	Parameter type: <Sip::RegisterHeadStart> Format: - The time prior to expiration of a registration at which the UA sends a registration refresh. If the value of register_head_start is greater than (1 - start_min%) of the value for register_period, then the register_head_start value will be ignored and a timer equal to start_min% of the value for register_period will be used for this function, a value 0 means register_head_start will not be used - unit: second - range: [0...86400]	<i>optional parameter with default value: 600</i> The time prior to expiration of a registration at which the UA sends a registration refresh, if the value of register_head_start is greater than (1 - start_min%) of the value for register_period, then the register_head_start value will be ignored and a timer equal to start_min% of the value for register_period will be used for this function, a value 0 means, this value will not be used, valid input would be [0,32..86400]
[no] reg-start-min	Parameter type: <Sip::RegisterStartMin> Format: - The time prior to expiration of a registration at which a registration refresh is sent, if the value of register_head_start is greater than (1 - start_min%) of the value for the Expires value received in the 200 OK response to last REGISTER request for this line (either the Expires parameter in the Contact header or, if that is not present, in an Expires header), then the register_head_start value is ignored and a timer equal to start_min% of the value for register_period is used for this function - unit: percentage - range: [30...70]	<i>optional parameter with default value: 50</i> The time prior to expiration of a registration at which a registration refresh is sent. If the value of register_head_start is greater than (1 - start_min%) of the value for the Expires value received in the 200 OK response to last REGISTER request for this line (either the Expires parameter in the Contact header or, if that is not present, in an Expires header), then the register_head_start value is ignored and a timer equal to start_min% of the value for register_period is used for this function.
[no] init-reg-delay	Parameter type: <Sip::RegisterDelayInitialRegister> Format: - Configurable delayed initial register time for failure cases with response without Retry-After header included. range is [0,10...400] - unit: second	<i>optional parameter with default value: 180</i> Configurable delayed initial register time for failure cases with response without Retry-After header included. This object only applies to POTS. range is [0,10...400]

40.13 Voice Sip Transport Configuration Commands

Command Description

This command allows the operator to manage the Voice Sip Transport params.

IPv6 is actually not supported. All references to IPv6 must be ignored since mentioned for future usage only.

User Level

The command can be accessed by operators with sip privileges, and executed by operators with sip privileges.

Command Syntax

The command has the following syntax:

```
> configure voice sip ( no transport (trans-protocol) provider-name <Sip::TransportProviderName> ) | ( transport
(trans-protocol) provider-name <Sip::TransportProviderName> [ no admin-status | admin-status
<Sip::TransportAdminStatus> ] [ no port-rcv | port-rcv <Sip::TransportPortRcv> ] [ no tcp-idle-time | tcp-idle-time
<Sip::TransportTCPIidleTime> ] [ no max-out-udp-size | max-out-udp-size <Sip::TransportMaxOutgUdpReqSize>
] [ no tls-port-rcv | tls-port-rcv <Sip::TransportPortTLSPrcv> ] )
```

Command Parameters

Table 40.13-1 "Voice Sip Transport Configuration Commands" Resource Parameters

Resource Identifier	Type	Description
(trans-protocol)	Format: (udp tcp udp_tcp tls_over_tcp udp_tls tcp_tls udp_tcp_tls udp_swo_tcp) Possible values: - udp : transport protocol is UDP - tcp : transport protocol is TCP - udp_tcp : transport protocol is UDP or TCP. TCP is the preferred transport protocol. If UDP would be used and the size of the message exceeds a configured threshold then a switch can be made to TCP - tls_over_tcp : transport protocol is TLSoverTCP - udp_tls : transport protocol is UDP or TLSoverTCP. TLSoverTCP is the preferred transport protocol - tcp_tls : transport protocol is TCP or TLSoverTCP. TLSoverTCP	Terminations will use this transport for establishing the calls

Resource Identifier	Type	Description
	is the preferred transport protocol - udp_tcp_tls : transport protocol is UDP, TCP or TLS over TCP. TLS over TCP is the preferred transport protocol. The next preferred transport protocol is TCP and finally UDP. If UDP would be used and the size of the message exceeds a configured threshold then a switch can be made to TCP - udp_swo_tcp : transport protocol is UDP or TCP. Basically, UDP is to be used. When size of message exceeds a configured threshold then a switch is made to TCP	
provider-name	Parameter type: <Sip::TransportProviderName> Format: - uniquely identifies the transport provider name - length: x<=32	uniquely identify transport provider name

Table 40.13-2 "Voice Sip Transport Configuration Commands" Command Parameters

Parameter	Type	Description
[no] admin-status	Parameter type: <Sip::TransportAdminStatus> Format: (up down) Possible values: - up : unlock the dns server - down : lock the dns server	<i>optional parameter with default value: "down"</i> change administrative status
[no] port-rcv	Parameter type: <Sip::TransportPortRcv> Format: - Defines transport protocol port the UserAgent has to listen to for incoming SIP requests. - range: [0...65534]	<i>optional parameter with default value: 5060</i> Defines transport protocol port the User Agent has to listen to for incoming SIP requests.
[no] tcp-idle-time	Parameter type: <Sip::TransportTCPIIdleTime> Format: - Define the max time period that a TCP shall be kept alive without exchanging any msg. - unit: second - range: [32...3600]	<i>optional parameter with default value: 64</i> Define the max time period that a tcp shall be kept alive without exchanging any msg.
[no] max-out-udp-size	Parameter type: <Sip::TransportMaxOutgUdpReqSize> Format: - Define the maximum SIP message size that can be sent over UDP. The minimum value of IPv4 is 576, the minimum value for IPv6 is 1280 - unit: bytes - range: [576...65535]	<i>optional parameter with default value: 65535</i> Define the maximum SIP message size that can be sent over udp
[no] tls-port-rcv	Parameter type: <Sip::TransportPortTLSPortRcv> Format: - Define transport protocol port to which the SIP User Agent will listen when TLS over TCP applies as underlying transport protocol for SIP. - range: [0...65534]	<i>optional parameter with default value: 5061</i> Define transport protocol port to which the SIP User Agent will listen when TLS over TCP applies as underlying transport protocol for SIP.

40.14 Voice Sip Redundancy Table Configuration Commands

Command Description

This command allows the operator to manage the Voice Sip Redundancy table.

User Level

The command can be accessed by operators with sip privileges, and executed by operators with sip privileges.

Command Syntax

The command has the following syntax:

```
> configure voice sip redundancy (admin-domain-name) [ no support-redun | support-redun
<Sip::NetwRedunSupported> ] [ no dns-purge-timer | dns-purge-timer <Sip::NetwRedunDnsPurgeTimer> ] [ no
dns-ini-retr-int | dns-ini-retr-int <Sip::NetwRedunDnsInitRetranTimer> ] [ no dns-max-retr-nbr | dns-max-retr-nbr
<Sip::NetwRedunDnsMaxRetrNbr> ] [ no fg-monitor-method | fg-monitor-method
<Sip::NetwRedunFgMonitorMethod> ] [ no fg-monitor-int | fg-monitor-int <Sip::NetwRedunFgMonitorInt> ] [ no
bg-monitor-method | bg-monitor-method <Sip::NetwRedunBgMonitorMethod> ] [ no bg-monitor-int |
bg-monitor-int <Sip::NetwRedunBgMonitorInt> ] [ no stable-obs-period | stable-obs-period
<Sip::NetwRedunStableObsPeriod> ] [ no fo-hystersis | fo-hystersis <Sip::NetwRedunFailoverHystersis> ] [ no
del-upd-threshold | del-upd-threshold <Sip::NetwRedunDeliUpdThreshold> ] [ no auto-server-fo | auto-server-fo
<Sip::NetwRedunAutoFailOver> ] [ no auto-server-fb | auto-server-fb <Sip::NetwRedunAutoFailBack> ] [ no
auto-sos-fo | auto-sos-fo <Sip::NetwRedunAutoFailOver> ] [ no auto-sos-fb | auto-sos-fb
<Sip::NetwRedunAutoSosFailback> ] [ no rtry-after-thrsh | rtry-after-thrsh <Sip::NetwRedunRetryAfterThreshold>
] [ no options-max-fwd | options-max-fwd <Sip::NetwRedunOPTIONSMaxForward> ] [ no dns-redun-mode |
dns-redun-mode <Sip::NetwRedundnsredunmode> ] [ no fail-obs-timer | fail-obs-timer
<Sip::NetwRedunFailureObservationTimer> ] [ no fg-intv-503 | fg-intv-503 <Sip::NetwRedun503FGMonitorIntv>
] [ no time-thrsh-503 | time-thrsh-503 <Sip::NetwRedun503MaxTimeThreshold> ] [ no nbr-thrsh-503 |
nbr-thrsh-503 <Sip::NetwRedun503MaxNbrThreshold> ] [ no auto-srv-fo-timer | auto-srv-fo-timer
<Sip::netwRedunAutoSIPServerFOTimer> ]
```

Command Parameters

Table 40.14-1 "Voice Sip Redundancy Table Configuration Commands" Resource Parameters

Resource Identifier	Type	Description
(admin-domain-name)	Format: - uniquely name of this element - length: x<=32	The administrative domain name of the (farm of) SIP First hop(s)

Table 40.14-2 "Voice Sip Redundancy Table Configuration Commands" Command Parameters

Parameter	Type	Description
[no] support-redun	Parameter type: <Sip::NetwRedunSupported> Format: (enable	<i>optional parameter with default value: "disable"</i> This object allows the

Parameter	Type	Description
	disable) Possible values: - enable : support Redundancy - disable : doesn't support Redundancy	administrator to define whether the Voice Service Gateway network supports redundancy or not.
[no] dns-purge-timer	Parameter type: <Sip::NetwRedunDnsPurgeTimer> Format: - Expire of the DNS Purge Timer, a value 0 means that the DNS purge timer is disabled - unit: second - range: [0...86400]	<i>optional parameter with default value: 86400</i> Expire of the DNS Purge Timer, a value 0 means that the DNS purge timer is disabled.
[no] dns-ini-retr-int	Parameter type: <Sip::NetwRedunDnsInitRetranTimer> Format: - Initial DNS retransmission Interval - unit: milliseconds - range: [200...1000]	<i>optional parameter with default value: 500</i> The initial DNS query retransmission interval(in ms).
[no] dns-max-retr-nbr	Parameter type: <Sip::NetwRedunDnsMaxRetrNbr> Format: - Maximum DNS retransmission times - range: [0...4]	<i>optional parameter with default value: 2</i> The maximum DNS query retransmission times.
[no] fg-monitor-method	Parameter type: <Sip::NetwRedunFgMonitorMethod> Format: (register-method options-method passive-heartbeat) Possible values: - register-method : Foreground Service Healthy Monitoring mode : register-method - options-method : Foreground Service Healthy Monitoring mode : options-method - passive-heartbeat : Foreground Service Healthy Monitoring mode : passive-heartbeat	<i>optional parameter with default value: "register-method"</i> The Foreground healthy monitoring method.
[no] fg-monitor-int	Parameter type: <Sip::NetwRedunFgMonitorInt> Format: - The Foreground healthy monitoring interval, range is [0,30..3600],0 means disable. - unit: second	<i>optional parameter with default value: 90</i> The Foreground healthy monitoring interval, range is [0,30..3600],0 means disable.
[no] bg-monitor-method	Parameter type: <Sip::NetwRedunBgMonitorMethod> Format: options-method Possible values: - options-method : Background Service Healthy Monitoring mode : options-method	<i>optional parameter with default value: "options-method"</i> The Background healthy monitoring method.
[no] bg-monitor-int	Parameter type: <Sip::NetwRedunBgMonitorInt> Format: - The Background healthy monitoring interval,range is [0,60..86400], 0 means disable. - unit: second	<i>optional parameter with default value: 3600</i> The Background healthy monitoring interval,range is [0,60..86400], 0 means disable.
[no] stable-obs-period	Parameter type: <Sip::NetwRedunStableObsPeriod> Format: - Configurable stable operation observation period, a value 0 means that the Stable-Operation Observation Period is disabled - unit: second - range: [0...86400]	<i>optional parameter with default value: 21600</i> Configurable stable operation observation period, a value 0 means that the Stable-Operation Observation Period is disabled.
[no] fo-hystersis	Parameter type: <Sip::NetwRedunFailoverHystersis> Format: - Fail-Over Hysteresis Threshold, a value 0 means that the	<i>optional parameter with default value: 0</i> The Fail-Over hysteresis,a value

Parameter	Type	Description
	Fail-Over Hysteresis is disabled - range: [0...5]	0 means that the Fail-Over Hysteresis is disabled.
[no] del-upd-threshold	Parameter type: <Sip::NetwRedunDeliUpdThreshold> Format: - The Deliberate Update Threshold. When set to 0, then upon a SIP server priority change or a change of the list of SIP servers. DU is immediately triggered for idle SIP terminations. DU is triggered upon call completion for SIP terminations involved in a call, with a maximum time limit of 60 sec. i.e. if after 60 sec the call is still not finished, then the call is aborted and DU is performed for that SIP termination. - unit: second - range: [0...86400]	<i>optional parameter with default value: 0</i> The Deliberate Update Threshold. When set to 0, then upon a SIP server priority change or a change of the list of SIP servers. DU is immediately triggered for idle SIP terminations. DU is triggered upon call completion for SIP terminations involved in a call, with a maximum time limit of 60 sec. i.e. if after 60 sec the call is still not finished, then the call is aborted and DU is performed for that SIP termination.
[no] auto-server-fo	Parameter type: <Sip::NetwRedunAutoFailOver> Format: (enable disable) Possible values: - enable : Support autonomous Fail-Over - disable : Not support autonomous Fail-Over	<i>optional parameter with default value: "disable"</i> This object allows to enable/disable autonomous SIP Server Fail-Over.
[no] auto-server-fb	Parameter type: <Sip::NetwRedunAutoFailBack> Format: - support/unsupported Autonomous SIP server Fail-Back, a value 0 means disable this functionality, not 0 means that SIP server Fail-Back is enabled. The value indicates the time period by which the SIP server Fail-Back must be done - unit: second - range: [0...86400]	<i>optional parameter with default value: 0</i> This object allows to enable/disable autonomous SIP Server Fail-Back.If value != 0, the value indicates the time period by which the SIP server Fail-Back must be completed, a value 0 means disable
[no] auto-sos-fo	Parameter type: <Sip::NetwRedunAutoFailOver> Format: (enable disable) Possible values: - enable : Support autonomous Fail-Over - disable : Not support autonomous Fail-Over	<i>optional parameter with default value: "disable"</i> This object allows to enable/disable autonomous SOS Fail-Over.
[no] auto-sos-fb	Parameter type: <Sip::NetwRedunAutoSosFailback> Format: - support/unsupported Autonomous SOS Fail-Back, a value 0 means disable this functionality,not 0 means that SIP SOS Fail-Back is enabled. The value indicates the time period by which the SIP SOS Fail-Back must be done - unit: second - range: [0...86400]	<i>optional parameter with default value: 0</i> This object allows to enable/disable autonomous SOS Fail-Back.If value != 0, the value indicates the time period by which the SOS Fail-Back must be completed,a value 0 means disable
[no] rtry-after-thrsh	Parameter type: <Sip::NetwRedunRetryAfterThreshold> Format: - Retry-after threshold. - unit: milliseconds - range: [0...30000]	<i>optional parameter with default value: 0</i> The retry after Threshold.
[no] options-max-fwd	Parameter type: <Sip::NetwRedunOPTIONSMaxForward> Format:	<i>optional parameter with default value: 0</i>

Parameter	Type	Description
	- Max-Forward of OPTION, Value - 0: Must not forward this OPTIONS, Value - 1: Allow to forward once. - range: [0...1]	Max-forwarding is used to configure max-forward attribute for the forwarding property of the SIP OPTIONS message.
[no] dns-redun-mode	Parameter type: <Sip::NetwRedundnsredunmode> Format: (dns-redun-primary dns-redun-success) Possible values: - dns-redun-primary : dns redun mode is dns-redun-primary - dns-redun-success : dns redun mode is dns-redun-success	<i>optional parameter with default value: "dns-redun-primary"</i> DNS Redundancy Mode, dns-redun-primary means the DNS query will be sent to primary DNS server always firstly, dns-redun-success Means the DNS query will be sent to the DNS server where the previous request was successfully respond.
[no] fail-obs-timer	Parameter type: <Sip::NetwRedunFailureObservationTimer> Format: - The failure observation timer, range is [0,60..480]. - unit: second	<i>optional parameter with default value: 240</i> Configurable the failure observation timer for failure cases, The failure observation timer allowing to verify whether after the receipt of a recoverable error, a SIP register is still successfully replied. This object only applies to POTS. range is [0,60..480].
[no] fg-intv-503	Parameter type: <Sip::NetwRedun503FGMonitorIntv> Format: - The 503-restoration-mode FGHM interval, range is [0,2..3600]. - unit: second	<i>optional parameter with default value: 2</i> The configurable 503-restoration-mode FGHM interval that applies from the moment a 503 error response is received to the FGHM re-register request. This object has only relevance in case the overall restoration behaviour regarding a 503 response to a SIP register request is enabled in the SIP service Profile. This object only applies to POTS. range is [0,2..3600].
[no] time-thrsh-503	Parameter type: <Sip::NetwRedun503MaxTimeThreshold> Format: - The maximum elapse time during which a consecutive series of 503 responses to initial/re-register requests is allowed, range is [0,180..7200]. - unit: second	<i>optional parameter with default value: 0</i> The maximum elapse time during which a consecutive series of 503 responses to initial/re-register requests is allowed. The system will trigger a fail-over when EITHER the 503MaxTimeThreshold OR the 503MaxNbrThreshold is reached i.e. only one of the conditions must be fulfilled to trigger a fail-over. This object only applies to POTS. range is [0,180..7200].
[no] nbr-thrsh-503	Parameter type: <Sip::NetwRedun503MaxNbrThreshold> Format: - The maximum number of consecutive 503 responses to	<i>optional parameter with default value: 1</i> The maximum number of

Parameter	Type	Description
	initial/re-register requests that is allowed, range is [0,1,2..144].	consecutive 503 responses to initial/re-register requests that is allowed. The system will trigger a fail-over when EITHER the 503MaxTimeThreshold OR the 503MaxNbrThreshold is reached i.e. only one of the conditions must be fulfilled to trigger a fail-over. This object only applies to POTS. range is [0,1,2..144]. A value 1 means that the 503 Max Number Threshold equals [the number of configured and administratively enabled SIP terminations at the voice LT board * 2].
[no] auto-srv-fo-timer	Parameter type: <Sip::netwRedunAutoSIPServerFOTimer> Format: - The configured elapse time by which a graceful autonomous SIP Server Fail-Over/SOS Fail-Over must be completed for all involved SIP terminations. When set to the default value '86400': The netwRedunAutoSIPServerFOTimer is considered as 'disabled'. For those SIP terminations that are involved in an ongoing call, the fail-over is postponed till the ongoing call has terminated. (backward compatible behaviour.) When set to the value '0': The fail-over (for POTS as well as ISDN PRI and CAS R2 SIP terminations) is immediately triggered. Calls that are ongoing at the moment the fail-over is triggered are immediately dropped. When set to a value [1..86399]: For those POTS SIP terminations that are involved in an ongoing call at the moment the Fail-Over is triggered, the Fail-Over will be postponed until either the call is released (while the FO timer is still running) or the FO timer has expired or session-refresh failure or SIP in-dialog communication failure. Ongoing calls are immediately dropped upon the expiry of the FO timer. For ISDN PRA and CAS R2 terminations, the Fail-Over is immediately triggered, however ongoing calls are kept until either the call is released (while the FO timer is still running) or the FO timer has expired or session-refresh failure or SIP in-dialog communication failure. Ongoing calls are immediately dropped upon the expiry of the FO timer. New calls are established via E1 interface/B-channels that already made a fail-over. - unit: second - range: [0...86400]	<i>optional parameter with default value: 86400</i> The configured elapse time by which a graceful autonomous SIP Server Fail-Over/SOS Fail-Over must be completed for all involved SIP terminations. When set to the default value '86400': The netwRedunAutoSIPServerFOTimer is considered as 'disabled'. For those SIP terminations that are involved in an ongoing call, the fail-over is postponed till the ongoing call has terminated. (backward compatible behaviour.) When set to the value '0': The fail-over (for POTS as well as ISDN PRI and CAS R2 SIP terminations) is immediately triggered. Calls that are ongoing at the moment the fail-over is triggered are immediately dropped. When set to a value [1..86399]: For those POTS SIP terminations that are involved in an ongoing call at the moment the Fail-Over is triggered, the Fail-Over will be postponed until either the call is released (while the FO timer is still running) or the FO timer has expired or session-refresh failure or SIP in-dialog communication failure. Ongoing calls are immediately dropped upon the expiry of the FO timer. For ISDN PRA and CAS R2 terminations, the Fail-Over is immediately triggered, however ongoing calls are kept until either the call is

40 Voice Configuration Commands

Parameter	Type	Description
		released (while the FO timer is still running) or the FO timer has expired or session-refresh failure or SIP in-dialog communication failure. Ongoing calls are immediately dropped upon the expiry of the FO timer. New calls are established via E1 interface/B-channels that already made a fail-over.

40.15 Voice Sip System Session Timer Configuration Commands

Command Description

this command allows the operator to manage the voice sip session timer profile. The timer is used to consult with remote, and at last, if session timer was enabled, the refresh timer will be started by IPTK. The SIP Session Timer feature adds the capability to periodically refresh SIP sessions by sending repeated INVITE requests. The repeated INVITE requests, or re-INVITES, are sent during an active call leg to allow user agents (UA) or SIP proxies to determine the status of a SIP session. Without this keep alive mechanism, proxies that remember incoming and outgoing requests (stateful proxies) may continue to retain call state needlessly. If a UA fails to send a BYE message at the end of a session or if the BYE message is lost because of network problems, a stateful proxy does not know that the session has ended. The re-INVITES ensure that active sessions stay active and completed sessions are terminated.

User Level

The command can be accessed by operators with sip privileges, and executed by operators with sip privileges.

Command Syntax

The command has the following syntax:

```
> configure voice sip system session-timer [ [ no ] enable ] [ no status | status <Sip::SessionTimerAdminState> ] [
no min-se-time | min-se-time <Sip::SessionTimerMinSE> ] [ no se-time | se-time
<Sip::SessionTimerSessionExpire> ] [ no admin-status | admin-status <Sip::SysObjectsAdminStatus> ]
```

Command Parameters

Table 40.15-2 "Voice Sip System Session Timer Configuration Commands" Command Parameters

Parameter	Type	Description
[no] enable	Parameter type: boolean	<i>obsolete parameter replaced by parameter "status"</i> Prefix activated of session timer is enable
[no] status	Parameter type: <Sip::SessionTimerAdminState> Format: (enable disable enable-uas) Possible values: - enable : Prefix activated of session timer is enable - disable : Prefix activated of session timer is disable - enable-uas : Prefix activated of session timer is enableAsUas	<i>optional parameter with default value: "disable"</i> To configure the SIP Session Timer feature capability. If it's disable, shall not request session expiration in initial INVITE requests and 200 OK responses If it's enable, shall request session expiration in initial INVITE requests and 200 OK responses, and in both cases, if an incoming initial INVITE request contains a

Parameter	Type	Description
		session expiration header, but does not include the refresher value, then shall use uac for the refresher parameter. If it's enable-uas, shall request session expiration in initial INVITE requests and 200 OK responses, and in both cases, if an incoming initial INVITE request contains a session header, but does not include the refresher value, then shall use uas for the refresher parameter.
[no] min-se-time	Parameter type: <Sip::SessionTimerMinSE> Format: - value of min-se when use session time - unit: second - range: [90...65535]	<i>optional parameter with default value: "90"</i> Minimum Session Expires time. The lower bound for the session refresh interval. Because of the processing load of INVITE requests, the SIP proxy, User Agent Client and User Agent Server can have a configured minimum refresh timer value that they can accept. It is conveyed in the Min-SE header in the initial INVITE request. When making a call, the presence of the Min-SE header informs the UAS and any proxy of the minimum value that the UAC accepts for the session timer duration, in units of delta-seconds.
[no] se-time	Parameter type: <Sip::SessionTimerSessionExpire> Format: - value of session-expires when use sessiontime - unit: second - range: [90...65535]	<i>optional parameter with default value: "1800"</i> Session Expires Time. The upper bound for the session refresh interval. It is conveyed in the Session-Expires header in the initial INVITE request. If a session refresh request is not received before the interval passes, the session is considered terminated.
[no] admin-status	Parameter type: <Sip::SysObjectsAdminStatus> Format: (up down) Possible values: - up : unlock the sipSysObjects - down : lock the sipSysObjects	<i>optional parameter with default value: "down"</i> The administrative status of this sipSysObjects

40.16 Voice Sip DNS Server Configuration Commands

Command Description

This command allows the operator to manage the Voice Sip DNS Server profile.

IPv6 is actually not supported. All references to IPv6 must be ignored since mentioned for future usage only.

User Level

The command can be accessed by operators with sip privileges, and executed by operators with sip privileges.

Command Syntax

The command has the following syntax:

```
> configure voice sip ( no dnsserver (name) ) | ( dnsserver (name) [ no admin-status | admin-status
<Sip::sipDNSServerAdminStatus> ] address <Sip::sipDNSServerAddr> [ no priority | priority
<Sip::sipDNSServerPriority> ] [ no site | site <Sip::sipDNSServerSite> ] admin-domain-name
<Sip::AdminDomName> [ no port | port <Sip::sipDNSServerPort> ] )
```

Command Parameters

Table 40.16-1 "Voice Sip DNS Server Configuration Commands" Resource Parameters

Resource Identifier	Type	Description
(name)	Format: - uniquely identifies this voice dns server - length: 1<=x<=32	uniquely identify of this sip DNS server

Table 40.16-2 "Voice Sip DNS Server Configuration Commands" Command Parameters

Parameter	Type	Description
[no] admin-status	Parameter type: <Sip::sipDNSServerAdminStatus> Format: (up down) Possible values: - up : unlock the dns server - down : lock the dns server	<i>optional parameter with default value: "down"</i> administrative status of this DNS server
address	Parameter type: <Sip::sipDNSServerAddr> Format: (ipv4 : <Ip::V4Address> ipv6 : <Ip::V6Address>) Possible values: - ipv4 : the address type of the server is IPv4 - ipv6 : the address type of the server is IPv6 Field type <Ip::V4Address>	<i>mandatory parameter</i> The address(IPv4 or IPv6) of this DNS server

40 Voice Configuration Commands

Parameter	Type	Description
	- IPv4-address Field type <Ip::V6Address> - IPv6-address	
[no] priority	Parameter type: <Sip::sipDNSServerPriority> Format: - the SIP dns server priority, lower value with higher priority - range: [0...65535]	<i>optional parameter with default value: 100</i> The priority of sip DNS server, lower value with higher priority
[no] site	Parameter type: <Sip::sipDNSServerSite> Format: (primary-site geo-backup-site) Possible values: - primary-site : the server belongs to the GEO primary site - geo-backup-site : the server belongs to the GEO secondary site	<i>optional parameter with default value: "primary-site"</i> The site which the sip DNS server is belonged to
admin-domain-name	Parameter type: <Sip::AdminDomName> Format: - uniquely name of this element - length: x<=32	<i>mandatory parameter</i> The administrative domain name of the DNS server. The administrative domain might be the VoIP Access Seeker Network or the Connectivity Serving Network.
[no] port	Parameter type: <Sip::sipDNSServerPort> Format: - - range: [1...65534]	<i>optional parameter with default value: 53</i> The remote port of sip DNS server, a value 0 means use default value 53

40.17 Voice Sip DHCP Authentication Params Configuration Commands

Command Description

This command allows the operator to manage the Voice Sip DHCP authentication params.

User Level

The command can be accessed by operators with sip privileges, and executed by operators with sip privileges.

Command Syntax

The command has the following syntax:

```
> configure voice sip ( no dhcp-authent-para (ua-name) secret-id <Sip::DHCPAuthentParaSecretId> ) | (
dhcp-authent-para (ua-name) secret-id <Sip::DHCPAuthentParaSecretId> [ no key | key
<Sip::DHCPAuthentParaKey> ] [ no action-type | action-type <Sip::DHCPAuthentParaActionType> ] )
```

Command Parameters

Table 40.17-1 "Voice Sip DHCP Authentication Params Configuration Commands" Resource Parameters

Resource Identifier	Type	Description
(ua-name)	Format: - uniquely identifies the User Agent - length: 1<=x<=32	uniquely identify of the user agent
secret-id	Parameter type: <Sip::DHCPAuthentParaSecretId> Format: - Unique identifier of the DHCP message authentication parameter record - range: [1...4294967295]	A unique identifier of the DHCP message authentication parameter record

Table 40.17-2 "Voice Sip DHCP Authentication Params Configuration Commands" Command Parameters

Parameter	Type	Description
[no] key	Parameter type: <Sip::DHCPAuthentParaKey> Format: - DHCP secret key used for DHCP message authentication. Every letter in key must be in '0'~'9', 'a'~'f', 'A'~'F' and the string length must be even. - length: x<=32	<i>optional parameter with default value: ""</i> DHCP secret key used for DHCP message authentication. Every letter in key must be in '0'~'9', 'a'~'f', 'A'~'F' and the string length must be even.
[no] action-type	Parameter type: <Sip::DHCPAuthentParaActionType> Format: (normal-req-key force-discover	<i>optional parameter with default value: "normal-send-req"</i> the action type for the configured DHCP secret keys

40 Voice Configuration Commands

Parameter	Type	Description
	force-request normal-force-dis normal-force-req) Possible values: - normal-req-key : used when send DHCP request, not used for response - force-discover : used when force renew received with this key, will send DHCP discover - force-request : used when force renew received with this key, will send DHCP renew request - normal-force-dis : used when send DHCP request, not used for response, and when force renew received with this key, will send DHCP discover - normal-force-req : used when send DHCP request, not used for response, and when force renew received with this key, will send DHCP renew request	

40.18 Voice Sip Restoration Failover/Failback Type/Mode Configuration Commands

Command Description

This command allows the operator to change the Failover/Failback type or mode.

User Level

The command can be accessed by operators with sip privileges, and executed by operators with sip privileges.

Command Syntax

The command has the following syntax:

```
> configure voice sip redundancy-cmd (domain-name) [ no start-time | start-time <Sip::FailXStartTime> ] [ no
end-time | end-time <Sip::FailXEndTime> ] [ fail-x-type <Sip::FailXType> ]
```

Command Parameters

Table 40.18-1 "Voice Sip Restoration Failover/Failback Type/Mode Configuration Commands" Resource Parameters

Resource Identifier	Type	Description
(domain-name)	Format: - uniquely identifies the transport provider name - length: x<=32	uniquely identify of admin domain name

Table 40.18-2 "Voice Sip Restoration Failover/Failback Type/Mode Configuration Commands" Command Parameters

Parameter	Type	Description
[no] start-time	Parameter type: <Sip::FailXStartTime> Format: - The absolute time when the manually triggered GEO Fail-Over / Fail-Back needs to start. The unit is in seconds. - unit: second - range: [0...4294967295]	<i>optional parameter with default value: 0</i> The absolute time when the manually triggered GEO Fail-Over / Fail-Back needs to start. The unit is in seconds.
[no] end-time	Parameter type: <Sip::FailXEndTime> Format: - The absolute time when the manually triggered graceful GEO Fail-Over / Fail-Back needs to be completed. The unit is in seconds. - unit: second - range: [0...4294967295]	<i>optional parameter with default value: 0</i> The absolute time when the manually triggered graceful GEO Fail-Over / Fail-Back needs to be completed. The unit is in seconds.
fail-x-type	Parameter type: <Sip::FailXType> Format: (geo-fail-over geo-fail-back)	<i>optional parameter</i> Fail X type, failover or failback.

40 Voice Configuration Commands

Parameter	Type	Description
	Possible values: - geo-fail-over : geo fail over - geo-fail-back : geo fail back	

40.19 Voice Statistics Configure Command

Command Description

Set statistics configuration.

User Level

The command can be accessed by operators with sip privileges, and executed by operators with sip privileges.

Command Syntax

The command has the following syntax:

```
> configure voice sip statistics [ no stats-5min-config | stats-5min-config <Sip::FiveMStats> ] [ no cdr-config |
cdr-config <Sip::CallRecord> ]
```

Command Parameters

Table 40.19-2 "Voice Statistics Configure Command" Command Parameters

Parameter	Type	Description
[no] stats-5min-config	Parameter type: <Sip::FiveMStats> Format: (disable enable) Possible values: - disable : disable 5m stats function - enable : enable 5m stats function	<i>optional parameter with default value: "disable"</i> enable/disable the 5-Min Statistics
[no] cdr-config	Parameter type: <Sip::CallRecord> Format: (disable enable) Possible values: - disable : disable call record function - enable : enable call record function	<i>optional parameter with default value: "disable"</i> enable/disable the call record

40.20 Voice Statistics Mode Configuration

Command

Command Description

Change voice statistics Mode.

User Level

The command can be accessed by operators with sip privileges, and executed by operators with sip privileges.

Command Syntax

The command has the following syntax:

```
> configure voice sip statistics stats-config [ [ no ] per-line ] [ [ no ] per-board ] [ [ no ] per-system ] [ [ no ] per-call ] [ [ no ] out-any-rsp ] [ [ no ] out-180-rsp ] [ [ no ] out-200-rsp ] [ [ no ] in-any-rsp ] [ [ no ] in-180-rsp ] [ [ no ] in-200-rsp ]
```

Command Parameters

Table 40.20-2 "Voice Statistics Mode Configuration Command" Command Parameters

Parameter	Type	Description
[no] per-line	Parameter type: boolean	<i>optional parameter</i> enable per line statistics function
[no] per-board	Parameter type: boolean	<i>optional parameter</i> enable per board statistics function
[no] per-system	Parameter type: boolean	<i>optional parameter</i> enable per system statistics function
[no] per-call	Parameter type: boolean	<i>optional parameter</i> enable per call statistics function
[no] out-any-rsp	Parameter type: boolean	<i>optional parameter</i> enable Arbitrary Response Mode for out-going call answered
[no] out-180-rsp	Parameter type: boolean	<i>optional parameter</i> enable 180 Response Mode for out-going call answered
[no] out-200-rsp	Parameter type: boolean	<i>optional parameter</i> enable 200 Response Mode for out-going call answered
[no] in-any-rsp	Parameter type: boolean	<i>optional parameter</i> enable Arbitrary Response Mode for in-coming call answered
[no] in-180-rsp	Parameter type: boolean	<i>optional parameter</i> enable 180 Response Mode for

Parameter	Type	Description
		in-coming call answered
[no] in-200-rsp	Parameter type: boolean	<i>optional parameter</i> enable 200 Response Mode for in-coming call answered

40.21 Voice Sip Isdn/Cas Termination Configuration Commands

Command Description

This command allows the operator to manage the Voice Sip Isdn/Cas termination profile.

User Level

The command can be accessed by operators with sip privileges, and executed by operators with sip privileges.

Command Syntax

The command has the following syntax:

```
> configure voice sip ( no isdn-cas-term (if-index) ) | ( isdn-cas-term (if-index) [ no directory-number |
directory-number <Sip::TermDnumber> ] [ no user-name | user-name <Sip::TermUserName> ] [ no display-name |
display-name <Sip::TermUserName> ] [ no uri | uri <Sip::TermUri> ] [ no md5-realm | md5-realm
<Sip::MD5Realm> ] [ no md5-password | md5-password <Security::Password4> ] [ no aka-secret-key |
aka-secret-key <Security::Password8> ] [ no admin-status | admin-status <Sip::IsdnTermAdminStatus> ] [ no
line-id | line-id <Sip::ISDNTermLineId> ] [ no testaccessstate | testaccessstate <Sip::TestAccessState> ] [ no
busyoverwrite | busyoverwrite <Sip::TestAccessBusyOverWrite> ] [ no accessontimeout | accessontimeout
<Sip::TestAccessonTimeout> ] [ no provider-name | provider-name <Sip::TermUserProviderName> ] [ no
signalling-type | signalling-type <Sip::TermSignallingType> ] [ no cpn-screen | cpn-screen
<Sip::TermCallingScreen> ] [ no default-cpc | default-cpc <Sip::TermDefaultCPC> ] [ no restrict-acc | restrict-acc
<Sip::TermRestrictACC> ] [ no hunting-way | hunting-way <Sip::TermHuntingWay> ] [ no sip-rule-set |
sip-rule-set <Sip::IsdnCasManipulationRuleSet> ] [ no cas-exch-type | cas-exch-type <Sip::TermExchangeType> ]
[ no q-value | q-value <Sip::IsdnCasTerminationQValue> ] [ no reg-mode | reg-mode
<Sip::IsdnCasTerminationRegMode> ] [ no e1-hunting-way | e1-hunting-way
<Sip::IsdnCasTerminationE1HuntingWay> ] [ no e1-cluster-itf | e1-cluster-itf
<Sip::IsdnCasTerminationE1ClusterItf> ] [ no e1-cluster-name | e1-cluster-name
<Sip::IsdnCasTerminationE1ClusterName> ] [ no isdn-nsm-profile | isdn-nsm-profile <Sip::NsmProfile> ] [ no
cas-nsm-profile | cas-nsm-profile <Sip::CasNsmProfPointer> ] )
```

Command Parameters

Table 40.21-1 "Voice Sip Isdn/Cas Termination Configuration Commands" Resource Parameters

Resource Identifier	Type	Description
(if-index)	Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number	The unique internal identifier of the termination port

Resource Identifier	Type	Description
	Field type <Eqpt::PortId> - the port number	

Table 40.21-2 "Voice Sip Isdn/Cas Termination Configuration Commands" Command Parameters

Parameter	Type	Description
[no] directory-number	Parameter type: <Sip::TermDnumber> Format: - identify the DN of the subscriber line - length: x<=32	<i>optional parameter with default value: ""</i> Identify the directory (telephone) number of the subscriber line
[no] user-name	Parameter type: <Sip::TermUserName> Format: - identify the user name for this port - length: x<=64	<i>optional parameter with default value: ""</i> Identify the user name for this termination port
[no] display-name	Parameter type: <Sip::TermUserName> Format: - identify the user name for this port - length: x<=64	<i>optional parameter with default value: ""</i> Display name for this termination port
[no] uri	Parameter type: <Sip::TermUri> Format: - SIP uri by which the user agent identifies subscriber line - length: x<=80	<i>optional parameter with default value: ""</i> SIP URI by which user agent identifies subscriber line
[no] md5-realm	Parameter type: <Sip::MD5Realm> Format: - the realm identifier (Due to legacy reasons, the MD5 character string was included in the object name. Nevertheless, despite the MD5 string in the name of this object, from R5.8.x it is to be considered as a common configuration object for all authentication types that might require the configuration of an authentication realm identifier.) - length: x<=64	<i>optional parameter with default value: ""</i> Realm identifier corresponding to voice service gateway domain
[no] md5-password	Parameter type: <Security::Password4> Format: (prompt plain : <Security::PlainPassword4>) Possible values: - prompt : prompts the operator for a password - plain : the password in plain text, may contain any printable character defined by the US-ASCII character set and that has a decimal code in the range 33 to 126, and the length should be less than or equal to 64 (Due to legacy reasons, the MD5 character string was included in the parameter name. Nevertheless, despite the MD5 string in the name of this object, from R5.8.x it is to be considered as a common configuration object for all authentication types that might require the configuration of an authentication password.) Field type <Security::PlainPassword4> - the password, may contain any printable character defined by the US-ASCII character set and that has a decimal code in the range 33 to 126, and the length should be less than or equal to 64 (Due to legacy reasons, the MD5 character string was included in the parameter name. Nevertheless, despite the MD5 string in the name of this object, from R5.8.x it is to be considered as a common configuration object for all authentication types that might require the configuration of an authentication password.)	<i>optional parameter with default value: "plain : "</i> The password associated with the user

Parameter	Type	Description
[no] aka-secret-key	- length: x<=64 Parameter type: <Security::Password8> Format: (prompt plain : <Security::PlainPassword8>) Possible values: - prompt : prompts the operator for AKA shared secret key - plain : the AKA shared secret key in plain text, each character should be 0-f, and the length can only be 0 or 32 Field type <Security::PlainPassword8> - the AKA shared secret key, each character should be 0-f, and the length can only be 0 or 32 - length: x<=32	<i>optional parameter with default value: "plain : "</i> The AKA shared secret key
[no] admin-status	Parameter type: <Sip::IsdnTermAdminStatus> Format: (up down) Possible values: - up : unlock the sip isdn/cas termination - down : lock the sip isdn/cas termination	<i>optional parameter with default value: "down"</i> Identify the status of this port administration
[no] line-id	Parameter type: <Sip::ISDNTermLineId> Format: - Prior to ISR6.0.01: The Line ID of this PRA ISDN or R2 CAS SIP termination. It is contained in the Pani header. The line id configuration is not bounded to any format. It is the responsibility of the customer to define the desired line ID format. There is no restriction on the character set being used to configure the line ID/line ID format. From ISR6.0.01 onwards: The object allows the configuration, together or separately, for the pani header line id and/or the E1 interface CRC4 framing mode. In case the E1 interface CRC4 framing mode is not configured, the setting in the CDE profile applies. Otherwise (the E1 interface CRC4 framing mode is configured via this object), the input must be given via the following syntax: crc4:(enabled/disabled), 'crc4' is a fixed case-sensitive key-word immediately followed by a colon which in turn is immediately followed by the case-sensitive key-words 'enabled' or 'disabled'. 'enabled' means: Transmit and receive framing mode is set to CRC-multi frame. 'disabled' means: Transmit and receive framing mode is set to double frame. In case, it is required to configure both the CRC4 framing mode and the pani header line id, the CRC4 configuration input must be given prior to the pani header configuration input. In such case the syntax of the CRC4 configuration input is as described above, immediately followed by a semicolon and the semicolon immediately followed by the pani header line id in the same free format as described above: crc4:[enabled/disabled];[pani header line id]. - length: x<=63	<i>optional parameter with default value: ""</i> Identify the line id for this termination port
[no] testaccessstate	Parameter type: <Sip::TestAccessState> Format: (on off) Possible values: - on : turn on TestAccessState - off : turn off TestAccessState	<i>optional parameter with default value: "off"</i> Test access status

Parameter	Type	Description
[no] busyoverwrite	Parameter type: <Sip::TestAccessBusyOverWrite> Format: (true false) Possible values: - true : enable TestAccessBusyOverWrite parameter - false : disable TestAccessBusyOverWrite parameter	<i>optional parameter with default value: "false"</i> Test access busyoverwrite
[no] accessontimeout	Parameter type: <Sip::TestAccessonTimeout> Format: - value of test access on expires. - unit: second - range: [0...900]	<i>optional parameter with default value: "900"</i> Time to go until test access timeout. In case test access state is off, the value will be 0. In case test access state is on, this parameter is optional with default initial value 900. The value will start counting down, until value 0 and test access state will be off again
[no] provider-name	Parameter type: <Sip::TermUserProviderName> Format: - identify the user VSG name for this port - length: x<=32	<i>optional parameter with default value: "vsp1"</i> Identify the user VSG name for this termination port
[no] signalling-type	Parameter type: <Sip::TermSignallingType> Format: (isdn-pra cas-r2) Possible values: - isdn-pra : set signalling type to ISDN PRA - cas-r2 : set signalling type to CAS R2	<i>optional parameter with default value: "isdn-pra"</i> Identify the signalling type for this termination port. It can not be modified after term created.
[no] cpn-screen	Parameter type: <Sip::TermCallingScreen> Format: (disable enable) Possible values: - disable : disable calling party number screening - enable : enable calling party number screening	<i>optional parameter with default value: "enable"</i> Identify whether to support the screening of calling party number(CPN) for outgoing call of CAS R2 termination port. When enabled, the ISAMV shall request the calling party number from PBX and screen the CPN. When disabled, the ISAMV shall not request the calling party number and the default number assigned for the given termination shall be sent
[no] default-cpc	Parameter type: <Sip::TermDefaultCPC> Format: (passthrough ordinary specchg test payphone operator data payphoneiu atme) Possible values: - passthrough : bypass the cpc from PBX - ordinary : replace the cpc from PBX by ordinary	<i>optional parameter with default value: "passthrough"</i> Identify the default calling party's category for outgoing call of CAS R2 termination port. Value of passthrough means to bypass the cpc from PBX, other value means to replace the cpc from PBX by this value

Parameter	Type	Description
	- specchg : replace the cpc from PBX by specchg - test : replace the cpc from PBX by test - payphone : replace the cpc from PBX by payphone - operator : replace the cpc from PBX by operator - data : replace the cpc from PBX by data. data is not supported right now. - payphoneiu : replace the cpc from PBX by payphoneIU - atme : replace the cpc from PBX by atme	
[no] restrict-acc	Parameter type: <Sip::TermRestrictACC> Format: (disable enable) Possible values: - disable : no restriction for terminated ACC - enable : restriction for terminated ACC	<i>optional parameter with default value: "disable"</i> Identify whether the PBX is restricted for terminated automatic collect call for incoming call of CAS R2 termination port
[no] hunting-way	Parameter type: <Sip::TermHuntingWay> Format: (cyclic-forward sequential-forward sequential-reverse random-forward cyclic-reverse random-reverse) Possible values: - cyclic-forward : Initially the lowest B-channel is selected i.e. B-channel 1; afterwards, always again the next B-channel following the one used last is selected. - sequential-forward : The selection of the B-channel is based on an increasing port number, starting with the B-channel with the lowest port number of the E1/T1 interface and the next B-channel in the ordered series of B-channels is selected if the B-channel last used is busy. Again select the B-channel with the lowest port number. - sequential-reverse : The selection of the B-channel is based on an decreasing port number, starting with the B-channel with the highest port number of the E1/T1 interface and the next B-channel in the ordered series of B-channels is selected if the B-channel last used is busy. Again select the B-channel with the highest port number. - random-forward : allocation by random order. if the randomly selected B-channel is busy, the selection of a new candidate B-channel starts at the next in the ordered series of B-channels following the one been randomly selected, and follows increasing order. - cyclic-reverse : Initially the highest B-channel is selected i.e. B-channel 30; afterwards, always again the next B-channel following the one used last is selected. - random-reverse : allocation by random order. if the randomly selected B-channel is busy, the selection of a new candidate B-channel starts at the next in the ordered series of B-channels following the one been randomly selected, and follows decreasing order.	<i>optional parameter with default value: "cyclic-forward"</i> Identify the channel allocation method. For ISDN PRA, used for both outgoing and incoming calls. For CAS R2, only used for incoming call
[no] sip-rule-set	Parameter type: <Sip::IsdnCasManipulationRuleSet> Format: - the ISDN-PRA/CAS-R2 manipulation rule set, at most 4 rule ids can be configured for ISDN-PRA term and 3 rule ids for CAS-R2 term	<i>optional parameter with default value: ""</i> Identify the rules this termination can apply

Parameter	Type	Description
	- length: x<=4	
[no] cas-exch-type	Parameter type: <Sip::TermExchangeType> Format: (normal compelled-a3-and-b1 pulsed-a3-and-b1) Possible values: - normal : the exchange type is normal - compelled-a3-and-b1 : the exchange can only handle B-1 and compelled A3 when digit completed - pulsed-a3-and-b1 : the exchange can only handle B-1 and pulsed A3 when digit completed	<i>optional parameter with default value: "normal"</i> Only used for cas termination to identify the PBX type. It is only used for special legacy PBX in special nations and should be set to normal for normal PBX, otherwise it will break
[no] q-value	Parameter type: <Sip::IsdnCasTerminationQValue> Format: - The q value is a number specified as parameter in the Contact header field, denotes an order of preference - range: [0...100]	<i>optional parameter with default value: "100"</i> The q value is a number specified as parameter in the Contact header field, denotes an order of preference
[no] reg-mode	Parameter type: <Sip::IsdnCasTerminationRegMode> Format: (explicit implicit no-reg) Possible values: - explicit : The Explicit register (ER) mode is only relevant in case a list of individual DDI-EXTs has been manually configured and associated with this SIP termination - implicit : The Implicit register (IR) mode, the list of implicit registered DDI-EXTs is returned by the register server in the 200 OK response to the SIP register request - no-reg : The no-registration mode is only relevant in case the sip UA does not have to send any sip REGISTER / re-REGISTER request to the sipserver nor for the GDN, nor for the optional manually configured DDI-EXT.	<i>optional parameter with default value: "implicit"</i> The sipIsdnCasTerminationRegMode object allows to configure whether the implicit or explicit register mode applies
[no] e1-hunting-way	Parameter type: <Sip::IsdnCasTerminationE1HuntingWay> Format: (cyclic-forward sequential-forward-fl sequential-reverse-fl random-forward cyclic-reverse random-reverse sequential-forward-ud sequential-reverse-ud) Possible values: - cyclic-forward : The selection of the E1 interfaces is a cyclic process in which the different E1 interface are alternately selected. At the first selection attempt the first E1 in the configuration input will be selected and If no free channel on this interface the selection proceeds with the succeeding interface (i.e. in forward order) in the configuration order. For any subsequent selection attempt, the selection process will start at the interface which is succeeding the one in the configuration order that was selected last for the previous attempt (i.e. starting point proceeds in forward order). - sequential-forward-fl : Each time always start from the first	<i>optional parameter with default value: "cyclic-forward"</i> The selection of the E1 interface ways upon the receipt of an incoming call attempt (received from the IMS core side)

Parameter	Type	Description
	E1 in the configuration input, will select the next E1 in the order configured only when all B channels of current E1 are busy. - sequential-reverse-fl : Each time always start from the last E1 in the configuration input, will select the preceding E1 in the order configured only when all B channels of current E1 are busy. - random-forward : The selection of the E1 interfaces happens randomly. If selected E1 interface has no idle channel, then take the next E1 interface(forward) - cyclic-reverse : The selection of the E1 interfaces is a cyclic process in which the different E1 interface are alternately selected. At the first selection attempt the last E1 in the configuration input will be selected and If no free channel on this interface the selection proceeds with the preceding interface (i.e in reverse order) in the configuration order. For any subsequent selection attempt, the selection process will start at the interface which is preceding the one in the configuration order that was selected last for the previous attempt (i.e starting point proceeds in reverse order) - random-reverse : The selection of the E1 interfaces happens randomly. If selected E1 interface has no idle channel, then take the next E1 interface(reverse) - sequential-forward-ud : Aiming at having a equal load (more or less equal number of busy B-channels for each of the E1 interfaces in the E1 cluster. MIB readiness only. Unsupport now - sequential-reverse-ud : Aiming at having a equal load (more or less equal number of busy B-channels for each of the E1 interfaces in the E1 cluster. MIB readiness only. Unsupport now	
[no] e1-cluster-itf	Parameter type: <Sip::IsdnCasTerminationE1ClusterItf> Format: - The ifindex of interfaces. At maximum 8 ifIndexes can be configured. The ifindex used as index of the ISDN PRI/CAS R2 SIP termination must be configured in IsdnCasTerminationE1ClusterItf object. The order of the E1 interface ifindices in the configuration input for the sipIsdnCasTerminationE1ClusterItf object defines the priority of the E1 interface selection.	<i>optional parameter with default value: ""</i> A SIP termination is created on top of an E1 cluster that embraces multiple E1 interfaces
[no] e1-cluster-name	Parameter type: <Sip::IsdnCasTerminationE1ClusterName> Format: - Name of the E1 cluster - length: x<=32	<i>optional parameter with default value: ""</i> Name of the E1 cluster
[no] isdn-nsm-profile	Parameter type: <Sip::NsmProfile> Format: <pre>(none <Sip::NsmProfilePointer> name : <PrintableString>)</pre> Possible values: - none : no ISDN NSM profile assigned. - name : ISDN NSM profile name Field type <Sip::NsmProfilePointer> - the index of the ISDN NSM profile. - range: [1...32] Field type <PrintableString>	<i>optional parameter with default value: "none"</i> The nsm profile which should be associated with the ISDN PRA termination. For CAS R2 termination, it must be none.

Parameter	Type	Description
[no] cas-nsm-profile	- printable string Parameter type: <Sip::CasNsmProfPointer> Format: (none <Sip::CasNsmProfPointer> name : <PrintableString>) Possible values: - none : no CAS NSM profile assigned. - name : CAS NSM profile name Field type <Sip::CasNsmProfPointer> - the index of the CAS NSM profile. - range: [1...32] Field type <PrintableString> - printable string	<i>optional parameter with default value: "none"</i> The cas nsm profile which should be associated with the CAS R2 termination. For ISDN PRA termination, it must be none.

40.22 Voice Sip Isdn/Cas Termination Configuration Commands

Command Description

This command allows the operator to manage the Isdn Pri /Cas SIP termination created on top of an E1/T1 trunk (sub-)group.

User Level

The command can be accessed by operators with sip privileges, and executed by operators with sip privileges.

Command Syntax

The command has the following syntax:

```
> configure voice sip ( no pri-cas-tksg-term (if-index) tksg-id <Sip::TrunkSubGroupId> ) | ( pri-cas-tksg-term
(if-index) tksg-id <Sip::TrunkSubGroupId> [ no directory-number | directory-number <Sip::TermDnumber> ] [ no
user-name | user-name <Sip::TermUserName> ] [ no display-name | display-name <Sip::TermDisplayName> ] [ no
uri | uri <Sip::TermUri> ] [ no realm | realm <Sip::MD5Realm> ] [ no password | password <Security::Password4>
] [ no aka-secret-key | aka-secret-key <Security::Password8> ] [ no admin-status | admin-status
<Sip::IsdnTermAdminStatus> ] [ no line-id | line-id <Sip::PriTksgTermLineId> ] [ no provider-name |
provider-name <Sip::TermUserProviderName> ] [ no ds0-hunting-way | ds0-hunting-way
<Sip::TermHuntingWay> ] [ no itf-hunting-way | itf-hunting-way <Sip::IsdnCasTerminationItfHuntingWay> ] [ no
sip-rule-set | sip-rule-set <Sip::IsdnCasManipulationTksgRuleSet> ] [ no q-value | q-value
<Sip::IsdnCasTerminationQValue> ] [ no reg-mode | reg-mode <Sip::IsdnCasTerminationRegMode> ] [ no
extension | extension <Sip::SipPriCasTksgTermExtension> ] trunk-group-name
<Sip::SipPriCasTksgTermTrunkGroupName> [ no signalling-type | signalling-type
<Sip::TksgTermSignallingType> ] [ no cas-cpn-screen | cas-cpn-screen <Sip::TermCallingScreen> ] [ no
cas-default-cpc | cas-default-cpc <Sip::TermDefaultCPC> ] [ no cas-restrict-acc | cas-restrict-acc
<Sip::TermRestrictACC> ] [ no cas-exch-type | cas-exch-type <Sip::TermExchangeType> ] [ no isdn-nsm-profile |
isdn-nsm-profile <Sip::NsmProfile> ] [ no cas-nsm-profile | cas-nsm-profile <Sip::CasNsmProfPointer> ] [ no
uus-profile | uus-profile <Sip::UserToUserProfile> ] [ no cas-timer-profile | cas-timer-profile
<Sip::CasTimerProfPointer> ] )
```

Command Parameters

Table 40.22-1 "Voice Sip Isdn/Cas Termination Configuration Commands" Resource Parameters

Resource Identifier	Type	Description
(if-index)	Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId>	The ifindex of one of E1/T1 interfaces of the trunk (sub-)group on top of which the ISDN PRI / CAS SIP termination is created

Resource Identifier	Type	Description
	- the LT slot number Field type <Eqpt::PortId> - the port number	
tksg-id	Parameter type: <Sip::TrunkSubGroupId> Format: - The index of E1/T1 interface trunk sub-group. - range: [0...256]	The E1/T1 Trunk sub-group ID.

Table 40.22-2 "Voice Sip Isdn/Cas Termination Configuration Commands" Command Parameters

Parameter	Type	Description
[no] directory-number	Parameter type: <Sip::TermDnumber> Format: - identify the DN of the subscriber line - length: x<=32	<i>optional parameter with default value: ""</i> The global directory number (GDN)
[no] user-name	Parameter type: <Sip::TermUserName> Format: - identify the user name for this port - length: x<=64	<i>optional parameter with default value: ""</i> The user name for this ISDN PRI / CAS SIP termination
[no] display-name	Parameter type: <Sip::TermDisplayName> Format: - identify the display name for this port - length: x<=64	<i>optional parameter with default value: ""</i> The display name for this ISDN PRI / CAS SIP termination
[no] uri	Parameter type: <Sip::TermUri> Format: - SIP uri by which the user agent identifies subscriber line - length: x<=80	<i>optional parameter with default value: ""</i> The sip uri by which the SIP user agent identifies the SIP termination
[no] realm	Parameter type: <Sip::MD5Realm> Format: - the realm identifier (Due to legacy reasons, the MD5 character string was included in the object name. Nevertheless, despite the MD5 string in the name of this object, from R5.8.x it is to be considered as a common configuration object for all authentication types that might require the configuration of an authentication realm identifier.) - length: x<=64	<i>optional parameter with default value: ""</i> The Realm of the voice service gateway domain
[no] password	Parameter type: <Security::Password4> Format: (prompt plain : <Security::PlainPassword4>) Possible values: - prompt : prompts the operator for a password - plain : the password in plain text, may contain any printable character defined by the US-ASCII character set and that has a decimal code in the range 33 to 126, and the length should be less than or equal to 64 (Due to legacy reasons, the MD5 character string was included in the parameter name. Nevertheless, despite the MD5 string in the name of this object, from R5.8.x it is to be considered as a common configuration object for all authentication types that might require the configuration of an authentication password.) Field type <Security::PlainPassword4> - the password, may contain any printable character defined by the US-ASCII character set and that has a decimal code in the range 33 to 126, and the length should be less than or	<i>optional parameter with default value: "plain : "</i> The password of the ISDN PRI / CAS SIP termination

Parameter	Type	Description
	equal to 64 (Due to legacy reasons, the MD5 character string was included in the parameter name. Nevertheless, despite the MD5 string in the name of this object, from R5.8.x it is to be considered as a common configuration object for all authentication types that might require the configuration of an authentication password.) - length: x<=64	
[no] aka-secret-key	Parameter type: <Security::Password8> Format: (prompt plain : <Security::PlainPassword8>) Possible values: - prompt : prompts the operator for AKA shared secret key - plain : the AKA shared secret key in plain text, each character should be 0-f, and the length can only be 0 or 32 Field type <Security::PlainPassword8> - the AKA shared secret key, each character should be 0-f, and the length can only be 0 or 32 - length: x<=32	<i>optional parameter with default value: "plain : "</i> The AKA shared secret key of the ISDN PRI / CAS SIP termination
[no] admin-status	Parameter type: <Sip::IsdnTermAdminStatus> Format: (up down) Possible values: - up : unlock the sip isdn/cas termination - down : lock the sip isdn/cas termination	<i>optional parameter with default value: "down"</i> The administrative status of the ISDN PRI / CAS SIP termination.
[no] line-id	Parameter type: <Sip::PriTksgTermLineId> Format: - The line-id allows to configure the Fax Mode(fm) and/or the Voice Activity Detection(vad) and/or the processing procedure for the dtmf event tones(2833) and/or the Vbd-mode (vm) and/or the UDP port usage for T38 to voice switching (udp) and/or the Pani header line ID. Overall syntax: [fm:(value(1:3))];[vad:e vad:d];[2833:(value(1:4))];[vm:(value(1:4))];[udp:e udp:d];[(Pani header line-id value)] A semi-colon must be inserted between the configuration input strings. The configuration input must be given in lower case characters. No space allowed anywhere; no leading zero(es) allowed anywhere. In case the configuration input for one or multiple input strings must be changed, the configuration input for all other input strings must be repeated too i.e. the new configuration input for the line id parameter fully overwrites the previous configuration input. - Keyword : fm Values : range [1:3] 1 : g711vbd 2 : t.38-with-g711vbd-fallback-with-signaling 3 : t.38-with-g711vbd-fallback-without-signaling In case the keyword is not found in the configuration input of lind-id parameter, the system wide pre-provisioned value in the CDE profile file applies. - Keyword : vad Values : e d e : vad is enabled (sending comfort noise packets during silent periods) d : vad is disabled (do not send comfort noise packets during silent periods) In case the keyword is not found in the configuration input of the line-id parameter, the system wide pre-provisioned value in the CDE profile file applies. - Keyword : 2833 Values : range [1:4] 1 : the processing procedure is audio 2 : the processing	<i>optional parameter with default value: ""</i> The format of the line ID to be included in the PANI-HEADER.

Parameter	Type	Description
	procedure is rfc2833\n 3 : the processing procedure is both, audio and rfc2833\n 4 : audio has priority in the processing procedure\n In case the keyword is not found in the configuration input of the line-id parameter, the system wide configured value in the sipVspTable applies.\n - Keyword : vm\n Values : range [1:4]\n 1 : auto switch without negotiation\n 2 : renegotiation\n 3 : If V152 negotiation fails, autoswitch applies(not support now)\n 4 : If V152 negotiation fails, renegotiation applies(not support now)\n In case the keyword is not found in the configuration input of the line-id parameter, the system wide configured value in the sipVspTable applies.\n - Keyword : udp\n Values : e d\n e : the same UDP port is used for Voice and T38\n d : a different UDP port is used for Voice and T38\n In case the keyword is not found in the configuration input of the line-id parameter, the system wide configured value in the sipVspTable applies.\n - Pani header line id :\n Must always appear at the end of the configuration string.\n The configuration input is not bounded to any format i.e. It is the responsibility of the customer to define the desired line ID format; There is no restriction on the character set being used. - length: x<=63	
[no] provider-name	Parameter type: <Sip::TermUserProviderName> Format: - identify the user VSG name for this port - length: x<=32	<i>optional parameter with default value: "vsp1"</i> The name of the VSG the ISDN PRI /CAS SIP termination is associated with.
[no] ds0-hunting-way	Parameter type: <Sip::TermHuntingWay> Format: (cyclic-forward sequential-forward sequential-reverse random-forward cyclic-reverse random-reverse) Possible values: - cyclic-forward : Initially the lowest B-channel is selected i.e. B-channel 1; afterwards, always again the next B-channel following the one used last is selected. - sequential-forward : The selection of the B-channel is based on an increasing port number, starting with the B-channel with the lowest port number of the E1/T1 interface and the next B-channel in the ordered series of B-channel is selected if the B-channel last used is busy. Again select the B-channel with the lowest port number. - sequential-reverse : The selection of the B-channel is based on an decreasing port number, starting with the B-channel with the highest port number of the E1/T1 interface and the next B-channel in the ordered series of B-channels is selected if the B-channel last used is busy. Again select the B-channel with the highest port number. - random-forward : allocation by random order. if the randomly selected B-channel is busy, the selection of a new candidate B-channel starts at the next in the ordered series of B-channels following the one been randomly selected, and follows increasing order.	<i>optional parameter with default value: "cyclic-forward"</i> The channel selection method. For ISDN PRA, it applies both outgoing and incoming calls. For CAS, it applies to incoming calls only.

Parameter	Type	Description
	- cyclic-reverse : Initially the highest B-channel is selected i.e. B-channel 30; afterwards, always again the next B-channel following the one used last is selected. - random-reverse : allocation by random order. if the randomly selected B-channel is busy, the selection of a new candidate B-channel starts at the next in the ordered series of B-channels following the one been randomly selected, and follows decreasing order.	
[no] itf-hunting-way	Parameter type: <Sip::IsdnCasTerminationItfHuntingWay> Format: (cyclic-forward sequential-forward-fl sequential-reverse-fl random-forward cyclic-reverse random-reverse sequential-forward-ud sequential-reverse-ud) Possible values: - cyclic-forward : The selection of the E1/T1 interfaces is a cyclic process in which the different E1/T1 interface are alternately selected. At the first selection attempt the first E1/T1 in the configuration input will be selected and If no free channel on this interface the selection proceeds with the succeeding interface (i.e. in forward order) in the configuration order. For any subsequent selection attempt, the selection process will start at the interface which is succeeding the one in the configuration order that was selected last for the previous attempt (i.e. starting point proceeds in forward order) - sequential-forward-fl : Each time always start from the first E1/T1 in the configuration input, will select the next E1/T1 in the order configured only when all B channels of current E1/T1 are busy. - sequential-reverse-fl : Each time always start from the last E1/T1 in the configuration input, will select the preceding E1/T1 in the order configured only when all B channels of current E1/T1 are busy. - random-forward : The selection of the E1/T1 interfaces happens randomly. If selected E1/T1 interface has no idle channel, then take the next E1/T1 interface(forward) - cyclic-reverse : The selection of the E1/T1 interfaces is a cyclic process in which the different E1/T1 interface are alternately selected. At the first selection attempt the last E1/T1 in the configuration input will be selected and If no free channel on this interface the selection proceeds with the preceding interface (i.e in reverse order) in the configuration order. For any subsequent selection attempt, the selection process will start at the interface which is preceding the one in the configuration order that was selected last for the previous attempt (i.e starting point proceeds in reverse order) - random-reverse : The selection of the E1/T1 interfaces happens randomly. If selected E1/T1 interface has no idle channel, then take the next E1/T1 interface(reverse) - sequential-forward-ud : Aiming at having a equal load (more or less equal number of busy B-channels for each of	<i>optional parameter with default value: "cyclic-forward"</i> The E1/T1 interface selection method (for incoming call attempt)

Parameter	Type	Description
	the E1/T1 interfaces in the E1/T1 cluster. MIB readiness only. Unsupport now - sequential-reverse-ud : Aiming at having a equal load (more or less equal number of busy B-channels for each of the E1/T1 interfaces in the E1/T1 cluster. MIB readiness only. Unsupport now	
[no] sip-rule-set	Parameter type: <Sip::IsdnCasManipulationTksgRuleSet> Format: - the ISDN-PRA/CAS-R2 manipulation rule set, at most 32 rule ids can be configured for ISDN-PRA term and CAS-R2 term - length: x<=32	<i>optional parameter with default value: ""</i> The SIP termination specific rule set that applies to this ISDN PRI / CAS SIP termination.
[no] q-value	Parameter type: <Sip::IsdnCasTerminationQValue> Format: - The q value is a number specified as parameter in the Contact header field, denotes an order of preference - range: [0...100]	<i>optional parameter with default value: "100"</i> The q value for in case SIP Forking applies
[no] reg-mode	Parameter type: <Sip::IsdnCasTerminationRegMode> Format: (explicit implicit no-reg) Possible values: - explicit : The Explicit register (ER) mode is only relevant in case a list of individual DDI-EXTs has been manually configured and associated with this SIP termination - implicit : The Implicit register (IR) mode, the list of implicit registered DDI-EXTs is returned by the register server in the 200 OK response to the SIP register request - no-reg : The no-registration mode is only relevant in case the sip UA does not have to send any sip REGISTER / re-REGISTER request to the sipserver nor for the GDN, nor for the optional manually configured DDI-EXT.	<i>optional parameter with default value: "implicit"</i> The register mode : implicit registration, explicit registration, no-registration
[no] extension	Parameter type: <Sip::SipPriCasTksgTermExtension> Format: - The ifindex of interfaces. At maximum 32 ifIndexes can be configured. The ifindex used as index of the ISDN PRI/CAS SIP termination must be configured in SipPriCasTksgExtension object. The order of the E1/T1 interface ifindices in the configuration input for the SipPriCasTksgExtension object defines the priority of the E1/T1 interface selection.	<i>optional parameter with default value: ""</i> The list of E1/T1 interfaces that composes the Trunk (sub-)group.
trunk-group-name	Parameter type: <Sip::SipPriCasTksgTermTrunkGroupName> Format: - Name of the E1/T1 Trunk Group - length: x<=32	<i>mandatory parameter</i> The name of the E1/T1 Trunk Group
[no] signalling-type	Parameter type: <Sip::TksgTermSignallingType> Format: (isdn-pra cas-2bit-mfc-gr-fw-bw cas-2bit-dtmf cas-1bit-dtmf cas-1bit-mfc-gr-fw-bw cas-1bit-decadic cas-1bit-mfc-fw) Possible values:	<i>optional parameter with default value: "isdn-pra"</i> The signaling type for this SIP termination.

Parameter	Type	Description
	- isdn-pra : Q931/Q921 protocol based communication between the CPE side and the NIAT-A board - cas-2bit-mfc-gr-fw-bw : 2 bit line signaling and MFC register signaling in compliance with ITU-T Q.400-490 CAS R2 specification (supporting groups, forward and backward signals) - cas-2bit-dtmf : 2 bit line signaling and DTMF register signaling - cas-1bit-dtmf : 1 bit line signaling and DTMF register signaling - cas-1bit-mfc-gr-fw-bw : 1 bit line signaling and MFC register signaling (supporting groups, forward and backward signals). This ENUM value is actually NOT supported. - cas-1bit-decadic : 1 bit line signaling and DECADIC register signaling. This ENUM value is actually NOT supported. - cas-1bit-mfc-fw : 1 bit line signaling and MFC register signaling in compliance with ITU-T Q.310-Q322 CAS R1 specification (supporting only forward signals). This ENUM value is actually NOT supported.	
[no] cas-cpn-screen	Parameter type: <Sip::TermCallingScreen> Format: (disable enable) Possible values: - disable : disable calling party number screening - enable : enable calling party number screening	<i>optional parameter with default value: "enable"</i> To enable / disable the screening of the calling party number for calls originating at the CPE side. It applies to the CAS SIP termination only.
[no] cas-default-cpc	Parameter type: <Sip::TermDefaultCPC> Format: (passthrough ordinary specchg test payphone operator data payphoneiu atme) Possible values: - passthrough : bypass the cpc from PBX - ordinary : replace the cpc from PBX by ordinary - specchg : replace the cpc from PBX by specchg - test : replace the cpc from PBX by test - payphone : replace the cpc from PBX by payphone - operator : replace the cpc from PBX by operator - data : replace the cpc from PBX by data. data is not supported right now. - payphoneiu : replace the cpc from PBX by payphoneIU - atme : replace the cpc from PBX by atme	<i>optional parameter with default value: "passthrough"</i> The calling party's category for this SIP termination. In case a CAS SIP termination is expected to request the calling party number and category from the CPE, the received calling party's category shall be replaced by the configured category. It applies to the CAS SIP termination only.
[no] cas-restrict-acc	Parameter type: <Sip::TermRestrictACC> Format: (disable enable) Possible values: - disable : no restriction for terminated ACC - enable : restriction for terminated ACC	<i>optional parameter with default value: "disable"</i> To enable/disable whether the CPE is restricted for terminated Automatic Collect Call. It applies to the CAS SIP termination only.
[no] cas-exch-type	Parameter type: <Sip::TermExchangeType>	<i>optional parameter with default</i>

Parameter	Type	Description
	Format: (normal compelled-a3-and-b1 pulsed-a3-and-b1) Possible values: - normal : the exchange type is normal - compelled-a3-and-b1 : the exchange can only handle B-1 and compelled A3 when digit completed - pulsed-a3-and-b1 : the exchange can only handle B-1 and pulsed A3 when digit completed	<i>value: "normal"</i> To configure the exchange type : - the CPE supports all, the group A and the group B signals - compelled-a3-and-b1 - the CPE supports only the B-1 signal. Any other B-x signal sent to the CPE is ignored. - pulsed-a3-and-b1 - the CPE supports only the B-1 signal. A pulsed A-3 signal is sent to the CPE after DML analysis has completed and a B-1 signal is sent to the CPE after a SIP INVITE has been sent to the SIP server. It applies to the CAS SIP termination only.
[no] isdn-nsm-profile	Parameter type: <Sip::NsmProfile> Format: (none <Sip::NsmProfilePointer> name : <PrintableString>) Possible values: - none : no ISDN NSM profile assigned. - name : ISDN NSM profile name Field type <Sip::NsmProfilePointer> - the index of the ISDN NSM profile. - range: [1...32] Field type <PrintableString> - printable string	<i>optional parameter with default value: "none"</i> The nsm profile assigned to the ISDN PRI SIP termination.
[no] cas-nsm-profile	Parameter type: <Sip::CasNsmProfPointer> Format: (none <Sip::CasNsmProfPointer> name : <PrintableString>) Possible values: - none : no CAS NSM profile assigned. - name : CAS NSM profile name Field type <Sip::CasNsmProfPointer> - the index of the CAS NSM profile. - range: [1...32] Field type <PrintableString> - printable string	<i>optional parameter with default value: "none"</i> The cas nsm profile assigned to the CAS SIP termination.
[no] uus-profile	Parameter type: <Sip::UserToUserProfile> Format: (none <Sip::UserToUserProfilePointer> name : <PrintableString>) Possible values: - none : no ISDN user-to-user profile assigned. - name : ISDN user-to-user profile name Field type <Sip::UserToUserProfilePointer> - the index of the user-to-user profile. - range: [1...32] Field type <PrintableString> - printable string	<i>optional parameter with default value: "none"</i> The user-to-user service profile assigned to the ISDN PRI SIP termination.
[no] cas-timer-profile	Parameter type: <Sip::CasTimerProfPointer> Format:	<i>optional parameter with default value: "none"</i>

40 Voice Configuration Commands

Parameter	Type	Description
	(none <Sip::CasTimerProfPointer> name : <PrintableString>) Possible values: - none : no CAS timer profile assigned. - name : CAS timer profile name Field type <Sip::CasTimerProfPointer> - the index of the CAS timer profile. - range: [1...32] Field type <PrintableString> - printable string	The cas timer profile assigned to the CAS SIP termination.

40.23 Voice Sip Manipulation Rule Configuration Commands

Command Description

This command allows the operator to manage the Voice Sip manipulation rule profile.

User Level

The command can be accessed by operators with sip privileges, and executed by operators with sip privileges.

Command Syntax

The command has the following syntax:

```
> configure voice sip ( no manipulate-rule (rule-id) ) | ( manipulate-rule (rule-id) [ no admin-status | admin-status
<Sip::RuleAdminStatus> ] [ no rule-name | rule-name <Sip::RuleName> ] rule <Sip::ManipulateRule> [ no
rule-type | rule-type <Sip::ManipulateRuleType> ] )
```

Command Parameters

Table 40.23-1 "Voice Sip Manipulation Rule Configuration Commands" Resource Parameters

Resource Identifier	Type	Description
(rule-id)	Format: - the index of one manipulation rule - range: [1...255]	uniquely identify of this sip manipulation rule

Table 40.23-2 "Voice Sip Manipulation Rule Configuration Commands" Command Parameters

Parameter	Type	Description
[no] admin-status	Parameter type: <Sip::RuleAdminStatus> Format: (enabled disabled) Possible values: - enabled : the rule can be executed - disabled : the rule can't be executed	<i>optional parameter with default value: "disabled"</i> administrative status of this sip manipulation rule
[no] rule-name	Parameter type: <Sip::RuleName> Format: - The operator friendly name of the rule - length: x<=32	<i>optional parameter with default value: ""</i> The operator friendly name of the rule
rule	Parameter type: <Sip::ManipulateRule> Format: - The supported rule key phrases are listed below. Only 1 rule key phrase can be configured per rule.\n-[ISDN]outg-use-default-pbx-number:[value]\n-[ISDN]inc-add-phone-context-to-number\n-[ISDN]outg-add-country-area-code-in-phone-context:[countrycode]-[areacode]\n-	<i>mandatory parameter</i> The manipulation rule

Parameter	Type	Description
	[ISDN/CAS]inc-short-number-len:[shortnumberlength]\n- [ISDN]outg-add-domain-name-in-phone-context\n- [POTS]out-dialedprefix-outprefix:[dialedprefix]-[outprefix]\n- [POTS/ISDN/CAS]outg-call-duration-limitation:[Prefix(es)]-[MaxCallDuration]-[MaxToneDurationTimer]\n- [POTS/ISDN/CAS]inc-call-duration-limitation:[MaxCallDuration]-[MaxToneDurationTimer]\n- [POTS/ISDN]emergency-mode\n- [POTS/ISDN]priority-user\n- [CAS]outg-add-country-area-code-in-cpn:[countrycode]-[areacode]\n- [CAS]inc-del-local-country-code-in-cpn:[countrycode]\n- For further details about the value ranges and meaning of the different values, please have a look at the description of the sipRuleTable in the SIP-MIB. - length: 1<=x<=64	
[no] rule-type	Parameter type: <Sip::ManipulateRuleType> Format: (pots isdn-pra pots-all isdn-pra-all cas-r2 cas-r2-all) Possible values: - pots : this rule is applied to POTS term - isdn-pra : this rule is applied to ISDN PRA term - pots-all : this rule is applied to all POTS terms - isdn-pra-all : this rule is applied to all ISDN PRA terms - cas-r2 : this rule is applied to CAS term - cas-r2-all : this rule is applied to all CAS terms	<i>optional parameter with default value: "isdn-pra"</i> The manipulation rule type

40.24 Voice Sip Cas R2 Timer Configuration Commands

Command Description

This command allows the operator to manage the Voice Sip Cas R2 timer profile.

User Level

The command can be accessed by operators with sip privileges, and executed by operators with sip privileges.

Command Syntax

The command has the following syntax:

```
> configure voice sip cas-r2-timer (if-index) [ no seizure-ack | seizure-ack <Sip::CasR2TimerSeizureAck> ] [ no
disconnect-ack | disconnect-ack <Sip::CasR2TimerDisconnectAck> ] [ no force-rel-ack | force-rel-ack
<Sip::CasR2TimerForceReleaseAck> ] [ no pres-fwd-sig | pres-fwd-sig <Sip::CasR2TimerPreFwdSig> ] [ no
recept-fwd-sig | recept-fwd-sig <Sip::CasR2TimerRecpFwdSig> ] [ no re-answer | re-answer
<Sip::CasR2TimerReanswer> ] [ no call-process | call-process <Sip::CasR2TimerCallProcess> ]
```

Command Parameters

Table 40.24-1 "Voice Sip Cas R2 Timer Configuration Commands" Resource Parameters

Resource Identifier	Type	Description
(if-index)	Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number	The unique internal identifier of the termination port

Table 40.24-2 "Voice Sip Cas R2 Timer Configuration Commands" Command Parameters

Parameter	Type	Description
[no] seizure-ack	Parameter type: <Sip::CasR2TimerSeizureAck> Format: - Timer for the reception of the SEIZURE ACK Signal to the TDM R2 side. - unit: millisecond - range: [100...1000]	<i>optional parameter with default value: "200"</i> Timer for the reception of the SEIZURE ACK Signal to the TDM R2 side
[no] disconnect-ack	Parameter type: <Sip::CasR2TimerDisconnectAck> Format:	<i>optional parameter with default value: "90"</i>

40 Voice Configuration Commands

Parameter	Type	Description
	- Timer for the reception of the DISCONNECTION ACK Signal to the TDM R2 side. - unit: second - range: [1...360]	Timer for the reception of the DISCONNECTION ACK Signal to the TDM R2 side.
[no] force-rel-ack	Parameter type: <Sip::CasR2TimerForceReleaseAck> Format: - Timer for the reception of the FORCED RELEASE ACK / CLEAR BACK ACK Signal to the TDM R2 side. - unit: second - range: [1...360]	<i>optional parameter with default value: "90"</i> Timer for the reception of the FORCED RELEASE ACK / CLEAR BACK ACK Signal to the TDM R2 side.
[no] pres-fwd-sig	Parameter type: <Sip::CasR2TimerPreFwdSig> Format: - Timer that defines the interval for the presence of the FORWARDING Signal to the TDM R2 side. - unit: second - range: [1...36]	<i>optional parameter with default value: "15"</i> Timer that defines the interval for the presence of the FORWARDING Signal to the TDM R2 side.
[no] recept-fwd-sig	Parameter type: <Sip::CasR2TimerRecpFwdSig> Format: - Timer that defines the interval for the reception of the FORWARDING Signal to the TDM R2 side. - unit: second - range: [1...20]	<i>optional parameter with default value: "7"</i> Timer that defines the interval for the reception of the FORWARDING Signal to the TDM R2 side.
[no] re-answer	Parameter type: <Sip::CasR2TimerReanswer> Format: - The re-answer timer on terminated calls to the TDM R2 side. A value '0' configured for the re-answer timer means that the re-answer timer shall not be started. - unit: second - range: [0...360]	<i>optional parameter with default value: "90"</i> The re-answer timer on terminated calls to the TDM R2 side.
[no] call-process	Parameter type: <Sip::CasR2TimerCallProcess> Format: - Timer that defines the interval between digit collection completed and called party answering the call request. The timer is started for incoming call requests to the TDM R2 side. A value '0' configured for the call-process timer means that the call-process timer shall not be started. - unit: second - range: [0...360]	<i>optional parameter with default value: "0"</i> Timer that defines the interval between digit collection completed and called party answering the call request. The timer is started for incoming call requests to the TDM R2 side. A value '0' configured for the call-process timer means that the call-process timer shall not be started.

40.25 Voice Sip PUID Configuration Commands

Command Description

This command allows the operator to manage the PUID term.

User Level

The command can be accessed by operators with sip privileges, and executed by operators with sip privileges.

Command Syntax

The command has the following syntax:

```
> configure voice sip ( no isdn-cas-cls-puid (name) directory-number <Sip::TermDnumber> ) | ( isdn-cas-cls-puid
(name) directory-number <Sip::TermDnumber> [ no user-name | user-name <Sip::TermUserName> ] [ no uri | uri
<Sip::TermUri> ] [ no md5-password | md5-password <Security::Password4> ] [ no aka-secret-key | aka-secret-key
<Security::Password8> ] [ no display-name | display-name <Sip::TermUserName> ] )
```

Command Parameters

Table 40.25-1 "Voice Sip PUID Configuration Commands" Resource Parameters

Resource Identifier	Type	Description
(name)	Format: - Name of the E1 cluster - length: x<=32	Name of E1 or T1 cluster
directory-number	Parameter type: <Sip::TermDnumber> Format: - identify the DN of the subscriber line - length: x<=32	The directory number of this PUID

Table 40.25-2 "Voice Sip PUID Configuration Commands" Command Parameters

Parameter	Type	Description
[no] user-name	Parameter type: <Sip::TermUserName> Format: - identify the user name for this port - length: x<=64	<i>optional parameter with default value: ""</i> Identify the user name for this PUID
[no] uri	Parameter type: <Sip::TermUri> Format: - SIP uri by which the user agent identifies subscriber line - length: x<=80	<i>optional parameter with default value: ""</i> SIP URI by which user agent identifies PUID
[no] md5-password	Parameter type: <Security::Password4> Format: (prompt plain : <Security::PlainPassword4>) Possible values: - prompt : prompts the operator for a password - plain : the password in plain text, may contain any printable character defined by the US-ASCII character set	<i>optional parameter with default value: "plain : "</i> The password associated with the user

Parameter	Type	Description
	and that has a decimal code in the range 33 to 126, and the length should be less than or equal to 64 (Due to legacy reasons, the MD5 character string was included in the parameter name. Nevertheless, despite the MD5 string in the name of this object, from R5.8.x it is to be considered as a common configuration object for all authentication types that might require the configuration of an authentication password.) Field type <Security::PlainPassword4> - the password, may contain any printable character defined by the US-ASCII character set and that has a decimal code in the range 33 to 126, and the length should be less than or equal to 64 (Due to legacy reasons, the MD5 character string was included in the parameter name. Nevertheless, despite the MD5 string in the name of this object, from R5.8.x it is to be considered as a common configuration object for all authentication types that might require the configuration of an authentication password.) - length: x<=64	
[no] aka-secret-key	Parameter type: <Security::Password8> Format: <pre>(prompt plain : <Security::PlainPassword8>)</pre> Possible values: - prompt : prompts the operator for AKA shared secret key - plain : the AKA shared secret key in plain text, each character should be 0-f, and the length can only be 0 or 32 Field type <Security::PlainPassword8> - the AKA shared secret key, each character should be 0-f, and the length can only be 0 or 32 - length: x<=32	<i>optional parameter with default value: "plain : "</i> The AKA shared secret key
[no] display-name	Parameter type: <Sip::TermUserName> Format: - identify the user name for this port - length: x<=64	<i>optional parameter with default value: ""</i> Display name for this PUID

40.26 Voice Sip PUID Configuration Commands

Command Description

This command allows the operator to manage the DDI-EXTs of the ISDN PRI / CAS SIP termination

User Level

The command can be accessed by operators with sip privileges, and executed by operators with sip privileges.

Command Syntax

The command has the following syntax:

```
> configure voice sip ( no pri-cas-tksg-puid (if-index) tksg-id <Sip::TrunkSubGroupId> directory-number
<Sip::TermDnumber> ) | ( pri-cas-tksg-puid (if-index) tksg-id <Sip::TrunkSubGroupId> directory-number
<Sip::TermDnumber> [ no user-name | user-name <Sip::TermUserName> ] [ no uri | uri <Sip::TermUri> ] [ no
password | password <Security::Password4> ] [ no aka-secret-key | aka-secret-key <Security::Password8> ] [ no
display-name | display-name <Sip::TermUserName> ] )
```

Command Parameters

Table 40.26-1 "Voice Sip PUID Configuration Commands" Resource Parameters

Resource Identifier	Type	Description
(if-index)	Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number	The ifindex of the related ISDN PRI / CAS SIP termination
tksg-id	Parameter type: <Sip::TrunkSubGroupId> Format: - The index of E1/T1 interface trunk sub-group. - range: [0...256]	The E1/T1 Trunk sub-group ID
directory-number	Parameter type: <Sip::TermDnumber> Format: - identify the DN of the subscriber line - length: x<=32	The directory number of the DDI-EXT

Table 40.26-2 "Voice Sip PUID Configuration Commands" Command Parameters

Parameter	Type	Description
[no] user-name	Parameter type: <Sip::TermUserName> Format: - identify the user name for this port	<i>optional parameter with default value: ""</i> The user name of the DDI-EXT

Parameter	Type	Description
	- length: x<=64	
[no] uri	Parameter type: <Sip::TermUri> Format: - SIP uri by which the user agent identifies subscriber line - length: x<=80	<i>optional parameter with default value: ""</i> The SIP URI by which the SIP user agent identifies the DDI-EXT
[no] password	Parameter type: <Security::Password4> Format: (prompt plain : <Security::PlainPassword4>) Possible values: - prompt : prompts the operator for a password - plain : the password in plain text, may contain any printable character defined by the US-ASCII character set and that has a decimal code in the range 33 to 126, and the length should be less than or equal to 64 (Due to legacy reasons, the MD5 character string was included in the parameter name. Nevertheless, despite the MD5 string in the name of this object, from R5.8.x it is to be considered as a common configuration object for all authentication types that might require the configuration of an authentication password.) Field type <Security::PlainPassword4> - the password, may contain any printable character defined by the US-ASCII character set and that has a decimal code in the range 33 to 126, and the length should be less than or equal to 64 (Due to legacy reasons, the MD5 character string was included in the parameter name. Nevertheless, despite the MD5 string in the name of this object, from R5.8.x it is to be considered as a common configuration object for all authentication types that might require the configuration of an authentication password.) - length: x<=64	<i>optional parameter with default value: "plain : "</i> The password of the DDI-EXT
[no] aka-secret-key	Parameter type: <Security::Password8> Format: (prompt plain : <Security::PlainPassword8>) Possible values: - prompt : prompts the operator for AKA shared secret key - plain : the AKA shared secret key in plain text, each character should be 0-f, and the length can only be 0 or 32 Field type <Security::PlainPassword8> - the AKA shared secret key, each character should be 0-f, and the length can only be 0 or 32 - length: x<=32	<i>optional parameter with default value: "plain : "</i> The AKA shared secret key of the DDI-EXT
[no] display-name	Parameter type: <Sip::TermUserName> Format: - identify the user name for this port - length: x<=64	<i>optional parameter with default value: ""</i> Display name of this DDI-EXT

40.27 Voice Sip Isdn Nsm Profile Configuration Commands

Command Description

This command allows the operator to manage the Voice Sip Isdn nsm Profile profile.

User Level

The command can be accessed by operators with sip privileges, and executed by operators with sip privileges.

Command Syntax

The command has the following syntax:

```
> configure voice sip ( no isdn-nsm-prof (prof-name) ) | ( isdn-nsm-prof (prof-name) [ no version-nbr | version-nbr
<Sip::NsmProfileVersionNbr> ] [ no outg-from-no-cgpn | outg-from-no-cgpn <Sip::NsmOutFromNoCgpn> ] [ no
outg-privacy | outg-privacy <Sip::NsmOutPricy> ] [ no outg-from-pi | outg-from-pi <Sip::NsmOutFromPi> ] [ no
inc-from-noclip | inc-from-noclip <Sip::NsmIncFromNoClip> ] [ no inc-from-clip-pri | inc-from-clip-pri
<Sip::NsmIncFromClipPri> ] [ no inc-from-clip-ua | inc-from-clip-ua <Sip::NsmIncFromClipUa> ] [ no
inc-npi-to-cpn | inc-npi-to-cpn <Sip::NsmIncNpiToCpn> ] [ no inc-ton-to-cpn | inc-ton-to-cpn
<Sip::NsmIncTonToCpn> ] international-prefix <Sip::NsmProfInPrefix> [ no national-prefix | national-prefix
<Sip::NsmProfNPrefix> ] country-code <Sip::NsmProfCC> outg-cpn-length <Sip::NsmOutCpnLength> [ no
inc-cgpn-add-ac | inc-cgpn-add-ac <Sip::NsmIncCgpnAddAC> ] [ no inc-ton-to-cdpn | inc-ton-to-cdpn
<Sip::NsmIncTonToCdPn> ] )
```

Command Parameters

Table 40.27-1 "Voice Sip Isdn Nsm Profile Configuration Commands" Resource Parameters

Resource Identifier	Type	Description
(prof-name)	Format: - the name of a nsm profile - length: x<=32	The unique name identifier of an row in the sipIsdnNsmProfileTable.

Table 40.27-2 "Voice Sip Isdn Nsm Profile Configuration Commands" Command Parameters

Parameter	Type	Description
[no] version-nbr	Parameter type: <Sip::NsmProfileVersionNbr> Format: - a version number of the profile - range: [1...65535]	<i>optional parameter with default value: 1</i> The version number to the profile.
[no] outg-from-no-cgpn	Parameter type: <Sip::NsmOutFromNoCgpn> Format: (impu-gdn unavailable) Possible values: - impu-gdn : The From header is to be sent with the default group number for outgoing call	<i>optional parameter with default value: "impu-gdn"</i> This object allows indicating whether the From-header user part of an outgoing SIP Invite request needs to be set to 'Unavailable' or to include the

Parameter	Type	Description
	- unavailable : The From header is to be sent as unavailable@unknown.invalid for outgoing call	default group number
[no] outg-privacy	Parameter type: <Sip::NsmOutPricy> Format: (privacy-id-hdr-usr privacy-none) Possible values: - privacy-id-hdr-usr : Privacy header included with value id, header, user - privacy-none : Privacy header included with value none	<i>optional parameter with default value: "privacy-id-hdr-usr"</i> this object allows to indicate whether a privacy header field with value 'id, header, user' or a privacy header with value 'none' is to be included when CgPN IE received with NPI other than 'ISDN/telephony numbering plan' or 'unknown' or CgPN IE received with NPI is 'ISDN/telephony numbering plan' or 'unknown' and PI=absent.
[no] outg-from-pi	Parameter type: <Sip::NsmOutFromPi> Format: (anonymous not-anonymous) Possible values: - anonymous : the From header shall be set to: From: Anonymous sip:anonymous@anonymous.invalid - not-anonymous : the setting of the sipIsdnNsmProfileOutFromNoInvNbr object applies.	<i>optional parameter with default value: "not-anonymous"</i> This object allows to indicate whether the 'From' header is to be anonymized or not, when PI = Presentation restricted is received.
[no] inc-from-noclip	Parameter type: <Sip::NsmIncFromNoClip> Format: - the string value that IMS will send in the 'From' header user info in case the user does not have the CLIP feature assigned - length: x<=32	<i>optional parameter with default value: "unsubscribed"</i> This object allows to configure the string value the IMS will send in the 'From' header user info in case the terminating user does not have the CLIP feature assigned.
[no] inc-from-clip-pri	Parameter type: <Sip::NsmIncFromClipPri> Format: - the string value that IMS will send in the 'From' header user info in case the CLI has to be kept private - length: x<=32	<i>optional parameter with default value: "anonymous"</i> This object allows to configure the string value the IMS will send in the 'From' header user info in case the CLI has to be kept private.
[no] inc-from-clip-ua	Parameter type: <Sip::NsmIncFromClipUa> Format: - the string value that IMS will send in the 'From' header user info in case there's no CLI that can be passed to the MSAN - length: x<=32	<i>optional parameter with default value: "unavailable"</i> This object allows to configure the string value the IMS will send in the 'From' header user info in case no CLI is available.
[no] inc-npi-to-cpn	Parameter type: <Sip::NsmIncNpiToCpn> Format: (itu-t-e164 unknown) Possible values: - itu-t-e164 : the NPI is set to ISDN/telephony numbering plan (ITU-T Recommendation E.164) for incoming call - unknown : the NPI is set to unknown for incoming call	<i>optional parameter with default value: "unknown"</i> This object allows to configure how the numbering plan identifier field must be coded towards the terminating ISDN PRI user.
[no] inc-ton-to-cpn	Parameter type: <Sip::NsmIncTonToCpn> Format: (international unknown) Possible values:	<i>optional parameter with default value: "unknown"</i> This object allows to configure the preferred value of the TON (Type Of Number) parameter of

Parameter	Type	Description
	- international : the TON is set to international for incoming call - unknown : the TON is set to unknown for incoming call	CgPN IE that is sent to the terminating ISDN PRI user.
international-prefix	Parameter type: <Sip::NsmProfInPrefix> Format: - the string value of the international prefix - length: 1<=x<=8	<i>mandatory parameter</i> The international prefix. Mandatory parameter
[no] national-prefix	Parameter type: <Sip::NsmProfNPrefix> Format: - the string value of the national prefix - length: x<=4	<i>optional parameter with default value: ""</i> The national prefix.
country-code	Parameter type: <Sip::NsmProfCC> Format: - the string value of the country code - length: 1<=x<=8	<i>mandatory parameter</i> The country code. Mandatory parameter
outg-cpn-length	Parameter type: <Sip::NsmOutCpnLength> Format: - The length of digits - range: [0...15]	<i>mandatory parameter</i> The number of digits that allows the MSAN to distinguish whether the phone number received in the CgPN is a shortened phone number (a DDI extension) or a phone number with a national or international format. Mandatory parameter.
[no] inc-cgpn-add-ac	Parameter type: <Sip::NsmIncCgpnAddAC> Format: (disable enable) Possible values: - disable : Do not add area code to CgPN when intra-area call received - enable : Add area code to CgPN when intra-area call received	<i>optional parameter with default value: "disable"</i> This object allows to configure whether to add national prefix and area code to CgPN IE when receive an intra-area call.
[no] inc-ton-to-cdpn	Parameter type: <Sip::NsmIncTonToCdPn> Format: (unknown international national) Possible values: - unknown : the TON of CdPN is set to unknown for incoming call - international : the TON of CdPN is set to international for incoming call - national : the TON of CdPN is set to national for incoming call	<i>optional parameter with default value: "unknown"</i> This object allows to configure the value of the TON (Type Of Number) parameter of CdPN IE that is sent to the terminating ISDN PRI user.

40.28 Voice Sip Cas Nsm Profile Configuration Commands

Command Description

This command allows the operator to manage the Voice Sip Cas nsm Profile profile.

User Level

The command can be accessed by operators with sip privileges, and executed by operators with sip privileges.

Command Syntax

The command has the following syntax:

```
> configure voice sip ( no cas-nsm-prof (prof-name) ) | ( cas-nsm-prof (prof-name) [ no version-nbr | version-nbr
<Sip::CasNsmProfVersionNbr> ] [ no outg-from-no-cgpn | outg-from-no-cgpn
<Sip::CasNsmProfOutFromNoInvNbr> ] international-prefix <Sip::CasNsmProfInPrefix> [ no national-prefix |
national-prefix <Sip::CasNsmProfInPrefix> ] country-code <Sip::CasNsmProfCC> outg-cpn-length
<Sip::CasNsmProfCgPnNbrLength> )
```

Command Parameters

Table 40.28-1 "Voice Sip Cas Nsm Profile Configuration Commands" Resource Parameters

Resource Identifier	Type	Description
(prof-name)	Format: - the name of a nsm profile - length: 1<=x<=32	The unique name identifier of an row in the sipCasNsmProfileTable.

Table 40.28-2 "Voice Sip Cas Nsm Profile Configuration Commands" Command Parameters

Parameter	Type	Description
[no] version-nbr	Parameter type: <Sip::CasNsmProfVersionNbr> Format: - a version number of the profile - range: [1...65535]	<i>optional parameter with default value: 1</i> The version number to the profile.
[no] outg-from-no-cgpn	Parameter type: <Sip::CasNsmProfOutFromNoInvNbr> Format: (impu-gdn unavailable) Possible values: - impu-gdn : The From header is to be sent with the default group number for outgoing call - unavailable : The From header is to be sent as unavailable@unknown.invalid for outgoing call	<i>optional parameter with default value: "impu-gdn"</i> This object allows indicating whether the From-header user part of an outgoing SIP Invite request needs to be set to 'Unavailable' or to include the default group number
international-prefix	Parameter type: <Sip::CasNsmProfInPrefix> Format: - the string value of the international prefix	<i>mandatory parameter</i> The international prefix. Mandatory parameter

Parameter	Type	Description
	- length: 1<=x<=8	
[no] national-prefix	Parameter type: <Sip::CasNsmProfNPrefix> Format: - the string value of the national prefix - length: x<=4	<i>optional parameter with default value: ""</i> The national prefix.
country-code	Parameter type: <Sip::CasNsmProfCC> Format: - the string value of the country code - length: 1<=x<=8	<i>mandatory parameter</i> The country code. Mandatory parameter
outg-cpn-length	Parameter type: <Sip::CasNsmProfCgPnNbrLength> Format: - the length of digits - range: [0...15]	<i>mandatory parameter</i> The number of digits that allows the MSAN to distinguish whether the phone number received in the CgPN is a shortened phone number (a DDI extension) or a phone number with a national or international format. Mandatory parameter.

40.29 Voice Sip Pri User To User Profile Configuration Commands

Command Description

This command allows the operator to manage the Voice Sip Pri User To User Profile.

User Level

The command can be accessed by operators with sip privileges, and executed by operators with sip privileges.

Command Syntax

The command has the following syntax:

```
> configure voice sip ( no user-to-user-prof (prof-name) ) | ( user-to-user-prof (prof-name) [ no version-nbr |
version-nbr <Sip::UserToUserProfVersionNbr> ] [ no service-type | service-type
<Sip::UserToUserProfServiceType> ] [ no act-estab-call | act-estab-call
<Sip::UserToUserProfActivateEstablishCall> ] [ no act-stable-call | act-stable-call
<Sip::UserToUserProfActivateStableCall> ] [ no uus3-t1-timer | uus3-t1-timer
<Sip::UserToUserProfUUS3T1Timer> ] )
```

Command Parameters

Table 40.29-1 "Voice Sip Pri User To User Profile Configuration Commands" Resource Parameters

Resource Identifier	Type	Description
(prof-name)	Format: - The unique name identifier of a row in the sipPriUserToUserProfileTable - length: 1<=x<=32	The unique name identifier of a row in the sipPriUserToUserProfileTable.

Table 40.29-2 "Voice Sip Pri User To User Profile Configuration Commands" Command Parameters

Parameter	Type	Description
[no] version-nbr	Parameter type: <Sip::UserToUserProfVersionNbr> Format: - The version number of the pri user to user profile - range: [1...65535]	<i>optional parameter with default value: 1</i> The version number of the profile.
[no] service-type	Parameter type: <Sip::UserToUserProfServiceType> Format: uus3 Possible values: - uus3 : User-to-user information exchanged while a call is in the Active state	<i>optional parameter with default value: "uus3"</i> This object allows the operator to configure the UUS service type (UUS service 1, UUS service 2, UUS service 3). Only uus3 is supported.
[no] act-estab-call	Parameter type: <Sip::UserToUserProfActivateEstablishCall>	<i>optional parameter with default value: "false"</i>

Parameter	Type	Description
	Format: (true false) Possible values: - true : the UUS service will be active during call establishment - false : the UUS service will not be active during call establishment	If this object is set as true(1), the UUS service will be active during call establishment; the SETUP message shall contain an independent UUS service request. The value true(1) can only be set when the act-stable-call is set to false(2).
[no] act-stable-call	Parameter type: <Sip::UserToUserProfActivateStableCall> Format: (true false) Possible values: - true : the UUS service will be active during the active state of a call - false : the UUS service will not be active during the active state of a call	<i>optional parameter with default value: "false"</i> If this object is set as true(1), the UUS service will be active during the active state of a call; a FACILITY message indicating the UUS service request will be sent out for UUS service activation. The value true(1) can only be set when the act-estab-call is set to false(2).
[no] uus3-t1-timer	Parameter type: <Sip::UserToUserProfUUS3T1Timer> Format: - Value of UUS3-T1 timer - unit: second - range: [1...60]	<i>optional parameter with default value: 10</i> This object allows the operator to configure the UUS3-T1 timer. The timer is started when a FACILITY message indicating a User-To-user service 3 request is sent out and will be stopped when a response FACILITY message is received.

40.30 Voice Sip Isdn/Cas trunk sub-group Configuration Commands

Command Description

This command allows the operator to manage the E1/T1 trunk sub-group.

User Level

The command can be accessed by operators with sip privileges, and executed by operators with sip privileges.

Command Syntax

The command has the following syntax:

```
> configure voice sip ( no tksg (if-index) tksg-id <Sip::TksgId> interface <Itf::IsdnLine> ) | ( tksg (if-index) tksg-id
<Sip::TksgId> interface <Itf::IsdnLine> tksg-name <Sip::TksgName> ds0-bitmap <Sip::Ds0BitSet> [ no
admin-status | admin-status <Sip::IsdnTermAdminStatus> ] [ no ds0-hunting-way | ds0-hunting-way
<Sip::Ds0HuntingWay> ] )
```

Command Parameters

Table 40.30-1 "Voice Sip Isdn/Cas trunk sub-group Configuration Commands" Resource Parameters

Resource Identifier	Type	Description
(if-index)	Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number	The ifIndex of the ISDN PRI / CAS SIP termination that has been created on top of the E1/T1 trunk sub-group.
tksg-id	Parameter type: <Sip::TksgId> Format: - The index of trunk sub-group - range: [1...256]	The unique Identifier of the trunk sub-group (chosen by the operator in the range [1..256]).
interface	Parameter type: <Itf::IsdnLine> Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId>	The Ifindex of the E1/T1 interface at which the trunk sub-group is created.

Resource Identifier	Type	Description
	- the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number	

Table 40.30-2 "Voice Sip Isdn/Cas trunk sub-group Configuration Commands" Command Parameters

Parameter	Type	Description
tksg-name	Parameter type: <Sip::TksgName> Format: - The operator friendly name of the trunk sub-group. - length: 1<=x<=32	<i>mandatory parameter</i> The operator friendly name of the trunk sub-group.
ds0-bitmap	Parameter type: <Sip::Ds0BitSet> Format: - The bitmap indicating the DS0 channels that belong to the trunk sub-group.	<i>mandatory parameter</i> The bitmap indicating the DS0 channels that belong to the trunk sub-group.
[no] admin-status	Parameter type: <Sip::IsdnTermAdminStatus> Format: (up down) Possible values: - up : unlock the sip isdn/cas termination - down : lock the sip isdn/cas termination	<i>optional parameter with default value: "down"</i> The administrative status of the trunk sub-group.
[no] ds0-hunting-way	Parameter type: <Sip::Ds0HuntingWay> Format: (cyclic-forward sequential-forward sequential-reverse random-forward cyclic-reverse random-reverse inherit) Possible values: - cyclic-forward : DS0 channels are allocated cyclically. The preference is for the allocation of the subsequent idle channel in a cyclical manner. Initially the lowest DS0 channel is selected. i.e. DS0-channel 1; afterwards, always again the next DS0-channel following the one used last is selected. - sequential-forward : DS0 channels are allocated increasingly. The preference is for the allocation of the idle channel with the lowest number. - sequential-reverse : DS0 channels are allocated decreasingly. The preference is for the allocation of the idle channel with the highest number. - random-forward : DS0 channels are allocated randomly. The preference is for the allocation of the idle channel with the random number. If selected channel is busy, then Take the next free B-channel (forward) - cyclic-reverse : DS0 channels are allocated cyclically. Initially the highest DS0-channel is selected i.e. DS0-channel 30; afterwards, always again the preceding B-channel of the one used last is selected. - random-reverse : DS0 channels are allocated randomly. The preference is for the allocation of the idle channel with the random number. If selected channel is busy, then Take the	<i>optional parameter with default value: "inherit"</i> The hunting method for the DS0 channels of the trunk sub-group.

40 Voice Configuration Commands

Parameter	Type	Description
	next free B-channel (reverse) - inherit : DS0 channels are allocated as configured in the corresponding ISDN PRI/CAS R2 SIP termination entry in the sipPriCasTksgTerminationDs0HuntingWay object of the sipPriCasTksgTerminationTable.	

40.31 Voice Sip Physical Interface Configuration Commands

Command Description

This command allows the operator to manage the Voice Sip physical interface profile.

User Level

The command can be accessed by operators with sip privileges, and executed by operators with sip privileges.

Command Syntax

The command has the following syntax:

```
> configure voice sip ( no phys-itf (if-index) ) | ( phys-itf (if-index) [ no admin-status | admin-status
<Sip::PhysItfAdminStatus> ] [ no interface-type | interface-type <Sip::PhysItfType> ] [ no signalling-type |
signalling-type <Sip::PhysItfSignalingType> ] [ no e1-crc4frame | e1-crc4frame <Sip::PhysItfE1Crc4Framing> ] [
no t1-framemode | t1-framemode <Sip::PhysItfT1FrameMode> ] [ no t1-tx-linecode | t1-tx-linecode
<Sip::PhysItfT1LineCode> ] [ no t1-rx-linecode | t1-rx-linecode <Sip::PhysItfT1LineCode> ] [ no t1-lbo-value |
t1-lbo-value <Sip::PhysItfT1LBOValue> ] [ no blocking-bitmap | blocking-bitmap <Sip::PhysItfBlockingBitmap>
] [ no cap-name | cap-name <Sip::PhysItfCapName> ] [ no cas-sig-prof | cas-sig-prof <Sip::CasSignalProfPointer>
])
```

Command Parameters

Table 40.31-1 "Voice Sip Physical Interface Configuration Commands" Resource Parameters

Resource Identifier	Type	Description
(if-index)	Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number	The unique internal identifier of the physical E1/T1 interface

Table 40.31-2 "Voice Sip Physical Interface Configuration Commands" Command Parameters

Parameter	Type	Description
[no] admin-status	Parameter type: <Sip::PhysItfAdminStatus> Format: (up down testing)	<i>optional parameter with default value: "down"</i> The administrative status of the physical E1/T1 interface.

Parameter	Type	Description
	Possible values: - up : unlock the E1/T1 physical interface - down : lock the E1/T1 physical interface - testing : the operator is going to run or is running loop-back testing on this interface	
[no] interface-type	Parameter type: <Sip::PhysItfType> Format: (e1-itf-type t1-itf-type) Possible values: - e1-itf-type : E1 interface with 30 B channels. - t1-itf-type : T1 interface with 23 B channels.	<i>optional parameter with default value: "e1-itf-type"</i> The type of physical interface
[no] signalling-type	Parameter type: <Sip::PhysItfSignalingType> Format: (isdn-pra cas-2bit-mfc-gr-fw-bw cas-2bit-dtmf cas-1bit-dtmf cas-1bit-mfc-gr-fw-bw cas-1bit-decadic cas-1bit-mfc-fw) Possible values: - isdn-pra : Q931/Q921 protocol based communication between the CPE side and the NIAT-A board - cas-2bit-mfc-gr-fw-bw : 2 bit line signaling and MFC register signaling in compliance with ITU-T Q.400-490 CAS R2 specification (supporting groups, forward and backward signals) - cas-2bit-dtmf : 2 bit line signaling and DTMF register signaling - cas-1bit-dtmf : 1 bit line signaling and DTMF register signaling - cas-1bit-mfc-gr-fw-bw : 1 bit line signaling and MFC register signaling (supporting groups, forward and backward signals). This ENUM value is actually NOT supported. - cas-1bit-decadic : 1 bit line signaling and DECADIC register signaling. This ENUM value is actually NOT supported. - cas-1bit-mfc-fw : 1 bit line signaling and MFC register signaling in compliance with ITU-T Q.310-Q322 CAS R1 specification (supporting only forward signals). This ENUM value is actually NOT supported.	<i>optional parameter with default value: "isdn-pra"</i> The signaling type between the end-user (PBX) side and the NIAT-A board
[no] e1-crc4frame	Parameter type: <Sip::PhysItfE1Crc4Framing> Format: (cde-profile enabled disabled) Possible values: - cde-profile : default value defined in CDE. - enabled : CRC4 multiframe. - disabled : double frame.	<i>optional parameter with default value: "cde-profile"</i> The E1 interface CRC4 framing mode
[no] t1-framemode	Parameter type: <Sip::PhysItfT1FrameMode> Format: (cde-value f4 f12 f24	<i>optional parameter with default value: "cde-value"</i> The Frame Mode of the T1 interface

Parameter	Type	Description
	f72) Possible values: - cde-value : default value defined in CDE. - f4 : 4-frame multiframe. - f12 : 12-frame multiframe (D4). - f24 : 24-frame Superframe (ESF). - f72 : 72-frame multiframe (SLC96).	
[no] t1-tx-linecode	Parameter type: <Sip::PhysItfT1LineCode> Format: (cde-value ami ami-with-zcs b8zs) Possible values: - cde-value : default value defined in CDE. - ami : Alternate Mark Inversion. - ami-with-zcs : Alternate Mark Inversion with Zero-Code Suppression. - b8zs : Bipolar with 8-zero Substitution.	<i>optional parameter with default value: "cde-value"</i> The Tx line code of the T1 interface
[no] t1-rx-linecode	Parameter type: <Sip::PhysItfT1LineCode> Format: (cde-value ami ami-with-zcs b8zs) Possible values: - cde-value : default value defined in CDE. - ami : Alternate Mark Inversion. - ami-with-zcs : Alternate Mark Inversion with Zero-Code Suppression. - b8zs : Bipolar with 8-zero Substitution.	<i>optional parameter with default value: "cde-value"</i> The Rx line code of the T1 interface
[no] t1-lbo-value	Parameter type: <Sip::PhysItfT1LBOValue> Format: (lbo-0db lbo-7-5db lbo-15db) Possible values: - lbo-0db : LBO = 0dB, the resulting range of CI attenuation shall be 0 to 5.5 dB. - lbo-7-5db : LBO = 7.5dB, the resulting range of CI attenuation shall be 7.5 to 13.0 dB. - lbo-15db : LBO = 15dB, the resulting range of CI attenuation shall be 15 to 20.5 dB.	<i>optional parameter with default value: "lbo-0db"</i> The line build-out of the interface
[no] blocking-bitmap	Parameter type: <Sip::PhysItfBlockingBitmap> Format: - The bitmap indicating the TS channels that belong to the physical interface.	<i>optional parameter with default value: ""</i> The blocking/unblocking of a physical interface or TS channel (range)
[no] cap-name	Parameter type: <Sip::PhysItfCapName> Format: - The name of the Central Access Point that manages the E1/T1 interface - length: x<=31	<i>optional parameter with default value: ""</i> The name of the CAP
[no] cas-sig-prof	Parameter type: <Sip::CasSignalProfPointer> Format: (none <Sip::CasSignalProfPointer>	<i>optional parameter with default value: "none"</i> The cas timer profile assigned to the CAS SIP termination.

40 Voice Configuration Commands

Parameter	Type	Description
	name : <PrintableString>) Possible values: - none : no CAS signaling profile assigned. - name : CAS signaling profile name Field type <Sip::CasSignalProfPointer> - the index of the CAS signaling profile. - range: [1...32] Field type <PrintableString> - printable string	

40.32 Voice Sip Cas Signaling Profile Configuration Commands

Command Description

This command allows the operator to manage the Voice Sip Cas Signaling Profile.

User Level

The command can be accessed by operators with sip privileges, and executed by operators with sip privileges.

Command Syntax

The command has the following syntax:

```
> configure voice sip ( no cas-sig-prof (prof-name) ) | ( cas-sig-prof (prof-name) [ no version-nbr | version-nbr
<Sip::CasSignalProfVersionNbr> ] [ no idle | idle <Sip::CasSignalProfIdle> ] [ no seize | seize
<Sip::CasSignalProfSeize> ] [ no seize-ack | seize-ack <Sip::CasSignalProfSeizeAck> ] [ no answer | answer
<Sip::CasSignalProfAnswer> ] [ no fw-disconnect | fw-disconnect <Sip::CasSignalProfForwardDisconnect> ] [ no
fw-disconnect-ack | fw-disconnect-ack <Sip::CasSignalProfForwardDisconnectAck> ] [ no bw-disconnect |
bw-disconnect <Sip::CasSignalProfBackwardDisconnect> ] [ no bw-disconnect-ack | bw-disconnect-ack
<Sip::CasSignalProfBackwardDisconnectAck> ] [ no fault | fault <Sip::CasSignalProfFault> ] [ no block | block
<Sip::CasSignalProfBlock> ] [ no meter | meter <Sip::CasSignalProfMeter> ] [ no reject-call | reject-call
<Sip::CasSignalProfRejectCall> ] [ no bw-disc-reanswer | bw-disc-reanswer
<Sip::CasSignalProfBackwardDisconnectWithReAnswer> ] )
```

Command Parameters

Table 40.32-1 "Voice Sip Cas Signaling Profile Configuration Commands" Resource Parameters

Resource Identifier	Type	Description
(prof-name)	Format: - name of the signaling profile - length: 1<=x<=32	The unique name identifier of an row in the sipCasSignalingProfileTable.

Table 40.32-2 "Voice Sip Cas Signaling Profile Configuration Commands" Command Parameters

Parameter	Type	Description
[no] version-nbr	Parameter type: <Sip::CasSignalProfVersionNbr> Format: - version number of the signaling profile - range: [1...65535]	<i>optional parameter with default value: 1</i> The version number to the profile.
[no] idle	Parameter type: <Sip::CasSignalProfIdle> Format: - four signal bits(A/B/C/D) for line signal IDLE of CAS R2 or CAS R1 - range: [0...15]	<i>optional parameter with default value: "9"</i> Four signaling bits(A/B/C/D) for line signal IDLE of CAS R2 or CAS R1.
[no] seize	Parameter type: <Sip::CasSignalProfSeize> Format:	<i>optional parameter with default value: "1"</i>

40 Voice Configuration Commands

Parameter	Type	Description
	- four signal bits(A/B/C/D) for line signal Seize of CAS R2 or CAS R1 - range: [0...15]	Four signaling bits(A/B/C/D) for line signal Seizure of CAS R2 or CAS R1.
[no] seize-ack	Parameter type: <Sip::CasSignalProfSeizeAck> Format: - four signal bits(A/B/C/D) for line signal Seize Ack of CAS R2 or CAS R1 - range: [0...15]	<i>optional parameter with default value: "13"</i> Four signaling bits(A/B/C/D) for line signal Seizure Ack of CAS R2 or CAS R1.
[no] answer	Parameter type: <Sip::CasSignalProfAnswer> Format: - four signal bits(A/B/C/D) for line signal Answer of CAS R2 or CAS R1 - range: [0...15]	<i>optional parameter with default value: "5"</i> Four signaling bits(A/B/C/D) for line signal Answer of CAS R2 or CAS R1.
[no] fw-disconnect	Parameter type: <Sip::CasSignalProfForwardDisconnect> Format: - four signal bits(A/B/C/D) for line signal Forward disconnect of CAS R2 or CAS R1 - range: [0...15]	<i>optional parameter with default value: "9"</i> Four signaling bits(A/B/C/D) for line signal Forward disconnect of CAS R2 or CAS R1.
[no] fw-disconnect-ack	Parameter type: <Sip::CasSignalProfForwardDisconnectAck> Format: - four signal bits(A/B/C/D) for line signal Forward disconnect Ack of CAS R2 or CAS R1 - range: [0...15]	<i>optional parameter with default value: "9"</i> Four signaling bits(A/B/C/D) for line signal Forward disconnect Ack of CAS R2 or CAS R1.
[no] bw-disconnect	Parameter type: <Sip::CasSignalProfBackwardDisconnect> Format: - four signal bits(A/B/C/D) for line signal Backward disconnect of CAS R2 or CAS R1 - range: [0...15]	<i>optional parameter with default value: "1"</i> Four signaling bits(A/B/C/D) for line signal Backward disconnect of CAS R2 or CAS R1.
[no] bw-disconnect-ack	Parameter type: <Sip::CasSignalProfBackwardDisconnectAck> Format: - four signal bits(A/B/C/D) for line signal Backward disconnect Ack of CAS R2 or CAS R1 - range: [0...15]	<i>optional parameter with default value: "9"</i> Four signaling bits(A/B/C/D) for line signal Backward disconnect Ack of CAS R2 or CAS R1.
[no] fault	Parameter type: <Sip::CasSignalProfFault> Format: - four signal bits(A/B/C/D) for line signal Fault of CAS R2 or CAS R1 - range: [0...15]	<i>optional parameter with default value: "13"</i> Four signaling bits(A/B/C/D) for line signal Fault of CAS R2 or CAS R1.
[no] block	Parameter type: <Sip::CasSignalProfBlock> Format: - four signal bits(A/B/C/D) for line signal Block of CAS R2 or CAS R1 - range: [0...15]	<i>optional parameter with default value: "13"</i> Four signaling bits(A/B/C/D) for line signal Block of CAS R2 or CAS R1.
[no] meter	Parameter type: <Sip::CasSignalProfMeter> Format: - four signal bits(A/B/C/D) for line signal Meter of CAS R2 or CAS R1 - range: [0...15]	<i>optional parameter with default value: "13"</i> Four signaling bits(A/B/C/D) for line signal Meter of CAS R2 or CAS R1.
[no] reject-call	Parameter type: <Sip::CasSignalProfRejectCall> Format: - four signal bits(A/B/C/D) for line signal Reject Call of CAS R2 or CAS R1 - range: [0...15]	<i>optional parameter with default value: "1"</i> Four signaling bits(A/B/C/D) for line signal Reject call of CAS R2 or CAS R1.
[no] bw-disc-reanswer	Parameter type: <Sip::CasSignalProfBackwardDisconnectWithReAnswer>	<i>optional parameter with default value: "13"</i>

Parameter	Type	Description
	Format: - four signal bits(A/B/C/D) for line signal backward_disconnect with_reanswer of CAS R2 or CAS R1 - range: [0...15]	Four signaling bits(A/B/C/D) for line signal backward_disconnect with_reanswer of CAS R2 or CAS R1.

40.33 Central Access Point Table Configuration Commands

Command Description

This command allows the operator to configure Central Access Point Table.

User Level

The command can be accessed by operators with sip privileges, and executed by operators with sip privileges.

Command Syntax

The command has the following syntax:

```
> configure voice sip ( no cap (cap) ) | ( cap (cap) [ no cap-name | cap-name <Sip::CapName> ] [ no ne-name |
ne-name <Sip::NeName> ] [ no mode | mode <Sip::CapMode> ] [ no location | location <Sip::CapLocation> ] [ no
admin-status | admin-status <Sip::CapAdminStatus> ] [ no ip | ip <SIP::IpAddressAndMask> ] [ no udp-port |
udp-port <Sip::CapUDPPort> ] [ no gateway-ip | gateway-ip <Sip::CapGatewayIpAddr> ] [ no provider-name |
provider-name <Sip::CapProviderName> ] )
```

Command Parameters

Table 40.33-1 "Central Access Point Table Configuration Commands" Resource Parameters

Resource Identifier	Type	Description
(cap)	Format: - the central access point id - range: [1...16]	The unique identifier of this central access point

Table 40.33-2 "Central Access Point Table Configuration Commands" Command Parameters

Parameter	Type	Description
[no] cap-name	Parameter type: <Sip::CapName> Format: - The name of the Central Access Point - length: x<=32	<i>optional parameter with default value: ""</i> The operator friendly name of this central access point
[no] ne-name	Parameter type: <Sip::NeName> Format: - the name of the network element - length: x<=32	<i>optional parameter with default value: ""</i> The operator friendly name of NE that hosts the central access point
[no] mode	Parameter type: <Sip::CapMode> Format: (enabled disabled) Possible values: - enabled : cap mode enable for the ISDN PRI/CAS VoIP service	<i>optional parameter with default value: "disabled"</i> allows to configure whether the central access point mode is enabled or disabled

Parameter	Type	Description
	- disabled : cap mode disable for the ISDN PRI/CAS VoIP service	
[no] location	Parameter type: <Sip::CapLocation> Format: (local remote) Possible values: - local : the value is set to local in cap ne - remote : the value is set to remote in remote ne	<i>optional parameter with default value: "local"</i> allows to configure whether the central access point is hosted in the local NE or hosted
[no] admin-status	Parameter type: <Sip::CapAdminStatus> Format: (up down) Possible values: - up : the cap mode as configured becomes effective - down : the cap mode becomes not effective when cap mode enabled;non cap mode run in ISAMV NE when cap mode disabled	<i>optional parameter with default value: "down"</i> administrative status of this central access point
[no] ip	Parameter type: <SIP::IpAddressAndMask> Format: <Ip::V4Address> / <Sip::PrefixLength> Field type <Ip::V4Address> - IPv4-address Field type <Sip::PrefixLength> - prefix length of the subnet - range: [0...128]	<i>optional parameter with default value: "0.0.0.0/0"</i> the IPv4 address and prefix length of the Central Access Point
[no] udp-port	Parameter type: <Sip::CapUDPPort> Format: - The UDP port by which the cap can be addressed at the NVPS-C - range: [49152...65534]	<i>optional parameter with default value: "49152"</i> the UDP port by which the Central Access Point can be addressed via the proprietary communication protocol
[no] gateway-ip	Parameter type: <Sip::CapGatewayIpAddr> Format: - IPv4-address	<i>optional parameter with default value: "0.0.0.0"</i> the Gateway IP address that allows the CAP to send internal communication packets to the remote NE
[no] provider-name	Parameter type: <Sip::CapProviderName> Format: - provider name - length: x<=32	<i>optional parameter with default value: "common"</i> The operator friendly name of the Voice Service Provider

40.34 Central Access Point Table Configuration Commands

Command Description

This command allows the operator to configure Central Access Point Table.

User Level

The command can be accessed by operators with sip privileges, and executed by operators with sip privileges.

Command Syntax

The command has the following syntax:

```
> configure voice sip ( no ne-board cap-id <Sip::CapId> ne-id <Sip::NeId> board <Equipm::LtSlotIndex> ) | (
ne-board cap-id <Sip::CapId> ne-id <Sip::NeId> board <Equipm::LtSlotIndex> [ no admin-status | admin-status
<Sip::NeBoardAdminStatus> ] xhub-port <Sip::xHubPort> )
```

Command Parameters

Table 40.34-1 "Central Access Point Table Configuration Commands" Resource Parameters

Resource Identifier	Type	Description
cap-id	Parameter type: <Sip::CapId> Format: - the central access point id - range: [1...16]	The unique identifier of this central access point
ne-id	Parameter type: <Sip::NeId> Format: - the network element id - range: [1...8]	The unique identifier of the Network element.
board	Parameter type: <Equipm::LtSlotIndex> Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId>) Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number	The slot identifier of the NIAT-A LT board.

Table 40.34-2 "Central Access Point Table Configuration Commands" Command Parameters

Parameter	Type	Description
[no] admin-status	Parameter type: <Sip::NeBoardAdminStatus> Format: (up	<i>optional parameter with default value: "down"</i> administrative status of this

Parameter	Type	Description
	down) Possible values: - up : the NIAT-A LT board has been planned and has been physically pulled in - down : the NIAT-A LT board has not been planned yet or the NIAT-A LT board has been planned but is not physical plugged in.	NIAT-A LT board.
xhub-port	Parameter type: <Sip::xHubPort> Format: - The xHUB port to which the NIAT-A LT board is connected. - range: [1...32]	<i>mandatory parameter</i> The xHUB port to which the NIAT-A LT board is connected

40.35 Voice Sip Cas Timer Profile Configuration Commands

Command Description

This command allows the operator to manage the Voice Sip Cas Timer Profile profile.

User Level

The command can be accessed by operators with sip privileges, and executed by operators with sip privileges.

Command Syntax

The command has the following syntax:

```
> configure voice sip ( no cas-timer-prof (prof-name) ) | ( cas-timer-prof (prof-name) [ no version-nbr | version-nbr
<Sip::CasTimerProfVersionNbr> ] appl-bitmap <Sip::CasTimerProfAppliBitmap> [ no seize-ack | seize-ack
<Sip::CasTimerProfSeizeAck> ] [ no clear-back-ack | clear-back-ack <Sip::CasTimerProfClearBwAck> ] [ no
clear-fw-ack | clear-fw-ack <Sip::CasTimerProfClearFwAck> ] [ no presence-fw-sig | presence-fw-sig
<Sip::CasTimerProfPresenceFwSig> ] [ no receipt-fw-sig | receipt-fw-sig <Sip::CasTimerProfReceiptFwSig> ] [
no re-answer | re-answer <Sip::CasTimerProfReAnswer> ] [ no call-process | call-process
<Sip::CasTimerProfCallProcess> ] [ no delay-dial-min | delay-dial-min <Sip::CasTimerProfDelayDialingMinDur>
] [ no delay-dial-max | delay-dial-max <Sip::CasTimerProfDelayDialingMaxDur> ] [ no seize-state-time |
seize-state-time <Sip::CasTimerProfSeizeStateTime> ] [ no reg-recall-min | reg-recall-min
<Sip::CasTimerProfRegRecallMinDur> ] [ no reg-recall-max | reg-recall-max
<Sip::CasTimerProfRegRecallMaxDur> ] [ no decadic-pulse-dur | decadic-pulse-dur <Sip::CasTimerProfDpDur> ]
[ no decadic-break-dur | decadic-break-dur <Sip::CasTimerProfDpBreakDur> ] [ no inter-digit-peri | inter-digit-peri
<Sip::CasTimerProfInterDigitPeriod> ] [ no ring-fw | ring-fw <Sip::CasTimerProfRingForward> ] [ no
receipt-nbr-rcvd | receipt-nbr-rcvd <Sip::CasTimerProfReceipNbrRecv> ] [ no meter-pulse-dur | meter-pulse-dur
<Sip::CasTimerProfMeterPulseDur> ] )
```

Command Parameters

Table 40.35-1 "Voice Sip Cas Timer Profile Configuration Commands" Resource Parameters

Resource Identifier	Type	Description
(prof-name)	Format: - the name of a timer profile - length: 1<=x<=32	The unique name identifier of an row in the sipCasTimerProfileTable.

Table 40.35-2 "Voice Sip Cas Timer Profile Configuration Commands" Command Parameters

Parameter	Type	Description
[no] version-nbr	Parameter type: <Sip::CasTimerProfVersionNbr> Format: - a version number of the profile - range: [1...65535]	<i>optional parameter with default value: 1</i> The version number to the profile.
appl-bitmap	Parameter type: <Sip::CasTimerProfAppliBitmap> Format:	<i>mandatory parameter</i> A bitmap that allows to indicate

Parameter	Type	Description
	(cas-2bit-dtmf cas-1bit-dtmf cas-1bit-decade cas-1bit-mfc-fw cas-1bit-mfc-gr-fw-bw cas-2bit-mfc-gr-fw-bw) Possible values: - cas-2bit-dtmf : Indicate the timer objects of sipCasTimerProfileSeizeAck, sipCasTimerProfileClearBackAck, sipCasTimerProfileClearForwardAck, sipCasTimerProfileCallProcess, sipCasTimerProfileSeizureStateTime - cas-1bit-dtmf : Indicate the timer objects of sipCasTimerProfileClearBackAck, sipCasTimerProfileClearForwardAck, sipCasTimerProfileCallProcess, sipCasTimerProfileDelayDialingMinDuration, sipcasTimerProfileDelayDialingMaxDuration, sipCasTimerProfileSeizureStateTime - cas-1bit-decade : Indicate the timer objects of sipCasTimerProfileClearBackAck, sipCasTimerProfileClearForwardAck, sipCasTimerProfileCallProcess, sipCasTimerProfileDelayDialingMinDuration, sipCasTimerProfileDelayDialingMaxDuration, sipCasTimerProfileSeizureStateTime, sipCasTimerProfileDecadicAFPulseDuration, sipCasTimerProfileDecadicAFBreakDuration, sipCasTimerProfileDpInterdigitPeriod - cas-1bit-mfc-fw : Indicate the timer objects of sipCasTimerProfileClearBackAck, sipCasTimerProfileClearForwardAck, sipCasTimerProfileCallProcess, sipCasTimerProfileDelayDialingMinDuration, sipcasTimerProfileDelayDialingMaxDuration, sipCasTimerProfileRingForward - cas-1bit-mfc-gr-fw-bw : Indicate the timer objects of sipCasTimerProfileClearBackAck, sipCasTimerProfileClearForwardAck, sipCasTimerProfilePresenceForwardSig, sipCasTimerProfileReceiptForwardSig, sipCasTimerProfileCallProcess, sipCasTimerProfileSeizureStateTime, sipCasTimerProfileRegisterRecallMinDuration, sipCasTimerProfileRegisterRecallMaxDuration, sipCasTimerProfileReceiptNumberReceived - cas-2bit-mfc-gr-fw-bw : Indicate the timer objects of sipCasTimerProfileSeizeAck, sipCasTimerProfileClearBackAck, sipCasTimerProfileClearForwardAck, sipCasTimerProfilePresenceForwardSig, sipCasTimerProfileReceiptForwardSig, sipCasTimerProfileReanswer, sipCasTimerProfileCallProcess, sipCasTimerProfileRegisterRecallMinDuration, sipCasTimerProfileRegisterRecallMaxDuration,	the timer objects that are applicable to the profile.

40 Voice Configuration Commands

Parameter	Type	Description
	sipCasTimerProfileMeteringPulseDuration	
[no] seize-ack	Parameter type: <Sip::CasTimerProfSeizeAck> Format: - Timer for the receipt of the SEIZURE ACK Signal. - unit: millisecond - range: [100...1000]	<i>optional parameter with default value: "200"</i> Timer for the receipt of the SEIZURE ACK Signal. The unit is millisecond.
[no] clear-back-ack	Parameter type: <Sip::CasTimerProfClearBwAck> Format: - Timer for the receipt of the CLEAR BACK ACK Signal. - unit: second - range: [1...360]	<i>optional parameter with default value: "90"</i> Timer for the receipt of the CLEAR BACK ACK Signal. The unit is second.
[no] clear-fw-ack	Parameter type: <Sip::CasTimerProfClearFwAck> Format: - Timer for the receipt of the CLEAR FORWARD ACK Signal. - unit: second - range: [1...360]	<i>optional parameter with default value: "90"</i> Timer for the receipt of the CLEAR FORWARD ACK Signal. The unit is second.
[no] presence-fw-sig	Parameter type: <Sip::CasTimerProfPresenceFwSig> Format: - Timer that defines the interval for the presence of the FORWARDING Signal. - unit: second - range: [1...36]	<i>optional parameter with default value: "15"</i> Timer that defines the interval for the presence of the FORWARDING Signal. The unit is second.
[no] receipt-fw-sig	Parameter type: <Sip::CasTimerProfReceiptFwSig> Format: - Timer that defines the interval for the receipt of the FORWARDING Signal. - unit: second - range: [1...20]	<i>optional parameter with default value: "7"</i> Timer that defines the interval for the receipt of the FORWARDING Signal. The unit is second.
[no] re-answer	Parameter type: <Sip::CasTimerProfReAnswer> Format: - The re-answer timer on terminated calls to the TDM R2 side. - unit: second - range: [0...360]	<i>optional parameter with default value: "90"</i> The re-answer timer on terminated calls to the TDM R2 side. The unit is second.
[no] call-process	Parameter type: <Sip::CasTimerProfCallProcess> Format: - Timer for the call process. The timer is started after digit collection completed. - unit: second - range: [0...360]	<i>optional parameter with default value: "0"</i> Timer for the call process. The timer is started after digit collection completed. The unit is second.
[no] delay-dial-min	Parameter type: <Sip::CasTimerProfDelayDialingMinDur> Format: - Minimum time of the signal duration to recognize the delay-dialing signal (defined by ITU Q.311). - unit: millisecond - range: [140...500]	<i>optional parameter with default value: "220"</i> Minimum time of the signal duration to recognize the delay-dialing signal (defined by ITU Q.311). The unit is millisecond.
[no] delay-dial-max	Parameter type: <Sip::CasTimerProfDelayDialingMaxDur> Format: - Maximum time of the signal duration to recognize the delay-dialing signal (defined by ITU Q.311). - unit: millisecond - range: [140...500]	<i>optional parameter with default value: "250"</i> Maximum time of the signal duration to recognize the delay-dialing signal (defined by ITU Q.311). The unit is millisecond.
[no] seize-state-time	Parameter type: <Sip::CasTimerProfSeizeStateTime> Format:	<i>optional parameter with default value: "600"</i>

Parameter	Type	Description
	- The timer is used to indicate how long after the seizure signal. The value is set as 0 means that SVG will not start this timer and value 0 only apply to cas-2bit-dtmf signalling type termination. The actual valid range is from 200 ms to 1500 ms. - unit: millisecond - range: [0,200...1500]	The timer is used to indicate how long after the seizure signal, the originating side will start sending the CdPN, for those cases where the line signaling has no indication from the calling side that seizure is accepted. The value is set as 0 means that SVG will not start this timer and value 0 only apply to cas-2bit-dtmf signalling type termination. The actual valid range is from 200 ms to 1500 ms. The unit is millisecond.
[no] reg-recall-min	Parameter type: <Sip::CasTimerProfRegRecallMinDur> Format: - Minimum time of the signal duration to recognize the Register-recall signal. - unit: millisecond - range: [30...2000]	<i>optional parameter with default value: "40"</i> Minimum time of the signal duration to recognize the Register-recall signal. The unit is millisecond.
[no] reg-recall-max	Parameter type: <Sip::CasTimerProfRegRecallMaxDur> Format: - Maximum time of the signal duration to recognize the Register-recall signal. - unit: millisecond - range: [30...2000]	<i>optional parameter with default value: "890"</i> Maximum time of the signal duration to recognize the Register-recall signal. The unit is millisecond.
[no] decadic-pulse-dur	Parameter type: <Sip::CasTimerProfDpDur> Format: - Length of time for the generation of the Decadic Pulse signal. - unit: millisecond - range: [20...100]	<i>optional parameter with default value: "60"</i> Length of time for the generation of the Decadic Pulse signal. The unit is millisecond.
[no] decadic-break-dur	Parameter type: <Sip::CasTimerProfDpBreakDur> Format: - Length of time for the generation of the Decadic Pulse signal. - unit: millisecond - range: [20...100]	<i>optional parameter with default value: "40"</i> Length of time for the generation of the Decadic Pulse break. The unit is millisecond.
[no] inter-digit-peri	Parameter type: <Sip::CasTimerProfInterDigitPeriod> Format: - Timer for the inter-digit pauses. - unit: millisecond - range: [200...2000]	<i>optional parameter with default value: "600"</i> Timer for the inter-digit pauses. The unit is millisecond.
[no] ring-fw	Parameter type: <Sip::CasTimerProfRingForward> Format: - Length of time for the generation of the ring-forward signal (Q.311). - unit: second - range: [65...135]	<i>optional parameter with default value: "100"</i> Length of time for the generation of the ring-forward signal (Q.311). The unit is second.
[no] receipt-nbr-rcvd	Parameter type: <Sip::CasTimerProfReceipNbrRecv> Format: - Timer for the receipt of the Number-received signal. - unit: second - range: [15...100]	<i>optional parameter with default value: "30"</i> Timer for the receipt of the Number-received signal. The unit is second.
[no] meter-pulse-dur	Parameter type: <Sip::CasTimerProfMeterPulseDur> Format: - Length of time for the generation of the metering pulse.	<i>optional parameter with default value: "150"</i> Length of time for the generation

40 Voice Configuration Commands

Parameter	Type	Description
	- unit: millisecond - range: [50...500]	of the metering pulse. The unit is millisecond.

40.36 Network Element Table Configuration Commands

Command Description

This command allows the operator to configure Network Element Table.

User Level

The command can be accessed by operators with sip privileges, and executed by operators with sip privileges.

Command Syntax

The command has the following syntax:

```
> configure voice sip ( no network-element cap-id <Sip::CapId> ne-id <Sip::NeId> ) | ( network-element cap-id
<Sip::CapId> ne-id <Sip::NeId> ne-name <Sip::NeName> [ no role | role <Sip::NeRole> ] [ no admin-status |
admin-status <Sip::NeAdminStatus> ] [ no ip | ip <SIP::IpAddressAndMask> ] [ no vlan-id | vlan-id
<Sip::NeVlanId> ] )
```

Command Parameters

Table 40.36-1 "Network Element Table Configuration Commands" Resource Parameters

Resource Identifier	Type	Description
cap-id	Parameter type: <Sip::CapId> Format: - the central access point id - range: [1...16]	The unique identifier of this central access point
ne-id	Parameter type: <Sip::NeId> Format: - the network element id - range: [1...8]	The unique identifier of this network element

Table 40.36-2 "Network Element Table Configuration Commands" Command Parameters

Parameter	Type	Description
ne-name	Parameter type: <Sip::NeName> Format: - the name of the network element - length: x<=32	<i>mandatory parameter</i> The operator friendly name of this network element
[no] role	Parameter type: <Sip::NeRole> Format: (local-ne remote-ne cap-ne) Possible values: - local-ne : the entry of a REMOTE NE is configured in that same REMOTE NE	<i>optional parameter with default value: "cap-ne"</i> The CAP related role of the network element

40 Voice Configuration Commands

Parameter	Type	Description
	- remote-ne : the entry of a REMOTE NE is configured in the CAP NE or another REMOTE NE - cap-ne : the entry of the CAP NE is configured in the CAP NE or a remote NE	
[no] admin-status	Parameter type: <Sip::NeAdminStatus> Format: (up down) Possible values: - up : the ISAMv NE can be addressed - down : the ISAMv NE cannot be addressed	<i>optional parameter with default value: "down"</i> administrative status of this network element
[no] ip	Parameter type: <SIP::IpAddressAndMask> Format: <Ip::V4Address> / <Sip::PrefixLength> Field type <Ip::V4Address> - IPv4-address Field type <Sip::PrefixLength> - prefix length of the subnet - range: [0...128]	<i>optional parameter with default value: "0.0.0.0/0"</i> The internal communication IP address that applies to the NIAT-A LT boards
[no] vlan-id	Parameter type: <Sip::NeVlanId> Format: - The VLAN ID used by the internal communication between the CAP and the NIAT-A LT board - range: [0...4093]	<i>optional parameter with default value: "0"</i> The VLAN ID used by the internal communication between the CAP and the NIAT-A LT board

40.37 Voice Sip Call Query Configuration Commands

Command Description

This command allows the operator to create and start a call query for active call.

User Level

The command can be accessed by operators with sip privileges, and executed by operators with sip privileges.

Command Syntax

The command has the following syntax:

```
> configure voice sip ( no call-query (id) ) | ( call-query (id) [ no timeout-period | timeout-period
<Sip::TimeoutPeriod> ] target-dn <Sip::CallQueryTargetDN> [ no remote-dn | remote-dn
<Sip::CallQueryRemoteDN> ] [ no type | type <Sip::CallQueryType> ] )
```

Command Parameters

Table 40.37-1 "Voice Sip Call Query Configuration Commands" Resource Parameters

Resource Identifier	Type	Description
(id)	Format: - the index of call query session - range: [1]	The unique identifier of this call query session

Table 40.37-2 "Voice Sip Call Query Configuration Commands" Command Parameters

Parameter	Type	Description
[no] timeout-period	Parameter type: <Sip::TimeoutPeriod> Format: - Allows to set the whole timer of sending call query request to all configured LTs and receiving query results of these LTs. - unit: second - range: [1...255]	<i>optional parameter with default value: 10</i> Allows to set the whole timer of sending call query request to all configured LTs and receiving query results of these LTs.
target-dn	Parameter type: <Sip::CallQueryTargetDN> Format: - The Target DN is a number that is registered on that specific SVG shelf. It can be a GDN number or Puid number (for ISDN and CAS), and it can be either the calling or called number. If uri is configured, the Target DN should be consistent with user part in configured uri. If uri is not configured, the Target DN should be consistent with directory number. - length: 1<=x<=32	<i>mandatory parameter</i> The Target DN is a number that is registered on that specific SVG shelf. It can be a GDN number or Puid number (for ISDN and CAS), and it can be either the calling or called number. If uri is configured, the Target DN should be consistent with user part in configured uri. If uri is not configured, the Target DN should

40 Voice Configuration Commands

Parameter	Type	Description
		be consistent with directory number.
[no] remote-dn	Parameter type: <Sip::CallQueryRemoteDN> Format: - The Remote DN can be any number, this is the number with which the Target DN is expected to be in a call. - length: x<=32	<i>optional parameter with default value: ""</i> The Remote DN can be any number, this is the number with which the Target DN is expected to be in a call.
[no] type	Parameter type: <Sip::CallQueryType> Format: (pots isdn-pri cas) Possible values: - pots : only transfer request data to NPOT-B/NPOT-C and receive POTS call query results from them. - isdn-pri : only transfer request data to NIAT-A and receive ISDN-PRI call query results from them. - cas : only transfer request data to NIAT-A and receive CAS call query results from them.	<i>optional parameter with default value: "pots"</i> Allows to configure which type of call will be queried on Target DN.

40.38 Voice Cluster Configuration Commands

Command Description

This command allows the operator to manage the Voice Cluster.

User Level

The command can be accessed by operators with megaco privileges, and executed by operators with megaco privileges.

Command Syntax

The command has the following syntax:

> configure voice cluster (cluster-id)

Command Parameters

Table 40.38-1 "Voice Cluster Configuration Commands" Resource Parameters

Resource Identifier	Type	Description
(cluster-id)	Format: - the xvps cluster id - range: [1...8,11]	uniquely identify of this xvps cluster

40.39 Voice Megaco IP Configuration Commands

Command Description

This command allows the operator to manage the Voice Megaco xvps ip.

User Level

The command can be accessed by operators with megaco privileges, and executed by operators with megaco privileges.

Command Syntax

The command has the following syntax:

```
> configure voice cluster (cluster-id) ip [ no ivps-ip | ivps-ip <Ip::V4Address> ] [ no netmask | netmask
<Ip::V4Address> ] [ no router-ip | router-ip <Ip::V4Address> ] [ vlan-id <MEGACO::ivpsXLESVLAN> ] [ no
ip-mode | ip-mode <MEGACO::voiceIPConfigMode> ] [ no dhcption60 | dhcption60
<MEGACO::voiceIPDhcpv4Option60> ] [ no private-ip | private-ip <Ip::V4Address> ] [ no private-netmask |
private-netmask <Ip::V4Address> ] [ no private-vlan-id | private-vlan-id <MEGACO::ivpsPrivateVLAN> ]
```

Command Parameters

Table 40.39-1 "Voice Megaco IP Configuration Commands" Resource Parameters

Resource Identifier	Type	Description
(cluster-id)	Format: - the xvps cluster id - range: [1...8,11]	uniquely identify of this xvps cluster

Table 40.39-2 "Voice Megaco IP Configuration Commands" Command Parameters

Parameter	Type	Description
[no] ivps-ip	Parameter type: <Ip::V4Address> Format: - IPv4-address	<i>optional parameter with default value: "0.0.0.0"</i> xles ip address of this xvps cluster.When operator configure Ip parameters first time ,operator should provide ivps-ip,netmask and vlan-id at the same time.
[no] netmask	Parameter type: <Ip::V4Address> Format: - IPv4-address	<i>optional parameter with default value: "0.0.0.0"</i> xles ip subnet mask address of this xvps cluster.When operator configure Ip parameters first time ,operator should provide ivps-ip,netmask and vlan-id at the same time.
[no] router-ip	Parameter type: <Ip::V4Address> Format: - IPv4-address	<i>optional parameter with default value: "0.0.0.0"</i> the next hop ip address of this

Parameter	Type	Description
		xvps cluster. When operator configure Ip parameters first time ,operator should provide ivps-ip,netmask and vlan-id at the same time.
vlan-id	Parameter type: <MEGACO::ivpsXLESVLAN> Format: - the vlan id of xvps - range: [0...4093]	<i>optional parameter</i> vlan id of voice xvps cluster
[no] ip-mode	Parameter type: <MEGACO::voiceIPConfigMode> Format: (dhcp manual) Possible values: - dhcp : The ip mode is dhcp - manual : The ip mode is manual	<i>optional parameter with default value: "manual"</i> the configure mode of the IP addresses
[no] dhcption60	Parameter type: <MEGACO::voiceIPDhcpv4Option60> Format: - DHCP option 60 for the DHCP client - length: x<=64	<i>optional parameter with default value: ""</i> the DHCP option 60 for the DHCP client
[no] private-ip	Parameter type: <Ip::V4Address> Format: - IPv4-address	<i>optional parameter with default value: "0.0.0.0"</i> the private ip address of voice xvps cluster. When operator configure Ip parameters first time ,operator should provide ivps-ip,netmask and vlan-id at the same time.
[no] private-netmask	Parameter type: <Ip::V4Address> Format: - IPv4-address	<i>optional parameter with default value: "0.0.0.0"</i> the private ip subnet mask address of voice xvps cluster. When operator configure Ip parameters first time ,operator should provide ivps-ip,netmask and vlan-id at the same time.
[no] private-vlan-id	Parameter type: <MEGACO::ivpsPrivateVLAN> Format: - the private vlan id of xvps - range: [0...4093]	<i>optional parameter with default value: 0</i> the private vlan of voice xvps cluster. When operator configure Ip parameters first time ,operator should provide ivps-ip,netmask and vlan-id at the same time.

40.40 Voice Megaco Equipment Configuration Commands

Command Description

This command allows the operator to manage the Voice equipment. One ivps can manage at most 256 equipments, so the id of equipment is from 1 to 256.

If you want to configure a board or a termination, you must configure a equipment first.

User Level

The command can be accessed by operators with megaco privileges, and executed by operators with megaco privileges.

Command Syntax

The command has the following syntax:

```
> configure voice cluster (cluster-id) ( no equipment (equip-id) ) | ( equipment (equip-id) asam-id
<MEGACO::accessEquipmentAsamId> ip-address <Ip::V4Address> [ no next-hop | next-hop <Ip::V4Address> ] )
```

Command Parameters

Table 40.40-1 "Voice Megaco Equipment Configuration Commands" Resource Parameters

Resource Identifier	Type	Description
(cluster-id)	Format: - the xvps cluster id - range: [1...8,11]	uniquely identify of this xvps cluster
(equip-id)	Format: - id of equipment - range: [1...32]	uniquely identify of this equipment

Table 40.40-2 "Voice Megaco Equipment Configuration Commands" Command Parameters

Parameter	Type	Description
asam-id	Parameter type: <MEGACO::accessEquipmentAsamId> Format: - the equipment asam id of ne - range: [a-zA-Z0-9-_.] - length: x<=64	<i>mandatory parameter</i> asam identify of this ne
ip-address	Parameter type: <Ip::V4Address> Format: - IPv4-address	<i>mandatory parameter</i> <i>The parameter is not visible during modification.</i> the voice ip address of this isam-v ne.
[no] next-hop	Parameter type: <Ip::V4Address> Format:	<i>optional parameter with default value: "0.0.0.0"</i>

Parameter	Type	Description
	- IPv4-address	the ip address of the next hop for this isam-v ne

40.41 Voice Megaco Equipment Board Configuration Commands

Command Description

This command allows the operator to manage the Voice board. Before you configure a board, you must configure a equipment first.

User Level

The command can be accessed by operators with megaco privileges, and executed by operators with megaco privileges.

Command Syntax

The command has the following syntax:

```
> configure voice cluster (cluster-id) equipment (equip-id) ( no board (board-id) ) | ( board (board-id) planned-type
<Equipm::BoardFuncType> lanx-port <MEGACO::accessBoardLanxPort> )
```

Command Parameters

Table 40.41-1 "Voice Megaco Equipment Board Configuration Commands" Resource Parameters

Resource Identifier	Type	Description
(cluster-id)	Format: - the xvps cluster id - range: [1...8,11]	uniquely identify of this xvps cluster
(equip-id)	Format: - id of equipment - range: [1...32]	uniquely identify of this equipment
(board-id)	Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::NewSlotId> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::NewSlotId>) Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::NewSlotId> - the LT slot number	uniquely identify of this board. the CLI slot numbering method is based on logical concept. for XD shelf, CLI logic slot-id(1 to 16) is mapped to physical slot-id from 4 to 19. for FD shelf, CLI logic slot-id(1 to 16) is mapped to physical slot-id from 1 to 8 and 12 to 19. In extend-lt mode, the slot-id range shall be 1 to 18. For XD shelf, CLI logic slot-id(17 to 18) is mapped to physical slot-id from 2 to 3. for FD shelf, CLI logic slot-id(17 to 18) is mapped to physical slot-id from 10 to 11

Table 40.41-2 "Voice Megaco Equipment Board Configuration Commands" Command Parameters

Parameter	Type	Description
planned-type	Parameter type: <Equipm::BoardFuncType> Format: (nbat-b nbat-a npot-a nvps-a nvps-c polt-b npot-b npot-c ivps-b balt-a ivps-a polt-a isdn-24l pots-48l) Possible values: - nbat-b : ISDN Basic Access line termination board for FD (4B3T) - nbat-a : ISDN Basic Access line termination board for FD - npot-a : 48 Pots Only LT board for FD - nvps-a : Isam Voice Packet Server for FD - nvps-c : Isam Voice Packet Server for FD - polt-b : 48 Pots Only LT board for XD - npot-b : 72 Pots Only LT board for FD - npot-c : 48 Pots Only LT board for FD - ivps-b : Isam Voice Packet Server for XD - balt-a : 48 ISDN Only LT board for XD - ivps-a : Isam Voice Packet Server for XD - polt-a : 48 Pots Only LT board for XD - isdn-24l : 24 ISDN LT board for XD/FD, only for migration, can not be configured - pots-48l : 48 Pots LT board for XD/FD, only for migration, can not be configured	<i>mandatory parameter</i> the type of user board
lanx-port	Parameter type: <MEGACO::accessBoardLanxPort> Format: - the logic slot of board - range: [1...32]	<i>mandatory parameter</i> <i>The parameter is not visible during modification.</i> the logic slot of this board

40.42 Voice Megaco Equipment Termination Configuration Commands

Command Description

This command allows the operator to manage the Voice termination. Before you configure a termination, you must configure a equipment first.

User Level

The command can be accessed by operators with megaco privileges, and executed by operators with megaco privileges.

Command Syntax

The command has the following syntax:

```
> configure voice cluster (cluster-id) equipment (equip-id) ( no termination (port-id) ) | ( termination (port-id) [ no
type | type <MEGACO::accTerminationUserPortType> ] [ no isdn-codec | isdn-codec
<MEGACO::IsdnCodecType> ] [ no switch-type | switch-type <MEGACO::accTerminationPacketSwitchType> ] [
no activate-type | activate-type <MEGACO::accTerminationL1ActivateType> ] [ termination-id
<MEGACO::accessTerminationId> ] media-gateway-id <MEGACO::MediaGatewayId> [ no admin-status |
admin-status <MEGACO::accTerminationAdminStatus> ] [ no line-feed | line-feed
<MEGACO::accTerminationLineCharact> ] [ no rx-gain | rx-gain <MEGACO::accTerminationRxGain> ] [ no
tx-gain | tx-gain <MEGACO::accTerminationTxGain> ] [ no impedance | impedance
<MEGACO::accTerminationImpedance> ] [ no rtp-dscp | rtp-dscp <MEGACO::accTerminationVoiceDscp> ] [ no
rtp-pbits | rtp-pbits <MEGACO::accTerminationVoiceDot1P> ] [ no clip-mode | clip-mode
<MEGACO::accTerminationETSIClipDataMode> ] [ no metering-type | metering-type
<MEGACO::accTerminationMeteringPulseType> ] [ no directory-number | directory-number
<MEGACO::accTerminationDirectoryNumber> ] [ no voice-service | voice-service
<MEGACO::accTermVoiceServAtMgc> ] [ no reserved | reserved <MEGACO::accTerminationReserved> ] )
```

Command Parameters

Table 40.42-1 "Voice Megaco Equipment Termination Configuration Commands" Resource Parameters

Resource Identifier	Type	Description
(cluster-id)	Format: - the xvps cluster id - range: [1...8,11]	uniquely identify of this xvps cluster
(equip-id)	Format: - id of equipment - range: [1...32]	uniquely identify of this equipment
(port-id)	Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::NewSlotId> / <Eqpt::MegacoPortId> Field type <Eqpt::RackId>	unique identifier of this termination port

Resource Identifier	Type	Description
	- the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::NewSlotId> - the LT slot number Field type <Eqpt::MegacoPortId> - the port number of Megaco	

Table 40.42-2 "Voice Megaco Equipment Termination Configuration Commands" Command Parameters

Parameter	Type	Description
[no] type	Parameter type: <MEGACO::accTerminationUserPortType> Format: (pstn isdn) Possible values: - pstn : the termination type is pstn - isdn : the termination type is isdn	<i>optional parameter with default value: "pstn"</i> The type of termination user port
[no] isdn-codec	Parameter type: <MEGACO::IsdnCodecType> Format: (alaw ulaw) Possible values: - alaw : the codec type on TDM side of isdn is a_law - ulaw : the codec type on TDM side of isdn is u_law	<i>optional parameter with default value: "alaw"</i> the type of isdn codec on TDM side
[no] switch-type	Parameter type: <MEGACO::accTerminationPacketSwitchType> Format: (enable disable) Possible values: - enable : the packet switch type is enable - disable : the packet switch type is disable	<i>optional parameter with default value: "disable"</i> The type of the packet switch type, only for type isdn
[no] activate-type	Parameter type: <MEGACO::accTerminationL1ActivateType> Format: (permanent percall) Possible values: - permanent : the layer1 activate type is permanent - percall : the layer1 activate type is percall	<i>optional parameter with default value: "permanent"</i> The type of the layer1 activate type, only for type isdn
termination-id	Parameter type: <MEGACO::accessTerminationId> Format: - the termination id, if it is not specified, system will automatically assign a free one in range - range: [0...32767]	<i>optional parameter</i> The id of termination, if not entered during creating, it will be assigned by system
media-gateway-id	Parameter type: <MEGACO::MediaGatewayId> Format: - the media gateway table index - range: [1]	<i>mandatory parameter</i> The id of media gateway
[no] admin-status	Parameter type: <MEGACO::accTerminationAdminStatus> Format: (locked unlocked) Possible values: - locked : the admin status of termination is locked	<i>optional parameter with default value: "locked"</i> The administrative status of termination

40 Voice Configuration Commands

Parameter	Type	Description
	- unlocked : the admin status of termination is unlocked	
[no] line-feed	Parameter type: <MEGACO::accTerminationLineCharact> Format: (25 40) Possible values: - 25 : the line character is 25 mA - 40 : the line character is 40 mA	<i>optional parameter with default value: "25"</i> The line character of this termination, only for type pstn
[no] rx-gain	Parameter type: <MEGACO::accTerminationRxGain> Format: - the termination rx-gain - range: [-14...6]	<i>optional parameter with default value: "0"</i> The rx-gain of this termination, only for type pstn
[no] tx-gain	Parameter type: <MEGACO::accTerminationTxGain> Format: - the termination tx-gain - range: [-14...6]	<i>optional parameter with default value: "0"</i> The tx-gain of this termination, only for type pstn
[no] impedance	Parameter type: <MEGACO::accTerminationImpedance> Format: (default 200 220 220minisplitter 270 300 370 600 900 370minisplitter 600splitter 370nvlsasplitter 370skinnysplitter 270duratelsplitter 2703msplitter 100 150 220splitter reserv19 reserv20 reserv21) Possible values: - default : the impedance is default vaule - 200 : the line impedance is 200 ohm - 220 : the line impedance is 220 ohm - 220minisplitter : the line impedance is 220 ohm+ miniSplitter - 270 : the line impedance is 270 ohm - 300 : the line impedance is 300 ohm - 370 : the line impedance is 370 ohm - 600 : the line impedance is 600 ohm - 900 : the line impedance is 900 ohm - 370minisplitter : the line impedance is 370 ohm+ miniSplitter - 600splitter : the line impedance is 600 ohm+ Splitter - 370nvlsasplitter : the line impedance is 370 ohm+ NVLSASplitter - 370skinnysplitter : the line impedance is 370 ohm+ SkinnySplitter	<i>optional parameter with default value: "default"</i> The impedance of this termination, only for type pstn

Parameter	Type	Description
	- 270duratelsplitter : the line impedance is 270 ohm+ DuratelSplitter - 2703msplitter : the line impedance is 270 ohm+ 3MDplitter - 100 : the line impedance is 100 ohm - 150 : the line impedance is 150 ohm - 220splitter : the line impedance is 220 ohm+ Splitter - reserv19 : reserved for future use 19 - reserv20 : reserved for future use 20 - reserv21 : reserved for future use 21	
[no] rtp-dscp	Parameter type: <MEGACO::accTerminationVoiceDscp> Format: - the termination voice dscp - range: [-1...63]	<i>optional parameter with default value: "-1"</i> the voice dscp of termination
[no] rtp-pbits	Parameter type: <MEGACO::accTerminationVoiceDot1P> Format: - the termination voice p-bit - range: [-1...7]	<i>optional parameter with default value: "-1"</i> the voice p-bit of termination
[no] clip-mode	Parameter type: <MEGACO::accTerminationETSIClipDataMode> Format: (cdevalue fsk dtmf) Possible values: - cdevalue : cde configuration will be applied for etsi clip - fsk : fsk will be applied for etsi clip - dtmf : dtmf will be applied for etsi clip	<i>optional parameter with default value: "cdevalue"</i> the etsi clip data transmission protocol of this access termination, it can only be configured in pstn line cards
[no] metering-type	Parameter type: <MEGACO::accTerminationMeteringPulseType> Format: (pulse polarityreverse) Possible values: - pulse : 12/16 KHz sine waveform pulse will be applied for metering pulse - polarityreverse : line polarity reverse pulse will be applied for metering pulse	<i>optional parameter with default value: "pulse"</i> the metering pulse type of this access termination, it can only be configured on pstn line
[no] directory-number	Parameter type: <MEGACO::accTerminationDirectoryNumber> Format: - the termination directory number. '#' is invalid character - length: 1<=x<=16	<i>optional parameter with default value: ""</i> the directory number of this access termination, it can be configured on pstn and ISDN BA line
[no] voice-service	Parameter type: <MEGACO::accTermVoiceServAtMgc> Format: (enabled disabled) Possible values: - enabled : The voice service of termination is enabled - disabled : The voice service of termination is disabled	<i>optional parameter with default value: "enabled"</i> voice service provision of termination
[no] reserved	Parameter type: <MEGACO::accTerminationReserved> Format: - reserved for future usage - length: x<=32	<i>optional parameter with default value: ""</i> reserved for future usage

40.43 Voice Megaco Termination Configuration Commands

Command Description

This command allows the operator to enable/disable tca or configure the threshold for rtp packetloss, jitter and delay of the Voice termination.

User Level

The command can be accessed by operators with megaco privileges, and executed by operators with megaco privileges.

Command Syntax

The command has the following syntax:

```
> configure voice cluster (cluster-id) equipment (equip-id) termination (port-id) tca [ no tca-enable | tca-enable
<MEGACO::accTerminationTCAEnable> ] [ no rtp-pktloss-thres | rtp-pktloss-thres
<MEGACO::accTerminationRtpPacketLossTCAThreshold> ] [ no rtp-jitter-thres | rtp-jitter-thres
<MEGACO::accTerminationRtpJitterTCAThreshold> ] [ no rtp-delay-thres | rtp-delay-thres
<MEGACO::accTerminationRtpDelayTCAThreshold> ]
```

Command Parameters

Table 40.43-1 "Voice Megaco Termination Configuration Commands" Resource Parameters

Resource Identifier	Type	Description
(cluster-id)	Format: - the xvps cluster id - range: [1...8,11]	uniquely identify of this xvps cluster
(equip-id)	Format: - id of equipment - range: [1...32]	uniquely identify of this equipment
(port-id)	Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::NewSlotId> / <Eqpt::MegacoPortId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::NewSlotId> - the LT slot number Field type <Eqpt::MegacoPortId> - the port number of Megaco	unique identifier of this termination port

Table 40.43-2 "Voice Megaco Termination Configuration Commands" Command Parameters

Parameter	Type	Description
[no] tca-enable	Parameter type: <MEGACO::accTerminationTCAEnable> Format: (enabled disabled) Possible values: - enabled : enable tca alarm report - disabled : disable tca alarm report	<i>optional parameter with default value: "disabled"</i> Allows to enable/disable the Threshold Crossing Alarm feature for this termination
[no] rtp-pktloss-thres	Parameter type: <MEGACO::accTerminationRtpPacketLossTCAThreshold> Format: - the packet loss threshold for the termination - range: [0...100]	<i>optional parameter with default value: 1</i> the rtp packet loss threshold of this megaco termination,a value 0 means TCA_packetloss will be disabled
[no] rtp-jitter-thres	Parameter type: <MEGACO::accTerminationRtpJitterTCAThreshold> Format: - the interarrival jitter threshold for the termination - unit: millisec - range: [0...2147483647]	<i>optional parameter with default value: 60</i> the rtp interarrival jitter threshold of this megaco termination,a value 0 means TCA_jitter will be disabled
[no] rtp-delay-thres	Parameter type: <MEGACO::accTerminationRtpDelayTCAThreshold> Format: - the round trip delay threshold for the termination - unit: millisec - range: [0...2147483647]	<i>optional parameter with default value: 400</i> the rtp round trip delay threshold of this megaco termination,a value 0 means TCA_delay will be disabled

40.44 Voice Megaco Termination Lawful Intercept Configuration Commands

Command Description

This command allows the operator to enable/disable lawful intercept and configure the src-port,dest-ip,dest-port for li stream. the src ip is same as rtp ip.

User Level

The command can be accessed by operators with li_voice privileges, and executed by operators with li_voice privileges.

Command Syntax

The command has the following syntax:

```
> configure voice cluster (cluster-id) equipment (equip-id) termination (port-id) ( no li ) | ( li [ no state | state
<MEGACO::accTerminationLI> ] src-port <MEGACO::accTerminationLISrcUdpPort> dest-ip <Ip::V4Address>
dest-port <MEGACO::accTerminationLIDestUdpPort> )
```

Command Parameters

Table 40.44-1 "Voice Megaco Termination Lawful Intercept Configuration Commands" Resource Parameters

Resource Identifier	Type	Description
(cluster-id)	Format: - the xvps cluster id - range: [1...8,11]	uniquely identify of this xvps cluster
(equip-id)	Format: - id of equipment - range: [1...32]	uniquely identify of this equipment
(port-id)	Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::NewSlotId> / <Eqpt::MegacoPortId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::NewSlotId> - the LT slot number Field type <Eqpt::MegacoPortId> - the port number of Megaco	unique identifier of this termination port

Table 40.44-2 "Voice Megaco Termination Lawful Intercept Configuration Commands" Command Parameters

Parameter	Type	Description
[no] state	Parameter type: <MEGACO::accTerminationLI> Format: (enabled disabled) Possible values: - enabled : enable lawful intercept - disabled : disable lawful intercept	<i>optional parameter with default value: "disabled"</i> allows to enable/disable the lawful intercept feature for this termination
src-port	Parameter type: <MEGACO::accTerminationLISrcUdpPort> Format: - the source udp port for lawful intercept - range: [49153...65535]	<i>mandatory parameter</i> the source udp port for lawful intercept. source ip address is same as voice ip
dest-ip	Parameter type: <Ip::V4Address> Format: - IPv4-address	<i>mandatory parameter</i> the destination ip address for lawful intercept
dest-port	Parameter type: <MEGACO::accTerminationLIDestUdpPort> Format: - the destination udp port for lawful intercept - range: [0...65535]	<i>mandatory parameter</i> the destination udp port for lawful intercept

40.45 Voice Megaco Equipment Secondary Termination Configuration Commands

Command Description

This command allows the operator to manage the Voice secondary termination. Before you configure the secondary termination, you must configure an equipment and prime termination first.

User Level

The command can be accessed by operators with megaco privileges, and executed by operators with megaco privileges.

Command Syntax

The command has the following syntax:

```
> configure voice cluster (cluster-id) equipment (equip-id) ( no sharedlineterm (port-id) ) | ( sharedlineterm
(port-id) [ sharedlineterm-id <MEGACO::accessTerminationId> ] [ no admin-status | admin-status
<MEGACO::accTerminationAdminStatus> ] [ no directory-number | directory-number
<MEGACO::accTerminationDirectoryNumber> ] [ no voice-service | voice-service
<MEGACO::accTermVoiceServAtMgc> ] )
```

Command Parameters

Table 40.45-1 "Voice Megaco Equipment Secondary Termination Configuration Commands" Resource Parameters

Resource Identifier	Type	Description
(cluster-id)	Format: - the xvps cluster id - range: [1...8,11]	uniquely identify of this xvps cluster
(equip-id)	Format: - id of equipment - range: [1...32]	uniquely identify of this equipment
(port-id)	Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::NewSlotId> / <Eqpt::MegacoPortId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::NewSlotId> - the LT slot number Field type <Eqpt::MegacoPortId> - the port number of Megaco	unique identifier of the secondary termination port

Table 40.45-2 "Voice Megaco Equipment Secondary Termination Configuration Commands"

Command Parameters

Parameter	Type	Description
sharedlineterm-id	Parameter type: <MEGACO::accessTerminationId> Format: - the termination id, if it is not specified, system will automatically assign a free one in range - range: [0...32767]	<i>optional parameter</i> The id of the secondary termination, if not set manually during creating, it will be assigned by system
[no] admin-status	Parameter type: <MEGACO::accTerminationAdminStatus> Format: (locked unlocked) Possible values: - locked : the admin status of termination is locked - unlocked : the admin status of termination is unlocked	<i>optional parameter with default value: "locked"</i> The administrative status of the secondary termination
[no] directory-number	Parameter type: <MEGACO::accTerminationDirectoryNumber> Format: - the termination directory number. '#' is invalid character - length: 1<=x<=16	<i>optional parameter with default value: ""</i> the directory number of this access secondary termination
[no] voice-service	Parameter type: <MEGACO::accTermVoiceServAtMgc> Format: (enabled disabled) Possible values: - enabled : The voice service of termination is enabled - disabled : The voice service of termination is disabled	<i>optional parameter with default value: "enabled"</i> voice service provision of the secondary termination

40.46 Voice Megaco Media Gateway Configuration Commands

Command Description

This command allows the operator to manage the Voice Megaco media gateway.

- pstn-term-format: the termination id format pattern of pstn user.

If termid-type is hierarchy, It should be a string constructed according to the following rule:

[prefix][['Dslam_Id']][deli1]][['rack']][formater][deli2]]'shelf'[formater][deli3]'slot'[formater][deli4]'port'[formater] and thereinto:

'Dslam_Id' is key to indicate whether the Dslam id should be filled into hierarchy termination id. It is optional.

'rack' is key to indicate whether the rack id should be filled into hierarchy termination id. It is optional.

'shelf' is key to indicate the shelf id. It is mandatory.

'slot' is key to indicate the slot id. It is mandatory.

'port' is key to indicate the port id. It is mandatory.

Each key should present only once and the order of the keys should keep as in the rule.

deli can be zero or several characters, be note that the char must be valid for MEGACO termination id.

formater is a format string to indicate how ISAMV should format the id right before it. It must be constructed by zero or at most five digits. The number of digits indicate the minimum width of the id in the termination id, so if the width of the id is less than number of digits in formater, '0' is filling at the beginning. The value that converted by the digits into a integer indicates the value of the first device NO. in the termination id. If the no digit existing, it indicates that no format need to be applied.

prefix is a string constructed by any character that is valid for MEGACO termination id.

At least one of the deli and the formater must be presenting after the key(exclude 'Dslam_Id').

for example:

format string port position termination id

(dslamid/rack/shelf/slot/port)

AL/Dslam_Id/rack/shelf/slot/port nod01/1/1/1/1 AL/nod01/1/1/1/1

AL/Dslam_Id/shelf/slot/port nod01/1/1/1/1 AL/nod01/1/1/1

AL/rack/shelf/slot/port nod01/1/1/1/1 AL/1/1/1/1

AL/rack0/shelf0/slot0/port00 nod01/1/1/1/1 AL/0/0/0/00

ALDslam_Idrack0shelf0slot0port00 nod01/1/1/1/1 ALnod0100000

ALDslam_Idrack0shelf0slot0port0 nod01/1/1/1/12 ALnod0100012

 If the termid-type is flat, It should be a string constructed according to the following rule:

`[prefix]['<tid'[formater]']>'`

and thereinto:

prefix is a string construct by any character that is valid for MEGACO termination id.

formater is a format string to indicate how ISAMV should format the id right before it.

It must be constructed by zero or at most five digits. The number of digits indicate the minimum width of the id in the termination id. If it contains no digit, it indicates that no format need to be applied. for example:

format string port position termination id

(termination-id)

`AL/ 0 AL/0`

`AL 0 AL0`

`AL<tid000> 0 AL000`

`AL<tid000> 888 AL888`

 - *isdn-term-format*: the termination id format pattern of isdn user.

If termid-type is hierarchy, It should be a string constructed according to the following rule:

`[prefix][['Dslam_Id']][deli1]][['rack']][formater][deli2]]'shelf'[formater][deli3]'slot'[formater][deli4]'port'[formater]][deli4]'channel'`

and thereinto:

'Dslam_Id' is key to indicate whether the Dslam id should be filled into hierarchy termination id.

It is optional.

'rack' is key to indicate whether the rack id should be filled into hierarchy termination id.

It is optional.

'shelf' is key to indicate the shelf id. It is mandatory.

'slot' is key to indicate the slot id. It is mandatory.

'port' is key to indicate the port id. It is mandatory.

'channel' is key to indicate channel id. It is mandatory.

Each key should present only once and the order of the keys should keep as in the rule.

deli can be zero or several characters, be note that the char must be valid for MEGACO termination id.

formater is a format string to indicate how ISAMV should format the id right before it. It must be constructed by zero or at most five digits. The number of digits indicate the minimum width of the id in the termination id, so if the width of the id is less than number of digits in *formater*, '0' is filling at the beginning. The value that converted by the digits into a integer indicates the value of the first device NO. in the termination id. If the no digit existing, it indicates that no format need to be applied. suffix already includes delimiter, so *deli4* is will be replaced by suffix.

prefix is a string constructed by any character that is valid for MEGACO termination id.

At least one of the *deli* and the *formater* must be presenting after the key(exclude 'Dslam_Id').

for example:

format string port position termination id

(*dslamid/rack/shelf/slot/port suffix*)

BA/Dslam_Id/rack/shelf/slot/port/channel nod01/1/1/1/1 /B1 BA/nod01/1/1/1/1/B1

BA/Dslam_Id/shelf/slot/port/channel nod01/1/1/1/1 /B1 BA/nod01/1/1/1/B1

BA/rack/shelf/slot/port/channel nod01/1/1/1/1 /B1 BA/1/1/1/1/B1

BA/rack0/shelf0/slot0/port00/channel/channel nod01/1/1/1/1 /B1 BA/0/0/0/00/B1

BADslam_Idrack0shelf0slot0port00 nod01/1/1/1/1 /B1 BAnod0100000/B1

BADslam_Idrack0shelf0slot0port0/channel nod01/1/1/1/12 B1 BAnod0100012B1

If the *termid-type* is *flat*,It should be a string constructed according to the following rule:

[*prefix*]['<*tid*'[*formater*]'>']

and thereinto:

prefix is a string construct by any character that is valid for MEGACO termination id.

formater is a format string to indicate how ISAMV should format the id right before it.It must be constructed by zero or at most five digits. The number of digits indicat the minimum width of the id in the termination id,If contains no digit, it indicat that no format need to be applied. ISDN termination id should not be zero because zero is reserved for special use of IID.

for example:

format string port position termination id

(*termination-id suffix*)

BA/ 1 /B1 BA/1/B1

BA 1 /B1 BA1/B1

BA<tid000> 1 /B1 BA001/B1

BA<tid000> 888 /B1 BA888/B1

User Level

The command can be accessed by operators with megaco privileges, and executed by operators with megaco privileges.

Command Syntax

The command has the following syntax:

> configure voice cluster (cluster-id) (no media-gateway (media-gateway-id)) | (media-gateway

```

(media-gateway-id) [ no name | name <MEGACO::mediaGatewayName> ] [ no ip-mode | ip-mode
<MEGACO::voiceIPConfigMode> ] [ no dhcption60 | dhcption60 <MEGACO::voiceIPDhcpv4Option60> ] [
no ip-address | ip-address <Ip::V4Address> ] [ no netmask | netmask <Ip::V4Address> ] [ no udp-port | udp-port
<MEGACO::mediaGatewayUDPPort> ] [ no router-ip | router-ip <Ip::V4Address> ] vlan-id
<MEGACO::mediaGatewayVLAN> [ no mgc-type | mgc-type <MEGACO::mediaGatewayMgcType> ]
prim-mgc-ip <Ip::V4Address> [ no mgc-id | mgc-id <MEGACO::medGwyCtrlrCallServerId> ] [ no prim-mgc-udp
| prim-mgc-udp <MEGACO::medGwyCtrlrPrimaryUDPPort> ] [ no sec-mgc-ip | sec-mgc-ip <Ip::V4Address> ] [
no sec-mgc-udp | sec-mgc-udp <MEGACO::medGwyCtrlrSecondaryUDPPort> ] [ no tert-mgc-ip | tert-mgc-ip
<Ip::V4Address> ] [ no tert-mgc-udp | tert-mgc-udp <MEGACO::medGwyCtrlrTertiaryUDPPort> ] [ no
quat-mgc-ip | quat-mgc-ip <Ip::V4Address> ] [ no quat-mgc-udp | quat-mgc-udp
<MEGACO::medGwyCtrlrQuaternaryUDPPort> ] [ no esa-mgc-service | esa-mgc-service
<MEGACO::mediaGatewayESAMgcService> ] [ no mg-mid-type | mg-mid-type
<MEGACO::mediaGatewayMidType> ] [ no mg-domain-name | mg-domain-name
<MEGACO::mediaGatewayDomainName> ] [ no svcreason-format | svcreason-format
<MEGACO::mediaGatewaySVCReasonFormat> ] [ no mg-profile-name | mg-profile-name
<MEGACO::mediaGatewayProfileName> ] [ no admin-status | admin-status
<MEGACO::mediaGatewayadminStatus> ] [ no termid-type | termid-type <MEGACO::mediaGwyTermFormat> ]
[ no pstn-term-format | pstn-term-format <MEGACO::mediaGwyPstnTermFormat> ] [ isdn-term-format
<MEGACO::mediaGwyIsdnTermFormat> ] [ isdn-suffix1 <MEGACO::mediaGwyIsdnSuffix> ] [ isdn-suffix2
<MEGACO::mediaGwyIsdnSuffix> ] [ no max-transhandling | max-transhandling <MEGACO::mediaGwyTMax>
] [ no max-network-delay | max-network-delay <MEGACO::mediaGwyMaxNetworkDelay> ] [ no max-retrans |
max-retrans <MEGACO::mediaGwyMaxRetrans> ] [ no red-bat-delay | red-bat-delay
<MEGACO::mediaGwyRedBatteryDelay> ] [ no release-delay | release-delay
<MEGACO::mediaGwyReleaseDelay> ] [ no release-type | release-type <MEGACO::mediaGwyReleaseType> ] [
no wt-rls-delay | wt-rls-delay <MEGACO::mediaGwyWaitingReleaseDelay> ] [ no active-heartbeat |
active-heartbeat <MEGACO::mediaGwyHeartBeat> ] [ no passive-heartbeat | passive-heartbeat
<MEGACO::mediaGwyHeartBeat> ] [ no retrans | retrans <MEGACO::mediaGwyRetrans> ] [ no
max-waiting-delay | max-waiting-delay <MEGACO::mediaGwyMaxWaitingDelay> ] [ no prov-rpl-time |
prov-rpl-time <MEGACO::mediaGwyProvResp> ] [ no signal-dscp | signal-dscp
<MEGACO::mediaGatewaySignDscp> ] [ no signal-pbits | signal-pbits <MEGACO::mediaGatewaySignDot1P> ] [
no rtp-dscp | rtp-dscp <MEGACO::mediaGatewayVoiceDscp> ] [ no rtp-pbits | rtp-pbits
<MEGACO::mediaGatewayVoiceDot1P> ] [ no event-req-id | event-req-id <MEGACO::medGwyEventRequestId>
] [ [ no ] stml-stdsg-evt ] [ [ no ] al-of-evt ] [ [ no ] al-on-evt ] [ [ no ] al-of-strict-evt ] [ [ no ] al-on-strict-evt ] [ [ no
] mg-overload-evt ] [ [ no ] mg-dummy-evt ] [ no rfc2833-pl-type | rfc2833-pl-type
<MEGACO::mediaGatewayRfc2833PayloadType> ] [ no rfc2833-process | rfc2833-process
<MEGACO::mediaGatewayRfc2833Process> ] [ no dial-start-timer | dial-start-timer
<MEGACO::mediaGatewayDialStartTimer> ] [ no dial-long-timer | dial-long-timer
<MEGACO::mediaGatewayDialLongTimer> ] [ no dial-short-timer | dial-short-timer
<MEGACO::mediaGatewayDialShortTimer> ] [ no min-data-jitter | min-data-jitter
<MEGACO::mediaGatewayDataJitter> ] [ no init-data-jitter | init-data-jitter
<MEGACO::mediaGatewayDataJitter> ] [ no max-data-jitter | max-data-jitter
<MEGACO::mediaGatewayDataJitter> ] [ no ephe-term-prefix | ephe-term-prefix
<MEGACO::mediaGatewayEpheTermPrefix> ] [ no ephe-term-min | ephe-term-min
<MEGACO::mediaGatewayEpheTerm> ] [ no ephe-term-max | ephe-term-max
<MEGACO::mediaGatewayEpheTerm> ] )

```

Command Parameters

Table 40.46-1 "Voice Megaco Media Gateway Configuration Commands" Resource Parameters

Resource Identifier	Type	Description
(cluster-id)	Format: - the xvps cluster id - range: [1...8,11]	uniquely identify of this xvps cluster
(media-gateway-id)	Format: - the media gateway table index - range: [1]	uniquely identify of this media gateway

Table 40.46-2 "Voice Megaco Media Gateway Configuration Commands" Command Parameters

Parameter	Type	Description
[no] name	Parameter type: <MEGACO::mediaGatewayName> Format: - uniquely name of this media gateway - length: 1<=x<=64	<i>optional parameter with default value: "AG"</i> device name of media gateway, can be modified when mgi is locked, this parameter will be used for mg mid when mg-mid-type select device-name. only '*', '/', '_', '\$', '@', 'ALPHA', 'DIGIT', '-', '.' are valid for device-name.
[no] ip-mode	Parameter type: <MEGACO::voiceIPConfigMode> Format: (dhcp manual) Possible values: - dhcp : The ip mode is dhcp - manual : The ip mode is manual	<i>optional parameter with default value: "manual"</i> the ip mode of this media gateway
[no] dhcption60	Parameter type: <MEGACO::voiceIPDhcpv4Option60> Format: - DHCP option 60 for the DHCP client - length: x<=64	<i>optional parameter with default value: ""</i> the DHCP option 60 for the DHCP client
[no] ip-address	Parameter type: <Ip::V4Address> Format: - IPv4-address	<i>optional parameter with default value: "0.0.0.0"</i> the ip address of this media gateway
[no] netmask	Parameter type: <Ip::V4Address> Format: - IPv4-address	<i>optional parameter with default value: "0.0.0.0"</i> the netmask of this media gateway
[no] udp-port	Parameter type: <MEGACO::mediaGatewayUDPPort> Format: - the udp port of media gateway - range: [1025...65534]	<i>optional parameter with default value: 2944</i> the udp port of mgi
[no] router-ip	Parameter type: <Ip::V4Address> Format: - IPv4-address	<i>optional parameter with default value: "0.0.0.0"</i> the next hop ip address of media gateway
vlan-id	Parameter type: <MEGACO::mediaGatewayVLAN> Format: - the vlan id of media gateway - range: [1...4093]	<i>mandatory parameter</i> the vlan id of this xvps cluster
[no] mgc-type	Parameter type: <MEGACO::mediaGatewayMgcType> Format: (general lucent-fs5000 alcatel-a5020 alcatel-e10 zte-zxss hw-soft3000 siemens nortel ericsson meta-softswitch italtel comverse	<i>optional parameter with default value: "general"</i> the type of media gateway controller

Parameter	Type	Description
	g6-gr303 other-vendor3 other-vendor4 other-vendor16 other-vendor17) Possible values: - general : The type of mgc is general - lucent-fs5000 : The type of mgc is lucent-fs5000 - alcatel-a5020 : The type of mgc is alcatel-a5020 - alcatel-e10 : The type of mgc is alcatel-e10 - zte-zxss : The type of mgc is zte-zxss - hw-soft3000 : The type of mgc is hw-soft3000 - siemens : The type of mgc is siemens - nortel : The type of mgc is nortel - ericsson : The type of mgc is ericsson - meta-softswitch : The type of mgc is meta-softswitch - italtel : The type of mgc is italtel - comverse : The type of mgc is comverse - g6-gr303 : The type of mgc is g6-gr303 - other-vendor3 : The type of mgc is other-vendor3 - other-vendor4 : The type of mgc is other-vendor4 - other-vendor16 : The type of mgc is other-vendor16 - other-vendor17 : The type of mgc is other-vendor17	
prim-mgc-ip	Parameter type: <Ip::V4Address> Format: - IPv4-address	<i>mandatory parameter</i> the ip address of the primary media gateway controller
[no] mgc-id	Parameter type: <MEGACO::medGwyCtrlrCallServerId> Format: - a signed integer	<i>optional parameter with default value: 0</i> the identifier of the peer call server
[no] prim-mgc-udp	Parameter type: <MEGACO::medGwyCtrlrPrimaryUDPPort> Format: - the primary udp port of media gateway controller - range: [1...65534]	<i>optional parameter with default value: 2944</i> the udp port of primary mgc
[no] sec-mgc-ip	Parameter type: <Ip::V4Address> Format: - IPv4-address	<i>optional parameter with default value: "0.0.0.0"</i> the ip address of the secondary media gateway controller
[no] sec-mgc-udp	Parameter type: <MEGACO::medGwyCtrlrSecondaryUDPPort> Format: - the secondary udp port of media gateway controller - range: [1...65534]	<i>optional parameter with default value: 2944</i> the udp port of secondary mgc
[no] tert-mgc-ip	Parameter type: <Ip::V4Address> Format: - IPv4-address	<i>optional parameter with default value: "0.0.0.0"</i> the ip address of the tertiary media gateway controller
[no] tert-mgc-udp	Parameter type: <MEGACO::medGwyCtrlrTertiaryUDPPort> Format: - the tertiary udp port of media gateway controller - range: [1...65534]	<i>optional parameter with default value: 2944</i> the udp port of tertiary mgc
[no] quat-mgc-ip	Parameter type: <Ip::V4Address> Format: - IPv4-address	<i>optional parameter with default value: "0.0.0.0"</i> the ip address of the quaternary media gateway controller

40 Voice Configuration Commands

Parameter	Type	Description
[no] quat-mgc-udp	Parameter <MEGACO::medGwyCtrlrQuaternaryUDPPort> Format: - the quaternary udp port of media gateway controller - range: [1...65534]	type: optional parameter with default value: 2944 the udp port of quaternary mgc
[no] esa-mgc-service	Parameter <MEGACO::mediaGatewayESAMgcService> Format: (enable disable) Possible values: - enable : enable local ESA mgc service - disable : disable local ESA mgc service	type: optional parameter with default value: "disable" the state of local ESA mgc service
[no] mg-mid-type	Parameter type: <MEGACO::mediaGatewayMidType> Format: (ipv4 ipv4-port domain-name domain-name-port device-name) Possible values: - ipv4 : The mg mid type is ipv4 - ipv4-port : The mg mid type is ipv4+port - domain-name : The mg mid type is domain-name - domain-name-port : The mg mid type is domain-name+port - device-name : The mg mid type is device-name	optional parameter with default value: "ipv4-port" the mid type of this media gateway: if ipv4 is selected, the MG ip-address will be used; if ipv4-port is selected, the MG ip-address + udp-port will be used; if domain-name is selected, the mg-domain-name will be used; if domain-name-port is selected, the mg-domain-name + udp-port will be used; if device-name is selected, the mg name will be used for mg mid.
[no] mg-domain-name	Parameter type: <MEGACO::mediaGatewayDomainName> Format: - domain name of this media gateway - length: 1<=x<=255	optional parameter with default value: "isamv.alcatel-lucent.com" the domain name of media gateway, used when mg-addr-type is domain-name or domain-name-port. only 'ALPHA','DIGIT', '-', ' ', '@' are valid for domainName; max length is 255.
[no] svcreason-format	Parameter <MEGACO::mediaGatewaySVCReasonFormat> Format: (with-quotation without-quotation) Possible values: - with-quotation : the mg service change reason format is with-quotation - without-quotation : the mg service change reason format is without-quotation	type: optional parameter with default value: "with-quotation" The format of service change reason, which used in H248 service change.
[no] mg-profile-name	Parameter type: <MEGACO::mediaGatewayProfileName> Format: - profile name of this media gateway - length: 1<=x<=64	optional parameter with default value: "AGW" profile name of this media gateway. which used in h248 message service change. the max number of the string is 64.
[no] admin-status	Parameter type: <MEGACO::mediaGatewayadminStatus> Format: (locked unlocked) Possible values:	optional parameter with default value: "locked" the administrative status of this media gateway

Parameter	Type	Description
	- locked : The admin status is locked - unlocked : The admin status is unlocked	
[no] termid-type	Parameter type: <MEGACO::mediaGwyTermFormat> Format: (hierarchy flat) Possible values: - hierarchy : The termination id format is hierarchy - flat : The termination id format is flat	<i>optional parameter with default value: "flat"</i> termination id format
[no] pstn-term-format	Parameter type: <MEGACO::mediaGwyPstnTermFormat> Format: - the termination id format pattern of pstn user, the termination id format type has two types:flat and hierarchy.Flat type: example AL; AALN;length: [1...10].Hierarchy type: example AL/Dslam_Id/rack/shelf/slot/port (Dslam_Id/rack optional) length: [1...72]. - length: 1<=x<=72	<i>optional parameter with default value: "AL"</i> the termination id format pattern of pstn user
isdn-term-format	Parameter type: <MEGACO::mediaGwyIsdnTermFormat> Format: - the termination id format pattern of isdn user, the termination id format type has two types:flat and hierarchy.Flat type: example BA;length: [1...10]. Hierarchy type: example BA/Dslam_Id/rack/shelf/slot/port/channel(Dslam_Id/rack optional) length:[1...72]. - length: 1<=x<=72	<i>optional parameter</i> the termination id format pattern of isdn user
isdn-suffix1	Parameter type: <MEGACO::mediaGwyIsdnSuffix> Format: - the suffix1 of the isdn user termination format - length: 1<=x<=8	<i>optional parameter</i> the suffix1 of the isdn user termination format
isdn-suffix2	Parameter type: <MEGACO::mediaGwyIsdnSuffix> Format: - the suffix1 of the isdn user termination format - length: 1<=x<=8	<i>optional parameter</i> the suffix2 of the isdn user termination format
[no] max-transhandling	Parameter type: <MEGACO::mediaGwyTMax> Format: - the max time of mgc handling the transaction - range: [1000...30000]	<i>optional parameter with default value: 16000</i> the max time of mgc handling the transaction, the unit is millisecond
[no] max-network-delay	Parameter type: <MEGACO::mediaGwyMaxNetworkDelay> Format: - the max network delay time, the unit is millisecond - range: [100...1000]	<i>optional parameter with default value: 500</i> the max network delay time, the unit is millisecond
[no] max-retrans	Parameter type: <MEGACO::mediaGwyMaxRetrans> Format: - the max retransmit times of the transaction, the unit is times - range: [7...11]	<i>optional parameter with default value: 7</i> the max retransmit times of the transaction
[no] red-bat-delay	Parameter type: <MEGACO::mediaGwyRedBatteryDelay> Format: - the delay before MGI coming into reduced battery state - range: [0...120000]	<i>optional parameter with default value: 70000</i> the delay before mgi coming into reduced battery state
[no] release-delay	Parameter type: <MEGACO::mediaGwyReleaseDelay> Format: - the delay before mgi releasing all sessions	<i>optional parameter with default value: 600000</i> the delay before mgi releasing all

40 Voice Configuration Commands

Parameter	Type	Description
	- unit: millisecond - range: [0...900000]	sessions
[no] release-type	Parameter type: <MEGACO::mediaGwyReleaseType> Format: (normal never) Possible values: - normal : release type is normal - never : release type is never	<i>optional parameter with default value: "normal"</i> the type of releasing the active call
[no] wt-rls-delay	Parameter type: <MEGACO::mediaGwyWaitingReleaseDelay> Format: - the delay after the graceful lock delay timer expired - range: [0...3600000]	<i>optional parameter with default value: 0</i> the delay after the graceful lock delay timer expired
[no] active-heartbeat	Parameter type: <MEGACO::mediaGwyHeartBeat> Format: (fix : <MEGACO::mediaGwyHeartBeatInterval> dynamic) Possible values: - fix : The heart beat mode is fixed - dynamic : The heart beat mode is dynamic Field type <MEGACO::mediaGwyHeartBeatInterval> - the heart beat interval value, if input less than 1s, it will be set to 1s - unit: 10 msec - range: [0...65535]	<i>optional parameter with default value: "fix : 0"</i> the active heart beat mode and interval
[no] passive-heartbeat	Parameter type: <MEGACO::mediaGwyHeartBeat> Format: (fix : <MEGACO::mediaGwyHeartBeatInterval> dynamic) Possible values: - fix : The heart beat mode is fixed - dynamic : The heart beat mode is dynamic Field type <MEGACO::mediaGwyHeartBeatInterval> - the heart beat interval value, if input less than 1s, it will be set to 1s - unit: 10 msec - range: [0...65535]	<i>optional parameter with default value: "dynamic"</i> the passive heart beat mode and interval
[no] retrans	Parameter type: <MEGACO::mediaGwyRetrans> Format: (fix : <MEGACO::mediaGwyRetransInterval> dynamic) Possible values: - fix : The re-transmission mode is fixed - dynamic : The re-transmission mode is dynamic Field type <MEGACO::mediaGwyRetransInterval> - the heart beat interval value - range: [100...4000]	<i>optional parameter with default value: "fix : 4000"</i> the retransmission mode and interval
[no] max-waiting-delay	Parameter type: <MEGACO::mediaGwyMaxWaitingDelay> Format: - max time to wait after a restart before contacting to the call server. - range: [0...120]	<i>optional parameter with default value: 5</i> max time to wait after a restart before contacting to the call server
[no] prov-rpl-time	Parameter type: <MEGACO::mediaGwyProvResp> Format: - the time need to send a transaction pending - range: [0...10000]	<i>optional parameter with default value: 1000</i> the time need to send a transaction pending since the

Parameter	Type	Description
		reception of the transaction
[no] signal-dscp	Parameter type: <MEGACO::mediaGatewaySignDscp> Format: - the signaling dscp of media gateway - range: [0...63]	<i>optional parameter with default value: "0"</i> the signaling dscp of this media gateway
[no] signal-pbits	Parameter type: <MEGACO::mediaGatewaySignDot1P> Format: - the signaling p-bit of media gateway - range: [0...7]	<i>optional parameter with default value: "0"</i> the signaling p-bit of this media gateway
[no] rtp-dscp	Parameter type: <MEGACO::mediaGatewayVoiceDscp> Format: - the voice dscp of media gateway - range: [0...63]	<i>optional parameter with default value: "0"</i> the voice dscp of this media gateway
[no] rtp-pbits	Parameter type: <MEGACO::mediaGatewayVoiceDot1P> Format: - the voice p-bit of media gateway - range: [0...7]	<i>optional parameter with default value: "0"</i> the voice p-bit of this media gateway
[no] event-req-id	Parameter type: <MEGACO::medGwyEventRequestId> Format: - the event request id of this media gateway - range: [0...65535]	<i>optional parameter with default value: 0</i> the event request id of this media gateway
[no] stml-stdsg-evt	Parameter type: boolean	<i>optional parameter</i> permit notify of stimal/stedsig event
[no] al-of-evt	Parameter type: boolean	<i>optional parameter</i> permit notify of al/of event
[no] al-on-evt	Parameter type: boolean	<i>optional parameter</i> permit notify of al/on event
[no] al-of-strict-evt	Parameter type: boolean	<i>optional parameter</i> permit notify of al/of strict=state event
[no] al-on-strict-evt	Parameter type: boolean	<i>optional parameter</i> permit notify of al/on strict=state event
[no] mg-overload-evt	Parameter type: boolean	<i>optional parameter</i> permit notify of ocp/mg_overload event
[no] mg-dummy-evt	Parameter type: boolean	<i>optional parameter</i> dummy parameter for reserved bit
[no] rfc2833-pl-type	Parameter type: <MEGACO::mediaGatewayRfc2833PayloadType> Format: - payload type according to rfc2833 - range: [96...127]	<i>optional parameter with default value: 96</i> payload type according to rfc2833
[no] rfc2833-process	Parameter type: <MEGACO::mediaGatewayRfc2833Process> Format: (audio rfc2833 both) Possible values: - audio : processing procedure is audio - rfc2833 : processing procedure is rfc2833 - both : processing procedure is both	<i>optional parameter with default value: "audio"</i> processing procedure for the dtmf event tones
[no] dial-start-timer	Parameter type: <MEGACO::mediaGatewayDialStartTimer>	<i>optional parameter with default value: 10</i>

40 Voice Configuration Commands

Parameter	Type	Description
	Format: - dialing start timer in second - unit: second - range: [0...99]	maximum waiting time for dialing the first digit
[no] dial-long-timer	Parameter <MEGACO::mediaGatewayDialLongTimer> Format: - dialing start long in second - unit: second - range: [1...60]	type: <i>optional parameter with default value: 20</i> maximum waiting time for dialing when no matching found in the digitmap
[no] dial-short-timer	Parameter <MEGACO::mediaGatewayDialShortTimer> Format: - dialing short timer in second - unit: second - range: [1...60]	type: <i>optional parameter with default value: 5</i> maximum waiting time for dialing when matching found in the digitmap
[no] min-data-jitter	Parameter type: <MEGACO::mediaGatewayDataJitter> Format: - jitter buffer for data calls working in rtp mode - unit: millisecond - range: [0...200]	<i>optional parameter with default value: 50</i> minimum jitter buffer for data calls working in rtp mode
[no] init-data-jitter	Parameter type: <MEGACO::mediaGatewayDataJitter> Format: - jitter buffer for data calls working in rtp mode - unit: millisecond - range: [0...200]	<i>optional parameter with default value: 50</i> initial jitter buffer for data calls working in rtp mode
[no] max-data-jitter	Parameter type: <MEGACO::mediaGatewayDataJitter> Format: - jitter buffer for data calls working in rtp mode - unit: millisecond - range: [0...200]	<i>optional parameter with default value: 50</i> maximum jitter buffer for data calls working in rtp mode
[no] ephe-term-prefix	Parameter <MEGACO::mediaGatewayEpheTermPrefix> Format: - prefix to compose the ephemeral termination id - length: 1<=x<=10	type: <i>optional parameter with default value: "E"</i> prefix to compose the ephemeral termination id
[no] ephe-term-min	Parameter type: <MEGACO::mediaGatewayEpheTerm> Format: - ephemeral termination id - range: [0...4294967295]	<i>optional parameter with default value: 65536</i> minimum ephemeral termination id
[no] ephe-term-max	Parameter type: <MEGACO::mediaGatewayEpheTerm> Format: - ephemeral termination id - range: [0...4294967295]	<i>optional parameter with default value: 72366</i> maximum ephemeral termination id

40.47 Voice Megaco Signal Gateway Configuration Commands

Command Description

This command allows the operator to manage the Voice Megaco signal gateway.

User Level

The command can be accessed by operators with megaco privileges, and executed by operators with megaco privileges.

Command Syntax

The command has the following syntax:

```
> configure voice cluster (cluster-id) ( no signal-gateway (signal-gateway-id) ) | ( signal-gateway
(signal-gateway-id) prim-asp-ip <Ip::V4Address> prim-sctp-port
<MEGACO::signallingGatewayInterfacePrimarySCTPPort> [ no sec-asp-ip | sec-asp-ip <Ip::V4Address> ] [ no
sec-sctp-port | sec-sctp-port <MEGACO::signallingGatewayInterfaceSecondarySCTPPort> ] [ no tert-asp-ip |
tert-asp-ip <Ip::V4Address> ] [ no tert-sctp-port | tert-sctp-port
<MEGACO::signallingGatewayInterfaceTertiarySCTPPort> ] [ no quat-asp-ip | quat-asp-ip <Ip::V4Address> ] [ no
quat-sctp-port | quat-sctp-port <MEGACO::signallingGatewayInterfaceQuaternarySCTPPort> ] ip-address
<Ip::V4Address> sgi-user-label <MEGACO::signallingGatewayInterfaceUserLabel> sgi-mgi
<MEGACO::MediaGatewayId> [ no admin-status | admin-status
<MEGACO::signallingGatewayInterfaceAdminStatus> ] )
```

Command Parameters

Table 40.47-1 "Voice Megaco Signal Gateway Configuration Commands" Resource Parameters

Resource Identifier	Type	Description
(cluster-id)	Format: - the xvps cluster id - range: [1...8,11]	uniquely identify of this xvps cluster
(signal-gateway-id)	Format: - the signal gateway table index - range: [1]	uniquely identify of this signal gateway

Table 40.47-2 "Voice Megaco Signal Gateway Configuration Commands" Command Parameters

Parameter	Type	Description
prim-asp-ip	Parameter type: <Ip::V4Address> Format: - IPv4-address	<i>mandatory parameter</i> the primary asp ip
prim-sctp-port	Parameter type: <MEGACO::signallingGatewayInterfacePrimarySCTPPort> Format: - the sctp port of the primary asp	<i>mandatory parameter</i> the sctp port of the primary asp

Parameter	Type	Description
	- range: [1...65534]	
[no] sec-asp-ip	Parameter type: <Ip::V4Address> Format: - IPv4-address	<i>optional parameter with default value: "0.0.0.0"</i> the secondary asp ip
[no] sec-sctp-port	Parameter type: <MEGACO::signallingGatewayInterfaceSecondarySCTPPort> Format: - the sctp port of the secondary asp - range: [1...65534]	<i>optional parameter with default value: 9900</i> the sctp port of the secondary asp
[no] tert-asp-ip	Parameter type: <Ip::V4Address> Format: - IPv4-address	<i>optional parameter with default value: "0.0.0.0"</i> the tertiary asp ip
[no] tert-sctp-port	Parameter type: <MEGACO::signallingGatewayInterfaceTertiarySCTPPort> Format: - the sctp port of the tertiary asp - range: [1...65534]	<i>optional parameter with default value: 9900</i> the sctp port of the tertiary asp
[no] quat-asp-ip	Parameter type: <Ip::V4Address> Format: - IPv4-address	<i>optional parameter with default value: "0.0.0.0"</i> the quaternary asp ip
[no] quat-sctp-port	Parameter type: <MEGACO::signallingGatewayInterfaceQuaternarySCTPPort> Format: - the sctp port of the quaternary asp - range: [1...65534]	<i>optional parameter with default value: 9900</i> the sctp port of the quaternary asp
ip-address	Parameter type: <Ip::V4Address> Format: - IPv4-address	<i>mandatory parameter</i> <i>The parameter is not visible during modification.</i> the ip address of this signal gateway
sgi-user-label	Parameter type: <MEGACO::signallingGatewayInterfaceUserLabel> Format: - the user label of the signal gateway interface - length: 1<=x<=64	<i>mandatory parameter</i> the user label of the signal gateway interface
sgi-mgi	Parameter type: <MEGACO::MediaGatewayId> Format: - the media gateway table index - range: [1]	<i>mandatory parameter</i> <i>The parameter is not visible during modification.</i> The id of media gateway associated with signal gateway
[no] admin-status	Parameter type: <MEGACO::signallingGatewayInterfaceAdminStatus> Format: (locked unlocked) Possible values: - locked : the admin status of signal gateway is locked - unlocked : the admin status of signal gateway is unlocked	<i>optional parameter with default value: "locked"</i> The administrative status of signal gateway

40.48 Epon Ont Voice SIP UserAgent Configuration

Command Description

This command allows the operator to configure EPON ONT voice sip user agent parameters

User Level

The command can be accessed by operators with sip,megaco privileges, and executed by operators with sip,megaco privileges.

Command Syntax

The command has the following syntax:

```
> configure voice eont ( no sip-useragent (ont-idx) ) | ( sip-useragent (ont-idx) [ no udp-port | udp-port
<Epon::UdpPort> ] proxy-pri-ip <Epon::PxyPrimaryIp> [ no proxy-pri-port | proxy-pri-port
<Epon::PxyPrimaryPort> ] [ proxy-sec-ip <Epon::PxySecondaryIp> ] [ no proxy-sec-port | proxy-sec-port
<Epon::PxySecondaryPort> ] reg-pri-ip <Epon::RegPrimaryIp> [ no reg-pri-port | reg-pri-port
<Epon::RegPrimaryPort> ] [ reg-sec-ip <Epon::RegSecondaryIp> ] [ no reg-sec-port | reg-sec-port
<Epon::RegSecondaryPort> ] [ outbound-ip <Epon::OutboundIp> ] [ no outbound-port | outbound-port
<Epon::OutboundPort> ] [ no reg-intval | reg-intval <Epon::RegInterval> ] [ no heartbeat-mode | heartbeat-mode
<Epon::HeartBeatMode> ] [ no heartbeat-cycle | heartbeat-cycle <Epon::HeartBeatCycle> ] [ no heartbeat-count |
heartbeat-count <Epon::HeartBeatCount> ] digit-map-prof <Epon::DigitMapProfile> )
```

Command Parameters

Table 40.48-1 "Epon Ont Voice SIP UserAgent Configuration" Resource Parameters

Resource Identifier	Type	Description
(ont-idx)	Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Eqpt::OntId> - the ONT identifier	ONT index

Table 40.48-2 "Epon Ont Voice SIP UserAgent Configuration" Command Parameters

Parameter	Type	Description
[no] udp-port	Parameter type: <Epon::UdpPort> Format: - sip udp port number - range: [0...65535]	<i>optional parameter with default value: "5060"</i> signal udp port of sip user agent

40 Voice Configuration Commands

Parameter	Type	Description
proxy-pri-ip	Parameter type: <Epon::PxyPrimaryIp> Format: - IPv4-address	<i>mandatory parameter</i> sip proxy primary ip address
[no] proxy-pri-port	Parameter type: <Epon::PxyPrimaryPort> Format: - sip udp port number - range: [0...65535]	<i>optional parameter with default value: "5060"</i> sip proxy primary udp port
proxy-sec-ip	Parameter type: <Epon::PxySecondaryIp> Format: - IPv4-address	<i>optional parameter</i> sip proxy secondary ip address
[no] proxy-sec-port	Parameter type: <Epon::PxySecondaryPort> Format: - sip udp port number - range: [0...65535]	<i>optional parameter with default value: "5060"</i> sip proxy secondary udp port
reg-pri-ip	Parameter type: <Epon::RegPrimaryIp> Format: - IPv4-address	<i>mandatory parameter</i> sip register server primary ip address
[no] reg-pri-port	Parameter type: <Epon::RegPrimaryPort> Format: - sip udp port number - range: [0...65535]	<i>optional parameter with default value: "5060"</i> sip register primary udp port
reg-sec-ip	Parameter type: <Epon::RegSecondaryIp> Format: - IPv4-address	<i>optional parameter</i> sip register server secondary ip address
[no] reg-sec-port	Parameter type: <Epon::RegSecondaryPort> Format: - sip udp port number - range: [0...65535]	<i>optional parameter with default value: "5060"</i> sip register secondary udp port
outbound-ip	Parameter type: <Epon::OutboundIp> Format: - IPv4-address	<i>optional parameter</i> sip out bound proxy ip address
[no] outbound-port	Parameter type: <Epon::OutboundPort> Format: - sip udp port number - range: [0...65535]	<i>optional parameter with default value: "5060"</i> sip out bound proxy udp port
[no] reg-intval	Parameter type: <Epon::RegInterval> Format: - reg refresh period - range: [0...4294967295]	<i>optional parameter with default value: "3600"</i> registering refresh period
[no] heartbeat-mode	Parameter type: <Epon::HeartBeatMode> Format: (enable disable) Possible values: - enable : enable heart beat mode - disable : disable heart beat mode	<i>optional parameter with default value: "enable"</i> heart beat mode
[no] heartbeat-cycle	Parameter type: <Epon::HeartBeatCycle> Format: - heartbeat count - range: [0...65535]	<i>optional parameter with default value: "60"</i> heart beat cycle
[no] heartbeat-count	Parameter type: <Epon::HeartBeatCount> Format: - heartbeat count - range: [0...65535]	<i>optional parameter with default value: "3"</i> heart beat times
digit-map-prof	Parameter type: <Epon::DigitMapProfile> Format: - digitmap profile id	<i>mandatory parameter</i> digitmap profile id

Parameter	Type	Description
	- range: [1...32]	

40.49 Epon Ont Pots Configuration Command

Command Description

This command configures provisioning data associated with an ONT Pots Port.

User Level

The command can be accessed by operators with sip,megaco privileges, and executed by operators with sip,megaco privileges.

Command Syntax

The command has the following syntax:

```
> configure voice eont ( no pots (uni-idx) ) | ( pots (uni-idx) [ [ no ] admin-up ] [ no user-account | user-account
<Epon::UserAcc> ] [ no user-name | user-name <Epon::UserName> ] [ no user-pwd | user-pwd <Epon::UserPwd> ]
[ tid-name <Epon::TidName> ] )
```

Command Parameters

Table 40.49-1 "Epon Ont Pots Configuration Command" Resource Parameters

Resource Identifier	Type	Description
(uni-idx)	Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Epon::EontSlot> / <Epon::EontPort> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Eqpt::OntId> - the ONT identifier Field type <Epon::EontSlot> - Epon Ont Slot - range: [1...16] Field type <Epon::EontPort> - Epon Ont Port - range: [1...64]	ONT UNI interface

Table 40.49-2 "Epon Ont Pots Configuration Command" Command Parameters

Parameter	Type	Description
[no] admin-up	Parameter type: boolean	<i>optional parameter</i> admin status is up (read-only for voicefxs interface)

Parameter	Type	Description
[no] user-account	Parameter type: <Epon::UserAcc> Format: - sip user account - length: x<=16	<i>optional parameter with default value: ""</i> sip user account
[no] user-name	Parameter type: <Epon::UserName> Format: - user name - length: 1<=x<=32	<i>optional parameter with default value: ""</i> sip user name
[no] user-pwd	Parameter type: <Epon::UserPwd> Format: - sip user password hidden from users - length: x<=16	<i>optional parameter with default value: ""</i> sip user password
tid-name	Parameter type: <Epon::TidName> Format: - tid name - length: 1<=x<=32	<i>optional parameter</i> h248 tid name

40.50 Epon Ont Voice Common Configuration Command

Command Description

This command configures EPON ONT voice common parameters.

ip /mask /gateway - If ip-mode is not static IP, this parameter has no meaning. When ip-mode is static, this parameter should be configured.

svlan - If tag- mode is not stack, this parameter has no meaning.

User Level

The command can be accessed by operators with sip,megaco privileges, and executed by operators with sip,megaco privileges.

Command Syntax

The command has the following syntax:

```
> configure voice eont ( no comm-para (ont-idx) ) | ( comm-para (ont-idx) [ no ip-mode | ip-mode <Epon::IpMode>
] [ ip <Epon::IpAddr> ] [ mask <Epon::IpAddr> ] [ gateway <Epon::IpAddr> ] [ no pppoe-mode | pppoe-mode
<Epon::pppoeMode> ] [ no pppoe-username | pppoe-username <Epon::pppoeUsrName> ] [ no pppoe-pwd |
pppoe-pwd <Epon::pppoePwd> ] [ no tagged-mode | tagged-mode <Epon::TagMode> ] cvlan <Epon::cvlan> [ no
svlan | svlan <Epon::svlan> ] [ no pbit | pbit <Epon::pbit> ] [ no t38-admin | t38-admin <Epon::faxMode> ] [ no fax
| fax <Epon::ctrlMode> ] )
```

Command Parameters

Table 40.50-1 "Epon Ont Voice Common Configuration Command" Resource Parameters

Resource Identifier	Type	Description
(ont-idx)	Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Eqpt::OntId> - the ONT identifier	Ont Index

Table 40.50-2 "Epon Ont Voice Common Configuration Command" Command Parameters

Parameter	Type	Description
[no] ip-mode	Parameter type: <Epon::IpMode> Format: (static dhcp pppoe) Possible values: - static : static mode - dhcp : dhcp mode - pppoe : PPPoE mode	<i>optional parameter with default value: "static"</i> mode to get the voice ip address
ip	Parameter type: <Epon::IpAddr> Format: - IPv4-address	<i>optional parameter</i> static voice ip address
mask	Parameter type: <Epon::IpAddr> Format: - IPv4-address	<i>optional parameter</i> subnet of the voice ip
gateway	Parameter type: <Epon::IpAddr> Format: - IPv4-address	<i>optional parameter</i> default gateway of the voice ip
[no] pppoe-mode	Parameter type: <Epon::pppoeMode> Format: (auto chap pap) Possible values: - auto : AUTO mode - chap : CHAP mode - pap : PAP mode	<i>optional parameter with default value: "auto"</i> PPPoE configure mode
[no] pppoe-username	Parameter type: <Epon::pppoeUsrName> Format: - user name - length: 1<=x<=32	<i>optional parameter with default value: ""</i> PPPoE user name
[no] pppoe-pwd	Parameter type: <Epon::pppoePwd> Format: - PPPoE password hidden from users - length: 1<=x<=32	<i>optional parameter with default value: ""</i> PPPoE password
[no] tagged-mode	Parameter type: <Epon::TagMode> Format: (transparent tag stacking) Possible values: - transparent : transparent mode - tag : tagged mode - stacking : stacking mode	<i>optional parameter with default value: "tag"</i> vlan tag mode
cvlan	Parameter type: <Epon::cvlan> Format: - Vlan id - range: [0...4093]	<i>mandatory parameter</i> customer vlan for voice
[no] svlan	Parameter type: <Epon::svlan> Format: - Vlan id - range: [2...4093,0]	<i>optional parameter with default value: 0L</i> Service vlan for voice
[no] pbit	Parameter type: <Epon::pbit> Format: - DBA polling level - range: [0...7]	<i>optional parameter with default value: 5L</i> dot1p of voice flow
[no] t38-admin	Parameter type: <Epon::faxMode>	<i>optional parameter with default</i>

40 Voice Configuration Commands

Parameter	Type	Description
	Format: (t30 t38) Possible values: - t30 : t30 mode - t38 : t38 mode	<i>value: "t30"</i> choose fax mode
[no] fax	Parameter type: <Epon::ctrlMode> Format: (negotiation autovbd) Possible values: - negotiation : Negotiation mode - autovbd : auto VBD mode	<i>optional parameter with default value: "negotiation"</i> fax or modem control mode

40.51 Epon Ont Voice media gateway Configuration Command

Command Description

This command configures EPON ONT voice media gateway parameters.

gw-id - Identifier of media gateway. It is only valid if reg-mode is domain or equip.

tid-digit-len - tid digit length. Tid digit length + prefix length should be less than or equal to 32

User Level

The command can be accessed by operators with sip,megaco privileges, and executed by operators with sip,megaco privileges.

Command Syntax

The command has the following syntax:

```
> configure voice eont ( no media-gateway (ont-idx) ) | ( media-gateway (ont-idx) [ no udp-port | udp-port
<Epon::udp> ] mgc-pri-ip <Epon::IpAddr> [ no mgc-pri-port | mgc-pri-port <Epon::udp> ] [ no mgc-sec-ip |
mgc-sec-ip <Epon::IpAddr> ] [ no mgc-sec-port | mgc-sec-port <Epon::udp> ] [ no reg-mode | reg-mode
<Epon::regMode> ] [ gw-id <Epon::gwid> ] [ no heartbeat-mode | heartbeat-mode <Epon::HBMode> ] [ no
heartbeat-cycle | heartbeat-cycle <Epon::HBCycle> ] [ no heartbeat-count | heartbeat-count <Epon::HBVal> ]
tid-num <Epon::TidNum> tid-prefix <Epon::TidPrefix> tid-digit-begin <Epon::TidDigit> tid-mode
<Epon::TidMode> tid-digit-len <Epon::TidLen> )
```

Command Parameters

Table 40.51-1 "Epon Ont Voice media gateway Configuration Command" Resource Parameters

Resource Identifier	Type	Description
(ont-idx)	Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Eqpt::OntId> - the ONT identifier	Ont Index

Table 40.51-2 "Epon Ont Voice media gateway Configuration Command" Command Parameters

40 Voice Configuration Commands

Parameter	Type	Description
[no] udp-port	Parameter type: <Epon::udp> Format: - DBA polling interval per pon interface - range: [0...65535]	<i>optional parameter with default value: 2944</i> signal udp port of media gateway
mgc-pri-ip	Parameter type: <Epon::IpAddr> Format: - IPv4-address	<i>mandatory parameter</i> primary ip address of MGC
[no] mgc-pri-port	Parameter type: <Epon::udp> Format: - DBA polling interval per pon interface - range: [0...65535]	<i>optional parameter with default value: 2944</i> udp port of the primary MGC
[no] mgc-sec-ip	Parameter type: <Epon::IpAddr> Format: - IPv4-address	<i>optional parameter with default value: "0.0.0.0"</i> secondary ip address of MGC
[no] mgc-sec-port	Parameter type: <Epon::udp> Format: - DBA polling interval per pon interface - range: [0...65535]	<i>optional parameter with default value: 2944</i> udp port of the secondary MGC
[no] reg-mode	Parameter type: <Epon::regMode> Format: (ip domain equip) Possible values: - ip : - domain : - equip :	<i>optional parameter with default value: "ip"</i> register mode of media gateway
gw-id	Parameter type: <Epon::gwid> Format: - media gateway identifier - length: x<=64	<i>optional parameter</i> corresponding ID for a given Media Gw
[no] heartbeat-mode	Parameter type: <Epon::HBMode> Format: (enabled disabled) Possible values: - enabled : heartbeat function enabled - disabled : heartbeat function disabled	<i>optional parameter with default value: "enabled"</i> link checking mode
[no] heartbeat-cycle	Parameter type: <Epon::HBCycle> Format: - Heart Beat cycle - unit: secs - range: [0...65535]	<i>optional parameter with default value: 60L</i> heart beat cycle
[no] heartbeat-count	Parameter type: <Epon::HBVal> Format: - DBA polling interval per pon interface - range: [0...65535]	<i>optional parameter with default value: 3L</i> The heart beat times
tid-num	Parameter type: <Epon::TidNum> Format: - Number of rtp tid - range: [0...255]	<i>mandatory parameter</i> Number of rtp tid
tid-prefix	Parameter type: <Epon::TidPrefix> Format: - an octet string defining mnemonic of EPON - length: 1<=x<=16	<i>mandatory parameter</i> prefix of rtp tid
tid-digit-begin	Parameter type: <Epon::TidDigit> Format:	<i>mandatory parameter</i> begin number of tid digit

Parameter	Type	Description
	- DBA polling interval per pon interface - range: [0...65535]	
tid-mode	Parameter type: <Epon::TidMode> Format: (inline notinline) Possible values: - inline : - notinline :	<i>mandatory parameter</i> tid digit line up mode
tid-digit-len	Parameter type: <Epon::TidLen> Format: - - range: [1...31]	<i>mandatory parameter</i> tid digit length

40.52 Voice Sip LSA Server Configuration Commands

Command Description

This command allows the operator to manage the Voice Sip LSA Server profile.

User Level

The command can be accessed by operators with sip privileges, and executed by operators with sip privileges.

Command Syntax

The command has the following syntax:

```
> configure voice lsa-server ( no system (name) ) | ( system (name) slot-id <LSA::SlotIndex> country-code
<LSA::CountryCode> area-code <LSA::AreaCode> [ no admin-status | admin-status <LSA::SystemAdminStatus>
])
```

Command Parameters

Table 40.52-1 "Voice Sip LSA Server Configuration Commands" Resource Parameters

Resource Identifier	Type	Description
(name)	Format: - uniquely identify this LSA server system - length: 1<=x<=32	uniquely identify this voice LSA server system

Table 40.52-2 "Voice Sip LSA Server Configuration Commands" Command Parameters

Parameter	Type	Description
slot-id	Parameter type: <LSA::SlotIndex> Format: (lt : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> nt <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::EqSlotId> vvps-a) Possible values: - lt : 7302/7330/7360 ISAM FTTN : slot id of the NVPS-C board at which LSA server is hosted - nt : 7363 MX : slot id of NT board - vvps-a : 7302/7330/7360: slot id of the VVPS-A at which the LSA server is hosted Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number	<i>mandatory parameter</i> 7302/7330/7360 ISAM FTTN : slot-id of the physical NVPS-C board while LSA server is hosted at physical NVPS-C board; slot id of the VVPS-A if LSA server is hosted at VVPS-A board (only applicable on NANT-E/FANT-F). 7363 MX : slot id of NT board

Parameter	Type	Description
	Field type <Eqpt::EqSlotId> - the equipment slot number	
country-code	Parameter type: <LSA::CountryCode> Format: - country code of the LSA server system - length: 1<=x<=32	<i>mandatory parameter</i> country code used by this LSA server to complete the DN received in an incoming sip invite request
area-code	Parameter type: <LSA::AreaCode> Format: - area code of the LSA server system - length: 1<=x<=32	<i>mandatory parameter</i> area code used by this LSA server to complete the DN received in an incoming sip invite request
[no] admin-status	Parameter type: <LSA::SystemAdminStatus> Format: (up down) Possible values: - up : unlock the LSA server system - down : lock the LSA server system	<i>optional parameter with default value: "down"</i> administrative status of the LSA server

40.53 Voice Sip LSA Server Configuration Commands

Command Description

This command allows the operator to manage the Voice Sip LSA Server profile.

User Level

The command can be accessed by operators with sip privileges, and executed by operators with sip privileges.

Command Syntax

The command has the following syntax:

```
> configure voice lsa-server ( no instance (name) ) | ( instance (name) slot-id <LSA::SlotIndex> sign-ip
<LSA::IpAddressAndMask> [ no sign-port | sign-port <LSA::InstanceSignPort> ] sign-vlan
<LSA::InstanceSignVlan> [ no sign-gw-ip | sign-gw-ip <LSA::IpAddress> ] [ no admin-status | admin-status
<LSA::InstanceAdminStatus> ] [ no sg-name | sg-name <LSA::InstanceSGDomName> ] [ no lsa-md5-realm |
lsa-md5-realm <LSA::MD5Realm> ] [ no lsa-md5-password | lsa-md5-password <Security::Password4> ] )
```

Command Parameters

Table 40.53-1 "Voice Sip LSA Server Configuration Commands" Resource Parameters

Resource Identifier	Type	Description
(name)	Format: - uniquely identify this LSA server instance - length: 1<=x<=32	uniquely identify this LSA server instance

Table 40.53-2 "Voice Sip LSA Server Configuration Commands" Command Parameters

Parameter	Type	Description
slot-id	Parameter type: <LSA::SlotIndex> Format: (lt : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> nt <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::EqSlotId> vvps-a) Possible values: - lt : 7302/7330/7360 ISAM FTTN : slot id of the NVPS-C board at which LSA server is hosted - nt : 7363 MX : slot id of NT board - vvps-a : 7302/7330/7360: slot id of the VVPS-A at which the LSA server is hosted Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number	<i>mandatory parameter</i> 7302/7330/7360 ISAM FTTN : slot-id of the physical NVPS-C board while LSA server is hosted at physical NVPS-C board; slot id of the VVPS-A if LSA server is hosted at VVPS-A board (only applicable on NANT-E/FANT-F). 7363 MX : slot id of the NT board

Parameter	Type	Description
	Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::EqSlotId> - the equipment slot number	
sign-ip	Parameter type: <LSA::IpAddressAndMask> Format: ipv4 : <Ip::V4Address> / <LSA::PrefixLength> Possible values: - ipv4 : the address type of the LSA server instance is ipv4 Field type <Ip::V4Address> - IPv4-address Field type <LSA::PrefixLength> - prefix length of the subnet - range: [0...32]	<i>mandatory parameter</i> signaling IP address + prefix length used by this LSA server instance
[no] sign-port	Parameter type: <LSA::InstanceSignPort> Format: - the SIP LSA server Instance port - range: [1...65534]	<i>optional parameter with default value: 5060</i> signaling port used by this LSA server instance
sign-vlan	Parameter type: <LSA::InstanceSignVlan> Format: - vlan id of LSA server instance - range: [1...4093]	<i>mandatory parameter</i> signaling vlan ID used by this LSA server instance
[no] sign-gw-ip	Parameter type: <LSA::IpAddress> Format: - IPv4-address	<i>optional parameter with default value: "0.0.0.0"</i> default signaling gateway IP address used by this LSA server instance
[no] admin-status	Parameter type: <LSA::InstanceAdminStatus> Format: (up down) Possible values: - up : unlock the LSA server instance - down : lock the LSA server instance	<i>optional parameter with default value: "down"</i> administrative status of this LSA server instance
[no] sg-name	Parameter type: <LSA::InstanceSGDomName> Format: - uniquely name of this element - length: x<=32	<i>optional parameter with default value: "vsp1"</i> name of the service gateway associated with this LSA server instance
[no] lsa-md5-realm	Parameter type: <LSA::MD5Realm> Format: - the string for MD5 - length: x<=64	<i>optional parameter with default value: ""</i> realm used by this LSA server instance to authenticate an incoming SIP register request
[no] lsa-md5-password	Parameter type: <Security::Password4> Format: (prompt plain : <Security::PlainPassword4>) Possible values: - prompt : prompts the operator for a password - plain : the password in plain text, may contain any printable character defined by the US-ASCII character set and that has a decimal code in the range 33 to 126, and the length should be less than or equal to 64 (Due to legacy reasons, the MD5 character string was included in the parameter name. Nevertheless, despite the MD5 string in the name of this object, from R5.8.x it is to be considered as a	<i>optional parameter with default value: "plain : "</i> password used by this LSA server instance to authenticate an incoming SIP register request

40 Voice Configuration Commands

Parameter	Type	Description
	common configuration object for all authentication types that might require the configuration of an authentication password.) Field type <Security::PlainPassword4> - the password, may contain any printable character defined by the US-ASCII character set and that has a decimal code in the range 33 to 126, and the length should be less than or equal to 64 (Due to legacy reasons, the MD5 character string was included in the parameter name. Nevertheless, despite the MD5 string in the name of this object, from R5.8.x it is to be considered as a common configuration object for all authentication types that might require the configuration of an authentication password.) - length: x<=64	

40.54 Voice Sip LSA Server Emergency Service Configuration Commands

Command Description

This command allows the operator to manage the Voice Sip LSA Server Emergency Service profile.

User Level

The command can be accessed by operators with sip privileges, and executed by operators with sip privileges.

Command Syntax

The command has the following syntax:

```
> configure voice lsa-server ( no emergency-service dn <LSA::Dn> gateway-dn <LSA::GtwyDn> ) | (
emergency-service dn <LSA::Dn> gateway-dn <LSA::GtwyDn> slot-id <LSA::SlotIndex> [ no name | name
<LSA::EmergServiceName> ] [ no sg-name | sg-name <LSA::EmergVsgName> ] [ no gateway-ddidn |
gateway-ddidn <LSA::GtwyDDIDn> ] [ no gateway-dn-type | gateway-dn-type <LSA::GtwyDnType> ] )
```

Command Parameters

Table 40.54-1 "Voice Sip LSA Server Emergency Service Configuration Commands" Resource Parameters

Resource Identifier	Type	Description
dn	Parameter type: <LSA::Dn> Format: - emergency service directory number - length: 1<=x<=8	emergency service directory number
gateway-dn	Parameter type: <LSA::GtwyDn> Format: - directory number only includes the subscriber number to which the emergency call is to be addressed. - length: 1<=x<=32	directory number only includes the subscriber number to which the emergency call is to be addressed

Table 40.54-2 "Voice Sip LSA Server Emergency Service Configuration Commands" Command Parameters

Parameter	Type	Description
slot-id	Parameter type: <LSA::SlotIndex> Format: (lt : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> nt <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::EqSlotId> vvps-a) Possible values: - lt : 7302/7330/7360 ISAM FTTN : slot id of the NVPS-C board at which LSA server is hosted	<i>mandatory parameter</i> 7302/7330/7360 ISAM FTTN : slot-id of the physical NVPS-C board while LSA server is hosted at physical NVPS-C board; slot id of the VVPS-A if LSA server is hosted at VVPS-A board (only applicable on NANT-E/FANT-F). 7363 MX :

40 Voice Configuration Commands

Parameter	Type	Description
	- nt : 7363 MX : slot id of NT board - vvps-a : 7302/7330/7360: slot id of the VVPS-A at which the LSA server is hosted - Field type <Eqpt::RackId> - the rack number - Field type <Eqpt::ShelfId> - the shelf number - Field type <Eqpt::SlotId> - the LT slot number - Field type <Eqpt::EqSlotId> - the equipment slot number	slot id of NT board
[no] name	Parameter type: <LSA::EmergServiceName> Format: - the name of LSA emergency service - length: x<=32	<i>optional parameter with default value: ""</i> name of this LSA emergency service
[no] sg-name	Parameter type: <LSA::EmergVsgName> Format: - uniquely name of this element - length: x<=32	<i>optional parameter with default value: "vsp1"</i> name of the Voice SERVICE GATEWAY associated with this LSA emergency service
[no] gateway-ddidn	Parameter type: <LSA::GtwyDDIDn> Format: - the ISDN DDI number which the emergency call is to be addressed. - length: x<=32	<i>optional parameter with default value: ""</i> the ISDN DDI number which the emergency call is to be addressed
[no] gateway-dn-type	Parameter type: <LSA::GtwyDnType> Format: (pots isdn-pra) Possible values: - pots : the gateway-dn is a POTS number. - isdn-pra : the gateway-dn is an ISDN PRA number	<i>optional parameter with default value: "pots"</i> the type of the gateway-dn

40.55 Voice extline Configuration Commands

Command Description

This command allows the operator to manage the Voice extline profile.

User Level

The command can be accessed by operators with all privileges, and executed by operators with all privileges.

Command Syntax

The command has the following syntax:

```
> configure voice ( no extline (if-index) ) | ( extline (if-index) local-ip <ExtLine::IpAddressAndMask> [ no
gateway-ip | gateway-ip <ExtLine::ExtLineIpAddr> ] [ no ip-addr-policy | ip-addr-policy <ExtLine::IpAddrPolicy>
] vlan-id <ExtLine::ExtLineVlanId> fxo-ip <ExtLine::FxoIpAddr> fxo-port <ExtLine::ExtLinePort> [ no
admin-status | admin-status <ExtLine::ExtLineAdminStatus> ] [ no codec | codec <ExtLine::ExtLineCodec> ] [ no
ptime | ptime <ExtLine::ExtLinePtime> ] [ no echo-cancel | echo-cancel <ExtLine::ExtLineEc> ] [ no silence-suppr
| silence-suppr <ExtLine::ExtLineSilence> ] [ no impedance | impedance <ExtLine::ExtLineImpedance> ] [ no
rx-gain | rx-gain <ExtLine::ExtLineRxGain> ] [ no tx-gain | tx-gain <ExtLine::ExtLineTxGain> ] [ no dscp | dscp
<ExtLine::ExtLineDscp> ] [ no pbits | pbits <ExtLine::ExtLinePbits> ] )
```

Command Parameters

Table 40.55-1 "Voice extline Configuration Commands" Resource Parameters

Resource Identifier	Type	Description
(if-index)	Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number	The unique internal identifier of the extension line port

Table 40.55-2 "Voice extline Configuration Commands" Command Parameters

Parameter	Type	Description
local-ip	Parameter type: <ExtLine::IpAddressAndMask> Format: <Ip::V4Address> / <ExtLine::PrefixLength> Field type <Ip::V4Address> - IPv4-address Field type <ExtLine::PrefixLength> - prefix length of the subnet - range: [0...32]	<i>mandatory parameter</i> identify the IP address of this extension line

40 Voice Configuration Commands

Parameter	Type	Description
[no] gateway-ip	Parameter type: <ExtLine::ExtLineIpAddr> Format: - IPv4-address	<i>optional parameter with default value: "0.0.0.0"</i> IP address of the gateway, must be set when manual mode and ip-address-policy is distributed, otherwise it is optional
[no] ip-addr-policy	Parameter type: <ExtLine::IpAddrPolicy> Format: (distributed centralized) Possible values: - distributed : the ip address policy of the user agent operation is to use an IP address per Voice LT, not applicable for NGVR and ANSI MDU - centralized : the ip address policy of the user agent operation is to use a single IP address for the ISAM Voice, NGVR and ANSI MDU	<i>optional parameter with default value: "distributed"</i> The ip address policy of the extension line
vlan-id	Parameter type: <ExtLine::ExtLineVlanId> Format: - vlan id - range: [1...4093]	<i>mandatory parameter</i> vlan id for rtp packet
fxo-ip	Parameter type: <ExtLine::FxoIpAddr> Format: - IPv4-address	<i>mandatory parameter</i> identify the IP address of this fxo
fxo-port	Parameter type: <ExtLine::ExtLinePort> Format: - the extension line local port - range: [1...65534]	<i>mandatory parameter</i> port of the fxo
[no] admin-status	Parameter type: <ExtLine::ExtLineAdminStatus> Format: (up down) Possible values: - up : the status of the user agent operation is up - down : the status of the user agent operation is down	<i>optional parameter with default value: "down"</i> identify the status of this line administration
[no] codec	Parameter type: <ExtLine::ExtLineCodec> Format: (g711-a-law g711-u-law g723 g729) Possible values: - g711-a-law : the extension line codec is g711-a-law - g711-u-law : the extension line codec is g711-u-law - g723 : the extension line codec is g723 - g729 : the extension line codec is g729	<i>optional parameter with default value: "g711-a-law"</i> configure the line codec of this extension line
[no] ptime	Parameter type: <ExtLine::ExtLinePtime> Format: - value of the extension line package time - unit: milliseconds - range: [10...60]	<i>optional parameter with default value: "20"</i> configure the line ptime of this extension line,ptime accepts values only in multiples of 10.if codec is configuread as g723,the ptime accepts only 30 and 60.if codec is configuread as g711-a-law,g711-u-law,g729,the ptime can accept:10,20,30,40,50,60

Parameter	Type	Description
[no] echo-cancel	Parameter type: <ExtLine::ExtLineEc> Format: (on off) Possible values: - on : the extension line echo canceller is on - off : the extension line echo canceller is off	<i>optional parameter with default value: "off"</i> configure the line EC of this extension line
[no] silence-suppr	Parameter type: <ExtLine::ExtLineSilence> Format: (on off) Possible values: - on : the extension line echo canceller is on - off : the extension line echo canceller is off	<i>optional parameter with default value: "on"</i> configure the line silence support of this extension line
[no] impedance	Parameter type: <ExtLine::ExtLineImpedance> Format: (cdeprofile 200 220 220minisplitter 270 300 370 600 900 370minisplitter 600splitter 370nvlsasplitter 370skinnysplitter 270duratelsplitter 2703msplitter 100 150 220splitter reserv19 reserv20 reserv21) Possible values: - cdeprofile : the impedance is default value - 200 : the line impedance is 200 ohm - 220 : the line impedance is 220 ohm - 220minisplitter : the line impedance is 220 ohm+ miniSplitter - 270 : the line impedance is 270 ohm - 300 : the line impedance is 300 ohm - 370 : the line impedance is 370 ohm - 600 : the line impedance is 600 ohm - 900 : the line impedance is 900 ohm - 370minisplitter : the line impedance is 370 ohm+ miniSplitter - 600splitter : the line impedance is 600 ohm+splitter - 370nvlsasplitter : the line impedance is 370 ohm+ NVLSASplitter - 370skinnysplitter : the line impedance is 370 ohm+ SkinnySplitter - 270duratelsplitter : the line impedance is 270 ohm+ DuratelSplitter	<i>optional parameter with default value: "cdeprofile"</i> configure the line impedance of this extension line

40 Voice Configuration Commands

Parameter	Type	Description
	- 270msplitter : the line impedance is 270 ohm+ 3MDsplitter - 100 : the line impedance is 100 ohm - 150 : the line impedance is 150 ohm - 220splitter : the line impedance is 220 ohm+ splitter - reserv19 : reserved for future use 19 - reserv20 : reserved for future use 20 - reserv21 : reserved for future use 21	
[no] rx-gain	Parameter type: <ExtLine::ExtLineRxGain> Format: - the line rx_gain range -14...6 - range: [-14...6]	<i>optional parameter with default value: "0"</i> configure the line rx_gain of this extension line
[no] tx-gain	Parameter type: <ExtLine::ExtLineTxGain> Format: - the line tx_gain range -14...6 - range: [-14...6]	<i>optional parameter with default value: "0"</i> configure the line tx_gain of this extension line
[no] dscp	Parameter type: <ExtLine::ExtLineDscp> Format: - dscp mark for rtp or rtcp packets - range: [0...63]	<i>optional parameter with default value: 46</i> dscp mark for extension line packets
[no] pbits	Parameter type: <ExtLine::ExtLinePbits> Format: - the dot-1p bit value - range: [0...7]	<i>optional parameter with default value: 6</i> 802.1p bits for extension line packets.

40.56 Voice Pseudo Wire Configuration Commands

Command Description

This command allows the operator to manage the Voice pseudo wire profile.

User Level

The command can be accessed by operators with all privileges, and executed by operators with all privileges.

Command Syntax

The command has the following syntax:

```
> configure voice ( no pseudo-wire (if-index) ) | ( pseudo-wire (if-index) channelset <PwEncapTdm::ChannelSet> [
no ip-addr-policy | ip-addr-policy <PwEncapTdm::IpAddrPolicy> ] local-ip <PwEncapTdm::IpAddressAndMask>
dest-ip <PwEncapTdm::IpAddress> dest-udp-port <PwEncapTdm::UDPPort> [ no gateway-ip | gateway-ip
<PwEncapTdm::IpAddress> ] vlan-id <PwEncapTdm::VlanId> [ no p-bits | p-bits <PwEncapTdm::Pbits> ] [ no
dscp | dscp <PwEncapTdm::Dscp> ] [ no admin-status | admin-status <PwEncapTdm::AdminStatus> ] [ no
data-jitter | data-jitter <PwEncapTdm::DataJitter> ] p-time <PwEncapTdm::PacketInterval> [ no payload-type |
payload-type <PwEncapTdm::PayloadType> ] )
```

Command Parameters

Table 40.56-1 "Voice Pseudo Wire Configuration Commands" Resource Parameters

Resource Identifier	Type	Description
(if-index)	Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number	The unique internal identifier of the pseudo wire port

Table 40.56-2 "Voice Pseudo Wire Configuration Commands" Command Parameters

Parameter	Type	Description
channelset	Parameter type: <PwEncapTdm::ChannelSet> Format: - channels for pseudo wire - length: 1<=x<=31	<i>mandatory parameter</i> assign channels for pseudo wire. master DS0 Channel must appear as the first one in the DS0 channel list. Total pseudo wire DS0 should be less than 193 on every NIAT-A pack
[no] ip-addr-policy	Parameter type: <PwEncapTdm::IpAddrPolicy> Format:	<i>optional parameter with default value: "pw-distinct-ip-mode"</i>

Parameter	Type	Description
	(pw-distinct-ip-mode pw-shared-ip-mode) Possible values: - pw-distinct-ip-mode : the ip address policy of the pseudo wire, operation is to use an IP address per NIAT-A board - pw-shared-ip-mode : the ip address policy of the pseudo wire, operation is to use a single IP address for the PW traffic	The ip address policy of the pseudo wire
local-ip	Parameter type: <PwEncapTdm::IpAddressAndMask> Format: <Ip::V4Address> / <PwEncapTdm::PrefixLength> Field type <Ip::V4Address> - IPv4-address Field type <PwEncapTdm::PrefixLength> - prefix length of the subnet - range: [0...32]	<i>mandatory parameter</i> identify the IP address and prefix length of this pseudo wire
dest-ip	Parameter type: <PwEncapTdm::IpAddress> Format: - IPv4-address	<i>mandatory parameter</i> the destination IP address of this pseudo wire
dest-udp-port	Parameter type: <PwEncapTdm::UDPPort> Format: - the udp port of pseudo wire - range: [1...65535]	<i>mandatory parameter</i> the destination udp port of pseudo wire
[no] gateway-ip	Parameter type: <PwEncapTdm::IpAddress> Format: - IPv4-address	<i>optional parameter with default value: "0.0.0.0"</i> IP address of the gateway, must be set when manual mode and ip-address-policy is pw-distinct-ip-mode, otherwise it is optional
vlan-id	Parameter type: <PwEncapTdm::VlanId> Format: - vlan id - range: [1...4093]	<i>mandatory parameter</i> vlan id for pseudo wire packet
[no] p-bits	Parameter type: <PwEncapTdm::Pbits> Format: - the dot-1p bit value - range: [0...7]	<i>optional parameter with default value: 6</i> 802.1p bits for pseudo wire packets
[no] dscp	Parameter type: <PwEncapTdm::Dscp> Format: - dscp mark for rtp or rtcp packets - range: [0...63]	<i>optional parameter with default value: 46</i> dscp mark for pseudo wire packets
[no] admin-status	Parameter type: <PwEncapTdm::AdminStatus> Format: (up down) Possible values: - up : unlock the pseudo wire - down : lock the pseudo wire	<i>optional parameter with default value: "down"</i> identify the status of this pseudo wire administration
[no] data-jitter	Parameter type: <PwEncapTdm::DataJitter> Format: - jitter buffer for PW channel in millisecond - unit: millisecond - range: [0...200]	<i>optional parameter with default value: 50</i> data jitter buffer for pseudo wire.\nwhen p-time = 1, the range is [0...100]
p-time	Parameter type: <PwEncapTdm::PacketInterval> Format: - packetization interval for pseudo wire in millisecond	<i>mandatory parameter</i> packetization interval for pseudo wire packets.\nThe valid value is

Parameter	Type	Description
	- unit: millisecond - range: [1...10]	linked with the number of DS0(N) by the following relationship: $N * p\text{-time} \leq 31$. The package size is $8 * N * \text{packetization interval}$
[no] payload-type	Parameter type: <PwEncapTdm::PayloadType> Format: - payload type for pseudo wire packets - range: [96...127]	<i>optional parameter with default value: 96</i> payload type for pseudo wire packets

41- Voice Ont Configuration Commands

41.1 Voice Ont Configuration Command Tree	41-1362
41.2 Voice ONT Service Configuration Command	41-1369
41.3 Performance Monitoring configuration command for VOIP service	41-1374
41.4 Voice ONT POTS Configuration Command	41-1376
41.5 Voice ONT Voice-Port Configuration Command	41-1380
41.6 GPON Authentication Security Profile Configuration Command	41-1384
41.7 Voice ONT Secure URI profile Configuration command	41-1386
41.8 GPON URI Profile Configuration Command	41-1388
41.9 GPON Tone Pattern Profile Configuration Command	41-1389
41.10 GPON Tone Pattern Sequence Profile Configuration Command	41-1391
41.11 Tone Event Profile Configuration Command	41-1395
41.12 GPON Busy Tone Event Profile Configuration Command	41-1396
41.13 GPON First Call Wait Tone Event Profile Configuration Command	41-1398
41.14 GPON Second Call Wait Tone Event Profile Configuration Command	41-1400
41.15 GPON Third Call Wait Tone Event Profile Configuration Command	41-1402
41.16 GPON Fourth Call Wait Tone Event Profile Configuration Command	41-1404
41.17 GPON Alert Tone Event Profile Configuration Command	41-1406
41.18 GPON Special Dial Tone Event Profile Configuration Command	41-1408
41.19 GPON Special Info Tone Event Profile Configuration Command	41-1410
41.20 GPON Release Tone Event Profile Configuration Command	41-1412
41.21 GPON Congest Tone Event Profile Configuration Command	41-1414
41.22 GPON Confirm Tone Event Profile Configuration Command	41-1416
41.23 GPON Dial Tone Event Profile Configuration Command	41-1418
41.24 GPON Message Wait Tone Event Profile Configuration Command	41-1420
41.25 GPON Reorder Tone Event Profile Configuration Command	41-1422
41.26 GPON Ring Back Tone Event Profile Configuration Command	41-1424
41.27 GPON Roh Tone Event Profile Configuration Command	41-1426
41.28 GPON Stutter Tone Event Profile Configuration Command	41-1428
41.29 GPON Intrusion Tone Event Profile Configuration	41-1430

Command	
41.30 GPON Dead Tone Event Profile Configuration	41-1432
Command	
41.31 GPON First User Defined Tone Event Profile	41-1434
Configuration Command	
41.32 GPON Second User Defined Tone Event Profile	41-1436
Configuration Command	
41.33 GPON Third User Defined Tone Event Profile	41-1438
Configuration Command	
41.34 GPON Fourth User Defined Tone Event Profile	41-1440
Configuration Command	
41.35 GPON Network Dial Plan Profile Configuration	41-1442
Command	
41.36 Create a RTP profile	41-1444
41.37 Create a Voice Service profile	41-1446
41.38 Create a VOIP Application Service Profile	41-1449
41.39 Create a VOIP media profile	41-1454
41.40 GPON Ringing Pattern Profile Configuration	41-1460
Command	
41.41 GPON Ringing Pattern Sequence Profile	41-1462
Configuration Command	
41.42 GPON Ring Event Profile Configuration Command	41-1465
41.43 GPON VOIP Feature Access Codes Profile	41-1468
Configuration Command	
41.44 GPON Common VOIP Configuration Command	41-1471
41.45 GPON Voice ONT POTS Rtp PM Mode Configuration	41-1473
Command	
41.46 GPON ONT SIP Configuration Command	41-1475
41.47 Voice Ont SIP Agent PM Mode Configuration	41-1479
Command	
41.48 Voice Ont SIP Agent Call PM Mode Configuration	41-1481
Command	
41.49 Configure ont POT SIP	41-1483
41.50 Voice ONT MGC Configuration command	41-1487
41.51 Voice ONT MGC PM monitoring command	41-1491
41.52 Voice Ont Pots Call PM Mode Configuration	41-1493
Command	

41.1 Voice Ont Configuration Command Tree

Description

This chapter gives an overview of nodes that are handled by "Voice Ont Configuration Commands".

Command Tree

```
----configure
  ----voice
    ----ont
      ----[no] service
        - (voip-index)
        - [no] label
        - [no] ip-address
        - [no] net-mask
        - [no] default-router
        - [no] mgc-ip-addr
        - [no] sec-mgc-ip-addr
        - [no] ftp-serv-ip-addr
        - [no] dhcp
        - [no] mgc-udp-port
        - [no] voip-dscp
        - [no] voip-mode
        - conf-file-name
        - [no] client-id
        - [no] secret-id
        - [no] secret-k
        - [no] ipsec-enable
        - [no] conf-method
        - [no] spg-prof
        - [no] spg-user-name
        - [no] spg-passwd
        - [no] spg-realm
        - [no] ftp-user-name
        - [no] ftp-passwd
        - vlan
        - [no] admin-state
        - [no] uncond-omci-dnld
      ----tc-layer
        - [no] pm-collect
    ----pots
      - (uni-idx)
      - [no] custinfo
      - [no] voip-serv
      - [no] termination-id
      - [no] pots-pwr-timer
      - [no] call-hist
      - [no] pwr-override
      - [no] sip-msg-tot-th
      - [no] brr-pkt-loss-th
      - [no] excess-jitter-th
      - [no] rx-gain
```

- [no] tx-gain
- [no] pots-dscp
- [no] veip-ptr
- [no] admin-state
- [no] transmit-path
- [no] nominal-feed-vol
- voice-port**
 - **(uni-idx)**
 - [no] custinfo
 - [no] voipconfig
 - [no] pots-pwr-timer
 - [no] call-hist
 - [no] pwr-override
 - [no] rx-gain
 - [no] tx-gain
 - [no] impedance
 - [no] voip-media-prof
 - [no] ne-file-name
 - [no] admin-state
- [no] auth-sec-prof**
 - **(index)**
 - name
 - [no] validation-scheme
 - [no] user-name
 - [no] password
 - [no] realm
- [no] sec-uri-profile**
 - **(index)**
 - name
 - [no] auth-securi-prof
 - uri-prof
- [no] uri-prof**
 - **(index)**
 - name
 - [no] address
 - [no] version
- [no] tone-seg-profile**
 - **(index)**
 - name
 - freq1
 - power1
 - freq2
 - power2
 - freq3
 - power3
 - freq4
 - power4
 - modulation-freq
 - modulation-power
 - duration
- [no] tone-seq-profile**
 - **(index)**
 - name
 - pattern-prof1
 - [no] pattern-prof2
 - [no] pattern-prof3
 - [no] pattern-prof4
 - [no] pattern-prof5
 - [no] pattern-prof6

- [no] pattern-prof7
- [no] pattern-prof8
- [no] **tone-event-prof**
- (index)
- name
- busy-tone**
 - [no] tone-seq-prof
 - [no] file-prof
 - [no] repeat
- callwait1-tone**
 - [no] tone-seq-prof
 - [no] file-prof
 - [no] repeat
- callwait2-tone**
 - [no] tone-seq-prof
 - [no] file-prof
 - [no] repeat
- callwait3-tone**
 - [no] tone-seq-prof
 - [no] file-prof
 - [no] repeat
- callwait4-tone**
 - [no] tone-seq-prof
 - [no] file-prof
 - [no] repeat
- alert-tone**
 - [no] tone-seq-prof
 - [no] file-prof
 - [no] repeat
- special-dial-tone**
 - [no] tone-seq-prof
 - [no] file-prof
 - [no] repeat
- special-info-tone**
 - [no] tone-seq-prof
 - [no] file-prof
 - [no] repeat
- release-tone**
 - [no] tone-seq-prof
 - [no] file-prof
 - [no] repeat
- congest-tone**
 - [no] tone-seq-prof
 - [no] file-prof
 - [no] repeat
- confirm-tone**
 - [no] tone-seq-prof
 - [no] file-prof
 - [no] repeat
- dial-tone**
 - [no] tone-seq-prof
 - [no] file-prof
 - [no] repeat
- msg-wait-tone**
 - [no] tone-seq-prof
 - [no] file-prof
 - [no] repeat
- reorder-tone**
 - [no] tone-seq-prof

```

- [no] file-prof
- [no] repeat
----ringback-tone
- [no] tone-seq-prof
- [no] file-prof
- [no] repeat
----roh-tone
- [no] tone-seq-prof
- [no] file-prof
- [no] repeat
----stutter-tone
- [no] tone-seq-prof
- [no] file-prof
- [no] repeat
----intrusion-tone
- [no] tone-seq-prof
- [no] file-prof
- [no] repeat
----dead-tone
- [no] tone-seq-prof
- [no] file-prof
- [no] repeat
----userdef1-tone
- [no] tone-seq-prof
- [no] file-prof
- [no] repeat
----userdef2-tone
- [no] tone-seq-prof
- [no] file-prof
- [no] repeat
----userdef3-tone
- [no] tone-seq-prof
- [no] file-prof
- [no] repeat
----userdef4-tone
- [no] tone-seq-prof
- [no] file-prof
- [no] repeat
----[no] nwdial-plan-prof
- (index)
- name
- [no] critical-timeout
- [no] partial-timeout
- [no] format
- digitmap1
- digitmap2
- digitmap3
- digitmap4
----[no] rtp-profile
- (index)
- name
- [no] local-port-min
- [no] local-port-max
- [no] dscp
- [no] piggy-back-event
- [no] tone-event
- [no] dtmf-event
- [no] cas-event
----[no] voice-serv-prof

```

- (index)

- name
- [no] securi-prof
- [no] toneset-prof
- [no] ringingset-prof
- [no] announce-type
- [no] jitter-target
- [no] jitter-max
- [no] echo-cancel
- [no] dtmf-level
- [no] dtmf-duration
- [no] hook-flash-min
- [no] hook-flash-max
- [no] pstn-variant

----[no] voip-app-service

- (index)

- name
- [no] calling-number
- [no] calling-name
- [no] caller-id-block
- [no] caller-id-number
- [no] caller-id-name
- [no] anonymous-block
- [no] call-waiting
- [no] callerid-announce
- [no] three-way-calling
- [no] call-transfer
- [no] call-hold
- [no] call-park
- [no] do-not-disturb
- [no] flash-on-emerg-cal
- [no] emerg-ser-org-hold
- [no] six-way-calling
- [no] mwi-splash-ring
- [no] mwi-spl-dialtone
- [no] mwi-visual-indi
- [no] call-fwd-indicate
- [no] dir-conn-feature
- [no] dialtone-dely-opt
- [no] dir-conn-prof
- [no] bridge-prof
- [no] conf-prof

----[no] voip-media-prof

- (index)

- name
- [no] voiceserviceprof
- [no] rtp-prof
- [no] fax-mode
- [no] codec1st
- [no] pkt-period1st
- [no] silence1st
- [no] codec2nd
- [no] pkt-period2nd
- [no] silence2nd
- [no] codec3rd
- [no] pkt-period3rd
- [no] silence3rd
- [no] codec4th

- [no] pkt-period4th
- [no] silence4th
- [no] outofband-dtmf
- [no] ring-seg-prof
 - (index)
 - name
 - [no] profile-ring
 - ring-duration
- [no] ring-seq-prof
 - (index)
 - name
 - pattern1
 - [no] pattern2
 - [no] pattern3
 - [no] pattern4
 - [no] pattern5
- [no] ringing-profile
 - (index)
 - name
 - [no] ringing-seq-prof
 - [no] ringing-file-prof
 - [no] ringing-repeat
 - [no] splash-seq-prof
 - [no] splash-file-prof
 - [no] splash-repeat
- [no] feat-acccode-prof
 - (index)
 - name
 - [no] cancel-call-wait
 - [no] hold
 - [no] park
 - [no] act-caller-id
 - [no] deact-caller-id
 - [no] act-dnd
 - [no] deact-dnd
 - [no] dnd-pin
 - [no] emergency
 - [no] intercom
 - [no] attend-call-trans
 - [no] blind-call-trans
- [no] voip-config
 - (voip-index)
 - protocol
 - [no] conf-method
 - [no] securi-prof
- pots-rtp
 - (uni-index)
 - [no] pm-collect
- [no] sip-config
 - (sip-index)
 - [no] proxy-serv-prof
 - [no] outproxy-serv-prof
 - [no] primary-dns
 - [no] secondary-dns
 - [no] reg-expire-time
 - [no] re-reg-head-start
 - [no] aor-host-prt-prof
 - [no] registrar-prof
 - [no] soft-sw-vendor

- [no] opt-tx-cntrl
- [no] uri-format
- [no] dscp
- [no] udp-port
- sip-agent**
 - **(ont-index)**
 - [no] pm-collect
- sip-call**
 - **(ont-index)**
 - [no] pm-collect
- voice-sip-port**
 - **(pots-index)**
 - [no] user-aor
 - [no] display-name
 - [no] val-scheme
 - [no] user-name
 - [no] password
 - [no] realm
 - [no] voice-mail-prof
 - [no] voice-mail-to
 - [no] ntwk-dp-prof
 - [no] app-serv-prof
 - [no] ac-code-prof
 - [no] rlstimer
 - [no] rohtimer
- [no] mgc-config**
 - **(if-index)**
 - pri-mgcuri-profid
 - sec-mgcuri-profid
 - [no] protocol-ver
 - [no] msg-format
 - [no] max-retry-time
 - [no] max-retries
 - [no] status-delay-time
 - base-termid
 - [no] sig-dscp
 - [no] udp-port
 - [no] sw-vendor
 - [no] cnf-msg-profid
- mgc-agent**
 - **(voip-index)**
 - [no] pm-collect
- pots-call**
 - **(uni-idx)**
 - [no] pm-collect

41.2 Voice ONT Service Configuration Command

Command Description

This command is to configure the service related parameters for ONT.

NOTE: OLT prohibits the entry of the following range of well-known IP addresses:

224.0.0.0 to 239.255.255.255 (multicast)

127.0.0.0 to 127.255.255.255 (loopback)

User Level

The command can be accessed by operators with sip, megaco privileges, and executed by operators with sip, megaco privileges.

Command Syntax

The command has the following syntax:

```
> configure voice ont ( no service (voip-index) ) | ( service (voip-index) [ no label | label <Gpon::Label> ] [ no ip-address | ip-address <Gpon::Ipaddr> ] [ no net-mask | net-mask <Gpon::Ipaddr> ] [ no default-router | default-router <Gpon::Ipaddr> ] [ no mgc-ip-addr | mgc-ip-addr <Gpon::Ipaddr> ] [ no sec-mgc-ip-addr | sec-mgc-ip-addr <Gpon::Ipaddr> ] [ no ftp-serv-ip-addr | ftp-serv-ip-addr <Gpon::Ipaddr> ] [ no dhcp | dhcp <Gpon::Dhcp> ] [ no mgc-udp-port | mgc-udp-port <Gpon::PortSignalling> ] [ no voip-dscp | voip-dscp <Gpon::DscpSetting> ] [ no voip-mode | voip-mode <Gpon::GWMode> ] conf-file-name <Gpon::ConfName> [ no client-id | client-id <Gpon::ClientID> ] [ no secret-id | secret-id <Gpon::SecretID> ] [ no secret-k | secret-k <Gpon::SecretK> ] [ no ipsec-enable | ipsec-enable <Gpon::IpSec> ] [ no conf-method | conf-method <Gpon::SrvConfMethod> ] [ no spg-prof | spg-prof <Gpon::UriProfileName> ] [ no spg-user-name | spg-user-name <Gpon::SippingAuthUserName> ] [ no spg-passwd | spg-passwd <Gpon::AuthPasswd> ] [ no spg-realm | spg-realm <Gpon::Realm> ] [ no ftp-user-name | ftp-user-name <Gpon::FtpAuth> ] [ no ftp-passwd | ftp-passwd <Security::Password5> ] vlan <Vlan::Index> [ no admin-state | admin-state <Gpon::AdminState> ] [ [ no ] uncond-omci-dnld ] )
```

Command Parameters

Table 41.2-1 "Voice ONT Service Configuration Command" Resource Parameters

Resource Identifier	Type	Description
(voip-index)	Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / 1 ng2 : <Ng2::ChannelGroup> / <Ng2::SubchannelGroup> / <Ng2::OntId> / 1) Possible values: - ng2 : ngpon2 style identification Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number	a unique interface index

Resource Identifier	Type	Description
	Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Eqpt::OntId> - the ONT identifier Possible values: - 1 : Gpon voip Port Field type <Ng2::ChannelGroup> - channel group number Field type <Ng2::SubchannelGroup> - subchannel group number Field type <Ng2::OntId> - the ONT identifier Possible values: - 1 : Gpon voip Port	

Table 41.2-2 "Voice ONT Service Configuration Command" Command Parameters

Parameter	Type	Description
[no] label	Parameter type: <Gpon::Label> Format: - char string - length: x<=80	<i>optional parameter with default value: ""</i> label used to identify service
[no] ip-address	Parameter type: <Gpon::Ipaddr> Format: - IPv4-address	<i>optional parameter with default value: "0.0.0.0"</i> <i>The parameter is not visible during modification.</i> ip Address of the ONT VoIP Client
[no] net-mask	Parameter type: <Gpon::Ipaddr> Format: - IPv4-address	<i>optional parameter with default value: "0.0.0.0"</i> <i>The parameter is not visible during modification.</i> subnet mask for the VoIP client's subnet
[no] default-router	Parameter type: <Gpon::Ipaddr> Format: - IPv4-address	<i>optional parameter with default value: "0.0.0.0"</i> <i>The parameter is not visible during modification.</i> default next hop IP Address used by the VoIP Client
[no] mgc-ip-addr	Parameter type: <Gpon::Ipaddr> Format: - IPv4-address	<i>optional parameter with default value: "0.0.0.0"</i> <i>The parameter is not visible during modification.</i> IP Address of the Network Media Gateway
[no] sec-mgc-ip-addr	Parameter type: <Gpon::Ipaddr> Format: - IPv4-address	<i>optional parameter with default value: "0.0.0.0"</i> <i>The parameter is not visible during modification.</i> IP Address of the secondary Network Media Gateway
[no] ftp-serv-ip-addr	Parameter type: <Gpon::Ipaddr> Format: - IPv4-address	<i>optional parameter with default value: "0.0.0.0"</i> <i>The parameter is not visible during modification.</i>

Parameter	Type	Description
		IP Address of the FTP Server that contains the VoIP configuration files that the ONT needs to download
[no] dhcp	Parameter type: <Gpon::Dhcp> Format: (enabled disabled) Possible values: - enabled : DHCP is enabled - disabled : DHCP is disabled	<i>optional parameter with default value: "disabled"</i> The parameter is not visible during modification. designate whether DHCP is enabled
[no] mgc-udp-port	Parameter type: <Gpon::PortSignalling> Format: - TCP or UDP port used for signalling (L2 only) - range: [0...65535]	<i>optional parameter with default value: 2944L</i> The parameter is not visible during modification. UDP port of the Media Gateway Controller used for signaling
[no] voip-dscp	Parameter type: <Gpon::DscpSetting> Format: - to set the DSCP value that the Voip Client will use - range: [0...63]	<i>optional parameter with default value: 24L</i> The parameter is not visible during modification. to set the DSCP value that the Voip Client will use
[no] voip-mode	Parameter type: <Gpon::GWMode> Format: (gr303-h248 v5.x-h248 softswitch-h248 sip1 sip2) Possible values: - gr303-h248 : GR303-H248 - v5.x-h248 : V5.x-H248 - softswitch-h248 : Softswitch-H248 - sip1 : Mode 1 SIP - sip2 : Mode 2 SIP	<i>optional parameter with default value: "sip1"</i> The parameter is not visible during modification. Used to set Voice Gateway signalling mode.
conf-file-name	Parameter type: <Gpon::ConfName> Format: - name of the Planned Configuration File that the VoIP Client must use for VoIP configuration. - length: x<=49	<i>mandatory parameter</i> name of the Planned Configuration File that the VoIP Client must use for VoIP configuration.
[no] client-id	Parameter type: <Gpon::ClientID> Format: - to uniquely identify the VoIP Client. - length: x<=25	<i>optional parameter with default value: ""</i> DHCP option 61 clientid associated with the VoIP service.
[no] secret-id	Parameter type: <Gpon::SecretID> Format: - DHCP Option 90 Secret ID for VoIP Service. Up to 8 hexadecimal characters (example 01:02:03:04). - length: x<=4	<i>optional parameter with default value: ""</i> The parameter is not visible during modification. DHCP Option 90 Secret ID for VoIP Service. Up to 8 hexadecimal characters.
[no] secret-k	Parameter type: <Gpon::SecretK> Format: - DHCP Option 90 Secret-K for VoIP Service. Up to 32 hexadecimal characters (example 01:02:03:04:05:06:07:08:09:10:11:12:13:14:15:16).	<i>optional parameter with default value: ""</i> The parameter is not visible during modification. DHCP Option 90 Secret-K for

41 Voice Ont Configuration Commands

Parameter	Type	Description
	- length: x<=16	VoIP Service. Up to 32 hexadecimal characters.
[no] ipsec-enable	Parameter type: <Gpon::IpSec> Format: (enabled disabled) Possible values: - enabled : IPSEC is enabled - disabled : IPSEC is disabled	<i>optional parameter with default value: "disabled"</i> The parameter is not visible during modification. Used to designate whether IPSEC is enabled or disabled.
[no] conf-method	Parameter type: <Gpon::SrvConfMethod> Format: (ftp sipping omci) Possible values: - ftp : FTP Server - sipping : Sipping Server, editing to and from sipping is not allowed - omci : Omci ftp	<i>optional parameter with default value: "ftp"</i> Used to determine the primary method the ONT uses to obtain VoIP configuration information.
[no] spg-prof	Parameter type: <Gpon::UriProfileName> Format: (none <Gpon:UriProfilePtr> name : <AsamProfileName>) Possible values: - none : no profile to associate - name : profile name Field type <Gpon:UriProfilePtr> - Index of the URI profile that contains the IP address of the server - range: [0...100] Data driven field type Possible values are depending on the actual configuration and software. The currently allowed values can be shown with online-help.	<i>optional parameter with default value: ""</i> URI profile that contains the address for acquiring the SIPPING Server.
[no] spg-user-name	Parameter type: <Gpon::SippingAuthUserName> Format: - user name required for sipping authentication - length: x<=25	<i>optional parameter with default value: ""</i> Username required for authentication with the SIPPING Server OR for PPPoE authentication.
[no] spg-passwd	Parameter type: <Gpon::AuthPasswd> Format: - password required for authentication - length: x<=25	<i>optional parameter with default value: ""</i> Password required for authentication with the SIPPING Server OR for PPPoE authentication.
[no] spg-realm	Parameter type: <Gpon::Realm> Format: - realm required for authentication - length: x<=25	<i>optional parameter with default value: ""</i> Realm for authentication with the SIPPING Server OR for the PPPoE access concentrator name.
[no] ftp-user-name	Parameter type: <Gpon::FtpAuth> Format: - authentication string - length: x<=25	<i>optional parameter with default value: ""</i> the Username required for authentication with the FTP Server.

Parameter	Type	Description
[no] ftp-passwd	Parameter type: <Security::Password5> Format: (prompt plain : <Security::PlainPassword5>) Possible values: - prompt : prompts the operator for a password - plain : the password in plain text Field type <Security::PlainPassword5> - authentication string - length: x<=25	<i>optional parameter with default value: "plain : "</i> password required for authentication with the FTP Server.
vlan	Parameter type: <Vlan::Index> Format: (<Vlan::UVlanIndex> stacked : <Vlan::SVlanIndexStacked> : <Vlan::CVlanIndex>) Possible values: - stacked : stacked vlan identity Field type <Vlan::UVlanIndex> - unstacked vlan identity - range: [1...4093,4096] Field type <Vlan::SVlanIndexStacked> - service vlan identity - range: [1...4093] Field type <Vlan::CVlanIndex> - customer vlan identity - range: [0...4093]	<i>mandatory parameter</i> <i>The parameter is not visible during modification.</i> vlan id
[no] admin-state	Parameter type: <Gpon::AdminState> Format: (locked unlocked) Possible values: - locked : Setting it to 'locked' causes OLT to block upstream traffic on this service - unlocked : Setting it to 'unlocked' causes OLT to allow upstream traffic on this service	<i>optional parameter with default value: "unlocked"</i> Setting it to 'locked' causes OLT to block upstream traffic on this service
[no] uncond-omci-dnld	Parameter type: boolean	<i>optional parameter</i> <i>The parameter is not visible during creation.</i> download Voip XML unconditionally

41.3 Performance Monitoring configuration command for VOIP service

Command Description

configures the PM Mode of ONT-side TC-layer counters.

User Level

The command can be accessed by operators with sip,megaco privileges, and executed by operators with sip,megaco privileges.

Command Syntax

The command has the following syntax:

```
> configure voice ont service (voip-index) tc-layer [ no pm-collect | pm-collect <Gpon::PmEnable> ]
```

Command Parameters

Table 41.3-1 "Performance Monitoring configuration command for VOIP service" Resource Parameters

Resource Identifier	Type	Description
(voip-index)	Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / 1 ng2 : <Ng2::ChannelGroup> / <Ng2::SubchannelGroup> / <Ng2::OntId> / 1) Possible values: - ng2 : ngpon2 style identification Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Eqpt::OntId> - the ONT identifier Possible values: - 1 : Gpon voip Port Field type <Ng2::ChannelGroup> - channel group number Field type <Ng2::SubchannelGroup> - subchannel group number Field type <Ng2::OntId>	a unique interface index

Resource Identifier	Type	Description
	- the ONT identifier Possible values: - 1 : Gpon voip Port	

Table 41.3-2 "Performance Monitoring configuration command for VOIP service" Command Parameters

Parameter	Type	Description
[no] pm-collect	Parameter type: <Gpon::PmEnable> Format: (disable enable) Possible values: - disable : disable the collection - enable : enable the collection	<i>optional parameter with default value: "disable"</i> indicates whether tc layer counter Performance Monitors should be collected for this VOIP Service

41.4 Voice ONT POTS Configuration Command

Command Description

This command allows the operator to configure pots specific data associated with an ont.

Parameter Termination ID is a case insensitive string up to 25 characters long. Only the following characters are allowed:

['a'..'z', 'A'..'Z', '0'..'9', '*', '/', '-', '_', '\$', '@', or ' '].

The first character must be alphabetic. The string 'ROOT' is not allowed.

User Level

The command can be accessed by operators with sip, megaco privileges, and executed by operators with sip, megaco privileges.

Command Syntax

The command has the following syntax:

```
> configure voice ont pots (uni-idx) [ no custinfo | custinfo <Gpon::CustInfo> ] [ no voip-serv | voip-serv
<Gpon::VoipSrvIndex> ] [ no termination-id | termination-id <Gpon::TerminationId> ] [ no pots-pwr-timer |
pots-pwr-timer <Gpon::PotsPwrTimer> ] [ no call-hist | call-hist <Gpon::CallHist> ] [ no pwr-override |
pwr-override <Gpon::PotsPwrShedOverride> ] [ no sip-msg-tot-th | sip-msg-tot-th
<Gpon::SipMsgTimeOutThreshold> ] [ no brr-pkt-loss-th | brr-pkt-loss-th <Gpon::BrrPktLossThreshold> ] [ no
excess-jitter-th | excess-jitter-th <Gpon::ExcessJitterThreshold> ] [ no rx-gain | rx-gain <Gpon::RxGain> ] [ no
tx-gain | tx-gain <Gpon::TxGain> ] [ no pots-dscp | pots-dscp <Gpon::PotsDscpSetting> ] [ no veip-ptr | veip-ptr
<Gpon::OntSpIndexOrZero> ] [ no admin-state | admin-state <Gpon::PotsAdminState> ] [ no transmit-path |
transmit-path <Gpon::Transmission> ] [ no nominal-feed-vol | nominal-feed-vol <Gpon::NominalFeedVoltage> ]
```

Command Parameters

Table 41.4-1 "Voice ONT POTS Configuration Command" Resource Parameters

Resource Identifier	Type	Description
(uni-idx)	Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Gpon::OntSlotId> / <Gpon::OntPotsPortId> ng2 : <Ng2::ChannelGroup> / <Ng2::SubchannelGroup> / <Ng2::OntId> / <Gpon::OntSlotId> / <Gpon::OntPotsPortId>) Possible values: - ng2 : ngpon2 style identification Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number	interface index of the pots uni

Resource Identifier	Type	Description
	Field type <Eqpt::PonId> - the PON identifier Field type <Eqpt::OntId> - the ONT identifier Field type <Ng2::ChannelGroup> - channel group number Field type <Ng2::SubchannelGroup> - subchannel group number Field type <Ng2::OntId> - the ONT identifier Field type <Gpon::OntSlotId> - Gpon Ont Slot - range: [1...14] Field type <Gpon::OntPotsPortId> - Gpon Ont Pots Port - range: [1...24]	

Table 41.4-2 "Voice ONT POTS Configuration Command" Command Parameters

Parameter	Type	Description
[no] custinfo	Parameter type: <Gpon::CustInfo> Format: - a printable string - length: x<=80	<i>optional parameter with default value: ""</i> information about pots port
[no] voip-serv	Parameter type: <Gpon::VoipSrvIndex> Format: - service number of the voip client service - range: [1]	<i>optional parameter with default value: "1"</i> service number of the voip client service
[no] termination-id	Parameter type: <Gpon::TerminationId> Format: - identifies the POTS port in H248 VoIP signalling messages. The first character must be alphabetic. The string 'ROOT' is not allowed. - range: [a-zA-Z0-9*/-_\$.@.] - length: x<=25	<i>optional parameter with default value: ""</i> identifies the POTS port in H248 VoIP signalling messages
[no] pots-pwr-timer	Parameter type: <Gpon::PotsPwrTimer> Format: - time during which pots loop voltage is held up - range: [0...65535]	<i>optional parameter with default value: "0"</i> time during which pots loop voltage is held up
[no] call-hist	Parameter type: <Gpon::CallHist> Format: (enable disable) Possible values: - enable : enable PM collection - disable : disable PM collection	<i>optional parameter with default value: "disable"</i> indicates whether or not a call history to be maintained for this line.
[no] pwr-override	Parameter type: <Gpon::PotsPwrShedOverride> Format: (true false) Possible values: - true : port excluded from voice class power shedding - false : port included in voice class power shedding	<i>optional parameter with default value: "false"</i> voice class power shedding
[no] sip-msg-tot-th	Parameter type: <Gpon::SipMsgTimeOutThreshold> Format: - threshold for raising the SIP message timeout tca alarm - range: [0...65535]	<i>optional parameter with default value: "0"</i> threshold for raising the SIP message timeout tca alarm
[no] brr-pkt-loss-th	Parameter type: <Gpon::BrrPktLossThreshold>	<i>optional parameter with default</i>

41 Voice Ont Configuration Commands

Parameter	Type	Description
	Format: - threshold for raising the bearer packet loss tca alarm - unit: 1/256ths - range: [0...255]	<i>value: "0"</i> threshold for raising the bearer packet loss tca alarm
[no] excess-jitter-th	Parameter type: <Gpon::ExcessJitterThreshold> Format: - threshold for raising the jitter tca alarm in milliseconds - unit: milliseconds - range: [0...65535]	<i>optional parameter with default value: "0"</i> excessive jitter threshold in milliseconds
[no] rx-gain	Parameter type: <Gpon::RxGain> Format: - gain value for the received signal in 0.1db increments - unit: db - range: [-12...6]	<i>optional parameter with default value: 0</i> gain value for the received signal in 0.1db increments
[no] tx-gain	Parameter type: <Gpon::TxGain> Format: - gain value for the transmit signal in 0.1db increments - unit: db - range: [-12...6]	<i>optional parameter with default value: 0</i> gain value for the transmit signal in 0.1db increments
[no] pots-dscp	Parameter type: <Gpon::PotsDscpSetting> Format: - dscp value for use in outgoing voip bearer packets (L3 only) - range: [0...63]	<i>optional parameter with default value: 46</i> dscp value for use in outgoing voip bearer packets
[no] veip-ptr	Parameter type: <Gpon::OntSpIndexOrZero> Format: (<Gpon::OntSlotId2> / <Gpon::OntPortId2> none) Possible values: - none : default value Field type <Gpon::OntSlotId2> - Gpon Ont Slot - range: [0...14] Field type <Gpon::OntPortId2> - Gpon Ont Port - range: [0...16]	<i>optional parameter with default value: "none"</i> interface index of the veip uni
[no] admin-state	Parameter type: <Gpon::PotsAdminState> Format: (unlocked locked) Possible values: - unlocked : activates the pots port - locked : deactivates the pots port	<i>optional parameter with default value: "locked"</i> administrative state of ptp pots uni
[no] transmit-path	Parameter type: <Gpon::Transmission> Format: (full-time part-time not-supported) Possible values: - full-time : full-time on-hook transmission - part-time : part-time on-hook transmission - not-supported : do not care and do not send any OMCI	<i>optional parameter with default value: "not-supported"</i> allows setting the POTS UNI either to full-time onhook transmission
[no] nominal-feed-vol	Parameter type: <Gpon::NominalFeedVoltage> Format: (not-supported <Gpon::NominalFeedVoltage>) Possible values:	<i>optional parameter with default value: "not-supported"</i> indicates the designed nominal feed voltage of the POTS loop

Parameter	Type	Description
	- not-supported : do not care and do not send any OMCI - Field type <Gpon::NominalFeedVoltage> - indicates the designed nominal feed voltage of the POTS loop - unit: Volts - range: [1...255,65535]	

Command Output

Table 41.4-3 "Voice ONT POTS Configuration Command" Display parameters

Specific Information		
name	Type	Description
oper-state	Parameter type: <Gpon::PotsOperState> (enabled disabled unknown) Possible values: - enabled : enable the service - disabled : disable the service - unknown : unknown state	operational state of the service <i>This element is always shown.</i>

41.5 Voice ONT Voice-Port Configuration Command

Command Description

This command allows the operator to configure the voice port specific data associated with an ont.

User Level

The command can be accessed by operators with sip,megaco privileges, and executed by operators with sip,megaco privileges.

Command Syntax

The command has the following syntax:

```
> configure voice ont voice-port (uni-idx) [ no custinfo | custinfo <Gpon::CustInfo> ] [ no voipconfig | voipconfig
<Gpon::VoipConfig> ] [ no pots-pwr-timer | pots-pwr-timer <Gpon::PotsPwrTimer> ] [ no call-hist | call-hist
<Gpon::CallHist> ] [ no pwr-override | pwr-override <Gpon::PotsPwrShedOverride> ] [ no rx-gain | rx-gain
<Gpon::RxGain> ] [ no tx-gain | tx-gain <Gpon::TxGain> ] [ no impedance | impedance <Gpon::Impedance> ] [ no
voip-media-prof | voip-media-prof <Gpon::VoipMediaProfilePointer> ] [ no ne-file-name | ne-file-name
<Gpon::NEFileName> ] [ no admin-state | admin-state <Gpon::PotsAdminState> ]
```

Command Parameters

Table 41.5-1 "Voice ONT Voice-Port Configuration Command" Resource Parameters

Resource Identifier	Type	Description
(uni-idx)	Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Gpon::OntSlotId> / <Gpon::OntPotsPortId> ng2 : <Ng2::ChannelGroup> / <Ng2::SubchannelGroup> / <Ng2::OntId> / <Gpon::OntSlotId> / <Gpon::OntPotsPortId>) Possible values: - ng2 : ngpon2 style identification Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Eqpt::OntId> - the ONT identifier Field type <Ng2::ChannelGroup>	interface index of the pots uni

Resource Identifier	Type	Description
	- channel group number Field type <Ng2::SubchannelGroup> - subchannel group number Field type <Ng2::OntId> - the ONT identifier Field type <Gpon::OntSlotId> - Gpon Ont Slot - range: [1...14] Field type <Gpon::OntPotsPortId> - Gpon Ont Pots Port - range: [1...24]	

Table 41.5-2 "Voice ONT Voice-Port Configuration Command" Command Parameters

Parameter	Type	Description
[no] custinfo	Parameter type: <Gpon::CustInfo> Format: - a printable string - length: x<=80	<i>optional parameter with default value: ""</i> information about pots port
[no] voipconfig	Parameter type: <Gpon::VoipConfig> Format: (none mgc sip) Possible values: - none : no association with sip or megaco - mgc : associates with mgc agent - sip : associates with sip agent	<i>optional parameter with default value: "none"</i> associates pots port with sip or mgc agent
[no] pots-pwr-timer	Parameter type: <Gpon::PotsPwrTimer> Format: - time during which pots loop voltage is held up - range: [0...65535]	<i>optional parameter with default value: "0"</i> time during which pots loop voltage is held up
[no] call-hist	Parameter type: <Gpon::CallHist> Format: (enable disable) Possible values: - enable : enable PM collection - disable : disable PM collection	<i>optional parameter with default value: "disable"</i> indicates whether or not a call history to be maintained for this line.
[no] pwr-override	Parameter type: <Gpon::PotsPwrShedOverride> Format: (true false) Possible values: - true : port excluded from voice class power shedding - false : port included in voice class power shedding	<i>optional parameter with default value: "false"</i> voice class power shedding
[no] rx-gain	Parameter type: <Gpon::RxGain> Format: - gain value for the received signal in 0.1db increments - unit: db - range: [-12...6]	<i>optional parameter with default value: 0</i> gain value for the received signal in 0.1db increments
[no] tx-gain	Parameter type: <Gpon::TxGain> Format: - gain value for the transmit signal in 0.1db increments - unit: db - range: [-12...6]	<i>optional parameter with default value: 0</i> gain value for the transmit signal in 0.1db increments
[no] impedance	Parameter type: <Gpon::Impedance> Format:	<i>optional parameter with default value: "unspecified"</i>

41 Voice Ont Configuration Commands

Parameter	Type	Description
	(600 900 750 820 1050 unspecified) Possible values: - 600 : 600 Ohms - 900 : 900 Ohms - 750 : 750 Ohms + 150 nF + 270 ohms - 820 : 820 Ohms + 115 nF + 220 ohms - 1050 : 1050 ohms + 230 nF + 320 ohms - unspecified : the impedance of the line will be handled by the ont internally	standard impedance settings for the pots line
[no] voip-media-prof	Parameter type: <Gpon::VoipMediaProfilePointer> Format: (none <Gpon::VoipMediaProfilePointer> name : <AsamProfileName>) Possible values: - none : no profile to associate - name : profile name Field type <Gpon::VoipMediaProfilePointer> - profile index - range: [0...20] Data driven field type Possible values are depending on the actual configuration and software. The currently allowed values can be shown with online-help.	<i>optional parameter with default value: "none"</i> voip media profile
[no] ne-file-name	Parameter type: <Gpon::NEFileName> Format: - file name used to supplement the network extension file pointer in voice service profile - length: x<=50	<i>optional parameter with default value: ""</i> file name used to supplement the network extension file pointer in voice service profile
[no] admin-state	Parameter type: <Gpon::PotsAdminState> Format: (unlocked locked) Possible values: - unlocked : activates the pots port - locked : deactivates the pots port	<i>optional parameter with default value: "locked"</i> administrative state of pptp pots uni

Command Output

Table 41.5-3 "Voice ONT Voice-Port Configuration Command" Display parameters

Specific Information		
name	Type	Description
oper-state	Parameter type: <Gpon::PotsOperState> (enabled disabled unknown) Possible values: - enabled : enable the service - disabled : disable the service - unknown : unknown state	operational state of the service <i>This element is always shown.</i>

41.6 GPON Authentication Security Profile Configuration Command

Command Description

This command creates the profile for accessing the server storing authentication security information for contacting network addresses. These profiles are normally associated with Voip Services that must reference common authentication information.

User Level

The command can be accessed by operators with equipment privileges, and executed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

```
> configure voice ont ( no auth-sec-prof (index) ) | ( auth-sec-prof (index) name <AsamProfileName> [ no
validation-scheme | validation-scheme <Gpon::AuthSecValScheme> ] [ no user-name | user-name
<Gpon::AuthUserName> ] [ no password | password <Security::Password5> ] [ no realm | realm <Gpon::Realm> ]
)
```

Command Parameters

Table 41.6-1 "GPON Authentication Security Profile Configuration Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - profile index - range: [1...20]	profile index

Table 41.6-2 "GPON Authentication Security Profile Configuration Command" Command Parameters

Parameter	Type	Description
name	Parameter type: <AsamProfileName> Format: - a profile name - range: [a-zA-Z0-9-_.] - length: 1<=x<=32	<i>mandatory parameter</i> <i>The parameter is not visible during modification.</i> profile name
[no] validation-scheme	Parameter type: <Gpon::AuthSecValScheme> Format: (disabled md5-digest basic-authentic) Possible values: - disabled : Validation disabled	<i>optional parameter with default value: "md5-digest"</i> <i>The parameter is not visible during modification.</i> validation scheme required for authentication

Parameter	Type	Description
	- md5-digest : validate using md5 digest authentication - basic-authentic : Validate using basic authentication	
[no] user-name	Parameter type: <Gpon::AuthUserName> Format: - user name required for authentication - length: x<=50	<i>optional parameter with default value: ""</i> <i>The parameter is not visible during modification.</i> user name required for authentication
[no] password	Parameter type: <Security::Password5> Format: (prompt plain : <Security::PlainPassword5>) Possible values: - prompt : prompts the operator for a password - plain : the password in plain text Field type <Security::PlainPassword5> - authentication string - length: x<=25	<i>optional parameter with default value: "plain : "</i> <i>The parameter is not visible during modification.</i> password required for authentication
[no] realm	Parameter type: <Gpon::Realm> Format: - realm required for authentication - length: x<=25	<i>optional parameter with default value: ""</i> <i>The parameter is not visible during modification.</i> realm required for authentication

41.7 Voice ONT Secure URI profile Configuration command

Command Description

This command creates a Secure URI Profile.

It provides (via pointers to other profiles) both the URI for accessing information plus the security information necessary to access the information

User Level

The command can be accessed by operators with equipment privileges, and executed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

```
> configure voice ont ( no sec-uri-profile (index) ) | ( sec-uri-profile (index) name <AsamProfileName> [ no
auth-securi-prof | auth-securi-prof <Gpon::AuthProfileName> ] uri-prof <Gpon::UriProfileName> )
```

Command Parameters

Table 41.7-1 "Voice ONT Secure URI profile Configuration command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - profile index - range: [1...50]	a unique profile index

Table 41.7-2 "Voice ONT Secure URI profile Configuration command" Command Parameters

Parameter	Type	Description
name	Parameter type: <AsamProfileName> Format: - a profile name - range: [a-zA-Z0-9-_.] - length: 1<=x<=32	<i>mandatory parameter</i> <i>The parameter is not visible during modification.</i> A string 1..32 characters long which uniquely identifies this Secure URI Profile
[no] auth-securi-prof	Parameter type: <Gpon::AuthProfileName> Format: (none <Gpon:AuthProfPtr> name : <AsamProfileName>) Possible values: - none : no profile to associate - name : profile name Field type <Gpon:AuthProfPtr>	<i>optional parameter with default value: "none"</i> <i>The parameter is not visible during modification.</i> Authentication security profile that contains network address of the security server

Parameter	Type	Description
	- Index of the Authentication security profile - range: [0...20] Data driven field type Possible values are depending on the actual configuration and software. The currently allowed values can be shown with online-help.	
uri-prof	Parameter type: <Gpon::UriProfileName> Format: (none <Gpon:UriProfilePtr> name : <AsamProfileName>) Possible values: - none : no profile to associate - name : profile name Field type <Gpon:UriProfilePtr> - Index of the URI profile that contains the IP address of the server - range: [0...100] Data driven field type Possible values are depending on the actual configuration and software. The currently allowed values can be shown with online-help.	<i>mandatory parameter</i> <i>The parameter is not visible during modification.</i> uri profile that contains network address of the configuration server

Command Output

Table 41.7-3 "Voice ONT Secure URI profile Configuration command" Display parameters

Specific Information		
name	Type	Description
auth-securi-prof-name	Parameter type: <Gpon::IgnoredPrintableString> - ignored printable string	name of the authentication security uri profile <i>This element is only shown in detail mode.</i>
uri-prof-name	Parameter type: <Gpon::IgnoredPrintableString> - ignored printable string	name of the uri profile <i>This element is only shown in detail mode.</i>

41.8 GPON URI Profile Configuration Command

Command Description

This command creates the URI profile for accessing the configuration server. These profiles are normally associated with Voip Services.

User Level

The command can be accessed by operators with equipment privileges, and executed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

```
> configure voice ont ( no uri-prof (index) ) | ( uri-prof (index) name <AsamProfileName> [ no address | address <Gpon::UriProfileAddress> ] [ no version | version <Gpon::UriProfileVersionNbr> ] )
```

Command Parameters

Table 41.8-1 "GPON URI Profile Configuration Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - profile index - range: [1...100]	profile index

Table 41.8-2 "GPON URI Profile Configuration Command" Command Parameters

Parameter	Type	Description
name	Parameter type: <AsamProfileName> Format: - a profile name - range: [a-zA-Z0-9-_.] - length: 1<=x<=32	<i>mandatory parameter</i> <i>The parameter is not visible during modification.</i> profile name
[no] address	Parameter type: <Gpon::UriProfileAddress> Format: - uri profile address - length: x<=100	<i>optional parameter with default value: ""</i> uri profile address that contains a Fully Qualified Domain Name (FQDN) or an IP Address (in dot notation)
[no] version	Parameter type: <Gpon::UriProfileVersionNbr> Format: - uri profile version number - range: [1...2147483647]	<i>optional parameter with default value: 1L</i> uri profile version number

41.9 GPON Tone Pattern Profile Configuration Command

Command Description

This command creates a profile that defines a tone (multi-frequency is supported) segment including duration and power. Multiple tone segment profiles are used to specify a tone that will be applied to the analog signal to the handset when a particular call event/condition occurs, such as sending a busy tone when the called party is busy.

User Level

The command can be accessed by operators with sip,megaco privileges, and executed by operators with sip,megaco privileges.

Command Syntax

The command has the following syntax:

```
> configure voice ont ( no tone-seg-profile (index) ) | ( tone-seg-profile (index) name <AsamProfileName> freq1
<Gpon::ToneSegFrequency> power1 <Gpon::ToneSegPower> freq2 <Gpon::ToneSegFrequency> power2
<Gpon::ToneSegPower> freq3 <Gpon::ToneSegFrequency> power3 <Gpon::ToneSegPower> freq4
<Gpon::ToneSegFrequency> power4 <Gpon::ToneSegPower> modulation-freq
<Gpon::ToneSegModulationFrequency> modulation-power <Gpon::ToneSegPower> duration
<Gpon::ToneSegDuration> )
```

Command Parameters

Table 41.9-1 "GPON Tone Pattern Profile Configuration Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - profile index - range: [1...50]	profile index

Table 41.9-2 "GPON Tone Pattern Profile Configuration Command" Command Parameters

Parameter	Type	Description
name	Parameter type: <AsamProfileName> Format: - a profile name - range: [a-zA-Z0-9-_.] - length: 1<=x<=32	mandatory parameter The parameter is not visible during modification. profile name
freq1	Parameter type: <Gpon::ToneSegFrequency> Format: - frequency - unit: Hz - range: [0...4000]	mandatory parameter The parameter is not visible during modification. frequency of one of the tone components
power1	Parameter type: <Gpon::ToneSegPower> Format:	mandatory parameter The parameter is not visible

41 Voice Ont Configuration Commands

Parameter	Type	Description
	- power level - unit: dBm - range: [-25.5...0.0]	during modification. power level of freq1
freq2	Parameter type: <Gpon::ToneSegFrequency> Format: - frequency - unit: Hz - range: [0...4000]	<i>mandatory parameter</i> <i>The parameter is not visible during modification.</i> frequency of one of the tone components
power2	Parameter type: <Gpon::ToneSegPower> Format: - power level - unit: dBm - range: [-25.5...0.0]	<i>mandatory parameter</i> <i>The parameter is not visible during modification.</i> power level of freq2
freq3	Parameter type: <Gpon::ToneSegFrequency> Format: - frequency - unit: Hz - range: [0...4000]	<i>mandatory parameter</i> <i>The parameter is not visible during modification.</i> frequency of one of the tone components
power3	Parameter type: <Gpon::ToneSegPower> Format: - power level - unit: dBm - range: [-25.5...0.0]	<i>mandatory parameter</i> <i>The parameter is not visible during modification.</i> power level of freq3
freq4	Parameter type: <Gpon::ToneSegFrequency> Format: - frequency - unit: Hz - range: [0...4000]	<i>mandatory parameter</i> <i>The parameter is not visible during modification.</i> frequency of one of the tone components
power4	Parameter type: <Gpon::ToneSegPower> Format: - power level - unit: dBm - range: [-25.5...0.0]	<i>mandatory parameter</i> <i>The parameter is not visible during modification.</i> power level of freq4
modulation-freq	Parameter type: <Gpon::ToneSegModulationFrequency> Format: - frequency - unit: Hz - range: [0...2000]	<i>mandatory parameter</i> <i>The parameter is not visible during modification.</i> modulation frequency for the tone segment
modulation-power	Parameter type: <Gpon::ToneSegPower> Format: - power level - unit: dBm - range: [-25.5...0.0]	<i>mandatory parameter</i> <i>The parameter is not visible during modification.</i> modulation power for the tone segment
duration	Parameter type: <Gpon::ToneSegDuration> Format: - duration - unit: milliseconds - range: [0...65535]	<i>mandatory parameter</i> <i>The parameter is not visible during modification.</i> duration of the tone segment

41.10 GPON Tone Pattern Sequence Profile Configuration Command

Command Description

This command creates a profile that defines a tone sequence by serially identifying tone segment profiles to associate for a sequence.

User Level

The command can be accessed by operators with sip,megaco privileges, and executed by operators with sip,megaco privileges.

Command Syntax

The command has the following syntax:

```
> configure voice ont ( no tone-seq-profile (index) ) | ( tone-seq-profile (index) name <AsamProfileName>
pattern-prof1 <Gpon::ZeroToneSegProfile> [ no pattern-prof2 | pattern-prof2 <Gpon::ZeroToneSegProfile> ] [ no
pattern-prof3 | pattern-prof3 <Gpon::ZeroToneSegProfile> ] [ no pattern-prof4 | pattern-prof4
<Gpon::ZeroToneSegProfile> ] [ no pattern-prof5 | pattern-prof5 <Gpon::ZeroToneSegProfile> ] [ no pattern-prof6
| pattern-prof6 <Gpon::ZeroToneSegProfile> ] [ no pattern-prof7 | pattern-prof7 <Gpon::ZeroToneSegProfile> ] [
no pattern-prof8 | pattern-prof8 <Gpon::ZeroToneSegProfile> ] )
```

Command Parameters

Table 41.10-1 "GPON Tone Pattern Sequence Profile Configuration Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - profile index - range: [1...50]	profile index

Table 41.10-2 "GPON Tone Pattern Sequence Profile Configuration Command" Command Parameters

Parameter	Type	Description
name	Parameter type: <AsamProfileName> Format: - a profile name - range: [a-zA-Z0-9-_.] - length: 1<=x<=32	mandatory parameter The parameter is not visible during modification. profile name
pattern-prof1	Parameter type: <Gpon::ZeroToneSegProfile> Format: (none <Gpon::ZeroToneSegProfilePointer> name : <AsamProfileName>) Possible values:	mandatory parameter The parameter is not visible during modification. tone segment profile

41 Voice Ont Configuration Commands

Parameter	Type	Description
	- none : no profile to associate - name : profile name Field type <Gpon::ZeroToneSegProfilePointer> - profile index - range: [0...50] Data driven field type Possible values are depending on the actual configuration and software. The currently allowed values can be shown with online-help.	
[no] pattern-prof2	Parameter type: <Gpon::ZeroToneSegProfile> Format: (none <Gpon::ZeroToneSegProfilePointer> name : <AsamProfileName>) Possible values: - none : no profile to associate - name : profile name Field type <Gpon::ZeroToneSegProfilePointer> - profile index - range: [0...50] Data driven field type Possible values are depending on the actual configuration and software. The currently allowed values can be shown with online-help.	<i>optional parameter with default value: "none"</i> <i>The parameter is not visible during modification.</i> tone segment profile
[no] pattern-prof3	Parameter type: <Gpon::ZeroToneSegProfile> Format: (none <Gpon::ZeroToneSegProfilePointer> name : <AsamProfileName>) Possible values: - none : no profile to associate - name : profile name Field type <Gpon::ZeroToneSegProfilePointer> - profile index - range: [0...50] Data driven field type Possible values are depending on the actual configuration and software. The currently allowed values can be shown with online-help.	<i>optional parameter with default value: "none"</i> <i>The parameter is not visible during modification.</i> tone segment profile
[no] pattern-prof4	Parameter type: <Gpon::ZeroToneSegProfile> Format: (none <Gpon::ZeroToneSegProfilePointer> name : <AsamProfileName>) Possible values: - none : no profile to associate - name : profile name Field type <Gpon::ZeroToneSegProfilePointer> - profile index - range: [0...50] Data driven field type Possible values are depending on the actual configuration and software. The currently allowed values can be shown with online-help.	<i>optional parameter with default value: "none"</i> <i>The parameter is not visible during modification.</i> tone segment profile
[no] pattern-prof5	Parameter type: <Gpon::ZeroToneSegProfile> Format: (none	<i>optional parameter with default value: "none"</i> <i>The parameter is not visible</i>

Parameter	Type	Description
	<Gpon::ZeroToneSegProfilePointer> name : <AsamProfileName>) Possible values: - none : no profile to associate - name : profile name Field type <Gpon::ZeroToneSegProfilePointer> - profile index - range: [0...50] Data driven field type Possible values are depending on the actual configuration and software. The currently allowed values can be shown with online-help.	during modification. tone segment profile
[no] pattern-prof6	Parameter type: <Gpon::ZeroToneSegProfile> Format: (none <Gpon::ZeroToneSegProfilePointer> name : <AsamProfileName>) Possible values: - none : no profile to associate - name : profile name Field type <Gpon::ZeroToneSegProfilePointer> - profile index - range: [0...50] Data driven field type Possible values are depending on the actual configuration and software. The currently allowed values can be shown with online-help.	<i>optional parameter with default value: "none"</i> <i>The parameter is not visible during modification.</i> tone segment profile
[no] pattern-prof7	Parameter type: <Gpon::ZeroToneSegProfile> Format: (none <Gpon::ZeroToneSegProfilePointer> name : <AsamProfileName>) Possible values: - none : no profile to associate - name : profile name Field type <Gpon::ZeroToneSegProfilePointer> - profile index - range: [0...50] Data driven field type Possible values are depending on the actual configuration and software. The currently allowed values can be shown with online-help.	<i>optional parameter with default value: "none"</i> <i>The parameter is not visible during modification.</i> tone segment profile
[no] pattern-prof8	Parameter type: <Gpon::ZeroToneSegProfile> Format: (none <Gpon::ZeroToneSegProfilePointer> name : <AsamProfileName>) Possible values: - none : no profile to associate - name : profile name Field type <Gpon::ZeroToneSegProfilePointer> - profile index - range: [0...50] Data driven field type Possible values are depending on the actual configuration and software. The currently allowed values can be shown with online-help.	<i>optional parameter with default value: "none"</i> <i>The parameter is not visible during modification.</i> tone segment profile

Command Output

Table 41.10-3 "GPON Tone Pattern Sequence Profile Configuration Command" Display parameters

Specific Information		
name	Type	Description
pattern-prof1-name	Parameter type: <Gpon::IgnoredPrintableString> - ignored printable string	name of the tone segment profile <i>This element is only shown in detail mode.</i>
pattern-prof2-name	Parameter type: <Gpon::IgnoredPrintableString> - ignored printable string	name of the tone segment profile <i>This element is only shown in detail mode.</i>
pattern-prof3-name	Parameter type: <Gpon::IgnoredPrintableString> - ignored printable string	name of the tone segment profile <i>This element is only shown in detail mode.</i>
pattern-prof4-name	Parameter type: <Gpon::IgnoredPrintableString> - ignored printable string	name of the tone segment profile <i>This element is only shown in detail mode.</i>
pattern-prof5-name	Parameter type: <Gpon::IgnoredPrintableString> - ignored printable string	name of the tone segment profile <i>This element is only shown in detail mode.</i>
pattern-prof6-name	Parameter type: <Gpon::IgnoredPrintableString> - ignored printable string	name of the tone segment profile <i>This element is only shown in detail mode.</i>
pattern-prof7-name	Parameter type: <Gpon::IgnoredPrintableString> - ignored printable string	name of the tone segment profile <i>This element is only shown in detail mode.</i>
pattern-prof8-name	Parameter type: <Gpon::IgnoredPrintableString> - ignored printable string	name of the tone segment profile <i>This element is only shown in detail mode.</i>

41.11 Tone Event Profile Configuration Command

Command Description

This command is used to create a profile that contains the associations of tone sequence profiles or file ids to call event/conditions.

Note, this profile supports either method for making this association (use of the tone sequence profile or identifying a file on the ONT where a bit map of the tone is located).

User Level

The command can be accessed by operators with sip,megaco privileges, and executed by operators with sip,megaco privileges.

Command Syntax

The command has the following syntax:

```
> configure voice ont ( no tone-event-prof (index) ) | ( tone-event-prof (index) name <AsamProfileName> )
```

Command Parameters

Table 41.11-1 "Tone Event Profile Configuration Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - tone event profile index - range: [1...5]	profile index

Table 41.11-2 "Tone Event Profile Configuration Command" Command Parameters

Parameter	Type	Description
name	Parameter type: <AsamProfileName> Format: - a profile name - range: [a-zA-Z0-9-_.] - length: 1<=x<=32	<i>mandatory parameter</i> profile name

41.12 GPON Busy Tone Event Profile Configuration Command

Command Description

This command is used to change or configure the definition of a Busy tone within the tone set.

As noted in the Tone Event Profile configuration command, the selection of the tone can be either via pointing to a Tone Sequence Profile, or by referencing a file on the ONT.

This command supports either mechanism.

User Level

The command can be accessed by operators with sip,megaco privileges, and executed by operators with sip,megaco privileges.

Command Syntax

The command has the following syntax:

```
> configure voice ont tone-event-prof (index) busy-tone [ no tone-seq-prof | tone-seq-prof <Gpon::ToneSeqProfile> ] [ no file-prof | file-prof <Gpon::FileProfile> ] [ no repeat | repeat <Gpon::RepetitionNbr> ]
```

Command Parameters

Table 41.12-1 "GPON Busy Tone Event Profile Configuration Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - tone event profile index - range: [1...5]	profile index

Table 41.12-2 "GPON Busy Tone Event Profile Configuration Command" Command Parameters

Parameter	Type	Description
[no] tone-seq-prof	Parameter type: <Gpon::ToneSeqProfile> Format: (none <Gpon::ToneSeqProfPtr> name : <AsamProfileName>) Possible values: - none : no profile to associate - name : profile name Field type <Gpon::ToneSeqProfPtr> - profile index - range: [0...50] Data driven field type Possible values are depending on the actual configuration and software.	<i>optional parameter with default value: "none"</i> tone sequence profile

Parameter	Type	Description
	The currently allowed values can be shown with online-help.	
[no] file-prof	Parameter type: <Gpon::FileProfile> Format: (none <Gpon::FileProfPtr> name : <AsamProfileName>) Possible values: - none : no profile to associate - name : profile name Field type <Gpon::FileProfPtr> - profile index - range: [0...100] Data driven field type Possible values are depending on the actual configuration and software. The currently allowed values can be shown with online-help.	<i>optional parameter with default value: "none"</i> uri profile
[no] repeat	Parameter type: <Gpon::RepetitionNbr> Format: - repetition number - range: [0...10]	<i>optional parameter with default value: 0L</i> number of times the tone file is repeated

41.13 GPON First Call Wait Tone Event Profile Configuration Command

Command Description

This command is used to change or configure the definition of the first Call Wait tone within the tone set.

As noted in the Tone Event Profile configuration command, the selection of the tone can be either via pointing to a Tone Sequence Profile, or by referencing a file on the ONT.

This command supports either mechanism.

User Level

The command can be accessed by operators with sip,megaco privileges, and executed by operators with sip,megaco privileges.

Command Syntax

The command has the following syntax:

```
> configure voice ont tone-event-prof (index) callwait1-tone [ no tone-seq-prof | tone-seq-prof
<Gpon::ToneSeqProfile> ] [ no file-prof | file-prof <Gpon::FileProfile> ] [ no repeat | repeat
<Gpon::RepetitionNbr> ]
```

Command Parameters

Table 41.13-1 "GPON First Call Wait Tone Event Profile Configuration Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - tone event profile index - range: [1...5]	profile index

Table 41.13-2 "GPON First Call Wait Tone Event Profile Configuration Command" Command Parameters

Parameter	Type	Description
[no] tone-seq-prof	Parameter type: <Gpon::ToneSeqProfile> Format: (none <Gpon::ToneSeqProfPtr> name : <AsamProfileName>) Possible values: - none : no profile to associate - name : profile name Field type <Gpon::ToneSeqProfPtr> - profile index - range: [0...50]	optional parameter with default value: "none" tone sequence profile

Parameter	Type	Description
	Data driven field type Possible values are depending on the actual configuration and software. The currently allowed values can be shown with online-help.	
[no] file-prof	Parameter type: <Gpon::FileProfile> Format: (none <Gpon::FileProfPtr> name : <AsamProfileName>) Possible values: - none : no profile to associate - name : profile name Field type <Gpon::FileProfPtr> - profile index - range: [0...100] Data driven field type Possible values are depending on the actual configuration and software. The currently allowed values can be shown with online-help.	<i>optional parameter with default value: "none"</i> uri profile
[no] repeat	Parameter type: <Gpon::RepetitionNbr> Format: - repetition number - range: [0...10]	<i>optional parameter with default value: 0L</i> number of times the tone file is repeated

41.14 GPON Second Call Wait Tone Event Profile Configuration Command

Command Description

This command is used to change or configure the definition of the second Call Wait tone within the tone set.

As noted in the Tone Event Profile configuration command, the selection of the tone can be either via pointing to a Tone Sequence Profile, or by referencing a file on the ONT.

This command supports either mechanism.

User Level

The command can be accessed by operators with sip,megaco privileges, and executed by operators with sip,megaco privileges.

Command Syntax

The command has the following syntax:

```
> configure voice ont tone-event-prof (index) callwait2-tone [ no tone-seq-prof | tone-seq-prof
<Gpon::ToneSeqProfile> ] [ no file-prof | file-prof <Gpon::FileProfile> ] [ no repeat | repeat
<Gpon::RepetitionNbr> ]
```

Command Parameters

Table 41.14-1 "GPON Second Call Wait Tone Event Profile Configuration Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - tone event profile index - range: [1...5]	profile index

Table 41.14-2 "GPON Second Call Wait Tone Event Profile Configuration Command" Command Parameters

Parameter	Type	Description
[no] tone-seq-prof	Parameter type: <Gpon::ToneSeqProfile> Format: (none <Gpon::ToneSeqProfPtr> name : <AsamProfileName>) Possible values: - none : no profile to associate - name : profile name Field type <Gpon::ToneSeqProfPtr> - profile index - range: [0...50]	<i>optional parameter with default value: "none"</i> tone sequence profile

Parameter	Type	Description
	Data driven field type Possible values are depending on the actual configuration and software. The currently allowed values can be shown with online-help.	
[no] file-prof	Parameter type: <Gpon::FileProfile> Format: (none <Gpon::FileProfPtr> name : <AsamProfileName>) Possible values: - none : no profile to associate - name : profile name Field type <Gpon::FileProfPtr> - profile index - range: [0...100] Data driven field type Possible values are depending on the actual configuration and software. The currently allowed values can be shown with online-help.	<i>optional parameter with default value: "none"</i> uri profile
[no] repeat	Parameter type: <Gpon::RepetitionNbr> Format: - repetition number - range: [0...10]	<i>optional parameter with default value: 0L</i> number of times the tone file is repeated

41.15 GPON Third Call Wait Tone Event Profile Configuration Command

Command Description

This command is used to change or configure the definition of the third Call Wait tone within the tone set.

As noted in the Tone Event Profile configuration command, the selection of the tone can be either via pointing to a Tone Sequence Profile, or by referencing a file on the ONT.

This command supports either mechanism.

User Level

The command can be accessed by operators with sip,megaco privileges, and executed by operators with sip,megaco privileges.

Command Syntax

The command has the following syntax:

```
> configure voice ont tone-event-prof (index) callwait3-tone [ no tone-seq-prof | tone-seq-prof
<Gpon::ToneSeqProfile> ] [ no file-prof | file-prof <Gpon::FileProfile> ] [ no repeat | repeat
<Gpon::RepetitionNbr> ]
```

Command Parameters

Table 41.15-1 "GPON Third Call Wait Tone Event Profile Configuration Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - tone event profile index - range: [1...5]	profile index

Table 41.15-2 "GPON Third Call Wait Tone Event Profile Configuration Command" Command Parameters

Parameter	Type	Description
[no] tone-seq-prof	Parameter type: <Gpon::ToneSeqProfile> Format: (none <Gpon::ToneSeqProfPtr> name : <AsamProfileName>) Possible values: - none : no profile to associate - name : profile name Field type <Gpon::ToneSeqProfPtr> - profile index - range: [0...50]	optional parameter with default value: "none" tone sequence profile

Parameter	Type	Description
	Data driven field type Possible values are depending on the actual configuration and software. The currently allowed values can be shown with online-help.	
[no] file-prof	Parameter type: <Gpon::FileProfile> Format: (none <Gpon::FileProfPtr> name : <AsamProfileName>) Possible values: - none : no profile to associate - name : profile name Field type <Gpon::FileProfPtr> - profile index - range: [0...100] Data driven field type Possible values are depending on the actual configuration and software. The currently allowed values can be shown with online-help.	<i>optional parameter with default value: "none"</i> uri profile
[no] repeat	Parameter type: <Gpon::RepetitionNbr> Format: - repetition number - range: [0...10]	<i>optional parameter with default value: 0L</i> number of times the tone file is repeated

41.16 GPON Fourth Call Wait Tone Event Profile Configuration Command

Command Description

This command is used to change or configure the definition of a fourth Call Wait tone within the tone set.

As noted in the Tone Event Profile configuration command, the selection of the tone can be either via pointing to a Tone Sequence Profile, or by referencing a file on the ONT.

This command supports either mechanism.

User Level

The command can be accessed by operators with sip,megaco privileges, and executed by operators with sip,megaco privileges.

Command Syntax

The command has the following syntax:

```
> configure voice ont tone-event-prof (index) callwait4-tone [ no tone-seq-prof | tone-seq-prof
<Gpon::ToneSeqProfile> ] [ no file-prof | file-prof <Gpon::FileProfile> ] [ no repeat | repeat
<Gpon::RepetitionNbr> ]
```

Command Parameters

Table 41.16-1 "GPON Fourth Call Wait Tone Event Profile Configuration Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - tone event profile index - range: [1...5]	profile index

Table 41.16-2 "GPON Fourth Call Wait Tone Event Profile Configuration Command" Command Parameters

Parameter	Type	Description
[no] tone-seq-prof	Parameter type: <Gpon::ToneSeqProfile> Format: (none <Gpon::ToneSeqProfPtr> name : <AsamProfileName>) Possible values: - none : no profile to associate - name : profile name Field type <Gpon::ToneSeqProfPtr> - profile index - range: [0...50]	optional parameter with default value: "none" tone sequence profile

Parameter	Type	Description
	Data driven field type Possible values are depending on the actual configuration and software. The currently allowed values can be shown with online-help.	
[no] file-prof	Parameter type: <Gpon::FileProfile> Format: (none <Gpon::FileProfPtr> name : <AsamProfileName>) Possible values: - none : no profile to associate - name : profile name Field type <Gpon::FileProfPtr> - profile index - range: [0...100] Data driven field type Possible values are depending on the actual configuration and software. The currently allowed values can be shown with online-help.	<i>optional parameter with default value: "none"</i> URI profile
[no] repeat	Parameter type: <Gpon::RepetitionNbr> Format: - repetition number - range: [0...10]	<i>optional parameter with default value: "0"</i> number of times the tone file is repeated

41.17 GPON Alert Tone Event Profile Configuration Command

Command Description

This command is used to change or configure the definition of a Alert tone within the tone set.

As noted in the Tone Event Profile configuration command, the selection of the tone can be either via pointing to a Tone Sequence Profile, or by referencing a file on the ONT.

This command supports either mechanism.

User Level

The command can be accessed by operators with sip,megaco privileges, and executed by operators with sip,megaco privileges.

Command Syntax

The command has the following syntax:

```
> configure voice ont tone-event-prof (index) alert-tone [ no tone-seq-prof | tone-seq-prof <Gpon::ToneSeqProfile> ] [ no file-prof | file-prof <Gpon::FileProfile> ] [ no repeat | repeat <Gpon::RepetitionNbr> ]
```

Command Parameters

Table 41.17-1 "GPON Alert Tone Event Profile Configuration Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - tone event profile index - range: [1...5]	profile index

Table 41.17-2 "GPON Alert Tone Event Profile Configuration Command" Command Parameters

Parameter	Type	Description
[no] tone-seq-prof	Parameter type: <Gpon::ToneSeqProfile> Format: (none <Gpon::ToneSeqProfPtr> name : <AsamProfileName>) Possible values: - none : no profile to associate - name : profile name Field type <Gpon::ToneSeqProfPtr> - profile index - range: [0...50] Data driven field type Possible values are depending on the actual configuration and software.	<i>optional parameter with default value: "none"</i> tone sequence profile

Parameter	Type	Description
	The currently allowed values can be shown with online-help.	
[no] file-prof	Parameter type: <Gpon::FileProfile> Format: (none <Gpon::FileProfPtr> name : <AsamProfileName>) Possible values: - none : no profile to associate - name : profile name Field type <Gpon::FileProfPtr> - profile index - range: [0...100] Data driven field type Possible values are depending on the actual configuration and software. The currently allowed values can be shown with online-help.	<i>optional parameter with default value: "none"</i> URI profile
[no] repeat	Parameter type: <Gpon::RepetitionNbr> Format: - repetition number - range: [0...10]	<i>optional parameter with default value: "0"</i> number of times the tone file is repeated

41.18 GPON Special Dial Tone Event Profile Configuration Command

Command Description

This command is used to change or configure the definition of a Special Dial tone within the tone set.

As noted in the Tone Event Profile configuration command, the selection of the tone can be either via pointing to a Tone Sequence Profile, or by referencing a file on the ONT.

This command supports either mechanism.

User Level

The command can be accessed by operators with sip,megaco privileges, and executed by operators with sip,megaco privileges.

Command Syntax

The command has the following syntax:

```
> configure voice ont tone-event-prof (index) special-dial-tone [ no tone-seq-prof | tone-seq-prof
<Gpon::ToneSeqProfile> ] [ no file-prof | file-prof <Gpon::FileProfile> ] [ no repeat | repeat
<Gpon::RepetitionNbr> ]
```

Command Parameters

Table 41.18-1 "GPON Special Dial Tone Event Profile Configuration Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - tone event profile index - range: [1...5]	profile index

Table 41.18-2 "GPON Special Dial Tone Event Profile Configuration Command" Command Parameters

Parameter	Type	Description
[no] tone-seq-prof	Parameter type: <Gpon::ToneSeqProfile> Format: (none <Gpon::ToneSeqProfPtr> name : <AsamProfileName>) Possible values: - none : no profile to associate - name : profile name Field type <Gpon::ToneSeqProfPtr> - profile index - range: [0...50]	optional parameter with default value: "none" tone sequence profile

Parameter	Type	Description
	Data driven field type Possible values are depending on the actual configuration and software. The currently allowed values can be shown with online-help.	
[no] file-prof	Parameter type: <Gpon::FileProfile> Format: (none <Gpon::FileProfPtr> name : <AsamProfileName>) Possible values: - none : no profile to associate - name : profile name Field type <Gpon::FileProfPtr> - profile index - range: [0...100] Data driven field type Possible values are depending on the actual configuration and software. The currently allowed values can be shown with online-help.	<i>optional parameter with default value: "none"</i> URI profile
[no] repeat	Parameter type: <Gpon::RepetitionNbr> Format: - repetition number - range: [0...10]	<i>optional parameter with default value: "0"</i> number of times the tone file is repeated

41.19 GPON Special Info Tone Event Profile Configuration Command

Command Description

This command is used to change or configure the definition of a Special Info tone within the tone set.

As noted in the Tone Event Profile configuration command, the selection of the tone can be either via pointing to a Tone Sequence Profile, or by referencing a file on the ONT.

This command supports either mechanism.

User Level

The command can be accessed by operators with sip,megaco privileges, and executed by operators with sip,megaco privileges.

Command Syntax

The command has the following syntax:

```
> configure voice ont tone-event-prof (index) special-info-tone [ no tone-seq-prof | tone-seq-prof
<Gpon::ToneSeqProfile> ] [ no file-prof | file-prof <Gpon::FileProfile> ] [ no repeat | repeat
<Gpon::RepetitionNbr> ]
```

Command Parameters

Table 41.19-1 "GPON Special Info Tone Event Profile Configuration Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - tone event profile index - range: [1...5]	profile index

Table 41.19-2 "GPON Special Info Tone Event Profile Configuration Command" Command Parameters

Parameter	Type	Description
[no] tone-seq-prof	Parameter type: <Gpon::ToneSeqProfile> Format: (none <Gpon::ToneSeqProfPtr> name : <AsamProfileName>) Possible values: - none : no profile to associate - name : profile name Field type <Gpon::ToneSeqProfPtr> - profile index - range: [0...50]	optional parameter with default value: "none" tone sequence profile

Parameter	Type	Description
	Data driven field type Possible values are depending on the actual configuration and software. The currently allowed values can be shown with online-help.	
[no] file-prof	Parameter type: <Gpon::FileProfile> Format: (none <Gpon::FileProfPtr> name : <AsamProfileName>) Possible values: - none : no profile to associate - name : profile name Field type <Gpon::FileProfPtr> - profile index - range: [0...100] Data driven field type Possible values are depending on the actual configuration and software. The currently allowed values can be shown with online-help.	<i>optional parameter with default value: "none"</i> URI profile
[no] repeat	Parameter type: <Gpon::RepetitionNbr> Format: - repetition number - range: [0...10]	<i>optional parameter with default value: "0"</i> number of times the tone file is repeated

41.20 GPON Release Tone Event Profile Configuration Command

Command Description

This command is used to change or configure the definition of a Release tone within the tone set.

As noted in the Tone Event Profile configuration command, the selection of the tone can be either via pointing to a Tone Sequence Profile, or by referencing a file on the ONT.

This command supports either mechanism.

User Level

The command can be accessed by operators with sip,megaco privileges, and executed by operators with sip,megaco privileges.

Command Syntax

The command has the following syntax:

```
> configure voice ont tone-event-prof (index) release-tone [ no tone-seq-prof | tone-seq-prof
<Gpon::ToneSeqProfile> ] [ no file-prof | file-prof <Gpon::FileProfile> ] [ no repeat | repeat
<Gpon::RepetitionNbr> ]
```

Command Parameters

Table 41.20-1 "GPON Release Tone Event Profile Configuration Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - tone event profile index - range: [1...5]	profile index

Table 41.20-2 "GPON Release Tone Event Profile Configuration Command" Command Parameters

Parameter	Type	Description
[no] tone-seq-prof	Parameter type: <Gpon::ToneSeqProfile> Format: (none <Gpon::ToneSeqProfPtr> name : <AsamProfileName>) Possible values: - none : no profile to associate - name : profile name Field type <Gpon::ToneSeqProfPtr> - profile index - range: [0...50] Data driven field type Possible values are depending on the actual configuration	<i>optional parameter with default value: "none"</i> tone sequence profile

Parameter	Type	Description
	and software. The currently allowed values can be shown with online-help.	
[no] file-prof	Parameter type: <Gpon::FileProfile> Format: (none <Gpon::FileProfPtr> name : <AsamProfileName>) Possible values: - none : no profile to associate - name : profile name Field type <Gpon::FileProfPtr> - profile index - range: [0...100] Data driven field type Possible values are depending on the actual configuration and software. The currently allowed values can be shown with online-help.	<i>optional parameter with default value: "none"</i> URI profile
[no] repeat	Parameter type: <Gpon::RepetitionNbr> Format: - repetition number - range: [0...10]	<i>optional parameter with default value: "0"</i> number of times the tone file is repeated

41.21 GPON Congest Tone Event Profile Configuration Command

Command Description

This command is used to change or configure the definition of a congest tone within the tone set.

As noted in the Tone Event Profile configuration command, the selection of the tone can be either via pointing to a Tone Sequence Profile, or by referencing a file on the ONT.

This command supports either mechanism.

User Level

The command can be accessed by operators with sip,megaco privileges, and executed by operators with sip,megaco privileges.

Command Syntax

The command has the following syntax:

```
> configure voice ont tone-event-prof (index) congest-tone [ no tone-seq-prof | tone-seq-prof
<Gpon::ToneSeqProfile> ] [ no file-prof | file-prof <Gpon::FileProfile> ] [ no repeat | repeat
<Gpon::RepetitionNbr> ]
```

Command Parameters

Table 41.21-1 "GPON Congest Tone Event Profile Configuration Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - tone event profile index - range: [1...5]	profile index

Table 41.21-2 "GPON Congest Tone Event Profile Configuration Command" Command Parameters

Parameter	Type	Description
[no] tone-seq-prof	Parameter type: <Gpon::ToneSeqProfile> Format: (none <Gpon::ToneSeqProfPtr> name : <AsamProfileName>) Possible values: - none : no profile to associate - name : profile name Field type <Gpon::ToneSeqProfPtr> - profile index - range: [0...50] Data driven field type	<i>optional parameter with default value: "none"</i> tone sequence profile

Parameter	Type	Description
	Possible values are depending on the actual configuration and software. The currently allowed values can be shown with online-help.	
[no] file-prof	Parameter type: <Gpon::FileProfile> Format: (none <Gpon::FileProfPtr> name : <AsamProfileName>) Possible values: - none : no profile to associate - name : profile name Field type <Gpon::FileProfPtr> - profile index - range: [0...100] Data driven field type Possible values are depending on the actual configuration and software. The currently allowed values can be shown with online-help.	<i>optional parameter with default value: "none"</i> URI profile
[no] repeat	Parameter type: <Gpon::RepetitionNbr> Format: - repetition number - range: [0...10]	<i>optional parameter with default value: "0"</i> number of times the tone file is repeated

41.22 GPON Confirm Tone Event Profile Configuration Command

Command Description

This command is used to change or configure the definition of a Confirm tone within the tone set.

As noted in the Tone Event Profile configuration command, the selection of the tone can be either via pointing to a Tone Sequence Profile, or by referencing a file on the ONT.

This command supports either mechanism.

User Level

The command can be accessed by operators with sip,megaco privileges, and executed by operators with sip,megaco privileges.

Command Syntax

The command has the following syntax:

```
> configure voice ont tone-event-prof (index) confirm-tone [ no tone-seq-prof | tone-seq-prof
<Gpon::ToneSeqProfile> ] [ no file-prof | file-prof <Gpon::FileProfile> ] [ no repeat | repeat
<Gpon::RepetitionNbr> ]
```

Command Parameters

Table 41.22-1 "GPON Confirm Tone Event Profile Configuration Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - tone event profile index - range: [1...5]	profile index

Table 41.22-2 "GPON Confirm Tone Event Profile Configuration Command" Command Parameters

Parameter	Type	Description
[no] tone-seq-prof	Parameter type: <Gpon::ToneSeqProfile> Format: (none <Gpon::ToneSeqProfPtr> name : <AsamProfileName>) Possible values: - none : no profile to associate - name : profile name Field type <Gpon::ToneSeqProfPtr> - profile index - range: [0...50] Data driven field type	<i>optional parameter with default value: "none"</i> tone sequence profile

Parameter	Type	Description
	Possible values are depending on the actual configuration and software. The currently allowed values can be shown with online-help.	
[no] file-prof	Parameter type: <Gpon::FileProfile> Format: (none <Gpon::FileProfPtr> name : <AsamProfileName>) Possible values: - none : no profile to associate - name : profile name Field type <Gpon::FileProfPtr> - profile index - range: [0...100] Data driven field type Possible values are depending on the actual configuration and software. The currently allowed values can be shown with online-help.	<i>optional parameter with default value: "none"</i> uri profile
[no] repeat	Parameter type: <Gpon::RepetitionNbr> Format: - repetition number - range: [0...10]	<i>optional parameter with default value: 0L</i> number of times the tone file is repeated

41.23 GPON Dial Tone Event Profile Configuration Command

Command Description

This command is used to change or configure the definition of the Dial tone within the tone set.

As noted in the Tone Event Profile configuration command, the selection of the tone can be either via pointing to a Tone Sequence Profile, or by referencing a file on the ONT.

This command supports either mechanism.

User Level

The command can be accessed by operators with sip,megaco privileges, and executed by operators with sip,megaco privileges.

Command Syntax

The command has the following syntax:

```
> configure voice ont tone-event-prof (index) dial-tone [ no tone-seq-prof | tone-seq-prof <Gpon::ToneSeqProfile> ] [ no file-prof | file-prof <Gpon::FileProfile> ] [ no repeat | repeat <Gpon::RepetitionNbr> ]
```

Command Parameters

Table 41.23-1 "GPON Dial Tone Event Profile Configuration Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - tone event profile index - range: [1...5]	profile index

Table 41.23-2 "GPON Dial Tone Event Profile Configuration Command" Command Parameters

Parameter	Type	Description
[no] tone-seq-prof	Parameter type: <Gpon::ToneSeqProfile> Format: (none <Gpon::ToneSeqProfPtr> name : <AsamProfileName>) Possible values: - none : no profile to associate - name : profile name Field type <Gpon::ToneSeqProfPtr> - profile index - range: [0...50] Data driven field type Possible values are depending on the actual configuration and software.	<i>optional parameter with default value: "none"</i> tone sequence profile

Parameter	Type	Description
	The currently allowed values can be shown with online-help.	
[no] file-prof	Parameter type: <Gpon::FileProfile> Format: (none <Gpon::FileProfPtr> name : <AsamProfileName>) Possible values: - none : no profile to associate - name : profile name Field type <Gpon::FileProfPtr> - profile index - range: [0...100] Data driven field type Possible values are depending on the actual configuration and software. The currently allowed values can be shown with online-help.	<i>optional parameter with default value: "none"</i> uri profile
[no] repeat	Parameter type: <Gpon::RepetitionNbr> Format: - repetition number - range: [0...10]	<i>optional parameter with default value: 0L</i> number of times the tone file is repeated

41.24 GPON Message Wait Tone Event Profile Configuration Command

Command Description

This command is used to change or configure the definition of a Message wait tone within the tone set.

As noted in the Tone Event Profile configuration command, the selection of the tone can be either via pointing to a Tone Sequence Profile, or by referencing a file on the ONT.

This command supports either mechanism.

User Level

The command can be accessed by operators with sip,megaco privileges, and executed by operators with sip,megaco privileges.

Command Syntax

The command has the following syntax:

```
> configure voice ont tone-event-prof (index) msg-wait-tone [ no tone-seq-prof | tone-seq-prof
<Gpon::ToneSeqProfile> ] [ no file-prof | file-prof <Gpon::FileProfile> ] [ no repeat | repeat
<Gpon::RepetitionNbr> ]
```

Command Parameters

Table 41.24-1 "GPON Message Wait Tone Event Profile Configuration Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - tone event profile index - range: [1...5]	profile index

Table 41.24-2 "GPON Message Wait Tone Event Profile Configuration Command" Command Parameters

Parameter	Type	Description
[no] tone-seq-prof	Parameter type: <Gpon::ToneSeqProfile> Format: (none <Gpon::ToneSeqProfPtr> name : <AsamProfileName>) Possible values: - none : no profile to associate - name : profile name Field type <Gpon::ToneSeqProfPtr> - profile index - range: [0...50]	optional parameter with default value: "none" tone sequence profile

Parameter	Type	Description
	Data driven field type Possible values are depending on the actual configuration and software. The currently allowed values can be shown with online-help.	
[no] file-prof	Parameter type: <Gpon::FileProfile> Format: (none <Gpon::FileProfPtr> name : <AsamProfileName>) Possible values: - none : no profile to associate - name : profile name Field type <Gpon::FileProfPtr> - profile index - range: [0...100] Data driven field type Possible values are depending on the actual configuration and software. The currently allowed values can be shown with online-help.	<i>optional parameter with default value: "none"</i> uri profile
[no] repeat	Parameter type: <Gpon::RepetitionNbr> Format: - repetition number - range: [0...10]	<i>optional parameter with default value: 0L</i> number of times the tone file is repeated

41.25 GPON Reorder Tone Event Profile Configuration Command

Command Description

This command is used to change or configure the definition of a Reorder tone within the tone set.

As noted in the Tone Event Profile configuration command, the selection of the tone can be either via pointing to a Tone Sequence Profile, or by referencing a file on the ONT.

This command supports either mechanism.

User Level

The command can be accessed by operators with sip,megaco privileges, and executed by operators with sip,megaco privileges.

Command Syntax

The command has the following syntax:

```
> configure voice ont tone-event-prof (index) reorder-tone [ no tone-seq-prof | tone-seq-prof
<Gpon::ToneSeqProfile> ] [ no file-prof | file-prof <Gpon::FileProfile> ] [ no repeat | repeat
<Gpon::RepetitionNbr> ]
```

Command Parameters

Table 41.25-1 "GPON Reorder Tone Event Profile Configuration Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - tone event profile index - range: [1...5]	profile index

Table 41.25-2 "GPON Reorder Tone Event Profile Configuration Command" Command Parameters

Parameter	Type	Description
[no] tone-seq-prof	Parameter type: <Gpon::ToneSeqProfile> Format: (none <Gpon::ToneSeqProfPtr> name : <AsamProfileName>) Possible values: - none : no profile to associate - name : profile name Field type <Gpon::ToneSeqProfPtr> - profile index - range: [0...50] Data driven field type	<i>optional parameter with default value: "none"</i> tone sequence profile

Parameter	Type	Description
	Possible values are depending on the actual configuration and software. The currently allowed values can be shown with online-help.	
[no] file-prof	Parameter type: <Gpon::FileProfile> Format: (none <Gpon::FileProfPtr> name : <AsamProfileName>) Possible values: - none : no profile to associate - name : profile name Field type <Gpon::FileProfPtr> - profile index - range: [0...100] Data driven field type Possible values are depending on the actual configuration and software. The currently allowed values can be shown with online-help.	<i>optional parameter with default value: "none"</i> uri profile
[no] repeat	Parameter type: <Gpon::RepetitionNbr> Format: - repetition number - range: [0...10]	<i>optional parameter with default value: 0L</i> number of times the tone file is repeated

41.26 GPON Ring Back Tone Event Profile Configuration Command

Command Description

This command is used to change or configure the definition of a Ring Back tone within the tone set.

As noted in the Tone Event Profile configuration command, the selection of the tone can be either via pointing to a Tone Sequence Profile, or by referencing a file on the ONT.

This command supports either mechanism.

User Level

The command can be accessed by operators with sip,megaco privileges, and executed by operators with sip,megaco privileges.

Command Syntax

The command has the following syntax:

```
> configure voice ont tone-event-prof (index) ringback-tone [ no tone-seq-prof | tone-seq-prof
<Gpon::ToneSeqProfile> ] [ no file-prof | file-prof <Gpon::FileProfile> ] [ no repeat | repeat
<Gpon::RepetitionNbr> ]
```

Command Parameters

Table 41.26-1 "GPON Ring Back Tone Event Profile Configuration Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - tone event profile index - range: [1...5]	profile index

Table 41.26-2 "GPON Ring Back Tone Event Profile Configuration Command" Command Parameters

Parameter	Type	Description
[no] tone-seq-prof	Parameter type: <Gpon::ToneSeqProfile> Format: (none <Gpon::ToneSeqProfPtr> name : <AsamProfileName>) Possible values: - none : no profile to associate - name : profile name Field type <Gpon::ToneSeqProfPtr> - profile index - range: [0...50]	optional parameter with default value: "none" tone sequence profile

Parameter	Type	Description
	Data driven field type Possible values are depending on the actual configuration and software. The currently allowed values can be shown with online-help.	
[no] file-prof	Parameter type: <Gpon::FileProfile> Format: (none <Gpon::FileProfPtr> name : <AsamProfileName>) Possible values: - none : no profile to associate - name : profile name Field type <Gpon::FileProfPtr> - profile index - range: [0...100] Data driven field type Possible values are depending on the actual configuration and software. The currently allowed values can be shown with online-help.	<i>optional parameter with default value: "none"</i> uri profile
[no] repeat	Parameter type: <Gpon::RepetitionNbr> Format: - repetition number - range: [0...10]	<i>optional parameter with default value: 0L</i> number of times the tone file is repeated

41.27 GPON Roh Tone Event Profile Configuration Command

Command Description

This command is used to change or configure the definition of a Roh tone within the tone set.

As noted in the Tone Event Profile configuration command, the selection of the tone can be either via pointing to a Tone Sequence Profile, or by referencing a file on the ONT.

This command supports either mechanism.

User Level

The command can be accessed by operators with sip,megaco privileges, and executed by operators with sip,megaco privileges.

Command Syntax

The command has the following syntax:

```
> configure voice ont tone-event-prof (index) roh-tone [ no tone-seq-prof | tone-seq-prof <Gpon::ToneSeqProfile> ]
[ no file-prof | file-prof <Gpon::FileProfile> ] [ no repeat | repeat <Gpon::RepetitionNbr> ]
```

Command Parameters

Table 41.27-1 "GPON Roh Tone Event Profile Configuration Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - tone event profile index - range: [1...5]	profile index

Table 41.27-2 "GPON Roh Tone Event Profile Configuration Command" Command Parameters

Parameter	Type	Description
[no] tone-seq-prof	Parameter type: <Gpon::ToneSeqProfile> Format: (none <Gpon::ToneSeqProfPtr> name : <AsamProfileName>) Possible values: - none : no profile to associate - name : profile name Field type <Gpon::ToneSeqProfPtr> - profile index - range: [0...50] Data driven field type Possible values are depending on the actual configuration and software.	<i>optional parameter with default value: "none"</i> tone sequence profile

Parameter	Type	Description
	The currently allowed values can be shown with online-help.	
[no] file-prof	Parameter type: <Gpon::FileProfile> Format: (none <Gpon::FileProfPtr> name : <AsamProfileName>) Possible values: - none : no profile to associate - name : profile name Field type <Gpon::FileProfPtr> - profile index - range: [0...100] Data driven field type Possible values are depending on the actual configuration and software. The currently allowed values can be shown with online-help.	<i>optional parameter with default value: "none"</i> uri profile
[no] repeat	Parameter type: <Gpon::RepetitionNbr> Format: - repetition number - range: [0...10]	<i>optional parameter with default value: 0L</i> number of times the tone file is repeated

41.28 GPON Stutter Tone Event Profile Configuration Command

Command Description

This command is used to change or configure the definition of a Stutter tone within the tone set.

As noted in the Tone Event Profile configuration command, the selection of the tone can be either via pointing to a Tone Sequence Profile, or by referencing a file on the ONT.

This command supports either mechanism.

User Level

The command can be accessed by operators with sip,megaco privileges, and executed by operators with sip,megaco privileges.

Command Syntax

The command has the following syntax:

```
> configure voice ont tone-event-prof (index) stutter-tone [ no tone-seq-prof | tone-seq-prof
<Gpon::ToneSeqProfile> ] [ no file-prof | file-prof <Gpon::FileProfile> ] [ no repeat | repeat
<Gpon::RepetitionNbr> ]
```

Command Parameters

Table 41.28-1 "GPON Stutter Tone Event Profile Configuration Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - tone event profile index - range: [1...5]	profile index

Table 41.28-2 "GPON Stutter Tone Event Profile Configuration Command" Command Parameters

Parameter	Type	Description
[no] tone-seq-prof	Parameter type: <Gpon::ToneSeqProfile> Format: (none <Gpon::ToneSeqProfPtr> name : <AsamProfileName>) Possible values: - none : no profile to associate - name : profile name Field type <Gpon::ToneSeqProfPtr> - profile index - range: [0...50] Data driven field type Possible values are depending on the actual configuration	<i>optional parameter with default value: "none"</i> tone sequence profile

Parameter	Type	Description
	and software. The currently allowed values can be shown with online-help.	
[no] file-prof	Parameter type: <Gpon::FileProfile> Format: (none <Gpon::FileProfPtr> name : <AsamProfileName>) Possible values: - none : no profile to associate - name : profile name Field type <Gpon::FileProfPtr> - profile index - range: [0...100] Data driven field type Possible values are depending on the actual configuration and software. The currently allowed values can be shown with online-help.	<i>optional parameter with default value: "none"</i> uri profile
[no] repeat	Parameter type: <Gpon::RepetitionNbr> Format: - repetition number - range: [0...10]	<i>optional parameter with default value: 0L</i> number of times the tone file is repeated

41.29 GPON Intrusion Tone Event Profile Configuration Command

Command Description

This command is used to change or configure the definition of a Intrusion tone within the tone set.

As noted in the Tone Event Profile configuration command, the selection of the tone can be either via pointing to a Tone Sequence Profile, or by referencing a file on the ONT.

This command supports either mechanism

User Level

The command can be accessed by operators with sip,megaco privileges, and executed by operators with sip,megaco privileges.

Command Syntax

The command has the following syntax:

```
> configure voice ont tone-event-prof (index) intrusion-tone [ no tone-seq-prof | tone-seq-prof
<Gpon::ToneSeqProfile> ] [ no file-prof | file-prof <Gpon::FileProfile> ] [ no repeat | repeat
<Gpon::RepetitionNbr> ]
```

Command Parameters

Table 41.29-1 "GPON Intrusion Tone Event Profile Configuration Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - tone event profile index - range: [1...5]	profile index

Table 41.29-2 "GPON Intrusion Tone Event Profile Configuration Command" Command Parameters

Parameter	Type	Description
[no] tone-seq-prof	Parameter type: <Gpon::ToneSeqProfile> Format: (none <Gpon::ToneSeqProfPtr> name : <AsamProfileName>) Possible values: - none : no profile to associate - name : profile name Field type <Gpon::ToneSeqProfPtr> - profile index - range: [0...50]	optional parameter with default value: "none" tone sequence profile

Parameter	Type	Description
	Data driven field type Possible values are depending on the actual configuration and software. The currently allowed values can be shown with online-help.	
[no] file-prof	Parameter type: <Gpon::FileProfile> Format: (none <Gpon::FileProfPtr> name : <AsamProfileName>) Possible values: - none : no profile to associate - name : profile name Field type <Gpon::FileProfPtr> - profile index - range: [0...100] Data driven field type Possible values are depending on the actual configuration and software. The currently allowed values can be shown with online-help.	<i>optional parameter with default value: "none"</i> URI profile
[no] repeat	Parameter type: <Gpon::RepetitionNbr> Format: - repetition number - range: [0...10]	<i>optional parameter with default value: "0"</i> number of times the tone file is repeated

41.30 GPON Dead Tone Event Profile Configuration Command

Command Description

This command is used to change or configure the definition of a Dead tone within the tone set.

As noted in the Tone Event Profile configuration command, the selection of the tone can be either via pointing to a Tone Sequence Profile, or by referencing a file on the ONT.

This command supports either mechanism

User Level

The command can be accessed by operators with sip,megaco privileges, and executed by operators with sip,megaco privileges.

Command Syntax

The command has the following syntax:

```
> configure voice ont tone-event-prof (index) dead-tone [ no tone-seq-prof | tone-seq-prof <Gpon::ToneSeqProfile> ] [ no file-prof | file-prof <Gpon::FileProfile> ] [ no repeat | repeat <Gpon::RepetitionNbr> ]
```

Command Parameters

Table 41.30-1 "GPON Dead Tone Event Profile Configuration Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - tone event profile index - range: [1...5]	profile index

Table 41.30-2 "GPON Dead Tone Event Profile Configuration Command" Command Parameters

Parameter	Type	Description
[no] tone-seq-prof	Parameter type: <Gpon::ToneSeqProfile> Format: (none <Gpon::ToneSeqProfPtr> name : <AsamProfileName>) Possible values: - none : no profile to associate - name : profile name Field type <Gpon::ToneSeqProfPtr> - profile index - range: [0...50] Data driven field type Possible values are depending on the actual configuration and software.	<i>optional parameter with default value: "none"</i> tone segment profile

Parameter	Type	Description
	The currently allowed values can be shown with online-help.	
[no] file-prof	Parameter type: <Gpon::FileProfile> Format: (none <Gpon::FileProfPtr> name : <AsamProfileName>) Possible values: - none : no profile to associate - name : profile name Field type <Gpon::FileProfPtr> - profile index - range: [0...100] Data driven field type Possible values are depending on the actual configuration and software. The currently allowed values can be shown with online-help.	<i>optional parameter with default value: "none"</i> URI profile
[no] repeat	Parameter type: <Gpon::RepetitionNbr> Format: - repetition number - range: [0...10]	<i>optional parameter with default value: "0"</i> number of times the tone file is repeated

41.31 GPON First User Defined Tone Event Profile Configuration Command

Command Description

This command is used to change or configure the definition of a First User Defined tone within the tone set.

As noted in the Tone Event Profile configuration command, the selection of the tone can be either via pointing to a Tone Sequence Profile, or by referencing a file on the ONT.

This command supports either mechanism

User Level

The command can be accessed by operators with sip,megaco privileges, and executed by operators with sip,megaco privileges.

Command Syntax

The command has the following syntax:

```
> configure voice ont tone-event-prof (index) userdef1-tone [ no tone-seq-prof | tone-seq-prof
<Gpon::ToneSeqProfile> ] [ no file-prof | file-prof <Gpon::FileProfile> ] [ no repeat | repeat
<Gpon::RepetitionNbr> ]
```

Command Parameters

Table 41.31-1 "GPON First User Defined Tone Event Profile Configuration Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - tone event profile index - range: [1...5]	profile index

Table 41.31-2 "GPON First User Defined Tone Event Profile Configuration Command" Command Parameters

Parameter	Type	Description
[no] tone-seq-prof	Parameter type: <Gpon::ToneSeqProfile> Format: (none <Gpon::ToneSeqProfPtr> name : <AsamProfileName>) Possible values: - none : no profile to associate - name : profile name Field type <Gpon::ToneSeqProfPtr> - profile index - range: [0...50]	optional parameter with default value: "none" tone segment profile

Parameter	Type	Description
	Data driven field type Possible values are depending on the actual configuration and software. The currently allowed values can be shown with online-help.	
[no] file-prof	Parameter type: <Gpon::FileProfile> Format: (none <Gpon::FileProfPtr> name : <AsamProfileName>) Possible values: - none : no profile to associate - name : profile name Field type <Gpon::FileProfPtr> - profile index - range: [0...100] Data driven field type Possible values are depending on the actual configuration and software. The currently allowed values can be shown with online-help.	<i>optional parameter with default value: "none"</i> URI profile
[no] repeat	Parameter type: <Gpon::RepetitionNbr> Format: - repetition number - range: [0...10]	<i>optional parameter with default value: "0"</i> number of times the tone file is repeated

41.32 GPON Second User Defined Tone Event Profile Configuration Command

Command Description

This command is used to change or configure the definition of a Second User Defined tone within the tone set.

As noted in the Tone Event Profile configuration command, the selection of the tone can be either via pointing to a Tone Sequence Profile, or by referencing a file on the ONT.

This command supports either mechanism.

User Level

The command can be accessed by operators with sip,megaco privileges, and executed by operators with sip,megaco privileges.

Command Syntax

The command has the following syntax:

```
> configure voice ont tone-event-prof (index) userdef2-tone [ no tone-seq-prof | tone-seq-prof
<Gpon::ToneSeqProfile> ] [ no file-prof | file-prof <Gpon::FileProfile> ] [ no repeat | repeat
<Gpon::RepetitionNbr> ]
```

Command Parameters

Table 41.32-1 "GPON Second User Defined Tone Event Profile Configuration Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - tone event profile index - range: [1...5]	profile index

Table 41.32-2 "GPON Second User Defined Tone Event Profile Configuration Command" Command Parameters

Parameter	Type	Description
[no] tone-seq-prof	Parameter type: <Gpon::ToneSeqProfile> Format: (none <Gpon::ToneSeqProfPtr> name : <AsamProfileName>) Possible values: - none : no profile to associate - name : profile name Field type <Gpon::ToneSeqProfPtr> - profile index - range: [0...50]	optional parameter with default value: "none" tone segment profile

Parameter	Type	Description
	Data driven field type Possible values are depending on the actual configuration and software. The currently allowed values can be shown with online-help.	
[no] file-prof	Parameter type: <Gpon::FileProfile> Format: (none <Gpon::FileProfPtr> name : <AsamProfileName>) Possible values: - none : no profile to associate - name : profile name Field type <Gpon::FileProfPtr> - profile index - range: [0...100] Data driven field type Possible values are depending on the actual configuration and software. The currently allowed values can be shown with online-help.	<i>optional parameter with default value: "none"</i> URI profile
[no] repeat	Parameter type: <Gpon::RepetitionNbr> Format: - repetition number - range: [0...10]	<i>optional parameter with default value: "0"</i> number of times the tone file is repeated

41.33 GPON Third User Defined Tone Event Profile Configuration Command

Command Description

This command is used to change or configure the definition of a Third User Defined tone within the tone set.

As noted in the Tone Event Profile configuration command, the selection of the tone can be either via pointing to a Tone Sequence Profile, or by referencing a file on the ONT.

This command supports either mechanism.

User Level

The command can be accessed by operators with sip,megaco privileges, and executed by operators with sip,megaco privileges.

Command Syntax

The command has the following syntax:

```
> configure voice ont tone-event-prof (index) userdef3-tone [ no tone-seq-prof | tone-seq-prof
<Gpon::ToneSeqProfile> ] [ no file-prof | file-prof <Gpon::FileProfile> ] [ no repeat | repeat
<Gpon::RepetitionNbr> ]
```

Command Parameters

Table 41.33-1 "GPON Third User Defined Tone Event Profile Configuration Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - tone event profile index - range: [1...5]	profile index

Table 41.33-2 "GPON Third User Defined Tone Event Profile Configuration Command" Command Parameters

Parameter	Type	Description
[no] tone-seq-prof	Parameter type: <Gpon::ToneSeqProfile> Format: (none <Gpon::ToneSeqProfPtr> name : <AsamProfileName>) Possible values: - none : no profile to associate - name : profile name Field type <Gpon::ToneSeqProfPtr> - profile index - range: [0...50]	optional parameter with default value: "none" tone segment profile

Parameter	Type	Description
	Data driven field type Possible values are depending on the actual configuration and software. The currently allowed values can be shown with online-help.	
[no] file-prof	Parameter type: <Gpon::FileProfile> Format: (none <Gpon::FileProfPtr> name : <AsamProfileName>) Possible values: - none : no profile to associate - name : profile name Field type <Gpon::FileProfPtr> - profile index - range: [0...100] Data driven field type Possible values are depending on the actual configuration and software. The currently allowed values can be shown with online-help.	<i>optional parameter with default value: "none"</i> URI profile
[no] repeat	Parameter type: <Gpon::RepetitionNbr> Format: - repetition number - range: [0...10]	<i>optional parameter with default value: "0"</i> number of times the tone file is repeated

41.34 GPON Fourth User Defined Tone Event Profile Configuration Command

Command Description

This command is used to change or configure the definition of a Fourth User Defined tone within the tone set.

As noted in the Tone Event Profile configuration command, the selection of the tone can be either via pointing to a Tone Sequence Profile, or by referencing a file on the ONT.

This command supports either mechanism.

User Level

The command can be accessed by operators with sip,megaco privileges, and executed by operators with sip,megaco privileges.

Command Syntax

The command has the following syntax:

```
> configure voice ont tone-event-prof (index) userdef4-tone [ no tone-seq-prof | tone-seq-prof
<Gpon::ToneSeqProfile> ] [ no file-prof | file-prof <Gpon::FileProfile> ] [ no repeat | repeat
<Gpon::RepetitionNbr> ]
```

Command Parameters

Table 41.34-1 "GPON Fourth User Defined Tone Event Profile Configuration Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - tone event profile index - range: [1...5]	profile index

Table 41.34-2 "GPON Fourth User Defined Tone Event Profile Configuration Command" Command Parameters

Parameter	Type	Description
[no] tone-seq-prof	Parameter type: <Gpon::ToneSeqProfile> Format: (none <Gpon::ToneSeqProfPtr> name : <AsamProfileName>) Possible values: - none : no profile to associate - name : profile name Field type <Gpon::ToneSeqProfPtr> - profile index - range: [0...50]	optional parameter with default value: "none" tone segment profile

Parameter	Type	Description
	Data driven field type Possible values are depending on the actual configuration and software. The currently allowed values can be shown with online-help.	
[no] file-prof	Parameter type: <Gpon::FileProfile> Format: (none <Gpon::FileProfPtr> name : <AsamProfileName>) Possible values: - none : no profile to associate - name : profile name Field type <Gpon::FileProfPtr> - profile index - range: [0...100] Data driven field type Possible values are depending on the actual configuration and software. The currently allowed values can be shown with online-help.	<i>optional parameter with default value: "none"</i> URI profile
[no] repeat	Parameter type: <Gpon::RepetitionNbr> Format: - repetition number - range: [0...10]	<i>optional parameter with default value: "0"</i> number of times the tone file is repeated

41.35 GPON Network Dial Plan Profile Configuration Command

Command Description

This command creates a profile that defines a Network Dial Plan.

User Level

The command can be accessed by operators with sip,megaco privileges, and executed by operators with sip,megaco privileges.

Command Syntax

The command has the following syntax:

```
> configure voice ont ( no nwdial-plan-prof (index) ) | ( nwdial-plan-prof (index) name <AsamProfileName> [ no
critical-timeout | critical-timeout <Gpon::TimeOut> ] [ no partial-timout | partial-timout <Gpon::TimeOut> ] [ no
format | format <Gpon::PlanFormat> ] [ digitmap1 <Gpon::Digit> ] [ digitmap2 <Gpon::Digit> ] [ digitmap3
<Gpon::Digit> ] [ digitmap4 <Gpon::Digit> ] )
```

Command Parameters

Table 41.35-1 "GPON Network Dial Plan Profile Configuration Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - profile index - range: [1...20]	network dial plan profile

Table 41.35-2 "GPON Network Dial Plan Profile Configuration Command" Command Parameters

Parameter	Type	Description
name	Parameter type: <AsamProfileName> Format: - a profile name - range: [a-zA-Z0-9-_.] - length: 1<=x<=32	mandatory parameter The parameter is not visible during modification. name of profile
[no] critical-timeout	Parameter type: <Gpon::TimeOut> Format: - dial timeout - unit: sec - range: [1.000...40.000]	optional parameter with default value: 4L The parameter is not visible during modification. critical dial timeout in seconds
[no] partial-timout	Parameter type: <Gpon::TimeOut> Format: - dial timeout - unit: sec - range: [1.000...40.000]	optional parameter with default value: 16L The parameter is not visible during modification. partial dial timeout in seconds
[no] format	Parameter type: <Gpon::PlanFormat>	optional parameter with default

Parameter	Type	Description
	Format: (not-def h248 nsc) Possible values: - not-def : not defined - h248 : h.248 format using dial plan tokens - nsc : nsc format	<i>value: "h248"</i> <i>The parameter is not visible during modification.</i> specifies the dial plan format
digitmap1	Parameter type: <Gpon::Digit> Format: - ASCII character string - length: x<=256	<i>optional parameter</i> <i>The parameter is not visible during modification.</i> specifies part 1 of the actual digit map ascii symbols with delimiter '1'
digitmap2	Parameter type: <Gpon::Digit> Format: - ASCII character string - length: x<=256	<i>optional parameter</i> <i>The parameter is not visible during modification.</i> specifies part 2 of the actual digit map ascii symbols with delimiter '1'
digitmap3	Parameter type: <Gpon::Digit> Format: - ASCII character string - length: x<=256	<i>optional parameter</i> <i>The parameter is not visible during modification.</i> specifies part 3 of the actual digit map ascii symbols with delimiter '1'
digitmap4	Parameter type: <Gpon::Digit> Format: - ASCII character string - length: x<=256	<i>optional parameter</i> <i>The parameter is not visible during modification.</i> specifies part 4 of the actual digit map ascii symbols with delimiter '1'

41.36 Create a RTP profile

Command Description

This command creates a RTP profile which provides information required by Real Time Protocol.

User Level

The command can be accessed by operators with sip,megaco privileges, and executed by operators with sip,megaco privileges.

Command Syntax

The command has the following syntax:

```
> configure voice ont ( no rtp-profile (index) ) | ( rtp-profile (index) name <Gpon::RtpProfileName> [ no
local-port-min | local-port-min <Gpon::LocalPortMin> ] [ no local-port-max | local-port-max
<Gpon::LocalPortMax> ] [ no dscp | dscp <Gpon::Dscp> ] [ no piggy-back-event | piggy-back-event
<Gpon::PiggyBackEvent> ] [ no tone-event | tone-event <Gpon::ToneEvent> ] [ no dtmf-event | dtmf-event
<Gpon::DtmfEvent> ] [ no cas-event | cas-event <Gpon::CasEvent> ] )
```

Command Parameters

Table 41.36-1 "Create a RTP profile" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - access identifier - range: [1...10]	access identifier of rtp profile

Table 41.36-2 "Create a RTP profile" Command Parameters

Parameter	Type	Description
name	Parameter type: <Gpon::RtpProfileName> Format: - unique rtp profile name - length: 1<=x<=32	mandatory parameter The parameter is not visible during modification. unique rtp profile name
[no] local-port-min	Parameter type: <Gpon::LocalPortMin> Format: - Local port - range: [5000...65000]	optional parameter with default value: 50000L The parameter is not visible during modification. base rtp port for voice traffic
[no] local-port-max	Parameter type: <Gpon::LocalPortMax> Format: - Local port - range: [5000...65000]	optional parameter with default value: 60000L The parameter is not visible during modification. highest rtp port for voice traffic
[no] dscp	Parameter type: <Gpon::Dscp> Format: - dscp setting - range: [0...63]	optional parameter with default value: 46L The parameter is not visible during modification.

Parameter	Type	Description
		value of dscp setting to use in ip header
[no] piggy-back-event	Parameter type: <Gpon::PiggyBackEvent> Format: (disabled enabled) Possible values: - disabled : disabled rtp piggyback events - enabled : enabled rtp poggyback events	<i>optional parameter with default value: "disabled"</i> <i>The parameter is not visible during modification.</i> handling of rtp piggy back events
[no] tone-event	Parameter type: <Gpon::ToneEvent> Format: (disabled enabled) Possible values: - disabled : disabled rtp tone events - enabled : enabled rtp tone events	<i>optional parameter with default value: "disabled"</i> <i>The parameter is not visible during modification.</i> handling tones via rtp tones
[no] dtmf-event	Parameter type: <Gpon::DtmfEvent> Format: (disabled enabled) Possible values: - disabled : disabled rtp dtmf events - enabled : enabled rtp dtmf events	<i>optional parameter with default value: "disabled"</i> <i>The parameter is not visible during modification.</i> handling dtmf via rtp dtmf
[no] cas-event	Parameter type: <Gpon::CasEvent> Format: (disabled enabled) Possible values: - disabled : disabled rtp cas events - enabled : enabled rtp cas events	<i>optional parameter with default value: "disabled"</i> <i>The parameter is not visible during modification.</i> handling cas via rtp cas

41.37 Create a Voice Service profile

Command Description

This command creates a Voice Service profile which provides information required voice service function.

User Level

The command can be accessed by operators with sip,megaco privileges, and executed by operators with sip,megaco privileges.

Command Syntax

The command has the following syntax:

```
> configure voice ont ( no voice-serv-prof (index) ) | ( voice-serv-prof (index) name
<Gpon::VoiceServiceProfileName> [ no securi-prof | securi-prof <Gpon::SecureUriProfilePointer> ] [ no
toneset-prof | toneset-prof <Gpon::ToneEventProfilePointer> ] [ no ringingset-prof | ringingset-prof
<Gpon::RingEventProfilePointer> ] [ no announce-type | announce-type <Gpon::AnnounceType> ] [ no jitter-target
| jitter-target <Gpon::JitterTarget> ] [ no jitter-max | jitter-max <Gpon::JitterMax> ] [ no echo-cancel | echo-cancel
<Gpon::EchoCancel> ] [ no dtmf-level | dtmf-level <Gpon::DtmfLevel> ] [ no dtmf-duration | dtmf-duration
<Gpon::DtmfDuration> ] [ no hook-flash-min | hook-flash-min <Gpon::HookFlashMin> ] [ no hook-flash-max |
hook-flash-max <Gpon::HookFlashMax> ] [ no pstn-variant | pstn-variant <Gpon::PstnVariant> ] )
```

Command Parameters

Table 41.37-1 "Create a Voice Service profile" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - access identifier - range: [1...10]	access identifier of voice service profile

Table 41.37-2 "Create a Voice Service profile" Command Parameters

Parameter	Type	Description
name	Parameter type: <Gpon::VoiceServiceProfileName> Format: - unique voip media profile name - length: 1<=x<=32	<i>mandatory parameter</i> <i>The parameter is not visible during modification.</i> unique voice service profile name
[no] securi-prof	Parameter type: <Gpon::SecureUriProfilePointer> Format: (none <Gpon::SecureUriProfilePointer> name : <AsamProfileName>) Possible values: - none : no profile to associate - name : profile name Field type <Gpon::SecureUriProfilePointer> - profile index - range: [0...50]	<i>optional parameter with default value: 0L</i> <i>The parameter is not visible during modification.</i> voice service security profile pointer

Parameter	Type	Description
	Data driven field type Possible values are depending on the actual configuration and software. The currently allowed values can be shown with online-help.	
[no] toneset-prof	Parameter type: <Gpon::ToneEventProfilePointer> Format: (none <Gpon::ToneEventProfilePointer> name : <AsamProfileName>) Possible values: - none : no profile to associate - name : profile name Field type <Gpon::ToneEventProfilePointer> - profile index - range: [0...5] Data driven field type Possible values are depending on the actual configuration and software. The currently allowed values can be shown with online-help.	<i>optional parameter with default value: 0L</i> <i>The parameter is not visible during modification.</i> tone set profile it contains tone definitions
[no] ringingset-prof	Parameter type: <Gpon::RingEventProfilePointer> Format: (none <Gpon::RingEventProfilePointer> name : <AsamProfileName>) Possible values: - none : no profile to associate - name : profile name Field type <Gpon::RingEventProfilePointer> - profile index - range: [0...5] Data driven field type Possible values are depending on the actual configuration and software. The currently allowed values can be shown with online-help.	<i>optional parameter with default value: 0L</i> <i>The parameter is not visible during modification.</i> ringing set profile
[no] announce-type	Parameter type: <Gpon::AnnounceType> Format: (silence recorder-tone fast-busy voice not-applicable) Possible values: - silence : silence - recorder-tone : recorder type - fast-busy : fast busy - voice : voice - not-applicable : not applicable	<i>optional parameter with default value: 255L</i> <i>The parameter is not visible during modification.</i> treatment when subscriber goes off-hook
[no] jitter-target	Parameter type: <Gpon::JitterTarget> Format: - jitter target - range: [0...65535]	<i>optional parameter with default value: 0L</i> <i>The parameter is not visible during modification.</i> target value of jitter buffer in msec
[no] jitter-max	Parameter type: <Gpon::JitterMax> Format: - jitter max - range: [0...65535]	<i>optional parameter with default value: 0L</i> <i>The parameter is not visible during modification.</i>

41 Voice Ont Configuration Commands

Parameter	Type	Description
		max buffer value of jitter buffer in msec
[no] echo-cancel	Parameter type: <Gpon::EchoCancel> Format: (disabled enabled) Possible values: - disabled : disabled echo cancellation - enabled : enabled echo cancellation	<i>optional parameter with default value: 1L</i> <i>The parameter is not visible during modification.</i> enable or disable echo cancellation
[no] dtmf-level	Parameter type: <Gpon::DtmfLevel> Format: - dtmf level - range: [-25...-3,0]	<i>optional parameter with default value: 0L</i> <i>The parameter is not visible during modification.</i> power level of dtmf tone
[no] dtmf-duration	Parameter type: <Gpon::DtmfDuration> Format: - dtmf duration - range: [0...65535]	<i>optional parameter with default value: 0L</i> <i>The parameter is not visible during modification.</i> duration the tone being sent to subscriber
[no] hook-flash-min	Parameter type: <Gpon::HookFlashMin> Format: - hook flash min - range: [0...65535]	<i>optional parameter with default value: 0L</i> <i>The parameter is not visible during modification.</i> minimum duration to determine a hook flash event
[no] hook-flash-max	Parameter type: <Gpon::HookFlashMax> Format: - hook flash max - range: [0...65535]	<i>optional parameter with default value: 0L</i> <i>The parameter is not visible during modification.</i> maximum duration to determine a hook flash event
[no] pstn-variant	Parameter type: <Gpon::PstnVariant> Format: - country code for the pots line - range: [0...999]	<i>optional parameter with default value: 0L</i> <i>The parameter is not visible during modification.</i> current country code for pots line

Command Output

Table 41.37-3 "Create a Voice Service profile" Display parameters

Specific Information		
name	Type	Description
securi-prof-name	Parameter type: <Gpon::IgnoredPrintableString> - ignored printable string	security profile pointer <i>This element is always shown.</i>
toneset-prof-name	Parameter type: <Gpon::IgnoredPrintableString> - ignored printable string	tone event profile pointer <i>This element is always shown.</i>
ringingset-prof-name	Parameter type: <Gpon::IgnoredPrintableString> - ignored printable string	ringing set event profile pointer <i>This element is always shown.</i>

41.38 Create a VOIP Application Service Profile

Command Description

This command creates a VOIP Application service profile which provides configuration information regarding calling features.

User Level

The command can be accessed by operators with sip,megaco privileges, and executed by operators with sip,megaco privileges.

Command Syntax

The command has the following syntax:

```
> configure voice ont ( no voip-app-service (index) ) | ( voip-app-service (index) name
<Gpon::VoipAppProfileName> [ no calling-number | calling-number <Gpon::CidCallingNumber> ] [ no
calling-name | calling-name <Gpon::CidCallingName> ] [ no caller-id-block | caller-id-block
<Gpon::CidCidBlock> ] [ no caller-id-number | caller-id-number <Gpon::CidCidNumber> ] [ no caller-id-name |
caller-id-name <Gpon::CidCidName> ] [ no anonymous-block | anonymous-block <Gpon::CidAcr> ] [ no
call-waiting | call-waiting <Gpon::CwaitCallWaiting> ] [ no callerid-announce | callerid-announce
<Gpon::CwaitIdAnnounce> ] [ no three-way-calling | three-way-calling <Gpon::Ctrans3WayCalling> ] [ no
call-transfer | call-transfer <Gpon::CtransCallTransfer> ] [ no call-hold | call-hold <Gpon::CtransCallHold> ] [ no
call-park | call-park <Gpon::CtransCallPark> ] [ no do-not-disturb | do-not-disturb <Gpon::CtransDoNotDisturb> ]
[ no flash-on-emerg-cal | flash-on-emerg-cal <Gpon::CtransFlashOnEmergency> ] [ no emer-ser-org-hold |
emer-ser-org-hold <Gpon::CtransEmergencyServiceOrginateHold> ] [ no six-way-calling | six-way-calling
<Gpon::Ctrans6WayCalling> ] [ no mwi-splash-ring | mwi-splash-ring <Gpon::CpresentMwiSplashRing> ] [ no
mwi-spl-dialtone | mwi-spl-dialtone <Gpon::CpresentMwiSpecialDialtone> ] [ no mwi-visual-indi |
mwi-visual-indi <Gpon::CpresentMwiVisualIndication> ] [ no call-fwd-indicate | call-fwd-indicate
<Gpon::CpresentCallFwdIndicate> ] [ no dir-conn-feature | dir-conn-feature <Gpon::DirConnFeature> ] [ no
dialtone-dely-opt | dialtone-dely-opt <Gpon::DialtoneDelayOpt> ] [ no dir-conn-prof | dir-conn-prof
<Gpon::DirConnectProfilePointer> ] [ no bridge-prof | bridge-prof <Gpon::BridgeProfilePointer> ] [ no conf-prof |
conf-prof <Gpon::ConfProfilePointer> ] )
```

Command Parameters

Table 41.38-1 "Create a VOIP Application Service Profile" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - access identifier - range: [1...20]	an access identifier index

Table 41.38-2 "Create a VOIP Application Service Profile" Command Parameters

Parameter	Type	Description
name	Parameter type: <Gpon::VoipAppProfileName> Format: - unique voip app profile name - length: 1<=x<=32	<i>mandatory parameter</i> <i>The parameter is not visible during modification.</i> unique voip app service profile

41 Voice Ont Configuration Commands

Parameter	Type	Description
[no] calling-number	Parameter type: <Gpon::CidCallingNumber> Format: (disable enable) Possible values: - disable : disable - enable : enable	name <i>optional parameter with default value: "disable"</i> <i>The parameter is not visible during modification.</i> caller id supports calling number
[no] calling-name	Parameter type: <Gpon::CidCallingName> Format: (disable enable) Possible values: - disable : disable - enable : enable	<i>optional parameter with default value: "disable"</i> <i>The parameter is not visible during modification.</i> caller id supports calling name
[no] caller-id-block	Parameter type: <Gpon::CidCidBlock> Format: (disable enable) Possible values: - disable : disable - enable : enable	<i>optional parameter with default value: "disable"</i> <i>The parameter is not visible during modification.</i> block both cid number and name
[no] caller-id-number	Parameter type: <Gpon::CidCidNumber> Format: (public private) Possible values: - public : disable - private : enable	<i>optional parameter with default value: "public"</i> <i>The parameter is not visible during modification.</i> permanent presentation status for number
[no] caller-id-name	Parameter type: <Gpon::CidCidName> Format: (public private) Possible values: - public : disable - private : enable	<i>optional parameter with default value: "public"</i> <i>The parameter is not visible during modification.</i> permanent presentation status for name
[no] anonymous-block	Parameter type: <Gpon::CidAcr> Format: (disable enable) Possible values: - disable : disable - enable : enable	<i>optional parameter with default value: "disable"</i> <i>The parameter is not visible during modification.</i> anonymous cid blocking
[no] call-waiting	Parameter type: <Gpon::CwaitCallWaiting> Format: (disable enable) Possible values: - disable : disable - enable : enable	<i>optional parameter with default value: "disable"</i> <i>The parameter is not visible during modification.</i> call waiting feature supported
[no] callerid-announce	Parameter type: <Gpon::CwaitIdAnnounce> Format: (disable enable) Possible values: - disable : disable - enable : enable	<i>optional parameter with default value: "disable"</i> <i>The parameter is not visible during modification.</i> caller id announcement feature supported

Parameter	Type	Description
[no] three-way-calling	Parameter type: <Gpon::Ctrans3WayCalling> Format: (disable enable) Possible values: - disable : disable - enable : enable	optional parameter with default value: "disable" The parameter is not visible during modification. 3 way calling
[no] call-transfer	Parameter type: <Gpon::CtransCallTransfer> Format: (disable enable) Possible values: - disable : disable - enable : enable	optional parameter with default value: "disable" The parameter is not visible during modification. call transfer supported
[no] call-hold	Parameter type: <Gpon::CtransCallHold> Format: (disable enable) Possible values: - disable : disable - enable : enable	optional parameter with default value: "disable" The parameter is not visible during modification. call hold
[no] call-park	Parameter type: <Gpon::CtransCallPark> Format: (disable enable) Possible values: - disable : disable - enable : enable	optional parameter with default value: "disable" The parameter is not visible during modification. call park
[no] do-not-disturb	Parameter type: <Gpon::CtransDoNotDisturb> Format: (disable enable) Possible values: - disable : disable - enable : enable	optional parameter with default value: "disable" The parameter is not visible during modification. do not disturb
[no] flash-on-emerg-cal	Parameter type: <Gpon::CtransFlashOnEmergency> Format: (disable enable) Possible values: - disable : disable - enable : enable	optional parameter with default value: "disable" The parameter is not visible during modification. flash on emergency call
[no] emer-ser-org-hold	Parameter type: <Gpon::CtransEmergencyServiceOriginateHold> Format: (disable enable) Possible values: - disable : disable - enable : enable	optional parameter with default value: "disable" The parameter is not visible during modification. emergency service originate hold
[no] six-way-calling	Parameter type: <Gpon::Ctrans6WayCalling> Format: (disable enable) Possible values: - disable : disable - enable : enable	optional parameter with default value: "disable" The parameter is not visible during modification. 6 way calling

41 Voice Ont Configuration Commands

Parameter	Type	Description
[no] mwi-splash-ring	Parameter type: <Gpon::CpresentMwiSplashRing> Format: (disable enable) Possible values: - disable : disable - enable : enable	<i>optional parameter with default value: "disable"</i> <i>The parameter is not visible during modification.</i> message waiting indication splash ring
[no] mwi-spl-dialtone	Parameter type: <Gpon::CpresentMwiSpecialDialtone> Format: (disable enable) Possible values: - disable : disable - enable : enable	<i>optional parameter with default value: "disable"</i> <i>The parameter is not visible during modification.</i> message waiting indication special dial tone
[no] mwi-visual-indi	Parameter type: <Gpon::CpresentMwiVisualIndication> Format: (disable enable) Possible values: - disable : disable - enable : enable	<i>optional parameter with default value: "disable"</i> <i>The parameter is not visible during modification.</i> message waiting indication visual indication
[no] call-fwd-indicate	Parameter type: <Gpon::CpresentCallFwdIndicate> Format: (disable enable) Possible values: - disable : disable - enable : enable	<i>optional parameter with default value: "disable"</i> <i>The parameter is not visible during modification.</i> call forwarding indication
[no] dir-conn-feature	Parameter type: <Gpon::DirConnFeature> Format: (disable enable) Possible values: - disable : disable - enable : enable	<i>optional parameter with default value: "disable"</i> <i>The parameter is not visible during modification.</i> direct connect feature
[no] dialtone-dely-opt	Parameter type: <Gpon::DialtoneDelayOpt> Format: (disable enable) Possible values: - disable : disable - enable : enable	<i>optional parameter with default value: "disable"</i> <i>The parameter is not visible during modification.</i> dial tone delay option
[no] dir-conn-prof	Parameter type: <Gpon::DirConnectProfilePointer> Format: (none <Gpon::DirConnectProfilePointer> name : <AsamProfileName>) Possible values: - none : no profile to associate - name : profile name Field type <Gpon::DirConnectProfilePointer> - profile index - range: [0...50] Data driven field type Possible values are depending on the actual configuration and software. The currently allowed values can be shown with online-help.	<i>optional parameter with default value: 0L</i> <i>The parameter is not visible during modification.</i> secure uri profile that contains ip of address of direct connect

Parameter	Type	Description
[no] bridge-prof	Parameter type: <Gpon::BridgeProfilePointer> Format: (none <Gpon::BridgeProfilePointer> name : <AsamProfileName>) Possible values: - none : no profile to associate - name : profile name Field type <Gpon::BridgeProfilePointer> - profile index - range: [0...50] Data driven field type Possible values are depending on the actual configuration and software. The currently allowed values can be shown with online-help.	<i>optional parameter with default value: 0L</i> <i>The parameter is not visible during modification.</i> secure uri profile that contains ip address of bridge line agent
[no] conf-prof	Parameter type: <Gpon::ConfProfilePointer> Format: (none <Gpon::ConfProfilePointer> name : <AsamProfileName>) Possible values: - none : no profile to associate - name : profile name Field type <Gpon::ConfProfilePointer> - profile index - range: [0...50] Data driven field type Possible values are depending on the actual configuration and software. The currently allowed values can be shown with online-help.	<i>optional parameter with default value: 0L</i> <i>The parameter is not visible during modification.</i> secure uri profile that contains ip address of conference factory

Command Output

Table 41.38-3 "Create a VOIP Application Service Profile" Display parameters

Specific Information		
name	Type	Description
dir-conn-prof-name	Parameter type: <Gpon::IgnoredPrintableString> - ignored printable string	name of the secure uri profile pointer <i>This element is always shown.</i>
bridge-prof-name	Parameter type: <Gpon::IgnoredPrintableString> - ignored printable string	name of the secure uri profile pointer <i>This element is always shown.</i>
conf-prof-name	Parameter type: <Gpon::IgnoredPrintableString> - ignored printable string	name of the secure uri profile pointer <i>This element is always shown.</i>

41.39 Create a VOIP media profile

Command Description

This command creates a VOIP media profile which provides information pertaining to voice encoding.

User Level

The command can be accessed by operators with sip,megaco privileges, and executed by operators with sip,megaco privileges.

Command Syntax

The command has the following syntax:

```
> configure voice ont ( no voip-media-prof (index) ) | ( voip-media-prof (index) name
<Gpon::VoipMediaProfileName> [ no voiceserviceprof | voiceserviceprof <Gpon::VoiceServiceProfilePointer> ] [
no rtp-prof | rtp-prof <Gpon::RtpProfilePointer> ] [ no fax-mode | fax-mode <Gpon::FaxMode> ] [ no codec1st |
codec1st <Gpon::CodecOrder> ] [ no pkt-period1st | pkt-period1st <Gpon::PktPeriodOrd> ] [ no silence1st |
silence1st <Gpon::SilenceOrder> ] [ no codec2nd | codec2nd <Gpon::CodecOrder> ] [ no pkt-period2nd |
pkt-period2nd <Gpon::PktPeriodOrd> ] [ no silence2nd | silence2nd <Gpon::SilenceOrder> ] [ no codec3rd |
codec3rd <Gpon::CodecOrder> ] [ no pkt-period3rd | pkt-period3rd <Gpon::PktPeriodOrd> ] [ no silence3rd |
silence3rd <Gpon::SilenceOrder> ] [ no codec4th | codec4th <Gpon::CodecOrder> ] [ no pkt-period4th |
pkt-period4th <Gpon::PktPeriodOrd> ] [ no silence4th | silence4th <Gpon::SilenceOrder> ] [ no outofband-dtmf |
outofband-dtmf <Gpon::OutOfBand> ] )
```

Command Parameters

Table 41.39-1 "Create a VOIP media profile" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - access identifier - range: [1...10]	access identifier of voip media profile

Table 41.39-2 "Create a VOIP media profile" Command Parameters

Parameter	Type	Description
name	Parameter type: <Gpon::VoipMediaProfileName> Format: - unique voip media profile name - length: 1<=x<=32	<i>mandatory parameter</i> <i>The parameter is not visible during modification.</i> unique voip media profile name
[no] voiceserviceprof	Parameter type: <Gpon::VoiceServiceProfilePointer> Format: (none <Gpon::VoiceServiceProfilePointer> name : <AsamProfileName>) Possible values: - none : no profile to associate - name : profile name Field type <Gpon::VoiceServiceProfilePointer>	<i>optional parameter with default value: 0L</i> <i>The parameter is not visible during modification.</i> voice service profile pointer

Parameter	Type	Description
	- profile index - range: [0...10] Data driven field type Possible values are depending on the actual configuration and software. The currently allowed values can be shown with online-help.	
[no] rtp-prof	Parameter type: <Gpon::RtpProfilePointer> Format: (none <Gpon::RtpProfilePointer> name : <AsamProfileName>) Possible values: - none : no profile to associate - name : profile name Field type <Gpon::RtpProfilePointer> - profile index - range: [0...10] Data driven field type Possible values are depending on the actual configuration and software. The currently allowed values can be shown with online-help.	<i>optional parameter with default value: 0L</i> <i>The parameter is not visible during modification.</i> rtp profile
[no] fax-mode	Parameter type: <Gpon::FaxMode> Format: (passthru t.38) Possible values: - passthru : passthru mode - t.38 : t.38 mode	<i>optional parameter with default value: "passthru"</i> <i>The parameter is not visible during modification.</i> defines how to handle fax calls
[no] codec1st	Parameter type: <Gpon::CodecOrder> Format: (pcmu unknown unknown gsm g723 div4.8 div4.16 lpc pcma g722 116.2 116.1 qcelp cn mpa g728 div4.11 div4.22 g729) Possible values: - pcmu : pcmu - unknown : reserved - unknown : reserved - gsm : gsm - g723 : g723 - div4.8 : div4.8 - div4.16 : div4.16	<i>optional parameter with default value: "pcmu"</i> <i>The parameter is not visible during modification.</i> codec selection option

41 Voice Ont Configuration Commands

Parameter	Type	Description
	- lpc : lpc - pcma : pcma - g722 : g722 - l16.2 : l16.2 - l16.1 : l16.1 - qcelp : qcelp - cn : cn - mpa : mpa - g728 : g728 - div4.11 : div4.11 - div4.22 : div4.22 - g729 : g729	
[no] pkt-period1st	Parameter type: <Gpon::PktPeriodOrd> Format: - packet period order - range: [10...30]	<i>optional parameter with default value: 10L</i> <i>The parameter is not visible during modification.</i> packet period selection option
[no] silence1st	Parameter type: <Gpon::SilenceOrder> Format: (off on) Possible values: - off : off - on : on	<i>optional parameter with default value: "off"</i> <i>The parameter is not visible during modification.</i> silence suppression selection mode
[no] codec2nd	Parameter type: <Gpon::CodecOrder> Format: (pcmu unknown unknown gsm g723 div4.8 div4.16 lpc pcma g722 l16.2 l16.1 qcelp cn mpa g728 div4.11 div4.22 g729) Possible values: - pcmu : pcmu - unknown : reserved - unknown : reserved - gsm : gsm - g723 : g723 - div4.8 : div4.8 - div4.16 : div4.16 - lpc : lpc - pcma : pcma - g722 : g722 - l16.2 : l16.2	<i>optional parameter with default value: "pcmu"</i> <i>The parameter is not visible during modification.</i> codec selection option

Parameter	Type	Description
	- l16.1 : l16.1 - qcelp : qcelp - cn : cn - mpa : mpa - g728 : g728 - div4.11 : div4.11 - div4.22 : div4.22 - g729 : g729	
[no] pkt-period2nd	Parameter type: <Gpon::PktPeriodOrd> Format: - packet period order - range: [10...30]	<i>optional parameter with default value: 10L</i> <i>The parameter is not visible during modification.</i> packet period selection option
[no] silence2nd	Parameter type: <Gpon::SilenceOrder> Format: (off on) Possible values: - off : off - on : on	<i>optional parameter with default value: "off"</i> <i>The parameter is not visible during modification.</i> silence suppression selection mode
[no] codec3rd	Parameter type: <Gpon::CodecOrder> Format: (pcmu unknown unknown gsm g723 div4.8 div4.16 lpc pcma g722 l16.2 l16.1 qcelp cn mpa g728 div4.11 div4.22 g729) Possible values: - pcmu : pcmu - unknown : reserved - unknown : reserved - gsm : gsm - g723 : g723 - div4.8 : div4.8 - div4.16 : div4.16 - lpc : lpc - pcma : pcma - g722 : g722 - l16.2 : l16.2 - l16.1 : l16.1 - qcelp : qcelp - cn : cn - mpa : mpa	<i>optional parameter with default value: "pcmu"</i> <i>The parameter is not visible during modification.</i> codec selection option

41 Voice Ont Configuration Commands

Parameter	Type	Description
	- g728 : g728 - div4.11 : div4.11 - div4.22 : div4.22 - g729 : g729	
[no] pkt-period3rd	Parameter type: <Gpon::PktPeriodOrd> Format: - packet period order - range: [10...30]	<i>optional parameter with default value: 10L</i> <i>The parameter is not visible during modification.</i> packet period selection option
[no] silence3rd	Parameter type: <Gpon::SilenceOrder> Format: (off on) Possible values: - off : off - on : on	<i>optional parameter with default value: "off"</i> <i>The parameter is not visible during modification.</i> silence suppression selection mode
[no] codec4th	Parameter type: <Gpon::CodecOrder> Format: (pcmu unknown unknown gsm g723 div4.8 div4.16 lpc pcma g722 l16.2 l16.1 qcelp cn mpa g728 div4.11 div4.22 g729) Possible values: - pcmu : pcmu - unknown : reserved - unknown : reserved - gsm : gsm - g723 : g723 - div4.8 : div4.8 - div4.16 : div4.16 - lpc : lpc - pcma : pcma - g722 : g722 - l16.2 : l16.2 - l16.1 : l16.1 - qcelp : qcelp - cn : cn - mpa : mpa - g728 : g728 - div4.11 : div4.11 - div4.22 : div4.22 - g729 : g729	<i>optional parameter with default value: "pcmu"</i> <i>The parameter is not visible during modification.</i> codec selection option

Parameter	Type	Description
[no] pkt-period4th	Parameter type: <Gpon::PktPeriodOrd> Format: - packet period order - range: [10...30]	<i>optional parameter with default value: 10L</i> <i>The parameter is not visible during modification.</i> packet period selection option
[no] silence4th	Parameter type: <Gpon::SilenceOrder> Format: (off on) Possible values: - off : off - on : on	<i>optional parameter with default value: "off"</i> <i>The parameter is not visible during modification.</i> silence suppression selection mode
[no] outofband-dtmf	Parameter type: <Gpon::OutOfBand> Format: (disabled enabled) Possible values: - disabled : dtmf are carried in pcm streams - enabled : dtmf signals are carried out of band	<i>optional parameter with default value: "enabled"</i> <i>The parameter is not visible during modification.</i> selects out of band dtmf carriage

Command Output

Table 41.39-3 "Create a VOIP media profile" Display parameters

Specific Information		
name	Type	Description
voiceserviceprof-name	Parameter type: <Gpon::IgnoredPrintableString> - ignored printable string	voice service profile pointer <i>This element is always shown.</i>
rtp-prof-name	Parameter type: <Gpon::IgnoredPrintableString> - ignored printable string	rtp profile pointer <i>This element is always shown.</i>

41.40 GPON Ringing Pattern Profile Configuration Command

Command Description

This command creates a profile that defines a ringing segment including duration or whether it is silent. Multiple ringing segment profiles are used to specify the ringing that will be applied to the analog line to ring the phone. Only two types of ringing are supported ("normal" or "splash") are supported via this method..

User Level

The command can be accessed by operators with sip,megaco privileges, and executed by operators with sip,megaco privileges.

Command Syntax

The command has the following syntax:

```
> configure voice ont ( no ring-seg-prof (index) ) | ( ring-seg-prof (index) name <AsamProfileName> [ no
profile-ring | profile-ring <Gpon::ProfileRing> ] ring-duration <Gpon::RingDuration> )
```

Command Parameters

Table 41.40-1 "GPON Ringing Pattern Profile Configuration Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - profile index - range: [1...20]	index of profile

Table 41.40-2 "GPON Ringing Pattern Profile Configuration Command" Command Parameters

Parameter	Type	Description
name	Parameter type: <AsamProfileName> Format: - a profile name - range: [a-zA-Z0-9-_.] - length: 1<=x<=32	<i>mandatory parameter</i> <i>The parameter is not visible during modification.</i> name of profile
[no] profile-ring	Parameter type: <Gpon::ProfileRing> Format: (ringing silent) Possible values: - ringing : supplies ringing - silent : specifies a silent period	<i>optional parameter with default value: "ringing"</i> <i>The parameter is not visible during modification.</i> Ringing sequence profile.
ring-duration	Parameter type: <Gpon::RingDuration> Format: - duration of the tone segment in (msec). - unit: msec	<i>mandatory parameter</i> <i>The parameter is not visible during modification.</i> Valid values are 0 to 65535 (0 to

41 Voice Ont Configuration Commands

Parameter	Type	Description
	- range: [0...65535]	65.535 seconds) A value of 0 means ring indefinitely until a call event occurs causing ringing to be removed from the lineDuration of the tone segment (in msec)

41.41 GPON Ringing Pattern Sequence Profile Configuration Command

Command Description

This command creates a profile that defines a ringing sequence by serially identifying ring segment profiles to associate for a ringing sequence

NOTE: Segment 1 is mandatory to be entered. The remainders are optional. Other than the zero value (profile ID), the same Ring pattern cannot be referenced more than twice within the same profile. To cause a repeating sequence, reuse the profile ID from pattern1 or name from that first profile reference to define the looping of ring segments. These patterns represent the play order of the ring segments

User Level

The command can be accessed by operators with sip,megaco privileges, and executed by operators with sip,megaco privileges.

Command Syntax

The command has the following syntax:

```
> configure voice ont ( no ring-seq-prof (index) ) | ( ring-seq-prof (index) name <AsamProfileName> pattern1
<Gpon::RingingProf> [ no pattern2 | pattern2 <Gpon::RingingProfPointer> ] [ no pattern3 | pattern3
<Gpon::RingingProfPointer> ] [ no pattern4 | pattern4 <Gpon::RingingProfPointer> ] [ no pattern5 | pattern5
<Gpon::RingingProfPointer> ] )
```

Command Parameters

Table 41.41-1 "GPON Ringing Pattern Sequence Profile Configuration Command " Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - profile index - range: [1...20]	index of profile

Table 41.41-2 "GPON Ringing Pattern Sequence Profile Configuration Command " Command Parameters

Parameter	Type	Description
name	Parameter type: <AsamProfileName> Format: - a profile name - range: [a-zA-Z0-9-_.] - length: 1<=x<=32	<i>mandatory parameter</i> <i>The parameter is not visible during modification.</i> name of profile
pattern1	Parameter type: <Gpon::RingingProf> Format: (<Gpon::RingingSetProfilePtr>	<i>mandatory parameter</i> <i>The parameter is not visible during modification.</i>

Parameter	Type	Description
	name : <AsamProfileName>) Possible values: - name : profile name Field type <Gpon::RingingSetProfilePtr> - profile index - range: [0...20] Data driven field type Possible values are depending on the actual configuration and software. The currently allowed values can be shown with online-help.	ring segment profile
[no] pattern2	Parameter type: <Gpon::RingingProfPointer> Format: (none <Gpon::RingingSetProfilePtr> name : <AsamProfileName>) Possible values: - none : no profile to associate - name : profile name Field type <Gpon::RingingSetProfilePtr> - profile index - range: [0...20] Data driven field type Possible values are depending on the actual configuration and software. The currently allowed values can be shown with online-help.	<i>optional parameter with default value: "none"</i> <i>The parameter is not visible during modification.</i> ring segment profile
[no] pattern3	Parameter type: <Gpon::RingingProfPointer> Format: (none <Gpon::RingingSetProfilePtr> name : <AsamProfileName>) Possible values: - none : no profile to associate - name : profile name Field type <Gpon::RingingSetProfilePtr> - profile index - range: [0...20] Data driven field type Possible values are depending on the actual configuration and software. The currently allowed values can be shown with online-help.	<i>optional parameter with default value: "none"</i> <i>The parameter is not visible during modification.</i> ring segment profile
[no] pattern4	Parameter type: <Gpon::RingingProfPointer> Format: (none <Gpon::RingingSetProfilePtr> name : <AsamProfileName>) Possible values: - none : no profile to associate - name : profile name Field type <Gpon::RingingSetProfilePtr> - profile index - range: [0...20] Data driven field type Possible values are depending on the actual configuration and software. The currently allowed values can be shown with online-help.	<i>optional parameter with default value: "none"</i> <i>The parameter is not visible during modification.</i> ring segment profile
[no] pattern5	Parameter type: <Gpon::RingingProfPointer> Format:	<i>optional parameter with default value: "none"</i>

41 Voice Ont Configuration Commands

Parameter	Type	Description
	(none <Gpon::RingingSetProfilePtr> name : <AsamProfileName>) Possible values: - none : no profile to associate - name : profile name Field type <Gpon::RingingSetProfilePtr> - profile index - range: [0...20] Data driven field type Possible values are depending on the actual configuration and software. The currently allowed values can be shown with online-help.	<i>The parameter is not visible during modification.</i> ring segment profile

41.42 GPON Ring Event Profile Configuration Command

Command Description

This command can be used to create a profile that contains the associations of ringing sequence profiles or file ids to ringing selections. Note, this profile supports either method for making this association (use of the ringing sequence profile or identifying a file on the ONT that defines the ringing).

User Level

The command can be accessed by operators with sip,megaco privileges, and executed by operators with sip,megaco privileges.

Command Syntax

The command has the following syntax:

```
> configure voice ont ( no ringing-profile (index) ) | ( ringing-profile (index) name <AsamProfileName> [ no ringing-seq-prof | ringing-seq-prof <Gpon::RingingseqPointer> ] [ no ringing-file-prof | ringing-file-prof <Gpon::RingingfilePointer> ] [ no ringing-repeat | ringing-repeat <Gpon::RingRepeat> ] [ no splash-seq-prof | splash-seq-prof <Gpon::RingingseqPointer> ] [ no splash-file-prof | splash-file-prof <Gpon::RingingfilePointer> ] [ no splash-repeat | splash-repeat <Gpon::SplashRepeat> ] )
```

Command Parameters

Table 41.42-1 "GPON Ring Event Profile Configuration Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - profile index - range: [1...5]	index of profile

Table 41.42-2 "GPON Ring Event Profile Configuration Command" Command Parameters

Parameter	Type	Description
name	Parameter type: <AsamProfileName> Format: - a profile name - range: [a-zA-Z0-9-_.] - length: 1<=x<=32	<i>mandatory parameter</i> <i>The parameter is not visible during modification.</i> name of profile
[no] ringing-seq-prof	Parameter type: <Gpon::RingingseqPointer> Format: (none <Gpon::RingingFileProfPoint> name : <AsamProfileName>) Possible values: - none : no profile to associate - name : profile name	<i>optional parameter with default value: "none"</i> <i>The parameter is not visible during modification.</i> ringing sequence profile

41 Voice Ont Configuration Commands

Parameter	Type	Description
	Field type <Gpon::RingingFileProfPoint> - profile index - range: [0...100] Data driven field type Possible values are depending on the actual configuration and software. The currently allowed values can be shown with online-help.	
[no] ringing-file-prof	Parameter type: <Gpon::RingingfilePointer> Format: (none <Gpon::RingingFileProfPoint> name : <AsamProfileName>) Possible values: - none : no profile to associate - name : profile name Field type <Gpon::RingingFileProfPoint> - profile index - range: [0...100] Data driven field type Possible values are depending on the actual configuration and software. The currently allowed values can be shown with online-help.	<i>optional parameter with default value: "none"</i> <i>The parameter is not visible during modification.</i> uri profile that contains the location of the file that contains the ringing definition
[no] ringing-repeat	Parameter type: <Gpon::RingRepeat> Format: - Specifies how many times the ringing file is to be repeated for a ringing event - range: [0...10]	<i>optional parameter with default value: 0L</i> <i>The parameter is not visible during modification.</i> Specifies how many times the ringing file is to be repeated for a ringing event. Valid range is 0..10. Default of 0 means repeats until the end of the tone event.
[no] splash-seq-prof	Parameter type: <Gpon::RingingseqPointer> Format: (none <Gpon::RingingFileProfPoint> name : <AsamProfileName>) Possible values: - none : no profile to associate - name : profile name Field type <Gpon::RingingFileProfPoint> - profile index - range: [0...100] Data driven field type Possible values are depending on the actual configuration and software. The currently allowed values can be shown with online-help.	<i>optional parameter with default value: "none"</i> <i>The parameter is not visible during modification.</i> Splash ringing sequence profile
[no] splash-file-prof	Parameter type: <Gpon::RingingfilePointer> Format: (none <Gpon::RingingFileProfPoint> name : <AsamProfileName>) Possible values: - none : no profile to associate - name : profile name Field type <Gpon::RingingFileProfPoint> - profile index - range: [0...100]	<i>optional parameter with default value: "none"</i> <i>The parameter is not visible during modification.</i> Splash ringing sequence profile

Parameter	Type	Description
	Data driven field type Possible values are depending on the actual configuration and software. The currently allowed values can be shown with online-help.	
[no] splash-repeat	Parameter type: <Gpon::SplashRepeat> Format: - Specifies how many times the ringing file is to be repeated for a ringing event. - range: [0...10]	<i>optional parameter with default value: 0L</i> <i>The parameter is not visible during modification.</i> Specifies how many times the ringing file is to be repeated for a ringing event. Valid range is 0..10. Default of 0 means repeats until the end of the tone event.

Command Output

Table 41.42-3 "GPON Ring Event Profile Configuration Command" Display parameters

Specific Information		
name	Type	Description
ringing-seq-prof-name	Parameter type: <Gpon::IgnoredPrintableString> - ignored printable string	name of the default uri profile <i>This element is only shown in detail mode.</i>
ringing-file-prof-name	Parameter type: <Gpon::IgnoredPrintableString> - ignored printable string	name of the default uri profile <i>This element is only shown in detail mode.</i>
splash-seq-prof-name	Parameter type: <Gpon::IgnoredPrintableString> - ignored printable string	name of the default uri profile <i>This element is only shown in detail mode.</i>
splash-file-prof-name	Parameter type: <Gpon::IgnoredPrintableString> - ignored printable string	name of the default uri profile <i>This element is only shown in detail mode.</i>

41.43 GPON VOIP Feature Access Codes Profile Configuration Command

Command Description

This command creates a profile that defines a set of Feature Access Codes.

User Level

The command can be accessed by operators with sip,megaco privileges, and executed by operators with sip,megaco privileges.

Command Syntax

The command has the following syntax:

```
> configure voice ont ( no feat-acccode-prof (index) ) | ( feat-acccode-prof (index) name <AsamProfileName> [ no
cancel-call-wait | cancel-call-wait <Gpon::Accesscode> ] [ no hold | hold <Gpon::Accesscode> ] [ no park | park
<Gpon::Accesscode> ] [ no act-caller-id | act-caller-id <Gpon::Accesscode> ] [ no deact-caller-id | deact-caller-id
<Gpon::Accesscode> ] [ no act-dnd | act-dnd <Gpon::Accesscode> ] [ no deact-dnd | deact-dnd
<Gpon::Accesscode> ] [ no dnd-pin | dnd-pin <Gpon::Accesscode> ] [ no emergency | emergency
<Gpon::Accesscode> ] [ no intercom | intercom <Gpon::Accesscode> ] [ no attend-call-trans | attend-call-trans
<Gpon::Accesscode> ] [ no blind-call-trans | blind-call-trans <Gpon::Accesscode> ] )
```

Command Parameters

Table 41.43-1 "GPON VOIP Feature Access Codes Profile Configuration Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - profile index - range: [1...20]	feature access codes profile.

Table 41.43-2 "GPON VOIP Feature Access Codes Profile Configuration Command" Command Parameters

Parameter	Type	Description
name	Parameter type: <AsamProfileName> Format: - a profile name - range: [a-zA-Z0-9-_.] - length: 1<=x<=32	mandatory parameter The parameter is not visible during modification. name of profile
[no] cancel-call-wait	Parameter type: <Gpon::Accesscode> Format: - access code - range: [0-9*#] - length: x<=5	optional parameter with default value: "" The parameter is not visible during modification. access code to cancel call waiting.

Parameter	Type	Description
[no] hold	Parameter type: <Gpon::Accesscode> Format: - access code - range: [0-9*#] - length: x<=5	<i>optional parameter with default value: ""</i> <i>The parameter is not visible during modification.</i> access code to hold a call
[no] park	Parameter type: <Gpon::Accesscode> Format: - access code - range: [0-9*#] - length: x<=5	<i>optional parameter with default value: ""</i> <i>The parameter is not visible during modification.</i> access code to park a call
[no] act-caller-id	Parameter type: <Gpon::Accesscode> Format: - access code - range: [0-9*#] - length: x<=5	<i>optional parameter with default value: ""</i> <i>The parameter is not visible during modification.</i> access code to activate caller id.
[no] deact-caller-id	Parameter type: <Gpon::Accesscode> Format: - access code - range: [0-9*#] - length: x<=5	<i>optional parameter with default value: ""</i> <i>The parameter is not visible during modification.</i> access code to deactivate caller id.
[no] act-dnd	Parameter type: <Gpon::Accesscode> Format: - access code - range: [0-9*#] - length: x<=5	<i>optional parameter with default value: ""</i> <i>The parameter is not visible during modification.</i> access code to activate do not disturb
[no] deact-dnd	Parameter type: <Gpon::Accesscode> Format: - access code - range: [0-9*#] - length: x<=5	<i>optional parameter with default value: ""</i> <i>The parameter is not visible during modification.</i> access code to de-activate do not disturb
[no] dnd-pin	Parameter type: <Gpon::Accesscode> Format: - access code - range: [0-9*#] - length: x<=5	<i>optional parameter with default value: ""</i> <i>The parameter is not visible during modification.</i> access code to to change the do not disturb pin.
[no] emergency	Parameter type: <Gpon::Accesscode> Format: - access code - range: [0-9*#] - length: x<=5	<i>optional parameter with default value: ""</i> <i>The parameter is not visible during modification.</i> access code to set the emergency service number.
[no] intercom	Parameter type: <Gpon::Accesscode> Format: - access code - range: [0-9*#] - length: x<=5	<i>optional parameter with default value: ""</i> <i>The parameter is not visible during modification.</i> access code to enable intercom service
[no] attend-call-trans	Parameter type: <Gpon::Accesscode> Format: - access code - range: [0-9*#] - length: x<=5	<i>optional parameter with default value: ""</i> <i>The parameter is not visible during modification.</i> access code to select attended call transfer behavior.

41 Voice Ont Configuration Commands

Parameter	Type	Description
[no] blind-call-trans	Parameter type: <Gpon::Accesscode> Format: - access code - range: [0-9*#] - length: x<=5	<i>optional parameter with default value: ""</i> <i>The parameter is not visible during modification.</i> select unattended call transfer behavior.

41.44 GPON Common VOIP Configuration

Command

Command Description

This command creates the common VoIP configuration for the ONT. It must be created after creating an IP Host on the ONT. It ties directly to the IP Host via the AID. Note, only one VoIP client can be supported in an ONT at this time.

User Level

The command can be accessed by operators with sip,megaco privileges, and executed by operators with sip,megaco privileges.

Command Syntax

The command has the following syntax:

```
> configure voice ont ( no voip-config (voip-index) ) | ( voip-config (voip-index) protocol <Gpon::VoipProtocol> [
no conf-method | conf-method <Gpon::ConfMethod> ] [ no securi-prof | securi-prof <Gpon::SecuriProf> ] )
```

Command Parameters

Table 41.44-1 "GPON Common VOIP Configuration Command" Resource Parameters

Resource Identifier	Type	Description
(voip-index)	Format: (ont : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Gpon::IpHostId> ont:ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / <Ng2::IpHostId>) Possible values: - ont:ng2 : ngpon2 ont - ont : ont Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Eqpt::OntId> - the ONT identifier Field type <Eqpt::ChannelGroupId> - the channel group identifier Field type <Eqpt::SubChannelGroupId>	a unique interface index

Resource Identifier	Type	Description
	- the subchannel group identifier Field type <Eqpt::Ng2OntId> - the NG2 ONT identifier Field type <Gpon::IpHostID> - iphost id Field type <Ng2::IpHostID> - iphost id (ngpon2)	

Table 41.44-2 "GPON Common VOIP Configuration Command" Command Parameters

Parameter	Type	Description
protocol	Parameter type: <Gpon::VoipProtocol> Format: (sip h248) Possible values: - sip : sip signalling protocol - h248 : h248 signalling protocol	<i>mandatory parameter</i> protocol
[no] conf-method	Parameter type: <Gpon::ConfMethod> Format: (omci ftp) Possible values: - omci : FTP Server - ftp : FTP Server	<i>optional parameter with default value: "omci"</i> configuration method
[no] securi-prof	Parameter type: <Gpon::SecuriProf> Format: (none <Gpon::SecuriProfilePointer> name : <AsamProfileName>) Possible values: - none : no profile to associate - name : profile name Field type <Gpon::SecuriProfilePointer> - profile index - range: [0...50] Data driven field type Possible values are depending on the actual configuration and software. The currently allowed values can be shown with online-help.	<i>optional parameter with default value: "none"</i> securi prof

41.45 GPON Voice ONT POTS Rtp PM Mode Configuration Command

Command Description

This command allows the operator to configure the PM Mode of ONT POTS Rtp monitoring.

User Level

The command can be accessed by operators with sip,megaco privileges, and executed by operators with sip,megaco privileges.

Command Syntax

The command has the following syntax:

```
> configure voice ont pots-rtp (uni-index) [ no pm-collect | pm-collect <Gpon::OntPmCollect> ]
```

Command Parameters

Table 41.45-1 "GPON Voice ONT POTS Rtp PM Mode Configuration Command" Resource Parameters

Resource Identifier	Type	Description
(uni-index)	Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Gpon::OntSlotId> / <Gpon::OntPotsPortId> ng2 : <Ng2::ChannelGroup> / <Ng2::SubchannelGroup> / <Ng2::OntId> / <Gpon::OntSlotId> / <Gpon::OntPotsPortId>) Possible values: - ng2 : ngpon2 style identification Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Eqpt::OntId> - the ONT identifier Field type <Ng2::ChannelGroup> - channel group number Field type <Ng2::SubchannelGroup> - subchannel group number Field type <Ng2::OntId>	gpon ont port index

41 Voice Ont Configuration Commands

Resource Identifier	Type	Description
	- the ONT identifier Field type <Gpon::OntSlotId> - Gpon Ont Slot - range: [1...14] - Gpon Ont PotsPort Field type <Gpon::OntPotsPortId> - Gpon Ont Pots Port - range: [1...24]	

Table 41.45-2 "GPON Voice ONT POTS Rtp PM Mode Configuration Command" Command Parameters

Parameter	Type	Description
[no] pm-collect	Parameter type: <Gpon::OntPmCollect> Format: (enable disable) Possible values: - enable : enable PM - disable : disable PM	<i>optional parameter with default value: "disable"</i> ONT POTS Rtp performance monitoring

41.46 GPON ONT SIP Configuration Command

Command Description

This command creates the SIP configuration for the ONT. It must be created after creating a VOIP Configuration on the ONT. Note, only one VoIP client can be supported in an ONT at this time.

NOTE:

OLT prohibits the entry of the following range of well-known IP addresses for the parameters *primary-dns* and *secondary-dns*:

224.0.0.0 to 239.255.255.255 (multicast)

127.0.0.0 to 127.255.255.255 (loopback)

255.255.255.255 (broadcast)

User Level

The command can be accessed by operators with *sip,megaco* privileges, and executed by operators with *sip,megaco* privileges.

Command Syntax

The command has the following syntax:

```
> configure voice ont ( no sip-config (sip-index) ) | ( sip-config (sip-index) [ no proxyserv-prof | proxyserv-prof
<Gpon::UriProfileName> ] [ no outproxyserv-prof | outproxyserv-prof <Gpon::UriProfileName> ] [ no primary-dns
| primary-dns <Gpon::IpAddress> ] [ no secondary-dns | secondary-dns <Gpon::IpAddress> ] [ no reg-expire-time |
reg-expire-time <Gpon::RegExpireTime> ] [ no re-reg-head-start | re-reg-head-start <Gpon::ReRegHeadStart> ] [
no aor-host-prt-prof | aor-host-prt-prof <Gpon::UriProfileName> ] [ no registrar-prof | registrar-prof
<Gpon::SecuriProf> ] [ no soft-sw-vendor | soft-sw-vendor <Gpon::SwVendor> ] [ no opt-tx-cntrl | opt-tx-cntrl
<Gpon::OpticalTxCntrl> ] [ no uri-format | uri-format <Gpon::UriFormat> ] [ no dscp | dscp <Gpon::SigDscp> ] [
no udp-port | udp-port <Gpon::SipUdpPort> ] )
```

Command Parameters

Table 41.46-1 "GPON ONT SIP Configuration Command" Resource Parameters

Resource Identifier	Type	Description
(sip-index)	Format: (ont : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Gpon::IpHostId> ont:ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / <Ng2::IpHostId>) Possible values: - ont:ng2 : ngpon2 ont - ont : ont Field type <Eqpt::RackId> - the rack number	SIP ONT index

Resource Identifier	Type	Description
	Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Eqpt::OntId> - the ONT identifier Field type <Eqpt::ChannelGroupId> - the channel group identifier Field type <Eqpt::SubChannelGroupId> - the subchannel group identifier Field type <Eqpt::Ng2OntId> - the NG2 ONT identifier Field type <Gpon::IpHostID> - iphost id Field type <Ng2::IpHostID> - iphost id (ngpon2)	

Table 41.46-2 "GPON ONT SIP Configuration Command" Command Parameters

Parameter	Type	Description
[no] proxyserv-prof	Parameter type: <Gpon::UriProfileName> Format: (none <Gpon:UriProfilePtr> name : <AsamProfileName>) Possible values: - none : no profile to associate - name : profile name Field type <Gpon:UriProfilePtr> - Index of the URI profile that contains the IP address of the server - range: [0...100] Data driven field type Possible values are depending on the actual configuration and software. The currently allowed values can be shown with online-help.	<i>optional parameter with default value: "none"</i> URI profile of the SIP proxy server for SIP signaling messages
[no] outproxyserv-prof	Parameter type: <Gpon::UriProfileName> Format: (none <Gpon:UriProfilePtr> name : <AsamProfileName>) Possible values: - none : no profile to associate - name : profile name Field type <Gpon:UriProfilePtr> - Index of the URI profile that contains the IP address of the server - range: [0...100] Data driven field type Possible values are depending on the actual configuration and software. The currently allowed values can be shown with online-help.	<i>optional parameter with default value: "none"</i> URI profile of the outbound SIP proxy server for SIP signaling messages
[no] primary-dns	Parameter type: <Gpon::IpAddress> Format: - IPv4-address	<i>optional parameter with default value: "0.0.0.0"</i> primary SIP DNS server ip address

Parameter	Type	Description
[no] secondary-dns	Parameter type: <Gpon::IpAddress> Format: - IPv4-address	<i>optional parameter with default value: "0.0.0.0"</i> secondary SIP DNS server ip address
[no] reg-expire-time	Parameter type: <Gpon::RegExpireTime> Format: - sip registration expiration time - unit: sec - range: [0...86400]	<i>optional parameter with default value: "3600"</i> SIP registration expiration time
[no] re-reg-head-start	Parameter type: <Gpon::ReRegHeadStart> Format: - Re-registration head start time - unit: sec - range: [0...600]	<i>optional parameter with default value: "360"</i> re-registration head start time
[no] aor-host-prt-prof	Parameter type: <Gpon::UriProfileName> Format: (none <Gpon:UriProfilePtr> name : <AsamProfileName>) Possible values: - none : no profile to associate - name : profile name Field type <Gpon:UriProfilePtr> - Index of the URI profile that contains the IP address of the server - range: [0...100] Data driven field type Possible values are depending on the actual configuration and software. The currently allowed values can be shown with online-help.	<i>optional parameter with default value: "none"</i> URI profile that contains the host or domain part of the SIP address of record
[no] registrar-prof	Parameter type: <Gpon::SecuriProf> Format: (none <Gpon::SecuriProfilePointer> name : <AsamProfileName>) Possible values: - none : no profile to associate - name : profile name Field type <Gpon::SecuriProfilePointer> - profile index - range: [0...50] Data driven field type Possible values are depending on the actual configuration and software. The currently allowed values can be shown with online-help.	<i>optional parameter with default value: "none"</i> URI profile of the registrar server
[no] soft-sw-vendor	Parameter type: <Gpon::SwVendor> Format: - name of the sip gateway softswitch vendor - range: [A-Z] - length: x<=4	<i>optional parameter with default value: ""</i> name of the SIP gateway softswitch vendor
[no] opt-tx-cntrl	Parameter type: <Gpon::OpticalTxCntrl> Format: (disable enable) Possible values: - disable : disable optional transmission control - enable : enable optional transmission control	<i>optional parameter with default value: "disable"</i> optional transmission control indicating whether the ONT is enabled/disabled to transmit value options

Parameter	Type	Description
[no] uri-format	Parameter type: <Gpon::UriFormat> Format: (tel-uri sip-uri) Possible values: - tel-uri : tel uri format - sip-uri : sip uri format	<i>optional parameter with default value: "tel-uri"</i> URI format to specify the format of the URI in outgoing SIP messages
[no] dscp	Parameter type: <Gpon::SigDscp> Format: - dscp value - range: [0...63]	<i>optional parameter with default value: "24"</i> dscp setting value to use in the ip header of outgoing SIP signaling packets
[no] udp-port	Parameter type: <Gpon::SipUdpPort> Format: - udp port - range: [5000...6000]	<i>optional parameter with default value: "5060"</i> <i>The parameter is not visible during modification.</i> specifies the udp port number to be used for SIP signaling messages

Command Output

Table 41.46-3 "GPON ONT SIP Configuration Command" Display parameters

Specific Information		
name	Type	Description
proxyserv-prof-name	Parameter type: <Gpon::IgnoredPrintableString> - ignored printable string	name of the URI profile that contains the ip address of the SIP proxy server for SIP signaling messages. <i>This element is always shown.</i>
outproxyserv-prof-name	Parameter type: <Gpon::IgnoredPrintableString> - ignored printable string	name of the URI profile that contains the ip address of the outbound SIP proxy server for SIP signaling messages. <i>This element is always shown.</i>
aor-host-prt-prof-name	Parameter type: <Gpon::IgnoredPrintableString> - ignored printable string	name of the URI profile that contains the host or domain part of the SIP address of record. <i>This element is always shown.</i>
registrar-prof-name	Parameter type: <Gpon::IgnoredPrintableString> - ignored printable string	name of the secure URI profile that contains the IP address of the registrar server. <i>This element is always shown.</i>

41.47 Voice Ont SIP Agent PM Mode Configuration Command

Command Description

This command allows the operator to configure the PM Mode of ONT SIP Agent monitoring.

User Level

The command can be accessed by operators with sip,megaco privileges, and executed by operators with sip,megaco privileges.

Command Syntax

The command has the following syntax:

```
> configure voice ont sip-agent (ont-index) [ no pm-collect | pm-collect <Gpon::PmEnable> ]
```

Command Parameters

Table 41.47-1 "Voice Ont SIP Agent PM Mode Configuration Command" Resource Parameters

Resource Identifier	Type	Description
(ont-index)	Format: (ont : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Gpon::IpHostId> ont:ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / <Ng2::IpHostId>) Possible values: - ont:ng2 : ngpon2 ont - ont : ont Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Eqpt::OntId> - the ONT identifier Field type <Eqpt::ChannelGroupId> - the channel group identifier Field type <Eqpt::SubChannelGroupId> - the subchannel group identifier Field type <Eqpt::Ng2OntId> - the NG2 ONT identifier	ont index

41 Voice Ont Configuration Commands

Resource Identifier	Type	Description
	Field type <Gpon::IpHostID> - iphost id Field type <Ng2::IpHostID> - iphost id (ngpon2)	

Table 41.47-2 "Voice Ont SIP Agent PM Mode Configuration Command" Command Parameters

Parameter	Type	Description
[no] pm-collect	Parameter type: <Gpon::PmEnable> Format: (disable enable) Possible values: - disable : disable the collection - enable : enable the collection	<i>optional parameter with default value: "disable"</i> performance mode state

41.48 Voice Ont SIP Agent Call PM Mode Configuration Command

Command Description

This command allows the operator to configure the PM Mode of ONT SIP Agent Call monitoring.

User Level

The command can be accessed by operators with sip,megaco privileges, and executed by operators with sip,megaco privileges.

Command Syntax

The command has the following syntax:

```
> configure voice ont sip-call (ont-index) [ no pm-collect | pm-collect <Gpon::PmEnable> ]
```

Command Parameters

Table 41.48-1 "Voice Ont SIP Agent Call PM Mode Configuration Command" Resource Parameters

Resource Identifier	Type	Description
(ont-index)	Format: (ont : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Gpon::IpHostId> ont:ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / <Ng2::IpHostId>) Possible values: - ont:ng2 : ngpon2 ont - ont : ont Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Eqpt::OntId> - the ONT identifier Field type <Eqpt::ChannelGroupId> - the channel group identifier Field type <Eqpt::SubChannelGroupId> - the subchannel group identifier Field type <Eqpt::Ng2OntId>	ont index

41 Voice Ont Configuration Commands

Resource Identifier	Type	Description
	- the NG2 ONT identifier Field type <Gpon::IpHostID> - iphost id Field type <Ng2::IpHostID> - iphost id (ngpon2)	

Table 41.48-2 "Voice Ont SIP Agent Call PM Mode Configuration Command" Command Parameters

Parameter	Type	Description
[no] pm-collect	Parameter type: <Gpon::PmEnable> Format: (disable enable) Possible values: - disable : disable the collection - enable : enable the collection	<i>optional parameter with default value: "disable"</i> performance mode state

41.49 Configure ont POT SIP

Command Description

This command edits a POT's port's SIP parameter for those line using SIP instead of MGC.

User Level

The command can be accessed by operators with sip,megaco privileges, and executed by operators with sip,megaco privileges.

Command Syntax

The command has the following syntax:

```
> configure voice ont voice-sip-port (pots-index) [ no user-aor | user-aor <Gpon::UserAddress> ] [ no display-name
| display-name <Gpon::DisplayName> ] [ no val-scheme | val-scheme <Gpon::AuthSecValScheme> ] [ no
user-name | user-name <Gpon::AuthUserName> ] [ no password | password <Security::Password5> ] [ no realm |
realm <Gpon::Realm> ] [ no voice-mail-prof | voice-mail-prof <Gpon::VoiceMailProfilePointer> ] [ no
voice-mail-to | voice-mail-to <Gpon::VoiceMailTo> ] [ no ntwk-dp-prof | ntwk-dp-prof
<Gpon::NetDialPlanProfilePointer> ] [ no app-serv-prof | app-serv-prof <Gpon::AppServProfilePointer> ] [ no
ac-code-prof | ac-code-prof <Gpon::AccessCodeProfilePointer> ] [ no rlstimer | rlstimer <Gpon::RlsTimer> ] [ no
rohtimer | rohtimer <Gpon::RohTimer> ]
```

Command Parameters

Table 41.49-1 "Configure ont POT SIP" Resource Parameters

Resource Identifier	Type	Description
(pots-index)	Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Gpon::OntSlotId> / <Gpon::OntPotsPortId> ng2 : <Ng2::ChannelGroup> / <Ng2::SubchannelGroup> / <Ng2::OntId> / <Gpon::OntSlotId> / <Gpon::OntPotsPortId>) Possible values: - ng2 : ngpon2 style identification Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Eqpt::OntId> - the ONT identifier Field type <Ng2::ChannelGroup> - channel group number	an ontpots access identifier index

41 Voice Ont Configuration Commands

Resource Identifier	Type	Description
	Field type <Ng2::SubchannelGroup> - subchannel group number Field type <Ng2::OntId> - the ONT identifier Field type <Gpon::OntSlotId> - Gpon Ont Slot - range: [1...14] Field type <Gpon::OntPotsPortId> - Gpon Ont Pots Port - range: [1...24]	

Table 41.49-2 "Configure ont POT SIP" Command Parameters

Parameter	Type	Description
[no] user-aor	Parameter type: <Gpon::UserAddress> Format: - user identification - length: x<=50	<i>optional parameter with default value: ""</i> user address of record
[no] display-name	Parameter type: <Gpon::DisplayName> Format: - customer id used to display name in outgoing sip message - length: x<=25	<i>optional parameter with default value: ""</i> customer ID user for display name
[no] val-scheme	Parameter type: <Gpon::AuthSecValScheme> Format: (disabled md5-digest basic-authentic) Possible values: - disabled : Validation disabled - md5-digest : validate using md5 digest authentication - basic-authentic : Validate using basic authentication	<i>optional parameter with default value: "disabled"</i> validation scheme required for authentication
[no] user-name	Parameter type: <Gpon::AuthUserName> Format: - user name required for authentication - length: x<=50	<i>optional parameter with default value: ""</i> user name required for authentication
[no] password	Parameter type: <Security::Password5> Format: (prompt plain : <Security::PlainPassword5>) Possible values: - prompt : prompts the operator for a password - plain : the password in plain text Field type <Security::PlainPassword5> - authentication string - length: x<=25	<i>optional parameter with default value: "plain : "</i> password string hidden from users
[no] realm	Parameter type: <Gpon::Realm> Format: - realm required for authentication - length: x<=25	<i>optional parameter with default value: ""</i> realm for authentication
[no] voice-mail-prof	Parameter type: <Gpon::VoiceMailProfilePointer> Format: (none <Gpon::VoiceMailProfilePointer> name : <AsamProfileName>) Possible values: - none : no profile to associate - name : profile name Field type <Gpon::VoiceMailProfilePointer>	<i>optional parameter with default value: 0L</i> voice mail profile contains sip voice-mail information

Parameter	Type	Description
	- profile index - range: [0...20] Data driven field type Possible values are depending on the actual configuration and software. The currently allowed values can be shown with online-help.	
[no] voice-mail-to	Parameter type: <Gpon::VoiceMailTo> Format: - voice mail subscription expiration time in seconds - unit: seconds - range: [0...86400]	<i>optional parameter with default value: 3600L</i> voice mail subscription expiration time in seconds
[no] ntwk-dp-prof	Parameter type: <Gpon::NetDialPlanProfilePointer> Format: (none <Gpon::NetDialPlanProfilePointer> name : <AsamProfileName>) Possible values: - none : no profile to associate - name : profile name Field type <Gpon::NetDialPlanProfilePointer> - profile index - range: [0...20] Data driven field type Possible values are depending on the actual configuration and software. The currently allowed values can be shown with online-help.	<i>optional parameter with default value: 0L</i> Network dial plan profile contains network dial plan information
[no] app-serv-prof	Parameter type: <Gpon::AppServProfilePointer> Format: (none <Gpon::AppServProfilePointer> name : <AsamProfileName>) Possible values: - none : no profile to associate - name : profile name Field type <Gpon::AppServProfilePointer> - profile index - range: [0...20] Data driven field type Possible values are depending on the actual configuration and software. The currently allowed values can be shown with online-help.	<i>optional parameter with default value: 0L</i> Application service profile that contains information related to calling features
[no] ac-code-prof	Parameter type: <Gpon::AccessCodeProfilePointer> Format: (none <Gpon::AccessCodeProfilePointer> name : <AsamProfileName>) Possible values: - none : no profile to associate - name : profile name Field type <Gpon::AccessCodeProfilePointer> - profile index - range: [0...20] Data driven field type Possible values are depending on the actual configuration and software. The currently allowed values can be shown with online-help.	<i>optional parameter with default value: 0L</i> VOIP access code profile that contains information related to administrative feature
[no] rlstimer	Parameter type: <Gpon::RlsTimer>	<i>optional parameter with default</i>

Parameter	Type	Description
	Format: - sip release timer - unit: seconds - range: [0...60]	<i>value: 10L</i> SIP release timer
[no] rohtimer	Parameter type: <Gpon::RohTimer> Format: - receiver off-hook timer - unit: seconds - range: [0...60]	<i>optional parameter with default value: 15L</i> Receiver off-Hook timer that specifies how long in seconds the line is in ROH condition

Command Output

Table 41.49-3 "Configure ont POT SIP" Display parameters

Specific Information		
name	Type	Description
ntwk-dp-prof-name	Parameter type: <Gpon::IgnoredPrintableString> - ignored printable string	name of the authentication security profile pointer <i>This element is always shown.</i>
app-serv-prof-name	Parameter type: <Gpon::IgnoredPrintableString> - ignored printable string	name of the authentication security profile pointer <i>This element is always shown.</i>
ac-code-prof-name	Parameter type: <Gpon::IgnoredPrintableString> - ignored printable string	name of the authentication security profile pointer <i>This element is always shown.</i>

41.50 Voice ONT MGC Configuration command

Command Description

This command creates the MEGACO configuration of the ONT

NOTE: Only one VoIP client can be supported in an ONT at this time

User Level

The command can be accessed by operators with sip,megaco privileges, and executed by operators with sip,megaco privileges.

Command Syntax

The command has the following syntax:

```
> configure voice ont ( no mgc-config (if-index) ) | ( mgc-config (if-index) pri-mgcuri-profid
<Gpon::ReqSecureUriProfileName> sec-mgcuri-profid <Gpon::ReqSecureUriProfileName> [ no protocol-ver |
protocol-ver <Gpon::PrctlVer> ] [ no msg-format | msg-format <Gpon::MsgFormat> ] [ no max-retry-time |
max-retry-time <Gpon::MaxRtryTime> ] [ no max-retries | max-retries <Gpon::MaxRetry> ] [ no status-delay-time |
status-delay-time <Gpon::DelayTime> ] base-termid <Gpon::TerminationId> [ no sig-dscp | sig-dscp
<Gpon::SigDscp> ] [ no udp-port | udp-port <Gpon::UdpPort> ] [ no sw-vendor | sw-vendor
<Gpon::MgcVendorName> ] [ no cnf-msg-profid | cnf-msg-profid <Gpon::UriProfileName> ] )
```

Command Parameters

Table 41.50-1 "Voice ONT MGC Configuration command" Resource Parameters

Resource Identifier	Type	Description
(if-index)	Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / 1 ng2 : <Ng2::ChannelGroup> / <Ng2::SubchannelGroup> / <Ng2::OntId> / 1) Possible values: - ng2 : ngpon2 style identification Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Eqpt::OntId> - the ONT identifier Possible values: - 1 : Gpon voip Port Field type <Ng2::ChannelGroup> - channel group number	ifindex of iphost uni

41 Voice Ont Configuration Commands

Resource Identifier	Type	Description
	Field type <Ng2::SubchannelGroup> - subchannel group number Field type <Ng2::OntId> - the ONT identifier Possible values: - 1 : Gpon voip Port	

Table 41.50-2 "Voice ONT MGC Configuration command" Command Parameters

Parameter	Type	Description
pri-mgcuri-profid	Parameter type: <Gpon::ReqSecureUriProfileName> Format: (<Gpon:SecUriProfPtr> name : <AsamProfileName>) Possible values: - name : profile name Field type <Gpon:SecUriProfPtr> - Index of the sec-uri profile that contains the IP address of the server - range: [1...50] Data driven field type Possible values are depending on the actual configuration and software. The currently allowed values can be shown with online-help.	<i>mandatory parameter</i> Uri profile that contains the ip address of the primary media gateway controller
sec-mgcuri-profid	Parameter type: <Gpon::ReqSecureUriProfileName> Format: (<Gpon:SecUriProfPtr> name : <AsamProfileName>) Possible values: - name : profile name Field type <Gpon:SecUriProfPtr> - Index of the sec-uri profile that contains the IP address of the server - range: [1...50] Data driven field type Possible values are depending on the actual configuration and software. The currently allowed values can be shown with online-help.	<i>mandatory parameter</i> Uri profile that contains the ip address of the secondary media gateway controller
[no] protocol-ver	Parameter type: <Gpon::PrctlVer> Format: - Selects the version of MGC protocol signalling to be used - range: [0...2]	<i>optional parameter with default value: 0L</i> Selects the version of the MGC signaling protocol to be used
[no] msg-format	Parameter type: <Gpon::MsgFormat> Format: - Selects message format value - range: [0...2]	<i>optional parameter with default value: 0L</i> <i>The parameter is not visible during modification.</i> Specifies the message format
[no] max-retry-time	Parameter type: <Gpon::MaxRtryTime> Format: - Specifies the maximum retry time for MGC transaction - unit: sec - range: [0...60]	<i>optional parameter with default value: 0L</i> Specifies the maximum retry time (in seconds) for MGC transaction
[no] max-retries	Parameter type: <Gpon::MaxRetry> Format: - Specifies the maximum number of times a message is transmitted to the MGC - range: [0...10]	<i>optional parameter with default value: 0L</i> Specifies the maximum number of times a message is transmitted to the MGC
[no] status-delay-time	Parameter type: <Gpon::DelayTime>	<i>optional parameter with default</i>

Parameter	Type	Description
	Format: - Service status delay time (in seconds) for changes in line service status - unit: sec - range: [0...60]	<i>value: 0L</i> Service status delay time (in seconds) for changes in line service status
base-termid	Parameter type: <Gpon::TerminationId> Format: - identifies the POTS port in H248 VoIP signalling messages. The first character must be alphabetic. The string 'ROOT' is not allowed. - range: [a-zA-Z0-9*/-_\$@.] - length: x<=25	<i>mandatory parameter</i> Base string for H248 physical termination Id
[no] sig-dscp	Parameter type: <Gpon::SigDscp> Format: - dscp value - range: [0...63]	<i>optional parameter with default value: 24L</i> DSCP value for use in outgoing signaling packets towards the Soft Switch
[no] udp-port	Parameter type: <Gpon::UdpPort> Format: - Specifies the UDP port number to be used for MGC signaling messages - range: [2000...3000]	<i>optional parameter with default value: 2944L</i> <i>The parameter is not visible during modification.</i> Specifies the UDP port number to be used for MGC signaling messages
[no] sw-vendor	Parameter type: <Gpon::MgcVendorName> Format: - vendor id - 4 ASCII characters - range: [a-zA-Z0-9] - length: 4	<i>optional parameter with default value: ""</i> Specifies the gateway soft switch Vendor
[no] cnf-msg-profid	Parameter type: <Gpon::UriProfileName> Format: (none <Gpon:UriProfilePtr> name : <AsamProfileName>) Possible values: - none : no profile to associate - name : profile name Field type <Gpon:UriProfilePtr> - Index of the URI profile that contains the IP address of the server - range: [0...100] Data driven field type Possible values are depending on the actual configuration and software. The currently allowed values can be shown with online-help.	<i>optional parameter with default value: "none"</i> Index or Name of the URI Profile that contains the Message Identifier string for H.248 messages

Command Output

Table 41.50-3 "Voice ONT MGC Configuration command" Display parameters

Specific Information		
name	Type	Description
pri-mgcuri-prof-name	Parameter type: <Gpon::IgnoredPrintableString> - ignored printable string	name of the primary uri profile <i>This element is only shown in detail mode.</i>
sec-mgcuri-prof-name	Parameter type: <Gpon::IgnoredPrintableString> - ignored printable string	name of the secondary uri profile <i>This element is only shown in</i>

41 Voice Ont Configuration Commands

name	Type	Description
		<i>detail mode.</i>
conf-mgcuri-prof-name	Parameter type: <Gpon::IgnoredPrintableString> - ignored printable string	name of the H.248 message identifier uri profile <i>This element is only shown in detail mode.</i>

41.51 Voice ONT MGC PM monitoring command

Command Description

This command sets the PM Mode of ONT MGC Agent monitoring

User Level

The command can be accessed by operators with sip,megaco privileges, and executed by operators with sip,megaco privileges.

Command Syntax

The command has the following syntax:

```
> configure voice ont mgc-agent (voip-index) [ no pm-collect | pm-collect <Gpon::PmEnable> ]
```

Command Parameters

Table 41.51-1 "Voice ONT MGC PM monitoring command" Resource Parameters

Resource Identifier	Type	Description
(voip-index)	Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / 1 ng2 : <Ng2::ChannelGroup> / <Ng2::SubchannelGroup> / <Ng2::OntId> / 1) Possible values: - ng2 : ngpon2 style identification Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Eqpt::OntId> - the ONT identifier Possible values: - 1 : Gpon voip Port Field type <Ng2::ChannelGroup> - channel group number Field type <Ng2::SubchannelGroup> - subchannel group number Field type <Ng2::OntId> - the ONT identifier Possible values: - 1 : Gpon voip Port	a unique voip ont index

Table 41.51-2 "Voice ONT MGC PM monitoring command" Command Parameters

Parameter	Type	Description
[no] pm-collect	Parameter type: <Gpon::PmEnable> Format: (disable enable) Possible values: - disable : disable the collection - enable : enable the collection	<i>optional parameter with default value: "disable"</i> This indicates whether MGC Performance Monitors should be collected for this MGC Config instance

41.52 Voice Ont Pots Call PM Mode Configuration Command

Command Description

This command allows the operator to configure the PM Mode of ONT POTS Call monitoring

User Level

The command can be accessed by operators with sip,megaco privileges, and executed by operators with sip,megaco privileges.

Command Syntax

The command has the following syntax:

```
> configure voice ont pots-call (uni-idx) [ no pm-collect | pm-collect <Gpon::OntPmCollect> ]
```

Command Parameters

Table 41.52-1 "Voice Ont Pots Call PM Mode Configuration Command" Resource Parameters

Resource Identifier	Type	Description
(uni-idx)	Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Gpon::OntSlotId> / <Gpon::OntPotsPortId> ng2 : <Ng2::ChannelGroup> / <Ng2::SubchannelGroup> / <Ng2::OntId> / <Gpon::OntSlotId> / <Gpon::OntPotsPortId>) Possible values: - ng2 : ngpon2 style identification Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Eqpt::OntId> - the ONT identifier Field type <Ng2::ChannelGroup> - channel group number Field type <Ng2::SubchannelGroup> - subchannel group number Field type <Ng2::OntId> - the ONT identifier	identification of the ont interface index

41 Voice Ont Configuration Commands

Resource Identifier	Type	Description
	Field type <Gpon::OntSlotId> - Gpon Ont Slot - range: [1...14] Field type <Gpon::OntPotsPortId> - Gpon Ont Pots Port - range: [1...24]	

Table 41.52-2 "Voice Ont Pots Call PM Mode Configuration Command" Command Parameters

Parameter	Type	Description
[no] pm-collect	Parameter type: <Gpon::OntPmCollect> Format: (enable disable) Possible values: - enable : enable PM - disable : disable PM	<i>optional parameter with default value: "disable"</i> enable/disable pm mode of ont-pots call monitoring

42- Debug Configuration Commands

42.1 Debug Configuration Command Tree	42-1496
42.2 Protocol Tracing Configuration Command	42-1497

42.1 Debug Configuration Command Tree

Description

This chapter gives an overview of nodes that are handled by "Debug Configuration Commands".

Command Tree

```
----configure
  ----debug-trace
    ----[no] protocol-trace
      - (trace-subject)
      - protocol
      - syslog
      - [no] events
      - [no] packet-summary
```

42.2 Protocol Tracing Configuration Command

Command Description

This commands allows the operator to enable/disable protocol tracing. The operator can enter the protocol, port and level of detail for which tracing can be enabled. It is mandatory to enable/disable atleast one of the tracings, events or packet-summary.

User Level

The command can be accessed by operators with security privileges, and executed by operators with security privileges.

Command Syntax

The command has the following syntax:

```
> configure debug-trace ( no protocol-trace (trace-subject) protocol <Debug::Protocol> ) | ( protocol-trace
(trace-subject) protocol <Debug::Protocol> syslog <Debug::SyslogMsgType> [ [ no ] events ] [ [ no ]
packet-summary ] )
```

Command Parameters

Table 42.2-1 "Protocol Tracing Configuration Command" Resource Parameters

Resource Identifier	Type	Description
(trace-subject)	Format: (dsl-line : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Debug::PortId> atm-pvc : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Debug::PortId> : <Eqpt::VpiMandatoryId> : <Eqpt::VciMandatoryId> shdsl-line : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Debug::PortId> ethernet-line : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Debug::PortId> uni : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> / <Eqpt::OntPortId> voip : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> uni.ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / vuni uni.ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / <Eqpt::Ng2OntSlotId> / <Eqpt::Ng2OntPortId>) Possible values: - dsl-line : the xDSL line - atm-pvc : the PVC of the ADSL line - shdsl-line : a static shdsl line interface	subject for which tracing is enabled(e.g ADSL line,PVC)

Resource Identifier	Type	Description
	- ethernet-line : a native ethernet line interface - uni : GPON ONT uni interface - voip : virtual uni identifier - uni:ng2 : NGPON ONT uni interface Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Debug::PortId> - the portId Field type <Eqpt::VpiMandatoryId> - atm VPI Field type <Eqpt::VciMandatoryId> - atm VCI Field type <Eqpt::PonId> - the PON identifier Field type <Eqpt::OntId> - the ONT identifier Field type <Eqpt::OntSlotId> - the ONT SLOT identifier Field type <Eqpt::OntPortId> - the ONT PORT identifier Field type <Eqpt::ChannelGroupId> - the channel group identifier Field type <Eqpt::SubChannelGroupId> - the subchannel group identifier Field type <Eqpt::Ng2OntId> - the NG2 ONT identifier Possible values: - vuni : virtual NGPON2 uni identifier Field type <Eqpt::Ng2OntSlotId> - the NGPON2 ONT SLOT identifier Field type <Eqpt::Ng2OntPortId> - the NGPON2 ONT PORT identifier	
protocol	Parameter type: <Debug::Protocol> Format: (igmp dhcp arp dhcpv6 pppoe all) Possible values: - igmp : enable tracing for igmp protocol - dhcp : enable tracing for dhcp protocol - arp : enable tracing for arp protocol - dhcpv6 : enable tracing for dhcpv6 protocol - pppoe : enable tracing for pppoe protocol - all : enable tracing for all protocols	protocol to be traced

Table 42.2-2 "Protocol Tracing Configuration Command" Command Parameters

Parameter	Type	Description
syslog	Parameter type: <Debug::SyslogMsgType> Format: (tracing1	<i>mandatory parameter</i> <i>The parameter is not visible during modification.</i>

Parameter	Type	Description
	tracing2 tracing3 tracing4) Possible values: - tracing1 : msg type tracing1 used for syslog - tracing2 : msg type tracing2 used for syslog - tracing3 : msg type tracing3 used for syslog - tracing4 : msg type tracing4 used for syslog	msg type used to log trace msgs to syslog
[no] events	Parameter type: boolean	<i>optional parameter</i> enable events tracing
[no] packet-summary	Parameter type: boolean	<i>optional parameter</i> enable pkt summary tracing

43- Ethernet User Ports Configuration Commands

43.1 Ethernet User Ports Configuration Command Tree	43-1501
43.2 Ethernet Line Configuration Command	43-1502
43.3 Ethernet Line TCA Threshold Configuration Command	43-1504
43.4 Ethernet Line Mau Configuration Command	43-1506

43.1 Ethernet User Ports Configuration Command Tree

Description

This chapter gives an overview of nodes that are handled by "Ethernet User Ports Configuration Commands".

Command Tree

```

----configure
  ----ethernet
    ----line
      - (if-index)
      - port-type
      - [no] admin-up
      ----tca-line-threshold
        - [no] enable
        - [no] los
        - [no] fcs
        - [no] rx-octets
        - [no] tx-octets
        - [no] los-day
        - [no] fcs-day
        - [no] rx-octets-day
        - [no] tx-octets-day
      ----mau
        - (index)
        - type
        - power
        - [no] speed-auto-sense
        - [no] autonegotiate
        - [no] cap100base-tfd
        - [no] cap1000base-xfd
        - [no] cap1000base-tfd

```

43.2 Ethernet Line Configuration Command

Command Description

This command allows the operator to configure the ethernet line.

User Level

The command can be accessed by operators with transport privileges, and executed by operators with transport privileges.

Command Syntax

The command has the following syntax:

```
> configure ethernet line (if-index) [ port-type <ETHITF::PortType> ] [ [ no ] admin-up ]
```

Command Parameters

Table 43.2-1 "Ethernet Line Configuration Command" Resource Parameters

Resource Identifier	Type	Description
(if-index)	Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number	interface index of the port

Table 43.2-2 "Ethernet Line Configuration Command" Command Parameters

Parameter	Type	Description
port-type	Parameter type: <ETHITF::PortType> Format: (uni nni hc-uni uplink) Possible values: - uni : uni port type - nni : nni port type - hc-uni : hicap uni port type - uplink : uplink port type	<i>optional parameter</i> the whole network service model based on this interface
[no] admin-up	Parameter type: boolean	<i>optional parameter</i> admin status is up (read-only for voicefxs interface)

43.3 Ethernet Line TCA Threshold Configuration Command

Command Description

This command allows the operator to configure the Threshold Crossing Alert (TCA) thresholds. The configuration is specific per ethernet line.

User Level

The command can be accessed by operators with transport privileges, and executed by operators with transport privileges.

Command Syntax

The command has the following syntax:

```
> configure ethernet line (if-index) tca-line-threshold [ [ no ] enable ] [ no los | los <ETHITF::TcaThresholdLOS> ]
[ no fcs | fcs <ETHITF::TcaThresholdFCS> ] [ no rx-octets | rx-octets <ETHITF::TcaThresholdMB> ] [ no
tx-octets | tx-octets <ETHITF::TcaThresholdMB> ] [ no los-day | los-day <ETHITF::TcaThresholdLOS> ] [ no
fcs-day | fcs-day <ETHITF::TcaThresholdFCS> ] [ no rx-octets-day | rx-octets-day <ETHITF::TcaThresholdMB> ]
[ no tx-octets-day | tx-octets-day <ETHITF::TcaThresholdMB> ]
```

Command Parameters

Table 43.3-1 "Ethernet Line TCA Threshold Configuration Command" Resource Parameters

Resource Identifier	Type	Description
(if-index)	Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number	interface index of the port

Table 43.3-2 "Ethernet Line TCA Threshold Configuration Command" Command Parameters

Parameter	Type	Description
[no] enable	Parameter type: boolean	<i>optional parameter</i> enable the reporting of TCA's for this ethernet line
[no] los	Parameter type: <ETHITF::TcaThresholdLOS> Format: - the tca threshold value (times), 0 - disable	<i>optional parameter with default value: 0</i> loss of signal error in 15 minute

Parameter	Type	Description
[no] fcs	Parameter type: <ETHITF::TcaThresholdFCS> Format: - the tca threshold value (frames), 0 - disable	<i>optional parameter with default value: 0</i> frame check sequence error in 15 minute
[no] rx-octets	Parameter type: <ETHITF::TcaThresholdMB> Format: - the tca threshold value (specify octets in MB), 0 - disable	<i>optional parameter with default value: 0</i> received octets in 15 minute (specify in MB)
[no] tx-octets	Parameter type: <ETHITF::TcaThresholdMB> Format: - the tca threshold value (specify octets in MB), 0 - disable	<i>optional parameter with default value: 0</i> transmitted octets in 15 minute (specify in MB)
[no] los-day	Parameter type: <ETHITF::TcaThresholdLOS> Format: - the tca threshold value (times), 0 - disable	<i>optional parameter with default value: 0</i> loss of signal error in 1 day
[no] fcs-day	Parameter type: <ETHITF::TcaThresholdFCS> Format: - the tca threshold value (frames), 0 - disable	<i>optional parameter with default value: 0</i> frame check sequence error in 1 day
[no] rx-octets-day	Parameter type: <ETHITF::TcaThresholdMB> Format: - the tca threshold value (specify octets in MB), 0 - disable	<i>optional parameter with default value: 0</i> received octets in 1 day (specify in MB)
[no] tx-octets-day	Parameter type: <ETHITF::TcaThresholdMB> Format: - the tca threshold value (specify octets in MB), 0 - disable	<i>optional parameter with default value: 0</i> transmitted octets in 1 day (specify in MB)

43.4 Ethernet Line Mau Configuration Command

Command Description

This command allows the operator to configure the Mau. The configuration is specific per ethernet line.

User Level

The command can be accessed by operators with transport privileges, and executed by operators with transport privileges.

Command Syntax

The command has the following syntax:

```
> configure ethernet line (if-index) mau (index) [ type <Ether::MAUType> ] [ power <ETHITF::Power> ] [ [ no ] speed-auto-sense ] [ [ no ] autonegotiate ] [ [ no ] cap100base-tfd ] [ [ no ] cap1000base-xfd ] [ [ no ] cap1000base-tfd ]
```

Command Parameters

Table 43.4-1 "Ethernet Line Mau Configuration Command" Resource Parameters

Resource Identifier	Type	Description
(if-index)	Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number	interface index of the port
(index)	Format: - port to which the MAU is connected - range: [1...2147483647]	identify MAU, among others connected to same interface

Table 43.4-2 "Ethernet Line Mau Configuration Command" Command Parameters

Parameter	Type	Description
type	Parameter type: <Ether::MAUType> Format: (10baset 100basexhd 100basexfd 100basexhd 100basexfd 1000basexhd 1000basexfd	<i>optional parameter</i> the mau type

Parameter	Type	Description
	1000baselxhd 1000baselxfd 1000basesxhd 1000basesxfd 1000basethd 1000basetfd 10gbasex 10gbaser 10gbaseer 10gbaselr 10gbasesr 100basebx10d 100basebx10u 100baselx10 1000basebx10d 1000basebx10u 1000baselx10 2500basex 10gbasetfd) Possible values: - 10baset : UTP 10M - 100basetxhd : UTP 100M half duplex - 100basetxfd : UTP 100M full duplex - 100basefxhd : X fiber over PMT half duplex - 100basefxfd : X fiber over PMT full duplex - 1000basexhd : PCS/PMA,unknown PMD, half duplex - 1000basexfd : PCS/PMA,unknown PMD, full duplex - 1000baselxhd : fiber over long-wavelength laser half duplex - 1000baselxfd : fiber over long-wavelength laser full duplex - 1000basesxhd : fiber over short-wavelength laser half duplex - 1000basesxfd : fiber over short-wavelength laser full duplex - 1000basethd : UTP 1G half duplex - 1000basetfd : UTP 1G full duplex - 10gbasex : fiber 10G ethernet, PCS 8B/10B - 10gbaser : fiber 10G ethernet, PCS 64B/66B - 10gbaseer : fiber 10G ethernet extended reach, 30km - 10gbaselr : fiber 10G ethernet long reach, 10km - 10gbasesr : fiber 10G ethernet short reach, 300m - 100basebx10d : one single-mode fiber OLT long wavelength, 10km, 100 base - 100basebx10u : one single-mode fiber ONU, long wavelength, 10km, 100 base - 100baselx10 : two single-mode fibers over long wavelength, 10km, 100 base - 1000basebx10d : one single-mode fiber OLT over long wavelength, 10km, 1000 base - 1000basebx10u : one single-mode fiber ONU over long wavelength, 10km, 1000 base - 1000baselx10 : two single-mode fibers over long wavelength, 10km, 1000 base - 2500basex : single-mode fibers, 2.5G base - 10gbasetfd : UTP 10G full duplex	
power	Parameter type: <ETHITF::Power> Format:	<i>optional parameter</i> the administrative status of sfp

43 Ethernet User Ports Configuration Commands

Parameter	Type	Description
	(up down) Possible values: - up : up - down : down	power
[no] speed-auto-sense	Parameter type: boolean	<i>optional parameter</i> enable auto-sensing fiber speed on this port
[no] autonegotiate	Parameter type: boolean	<i>optional parameter</i> enable auto-negotiation on this port
[no] cap100base-tfd	Parameter type: boolean	<i>optional parameter</i> advertise 100M electrical
[no] cap1000base-xfd	Parameter type: boolean	<i>optional parameter</i> advertise 1G optical
[no] cap1000base-tfd	Parameter type: boolean	<i>optional parameter</i> advertise 1G electrical

44- *ONT Ethernet Port Configuration Command*

44.1 ONT Ethernet Port Configuration Command Tree	44-1510
44.2 ONT Ethernet Port Configuration Command	44-1511
44.3 ONT Ethernet Port Physical Layer Performance Monitoring Configuration Command	44-1515
44.4 Ethernet ONT Uni Physical Layer Configuration Command	44-1517
44.5 Ethernet ONT Uni Layer 2 Configuration Command	44-1519
44.6 L2 UNI ONT Performance Monitor Extended 32bit Configuration Command	44-1521
44.7 UNI Port Shutdown-Ais Configuration Commands	44-1523

44.1 ONT Ethernet Port Configuration Command Tree

Description

This chapter gives an overview of nodes that are handled by "ONT Ethernet Port Configuration Command".

Command Tree

```
----configure
  ----ethernet
    ----ont
      - (uni-idx)
      - [no] cust-info
      - auto-detect
      - [no] power-control
      - [no] pse-class
      - [no] pse-pw-priority
      - [no] pwr-override
      - [no] lpt-mode
      - [no] admin-state
    ----X port
      - [no] pm-collect
    ----phy
      - [no] pm
    ----l2
      - [no] pm
      - [no] tca
      - [no] dropped-frames-up
      - [no] dropped-frames-dn
    ----pm-collect-ext
      - [no] pm-collect
      - [no] p-bits
      - [no] vlan-id
    ----cfm
      - [no] portshut-ais
```


44.2 ONT Ethernet Port Configuration Command

Command Description

This command allows the operator to modify ONT Ethernet port provisioning data.

User Level

The command can be accessed by operators with transport privileges, and executed by operators with transport privileges.

Command Syntax

The command has the following syntax:

```
> configure ethernet ont (uni-idx) [ no cust-info | cust-info <Gpon::CustInfo> ] [ auto-detect <Gpon::AutoDetect> ]
[ no power-control | power-control <Gpon::PowerControl> ] [ no pse-class | pse-class <Gpon::PSEClass> ] [ no
pse-pw-priority | pse-pw-priority <Gpon::PSEPwrPri> ] [ no pwr-override | pwr-override
<Gpon::PowerShedOverride> ] [ no lpt-mode | lpt-mode <Gpon::LPTMODE> ] [ no admin-state | admin-state
<Gpon::ItfAdminStatus> ]
```

Command Parameters

Table 44.2-1 "ONT Ethernet Port Configuration Command" Resource Parameters

Resource Identifier	Type	Description
(uni-idx)	Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Gpon::OntSlotId> / <Gpon::OntPortId> ng2 : <Ng2::ChannelGroup> / <Ng2::SubchannelGroup> / <Ng2::OntId> / <Gpon::OntSlotId> / <Gpon::OntPortId>) Possible values: - ng2 : ngpon2 style identification Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Ng2::ChannelGroup> - channel group number Field type <Ng2::SubchannelGroup> - subchannel group number Field type <Eqpt::OntId> - the ONT identifier Field type <Ng2::OntId> - the ONT identifier	identification of the uni interface index

44 ONT Ethernet Port Configuration Command

Resource Identifier	Type	Description
	Field type <Gpon::OntSlotId> - Gpon Ont Slot - range: [1...14] Field type <Gpon::OntPortId> - Gpon Ont Port - range: [1...16]	

Table 44.2-2 "ONT Ethernet Port Configuration Command" Command Parameters

Parameter	Type	Description
[no] cust-info	Parameter type: <Gpon::CustInfo> Format: - a printable string - length: x<=80	<i>optional parameter with default value: "none"</i> port information
auto-detect	Parameter type: <Gpon::AutoDetect> Format: (10_100baset-auto 10baset-fd 100baset-fd 1000baset-fd auto-basetfd 10gig-fd 2.5gig-fd 5gig-fd 10baset-auto 10baset-hd 100baset-hd 1000baset-hd autobaset-hd 10_100_1000baset-auto 100baset-auto auto 1000baset-auto) Possible values: - 10_100baset-auto : 10/100/1000 Base T, auto sensing (note: this auto sensing behavior ensures backward compatibility with older software releases. It may result in the port negotiating to 1 Gbps) - 10baset-fd : 10 Base T, full duplex - 100baset-fd : 100 Base T, full duplex - 1000baset-fd : 1000 Base T, full duplex - auto-basetfd : 10/100/1000 Base T, full duplex - 10gig-fd : 10 Gig, full duplex only - 2.5gig-fd : 2.5 Gig, full duplex only - 5gig-fd : 5 Gig, full duplex only - 10baset-auto : 10 Base T, automatic sensing - 10baset-hd : 10 Base T, half Duplex - 100baset-hd : 100 Base T, half duplex - 1000baset-hd : 1000 Base T, half duplex - autobaset-hd : 10/100/1000 Base T, half duplex - 10_100_1000baset-auto : 10/100/1000 Base T, auto sensing - 100baset-auto : 100 Base T, auto sensing - auto : 10/100/1000 Base T, auto sensing - 1000baset-auto : 1000 Base T auto sensing	<i>optional parameter</i> auto detection configuration
[no] power-control	Parameter type: <Gpon::PowerControl> Format: (enable	<i>optional parameter with default value: "disable"</i> power control configuration

Parameter	Type	Description
	disable) Possible values: - enable : provide power to external equipment - disable : not provide power to external equipment	
[no] pse-class	Parameter type: <Gpon::PSEClass> Format: (0 1 2 3 4 5) Possible values: - 0 : Default output power - 1 : Class 0, the output power is 15.4w - 2 : Class 1, the output power is 4.0w - 3 : Class 2, the output power is 7.0w - 4 : Class 3, the output power is 15.4w - 5 : Class 4, the output power is 30.0w	<i>optional parameter with default value: "0"</i> power class configuration
[no] pse-pw-priority	Parameter type: <Gpon::PSEPwrPri> Format: (critical high low) Possible values: - critical : Prevents overcurrent situations by last disconnecting the ports with critical priority - high : Prevents overcurrent situations by disconnecting the ports with high priority - low : Prevents overcurrent situations by first disconnecting the ports with lower priority(Default)	<i>optional parameter with default value: "low"</i> power supply priority
[no] pwr-override	Parameter type: <Gpon::PowerShedOverride> Format: (enable disable) Possible values: - enable : port is excluded from data class power shedding - disable : port is included in data class power shedding	<i>optional parameter with default value: "disable"</i> configure power shedding
[no] lpt-mode	Parameter type: <Gpon::LPTMODE> Format: (not-supported enabled disabled) Possible values: - not-supported : ignore and don't send the configuration to ONT - enabled : enable the LPT mode on this port - disabled : disable the LPT mode on this port	<i>optional parameter with default value: "not-supported"</i> LinkPassThrough(LPT) mode configuration
[no] admin-state	Parameter type: <Gpon::IfAdminStatus> Format: (up down) Possible values: - up : set the admin-state to up - down : set the admin-state to down	<i>optional parameter with default value: "down"</i> <i>The parameter is not visible during creation.</i> administrative status of the interface

Command Output

Table 44.2-3 "ONT Ethernet Port Configuration Command" Display parameters

Specific Information		
name	Type	Description
oper-state	Parameter type: <Itf::ifOperStatus> (up down testing unknown dormant no-value) Possible values: - up : up,traffic can pass - down : down,no traffic is passing - testing : testing,no traffic is passing - unknown : unknown - dormant : dormant,no traffic is passing - no-value : no entry in the table	the operational state of the interface <i>This element is always shown.</i>

44.3 ONT Ethernet Port Physical Layer

Performance Monitoring Configuration Command

Command Description

Obsolete command, replaced by `configure ethernet ont phy pm`.

This command allows the operator to enable or disable PM on the ONT ethernet port physical layer.

User Level

The command can be accessed by operators with transport privileges, and executed by operators with transport privileges.

Command Syntax

The command has the following syntax:

```
> configure ethernet ont (uni-idx) port [ no pm-collect | pm-collect <Gpon::OntPmCollect> ]
```

Obsolete command, replaced by `configure ethernet ont phy pm`.

Command Parameters

Table 44.3-1 "ONT Ethernet Port Physical Layer Performance Monitoring Configuration Command" Resource Parameters

Resource Identifier	Type	Description
(uni-idx)	Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Gpon::OntSlotId> / <Gpon::OntPortId> ng2 : <Ng2::ChannelGroup> / <Ng2::SubchannelGroup> / <Ng2::OntId> / <Gpon::OntSlotId> / <Gpon::OntPortId>) Possible values: - ng2 : ngpon2 style identification Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Ng2::ChannelGroup> - channel group number Field type <Ng2::SubchannelGroup> - subchannel group number Field type <Eqpt::OntId>	identification of the uni interface index

44 ONT Ethernet Port Configuration Command

Resource Identifier	Type	Description
	- the ONT identifier Field type <Ng2::OntId> - the ONT identifier Field type <Gpon::OntSlotId> - Gpon Ont Slot - range: [1...14] - Gpon Ont Port Field type <Gpon::OntPortId> - Gpon Ont Port - range: [1...16]	

Table 44.3-2 "ONT Ethernet Port Physical Layer Performance Monitoring Configuration Command" Command Parameters

Parameter	Type	Description
[no] pm-collect	Parameter type: <Gpon::OntPmCollect> Format: (enable disable) Possible values: - enable : enable PM - disable : disable PM	<i>optional parameter with default value: "disable"</i> ethernet port physical layer performance monitoring

44.4 Ethernet ONT Uni Physical Layer Configuration Command

Command Description

This command allows the operator to provision performance monitoring for an Ethernet ONT physical layer UNI.

User Level

The command can be accessed by operators with transport privileges, and executed by operators with transport privileges.

Command Syntax

The command has the following syntax:

```
> configure ethernet ont (uni-idx) phy [ no pm | pm <Gpon::OntPmCollect> ]
```

Command Parameters

Table 44.4-1 "Ethernet ONT Uni Physical Layer Configuration Command" Resource Parameters

Resource Identifier	Type	Description
(uni-idx)	Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Gpon::OntSlotId> / <Gpon::OntPortId> ng2 : <Ng2::ChannelGroup> / <Ng2::SubchannelGroup> / <Ng2::OntId> / <Gpon::OntSlotId> / <Gpon::OntPortId>) Possible values: - ng2 : ngpon2 style identification Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Ng2::ChannelGroup> - channel group number Field type <Ng2::SubchannelGroup> - subchannel group number Field type <Eqpt::OntId> - the ONT identifier Field type <Ng2::OntId> - the ONT identifier Field type <Gpon::OntSlotId>	identification of the uni interface index

Resource Identifier	Type	Description
	- Gpon Ont Slot - range: [1...14] Field type <Gpon::OntPortId> - Gpon Ont Port - range: [1...16]	

Table 44.4-2 "Ethernet ONT Uni Physical Layer Configuration Command" Command Parameters

Parameter	Type	Description
[no] pm	Parameter type: <Gpon::OntPmCollect> Format: (enable disable) Possible values: - enable : enable PM - disable : disable PM	<i>optional parameter with default value: "disable"</i> physical layer pm collection

Command Output

Table 44.4-3 "Ethernet ONT Uni Physical Layer Configuration Command" Display parameters

Specific Information		
name	Type	Description
pm-intervals	Parameter type: <SignedInteger> - a signed integer	number of rows currently present in the gponEtherTrafficIntervalTable <i>This element is only shown in detail mode.</i>

44.5 Ethernet ONT Uni Layer 2 Configuration Command

Command Description

This command allows the operator to provision performance monitoring and threshold crossing alerts for an Ethernet ONT layer 2 UNI.

User Level

The command can be accessed by operators with transport privileges, and executed by operators with transport privileges.

Command Syntax

The command has the following syntax:

```
> configure ethernet ont (uni-idx) l2 [ no pm | pm <Gpon::OntPmCollect> ] [ no tca | tca <Gpon::OntPmCollect> ] [
no dropped-frames-up | dropped-frames-up <Gpon::ErrorCountThreshold> ] [ no dropped-frames-dn |
dropped-frames-dn <Gpon::ErrorCountThreshold> ]
```

Command Parameters

Table 44.5-1 "Ethernet ONT Uni Layer 2 Configuration Command" Resource Parameters

Resource Identifier	Type	Description
(uni-idx)	Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Gpon::OntSlotId> / <Gpon::OntPortId> ng2 : <Ng2::ChannelGroup> / <Ng2::SubchannelGroup> / <Ng2::OntId> / <Gpon::OntSlotId> / <Gpon::OntPortId>) Possible values: - ng2 : ngpon2 style identification Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Ng2::ChannelGroup> - channel group number Field type <Ng2::SubchannelGroup> - subchannel group number Field type <Eqpt::OntId> - the ONT identifier	identification of the uni interface index

Resource Identifier	Type	Description
	Field type <Ng2::OntId> - the ONT identifier Field type <Gpon::OntSlotId> - Gpon Ont Slot - range: [1...14] Field type <Gpon::OntPortId> - Gpon Ont Port - range: [1...16]	

Table 44.5-2 "Ethernet ONT Uni Layer 2 Configuration Command" Command Parameters

Parameter	Type	Description
[no] pm	Parameter type: <Gpon::OntPmCollect> Format: (enable disable) Possible values: - enable : enable PM - disable : disable PM	<i>optional parameter with default value: "disable"</i> l2 pm collection
[no] tca	Parameter type: <Gpon::OntPmCollect> Format: (enable disable) Possible values: - enable : enable PM - disable : disable PM	<i>optional parameter with default value: "disable"</i> l2 threshold crossing alerts
[no] dropped-frames-up	Parameter type: <Gpon::ErrorCountThreshold> Format: (disable <Gpon::ErrorCountThreshold>) Possible values: - disable : disable tca Field type <Gpon::ErrorCountThreshold> - error count threshold (0-4294967295) - range: [0...4294967295]	<i>optional parameter with default value: "disable"</i> incoming (upstream) dropped frames threshold
[no] dropped-frames-dn	Parameter type: <Gpon::ErrorCountThreshold> Format: (disable <Gpon::ErrorCountThreshold>) Possible values: - disable : disable tca Field type <Gpon::ErrorCountThreshold> - error count threshold (0-4294967295) - range: [0...4294967295]	<i>optional parameter with default value: "disable"</i> outgoing (downstream) dropped frames threshold

Command Output

Table 44.5-3 "Ethernet ONT Uni Layer 2 Configuration Command" Display parameters

Specific Information		
name	Type	Description
pm-intervals	Parameter type: <SignedInteger> - a signed integer	number of rows currently present in the gponEtherTrafficIntervalTable <i>This element is only shown in detail mode.</i>

44.6 L2 UNI ONT Performance Monitor Extended 32bit Configuration Command

Command Description

This command sets the PM EXT parameters.

User Level

The command can be accessed by operators with equipment privileges, and executed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

```
> configure ethernet ont (uni-idx) l2 pm-collect-ext [ no pm-collect | pm-collect <Gpon::OntPmCollect> ] [ no p-bits | p-bits <SignedInteger> ] [ no vlan-id | vlan-id <Vlan::VlanIndexOrZero> ]
```

Command Parameters

Table 44.6-1 "L2 UNI ONT Performance Monitor Extended 32bit Configuration Command" Resource Parameters

Resource Identifier	Type	Description
(uni-idx)	Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Gpon::OntSlotId> / <Gpon::OntPortId> ng2 : <Ng2::ChannelGroup> / <Ng2::SubchannelGroup> / <Ng2::OntId> / <Gpon::OntSlotId> / <Gpon::OntPortId>) Possible values: - ng2 : ngpon2 style identification Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Ng2::ChannelGroup> - channel group number Field type <Ng2::SubchannelGroup> - subchannel group number Field type <Eqpt::OntId> - the ONT identifier Field type <Ng2::OntId>	identification of the uni interface index

44 ONT Ethernet Port Configuration Command

Resource Identifier	Type	Description
	- the ONT identifier Field type <Gpon::OntSlotId> - Gpon Ont Slot - range: [1...14] Field type <Gpon::OntPortId> - Gpon Ont Port - range: [1...16]	

**Table 44.6-2 "L2 UNI ONT Performance Monitor Extended 32bit Configuration Command"
Command Parameters**

Parameter	Type	Description
[no] pm-collect	Parameter type: <Gpon::OntPmCollect> Format: (enable disable) Possible values: - enable : enable PM - disable : disable PM	<i>optional parameter with default value: "disable"</i> indicates whether enable this pm collect for this Ethernet Port
[no] p-bits	Parameter type: <SignedInteger> Format: - a signed integer	<i>optional parameter with default value: 0xFF</i> indicates the P bits of the TCI field are used to filter the PM data collected or not 0xFF: not used 0-7: p-bit used to filter data
[no] vlan-id	Parameter type: <Vlan::VlanIndexOrZero> Format: - vlan id - range: [0...4092]	<i>optional parameter with default value: 0</i> indicates the vlan-id bits of the TCI field are used to filter the PM data collected 0: not used Other value : this vlan-id used to filter data

44.7 UNI Port Shutdown-Ais Configuration Commands

Command Description

This attribute is linked to a CFM functionality on the ONU. It indicates if the ONU is programmed to autonomously shut down its UNI upon reception of a downstream AIS PDU on an UP MEP residing on top of the ONU UNI.

User Level

The command can be accessed by operators with transport privileges, and executed by operators with transport privileges.

Command Syntax

The command has the following syntax:

```
> configure ethernet ont (uni-idx) cfm [ [ no ] portshut-ais ]
```

Command Parameters

Table 44.7-1 "UNI Port Shutdown-Ais Configuration Commands" Resource Parameters

Resource Identifier	Type	Description
(uni-idx)	Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Gpon::OntSlotId> / <Gpon::OntPortId> ng2 : <Ng2::ChannelGroup> / <Ng2::SubchannelGroup> / <Ng2::OntId> / <Gpon::OntSlotId> / <Gpon::OntPortId>) Possible values: - ng2 : ngpon2 style identification Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Ng2::ChannelGroup> - channel group number Field type <Ng2::SubchannelGroup> - subchannel group number Field type <Eqpt::OntId> - the ONT identifier Field type <Ng2::OntId> - the ONT identifier	identification of the uni interface index

44 ONT Ethernet Port Configuration Command

Resource Identifier	Type	Description
	Field type <Gpon::OntSlotId> - Gpon Ont Slot - range: [1...14] Field type <Gpon::OntPortId> - Gpon Ont Port - range: [1...16]	

Table 44.7-2 "UNI Port Shutdown-Ais Configuration Commands" Command Parameters

Parameter	Type	Description
[no] portshut-ais	Parameter type: boolean	<i>optional parameter</i> shutdown the corresponding Ethernet port on ONT when receiving DS Y.1731 AIS PDU.

45- Epon Ont Ethernet Configuration Command

45.1 Epon Ont Ethernet Configuration Command Tree	45-1526
45.2 Epon Ont ethernet Configuration Command	45-1527
45.3 Epon Ont Flow Configuration Command	45-1528
45.4 Epon Ont Ethernet Multicast Vlan Configuration Command	45-1530
45.5 Epon Ont Ethernet Vlan Translation Configuration Command	45-1532
45.6 Epon Ont Ethernet Multicast Vlan Translation Configuration Command	45-1534

45.1 Epon Ont Ethernet Configuration Command Tree

Description

This chapter gives an overview of nodes that are handled by "Epon Ont Ethernet Configuration Command".

Command Tree

```
----configure
  ----ethernet
    ----eont
      ----[no] port
        - (uni-index)
          ----[no] filter
            - (filterid)
            - profileid
            - precedence
            - [no] acl
            - [no] dot1p
            - [no] llid
            - queueid
          ----[no] snoopmcastvlan
            - (vlanid)
          ----[no] usercvlan
            - (usercvlanid)
            - networkcvlan
          ----[no] mcastvlan
            - (mcastvlanid)
            - uservlan
```


45.2 Epon Ont ethernet Configuration Command

Command Description

This command allows the operator to configure ethernet parameters of ONT physical UNI

User Level

The command can be accessed by operators with transport privileges, and executed by operators with transport privileges.

Command Syntax

The command has the following syntax:

```
> configure ethernet eont ( no port (uni-index) ) | ( port (uni-index) )
```

Command Parameters

Table 45.2-1 "Epon Ont ethernet Configuration Command" Resource Parameters

Resource Identifier	Type	Description
(uni-index)	Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Epon::EontSlot> / <Epon::EontPort> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Eqpt::OntId> - the ONT identifier Field type <Epon::EontSlot> - Epon Ont Slot - range: [1...16] Field type <Epon::EontPort> - Epon Ont Port - range: [1...64]	ONT UNI interface

45.3 Epon Ont Flow Configuration Command

Command Description

This command allows the operator to configure traffic flows at ONT physical UNI

Note: The ont flow can be created or deleted, but cannot be modified

User Level

The command can be accessed by operators with equipment privileges, and executed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

```
> configure ethernet eont port (uni-index) ( no filter (filterid) ) | ( filter (filterid) profileid <Epon::ProfileId>
precedence <Epon::Precedence> [ no acl | acl <Epon::Acl> ] [ no dot1p | dot1p <Epon::FilterPBit> ] [ no llid | llid
<Epon::Llid> ] queueid <Epon::QueueId> )
```

Command Parameters

Table 45.3-1 "Epon Ont Flow Configuration Command" Resource Parameters

Resource Identifier	Type	Description
(uni-index)	Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Epon::EontSlot> / <Epon::EontPort> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Eqpt::OntId> - the ONT identifier Field type <Epon::EontSlot> - Epon Ont Slot - range: [1...16] Field type <Epon::EontPort> - Epon Ont Port - range: [1...64]	ONT UNI interface
(filterid)	Format: - Filter ID - range: [1...8]	Filter identifier

Table 45.3-2 "Epon Ont Flow Configuration Command" Command Parameters

Parameter	Type	Description
profileid	Parameter type: <Epon::ProfileId> Format: - traffic profile ID - range: [1...8192]	<i>mandatory parameter</i> traffic profile ID used to classify traffic
precedence	Parameter type: <Epon::Precedence> Format: - flow precedence - range: [1...8]	<i>mandatory parameter</i> flow precedence
[no] acl	Parameter type: <Epon::Acl> Format: (pass drop) Possible values: - pass : flow behavior pass - drop : flow behavior drop	<i>optional parameter with default value: "pass"</i> flow behavior
[no] dot1p	Parameter type: <Epon::FilterPBit> Format: - default pbit - range: [0...7,255]	<i>optional parameter with default value: "255"</i> default pbit of this port
[no] llid	Parameter type: <Epon::Llid> Format: - logical link ID,only for EPON onu. As to DPOE, 1*1 llidpattern onu has 1 llid binding with 4 queues; 2*1 llidpattern onu has 2 llids, each llid binding with 4 queues; for 1*4/1*8/2*4 , llid n is fixedly binded with queue n,that is,llid 1 is binded with queue 1... - range: [1...1]	<i>optional parameter with default value: "1"</i> logical link id for this flow
queueid	Parameter type: <Epon::QueueId> Format: - queue for the flow,range 1-4 for EPON,range 1-8 for DPOE. As to DPOE, for 1*1/2*1/1*4 llidpattern onu, range is 1-4; for 1*8/2*4 llidpattern onu, range is 1-8. - range: [1...8]	<i>mandatory parameter</i> queue for this flow. Mandatory parameter.

45.4 Epon Ont Ethernet Multicast Vlan Configuration Command

Command Description

This command allows the operator to configure multicast vlan allowed for Ethernet port.

Note: The multicast vlan for port cannot be modified.

User Level

The command can be accessed by operators with equipment privileges, and executed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

```
> configure ethernet eont port (uni-index) ( no snoopmcastvlan (vlanid) ) | ( snoopmcastvlan (vlanid) )
```

Command Parameters

Table 45.4-1 "Epon Ont Ethernet Multicast Vlan Configuration Command" Resource Parameters

Resource Identifier	Type	Description
(uni-index)	Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Epon::EontSlot> / <Epon::EontPort> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Eqpt::OntId> - the ONT identifier Field type <Epon::EontSlot> - Epon Ont Slot - range: [1...16] Field type <Epon::EontPort> - Epon Ont Port - range: [1...64]	ONT UNI interface
(vlanid)	Format: - vlan id - range: [1...4093]	multicast vlan id allowed for port

45.5 Epon Ont Ethernet Vlan Translation Configuration Command

Command Description

This command allows the operator to configure vlan translation for tagged packet on ont Ethernet port.

Note: The networkcvlan cannot be modified

Note: This command should be shown only if the vlanmode of the Ethernet port is translation, trunk or aggregation.

User Level

The command can be accessed by operators with equipment privileges, and executed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

```
> configure ethernet eont port (uni-index) ( no usercvlan (usercvlanid) ) | ( usercvlan (usercvlanid) [ networkcvlan
<Epon::NwCvlanId> ] )
```

Command Parameters

Table 45.5-1 "Epon Ont Ethernet Vlan Translation Configuration Command" Resource Parameters

Resource Identifier	Type	Description
(uni-index)	Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Epon::EontSlot> / <Epon::EontPort> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Eqpt::OntId> - the ONT identifier Field type <Epon::EontSlot> - Epon Ont Slot - range: [1...16] Field type <Epon::EontPort> - Epon Ont Port - range: [1...64]	ONT UNI interface

Resource Identifier	Type	Description
(usercvlanid)	Format: - vlan id - range: [1...4093]	userside vlan id allowed for port

Table 45.5-2 "Epon Ont Ethernet Vlan Translation Configuration Command" Command Parameters

Parameter	Type	Description
networkcvlan	Parameter type: <Epon::NwCvlanId> Format: - vlan id - range: [1...4093]	<i>optional parameter</i> the networkside VLAN of the physical UNI and when you don't config the network VLAN, don't enter the keyword networkcvlan

45.6 Epon Ont Ethernet Multicast Vlan Translation Configuration Command

Command Description

This command allows the operator to configure multicast vlan translation if multiconf for this port is translation.

Note: the uservlan cannot be modified.

Note: This command should be shown only if the multiconf of the Ethernet port is translation.

User Level

The command can be accessed by operators with equipment privileges, and executed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

```
> configure ethernet eont port (uni-index) ( no mcastvlan (mcastvlanid) ) | ( mcastvlan (mcastvlanid) uservlan
<Epon::uservlan> )
```

Command Parameters

Table 45.6-1 "Epon Ont Ethernet Multicast Vlan Translation Configuration Command" Resource Parameters

Resource Identifier	Type	Description
(uni-index)	Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Epon::EontSlot> / <Epon::EontPort> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Eqpt::OntId> - the ONT identifier Field type <Epon::EontSlot> - Epon Ont Slot - range: [1...16] Field type <Epon::EontPort> - Epon Ont Port - range: [1...64]	ONT UNI interface

Resource Identifier	Type	Description
(mcastvlanid)	Format: - vlan id - range: [1...4093]	macst VLAN ID

Table 45.6-2 "Epon Ont Ethernet Multicast Vlan Translation Configuration Command" Command Parameters

Parameter	Type	Description
uservlan	Parameter type: <Epon::uservlan> Format: - vlan id - range: [1...4093]	<i>mandatory parameter</i> the userside VLAN

46- Efm Oam Configuration Commands

46.1 Efm Oam Configuration Command Tree	46-1537
46.2 Efm Oam Interface ConfigurationCommand	46-1538

46.1 Efm Oam Configuration Command Tree

Description

This chapter gives an overview of nodes that are handled by "Efm Oam Configuration Commands".

Command Tree

```
----configure
  ----efm-oam
    ----interface
      - (interface)
      - [no] admin-up
      - [no] passive-mode
      - [no] keep-alive-intvl
      - [no] response-intvl
      X data-length
      X bitrate
      X smac
      X dmac
```

46.2 Efm Oam Interface ConfigurationCommand

Command Description

This command will allow the operator to enable/disable EFM OAM on the specified Ethernet-like interface and configure the mode, alive timer and response timer intervals. In addition also the internal traffic generator data applicable to this interface can be configured.

User Level

The command can be accessed by operators with transport privileges, and executed by operators with transport privileges.

Command Syntax

The command has the following syntax:

```
> configure efm-oam interface (interface) [ [ no ] admin-up ] [ [ no ] passive-mode ] [ no keep-alive-intvl |
keep-alive-intvl <Ether::KeepAliveTimeTicks> ] [ no response-intvl | response-intvl <Ether::ResponseTimeTicks>
] [ data-length <Ether::TraffGenDataLengthType> ] [ bitrate <Ether::TraffGenBitRateType> ] [ smac
<Ether::MacAddr> ] [ dmac <Ether::MacAddr> ]
```

Command Parameters

Table 46.2-1 "Efm Oam Interface ConfigurationCommand" Resource Parameters

Resource Identifier	Type	Description
(interface)	Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number	identification of EFM port / Ethernet port

Table 46.2-2 "Efm Oam Interface ConfigurationCommand" Command Parameters

Parameter	Type	Description
[no] admin-up	Parameter type: boolean	<i>optional parameter</i> enable efm oam
[no] passive-mode	Parameter type: boolean	<i>optional parameter</i> oam mode is passive
[no] keep-alive-intvl	Parameter type: <Ether::KeepAliveTimeTicks> Format: - a timeout value expressed in seconds - unit: seconds - range: [1...300]	<i>optional parameter with default value: 300</i> keep alive time interval

Parameter	Type	Description
[no] response-intvl	Parameter type: <Ether::ResponseTimeTicks> Format: - a timeout value expressed in seconds - unit: seconds - range: [2...10]	<i>optional parameter with default value: 5</i> variable response interval
data-length	Parameter type: <Ether::TraffGenDataLengthType> Format: - A value of 1 up to 1500. Indicates length in bytes. - unit: byte - range: [1...1500]	<i>obsolete parameter that will be ignored</i> Internal traffic generator data: Length of datafield, in bytes, of the to be generated test traffic. Must be a value from 1 up to 1500.
bitrate	Parameter type: <Ether::TraffGenBitRateType> Format: (100k 1m 10m 100m 1g) Possible values: - 100k : bitrate = 100K bit/sec - 1m : bitrate = 1M bit/sec - 10m : bitrate = 10M bit/sec - 100m : bitrate = 100M bit/sec - 1g : bitrate = 1G bit/sec	<i>obsolete parameter that will be ignored</i> Internal traffic generator data: Bitrate of the to be generated test traffic.
smac	Parameter type: <Ether::MacAddr> Format: - mac address (aa:bb:cc:a1:02:03) - length: 6	<i>obsolete parameter that will be ignored</i> Internal traffic generator data: source MAC address.
dmac	Parameter type: <Ether::MacAddr> Format: - mac address (aa:bb:cc:a1:02:03) - length: 6	<i>obsolete parameter that will be ignored</i> Internal traffic generator data: destination MAC address.

47- CFM Configuration Commands

47.1 CFM Configuration Command Tree	47-1541
47.2 Maintenance Domain Configuration Command	47-1543
47.3 Maintenance Association Configuration Command	47-1545
47.4 Maintenance Association End Point Configuration Command	47-1549
47.5 MEP located on ONU UNI enabled ITU-T Y.1731 Ethernet Alarm Indication Signal(ETH-AIS) function Configuration Commands	47-1553
47.6 Active Remote Maintenance Association End Point Configuration Command	47-1555
47.7 Remote Maintenance Association End Point Configuration Command	47-1556
47.8 Synthetic Loss Measurement configuration Commands	47-1557
47.9 CFM PM-Proactive test management Command	47-1558
47.10 CFM PM Proactive test management Command	47-1559

47.1 CFM Configuration Command Tree

Description

This chapter gives an overview of nodes that are handled by "CFM Configuration Commands".

Command Tree

```

----configure
  ----cfm
    ----[no] domain
      - (domain-index)
      - name
      - level
    ----[no] association
      - (association-index)
      - [no] bridgeport
      - [no] vlan
      - [no] mhf-creation
      - name
      - [no] ccm-interval
      - [no] ccm-aware
      - [no] ccm-admin-state
      - [no] mhf-location
      - ltm-filtering
      - [no] dual-tag-aware
    ----[no] mep
      - (mepid)
      - location
      - [no] cci-enable
      - [no] ccm-priority
      - [no] equipment
      - [no] low-pri-defect
      - [no] fng-alarm-time
      - [no] fng-reset-time
      - [no] slm-resp-enable
      - [no] dm-resp-enable
      - [no] lm-resp
      - [no] slm-init-enable
      - [no] lm-init
    ----y1731ais
      - [no] ais-enable
      - [no] meg-level
      - [no] period
      - [no] priority
      - [no] portshut-enable
    ----[no] active-remote-mep
      - (active-remote-mepid)
    ----[no] remote-mep
      - (rmepid)
  ----slm
    - [no] inactivity-time
  ----y1731pm

```

----[no] domain

- (domain-index)
- association
- mep
- session-id
- type
- target-mac
- [no] priority
- [no] admin-up
- interval
- size
- measurement-intvl

47.2 Maintenance Domain Configuration Command

Command Description

This command is used to define a Maintenance Domain (MD) at particular maintenance level. There are 8 possible levels. Note that once created, the MD cannot be modified. To modify, delete the entry and create a new one.

Note that, if an MD is deleted, any subtending Maintenance Associations (MAs), and their subtending Maintenance Points (MPs), will be automatically deleted only if CCM Admin State is locked for all of the MAs.

User Level

The command can be accessed by operators with alarm , oam , vlan privileges, and executed by operators with alarm , oam , vlan privileges.

Command Syntax

The command has the following syntax:

```
> configure cfm ( no domain (domain-index) ) | ( domain (domain-index) name <Cfm::FormattedName> level
<Cfm::MdLevelType> )
```

Command Parameters

Table 47.2-1 "Maintenance Domain Configuration Command" Resource Parameters

Resource Identifier	Type	Description
(domain-index)	Format: - Maintenance Domain (MD) index - range: [1...4294967295]	Maintenance Domain (MD) index

Table 47.2-2 "Maintenance Domain Configuration Command" Command Parameters

Parameter	Type	Description
name	Parameter type: <Cfm::FormattedName> Format: (dns : <Cfm::PrintableString> mac : <Cfm::MacAddress> string : <Cfm::PrintableString> none) Possible values: - dns : DNS name (e.g. nokia.com) - mac : MAC address plus 2 hex octets, e.g. 11:22:33:44:55:66:77:88 - string : A character string (e.g. operator) - none : No MD name. Field type <Cfm::PrintableString> - all characters except for characters 0 to 31 - length: 1<=x<=43 Field type <Cfm::MacAddress> - MAC address plus 2 hex octets, e.g.	<i>mandatory parameter</i> <i>The parameter is not visible during modification.</i> Maintenance Domain (MD) name type and unique name

47 CFM Configuration Commands

Parameter	Type	Description
	11:22:33:44:55:66:77:88 - length: 8	
level	Parameter type: <Cfm::MdLevelType> Format: - Maintenance Domain (MD) level - range: [0...7]	<i>mandatory parameter</i> <i>The parameter is not visible during modification.</i> Maintenance Domain (MD) level

47.3 Maintenance Association Configuration

Command

Command Description

This command is used to create or modify a Maintenance Association (MA). The VlanId has been made optional in the Command Syntax as VlanId is mandatory for creation and is not applicable for modification. Each Maintenance Domain (MD) can have one or more MAs.

Note that, if an MA is deleted, any subtending Maintenance Points (MPs) will automatically be deleted.

Maintenance Association (MA) name and type is unique within the domain. When MA name is not configured explicitly during MA creation, default ma name is computed as follows. Ex: default name for ma 1 is ma1 of string type

User Level

The command can be accessed by operators with alarm , oam , vlan privileges, and executed by operators with alarm , oam , vlan privileges.

Command Syntax

The command has the following syntax:

```
> configure cfm domain (domain-index) ( no association (association-index) ) | ( association (association-index) [
no bridgeport | bridgeport <Cfm::InterfaceZeroIndex> ] [ no vlan | vlan <Network::StackedVlan> ] [ no
mhf-creation | mhf-creation <Cfm::CfmMhfCreationType> ] [ name <Cfm::MaFormattedName> ] [ no ccm-interval
| ccm-interval <Cfm::CfmMaCcmInterval> ] [ [ no ] ccm-aware ] [ no ccm-admin-state | ccm-admin-state
<Cfm::CfmMaCcmAdminState> ] [ no mhf-location | mhf-location <Cfm::CfmMaMhfLocationType> ] [
ltm-filtering <Cfm::CfmMaLtmFilter> ] [ [ no ] dual-tag-aware ] )
```

Command Parameters

Table 47.3-1 "Maintenance Association Configuration Command" Resource Parameters

Resource Identifier	Type	Description
(domain-index)	Format: - Maintenance Domain (MD) index - range: [1...4294967295]	Maintenance Domain (MD) index
(association-index)	Format: - Maintenance Association (MA) index. Unique within an MD - range: [1...4294967295]	Maintenance Association (MA) index. Unique within an MD

Table 47.3-2 "Maintenance Association Configuration Command" Command Parameters

Parameter	Type	Description
[no] bridgeport	Parameter type: <Cfm::InterfaceZeroIndex> Format: (none	optional parameter with default value: "none" The parameter is not visible

Parameter	Type	Description
	<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> / <Eqpt::OntPortId> ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / <Eqpt::Ng2OntSlotId> / <Eqpt::Ng2OntPortId> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / vuni) Possible values: - none : no port - ng2 : ngpon2 style identification Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number Field type <Eqpt::PonId> - the PON identifier Field type <Eqpt::OntId> - the ONT identifier Field type <Eqpt::ChannelGroupId> - the channel group identifier Field type <Eqpt::SubChannelGroupId> - the subchannel group identifier Field type <Eqpt::Ng2OntId> - the NG2 ONT identifier Possible values: - voip : virtual uni identifier Possible values: - vuni : virtual NGPON2 uni identifier Field type <Eqpt::OntSlotId> - the ONT SLOT identifier Field type <Eqpt::OntPortId> - the ONT PORT identifier Field type <Eqpt::Ng2OntSlotId> - the NGPON2 ONT SLOT identifier Field type <Eqpt::Ng2OntPortId> - the NGPON2 ONT PORT identifier	during modification. IfIndex of UNI
[no] vlan	Parameter type: <Network::StackedVlan> Format: (<Network::UVlanIndex> stacked : <Network::SVlanIndex> : <Network::CVlanIndex>) Possible values: - stacked : stacked vlan identity Field type <Network::UVlanIndex> - unstacked vlan identity - range: [1...4093] Field type <Network::SVlanIndex> - service vlan identity - range: [2...4093] Field type <Network::CVlanIndex>	optional parameter with default value: "stacked : 0 : 4097" The parameter is not visible during modification. when vlan is not specified it will be vlan Unaware MA

Parameter	Type	Description
	- customer vlan identity - range: [0...4093]	
[no] mhf-creation	Parameter type: <Cfm::CfmMhfCreationType> Format: (mhf-none mhf-default) Possible values: - mhf-none : No MHF creation for this VLAN ID - mhf-default : MHF creation for this VLAN ID on related bridge ports	<i>optional parameter with default value: "mhf-none"</i> MIP Half Function (MHF) creation control
name	Parameter type: <Cfm::MaFormattedName> Format: (pvid : <Cfm::MaNamePvid> string : <Cfm::MaNameCharstr> uint16 : <Cfm::MaNameUint16> vpnid : <Cfm::MaVpnid> icc : <Cfm::MaNameIcc>) Possible values: - pvid : [0...4094] - string : Raw ascii up to 45 Characters, except the character code 0-31(decimal) are not used - uint16 : [0..65535] - vpnid : RFC-2685 VPN ID Format(7 Octet): xxx:xxx, eg:000102:FFAA77BB, x is between 00 and FF - icc : Raw ascii exactly 13 characters, except the character code 0-31(decimal) are not used Field type <Cfm::MaNamePvid> - MaName Pvid Range [0...4094] - length: x<=4 Field type <Cfm::MaNameCharstr> - Raw ascii up to 45 Characters, except the character code 0-31 decimal - length: x<=45 Field type <Cfm::MaNameUint16> - MaName Uint16 Range [0...65535] - length: x<=5 Field type <Cfm::MaVpnid> - MaName VpnId 7 Octet Format : xxx:xxx, where x is a between 00 and FF eg:11FF33:AABBCCDD - length: 15 Field type <Cfm::MaNameIcc> - MaName Icc Raw ascii exactly 13 characters - length: 13	<i>optional parameter</i> Maintenance Association (MA) name and type is unique within the domain.
[no] ccm-interval	Parameter type: <Cfm::CfmMaCcmInterval> Format: (0 3.33ms 10ms 100ms 1 10 60 600) Possible values: - 0 : CCM Rx disable - 3.33ms : CCM Interval 3.33 mSecs - 10ms : CCM Interval 10 mSecs	<i>optional parameter with default value: "10"</i> CCM Tx Interval for the MA

47 CFM Configuration Commands

Parameter	Type	Description
	- 100ms : CCM Interval 100 mSecs - 1 : CCM Interval 1 secs - 10 : CCM Interval 10 secs - 60 : CCM Interval 1 Min - 600 : CCM Interval 10 Min	
[no] ccm-aware	Parameter type: boolean	<i>optional parameter</i> turn on the CCM frame processing on reception
[no] ccm-admin-state	Parameter type: <Cfm::CfmMaCcmAdminState> Format: (unlock lock) Possible values: - unlock : sets CCM AdminState to activate(unlock) ccm function - lock : sets CCM AdminState to de-activate(lock) ccm function	<i>optional parameter with default value: "lock"</i> activate(unlock)/de-activate(lock) CCM function on the MA
[no] mhf-location	Parameter type: <Cfm::CfmMaMhfLocationType> Format: (default ltuplink vbp onu ltuplink-vbp ltuplink-onu vbp-onu ltuplink-vbp-onu) Possible values: - default : default value: for GPON board, MIP is set on onu; for DSL board, MIP is set on vbp. - ltuplink : MIP is set on lt uplink - vbp : MIP is set on olt virtual bridgeport - onu : MIP is set on onu - ltuplink-vbp : MIPs are set on lt up link and virtual bridgeport - ltuplink-onu : MIPs are set on lt uplink and onu - vbp-onu : MIPs are set on virtual bridgeport and onu - ltuplink-vbp-onu : MIPs are set on olt uplink, virtual bridgeport and onu	<i>optional parameter with default value: "default"</i> <i>The parameter is not visible during modification.</i> MA Mhf Location : distinguish MIP location
ltm-filtering	Parameter type: <Cfm::CfmMaLtmFilter> Format: (enable disable) Possible values: - enable : enable ltm-filtering - disable : disable ltm-filtering	<i>optional parameter</i> Upstream LTM filtering enable/disable. default = enable
[no] dual-tag-aware	Parameter type: boolean	<i>optional parameter</i> Process CFM Messages upto 2 vlan tags in C-Vlan CC mode, refer OAM documentation for hardware support information.

47.4 Maintenance Association End Point Configuration Command

Command Description

This command is used to configure a Maintenance association End Point (MEP) within a Maintenance Association (MA). Each MA can have zero or more MEPs. Once a MEP is created, it cannot be modified. To modify the MEP, delete the entry and create a new one.

Note that there are correlations between a MEP and a VLAN port location. To create a MEP, the MEP's MA must be associated with the VLAN-port location's VLAN. Also if the VLAN-port is deleted, the related MEP(s) will automatically be deleted.

User Level

The command can be accessed by operators with alarm , oam , vlan privileges, and executed by operators with alarm , oam , vlan privileges.

Command Syntax

The command has the following syntax:

```
> configure cfm domain (domain-index) association (association-index) ( no mep (mepid) ) | ( mep (mepid)
location <Cfm::location> [ [ no ] cci-enable ] [ no ccm-priority | ccm-priority <Cfm::MepCcmPriority> ] [ no
equipment | equipment <Cfm::MepEquipmentType> ] [ no low-pri-defect | low-pri-defect
<Cfm::MepLowPriorityDefect> ] [ no fng-alarm-time | fng-alarm-time <Cfm::MepFngAlarmTime> ] [ no
fng-reset-time | fng-reset-time <Cfm::MepFngResetTime> ] [ [ no ] slm-resp-enable ] [ [ no ] dm-resp-enable ] [ no
lm-resp | lm-resp <Cfm::MepLmEnableDisable> ] [ [ no ] slm-init-enable ] [ no lm-init | lm-init
<Cfm::MepLmInitEnableDisable> ] )
```

Command Parameters

Table 47.4-1 "Maintenance Association End Point Configuration Command" Resource Parameters

Resource Identifier	Type	Description
(domain-index)	Format: - Maintenance Domain (MD) index - range: [1...4294967295]	Maintenance Domain (MD) index
(association-index)	Format: - Maintenance Association (MA) index. Unique within an MD - range: [1...4294967295]	Maintenance Association (MA) index. Unique within an MD
(mepid)	Format: - MA End Point (MEP) ID. Unique within an MA - range: [1...8191]	MA End Point (MEP) ID. Unique within an MA

Table 47.4-2 "Maintenance Association End Point Configuration Command" Command Parameters

Parameter	Type	Description
location	Parameter type: <Cfm::location> Format: (user : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::VpiId> : <Eqpt::VciId> user : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> slot : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> user : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> / <Eqpt::OntPortId> user : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / voip user : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / vuni ng2 : <Ng2::ChannelGroup> / <Ng2::SubchannelGroup> / <Ng2::OntId> / <Eqpt::Ng2OntSlotId> / <Eqpt::Ng2OntPortId> ng2 : <Ng2::ChannelGroup> / <Ng2::SubchannelGroup> / <Ng2::OntId> / vuni) Possible values: - user : User bridge-port location - slot : slot location - ng2 : ngpon2 style identification Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number Field type <Eqpt::VpiId> - atm VPI Field type <Eqpt::VciId> - atm VCI Field type <Eqpt::PonId> - the PON identifier Field type <Eqpt::OntId> - the ONT identifier Field type <Ng2::ChannelGroup> - channel group number Field type <Ng2::SubchannelGroup> - subchannel group number Field type <Ng2::OntId> - the ONT identifier Possible values: - voip : virtual uni identifier obsolete alternative replaced by vuni - vuni : virtual uni identifier Possible values: - vuni : virtual NGPON2 uni identifier Field type <Eqpt::OntSlotId> - the ONT SLOT identifier Field type <Eqpt::OntPortId> - the ONT PORT identifier Field type <Eqpt::Ng2OntSlotId> - the NGPON2 ONT SLOT identifier	mandatory parameter The parameter is not visible during modification. Maintenance association End Point (MEP) location

Parameter	Type	Description
	Field type <Eqpt::Ng2OntPortId> - the NGPON2 ONT PORT identifier	
[no] cci-enable	Parameter type: boolean	<i>optional parameter</i> Enable CCM generation on the current MEP
[no] ccm-priority	Parameter type: <Cfm::MepCcmPriority> Format: - Priority value for CCMs transmitted by the MEP - range: [0...7]	<i>optional parameter with default value: 7UL</i> Priority value for CCMs transmitted by the MEP
[no] equipment	Parameter type: <Cfm::MepEquipmentType> Format: (default olt onu) Possible values: - default : Gpon Onu or Dsl - olt : Gpon LT - onu : Gpon Onu	<i>optional parameter with default value: "default"</i> <i>The parameter is not visible during modification.</i> Identifies the equipment type of mep ,only supported on Gpon Lt
[no] low-pri-defect	Parameter type: <Cfm::MepLowPriorityDefect> Format: (all-def mac-rem-err-xcon rem-err-xcon err-xcon xcon no-xcon) Possible values: - all-def : For DefRDICCM, DefMACstatus, DefRemoteCCM,DefErrorCCM, and DefXconCCM - mac-rem-err-xcon : Only DefMACstatus, DefRemoteCCM,DefErrorCCM, and DefXconCCM (default) - rem-err-xcon : Only DefRemoteCCM, DefErrorCCM, and DefXconCCM - err-xcon : Only DefErrorCCM and DefXconCCM - xcon : Only DefXconCCM - no-xcon : No defects DefXcon or lower are to be reported	<i>optional parameter with default value: "mac-rem-err-xcon"</i> The lowest priority defect that is allowed to generate fault alarm
[no] fng-alarm-time	Parameter type: <Cfm::MepFngAlarmTime> Format: - multiples of 250 ticks are supported(250,500,750,1000).default = 250 ticks(2.5sec) - unit: 1/100 sec - range: [250...1000]	<i>optional parameter with default value: 250L</i> The time in ticks(1 tick = 10ms) that defects must be present before a Fault alarm is issued.
[no] fng-reset-time	Parameter type: <Cfm::MepFngResetTime> Format: - multiples of 250 ticks are supported(250,500,750,1000).default = 1000 ticks(10sec) - unit: 1/100 sec - range: [250...1000]	<i>optional parameter with default value: 1000L</i> The time in ticks (1tick = 10ms) that defects must be absent before re-enabling a Fault Alarm.
[no] slm-resp-enable	Parameter type: boolean	<i>optional parameter</i> slm responder is enabled on the current mep
[no] dm-resp-enable	Parameter type: boolean	<i>optional parameter</i> dm responder is enabled on the current mep
[no] lm-resp	Parameter type: <Cfm::MepLmEnableDisable> Format:	<i>optional parameter with default value: "disable"</i>

47 CFM Configuration Commands

Parameter	Type	Description
	(disable enable-per-vlan enable-per-pbit) Possible values: - disable : lm responder is disabled on the current mep - enable-per-vlan : lm responder is enabled per vlan on the current mep - enable-per-pbit : lm responder is enabled per vlan per pbit on the current mep	configure LM responder on the current mep
[no] slm-init-enable	Parameter type: boolean	<i>optional parameter</i> slm initiator is enabled on the current mep
[no] lm-init	Parameter type: <Cfm::MepLmInitEnableDisable> Format: (disable enable-per-vlan enable-per-pbit) Possible values: - disable : lm initiator is disabled on the current mep - enable-per-vlan : lm initiator is enabled per vlan on the current mep - enable-per-pbit : lm initiator is enabled per vlan per pbit on the current mep	<i>optional parameter with default value: "disable"</i> configure lm initiator on the current mep

47.5 MEP located on ONU UNI enabled ITU-T Y.1731 Ethernet Alarm Indication Signal(ETH-AIS) function Configuration Commands

Command Description

This command allows the operator to enable or disable the ETH-AIS(ITU-T Y.1731) function for the MEP located on ONT UNI.

User Level

The command can be accessed by operators with alarm privileges, and executed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> configure cfm domain (domain-index) association (association-index) mep (mepid) y1731ais [ [ no ] ais-enable ]
[ no meg-level | meg-level <Cfm::MepAisMegLevel> ] [ no period | period <Cfm::MepAisPeriod> ] [ no priority |
priority <Cfm::MepAisPriority> ] [ [ no ] portshut-enable ]
```

Command Parameters

Table 47.5-1 "MEP located on ONU UNI enabled ITU-T Y.1731 Ethernet Alarm Indication Signal(ETH-AIS) function Configuration Commands" Resource Parameters

Resource Identifier	Type	Description
(domain-index)	Format: - Maintenance Domain (MD) index - range: [1...4294967295]	Maintenance Domain (MD) index
(association-index)	Format: - Maintenance Association (MA) index. Unique within an MD - range: [1...4294967295]	Maintenance Association (MA) index. Unique within an MD
(mepid)	Format: - MA End Point (MEP) ID. Unique within an MA - range: [1...8191]	MA End Point (MEP) ID. Unique within an MA

Table 47.5-2 "MEP located on ONU UNI enabled ITU-T Y.1731 Ethernet Alarm Indication Signal(ETH-AIS) function Configuration Commands" Command Parameters

Parameter	Type	Description
[no] ais-enable	Parameter type: boolean	<i>optional parameter</i> AIS generation is enabled on the current MEP
[no] meg-level	Parameter type: <Cfm::MepAisMegLevel>	<i>optional parameter with default</i>

47 CFM Configuration Commands

Parameter	Type	Description
	Format: - Meg Level for AIS frames transmitted by the MEP - range: [0...7]	<i>value: 0L</i> MEG level at which the most immediate client layer MIPs and MEPs exist
[no] period	Parameter type: <Cfm::MepAisPeriod> Format: - Period of the AIS frames transmitted by the MEP, 0 (per second), 1 (per minute) - range: [0...1]	<i>optional parameter with default value: 0L</i> Determines transmission periodicity of frames with AIS information
[no] priority	Parameter type: <Cfm::MepAisPriority> Format: - Priority value for AIS frames transmitted by the MEP - range: [0...7]	<i>optional parameter with default value: 7L</i> Identifies the priority of frames with ETH-AIS information
[no] portshut-enable	Parameter type: boolean	<i>optional parameter</i> shutdown enabled on the current MEP

47.6 Active Remote Maintenance Association End Point Configuration Command

Command Description

This command is used to configure a Active Remote Maintenance association End Point (RMEP) within a Maintenance End Point (MEP). Once an active RMEP is created, it cannot be modified. To modify the Active RMEP, delete the entry and create a new one.

User Level

The command can be accessed by operators with alarm , oam , vlan privileges, and executed by operators with alarm , oam , vlan privileges.

Command Syntax

The command has the following syntax:

```
> configure cfm domain (domain-index) association (association-index) mep (mepid) ( no active-remote-mep (active-remote-mepid) ) | ( active-remote-mep (active-remote-mepid) )
```

Command Parameters

Table 47.6-1 "Active Remote Maintenance Association End Point Configuration Command" Resource Parameters

Resource Identifier	Type	Description
(domain-index)	Format: - Maintenance Domain (MD) index - range: [1...4294967295]	Maintenance Domain (MD) index
(association-index)	Format: - Maintenance Association (MA) index. Unique within an MD - range: [1...4294967295]	Maintenance Association (MA) index. Unique within an MD
(mepid)	Format: - MA End Point (MEP) ID. Unique within an MA - range: [1...8191]	MA End Point (MEP) ID. Unique within an MA
(active-remote-mepid)	Format: - MA End Point (MEP) ID. Unique within an MA - range: [1...8191]	Active Remote MepID.

47.7 Remote Maintenance Association End Point Configuration Command

Command Description

This command is used to configure a Remote Maintenance association End Point (RMEP) within a Maintenance Association (MA). Remote MEP is useful only in case CCM is activated on an MA. Once a RMEP is created, it cannot be modified. To modify the RMEP, delete the entry and create a new one.

User Level

The command can be accessed by operators with alarm , oam , vlan privileges, and executed by operators with alarm , oam , vlan privileges.

Command Syntax

The command has the following syntax:

```
> configure cfm domain (domain-index) association (association-index) ( no remote-mep (rmepid) ) | ( remote-mep (rmepid) )
```

Command Parameters

Table 47.7-1 "Remote Maintenance Association End Point Configuration Command" Resource Parameters

Resource Identifier	Type	Description
(domain-index)	Format: - Maintenance Domain (MD) index - range: [1...4294967295]	Maintenance Domain (MD) index
(association-index)	Format: - Maintenance Association (MA) index. Unique within an MD - range: [1...4294967295]	Maintenance Association (MA) index. Unique within an MD
(rmepid)	Format: - MA End Point (MEP) ID. Unique within an MA - range: [1...8191]	Remote MA End Point (MEP) ID. Unique within an MA

47.8 Synthetic Loss Measurement configuration Commands

Command Description

This command can be used to configure the parameters for synthetic loss measurement

User Level

The command can be accessed by operators with alarm , oam , vlan privileges, and executed by operators with alarm , oam , vlan privileges.

Command Syntax

The command has the following syntax:

```
> configure cfm slm [ no inactivity-time | inactivity-time <Cfm::slmInactivityTime> ]
```

Command Parameters

Table 47.8-2 "Synthetic Loss Measurement configuration Commands" Command Parameters

Parameter	Type	Description
[no] inactivity-time	Parameter type: <Cfm::slmInactivityTime> Format: - inactivity time - unit: seconds - range: [10...100]	<i>optional parameter with default value: 100L</i> value of slm inactivity timer

47.9 CFM PM-Proactive test management

Command

Command Description

This command is used to configure PM-Proactive tests.

User Level

The command can be accessed by operators with alarm , oam , vlan privileges, and executed by operators with alarm , oam , vlan privileges.

Command Syntax

The command has the following syntax:

```
> configure cfm y1731pm
```


47.10 CFM PM Proactive test management Command

Command Description

This command is used to configure PM Proactive tests.

User Level

The command can be accessed by operators with alarm , oam , vlan privileges, and executed by operators with alarm , oam , vlan privileges.

Command Syntax

The command has the following syntax:

```
> configure cfm y1731pm ( no domain (domain-index) association <Cfm::CfmMaIndexType> mep
<Cfm::MepIdType> session-id <Cfm::SessionIdType> ) | ( domain (domain-index) association
<Cfm::CfmMaIndexType> mep <Cfm::MepIdType> session-id <Cfm::SessionIdType> type <Cfm::PmTestType>
target-mac <Vlan::MacAddr> [ no priority | priority <Vlan::Priority> ] [ [ no ] admin-up ] [ interval
<Cfm::PmIntervalType> ] [ size <Cfm::PmDataSizeType> ] [ measurement-intvl
<Cfm::PmMeasurementIntervalType> ] )
```

Command Parameters

Table 47.10-1 "CFM PM Proactive test management Command" Resource Parameters

Resource Identifier	Type	Description
(domain-index)	Format: - Maintenance Domain (MD) index - range: [1...4294967295]	Maintenance Domain Index.
association	Parameter type: <Cfm::CfmMaIndexType> Format: - Maintenance Association (MA) index. Unique within an MD - range: [1...4294967295]	Maintenance Association Index.
mep	Parameter type: <Cfm::MepIdType> Format: - MA End Point (MEP) ID. Unique within an MA - range: [1...8191]	Maintenance Association End Point (MEP) ID. Unique within an MA.
session-id	Parameter type: <Cfm::SessionIdType> Format: - Session Id for PM proactive - range: [1...3600]	PM Proactive test SessionId.

Table 47.10-2 "CFM PM Proactive test management Command" Command Parameters

Parameter	Type	Description
type	Parameter type: <Cfm::PmTestType>	<i>mandatory parameter</i>

47 CFM Configuration Commands

Parameter	Type	Description
	Format: (single-ended-slm single-ended-lm) Possible values: - single-ended-slm : sets test type to SLM - single-ended-lm : sets test type to LM	<i>The parameter is not visible during modification.</i> Y1731 PM Test type
target-mac	Parameter type: <Vlan::MacAddr> Format: - mac address (aa:bb:cc:a1:02:03) - unit: Byte - length: 6	<i>mandatory parameter</i> <i>The parameter is not visible during modification.</i> MAC address of the PM responder(Target).
[no] priority	Parameter type: <Vlan::Priority> Format: - priority of ethernet frames - range: [0...7]	<i>optional parameter with default value: 7L</i> Priority. A 3 bit value to be used in the VLAN tag.
[no] admin-up	Parameter type: boolean	<i>optional parameter</i> Start the PM test
interval	Parameter type: <Cfm::PmIntervalType> Format: - PM interval (sec) SLM: [1...10] LM: [60 or 300] - range: [1...10,60,300]	<i>optional parameter</i> Interval in which PM packets are transmitted.1sec - 10sec for SLM, 60sec or 300sec for LM
size	Parameter type: <Cfm::PmDataSizeType> Format: (not-applicable <Cfm::PmDataSize>) Possible values: - not-applicable : For single-ended-lm, the value of this object is not-applicable Field type <Cfm::PmDataSize> - Datasize for the SLM proactive test - range: [0...1500]	<i>optional parameter</i> Size of data TLV
measurement-intvl	Parameter type: <Cfm::PmMeasurementIntervalType> Format: (not-applicable <Cfm::PmMeasurementInterval>) Possible values: - not-applicable : For single-ended-lm, the value of this object is not-applicable Field type <Cfm::PmMeasurementInterval> - Measurement interval - unit: seconds - range: [60,300]	<i>optional parameter</i> The time for which the synthetic loss calculation is made periodically.

48- *Trouble-Shooting Configuration Commands*

48.1 Trouble-Shooting Configuration Command Tree	48-1562
48.2 Trouble-shooting Interface Configuration Commands	48-1563

48.1 Trouble-Shooting Configuration Command Tree

Description

This chapter gives an overview of nodes that are handled by "Trouble-Shooting Configuration Commands".

Command Tree

```
----configure
  ----trouble-shooting
    ----statistics
      ----[no] interface
        - (if-index)
```

48.2 Trouble-shooting Interface Configuration Commands

Command Description

This command allows the operator to enable or disable the extensive trouble-shooting counters.

User Level

The command can be accessed by operators with security privileges, and executed by operators with security privileges.

Command Syntax

The command has the following syntax:

```
> configure trouble-shooting statistics ( no interface (if-index) ) | ( interface (if-index) )
```

Command Parameters

Table 48.2-1 "Trouble-shooting Interface Configuration Commands" Resource Parameters

Resource Identifier	Type	Description
(if-index)	Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> / <Eqpt::OntPortId> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / voip <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / vuni uni:ng2 : <Ng2::ChannelGroup> / <Ng2::SubchannelGroup> / <Ng2::OntId> / <Eqpt::Ng2OntSlotId> / <Eqpt::Ng2OntPortId> chpair : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::ChannelPairId> vlanport : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlanport : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> / <Eqpt::OntPortId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlanport : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> / <Eqpt::OntPortId> :	interface index of the port

Resource Identifier	Type	Description
	<pre> <Eqpt::UnstackedVlan> vlanport : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / voip : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlanport : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / vuni : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlanport : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / voip : <Eqpt::UnstackedVlan> vlanport : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / vuni : <Eqpt::UnstackedVlan> vlanport : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::LLId> : <Eqpt::UnstackedVlan> vlanport : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::LLId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlanport : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::UnstackedVlan> vlanport : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::VpiId> : <Eqpt::VciId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlanport : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::VpiId> : <Eqpt::VciId> : <Eqpt::UnstackedVlan>) Possible values: - uni:ng2 : ng2 uni index - chpair : channel pair index - vlanport : vlan port Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number Field type <Eqpt::VpiId> - atm VPI Field type <Eqpt::VciId> - atm VCI Field type <Eqpt::PonId> - the PON identifier Field type <Eqpt::OntId> - the ONT identifier Possible values: - voip : virtual uni identifier obsolete alternative replaced by vuni - vuni : virtual uni identifier Field type <Eqpt::OntSlotId> - the ONT SLOT identifier Field type <Eqpt::OntPortId> - the ONT PORT identifier Field type <Eqpt::LLId> - the LLID identifier,range 1 for EPON,range 1-8 for DPOE </pre>	

Resource Identifier	Type	Description
	Field type <Eqpt::ChannelPairId> - the channel pair identifier Field type <Ng2::ChannelGroup> - channel group number Field type <Ng2::SubchannelGroup> - subchannel group number Field type <Ng2::OntId> - the ONT identifier Possible values: - stacked : stacked vlan identity Field type <Eqpt::UnstackedVlan> - unstacked vlan id Field type <Eqpt::SVlan> - service vlan id Field type <Eqpt::CVlan> - customer vlan id Possible values: - vuni : virtual NGPON2 uni identifier Field type <Eqpt::Ng2OntSlotId> - the NGPON2 ONT SLOT identifier Field type <Eqpt::Ng2OntPortId> - the NGPON2 ONT PORT identifier	

49- *Trouble-Shooting Pbit Counter Configuration*

Command

49.1 Trouble-Shooting Pbit Counter Configuration Command Tree	49-1567
49.2 Trouble-shooting pbit counter Interface Configuration Commands	49-1568

49.1 Trouble-Shooting Pbit Counter Configuration Command Tree

Description

This chapter gives an overview of nodes that are handled by "Trouble-Shooting Pbit Counter Configuration Command".

Command Tree

```
----configure
  ----trouble-shooting
    ----pbit
      ----statistics
        ----[no] interface
          - (if-index)
```

49.2 Trouble-shooting pbit counter Interface Configuration Commands

Command Description

This command allows the operator to enable or disable trouble-shooting pbit counters.

User Level

The command can be accessed by operators with security privileges, and executed by operators with security privileges.

Command Syntax

The command has the following syntax:

> configure trouble-shooting pbit statistics (no interface (if-index)) | (interface (if-index))

Command Parameters

Table 49.2-1 "Trouble-shooting pbit counter Interface Configuration Commands" Resource Parameters

Resource Identifier	Type	Description
(if-index)	Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> / <Eqpt::OntPortId> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / voip <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / vuni vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> / <Eqpt::OntPortId> : <Eqpt::UnstackedVlan> vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> / <Eqpt::OntPortId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / voip : <Eqpt::UnstackedVlan> vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / vuni : <Eqpt::UnstackedVlan> vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> /	interface index of the Bridge port or vlan port

Resource Identifier	Type	Description
	<pre> <Eqpt::PonId> / <Eqpt::OntId> / voip : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / vuni : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::VpId> : <Eqpt::VciId> : <Eqpt::UnstackedVlan> vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::VpId> : <Eqpt::VciId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> uni:ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / <Eqpt::Ng2OntSlotId> / <Eqpt::Ng2OntPortId> vlan:ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / <Eqpt::Ng2OntSlotId> / <Eqpt::Ng2OntPortId> : <Eqpt::UnstackedVlan> vlan:ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / <Eqpt::Ng2OntSlotId> / <Eqpt::Ng2OntPortId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> uni:ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / vuni) Possible values: - vlan : vlan - uni:ng2 : ngpon2 UNI style identification - vlan:ng2 : ngpon2 vlan Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number Field type <Eqpt::VpId> - atm VPI Field type <Eqpt::VciId> - atm VCI Field type <Eqpt::PonId> - the PON identifier Field type <Eqpt::ChannelGroupId> - the channel group identifier Field type <Eqpt::SubChannelGroupId> - the subchannel group identifier Field type <Eqpt::OntId> - the ONT identifier Field type <Eqpt::Ng2OntId> - the NG2 ONT identifier Possible values: - voip : virtual uni identifier obsolete alternative replaced by vuni - vuni : virtual uni identifier Possible values: - vuni : virtual NGPON2 uni identifier Field type <Eqpt::OntSlotId> </pre>	

49 Trouble-Shooting Pbit Counter Configuration Command

Resource Identifier	Type	Description
	- the ONT SLOT identifier Field type <Eqpt::OntPortId> - the ONT PORT identifier Field type <Eqpt::Ng2OntSlotId> - the NGPON2 ONT SLOT identifier Field type <Eqpt::Ng2OntPortId> - the NGPON2 ONT PORT identifier Possible values: - stacked : stacked vlan identity Field type <Eqpt::UnstackedVlan> - unstacked vlan id Field type <Eqpt::SVlan> - service vlan id Field type <Eqpt::CVlan> - customer vlan id	

50- Trouble-Shooting Pon Interface Configuration Command

50.1 Trouble-Shooting Pon Interface Configuration Command Tree	50-1572
50.2 Trouble-shooting Pon Interface Configuration Commands	50-1573
50.3 Trouble-Shooting threshold Configuration Commands	50-1574
50.4 Trouble shooting Configuration Command	50-1575

50.1 Trouble-Shooting Pon Interface Configuration Command Tree

Description

This chapter gives an overview of nodes that are handled by "Trouble-Shooting Pon Interface Configuration Command".

Command Tree

```
----configure
  ----trouble-shooting
    ----pon
      ----statistics
        ----[no] interface
          - (if-index)
        ----threshold
          - [no] interval
        ----interface
          - (if-index)
          - [no] bw-th-up
          - [no] bw-th-dn
```

50.2 Trouble-shooting Pon Interface Configuration Commands

Command Description

This command allows the operator to enable or disable the extensive trouble-shooting counters over a Pon Line.

User Level

The command can be accessed by operators with security privileges, and executed by operators with security privileges.

Command Syntax

The command has the following syntax:

```
> configure trouble-shooting pon statistics ( no interface (if-index) ) | ( interface (if-index) )
```

Command Parameters

Table 50.2-1 "Trouble-shooting Pon Interface Configuration Commands" Resource Parameters

Resource Identifier	Type	Description
(if-index)	Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> x-pon : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::XPonId> 25g-pon : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::M25GPonId>) Possible values: - 25g-pon : 25g-pon - x-pon : xgs-pon Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Eqpt::XPonId> - the XGS PON identifier Field type <Eqpt::M25GPonId> - the 25G PON identifier	interface index of the pon port

50.3 Trouble-Shooting threshold Configuration Commands

Command Description

This command is to configure the ethernet traffic tca detect interval

User Level

The command can be accessed by operators with security privileges, and executed by operators with security privileges.

Command Syntax

The command has the following syntax:

> configure trouble-shooting pon statistics threshold [no interval | interval <Gpon::TcaDetectIntval>]

Command Parameters

Table 50.3-2 "Trouble-Shooting threshold Configuration Commands" Command Parameters

Parameter	Type	Description
[no] interval	Parameter type: <Gpon::TcaDetectIntval> Format: - ethernet traffic tca detect interval for pon in second - range: [60...86400]	<i>optional parameter with default value: "300"</i> ethernet traffic tca detect interval for pon in second

50.4 Trouble shooting Configuration Command

Command Description

This command is to configure the pon threshold of bytes up or down.

User Level

The command can be accessed by operators with equipment privileges, and executed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

```
> configure trouble-shooting pon statistics threshold interface (if-index) [ no bw-th-up | bw-th-up
<Gpon::TrbstBwThUp> ] [ no bw-th-dn | bw-th-dn <Gpon::TrbstBwThDn> ]
```

Command Parameters

Table 50.4-1 "Trouble shooting Configuration Command" Resource Parameters

Resource Identifier	Type	Description
(if-index)	Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> x-pon : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::XPonId> 25g-pon : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::M25GPonId>) Possible values: - 25g-pon : 25g-pon - x-pon : xgs-pon Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Eqpt::XPonId> - the XGS PON identifier Field type <Eqpt::M25GPonId> - the 25G PON identifier	interface index of the pon port

Table 50.4-2 "Trouble shooting Configuration Command" Command Parameters

Parameter	Type	Description
[no] bw-th-up	Parameter type: <Gpon::TrbstBwThUp> Format:	optional parameter with default value: "0"

50 Trouble-Shooting Pon Interface Configuration Command

Parameter	Type	Description
	- the attribute is used to specify the average rate threshold in kbps for upstream traffic,0 is disable - range: [0...4294967295]	the attribute is used to specify the average rate threshold in kbps for upstream traffic,0 is disable
[no] bw-th-dn	Parameter type: <Gpon::TrbstBwThDn> Format: - the attribute is used to specify the average rate threshold in kbps for downstream traffic,0 is disable - range: [0...4294967295]	<i>optional parameter with default value: "0"</i> the attribute is used to specify the average rate threshold in kbps for downstream traffic,0 is disable

51- Trouble-Shooting Color Counter Configuration Command

51.1 Trouble-Shooting Color Counter Configuration Command Tree	51-1578
51.2 Trouble-shooting color counter Interface Configuration Commands	51-1579

51.1 Trouble-Shooting Color Counter Configuration Command Tree

Description

This chapter gives an overview of nodes that are handled by "Trouble-Shooting Color Counter Configuration Command".

Command Tree

```
----configure
  ----trouble-shooting
    ----color
      ----statistics
        ----[no] interface
          - (if-index)
```

51.2 Trouble-shooting color counter Interface Configuration Commands

Command Description

This command allows the operator to enable or disable trouble-shooting color counters.

User Level

The command can be accessed by operators with security privileges, and executed by operators with security privileges.

Command Syntax

The command has the following syntax:

```
> configure trouble-shooting color statistics ( no interface (if-index) ) | ( interface (if-index) )
```

Command Parameters

Table 51.2-1 "Trouble-shooting color counter Interface Configuration Commands" Resource Parameters

Resource Identifier	Type	Description
(if-index)	Format: (vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::VpiId> : <Eqpt::VciId> : <Eqpt::UnstackedVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::UnstackedVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::VpiId> : <Eqpt::VciId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> / <Eqpt::OntPortId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> / <Eqpt::OntPortId> : <Eqpt::UnstackedVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / voip : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> /	interface index of the vlan port

51 Trouble-Shooting Color Counter Configuration Command

Resource Identifier	Type	Description
	<pre> <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / vuni : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / voip : <Eqpt::UnstackedVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / vuni : <Eqpt::UnstackedVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::LLId> : <Eqpt::UnstackedVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::LLId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan>) Possible values: - vlan-port : vlan port Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number Field type <Eqpt::Vpild> - atm VPI Field type <Eqpt::VciId> - atm VCI Field type <Eqpt::PonId> - the PON identifier Field type <Eqpt::OntId> - the ONT identifier Possible values: - voip : virtual uni identifier obsolete alternative replaced by vuni - vuni : virtual uni identifier Field type <Eqpt::OntSlotId> - the ONT SLOT identifier Field type <Eqpt::OntPortId> - the ONT PORT identifier Field type <Eqpt::LLId> - the LLID identifier,range 1 for EPON,range 1-8 for DPOE Possible values: - stacked : stacked vlan identity Field type <Eqpt::UnstackedVlan> - unstacked vlan id Field type <Eqpt::SVlan> - service vlan id Field type <Eqpt::CVlan> - customer vlan id </pre>	

52- IPoA/E IW Configuration Commands

52.1 IPoA/E IW Configuration Command Tree	52-1582
52.2 IPoA/E IW Interworking Port Configuration Command	52-1583
52.3 IPoA/E IW Gateway Configuration Command	52-1585

52.1 IPoA/E IW Configuration Command Tree

Description

This chapter gives an overview of nodes that are handled by "IPoA/E IW Configuration Commands".

Command Tree

```
----configure
  ----ipoa/e-iw
    ----[no] port
      - (interworking-port)
      - user-ip
      - gw-ip
    ----[no] gateway
      - (vlanid)
      - gw-ip-addr
```


52.2 IPoA/E IW Interworking Port Configuration Command

Command Description

This command allows the operator to configure the parameter on the IPOA L2 interworking port level

User Level

The command can be accessed by operators with ip privileges, and executed by operators with ip privileges.

Command Syntax

The command has the following syntax:

```
> configure ipoa/e-iw ( no port (interworking-port) ) | ( port (interworking-port) [ user-ip <Ip::V4AddressHex> ] [ gw-ip <Ip::V4AddressHex> ] )
```

Command Parameters

Table 52.2-1 "IPoA/E IW Interworking Port Configuration Command" Resource Parameters

Resource Identifier	Type	Description
(interworking-port)	Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::VpId> : <Eqpt::VcId> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId>) Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number Field type <Eqpt::VpId> - atm VPI Field type <Eqpt::VcId> - atm VCI	index of rack/shelf/slot/port user-bridgeport

Table 52.2-2 "IPoA/E IW Interworking Port Configuration Command" Command Parameters

Parameter	Type	Description
user-ip	Parameter type: <Ip::V4AddressHex> Format: - IPv4-address	<i>optional parameter</i> ip address for user
gw-ip	Parameter type: <Ip::V4AddressHex> Format:	<i>optional parameter</i> ip address for next-hop gateway

52 IPoA/E IW Configuration Commands

Parameter	Type	Description
	- IPv4-address	

52.3 IPoA/E IW Gateway Configuration Command

Command Description

This command allows the operator to configure gateway address per L2 forwarder vlan

User Level

The command can be accessed by operators with ip privileges, and executed by operators with ip privileges.

Command Syntax

The command has the following syntax:

```
> configure ipoa/e-iw ( no gateway (vlanid) ) | ( gateway (vlanid) gw-ip-addr <Ip::V4AddressHex> )
```

Command Parameters

Table 52.3-1 "IPoA/E IW Gateway Configuration Command" Resource Parameters

Resource Identifier	Type	Description
(vlanid)	Format: (<Network::UVlanIndex> stacked : <Network::SVlanIndex> : <Network::CVlanIndex>) Possible values: - stacked : stacked vlan identity Field type <Network::UVlanIndex> - unstacked vlan identity - range: [1...4093] Field type <Network::SVlanIndex> - service vlan identity - range: [2...4093] Field type <Network::CVlanIndex> - customer vlan identity - range: [0...4093]	vlan id

Table 52.3-2 "IPoA/E IW Gateway Configuration Command" Command Parameters

Parameter	Type	Description
gw-ip-addr	Parameter type: <Ip::V4AddressHex> Format: - IPv4-address	<i>mandatory parameter</i> the gateway ip address

53- LineTest Configuration Commands

53.1 LineTest Configuration Command Tree	53-1587
53.2 Megaco LineTest Session Configuration Command	53-1589
53.3 Megaco LineTest Line Configuration Command	53-1593
53.4 MEGACO LineTest Param Configuration Command	53-1595
53.5 SINGLE LineTest Session Configuration Command	53-1600
53.6 SINGLE LineTest Line Configuration Command	53-1606
53.7 SINGLE LineTest Param Configuration Command	53-1608

53.1 LineTest Configuration Command Tree

Description

This chapter gives an overview of nodes that are handled by "LineTest Configuration Commands".

Command Tree

```

----configure
  ----linetest
    ----cluster
      - (cluster-id)
      ----ltsession
        - (sessionid)
        - session-cmd
        - ownerid
        - timeout-period
        - line-num
        - type-high
        - type-low
        - test-parm-num
        - test-mode
        - type-extend
      ----ltline
        - (sessionid)
        - lineid
        - line-status
      ----ltparm
        - (sessionid)
        - test-name(unit)
        - value1
        - value2
        - value3
        - value4
        - value5
        - min-threshold
        - max-threshold
        - min-threshold2
        - max-threshold2
        - ltstrvalue1
    ----single
      ----ltsession
        - (sessionid)
        - session-cmd
        - ownerid
        - timeout-period
        - line-num
        - type-high
        - type-low
        - test-parm-num
        - test-mode
        - inactive-timer
        - type-extend

```

- [no] group-opt
- [no] busy-overwrite
- [no] force-measure

----ltline

- (sessionid)
- lineid
- line-status

----ltparm

- (sessionid)
- test-name(unit)
- value1
- value2
- value3
- value4
- value5
- min-threshold
- max-threshold
- min-threshold2
- max-threshold2
- ltstrvalue1

53.2 Megaco LineTest Session Configuration Command

Command Description

This command allows the operator to configure the MEGACO LineTest session parameters.

User Level

The command can be accessed by operators with megaco privileges, and executed by operators with megaco privileges.

Command Syntax

The command has the following syntax:

```
> configure linetest cluster (cluster-id) ltsession (sessionid) [ session-cmd <LineTest::SessCmdForConfig> ] [
ownerid <Gauge> ] [ timeout-period <LineTest::TimeOutPerVoice> ] [ line-num <LineTest::LineNum> ] [
type-high <LineTest::ltTypeHigh> ] [ type-low <LineTest::ltTypeLow> ] [ test-parm-num
<LineTest::TestParmNum> ] [ test-mode <LineTest::TestModeForConfig> ] [ type-extend
<LineTest::ltTypeExtend> ]
```

Command Parameters

Table 53.2-1 "Megaco LineTest Session Configuration Command" Resource Parameters

Resource Identifier	Type	Description
(cluster-id)	Format: - the xvps cluster id - range: [1...8,11]	uniquely identify of this xvps cluster
(sessionid)	Format: - available session id - range: [1]	uniquely identify of session

Table 53.2-2 "Megaco LineTest Session Configuration Command" Command Parameters

Parameter	Type	Description
session-cmd	Parameter type: <LineTest::SessCmdForConfig> Format: (create starttest sendinfo startinfo destroy recv-subtest start-subtest repeat endtest) Possible values:	<i>optional parameter</i> the linetest session command

53 LineTest Configuration Commands

Parameter	Type	Description
	- create : create a test session - starttest : transfer data done, start a test - sendinfo : start to transfer info data for an underway test - startinfo : transfer info data done, start info operation - destroy : destroy a test session - recv-subtest : start to transfer the sub-test's data - start-subtest : transfer sub-test's data done, start the sub-test - repeat : repeat the last test - endtest : end current test session	
ownerid	Parameter type: <Gauge> Format: - gauge	<i>optional parameter</i> ownerid of the session
timeout-period	Parameter type: <LineTest::TimeOutPerVoice> Format: - allows to set the whole test timer including all test \r\nitems of all lines for the session. Should be larger \r\nthan or equal to the sum of all lines' limited time plus\r\nline test management time <2s>. Each line's limited time\r\nis the sum of all the test items' limited time in this \r\nline. There are two exceptions: a) cable-pair-ident,\r\nwhich uses a fixed limitation 65~5400s;\r\nb) diagnosis-call, which uses a fixed limitation 42~120s.\r\n\r\nTest items' limited time(second):\r\n test type time \r\n- type-high\r\n group 20 \r\n feeded-ac-vol 3 \r\n foreign-ac-vol 10 \r\n feeded-dc-vol 3 \r\n foreign-dc-vol 15 \r\n feeding-current 3 \r\n resistance 6 \r\n capacitance 15 \r\n impedance 5 \r\n low-capacit-phone 20 \r\n force-ring-subscrib 120 \r\n dialton-delay 8 \r\n msocket-detection 6 \r\n- type-low\r\n ac-current 66 \r\n dc-current 66 \r\n noise-level 66 \r\n howler 120 \r\n status-monitored 3 \r\n talking-father 3 \r\n line-reverse-sub 60 \r\n p-meter-pulse-sub 6 \r\n ring-subscrib-sub 60 \r\n dpdtmf-signal-sub 60 \r\n userloop-sub 6 \r\n isdn-loopback 20 \r\n diagnosis-caller N/A \r\n diagnosis-callee N/A \r\n- type-extend\r\n gr909-ringer 20 \r\n gr909-dialtone-d 8 \r\n gr909-roh 20 \r\n gr909-hazardous-p 20 \r\n gr909-femf 20 \r\n gr909-resistive-f 20 - unit: second - range: [2...4294967295]	<i>optional parameter</i> timeout period
line-num	Parameter type: <LineTest::LineNum> Format: - line number in the session of test - range: [1...72]	<i>optional parameter</i> line number in the session of test
type-high	Parameter type: <LineTest::ltTypeHigh> Format: (none group feeded-ac-vol foreign-ac-vol feeded-dc-vol foreign-dc-vol feeding-current resistance capacitance impedance	<i>optional parameter</i> indicate line test items

Parameter	Type	Description
	low-capacit-phone force-ring-subscrib dialton-delay msocket-detection) Possible values: - none : null - group : group test, see group-opt argument for the content of the group test - feeded-ac-vol : feeded ac rms voltage test, HBit31/30/29 - foreign-ac-vol : foreign ac rms voltage test, HBit26/27/28 - feeded-dc-vol : feeded dc voltage test, HBit18/23/24/25 - foreign-dc-vol : foreign dc voltage test, HBit20/21/22 - feeding-current : feeding current test, HBit19 - resistance : insulating resistance test, HBit12/13/14/15/16/17 (ISDN line test only support HBit14/15/16/17) - capacitance : capacitance test, HBit8/9/10/11 - impedance : impedance test, HBit4/5/6/7 - low-capacit-phone : low capacitance phone detect test, HBit3 - force-ring-subscrib : force ring subscriber test, HBit2 - dialton-delay : dial tone delay test of user circuit only in idle , HBit1 - msocket-detection : termination (m socket detection) test, HBit0	
type-low	Parameter type: <LineTest::ltTypeLow> Format: (none ac-current dc-current noise-level howler status-monitored cable-pair-ident talking-father line-reverse-sub p-meter-pulse-sub ring-subscrib-sub dpdtmf-signal-sub userloop-sub isdn-loopback diagnosis-caller diagnosis-callee) Possible values: - none : null - ac-current : ac current test normal test, LBit29/30/31 - dc-current : dc current test normal test, LBit28/27/26 - noise-level : noise level normal test, LBit24 - howler : howler test under normal test, LBit22 - status-monitored : status monitored test, LBit20 - cable-pair-ident : cable pair identification test, LBit19 - talking-father : talking test (father test item), LBit18 - line-reverse-sub : line reverse test, subtest of talking test, LBit17 - p-meter-pulse-sub : private meter pulses test, subtest of talking test, LBit16 - ring-subscrib-sub : ring subscriber with auto ring test,	<i>optional parameter</i> indicate line test items

53 LineTest Configuration Commands

Parameter	Type	Description
	subtest of talking test, LBit15 - dpdtmf-signal-sub : dp/dtmf signal test, subtest of talking test, LBit14 - userloop-sub : resistance of user loop (tip-ring), subtest of talking test, LBit13 - isdn-loopback : isdn loop back test, LBit10 - diagnosis-caller : H248 Voice Diagnosis Caller test, LBit8 - diagnosis-callee : H248 Voice Diagnosis Callee test, LBit7	
test-parm-num	Parameter type: <LineTest::TestParmNum> Format: - parameter lines number in the session of test - range: [0...6]	<i>optional parameter</i> parameter lines number in the session for test
test-mode	Parameter type: <LineTest::TestModeForConfig> Format: (single interactive cablepair) Possible values: - single : the test will be end after one time - interactive : the interactive test - cablepair : the cable pair test	<i>optional parameter</i> test mode
type-extend	Parameter type: <LineTest::LtTypeExtend> Format: (none gr909-ringers gr909-dialtone-d gr909-roh gr909-hazardous-p gr909-femf gr909-resistive-f diagnosis-call) Possible values: - none : null - gr909-ringers : ringers test, ExBit26 - gr909-dialtone-d : draw and break dial tone delay test, ExBit25 - gr909-roh : receiver off hook test, ExBit24 - gr909-hazardous-p : hazardous potential test, ExBit23, - gr909-femf : foreign electromotive force test, ExBit22 - gr909-resistive-f : resistive faults test, ExBit21 - diagnosis-call : diagnosis call test, ExBit14	<i>optional parameter</i> indicate line test items

53.3 Megaco LineTest Line Configuration Command

Command Description

This command allows the operator to configure the MEGACO LineTest line parameters.

User Level

The command can be accessed by operators with megaco privileges, and executed by operators with megaco privileges.

Command Syntax

The command has the following syntax:

```
> configure linetest cluster (cluster-id) ltline (sessionid) lineid <Itf::LineTestMegacoLineId> [ line-status <LineTest::LineStatusForConfig> ]
```

Command Parameters

Table 53.3-1 "Megaco LineTest Line Configuration Command" Resource Parameters

Resource Identifier	Type	Description
(cluster-id)	Format: - the xvps cluster id - range: [1...8,11]	uniquely identify of this xvps cluster
(sessionid)	Format: - available session id - range: [1]	uniquely identify of session
lineid	Parameter type: <Itf::LineTestMegacoLineId> Format: <Eqpt::NodeId> / <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::NewSlotId> / <Eqpt::MegacoPortId> Field type <Eqpt::NodeId> - the Node number Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::NewSlotId> - the LT slot number Field type <Eqpt::MegacoPortId> - the port number of Megaco	Identify of line

Table 53.3-2 "Megaco LineTest Line Configuration Command" Command Parameters

Parameter	Type	Description
line-status	Parameter type: <LineTest::LineStatusForConfig>	<i>optional parameter</i>

53 LineTest Configuration Commands

Parameter	Type	Description
	Format: (intest testover rstpartlyready) Possible values: - intest : put the line in test - testover : the line tested, and the result is ready for polling, it is read-only - rstpartlyready : defined for dp/dtmf test	status of line for test

53.4 MEGACO LineTest Param Configuration Command

Command Description

This command allows the operator to manage megaco linetest parameters.

User Level

The command can be accessed by operators with megaco privileges, and executed by operators with megaco privileges.

Command Syntax

The command has the following syntax:

```
> configure linetest cluster (cluster-id) ltparm (sessionid) test-name(unit) <LineTest::TestTypeMegaco> [ value1
<LineTest::ParaValue1Voice> ] [ value2 <LineTest::ParaValue2Voice> ] [ value3 <LineTest::ParaValue3Voice> ]
[ value4 <LineTest::ParaValue4Voice> ] [ value5 <LineTest::ParaValue5Voice> ] [ min-threshold
<LineTest::TestThreshold> ] [ max-threshold <LineTest::TestThreshold> ] [ min-threshold2
<LineTest::TestThreshold> ] [ max-threshold2 <LineTest::TestThreshold> ] [ ltstrvalue1
<LineTest::ParaStringValueString> ]
```

Command Parameters

Table 53.4-1 "MEGACO LineTest Param Configuration Command" Resource Parameters

Resource Identifier	Type	Description
(cluster-id)	Format: - the xvps cluster id - range: [1...8,11]	uniquely identify of this xvps cluster
(sessionid)	Format: - available session id - range: [1]	uniquely identify of session
test-name(unit)	Parameter type: <LineTest::TestTypeMegaco> Format: (feeded-ac-tr(mv) feeded-ac-tg(mv) feeded-ac-rg(mv) foreign-ac-tr(mv) foreign-ac-tg(mv) foreign-ac-rg(mv) feeded-dc-tr(mv) foreign-dc-tr(mv) foreign-dc-tg(mv) foreign-dc-rg(mv) feed-current(ua) feeded-dc-rt(mv)	test type

Resource Identifier	Type	Description
	resist-tr(ohm) resist-rt(ohm) resist-tg(ohm) resist-rg(ohm) resist-tbat(ohm) resist-rbat(ohm) capacitanc-tr(nf) capacitanc-rt(nf) capacitanc-tg(nf) capacitanc-rg(nf) impedance-tr(ohm) impedance-tg(ohm) impedance-rg(ohm) low-capacit-phone force-ring-subscrib dialton-delay(ms) msocket-detection ac-current-tr(ua) ac-current-tg(ua) ac-current-rg(ua) dc-current-tr(ua) dc-current-tg(ua) dc-current-rg(ua) noise-lv-0.001dbm howler-test-park status-monitored cable-pair-ident talking-father line-reverse-sub p-meter-pulse-sub ring-subscrib-sub dpdtmf-signal-sub userloop-sub(ohm) feeded-dc-tg(mv) feeded-dc-rg(mv) impedance-rt(ohm) isdn-loopback ringer-ren(mren) dialtone-delay-db(ms) gr909-roh gr909-hazardous-p gr909-femf gr909-resistive-f diagnosis-call(1/10s) Possible values: - feeded-ac-tr(mv) : feeded ac rms voltage of user line (tip-ring) - feeded-ac-tg(mv) : feeded ac rms voltage of user line (tip-ground) - feeded-ac-rg(mv) : feeded ac rms voltage of user line (ring-ground) - foreign-ac-tr(mv) : foreign ac rms voltage of user line (tip-ring) - foreign-ac-tg(mv) : foreign ac rms voltage of user line (tip-ground) - foreign-ac-rg(mv) : foreign ac rms voltage of user line (ring-ground)	

Resource Identifier	Type	Description
	- feeded-dc-tr(mv) : feeded dc voltage of user line (tip-ring) - foreign-dc-tr(mv) : foreign dc voltage of user line (tip-ring) - foreign-dc-tg(mv) : foreign dc voltage of user line (tip-ground) - foreign-dc-rg(mv) : foreign dc voltage of user line (ring-ground) - feed-current(ua) : feeding current (tip-ring) - feeded-dc-rt(mv) : feeded dc voltage of user line (ring-tip) - resist-tr(ohm) : insulating resistance of user line (tip-ring) - resist-rt(ohm) : insulating resistance of user line (ring-tip) - resist-tg(ohm) : insulating resistance of user line (tip-ground) - resist-rg(ohm) : insulating resistance of user line (ring-ground) - resist-tbat(ohm) : insulating battery resistance of user line (tip-bat) - resist-rbat(ohm) : insulating battery resistance of user line (ring-bat) - capacitanc-tr(nf) : capacitance of user line (tip-ring) - capacitanc-rt(nf) : capacitance of user line (ring-tip) - capacitanc-tg(nf) : capacitance of user line (tip-ground) - capacitanc-rg(nf) : capacitance of user line (ring-ground) - impedance-tr(ohm) : impedance of user circuit (tip-ring) - impedance-tg(ohm) : impedance of user circuit (tip-ground) - impedance-rg(ohm) : impedance of user circuit (ring-ground) - low-capacit-phone : low capacitance phone detect - force-ring-subscrib : force ring subscriber test - dialton-delay(ms) : dial tone delay of user circuit only in idle - msocket-detection : termination (m socket detection) - ac-current-tr(ua) : ac current test normal test (tip-ring) - ac-current-tg(ua) : ac current test normal test (tip-ground) - ac-current-rg(ua) : ac current test normal test (ring-ground) - dc-current-tr(ua) : dc current test normal test (tip-ring) - dc-current-tg(ua) : dc current test normal test (tip-ground) - dc-current-rg(ua) : dc current test normal test (ring-ground) - noise-lv-0.001dbm : noise level normal test - howler-test-park : howler test under normal test condition only in parking - status-monitored : status monitored test - cable-pair-ident : cable pair identification test - talking-father : talking test (father test item) - line-reverse-sub : line reverse test, subtest of talking test - p-meter-pulse-sub : private meter pulses test, subtest of talking test - ring-subscrib-sub : ring subscriber with auto ring test, subtest of talking test - dpdtmf-signal-sub : dp/dtmf signal test, subtest of talking test - userloop-sub(ohm) : resistance of user loop (tip-ring), subtest of talking test - feeded-dc-tg(mv) : feeded dc voltage of user line (tip-ground) - feeded-dc-rg(mv) : feeded dc voltage of user line (ring-ground)	

Resource Identifier	Type	Description
	- impedance-rt(ohm) : impedance of user circuit (ring-tip) - isdn-loopback : isdn loop back test - ringer-ren(mren) : gr909 ringer equivalency number testing - dialtone-delay-db(ms) : gr909 draw and break dial tone delay testing - gr909-roh : gr909 receiver off hook testing - gr909-hazardous-p : gr909 Hazardous Potential testing - gr909-femf : gr909 Foreign ElectroMotive Force testing - gr909-resistive-f : gr909 resistive faults testing - diagnosis-call(1/10s) : diagnosis call test	

Table 53.4-2 "MEGACO LineTest Param Configuration Command" Command Parameters

Parameter	Type	Description
value1	Parameter type: <LineTest::ParaValue1Voice> Format: - parameter value required for the execution of the \r\nspecified test type.\r\n<resistance tr/rt(ohm)>:\r\n Meaning: allows to configure whether it is required \r\n to test the 'signature' or not.\r\n Applicability : MELT only.\r\n Range: No(0) Yes(1)\r\n Default: No(0)\r\n <impedance tr/tg/rg(ohm)>:\r\n Meaning: allows to configure the frequency the test \r\n must run with.\r\n Range: 5~3000\r\n Default: 20 Unit: Hz\r\n <status-monitored>:\r\n Meaning: allows to configure whether to check real \r\n parking or short current state.\r\n Range: No(1) Yes(2)\r\n No default value.\r\n <cable-pair-ident>:\r\n Meaning: allows to configure the frequency the test \r\n must run with.\r\n Applicability : MELT only.\r\n Range: 300~3400\r\n Default: 800 Unit: Hz\r\n For SHDSL, only 800 Hz (default) and 1000 Hz are \r\n supported.\r\n <p-meter-pulse-sub>:\r\n Meaning: allows to configure the metering mode.\r\n Range: 1 TAPI_METER_MODE_TTX\r\n 2 TAPI_METER_MODE_REVPOL\r\n No default value.\r\n <dptmf-signal-sub>:\r\n Meaning: allows to configure the number of signals \r\n to be gathered.\r\n Range: 1~20\r\n No default value.\r\n <isdn-loopback>:\r\n Meaning: allows to configure the testside.\r\n Range: 1 LoopbackOnNTSide\r\n 2 LoopbackOnLtSide\r\n 3 LoopbackBothSide	<i>optional parameter</i> test parameter value1
value2	Parameter type: <LineTest::ParaValue2Voice> Format: - parameter value required for the execution of the \r\nspecified test type.\r\n<impedance tr/tg/rg(ohm)>:\r\n Meaning: allows to configure the RMS voltage level.\r\n Range: -150~+150\r\n Default: 15 Unit: V\r\n <cable-pair-ident>:\r\n Meaning: allows to configure the power level.\r\n Applicability : MELT only.\r\n Range: -600~0\r\n For XDSL, range is -600~-160\r\n For SHDSL, range is -340~-40\r\n Default: -160 Unit: 0.1 dbm	<i>optional parameter</i> test parameter value2
value3	Parameter type: <LineTest::ParaValue3Voice> Format: - parameter value3 is actually not used	<i>optional parameter</i> test parameter value3
value4	Parameter type: <LineTest::ParaValue4Voice> Format: - parameter value4 is actually not used	<i>optional parameter</i> test parameter value4

Parameter	Type	Description
value5	Parameter type: <LineTest::ParaValue5Voice> Format: - parameter value5 is actually not used	<i>optional parameter</i> test parameter value5
min-threshold	Parameter type: <LineTest::TestThreshold> Format: - threshold of the test type - range: [-2147483647...2147483647]	<i>optional parameter</i> threshold min of this test type
max-threshold	Parameter type: <LineTest::TestThreshold> Format: - threshold of the test type - range: [-2147483647...2147483647]	<i>optional parameter</i> threshold max of this test type
min-threshold2	Parameter type: <LineTest::TestThreshold> Format: - threshold of the test type - range: [-2147483647...2147483647]	<i>optional parameter</i> threshold2 min of this test type
max-threshold2	Parameter type: <LineTest::TestThreshold> Format: - threshold of the test type - range: [-2147483647...2147483647]	<i>optional parameter</i> threshold2 max of this test type
ltstrvalue1	Parameter type: <LineTest::ParaStringValueString> Format: - string parameter value required for the execution of the \r\nspecified test type.\r\n<diagnosis-call(1/10s)>:\r\n Meaning: allows to configure destination number.\r\n Applicability: NBLT only.\r\n Range: 0~9, *, #.\r\n No default value.\r\n Length: 1~16.	<i>optional parameter</i> test parameter string value1

53.5 SINGLE LineTest Session Configuration Command

Command Description

This command allows the operator to configure the single LineTest session parameters.

User Level

The command can be accessed by operators with sip , xdsl privileges, and executed by operators with sip , xdsl privileges.

Command Syntax

The command has the following syntax:

```
> configure linetest single ltsession (sessionid) [ session-cmd <LineTest::SessCmdForConfig> ] [ ownerid
<Gauge> ] [ timeout-period <LineTest::TimeOutPerSip> ] [ line-num <LineTest::LineNum> ] [ type-high
<LineTest::ltTypeHigh> ] [ type-low <LineTest::ltTypeLowSip> ] [ test-param-num <LineTest::TestParmNum> ] [
test-mode <LineTest::TestModeForConfig> ] [ inactive-timer <LineTest::InactTimer> ] [ type-extend
<LineTest::ltTypeExtendSip> ] [ no group-opt | group-opt <LineTest::ltGroupTestOpt> ] [ no busy-overwrite |
busy-overwrite <LineTest::ltBusyOverwriteFlag> ] [ no force-measure | force-measure <LineTest::ForceMeasure>
]
```

Command Parameters

Table 53.5-1 "SINGLE LineTest Session Configuration Command" Resource Parameters

Resource Identifier	Type	Description
(sessionid)	Format: - available session id - range: [1...16]	uniquely identify of session

Table 53.5-2 "SINGLE LineTest Session Configuration Command" Command Parameters

Parameter	Type	Description
session-cmd	Parameter type: <LineTest::SessCmdForConfig> Format: (create starttest sendinfo startinfo destroy recv-subtest start-subtest repeat endtest) Possible values: - create : create a test session	<i>optional parameter</i> the linetest session command

Parameter	Type	Description
	- starttest : transfer data done, start a test - sendinfo : start to transfer info data for an underway test - startinfo : transfer info data done, start info operation - destroy : destroy a test session - recv-subtest : start to transfer the sub-test's data - start-subtest : transfer sub-test's data done, start the sub-test - repeat : repeat the last test - endtest : end current test session	
ownerid	Parameter type: <Gauge> Format: - gauge	<i>optional parameter</i> ownerid of the session
timeout-period	Parameter type: <LineTest::TimeOutPerSip> Format: - allows to set the whole test timer including all test \r\nitems of all lines for the session. Should be larger \r\nthan or equal to the sum of all lines' limited time plus\r\nline test management time <2s>. Each line's limited time\r\nis the sum of all the test items' limited time in this \r\nline. There are two exceptions: a) cable-pair-ident,\r\nwhich uses a fixed limitation 60~5400s;\r\nb) diagnosis-call, which uses a fixed limitation 42~120s.\r\nTest items' limited time(second):\r\n test type POTS MELT \r\n- type-high\r\n group 20 18 \r\n feeded-ac-vol 3 N/A \r\n foreign-ac-vol 10 5 \r\n feeded-dc-vol 3 N/A \r\n foreign-dc-vol 15 5 \r\n feeding-current 3 N/A \r\n resistance 6 18 \r\n capacitance 15 18 \r\n impedance 5 N/A \r\n low-capacit-phone 20 N/A \r\n force-ring-subscrib 120 N/A \r\n dialton-delay 8 N/A \r\n msocket-detection 6 N/A \r\n- type-low\r\n ac-current 66 N/A \r\n dc-current 66 N/A \r\n noise-level 66 N/A \r\n howler 120 N/A \r\n status-monitored 3 N/A \r\n talking-father 3 N/A \r\n line-reverse-sub 60 N/A \r\n p-meter-pulse-sub 6 N/A \r\n ring-subscrib-sub 60 N/A \r\n dpdtmf-signal-sub 60 N/A \r\n userloop-sub 6 N/A \r\n etsi-signature N/A 18 \r\n electronic-ringer 10 N/A \r\n longitudinal-current 3 N/A \r\n conductance 8 20 \r\n susceptance 8 20 \r\n iltf-hazardous-voltage 30 20 \r\n- type-extend\r\n iltf-term-signature N/A 20 \r\n iltf-term-capacitiv 15 20 \r\n iltf-ppa-test 15 20 \r\n roh-test 8 20 \r\n gr909-ringer 20 N/A \r\n gr909-dialtone-d 8 N/A \r\n gr909-roh 20 N/A \r\n gr909-hazardous-p 20 N/A \r\n gr909-femf 20 N/A \r\n gr909-resistive-f 20 N/A \r\n iltf-term-ringer 10 N/A \r\n zener-res-volt 8 20 \r\n isdn-pra-remotelb 2 N/A \r\n isdn-pra-ploadlb 2 N/A \r\n isdn-pra-locallb 4 N/A \r\n isdn-pra-cablelb 2 N/A \r\n cas-r2-remotelb 2 N/A \r\n cas-r2-ploadlb 2 N/A \r\n cas-r2-locallb 4 N/A \r\n cas-r2-cablelb 2 N/A - unit: second - range: [2...4294967295]	<i>optional parameter</i> timeout period
line-num	Parameter type: <LineTest::LineNum> Format: - line number in the session of test - range: [1...72]	<i>optional parameter</i> line number in the session of test (Max line number depends on the physical line number of the device)
type-high	Parameter type: <LineTest::ltTypeHigh>	<i>optional parameter</i>

53 LineTest Configuration Commands

Parameter	Type	Description
	Format: (none group feeded-ac-vol foreign-ac-vol feeded-dc-vol foreign-dc-vol feeding-current resistance capacitance impedance low-capacit-phone force-ring-subscrib dialton-delay msocket-detection) Possible values: - none : null - group : group test, see group-opt argument for the content of the group test - feeded-ac-vol : feeded ac rms voltage test, HBit31/30/29 - foreign-ac-vol : foreign ac rms voltage test, HBit26/27/28 - feeded-dc-vol : feeded dc voltage test, HBit18/23/24/25 - foreign-dc-vol : foreign dc voltage test, HBit20/21/22 - feeding-current : feeding current test, HBit19 - resistance : insulating resistance test, HBit12/13/14/15/16/17(ISDN line test only support HBit14/15/16/17) - capacitance : capacitance test, HBit8/9/10/11 - impedance : impedance test, HBit4/5/6/7 - low-capacit-phone : low capacitance phone detect test, HBit3 - force-ring-subscrib : force ring subscriber test, HBit2 - dialton-delay : dial tone delay test of user circuit only in idle , HBit1 - msocket-detection : termination (m socket detection) test, HBit0	indicate line test items
type-low	Parameter type: <LineTest::ltTypeLowSip> Format: (none ac-current dc-current noise-level howler status-monitored cable-pair-ident talking-father line-reverse-sub p-meter-pulse-sub ring-subscrib-sub dpdtmf-signal-sub userloop-sub etsi-signature electronic-ringer longitudinal-current conductance susceptance iltf-hazardous-voltage)	<i>optional parameter</i> indicate line test items

Parameter	Type	Description
	Possible values: - none : null - ac-current : ac current test normal test, LBit29/30/31 - dc-current : dc current test normal test, LBit28/27/26 - noise-level : noise level normal test, LBit24 - howler : howler test under normal test, LBit22 - status-monitored : status monitored test, LBit20 - cable-pair-ident : cable pair identification test, LBit19 - talking-father : talking test (father test item), LBit18 - line-reverse-sub : line reverse test, subtest of talking test, LBit17 - p-meter-pulse-sub : private meter pulses test, subtest of talking test, LBit16 - ring-subscrib-sub : ring subscriber with auto ring test, subtest of talking test, LBit15 - dpdtmf-signal-sub : dp/dtmf signal test, subtest of talking test, LBit14 - userloop-sub : resistance of user loop (tip-ring), subtest of talking test, LBit13 - etsi-signature : etsi signature test, including capacitance and resistance, LBit12/11, for MELT only - electronic-ringer : electronic ringer detect test, including capacitance and resistance, LBit12/11, for NPOT-B only - longitudinal-current : longitudinal current test, LBit9 - conductance : termination conductance test, LBit4/5/6 - susceptance : termination susceptance test, LBit1/2/3 - iltf-hazardous-voltage: hazardous voltage detection test, LBit0	
test-parm-num	Parameter type: <LineTest::TestParmNum> Format: - parameter lines number in the session of test - range: [0...6]	<i>optional parameter</i> parameter lines number in the session for test
test-mode	Parameter type: <LineTest::TestModeForConfig> Format: (single interactive cablepair) Possible values: - single : the test will be end after one time - interactive : the interactive test - cablepair : the cable pair test	<i>optional parameter</i> test mode
inactive-timer	Parameter type: <LineTest::InactTimer> Format: - session inactive timer, 0 means never destroy the session automatically - unit: second - range: [0,120...65535]	<i>optional parameter</i> session inactive timer
type-extend	Parameter type: <LineTest::ItTypeExtendSip> Format: (none iltf-term-signature iltf-term-capacitiv iltf-ppa-test roh-test gr909-ringers gr909-dialtone-d gr909-roh	<i>optional parameter</i> indicate line test items

Parameter	Type	Description
	gr909-hazardous-p gr909-femf gr909-resistive-f iltf-term-ringer zener-res-volt isdn-pra-remotelb isdn-pra-ploadlb isdn-pra-locallb isdn-pra-cablelb cas-r2-remotelb cas-r2-ploadlb cas-r2-locallb cas-r2-cablelb diagnosis-call) Possible values: - none : null - iltf-term-signature : galvanic signature detection, ExBit31, only applicable for MELT - iltf-term-capacitiv : end device capacitance >50nF detection, ExBit30 - iltf-ppa-test : ppa variant test, ExBit29 - roh-test : termination roh test, ExBit28 - gr909-ringers : ringers test, ExBit26 - gr909-dialtone-d : draw and break dial tone delay test, ExBit25 - gr909-roh : receiver off hook test, ExBit24 - gr909-hazardous-p : hazardous potential test, ExBit23, - gr909-femf : foreign electromotive force test, ExBit22 - gr909-resistive-f : resistive faults test, ExBit21 - iltf-term-ringer : Termination Ringer Testing, ExBit27, only applicable for NPOT-B/C - zener-res-volt : Zener Resistance and Voltage test, ExBit20/19 - isdn-pra-remotelb : ISDN PRA Remote loopback test, ExBit18 - isdn-pra-ploadlb : ISDN PRA Payload loopback test, ExBit17 - isdn-pra-locallb : ISDN PRA Local loopback test, ExBit16 - isdn-pra-cablelb : ISDN PRA Cable loopback test, ExBit15 - cas-r2-remotelb : CAS R2 Remote loopback test, ExBit18 - cas-r2-ploadlb : CAS R2 Payload loopback test, ExBit17 - cas-r2-locallb : CAS R2 Local loopback test, ExBit16 - cas-r2-cablelb : CAS R2 Cable loopback test, ExBit15 - diagnosis-call : diagnosis call test, ExBit14	
[no] group-opt	Parameter type: <LineTest::ltGroupTestOpt> Format: (none extended pots-collective melt-collective) Possible values: - none : identifier group test normal report value, HBit28/27/26/22/21/20/17/16/15/14/11/9/8 - extended : identifier group test extended report value, HBit28/27/26/22/21/20/17/16/15/14/11/9/8 - pots-collective : identifier pots collective tests, HBit28/27/26/22/21/20/17/16/15/14/11/9/8,	<i>optional parameter with default value: "none"</i> indicate line test items

Parameter	Type	Description
	LBit12/11/6/5/4/3/2/1, ExBit30/29/28/27/20/19 - melt-collective : identifier MELT collective tests, HBit28/27/26/22/21/20/17/16/15/14/11/9/8, LBit12/11/6/5/4/3/2/1, ExBit31/30/29/28/20/19	
[no] busy-overwrite	Parameter type: <LineTest::ltBusyOverwriteFlag> Format: (true false) Possible values: - true : busy overwrite enable - false : busy overwrite disable	<i>optional parameter with default value: "false"</i> Session Busy Overwrite status
[no] force-measure	Parameter type: <LineTest::ForceMeasure> Format: (true false) Possible values: - true : force the MELT measurement for requested line tests - false : force measurement is not required	<i>optional parameter with default value: "false"</i> status of line for test

53.6 SINGLE LineTest Line Configuration Command

Command Description

This command allows the operator to configure the single LineTest line parameters.

User Level

The command can be accessed by operators with sip , xdsl privileges, and executed by operators with sip , xdsl privileges.

Command Syntax

The command has the following syntax:

```
> configure linetest single ltline (sessionid) lineid <Itf::LineTestSingleLineId> [ line-status
<LineTest::LineStatusForConfig> ]
```

Command Parameters

Table 53.6-1 "SINGLE LineTest Line Configuration Command" Resource Parameters

Resource Identifier	Type	Description
(sessionid)	Format: - available session id - range: [1...16]	uniquely identify of session
lineid	Parameter type: <Itf::LineTestSingleLineId> Format: <Eqpt::NodeId> / <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> Field type <Eqpt::NodeId> - the Node number Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number	Identify of line

Table 53.6-2 "SINGLE LineTest Line Configuration Command" Command Parameters

Parameter	Type	Description
line-status	Parameter type: <LineTest::LineStatusForConfig> Format: (intest testover	<i>optional parameter</i> status of line for test

Parameter	Type	Description
	rstpartlyready) Possible values: - intest : put the line in test - testover : the line tested, and the result is ready for polling, it is read-only - rstpartlyready : defined for dp/dtmf test	

53.7 SINGLE LineTest Param Configuration Command

Command Description

This command allows the operator to manage single linetest parameters.

User Level

The command can be accessed by operators with sip , xdsl privileges, and executed by operators with sip , xdsl privileges.

Command Syntax

The command has the following syntax:

```
> configure linetest single ltparm (sessionid) test-name(unit) <LineTest::TestTypeSip> [ value1
<LineTest::ParaValue1Sip> ] [ value2 <LineTest::ParaValue2Sip> ] [ value3 <LineTest::ParaValue3Sip> ] [
value4 <LineTest::ParaValue4Sip> ] [ value5 <LineTest::ParaValue5Sip> ] [ min-threshold
<LineTest::TestThreshold> ] [ max-threshold <LineTest::TestThreshold> ] [ min-threshold2
<LineTest::TestThreshold> ] [ max-threshold2 <LineTest::TestThreshold> ] [ ltstrvalue1
<LineTest::ParaStrValueString> ]
```

Command Parameters

Table 53.7-1 "SINGLE LineTest Param Configuration Command" Resource Parameters

Resource Identifier	Type	Description
(sessionid)	Format: - available session id - range: [1...16]	uniquely identify of session
test-name(unit)	Parameter type: <LineTest::TestTypeSip> Format: (feeded-ac-tr(mv) feeded-ac-tg(mv) feeded-ac-rg(mv) foreign-ac-tr(mv) foreign-ac-tg(mv) foreign-ac-rg(mv) feeded-dc-tr(mv) foreign-dc-tr(mv) foreign-dc-tg(mv) foreign-dc-rg(mv) feed-current(ua) feeded-dc-rt(mv) resist-tr(ohm) resist-rt(ohm) resist-tg(ohm)	test type

Resource Identifier	Type	Description
	resist-rg(ohm) resist-tbat(ohm) resist-rbat(ohm) capacitanc-tr(nf) capacitanc-rt(nf) capacitanc-tg(nf) capacitanc-rg(nf) impedance-tr(ohm) impedance-tg(ohm) impedance-rg(ohm) low-capacit-phone force-ring-subscrib dialton-delay(ms) msocket-detection ac-current-tr(ua) ac-current-tg(ua) ac-current-rg(ua) dc-current-tr(ua) dc-current-tg(ua) dc-current-rg(ua) noise-lv-0.001dbm howler-test-park status-monitored cable-pair-ident talking-father line-reverse-sub p-meter-pulse-sub ring-subscrib-sub dpdtmf-signal-sub userloop-sub(ohm) capacit-sign(pf) resist-sign(ohm) feeded-dc-tg(mv) feeded-dc-rg(mv) impedance-rt(ohm) long-current(ua) diagnosis-caller diagnosis-callee conductance-tr(1/10us) conductance-tg(1/10us) conductance-rg(1/10us) susceptance-tr(1/10us) susceptance-tg(1/10us) susceptance-rg(1/10us) hazardous-volt(1/2) term-signature(1/0) term-capacitiv(1/0) ppa-test(ppa-variant) roh-test(1/0) term_ringer(1/0) ringer-ren(mren) dialtone-delay-db(ms) gr909-roh gr909-hazardous-p gr909-femf gr909-resistive-f zener-res(ohm)	

Resource Identifier	Type	Description
	zener-volt(uv) remotelb ploadlb locallb cablelb isdn-pra-remotelb isdn-pra-ploadlb isdn-pra-locallb isdn-pra-cablelb cas-r2-remotelb cas-r2-ploadlb cas-r2-locallb cas-r2-cablelb diagnosis-call(1/10s)) Possible values: - feeded-ac-tr(mv) : feeded ac rms voltage of user line (tip-ring) - feeded-ac-tg(mv) : feeded ac rms voltage of user line (tip-ground) - feeded-ac-rg(mv) : feeded ac rms voltage of user line (ring-ground) - foreign-ac-tr(mv) : foreign ac rms voltage of user line (tip-ring) - foreign-ac-tg(mv) : foreign ac rms voltage of user line (tip-ground) - foreign-ac-rg(mv) : foreign ac rms voltage of user line (ring-ground) - feeded-dc-tr(mv) : feeded dc voltage of user line (tip-ring) - foreign-dc-tr(mv) : foreign dc voltage of user line (tip-ring) - foreign-dc-tg(mv) : foreign dc voltage of user line (tip-ground) - foreign-dc-rg(mv) : foreign dc voltage of user line (ring-ground) - feed-current(ua) : feeding current (tip-ring) - feeded-dc-rt(mv) : feeded dc voltage of user line (ring-tip) - resist-tr(ohm) : insulating resistance of user line (tip-ring) - resist-rt(ohm) : insulating resistance of user line (ring-tip) - resist-tg(ohm) : insulating resistance of user line (tip-ground) - resist-rg(ohm) : insulating resistance of user line (ring-ground) - resist-tbat(ohm) : insulating battery resistance of user line (tip-bat) - resist-rbat(ohm) : insulating battery resistance of user line (ring-bat) - capacitanc-tr(nf) : capacitance of user line (tip-ring) - capacitanc-rt(nf) : capacitance of user line (ring-tip) - capacitanc-tg(nf) : capacitance of user line (tip-ground) - capacitanc-rg(nf) : capacitance of user line (ring-ground) - impedance-tr(ohm) : impedance of user circuit (tip-ring) - impedance-tg(ohm) : impedance of user circuit (tip-ground) - impedance-rg(ohm) : impedance of user circuit (ring-ground) - low-capacit-phone : low capacitance phone detect - force-ring-subscrib : force ring subscriber test - dialton-delay(ms) : dial tone delay of user circuit only in	

Resource Identifier	Type	Description
	- idle - msocket-detection : termination (m socket detection) - ac-current-tr(ua) : ac current test normal test (tip-ring) - ac-current-tg(ua) : ac current test normal test (tip-ground) - ac-current-rg(ua) : ac current test normal test (ring-ground) - dc-current-tr(ua) : dc current test normal test (tip-ring) - dc-current-tg(ua) : dc current test normal test (tip-ground) - dc-current-rg(ua) : dc current test normal test (ring-ground) - noise-lv-0.001dbm : noise level normal test - howler-test-park : howler test under normal test condition only in parking - status-monitored : status monitored test - cable-pair-ident : cable pair identification test - talking-father : talking test (father test item) - line-reverse-sub : line reverse test, subtest of talking test - p-meter-pulse-sub : private meter pulses test, subtest of talking test - ring-subscrib-sub : ring subscriber with auto ring test, subtest of talking test - dpdtmf-signal-sub : dp/dtmf signal test, subtest of talking test - userloop-sub(ohm) : resistance of user loop (tip-ring), subtest of talking test - capacit-sign(pf) : capacitance of etsi signature or electronic ringer - resist-sign(ohm) : resistance of etsi signature or electronic ringer - feeded-dc-tg(mv) : feeded dc voltage of user line (tip-ground) - feeded-dc-rg(mv) : feeded dc voltage of user line (ring-ground) - impedance-rt(ohm) : impedance of user circuit (ring-tip) - long-current(ua) : difference between the currents on the a-lead and the b-lead (longitudinal current) - diagnosis-caller : H248 Voice Diagnosis Caller - diagnosis-callee : H248 Voice Diagnosis Callee - conductance-tr(1/10us): Conductance of user line (Tip-Ring) - conductance-tg(1/10us): Conductance of user line (Tip-Ground) - conductance-rg(1/10us): Conductance of user line (Ring-Ground) - susceptance-tr(1/10us): Susceptance of user line (Tip-Ring) - susceptance-tg(1/10us): Susceptance of user line (Tip-Ground) - susceptance-rg(1/10us): Susceptance of user line (Ring-Ground) - hazardous-volt(1/2) : whether voltage value is hazardous or not(iltf-hazardous-voltage) - term-signature(1/0) : whether termination signature is detected(iltf-termination-signature) - term-capacitiv(1/0) : whether termination capacitance is detected(iltf-termination-capacitiv) - ppa-test(ppa-variant) : test ppa variant(iltf-ppa) - roh-test(1/0) : test termination roh - term_ringer(1/0) : whether termination ringer is detected	

Resource Identifier	Type	Description
	- ringer-ren(mren) : gr909 ringer equivalency number testing - dialtone-delay-db(ms) : gr909 draw and break dial tone delay testing - gr909-roh : gr909 receiver off hook testing - gr909-hazardous-p : gr909 Hazardous Potential testing - gr909-femf : gr909 Foreign ElectroMotive Force testing - gr909-resistive-f : gr909 resistive faults testing - zener-res(ohm) : test zener resistance - zener-volt(uv) : test zener voltage - remotelb : E1 or T1 Remote loopback test - ploaddb : E1 or T1 Payload loopback test - locallb : E1 or T1 Local loopback test - cablelb : E1 or T1 Cable loopback test - isdn-pra-remotelb : ISDN PRA Remote loopback test - isdn-pra-ploaddb : ISDN PRA Payload loopback test - isdn-pra-locallb : ISDN PRA Local loopback test - isdn-pra-cablelb : ISDN PRA Cable loopback test - cas-r2-remotelb : CAS R2 Remote loopback test - cas-r2-ploaddb : CAS R2 Payload loopback test - cas-r2-locallb : CAS R2 Local loopback test - cas-r2-cablelb : CAS R2 Cable loopback test - diagnosis-call(1/10s) : diagnosis call test	

Table 53.7-2 "SINGLE LineTest Param Configuration Command" Command Parameters

Parameter	Type	Description
value1	Parameter type: <LineTest::ParaValue1Sip> Format: - parameter value required for the execution of the \r\nspecified test type.\r\n<resistance tr/rt(ohm)>:\r\n Meaning: allows to configure whether it is required \r\n to test the 'signature' or not.\r\n Applicability : MELT only.\r\n Range: No(0) Yes(1)\r\n Default: No(0)\r\n <impedance tr/tg/rg(ohm)>:\r\n Meaning: allows to configure the frequency the test \r\n must run with.\r\n Range: 5~3000\r\n Default: 20 Unit: Hz\r\n <status-monitored>:\r\n Meaning: allows to configure whether to check real \r\n parking or short current state.\r\n Range: No(1) Yes(2)\r\n No default value.\r\n <cable-pair-ident>:\r\n Meaning: allows to configure the frequency the test \r\n must run with.\r\n Applicability : MELT only.\r\n Range: 300~3400\r\n Default: 800 Unit: Hz\r\n For SHDSL, only 800 Hz (default) and 1000 Hz are \r\n supported.\r\n <p-meter-pulse-sub>:\r\n Meaning: allows to configure the metering mode.\r\n Range: 1 TAPI_METER_MODE_TTX\r\n 2 TAPI_METER_MODE_REVPOL\r\n No default value.\r\n <dpdtmf-signal-sub>:\r\n Meaning: allows to configure the number of signals\r\n to be gathered.\r\n Range: 1~20\r\n No default value.\r\n <isdn-pra-locallb / cablelb>:\r\n Meaning: allows to configure the test pattern to be \r\n used for the loopback test.\r\n If no input is given, a 'Pseudo-random' pattern is \r\n defined and applied by the system.\r\n If an input is given (value in the range 0~254), the \r\n value defines the pattern (range 0x00~0xFE) to be used \r\n for the loopback test.\r\n Range: 0~254\r\n Default: 'Pseudo-random' pattern (no input	<i>optional parameter</i> test parameter value1

Parameter	Type	Description
	given)\r\n<cas-r2-locallb / cablelb>:\r\n Meaning: allows to configure the test pattern to be \r\n used for the loopback test.\r\n If no input is given, a 'Pseudo-random' pattern is \r\n defined and applied by the system.\r\n If an input is given (value in the range 0~254), the \r\n value defines the pattern (range 0x00~0xFE) to be used \r\n for the loopback test.\r\n Range: 0~254\r\n Default: 'Pseudo-random' pattern (no input given)	
value2	Parameter type: <LineTest::ParaValue2Sip> Format: - parameter value required for the execution of the \r\n unspecified test type.\r\n <impedance tr/tg/rg(ohm)>:\r\n Meaning: allows to configure the RMS voltage level.\r\n Range: -150~+150\r\n Default: 15 Unit: V\r\n \r\n <cable-pair-ident>:\r\n Meaning: allows to configure the power level.\r\n Applicability : MELT only.\r\n Range: -600~0\r\n For XDSL, range is -600~-160\r\n For SHDSL, range is -340~-40\r\n Default: -160 Unit: 0.1 dbm	<i>optional parameter</i> test parameter value2
value3	Parameter type: <LineTest::ParaValue3Sip> Format: - parameter value3 is actually not used	<i>optional parameter</i> test parameter value3
value4	Parameter type: <LineTest::ParaValue4Sip> Format: - parameter value4 is actually not used	<i>optional parameter</i> test parameter value4
value5	Parameter type: <LineTest::ParaValue5Sip> Format: - parameter value5 is actually not used	<i>optional parameter</i> test parameter value5
min-threshold	Parameter type: <LineTest::TestThreshold> Format: - threshold of the test type - range: [-2147483647...2147483647]	<i>optional parameter</i> threshold min of this test type
max-threshold	Parameter type: <LineTest::TestThreshold> Format: - threshold of the test type - range: [-2147483647...2147483647]	<i>optional parameter</i> threshold max of this test type
min-threshold2	Parameter type: <LineTest::TestThreshold> Format: - threshold of the test type - range: [-2147483647...2147483647]	<i>optional parameter</i> threshold2 min of this test type
max-threshold2	Parameter type: <LineTest::TestThreshold> Format: - threshold of the test type - range: [-2147483647...2147483647]	<i>optional parameter</i> threshold2 max of this test type
ltstrvalue1	Parameter type: <LineTest::ParaStringValueString> Format: - string parameter value required for the execution of the \r\n unspecified test type.\r\n <diagnosis-call(1/10s)>:\r\n Meaning: allows to configure destination number.\r\n Applicability: NBLT only.\r\n Range: 0~9, *, #,\r\n No default value.\r\n Length: 1~16.	<i>optional parameter</i> test parameter string value1

54- LACP Configuration Commands

54.1 LACP Configuration Command Tree	54-1615
54.2 LACP general configuration command	54-1616
54.3 LACP port configuration command	54-1617
54.4 LACP group configuration command	54-1618
54.5 LACP Group Port configuration command	54-1620

54.1 LACP Configuration Command Tree

Description

This chapter gives an overview of nodes that are handled by "LACP Configuration Commands".

Command Tree

```
----configure
  ----link-agg
    ----general
      - [no] priority
    ----port
      - (port)
      - [no] passive-lacp
      - [no] short-timeout
      - [no] actor-port-prio
    ----group
      - (group)
      - load-sharing-policy
      - [no] max-active-port
      - [no] swo-threshold
      - [no] priority
      - swo-revert
      - mode
      - master-iwf
    ----[no] port
      - (port)
```

54.2 LACP general configuration command

Command Description

This command allows the operator to configure the general LACP parameters.

User Level

The command can be accessed by operators with lacp privileges, and executed by operators with lacp privileges.

Command Syntax

The command has the following syntax:

```
> configure link-agg general [ no priority | priority <Lacp::SysPriority> ]
```

Command Parameters

Table 54.2-2 "LACP general configuration command" Command Parameters

Parameter	Type	Description
[no] priority	Parameter type: <Lacp::SysPriority> Format: - the lacp system priority - range: [1...65535]	<i>optional parameter with default value: 1</i> the lacp system priority

54.3 LACP port configuration command

Command Description

This command allows the operator to configure the link aggregation port parameters.

User Level

The command can be accessed by operators with lacp privileges, and executed by operators with lacp privileges.

Command Syntax

The command has the following syntax:

```
> configure link-agg port (port) [ [ no ] passive-lacp ] [ [ no ] short-timeout ] [ no actor-port-prio | actor-port-prio
<Lacp::ActorPortPriority> ]
```

Command Parameters

Table 54.3-1 "LACP port configuration command" Resource Parameters

Resource Identifier	Type	Description
(port)	Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number	interface index of the port

Table 54.3-2 "LACP port configuration command" Command Parameters

Parameter	Type	Description
[no] passive-lacp	Parameter type: boolean	<i>optional parameter</i> set lacp inactive for the actor
[no] short-timeout	Parameter type: boolean	<i>optional parameter</i> short timeout for the lacp protocol
[no] actor-port-prio	Parameter type: <Lacp::ActorPortPriority> Format: - la aggregate port priority - range: [0...65535]	<i>optional parameter with default value: "1"</i> port priority for the actor

54.4 LACP group configuration command

Command Description

This command allows the operator to configure the link aggregation group parameters.

User Level

The command can be accessed by operators with lacp privileges, and executed by operators with lacp privileges.

Command Syntax

The command has the following syntax:

```
> configure link-agg group (group) [ load-sharing-policy <Lacp::LoadSharingPolicy> ] [ no max-active-port |
max-active-port <Lacp::MaxActivePort> ] [ no swo-threshold | swo-threshold <Lacp::SwThreshold> ] [ no priority
| priority <Lacp::AggSysPri> ] [ swo-revert <Lacp::SwRevert> ] [ mode <Lacp::Mode> ] [ master-iwf
<Lacp::MasterIwf> ]
```

Command Parameters

Table 54.4-1 "LACP group configuration command" Resource Parameters

Resource Identifier	Type	Description
(group)	Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number	interface index of the link aggregation group

Table 54.4-2 "LACP group configuration command" Command Parameters

Parameter	Type	Description
load-sharing-policy	Parameter type: <Lacp::LoadSharingPolicy> Format: (mac-src mac-dst mac-src-dst ip-src ip-dst ip-src-dst l2-l3-hybrid-model) Possible values: - mac-src : source mac based - mac-dst : destination mac based	<i>optional parameter</i> link aggregation load sharing policy

Parameter	Type	Description
	- mac-src-dst : source and destination mac based - ip-src : source ip based - ip-dst : destination ip based - ip-src-dst : source and destination ip based - l2-l3-hybrid-model : l2 and l3 hybrid model based	
[no] max-active-port	Parameter type: <Lacp::MaxActivePort> Format: - max active port - range: [1...8]	<i>optional parameter with default value: 8</i> the max active port number in a LAG
[no] swo-threshold	Parameter type: <Lacp::SwThreshold> Format: - the switchover threshold in a cross-lt LAG - range: [0...8]	<i>optional parameter with default value: 0</i> the switchover threshold in a cross-lt LAG
[no] priority	Parameter type: <Lacp::AggSysPri> Format: - the lacp agg actor system priority - range: [0...65535]	<i>optional parameter with default value: "0"</i> the system priority in a LAG
swo-revert	Parameter type: <Lacp::SwRevert> Format: (disable enable) Possible values: - disable : disable switchover revert - enable : enable switchover revert	<i>optional parameter</i> the switchover revert flag in a cross-lt LAG
mode	Parameter type: <Lacp::Mode> Format: (static dynamic) Possible values: - static : static mode - dynamic : dynamic mode	<i>optional parameter</i> lacp mode
master-iwf	Parameter type: <Lacp::MasterIwf> Format: (auto unset) Possible values: - auto : app select the IWF connected to the primary link of the lag - unset : dummy lag	<i>optional parameter</i> master iwf value

54.5 LACP Group Port configuration command

Command Description

This command allows the operator to add/remove link aggregation group member ports.

User Level

The command can be accessed by operators with lacp privileges, and executed by operators with lacp privileges.

Command Syntax

The command has the following syntax:

```
> configure link-agg group (group) ( no port (port) ) | ( port (port) )
```

Command Parameters

Table 54.5-1 "LACP Group Port configuration command" Resource Parameters

Resource Identifier	Type	Description
(group)	Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number	interface index of the link aggregation group
(port)	Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number	Interface index of the port

55- MSTP Configuration Commands

55.1 MSTP Configuration Command Tree	55-1622
55.2 MSTP general configuration Command	55-1623
55.3 MSTP Instance configuration Command	55-1625
55.4 MSTP Vlan-Instance Mapping configuration Command	55-1626
55.5 MSTP Port configuration Command	55-1627
55.6 MSTP Port-Instance configuration Command	55-1629

55.1 MSTP Configuration Command Tree

Description

This chapter gives an overview of nodes that are handled by "MSTP Configuration Commands".

Command Tree

```
----configure
  ----xstp
    ----general
      - [no] enable-stp
      - [no] priority
      - [no] max-instance-num
      - [no] max-age
      - [no] hello-time
      - [no] forward-delay
      - [no] version
      - [no] tx-hold-count
      - [no] path-cost-type
      - [no] max-hop-count
      - region-name
      - [no] region-version
      - [no] config-id-sel
    ----[no] instance
      - (instance)
      - [no] priority
    ----[no] associate-vlan
      - (vlan)
  ----port
    - (port)
    - [no] priority
    - [no] enable-stp
    - path-cost
    - [no] edge-port
    - [no] admin-p2p
    - [no] hello-time
  ----port-instance
    - (port)
    - instance
    - [no] priority
    - [no] enable-stp
    - path-cost
```


55.2 MSTP general configuration Command

Command Description

This command allows the operator to configure the general MSTP parameters. The configuration of the parameters apply for the whole bridge.

The port, instance and port-instance specific MSTP parameters are in subsequent chapters.

The bridge max-age value should be less than or equal to $(2 * ((\text{forward-delay}/100) - 1))$ and should be greater than or equal to $(2 * ((\text{Port hello-time}/100) + 1))$.

The bridge hello-time is only applicable when the version is stp/rstp, in case of version mstp the port hello-time is used.

User Level

The command can be accessed by operators with mstp privileges, and executed by operators with mstp privileges.

Command Syntax

The command has the following syntax:

```
> configure xstp general [ [ no ] enable-stp ] [ no priority | priority <Mstp::StpPriority> ] [ no max-instance-num |
max-instance-num <Mstp::StpMaxInstanceNumber> ] [ no max-age | max-age <Mstp::StpMaxAge> ] [ no
hello-time | hello-time <Mstp::StpHelloTime> ] [ no forward-delay | forward-delay <Mstp::StpFwDelay> ] [ no
version | version <Mstp::StpProtVersion> ] [ no tx-hold-count | tx-hold-count <Mstp::StpTxHoldCount> ] [ no
path-cost-type | path-cost-type <Mstp::StpPathCostType> ] [ no max-hop-count | max-hop-count
<Mstp::StpMaxHopCount> ] [ region-name <Mstp::StpRegionName> ] [ no region-version | region-version
<Mstp::StpRegionVersion> ] [ no config-id-sel | config-id-sel <Mstp::StpConfigIdSelector> ]
```

Command Parameters

Table 55.2-2 "MSTP general configuration Command" Command Parameters

Parameter	Type	Description
[no] enable-stp	Parameter type: boolean	optional parameter all stp protocol operations start
[no] priority	Parameter type: <Mstp::StpPriority> Format: - stp bridge priority(n*4096) - range: [0...61440]	optional parameter with default value: 32768 stp bridge priority(n*4096)
[no] max-instance-num	Parameter type: <Mstp::StpMaxInstanceNumber> Format: - the max spanning trees number - range: [1...65]	optional parameter with default value: 65 the maximum number of spanning trees to be allowed
[no] max-age	Parameter type: <Mstp::StpMaxAge> Format: - stp max-age for root-bridge(n*100) - unit: 10msec - range: [600...4000]	optional parameter with default value: 2000 stp max-age for root-bridge(n*100)

55 MSTP Configuration Commands

Parameter	Type	Description
[no] hello-time	Parameter type: <Mstp::StpHelloTime> Format: - stp bridge hello time(n*100) - unit: 10msec - range: [100...1000]	<i>optional parameter with default value: 200</i> stp hello-time for bridge acting as root(n*100)
[no] forward-delay	Parameter type: <Mstp::StpFwDelay> Format: - stp bridge forward delay(n*100) - unit: 10msec - range: [400...3000]	<i>optional parameter with default value: 1500</i> forward delay value (n*100)
[no] version	Parameter type: <Mstp::StpProtVersion> Format: (stp-compatible rstp mstp) Possible values: - stp-compatible : spanning tree protocol IEEE 802.1D - rstp : rapid spanning tree protocol IEEE 802.1w - mstp : multiple spanning tree protocol IEEE 802.1s	<i>optional parameter with default value: "mstp"</i> spanning tree protocol version
[no] tx-hold-count	Parameter type: <Mstp::StpTxHoldCount> Format: - maximum transmission rate limit - range: [1...10]	<i>optional parameter with default value: 3</i> maximum transmission rate limit
[no] path-cost-type	Parameter type: <Mstp::StpPathCostType> Format: (16-bit 32-bit) Possible values: - 16-bit : stp-8021d-1998 path cost - 32-bit : stp-8021t-2001 path cost	<i>optional parameter with default value: "32-bit"</i> version of stp default path costs
[no] max-hop-count	Parameter type: <Mstp::StpMaxHopCount> Format: - maximum hop count value - unit: 10msec - range: [600...4000]	<i>optional parameter with default value: 2000</i> max hop count(n*100)
region-name	Parameter type: <Mstp::StpRegionName> Format: - name of the regions configuration - length: x<=32	<i>optional parameter</i> name of regions configuration(by default the bridge mac address)
[no] region-version	Parameter type: <Mstp::StpRegionVersion> Format: - version of the MSTP region - range: [0...65535]	<i>optional parameter with default value: 0</i> version of the MSTP region
[no] config-id-sel	Parameter type: <Mstp::StpConfigIdSelector> Format: - configuration id format selector to identify the bridge - range: [0...255]	<i>optional parameter with default value: 0</i> configuration id selector used to identify the bridge

55.3 MSTP Instance configuration Command

Command Description

This command allows the operator to configure the MSTP parameters for a specific MSTP instance.

User Level

The command can be accessed by operators with mstp privileges, and executed by operators with mstp privileges.

Command Syntax

The command has the following syntax:

```
> configure xstp ( no instance (instance) ) | ( instance (instance) [ no priority | priority <Mstp::StpPriority> ] )
```

Command Parameters

Table 55.3-1 "MSTP Instance configuration Command" Resource Parameters

Resource Identifier	Type	Description
(instance)	Format: - MSTP Instance - range: [1...64]	MSTP instance

Table 55.3-2 "MSTP Instance configuration Command" Command Parameters

Parameter	Type	Description
[no] priority	Parameter type: <Mstp::StpPriority> Format: - stp bridge priority(n*4096) - range: [0...61440]	<i>optional parameter with default value: 32768</i> the Bridge Priority(n*4096)

55.4 MSTP Vlan-Instance Mapping configuration

Command

Command Description

This command allows the operator to map/unmap VLANs to a specific MSTP instance. The VLAN can be associated with the MSTP instance without being configured first. One or more VLANs can be associated to an instance, but one VLAN can not be assigned to different instances.

User Level

The command can be accessed by operators with mstp privileges, and executed by operators with mstp privileges.

Command Syntax

The command has the following syntax:

```
> configure xstp instance (instance) ( no associate-vlan (vlan) ) | ( associate-vlan (vlan) )
```

Command Parameters

Table 55.4-1 "MSTP Vlan-Instance Mapping configuration Command" Resource Parameters

Resource Identifier	Type	Description
(instance)	Format: - MSTP Instance - range: [1...64]	MSTP instance
(vlan)	Format: (<Network::UVlanIndex> stacked : <Network::SVlanIndex> : <Network::CVlanIndex>) Possible values: - stacked : stacked vlan identity Field type <Network::UVlanIndex> - unstacked vlan identity - range: [1...4093] Field type <Network::SVlanIndex> - service vlan identity - range: [2...4093] Field type <Network::CVlanIndex> - customer vlan identity - range: [0...4093]	vlan id to be associated with the mstp instance

55.5 MSTP Port configuration Command

Command Description

This command allows the operator to configure the port parameters for the Common Instance.

By default mstp is disabled on the ports.

User Level

The command can be accessed by operators with mstp privileges, and executed by operators with mstp privileges.

Command Syntax

The command has the following syntax:

```
> configure xstp port (port) [ no priority | priority <Mstp::MstpPortPriority> ] [ [ no ] enable-stp ] [ path-cost
<Mstp::MstpPathCost> ] [ [ no ] edge-port ] [ no admin-p2p | admin-p2p <Mstp::MstpAdminP2PPort> ] [ no
hello-time | hello-time <Mstp::StpHelloTime> ]
```

Command Parameters

Table 55.5-1 "MSTP Port configuration Command" Resource Parameters

Resource Identifier	Type	Description
(port)	Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number	Interface index of the lag

Table 55.5-2 "MSTP Port configuration Command" Command Parameters

Parameter	Type	Description
[no] priority	Parameter type: <Mstp::MstpPortPriority> Format: - mstp port priority(n*16) - range: [0...240]	<i>optional parameter with default value: 128</i> mstp port priority(n*16)
[no] enable-stp	Parameter type: boolean	<i>optional parameter</i> current Msti port state enabled
path-cost	Parameter type: <Mstp::MstpPathCost> Format: - port path cost - range: [1...200000000]	<i>optional parameter</i> port path cost
[no] edge-port	Parameter type: boolean	<i>optional parameter</i>

55 MSTP Configuration Commands

Parameter	Type	Description
[no] admin-p2p	Parameter type: <Mstp::MstpAdminP2PPort> Format: (force-true force-false auto) Possible values: - force-true : p2p link connection - force-false : shared media connection - auto : auto	port state enabled for the MSTP <i>optional parameter with default value: "auto"</i> admin p2p status of the LAN segment attached to the port
[no] hello-time	Parameter type: <Mstp::StpHelloTime> Format: - stp bridge hello time(n*100) - unit: 10msec - range: [100...1000]	<i>optional parameter with default value: 200</i> port hello time(n*100)

55.6 MSTP Port-Instance configuration Command

Command Description

This command allows the operator to configure the MSTP parameters for a specific port-instance configuration. In order to be able to configure the port-instance parameters, the port must be member of the vlan-port map. This configuration applies to the Mstp.

User Level

The command can be accessed by operators with mstp privileges, and executed by operators with mstp privileges.

Command Syntax

The command has the following syntax:

```
> configure xstp port-instance (port) instance <Mstp::MstpInstance> [ no priority | priority
<Mstp::MstpPortPriority> ] [ [ no ] enable-stp ] [ path-cost <Mstp::MstpPathCost> ]
```

Command Parameters

Table 55.6-1 "MSTP Port-Instance configuration Command" Resource Parameters

Resource Identifier	Type	Description
(port)	Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number	interface index of the lag
instance	Parameter type: <Mstp::MstpInstance> Format: - MSTP Instance - range: [1...64]	mstp instance

Table 55.6-2 "MSTP Port-Instance configuration Command" Command Parameters

Parameter	Type	Description
[no] priority	Parameter type: <Mstp::MstpPortPriority> Format: - mstp port priority(n*16) - range: [0...240]	optional parameter with default value: 128 mstp port priority(n*16)
[no] enable-stp	Parameter type: boolean	optional parameter current Msti port state enabled
path-cost	Parameter type: <Mstp::MstpPathCost> Format:	optional parameter port path cost

55 MSTP Configuration Commands

Parameter	Type	Description
	- port path cost - range: [1...200000000]	

56- Application Intelligence Configuration Commands

56.1 Application Intelligence Configuration Command Tree	56-1632
56.2 Application configuration command	56-1633
56.3 AI Platform configuration command	56-1634
56.4 Application 'download and installation' configuration command	56-1636

56.1 Application Intelligence Configuration Command Tree

Description

This chapter gives an overview of nodes that are handled by "Application Intelligence Configuration Commands".

Command Tree

```
----configure
----ai
----[no] application
- (application)
- [no] uri
----[no] platform
- (slot)
- virtualplatform
- [no] adminstate
- [no] oamadminstate
- [no] mngtvlan
- [no] ipaddresstype
- [no] ipaddressandmask
- [no] defaultgateway
----[no] application
- (application)
- [no] adminstate
```

56.2 Application configuration command

Command Description

This command is used to register an Application and the Uniform Resource Identifier (URI) from where it can be downloaded.

Obviously a correct URI is essential to have a successful download.

Typical examples for a URI: http://<some-address> or ftp://<some-address>

The system does not perform a URI syntax / semantic check at Application configuration time.

Instead the URI will be used only at the time an Application is configured to be installed on a specific AI Platform and failures will be reported at that time.

Note that this data can not be changed when the Application is planned for download and installation on an AI Platform.

User Level

The command can be accessed by operators with ai privileges, and executed by operators with ai privileges.

Command Syntax

The command has the following syntax:

```
> configure ai ( no application (application) ) | ( application (application) [ no uri | uri <AI::Uri> ] )
```

Command Parameters

Table 56.2-1 "Application configuration command" Resource Parameters

Resource Identifier	Type	Description
(application)	Format: - a name for the Application - range: [a-zA-Z0-9!#\$%&()*+-./:;=?@[_~] - length: 1<=x<=31	The name of the Application

Table 56.2-2 "Application configuration command" Command Parameters

Parameter	Type	Description
[no] uri	Parameter type: <AI::Uri> Format: - a uri name - range: [a-zA-Z0-9!#\$%&()*+-./:;=?@[_~] - length: x<=255	<i>optional parameter with default value: ""</i> name of the Uniform Resource Identifier (URI). Typical examples for a URI: http://<some-address> or ftp://<some-address>

56.3 AI Platform configuration command

Command Description

This command is used to administratively (un)lock an AI Platform and to configure the parameters that will allow external OAM access to it.

Unlocking the platform causes the platform to start up.

Locking the AI Platform results in bringing it down which means also that all Applications are down.

Note that a modify of OAM parameters requires the locking of the external OAM parameters which makes the external OAM access unavailable.

User Level

The command can be accessed by operators with ai privileges, and executed by operators with ai privileges.

Command Syntax

The command has the following syntax:

```
> configure ai ( no platform (slot) virtualplatform <AI::VirtualPlatform> ) | ( platform (slot) virtualplatform
<AI::VirtualPlatform> [ no adminstate | adminstate <AI::AdminState> ] [ no oamadminstate | oamadminstate
<AI::AdminState> ] [ no mngtvlan | mngtvlan <Vlan::VlanNameIndex> ] [ no ipaddresstype | ipaddresstype
<AI::IpAddressType> ] [ no ipaddressandmask | ipaddressandmask <Ip::AddressAndMask> ] [ no defaultgateway |
defaultgateway <Aaa::InetAddress> ] )
```

Command Parameters

Table 56.3-1 "AI Platform configuration command" Resource Parameters

Resource Identifier	Type	Description
(slot)	Format: (nt-a nt-b) Possible values: - nt-a : nt-a slot - nt-b : nt-b slot	slot Id of the AI Platform
virtualplatform	Parameter type: <AI::VirtualPlatform> Format: - AI Virtual Platform Index within the Slot - range: [1]	virtual Id within the slot of the AI Platform

Table 56.3-2 "AI Platform configuration command" Command Parameters

Parameter	Type	Description
[no] adminstate	Parameter type: <AI::AdminState> Format: (unlocked locked) Possible values:	<i>optional parameter with default value: "locked"</i> determines if the AI Platform shall be started up

Parameter	Type	Description
	- unlocked : The identified resource is allowed to be used - locked : The identified resource is not allowed to be used	
[no] oamadminstate	Parameter type: <AI::AdminState> Format: (unlocked locked) Possible values: - unlocked : The identified resource is allowed to be used - locked : The identified resource is not allowed to be used	<i>optional parameter with default value: "locked"</i> determines if an external OAM mngt interface shall be provided
[no] mngtvlan	Parameter type: <Vlan::VlanNameIndex> Format: - vlan id - range: [1...4093]	<i>optional parameter with default value: "4093"</i> management VLAN providing external OAM access to the AI Platform
[no] ipaddresstype	Parameter type: <AI::IpAddressType> Format: ipv4 Possible values: - ipv4 : ipv4	<i>optional parameter with default value: "ipv4"</i> the type of the IP address within the ipaddressandmask and the defaultgateway parameters
[no] ipaddressandmask	Parameter type: <Ip::AddressAndMask> Format: <Ip::V4Address> / <Ip::PrefixLength> Field type <Ip::V4Address> - IPv4-address Field type <Ip::PrefixLength> - IP address prefix length - range: [0...30]	<i>optional parameter with default value: "0.0.0.0/0"</i> OAM IP address to access the AI Platform
[no] defaultgateway	Parameter type: <Aaa::InetAddress> Format: - IPv4-address	<i>optional parameter with default value: "0.0.0.0"</i> default gateway IP address

56.4 Application 'download and installation' configuration command

Command Description

This command is used to configure the Applications to be downloaded and installed on a specified AI Platform.

User Level

The command can be accessed by operators with ai privileges, and executed by operators with ai privileges.

Command Syntax

The command has the following syntax:

```
> configure ai platform (slot)virtualplatform <AI::VirtualPlatform> ( no application (application) ) | ( application (application) [ no adminstate | adminstate <AI::AdminState> ] )
```

Command Parameters

Table 56.4-1 "Application 'download and installation' configuration command" Resource Parameters

Resource Identifier	Type	Description
(slot)	Format: (nt-a nt-b) Possible values: - nt-a : nt-a slot - nt-b : nt-b slot	slot Id of the AI Platform
virtualplatform	Parameter type: <AI::VirtualPlatform> Format: - AI Virtual Platform Index within the Slot - range: [1]	virtual Id within the slot of the AI Platform
(application)	Format: - a name for the Application - range: [a-zA-Z0-9!#\$%&()*+-./:;=?@[_~] - length: 1<=x<=31	the unique Application name

Table 56.4-2 "Application 'download and installation' configuration command" Command Parameters

Parameter	Type	Description
[no] adminstate	Parameter type: <AI::AdminState> Format: (unlocked locked) Possible values: - unlocked : The identified resource is allowed to be used	<i>optional parameter with default value: "locked"</i> determines if the Application shall be downloaded and installed

56 Application Intelligence Configuration Commands

Parameter	Type	Description
	- locked : The identified resource is not allowed to be used	

57- NGpon2 Channel Group/Sub Channel Group Configuration Commands

57.1 NGpon2 Channel Group/Sub Channel Group Configuration Command Tree	57-1639
57.2 NGpon2 Channel Group Configuration Command	57-1640
57.3 NGpon2 Channel Group Member Association Command	57-1642
57.4 NGpon2 Sub Channel Group Configuration Command	57-1643
57.5 NGpon2 Sub Channel Group Member Association Command	57-1646

57.1 NGpon2 Channel Group/Sub Channel Group Configuration Command Tree

Description

This chapter gives an overview of nodes that are handled by "NGpon2 Channel Group/Sub Channel Group Configuration Commands".

Command Tree

```
----configure
  ----channel-group
    ----[no] id
      - (channel-group-id)
      - [no] name
      - [no] polling-period
      - [no] raman-reduct
      - [no] ng2sys-id
      - [no] admin-state
    ----[no] channel-pair
      - (channel-pair)
    ----subchannel-group
      ----[no] id
        - (subchannel-group)
        - [no] name
        - [no] auth-method
        - [no] mcast-encrypt
        - [no] fec-dn
        - [no] closest-ont
        - [no] diff-reach
        - [no] admin-state
        - [no] cpi
      ----[no] channel-pair
        - (channel-pair)
```

57.2 NGpon2 Channel Group Configuration Command

Command Description

This command configures a NGpon2 Channel Group.

User Level

The command can be accessed by operators with equipment privileges, and executed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

```
> configure channel-group ( no id (channel-group-id) ) | ( id (channel-group-id) [ no name | name <Ng2::Label> ] [ no polling-period | polling-period <Ng2::ChanGrpPollingPeriod> ] [ no raman-reduct | raman-reduct <Ng2::RamanReduction> ] [ no ng2sys-id | ng2sys-id <Ng2::SysId> ] [ no admin-state | admin-state <Gpon::ItfAdminStatus> ] )
```

Command Parameters

Table 57.2-1 "NGpon2 Channel Group Configuration Command" Resource Parameters

Resource Identifier	Type	Description
(channel-group-id)	Format: <Ng2::ChannelGroup> Field type <Ng2::ChannelGroup> - channel group number	identification of the channel group index

Table 57.2-2 "NGpon2 Channel Group Configuration Command" Command Parameters

Parameter	Type	Description
[no] name	Parameter type: <Ng2::Label> Format: - a printable string - length: x<=50	<i>optional parameter with default value: ""</i> textual string that can be used to label this channel group
[no] polling-period	Parameter type: <Ng2::ChanGrpPollingPeriod> Format: - period between autodetection procedure on each pair in the group - unit: 1/10 sec - range: [1...864000]	<i>optional parameter with default value: 100</i> period between autodetection procedure on each pair in the group
[no] raman-reduct	Parameter type: <Ng2::RamanReduction> Format: (enable disable) Possible values:	<i>optional parameter with default value: "disable"</i> enable/disable Raman Reduction code for this channel group

Parameter	Type	Description
	- enable : raman reduction code enabled - disable : raman reduction code disabled	
[no] ng2sys-id	Parameter type: <Ng2::SysId> Format: - ng2sysid - 5 hex characters - length: x<=5	<i>optional parameter with default value: "00000"</i> ng2sysid
[no] admin-state	Parameter type: <Gpon::ItfAdminStatus> Format: (up down) Possible values: - up : set the admin-state to up - down : set the admin-state to down	<i>optional parameter with default value: "down"</i> <i>The parameter is not visible during creation.</i> administrative status of the channel group

Command Output

Table 57.2-3 "NGpon2 Channel Group Configuration Command" Display parameters

Specific Information		
name	Type	Description
oper-state	Parameter type: <Itf::ifOperStatus> (up down testing unknown dormant no-value) Possible values: - up : up,traffic can pass - down : down,no traffic is passing - testing : testing,no traffic is passing - unknown : unknown - dormant : dormant,no traffic is passing - no-value : no entry in the table	operational state of the channel group <i>This element is always shown.</i>

57.3 NGpon2 Channel Group Member Association Command

Command Description

This command associates a NGpon2 Channel Pair with a Channel Group.

User Level

The command can be accessed by operators with equipment privileges, and executed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

```
> configure channel-group id (channel-group-id) ( no channel-pair (channel-pair) ) | ( channel-pair (channel-pair) )
```

Command Parameters

Table 57.3-1 "NGpon2 Channel Group Member Association Command" Resource Parameters

Resource Identifier	Type	Description
(channel-group-id)	Format: <Ng2::ChannelGroup> Field type <Ng2::ChannelGroup> - channel group number	identification of the channel group index
(channel-pair)	Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::ChannelPairId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::ChannelPairId> - the channel pair identifier	channel-pair associated with this channel-group

57.4 NGpon2 Sub Channel Group Configuration Command

Command Description

This command configures a NGpon2 Sub Channel Group.

Note: The value of sig-degrade-th must be greater than sig-fail-th (i.e. sig-degrade-th must represent a lower BER value)

The value of closest-ont can be changed only after setting the administrative status to down.

The value of diff-reach can be changed only after setting the administrative status to down. When an ONT is located at a greater distance than is configured, its reply will be delayed and may disturb other PON traffic.

The value of fec-dn can be changed only after setting the administrative status to down. If the FEC change is made while the admin status is up, then it must be set to down and then put back to up for the change to take place.

The value of auth-method can be changed only after setting the administrative status to down.

User Level

The command can be accessed by operators with equipment privileges, and executed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

```
> configure channel-group id (channel-group-id) subchannel-group ( no id (subchannel-group) ) | ( id (subchannel-group) [ no name | name <Ng2::Label> ] [ no auth-method | auth-method <Ng2::SubChanAuthMethod> ] [ no mcast-encrypt | mcast-encrypt <Ng2::MCastEncryption> ] [ no fec-dn | fec-dn <Gpon::FecDn> ] [ no closest-ont | closest-ont <Ng2::OntDistance> ] [ no diff-reach | diff-reach <Ng2::PonDiffReach> ] [ no admin-state | admin-state <Gpon::ItfAdminStatus> ] [ no cpi | cpi <Ng2::SubchannelGroupCpi> ] )
```

Command Parameters

Table 57.4-1 "NGpon2 Sub Channel Group Configuration Command" Resource Parameters

Resource Identifier	Type	Description
(channel-group-id)	Format: <Ng2::ChannelGroup> Field type <Ng2::ChannelGroup> - channel group number	identification of the channel group index
(subchannel-group)	Format: - subchannel group number - range: [1...4]	identification of the subchannel group index

Table 57.4-2 "NGpon2 Sub Channel Group Configuration Command" Command Parameters

57 NGpon2 Channel Group/Sub Channel Group Configuration Commands

Parameter	Type	Description
[no] name	Parameter type: <Ng2::Label> Format: - a printable string - length: x<=50	<i>optional parameter with default value: ""</i> textual string that can be used to label this subchannel group
[no] auth-method	Parameter type: <Ng2::SubChanAuthMethod> Format: (sn-slid logical loidpre logical-std loidpre-std) Possible values: - sn-slid : Serial Number and SLID authentication - logical : logical authentication - loidpre : loid precedence mix authentication - logical-std : standard logical authentication - loidpre-std : standard loid precedence mix authentication	<i>optional parameter with default value: "sn-slid"</i> authentication method used for ONTs in this subchannel group
[no] mcast-encrypt	Parameter type: <Ng2::MCastEncryption> Format: (enable disable) Possible values: - enable : multicast encryption enabled - disable : multicast encryption disabled	<i>optional parameter with default value: "disable"</i> enable/disable downstream multicast GEM encryption mode
[no] fec-dn	Parameter type: <Gpon::FecDn> Format: (enable disable) Possible values: - enable : fec is enabled - disable : fec is disabled	<i>optional parameter with default value: "enable"</i> use of fec in downstream direction for all olt transmissions
[no] closest-ont	Parameter type: <Ng2::OntDistance> Format: - closest ont distance - unit: km - range: [0,20]	<i>optional parameter with default value: 0L</i> the distance of the closest ont on the pon
[no] diff-reach	Parameter type: <Ng2::PonDiffReach> Format: - pon differential reach - unit: km - range: [20,40]	<i>optional parameter with default value: 20L</i> the maximum differential logical reach on the PON
[no] admin-state	Parameter type: <Gpon::ItfAdminStatus> Format: (up down) Possible values: - up : set the admin-state to up - down : set the admin-state to down	<i>optional parameter with default value: "down"</i> <i>The parameter is not visible during creation.</i> administrative status of the subchannel group
[no] cpi	Parameter type: <Ng2::SubchannelGroupCpi> Format: - channel partition index - range: [0...15]	<i>optional parameter with default value: 0L</i> channel partition index of the subchannel group

Command Output

Table 57.4-3 "NGpon2 Sub Channel Group Configuration Command" Display parameters

Specific Information		
name	Type	Description
oper-state	Parameter type: <Itf::ifOperStatus> (up down testing unknown dormant no-value) Possible values: - up : up,traffic can pass - down : down,no traffic is passing - testing : testing,no traffic is passing - unknown : unknown - dormant : dormant,no traffic is passing - no-value : no entry in the table	operational state of the subchannel group <i>This element is always shown.</i>

57.5 NGpon2 Sub Channel Group Member Association Command

Command Description

This command associates a NGpon2 Channel Pair with a Sub Channel Group.

This will only be possible if the channel-pair has the same channel-speed as the rest of the members

User Level

The command can be accessed by operators with equipment privileges, and executed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

```
> configure channel-group id (channel-group-id) subchannel-group id (subchannel-group) ( no channel-pair (channel-pair) ) | ( channel-pair (channel-pair) )
```

Command Parameters

Table 57.5-1 "NGpon2 Sub Channel Group Member Association Command" Resource Parameters

Resource Identifier	Type	Description
(channel-group-id)	Format: <Ng2::ChannelGroup> Field type <Ng2::ChannelGroup> - channel group number	identification of the channel group index
(subchannel-group)	Format: - subchannel group number - range: [1...4]	identification of the subchannel group index
(channel-pair)	Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::ChannelPairId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::ChannelPairId> - the channel pair identifier	channel-pair associated with this subchannel-group

58- Pon Configuration Commands

58.1 Pon Configuration Command Tree	58-1648
58.2 Pon Configuration Command	58-1651
58.3 Pon Interface Configuration Command	58-1652
58.4 Pon GEM Port Performance Monitoring Configuration Command	58-1657
58.5 OLT-SIDE TC-layer Performance Monitoring Counter Thresholds Configuration Command for PON	58-1659
58.6 Multicast TC-layer Performance Monitoring Command for PON	58-1661
58.7 XGPON Physical-layer Performance Monitoring Command for PON	58-1663
58.8 XGPON Upstream FEC Performance Monitoring Command for PON	58-1665
58.9 XGPON TC-layer Performance Monitoring Command for PON	58-1667
58.10 OTDR enable Command for PON	58-1669
58.11 PON Utilization PM Configuration Command	58-1671
58.12 PON Utilization TCA Threshold Configuration Command	58-1673
58.13 Deactivate Ont threshold Configuration Commands	58-1679
58.14 Deactivate Ont threshold Configuration Commands	58-1681
58.15 Deactivate Ont threshold Configuration Commands	58-1683
58.16 Power Shedding Profile Configuration Command	58-1685
58.17 Voice ONT Secure URI profile Configuration command	58-1687
58.18 GPON Authentication Security Profile Configuration Command	58-1689
58.19 GPON URI Profile Configuration Command	58-1691

58.1 Pon Configuration Command Tree

Description

This chapter gives an overview of nodes that are handled by "Pon Configuration Commands".

Command Tree

```
----configure
----pon
  - [no] pwrbrst-mode
  - [no] range-mode
----interface
  - (pon-idx)
  - [no] label
  - [no] ber-calc-period
  - [no] polling-period
  - [no] sig-degrade-th
  - [no] sig-fail-th
  - [no] fec-dn
  - [no] raman-reduct
  - [no] closest-ont
  - [no] diff-reach
  - [no] pon-tag
  - [no] pon-id
  - [no] mcast-encrypt
  - [no] auth-method
  - [no] ponid-interval
  - [no] ponid-odn
  - [no] ponid-identifier
  - [no] max-ranging-onts
  - [no] tconts-per-frame
  - [no] admin-state
  - [no] pon-speed
  - [no] burst-overhead
  - [no] onu-prov-mode
----tc-layer
  - [no] pm-collect
----tc-layer-threshold
  - [no] error-frags-up
----mcast-tc-layer
  - [no] pm-collect
----phy-layer
  - [no] pm-collect
----fec-tc-layer
  - [no] pm-collect
----xg-tc-layer
  - [no] pm-collect
----otdr
  - [no] mode
----utilization
  - [no] pon-pmcollect
  - [no] ont-pmcollect
```

```

- [no] ontbulk-pmcollect
----threshold
  - [no] txmcutilhi
  - [no] txmcutilmd
  - [no] txmcutillo
  - [no] txtotutilhi
  - [no] txtotutilmd
  - [no] txtotutillo
  - [no] rxtotutilhi
  - [no] rxtotutilmd
  - [no] rxtotutillo
  - [no] dbacongperiodhi
  - [no] dbacongperiodmd
  - [no] dbacongperiodlo
  - [no] txucdropfrmhi
  - [no] txucdropfrmmd
  - [no] txucdropfrmlo
  - [no] txmcdropfrmhi
  - [no] txmcdropfrmmd
  - [no] txmcdropfrmlo
  - [no] txbcdropfrmhi
  - [no] txbcdropfrmmd
  - [no] txbcdropfrmlo
  - [no] rxtotdropfrmhi
  - [no] rxtotdropfrmmd
  - [no] rxtotdropfrmlo
  - [no] numtcint
  - [no] numtcintdba
  - [no] dbacongthresh
----deact-ont-tca
- [no] mode
- [no] monitor-interval
----threshold-percent
  - [no] high
  - [no] high-clr
  - [no] low
  - [no] low-clr
----threshold-number
  - [no] high
  - [no] high-clr
  - [no] low
  - [no] low-clr
----X [no] power-shed-prof
- (profile-idx)
- profile-name
- [no] restore-time
- [no] data-class-time
- [no] voice-class-time
- [no] video-class-time
- [no] dsl-class-time
- [no] ces-class-time
----[no] sec-uri-profile
- (index)
- name
- [no] auth-securi-prof
- uri-prof
----[no] auth-sec-prof
- (index)

```

58 Pon Configuration Commands

- name
- [no] validation-scheme
- [no] user-name
- [no] password
- [no] realm
- [no] uri-prof**
- **(index)**
- name
- [no] address
- [no] version

58.2 Pon Configuration Command

Command Description

This command allows the operator to configure range mode of all GPON interface.

User Level

The command can be accessed by operators with equipment privileges, and executed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

```
> configure pon [ no pwrbrst-mode | pwrbrst-mode <Gpon::PowerBurstMode> ] [ no range-mode | range-mode <Gpon::RangeMode> ]
```

Command Parameters

Table 58.2-2 "Pon Configuration Command" Command Parameters

Parameter	Type	Description
[no] pwrbrst-mode	Parameter type: <Gpon::PowerBurstMode> Format: (disable enable) Possible values: - disable : disable power burst detection mode - enable : enable power burst detection mode	<i>optional parameter with default value: "disable"</i> power burst detection mode for gpon
[no] range-mode	Parameter type: <Gpon::RangeMode> Format: (normal alientolerant) Possible values: - normal : use normal mode - alientolerant : use alien tolerant range mode which allows ONTs to range in the presence of Alien ONUs	<i>optional parameter with default value: "normal"</i> range mode for gpon

58.3 Pon Interface Configuration Command

Command Description

This command allows the operator to configure the provisioning data associated with a PON interface.

Note: The value of sig-degrade-th must be greater than sig-fail-th (i.e. sig-degrade-th must represent a lower BER value)

The value of closest-ont can be changed only after setting the administrative status to down.

The value of diff-reach can be changed only after setting the administrative status to down.

The value of fec-dn can be changed only after setting the administrative status to down. If the FEC change is made while the admin status is up, then it must be set to down and then put back to up for the change to take place.

The value of auth-method can be changed only after setting the administrative status to down.

User Level

The command can be accessed by operators with equipment privileges, and executed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

```
> configure pon interface (pon-idx) [ no label | label <Gpon::Label> ] [ no ber-calc-period | ber-calc-period
<Gpon::BerCalcPeriod> ] [ no polling-period | polling-period <Gpon::PollingPeriod> ] [ no sig-degrade-th |
sig-degrade-th <Gpon::SignalDegThreshold> ] [ no sig-fail-th | sig-fail-th <Gpon::SignalFailThreshold> ] [ no
fec-dn | fec-dn <Gpon::FecDn> ] [ no raman-reduct | raman-reduct <Gpon::RamanReduct> ] [ no closest-ont |
closest-ont <Gpon::OntDistance> ] [ no diff-reach | diff-reach <Gpon::PonDiffReach> ] [ no pon-tag | pon-tag
<Gpon::PonTag> ] [ no pon-id | pon-id <Gpon::PonXgId> ] [ no mcast-encrypt | mcast-encrypt
<Gpon::McEncrypt> ] [ no auth-method | auth-method <Gpon::AuthMethod> ] [ no ponid-interval | ponid-interval
<Gpon::GponIdInterval> ] [ no ponid-odn | ponid-odn <Gpon::GponIdOdn> ] [ no ponid-identifier |
ponid-identifier <Gpon::GponId> ] [ no max-ranging-onts | max-ranging-onts <Gpon::MaxRangingOnts> ] [ no
tconts-per-frame | tconts-per-frame <Gpon::TcontsPerFrame> ] [ no admin-state | admin-state
<Gpon::ItfAdminStatus> ] [ no pon-speed | pon-speed <Gpon::PonSpeed> ] [ no burst-overhead | burst-overhead
<Gpon::BurstModeOverhead> ] [ no onu-prov-mode | onu-prov-mode <Gpon::OnuProvMode> ]
```

Command Parameters

Table 58.3-1 "Pon Interface Configuration Command" Resource Parameters

Resource Identifier	Type	Description
(pon-idx)	Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> x-pon : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::XPonId> 25g-pon : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::M25GPonId>)	pon index

Resource Identifier	Type	Description
	Possible values: - 25g-pon : 25g pon - x-pon : Xgs pon Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Eqpt::XPonId> - the XGS PON identifier Field type <Eqpt::M25GPonId> - the 25G PON identifier	

Table 58.3-2 "Pon Interface Configuration Command" Command Parameters

Parameter	Type	Description
[no] label	Parameter type: <Gpon::Label> Format: - char string - length: x<=80	<i>optional parameter with default value: ""</i> label of the pon port
[no] ber-calc-period	Parameter type: <Gpon::BerCalcPeriod> Format: - ber measurement period - unit: 1/10 sec - range: [1...864000]	<i>optional parameter with default value: 10L</i> measurement period to determine whether a signal degraded alarm has occurred for an ont
[no] polling-period	Parameter type: <Gpon::PollingPeriod> Format: - polling period - unit: 1/10 sec - range: [1...864000]	<i>optional parameter with default value: 100L</i> period between two consecutive times the autodetection procedure on pon is executed
[no] sig-degrade-th	Parameter type: <Gpon::SignalDegThreshold> Format: - signal degrade threshold (x) - unit: 10 ^ (-x) - range: [4...10]	<i>optional parameter with default value: 9L</i> ber threshold used to detect signal degrade alarms for onts
[no] sig-fail-th	Parameter type: <Gpon::SignalFailThreshold> Format: - signal fail threshold (x) - unit: 10 ^ (-x) - range: [3...8]	<i>optional parameter with default value: 5L</i> ber threshold used to detect a signal fail alarms for onts
[no] fec-dn	Parameter type: <Gpon::FecDn> Format: (enable disable) Possible values: - enable : fec is enabled - disable : fec is disabled	<i>optional parameter with default value: "disable,ngpon : enable"</i> use of fec in downstream direction for all olt transmissions
[no] raman-reduct	Parameter type: <Gpon::RamanReduct> Format: (enable disable) Possible values: - enable : raman reduction code enabled - disable : raman reduction code disabled	<i>optional parameter with default value: "disable"</i> use of raman reduction code for overlay video in downstream direction
[no] closest-ont	Parameter type: <Gpon::OntDistance>	<i>optional parameter with default</i>

58 Pon Configuration Commands

Parameter	Type	Description
	Format: - closest ont distance(ngpon range is [0,20] unit: km) - unit: km - range: [0...40]	<i>value: 0L</i> the distance of the closest ont on the pon
[no] diff-reach	Parameter type: <Gpon::PonDiffReach> Format: - pon differential reach(ngpon range is [20,40] unit: km) - unit: km - range: [20,34,40]	<i>optional parameter with default value: 20L</i> the maximum differential logical reach on the PON
[no] pon-tag	Parameter type: <Gpon::PonTag> Format: - Pon Tag - 16 hex characters - length: x<=16	<i>optional parameter with default value: "0000000000000000"</i> label of the pon port
[no] pon-id	Parameter type: <Gpon::PonXgId> Format: - Pon Id - 8 hex characters - length: x<=8	<i>optional parameter with default value: "00000000"</i> label of the pon port
[no] mcast-encrypt	Parameter type: <Gpon::McEncrypt> Format: (enable disable) Possible values: - enable : mcast encryption is enabled - disable : mcast encryption is disabled	<i>optional parameter with default value: "disable"</i> Multicast encryption enable
[no] auth-method	Parameter type: <Gpon::AuthMethod> Format: (sn-slid logical loidpre logical-std loidpre-std loid-sn-slid) Possible values: - sn-slid : sn and slid authentication - logical : logical authentication - loidpre : loid precedence mix authentication - logical-std : standard logical authentication - loidpre-std : standard loid precedence mix authentication - loid-sn-slid : loid,sn and slid mixing authentication	<i>optional parameter with default value: "sn-slid"</i> ont authentication mode option for this pon interface level
[no] ponid-interval	Parameter type: <Gpon::GponIdInterval> Format: - interval time - unit: second - range: [0...60]	<i>optional parameter with default value: 0L</i> interval to send GPON-ID PLOAM message in second
[no] ponid-odn	Parameter type: <Gpon::GponIdOdn> Format: (a b bplus c cplus auto) Possible values: - a : ODN Level A - b : ODN Level B - bplus : ODN Level B+ - c : ODN Level C	<i>optional parameter with default value: "auto"</i> ODN class of the pon port

Parameter	Type	Description
	- cplus : ODN Level C+ - auto : Auto Detected	
[no] ponid-identifier	Parameter type: <Gpon::GponId> Format: - Pon Id - 14 hex characters - length: 14	<i>optional parameter with default value: "00000000000000"</i> label of the pon port
[no] max-ranging-onts	Parameter type: <Gpon::MaxRangingOnt> Format: - ranging onts number;if 0 indicates bandwidth calculated by provisioned onts; other value indicates pre-configured onts - range: [0...128]	<i>optional parameter with default value: 128L</i> max ranging ont number for guaranteed bandwidth cac
[no] tconts-per-frame	Parameter type: <Gpon::TcontsPerFrame> Format: - maximum number of tconts per upstream frame, to calculate guaranteed bandwidth(GPON range is [1...64], XGSPON and XGPON1 range[0...64]) - range: [0...64]	<i>optional parameter with default value: "64L,xgs : 44L,ngpon : 16L"</i> max service tcont number per gtc frame
[no] admin-state	Parameter type: <Gpon::ItfAdminStatus> Format: (up down) Possible values: - up : set the admin-state to up - down : set the admin-state to down	<i>optional parameter with default value: "down"</i> <i>The parameter is not visible during creation.</i> administrative status of the interface
[no] pon-speed	Parameter type: <Gpon::PonSpeed> Format: (nominal 10g-10g 10g-2.5g) Possible values: - nominal : nominal line rate of the pon technology : 2.5g down / 1.25g up for gpon; 10g down / dual-rate up for ngpon - 10g-10g : 10g down / 10g up - 10g-2.5g : 10g down / 2.5g up	<i>optional parameter with default value: "nominal"</i> pon speed
[no] burst-overhead	Parameter type: <Gpon::BurstModeOverhead> Format: (robust reduced) Possible values: - robust : robust - reduced : reduced	<i>optional parameter with default value: "robust"</i> burst mode overhead
[no] onu-prov-mode	Parameter type: <Gpon::OnuProvMode> Format: (semi-auto auto) Possible values: - semi-auto : ONU semi-auto provisioning. Template file needs to be specified in ONT config - auto : ONU auto provisioning. Template file selection done automatically based on ONT type	<i>optional parameter with default value: "semi-auto"</i> ONU auto provisioning mode

Command Output

Table 58.3-3 "Pon Interface Configuration Command" Display parameters

Specific Information

58 Pon Configuration Commands

name	Type	Description
oper-state	Parameter type: <Itf::ifOperStatus> (up down testing unknown dormant no-value) Possible values: - up : up,traffic can pass - down : down,no traffic is passing - testing : testing,no traffic is passing - unknown : unknown - dormant : dormant,no traffic is passing - no-value : no entry in the table	operational state of the interface <i>This element is always shown.</i>

58.4 Pon GEM Port Performance Monitoring Configuration Command

Command Description

This command allows the operator to set the PM mode of OLT side GEM based counters for errored fragments.

User Level

The command can be accessed by operators with equipment privileges, and executed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

```
> configure pon interface (pon-idx) tc-layer [ no pm-collect | pm-collect <Gpon::OntPmTcaCollect> ]
```

Command Parameters

Table 58.4-1 "Pon GEM Port Performance Monitoring Configuration Command" Resource Parameters

Resource Identifier	Type	Description
(pon-idx)	Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> x-pon : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::XPonId> 25g-pon : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::M25GPonId>) Possible values: - 25g-pon : 25g pon - x-pon : Xgs pon Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Eqpt::XPonId> - the XGS PON identifier Field type <Eqpt::M25GPonId> - the 25G PON identifier	pon index

Table 58.4-2 "Pon GEM Port Performance Monitoring Configuration Command" Command

Parameters

Parameter	Type	Description
[no] pm-collect	Parameter type: <Gpon::OntPmTcaCollect> Format: (none pm-enable tca-enable) Possible values: - none : no pm - pm-enable : enable pm - tca-enable : enable tca	<i>optional parameter with default value: "pm-enable"</i> olt-side aggregate TC Layer performance monitoring

58.5 OLT-SIDE TC-layer Performance Monitoring Counter Thresholds Configuration Command for PON

Command Description

This command allows the operator to enable configuration of performance Monitoring counter thresholds for OLT-Side TC-layer errored fragments.

User Level

The command can be accessed by operators with equipment privileges, and executed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

```
> configure pon interface (pon-idx) tc-layer-threshold [ no error-frags-up | error-frags-up
<Gpon::TcaThresholdValue> ]
```

Command Parameters

Table 58.5-1 "OLT-SIDE TC-layer Performance Monitoring Counter Thresholds Configuration Command for PON" Resource Parameters

Resource Identifier	Type	Description
(pon-idx)	Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> x-pon : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::XPonId> 25g-pon : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::M25GPonId>) Possible values: - 25g-pon : 25g pon - x-pon : Xgs pon Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Eqpt::XPonId>	pon index

58 Pon Configuration Commands

Resource Identifier	Type	Description
	- the XGS PON identifier - Field type <Eqpt::M25GPonId> - the 25G PON identifier	

Table 58.5-2 "OLT-SIDE TC-layer Performance Monitoring Counter Thresholds Configuration Command for PON" Command Parameters

Parameter	Type	Description
[no] error-frags-up	Parameter type: <Gpon::TcaThresholdValue> Format: (disabled <Gpon::TcaThresholdValue>) Possible values: - disabled : threshold is disabled Field type <Gpon::TcaThresholdValue> - tc-layer tca threshold value (4294967295=disabled) - range: [0...4294967294,4294967295]	<i>optional parameter with default value: "disabled"</i> tca setting for errored gem fragments

58.6 Multicast TC-layer Performance Monitoring Command for PON

Command Description

This command allows the operator to enable or disable the OLT-side Multicast Port Performance Monitor collection for the PON.

User Level

The command can be accessed by operators with equipment privileges, and executed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

```
> configure pon interface (pon-idx) mcast-tc-layer [ no pm-collect | pm-collect <Gpon::OntPmCollect> ]
```

Command Parameters

Table 58.6-1 "Multicast TC-layer Performance Monitoring Command for PON" Resource Parameters

Resource Identifier	Type	Description
(pon-idx)	Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> x-pon : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::XPonId> 25g-pon : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::M25GPonId>) Possible values: - 25g-pon : 25g pon - x-pon : Xgs pon Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Eqpt::XPonId> - the XGS PON identifier Field type <Eqpt::M25GPonId> - the 25G PON identifier	pon index

Table 58.6-2 "Multicast TC-layer Performance Monitoring Command for PON" Command Parameters

Parameter	Type	Description
[no] pm-collect	Parameter type: <Gpon::OntPmCollect> Format: (enable disable) Possible values: - enable : enable PM - disable : disable PM	<i>optional parameter with default value: "disable"</i> OLT-side multicast performance monitoring

Command Output

Table 58.6-3 "Multicast TC-layer Performance Monitoring Command for PON" Display parameters

Specific Information		
name	Type	Description
interval-no	Parameter type: <SignedInteger> - a signed integer	number of rows currently present in the gponMulticastServiceOltsideGemInterval <i>This element is always shown.</i>

58.7 XGPON Physical-layer Performance Monitoring Command for PON

Command Description

This command allows the operator to enable or disable the OLT-side XGPON Physical Performance Monitor collection for the PON.

User Level

The command can be accessed by operators with equipment privileges, and executed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

```
> configure pon interface (pon-idx) phy-layer [ no pm-collect | pm-collect <Gpon::PmEnable> ]
```

Command Parameters

Table 58.7-1 "XGPON Physical-layer Performance Monitoring Command for PON" Resource Parameters

Resource Identifier	Type	Description
(pon-idx)	Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> x-pon : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::XPonId> 25g-pon : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::M25GPonId>) Possible values: - 25g-pon : 25g pon - x-pon : Xgs pon Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Eqpt::XPonId> - the XGS PON identifier Field type <Eqpt::M25GPonId> - the 25G PON identifier	pon index

Table 58.7-2 "XGPON Physical-layer Performance Monitoring Command for PON" Command Parameters

Parameter	Type	Description
[no] pm-collect	Parameter type: <Gpon::PmEnable> Format: (disable enable) Possible values: - disable : disable the collection - enable : enable the collection	optional parameter with default value: "disable" OLT-side XGPON Physical performance monitoring

Command Output

Table 58.7-3 "XGPON Physical-layer Performance Monitoring Command for PON" Display parameters

Specific Information		
name	Type	Description
interval-no	Parameter type: <SignedInteger> - a signed integer	number of rows currently present in the gponMulticastServiceOltsideGemInterval This element is always shown.

58.8 XGPON Upstream FEC Performance Monitoring Command for PON

Command Description

This command allows the operator to enable or disable the OLT-side XGPON upstream FEC Performance Monitor collection for the PON.

User Level

The command can be accessed by operators with equipment privileges, and executed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

```
> configure pon interface (pon-idx) fec-tc-layer [ no pm-collect | pm-collect <Gpon::PmEnable> ]
```

Command Parameters

Table 58.8-1 "XGPON Upstream FEC Performance Monitoring Command for PON" Resource Parameters

Resource Identifier	Type	Description
(pon-idx)	Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> x-pon : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::XPonId> 25g-pon : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::M25GPonId>) Possible values: - 25g-pon : 25g pon - x-pon : Xgs pon Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Eqpt::XPonId> - the XGS PON identifier Field type <Eqpt::M25GPonId> - the 25G PON identifier	pon index

Table 58.8-2 "XGPON Upstream FEC Performance Monitoring Command for PON" Command Parameters

Parameter	Type	Description
[no] pm-collect	Parameter type: <Gpon::PmEnable> Format: (disable enable) Possible values: - disable : disable the collection - enable : enable the collection	<i>optional parameter with default value: "disable"</i> OLT-side upstream FEC performance monitoring

Command Output

Table 58.8-3 "XGPON Upstream FEC Performance Monitoring Command for PON" Display parameters

Specific Information		
name	Type	Description
interval-no	Parameter type: <SignedInteger> - a signed integer	number of rows currently present in the gponMulticastServiceOltsideGemInterval <i>This element is always shown.</i>

58.9 XGPON TC-layer Performance Monitoring

Command for PON

Command Description

This command allows the operator to enable or disable the OLT-side XGPON TC-layer Performance Monitor collection for the PON.

User Level

The command can be accessed by operators with equipment privileges, and executed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

```
> configure pon interface (pon-idx) xg-tc-layer [ no pm-collect | pm-collect <Gpon::PmEnable> ]
```

Command Parameters

Table 58.9-1 "XGPON TC-layer Performance Monitoring Command for PON" Resource Parameters

Resource Identifier	Type	Description
(pon-idx)	Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> x-pon : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::XPonId> 25g-pon : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::M25GPonId>) Possible values: - 25g-pon : 25g pon - x-pon : Xgs pon Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Eqpt::XPonId> - the XGS PON identifier Field type <Eqpt::M25GPonId> - the 25G PON identifier	pon index

Table 58.9-2 "XGPON TC-layer Performance Monitoring Command for PON" Command Parameters

Parameter	Type	Description
[no] pm-collect	Parameter type: <Gpon::PmEnable> Format: (disable enable) Possible values: - disable : disable the collection - enable : enable the collection	<i>optional parameter with default value: "disable"</i> OLT-side tc-layer performance monitoring

Command Output

Table 58.9-3 "XGPON TC-layer Performance Monitoring Command for PON" Display parameters

Specific Information		
name	Type	Description
interval-no	Parameter type: <SignedInteger> - a signed integer	number of rows currently present in the gponMulticastServiceOltsideGemInterval <i>This element is always shown.</i>

58.10 OTDR enable Command for PON

Command Description

This command allows the operator to enable or disable the otdr functionality on the given pon.

Besides the enable and disable option, a third option "test" is possible. This option is only to be used in lab conditions to immediately collect the otdr measurement data and as a result generate load on the i2c bus.

User Level

The command can be accessed by operators with equipment privileges, and executed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

```
> configure pon interface (pon-idx) otdr [ no mode | mode <Gpon::OTDRenable> ]
```

Command Parameters

Table 58.10-1 "OTDR enable Command for PON" Resource Parameters

Resource Identifier	Type	Description
(pon-idx)	Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> x-pon : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::XPonId> 25g-pon : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::M25GPonId>) Possible values: - 25g-pon : 25g pon - x-pon : Xgs pon Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Eqpt::XPonId> - the XGS PON identifier Field type <Eqpt::M25GPonId> - the 25G PON identifier	pon index

Table 58.10-2 "OTDR enable Command for PON" Command Parameters

58 Pon Configuration Commands

Parameter	Type	Description
[no] mode	Parameter type: <Gpon::OTDRenable> Format: (enable disable test) Possible values: - enable : otdr enable - disable : otdr disable - test : otdr test : only to be used in lab conditions	<i>optional parameter with default value: "disable"</i> enable otdr

58.11 PON Utilization PM Configuration Command

Command Description

This command configures the PON and ONT utilization performance monitoring modes for a PON.

User Level

The command can be accessed by operators with equipment privileges, and executed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

```
> configure pon interface (pon-idx) utilization [ no pon-pmcollect | pon-pmcollect <Gpon::PonUtilPmTcaCollect> ]
[ no ont-pmcollect | ont-pmcollect <Gpon::PonUtilOntPmCollect> ] [ no ontbulk-pmcollect | ontbulk-pmcollect
<Gpon::OntPmCollect> ]
```

Command Parameters

Table 58.11-1 "PON Utilization PM Configuration Command" Resource Parameters

Resource Identifier	Type	Description
(pon-idx)	Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> x-pon : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::XPonId> 25g-pon : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::M25GPonId>) Possible values: - 25g-pon : 25g pon - x-pon : Xgs pon Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Eqpt::XPonId> - the XGS PON identifier Field type <Eqpt::M25GPonId> - the 25G PON identifier	pon index

Table 58.11-2 "PON Utilization PM Configuration Command" Command Parameters

Parameter	Type	Description
[no] pon-pmcollect	Parameter type: <Gpon::PonUtilPmTcaCollect>	optional parameter with default

58 Pon Configuration Commands

Parameter	Type	Description
	Format: (none pm-enable tca-enable inherit) Possible values: - none : no pm - pm-enable : enable pm - tca-enable : enable tca - inherit : inherit from generic-pon (system-wide) pon-pmcollect and threshold values	<i>value: "inherit"</i> pon utilization performance monitoring
[no] ont-pmcollect	Parameter type: <Gpon::PonUtilOntPmCollect> Format: (enable disable inherit) Possible values: - enable : enable PM - disable : disable PM - inherit : inherit from generic-pon (system-wide) ont-pmcollect value	<i>optional parameter with default value: "inherit"</i> pon utilization ont detailed performance monitoring
[no] ontbulk-pmcollect	Parameter type: <Gpon::OntPmCollect> Format: (enable disable) Possible values: - enable : enable PM - disable : disable PM	<i>optional parameter with default value: "disable"</i> pon utilization ont pm bulk collectable via BFMU

58.12 PON Utilization TCA Threshold Configuration Command

Command Description

This command configures the utilization TCA threshold parameters for a PON.

User Level

The command can be accessed by operators with equipment privileges, and executed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

```
> configure pon interface (pon-idx) utilization threshold [ no txmcutilhi | txmcutilhi
<Gpon::PonUtilTcaThresholdPercent> ] [ no txmcutilmd | txmcutilmd <Gpon::PonUtilTcaThresholdPercent> ] [ no
txmcutillo | txmcutillo <Gpon::PonUtilTcaThresholdPercent> ] [ no txtotutilhi | txtotutilhi
<Gpon::PonUtilTcaThresholdPercent> ] [ no txtotutilmd | txtotutilmd <Gpon::PonUtilTcaThresholdPercent> ] [ no
txtotutillo | txtotutillo <Gpon::PonUtilTcaThresholdPercent> ] [ no rxtotutilhi | rxtotutilhi
<Gpon::PonUtilTcaThresholdPercent> ] [ no rxtotutilmd | rxtotutilmd <Gpon::PonUtilTcaThresholdPercent> ] [ no
rxtotutillo | rxtotutillo <Gpon::PonUtilTcaThresholdPercent> ] [ no dbacongperiodhi | dbacongperiodhi
<Gpon::PonUtilTcaThresholdPercent> ] [ no dbacongperiodmd | dbacongperiodmd
<Gpon::PonUtilTcaThresholdPercent> ] [ no dbacongperiodlo | dbacongperiodlo
<Gpon::PonUtilTcaThresholdPercent> ] [ no txucdropfrmhi | txucdropfrmhi
<Gpon::PonUtilTcaDroppedPacketsThreshold> ] [ no txucdropfrmmd | txucdropfrmmd
<Gpon::PonUtilTcaDroppedPacketsThreshold> ] [ no txucdropfrmlo | txucdropfrmlo
<Gpon::PonUtilTcaDroppedPacketsThreshold> ] [ no txmcdropfrmhi | txmcdropfrmhi
<Gpon::PonUtilTcaDroppedPacketsThreshold> ] [ no txmcdropfrmmd | txmcdropfrmmd
<Gpon::PonUtilTcaDroppedPacketsThreshold> ] [ no txmcdropfrmlo | txmcdropfrmlo
<Gpon::PonUtilTcaDroppedPacketsThreshold> ] [ no txbcdropfrmhi | txbcdropfrmhi
<Gpon::PonUtilTcaDroppedPacketsThreshold> ] [ no txbcdropfrmmd | txbcdropfrmmd
<Gpon::PonUtilTcaDroppedPacketsThreshold> ] [ no txbcdropfrmlo | txbcdropfrmlo
<Gpon::PonUtilTcaDroppedPacketsThreshold> ] [ no rxtotdropfrmhi | rxtotdropfrmhi
<Gpon::PonUtilTcaDroppedPacketsThreshold> ] [ no rxtotdropfrmmd | rxtotdropfrmmd
<Gpon::PonUtilTcaDroppedPacketsThreshold> ] [ no rxtotdropfrmlo | rxtotdropfrmlo
<Gpon::PonUtilTcaDroppedPacketsThreshold> ] [ no numtcint | numtcint <Gpon::PonUtilTcaInterval> ] [ no
numtcintdba | numtcintdba <Gpon::PonUtilTcaInterval> ] [ no dbacongthresh | dbacongthresh
<Gpon::PonUtilTcaCongThreshold> ]
```

Command Parameters

Table 58.12-1 "PON Utilization TCA Threshold Configuration Command" Resource Parameters

Resource Identifier	Type	Description
(pon-idx)	Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> /	pon index

Resource Identifier	Type	Description
	<Eqpt::PonId> x-pon : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::XPonId> 25g-pon : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::M25GPonId>) Possible values: - 25g-pon : 25g pon - x-pon : Xgs pon Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Eqpt::XPonId> - the XGS PON identifier Field type <Eqpt::M25GPonId> - the 25G PON identifier	

Table 58.12-2 "PON Utilization TCA Threshold Configuration Command" Command Parameters

Parameter	Type	Description
[no] txmcutilhi	Parameter type: <Gpon::PonUtilTcaThresholdPercent> Format: (disabled <Gpon::PonUtilTcaThresholdPercent>) Possible values: - disabled : threshold is disabled Field type <Gpon::PonUtilTcaThresholdPercent> - utilization percentage threshold - range: [0...100]	optional parameter with default value: "disabled" Utilization level (percentage) that will result in declaration of T-TXMCUTILHI alarm
[no] txmcutilmd	Parameter type: <Gpon::PonUtilTcaThresholdPercent> Format: (disabled <Gpon::PonUtilTcaThresholdPercent>) Possible values: - disabled : threshold is disabled Field type <Gpon::PonUtilTcaThresholdPercent> - utilization percentage threshold - range: [0...100]	optional parameter with default value: "disabled" Utilization level (percentage) that will result in declaration of T-TXMCUTILMD alarm
[no] txmcutillo	Parameter type: <Gpon::PonUtilTcaThresholdPercent> Format: (disabled <Gpon::PonUtilTcaThresholdPercent>) Possible values: - disabled : threshold is disabled Field type <Gpon::PonUtilTcaThresholdPercent> - utilization percentage threshold - range: [0...100]	optional parameter with default value: "disabled" Utilization level (percentage) that will result in declaration of T-TXMCUTILLO alarm
[no] txtotutilhi	Parameter type: <Gpon::PonUtilTcaThresholdPercent> Format: (disabled <Gpon::PonUtilTcaThresholdPercent>) Possible values: - disabled : threshold is disabled Field type <Gpon::PonUtilTcaThresholdPercent>	optional parameter with default value: "disabled" Utilization level (percentage) that will result in declaration of T-TXTOTUTILHI alarm

Parameter	Type	Description
	- utilization percentage threshold - range: [0...100]	
[no] txtotutilmd	Parameter type: <Gpon::PonUtilTcaThresholdPercent> Format: (disabled <Gpon::PonUtilTcaThresholdPercent>) Possible values: - disabled : threshold is disabled Field type <Gpon::PonUtilTcaThresholdPercent> - utilization percentage threshold - range: [0...100]	<i>optional parameter with default value: "disabled"</i> Utilization level (percentage) that will result in declaration of T-TXTOTUTILMD alarm
[no] txtotutillo	Parameter type: <Gpon::PonUtilTcaThresholdPercent> Format: (disabled <Gpon::PonUtilTcaThresholdPercent>) Possible values: - disabled : threshold is disabled Field type <Gpon::PonUtilTcaThresholdPercent> - utilization percentage threshold - range: [0...100]	<i>optional parameter with default value: "disabled"</i> Utilization level (percentage) that will result in declaration of T-TXTOTUTILLO alarm
[no] rxtotutilhi	Parameter type: <Gpon::PonUtilTcaThresholdPercent> Format: (disabled <Gpon::PonUtilTcaThresholdPercent>) Possible values: - disabled : threshold is disabled Field type <Gpon::PonUtilTcaThresholdPercent> - utilization percentage threshold - range: [0...100]	<i>optional parameter with default value: "disabled"</i> Utilization level (percentage) that will result in declaration of T-RXTOTUTILHI alarm
[no] rxtotutilmd	Parameter type: <Gpon::PonUtilTcaThresholdPercent> Format: (disabled <Gpon::PonUtilTcaThresholdPercent>) Possible values: - disabled : threshold is disabled Field type <Gpon::PonUtilTcaThresholdPercent> - utilization percentage threshold - range: [0...100]	<i>optional parameter with default value: "disabled"</i> Utilization level (percentage) that will result in declaration of T-RXTOTUTILMD alarm
[no] rxtotutillo	Parameter type: <Gpon::PonUtilTcaThresholdPercent> Format: (disabled <Gpon::PonUtilTcaThresholdPercent>) Possible values: - disabled : threshold is disabled Field type <Gpon::PonUtilTcaThresholdPercent> - utilization percentage threshold - range: [0...100]	<i>optional parameter with default value: "disabled"</i> Utilization level (percentage) that will result in declaration of T-RXTOTUTILLO alarm
[no] dbacongperiodhi	Parameter type: <Gpon::PonUtilTcaThresholdPercent> Format: (disabled <Gpon::PonUtilTcaThresholdPercent>) Possible values: - disabled : threshold is disabled Field type <Gpon::PonUtilTcaThresholdPercent> - utilization percentage threshold - range: [0...100]	<i>optional parameter with default value: "disabled"</i> Utilization level (percentage) that will result in declaration of T-DBACONGPERIODHI alarm
[no] dbacongperiodmd	Parameter type: <Gpon::PonUtilTcaThresholdPercent>	<i>optional parameter with default</i>

58 Pon Configuration Commands

Parameter	Type	Description
	Format: (disabled <Gpon::PonUtilTcaThresholdPercent>) Possible values: - disabled : threshold is disabled Field type <Gpon::PonUtilTcaThresholdPercent> - utilization percentage threshold - range: [0...100]	<i>value: "disabled"</i> Utilization level (percentage) that will result in declaration of T-DBACONGPERIODMD alarm
[no] dbacongperiodlo	Parameter type: <Gpon::PonUtilTcaThresholdPercent> Format: (disabled <Gpon::PonUtilTcaThresholdPercent>) Possible values: - disabled : threshold is disabled Field type <Gpon::PonUtilTcaThresholdPercent> - utilization percentage threshold - range: [0...100]	<i>optional parameter with default value: "disabled"</i> Utilization level (percentage) that will result in declaration of T-DBACONGPERIODLO alarm
[no] txucdropfrmhi	Parameter <Gpon::PonUtilTcaDroppedPacketsThreshold> Format: (disabled <Gpon::PonUtilTcaDroppedPacketsThreshold>) Possible values: - disabled : threshold is disabled Field type <Gpon::PonUtilTcaDroppedPacketsThreshold> - dropped frames threshold - range: [0...1000000000]	<i>optional parameter with default value: "disabled"</i> Number of dropped frames that will result in declaration of T-TXUCDROPPFRMHI alarm
[no] txucdropfrmmmd	Parameter <Gpon::PonUtilTcaDroppedPacketsThreshold> Format: (disabled <Gpon::PonUtilTcaDroppedPacketsThreshold>) Possible values: - disabled : threshold is disabled Field type <Gpon::PonUtilTcaDroppedPacketsThreshold> - dropped frames threshold - range: [0...1000000000]	<i>optional parameter with default value: "disabled"</i> Number of dropped frames that will result in declaration of T-TXUCDROPPFRMMD alarm
[no] txucdropfrmlo	Parameter <Gpon::PonUtilTcaDroppedPacketsThreshold> Format: (disabled <Gpon::PonUtilTcaDroppedPacketsThreshold>) Possible values: - disabled : threshold is disabled Field type <Gpon::PonUtilTcaDroppedPacketsThreshold> - dropped frames threshold - range: [0...1000000000]	<i>optional parameter with default value: "disabled"</i> Number of dropped frames that will result in declaration of T-TXUCDROPPFRMLO alarm
[no] txmcdropfrmhi	Parameter <Gpon::PonUtilTcaDroppedPacketsThreshold> Format: (disabled <Gpon::PonUtilTcaDroppedPacketsThreshold>) Possible values: - disabled : threshold is disabled Field type <Gpon::PonUtilTcaDroppedPacketsThreshold> - dropped frames threshold - range: [0...1000000000]	<i>optional parameter with default value: "disabled"</i> Number of dropped frames that will result in declaration of T-TXMCDROPPFRMHI alarm

Parameter	Type	Description
[no] txmcdropfrmmd	Parameter <Gpon::PonUtilTcaDroppedPacketsThreshold> Format: (disabled <Gpon::PonUtilTcaDroppedPacketsThreshold>) Possible values: - disabled : threshold is disabled Field type <Gpon::PonUtilTcaDroppedPacketsThreshold> - dropped frames threshold - range: [0...1000000000]	optional parameter with default value: "disabled" Number of dropped frames that will result in declaration of T-TXMCDROPFRMMD alarm
[no] txmcdropfrmlo	Parameter <Gpon::PonUtilTcaDroppedPacketsThreshold> Format: (disabled <Gpon::PonUtilTcaDroppedPacketsThreshold>) Possible values: - disabled : threshold is disabled Field type <Gpon::PonUtilTcaDroppedPacketsThreshold> - dropped frames threshold - range: [0...1000000000]	optional parameter with default value: "disabled" Number of dropped frames that will result in declaration of T-TXMCDROPFRMLO alarm
[no] txbcdropfrmhi	Parameter <Gpon::PonUtilTcaDroppedPacketsThreshold> Format: (disabled <Gpon::PonUtilTcaDroppedPacketsThreshold>) Possible values: - disabled : threshold is disabled Field type <Gpon::PonUtilTcaDroppedPacketsThreshold> - dropped frames threshold - range: [0...1000000000]	optional parameter with default value: "disabled" Number of dropped frames that will result in declaration of T-TXBCDROPFRMHI alarm
[no] txbcdropfrmmd	Parameter <Gpon::PonUtilTcaDroppedPacketsThreshold> Format: (disabled <Gpon::PonUtilTcaDroppedPacketsThreshold>) Possible values: - disabled : threshold is disabled Field type <Gpon::PonUtilTcaDroppedPacketsThreshold> - dropped frames threshold - range: [0...1000000000]	optional parameter with default value: "disabled" Number of dropped frames that will result in declaration of T-TXBCDROPFRMMD alarm
[no] txbcdropfrmlo	Parameter <Gpon::PonUtilTcaDroppedPacketsThreshold> Format: (disabled <Gpon::PonUtilTcaDroppedPacketsThreshold>) Possible values: - disabled : threshold is disabled Field type <Gpon::PonUtilTcaDroppedPacketsThreshold> - dropped frames threshold - range: [0...1000000000]	optional parameter with default value: "disabled" Number of dropped frames that will result in declaration of T-TXBCDROPFRMLO alarm
[no] rxtotdropfrmhi	Parameter <Gpon::PonUtilTcaDroppedPacketsThreshold> Format: (disabled <Gpon::PonUtilTcaDroppedPacketsThreshold>) Possible values: - disabled : threshold is disabled	optional parameter with default value: "disabled" Dropped frames that will result in declaration of T-RXTOTCDROPFRMHI alarm

58 Pon Configuration Commands

Parameter	Type	Description
	Field type <Gpon::PonUtilTcaDroppedPacketsThreshold> - dropped frames threshold - range: [0...1000000000]	
[no] rxtotdropfrmmmd	Parameter type: <Gpon::PonUtilTcaDroppedPacketsThreshold> Format: (disabled <Gpon::PonUtilTcaDroppedPacketsThreshold>) Possible values: - disabled : threshold is disabled Field type <Gpon::PonUtilTcaDroppedPacketsThreshold> - dropped frames threshold - range: [0...1000000000]	<i>optional parameter with default value: "disabled"</i> Number of dropped frames that will result in declaration of T-RXTOTDROPPFRMMD alarm
[no] rxtotdropfrmlo	Parameter type: <Gpon::PonUtilTcaDroppedPacketsThreshold> Format: (disabled <Gpon::PonUtilTcaDroppedPacketsThreshold>) Possible values: - disabled : threshold is disabled Field type <Gpon::PonUtilTcaDroppedPacketsThreshold> - dropped frames threshold - range: [0...1000000000]	<i>optional parameter with default value: "disabled"</i> Number of dropped frames that will result in declaration of T-RXTOTCDROPPFRMLO alarm
[no] numtcint	Parameter type: <Gpon::PonUtilTcaInterval> Format: (1 <Gpon::PonUtilTcaInterval>) Possible values: - 1 : Initial Default Field type <Gpon::PonUtilTcaInterval> - interval threshold - range: [1...96]	<i>optional parameter with default value: "1"</i> Number of contiguous 5-minute intervals for the non-DBA PON utilization thresholds to be exceeded for TCA alarm generation or clearing
[no] numtcintdba	Parameter type: <Gpon::PonUtilTcaInterval> Format: (1 <Gpon::PonUtilTcaInterval>) Possible values: - 1 : Initial Default Field type <Gpon::PonUtilTcaInterval> - interval threshold - range: [1...96]	<i>optional parameter with default value: "1"</i> Number of contiguous 5-minute intervals for the DBA PON congestion thresholds to be exceeded for TCA alarm generation or clearing
[no] dbacongthresh	Parameter type: <Gpon::PonUtilTcaCongThreshold> Format: (90 <Gpon::PonUtilTcaCongThreshold>) Possible values: - 90 : Initial Default Field type <Gpon::PonUtilTcaCongThreshold> - dba congestion percentage threshold - range: [0...100]	<i>optional parameter with default value: "90"</i> Configured DBA congestion threshold as a percentage of the maximum consumable bandwidth

58.13 Deactivate Ont threshold Configuration Commands

Command Description

This command allows the operator to configure deactivate ont threshold.

User Level

The command can be accessed by operators with equipment privileges, and executed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

```
> configure pon interface (pon-idx) deact-ont-tca [ no mode | mode <Gpon::DeactOnuTcaMode> ] [ no
monitor-interval | monitor-interval <Gpon::DeactOnuInterval> ]
```

Command Parameters

Table 58.13-1 "Deactivate Ont threshold Configuration Commands" Resource Parameters

Resource Identifier	Type	Description
(pon-idx)	Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> x-pon : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::XPonId> 25g-pon : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::M25GPonId>) Possible values: - 25g-pon : 25g pon - x-pon : Xgs pon Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Eqpt::XPonId> - the XGS PON identifier Field type <Eqpt::M25GPonId> - the 25G PON identifier	pon index

Table 58.13-2 "Deactivate Ont threshold Configuration Commands" Command Parameters

58 Pon Configuration Commands

Parameter	Type	Description
[no] mode	Parameter type: <Gpon::DeactOnuTcaMode> Format: (disable percent number) Possible values: - disable : disable mode - percent : percentage mode - number : number mode	<i>optional parameter with default value: "disable"</i> Used to specify PON or Channel-Pair deactivated ONT detection mode.
[no] monitor-interval	Parameter type: <Gpon::DeactOnuInterval> Format: - tca interval - unit: second - range: [5...300]	<i>optional parameter with default value: 30L</i> Used to specify PON or Channel-Pair deactivated ONT detection interval.

58.14 Deactivate Ont threshold Configuration Commands

Command Description

This command allows the operator to configure deactivate ont threshold.

User Level

The command can be accessed by operators with equipment privileges, and executed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

```
> configure pon interface (pon-idx) deact-ont-tca threshold-percent [ no high | high <Gpon::DeactOnuTcaPctHigh>
] [ no high-clr | high-clr <Gpon::DeactOnuTcaPctHigh> ] [ no low | low <Gpon::DeactOnuTcaPctLow> ] [ no
low-clr | low-clr <Gpon::DeactOnuTcaPctLow> ]
```

Command Parameters

Table 58.14-1 "Deactivate Ont threshold Configuration Commands" Resource Parameters

Resource Identifier	Type	Description
(pon-idx)	Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> x-pon : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::XPonId> 25g-pon : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::M25GPonId>) Possible values: - 25g-pon : 25g pon - x-pon : Xgs pon Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Eqpt::XPonId> - the XGS PON identifier Field type <Eqpt::M25GPonId> - the 25G PON identifier	pon index

Table 58.14-2 "Deactivate Ont threshold Configuration Commands" Command Parameters

Parameter	Type	Description
[no] high	Parameter type: <Gpon::DeactOnuTcaPctHigh> Format: - tca threshold in percent - range: [1...100]	<i>optional parameter with default value: 90L</i> Used to specify PON or Channel-Pair deactivated ONT detection high threshold in percent.
[no] high-clr	Parameter type: <Gpon::DeactOnuTcaPctHigh> Format: - tca threshold in percent - range: [1...100]	<i>optional parameter with default value: 90L</i> Used to specify PON or Channel-Pair deactivated ONT detection high clear threshold in percent.
[no] low	Parameter type: <Gpon::DeactOnuTcaPctLow> Format: - tca threshold in percent - range: [1...100]	<i>optional parameter with default value: 40L</i> Used to specify PON or Channel-Pair deactivated ONT detection low threshold in percent.
[no] low-clr	Parameter type: <Gpon::DeactOnuTcaPctLow> Format: - tca threshold in percent - range: [1...100]	<i>optional parameter with default value: 40L</i> Used to specify PON or Channel-Pair deactivated ONT detection low clear threshold in percent.

58.15 Deactivate Ont threshold Configuration Commands

Command Description

This command allows the operator to configure deactivate ont threshold.

User Level

The command can be accessed by operators with equipment privileges, and executed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

```
> configure pon interface (pon-idx) deact-ont-tca threshold-number [ no high | high
<Gpon::DeactOnuTcaNbrHigh> ] [ no high-clr | high-clr <Gpon::DeactOnuTcaNbrHigh> ] [ no low | low
<Gpon::DeactOnuTcaNbrLow> ] [ no low-clr | low-clr <Gpon::DeactOnuTcaNbrLow> ]
```

Command Parameters

Table 58.15-1 "Deactivate Ont threshold Configuration Commands" Resource Parameters

Resource Identifier	Type	Description
(pon-idx)	Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> x-pon : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::XPonId> 25g-pon : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::M25GPonId>) Possible values: - 25g-pon : 25g pon - x-pon : Xgs pon Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Eqpt::XPonId> - the XGS PON identifier Field type <Eqpt::M25GPonId> - the 25G PON identifier	pon index

Table 58.15-2 "Deactivate Ont threshold Configuration Commands" Command Parameters

Parameter	Type	Description
[no] high	Parameter type: <Gpon::DeactOnuTcaNbrHigh> Format: - tca threshold in number - range: [1...128]	<i>optional parameter with default value: 57L</i> Used to specify PON or Channel-Pair deactivated ONT detection high threshold in number.
[no] high-clr	Parameter type: <Gpon::DeactOnuTcaNbrHigh> Format: - tca threshold in number - range: [1...128]	<i>optional parameter with default value: 57L</i> Used to specify PON or Channel-Pair deactivated ONT detection high clear threshold in number.
[no] low	Parameter type: <Gpon::DeactOnuTcaNbrLow> Format: - tca threshold in number - range: [1...128]	<i>optional parameter with default value: 25L</i> Used to specify PON or Channel-Pair deactivated ONT detection low threshold in number.
[no] low-clr	Parameter type: <Gpon::DeactOnuTcaNbrLow> Format: - tca threshold in number - range: [1...128]	<i>optional parameter with default value: 25L</i> Used to specify PON or Channel-Pair deactivated ONT detection low clear threshold in number.

58.16 Power Shedding Profile Configuration Command

Command Description

Obsolete command, replaced by configure generic-pon power-shed-prof.

This command allows the operator to configure the Power Shedding Profiles.

User Level

The command can be accessed by operators with equipment privileges, and executed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

```
> configure pon ( no power-shed-prof (profile-idx) ) | ( power-shed-prof (profile-idx) profile-name
<AsamProfileName> [ no restore-time | restore-time <Gpon::RestoreTime> ] [ no data-class-time | data-class-time
<Gpon::DataClassTime> ] [ no voice-class-time | voice-class-time <Gpon::VoiceClassTime> ] [ no
video-class-time | video-class-time <Gpon::VideoClassTime> ] [ no dsl-class-time | dsl-class-time
<Gpon::DslClassTime> ] [ no ces-class-time | ces-class-time <Gpon::CesClassTime> ] )
```

Obsolete command, replaced by configure generic-pon power-shed-prof.

Command Parameters

Table 58.16-1 "Power Shedding Profile Configuration Command" Resource Parameters

Resource Identifier	Type	Description
(profile-idx)	Format: - profile index - range: [1...50]	profile index

Table 58.16-2 "Power Shedding Profile Configuration Command" Command Parameters

Parameter	Type	Description
profile-name	Parameter type: <AsamProfileName> Format: - a profile name - range: [a-zA-Z0-9-_.] - length: 1<=x<=32	<i>mandatory parameter</i> <i>The parameter is not visible during modification.</i> name of the profile
[no] restore-time	Parameter type: <Gpon::RestoreTime> Format: - zero means no-shed, and one means immediate-shed - unit: secs - range: [0...28800]	<i>optional parameter with default value: 0L</i> <i>The parameter is not visible during modification.</i> time delay required before resetting timers to zero after a full power restore

Parameter	Type	Description
[no] data-class-time	Parameter type: <Gpon::DataClassTime> Format: - zero means no-shed, and one means immediate-shed - unit: secs - range: [0...28800]	<i>optional parameter with default value: 0L</i> <i>The parameter is not visible during modification.</i> time delay required before shedding power for data uni classes.
[no] voice-class-time	Parameter type: <Gpon::VoiceClassTime> Format: - zero means no-shed, and one means immediate-shed - unit: secs - range: [0...28800]	<i>optional parameter with default value: 0L</i> <i>The parameter is not visible during modification.</i> the time delay required before shedding power for voice uni classes.
[no] video-class-time	Parameter type: <Gpon::VideoClassTime> Format: - zero means no-shed, and one means immediate-shed - unit: secs - range: [0...28800]	<i>optional parameter with default value: 0L</i> <i>The parameter is not visible during modification.</i> the time delay required before shedding power for the video ani class.
[no] dsl-class-time	Parameter type: <Gpon::DslClassTime> Format: - zero means no-shed, and one means immediate-shed - unit: secs - range: [0...28800]	<i>optional parameter with default value: 0L</i> <i>The parameter is not visible during modification.</i> the time delay required before shedding power for dsl uni classes.
[no] ces-class-time	Parameter type: <Gpon::CesClassTime> Format: - zero means no-shed, and one means immediate-shed - unit: secs - range: [0...28800]	<i>optional parameter with default value: 0L</i> <i>The parameter is not visible during modification.</i> the time delay required before shedding power for ces uni classes.

Command Output

Table 58.16-3 "Power Shedding Profile Configuration Command" Display parameters

Specific Information		
name	Type	Description
scope	Parameter type: <Gpon::Scope> (local network) Possible values: - local : local scope - network : network wide scope	scope of the profile <i>This element is always shown.</i>

58.17 Voice ONT Secure URI profile Configuration command

Command Description

This command creates a Secure URI Profile.

It provides (via pointers to other profiles) both the URI for accessing information plus the security information necessary to access the information

User Level

The command can be accessed by operators with equipment privileges, and executed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

```
> configure pon ( no sec-uri-profile (index) ) | ( sec-uri-profile (index) name <AsamProfileName> [ no
auth-securi-prof | auth-securi-prof <Gpon::AuthProfileName> ] uri-prof <Gpon::UriProfileName> )
```

Command Parameters

Table 58.17-1 "Voice ONT Secure URI profile Configuration command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - profile index - range: [1...50]	a unique profile index

Table 58.17-2 "Voice ONT Secure URI profile Configuration command" Command Parameters

Parameter	Type	Description
name	Parameter type: <AsamProfileName> Format: - a profile name - range: [a-zA-Z0-9-_.] - length: 1<=x<=32	<i>mandatory parameter</i> <i>The parameter is not visible during modification.</i> A string 1..32 characters long which uniquely identifies this Secure URI Profile
[no] auth-securi-prof	Parameter type: <Gpon::AuthProfileName> Format: (none <Gpon:AuthProfPtr> name : <AsamProfileName>) Possible values: - none : no profile to associate - name : profile name Field type <Gpon:AuthProfPtr>	<i>optional parameter with default value: "none"</i> <i>The parameter is not visible during modification.</i> Authentication security profile that contains network address of the security server

Parameter	Type	Description
	- Index of the Authentication security profile - range: [0...20] Data driven field type Possible values are depending on the actual configuration and software. The currently allowed values can be shown with online-help.	
uri-prof	Parameter type: <Gpon::UriProfileName> Format: (none <Gpon:UriProfilePtr> name : <AsamProfileName>) Possible values: - none : no profile to associate - name : profile name Field type <Gpon:UriProfilePtr> - Index of the URI profile that contains the IP address of the server - range: [0...100] Data driven field type Possible values are depending on the actual configuration and software. The currently allowed values can be shown with online-help.	<i>mandatory parameter</i> <i>The parameter is not visible during modification.</i> uri profile that contains network address of the configuration server

Command Output

Table 58.17-3 "Voice ONT Secure URI profile Configuration command" Display parameters

Specific Information		
name	Type	Description
auth-securi-prof-name	Parameter type: <Gpon::IgnoredPrintableString> - ignored printable string	name of the authentication security uri profile <i>This element is only shown in detail mode.</i>
uri-prof-name	Parameter type: <Gpon::IgnoredPrintableString> - ignored printable string	name of the uri profile <i>This element is only shown in detail mode.</i>

58.18 GPON Authentication Security Profile Configuration Command

Command Description

This command creates the profile for accessing the server storing authentication security information for contacting network addresses. These profiles are normally associated with Voip Services that must reference common authentication information.

User Level

The command can be accessed by operators with equipment privileges, and executed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

```
> configure pon ( no auth-sec-prof (index) ) | ( auth-sec-prof (index) name <AsamProfileName> [ no
validation-scheme | validation-scheme <Gpon::AuthSecValScheme> ] [ no user-name | user-name
<Gpon::AuthUserName> ] [ no password | password <Security::Password5> ] [ no realm | realm <Gpon::Realm> ]
)
```

Command Parameters

Table 58.18-1 "GPON Authentication Security Profile Configuration Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - profile index - range: [1...20]	profile index

Table 58.18-2 "GPON Authentication Security Profile Configuration Command" Command Parameters

Parameter	Type	Description
name	Parameter type: <AsamProfileName> Format: - a profile name - range: [a-zA-Z0-9-_.] - length: 1<=x<=32	<i>mandatory parameter</i> <i>The parameter is not visible during modification.</i> profile name
[no] validation-scheme	Parameter type: <Gpon::AuthSecValScheme> Format: (disabled md5-digest basic-authentic) Possible values: - disabled : Validation disabled	<i>optional parameter with default value: "md5-digest"</i> <i>The parameter is not visible during modification.</i> validation scheme required for authentication

58 Pon Configuration Commands

Parameter	Type	Description
	- md5-digest : validate using md5 digest authentication - basic-authentic : Validate using basic authentication	
[no] user-name	Parameter type: <Gpon::AuthUserName> Format: - user name required for authentication - length: x<=50	<i>optional parameter with default value: ""</i> <i>The parameter is not visible during modification.</i> user name required for authentication
[no] password	Parameter type: <Security::Password5> Format: (prompt plain : <Security::PlainPassword5>) Possible values: - prompt : prompts the operator for a password - plain : the password in plain text Field type <Security::PlainPassword5> - authentication string - length: x<=25	<i>optional parameter with default value: "plain : "</i> <i>The parameter is not visible during modification.</i> password required for authentication
[no] realm	Parameter type: <Gpon::Realm> Format: - realm required for authentication - length: x<=25	<i>optional parameter with default value: ""</i> <i>The parameter is not visible during modification.</i> realm required for authentication

58.19 GPON URI Profile Configuration Command

Command Description

This command creates the URI profile for accessing the configuration server. These profiles are normally associated with Voip Services.

User Level

The command can be accessed by operators with equipment privileges, and executed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

```
> configure pon ( no uri-prof (index) ) | ( uri-prof (index) name <AsamProfileName> [ no address | address
<Gpon::UriProfileAddress> ] [ no version | version <Gpon::UriProfileVersionNbr> ] )
```

Command Parameters

Table 58.19-1 "GPON URI Profile Configuration Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - profile index - range: [1...100]	profile index

Table 58.19-2 "GPON URI Profile Configuration Command" Command Parameters

Parameter	Type	Description
name	Parameter type: <AsamProfileName> Format: - a profile name - range: [a-zA-Z0-9-_.] - length: 1<=x<=32	<i>mandatory parameter</i> <i>The parameter is not visible during modification.</i> profile name
[no] address	Parameter type: <Gpon::UriProfileAddress> Format: - uri profile address - length: x<=100	<i>optional parameter with default value: ""</i> uri profile address that contains a Fully Qualified Domain Name (FQDN) or an IP Address (in dot notation)
[no] version	Parameter type: <Gpon::UriProfileVersionNbr> Format: - uri profile version number - range: [1...2147483647]	<i>optional parameter with default value: 1L</i> uri profile version number

59- Uni Ont Configuration Commands

59.1 Uni Ont Configuration Command Tree	59-1693
59.2 Uni Ont Video Configuration Command	59-1694
59.3 Uni Ont TC layer Ccounters Configuration Command	59-1696

59.1 Uni Ont Configuration Command Tree

Description

This chapter gives an overview of nodes that are handled by "Uni Ont Configuration Commands".

Command Tree

```
----configure
  ----uni
    ----ont
      ----video
        - (ont-index)
        - [no] pwr-override
        - [no] service-timer
        - [no] admin-state
      ----tc-layer
        - (ont-index)
        - [no] pm-collect
```

59.2 Uni Ont Video Configuration Command

Command Description

This command allows the operator to configure a uni ont video.

User Level

The command can be accessed by operators with equipment privileges, and executed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

```
> configure uni ont video (ont-index) [ [ no ] pwr-override ] [ no service-timer | service-timer
<Gpon::UniServiceTimer> ] [ no admin-state | admin-state <Gpon::UniAdminState> ]
```

Command Parameters

Table 59.2-1 "Uni Ont Video Configuration Command" Resource Parameters

Resource Identifier	Type	Description
(ont-index)	Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Gpon::OntSlotId> / <Gpon::OntPortId> ng2 : <Ng2::ChannelGroup> / <Ng2::SubchannelGroup> / <Ng2::OntId> / <Gpon::OntSlotId> / <Gpon::OntPortId>) Possible values: - ng2 : ngpon2 style identification Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Ng2::ChannelGroup> - channel group number Field type <Ng2::SubchannelGroup> - subchannel group number Field type <Eqpt::OntId> - the ONT identifier Field type <Ng2::OntId> - the ONT identifier Field type <Gpon::OntSlotId> - Gpon Ont Slot - range: [1...14]	gpon ont index

Resource Identifier	Type	Description
	Field type <Gpon::OntPortId> - Gpon Ont Port - range: [1...16]	

Table 59.2-2 "Uni Ont Video Configuration Command" Command Parameters

Parameter	Type	Description
[no] pwr-override	Parameter type: boolean	<i>optional parameter</i> exclude the port from video overlay class power shedding
[no] service-timer	Parameter type: <Gpon::UniServiceTimer> Format: - RF service timer in hours. - unit: hour - range: [-1,0...48]	<i>optional parameter with default value: -1</i> RF service timer in hours.
[no] admin-state	Parameter type: <Gpon::UniAdminState> Format: (unlocked locked) Possible values: - unlocked : activates the video port - locked : deactivates the video port	<i>optional parameter with default value: "locked"</i> administrative state of the video port

Command Output

Table 59.2-3 "Uni Ont Video Configuration Command" Display parameters

Specific Information		
name	Type	Description
oper-state	Parameter type: <Gpon::UniOperState> (enabled disabled unknown) Possible values: - enabled : enable the port - disabled : disable the port - unknown : unknown state	operational state of the video port <i>This element is always shown.</i>

59.3 Uni Ont TC layer Ccounters Configuration Command

Command Description

This command allows the operator to configure a uni ont tc layer counters.

User Level

The command can be accessed by operators with equipment privileges, and executed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

```
> configure uni ont tc-layer (ont-index) [ no pm-collect | pm-collect <Gpon::UniPmCollect> ]
```

Command Parameters

Table 59.3-1 "Uni Ont TC layer Ccounters Configuration Command" Resource Parameters

Resource Identifier	Type	Description
(ont-index)	Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Gpon::OntSlotId> / <Gpon::OntPortId> ng2 : <Ng2::ChannelGroup> / <Ng2::SubchannelGroup> / <Ng2::OntId> / <Gpon::OntSlotId> / <Gpon::OntPortId>) Possible values: - ng2 : ngpon2 style identification Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Ng2::ChannelGroup> - channel group number Field type <Ng2::SubchannelGroup> - subchannel group number Field type <Eqpt::OntId> - the ONT identifier Field type <Ng2::OntId> - the ONT identifier Field type <Gpon::OntSlotId>	gpon ont index

Resource Identifier	Type	Description
	- Gpon Ont Slot - range: [1...14] Field type <Gpon::OntPortId> - Gpon Ont Port - range: [1...16]	

Table 59.3-2 "Uni Ont TC layer Ccounters Configuration Command" Command Parameters

Parameter	Type	Description
[no] pm-collect	Parameter type: <Gpon::UniPmCollect> Format: (disable enable) Possible values: - disable : disable the gem-port performance monitors - enable : enable the gem-port performance monitors	<i>optional parameter with default value: "disable"</i> enable/disable TC Layer Performance monitors

60- CES Configuration Commands

60.1 CES Configuration Command Tree	60-1699
60.2 CES Maintenance Profile Configuration Command	60-1701
60.3 CES Service Port Provisioning Configuration Command	60-1703
60.4 CES Service PM Mode Configuration Command	60-1706
60.5 CES Service Configuration Command	60-1708
60.6 CES Service Gem Port Configuration Command	60-1713
60.7 CES Service Configuration Command	60-1715

60.1 CES Configuration Command Tree

Description

This chapter gives an overview of nodes that are handled by "CES Configuration Commands".

Command Tree

```

----configure
  ----ces
    ----ont
      ----[no] profile
        - (profile-idx)
        - profile-name
        - [no] jitter-buff-max
        - [no] fill-policy
        - [no] rbit-recv-policy
        - [no] lbit-recv-policy
      ----line
        - (uni-idx)
        - mode
        - frame
        - [no] encoding
        - [no] line-length
        - [no] pwr-override
        - [no] sst
        - [no] admin-state
      ----port
        - [no] pm-collect
      ----[no] service
        - (uni-idx)
        - service-nbr
        - [no] service-type
        - [no] label
        - [no] signaling
        - [no] timeslot-map
        - [no] payload-size
        - [no] pl-encap-delay
        - [no] timing-mode
        - [no] transmit-ckt-id
        - [no] expected-ckt-id
        - [no] maintenance-prof
        - [no] dest-mac-address
        - [no] rtp-enable
        - vlan
        - [no] admin-up
        - [no] udp-port
        - [no] dscp
        - [no] farend-ipinfo
        - [no] rtp-clock-ref
        - [no] rtp-ts-mode
        - [no] rtp-ptyp-pay
        - [no] rtp-ptyp-sig

```

- [no] rtp-sync-pay
- [no] rtp-sync-sig
- [no] rtp-exp-ptyp-pay
- [no] rtp-exp-ptyp-sig
- [no] rtp-exp-sync-pay
- [no] rtp-exp-sync-sig
- tc-layer**
 - [no] pm-collect
- pseudo-wire**
 - [no] pm-collect

60.2 CES Maintenance Profile Configuration Command

Command Description

This command allows the operator to configure CES Maintenance profile.

User Level

The command can be accessed by operators with equipment privileges, and executed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

```
> configure ces ont ( no profile (profile-idx) ) | ( profile (profile-idx) profile-name <AsamProfileName> [ no
jitter-buff-max | jitter-buff-max <Ces::JitterBuffMax> ] [ no fill-policy | fill-policy <Ces::FillPolicy> ] [ no
rbit-recv-policy | rbit-recv-policy <Ces::RbitRecvPolicy> ] [ no lbit-recv-policy | lbit-recv-policy
<Ces::LbitRecvPolicy> ] )
```

Command Parameters

Table 60.2-1 "CES Maintenance Profile Configuration Command" Resource Parameters

Resource Identifier	Type	Description
(profile-idx)	Format: - ces maintenance profile index value - range: [1...20]	ces maintenance profile index value

Table 60.2-2 "CES Maintenance Profile Configuration Command" Command Parameters

Parameter	Type	Description
profile-name	Parameter type: <AsamProfileName> Format: - a profile name - range: [a-zA-Z0-9-_.] - length: 1<=x<=32	<i>mandatory parameter</i> ces maintenance profile name
[no] jitter-buff-max	Parameter type: <Ces::JitterBuffMax> Format: - maximum depth for jitter buffer in micro seconds. For values except 0 that are not multiples of 8 are rounded up so that the result is effective range of 1..200 milliseconds - range: [0...1600]	<i>optional parameter with default value: "0"</i> maximum depth of the jitter buffer
[no] fill-policy	Parameter type: <Ces::FillPolicy> Format: (ont-default all-ones idle)	<i>optional parameter with default value: "ont-default"</i> payload bit pattern

60 CES Configuration Commands

Parameter	Type	Description
	Possible values: - ont-default : ONT default vendor-specific - all-ones : play out all 1s - idle : play out DS1 idle	
[no] rbit-recv-policy	Parameter type: <Ces::RbitRecvPolicy> Format: (no-act all-ones idle) Possible values: - no-act : no action - all-ones : use service-specific RAI/REI/RDI code - idle : idle signalling and idle payload	<i>optional parameter with default value: "no-act"</i> rbit receive policy
[no] lbit-recv-policy	Parameter type: <Ces::LbitRecvPolicy> Format: (ssais idle) Possible values: - ssais : use service specific AIS code - idle : idle signalling and idle payload	<i>optional parameter with default value: "ssais"</i> lbit receive policy

60.3 CES Service Port Provisioning Configuration Command

Command Description

This command allows the operator to configure ONT CESUNI port provisioning data. All modifications are service affecting.

User Level

The command can be accessed by operators with equipment privileges, and executed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

```
> configure ces ont line (uni-idx) [ mode <Ces::PortStructure> ] [ frame <Ces::Frame> ] [ no encoding | encoding <Ces::Encoding> ] [ no line-length | line-length <Ces::LineLength> ] [ [ no ] pwr-override ] [ no sst | sst <Ces::BponLoopBack> ] [ no admin-state | admin-state <Gpon::ItfAdminStatus> ]
```

Command Parameters

Table 60.3-1 "CES Service Port Provisioning Configuration Command" Resource Parameters

Resource Identifier	Type	Description
(uni-idx)	Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Gpon::OntSlotId> / <Gpon::OntPortId> ng2 : <Ng2::ChannelGroup> / <Ng2::SubchannelGroup> / <Ng2::OntId> / <Gpon::OntSlotId> / <Gpon::OntPortId>) Possible values: - ng2 : ngpon2 style identification Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Ng2::ChannelGroup> - channel group number Field type <Ng2::SubchannelGroup> - subchannel group number Field type <Eqpt::OntId> - the ONT identifier	interface index of the ces ont uni

Resource Identifier	Type	Description
	Field type <Ng2::OntId> - the ONT identifier Field type <Gpon::OntSlotId> - Gpon Ont Slot - range: [1...14] Field type <Gpon::OntPortId> - Gpon Ont Port - range: [1...16]	

Table 60.3-2 "CES Service Port Provisioning Configuration Command" Command Parameters

Parameter	Type	Description
mode	Parameter type: <Ces::PortStructure> Format: (unstructured structured) Possible values: - unstructured : unstructured mode - structured : structured mode	<i>optional parameter</i> DS1/E1 port structure
frame	Parameter type: <Ces::Frame> Format: (esf sf unframed pcm30 pcm31) Possible values: - esf : extended superframe(only for DS1 and mode=structured) - sf : superframe(only for DS1 and mode=structured) - unframed : unframed(valid only and mode=unstructured) - pcm30 : pcm 30(only for E1 and mode=structured) - pcm31 : pcm 31(only for E1 and mode=structured)	<i>optional parameter</i> port framing
[no] encoding	Parameter type: <Ces::Encoding> Format: (b8zs ami hdb3) Possible values: - b8zs : b8zs encoding scheme(only for DS1) - ami : ami encoding scheme - hdb3 : hdb3 encoding scheme(only for E1)	<i>optional parameter with default value: "b8zs"</i> port encoding
[no] line-length	Parameter type: <Ces::LineLength> Format: (0to133ft 133to266ft 266to399ft 399to533ft 533to655ft 7andhalfdb 15db 22andhalfdb 75ohms 120ohms) Possible values: - 0to133ft : 0 - 133 ft (only for DS1) - 133to266ft : 133 - 266 ft (only for DS1) - 266to399ft : 266 - 399 ft (only for DS1)	<i>optional parameter with default value: ""</i> length of the twisted pair cable

Parameter	Type	Description
	- 399to533ft : 399 - 533 ft (only for DS1) - 533to655ft : 533 - 655 ft (only for DS1) - 7andhalfdb : 7.5 db (only for DS1) - 15db : 15 db (only for DS1) - 22andhalfdb : 22.5 db (only for DS1) - 75ohms : 75 ohms (only for E1) - 120ohms : 120 ohms (only for E1)	
[no] pwr-override	Parameter type: boolean	<i>optional parameter</i> port excluded from CES class power shedding
[no] sst	Parameter type: <Ces::BponLoopBack> Format: (no-loopback line-loopback inward-loopback) Possible values: - no-loopback : no loopback - line-loopback : line loopback - inward-loopback : inward loopback	<i>optional parameter with default value: "no-loopback"</i> loop back configuration
[no] admin-state	Parameter type: <Gpon::ItfAdminStatus> Format: (up down) Possible values: - up : set the admin-state to up - down : set the admin-state to down	<i>optional parameter with default value: "down"</i> <i>The parameter is not visible during creation.</i> administrative status of the interface

Command Output

Table 60.3-3 "CES Service Port Provisioning Configuration Command" Display parameters

Specific Information		
name	Type	Description
oper-state	Parameter type: <Itf::ifOperStatus> (up down testing unknown dormant no-value) Possible values: - up : up,traffic can pass - down : down,no traffic is passing - testing : testing,no traffic is passing - unknown : unknown - dormant : dormant,no traffic is passing - no-value : no entry in the table	the operational state of the interface <i>This element is always shown.</i>
card-type	Parameter type: <Ces::CardConfig> (ds1 e1) Possible values: - ds1 : DS1 card - e1 : E1 card	card type <i>This element is always shown.</i>

60.4 CES Service PM Mode Configuration Command

Command Description

This command allows the operator to configure the PM Mode of CESUNI ports on a specific ONT

User Level

The command can be accessed by operators with equipment privileges, and executed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

```
> configure ces ont line (uni-idx) port [ no pm-collect | pm-collect <Ces::GemPmCollectInd> ]
```

Command Parameters

Table 60.4-1 "CES Service PM Mode Configuration Command" Resource Parameters

Resource Identifier	Type	Description
(uni-idx)	Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Gpon::OntSlotId> / <Gpon::OntPortId> ng2 : <Ng2::ChannelGroup> / <Ng2::SubchannelGroup> / <Ng2::OntId> / <Gpon::OntSlotId> / <Gpon::OntPortId>) Possible values: - ng2 : ngpon2 style identification Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Ng2::ChannelGroup> - channel group number Field type <Ng2::SubchannelGroup> - subchannel group number Field type <Eqpt::OntId> - the ONT identifier Field type <Ng2::OntId> - the ONT identifier Field type <Gpon::OntSlotId>	interface index of the ces ont uni

Resource Identifier	Type	Description
	- Gpon Ont Slot - range: [1...14] Field type <Gpon::OntPortId> - Gpon Ont Port - range: [1...16]	

Table 60.4-2 "CES Service PM Mode Configuration Command" Command Parameters

Parameter	Type	Description
[no] pm-collect	Parameter type: <Ces::GemPmCollectInd> Format: (enable disable) Possible values: - enable : enable PM (L2 only) - disable : disable PM (L2 only)	<i>optional parameter with default value: "disable"</i> CES port Performance monitor

60.5 CES Service Configuration Command

Command Description

This command allows the operator to configure CES service.

User Level

The command can be accessed by operators with equipment privileges, and executed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

```
> configure ces ont ( no service (uni-idx) service-nbr <Ces::ServiceNumber> ) | ( service (uni-idx) service-nbr
<Ces::ServiceNumber> [ no service-type | service-type <Ces::ServiceType> ] [ no label | label <Ces::Label> ] [ no
signaling | signaling <Ces::Signalling> ] [ no timeslot-map | timeslot-map <Ces::TimeSlotMap> ] [ no payload-size
| payload-size <Ces::PayloadSize> ] [ no pl-encap-delay | pl-encap-delay <Ces::PayloadEncapDelay> ] [ no
timing-mode | timing-mode <Ces::TimingNode> ] [ no transmit-ckt-id | transmit-ckt-id <Ces::TransmitCktId> ] [
no expected-ckt-id | expected-ckt-id <Ces::ExpectedCktId> ] [ no maintenance-prof | maintenance-prof
<Ces::MaintProfIndex> ] [ no dest-mac-address | dest-mac-address <Ces::DestMacAddress> ] [ no rtp-enable |
rtp-enable <Ces::RtpEnable> ] vlan <Vlan::Index> [ no admin-up | admin-up <Ces::AdminState> ] [ no udp-port |
udp-port <Ces::UdpPort> ] [ no dscp | dscp <Ces::DscpSetting> ] [ no farend-ipinfo | farend-ipinfo
<Ces::FarEndIpInfo> ] [ no rtp-clock-ref | rtp-clock-ref <Ces::RtpClockRef> ] [ no rtp-ts-mode | rtp-ts-mode
<Ces::RtpTimeStampMode> ] [ no rtp-ptyp-pay | rtp-ptyp-pay <Ces::RtpPayloadTypePayloadChannel> ] [ no
rtp-ptyp-sig | rtp-ptyp-sig <Ces::RtpPayloadTypeSigChannel> ] [ no rtp-sync-pay | rtp-sync-pay
<Ces::RtpSyncSourcePayloadChannel> ] [ no rtp-sync-sig | rtp-sync-sig <Ces::RtpSyncSourceSigChannel> ] [ no
rtp-exp-ptyp-pay | rtp-exp-ptyp-pay <Ces::RtpExpectedPayloadTypePayloadChannel> ] [ no rtp-exp-ptyp-sig |
rtp-exp-ptyp-sig <Ces::RtpExpectedPayloadTypeSigChannel> ] [ no rtp-exp-sync-pay | rtp-exp-sync-pay
<Ces::RtpExpectedSyncSourcePayloadChannel> ] [ no rtp-exp-sync-sig | rtp-exp-sync-sig
<Ces::RtpExpectedSyncSourceSigChannel> ] )
```

Command Parameters

Table 60.5-1 "CES Service Configuration Command" Resource Parameters

Resource Identifier	Type	Description
(uni-idx)	Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> / <Eqpt::OntPortId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier	interface index of the ces ont uni

Resource Identifier	Type	Description
	Field type <Eqpt::OntId> - the ONT identifier Field type <Eqpt::OntSlotId> - the ONT SLOT identifier Field type <Eqpt::OntPortId> - the ONT PORT identifier	
service-nbr	Parameter type: <Ces::ServiceNumber> Format: - interval number - range: [1]	service number

Table 60.5-2 "CES Service Configuration Command" Command Parameters

Parameter	Type	Description
[no] service-type	Parameter type: <Ces::ServiceType> Format: (12 13) Possible values: - 12 : Layer2 (ethernet) - 13 : layer3 (IP/UDP)	<i>optional parameter with default value: "12"</i> <i>The parameter is not visible during modification.</i> underlying transport type - ethernet (12) vs. udp/ip (13)
[no] label	Parameter type: <Ces::Label> Format: - label of the service - length: x<=20	<i>optional parameter with default value: ""</i> label of the service
[no] signaling	Parameter type: <Ces::Signalling> Format: (no-sig cas) Possible values: - no-sig : no signalling - cas : carried in a separate signalling channel	<i>optional parameter with default value: "no-sig"</i> <i>The parameter is not visible during modification.</i> signaling
[no] timeslot-map	Parameter type: <Ces::TimeSlotMap> Format: - time slot map - length: 4	<i>optional parameter with default value: "ff : ff : ff : 00"</i> time slot map
[no] payload-size	Parameter type: <Ces::PayloadSize> Format: - payload size, applicable only if service type is unstructured;value 192 for DS1 and 256 for E1. - range: [192,256]	<i>optional parameter with default value: 0L</i> <i>The parameter is not visible during modification.</i> payload size
[no] pl-encap-delay	Parameter type: <Ces::PayloadEncapDelay> Format: - payload encapsulation delay, number of 125 microsecond frames to be encapsulated in each PW packet;only significant and required in structured mode. - range: [8,16,24,32,64]	<i>optional parameter with default value: 0L</i> payload encapsulation delay
[no] timing-mode	Parameter type: <Ces::TimingNode> Format: (net diff adaptive loop) Possible values: - net : network timing - diff : differential timing - adaptive : adaptive timing - loop : loop timing	<i>optional parameter with default value: "adaptive"</i> timing mode of the TDM service

60 CES Configuration Commands

Parameter	Type	Description
[no] transmit-ckt-id	Parameter type: <Ces::TransmitCktId> Format: - transmit circuit id (L2 only) - length: 8	<i>optional parameter with default value: "00 : 00 : 00 : 00 : 00 : 00 : 00 : 00"</i> transmit circuit id (L2 only)
[no] expected-ckt-id	Parameter type: <Ces::ExpectedCktId> Format: - expected circuit id (L2 only) - length: 8	<i>optional parameter with default value: "00 : 00 : 00 : 00 : 00 : 00 : 00 : 00"</i> expected circuit id (L2 only)
[no] maintenance-prof	Parameter type: <Ces::MaintProfIndex> Format: (none <Ces::MaintProfIndex>) Possible values: - none : no profile to associate Field type <Ces::MaintProfIndex> - a ces maintenance profile index value - range: [0...20]	<i>optional parameter with default value: "none"</i> maintenance profile
[no] dest-mac-address	Parameter type: <Ces::DestMacAddress> Format: - a mac-address (example : 01:02:03:04:05:06) (L2 only) - length: 6	<i>optional parameter with default value: "00 : 00 : 00 : 00 : 00 : 00"</i> destination mac address (L2 only)
[no] rtp-enable	Parameter type: <Ces::RtpEnable> Format: (enabled disabled) Possible values: - enabled : enable rtp - disabled : disable rtp	<i>optional parameter with default value: "disabled"</i> rtp enable
vlan	Parameter type: <Vlan::Index> Format: (<Vlan::UVlanIndex> stacked : <Vlan::SVlanIndexStacked> <Vlan::CVlanIndex>) Possible values: - stacked : stacked vlan identity Field type <Vlan::UVlanIndex> - unstacked vlan identity - range: [1...4093,4096] Field type <Vlan::SVlanIndexStacked> - service vlan identity - range: [1...4093] Field type <Vlan::CVlanIndex> - customer vlan identity - range: [0...4093]	<i>mandatory parameter</i> <i>The parameter is not visible during modification.</i> vlan id
[no] admin-up	Parameter type: <Ces::AdminState> Format: (unlocked locked) Possible values: - unlocked : start sending upstream allocation grants - locked : stop sending upstream allocation grants	<i>optional parameter with default value: "unlocked"</i> administrative state of the service
[no] udp-port	Parameter type: <Ces::UdpPort> Format: - udp port (L3 only) - range: [2142,49152...65535]	<i>optional parameter with default value: 2142L</i> <i>The parameter is not visible during modification.</i> unique udp port number for l3 service (L3 only)

Parameter	Type	Description
[no] dscp	Parameter type: <Ces::DscpSetting> Format: - to set the DSCP value that the Voip Client will use - range: [0...63]	<i>optional parameter with default value: 46L</i> DSCP Value (L3 only)
[no] farend-ipinfo	Parameter type: <Ces::FarEndIpInfo> Format: - far end URI. Example = udp://<ip-addr>:<udp-port> (L3 only) - length: x<=50	<i>optional parameter with default value: ""</i> URI of the far-end termination point (L3 only)
[no] rtp-clock-ref	Parameter type: <Ces::RtpClockRef> Format: - frequency of the common timing reference (L3 only) - range: [0...1000]	<i>optional parameter with default value: 0L</i> frequency of the common timing reference (in multiples of 8 kHz) (L3 only)
[no] rtp-ts-mode	Parameter type: <Ces::RtpTimeStampMode> Format: (unknown absolute differential) Possible values: - unknown : not applicable (L3 only) - absolute : absolute mode (L3 only) - differential : differential mode (L3 only)	<i>optional parameter with default value: "unknown"</i> Mode in which RTP timestamps are generated in the TDM to PSN direction (L3 only)
[no] rtp-ptyp-pay	Parameter type: <Ces::RtpPayloadTypePayloadChannel> Format: - RTP payload type for the payload channel in the TDM to PSN direction (L3 only) - range: [96...127]	<i>optional parameter with default value: 96L</i> RTP payload type for the payload channel in the TDM to PSN direction (L3 only)
[no] rtp-ptyp-sig	Parameter type: <Ces::RtpPayloadTypeSigChannel> Format: - RTP payload type for the signalling channel (L3 only) - range: [0]	<i>optional parameter with default value: 0L</i> RTP payload type for the signalling channel in the TDM to PSN direction (L3 only)
[no] rtp-sync-pay	Parameter type: <Ces::RtpSyncSourcePayloadChannel> Format: - RTP synchronization source for the payload channel (L3 only) - range: [0...65535]	<i>optional parameter with default value: 0L</i> RTP synchronization source for the payload channel in the TDM to PSN direction (L3 only)
[no] rtp-sync-sig	Parameter type: <Ces::RtpSyncSourceSigChannel> Format: - RTP synchronization source for the signalling channel (L3 only) - range: [0]	<i>optional parameter with default value: 0L</i> RTP synchronization source for the signalling channel in the TDM to PSN direction (L3 only)
[no] rtp-exp-ptyp-pay	Parameter type: <Ces::RtpExpectedPayloadTypePayloadChannel> Format: - RTP payload type for the payload channel (L3 only) - range: [0...127]	<i>optional parameter with default value: 0L</i> RTP expected payload type for the payload channel in the PSN to TDM direction (L3 only)
[no] rtp-exp-ptyp-sig	Parameter type: <Ces::RtpExpectedPayloadTypeSigChannel> Format: - RTP payload type for the signalling channel (L3 only) - range: [0]	<i>optional parameter with default value: 0L</i> RTP expected payload type for the signalling channel in the PSN to TDM direction (L3 only)
[no] rtp-exp-sync-pay	Parameter type: <Ces::RtpExpectedSyncSourcePayloadChannel> Format: - RTP synchronization source for the payload channel (L3 only)	<i>optional parameter with default value: 0L</i> RTP expected synchronization source for the payload channel in

Parameter	Type	Description
	only) - range: [0...65535]	the TDM to PSN direction (L3 only)
[no] rtp-exp-sync-sig	Parameter type: <Ces::RtpExpectedSyncSourceSigChannel> Format: - RTP synchronization source for the signalling channel (L3 only) - range: [0]	<i>optional parameter with default value: 0L</i> RTP expected synchronization source for the signalling channel in the TDM to PSN direction (L3 only)

Command Output

Table 60.5-3 "CES Service Configuration Command" Display parameters

Specific Information		
name	Type	Description
oper-state	Parameter type: <Ces::OperState> (enabled disabled unknown) Possible values: - enabled : enable the service - disabled : disable the service - unknown : unknown state	operational state of the service <i>This element is always shown.</i>
maint-prof-name	Parameter type: <Ces::IgnoredPrintableString> - ignored printable string	ces maintenance profile <i>This element is always shown.</i>

60.6 CES Service Gem Port Configuration Command

Command Description

This command allows the operator to configure CES gem port performance monitor.

User Level

The command can be accessed by operators with equipment privileges, and executed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

```
> configure ces ont service (uni-idx)service-nbr <Ces::ServiceNumber> tc-layer [ no pm-collect | pm-collect
<Ces::GemPmCollectInd> ]
```

Command Parameters

Table 60.6-1 "CES Service Gem Port Configuration Command" Resource Parameters

Resource Identifier	Type	Description
(uni-idx)	Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> / <Eqpt::OntPortId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Eqpt::OntId> - the ONT identifier Field type <Eqpt::OntSlotId> - the ONT SLOT identifier Field type <Eqpt::OntPortId> - the ONT PORT identifier	interface index of the ces ont uni
service-nbr	Parameter type: <Ces::ServiceNumber> Format: - interval number - range: [1]	service number

Table 60.6-2 "CES Service Gem Port Configuration Command" Command Parameters

60 CES Configuration Commands

Parameter	Type	Description
[no] pm-collect	Parameter type: <Ces::GemPmCollectInd> Format: (enable disable) Possible values: - enable : enable PM (L2 only) - disable : disable PM (L2 only)	<i>optional parameter with default value: "disable"</i> TC Layer performance monitoring

60.7 CES Service Configuration Command

Command Description

This command allows the operator to configure CES pseudo-wire performance monitor.

User Level

The command can be accessed by operators with equipment privileges, and executed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

```
> configure ces ont service (uni-idx)service-nbr <Ces::ServiceNumber> pseudo-wire [ no pm-collect | pm-collect
<Ces::PwPmCollectInd> ]
```

Command Parameters

Table 60.7-1 "CES Service Configuration Command" Resource Parameters

Resource Identifier	Type	Description
(uni-idx)	Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> / <Eqpt::OntPortId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Eqpt::OntId> - the ONT identifier Field type <Eqpt::OntSlotId> - the ONT SLOT identifier Field type <Eqpt::OntPortId> - the ONT PORT identifier	interface index of the ces ont uni
service-nbr	Parameter type: <Ces::ServiceNumber> Format: - interval number - range: [1]	service number

Table 60.7-2 "CES Service Configuration Command" Command Parameters

Parameter	Type	Description
[no] pm-collect	Parameter type: <Ces::PwPmCollectInd> Format:	optional parameter with default value: "disable"

60 CES Configuration Commands

Parameter	Type	Description
	(enable disable) Possible values: - enable : enable PM - disable : disable PM	pseudo-wire performance monitor

61- ANI ONT Configuration Commands

61.1 ANI ONT Configuration Command Tree	61-1718
61.2 ANI ONT Thershold Configuration Command	61-1719
61.3 ANI ONT Video Configuration Command	61-1721

61.1 ANI ONT Configuration Command Tree

Description

This chapter gives an overview of nodes that are handled by "ANI ONT Configuration Commands".

Command Tree

```
----configure
  ----ani
    ----ont
      ----[no] tca-thresh
        - (ont-idx)
        - [no] lower-optical-th
        - [no] upper-optical-th
        - [no] rssi-profile
      ----[no] video
        - (ont-idx)
        - [no] plnd-agc-mode
        - [no] agc-offset
        - [no] lower-optical-th
        - [no] upper-optical-th
```


61.2 ANI ONT Thershold Configuration Command

Command Description

This command edits provisioning data associated with an ONT ANI.

User Level

The command can be accessed by operators with equipment privileges, and executed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

```
> configure ani ont ( no tca-thresh (ont-idx) ) | ( tca-thresh (ont-idx) [ no lower-optical-th | lower-optical-th
<Gpon::OpticalthreshLow> ] [ no upper-optical-th | upper-optical-th <Gpon::OpticalthreshHigh> ] [ no rssi-profile |
rssi-profile <Gpon::RssiProfileId> ] )
```

Command Parameters

Table 61.2-1 "ANI ONT Thershold Configuration Command" Resource Parameters

Resource Identifier	Type	Description
(ont-idx)	Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> ng2 : <Ng2::ChannelGroup> / <Ng2::SubchannelGroup> / <Ng2::OntId>) Possible values: - ng2 : ngpon2 style identification Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Ng2::ChannelGroup> - channel group number Field type <Ng2::SubchannelGroup> - subchannel group number Field type <Eqpt::OntId> - the ONT identifier Field type <Ng2::OntId> - the ONT identifier	ont index

Table 61.2-2 "ANI ONT Thershold Configuration Command" Command Parameters

61 ANI ONT Configuration Commands

Parameter	Type	Description
[no] lower-optical-th	Parameter type: <Gpon::OpticalthreshLow> Format: - optical level ONT uses to declare the low recieved - unit: dBm - range: [-127...0.5]	<i>optional parameter with default value: 0.5</i> indicates the optical level the ONT uses to declare the Low received.Value 0.5 dBm means ONT internal choice which would be MIB default 1
[no] upper-optical-th	Parameter type: <Gpon::OpticalthreshHigh> Format: - optical level ONT uses to declare the high recieved - unit: dBm - range: [-127...0.5]	<i>optional parameter with default value: 0.5</i> indicates the optical level the ONT uses to declare the High received.Value 0.5 dBm means ONT internal choice which would be MIB default 1
[no] rssi-profile	Parameter type: <Gpon::RssiProfileId> Format: - an unique index value for the rssi profile(0-200 configurable) - range: [0...200]	<i>optional parameter with default value: "0"</i> an unique index of the rssi profile(0-200)

61.3 ANI ONT Video Configuration Command

Command Description

This command edits provisioning data associated with a ONTVIDANI.

User Level

The command can be accessed by operators with equipment privileges, and executed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

```
> configure ani ont ( no video (ont-idx) ) | ( video (ont-idx) [ no plnd-agc-mode | plnd-agc-mode
<Gpon::AgcMode> ] [ no agc-offset | agc-offset <Gpon::AgcOffset> ] [ no lower-optical-th | lower-optical-th
<Gpon::VidOpticalThresh> ] [ no upper-optical-th | upper-optical-th <Gpon::VidOpticalThresh> ] )
```

Command Parameters

Table 61.3-1 "ANI ONT Video Configuration Command" Resource Parameters

Resource Identifier	Type	Description
(ont-idx)	Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> ng2 : <Ng2::ChannelGroup> / <Ng2::SubchannelGroup> / <Ng2::OntId>) Possible values: - ng2 : ngpon2 style identification Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Ng2::ChannelGroup> - channel group number Field type <Ng2::SubchannelGroup> - subchannel group number Field type <Eqpt::OntId> - the ONT identifier Field type <Ng2::OntId> - the ONT identifier	ont index

Table 61.3-2 "ANI ONT Video Configuration Command" Command Parameters

61 ANI ONT Configuration Commands

Parameter	Type	Description
[no] plnd-agc-mode	Parameter type: <Gpon::AgcMode> Format: (no-agc broad-band-agc) Possible values: - no-agc : No AGC is used - broad-band-agc : Broadband RF AGC is used	<i>optional parameter with default value: "broad-band-agc"</i> allows provisioning of the ONT's AGC capabilities
[no] agc-offset	Parameter type: <Gpon::Agcoffset> Format: - Offset value to be used for Broadband RF AGC or Optical - unit: db - range: [-12...12]	<i>optional parameter with default value: 2</i> indicates the offset value to be used for Broadband RF AGC or Optical
[no] lower-optical-th	Parameter type: <Gpon::Vidopticalthresh> Format: - optical level the ONT uses to declare the Video-OOR high/Low alarm - unit: dBm - range: [-12...6]	<i>optional parameter with default value: -9.5</i> indicates the optical level the ONT uses to declare the Video-OOR Low alarm
[no] upper-optical-th	Parameter type: <Gpon::Vidopticalthresh> Format: - optical level the ONT uses to declare the Video-OOR high/Low alarm - unit: dBm - range: [-12...6]	<i>optional parameter with default value: 1.0</i> indicates the optical level the ONT uses to declare the Video-OOR high alarm

62- ONT HPNA Configuration Commands

62.1 ONT HPNA Configuration Command Tree	62-1724
62.2 ONT HPNA Configuration Command	62-1725
62.3 ONT HPNA L2 Port Performance Monitoring Configuration Command	62-1728
62.4 Hpna ONT Uni Layer 2 Configuration Command	62-1730

62.1 ONT HPNA Configuration Command Tree

Description

This chapter gives an overview of nodes that are handled by "ONT HPNA Configuration Commands".

Command Tree

```
----configure
----hpna
----ont
  - (uni-idx)
  - cust-info
  - [no] pwr-override
  - [no] master-mode
  - [no] admin-state
  ----X port
  ----l2
    - [no] pm
    - [no] tca
    - [no] dropped-frames-up
    - [no] dropped-frames-dn
```

62.2 ONT HPNA Configuration Command

Command Description

This command allows the operator to modify ONT HPNA port provisioning data.

User Level

The command can be accessed by operators with equipment privileges, and executed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

```
> configure hpna ont (uni-idx) [ cust-info <Gpon::CustomerInfo> ] [ no pwr-override | pwr-override
<Gpon::OntPwrShedState> ] [ no master-mode | master-mode <Gpon::HpnaMasterSelect> ] [ no admin-state |
admin-state <Gpon::ItfAdminStatus> ]
```

Command Parameters

Table 62.2-1 "ONT HPNA Configuration Command" Resource Parameters

Resource Identifier	Type	Description
(uni-idx)	Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Gpon::OntSlotId> / <Gpon::OntPortId> ng2 : <Ng2::ChannelGroup> / <Ng2::SubchannelGroup> / <Ng2::OntId> / <Gpon::OntSlotId> / <Gpon::OntPortId>) Possible values: - ng2 : ngpon2 style identification Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Ng2::ChannelGroup> - channel group number Field type <Ng2::SubchannelGroup> - subchannel group number Field type <Eqpt::OntId> - the ONT identifier Field type <Ng2::OntId> - the ONT identifier Field type <Gpon::OntSlotId> - Gpon Ont Slot	identification of the hpna interface index

Resource Identifier	Type	Description
	- range: [1...14] - Field type <Gpon::OntPortId> - Gpon Ont Port - range: [1...16]	

Table 62.2-2 "ONT HPNA Configuration Command" Command Parameters

Parameter	Type	Description
cust-info	Parameter type: <Gpon::CustomerInfo> Format: - char string - length: x<=80	<i>optional parameter</i> information for HPNA port
[no] pwr-override	Parameter type: <Gpon::OntPwrShedState> Format: (enabled disabled) Possible values: - enabled : enabled - disabled : disabled	<i>optional parameter with default value: "disabled"</i> power settings to be included for data class power shedding
[no] master-mode	Parameter type: <Gpon::HpnaMasterSelect> Format: (default auto forced) Possible values: - default : default master mode - auto : auto master mode - forced : forced master mode	<i>optional parameter with default value: "default"</i> master mode of HPNA mac
[no] admin-state	Parameter type: <Gpon::ItfAdminStatus> Format: (up down) Possible values: - up : set the admin-state to up - down : set the admin-state to down	<i>optional parameter with default value: "down"</i> <i>The parameter is not visible during creation.</i> administrative status of the interface

Command Output

Table 62.2-3 "ONT HPNA Configuration Command" Display parameters

Specific Information		
name	Type	Description
base-mac-address	Parameter type: <Ces::DestMacAddress> - a mac-address (example : 01:02:03:04:05:06) (L2 only) - length: 6	base mac address <i>This element is always shown.</i>
port-configuration	Parameter type: <Gpon::HpnaConfigStatus> (unknown coax_12_28 phone_12_28) Possible values: - unknown : cant reach the ont or the ont didnt return a response to the query - coax_12_28 : not supported - phone_12_28 : not supported	configuration status of hpna uni <i>This element is always shown.</i>
oper-state	Parameter type: <Itf::ifOperStatus> (up down testing	the operational state of the interface <i>This element is always shown.</i>

name	Type	Description
	unknown dormant no-value) Possible values: - up : up,traffic can pass - down : down,no traffic is passing - testing : testing,no traffic is passing - unknown : unknown - dormant : dormant,no traffic is passing - no-value : no entry in the table	

62.3 ONT HPNA L2 Port Performance Monitoring Configuration Command

Command Description

Obsolete command, replaced by configure hpna ont l2 pm.

This command allows the operator to enable or disable PM on the HPNA layer 2 ports of the ONT.

User Level

The command can be accessed by operators with equipment privileges, and executed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

```
> configure hpna ont (uni-idx) port [ no pm-collect | pm-collect <Gpon::OntPmCollect> ]
```

Obsolete command, replaced by configure hpna ont l2 pm.

Command Parameters

Table 62.3-1 "ONT HPNA L2 Port Performance Monitoring Configuration Command" Resource Parameters

Resource Identifier	Type	Description
(uni-idx)	Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Gpon::OntSlotId> / <Gpon::OntPortId> ng2 : <Ng2::ChannelGroup> / <Ng2::SubchannelGroup> / <Ng2::OntId> / <Gpon::OntSlotId> / <Gpon::OntPortId>) Possible values: - ng2 : ngpon2 style identification Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Ng2::ChannelGroup> - channel group number Field type <Ng2::SubchannelGroup> - subchannel group number Field type <Eqpt::OntId>	identification of the hpna interface index

Resource Identifier	Type	Description
	- the ONT identifier Field type <Ng2::OntId> - the ONT identifier Field type <Gpon::OntSlotId> - Gpon Ont Slot - range: [1...14] - Gpon Ont Port Field type <Gpon::OntPortId> - Gpon Ont Port - range: [1...16]	

Table 62.3-2 "ONT HPNA L2 Port Performance Monitoring Configuration Command" Command Parameters

Parameter	Type	Description
[no] pm-collect	Parameter type: <Gpon::OntPmCollect> Format: (enable disable) Possible values: - enable : enable PM - disable : disable PM	<i>optional parameter with default value: "disable"</i> hpna port layer 2 performance monitoring

62.4 Hpna ONT Uni Layer 2 Configuration Command

Command Description

This command allows the operator to provision performance monitoring and threshold crossing alerts for an Hpna ONT layer 2 UNI.

User Level

The command can be accessed by operators with equipment privileges, and executed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

```
> configure hpna ont (uni-idx) l2 [ no pm | pm <Gpon::OntPmCollect> ] [ no tca | tca <Gpon::OntPmCollect> ] [ no
dropped-frames-up | dropped-frames-up <Gpon::ErrorCountThreshold> ] [ no dropped-frames-dn |
dropped-frames-dn <Gpon::ErrorCountThreshold> ]
```

Command Parameters

Table 62.4-1 "Hpna ONT Uni Layer 2 Configuration Command" Resource Parameters

Resource Identifier	Type	Description
(uni-idx)	Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Gpon::OntSlotId> / <Gpon::OntPortId> ng2 : <Ng2::ChannelGroup> / <Ng2::SubchannelGroup> / <Ng2::OntId> / <Gpon::OntSlotId> / <Gpon::OntPortId>) Possible values: - ng2 : ngpon2 style identification Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Ng2::ChannelGroup> - channel group number Field type <Ng2::SubchannelGroup> - subchannel group number Field type <Eqpt::OntId> - the ONT identifier	identification of the hpna interface index

Resource Identifier	Type	Description
	Field type <Ng2::OntId> - the ONT identifier Field type <Gpon::OntSlotId> - Gpon Ont Slot - range: [1...14] Field type <Gpon::OntPortId> - Gpon Ont Port - range: [1...16]	

Table 62.4-2 "Hpna ONT Uni Layer 2 Configuration Command" Command Parameters

Parameter	Type	Description
[no] pm	Parameter type: <Gpon::OntPmCollect> Format: (enable disable) Possible values: - enable : enable PM - disable : disable PM	<i>optional parameter with default value: "disable"</i> l2 pm collection
[no] tca	Parameter type: <Gpon::OntPmCollect> Format: (enable disable) Possible values: - enable : enable PM - disable : disable PM	<i>optional parameter with default value: "disable"</i> l2 threshold crossing alerts
[no] dropped-frames-up	Parameter type: <Gpon::ErrorCountThreshold> Format: (disable <Gpon::ErrorCountThreshold>) Possible values: - disable : disable tca Field type <Gpon::ErrorCountThreshold> - error count threshold (0-4294967295) - range: [0...4294967295]	<i>optional parameter with default value: "disable"</i> incoming (upstream) dropped frames threshold
[no] dropped-frames-dn	Parameter type: <Gpon::ErrorCountThreshold> Format: (disable <Gpon::ErrorCountThreshold>) Possible values: - disable : disable tca Field type <Gpon::ErrorCountThreshold> - error count threshold (0-4294967295) - range: [0...4294967295]	<i>optional parameter with default value: "disable"</i> outgoing (downstream) dropped frames threshold

Command Output

Table 62.4-3 "Hpna ONT Uni Layer 2 Configuration Command" Display parameters

Specific Information		
name	Type	Description
pm-intervals	Parameter type: <SignedInteger> - a signed integer	number of rows currently present in the gponEtherTrafficIntervalTable <i>This element is only shown in detail mode.</i>

63- L2UNI Configuration Commands

63.1 L2UNI Configuration Command Tree	63-1733
63.2 L2 UNI ONT Performance Monitor Configuration Command	63-1734
63.3 L2 UNI ONT Performance Monitor Extended 32bit Configuration Command	63-1736
63.4 TC-layer Performance Monitoring Counter Thresholds Configuration Command for ONTL2UNI	63-1738

63.1 L2UNI Configuration Command Tree

Description

This chapter gives an overview of nodes that are handled by "L2UNI Configuration Commands".

Command Tree

```
----configure
  ----l2uni
    ----ont
      ----performance-monitor
        - (if-index)
        - [no] pm-collect
        - [no] pm-collect-64bit
      ----pm-collect-ext
        - [no] pm-collect
        - [no] p-bits
        - [no] vlan-id
      ----tc-layer-threshold
        - (if-index)
        - [no] dropped-frames-up
        - [no] dropped-frames-dn
```

63.2 L2 UNI ONT Performance Monitor Configuration Command

Command Description

This command sets the PM Mode of ONTL2UNI.

User Level

The command can be accessed by operators with equipment privileges, and executed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

```
> configure l2uni ont performance-monitor (if-index) [ no pm-collect | pm-collect <Gpon::OntPmTcaCollect> ] [
no pm-collect-64bit | pm-collect-64bit <Gpon::Ont64bitPmCollect> ]
```

Command Parameters

Table 63.2-1 "L2 UNI ONT Performance Monitor Configuration Command" Resource Parameters

Resource Identifier	Type	Description
(if-index)	Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Gpon::OntSlotId> / <Gpon::OntPortId> ng2 : <Ng2::ChannelGroup> / <Ng2::SubchannelGroup> / <Ng2::OntId> / <Gpon::OntSlotId> / <Gpon::OntPortId>) Possible values: - ng2 : ngpon2 style identification Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Ng2::ChannelGroup> - channel group number Field type <Ng2::SubchannelGroup> - subchannel group number Field type <Eqpt::OntId> - the ONT identifier Field type <Ng2::OntId> - the ONT identifier	interface index of the port

Resource Identifier	Type	Description
	Field type <Gpon::OntSlotId> - Gpon Ont Slot - range: [1...14] Field type <Gpon::OntPortId> - Gpon Ont Port - range: [1...16]	

Table 63.2-2 "L2 UNI ONT Performance Monitor Configuration Command" Command Parameters

Parameter	Type	Description
[no] pm-collect	Parameter type: <Gpon::OntPmTcaCollect> Format: (none pm-enable tca-enable) Possible values: - none : no pm - pm-enable : enable pm - tca-enable : enable tca	<i>optional parameter with default value: "none"</i> indicates whether Ethernet Traffic Performance Monitors should be collected for this Ethernet Port.
[no] pm-collect-64bit	Parameter type: <Gpon::Ont64bitPmCollect> Format: (none pm-enable) Possible values: - none : no pm - pm-enable : enable pm	<i>optional parameter with default value: "none"</i> indicates whether Ethernet Traffic Performance Monitors should be collected for this Ethernet Port.

63.3 L2 UNI ONT Performance Monitor Extended 32bit Configuration Command

Command Description

This command sets the PM EXT parameters.

User Level

The command can be accessed by operators with equipment privileges, and executed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

```
> configure l2uni ont performance-monitor (if-index) pm-collect-ext [ no pm-collect | pm-collect
<Gpon::OntPmCollect> ] [ no p-bits | p-bits <SignedInteger> ] [ no vlan-id | vlan-id <Vlan::VlanIndexOrZero> ]
```

Command Parameters

Table 63.3-1 "L2 UNI ONT Performance Monitor Extended 32bit Configuration Command" Resource Parameters

Resource Identifier	Type	Description
(if-index)	Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Gpon::OntSlotId> / <Gpon::OntPortId> ng2 : <Ng2::ChannelGroup> / <Ng2::SubchannelGroup> / <Ng2::OntId> / <Gpon::OntSlotId> / <Gpon::OntPortId>) Possible values: - ng2 : ngpon2 style identification Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Ng2::ChannelGroup> - channel group number Field type <Ng2::SubchannelGroup> - subchannel group number Field type <Eqpt::OntId> - the ONT identifier Field type <Ng2::OntId>	interface index of the port

Resource Identifier	Type	Description
	- the ONT identifier Field type <Gpon::OntSlotId> - Gpon Ont Slot - range: [1...14] Field type <Gpon::OntPortId> - Gpon Ont Port - range: [1...16]	

**Table 63.3-2 "L2 UNI ONT Performance Monitor Extended 32bit Configuration Command"
Command Parameters**

Parameter	Type	Description
[no] pm-collect	Parameter type: <Gpon::OntPmCollect> Format: (enable disable) Possible values: - enable : enable PM - disable : disable PM	<i>optional parameter with default value: "disable"</i> indicates whether enable this pm collect for this Ethernet Port
[no] p-bits	Parameter type: <SignedInteger> Format: - a signed integer	<i>optional parameter with default value: 0xFF</i> indicates the P bits of the TCI field are used to filter the PM data collected or not 0xFF: not used 0-7: p-bit used to filter data
[no] vlan-id	Parameter type: <Vlan::VlanIndexOrZero> Format: - vlan id - range: [0...4092]	<i>optional parameter with default value: 0</i> indicates the vlan-id bits of the TCI field are used to filter the PM data collected 0: not used Other value : this vlan-id used to filter data

63.4 TC-layer Performance Monitoring Counter Thresholds Configuration Command for ONTL2UNI

Command Description

This command allows the operator to enable configuration of performance Monitoring counter thresholds for ONTL2UNI.

User Level

The command can be accessed by operators with equipment privileges, and executed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

```
> configure l2uni ont tc-layer-threshold (if-index) [ no dropped-frames-up | dropped-frames-up
<Gpon::TcaThresholdValue> ] [ no dropped-frames-dn | dropped-frames-dn <Gpon::TcaThresholdValue> ]
```

Command Parameters

Table 63.4-1 "TC-layer Performance Monitoring Counter Thresholds Configuration Command for ONTL2UNI" Resource Parameters

Resource Identifier	Type	Description
(if-index)	Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Gpon::OntSlotId> / <Gpon::OntPortId> ng2 : <Ng2::ChannelGroup> / <Ng2::SubchannelGroup> / <Ng2::OntId> / <Gpon::OntSlotId> / <Gpon::OntPortId>) Possible values: - ng2 : ngpon2 style identification Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Ng2::ChannelGroup> - channel group number Field type <Ng2::SubchannelGroup> - subchannel group number Field type <Eqpt::OntId> - the ONT identifier	interface index of the port

Resource Identifier	Type	Description
	Field type <Ng2::OntId> - the ONT identifier Field type <Gpon::OntSlotId> - Gpon Ont Slot - range: [1...14] Field type <Gpon::OntPortId> - Gpon Ont Port - range: [1...16]	

Table 63.4-2 "TC-layer Performance Monitoring Counter Thresholds Configuration Command for ONTL2UNI" Command Parameters

Parameter	Type	Description
[no] dropped-frames-up	Parameter type: <Gpon::TcaThresholdValue> Format: (disabled <Gpon::TcaThresholdValue>) Possible values: - disabled : threshold is disabled Field type <Gpon::TcaThresholdValue> - tc-layer tca threshold value (4294967295=disabled) - range: [0...4294967294,4294967295]	<i>optional parameter with default value: "disabled"</i> tca setting for dropped frames in upstream
[no] dropped-frames-dn	Parameter type: <Gpon::TcaThresholdValue> Format: (disabled <Gpon::TcaThresholdValue>) Possible values: - disabled : threshold is disabled Field type <Gpon::TcaThresholdValue> - tc-layer tca threshold value (4294967295=disabled) - range: [0...4294967294,4294967295]	<i>optional parameter with default value: "disabled"</i> tca setting for dropped frames in downstream

64- IpHost Configuration Commands

64.1 IpHost Configuration Command Tree	64-1741
64.2 Voice Ont IP-Host Configuration Command	64-1742
64.3 Voice Ont IP-Host PM Mode Configuration Command	64-1746

64.1 IpHost Configuration Command Tree

Description

This chapter gives an overview of nodes that are handled by "IpHost Configuration Commands".

Command Tree

```
----configure
  ----[no] iphost
    ----[no] ont
      - (index)
      - [no] ip-address
      - [no] net-mask
      - [no] default-router
      - [no] dns-addr
      - [no] sec-dns-addr
      - [no] dhcp
      - [no] dhcp-dscp
      - [no] host-id
      - [no] ping
      - [no] traceroute
      - vlan
      - [no] admin-state
    ----performance-monitor
      - [no] pm-collect
```

64.2 Voice Ont IP-Host Configuration Command

Command Description

This command creates an IP host in the ONT. It must be created prior to creating services on an ONT that will use this IP stack.

Prior to entering this command the following must have been already created: S-VLAN to associate for this stack The ONT for this stack

If DHCP is enabled, the addressed obtain will override manual provisioning of ip-address, net-mask, default-router
NOTE: Allowable range for IP address is 0.0.0.0 to 255.255.255.255 OLT prohibits the entry of the following range of well-known IP addresses: 224.0.0.0 to 239.255.255.255 (multicast) 127.0.0.0 to 127.255.255.255 (loopback) 256.256.256.256 (broadcast)

User Level

The command can be accessed by operators with sip,megaco,vlan privileges, and executed by operators with sip,megaco,vlan privileges.

Command Syntax

The command has the following syntax:

```
> configure iphost ( no ont (index) ) | ( ont (index) [ no ip-address | ip-address <Gpon::Ipaddr> ] [ no net-mask |
net-mask <Gpon::Ipaddr> ] [ no default-router | default-router <Gpon::Ipaddr> ] [ no dns-addr | dns-addr
<Gpon::Ipaddr> ] [ no sec-dns-addr | sec-dns-addr <Gpon::Ipaddr> ] [ no dhcp | dhcp <Gpon::IpHostDhcp> ] [ no
dhcp-dscp | dhcp-dscp <Gpon::SigDscp> ] [ no host-id | host-id <Gpon::ClientID> ] [ no ping | ping <Gpon::Ping>
] [ no traceroute | traceroute <Gpon::Traceroute> ] [ vlan <Vlan::Index> ] [ no admin-state | admin-state
<Gpon::ItfAdminStatus> ] )
```

Command Parameters

Table 64.2-1 "Voice Ont IP-Host Configuration Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: (ont : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Gpon::IpHostID> vlanport : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / vuni : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlanport : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / vuni : <Eqpt::UnstackedVlan> ont.ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / <Ng2::IpHostID> vlanport.ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / vuni : stacked : <Eqpt::SVlan> : <Eqpt::CVlan>	a unique interface index

Resource Identifier	Type	Description
	vlanport:ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / vuni : <Eqpt::UnstackedVlan>) Possible values: - ont:ng2 : ngpon2 ont - vlanport:ng2 : ngpon2 vlanport - ont : ont - vlanport : vlanport Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Eqpt::OntId> - the ONT identifier Field type <Eqpt::ChannelGroupId> - the channel group identifier Field type <Eqpt::SubChannelGroupId> - the subchannel group identifier Field type <Eqpt::Ng2OntId> - the NG2 ONT identifier Possible values: - vuni : virtual uni identifier Possible values: - vuni : virtual NGPON2 uni identifier Field type <Gpon::IpHostID> - iphost id Field type <Ng2::IpHostID> - iphost id (ngpon2) Possible values: - stacked : stacked vlan identity Field type <Eqpt::UnstackedVlan> - unstacked vlan id Field type <Eqpt::SVlan> - service vlan id Field type <Eqpt::CVlan> - customer vlan id	

Table 64.2-2 "Voice Ont IP-Host Configuration Command" Command Parameters

Parameter	Type	Description
[no] ip-address	Parameter type: <Gpon::Ipaddr> Format: - IPv4-address	<i>optional parameter with default value: "0.0.0.0"</i> IP address of the IP Host at the ONT. Note: IP@ and net-mask are required parameters and need to be entered at the same time.
[no] net-mask	Parameter type: <Gpon::Ipaddr> Format: - IPv4-address	<i>optional parameter with default value: "0.0.0.0"</i> IP address network mask of the IP Host at the ONT. Note: IP@ and net-mask are required parameters and need to be entered at the same time.
[no] default-router	Parameter type: <Gpon::Ipaddr>	<i>optional parameter with default</i>

64 IpHost Configuration Commands

Parameter	Type	Description
	Format: - IPv4-address	value: "0.0.0.0" IP address of the default router
[no] dns-addr	Parameter type: <Gpon::Ipaddr> Format: - IPv4-address	optional parameter with default value: "0.0.0.0" address of the primary DNS server(when dhcp is disabled)
[no] sec-dns-addr	Parameter type: <Gpon::Ipaddr> Format: - IPv4-address	optional parameter with default value: "0.0.0.0" address of the secondary DNS server(when dhcp is disabled)
[no] dhcp	Parameter type: <Gpon::IpHostDhcp> Format: (enabled disabled) Possible values: - enabled : DHCP is enabled - disabled : DHCP is disabled	optional parameter with default value: "disabled" designate whether DHCP is enabled
[no] dhcp-dscp	Parameter type: <Gpon::SigDscp> Format: - dscp value - range: [0...63]	optional parameter with default value: 24 dscp value for use in outgoing dhcp packets
[no] host-id	Parameter type: <Gpon::ClientID> Format: - to uniquely identify the VoIP Client. - length: x<=25	optional parameter with default value: "" dhcp option 61 clientid associated with the ip host
[no] ping	Parameter type: <Gpon::Ping> Format: (enabled disabled) Possible values: - enabled : enable the ping facility - disabled : disable the ping facility	optional parameter with default value: "disabled" determines whether host should respond to ping
[no] traceroute	Parameter type: <Gpon::Traceroute> Format: (enabled disabled) Possible values: - enabled : enable the traceroute facility - disabled : disable the traceroute facility	optional parameter with default value: "disabled" determines whether host should respond to traceroute messages
vlan	Parameter type: <Vlan::Index> Format: (<Vlan::UVlanIndex> stacked : <Vlan::SVlanIndexStacked> <Vlan::CVlanIndex>) Possible values: - stacked : stacked vlan identity Field type <Vlan::UVlanIndex> - unstacked vlan identity - range: [1...4093,4096] Field type <Vlan::SVlanIndexStacked> - service vlan identity - range: [1...4093] Field type <Vlan::CVlanIndex> - customer vlan identity - range: [0...4093]	optional parameter The parameter is not visible during modification. vlan-id
[no] admin-state	Parameter type: <Gpon::ItfAdminStatus> Format:	optional parameter with default value: "up"

Parameter	Type	Description
	(up down) Possible values: - up : set the admin-state to up - down : set the admin-state to down	<i>The parameter is not visible during creation.</i> administrative state of the interface

Command Output

Table 64.2-3 "Voice Ont IP-Host Configuration Command" Display parameters

Specific Information		
name	Type	Description
oper-state	Parameter type: <Itf::ifOperStatus> (up down testing unknown dormant no-value) Possible values: - up : up,traffic can pass - down : down,no traffic is passing - testing : testing,no traffic is passing - unknown : unknown - dormant : dormant,no traffic is passing - no-value : no entry in the table	operational state of the interface <i>This element is always shown.</i>

64.3 Voice Ont IP-Host PM Mode Configuration Command

Command Description

This command allows the operator to configure the PM Mode of ONT IP Host monitoring

User Level

The command can be accessed by operators with sip,megaco privileges, and executed by operators with sip,megaco privileges.

Command Syntax

The command has the following syntax:

```
> configure iphost ont (index) performance-monitor [ no pm-collect | pm-collect <Gpon::PmEnable> ]
```

Command Parameters

Table 64.3-1 "Voice Ont IP-Host PM Mode Configuration Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: (ont : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Gpon::IpHostID> vlanport : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / vuni : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlanport : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / vuni : <Eqpt::UnstackedVlan> ont:ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / <Ng2::IpHostID> vlanport:ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / vuni : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlanport:ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / vuni : <Eqpt::UnstackedVlan>) Possible values: - ont:ng2 : ngpon2 ont - vlanport:ng2 : ngpon2 vlanport - ont : ont - vlanport : vlanport Field type <Eqpt::RackId> - the rack number	a unique interface index

Resource Identifier	Type	Description
	Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Eqpt::OntId> - the ONT identifier Field type <Eqpt::ChannelGroupId> - the channel group identifier Field type <Eqpt::SubChannelGroupId> - the subchannel group identifier Field type <Eqpt::Ng2OntId> - the NG2 ONT identifier Possible values: - vuni : virtual uni identifier Possible values: - vuni : virtual NGPON2 uni identifier Field type <Gpon::IpHostID> - iphost id Field type <Ng2::IpHostID> - iphost id (ngpon2) Possible values: - stacked : stacked vlan identity Field type <Eqpt::UnstackedVlan> - unstacked vlan id Field type <Eqpt::SVlan> - service vlan id Field type <Eqpt::CVlan> - customer vlan id	

Table 64.3-2 "Voice Ont IP-Host PM Mode Configuration Command" Command Parameters

Parameter	Type	Description
[no] pm-collect	Parameter type: <Gpon::PmEnable> Format: (disable enable) Possible values: - disable : disable the collection - enable : enable the collection	<i>optional parameter with default value: "disable"</i>

65- ONT VEIP Configuration Commands

65.1 ONT VEIP Configuration Command Tree	65-1749
65.2 ONT VEIP Configuration Command	65-1750
65.3 ONT VEIP Port L2 Performance Monitoring Configuration Command	65-1752
65.4 Veip ONT Uni Layer 2 Configuration Command	65-1754
65.5 L2 UNI ONT Performance Monitor Extended 32bit Configuration Command	65-1757

65.1 ONT VEIP Configuration Command Tree

Description

This chapter gives an overview of nodes that are handled by "ONT VEIP Configuration Commands".

Command Tree

```

----configure
  ----veip
    ----ont
      - (uni-idx)
      - [no] domain-name
      - [no] lpt-mode
      - [no] admin-state
      ----X port
        - [no] pm-collect
      ----l2
        - [no] pm
        - [no] pm-64bit
        - [no] tca
        - [no] dropped-frames-up
        - [no] dropped-frames-dn
      ----pm-ext
        - [no] pm-collect
        - [no] p-bits
        - [no] vlan-id

```

65.2 ONT VEIP Configuration Command

Command Description

This command allows the operator to modify ONT VEIP port provisioning data.

User Level

The command can be accessed by operators with equipment privileges, and executed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

```
> configure veip ont (uni-idx) [ no domain-name | domain-name <Gpon::DomainName> ] [ no lpt-mode | lpt-mode <Gpon::LPTMODE> ] [ no admin-state | admin-state <Gpon::ItfAdminStatus> ]
```

Command Parameters

Table 65.2-1 "ONT VEIP Configuration Command" Resource Parameters

Resource Identifier	Type	Description
(uni-idx)	Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Gpon::OntSlotId> / <Gpon::OntPortId> ng2 : <Ng2::ChannelGroup> / <Ng2::SubchannelGroup> / <Ng2::OntId> / <Gpon::OntSlotId> / <Gpon::OntPortId>) Possible values: - ng2 : ngpon2 style identification Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Ng2::ChannelGroup> - channel group number Field type <Ng2::SubchannelGroup> - subchannel group number Field type <Eqpt::OntId> - the ONT identifier Field type <Ng2::OntId> - the ONT identifier Field type <Gpon::OntSlotId> - Gpon Ont Slot - range: [1...14]	identification of the uni interface index

Resource Identifier	Type	Description
	Field type <Gpon::OntPortId> - Gpon Ont Port - range: [1...16]	

Table 65.2-2 "ONT VEIP Configuration Command" Command Parameters

Parameter	Type	Description
[no] domain-name	Parameter type: <Gpon::DomainName> Format: - to uniquely identify the VEIP Client. - length: x<=25	<i>optional parameter with default value: "none"</i> Domain Name to identify VEIP
[no] lpt-mode	Parameter type: <Gpon::LPTMODE> Format: (not-supported enabled disabled) Possible values: - not-supported : ignore and don't send the configuration to ONT - enabled : enable the LPT mode on this port - disabled : disable the LPT mode on this port	<i>optional parameter with default value: "not-supported"</i> LinkPassThrough(LPT) mode configuration
[no] admin-state	Parameter type: <Gpon::ItfAdminStatus> Format: (up down) Possible values: - up : set the admin-state to up - down : set the admin-state to down	<i>optional parameter with default value: "down"</i> <i>The parameter is not visible during creation.</i> administrative status of the interface

Command Output

Table 65.2-3 "ONT VEIP Configuration Command" Display parameters

Specific Information		
name	Type	Description
oper-state	Parameter type: <Itf::ifOperStatus> (up down testing unknown dormant no-value) Possible values: - up : up,traffic can pass - down : down,no traffic is passing - testing : testing,no traffic is passing - unknown : unknown - dormant : dormant,no traffic is passing - no-value : no entry in the table	the operational state of the interface <i>This element is always shown.</i>

65.3 ONT VEIP Port L2 Performance Monitoring Configuration Command

Command Description

Obsolete command, replaced by `configure veip ont l2 pm`.

This command allows the operator to enable or disable PM on the VEIP layer 2 ports of the ONT.

User Level

The command can be accessed by operators with equipment privileges, and executed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

```
> configure veip ont (uni-idx) port [ no pm-collect | pm-collect <Gpon::OntPmCollect> ]
```

Obsolete command, replaced by `configure veip ont l2 pm`.

Command Parameters

Table 65.3-1 "ONT VEIP Port L2 Performance Monitoring Configuration Command" Resource Parameters

Resource Identifier	Type	Description
(uni-idx)	Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Gpon::OntSlotId> / <Gpon::OntPortId> ng2 : <Ng2::ChannelGroup> / <Ng2::SubchannelGroup> / <Ng2::OntId> / <Gpon::OntSlotId> / <Gpon::OntPortId>) Possible values: - ng2 : ngpon2 style identification Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Ng2::ChannelGroup> - channel group number Field type <Ng2::SubchannelGroup> - subchannel group number Field type <Eqpt::OntId>	identification of the uni interface index

Resource Identifier	Type	Description
	- the ONT identifier Field type <Ng2::OntId> - the ONT identifier Field type <Gpon::OntSlotId> - Gpon Ont Slot - range: [1...14] Field type <Gpon::OntPortId> - Gpon Ont Port - range: [1...16]	

Table 65.3-2 "ONT VEIP Port L2 Performance Monitoring Configuration Command" Command Parameters

Parameter	Type	Description
[no] pm-collect	Parameter type: <Gpon::OntPmCollect> Format: (enable disable) Possible values: - enable : enable PM - disable : disable PM	<i>optional parameter with default value: "disable"</i> veip port layer 2 performance monitoring

65.4 Veip ONT Uni Layer 2 Configuration Command

Command Description

This command allows the operator to provision performance monitoring and threshold crossing alerts for an Veip ONT layer 2 UNI.

User Level

The command can be accessed by operators with equipment privileges, and executed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

```
> configure veip ont (uni-idx) l2 [ no pm | pm <Gpon::OntPmCollect> ] [ no pm-64bit | pm-64bit
<Gpon::OntPmCollect> ] [ no tca | tca <Gpon::OntPmCollect> ] [ no dropped-frames-up | dropped-frames-up
<Gpon::ErrorCountThreshold> ] [ no dropped-frames-dn | dropped-frames-dn <Gpon::ErrorCountThreshold> ]
```

Command Parameters

Table 65.4-1 "Veip ONT Uni Layer 2 Configuration Command" Resource Parameters

Resource Identifier	Type	Description
(uni-idx)	Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Gpon::OntSlotId> / <Gpon::OntPortId>) ng2 : <Ng2::ChannelGroup> / <Ng2::SubchannelGroup> / <Ng2::OntId> / <Gpon::OntSlotId> / <Gpon::OntPortId>) Possible values: - ng2 : ngpon2 style identification Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Ng2::ChannelGroup> - channel group number Field type <Ng2::SubchannelGroup> - subchannel group number Field type <Eqpt::OntId> - the ONT identifier Field type <Ng2::OntId> - the ONT identifier Field type <Gpon::OntSlotId>	identification of the uni interface index

Resource Identifier	Type	Description
	- Gpon Ont Slot - range: [1...14] Field type <Gpon::OntPortId> - Gpon Ont Port - range: [1...16]	

Table 65.4-2 "Veip ONT Uni Layer 2 Configuration Command" Command Parameters

Parameter	Type	Description
[no] pm	Parameter type: <Gpon::OntPmCollect> Format: (enable disable) Possible values: - enable : enable PM - disable : disable PM	<i>optional parameter with default value: "disable"</i> l2 pm collection
[no] pm-64bit	Parameter type: <Gpon::OntPmCollect> Format: (enable disable) Possible values: - enable : enable PM - disable : disable PM	<i>optional parameter with default value: "disable"</i> l2 pm-64bit collection
[no] tca	Parameter type: <Gpon::OntPmCollect> Format: (enable disable) Possible values: - enable : enable PM - disable : disable PM	<i>optional parameter with default value: "disable"</i> l2 threshold crossing alerts
[no] dropped-frames-up	Parameter type: <Gpon::ErrorCountThreshold> Format: (disable <Gpon::ErrorCountThreshold>) Possible values: - disable : disable tca Field type <Gpon::ErrorCountThreshold> - error count threshold (0-4294967295) - range: [0...4294967295]	<i>optional parameter with default value: "disable"</i> incoming (upstream) dropped frames threshold
[no] dropped-frames-dn	Parameter type: <Gpon::ErrorCountThreshold> Format: (disable <Gpon::ErrorCountThreshold>) Possible values: - disable : disable tca Field type <Gpon::ErrorCountThreshold> - error count threshold (0-4294967295) - range: [0...4294967295]	<i>optional parameter with default value: "disable"</i> outgoing (downstream) dropped frames threshold

Command Output

Table 65.4-3 "Veip ONT Uni Layer 2 Configuration Command" Display parameters

Specific Information		
name	Type	Description
pm-intervals	Parameter type: <SignedInteger> - a signed integer	number of rows currently present in the gponEtherTrafficIntervalTable

65 ONT VEIP Configuration Commands

name	Type	Description
		<i>This element is only shown in detail mode.</i>

65.5 L2 UNI ONT Performance Monitor Extended 32bit Configuration Command

Command Description

This command sets the PM EXT parameters.

User Level

The command can be accessed by operators with equipment privileges, and executed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

```
> configure veip ont (uni-idx) l2 pm-ext [ no pm-collect | pm-collect <Gpon::OntPmCollect> ] [ no p-bits | p-bits <SignedInteger> ] [ no vlan-id | vlan-id <Vlan::VlanIndexOrZero> ]
```

Command Parameters

Table 65.5-1 "L2 UNI ONT Performance Monitor Extended 32bit Configuration Command" Resource Parameters

Resource Identifier	Type	Description
(uni-idx)	Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Gpon::OntSlotId> / <Gpon::OntPortId> ng2 : <Ng2::ChannelGroup> / <Ng2::SubchannelGroup> / <Ng2::OntId> / <Gpon::OntSlotId> / <Gpon::OntPortId>) Possible values: - ng2 : ngpon2 style identification Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Ng2::ChannelGroup> - channel group number Field type <Ng2::SubchannelGroup> - subchannel group number Field type <Eqpt::OntId> - the ONT identifier Field type <Ng2::OntId>	identification of the uni interface index

Resource Identifier	Type	Description
	- the ONT identifier Field type <Gpon::OntSlotId> - Gpon Ont Slot - range: [1...14] Field type <Gpon::OntPortId> - Gpon Ont Port - range: [1...16]	

**Table 65.5-2 "L2 UNI ONT Performance Monitor Extended 32bit Configuration Command"
Command Parameters**

Parameter	Type	Description
[no] pm-collect	Parameter type: <Gpon::OntPmCollect> Format: (enable disable) Possible values: - enable : enable PM - disable : disable PM	<i>optional parameter with default value: "disable"</i> indicates whether enable this pm collect for this veip Port
[no] p-bits	Parameter type: <SignedInteger> Format: - a signed integer	<i>optional parameter with default value: 0xFF</i> indicates the P bits of the TCI field are used to filter the PM data collected or not 0xFF: not used 0-7: p-bit used to filter data
[no] vlan-id	Parameter type: <Vlan::VlanIndexOrZero> Format: - vlan id - range: [0...4092]	<i>optional parameter with default value: 0</i> indicates the vlan-id bits of the TCI field are used to filter the PM data collected 0: not used Other value : this vlan-id used to filter data

66- MoCA Configuration Commands

66.1 MoCA Configuration Command Tree	66-1760
66.2 MoCA ONT Uni Configuration Command	66-1761
66.3 MoCA ONT Uni Physical Layer Configuration Command	66-1764
66.4 MoCA ONT Uni Layer 2 Configuration Command	66-1766

66.1 MoCA Configuration Command Tree

Description

This chapter gives an overview of nodes that are handled by "MoCA Configuration Commands".

Command Tree

```
----configure
  ----moca
    ----ont
      - (uni-idx)
      - [no] cust-info
      - [no] tx-pwr
      - [no] net-coord
      - [no] snr-margin
      - [no] password
      - [no] privacy
      - [no] bw-alarm-thresh
      - [no] auto-pwr-ctl
      - [no] pwr-override
      - [no] admin-state
    ----phy
      - [no] pm
      - [no] tca
      - [no] rx-err
    ----l2
      - [no] pm
      - [no] tca
      - [no] dropped-frames-up
      - [no] dropped-frames-dn
```

66.2 MoCA ONT Uni Configuration Command

Command Description

This command configures a MoCA ONT uni.

User Level

The command can be accessed by operators with equipment privileges, and executed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

```
> configure moca ont (uni-idx) [ no cust-info | cust-info <Gpon::CustInfo> ] [ no tx-pwr | tx-pwr <Moca::TxPwr> ]
[ no net-coord | net-coord <Moca::NetworkCoordinator> ] [ no snr-margin | snr-margin
<Moca::SignalToNoiseRatioMargin> ] [ no password | password <Moca::Password> ] [ no privacy | privacy
<Moca::Privacy> ] [ no bw-alarm-thresh | bw-alarm-thresh <Moca::minBwAlarmThreshold> ] [ no auto-pwr-ctl |
auto-pwr-ctl <Moca::AutomaticPowerControl> ] [ no pwr-override | pwr-override <Gpon::PowerShedOverride> ] [
no admin-state | admin-state <Gpon::ItfAdminStatus> ]
```

Command Parameters

Table 66.2-1 "MoCA ONT Uni Configuration Command" Resource Parameters

Resource Identifier	Type	Description
(uni-idx)	Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Gpon::OntSlotId> / <Gpon::OntPortId> ng2 : <Ng2::ChannelGroup> / <Ng2::SubchannelGroup> / <Ng2::OntId> / <Gpon::OntSlotId> / <Gpon::OntPortId>) Possible values: - ng2 : ngpon2 style identification Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Ng2::ChannelGroup> - channel group number Field type <Ng2::SubchannelGroup> - subchannel group number Field type <Eqpt::OntId> - the ONT identifier Field type <Ng2::OntId>	identification of the uni interface index

Resource Identifier	Type	Description
	- the ONT identifier Field type <Gpon::OntSlotId> - Gpon Ont Slot - range: [1...14] Field type <Gpon::OntPortId> - Gpon Ont Port - range: [1...16]	

Table 66.2-2 "MoCA ONT Uni Configuration Command" Command Parameters

Parameter	Type	Description
[no] cust-info	Parameter type: <Gpon::CustInfo> Format: - a printable string - length: x<=80	optional parameter with default value: "" port label
[no] tx-pwr	Parameter type: <Moca::TxPwr> Format: - transmitter power level in dBm - range: [-31...0]	optional parameter with default value: -14L target transmitter power level (dBm)
[no] net-coord	Parameter type: <Moca::NetworkCoordinator> Format: (auto always never) Possible values: - auto : negotiate for network coordinator - always : always be the network coordinator - never : never be the network coordinator	optional parameter with default value: "auto" moca network coordinating role
[no] snr-margin	Parameter type: <Moca::SignalToNoiseRatioMargin> Format: - threshold above measured rx noise floor in dBm - range: [-3...3]	optional parameter with default value: 2L margin above Rx noise floor for variations in return loss (dBm)
[no] password	Parameter type: <Moca::Password> Format: - hidden moca encryption key - length: x<=17	optional parameter with default value: "" hidden moca encryption key (0-17 numeric characters)
[no] privacy	Parameter type: <Moca::Privacy> Format: (enable disable) Possible values: - enable : link-layer security activated - disable : link-layer security deactivated	optional parameter with default value: "disable" link layer security
[no] bw-alarm-thresh	Parameter type: <Moca::minBwAlarmThreshold> Format: (disable <Moca::minBwAlarmThreshold>) Possible values: - disable : disable bw threshold alarm Field type <Moca::minBwAlarmThreshold> - minimum phy link bandwidth (Mbps) between two nodes - range: [0,57...3200]	optional parameter with default value: 180L minimum phy link bandwidth between two nodes (Mbps)
[no] auto-pwr-ctl	Parameter type: <Moca::AutomaticPowerControl> Format: (enable disable) Possible values: - enable : apc enabled	optional parameter with default value: "enable" automatic power control

Parameter	Type	Description
[no] pwr-override	- disable : apc disabled Parameter type: <Gpon::PowerShedOverride> Format: (enable disable) Possible values: - enable : port is excluded from data class power shedding - disable : port is included in data class power shedding	<i>optional parameter with default value: "disable"</i> power shed override
[no] admin-state	Parameter type: <Gpon::ItfAdminStatus> Format: (up down) Possible values: - up : set the admin-state to up - down : set the admin-state to down	<i>optional parameter with default value: "down"</i> <i>The parameter is not visible during creation.</i> administrative status of the interface

Command Output

Table 66.2-3 "MoCA ONT Uni Configuration Command" Display parameters

Specific Information		
name	Type	Description
oper-state	Parameter type: <Itf::ifOperStatus> (up down testing unknown dormant no-value) Possible values: - up : up,traffic can pass - down : down,no traffic is passing - testing : testing,no traffic is passing - unknown : unknown - dormant : dormant,no traffic is passing - no-value : no entry in the table	operational state of the interface <i>This element is always shown.</i>

66.3 MoCA ONT Uni Physical Layer Configuration Command

Command Description

This command allows the operator to provision performance monitoring and threshold crossing alerts for a MoCA ONT physical layer UNI.

User Level

The command can be accessed by operators with equipment privileges, and executed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

```
> configure moca ont (uni-idx) phy [ no pm | pm <Gpon::OntPmCollect> ] [ no tca | tca <Gpon::OntPmCollect> ] [ no rx-err | rx-err <Gpon::ErrorCountThreshold> ]
```

Command Parameters

Table 66.3-1 "MoCA ONT Uni Physical Layer Configuration Command" Resource Parameters

Resource Identifier	Type	Description
(uni-idx)	Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Gpon::OntSlotId> / <Gpon::OntPortId> ng2 : <Ng2::ChannelGroup> / <Ng2::SubchannelGroup> / <Ng2::OntId> / <Gpon::OntSlotId> / <Gpon::OntPortId>) Possible values: - ng2 : ngpon2 style identification Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Ng2::ChannelGroup> - channel group number Field type <Ng2::SubchannelGroup> - subchannel group number Field type <Eqpt::OntId> - the ONT identifier Field type <Ng2::OntId>	identification of the uni interface index

Resource Identifier	Type	Description
	- the ONT identifier Field type <Gpon::OntSlotId> - Gpon Ont Slot - range: [1...14] Field type <Gpon::OntPortId> - Gpon Ont Port - range: [1...16]	

Table 66.3-2 "MoCA ONT Uni Physical Layer Configuration Command" Command Parameters

Parameter	Type	Description
[no] pm	Parameter type: <Gpon::OntPmCollect> Format: (enable disable) Possible values: - enable : enable PM - disable : disable PM	<i>optional parameter with default value: "disable"</i> physical layer pm collection
[no] tca	Parameter type: <Gpon::OntPmCollect> Format: (enable disable) Possible values: - enable : enable PM - disable : disable PM	<i>optional parameter with default value: "disable"</i> physical layer threshold crossing alerts
[no] rx-err	Parameter type: <Gpon::ErrorCountThreshold> Format: (disable <Gpon::ErrorCountThreshold>) Possible values: - disable : disable tca Field type <Gpon::ErrorCountThreshold> - error count threshold (0-4294967295) - range: [0...4294967295]	<i>optional parameter with default value: "disable"</i> incoming (upstream) errored packet threshold

Command Output

Table 66.3-3 "MoCA ONT Uni Physical Layer Configuration Command" Display parameters

Specific Information		
name	Type	Description
pm-intervals	Parameter type: <SignedInteger> - a signed integer	number of rows currently present in the mocalfIntervalTable <i>This element is only shown in detail mode.</i>

66.4 MoCA ONT Uni Layer 2 Configuration Command

Command Description

This command allows the operator to provision performance monitoring and threshold crossing alerts for a MoCA ONT layer 2 UNI.

User Level

The command can be accessed by operators with equipment privileges, and executed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

```
> configure moca ont (uni-idx) l2 [ no pm | pm <Gpon::OntPmCollect> ] [ no tca | tca <Gpon::OntPmCollect> ] [
no dropped-frames-up | dropped-frames-up <Gpon::ErrorCountThreshold> ] [ no dropped-frames-dn |
dropped-frames-dn <Gpon::ErrorCountThreshold> ]
```

Command Parameters

Table 66.4-1 "MoCA ONT Uni Layer 2 Configuration Command" Resource Parameters

Resource Identifier	Type	Description
(uni-idx)	Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Gpon::OntSlotId> / <Gpon::OntPortId> ng2 : <Ng2::ChannelGroup> / <Ng2::SubchannelGroup> / <Ng2::OntId> / <Gpon::OntSlotId> / <Gpon::OntPortId>) Possible values: - ng2 : ngpon2 style identification Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Ng2::ChannelGroup> - channel group number Field type <Ng2::SubchannelGroup> - subchannel group number Field type <Eqpt::OntId> - the ONT identifier	identification of the uni interface index

Resource Identifier	Type	Description
	Field type <Ng2::OntId> - the ONT identifier Field type <Gpon::OntSlotId> - Gpon Ont Slot - range: [1...14] Field type <Gpon::OntPortId> - Gpon Ont Port - range: [1...16]	

Table 66.4-2 "MoCA ONT Uni Layer 2 Configuration Command" Command Parameters

Parameter	Type	Description
[no] pm	Parameter type: <Gpon::OntPmCollect> Format: (enable disable) Possible values: - enable : enable PM - disable : disable PM	<i>optional parameter with default value: "disable"</i> l2 pm collection
[no] tca	Parameter type: <Gpon::OntPmCollect> Format: (enable disable) Possible values: - enable : enable PM - disable : disable PM	<i>optional parameter with default value: "disable"</i> l2 threshold crossing alerts
[no] dropped-frames-up	Parameter type: <Gpon::ErrorCountThreshold> Format: (disable <Gpon::ErrorCountThreshold>) Possible values: - disable : disable tca Field type <Gpon::ErrorCountThreshold> - error count threshold (0-4294967295) - range: [0...4294967295]	<i>optional parameter with default value: "disable"</i> incoming (upstream) dropped frames threshold
[no] dropped-frames-dn	Parameter type: <Gpon::ErrorCountThreshold> Format: (disable <Gpon::ErrorCountThreshold>) Possible values: - disable : disable tca Field type <Gpon::ErrorCountThreshold> - error count threshold (0-4294967295) - range: [0...4294967295]	<i>optional parameter with default value: "disable"</i> outgoing (downstream) dropped frames threshold

Command Output

Table 66.4-3 "MoCA ONT Uni Layer 2 Configuration Command" Display parameters

Specific Information		
name	Type	Description
pm-intervals	Parameter type: <SignedInteger> - a signed integer	number of rows currently present in the gponEtherTrafficIntervalTable <i>This element is only shown in detail mode.</i>

67- Configure NTP parameters on a specific ONT

67.1 Configure NTP parameters on a specific ONT Tree	67-1769
67.2 Configure NTP parameters on a specific ONT	67-1770

67.1 Configure NTP parameters on a specific ONT Tree

Description

This chapter gives an overview of nodes that are handled by "Configure NTP parameters on a specific ONT".

Command Tree

```
----configure
  ----ntp
    ----[no] ont
      - (ont-idx)
      - [no] client-state
      - [no] config-mode
      - [no] server1-ip-addr
      - [no] server2-ip-addr
      - [no] server3-ip-addr
      - [no] oper-mode
      - [no] key-identifier
      - [no] key
```

67.2 Configure NTP parameters on a specific ONT

Command Description

This command sets the NTP parameters on a specific ONT, in case of server1-ip-addr, server2-ip-addr and server3-ip-addr, following range of ip-addresses are not allowed: 127.0.0.0 to 127.255.255.255 (loopback)

User Level

The command can be accessed by operators with equipment privileges, and executed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

```
> configure ntp ( no ont (ont-idx) ) | ( ont (ont-idx) [ no client-state | client-state <Gpon::ClientState> ] [ no
config-mode | config-mode <Gpon::ConfigMode> ] [ no server1-ip-addr | server1-ip-addr <Gpon::Ipaddr> ] [ no
server2-ip-addr | server2-ip-addr <Gpon::Ipaddr> ] [ no server3-ip-addr | server3-ip-addr <Gpon::Ipaddr> ] [ no
oper-mode | oper-mode <Gpon::OperMode> ] [ no key-identifier | key-identifier <Gpon::KeyIdIdentifier> ] [ no key |
key <Gpon::OntNtpKey> ] )
```

Command Parameters

Table 67.2-1 "Configure NTP parameters on a specific ONT" Resource Parameters

Resource Identifier	Type	Description
(ont-idx)	Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> ng2 : <Ng2::ChannelGroup> / <Ng2::SubchannelGroup> / <Ng2::OntId>) Possible values: - ng2 : ngpon2 style identification Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Ng2::ChannelGroup> - channel group number Field type <Ng2::SubchannelGroup> - subchannel group number Field type <Eqpt::OntId> - the ONT identifier Field type <Ng2::OntId> - the ONT identifier	identification of the ont

Table 67.2-2 "Configure NTP parameters on a specific ONT" Command Parameters

Parameter	Type	Description
[no] client-state	Parameter type: <Gpon::ClientState> Format: (on off) Possible values: - on : indicates ntp Client On - off : indicates ntp Client Off	<i>optional parameter with default value: "off"</i> indicates whether ntp client should be on or off
[no] config-mode	Parameter type: <Gpon::ConfigMode> Format: (dhcp manual) Possible values: - dhcp : dhcp mode - manual : manual	<i>optional parameter with default value: "dhcp"</i> used to designate whether dhcp is designated as the method by which the ont obtains ntp server addresses
[no] server1-ip-addr	Parameter type: <Gpon::Ipaddr> Format: - IPv4-address	<i>optional parameter with default value: "0.0.0.0"</i> ip address of the 1st ntp server.
[no] server2-ip-addr	Parameter type: <Gpon::Ipaddr> Format: - IPv4-address	<i>optional parameter with default value: "0.0.0.0"</i> ip address of the second ntp server.
[no] server3-ip-addr	Parameter type: <Gpon::Ipaddr> Format: - IPv4-address	<i>optional parameter with default value: "0.0.0.0"</i> ip Address of the third ntp server
[no] oper-mode	Parameter type: <Gpon::OperMode> Format: (unicast multicast broadcast) Possible values: - unicast : unicast mode of operation - multicast : multicast mode of operation - broadcast : broadcast mode of operation	<i>optional parameter with default value: "unicast"</i> ntp mode of operation
[no] key-identifier	Parameter type: <Gpon::KeyIdentifier> Format: - key that should be used by the ntp server - range: [0...65535]	<i>optional parameter with default value: 0</i> specifies the key that should be used by the ntp server
[no] key	Parameter type: <Gpon::OntNtpKey> Format: - actual key used by the ont - length: x<=16	<i>optional parameter with default value: ""</i> specifies the actual key used by the ont

68- Channel Pair Configuration Commands

68.1 Channel Pair Configuration Command Tree	68-1773
68.2 Channel Pair Profiles Configuration Command	68-1775
68.3 Channel-Pair Wavelength Profile Configuration Command	68-1776
68.4 Channel Pair Interface Configuration Command	68-1778
68.5 Channel Pair XGEM Port Performance Monitoring Configuration Command	68-1782
68.6 OLT-SIDE TC-layer Performance Monitoring Counter Thresholds Configuration Command for channel pair	68-1784
68.7 Multicast TC-layer Performance Monitoring Command for channel pair	68-1786
68.8 NGPON2 Physical-layer Performance Monitoring Command for channel pair	68-1788
68.9 NGPON2 Upstream FEC Performance Monitoring Command for channel pair	68-1790
68.10 NGPON2 TC-layer Performance Monitoring Command for channel pair	68-1792
68.11 Trouble shooting Configuration Command	68-1794
68.12 Trouble-shooting Interface Configuration Commands	68-1795
68.13 Trouble shooting Configuration Command	68-1796
68.14 Channel Pair Utilization PM Configuration Command	68-1797
68.15 Channel Pair Utilization TCA Threshold Configuration Command	68-1799
68.16 Deactivate Ont threshold Configuration Commands	68-1805
68.17 Deactivate Ont threshold Configuration Commands	68-1807
68.18 Deactivate Ont threshold Configuration Commands	68-1809
68.19 Trouble-Shooting threshold Configuration Commands	68-1811

68.1 Channel Pair Configuration Command Tree

Description

This chapter gives an overview of nodes that are handled by "Channel Pair Configuration Commands".

Command Tree

```

----configure
  ----channel-pair
    ----profiles
      ----[no] wavelength-prof
        - (profile-idx)
        - name
        - upstream-channel-id
        - downstream-channel-id
        - downstream-lambda
    ----interface
      - (chanpair-idx)
      - [no] label
      - [no] pon-tag
      - [no] x-pon-id
      - [no] max-ranging-onts
      - [no] tconts-per-frame
      - [no] ber-calc-period
      - [no] sig-degrade-th
      - [no] sig-fail-th
      - [no] wavelength-prof
      - [no] channel-speed
      - [no] burst-overhead
      - [no] admin-label
      - [no] onu-prov-mode
      - [no] admin-state
    ----tc-layer
      - [no] pm-collect
    ----tc-layer-threshold
      - [no] error-frags-up
    ----mcast-tc-layer
      - [no] pm-collect
    ----phy-layer
      - [no] pm-collect
    ----fec-tc-layer
      - [no] pm-collect
    ----xg-tc-layer
      - [no] pm-collect
    ----troubleshooting
      ----[no] enable
      ----threshold
        - [no] upstr-bw-thresh
        - [no] downstr-bw-thresh
    ----utilization
      - [no] chpair-pmcollect
      - [no] ont-pmcollect

```

- [no] ontbulk-pmcollect
- threshold**
 - [no] txmcutilhi
 - [no] txmcutilmd
 - [no] txmcutillo
 - [no] txtotutilhi
 - [no] txtotutilmd
 - [no] txtotutillo
 - [no] rxtotutilhi
 - [no] rxtotutilmd
 - [no] rxtotutillo
 - [no] dbacongperiodhi
 - [no] dbacongperiodmd
 - [no] dbacongperiodlo
 - [no] txucdropfrmhi
 - [no] txucdropfrmmd
 - [no] txucdropfrmlo
 - [no] txmcdropfrmhi
 - [no] txmcdropfrmmd
 - [no] txmcdropfrmlo
 - [no] txbcdropfrmhi
 - [no] txbcdropfrmmd
 - [no] txbcdropfrmlo
 - [no] rxtotdropfrmhi
 - [no] rxtotdropfrmmd
 - [no] rxtotdropfrmlo
 - [no] numtcint
 - [no] numtcintdba
 - [no] dbacongthresh
- deact-ont-tca**
 - [no] mode
 - [no] monitor-interval
- threshold-percent**
 - [no] high
 - [no] high-clr
 - [no] low
 - [no] low-clr
- threshold-number**
 - [no] high
 - [no] high-clr
 - [no] low
 - [no] low-clr
- troubleshooting**
 - [no] bw-meter-interval

68.2 Channel Pair Profiles Configuration Command

Command Description

This command allows the operator to configure the provisioning data associated with a channel pair profile.

User Level

The command can be accessed by operators with equipment privileges, and executed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

> configure channel-pair profiles

68.3 Channel-Pair Wavelength Profile Configuration Command

Command Description

This command allows the operator to configure the Channel-pair Wavelength Profiles.

User Level

The command can be accessed by operators with equipment privileges, and executed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

```
> configure channel-pair profiles ( no wavelength-prof (profile-idx) ) | ( wavelength-prof (profile-idx) name
<AsamProfileName> upstream-channel-id <Gpon::ChannelId> downstream-channel-id <Gpon::ChannelId>
downstream-lambda <Gpon::DownstreamLambda> )
```

Command Parameters

Table 68.3-1 "Channel-Pair Wavelength Profile Configuration Command" Resource Parameters

Resource Identifier	Type	Description
(profile-idx)	Format: - profile index (Note that index [1..8], 33 and 34 are used for the default profiles) - range: [1...34]	profile index

Table 68.3-2 "Channel-Pair Wavelength Profile Configuration Command" Command Parameters

Parameter	Type	Description
name	Parameter type: <AsamProfileName> Format: - a profile name - range: [a-zA-Z0-9-_.] - length: 1<=x<=32	<i>mandatory parameter</i> <i>The parameter is not visible during modification.</i> name of the profile
upstream-channel-id	Parameter type: <Gpon::ChannelId> Format: - channel id - range: [1...16]	<i>mandatory parameter</i> <i>The parameter is not visible during modification.</i> up-channel id, must be 1 in case of XGS-PON
downstream-channel-id	Parameter type: <Gpon::ChannelId> Format: - channel id - range: [1...16]	<i>mandatory parameter</i> <i>The parameter is not visible during modification.</i> down-channel id
downstream-lambda	Parameter type: <Gpon::DownstreamLambda> Format:	<i>mandatory parameter</i> <i>The parameter is not visible</i>

68 Channel Pair Configuration Commands

Parameter	Type	Description
	- downstream lambda range for a channel-pair - range: [131000,149000,156000...161000]	<i>during modification.</i> downstream wavelength for the channel-pair using this profile

68.4 Channel Pair Interface Configuration

Command

Command Description

This command allows the operator to configure the provisioning data associated with a channel pair interface.

The value of channel-speed can be only changed if the channel pair is not currently a member of a subchannelgroup. All channel pairs in a subchannelgroup must have the same channel-speed. The equipped optics will not be checked against the configured speed. It is up to the operator to ensure that these match.

User Level

The command can be accessed by operators with equipment privileges, and executed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

```
> configure channel-pair interface (chanpair-idx) [ no label | label <Gpon::Label> ] [ no pon-tag | pon-tag
<Gpon::PonTag> ] [ no x-pon-id | x-pon-id <Ng2::XPonId> ] [ no max-ranging-onts | max-ranging-onts
<Ng2::ChanPairMaxRangingOnt> ] [ no tconts-per-frame | tconts-per-frame <Ng2::ChanPairTcontsPerFrame> ] [
no ber-calc-period | ber-calc-period <Ng2::ChanPairBerPeriod> ] [ no sig-degrade-th | sig-degrade-th
<Ng2::ChanPairSdThreshold> ] [ no sig-fail-th | sig-fail-th <Ng2::ChanPairSfThreshold> ] [ no wavelength-prof |
wavelength-prof <Gpon::WavelengthProfile> ] [ no channel-speed | channel-speed <Gpon::ChannelSpeed> ] [ no
burst-overhead | burst-overhead <Gpon::BurstModeOverhead> ] [ no admin-label | admin-label
<Ng2::AdminLabel> ] [ no onu-prov-mode | onu-prov-mode <Gpon::OnuProvMode> ] [ no admin-state |
admin-state <Gpon::ItfAdminStatus> ]
```

Command Parameters

Table 68.4-1 "Channel Pair Interface Configuration Command" Resource Parameters

Resource Identifier	Type	Description
(chanpair-idx)	Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::ChannelPairId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::ChannelPairId> - the channel pair identifier	channel pair index

Table 68.4-2 "Channel Pair Interface Configuration Command" Command Parameters

Parameter	Type	Description
[no] label	Parameter type: <Gpon::Label> Format: - char string - length: x<=80	<i>optional parameter with default value: ""</i> label of the channel pair port
[no] pon-tag	Parameter type: <Gpon::PonTag> Format: - Pon Tag - 16 hex characters - length: x<=16	<i>optional parameter with default value: "0000000000000000"</i> label of the channel-pair port
[no] x-pon-id	Parameter type: <Ng2::XPonId> Format: - Pon Id - 8 hex characters - length: x<=8	<i>optional parameter with default value: "00000000"</i> label of the channelpair port, used when channelpair is in XGS-mode
[no] max-ranging-onts	Parameter type: <Ng2::ChanPairMaxRangingOnt> Format: - ranging onts number;if 0 indicates bandwidth calculated by provisioned onts; other value indicates pre-configured onts - range: [0...128]	<i>optional parameter with default value: 128L</i> max ranging ont number for guaranteed bandwidth cac
[no] tconts-per-frame	Parameter type: <Ng2::ChanPairTcontsPerFrame> Format: - tcont number to calculate the guaranteed bandwidth. Range: XGSPON and XGPON1 [0..64], NGPON2 [0..16] - range: [0...64]	<i>optional parameter with default value: 16L</i> max service tcont number per gtc frame
[no] ber-calc-period	Parameter type: <Ng2::ChanPairBerPeriod> Format: - ber caculate period used to detect determine whether an SDi/SFi alarm has occurred for an ONT. default = 10 - unit: 1/10 sec - range: [1...864000]	<i>optional parameter with default value: 10L</i> ber caculate period used to detect determine whether an SDi/SFi alarm has occurred for an ONT
[no] sig-degrade-th	Parameter type: <Ng2::ChanPairSdThreshold> Format: - ber threshold used to detect a signal degrade alarms for onts default = 9 - range: [4...10]	<i>optional parameter with default value: 9L</i> the BER threshold used to detect Signal Degrade alarms for ONTs on this PON
[no] sig-fail-th	Parameter type: <Ng2::ChanPairSfThreshold> Format: - ber threshold used to detect a signal fail alarms for onts default = 5 - range: [3...8]	<i>optional parameter with default value: 5L</i> the BER threshold used to detect Signal Fail alarms for ONTs on this PON
[no] wavelength-prof	Parameter type: <Gpon::WavelengthProfile> Format: (none <Gpon::WavelengthProfile> name : <AsamProfileName>) Possible values: - none : no profile to associate - name : profile name Field type <Gpon::WavelengthProfile> - profile index - range: [0...34] Data driven field type Possible values are depending on the actual configuration and software. The currently allowed values can be shown with online-help.	<i>optional parameter with default value: "none"</i> wavelength profile
[no] channel-speed	Parameter type: <Gpon::ChannelSpeed> Format: (unplanned	<i>optional parameter with default value: "unplanned"</i> channel speed

Parameter	Type	Description
	10g-10g 10g-2.5g 2.5g-2.5g 10g-dualrate) Possible values: - unplanned : unplanned - 10g-10g : 10g down / 10g up - 10g-2.5g : 10g down / 2.5g up - 2.5g-2.5g : 2.5g down / 2.5 up - 10g-dualrate : 10g down / dual-rate up	
[no] burst-overhead	Parameter type: <Gpon::BurstModeOverhead> Format: (robust reduced) Possible values: - robust : robust - reduced : reduced	optional parameter with default value: "robust" burst mode overhead
[no] admin-label	Parameter type: <Ng2::AdminLabel> Format: - Admin label - 7 hex characters - length: x<=7	optional parameter with default value: "0000000" admin label of the channelpair port, used when channelpair is in TWDM-mode
[no] onu-prov-mode	Parameter type: <Gpon::OnuProvMode> Format: (semi-auto auto) Possible values: - semi-auto : ONU semi-auto provisioning. Template file needs to be specified in ONT config - auto : ONU auto provisioning. Template file selection done automatically based on ONT type	optional parameter with default value: "semi-auto" ONU auto provisioning mode
[no] admin-state	Parameter type: <Gpon::ItfAdminStatus> Format: (up down) Possible values: - up : set the admin-state to up - down : set the admin-state to down	optional parameter with default value: "down" The parameter is not visible during creation. administrative status of the interface

Command Output

Table 68.4-3 "Channel Pair Interface Configuration Command" Display parameters

Specific Information		
name	Type	Description
oper-state	Parameter type: <Itf::ifOperStatus> (up down testing unknown dormant no-value) Possible values: - up : up,traffic can pass - down : down,no traffic is passing - testing : testing,no traffic is passing - unknown : unknown	operational state of the interface <i>This element is always shown.</i>

name	Type	Description
	- dormant : dormant,no traffic is passing - no-value : no entry in the table	
actual-lambda-down	Parameter type: <Gpon::ActualDownstreamLambda> - downstream lambda range for a channel-pair - range: [131000,149000,156000...161000]	the actual lambda used in downstream <i>This element is always shown.</i>

68.5 Channel Pair XGEM Port Performance Monitoring Configuration Command

Command Description

This command allows the operator to set the PM mode of OLT side XGEM based counters for errored fragments.

User Level

The command can be accessed by operators with equipment privileges, and executed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

```
> configure channel-pair interface (chanpair-idx) tc-layer [ no pm-collect | pm-collect <Gpon::OntPmTcaCollect> ]
```

Command Parameters

Table 68.5-1 "Channel Pair XGEM Port Performance Monitoring Configuration Command" Resource Parameters

Resource Identifier	Type	Description
(chanpair-idx)	Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::ChannelPairId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::ChannelPairId> - the channel pair identifier	channel pair index

Table 68.5-2 "Channel Pair XGEM Port Performance Monitoring Configuration Command" Command Parameters

Parameter	Type	Description
[no] pm-collect	Parameter type: <Gpon::OntPmTcaCollect> Format: (none pm-enable tca-enable) Possible values: - none : no pm - pm-enable : enable pm - tca-enable : enable tca	<i>optional parameter with default value: "pm-enable"</i> olt-side aggregate TC Layer performance monitoring

68.6 OLT-SIDE TC-layer Performance Monitoring Counter Thresholds Configuration Command for channel pair

Command Description

This command allows the operator to enable configuration of performance Monitoring counter thresholds for OLT-Side TC-layer errored fragments.

User Level

The command can be accessed by operators with equipment privileges, and executed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

```
> configure channel-pair interface (chanpair-idx) tc-layer-threshold [ no error-frags-up | error-frags-up <Gpon::TcaThresholdValue> ]
```

Command Parameters

Table 68.6-1 "OLT-SIDE TC-layer Performance Monitoring Counter Thresholds Configuration Command for channel pair" Resource Parameters

Resource Identifier	Type	Description
(chanpair-idx)	Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::ChannelPairId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::ChannelPairId> - the channel pair identifier	channel pair index

Table 68.6-2 "OLT-SIDE TC-layer Performance Monitoring Counter Thresholds Configuration Command for channel pair" Command Parameters

Parameter	Type	Description
[no] error-frags-up	Parameter type: <Gpon::TcaThresholdValue> Format: (disabled <Gpon::TcaThresholdValue>)	optional parameter with default value: "disabled" tca setting for errored gem fragments

Parameter	Type	Description
	Possible values: - disabled : threshold is disabled Field type <Gpon::TcaThresholdValue> - tc-layer tca threshold value (4294967295=disabled) - range: [0...4294967294,4294967295]	

68.7 Multicast TC-layer Performance Monitoring

Command for channel pair

Command Description

This command allows the operator to enable or disable the OLT-side Multicast Port Performance Monitor collection for the channel pair.

User Level

The command can be accessed by operators with equipment privileges, and executed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

```
> configure channel-pair interface (chanpair-idx) mcast-tc-layer [ no pm-collect | pm-collect <Gpon::OntPmCollect> ]
```

Command Parameters

Table 68.7-1 "Multicast TC-layer Performance Monitoring Command for channel pair" Resource Parameters

Resource Identifier	Type	Description
(chanpair-idx)	Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::ChannelPairId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::ChannelPairId> - the channel pair identifier	channel pair index

Table 68.7-2 "Multicast TC-layer Performance Monitoring Command for channel pair" Command Parameters

Parameter	Type	Description
[no] pm-collect	Parameter type: <Gpon::OntPmCollect> Format: (enable disable) Possible values: - enable : enable PM - disable : disable PM	<i>optional parameter with default value: "disable"</i> OLT-side multicast performance monitoring

Command Output

Table 68.7-3 "Multicast TC-layer Performance Monitoring Command for channel pair" Display parameters

Specific Information		
name	Type	Description
interval-no	Parameter type: <SignedInteger> - a signed integer	number of rows currently present in the gponMulticastServiceOltsideGemInterval. <i>This element is always shown.</i>

68.8 NGPON2 Physical-layer Performance Monitoring Command for channel pair

Command Description

This command allows the operator to enable or disable the OLT-side NGPON2 Physical Performance Monitor collection for the channel pair.

User Level

The command can be accessed by operators with equipment privileges, and executed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

```
> configure channel-pair interface (chanpair-idx) phy-layer [ no pm-collect | pm-collect <Gpon::PmEnable> ]
```

Command Parameters

**Table 68.8-1 "NGPON2 Physical-layer Performance Monitoring Command for channel pair"
Resource Parameters**

Resource Identifier	Type	Description
(chanpair-idx)	Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::ChannelPairId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::ChannelPairId> - the channel pair identifier	channel pair index

**Table 68.8-2 "NGPON2 Physical-layer Performance Monitoring Command for channel pair"
Command Parameters**

Parameter	Type	Description
[no] pm-collect	Parameter type: <Gpon::PmEnable> Format: (disable enable) Possible values: - disable : disable the collection - enable : enable the collection	<i>optional parameter with default value: "disable"</i> OLT-side NGPON2 Physical performance monitoring

Command Output

Table 68.8-3 "NGPON2 Physical-layer Performance Monitoring Command for channel pair"
Display parameters

Specific Information		
name	Type	Description
interval-no	Parameter type: <SignedInteger> - a signed integer	number of rows currently present in the gponMulticastServiceOltsideGemInterval. <i>This element is always shown.</i>

68.9 NGPON2 Upstream FEC Performance Monitoring Command for channel pair

Command Description

This command allows the operator to enable or disable the OLT-side NGPON2 upstream FEC Performance Monitor collection for the channel pair.

User Level

The command can be accessed by operators with equipment privileges, and executed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

```
> configure channel-pair interface (chanpair-idx) fec-tc-layer [ no pm-collect | pm-collect <Gpon::PmEnable> ]
```

Command Parameters

**Table 68.9-1 "NGPON2 Upstream FEC Performance Monitoring Command for channel pair"
Resource Parameters**

Resource Identifier	Type	Description
(chanpair-idx)	Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::ChannelPairId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::ChannelPairId> - the channel pair identifier	channel pair index

**Table 68.9-2 "NGPON2 Upstream FEC Performance Monitoring Command for channel pair"
Command Parameters**

Parameter	Type	Description
[no] pm-collect	Parameter type: <Gpon::PmEnable> Format: (disable enable) Possible values: - disable : disable the collection - enable : enable the collection	optional parameter with default value: "disable" OLT-side upstream FEC performance monitoring

Command Output

Table 68.9-3 "NGPON2 Upstream FEC Performance Monitoring Command for channel pair"
Display parameters

Specific Information		
name	Type	Description
interval-no	Parameter type: <SignedInteger> - a signed integer	number of rows currently present in the gponMulticastServiceOltsideGemInterval. This element is always shown.

68.10 NGPON2 TC-layer Performance Monitoring

Command for channel pair

Command Description

This command allows the operator to enable or disable the OLT-side NGPON2 TC-layer Performance Monitor collection for the channel pair.

User Level

The command can be accessed by operators with equipment privileges, and executed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

```
> configure channel-pair interface (chanpair-idx) xg-tc-layer [ no pm-collect | pm-collect <Gpon::PmEnable> ]
```

Command Parameters

Table 68.10-1 "NGPON2 TC-layer Performance Monitoring Command for channel pair" Resource Parameters

Resource Identifier	Type	Description
(chanpair-idx)	Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::ChannelPairId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::ChannelPairId> - the channel pair identifier	channel pair index

Table 68.10-2 "NGPON2 TC-layer Performance Monitoring Command for channel pair" Command Parameters

Parameter	Type	Description
[no] pm-collect	Parameter type: <Gpon::PmEnable> Format: (disable enable) Possible values: - disable : disable the collection - enable : enable the collection	<i>optional parameter with default value: "disable"</i> OLT-side tc-layer performance monitoring

Command Output

Table 68.10-3 "NGPON2 TC-layer Performance Monitoring Command for channel pair" Display parameters

Specific Information		
name	Type	Description
interval-no	Parameter type: <SignedInteger> - a signed integer	number of rows currently present in the gponMulticastServiceOltsideGemInterval. This element is always shown.

68.11 Trouble shooting Configuration Command

Command Description

This command is to configure the channel-pair threshold of bytes up or down.

User Level

The command can be accessed by operators with equipment privileges, and executed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

> configure channel-pair interface (chanpair-idx) troubleshooting

Command Parameters

Table 68.11-1 "Trouble shooting Configuration Command" Resource Parameters

Resource Identifier	Type	Description
(chanpair-idx)	Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::ChannelPairId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::ChannelPairId> - the channel pair identifier	channel pair index

68.12 Trouble-shooting Interface Configuration Commands

Command Description

This command allows the operator to enable or disable the extensive trouble-shooting counters.

By default troubleshooting is not enabled on a channelpair.

Note however that this default is not displayed by an info config neither info config detail.

When troubleshooting is enabled on a specific channelpair, info config and info config detail will both report it.

User Level

The command can be accessed by operators with security privileges, and executed by operators with security privileges.

Command Syntax

The command has the following syntax:

> configure channel-pair interface (chanpair-idx) troubleshooting (no enable) | (enable)

Command Parameters

Table 68.12-1 "Trouble-shooting Interface Configuration Commands" Resource Parameters

Resource Identifier	Type	Description
(chanpair-idx)	Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::ChannelPairId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::ChannelPairId> - the channel pair identifier	channel pair index

68.13 Trouble shooting Configuration Command

Command Description

This command is to configure the channel-pair threshold of bytes up or down.

User Level

The command can be accessed by operators with equipment privileges, and executed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

```
> configure channel-pair interface (chanpair-idx) troubleshooting threshold [ no upstr-bw-thresh | upstr-bw-thresh
<Gpon::TrbstBwThUp> ] [ no downstr-bw-thresh | downstr-bw-thresh <Gpon::TrbstBwThDn> ]
```

Command Parameters

Table 68.13-1 "Trouble shooting Configuration Command" Resource Parameters

Resource Identifier	Type	Description
(chanpair-idx)	Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::ChannelPairId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::ChannelPairId> - the channel pair identifier	channel pair index

Table 68.13-2 "Trouble shooting Configuration Command" Command Parameters

Parameter	Type	Description
[no] upstr-bw-thresh	Parameter type: <Gpon::TrbstBwThUp> Format: - the attribute is used to specify the average rate threshold in kbps for upstream traffic,0 is disable - range: [0...4294967295]	<i>optional parameter with default value: "0"</i> the attribute is used to specify the average rate threshold in kbps for upstream traffic,0 is disable
[no] downstr-bw-thresh	Parameter type: <Gpon::TrbstBwThDn> Format: - the attribute is used to specify the average rate threshold in kbps for downstream traffic,0 is disable - range: [0...4294967295]	<i>optional parameter with default value: "0"</i> the attribute is used to specify the average rate threshold in kbps for downstream traffic,0 is disable

68.14 Channel Pair Utilization PM Configuration Command

Command Description

This command configures the channel-pair and ont utilization performance monitoring modes for a channel-pair.

User Level

The command can be accessed by operators with equipment privileges, and executed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

```
> configure channel-pair interface (chanpair-idx) utilization [ no chpair-pmcollect | chpair-pmcollect
<Gpon::PonUtilPmTcaCollect> ] [ no ont-pmcollect | ont-pmcollect <Gpon::PonUtilOntPmCollect> ] [ no
ontbulk-pmcollect | ontbulk-pmcollect <Gpon::OntPmCollect> ]
```

Command Parameters

Table 68.14-1 "Channel Pair Utilization PM Configuration Command" Resource Parameters

Resource Identifier	Type	Description
(chanpair-idx)	Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::ChannelPairId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::ChannelPairId> - the channel pair identifier	channel pair index

Table 68.14-2 "Channel Pair Utilization PM Configuration Command" Command Parameters

Parameter	Type	Description
[no] chpair-pmcollect	Parameter type: <Gpon::PonUtilPmTcaCollect> Format: (none pm-enable tca-enable inherit) Possible values: - none : no pm - pm-enable : enable pm	<i>optional parameter with default value: "inherit"</i> channel-pair utilization performance monitoring

68 Channel Pair Configuration Commands

Parameter	Type	Description
	- tca-enable : enable tca - inherit : inherit from generic-pon (system-wide) pon-pmcollect and threshold values	
[no] ont-pmcollect	Parameter type: <Gpon::PonUtilOntPmCollect> Format: (enable disable inherit) Possible values: - enable : enable PM - disable : disable PM - inherit : inherit from generic-pon (system-wide) ont-pmcollect value	<i>optional parameter with default value: "inherit"</i> channel-pair utilization ont detailed performance monitoring
[no] ontbulk-pmcollect	Parameter type: <Gpon::OntPmCollect> Format: (enable disable) Possible values: - enable : enable PM - disable : disable PM	<i>optional parameter with default value: "disable"</i> channel-pair utilization ont pm bulk collectable via BFMU

68.15 Channel Pair Utilization TCA Threshold Configuration Command

Command Description

This command configures the utilization TCA threshold parameters for a channel-pair.

User Level

The command can be accessed by operators with equipment privileges, and executed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

```
> configure channel-pair interface (chanpair-idx) utilization threshold [ no txmcutilhi | txmcutilhi
<Gpon::PonUtilTcaThresholdPercent> ] [ no txmcutilmd | txmcutilmd <Gpon::PonUtilTcaThresholdPercent> ] [ no
txmcutillo | txmcutillo <Gpon::PonUtilTcaThresholdPercent> ] [ no txtotutilhi | txtotutilhi
<Gpon::PonUtilTcaThresholdPercent> ] [ no txtotutilmd | txtotutilmd <Gpon::PonUtilTcaThresholdPercent> ] [ no
txtotutillo | txtotutillo <Gpon::PonUtilTcaThresholdPercent> ] [ no rxtotutilhi | rxtotutilhi
<Gpon::PonUtilTcaThresholdPercent> ] [ no rxtotutilmd | rxtotutilmd <Gpon::PonUtilTcaThresholdPercent> ] [ no
rxtotutillo | rxtotutillo <Gpon::PonUtilTcaThresholdPercent> ] [ no dbacongperiodhi | dbacongperiodhi
<Gpon::PonUtilTcaThresholdPercent> ] [ no dbacongperiodmd | dbacongperiodmd
<Gpon::PonUtilTcaThresholdPercent> ] [ no dbacongperiodlo | dbacongperiodlo
<Gpon::PonUtilTcaThresholdPercent> ] [ no txucdropfrmhi | txucdropfrmhi
<Gpon::PonUtilTcaDroppedPacketsThreshold> ] [ no txucdropfrmmd | txucdropfrmmd
<Gpon::PonUtilTcaDroppedPacketsThreshold> ] [ no txucdropfrmlo | txucdropfrmlo
<Gpon::PonUtilTcaDroppedPacketsThreshold> ] [ no txmcdropfrmhi | txmcdropfrmhi
<Gpon::PonUtilTcaDroppedPacketsThreshold> ] [ no txmcdropfrmmd | txmcdropfrmmd
<Gpon::PonUtilTcaDroppedPacketsThreshold> ] [ no txmcdropfrmlo | txmcdropfrmlo
<Gpon::PonUtilTcaDroppedPacketsThreshold> ] [ no txbcdropfrmhi | txbcdropfrmhi
<Gpon::PonUtilTcaDroppedPacketsThreshold> ] [ no txbcdropfrmmd | txbcdropfrmmd
<Gpon::PonUtilTcaDroppedPacketsThreshold> ] [ no txbcdropfrmlo | txbcdropfrmlo
<Gpon::PonUtilTcaDroppedPacketsThreshold> ] [ no rxtotdropfrmhi | rxtotdropfrmhi
<Gpon::PonUtilTcaDroppedPacketsThreshold> ] [ no rxtotdropfrmmd | rxtotdropfrmmd
<Gpon::PonUtilTcaDroppedPacketsThreshold> ] [ no rxtotdropfrmlo | rxtotdropfrmlo
<Gpon::PonUtilTcaDroppedPacketsThreshold> ] [ no numtcint | numtcint <Gpon::PonUtilTcaInterval> ] [ no
numtcintdba | numtcintdba <Gpon::PonUtilTcaInterval> ] [ no dbacongthresh | dbacongthresh
<Gpon::PonUtilTcaCongThreshold> ]
```

Command Parameters

Table 68.15-1 "Channel Pair Utilization TCA Threshold Configuration Command" Resource Parameters

Resource Identifier	Type	Description
(chanpair-idx)	Format:	channel pair index

Resource Identifier	Type	Description
	<code><Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::ChannelPairId></code> Field type <code><Eqpt::RackId></code> - the rack number Field type <code><Eqpt::ShelfId></code> - the shelf number Field type <code><Eqpt::SlotId></code> - the LT slot number Field type <code><Eqpt::ChannelPairId></code> - the channel pair identifier	

Table 68.15-2 "Channel Pair Utilization TCA Threshold Configuration Command" Command Parameters

Parameter	Type	Description
[no] txmcutilhi	Parameter type: <code><Gpon::PonUtilTcaThresholdPercent></code> Format: (disabled <code><Gpon::PonUtilTcaThresholdPercent></code>) Possible values: - disabled : threshold is disabled Field type <code><Gpon::PonUtilTcaThresholdPercent></code> - utilization percentage threshold - range: [0...100]	<i>optional parameter with default value: "disabled"</i> utilization level (percentage) that will result in declaration of T-TXMCUTILHI alarm
[no] txmcutilmd	Parameter type: <code><Gpon::PonUtilTcaThresholdPercent></code> Format: (disabled <code><Gpon::PonUtilTcaThresholdPercent></code>) Possible values: - disabled : threshold is disabled Field type <code><Gpon::PonUtilTcaThresholdPercent></code> - utilization percentage threshold - range: [0...100]	<i>optional parameter with default value: "disabled"</i> utilization level (percentage) that will result in declaration of T-TXMCUTILMD alarm
[no] txmcutillo	Parameter type: <code><Gpon::PonUtilTcaThresholdPercent></code> Format: (disabled <code><Gpon::PonUtilTcaThresholdPercent></code>) Possible values: - disabled : threshold is disabled Field type <code><Gpon::PonUtilTcaThresholdPercent></code> - utilization percentage threshold - range: [0...100]	<i>optional parameter with default value: "disabled"</i> utilization level (percentage) that will result in declaration of T-TXMCUTILLO alarm
[no] txtotutilhi	Parameter type: <code><Gpon::PonUtilTcaThresholdPercent></code> Format: (disabled <code><Gpon::PonUtilTcaThresholdPercent></code>) Possible values: - disabled : threshold is disabled Field type <code><Gpon::PonUtilTcaThresholdPercent></code> - utilization percentage threshold - range: [0...100]	<i>optional parameter with default value: "disabled"</i> utilization level (percentage) that will result in declaration of T-TXTOTUTILHI alarm
[no] txtotutilmd	Parameter type: <code><Gpon::PonUtilTcaThresholdPercent></code> Format: (disabled <code><Gpon::PonUtilTcaThresholdPercent></code>) Possible values: - disabled : threshold is disabled Field type <code><Gpon::PonUtilTcaThresholdPercent></code>	<i>optional parameter with default value: "disabled"</i> utilization level (percentage) that will result in declaration of T-TXTOTUTILMD alarm

Parameter	Type	Description
	- utilization percentage threshold - range: [0...100]	
[no] txtotutillo	Parameter type: <Gpon::PonUtilTcaThresholdPercent> Format: (disabled <Gpon::PonUtilTcaThresholdPercent>) Possible values: - disabled : threshold is disabled Field type <Gpon::PonUtilTcaThresholdPercent> - utilization percentage threshold - range: [0...100]	<i>optional parameter with default value: "disabled"</i> utilization level (percentage) that will result in declaration of T-TXTOTUTILLO alarm
[no] rxtotutilhi	Parameter type: <Gpon::PonUtilTcaThresholdPercent> Format: (disabled <Gpon::PonUtilTcaThresholdPercent>) Possible values: - disabled : threshold is disabled Field type <Gpon::PonUtilTcaThresholdPercent> - utilization percentage threshold - range: [0...100]	<i>optional parameter with default value: "disabled"</i> utilization level (percentage) that will result in declaration of T-RXTOTUTILHI alarm
[no] rxtotutilmd	Parameter type: <Gpon::PonUtilTcaThresholdPercent> Format: (disabled <Gpon::PonUtilTcaThresholdPercent>) Possible values: - disabled : threshold is disabled Field type <Gpon::PonUtilTcaThresholdPercent> - utilization percentage threshold - range: [0...100]	<i>optional parameter with default value: "disabled"</i> utilization level (percentage) that will result in declaration of T-RXTOTUTILMD alarm
[no] rxtotutillo	Parameter type: <Gpon::PonUtilTcaThresholdPercent> Format: (disabled <Gpon::PonUtilTcaThresholdPercent>) Possible values: - disabled : threshold is disabled Field type <Gpon::PonUtilTcaThresholdPercent> - utilization percentage threshold - range: [0...100]	<i>optional parameter with default value: "disabled"</i> utilization level (percentage) that will result in declaration of T-RXTOTUTILLO alarm
[no] dbacongperiodhi	Parameter type: <Gpon::PonUtilTcaThresholdPercent> Format: (disabled <Gpon::PonUtilTcaThresholdPercent>) Possible values: - disabled : threshold is disabled Field type <Gpon::PonUtilTcaThresholdPercent> - utilization percentage threshold - range: [0...100]	<i>optional parameter with default value: "disabled"</i> utilization level (percentage) that will result in declaration of T-DBACONGPERIODHI alarm
[no] dbacongperiodmd	Parameter type: <Gpon::PonUtilTcaThresholdPercent> Format: (disabled <Gpon::PonUtilTcaThresholdPercent>) Possible values: - disabled : threshold is disabled Field type <Gpon::PonUtilTcaThresholdPercent> - utilization percentage threshold - range: [0...100]	<i>optional parameter with default value: "disabled"</i> utilization level (percentage) that will result in declaration of T-DBACONGPERIODMD alarm
[no] dbacongperiodlo	Parameter type: <Gpon::PonUtilTcaThresholdPercent>	<i>optional parameter with default</i>

68 Channel Pair Configuration Commands

Parameter	Type	Description
	Format: (disabled <Gpon::PonUtilTcaThresholdPercent>) Possible values: - disabled : threshold is disabled Field type <Gpon::PonUtilTcaThresholdPercent> - utilization percentage threshold - range: [0...100]	<i>value: "disabled"</i> utilization level (percentage) that will result in declaration of T-DBACONGPERIODLO alarm
[no] txucdropfrmhi	Parameter <Gpon::PonUtilTcaDroppedPacketsThreshold> type: Format: (disabled <Gpon::PonUtilTcaDroppedPacketsThreshold>) Possible values: - disabled : threshold is disabled Field type <Gpon::PonUtilTcaDroppedPacketsThreshold> - dropped frames threshold - range: [0...1000000000]	<i>optional parameter with default value: "disabled"</i> number of dropped frames that will result in declaration of T-TXUCDROPPFRMHI alarm
[no] txucdropfrmmd	Parameter <Gpon::PonUtilTcaDroppedPacketsThreshold> type: Format: (disabled <Gpon::PonUtilTcaDroppedPacketsThreshold>) Possible values: - disabled : threshold is disabled Field type <Gpon::PonUtilTcaDroppedPacketsThreshold> - dropped frames threshold - range: [0...1000000000]	<i>optional parameter with default value: "disabled"</i> number of dropped frames that will result in declaration of T-TXUCDROPPFRMMD alarm
[no] txucdropfrmlo	Parameter <Gpon::PonUtilTcaDroppedPacketsThreshold> type: Format: (disabled <Gpon::PonUtilTcaDroppedPacketsThreshold>) Possible values: - disabled : threshold is disabled Field type <Gpon::PonUtilTcaDroppedPacketsThreshold> - dropped frames threshold - range: [0...1000000000]	<i>optional parameter with default value: "disabled"</i> number of dropped frames that will result in declaration of T-TXUCDROPPFRMLO alarm
[no] txmcdropfrmhi	Parameter <Gpon::PonUtilTcaDroppedPacketsThreshold> type: Format: (disabled <Gpon::PonUtilTcaDroppedPacketsThreshold>) Possible values: - disabled : threshold is disabled Field type <Gpon::PonUtilTcaDroppedPacketsThreshold> - dropped frames threshold - range: [0...1000000000]	<i>optional parameter with default value: "disabled"</i> number of dropped frames that will result in declaration of T-TXMCDROPPFRMHI alarm
[no] txmcdropfrmmd	Parameter <Gpon::PonUtilTcaDroppedPacketsThreshold> type: Format: (disabled <Gpon::PonUtilTcaDroppedPacketsThreshold>) Possible values: - disabled : threshold is disabled Field type <Gpon::PonUtilTcaDroppedPacketsThreshold> - dropped frames threshold	<i>optional parameter with default value: "disabled"</i> number of dropped frames that will result in declaration of T-TXMCDROPPFRMMD alarm

Parameter	Type	Description
[no] txmcdropfrmlo	Parameter - range: [0...1000000000] type: <Gpon::PonUtilTcaDroppedPacketsThreshold> Format: (disabled <Gpon::PonUtilTcaDroppedPacketsThreshold>) Possible values: - disabled : threshold is disabled Field type <Gpon::PonUtilTcaDroppedPacketsThreshold> - dropped frames threshold - range: [0...1000000000]	optional parameter with default value: "disabled" number of dropped frames that will result in declaration of T-TXMCDROPFRMLO alarm
[no] txbcdropfrmhi	Parameter - range: [0...1000000000] type: <Gpon::PonUtilTcaDroppedPacketsThreshold> Format: (disabled <Gpon::PonUtilTcaDroppedPacketsThreshold>) Possible values: - disabled : threshold is disabled Field type <Gpon::PonUtilTcaDroppedPacketsThreshold> - dropped frames threshold - range: [0...1000000000]	optional parameter with default value: "disabled" number of dropped frames that will result in declaration of T-TXBCDROPFRMHI alarm
[no] txbcdropfrmmd	Parameter - range: [0...1000000000] type: <Gpon::PonUtilTcaDroppedPacketsThreshold> Format: (disabled <Gpon::PonUtilTcaDroppedPacketsThreshold>) Possible values: - disabled : threshold is disabled Field type <Gpon::PonUtilTcaDroppedPacketsThreshold> - dropped frames threshold - range: [0...1000000000]	optional parameter with default value: "disabled" number of dropped frames that will result in declaration of T-TXBCDROPFRMMD alarm
[no] txbcdropfrmlo	Parameter - range: [0...1000000000] type: <Gpon::PonUtilTcaDroppedPacketsThreshold> Format: (disabled <Gpon::PonUtilTcaDroppedPacketsThreshold>) Possible values: - disabled : threshold is disabled Field type <Gpon::PonUtilTcaDroppedPacketsThreshold> - dropped frames threshold - range: [0...1000000000]	optional parameter with default value: "disabled" number of dropped frames that will result in declaration of T-TXBCDROPFRMLO alarm
[no] rxtotdropfrmhi	Parameter - range: [0...1000000000] type: <Gpon::PonUtilTcaDroppedPacketsThreshold> Format: (disabled <Gpon::PonUtilTcaDroppedPacketsThreshold>) Possible values: - disabled : threshold is disabled Field type <Gpon::PonUtilTcaDroppedPacketsThreshold> - dropped frames threshold - range: [0...1000000000]	optional parameter with default value: "disabled" number of dropped frames that will result in declaration of T-RXTOTCDROPFRMHI alarm
[no] rxtotdropfrmmd	Parameter - range: [0...1000000000] type: <Gpon::PonUtilTcaDroppedPacketsThreshold> Format: (disabled <Gpon::PonUtilTcaDroppedPacketsThreshold>) Possible values:	optional parameter with default value: "disabled" number of dropped frames that will result in declaration of T-RXTOTDROPFRMMD alarm

68 Channel Pair Configuration Commands

Parameter	Type	Description
	- disabled : threshold is disabled Field type <Gpon::PonUtilTcaDroppedPacketsThreshold> - dropped frames threshold - range: [0...1000000000]	
[no] rxtotdropfrmlo	Parameter type: <Gpon::PonUtilTcaDroppedPacketsThreshold> Format: (disabled <Gpon::PonUtilTcaDroppedPacketsThreshold>) Possible values: - disabled : threshold is disabled Field type <Gpon::PonUtilTcaDroppedPacketsThreshold> - dropped frames threshold - range: [0...1000000000]	<i>optional parameter with default value: "disabled"</i> number of dropped frames that will result in declaration of T-RXTOTCDROPFRMLO alarm
[no] numtcint	Parameter type: <Gpon::PonUtilTcaInterval> Format: (1 <Gpon::PonUtilTcaInterval>) Possible values: - 1 : Initial Default Field type <Gpon::PonUtilTcaInterval> - interval threshold - range: [1...96]	<i>optional parameter with default value: "1"</i> number of contiguous 5-minute intervals for the non-DBA utilization thresholds to be exceeded for tca alarm
[no] numtcintdba	Parameter type: <Gpon::PonUtilTcaInterval> Format: (1 <Gpon::PonUtilTcaInterval>) Possible values: - 1 : Initial Default Field type <Gpon::PonUtilTcaInterval> - interval threshold - range: [1...96]	<i>optional parameter with default value: "1"</i> number of contiguous 5-minute intervals for the DBA congestion thresholds to be exceeded for tca alarm
[no] dbacongthresh	Parameter type: <Gpon::PonUtilTcaCongThreshold> Format: (90 <Gpon::PonUtilTcaCongThreshold>) Possible values: - 90 : Initial Default Field type <Gpon::PonUtilTcaCongThreshold> - dba congestion percentage threshold - range: [0...100]	<i>optional parameter with default value: "90"</i> DBA congestion threshold as a percentage of the maximum consumable bandwidth

68.16 Deactivate Ont threshold Configuration Commands

Command Description

This command allows the operator to configure deactivate ont threshold.

User Level

The command can be accessed by operators with equipment privileges, and executed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

```
> configure channel-pair interface (chanpair-idx) deact-ont-tca [ no mode | mode <Gpon::DeactOnuTcaMode> ] [
no monitor-interval | monitor-interval <Gpon::DeactOnuInterval> ]
```

Command Parameters

Table 68.16-1 "Deactivate Ont threshold Configuration Commands" Resource Parameters

Resource Identifier	Type	Description
(chanpair-idx)	Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::ChannelPairId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::ChannelPairId> - the channel pair identifier	channel pair index

Table 68.16-2 "Deactivate Ont threshold Configuration Commands" Command Parameters

Parameter	Type	Description
[no] mode	Parameter type: <Gpon::DeactOnuTcaMode> Format: (disable percent number) Possible values: - disable : disable mode - percent : percentage mode - number : number mode	<i>optional parameter with default value: "disable"</i> Used to specify PON or Channel-Pair deactivated ONT detection mode.
[no] monitor-interval	Parameter type: <Gpon::DeactOnuInterval>	<i>optional parameter with default</i>

68 Channel Pair Configuration Commands

Parameter	Type	Description
	Format: - tca interval - unit: second - range: [5...300]	<i>value: 30L</i> Used to specify PON or Channel-Pair deactivated ONT detection interval.

68.17 Deactivate Ont threshold Configuration Commands

Command Description

This command allows the operator to configure deactivate ont threshold.

User Level

The command can be accessed by operators with equipment privileges, and executed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

```
> configure channel-pair interface (chanpair-idx) deact-ont-tca threshold-percent [ no high | high
<Gpon::DeactOnuTcaPctHigh> ] [ no high-clr | high-clr <Gpon::DeactOnuTcaPctHigh> ] [ no low | low
<Gpon::DeactOnuTcaPctLow> ] [ no low-clr | low-clr <Gpon::DeactOnuTcaPctLow> ]
```

Command Parameters

Table 68.17-1 "Deactivate Ont threshold Configuration Commands" Resource Parameters

Resource Identifier	Type	Description
(chanpair-idx)	Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::ChannelPairId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::ChannelPairId> - the channel pair identifier	channel pair index

Table 68.17-2 "Deactivate Ont threshold Configuration Commands" Command Parameters

Parameter	Type	Description
[no] high	Parameter type: <Gpon::DeactOnuTcaPctHigh> Format: - tca threshold in percent - range: [1...100]	<i>optional parameter with default value: 90L</i> Used to specify PON or Channel-Pair deactivated ONT detection high threshold in percent.
[no] high-clr	Parameter type: <Gpon::DeactOnuTcaPctHigh> Format: - tca threshold in percent	<i>optional parameter with default value: 90L</i> Used to specify PON or

68 Channel Pair Configuration Commands

Parameter	Type	Description
	- range: [1...100]	Channel-Pair deactivated ONT detection high clear threshold in percent.
[no] low	Parameter type: <Gpon::DeactOnuTcaPctLow> Format: - tca threshold in percent - range: [1...100]	<i>optional parameter with default value: 40L</i> Used to specify PON or Channel-Pair deactivated ONT detection low threshold in percent.
[no] low-clr	Parameter type: <Gpon::DeactOnuTcaPctLow> Format: - tca threshold in percent - range: [1...100]	<i>optional parameter with default value: 40L</i> Used to specify PON or Channel-Pair deactivated ONT detection low clear threshold in percent.

68.18 Deactivate Ont threshold Configuration Commands

Command Description

This command allows the operator to configure deactivate ont threshold.

User Level

The command can be accessed by operators with equipment privileges, and executed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

```
> configure channel-pair interface (chanpair-idx) deact-ont-tca threshold-number [ no high | high
<Gpon::DeactOnuTcaNbrHigh> ] [ no high-clr | high-clr <Gpon::DeactOnuTcaNbrHigh> ] [ no low | low
<Gpon::DeactOnuTcaNbrLow> ] [ no low-clr | low-clr <Gpon::DeactOnuTcaNbrLow> ]
```

Command Parameters

Table 68.18-1 "Deactivate Ont threshold Configuration Commands" Resource Parameters

Resource Identifier	Type	Description
(chanpair-idx)	Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::ChannelPairId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::ChannelPairId> - the channel pair identifier	channel pair index

Table 68.18-2 "Deactivate Ont threshold Configuration Commands" Command Parameters

Parameter	Type	Description
[no] high	Parameter type: <Gpon::DeactOnuTcaNbrHigh> Format: - tca threshold in number - range: [1...128]	<i>optional parameter with default value: 57L</i> Used to specify PON or Channel-Pair deactivated ONT detection high threshold in number.
[no] high-clr	Parameter type: <Gpon::DeactOnuTcaNbrHigh> Format: - tca threshold in number	<i>optional parameter with default value: 57L</i> Used to specify PON or

68 Channel Pair Configuration Commands

Parameter	Type	Description
	- range: [1...128]	Channel-Pair deactivated ONT detection high clear threshold in number.
[no] low	Parameter type: <Gpon::DeactOnuTcaNbrLow> Format: - tca threshold in number - range: [1...128]	<i>optional parameter with default value: 25L</i> Used to specify PON or Channel-Pair deactivated ONT detection low threshold in number.
[no] low-clr	Parameter type: <Gpon::DeactOnuTcaNbrLow> Format: - tca threshold in number - range: [1...128]	<i>optional parameter with default value: 25L</i> Used to specify PON or Channel-Pair deactivated ONT detection low clear threshold in number.

68.19 Trouble-Shooting threshold Configuration Commands

Command Description

This command is to configure the ethernet traffic tca detect interval

User Level

The command can be accessed by operators with security privileges, and executed by operators with security privileges.

Command Syntax

The command has the following syntax:

```
> configure channel-pair troubleshooting [ no bw-meter-interval | bw-meter-interval <Gpon::TcaDetectIntval> ]
```

Command Parameters

Table 68.19-2 "Trouble-Shooting threshold Configuration Commands" Command Parameters

Parameter	Type	Description
[no] bw-meter-interval	Parameter type: <Gpon::TcaDetectIntval> Format: - ethernet traffic tca detect interval for pon in second - range: [60...86400]	<i>optional parameter with default value: "300"</i> ethernet traffic tca detect interval for channel pair in second

69- Epon Configuration Commands

69.1 Epon Configuration Command Tree	69-1813
69.2 Epon Interface Configuration Command	69-1814
69.3 OTDR enable Command for PON	69-1818

69.1 Epon Configuration Command Tree

Description

This chapter gives an overview of nodes that are handled by "Epon Configuration Commands".

Command Tree

```

----configure
  ----epon
    ----[no] interface
      - (epon-idx)
      - [no] polling-period
      - [no] dba-polling0
      - [no] dba-polling1
      - [no] dba-polling2
      - [no] dba-polling3
      - [no] dba-polling4
      - [no] dba-polling5
      - [no] dba-polling6
      - [no] dba-polling7
      - [no] auth-mode
      - [no] pm-collect
      - [no] fec-dn
      - [no] rssi
      - [no] rx-pwr-low
      - [no] rx-pwr-high
      - [no] op-module-type
      - [no] pon-port-mode
      - [no] idlepwrta
      - [no] idlepwrthreshold
    ----otdr
      - [no] mode

```

69.2 Epon Interface Configuration Command

Command Description

This command allows the operator to configure the provisioning data associated with a EPON interface.

Note: The value of sig-degrade-th must be greater than sig-fail-th (i.e. sig-degrade-th must represent a lower BER value).

The value of fec-dn can be changed only after setting the administrative status to down. If the FEC change is made while the adm in status is up, then it must be set to down and then put back to up for the change to take place.

User Level

The command can be accessed by operators with equipment privileges, and executed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

```
> configure epon ( no interface (epon-idx) ) | ( interface (epon-idx) [ no polling-period | polling-period
<epon::pollingperiod> ] [ no dba-polling0 | dba-polling0 <epon::dbapollinginterval0> ] [ no dba-polling1 |
dba-polling1 <epon::dbapollinginterval1> ] [ no dba-polling2 | dba-polling2 <epon::dbapollinginterval2> ] [ no
dba-polling3 | dba-polling3 <epon::dbapollinginterval3> ] [ no dba-polling4 | dba-polling4
<epon::dbapollinginterval4> ] [ no dba-polling5 | dba-polling5 <epon::dbapollinginterval5> ] [ no dba-polling6 |
dba-polling6 <epon::dbapollinginterval6> ] [ no dba-polling7 | dba-polling7 <epon::dbapollinginterval7> ] [ no
auth-mode | auth-mode <epon::authmode> ] [ no pm-collect | pm-collect <epon::pmcollect> ] [ no fec-dn | fec-dn
<epon::fecdn> ] [ no rssi | rssi <epon::rssiadmind> ] [ no rx-pwr-low | rx-pwr-low <epon::rxpowerlow> ] [ no
rx-pwr-high | rx-pwr-high <epon::rxpowerhigh> ] [ no op-module-type | op-module-type <epon::opmoduletype> ] [
no pon-port-mode | pon-port-mode <epon::ponportmode> ] [ no idlepwrta | idlepwrta <epon::idlepwrta> ] [ no
idlepwrthreshold | idlepwrthreshold <epon::idlth> ] )
```

Command Parameters

Table 69.2-1 "Epon Interface Configuration Command" Resource Parameters

Resource Identifier	Type	Description
(epon-idx)	Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier	Pon interface

Table 69.2-2 "Epon Interface Configuration Command" Command Parameters

Parameter	Type	Description
[no] polling-period	Parameter type: <epon::pollingperiod> Format: - discovery window for onu register - range: [10...65540]	<i>optional parameter with default value: 1000L</i> discovery window for ONT register
[no] dba-polling0	Parameter type: <epon::dbapollinginterval0> Format: - DBA polling interval per pon interface - range: [0...65535]	<i>optional parameter with default value: 15L</i> DBA polling interval time for level-0
[no] dba-polling1	Parameter type: <epon::dbapollinginterval1> Format: - DBA polling interval per pon interface - range: [0...65535]	<i>optional parameter with default value: 30L</i> DBA polling interval time for level-1
[no] dba-polling2	Parameter type: <epon::dbapollinginterval2> Format: - DBA polling interval per pon interface - range: [0...65535]	<i>optional parameter with default value: 60L</i> DBA polling interval time for level-2
[no] dba-polling3	Parameter type: <epon::dbapollinginterval3> Format: - DBA polling interval per pon interface - range: [0...65535]	<i>optional parameter with default value: 60L</i> DBA polling interval time for level-3
[no] dba-polling4	Parameter type: <epon::dbapollinginterval4> Format: - DBA polling interval per pon interface - range: [0...65535]	<i>optional parameter with default value: 60L</i> DBA polling interval time for level-4
[no] dba-polling5	Parameter type: <epon::dbapollinginterval5> Format: - DBA polling interval per pon interface - range: [0...65535]	<i>optional parameter with default value: 60L</i> DBA polling interval time for level-5
[no] dba-polling6	Parameter type: <epon::dbapollinginterval6> Format: - DBA polling interval per pon interface - range: [0...65535]	<i>optional parameter with default value: 60L</i> DBA polling interval time for level-6
[no] dba-polling7	Parameter type: <epon::dbapollinginterval7> Format: - DBA polling interval per pon interface - range: [0...65535]	<i>optional parameter with default value: 60L</i> DBA polling interval time for level-7
[no] auth-mode	Parameter type: <epon::authmode> Format: (mix mac logicalid) Possible values: - mix : - mac : - logicalid :	<i>optional parameter with default value: "mix"</i> authentication mode for ONT
[no] pm-collect	Parameter type: <epon::pmcollect> Format: (enable disable) Possible values: - enable : PM collection enabled - disable : PM collection disabled	<i>optional parameter with default value: "disable"</i> Performance monitor switch
[no] fec-dn	Parameter type: <epon::fecdn> Format: (enable disable) Possible values:	<i>optional parameter with default value: "disable"</i> enable or disable FEC in Downstream direction

69 Epon Configuration Commands

Parameter	Type	Description
	- enable : fec is enabled - disable : fec is disabled	
[no] rssi	Parameter type: <epon::rssiadmin> Format: (enable disable) Possible values: - enable : RSSI function enabled - disable : RSSI function disabled	<i>optional parameter with default value: "disable"</i> Enable or disable RSSI function on this PON
[no] rx-pwr-low	Parameter type: <epon::rxpowerlow> Format: <Epon::float> Field type <Epon::float> - OLT side TCA threshold - unit: dbm - range: [-40...8.2]	<i>optional parameter with default value: "-27"</i> alarm low threshold for RXPWR
[no] rx-pwr-high	Parameter type: <epon::rxpowerhigh> Format: <Epon::float> Field type <Epon::float> - OLT side TCA threshold - unit: dbm - range: [-40...8.2]	<i>optional parameter with default value: "-6"</i> alarm high threshold for RXPWR
[no] op-module-type	Parameter type: <epon::opmoduletype> Format: (auto 1000base-px20h 1000base-px20 10/1gbase-prx 10gbase-pr-d3 10g1g/1gbase-prx 10g1g/10gbase-pr) Possible values: - auto : auto - 1000base-px20h : 1000base-px20h - 1000base-px20 : 1000base-px20 - 10/1gbase-prx : 10/1gbase-prx - 10gbase-pr-d3 : 10gbase-pr-d3 - 10g1g/1gbase-prx : 10g1g/1gbase-prx - 10g1g/10gbase-pr : 10g1g/10gbase-pr	<i>optional parameter with default value: "auto"</i> identify optical module type
[no] pon-port-mode	Parameter type: <epon::ponportmode> Format: (1g 10g-asym 1g,10g-asym 10g-sym 1g,10g-sym 10g-asym,10g-sym 1g,10g-asym,10g-sym) Possible values: - 1g : 1g - 10g-asym : 10g asymmetric - 1g,10g-asym : 1g, 10g asymmetric - 10g-sym : 10g symmetric - 1g,10g-sym : 1g, 10g symmetric - 10g-asym,10g-sym : 10g asymmetric, 10g symmetric - 1g,10g-asym,10g-sym : 1g, 10g asymmetric, 10g	<i>optional parameter with default value: "1g,10g-asym,10g-sym"</i> Pon port mode, to limit the registered ont type

Parameter	Type	Description
	symmetric	
[no] idlepwtca	Parameter type: <epon::idlepwtca> Format: (enable disable) Possible values: - enable : enable pon idle pwr monitor - disable : disable pon idle pwr monitor	<i>optional parameter with default value: "disable"</i> Pon idle pwr monitor
[no] idlepwrthreshold	Parameter type: <epon::idlth> Format: <Epon::floatidlepwr> Field type <Epon::floatidlepwr> - OLT side TCA threshold - unit: dbm - range: [-40...8.164]	<i>optional parameter with default value: "-30"</i> add a new idlepwrthreshold parameter

69.3 OTDR enable Command for PON

Command Description

This command allows the operator to enable or disable the otdr functionality on the given epon.

User Level

The command can be accessed by operators with equipment privileges, and executed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

```
> configure epon interface (epon-idx) otdr [ no mode | mode <Epon::OTDRenable> ]
```

Command Parameters

Table 69.3-1 "OTDR enable Command for PON" Resource Parameters

Resource Identifier	Type	Description
(epon-idx)	Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier	Pon interface

Table 69.3-2 "OTDR enable Command for PON" Command Parameters

Parameter	Type	Description
[no] mode	Parameter type: <Epon::OTDRenable> Format: (enable disable test) Possible values: - enable : otdr enable - disable : otdr disable - test : otdr test	<i>optional parameter with default value: "disable"</i> enable otdr

70- Epon Profile Configuration Commands

70.1 Epon Profile Configuration Command Tree	70-1820
70.2 Epon Filter Profile Configuration Command	70-1822
70.3 Epon Digit Map Profile Configuration Command	70-1829
70.4 Epon Alarm Control Profile Configuration Command	70-1830

70.1 Epon Profile Configuration Command Tree

Description

This chapter gives an overview of nodes that are handled by "Epon Profile Configuration Commands".

Command Tree

```
----configure
  ----epon
    ----profiles
      ----[no] filter
        - (profile-idx)
        - profile-name
        - [no] classfandv1
        - [no] classac1
        - [no] classfandv2
        - [no] classac2
        - [no] classfandv3
        - [no] classac3
        - [no] classfandv4
        - [no] classac4
      ----[no] digitmap
        - (profile-idx)
        - substr-idx
        - profile-name
        - substring
      ----[no] ontalarm
        - (name)
        - [no] equip-almr
        - [no] power-almr
        - [no] batt-miss
        - [no] batt-fail
        - [no] batt-volt-low
        - [no] phy-intr-almr
        - [no] selftest-fail
        - [no] otemp-hi-almr
        - [no] otemp-lo-almr
        - [no] iad-conn-fail
        - [no] pon-ifswitch
        - [no] rxpow-hi-almr
        - [no] rxpow-lo-almr
        - [no] txpow-hi-almr
        - [no] txpow-lo-almr
        - [no] txbi-hi-almr
        - [no] txbi-lo-almr
        - [no] vcc-hi-almr
        - [no] vcc-lo-almr
        - [no] temp-hi-almr
        - [no] temp-lo-almr
        - [no] rxpow-hi-warn
        - [no] rxpow-lo-warn
        - [no] txpow-hi-warn
```

- [no] txpow-lo-warn
- [no] txbi-hi-warn
- [no] txbi-lo-warn
- [no] vcc-hi-warn
- [no] vcc-lo-warn
- [no] temp-hi-warn
- [no] temp-lo-warn
- [no] ethp-aneg-fl
- [no] ethp-los
- [no] ethp-fail
- [no] ethp-loopback
- [no] ethp-conges
- [no] potsp-fail
- [no] e1port-fail
- [no] e1-tim-unlock
- [no] e1-los

70.2 Epon Filter Profile Configuration Command

Command Description

This command allows the operator to configure an ont filter profile.

Note: The profile could not be modified.

This object contains a table for defining classification and filter rules by operator. The max field for one rule could be specified is 4.

User Level

The command can be accessed by operators with equipment privileges, and executed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

```
> configure epon profiles ( no filter (profile-idx) ) | ( filter (profile-idx) profile-name <AsamProfileName> [ no
classfandv1 | classfandv1 <Epon::ClassVal> ] [ no classac1 | classac1 <Epon::ClassAc> ] [ no classfandv2 |
classfandv2 <Epon::ClassVal> ] [ no classac2 | classac2 <Epon::ClassAc> ] [ no classfandv3 | classfandv3
<Epon::ClassVal> ] [ no classac3 | classac3 <Epon::ClassAc> ] [ no classfandv4 | classfandv4 <Epon::ClassVal> ]
[ no classac4 | classac4 <Epon::ClassAc> ] )
```

Command Parameters

Table 70.2-1 "Epon Filter Profile Configuration Command" Resource Parameters

Resource Identifier	Type	Description
(profile-idx)	Format: - filter profile id - range: [1...8192]	index to the Profile

Table 70.2-2 "Epon Filter Profile Configuration Command" Command Parameters

Parameter	Type	Description
profile-name	Parameter type: <AsamProfileName> Format: - a profile name - range: [a-zA-Z0-9-_.] - length: 1<=x<=32	<i>mandatory parameter</i> A string 1..32 characters long which uniquely identifies this Profile
[no] classfandv1	Parameter type: <Epon::ClassVal> Format: (dmac : <Epon::Mac16Addr> smac : <Epon::Mac16Addr> vlanpriority : <Epon::ClassVal> vlanid : <Epon::ClassVal> ethtype : <Epon::EthHexType> dip : <Epon::IpAdd> sip : <Epon::IpAdd>	<i>optional parameter with default value: "noconfig : 65535"</i> field and value for classification

Parameter	Type	Description
	ipversion : <Epon::ClassVal> ipdscp : <Epon::ClassVal> ipprecedence : <Epon::ClassVal> sport : <Epon::ClassVal> dport : <Epon::ClassVal> ipprotocol : <Epon::ClassVal> noconfig : <Epon::ClassVal>) Possible values: - dmac : - smac : - vlanpriority : - vlanid : - ethtype : - dip : - sip : - ipversion : - ipdscp : - ipprecedence : - sport : - dport : - ipprotocol : - noconfig : fv not set value Field type <Epon::Mac16Addr> - mac-address (example : 01:02:03:04:05:06) - length: 6 Field type <Epon::IpAddr> - Source/Destination IP Address Field type <Epon::ClassVal> - EponTcClassifierFieldsType Field type <Epon::ClassVal> - EponTcClassifierFieldsType Field type <Epon::ClassVal> - EponTcClassifierFieldsType Field type <Epon::EthHexType> - eth type(example : 8860) - range: [a-fA-F0-9] - length: 1<=x<=4 Field type <Epon::ClassVal> - EponTcClassifierFieldsType Field type <Epon::ClassVal> - EponTcClassifierFieldsType Field type <Epon::ClassVal> - EponTcClassifierFieldsType Field type <Epon::ClassVal> - EponTcClassifierFieldsType Field type <Epon::ClassVal> - EponTcClassifierFieldsType	
[no] classac1	Parameter type: <Epon::ClassAc> Format: (match nomatch equal nonequal nogreater noless fieldexist fieldnoexist	<i>optional parameter with default value: "acnoconfig"</i> action for classification

70 Epon Profile Configuration Commands

Parameter	Type	Description
	acnoconfig) Possible values: - match : always match - nomatch : nevermatch - equal : equal - nonequal : not equal - nogreater : less than or equal - noless : greater than or equal - fieldexist : field exist - fieldnoexist : field not exist - acnoconfig : ac not set value	
[no] classfandv2	Parameter type: <Epon::ClassVal> Format: (dmac : <Epon::Mac16Addr> smac : <Epon::Mac16Addr> vlanpriority : <Epon::ClassVal> vlanid : <Epon::ClassVal> ethtype : <Epon::EthHexType> dip : <Epon::IpAdd> sip : <Epon::IpAdd> ipversion : <Epon::ClassVal> ipdscp : <Epon::ClassVal> ipprecedence : <Epon::ClassVal> sport : <Epon::ClassVal> dport : <Epon::ClassVal> ipprotocol : <Epon::ClassVal> noconfig : <Epon::ClassVal>) Possible values: - dmac : - smac : - vlanpriority : - vlanid : - ethtype : - dip : - sip : - ipversion : - ipdscp : - ipprecedence : - sport : - dport : - ipprotocol : - noconfig : fv not set value Field type <Epon::Mac16Addr> - mac-address (example : 01:02:03:04:05:06) - length: 6 Field type <Epon::IpAdd> - Source/Destination IP Address Field type <Epon::ClassVal> - EponTcClassifierFieldsType Field type <Epon::ClassVal> - EponTcClassifierFieldsType Field type <Epon::ClassVal> - EponTcClassifierFieldsType Field type <Epon::EthHexType> - eth type(example : 8860) - range: [a-fA-F0-9] - length: 1<=x<=4	<i>optional parameter with default value: "noconfig : 65535"</i> field and value for classification

Parameter	Type	Description
	Field type <Epon::ClassVal> - EponTcClassifierFieldsType Field type <Epon::ClassVal> - EponTcClassifierFieldsType Field type <Epon::ClassVal> - EponTcClassifierFieldsType Field type <Epon::ClassVal> - EponTcClassifierFieldsType Field type <Epon::ClassVal> - EponTcClassifierFieldsType	
[no] classac2	Parameter type: <Epon::ClassAc> Format: (match nomatch equal nonequal nogreater noless fieldexist fieldnoexist acnoconfig) Possible values: - match : always match - nomatch : nevermatch - equal : equal - nonequal : not equal - nogreater : less than or equal - noless : greater than or equal - fieldexist : field exist - fieldnoexist : field not exist - acnoconfig : ac not set value	<i>optional parameter with default value: "acnoconfig"</i> action for classification
[no] classfandv3	Parameter type: <Epon::ClassVal> Format: (dmac : <Epon::Mac16Addr> smac : <Epon::Mac16Addr> vlanpriority : <Epon::ClassVal> vlanid : <Epon::ClassVal> ethtype : <Epon::EthHexType> dip : <Epon::IpAdd> sip : <Epon::IpAdd> ipversion : <Epon::ClassVal> ipdscp : <Epon::ClassVal> ipprecedence : <Epon::ClassVal> sport : <Epon::ClassVal> dport : <Epon::ClassVal> ipprotocol : <Epon::ClassVal> noconfig : <Epon::ClassVal>) Possible values: - dmac : - smac : - vlanpriority : - vlanid : - ethtype : - dip : - sip : - ipversion : - ipdscp :	<i>optional parameter with default value: "noconfig : 65535"</i> field and value for classification

70 Epon Profile Configuration Commands

Parameter	Type	Description
	- ipprecedence : - sport : - dport : - ipprotocol : - noconfig : fv not set value - Field type <Epon::Mac16Addr> - mac-address (example : 01:02:03:04:05:06) - length: 6 - Field type <Epon::IpAdd> - Source/Destination IP Address - Field type <Epon::ClassVal> - EponTcClassifierFieldsType - Field type <Epon::ClassVal> - EponTcClassifierFieldsType - Field type <Epon::ClassVal> - EponTcClassifierFieldsType - Field type <Epon::EthHexType> - eth type(example : 8860) - range: [a-fA-F0-9] - length: 1<=x<=4 - Field type <Epon::ClassVal> - EponTcClassifierFieldsType - Field type <Epon::ClassVal> - EponTcClassifierFieldsType - Field type <Epon::ClassVal> - EponTcClassifierFieldsType - Field type <Epon::ClassVal> - EponTcClassifierFieldsType - Field type <Epon::ClassVal> - EponTcClassifierFieldsType	
[no] classac3	Parameter type: <Epon::ClassAc> Format: (match nomatch equal nonequal nogreater noless fieldexist fieldnoexist acnoconfig) Possible values: - match : always match - nomatch : nevermatch - equal : equal - nonequal : not equal - nogreater : less than or equal - noless : greater than or equal - fieldexist : field exist - fieldnoexist : field not exist - acnoconfig : ac not set value	<i>optional parameter with default value: "acnoconfig"</i> action for classification
[no] classfandv4	Parameter type: <Epon::ClassVal> Format: (dmac : <Epon::Mac16Addr> smac : <Epon::Mac16Addr> vlanpriority : <Epon::ClassVal> vlanid : <Epon::ClassVal>	<i>optional parameter with default value: "noconfig : 65535"</i> field and value for classification

Parameter	Type	Description
	ethtype : <Epon::EthHexType> dip : <Epon::IpAddr> sip : <Epon::IpAddr> ipversion : <Epon::ClassVal> ipdscp : <Epon::ClassVal> ipprecedence : <Epon::ClassVal> sport : <Epon::ClassVal> dport : <Epon::ClassVal> ipprotocol : <Epon::ClassVal> noconfig : <Epon::ClassVal>) Possible values: - dmac : - smac : - vlanpriority : - vlanid : - ethtype : - dip : - sip : - ipversion : - ipdscp : - ipprecedence : - sport : - dport : - ipprotocol : - noconfig : fv not set value Field type <Epon::Mac16Addr> - mac-address (example : 01:02:03:04:05:06) - length: 6 Field type <Epon::IpAddr> - Source/Destination IP Address Field type <Epon::ClassVal> - EponTcClassifierFieldsType Field type <Epon::ClassVal> - EponTcClassifierFieldsType Field type <Epon::ClassVal> - EponTcClassifierFieldsType Field type <Epon::EthHexType> - eth type(example : 8860) - range: [a-fA-F0-9] - length: 1<=x<=4 Field type <Epon::ClassVal> - EponTcClassifierFieldsType Field type <Epon::ClassVal> - EponTcClassifierFieldsType Field type <Epon::ClassVal> - EponTcClassifierFieldsType Field type <Epon::ClassVal> - EponTcClassifierFieldsType Field type <Epon::ClassVal> - EponTcClassifierFieldsType	
[no] classac4	Parameter type: <Epon::ClassAc> Format: (match nomatch equal nonequal nogreater	<i>optional parameter with default value: "acnoconfig"</i> action for classification

70 Epon Profile Configuration Commands

Parameter	Type	Description
	noless fieldexist fieldnoexist acnoconfig) Possible values: - match : always match - nomatch : nevermatch - equal : equal - nonequal : not equal - nogreater : less than or equal - noless : greater than or equal - fieldexist : field exist - fieldnoexist : field not exist - acnoconfig : ac not set value	

70.3 Epon Digit Map Profile Configuration Command

Command Description

This command allows the operator to configure a sip digit map profile.

profile-name - A string 1..32 characters long which uniquely identifies this Profile.

substring - SIP Digit Map string.

User Level

The command can be accessed by operators with equipment privileges, and executed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

```
> configure epon profiles ( no digitmap (profile-idx) substr-idx <AsamProfileIndex> ) | ( digitmap (profile-idx)
  substr-idx <AsamProfileIndex> profile-name <AsamProfileName> substring <Epon::substring> )
```

Command Parameters

Table 70.3-1 "Epon Digit Map Profile Configuration Command" Resource Parameters

Resource Identifier	Type	Description
(profile-idx)	Format: - a profile index - range: [1...250]	index to the eponSIPDigitMapProfileTable
substr-idx	Parameter type: <AsamProfileIndex> Format: - a profile index - range: [1...250]	sub-string index to the eponSIPDigitMapProfileTable

Table 70.3-2 "Epon Digit Map Profile Configuration Command" Command Parameters

Parameter	Type	Description
profile-name	Parameter type: <AsamProfileName> Format: - a profile name - range: [a-zA-Z0-9-_.] - length: 1<=x<=32	<i>mandatory parameter</i> A string 1 to 32 characters long which uniquely identifies this Profile
substring	Parameter type: <Epon::substring> Format: - sub string index to the SIP Digit Map Profile - length: x<=256	<i>mandatory parameter</i> SIP Digit Map string

70.4 Epon Alarm Control Profile Configuration Command

Command Description

This command allows the operator to configures an ont alarm control profile.

Note: The profile can be modified.

This object contains a table for defining alarm control bitmap by operator. Each bit indicates a sort of ONU alarm is enable or disable

User Level

The command can be accessed by operators with equipment privileges, and executed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

```
> configure epon profiles ( no ontalarm (name) ) | ( ontalarm (name) [ [ no ] equip-alm ] [ [ no ] power-alm ] [ [ no ] batt-miss ] [ [ no ] batt-fail ] [ [ no ] batt-volt-low ] [ [ no ] phy-intr-alm ] [ [ no ] selftest-fail ] [ [ no ] otemp-hi-alm ] [ [ no ] otemp-lo-alm ] [ [ no ] iad-conn-fail ] [ [ no ] pon-ifswitch ] [ [ no ] rxpow-hi-alm ] [ [ no ] rxpow-lo-alm ] [ [ no ] txpow-hi-alm ] [ [ no ] txpow-lo-alm ] [ [ no ] txbi-hi-alm ] [ [ no ] txbi-lo-alm ] [ [ no ] vcc-hi-alm ] [ [ no ] vcc-lo-alm ] [ [ no ] temp-hi-alm ] [ [ no ] temp-lo-alm ] [ [ no ] rxpow-hi-warn ] [ [ no ] rxpow-lo-warn ] [ [ no ] txpow-hi-warn ] [ [ no ] txpow-lo-warn ] [ [ no ] txbi-hi-warn ] [ [ no ] txbi-lo-warn ] [ [ no ] vcc-hi-warn ] [ [ no ] vcc-lo-warn ] [ [ no ] temp-hi-warn ] [ [ no ] temp-lo-warn ] [ [ no ] ethp-aneg-fl ] [ [ no ] ethp-los ] [ [ no ] ethp-fail ] [ [ no ] ethp-loopback ] [ [ no ] ethp-conges ] [ [ no ] potsp-fail ] [ [ no ] e1port-fail ] [ [ no ] e1-tim-unlock ] [ [ no ] e1-los ] )
```

Command Parameters

Table 70.4-1 "Epon Alarm Control Profile Configuration Command" Resource Parameters

Resource Identifier	Type	Description
(name)	Format: - name of the Alarm Control profile - length: 1<=x<=32	A unique profile name

Table 70.4-2 "Epon Alarm Control Profile Configuration Command" Command Parameters

Parameter	Type	Description
[no] equip-alm	Parameter type: boolean	<i>optional parameter</i> enable EquipmentAlarm
[no] power-alm	Parameter type: boolean	<i>optional parameter</i> enable PowerAlarm
[no] batt-miss	Parameter type: boolean	<i>optional parameter</i> enable BatteryMissing
[no] batt-fail	Parameter type: boolean	<i>optional parameter</i>

Parameter	Type	Description
		enable BatteryFailure
[no] batt-volt-low	Parameter type: boolean	<i>optional parameter</i> enable BatteryVoltLow
[no] phy-intr-alm	Parameter type: boolean	<i>optional parameter</i> enable PhysicalIntrusionAlarm
[no] selftest-fail	Parameter type: boolean	<i>optional parameter</i> enable ONUSelfTestFailure
[no] otemp-hi-alm	Parameter type: boolean	<i>optional parameter</i> enable ONUTempHighAlarm
[no] otemp-lo-alm	Parameter type: boolean	<i>optional parameter</i> enable ONUTempLowAlarm
[no] iad-conn-fail	Parameter type: boolean	<i>optional parameter</i> enable IADConnectionFailure
[no] pon-ifswitch	Parameter type: boolean	<i>optional parameter</i> enable PON_IFSwitch
[no] rxpow-hi-alm	Parameter type: boolean	<i>optional parameter</i> enable RXPowerHighAlarm
[no] rxpow-lo-alm	Parameter type: boolean	<i>optional parameter</i> enable RXPowerLowAlarm
[no] txpow-hi-alm	Parameter type: boolean	<i>optional parameter</i> enable TXPowerHighAlarm
[no] txpow-lo-alm	Parameter type: boolean	<i>optional parameter</i> enable TXPowerLowAlarm
[no] txbi-hi-alm	Parameter type: boolean	<i>optional parameter</i> enable TXBiasHighAlarm
[no] txbi-lo-alm	Parameter type: boolean	<i>optional parameter</i> enable TXBiasLowAlarm
[no] vcc-hi-alm	Parameter type: boolean	<i>optional parameter</i> enable VccHighAlarm
[no] vcc-lo-alm	Parameter type: boolean	<i>optional parameter</i> enable VccLowAlarm
[no] temp-hi-alm	Parameter type: boolean	<i>optional parameter</i> enable TempHighAlarm
[no] temp-lo-alm	Parameter type: boolean	<i>optional parameter</i> enable TempLowAlarm
[no] rxpow-hi-warn	Parameter type: boolean	<i>optional parameter</i> enable RXPowerHighWarning
[no] rxpow-lo-warn	Parameter type: boolean	<i>optional parameter</i> enable RXPowerLowWarning
[no] txpow-hi-warn	Parameter type: boolean	<i>optional parameter</i> enable TXPowerHighWarning
[no] txpow-lo-warn	Parameter type: boolean	<i>optional parameter</i> enable TXPowerLowWarning
[no] txbi-hi-warn	Parameter type: boolean	<i>optional parameter</i> enable TXBiasHighWarning
[no] txbi-lo-warn	Parameter type: boolean	<i>optional parameter</i> enable TXBiasLowWarning
[no] vcc-hi-warn	Parameter type: boolean	<i>optional parameter</i> enable VccHighWarning
[no] vcc-lo-warn	Parameter type: boolean	<i>optional parameter</i> enable VccLowWarning
[no] temp-hi-warn	Parameter type: boolean	<i>optional parameter</i> enable TempHighWarning
[no] temp-lo-warn	Parameter type: boolean	<i>optional parameter</i> enable TempLowWarning
[no] ethp-aneg-fl	Parameter type: boolean	<i>optional parameter</i> enable EthPortAutoNegFailure

70 Epon Profile Configuration Commands

Parameter	Type	Description
[no] ethp-los	Parameter type: boolean	<i>optional parameter</i> enable EthPortLOS
[no] ethp-fail	Parameter type: boolean	<i>optional parameter</i> enable EthPortFailure
[no] ethp-loopback	Parameter type: boolean	<i>optional parameter</i> enable EthPortLoopback
[no] ethp-conges	Parameter type: boolean	<i>optional parameter</i> enable EthPortCongestion
[no] potsp-fail	Parameter type: boolean	<i>optional parameter</i> enable POTSPortFailure
[no] e1port-fail	Parameter type: boolean	<i>optional parameter</i> enable E1PortFailure
[no] e1-tim-unlock	Parameter type: boolean	<i>optional parameter</i> enable E1TimingUnlock
[no] e1-los	Parameter type: boolean	<i>optional parameter</i> enable E1LOS

71- Epon Profile Configuration Commands

71.1 Epon Profile Configuration Command Tree	71-1834
71.2 OTDR enable Command for PON	71-1835

71.1 Epon Profile Configuration Command Tree

Description

This chapter gives an overview of nodes that are handled by "Epon Profile Configuration Commands".

Command Tree

```
----configure
  ----epon
    ----alarm
      ----[no] flag
        - (alarm-idx)
        - software-version
        - [no] fireware-version
        - flag-alarm-state
```

71.2 OTDR enable Command for PON

Command Description

This command allows the operator to enable or disable the otdr functionality on the given epon.

User Level

The command can be accessed by operators with equipment privileges, and executed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

```
> configure epon alarm ( no flag (alarm-idx) ) | ( flag (alarm-idx) software-version <Epon::SoftWareVersion> [ no
fireware-version | fireware-version <Epon::FireWareVersion> ] flag-alarm-state <Epon::FlagAlarmState> )
```

Command Parameters

Table 71.2-1 "OTDR enable Command for PON" Resource Parameters

Resource Identifier	Type	Description
(alarm-idx)	Format: - the epon alarm flag index - range: [1...250]	index to the alarm

Table 71.2-2 "OTDR enable Command for PON" Command Parameters

Parameter	Type	Description
software-version	Parameter type: <Epon::SoftWareVersion> Format: - Epon alarm sw version - length: x<=16	<i>mandatory parameter</i> the software version
[no] fireware-version	Parameter type: <Epon::FireWareVersion> Format: - Epon alarm fw version - length: x<=16	<i>optional parameter with default value: ""</i> the fireware version
flag-alarm-state	Parameter type: <Epon::FlagAlarmState> Format: (sameasctc21 diffwithctc21) Possible values: - sameasctc21 : alarm state is same as ctc - diffwithctc21 : alarm state is not same as ctc	<i>mandatory parameter</i> the flag alarm state

72- Tr069 Server Management Configuration Commands

72.1 Tr069 Server Management Configuration Command Tree	72-1837
72.2 ONT Tr069 Configuration Command	72-1838

72.1 Tr069 Server Management Configuration

Command Tree

Description

This chapter gives an overview of nodes that are handled by "Tr069 Server Management Configuration Commands".

Command Tree

```
----configure
  ----tr069serv
    ----[no] ont
      - (uni-idx)
      - [no] securi-prof
      - [no] vlan
      - [no] pbit
      - [no] admin-state
```

72.2 ONT Tr069 Configuration Command

Command Description

This command allows the operator to set ONT Tr069 provisioning data.

User Level

The command can be accessed by operators with equipment privileges, and executed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

```
> configure tr069serv ( no ont (uni-idx) ) | ( ont (uni-idx) [ no securi-prof | securi-prof
<Gpon::SecureUriProfilePointer> ] [ no vlan | vlan <Gpon::Tr069VlanId> ] [ no pbit | pbit <Gpon::Pbit> ] [ no
admin-state | admin-state <Gpon::AdminStatus> ] )
```

Command Parameters

Table 72.2-1 "ONT Tr069 Configuration Command" Resource Parameters

Resource Identifier	Type	Description
(uni-idx)	Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> / <Eqpt::OntPortId> ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / <Eqpt::Ng2OntSlotId> / <Eqpt::Ng2OntPortId> ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / vuni) Possible values: - ng2 : ngpon2 style identification Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Eqpt::ChannelGroupId> - the channel group identifier Field type <Eqpt::SubChannelGroupId> - the subchannel group identifier Field type <Eqpt::OntId> - the ONT identifier Field type <Eqpt::Ng2OntId>	identification of the uni interface index

Resource Identifier	Type	Description
	- the NG2 ONT identifier Possible values: - vuni : virtual NGPON2 uni identifier Field type <Eqpt::OntSlotId> - the ONT SLOT identifier Field type <Eqpt::OntPortId> - the ONT PORT identifier Field type <Eqpt::Ng2OntSlotId> - the NGPON2 ONT SLOT identifier Field type <Eqpt::Ng2OntPortId> - the NGPON2 ONT PORT identifier	

Table 72.2-2 "ONT Tr069 Configuration Command" Command Parameters

Parameter	Type	Description
[no] securi-prof	Parameter type: <Gpon::SecureUriProfilePointer> Format: (none <Gpon::SecureUriProfilePointer> name : <AsamProfileName>) Possible values: - none : no profile to associate - name : profile name Field type <Gpon::SecureUriProfilePointer> - profile index - range: [0...50] Data driven field type Possible values are depending on the actual configuration and software. The currently allowed values can be shown with online-help.	<i>optional parameter with default value: 0L</i> Tr069 server security profile pointer
[no] vlan	Parameter type: <Gpon::Tr069VlanId> Format: - vlan id for tr069 server - range: [1...4093,4097]	<i>optional parameter with default value: 4097</i> vlan id for tr069 server
[no] pbit	Parameter type: <Gpon::Pbit> Format: - gpon pbit - range: [0...7]	<i>optional parameter with default value: 0</i> p-bit value for tr069 server
[no] admin-state	Parameter type: <Gpon::AdminStatus> Format: (down up) Possible values: - down : set the admin-state to down - up : set the admin-state to up	<i>optional parameter with default value: "down"</i> administrative status of the interface

73- Snmp Agent Management Configuration Commands

73.1 Snmp Agent Management Configuration Command Tree	73-1841
73.2 ONT Snmp-agent Configuration Command	73-1842

73.1 Snmp Agent Management Configuration

Command Tree

Description

This chapter gives an overview of nodes that are handled by "Snmp Agent Management Configuration Commands".

Command Tree

```
----configure
  ----snmp-agent
    ----[no] ont
      - (uni-idx)
      - [no] read-community
      - [no] write-community
      - [no] iphc-vlan
```

73.2 ONT Snmp-agent Configuration Command

Command Description

This command allows the operator to set ONT Snmp-agent provisioning data.

User Level

The command can be accessed by operators with equipment privileges, and executed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

```
> configure snmp-agent ( no ont (uni-idx) ) | ( ont (uni-idx) [ no read-community | read-community
<Gpon::CommunityString> ] [ no write-community | write-community <Gpon::CommunityString> ] [ no iphc-vlan
| iphc-vlan <Gpon::MgmtVlanId> ] )
```

Command Parameters

Table 73.2-1 "ONT Snmp-agent Configuration Command" Resource Parameters

Resource Identifier	Type	Description
(uni-idx)	Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> / <Eqpt::OntPortId> ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / <Eqpt::Ng2OntSlotId> / <Eqpt::Ng2OntPortId> ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / vuni) Possible values: - ng2 : ngpon2 style identification Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Eqpt::ChannelGroupId> - the channel group identifier Field type <Eqpt::SubChannelGroupId> - the subchannel group identifier Field type <Eqpt::OntId> - the ONT identifier Field type <Eqpt::Ng2OntId>	identification of the uni interface index

Resource Identifier	Type	Description
	- the NG2 ONT identifier Possible values: - vuni : virtual NGPON2 uni identifier Field type <Eqpt::OntSlotId> - the ONT SLOT identifier Field type <Eqpt::OntPortId> - the ONT PORT identifier Field type <Eqpt::Ng2OntSlotId> - the NGPON2 ONT SLOT identifier Field type <Eqpt::Ng2OntPortId> - the NGPON2 ONT PORT identifier	

Table 73.2-2 "ONT Snmp-agent Configuration Command" Command Parameters

Parameter	Type	Description
[no] read-community	Parameter type: <Gpon::CommunityString> Format: - ont community string - length: 1<=x<=24	<i>optional parameter with default value: "public"</i> read community for snmp agent
[no] write-community	Parameter type: <Gpon::CommunityString> Format: - ont community string - length: 1<=x<=24	<i>optional parameter with default value: "private"</i> write community for snmp agent
[no] iphc-vlan	Parameter type: <Gpon::MgmtVlanId> Format: - vlan id for management service - range: [0,1...4093]	<i>optional parameter with default value: 0</i> iphc vlan for snmp agent

74- Distributed Router Configuration Commands

74.1 Distributed Router Configuration Command Tree	74-1845
74.2 Drouter IP Configuration Command	74-1846
74.3 Inbound MPLS LSP Configuration Command	74-1848
74.4 Static Outbound MPLS LSP Configuration Command	74-1849
74.5 SDP Configuration Command	74-1851

74.1 Distributed Router Configuration Command Tree

Description

This chapter gives an overview of nodes that are handled by "Distributed Router Configuration Commands".

Command Tree

```

----configure
  ----dist-router
    ----[no] interface
      - (lt-vlan)
      - [no] addrtype
      - ip-address
      - [no] mpls
    ----mpls
      ----[no] interface
        - (index)
        - label-map
      ----[no] static-lsp
        - (lsp-name)
        - interface
        - push
        - [no] nexthopaddrtype
        - nexthop
    ----[no] sdp
      - (sdp-id)
      - lsp-name
  
```

74.2 Drouter IP Configuration Command

Command Description

This command allows the operator to configure a distributed router IP interface on a linecard and assign an IP address.

User Level

The command can be accessed by operators with drouter privileges, and executed by operators with drouter privileges.

Command Syntax

The command has the following syntax:

```
> configure dist-router ( no interface (lt-vlan) ) | ( interface (lt-vlan) [ no addrtype | addrtype
<Drouter::IpAddressType> ] ip-address <Drouter::IntfAddAndMask> [ [ no ] mpls ] )
```

Command Parameters

Table 74.2-1 "Drouter IP Configuration Command" Resource Parameters

Resource Identifier	Type	Description
(lt-vlan)	Format: (slot-vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> : <Eqpt::UnstackedVlan> slot-stacked : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> : <Eqpt::SVlan> : <Eqpt::CVlan>) Possible values: - slot-vlan : slot unstacked (supported vlan [1...4093]) - slot-stacked : slot stacked (supported cvlan [0...4093]) Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::UnstackedVlan> - unstacked vlan id Field type <Eqpt::SVlan> - service vlan id Field type <Eqpt::CVlan> - customer vlan id	lt-vlan index

Table 74.2-2 "Drouter IP Configuration Command" Command Parameters

Parameter	Type	Description
[no] addrtype	Parameter type: <Drouter::IpAddressType> Format: (ipv4	<i>optional parameter with default value: "ipv4"</i> specify the type of IP address

Parameter	Type	Description
	ipv6) Possible values: - ipv4 : ipv4 - ipv6 : ipv6	
ip-address	Parameter type: <Drouter::IntfAddAndMask> Format: <Drouter::V4AddressHex> / <Drouter::PrefixLength> Field type <Drouter::V4AddressHex> - IP Address Field type <Drouter::PrefixLength> - prefix length of the subnet - range: [1...31]	<i>mandatory parameter</i> specify IP Address
[no] mpls	Parameter type: boolean	<i>optional parameter</i> enable MPLS on the IP interface

74.3 Inbound MPLS LSP Configuration Command

Command Description

This command allows the operator to configure an inbound MPLS LSP, include the MPLS label of an incoming MPLS tunnel.

User Level

The command can be accessed by operators with drouter privileges, and executed by operators with drouter privileges.

Command Syntax

The command has the following syntax:

```
> configure dist-router mpls ( no interface (index) label-map <Drouter::InSegLabel> ) | ( interface (index) label-map <Drouter::InSegLabel> )
```

Command Parameters

Table 74.3-1 "Inbound MPLS LSP Configuration Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: (slot-vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> : <Eqpt::UnstackedVlan> slot-stacked : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> : <Eqpt::SVlan> : <Eqpt::CVlan>) Possible values: - slot-vlan : slot unstacked - slot-stacked : slot stacked Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::UnstackedVlan> - unstacked vlan id Field type <Eqpt::SVlan> - service vlan id Field type <Eqpt::CVlan> - customer vlan id	MPLS enabled ip interface index
label-map	Parameter type: <Drouter::InSegLabel> Format: - MPLS Insegment label - range: [32...1023]	Specify incoming MPLS label

74.4 Static Outbound MPLS LSP Configuration Command

Command Description

This command allows the operator to configure a static outbound MPLS LSP, include the MPLS label and nexthop of an outgoing MPLS tunnel.

User Level

The command can be accessed by operators with drouter privileges, and executed by operators with drouter privileges.

Command Syntax

The command has the following syntax:

```
> configure dist-router mpls ( no static-lsp (lsp-name) ) | ( static-lsp (lsp-name) interface <Drouter::IfIndex> push
<Drouter::OutLabel> [ no nexthopaddrtype | nexthopaddrtype <Drouter::IpAddressType> ] nexthop
<Ip::V4AddressHex> )
```

Command Parameters

Table 74.4-1 "Static Outbound MPLS LSP Configuration Command" Resource Parameters

Resource Identifier	Type	Description
(lsp-name)	Format: - LSP name - range: [a-zA-Z0-9-_.] - length: 1<=x<=32	Administrative name for the LSP

Table 74.4-2 "Static Outbound MPLS LSP Configuration Command" Command Parameters

Parameter	Type	Description
interface	Parameter type: <Drouter::IfIndex> Format: (slot-vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> : <Eqpt::UnstackedVlan> slot-stacked : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> : <Eqpt::SVlan> : <Eqpt::CVlan>) Possible values: - slot-vlan : slot unstacked - slot-stacked : slot stacked Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number	<i>mandatory parameter</i> specify the outgoing interface

74 Distributed Router Configuration Commands

Parameter	Type	Description
	Field type <Eqpt::UnstackedVlan> - unstacked vlan id Field type <Eqpt::SVlan> - service vlan id Field type <Eqpt::CVlan> - customer vlan id	
push	Parameter type: <Drouter::OutLabel> Format: - Out Label - range: [1...1048575]	<i>mandatory parameter</i> specify the outgoing label
[no] nexthopaddrtype	Parameter type: <Drouter::IpAddressType> Format: (ipv4 ipv6) Possible values: - ipv4 : ipv4 - ipv6 : ipv6	<i>optional parameter with default value: "ipv4"</i> specify the type of next hop IP address
nexthop	Parameter type: <Ip::V4AddressHex> Format: - IPv4-address	<i>mandatory parameter</i> Next hop IP address

74.5 SDP Configuration Command

Command Description

This command allows the operator to configure an SDP (typically corresponding to an MPLS tunnel).

User Level

The command can be accessed by operators with drouter privileges, and executed by operators with drouter privileges.

Command Syntax

The command has the following syntax:

```
> configure dist-router ( no sdp (sdp-id) ) | ( sdp (sdp-id) lsp-name <Drouter::MplsLspName> )
```

Command Parameters

Table 74.5-1 "SDP Configuration Command" Resource Parameters

Resource Identifier	Type	Description
(sdp-id)	Format: - SDP ID - range: [1...17407]	SDP Identifier

Table 74.5-2 "SDP Configuration Command" Command Parameters

Parameter	Type	Description
lsp-name	Parameter type: <Drouter::MplsLspName> Format: - LSP name - range: [a-zA-Z0-9-_.] - length: 1<=x<=32	<i>mandatory parameter</i> LSP name to set the LSP list

75- Distributed Service Configuration Commands

75.1 Distributed Service Configuration Command Tree	75-1853
75.2 Distributed Service Configuration Command	75-1854
75.3 SDP Binding Configuration Command	75-1856
75.4 APIPE SDP Binding Configuration Command	75-1857
75.5 VCL Binding Configuration Command	75-1858

75.1 Distributed Service Configuration Command Tree

Description

This chapter gives an overview of nodes that are handled by "Distributed Service Configuration Commands".

Command Tree

```
----configure
  ----[no] dist-service
    - (service-id)
    - [no] service-type
    - [no] qos-profile
  ----[no] sdp
    - (spoke-sdp-id)
    - egress-vc-label
    - ingress-vc-label
  ----apipe-sdp
    - (spoke-sdpid)
    - [no] max-cells
    - [no] max-delay
  ----[no] apipe-pvc
    - (atm-pvc)
    - in-mapped-vpi
    - in-mapped-vci
    - out-mapped-vpi
    - out-mapped-vci
```

75.2 Distributed Service Configuration Command

Command Description

This command allows the operator to configure a distributed service.

User Level

The command can be accessed by operators with drouter privileges, and executed by operators with drouter privileges.

Command Syntax

The command has the following syntax:

```
> configure dist-service (service-id) [ no service-type | service-type <Drouter::ServiceType> ] [ no qos-profile | qos-profile <Qos::QosSessionProfileName> ]
```

Command Parameters

Table 75.2-1 "Distributed Service Configuration Command" Resource Parameters

Resource Identifier	Type	Description
(service-id)	Format: - Service ID - range: [1...2147483647]	Service Identifier

Table 75.2-2 "Distributed Service Configuration Command" Command Parameters

Parameter	Type	Description
[no] service-type	Parameter type: <Drouter::ServiceType> Format: (unknown epipe p3pipe tls vprn ies mirror apipe fpipe ipipe cpipe) Possible values: - unknown : unknown - epipe : epipe - p3pipe : p3pipe - tls : tls - vprn : vprn - ies : ies - mirror : mirror	<i>optional parameter with default value: "apipe"</i> Service type to be configured

Parameter	Type	Description
	- apipe : apipe - fpipe : fpipe - ipipe : ipipe - cpipe : cpipe	
[no] qos-profile	Parameter type: <Qos::QosSessionProfileName> Format: (none name : <Qos::IgnoredQosProfileName>) Possible values: - none : no profile name to associate - name : enter profile name to be associated Data driven field type Possible values are depending on the actual configuration and software. The currently allowed values can be shown with online-help.	<i>optional parameter with default value: "none"</i> qos profile attached to the service

75.3 SDP Binding Configuration Command

Command Description

This command allows the operator to associate an SDP (typically corresponding to an MPLS tunnel) to a service.

User Level

The command can be accessed by operators with drouter privileges, and executed by operators with drouter privileges.

Command Syntax

The command has the following syntax:

```
> configure dist-service (service-id) ( no sdp (spoke-sdp-id) ) | ( sdp (spoke-sdp-id) egress-vc-label  
<Drouter::EgressLabel> ingress-vc-label <Drouter::IngressLabel> )
```

Command Parameters

Table 75.3-1 "SDP Binding Configuration Command" Resource Parameters

Resource Identifier	Type	Description
(service-id)	Format: - Service ID - range: [1...2147483647]	Service Identifier
(spoke-sdp-id)	Format: id : <Drouter::SdpId> Possible values: - id : SDP ID Field type <Drouter::SdpId> - SDP ID - range: [1...17407]	SDP Identifier

Table 75.3-2 "SDP Binding Configuration Command" Command Parameters

Parameter	Type	Description
egress-vc-label	Parameter type: <Drouter::EgressLabel> Format: - MPLS Egress label - range: [1...1048575]	<i>mandatory parameter</i> MPLS label used by this device to send packets out
ingress-vc-label	Parameter type: <Drouter::IngressLabel> Format: - MPLS ingress label - range: [2048...18431]	<i>mandatory parameter</i> MPLS label used by the far-end device

75.4 APIPE SDP Binding Configuration Command

Command Description

This command allows the operator to configure the particular association between an SDP (typically corresponding to an MPLS tunnel) and an APIPE service, including the specific handling of upstream cell concatenation. It is used to configure an ATM Pseudowire on a linecard.

User Level

The command can be accessed by operators with drouter privileges, and executed by operators with drouter privileges.

Command Syntax

The command has the following syntax:

```
> configure dist-service (service-id) apipe-sdp (spoke-sdpid) [ no max-cells | max-cells <Drouter::MaxCells> ] [ no max-delay | max-delay <Drouter::MaxDelay> ]
```

Command Parameters

Table 75.4-1 "APIPE SDP Binding Configuration Command" Resource Parameters

Resource Identifier	Type	Description
(service-id)	Format: - Service ID - range: [1...2147483647]	Service Identifier
(spoke-sdpid)	Format: id : <Drouter::SdpId> Possible values: - id : SDP ID Field type <Drouter::SdpId> - SDP ID - range: [1...17407]	SDP Identifier

Table 75.4-2 "APIPE SDP Binding Configuration Command" Command Parameters

Parameter	Type	Description
[no] max-cells	Parameter type: <Drouter::MaxCells> Format: - Maximum number of ATM cells to accumulate into a MPLS packet - range: [1...8]	<i>optional parameter with default value: 1</i> Maximum number of ATM cells to accumulate into a MPLS packet
[no] max-delay	Parameter type: <Drouter::MaxDelay> Format: - Maximum amount of time to wait while performing ATM cell concatenation into an MPLS packet - unit: msec - range: [1...10]	<i>optional parameter with default value: 4</i> Maximum amount of time to wait while performing ATM cell concatenation into an MPLS packet

75.5 VCL Binding Configuration Command

Command Description

This command allows the operator to configure an ATM cross-connect between an ATM PVC on the DSL line and the ATM VPI/VCI value used in an ATM Pseudowire.

User Level

The command can be accessed by operators with drouter privileges, and executed by operators with drouter privileges.

Command Syntax

The command has the following syntax:

```
> configure dist-service (service-id) ( no apipe-pvc (atm-pvc) ) | ( apipe-pvc (atm-pvc) in-mapped-vpi
<Drouter::InMappedVpi> in-mapped-vci <Drouter::InMappedVci> out-mapped-vpi <Drouter::OutMappedVpi>
out-mapped-vci <Drouter::OutMappedVci> )
```

Command Parameters

Table 75.5-1 "VCL Binding Configuration Command" Resource Parameters

Resource Identifier	Type	Description
(service-id)	Format: - Service ID - range: [1...2147483647]	Service Identifier
(atm-pvc)	Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::VpiId> : <Eqpt::VciId> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId>) Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number Field type <Eqpt::VpiId> - atm VPI Field type <Eqpt::VciId> - atm VCI	atm pvc index

Table 75.5-2 "VCL Binding Configuration Command" Command Parameters

Parameter	Type	Description
in-mapped-vpi	Parameter type: <Drouter::InMappedVpi> Format:	<i>mandatory parameter</i> atm inmapped vpi value for the

Parameter	Type	Description
	- In-mapped VPI - range: [0...255]	apipe service
in-mapped-vci	Parameter type: <Drouter::InMappedVci> Format: - In-mapped VCI - range: [32...65535]	<i>mandatory parameter</i> atm inmapped vci value for the apipe service
out-mapped-vpi	Parameter type: <Drouter::OutMappedVpi> Format: - Out-mapped VPI - range: [0...255]	<i>mandatory parameter</i> atm outmapped vpi value for the apipe service
out-mapped-vci	Parameter type: <Drouter::OutMappedVci> Format: - Out-mapped VCI - range: [32...65535]	<i>mandatory parameter</i> atm outmapped vci value for the apipe service

76- BCMP Configuration Commands

76.1 BCMP Configuration Command Tree	76-1861
76.2 BCMP system Configuration Commands	76-1862

76.1 BCMP Configuration Command Tree

Description

This chapter gives an overview of nodes that are handled by "BCMP Configuration Commands".

Command Tree

```
----configure
  ----bcmp
    ----system
      - [no] adminstate
      - [no] serveripaddr
      - [no] serverudpport
```

76.2 BCMP system Configuration Commands

Command Description

This command allows the operator to manage the BCMP system parameters.

User Level

The command can be accessed by operators with equipment privileges, and executed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

```
> configure bcmp system [ no adminstate | adminstate <bcmp::bcmpAdminState> ] [ no serveripaddr | serveripaddr <Ip::V4Address> ] [ no serverudpport | serverudpport <bcmp::bcmpServerUdpPort> ]
```

Command Parameters

Table 76.2-2 "BCMP system Configuration Commands" Command Parameters

Parameter	Type	Description
[no] adminstate	Parameter type: <bcmp::bcmpAdminState> Format: (enable-bcmp disable-bcmp) Possible values: - enable-bcmp : start bcmp protocol handling in the system - disable-bcmp : stop bcmp protocol handling in the system	<i>optional parameter with default value: "disable-bcmp"</i> the switch to specify the admin state of BCMP subsystem
[no] serveripaddr	Parameter type: <Ip::V4Address> Format: - IPv4-address	<i>optional parameter with default value: "192.168.100.100"</i> the IP address of BCMP server
[no] serverudpport	Parameter type: <bcmp::bcmpServerUdpPort> Format: - the Bcmp Server Udp port - range: [1...65535]	<i>optional parameter with default value: 5000</i> the Socket UDP port of BCMP server

77- System Level Generic Pon Config Commands

77.1 System Level Generic Pon Config Command Tree	77-1864
77.2 Generic PON Data Path Integrity Threshold command	77-1866
77.3 Generic PON Utilization PM Mode Configuration Command	77-1867
77.4 Generic PON Utilization TCA Threshold Configuration Command	77-1868
77.5 System ONT Configuration Command	77-1874
77.6 Power Shedding Profile Configuration Command	77-1876
77.7 OLT GIS info Configuration Command	77-1878
77.8 System PONLOS Alarm Re-define Switch	77-1880

77.1 System Level Generic Pon Config Command Tree

Description

This chapter gives an overview of nodes that are handled by "System Level Generic Pon Config Commands".

Command Tree

- configure
 - generic-pon
 - dpinteg-threshold
 - utilization
 - [no] pon-pmcollect
 - [no] ont-pmcollect
 - threshold
 - [no] txmcutilhi
 - [no] txmcutilmd
 - [no] txmcutillo
 - [no] txtotutilhi
 - [no] txtotutilmd
 - [no] txtotutillo
 - [no] rxtotutilhi
 - [no] rxtotutilmd
 - [no] rxtotutillo
 - [no] dbacongperiodhi
 - [no] dbacongperiodmd
 - [no] dbacongperiodlo
 - [no] txucdropfrmhi
 - [no] txucdropfrmmd
 - [no] txucdropfrmlo
 - [no] txmcdropfrmhi
 - [no] txmcdropfrmmd
 - [no] txmcdropfrmlo
 - [no] txbcdropfrmhi
 - [no] txbcdropfrmmd
 - [no] txbcdropfrmlo
 - [no] rxtotdropfrmhi
 - [no] rxtotdropfrmmd
 - [no] rxtotdropfrmlo
 - [no] numtcint
 - [no] numtcintdba
 - [no] dbacongthresh
- ont
 - [no] slid-mode
 - [no] sn-bundle-timer
 - [no] sw-ver-mis-block
 - [no] sn-autounlock
- [no] power-shed-prof
 - (profile-idx)
 - profile-name

- [no] restore-time
- [no] data-class-time
- [no] voice-class-time
- [no] video-class-time
- [no] dsl-class-time
- [no] ces-class-time

----gis-info

- [no] longitude
- [no] latitude
- [no] elevation
- [no] horizontal-error
- [no] altitude-error
- [no] area-code
- [no] timestamp
- [no] gis-digest
- [no] gis-check

----alarmflag

- [no] ponlos-alarm-ctrl

77.2 Generic PON Data Path Integrity Threshold command

Command Description

This command configures the PON/Channel-pair Data Path Integrity Threshold

User Level

The command can be accessed by operators with equipment privileges, and executed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

> configure generic-pon dpinteg-threshold <Gpon::dpintegThreshold>

Command Parameters

Table 77.2-2 "Generic PON Data Path Integrity Threshold command" Command Parameters

Parameter	Type	Description
dpinteg-threshold	Parameter type: <Gpon::dpintegThreshold> Format: - Datapath Integrity Threshold - range: [0...100]	<i>optional parameter</i> configure data-path integrity threshold value for gpon/ngpon2

77.3 Generic PON Utilization PM Mode Configuration Command

Command Description

This command configures the generic PON (system-wide) utilization performance monitoring modes for PONs and channel-pairs.

User Level

The command can be accessed by operators with equipment privileges, and executed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

```
> configure generic-pon utilization [ no pon-pmcollect | pon-pmcollect <Gpon::OntPmTcaCollect> ] [ no ont-pmcollect | ont-pmcollect <Gpon::OntPmCollect> ]
```

Command Parameters

Table 77.3-2 "Generic PON Utilization PM Mode Configuration Command" Command Parameters

Parameter	Type	Description
[no] pon-pmcollect	Parameter type: <Gpon::OntPmTcaCollect> Format: (none pm-enable tca-enable) Possible values: - none : no pm - pm-enable : enable pm - tca-enable : enable tca	<i>optional parameter with default value: "none"</i> system-wide PON / channel-pair utilization performance monitoring
[no] ont-pmcollect	Parameter type: <Gpon::OntPmCollect> Format: (enable disable) Possible values: - enable : enable PM - disable : disable PM	<i>optional parameter with default value: "disable"</i> system-wide utilization ONT detailed performance monitoring

77.4 Generic PON Utilization TCA Threshold Configuration Command

Command Description

This command configures the generic PON (system-wide) utilization TCA threshold parameters for PONs and channel-pairs.

User Level

The command can be accessed by operators with equipment privileges, and executed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

```
> configure generic-pon utilization threshold [ no txmcutilhi | txmcutilhi <Gpon::PonUtilTcaThresholdPercent> ] [
no txmcutilmd | txmcutilmd <Gpon::PonUtilTcaThresholdPercent> ] [ no txmcutillo | txmcutillo
<Gpon::PonUtilTcaThresholdPercent> ] [ no txtotutilhi | txtotutilhi <Gpon::PonUtilTcaThresholdPercent> ] [ no
txtotutilmd | txtotutilmd <Gpon::PonUtilTcaThresholdPercent> ] [ no txtotutillo | txtotutillo
<Gpon::PonUtilTcaThresholdPercent> ] [ no rxtotutilhi | rxtotutilhi <Gpon::PonUtilTcaThresholdPercent> ] [ no
rxtotutilmd | rxtotutilmd <Gpon::PonUtilTcaThresholdPercent> ] [ no rxtotutillo | rxtotutillo
<Gpon::PonUtilTcaThresholdPercent> ] [ no dbacongperiodhi | dbacongperiodhi
<Gpon::PonUtilTcaThresholdPercent> ] [ no dbacongperiodmd | dbacongperiodmd
<Gpon::PonUtilTcaThresholdPercent> ] [ no dbacongperiodlo | dbacongperiodlo
<Gpon::PonUtilTcaThresholdPercent> ] [ no txucdropfrmhi | txucdropfrmhi
<Gpon::PonUtilTcaDroppedPacketsThreshold> ] [ no txucdropfrmmd | txucdropfrmmd
<Gpon::PonUtilTcaDroppedPacketsThreshold> ] [ no txucdropfrmlo | txucdropfrmlo
<Gpon::PonUtilTcaDroppedPacketsThreshold> ] [ no txmcdropfrmhi | txmcdropfrmhi
<Gpon::PonUtilTcaDroppedPacketsThreshold> ] [ no txmcdropfrmmd | txmcdropfrmmd
<Gpon::PonUtilTcaDroppedPacketsThreshold> ] [ no txmcdropfrmlo | txmcdropfrmlo
<Gpon::PonUtilTcaDroppedPacketsThreshold> ] [ no txbcdropfrmhi | txbcdropfrmhi
<Gpon::PonUtilTcaDroppedPacketsThreshold> ] [ no txbcdropfrmmd | txbcdropfrmmd
<Gpon::PonUtilTcaDroppedPacketsThreshold> ] [ no txbcdropfrmlo | txbcdropfrmlo
<Gpon::PonUtilTcaDroppedPacketsThreshold> ] [ no rxtotdropfrmhi | rxtotdropfrmhi
<Gpon::PonUtilTcaDroppedPacketsThreshold> ] [ no rxtotdropfrmmd | rxtotdropfrmmd
<Gpon::PonUtilTcaDroppedPacketsThreshold> ] [ no rxtotdropfrmlo | rxtotdropfrmlo
<Gpon::PonUtilTcaDroppedPacketsThreshold> ] [ no numtcint | numtcint <Gpon::PonUtilTcaInterval> ] [ no
numtcintdba | numtcintdba <Gpon::PonUtilTcaInterval> ] [ no dbacongthresh | dbacongthresh
<Gpon::PonUtilTcaCongThreshold> ]
```

Command Parameters

Table 77.4-2 "Generic PON Utilization TCA Threshold Configuration Command" Command Parameters

Parameter	Type	Description
[no] txmcutilhi	Parameter type: <Gpon::PonUtilTcaThresholdPercent> Format: (disabled <Gpon::PonUtilTcaThresholdPercent>) Possible values: - disabled : threshold is disabled Field type <Gpon::PonUtilTcaThresholdPercent> - utilization percentage threshold - range: [0...100]	<i>optional parameter with default value: "disabled"</i> Utilization level (percentage) that will result in declaration of T-TXMCUTILHI alarm
[no] txmcutilmd	Parameter type: <Gpon::PonUtilTcaThresholdPercent> Format: (disabled <Gpon::PonUtilTcaThresholdPercent>) Possible values: - disabled : threshold is disabled Field type <Gpon::PonUtilTcaThresholdPercent> - utilization percentage threshold - range: [0...100]	<i>optional parameter with default value: "disabled"</i> Utilization level (percentage) that will result in declaration of T-TXMCUTILMD alarm
[no] txmcutillo	Parameter type: <Gpon::PonUtilTcaThresholdPercent> Format: (disabled <Gpon::PonUtilTcaThresholdPercent>) Possible values: - disabled : threshold is disabled Field type <Gpon::PonUtilTcaThresholdPercent> - utilization percentage threshold - range: [0...100]	<i>optional parameter with default value: "disabled"</i> Utilization level (percentage) that will result in declaration of T-TXMCUTILLO alarm
[no] txtotutilhi	Parameter type: <Gpon::PonUtilTcaThresholdPercent> Format: (disabled <Gpon::PonUtilTcaThresholdPercent>) Possible values: - disabled : threshold is disabled Field type <Gpon::PonUtilTcaThresholdPercent> - utilization percentage threshold - range: [0...100]	<i>optional parameter with default value: "disabled"</i> Utilization level (percentage) that will result in declaration of T-TXTOTUTILHI alarm
[no] txtotutilmd	Parameter type: <Gpon::PonUtilTcaThresholdPercent> Format: (disabled <Gpon::PonUtilTcaThresholdPercent>) Possible values: - disabled : threshold is disabled Field type <Gpon::PonUtilTcaThresholdPercent> - utilization percentage threshold - range: [0...100]	<i>optional parameter with default value: "disabled"</i> Utilization level (percentage) that will result in declaration of T-TXTOTUTILMD alarm
[no] txtotutillo	Parameter type: <Gpon::PonUtilTcaThresholdPercent> Format: (disabled <Gpon::PonUtilTcaThresholdPercent>) Possible values: - disabled : threshold is disabled Field type <Gpon::PonUtilTcaThresholdPercent> - utilization percentage threshold - range: [0...100]	<i>optional parameter with default value: "disabled"</i> Utilization level (percentage) that will result in declaration of T-TXTOTUTILLO alarm
[no] rxtotutilhi	Parameter type: <Gpon::PonUtilTcaThresholdPercent> Format: (disabled	<i>optional parameter with default value: "disabled"</i> Utilization level (percentage) that

77 System Level Generic Pon Config Commands

Parameter	Type	Description
	<Gpon::PonUtilTcaThresholdPercent>) Possible values: - disabled : threshold is disabled Field type <Gpon::PonUtilTcaThresholdPercent> - utilization percentage threshold - range: [0...100]	will result in declaration of T-RXTOTUTILHI alarm
[no] rxtotutilmd	Parameter type: <Gpon::PonUtilTcaThresholdPercent> Format: (disabled <Gpon::PonUtilTcaThresholdPercent>) Possible values: - disabled : threshold is disabled Field type <Gpon::PonUtilTcaThresholdPercent> - utilization percentage threshold - range: [0...100]	<i>optional parameter with default value: "disabled"</i> Utilization level (percentage) that will result in declaration of T-RXTOTUTILMD alarm
[no] rxtotutillo	Parameter type: <Gpon::PonUtilTcaThresholdPercent> Format: (disabled <Gpon::PonUtilTcaThresholdPercent>) Possible values: - disabled : threshold is disabled Field type <Gpon::PonUtilTcaThresholdPercent> - utilization percentage threshold - range: [0...100]	<i>optional parameter with default value: "disabled"</i> Utilization level (percentage) that will result in declaration of T-RXTOTUTILLO alarm
[no] dbacongperiodhi	Parameter type: <Gpon::PonUtilTcaThresholdPercent> Format: (disabled <Gpon::PonUtilTcaThresholdPercent>) Possible values: - disabled : threshold is disabled Field type <Gpon::PonUtilTcaThresholdPercent> - utilization percentage threshold - range: [0...100]	<i>optional parameter with default value: "disabled"</i> Utilization level (percentage) that will result in declaration of T-DBACONGPERIODHI alarm
[no] dbacongperiodmd	Parameter type: <Gpon::PonUtilTcaThresholdPercent> Format: (disabled <Gpon::PonUtilTcaThresholdPercent>) Possible values: - disabled : threshold is disabled Field type <Gpon::PonUtilTcaThresholdPercent> - utilization percentage threshold - range: [0...100]	<i>optional parameter with default value: "disabled"</i> Utilization level (percentage) that will result in declaration of T-DBACONGPERIODMD alarm
[no] dbacongperiodlo	Parameter type: <Gpon::PonUtilTcaThresholdPercent> Format: (disabled <Gpon::PonUtilTcaThresholdPercent>) Possible values: - disabled : threshold is disabled Field type <Gpon::PonUtilTcaThresholdPercent> - utilization percentage threshold - range: [0...100]	<i>optional parameter with default value: "disabled"</i> Utilization level (percentage) that will result in declaration of T-DBACONGPERIODLO alarm
[no] txucdropfrmhi	Parameter <Gpon::PonUtilTcaDroppedPacketsThreshold> Format: (disabled <Gpon::PonUtilTcaDroppedPacketsThreshold>) Possible values:	type: <i>optional parameter with default value: "disabled"</i> Number of dropped frames that will result in declaration of T-TXUCDROPFRMHI alarm

Parameter	Type	Description
	- disabled : threshold is disabled Field type <Gpon::PonUtilTcaDroppedPacketsThreshold> - dropped frames threshold - range: [0...1000000000]	
[no] txucdropfrmmd	Parameter type: <Gpon::PonUtilTcaDroppedPacketsThreshold> Format: (disabled <Gpon::PonUtilTcaDroppedPacketsThreshold>) Possible values: - disabled : threshold is disabled Field type <Gpon::PonUtilTcaDroppedPacketsThreshold> - dropped frames threshold - range: [0...1000000000]	<i>optional parameter with default value: "disabled"</i> Number of dropped frames that will result in declaration of T-TXUCDROPFRMMD alarm
[no] txucdropfrmlo	Parameter type: <Gpon::PonUtilTcaDroppedPacketsThreshold> Format: (disabled <Gpon::PonUtilTcaDroppedPacketsThreshold>) Possible values: - disabled : threshold is disabled Field type <Gpon::PonUtilTcaDroppedPacketsThreshold> - dropped frames threshold - range: [0...1000000000]	<i>optional parameter with default value: "disabled"</i> Number of dropped frames that will result in declaration of T-TXUCDROPFRMLO alarm
[no] txmcdropfrmhi	Parameter type: <Gpon::PonUtilTcaDroppedPacketsThreshold> Format: (disabled <Gpon::PonUtilTcaDroppedPacketsThreshold>) Possible values: - disabled : threshold is disabled Field type <Gpon::PonUtilTcaDroppedPacketsThreshold> - dropped frames threshold - range: [0...1000000000]	<i>optional parameter with default value: "disabled"</i> Number of dropped frames that will result in declaration of T-TXMCDROPFRMHI alarm
[no] txmcdropfrmmd	Parameter type: <Gpon::PonUtilTcaDroppedPacketsThreshold> Format: (disabled <Gpon::PonUtilTcaDroppedPacketsThreshold>) Possible values: - disabled : threshold is disabled Field type <Gpon::PonUtilTcaDroppedPacketsThreshold> - dropped frames threshold - range: [0...1000000000]	<i>optional parameter with default value: "disabled"</i> Number of dropped frames that will result in declaration of T-TXMCDROPFRMMD alarm
[no] txmcdropfrmlo	Parameter type: <Gpon::PonUtilTcaDroppedPacketsThreshold> Format: (disabled <Gpon::PonUtilTcaDroppedPacketsThreshold>) Possible values: - disabled : threshold is disabled Field type <Gpon::PonUtilTcaDroppedPacketsThreshold> - dropped frames threshold - range: [0...1000000000]	<i>optional parameter with default value: "disabled"</i> Number of dropped frames that will result in declaration of T-TXMCDROPFRMLO alarm
[no] txbcdropfrmhi	Parameter type: <Gpon::PonUtilTcaDroppedPacketsThreshold> Format:	<i>optional parameter with default value: "disabled"</i> Number of dropped frames that

77 System Level Generic Pon Config Commands

Parameter	Type	Description
	(disabled <Gpon::PonUtilTcaDroppedPacketsThreshold>) Possible values: - disabled : threshold is disabled Field type <Gpon::PonUtilTcaDroppedPacketsThreshold> - dropped frames threshold - range: [0...1000000000]	will result in declaration of T-TXBCDROPFMRMHI alarm
[no] txbcdropfrmmmd	Parameter type: <Gpon::PonUtilTcaDroppedPacketsThreshold> Format: (disabled <Gpon::PonUtilTcaDroppedPacketsThreshold>) Possible values: - disabled : threshold is disabled Field type <Gpon::PonUtilTcaDroppedPacketsThreshold> - dropped frames threshold - range: [0...1000000000]	<i>optional parameter with default value: "disabled"</i> Number of dropped frames that will result in declaration of T-TXBCDROPFMRMMD alarm
[no] txbcdropfrmlo	Parameter type: <Gpon::PonUtilTcaDroppedPacketsThreshold> Format: (disabled <Gpon::PonUtilTcaDroppedPacketsThreshold>) Possible values: - disabled : threshold is disabled Field type <Gpon::PonUtilTcaDroppedPacketsThreshold> - dropped frames threshold - range: [0...1000000000]	<i>optional parameter with default value: "disabled"</i> Number of dropped frames that will result in declaration of T-TXBCDROPFMRMLO alarm
[no] rxtotdropfrmhi	Parameter type: <Gpon::PonUtilTcaDroppedPacketsThreshold> Format: (disabled <Gpon::PonUtilTcaDroppedPacketsThreshold>) Possible values: - disabled : threshold is disabled Field type <Gpon::PonUtilTcaDroppedPacketsThreshold> - dropped frames threshold - range: [0...1000000000]	<i>optional parameter with default value: "disabled"</i> Dropped frames that will result in declaration of T-RXTOTCDROPFMRMHI alarm
[no] rxtotdropfrmmmd	Parameter type: <Gpon::PonUtilTcaDroppedPacketsThreshold> Format: (disabled <Gpon::PonUtilTcaDroppedPacketsThreshold>) Possible values: - disabled : threshold is disabled Field type <Gpon::PonUtilTcaDroppedPacketsThreshold> - dropped frames threshold - range: [0...1000000000]	<i>optional parameter with default value: "disabled"</i> Number of dropped frames that will result in declaration of T-RXTOTCDROPFMRMMD alarm
[no] rxtotdropfrmlo	Parameter type: <Gpon::PonUtilTcaDroppedPacketsThreshold> Format: (disabled <Gpon::PonUtilTcaDroppedPacketsThreshold>) Possible values: - disabled : threshold is disabled Field type <Gpon::PonUtilTcaDroppedPacketsThreshold> - dropped frames threshold - range: [0...1000000000]	<i>optional parameter with default value: "disabled"</i> Number of dropped frames that will result in declaration of T-RXTOTCDROPFMRMLO alarm

Parameter	Type	Description
[no] numtcint	Parameter type: <Gpon::PonUtilTcaInterval> Format: (1 <Gpon::PonUtilTcaInterval>) Possible values: - 1 : Initial Default Field type <Gpon::PonUtilTcaInterval> - interval threshold - range: [1...96]	<i>optional parameter with default value: "1"</i> Number of contiguous 5-minute intervals for the non-DBA PON utilization thresholds to be exceeded for TCA alarm generation or clearing
[no] numtcintdba	Parameter type: <Gpon::PonUtilTcaInterval> Format: (1 <Gpon::PonUtilTcaInterval>) Possible values: - 1 : Initial Default Field type <Gpon::PonUtilTcaInterval> - interval threshold - range: [1...96]	<i>optional parameter with default value: "1"</i> Number of contiguous 5-minute intervals for the DBA PON congestion thresholds to be exceeded for TCA alarm generation or clearing
[no] dbacongthresh	Parameter type: <Gpon::PonUtilTcaCongThreshold> Format: (90 <Gpon::PonUtilTcaCongThreshold>) Possible values: - 90 : Initial Default Field type <Gpon::PonUtilTcaCongThreshold> - dba congestion percentage threshold - range: [0...100]	<i>optional parameter with default value: "90"</i> Configured DBA congestion threshold as a percentage of the maximum consumable bandwidth

77.5 System ONT Configuration Command

Command Description

This command is to configure the system wide ONT related parameters.

User Level

The command can be accessed by operators with equipment privileges, and executed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

```
> configure generic-pon ont [ no slid-mode | slid-mode <Gpon::SlidMode> ] [ no sn-bundle-timer | sn-bundle-timer
<Gpon::SnBundleTimer> ] [ no sw-ver-mis-block | sw-ver-mis-block <Gpon::SwVerMisBlock> ] [ no
sn-autounlock | sn-autounlock <Gpon::OntAuthMode> ]
```

Command Parameters

Table 77.5-2 "System ONT Configuration Command" Command Parameters

Parameter	Type	Description
[no] slid-mode	Parameter type: <Gpon::SlidMode> Format: (ascii hexa-dec) Possible values: - ascii : ascii interpretation for subscriber location - hexa-dec : hexadecimal mode interpretation for subscriber location	<i>optional parameter with default value: "ascii"</i> display interpretation for gpon/ngpon2 subscriber location id
[no] sn-bundle-timer	Parameter type: <Gpon::SnBundleTimer> Format: - the system timer for auto bundling sn - unit: hour - range: [1...72]	<i>optional parameter with default value: 24L</i> the system timer for bundling sn with loid/slid when gpon/ngpon2 ont is in auto-bundle mode
[no] sw-ver-mis-block	Parameter type: <Gpon::SwVerMisBlock> Format: (enable disable) Possible values: - enable : block the user traffic when ont version mismatch - disable : do not block the user traffic when ont version mismatch	<i>optional parameter with default value: "enable"</i> the control behavior of user traffic block when for gpon/ngpon2 ont version mismatch
[no] sn-autounlock	Parameter type: <Gpon::OntAuthMode> Format: (disable enable) Possible values:	<i>optional parameter with default value: "disable"</i> unlock ONT automatically after ONT authenticated

Parameter	Type	Description
	- disable : disable unlock ONT automatically after ONT authenticated - enable : enable unlock ONT automatically after ONT authenticated	

77.6 Power Shedding Profile Configuration Command

Command Description

This command allows the operator to configure the Power Shedding Profiles for gpon and ngpon2

User Level

The command can be accessed by operators with equipment privileges, and executed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

```
> configure generic-pon ( no power-shed-prof (profile-idx) ) | ( power-shed-prof (profile-idx) profile-name
<AsamProfileName> [ no restore-time | restore-time <Gpon::RestoreTime> ] [ no data-class-time | data-class-time
<Gpon::DataClassTime> ] [ no voice-class-time | voice-class-time <Gpon::VoiceClassTime> ] [ no
video-class-time | video-class-time <Gpon::VideoClassTime> ] [ no dsl-class-time | dsl-class-time
<Gpon::DslClassTime> ] [ no ces-class-time | ces-class-time <Gpon::CesClassTime> ] )
```

Command Parameters

Table 77.6-1 "Power Shedding Profile Configuration Command" Resource Parameters

Resource Identifier	Type	Description
(profile-idx)	Format: - profile index - range: [1...50]	profile index

Table 77.6-2 "Power Shedding Profile Configuration Command" Command Parameters

Parameter	Type	Description
profile-name	Parameter type: <AsamProfileName> Format: - a profile name - range: [a-zA-Z0-9-_.] - length: 1<=x<=32	<i>mandatory parameter</i> <i>The parameter is not visible during modification.</i> name of the profile
[no] restore-time	Parameter type: <Gpon::RestoreTime> Format: - zero means no-shed, and one means immediate-shed - unit: secs - range: [0...28800]	<i>optional parameter with default value: 0L</i> <i>The parameter is not visible during modification.</i> time delay required before resetting timers to zero after a full power restore
[no] data-class-time	Parameter type: <Gpon::DataClassTime> Format: - zero means no-shed, and one means immediate-shed	<i>optional parameter with default value: 0L</i> <i>The parameter is not visible</i>

Parameter	Type	Description
	- unit: secs - range: [0...28800]	during modification. time delay required before shedding power for data uni classes.
[no] voice-class-time	Parameter type: <Gpon::VoiceClassTime> Format: - zero means no-shed, and one means immediate-shed - unit: secs - range: [0...28800]	optional parameter with default value: 0L The parameter is not visible during modification. the time delay required before shedding power for voice uni classes.
[no] video-class-time	Parameter type: <Gpon::VideoClassTime> Format: - zero means no-shed, and one means immediate-shed - unit: secs - range: [0...28800]	optional parameter with default value: 0L The parameter is not visible during modification. the time delay required before shedding power for the video uni class.
[no] dsl-class-time	Parameter type: <Gpon::DslClassTime> Format: - zero means no-shed, and one means immediate-shed - unit: secs - range: [0...28800]	optional parameter with default value: 0L The parameter is not visible during modification. the time delay required before shedding power for dsl uni classes.
[no] ces-class-time	Parameter type: <Gpon::CesClassTime> Format: - zero means no-shed, and one means immediate-shed - unit: secs - range: [0...28800]	optional parameter with default value: 0L The parameter is not visible during modification. the time delay required before shedding power for ces uni classes.

Command Output

Table 77.6-3 "Power Shedding Profile Configuration Command" Display parameters

Specific Information		
name	Type	Description
scope	Parameter type: <Gpon::Scope> (local network) Possible values: - local : local scope - network : network wide scope	scope of the profile <i>This element is always shown.</i>

77.7 OLT GIS info Configuration Command

Command Description

This command configures the OLT GIS info.

User Level

The command can be accessed by operators with equipment privileges, and executed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

```
> configure generic-pon gis-info [ no longitude | longitude <Gpon::OltLongitude> ] [ no latitude | latitude <Gpon::OltLatitude> ] [ no elevation | elevation <Gpon::OltElevation> ] [ no horizontal-error | horizontal-error <Gpon::OltHrzErr> ] [ no altitude-error | altitude-error <Gpon::OltAltErr> ] [ no area-code | area-code <Gpon::OltAreaCode> ] [ no timestamp | timestamp <Gpon::OltTimestamp> ] [ no gis-digest | gis-digest <Gpon::OltGisDigest> ] [ no gis-check | gis-check <Gpon::OltGisCheck> ]
```

Command Parameters

Table 77.7-2 "OLT GIS info Configuration Command" Command Parameters

Parameter	Type	Description
[no] longitude	Parameter type: <Gpon::OltLongitude> Format: - longitude of the GIS info - unit: degree - range: [-180.00000...180.00000]	<i>optional parameter with default value: "0.00000"</i> longitude of GIS info
[no] latitude	Parameter type: <Gpon::OltLatitude> Format: - latitude of the GIS info - unit: degree - range: [-90.00000...90.00000]	<i>optional parameter with default value: "0.00000"</i> latitude of GIS info
[no] elevation	Parameter type: <Gpon::OltElevation> Format: - latitude of the GIS info - unit: meter - range: [-32768...32767]	<i>optional parameter with default value: "0"</i> elevation of GIS info
[no] horizontal-error	Parameter type: <Gpon::OltHrzErr> Format: - horizontal error of the GIS info - unit: meter - range: [0...65535]	<i>optional parameter with default value: "0"</i> horizontal error of GIS info
[no] altitude-error	Parameter type: <Gpon::OltAltErr> Format: - altitude error of the GIS info - unit: meter	<i>optional parameter with default value: "0"</i> altitude error of GIS info

Parameter	Type	Description
	- range: [0...65535]	
[no] area-code	Parameter type: <Gpon::OltAreaCode> Format: - altitude error of the GIS info - 12 Decimal charaters - length: 12	<i>optional parameter with default value: "000000000000"</i> area code of GIS info
[no] timestamp	Parameter type: <Gpon::OltTimestamp> Format: - the seconds eclapsed since 1970-01-01:00:00:00 - unit: Seconds - range: [0...4294967295]	<i>optional parameter with default value: "0"</i> timestamp of GIS info
[no] gis-digest	Parameter type: <Gpon::OltGisDigest> Format: - digest of the GIS info - 16 hex characters - length: 16	<i>optional parameter with default value: "0000000000000000"</i> GIS digest of GIS info
[no] gis-check	Parameter type: <Gpon::OltGisCheck> Format: - check of the GIS info - 4 hex characters - length: 4	<i>optional parameter with default value: "0000"</i> GIS digest of GIS info

77.8 System PONLOS Alarm Re-define Switch

Command Description

This command configures PONLOS (system-wide) alarm redefine switch for PONs and channel-pairs.

if disable, "PONLOS" means original Loss of Signal; if enable, "PONLOS" will be redefined for trunk fiber broken

User Level

The command can be accessed by operators with equipment privileges, and executed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

> configure generic-pon alarmflag [no ponlos-alarm-ctrl | ponlos-alarm-ctrl <Gpon::Alarmflag>]

Command Parameters

Table 77.8-2 "System PONLOS Alarm Re-define Switch" Command Parameters

Parameter	Type	Description
[no] ponlos-alarm-ctrl	Parameter type: <Gpon::Alarmflag> Format: (enable disable) Possible values: - enable : enable means trunk Fiber cutoff alarm - disable : disable means PONLOS alarm	<i>optional parameter with default value: "disable"</i> if disable, PONLOS means original Loss of Signal; if enable, PONLOS will be redefined for trunk fiber broken

78- CLI Alias Configuration Command

78.1 CLI Alias Configuration Command Tree	78-1882
78.2 CLI Alias Configuration Command	78-1883

78.1 CLI Alias Configuration Command Tree

Description

This chapter gives an overview of nodes that are handled by "CLI Alias Configuration Command".

Command Tree

```
----configure
----[no] alias
  - (name)
  - (value)
```

78.2 CLI Alias Configuration Command

Command Description

This command allows the operator to configure CLI alias commands for the system.

Alias names may not match any of the reserved cli node keywords. Alias names may not contain whitespace or chars '?' or '#'. Alias names may not match an existing alias value.

Alias values may not contain chars '?' or '#'. '\n' or '\r' are disallowed unless they are used within literal string parameters. An alias value may not match an existing alias name.

Cli command parameters entered as part of the alias value will not be validated until the alias is executed.

The order of the displayed alias commands when executing the 'info configure alias' command does not persist after an NT switchover or reset.

User Level

The command can be accessed by operators with equipment privileges, and executed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

> configure alias (name) (value)

Command Parameters

Table 78.2-1 "CLI Alias Configuration Command" Resource Parameters

Resource Identifier	Type	Description
(name)	Format: - alias name for the command - range: [a-z0-9] - length: 2<=x<=8	alias name

Table 78.2-2 "CLI Alias Configuration Command" Command Parameters

Parameter	Type	Description
(value)	Format: - command string for alias - length: 2<=x<=128	<i>mandatory parameter</i> command string for alias

79- Dhcp-Server Configuration Data

79.1 Dhcp-Server Configuration Data Tree	79-1885
79.2 Dhcp-Server Configuration Data	79-1886

79.1 Dhcp-Server Configuration Data Tree

Description

This chapter gives an overview of nodes that are handled by "Dhcp-Server Configuration Data".

Command Tree

```
----configure
  ----dhcp-server
    - start-addr
    - stop-addr
    - [no] lease-time
    - (restart)
```

79.2 Dhcp-Server Configuration Data

Command Description

This command allows the operator to manage the dhcp server information

User Level

The command can be accessed by operators with xdsl privileges, and executed by operators with xdsl privileges.

Command Syntax

The command has the following syntax:

```
> configure dhcp-server [ start-addr <Ip::V4Address> ] [ stop-addr <Ip::V4Address> ] [ no lease-time | lease-time <CWMP::LeaseTime> ] [ (restart) ]
```

Command Parameters

Table 79.2-2 "Dhcp-Server Configuration Data" Command Parameters

Parameter	Type	Description
start-addr	Parameter type: <Ip::V4Address> Format: - IPv4-address	<i>optional parameter</i> the start address of dynamic IP pool
stop-addr	Parameter type: <Ip::V4Address> Format: - IPv4-address	<i>optional parameter</i> the stop address of dynamic IP pool
[no] lease-time	Parameter type: <CWMP::LeaseTime> Format: - the lease time for the client - unit: sec - range: [300...259200] - length: 300<=x<=259200	<i>optional parameter with default value: 43200L</i> the lease time for the client. The range of the value is [300s, 259200s]
(restart)	Format: restart Possible values: - restart : restart the dhcp server	<i>optional parameter</i> to restart the dhcp server, the dhcp-server configuration will be effective after restarting dhcp server

80- Cwmp platform Configuration Commands

80.1 Cwmp platform Configuration Command Tree	80-1888
80.2 Cwmp Platform Configuration Commands	80-1889

80.1 Cwmp platform Configuration Command Tree

Description

This chapter gives an overview of nodes that are handled by "Cwmp platform Configuration Commands".

Command Tree

```
----configure
  ----cwmp
    ----plt
      - [no] adminstate
```

80.2 Cwmp Platform Configuration Commands

Command Description

This command configure cwmp platform for nat function.

Note: Once the remaining-lease timer has expired, esponding user interface.

User Level

The command can be accessed by operators with xdsl privileges, and executed by operators with xdsl privileges.

Command Syntax

The command has the following syntax:

```
> configure cwmp plt [ no adminstate | adminstate <CWMP::AdminStatus> ]
```

Command Parameters

Table 80.2-2 "Cwmp Platform Configuration Commands" Command Parameters

Parameter	Type	Description
[no] adminstate	Parameter type: <CWMP::AdminStatus> Format: (unlocked locked) Possible values: - unlocked : the identified resource is allowed to be used - locked : the identified resource is not allowed to be used	<i>optional parameter with default value: "locked"</i> enable or disable the cwmp platform

81- *NAPT aging-time configuration Command*

81.1 NAPT aging-time configuration Command Tree	81-1891
81.2 NAPT aging-time configuration Command	81-1892

81.1 NAPT aging-time configuration Command Tree

Description

This chapter gives an overview of nodes that are handled by "NAPT aging-time configuration Command".

Command Tree

```
----configure
  ----nat
    - [no] aging-time
```

81.2 NAPT aging-time configuration Command

Command Description

This command is used to provision the aging time for the nat table.

User Level

The command can be accessed by operators with xdsl privileges, and executed by operators with xdsl privileges.

Command Syntax

The command has the following syntax:

```
> configure nat [ no aging-time | aging-time <CWMP::AgingTime> ]
```

Command Parameters

Table 81.2-2 "NAPT aging-time configuration Command" Command Parameters

Parameter	Type	Description
[no] aging-time	Parameter type: <CWMP::AgingTime> Format: - The range of the value is [60s, 240s], the default value is 120 seconds. - range: [60...240]	<i>optional parameter with default value: 120</i> the aging time for the napt record.

82- E1 Configuration Commands

82.1 E1 Configuration Command Tree	82-1894
82.2 E1 Configuration Command	82-1895

82.1 E1 Configuration Command Tree

Description

This chapter gives an overview of nodes that are handled by "E1 Configuration Commands".

Command Tree

```
----configure
  ----e1
    ----line
      - (if-index)
      - [no] active
      - [no] line-coding
      - [no] framing-mode
      - [no] crc
      - [no] multi-framing
      - [no] transmit-clk-src
      - [no] line-impedance
      - [no] admin-up
```


82.2 E1 Configuration Command

Command Description

This command allows the operator to configure the E1 line.

User Level

The command can be accessed by operators with xdsl privileges, and executed by operators with xdsl privileges.

Command Syntax

The command has the following syntax:

```
> configure e1 line (if-index) [ [ no ] active ] [ no line-coding | line-coding <E1::LineCoding> ] [ no framing-mode
| framing-mode <E1::FramingMode> ] [ no crc | crc <E1::Crc> ] [ no multi-framing | multi-framing
<E1::MultiFraming> ] [ no transmit-clk-src | transmit-clk-src <E1::TransmitClkSrc> ] [ no line-impedance |
line-impedance <E1::LineImpedance> ] [ [ no ] admin-up ]
```

Command Parameters

Table 82.2-1 "E1 Configuration Command" Resource Parameters

Resource Identifier	Type	Description
(if-index)	Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number	interface index of the port

Table 82.2-2 "E1 Configuration Command" Command Parameters

Parameter	Type	Description
[no] active	Parameter type: boolean	<i>optional parameter</i> set the span-profile active
[no] line-coding	Parameter type: <E1::LineCoding> Format: (ami hdb3) Possible values: - ami : Specifies Alternate Mark Inversion (AMI) as the linecode type - hdb3 : Specifies High-Density Bipolar 3 (HDB3) as the linecode type	<i>optional parameter with default value: "hdb3"</i> encoding type of the E1 interface
[no] framing-mode	Parameter type: <E1::FramingMode>	<i>optional parameter with default</i>

82 E1 Configuration Commands

Parameter	Type	Description
	Format: (unframed framed) Possible values: - unframed : Unframed E1 type - framed : Framed E1 type	<i>value: "unframed"</i> specifies framing of E1 interface
[no] crc	Parameter type: <E1::Crc> Format: (disable enable) Possible values: - disable : no CRC4 - enable : Enable CRC4	<i>optional parameter with default value: "disable"</i> enable or disable CRC4 for this e1 interface
[no] multi-framing	Parameter type: <E1::MultiFraming> Format: (disable enable) Possible values: - disable : No multi framing - enable : Enable multi framing	<i>optional parameter with default value: "disable"</i> Specifies if multi framing to be used
[no] transmit-clk-src	Parameter type: <E1::TransmitClkSrc> Format: (external internal) Possible values: - external : Specifies that the network clock source is used - internal : Specifies that the internal clock source is used	<i>optional parameter with default value: "external"</i> Specifies clock source to be used for the e1 interface
[no] line-impedance	Parameter type: <E1::LineImpedance> Format: (75ohms 120ohms) Possible values: - 75ohms : indicates the line impedance value unbalanced 75ohms - 120ohms : indicates the line impedance value balanced 120 ohms	<i>optional parameter with default value: "120ohms"</i> Nominal line impedance
[no] admin-up	Parameter type: boolean	<i>optional parameter</i> admin status is up

83- LLDPMed Configuration Commands

83.1 LLDPMed Configuration Command Tree	83-1898
83.2 LLDPMed Configuration Command	83-1899
83.3 LLDP port configuration	83-1900
83.4 LLDP MED Local Media Policy configuration	83-1903

83.1 LLDPMed Configuration Command Tree

Description

This chapter gives an overview of nodes that are handled by "LLDPMed Configuration Commands".

Command Tree

```
----configure
  ----lldp-med
    ----[no] port
      - (port-index)
      - [no] adminstatus
      - [no] tx-msgtxinterval
      - [no] tx-msgtxhold
      - [no] tx-reinitdelay
      - [no] tx-txcreditmax
      - [no] tx-msgfasttx
      - [no] tx-txfastinit
    ----[no] media-policy
      - (port-index)
      - app-type
      - vlan-id
      - priority
      - dscp
      - unknown
      - tagged
```

83.2 LLDPMed Configuration Command

Command Description

This command allows the operator to specify LLDPMed parameters.

LLDP is specified as IEEE 802.1ab, while MED is specified by TIA-1057.

Currently only port config table and local media policy table are supported.

User Level

The command can be accessed by operators with lldpmed privileges, and executed by operators with lldpmed privileges.

Command Syntax

The command has the following syntax:

> configure lldp-med

83.3 LLDP port configuration

Command Description

LLDP port configuration implemented by private MIB definition which is based on:

<http://www.ieee802.org/1/files/public/MIBs/LLDP-V2-MIB-201502160000Z.txt>

User Level

The command can be accessed by operators with `lldpmed` privileges, and executed by operators with `lldpmed` privileges.

Command Syntax

The command has the following syntax:

```
> configure lldp-med ( no port (port-index) ) | ( port (port-index) [ no adminstatus | adminstatus
<LLDP::AdminStatus> ] [ no tx-msgtxinterval | tx-msgtxinterval <LLDP::MsgTxInterval> ] [ no tx-msgtxhold |
tx-msgtxhold <LLDP::MsgTxHold> ] [ no tx-reinitdelay | tx-reinitdelay <LLDP::ReinitDelay> ] [ no
tx-txcreditmax | tx-txcreditmax <LLDP::CreditMax> ] [ no tx-msgfasttx | tx-msgfasttx <LLDP::MsgFastTx> ] [ no
tx-txfastinit | tx-txfastinit <LLDP::MsgTxFastInit> ] )
```

Command Parameters

Table 83.3-1 "LLDP port configuration" Resource Parameters

Resource Identifier	Type	Description
(port-index)	Format: (uni : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> / <Eqpt::OntPortId> uni:ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / <Eqpt::Ng2OntSlotId> / <Eqpt::Ng2OntPortId> uni:ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / vuni) Possible values: - uni : uni - uni:ng2 : ngpon2 UNI style identification Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Eqpt::OntId> - the ONT identifier Field type <Eqpt::ChannelGroupId>	uni port

Resource Identifier	Type	Description
	- the channel group identifier Field type <Eqpt::SubChannelGroupId> - the subchannel group identifier Field type <Eqpt::Ng2OntId> - the NG2 ONT identifier Possible values: - vuni : virtual NGPON2 uni identifier Field type <Eqpt::OntSlotId> - the ONT SLOT identifier Field type <Eqpt::OntPortId> - the ONT PORT identifier Field type <Eqpt::Ng2OntSlotId> - the NGPON2 ONT SLOT identifier Field type <Eqpt::Ng2OntPortId> - the NGPON2 ONT PORT identifier	

Table 83.3-2 "LLDP port configuration" Command Parameters

Parameter	Type	Description
[no] adminstatus	Parameter type: <LLDP::AdminStatus> Format: (tx-only rx-only tx-and-rx disabled) Possible values: - tx-only : txOnly - rx-only : rxOnly - tx-and-rx : txAndRx - disabled : disabled	<i>optional parameter with default value: "tx-and-rx"</i> The administratively desired status of the local LLDP agent.
[no] tx-msgtxinterval	Parameter type: <LLDP::MsgTxInterval> Format: - The interval at which LLDP frames are transmitted on behalf of this LLDP agent. - range: [5...32768]	<i>optional parameter with default value: 30</i> The interval at which LLDP frames are transmitted on behalf of this LLDP agent.
[no] tx-msgtxhold	Parameter type: <LLDP::MsgTxHold> Format: - The time-to-live value expressed as a multiple of the lldpV2MessageTxInterval object. - range: [2...10]	<i>optional parameter with default value: 4</i> msg tx hold multiplier
[no] tx-reinitdelay	Parameter type: <LLDP::ReinitDelay> Format: - the delay (in units of seconds) from when admin status becomes 'disabled' until re-initialization is attempted. - range: [1...10]	<i>optional parameter with default value: 2</i> delay (in units of seconds) from port disabled until re-initiated.
[no] tx-txcreditmax	Parameter type: <LLDP::CreditMax> Format: - The maximum number of consecutive LLDPDUs that can be transmitted at any time. - range: [1...100]	<i>optional parameter with default value: 5</i> The maximum number of consecutive LLDPDUs that can be transmitted at any time.
[no] tx-msgfasttx	Parameter type: <LLDP::MsgFastTx> Format: - The interval at which LLDP frames are transmitted on behalf of this LLDP agent during fast transmission period - range: [1...3600]	<i>optional parameter with default value: 1</i> tx interval during fast transmission period
[no] tx-txfastinit	Parameter type: <LLDP::MsgTxFastInit> Format: - determines the number of transmissions that are made in	<i>optional parameter with default value: 4</i> the number of transmissions that

83 LLDPMed Configuration Commands

Parameter	Type	Description
	fast transmission mode. - range: [1...8]	are made in fast transmission mode.

83.4 LLDP MED Local Media Policy configuration

Command Description

The MIB table *lldpXMedLocMediaPolicyTable* is readonly. To support modification of it, a private copy with read/write access has been introduced.

User Level

The command can be accessed by operators with *lldpmed* privileges, and executed by operators with *lldpmed* privileges.

Command Syntax

The command has the following syntax:

```
> configure lldp-med ( no media-policy (port-index) app-type <LLDP::AppType> ) | ( media-policy (port-index)
app-type <LLDP::AppType> vlan-id <Eqpt::VlanId> priority <Eqpt::Priority> dscp <Qos::DscpCodepoint>
unknown <LLDP::Boolean> tagged <LLDP::Boolean> )
```

Command Parameters

Table 83.4-1 "LLDP MED Local Media Policy configuration" Resource Parameters

Resource Identifier	Type	Description
(port-index)	Format: (uni : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> / <Eqpt::OntPortId> uni:ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / <Eqpt::Ng2OntSlotId> / <Eqpt::Ng2OntPortId> uni:ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / vuni) Possible values: - uni : uni - uni:ng2 : ngpon2 UNI style identification Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Eqpt::OntId> - the ONT identifier Field type <Eqpt::ChannelGroupId> - the channel group identifier Field type <Eqpt::SubChannelGroupId>	uni port

Resource Identifier	Type	Description
	- the subchannel group identifier Field type <Eqpt::Ng2OntId> - the NG2 ONT identifier Possible values: - vuni : virtual NGPON2 uni identifier Field type <Eqpt::OntSlotId> - the ONT SLOT identifier Field type <Eqpt::OntPortId> - the ONT PORT identifier Field type <Eqpt::Ng2OntSlotId> - the NGPON2 ONT SLOT identifier Field type <Eqpt::Ng2OntPortId> - the NGPON2 ONT PORT identifier	
app-type	Parameter type: <LLDP::AppType> Format: (unknown voice voice-signaling guest-voice guest-voice-signaling softphone-voice video-conferencing streaming-video video-signaling) Possible values: - unknown : - voice : - voice-signaling : - guest-voice : - guest-voice-signaling : - softphone-voice : - video-conferencing : - streaming-video : - video-signaling :	app type

Table 83.4-2 "LLDP MED Local Media Policy configuration" Command Parameters

Parameter	Type	Description
vlan-id	Parameter type: <Eqpt::VlanId> Format: - vlan index - range: [0...4095]	<i>mandatory parameter</i> vlan id
priority	Parameter type: <Eqpt::Priority> Format: - priority range 0 to 7 - range: [0...7]	<i>mandatory parameter</i> priority
dscp	Parameter type: <Qos::DscpCodepoint> Format: - the number of the DSCP codepoint - range: [0...63]	<i>mandatory parameter</i> dscp
unknown	Parameter type: <LLDP::Boolean> Format: (true false) Possible values: - true : true - false : false	<i>mandatory parameter</i> unknown
tagged	Parameter type: <LLDP::Boolean>	<i>mandatory parameter</i>

Parameter	Type	Description
	Format: (true false) Possible values: - true : true - false : false	tagged

84- Dual-Parenting Configuration Commands

84.1 Dual-Parenting Configuration Command Tree

84-1907

84.1 Dual-Parenting Configuration Command Tree

Description

This chapter gives an overview of nodes that are handled by "Dual-Parenting Configuration Commands".

Command Tree

----configure
----dual-parenting

85- Dual-Parenting ProtGrp Configuration Commands

85.1 Dual-Parenting ProtGrp Configuration Command Tree	85-1909
85.2 Dual-Parenting ProtGrp Configuration Command	85-1910

85.1 Dual-Parenting ProtGrp Configuration

Command Tree

Description

This chapter gives an overview of nodes that are handled by "Dual-Parenting ProtGrp Configuration Commands".

Command Tree

```
----configure
  ----dual-parenting
    ----[no] protection-group
      - (local-port)
      - prot-type
      - peer-node-name
      - protection-group-id
      - [no] prot-group-status
```

85.2 Dual-Parenting ProtGrp Configuration Command

Command Description

This command allows the operator to configure dual-parenting protection group. The system will decide which port of the two becomes active. In case of failure of one port the other port will take over. A forced switchover can also be triggered manually by the operator.

The port protection group is identified by the first port in the group that is intended to be protected. The following parameters can be configured for the protection group :

- *local-port-index*: the local-port-index that will ensure the protection of the first one.

User Level

The command can be accessed by operators with equipment privileges, and executed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

```
> configure dual-parenting ( no protection-group (local-port) ) | ( protection-group (local-port) prot-type
<Equipm::DualParentProtGrpType> peer-node-name <Equipm::DualParentProtGrpPeerNodeName>
protection-group-id <Equipm::DualParentProtGrpId> [ [ no ] prot-group-status ] )
```

Command Parameters

Table 85.2-1 "Dual-Parenting ProtGrp Configuration Command" Resource Parameters

Resource Identifier	Type	Description
(local-port)	Format: (pon : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> chpair : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::ChannelPairId>) Possible values: - pon : pon-aid - chpair : chpair-aid Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Eqpt::ChannelPairId>	the local port identifier of the dual-parenting in the protection group

Resource Identifier	Type	Description
	- the channel pair identifier	

Table 85.2-2 "Dual-Parenting ProtGrp Configuration Command" Command Parameters

Parameter	Type	Description
prot-type	Parameter type: <Equipm::DualParentProtGrpType> Format: (primary secondary) Possible values: - primary : primary node - secondary : secondary node	<i>mandatory parameter</i> the dual-parenting protection group pro-type
peer-node-name	Parameter type: <Equipm::DualParentProtGrpPeerNodeName> Format: - a printable string - length: 1<=x<=127	<i>mandatory parameter</i> the dual-parenting peer-node-name
protection-group-id	Parameter type: <Equipm::DualParentProtGrpId> Format: - index of dual-parenting protection group - range: [1...127]	<i>mandatory parameter</i> the protection group id in the dual-parenting protection group
[no] prot-group-status	Parameter type: boolean	<i>optional parameter</i>

86- Dual-Parenting local-node Configuration Commands

86.1 Dual-Parenting local-node Configuration Command Tree	86-1913
86.2 Dual-Parenting local-node Configuration Command	86-1914

86.1 Dual-Parenting local-node Configuration

Command Tree

Description

This chapter gives an overview of nodes that are handled by "Dual-Parenting local-node Configuration Commands".

Command Tree

```
----configure
  ----dual-parenting
    ----[no] local-node
      - (node-id)
      - node-name
      - ip_subnet
```

86.2 Dual-Parenting local-node Configuration

Command

Command Description

This command allows the operator to configure a local node . The system will decide which port of the two becomes active. In case of failure of one port the other port will take over. A forced switchover can also be triggered manually by the operator.

The port protection group is identified by the first port in the group that is intended to be protected. The following parameters can be configured for the protection group :

- *local-node-id: the local-node-id that will ensure the protection of the first one.*

User Level

The command can be accessed by operators with equipment privileges, and executed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

```
> configure dual-parenting ( no local-node (node-id) ) | ( local-node (node-id) node-name
<Equipm::DualParentProtGrpLocalNodeName> ip_subnet <Ip::V4Address> )
```

Command Parameters

Table 86.2-1 "Dual-Parenting local-node Configuration Command" Resource Parameters

Resource Identifier	Type	Description
(node-id)	Format: - index of node id - range: [1...15]	the config of dual-parenting local-node id

Table 86.2-2 "Dual-Parenting local-node Configuration Command" Command Parameters

Parameter	Type	Description
node-name	Parameter type: <code><Equipm::DualParentProtGrpLocalNodeName></code> Format: - a printable string - length: 1<=x<=127	<i>mandatory parameter</i> the dual-parenting of local-node-name
ip_subnet	Parameter type: <code><Ip::V4Address></code> Format: - IPv4-address	<i>mandatory parameter</i> the ip_subnet of local-node.must config it like:x.x.0.0

87- Dual-Parenting peer-node Configuration Commands

87.1 Dual-Parenting peer-node Configuration Command Tree	87-1916
87.2 Dual-Parenting peer-node Configuration Command	87-1917

87.1 Dual-Parenting peer-node Configuration

Command Tree

Description

This chapter gives an overview of nodes that are handled by "Dual-Parenting peer-node Configuration Commands".

Command Tree

```
----configure
  ----dual-parenting
    ----[no] peer-node
      - (node-id)
      - node-name
      - sync-vlan
```

87.2 Dual-Parenting peer-node Configuration

Command

Command Description

This command allows the operator to configure peer node. The system will decide which port of the two becomes active. In case of failure of one port the other port will take over. A forced switchover can also be triggered manually by the operator.

The port protection group is identified by the first port in the group that is intended to be protected. The following parameters can be configured for the protection group :

- *peer-node-id: the peer-node-id that will ensure the protection of the first one.*

User Level

The command can be accessed by operators with equipment privileges, and executed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

```
> configure dual-parenting ( no peer-node (node-id) ) | ( peer-node (node-id) node-name
<Equipm::DualParentProtGrpPeerNodeName> sync-vlan <Eqpt::SyncVlanId> )
```

Command Parameters

Table 87.2-1 "Dual-Parenting peer-node Configuration Command" Resource Parameters

Resource Identifier	Type	Description
(node-id)	Format: - index of node id - range: [1...15]	the config of dual-parenting peer-node id

Table 87.2-2 "Dual-Parenting peer-node Configuration Command" Command Parameters

Parameter	Type	Description
node-name	Parameter type: <Equipm::DualParentProtGrpPeerNodeName> Format: - a printable string - length: 1<=x<=127	<i>mandatory parameter</i> the dual-parenting of peer-node name
sync-vlan	Parameter type: <Eqpt::SyncVlanId> Format: - Sync vlan index - range: [2...4093]	<i>mandatory parameter</i> the sync-vlan-id for dual-parenting typeb

88- *Interface Management Configuration*

Commands

88.1 Interface Management Configuration Command Tree	88-1919
88.2 TC-layer Performance Monitoring Command	88-1920

88.1 Interface Management Configuration

Command Tree

Description

This chapter gives an overview of nodes that are handled by "Interface Management Configuration Commands".

Command Tree

```
----configure
  ----tc-layer
    ----ont-side
      - (ont-idx)
      - [no] pm-collect
```

88.2 TC-layer Performance Monitoring Command

Command Description

This command allows the operator to enable or disable the ONT-side Gem Port Performance Monitor collection for the ONT.

User Level

The command can be accessed by operators with equipment privileges, and executed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

```
> configure tc-layer ont-side (ont-idx) [ no pm-collect | pm-collect <Gpon::OntPmCollect> ]
```

Command Parameters

Table 88.2-1 "TC-layer Performance Monitoring Command" Resource Parameters

Resource Identifier	Type	Description
(ont-idx)	Format: (uni:ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / <Eqpt::Ng2OntSlotId> / <Eqpt::Ng2OntPortId> voip:ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> mcast : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> uni : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> / <Eqpt::OntPortId> voip : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> mcast:ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId>) Possible values: - mcast : multicast - mcast:ng2 : ngpon2 multicast style identification - uni : uni - uni:ng2 : ngpon2 UNI style identification - voip : voip - voip:ng2 : voip Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId>	ONT index

Resource Identifier	Type	Description
	- the LT slot number - Field type <Eqpt::PonId> - the PON identifier - Field type <Eqpt::ChannelGroupId> - the channel group identifier - Field type <Eqpt::SubChannelGroupId> - the subchannel group identifier - Field type <Eqpt::OntId> - the ONT identifier - Field type <Eqpt::Ng2OntId> - the NG2 ONT identifier - Possible values: - vuni : virtual NGPON2 uni identifier - Field type <Eqpt::OntSlotId> - the ONT SLOT identifier - Field type <Eqpt::OntPortId> - the ONT PORT identifier - Field type <Eqpt::Ng2OntSlotId> - the NGPON2 ONT SLOT identifier - Field type <Eqpt::Ng2OntPortId> - the NGPON2 ONT PORT identifier	

Table 88.2-2 "TC-layer Performance Monitoring Command" Command Parameters

Parameter	Type	Description
[no] pm-collect	Parameter type: <Gpon::OntPmCollect> Format: (enable disable) Possible values: - enable : enable PM - disable : disable PM	<i>optional parameter with default value: "disable"</i> pm collect enable

89- IPv6 Configuration Commands

89.1 IPv6 Configuration Command Tree	89-1923
89.2 ipv6 anti-spoofing Configuration Command	89-1924

89.1 IPv6 Configuration Command Tree

Description

This chapter gives an overview of nodes that are handled by "IPv6 Configuration Commands".

Command Tree

```
----configure
  ----ipv6-antispoofing
    ----slot
      - (slot)
      - [no] bit-len
```

89.2 ipv6 anti-spoofing Configuration Command

Command Description

This command allows the operator to configure the bit length of the IPv6 address on which IPv6 anti-spoofing based.

User Level

The command can be accessed by operators with ip privileges, and executed by operators with ip privileges.

Command Syntax

The command has the following syntax:

```
> configure ipv6-antispoofing slot (slot) [ no bit-len | bit-len <ipv6::bitLength> ]
```

Command Parameters

Table 89.2-1 "ipv6 anti-spoofing Configuration Command" Resource Parameters

Resource Identifier	Type	Description
(slot)	Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId>) Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number	the physical number of the slot

Table 89.2-2 "ipv6 anti-spoofing Configuration Command" Command Parameters

Parameter	Type	Description
[no] bit-len	Parameter type: <ipv6::bitLength> Format: - number of bits that is checked during IPv6 address anti-spoofing. - range: [64,128]	<i>optional parameter with default value: "64"</i> bit length of the IPv6 address on which IPv6 anti-spoofing based

90- Mcast control Configuration Commands

90.1 Mcast control Configuration Command Tree	90-1926
90.2 mcast Channel Configuration Command	90-1928
90.3 IGMP Channel Permission Package Members Configuration Command	90-1933
90.4 IGMP Channel Preview Package Members Configuration Command	90-1936
90.5 mcast System Configuration Command	90-1939
90.6 IGMP System CDR Type Configuration Command	90-1943
90.7 MLD Vlan System Configuration Command	90-1944
90.8 MLD Vlan System Configuration Command	90-1945
90.9 IGMP Vlan System Configuration Command	90-1946
90.10 IGMP Vlan System Configuration Command	90-1947
90.11 mcast Multicast Vlan Translation Command	90-1948
90.12 Multicast Pon Vlan Translation Command	90-1949
90.13 Multicast Service Context Configuration Command	90-1950
90.14 mcast Package Bitmaps Configuration Command	90-1951

90.1 Mcast control Configuration Command Tree

Description

This chapter gives an overview of nodes that are handled by "Mcast control Configuration Commands".

Command Tree

```
----configure
  ----mcast-control
    ----[no] channel
      - (port)
      - [no] perm-pkg-bitmap
      - [no] max-num-group
      - [no] mode
      X (cac-disable)
      X (ip-anti-spoof-dis)
      - [no] igmp-version
      - [no] mld-version
      - [no] forking
      - [no] lt-ont-signaling
      - [no] mc-pbit-value
      - [no] mcast-vlan-id
      - [no] mc-vlan-xlate
      - [no] mcast-svc-context
      - [no] max-msg-rate
      - [no] ip-version
    ----[no] fullview-packages
      - (package)
    ----[no] preview-packages
      - (package)
  ----system
    - [no] src-ip-address
    - [no] v6-src-ip-address
    - [no] verify-checksum
    - [no] query-interval
    - [no] max-rsp-time
    - [no] robustness
    - [no] mem-query-int
    - [no] last-memb-cnt
    - [no] last-max-rsp-tim
    - [no] host-report-intv
    - [no] start
    - [no] preview-valid
    - [no] cdr-validation
    - [no] cdr-generation
    - [no] except-cdr-rate
    - [no] cdr-export
    - [no] cdr-file-aging
    - [no] cdr-polling
    - [no] user-igmp-version
    - [no] netw-igmp-version
    - [no] user-mld-version
```



```

- [no] netw-mld-version
- [no] v3-max-num-rec
- [no] forking
- [no] lt-ont-signaling
- [no] vlan-selection
- [no] disc-lwr-version
- [no] uncfg-mcast-supp
----cdr-type
- [no] periodic
- [no] period
- [no] attempt-max-pview
- [no] attempt-blackout
- [no] attempt-no-perm
----ipv6
----[no] vlan
- (vlan-id)
- netw-mld-version
- [no] mldv2-max-num-rec
----ipv4
----[no] vlan
- (vlan-id)
- netw-igmp-version
- [no] v3-max-num-rec
----[no] mc-vlan-xlate
- (nwvlan)
- ponvlan
----[no] mc-pon-vlan-xlate
- (pon)
- nwvlan
- ponvlan
----[no] mcast-svc-context
- (name)
----package
- (index)
- [no] name
- [no] template-name
- [no] template-version

```

90.2 mcast Channel Configuration Command

Command Description

This command allows the operator to create and configure the mcast channel parameters.

User Level

The command can be accessed by operators with igmp privileges, and executed by operators with igmp privileges.

Command Syntax

The command has the following syntax:

```
> configure mcast-control ( no channel (port) ) | ( channel (port) [ no perm-pkg-bitmap | perm-pkg-bitmap
<Igmp::PermPkgBitMap> ] [ no max-num-group | max-num-group <Igmp::ChannelMaxNumGroup> ] [ no mode |
mode <Igmp::ChannelProtocolMode> ] [ (cac-disable) ] [ (ip-anti-spoof-dis) ] [ no igmp-version | igmp-version
<Igmp::UserItfVersion> ] [ no mld-version | mld-version <Igmp::MldUserItfVersion> ] [ no forking | forking
<Igmp::ForkingStatus> ] [ no lt-ont-signaling | lt-ont-signaling <Igmp::ChannelLtOntSignaling> ] [ no
mc-pbit-value | mc-pbit-value <Igmp::McPbitValue> ] [ no mcast-vlan-id | mcast-vlan-id
<Igmp::ProtocolMcastVlan> ] [ no mc-vlan-xlate | mc-vlan-xlate <Igmp::mcVlanXlateAdmin> ] [ no
mcast-svc-context | mcast-svc-context <Igmp::McastSvcCtxtName> ] [ no max-msg-rate | max-msg-rate
<Igmp::ChannelMaxMsgRate> ] [ no ip-version | ip-version <Igmp::ip-version> ] )
```

Command Parameters

Table 90.2-1 "mcast Channel Configuration Command" Resource Parameters

Resource Identifier	Type	Description
(port)	Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::VpiId> : <Eqpt::VciId> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::VpiId> : <Eqpt::VciId> : <Eqpt::UnstackedVlan> vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::UnstackedVlan> vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::VpiId> : <Eqpt::VciId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> / <Eqpt::OntPortId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> /	identification of the port, vlanport or virtual channel

Resource Identifier	Type	Description
	<code><Eqpt::OntPortId> : <Eqpt::UnstackedVlan></code> <code> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> /</code> <code><Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> /</code> <code><Eqpt::OntPortId></code> <code> vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> /</code> <code><Eqpt::PonId> / <Eqpt::OntId> / voip : stacked :</code> <code><Eqpt::SVlan> : <Eqpt::CVlan></code> <code> vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> /</code> <code><Eqpt::PonId> / <Eqpt::OntId> / vuni : stacked :</code> <code><Eqpt::SVlan> : <Eqpt::CVlan></code> <code> vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> /</code> <code><Eqpt::PonId> / <Eqpt::OntId> / voip :</code> <code><Eqpt::UnstackedVlan></code> <code> vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> /</code> <code><Eqpt::PonId> / <Eqpt::OntId> / vuni :</code> <code><Eqpt::UnstackedVlan></code> <code> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> /</code> <code><Eqpt::PonId> / <Eqpt::OntId> / voip</code> <code> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> /</code> <code><Eqpt::PonId> / <Eqpt::OntId> / vuni</code> <code> vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> /</code> <code><Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::LLId> : stacked :</code> <code><Eqpt::SVlan> : <Eqpt::CVlan></code> <code> vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> /</code> <code><Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::LLId> :</code> <code><Eqpt::UnstackedVlan></code> <code> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> /</code> <code><Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::LLId></code> <code> vlan:ng2 : <Eqpt::ChannelGroupId> /</code> <code><Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> /</code> <code><Eqpt::Ng2OntSlotId> / <Eqpt::Ng2OntPortId> : stacked :</code> <code><Eqpt::SVlan> : <Eqpt::CVlan></code> <code> vlan:ng2 : <Eqpt::ChannelGroupId> /</code> <code><Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> /</code> <code><Eqpt::Ng2OntSlotId> / <Eqpt::Ng2OntPortId> :</code> <code><Eqpt::UnstackedVlan>)</code> Possible values: - vlan : vlan port - vlan:ng2 : ngpon2 vlan port Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number Field type <Eqpt::VpiId> - atm VPI Field type <Eqpt::VciId> - atm VCI Field type <Eqpt::PonId> - the PON identifier Field type <Eqpt::ChannelGroupId> - the channel group identifier Field type <Eqpt::SubChannelGroupId> - the subchannel group identifier	

90 Mcast control Configuration Commands

Resource Identifier	Type	Description
	Field type <Eqpt::Ng2OntId> - the NG2 ONT identifier Field type <Eqpt::OntId> - the ONT identifier Possible values: - voip : virtual uni identifier obsolete alternative replaced by vuni - vuni : virtual uni identifier Possible values: - vuni : virtual NGPON2 uni identifier Field type <Eqpt::OntSlotId> - the ONT SLOT identifier Field type <Eqpt::OntPortId> - the ONT PORT identifier Field type <Eqpt::Ng2OntSlotId> - the NGPON2 ONT SLOT identifier Field type <Eqpt::Ng2OntPortId> - the NGPON2 ONT PORT identifier Field type <Eqpt::LLId> - the LLID identifier,range 1 for EPON,range 1-8 for DPOE Possible values: - stacked : stacked vlan identity Field type <Eqpt::UnstackedVlan> - unstacked vlan id Field type <Eqpt::SVlan> - service vlan id Field type <Eqpt::CVlan> - customer vlan id	

Table 90.2-2 "mcast Channel Configuration Command" Command Parameters

Parameter	Type	Description
[no] perm-pkg-bitmap	Parameter type: <IgmP::PermPkgBitMap> Format: - a binary string - length: 128	<i>optional parameter with default value:</i> "01 : 00 : 00 : 00 : 00 : 00 : : 00 :" packages, the user is allowed to join
[no] max-num-group	Parameter type: <IgmP::ChannelMaxNumGroup> Format: - Max group number this port can support.The value depends on the board type and port type,please refer to the	<i>optional parameter with default value:</i> 0 Max group number this port can support.The value depends on the

Parameter	Type	Description
	product information document for detail. - range: [0...2048]	board type and port type, please refer to the product information document for detail.
[no] mode	Parameter type: <Igmp::ChannelProtocolMode> Format: (ipoe pppoe) Possible values: - ipoe : IPoE mode - pppoe : PPPoE mode	<i>optional parameter with default value: "ipoe"</i> protocol mode (ipoe or pppoe)
(cac-disable)	Format: (cac-disable cac) Possible values: - cac-disable : disables bandwidth CAC for conf. streams, default=enable - cac : enables bandwidth CAC for conf. streams, default=enable	<i>obsolete parameter that will be ignored</i> bandwidth CAC for pre-configured multicast streams
(ip-anti-spoof-dis)	Format: (ip-anti-spoof-dis ip-anti-spoof) Possible values: - ip-anti-spoof-dis : disables IP@ anti-spoofing, default=enable - ip-anti-spoof : enables IP@ anti-spoofing, default=enable	<i>obsolete parameter that will be ignored</i> enables IP@ anti-spoofing on this user-interface
[no] igmp-version	Parameter type: <Igmp::UserItfVersion> Format: (system-inherited 2 3) Possible values: - system-inherited : inherits GMQs to user version from the system level - 2 : IGMPV2 GMQs - 3 : IGMPV3 GMQs	<i>optional parameter with default value: "system-inherited"</i> version of the IGMP protocol
[no] mld-version	Parameter type: <Igmp::MldUserItfVersion> Format: (system-inherited 1 2) Possible values: - system-inherited : inherits GMQs to user version from the system level - 1 : MLDV1 GMQs - 2 : MLDV2 GMQs	<i>optional parameter with default value: "system-inherited"</i> version of the MLD protocol
[no] forking	Parameter type: <Igmp::ForkingStatus> Format: (system-inherited enable disable) Possible values: - system-inherited : inherits forking status from the system level - enable : enable IGMP forking - disable : disable IGMP forking	<i>optional parameter with default value: "system-inherited"</i> forking status of the IGMP protocol
[no] lt-ont-signaling	Parameter type: <Igmp::ChannelLtOntSignaling> Format:	<i>optional parameter with default value: "inherited"</i>

90 Mcast control Configuration Commands

Parameter	Type	Description
	(enabled disabled inherited) Possible values: - enabled : lt to ont signaling is enabled - disabled : lt to ont signaling is disabled - inherited : inherits lt to ont signaling from the system level	<i>The parameter is not visible during modification.</i> lt to ont signaling parameter
[no] mc-pbit-value	Parameter type: <Igmp::McPbitValue> Format: - default P-bit value to be used by the ONT on the UNI-side for downstream multicast traffic towards subscribers - range: [0...8]	<i>optional parameter with default value: 8</i> default P-bit value to be used by the ONT on the UNI-side for downstream multicast traffic towards subscribers
[no] mcast-vlan-id	Parameter type: <Igmp::ProtocolMcastVlan> Format: - vlan selection value - range: [0...4093]	<i>optional parameter with default value: 0</i> vlan selection for multicast channel
[no] mc-vlan-xlate	Parameter type: <Igmp::mcVlanXlateAdmin> Format: (enabled disabled) Possible values: - enabled : allow mcast vlan translation - disabled : disallow mcast vlan translation	<i>optional parameter with default value: "disabled"</i> to enable or disable mcast vlan translation
[no] mcast-svc-context	Parameter type: <Igmp::McastSvcCtxtName> Format: (name : <Qos::IgnoredQosProfileName> default) Possible values: - default : Default profile is associated - name : Name of the multicast service context profile Data driven field type Possible values are depending on the actual configuration and software. The currently allowed values can be shown with online-help.	<i>optional parameter with default value: "default"</i> Multicast Service Context Name
[no] max-msg-rate	Parameter type: <Igmp::ChannelMaxMsgRate> Format: - Maximum number of Upstream IGMP messages that can be received on this IGMP channel - unit: messages/second - range: [0...256]	<i>optional parameter with default value: 0</i> Default value 0 indicates that the value is inherited from what is set in the system wide setting using command - configure qos dsl-ctrl-pkt-policer sustained-rate [1...64] burst-size [1...128]
[no] ip-version	Parameter type: <Igmp::ip-version> Format: (ipv4 ipv6) Possible values: - ipv4 : support IGMP - ipv6 : support MLD	<i>optional parameter with default value: "ipv4"</i> the protocol the user want to use, IGMP(ipv4) or MLD(ipv6).

90.3 IGMP Channel Permission Package Members Configuration Command

Command Description

This command allows the operator to configure the IGMP channel permission package members.

User Level

The command can be accessed by operators with igmp privileges, and executed by operators with igmp privileges.

Command Syntax

The command has the following syntax:

```
> configure mcast-control channel (port) ( no fullview-packages (package) ) | ( fullview-packages (package) )
```

Command Parameters

Table 90.3-1 "IGMP Channel Permission Package Members Configuration Command" Resource Parameters

Resource Identifier	Type	Description
(port)	Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::VpiId> : <Eqpt::VciId> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::VpiId> : <Eqpt::VciId> : <Eqpt::UnstackedVlan> vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::UnstackedVlan> vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::VpiId> : <Eqpt::VciId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> / <Eqpt::OntPortId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> / <Eqpt::OntPortId> : <Eqpt::UnstackedVlan> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> / <Eqpt::OntPortId>	identification of the port, vlanport or virtual channel

Resource Identifier	Type	Description
	vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / voip : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / vuni : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / voip : <Eqpt::UnstackedVlan> vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / vuni : <Eqpt::UnstackedVlan> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / voip <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / vuni vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::LLId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::LLId> : <Eqpt::UnstackedVlan> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::LLId> vlan:ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / <Eqpt::Ng2OntSlotId> / <Eqpt::Ng2OntPortId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan:ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / <Eqpt::Ng2OntSlotId> / <Eqpt::Ng2OntPortId> : <Eqpt::UnstackedVlan>) Possible values: - vlan : vlan port - vlan:ng2 : ngpon2 vlan port Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number Field type <Eqpt::VpiId> - atm VPI Field type <Eqpt::VciId> - atm VCI Field type <Eqpt::PonId> - the PON identifier Field type <Eqpt::ChannelGroupId> - the channel group identifier Field type <Eqpt::SubChannelGroupId> - the subchannel group identifier Field type <Eqpt::Ng2OntId> - the NG2 ONT identifier Field type <Eqpt::OntId> - the ONT identifier	

Resource Identifier	Type	Description
	Possible values: - voip : virtual uni identifier obsolete alternative replaced by vuni - vuni : virtual uni identifier Possible values: - vuni : virtual NGPON2 uni identifier Field type <Eqpt::OntSlotId> - the ONT SLOT identifier Field type <Eqpt::OntPortId> - the ONT PORT identifier Field type <Eqpt::Ng2OntSlotId> - the NGPON2 ONT SLOT identifier Field type <Eqpt::Ng2OntPortId> - the NGPON2 ONT PORT identifier Field type <Eqpt::LLId> - the LLID identifier, range 1 for EPON, range 1-8 for DPOE Possible values: - stacked : stacked vlan identity Field type <Eqpt::UnstackedVlan> - unstacked vlan id Field type <Eqpt::SVlan> - service vlan id Field type <Eqpt::CVlan> - customer vlan id	
(package)	Format: - the package number - range: [1...1024]	package member

90.4 IGMP Channel Preview Package Members Configuration Command

Command Description

This command allows the operator to configure the IGMP channel preview package members.

User Level

The command can be accessed by operators with igmp privileges, and executed by operators with igmp privileges.

Command Syntax

The command has the following syntax:

```
> configure mcast-control channel (port) ( no preview-packages (package) ) | ( preview-packages (package) )
```

Command Parameters

Table 90.4-1 "IGMP Channel Preview Package Members Configuration Command" Resource Parameters

Resource Identifier	Type	Description
(port)	Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::VpId> : <Eqpt::VciId> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::VpId> : <Eqpt::VciId> : <Eqpt::UnstackedVlan> vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::UnstackedVlan> vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::VpId> : <Eqpt::VciId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> / <Eqpt::OntPortId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> / <Eqpt::OntPortId> : <Eqpt::UnstackedVlan> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> / <Eqpt::OntPortId>	identification of the port, vlanport or virtual channel

Resource Identifier	Type	Description
	vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / voip : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / vuni : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / voip : <Eqpt::UnstackedVlan> vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / vuni : <Eqpt::UnstackedVlan> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / voip <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / vuni vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::LLId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::LLId> : <Eqpt::UnstackedVlan> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::LLId> vlan:ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / <Eqpt::Ng2OntSlotId> / <Eqpt::Ng2OntPortId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan:ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / <Eqpt::Ng2OntSlotId> / <Eqpt::Ng2OntPortId> : <Eqpt::UnstackedVlan>) Possible values: - vlan : vlan port - vlan:ng2 : ngpon2 vlan port Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number Field type <Eqpt::VpiId> - atm VPI Field type <Eqpt::VciId> - atm VCI Field type <Eqpt::PonId> - the PON identifier Field type <Eqpt::ChannelGroupId> - the channel group identifier Field type <Eqpt::SubChannelGroupId> - the subchannel group identifier Field type <Eqpt::Ng2OntId> - the NG2 ONT identifier Field type <Eqpt::OntId> - the ONT identifier	

90 Mcast control Configuration Commands

Resource Identifier	Type	Description
	Possible values: - voip : virtual uni identifier obsolete alternative replaced by vuni - vuni : virtual uni identifier Possible values: - vuni : virtual NGPON2 uni identifier Field type <Eqpt::OntSlotId> - the ONT SLOT identifier Field type <Eqpt::OntPortId> - the ONT PORT identifier Field type <Eqpt::Ng2OntSlotId> - the NGPON2 ONT SLOT identifier Field type <Eqpt::Ng2OntPortId> - the NGPON2 ONT PORT identifier Field type <Eqpt::LLId> - the LLID identifier, range 1 for EPON, range 1-8 for DPOE Possible values: - stacked : stacked vlan identity Field type <Eqpt::UnstackedVlan> - unstacked vlan id Field type <Eqpt::SVlan> - service vlan id Field type <Eqpt::CVlan> - customer vlan id	
(package)	Format: - the package number - range: [1...1024]	package member

90.5 mcast System Configuration Command

Command Description

This command allows the operator to configure the mcast parameters that are globally applicable to the Node.

User Level

The command can be accessed by operators with igmp privileges, and executed by operators with igmp privileges.

Command Syntax

The command has the following syntax:

```
> configure mcast-control system [ no src-ip-address | src-ip-address <Ip::V4Address> ] [ no v6-src-ip-address |
v6-src-ip-address <Igmp::Ipv6LinkLocalAddress> ] [ [ no ] verify-checksum ] [ no query-interval | query-interval
<Igmp::SystemQueryInterval> ] [ no max-rsp-time | max-rsp-time <Igmp::SystemQueryMaxResponseTime> ] [ no
robustness | robustness <Igmp::SystemRobustness> ] [ no mem-query-int | mem-query-int
<Igmp::MembQueryIntvl> ] [ no last-memb-cnt | last-memb-cnt <Igmp::MembQueryCount> ] [ no
last-max-rsp-tim | last-max-rsp-tim <Igmp::SystemLastMembMaxRespTime> ] [ no host-report-intv |
host-report-intv <Igmp::SystemUnsolicitedReportIntvl> ] [ [ no ] start ] [ no preview-valid | preview-valid
<Igmp::SystemPrevalidIntvl> ] [ no cdr-validation | cdr-validation <Igmp::SystemPrecdrvalidIntvl> ] [ [ no ]
cdr-generation ] [ no except-cdr-rate | except-cdr-rate <Igmp::CDRGenerationForSingles> ] [ no cdr-export |
cdr-export <Igmp::CDRGenerationMethod> ] [ no cdr-file-aging | cdr-file-aging <Igmp::CDRFileAgingTime> ] [
no cdr-polling | cdr-polling <Igmp::CDRSystemPollingCycle> ] [ no user-igmp-version | user-igmp-version
<Igmp::igmpSystemGMQToUserSideVersion> ] [ no netw-igmp-version | netw-igmp-version
<Igmp::V3ProcessingAdminStatus> ] [ no user-mld-version | user-mld-version
<Igmp::igmpSystemMLDGMQToUserSideVersion> ] [ no netw-mld-version | netw-mld-version
<Igmp::MldProcessingAdminStatus> ] [ no v3-max-num-rec | v3-max-num-rec
<Igmp::V3MaxNumRecordsReport> ] [ [ no ] forking ] [ [ no ] lt-ont-signaling ] [ [ no ] vlan-selection ] [ [ no ]
disc-lwr-version ] [ no uncfg-mcast-supp | uncfg-mcast-supp <Igmp::igmpSystemUncfgMcastSupport> ]
```

Command Parameters

Table 90.5-2 "mcast System Configuration Command" Command Parameters

Parameter	Type	Description
[no] src-ip-address	Parameter type: <Ip::V4Address> Format: - IPv4-address	optional parameter with default value: "0.0.0.0" source ip addr which is tx in every mcast IP datagram
[no] v6-src-ip-address	Parameter type: <Igmp::Ipv6LinkLocalAddress> Format: - ipv6 link local address	optional parameter with default value: "::: source ipv6 address(link local address) which is tx in every mcast IP datagram
[no] verify-checksum	Parameter type: boolean	optional parameter verification performed on Rx mcast frame
[no] query-interval	Parameter type: <Igmp::SystemQueryInterval>	optional parameter with default

90 Mcast control Configuration Commands

Parameter	Type	Description
	Format: - interval at which general membership queries transmitted - unit: sec - range: [2...3175]	<i>value: 125</i> interval at which general membership queries transmitted
[no] max-rsp-time	Parameter type: <Igmp::SystemQueryMaxResponseTime> Format: - max query response time advertised in queries - unit: 1/10 sec - range: [1...31744]	<i>optional parameter with default value: 100</i> max query response time advertised in queries 1/10 sec
[no] robustness	Parameter type: <Igmp::SystemRobustness> Format: - tuning for the expected packet loss on a subnet - range: [1...10]	<i>optional parameter with default value: 2</i> expected pkt loss on subnet
[no] mem-query-int	Parameter type: <Igmp::MembQueryIntvl> Format: - spacing between GSQs (group-specific queries) - unit: 1/10 sec - range: [2...31744]	<i>optional parameter with default value: 10</i> minimum interval between group-specific queries
[no] last-memb-cnt	Parameter type: <Igmp::MembQueryCount> Format: - number of GSQs (group-specific queries) to be sent - range: [1...10]	<i>optional parameter with default value: 2</i> number of GSQs (group-specific queries) to be sent
[no] last-max-rsp-tim	Parameter type: <Igmp::SystemLastMembMaxRespTime> Format: - allows shorter max response time - unit: 1/10 sec - range: [1...31744]	<i>optional parameter with default value: 2</i> allows shorter max response time
[no] host-report-intv	Parameter type: <Igmp::SystemUnsolicitedReportIntvl> Format: - interval of repetitions of host's report of grp membership - unit: 1/10 sec - range: [1...255]	<i>optional parameter with default value: 10</i> interval of repetitions of host's report of grp membership
[no] start	Parameter type: boolean	<i>optional parameter</i> start Mcast app module
[no] preview-valid	Parameter type: <Igmp::SystemPrevalidIntvl> Format: - time interval that confirm the preview session is valid - unit: sec - range: [1...120]	<i>optional parameter with default value: 8</i> time interval that confirm the preview session is valid
[no] cdr-validation	Parameter type: <Igmp::SystemPrecdrvalidIntvl> Format: (none <Igmp::SystemPrecdrvalidIntvl>) Possible values: - none : CDR generation valid immediately Field type <Igmp::SystemPrecdrvalidIntvl> - minimum session time for generating a CDR - unit: sec - range: [0...120]	<i>optional parameter with default value: 2</i> minimum session time for generating a CDR
[no] cdr-generation	Parameter type: boolean	<i>optional parameter</i> start CDR generation in the system
[no] except-cdr-rate	Parameter type: <Igmp::CDRGenerationForSingles> Format: - limit the generation of CDR records - unit: min - range: [1...30]	<i>optional parameter with default value: 3</i> limit the generation of the CDR records

Parameter	Type	Description
[no] cdr-export	Parameter type: <Igmpp::CDRGenerationMethod> Format: (local-file-storage remote-logging) Possible values: - local-file-storage : method the cdr generated and forwarded - remote-logging : remote logging method	<i>optional parameter with default value: "local-file-storage"</i> the method the cdr is to be generated and forwarded
[no] cdr-file-aging	Parameter type: <Igmpp::CDRFileAgingTime> Format: - configure the CDR file aging time - unit: hour - range: [4...24]	<i>optional parameter with default value: 8</i> configure the CDR file aging time
[no] cdr-polling	Parameter type: <Igmpp::CDRSystemPollingCycle> Format: - configure the polling period for the CDR records, in multiples of 60 - unit: sec - range: [60...900]	<i>optional parameter with default value: 180</i> configure the polling period for the CDR records
[no] user-igmp-version	Parameter type: <Igmpp::igmpSystemGMQToUserSideVersion> Format: (2 3) Possible values: - 2 : IGMPv2 GMQs - 3 : IGMPv3 GMQs	<i>optional parameter with default value: "3"</i> version of the IGMP protocol
[no] netw-igmp-version	Parameter type: <Igmpp::V3ProcessingAdminStatus> Format: (2 3) Possible values: - 2 : IGMP version2 - 3 : IGMP version3	<i>optional parameter with default value: "3"</i> version for IGMP packet to receive/forward to n/w side
[no] user-mld-version	Parameter type: <Igmpp::igmpSystemMLDGMQToUserSideVersion> Format: (1 2) Possible values: - 1 : MLDv1 GMQs - 2 : MLDv2 GMQs	<i>optional parameter with default value: "2"</i> version of the MLD protocol
[no] netw-mld-version	Parameter type: <Igmpp::MldProcessingAdminStatus> Format: (1 2) Possible values: - 1 : MLDV1 version1 - 2 : MLDV2 version2	<i>optional parameter with default value: "2"</i> version for MLD packet to receive/forward to n/w side
[no] v3-max-num-rec	Parameter type: <Igmpp::V3MaxNumRecordsReport> Format: - max number of records in an IGMPv3 membership report - range: [0...10]	<i>optional parameter with default value: 3</i> max num of group records in one IGMPv3 or MLDv2 report (2 exp N)
[no] forking	Parameter type: boolean	<i>optional parameter</i> enable IGMP forking in the system level
[no] lt-ont-signaling	Parameter type: boolean	<i>optional parameter</i>

90 Mcast control Configuration Commands

Parameter	Type	Description
		enables It to ont signaling at system level
[no] vlan-selection	Parameter type: boolean	<i>optional parameter</i> enable vlan selection
[no] disc-lwr-version	Parameter type: boolean	<i>optional parameter</i> discard lower version packets
[no] uncfg-mcast-supp	Parameter type: <Igmpr::igmpSystemUncfgMcastSupport> Format: (legacy asmandssm) Possible values: - legacy : enable un-configured SSM and ASM support for GPON LTs and un-configured ASM support alone for DSL LTs - asmandssm : enable unconfigured SSM and ASM support for GPON and DSL LT cards	<i>optional parameter with default value: "legacy"</i> enable un-configured SSM/ASM support for GPON/DSL LT cards

90.6 IGMP System CDR Type Configuration Command

Command Description

This command allows the operator to configure the IGMP system Call Detail Record

User Level

The command can be accessed by operators with igmp privileges, and executed by operators with igmp privileges.

Command Syntax

The command has the following syntax:

```
> configure mcast-control system cdr-type [ [ no ] periodic ] [ no period | period <Igmp::IntermGenCDRPeriod> ] [
[ no ] attempt-max-pview ] [ [ no ] attempt-blackout ] [ [ no ] attempt-no-perm ]
```

Command Parameters

Table 90.6-2 "IGMP System CDR Type Configuration Command" Command Parameters

Parameter	Type	Description
[no] periodic	Parameter type: boolean	<i>optional parameter</i> interim CDR records generated for fullview/preview
[no] period	Parameter type: <Igmp::IntermGenCDRPeriod> Format: - intermediate CDR generation period, in multiples of 5 - unit: min - range: [15...60]	<i>optional parameter with default value: 15</i> intermediate CDR generation period
[no] attempt-max-pview	Parameter type: boolean	<i>optional parameter</i> CDR generated when max nbr preview exceeded is true
[no] attempt-blackout	Parameter type: boolean	<i>optional parameter</i> CDR generated allowed when blackout period is active
[no] attempt-no-perm	Parameter type: boolean	<i>optional parameter</i> CDR generated to join a mcast with no access rights

90.7 MLD Vlan System Configuration Command

Command Description

This command allows the operator to configure the MLD parameters on a per Vlan basis.

User Level

The command can be accessed by operators with igmp privileges, and executed by operators with igmp privileges.

Command Syntax

The command has the following syntax:

```
> configure mcast-control ipv6
```

90.8 MLD Vlan System Configuration Command

Command Description

This command allows the operator to configure the MLD parameters on a per Vlan basis.

User Level

The command can be accessed by operators with igmp privileges, and executed by operators with igmp privileges.

Command Syntax

The command has the following syntax:

```
> configure mcast-control ipv6 ( no vlan (vlan-id) ) | ( vlan (vlan-id) netw-mld-version
<Igmp::VlanMldV2ProcessStatus> [ no mldv2-max-num-rec | mldv2-max-num-rec
<Igmp::MldV2MaxNumRecordReport> ] )
```

Command Parameters

Table 90.8-1 "MLD Vlan System Configuration Command" Resource Parameters

Resource Identifier	Type	Description
(vlan-id)	Format: - vlan index - range: [1...4093]	index of the system vlan

Table 90.8-2 "MLD Vlan System Configuration Command" Command Parameters

Parameter	Type	Description
netw-mld-version	Parameter type: <Igmp::VlanMldV2ProcessStatus> Format: (1 2) Possible values: - 1 : MLD version1 - 2 : MLD version2	<i>mandatory parameter</i> MLD version of the protocol
[no] mldv2-max-num-rec	Parameter type: <Igmp::MldV2MaxNumRecordReport> Format: - max num of group records in one MLDv2 report (2 exp N) - range: [0...10]	<i>optional parameter with default value: 3</i> max num of group records in one MLDv2 report (2 exp N)

90.9 IGMP Vlan System Configuration Command

Command Description

This command allows the operator to configure the IGMP parameters on a per Vlan basis.

User Level

The command can be accessed by operators with igmp privileges, and executed by operators with igmp privileges.

Command Syntax

The command has the following syntax:

```
> configure mcast-control ipv4
```

90.10 IGMP Vlan System Configuration Command

Command Description

This command allows the operator to configure the IGMP parameters on a per Vlan basis.

User Level

The command can be accessed by operators with igmp privileges, and executed by operators with igmp privileges.

Command Syntax

The command has the following syntax:

```
> configure mcast-control ipv4 ( no vlan (vlan-id) ) | ( vlan (vlan-id) netw-igmp-version
<Igmp::VlanV3ProcessStatus> [ no v3-max-num-rec | v3-max-num-rec <Igmp::V3MaxNumRecordReport> ] )
```

Command Parameters

Table 90.10-1 "IGMP Vlan System Configuration Command" Resource Parameters

Resource Identifier	Type	Description
(vlan-id)	Format: - vlan index - range: [1...4093]	index of the system vlan

Table 90.10-2 "IGMP Vlan System Configuration Command" Command Parameters

Parameter	Type	Description
netw-igmp-version	Parameter type: <Igmp::VlanV3ProcessStatus> Format: (2 3) Possible values: - 2 : IGMP version2 - 3 : IGMP version3	<i>mandatory parameter</i> IGMP version of the protocol
[no] v3-max-num-rec	Parameter type: <Igmp::V3MaxNumRecordReport> Format: - max num of group records in one IGMPv3 or MLDv2 report (2 exp N) - range: [0...10]	<i>optional parameter with default value: 3</i> max num of group records in one IGMPv3 report (2 exp N)

90.11 mcast Multicast Vlan Translation Command

Command Description

This command allows the operator configure source-pon vlan translation.

User Level

The command can be accessed by operators with igmp privileges, and executed by operators with igmp privileges.

Command Syntax

The command has the following syntax:

```
> configure mcast-control ( no mc-vlan-xlate (nwvlan) ) | ( mc-vlan-xlate (nwvlan) ponvlan <Igmp::mcPonVlanId> )
```

Command Parameters

Table 90.11-1 "mcast Multicast Vlan Translation Command" Resource Parameters

Resource Identifier	Type	Description
(nwvlan)	Format: - the multicast vlan id - range: [2...4093]	identification of the network-side virtual lan

Table 90.11-2 "mcast Multicast Vlan Translation Command" Command Parameters

Parameter	Type	Description
ponvlan	Parameter type: <Igmp::mcPonVlanId> Format: - vlan index - range: [1...4093]	<i>mandatory parameter</i> identification of the pon-side virtual lan

90.12 Multicast Pon Vlan Translation Command

Command Description

This command allows the operator configure source-pon vlan translation on pon port.

User Level

The command can be accessed by operators with igmp privileges, and executed by operators with igmp privileges.

Command Syntax

The command has the following syntax:

```
> configure mcast-control ( no mc-pon-vlan-xlate (pon) nwvlan <Igmp::mcSrcVlanId> ) | ( mc-pon-vlan-xlate (pon) nwvlan <Igmp::mcSrcVlanId> ponvlan <Igmp::mcPonVlanId> )
```

Command Parameters

Table 90.12-1 "Multicast Pon Vlan Translation Command" Resource Parameters

Resource Identifier	Type	Description
(pon)	Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier	identification of the pon interface
nwvlan	Parameter type: <Igmp::mcSrcVlanId> Format: - the multicast vlan id - range: [2...4093]	identification of the network-side virtual lan

Table 90.12-2 "Multicast Pon Vlan Translation Command" Command Parameters

Parameter	Type	Description
ponvlan	Parameter type: <Igmp::mcPonVlanId> Format: - vlan index - range: [1...4093]	<i>mandatory parameter</i> identification of the pon-side virtual lan

90.13 Multicast Service Context Configuration

Command

Command Description

This command allows the operator to configure multicast service context

User Level

The command can be accessed by operators with igmp privileges, and executed by operators with igmp privileges.

Command Syntax

The command has the following syntax:

> configure mcast-control (no mcast-svc-context (name)) | (mcast-svc-context (name))

Command Parameters

Table 90.13-1 "Multicast Service Context Configuration Command" Resource Parameters

Resource Identifier	Type	Description
(name)	Format: - a profile name - range: [a-zA-Z0-9-_.] - length: 1<=x<=32	A unique profile name for the service context

90.14 mcast Package Bitmaps Configuration Command

Command Description

This command allows the operator to configure mcast package bitmaps. The package is intended primarily for use by a network/element manager, such as an AMS, to support multiple sets of packages in different regions.

A package is a group of zero or more multicast sources that share a common access permission. Grouping the source channels into one or more packages provides flexibility for the service provider to deliver different levels of services to the end users; for example, "Basic Package", "Middle-Tier Package", and "Premium Package".

***NOTE:** There is no requirement to configure the package. If the package is modified, there is no effect on the multicast source.*

User Level

The command can be accessed by operators with igmp privileges, and executed by operators with igmp privileges.

Command Syntax

The command has the following syntax:

```
> configure mcast-control package (index) [ no name | name <Igmp::igmpPackageName> ] [ no template-name |
template-name <Igmp::igmpPackageTemplateName> ] [ no template-version | template-version
<Igmp::igmpPackageTemplateVersion> ]
```

Command Parameters

Table 90.14-1 "mcast Package Bitmaps Configuration Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of the package - range: [1...1024]	index of the package

Table 90.14-2 "mcast Package Bitmaps Configuration Command" Command Parameters

Parameter	Type	Description
[no] name	Parameter type: <Igmp::igmpPackageName> Format: - a printable string - length: x<=32	<i>optional parameter with default value: ""</i> name of the package
[no] template-name	Parameter type: <Igmp::igmpPackageTemplateName> Format: - a printable string - length: x<=32	<i>optional parameter with default value: ""</i> name of the service template containing this pkg
[no] template-version	Parameter type: <Igmp::igmpPackageTemplateVersion> Format: - version of the service template containing this package	<i>optional parameter with default value: 0</i> version of the service template

90 Mcast control Configuration Commands

Parameter	Type	Description
	- range: [0...65535]	containing this pkg

91- Equipment Status Commands

91.1 Equipment Status Command Tree	91-1954
91.2 Slot Status Command	91-1955
91.3 Profile Description Command	91-1961
91.4 Applique Status Command	91-1962
91.5 Shelf Summary Status Command	91-1966
91.6 Protection Element Status Command	91-1968
91.7 Protection Group Status Command	91-1971
91.8 External-link-host Status Commands	91-1974
91.9 External-link-remote Status Commands	91-1978
91.10 SFP/XFP Diagnostics Status Command	91-1981
91.11 SFP/XFP Diagnostics Status Command	91-1988
91.12 Sfp RSSI Configuration Command	91-1995
91.13 Board Temperature Status Command	91-1996
91.14 Board Planned Resource Command	91-1998
91.15 Transceiver Inventory Status Command	91-2000
91.16 NE Status Command	91-2008
91.17 Rack Status Command	91-2010
91.18 Shelf Status Command	91-2012
91.19 Power Supply Status Command	91-2016

91.1 Equipment Status Command Tree

Description

This chapter gives an overview of nodes that are handled by "Equipment Status Commands".

Command Tree

```
----show
  ----equipment
    ----slot
      - (slot)
    ----capab-profile
      - (profilename)
    ----applique
      - (applique)
    ----shelf-summary
      - (shelf)
    ----protection-element
      - (slot-id)
    ----protection-group
      - (prot-group-id)
    ----external-link-host
      - (index)
    ----external-link-remote
      - (exp-slot)
    ----diagnostics
      ----sfp
        - (position)
      ----sfp-threshold
        - (position)
    ----rssiprof
      - (index)
    ----temperature
      - (slot)
      - sensor-id
    ----planned-resource
      - (slot)
      - resource-id
    ----transceiver-inventory
      - (index)
    ----isam
    ----rack
      - (rack)
    ----shelf
      - (shelf)
    ----power-supply
      - (psu-num)
```

91.2 Slot Status Command

Command Description

This command shows the slot status. The following information is shown for each slot:

- *type* : describes the type of the unit that is currently present in the slot.
- *capab-profile*: capability profile assigned to the slot, applicable for line boards, NTIOs and mini-NT NRNT-A.
- *oper-status*: describes whether the unit is able to perform its normal operation.
- *error-status*: provides the reason why the board is not operational. These values correspond to the alarms generated in case of a failure.
- *available-status*: provides further information regarding the state of the unit.
- *manufacturer*: provides an identification of the unit manufacturer.
- *inventory-pba*: provides the Nokia Printed Board Assembly code of the unit.
- *inventory-fpba*: provides the Nokia Printed Board Assembly code of the unit which also identifies the boot software.
- *inventory-ics*: provides the Item Change Status iteration code of the unit.
- *inventory-clei*: provides the (USA) Common Language Equipment Identification code of the unit.
- *serial-no*: provides the serial number of the board.
- *failed-test*: provides identification of the last failing test using four numbers, from MSB to LSB:
 - - table number (1 byte)
 - - segment number (1 byte)
 - - case number (1 byte)
 - - check number (1 byte)

As long as there has been no failing self test, the value of this attribute will be 0.

User Level

The command can be accessed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

```
> show equipment slot [ (slot) ]
```

Command Parameters

Table 91.2-1 "Slot Status Command" Resource Parameters

Resource Identifier	Type	Description
(slot)	Format: (lt : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> nt-a nt-b nt acu : <Eqpt::RackId> / <Eqpt::ShelfId> bat-a : <Eqpt::RackId> / <Eqpt::ShelfId> bat-b : <Eqpt::RackId> / <Eqpt::ShelfId> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::EqSlotId>	the physical slot position

Resource Identifier	Type	Description
	<pre> ext-a : <Eqpt::RackId> / <Eqpt::ShelfId> ext-b : <Eqpt::RackId> / <Eqpt::ShelfId> ctrl : <Eqpt::RackId> / <Eqpt::ShelfId> vlt : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::VirtualSlotId>) Possible values: - lt : lt-slot - vlt : virtual LT slot (VVPS board can only be planned at NANT-E / FANT-F) - nt-a : nt-a slot - nt-b : nt-b slot - nt : nt slot - ext-a : nt-a slot in an extension shelf - ext-b : nt-b slot in an extension shelf - acu : acu slot - bat-a : bat-a slot - bat-b : bat-b slot - ctrl : ctrl-slot Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::VirtualSlotId> - the virtual LT slot number Field type <Eqpt::EqSlotId> - the equipment slot number </pre>	

Command Output

Table 91.2-2 "Slot Status Command" Display parameters

Specific Information		
name	Type	Description
planned-type	Parameter type: <Equipm::BrdType> Data driven field type Possible values are depending on the actual configuration and software. The currently allowed values can be shown with online-help.	A string representing the board that is planned in the slot. <i>This element is only shown in detail mode.</i>
actual-type	Parameter type: <Equipm::ActBoardType> Data driven field type Possible values are depending on the actual configuration and software. The currently allowed values can be shown with online-help.	A string representing the board that is actually present in the slot. <i>This element is always shown.</i>
oper-status short name: enabled	Parameter type: <Equipm::OperStatus> ((enabled yes) (disabled no)) Possible values: - enabled : - yes : - disabled : - no :	Specifies whether the plug-in unit is able to perform its normal operation. <i>This element is always shown.</i>
error-status	Parameter type: <Equipm::OperError> (no-error type-mismatch board-missing	Specifies for what reason the board is not operational. These values correspond with the alarms which are generated in

name	Type	Description
	no-installation no-planned-board waiting-for-sw init-boot-failed init-download-failed init-connection-failed configuration-failed board-reset-protection invalid-parameter temperature-alarm tempshutdown defense board-not-licensed sem-power-fail sem-ups-fail incompatible-slot download-ongoing upgrade-via-sby board-shelf-mismatch unknown-error) Possible values: - no-error : - type-mismatch : - board-missing : - no-installation : - no-planned-board : - waiting-for-sw : - init-boot-failed : - init-download-failed : - init-connection-failed: - configuration-failed : - board-reset-protection: - invalid-parameter : - temperature-alarm : - tempshutdown : - defense : - board-not-licensed : - sem-power-fail : - sem-ups-fail : - incompatible-slot : - download-ongoing : - upgrade-via-sby : - board-shelf-mismatch : - unknown-error :	case of a failure. <i>This element is always shown.</i>
availability	Parameter type: <Equipm::AvailStatus> (available in-test failed power-off not-installed offline dependency ext-managed) Possible values: - available : - in-test : - failed :	Specifies the state of the board. It is set to available after a successful selftest of the board (if applicable). <i>This element is always shown.</i>

91 Equipment Status Commands

name	Type	Description
	- power-off : - not-installed : - offline : - dependency : - ext-managed :	
alarm-profile	Parameter type: <Equipm::AlarmProf> (none name : <PrintableString-0-32>) Possible values: - none : no profile name to associate - name : profile name Field type <PrintableString-0-32> - a printable string - length: x<=32	The name of the customized alarm profile that is allocated to the board, if any. <i>This element is only shown in detail mode.</i>
capab-profile	Parameter type: <Equipm::CapabilityProfile> Data driven field type Possible values are depending on the actual configuration and software. The currently allowed values can be shown with online-help.	To display the configured profile of the board. <i>This element is only shown in detail mode.</i>
operational-mode	Parameter type: <Equipm::OperationalMode> (not-set gpon xgs mpm-gpon-xgs dual-gpon u-ngpon twenty-five-g ng-pon2 mpm-gpon-xgpon) Possible values: - not-set : cage mode not-set - gpon : cage mode set to gpon - xgs : cage mode set to xgs - mpm-gpon-xgs : cage mode set to mpm-gpon-xgs - dual-gpon : cage mode set to dual-gpon - u-ngpon : cage mode set to u-ngpon - twenty-five-g : cage mode set to 25g - ng-pon2 : cage mode set to ng-pon2 - mpm-gpon-xgpon : cage mode set to mpm-gpon-xgpon	To display the configured profile of the board. <i>This element is only shown in detail mode.</i>
manufacturer	Parameter type: <PrintableString> - printable string	Specifies the company of the board. <i>This element is only shown in detail mode.</i>
mnemonic	Parameter type: <PrintableString> - printable string	Specifies the name of the board. <i>This element is only shown in detail mode.</i>
pba-code	Parameter type: <PrintableString> - printable string	Specifies the Nokia printed board assembly code of of the board. <i>This element is only shown in detail mode.</i>
fpba-code	Parameter type: <PrintableString> - printable string	Specifies the Nokia printed board assembly code of the board, which also identifies the boot software. <i>This element is only shown in detail mode.</i>
fpba-ics	Parameter type: <PrintableString>	Specifies the item change status

name	Type	Description
	- printable string	iteration code of the board. <i>This element is only shown in detail mode.</i>
clei-code	Parameter type: <PrintableString> - printable string	Specifies the common language equipment identification code of the board. <i>This element is only shown in detail mode.</i>
serial-no	Parameter type: <PrintableString> - printable string	Specifies the serial number of the board. <i>This element is only shown in detail mode.</i>
failed-test	Parameter type: <Equipm::Octet-4> - a binary string	Specifies the last failing test. <i>This element is only shown in detail mode.</i>
lt-restart-time	Parameter type: <Equipm::restartTime> - the time (yyyy-mm-dd:hour:minutes:secs) - unit: UTC	The last restart time. This element is supported on LTs as well as NTs. <i>This element is only shown in detail mode.</i>
lt-restart-cause	Parameter type: <Equipm::eqptBoardLastRestartCause> (poweron watchdog cold_reset warm_reset hot_reset hot_reload clean_data emergency_build poweron_reset commit_failure timezone_modified other) Possible values: - poweron : restart after power on - watchdog : restart triggered by HW watchdog timeout - cold_reset : HW reset of the board with selftest - warm_reset : HW reset of the board without selftest - hot_reset : operational SW restart without HW reset - hot_reload : operational SW reload and restart without HW reset - clean_data : operational SW triggered HW reset with DB clean - emergency_build : cold reset when error escalation mechanism keeps failing - poweron_reset : operational SW triggered restart as poweron - commit_failure : restart due to new SW package commit failure - timezone_modified : restart reported due to a change in Time Zone offset - other : restart due to unknown reason	the cause of the most recent restart of the board <i>This element is only shown in detail mode.</i>
lt-restart-num short name: restrt-cnt	Parameter type: <Counter> - 32 bit counter	the number of times the board has restarted (It is only applicable for LTs) <i>This element is always shown.</i>
restart-cnt-per-lt	Parameter type: <Counter>	the number of times the board has

91 Equipment Status Commands

name	Type	Description
	- 32 bit counter	restarted(applicable for LTs and Per LT basis, not like Per slot(lt-restart-num) counter) <i>This element is only shown in detail mode.</i>
mgnt-entity-oamipaddr	Parameter type: <Ip::V4Address> - IPv4-address	an ip address is used to as the oam ip. <i>This element is only shown in detail mode.</i>
mgnt-entity-pairnum	Parameter type: <SignedInteger> - a signed integer	the paired number on the xvps's shelf. <i>This element is only shown in detail mode.</i>
dual-host-ip	Parameter type: <Ip::V4Address> - IPv4-address	the dual host ip address <i>This element is only shown in detail mode.</i>
dual-host-loc	Parameter type: <Equipm::Dualhost> (<Eqpt::MultiRackId> / <Eqpt::MultiShelfId> none) Possible values: - none : no host lsm location Field type <Eqpt::MultiRackId> - the rack number Field type <Eqpt::MultiShelfId> - the shelf number	the dual host lsm location <i>This element is only shown in detail mode.</i>
board-40gkr4	Parameter type: <Equipm::board40GKR4> (inherited disable enable) Possible values: - inherited : enable or disable 40G KR4 of the board is controlled by system level parameter - disable : the board should not work in 40GKR4 no matter the value of system level - enable : the board should work in 40GKR4 no matter the value of system level	To display the 40GKR4 of the board. <i>This element is only shown in detail mode.</i>

91.3 Profile Description Command

Command Description

This command displays the information related to a profile. The following information is shown for each profile:

- *profile-id* : displays the profile-id associated with a profile name
- *description* : displays the description of the profile.
- *board-type*: displays the board type associated with a given profile

User Level

The command can be accessed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

```
> show equipment capab-profile [ (profilename) ]
```

Command Parameters

Table 91.3-1 "Profile Description Command" Resource Parameters

Resource Identifier	Type	Description
(profilename)	Format: Data driven field type Possible values are depending on the actual configuration and software. The currently allowed values can be shown with online-help.	the profile name

Command Output

Table 91.3-2 "Profile Description Command" Display parameters

Specific Information		
name	Type	Description
profile-id	Parameter type: <AsamProfilePointer> - a pointer to a profile or profile index - range: [0...65535]	The profile id of the corresponding profile name. <i>This element is always shown.</i>
description	Parameter type: <PrintableString> - printable string	Description of the profile <i>This element is always shown.</i>
board-type	Parameter type: <Equipm::Profile> Data driven field type Possible values are depending on the actual configuration and software. The currently allowed values can be shown with online-help.	Description of the profile <i>This element is always shown.</i>

91.4 Applique Status Command

Command Description

This command shows the applique status. The following information is shown for each applique slot:

- *type*: provides the type of the applique that is currently present in the slot.
- *oper-status*: describes whether the applique is able to perform its normal operation.
- *error-status*: describes the reason why the applique is not operational. These values correspond to the alarms generated in case of a failure.
- *available-status*: provides further information regarding the state of the applique.
- *manufacturer*: provides an identification of the applique manufacturer.
- *inventory-pba*: provides the Nokia Printed Board Assembly code of the applique.
- *inventory-fpba*: provides the Nokia Printed Board Assembly code of the applique which also identifies the boot software.
- *inventory-ics*: provides the Item Change Status iteration code of the applique.
- *inventory-clei*: provides the (USA) Common Language Equipment Identification code of the applique.
- *serial-no*: provides the serial number of the applique.
- *failed-test*: provides the identification of the last failing test using four numbers, from MSB to LSB:
 - - table number (1 byte)
 - - segment number (1 byte)
 - - case number (1 byte)
 - - check number (1 byte)

As long as there has been no failing self test, the value of this attribute will be 0.

User Level

The command can be accessed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

```
> show equipment applique [ (applique) ]
```

Command Parameters

Table 91.4-1 "Applique Status Command" Resource Parameters

Resource Identifier	Type	Description
(applique)	Format: (iont : <Eqpt::RackId> / <Eqpt::ShelfId> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::AppliqueSlotId> lp : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::LtAppliqueSlotId> ntio-1 ntio-2) Possible values: - iont : an nt applique slot	the physical applique position

Resource Identifier	Type	Description
	- lp : an lt applique slot - ntio-1 : an nt applique slot in a single or multiple-ntio-shelf - ntio-2 : an nt applique slot in a multiple-ntio-shelf Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::AppliqueSlotId> - the applique slot number Field type <Eqpt::LtAppliqueSlotId> - the LT Applique slot number	

Command Output

Table 91.4-2 "Applique Status Command" Display parameters

Specific Information		
name	Type	Description
planned-type	Parameter type: <Equipm::AppliqueType> Data driven field type Possible values are depending on the actual configuration and software. The currently allowed values can be shown with online-help.	A string representing the board that is planned in the slot. <i>This element is only shown in detail mode.</i>
actual-type	Parameter type: <Equipm::AppliqueType> Data driven field type Possible values are depending on the actual configuration and software. The currently allowed values can be shown with online-help.	A string representing the board that is actually present in the slot. <i>This element is always shown.</i>
oper-status short name: enabled	Parameter type: <Equipm::OperStatus> ((enabled yes) (disabled no)) Possible values: - enabled : - yes : - disabled : - no :	Specifies whether the plug-in unit is able to perform its normal operation. <i>This element is always shown.</i>
error-status	Parameter type: <Equipm::OperError> (no-error type-mismatch board-missing no-installation no-planned-board waiting-for-sw init-boot-failed init-download-failed init-connection-failed configuration-failed board-reset-protection invalid-parameter temperature-alarm tempshutdown defense board-not-licensed sem-power-fail sem-ups-fail incompatible-slot download-ongoing	Specifies for what reason the board is not operational. These values correspond with the alarms which are generated in case of a failure. <i>This element is always shown.</i>

91 Equipment Status Commands

name	Type	Description
	upgrade-via-sby board-shelf-mismatch unknown-error) Possible values: - no-error : - type-mismatch : - board-missing : - no-installation : - no-planned-board : - waiting-for-sw : - init-boot-failed : - init-download-failed : - init-connection-failed: - configuration-failed : - board-reset-protection: - invalid-parameter : - temperature-alarm : - tempshutdown : - defense : - board-not-licensed : - sem-power-fail : - sem-ups-fail : - incompatible-slot : - download-ongoing : - upgrade-via-sby : - board-shelf-mismatch : - unknown-error :	
availability	Parameter type: <Equipm::AvailStatus> (available in-test failed power-off not-installed offline dependency ext-managed) Possible values: - available : - in-test : - failed : - power-off : - not-installed : - offline : - dependency : - ext-managed :	Specifies the state of the board. It is set to available after a successful selftest of the board (if applicable). <i>This element is always shown.</i>
manufacturer	Parameter type: <PrintableString> - printable string	Specifies the company of the board. <i>This element is only shown in detail mode.</i>
mnemonic	Parameter type: <PrintableString> - printable string	Specifies the name of the board. <i>This element is only shown in detail mode.</i>
pba-code	Parameter type: <PrintableString> - printable string	Specifies the Nokia Printed Board Assembly code of of the board. <i>This element is only shown in detail mode.</i>

name	Type	Description
fpba-code	Parameter type: <PrintableString> - printable string	Specifies the Nokia Printed Board Assembly code of the board, which also identifies the boot software. <i>This element is only shown in detail mode.</i>
fpba-ics	Parameter type: <PrintableString> - printable string	Specifies the item change status iteration code of the board. <i>This element is only shown in detail mode.</i>
clei-code	Parameter type: <PrintableString> - printable string	Specifies the common language equipment identification code of the board. <i>This element is only shown in detail mode.</i>
serial-no	Parameter type: <PrintableString> - printable string	Specifies the serial number of the board. <i>This element is only shown in detail mode.</i>
failed-test	Parameter type: <Equipm::Octet-4> - a binary string	Specifies the last failing test. <i>This element is only shown in detail mode.</i>

91.5 Shelf Summary Status Command

Command Description

This commands shows a summary of the slots in a shelf.

The least significant bit of the first byte shown corresponds to the slot position 1.

User Level

none

Command Syntax

The command has the following syntax:

> show equipment shelf-summary [(shelf)]

Command Parameters

Table 91.5-1 "Shelf Summary Status Command" Resource Parameters

Resource Identifier	Type	Description
(shelf)	Format: <Eqpt::RackId> / <Eqpt::ShelfId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number	the physical shelf position

Command Output

Table 91.5-2 "Shelf Summary Status Command" Display parameters

Specific Information		
name	Type	Description
changes	Parameter type: <Counter> - 32 bit counter	Number of configuration or status changes for slots/boards within this shelf. <i>This element is always shown.</i>
occupied-slots	Parameter type: <Equipm::Octet-8> - a binary string - length: 8	Specifies the occupation of slots. <i>This element is only shown in detail mode.</i>
admin-unlocked	Parameter type: <Equipm::Octet-8> - a binary string - length: 8	Specifies the administrative state of the boards whether it is locked or not. <i>This element is only shown in detail mode.</i>
oper-unlocked	Parameter type: <Equipm::Octet-8> - a binary string	Specifies the operational state of the boards whether it is locked or

91 Equipment Status Commands

name	Type	Description
	- length: 8	not. <i>This element is only shown in detail mode.</i>
avail-boards	Parameter type: <Equipm::Octet-8> - a binary string - length: 8	Specifies the availability state of the boards whether it is available or not. <i>This element is only shown in detail mode.</i>
mismatches	Parameter type: <Equipm::Octet-8> - a binary string - length: 8	Specifies any mismatch between the actual board-type and the planned board-type. <i>This element is always shown.</i>
alarms	Parameter type: <Equipm::Octet-8> - a binary string - length: 8	Specifies the boards which generated an alarm. <i>This element is always shown.</i>

91.6 Protection Element Status Command

Command Description

This command shows the protected element-related parameter of the equipment.

User Level

The command can be accessed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

> show equipment protection-element [(slot-id)]

Command Parameters

Table 91.6-1 "Protection Element Status Command" Resource Parameters

Resource Identifier	Type	Description
(slot-id)	Format: (lt : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> nt-a nt-b <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::EqSlotId> vlt : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::VirtualSlotId>) Possible values: - lt : lt-slot - vlt : virtual LT slot (VVPS board can only be planned at NANT-E / FANT-F) - nt-a : nt-a slot - nt-b : nt-b slot Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::VirtualSlotId> - the virtual LT slot number Field type <Eqpt::EqSlotId> - the equipment slot number	Index in eqpt Prot Element Table

Command Output

Table 91.6-2 "Protection Element Status Command" Display parameters

Specific Information

name	Type	Description
standby-status	Parameter type: <Equipm::ProtElementStandbyStatus> (providing-service hot-standby cold-standby idle) Possible values: - providing-service : providing services - hot-standby : hot standby - cold-standby : cold standby - idle : idle	The standby status of the protection group element. <i>This element is always shown.</i>
group-id	Parameter type: <Equipm::ProtGroupId> - index of protection group - range: [1...109]	The belonged group id of protection element. <i>This element is always shown.</i>
redcy-ctrl-status	Parameter type: <Equipm::ProtElementRedcyCtrlStatus> (normal forced_active) Possible values: - normal : enables redundancy (active or standby) - forced_active : forces the element to be active	the redcy ctrl status of the protection group element. <i>This element is always shown.</i>
stdby-stat-chg-reason short name: stdby-chg-reas	Parameter type: <Equipm::ProtElementStandByStatusChgReason> (none prot-grp-lckd forced-active (peernt-link-unav lk-unav) peer-lckd peer-not-plan peer-not-plugin db-not-sync shub-not-sync shub-sdkfail shub-recov-sdkfail shub-hwfail shub-dyn-syncfail shub-stat-syncfail shub-peer-commfail (shub-failure shub-fail) (lk-grp-notavail lk-grp-ntav) lt-not-enabled (shub-higig-failure shub-higig-fail) (shub-discovery-failure shub-disc-fail) (shub-reconcile-failure shub-recon-fail) (dpoe-application-fail dpoe-app-fail) (dpoe-communicate-fail dpoe-comm-fail) (dpoe-synchronize-fail dpoe-sync-fail) (dpoe-unreachable dpoe-unrchble)) Possible values: - none : standby state is hot standby or not applicable (default value) - prot-grp-lckd : redundancy not enabled - forced-active : active board is put to forced active - peernt-link-unav : standby NT link not available - lk-unav : standby NT link not available - peer-lckd : standby board locked - peer-not-plan : standby board not planned - peer-not-plugin : standby board not plugged in - db-not-sync : database not synchronized	reason why the standby-status of the protection-group is changed <i>This element is always shown.</i>

91 Equipment Status Commands

name	Type	Description
	- shub-not-sync : shub data not synchronized - shub-sdkfail : stdby shub detected non-recov sdk failure - shub-recov-sdkfail : stdby shub detected recov sdk failure - shub-hwfail : stdby shub detected hw failure - shub-dyn-syncfail : shub dynamic data not synchronized - shub-stat-syncfail : shub static data not synchronized - shub-peer-commfail : stdby shub lost communication with active shub - shub-failure : stdby shub not alive - shub-fail : stdby shub not alive - lk-grp-notavail : link group not available - lk-grp-ntav : link group not available - lt-not-enabled : LT not enabled in case of LT redundancy - shub-higig-failure : shub HiGig failure - shub-higig-fail : shub HiGig failure - shub-discovery-failure: shub unable to discover its peer - shub-disc-fail : shub unable to discover its peer - shub-reconcile-failure: shub unable to synchronise with peer - shub-recon-fail : shub unable to synchronise with peer - dpoe-application-fail : dpoe has detected application failure - dpoe-app-fail : dpoe has detected application failure - dpoe-communicate-fail : dpoe has lost communication with active dpoe - dpoe-comm-fail : dpoe has lost communication with active dpoe - dpoe-synchronize-fail : dpoe unable to synchronise with peer - dpoe-sync-fail : dpoe unable to synchronise with peer - dpoe-unreachable : dpoe is unreachable - dpoe-unrchble : dpoe is unreachable	

91.7 Protection Group Status Command

Command Description

This command shows the parameters related to protection groups.

User Level

The command can be accessed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

```
> show equipment protection-group [ (prot-group-id) ]
```

Command Parameters

Table 91.7-1 "Protection Group Status Command" Resource Parameters

Resource Identifier	Type	Description
(prot-group-id)	Format: - a signed integer	Index in eqpt Prot Group Table

Command Output

Table 91.7-2 "Protection Group Status Command" Display parameters

Specific Information		
name	Type	Description
admin-status	Parameter type: <Equipm::PortGroupAdminStatus> (unlock lock) Possible values: - unlock : unlock - lock : lock	distinguishes the administration-status <i>This element is always shown.</i>
service-status	Parameter type: <Equipm::ServiceStatus> (in-service not-in-service) Possible values: - in-service : the protection group is in service - not-in-service : the protection group is not in service	indicate the service status of protection group, a protection group and its elements are not configurable when it is out of service <i>This element is always shown.</i>
eps-quenchfactor	Parameter type: <Equipm::TimeTicks> - timer value for quench mechanish - unit: 1/100 sec	timervalue of quenching mechanism, 0 is valid value <i>This element is only shown in detail mode.</i>
prot-group-type	Parameter type: <Equipm::PortGroupType> (one-plus-one one-for-n)	distinguishes between 1+1 and 1:N protection groups <i>This element is always shown.</i>

91 Equipment Status Commands

name	Type	Description
	Possible values: - one-plus-one : one to one - one-for-n : one to many	
prot-changes	Parameter type: <Counter> - 32 bit counter	wrap around counter which indicates the number of status changes in this protection group as well as the status changes for the protecting elements within this group <i>This element is only shown in detail mode.</i>
switchover-count	Parameter type: <Counter> - 32 bit counter	wrap around counter for the number of switchovers being performed <i>This element is only shown in detail mode.</i>
last-switchover-reason	Parameter type: <Equipm::SwitchOverReason> (no-switch-over forced-active board-not-present extender-chain-failure link-failure watchdog-timeout file-system-corrupt configuration-mismatch board-unplanned board-locked shelf-defense revertive-switchover shub-pollfailure shub-hwfailure shub-sdkfailure dpoe-appfailure dpoe-unreachable forced-switchover) Possible values: - no-switch-over : no switch over has been performed yet - forced-active : chain A is forced - board-not-present : board is removed or not reachable - extender-chain-failure: extender chain failure - link-failure : link failure - watchdog-timeout : redundancy watchdog - file-system-corrupt : corruption of file system - configuration-mismatch: mismatch in boardType or Swversion - board-unplanned : board has been unplanned - board-locked : board has been locked - shelf-defense : shelf-error detected by defense - revertive-switchover : switchover because protected board is operational again (in case of 1:N) - shub-pollfailure : shub failure - shub-hwfailure : active shub detected a hw failure - shub-sdkfailure : active shub detected a sdk failure - dpoe-appfailure : active dpoe detected application failure - dpoe-unreachable : active dpoe is not reachable - forced-switchover : forced switchover by user	contains the reason of the last switch over <i>This element is only shown in detail mode.</i>
alarm-bitmap	Parameter type: <Equipm::BitMapType>	status bitmap: bit 0 set means no

name	Type	Description
	(no-alarm stand-by-degrd) Possible values: - no-alarm : no-alarm - stand-by-degrd : standby degradation alarm	defect at all, bit 1 : if bit set, loss of switch-over capabilities alarm is set (excludes bit 0 setting), bit 2 .. 31 : reserved for future extensions <i>This element is only shown in detail mode.</i>
oper-prot-element	Parameter type: <SignedInteger> - a signed integer	only supported for 1:N protection groups, indicates which element is currently protected by the spare element, value 0 means that currently the spare element is not protecting any element <i>This element is only shown in detail mode.</i>

91.8 External-link-host Status Commands

Command Description

This command allows the operator to show the host shelf's external-links status. The following information is shown for each external-link:

- The SHub/IHub port which the host external link is connected to
- The downlink status
- The slot id of the expansion shelf that is cabled to the host expansion board.
- The output "none" for the display parameter "exp-slot" means the sfp is not connected to any rack/shelf/slot.

User Level

The command can be accessed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

```
> show equipment external-link-host [ (index) ]
```

Command Parameters

Table 91.8-1 "External-link-host Status Commands" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: (<Eqpt::ExtSfpFaceplateType> nt : sfp : <Eqpt::ExtSfpFaceplateType> nt : xfp : <Eqpt::ExtSfpFaceplateType> lt : <Eqpt::HostRackId> / <Eqpt::HostShelfId> / <Eqpt::LtExtSlotId> / <Eqpt::ExtSfpFaceplateType> ntio-1 : sfp : <Eqpt::ExtSfpFaceplateType> ntio-1 : xfp : <Eqpt::ExtSfpFaceplateType> ntio-2 : sfp : <Eqpt::ExtSfpFaceplateType> ntio-2 : xfp : <Eqpt::ExtSfpFaceplateType>) Possible values: - nt : active nt slot - lt : lt-slot - ntio-1 : an nt applique slot in a single or multiple-ntio-shelf - ntio-2 : an nt applique slot in a multiple-ntio-shelf Field type <Eqpt::HostRackId> - the rack number Field type <Eqpt::HostShelfId> - the shelf number Field type <Eqpt::LtExtSlotId> - the LT slot number Possible values: - sfp : SFP port - xfp : XFP port	the physical sfp or xfp cage position

Resource Identifier	Type	Description
	Field type <Eqpt::ExtSfpFaceplateType> - The faceplate on which remote LT is connected	

Command Output

Table 91.8-2 "External-link-host Status Commands" Display parameters

Specific Information		
name	Type	Description
shub-port	Parameter type: <Equipm::lanxPortNumber> - a signed integer	the shub port which the host external link is connected to <i>This element is always shown.</i>
downlink-status	Parameter type: <Equipm::HostSfpDownlinkStatus> (ok sfp-not-present los tx-fail invalid-nokia-id unknown sfp-control-fail uplink tx-fail-and-los) Possible values: - ok : the downlink is operational - sfp-not-present : no sfp present for the downlink - los : los is detected by the host for the downlink - tx-fail : the downlink tx failed - invalid-nokia-id : the downlink sfp plugged does not have a valid nokia id - unknown : the host expansion card is planned but not inserted - sfp-control-fail : sfp not responding or i2c failure - uplink : the sfp is configured as uplink - tx-fail-and-los : the downlink tx failed and los detected by the host for the downlink	the host expansion card's external downlink status <i>This element is always shown.</i>
exp-slot	Parameter type: <Equipm::ExpansionSlotIndex> <Eqpt::ExpRack> / <Eqpt::ExpShelf> / <Eqpt::ExpSlot> Field type <Eqpt::ExpRack> - the physical number of the expansion rack, 0 stands for no remote Field type <Eqpt::ExpShelf> - physical nbr of expansion shelf within expansion rack, 0 stands for no remote Field type <Eqpt::ExpSlot> - the physical number of the slot within expansion shelf, 0 stands for no remote	the slot id of the expansion shelf that is cabled to the host expansion board <i>This element is always shown.</i>
host-sfp-type	Parameter type: <Equipm::SfpType> (unknown 1000base-sx 1000base-lx 1000base-cx 1000base-t 100base-lx/lx10 100base-fx base-bx10 base-px reserved	the host shelf sfp type <i>This element is only shown in detail mode.</i>

91 Equipment Status Commands

name	Type	Description
	10gbase-ew 10gbase-lw 10gbase-sw 10gbase-lrm 10gbase-er 10gbase-lr 10gbase-sr 10gbase-sr-sw 10gbase-sr-lw 10gbase-sr-ew 10gbase-lr-sw 10gbase-lr-lw 10gbase-lr-ew 10gbase-er-sw 10gbase-er-lw 10gbase-er-ew 10gbase-lrm-sw 10gbase-lrm-lw 10gbase-lrm-ew 2500base-sx 2500base-lx 2500base-bx) Possible values: - unknown : the sfp ethernet type is not known - 1000base-sx : gigabit ethernet compliance code - 1000base-lx : gigabit ethernet compliance code - 1000base-cx : gigabit ethernet compliance code - 1000base-t : gigabit ethernet compliance code - 100base-lx/lx10 : gigabit ethernet compliance code - 100base-fx : gigabit ethernet compliance code - base-bx10 : gigabit ethernet compliance code - base-px : gigabit ethernet compliance code - reserved : reserved bit 8 - 10gbase-ew : 10 gigabit ethernet compliance code - 10gbase-lw : 10 gigabit ethernet compliance code - 10gbase-sw : 10 gigabit ethernet compliance code - 10gbase-lrm : 10 gigabit ethernet compliance code - 10gbase-er : 10 gigabit ethernet compliance code - 10gbase-lr : 10 gigabit ethernet compliance code - 10gbase-sr : 10 gigabit ethernet compliance code - 10gbase-sr-sw : 10 gigabit ethernet compliance code - 10gbase-sr-lw : 10 gigabit ethernet compliance code - 10gbase-sr-ew : 10 gigabit ethernet compliance code - 10gbase-lr-sw : 10 gigabit ethernet compliance code - 10gbase-lr-lw : 10 gigabit ethernet compliance code - 10gbase-lr-ew : 10 gigabit ethernet compliance code - 10gbase-er-sw : 10 gigabit ethernet compliance code - 10gbase-er-lw : 10 gigabit ethernet compliance code - 10gbase-er-ew : 10 gigabit ethernet compliance code - 10gbase-lrm-sw : 10 gigabit ethernet compliance code - 10gbase-lrm-lw : 10 gigabit ethernet compliance code - 10gbase-lrm-ew : 10 gigabit ethernet compliance code - 2500base-sx : gigabit ethernet compliance code - 2500base-lx : gigabit ethernet compliance code - 2500base-bx : gigabit ethernet compliance code	
cabling-status	Parameter type: <Equipm::SfpCableMismatch> (no-mismatch	the host shelf cabling mismatch <i>This element is always shown.</i>

name	Type	Description
	unexpected-lt assign-mismatch incompat-shelf) Possible values: - no-mismatch : no cabling mismatch is detected - unexpected-lt : remote LT is detected at an unassigned downlink SFP port - assign-mismatch : the detected remote LT does not match the LT assigned to this host SFP - incompat-shelf : the detected remote shelf does not match the shelf type assigned to this host SFP	
phy-address	Parameter type: <Ip::PhysicalAddress> - media dependent physical address - length: 8	the physical address of the remote interface cabled to host shelf SFP <i>This element is only shown in detail mode.</i>

91.9 External-link-remote Status Commands

Command Description

This command allows the operator to show the remote shelves external-links status. The following information is shown for each external-link:

- The slot id of the expansion shelf
- The link status
- The faceplate number of the host external-link device in which the expansion shelf's external-link device is cabled to

User Level

The command can be accessed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

```
> show equipment external-link-remote [ (exp-slot) ]
```

Command Parameters

Table 91.9-1 "External-link-remote Status Commands" Resource Parameters

Resource Identifier	Type	Description
(exp-slot)	Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::ExpSlotId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::ExpSlotId> - the expansion slot number	the physical expansion slot position

Command Output

Table 91.9-2 "External-link-remote Status Commands" Display parameters

Specific Information		
name	Type	Description
sfp-status	Parameter type: <Equipm::ExpSfpStatus> (ok sfp-not-present los tx-fail invalid-nokia-id unknown sfp-control-fail	the status of the expansion shelf sfp <i>This element is always shown.</i>

name	Type	Description
	tx-fail-and-los) Possible values: - ok : the expansion shelf SFP is operational - sfp-not-present : no sfp present - los : los is detected by the expansion shelf sfp - tx-fail : the expansion shelf tx failed - invalid-nokia-id : the expansion shelf sfp plugged does not have a valid nokia id - unknown : the status is not available or cannot be retrieved - sfp-control-fail : sfp not responding or i2c failure - tx-fail-and-los : the expansion shelf tx failed and los detected by the expansion shelf sfp	
host-sfp-faceplate-nbr	Parameter type: <Equipm::LtFaceplateRemoteExtLinkIndex> (<Eqpt::ExtSfpFaceplateType> nt : sfp : <Eqpt::ExtSfpFaceplateType> nt : xfp : <Eqpt::ExtSfpFaceplateType> lt : <Eqpt::HostRackId> / <Eqpt::HostShelfId> / <Eqpt::LtExtSlotId> / <Eqpt::ExtSfpFaceplateType> ntio-1 : sfp : <Eqpt::ExtSfpFaceplateType> ntio-1 : xfp : <Eqpt::ExtSfpFaceplateType> ntio-2 : sfp : <Eqpt::ExtSfpFaceplateType> ntio-2 : xfp : <Eqpt::ExtSfpFaceplateType> not-cabled) Possible values: - not-cabled : device is not cabled - nt : active nt slot - lt : lt-slot - ntio-1 : an nt applique slot in a single or multiple-ntio-shelf - ntio-2 : an nt applique slot in a multiple-ntio-shelf Field type <Eqpt::HostRackId> - the rack number Field type <Eqpt::HostShelfId> - the shelf number Field type <Eqpt::LtExtSlotId> - the LT slot number Possible values: - sfp : SFP port - xfp : XFP port Field type <Eqpt::ExtSfpFaceplateType> - The faceplate on which remote LT is connected	the faceplate number of the host shelf external-link device which the expansion shelf external-link device is cabled to <i>This element is always shown.</i>
exp-sfp-type	Parameter type: <Equipm::SfpType> (unknown 1000base-sx 1000base-lx 1000base-cx 1000base-t 100base-lx/lx10 100base-fx base-bx10 base-px reserved 10gbase-ew 10gbase-lw 10gbase-sw 10gbase-lrm 10gbase-er	the expansion shelf sfp type <i>This element is always shown.</i>

91 Equipment Status Commands

name	Type	Description
	10gbase-lr 10gbase-sr 10gbase-sr-sw 10gbase-sr-lw 10gbase-sr-ew 10gbase-lr-sw 10gbase-lr-lw 10gbase-lr-ew 10gbase-er-sw 10gbase-er-lw 10gbase-er-ew 10gbase-lrm-sw 10gbase-lrm-lw 10gbase-lrm-ew 2500base-sx 2500base-lx 2500base-bx) Possible values: - unknown : the sfp ethernet type is not known - 1000base-sx : gigabit ethernet compliance code - 1000base-lx : gigabit ethernet compliance code - 1000base-cx : gigabit ethernet compliance code - 1000base-t : gigabit ethernet compliance code - 100base-lx/lx10 : gigabit ethernet compliance code - 100base-fx : gigabit ethernet compliance code - base-bx10 : gigabit ethernet compliance code - base-px : gigabit ethernet compliance code - reserved : reserved bit 8 - 10gbase-ew : 10 gigabit ethernet compliance code - 10gbase-lw : 10 gigabit ethernet compliance code - 10gbase-sw : 10 gigabit ethernet compliance code - 10gbase-lrm : 10 gigabit ethernet compliance code - 10gbase-er : 10 gigabit ethernet compliance code - 10gbase-lr : 10 gigabit ethernet compliance code - 10gbase-sr : 10 gigabit ethernet compliance code - 10gbase-sr-sw : 10 gigabit ethernet compliance code - 10gbase-sr-lw : 10 gigabit ethernet compliance code - 10gbase-sr-ew : 10 gigabit ethernet compliance code - 10gbase-lr-sw : 10 gigabit ethernet compliance code - 10gbase-lr-lw : 10 gigabit ethernet compliance code - 10gbase-lr-ew : 10 gigabit ethernet compliance code - 10gbase-er-sw : 10 gigabit ethernet compliance code - 10gbase-er-lw : 10 gigabit ethernet compliance code - 10gbase-er-ew : 10 gigabit ethernet compliance code - 10gbase-lrm-sw : 10 gigabit ethernet compliance code - 10gbase-lrm-lw : 10 gigabit ethernet compliance code - 10gbase-lrm-ew : 10 gigabit ethernet compliance code - 2500base-sx : gigabit ethernet compliance code - 2500base-lx : gigabit ethernet compliance code - 2500base-bx : gigabit ethernet compliance code	

91.10 SFP/XFP Diagnostics Status Command

Command Description

This command allows the operator to read real-time diagnostic measurements from the A2 bank of a specified SFP or lower data bank of XFP. The following information is shown for each specified sfp/xfp:

- The slot index of the sfp
- The number of the sfp cage
- The diagnostics availability: For XFP, AO denotes the upper bank and A2 denotes the lower bank.
- The Loss of Signal status
- The Transmit Fault status
- The transmit power (tx-power): This parameter displays the transmit power of the SFP/XFP. It is a string that can be one of the following possible values:
 - A string containing power value ranging from "-40.00 dBm" to "8.16 dBm", in 0.01 dBm increments.
 - "No Power" - When no optical power is being transmitted by an sfp.
 - "NotApplicable" - This is used for an electrical SFP.
 - "NotAvailable" - The measurement could not be obtained.
 - "Invalid" - The calibration calculation returned an invalid result.
- The received power (rx-power): This parameter displays the received power of the SFP/XFP(not applicable for pon ports). It is a string that can be one of the following possible values:
 - A string containing power value ranging from "-40.00 dBm" to "8.16 dBm", in 0.01 dBm increments.
 - "No Power" - When no optical power is being received by an sfp.
 - "NotApplicable" - This is used for an electrical SFP.
 - "NotAvailable" - The measurement could not be obtained.
 - "Invalid" - The calibration calculation returned an invalid result.
- The transmit bias current (tx-bias-current) : This parameter displays the transmit bias current of the SFP/XFP. It is a string that can be one of the following possible values:
 - A string containing a current value ranging from "0.00 mA" to "262.00 mA", in 0.01 mA increments.
 - "NotApplicable" - This is used for an electrical SFP.
 - "NotAvailable" - The measurement could not be obtained.
 - "Invalid" - The calibration calculation returned an invalid result.
- The transceiver supply voltage (supply-voltage) : This parameter displays the transceiver supply voltage of the SFP/XFP. It is a string that can be one of the following possible values:
 - A string containing a voltage value ranging from "0.00 VDC" to "6.55 VDC", in 0.01 VDC increments.
 - "NotAvailable" - The measurement could not be obtained.
 - "Invalid" - The calibration calculation returned an invalid result.
- The temperature : This parameter displays the temperature of the SFP/XFP. It is a string that can be one of the following possible values:
 - A string containing a temperature value ranging from "-128.00 degrees Celsius" to "128.00 degrees Celsius" in 0.01 degrees Celsius increments.
 - "NotAvailable" - The measurement could not be obtained.
- temperature-tca : This parameter displays the freshly-measured temperature alarm/warning threshold crossing status of the specified SFP/SFP+/XFP. It is a string that can be one of the following possible values:
 - "not-available" - the measurement could not be obtained
 - "normal-value" - No threshold crossing, present value is within the threshold
 - "low-warning-th" - Present value is greater than the low warning level threshold
 - "low-alarm-th" - Present value is greater than the low alarm level threshold
 - "high-warning-th" - Present value is greater than the high warning level threshold
 - "high-alarm-th" - Present value is greater than the high alarm level threshold
- voltage-tca : This parameter displays the freshly-measured voltage alarm/warning threshold crossing status of the specified SFP/SFP+/XFP. It is a string that can be one of the following possible values:

- "not-available" - the measurement could not be obtained
- "normal-value" - No threshold crossing, present value is within the threshold
- "low-warning-th" - Present value is greater than the low warning level threshold
- "low-alarm-th" - Present value is greater than the low alarm level threshold
- "high-warning-th" - Present value is greater than the high warning level threshold
- "high-alarm-th" - Present value is greater than the high alarm level threshold
- *tx-power-tca* : This parameter displays the freshly-measured tx-power alarm/warning threshold crossing status of the specified SFP/SFP+/XFP. It is a string that can be one of the following possible values:
 - "not-available" - the measurement could not be obtained
 - "normal-value" - No threshold crossing, present value is within the threshold
 - "low-warning-th" - Present value is greater than the low warning level threshold
 - "low-alarm-th" - Present value is greater than the low alarm level threshold
 - "high-warning-th" - Present value is greater than the high warning level threshold
 - "high-alarm-th" - Present value is greater than the high alarm level threshold
- *bias-current-tca* : This parameter displays the freshly-measured bias-current alarm/warning threshold crossing status of the specified SFP/SFP+/XFP. It is a string that can be one of the following possible values:
 - "not-available" - the measurement could not be obtained
 - "normal-value" - No threshold crossing, present value is within the threshold
 - "low-warning-th" - Present value is greater than the low warning level threshold
 - "low-alarm-th" - Present value is greater than the low alarm level threshold
 - "high-warning-th" - Present value is greater than the high warning level threshold
 - "high-alarm-th" - Present value is greater than the high alarm level threshold
- *rx-power-tca* : This parameter displays the freshly-measured rx-power alarm/warning threshold crossing status of the specified SFP/SFP+/XFP(not applicable for pon ports). It is a string that can be one of the following possible values:
 - "not-available" - the measurement could not be obtained
 - "normal-value" - No threshold crossing, present value is within the threshold
 - "low-warning-th" - Present value is greater than the low warning level threshold
 - "low-alarm-th" - Present value is greater than the low alarm level threshold
 - "high-warning-th" - Present value is greater than the high warning level threshold
 - "high-alarm-th" - Present value is greater than the high alarm level threshold

User Level

The command can be accessed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

```
> show equipment diagnostics sfp [ (position) ]
```

Command Parameters

Table 91.10-1 "SFP/XFP Diagnostics Status Command" Resource Parameters

Resource Identifier	Type	Description
(position)	Format: (acu : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SfpCageNumber> iont : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SfpCageNumber>	the physical sfp or xfp cage position

Resource Identifier	Type	Description
	remote-sfp : <Eqpt::ExpRack> / <Eqpt::ExpShelf> : sfp : <Eqpt::SfpCageNumber> remote-sfp : <Eqpt::ExpRack> / <Eqpt::ExpShelf> : xfp : <Eqpt::SfpCageNumber> remote-sfp : <Eqpt::ExpRack> / <Eqpt::ExpShelf> : qsfp : <Eqpt::SfpCageNumber> remote-sfp : <Eqpt::ExpRack> / <Eqpt::ExpShelf> : cfp : <Eqpt::SfpCageNumber> remote-sfp : <Eqpt::ExpRack> / <Eqpt::ExpShelf> : sfp1 : <Eqpt::SfpCageNumber> remote-sfp : <Eqpt::ExpRack> / <Eqpt::ExpShelf> : sfp2 : <Eqpt::SfpCageNumber> remote-sfp : <Eqpt::ExpRack> / <Eqpt::ExpShelf> : xfp1 : <Eqpt::SfpCageNumber> remote-sfp : <Eqpt::ExpRack> / <Eqpt::ExpShelf> : xfp2 : <Eqpt::SfpCageNumber> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::EqSlotId> / <Eqpt::SfpCageNumber> nt : sfp : <Eqpt::SfpCageNumber> nt : xfp : <Eqpt::SfpCageNumber> nt : qsfp : <Eqpt::SfpCageNumber> nt : cfp : <Eqpt::SfpCageNumber> nt : sfp1 : <Eqpt::SfpCageNumber> nt : sfp2 : <Eqpt::SfpCageNumber> nt : xfp1 : <Eqpt::SfpCageNumber> nt : xfp2 : <Eqpt::SfpCageNumber> lt : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> : sfp : <Eqpt::SfpCageNumber> lt : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> : xfp : <Eqpt::SfpCageNumber> lt : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> : qsfp : <Eqpt::SfpCageNumber> lt : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> : cfp : <Eqpt::SfpCageNumber> lt : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> : sfp1 : <Eqpt::SfpCageNumber> lt : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> : sfp2 : <Eqpt::SfpCageNumber> lt : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> : xfp1 : <Eqpt::SfpCageNumber> lt : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> : xfp2 : <Eqpt::SfpCageNumber> ntio-1 : sfp : <Eqpt::SfpCageNumber> ntio-1 : xfp : <Eqpt::SfpCageNumber> ntio-1 : qsfp : <Eqpt::SfpCageNumber> ntio-1 : cfp : <Eqpt::SfpCageNumber> ntio-1 : sfp1 : <Eqpt::SfpCageNumber> ntio-1 : sfp2 : <Eqpt::SfpCageNumber> ntio-1 : xfp1 : <Eqpt::SfpCageNumber> ntio-1 : xfp2 : <Eqpt::SfpCageNumber> ntio-2 : sfp : <Eqpt::SfpCageNumber> ntio-2 : xfp : <Eqpt::SfpCageNumber> ntio-2 : qsfp : <Eqpt::SfpCageNumber> ntio-2 : cfp : <Eqpt::SfpCageNumber> ntio-2 : sfp1 : <Eqpt::SfpCageNumber> ntio-2 : sfp2 : <Eqpt::SfpCageNumber> ntio-2 : xfp1 : <Eqpt::SfpCageNumber>	

Resource Identifier	Type	Description
	ntio-2 : xfp2 : <Eqpt::SfpCageNumber> nt-a : sfp : <Eqpt::SfpCageNumber> nt-a : xfp : <Eqpt::SfpCageNumber> nt-a : qsfp : <Eqpt::SfpCageNumber> nt-a : cfp : <Eqpt::SfpCageNumber> nt-a : sfp1 : <Eqpt::SfpCageNumber> nt-a : sfp2 : <Eqpt::SfpCageNumber> nt-a : xfp1 : <Eqpt::SfpCageNumber> nt-a : xfp2 : <Eqpt::SfpCageNumber> nt-b : sfp : <Eqpt::SfpCageNumber> nt-b : xfp : <Eqpt::SfpCageNumber> nt-b : qsfp : <Eqpt::SfpCageNumber> nt-b : cfp : <Eqpt::SfpCageNumber> nt-b : sfp1 : <Eqpt::SfpCageNumber> nt-b : sfp2 : <Eqpt::SfpCageNumber> nt-b : xfp1 : <Eqpt::SfpCageNumber> nt-b : xfp2 : <Eqpt::SfpCageNumber>) Possible values: - acu : acu slot - iont : an nt applique slot - remote-sfp : remote sfp - nt : active nt slot - lt : lt-slot - ntio-1 : an nt applique slot in a single or multiple-ntio-shelf - ntio-2 : an nt applique slot in a multiple-ntio-shelf - nt-a : nt-a slot - nt-b : nt-b slot Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ExpRack> - the physical number of the expansion rack, 0 stands for no remote Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::ExpShelf> - physical nbr of expansion shelf within expansion rack, 0 stands for no remote Field type <Eqpt::EqSlotId> - the equipment slot number Field type <Eqpt::SlotId> - the LT slot number Possible values: - sfp : SFP port - xfp : XFP port - qsfp : QSFP port - cfp : CFP4 port - sfp1 : SFP port 1 - sfp2 : SFP port 2 - xfp1 : XFP port 1 - xfp2 : XFP port 2 Field type <Eqpt::SfpCageNumber> - the SFP cage number - range: [0...2304]	

Command Output

Table 91.10-2 "SFP/XFP Diagnostics Status Command" Display parameters

Specific Information		
name	Type	Description
diag-avail-status	Parameter type: <Eqpt::SfpDiagAvailable> (no-error cage-no-diag-supp cage-empty cage-no-a2-supp a0-read-failed a0-checksum-failed sfp-no-a2-supp a2-read-failed a2-checksum-failed optics-present) Possible values: - no-error : sfp diag is available - cage-no-diag-supp : cage does not support diag - cage-empty : cage is empty - cage-no-a2-supp : cage does not support A2 - a0-read-failed : A0 read failed - a0-checksum-failed : A0 checksum failed - sfp-no-a2-supp : SFP does not support A2 - a2-read-failed : A2 read failed - a2-checksum-failed : A2 checksum failed - optics-present : SFP/XFS inserted into cage	sfp/xfp diagnostics availability status. for xfp, a0 denotes the upper bank and a2 denotes the lower bank <i>This element is always shown.</i>
los	Parameter type: <PrintableString> - printable string	loss of signal <i>This element is always shown.</i>
tx-fault	Parameter type: <Eqpt::SfpDiagTxFault> (tx-fault no-tx-fault not-applicable not-available) Possible values: - tx-fault : transmit fault info - no-tx-fault : no tx fault - not-applicable : not applicable - not-available : not available	sfp/xfp tx fault <i>This element is always shown.</i>
tx-power	Parameter type: <PrintableString> - printable string	the transmit power. <i>This element is only shown in detail mode.</i>
rx-power	Parameter type: <PrintableString> - printable string	the received power - not applicable for PON ports <i>This element is only shown in detail mode.</i>
tx-bias-current	Parameter type: <PrintableString> - printable string	the transmit bias current. <i>This element is only shown in detail mode.</i>
supply-voltage	Parameter type: <PrintableString> - printable string	the transceiver supply voltage. <i>This element is only shown in detail mode.</i>
temperature	Parameter type: <PrintableString> - printable string	the temperature. <i>This element is only shown in detail mode.</i>
temperature-tca	Parameter type: <Eqpt::Tca> (high-alarm-th low-alarm-th high-warning-th	the temperature alarm or warning <i>This element is only shown in detail mode.</i>

91 Equipment Status Commands

name	Type	Description
	low-warning-th normal-value not-available) Possible values: - high-alarm-th : Present value is greater than the configured/pre-set alarm value - low-alarm-th : Present value is lower than the configured/pre-set alarm value - high-warning-th : Present value is greater than the configured/pre-set warning value - low-warning-th : Present value is lower than the configured/pre-set warning value - normal-value : Present value is under normal limits - not-available : Value is not available	
voltage-tca	Parameter type: <Eqpt::Tca> (high-alarm-th low-alarm-th high-warning-th low-warning-th normal-value not-available) Possible values: - high-alarm-th : Present value is greater than the configured/pre-set alarm value - low-alarm-th : Present value is lower than the configured/pre-set alarm value - high-warning-th : Present value is greater than the configured/pre-set warning value - low-warning-th : Present value is lower than the configured/pre-set warning value - normal-value : Present value is under normal limits - not-available : Value is not available	the voltage alarm or warning <i>This element is only shown in detail mode.</i>
bias-current-tca	Parameter type: <Eqpt::Tca> (high-alarm-th low-alarm-th high-warning-th low-warning-th normal-value not-available) Possible values: - high-alarm-th : Present value is greater than the configured/pre-set alarm value - low-alarm-th : Present value is lower than the configured/pre-set alarm value - high-warning-th : Present value is greater than the configured/pre-set warning value - low-warning-th : Present value is lower than the configured/pre-set warning value - normal-value : Present value is under normal limits - not-available : Value is not available	the bias-current alarm or warning <i>This element is only shown in detail mode.</i>
tx-power-tca	Parameter type: <Eqpt::Tca> (high-alarm-th low-alarm-th high-warning-th low-warning-th normal-value not-available)	the temperature alarm or warning <i>This element is only shown in detail mode.</i>

name	Type	Description
	Possible values: - high-alarm-th : Present value is greater than the configured/pre-set alarm value - low-alarm-th : Present value is lower than the configured/pre-set alarm value - high-warning-th : Present value is greater than the configured/pre-set warning value - low-warning-th : Present value is lower than the configured/pre-set warning value - normal-value : Present value is under normal limits - not-available : Value is not available	
rx-power-tca	Parameter type: <Eqpt::Tca> (high-alarm-th low-alarm-th high-warning-th low-warning-th normal-value not-available) Possible values: - high-alarm-th : Present value is greater than the configured/pre-set alarm value - low-alarm-th : Present value is lower than the configured/pre-set alarm value - high-warning-th : Present value is greater than the configured/pre-set warning value - low-warning-th : Present value is lower than the configured/pre-set warning value - normal-value : Present value is under normal limits - not-available : Value is not available	the temperature alarm or warning-not applicable for PON ports <i>This element is only shown in detail mode.</i>
rsi-profile-id	Parameter type: <Eqpt::RssiShowProfileIndex> - an unique index value for the rsi profile(1-200 user-defined , 65535 - automode) - range: [1...65535]	an unique index of the rsi profile <i>This element is always shown.</i>
rsi-state	Parameter type: <Eqpt::RssiState> ((enable yes) (disable no)) Possible values: - enable : enable rsi functionality - yes : enable rsi functionality - disable : disable rsi functionality - no : disable rsi functionality	to enable or disable the rsi functionality on sfps for uplink ports <i>This element is always shown.</i>

91.11 SFP/XFP Diagnostics Status Command

Command Description

This command allows the operator to read real-time diagnostic measurements from the A2 bank of a specified SFP or lower data bank of XFP. The following information is shown for each specified sfp/xfp:

- The slot index of the sfp
- The number of the sfp cage
- The diagnostics availability: For XFP, AO denotes the upper bank and A2 denotes the lower bank.
- The Loss of Signal status
- The Transmit Fault status
- The transmit power (tx-power): This parameter displays the transmit power of the SFP/XFP. It is a string that can be one of the following possible values:
 - A string containing power value ranging from "-40.00 dBm" to "8.16 dBm", in 0.01 dBm increments.
 - "No Power" - When no optical power is being transmitted by an sfp.
 - "NotApplicable" - This is used for an electrical SFP.
 - "NotAvailable" - The measurement could not be obtained.
 - "Invalid" - The calibration calculation returned an invalid result.
- The received power (rx-power): This parameter displays the received power of the SFP/XFP(not applicable for pon ports). It is a string that can be one of the following possible values:
 - A string containing power value ranging from "-40.00 dBm" to "8.16 dBm", in 0.01 dBm increments.
 - "No Power" - When no optical power is being received by an sfp.
 - "NotApplicable" - This is used for an electrical SFP.
 - "NotAvailable" - The measurement could not be obtained.
 - "Invalid" - The calibration calculation returned an invalid result.
- The transmit bias current (tx-bias-current) : This parameter displays the transmit bias current of the SFP/XFP. It is a string that can be one of the following possible values:
 - A string containing a current value ranging from "0.00 mA" to "262.00 mA", in 0.01 mA increments.
 - "NotApplicable" - This is used for an electrical SFP.
 - "NotAvailable" - The measurement could not be obtained.
 - "Invalid" - The calibration calculation returned an invalid result.
- The transceiver supply voltage (supply-voltage) : This parameter displays the transceiver supply voltage of the SFP/XFP. It is a string that can be one of the following possible values:
 - A string containing a voltage value ranging from "0.00 VDC" to "6.55 VDC", in 0.01 VDC increments.
 - "NotAvailable" - The measurement could not be obtained.
 - "Invalid" - The calibration calculation returned an invalid result.
- The temperature : This parameter displays the temperature of the SFP/XFP. It is a string that can be one of the following possible values:
 - A string containing a temperature value ranging from "-128.00 degrees Celsius" to "128.00 degrees Celsius" in 0.01 degrees Celsius increments.
 - "NotAvailable" - The measurement could not be obtained.
- temperature-tca : This parameter displays the freshly-measured temperature alarm/warning threshold crossing status of the specified SFP/SFP+/XFP. It is a string that can be one of the following possible values:
 - "not-available" - the measurement could not be obtained
 - "normal-value" - No threshold crossing, present value is within the threshold
 - "low-warning-th" - Present value is greater than the low warning level threshold
 - "low-alarm-th" - Present value is greater than the low alarm level threshold
 - "high-warning-th" - Present value is greater than the high warning level threshold
 - "high-alarm-th" - Present value is greater than the high alarm level threshold
- voltage-tca : This parameter displays the freshly-measured voltage alarm/warning threshold crossing status of the specified SFP/SFP+/XFP. It is a string that can be one of the following possible values:

- "not-available" - the measurement could not be obtained
 - "normal-value" - No threshold crossing, present value is within the threshold
 - "low-warning-th" - Present value is greater than the low warning level threshold
 - "low-alarm-th" - Present value is greater than the low alarm level threshold
 - "high-warning-th" - Present value is greater than the high warning level threshold
 - "high-alarm-th" - Present value is greater than the high alarm level threshold
- *tx-power-tca* : This parameter displays the freshly-measured tx-power alarm/warning threshold crossing status of the specified SFP/SFP+/XFP. It is a string that can be one of the following possible values:
 - "not-available" - the measurement could not be obtained
 - "normal-value" - No threshold crossing, present value is within the threshold
 - "low-warning-th" - Present value is greater than the low warning level threshold
 - "low-alarm-th" - Present value is greater than the low alarm level threshold
 - "high-warning-th" - Present value is greater than the high warning level threshold
 - "high-alarm-th" - Present value is greater than the high alarm level threshold
 - *bias-current-tca* : This parameter displays the freshly-measured bias-current alarm/warning threshold crossing status of the specified SFP/SFP+/XFP. It is a string that can be one of the following possible values:
 - "not-available" - the measurement could not be obtained
 - "normal-value" - No threshold crossing, present value is within the threshold
 - "low-warning-th" - Present value is greater than the low warning level threshold
 - "low-alarm-th" - Present value is greater than the low alarm level threshold
 - "high-warning-th" - Present value is greater than the high warning level threshold
 - "high-alarm-th" - Present value is greater than the high alarm level threshold
 - *rx-power-tca* : This parameter displays the freshly-measured rx-power alarm/warning threshold crossing status of the specified SFP/SFP+/XFP(not applicable for pon ports). It is a string that can be one of the following possible values:
 - "not-available" - the measurement could not be obtained
 - "normal-value" - No threshold crossing, present value is within the threshold
 - "low-warning-th" - Present value is greater than the low warning level threshold
 - "low-alarm-th" - Present value is greater than the low alarm level threshold
 - "high-warning-th" - Present value is greater than the high warning level threshold
 - "high-alarm-th" - Present value is greater than the high alarm level threshold

User Level

The command can be accessed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

```
> show equipment diagnostics sfp-threshold [ (position) ]
```

Command Parameters

Table 91.11-1 "SFP/XFP Diagnostics Status Command" Resource Parameters

Resource Identifier	Type	Description
(position)	Format: (acu : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SfpCageNumber> iont : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SfpCageNumber>	the physical sfp or xfp cage position

Resource Identifier	Type	Description
	remote-sfp : <Eqpt::ExpRack> / <Eqpt::ExpShelf> : sfp : <Eqpt::SfpCageNumber> remote-sfp : <Eqpt::ExpRack> / <Eqpt::ExpShelf> : xfp : <Eqpt::SfpCageNumber> remote-sfp : <Eqpt::ExpRack> / <Eqpt::ExpShelf> : qsfp : <Eqpt::SfpCageNumber> remote-sfp : <Eqpt::ExpRack> / <Eqpt::ExpShelf> : cfp : <Eqpt::SfpCageNumber> remote-sfp : <Eqpt::ExpRack> / <Eqpt::ExpShelf> : sfp1 : <Eqpt::SfpCageNumber> remote-sfp : <Eqpt::ExpRack> / <Eqpt::ExpShelf> : sfp2 : <Eqpt::SfpCageNumber> remote-sfp : <Eqpt::ExpRack> / <Eqpt::ExpShelf> : xfp1 : <Eqpt::SfpCageNumber> remote-sfp : <Eqpt::ExpRack> / <Eqpt::ExpShelf> : xfp2 : <Eqpt::SfpCageNumber> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::EqSlotId> / <Eqpt::SfpCageNumber> nt : sfp : <Eqpt::SfpCageNumber> nt : xfp : <Eqpt::SfpCageNumber> nt : qsfp : <Eqpt::SfpCageNumber> nt : cfp : <Eqpt::SfpCageNumber> nt : sfp1 : <Eqpt::SfpCageNumber> nt : sfp2 : <Eqpt::SfpCageNumber> nt : xfp1 : <Eqpt::SfpCageNumber> nt : xfp2 : <Eqpt::SfpCageNumber> lt : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> : sfp : <Eqpt::SfpCageNumber> lt : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> : xfp : <Eqpt::SfpCageNumber> lt : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> : qsfp : <Eqpt::SfpCageNumber> lt : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> : cfp : <Eqpt::SfpCageNumber> lt : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> : sfp1 : <Eqpt::SfpCageNumber> lt : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> : sfp2 : <Eqpt::SfpCageNumber> lt : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> : xfp1 : <Eqpt::SfpCageNumber> lt : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> : xfp2 : <Eqpt::SfpCageNumber> ntio-1 : sfp : <Eqpt::SfpCageNumber> ntio-1 : xfp : <Eqpt::SfpCageNumber> ntio-1 : qsfp : <Eqpt::SfpCageNumber> ntio-1 : cfp : <Eqpt::SfpCageNumber> ntio-1 : sfp1 : <Eqpt::SfpCageNumber> ntio-1 : sfp2 : <Eqpt::SfpCageNumber> ntio-1 : xfp1 : <Eqpt::SfpCageNumber> ntio-1 : xfp2 : <Eqpt::SfpCageNumber> ntio-2 : sfp : <Eqpt::SfpCageNumber> ntio-2 : xfp : <Eqpt::SfpCageNumber> ntio-2 : qsfp : <Eqpt::SfpCageNumber> ntio-2 : cfp : <Eqpt::SfpCageNumber> ntio-2 : sfp1 : <Eqpt::SfpCageNumber> ntio-2 : sfp2 : <Eqpt::SfpCageNumber> ntio-2 : xfp1 : <Eqpt::SfpCageNumber>	

Resource Identifier	Type	Description
	ntio-2 : xfp2 : <Eqpt::SfpCageNumber> nt-a : sfp : <Eqpt::SfpCageNumber> nt-a : xfp : <Eqpt::SfpCageNumber> nt-a : qsfp : <Eqpt::SfpCageNumber> nt-a : cfp : <Eqpt::SfpCageNumber> nt-a : sfp1 : <Eqpt::SfpCageNumber> nt-a : sfp2 : <Eqpt::SfpCageNumber> nt-a : xfp1 : <Eqpt::SfpCageNumber> nt-a : xfp2 : <Eqpt::SfpCageNumber> nt-b : sfp : <Eqpt::SfpCageNumber> nt-b : xfp : <Eqpt::SfpCageNumber> nt-b : qsfp : <Eqpt::SfpCageNumber> nt-b : cfp : <Eqpt::SfpCageNumber> nt-b : sfp1 : <Eqpt::SfpCageNumber> nt-b : sfp2 : <Eqpt::SfpCageNumber> nt-b : xfp1 : <Eqpt::SfpCageNumber> nt-b : xfp2 : <Eqpt::SfpCageNumber>) Possible values: - acu : acu slot - iont : an nt applique slot - remote-sfp : remote sfp - nt : active nt slot - lt : lt-slot - ntio-1 : an nt applique slot in a single or multiple-ntio-shelf - ntio-2 : an nt applique slot in a multiple-ntio-shelf - nt-a : nt-a slot - nt-b : nt-b slot Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ExpRack> - the physical number of the expansion rack, 0 stands for no remote Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::ExpShelf> - physical nbr of expansion shelf within expansion rack, 0 stands for no remote Field type <Eqpt::EqSlotId> - the equipment slot number Field type <Eqpt::SlotId> - the LT slot number Possible values: - sfp : SFP port - xfp : XFP port - qsfp : QSFP port - cfp : CFP4 port - sfp1 : SFP port 1 - sfp2 : SFP port 2 - xfp1 : XFP port 1 - xfp2 : XFP port 2 Field type <Eqpt::SfpCageNumber> - the SFP cage number - range: [0...2304]	

Command Output

Table 91.11-2 "SFP/XFP Diagnostics Status Command" Display parameters

Specific Information		
name	Type	Description
rx-pwr-alm-low	Parameter type: <PrintableString> - printable string	alarm low threshold for Rx power <i>This element is always shown.</i>
rx-pwr-alm-high	Parameter type: <PrintableString> - printable string	alarm high threshold for Rx power <i>This element is always shown.</i>
rx-pwr-warn-low	Parameter type: <PrintableString> - printable string	warn low threshold for Rx power <i>This element is only shown in detail mode.</i>
rx-pwr-warn-high	Parameter type: <PrintableString> - printable string	warn high threshold for Rx power <i>This element is only shown in detail mode.</i>
tx-pwr-alm-low	Parameter type: <PrintableString> - printable string	alarm low threshold for Tx power <i>This element is always shown.</i>
tx-pwr-alm-high	Parameter type: <PrintableString> - printable string	alarm high threshold for Tx power <i>This element is always shown.</i>
tx-pwr-warn-low	Parameter type: <PrintableString> - printable string	warn low threshold for Tx power <i>This element is only shown in detail mode.</i>
tx-pwr-warn-high	Parameter type: <PrintableString> - printable string	warn high threshold for Tx power <i>This element is only shown in detail mode.</i>
temp-alm-low	Parameter type: <PrintableString> - printable string	alarm low threshold for temperature <i>This element is only shown in detail mode.</i>
temp-alm-high	Parameter type: <PrintableString> - printable string	alarm high threshold for temperature <i>This element is only shown in detail mode.</i>
temp-warn-low	Parameter type: <PrintableString> - printable string	warn low threshold for temperature <i>This element is only shown in detail mode.</i>
temp-warn-high	Parameter type: <PrintableString> - printable string	warn high threshold for temperature <i>This element is only shown in detail mode.</i>
bias-alm-low	Parameter type: <PrintableString> - printable string	alarm low threshold for bias <i>This element is only shown in detail mode.</i>
bias-alm-high	Parameter type: <PrintableString> - printable string	alarm high threshold for bias <i>This element is only shown in detail mode.</i>
bias-warn-low	Parameter type: <PrintableString> - printable string	warn low threshold for bias <i>This element is only shown in detail mode.</i>
bias-warn-high	Parameter type: <PrintableString> - printable string	warn high threshold for bias <i>This element is only shown in detail mode.</i>
voltage-alm-low	Parameter type: <PrintableString> - printable string	alarm low threshold for Voltage <i>This element is only shown in detail mode.</i>
voltage-alm-high	Parameter type: <PrintableString>	alarm high threshold for Voltage

name	Type	Description
	- printable string	<i>This element is only shown in detail mode.</i>
voltage-warn-low	Parameter type: <PrintableString> - printable string	warn low threshold for Voltage <i>This element is only shown in detail mode.</i>
voltage-warn-high	Parameter type: <PrintableString> - printable string	warn high threshold for Voltage <i>This element is only shown in detail mode.</i>
erx-alm-low	Parameter type: <PrintableString> - printable string	alarm low threshold for ext Rx power <i>This element is only shown in detail mode.</i>
erx-alm-high	Parameter type: <PrintableString> - printable string	alarm high threshold for ext Rx power <i>This element is only shown in detail mode.</i>
erx-warn-low	Parameter type: <PrintableString> - printable string	warn low threshold for ext Rx power <i>This element is only shown in detail mode.</i>
erx-warn-high	Parameter type: <PrintableString> - printable string	warn high threshold for ext Rx power <i>This element is only shown in detail mode.</i>
etx-alm-low	Parameter type: <PrintableString> - printable string	alarm low threshold for ext Tx power <i>This element is only shown in detail mode.</i>
etx-alm-high	Parameter type: <PrintableString> - printable string	alarm high threshold for ext Tx power <i>This element is only shown in detail mode.</i>
etx-warn-low	Parameter type: <PrintableString> - printable string	warn low threshold for ext Tx power <i>This element is only shown in detail mode.</i>
etx-warn-high	Parameter type: <PrintableString> - printable string	warn high threshold for ext Tx power <i>This element is only shown in detail mode.</i>
ebias-alm-low	Parameter type: <PrintableString> - printable string	alarm low threshold for ext bias <i>This element is only shown in detail mode.</i>
ebias-alm-high	Parameter type: <PrintableString> - printable string	alarm high threshold for ext bias <i>This element is only shown in detail mode.</i>
ebias-warn-low	Parameter type: <PrintableString> - printable string	warn low threshold for ext bias <i>This element is only shown in detail mode.</i>
ebias-warn-high	Parameter type: <PrintableString> - printable string	warn high threshold for ext bias <i>This element is only shown in detail mode.</i>
etemp-alm-low	Parameter type: <PrintableString> - printable string	alarm low threshold for ext temp <i>This element is only shown in detail mode.</i>
etemp-alm-high	Parameter type: <PrintableString> - printable string	alarm high threshold for ext temp <i>This element is only shown in detail mode.</i>

91 Equipment Status Commands

name	Type	Description
		<i>detail mode.</i>
etemp-warn-low	Parameter type: <PrintableString> - printable string	warn low threshold for ext temp <i>This element is only shown in detail mode.</i>
etemp-warn-high	Parameter type: <PrintableString> - printable string	warn high threshold for ext temp <i>This element is only shown in detail mode.</i>

91.12 Sfp RSSI Configuration Command

Command Description

This command allows the operator to create and configure the RSSI parameters on SFPs.

User Level

The command can be accessed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

> show equipment rssiprof [(index)]

Command Parameters

Table 91.12-1 "Sfp RSSI Configuration Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - an unique index value for the rssi profile(1-200:userdefined,65535:automode) - range: [1...200,65535]	an unique index of the rssi profile

Command Output

Table 91.12-2 "Sfp RSSI Configuration Command" Display parameters

Specific Information		
name	Type	Description
name	Parameter type: <Eqpt::DisplayString> - string to identify the rssi profile - length: 1<=x<=16	A unique profile name <i>This element is always shown.</i>
ref-count	Parameter type: <Eqpt::rssiRefCount> - number of entities using this particular profile - range: [0...65535]	rssi profile reference count <i>This element is always shown.</i>

91.13 Board Temperature Status Command

Command Description

This command shows the board temperature status. The following information is shown for each thermal sensor:

- *act-temp* : actual temperature of thermal sensor; expressed in degrees Celsius.
- *tca-low*: low thresholds for the alarm "Temperature Exceeded"; expressed in degrees Celsius.
- *tca-high*: high thresholds for the alarm "Temperature Exceeded"; expressed in degrees Celsius.
- *shut-low*: low threshold for the alarm "Temperature Shutdown"; expressed in degrees Celsius.
- *shut-high*: high threshold for the alarm "Temperature Shutdown"; expressed in degrees Celsius.

User Level

The command can be accessed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

```
> show equipment temperature [ (slot) [ sensor-id <Equipm::SensorId> ] ]
```

Command Parameters

Table 91.13-1 "Board Temperature Status Command" Resource Parameters

Resource Identifier	Type	Description
(slot)	Format: (lt : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> nt-a nt-b nt iont : <Eqpt::RackId> / <Eqpt::ShelfId> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::EqSlotId> ctrl : <Eqpt::RackId> / <Eqpt::ShelfId> ntio-1 ntio-2) Possible values: - lt : lt-slot - nt-a : nt-a slot - nt-b : nt-b slot - nt : nt slot - iont : an nt applique slot - ctrl : ctrl-slot - ntio-1 : an nt applique slot in a single or multiple-ntio-shelf - ntio-2 : an nt applique slot in a multiple-ntio-shelf Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId>	the physical slot position

Resource Identifier	Type	Description
	- the LT slot number Field type <Eqpt::EqSlotId> - the equipment slot number	
sensor-id	Parameter type: <Equipm::SensorId> Format: - the sensor id of a board - range: [1...15]	the sensor id of a board

Command Output

Table 91.13-2 "Board Temperature Status Command" Display parameters

Specific Information		
name	Type	Description
actual-temperature short name: act-temp	Parameter type: <SignedInteger> - a signed integer	actual temperature of thermal sensor; expressed in degrees Celsius. <i>This element is always shown.</i>
tca-threshold-low short name: tca-low	Parameter type: <SignedInteger> - a signed integer	Low thresholds for the alarm "Temperature Exceeded"; expressed in degrees Celsius. <i>This element is always shown.</i>
tca-threshold-high short name: tca-high	Parameter type: <SignedInteger> - a signed integer	High thresholds for the alarm "Temperature Exceeded"; expressed in degrees Celsius. <i>This element is always shown.</i>
shut-threshold-low short name: shut-low	Parameter type: <SignedInteger> - a signed integer	Low threshold for the alarm "Temperature Shutdown"; expressed in degrees Celsius. <i>This element is always shown.</i>
shut-threshold-high short name: shut-high	Parameter type: <SignedInteger> - a signed integer	High threshold for the alarm "Temperature Shutdown"; expressed in degrees Celsius. <i>This element is always shown.</i>

91.14 Board Planned Resource Command

Command Description

This commands shows the actual values of configured hardware resources on boards.. The following information is shown for each resource:

- *current*: The actual planned value for the resource
- *max-value*: The maximum value that the board supports for this resource.
- *description*: A string describing the planned resource for this board.

User Level

The command can be accessed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

```
> show equipment planned-resource [ (slot) [ resource-id <SignedInteger> ] ]
```

Command Parameters

Table 91.14-1 "Board Planned Resource Command" Resource Parameters

Resource Identifier	Type	Description
(slot)	Format: lt : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> Possible values: - lt : lt-slot Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number	the physical slot position
resource-id	Parameter type: <SignedInteger> Format: - a signed integer	the planned resource id of a board

Command Output

Table 91.14-2 "Board Planned Resource Command" Display parameters

Specific Information		
name	Type	Description
current-value short name: cur-val	Parameter type: <SignedInteger> - a signed integer	The actual planned value for the resource. <i>This element is always shown.</i>
maximum-value	Parameter type: <SignedInteger>	The maximum value that the

91 Equipment Status Commands

name	Type	Description
short name: max-val	- a signed integer	board supports for this resource. <i>This element is always shown.</i>
description short name: description	Parameter type: <PrintableString> - printable string	A string describing the planned resource for this board. <i>This element is always shown.</i>

91.15 Transceiver Inventory Status Command

Command Description

This command retrieves the configuration data associated with SFP/SFP+/XFP. The following information is shown for each specified sfp/sfp+/xfp:

- For the following data, output "not-Available" implies that the the measurement could not be obtained.
- *inventory-status* - the transceiver inventory status. For XFP, AO denotes the upper bank and A2 denotes the lower bank.
- *nokia-part-num* - the nokia part number available in sfp or xfp eeprom
- *clei-code* - the clei code available in sfp or xfp eeprom
- *tx-wavelength* - the transmission wavelength available in sfp or xfp eeprom
- *fiber-type* - the fiber type available in sfp or xfp eeprom
- *additional-info* - the customer specific additional information of the specified sfp or sfp+ or xfp
- *mfg-name* - the manufacturer name available in sfp or xfp eeprom
- *mfg-oui* - the manufacturer code available in sfp or xfp eeprom
- *mfg-date* - the manufacturer date available in sfp or xfp eeprom
- *vendor-serial-num* - the vendor serial number available in sfp or xfp eeprom

User Level

The command can be accessed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

```
> show equipment transceiver-inventory [ (index) ]
```

Command Parameters

Table 91.15-1 "Transceiver Inventory Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: (acu : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SfpCageNumber> iont : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SfpCageNumber> remote-sfp : <Eqpt::ExpRack> / <Eqpt::ExpShelf> : sfp : <Eqpt::SfpCageNumber> remote-sfp : <Eqpt::ExpRack> / <Eqpt::ExpShelf> : xfp : <Eqpt::SfpCageNumber> remote-sfp : <Eqpt::ExpRack> / <Eqpt::ExpShelf> : qsfp : <Eqpt::SfpCageNumber> remote-sfp : <Eqpt::ExpRack> / <Eqpt::ExpShelf> : cfp : <Eqpt::SfpCageNumber> remote-sfp : <Eqpt::ExpRack> / <Eqpt::ExpShelf> : sfp1 : <Eqpt::SfpCageNumber> remote-sfp : <Eqpt::ExpRack> / <Eqpt::ExpShelf> : sfp2 :	the physical sfp or xfp cage position

Resource Identifier	Type	Description
	<code><Eqpt::SfpCageNumber></code> <code> remote-sfp : <Eqpt::ExpRack> / <Eqpt::ExpShelf> : xfp1 : <Eqpt::SfpCageNumber></code> <code> remote-sfp : <Eqpt::ExpRack> / <Eqpt::ExpShelf> : xfp2 : <Eqpt::SfpCageNumber></code> <code> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::EqSlotId> / <Eqpt::SfpCageNumber></code> <code> nt : sfp : <Eqpt::SfpCageNumber></code> <code> nt : xfp : <Eqpt::SfpCageNumber></code> <code> nt : qsfp : <Eqpt::SfpCageNumber></code> <code> nt : cfp : <Eqpt::SfpCageNumber></code> <code> nt : sfp1 : <Eqpt::SfpCageNumber></code> <code> nt : sfp2 : <Eqpt::SfpCageNumber></code> <code> nt : xfp1 : <Eqpt::SfpCageNumber></code> <code> nt : xfp2 : <Eqpt::SfpCageNumber></code> <code> lt : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> : sfp : <Eqpt::SfpCageNumber></code> <code> lt : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> : xfp : <Eqpt::SfpCageNumber></code> <code> lt : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> : qsfp : <Eqpt::SfpCageNumber></code> <code> lt : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> : cfp : <Eqpt::SfpCageNumber></code> <code> lt : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> : sfp1 : <Eqpt::SfpCageNumber></code> <code> lt : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> : sfp2 : <Eqpt::SfpCageNumber></code> <code> lt : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> : xfp1 : <Eqpt::SfpCageNumber></code> <code> lt : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> : xfp2 : <Eqpt::SfpCageNumber></code> <code> ntio-1 : sfp : <Eqpt::SfpCageNumber></code> <code> ntio-1 : xfp : <Eqpt::SfpCageNumber></code> <code> ntio-1 : qsfp : <Eqpt::SfpCageNumber></code> <code> ntio-1 : cfp : <Eqpt::SfpCageNumber></code> <code> ntio-1 : sfp1 : <Eqpt::SfpCageNumber></code> <code> ntio-1 : sfp2 : <Eqpt::SfpCageNumber></code> <code> ntio-1 : xfp1 : <Eqpt::SfpCageNumber></code> <code> ntio-1 : xfp2 : <Eqpt::SfpCageNumber></code> <code> ntio-2 : sfp : <Eqpt::SfpCageNumber></code> <code> ntio-2 : xfp : <Eqpt::SfpCageNumber></code> <code> ntio-2 : qsfp : <Eqpt::SfpCageNumber></code> <code> ntio-2 : cfp : <Eqpt::SfpCageNumber></code> <code> ntio-2 : sfp1 : <Eqpt::SfpCageNumber></code> <code> ntio-2 : sfp2 : <Eqpt::SfpCageNumber></code> <code> ntio-2 : xfp1 : <Eqpt::SfpCageNumber></code> <code> ntio-2 : xfp2 : <Eqpt::SfpCageNumber></code> <code> nt-a : sfp : <Eqpt::SfpCageNumber></code> <code> nt-a : xfp : <Eqpt::SfpCageNumber></code> <code> nt-a : qsfp : <Eqpt::SfpCageNumber></code> <code> nt-a : cfp : <Eqpt::SfpCageNumber></code> <code> nt-a : sfp1 : <Eqpt::SfpCageNumber></code> <code> nt-a : sfp2 : <Eqpt::SfpCageNumber></code> <code> nt-a : xfp1 : <Eqpt::SfpCageNumber></code> <code> nt-a : xfp2 : <Eqpt::SfpCageNumber></code> <code> nt-b : sfp : <Eqpt::SfpCageNumber></code> <code> nt-b : xfp : <Eqpt::SfpCageNumber></code>	

Resource Identifier	Type	Description
	nt-b : qsfp : <Eqpt::SfpCageNumber> nt-b : cfp : <Eqpt::SfpCageNumber> nt-b : sfp1 : <Eqpt::SfpCageNumber> nt-b : sfp2 : <Eqpt::SfpCageNumber> nt-b : xfp1 : <Eqpt::SfpCageNumber> nt-b : xfp2 : <Eqpt::SfpCageNumber>) Possible values: - acu : acu slot - iont : an nt applique slot - remote-sfp : remote sfp - nt : active nt slot - lt : lt-slot - ntio-1 : an nt applique slot in a single or multiple-ntio-shelf - ntio-2 : an nt applique slot in a multiple-ntio-shelf - nt-a : nt-a slot - nt-b : nt-b slot Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ExpRack> - the physical number of the expansion rack, 0 stands for no remote Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::ExpShelf> - physical nbr of expansion shelf within expansion rack, 0 stands for no remote Field type <Eqpt::EqSlotId> - the equipment slot number Field type <Eqpt::SlotId> - the LT slot number Possible values: - sfp : SFP port - xfp : XFP port - qsfp : QSFP port - cfp : CFP4 port - sfp1 : SFP port 1 - sfp2 : SFP port 2 - xfp1 : XFP port 1 - xfp2 : XFP port 2 Field type <Eqpt::SfpCageNumber> - the SFP cage number - range: [0...2304]	

Command Output

Table 91.15-2 "Transceiver Inventory Status Command" Display parameters

Specific Information		
name	Type	Description
inventory-status	Parameter type: <Eqpt::InvStatus> (no-error cage-empty cage-no-a2-supp a0-read-failed a0-checksum-failed sfp-no-a2-supp a2-read-failed	transceiver inventory status. for xfp, a0 denotes the upper bank and a2 denotes the lower bank <i>This element is always shown.</i>

name	Type	Description
	a2-checksum-failed optics-present) Possible values: - no-error : sfp inventory is available - cage-empty : cage is empty - cage-no-a2-suppl : cage does not support A2 - a0-read-failed : A0 read failed - a0-checksum-failed : A0 checksum failed - sfp-no-a2-suppl : SFP does not support A2 - a2-read-failed : A2 read failed - a2-checksum-failed : A2 checksum failed - optics-present : SFP/XFS inserted into cage	
nokia-part-num	Parameter type: <PrintableString> - printable string	the nokia part number available in sfp or xfp eeprom <i>This element is always shown.</i>
clei-code	Parameter type: <PrintableString> - printable string	the clei code available in sfp or xfp eeprom <i>This element is only shown in detail mode.</i>
tx-wavelength	Parameter type: <PrintableString> - printable string	the transmission wavelength available in sfp or xfp eeprom <i>This element is always shown.</i>
fiber-type	Parameter type: <Eqpt::FiberType> (single-mode multi-mode not-available) Possible values: - single-mode : single-mode fiber - multi-mode : multi-mode - not-available : fiber type is not available	the fiber type available in sfp or xfp eeprom. <i>This element is always shown.</i>
mfg-name	Parameter type: <PrintableString> - printable string	the manufacturer name available in sfp or xfp eeprom <i>This element is only shown in detail mode.</i>
mfg-oui	Parameter type: <PrintableString> - printable string	the manufacturer code available in sfp or xfp eeprom <i>This element is only shown in detail mode.</i>
mfg-date	Parameter type: <PrintableString> - printable string	the manufacturer date in dd/mm/yyyy format available in sfp or xfp eeprom <i>This element is only shown in detail mode.</i>
vendor-serial-num	Parameter type: <PrintableString> - printable string	the vendor serial number available in sfp or xfp eeprom <i>This element is only shown in detail mode.</i>
additional-info	Parameter type: <PrintableString> - printable string	the customer specific additional information of the specified sfp or sfp+ or xfp <i>This element is only shown in detail mode.</i>
rssf-sfptype	Parameter type: <Eqpt::RssfSfpType> (not-available px20 px20plus prx_t1	sfp type of ports wch configured rssf profile <i>This element is always shown.</i>

91 Equipment Status Commands

name	Type	Description
	pr_t2	
	prx_t3	
	pr_t4	
	bplusc	
	bplusi	
	bplusi_onu	
	cplusc	
	cplusi	
	e1t1_eth	
	e3ds3_eth	
	stm1oc3_eth	
	e1t1_tdm	
	100base_fx	
	100base_lx	
	100base_bx10u	
	100base_bx10d	
	100base_tx	
	1000base_t	
	1000base_cx	
	1000base_sx	
	1000base_lx	
	1000base_bx10u	
	1000base_bx10d	
	1000base_bx40u	
	1000base_bx40d	
	1000base_ex	
	1000base_zx	
	n1_c	
	n2a_c	
	n2b_c	
	1000base_vx	
	2500base	
	10gbase_sr	
	10gbase_lr	
	10gbase_lrm	
	10gbase_er	
	10gbase_sw	
	10gbase_lw	
	10gbase_ew	
	40gbase_sr4	
	40gbase_lr4	
	40gbase_cr4	
	10gbase_bx40u	
	10gbase_bx40d	
	10gbase_zrcwdm	
	10gbase_zrdwdm	
	1000base_bx20u	
	1000base_bx20d	
	n1_i	
	n2a_i	
	n2b_i	
	100gbase_lr4	
	100gbase_sr4	
	10gbase_bx10u	
	10gbase_bx10d	
	1000base_zrcwdm	
	10gbase_zr	

name	Type	Description
	<pre> 10gbase_bx80u 10gbase_bx80d 1000base_bx80u 1000base_bx80d 100gbase_er4 cplusplusi 10gbase_t 10gbase_bx60u 10gbase_bx60d 2500base_bx40u 2500base_bx40d e1-i 1000base_ezx n2a_cplus_c 40gbase_psm4_lr 10gbase_ercwdm bplus_e 10gbase_bx20u 10gbase_bx20d cplusplusc cpluse d_i e1-c) Possible values: - not-available : fiber type is not available - px20 : single-mode fiber - px20plus : multi-mode - prx_t1 : single-mode fiber - pr_t2 : multi-mode - prx_t3 : single-mode fiber - pr_t4 : multi-mode - bplusc : single-mode fiber - bplusi : single-mode fiber - bplusi_onu : single-mode fiber - cplusc : single-mode fiber - cplusi : single-mode fiber - e1t1_eth : Electrical E1/T1 Ethernet bridged SFP (Ethernet over E1/T1 per GFP, HDLC or cHDLC encapsulation) - e3ds3_eth : Electrical E3/DS3 Ethernet bridged SFP (Ethernet over E3/DS2 per GFP, HDLC or cHDLC encapsulation) - stm1oc3_eth : Optical STM-1/OC3 Ethernet bridged SFP (Ethernet over STM-1/OC3 per GFP encapsulation) - e1t1_tdm : Electrical 2 x E1 TDM PW SFP (TDM E1 over Ethernet per MEF8 encapsulation) - 100base_fx : 100M multi-mode fiber - 100base_lx : 100M long-reach single-mode fiber - 100base_bx10u : 100M single-strand upstream single-mode fiber - 100base_bx10d : 100M single-strand downstream single-mode fiber - 100base_tx : 100M copper twisted-pair cable - 1000base_t : 1G copper twisted-pair cable - 1000base_cx : 1G copper twin-axial cable - 1000base_sx : 1G short-reach multi-mode fiber - 1000base_lx : 1G long-reach single-mode fiber - 1000base_bx10u : 1G single-strand upstream single-mode </pre>	

91 Equipment Status Commands

name	Type	Description
	fiber - 1000base_bx10d : 1G single-strand downstream single-mode fiber - 1000base_bx40u : 1G extended-reach upstream single-mode fiber - 1000base_bx40d : 1G extended-reach downstream single-mode fiber - 1000base_ex : 1G extended-reach 40km single-mode fiber - 1000base_zx : 1G extended reach 70km single-mode fiber - n1_c : 10G GPON N1 C-temp fiber - n2a_c : 10G GPON N2A C-temp fiber - n2b_c : 10G GPON N2B C-temp fiber - 1000base_vx : 1G CWDM fiber - 2500base : 2500M fiber - 10gbase_sr : 10G short-reach multi-mode fiber - 10gbase_lr : 10G long-reach single-mode fiber - 10gbase_lrm : 10G long-reach multi-mode fiber - 10gbase_er : 10G extended-reach single-mode fiber - 10gbase_sw : 10G short-reach wan multi-mode fiber - 10gbase_lw : 10G long-reach wan single-mode fiber - 10gbase_ew : 10G extended-reach wan single-mode fiber - 40gbase_sr4 : 40G short-reach multi-mode fiber - 40gbase_lr4 : 40G long-reach single-mode fiber - 40gbase_cr4 : 40G copper cable - 10gbase_bx40u : 10G extended-reach upstream single-mode fiber - 10gbase_bx40d : 10G extended-reach downstream single-mode fiber - 10gbase_zrcwmdm : 10G extended-reach single-mode fiber - 10gbase_zrdwmdm : 10G extended-reach single-mode fiber - 1000base_bx20u : One single-mode fiber ONU, long wavelength, 20km - 1000base_bx20d : One single-mode fiber OLT, long wavelength, 20km - n1_i : 10G GPON N1 I-temp fiber - n2a_i : 10G GPON N2A I-temp fiber - n2b_i : 10G GPON N2B I-temp fiber - 100gbase_lr4 : 100G long-reach single-mode fiber - 100gbase_sr4 : 100G short-reach multi-mode fiber - 10gbase_bx10u : 10G extended-reach upstream single-mode fiber - 10gbase_bx10d : 10G extended-reach downstream single-mode fiber - 1000base_zrcwmdm : 1G extended-reach single-mode fiber - 10gbase_zr : 10G extended-reach single-mode fiber - 10gbase_bx80u : 10G extended-reach upstream single-mode fiber - 10gbase_bx80d : 10G extended-reach downstream single-mode fiber - 1000base_bx80u : 1G extended-reach upstream single-mode fiber - 1000base_bx80d : 1G extended-reach downstream single-mode fiber - 100gbase_er4 : 100G extended-reach single-mode fiber - cplusplusi : single-mode fiber - 10gbase_t : 10G copper twisted-pair cable - 10gbase_bx60u : 10G extended-reach upstream	

name	Type	Description
	single-mode fiber - 10gbase_bx60d : 10G extended-reach downstream single-mode fiber - 2500base_bx40u : 2500M extended-reach upstream single-mode fiber - 2500base_bx40d : 2500M extended-reach downstream single-mode fiber - e1-i : 10G GPON E1 I-temp fiber - 1000base_ezx : 1G extended-reach 120km fiber - n2a_cplus_c : XGPON1 Combo N2a C+ C-temp fiber - 40gbase_psm4_lr : 40G long-reach parallel single-mode fiber with four channels - 10gbase_ercwdm : 10G extended-reach single-mode fiber - bplus_e : single-mode fiber - 10gbase_bx20u : 10G extended-reach upstream single-mode fiber - 10gbase_bx20d : 10G extended-reach downstream single-mode fiber - cplusplus : single-mode fiber - cpluse : single-mode fiber - d_i : single-mode fiber - e1-c : single-mode fiber	
optic-identifier	Parameter type: <PrintableString> - printable string	identifies the optic type that is plugged in, sfp, sfp_dd, sfp+, xfp <i>This element is only shown in detail mode.</i>

91.16 NE Status Command

Command Description

This command displays the status of the NE.

User Level

The command can be accessed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

> show equipment isam

Command Output

Table 91.16-2 "NE Status Command" Display parameters

Specific Information		
name	Type	Description
planned-type	Parameter type: <Equipm::SystemType> (laus laeu leeu maus leus lneu leww lnww) Possible values: - laus : large ASAM US / ANSI market (6 racks, 3 shelves per rack) - laeu : large ASAM EU / ETSI market (6 racks, 3 shelves per rack) - leeu : large ISAM for EU / ETSI market - maus : mini RAM ASAM for US / ANSI market - leus : large ISAM for US / ANSI market - lneu : new equipment practice (NEP) - leww : large ISAM World wide - lnww : large ISAM World wide	Specifies the planned isam type. <i>This element is only shown in detail mode.</i>
actual-type	Parameter type: <Equipm::SystemType> (laus laeu leeu maus leus lneu leww	A string representing the system type that is actually present. <i>This element is always shown.</i>

name	Type	Description
	lnww) Possible values: - laus : large ASAM US / ANSI market (6 racks, 3 shelves per rack) - laeu : large ASAM EU / ETSI market (6 racks, 3 shelves per rack) - leeu : large ISAM for EU / ETSI market - maus : mini RAM ASAM for US / ANSI market - leus : large ISAM for US / ANSI market - lneu : new equipment practice (NEP) - leww : large ISAM World wide - lnww : large ISAM World wide	
description	Parameter type: <Description-127> - description to help the operator to identify the object - length: x<=127	Specifies the location of the system. <i>This element is only shown in detail mode.</i>

91.17 Rack Status Command

Command Description

This command shows the rack status.

User Level

The command can be accessed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

```
> show equipment rack [ (rack) ]
```

Command Parameters

Table 91.17-1 "Rack Status Command" Resource Parameters

Resource Identifier	Type	Description
(rack)	Format: <Eqpt::RackId> Field type <Eqpt::RackId> - the rack number	the rack identifier

Command Output

Table 91.17-2 "Rack Status Command" Display parameters

Specific Information		
name	Type	Description
planned-type	Parameter type: <Equipm::RackType> (altr-e altr-a not-planned not-allowed empty) Possible values: - altr-e : ISAM ETSI DSL line termination rack (2200mm) - altr-a : ISAM ANSI DSL line termination rack - not-planned : holder is not planned - not-allowed : shelf is not allowed in this position - empty : shelf is empty in this position	Specifies the planned rack type. <i>This element is only shown in detail mode.</i>
actual-type	Parameter type: <Equipm::RackType> (altr-e altr-a not-planned not-allowed	A string representing the racktype that is actually present. <i>This element is always shown.</i>

name	Type	Description
	empty) Possible values: - altr-e : ISAM ETSI DSL line termination rack (2200mm) - altr-a : ISAM ANSI DSL line termination rack - not-planned : holder is not planned - not-allowed : shelf is not allowed in this position - empty : shelf is empty in this position	
description	Parameter type: <Description-127> - description to help the operator to identify the object - length: x<=127	Specifies the location of the rack. <i>This element is only shown in detail mode.</i>

91.18 Shelf Status Command

Command Description

This command shows the shelf status. The following information is shown in addition to configuration information:

- *oper-status: describes whether the board is able to perform its normal operation.*
- *error-status: provides the reason why the board is not operational. These values correspond to the alarms generated in case of a failure.*
- *available-status: provides further information regarding the state of the board.*

User Level

The command can be accessed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

```
> show equipment shelf [ (shelf) ]
```

Command Parameters

Table 91.18-1 "Shelf Status Command" Resource Parameters

Resource Identifier	Type	Description
(shelf)	Format: <Eqpt::RackId> / <Eqpt::ShelfId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number	a shelf identifier: <rack>/<shelf>

Command Output

Table 91.18-2 "Shelf Status Command" Display parameters

Specific Information		
name	Type	Description
planned-type	Parameter type: <Equipm::ShelfType> Data driven field type Possible values are depending on the actual configuration and software. The currently allowed values can be shown with online-help.	Specifies the planned shelf type. <i>This element is only shown in detail mode.</i>
actual-type	Parameter type: <Equipm::ShelfType> Data driven field type Possible values are depending on the actual configuration and software. The currently allowed values can be shown with online-help.	A string representing the shelftype that is actually present in the rack. <i>This element is always shown.</i>
admin-status	Parameter type: <Equipm::HolderAdminStatus>	Specifies the shelf is locked or

name	Type	Description
short name: locked	((lock yes) (unlock no)) Possible values: - lock : the holder is locked - yes : the holder is locked - unlock : the holder is unlocked - no : the holder is unlocked	not. <i>This element is only shown in detail mode.</i>
oper-status short name: enabled	Parameter type: <Equipm::OperStatus> ((enabled yes) (disabled no)) Possible values: - enabled : - yes : - disabled : - no :	Specifies whether or not the shelf is capable of performing its normal functions. <i>This element is always shown.</i>
error-status	Parameter type: <Equipm::OperError> (no-error type-mismatch board-missing no-installation no-planned-board waiting-for-sw init-boot-failed init-download-failed init-connection-failed configuration-failed board-reset-protection invalid-parameter temperature-alarm tempshutdown defense board-not-licensed sem-power-fail sem-ups-fail incompatible-slot download-ongoing upgrade-via-sby board-shelf-mismatch unknown-error) Possible values: - no-error : - type-mismatch : - board-missing : - no-installation : - no-planned-board : - waiting-for-sw : - init-boot-failed : - init-download-failed : - init-connection-failed : - configuration-failed : - board-reset-protection : - invalid-parameter : - temperature-alarm : - tempshutdown : - defense : - board-not-licensed : - sem-power-fail :	Specifies for what reason the shelf is not operational. <i>This element is always shown.</i>

91 Equipment Status Commands

name	Type	Description
	- sem-ups-fail : - incompatible-slot : - download-ongoing : - upgrade-via-sby : - board-shelf-mismatch : - unknown-error :	
availability	Parameter type: <Equipm::AvailStatus> (available in-test failed power-off not-installed offline dependency ext-managed) Possible values: - available : - in-test : - failed : - power-off : - not-installed : - offline : - dependency : - ext-managed :	Specifies whether the shelf is available or not. <i>This element is always shown.</i>
shelf-mode	Parameter type: <Equipm::HolderModeForShow> (no-extended-lt-slots extended-lt-slots no-ntb-slot no-extended-slots no-ntio-slots ngpon gpon ngpon-port-reduced gpon-mng-ngpon gpon-mng-reduced) Possible values: - no-extended-lt-slots : no extended lt slots - extended-lt-slots : change to extended lt slots - no-ntb-slot : use ntb slot as lt slot - no-extended-slots : no extended slots - no-ntio-slots : not changeable - ngpon : use universal ngpon lt (supports NG-PON2, XGS-PON and XG-PON1 currently) - gpon : use gpon lt - ngpon-port-reduced : use ngpon port reduced mode lt (supports ERPS) - gpon-mng-ngpon : use gpon managed ngpon management model - gpon-mng-reduced : use gpon managed ngpon port reduced mode lt(supports ERPS)	the shelf mode <i>This element is only shown in detail mode.</i>
class	Parameter type: <Equipm::ShelfClass> (main-iq-hcl ext-iq ext-hcl main-ethernet ext-ethernet) Possible values:	Specifies classification of shelves. <i>This element is only shown in detail mode.</i>

name	Type	Description
	- main-iq-hcl : main shelf - supports iq- and hcl-based traffic - ext-iq : extension shelf - supports only iq-based traffic - ext-hcl : extension shelf - support only hcs-based traffic - main-ethernet : main shelf - supports ethernet-based traffic - ext-ethernet : extension shelf - supports ethernet-based traffic	
serial-no	Parameter type: <Equipm::ShelfSerial> - printable string	Specifies the serial number of the shelf. <i>This element is only shown in detail mode.</i>
variant	Parameter type: <Equipm::ShelfVariant> - printable string	the Nokia code of the shelf. <i>This element is only shown in detail mode.</i>
ics-code	Parameter type: <Equipm::ShelfICS> - printable string	the item change status iteration code of the shelf. <i>This element is only shown in detail mode.</i>
description	Parameter type: <Description-127> - description to help the operator to identify the object - length: x<=127	Specifies the location of the shelf. <i>This element is only shown in detail mode.</i>

91.19 Power Supply Status Command

Command Description

This command shows the status of the power supply installed on the system.

- *psu-num:* shows the power supply's number.
- *part-num:* shows the power supply's part number.
- *v-in:* shows incoming voltage arriving at the power supply.
- *i-in:* shows incoming current arriving at the power supply.
- *v-out:* shows outgoing voltage provided by the power supply.
- *i-out:* shows outgoing current provided by the power supply.
- *temperature:* shows the temperature of the power supply.
- *present:* shows the presence status of the power supply
- *fault:* shows the fault status of the power supply. If a fault is detected, more information can be retrieved with the 'detail' version of this command
- *clei-code:* shows the power supply's clei code
- *ser-num:* shows the power supply's serial number
- *v-in-err:* report the fault or error happening at the incoming voltage level.
- *i-in-err:* report the fault or error happening at the incoming current level.
- *v-out-err:* report the fault or error happening at the outgoing voltage level.
- *i-out-err:* report the fault or error happening at the outgoing current level.
- *temperature-err:* report the fault or error happening at the temperature level.
- *cml-err:* report the fault or error happening at the communication, memory or logic (cml) level.

User Level

The command can be accessed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

```
> show equipment power-supply [ (psu-num) ]
```

Command Parameters

Table 91.19-1 "Power Supply Status Command" Resource Parameters

Resource Identifier	Type	Description
(psu-num)	Format: - Power supply ID	The power supply unit number

Command Output

Table 91.19-2 "Power Supply Status Command" Display parameters

Specific Information		
name	Type	Description
part-number	Parameter type: <PrintableString>	The part number of the installed

name	Type	Description
	- printable string	power supply <i>This element is always shown.</i>
v-in	Parameter type: <Equipm::MilliVoltType> - Millivolt converter to volt	The incoming voltage arriving at the power supply <i>This element is always shown.</i>
i-in	Parameter type: <Equipm::MilliAmpereType> - Milliampere converter to ampere	The incoming current arriving at the power supply <i>This element is always shown.</i>
v-out	Parameter type: <Equipm::MilliVoltType> - Millivolt converter to volt	The output voltage provided by the power supply <i>This element is always shown.</i>
i-out	Parameter type: <Equipm::MilliAmpereType> - Milliampere converter to ampere	The outgoing current provided by the power supply <i>This element is always shown.</i>
temperature	Parameter type: <Equipm::MilliTemperatureType> - Milli converter to y.x value	The current temperature of the power supply <i>This element is always shown.</i>
present	Parameter type: <Equipm::PowerSupplyPresent> (yes no) Possible values: - yes : PSU connector is plugged in - no : PSU connector is not plugged in	The presence of the power supply <i>This element is always shown.</i>
fault	Parameter type: <Equipm::PowerSupplyFaultDetected> (yes no) Possible values: - yes : The power supply has a fault - no : The power supply does not have a fault	The fault status of the power supply <i>This element is always shown.</i>

Only Show Details: identification

name	Type	Description
clei-code	Parameter type: <PrintableString> - printable string	The CLEI code of the installed power supply <i>This element is only shown in detail mode.</i>
ser-num	Parameter type: <PrintableString> - printable string	The serial number of the installed power supply <i>This element is only shown in detail mode.</i>

Only Show Details: fault

name	Type	Description
v-in-err	Parameter type: <Equipm::PowerSupplyFaultVin> (no-error (overvoltage-fault ov fault) (overvoltage-warning ov warn) (undervoltage-warning un warn) (undervoltage-fault un fault) (ac-nok-fault ac fault) (ac-nok-warning ac warning) (not-enough-in-vol unit off insuf volt)) Possible values: - no-error : no error - overvoltage-fault : overvoltage fault - ov fault : overvoltage fault - overvoltage-warning : overvoltage warning - ov warn : overvoltage warning	The error/fault status of the incoming voltage <i>This element is only shown in detail mode.</i>

91 Equipment Status Commands

name	Type	Description
	- undervoltage-warning : undervoltage warning - un warn : undervoltage warning - undervoltage-fault : undervoltage fault - un fault : undervoltage fault - ac-nok-fault : ac nok fault - ac fault : ac nok fault - ac-nok-warning : ac nok warning - ac warning : ac nok warning - not-enough-in-vol : unit off for insufficient input voltage - unit off insuf volt : unit off for insufficient input voltage	
v-out-err	Parameter type: <Equipm::PowerSupplyFaultVout> (no-error (overvoltage-fault ov-fault) (overvoltage-warning ov-warn) (undervoltage-warning un-warn) (undervoltage-fault un-fault)) Possible values: - no-error : no error - overvoltage-fault : overvoltage fault - ov-fault : overvoltage fault - overvoltage-warning : overvoltage warning - ov-warn : overvoltage warning - undervoltage-warning : undervoltage warning - un-warn : undervoltage warning - undervoltage-fault : undervoltage fault - un-fault : undervoltage fault	The error/fault status of the outgoing voltage <i>This element is only shown in detail mode.</i>
i-in-err	Parameter type: <Equipm::PowerSupplyFaultIin> (no-error (overcurrent-fault oc-fault) (overcurrent-warning oc-warn) (overpower-warning op-warn)) Possible values: - no-error : no error - overcurrent-fault : overcurrent fault - oc-fault : overcurrent fault - overcurrent-warning : overcurrent warning - oc-warn : overcurrent warning - overpower-warning : overpower warning - op-warn : overpower warning	The error/fault status of the incoming current <i>This element is only shown in detail mode.</i>
i-out-err	Parameter type: <Equipm::PowerSupplyFaultIout> (no-error (overcurrent-fault oc-fault) (overcurrent-warning oc-warn) (undercurrent-warning uc-warn) (undercurrent-fault uc-fault)) Possible values: - no-error : no error - overcurrent-fault : overcurrent fault - oc-fault : overcurrent fault - overcurrent-warning : overcurrent warning - oc-warn : overcurrent warning - undercurrent-warning : undercurrent warning - uc-warn : undercurrent warning - undercurrent-fault : undercurrent fault - uc-fault : undercurrent fault	The error/fault status of the outgoing current <i>This element is only shown in detail mode.</i>
temperature-err	Parameter type: <Equipm::PowerSupplyFaultTemperature> (no-error	The error/fault status on the temperature

name	Type	Description
	(overtemper-fault oc-fault) (overtemper-warning oc-warn) (undertemper-warning uc-warn) (undertemper-fault uc-fault)) Possible values: - no-error : no error - overtemper-fault : overtemperature fault - oc-fault : overtemperature fault - overtemper-warning : overtemperature warning - oc-warn : overtemperature warning - undertemper-warning : undertemperature warning - uc-warn : undertemperature warning - undertemper-fault : undertemperature fault - uc-fault : undertemperature fault	<i>This element is only shown in detail mode.</i>
cml-err	Parameter type: <Equipm::PowerSupplyFaultCml> (no-error inv-unsup-cmd-rcvd inv-unsup-data-rcvd pkt-err-chk (memory-fault mem-fault) (processor-fault proc-fault) oth-com-fault oth-mem-log-fault) Possible values: - no-error : no error - inv-unsup-cmd-rcvd : an invalid or unsupported command has been received - inv-unsup-data-rcvd : an invalid or unsupported data has been received - pkt-err-chk : packet error check has failed - memory-fault : a memory fault happened into the power supply - mem-fault : a memory fault happened into the power supply - processor-fault : a processor fault happened into the power supply - proc-fault : a processor fault happened into the power supply - oth-com-fault : a communication fault has been detected - oth-mem-log-fault : a memory or logic fault has been detected	The error/fault status on the Communication, Logic and Memory <i>This element is only shown in detail mode.</i>

92- ONT Status Commands

92.1 ONT Status Command Tree	92-2022
92.2 ONT Interface Command	92-2025
92.3 ONT Interface Operational Status Command	92-2029
92.4 ONT Card Status Command	92-2035
92.5 ONT Software Control Status Command	92-2038
92.6 ONT Software Version Status Command	92-2039
92.7 ONT Software Download Status Command	92-2040
92.8 ONT Data Store Status Command	92-2044
92.9 ONT Optics Status Command	92-2046
92.10 ONT Optics History Status Command	92-2049
92.11 ONT Power Shedding Status Command	92-2053
92.12 GPON ont Olt-side on-demand Aggregate gem Current-Interval Performance Monitoring Command	92-2055
92.13 GPON ont Olt-side on-demand aggregate gem Previous-Interval Performance Monitoring Command	92-2057
92.14 GPON ont Ont-side aggregate gem Current-Interval Performance Monitoring Command	92-2059
92.15 GPON ont Ont-side Aggregate gem Previous-Interval Performance Monitoring Command	92-2061
92.16 GPON ont Olt-side Always-on Aggregate gem Current-Interval Performance Monitoring Command	92-2063
92.17 GPON Ont Olt-side Always-on Aggregate gem Previous-Interval Performance Monitoring Command	92-2065
92.18 Multicast TC-layer Current Interval Performance Data Status Command	92-2067
92.19 Multicast TC-layer Previous Interval Performance Data Status Command	92-2069
92.20 Fec TC-layer Current Interval Counters Command	92-2071
92.21 Olt-side FEC TC-layer Current Interval Counters Command	92-2073
92.22 ONT Software Control List Status Command	92-2075
92.23 GPON ont pon aggregate ethernet Current-Interval Performance Monitoring Command	92-2077
92.24 GPON ont pon Aggregate ethernet Previous-Interval Performance Monitoring Command	92-2079
92.25 GPON ont pon aggregate ethernet total Performance Monitoring Command	92-2082
92.26 Olt-side Physical-layer Current Interval Counters Command	92-2084
92.27 XGPON ONT Ont-side tc-layer Current-Interval Performance Monitoring Command	92-2086
92.28 XGPON ONT Ont-side tc-layer Previous-Interval Performance Monitoring Command	92-2088
92.29 XGPON ONT Olt-side tc-layer Current-Interval Performance Monitoring Command	92-2090
92.30 XGPON ONT Olt-side tc-layer Previous-Interval Performance Monitoring Command	92-2092
92.31 ONT Utilization Current Interval PM Command	92-2094
92.32 ONT Utilization Previous Interval PM Command	92-2096
92.33 ONT Configure File Download Status Command	92-2098

92.34 ONT Configure File Download Status Command	92-2103
92.35 ONT Config File Download Status Per Channel Group/Sub Channel Group Command	92-2104
92.36 ONT Index Lookup Command	92-2110
92.37 ONT Gis Info Command	92-2112
92.38 XGPON ONT Olt-side Performance Monitoring Command	92-2114
92.39 XGPON ONT Previous-Interval Performance Monitoring Command	92-2117
92.40 GPON ONT Memory Usage Current-Interval Performance Monitoring Command	92-2120
92.41 GPON ONT Memory Usage Previous-Interval Performance Monitoring Command	92-2122
92.42 GPON ONT CPU Load Current-Interval Performance Monitoring Command	92-2124
92.43 GPON ONT CPU Load previous-Interval Performance Monitoring Command	92-2126

92.1 ONT Status Command Tree

Description

This chapter gives an overview of nodes that are handled by "ONT Status Commands".

Command Tree

```
----show
  ----equipment
    ----ont
      ----interface
        - (ont-idx)
      ----operational-data
        - (ont-idx)
      ----slot
        - (ont-slot-idx)
      ----sw-ctrl
        - (sw-ctrl-idx)
      ----sw-version
        - (sw-ver-id)
      ----sw-download
        - (ont-idx)
      ----data-store
        - (ont-idx)
      ----optics
        - (ont-idx)
      ----optics-history
        - (ont-idx)
      ----pwr-shed
        - (ont-idx)
      ----tc-layer
        ----olt-side-on-demand
          ----current-interval
            - (ont-idx)
          ----previous-interval
            - (ont-idx)
            - interval-num
        ----ont-side
          ----current-interval
            - (ont-idx)
          ----previous-interval
            - (ont-idx)
            - interval-num
        ----olt-side
          ----current-interval
            - (ont-idx)
          ----previous-interval
            - (ont-idx)
            - interval-num
      ----mcast-tc-layer
        ----ont-side
          ----current-interval
            - (ont-idx)
```



```

        ----previous-interval
            - (ont-idx)
            - interval-no
----fec-tc-layer
    ----ont-side
        ----current-interval
            - (ont-idx)
    ----olt-side
        ----current-interval
            - (ont-idx)
----sw-ctrl-list
    - (sw-ctrl-idx)
----ethernet
    ----current-interval
        - (ont-idx)
    ----previous-interval
        - (ont-idx)
        - interval-num
    ----total
        - (ont-idx)
----phy-layer
    ----olt-side
        ----current-interval
            - (ont-idx)
----xg-tc-layer
    ----ont-side
        ----current-interval
            - (ont-idx)
        ----previous-interval
            - (ont-idx)
            - interval-no
    ----olt-side
        ----current-interval
            - (ont-idx)
        ----previous-interval
            - (ont-idx)
            - interval-no
----utilization
    ----current-interval
        - (ont-idx)
    ----previous-interval
        - (ont-idx)
        - interval-num
----cfg-download
    - (ont-idx)
----ng2-cfg-download
    ----channel-group
        - (channel-group)
        - subchannel-group
        - ont-id
----index
    - (ont-search-string)
----gis
    - (ont-idx)
----xg-mgmt
    ----ont-side
        ----current-interval
            - (ont-idx)
        ----previous-interval

```

- (ont-idx)
- interval-no
- memory-usage
- current-interval
 - (ont-idx)
- previous-interval
 - (ont-idx)
 - interval-num
- cpu-load
- current-interval
 - (ont-idx)
- previous-interval
 - (ont-idx)
 - interval-num

92.2 ONT Interface Command

Command Description

This command reports Interface parameters for the ont.

User Level

The command can be accessed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

```
> show equipment ont interface [ (ont-idx) ]
```

Command Parameters

Table 92.2-1 "ONT Interface Command" Resource Parameters

Resource Identifier	Type	Description
(ont-idx)	Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> ng2 : <Ng2::ChannelGroup> / <Ng2::SubchannelGroup> / <Ng2::OntId>) Possible values: - ng2 : ngpon2 style identification Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Ng2::ChannelGroup> - channel group number Field type <Ng2::SubchannelGroup> - subchannel group number Field type <Eqpt::OntId> - the ONT identifier Field type <Ng2::OntId> - the ONT identifier	identification of ont

Command Output

Table 92.2-2 "ONT Interface Command" Display parameters

Specific Information

92 ONT Status Commands

name	Type	Description
eqpt-ver-num	Parameter type: <Gpon::SwVer> - ont sw version - length: 1<=x<=14	version number of the ont <i>This element is always shown.</i>
sw-ver-act	Parameter type: <Gpon::SwVer> - ont sw version - length: 1<=x<=14	active software version in the ont <i>This element is always shown.</i>
sw-ver-psv	Parameter type: <Gpon::SwVer> - ont sw version - length: 1<=x<=14	passive software version in the ont <i>This element is only shown in detail mode.</i>
vendor-id	Parameter type: <Gpon::VendorId> - vendor id - 4 ASCII characters - range: [a-zA-Z0-9] - length: 4	vendor id <i>This element is only shown in detail mode.</i>
equip-id	Parameter type: <Gpon::EquipId> - ont equip Id - length: x<=20	equipment id <i>This element is only shown in detail mode.</i>
actual-num-slots	Parameter type: <Gpon::ActualOntSlotId> - Gpon Ont Slot - range: [0...16]	actual number of slots on ont <i>This element is always shown.</i>
version-number	Parameter type: <Gpon::OntVersion> - the version number of a card - length: x<=14	version number of ont <i>This element is always shown.</i>
num-tconts	Parameter type: <Gpon::Tconts> - tconts - range: [0...4095]	number of t-conts supported <i>This element is only shown in detail mode.</i>
num-trf-sched	Parameter type: <Gpon::TrafficSched> - traffic schedule - range: [0...255]	number of traffic schedulers supported <i>This element is only shown in detail mode.</i>
num-prio-queues	Parameter type: <Gpon::PrioQueues> - priority queues - range: [0...4095]	number of priority queues supported <i>This element is only shown in detail mode.</i>
auto-sw-planned-ver	Parameter type: <Gpon::SwVer> - ont sw version - length: 1<=x<=14	planned software of ont <i>This element is only shown in detail mode.</i>
auto-sw-download-ver	Parameter type: <Gpon::SwVer> - ont sw version - length: 1<=x<=14	download software version of ont <i>This element is only shown in detail mode.</i>
sernum	Parameter type: <Gpon::SerNum2> <Gpon::VendorIdNum> : <Gpon::SerialNo> Field type <Gpon::VendorIdNum> - vendor id -4 ASCII characters - length: 4 Field type <Gpon::SerialNo> - serial num - 8 ASCII characters - range: [a-fA-F0-9] - length: 8	Serial number of ont <i>This element is always shown.</i>
yp-serial-no	Parameter type: <Gpon::YpSerialNumber> (unknown <PrintableString>) Possible values: - unknown : yp serial number not supported for this ONT Field type <PrintableString> - printable string	Yp Serial number of ont <i>This element is always shown.</i>
oper-spec-ver	Parameter type: <Gpon::OperSpecVer>	the ctc spec version supported by

name	Type	Description
	(ctc-v2.0 unknown <Gpon::OperSpecVer>) Possible values: - ctc-v2.0 : ctc version 2.0 - unknown : the version is unknown Field type <Gpon::OperSpecVer> - the ctc spec version supported by the ont - range: [0...256]	the ont <i>This element is only shown in detail mode.</i>
act-ont-type	Parameter type: <Gpon::ActOntType> (sfu hgu sbu cbu mdu mtu unknown <Gpon::ActOntType>) Possible values: - sfu : the ont type is sfu - hgu : the ont type is hgu - sbu : the ont type is sbu - cbu : the ont type is cbu - mdu : the ont type is mdu - mtu : the ont type is mtu - unknown : the ont type is unknown Field type <Gpon::ActOntType> - the ctc ont type - range: [0...256]	the ctc ont type <i>This element is only shown in detail mode.</i>
act-txpower-ctrl	Parameter type: <Gpon::ActTxPwrCtrl> (not-supported tx-only tx-rx unknown <Gpon::ActTxPwrCtrl>) Possible values: - not-supported : not supported - tx-only : only supporting tx control - tx-rx : tx and rx power supplies can be controlled independently - unknown : the power supply ctrl mode is unknown Field type <Gpon::ActTxPwrCtrl> - whether power supply of ONT transmitter can be independently controlled - range: [0...256]	whether power supply of ONT transmitter can be independently controlled <i>This element is only shown in detail mode.</i>
sn-bundle-status	Parameter type: <Gpon::SnBundleStatus> (idle bundling bundled) Possible values: - idle : the sn currently is not bundled - bundling : the sn currently is not bundled while auto-bundle timer has been started - bundled : the sn currently is bundled	sn with loid/sluid bundling status <i>This element is only shown in detail mode.</i>
cfgfile1-ver-act	Parameter type: <Gpon::CfgFile> - ont configure file version - length: 1<=x<=14	active configure file 1 version in the ont <i>This element is always shown.</i>

92 ONT Status Commands

name	Type	Description
cfgfile1-ver-psv	Parameter type: <Gpon::CfgFile> - ont configure file version - length: 1<=x<=14	passive configure file 1 version in the ont <i>This element is only shown in detail mode.</i>
cfgfile2-ver-act	Parameter type: <Gpon::CfgFile> - ont configure file version - length: 1<=x<=14	active configure file 2 version in the ont <i>This element is always shown.</i>
cfgfile2-ver-psv	Parameter type: <Gpon::CfgFile> - ont configure file version - length: 1<=x<=14	passive configure file 2 version in the ont <i>This element is only shown in detail mode.</i>
actual-us-rate	Parameter type: <Gpon::ActualUsRate> (2.5g 10g 1.25g 25g) Possible values: - : unknown - 2.5g : 2.5 GBit/sec - 10g : 10 GBit/sec - 1.25g : 1.25 GBit/sec - 25g : 25 GBit/sec	actual upstream rate. <i>This element is always shown.</i>
template-name	Parameter type: <Gpon::OnuProvTemplateName> - Template name to be used for ONU auto provisioning - range: [a-zA-Z0-9-_ - length: x<=20	ONT Semi-Auto Provision template name <i>This element is only shown in detail mode.</i>
auto-prov-status	Parameter type: <Gpon::OnuAutoProvStatus> (not-applicable failed success) Possible values: - not-applicable : ONU semi-auto provisioning is not applicable - failed : ONU semi-auto provisioning failed - success : ONU semi-auto provisioning is success	ONT Semi-Auto provisioning status <i>This element is only shown in detail mode.</i>

92.3 ONT Interface Operational Status Command

Command Description

this command reports current operational parameters for the ont.

User Level

The command can be accessed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

```
> show equipment ont operational-data [ (ont-idx) ]
```

Command Parameters

Table 92.3-1 "ONT Interface Operational Status Command" Resource Parameters

Resource Identifier	Type	Description
(ont-idx)	Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> ng2 : <Ng2::ChannelGroup> / <Ng2::SubchannelGroup> / <Ng2::OntId>) Possible values: - ng2 : ngpon2 style identification Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Ng2::ChannelGroup> - channel group number Field type <Ng2::SubchannelGroup> - subchannel group number Field type <Eqpt::OntId> - the ONT identifier Field type <Ng2::OntId> - the ONT identifier	identification of ont

Command Output

Table 92.3-2 "ONT Interface Operational Status Command" Display parameters

Specific Information

92 ONT Status Commands

name	Type	Description
loss-of-signal	Parameter type: <Gpon::LossOfSignal> (no yes) Possible values: - no : no loss of signal - yes : loss of signal	loss of signal alarm (los). <i>This element is always shown.</i>
loss-of-ack	Parameter type: <Gpon::LossOfAck> (no yes) Possible values: - no : no loss of acknowledgement - yes : loss of acknowledgement	loss of acknowledge alarm (loa). <i>This element is always shown.</i>
loss-of-gem	Parameter type: <Gpon::LossOfGem> (no yes) Possible values: - no : no loss of gem channel delineation - yes : loss of gem channel delineation	loss of gem channel delineation (lcd). <i>This element is always shown.</i>
physical-eqpt-err	Parameter type: <Gpon::PhysicalEqptErr> (no yes) Possible values: - no : no physical equipment error - yes : physical equipment error	physical equipment error (pee). <i>This element is only shown in detail mode.</i>
startup-failure	Parameter type: <Gpon::StartupFailure> (no yes) Possible values: - no : no startup failure - yes : startup failure	startup failure (suf). <i>This element is only shown in detail mode.</i>
signal-degrade	Parameter type: <Gpon::SignalDegrade> (no yes) Possible values: - no : no signal degrade - yes : signal degrade	signal degrade (sd). <i>This element is only shown in detail mode.</i>
ont-disabled	Parameter type: <Gpon::OntDisabled> (no yes) Possible values: - no : ont not disabled - yes : ont disabled	ont disabled (ontdisabled). <i>This element is always shown.</i>
msg-error-msg	Parameter type: <Gpon::MsgErrorMsg> (no yes) Possible values: - no : no message error message - yes : message error message	message error message (mem). <i>This element is only shown in detail mode.</i>
inactive	Parameter type: <Gpon::Inactive> (no yes) Possible values: - no : active - yes : inactive	inactive (inact). <i>This element is always shown.</i>
loss-of-frame	Parameter type: <Gpon::LossOfFrame> (no yes)	loss of frame (lof). <i>This element is only shown in detail mode.</i>

name	Type	Description
	Possible values: - no : no loss of frame - yes : loss of frame	
signal-fail	Parameter type: <Gpon::SignalFail> (no yes) Possible values: - no : no signal failure - yes : signal failure	signal fail (sf). <i>This element is only shown in detail mode.</i>
dying-gasp	Parameter type: <Gpon::DyingGasp> (no yes) Possible values: - no : no dying gasp - yes : dying gasp	dying gasp (dg). <i>This element is always shown.</i>
deactivate-fail	Parameter type: <Gpon::DeactivateFail> (no yes) Possible values: - no : no deactivate failure - yes : deactivate failure	deactivate failure (df). <i>This element is only shown in detail mode.</i>
loss-of-ploam	Parameter type: <Gpon::LossOfPloam> (no yes) Possible values: - no : no loss of ploam - yes : loss of ploam	loss of ploam(lop). <i>This element is only shown in detail mode.</i>
drift-of-window	Parameter type: <Gpon::DriftOfWindow> (no yes) Possible values: - no : no drift of window - yes : drift of window	drift of window (dow). <i>This element is only shown in detail mode.</i>
remote-defect-ind	Parameter type: <Gpon::RemoteDefectInd> (no yes) Possible values: - no : no remote defect indication - yes : remote defect indication	remote defect indication (rdi). <i>This element is only shown in detail mode.</i>
loss-of-key-sync	Parameter type: <Gpon::LossOfKeySync> (no yes) Possible values: - no : no loss of key synchronization - yes : loss of key synchronization	loss of key synchronization (loks). <i>This element is only shown in detail mode.</i>
rogue-ont-disabled	Parameter type: <Gpon::RogueOntDis> (no yes) Possible values: - no : no rogue ont disable - yes : rogue ont disable	rogue ont disable (rogueontdis). <i>This element is only shown in detail mode.</i>
diff-reach	Parameter type: <Gpon::DiffReach> (no yes) Possible values: - no : differential reach capability not exceeded - yes : differential reach capability exceeded	differential reach capability exceeded (difreach). <i>This element is only shown in detail mode.</i>

name	Type	Description
ont-olt-distance	Parameter type: <Gpon::OntOltDist> (invalid not-supported <Gpon::DistOntOlt>) Possible values: - invalid : valid measurement is currently unattainable for some reason - not-supported : the measurement functionality is not supported by this particular unit. Field type <Gpon::DistOntOlt> - estimate of the distance between this ont and the olt - unit: km - range: [0...6550,6553.4...6553.5]	estimate of the distance between this ont and the olt. <i>This element is always shown.</i>
tod-sync	Parameter type: <Gpon::OntSyncStatus> (no yes) Possible values: - no : ont Clock not synced to olt - yes : ont Clock synced to olt	the ont clock tod synchronized status. <i>This element is always shown.</i>
sw-ver-act	Parameter type: <Gpon::SwVer> - ont sw version - length: 1<=x<=14	active software version in the ont. <i>This element is only shown in detail mode.</i>
sw-ver-psv	Parameter type: <Gpon::SwVer> - ont sw version - length: 1<=x<=14	passive software version in the ont. <i>This element is only shown in detail mode.</i>
last-restart-reason	Parameter type: <Gpon::OntLatestRestartReason> (unspecified-other software-restart hardware-restart timer-expiration hardware-error hardware-auto-restart over-temperature software-out-of-memory software-auto-restart user-software-restart n/a) Possible values: - unspecified-other : Unspecified other - software-restart : User initiated software restart remotely by OMCI/PLOAM - hardware-restart : User initiated hardware restart - timer-expiration : Self-monitor timer expiration - hardware-error : Hardware error (bus time-out, misaligned memory access, etc.) - hardware-auto-restart : Hardware auto-restart (on-board voltage monitor auto-restart, etc.) - over-temperature : Over temperature - software-out-of-memory: Software out of memory - software-auto-restart : Software auto-restart (unresolvable references, critical internal inconsistency) - user-software-restart : User initiated software restart locally by CLI/WEB - n/a : unknown	show ont latest restart reason <i>This element is always shown.</i>
down-reason	Parameter type: <Gpon::OntLastDownReason> (loss-of-signal	down cause of ont form OLT perspective

name	Type	Description
	loss-of-acknowledge channel-delineation equipment-error start-up-failure signal-degrade ont-disabled error-message ploam-inactive loss-of-frame signal-failure dying-gasp deactivate-failure loss-of-oam drift-of-window remote-defect loss-of-key-signal roque-ont-disabled pon-exceeds-diff-reach loss-of-omci-channel ont-omci-failure ont-equipment-failure sw-activation-failure password-auth-failure equipment-mismatch invalid-active-version upstream-rate-mismatch me-mismatch-alarm voip-config-error ont-temperature-rise ont-tuning-failed user-software-restart admin-down pon-down not-yet-detected lt-reboot n/a) Possible values: - loss-of-signal : PLOAM Loss Of Signal - loss-of-acknowledge : PLOAM Loss of Acknowledgement - channel-delineation : PLOAM Loss of Channel Delineation - equipment-error : PLOAM Physical Equipment Error - start-up-failure : PLOAM Start Up Failure - signal-degrade : PLOAM Signal Degrade - ont-disabled : PLOAM Misbehaved ONT Disabled - error-message : PLOAM Message Error Message - ploam-inactive : PLOAM Inactive - loss-of-frame : PLOAM Loss of Frame - signal-failure : PLOAM Signal Fail - dying-gasp : PLOAM Dying Gasp - deactivate-failure : PLOAM Deactivate Failure - loss-of-oam : PLOAM Loss of Operations, Administrations and Maintenance - drift-of-window : PLOAM Drift of Window - remote-defect : PLOAM Remote Defect Indication - loss-of-key-signal : PLOAM Loss of Key Signal - roque-ont-disabled : PLOAM Roque ONT Disabled	<i>This element is always shown.</i>

92 ONT Status Commands

name	Type	Description
	- pon-exceeds-diff-reach: PLOAM PON exceeds differential reach capability - loss-of-omci-channel : PLOAM Loss of OMCI Channel on ONT - ont-omci-failure : ONT OMCI Failure - ont-equipment-failure : ONT Equipment Failure - sw-activation-failure : ONT Software Activation Failed - password-auth-failure : ONT Password Authentication Failed - equipment-mismatch : ONT Equipment Mismatch Alarm - invalid-active-version: ONT Invalid active version - upstream-rate-mismatch: ONT Planned and active Upstream Rate Mismatch - me-mismatch-alarm : ONT ME Mismatch Alarm - voip-config-error : VOIP Configuration File Error - ont-temperature-rise : ONT Temperature Rise - ont-tuning-failed : ONT Tuning Failed - user-software-restart : User initiated software restart locally by CLI/WEB - admin-down : Admin down - pon-down : Pon down - not-yet-detected : Not Yet Detected - lt-reboot : Down by LT - ONT went down due to LT reboot - n/a : Unknown	

92.4 ONT Card Status Command

Command Description

This command show ont card holder actual information.

User Level

The command can be accessed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

```
> show equipment ont slot [ (ont-slot-idx) ]
```

Command Parameters

Table 92.4-1 "ONT Card Status Command" Resource Parameters

Resource Identifier	Type	Description
(ont-slot-idx)	Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Gpon::OntSlotId> ng2 : <Ng2::ChannelGroup> / <Ng2::SubchannelGroup> / <Ng2::OntId> / <Gpon::OntSlotId>) Possible values: - ng2 : ngpon2 style identification Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Ng2::ChannelGroup> - channel group number Field type <Ng2::SubchannelGroup> - subchannel group number Field type <Eqpt::OntId> - the ONT identifier Field type <Ng2::OntId> - the ONT identifier Field type <Gpon::OntSlotId> - Gpon Ont Slot - range: [1...14]	current operational parameters for the ont

Command Output

Table 92.4-2 "ONT Card Status Command" Display parameters

Specific Information		
name	Type	Description
act-num-data-ports	Parameter type: <Gpon::OntCardNoOfPorts> - the actual number of ports - range: [0...24]	the actual number of data ports for the ont card. <i>This element is always shown.</i>
act-num-voice-ports	Parameter type: <Gpon::OntCardNoOfPotsPorts> - the actual number of ports - range: [0...24]	the actual number of voice ports for the ont card. <i>This element is always shown.</i>
actual-card-type	Parameter type: <Gpon::OntCardType> (ethernet 10_100baset pots 802_11 vdsl2pots vdsl2 ethpots none video veip ds1/e1 hpna 2488_1244 moca unknown) Possible values: - ethernet : 10/100/1000/10000 base-t - 10_100baset : 10/100 base-t or 10/100/1000 base-t card - pots : pots card - 802_11 : 80211 card - vdsl2pots : vdsl2/pots combo card - vdsl2 : vdsl2 only card - ethpots : ethernet/pots combo card - none : no card is present - video : video card - veip : VEIP card - ds1/e1 : configurable ds1/e1 card - hpna : hpna card - 2488_1244 : GPON24881244 card - moca : moca - unknown : an unknown card type is present	the type of card that is present in the ont. <i>This element is always shown.</i>
actual-ont-integ	Parameter type: <Gpon::OntInteg> (nonintegrated integrated unknown) Possible values: - nonintegrated : non-integrated interfaces (pluggable units) - integrated : integrated interfaces (no pluggable units) - unknown : not known	how the interfaces at the ont are modeled. <i>This element is only shown in detail mode.</i>
actual-serial-num	Parameter type: <Gpon::OntSerial> - significant 8 characters of the serial number - length: x<=8	the least significant 8 characters of the serial number of a card that is present in the ont. <i>This element is always shown.</i>
actual-version-num	Parameter type: <Gpon::OntVersion> - the version number of a card - length: x<=14	the version number of a card that is present in the ont. <i>This element is only shown in detail mode.</i>

name	Type	Description
actual-vendorid	Parameter type: <Gpon::OntVendor> - the vendor id of a card - length: x<=4	the vendor id of a card that is present in the ont. <i>This element is only shown in detail mode.</i>
actual-cardid	Parameter type: <Gpon::OntCardId> - the identifier of a card - length: x<=20	the identifier of a card (such as clei code) that is present in the ont. <i>This element is only shown in detail mode.</i>
state	Parameter type: <Gpon::OntOperState> (enabled disabled) Possible values: - enabled : enabled - disabled : disabled	operation state of ont. <i>This element is always shown.</i>

92.5 ONT Software Control Status Command

Command Description

This command shows an association between an ont hardware version/variant and an ont software version.

User Level

The command can be accessed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

```
> show equipment ont sw-ctrl [ (sw-ctrl-idx) ]
```

Command Parameters

Table 92.5-1 "ONT Software Control Status Command" Resource Parameters

Resource Identifier	Type	Description
(sw-ctrl-idx)	Format: - ont software control table index - range: [1...250]	ont software control table index

Command Output

Table 92.5-2 "ONT Software Control Status Command" Display parameters

Specific Information		
name	Type	Description
last-update-time	Parameter type: <Gpon::OntLastUpdateTime> - the time (yyyy-mm-dd:hour:minutes:secs) - unit: UTC	last update time of ont software control table. <i>This element is always shown.</i>
num-ref-onts	Parameter type: <Gpon::OntNoOfRefONTs> - number of onts that are referencing - range: [0...4608]	the number of onts that are referencing this ont software control entry. <i>This element is always shown.</i>
pre-plan-swver	Parameter type: <Gpon::OntVersion> - the version number of a card - length: x<=14	the previous planned ont software version used when swverplan=auto . <i>This element is always shown.</i>

92.6 ONT Software Version Status Command

Command Description

This command reports the ont software version files that are currently resident on the nt file system.

User Level

The command can be accessed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

> show equipment ont sw-version [(sw-ver-id)]

Command Parameters

Table 92.6-1 "ONT Software Version Status Command" Resource Parameters

Resource Identifier	Type	Description
(sw-ver-id)	Format: - software version info index - range: [1...250]	index of software version file

Command Output

Table 92.6-2 "ONT Software Version Status Command" Display parameters

Specific Information		
name	Type	Description
sw-ver	Parameter type: <Gpon::OntVersion> - the version number of a card - length: x<=14	ont software version identifier. <i>This element is always shown.</i>
sw-ver-size	Parameter type: <Gpon::OntSwVerSize> - ont software file size - range: [0...4294967295]	this attribute contains the ont software file size (in bytes). <i>This element is always shown.</i>

92.7 ONT Software Download Status Command

Command Description

This command shows individual ont fine-grain status associated with any sw download activity.

User Level

The command can be accessed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

> show equipment ont sw-download [(ont-idx)]

Command Parameters

Table 92.7-1 "ONT Software Download Status Command" Resource Parameters

Resource Identifier	Type	Description
(ont-idx)	Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> ng2 : <Ng2::ChannelGroup> / <Ng2::SubchannelGroup> / <Ng2::OntId>) Possible values: - ng2 : ngpon2 style identification Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Ng2::ChannelGroup> - channel group number Field type <Ng2::SubchannelGroup> - subchannel group number Field type <Eqpt::OntId> - the ONT identifier Field type <Ng2::OntId> - the ONT identifier	current operational parameters for the ont

Command Output

Table 92.7-2 "ONT Software Download Status Command" Display parameters

Specific Information

name	Type	Description
planned	Parameter type: <Gpon::notPlnd> (no yes) Possible values: - no : ont is planned - yes : ont is not planned	ont is not planned. <i>This element is always shown.</i>
inactive	Parameter type: <Gpon::inAct> (no yes) Possible values: - no : ont is active - yes : ont is not active	ont is not active. <i>This element is only shown in detail mode.</i>
planned-notok	Parameter type: <Gpon::nokPlnd> (no yes) Possible values: - no : planned sw is active - yes : planned sw is not active	planned did not equal to active. <i>This element is only shown in detail mode.</i>
download-notok	Parameter type: <Gpon::nokDld> (no yes) Possible values: - no : download software is in active or passive - yes : download software is not active or passive	download did not equal to active / passive. <i>This element is only shown in detail mode.</i>
download-inprogress	Parameter type: <Gpon::dldInProg> (no yes) Possible values: - no : download not started - yes : download started	download activity in progress. <i>This element is always shown.</i>
ntlt-inprogress	Parameter type: <Gpon::ntltInProg> (no yes) Possible values: - no : ntlt file transfer not in progress - yes : ntlt file transfer in progress	ntlt file transfer in progress. <i>This element is always shown.</i>
omci-inprogress	Parameter type: <Gpon::omciInProg> (no yes) Possible values: - no : omci file transfer not in progress - yes : omci file transfer in progress	omci file transfer in progress. <i>This element is always shown.</i>
ontflash-inprogress	Parameter type: <Gpon::ontFlashInProg> (no yes) Possible values: - no : ont write not in progress - yes : ont flash in progress	ont flash in progress. <i>This element is only shown in detail mode.</i>
ontswact-inprogress	Parameter type: <Gpon::ontSwActInProg> (no yes) Possible values: - no : ont software activation not in progress - yes : ont software activation in progress	ont software activation is progress. <i>This element is always shown.</i>
ntlt-failure	Parameter type: <Gpon::ntltFailure> (no yes)	ntlt file transfer failure. <i>This element is only shown in detail mode.</i>

name	Type	Description
	Possible values: - no : ntl file transfer not failed - yes : ntl file transfer failed	
omci-failure	Parameter type: <Gpon::omciFailure> (no yes) Possible values: - no : omci file transfer not failed - yes : omci file transfer failed	omci file transfer failure. <i>This element is only shown in detail mode.</i>
ontflash-failure	Parameter type: <Gpon::ontFlashFail> (no yes) Possible values: - no : ont flash writing not failed - yes : ont flash writing failed	ont flash write failure. <i>This element is only shown in detail mode.</i>
ontswact-failure	Parameter type: <Gpon::ontSwActFail> (no yes) Possible values: - no : ont software activate not failed - yes : ont software activate failed	ont software activation failure. <i>This element is only shown in detail mode.</i>
download-file-notfound	Parameter type: <Gpon::noDldFile> (no yes) Possible values: - no : download file found - yes : download file not found	download file not found. <i>This element is always shown.</i>
no-matching-software	Parameter type: <Gpon::noMatch> (no yes) Possible values: - no : sw entry found in ctrl table - yes : sw entry not found in table	entry match not found in sw ctrl table. <i>This element is only shown in detail mode.</i>
sw-version-mismatch	Parameter type: <Gpon::swVerMisMatch> (no yes) Possible values: - no : software version match - yes : software version mismatch	software version mismatch. <i>This element is always shown.</i>
sw-download-failure	Parameter type: <Gpon::swDlFail> (no yes) Possible values: - no : software download not failed - yes : software download failed	software download failed. <i>This element is always shown.</i>
sw-delayactivate	Parameter type: <Gpon::swDelayActivate> (no yes) Possible values: - no : no delay activation pending - yes : delay activation pending	software activation delayed. <i>This element is always shown.</i>
sw-download-pending	Parameter type: <Gpon::downloadPending> (no yes) Possible values: - no : no download activity pending - yes : download activity pending	sw download activity is pending. <i>This element is only shown in detail mode.</i>

92.8 ONT Data Store Status Command

Command Description

This command reports information on the latest ont data dump/save.

User Level

The command can be accessed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

> show equipment ont data-store [(ont-idx)]

Command Parameters

Table 92.8-1 "ONT Data Store Status Command" Resource Parameters

Resource Identifier	Type	Description
(ont-idx)	Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> ng2 : <Ng2::ChannelGroup> / <Ng2::SubchannelGroup> / <Ng2::OntId>) Possible values: - ng2 : ngpon2 style identification Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Ng2::ChannelGroup> - channel group number Field type <Ng2::SubchannelGroup> - subchannel group number Field type <Eqpt::OntId> - the ONT identifier Field type <Ng2::OntId> - the ONT identifier	access identifier for the ont

Command Output

Table 92.8-2 "ONT Data Store Status Command" Display parameters

Specific Information

name	Type	Description
ont-status	Parameter type: <Gpon::OntDataStatus> (unknown notsupported reported) Possible values: - unknown : unknown (olt has not yet communicated with ont) - notsupported : ont does not support data store feature - reported : dumpdate and dumptime reported by the ont	current status ont data save. <i>This element is always shown.</i>
last-dump-time	Parameter type: <Gpon::OntLastUpdateTime> - the time (yyyy-mm-dd:hour:minutes:secs) - unit: UTC	date of the last data dump/save. <i>This element is always shown.</i>

92.9 ONT Optics Status Command

Command Description

This command reports a summary of current optical power levels between the olt and a specific ont.

User Level

The command can be accessed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

> show equipment ont optics [(ont-idx)]

Command Parameters

Table 92.9-1 "ONT Optics Status Command" Resource Parameters

Resource Identifier	Type	Description
(ont-idx)	Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> ng2 : <Ng2::ChannelGroup> / <Ng2::SubchannelGroup> / <Ng2::OntId>) Possible values: - ng2 : ngpon2 style identification Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Ng2::ChannelGroup> - channel group number Field type <Ng2::SubchannelGroup> - subchannel group number Field type <Eqpt::OntId> - the ONT identifier Field type <Ng2::OntId> - the ONT identifier	access identifier for the ont

Command Output

Table 92.9-2 "ONT Optics Status Command" Display parameters

Specific Information

name	Type	Description
rx-signal-level	Parameter type: <Gpon::OntOpticalSignalLevel> (unknown unsupported <Gpon::OpticalSignalLevel>) Possible values: - unknown : olt has not yet communicated with ont - unsupported : ont does not support the measurement of this attribute Field type <Gpon::OpticalSignalLevel> - ont receive / transmit optical signal level - unit: dbm - range: [-65.536...65.538]	indicates the current measurement of the ont receive optical signal level in dBm . <i>This element is always shown.</i>
tx-signal-level	Parameter type: <Gpon::OntOpticalSignalLevel> (unknown unsupported <Gpon::OpticalSignalLevel>) Possible values: - unknown : olt has not yet communicated with ont - unsupported : ont does not support the measurement of this attribute Field type <Gpon::OpticalSignalLevel> - ont receive / transmit optical signal level - unit: dbm - range: [-65.536...65.538]	indicates the current measurement of the ont transmit optical signal level in dBm . <i>This element is always shown.</i>
ont-temperature	Parameter type: <Gpon::OntTemperature> (unknown unsupported <Gpon::OntTemperature>) Possible values: - unknown : olt has not yet communicated with ont - unsupported : ont does not support the measurement of this attribute Field type <Gpon::OntTemperature> - temperature of ont optical module - unit: degree C - range: [-128...128.004]	indicates the current temperature of the optics module associated with this ont. <i>This element is always shown.</i>
ont-voltage	Parameter type: <Gpon::OntVoltage> (unknown unsupported <Gpon::OntVoltage>) Possible values: - unknown : olt has not yet communicated with ont - unsupported : ont does not support the measurement of this attribute Field type <Gpon::OntVoltage> - power feed voltage of ont optical module - unit: Volts - range: [-655.36...655.38]	indicates the current voltage of the optics module associated with this ont. <i>This element is always shown.</i>
laser-bias-curr	Parameter type: <Gpon::OntLaserBias> (unknown unsupported <Gpon::LaserBias>) Possible values: - unknown : olt has not yet communicated with ont - unsupported : ont does not support the measurement of this attribute Field type <Gpon::LaserBias>	indicates the current bias current of the laser associated with this ont. <i>This element is always shown.</i>

92 ONT Status Commands

name	Type	Description
	- indicates the bias current of the laser - unit: uA - range: [0...131074]	
olt-rx-sig-level	Parameter type: <Gpon::OntOltRxSignalLevel> (invalid unsupported <Gpon::OltRxSignalLevel>) Possible values: - invalid : valid measurement is currently unattainable for some reason - unsupported : measurement functionality is not supported Field type <Gpon::OltRxSignalLevel> - measurement of the ont receive optical signal level in dBm - unit: dbm - range: [-50...0,6553.4...6553.5]	indicates the current level of the ONT's optical signal(as measured at olt-side) <i>This element is always shown.</i>

92.10 ONT Optics History Status Command

Command Description

This command reports the history of optical power levels between the olt and a specific ont.

User Level

The command can be accessed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

```
> show equipment ont optics-history [ (ont-idx) ]
```

Command Parameters

Table 92.10-1 "ONT Optics History Status Command" Resource Parameters

Resource Identifier	Type	Description
(ont-idx)	Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> ng2 : <Ng2::ChannelGroup> / <Ng2::SubchannelGroup> / <Ng2::OntId>) Possible values: - ng2 : ngpon2 style identification Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Ng2::ChannelGroup> - channel group number Field type <Ng2::SubchannelGroup> - subchannel group number Field type <Eqpt::OntId> - the ONT identifier Field type <Ng2::OntId> - the ONT identifier	access identifier for the ont

Command Output

Table 92.10-2 "ONT Optics History Status Command" Display parameters

Specific Information

92 ONT Status Commands

name	Type	Description
last-update-time	Parameter type: <Gpon::OntLastUpdateTime> - the time (yyyy-mm-dd:hour:minutes:secs) - unit: UTC	date of the last data dump/save. <i>This element is always shown.</i>
ont-rx-signal-level	Parameter type: <Gpon::OntOpticalSignalLevel> (unknown unsupported <Gpon::OpticalSignalLevel>) Possible values: - unknown : olt has not yet communicated with ont - unsupported : ont does not support the measurement of this attribute Field type <Gpon::OpticalSignalLevel> - ont receive / transmit optical signal level - unit: dbm - range: [-65.536...65.538]	indicates the daily measurement of the ont receive optical signal level in dBm . <i>This element is always shown.</i>
ont-tx-signal-level	Parameter type: <Gpon::OntOpticalSignalLevel> (unknown unsupported <Gpon::OpticalSignalLevel>) Possible values: - unknown : olt has not yet communicated with ont - unsupported : ont does not support the measurement of this attribute Field type <Gpon::OpticalSignalLevel> - ont receive / transmit optical signal level - unit: dbm - range: [-65.536...65.538]	indicates the daily measurement of the ont transmit optical signal level in dBm . <i>This element is always shown.</i>
ont-temperature	Parameter type: <Gpon::OntTemperature> (unknown unsupported <Gpon::OntTemperature>) Possible values: - unknown : olt has not yet communicated with ont - unsupported : ont does not support the measurement of this attribute Field type <Gpon::OntTemperature> - temperature of ont optical module - unit: degree C - range: [-128...128.004]	indicates the daily temperature of the optics module associated with this ont. <i>This element is always shown.</i>
ont-voltage	Parameter type: <Gpon::OntVoltage> (unknown unsupported <Gpon::OntVoltage>) Possible values: - unknown : olt has not yet communicated with ont - unsupported : ont does not support the measurement of this attribute Field type <Gpon::OntVoltage> - power feed voltage of ont optical module - unit: Volts - range: [-655.36...655.38]	indicates the daily voltage of the optics module associated with this ont. <i>This element is always shown.</i>
ont-laser-bias-curr	Parameter type: <Gpon::OntLaserBias> (unknown unsupported <Gpon::LaserBias>) Possible values: - unknown : olt has not yet communicated with ont	indicates the daily bias current of the laser associated with this ont. <i>This element is always shown.</i>

name	Type	Description
	- unsupported : ont does not support the measurement of this attribute - Field type <Gpon::LaserBias> - indicates the bias current of the laser - unit: uA - range: [0...131074]	
olt-rx-signal-level	Parameter type: <Gpon::OntOltRxSignalLevel> (invalid unsupported <Gpon::OltRxSignalLevel>) Possible values: - invalid : valid measurement is currently unattainable for some reason - unsupported : measurement functionality is not supported Field type <Gpon::OltRxSignalLevel> - measurement of the ont receive optical signal level in dBm - unit: dbm - range: [-50...0,6553.4...6553.5]	indicates the daily measurement of the ont receive optical signal level in dBm. <i>This element is always shown.</i>
olt-tx-signal-level	Parameter type: <Gpon::OntOltTxSignalLevel> (invalid unsupported <Gpon::OltTxSignalLevel>) Possible values: - invalid : valid measurement is currently unattainable for some reason - unsupported : measurement functionality is not supported Field type <Gpon::OltTxSignalLevel> - measurement of the ont transmit optical signal level in dBm - unit: dbm - range: [-30...30,6553.4...6553.5]	indicates the daily measurement of the ont transmit optical signal level in dBm. <i>This element is always shown.</i>
olt-temperature	Parameter type: <Gpon::OntOltTemp> (invalid unsupported <Gpon::OltTemp>) Possible values: - invalid : valid measurement is currently unattainable for some reason - unsupported : measurement functionality is not supported Field type <Gpon::OltTemp> - temperature of the optics module - unit: degree C - range: [-100...100,655.34...655.35]	Indicates the daily temperature of the optics module associated with this pon. <i>This element is always shown.</i>
olt-voltage	Parameter type: <Gpon::OntOltPwrFeedVoltage> (invalid unsupported <Gpon::OntOltVoltage>) Possible values: - invalid : valid measurement is currently unattainable for some reason - unsupported : measurement functionality is not supported Field type <Gpon::OntOltVoltage> - temperature of the optics module - unit: Volts - range: [0...20,655.34...655.35]	indicates the daily voltage of the optics module associated with this pon. <i>This element is always shown.</i>
olt-laser-bias-curr	Parameter type: <Gpon::OntOltLaserBias> (invalid	indicates the daily bias current of the laser associated with this pon.

92 ONT Status Commands

name	Type	Description
	notsupported <Gpon::OntOltLaserBias>) Possible values: - invalid : valid measurement is currently unattainable for some reason - notsupported : measurement functionality is not supported Field type <Gpon::OntOltLaserBias> - bias current of the laser - unit: mA - range: [0...500,65534...65535]	This element is always shown.

92.11 ONT Power Shedding Status Command

Command Description

This command shows the power shedding status information of an ont.

User Level

The command can be accessed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

```
> show equipment ont pwr-shed [ (ont-idx) ]
```

Command Parameters

Table 92.11-1 "ONT Power Shedding Status Command" Resource Parameters

Resource Identifier	Type	Description
(ont-idx)	Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> ng2 : <Ng2::ChannelGroup> / <Ng2::SubchannelGroup> / <Ng2::OntId>) Possible values: - ng2 : ngpon2 style identification Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Ng2::ChannelGroup> - channel group number Field type <Ng2::SubchannelGroup> - subchannel group number Field type <Eqpt::OntId> - the ONT identifier Field type <Ng2::OntId> - the ONT identifier	access identifier for the ont

Command Output

Table 92.11-2 "ONT Power Shedding Status Command" Display parameters

Specific Information

92 ONT Status Commands

name	Type	Description
ont-status	Parameter type: <Gpon::OntPwrStatus> (unknown notsupported supported) Possible values: - unknown : unknown (olt has not yet communicated with ont) - notsupported : ont does not support power shedding feature - supported : ont supports power shedding status feature and status is known	indication of power shedding status feature of the ont. <i>This element is always shown.</i>
data-class	Parameter type: <Gpon::DataClass> (not-in-effect in-effect) Possible values: - not-in-effect : power shedding not in effect - in-effect : power shedding in effect	power shedding of data-class. <i>This element is always shown.</i>
voice-class	Parameter type: <Gpon::VoiceClass> (not-in-effect in-effect) Possible values: - not-in-effect : power shedding not in effect - in-effect : power shedding in effect	power shedding of voice-class. <i>This element is always shown.</i>
video-class	Parameter type: <Gpon::VideoClass> (not-in-effect in-effect) Possible values: - not-in-effect : power shedding not in effect - in-effect : power shedding in effect	power shedding of video-class. <i>This element is always shown.</i>
dsl-class	Parameter type: <Gpon::DslClass> (not-in-effect in-effect) Possible values: - not-in-effect : power shedding not in effect - in-effect : power shedding in effect	power shedding of dsl-class. <i>This element is always shown.</i>
ces-class	Parameter type: <Gpon::CesClass> (not-in-effect in-effect) Possible values: - not-in-effect : power shedding not in effect - in-effect : power shedding in effect	power shedding of ces-class. <i>This element is always shown.</i>

92.12 GPON ont Olt-side on-demand Aggregate gem Current-Interval Performance Monitoring Command

Command Description

This command retrieves OLT-side TC layer (GEM-based) current interval performance monitoring data for the ONT

User Level

The command can be accessed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

```
> show equipment ont tc-layer olt-side-on-demand current-interval [ (ont-idx) ]
```

Command Parameters

Table 92.12-1 "GPON ont Olt-side on-demand Aggregate gem Current-Interval Performance Monitoring Command" Resource Parameters

Resource Identifier	Type	Description
(ont-idx)	Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> ng2 : <Ng2::ChannelGroup> / <Ng2::SubchannelGroup> / <Ng2::OntId>) Possible values: - ng2 : ngpon2 style identification Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Ng2::ChannelGroup> - channel group number Field type <Ng2::SubchannelGroup> - subchannel group number Field type <Eqpt::OntId> - the ONT identifier	identification of ont

Resource Identifier	Type	Description
	Field type <Ng2::OntId> - the ONT identifier	

Command Output

Table 92.12-2 "GPON ont Olt-side on-demand Aggregate gem Current-Interval Performance Monitoring Command" Display parameters

Specific Information		
name	Type	Description
lost-frags-down	Parameter type: <Counter> - 32 bit counter	count of lost gem fragments downstream <i>This element is always shown.</i>
lost-frags-up	Parameter type: <Counter> - 32 bit counter	count of lost gem fragments upstream <i>This element is always shown.</i>
receive-frags	Parameter type: <Counter> - 32 bit counter	count of receive gem fragments <i>This element is always shown.</i>
transmit-frags	Parameter type: <Counter> - 32 bit counter	count of transmitted gem fragments <i>This element is always shown.</i>
receive-blocks	Parameter type: <OctetCounter64> - 64 bit counter,range:[0-9223372036854775808]	count of receive gem blocks <i>This element is always shown.</i>
transmit-blocks	Parameter type: <OctetCounter64> - 64 bit counter,range:[0-9223372036854775808]	count of transmitted gem blocks <i>This element is always shown.</i>

92.13 GPON ont Olt-side on-demand aggregate gem Previous-Interval Performance Monitoring Command

Command Description

This command retrieves OLT-side TC layer (GEM-based) previous interval performance monitoring data for the ONT.

User Level

The command can be accessed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

```
> show equipment ont tc-layer olt-side-on-demand previous-interval [ (ont-idx) [ interval-num <Gpon::IntervalNo> ] ]
```

Command Parameters

Table 92.13-1 "GPON ont Olt-side on-demand aggregate gem Previous-Interval Performance Monitoring Command" Resource Parameters

Resource Identifier	Type	Description
(ont-idx)	Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> ng2 : <Ng2::ChannelGroup> / <Ng2::SubchannelGroup> / <Ng2::OntId>) Possible values: - ng2 : ngpon2 style identification Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Ng2::ChannelGroup> - channel group number Field type <Ng2::SubchannelGroup> - subchannel group number Field type <Eqpt::OntId>	identification of ont

Resource Identifier	Type	Description
	- the ONT identifier Field type <Ng2::OntId> - the ONT identifier	
interval-num	Parameter type: <Gpon::IntervalNo> Format: - a number of a previous interval number - range: [1...32]	identifies prev 15min intvls, val 1 as the latest intvl

Command Output

Table 92.13-2 "GPON ont Olt-side on-demand aggregate gem Previous-Interval Performance Monitoring Command" Display parameters

Specific Information		
name	Type	Description
lost-frags-down	Parameter type: <Counter> - 32 bit counter	count of lost gem fragments downstream <i>This element is always shown.</i>
lost-frags-up	Parameter type: <Counter> - 32 bit counter	count of lost gem Fragments upstream <i>This element is always shown.</i>
receive-frags	Parameter type: <Counter> - 32 bit counter	count of recieve gem fragments <i>This element is always shown.</i>
transmit-frags	Parameter type: <Counter> - 32 bit counter	count of transmitted gem fragments <i>This element is always shown.</i>
receive-blocks	Parameter type: <OctetCounter64> - 64 bit counter,range:[0-9223372036854775808]	count of recieve gem blocks <i>This element is always shown.</i>
transmit-blocks	Parameter type: <OctetCounter64> - 64 bit counter,range:[0-9223372036854775808]	count of transmitted gem blocks <i>This element is always shown.</i>

92.14 GPON ont Ont-side aggregate gem Current-Interval Performance Monitoring Command

Command Description

This command retrieves ONT-side TC layer (GEM-based) current interval performance monitoring data for the ONT

User Level

The command can be accessed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

```
> show equipment ont tc-layer ont-side current-interval [ (ont-idx) ]
```

Command Parameters

Table 92.14-1 "GPON ont Ont-side aggregate gem Current-Interval Performance Monitoring Command" Resource Parameters

Resource Identifier	Type	Description
(ont-idx)	Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> ng2 : <Ng2::ChannelGroup> / <Ng2::SubchannelGroup> / <Ng2::OntId>) Possible values: - ng2 : ngpon2 style identification Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Ng2::ChannelGroup> - channel group number Field type <Ng2::SubchannelGroup> - subchannel group number Field type <Eqpt::OntId> - the ONT identifier	identification of ont

Resource Identifier	Type	Description
	Field type <Ng2::OntId> - the ONT identifier	

Command Output

Table 92.14-2 "GPON ont Ont-side aggregate gem Current-Interval Performance Monitoring Command" Display parameters

Specific Information		
name	Type	Description
lost-frags-down	Parameter type: <Counter> - 32 bit counter	count of lost gem fragments downstream <i>This element is always shown.</i>
lost-frags-up	Parameter type: <Counter> - 32 bit counter	count of lost gem fragments upstream <i>This element is always shown.</i>
receive-frags	Parameter type: <Counter> - 32 bit counter	count of receive gem fragments <i>This element is always shown.</i>
transmit-frags	Parameter type: <Counter> - 32 bit counter	count of transmitted gem fragments <i>This element is always shown.</i>
receive-blocks	Parameter type: <OctetCounter64> - 64 bit counter,range:[0-9223372036854775808]	count of receive gem blocks <i>This element is always shown.</i>
transmit-blocks	Parameter type: <OctetCounter64> - 64 bit counter,range:[0-9223372036854775808]	count of transmitted gem blocks <i>This element is always shown.</i>
bad-headers	Parameter type: <Counter> - 32 bit counter	count of received gem headers that are bad <i>This element is always shown.</i>

92.15 GPON ont Ont-side Aggregate gem Previous-Interval Performance Monitoring Command

Command Description

This command retrieves ONT-side TC layer (GEM-based) previous interval performance monitoring data for the ONT

User Level

The command can be accessed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

```
> show equipment ont tc-layer ont-side previous-interval [ (ont-idx) [ interval-num <Gpon::IntervalNo> ] ]
```

Command Parameters

Table 92.15-1 "GPON ont Ont-side Aggregate gem Previous-Interval Performance Monitoring Command" Resource Parameters

Resource Identifier	Type	Description
(ont-idx)	Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> ng2 : <Ng2::ChannelGroup> / <Ng2::SubchannelGroup> / <Ng2::OntId>) Possible values: - ng2 : ngpon2 style identification Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Ng2::ChannelGroup> - channel group number Field type <Ng2::SubchannelGroup> - subchannel group number Field type <Eqpt::OntId> - the ONT identifier	identification of ont

Resource Identifier	Type	Description
	Field type <Ng2::OntId> - the ONT identifier	
interval-num	Parameter type: <Gpon::IntervalNo> Format: - a number of a previous interval number - range: [1...32]	identifies prev 15min intvls, val 1 as the latest intvl

Command Output

Table 92.15-2 "GPON ont Ont-side Aggregate gem Previous-Interval Performance Monitoring Command" Display parameters

Specific Information		
name	Type	Description
lost-frags-down	Parameter type: <Counter> - 32 bit counter	count of lost gem fragments downstream <i>This element is always shown.</i>
lost-frags-up	Parameter type: <Counter> - 32 bit counter	count of lost gem fragments upstream <i>This element is always shown.</i>
receive-frags	Parameter type: <Counter> - 32 bit counter	count of recieve gem fragments <i>This element is always shown.</i>
transmit-frags	Parameter type: <Counter> - 32 bit counter	count of transmitted gem fragments <i>This element is always shown.</i>
receive-blocks	Parameter type: <OctetCounter64> - 64 bit counter, range: [0-9223372036854775808]	count of recieve gem blocks <i>This element is always shown.</i>
transmit-blocks	Parameter type: <OctetCounter64> - 64 bit counter, range: [0-9223372036854775808]	count of transmitted gem blocks <i>This element is always shown.</i>
bad-headers	Parameter type: <Counter> - 32 bit counter	count of received gem headers that are bad <i>This element is always shown.</i>

92.16 GPON ont Olt-side Always-on Aggregate gem Current-Interval Performance Monitoring Command

Command Description

This command reports OLT-side TC layer (GEM-based) current interval performance monitoring data for errored fragments

User Level

The command can be accessed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

```
> show equipment ont tc-layer olt-side current-interval [ (ont-idx) ]
```

Command Parameters

Table 92.16-1 "GPON ont Olt-side Always-on Aggregate gem Current-Interval Performance Monitoring Command" Resource Parameters

Resource Identifier	Type	Description
(ont-idx)	Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> ng2 : <Ng2::ChannelGroup> / <Ng2::SubchannelGroup> / <Ng2::OntId>) Possible values: - ng2 : ngpon2 style identification Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Ng2::ChannelGroup> - channel group number Field type <Ng2::SubchannelGroup> - subchannel group number Field type <Eqpt::OntId> - the ONT identifier	identification of ont

Resource Identifier	Type	Description
	Field type <Ng2::OntId> - the ONT identifier	

Command Output

Table 92.16-2 "GPON ont Olt-side Always-on Aggregate gem Current-Interval Performance Monitoring Command" Display parameters

Specific Information		
name	Type	Description
err-frags-up	Parameter type: <Counter> - 32 bit counter	a count of errored gem fragments (upstream) <i>This element is always shown.</i>

92.17 GPON Ont Olt-side Always-on Aggregate gem Previous-Interval Performance Monitoring Command

Command Description

This command reports command reports OLT-side TC layer (GEM-based)previous interval performance monitoring data for errored fragments for ONT

User Level

The command can be accessed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

```
> show equipment ont tc-layer olt-side previous-interval [ (ont-idx) [ interval-num <Gpon::IntervalNo> ] ]
```

Command Parameters

Table 92.17-1 "GPON Ont Olt-side Always-on Aggregate gem Previous-Interval Performance Monitoring Command" Resource Parameters

Resource Identifier	Type	Description
(ont-idx)	Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> ng2 : <Ng2::ChannelGroup> / <Ng2::SubchannelGroup> / <Ng2::OntId>) Possible values: - ng2 : ngpon2 style identification Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Ng2::ChannelGroup> - channel group number Field type <Ng2::SubchannelGroup> - subchannel group number Field type <Eqpt::OntId> - the ONT identifier	identification of ont

Resource Identifier	Type	Description
	Field type <Ng2::OntId> - the ONT identifier	
interval-num	Parameter type: <Gpon::IntervalNo> Format: - a number of a previous interval number - range: [1...32]	identifies prev 15min intvls, val 1 as the latest intvl

Command Output

Table 92.17-2 "GPON Ont Olt-side Always-on Aggregate gem Previous-Interval Performance Monitoring Command" Display parameters

Specific Information		
name	Type	Description
err-frags-up	Parameter type: <Counter> - 32 bit counter	count of errored gem fragments (upstream) <i>This element is always shown.</i>

92.18 Multicast TC-layer Current Interval Performance Data Status Command

Command Description

This command displays various statistics collected for Multicast ONT TC-layer during the current 15 minute interval of operation.

User Level

The command can be accessed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

```
> show equipment ont mcast-tc-layer ont-side current-interval [ (ont-idx) ]
```

Command Parameters

Table 92.18-1 "Multicast TC-layer Current Interval Performance Data Status Command" Resource Parameters

Resource Identifier	Type	Description
(ont-idx)	Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> ng2 : <Ng2::ChannelGroup> / <Ng2::SubchannelGroup> / <Ng2::OntId>) Possible values: - ng2 : ngpon2 style identification Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Ng2::ChannelGroup> - channel group number Field type <Ng2::SubchannelGroup> - subchannel group number Field type <Eqpt::OntId> - the ONT identifier Field type <Ng2::OntId> - the ONT identifier	ont index

Command Output

Table 92.18-2 "Multicast TC-layer Current Interval Performance Data Status Command" Display parameters

Specific Information		
name	Type	Description
lost-frags-dn	Parameter type: <Counter> - 32 bit counter	count of lost gem fragments in downstream direction <i>This element is always shown.</i>
receive-frags	Parameter type: <Counter> - 32 bit counter	count of received gem fragments <i>This element is always shown.</i>
receive-blocks	Parameter type: <Counter> - 32 bit counter	count of received gem blocks <i>This element is always shown.</i>

92.19 Multicast TC-layer Previous Interval Performance Data Status Command

Command Description

This command displays various statistics collected for Multicast ONT TC-layer over the previous 8 hours of operations which is broken in to 32 completed 15 minute intervals.

User Level

The command can be accessed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

```
> show equipment ont mcast-tc-layer ont-side previous-interval [ (ont-idx) [ interval-no <Gpon::IntervalNo> ] ]
```

Command Parameters

Table 92.19-1 "Multicast TC-layer Previous Interval Performance Data Status Command" Resource Parameters

Resource Identifier	Type	Description
(ont-idx)	Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> ng2 : <Ng2::ChannelGroup> / <Ng2::SubchannelGroup> / <Ng2::OntId>) Possible values: - ng2 : ngpon2 style identification Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Ng2::ChannelGroup> - channel group number Field type <Ng2::SubchannelGroup> - subchannel group number Field type <Eqpt::OntId> - the ONT identifier Field type <Ng2::OntId> - the ONT identifier	ont index
interval-no	Parameter type: <Gpon::IntervalNo>	identifies prev 15min intvls, val 1

Resource Identifier	Type	Description
	Format: - a number of a previous interval number - range: [1...32]	as the latest intvl

Command Output

Table 92.19-2 "Multicast TC-layer Previous Interval Performance Data Status Command" Display parameters

Specific Information		
name	Type	Description
lost-frags-dn	Parameter type: <Counter> - 32 bit counter	count of lost gem fragments in downstream direction <i>This element is always shown.</i>
receive-frags	Parameter type: <Counter> - 32 bit counter	count of received gem fragments <i>This element is always shown.</i>
receive-blocks	Parameter type: <Counter> - 32 bit counter	count of received gem blocks <i>This element is always shown.</i>

92.20 Fec TC-layer Current Interval Counters Command

Command Description

This command displays various statistics collected for Fec ONT TC-layer during the current 15 minute interval of operation.

User Level

The command can be accessed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

```
> show equipment ont fec-tc-layer ont-side current-interval [ (ont-idx) ]
```

Command Parameters

Table 92.20-1 "Fec TC-layer Current Interval Counters Command" Resource Parameters

Resource Identifier	Type	Description
(ont-idx)	Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> ng2 : <Ng2::ChannelGroup> / <Ng2::SubchannelGroup> / <Ng2::OntId>) Possible values: - ng2 : ngpon2 style identification Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Ng2::ChannelGroup> - channel group number Field type <Ng2::SubchannelGroup> - subchannel group number Field type <Eqpt::OntId> - the ONT identifier Field type <Ng2::OntId> - the ONT identifier	ont index

Command Output

Table 92.20-2 "Fec TC-layer Current Interval Counters Command" Display parameters

Specific Information		
name	Type	Description
corrected-bytes	Parameter type: <Counter> - 32 bit counter	A count of number of bytes that were corrected by the FEC function <i>This element is always shown.</i>
corrected-code-words	Parameter type: <Counter> - 32 bit counter	A count of number of code words that were corrected by the FEC function. <i>This element is always shown.</i>
uncorrected-words	Parameter type: <Counter> - 32 bit counter	A count of number of errored code words that could not be corrected by the FEC function. <i>This element is always shown.</i>
total-code-words	Parameter type: <Counter> - 32 bit counter	A count of total number of received code words. <i>This element is always shown.</i>
fec-seconds	Parameter type: <Counter> - 32 bit counter	A count seconds during which there was a forward error correction anomaly. <i>This element is always shown.</i>

92.21 Olt-side FEC TC-layer Current Interval Counters Command

Command Description

This command displays various statistics collected for olt-side FEC ONT TC-layer during the current 15 minute interval of operation.

User Level

The command can be accessed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

```
> show equipment ont fec-tc-layer olt-side current-interval [ (ont-idx) ]
```

Command Parameters

Table 92.21-1 "Olt-side FEC TC-layer Current Interval Counters Command" Resource Parameters

Resource Identifier	Type	Description
(ont-idx)	Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> ng2 : <Ng2::ChannelGroup> / <Ng2::SubchannelGroup> / <Ng2::OntId>) Possible values: - ng2 : ngpon2 style identification Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Ng2::ChannelGroup> - channel group number Field type <Ng2::SubchannelGroup> - subchannel group number Field type <Eqpt::OntId> - the ONT identifier Field type <Ng2::OntId> - the ONT identifier	ont index

Command Output

Table 92.21-2 "Olt-side FEC TC-layer Current Interval Counters Command" Display parameters

Specific Information		
name	Type	Description
corrected-bytes	Parameter type: <Counter> - 32 bit counter	A count of number of bytes that were corrected by the FEC function <i>This element is always shown.</i>
corrected-code-words	Parameter type: <Counter> - 32 bit counter	A count of number of code words that were corrected by the FEC function. <i>This element is always shown.</i>
uncorrected-words	Parameter type: <Counter> - 32 bit counter	A count of number of errored code words that could not be corrected by the FEC function. <i>This element is always shown.</i>
total-code-words	Parameter type: <Counter> - 32 bit counter	A count of total number of received code words. <i>This element is always shown.</i>

92.22 ONT Software Control List Status Command

Command Description

This command shows an list of ONT associated with the given particular ont software control id. Index is mandatory parameter.

User Level

The command can be accessed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

```
> show equipment ont sw-ctrl-list [ (sw-ctrl-idx) ]
```

Command Parameters

Table 92.22-1 "ONT Software Control List Status Command" Resource Parameters

Resource Identifier	Type	Description
(sw-ctrl-idx)	Format: - ont software control table index - range: [1...250]	ont software control table index

Command Output

Table 92.22-2 "ONT Software Control List Status Command" Display parameters

Specific Information		
name	Type	Description
ont	Parameter type: <Gpon::OntIndex> (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> ng2 : <Ng2::ChannelGroup> / <Ng2::SubchannelGroup> / <Ng2::OntId>) Possible values: - ng2 : ngpon2 style identification Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Ng2::ChannelGroup> - channel group number Field type <Ng2::SubchannelGroup>	aid of associated onts. <i>This element is always shown.</i>

92 ONT Status Commands

name	Type	Description
	- subchannel group number Field type <Eqpt::OntId> - the ONT identifier Field type <Ng2::OntId> - the ONT identifier	

92.23 GPON ont pon aggregate ethernet

Current-Interval Performance Monitoring

Command

Command Description

This command retrieves ONT-side ethernet current interval performance monitoring data for the ONT

User Level

The command can be accessed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

```
> show equipment ont ethernet current-interval [ (ont-idx) ]
```

Command Parameters

Table 92.23-1 "GPON ont pon aggregate ethernet Current-Interval Performance Monitoring Command" Resource Parameters

Resource Identifier	Type	Description
(ont-idx)	Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> ng2 : <Ng2::ChannelGroup> / <Ng2::SubchannelGroup> / <Ng2::OntId>) Possible values: - ng2 : ngpon2 style identification Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Ng2::ChannelGroup> - channel group number Field type <Ng2::SubchannelGroup> - subchannel group number Field type <Eqpt::OntId> - the ONT identifier Field type <Ng2::OntId>	identification of ont

Resource Identifier	Type	Description
	- the ONT identifier	

Command Output

Table 92.23-2 "GPON ont pon aggregate ethernet Current-Interval Performance Monitoring Command" Display parameters

Specific Information		
name	Type	Description
eth-errors-down	Parameter type: <Counter> - 32 bit counter	count of ethernet errors downstream <i>This element is always shown.</i>
eth-errors-up	Parameter type: <Counter> - 32 bit counter	count of ethernet errors upstream <i>This element is always shown.</i>
eth-frames-down	Parameter type: <OctetCounter64> - 64 bit counter,range:[0-9223372036854775808]	total count of ethernet packets downstream <i>This element is always shown.</i>
eth-frames-up	Parameter type: <OctetCounter64> - 64 bit counter,range:[0-9223372036854775808]	total count of ethernet packets upstream <i>This element is always shown.</i>
eth-bytes-down	Parameter type: <OctetCounter64> - 64 bit counter,range:[0-9223372036854775808]	count of ethernet bytes downstream <i>This element is always shown.</i>
eth-bytes-up	Parameter type: <OctetCounter64> - 64 bit counter,range:[0-9223372036854775808]	count of ethernet bytes upstream <i>This element is always shown.</i>
eth-unicast-down	Parameter type: <OctetCounter64> - 64 bit counter,range:[0-9223372036854775808]	count of ethernet unicast downstream <i>This element is only shown in detail mode.</i>
eth-unicast-up	Parameter type: <OctetCounter64> - 64 bit counter,range:[0-9223372036854775808]	count of ethernet unicast upstream <i>This element is only shown in detail mode.</i>
eth-multicast-down	Parameter type: <OctetCounter64> - 64 bit counter,range:[0-9223372036854775808]	count of ethernet multicast downstream <i>This element is only shown in detail mode.</i>
eth-multicast-up	Parameter type: <OctetCounter64> - 64 bit counter,range:[0-9223372036854775808]	count of ethernet multicast upstream <i>This element is only shown in detail mode.</i>
eth-broadcast-down	Parameter type: <OctetCounter64> - 64 bit counter,range:[0-9223372036854775808]	count of ethernet broadcast downstream <i>This element is only shown in detail mode.</i>
eth-broadcast-up	Parameter type: <OctetCounter64> - 64 bit counter,range:[0-9223372036854775808]	count of ethernet broadcast upstream <i>This element is only shown in detail mode.</i>
eth-rate-down	Parameter type: <OctetCounter64> - 64 bit counter,range:[0-9223372036854775808]	count of ethernet rate downstream <i>This element is always shown.</i>
eth-rate-up	Parameter type: <OctetCounter64> - 64 bit counter,range:[0-9223372036854775808]	count of ethernet rate upstream <i>This element is always shown.</i>

92.24 GPON ont pon Aggregate ethernet Previous-Interval Performance Monitoring Command

Command Description

This command retrieves ONT-side ethernet previous interval performance monitoring data for the ONT

User Level

The command can be accessed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

```
> show equipment ont ethernet previous-interval [ (ont-idx) [ interval-num <Gpon::IntervalNo> ] ]
```

Command Parameters

Table 92.24-1 "GPON ont pon Aggregate ethernet Previous-Interval Performance Monitoring Command" Resource Parameters

Resource Identifier	Type	Description
(ont-idx)	Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> ng2 : <Ng2::ChannelGroup> / <Ng2::SubchannelGroup> / <Ng2::OntId>) Possible values: - ng2 : ngpon2 style identification Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Ng2::ChannelGroup> - channel group number Field type <Ng2::SubchannelGroup> - subchannel group number Field type <Eqpt::OntId> - the ONT identifier Field type <Ng2::OntId>	identification of ont

Resource Identifier	Type	Description
	- the ONT identifier	
interval-num	Parameter type: <Gpon::IntervalNo> Format: - a number of a previous interval number - range: [1...32]	identifies prev 15min intvls, val 1 as the latest intvl

Command Output

Table 92.24-2 "GPON ont pon Aggregate ethernet Previous-Interval Performance Monitoring Command" Display parameters

Specific Information		
name	Type	Description
eth-errors-down	Parameter type: <Counter> - 32 bit counter	count of ethernet errors downstream <i>This element is always shown.</i>
eth-errors-up	Parameter type: <Counter> - 32 bit counter	count of ethernet errors upstream <i>This element is always shown.</i>
eth-frames-down	Parameter type: <OctetCounter64> - 64 bit counter, range: [0-9223372036854775808]	total count of ethernet packets downstream <i>This element is always shown.</i>
eth-frames-up	Parameter type: <OctetCounter64> - 64 bit counter, range: [0-9223372036854775808]	total count of ethernet packets upstream <i>This element is always shown.</i>
eth-bytes-down	Parameter type: <OctetCounter64> - 64 bit counter, range: [0-9223372036854775808]	count of ethernet bytes downstream <i>This element is always shown.</i>
eth-bytes-up	Parameter type: <OctetCounter64> - 64 bit counter, range: [0-9223372036854775808]	count of ethernet bytes upstream <i>This element is always shown.</i>
eth-unicast-down	Parameter type: <OctetCounter64> - 64 bit counter, range: [0-9223372036854775808]	count of ethernet unicast downstream <i>This element is only shown in detail mode.</i>
eth-unicast-up	Parameter type: <OctetCounter64> - 64 bit counter, range: [0-9223372036854775808]	count of ethernet unicast upstream <i>This element is only shown in detail mode.</i>
eth-multicast-down	Parameter type: <OctetCounter64> - 64 bit counter, range: [0-9223372036854775808]	count of ethernet multicast downstream <i>This element is only shown in detail mode.</i>
eth-multicast-up	Parameter type: <OctetCounter64> - 64 bit counter, range: [0-9223372036854775808]	count of ethernet multicast upstream <i>This element is only shown in detail mode.</i>
eth-broadcast-down	Parameter type: <OctetCounter64> - 64 bit counter, range: [0-9223372036854775808]	count of ethernet broadcast downstream <i>This element is only shown in detail mode.</i>
eth-broadcast-up	Parameter type: <OctetCounter64> - 64 bit counter, range: [0-9223372036854775808]	count of ethernet broadcast upstream <i>This element is only shown in detail mode.</i>
eth-rate-down	Parameter type: <OctetCounter64> - 64 bit counter, range: [0-9223372036854775808]	count of ethernet rate downstream <i>This element is always shown.</i>
eth-rate-up	Parameter type: <OctetCounter64> - 64 bit counter, range: [0-9223372036854775808]	count of ethernet rate upstream <i>This element is always shown.</i>

92.25 GPON ont pon aggregate ethernet total Performance Monitoring Command

Command Description

This command retrieves ONT-side ethernet total performance monitoring data for the ONT

User Level

The command can be accessed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

```
> show equipment ont ethernet total [ (ont-idx) ]
```

Command Parameters

Table 92.25-1 "GPON ont pon aggregate ethernet total Performance Monitoring Command" Resource Parameters

Resource Identifier	Type	Description
(ont-idx)	Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> ng2 : <Ng2::ChannelGroup> / <Ng2::SubchannelGroup> / <Ng2::OntId>) Possible values: - ng2 : ngpon2 style identification Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Ng2::ChannelGroup> - channel group number Field type <Ng2::SubchannelGroup> - subchannel group number Field type <Eqpt::OntId> - the ONT identifier Field type <Ng2::OntId> - the ONT identifier	identification of ont

Command Output

**Table 92.25-2 "GPON ont pon aggregate ethernet total Performance Monitoring Command"
Display parameters**

Specific Information		
name	Type	Description
eth-frames-down	Parameter type: <OctetCounter64> - 64 bit counter,range:[0-9223372036854775808]	total count of ethernet packets downstream <i>This element is always shown.</i>
eth-frames-up	Parameter type: <OctetCounter64> - 64 bit counter,range:[0-9223372036854775808]	total count of ethernet packets upstream <i>This element is always shown.</i>
eth-bytes-down	Parameter type: <OctetCounter64> - 64 bit counter,range:[0-9223372036854775808]	count of ethernet bytes downstream <i>This element is always shown.</i>
eth-bytes-up	Parameter type: <OctetCounter64> - 64 bit counter,range:[0-9223372036854775808]	count of ethernet bytes upstream <i>This element is always shown.</i>
eth-unicast-down	Parameter type: <OctetCounter64> - 64 bit counter,range:[0-9223372036854775808]	count of ethernet unicast downstream <i>This element is only shown in detail mode.</i>
eth-unicast-up	Parameter type: <OctetCounter64> - 64 bit counter,range:[0-9223372036854775808]	count of ethernet unicast upstream <i>This element is only shown in detail mode.</i>
eth-multicast-down	Parameter type: <OctetCounter64> - 64 bit counter,range:[0-9223372036854775808]	count of ethernet multicast downstream <i>This element is only shown in detail mode.</i>
eth-multicast-up	Parameter type: <OctetCounter64> - 64 bit counter,range:[0-9223372036854775808]	count of ethernet multicast upstream <i>This element is only shown in detail mode.</i>
eth-broadcast-down	Parameter type: <OctetCounter64> - 64 bit counter,range:[0-9223372036854775808]	count of ethernet broadcast downstream <i>This element is only shown in detail mode.</i>
eth-broadcast-up	Parameter type: <OctetCounter64> - 64 bit counter,range:[0-9223372036854775808]	count of ethernet broadcast upstream <i>This element is only shown in detail mode.</i>

92.26 Olt-side Physical-layer Current Interval Counters Command

Command Description

This command displays various statistics collected at the ONT for olt-side physical-layer during the current 15 minute interval of operation.

User Level

The command can be accessed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

```
> show equipment ont phy-layer olt-side current-interval [ (ont-idx) ]
```

Command Parameters

Table 92.26-1 "Olt-side Physical-layer Current Interval Counters Command" Resource Parameters

Resource Identifier	Type	Description
(ont-idx)	Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> ng2 : <Ng2::ChannelGroup> / <Ng2::SubchannelGroup> / <Ng2::OntId>) Possible values: - ng2 : ngpon2 style identification Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Ng2::ChannelGroup> - channel group number Field type <Ng2::SubchannelGroup> - subchannel group number Field type <Eqpt::OntId> - the ONT identifier Field type <Ng2::OntId> - the ONT identifier	ont index

Command Output

Table 92.26-2 "Olt-side Physical-layer Current Interval Counters Command" Display parameters

Specific Information		
name	Type	Description
bip32-prot-words	Parameter type: <OctetCounter64> - 64 bit counter,range:[0-9223372036854775808]	A count of total number of BIP32 words on physical-layer <i>This element is always shown.</i>
bip32-bit-errors	Parameter type: <OctetCounter64> - 64 bit counter,range:[0-9223372036854775808]	A count of number of BIP32 errors on physical-layer <i>This element is always shown.</i>

92.27 XGPON ONT Ont-side tc-layer

Current-Interval Performance Monitoring

Command

Command Description

This command retrieves XGPON ONT-side TC layer (GEM-based) current interval performance monitoring data for the ONT

User Level

The command can be accessed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

```
> show equipment ont xg-tc-layer ont-side current-interval [ (ont-idx) ]
```

Command Parameters

Table 92.27-1 "XGPON ONT Ont-side tc-layer Current-Interval Performance Monitoring Command" Resource Parameters

Resource Identifier	Type	Description
(ont-idx)	Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> ng2 : <Ng2::ChannelGroup> / <Ng2::SubchannelGroup> / <Ng2::OntId>) Possible values: - ng2 : ngpon2 style identification Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Ng2::ChannelGroup> - channel group number Field type <Ng2::SubchannelGroup> - subchannel group number Field type <Eqpt::OntId> - the ONT identifier	identification of ont

Resource Identifier	Type	Description
	Field type <Ng2::OntId> - the ONT identifier	

Command Output

Table 92.27-2 "XGPON ONT Ont-side tc-layer Current-Interval Performance Monitoring Command" Display parameters

Specific Information		
name	Type	Description
hec-errs	Parameter type: <Counter> - 32 bit counter	count of lost gem fragments downstream <i>This element is always shown.</i>
key-errs	Parameter type: <Counter> - 32 bit counter	count of lost gem fragments upstream <i>This element is always shown.</i>
psb-hec	Parameter type: <Counter> - 32 bit counter	This attribute counts HEC errors in any of the fields of the downstream physical sync block. <i>This element is always shown.</i>
xh-tc	Parameter type: <Counter> - 32 bit counter	HEC errors detected in the XGTC header. <i>This element is always shown.</i>
unknow-prof	Parameter type: <Counter> - 32 bit counter	the number of grants received whose specified profile was not known to the ONU <i>This element is always shown.</i>
tr-xgem-frame	Parameter type: <Counter> - 32 bit counter	the number of non-idle XGEM frames transmitted <i>This element is always shown.</i>
frag-xgem-fram	Parameter type: <Counter> - 32 bit counter	counts the number of non-idle XGEM frames transmitted <i>This element is always shown.</i>
xgem-lostword	Parameter type: <Counter> - 32 bit counter	counts the number of non-idle XGEM frames transmitted <i>This element is always shown.</i>

92.28 XGPON ONT Ont-side tc-layer Previous-Interval Performance Monitoring Command

Command Description

This command retrieves XGPON ONT-side TC layer (GEM-based) previous interval performance monitoring data for the ONT

User Level

The command can be accessed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

```
> show equipment ont xg-tc-layer ont-side previous-interval [ (ont-idx) [ interval-no <Gpon::IntervalNo> ] ]
```

Command Parameters

Table 92.28-1 "XGPON ONT Ont-side tc-layer Previous-Interval Performance Monitoring Command" Resource Parameters

Resource Identifier	Type	Description
(ont-idx)	Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> ng2 : <Ng2::ChannelGroup> / <Ng2::SubchannelGroup> / <Ng2::OntId>) Possible values: - ng2 : ngpon2 style identification Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Ng2::ChannelGroup> - channel group number Field type <Ng2::SubchannelGroup> - subchannel group number Field type <Eqpt::OntId> - the ONT identifier	ont index

Resource Identifier	Type	Description
	Field type <Ng2::OntId> - the ONT identifier	
interval-no	Parameter type: <Gpon::IntervalNo> Format: - a number of a previous interval number - range: [1...32]	identifies prev 15min intvls, val 1 as the latest intvl

Command Output

Table 92.28-2 "XGPON ONT Ont-side tc-layer Previous-Interval Performance Monitoring Command" Display parameters

Specific Information		
name	Type	Description
hec-errs	Parameter type: <Counter> - 32 bit counter	count of hec errors <i>This element is always shown.</i>
key-errs	Parameter type: <Counter> - 32 bit counter	count of key errors <i>This element is always shown.</i>
psb-hec	Parameter type: <Counter> - 32 bit counter	This attribute counts HEC errors in any of the fields of the downstream physical sync block. <i>This element is always shown.</i>
xg-tc	Parameter type: <Counter> - 32 bit counter	This attribute counts HEC errors detected in the XGTC header . <i>This element is always shown.</i>
unknow-prof	Parameter type: <Counter> - 32 bit counter	This attribute counts the number of grants received whose specified profile was not known to the ONU. <i>This element is always shown.</i>
tr-xgem-frame	Parameter type: <Counter> - 32 bit counter	This attribute counts the number of non-idle XGEM frames transmitted. If an SDU is fragmented, each fragment is an XGEM frame and is counted as such. <i>This element is always shown.</i>
frag-xgem-fram	Parameter type: <Counter> - 32 bit counter	This attribute counts the number of XGEM frames that represent fragmented SDUs, as indicated by the LF bit =0. <i>This element is always shown.</i>
xgem-lostword	Parameter type: <Counter> - 32 bit counter	This attribute counts the number of four-byte words lost because of an XGEM frame HEC error. In general, all XGTC payload following the error is lost, until the next PSBd event. <i>This element is always shown.</i>

92.29 XGPON ONT Olt-side tc-layer Current-Interval Performance Monitoring Command

Command Description

This command retrieves XGPON OLT-side TC layer (GEM-based) current interval performance monitoring data for the ONT

User Level

The command can be accessed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

```
> show equipment ont xg-tc-layer olt-side current-interval [ (ont-idx) ]
```

Command Parameters

Table 92.29-1 "XGPON ONT Olt-side tc-layer Current-Interval Performance Monitoring Command" Resource Parameters

Resource Identifier	Type	Description
(ont-idx)	Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> ng2 : <Ng2::ChannelGroup> / <Ng2::SubchannelGroup> / <Ng2::OntId>) Possible values: - ng2 : ngpon2 style identification Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Ng2::ChannelGroup> - channel group number Field type <Ng2::SubchannelGroup> - subchannel group number Field type <Eqpt::OntId> - the ONT identifier Field type <Ng2::OntId> - the ONT identifier	identification of ont

Command Output

Table 92.29-2 "XGPON ONT Olt-side tc-layer Current-Interval Performance Monitoring Command" Display parameters

Specific Information		
name	Type	Description
hec-errs	Parameter type: <Counter> - 32 bit counter	count of lost gem fragments downstream <i>This element is always shown.</i>
key-errs	Parameter type: <Counter> - 32 bit counter	count of lost gem fragments upstream <i>This element is always shown.</i>
rng-time-msgs	Parameter type: <Counter> - 32 bit counter	count of recieve gem fragments <i>This element is always shown.</i>

92.30 XGPON ONT Olt-side tc-layer Previous-Interval Performance Monitoring Command

Command Description

This command retrieves XGPON OLT-side TC layer (GEM-based) previous interval performance monitoring data for the ONT

User Level

The command can be accessed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

```
> show equipment ont xg-tc-layer olt-side previous-interval [ (ont-idx) [ interval-no <Gpon::IntervalNo> ] ]
```

Command Parameters

Table 92.30-1 "XGPON ONT Olt-side tc-layer Previous-Interval Performance Monitoring Command" Resource Parameters

Resource Identifier	Type	Description
(ont-idx)	Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> ng2 : <Ng2::ChannelGroup> / <Ng2::SubchannelGroup> / <Ng2::OntId>) Possible values: - ng2 : ngpon2 style identification Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Ng2::ChannelGroup> - channel group number Field type <Ng2::SubchannelGroup> - subchannel group number Field type <Eqpt::OntId> - the ONT identifier	ont index

Resource Identifier	Type	Description
	Field type <Ng2::OntId> - the ONT identifier	
interval-no	Parameter type: <Gpon::IntervalNo> Format: - a number of a previous interval number - range: [1...32]	identifies prev 15min intvls, val 1 as the latest intvl

Command Output

Table 92.30-2 "XGPON ONT Olt-side tc-layer Previous-Interval Performance Monitoring Command" Display parameters

Specific Information		
name	Type	Description
hec-errs	Parameter type: <Counter> - 32 bit counter	count of hec errors <i>This element is always shown.</i>
key-errs	Parameter type: <Counter> - 32 bit counter	count of key errors <i>This element is always shown.</i>
rng-time-msgs	Parameter type: <Counter> - 32 bit counter	A count of number of ranging time messages that were sent for this ONT. <i>This element is always shown.</i>

92.31 ONT Utilization Current Interval PM Command

Command Description

This command retrieves ONT utilization current interval performance monitoring data.

User Level

The command can be accessed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

> show equipment ont utilization current-interval [(ont-idx)]

Command Parameters

Table 92.31-1 "ONT Utilization Current Interval PM Command" Resource Parameters

Resource Identifier	Type	Description
(ont-idx)	Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> ng2 : <Ng2::ChannelGroup> / <Ng2::SubchannelGroup> / <Ng2::OntId>) Possible values: - ng2 : ngpon2 style identification Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Ng2::ChannelGroup> - channel group number Field type <Ng2::SubchannelGroup> - subchannel group number Field type <Eqpt::OntId> - the ONT identifier Field type <Ng2::OntId> - the ONT identifier	identification of ONT

Command Output

Table 92.31-2 "ONT Utilization Current Interval PM Command" Display parameters

Specific Information		
name	Type	Description
txucfrm	Parameter type: <OctetCounter64> - 64 bit counter,range:[0-9223372036854775808]	count of total unicast frames transmitted downstream on the PON or channel-pair for that ONT <i>This element is always shown.</i>
rxucfrm	Parameter type: <OctetCounter64> - 64 bit counter,range:[0-9223372036854775808]	count of total unicast frames transmitted upstream on the PON or channel-pair for that ONT <i>This element is always shown.</i>
txucdropfrm	Parameter type: <OctetCounter64> - 64 bit counter,range:[0-9223372036854775808]	count of total unicast frames dropped on the PON or channel-pair destined for that ONT <i>This element is always shown.</i>
rxucdropfrm	Parameter type: <OctetCounter64> - 64 bit counter,range:[0-9223372036854775808]	count of total unicast bytes dropped on the PON or channel-pair from that ONT <i>This element is always shown.</i>
txucbyte	Parameter type: <OctetCounter64> - 64 bit counter,range:[0-9223372036854775808]	count of total unicast bytes transmitted downstream on the PON or channel-pair for that ONT <i>This element is only shown in detail mode.</i>
rxucbyte	Parameter type: <OctetCounter64> - 64 bit counter,range:[0-9223372036854775808]	count of total unicast bytes transmitted upstream on the PON or channel-pair for that ONT <i>This element is only shown in detail mode.</i>
txucdropbyte	Parameter type: <OctetCounter64> - 64 bit counter,range:[0-9223372036854775808]	count of total unicast bytes dropped on the PON or channel-pair destined for that ONT <i>This element is only shown in detail mode.</i>
rxucdropbyte	Parameter type: <OctetCounter64> - 64 bit counter,range:[0-9223372036854775808]	count of total unicast bytes dropped on the PON or channel-pair from that ONT <i>This element is only shown in detail mode.</i>

92.32 ONT Utilization Previous Interval PM Command

Command Description

This command retrieves ONT utilization previous interval performance monitoring data.

User Level

The command can be accessed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

```
> show equipment ont utilization previous-interval [ (ont-idx) [ interval-num <Gpon::FiveMinIntvlNo> ] ]
```

Command Parameters

Table 92.32-1 "ONT Utilization Previous Interval PM Command" Resource Parameters

Resource Identifier	Type	Description
(ont-idx)	Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> ng2 : <Ng2::ChannelGroup> / <Ng2::SubchannelGroup> / <Ng2::OntId>) Possible values: - ng2 : ngpon2 style identification Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Ng2::ChannelGroup> - channel group number Field type <Ng2::SubchannelGroup> - subchannel group number Field type <Eqpt::OntId> - the ONT identifier Field type <Ng2::OntId> - the ONT identifier	identification of ONT
interval-num	Parameter type: <Gpon::FiveMinIntvlNo> Format: - a number of a previous five minute interval number	identifies prev five-min interval (1 is the most recent)

Resource Identifier	Type	Description
	- range: [1...288]	

Command Output

Table 92.32-2 "ONT Utilization Previous Interval PM Command" Display parameters

Specific Information		
name	Type	Description
txucfrm	Parameter type: <OctetCounter64> - 64 bit counter,range:[0-9223372036854775808]	count of total unicast frames transmitted downstream on the PON or channel-pair for that ONT <i>This element is always shown.</i>
rxucfrm	Parameter type: <OctetCounter64> - 64 bit counter,range:[0-9223372036854775808]	count of total unicast frames transmitted upstream on the PON or channel-pair for that ONT <i>This element is always shown.</i>
txucdropfrm	Parameter type: <OctetCounter64> - 64 bit counter,range:[0-9223372036854775808]	count of total unicast frames dropped on the PON or channel-pair destined for that ONT <i>This element is always shown.</i>
rxucdropfrm	Parameter type: <OctetCounter64> - 64 bit counter,range:[0-9223372036854775808]	count of total unicast bytes dropped on the PON or channel-pair from that ONT <i>This element is always shown.</i>
txucbyte	Parameter type: <OctetCounter64> - 64 bit counter,range:[0-9223372036854775808]	count of total unicast bytes transmitted downstream on the PON or channel-pair for that ONT <i>This element is only shown in detail mode.</i>
rxucbyte	Parameter type: <OctetCounter64> - 64 bit counter,range:[0-9223372036854775808]	count of total unicast bytes transmitted upstream on the PON or channel-pair for that ONT <i>This element is only shown in detail mode.</i>
txucdropbyte	Parameter type: <OctetCounter64> - 64 bit counter,range:[0-9223372036854775808]	count of total unicast bytes dropped on the PON or channel-pair destined for that ONT <i>This element is only shown in detail mode.</i>
rxucdropbyte	Parameter type: <OctetCounter64> - 64 bit counter,range:[0-9223372036854775808]	count of total unicast bytes dropped on the PON or channel-pair from that ONT <i>This element is only shown in detail mode.</i>

92.33 ONT Configure File Download Status Command

Command Description

This command shows individual ont fine-grain status associated with any configure file download activity.

User Level

The command can be accessed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

> show equipment ont cfg-download [(ont-idx)]

Command Parameters

Table 92.33-1 "ONT Configure File Download Status Command" Resource Parameters

Resource Identifier	Type	Description
(ont-idx)	Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> ng2 : <Ng2::ChannelGroup> / <Ng2::SubchannelGroup> / <Ng2::OntId>) Possible values: - ng2 : ngpon2 style identification Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Ng2::ChannelGroup> - channel group number Field type <Ng2::SubchannelGroup> - subchannel group number Field type <Eqpt::OntId> - the ONT identifier Field type <Ng2::OntId> - the ONT identifier	current operational parameters for the ont

Command Output

Table 92.33-2 "ONT Configure File Download Status Command" Display parameters

Specific Information		
name	Type	Description
planned	Parameter type: <Gpon::notPlnd> (no yes) Possible values: - no : ont is planned - yes : ont is not planned	ont is not planned. <i>This element is always shown.</i>
inactive	Parameter type: <Gpon::inAct> (no yes) Possible values: - no : ont is active - yes : ont is not active	ont is not active. <i>This element is only shown in detail mode.</i>
cfg1-planned-notok	Parameter type: <Gpon::cfgNokPlnd> (no yes) Possible values: - no : planned configure file is active - yes : planned configure file is not active	planned configure file 1 did not equal to active. <i>This element is only shown in detail mode.</i>
cfg1-dld-notok	Parameter type: <Gpon::cfgNokDld> (no yes) Possible values: - no : download configure file is in active or passive - yes : download configure file is not active or passive	download configure file 1 did not equal to active / passive. <i>This element is only shown in detail mode.</i>
cfg1-dld-inprogress	Parameter type: <Gpon::dldInProg> (no yes) Possible values: - no : download not started - yes : download started	configure file 1 download activity in progress. <i>This element is always shown.</i>
cfg1-ntlt-inprogress	Parameter type: <Gpon::ntltInProg> (no yes) Possible values: - no : ntlt file transfer not in progress - yes : ntlt file transfer in progress	configure file 1 ntlt file transfer in progress. <i>This element is always shown.</i>
cfg1-omci-inprogress	Parameter type: <Gpon::omciInProg> (no yes) Possible values: - no : omci file transfer not in progress - yes : omci file transfer in progress	configure file 1 omci file transfer in progress. <i>This element is always shown.</i>
cfg1-flash-inprogress	Parameter type: <Gpon::ontFlashInProg> (no yes) Possible values: - no : ont write not in progress - yes : ont flash in progress	configure file 1 ont flash in progress. <i>This element is only shown in detail mode.</i>
cfg1-act-inprogress	Parameter type: <Gpon::ontCfgActInProg> (no yes) Possible values: - no : ont configure file activation not in progress - yes : ont configure file activation in progress	ont configure file 1 activation is progress. <i>This element is always shown.</i>

92 ONT Status Commands

name	Type	Description
cfg1-ntlt-failure	Parameter type: <Gpon::ntltFailure> (no yes) Possible values: - no : ntlt file transfer not failed - yes : ntlt file transfer failed	configure file 1 ntlt file transfer failure. <i>This element is only shown in detail mode.</i>
cfg1-omci-failure	Parameter type: <Gpon::omciFailure> (no yes) Possible values: - no : omci file transfer not failed - yes : omci file transfer failed	configure file 1 omci file transfer failure. <i>This element is only shown in detail mode.</i>
cfg1-ontflash-failure	Parameter type: <Gpon::ontFlashFail> (no yes) Possible values: - no : ont flash writing not failed - yes : ont flash writing failed	configure file 1 ont flash write failure. <i>This element is only shown in detail mode.</i>
ontcfg1act-failure	Parameter type: <Gpon::ontCfgActFail> (no yes) Possible values: - no : ont configure file activate not failed - yes : ont configure file activate failed	ont configure file 1 activation failure. <i>This element is only shown in detail mode.</i>
dld-cfgfile1-notfound	Parameter type: <Gpon::noDldFile> (no yes) Possible values: - no : download file found - yes : download file not found	download configure file 1 not found. <i>This element is only shown in detail mode.</i>
no-matching-cfgfile1	Parameter type: <Gpon::cfgNoMatch> (no yes) Possible values: - no : configure file entry found in ctrl table - yes : configure file entry not found in table	entry match not found in sw ctrl table. <i>This element is only shown in detail mode.</i>
cfgfile1-mismatch	Parameter type: <Gpon::cfgFileMisMatch> (no yes) Possible values: - no : configure file match - yes : configure file mismatch	configure file 1 mismatch. <i>This element is only shown in detail mode.</i>
cfgfile1-dld-failure	Parameter type: <Gpon::cfgDlFail> (no yes) Possible values: - no : configure file download not failed - yes : configure file download failed	configure file 1 download failed. <i>This element is only shown in detail mode.</i>
cfgfile1-delayactivate	Parameter type: <Gpon::cfgDelayActivate> (no yes) Possible values: - no : no delay activation pending - yes : delay activation pending	configure file 1 activation delayed. <i>This element is only shown in detail mode.</i>
cfgfile1-dld-pending	Parameter type: <Gpon::downloadPending> (no yes)	configure file 1 download activity is pending. <i>This element is only shown in</i>

name	Type	Description
	Possible values: - no : no download activity pending - yes : download activity pending	<i>detail mode.</i>
cfg2-planned-notok	Parameter type: <Gpon::cfgNokPlnd> (no yes) Possible values: - no : planned configure file is active - yes : planned configure file is not active	planned configure file 2 did not equal to active. <i>This element is only shown in detail mode.</i>
cfg2-dld-notok	Parameter type: <Gpon::cfgNokDld> (no yes) Possible values: - no : download configure file is in active or passive - yes : download configure file is not active or passive	download configure file 2 did not equal to active / passive. <i>This element is only shown in detail mode.</i>
cfg2-dld-inprogress	Parameter type: <Gpon::dldInProg> (no yes) Possible values: - no : download not started - yes : download started	configure file 2 download activity in progress. <i>This element is always shown.</i>
cfg2-ntlt-inprogress	Parameter type: <Gpon::ntltInProg> (no yes) Possible values: - no : ntl file transfer not in progress - yes : ntl file transfer in progress	configure file 2 ntl file transfer in progress. <i>This element is always shown.</i>
cfg2-omci-inprogress	Parameter type: <Gpon::omciInProg> (no yes) Possible values: - no : omci file transfer not in progress - yes : omci file transfer in progress	configure file 2 omci file transfer in progress. <i>This element is always shown.</i>
cfg2-flash-inprogress	Parameter type: <Gpon::ontFlashInProg> (no yes) Possible values: - no : ont write not in progress - yes : ont flash in progress	configure file 2 ont flash in progress. <i>This element is only shown in detail mode.</i>
cfg2-act-inprogress	Parameter type: <Gpon::ontCfgActInProg> (no yes) Possible values: - no : ont configure file activation not in progress - yes : ont configure file activation in progress	ont configure file 2 activation is progress. <i>This element is always shown.</i>
cfg2-ntlt-failure	Parameter type: <Gpon::ntltFailure> (no yes) Possible values: - no : ntl file transfer not failed - yes : ntl file transfer failed	configure file 2 ntl file transfer failure. <i>This element is only shown in detail mode.</i>
cfg2-omci-failure	Parameter type: <Gpon::omciFailure> (no yes) Possible values: - no : omci file transfer not failed - yes : omci file transfer failed	configure file 2 omci file transfer failure. <i>This element is only shown in detail mode.</i>

92 ONT Status Commands

name	Type	Description
cfg2-ontflash-failure	Parameter type: <Gpon::ontFlashFail> (no yes) Possible values: - no : ont flash writing not failed - yes : ont flash writing failed	configure file 2 ont flash write failure. <i>This element is only shown in detail mode.</i>
ontcfg2act-failure	Parameter type: <Gpon::ontCfgActFail> (no yes) Possible values: - no : ont configure file activate not failed - yes : ont configure file activate failed	ont configure file 2 activation failure. <i>This element is only shown in detail mode.</i>
dld-cfgfile2-notfound	Parameter type: <Gpon::noDldFile> (no yes) Possible values: - no : download file found - yes : download file not found	download configure file 2 not found. <i>This element is only shown in detail mode.</i>
no-matching-cfgfile2	Parameter type: <Gpon::cfgNoMatch> (no yes) Possible values: - no : configure file entry found in ctrl table - yes : configure file entry not found in table	entry match not found in sw ctrl table. <i>This element is only shown in detail mode.</i>
cfgfile2-mismatch	Parameter type: <Gpon::cfgFileMisMatch> (no yes) Possible values: - no : configure file match - yes : configure file mismatch	configure file 2 mismatch. <i>This element is only shown in detail mode.</i>
cfgfile2-dld-failure	Parameter type: <Gpon::cfgDlFail> (no yes) Possible values: - no : configure file download not failed - yes : configure file download failed	configure file 2 download failed. <i>This element is only shown in detail mode.</i>
cfgfile2-delayactivate	Parameter type: <Gpon::cfgDelayActivate> (no yes) Possible values: - no : no delay activation pending - yes : delay activation pending	configure file 2 activation delayed. <i>This element is only shown in detail mode.</i>
cfgfile2-dld-pending	Parameter type: <Gpon::downloadPending> (no yes) Possible values: - no : no download activity pending - yes : download activity pending	configure file 2 download activity is pending. <i>This element is only shown in detail mode.</i>

92.34 ONT Configure File Download Status Command

Command Description

This command shows individual ngpon2 ont fine-grain status associated with any configure file download activity.

User Level

The command can be accessed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

```
> show equipment ont ng2-cfg-download
```

92.35 ONT Config File Download Status Per Channel Group/Sub Channel Group Command

Command Description

show individual ont fine-grain status associated with any config file download activity.

User Level

The command can be accessed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

```
> show equipment ont ng2-cfg-download channel-group [ (channel-group) [ subchannel-group
<Ng2::SubchannelGroupId> ] [ ont-id <Ng2::OntNum> ] ]
```

Command Parameters

Table 92.35-1 "ONT Config File Download Status Per Channel Group/Sub Channel Group Command" Resource Parameters

Resource Identifier	Type	Description
(channel-group)	Format: <Ng2::ChannelGroup> Field type <Ng2::ChannelGroup> - channel group number	channel group id
subchannel-group	Parameter type: <Ng2::SubchannelGroupId> Format: - subchannel group number - range: [1...4]	subchannel group id
ont-id	Parameter type: <Ng2::OntNum> Format: - ont id in a subchannel group - range: [1...256]	ont id

Command Output

Table 92.35-2 "ONT Config File Download Status Per Channel Group/Sub Channel Group Command" Display parameters

Specific Information		
name	Type	Description
ont	Parameter type: <Gpon::OntIndex> (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId>	ont ifindex <i>This element is always shown.</i>

name	Type	Description
	ng2 : <Ng2::ChannelGroup> / <Ng2::SubchannelGroup> / <Ng2::OntId>) Possible values: - ng2 : ngpon2 style identification Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Ng2::ChannelGroup> - channel group number Field type <Ng2::SubchannelGroup> - subchannel group number Field type <Eqpt::OntId> - the ONT identifier Field type <Ng2::OntId> - the ONT identifier	
planned	Parameter type: <Gpon::notPlnd> (no yes) Possible values: - no : ont is planned - yes : ont is not planned	ont is not planned. <i>This element is always shown.</i>
inactive	Parameter type: <Gpon::inAct> (no yes) Possible values: - no : ont is active - yes : ont is not active	ont is not active. <i>This element is only shown in detail mode.</i>
cfg1-planned-notok	Parameter type: <Gpon::cfgNokPlnd> (no yes) Possible values: - no : planned configure file is active - yes : planned configure file is not active	planned configure file 1 did not equal to active. <i>This element is only shown in detail mode.</i>
cfg1-dld-notok	Parameter type: <Gpon::cfgNokDld> (no yes) Possible values: - no : download configure file is in active or passive - yes : download configure file is not active or passive	download configure file 1 did not equal to active / passive. <i>This element is only shown in detail mode.</i>
cfg1-dld-inprogress	Parameter type: <Gpon::dldInProg> (no yes) Possible values: - no : download not started - yes : download started	configure file 1 download activity in progress. <i>This element is always shown.</i>
cfg1-ntlt-inprogress	Parameter type: <Gpon::ntltInProg> (no yes) Possible values: - no : ntlt file transfer not in progress - yes : ntlt file transfer in progress	configure file 1 ntlt file transfer in progress. <i>This element is always shown.</i>
cfg1-omci-inprogress	Parameter type: <Gpon::omciInProg>	configure file 1 omci file transfer

name	Type	Description
	(no yes) Possible values: - no : omci file transfer not in progress - yes : omci file transfer in progress	in progress. <i>This element is always shown.</i>
cfg1-flash-inprogress	Parameter type: <Gpon::ontFlashInProg> (no yes) Possible values: - no : ont write not in progress - yes : ont flash in progress	configure file 1 ont flash in progress. <i>This element is only shown in detail mode.</i>
cfg1-act-inprogress	Parameter type: <Gpon::ontCfgActInProg> (no yes) Possible values: - no : ont configure file activation not in progress - yes : ont configure file activation in progress	ont configure file 1 activation is progress. <i>This element is always shown.</i>
cfg1-ntlt-failure	Parameter type: <Gpon::ntltFailure> (no yes) Possible values: - no : ntlt file transfer not failed - yes : ntlt file transfer failed	configure file 1 ntlt file transfer failure. <i>This element is only shown in detail mode.</i>
cfg1-omci-failure	Parameter type: <Gpon::omciFailure> (no yes) Possible values: - no : omci file transfer not failed - yes : omci file transfer failed	configure file 1 omci file transfer failure. <i>This element is only shown in detail mode.</i>
cfg1-ontflash-failure	Parameter type: <Gpon::ontFlashFail> (no yes) Possible values: - no : ont flash writing not failed - yes : ont flash writing failed	configure file 1 ont flash write failure. <i>This element is only shown in detail mode.</i>
ontcfg1act-failure	Parameter type: <Gpon::ontCfgActFail> (no yes) Possible values: - no : ont configure file activate not failed - yes : ont configure file activate failed	ont configure file 1 activation failure. <i>This element is only shown in detail mode.</i>
dld-cfgfile1-notfound	Parameter type: <Gpon::noDldFile> (no yes) Possible values: - no : download file found - yes : download file not found	download configure file 1 not found. <i>This element is only shown in detail mode.</i>
no-matching-cfgfile1	Parameter type: <Gpon::cfgNoMatch> (no yes) Possible values: - no : configure file entry found in ctrl table - yes : configure file entry not found in table	entry match not found in sw ctrl table. <i>This element is only shown in detail mode.</i>
cfgfile1-mismatch	Parameter type: <Gpon::cfgFileMisMatch> (no yes) Possible values:	configure file 1 mismatch. <i>This element is only shown in detail mode.</i>

name	Type	Description
	- no : configure file match - yes : configure file mismatch	
cfgfile1-dld-failure	Parameter type: <Gpon::cfgDIFail> (no yes) Possible values: - no : configure file download not failed - yes : configure file download failed	configure file 1 download failed. <i>This element is only shown in detail mode.</i>
cfgfile1-delayactivate	Parameter type: <Gpon::cfgDelayActivate> (no yes) Possible values: - no : no delay activation pending - yes : delay activation pending	configure file 1 activation delayed. <i>This element is only shown in detail mode.</i>
cfgfile1-dld-pending	Parameter type: <Gpon::downloadPending> (no yes) Possible values: - no : no download activity pending - yes : download activity pending	configure file 1 download activity is pending. <i>This element is only shown in detail mode.</i>
cfg2-planned-notok	Parameter type: <Gpon::cfgNokPlnd> (no yes) Possible values: - no : planned configure file is active - yes : planned configure file is not active	planned configure file 2 did not equal to active. <i>This element is only shown in detail mode.</i>
cfg2-dld-notok	Parameter type: <Gpon::cfgNokDld> (no yes) Possible values: - no : download configure file is in active or passive - yes : download configure file is not active or passive	download configure file 2 did not equal to active / passive. <i>This element is only shown in detail mode.</i>
cfg2-dld-inprogress	Parameter type: <Gpon::dldInProg> (no yes) Possible values: - no : download not started - yes : download started	configure file 2 download activity in progress. <i>This element is always shown.</i>
cfg2-ntlt-inprogress	Parameter type: <Gpon::ntltInProg> (no yes) Possible values: - no : ntlt file transfer not in progress - yes : ntlt file transfer in progress	configure file 2 ntlt file transfer in progress. <i>This element is always shown.</i>
cfg2-omci-inprogress	Parameter type: <Gpon::omciInProg> (no yes) Possible values: - no : omci file transfer not in progress - yes : omci file transfer in progress	configure file 2 omci file transfer in progress. <i>This element is always shown.</i>
cfg2-flash-inprogress	Parameter type: <Gpon::ontFlashInProg> (no yes) Possible values: - no : ont write not in progress - yes : ont flash in progress	configure file 2 ont flash in progress. <i>This element is only shown in detail mode.</i>
cfg2-act-inprogress	Parameter type: <Gpon::ontCfgActInProg>	ont configure file 2 activation is

92 ONT Status Commands

name	Type	Description
	(no yes) Possible values: - no : ont configure file activation not in progress - yes : ont configure file activation in progress	progress. <i>This element is always shown.</i>
cfg2-ntlt-failure	Parameter type: <Gpon::ntltFailure> (no yes) Possible values: - no : ntlt file transfer not failed - yes : ntlt file transfer failed	configure file 2 ntlt file transfer failure. <i>This element is only shown in detail mode.</i>
cfg2-omci-failure	Parameter type: <Gpon::omciFailure> (no yes) Possible values: - no : omci file transfer not failed - yes : omci file transfer failed	configure file 2 omci file transfer failure. <i>This element is only shown in detail mode.</i>
cfg2-ontflash-failure	Parameter type: <Gpon::ontFlashFail> (no yes) Possible values: - no : ont flash writing not failed - yes : ont flash writing failed	configure file 2 ont flash write failure. <i>This element is only shown in detail mode.</i>
ontcfg2act-failure	Parameter type: <Gpon::ontCfgActFail> (no yes) Possible values: - no : ont configure file activate not failed - yes : ont configure file activate failed	ont configure file 2 activation failure. <i>This element is only shown in detail mode.</i>
dld-cfgfile2-notfound	Parameter type: <Gpon::noDldFile> (no yes) Possible values: - no : download file found - yes : download file not found	download configure file 2 not found. <i>This element is only shown in detail mode.</i>
no-matching-cfgfile2	Parameter type: <Gpon::cfgNoMatch> (no yes) Possible values: - no : configure file entry found in ctrl table - yes : configure file entry not found in table	entry match not found in sw ctrl table. <i>This element is only shown in detail mode.</i>
cfgfile2-mismatch	Parameter type: <Gpon::cfgFileMisMatch> (no yes) Possible values: - no : configure file match - yes : configure file mismatch	configure file 2 mismatch. <i>This element is only shown in detail mode.</i>
cfgfile2-dld-failure	Parameter type: <Gpon::cfgDlFail> (no yes) Possible values: - no : configure file download not failed - yes : configure file download failed	configure file 2 download failed. <i>This element is only shown in detail mode.</i>
cfgfile2-delayactivate	Parameter type: <Gpon::cfgDelayActivate> (no yes) Possible values:	configure file 2 activation delayed. <i>This element is only shown in detail mode.</i>

name	Type	Description
	- no : no delay activation pending - yes : delay activation pending	
cfgfile2-dld-pending	Parameter type: <Gpon::downloadPending> (no yes) Possible values: - no : no download activity pending - yes : download activity pending	configure file 2 download activity is pending. <i>This element is only shown in detail mode.</i>

92.36 ONT Index Lookup Command

Command Description

This command is to look for ONT AID based on the given search string.

Usage: show equipment ont index {search mode : search string}

search mode is the type of search string, only support "sn" at current

search string is used to look for ONT AID, only support serial number at current

User Level

The command can be accessed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

```
> show equipment ont index [ (ont-search-string) ]
```

Command Parameters

Table 92.36-1 "ONT Index Lookup Command" Resource Parameters

Resource Identifier	Type	Description
(ont-search-string)	Format: sn : <Gpon::VendorId> : <Gpon::SerialNo> Possible values: - sn : search ONT AID by SN Field type <Gpon::VendorId> - vendor id - 4 ASCII characters - range: [a-zA-Z0-9] - length: 4 Field type <Gpon::SerialNo> - serial num - 8 ASCII characters - range: [a-fA-F0-9] - length: 8	gpon ont search string:search mode and search string

Command Output

Table 92.36-2 "ONT Index Lookup Command" Display parameters

Specific Information		
name	Type	Description
ont-idx	Parameter type: <Gpon::OntIndex> (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> ng2 : <Ng2::ChannelGroup> / <Ng2::SubchannelGroup> / <Ng2::OntId>)	identification of ont <i>This element is always shown.</i>

name	Type	Description
	Possible values: - ng2 : ngpon2 style identification Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Ng2::ChannelGroup> - channel group number Field type <Ng2::SubchannelGroup> - subchannel group number Field type <Eqpt::OntId> - the ONT identifier Field type <Ng2::OntId> - the ONT identifier	

92.37 ONT Gis Info Command

Command Description

This command reports the GIS info of the ONT.

User Level

The command can be accessed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

```
> show equipment ont gis [ (ont-idx) ]
```

Command Parameters

Table 92.37-1 "ONT Gis Info Command" Resource Parameters

Resource Identifier	Type	Description
(ont-idx)	Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> ng2 : <Ng2::ChannelGroup> / <Ng2::SubchannelGroup> / <Ng2::OntId>) Possible values: - ng2 : ngpon2 style identification Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Ng2::ChannelGroup> - channel group number Field type <Ng2::SubchannelGroup> - subchannel group number Field type <Eqpt::OntId> - the ONT identifier Field type <Ng2::OntId> - the ONT identifier	access identifier for the ont

Command Output

Table 92.37-2 "ONT Gis Info Command" Display parameters

Specific Information

name	Type	Description
longitude	Parameter type: <Gpon::OltLongitude> - longitude of the GIS info - unit: degree - range: [-180.00000...180.00000]	indicates the gis longitude of the ont. <i>This element is always shown.</i>
latitude	Parameter type: <Gpon::OltLatitude> - latitude of the GIS info - unit: degree - range: [-90.00000...90.00000]	indicates the gis latitude of the ont. <i>This element is always shown.</i>
elevation	Parameter type: <Gpon::OltElevation> - latitude of the GIS info - unit: meter - range: [-32768...32767]	indicates the gis latitude of the ont. <i>This element is always shown.</i>
horizontal-error	Parameter type: <Gpon::OltHrzErr> - horizontal error of the GIS info - unit: meter - range: [0...65535]	indicates the gis horizontal error of the ont. <i>This element is always shown.</i>
altitude-error	Parameter type: <Gpon::OltAltErr> - altitude error of the GIS info - unit: meter - range: [0...65535]	indicates the gis altitude error of the ont. <i>This element is always shown.</i>
area-code	Parameter type: <Gpon::OltAreaCode> - altitude error of the GIS info - 12 Decimal charaters - length: 12	indicates the gis area code of the ont. <i>This element is always shown.</i>
timestamp	Parameter type: <Gpon::OltTimestamp> - the seconds eclapsed since 1970-01-01:00:00:00 - unit: Seconds - range: [0...4294967295]	indicates the gis timestamp of the ont. <i>This element is always shown.</i>
gis-digest	Parameter type: <Gpon::OltGisDigest> - digest of the GIS info - 16 hex characters - length: 16	indicates the gis digest of the ont. <i>This element is always shown.</i>

92.38 XGPON ONT Olt-side Performance Monitoring Command

Command Description

This command retrieves XGPON ont-side current-interval performance monitoring data for the ONT

User Level

The command can be accessed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

> show equipment ont xg-mgmt ont-side current-interval [(ont-idx)]

Command Parameters

Table 92.38-1 "XGPON ONT Olt-side Performance Monitoring Command" Resource Parameters

Resource Identifier	Type	Description
(ont-idx)	Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> ng2 : <Ng2::ChannelGroup> / <Ng2::SubchannelGroup> / <Ng2::OntId>) Possible values: - ng2 : ngpon2 style identification Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Ng2::ChannelGroup> - channel group number Field type <Ng2::SubchannelGroup> - subchannel group number Field type <Eqpt::OntId> - the ONT identifier Field type <Ng2::OntId> - the ONT identifier	ont index

Command Output

Table 92.38-2 "XGPON ONT Olt-side Performance Monitoring Command" Display parameters

Specific Information		
name	Type	Description
ploammic-errmsgs	Parameter type: <Counter> - 32 bit counter	Count of MIC errors detected in downstream PLOAM messages <i>This element is only shown in detail mode.</i>
downsploam-msgs	Parameter type: <Counter> - 32 bit counter	count of received gem fragments <i>This element is always shown.</i>
profrece-msgs	Parameter type: <Counter> - 32 bit counter	count of received gem blocks <i>This element is always shown.</i>
rangtime-recemsgs	Parameter type: <Counter> - 32 bit counter	Count of downstream ranging_time messages received <i>This element is only shown in detail mode.</i>
deactonuid-msgs	Parameter type: <Counter> - 32 bit counter	Count of downstream deactivate_ONU-ID messages received <i>This element is only shown in detail mode.</i>
disablesn-msgs	Parameter type: <Counter> - 32 bit counter	Count of downstream disable_serial_number messages received <i>This element is only shown in detail mode.</i>
req-registration	Parameter type: <Counter> - 32 bit counter	Count of downstream request_registration messages received <i>This element is only shown in detail mode.</i>
allocid-msgs	Parameter type: <Counter> - 32 bit counter	Count of downstream assign_alloc-ID messages received <i>This element is only shown in detail mode.</i>
keycontrol-msgs	Parameter type: <Counter> - 32 bit counter	Count of downstream key_control messages received <i>This element is only shown in detail mode.</i>
sleepallow-msgs	Parameter type: <Counter> - 32 bit counter	Count of downstream sleep_allow messages received <i>This element is only shown in detail mode.</i>
baseomci-msgs	Parameter type: <Counter> - 32 bit counter	Count of downstream baseline messages received <i>This element is only shown in detail mode.</i>
extendomci-msgs	Parameter type: <Counter> - 32 bit counter	Count of downstream extended messages received <i>This element is only shown in detail mode.</i>
assonuid-msgs	Parameter type: <Counter> - 32 bit counter	Count of downstream assign_ONU-ID messages received <i>This element is only shown in detail mode.</i>
omcimic-errmsgs	Parameter type: <Counter>	Count of MIC errors detected in

92 ONT Status Commands

name	Type	Description
	- 32 bit counter	downstream OMCI messages <i>This element is only shown in detail mode.</i>
usploam-msgs	Parameter type: <Counter> - 32 bit counter	Count of upstream PLOAM messages transmitted, excluding acknowledge messages <i>This element is always shown.</i>
serinumonu-msgs	Parameter type: <Counter> - 32 bit counter	Count of upstream Serial_number_ONU PLOAM messages transmitted <i>This element is always shown.</i>
registr-msgs	Parameter type: <Counter> - 32 bit counter	Count of upstream registration PLOAM messages transmitted <i>This element is always shown.</i>
keyreport-msgs	Parameter type: <Counter> - 32 bit counter	Count of upstream key_report PLOAM messages transmitted <i>This element is always shown.</i>
acknow-msgs	Parameter type: <Counter> - 32 bit counter	Count of upstream acknowledge PLOAM messages transmitted <i>This element is only shown in detail mode.</i>
sleepreq-msgs	Parameter type: <Counter> - 32 bit counter	Count of upstream sleep_request PLOAM messages transmitted <i>This element is only shown in detail mode.</i>

92.39 XGPON ONT Previous-Interval Performance Monitoring Command

Command Description

This command retrieves XGPON ONT previous interval performance monitoring data for the ONT

User Level

The command can be accessed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

```
> show equipment ont xg-mgmt ont-side previous-interval [ (ont-idx) [ interval-no <Gpon::IntervalNo> ] ]
```

Command Parameters

Table 92.39-1 "XGPON ONT Previous-Interval Performance Monitoring Command" Resource Parameters

Resource Identifier	Type	Description
(ont-idx)	Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> ng2 : <Ng2::ChannelGroup> / <Ng2::SubchannelGroup> / <Ng2::OntId>) Possible values: - ng2 : ngpon2 style identification Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Ng2::ChannelGroup> - channel group number Field type <Ng2::SubchannelGroup> - subchannel group number Field type <Eqpt::OntId> - the ONT identifier Field type <Ng2::OntId> - the ONT identifier	ont index
interval-no	Parameter type: <Gpon::IntervalNo> Format:	identifies prev 15min intvls, val 1 as the latest intvl

Resource Identifier	Type	Description
	- a number of a previous interval number - range: [1...32]	

Command Output

Table 92.39-2 "XGPON ONT Previous-Interval Performance Monitoring Command" Display parameters

Specific Information		
name	Type	Description
ploammic-errmsgs	Parameter type: <Counter> - 32 bit counter	Count of MIC errors detected in downstream PLOAM messages <i>This element is only shown in detail mode.</i>
downsploam-msgs	Parameter type: <Counter> - 32 bit counter	Count of downstream PLOAM messages <i>This element is always shown.</i>
profrece-msgs	Parameter type: <Counter> - 32 bit counter	Count of downstream profile messages received <i>This element is always shown.</i>
rangtime-recemsgs	Parameter type: <Counter> - 32 bit counter	Count of downstream ranging_time messages received <i>This element is only shown in detail mode.</i>
deactonuid-msgs	Parameter type: <Counter> - 32 bit counter	Count of downstream deactivate_ONU-ID messages received <i>This element is only shown in detail mode.</i>
disablesn-msgs	Parameter type: <Counter> - 32 bit counter	Count of downstream disable_serial_number messages received <i>This element is only shown in detail mode.</i>
req-registration	Parameter type: <Counter> - 32 bit counter	Count of downstream request_registration messages received <i>This element is only shown in detail mode.</i>
allocid-msgs	Parameter type: <Counter> - 32 bit counter	Count of downstream assign_alloc-ID messages received <i>This element is only shown in detail mode.</i>
keycontrol-msgs	Parameter type: <Counter> - 32 bit counter	Count of downstream key_control messages received <i>This element is only shown in detail mode.</i>
sleepallow-msgs	Parameter type: <Counter> - 32 bit counter	Count of downstream sleep_allow messages received <i>This element is only shown in detail mode.</i>
baseomci-msgs	Parameter type: <Counter> - 32 bit counter	Count of downstream baseline messages received <i>This element is only shown in detail mode.</i>
extendomci-msgs	Parameter type: <Counter>	Count of downstream extended

name	Type	Description
	- 32 bit counter	messages received <i>This element is only shown in detail mode.</i>
assonuid-msgs	Parameter type: <Counter> - 32 bit counter	Count of downstream assign_ONU-ID messages received <i>This element is only shown in detail mode.</i>
omcemic-errmsgs	Parameter type: <Counter> - 32 bit counter	Count of MIC errors detected in downstream OMCI messages <i>This element is only shown in detail mode.</i>
usploam-msgs	Parameter type: <Counter> - 32 bit counter	Count of upstream PLOAM messages transmitted, excluding acknowledge messages <i>This element is always shown.</i>
serinumonu-msgs	Parameter type: <Counter> - 32 bit counter	Count of upstream Serial_number_ONU PLOAM messages transmitted <i>This element is always shown.</i>
registr-msgs	Parameter type: <Counter> - 32 bit counter	Count of upstream registration PLOAM messages transmitted <i>This element is always shown.</i>
keyreport-msgs	Parameter type: <Counter> - 32 bit counter	Count of upstream key_report PLOAM messages transmitted <i>This element is always shown.</i>
acknow-msgs	Parameter type: <Counter> - 32 bit counter	Count of upstream acknowledge PLOAM messages transmitted <i>This element is only shown in detail mode.</i>
sleepreq-msgs	Parameter type: <Counter> - 32 bit counter	Count of upstream sleep_request PLOAM messages transmitted <i>This element is only shown in detail mode.</i>

92.40 GPON ONT Memory Usage Current-Interval Performance Monitoring Command

Command Description

This command retrieves ONT-side memory usage current interval performance monitoring data for the ONT

User Level

The command can be accessed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

```
> show equipment ont memory-usage current-interval [ (ont-idx) ]
```

Command Parameters

Table 92.40-1 "GPON ONT Memory Usage Current-Interval Performance Monitoring Command" Resource Parameters

Resource Identifier	Type	Description
(ont-idx)	Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> ng2 : <Ng2::ChannelGroup> / <Ng2::SubchannelGroup> / <Ng2::OntId>) Possible values: - ng2 : ngpon2 style identification Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Ng2::ChannelGroup> - channel group number Field type <Ng2::SubchannelGroup> - subchannel group number Field type <Eqpt::OntId> - the ONT identifier Field type <Ng2::OntId> - the ONT identifier	identification of ont

Command Output

**Table 92.40-2 "GPON ONT Memory Usage Current-Interval Performance Monitoring Command"
Display parameters**

Specific Information		
name	Type	Description
total(kbytes)	Parameter type: <Gpon::OntMemory> (unknown <Gpon::OntMemory>) Possible values: - unknown : olt has not yet communicated with ont or ont doesn't support Field type <Gpon::OntMemory> - ont memory usage - range: [0...4294967295]	the size of the total memory on this ONT <i>This element is always shown.</i>
used(kbytes)	Parameter type: <Gpon::OntMemory> (unknown <Gpon::OntMemory>) Possible values: - unknown : olt has not yet communicated with ont or ont doesn't support Field type <Gpon::OntMemory> - ont memory usage - range: [0...4294967295]	the size of the memory actually in use <i>This element is always shown.</i>
used-portion(%)	Parameter type: <Gpon::OntMemoryUsage> (unknown <Gpon::OntMemoryUsage>) Possible values: - unknown : olt has not yet communicated with ont or ont doesn't support Field type <Gpon::OntMemoryUsage> - the size of the memory actually in use, expressed as a portion of the total memory - range: [0...4294967295]	the size of the memory actually in use, expressed as a portion of the total memory <i>This element is always shown.</i>

92.41 GPON ONT Memory Usage Previous-Interval Performance Monitoring Command

Command Description

This command retrieves ONT-side memory usage previous interval performance monitoring data for the ONT

User Level

The command can be accessed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

```
> show equipment ont memory-usage previous-interval [ (ont-idx) [ interval-num <Gpon::DayIntervalNo> ] ]
```

Command Parameters

Table 92.41-1 "GPON ONT Memory Usage Previous-Interval Performance Monitoring Command" Resource Parameters

Resource Identifier	Type	Description
(ont-idx)	Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> ng2 : <Ng2::ChannelGroup> / <Ng2::SubchannelGroup> / <Ng2::OntId>) Possible values: - ng2 : ngpon2 style identification Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Ng2::ChannelGroup> - channel group number Field type <Ng2::SubchannelGroup> - subchannel group number Field type <Eqpt::OntId> - the ONT identifier Field type <Ng2::OntId> - the ONT identifier	identification of ont
interval-num	Parameter type: <Gpon::DayIntervalNo> Format:	identifies prev 24-hour intvls, val 1 as the latest intvl

Resource Identifier	Type	Description
	- a number of a previous interval number - range: [1...7]	

Command Output

**Table 92.41-2 "GPON ONT Memory Usage Previous-Interval Performance Monitoring Command"
Display parameters**

Specific Information		
name	Type	Description
total(kbytes)	Parameter type: <Gpon::OntMemory> (unknown <Gpon::OntMemory>) Possible values: - unknown : olt has not yet communicated with ont or ont doesn't support Field type <Gpon::OntMemory> - ont memory usage - range: [0...4294967295]	the size of the total memory on this ONT <i>This element is always shown.</i>
used(kbytes)	Parameter type: <Gpon::OntMemory> (unknown <Gpon::OntMemory>) Possible values: - unknown : olt has not yet communicated with ont or ont doesn't support Field type <Gpon::OntMemory> - ont memory usage - range: [0...4294967295]	the size of the memory actually in use <i>This element is always shown.</i>
used-portion(%)	Parameter type: <Gpon::OntMemoryUsage> (unknown <Gpon::OntMemoryUsage>) Possible values: - unknown : olt has not yet communicated with ont or ont doesn't support Field type <Gpon::OntMemoryUsage> - the size of the memory actually in use, expressed as a portion of the total memory - range: [0...4294967295]	the size of the memory actually in use, expressed as a portion of the total memory <i>This element is always shown.</i>

92.42 GPON ONT CPU Load Current-Interval Performance Monitoring Command

Command Description

This command retrieves ONT-side cpu load current interval performance monitoring data for the ONT

User Level

The command can be accessed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

```
> show equipment ont cpu-load current-interval [ (ont-idx) ]
```

Command Parameters

Table 92.42-1 "GPON ONT CPU Load Current-Interval Performance Monitoring Command" Resource Parameters

Resource Identifier	Type	Description
(ont-idx)	Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> ng2 : <Ng2::ChannelGroup> / <Ng2::SubchannelGroup> / <Ng2::OntId>) Possible values: - ng2 : ngpon2 style identification Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Ng2::ChannelGroup> - channel group number Field type <Ng2::SubchannelGroup> - subchannel group number Field type <Eqpt::OntId> - the ONT identifier Field type <Ng2::OntId> - the ONT identifier	identification of ont

Command Output

**Table 92.42-2 "GPON ONT CPU Load Current-Interval Performance Monitoring Command"
Display parameters**

Specific Information		
name	Type	Description
average(%)	Parameter type: <Gpon::OntCPULoad> (unknown <Gpon::OntCPULoad>) Possible values: - unknown : olt has not yet communicated with ont or ont doesn't support Field type <Gpon::OntCPULoad> - cpu load average of ont during a 15-min interval, expressed as a percentage - range: [0...4294967295]	average CPU load for the measurement period , expressed in percentage <i>This element is always shown.</i>

92.43 GPON ONT CPU Load previous-Interval Performance Monitoring Command

Command Description

This command retrieves ONT-side cpu load previous interval performance monitoring data for the ONT

User Level

The command can be accessed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

```
> show equipment ont cpu-load previous-interval [ (ont-idx) [ interval-num <Gpon::IntervalNo> ] ]
```

Command Parameters

Table 92.43-1 "GPON ONT CPU Load previous-Interval Performance Monitoring Command" Resource Parameters

Resource Identifier	Type	Description
(ont-idx)	Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> ng2 : <Ng2::ChannelGroup> / <Ng2::SubchannelGroup> / <Ng2::OntId>) Possible values: - ng2 : ngpon2 style identification Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Ng2::ChannelGroup> - channel group number Field type <Ng2::SubchannelGroup> - subchannel group number Field type <Eqpt::OntId> - the ONT identifier Field type <Ng2::OntId> - the ONT identifier	identification of ont
interval-num	Parameter type: <Gpon::IntervalNo> Format:	identifies prev 15-minute intvls, val 1 as the latest intvl

Resource Identifier	Type	Description
	- a number of a previous interval number - range: [1...32]	

Command Output

**Table 92.43-2 "GPON ONT CPU Load previous-Interval Performance Monitoring Command"
Display parameters**

Specific Information		
name	Type	Description
average(%)	Parameter type: <Gpon::OntCPULoad> (unknown <Gpon::OntCPULoad>) Possible values: - unknown : olt has not yet communicated with ont or ont doesn't support Field type <Gpon::OntCPULoad> - cpu load average of ont during a 15-min interval, expressed as a percentage - range: [0...4294967295]	average CPU load for the measurement period , expressed in percentage <i>This element is always shown.</i>

93- ONT Ranging Status Commands

93.1 ONT Ranging Status Command Tree	93-2129
93.2 ONT Channel-group Ranging Status Command	93-2130
93.3 ONT Channel-pair Ranging Status Command	93-2133

93.1 ONT Ranging Status Command Tree

Description

This chapter gives an overview of nodes that are handled by "ONT Ranging Status Commands".

Command Tree

```
----show
  ----equipment
    ----ont
      ----ranging-status
        ----channel-group
          - (channel-group)
          - subchannel-group
          - ont-id
        ----channel-pair
          - (chpair)
          - ont
```

93.2 ONT Channel-group Ranging Status Command

Command Description

This command reports the onts in a channel group and their preferred and ranged channel-pair along with ranging status

User Level

The command can be accessed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

```
> show equipment ont ranging-status channel-group [ (channel-group) [ subchannel-group
<Ng2::SubchannelGroupId> ] [ ont-id <Ng2::OntNum> ] ]
```

Command Parameters

Table 93.2-1 "ONT Channel-group Ranging Status Command" Resource Parameters

Resource Identifier	Type	Description
(channel-group)	Format: <Ng2::ChannelGroup> Field type <Ng2::ChannelGroup> - channel group number	channel group id
subchannel-group	Parameter type: <Ng2::SubchannelGroupId> Format: - subchannel group number - range: [1...4]	subchannel group id
ont-id	Parameter type: <Ng2::OntNum> Format: - ont id in a subchannel group - range: [1...256]	ont id

Command Output

Table 93.2-2 "ONT Channel-group Ranging Status Command" Display parameters

Specific Information		
name	Type	Description
ont	Parameter type: <Gpon::OntIndex> (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> ng2 : <Ng2::ChannelGroup> / <Ng2::SubchannelGroup> /	ont ifindex <i>This element is always shown.</i>

name	Type	Description
	<Ng2::OntId>) Possible values: - ng2 : ngpon2 style identification Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Ng2::ChannelGroup> - channel group number Field type <Ng2::SubchannelGroup> - subchannel group number Field type <Eqpt::OntId> - the ONT identifier Field type <Ng2::OntId> - the ONT identifier	
ranging status	Parameter type: <Ng2::OntRangedStatusChanGroup> (ranged-on-pref ranged-on-prot not-ranged ranged-parked rng-on-altpref) Possible values: - ranged-on-pref : Ranged on Preferred Channel Pair - ranged-on-prot : Ranged on Protection Channel Pair - not-ranged : NOT Ranged - ranged-parked : Ranged/parked - rng-on-altpref : Ranged on Alternative Preferred Channel Pair	ont ranging status <i>This element is always shown.</i>
ranged-on chpair short name: rngd on-chpair	Parameter type: <Ng2::ChannelPairIndexOrZero> (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::ChannelPairId> -) Possible values: - - : ont not ranged Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::ChannelPairId> - the channel pair identifier	ranged channel pair <i>This element is always shown.</i>
backup-chpair status	Parameter type: <Ng2::OntBackupChPairStatusChanGroup> (pref-ready pref-not-ready prot-ready prot-not-ready not-ready none altpref-ready altpref-not-rdy) Possible values: - pref-ready : Preferred Channel Pair ready	backup channel pair status <i>This element is always shown.</i>

93 ONT Ranging Status Commands

name	Type	Description
	- pref-not-ready : Preferred Channel Pair NOT ready - prot-ready : Protection Channel Pair ready - prot-not-ready : Protection Channel Pair NOT ready - not-ready : NOT ready - none : None - altpref-ready : Alternative Preferred Channel Pair ready - altpref-not-rdy : Alternative Preferred Channel Pair NOT ready	
preferred-chpair short name: prefer-chpair	Parameter type: <Ng2::ChannelPairIndexOrZero> (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::ChannelPairId> -) Possible values: - - : ont not ranged Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::ChannelPairId> - the channel pair identifier	preferred channel pair <i>This element is always shown.</i>
protection-chpair short name: protect-chpair	Parameter type: <Ng2::ChannelPairIndexOrZero> (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::ChannelPairId> -) Possible values: - - : ont not ranged Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::ChannelPairId> - the channel pair identifier	protection channel pair <i>This element is always shown.</i>
alt-pref-chpair short name: altpref-chpair	Parameter type: <Ng2::ChannelPairIndexOrZero> (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::ChannelPairId> -) Possible values: - - : ont not ranged Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::ChannelPairId> - the channel pair identifier	alternative preferred channel pair <i>This element is always shown.</i>

93.3 ONT Channel-pair Ranging Status Command

Command Description

This command reports the onts on a channel pair and their ranging status

User Level

The command can be accessed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

```
> show equipment ont ranging-status channel-pair [ (chpair) [ ont <Gpon::OntIndex> ] ]
```

Command Parameters

Table 93.3-1 "ONT Channel-pair Ranging Status Command" Resource Parameters

Resource Identifier	Type	Description
(chpair)	Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::ChannelPairId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::ChannelPairId> - the channel pair identifier	channel pair ifindex
ont	Parameter type: <Gpon::OntIndex> Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> ng2 : <Ng2::ChannelGroup> / <Ng2::SubchannelGroup> / <Ng2::OntId>) Possible values: - ng2 : ngpon2 style identification Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Ng2::ChannelGroup> - channel group number	ont ifindex

Resource Identifier	Type	Description
	Field type <Ng2::SubchannelGroup> - subchannel group number Field type <Eqpt::OntId> - the ONT identifier Field type <Ng2::OntId> - the ONT identifier	

Command Output

Table 93.3-2 "ONT Channel-pair Ranging Status Command" Display parameters

Specific Information		
name	Type	Description
usage-by-ont	Parameter type: <Ng2::OntRangedStatusChanPair> (pref-ranged pref-not-ranged pref-not-ranged-ready pref-not-rng-not-ready prot-ranged prot-not-ranged-ready prot-not-rng-not-ready ranged-parked altpref-ranged altpref-not-ranged-rdy altpref-not-rng-not-rdy) Possible values: - pref-ranged : Channel-pair is preferred and ONT is ranged on it - pref-not-ranged : Channel-pair is preferred and ONT is NOT ranged on it, no protection - pref-not-ranged-ready : Channel-pair is preferred and ONT is NOT ranged on it, ready - pref-not-rng-not-ready: Channel-pair is preferred and ONT is NOT ranged on it, not ready - prot-ranged : Channel-pair is protection and ONT is ranged on it - prot-not-ranged-ready : Channel-pair is protection and ONT is NOT ranged on it, ready - prot-not-rng-not-ready: Channel-pair is protection and ONT is NOT ranged on it, not ready - ranged-parked : Channel-pair is NOT preferred, NOT protection and NOT alternative preferred and ONT is ranged on it, parked - altpref-ranged : Channel-pair is alternative preferred and ONT is ranged on it - altpref-not-ranged-rdy: Channel-pair is alternative preferred and ONT is NOT ranged on it, ready - altpref-not-rng-not-rdy: Channel-pair is alternative preferred and ONT is NOT ranged on it, not ready	ont ranging status <i>This element is always shown.</i>

94- ONT Software Download Status Command

94.1 ONT Software Download Status Command Tree	94-2136
94.2 ONT Software Download Status Per Channel Group/Sub Channel Group Command	94-2137

94.1 ONT Software Download Status Command Tree

Description

This chapter gives an overview of nodes that are handled by "ONT Software Download Status Command".

Command Tree

```
----show
  ----equipment
    ----ont
      ----ng2-sw-download
        ----channel-group
          - (channel-group)
          - subchannel-group
          - ont-id
```

94.2 ONT Software Download Status Per Channel Group/Sub Channel Group Command

Command Description

show individual ont fine-grain status associated with any sw download activity.

User Level

The command can be accessed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

```
> show equipment ont ng2-sw-download channel-group [ (channel-group) [ subchannel-group
<Ng2::SubchannelGroupId> ] [ ont-id <Ng2::OntNum> ] ]
```

Command Parameters

Table 94.2-1 "ONT Software Download Status Per Channel Group/Sub Channel Group Command" Resource Parameters

Resource Identifier	Type	Description
(channel-group)	Format: <Ng2::ChannelGroup> Field type <Ng2::ChannelGroup> - channel group number	channel group id
subchannel-group	Parameter type: <Ng2::SubchannelGroupId> Format: - subchannel group number - range: [1...4]	subchannel group id
ont-id	Parameter type: <Ng2::OntNum> Format: - ont id in a subchannel group - range: [1...256]	ont id

Command Output

Table 94.2-2 "ONT Software Download Status Per Channel Group/Sub Channel Group Command" Display parameters

Specific Information		
name	Type	Description
ont	Parameter type: <Gpon::OntIndex> (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId>	ont ifindex <i>This element is always shown.</i>

94 ONT Software Download Status Command

name	Type	Description
	ng2 : <Ng2::ChannelGroup> / <Ng2::SubchannelGroup> / <Ng2::OntId>) Possible values: - ng2 : ngpon2 style identification Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Ng2::ChannelGroup> - channel group number Field type <Ng2::SubchannelGroup> - subchannel group number Field type <Eqpt::OntId> - the ONT identifier Field type <Ng2::OntId> - the ONT identifier	
planned	Parameter type: <Gpon::notPlnd> (no yes) Possible values: - no : ont is planned - yes : ont is not planned	ont is not planned. <i>This element is always shown.</i>
inactive	Parameter type: <Gpon::inAct> (no yes) Possible values: - no : ont is active - yes : ont is not active	ont is not active. <i>This element is only shown in detail mode.</i>
planned-notok	Parameter type: <Gpon::nokPlnd> (no yes) Possible values: - no : planned sw is active - yes : planned sw is not active	planned did not equal to active. <i>This element is only shown in detail mode.</i>
download-notok	Parameter type: <Gpon::nokDld> (no yes) Possible values: - no : download software is in active or passive - yes : download software is not active or passive	download did not equal to active / passive. <i>This element is only shown in detail mode.</i>
download-inprogress	Parameter type: <Gpon::dldInProg> (no yes) Possible values: - no : download not started - yes : download started	download activity in progress. <i>This element is always shown.</i>
ntlt-inprogress	Parameter type: <Gpon::ntltInProg> (no yes) Possible values: - no : ntlt file transfer not in progress - yes : ntlt file transfer in progress	ntlt file transfer in progress. <i>This element is always shown.</i>
omci-inprogress	Parameter type: <Gpon::omciInProg>	omci file transfer in progress.

name	Type	Description
	(no yes) Possible values: - no : omci file transfer not in progress - yes : omci file transfer in progress	<i>This element is always shown.</i>
ontflash-inprogress	Parameter type: <Gpon::ontFlashInProg> (no yes) Possible values: - no : ont write not in progress - yes : ont flash in progress	ont flash in progress. <i>This element is only shown in detail mode.</i>
ontswact-inprogress	Parameter type: <Gpon::ontSwActInProg> (no yes) Possible values: - no : ont software activation not in progress - yes : ont software activation in progress	ont software activation is progress. <i>This element is always shown.</i>
ntlt-failure	Parameter type: <Gpon::ntltFailure> (no yes) Possible values: - no : ntlt file transfer not failed - yes : ntlt file transfer failed	ntlt file transfer failure. <i>This element is only shown in detail mode.</i>
omci-failure	Parameter type: <Gpon::omciFailure> (no yes) Possible values: - no : omci file transfer not failed - yes : omci file transfer failed	omci file transfer failure. <i>This element is only shown in detail mode.</i>
ontflash-failure	Parameter type: <Gpon::ontFlashFail> (no yes) Possible values: - no : ont flash writing not failed - yes : ont flash writing failed	ont flash write failure. <i>This element is only shown in detail mode.</i>
ontswact-failure	Parameter type: <Gpon::ontSwActFail> (no yes) Possible values: - no : ont software activate not failed - yes : ont software activate failed	ont software activation failure. <i>This element is only shown in detail mode.</i>
download-file-notfound	Parameter type: <Gpon::noDldFile> (no yes) Possible values: - no : download file found - yes : download file not found	download file not found. <i>This element is always shown.</i>
no-matching-software	Parameter type: <Gpon::noMatch> (no yes) Possible values: - no : sw entry found in ctrl table - yes : sw entry not found in table	entry match not found in sw ctrl table. <i>This element is only shown in detail mode.</i>
sw-version-mismatch	Parameter type: <Gpon::swVerMisMatch> (no yes) Possible values:	software version mismatch. <i>This element is always shown.</i>

94 ONT Software Download Status Command

name	Type	Description
	- no : software version match - yes : software version mismatch	
sw-download-failure	Parameter type: <Gpon::swDIFail> (no yes) Possible values: - no : software download not failed - yes : software download failed	software download failed. <i>This element is always shown.</i>
sw-delayactivate	Parameter type: <Gpon::swDelayActivate> (no yes) Possible values: - no : no delay activation pending - yes : delay activation pending	software activation delayed. <i>This element is always shown.</i>
sw-download-pending	Parameter type: <Gpon::downloadPending> (no yes) Possible values: - no : no download activity pending - yes : download activity pending	sw download activity is pending. <i>This element is only shown in detail mode.</i>

95- ONT Status Commands

95.1 ONT Status Command Tree	95-2142
95.2 GPON ONT Status Command	95-2143
95.3 GPON ONT Status Command	95-2146
95.4 GPON ONT Status Command	95-2149
95.5 NGPON ONT Status Command	95-2152

95.1 ONT Status Command Tree

Description

This chapter gives an overview of nodes that are handled by "ONT Status Commands".

Command Tree

```
----show
  ----equipment
    ----ont
      ----status
        ----pon
          - (pon)
          - ont
        ----x-pon
          - (x-pon)
          - ont
        ----twenty-five-g
          - (twenty-five-g)
          - ont
        ----channel-pair
          - (chanpair)
          - ont
```


95.2 GPON ONT Status Command

Command Description

This command reports a summary of ont parameters under a given pon

User Level

The command can be accessed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

```
> show equipment ont status pon [ (pon) [ ont <Gpon::OntIndex> ] ]
```

Command Parameters

Table 95.2-1 "GPON ONT Status Command" Resource Parameters

Resource Identifier	Type	Description
(pon)	Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier	access identifier for the pon
ont	Parameter type: <Gpon::OntIndex> Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> ng2 : <Ng2::ChannelGroup> / <Ng2::SubchannelGroup> / <Ng2::OntId>) Possible values: - ng2 : ngpon2 style identification Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Ng2::ChannelGroup> - channel group number	identification of ont

Resource Identifier	Type	Description
	Field type <Ng2::SubchannelGroup> - subchannel group number Field type <Eqpt::OntId> - the ONT identifier Field type <Ng2::OntId> - the ONT identifier	

Command Output

Table 95.2-2 "GPON ONT Status Command" Display parameters

Specific Information		
name	Type	Description
sernum	Parameter type: <Gpon::SerNum2> <Gpon::VendorIdNum> : <Gpon::SerialNo> Field type <Gpon::VendorIdNum> - vendor id -4 ASCII characters - length: 4 Field type <Gpon::SerialNo> - serial num - 8 ASCII characters - range: [a-fA-F0-9] - length: 8	Serial number of ont <i>This element is always shown.</i>
admin-status	Parameter type: <Itf::ifAdminStatus> (not-appl up down testing) Possible values: - not-appl : not-applicable - up : admin status is up - down : admin status is down - testing : no operational packets can be passed	Specifies admin state of the interface. <i>This element is always shown.</i>
oper-status	Parameter type: <Itf::ifAdminStatus> (not-appl up down testing) Possible values: - not-appl : not-applicable - up : admin status is up - down : admin status is down - testing : no operational packets can be passed	Specifies oper state of the interface. <i>This element is always shown.</i>
olt-rx-sig-level(dbm)	Parameter type: <Gpon::OntOltRxSignalLevel> (invalid unsupported <Gpon::OltRxSignalLevel>) Possible values: - invalid : valid measurement is currently unattainable for some reason - unsupported : measurement functionality is not supported Field type <Gpon::OltRxSignalLevel> - measurement of the ont receive optical signal level in dBm - unit: dbm - range: [-50...0,6553.4...6553.5]	indicates the current level of the ONT's optical signal(as measured at olt-side) <i>This element is always shown.</i>
ont-olt-distance(km)	Parameter type: <Gpon::OntOltDist> (invalid not-supported	estimate of the distance between this ont and the olt. <i>This element is always shown.</i>

name	Type	Description
	<Gpon::DistOntOlt>) Possible values: - invalid : valid measurement is currently unattainable for some reason - not-supported : the measurement functionality is not supported by this particular unit. Field type <Gpon::DistOntOlt> - estimate of the distance between this ont and the olt - unit: km - range: [0...6550,6553.4...6553.5]	
desc1	Parameter type: <Gpon::Desc> - desc - length: x<=64	free-form textual field for user to describe the ONT <i>This element is always shown.</i>
desc2	Parameter type: <Gpon::Desc> - desc - length: x<=64	free-form textual field for user to describe the ONT <i>This element is always shown.</i>
hostname	Parameter type: <Gpon::HostName> (undefined unknown <Gpon::hostname>) Possible values: - undefined : DHCP is unavailable or ONT returns null string - unknown : OLT could not communicate with ONT for discovery Field type <Gpon::hostname> - host name address - length: x<=255	the host name <i>This element is always shown.</i>

95.3 GPON ONT Status Command

Command Description

This command reports a summary of ont parameters under a given x-pon

User Level

The command can be accessed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

```
> show equipment ont status x-pon [ (x-pon) [ ont <Gpon::OntIndex> ] ]
```

Command Parameters

Table 95.3-1 "GPON ONT Status Command" Resource Parameters

Resource Identifier	Type	Description
(x-pon)	Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::XPonId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::XPonId> - the XGS PON identifier	access identifier for the pon
ont	Parameter type: <Gpon::OntIndex> Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> ng2 : <Ng2::ChannelGroup> / <Ng2::SubchannelGroup> / <Ng2::OntId>) Possible values: - ng2 : ngpon2 style identification Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Ng2::ChannelGroup> - channel group number	identification of ont

Resource Identifier	Type	Description
	Field type <Ng2::SubchannelGroup> - subchannel group number Field type <Eqpt::OntId> - the ONT identifier Field type <Ng2::OntId> - the ONT identifier	

Command Output

Table 95.3-2 "GPON ONT Status Command" Display parameters

Specific Information		
name	Type	Description
sernum	Parameter type: <Gpon::SerNum2> <Gpon::VendorIdNum> : <Gpon::SerialNo> Field type <Gpon::VendorIdNum> - vendor id -4 ASCII characters - length: 4 Field type <Gpon::SerialNo> - serial num - 8 ASCII characters - range: [a-fA-F0-9] - length: 8	Serial number of ont <i>This element is always shown.</i>
admin-status	Parameter type: <Itf::ifAdminStatus> (not-appl up down testing) Possible values: - not-appl : not-applicable - up : admin status is up - down : admin status is down - testing : no operational packets can be passed	Specifies admin state of the interface. <i>This element is always shown.</i>
oper-status	Parameter type: <Itf::ifAdminStatus> (not-appl up down testing) Possible values: - not-appl : not-applicable - up : admin status is up - down : admin status is down - testing : no operational packets can be passed	Specifies oper state of the interface. <i>This element is always shown.</i>
olt-rx-sig-level(dbm)	Parameter type: <Gpon::OntOltRxSignalLevel> (invalid unsupported <Gpon::OltRxSignalLevel>) Possible values: - invalid : valid measurement is currently unattainable for some reason - unsupported : measurement functionality is not supported Field type <Gpon::OltRxSignalLevel> - measurement of the ont receive optical signal level in dBm - unit: dbm - range: [-50...0,6553.4...6553.5]	indicates the current level of the ONT's optical signal(as measured at olt-side) <i>This element is always shown.</i>
ont-olt-distance(km)	Parameter type: <Gpon::OntOltDist> (invalid not-supported	estimate of the distance between this ont and the olt. <i>This element is always shown.</i>

95 ONT Status Commands

name	Type	Description
	<Gpon::DistOntOlt>) Possible values: - invalid : valid measurement is currently unattainable for some reason - not-supported : the measurement functionality is not supported by this particular unit. Field type <Gpon::DistOntOlt> - estimate of the distance between this ont and the olt - unit: km - range: [0...6550,6553.4...6553.5]	
desc1	Parameter type: <Gpon::Desc> - desc - length: x<=64	free-form textual field for user to describe the ONT <i>This element is always shown.</i>
desc2	Parameter type: <Gpon::Desc> - desc - length: x<=64	free-form textual field for user to describe the ONT <i>This element is always shown.</i>
hostname	Parameter type: <Gpon::HostName> (undefined unknown <Gpon::hostname>) Possible values: - undefined : DHCP is unavailable or ONT returns null string - unknown : OLT could not communicate with ONT for discovery Field type <Gpon::hostname> - host name address - length: x<=255	the host name <i>This element is always shown.</i>

95.4 GPON ONT Status Command

Command Description

This command reports a summary of ont parameters under a given 25g-pon

User Level

The command can be accessed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

```
> show equipment ont status twenty-five-g [ (twenty-five-g) [ ont <Gpon::OntIndex> ] ]
```

Command Parameters

Table 95.4-1 "GPON ONT Status Command" Resource Parameters

Resource Identifier	Type	Description
(twenty-five-g)	Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::M25GPonId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::M25GPonId> - the 25G PON identifier	access identifier for the pon
ont	Parameter type: <Gpon::OntIndex> Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> ng2 : <Ng2::ChannelGroup> / <Ng2::SubchannelGroup> / <Ng2::OntId>) Possible values: - ng2 : ngpon2 style identification Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Ng2::ChannelGroup> - channel group number	identification of ont

Resource Identifier	Type	Description
	Field type <Ng2::SubchannelGroup> - subchannel group number Field type <Eqpt::OntId> - the ONT identifier Field type <Ng2::OntId> - the ONT identifier	

Command Output

Table 95.4-2 "GPON ONT Status Command" Display parameters

Specific Information		
name	Type	Description
sernum	Parameter type: <Gpon::SerNum2> <Gpon::VendorIdNum> : <Gpon::SerialNo> Field type <Gpon::VendorIdNum> - vendor id -4 ASCII characters - length: 4 Field type <Gpon::SerialNo> - serial num - 8 ASCII characters - range: [a-fA-F0-9] - length: 8	Serial number of ont <i>This element is always shown.</i>
admin-status	Parameter type: <Itf::ifAdminStatus> (not-appl up down testing) Possible values: - not-appl : not-applicable - up : admin status is up - down : admin status is down - testing : no operational packets can be passed	Specifies admin state of the interface. <i>This element is always shown.</i>
oper-status	Parameter type: <Itf::ifAdminStatus> (not-appl up down testing) Possible values: - not-appl : not-applicable - up : admin status is up - down : admin status is down - testing : no operational packets can be passed	Specifies oper state of the interface. <i>This element is always shown.</i>
olt-rx-sig-level(dbm)	Parameter type: <Gpon::OntOltRxSignalLevel> (invalid unsupported <Gpon::OltRxSignalLevel>) Possible values: - invalid : valid measurement is currently unattainable for some reason - unsupported : measurement functionality is not supported Field type <Gpon::OltRxSignalLevel> - measurement of the ont receive optical signal level in dBm - unit: dbm - range: [-50...0,6553.4...6553.5]	indicates the current level of the ONT's optical signal(as measured at olt-side) <i>This element is always shown.</i>
ont-olt-distance(km)	Parameter type: <Gpon::OntOltDist> (invalid not-supported	estimate of the distance between this ont and the olt. <i>This element is always shown.</i>

name	Type	Description
	<Gpon::DistOntOlt>) Possible values: - invalid : valid measurement is currently unattainable for some reason - not-supported : the measurement functionality is not supported by this particular unit. Field type <Gpon::DistOntOlt> - estimate of the distance between this ont and the olt - unit: km - range: [0...6550,6553.4...6553.5]	
desc1	Parameter type: <Gpon::Desc> - desc - length: x<=64	free-form textual field for user to describe the ONT <i>This element is always shown.</i>
desc2	Parameter type: <Gpon::Desc> - desc - length: x<=64	free-form textual field for user to describe the ONT <i>This element is always shown.</i>
hostname	Parameter type: <Gpon::HostName> (undefined unknown <Gpon::hostname>) Possible values: - undefined : DHCP is unavailable or ONT returns null string - unknown : OLT could not communicate with ONT for discovery Field type <Gpon::hostname> - host name address - length: x<=255	the host name <i>This element is always shown.</i>

95.5 NGPON ONT Status Command

Command Description

This command reports a summary of ont parameters under a given channel pair

User Level

The command can be accessed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

```
> show equipment ont status channel-pair [ (chanpair) [ ont <Gpon::OntIndex> ] ]
```

Command Parameters

Table 95.5-1 "NGPON ONT Status Command" Resource Parameters

Resource Identifier	Type	Description
(chanpair)	Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::ChannelPairId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::ChannelPairId> - the channel pair identifier	access identifier for the channel pair
ont	Parameter type: <Gpon::OntIndex> Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> ng2 : <Ng2::ChannelGroup> / <Ng2::SubchannelGroup> / <Ng2::OntId>) Possible values: - ng2 : ngpon2 style identification Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Ng2::ChannelGroup> - channel group number	identification of ont

Resource Identifier	Type	Description
	Field type <Ng2::SubchannelGroup> - subchannel group number Field type <Eqpt::OntId> - the ONT identifier Field type <Ng2::OntId> - the ONT identifier	

Command Output

Table 95.5-2 "NGPON ONT Status Command" Display parameters

Specific Information		
name	Type	Description
sernum	Parameter type: <Gpon::SerNum2> <Gpon::VendorIdNum> : <Gpon::SerialNo> Field type <Gpon::VendorIdNum> - vendor id -4 ASCII characters - length: 4 Field type <Gpon::SerialNo> - serial num - 8 ASCII characters - range: [a-fA-F0-9] - length: 8	Serial number of ont <i>This element is always shown.</i>
admin-status	Parameter type: <Itf::ifAdminStatus> (not-appl up down testing) Possible values: - not-appl : not-applicable - up : admin status is up - down : admin status is down - testing : no operational packets can be passed	Specifies admin state of the interface. <i>This element is always shown.</i>
oper-status	Parameter type: <Itf::ifAdminStatus> (not-appl up down testing) Possible values: - not-appl : not-applicable - up : admin status is up - down : admin status is down - testing : no operational packets can be passed	Specifies oper state of the interface. <i>This element is always shown.</i>
olt-rx-sig-level(dbm)	Parameter type: <Gpon::OntOltRxSignalLevel> (invalid unsupported <Gpon::OltRxSignalLevel>) Possible values: - invalid : valid measurement is currently unattainable for some reason - unsupported : measurement functionality is not supported Field type <Gpon::OltRxSignalLevel> - measurement of the ont receive optical signal level in dBm - unit: dbm - range: [-50...0,6553.4...6553.5]	indicates the current level of the ONT's optical signal(as measured at olt-side) <i>This element is always shown.</i>
ont-olt-distance(km)	Parameter type: <Gpon::OntOltDist> (invalid not-supported	estimate of the distance between this ont and the olt. <i>This element is always shown.</i>

name	Type	Description
	<Gpon::DistOntOlt>) Possible values: - invalid : valid measurement is currently unattainable for some reason - not-supported : the measurement functionality is not supported by this particular unit. Field type <Gpon::DistOntOlt> - estimate of the distance between this ont and the olt - unit: km - range: [0...6550,6553.4...6553.5]	
desc1	Parameter type: <Gpon::Desc> - desc - length: x<=64	free-form textual field for user to describe the ONT <i>This element is always shown.</i>
desc2	Parameter type: <Gpon::Desc> - desc - length: x<=64	free-form textual field for user to describe the ONT <i>This element is always shown.</i>
hostname	Parameter type: <Gpon::HostName> (undefined unknown <Gpon::hostname>) Possible values: - undefined : DHCP is unavailable or ONT returns null string - unknown : OLT could not communicate with ONT for discovery Field type <Gpon::hostname> - host name address - length: x<=255	the host name <i>This element is always shown.</i>
ranging-status	Parameter type: <Ng2::OntRangedStatusChanPair> (pref-ranged pref-not-ranged pref-not-ranged-ready pref-not-rng-not-ready prot-ranged prot-not-ranged-ready prot-not-rng-not-ready ranged-parked altpref-ranged altpref-not-ranged-rdy altprf-not-rng-not-rdy) Possible values: - pref-ranged : Channel-pair is preferred and ONT is ranged on it - pref-not-ranged : Channel-pair is preferred and ONT is NOT ranged on it, no protection - pref-not-ranged-ready : Channel-pair is preferred and ONT is NOT ranged on it, ready - pref-not-rng-not-ready: Channel-pair is preferred and ONT is NOT ranged on it, not ready - prot-ranged : Channel-pair is protection and ONT is ranged on it - prot-not-ranged-ready : Channel-pair is protection and ONT is NOT ranged on it, ready - prot-not-rng-not-ready: Channel-pair is protection and ONT is NOT ranged on it, not ready - ranged-parked : Channel-pair is NOT preferred, NOT protection and NOT alternative preferred and ONT is ranged	ont ranging status <i>This element is always shown.</i>

name	Type	Description
	on it, parked - altpref-ranged : Channel-pair is alternative preferred and ONT is ranged on it - altpref-not-ranged-rdy: Channel-pair is alternative preferred and ONT is NOT ranged on it, ready - altprf-not-rng-not-rdy: Channel-pair is alternative preferred and ONT is NOT ranged on it, not ready	

96- Epon Ont Status Command

96.1 Epon Ont Status Command Tree	96-2157
96.2 EONT Interface Status Command	96-2158
96.3 Epon Ont Optics Status Command	96-2163
96.4 Epon Ont LLID Status Command	96-2166
96.5 EONT Software Version Status Command	96-2168
96.6 Epon Pon Performance Statistics Command	96-2169
96.7 Epon Ont Current 15min Status Command	96-2170
96.8 Epon Ont Current 1day Status Command	96-2174
96.9 Epon Ont Previous 15min Status Command	96-2178
96.10 Epon Ont Previous 1day Status Command	96-2182
96.11 Epon Ont Mac Mapping Command	96-2186
96.12 Epon Ont Loid Mapping Command	96-2188

96.1 Epon Ont Status Command Tree

Description

This chapter gives an overview of nodes that are handled by "Epon Ont Status Command".

Command Tree

```

----show
  ----equipment
    ----eont
      ----interface
        - (ont-idx)
      ----optics
        - (ont-idx)
      ----llid
        - (llid-idx)
      ----sw-version
        - (sw-ver-id)
      ----tc-layer
        ----current-15min
          - (ont-idx)
        ----current-1day
          - (ont-idx)
        ----previous-15min
          - (ont-idx)
          ----interval-num
            - (interval-num)
        ----previous-1day
          - (ont-idx)
          ----interval-num
            - (interval-num)
      ----mac-mapping
        - (epon-idx)
        - mac-address
      ----loid-mapping
        - (epon-idx)
        - loid

```

96.2 EONT Interface Status Command

Command Description

This command displays current operational parameters for the eont.

User Level

The command can be accessed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

```
> show equipment eont interface [ (ont-idx) ]
```

Command Parameters

Table 96.2-1 "EONT Interface Status Command" Resource Parameters

Resource Identifier	Type	Description
(ont-idx)	Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Eqpt::OntId> - the ONT identifier	Ont index

Command Output

Table 96.2-2 "EONT Interface Status Command" Display parameters

Specific Information		
name	Type	Description
vendor-id	Parameter type: <Epon::OntIden> - Octet String - length: x<=4	ONT vendor ID <i>This element is always shown.</i>
model-id	Parameter type: <Epon::OntIden> - Octet String - length: x<=4	ONT model ID <i>This element is always shown.</i>
hw-version	Parameter type: <Epon::HwVer> - Octet String	ONT hardware version <i>This element is always shown.</i>

name	Type	Description
	- length: 1<=x<=8	
chip-vendorid	Parameter type: <Epon::ChipId> - Octet String - length: 1<=x<=2	chip vendor id <i>This element is only shown in detail mode.</i>
chip-moduleid	Parameter type: <Epon::ChipId> - Octet String - length: 1<=x<=2	chip module ID <i>This element is only shown in detail mode.</i>
chip-version	Parameter type: <Epon::ChipVer> - Octet String - length: x<=3	chip version <i>This element is only shown in detail mode.</i>
battery-bkup	Parameter type: <Epon::BttryBkup> (yes no) Possible values: - yes : it has backup battery - no : no backup battery	whether the ONT is equipped with battery backup <i>This element is always shown.</i>
sw-ver-act	Parameter type: <Epon::SwVer> - eont sw version - length: x<=16	the active software version in the ONT <i>This element is always shown.</i>
firmware-version	Parameter type: <Epon::FwVer> - Octet String - length: x<=4	firmware version <i>This element is only shown in detail mode.</i>
fec-capability	Parameter type: <Epon::fec> (unknown support nosupport) Possible values: - unknown : - support : - nosupport :	FEC ability of the ONT <i>This element is always shown.</i>
fastleave-capability	Parameter type: <Epon::FLCap> (unknown snoop nfl snoop fl snoop nfl, snoop fl ctc non ctc nfl,snoop nfl ctc nfl,snoop fl ctc-snoop nfl,snoop fl ctc fl ctc fl,snooping nfl ctc fl,snoop fl ctc-snoop fl,snoop nfl ctc fl,ctc nfl ctc fl,ctc-snoop nfl ctc-snoop fl,ctc nfl ctc-snoop fl, nfl) Possible values: - unknown : unknown - snoop nfl : IGMP snooping non-fast-leave - snoop fl : IGMP snooping fast-leave - snoop nfl, snoop fl : IGMP snooping non-fast-leave, IGMP snooping fast-leave - ctc non : CTC non-fast-leave - ctc nfl,snoop nfl : CTC non-fast-leave, IGMP snooping non-fast-leave - ctc nfl,snoop fl : CTC non-fast-leave, IGMP snooping	Fastleave ability of the ont <i>This element is always shown.</i>

name	Type	Description
	fast-leave - ctc-snoop nfl,snoop fl: CTC non-fast-leave, IGMP snooping fast-leave, IGMP snooping non-fast-leave - ctc fl : CTC fast-leave - ctc fl,snooping nfl : CTC fast-leave, IGMP snooping non-fast-leave - ctc fl,snoop fl : CTC fast-leave, IGMP snooping fast-leave - ctc-snoop fl,snoop nfl: CTC fast-leave, IGMP snooping fast-leave, IGMP snooping non-fast-leave - ctc fl,ctc nfl : CTC fast-leave, CTC non-fast-leave - ctc fl,ctc-snoop nfl : CTC fast-leave, CTC non-fast-leave, IGMP snooping non-fast-leave - ctc-snoop fl,ctc nfl : CTC fast-leave, CTC non-fast-leave, IGMP snooping fast-leave - ctc-snoop fl, nfl : CTC fast-leave, CTC non-fast-leave, IGMP snooping fast-leave, IGMP snooping non-fast-leave	
rtt	Parameter type: <Epon::rtt> - round trip time - unit: 16ns - range: [0...27111]	round trip time <i>This element is only shown in detail mode.</i>
maxllid-num	Parameter type: <SignedInteger> - a signed integer	max supported logical link. <i>This element is only shown in detail mode.</i>
assgnqueueup-num	Parameter type: <SignedInteger> - a signed integer	assigned queue number upstream <i>This element is only shown in detail mode.</i>
assgnqueuedown-num	Parameter type: <SignedInteger> - a signed integer	assigned queue number downstream <i>This element is only shown in detail mode.</i>
maxqueueupnum-llid	Parameter type: <SignedInteger> - a signed integer	max queue number per logical link <i>This element is only shown in detail mode.</i>
maxqueuedownnum-port	Parameter type: <SignedInteger> - a signed integer	max queue number per uni-port <i>This element is only shown in detail mode.</i>
fe-num	Parameter type: <SignedInteger> - a signed integer	number of FE ports per ONT <i>This element is only shown in detail mode.</i>
fe-bitmap	Parameter type: <Epon::BitMap> - Octet String - length: 1<=x<=8	FE port bitmap <i>This element is only shown in detail mode.</i>
ge-num	Parameter type: <SignedInteger> - a signed integer	number of GE ports per ONT <i>This element is only shown in detail mode.</i>
ge-bitmap	Parameter type: <Epon::BitMap> - Octet String - length: 1<=x<=8	GE port bitmap <i>This element is only shown in detail mode.</i>
pots-num	Parameter type: <SignedInteger> - a signed integer	number of POTS port per ONT <i>This element is only shown in detail mode.</i>
e1-num	Parameter type: <SignedInteger> - a signed integer	number of E1 port per ONT <i>This element is only shown in detail mode.</i>
adsl2-num	Parameter type: <SignedInteger> - a signed integer	number of ADSL2+ port per ONT

name	Type	Description
		<i>This element is only shown in detail mode.</i>
vdsl-num	Parameter type: <SignedInteger> - a signed integer	number of VDSL2 port per ONT <i>This element is only shown in detail mode.</i>
actual-mac	Parameter type: <Epon::MacAddr> - mac-address (example : 01:02:03:04:05:06) - length: 6	actual ONT Mac address <i>This element is always shown.</i>
ipv6-aware	Parameter type: <Epon::Ipv6Aware> (nosupport support) Possible values: - nosupport : - support :	support IPV6 or not <i>This element is only shown in detail mode.</i>
power-control-cap	Parameter type: <Epon::PowerControlCap> (nosupport tx tx and rx) Possible values: - nosupport : - tx : - tx and rx :	the Ont power control capability <i>This element is only shown in detail mode.</i>
ont-type	Parameter type: <Epon::OntType> (sfu hgu sbu box_model_mdu mini_modular_mdu box_modular_mdu frame_modular_mdu modular_mdu mtu) Possible values: - sfu : - hgu : - sbu : - box_model_mdu : - mini_modular_mdu : - box_modular_mdu : - frame_modular_mdu : - modular_mdu : - mtu :	the Ont type <i>This element is only shown in detail mode.</i>
ont-protection-type	Parameter type: <Epon::Ont ProtecType> (nosupport typec typed) Possible values: - nosupport : - typec : - typed :	the Ont protection type <i>This element is only shown in detail mode.</i>
pon-port-num	Parameter type: <SignedInteger> - a signed integer	Pon port number <i>This element is only shown in detail mode.</i>
ont-slot-num	Parameter type: <SignedInteger> - a signed integer	ont slot number <i>This element is only shown in detail mode.</i>
wlan-port-num	Parameter type: <SignedInteger>	ont WLAN port number

96 Epon Ont Status Command

name	Type	Description
	- a signed integer	<i>This element is only shown in detail mode.</i>
usb-port-num	Parameter type: <SignedInteger> - a signed integer	ont USB port number <i>This element is only shown in detail mode.</i>
rf-port-num	Parameter type: <SignedInteger> - a signed integer	ont RF port number <i>This element is only shown in detail mode.</i>
alarm-profile	Parameter type: <Epon::EponAlrmCtrlProfileName> - name of the Alarm Control profile - length: 1<=x<=32	name of the alarm control profile <i>This element is only shown in detail mode.</i>

96.3 Epon Ont Optics Status Command

Command Description

User Level

The command can be accessed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

```
> show equipment eont optics [ (ont-idx) ]
```

Command Parameters

Table 96.3-1 "Epon Ont Optics Status Command" Resource Parameters

Resource Identifier	Type	Description
(ont-idx)	Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Eqpt::OntId> - the ONT identifier	Ont index

Command Output

Table 96.3-2 "Epon Ont Optics Status Command" Display parameters

Specific Information		
name	Type	Description
ont-tx-sig-lvl 0.1uw	Parameter type: <Epon::OpticalSignalLevel> (unknown <Epon::OpticalSignalLevel>) Possible values: - unknown : a valid measurement is currently unattainable for some reason Field type <Epon::OpticalSignalLevel> - olt optical signal level - unit: 0.1 uW - range: [0...65535]	This attribute indicates the current measurement of the ONT transmit optical signal level in 0.1 uW steps <i>This element is always shown.</i>

96 Epon Ont Status Command

name	Type	Description
ont-tx-sig-lvl dbm	Parameter type: <Epon::OpticalPwrDbm> (-inf unknown <Epon::OpticalPwrDbm>) Possible values: - -inf : - unknown : a valid measurement is currently unattainable for some reason Field type <Epon::OpticalPwrDbm> - power of optical unit - unit: dbm - range: [-99.0...9.0]	This attribute indicates the current measurement of the ONT transmit optical signal level in dBm <i>This element is only shown in detail mode.</i>
ont-rx-sig-lvl 0.1uw	Parameter type: <Epon::OpticalSignalLevel> (unknown <Epon::OpticalSignalLevel>) Possible values: - unknown : a valid measurement is currently unattainable for some reason Field type <Epon::OpticalSignalLevel> - olt optical signal level - unit: 0.1 uW - range: [0...65535]	This attribute indicates the current measurement of the ONT receive optical signal level in 0.1 uW steps <i>This element is always shown.</i>
ont-rx-sig-lvl dbm	Parameter type: <Epon::OpticalPwrDbm> (-inf unknown <Epon::OpticalPwrDbm>) Possible values: - -inf : - unknown : a valid measurement is currently unattainable for some reason Field type <Epon::OpticalPwrDbm> - power of optical unit - unit: dbm - range: [-99.0...9.0]	This attribute indicates the current measurement of the ONT receive optical signal level in dBm <i>This element is only shown in detail mode.</i>
ont-temperature 1/256c short name: ont-temperature 1//256c	Parameter type: <Epon::Temperature> (unknown <Epon::Temperature>) Possible values: - unknown : a valid measurement is currently unattainable for some reason Field type <Epon::Temperature> - temperature of olt optical module - unit: 1/256 Celsius - range: [-32768...32768]	This attribute indicates the current temperature of the optics module associated with this ONT <i>This element is always shown.</i>
ont-temperature c	Parameter type: <Epon::OpticalTempC> - temperature of optical unit - unit: degree C - range: [-128...128]	This attribute indicates the current temperature of the optics module associated with this ONT <i>This element is only shown in detail mode.</i>
ont-voltage 0.1mv short name: ont-voltage-0.1mv	Parameter type: <Epon::Voltage> (unknown <Epon::Voltage>) Possible values: - unknown : a valid measurement is currently unattainable for some reason Field type <Epon::Voltage> - power feed voltage of olt optical module	This attribute indicates the current voltage of the optics module associated with this ONT <i>This element is always shown.</i>

name	Type	Description
	- unit: 100u Volts - range: [0...65500]	
ont-voltage v	Parameter type: <Epon::OpticalVoltageV> - voltage of optical unit - unit: volts - range: [0...6.55]	This attribute indicates the current voltage of the optics module associated with this ONT <i>This element is only shown in detail mode.</i>
ont-bias 2ua	Parameter type: <Epon::LaserBias> (unknown <Epon::LaserBias>) Possible values: - unknown : a valid measurement is currently unattainable for some reason Field type <Epon::LaserBias> - indicates the current bias current of the laser - unit: 2uA - range: [0...131000]	This attribute indicates the current bias current in 2 uA steps of the laser associated with this ONT <i>This element is always shown.</i>
ont-bias ma	Parameter type: <Epon::OpticalBiasMa> - bias of optical unit - unit: mA - range: [0...262]	This attribute indicates the current bias current in mA of the laser associated with this ONT <i>This element is only shown in detail mode.</i>
olt-rx-sig-lvl 0.1uw	Parameter type: <Epon::OpticalSignalLevel> (unknown <Epon::OpticalSignalLevel>) Possible values: - unknown : a valid measurement is currently unattainable for some reason Field type <Epon::OpticalSignalLevel> - olt optical signal level - unit: 0.1 uW - range: [0...65535]	This attribute indicates the current measurement of the ONT receive optical signal level in 0.1 uW steps for the specific ONT <i>This element is always shown.</i>
olt-rx-sig-lvl dbm	Parameter type: <Epon::OpticalPwrDbm> (-inf unknown <Epon::OpticalPwrDbm>) Possible values: - -inf ; - unknown : a valid measurement is currently unattainable for some reason Field type <Epon::OpticalPwrDbm> - power of optical unit - unit: dbm - range: [-99.0...9.0]	This attribute indicates the current measurement of the ONT receive optical signal level in dBm for the specific ONT <i>This element is only shown in detail mode.</i>

96.4 Epon Ont LLID Status Command

Command Description

User Level

The command can be accessed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

```
> show equipment eont llid [ (llid-idx) ]
```

Command Parameters

Table 96.4-1 "Epon Ont LLID Status Command" Resource Parameters

Resource Identifier	Type	Description
(llid-idx)	Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Epon::llid> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Eqpt::OntId> - the ONT identifier Field type <Epon::llid> - Ont llid number, range 1 for EPON, range 1-8 for DPOE - range: [1...8]	Ont llid index

Command Output

Table 96.4-2 "Epon Ont LLID Status Command" Display parameters

Specific Information		
name	Type	Description
up-queue-num	Parameter type: <Epon::QNum> - a signed integer	This attribute indicates the queue number upstream for LLID. <i>This element is always shown.</i>
assigned-serial-num	Parameter type: <Epon::SerialNum> - a signed integer	This attribute indicates the assigned serial number of LLID. <i>This element is always shown.</i>

96.5 EONT Software Version Status Command

Command Description

This command reports the ont software version files that are currently resident on the nt file system.

User Level

The command can be accessed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

> show equipment eont sw-version [(sw-ver-id)]

Command Parameters

Table 96.5-1 "EONT Software Version Status Command" Resource Parameters

Resource Identifier	Type	Description
(sw-ver-id)	Format: - software version info index - range: [1...250]	index of software version file

Command Output

Table 96.5-2 "EONT Software Version Status Command" Display parameters

Specific Information		
name	Type	Description
sw-ver	Parameter type: <Epon::EontVersion> - eont sw version - length: x<=16	eont software version identifier. <i>This element is always shown.</i>
sw-ver-size	Parameter type: <Epon::EontSwVerSize> - eont software file size - unit: bytes - range: [0...4294967295]	this attribute contains the eont software file size (in bytes). <i>This element is always shown.</i>

96.6 Epon Pon Performance Statistics Command

Command Description

This command indicates the Epon performance counters specific to a PON port on ONT side.

User Level

The command can be accessed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

```
> show equipment eont tc-layer
```

96.7 Epon Ont Current 15min Status Command

Command Description

User Level

The command can be accessed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

```
> show equipment eont tc-layer current-15min [ (ont-idx) ]
```

Command Parameters

Table 96.7-1 "Epon Ont Current 15min Status Command" Resource Parameters

Resource Identifier	Type	Description
(ont-idx)	Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Eqpt::OntId> - the ONT identifier	Ont index

Command Output

Table 96.7-2 "Epon Ont Current 15min Status Command" Display parameters

Specific Information		
name	Type	Description
elapsed-time	Parameter type: <SignedInteger> - a signed integer	Elapsed time in interval <i>This element is always shown.</i>
measure-time	Parameter type: <SignedInteger> - a signed integer	Measured time in interval <i>This element is always shown.</i>
octets-up	Parameter type: <Epon::OctetCounter> - Epon Frames counter	octets transferred in upstream direction <i>This element is always shown.</i>
frames-up	Parameter type: <Epon::OctetCounter> - Epon Frames counter	Total Frames transferred in upstream direction <i>This element is always shown.</i>

name	Type	Description
segment1octets-up	Parameter type: <Epon::OctetCounter> - Epon Frames counter	64 Octet Frames in upstream direction <i>This element is only shown in detail mode.</i>
segment2octets-up	Parameter type: <Epon::OctetCounter> - Epon Frames counter	65-127 Octet Frames in upstream direction <i>This element is only shown in detail mode.</i>
segment3octets-up	Parameter type: <Epon::OctetCounter> - Epon Frames counter	128-255 Octet Frames in upstream direction <i>This element is only shown in detail mode.</i>
segment4octets-up	Parameter type: <Epon::OctetCounter> - Epon Frames counter	256-511 Octet Frames in upstream direction <i>This element is only shown in detail mode.</i>
segment5octets-up	Parameter type: <Epon::OctetCounter> - Epon Frames counter	512-1023 Octet Frames in upstream direction <i>This element is only shown in detail mode.</i>
segment6octets-up	Parameter type: <Epon::OctetCounter> - Epon Frames counter	1024-1518 Octet Frames in upstream direction <i>This element is only shown in detail mode.</i>
segment7octets-up	Parameter type: <Epon::OctetCounter> - Epon Frames counter	1519+ Octet Frames in upstream direction <i>This element is only shown in detail mode.</i>
octets-down	Parameter type: <Epon::OctetCounter> - Epon Frames counter	octets transferred in downstream direction <i>This element is always shown.</i>
frames-down	Parameter type: <Epon::OctetCounter> - Epon Frames counter	Total Frames transferred in downstream direction <i>This element is always shown.</i>
segment1octets-down	Parameter type: <Epon::OctetCounter> - Epon Frames counter	64 Octet Frames in downstream direction <i>This element is only shown in detail mode.</i>
segment2octets-down	Parameter type: <Epon::OctetCounter> - Epon Frames counter	65-127 Octet Frames in downstream direction <i>This element is only shown in detail mode.</i>
segment3octets-down	Parameter type: <Epon::OctetCounter> - Epon Frames counter	128-255 Octet Frames in downstream direction <i>This element is only shown in detail mode.</i>
segment4octets-down	Parameter type: <Epon::OctetCounter> - Epon Frames counter	256-511 Octet Frames in downstream direction <i>This element is only shown in detail mode.</i>
segment5octets-down	Parameter type: <Epon::OctetCounter> - Epon Frames counter	512-1023 Octet Frames in downstream direction <i>This element is only shown in detail mode.</i>
segment6octets-down	Parameter type: <Epon::OctetCounter> - Epon Frames counter	1024-1518 Octet Frames in downstream direction <i>This element is only shown in</i>

96 Epon Ont Status Command

name	Type	Description
		<i>detail mode.</i>
segment7octets-down	Parameter type: <Epon::OctetCounter> - Epon Frames counter	1519+ Octet Frames in downstream direction <i>This element is only shown in detail mode.</i>
unicastframes-up	Parameter type: <Epon::OctetCounter> - Epon Frames counter	unicast Frames in upstream direction <i>This element is only shown in detail mode.</i>
unicastframes-down	Parameter type: <Epon::OctetCounter> - Epon Frames counter	unicast Frames in downstream direction <i>This element is only shown in detail mode.</i>
multicastframes-up	Parameter type: <Epon::OctetCounter> - Epon Frames counter	multicast Frames in upstream direction <i>This element is only shown in detail mode.</i>
multicastframes-down	Parameter type: <Epon::OctetCounter> - Epon Frames counter	multicast Frames in downstream direction <i>This element is only shown in detail mode.</i>
broadcastframes-up	Parameter type: <Epon::OctetCounter> - Epon Frames counter	boardcast Frames in upstream direction <i>This element is only shown in detail mode.</i>
broadcastframes-down	Parameter type: <Epon::OctetCounter> - Epon Frames counter	boardcast Frames in downstream direction <i>This element is only shown in detail mode.</i>
drpframes-up	Parameter type: <Epon::OctetCounter> - Epon Frames counter	discard Frames in upstream direction <i>This element is only shown in detail mode.</i>
drpframes-down	Parameter type: <Epon::OctetCounter> - Epon Frames counter	discard Frames in downstream direction <i>This element is only shown in detail mode.</i>
errframes-up	Parameter type: <Epon::OctetCounter> - Epon Frames counter	error Frames in upstream direction <i>This element is only shown in detail mode.</i>
errframes-down	Parameter type: <Epon::OctetCounter> - Epon Frames counter	error Frames in downstream direction <i>This element is only shown in detail mode.</i>
crcerrframes-down	Parameter type: <Epon::OctetCounter> - Epon Frames counter	CRC error Frames in downstream direction <i>This element is only shown in detail mode.</i>
undframes-up	Parameter type: <Epon::OctetCounter> - Epon Frames counter	less than 64 bytes Frames in upstream direction <i>This element is only shown in detail mode.</i>
undframes-down	Parameter type: <Epon::OctetCounter> - Epon Frames counter	less than 64 bytes Frames in downstream direction <i>This element is only shown in detail mode.</i>

name	Type	Description
ovrframes-up	Parameter type: <Epon::OctetCounter> - Epon Frames counter	1526+ Frames in upstream direction <i>This element is only shown in detail mode.</i>
ovrframes-down	Parameter type: <Epon::OctetCounter> - Epon Frames counter	1526+ Frames in downstream direction <i>This element is only shown in detail mode.</i>
dropevents-up	Parameter type: <Epon::OctetCounter> - Epon Frames counter	drop event in upstream direction on a ONT PON port <i>This element is only shown in detail mode.</i>
dropevents-down	Parameter type: <Epon::OctetCounter> - Epon Frames counter	drop event in downstream direction on a ONT PON port <i>This element is only shown in detail mode.</i>
fragments-up	Parameter type: <Epon::OctetCounter> - Epon Frames counter	fragment frames in upstream direction on a ONT PON port <i>This element is only shown in detail mode.</i>
fragments-down	Parameter type: <Epon::OctetCounter> - Epon Frames counter	fragment frames in downstream direction on a ONT PON port <i>This element is only shown in detail mode.</i>
jabberframes-up	Parameter type: <Epon::OctetCounter> - Epon Frames counter	jabber frames in upstream direction on a ONT PON port <i>This element is only shown in detail mode.</i>
jabberframes-down	Parameter type: <Epon::OctetCounter> - Epon Frames counter	jabber frames in downstream direction on a ONT PON port <i>This element is only shown in detail mode.</i>
statuschange	Parameter type: <Epon::OctetCounter> - Epon Frames counter	the number of status change on a ONT PON port <i>This element is only shown in detail mode.</i>

96.8 Epon Ont Current 1day Status Command

Command Description

User Level

The command can be accessed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

```
> show equipment eont tc-layer current-1day [ (ont-idx) ]
```

Command Parameters

Table 96.8-1 "Epon Ont Current 1day Status Command" Resource Parameters

Resource Identifier	Type	Description
(ont-idx)	Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Eqpt::OntId> - the ONT identifier	Ont index

Command Output

Table 96.8-2 "Epon Ont Current 1day Status Command" Display parameters

Specific Information		
name	Type	Description
elapsed-time	Parameter type: <SignedInteger> - a signed integer	Elapsed time in interval <i>This element is always shown.</i>
measure-time	Parameter type: <SignedInteger> - a signed integer	Measured time in interval <i>This element is always shown.</i>
octets-up	Parameter type: <Epon::OctetCounter> - Epon Frames counter	octets transferred in upstream direction <i>This element is always shown.</i>
frames-up	Parameter type: <Epon::OctetCounter> - Epon Frames counter	Total Frames transferred in upstream direction <i>This element is always shown.</i>

name	Type	Description
segment1octets-up	Parameter type: <Epon::OctetCounter> - Epon Frames counter	64 Octet Frames in upstream direction <i>This element is only shown in detail mode.</i>
segment2octets-up	Parameter type: <Epon::OctetCounter> - Epon Frames counter	65-127 Octet Frames in upstream direction <i>This element is only shown in detail mode.</i>
segment3octets-up	Parameter type: <Epon::OctetCounter> - Epon Frames counter	128-255 Octet Frames in upstream direction <i>This element is only shown in detail mode.</i>
segment4octets-up	Parameter type: <Epon::OctetCounter> - Epon Frames counter	256-511 Octet Frames in upstream direction <i>This element is only shown in detail mode.</i>
segment5octets-up	Parameter type: <Epon::OctetCounter> - Epon Frames counter	512-1023 Octet Frames in upstream direction <i>This element is only shown in detail mode.</i>
segment6octets-up	Parameter type: <Epon::OctetCounter> - Epon Frames counter	1024-1518 Octet Frames in upstream direction <i>This element is only shown in detail mode.</i>
segment7octets-up	Parameter type: <Epon::OctetCounter> - Epon Frames counter	1519+ Octet Frames in upstream direction <i>This element is only shown in detail mode.</i>
octets-down	Parameter type: <Epon::OctetCounter> - Epon Frames counter	octets transferred in downstream direction <i>This element is always shown.</i>
frames-down	Parameter type: <Epon::OctetCounter> - Epon Frames counter	Total Frames transferred in downstream direction <i>This element is always shown.</i>
segment1octets-down	Parameter type: <Epon::OctetCounter> - Epon Frames counter	64 Octet Frames in downstream direction <i>This element is only shown in detail mode.</i>
segment2octets-down	Parameter type: <Epon::OctetCounter> - Epon Frames counter	65-127 Octet Frames in downstream direction <i>This element is only shown in detail mode.</i>
segment3octets-down	Parameter type: <Epon::OctetCounter> - Epon Frames counter	128-255 Octet Frames in downstream direction <i>This element is only shown in detail mode.</i>
segment4octets-down	Parameter type: <Epon::OctetCounter> - Epon Frames counter	256-511 Octet Frames in downstream direction <i>This element is only shown in detail mode.</i>
segment5octets-down	Parameter type: <Epon::OctetCounter> - Epon Frames counter	512-1023 Octet Frames in downstream direction <i>This element is only shown in detail mode.</i>
segment6octets-down	Parameter type: <Epon::OctetCounter> - Epon Frames counter	1024-1518 Octet Frames in downstream direction <i>This element is only shown in</i>

96 Epon Ont Status Command

name	Type	Description
		<i>detail mode.</i>
segment7octets-down	Parameter type: <Epon::OctetCounter> - Epon Frames counter	1519+ Octet Frames in downstream direction <i>This element is only shown in detail mode.</i>
unicastframes-up	Parameter type: <Epon::OctetCounter> - Epon Frames counter	unicast Frames in upstream direction <i>This element is only shown in detail mode.</i>
unicastframes-down	Parameter type: <Epon::OctetCounter> - Epon Frames counter	unicast Frames in downstream direction <i>This element is only shown in detail mode.</i>
multicastframes-up	Parameter type: <Epon::OctetCounter> - Epon Frames counter	multicast Frames in upstream direction <i>This element is only shown in detail mode.</i>
multicastframes-down	Parameter type: <Epon::OctetCounter> - Epon Frames counter	multicast Frames in downstream direction <i>This element is only shown in detail mode.</i>
broadcastframes-up	Parameter type: <Epon::OctetCounter> - Epon Frames counter	boardcast Frames in upstream direction <i>This element is only shown in detail mode.</i>
broadcastframes-down	Parameter type: <Epon::OctetCounter> - Epon Frames counter	boardcast Frames in downstream direction <i>This element is only shown in detail mode.</i>
drpframes-up	Parameter type: <Epon::OctetCounter> - Epon Frames counter	discard Frames in upstream direction <i>This element is only shown in detail mode.</i>
drpframes-down	Parameter type: <Epon::OctetCounter> - Epon Frames counter	discard Frames in downstream direction <i>This element is only shown in detail mode.</i>
errframes-up	Parameter type: <Epon::OctetCounter> - Epon Frames counter	error Frames in upstream direction <i>This element is only shown in detail mode.</i>
errframes-down	Parameter type: <Epon::OctetCounter> - Epon Frames counter	error Frames in downstream direction <i>This element is only shown in detail mode.</i>
crcerrframes-down	Parameter type: <Epon::OctetCounter> - Epon Frames counter	CRC error Frames in downstream direction <i>This element is only shown in detail mode.</i>
undframes-up	Parameter type: <Epon::OctetCounter> - Epon Frames counter	less than 64 bytes Frames in upstream direction <i>This element is only shown in detail mode.</i>
undframes-down	Parameter type: <Epon::OctetCounter> - Epon Frames counter	less than 64 bytes Frames in downstream direction <i>This element is only shown in detail mode.</i>

name	Type	Description
ovrframes-up	Parameter type: <Epon::OctetCounter> - Epon Frames counter	1526+ Frames in upstream direction <i>This element is only shown in detail mode.</i>
ovrframes-down	Parameter type: <Epon::OctetCounter> - Epon Frames counter	1526+ Frames in downstream direction <i>This element is only shown in detail mode.</i>
dropevents-up	Parameter type: <Epon::OctetCounter> - Epon Frames counter	drop event in upstream direction on a ONT PON port <i>This element is only shown in detail mode.</i>
dropevents-down	Parameter type: <Epon::OctetCounter> - Epon Frames counter	drop event in downstream direction on a ONT PON port <i>This element is only shown in detail mode.</i>
fragments-up	Parameter type: <Epon::OctetCounter> - Epon Frames counter	fragment frames in upstream direction on a ONT PON port <i>This element is only shown in detail mode.</i>
fragments-down	Parameter type: <Epon::OctetCounter> - Epon Frames counter	fragment frames in downstream direction on a ONT PON port <i>This element is only shown in detail mode.</i>
jabberframes-up	Parameter type: <Epon::OctetCounter> - Epon Frames counter	jabber frames in upstream direction on a ONT PON port <i>This element is only shown in detail mode.</i>
jabberframes-down	Parameter type: <Epon::OctetCounter> - Epon Frames counter	jabber frames in downstream direction on a ONT PON port <i>This element is only shown in detail mode.</i>
statuschange	Parameter type: <Epon::OctetCounter> - Epon Frames counter	the number of status change on a ONT PON port <i>This element is only shown in detail mode.</i>

96.9 Epon Ont Previous 15min Status Command

Command Description

User Level

The command can be accessed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

```
> show equipment eont tc-layer previous-15min (ont-idx) interval-num [ (interval-num) ]
```

Command Parameters

Table 96.9-1 "Epon Ont Previous 15min Status Command" Resource Parameters

Resource Identifier	Type	Description
(ont-idx)	Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Eqpt::OntId> - the ONT identifier	Ont index
(interval-num)	Format: - Previous interval reference - range: [1...192]	Previous interval reference

Command Output

Table 96.9-2 "Epon Ont Previous 15min Status Command" Display parameters

Specific Information		
name	Type	Description
measure-time	Parameter type: <SignedInteger> - a signed integer	Measured time in interval <i>This element is always shown.</i>
octets-up	Parameter type: <Epon::OctetCounter> - Epon Frames counter	octets transferred in upstream direction <i>This element is always shown.</i>
frames-up	Parameter type: <Epon::OctetCounter> - Epon Frames counter	Total Frames transferred in upstream direction

name	Type	Description
		<i>This element is always shown.</i>
segment1octets-up	Parameter type: <Epon::OctetCounter> - Epon Frames counter	64 Octet Frames in upstream direction <i>This element is only shown in detail mode.</i>
segment2octets-up	Parameter type: <Epon::OctetCounter> - Epon Frames counter	65-127 Octet Frames in upstream direction <i>This element is only shown in detail mode.</i>
segment3octets-up	Parameter type: <Epon::OctetCounter> - Epon Frames counter	128-255 Octet Frames in upstream direction <i>This element is only shown in detail mode.</i>
segment4octets-up	Parameter type: <Epon::OctetCounter> - Epon Frames counter	256-511 Octet Frames in upstream direction <i>This element is only shown in detail mode.</i>
segment5octets-up	Parameter type: <Epon::OctetCounter> - Epon Frames counter	512-1023 Octet Frames in upstream direction <i>This element is only shown in detail mode.</i>
segment6octets-up	Parameter type: <Epon::OctetCounter> - Epon Frames counter	1024-1518 Octet Frames in upstream direction <i>This element is only shown in detail mode.</i>
segment7octets-up	Parameter type: <Epon::OctetCounter> - Epon Frames counter	1519+ Octet Frames in upstream direction <i>This element is only shown in detail mode.</i>
octets-down	Parameter type: <Epon::OctetCounter> - Epon Frames counter	octets transferred in downstream direction <i>This element is always shown.</i>
frames-down	Parameter type: <Epon::OctetCounter> - Epon Frames counter	Total Frames transferred in downstream direction <i>This element is always shown.</i>
segment1octets-down	Parameter type: <Epon::OctetCounter> - Epon Frames counter	64 Octet Frames in downstream direction <i>This element is only shown in detail mode.</i>
segment2octets-down	Parameter type: <Epon::OctetCounter> - Epon Frames counter	65-127 Octet Frames in downstream direction <i>This element is only shown in detail mode.</i>
segment3octets-down	Parameter type: <Epon::OctetCounter> - Epon Frames counter	128-255 Octet Frames in downstream direction <i>This element is only shown in detail mode.</i>
segment4octets-down	Parameter type: <Epon::OctetCounter> - Epon Frames counter	256-511 Octet Frames in downstream direction <i>This element is only shown in detail mode.</i>
segment5octets-down	Parameter type: <Epon::OctetCounter> - Epon Frames counter	512-1023 Octet Frames in downstream direction <i>This element is only shown in detail mode.</i>
segment6octets-down	Parameter type: <Epon::OctetCounter> - Epon Frames counter	1024-1518 Octet Frames in downstream direction

96 Epon Ont Status Command

name	Type	Description
		<i>This element is only shown in detail mode.</i>
segment7octets-down	Parameter type: <Epon::OctetCounter> - Epon Frames counter	1519+ Octet Frames in downstream direction <i>This element is only shown in detail mode.</i>
unicastframes-up	Parameter type: <Epon::OctetCounter> - Epon Frames counter	unicast Frames in upstream direction <i>This element is only shown in detail mode.</i>
unicastframes-down	Parameter type: <Epon::OctetCounter> - Epon Frames counter	unicast Frames in downstream direction <i>This element is only shown in detail mode.</i>
multicastframes-up	Parameter type: <Epon::OctetCounter> - Epon Frames counter	multicast Frames in upstream direction <i>This element is only shown in detail mode.</i>
multicastframes-down	Parameter type: <Epon::OctetCounter> - Epon Frames counter	multicast Frames in downstream direction <i>This element is only shown in detail mode.</i>
broadcastframes-up	Parameter type: <Epon::OctetCounter> - Epon Frames counter	boardcast Frames in upstream direction <i>This element is only shown in detail mode.</i>
broadcastframes-down	Parameter type: <Epon::OctetCounter> - Epon Frames counter	boardcast Frames in downstream direction <i>This element is only shown in detail mode.</i>
drpframes-up	Parameter type: <Epon::OctetCounter> - Epon Frames counter	discard Frames in upstream direction <i>This element is only shown in detail mode.</i>
drpframes-down	Parameter type: <Epon::OctetCounter> - Epon Frames counter	discard Frames in downstream direction <i>This element is only shown in detail mode.</i>
errframes-up	Parameter type: <Epon::OctetCounter> - Epon Frames counter	error Frames in upstream direction <i>This element is only shown in detail mode.</i>
errframes-down	Parameter type: <Epon::OctetCounter> - Epon Frames counter	error Frames in downstream direction <i>This element is only shown in detail mode.</i>
crcerrframes-down	Parameter type: <Epon::OctetCounter> - Epon Frames counter	CRC error Frames in downstream direction <i>This element is only shown in detail mode.</i>
undframes-up	Parameter type: <Epon::OctetCounter> - Epon Frames counter	less than 64 bytes Frames in upstream direction <i>This element is only shown in detail mode.</i>
undframes-down	Parameter type: <Epon::OctetCounter> - Epon Frames counter	less than 64 bytes Frames in downstream direction <i>This element is only shown in</i>

name	Type	Description
		<i>detail mode.</i>
ovrframes-up	Parameter type: <Epon::OctetCounter> - Epon Frames counter	1526+ Frames in upstream direction <i>This element is only shown in detail mode.</i>
ovrframes-down	Parameter type: <Epon::OctetCounter> - Epon Frames counter	1526+ Frames in downstream direction <i>This element is only shown in detail mode.</i>
dropevents-up	Parameter type: <Epon::OctetCounter> - Epon Frames counter	drop event in upstream direction on a ONT PON port <i>This element is only shown in detail mode.</i>
dropevents-down	Parameter type: <Epon::OctetCounter> - Epon Frames counter	drop event in downstream direction on a ONT PON port <i>This element is only shown in detail mode.</i>
fragments-up	Parameter type: <Epon::OctetCounter> - Epon Frames counter	fragment frames in upstream direction on a ONT PON port <i>This element is only shown in detail mode.</i>
fragments-down	Parameter type: <Epon::OctetCounter> - Epon Frames counter	fragment frames in downstream direction on a ONT PON port <i>This element is only shown in detail mode.</i>
jabberframes-up	Parameter type: <Epon::OctetCounter> - Epon Frames counter	jabber frames in upstream direction on a ONT PON port <i>This element is only shown in detail mode.</i>
jabberframes-down	Parameter type: <Epon::OctetCounter> - Epon Frames counter	jabber frames in downstream direction on a ONT PON port <i>This element is only shown in detail mode.</i>
statuschange	Parameter type: <Epon::OctetCounter> - Epon Frames counter	the number of status change on a ONT PON port <i>This element is only shown in detail mode.</i>

96.10 Epon Ont Previous 1day Status Command

Command Description

User Level

The command can be accessed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

```
> show equipment eont tc-layer previous-1day (ont-idx) interval-num [ (interval-num) ]
```

Command Parameters

Table 96.10-1 "Epon Ont Previous 1day Status Command" Resource Parameters

Resource Identifier	Type	Description
(ont-idx)	Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Eqpt::OntId> - the ONT identifier	Ont index
(interval-num)	Format: - Previous interval reference - range: [1...2]	Previous interval reference

Command Output

Table 96.10-2 "Epon Ont Previous 1day Status Command" Display parameters

Specific Information		
name	Type	Description
measure-time	Parameter type: <SignedInteger> - a signed integer	Measured time in interval <i>This element is always shown.</i>
octets-up	Parameter type: <Epon::OctetCounter> - Epon Frames counter	octets transferred in upstream direction <i>This element is always shown.</i>
frames-up	Parameter type: <Epon::OctetCounter> - Epon Frames counter	Total Frames transferred in upstream direction

name	Type	Description
		<i>This element is always shown.</i>
segment1octets-up	Parameter type: <Epon::OctetCounter> - Epon Frames counter	64 Octet Frames in upstream direction <i>This element is only shown in detail mode.</i>
segment2octets-up	Parameter type: <Epon::OctetCounter> - Epon Frames counter	65-127 Octet Frames in upstream direction <i>This element is only shown in detail mode.</i>
segment3octets-up	Parameter type: <Epon::OctetCounter> - Epon Frames counter	128-255 Octet Frames in upstream direction <i>This element is only shown in detail mode.</i>
segment4octets-up	Parameter type: <Epon::OctetCounter> - Epon Frames counter	256-511 Octet Frames in upstream direction <i>This element is only shown in detail mode.</i>
segment5octets-up	Parameter type: <Epon::OctetCounter> - Epon Frames counter	512-1023 Octet Frames in upstream direction <i>This element is only shown in detail mode.</i>
segment6octets-up	Parameter type: <Epon::OctetCounter> - Epon Frames counter	1024-1518 Octet Frames in upstream direction <i>This element is only shown in detail mode.</i>
segment7octets-up	Parameter type: <Epon::OctetCounter> - Epon Frames counter	1519+ Octet Frames in upstream direction <i>This element is only shown in detail mode.</i>
octets-down	Parameter type: <Epon::OctetCounter> - Epon Frames counter	octets transferred in downstream direction <i>This element is always shown.</i>
frames-down	Parameter type: <Epon::OctetCounter> - Epon Frames counter	Total Frames transferred in downstream direction <i>This element is always shown.</i>
segment1octets-down	Parameter type: <Epon::OctetCounter> - Epon Frames counter	64 Octet Frames in downstream direction <i>This element is only shown in detail mode.</i>
segment2octets-down	Parameter type: <Epon::OctetCounter> - Epon Frames counter	65-127 Octet Frames in downstream direction <i>This element is only shown in detail mode.</i>
segment3octets-down	Parameter type: <Epon::OctetCounter> - Epon Frames counter	128-255 Octet Frames in downstream direction <i>This element is only shown in detail mode.</i>
segment4octets-down	Parameter type: <Epon::OctetCounter> - Epon Frames counter	256-511 Octet Frames in downstream direction <i>This element is only shown in detail mode.</i>
segment5octets-down	Parameter type: <Epon::OctetCounter> - Epon Frames counter	512-1023 Octet Frames in downstream direction <i>This element is only shown in detail mode.</i>
segment6octets-down	Parameter type: <Epon::OctetCounter> - Epon Frames counter	1024-1518 Octet Frames in downstream direction

96 Epon Ont Status Command

name	Type	Description
		<i>This element is only shown in detail mode.</i>
segment7octets-down	Parameter type: <Epon::OctetCounter> - Epon Frames counter	1519+ Octet Frames in downstream direction <i>This element is only shown in detail mode.</i>
unicastframes-up	Parameter type: <Epon::OctetCounter> - Epon Frames counter	unicast Frames in upstream direction <i>This element is only shown in detail mode.</i>
unicastframes-down	Parameter type: <Epon::OctetCounter> - Epon Frames counter	unicast Frames in downstream direction <i>This element is only shown in detail mode.</i>
multicastframes-up	Parameter type: <Epon::OctetCounter> - Epon Frames counter	multicast Frames in upstream direction <i>This element is only shown in detail mode.</i>
multicastframes-down	Parameter type: <Epon::OctetCounter> - Epon Frames counter	multicast Frames in downstream direction <i>This element is only shown in detail mode.</i>
broadcastframes-up	Parameter type: <Epon::OctetCounter> - Epon Frames counter	boardcast Frames in upstream direction <i>This element is only shown in detail mode.</i>
broadcastframes-down	Parameter type: <Epon::OctetCounter> - Epon Frames counter	boardcast Frames in downstream direction <i>This element is only shown in detail mode.</i>
drpframes-up	Parameter type: <Epon::OctetCounter> - Epon Frames counter	discard Frames in upstream direction <i>This element is only shown in detail mode.</i>
drpframes-down	Parameter type: <Epon::OctetCounter> - Epon Frames counter	discard Frames in downstream direction <i>This element is only shown in detail mode.</i>
errframes-up	Parameter type: <Epon::OctetCounter> - Epon Frames counter	error Frames in upstream direction <i>This element is only shown in detail mode.</i>
errframes-down	Parameter type: <Epon::OctetCounter> - Epon Frames counter	error Frames in downstream direction <i>This element is only shown in detail mode.</i>
crcerrframes-down	Parameter type: <Epon::OctetCounter> - Epon Frames counter	CRC error Frames in downstream direction <i>This element is only shown in detail mode.</i>
undframes-up	Parameter type: <Epon::OctetCounter> - Epon Frames counter	less than 64 bytes Frames in upstream direction <i>This element is only shown in detail mode.</i>
undframes-down	Parameter type: <Epon::OctetCounter> - Epon Frames counter	less than 64 bytes Frames in downstream direction <i>This element is only shown in</i>

name	Type	Description
		<i>detail mode.</i>
ovrframes-up	Parameter type: <Epon::OctetCounter> - Epon Frames counter	1526+ Frames in upstream direction <i>This element is only shown in detail mode.</i>
ovrframes-down	Parameter type: <Epon::OctetCounter> - Epon Frames counter	1526+ Frames in downstream direction <i>This element is only shown in detail mode.</i>
dropevents-up	Parameter type: <Epon::OctetCounter> - Epon Frames counter	drop event in upstream direction on a ONT PON port <i>This element is only shown in detail mode.</i>
dropevents-down	Parameter type: <Epon::OctetCounter> - Epon Frames counter	drop event in downstream direction on a ONT PON port <i>This element is only shown in detail mode.</i>
fragments-up	Parameter type: <Epon::OctetCounter> - Epon Frames counter	fragment frames in upstream direction on a ONT PON port <i>This element is only shown in detail mode.</i>
fragments-down	Parameter type: <Epon::OctetCounter> - Epon Frames counter	fragment frames in downstream direction on a ONT PON port <i>This element is only shown in detail mode.</i>
jabberframes-up	Parameter type: <Epon::OctetCounter> - Epon Frames counter	jabber frames in upstream direction on a ONT PON port <i>This element is only shown in detail mode.</i>
jabberframes-down	Parameter type: <Epon::OctetCounter> - Epon Frames counter	jabber frames in downstream direction on a ONT PON port <i>This element is only shown in detail mode.</i>
statuschange	Parameter type: <Epon::OctetCounter> - Epon Frames counter	the number of status change on a ONT PON port <i>This element is only shown in detail mode.</i>

96.11 Epon Ont Mac Mapping Command

Command Description

This command displays ont mac mapping

User Level

The command can be accessed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

```
> show equipment eont mac-mapping [ (epon-idx) [ mac-address <Epon::MacAddr> ] ]
```

Command Parameters

Table 96.11-1 "Epon Ont Mac Mapping Command" Resource Parameters

Resource Identifier	Type	Description
(epon-idx)	Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier	epon ifIndex
mac-address	Parameter type: <Epon::MacAddr> Format: - mac-address (example : 01:02:03:04:05:06) - length: 6	epon ont mac address

Command Output

Table 96.11-2 "Epon Ont Mac Mapping Command" Display parameters

Specific Information		
name	Type	Description
ontid	Parameter type: <Epon::OntIdx> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId>	epon ont ifIndex <i>This element is always shown.</i>

name	Type	Description
	- the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Eqpt::OntId> - the ONT identifier	

96.12 Epon Ont Loid Mapping Command

Command Description

This command displays ont loid mapping

User Level

The command can be accessed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

```
> show equipment eont loid-mapping [ (epon-idx) [ loid <Epon::LoidId> ] ]
```

Command Parameters

Table 96.12-1 "Epon Ont Loid Mapping Command" Resource Parameters

Resource Identifier	Type	Description
(epon-idx)	Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier	epon ifIndex
loid	Parameter type: <Epon::LoidId> Format: - Authentication ID - length: 1<=x<=24	epon ont loid

Command Output

Table 96.12-2 "Epon Ont Loid Mapping Command" Display parameters

Specific Information		
name	Type	Description
ontid	Parameter type: <Epon::OntIdx> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId>	epon ont ifIndex <i>This element is always shown.</i>

name	Type	Description
	- the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Eqpt::OntId> - the ONT identifier	

97- *show tc-layer pm data*

97.1 show tc-layer pm data Tree	97-2191
97.2 show TC-layer ONT side Current Interval Performance Data Status Command	97-2192
97.3 show TC-layer ONT side Previous Interval Performance Data Status Command	97-2194

97.1 show tc-layer pm data Tree

Description

This chapter gives an overview of nodes that are handled by "show tc-layer pm data".

Command Tree

```
----show
  ----tc-layer
    ----ont-side
      ----current-interval
        - (index)
      ----previous-interval
        - (index)
        - interval-no
```

97.2 show TC-layer ONT side Current Interval Performance Data Status Command

Command Description

This command displays various statistics collected for Multicast ONT TC-layer during the current 15 minute interval of operation.

User Level

The command can be accessed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

```
> show tc-layer ont-side current-interval [ (index) ]
```

Command Parameters

Table 97.2-1 "show TC-layer ONT side Current Interval Performance Data Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: (uni:ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / <Eqpt::Ng2OntSlotId> / <Eqpt::Ng2OntPortId> voip:ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> mcast : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> uni : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> / <Eqpt::OntPortId> voip : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> mcast:ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId>) Possible values: - mcast : multicast - mcast:ng2 : ngpon2 multicast style identification - uni : uni - uni:ng2 : ngpon2 UNI style identification - voip : voip - voip:ng2 : voip Field type <Eqpt::RackId> - the rack number	pm index

Resource Identifier	Type	Description
	Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Eqpt::ChannelGroupId> - the channel group identifier Field type <Eqpt::SubChannelGroupId> - the subchannel group identifier Field type <Eqpt::OntId> - the ONT identifier Field type <Eqpt::Ng2OntId> - the NG2 ONT identifier Possible values: - vuni : virtual NGPON2 uni identifier Field type <Eqpt::OntSlotId> - the ONT SLOT identifier Field type <Eqpt::OntPortId> - the ONT PORT identifier Field type <Eqpt::Ng2OntSlotId> - the NGPON2 ONT SLOT identifier Field type <Eqpt::Ng2OntPortId> - the NGPON2 ONT PORT identifier	

Command Output

**Table 97.2-2 "show TC-layer ONT side Current Interval Performance Data Status Command"
Display parameters**

Specific Information		
name	Type	Description
tx-gem-frames	Parameter type: <Counter> - 32 bit counter	count of transmit gem frames direction <i>This element is always shown.</i>
rx-gem-frames	Parameter type: <Counter> - 32 bit counter	count of received gem frames <i>This element is always shown.</i>
tx-payload-bytes	Parameter type: <OctetCounter64> - 64 bit counter,range:[0-9223372036854775808]	count of transmit payload bytes <i>This element is always shown.</i>
rx-payload-bytes	Parameter type: <OctetCounter64> - 64 bit counter,range:[0-9223372036854775808]	count of recieved payload bytes <i>This element is always shown.</i>
encrypkey-errors	Parameter type: <Counter> - 32 bit counter	count of get encrypt key errors <i>This element is always shown.</i>

97.3 show TC-layer ONT side Previous Interval Performance Data Status Command

Command Description

This command displays various statistics collected for Multicast ONT TC-layer over the previous 8 hours of operations which is broken in to 32 completed 15 minute intervals.

User Level

The command can be accessed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

```
> show tc-layer ont-side previous-interval [ (index) [ interval-no <Gpon::IntervalNo> ] ]
```

Command Parameters

Table 97.3-1 "show TC-layer ONT side Previous Interval Performance Data Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: (uni:ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / <Eqpt::Ng2OntSlotId> / <Eqpt::Ng2OntPortId> voip:ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> mcast : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> uni : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> / <Eqpt::OntPortId> voip : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> mcast:ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId>) Possible values: - mcast : multicast - mcast:ng2 : ngpon2 multicast style identification - uni : uni - uni:ng2 : ngpon2 UNI style identification - voip : voip - voip:ng2 : voip Field type <Eqpt::RackId> - the rack number	pm index

Resource Identifier	Type	Description
	Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Eqpt::ChannelGroupId> - the channel group identifier Field type <Eqpt::SubChannelGroupId> - the subchannel group identifier Field type <Eqpt::OntId> - the ONT identifier Field type <Eqpt::Ng2OntId> - the NG2 ONT identifier Possible values: - vuni : virtual NGPON2 uni identifier Field type <Eqpt::OntSlotId> - the ONT SLOT identifier Field type <Eqpt::OntPortId> - the ONT PORT identifier Field type <Eqpt::Ng2OntSlotId> - the NGPON2 ONT SLOT identifier Field type <Eqpt::Ng2OntPortId> - the NGPON2 ONT PORT identifier	
interval-no	Parameter type: <Gpon::IntervalNo> Format: - a number of a previous interval number - range: [1...32]	identifies prev 15min intvls, val 1 as the latest intvl

Command Output

**Table 97.3-2 "show TC-layer ONT side Previous Interval Performance Data Status Command"
Display parameters**

Specific Information		
name	Type	Description
tx-gem-frames	Parameter type: <Counter> - 32 bit counter	count of transmit gem frames direction <i>This element is always shown.</i>
rx-gem-frames	Parameter type: <Counter> - 32 bit counter	count of received gem frames <i>This element is always shown.</i>
tx-payload-bytes	Parameter type: <OctetCounter64> - 64 bit counter, range: [0-9223372036854775808]	count of transmit payload bytes <i>This element is always shown.</i>
rx-payload-bytes	Parameter type: <OctetCounter64> - 64 bit counter, range: [0-9223372036854775808]	count of recieved payload bytes <i>This element is always shown.</i>
encrypkey-errors	Parameter type: <Counter> - 32 bit counter	count of get encrypt key errors <i>This element is always shown.</i>

98- Protection Group Status Commands

98.1 Protection Group Status Command Tree	98-2197
98.2 Protection Group Status Command	98-2198

98.1 Protection Group Status Command Tree

Description

This chapter gives an overview of nodes that are handled by "Protection Group Status Commands".

Command Tree

```
----show
  ----port-protection
    - (port)
```

98.2 Protection Group Status Command

Command Description

This command shows the protection group status. The following information is shown for each group :

- *first-port*: describes the port index of the first port in the protection group.
- *paired-port*: describes the port index of the paired port in the protection group.
- *first-state*: describes the operational status of the first port.
- *paired-state*: describes the operational status of the paired port.
- *swo-reason*: describes the reason for the last switchover.
- *num-swo*: describes the number of switchovers that have occurred.

User Level

The command can be accessed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

> show port-protection (port)

Command Parameters

Table 98.2-1 "Protection Group Status Command" Resource Parameters

Resource Identifier	Type	Description
(port)	Format: (pon : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> chpair : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::ChannelPairId>) Possible values: - pon : pon-aid - chpair : chpair-aid Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Eqpt::ChannelPairId> - the channel pair identifier	the port identifier of the first port in the protection group.

Command Output

Table 98.2-2 "Protection Group Status Command" Display parameters

Specific Information		
name	Type	Description
paired-port	Parameter type: <RedPort::PairedPortIndex> (pon : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> chpair : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::ChannelPairId>) Possible values: - pon : pon-aid - chpair : chpair-aid Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Eqpt::ChannelPairId> - the channel pair identifier	the port identifier of the paired port in the protection group. <i>This element is always shown.</i>
port-state	Parameter type: <RedPort::ProtectionStatus> ((active-up act-up) (active-down act-down) (inactive-up inact-up) (inactive-down inact-down)) Possible values: - active-up : - act-up : - active-down : - act-down : - inactive-up : - inact-up : - inactive-down : - inact-down :	specifies the status of the first port in the protection group. <i>This element is always shown.</i>
paired-state	Parameter type: <RedPort::ProtectionStatus> ((active-up act-up) (active-down act-down) (inactive-up inact-up) (inactive-down inact-down)) Possible values: - active-up : - act-up : - active-down : - act-down : - inactive-up : - inact-up : - inactive-down : - inact-down :	specifies the status of the paired port in the protection group. <i>This element is always shown.</i>
swo-reason	Parameter type: <RedPort::SwitchReason> (no-switch-over port-admin-change forced-switch-over link-failure board-failure) Possible values: - no-switch-over : no switch over has been performed yet - port-admin-change : port was set admin down - forced-switch-over : operator requested switchover	specifies the last switchover reason. <i>This element is always shown.</i>

98 Protection Group Status Commands

name	Type	Description
	- link-failure : link failure - board-failure : board failure	
num-swo	Parameter type: <SignedInteger> - a signed integer	specifies the number of times a switchover occurred. <i>This element is always shown.</i>

99- *Trap Status Commands*

99.1 Trap Status Command Tree	99-2202
99.2 Trap Manager Queue Status Command	99-2203
99.3 Trap Manager Queue Status Command	99-2204

99.1 Trap Status Command Tree

Description

This chapter gives an overview of nodes that are handled by "Trap Status Commands".

Command Tree

```
----show
  ----trap
    ----v6manager
      - (ipv6address)
    ----manager
      - (address)
```

99.2 Trap Manager Queue Status Command

Command Description

This command displays the status of the trap manager queue.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show trap v6manager [ (ipv6address) ]
```

Command Parameters

Table 99.2-1 "Trap Manager Queue Status Command" Resource Parameters

Resource Identifier	Type	Description
(ipv6address)	Format: <ipv6::Prefix> / <Trap::Port> Field type <ipv6::Prefix> - IPv6-address Field type <Trap::Port> - trap port number - range: [1...65535]	the IPv6 address of the manager

Command Output

Table 99.2-2 "Trap Manager Queue Status Command" Display parameters

Specific Information		
name	Type	Description
last-reset-time	Parameter type: <Sys::timeInSecs> - the time (yyyy-mm-dd:hour:minutes:secs) - unit: UTC	time when the buffer has been reset. <i>This element is always shown.</i>
buffer-status	Parameter type: <Trap::QueueStatus> (no-traps-lost traps-lost) Possible values: - no-traps-lost : the queue did not overflow - no traps were lost - traps-lost : the queue did overflow - traps were lost	specifies whether the trap buffer is overflowed or not. <i>This element is always shown.</i>

99.3 Trap Manager Queue Status Command

Command Description

This command displays the status of the trap manager queue.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show trap manager [ (address) ]
```

Command Parameters

Table 99.3-1 "Trap Manager Queue Status Command" Resource Parameters

Resource Identifier	Type	Description
(address)	Format: <Ip::V4Address> : <Trap::Port> Field type <Ip::V4Address> - IPv4-address Field type <Trap::Port> - trap port number - range: [1...65535]	the IP address of the manager

Command Output

Table 99.3-2 "Trap Manager Queue Status Command" Display parameters

Specific Information		
name	Type	Description
last-reset-time	Parameter type: <Sys::timeInSecs> - the time (yyyy-mm-dd:hour:minutes:secs) - unit: UTC	time when the buffer has been reset. <i>This element is always shown.</i>
buffer-status	Parameter type: <Trap::QueueStatus> (no-traps-lost traps-lost) Possible values: - no-traps-lost : the queue did not overflow - no traps were lost - traps-lost : the queue did overflow - traps were lost	specifies whether the trap buffer is overflowed or not. <i>This element is always shown.</i>

100- Alarm Delta Log Status Commands

100.1 Alarm Delta Log Status Command Tree	100-2206
100.2 Alarm Generic Delta Alarm Log Status Command	100-2207
100.3 Indeterminate Alarm Delta Log Status Command	100-2209
100.4 Warning Alarm Delta Log Status Command	100-2264
100.5 Minor Alarm Delta Log Status Command	100-2319
100.6 Major Alarm Delta Log Status Command	100-2374
100.7 Critical Alarm Delta Log Status Command	100-2429

100.1 Alarm Delta Log Status Command Tree

Description

This chapter gives an overview of nodes that are handled by "Alarm Delta Log Status Commands".

Command Tree

```
----show
  ----alarm
    ----delta-log
      ----alarm-changes
      ----indeterminate
        - (index)
      ----warning
        - (index)
      ----minor
        - (index)
      ----major
        - (index)
      ----critical
        - (index)
```


100.2 Alarm Generic Delta Alarm Log Status Command

Command Description

This command displays the number of reported alarm changes per severity level and in total.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

> show alarm delta-log alarm-changes

Command Output

Table 100.2-2 "Alarm Generic Delta Alarm Log Status Command" Display parameters

Specific Information		
name	Type	Description
all	Parameter type: <Counter> - 32 bit counter	total number of changes of all reported alarms since startup and is independent of the alarm severity level. <i>This element is always shown.</i>
indeterminate	Parameter type: <Counter> - 32 bit counter	total number of changes of all reported alarms with a severity level indeterminate since startup. <i>This element is always shown.</i>
warning	Parameter type: <Counter> - 32 bit counter	total number of changes of all reported alarms with a severity level warning since startup. <i>This element is always shown.</i>
minor	Parameter type: <Counter> - 32 bit counter	total number of changes of all reported alarms with a severity level minor since startup. <i>This element is always shown.</i>
major	Parameter type: <Counter> - 32 bit counter	total number of changes of all reported alarms with a severity level major since startup. <i>This element is always shown.</i>
critical	Parameter type: <Counter> - 32 bit counter	total number of changes of all reported alarms with a severity level critical since startup. <i>This element is always shown.</i>

100.3 Indeterminate Alarm Delta Log Status Command

Command Description

This command displays alarm values for all reported alarms with a severity level indeterminate.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm delta-log indeterminate [ (index) ]
```

Command Parameters

Table 100.3-1 "Indeterminate Alarm Delta Log Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	delta log alarm table index

Command Output

Table 100.3-2 "Indeterminate Alarm Delta Log Status Command" Display parameters

Specific Information		
name	Type	Description
type	Parameter type: <Alarm::alarmIndexExt> (all xtca-ne-es xtca-ne-ses xtca-ne-uas xtca-ne-day-es xtca-ne-day-ses xtca-ne-day-uas xtca-fe-es xtca-fe-ses xtca-fe-uas xtca-fe-day-es xtca-fe-day-ses xtca-fe-day-uas xtca-leftrs xtca-day-leftrs	unique id for an alarm. <i>This element is always shown.</i>

100 Alarm Delta Log Status Commands

name	Type	Description
	xtca-fe-leftrs	
	xtca-fe-day-leftrs	
	xtca-auto-port-reset	
	xtca-reinit	
	xtca-day-reinit	
	xdsl-ne-los	
	xdsl-ne-lof	
	xdsl-ne-lom	
	xdsl-ne-ese	
	xdsl-act-cfg-error	
	xdsl-act-not-feas	
	xdsl-up-br-reach	
	xdsl-ne-ncd	
	xdsl-ne-lcd	
	xdsl-fe-los	
	xdsl-fe-lof	
	xdsl-fe-lpr	
	xdsl-fe-lol	
	xdsl-fe-lom	
	xdsl-fe-ese	
	xdsl-fe-upbo-vio	
	xdsl-fe-cpe-pol	
	xdsl-tpstc-mis	
	xdsl-act-comm	
	xdsl-act-modem	
	xdsl-do-br-reach	
	xdsl-fe-ncd	
	xdsl-fe-lcd	
	xdsl-frtx-init-fail	
	xdsl-vect-dle	
	xdsl-fe-mis-peer-35b	
	vectline-xtc-var-vict	
	vectline-xtc-var-dist	
	vectline-corp-errf	
	vect-cpe-cap-mismatch	
	vectline-conf_notfeas	
	vect-vp-lt-mismatch	
	vect-inv-qsf	
	vect-vp-lt-fail	
	vect-no-gain-at-init	
	sw-rollback	
	db-rollback	
	xvps-inv-dbase	
	inv-cde-file	
	miss-cde-file	
	cde-hash-error	
	auto-fetch-failure	
	low-disk-space	
	cell-discard-up	
	cell-discard-down	
	persist-data-loss	
	mac-conflict	
	vmac-full	
	sntp-comm-lost	
	preferred-mode	
	timing-reference	
	nt-disk-95%full	

name	Type	Description
	shub-loc	
	cf-error	
	back-pnl-inv	
	ihub-conf-loss	
	rack-power	
	rack-fan-unit1	
	rack-fan-unit2	
	shelf-mismatch	
	shelf-missing	
	shelf-install-missing	
	door	
	ac-power-fail	
	board-mismatch	
	waiting-for-sw	
	temp-exceeded	
	backplane-data-failure	
	temp-shutdown	
	board-missing	
	board-instl-missing	
	board-init	
	board-reset-prot	
	sem-power-fail	
	sem-ups-fail	
	board-reset-cf	
	vlan-assign-fail	
	vsa-info-invalid	
	auth-mac-conflict	
	user-pwd-fault	
	up-plan-bitrate	
	up-min-bitrate	
	up-config-not-feas	
	down-plan-bitrate	
	down-min-bitrate	
	down-config-not-feas	
	non-bonding-cpe	
	multiple-cpes	
	register	
	group-incomplete	
	host-sfp-los	
	host-sfp-tx-fail	
	host-sfp-not-prst	
	host-sfp-inv-id	
	host-sfp-ctrl-fail	
	host-sfp-rmtlt	
	host-sfp-mismatch	
	host-sfp-incompt	
	exp-sfp-los	
	exp-sfp-tx-fail	
	exp-sfp-not-prst	
	exp-sfp-inv-id	
	exp-sfp-ctrl-fail	
	exp-sfp-1-los	
	exp-sfp-2-los	
	ext-qsfp-invld	
	tx-power-high-alarm	
	tx-power-low-alarm	
	rx-power-high-alarm	

100 Alarm Delta Log Status Commands

name	Type	Description
	rx-power-low-alarm tx-biascur-high-alarm tx-biascur-low-alarm volt-high-alarm volt-low-alarm temp-high-alarm temp-low-alarm tx-power-high-warn tx-power-low-warn rx-power-high-warn rx-power-low-warn tx-biascur-high-warn tx-biascur-low-warn volt-high-warn volt-low-warn temp-high-warn temp-low-warn onu-unprovisioned signal-loss bitrate-high opmodule-mismatch key-fail-one-churn key-fail-three-churn oam-discov-fail report-timeout total-packets-exceed arp-packets-exceed dhcp-packets-exceed igmp-packets-exceed pppoe-packets-exceed nd-packets-exceed icmpv6-packets-exceed mld-packets-exceed dhcpv6-packets-exceed cfm-packets-exceed dsx1-serdes-fail dsx1-tributary1-fail dsx1-tributary2-fail dsx1-los-fail dsx1-ais-sync dsx1-lof-sync dsx1-los-sync dsx1-deg-fail dsx1-rei-from-liu dsx1-rdi-from-liu dsx1-crc6-from-liu dsx1-crc4-from-liu dsx1-crc4-th-from-liu dsx1-ais-from-liu dsx1-los-from-liu dsx1-lof-from-liu dsx1-lomf-from-liu dsx1-rei-from-iwf dsx1-rdi-from-iwf dsx1-crc6-from-iwf dsx1-crc4-from-iwf dsx1-crc4-th-from-iwf	

name	Type	Description
	dsx1-ais-from-iwf	
	dsx1-los-from-iwf	
	dsx1-lof-from-iwf	
	dsx1-lomf-from-iwf	
	pppce-trans-15min-tca	
	pppce-sess-15min-tca	
	pppce-trans-1day-tca	
	pppce-sess-1day-tca	
	custom1	
	custom2	
	custom3	
	custom4	
	custom5	
	he-custom1	
	he-custom2	
	he-custom3	
	he-custom4	
	he-custom5	
	he-custom6	
	custom6	
	custom7	
	custom8	
	custom9	
	custom10	
	custom11	
	custom12	
	custom13	
	custom14	
	custom15	
	custom16	
	custom17	
	loss-swo-cap	
	ping-check-fail	
	der-temp1	
	der-temp2	
	der-temp3	
	der-temp4	
	der-temp5	
	der-temp6	
	der-temp7	
	der-temp8	
	der-temp9	
	der-temp10	
	der-temp11	
	der-temp12	
	der-temp13	
	der-temp14	
	der-temp15	
	der-temp16	
	der-temp17	
	der-temp18	
	der-temp19	
	der-temp20	
	der-temp21	
	der-temp22	
	der-temp23	
	der-temp24	

100 Alarm Delta Log Status Commands

name	Type	Description
	der-temp25	
	der-temp26	
	der-temp27	
	der-temp28	
	der-temp29	
	der-temp30	
	der-temp31	
	der-spa1	
	der-spa2	
	der-spa3	
	der-spa4	
	der-spa5	
	der-spa6	
	der-spa7	
	der-spa8	
	der-spa9	
	der-spa10	
	der-spa11	
	der-spa12	
	der-spa13	
	der-spa14	
	der-spa15	
	der-spa16	
	der-spa17	
	der-spa18	
	der-spa19	
	der-spa20	
	der-spa21	
	der-spa22	
	der-spa23	
	der-spa24	
	der-spa25	
	der-spa26	
	der-spa27	
	der-spa28	
	der-spa29	
	der-spa30	
	der-spa31	
	apsf-alarm	
	custextalarm1	
	custextalarm2	
	custextalarm3	
	custextalarm4	
	custextalarm5	
	pluginfan	
	plugin-dc-a	
	plugin-dc-b	
	plugin-dg	
	ntr-a-loss	
	ntr-b-loss	
	xvps-conf-loss	
	mac-entry-nofree	
	fibre-conn-mismatch	
	link-cap-mismatch	
	eqpt-cap-mismatch	
	ctrl-dnld-failure	
	melt-hw-issue	

name	Type	Description
	melt-board-reset board-shelf-mismatch mgnt-type-mismatch fileserv-unavail shdsl-n-loopback shdsl-c-loopback shdsl-conferr shdsl-atm-lcd shdsl-lpr shdsl-secu-err shdsl-dev-fault shdsl-atm-ncd shdsl-n-losw shdsl-c-losw shdsl-n-aten shdsl-c-aten shdsl-n-snr shdsl-c-snr shdsl-n-dccont shdsl-c-dccont shdsl-c-actfail e1-fe-rai e1-ne-rai e1-fe-ais e1-ne-ais e1-lof e1-los e1-loopback ima-grp-fe-su ima-grp-fe-cfg ima-grp-ne-cfg ima-grp-fe-nl ima-grp-ne-nl ima-grp-fe-blk ima-lnk-lif ima-lnk-lods ima-lnk-misc ima-lnk-rfi ima-lnk-fault ima-lnk-txblk ima-lnk-rxblk bad-digitmap dhcp-unreach dhcp-no-srv dhcp-inv-srv norpniewithsoftdsp unknown-sub ground-key port-hightemp port-jbfltca reg-domainname reg-auth reg-timeout reg-srvfailresp inv-domainname inv-auth inv-timeout	

100 Alarm Delta Log Status Commands

name	Type	Description
	inv-srvfailresp subs-srvfailresp subs-domainname subs-auth subs-refreshfail subs-inittimeout emergency-call e1sip-reg-domainname e1sip-reg-auth e1sip-reg-timeout e1sip-reg-srvfailresp e1sip-inv-domainname e1sip-inv-auth e1sip-inv-timeout e1sip-inv-srvfailresp e1sip-emergency-call e1itf-ais-signal e1itf-los-signal e1itf-rai-signal e1sip-misconfig-mgc10 e1sip-nsmprf-missed e1t1itf-recv-ais e1t1itf-recv-los e1t1itf-recv-rai transport-mismatch dns-lookup-failure none-dns-srv no-dns-srv none-srv no-srv reg-srv-unreach proxy-srv-unreach dhcp-srv-unreach fo-trigger fb-trigger du-trigger ssp-missing dns-pool-exceed lsa-fo-trigger reg-domainname-sec reg-auth-sec reg-timeout-sec reg-srvfailresp-sec inv-domainname-sec inv-auth-sec inv-timeout-sec inv-srvfailresp-sec subs-srvfailresp-sec subs-domainname-sec subs-auth-sec subs-refreshfail-sec subs-inittimeout-sec emergency-call-sec fanout up-overflow upobc-overflow dwobc-overflow	

name	Type	Description
	dw-overflow lwpri-overflow queue-drop queue-load queue-peak-usage mgc-unreachable failover-to-esamgc sgc-unreachable lcard-unreach-srvcard lcard-type-mismatch meg-unknown-sub meg-ground-key meg-high-temp meg-act-fail meg-over-current line-showering low-qos-packetloss low-qos-jitter low-qos-delay sig-brd-persist-loss sig-brd-disk-full sig-brd-db-rollback mg-overload meg-unknown-sub-sec line-showering-sec loss-env-mon etca-los etca-fcs etca-day-los etca-day-fcs etca-rx-octets etca-tx-octets etca-day-rx-octets etca-day-tx-octets user-sfp-los user-sfp-tx-fail user-sfp-not-prst user-sfp-inv-id user-sfp-t-exceed user-sfp-mismatch uplink-sfp-los uplink-sfp-tx-fail uplink-sfp-not-prst uplink-sfp-inv-id uplink-sfp-t-exceed uplink-sfp-mismatch loss-lmswp-cap inv-xvps-pair-data network-power-loss hw-fault bat-miss bat-fail bat-low bat-a-fail bat-b-fail ac-vol-out-range network-power-loss-b	

100 Alarm Delta Log Status Commands

name	Type	Description
	sem-ac-power-fail	
	sem-ups-low-volt	
	dc-a-fail	
	dc-b-fail	
	plan-power-mismatch	
	water-seepage-in-box	
	sealed-box-open	
	dc-a-vol-out-range	
	dc-b-vol-out-range	
	inlet-temp-major	
	inlet-temp-critical	
	psu-fail-crit	
	psu-a-fail-presence	
	psu-a-fail-vin-ac-nok	
	psu-a-fail-vin-uv	
	psu-a-fail-vin-ov	
	psu-a-fail-vout-uv	
	psu-a-fail-vout-ov	
	psu-a-fail-iout-oc	
	psu-a-fail-overtemp	
	psu-b-fail-presence	
	psu-b-fail-vin-ac-nok	
	psu-b-fail-vin-uv	
	psu-b-fail-vin-ov	
	psu-b-fail-vout-uv	
	psu-b-fail-vout-ov	
	psu-b-fail-iout-oc	
	psu-b-fail-overtemp	
	synce-fail	
	bits-fail	
	bits-output-shutoff	
	ieee1588-fail	
	gnss-fail	
	ieee1588-hybrid-fail	
	signal-loss	
	signal-efd	
	esmc-loss	
	bits-output-exceed	
	ql-input-exceed	
	holdover	
	lti	
	tod-reference-fail	
	internal-clk-fail	
	bgp-peer-down	
	bgp-routes-mid-limit	
	isis-adjacency-down	
	isis-adjacency-reject	
	isis-instance-down	
	ospf-lsa-limit	
	ospf-lsa-mid-limit	
	ospf-neighbor-down	
	ospf-instance-down	
	ospf3-lsa-limit	
	ospf3-lsa-mid-limit	
	ospf3-neighbor-down	
	ospf3-instance-down	
	rip-instance-down	

name	Type	Description
	lag-down lagsubgrp-thresh-reach lagsubgrp-switch-fail no-unpinned-free-ports general-arp-limit gen-switch-out-of-res ipv6-nc-limit dhcp-session-oor ihub-fdb-limit ihub-mac-limit l2fw-stp-exception l2fw-stp-root-guard vprn-routes-limit vprn-ipv6-routes-limit dhcipv6-lease-limit dhcipv4-lease-limit vpls-mfib-limit ihub-ipv6-dad-own ihub-ipv6-dad ihub-ipv6-dup-pd-route vpls-duplicate-mac vpls-fdb-limit vpls-self-duplic-mac vpls-sdp-self-dup-mac link-down link-lagport-add-fail link-conf-mismatch ihub-peer-comm ihub-sw-fail ihub-hw-fail ihub-link-fail ihub-proc-overload ihub-out-of-mem ntp-comm-lost ldp-instance-down ldp-session-down mpls-instance-down mpls-lsp-down mpls-lsp-path-down sdp-instance-down sdp-binding-down epipe-instance-down lldpmed-portcfg-mis lldpmed-mediapl-mis vlanport-svc-mismatch mcsrc-stream-lost eqptsupl-syslog-upload eqptsupl-ontsw-dnload cf-75%used cf-90%used olt-gen-pon-com-fail olt-gen-tx-fail olt-gen-unprov-ont olt-gen-pon-eqpt-prov olt-gen-pon-loss-sig olt-gen-pon-diagnostic olt-gen-loid-conflict	

100 Alarm Delta Log Status Commands

name	Type	Description
	olt-gen-loid-pwderr	
	olt-gen-pon-alien-test	
	olt-gen-alien-detect	
	olt-gen-rng-mism	
	olt-gen-sfp-mism	
	olt-gen-deact-hightca	
	olt-gen-deact-lowtca	
	olt-gen-dp-integ	
	olt-gen-ddr-fault	
	olt-pon-tc-err-frag-tc	
	olt-ont-tc-err-frag-tc	
	ont-ploam-loss-sig	
	ont-ploam-loss-ack	
	ont-ploam-loss-cd	
	ont-ploam-phy-eqpt-err	
	ont-ploam-startup-fail	
	ont-ploam-sig-degrade	
	ont-ploam-disabled	
	ont-ploam-err-msg	
	ont-ploam-inactive	
	ont-ploam-sig-fail	
	ont-ploam-dying-gasp	
	ont-ploam-deact-fail	
	ont-ploam-oam	
	ont-ploam-win-drift	
	ont-ploam-rdi	
	ont-ploam-loss-ks	
	ont-ploam-pwr-burst	
	ont-ploam-roq-disa	
	ont-ploam-diff-reach	
	ont-ploam-looc	
	sfu-ploam-loss-sig	
	sfu-ploam-loss-ack	
	sfu-ploam-loss-cd	
	sfu-ploam-phy-eqpt-err	
	sfu-ploam-startup-fail	
	sfu-ploam-sig-degrade	
	sfu-ploam-disabled	
	sfu-ploam-err-msg	
	sfu-ploam-inactive	
	sfu-ploam-sig-fail	
	sfu-ploam-dying-gasp	
	sfu-ploam-deact-fail	
	sfu-ploam-oam	
	sfu-ploam-win-drift	
	sfu-ploam-rdi	
	sfu-ploam-loss-ks	
	sfu-ploam-pwr-burst	
	sfu-ploam-roq-disa	
	sfu-ploam-diff-reach	
	sfu-ploam-looc	
	soho-ploam-loss-sig	
	soho-ploam-loss-ack	
	soho-ploam-loss-cd	
	soho-ploam-phy-eqpt-er	
	soho-ploam-startup-fai	
	soho-ploam-sig-degrade	

name	Type	Description
	soho-ploam-disabled	
	soho-ploam-err-msg	
	soho-ploam-inactive	
	soho-ploam-sig-fail	
	soho-ploam-dying-gasp	
	soho-ploam-deact-fail	
	soho-ploam-oam	
	soho-ploam-win-drift	
	soho-ploam-rdi	
	soho-ploam-loss-ks	
	soho-ploam-pwr-burst	
	soho-ploam-rog-disa	
	soho-ploam-diff-reach	
	soho-ploam-looc	
	mdu-ploam-loss-sig	
	mdu-ploam-loss-ack	
	mdu-ploam-loss-cd	
	mdu-ploam-phy-eqpt-err	
	mdu-ploam-startup-fail	
	mdu-ploam-sig-degrade	
	mdu-ploam-disabled	
	mdu-ploam-err-msg	
	mdu-ploam-inactive	
	mdu-ploam-sig-fail	
	mdu-ploam-dying-gasp	
	mdu-ploam-deact-fail	
	mdu-ploam-oam	
	mdu-ploam-win-drift	
	mdu-ploam-rdi	
	mdu-ploam-loss-ks	
	mdu-ploam-pwr-burst	
	mdu-ploam-rog-disa	
	mdu-ploam-diff-reach	
	mdu-ploam-looc	
	ont-hpna-ser-mis	
	ont-hpna-los-sig	
	ont-moca-svc-mis	
	ont-moca-link-los	
	ont-moca-min-bw	
	ont-moca-tca-rx-err-fr	
	ont-sipa-reg-nm-fail	
	ont-sipa-reg-rec-fail	
	ont-sipa-reg-con-fail	
	ont-sipa-reg-val-fail	
	ont-sipa-reg-mis	
	ont-vcd-cfg-nm-fail	
	ont-vcd-cfg-rech-fail	
	ont-vcd-cfg-conn-fail	
	ont-vcd-cfg-vali-fail	
	ont-vcd-cfg-auth-fail	
	ont-vcd-cfg-resp-tmout	
	ont-vcd-cfg-resp-err	
	ont-vcd-cfg-file-err	
	ont-vcd-sub-nm-fail	
	ont-vcd-sub-rech-fail	
	ont-vcd-sub-conn-fail	
	ont-vcd-sub-vali-fail	

100 Alarm Delta Log Status Commands

name	Type	Description
	ont-vcd-sub-auth-fail	
	ont-vcd-sub-resp-tmout	
	ont-vcd-sub-resp-err	
	ont-vcd-reb-requ	
	ont-vcd-mis	
	ont-mgc-mis	
	ont-mgc-timeout	
	ont-sip-reg-dns	
	ont-sip-reg-fail	
	ont-sip-reg-timeout	
	ont-sip-reg-err-resps	
	ont-sip-inv-dns	
	ont-sip-inv-auth	
	ont-sip-inv-timeout	
	ont-sip-inv-err	
	ont-svc-pots-subs-refr	
	ont-svc-pots-not-refr	
	ont-svc-pots-icfg-err	
	ont-veip-mismatch	
	ont-ip-host-mismatch	
	ont-ip-host-file	
	ont-ip-host-ip-alloc	
	olt-pon-up-bw-tca	
	olt-pon-down-bw-tca	
	ont-gen-omci-fail	
	ont-gen-eqpt-selftest	
	ont-gen-ac-pwr-fail	
	ont-gen-bat-missing	
	ont-gen-bat-low	
	ont-gen-bat-fail	
	ont-gen-phys-intrusion	
	ont-gen-sw-dnload-f	
	ont-gen-sw-dnload-p	
	ont-gen-sw-act-fail	
	ont-gen-eqpt-vers-mis	
	ont-gen-sw-vers-mis	
	ont-gen-us-rate-mis	
	ont-gen-mdu-env1	
	ont-gen-mdu-env2	
	ont-gen-mdu-env3	
	ont-gen-nw-time-err	
	ont-gen-opt-sig-high	
	ont-gen-opt-sig-low	
	ont-gen-eqpt-prov-sa	
	ont-gen-eqpt-prov-nsa	
	pon-t-txmcutilhi	
	pon-t-txmcutilmd	
	pon-t-txmcutillo	
	pon-t-txtotutilhi	
	pon-t-txtotutilmd	
	pon-t-txtotutillo	
	pon-t-rxtotutilhi	
	pon-t-rxtotutilmd	
	pon-t-rxtotutillo	
	pon-t-dbacongperiodhi	
	pon-t-dbacongperiodmd	
	pon-t-dbacongperiodlo	

name	Type	Description
	pon-t-txucdropfrmhi	
	pon-t-txucdropfrmmd	
	pon-t-txucdropfrmlo	
	pon-t-txmcdropfrmhi	
	pon-t-txmcdropfrmmd	
	pon-t-txmcdropfrmlo	
	pon-t-txbcdropfrmhi	
	pon-t-txbcdropfrmmd	
	pon-t-txbcdropfrmlo	
	pon-t-rxtotdropfrmhi	
	pon-t-rxtotdropfrmmd	
	pon-t-rxtotdropfrmlo	
	chpr-t-txmcutilhi	
	chpr-t-txmcutilmd	
	chpr-t-txmcutillo	
	chpr-t-txtotutilhi	
	chpr-t-txtotutilmd	
	chpr-t-txtotutillo	
	chpr-t-rxtotutilhi	
	chpr-t-rxtotutilmd	
	chpr-t-rxtotutillo	
	chpr-t-dbacongperiodhi	
	chpr-t-dbacongperiodmd	
	chpr-t-dbacongperiodlo	
	chpr-t-txucdropfrmhi	
	chpr-t-txucdropfrmmd	
	chpr-t-txucdropfrmlo	
	chpr-t-txmcdropfrmhi	
	chpr-t-txmcdropfrmmd	
	chpr-t-txmcdropfrmlo	
	chpr-t-txbcdropfrmhi	
	chpr-t-txbcdropfrmmd	
	chpr-t-txbcdropfrmlo	
	chpr-t-rxtotdropfrmhi	
	chpr-t-rxtotdropfrmmd	
	chpr-t-rxtotdropfrmlo	
	sfu-gen-omci-fail	
	sfu-gen-eqpt-selftest	
	sfu-gen-ac-pwr-fail	
	sfu-gen-bat-missing	
	sfu-gen-bat-low	
	sfu-gen-bat-fail	
	sfu-gen-sw-dnload-f	
	sfu-gen-sw-dnload-p	
	sfu-gen-sw-act-fail	
	sfu-gen-eqpt-vers-mis	
	sfu-gen-sw-vers-mis	
	sfu-gen-us-rate-mis	
	sfu-gen-tune-fail	
	sfu-gen-nw-time-err	
	sfu-gen-opt-sig-high	
	sfu-gen-opt-sig-low	
	sfu-gen-eqpt-prov-sa	
	sfu-gen-eqpt-prov-nsa	
	soho-gen-omci-fail	
	soho-gen-eqpt-selftest	
	soho-gen-ac-pwr-fail	

100 Alarm Delta Log Status Commands

name	Type	Description
	soho-gen-bat-missing	
	soho-gen-bat-low	
	soho-gen-bat-fail	
	soho-gen-sw-dnload-f	
	soho-gen-sw-dnload-p	
	soho-gen-sw-act-fail	
	soho-gen-eqpt-vers-mis	
	soho-gen-sw-vers-mis	
	soho-gen-us-rate-mis	
	soho-gen-tune-fail	
	soho-gen-nw-time-err	
	soho-gen-opt-sig-high	
	soho-gen-opt-sig-low	
	soho-gen-eqpt-prov-sa	
	soho-gen-eqpt-prov-nsa	
	mdu-gen-omci-fail	
	mdu-gen-eqpt-selftest	
	mdu-gen-ac-pwr-fail	
	mdu-gen-bat-missing	
	mdu-gen-bat-low	
	mdu-gen-bat-fail	
	mdu-gen-phys-intrusion	
	mdu-gen-sw-dnload-f	
	mdu-gen-sw-dnload-p	
	mdu-gen-sw-act-fail	
	mdu-gen-eqpt-vers-mis	
	mdu-gen-sw-vers-mis	
	mdu-gen-us-rate-mis	
	mdu-gen-tune-fail	
	mdu-gen-mdu-env1	
	mdu-gen-mdu-env2	
	mdu-gen-mdu-env3	
	mdu-gen-nw-time-err	
	mdu-gen-opt-sig-high	
	mdu-gen-opt-sig-low	
	mdu-gen-eqpt-prov-sa	
	mdu-gen-eqpt-prov-nsa	
	ont-gen-sw-dnload-file	
	ont-gen-fan-fail	
	ont-gen-high-temp	
	ont-gen-high-temp-ex	
	ont-gen-emergency-call	
	ont-gen-sw-version	
	ont-poe-exceed-max	
	ont-poe-overload-yell	
	ont-opti-malfunc	
	ont-gen-cfgdld-fail	
	ont-gen-rssi-mis	
	ont-gen-tx-pwr-low	
	ont-gen-temp-high	
	ont-gen-volt-high	
	ont-gen-bias-high	
	ont-loopdetect-mis	
	ont-olt-rx-pw-lo	
	ont-olt-rx-pw-hig	
	ont-olt-rx-pw-warnlo	
	ont-olt-rx-pw-warnhig	

name	Type	Description
	ont-gen-tod-out-sync	
	ont-gen-tune-fail	
	hgu-tr069-parm-fail	
	ont-gen-tod-mismatch	
	sfu-sup-sw-file-error	
	sfu-sup-fan-failure	
	sfu-sup-temp-high-warn	
	sfu-sup-temp-shutoff	
	sfu-sup-emergency-call	
	sfu-sup-swverctrl-err	
	sfu-sup-poe-exceed-max	
	sfu-sup-poe-over-yell	
	sfu-opti-malfunc	
	sfu-sup-cfg-dnld-fail	
	sfu-sup-rssi-cfg-mism	
	sfu-sup-sfp-tx-low	
	sfu-sup-sfp-temp-high	
	sfu-sup-sfp-volt-high	
	sfu-sup-sfp-bias-high	
	sfu-sup-ld-cfg-mism	
	sfu-sup-olt-rx-low	
	sfu-sup-olt-rx-high	
	sfu-sup-olt-rx-lo-warn	
	sfu-sup-olt-rx-hi-warn	
	sfu-sup-tod-out-sync	
	sfu-sup-ont-tune-fail	
	sfu-tr069-parm-fail	
	sfu-sup-tod-mismatch	
	soho-sup-sw-file-error	
	soho-sup-fan-failure	
	soho-sup-temp-high-war	
	soho-sup-temp-shutoff	
	soho-sup-emergency-cal	
	soho-sup-swverctrl-err	
	soho-sup-poe-exceed-ma	
	soho-sup-poe-over-yell	
	soho-opti-malfunc	
	soho-sup-cfg-dnld-fail	
	soho-sup-rssi-cfg-mism	
	soho-sup-sfp-tx-low	
	soho-sup-sfp-temp-high	
	soho-sup-sfp-volt-high	
	soho-sup-sfp-bias-high	
	soho-sup-ld-cfg-mism	
	soho-sup-olt-rx-low	
	soho-sup-olt-rx-high	
	soho-sup-olt-rx-lo-war	
	soho-sup-olt-rx-hi-war	
	soho-sup-tod-out-sync	
	soho-sup-ont-tune-fail	
	soho-tr069-parm-fail	
	soho-sup-tod-mismatch	
	mdu-sup-sw-file-error	
	mdu-sup-fan-failure	
	mdu-sup-temp-high-warn	
	mdu-sup-temp-shutoff	
	mdu-sup-emergency-call	

100 Alarm Delta Log Status Commands

name	Type	Description
	mdu-sup-swverctrl-err	
	mdu-sup-poe-exceed-max	
	mdu-sup-poe-over-yell	
	mdu-opti-malfunc	
	mdu-sup-cfg-dnld-fail	
	mdu-sup-rssi-cfg-mism	
	mdu-sup-sfp-tx-low	
	mdu-sup-sfp-temp-high	
	mdu-sup-sfp-volt-high	
	mdu-sup-sfp-bias-high	
	mdu-sup-ld-cfg-mism	
	mdu-sup-olt-rx-low	
	mdu-sup-olt-rx-high	
	mdu-sup-olt-rx-lo-warn	
	mdu-sup-olt-rx-hi-warn	
	mdu-sup-tod-out-sync	
	mdu-sup-ont-tune-fail	
	mdu-tr069-parm-fail	
	mdu-sup-tod-mismatch	
	ont-sbscr-lim-missing	
	ont-sbscr-lim-type-mis	
	ont-sbscr-lim-removal	
	ont-sbscr-lim-fail	
	ont-sbscr-lim-svc-mis	
	ont-sbscr-lim-port-mis	
	ont-svc-video-conf-mis	
	ont-svc-video-pw-high	
	ont-svc-video-pw-low	
	ont-svc-pots-svc-mis	
	ont-svc-pots-rtcp-lost	
	ont-svc-pots-icnf-subs	
	ont-svc-pots-icnf-ntfy	
	ont-svc-pots-icnf-http	
	ont-svc-pots-sip-reg	
	ont-svc-pots-sip-inv	
	ont-svc-pots-sip-subsc	
	ont-svc-pots-sip-mt-tc	
	ont-svc-pots-pk-los-tc	
	ont-svc-pots-jitter-tc	
	ont-svc-pots-subs-dns	
	ont-svc-pots-subs-tcp	
	ont-svc-pots-subs-tls	
	ont-svc-pots-subs-auth	
	ont-svc-pots-subs-to	
	ont-svc-pots-subs-err	
	ont-svc-pots-not-to	
	ont-svc-pots-notref-to	
	ont-svc-pots-not-mal	
	ont-svc-pots-not-rej	
	ont-svc-pots-http-dns	
	ont-svc-pots-http-tcp	
	ont-svc-pots-http-tls	
	ont-svc-pots-http-auth	
	ont-svc-pots-http-to	
	ont-svc-pots-http-err	
	ont-svc-pots-http-mal	
	ont-svc-pots-insuff	

name	Type	Description
	ont-svc-pots-poos ont-svc-lan-mismatch ont-svc-lan-loss-sig ont-svc-enet-poos ont-svc-ces-ds1-mis ont-svc-ces-ds1-los ont-svc-ces-ds1-lof ont-svc-ces-ds1-rair ont-svc-ces-ds1-ais ont-svc-ces-ds1-lnlpbk ont-svc-ces-ds1-tmlpbk ont-svc-ces-e1-mis ont-svc-ces-e1-los ont-svc-ces-e1-lof ont-svc-ces-e1-rair ont-svc-ces-e1-ais ont-svc-voip-cnf-file ont-svc-voip-svc-mis ont-svc-voip-gw-comm ont-svc-voip-dhcp-fail ont-svc-voip-icnf-sub ont-svc-voip-icnf-ntfy ont-svc-voip-icnf-http ont-svc-voip-dhcp-to ont-svc-voip-dhcp-mal ont-svc-voip-dhcp-noad ont-svc-voip-dhcp-leas ont-svc-voip-sub-dns ont-svc-voip-sub-tcp ont-svc-voip-sub-tls ont-svc-voip-sub-auth ont-svc-voip-sub-to ont-svc-voip-sub-err ont-svc-voip-not-to ont-svc-voip-notref-to ont-svc-voip-not-mal ont-svc-voip-not-rej ont-svc-voip-http-dns ont-svc-voip-http-tcp ont-svc-voip-http-tls ont-svc-voip-http-auth ont-svc-voip-http-to ont-svc-voip-http-err ont-svc-voip-http-mal ont-svc-voip-sub-refr ont-svc-voip-not-refr ont-svc-voip-icfg-err ont-svc-v-ani-conf-mis ont-svc-v-ani-loss-sig ont-svc-v-ani-lv-high ont-svc-v-ani-lv-low ont-svc-pwe-mismatch ont-svc-pwe-reordr-lof ont-svc-pwe-jitt-buf-o ont-svc-pwe-jitt-buf-u ont-svc-pwe-malf-frms ont-svc-pwe-late-frms	

100 Alarm Delta Log Status Commands

name	Type	Description
	ont-svc-pwe-link-loss ont-svc-pwe-arp-fail ont-svc-xdsl-mismatch ont-svc-xdsl-ne-lof ont-svc-xdsl-ne-los ont-svc-xdsl-ne-line ont-svc-xdsl-ne-lol ont-svc-xdsl-fe-lof ont-svc-xdsl-fe-los ont-svc-xdsl-fe-lop ont-svc-xdsl-cnfr-err ont-svc-xdsl-ne-es-tc ont-svc-xdsl-ne-ses-tc ont-svc-xdsl-ne-uas-tc ont-svc-xdsl-fe-es-tc ont-svc-xdsl-fe-ses-tc ont-svc-xdsl-fe-uas-tc ont-tc-rx-los-frag-tc ont-tc-tx-los-frag-tc ont-tc-bad-gem-hd-tc ont-uni-ds-drrpd-fr-tc ont-uni-up-drrpd-fr-tc ont-uni-ds-crc-fr-tc ont-uni-up-crc-fr-tc ont-cpu-util-tca ont-mem-util-tca pim-neighbor-down pim-max-mcroutes li-traffic-disabled li-bandwidth-limit li-out-of-res otdr-cap-mismatch login-successful login-failure cfm-defrdiccm cfm-defmacstatus cfm-defremoteccm cfm-deferrorccm cfm-defxconccm cfm-defais bfd-session-down bfd-max-resource bfd-stale-entry tca-outputbw tca-inputbw tca-rxcrcalign tca-txcrcalign tca-txcollisions tca-outputhighbw tca-outputmedbw tca-outputlowbw tca-inputhighbw tca-inputmediumbw tca-inputlowbw eth-cfm-defrdiccm eth-cfm-defmacstatus eth-cfm-defremoteccm	

name	Type	Description
	eth-cfm-deferrorccm	
	eth-cfm-defxconccm	
	rsvp-neighbor-down	
	rsvp-instance-down	
	eth-ring-path-block	
	ai-platform-down	
	ai-appl-install-fail	
	ip-assign-fail	
	ont-tr069-serv-mis	
	ont-snmp-mis	
	bsf-dhcpv4	
	bsf-dhcpv6	
	bsf-pon	
	bsf-vbridge	
	bsf-qos	
	bsf-igmp	
	bsf-lxfwd	
	prot-not-available	
	prot-switchover-fail	
	efm-oam-cpelinkfault	
	efm-oam-cpedyinggasp	
	efm-oam-cpecrevt	
	ont-loopdetect	
	alarm-tbl-overflow	
	auto-switch-status	
	auswqueuefullatm	
	auswbkpfailatm	
	auswrecfgfailatm	
	auswdataunatm	
	auswqueuefulptm	
	auswbkpfailptm	
	auswrecfgfailptm	
	auswdataunptm	
	auswbakpfailatm	
	chpr-com-fail	
	chpr-tx-fail	
	chpr-unprov-ont	
	chpr-prov-mismatch	
	chpr-loss-sig	
	chpr-diagnostic	
	chpr-loid-conflict	
	chpr-loid-pwd-err	
	chpr-stk-laser-dis	
	chpr-sfp-mismatch	
	chpr-rng-mismatch	
	chpr-alien-test	
	chpr-alien-detect	
	chpr-deact-hightca	
	chpr-deact-lowtca	
	chpr-dp-integ	
	olt-chpr-tc-err-frag	
	olt-chpr-up-bw-tca	
	olt-chpr-down-bw-tca	
	cfg-dld-fail	
	cfg-act-fail	
	cfg-dld-ip	
	cfg-ver-mismatch	

100 Alarm Delta Log Status Commands

name	Type	Description
	cfg-file-missing cfg-verctrl-err cfg-not-supported ont-prot-not-available ont-gen-temp-low ont-gen-volt-low ont-gen-tx-pwr-high ont-gen-bias-low ont-gen-rx-hwarn ont-gen-rx-lwarn ont-gen-tx-hwarn ont-gen-tx-lwarn ont-gen-temp-hwarn ont-gen-temp-lwarn ont-gen-volt-hwarn ont-gen-volt-lwarn ont-gen-bias-hwarn ont-gen-bias-lwarn sfu-sup2-temp-low sfu-sup2-volt-low sfu-sup2-tx-high sfu-sup2-bias-low sfu-sup2-rx-hwarn sfu-sup2-rx-lwarn sfu-sup2-tx-hwarn sfu-sup2-tx-lwarn sfu-sup2-temp-hwarn sfu-sup2-temp-lwarn sfu-sup2-volt-hwarn sfu-sup2-volt-lwarn sfu-sup2-bias-hwarn sfu-sup2-bias-lwarn soho-sup2-temp-low soho-sup2-volt-low soho-sup2-tx-high soho-sup2-bias-low soho-sup2-rx-hwarn soho-sup2-rx-lwarn soho-sup2-tx-hwarn soho-sup2-tx-lwarn soho-sup2-temp-hwarn soho-sup2-temp-lwarn soho-sup2-volt-hwarn soho-sup2-volt-lwarn soho-sup2-bias-hwarn soho-sup2-bias-lwarn mdu-sup2-temp-low mdu-sup2-volt-low mdu-sup2-tx-high mdu-sup2-bias-low mdu-sup2-rx-hwarn mdu-sup2-rx-lwarn mdu-sup2-tx-hwarn mdu-sup2-tx-lwarn mdu-sup2-temp-hwarn mdu-sup2-temp-lwarn mdu-sup2-volt-hwarn	

name	Type	Description
	mdu-sup2-volt-lwarn mdu-sup2-bias-hwarn mdu-sup2-bias-lwarn cust-alm1 cust-alm2 cust-alm3 cust-alm4 cust-alm5 cust-alm6 cust-alm7 cust-alm8 cust-alm9 cust-alm10 cust-alm11 cust-alm12 cust-alm13 cust-alm14 cust-alm15 cust-alm16 cust-alm17 cust-alm18 cust-alm19 cust-alm20 cust-alm21 cust-alm22 cust-alm23 cust-alm24 cust-alm25 cust-alm26 cust-alm27 cust-alm28 cust-alm29 cust-alm30 cust-alm31 ethernet-ring-ptfwst ethernet-ring-fop-to ethernet-ring-fop-pm fpm-depletion exp-seizureack exp-disconack exp-forcerelack packet-loss remote-packet-loss no-dsp-resource la-down la-standby-na la-switch-fail la-degrade melt-board-reset board-shelf-mismatch fcs-thresh-exceed) Possible values: - all : all alarms for query - xtca-ne-es : errored seconds in 15 min - xtca-ne-ses : severely errored seconds in 15 min - xtca-ne-uas : unavailable seconds in 15 min - xtca-ne-day-es : errored seconds in 1 day	

100 Alarm Delta Log Status Commands

name	Type	Description
	- xtca-ne-day-ses : severely errored seconds in 1 day - xtca-ne-day-uas : unavailable seconds in 1 day - xtca-fe-es : errored seconds in 15 min - xtca-fe-ses : severely errored secs in 15 min - xtca-fe-uas : unavailable seconds in 15 min - xtca-fe-day-es : errored seconds in 1 day - xtca-fe-day-ses : severely errored secs in 1 day - xtca-fe-day-uas : unavailable seconds in 1 day - xtca-leftrs : low error free throughput seconds in 15 min - xtca-day-leftrs : low error free throughput seconds in 1 day - xtca-fe-leftrs : far end low error free throughput seconds in 15 min - xtca-fe-day-leftrs : far end low error free throughput seconds in 1 day - xtca-auto-port-reset : auto-port-resets in 1 week - xtca-reinit : Reinitialization seconds in 15 min - xtca-day-reinit : Reinitialization seconds in 1 day - xdsl-ne-los : loss of signal - xdsl-ne-lof : loss of frame - xdsl-ne-lom : loss of margin - xdsl-ne-ese : excessive severe errors - xdsl-act-cfg-error : line configuration data cannot be used - xdsl-act-not-feas : line capacity not enough to setup requested profile - xdsl-up-br-reach : planned bitrate not reached after initialization - xdsl-ne-ncd : no cell delineation - xdsl-ne-lcd : loss of cell delineation - xdsl-fe-los : loss of signal - xdsl-fe-lof : loss of frame - xdsl-fe-lpr : loss of power - xdsl-fe-lol : loss of link - xdsl-fe-lom : loss of margin - xdsl-fe-ese : excessive severe errors - xdsl-fe-upbo-vio : upbo violation - xdsl-fe-cpe-pol : activation failure cpe policing - xdsl-tpstc-mis : mismatch between the configured tps-tc mode and the mode supported by the connected cpe - xdsl-act-comm : init not successful due to communications problem - xdsl-act-modem : no peer modem detected - xdsl-do-br-reach : planned bitrate not reached after init - xdsl-fe-ncd : no cell delineation - xdsl-fe-lcd : loss of cell delineation - xdsl-frtx-init-fail : init not successful due to forced rtx - xdsl-vect-dle : vectoring disorderly leaving event - xdsl-fe-mis-peer-35b : VDSL2 35b opmode mismatch between XTU-C and XTU-R - vectline-xtc-var-vict : excessive victim crosstalk coefficients variation - vectline-xtc-var-dist : excessive disturber crosstalk coefficients variation - vectline-corp-errf : corrupted or missing errorf-samples - vect-cpe-cap-mismatch : not allowed Vectoring CPE connected - vectline-conf_notfeas : vect line configuration not feasible - vect-vp-lt-mismatch : actual vp-lt connection(s) do not	

name	Type	Description
	match expected vp-lt connection(s) or vp-lt connection lost - vect-inv-qsf : qsf has no valid Nokia ID - vect-vp-lt-fail : vp-lt connection not operational - vect-no-gain-at-init : Lines cannot train in gain-at-init mode - sw-rollback : non active oswp,db cannot be operational - will rollback - db-rollback : selected oswp,db cannot be operational - will rollback - xvps-inv-dbase : invalid xvps dbase - inv-cde-file : invalid xvps cde file - miss-cde-file : missing cde profile - cde-hash-error : cde profile hash error - auto-fetch-failure : not able to fetch file from specified server - low-disk-space : insufficient space for Sw storage - cell-discard-up : cell discarded in the upstream direction - cell-discard-down : cell discarded in the downstream direction - persist-data-loss : all data lost after restart - system not configured - mac-conflict : duplicate mac address on the bridge port - vmac-full : virtual mac address is full on the bridge port - sntp-comm-lost : sntp server not responding - preferred-mode : preferred mode not available - timing-reference : timing reference failure - nt-disk-95%full : nt disk 95% full - shub-loc : communication lost with shub - cf-error : compact flash access error - back-pnl-inv : BackPanel-type Invalid - ihub-conf-loss : iHub configuration loss - recent changes lost - rack-power : power fuse broken - rack-fan-unit1 : fan unit rack 1 failing - rack-fan-unit2 : fan unit rack 2 failing - shelf-mismatch : shelf type different from planned type - shelf-missing : detected shelf no longer detected - shelf-install-missing : shelf planned but not installed - door : open cabinet door - ac-power-fail : external power failure - shelf shutdown in 15 minutes - board-mismatch : board inserted different from planned - waiting-for-sw : not able to download all the applicable sw files - temp-exceeded : temperature threshold exceeded on the board - backplane-data-failure : lt port on backplane data failure - temp-shutdown : board powered down itself - too high temperature - board-missing : board detected after planning - now missing - board-instl-missing : board never detected after planning - board-init : board initialisation failure - board-reset-prot : number of resets exceeded - sem-power-fail : SEM external power failure - sem-ups-fail : SEM external power supply failure - board-reset-cf : board reset and/or communication failure	

100 Alarm Delta Log Status Commands

name	Type	Description
	- vlan-assign-fail : failure to assign VLAN for a user session - vsa-info-invalid : radius fail to assign a valid vsa to a user session - auth-mac-conflict : failure to check mac conflict for a user session - user-pwd-fault : failure to check user or password of a user session - up-plan-bitrate : upstream bitrate is above min and below planned - up-min-bitrate : upstream bitrate is below min bitrate - up-config-not-feas : upstream bitrate is not enough to set up config group - down-plan-bitrate : downstream bitrate is above min and below planned - down-min-bitrate : downstream bitrate is below min bitrate - down-config-not-feas : downstream bitrate is not enough to set up config group - non-bonding-cpe : no bonding cpe modem is connected - multiple-cpes : bonding group has multiple cpe modems connected - register : bonding group discovery or aggregation register failure - group-incomplete : bonding group is incomplete - host-sfp-los : loss of signal - host-sfp-tx-fail : Tx failure - host-sfp-not-prst : not present - host-sfp-inv-id : no valid Nokia ID - host-sfp-ctrl-fail : control failure - host-sfp-rmtlt : unexpected remote plug-in - host-sfp-mismatch : assignment does not match reported rack/shelf/slot - host-sfp-incompt : incompatible shelf type detected - exp-sfp-los : expansion side loss of signal - exp-sfp-tx-fail : Tx failure - exp-sfp-not-prst : not present - exp-sfp-inv-id : no valid Nokia ID - exp-sfp-ctrl-fail : control failure - exp-sfp-1-los : expansion side sfp1 loss of signal - exp-sfp-2-los : expansion side sfp2 loss of signal - ext-qsfp-invld : Invalid Nokia ID - tx-power-high-alarm : tx power more than alarm range - tx-power-low-alarm : tx power less than alarm range - rx-power-high-alarm : rx power more than alarm range - rx-power-low-alarm : rx power less than alarm range - tx-biascur-high-alarm : tx bias current high alarm - tx-biascur-low-alarm : tx bias current low alarm - volt-high-alarm : voltage high alarm - volt-low-alarm : voltage low alarm - temp-high-alarm : temperature high alarm - temp-low-alarm : temperature low alarm - tx-power-high-warn : tx power more than warn range - tx-power-low-warn : tx power less than warn range - rx-power-high-warn : rx power more than warn range - rx-power-low-warn : rx power less than warn range - tx-biascur-high-warn : tx bias current high warn - tx-biascur-low-warn : tx bias current low warn - volt-high-warn : voltage high warn	

name	Type	Description
	- volt-low-warn : voltage low warn - temp-high-warn : temperature high warn - temp-low-warn : temperature low warn - onu-unprovisioned : unprovisioned ont - signal-loss : pon loss of signal - bitrate-high : the error bit rate high at pon interface - opmodule-mismatch : the optical module mismatched at pon interface - key-fail-one-churn : key exchange failure during one churning time - key-fail-three-churn : key exchange failure during three churning time - oam-discov-fail : extend oam discovery failure - report-timeout : report timeout detecting - total-packets-exceed : total amount of protocol packets exceed threshold - arp-packets-exceed : protocol arp packets exceed threshold - dhcp-packets-exceed : protocol dhcp packets exceed threshold - igmp-packets-exceed : protocol igmp packets exceed threshold - pppoe-packets-exceed : protocol pppoe packets exceed threshold - nd-packets-exceed : protocol nd packets exceed threshold - icmpv6-packets-exceed : protocol icmpv6 packets exceed threshold - mld-packets-exceed : protocol mld packets exceed threshold - dhcpv6-packets-exceed : protocol dhcpv6 packets exceed threshold - cfm-packets-exceed : protocol cfm packets exceed threshold - dsx1-serdes-fail : SERDES clock alarm failure - dsx1-tributary1-fail : The tributary 1 clock is not present - dsx1-tributary2-fail : The tributary 2 clock is not present - dsx1-los-fail : All the selected tribs in Loss of Signal - dsx1-ais-sync : Alarm Indication signal on the tributary selected as sync source - dsx1-lof-sync : Loss of Framing on the tributary selected as sync source - dsx1-los-sync : Loss of signal on the tributary selected as sync source - dsx1-deg-fail : Signal degrade Alarm - dsx1-rei-from-liu : Remote Error Indication alarm from LIU - dsx1-rdi-from-liu : Remote Defect Alarm from LIU - dsx1-crc6-from-liu : Cyclic Redundancy check-6 alarm from LIU - dsx1-crc4-from-liu : Cyclic Redundancy check-4 alarm from LIU - dsx1-crc4-th-from-liu : Cyclic Redundancy check-4 threshold alarm from LIU - dsx1-ais-from-liu : Alarm Indication Signal alarm from LIU - dsx1-los-from-liu : Loss of signal alarm from LIU - dsx1-lof-from-liu : Loss of framing alarm from LIU - dsx1-lomf-from-liu : Loss of Multi-frame alarm from LIU	

100 Alarm Delta Log Status Commands

name	Type	Description
	- dsx1-rei-from-iwf : Remote Error Indication alarm from IWF - dsx1-rdi-from-iwf : Remote Defect Alarm from IWF - dsx1-crc6-from-iwf : Cyclic Redundancy check-6 alarm from IWF - dsx1-crc4-from-iwf : Cyclic Redundancy check-4 alarm from IWF - dsx1-crc4-th-from-iwf : Cyclic Redundancy check-4 threshold alarm from IWF - dsx1-ais-from-iwf : Alarm Indication Signal alarm from IWF - dsx1-los-from-iwf : Loss of signal alarm from IWF - dsx1-lof-from-iwf : Loss of framing alarm from IWF - dsx1-lomf-from-iwf : Loss of Multi-frame alarm from IWF - pppce-trans-15min-tca : 15 minutes transaction timeout count exceeds configured TCA - pppce-sess-15min-tca : 15 minutes session timeout count exceeds configured TCA - pppce-trans-1day-tca : 1day transaction timeout count exceeds configured TCA - pppce-sess-1day-tca : 1day session timeout count exceeds configured TCA - custom1 : customizable alarm 1 - custom2 : customizable alarm 2 - custom3 : customizable alarm 3 - custom4 : customizable alarm 4 - custom5 : customizable alarm 5 - he-custom1 : host expansion customizable alarm 1 - he-custom2 : host expansion customizable alarm 2 - he-custom3 : host expansion customizable alarm 3 - he-custom4 : host expansion customizable alarm 4 - he-custom5 : host expansion customizable alarm 5 - he-custom6 : host expansion customizable alarm 6 - custom6 : customizable alarm 6 - custom7 : customizable alarm 7 - custom8 : customizable alarm 8 - custom9 : customizable alarm 9 - custom10 : customizable alarm 10 - custom11 : customizable alarm 11 - custom12 : customizable alarm 12 - custom13 : customizable alarm 13 - custom14 : customizable alarm 14 - custom15 : customizable alarm 15 - custom16 : customizable alarm 16 - custom17 : customizable alarm 17 - loss-swo-cap : switch over capability in a redundant system - ping-check-fail : ping check in a redundant system - der-temp1 : Derived Alarm for Temporal Filter 1 - der-temp2 : Derived Alarm for Temporal Filter 2 - der-temp3 : Derived Alarm for Temporal Filter 3 - der-temp4 : Derived Alarm for Temporal Filter 4 - der-temp5 : Derived Alarm for Temporal Filter 5 - der-temp6 : Derived Alarm for Temporal Filter 6 - der-temp7 : Derived Alarm for Temporal Filter 7 - der-temp8 : Derived Alarm for Temporal Filter 8 - der-temp9 : Derived Alarm for Temporal Filter 9 - der-temp10 : Derived Alarm for Temporal Filter 10	

name	Type	Description
	- der-temp11 : Derived Alarm for Temporal Filter 11 - der-temp12 : Derived Alarm for Temporal Filter 12 - der-temp13 : Derived Alarm for Temporal Filter 13 - der-temp14 : Derived Alarm for Temporal Filter 14 - der-temp15 : Derived Alarm for Temporal Filter 15 - der-temp16 : Derived Alarm for Temporal Filter 16 - der-temp17 : Derived Alarm for Temporal Filter 17 - der-temp18 : Derived Alarm for Temporal Filter 18 - der-temp19 : Derived Alarm for Temporal Filter 19 - der-temp20 : Derived Alarm for Temporal Filter 20 - der-temp21 : Derived Alarm for Temporal Filter 21 - der-temp22 : Derived Alarm for Temporal Filter 22 - der-temp23 : Derived Alarm for Temporal Filter 23 - der-temp24 : Derived Alarm for Temporal Filter 24 - der-temp25 : Derived Alarm for Temporal Filter 25 - der-temp26 : Derived Alarm for Temporal Filter 26 - der-temp27 : Derived Alarm for Temporal Filter 27 - der-temp28 : Derived Alarm for Temporal Filter 28 - der-temp29 : Derived Alarm for Temporal Filter 29 - der-temp30 : Derived Alarm for Temporal Filter 30 - der-temp31 : Derived Alarm for Temporal Filter 31 - der-spa1 : Derived Alarm for Spatial Filter 1 - der-spa2 : Derived Alarm for Spatial Filter 2 - der-spa3 : Derived Alarm for Spatial Filter 3 - der-spa4 : Derived Alarm for Spatial Filter 4 - der-spa5 : Derived Alarm for Spatial Filter 5 - der-spa6 : Derived Alarm for Spatial Filter 6 - der-spa7 : Derived Alarm for Spatial Filter 7 - der-spa8 : Derived Alarm for Spatial Filter 8 - der-spa9 : Derived Alarm for Spatial Filter 9 - der-spa10 : Derived Alarm for Spatial Filter 10 - der-spa11 : Derived Alarm for Spatial Filter 11 - der-spa12 : Derived Alarm for Spatial Filter 12 - der-spa13 : Derived Alarm for Spatial Filter 13 - der-spa14 : Derived Alarm for Spatial Filter 14 - der-spa15 : Derived Alarm for Spatial Filter 15 - der-spa16 : Derived Alarm for Spatial Filter 16 - der-spa17 : Derived Alarm for Spatial Filter 17 - der-spa18 : Derived Alarm for Spatial Filter 18 - der-spa19 : Derived Alarm for Spatial Filter 19 - der-spa20 : Derived Alarm for Spatial Filter 20 - der-spa21 : Derived Alarm for Spatial Filter 21 - der-spa22 : Derived Alarm for Spatial Filter 22 - der-spa23 : Derived Alarm for Spatial Filter 23 - der-spa24 : Derived Alarm for Spatial Filter 24 - der-spa25 : Derived Alarm for Spatial Filter 25 - der-spa26 : Derived Alarm for Spatial Filter 26 - der-spa27 : Derived Alarm for Spatial Filter 27 - der-spa28 : Derived Alarm for Spatial Filter 28 - der-spa29 : Derived Alarm for Spatial Filter 29 - der-spa30 : Derived Alarm for Spatial Filter 30 - der-spa31 : Derived Alarm for Spatial Filter 31 - apsf-alarm : Applique Power Supply Failure - custextalarm1 : Customizable External Alarm Number 1 - custextalarm2 : Customizable External Alarm Number 2 - custextalarm3 : Customizable External Alarm Number 3 - custextalarm4 : Customizable External Alarm Number 4	

100 Alarm Delta Log Status Commands

name	Type	Description
	- custextalarm5 : Customizable External Alarm Number 5 - pluginfan : REM Fan Alarm - plugin-dc-a : REM DC A Alarm - plugin-dc-b : REM DC B Alarm - plugin-dg : Dying Gasp Alarm - ntr-a-loss : NTR-A signal is not available - ntr-b-loss : NTR-B signal is not available - xvps-conf-loss : xvps configuration loss - mac-entry-nofree : no free mac entry in the mac table on It board - fibre-conn-mismatch : REM Fibre Connection Mismatch Alarm - link-cap-mismatch : Link speed capability mismatch - eqpt-cap-mismatch : Link equipment capability mismatch - ctrl-dnld-failure : Controller card download failure - melt-hw-issue : MELT hardware issue - melt-board-reset : MELT board reset - board-shelf-mismatch : board type and shelf type mismatch - mgnt-type-mismatch : Board management type mismatch - fileserv-unavail : file transfer Server unavailable or file transfer failed - shdsl-n-loopback : loopback active at the network side - shdsl-c-loopback : loopback active at the customer side - shdsl-conferr : configuration error - shdsl-atm-lcd : loss of atm cell delineation - shdsl-lpr : loss of power at stu-r - shdsl-secu-err : unable to disable stu-r access - shdsl-dev-fault : device fault - shdsl-atm-ncd : no atm cell delineation - shdsl-n-losw : loss of sync word at the network side on each pair - shdsl-c-losw : loss of sync word at the customer side on each pair - shdsl-n-aten : loop attenuation alarm at the network side on each pair - shdsl-c-aten : loop attenuation alarm at the customer side on each pair - shdsl-n-snr : snr margin alarm at the network side each pair - shdsl-c-snr : snr margin alarm at the customer side on each pair - shdsl-n-dccont : dc continuity fault at the network side on each pair - shdsl-c-dccont : dc continuity fault at the customer side on each pair - shdsl-c-actfail : activation failure at the customer side on each pair - e1-fe-rai : Receiving Remote Alarm Indication - e1-ne-rai : Transmitting Remote Alarm Indication - e1-fe-ais : Receiving Alarm Indication Signal - e1-ne-ais : Transmitting Alarm Indication Signal - e1-lof : E1 Loss of frame - e1-los : E1 Loss of Signal - e1-loopback : E1 facility in loopback - ima-grp-fe-su : far-end starting up - ima-grp-fe-cfg : far-end failed configuration - ima-grp-ne-cfg : near-end failed configuration - ima-grp-fe-nl : insufficient number of links at far-end	

name	Type	Description
	- ima-grp-ne-nl : insufficient number of links at near-end - ima-grp-fe-blk : far-end is blocked - ima-lnk-lif : loss of ima frame - ima-lnk-lods : link out of delay synchronization - ima-lnk-misc : link misconnect - ima-lnk-rfi : link remote failure indication - ima-lnk-fault : fault in link facility - ima-lnk-txblk : transmit blocked due to far-end - ima-lnk-rxblk : receive blocked due to far-end - bad-digitmap : Configured digitmap is unusable - dhcp-unreach : The DHCP server is unreachable - dhcp-no-srv : The address in DHCP reply is NULL - dhcp-inv-srv : The address in DHCP reply is invalid - norpniewithsoftdsp : do not plan / plug-in RPNI-E board with SoftDsp SW image - unknown-sub : subscriber exist in the POLT, but not in the appl server - ground-key : Return current to the ground - port-hightemp : Temperature threshold on user port exceeded. - port-jbfltca : JB fill level threshold on user port exceeded. - reg-domainname : Registration failure (resolving domain name). - reg-auth : Registration failure (authentication). - reg-timeout : Registration failure (message timeout). - reg-srvfailresp : Registration failure (failure response from server). - inv-domainname : Invitation failure (resolving domain name). - inv-auth : Invitation failure (authentication). - inv-timeout : Invitation failure (message timeout). - inv-srvfailresp : Invitation failure (failure response from server). - subs-srvfailresp : Subscribe failure (failure response from server). - subs-domainname : Subscribe failure (resolving domain name). - subs-auth : Subscribe failure (authentication). - subs-refreshfail : Subscribe failure (refresh failure). - subs-inittimeout : Subscribe failure (initial REQ timeout). - emergency-call : Emergency call for SIP POTS is ongoing. - e1sip-reg-domainname : E1 sip termination registration failure (resolving domain name). - e1sip-reg-auth : E1 sip termination registration failure (authentication). - e1sip-reg-timeout : E1 sip termination registration failure (message timeout). - e1sip-reg-srvfailresp : E1 sip termination registration failure (failure response from server). - e1sip-inv-domainname : E1 sip termination invitation failure (resolving domain name). - e1sip-inv-auth : E1 sip termination invitation failure (authentication). - e1sip-inv-timeout : E1 sip termination invitation failure (message timeout). - e1sip-inv-srvfailresp : E1 sip invitation failure (failure response from server).	

100 Alarm Delta Log Status Commands

name	Type	Description
	- e1sip-emergency-call : Emergency call for ISDN PRA/CAS R2 is ongoing. - e1itf-ais-signal : Alarm Indication Signal detected at E1 interface. - e1itf-los-signal : Loss Of Signal detected at E1 interface. - e1itf-rai-signal : Remote Alarm Indication detected at E1 interface. - e1sip-misconfig-mgc10 : Configuration not conform with the core network entity. - e1sip-nsmprf-missed : The SIP termination requires a NSM profile. - e1t1itf-recv-ais : Alarm Indication Signal received at interface. - e1t1itf-recv-los : Loss Of Signal received at interface. - e1t1itf-recv-rai : Remote Alarm Indication received at interface. - transport-mismatch : Transport protocol mismatch - dns-lookup-failure : Dns look up failure - none-dns-srv : No reply for all DNS serverd - no-dns-srv : No DNS servers configured - none-srv : No reply for all SIP First Hops - no-srv : No SIP First Hop configured - reg-srv-unreach : All SIP register servers are unreachable - proxy-srv-unreach : All SIP proxy servers are unreachable - dhcp-srv-unreach : The DHCP server is unreachable on this board - fo-trigger : Fail Over Triggered - fb-trigger : Fail Back Triggered - du-trigger : Deliberate Update Triggered - ssp-missing : SSP Missing in CDE - dns-pool-exceed : Number of different SG associated DNS pools exceed - lsa-fo-trigger : SIP voice service degraded - fail-over to LSA server - reg-domainname-sec : Registration failure (resolving domain name). - reg-auth-sec : Registration failure (authentication). - reg-timeout-sec : Registration failure (message timeout). - reg-srvfailresp-sec : Registration failure (failure response from server). - inv-domainname-sec : Invitation failure (resolving domain name). - inv-auth-sec : Invitation failure (authentication). - inv-timeout-sec : Invitation failure (message timeout). - inv-srvfailresp-sec : Invitation failure (failure response from server). - subs-srvfailresp-sec : Subscribe failure (failure response from server). - subs-domainname-sec : Subscribe failure (resolving domain name). - subs-auth-sec : Subscribe failure (authentication). - subs-refreshfail-sec : Subscribe failure (refresh failure). - subs-inittimeout-sec : Subscribe failure (initial REQ timeout). - emergency-call-sec : Emergency call for Secondary Termination is ongoing. - fanout : Lt load overflow	

name	Type	Description
	- up-overflow : Upstream load overflow - upobc-overflow : Upstream load to OBC overflow - dwobc-overflow : Downstream load to OBC overflow - dw-overflow : Downstream load overflow - lwpri-overflow : The number of BE and CL pkts dropped exceed threshold - queue-drop : The number of pkts dropped by queue exceeds threshold - queue-load : The queue load exceeds threshold - queue-peak-usage : The queue peak usage exceeds threshold - mgc-unreachable : loss of contact with the media gateway controller - failover-to-esamgc : failover to esa mgc - sgc-unreachable : loss of contac with signaling gateway controller - lcard-unreach-srvcard : line card unreachable with server card - lcard-type-mismatch : associate board of wrong type - meg-unknown-sub : the megaco subscriber is unknown - meg-ground-key : voice port ground key - meg-high-temp : voice port high temperature - meg-act-fail : the first link layer for isdn subscriber activation failure - meg-over-current : voice port over current - line-showering : line showering - low-qos-packetloss : the total packet loss has exceeded the configured threshold - low-qos-jitter : the rtp jitter has exceeded the configured threshold - low-qos-delay : the rtp delay has exceeded the configured threshold - sig-brd-persist-loss : voice signaling board persistent data loss - sig-brd-disk-full : voice signaling board disk 90% full - sig-brd-db-rollback : voice signaling board db rollback - mg-overload : mg overload - meg-unknown-sub-sec : The Megaco subscriber exists in voice signaling board but not in media gateway controller. - line-showering-sec : A subscriber line exceeds 20 off-hook / on-hook events / minute. - loss-env-mon : env-monitor box lost or not alive - etca-los : loss of signal errors in 15 min - etca-fcs : frame check sequence errors in 15 min - etca-day-los : loss of signal errors in 1 day - etca-day-fcs : frame check sequence errors in 1 day - etca-rx-octets : received octets in 15 min - etca-tx-octets : transmitted octets in 15 min - etca-day-rx-octets : received octets in 1 day - etca-day-tx-octets : transmitted octets in 1 day - user-sfp-los : user sfp loss of signal - user-sfp-tx-fail : user sfp tx failure - user-sfp-not-prst : user sfp not detected - user-sfp-inv-id : user sfp invalid id - user-sfp-t-exceed : user sfp temperature exceed - user-sfp-mismatch : user sfp mismatch the configured type - uplink-sfp-los : uplink sfp loss of signal	

100 Alarm Delta Log Status Commands

name	Type	Description
	- uplink-sfp-tx-fail : uplink sfp tx failure - uplink-sfp-not-prst : uplink sfp not detected - uplink-sfp-inv-id : uplink sfp invalid id - uplink-sfp-t-exceed : uplink sfp temperature exceed - uplink-sfp-mismatch : uplink sfp mismatch the configured type - loss-lmswp-cap : lsm redundancy - inv-xvps-pair-data : invalid xvps pair redundancy data - network-power-loss : Loss of Network Power - hw-fault : Hardware Failure - bat-miss : Power Source Battery Missing - bat-fail : Power Source Battery Failure - bat-low : Power Source Battery Charge LOW - bat-a-fail : Power Source BAT-A Fail - bat-b-fail : Power Source BAT-B Fail - ac-vol-out-range : AC Input Voltage Value Out of Range - network-power-loss-b : Loss of Network Power B - sem-ac-power-fail : External AC power supply failure - sem-ups-low-volt : External power supply low voltage - dc-a-fail : Local DC A power failure - dc-b-fail : Local DC B power failure - plan-power-mismatch : Planned and detected power mode mismatch - water-seepage-in-box : Detected water seepage in enclosure - sealed-box-open : Sealed box open detected - dc-a-vol-out-range : DC A Input Voltage Value Out of Range - dc-b-vol-out-range : DC B Input Voltage Value Out of Range - inlet-temp-major : The inlet temperature has exceeded a major level - inlet-temp-critical : The inlet temperature has exceeded a critical level - psu-fail-crit : Power Supply failure - psu-a-fail-presence : Power Supply A is not present - psu-a-fail-vin-ac-nok : Power Supply A has Vin AC fault - psu-a-fail-vin-uv : Power Supply A has Vin undervoltage - psu-a-fail-vin-ov : Power Supply A has Vin overvoltage - psu-a-fail-vout-uv : Power Supply A has Vout undervoltage - psu-a-fail-vout-ov : Power Supply A has Vout overvoltage - psu-a-fail-iout-oc : Power Supply A has Iout overcurrent - psu-a-fail-ovtemp : Power Supply A has over temperature - psu-b-fail-presence : Power Supply B is not present - psu-b-fail-vin-ac-nok : Power Supply B has Vin AC fault - psu-b-fail-vin-uv : Power Supply B has Vin undervoltage - psu-b-fail-vin-ov : Power Supply B has Vin overvoltage - psu-b-fail-vout-uv : Power Supply B has Vout undervoltage - psu-b-fail-vout-ov : Power Supply B has Vout overvoltage - psu-b-fail-iout-oc : Power Supply B has Iout overcurrent - psu-b-fail-ovtemp : Power Supply B has over temperature - synce-fail : synce clock source failure - bits-fail : bits clock source failure	

name	Type	Description
	- bits-output-shutoff : bits output failure - ieee1588-fail : ieee1588 clock source failure - gnss-fail : gnss clock source failure - ieee1588-hybrid-fail : ieee1588 hybrid tod source failure - signal-loss : synce or bits clock signal loss - signal-efd : synce or bits clock signal exceed frequency deviation - esmc-loss : clock source loss SSM infomation - bits-output-exceed : exceed bits output threshold - ql-input-exceed : exceed input clock source threshold - holdover : clock system is in the holdover - lti : all clock source failed - tod-reference-fail : Timing ToD Reference failed - internal-clk-fail : Internal CLK failed - bgp-peer-down : peer operational state is down - bgp-routes-mid-limit : 90% of max nbr of routes BGP can learn from a peer is reached - isis-adjacency-down : isis adjacency is down - isis-adjacency-reject : isis adjacency is rejected - isis-instance-down : isis instance is down or not - ospf-lsa-limit : limit of received LSA's is reached - ospf-lsa-mid-limit : 90% of limit of received LSA's is reached - ospf-neighbor-down : OSPF neighbour is down - ospf-instance-down : OSPF instance is down or not - ospf3-lsa-limit : limit of received OSPFv3 LSAs is reached - ospf3-lsa-mid-limit : 90% of limit of received OSPFv3 LSAs is reached - ospf3-neighbor-down : OSPFv3 neighbour is down - ospf3-instance-down : OSPFv3 instance is down or not - rip-instance-down : rip instance down - lag-down : lag down - lagsubgrp-thresh-reach: lag subgroup threshold reached - lagsubgrp-switch-fail : lag subgroup switchover failed - no-unpinned-free-ports: No free ports available for unpinned traffic - general-arp-limit : arp limit exceeded - gen-switch-out-of-res : failure due to lack of resources on switch - ipv6-nc-limit : ipv6 neighbor cache limit exceeded - dhcp-session-oor : dhcp session out of resources - ihub-fdb-limit : layer 2 fdb limit reached - ihub-mac-limit : layer 2 mac limit reached - l2fw-stp-exception : STP exception condition is present in the SAP - l2fw-stp-root-guard : STP root guard violation is present - vprn-routes-limit : limit of ip is reached - vprn-ipv6-routes-limit: limit of ipv6 is reached - dhcpv6-lease-limit : limit of dhcpv6 leases is reached - dhcpv4-lease-limit : limit of dhcpv4 leases is reached - vpls-mfib-limit : limit of fib table is reached - ihub-ipv6-dad-own : duplicate IPV6 address is detected for IP address allotted to system - ihub-ipv6-dad : duplicate IPV6 address is detected for a user's IP address - ihub-ipv6-dup-pd-route: ipv6 duplicate pd detected - vpls-duplicate-mac : duplicate mac address is detected	

100 Alarm Delta Log Status Commands

name	Type	Description
	- vpls-fdb-limit : limit of fdb table is reached - vpls-self-duplic-mac : duplicate of a system owned mac address detected on a sap - vpls-sdp-self-dup-mac : duplicate of a system owned mac address detected on a sdp binding - link-down : link is down - link-lagport-add-fail : failure to add port to LAG - link-conf-mismatch : SFP+plugin-types does not match the planned speed and/or auto-negotiation for the port - ihub-peer-comm : ihub peer to peer communication failure - ihub-sw-fail : IHUB s/w error - ihub-hw-fail : IHUB h/w error - ihub-link-fail : IHUB link failure - ihub-proc-overload : IHUB processor exceeded - ihub-out-of-mem : IHUB processor out of memory - ntp-comm-lost : No response is received from the NTP servers - ldp-instance-down : ldp instance down - ldp-session-down : ldp session down - mpls-instance-down : mpls instance down - mpls-lsp-down : lsp down - mpls-lsp-path-down : lsp path down - sdp-instance-down : sdp instance down - sdp-binding-down : sdp binding down - epipe-instance-down : epipe instance down - lldpmed-portcfg-mis : config request failure for lldpmed portconfig - lldpmed-mediapl-mis : config request failure for lldpmed mediapolicy - vlanport-svc-mismatch : config request failure for the provisioned vlanport - mcsrc-stream-lost : multicast video stream lost - eqptsupl-syslog-upload: upload of log file to remote server failure - eqptsupl-ontsw-dnload : ont sw download in progress - cf-75%used : Compact flash exceeds 75% of life expectancy - cf-90%used : Compact flash exceeds 90% of life expectancy - olt-gen-pon-com-fail : pon communication failure on olt - olt-gen-tx-fail : transmitter failure on olt - olt-gen-unprov-ont : unprovisioned ont on pon - olt-gen-pon-eqpt-prov : mismatch btw equipment and provisioning pon attributes - olt-gen-pon-loss-sig : pon loss of signal - olt-gen-pon-diagnostic: pon diagnostic test active - olt-gen-loid-conflict : loid conflict ont on pon - olt-gen-loid-pwderr : loid password error ont on pon - olt-gen-pon-alien-test: pon alien diagnostic test active - olt-gen-alien-detect : pon alien detect active - olt-gen-rng-mism : pon ranging mismatch active - olt-gen-sfp-mism : pon sfp mismatch active - olt-gen-deact-hightca : deactivated ont hightca threshold crossed - olt-gen-deact-lowtca : deactivated ont lowtca threshold crossed - olt-gen-dp-integ : pon data path integrity failure	

name	Type	Description
	- olt-gen-ddr-fault : pon failure due to ddr fault - olt-pon-tc-err-frag-tc: pon errored fragments threshold crossed - olt-ont-tc-err-frag-tc: ont errored fragments threshold crossed - ont-ploam-loss-sig : loss of signal at ont - ont-ploam-loss-ack : loss of acknowledge from ont - ont-ploam-loss-cd : loss of channel delineation of ont - ont-ploam-phy-eqpt-err: physical equipment error of ont - ont-ploam-startup-fail: startup failure in ranging of ont - ont-ploam-sig-degrade : signal degrade from ont - ont-ploam-disabled : ont disabled alarm - ont-ploam-err-msg : error message from ont - ont-ploam-inactive : inactive ont - ont-ploam-sig-fail : signal fail alarm from ont - ont-ploam-dying-gasp : dying gasp alarm from ont - ont-ploam-deact-fail : deactive failure of ont - ont-ploam-oam : loss of ploam for ont - ont-ploam-win-drift : drift of window alarm - ont-ploam-rdi : remote defect indication alarm - ont-ploam-loss-ks : loss of key synchronization alarm - ont-ploam-pwr-burst : power bursts on ont - ont-ploam-rog-disa : ont rogue disabled - ont-ploam-diff-reach : ont differential reach exceeded - ont-ploam-looc : Loss of OMCI channel due to persistent MIC failure - sfu-ploam-loss-sig : SFU ONT - loss of signal at ont - sfu-ploam-loss-ack : SFU ONT - loss of acknowledge from ont - sfu-ploam-loss-cd : SFU ONT - loss of channel delineation of ont - sfu-ploam-phy-eqpt-err: SFU ONT - physical equipment error of ont - sfu-ploam-startup-fail: SFU ONT - startup failure in ranging of ont - sfu-ploam-sig-degrade : SFU ONT - signal degrade from ont - sfu-ploam-disabled : SFU ONT - ont disabled alarm - sfu-ploam-err-msg : SFU ONT - error message from ont - sfu-ploam-inactive : SFU ONT - inactive ont - sfu-ploam-sig-fail : SFU ONT - signal fail alarm from ont - sfu-ploam-dying-gasp : SFU ONT - dying gasp alarm from ont - sfu-ploam-deact-fail : SFU ONT - deactive failure of ont - sfu-ploam-oam : SFU ONT - loss of ploam for ont - sfu-ploam-win-drift : SFU ONT - drift of window alarm - sfu-ploam-rdi : SFU ONT - remote defect indication alarm - sfu-ploam-loss-ks : SFU ONT - loss of key synchronization alarm - sfu-ploam-pwr-burst : SFU ONT - power bursts on ont - sfu-ploam-rog-disa : SFU ONT - ont rogue disabled - sfu-ploam-diff-reach : SFU ONT - ont differential reach exceeded - sfu-ploam-looc : SFU ONT - Loss of OMCI channel due to persistent MIC failure - soho-ploam-loss-sig : SOHO ONT - loss of signal at ont - soho-ploam-loss-ack : SOHO ONT - loss of acknowledge	

100 Alarm Delta Log Status Commands

name	Type	Description
	from ont - soho-ploam-loss-cd : SOHO ONT - loss of channel delineation of ont - soho-ploam-phy-eqpt-er: SOHO ONT - physical equipment error of ont - soho-ploam-startup-fai: SOHO ONT - startup failure in ranging of ont - soho-ploam-sig-degrade: SOHO ONT - signal degrade from ont - soho-ploam-disabled : SOHO ONT - ont disabled alarm - soho-ploam-err-msg : SOHO ONT - error message from ont - soho-ploam-inactive : SOHO ONT - inactive ont - soho-ploam-sig-fail : SOHO ONT - signal fail alarm from ont - soho-ploam-dying-gasp : SOHO ONT - dying gasp alarm from ont - soho-ploam-deact-fail : SOHO ONT - deactive failure of ont - soho-ploam-oam : SOHO ONT - loss of ploam for ont - soho-ploam-win-drift : SOHO ONT - drift of window alarm - soho-ploam-rdi : SOHO ONT - remote defect indication alarm - soho-ploam-loss-ks : SOHO ONT - loss of key synchronization alarm - soho-ploam-pwr-burst : SOHO ONT - power bursts on ont - soho-ploam-rog-disa : SOHO ONT - ont rogue disabled - soho-ploam-diff-reach : SOHO ONT - ont differential reach exceeded - soho-ploam-looc : SOHO ONT - Loss of OMCI channel due to persistent MIC failure - mdu-ploam-loss-sig : MDU ONT - loss of signal at ont - mdu-ploam-loss-ack : MDU ONT - loss of acknowledge from ont - mdu-ploam-loss-cd : MDU ONT - loss of channel delineation of ont - mdu-ploam-phy-eqpt-err: MDU ONT - physical equipment error of ont - mdu-ploam-startup-fail: MDU ONT - startup failure in ranging of ont - mdu-ploam-sig-degrade : MDU ONT - signal degrade from ont - mdu-ploam-disabled : MDU ONT - ont disabled alarm - mdu-ploam-err-msg : MDU ONT - error message from ont - mdu-ploam-inactive : MDU ONT - inactive ont - mdu-ploam-sig-fail : MDU ONT - signal fail alarm from ont - mdu-ploam-dying-gasp : MDU ONT - dying gasp alarm from ont - mdu-ploam-deact-fail : MDU ONT - deactive failure of ont - mdu-ploam-oam : MDU ONT - loss of ploam for ont - mdu-ploam-win-drift : MDU ONT - drift of window alarm - mdu-ploam-rdi : MDU ONT - remote defect indication alarm - mdu-ploam-loss-ks : MDU ONT - loss of key synchronization alarm	

name	Type	Description
	- mdu-ploam-pwr-burst : MDU ONT - power bursts on ont - mdu-ploam-roq-disa : MDU ONT - ont rogue disabled - mdu-ploam-diff-reach : MDU ONT - ont differential reach exceeded - mdu-ploam-looc : MDU ONT - Loss of OMCI channel due to persistent MIC failure - ont-hpna-ser-mis : hpna ont service mismatch - ont-hpna-los-sig : hpna loss of link - ont-moca-svc-mis : moca ont service mismatch - ont-moca-link-los : moca loss of link - ont-moca-min-bw : moca bw between nodes less than minimum bw - ont-moca-tca-rx-err-fr: moca rx errored frames threshold crossed - ont-sipa-reg-nm-fail : sipua registration name failed - ont-sipa-reg-rec-fail : sipua register reach failed - ont-sipa-reg-con-fail : sipua register connect failed - ont-sipa-reg-val-fail : sipua register validation failed - ont-sipa-reg-mis : sipua register mismatch - ont-vcd-cfg-nm-fail : vcd config name failed - ont-vcd-cfg-rech-fail : vcd config reach failed - ont-vcd-cfg-conn-fail : vcd config connect failed - ont-vcd-cfg-vali-fail : vcd config validation failed - ont-vcd-cfg-auth-fail : vcd config authentication failed - ont-vcd-cfg-resp-tmout: vcd config response timeout - ont-vcd-cfg-resp-err : vcd config response error - ont-vcd-cfg-file-err : vcd config file error - ont-vcd-sub-nm-fail : vcd subscription name failed - ont-vcd-sub-rech-fail : vcd subscription reach failed - ont-vcd-sub-conn-fail : vcd subscription connect failed - ont-vcd-sub-vali-fail : vcd subscription validation failed - ont-vcd-sub-auth-fail : vcd subscription authentication failed - ont-vcd-sub-resp-tmout: vcd subscription response timeout - ont-vcd-sub-resp-err : vcd subscription response error - ont-vcd-reb-requ : vcd reboot request - ont-vcd-mis : vcd mismatch - ont-mgc-mis : ont mgc mismatch - ont-mgc-timeout : ont mgc timeout - ont-sip-reg-dns : ont services pots sip registration failed (resolving domain name) - ont-sip-reg-fail : ont services pots sip registration authentication failed - ont-sip-reg-timeout : ont services pots sip registration timeout - ont-sip-reg-err-resps : ont services pots sip registration response error - ont-sip-inv-dns : ont services pots sip invitation failed (resolving domain name) - ont-sip-inv-auth : ont services pots sip invitation authentication failed - ont-sip-inv-timeout : ont services pots sip invitation timeout - ont-sip-inv-err : ont services pots sip invitation response error - ont-svc-pots-subs-refr: ont services pots iconfig subscription could not be refreshed	

100 Alarm Delta Log Status Commands

name	Type	Description
	- ont-svc-pots-not-refr : ont services pots iconfig notification could not be refreshed - ont-svc-pots-icfg-err : ont services pots service failed due to an unmapped iconfig error - ont-veip-mismatch : ont veip mismatch - ont-ip-host-mismatch : ont ip host mismatch - ont-ip-host-file : ont ip host file unavailable - ont-ip-host-ip-alloc : ont ip host IP allocation failure - olt-pon-up-bw-tca : OLT PON upstream bandwidth TCA - olt-pon-down-bw-tca : OLT PON downstream bandwidth TCA - ont-gen-omci-fail : loss of communication - ont-gen-eqpt-selftest : ont self-test failure - ont-gen-ac-pwr-fail : ac power failure on ont - ont-gen-bat-missing : battery missing - ont-gen-bat-low : battery low - ont-gen-bat-fail : battery failure - ont-gen-phys-intrusion : physical intrusion - ont-gen-sw-dnload-f : ont sw download failure - ont-gen-sw-dnload-p : ont sw download in progress - ont-gen-sw-act-fail : ont sw activation failure - ont-gen-eqpt-vers-mis : ont equipment version mismatch - ont-gen-sw-vers-mis : ont sw version mismatch - ont-gen-us-rate-mis : ont upstream rate mismatch - ont-gen-mdu-env1 : mdu environmental alarm#1 - ont-gen-mdu-env2 : mdu environmental alarm#2 - ont-gen-mdu-env3 : mdu environmental alarm#3 - ont-gen-nw-time-err : network timing protocol error - ont-gen-opt-sig-high : optical signal level too high - ont-gen-opt-sig-low : optical signal level too low - ont-gen-eqpt-prov-sa : service affecting mismatch btw equipment and provisioning attributes - ont-gen-eqpt-prov-nsa : non service affecting mismatch btw equipment and provisioning attributes - pon-t-txmcutilhi : pon utilization tx (downstream) multicast high threshold crossed - pon-t-txmcutilmd : pon utilization tx (downstream) multicast medium threshold crossed - pon-t-txmcutillo : pon utilization tx (downstream) multicast low threshold crossed - pon-t-txtotutilhi : pon utilization tx (downstream) total high threshold crossed - pon-t-txtotutilmd : pon utilization tx (downstream) total medium threshold crossed - pon-t-txtotutillo : pon utilization tx (downstream) total low threshold crossed - pon-t-rxtotutilhi : pon utilization rx (upstream) total high threshold crossed - pon-t-rxtotutilmd : pon utilization rx (upstream) total medium threshold crossed - pon-t-rxtotutillo : pon utilization rx (upstream) total low threshold crossed - pon-t-dbacongperiodhi : pon utilization rx (upstream) dbacongperiod high threshold crossed - pon-t-dbacongperiodmd : pon utilization rx (upstream) dbacongperiod medium threshold crossed - pon-t-dbacongperiodlo : pon utilization rx (upstream)	

name	Type	Description
	dbacongperiod low threshold crossed - pon-t-txucdropfrmhi : pon utilization tx (downstream) unicast drop frame high threshold crossed - pon-t-txucdropfrmmd : pon utilization tx (downstream) unicast drop frame medium threshold crossed - pon-t-txucdropfrmlo : pon utilization tx (downstream) unicast drop frame low threshold crossed - pon-t-txmcdropfrmhi : pon utilization tx (downstream) multicast drop frame high threshold crossed - pon-t-txmcdropfrmmd : pon utilization tx (downstream) multicast drop frame medium threshold crossed - pon-t-txmcdropfrmlo : pon utilization tx (downstream) multicast drop frame low threshold crossed - pon-t-txbcdropfrmhi : pon utilization tx (downstream) broadcast drop frame high threshold crossed - pon-t-txbcdropfrmmd : pon utilization tx (downstream) broadcast drop frame medium threshold crossed - pon-t-txbcdropfrmlo : pon utilization tx (downstream) broadcast drop frame low threshold crossed - pon-t-rxtotdropfrmhi : pon utilization rx (upstream) total drop frame high threshold crossed - pon-t-rxtotdropfrmmd : pon utilization rx (upstream) total drop frame medium threshold crossed - pon-t-rxtotdropfrmlo : pon utilization rx (upstream) total drop frame low threshold crossed - chpr-t-txmcutilhi : channel-pair utilization tx (downstream) multicast high threshold crossed - chpr-t-txmcutilmd : channel-pair utilization tx (downstream) multicast medium threshold crossed - chpr-t-txmcutillo : channel-pair utilization tx (downstream) multicast low threshold crossed - chpr-t-txtotutilhi : channel-pair utilization tx (downstream) total high threshold crossed - chpr-t-txtotutilmd : channel-pair utilization tx (downstream) total medium threshold crossed - chpr-t-txtotutillo : channel-pair utilization tx (downstream) total low threshold crossed - chpr-t-rxtotutilhi : channel-pair utilization rx (upstream) total high threshold crossed - chpr-t-rxtotutilmd : channel-pair utilization rx (upstream) total medium threshold crossed - chpr-t-rxtotutillo : channel-pair utilization rx (upstream) total low threshold crossed - chpr-t-dbacongperiodhi : channel-pair utilization rx (upstream) dbacongperiod high threshold crossed - chpr-t-dbacongperiodmd : channel-pair utilization rx (upstream) dbacongperiod medium threshold crossed - chpr-t-dbacongperiodlo : channel-pair utilization rx (upstream) dbacongperiod low threshold crossed - chpr-t-txucdropfrmhi : channel-pair utilization tx (downstream) unicast drop frame high threshold crossed - chpr-t-txucdropfrmmd : channel-pair utilization tx (downstream) unicast drop frame medium threshold crossed - chpr-t-txucdropfrmlo : channel-pair utilization tx (downstream) unicast drop frame low threshold crossed - chpr-t-txmcdropfrmhi : channel-pair utilization tx (downstream) multicast drop frame high threshold crossed	

100 Alarm Delta Log Status Commands

name	Type	Description
	- chpr-t-txmcdropfrmmd : channel-pair utilization tx (downstream) multicast drop frame medium threshold crossed - chpr-t-txmcdropfrmlo : channel-pair utilization tx (downstream) multicast drop frame low threshold crossed - chpr-t-txbcdropfrmhi : channel-pair utilization tx (downstream) broadcast drop frame high threshold crossed - chpr-t-txbcdropfrmmd : channel-pair utilization tx (downstream) broadcast drop frame medium threshold crossed - chpr-t-txbcdropfrmlo : channel-pair utilization tx (downstream) broadcast drop frame low threshold crossed - chpr-t-rxtotdropfrmhi : channel-pair utilization rx (upstream) total drop frame high threshold crossed - chpr-t-rxtotdropfrmmd : channel-pair utilization rx (upstream) total drop frame medium threshold crossed - chpr-t-rxtotdropfrmlo : channel-pair utilization rx (upstream) total drop frame low threshold crossed - sfu-gen-omci-fail : SFU ONT - loss of communication - sfu-gen-eqpt-selftest : SFU ONT - ont self-test failure - sfu-gen-ac-pwr-fail : SFU ONT - ac power failure on ont - sfu-gen-bat-missing : SFU ONT - battery missing - sfu-gen-bat-low : SFU ONT - battery low - sfu-gen-bat-fail : SFU ONT - battery failure - sfu-gen-sw-dnload-f : SFU ONT - ont sw download failure - sfu-gen-sw-dnload-p : SFU ONT - ont sw download in progress - sfu-gen-sw-act-fail : SFU ONT - ont sw activation failure - sfu-gen-eqpt-vers-mis : SFU ONT - ont equipment version mismatch - sfu-gen-sw-vers-mis : SFU ONT - ont sw version mismatch - sfu-gen-us-rate-mis : SFU ONT - ont upstream rate mismatch - sfu-gen-tune-fail : SFU ONT - ont has failed to tune to Target-ChnlPair - sfu-gen-nw-time-err : SFU ONT - network timing protocol error - sfu-gen-opt-sig-high : SFU ONT - optical signal level too high - sfu-gen-opt-sig-low : SFU ONT - optical signal level too low - sfu-gen-eqpt-prov-sa : SFU ONT - service affecting mismatch btw equipment and provisioning attributes - sfu-gen-eqpt-prov-nsa : SFU ONT - non service affecting mismatch btw equipment and provisioning attributes - soho-gen-omci-fail : SOHO ONT - loss of communication - soho-gen-eqpt-selftest : SOHO ONT - ont self-test failure - soho-gen-ac-pwr-fail : SOHO ONT - ac power failure on ont - soho-gen-bat-missing : SOHO ONT - battery missing - soho-gen-bat-low : SOHO ONT - battery low - soho-gen-bat-fail : SOHO ONT - battery failure - soho-gen-sw-dnload-f : SOHO ONT - ont sw download failure - soho-gen-sw-dnload-p : SOHO ONT - ont sw download in progress	

name	Type	Description
	- soho-gen-sw-act-fail : SOHO ONT - ont sw activation failure - soho-gen-eqpt-vers-mis: SOHO ONT - ont equipment version mismatch - soho-gen-sw-vers-mis : SOHO ONT - ont sw version mismatch - soho-gen-us-rate-mis : SOHO ONT - ont upstream rate mismatch - soho-gen-tune-fail : SOHO ONT - ont has failed to tune to Target-ChnlPair - soho-gen-nw-time-err : SOHO ONT - network timing protocol error - soho-gen-opt-sig-high : SOHO ONT - optical signal level too high - soho-gen-opt-sig-low : SOHO ONT - optical signal level too low - soho-gen-eqpt-prov-sa : SOHO ONT - service affecting mismatch btw equipment and provisioning attributes - soho-gen-eqpt-prov-nsa: SOHO ONT - non service affecting mismatch btw equipment and provisioning attributes - mdu-gen-omci-fail : MDU ONT - loss of communication - mdu-gen-eqpt-selftest : MDU ONT - ont self-test failure - mdu-gen-ac-pwr-fail : MDU ONT - ac power failure on ont - mdu-gen-bat-missing : MDU ONT - battery missing - mdu-gen-bat-low : MDU ONT - battery low - mdu-gen-bat-fail : MDU ONT - battery failure - mdu-gen-phys-intrusion: MDU ONT - physical intrusion - mdu-gen-sw-dnload-f : MDU ONT - ont sw download failure - mdu-gen-sw-dnload-p : MDU ONT - ont sw download in progress - mdu-gen-sw-act-fail : MDU ONT - ont sw activation failure - mdu-gen-eqpt-vers-mis : MDU ONT - ont equipment version mismatch - mdu-gen-sw-vers-mis : MDU ONT - ont sw version mismatch - mdu-gen-us-rate-mis : MDU ONT - ont upstream rate mismatch - mdu-gen-tune-fail : MDU ONT - ont has failed to tune to Target-ChnlPair - mdu-gen-mdu-env1 : MDU ONT - mdu environmental alarm#1 - mdu-gen-mdu-env2 : MDU ONT - mdu environmental alarm#2 - mdu-gen-mdu-env3 : MDU ONT - mdu environmental alarm#3 - mdu-gen-nw-time-err : MDU ONT - network timing protocol error - mdu-gen-opt-sig-high : MDU ONT - optical signal level too high - mdu-gen-opt-sig-low : MDU ONT - optical signal level too low - mdu-gen-eqpt-prov-sa : MDU ONT - service affecting mismatch btw equipment and provisioning attributes	

100 Alarm Delta Log Status Commands

name	Type	Description
	- mdu-gen-eqpt-prov-nsa : MDU ONT - non service affecting mismatch btw equipment and provisioning attributes - ont-gen-sw-dnload-file: ont sw download file missing - ont-gen-fan-fail : ont fan failure - ont-gen-high-temp : ont high temperature - ont-gen-high-temp-ex : ont excessive high temperature - ont-gen-emergency-call: ont emergency call - ont-gen-sw-version : ont sw version control error - ont-poe-exceed-max : ont poe exceed max - ont-poe-overload-yell : ONU is nearing its maximum ability to supply the power - ont-opti-malfunc : malfunction of ONT's optical transceiver - ont-gen-cfgdld-fail : download of voice xml file to ont failed - ont-gen-rssi-mis : ONU RSSI configuration mismatch - ont-gen-tx-pwr-low : ONU SFP Tx Power is lower than configured Alarm low threshold - ont-gen-temp-high : ONU SFP Temperature is higher than configured Alarm high threshold - ont-gen-volt-high : ONU SFP Voltage is higher than configured Alarm high threshold - ont-gen-bias-high : ONU SFP Bias is higher than configured Alarm high threshold - ont-loopdetect-mis : ont loop detect mismatch - ont-olt-rx-pw-lo : olt side receive power from ont low - ont-olt-rx-pw-hig : olt side receive power from ont high - ont-olt-rx-pw-warnlo : olt side receive power from ont low warning - ont-olt-rx-pw-warnhig : olt side receive power from ont high warning - ont-gen-tod-out-sync : ONU TOD is out-sync with OLT - ont-gen-tune-fail : ONU has failed to tune to Target-ChnlPair - hgu-tr069-parm-fail : hgu tr069 parameters mismatch - ont-gen-tod-mismatch : ONU TOD MISMATCH - sfu-sup-sw-file-error : SFU ONT - Software file has error or is missing - sfu-sup-fan-failure : SFU ONT - Fan failure - sfu-sup-temp-high-warn: SFU ONT - High temperature warning - sfu-sup-temp-shutoff : SFU ONT - Service disabled due to excessive temperature - sfu-sup-emergency-call: SFU ONT - Emergency call active - sfu-sup-swverctrl-err : SFU ONT - Software version control error - sfu-sup-poe-exceed-max: SFU ONT - Configured PoE feeding exceeds ONT maximum - sfu-sup-poe-over-yell : SFU ONT - ONU is nearing its maximum ability to supply the power - sfu-opti-malfunc : SFU ONT - Malfunction of ONT's optical transceiver - sfu-sup-cfg-dnld-fail : SFU ONT - Download of voice xml file to ONT failed - sfu-sup-rssi-cfg-mism : SFU ONT - RSSI configuration mismatch	

name	Type	Description
	- sfu-sup-sfp-tx-low : SFU ONT - SFP Tx Power below configured low-level alarm threshold - sfu-sup-sfp-temp-high : SFU ONT - SFP Temperature above configured high-level alarm threshold - sfu-sup-sfp-volt-high : SFU ONT - SFP Voltage above configured high-level alarm threshold - sfu-sup-sfp-bias-high : SFU ONT - SFP Bias above configured high-level alarm threshold - sfu-sup-ld-cfg-mism : SFU ONT - Loop detection configuration mismatch - sfu-sup-olt-rx-low : SFU ONT - OLT Rx power below receiver operating range - sfu-sup-olt-rx-high : SFU ONT - OLT Rx power above receiver operating range - sfu-sup-olt-rx-lo-warn: SFU ONT - OLT Rx power below low-level warning threshold - sfu-sup-olt-rx-hi-warn: SFU ONT - OLT Rx power above high-level warning threshold - sfu-sup-tod-out-sync : SFU ONT - ONU TOD is out-sync with OLT - sfu-sup-ont-tune-fail : SFU ONT - ONU has failed to tune to Target-ChnlPair - sfu-tr069-parm-fail : SFU ONT - hgu tr069 parameters mismatch - sfu-sup-tod-mismatch : SFU ONT - ONU TOD MISMATCH - soho-sup-sw-file-error: SOHO ONT - Software file has error or is missing - soho-sup-fan-failure : SOHO ONT - Fan failure - soho-sup-temp-high-war: SOHO ONT - High temperature warning - soho-sup-temp-shutoff : SOHO ONT - Service disabled due to excessive temperature - soho-sup-emergency-cal: SOHO ONT - Emergency call active - soho-sup-swverctrl-err: SOHO ONT - Software version control error - soho-sup-poe-exceed-ma: SOHO ONT - Configured PoE feeding exceeds ONT maximum - soho-sup-poe-over-yell: SOHO ONT - ONU is nearing its maximum ability to supply the power - soho-opti-malfunc : SOHO ONT - Malfunction of ONT's optical transceiver - soho-sup-cfg-dnld-fail: SOHO ONT - Download of voice xml file to ONT failed - soho-sup-rssi-cfg-mism: SOHO ONT - RSSI configuration mismatch - soho-sup-sfp-tx-low : SOHO ONT - SFP Tx Power below configured low-level alarm threshold - soho-sup-sfp-temp-high: SOHO ONT - SFP Temperature above configured high-level alarm threshold - soho-sup-sfp-volt-high: SOHO ONT - SFP Voltage above configured high-level alarm threshold - soho-sup-sfp-bias-high: SOHO ONT - SFP Bias above configured high-level alarm threshold - soho-sup-ld-cfg-mism : SOHO ONT - Loop detection configuration mismatch	

100 Alarm Delta Log Status Commands

name	Type	Description
	- soho-sup-olt-rx-low : SOHO ONT - OLT Rx power below receiver operating range - soho-sup-olt-rx-high : SOHO ONT - OLT Rx power above receiver operating range - soho-sup-olt-rx-lo-war: SOHO ONT - OLT Rx power below low-level warning threshold - soho-sup-olt-rx-hi-war: SOHO ONT - OLT Rx power above high-level warning threshold - soho-sup-tod-out-sync : SOHO ONT - ONU TOD is out-sync with OLT - soho-sup-ont-tune-fail: SOHO ONT - ONU has failed to tune to Target-ChnlPair - soho-tr069-param-fail : SOHO ONT - hgu tr069 parameters mismatch - soho-sup-tod-mismatch : SOHO ONT - ONU TOD MISMATCH - mdu-sup-sw-file-error : MDU ONT - Software file has error or is missing - mdu-sup-fan-failure : MDU ONT - Fan failure - mdu-sup-temp-high-warn: MDU ONT - High temperature warning - mdu-sup-temp-shutoff : MDU ONT - Service disabled due to excessive temperature - mdu-sup-emergency-call: MDU ONT - Emergency call active - mdu-sup-swverctrl-err : MDU ONT - Software version control error - mdu-sup-poe-exceed-max: MDU ONT - Configured PoE feeding exceeds ONT maximum - mdu-sup-poe-over-yell : MDU ONT - ONU is nearing its maximum ability to supply the power - mdu-opti-malfunc : MDU ONT - Malfunction of ONT's optical transceiver - mdu-sup-cfg-dnld-fail : MDU ONT - Download of voice xml file to ONT failed - mdu-sup-rssi-cfg-mism : MDU ONT - RSSI configuration mismatch - mdu-sup-sfp-tx-low : MDU ONT - SFP Tx Power below configured low-level alarm threshold - mdu-sup-sfp-temp-high : MDU ONT - SFP Temperature above configured high-level alarm threshold - mdu-sup-sfp-volt-high : MDU ONT - SFP Voltage above configured high-level alarm threshold - mdu-sup-sfp-bias-high : MDU ONT - SFP Bias above configured high-level alarm threshold - mdu-sup-ld-cfg-mism : MDU ONT - Loop detection configuration mismatch - mdu-sup-olt-rx-low : MDU ONT - OLT Rx power below receiver operating range - mdu-sup-olt-rx-high : MDU ONT - OLT Rx power above receiver operating range - mdu-sup-olt-rx-lo-warn: MDU ONT - OLT Rx power below low-level warning threshold - mdu-sup-olt-rx-hi-warn: MDU ONT - OLT Rx power above high-level warning threshold - mdu-sup-tod-out-sync : MDU ONT - ONU TOD is out-sync with OLT	

name	Type	Description
	- mdu-sup-ont-tune-fail : MDU ONT - ONU has failed to tune to Target-ChnlPair - mdu-tr069-param-fail : MDU ONT - hgu tr069 parameters mismatch - mdu-sup-tod-mismatch : MDU ONT - ONU TOD MISMATCH - ont-sbscr-lim-missing : provisioned ont card missing - ont-sbscr-lim-type-mis: wrong type plug-in ont card - ont-sbscr-lim-removal : improper removal ont card - ont-sbscr-lim-fail : ont card failure - ont-sbscr-lim-svc-mis : ont service mismatch for provisioned onu card - ont-sbscr-lim-port-mis: port mismatch btw actual and planned ont card - ont-svc-video-conf-mis: config request failure for video service - ont-svc-video-pw-high : high power level for rf video signal - ont-svc-video-pw-low : low power level for rf video signal - ont-svc-pots-svc-mis : ont service mismatch for provisioned pots - ont-svc-pots-rtcp-lost: pots realtime transport control protocol stream lost - ont-svc-pots-icnf-subs: pots line iconfig subscription failure - ont-svc-pots-icnf-ntfy: pots line iconfig notify failure - ont-svc-pots-icnf-http: pots line iconfig http failure - ont-svc-pots-sip-reg : pots line sip registration failure - ont-svc-pots-sip-inv : pots line sip invite request failure - ont-svc-pots-sip-subsc: pots line sip subscribe failure - ont-svc-pots-sip-mt-tc: pots line sip message timeout threshold crossed - ont-svc-pots-pk-los-tc: pots line rtp bearer packets loss threshold crossed - ont-svc-pots-jitter-tc: pots line rtp jitter threshold crossed - ont-svc-pots-subs-dns : pots line iconfig subscription failed (DNS) - ont-svc-pots-subs-tcp : pots line iconfig subscription failed (TCP) - ont-svc-pots-subs-tls : pots line iconfig subscription failed (TLS) - ont-svc-pots-subs-auth: pots line iconfig subscription failed authentication - ont-svc-pots-subs-to : pots line iconfig subscription failed (timeout) - ont-svc-pots-subs-err : pots line iconfig subscription response error - ont-svc-pots-not-to : pots line iconfig notification failed (timeout) - ont-svc-pots-notref-to: pots line iconfig notification refresh failed - ont-svc-pots-not-mal : pots line iconfig notification failed (malformed) - ont-svc-pots-not-rej : pots line iconfig notification rejected - ont-svc-pots-http-dns : pots line iconfig doc retrieval failed (DNS) - ont-svc-pots-http-tcp : pots line iconfig doc retrieval failed	

name	Type	Description
	(TCP) - ont-svc-pots-http-tls : pots line iconfig doc retrieval failed (TLS) - ont-svc-pots-http-auth: pots line iconfig doc retrieval failed (authentication) - ont-svc-pots-http-to : pots line iconfig doc retrieval failed (timeout) - ont-svc-pots-http-err : pots line iconfig doc retrieval response error - ont-svc-pots-http-mal : pots line iconfig doc retrieval failed (malformed) - ont-svc-pots-insuff : pots line iconfig service failed (insufficient data) - ont-svc-pots-poos : pots ports out of service - ont-svc-lan-mismatch : ont service mismatch for lan - ont-svc-lan-loss-sig : loss of signal on an ethernet port interface - ont-svc-enet-poos : Ethernet Ports out of Service - ont-svc-ces-ds1-mis : ont service mismatch for provisioned ces ds1 - ont-svc-ces-ds1-los : loss of signal at ds1 interface - ont-svc-ces-ds1-lof : loss of frame at ds1 interface - ont-svc-ces-ds1-rair : receiving rai at ds1 interface - ont-svc-ces-ds1-ais : receiving ais at ds1 interface - ont-svc-ces-ds1-lnlpbk: receiving line loopback at ds1 interface - ont-svc-ces-ds1-tmlpbk: receiving terminal loopback at ds1 interface - ont-svc-ces-e1-mis : ont service mismatch for provisioned ces e1 - ont-svc-ces-e1-los : loss of signal at e1 interface - ont-svc-ces-e1-lof : loss of frame at e1 interface - ont-svc-ces-e1-rair : receiving rai at e1 interface - ont-svc-ces-e1-ais : receiving ais at e1 interface - ont-svc-voip-cnf-file : voice configuration file error - ont-svc-voip-svc-mis : service mismatch for provisioned client service - ont-svc-voip-gw-comm : voice gateway communication failure - ont-svc-voip-dhcp-fail: voice dhcp server failure - ont-svc-voip-icnf-subs: voice iconfig subscription failure - ont-svc-voip-icnf-ntfy: voice iconfig notify failure - ont-svc-voip-icnf-http: voice iconfig http failure - ont-svc-voip-dhcp-to : DHCP server retransmissions timed out - ont-svc-voip-dhcp-mal : DHCP response was malformed - ont-svc-voip-dhcp-noad: DHCP server failed to issue the required parameters - ont-svc-voip-dhcp-leas: DHCP Server failure due to problem in lease renewal - ont-svc-voip-subs-dns : iConfig Subscription failure due to DNS problem - ont-svc-voip-subs-tcp : iConfig Subscription failure due to TCP socket problem - ont-svc-voip-subs-tls : iConfig Subscription failure due to TLS session problem - ont-svc-voip-subs-auth: iConfig Subscription failure due to	

name	Type	Description
	authentication error - ont-svc-voip-subs-to : iConfig Subscription failure due to retransmission timeout - ont-svc-voip-subs-err : iConfig Subscription failure due to response error - ont-svc-voip-not-to : iConfig Notify response timeout for new subscription - ont-svc-voip-notref-to: iConfig Notify response timeout for subscription refresh - ont-svc-voip-not-mal : iConfig Notify response is malformed - ont-svc-voip-not-rej : iConfig subscription request rejected by configuration server - ont-svc-voip-http-dns : VOIP client can't retrieve config doc due to DNS problem - ont-svc-voip-http-tcp : VOIP client can't retrieve config doc due to TCP socket problem - ont-svc-voip-http-tls : VOIP client can't retrieve config doc due to TLS session problem - ont-svc-voip-http-auth: VOIP client can't retrieve config doc due to auth error - ont-svc-voip-http-to : VOIP client can't retrieve config doc due to re-tx timeout - ont-svc-voip-http-err : VOIP client can't retrieve config doc due to response error - ont-svc-voip-http-mal : iConfig configuration document is malformed - ont-svc-voip-subs-refr: iConfig Subscription refresh error - ont-svc-voip-not-refr : iConfig Notify response for refresh subscribe failed - ont-svc-voip-icfg-err : iConfig Configuration Error - ont-svc-v-ani-conf-mis: config request failure for video ani service - ont-svc-v-ani-loss-sig: video loss of signal on ani - ont-svc-v-ani-lv-high : high video optical signal level - ont-svc-v-ani-lv-low : low video optical signal level - ont-svc-pwe-mismatch : service mismatch for provisioned pseudowire - ont-svc-pwe-reordr-lof: pseudowire reordering and loss of frame - ont-svc-pwe-jitt-buf-o: pseudowire jitter buffer overrun - ont-svc-pwe-jitt-buf-u: pseudowire jitter buffer underrun - ont-svc-pwe-malf-frms : pseudowire malformed frames - ont-svc-pwe-late-frms : pseudowire late frames - ont-svc-pwe-link-loss : pseudowire link loss - ont-svc-pwe-arp-fail : pseudowire arp failure - ont-svc-xdsl-mismatch : service mismatch for provisioned xdsl - ont-svc-xdsl-ne-lof : near end loss of frame - ont-svc-xdsl-ne-los : near end loss of signal - ont-svc-xdsl-ne-line : near end line init - ont-svc-xdsl-ne-lol : near end loss of link - ont-svc-xdsl-fe-lof : far end loss of frame - ont-svc-xdsl-fe-los : far end loss of signal - ont-svc-xdsl-fe-lop : far end loss of power - ont-svc-xdsl-cnfr-err : xdsl provisioning error - ont-svc-xdsl-ne-es-tc : near end errored seconds threshold	

100 Alarm Delta Log Status Commands

name	Type	Description
	crossed - ont-svc-xdsl-ne-ses-tc: near end severe errored seconds threshold crossed - ont-svc-xdsl-ne-uas-tc: ear end unavailable seconds threshold crossed - ont-svc-xdsl-fe-es-tc : far end errored seconds threshold crossed - ont-svc-xdsl-fe-ses-tc: far end severe errored seconds threshold crossed - ont-svc-xdsl-fe-uas-tc: far end unavailable seconds threshold crossed - ont-tc-rx-los-frag-tc : rx loss of gem fragments threshold crossed - ont-tc-tx-los-frag-tc : tx loss of gem fragments threshold crossed - ont-tc-bad-gem-hd-tc : bad gem header threshold crossed - ont-uni-ds-drp-d-fr-tc : downstream l2 dropped frames threshold crossed - ont-uni-up-drp-d-fr-tc : upstream l2 dropped frames threshold crossed - ont-uni-ds-crc-fr-tc : downstream l2 rx crc error frames threshold crossed - ont-uni-up-crc-fr-tc : upstream l2 rx crc error frames threshold crossed - ont-cpu-util-tca : ONT CPU utilization threshold crossed - ont-mem-util-tca : ONT memory utilization threshold crossed - pim-neighbor-down : pim neighbor down - pim-max-mcroutes : maximum routes reached - li-traffic-disabled : lawful interception of traffic disabled - li-bandwidth-limit : lawful intercept reached bandwidth limit - li-out-of-res : lawful intercept out of resources - otdr-cap-mismatch : otdr capability mismatch - login-successful : successful login via management access - login-failure : invalid login via management access has crossed the threshold limit - cfm-defrdiccm : rdi bit in ccm received - cfm-defmacstatus : ccm mac error status - cfm-defremoteccm : missing ccm from mep - cfm-deferrorccm : invalid ccm received - cfm-defxconccm : unexpected ccm received - cfm-defais : ethernet ais received - bfd-session-down : bfd session down - bfd-max-resource : bfd maximum resources reached - bfd-stale-entry : bfd stale entry present - tca-outputbw : tca output bandwidth - tca-inputbw : tca input bandwidth - tca-rxcrcalign : tca rxcrc align errors - tca-txcrcalign : tca txcrc align errors - tca-txcollisions : tca tx collision errors - tca-outputhighbw : tca output high bandwidth - tca-outputmedbw : tca output medium bandwidth - tca-outputlowbw : tca output low bandwidth - tca-inputhighbw : tca input high bandwidth - tca-inputmediumbw : tca input medium bandwidth - tca-inputlowbw : tca input low bandwidth	

name	Type	Description
	- eth-cfm-defrdiccm : rdi bit in ccm received - eth-cfm-defmacstatus : ccm mac error status - eth-cfm-defremoteccm : missing ccm from mep - eth-cfm-deferrorccm : invalid ccm received - eth-cfm-defxconccm : unexpected ccm received - rsvp-neighbor-down : rsvp neighbor down - rsvp-instance-down : rsvp instance down - eth-ring-path-block : eth ring path block - ai-platform-down : Application Intelligence Platform down - ai-appl-install-fail : Application installation failure - ip-assign-fail : Dhcp assigned address failure - ont-tr069-serv-mis : ont tr069 server config mismatch - ont-snmp-mis : ont snmp agent config mismatch - bsf-dhcpv4 : bulksync failed for dhcpv4 - bsf-dhcpv6 : bulksync failed for dhcpv6 - bsf-pon : bulksync failed for pon - bsf-vbridge : bulksync failed for vlan-bridge - bsf-qos : bulksync failed for qos - bsf-igmp : bulksync failed for igmp - bsf-lxfwd : bulksync failed for lxfwd - prot-not-available : no protection not available - prot-switchover-fail : port switch over failed - efm-oam-cpelinkfault : EFM-OAM CPE link fault - efm-oam-cpedyinggasp : EFM-OAM CPE dying gasp - efm-oam-cpecrevt : EFM-OAM CPE critical event - ont-loopdetect : ont loop detect - alarm-tbl-overflow : alarm table has overflowed - auto-switch-status : auto-switch status - auswqueuefullatm : auto-switch queue Full for ATM - auswbkpfailatm : auto-switch config data backup failed for ATM - auswrecfgfailatm : auto-switch fallback reconfiguration failed for ATM - auswdataunatm : auto-switch backup config data unavailable for ATM - auswqueuefulptm : auto-switch queue Full for PTM - auswbkpfailptm : auto-switch config data backup failed for PTM - auswrecfgfailptm : auto-switch fallback reconfiguration failed for PTM - auswdataunptm : auto-switch backup config data unavailable for PTM - auswbakpfailatm : auto-switch backup fail for ATM - chpr-com-fail : channel pair communication failure on olt - chpr-tx-fail : transmitter failure on channel pair - chpr-unprov-ont : unprovisioned ont on channel pair - chpr-prov-mismatch : mismatch btw equipment and provisioning pon attributes - chpr-loss-sig : channel pair loss of signal - chpr-diagnostic : channel pair diagnostic test active - chpr-loid-conflict : loid conflict ont on channel pair - chpr-loid-pwd-err : loid password error ont on channel pair - chpr-stk-laser-dis : stuck laser disabled on channel pair - chpr-sfp-mismatch : channel pair sfp mismatch - chpr-rng-mismatch : channel pair ranging mismatch - chpr-alien-test : channel pair alien diagnostic test active - chpr-alien-detect : channel pair alien detect active	

100 Alarm Delta Log Status Commands

name	Type	Description
	- chpr-deact-hightca : channel pair deactivated ont hightca threshold crossed - chpr-deact-lowtca : channel pair deactivated ont lowtca threshold crossed - chpr-dp-integ : channel pair data path integrity failure - olt-chpr-tc-err-frag : channelpair errored fragments threshold crossed - olt-chpr-up-bw-tca : OLT CHANNELPAIR upstream bandwidth TCA - olt-chpr-down-bw-tca : OLT CHANNELPAIR downstream bandwidth TCA - cfg-dld-fail : download of configure file to ont failed - cfg-act-fail : activate the passive config file failed - cfg-dld-ip : ont configure file download in progress - cfg-ver-mismatch : the planned configure file does not match the active configure file - cfg-file-missing : ont configure file missing or has an error - cfg-verctrl-err : ont configure file version control error - cfg-not-supported : ont not support the configure file download function - ont-prot-not-available: ONT/ONU protection not available - ont-gen-temp-low : ONU SFP temperature is lower than configured Alarm low threshold - ont-gen-volt-low : ONU SFP Voltage is lower than configured Alarm low threshold - ont-gen-tx-pwr-high : ONU SFP Tx power is higher than configured Alarm high threshold - ont-gen-bias-low : ONU SFP bias is lower than configured Alarm low threshold - ont-gen-rx-hwarn : ONU SFP Rx power is higher than warn threshold - ont-gen-rx-lwarn : ONU SFP Rx power is lower than warn threshold - ont-gen-tx-hwarn : ONU SFP Tx power is higher than warn threshold - ont-gen-tx-lwarn : ONU SFP Tx power is lower than warn threshold - ont-gen-temp-hwarn : ONU SFP temperature is higher than warn threshold - ont-gen-temp-lwarn : ONU SFP temperature is lower than warn threshold - ont-gen-volt-hwarn : ONU SFP Voltage is higher than warn threshold - ont-gen-volt-lwarn : ONU SFP Voltage is lower than warn threshold - ont-gen-bias-hwarn : ONU SFP bias is higher than warn threshold - ont-gen-bias-lwarn : ONU SFP bias is lower than warn threshold - sfu-sup2-temp-low : SFU ONT - SFP temperature is lower than configured Alarm low threshold - sfu-sup2-volt-low : SFU ONT - SFP Voltage is lower than configured Alarm low threshold - sfu-sup2-tx-high : SFU ONT - SFP tx power is higher than configured Alarm high threshold - sfu-sup2-bias-low : SFU ONT - SFP bias is lower than configured Alarm low threshold	

name	Type	Description
	- sfu-sup2-rx-hwarn : SFU ONT - SFP rx power is higher than configured warn threshold - sfu-sup2-rx-lwarn : SFU ONT - SFP rx power is lower than configured warn threshold - sfu-sup2-tx-hwarn : SFU ONT - SFP tx power is higher than configured warn threshold - sfu-sup2-tx-lwarn : SFU ONT - SFP tx power is lower than configured warn threshold - sfu-sup2-temp-hwarn : SFU ONT - SFP temperature is higher than configured warn threshold - sfu-sup2-temp-lwarn : SFU ONT - SFP temperature is lower than configured warn threshold - sfu-sup2-volt-hwarn : SFU ONT - SFP Voltage is higher than configured warn threshold - sfu-sup2-volt-lwarn : SFU ONT - SFP Voltage is lower than configured warn threshold - sfu-sup2-bias-hwarn : SFU ONT - SFP bias is higher than configured warn threshold - sfu-sup2-bias-lwarn : SFU ONT - SFP bias is lower than configured warn threshold - soho-sup2-temp-low : SOHO ONT - SFP temperature is lower than configured Alarm low threshold - soho-sup2-volt-low : SOHO ONT - SFP Voltage is lower than configured Alarm low threshold - soho-sup2-tx-high : SOHO ONT - SFP tx power is higher than configured Alarm low threshold - soho-sup2-bias-low : SOHO ONT - SFP bias is lower than configured Alarm low threshold - soho-sup2-rx-hwarn : SOHO ONT - SFP rx power is higher than warn threshold - soho-sup2-rx-lwarn : SOHO ONT - SFP rx power is lower than warn threshold - soho-sup2-tx-hwarn : SOHO ONT - SFP tx power is higher than warn threshold - soho-sup2-tx-lwarn : SOHO ONT - SFP tx power is lower than warn threshold - soho-sup2-temp-hwarn : SOHO ONT - SFP temperature is higher than warn threshold - soho-sup2-temp-lwarn : SOHO ONT - SFP temperature is lower than warn threshold - soho-sup2-volt-hwarn : SOHO ONT - SFP Voltage is higher than warn threshold - soho-sup2-volt-lwarn : SOHO ONT - SFP Voltage is lower than warn threshold - soho-sup2-bias-hwarn : SOHO ONT - SFP bias is higher than warn threshold - soho-sup2-bias-lwarn : SOHO ONT - SFP bias is lower than warn threshold - mdu-sup2-temp-low : MDU ONT - SFP temperature is lower than configured alarm low threshold - mdu-sup2-volt-low : MDU ONT - SFP Voltage is lower than configured alarm low threshold - mdu-sup2-tx-high : MDU ONT - SFP tx power is higher than configured alarm low threshold - mdu-sup2-bias-low : MDU ONT - SFP bias is lower than configured alarm low threshold - mdu-sup2-rx-hwarn : MDU ONT - SFP rx power is higher	

100 Alarm Delta Log Status Commands

name	Type	Description
	than warn threshold - mdu-sup2-rx-lwarn : MDU ONT - SFP rx power is lower than warn threshold - mdu-sup2-tx-hwarn : MDU ONT - SFP tx power is higher than warn threshold - mdu-sup2-tx-lwarn : MDU ONT - SFP tx power is lower than warn threshold - mdu-sup2-temp-hwarn : MDU ONT - SFP temperature is higher than warn threshold - mdu-sup2-temp-lwarn : MDU ONT - SFP temperature is lower than warn threshold - mdu-sup2-volt-hwarn : MDU ONT - SFP voltage is higher than warn threshold - mdu-sup2-volt-lwarn : MDU ONT - SFP voltage is lower than warn threshold - mdu-sup2-bias-hwarn : MDU ONT - SFP bias is higher than warn threshold - mdu-sup2-bias-lwarn : MDU ONT - SFP bias is lower than warn threshold - cust-alm1 : customizable alarm 1 - cust-alm2 : customizable alarm 2 - cust-alm3 : customizable alarm 3 - cust-alm4 : customizable alarm 4 - cust-alm5 : customizable alarm 5 - cust-alm6 : customizable alarm 6 - cust-alm7 : customizable alarm 7 - cust-alm8 : customizable alarm 8 - cust-alm9 : customizable alarm 9 - cust-alm10 : customizable alarm 10 - cust-alm11 : customizable alarm 11 - cust-alm12 : customizable alarm 12 - cust-alm13 : customizable alarm 13 - cust-alm14 : customizable alarm 14 - cust-alm15 : customizable alarm 15 - cust-alm16 : customizable alarm 16 - cust-alm17 : customizable alarm 17 - cust-alm18 : customizable alarm 18 - cust-alm19 : customizable alarm 19 - cust-alm20 : customizable alarm 20 - cust-alm21 : customizable alarm 21 - cust-alm22 : customizable alarm 22 - cust-alm23 : customizable alarm 23 - cust-alm24 : customizable alarm 24 - cust-alm25 : customizable alarm 25 - cust-alm26 : customizable alarm 26 - cust-alm27 : customizable alarm 27 - cust-alm28 : customizable alarm 28 - cust-alm29 : customizable alarm 29 - cust-alm30 : customizable alarm 30 - cust-alm31 : customizable alarm 31 - ethernet-ring-pthfwst : ethernet ring path forward state - ethernet-ring-fop-to : ethernet ring fop-to failure of protocol timeout - ethernet-ring-fop-pm : ethernet ring fop-pm failure of protocol provision mismatch - fpm-depletion : failsafe fpm depletion - exp-seizureack : Channel was blocked due to failure in the	

name	Type	Description
	reception of the SEIZURE ACK signal - exp-disconack : Channel was blocked due to failure in the reception of the DISCONNECTION ACK signal - exp-forcerelack : Channel was blocked due to failure in the reception of the BACKWARD DISCONNECTION ACK signal - packet-loss : Pseudo Wire entered the Packet loss state - remote-packet-loss : Remote Packet loss detected - no-dsp-resource : DSP resource allocation failed - la-down : Link aggregation group link-status is down - la-standby-na : Cross-lt lag on standby slot part is not available - la-switch-fail : Cross-lt lag fail to do switchover - la-degrade : Link aggregation group degrade - melt-board-reset : MELT board reset - board-shelf-mismatch : board type and shelf type mismatch - fcs-thresh-exceed : FCS counter threshold exceeded	
state	Parameter type: <Alarm::AlarmState> (active non-active) Possible values: - active : alarm is active - non-active : alarm is not active	reflect's the state of the alarm as either active or non-active. <i>This element is always shown.</i>
last-updated-on	Parameter type: <Sys::timeInSecs> - the time (yyyy-mm-dd:hour:minutes:secs) - unit: UTC	network time in seconds when the alarm was logged. <i>This element is always shown.</i>
additional-info	Parameter type: <Alarm::AdditionalInfo> - string to identify the owner (example: Tom) - length: x<=512	AdditionalInfo <i>This element is always shown.</i>

Only Show Details: indeterminate alarm table related generic information		
name	Type	Description
total-changes	Parameter type: <Counter> - 32 bit counter	total number of changes of all reported alarms with a severity level indeterminate since startup. <i>This element is only shown in detail mode.</i>
last-entry-id	Parameter type: <SignedInteger> - a signed integer	last entry that was added to the indeterminate delta log. <i>This element is only shown in detail mode.</i>
last-reset	Parameter type: <Sys::Time> - the time (yyyy-mm-dd:hour:minutes:secs) - unit: UTC	network time in seconds indicating when the indeterminate delta log was last reset. <i>This element is only shown in detail mode.</i>
log-overflowed	Parameter type: <Alarm::OverflowStatus> (yes no) Possible values: - yes : buffer has overflowed - no : no buffer overflow	specifies whether the indeterminate delta log is overflowed or not. <i>This element is only shown in detail mode.</i>

100.4 Warning Alarm Delta Log Status Command

Command Description

This command displays alarm values for all reported alarms with a severity level warning.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

> show alarm delta-log warning [(index)]

Command Parameters

Table 100.4-1 "Warning Alarm Delta Log Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	delta log alarm table index

Command Output

Table 100.4-2 "Warning Alarm Delta Log Status Command" Display parameters

Specific Information		
name	Type	Description
type	Parameter type: <Alarm::alarmIndexExt> (all xtca-ne-es xtca-ne-ses xtca-ne-uas xtca-ne-day-es xtca-ne-day-ses xtca-ne-day-uas xtca-fe-es xtca-fe-ses xtca-fe-uas xtca-fe-day-es xtca-fe-day-ses xtca-fe-day-uas xtca-leftrs xtca-day-leftrs xtca-fe-leftrs xtca-fe-day-leftrs xtca-auto-port-reset xtca-reinit	unique id for an alarm. <i>This element is always shown.</i>

name	Type	Description
	xtca-day-reinit	
	xdsl-ne-los	
	xdsl-ne-lof	
	xdsl-ne-lom	
	xdsl-ne-ese	
	xdsl-act-cfg-error	
	xdsl-act-not-feas	
	xdsl-up-br-reach	
	xdsl-ne-ncd	
	xdsl-ne-lcd	
	xdsl-fe-los	
	xdsl-fe-lof	
	xdsl-fe-lpr	
	xdsl-fe-lol	
	xdsl-fe-lom	
	xdsl-fe-ese	
	xdsl-fe-upbo-vio	
	xdsl-fe-cpe-pol	
	xdsl-tpstc-mis	
	xdsl-act-comm	
	xdsl-act-modem	
	xdsl-do-br-reach	
	xdsl-fe-ncd	
	xdsl-fe-lcd	
	xdsl-frtx-init-fail	
	xdsl-vect-dle	
	xdsl-fe-mis-peer-35b	
	vectline-xtc-var-vict	
	vectline-xtc-var-dist	
	vectline-corp-errf	
	vect-cpe-cap-mismatch	
	vectline-conf_notfeas	
	vect-vp-lt-mismatch	
	vect-inv-qsf	
	vect-vp-lt-fail	
	vect-no-gain-at-init	
	sw-rollback	
	db-rollback	
	xvps-inv-dbase	
	inv-cde-file	
	miss-cde-file	
	cde-hash-error	
	auto-fetch-failure	
	low-disk-space	
	cell-discard-up	
	cell-discard-down	
	persist-data-loss	
	mac-conflict	
	vmac-full	
	sntp-comm-lost	
	preferred-mode	
	timing-reference	
	nt-disk-95%full	
	shub-loc	
	cf-error	
	back-pnl-inv	
	ihub-conf-loss	

100 Alarm Delta Log Status Commands

name	Type	Description
	rack-power rack-fan-unit1 rack-fan-unit2 shelf-mismatch shelf-missing shelf-install-missing door ac-power-fail board-mismatch waiting-for-sw temp-exceeded backplane-data-failure temp-shutdown board-missing board-instl-missing board-init board-reset-prot sem-power-fail sem-ups-fail board-reset-cf vlan-assign-fail vsa-info-invalid auth-mac-conflict user-pwd-fault up-plan-bitrate up-min-bitrate up-config-not-feas down-plan-bitrate down-min-bitrate down-config-not-feas non-bonding-cpe multiple-cpes register group-incomplete host-sfp-los host-sfp-tx-fail host-sfp-not-prst host-sfp-inv-id host-sfp-ctrl-fail host-sfp-rmtlt host-sfp-mismatch host-sfp-incompt exp-sfp-los exp-sfp-tx-fail exp-sfp-not-prst exp-sfp-inv-id exp-sfp-ctrl-fail exp-sfp-1-los exp-sfp-2-los ext-qsfv-invld tx-power-high-alarm tx-power-low-alarm rx-power-high-alarm rx-power-low-alarm tx-biascur-high-alarm tx-biascur-low-alarm volt-high-alarm	

name	Type	Description
	volt-low-alarm temp-high-alarm temp-low-alarm tx-power-high-warn tx-power-low-warn rx-power-high-warn rx-power-low-warn tx-biascur-high-warn tx-biascur-low-warn volt-high-warn volt-low-warn temp-high-warn temp-low-warn onu-unprovisioned signal-loss bitrate-high opmodule-mismatch key-fail-one-churn key-fail-three-churn oam-discov-fail report-timeout total-packets-exceed arp-packets-exceed dhcp-packets-exceed igmp-packets-exceed pppoe-packets-exceed nd-packets-exceed icmpv6-packets-exceed mld-packets-exceed dhcpv6-packets-exceed cfm-packets-exceed dsx1-serdes-fail dsx1-tributary1-fail dsx1-tributary2-fail dsx1-los-fail dsx1-ais-sync dsx1-lof-sync dsx1-los-sync dsx1-deg-fail dsx1-rei-from-liu dsx1-rdi-from-liu dsx1-crc6-from-liu dsx1-crc4-from-liu dsx1-crc4-th-from-liu dsx1-ais-from-liu dsx1-los-from-liu dsx1-lof-from-liu dsx1-lomf-from-liu dsx1-rei-from-iwf dsx1-rdi-from-iwf dsx1-crc6-from-iwf dsx1-crc4-from-iwf dsx1-crc4-th-from-iwf dsx1-ais-from-iwf dsx1-los-from-iwf dsx1-lof-from-iwf dsx1-lomf-from-iwf	

100 Alarm Delta Log Status Commands

name	Type	Description
	pppce-trans-15min-tca pppce-sess-15min-tca pppce-trans-1day-tca pppce-sess-1day-tca custom1 custom2 custom3 custom4 custom5 he-custom1 he-custom2 he-custom3 he-custom4 he-custom5 he-custom6 custom6 custom7 custom8 custom9 custom10 custom11 custom12 custom13 custom14 custom15 custom16 custom17 loss-swo-cap ping-check-fail der-temp1 der-temp2 der-temp3 der-temp4 der-temp5 der-temp6 der-temp7 der-temp8 der-temp9 der-temp10 der-temp11 der-temp12 der-temp13 der-temp14 der-temp15 der-temp16 der-temp17 der-temp18 der-temp19 der-temp20 der-temp21 der-temp22 der-temp23 der-temp24 der-temp25 der-temp26 der-temp27 der-temp28	

name	Type	Description
	der-temp29	
	der-temp30	
	der-temp31	
	der-spa1	
	der-spa2	
	der-spa3	
	der-spa4	
	der-spa5	
	der-spa6	
	der-spa7	
	der-spa8	
	der-spa9	
	der-spa10	
	der-spa11	
	der-spa12	
	der-spa13	
	der-spa14	
	der-spa15	
	der-spa16	
	der-spa17	
	der-spa18	
	der-spa19	
	der-spa20	
	der-spa21	
	der-spa22	
	der-spa23	
	der-spa24	
	der-spa25	
	der-spa26	
	der-spa27	
	der-spa28	
	der-spa29	
	der-spa30	
	der-spa31	
	apsf-alarm	
	custextalarm1	
	custextalarm2	
	custextalarm3	
	custextalarm4	
	custextalarm5	
	pluginfan	
	plugin-dc-a	
	plugin-dc-b	
	plugin-dg	
	ntr-a-loss	
	ntr-b-loss	
	xvps-conf-loss	
	mac-entry-nofree	
	fibre-conn-mismatch	
	link-cap-mismatch	
	eqpt-cap-mismatch	
	ctrl-dnld-failure	
	melt-hw-issue	
	melt-board-reset	
	board-shelf-mismatch	
	mgnt-type-mismatch	
	fileserv-unavail	

100 Alarm Delta Log Status Commands

name	Type	Description
	shdsl-n-loopback	
	shdsl-c-loopback	
	shdsl-conferr	
	shdsl-atm-lcd	
	shdsl-lpr	
	shdsl-secu-err	
	shdsl-dev-fault	
	shdsl-atm-ncd	
	shdsl-n-losw	
	shdsl-c-losw	
	shdsl-n-aten	
	shdsl-c-aten	
	shdsl-n-snr	
	shdsl-c-snr	
	shdsl-n-dccont	
	shdsl-c-dccont	
	shdsl-c-actfail	
	e1-fe-rai	
	e1-ne-rai	
	e1-fe-ais	
	e1-ne-ais	
	e1-lof	
	e1-los	
	e1-loopback	
	ima-grp-fe-su	
	ima-grp-fe-cfg	
	ima-grp-ne-cfg	
	ima-grp-fe-nl	
	ima-grp-ne-nl	
	ima-grp-fe-blk	
	ima-lnk-lif	
	ima-lnk-lods	
	ima-lnk-misc	
	ima-lnk-rfi	
	ima-lnk-fault	
	ima-lnk-txblk	
	ima-lnk-rxblk	
	bad-digitmap	
	dhcp-unreach	
	dhcp-no-srv	
	dhcp-inv-srv	
	norpniewithsoftdsp	
	unknown-sub	
	ground-key	
	port-hightemp	
	port-jbfltca	
	reg-domainname	
	reg-auth	
	reg-timeout	
	reg-srvfailresp	
	inv-domainname	
	inv-auth	
	inv-timeout	
	inv-srvfailresp	
	subs-srvfailresp	
	subs-domainname	
	subs-auth	

name	Type	Description
	subs-refreshfail subs-inittimeout emergency-call e1sip-reg-domainname e1sip-reg-auth e1sip-reg-timeout e1sip-reg-srvfailresp e1sip-inv-domainname e1sip-inv-auth e1sip-inv-timeout e1sip-inv-srvfailresp e1sip-emergency-call e1l1tf-ais-signal e1l1tf-los-signal e1l1tf-rai-signal e1sip-misconfig-mgc10 e1sip-nsmprf-missed e1l1l1tf-recv-ais e1l1l1tf-recv-los e1l1l1tf-recv-rai transport-mismatch dns-lookup-failure none-dns-srv no-dns-srv none-srv no-srv reg-srv-unreach proxy-srv-unreach dhcp-srv-unreach fo-trigger fb-trigger du-trigger ssp-missing dns-pool-exceed lsa-fo-trigger reg-domainname-sec reg-auth-sec reg-timeout-sec reg-srvfailresp-sec inv-domainname-sec inv-auth-sec inv-timeout-sec inv-srvfailresp-sec subs-srvfailresp-sec subs-domainname-sec subs-auth-sec subs-refreshfail-sec subs-inittimeout-sec emergency-call-sec fanout up-overflow upobc-overflow dwobc-overflow dw-overflow lwpri-overflow queue-drop queue-load	

100 Alarm Delta Log Status Commands

name	Type	Description
	queue-peak-usage mgc-unreachable failover-to-esamgc sgc-unreachable lcard-unreach-srvcard lcard-type-mismatch meg-unknown-sub meg-ground-key meg-high-temp meg-act-fail meg-over-current line-showering low-qos-packetloss low-qos-jitter low-qos-delay sig-brd-persist-loss sig-brd-disk-full sig-brd-db-rollback mg-overload meg-unknown-sub-sec line-showering-sec loss-env-mon etca-los etca-fcs etca-day-los etca-day-fcs etca-rx-octets etca-tx-octets etca-day-rx-octets etca-day-tx-octets user-sfp-los user-sfp-tx-fail user-sfp-not-prst user-sfp-inv-id user-sfp-t-exceed user-sfp-mismatch uplink-sfp-los uplink-sfp-tx-fail uplink-sfp-not-prst uplink-sfp-inv-id uplink-sfp-t-exceed uplink-sfp-mismatch loss-lmswp-cap inv-xvps-pair-data network-power-loss hw-fault bat-miss bat-fail bat-low bat-a-fail bat-b-fail ac-vol-out-range network-power-loss-b sem-ac-power-fail sem-ups-low-volt dc-a-fail dc-b-fail	

name	Type	Description
	plan-power-mismatch water-seepage-in-box sealed-box-open dc-a-vol-out-range dc-b-vol-out-range inlet-temp-major inlet-temp-critical psu-fail-crit psu-a-fail-presence psu-a-fail-vin-ac-nok psu-a-fail-vin-uv psu-a-fail-vin-ov psu-a-fail-vout-uv psu-a-fail-vout-ov psu-a-fail-iout-oc psu-a-fail-overtemp psu-b-fail-presence psu-b-fail-vin-ac-nok psu-b-fail-vin-uv psu-b-fail-vin-ov psu-b-fail-vout-uv psu-b-fail-vout-ov psu-b-fail-iout-oc psu-b-fail-overtemp synce-fail bits-fail bits-output-shutoff ieee1588-fail gnss-fail ieee1588-hybrid-fail signal-loss signal-efd esmc-loss bits-output-exceed ql-input-exceed holdover lti tod-reference-fail internal-clk-fail bgp-peer-down bgp-routes-mid-limit isis-adjacency-down isis-adjacency-reject isis-instance-down ospf-lsa-limit ospf-lsa-mid-limit ospf-neighbor-down ospf-instance-down ospf3-lsa-limit ospf3-lsa-mid-limit ospf3-neighbor-down ospf3-instance-down rip-instance-down lag-down lagsubgrp-thresh-reach lagsubgrp-switch-fail no-unpinned-free-ports	

100 Alarm Delta Log Status Commands

name	Type	Description
	general-arp-limit gen-switch-out-of-res ipv6-nc-limit dhcp-session-oor ihub-fdb-limit ihub-mac-limit l2fw-stp-exception l2fw-stp-root-guard vprn-routes-limit vprn-ipv6-routes-limit dhcpv6-lease-limit dhcpv4-lease-limit vpls-mfib-limit ihub-ipv6-dad-own ihub-ipv6-dad ihub-ipv6-dup-pd-route vpls-duplicate-mac vpls-fdb-limit vpls-self-duplic-mac vpls-sdp-self-dup-mac link-down link-lagport-add-fail link-conf-mismatch ihub-peer-comm ihub-sw-fail ihub-hw-fail ihub-link-fail ihub-proc-overload ihub-out-of-mem ntp-comm-lost ldp-instance-down ldp-session-down mpls-instance-down mpls-lsp-down mpls-lsp-path-down sdp-instance-down sdp-binding-down epipe-instance-down lldpmed-portcfg-mis lldpmed-mediapl-mis vlanport-svc-mismatch mcsrc-stream-lost eqptsupl-syslog-upload eqptsupl-ontsw-dnload cf-75%used cf-90%used olt-gen-pon-com-fail olt-gen-tx-fail olt-gen-unprov-ont olt-gen-pon-eqpt-prov olt-gen-pon-loss-sig olt-gen-pon-diagnostic olt-gen-lold-conflict olt-gen-lold-pwderr olt-gen-pon-alien-test olt-gen-alien-detect olt-gen-rng-mism	

name	Type	Description
	olt-gen-sfp-mism	
	olt-gen-deact-hightca	
	olt-gen-deact-lowtca	
	olt-gen-dp-integ	
	olt-gen-ddr-fault	
	olt-pon-tc-err-frag-tc	
	olt-ont-tc-err-frag-tc	
	ont-ploam-loss-sig	
	ont-ploam-loss-ack	
	ont-ploam-loss-cd	
	ont-ploam-phy-eqpt-err	
	ont-ploam-startup-fail	
	ont-ploam-sig-degrade	
	ont-ploam-disabled	
	ont-ploam-err-msg	
	ont-ploam-inactive	
	ont-ploam-sig-fail	
	ont-ploam-dying-gasp	
	ont-ploam-deact-fail	
	ont-ploam-oam	
	ont-ploam-win-drift	
	ont-ploam-rdi	
	ont-ploam-loss-ks	
	ont-ploam-pwr-burst	
	ont-ploam-rog-disa	
	ont-ploam-diff-reach	
	ont-ploam-looc	
	sfu-ploam-loss-sig	
	sfu-ploam-loss-ack	
	sfu-ploam-loss-cd	
	sfu-ploam-phy-eqpt-err	
	sfu-ploam-startup-fail	
	sfu-ploam-sig-degrade	
	sfu-ploam-disabled	
	sfu-ploam-err-msg	
	sfu-ploam-inactive	
	sfu-ploam-sig-fail	
	sfu-ploam-dying-gasp	
	sfu-ploam-deact-fail	
	sfu-ploam-oam	
	sfu-ploam-win-drift	
	sfu-ploam-rdi	
	sfu-ploam-loss-ks	
	sfu-ploam-pwr-burst	
	sfu-ploam-rog-disa	
	sfu-ploam-diff-reach	
	sfu-ploam-looc	
	soho-ploam-loss-sig	
	soho-ploam-loss-ack	
	soho-ploam-loss-cd	
	soho-ploam-phy-eqpt-er	
	soho-ploam-startup-fai	
	soho-ploam-sig-degrade	
	soho-ploam-disabled	
	soho-ploam-err-msg	
	soho-ploam-inactive	
	soho-ploam-sig-fail	

100 Alarm Delta Log Status Commands

name	Type	Description
	soho-ploam-dying-gasp	
	soho-ploam-deact-fail	
	soho-ploam-oam	
	soho-ploam-win-drift	
	soho-ploam-rdi	
	soho-ploam-loss-ks	
	soho-ploam-pwr-burst	
	soho-ploam-roq-disa	
	soho-ploam-diff-reach	
	soho-ploam-looc	
	mdu-ploam-loss-sig	
	mdu-ploam-loss-ack	
	mdu-ploam-loss-cd	
	mdu-ploam-phy-eqpt-err	
	mdu-ploam-startup-fail	
	mdu-ploam-sig-degrade	
	mdu-ploam-disabled	
	mdu-ploam-err-msg	
	mdu-ploam-inactive	
	mdu-ploam-sig-fail	
	mdu-ploam-dying-gasp	
	mdu-ploam-deact-fail	
	mdu-ploam-oam	
	mdu-ploam-win-drift	
	mdu-ploam-rdi	
	mdu-ploam-loss-ks	
	mdu-ploam-pwr-burst	
	mdu-ploam-roq-disa	
	mdu-ploam-diff-reach	
	mdu-ploam-looc	
	ont-hpna-ser-mis	
	ont-hpna-los-sig	
	ont-moca-svc-mis	
	ont-moca-link-los	
	ont-moca-min-bw	
	ont-moca-tca-rx-err-fr	
	ont-sipa-reg-nm-fail	
	ont-sipa-reg-rec-fail	
	ont-sipa-reg-con-fail	
	ont-sipa-reg-val-fail	
	ont-sipa-reg-mis	
	ont-vcd-cfg-nm-fail	
	ont-vcd-cfg-rech-fail	
	ont-vcd-cfg-conn-fail	
	ont-vcd-cfg-vali-fail	
	ont-vcd-cfg-auth-fail	
	ont-vcd-cfg-resp-tmout	
	ont-vcd-cfg-resp-err	
	ont-vcd-cfg-file-err	
	ont-vcd-sub-nm-fail	
	ont-vcd-sub-rech-fail	
	ont-vcd-sub-conn-fail	
	ont-vcd-sub-vali-fail	
	ont-vcd-sub-auth-fail	
	ont-vcd-sub-resp-tmout	
	ont-vcd-sub-resp-err	
	ont-vcd-reb-requ	

name	Type	Description
	ont-vcd-mis	
	ont-mgc-mis	
	ont-mgc-timeout	
	ont-sip-reg-dns	
	ont-sip-reg-fail	
	ont-sip-reg-timeout	
	ont-sip-reg-err-resps	
	ont-sip-inv-dns	
	ont-sip-inv-auth	
	ont-sip-inv-timeout	
	ont-sip-inv-err	
	ont-svc-pots-subs-refr	
	ont-svc-pots-not-refr	
	ont-svc-pots-icfg-err	
	ont-veip-mismatch	
	ont-ip-host-mismatch	
	ont-ip-host-file	
	ont-ip-host-ip-alloc	
	olt-pon-up-bw-tca	
	olt-pon-down-bw-tca	
	ont-gen-omci-fail	
	ont-gen-eqpt-selftest	
	ont-gen-ac-pwr-fail	
	ont-gen-bat-missing	
	ont-gen-bat-low	
	ont-gen-bat-fail	
	ont-gen-phys-intrusion	
	ont-gen-sw-dnload-f	
	ont-gen-sw-dnload-p	
	ont-gen-sw-act-fail	
	ont-gen-eqpt-vers-mis	
	ont-gen-sw-vers-mis	
	ont-gen-us-rate-mis	
	ont-gen-mdu-env1	
	ont-gen-mdu-env2	
	ont-gen-mdu-env3	
	ont-gen-nw-time-err	
	ont-gen-opt-sig-high	
	ont-gen-opt-sig-low	
	ont-gen-eqpt-prov-sa	
	ont-gen-eqpt-prov-nsa	
	pon-t-txmcutilhi	
	pon-t-txmcutilmd	
	pon-t-txmcutillo	
	pon-t-txtotutilhi	
	pon-t-txtotutilmd	
	pon-t-txtotutillo	
	pon-t-rxtotutilhi	
	pon-t-rxtotutilmd	
	pon-t-rxtotutillo	
	pon-t-dbacongperiodhi	
	pon-t-dbacongperiodmd	
	pon-t-dbacongperiodlo	
	pon-t-txucdropfrmhi	
	pon-t-txucdropfrmd	
	pon-t-txucdropfrmlo	
	pon-t-txmcdropfrmhi	

100 Alarm Delta Log Status Commands

name	Type	Description
	pon-t-txmcdropfrmmd	
	pon-t-txmcdropfrmlo	
	pon-t-txbcdropfrmhi	
	pon-t-txbcdropfrmmd	
	pon-t-txbcdropfrmlo	
	pon-t-rxtotdropfrmhi	
	pon-t-rxtotdropfrmmd	
	pon-t-rxtotdropfrmlo	
	chpr-t-txmcutilhi	
	chpr-t-txmcutilmd	
	chpr-t-txmcutillo	
	chpr-t-txtotutilhi	
	chpr-t-txtotutilmd	
	chpr-t-txtotutillo	
	chpr-t-rxtotutilhi	
	chpr-t-rxtotutilmd	
	chpr-t-rxtotutillo	
	chpr-t-dbacongperiodhi	
	chpr-t-dbacongperiodmd	
	chpr-t-dbacongperiodlo	
	chpr-t-txucdropfrmhi	
	chpr-t-txucdropfrmmd	
	chpr-t-txucdropfrmlo	
	chpr-t-txmcdropfrmhi	
	chpr-t-txmcdropfrmmd	
	chpr-t-txmcdropfrmlo	
	chpr-t-txbcdropfrmhi	
	chpr-t-txbcdropfrmmd	
	chpr-t-txbcdropfrmlo	
	chpr-t-rxtotdropfrmhi	
	chpr-t-rxtotdropfrmmd	
	chpr-t-rxtotdropfrmlo	
	sfu-gen-omci-fail	
	sfu-gen-eqpt-selftest	
	sfu-gen-ac-pwr-fail	
	sfu-gen-bat-missing	
	sfu-gen-bat-low	
	sfu-gen-bat-fail	
	sfu-gen-sw-dnload-f	
	sfu-gen-sw-dnload-p	
	sfu-gen-sw-act-fail	
	sfu-gen-eqpt-vers-mis	
	sfu-gen-sw-vers-mis	
	sfu-gen-us-rate-mis	
	sfu-gen-tune-fail	
	sfu-gen-nw-time-err	
	sfu-gen-opt-sig-high	
	sfu-gen-opt-sig-low	
	sfu-gen-eqpt-prov-sa	
	sfu-gen-eqpt-prov-nsa	
	soho-gen-omci-fail	
	soho-gen-eqpt-selftest	
	soho-gen-ac-pwr-fail	
	soho-gen-bat-missing	
	soho-gen-bat-low	
	soho-gen-bat-fail	
	soho-gen-sw-dnload-f	

name	Type	Description
	soho-gen-sw-dnload-p	
	soho-gen-sw-act-fail	
	soho-gen-eqpt-vers-mis	
	soho-gen-sw-vers-mis	
	soho-gen-us-rate-mis	
	soho-gen-tune-fail	
	soho-gen-nw-time-err	
	soho-gen-opt-sig-high	
	soho-gen-opt-sig-low	
	soho-gen-eqpt-prov-sa	
	soho-gen-eqpt-prov-nsa	
	mdu-gen-omci-fail	
	mdu-gen-eqpt-selftest	
	mdu-gen-ac-pwr-fail	
	mdu-gen-bat-missing	
	mdu-gen-bat-low	
	mdu-gen-bat-fail	
	mdu-gen-phys-intrusion	
	mdu-gen-sw-dnload-f	
	mdu-gen-sw-dnload-p	
	mdu-gen-sw-act-fail	
	mdu-gen-eqpt-vers-mis	
	mdu-gen-sw-vers-mis	
	mdu-gen-us-rate-mis	
	mdu-gen-tune-fail	
	mdu-gen-mdu-env1	
	mdu-gen-mdu-env2	
	mdu-gen-mdu-env3	
	mdu-gen-nw-time-err	
	mdu-gen-opt-sig-high	
	mdu-gen-opt-sig-low	
	mdu-gen-eqpt-prov-sa	
	mdu-gen-eqpt-prov-nsa	
	ont-gen-sw-dnload-file	
	ont-gen-fan-fail	
	ont-gen-high-temp	
	ont-gen-high-temp-ex	
	ont-gen-emergency-call	
	ont-gen-sw-version	
	ont-poe-exceed-max	
	ont-poe-overload-yell	
	ont-opti-malfunc	
	ont-gen-cfgdld-fail	
	ont-gen-rssi-mis	
	ont-gen-tx-pwr-low	
	ont-gen-temp-high	
	ont-gen-volt-high	
	ont-gen-bias-high	
	ont-loopdetect-mis	
	ont-olt-rx-pw-lo	
	ont-olt-rx-pw-hig	
	ont-olt-rx-pw-warnlo	
	ont-olt-rx-pw-warnhig	
	ont-gen-tod-out-sync	
	ont-gen-tune-fail	
	hgu-tr069-param-fail	
	ont-gen-tod-mismatch	

100 Alarm Delta Log Status Commands

name	Type	Description
	sfu-sup-sw-file-error	
	sfu-sup-fan-failure	
	sfu-sup-temp-high-warn	
	sfu-sup-temp-shutoff	
	sfu-sup-emergency-call	
	sfu-sup-swverctrl-err	
	sfu-sup-poe-exceed-max	
	sfu-sup-poe-over-yell	
	sfu-opti-malfunc	
	sfu-sup-cfg-dnld-fail	
	sfu-sup-rssi-cfg-mism	
	sfu-sup-sfp-tx-low	
	sfu-sup-sfp-temp-high	
	sfu-sup-sfp-volt-high	
	sfu-sup-sfp-bias-high	
	sfu-sup-ld-cfg-mism	
	sfu-sup-olt-rx-low	
	sfu-sup-olt-rx-high	
	sfu-sup-olt-rx-lo-warn	
	sfu-sup-olt-rx-hi-warn	
	sfu-sup-tod-out-sync	
	sfu-sup-ont-tune-fail	
	sfu-tr069-parm-fail	
	sfu-sup-tod-mismatch	
	soho-sup-sw-file-error	
	soho-sup-fan-failure	
	soho-sup-temp-high-war	
	soho-sup-temp-shutoff	
	soho-sup-emergency-cal	
	soho-sup-swverctrl-err	
	soho-sup-poe-exceed-ma	
	soho-sup-poe-over-yell	
	soho-opti-malfunc	
	soho-sup-cfg-dnld-fail	
	soho-sup-rssi-cfg-mism	
	soho-sup-sfp-tx-low	
	soho-sup-sfp-temp-high	
	soho-sup-sfp-volt-high	
	soho-sup-sfp-bias-high	
	soho-sup-ld-cfg-mism	
	soho-sup-olt-rx-low	
	soho-sup-olt-rx-high	
	soho-sup-olt-rx-lo-war	
	soho-sup-olt-rx-hi-war	
	soho-sup-tod-out-sync	
	soho-sup-ont-tune-fail	
	soho-tr069-parm-fail	
	soho-sup-tod-mismatch	
	mdu-sup-sw-file-error	
	mdu-sup-fan-failure	
	mdu-sup-temp-high-warn	
	mdu-sup-temp-shutoff	
	mdu-sup-emergency-call	
	mdu-sup-swverctrl-err	
	mdu-sup-poe-exceed-max	
	mdu-sup-poe-over-yell	
	mdu-opti-malfunc	

name	Type	Description
	mdu-sup-cfg-dnld-fail mdu-sup-rssi-cfg-mism mdu-sup-sfp-tx-low mdu-sup-sfp-temp-high mdu-sup-sfp-volt-high mdu-sup-sfp-bias-high mdu-sup-ld-cfg-mism mdu-sup-olt-rx-low mdu-sup-olt-rx-high mdu-sup-olt-rx-lo-warn mdu-sup-olt-rx-hi-warn mdu-sup-tod-out-sync mdu-sup-ont-tune-fail mdu-tr069-param-fail mdu-sup-tod-mismatch ont-sbscr-lim-missing ont-sbscr-lim-type-mis ont-sbscr-lim-removal ont-sbscr-lim-fail ont-sbscr-lim-svc-mis ont-sbscr-lim-port-mis ont-svc-video-conf-mis ont-svc-video-pw-high ont-svc-video-pw-low ont-svc-pots-svc-mis ont-svc-pots-rtcp-lost ont-svc-pots-icnf-subs ont-svc-pots-icnf-ntfy ont-svc-pots-icnf-http ont-svc-pots-sip-reg ont-svc-pots-sip-inv ont-svc-pots-sip-subsc ont-svc-pots-sip-mt-tc ont-svc-pots-pk-los-tc ont-svc-pots-jitter-tc ont-svc-pots-subs-dns ont-svc-pots-subs-tcp ont-svc-pots-subs-tls ont-svc-pots-subs-auth ont-svc-pots-subs-to ont-svc-pots-subs-err ont-svc-pots-not-to ont-svc-pots-notref-to ont-svc-pots-not-mal ont-svc-pots-not-rej ont-svc-pots-http-dns ont-svc-pots-http-tcp ont-svc-pots-http-tls ont-svc-pots-http-auth ont-svc-pots-http-to ont-svc-pots-http-err ont-svc-pots-http-mal ont-svc-pots-insuff ont-svc-pots-poos ont-svc-lan-mismatch ont-svc-lan-loss-sig ont-svc-enet-poos	

100 Alarm Delta Log Status Commands

name	Type	Description
	ont-svc-ces-ds1-mis	
	ont-svc-ces-ds1-los	
	ont-svc-ces-ds1-lof	
	ont-svc-ces-ds1-rair	
	ont-svc-ces-ds1-ais	
	ont-svc-ces-ds1-lnlpbk	
	ont-svc-ces-ds1-tmlpbk	
	ont-svc-ces-e1-mis	
	ont-svc-ces-e1-los	
	ont-svc-ces-e1-lof	
	ont-svc-ces-e1-rair	
	ont-svc-ces-e1-ais	
	ont-svc-voip-cnf-file	
	ont-svc-voip-svc-mis	
	ont-svc-voip-gw-comm	
	ont-svc-voip-dhcp-fail	
	ont-svc-voip-icnf-sub	
	ont-svc-voip-icnf-ntfy	
	ont-svc-voip-icnf-http	
	ont-svc-voip-dhcp-to	
	ont-svc-voip-dhcp-mal	
	ont-svc-voip-dhcp-noad	
	ont-svc-voip-dhcp-leas	
	ont-svc-voip-sub-dns	
	ont-svc-voip-sub-tcp	
	ont-svc-voip-sub-tls	
	ont-svc-voip-sub-auth	
	ont-svc-voip-sub-to	
	ont-svc-voip-sub-err	
	ont-svc-voip-not-to	
	ont-svc-voip-notref-to	
	ont-svc-voip-not-mal	
	ont-svc-voip-not-rej	
	ont-svc-voip-http-dns	
	ont-svc-voip-http-tcp	
	ont-svc-voip-http-tls	
	ont-svc-voip-http-auth	
	ont-svc-voip-http-to	
	ont-svc-voip-http-err	
	ont-svc-voip-http-mal	
	ont-svc-voip-sub-refr	
	ont-svc-voip-not-refr	
	ont-svc-voip-icfg-err	
	ont-svc-v-ani-conf-mis	
	ont-svc-v-ani-loss-sig	
	ont-svc-v-ani-lv-high	
	ont-svc-v-ani-lv-low	
	ont-svc-pwe-mismatch	
	ont-svc-pwe-reordr-lof	
	ont-svc-pwe-jitt-buf-o	
	ont-svc-pwe-jitt-buf-u	
	ont-svc-pwe-malf-frms	
	ont-svc-pwe-late-frms	
	ont-svc-pwe-link-loss	
	ont-svc-pwe-arp-fail	
	ont-svc-xdsl-mismatch	
	ont-svc-xdsl-ne-lof	

name	Type	Description
	ont-svc-xdsl-ne-los ont-svc-xdsl-ne-line ont-svc-xdsl-ne-lol ont-svc-xdsl-fe-lof ont-svc-xdsl-fe-los ont-svc-xdsl-fe-lop ont-svc-xdsl-cnf-err ont-svc-xdsl-ne-es-tc ont-svc-xdsl-ne-ses-tc ont-svc-xdsl-ne-uas-tc ont-svc-xdsl-fe-es-tc ont-svc-xdsl-fe-ses-tc ont-svc-xdsl-fe-uas-tc ont-tc-rx-los-frag-tc ont-tc-tx-los-frag-tc ont-tc-bad-gem-hd-tc ont-uni-ds-drp-d-fr-tc ont-uni-up-drp-d-fr-tc ont-uni-ds-crc-fr-tc ont-uni-up-crc-fr-tc ont-cpu-util-tca ont-mem-util-tca pim-neighbor-down pim-max-mcroutes li-traffic-disabled li-bandwidth-limit li-out-of-res otdr-cap-mismatch login-successful login-failure cfm-defrdiccm cfm-defmacstatus cfm-defremoteccm cfm-deferrorccm cfm-defxconccm cfm-defais bfd-session-down bfd-max-resource bfd-stale-entry tca-outputbw tca-inputbw tca-rxcrcalign tca-txcrcalign tca-txcollisions tca-outputhighbw tca-outputmedbw tca-outputlowbw tca-inputhighbw tca-inputmediumbw tca-inputlowbw eth-cfm-defrdiccm eth-cfm-defmacstatus eth-cfm-defremoteccm eth-cfm-deferrorccm eth-cfm-defxconccm rsvp-neighbor-down rsvp-instance-down	

100 Alarm Delta Log Status Commands

name	Type	Description
	eth-ring-path-block	
	ai-platform-down	
	ai-appl-install-fail	
	ip-assign-fail	
	ont-tr069-serv-mis	
	ont-snmp-mis	
	bsf-dhcpv4	
	bsf-dhcpv6	
	bsf-pon	
	bsf-vbridge	
	bsf-qos	
	bsf-igmp	
	bsf-lxfwd	
	prot-not-available	
	prot-switchover-fail	
	efm-oam-cpelinkfault	
	efm-oam-cpedyinggasp	
	efm-oam-cpecrevt	
	ont-loopdetect	
	alarm-tbl-overflow	
	auto-switch-status	
	auswqueuefullatm	
	auswbkpfailatm	
	auswrecfgfailatm	
	auswdataunatm	
	auswqueuefulptm	
	auswbkpfailptm	
	auswrecfgfailptm	
	auswdataunptm	
	auswbakpfailatm	
	chpr-com-fail	
	chpr-tx-fail	
	chpr-unprov-ont	
	chpr-prov-mismatch	
	chpr-loss-sig	
	chpr-diagnostic	
	chpr-loid-conflict	
	chpr-loid-pwd-err	
	chpr-stk-laser-dis	
	chpr-sfp-mismatch	
	chpr-rng-mismatch	
	chpr-alien-test	
	chpr-alien-detect	
	chpr-deact-hightca	
	chpr-deact-lowtca	
	chpr-dp-integ	
	olt-chpr-tc-err-frag	
	olt-chpr-up-bw-tca	
	olt-chpr-down-bw-tca	
	cfg-dld-fail	
	cfg-act-fail	
	cfg-dld-ip	
	cfg-ver-mismatch	
	cfg-file-missing	
	cfg-verctrl-err	
	cfg-not-supported	
	ont-prot-not-available	

name	Type	Description
	ont-gen-temp-low	
	ont-gen-volt-low	
	ont-gen-tx-pwr-high	
	ont-gen-bias-low	
	ont-gen-rx-hwarn	
	ont-gen-rx-lwarn	
	ont-gen-tx-hwarn	
	ont-gen-tx-lwarn	
	ont-gen-temp-hwarn	
	ont-gen-temp-lwarn	
	ont-gen-volt-hwarn	
	ont-gen-volt-lwarn	
	ont-gen-bias-hwarn	
	ont-gen-bias-lwarn	
	sfu-sup2-temp-low	
	sfu-sup2-volt-low	
	sfu-sup2-tx-high	
	sfu-sup2-bias-low	
	sfu-sup2-rx-hwarn	
	sfu-sup2-rx-lwarn	
	sfu-sup2-tx-hwarn	
	sfu-sup2-tx-lwarn	
	sfu-sup2-temp-hwarn	
	sfu-sup2-temp-lwarn	
	sfu-sup2-volt-hwarn	
	sfu-sup2-volt-lwarn	
	sfu-sup2-bias-hwarn	
	sfu-sup2-bias-lwarn	
	soho-sup2-temp-low	
	soho-sup2-volt-low	
	soho-sup2-tx-high	
	soho-sup2-bias-low	
	soho-sup2-rx-hwarn	
	soho-sup2-rx-lwarn	
	soho-sup2-tx-hwarn	
	soho-sup2-tx-lwarn	
	soho-sup2-temp-hwarn	
	soho-sup2-temp-lwarn	
	soho-sup2-volt-hwarn	
	soho-sup2-volt-lwarn	
	soho-sup2-bias-hwarn	
	soho-sup2-bias-lwarn	
	mdu-sup2-temp-low	
	mdu-sup2-volt-low	
	mdu-sup2-tx-high	
	mdu-sup2-bias-low	
	mdu-sup2-rx-hwarn	
	mdu-sup2-rx-lwarn	
	mdu-sup2-tx-hwarn	
	mdu-sup2-tx-lwarn	
	mdu-sup2-temp-hwarn	
	mdu-sup2-temp-lwarn	
	mdu-sup2-volt-hwarn	
	mdu-sup2-volt-lwarn	
	mdu-sup2-bias-hwarn	
	mdu-sup2-bias-lwarn	
	cust-alm1	

100 Alarm Delta Log Status Commands

name	Type	Description
	cust-alm2 cust-alm3 cust-alm4 cust-alm5 cust-alm6 cust-alm7 cust-alm8 cust-alm9 cust-alm10 cust-alm11 cust-alm12 cust-alm13 cust-alm14 cust-alm15 cust-alm16 cust-alm17 cust-alm18 cust-alm19 cust-alm20 cust-alm21 cust-alm22 cust-alm23 cust-alm24 cust-alm25 cust-alm26 cust-alm27 cust-alm28 cust-alm29 cust-alm30 cust-alm31 ethernet-ring-pthfwst ethernet-ring-fop-to ethernet-ring-fop-pm fpm-depletion exp-seizureack exp-disconack exp-forcerelack packet-loss remote-packet-loss no-dsp-resource la-down la-standby-na la-switch-fail la-degrade melt-board-reset board-shelf-mismatch fcs-thresh-exceed) Possible values: - all : all alarms for query - xtca-ne-es : errored seconds in 15 min - xtca-ne-ses : severely errored seconds in 15 min - xtca-ne-uas : unavailable seconds in 15 min - xtca-ne-day-es : errored seconds in 1 day - xtca-ne-day-ses : severely errored seconds in 1 day - xtca-ne-day-uas : unavailable seconds in 1 day - xtca-fe-es : errored seconds in 15 min - xtca-fe-ses : severely errored secs in 15 min	

name	Type	Description
	- xtca-fe-uas : unavailable seconds in 15 min - xtca-fe-day-es : errored seconds in 1 day - xtca-fe-day-ses : severely errored secs in 1 day - xtca-fe-day-uas : unavailable seconds in 1 day - xtca-leftrs : low error free throughput seconds in 15 min - xtca-day-leftrs : low error free throughput seconds in 1 day - xtca-fe-leftrs : far end low error free throughput seconds in 15 min - xtca-fe-day-leftrs : far end low error free throughput seconds in 1 day - xtca-auto-port-reset : auto-port-resets in 1 week - xtca-reinit : Reinitialization seconds in 15 min - xtca-day-reinit : Reinitialization seconds in 1 day - xdsl-ne-los : loss of signal - xdsl-ne-lof : loss of frame - xdsl-ne-lom : loss of margin - xdsl-ne-ese : excessive severe errors - xdsl-act-cfg-error : line configuration data cannot be used - xdsl-act-not-feas : line capacity not enough to setup requested profile - xdsl-up-br-reach : planned bitrate not reached after initialization - xdsl-ne-ncd : no cell delineation - xdsl-ne-lcd : loss of cell delineation - xdsl-fe-los : loss of signal - xdsl-fe-lof : loss of frame - xdsl-fe-lpr : loss of power - xdsl-fe-lol : loss of link - xdsl-fe-lom : loss of margin - xdsl-fe-ese : excessive severe errors - xdsl-fe-upbo-vio : upbo violation - xdsl-fe-cpe-pol : activation failure cpe policing - xdsl-tpstc-mis : mismatch between the configured tps-tc mode and the mode supported by the connected cpe - xdsl-act-comm : init not successful due to communications problem - xdsl-act-modem : no peer modem detected - xdsl-do-br-reach : planned bitrate not reached after init - xdsl-fe-ncd : no cell delineation - xdsl-fe-lcd : loss of cell delineation - xdsl-ftrx-init-fail : init not successful due to forced rtx - xdsl-vect-dle : vectoring disorderly leaving event - xdsl-fe-mis-peer-35b : VDSL2 35b opmode mismatch between XTU-C and XTU-R - vectline-xtc-var-vict : excessive victim crosstalk coefficients variation - vectline-xtc-var-dist : excessive disturber crosstalk coefficients variation - vectline-corp-errf : corrupted or missing errorf-samples - vect-cpe-cap-mismatch : not allowed Vectoring CPE connected - vectline-conf_notfeas : vect line configuration not feasible - vect-vp-lt-mismatch : actual vp-lt connection(s) do not match expected vp-lt connection(s) or vp-lt connection lost - vect-inv-qsf : qsf has no valid Nokia ID - vect-vp-lt-fail : vp-lt connection not operational - vect-no-gain-at-init : Lines cannot train in gain-at-init	

100 Alarm Delta Log Status Commands

name	Type	Description
	mode - sw-rollback : non active oswp,db cannot be operational - will rollback - db-rollback : selected oswp,db cannot be operational - will rollback - xvps-inv-dbase : invalid xvps dbase - inv-cde-file : invalid xvps cde file - miss-cde-file : missing cde profile - cde-hash-error : cde profile hash error - auto-fetch-failure : not able to fetch file from specified server - low-disk-space : insufficient space for Sw storage - cell-discard-up : cell discarded in the upstream direction - cell-discard-down : cell discarded in the downstream direction - persist-data-loss : all data lost after restart - system not configured - mac-conflict : duplicate mac address on the bridge port - vmac-full : virtual mac address is full on the bridge port - sntp-comm-lost : sntp server not responding - preferred-mode : preferred mode not available - timing-reference : timing reference failure - nt-disk-95%full : nt disk 95% full - shub-loc : communication lost with shub - cf-error : compact flash access error - back-pnl-inv : BackPanel-type Invalid - ihub-conf-loss : iHub configuration loss - recent changes lost - rack-power : power fuse broken - rack-fan-unit1 : fan unit rack 1 failing - rack-fan-unit2 : fan unit rack 2 failing - shelf-mismatch : shelf type different from planned type - shelf-missing : detected shelf no longer detected - shelf-install-missing : shelf planned but not installed - door : open cabinet door - ac-power-fail : external power failure - shelf shutdown in 15 minutes - board-mismatch : board inserted different from planned - waiting-for-sw : not able to download all the applicable sw files - temp-exceeded : temperature threshold exceeded on the board - backplane-data-failure: It port on backplane data failure - temp-shutdown : board powered down itself - too high temperature - board-missing : board detected after planning - now missing - board-instl-missing : board never detected after planning - board-init : board initialisation failure - board-reset-prot : number of resets exceeded - sem-power-fail : SEM external power failure - sem-ups-fail : SEM external power supply failure - board-reset-cf : board reset and/or communication failure - vlan-assign-fail : failure to assign VLAN for a user session - vsa-info-invalid : radius fail to assign a valid vsa to a user session - auth-mac-conflict : failure to check mac conflict for a user	

name	Type	Description
	session - user-pwd-fault : failure to check user or password of a user session - up-plan-bitrate : upstream bitrate is above min and below planned - up-min-bitrate : upstream bitrate is below min bitrate - up-config-not-feas : upstream bitrate is not enough to set up config group - down-plan-bitrate : downstream bitrate is above min and below planned - down-min-bitrate : downstream bitrate is below min bitrate - down-config-not-feas : downstream bitrate is not enough to set up config group - non-bonding-cpe : no bonding cpe modem is connected - multiple-cpes : bonding group has multiple cpe modems connected - register : bonding group discovery or aggregation register failure - group-incomplete : bonding group is incomplete - host-sfp-los : loss of signal - host-sfp-tx-fail : Tx failure - host-sfp-not-prst : not present - host-sfp-inv-id : no valid Nokia ID - host-sfp-ctrl-fail : control failure - host-sfp-rmtlt : unexpected remote plug-in - host-sfp-mismatch : assignment does not match reported rack/shelf/slot - host-sfp-incompt : incompatible shelf type detected - exp-sfp-los : expansion side loss of signal - exp-sfp-tx-fail : Tx failure - exp-sfp-not-prst : not present - exp-sfp-inv-id : no valid Nokia ID - exp-sfp-ctrl-fail : control failure - exp-sfp-1-los : expansion side sfp1 loss of signal - exp-sfp-2-los : expansion side sfp2 loss of signal - ext-qsfp-invlid : Invalid Nokia ID - tx-power-high-alarm : tx power more than alarm range - tx-power-low-alarm : tx power less than alarm range - rx-power-high-alarm : rx power more than alarm range - rx-power-low-alarm : rx power less than alarm range - tx-biascur-high-alarm : tx bias current high alarm - tx-biascur-low-alarm : tx bias current low alarm - volt-high-alarm : voltage high alarm - volt-low-alarm : voltage low alarm - temp-high-alarm : temperature high alarm - temp-low-alarm : temperature low alarm - tx-power-high-warn : tx power more than warn range - tx-power-low-warn : tx power less than warn range - rx-power-high-warn : rx power more than warn range - rx-power-low-warn : rx power less than warn range - tx-biascur-high-warn : tx bias current high warn - tx-biascur-low-warn : tx bias current low warn - volt-high-warn : voltage high warn - volt-low-warn : voltage low warn - temp-high-warn : temperature high warn - temp-low-warn : temperature low warn - onu-unprovisioned : unprovisioned ont	

100 Alarm Delta Log Status Commands

name	Type	Description
	- signal-loss : pon loss of signal - bitrate-high : the error bit rate high at pon interface - opmodule-mismatch : the optical module mismatched at pon interface - key-fail-one-churn : key exchange failure during one churning time - key-fail-three-churn : key exchange failure during three churning time - oam-discov-fail : extend oam discovery failure - report-timeout : report timeout detecting - total-packets-exceed : total amount of protocol packets exceed threshold - arp-packets-exceed : protocol arp packets exceed threshold - dhcp-packets-exceed : protocol dhcp packets exceed threshold - igmp-packets-exceed : protocol igmp packets exceed threshold - pppoe-packets-exceed : protocol pppoe packets exceed threshold - nd-packets-exceed : protocol nd packets exceed threshold - icmpv6-packets-exceed : protocol icmpv6 packets exceed threshold - mld-packets-exceed : protocol mld packets exceed threshold - dhcpv6-packets-exceed : protocol dhcpv6 packets exceed threshold - cfm-packets-exceed : protocol cfm packets exceed threshold - dsx1-serdes-fail : SERDES clock alarm failure - dsx1-tributary1-fail : The tributary 1 clock is not present - dsx1-tributary2-fail : The tributary 2 clock is not present - dsx1-los-fail : All the selected tribs in Loss of Signal - dsx1-ais-sync : Alarm Indication signal on the tributary selected as sync source - dsx1-lof-sync : Loss of Framing on the tributary selected as sync source - dsx1-los-sync : Loss of signal on the tributary selected as sync source - dsx1-deg-fail : Signal degrade Alarm - dsx1-rei-from-liu : Remote Error Indication alarm from LIU - dsx1-rdi-from-liu : Remote Defect Alarm from LIU - dsx1-crc6-from-liu : Cyclic Redundancy check-6 alarm from LIU - dsx1-crc4-from-liu : Cyclic Redundancy check-4 alarm from LIU - dsx1-crc4-th-from-liu : Cyclic Redundancy check-4 threshold alarm from LIU - dsx1-ais-from-liu : Alarm Indication Signal alarm from LIU - dsx1-los-from-liu : Loss of signal alarm from LIU - dsx1-lof-from-liu : Loss of framing alarm from LIU - dsx1-lomf-from-liu : Loss of Multi-frame alarm from LIU - dsx1-rei-from-iwf : Remote Error Indication alarm from IWF - dsx1-rdi-from-iwf : Remote Defect Alarm from IWF - dsx1-crc6-from-iwf : Cyclic Redundancy check-6 alarm	

name	Type	Description
	from IWF - dsx1-crc4-from-iwf : Cyclic Redundancy check-4 alarm from IWF - dsx1-crc4-th-from-iwf : Cyclic Redundancy check-4 threshold alarm from IWF - dsx1-ais-from-iwf : Alarm Indication Signal alarm from IWF - dsx1-los-from-iwf : Loss of signal alarm from IWF - dsx1-lof-from-iwf : Loss of framing alarm from IWF - dsx1-lomf-from-iwf : Loss of Multi-frame alarm from IWF - pppce-trans-15min-tca : 15 minutes transaction timeout count exceeds configured TCA - pppce-sess-15min-tca : 15 minutes session timeout count exceeds configured TCA - pppce-trans-1day-tca : 1day transaction timeout count exceeds configured TCA - pppce-sess-1day-tca : 1day session timeout count exceeds configured TCA - custom1 : customizable alarm 1 - custom2 : customizable alarm 2 - custom3 : customizable alarm 3 - custom4 : customizable alarm 4 - custom5 : customizable alarm 5 - he-custom1 : host expansion customizable alarm 1 - he-custom2 : host expansion customizable alarm 2 - he-custom3 : host expansion customizable alarm 3 - he-custom4 : host expansion customizable alarm 4 - he-custom5 : host expansion customizable alarm 5 - he-custom6 : host expansion customizable alarm 6 - custom6 : customizable alarm 6 - custom7 : customizable alarm 7 - custom8 : customizable alarm 8 - custom9 : customizable alarm 9 - custom10 : customizable alarm 10 - custom11 : customizable alarm 11 - custom12 : customizable alarm 12 - custom13 : customizable alarm 13 - custom14 : customizable alarm 14 - custom15 : customizable alarm 15 - custom16 : customizable alarm 16 - custom17 : customizable alarm 17 - loss-swo-cap : switch over capability in a redundant system - ping-check-fail : ping check in a redundant system - der-temp1 : Derived Alarm for Temporal Filter 1 - der-temp2 : Derived Alarm for Temporal Filter 2 - der-temp3 : Derived Alarm for Temporal Filter 3 - der-temp4 : Derived Alarm for Temporal Filter 4 - der-temp5 : Derived Alarm for Temporal Filter 5 - der-temp6 : Derived Alarm for Temporal Filter 6 - der-temp7 : Derived Alarm for Temporal Filter 7 - der-temp8 : Derived Alarm for Temporal Filter 8 - der-temp9 : Derived Alarm for Temporal Filter 9 - der-temp10 : Derived Alarm for Temporal Filter 10 - der-temp11 : Derived Alarm for Temporal Filter 11 - der-temp12 : Derived Alarm for Temporal Filter 12 - der-temp13 : Derived Alarm for Temporal Filter 13 - der-temp14 : Derived Alarm for Temporal Filter 14	

100 Alarm Delta Log Status Commands

name	Type	Description
	- der-temp15 : Derived Alarm for Temporal Filter 15 - der-temp16 : Derived Alarm for Temporal Filter 16 - der-temp17 : Derived Alarm for Temporal Filter 17 - der-temp18 : Derived Alarm for Temporal Filter 18 - der-temp19 : Derived Alarm for Temporal Filter 19 - der-temp20 : Derived Alarm for Temporal Filter 20 - der-temp21 : Derived Alarm for Temporal Filter 21 - der-temp22 : Derived Alarm for Temporal Filter 22 - der-temp23 : Derived Alarm for Temporal Filter 23 - der-temp24 : Derived Alarm for Temporal Filter 24 - der-temp25 : Derived Alarm for Temporal Filter 25 - der-temp26 : Derived Alarm for Temporal Filter 26 - der-temp27 : Derived Alarm for Temporal Filter 27 - der-temp28 : Derived Alarm for Temporal Filter 28 - der-temp29 : Derived Alarm for Temporal Filter 29 - der-temp30 : Derived Alarm for Temporal Filter 30 - der-temp31 : Derived Alarm for Temporal Filter 31 - der-spa1 : Derived Alarm for Spatial Filter 1 - der-spa2 : Derived Alarm for Spatial Filter 2 - der-spa3 : Derived Alarm for Spatial Filter 3 - der-spa4 : Derived Alarm for Spatial Filter 4 - der-spa5 : Derived Alarm for Spatial Filter 5 - der-spa6 : Derived Alarm for Spatial Filter 6 - der-spa7 : Derived Alarm for Spatial Filter 7 - der-spa8 : Derived Alarm for Spatial Filter 8 - der-spa9 : Derived Alarm for Spatial Filter 9 - der-spa10 : Derived Alarm for Spatial Filter 10 - der-spa11 : Derived Alarm for Spatial Filter 11 - der-spa12 : Derived Alarm for Spatial Filter 12 - der-spa13 : Derived Alarm for Spatial Filter 13 - der-spa14 : Derived Alarm for Spatial Filter 14 - der-spa15 : Derived Alarm for Spatial Filter 15 - der-spa16 : Derived Alarm for Spatial Filter 16 - der-spa17 : Derived Alarm for Spatial Filter 17 - der-spa18 : Derived Alarm for Spatial Filter 18 - der-spa19 : Derived Alarm for Spatial Filter 19 - der-spa20 : Derived Alarm for Spatial Filter 20 - der-spa21 : Derived Alarm for Spatial Filter 21 - der-spa22 : Derived Alarm for Spatial Filter 22 - der-spa23 : Derived Alarm for Spatial Filter 23 - der-spa24 : Derived Alarm for Spatial Filter 24 - der-spa25 : Derived Alarm for Spatial Filter 25 - der-spa26 : Derived Alarm for Spatial Filter 26 - der-spa27 : Derived Alarm for Spatial Filter 27 - der-spa28 : Derived Alarm for Spatial Filter 28 - der-spa29 : Derived Alarm for Spatial Filter 29 - der-spa30 : Derived Alarm for Spatial Filter 30 - der-spa31 : Derived Alarm for Spatial Filter 31 - apsf-alarm : Applique Power Supply Failure - custextalarm1 : Customizable External Alarm Number 1 - custextalarm2 : Customizable External Alarm Number 2 - custextalarm3 : Customizable External Alarm Number 3 - custextalarm4 : Customizable External Alarm Number 4 - custextalarm5 : Customizable External Alarm Number 5 - pluginfan : REM Fan Alarm - plugin-dc-a : REM DC A Alarm - plugin-dc-b : REM DC B Alarm	

name	Type	Description
	- plugin-dg : Dying Gasp Alarm - ntr-a-loss : NTR-A signal is not available - ntr-b-loss : NTR-B signal is not available - xvps-conf-loss : xvps configuration loss - mac-entry-nofree : no free mac entry in the mac table on It board - fibre-conn-mismatch : REM Fibre Connection Mismatch Alarm - link-cap-mismatch : Link speed capability mismatch - eqpt-cap-mismatch : Link equipment capability mismatch - ctrl-dnld-failure : Controller card download failure - melt-hw-issue : MELT hardware issue - melt-board-reset : MELT board reset - board-shelf-mismatch : board type and shelf type mismatch - mgnt-type-mismatch : Board management type mismatch - fileserv-unavail : file transfer Server unavailable or file transfer failed - shdsl-n-loopback : loopback active at the network side - shdsl-c-loopback : loopback active at the customer side - shdsl-conferr : configuration error - shdsl-atm-lcd : loss of atm cell delineation - shdsl-lpr : loss of power at stu-r - shdsl-secu-err : unable to disable stu-r access - shdsl-dev-fault : device fault - shdsl-atm-ncd : no atm cell delineation - shdsl-n-losw : loss of sync word at the network side on each pair - shdsl-c-losw : loss of sync word at the customer side on each pair - shdsl-n-aten : loop attenuation alarm at the network side on each pair - shdsl-c-aten : loop attenuation alarm at the customer side on each pair - shdsl-n-snr : snr margin alarm at the network side each pair - shdsl-c-snr : snr margin alarm at the customer side on each pair - shdsl-n-dccont : dc continuity fault at the network side on each pair - shdsl-c-dccont : dc continuity fault at the customer side on each pair - shdsl-c-actfail : activation failure at the customer side on each pair - e1-fe-rai : Receiving Remote Alarm Indication - e1-ne-rai : Transmitting Remote Alarm Indication - e1-fe-ais : Receiving Alarm Indication Signal - e1-ne-ais : Transmitting Alarm Indication Signal - e1-lof : E1 Loss of frame - e1-los : E1 Loss of Signal - e1-loopback : E1 facility in loopback - ima-grp-fe-su : far-end starting up - ima-grp-fe-cfg : far-end failed configuration - ima-grp-ne-cfg : near-end failed configuration - ima-grp-fe-nl : insufficient number of links at far-end - ima-grp-ne-nl : insufficient number of links at near-end - ima-grp-fe-blk : far-end is blocked - ima-lnk-lif : loss of ima frame - ima-lnk-lods : link out of delay synchronization	

100 Alarm Delta Log Status Commands

name	Type	Description
	- ima-lnk-misc : link misconnect - ima-lnk-rfi : link remote failure indication - ima-lnk-fault : fault in link facility - ima-lnk-txblk : transmit blocked due to far-end - ima-lnk-rxblk : receive blocked due to far-end - bad-digitmap : Configured digitmap is unusable - dhcp-unreach : The DHCP server is unreachable - dhcp-no-srv : The address in DHCP reply is NULL - dhcp-inv-srv : The address in DHCP reply is invalid - norpniewithsoftdsp : do not plan / plug-in RPNI-E board with SoftDsp SW image - unknown-sub : subscriber exist in the POLT, but not in the appl server - ground-key : Return current to the ground - port-hightemp : Temperature threshold on user port exceeded. - port-jbfltca : JB fill level threshold on user port exceeded. - reg-domainname : Registration failure (resolving domain name). - reg-auth : Registration failure (authentication). - reg-timeout : Registration failure (message timeout). - reg-srvfailresp : Registration failure (failure response from server). - inv-domainname : Invitation failure (resolving domain name). - inv-auth : Invitation failure (authentication). - inv-timeout : Invitation failure (message timeout). - inv-srvfailresp : Invitation failure (failure response from server). - subs-srvfailresp : Subscribe failure (failure response from server). - subs-domainname : Subscribe failure (resolving domain name). - subs-auth : Subscribe failure (authentication). - subs-refreshfail : Subscribe failure (refresh failure). - subs-inittimeout : Subscribe failure (initial REQ timeout). - emergency-call : Emergency call for SIP POTS is ongoing. - e1sip-reg-domainname : E1 sip termination registration failure (resolving domain name). - e1sip-reg-auth : E1 sip termination registration failure (authentication). - e1sip-reg-timeout : E1 sip termination registration failure (message timeout). - e1sip-reg-srvfailresp : E1 sip termination registration failure (failure response from server). - e1sip-inv-domainname : E1 sip termination invitation failure (resolving domain name). - e1sip-inv-auth : E1 sip termination invitation failure (authentication). - e1sip-inv-timeout : E1 sip termination invitation failure (message timeout). - e1sip-inv-srvfailresp : E1 sip invitation failure (failure response from server). - e1sip-emergency-call : Emergency call for ISDN PRA/CAS R2 is ongoing. - e1itf-ais-signal : Alarm Indication Signal detected at E1 interface.	

name	Type	Description
	- e1itf-los-signal : Loss Of Signal detected at E1 interface. - e1itf-rai-signal : Remote Alarm Indication detected at E1 interface. - e1sip-misconfig-mgc10 : Configuration not conform with the core network entity. - e1sip-nsmprf-missed : The SIP termination requires a NSM profile. - e1t1itf-recv-ais : Alarm Indication Signal received at interface. - e1t1itf-recv-los : Loss Of Signal received at interface. - e1t1itf-recv-rai : Remote Alarm Indication received at interface. - transport-mismatch : Transport protocol mismatch - dns-lookup-failure : Dns look up failure - none-dns-srv : No reply for all DNS serverd - no-dns-srv : No DNS servers configured - none-srv : No reply for all SIP First Hops - no-srv : No SIP First Hop configured - reg-srv-unreach : All SIP register servers are unreachable - proxy-srv-unreach : All SIP proxy servers are unreachable - dhcp-srv-unreach : The DHCP server is unreachable on this board - fo-trigger : Fail Over Triggered - fb-trigger : Fail Back Triggered - du-trigger : Deliberate Update Triggered - ssp-missing : SSP Missing in CDE - dns-pool-exceed : Number of different SG associated DNS pools exceed - lsa-fo-trigger : SIP voice service degraded - fail-over to LSA server - reg-domainname-sec : Registration failure (resolving domain name). - reg-auth-sec : Registration failure (authentication). - reg-timeout-sec : Registration failure (message timeout). - reg-srvfailresp-sec : Registration failure (failure response from server). - inv-domainname-sec : Invitation failure (resolving domain name). - inv-auth-sec : Invitation failure (authentication). - inv-timeout-sec : Invitation failure (message timeout). - inv-srvfailresp-sec : Invitation failure (failure response from server). - subs-srvfailresp-sec : Subscribe failure (failure response from server). - subs-domainname-sec : Subscribe failure (resolving domain name). - subs-auth-sec : Subscribe failure (authentication). - subs-refreshfail-sec : Subscribe failure (refresh failure). - subs-inittimeout-sec : Subscribe failure (initial REQ timeout). - emergency-call-sec : Emergency call for Secondary Termination is ongoing. - fanout : Lt load overflow - up-overflow : Upstream load overflow - upobc-overflow : Upstream load to OBC overflow - dwobc-overflow : Downstream load to OBC overflow - dw-overflow : Downstream load overflow	

name	Type	Description
	- lwpri-overflow : The number of BE and CL pkts dropped exceed threshold - queue-drop : The number of pkts dropped by queue exceeds threshold - queue-load : The queue load exceeds threshold - queue-peak-usage : The queue peak usage exceeds threshold - mgc-unreachable : loss of contact with the media gateway controller - failover-to-esamgc : failover to esa mgc - sgc-unreachable : loss of contac with signaling gateway controller - lcard-unreach-srvcard : line card unreachable with server card - lcard-type-mismatch : associate board of wrong type - meg-unknown-sub : the megaco subscriber is unknown - meg-ground-key : voice port ground key - meg-high-temp : voice port high temperature - meg-act-fail : the first link layer for isdn subscriber activation failure - meg-over-current : voice port over current - line-showering : line showering - low-qos-packetloss : the total packet loss has exceeded the configured threshold - low-qos-jitter : the rtp jitter has exceeded the configured threshold - low-qos-delay : the rtp delay has exceeded the configured threshold - sig-brd-persist-loss : voice signaling board persistent data loss - sig-brd-disk-full : voice signaling board disk 90% full - sig-brd-db-rollback : voice signaling board db rollback - mg-overload : mg overload - meg-unknown-sub-sec : The Megaco subscriber exists in voice signaling board but not in media gateway controller. - line-showering-sec : A subscriber line exceeds 20 off-hook / on-hook events / minute. - loss-env-mon : env-monitor box lost or not alive - etca-los : loss of signal errors in 15 min - etca-fcs : frame check sequence errors in 15 min - etca-day-los : loss of signal errors in 1 day - etca-day-fcs : frame check sequence errors in 1 day - etca-rx-octets : received octets in 15 min - etca-tx-octets : transmitted octets in 15 min - etca-day-rx-octets : received octets in 1 day - etca-day-tx-octets : transmitted octets in 1 day - user-sfp-los : user sfp loss of signal - user-sfp-tx-fail : user sfp tx failure - user-sfp-not-prst : user sfp not detected - user-sfp-inv-id : user sfp invalid id - user-sfp-t-exceed : user sfp temperature exceed - user-sfp-mismatch : user sfp mismatch the configured type - uplink-sfp-los : uplink sfp loss of signal - uplink-sfp-tx-fail : uplink sfp tx failure - uplink-sfp-not-prst : uplink sfp not detected - uplink-sfp-inv-id : uplink sfp invalid id - uplink-sfp-t-exceed : uplink sfp temperature exceed	

name	Type	Description
	- uplink-sfp-mismatch : uplink sfp mismatch the configured type - loss-lsmwp-cap : lsm redundancy - inv-xvps-pair-data : invalid xvps pair redundancy data - network-power-loss : Loss of Network Power - hw-fault : Hardware Failure - bat-miss : Power Source Battery Missing - bat-fail : Power Source Battery Failure - bat-low : Power Source Battery Charge LOW - bat-a-fail : Power Source BAT-A Fail - bat-b-fail : Power Source BAT-B Fail - ac-vol-out-range : AC Input Voltage Value Out of Range - network-power-loss-b : Loss of Network Power B - sem-ac-power-fail : External AC power supply failure - sem-ups-low-volt : External power supply low voltage - dc-a-fail : Local DC A power failure - dc-b-fail : Local DC B power failure - plan-power-mismatch : Planned and detected power mode mismatch - water-seepage-in-box : Detected water seepage in enclosure - sealed-box-open : Sealed box open detected - dc-a-vol-out-range : DC A Input Voltage Value Out of Range - dc-b-vol-out-range : DC B Input Voltage Value Out of Range - inlet-temp-major : The inlet temperature has exceeded a major level - inlet-temp-critical : The inlet temperature has exceeded a critical level - psu-fail-crit : Power Supply failure - psu-a-fail-presence : Power Supply A is not present - psu-a-fail-vin-ac-nok : Power Supply A has Vin AC fault - psu-a-fail-vin-uv : Power Supply A has Vin undervoltage - psu-a-fail-vin-ov : Power Supply A has Vin overvoltage - psu-a-fail-vout-uv : Power Supply A has Vout undervoltage - psu-a-fail-vout-ov : Power Supply A has Vout overvoltage - psu-a-fail-iout-oc : Power Supply A has Iout overcurrent - psu-a-fail-vertemp : Power Supply A has over temperature - psu-b-fail-presence : Power Supply B is not present - psu-b-fail-vin-ac-nok : Power Supply B has Vin AC fault - psu-b-fail-vin-uv : Power Supply B has Vin undervoltage - psu-b-fail-vin-ov : Power Supply B has Vin overvoltage - psu-b-fail-vout-uv : Power Supply B has Vout undervoltage - psu-b-fail-vout-ov : Power Supply B has Vout overvoltage - psu-b-fail-iout-oc : Power Supply B has Iout overcurrent - psu-b-fail-vertemp : Power Supply B has over temperature - synce-fail : synce clock source failure - bits-fail : bits clock source failure - bits-output-shutoff : bits output failure - ieee1588-fail : ieee1588 clock source failure - gnss-fail : gnss clock source failure - ieee1588-hybrid-fail : ieee1588 hybrid tod source failure	

100 Alarm Delta Log Status Commands

name	Type	Description
	- signal-loss : synce or bits clock signal loss - signal-efd : synce or bits clock signal exceed frequency deviation - esmc-loss : clock source loss SSM information - bits-output-exceed : exceed bits output threshold - ql-input-exceed : exceed input clock source threshold - holdover : clock system is in the holdover - lti : all clock source failed - tod-reference-fail : Timing ToD Reference failed - internal-clk-fail : Internal CLK failed - bgp-peer-down : peer operational state is down - bgp-routes-mid-limit : 90% of max nbr of routes BGP can learn from a peer is reached - isis-adjacency-down : isis adjacency is down - isis-adjacency-reject : isis adjacency is rejected - isis-instance-down : isis instance is down or not - ospf-lsa-limit : limit of received LSA's is reached - ospf-lsa-mid-limit : 90% of limit of received LSA's is reached - ospf-neighbor-down : OSPF neighbour is down - ospf-instance-down : OSPF instance is down or not - ospf3-lsa-limit : limit of received OSPFv3 LSAs is reached - ospf3-lsa-mid-limit : 90% of limit of received OSPFv3 LSAs is reached - ospf3-neighbor-down : OSPFv3 neighbour is down - ospf3-instance-down : OSPFv3 instance is down or not - rip-instance-down : rip instance down - lag-down : lag down - lagsubgrp-thresh-reach: lag subgroup threshold reached - lagsubgrp-switch-fail : lag subgroup switchover failed - no-unpinned-free-ports: No free ports available for unpinned traffic - general-arp-limit : arp limit exceeded - gen-switch-out-of-res : failure due to lack of resources on switch - ipv6-nc-limit : ipv6 neighbor cache limit exceeded - dhcp-session-oor : dhcp session out of resources - ihub-fdb-limit : layer 2 fdb limit reached - ihub-mac-limit : layer 2 mac limit reached - l2fw-stp-exception : STP exception condition is present in the SAP - l2fw-stp-root-guard : STP root guard violation is present - vprn-routes-limit : limit of ip is reached - vprn-ipv6-routes-limit: limit of ipv6 is reached - dhcpv6-lease-limit : limit of dhcpv6 leases is reached - dhcpv4-lease-limit : limit of dhcpv4 leases is reached - vpls-mfib-limit : limit of fib table is reached - ihub-ipv6-dad-own : duplicate IPV6 address is detected for IP address allotted to system - ihub-ipv6-dad : duplicate IPV6 address is detected for a user's IP address - ihub-ipv6-dup-pd-route: ipv6 duplicate pd detected - vpls-duplicate-mac : duplicate mac address is detected - vpls-fdb-limit : limit of fdb table is reached - vpls-self-duplic-mac : duplicate of a system owned mac address detected on a sap - vpls-sdp-self-dup-mac : duplicate of a system owned mac	

name	Type	Description
	address detected on a sdp binding - link-down : link is down - link-lagport-add-fail : failure to add port to LAG - link-conf-mismatch : SFP+plugin-types does not match the planned speed and/or auto-negotiation for the port - ihub-peer-comm : ihub peer to peer communication failure - ihub-sw-fail : IHUB s/w error - ihub-hw-fail : IHUB h/w error - ihub-link-fail : IHUB link failure - ihub-proc-overload : IHUB processor exceeded - ihub-out-of-mem : IHUB processor out of memory - ntp-comm-lost : No response is received from the NTP servers - ldp-instance-down : ldp instance down - ldp-session-down : ldp session down - mpls-instance-down : mpls instance down - mpls-lsp-down : lsp down - mpls-lsp-path-down : lsp path down - sdp-instance-down : sdp instance down - sdp-binding-down : sdp binding down - epipe-instance-down : epipe instance down - lldpmed-portcfg-mis : config request failure for lldpmed portconfig - lldpmed-mediapl-mis : config request failure for lldpmed mediapolicy - vlanport-svc-mismatch : config request failure for the provisioned vlanport - mcsrc-stream-lost : multicast video stream lost - eqptsupl-syslog-upload: upload of log file to remote server failure - eqptsupl-ontsw-dnload : ont sw download in progress - cf-75%used : Compact flash exceeds 75% of life expectancy - cf-90%used : Compact flash exceeds 90% of life expectancy - olt-gen-pon-com-fail : pon communication failure on olt - olt-gen-tx-fail : transmitter failure on olt - olt-gen-unprov-ont : unprovisioned ont on pon - olt-gen-pon-eqpt-prov : mismatch btw equipment and provisioning pon attributes - olt-gen-pon-loss-sig : pon loss of signal - olt-gen-pon-diagnostic: pon diagnostic test active - olt-gen-loid-conflict : loid conflict ont on pon - olt-gen-loid-pwderr : loid password error ont on pon - olt-gen-pon-alien-test: pon alien diagnostic test active - olt-gen-alien-detect : pon alien detect active - olt-gen-rng-mism : pon ranging mismatch active - olt-gen-sfp-mism : pon sfp mismatch active - olt-gen-deact-hightca : deactivated ont hightca threshold crossed - olt-gen-deact-lowtca : deactivated ont lowtca threshold crossed - olt-gen-dp-integ : pon data path integriy failure - olt-gen-ddr-fault : pon failure due to ddr fault - olt-pon-tc-err-frag-tc: pon errored fragments threshold crossed - olt-ont-tc-err-frag-tc: ont errored fragments threshold	

100 Alarm Delta Log Status Commands

name	Type	Description
	crossed - ont-ploam-loss-sig : loss of signal at ont - ont-ploam-loss-ack : loss of acknowledge from ont - ont-ploam-loss-cd : loss of channel delineation of ont - ont-ploam-phy-eqpt-err: physical equipment error of ont - ont-ploam-startup-fail: startup failure in ranging of ont - ont-ploam-sig-degrade : signal degrade from ont - ont-ploam-disabled : ont disabled alarm - ont-ploam-err-msg : error message from ont - ont-ploam-inactive : inactive ont - ont-ploam-sig-fail : signal fail alarm from ont - ont-ploam-dying-gasp : dying gasp alarm from ont - ont-ploam-deact-fail : deactive failure of ont - ont-ploam-oam : loss of ploam for ont - ont-ploam-win-drift : drift of window alarm - ont-ploam-rdi : remote defect indication alarm - ont-ploam-loss-ks : loss of key synchronization alarm - ont-ploam-pwr-burst : power bursts on ont - ont-ploam-rog-disa : ont rogue disabled - ont-ploam-diff-reach : ont differential reach exceeded - ont-ploam-looc : Loss of OMCI channel due to persistent MIC failure - sfu-ploam-loss-sig : SFU ONT - loss of signal at ont - sfu-ploam-loss-ack : SFU ONT - loss of acknowledge from ont - sfu-ploam-loss-cd : SFU ONT - loss of channel delineation of ont - sfu-ploam-phy-eqpt-err: SFU ONT - physical equipment error of ont - sfu-ploam-startup-fail: SFU ONT - startup failure in ranging of ont - sfu-ploam-sig-degrade : SFU ONT - signal degrade from ont - sfu-ploam-disabled : SFU ONT - ont disabled alarm - sfu-ploam-err-msg : SFU ONT - error message from ont - sfu-ploam-inactive : SFU ONT - inactive ont - sfu-ploam-sig-fail : SFU ONT - signal fail alarm from ont - sfu-ploam-dying-gasp : SFU ONT - dying gasp alarm from ont - sfu-ploam-deact-fail : SFU ONT - deactive failure of ont - sfu-ploam-oam : SFU ONT - loss of ploam for ont - sfu-ploam-win-drift : SFU ONT - drift of window alarm - sfu-ploam-rdi : SFU ONT - remote defect indication alarm - sfu-ploam-loss-ks : SFU ONT - loss of key synchronization alarm - sfu-ploam-pwr-burst : SFU ONT - power bursts on ont - sfu-ploam-rog-disa : SFU ONT - ont rogue disabled - sfu-ploam-diff-reach : SFU ONT - ont differential reach exceeded - sfu-ploam-looc : SFU ONT - Loss of OMCI channel due to persistent MIC failure - soho-ploam-loss-sig : SOHO ONT - loss of signal at ont - soho-ploam-loss-ack : SOHO ONT - loss of acknowledge from ont - soho-ploam-loss-cd : SOHO ONT - loss of channel delineation of ont - soho-ploam-phy-eqpt-er: SOHO ONT - physical	

name	Type	Description
	equipment error of ont - soho-ploam-startup-fai: SOHO ONT - startup failure in ranging of ont - soho-ploam-sig-degrade: SOHO ONT - signal degrade from ont - soho-ploam-disabled : SOHO ONT - ont disabled alarm - soho-ploam-err-msg : SOHO ONT - error message from ont - soho-ploam-inactive : SOHO ONT - inactive ont - soho-ploam-sig-fail : SOHO ONT - signal fail alarm from ont - soho-ploam-dying-gasp : SOHO ONT - dying gasp alarm from ont - soho-ploam-deact-fail : SOHO ONT - deactive failure of ont - soho-ploam-oam : SOHO ONT - loss of ploam for ont - soho-ploam-win-drift : SOHO ONT - drift of window alarm - soho-ploam-rdi : SOHO ONT - remote defect indication alarm - soho-ploam-loss-ks : SOHO ONT - loss of key synchronization alarm - soho-ploam-pwr-burst : SOHO ONT - power bursts on ont - soho-ploam-rog-disa : SOHO ONT - ont rogue disabled - soho-ploam-diff-reach : SOHO ONT - ont differential reach exceeded - soho-ploam-looc : SOHO ONT - Loss of OMCI channel due to persistent MIC failure - mdu-ploam-loss-sig : MDU ONT - loss of signal at ont - mdu-ploam-loss-ack : MDU ONT - loss of acknowledge from ont - mdu-ploam-loss-cd : MDU ONT - loss of channel delineation of ont - mdu-ploam-phy-eqpt-err: MDU ONT - physical equipment error of ont - mdu-ploam-startup-fail: MDU ONT - startup failure in ranging of ont - mdu-ploam-sig-degrade : MDU ONT - signal degrade from ont - mdu-ploam-disabled : MDU ONT - ont disabled alarm - mdu-ploam-err-msg : MDU ONT - error message from ont - mdu-ploam-inactive : MDU ONT - inactive ont - mdu-ploam-sig-fail : MDU ONT - signal fail alarm from ont - mdu-ploam-dying-gasp : MDU ONT - dying gasp alarm from ont - mdu-ploam-deact-fail : MDU ONT - deactive failure of ont - mdu-ploam-oam : MDU ONT - loss of ploam for ont - mdu-ploam-win-drift : MDU ONT - drift of window alarm - mdu-ploam-rdi : MDU ONT - remote defect indication alarm - mdu-ploam-loss-ks : MDU ONT - loss of key synchronization alarm - mdu-ploam-pwr-burst : MDU ONT - power bursts on ont - mdu-ploam-rog-disa : MDU ONT - ont rogue disabled - mdu-ploam-diff-reach : MDU ONT - ont differential reach exceeded	

100 Alarm Delta Log Status Commands

name	Type	Description
	- mdu-ploam-looc : MDU ONT - Loss of OMCI channel due to persistent MIC failure - ont-hpna-ser-mis : hpna ont service mismatch - ont-hpna-los-sig : hpna loss of link - ont-moca-svc-mis : moca ont service mismatch - ont-moca-link-los : moca loss of link - ont-moca-min-bw : moca bw between nodes less than minimum bw - ont-moca-tca-rx-err-fr: moca rx errored frames threshold crossed - ont-sipa-reg-nm-fail : sipua registration name failed - ont-sipa-reg-rec-fail : sipua register reach failed - ont-sipa-reg-con-fail : sipua register connect failed - ont-sipa-reg-val-fail : sipua register validation failed - ont-sipa-reg-mis : sipua register mismatch - ont-vcd-cfg-nm-fail : vcd config name failed - ont-vcd-cfg-rech-fail : vcd config reach failed - ont-vcd-cfg-conn-fail : vcd config connect failed - ont-vcd-cfg-vali-fail : vcd config validation failed - ont-vcd-cfg-auth-fail : vcd config authentication failed - ont-vcd-cfg-resp-tmout: vcd config response timeout - ont-vcd-cfg-resp-err : vcd config response error - ont-vcd-cfg-file-err : vcd config file error - ont-vcd-sub-nm-fail : vcd subscription name failed - ont-vcd-sub-rech-fail : vcd subscription reach failed - ont-vcd-sub-conn-fail : vcd subscription connect failed - ont-vcd-sub-vali-fail : vcd subscription validation failed - ont-vcd-sub-auth-fail : vcd subscription authentication failed - ont-vcd-sub-resp-tmout: vcd subscription response timeout - ont-vcd-sub-resp-err : vcd subscription response error - ont-vcd-reb-requ : vcd reboot request - ont-vcd-mis : vcd mismatch - ont-mgc-mis : ont mgc mismatch - ont-mgc-timeout : ont mgc timeout - ont-sip-reg-dns : ont services pots sip registration failed (resolving domain name) - ont-sip-reg-fail : ont services pots sip registration authentication failed - ont-sip-reg-timeout : ont services pots sip registration timeout - ont-sip-reg-err-resps : ont services pots sip registration response error - ont-sip-inv-dns : ont services pots sip invitation failed (resolving domain name) - ont-sip-inv-auth : ont services pots sip invitation authentication failed - ont-sip-inv-timeout : ont services pots sip invitation timeout - ont-sip-inv-err : ont services pots sip invitation response error - ont-svc-pots-subs-refr: ont services pots iconfig subscription could not be refreshed - ont-svc-pots-not-refr : ont services pots iconfig notification could not be refreshed - ont-svc-pots-icfg-err : ont services pots service failed due to an unmapped iconfig error	

name	Type	Description
	- ont-veip-mismatch : ont veip mismatch - ont-ip-host-mismatch : ont ip host mismatch - ont-ip-host-file : ont ip host file unavailable - ont-ip-host-ip-alloc : ont ip host IP allocation failure - olt-pon-up-bw-tca : OLT PON upstream bandwidth TCA - olt-pon-down-bw-tca : OLT PON downstream bandwidth TCA - ont-gen-omci-fail : loss of communication - ont-gen-eqpt-selftest : ont self-test failure - ont-gen-ac-pwr-fail : ac power failure on ont - ont-gen-bat-missing : battery missing - ont-gen-bat-low : battery low - ont-gen-bat-fail : battery failure - ont-gen-phys-intrusion: physical intrusion - ont-gen-sw-dnload-f : ont sw download failure - ont-gen-sw-dnload-p : ont sw download in progress - ont-gen-sw-act-fail : ont sw activation failure - ont-gen-eqpt-vers-mis : ont equipment version mismatch - ont-gen-sw-vers-mis : ont sw version mismatch - ont-gen-us-rate-mis : ont upstream rate mismatch - ont-gen-mdu-env1 : mdu environmental alarm#1 - ont-gen-mdu-env2 : mdu environmental alarm#2 - ont-gen-mdu-env3 : mdu environmental alarm#3 - ont-gen-nw-time-err : network timing protocol error - ont-gen-opt-sig-high : optical signal level too high - ont-gen-opt-sig-low : optical signal level too low - ont-gen-eqpt-prov-sa : service affecting mismatch btw equipment and provisioning attributes - ont-gen-eqpt-prov-nsa : non service affecting mismatch btw equipment and provisioning attributes - pon-t-txmcutilhi : pon utilization tx (downstream) multicast high threshold crossed - pon-t-txmcutilmd : pon utilization tx (downstream) multicast medium threshold crossed - pon-t-txmcutillo : pon utilization tx (downstream) multicast low threshold crossed - pon-t-txtotutilhi : pon utilization tx (downstream) total high threshold crossed - pon-t-txtotutilmd : pon utilization tx (downstream) total medium threshold crossed - pon-t-txtotutillo : pon utilization tx (downstream) total low threshold crossed - pon-t-rxtotutilhi : pon utilization rx (upstream) total high threshold crossed - pon-t-rxtotutilmd : pon utilization rx (upstream) total medium threshold crossed - pon-t-rxtotutillo : pon utilization rx (upstream) total low threshold crossed - pon-t-dbacongperiodhi : pon utilization rx (upstream) dbacongperiod high threshold crossed - pon-t-dbacongperiodmd : pon utilization rx (upstream) dbacongperiod medium threshold crossed - pon-t-dbacongperiodlo : pon utilization rx (upstream) dbacongperiod low threshold crossed - pon-t-txucdropfrmhi : pon utilization tx (downstream) unicast drop frame high threshold crossed - pon-t-txucdropfrmd : pon utilization tx (downstream)	

name	Type	Description
	unicast drop frame medium threshold crossed - pon-t-txucdropfrmlo : pon utilization tx (downstream) unicast drop frame low threshold crossed - pon-t-txmcdropfrmhi : pon utilization tx (downstream) multicast drop frame high threshold crossed - pon-t-txmcdropfrmmd : pon utilization tx (downstream) multicast drop frame medium threshold crossed - pon-t-txmcdropfrmlo : pon utilization tx (downstream) multicast drop frame low threshold crossed - pon-t-txbcdropfrmhi : pon utilization tx (downstream) broadcast drop frame high threshold crossed - pon-t-txbcdropfrmmd : pon utilization tx (downstream) broadcast drop frame medium threshold crossed - pon-t-txbcdropfrmlo : pon utilization tx (downstream) broadcast drop frame low threshold crossed - pon-t-rxtotdropfrmhi : pon utilization rx (upstream) total drop frame high threshold crossed - pon-t-rxtotdropfrmmd : pon utilization rx (upstream) total drop frame medium threshold crossed - pon-t-rxtotdropfrmlo : pon utilization rx (upstream) total drop frame low threshold crossed - chpr-t-txmcutilhi : channel-pair utilization tx (downstream) multicast high threshold crossed - chpr-t-txmcutilmd : channel-pair utilization tx (downstream) multicast medium threshold crossed - chpr-t-txmcutillo : channel-pair utilization tx (downstream) multicast low threshold crossed - chpr-t-txtotutilhi : channel-pair utilization tx (downstream) total high threshold crossed - chpr-t-txtotutilmd : channel-pair utilization tx (downstream) total medium threshold crossed - chpr-t-txtotutillo : channel-pair utilization tx (downstream) total low threshold crossed - chpr-t-rxtotutilhi : channel-pair utilization rx (upstream) total high threshold crossed - chpr-t-rxtotutilmd : channel-pair utilization rx (upstream) total medium threshold crossed - chpr-t-rxtotutillo : channel-pair utilization rx (upstream) total low threshold crossed - chpr-t-dbacongperiodhi: channel-pair utilization rx (upstream) dbacongperiod high threshold crossed - chpr-t-dbacongperiodmd: channel-pair utilization rx (upstream) dbacongperiod medium threshold crossed - chpr-t-dbacongperiodlo: channel-pair utilization rx (upstream) dbacongperiod low threshold crossed - chpr-t-txucdropfrmhi : channel-pair utilization tx (downstream) unicast drop frame high threshold crossed - chpr-t-txucdropfrmmd : channel-pair utilization tx (downstream) unicast drop frame medium threshold crossed - chpr-t-txucdropfrmlo : channel-pair utilization tx (downstream) unicast drop frame low threshold crossed - chpr-t-txmcdropfrmhi : channel-pair utilization tx (downstream) multicast drop frame high threshold crossed - chpr-t-txmcdropfrmmd : channel-pair utilization tx (downstream) multicast drop frame medium threshold crossed - chpr-t-txmcdropfrmlo : channel-pair utilization tx	

name	Type	Description
	(downstream) multicast drop frame low threshold crossed - chpr-t-txbcdropfrmhi : channel-pair utilization tx (downstream) broadcast drop frame high threshold crossed - chpr-t-txbcdropfrmmd : channel-pair utilization tx (downstream) broadcast drop frame medium threshold crossed - chpr-t-txbcdropfrmlo : channel-pair utilization tx (downstream) broadcast drop frame low threshold crossed - chpr-t-rxtotdropfrmhi : channel-pair utilization rx (upstream) total drop frame high threshold crossed - chpr-t-rxtotdropfrmmd : channel-pair utilization rx (upstream) total drop frame medium threshold crossed - chpr-t-rxtotdropfrmlo : channel-pair utilization rx (upstream) total drop frame low threshold crossed - sfu-gen-omci-fail : SFU ONT - loss of communication - sfu-gen-eqpt-selftest : SFU ONT - ont self-test failure - sfu-gen-ac-pwr-fail : SFU ONT - ac power failure on ont - sfu-gen-bat-missing : SFU ONT - battery missing - sfu-gen-bat-low : SFU ONT - battery low - sfu-gen-bat-fail : SFU ONT - battery failure - sfu-gen-sw-dnload-f : SFU ONT - ont sw download failure - sfu-gen-sw-dnload-p : SFU ONT - ont sw download in progress - sfu-gen-sw-act-fail : SFU ONT - ont sw activation failure - sfu-gen-eqpt-vers-mis : SFU ONT - ont equipment version mismatch - sfu-gen-sw-vers-mis : SFU ONT - ont sw version mismatch - sfu-gen-us-rate-mis : SFU ONT - ont upstream rate mismatch - sfu-gen-tune-fail : SFU ONT - ont has failed to tune to Target-ChnlPair - sfu-gen-nw-time-err : SFU ONT - network timing protocol error - sfu-gen-opt-sig-high : SFU ONT - optical signal level too high - sfu-gen-opt-sig-low : SFU ONT - optical signal level too low - sfu-gen-eqpt-prov-sa : SFU ONT - service affecting mismatch btw equipment and provisioning attributes - sfu-gen-eqpt-prov-nsa : SFU ONT - non service affecting mismatch btw equipment and provisioning attributes - soho-gen-omci-fail : SOHO ONT - loss of communication - soho-gen-eqpt-selftest : SOHO ONT - ont self-test failure - soho-gen-ac-pwr-fail : SOHO ONT - ac power failure on ont - soho-gen-bat-missing : SOHO ONT - battery missing - soho-gen-bat-low : SOHO ONT - battery low - soho-gen-bat-fail : SOHO ONT - battery failure - soho-gen-sw-dnload-f : SOHO ONT - ont sw download failure - soho-gen-sw-dnload-p : SOHO ONT - ont sw download in progress - soho-gen-sw-act-fail : SOHO ONT - ont sw activation failure - soho-gen-eqpt-vers-mis : SOHO ONT - ont equipment version mismatch	

100 Alarm Delta Log Status Commands

name	Type	Description
	- soho-gen-sw-vers-mis : SOHO ONT - ont sw version mismatch - soho-gen-us-rate-mis : SOHO ONT - ont upstream rate mismatch - soho-gen-tune-fail : SOHO ONT - ont has failed to tune to Target-ChnlPair - soho-gen-nw-time-err : SOHO ONT - network timing protocol error - soho-gen-opt-sig-high : SOHO ONT - optical signal level too high - soho-gen-opt-sig-low : SOHO ONT - optical signal level too low - soho-gen-eqpt-prov-sa : SOHO ONT - service affecting mismatch btw equipment and provisioning attributes - soho-gen-eqpt-prov-nsa: SOHO ONT - non service affecting mismatch btw equipment and provisioning attributes - mdu-gen-omci-fail : MDU ONT - loss of communication - mdu-gen-eqpt-selftest : MDU ONT - ont self-test failure - mdu-gen-ac-pwr-fail : MDU ONT - ac power failure on ont - mdu-gen-bat-missing : MDU ONT - battery missing - mdu-gen-bat-low : MDU ONT - battery low - mdu-gen-bat-fail : MDU ONT - battery failure - mdu-gen-phys-intrusion: MDU ONT - physical intrusion - mdu-gen-sw-dnload-f : MDU ONT - ont sw download failure - mdu-gen-sw-dnload-p : MDU ONT - ont sw download in progress - mdu-gen-sw-act-fail : MDU ONT - ont sw activation failure - mdu-gen-eqpt-vers-mis : MDU ONT - ont equipment version mismatch - mdu-gen-sw-vers-mis : MDU ONT - ont sw version mismatch - mdu-gen-us-rate-mis : MDU ONT - ont upstream rate mismatch - mdu-gen-tune-fail : MDU ONT - ont has failed to tune to Target-ChnlPair - mdu-gen-mdu-env1 : MDU ONT - mdu environmental alarm#1 - mdu-gen-mdu-env2 : MDU ONT - mdu environmental alarm#2 - mdu-gen-mdu-env3 : MDU ONT - mdu environmental alarm#3 - mdu-gen-nw-time-err : MDU ONT - network timing protocol error - mdu-gen-opt-sig-high : MDU ONT - optical signal level too high - mdu-gen-opt-sig-low : MDU ONT - optical signal level too low - mdu-gen-eqpt-prov-sa : MDU ONT - service affecting mismatch btw equipment and provisioning attributes - mdu-gen-eqpt-prov-nsa : MDU ONT - non service affecting mismatch btw equipment and provisioning attributes - ont-gen-sw-dnload-file: ont sw download file missing	

name	Type	Description
	- ont-gen-fan-fail : ont fan failure - ont-gen-high-temp : ont high temperature - ont-gen-high-temp-ex : ont excessive high temperature - ont-gen-emergency-call: ont emergency call - ont-gen-sw-version : ont sw version control error - ont-poe-exceed-max : ont poe exceed max - ont-poe-overload-yell : ONU is nearing its maximum ability to supply the power - ont-opti-malfunc : malfunction of ONT's optical transceiver - ont-gen-cfgdld-fail : download of voice xml file to ont failed - ont-gen-rssi-mis : ONU RSSI configuration mismatch - ont-gen-tx-pwr-low : ONU SFP Tx Power is lower than configured Alarm low threshold - ont-gen-temp-high : ONU SFP Temperature is higher than configured Alarm high threshold - ont-gen-volt-high : ONU SFP Voltage is higher than configured Alarm high threshold - ont-gen-bias-high : ONU SFP Bias is higher than configured Alarm high threshold - ont-loopdetect-mis : ont loop detect mismatch - ont-olt-rx-pw-lo : olt side receive power from ont low - ont-olt-rx-pw-hig : olt side receive power from ont high - ont-olt-rx-pw-warnlo : olt side receive power from ont low warning - ont-olt-rx-pw-warnhig : olt side receive power from ont high warning - ont-gen-tod-out-sync : ONU TOD is out-sync with OLT - ont-gen-tune-fail : ONU has failed to tune to Target-ChnlPair - hgu-tr069-param-fail : hgu tr069 parameters mismatch - ont-gen-tod-mismatch : ONU TOD MISMATCH - sfu-sup-sw-file-error : SFU ONT - Software file has error or is missing - sfu-sup-fan-failure : SFU ONT - Fan failure - sfu-sup-temp-high-warn: SFU ONT - High temperature warning - sfu-sup-temp-shutoff : SFU ONT - Service disabled due to excessive temperature - sfu-sup-emergency-call: SFU ONT - Emergency call active - sfu-sup-swverctrl-err : SFU ONT - Software version control error - sfu-sup-poe-exceed-max: SFU ONT - Configured PoE feeding exceeds ONT maximum - sfu-sup-poe-over-yell : SFU ONT - ONU is nearing its maximum ability to supply the power - sfu-opti-malfunc : SFU ONT - Malfunction of ONT's optical transceiver - sfu-sup-cfg-dnld-fail : SFU ONT - Download of voice xml file to ONT failed - sfu-sup-rssi-cfg-mism : SFU ONT - RSSI configuration mismatch - sfu-sup-sfp-tx-low : SFU ONT - SFP Tx Power below configured low-level alarm threshold - sfu-sup-sfp-temp-high : SFU ONT - SFP Temperature above configured high-level alarm threshold	

100 Alarm Delta Log Status Commands

name	Type	Description
	- sfu-sup-sfp-volt-high : SFU ONT - SFP Voltage above configured high-level alarm threshold - sfu-sup-sfp-bias-high : SFU ONT - SFP Bias above configured high-level alarm threshold - sfu-sup-ld-cfg-mism : SFU ONT - Loop detection configuration mismatch - sfu-sup-olt-rx-low : SFU ONT - OLT Rx power below receiver operating range - sfu-sup-olt-rx-high : SFU ONT - OLT Rx power above receiver operating range - sfu-sup-olt-rx-lo-warn: SFU ONT - OLT Rx power below low-level warning threshold - sfu-sup-olt-rx-hi-warn: SFU ONT - OLT Rx power above high-level warning threshold - sfu-sup-tod-out-sync : SFU ONT - ONU TOD is out-sync with OLT - sfu-sup-ont-tune-fail : SFU ONT - ONU has failed to tune to Target-ChnlPair - sfu-tr069-param-fail : SFU ONT - hgu tr069 parameters mismatch - sfu-sup-tod-mismatch : SFU ONT - ONU TOD MISMATCH - soho-sup-sw-file-error: SOHO ONT - Software file has error or is missing - soho-sup-fan-failure : SOHO ONT - Fan failure - soho-sup-temp-high-war: SOHO ONT - High temperature warning - soho-sup-temp-shutoff : SOHO ONT - Service disabled due to excessive temperature - soho-sup-emergency-cal: SOHO ONT - Emergency call active - soho-sup-swverctrl-err: SOHO ONT - Software version control error - soho-sup-poe-exceed-ma: SOHO ONT - Configured PoE feeding exceeds ONT maximum - soho-sup-poe-over-yell: SOHO ONT - ONU is nearing its maximum ability to supply the power - soho-opti-malfunc : SOHO ONT - Malfunction of ONT's optical transceiver - soho-sup-cfg-dnld-fail: SOHO ONT - Download of voice xml file to ONT failed - soho-sup-rssi-cfg-mism: SOHO ONT - RSSI configuration mismatch - soho-sup-sfp-tx-low : SOHO ONT - SFP Tx Power below configured low-level alarm threshold - soho-sup-sfp-temp-high: SOHO ONT - SFP Temperature above configured high-level alarm threshold - soho-sup-sfp-volt-high: SOHO ONT - SFP Voltage above configured high-level alarm threshold - soho-sup-sfp-bias-high: SOHO ONT - SFP Bias above configured high-level alarm threshold - soho-sup-ld-cfg-mism : SOHO ONT - Loop detection configuration mismatch - soho-sup-olt-rx-low : SOHO ONT - OLT Rx power below receiver operating range - soho-sup-olt-rx-high : SOHO ONT - OLT Rx power above receiver operating range	

name	Type	Description
	- soho-sup-olt-rx-lo-war: SOHO ONT - OLT Rx power below low-level warning threshold - soho-sup-olt-rx-hi-war: SOHO ONT - OLT Rx power above high-level warning threshold - soho-sup-tod-out-sync : SOHO ONT - ONU TOD is out-sync with OLT - soho-sup-ont-tune-fail: SOHO ONT - ONU has failed to tune to Target-ChnlPair - soho-tr069-param-fail : SOHO ONT - hgu tr069 parameters mismatch - soho-sup-tod-mismatch : SOHO ONT - ONU TOD MISMATCH - mdu-sup-sw-file-error : MDU ONT - Software file has error or is missing - mdu-sup-fan-failure : MDU ONT - Fan failure - mdu-sup-temp-high-warn: MDU ONT - High temperature warning - mdu-sup-temp-shutoff : MDU ONT - Service disabled due to excessive temperature - mdu-sup-emergency-call: MDU ONT - Emergency call active - mdu-sup-swverctrl-err : MDU ONT - Software version control error - mdu-sup-poe-exceed-max: MDU ONT - Configured PoE feeding exceeds ONT maximum - mdu-sup-poe-over-yell : MDU ONT - ONU is nearing its maximum ability to supply the power - mdu-opti-malfunc : MDU ONT - Malfunction of ONT's optical transceiver - mdu-sup-cfg-dnld-fail : MDU ONT - Download of voice xml file to ONT failed - mdu-sup-rssi-cfg-mism : MDU ONT - RSSI configuration mismatch - mdu-sup-sfp-tx-low : MDU ONT - SFP Tx Power below configured low-level alarm threshold - mdu-sup-sfp-temp-high : MDU ONT - SFP Temperature above configured high-level alarm threshold - mdu-sup-sfp-volt-high : MDU ONT - SFP Voltage above configured high-level alarm threshold - mdu-sup-sfp-bias-high : MDU ONT - SFP Bias above configured high-level alarm threshold - mdu-sup-ld-cfg-mism : MDU ONT - Loop detection configuration mismatch - mdu-sup-olt-rx-low : MDU ONT - OLT Rx power below receiver operating range - mdu-sup-olt-rx-high : MDU ONT - OLT Rx power above receiver operating range - mdu-sup-olt-rx-lo-warn: MDU ONT - OLT Rx power below low-level warning threshold - mdu-sup-olt-rx-hi-warn: MDU ONT - OLT Rx power above high-level warning threshold - mdu-sup-tod-out-sync : MDU ONT - ONU TOD is out-sync with OLT - mdu-sup-ont-tune-fail : MDU ONT - ONU has failed to tune to Target-ChnlPair - mdu-tr069-param-fail : MDU ONT - hgu tr069 parameters mismatch	

100 Alarm Delta Log Status Commands

name	Type	Description
	- mdu-sup-tod-mismatch : MDU ONT - ONU TOD MISMATCH - ont-sbscr-lim-missing : provisioned ont card missing - ont-sbscr-lim-type-mis: wrong type plug-in ont card - ont-sbscr-lim-removal : improper removal ont card - ont-sbscr-lim-fail : ont card failure - ont-sbscr-lim-svc-mis : ont service mismatch for provisioned onu card - ont-sbscr-lim-port-mis: port mismatch btw actual and planned ont card - ont-svc-video-conf-mis: config request failure for video service - ont-svc-video-pw-high : high power level for rf video signal - ont-svc-video-pw-low : low power level for rf video signal - ont-svc-pots-svc-mis : ont service mismatch for provisioned pots - ont-svc-pots-rtcp-lost: pots realtime transport control protocol stream lost - ont-svc-pots-icnf-subs: pots line iconfig subscription failure - ont-svc-pots-icnf-ntfy: pots line iconfig notify failure - ont-svc-pots-icnf-http: pots line iconfig http failure - ont-svc-pots-sip-reg : pots line sip registration failure - ont-svc-pots-sip-inv : pots line sip invite request failure - ont-svc-pots-sip-subsc: pots line sip subscribe failure - ont-svc-pots-sip-mt-tc: pots line sip message timeout threshold crossed - ont-svc-pots-pk-los-tc: pots line rtp bearer packets loss threshold crossed - ont-svc-pots-jitter-tc: pots line rtp jitter threshold crossed - ont-svc-pots-subs-dns : pots line iconfig subscription failed (DNS) - ont-svc-pots-subs-tcp : pots line iconfig subscription failed (TCP) - ont-svc-pots-subs-tls : pots line iconfig subscription failed (TLS) - ont-svc-pots-subs-auth: pots line iconfig subscription failed authentication - ont-svc-pots-subs-to : pots line iconfig subscription failed (timeout) - ont-svc-pots-subs-err : pots line iconfig subscription response error - ont-svc-pots-not-to : pots line iconfig notification failed (timeout) - ont-svc-pots-notref-to: pots line iconfig notification refresh failed - ont-svc-pots-not-mal : pots line iconfig notification failed (malformed) - ont-svc-pots-not-rej : pots line iconfig notification rejected - ont-svc-pots-http-dns : pots line iconfig doc retrieval failed (DNS) - ont-svc-pots-http-tcp : pots line iconfig doc retrieval failed (TCP) - ont-svc-pots-http-tls : pots line iconfig doc retrieval failed (TLS) - ont-svc-pots-http-auth: pots line iconfig doc retrieval failed	

name	Type	Description
	(authentication) - ont-svc-pots-http-to : pots line iconfig doc retrieval failed (timeout) - ont-svc-pots-http-err : pots line iconfig doc retrieval response error - ont-svc-pots-http-mal : pots line iconfig doc retrieval failed (malformed) - ont-svc-pots-insuff : pots line iconfig service failed (insufficient data) - ont-svc-pots-poos : pots ports out of service - ont-svc-lan-mismatch : ont service mismatch for lan - ont-svc-lan-loss-sig : loss of signal on an ethernet port interface - ont-svc-enet-poos : Ethernet Ports out of Service - ont-svc-ces-ds1-mis : ont service mismatch for provisioned ces ds1 - ont-svc-ces-ds1-los : loss of signal at ds1 interface - ont-svc-ces-ds1-lof : loss of frame at ds1 interface - ont-svc-ces-ds1-rair : receiving rai at ds1 interface - ont-svc-ces-ds1-ais : receiving ais at ds1 interface - ont-svc-ces-ds1-lnlpbk: receiving line loopback at ds1 interface - ont-svc-ces-ds1-tmlpbk: receiving terminal loopback at ds1 interface - ont-svc-ces-e1-mis : ont service mismatch for provisioned ces e1 - ont-svc-ces-e1-los : loss of signal at e1 interface - ont-svc-ces-e1-lof : loss of frame at e1 interface - ont-svc-ces-e1-rair : receiving rai at e1 interface - ont-svc-ces-e1-ais : receiving ais at e1 interface - ont-svc-voip-cnf-file : voice configuration file error - ont-svc-voip-svc-mis : service mismatch for provisioned client service - ont-svc-voip-gw-comm : voice gateway communication failure - ont-svc-voip-dhcp-fail: voice dhcp server failure - ont-svc-voip-icnf-sub: voice iconfig subscription failure - ont-svc-voip-icnf-ntfy: voice iconfig notify failure - ont-svc-voip-icnf-http: voice iconfig http failure - ont-svc-voip-dhcp-to : DHCP server retransmissions timed out - ont-svc-voip-dhcp-mal : DHCP response was malformed - ont-svc-voip-dhcp-noad: DHCP server failed to issue the required parameters - ont-svc-voip-dhcp-leas: DHCP Server failure due to problem in lease renewal - ont-svc-voip-sub: iConfig Subscription failure due to DNS problem - ont-svc-voip-sub-tcp : iConfig Subscription failure due to TCP socket problem - ont-svc-voip-sub-tls : iConfig Subscription failure due to TLS session problem - ont-svc-voip-sub-auth: iConfig Subscription failure due to authentication error - ont-svc-voip-sub-to : iConfig Subscription failure due to retransmission timeout - ont-svc-voip-sub-err : iConfig Subscription failure due to	

name	Type	Description
	response error - ont-svc-voip-not-to : iConfig Notify response timeout for new subscription - ont-svc-voip-notref-to: iConfig Notify response timeout for subscription refresh - ont-svc-voip-not-mal : iConfig Notify response is malformed - ont-svc-voip-not-rej : iConfig subscription request rejected by configuration server - ont-svc-voip-http-dns : VOIP client can't retrieve config doc due to DNS problem - ont-svc-voip-http-tcp : VOIP client can't retrieve config doc due to TCP socket problem - ont-svc-voip-http-tls : VOIP client can't retrieve config doc due to TLS session problem - ont-svc-voip-http-auth: VOIP client can't retrieve config doc due to auth error - ont-svc-voip-http-to : VOIP client can't retrieve config doc due to re-tx timeout - ont-svc-voip-http-err : VOIP client can't retrieve config doc due to response error - ont-svc-voip-http-mal : iConfig configuration document is malformed - ont-svc-voip-subs-refr: iConfig Subscription refresh error - ont-svc-voip-not-refr : iConfig Notify response for refresh subscribe failed - ont-svc-voip-icfg-err : iConfig Configuration Error - ont-svc-v-ani-conf-mis: config request failure for video ani service - ont-svc-v-ani-loss-sig: video loss of signal on ani - ont-svc-v-ani-lv-high : high video optical signal level - ont-svc-v-ani-lv-low : low video optical signal level - ont-svc-pwe-mismatch : service mismatch for provisioned pseudowire - ont-svc-pwe-reordr-lof: pseudowire reordering and loss of frame - ont-svc-pwe-jitt-buf-o: pseudowire jitter buffer overrun - ont-svc-pwe-jitt-buf-u: pseudowire jitter buffer underrun - ont-svc-pwe-malf-frms : pseudowire malformed frames - ont-svc-pwe-late-frms : pseudowire late frames - ont-svc-pwe-link-loss : pseudowire link loss - ont-svc-pwe-arp-fail : pseudowire arp failure - ont-svc-xdsl-mismatch : service mismatch for provisioned xdsl - ont-svc-xdsl-ne-lof : near end loss of frame - ont-svc-xdsl-ne-los : near end loss of signal - ont-svc-xdsl-ne-line : near end line init - ont-svc-xdsl-ne-lol : near end loss of link - ont-svc-xdsl-fe-lof : far end loss of frame - ont-svc-xdsl-fe-los : far end loss of signal - ont-svc-xdsl-fe-lop : far end loss of power - ont-svc-xdsl-cnf-err : xdsl provisioning error - ont-svc-xdsl-ne-es-tc : near end errored seconds threshold crossed - ont-svc-xdsl-ne-ses-tc: near end severe errored seconds threshold crossed - ont-svc-xdsl-ne-uas-tc: ear end unavailable seconds	

name	Type	Description
	threshold crossed - ont-svc-xdsl-fe-es-tc : far end errored seconds threshold crossed - ont-svc-xdsl-fe-ses-tc: far end severe errored seconds threshold crossed - ont-svc-xdsl-fe-uas-tc: far end unavailable seconds threshold crossed - ont-tc-rx-los-frag-tc : rx loss of gem fragments threshold crossed - ont-tc-tx-los-frag-tc : tx loss of gem fragments threshold crossed - ont-tc-bad-gem-hd-tc : bad gem header threshold crossed - ont-uni-ds-drpdp-fr-tc : downstream l2 dropped frames threshold crossed - ont-uni-up-drpdp-fr-tc : upstream l2 dropped frames threshold crossed - ont-uni-ds-crc-fr-tc : downstream l2 rx crc error frames threshold crossed - ont-uni-up-crc-fr-tc : upstream l2 rx crc error frames threshold crossed - ont-cpu-util-tca : ONT CPU utilization threshold crossed - ont-mem-util-tca : ONT memory utilization threshold crossed - pim-neighbor-down : pim neighbor down - pim-max-mcroutes : maximum routes reached - li-traffic-disabled : lawful interception of traffic disabled - li-bandwidth-limit : lawful intercept reached bandwidth limit - li-out-of-res : lawful intercept out of resources - otdr-cap-mismatch : otdr capability mismatch - login-successful : successful login via management access - login-failure : invalid login via management access has crossed the threshold limit - cfm-defrdiccm : rdi bit in ccm received - cfm-defmacstatus : ccm mac error status - cfm-defremoteccm : missing ccm from mep - cfm-deferrorccm : invalid ccm received - cfm-defxconccm : unexpected ccm received - cfm-defais : ethernet ais received - bfd-session-down : bfd session down - bfd-max-resource : bfd maximum resources reached - bfd-stale-entry : bfd stale entry present - tca-outputbw : tca output bandwidth - tca-inputbw : tca input bandwidth - tca-rxcrcalign : tca rxrc align errors - tca-txcrcalign : tca txrc align errors - tca-txcollisions : tca tx collision errors - tca-outputhighbw : tca output high bandwidth - tca-outputmedbw : tca output medium bandwidth - tca-outputlowbw : tca output low bandwidth - tca-inputhighbw : tca input high bandwidth - tca-inputmediumbw : tca input medium bandwidth - tca-inputlowbw : tca input low bandwidth - eth-cfm-defrdiccm : rdi bit in ccm received - eth-cfm-defmacstatus : ccm mac error status - eth-cfm-defremoteccm : missing ccm from mep - eth-cfm-deferrorccm : invalid ccm received	

100 Alarm Delta Log Status Commands

name	Type	Description
	- eth-cfm-defxconccm : unexpected ccm received - rsvp-neighbor-down : rsvp neighbor down - rsvp-instance-down : rsvp instance down - eth-ring-path-block : eth ring path block - ai-platform-down : Application Intelligence Platform down - ai-appl-install-fail : Application installation failure - ip-assign-fail : Dhcp assigned address failure - ont-tr069-serv-mis : ont tr069 server config mismatch - ont-snmp-mis : ont snmp agent config mismatch - bsf-dhcpv4 : bulksync failed for dhcpv4 - bsf-dhcpv6 : bulksync failed for dhcpv6 - bsf-pon : bulksync failed for pon - bsf-vbridge : bulksync failed for vlan-bridge - bsf-qos : bulksync failed for qos - bsf-igmp : bulksync failed for igmp - bsf-lxfwd : bulksync failed for lxfwd - prot-not-available : no protection not available - prot-switchover-fail : port switch over failed - efm-oam-cpelinkfault : EFM-OAM CPE link fault - efm-oam-cpedyinggasp : EFM-OAM CPE dying gasp - efm-oam-cpecrevt : EFM-OAM CPE critical event - ont-loopdetect : ont loop detect - alm-tbl-overflow : alarm table has overflowed - auto-switch-status : auto-switch status - auswqueuefullatm : auto-switch queue Full for ATM - auswbkpfailatm : auto-switch config data backup failed for ATM - auswrecfgfailatm : auto-switch fallback reconfiguration failed for ATM - auswdataunatm : auto-switch backup config data unavailable for ATM - auswqueuefulptm : auto-switch queue Full for PTM - auswbkpfailptm : auto-switch config data backup failed for PTM - auswrecfgfailptm : auto-switch fallback reconfiguration failed for PTM - auswdataunptm : auto-switch backup config data unavailable for PTM - auswbakpfailatm : auto-switch backup fail for ATM - chpr-com-fail : channel pair communication failure on olt - chpr-tx-fail : transmitter failure on channel pair - chpr-unprov-ont : unprovisioned ont on channel pair - chpr-prov-mismatch : mismatch btw equipment and provisioning pon attributes - chpr-loss-sig : channel pair loss of signal - chpr-diagnostic : channel pair diagnostic test active - chpr-loid-conflict : loid conflict ont on channel pair - chpr-loid-pwd-err : loid password error ont on channel pair - chpr-stk-laser-dis : stuck laser disabled on channel pair - chpr-sfp-mismatch : channel pair sfp mismatch - chpr-rng-mismatch : channel pair ranging mismatch - chpr-alien-test : channel pair alien diagnostic test active - chpr-alien-detect : channel pair alien detect active - chpr-deact-hightca : channel pair deactivated ont hightca threshold crossed - chpr-deact-lowtca : channel pair deactivated ont lowtca threshold crossed	

name	Type	Description
	- chpr-dp-integ : channel pair data path integrity failure - olt-chpr-tc-err-frag : channelpair errored fragments threshold crossed - olt-chpr-up-bw-tca : OLT CHANNELPAIR upstream bandwidth TCA - olt-chpr-down-bw-tca : OLT CHANNELPAIR downstream bandwidth TCA - cfg-dld-fail : download of configure file to ont failed - cfg-act-fail : activate the passive config file failed - cfg-dld-ip : ont configure file download in progress - cfg-ver-mismatch : the planned configure file does not match the active configure file - cfg-file-missing : ont configure file missing or has an error - cfg-verctrl-err : ont configure file version control error - cfg-not-supported : ont not support the configure file download function - ont-prot-not-available: ONT/ONU protection not available - ont-gen-temp-low : ONU SFP temperature is lower than configured Alarm low threshold - ont-gen-volt-low : ONU SFP Voltage is lower than configured Alarm low threshold - ont-gen-tx-pwr-high : ONU SFP Tx power is higher than configured Alarm high threshold - ont-gen-bias-low : ONU SFP bias is lower than configured Alarm low threshold - ont-gen-rx-hwarn : ONU SFP Rx power is higher than warn threshold - ont-gen-rx-lwarn : ONU SFP Rx power is lower than warn threshold - ont-gen-tx-hwarn : ONU SFP Tx power is higher than warn threshold - ont-gen-tx-lwarn : ONU SFP Tx power is lower than warn threshold - ont-gen-temp-hwarn : ONU SFP temperature is higher than warn threshold - ont-gen-temp-lwarn : ONU SFP temperature is lower than warn threshold - ont-gen-volt-hwarn : ONU SFP Voltage is higher than warn threshold - ont-gen-volt-lwarn : ONU SFP Voltage is lower than warn threshold - ont-gen-bias-hwarn : ONU SFP bias is higher than warn threshold - ont-gen-bias-lwarn : ONU SFP bias is lower than warn threshold - sfu-sup2-temp-low : SFU ONT - SFP temperature is lower than configured Alarm low threshold - sfu-sup2-volt-low : SFU ONT - SFP Voltage is lower than configured Alarm low threshold - sfu-sup2-tx-high : SFU ONT - SFP tx power is higher than configured Alarm high threshold - sfu-sup2-bias-low : SFU ONT - SFP bias is lower than configured Alarm low threshold - sfu-sup2-rx-hwarn : SFU ONT - SFP rx power is higher than configured warn threshold - sfu-sup2-rx-lwarn : SFU ONT - SFP rx power is lower than configured warn threshold	

100 Alarm Delta Log Status Commands

name	Type	Description
	- sfu-sup2-tx-hwarn : SFU ONT - SFP tx power is higher than configured warn threshold - sfu-sup2-tx-lwarn : SFU ONT - SFP tx power is lower than configured warn threshold - sfu-sup2-temp-hwarn : SFU ONT - SFP temperature is higher than configured warn threshold - sfu-sup2-temp-lwarn : SFU ONT - SFP temperature is lower than configured warn threshold - sfu-sup2-volt-hwarn : SFU ONT - SFP Voltage is higher than configured warn threshold - sfu-sup2-volt-lwarn : SFU ONT - SFP Voltage is lower than configured warn threshold - sfu-sup2-bias-hwarn : SFU ONT - SFP bias is higher than configured warn threshold - sfu-sup2-bias-lwarn : SFU ONT - SFP bias is lower than configured warn threshold - soho-sup2-temp-low : SOHO ONT - SFP temperature is lower than configured Alarm low threshold - soho-sup2-volt-low : SOHO ONT - SFP Voltage is lower than configured Alarm low threshold - soho-sup2-tx-high : SOHO ONT - SFP tx power is higher than configured Alarm low threshold - soho-sup2-bias-low : SOHO ONT - SFP bias is lower than configured Alarm low threshold - soho-sup2-rx-hwarn : SOHO ONT - SFP rx power is higher than warn threshold - soho-sup2-rx-lwarn : SOHO ONT - SFP rx power is lower than warn threshold - soho-sup2-tx-hwarn : SOHO ONT - SFP tx power is higher than warn threshold - soho-sup2-tx-lwarn : SOHO ONT - SFP tx power is lower than warn threshold - soho-sup2-temp-hwarn : SOHO ONT - SFP temperature is higher than warn threshold - soho-sup2-temp-lwarn : SOHO ONT - SFP temperature is lower than warn threshold - soho-sup2-volt-hwarn : SOHO ONT - SFP Voltage is higher than warn threshold - soho-sup2-volt-lwarn : SOHO ONT - SFP Voltage is lower than warn threshold - soho-sup2-bias-hwarn : SOHO ONT - SFP bias is higher than warn threshold - soho-sup2-bias-lwarn : SOHO ONT - SFP bias is lower than warn threshold - mdu-sup2-temp-low : MDU ONT - SFP temperature is lower than configured alarm low threshold - mdu-sup2-volt-low : MDU ONT - SFP Voltage is lower than configured alarm low threshold - mdu-sup2-tx-high : MDU ONT - SFP tx power is higher than configured alarm low threshold - mdu-sup2-bias-low : MDU ONT - SFP bias is lower than configured alarm low threshold - mdu-sup2-rx-hwarn : MDU ONT - SFP rx power is higher than warn threshold - mdu-sup2-rx-lwarn : MDU ONT - SFP rx power is lower than warn threshold - mdu-sup2-tx-hwarn : MDU ONT - SFP tx power is higher	

name	Type	Description
	than warn threshold - mdu-sup2-tx-lwarn : MDU ONT - SFP tx power is lower than warn threshold - mdu-sup2-temp-hwarn : MDU ONT - SFP temperature is higher than warn threshold - mdu-sup2-temp-lwarn : MDU ONT - SFP temperature is lower than warn threshold - mdu-sup2-volt-hwarn : MDU ONT - SFP voltage is higher than warn threshold - mdu-sup2-volt-lwarn : MDU ONT - SFP voltage is lower than warn threshold - mdu-sup2-bias-hwarn : MDU ONT - SFP bias is higher than warn threshold - mdu-sup2-bias-lwarn : MDU ONT - SFP bias is lower than warn threshold - cust-alm1 : customizable alarm 1 - cust-alm2 : customizable alarm 2 - cust-alm3 : customizable alarm 3 - cust-alm4 : customizable alarm 4 - cust-alm5 : customizable alarm 5 - cust-alm6 : customizable alarm 6 - cust-alm7 : customizable alarm 7 - cust-alm8 : customizable alarm 8 - cust-alm9 : customizable alarm 9 - cust-alm10 : customizable alarm 10 - cust-alm11 : customizable alarm 11 - cust-alm12 : customizable alarm 12 - cust-alm13 : customizable alarm 13 - cust-alm14 : customizable alarm 14 - cust-alm15 : customizable alarm 15 - cust-alm16 : customizable alarm 16 - cust-alm17 : customizable alarm 17 - cust-alm18 : customizable alarm 18 - cust-alm19 : customizable alarm 19 - cust-alm20 : customizable alarm 20 - cust-alm21 : customizable alarm 21 - cust-alm22 : customizable alarm 22 - cust-alm23 : customizable alarm 23 - cust-alm24 : customizable alarm 24 - cust-alm25 : customizable alarm 25 - cust-alm26 : customizable alarm 26 - cust-alm27 : customizable alarm 27 - cust-alm28 : customizable alarm 28 - cust-alm29 : customizable alarm 29 - cust-alm30 : customizable alarm 30 - cust-alm31 : customizable alarm 31 - ethernet-ring-pthfwst : ethernet ring path forward state - ethernet-ring-fop-to : ethernet ring fop-to failure of protocol timeout - ethernet-ring-fop-pm : ethernet ring fop-pm failure of protocol provision mismatch - fpm-depletion : failsafe fpm depletion - exp-seizureack : Channel was blocked due to failure in the reception of the SEIZURE ACK signal - exp-disconack : Channel was blocked due to failure in the reception of the DISCONNECTION ACK signal - exp-forcerelack : Channel was blocked due to failure in the	

100 Alarm Delta Log Status Commands

name	Type	Description
	reception of the BACKWARD DISCONNECTION ACK signal - packet-loss : Pseudo Wire entered the Packet loss state - remote-packet-loss : Remote Packet loss detected - no-dsp-resource : DSP resource allocation failed - la-down : Link aggregation group link-status is down - la-standby-na : Cross-lt lag on standby slot part is not available - la-switch-fail : Cross-lt lag fail to do switchover - la-degrade : Link aggregation group degrade - melt-board-reset : MELT board reset - board-shelf-mismatch : board type and shelf type mismatch - fcs-thresh-exceed : FCS counter threshold exceeded	
state	Parameter type: <Alarm::AlarmState> (active non-active) Possible values: - active : alarm is active - non-active : alarm is not active	reflect's the state of the alarm as either active or non-active. <i>This element is always shown.</i>
last-updated-on	Parameter type: <Sys::timeInSecs> - the time (yyyy-mm-dd:hour:minutes:secs) - unit: UTC	network time in seconds when the alarm was logged. <i>This element is always shown.</i>
additional-info	Parameter type: <Alarm::AdditionalInfo> - string to identify the owner (example: Tom) - length: x<=512	AdditionalInfo <i>This element is always shown.</i>

Only Show Details: warning alarm table related generic information		
name	Type	Description
changes	Parameter type: <Counter> - 32 bit counter	total number of changes of all reported alarms with a severity level warning since startup. <i>This element is only shown in detail mode.</i>
last-entry-id	Parameter type: <SignedInteger> - a signed integer	last entry that was added to the warning delta log. <i>This element is only shown in detail mode.</i>
last-reset	Parameter type: <Sys::Time> - the time (yyyy-mm-dd:hour:minutes:secs) - unit: UTC	network time in seconds indicating when the warning delta log was last reset. <i>This element is only shown in detail mode.</i>
log-overflowed	Parameter type: <Alarm::OverflowStatus> (yes no) Possible values: - yes : buffer has overflowed - no : no buffer overflow	specifies whether the warning delta log is overflowed or not. <i>This element is only shown in detail mode.</i>

100.5 Minor Alarm Delta Log Status Command

Command Description

This command displays alarm values for all reported alarms with a severity level minor.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

> show alarm delta-log minor [(index)]

Command Parameters

Table 100.5-1 "Minor Alarm Delta Log Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	delta log alarm table index

Command Output

Table 100.5-2 "Minor Alarm Delta Log Status Command" Display parameters

Specific Information		
name	Type	Description
type	Parameter type: <Alarm::alarmIndexExt> (all xtca-ne-es xtca-ne-ses xtca-ne-uas xtca-ne-day-es xtca-ne-day-ses xtca-ne-day-uas xtca-fe-es xtca-fe-ses xtca-fe-uas xtca-fe-day-es xtca-fe-day-ses xtca-fe-day-uas xtca-leftrs xtca-day-leftrs xtca-fe-leftrs xtca-fe-day-leftrs xtca-auto-port-reset xtca-reinit	unique id for an alarm. <i>This element is always shown.</i>

100 Alarm Delta Log Status Commands

name	Type	Description
	xtca-day-reinit	
	xdsl-ne-los	
	xdsl-ne-lof	
	xdsl-ne-lom	
	xdsl-ne-ese	
	xdsl-act-cfg-error	
	xdsl-act-not-feas	
	xdsl-up-br-reach	
	xdsl-ne-ncd	
	xdsl-ne-lcd	
	xdsl-fe-los	
	xdsl-fe-lof	
	xdsl-fe-lpr	
	xdsl-fe-lol	
	xdsl-fe-lom	
	xdsl-fe-ese	
	xdsl-fe-upbo-vio	
	xdsl-fe-cpe-pol	
	xdsl-tpstc-mis	
	xdsl-act-comm	
	xdsl-act-modem	
	xdsl-do-br-reach	
	xdsl-fe-ncd	
	xdsl-fe-lcd	
	xdsl-frtx-init-fail	
	xdsl-vect-dle	
	xdsl-fe-mis-peer-35b	
	vectline-xtc-var-vict	
	vectline-xtc-var-dist	
	vectline-corp-errf	
	vect-cpe-cap-mismatch	
	vectline-conf_notfeas	
	vect-vp-lt-mismatch	
	vect-inv-qsf	
	vect-vp-lt-fail	
	vect-no-gain-at-init	
	sw-rollback	
	db-rollback	
	xvps-inv-dbase	
	inv-cde-file	
	miss-cde-file	
	cde-hash-error	
	auto-fetch-failure	
	low-disk-space	
	cell-discard-up	
	cell-discard-down	
	persist-data-loss	
	mac-conflict	
	vmac-full	
	sntp-comm-lost	
	preferred-mode	
	timing-reference	
	nt-disk-95%full	
	shub-loc	
	cf-error	
	back-pnl-inv	
	ihub-conf-loss	

name	Type	Description
	rack-power rack-fan-unit1 rack-fan-unit2 shelf-mismatch shelf-missing shelf-install-missing door ac-power-fail board-mismatch waiting-for-sw temp-exceeded backplane-data-failure temp-shutdown board-missing board-instl-missing board-init board-reset-prot sem-power-fail sem-ups-fail board-reset-cf vlan-assign-fail vsa-info-invalid auth-mac-conflict user-pwd-fault up-plan-bitrate up-min-bitrate up-config-not-feas down-plan-bitrate down-min-bitrate down-config-not-feas non-bonding-cpe multiple-cpes register group-incomplete host-sfp-los host-sfp-tx-fail host-sfp-not-prst host-sfp-inv-id host-sfp-ctrl-fail host-sfp-rmtlt host-sfp-mismatch host-sfp-incompt exp-sfp-los exp-sfp-tx-fail exp-sfp-not-prst exp-sfp-inv-id exp-sfp-ctrl-fail exp-sfp-1-los exp-sfp-2-los ext-qsfv-invl tx-power-high-alarm tx-power-low-alarm rx-power-high-alarm rx-power-low-alarm tx-biascur-high-alarm tx-biascur-low-alarm volt-high-alarm	

100 Alarm Delta Log Status Commands

name	Type	Description
	volt-low-alarm	
	temp-high-alarm	
	temp-low-alarm	
	tx-power-high-warn	
	tx-power-low-warn	
	rx-power-high-warn	
	rx-power-low-warn	
	tx-biascur-high-warn	
	tx-biascur-low-warn	
	volt-high-warn	
	volt-low-warn	
	temp-high-warn	
	temp-low-warn	
	onu-unprovisioned	
	signal-loss	
	bitrate-high	
	opmodule-mismatch	
	key-fail-one-churn	
	key-fail-three-churn	
	oam-discov-fail	
	report-timeout	
	total-packets-exceed	
	arp-packets-exceed	
	dhcp-packets-exceed	
	igmp-packets-exceed	
	pppoe-packets-exceed	
	nd-packets-exceed	
	icmpv6-packets-exceed	
	mld-packets-exceed	
	dhcpv6-packets-exceed	
	cfm-packets-exceed	
	dsx1-serdes-fail	
	dsx1-tributary1-fail	
	dsx1-tributary2-fail	
	dsx1-los-fail	
	dsx1-ais-sync	
	dsx1-lof-sync	
	dsx1-los-sync	
	dsx1-deg-fail	
	dsx1-rei-from-liu	
	dsx1-rdi-from-liu	
	dsx1-crc6-from-liu	
	dsx1-crc4-from-liu	
	dsx1-crc4-th-from-liu	
	dsx1-ais-from-liu	
	dsx1-los-from-liu	
	dsx1-lof-from-liu	
	dsx1-lomf-from-liu	
	dsx1-rei-from-iwf	
	dsx1-rdi-from-iwf	
	dsx1-crc6-from-iwf	
	dsx1-crc4-from-iwf	
	dsx1-crc4-th-from-iwf	
	dsx1-ais-from-iwf	
	dsx1-los-from-iwf	
	dsx1-lof-from-iwf	
	dsx1-lomf-from-iwf	

name	Type	Description
	pppce-trans-15min-tca pppce-sess-15min-tca pppce-trans-1day-tca pppce-sess-1day-tca custom1 custom2 custom3 custom4 custom5 he-custom1 he-custom2 he-custom3 he-custom4 he-custom5 he-custom6 custom6 custom7 custom8 custom9 custom10 custom11 custom12 custom13 custom14 custom15 custom16 custom17 loss-swo-cap ping-check-fail der-temp1 der-temp2 der-temp3 der-temp4 der-temp5 der-temp6 der-temp7 der-temp8 der-temp9 der-temp10 der-temp11 der-temp12 der-temp13 der-temp14 der-temp15 der-temp16 der-temp17 der-temp18 der-temp19 der-temp20 der-temp21 der-temp22 der-temp23 der-temp24 der-temp25 der-temp26 der-temp27 der-temp28	

100 Alarm Delta Log Status Commands

name	Type	Description
	der-temp29	
	der-temp30	
	der-temp31	
	der-spa1	
	der-spa2	
	der-spa3	
	der-spa4	
	der-spa5	
	der-spa6	
	der-spa7	
	der-spa8	
	der-spa9	
	der-spa10	
	der-spa11	
	der-spa12	
	der-spa13	
	der-spa14	
	der-spa15	
	der-spa16	
	der-spa17	
	der-spa18	
	der-spa19	
	der-spa20	
	der-spa21	
	der-spa22	
	der-spa23	
	der-spa24	
	der-spa25	
	der-spa26	
	der-spa27	
	der-spa28	
	der-spa29	
	der-spa30	
	der-spa31	
	apsf-alarm	
	custextalarm1	
	custextalarm2	
	custextalarm3	
	custextalarm4	
	custextalarm5	
	pluginfan	
	plugin-dc-a	
	plugin-dc-b	
	plugin-dg	
	ntr-a-loss	
	ntr-b-loss	
	xvps-conf-loss	
	mac-entry-nofree	
	fibre-conn-mismatch	
	link-cap-mismatch	
	eqpt-cap-mismatch	
	ctrl-dnld-failure	
	melt-hw-issue	
	melt-board-reset	
	board-shelf-mismatch	
	mgnt-type-mismatch	
	fileserv-unavail	

name	Type	Description
	shdsl-n-loopback	
	shdsl-c-loopback	
	shdsl-conferr	
	shdsl-atm-lcd	
	shdsl-lpr	
	shdsl-secu-err	
	shdsl-dev-fault	
	shdsl-atm-ncd	
	shdsl-n-losw	
	shdsl-c-losw	
	shdsl-n-aten	
	shdsl-c-aten	
	shdsl-n-snr	
	shdsl-c-snr	
	shdsl-n-dccont	
	shdsl-c-dccont	
	shdsl-c-actfail	
	e1-fe-rai	
	e1-ne-rai	
	e1-fe-ais	
	e1-ne-ais	
	e1-lof	
	e1-los	
	e1-loopback	
	ima-grp-fe-su	
	ima-grp-fe-cfg	
	ima-grp-ne-cfg	
	ima-grp-fe-nl	
	ima-grp-ne-nl	
	ima-grp-fe-blk	
	ima-lnk-lif	
	ima-lnk-lods	
	ima-lnk-misc	
	ima-lnk-rfi	
	ima-lnk-fault	
	ima-lnk-txblk	
	ima-lnk-rxblk	
	bad-digitmap	
	dhcp-unreach	
	dhcp-no-srv	
	dhcp-inv-srv	
	norpniewithsoftdsp	
	unknown-sub	
	ground-key	
	port-hightemp	
	port-jbfltca	
	reg-domainname	
	reg-auth	
	reg-timeout	
	reg-srvfailresp	
	inv-domainname	
	inv-auth	
	inv-timeout	
	inv-srvfailresp	
	subs-srvfailresp	
	subs-domainname	
	subs-auth	

100 Alarm Delta Log Status Commands

name	Type	Description
	subs-refreshfail subs-inittimeout emergency-call e1sip-reg-domainname e1sip-reg-auth e1sip-reg-timeout e1sip-reg-srvfailresp e1sip-inv-domainname e1sip-inv-auth e1sip-inv-timeout e1sip-inv-srvfailresp e1sip-emergency-call e1l1tf-ais-signal e1l1tf-los-signal e1l1tf-rai-signal e1sip-misconfig-mgc10 e1sip-nsmprf-missed e1l1l1tf-recv-ais e1l1l1tf-recv-los e1l1l1tf-recv-rai transport-mismatch dns-lookup-failure none-dns-srv no-dns-srv none-srv no-srv reg-srv-unreach proxy-srv-unreach dhcp-srv-unreach fo-trigger fb-trigger du-trigger ssp-missing dns-pool-exceed lsa-fo-trigger reg-domainname-sec reg-auth-sec reg-timeout-sec reg-srvfailresp-sec inv-domainname-sec inv-auth-sec inv-timeout-sec inv-srvfailresp-sec subs-srvfailresp-sec subs-domainname-sec subs-auth-sec subs-refreshfail-sec subs-inittimeout-sec emergency-call-sec fanout up-overflow upobc-overflow dwobc-overflow dw-overflow lwpri-overflow queue-drop queue-load	

name	Type	Description
	queue-peak-usage mgc-unreachable failover-to-esamgc sgc-unreachable lcard-unreach-srvcard lcard-type-mismatch meg-unknown-sub meg-ground-key meg-high-temp meg-act-fail meg-over-current line-showering low-qos-packetloss low-qos-jitter low-qos-delay sig-brd-persist-loss sig-brd-disk-full sig-brd-db-rollback mg-overload meg-unknown-sub-sec line-showering-sec loss-env-mon etca-los etca-fcs etca-day-los etca-day-fcs etca-rx-octets etca-tx-octets etca-day-rx-octets etca-day-tx-octets user-sfp-los user-sfp-tx-fail user-sfp-not-prst user-sfp-inv-id user-sfp-t-exceed user-sfp-mismatch uplink-sfp-los uplink-sfp-tx-fail uplink-sfp-not-prst uplink-sfp-inv-id uplink-sfp-t-exceed uplink-sfp-mismatch loss-lmswp-cap inv-xvps-pair-data network-power-loss hw-fault bat-miss bat-fail bat-low bat-a-fail bat-b-fail ac-vol-out-range network-power-loss-b sem-ac-power-fail sem-ups-low-volt dc-a-fail dc-b-fail	

100 Alarm Delta Log Status Commands

name	Type	Description
	- plan-power-mismatch - water-seepage-in-box - sealed-box-open - dc-a-vol-out-range - dc-b-vol-out-range - inlet-temp-major - inlet-temp-critical - psu-fail-crit - psu-a-fail-presence - psu-a-fail-vin-ac-nok - psu-a-fail-vin-uv - psu-a-fail-vin-ov - psu-a-fail-vout-uv - psu-a-fail-vout-ov - psu-a-fail-iout-oc - psu-a-fail-overtemp - psu-b-fail-presence - psu-b-fail-vin-ac-nok - psu-b-fail-vin-uv - psu-b-fail-vin-ov - psu-b-fail-vout-uv - psu-b-fail-vout-ov - psu-b-fail-iout-oc - psu-b-fail-overtemp - synce-fail - bits-fail - bits-output-shutoff - ieee1588-fail - gnss-fail - ieee1588-hybrid-fail - signal-loss - signal-efd - esmc-loss - bits-output-exceed - ql-input-exceed - holdover - lti - tod-reference-fail - internal-clk-fail - bgp-peer-down - bgp-routes-mid-limit - isis-adjacency-down - isis-adjacency-reject - isis-instance-down - ospf-lsa-limit - ospf-lsa-mid-limit - ospf-neighbor-down - ospf-instance-down - ospf3-lsa-limit - ospf3-lsa-mid-limit - ospf3-neighbor-down - ospf3-instance-down - rip-instance-down - lag-down - lagsubgrp-thresh-reach - lagsubgrp-switch-fail - no-unpinned-free-ports	

name	Type	Description
	general-arp-limit gen-switch-out-of-res ipv6-nc-limit dhcp-session-oor ihub-fdb-limit ihub-mac-limit l2fw-stp-exception l2fw-stp-root-guard vprn-routes-limit vprn-ipv6-routes-limit dhcpv6-lease-limit dhcpv4-lease-limit vpls-mfib-limit ihub-ipv6-dad-own ihub-ipv6-dad ihub-ipv6-dup-pd-route vpls-duplicate-mac vpls-fdb-limit vpls-self-duplic-mac vpls-sdp-self-dup-mac link-down link-lagport-add-fail link-conf-mismatch ihub-peer-comm ihub-sw-fail ihub-hw-fail ihub-link-fail ihub-proc-overload ihub-out-of-mem ntp-comm-lost ldp-instance-down ldp-session-down mpls-instance-down mpls-lsp-down mpls-lsp-path-down sdp-instance-down sdp-binding-down epipe-instance-down lldpmed-portcfg-mis lldpmed-mediapl-mis vlanport-svc-mismatch mcsrc-stream-lost eqptsupl-syslog-upload eqptsupl-ontsw-dnload cf-75%used cf-90%used olt-gen-pon-com-fail olt-gen-tx-fail olt-gen-unprov-ont olt-gen-pon-eqpt-prov olt-gen-pon-loss-sig olt-gen-pon-diagnostic olt-gen-lold-conflict olt-gen-lold-pwderr olt-gen-pon-alien-test olt-gen-alien-detect olt-gen-rng-mism	

100 Alarm Delta Log Status Commands

name	Type	Description
	olt-gen-sfp-mism	
	olt-gen-deact-hightca	
	olt-gen-deact-lowtca	
	olt-gen-dp-integ	
	olt-gen-ddr-fault	
	olt-pon-tc-err-frag-tc	
	olt-ont-tc-err-frag-tc	
	ont-ploam-loss-sig	
	ont-ploam-loss-ack	
	ont-ploam-loss-cd	
	ont-ploam-phy-eqpt-err	
	ont-ploam-startup-fail	
	ont-ploam-sig-degrade	
	ont-ploam-disabled	
	ont-ploam-err-msg	
	ont-ploam-inactive	
	ont-ploam-sig-fail	
	ont-ploam-dying-gasp	
	ont-ploam-deact-fail	
	ont-ploam-oam	
	ont-ploam-win-drift	
	ont-ploam-rdi	
	ont-ploam-loss-ks	
	ont-ploam-pwr-burst	
	ont-ploam-roq-disa	
	ont-ploam-diff-reach	
	ont-ploam-looc	
	sfu-ploam-loss-sig	
	sfu-ploam-loss-ack	
	sfu-ploam-loss-cd	
	sfu-ploam-phy-eqpt-err	
	sfu-ploam-startup-fail	
	sfu-ploam-sig-degrade	
	sfu-ploam-disabled	
	sfu-ploam-err-msg	
	sfu-ploam-inactive	
	sfu-ploam-sig-fail	
	sfu-ploam-dying-gasp	
	sfu-ploam-deact-fail	
	sfu-ploam-oam	
	sfu-ploam-win-drift	
	sfu-ploam-rdi	
	sfu-ploam-loss-ks	
	sfu-ploam-pwr-burst	
	sfu-ploam-roq-disa	
	sfu-ploam-diff-reach	
	sfu-ploam-looc	
	soho-ploam-loss-sig	
	soho-ploam-loss-ack	
	soho-ploam-loss-cd	
	soho-ploam-phy-eqpt-er	
	soho-ploam-startup-fai	
	soho-ploam-sig-degrade	
	soho-ploam-disabled	
	soho-ploam-err-msg	
	soho-ploam-inactive	
	soho-ploam-sig-fail	

name	Type	Description
	soho-ploam-dying-gasp	
	soho-ploam-deact-fail	
	soho-ploam-oam	
	soho-ploam-win-drift	
	soho-ploam-rdi	
	soho-ploam-loss-ks	
	soho-ploam-pwr-burst	
	soho-ploam-roq-disa	
	soho-ploam-diff-reach	
	soho-ploam-looc	
	mdu-ploam-loss-sig	
	mdu-ploam-loss-ack	
	mdu-ploam-loss-cd	
	mdu-ploam-phy-eqpt-err	
	mdu-ploam-startup-fail	
	mdu-ploam-sig-degrade	
	mdu-ploam-disabled	
	mdu-ploam-err-msg	
	mdu-ploam-inactive	
	mdu-ploam-sig-fail	
	mdu-ploam-dying-gasp	
	mdu-ploam-deact-fail	
	mdu-ploam-oam	
	mdu-ploam-win-drift	
	mdu-ploam-rdi	
	mdu-ploam-loss-ks	
	mdu-ploam-pwr-burst	
	mdu-ploam-roq-disa	
	mdu-ploam-diff-reach	
	mdu-ploam-looc	
	ont-hpna-ser-mis	
	ont-hpna-los-sig	
	ont-moca-svc-mis	
	ont-moca-link-los	
	ont-moca-min-bw	
	ont-moca-tca-rx-err-fr	
	ont-sipa-reg-nm-fail	
	ont-sipa-reg-rec-fail	
	ont-sipa-reg-con-fail	
	ont-sipa-reg-val-fail	
	ont-sipa-reg-mis	
	ont-vcd-cfg-nm-fail	
	ont-vcd-cfg-rech-fail	
	ont-vcd-cfg-conn-fail	
	ont-vcd-cfg-vali-fail	
	ont-vcd-cfg-auth-fail	
	ont-vcd-cfg-resp-tmout	
	ont-vcd-cfg-resp-err	
	ont-vcd-cfg-file-err	
	ont-vcd-sub-nm-fail	
	ont-vcd-sub-rech-fail	
	ont-vcd-sub-conn-fail	
	ont-vcd-sub-vali-fail	
	ont-vcd-sub-auth-fail	
	ont-vcd-sub-resp-tmout	
	ont-vcd-sub-resp-err	
	ont-vcd-reb-requ	

100 Alarm Delta Log Status Commands

name	Type	Description
	ont-vcd-mis ont-mgc-mis ont-mgc-timeout ont-sip-reg-dns ont-sip-reg-fail ont-sip-reg-timeout ont-sip-reg-err-resps ont-sip-inv-dns ont-sip-inv-auth ont-sip-inv-timeout ont-sip-inv-err ont-svc-pots-subs-refr ont-svc-pots-not-refr ont-svc-pots-icfg-err ont-veip-mismatch ont-ip-host-mismatch ont-ip-host-file ont-ip-host-ip-alloc olt-pon-up-bw-tca olt-pon-down-bw-tca ont-gen-omci-fail ont-gen-eqpt-selftest ont-gen-ac-pwr-fail ont-gen-bat-missing ont-gen-bat-low ont-gen-bat-fail ont-gen-phys-intrusion ont-gen-sw-dnload-f ont-gen-sw-dnload-p ont-gen-sw-act-fail ont-gen-eqpt-vers-mis ont-gen-sw-vers-mis ont-gen-us-rate-mis ont-gen-mdu-env1 ont-gen-mdu-env2 ont-gen-mdu-env3 ont-gen-nw-time-err ont-gen-opt-sig-high ont-gen-opt-sig-low ont-gen-eqpt-prov-sa ont-gen-eqpt-prov-nsa pon-t-txmcutilhi pon-t-txmcutilmd pon-t-txmcutillo pon-t-txtotutilhi pon-t-txtotutilmd pon-t-txtotutillo pon-t-rxtotutilhi pon-t-rxtotutilmd pon-t-rxtotutillo pon-t-dbacongperiodhi pon-t-dbacongperiodmd pon-t-dbacongperiodlo pon-t-txucdropfrmhi pon-t-txucdropfrmd pon-t-txucdropfrmlo pon-t-txmcdropfrmhi	

name	Type	Description
	pon-t-txmcdropfrmmd	
	pon-t-txmcdropfrmlo	
	pon-t-txbcdropfrmhi	
	pon-t-txbcdropfrmmd	
	pon-t-txbcdropfrmlo	
	pon-t-rxtotdropfrmhi	
	pon-t-rxtotdropfrmmd	
	pon-t-rxtotdropfrmlo	
	chpr-t-txmcutilhi	
	chpr-t-txmcutilmd	
	chpr-t-txmcutillo	
	chpr-t-txtotutilhi	
	chpr-t-txtotutilmd	
	chpr-t-txtotutillo	
	chpr-t-rxtotutilhi	
	chpr-t-rxtotutilmd	
	chpr-t-rxtotutillo	
	chpr-t-dbacongperiodhi	
	chpr-t-dbacongperiodmd	
	chpr-t-dbacongperiodlo	
	chpr-t-txucdropfrmhi	
	chpr-t-txucdropfrmmd	
	chpr-t-txucdropfrmlo	
	chpr-t-txmcdropfrmhi	
	chpr-t-txmcdropfrmmd	
	chpr-t-txmcdropfrmlo	
	chpr-t-txbcdropfrmhi	
	chpr-t-txbcdropfrmmd	
	chpr-t-txbcdropfrmlo	
	chpr-t-rxtotdropfrmhi	
	chpr-t-rxtotdropfrmmd	
	chpr-t-rxtotdropfrmlo	
	sfu-gen-omci-fail	
	sfu-gen-eqpt-selftest	
	sfu-gen-ac-pwr-fail	
	sfu-gen-bat-missing	
	sfu-gen-bat-low	
	sfu-gen-bat-fail	
	sfu-gen-sw-dnload-f	
	sfu-gen-sw-dnload-p	
	sfu-gen-sw-act-fail	
	sfu-gen-eqpt-vers-mis	
	sfu-gen-sw-vers-mis	
	sfu-gen-us-rate-mis	
	sfu-gen-tune-fail	
	sfu-gen-nw-time-err	
	sfu-gen-opt-sig-high	
	sfu-gen-opt-sig-low	
	sfu-gen-eqpt-prov-sa	
	sfu-gen-eqpt-prov-nsa	
	soho-gen-omci-fail	
	soho-gen-eqpt-selftest	
	soho-gen-ac-pwr-fail	
	soho-gen-bat-missing	
	soho-gen-bat-low	
	soho-gen-bat-fail	
	soho-gen-sw-dnload-f	

100 Alarm Delta Log Status Commands

name	Type	Description
	soho-gen-sw-dnload-p	
	soho-gen-sw-act-fail	
	soho-gen-eqpt-vers-mis	
	soho-gen-sw-vers-mis	
	soho-gen-us-rate-mis	
	soho-gen-tune-fail	
	soho-gen-nw-time-err	
	soho-gen-opt-sig-high	
	soho-gen-opt-sig-low	
	soho-gen-eqpt-prov-sa	
	soho-gen-eqpt-prov-nsa	
	mdu-gen-omci-fail	
	mdu-gen-eqpt-selftest	
	mdu-gen-ac-pwr-fail	
	mdu-gen-bat-missing	
	mdu-gen-bat-low	
	mdu-gen-bat-fail	
	mdu-gen-phys-intrusion	
	mdu-gen-sw-dnload-f	
	mdu-gen-sw-dnload-p	
	mdu-gen-sw-act-fail	
	mdu-gen-eqpt-vers-mis	
	mdu-gen-sw-vers-mis	
	mdu-gen-us-rate-mis	
	mdu-gen-tune-fail	
	mdu-gen-mdu-env1	
	mdu-gen-mdu-env2	
	mdu-gen-mdu-env3	
	mdu-gen-nw-time-err	
	mdu-gen-opt-sig-high	
	mdu-gen-opt-sig-low	
	mdu-gen-eqpt-prov-sa	
	mdu-gen-eqpt-prov-nsa	
	ont-gen-sw-dnload-file	
	ont-gen-fan-fail	
	ont-gen-high-temp	
	ont-gen-high-temp-ex	
	ont-gen-emergency-call	
	ont-gen-sw-version	
	ont-poe-exceed-max	
	ont-poe-overload-yell	
	ont-opti-malfunc	
	ont-gen-cfgdld-fail	
	ont-gen-rssi-mis	
	ont-gen-tx-pwr-low	
	ont-gen-temp-high	
	ont-gen-volt-high	
	ont-gen-bias-high	
	ont-loopdetect-mis	
	ont-olt-rx-pw-lo	
	ont-olt-rx-pw-hig	
	ont-olt-rx-pw-warnlo	
	ont-olt-rx-pw-warnhig	
	ont-gen-tod-out-sync	
	ont-gen-tune-fail	
	hgu-tr069-param-fail	
	ont-gen-tod-mismatch	

name	Type	Description
	sfu-sup-sw-file-error	
	sfu-sup-fan-failure	
	sfu-sup-temp-high-warn	
	sfu-sup-temp-shutoff	
	sfu-sup-emergency-call	
	sfu-sup-swverctrl-err	
	sfu-sup-poe-exceed-max	
	sfu-sup-poe-over-yell	
	sfu-opti-malfunc	
	sfu-sup-cfg-dnld-fail	
	sfu-sup-rssi-cfg-mism	
	sfu-sup-sfp-tx-low	
	sfu-sup-sfp-temp-high	
	sfu-sup-sfp-volt-high	
	sfu-sup-sfp-bias-high	
	sfu-sup-ld-cfg-mism	
	sfu-sup-olt-rx-low	
	sfu-sup-olt-rx-high	
	sfu-sup-olt-rx-lo-warn	
	sfu-sup-olt-rx-hi-warn	
	sfu-sup-tod-out-sync	
	sfu-sup-ont-tune-fail	
	sfu-tr069-parm-fail	
	sfu-sup-tod-mismatch	
	soho-sup-sw-file-error	
	soho-sup-fan-failure	
	soho-sup-temp-high-war	
	soho-sup-temp-shutoff	
	soho-sup-emergency-cal	
	soho-sup-swverctrl-err	
	soho-sup-poe-exceed-ma	
	soho-sup-poe-over-yell	
	soho-opti-malfunc	
	soho-sup-cfg-dnld-fail	
	soho-sup-rssi-cfg-mism	
	soho-sup-sfp-tx-low	
	soho-sup-sfp-temp-high	
	soho-sup-sfp-volt-high	
	soho-sup-sfp-bias-high	
	soho-sup-ld-cfg-mism	
	soho-sup-olt-rx-low	
	soho-sup-olt-rx-high	
	soho-sup-olt-rx-lo-war	
	soho-sup-olt-rx-hi-war	
	soho-sup-tod-out-sync	
	soho-sup-ont-tune-fail	
	soho-tr069-parm-fail	
	soho-sup-tod-mismatch	
	mdu-sup-sw-file-error	
	mdu-sup-fan-failure	
	mdu-sup-temp-high-warn	
	mdu-sup-temp-shutoff	
	mdu-sup-emergency-call	
	mdu-sup-swverctrl-err	
	mdu-sup-poe-exceed-max	
	mdu-sup-poe-over-yell	
	mdu-opti-malfunc	

100 Alarm Delta Log Status Commands

name	Type	Description
	mdu-sup-cfg-dnld-fail mdu-sup-rssi-cfg-mism mdu-sup-sfp-tx-low mdu-sup-sfp-temp-high mdu-sup-sfp-volt-high mdu-sup-sfp-bias-high mdu-sup-ld-cfg-mism mdu-sup-olt-rx-low mdu-sup-olt-rx-high mdu-sup-olt-rx-lo-warn mdu-sup-olt-rx-hi-warn mdu-sup-tod-out-sync mdu-sup-ont-tune-fail mdu-tr069-parm-fail mdu-sup-tod-mismatch ont-sbscr-lim-missing ont-sbscr-lim-type-mis ont-sbscr-lim-removal ont-sbscr-lim-fail ont-sbscr-lim-svc-mis ont-sbscr-lim-port-mis ont-svc-video-conf-mis ont-svc-video-pw-high ont-svc-video-pw-low ont-svc-pots-svc-mis ont-svc-pots-rtcp-lost ont-svc-pots-icnf-subs ont-svc-pots-icnf-ntfy ont-svc-pots-icnf-http ont-svc-pots-sip-reg ont-svc-pots-sip-inv ont-svc-pots-sip-subsc ont-svc-pots-sip-mt-tc ont-svc-pots-pk-los-tc ont-svc-pots-jitter-tc ont-svc-pots-subs-dns ont-svc-pots-subs-tcp ont-svc-pots-subs-tls ont-svc-pots-subs-auth ont-svc-pots-subs-to ont-svc-pots-subs-err ont-svc-pots-not-to ont-svc-pots-notref-to ont-svc-pots-not-mal ont-svc-pots-not-rej ont-svc-pots-http-dns ont-svc-pots-http-tcp ont-svc-pots-http-tls ont-svc-pots-http-auth ont-svc-pots-http-to ont-svc-pots-http-err ont-svc-pots-http-mal ont-svc-pots-insuff ont-svc-pots-poos ont-svc-lan-mismatch ont-svc-lan-loss-sig ont-svc-enet-poos	

name	Type	Description
	ont-svc-ces-ds1-mis ont-svc-ces-ds1-los ont-svc-ces-ds1-lof ont-svc-ces-ds1-rair ont-svc-ces-ds1-ais ont-svc-ces-ds1-lnlpbk ont-svc-ces-ds1-tmlpbk ont-svc-ces-e1-mis ont-svc-ces-e1-los ont-svc-ces-e1-lof ont-svc-ces-e1-rair ont-svc-ces-e1-ais ont-svc-voip-cnf-file ont-svc-voip-svc-mis ont-svc-voip-gw-comm ont-svc-voip-dhcp-fail ont-svc-voip-icnf-sub ont-svc-voip-icnf-ntfy ont-svc-voip-icnf-http ont-svc-voip-dhcp-to ont-svc-voip-dhcp-mal ont-svc-voip-dhcp-noad ont-svc-voip-dhcp-leas ont-svc-voip-sub-dns ont-svc-voip-sub-tcp ont-svc-voip-sub-tls ont-svc-voip-sub-auth ont-svc-voip-sub-to ont-svc-voip-sub-err ont-svc-voip-not-to ont-svc-voip-notref-to ont-svc-voip-not-mal ont-svc-voip-not-rej ont-svc-voip-http-dns ont-svc-voip-http-tcp ont-svc-voip-http-tls ont-svc-voip-http-auth ont-svc-voip-http-to ont-svc-voip-http-err ont-svc-voip-http-mal ont-svc-voip-sub-refr ont-svc-voip-not-refr ont-svc-voip-icfg-err ont-svc-v-ani-conf-mis ont-svc-v-ani-loss-sig ont-svc-v-ani-lv-high ont-svc-v-ani-lv-low ont-svc-pwe-mismatch ont-svc-pwe-reordr-lof ont-svc-pwe-jitt-buf-o ont-svc-pwe-jitt-buf-u ont-svc-pwe-malf-frms ont-svc-pwe-late-frms ont-svc-pwe-link-loss ont-svc-pwe-arp-fail ont-svc-xdsl-mismatch ont-svc-xdsl-ne-lof	

100 Alarm Delta Log Status Commands

name	Type	Description
	ont-svc-xdsl-ne-los ont-svc-xdsl-ne-line ont-svc-xdsl-ne-lol ont-svc-xdsl-fe-lof ont-svc-xdsl-fe-los ont-svc-xdsl-fe-lop ont-svc-xdsl-cnf-err ont-svc-xdsl-ne-es-tc ont-svc-xdsl-ne-ses-tc ont-svc-xdsl-ne-uas-tc ont-svc-xdsl-fe-es-tc ont-svc-xdsl-fe-ses-tc ont-svc-xdsl-fe-uas-tc ont-tc-rx-los-frag-tc ont-tc-tx-los-frag-tc ont-tc-bad-gem-hd-tc ont-uni-ds-drp-d-fr-tc ont-uni-up-drp-d-fr-tc ont-uni-ds-crc-fr-tc ont-uni-up-crc-fr-tc ont-cpu-util-tca ont-mem-util-tca pim-neighbor-down pim-max-mcroutes li-traffic-disabled li-bandwidth-limit li-out-of-res otdr-cap-mismatch login-successful login-failure cfm-defrdiccm cfm-defmacstatus cfm-defremoteccm cfm-deferrorccm cfm-defxconccm cfm-defais bfd-session-down bfd-max-resource bfd-stale-entry tca-outputbw tca-inputbw tca-rxcrcalign tca-txcrcalign tca-txcollisions tca-outputhighbw tca-outputmedbw tca-outputlowbw tca-inputhighbw tca-inputmediumbw tca-inputlowbw eth-cfm-defrdiccm eth-cfm-defmacstatus eth-cfm-defremoteccm eth-cfm-deferrorccm eth-cfm-defxconccm rsvp-neighbor-down rsvp-instance-down	

name	Type	Description
	eth-ring-path-block	
	ai-platform-down	
	ai-appl-install-fail	
	ip-assign-fail	
	ont-tr069-serv-mis	
	ont-snmp-mis	
	bsf-dhcpv4	
	bsf-dhcpv6	
	bsf-pon	
	bsf-vbridge	
	bsf-qos	
	bsf-igmp	
	bsf-lxfwd	
	prot-not-available	
	prot-switchover-fail	
	efm-oam-cpelinkfault	
	efm-oam-cpedyinggasp	
	efm-oam-cpecrevt	
	ont-loopdetect	
	alarm-tbl-overflow	
	auto-switch-status	
	auswqueuefullatm	
	auswbkpfailatm	
	auswrecfgfailatm	
	auswdataunatm	
	auswqueuefulptm	
	auswbkpfailptm	
	auswrecfgfailptm	
	auswdataunptm	
	auswbakpfailatm	
	chpr-com-fail	
	chpr-tx-fail	
	chpr-unprov-ont	
	chpr-prov-mismatch	
	chpr-loss-sig	
	chpr-diagnostic	
	chpr-loid-conflict	
	chpr-loid-pwd-err	
	chpr-stk-laser-dis	
	chpr-sfp-mismatch	
	chpr-rng-mismatch	
	chpr-alien-test	
	chpr-alien-detect	
	chpr-deact-hightca	
	chpr-deact-lowtca	
	chpr-dp-integ	
	olt-chpr-tc-err-frag	
	olt-chpr-up-bw-tca	
	olt-chpr-down-bw-tca	
	cfg-dld-fail	
	cfg-act-fail	
	cfg-dld-ip	
	cfg-ver-mismatch	
	cfg-file-missing	
	cfg-verctrl-err	
	cfg-not-supported	
	ont-prot-not-available	

100 Alarm Delta Log Status Commands

name	Type	Description
	ont-gen-temp-low	
	ont-gen-volt-low	
	ont-gen-tx-pwr-high	
	ont-gen-bias-low	
	ont-gen-rx-hwarn	
	ont-gen-rx-lwarn	
	ont-gen-tx-hwarn	
	ont-gen-tx-lwarn	
	ont-gen-temp-hwarn	
	ont-gen-temp-lwarn	
	ont-gen-volt-hwarn	
	ont-gen-volt-lwarn	
	ont-gen-bias-hwarn	
	ont-gen-bias-lwarn	
	sfu-sup2-temp-low	
	sfu-sup2-volt-low	
	sfu-sup2-tx-high	
	sfu-sup2-bias-low	
	sfu-sup2-rx-hwarn	
	sfu-sup2-rx-lwarn	
	sfu-sup2-tx-hwarn	
	sfu-sup2-tx-lwarn	
	sfu-sup2-temp-hwarn	
	sfu-sup2-temp-lwarn	
	sfu-sup2-volt-hwarn	
	sfu-sup2-volt-lwarn	
	sfu-sup2-bias-hwarn	
	sfu-sup2-bias-lwarn	
	soho-sup2-temp-low	
	soho-sup2-volt-low	
	soho-sup2-tx-high	
	soho-sup2-bias-low	
	soho-sup2-rx-hwarn	
	soho-sup2-rx-lwarn	
	soho-sup2-tx-hwarn	
	soho-sup2-tx-lwarn	
	soho-sup2-temp-hwarn	
	soho-sup2-temp-lwarn	
	soho-sup2-volt-hwarn	
	soho-sup2-volt-lwarn	
	soho-sup2-bias-hwarn	
	soho-sup2-bias-lwarn	
	mdu-sup2-temp-low	
	mdu-sup2-volt-low	
	mdu-sup2-tx-high	
	mdu-sup2-bias-low	
	mdu-sup2-rx-hwarn	
	mdu-sup2-rx-lwarn	
	mdu-sup2-tx-hwarn	
	mdu-sup2-tx-lwarn	
	mdu-sup2-temp-hwarn	
	mdu-sup2-temp-lwarn	
	mdu-sup2-volt-hwarn	
	mdu-sup2-volt-lwarn	
	mdu-sup2-bias-hwarn	
	mdu-sup2-bias-lwarn	
	cust-alm1	

name	Type	Description
	cust-alm2 cust-alm3 cust-alm4 cust-alm5 cust-alm6 cust-alm7 cust-alm8 cust-alm9 cust-alm10 cust-alm11 cust-alm12 cust-alm13 cust-alm14 cust-alm15 cust-alm16 cust-alm17 cust-alm18 cust-alm19 cust-alm20 cust-alm21 cust-alm22 cust-alm23 cust-alm24 cust-alm25 cust-alm26 cust-alm27 cust-alm28 cust-alm29 cust-alm30 cust-alm31 ethernet-ring-pthfwst ethernet-ring-fop-to ethernet-ring-fop-pm fpm-depletion exp-seizureack exp-disconack exp-forcerelack packet-loss remote-packet-loss no-dsp-resource la-down la-standby-na la-switch-fail la-degrade melt-board-reset board-shelf-mismatch fcs-thresh-exceed) Possible values: - all : all alarms for query - xtca-ne-es : errored seconds in 15 min - xtca-ne-ses : severely errored seconds in 15 min - xtca-ne-uas : unavailable seconds in 15 min - xtca-ne-day-es : errored seconds in 1 day - xtca-ne-day-ses : severely errored seconds in 1 day - xtca-ne-day-uas : unavailable seconds in 1 day - xtca-fe-es : errored seconds in 15 min - xtca-fe-ses : severely errored secs in 15 min	

100 Alarm Delta Log Status Commands

name	Type	Description
	- xtca-fe-uas : unavailable seconds in 15 min - xtca-fe-day-es : errored seconds in 1 day - xtca-fe-day-ses : severely errored secs in 1 day - xtca-fe-day-uas : unavailable seconds in 1 day - xtca-leftrs : low error free throughput seconds in 15 min - xtca-day-leftrs : low error free throughput seconds in 1 day - xtca-fe-leftrs : far end low error free throughput seconds in 15 min - xtca-fe-day-leftrs : far end low error free throughput seconds in 1 day - xtca-auto-port-reset : auto-port-resets in 1 week - xtca-reinit : Reinitialization seconds in 15 min - xtca-day-reinit : Reinitialization seconds in 1 day - xdsl-ne-los : loss of signal - xdsl-ne-lof : loss of frame - xdsl-ne-lom : loss of margin - xdsl-ne-ese : excessive severe errors - xdsl-act-cfg-error : line configuration data cannot be used - xdsl-act-not-feas : line capacity not enough to setup requested profile - xdsl-up-br-reach : planned bitrate not reached after initialization - xdsl-ne-ncd : no cell delineation - xdsl-ne-lcd : loss of cell delineation - xdsl-fe-los : loss of signal - xdsl-fe-lof : loss of frame - xdsl-fe-lpr : loss of power - xdsl-fe-lol : loss of link - xdsl-fe-lom : loss of margin - xdsl-fe-ese : excessive severe errors - xdsl-fe-upbo-vio : upbo violation - xdsl-fe-cpe-pol : activation failure cpe policing - xdsl-tpstc-mis : mismatch between the configured tps-tc mode and the mode supported by the connected cpe - xdsl-act-comm : init not successful due to communications problem - xdsl-act-modem : no peer modem detected - xdsl-do-br-reach : planned bitrate not reached after init - xdsl-fe-ncd : no cell delineation - xdsl-fe-lcd : loss of cell delineation - xdsl-fctx-init-fail : init not successful due to forced rtx - xdsl-vect-dle : vectoring disorderly leaving event - xdsl-fe-mis-peer-35b : VDSL2 35b opmode mismatch between XTU-C and XTU-R - vectline-xtc-var-vict : excessive victim crosstalk coefficients variation - vectline-xtc-var-dist : excessive disturber crosstalk coefficients variation - vectline-corp-errf : corrupted or missing errorf-samples - vect-cpe-cap-mismatch : not allowed Vectoring CPE connected - vectline-conf_notfeas : vect line configuration not feasible - vect-vp-lt-mismatch : actual vp-lt connection(s) do not match expected vp-lt connection(s) or vp-lt connection lost - vect-inv-qsf : qsf has no valid Nokia ID - vect-vp-lt-fail : vp-lt connection not operational - vect-no-gain-at-init : Lines cannot train in gain-at-init	

name	Type	Description
	mode - sw-rollback : non active oswp,db cannot be operational - will rollback - db-rollback : selected oswp,db cannot be operational - will rollback - xvps-inv-dbase : invalid xvps dbase - inv-cde-file : invalid xvps cde file - miss-cde-file : missing cde profile - cde-hash-error : cde profile hash error - auto-fetch-failure : not able to fetch file from specified server - low-disk-space : insufficient space for Sw storage - cell-discard-up : cell discarded in the upstream direction - cell-discard-down : cell discarded in the downstream direction - persist-data-loss : all data lost after restart - system not configured - mac-conflict : duplicate mac address on the bridge port - vmac-full : virtual mac address is full on the bridge port - sntp-comm-lost : sntp server not responding - preferred-mode : preferred mode not available - timing-reference : timing reference failure - nt-disk-95%full : nt disk 95% full - shub-loc : communication lost with shub - cf-error : compact flash access error - back-pnl-inv : BackPanel-type Invalid - ihub-conf-loss : iHub configuration loss - recent changes lost - rack-power : power fuse broken - rack-fan-unit1 : fan unit rack 1 failing - rack-fan-unit2 : fan unit rack 2 failing - shelf-mismatch : shelf type different from planned type - shelf-missing : detected shelf no longer detected - shelf-install-missing : shelf planned but not installed - door : open cabinet door - ac-power-fail : external power failure - shelf shutdown in 15 minutes - board-mismatch : board inserted different from planned - waiting-for-sw : not able to download all the applicable sw files - temp-exceeded : temperature threshold exceeded on the board - backplane-data-failure: It port on backplane data failure - temp-shutdown : board powered down itself - too high temperature - board-missing : board detected after planning - now missing - board-instl-missing : board never detected after planning - board-init : board initialisation failure - board-reset-prot : number of resets exceeded - sem-power-fail : SEM external power failure - sem-ups-fail : SEM external power supply failure - board-reset-cf : board reset and/or communication failure - vlan-assign-fail : failure to assign VLAN for a user session - vsa-info-invalid : radius fail to assign a valid vsa to a user session - auth-mac-conflict : failure to check mac conflict for a user	

100 Alarm Delta Log Status Commands

name	Type	Description
	- session - user-pwd-fault : failure to check user or password of a user session - up-plan-bitrate : upstream bitrate is above min and below planned - up-min-bitrate : upstream bitrate is below min bitrate - up-config-not-feas : upstream bitrate is not enough to set up config group - down-plan-bitrate : downstream bitrate is above min and below planned - down-min-bitrate : downstream bitrate is below min bitrate - down-config-not-feas : downstream bitrate is not enough to set up config group - non-bonding-cpe : no bonding cpe modem is connected - multiple-cpes : bonding group has multiple cpe modems connected - register : bonding group discovery or aggregation register failure - group-incomplete : bonding group is incomplete - host-sfp-los : loss of signal - host-sfp-tx-fail : Tx failure - host-sfp-not-prst : not present - host-sfp-inv-id : no valid Nokia ID - host-sfp-ctrl-fail : control failure - host-sfp-rmtlt : unexpected remote plug-in - host-sfp-mismatch : assignment does not match reported rack/shelf/slot - host-sfp-incompt : incompatible shelf type detected - exp-sfp-los : expansion side loss of signal - exp-sfp-tx-fail : Tx failure - exp-sfp-not-prst : not present - exp-sfp-inv-id : no valid Nokia ID - exp-sfp-ctrl-fail : control failure - exp-sfp-1-los : expansion side sfp1 loss of signal - exp-sfp-2-los : expansion side sfp2 loss of signal - ext-qsfp-invlid : Invalid Nokia ID - tx-power-high-alarm : tx power more than alarm range - tx-power-low-alarm : tx power less than alarm range - rx-power-high-alarm : rx power more than alarm range - rx-power-low-alarm : rx power less than alarm range - tx-biascur-high-alarm : tx bias current high alarm - tx-biascur-low-alarm : tx bias current low alarm - volt-high-alarm : voltage high alarm - volt-low-alarm : voltage low alarm - temp-high-alarm : temperature high alarm - temp-low-alarm : temperature low alarm - tx-power-high-warn : tx power more than warn range - tx-power-low-warn : tx power less than warn range - rx-power-high-warn : rx power more than warn range - rx-power-low-warn : rx power less than warn range - tx-biascur-high-warn : tx bias current high warn - tx-biascur-low-warn : tx bias current low warn - volt-high-warn : voltage high warn - volt-low-warn : voltage low warn - temp-high-warn : temperature high warn - temp-low-warn : temperature low warn - onu-unprovisioned : unprovisioned ont	

name	Type	Description
	- signal-loss : pon loss of signal - bitrate-high : the error bit rate high at pon interface - opmodule-mismatch : the optical module mismatched at pon interface - key-fail-one-churn : key exchange failure during one churning time - key-fail-three-churn : key exchange failure during three churning time - oam-discov-fail : extend oam discovery failure - report-timeout : report timeout detecting - total-packets-exceed : total amount of protocol packets exceed threshold - arp-packets-exceed : protocol arp packets exceed threshold - dhcp-packets-exceed : protocol dhcp packets exceed threshold - igmp-packets-exceed : protocol igmp packets exceed threshold - pppoe-packets-exceed : protocol pppoe packets exceed threshold - nd-packets-exceed : protocol nd packets exceed threshold - icmpv6-packets-exceed : protocol icmpv6 packets exceed threshold - mld-packets-exceed : protocol mld packets exceed threshold - dhcpv6-packets-exceed : protocol dhcpv6 packets exceed threshold - cfm-packets-exceed : protocol cfm packets exceed threshold - dsx1-serdes-fail : SERDES clock alarm failure - dsx1-tributary1-fail : The tributary 1 clock is not present - dsx1-tributary2-fail : The tributary 2 clock is not present - dsx1-los-fail : All the selected tribs in Loss of Signal - dsx1-ais-sync : Alarm Indication signal on the tributary selected as sync source - dsx1-lof-sync : Loss of Framing on the tributary selected as sync source - dsx1-los-sync : Loss of signal on the tributary selected as sync source - dsx1-deg-fail : Signal degrade Alarm - dsx1-rei-from-liu : Remote Error Indication alarm from LIU - dsx1-rdi-from-liu : Remote Defect Alarm from LIU - dsx1-crc6-from-liu : Cyclic Redundancy check-6 alarm from LIU - dsx1-crc4-from-liu : Cyclic Redundancy check-4 alarm from LIU - dsx1-crc4-th-from-liu : Cyclic Redundancy check-4 threshold alarm from LIU - dsx1-ais-from-liu : Alarm Indication Signal alarm from LIU - dsx1-los-from-liu : Loss of signal alarm from LIU - dsx1-lof-from-liu : Loss of framing alarm from LIU - dsx1-lomf-from-liu : Loss of Multi-frame alarm from LIU - dsx1-rei-from-iwf : Remote Error Indication alarm from IWF - dsx1-rdi-from-iwf : Remote Defect Alarm from IWF - dsx1-crc6-from-iwf : Cyclic Redundancy check-6 alarm	

100 Alarm Delta Log Status Commands

name	Type	Description
	- from IWF - dsx1-crc4-from-iwf : Cyclic Redundancy check-4 alarm from IWF - dsx1-crc4-th-from-iwf : Cyclic Redundancy check-4 threshold alarm from IWF - dsx1-ais-from-iwf : Alarm Indication Signal alarm from IWF - dsx1-los-from-iwf : Loss of signal alarm from IWF - dsx1-lof-from-iwf : Loss of framing alarm from IWF - dsx1-lomf-from-iwf : Loss of Multi-frame alarm from IWF - pppce-trans-15min-tca : 15 minutes transaction timeout count exceeds configured TCA - pppce-sess-15min-tca : 15 minutes session timeout count exceeds configured TCA - pppce-trans-1day-tca : 1day transaction timeout count exceeds configured TCA - pppce-sess-1day-tca : 1day session timeout count exceeds configured TCA - custom1 : customizable alarm 1 - custom2 : customizable alarm 2 - custom3 : customizable alarm 3 - custom4 : customizable alarm 4 - custom5 : customizable alarm 5 - he-custom1 : host expansion customizable alarm 1 - he-custom2 : host expansion customizable alarm 2 - he-custom3 : host expansion customizable alarm 3 - he-custom4 : host expansion customizable alarm 4 - he-custom5 : host expansion customizable alarm 5 - he-custom6 : host expansion customizable alarm 6 - custom6 : customizable alarm 6 - custom7 : customizable alarm 7 - custom8 : customizable alarm 8 - custom9 : customizable alarm 9 - custom10 : customizable alarm 10 - custom11 : customizable alarm 11 - custom12 : customizable alarm 12 - custom13 : customizable alarm 13 - custom14 : customizable alarm 14 - custom15 : customizable alarm 15 - custom16 : customizable alarm 16 - custom17 : customizable alarm 17 - loss-swo-cap : switch over capability in a redundant system - ping-check-fail : ping check in a redundant system - der-temp1 : Derived Alarm for Temporal Filter 1 - der-temp2 : Derived Alarm for Temporal Filter 2 - der-temp3 : Derived Alarm for Temporal Filter 3 - der-temp4 : Derived Alarm for Temporal Filter 4 - der-temp5 : Derived Alarm for Temporal Filter 5 - der-temp6 : Derived Alarm for Temporal Filter 6 - der-temp7 : Derived Alarm for Temporal Filter 7 - der-temp8 : Derived Alarm for Temporal Filter 8 - der-temp9 : Derived Alarm for Temporal Filter 9 - der-temp10 : Derived Alarm for Temporal Filter 10 - der-temp11 : Derived Alarm for Temporal Filter 11 - der-temp12 : Derived Alarm for Temporal Filter 12 - der-temp13 : Derived Alarm for Temporal Filter 13 - der-temp14 : Derived Alarm for Temporal Filter 14	

name	Type	Description
	- der-temp15 : Derived Alarm for Temporal Filter 15 - der-temp16 : Derived Alarm for Temporal Filter 16 - der-temp17 : Derived Alarm for Temporal Filter 17 - der-temp18 : Derived Alarm for Temporal Filter 18 - der-temp19 : Derived Alarm for Temporal Filter 19 - der-temp20 : Derived Alarm for Temporal Filter 20 - der-temp21 : Derived Alarm for Temporal Filter 21 - der-temp22 : Derived Alarm for Temporal Filter 22 - der-temp23 : Derived Alarm for Temporal Filter 23 - der-temp24 : Derived Alarm for Temporal Filter 24 - der-temp25 : Derived Alarm for Temporal Filter 25 - der-temp26 : Derived Alarm for Temporal Filter 26 - der-temp27 : Derived Alarm for Temporal Filter 27 - der-temp28 : Derived Alarm for Temporal Filter 28 - der-temp29 : Derived Alarm for Temporal Filter 29 - der-temp30 : Derived Alarm for Temporal Filter 30 - der-temp31 : Derived Alarm for Temporal Filter 31 - der-spa1 : Derived Alarm for Spatial Filter 1 - der-spa2 : Derived Alarm for Spatial Filter 2 - der-spa3 : Derived Alarm for Spatial Filter 3 - der-spa4 : Derived Alarm for Spatial Filter 4 - der-spa5 : Derived Alarm for Spatial Filter 5 - der-spa6 : Derived Alarm for Spatial Filter 6 - der-spa7 : Derived Alarm for Spatial Filter 7 - der-spa8 : Derived Alarm for Spatial Filter 8 - der-spa9 : Derived Alarm for Spatial Filter 9 - der-spa10 : Derived Alarm for Spatial Filter 10 - der-spa11 : Derived Alarm for Spatial Filter 11 - der-spa12 : Derived Alarm for Spatial Filter 12 - der-spa13 : Derived Alarm for Spatial Filter 13 - der-spa14 : Derived Alarm for Spatial Filter 14 - der-spa15 : Derived Alarm for Spatial Filter 15 - der-spa16 : Derived Alarm for Spatial Filter 16 - der-spa17 : Derived Alarm for Spatial Filter 17 - der-spa18 : Derived Alarm for Spatial Filter 18 - der-spa19 : Derived Alarm for Spatial Filter 19 - der-spa20 : Derived Alarm for Spatial Filter 20 - der-spa21 : Derived Alarm for Spatial Filter 21 - der-spa22 : Derived Alarm for Spatial Filter 22 - der-spa23 : Derived Alarm for Spatial Filter 23 - der-spa24 : Derived Alarm for Spatial Filter 24 - der-spa25 : Derived Alarm for Spatial Filter 25 - der-spa26 : Derived Alarm for Spatial Filter 26 - der-spa27 : Derived Alarm for Spatial Filter 27 - der-spa28 : Derived Alarm for Spatial Filter 28 - der-spa29 : Derived Alarm for Spatial Filter 29 - der-spa30 : Derived Alarm for Spatial Filter 30 - der-spa31 : Derived Alarm for Spatial Filter 31 - apsf-alarm : Applique Power Supply Failure - custextalarm1 : Customizable External Alarm Number 1 - custextalarm2 : Customizable External Alarm Number 2 - custextalarm3 : Customizable External Alarm Number 3 - custextalarm4 : Customizable External Alarm Number 4 - custextalarm5 : Customizable External Alarm Number 5 - pluginfan : REM Fan Alarm - plugin-dc-a : REM DC A Alarm - plugin-dc-b : REM DC B Alarm	

100 Alarm Delta Log Status Commands

name	Type	Description
	- plugin-dg : Dying Gasp Alarm - ntr-a-loss : NTR-A signal is not available - ntr-b-loss : NTR-B signal is not available - xvps-conf-loss : xvps configuration loss - mac-entry-nofree : no free mac entry in the mac table on It board - fibre-conn-mismatch : REM Fibre Connection Mismatch Alarm - link-cap-mismatch : Link speed capability mismatch - eqpt-cap-mismatch : Link equipment capability mismatch - ctrl-dnld-failure : Controller card download failure - melt-hw-issue : MELT hardware issue - melt-board-reset : MELT board reset - board-shelf-mismatch : board type and shelf type mismatch - mgnt-type-mismatch : Board management type mismatch - fileserv-unavail : file transfer Server unavailable or file transfer failed - shdsl-n-loopback : loopback active at the network side - shdsl-c-loopback : loopback active at the customer side - shdsl-conferr : configuration error - shdsl-atm-lcd : loss of atm cell delineation - shdsl-lpr : loss of power at stu-r - shdsl-secu-err : unable to disable stu-r access - shdsl-dev-fault : device fault - shdsl-atm-ncd : no atm cell delineation - shdsl-n-losw : loss of sync word at the network side on each pair - shdsl-c-losw : loss of sync word at the customer side on each pair - shdsl-n-aten : loop attenuation alarm at the network side on each pair - shdsl-c-aten : loop attenuation alarm at the customer side on each pair - shdsl-n-snr : snr margin alarm at the network side each pair - shdsl-c-snr : snr margin alarm at the customer side on each pair - shdsl-n-dccont : dc continuity fault at the network side on each pair - shdsl-c-dccont : dc continuity fault at the customer side on each pair - shdsl-c-actfail : activation failure at the customer side on each pair - e1-fe-rai : Receiving Remote Alarm Indication - e1-ne-rai : Transmitting Remote Alarm Indication - e1-fe-ais : Receiving Alarm Indication Signal - e1-ne-ais : Transmitting Alarm Indication Signal - e1-lof : E1 Loss of frame - e1-los : E1 Loss of Signal - e1-loopback : E1 facility in loopback - ima-grp-fe-su : far-end starting up - ima-grp-fe-cfg : far-end failed configuration - ima-grp-ne-cfg : near-end failed configuration - ima-grp-fe-nl : insufficient number of links at far-end - ima-grp-ne-nl : insufficient number of links at near-end - ima-grp-fe-blk : far-end is blocked - ima-lnk-lif : loss of ima frame - ima-lnk-lods : link out of delay synchronization	

name	Type	Description
	- ima-lnk-misc : link misconnect - ima-lnk-rfi : link remote failure indication - ima-lnk-fault : fault in link facility - ima-lnk-txblk : transmit blocked due to far-end - ima-lnk-rxblk : receive blocked due to far-end - bad-digitmap : Configured digitmap is unusable - dhcp-unreach : The DHCP server is unreachable - dhcp-no-srv : The address in DHCP reply is NULL - dhcp-inv-srv : The address in DHCP reply is invalid - norpniewithsoftdsp : do not plan / plug-in RPNI-E board with SoftDsp SW image - unknown-sub : subscriber exist in the POLT, but not in the appl server - ground-key : Return current to the ground - port-hightemp : Temperature threshold on user port exceeded. - port-jbfltca : JB fill level threshold on user port exceeded. - reg-domainname : Registration failure (resolving domain name). - reg-auth : Registration failure (authentication). - reg-timeout : Registration failure (message timeout). - reg-srvfailresp : Registration failure (failure response from server). - inv-domainname : Invitation failure (resolving domain name). - inv-auth : Invitation failure (authentication). - inv-timeout : Invitation failure (message timeout). - inv-srvfailresp : Invitation failure (failure response from server). - subs-srvfailresp : Subscribe failure (failure response from server). - subs-domainname : Subscribe failure (resolving domain name). - subs-auth : Subscribe failure (authentication). - subs-refreshfail : Subscribe failure (refresh failure). - subs-inittimeout : Subscribe failure (initial REQ timeout). - emergency-call : Emergency call for SIP POTS is ongoing. - e1sip-reg-domainname : E1 sip termination registration failure (resolving domain name). - e1sip-reg-auth : E1 sip termination registration failure (authentication). - e1sip-reg-timeout : E1 sip termination registration failure (message timeout). - e1sip-reg-srvfailresp : E1 sip termination registration failure (failure response from server). - e1sip-inv-domainname : E1 sip termination invitation failure (resolving domain name). - e1sip-inv-auth : E1 sip termination invitation failure (authentication). - e1sip-inv-timeout : E1 sip termination invitation failure (message timeout). - e1sip-inv-srvfailresp : E1 sip invitation failure (failure response from server). - e1sip-emergency-call : Emergency call for ISDN PRA/CAS R2 is ongoing. - e1itf-ais-signal : Alarm Indication Signal detected at E1 interface.	

100 Alarm Delta Log Status Commands

name	Type	Description
	- e1itf-los-signal : Loss Of Signal detected at E1 interface. - e1itf-rai-signal : Remote Alarm Indication detected at E1 interface. - e1sip-misconfig-mgc10 : Configuration not conform with the core network entity. - e1sip-nsmprf-missed : The SIP termination requires a NSM profile. - e1t1itf-recv-ais : Alarm Indication Signal received at interface. - e1t1itf-recv-los : Loss Of Signal received at interface. - e1t1itf-recv-rai : Remote Alarm Indication received at interface. - transport-mismatch : Transport protocol mismatch - dns-lookup-failure : Dns look up failure - none-dns-srv : No reply for all DNS serverd - no-dns-srv : No DNS servers configured - none-srv : No reply for all SIP First Hops - no-srv : No SIP First Hop configured - reg-srv-unreach : All SIP register servers are unreachable - proxy-srv-unreach : All SIP proxy servers are unreachable - dhcp-srv-unreach : The DHCP server is unreachable on this board - fo-trigger : Fail Over Triggered - fb-trigger : Fail Back Triggered - du-trigger : Deliberate Update Triggered - ssp-missing : SSP Missing in CDE - dns-pool-exceed : Number of different SG associated DNS pools exceed - lsa-fo-trigger : SIP voice service degraded - fail-over to LSA server - reg-domainname-sec : Registration failure (resolving domain name). - reg-auth-sec : Registration failure (authentication). - reg-timeout-sec : Registration failure (message timeout). - reg-srvfailresp-sec : Registration failure (failure response from server). - inv-domainname-sec : Invitation failure (resolving domain name). - inv-auth-sec : Invitation failure (authentication). - inv-timeout-sec : Invitation failure (message timeout). - inv-srvfailresp-sec : Invitation failure (failure response from server). - subs-srvfailresp-sec : Subscribe failure (failure response from server). - subs-domainname-sec : Subscribe failure (resolving domain name). - subs-auth-sec : Subscribe failure (authentication). - subs-refreshfail-sec : Subscribe failure (refresh failure). - subs-inittimeout-sec : Subscribe failure (initial REQ timeout). - emergency-call-sec : Emergency call for Secondary Termination is ongoing. - fanout : Lt load overflow - up-overflow : Upstream load overflow - upobc-overflow : Upstream load to OBC overflow - dwobc-overflow : Downstream load to OBC overflow - dw-overflow : Downstream load overflow	

name	Type	Description
	- lwpri-overflow : The number of BE and CL pkts dropped exceed threshold - queue-drop : The number of pkts dropped by queue exceeds threshold - queue-load : The queue load exceeds threshold - queue-peak-usage : The queue peak usage exceeds threshold - mgc-unreachable : loss of contact with the media gateway controller - failover-to-esamgc : failover to esa mgc - sgc-unreachable : loss of contac with signaling gateway controller - lcard-unreach-srvcard : line card unreachable with server card - lcard-type-mismatch : associate board of wrong type - meg-unknown-sub : the megaco subscriber is unknown - meg-ground-key : voice port ground key - meg-high-temp : voice port high temperature - meg-act-fail : the first link layer for isdn subscriber activation failure - meg-over-current : voice port over current - line-showering : line showering - low-qos-packetloss : the total packet loss has exceeded the configured threshold - low-qos-jitter : the rtp jitter has exceeded the configured threshold - low-qos-delay : the rtp delay has exceeded the configured threshold - sig-brd-persist-loss : voice signaling board persistent data loss - sig-brd-disk-full : voice signaling board disk 90% full - sig-brd-db-rollback : voice signaling board db rollback - mg-overload : mg overload - meg-unknown-sub-sec : The Megaco subscriber exists in voice signaling board but not in media gateway controller. - line-showering-sec : A subscriber line exceeds 20 off-hook / on-hook events / minute. - loss-env-mon : env-monitor box lost or not alive - etca-los : loss of signal errors in 15 min - etca-fcs : frame check sequence errors in 15 min - etca-day-los : loss of signal errors in 1 day - etca-day-fcs : frame check sequence errors in 1 day - etca-rx-octets : received octets in 15 min - etca-tx-octets : transmitted octets in 15 min - etca-day-rx-octets : received octets in 1 day - etca-day-tx-octets : transmitted octets in 1 day - user-sfp-los : user sfp loss of signal - user-sfp-tx-fail : user sfp tx failure - user-sfp-not-prst : user sfp not detected - user-sfp-inv-id : user sfp invalid id - user-sfp-t-exceed : user sfp temperature exceed - user-sfp-mismatch : user sfp mismatch the configured type - uplink-sfp-los : uplink sfp loss of signal - uplink-sfp-tx-fail : uplink sfp tx failure - uplink-sfp-not-prst : uplink sfp not detected - uplink-sfp-inv-id : uplink sfp invalid id - uplink-sfp-t-exceed : uplink sfp temperature exceed	

100 Alarm Delta Log Status Commands

name	Type	Description
	- uplink-sfp-mismatch : uplink sfp mismatch the configured type - loss-lsmwp-cap : lsm redundancy - inv-xvps-pair-data : invalid xvps pair redundancy data - network-power-loss : Loss of Network Power - hw-fault : Hardware Failure - bat-miss : Power Source Battery Missing - bat-fail : Power Source Battery Failure - bat-low : Power Source Battery Charge LOW - bat-a-fail : Power Source BAT-A Fail - bat-b-fail : Power Source BAT-B Fail - ac-vol-out-range : AC Input Voltage Value Out of Range - network-power-loss-b : Loss of Network Power B - sem-ac-power-fail : External AC power supply failure - sem-ups-low-volt : External power supply low voltage - dc-a-fail : Local DC A power failure - dc-b-fail : Local DC B power failure - plan-power-mismatch : Planned and detected power mode mismatch - water-seepage-in-box : Detected water seepage in enclosure - sealed-box-open : Sealed box open detected - dc-a-vol-out-range : DC A Input Voltage Value Out of Range - dc-b-vol-out-range : DC B Input Voltage Value Out of Range - inlet-temp-major : The inlet temperature has exceeded a major level - inlet-temp-critical : The inlet temperature has exceeded a critical level - psu-fail-crit : Power Supply failure - psu-a-fail-presence : Power Supply A is not present - psu-a-fail-vin-ac-nok : Power Supply A has Vin AC fault - psu-a-fail-vin-uv : Power Supply A has Vin undervoltage - psu-a-fail-vin-ov : Power Supply A has Vin overvoltage - psu-a-fail-vout-uv : Power Supply A has Vout undervoltage - psu-a-fail-vout-ov : Power Supply A has Vout overvoltage - psu-a-fail-iout-oc : Power Supply A has Iout overcurrent - psu-a-fail-ovtemp : Power Supply A has over temperature - psu-b-fail-presence : Power Supply B is not present - psu-b-fail-vin-ac-nok : Power Supply B has Vin AC fault - psu-b-fail-vin-uv : Power Supply B has Vin undervoltage - psu-b-fail-vin-ov : Power Supply B has Vin overvoltage - psu-b-fail-vout-uv : Power Supply B has Vout undervoltage - psu-b-fail-vout-ov : Power Supply B has Vout overvoltage - psu-b-fail-iout-oc : Power Supply B has Iout overcurrent - psu-b-fail-ovtemp : Power Supply B has over temperature - synce-fail : synce clock source failure - bits-fail : bits clock source failure - bits-output-shutoff : bits output failure - ieee1588-fail : ieee1588 clock source failure - gnss-fail : gnss clock source failure - ieee1588-hybrid-fail : ieee1588 hybrid tod source failure	

name	Type	Description
	- signal-loss : synce or bits clock signal loss - signal-efd : synce or bits clock signal exceed frequency deviation - esmc-loss : clock source loss SSM information - bits-output-exceed : exceed bits output threshold - ql-input-exceed : exceed input clock source threshold - holdover : clock system is in the holdover - lti : all clock source failed - tod-reference-fail : Timing ToD Reference failed - internal-clk-fail : Internal CLK failed - bgp-peer-down : peer operational state is down - bgp-routes-mid-limit : 90% of max nbr of routes BGP can learn from a peer is reached - isis-adjacency-down : isis adjacency is down - isis-adjacency-reject : isis adjacency is rejected - isis-instance-down : isis instance is down or not - ospf-lsa-limit : limit of received LSA's is reached - ospf-lsa-mid-limit : 90% of limit of received LSA's is reached - ospf-neighbor-down : OSPF neighbour is down - ospf-instance-down : OSPF instance is down or not - ospf3-lsa-limit : limit of received OSPFv3 LSAs is reached - ospf3-lsa-mid-limit : 90% of limit of received OSPFv3 LSAs is reached - ospf3-neighbor-down : OSPFv3 neighbour is down - ospf3-instance-down : OSPFv3 instance is down or not - rip-instance-down : rip instance down - lag-down : lag down - lagsubgrp-thresh-reach: lag subgroup threshold reached - lagsubgrp-switch-fail : lag subgroup switchover failed - no-unpinned-free-ports: No free ports available for unpinned traffic - general-arp-limit : arp limit exceeded - gen-switch-out-of-res : failure due to lack of resources on switch - ipv6-nc-limit : ipv6 neighbor cache limit exceeded - dhcp-session-oor : dhcp session out of resources - ihub-fdb-limit : layer 2 fdb limit reached - ihub-mac-limit : layer 2 mac limit reached - l2fw-stp-exception : STP exception condition is present in the SAP - l2fw-stp-root-guard : STP root guard violation is present - vprn-routes-limit : limit of ip is reached - vprn-ipv6-routes-limit: limit of ipv6 is reached - dhcpv6-lease-limit : limit of dhcpv6 leases is reached - dhcpv4-lease-limit : limit of dhcpv4 leases is reached - vpls-mfib-limit : limit of fib table is reached - ihub-ipv6-dad-own : duplicate IPV6 address is detected for IP address allotted to system - ihub-ipv6-dad : duplicate IPV6 address is detected for a user's IP address - ihub-ipv6-dup-pd-route: ipv6 duplicate pd detected - vpls-duplicate-mac : duplicate mac address is detected - vpls-fdb-limit : limit of fdb table is reached - vpls-self-dup-mac : duplicate of a system owned mac address detected on a sap - vpls-sdp-self-dup-mac : duplicate of a system owned mac	

100 Alarm Delta Log Status Commands

name	Type	Description
	address detected on a sdp binding - link-down : link is down - link-lagport-add-fail : failure to add port to LAG - link-conf-mismatch : SFP+plugin-types does not match the planned speed and/or auto-negotiation for the port - ihub-peer-comm : ihub peer to peer communication failure - ihub-sw-fail : IHUB s/w error - ihub-hw-fail : IHUB h/w error - ihub-link-fail : IHUB link failure - ihub-proc-overload : IHUB processor exceeded - ihub-out-of-mem : IHUB processor out of memory - ntp-comm-lost : No response is received from the NTP servers - ldp-instance-down : ldp instance down - ldp-session-down : ldp session down - mpls-instance-down : mpls instance down - mpls-lsp-down : lsp down - mpls-lsp-path-down : lsp path down - sdp-instance-down : sdp instance down - sdp-binding-down : sdp binding down - epipe-instance-down : epipe instance down - lldpmed-portcfg-mis : config request failure for lldpmed portconfig - lldpmed-mediapl-mis : config request failure for lldpmed mediapolicy - vlanport-svc-mismatch : config request failure for the provisioned vlanport - mcsrc-stream-lost : multicast video stream lost - eqptsupl-syslog-upload: upload of log file to remote server failure - eqptsupl-ontsw-dnload : ont sw download in progress - cf-75%used : Compact flash exceeds 75% of life expectancy - cf-90%used : Compact flash exceeds 90% of life expectancy - olt-gen-pon-com-fail : pon communication failure on olt - olt-gen-tx-fail : transmitter failure on olt - olt-gen-unprov-ont : unprovisioned ont on pon - olt-gen-pon-eqpt-prov : mismatch btw equipment and provisioning pon attributes - olt-gen-pon-loss-sig : pon loss of signal - olt-gen-pon-diagnostic: pon diagnostic test active - olt-gen-loid-conflict : loid conflict ont on pon - olt-gen-loid-pwderr : loid password error ont on pon - olt-gen-pon-alien-test: pon alien diagnostic test active - olt-gen-alien-detect : pon alien detect active - olt-gen-rng-mism : pon ranging mismatch active - olt-gen-sfp-mism : pon sfp mismatch active - olt-gen-deact-hightca : deactivated ont hightca threshold crossed - olt-gen-deact-lowtca : deactivated ont lowtca threshold crossed - olt-gen-dp-integ : pon data path integriy failure - olt-gen-ddr-fault : pon failure due to ddr fault - olt-pon-tc-err-frag-tc: pon errored fragments threshold crossed - olt-ont-tc-err-frag-tc: ont errored fragments threshold	

name	Type	Description
	crossed - ont-ploam-loss-sig : loss of signal at ont - ont-ploam-loss-ack : loss of acknowledge from ont - ont-ploam-loss-cd : loss of channel delineation of ont - ont-ploam-phy-eqpt-err: physical equipment error of ont - ont-ploam-startup-fail: startup failure in ranging of ont - ont-ploam-sig-degrade : signal degrade from ont - ont-ploam-disabled : ont disabled alarm - ont-ploam-err-msg : error message from ont - ont-ploam-inactive : inactive ont - ont-ploam-sig-fail : signal fail alarm from ont - ont-ploam-dying-gasp : dying gasp alarm from ont - ont-ploam-deact-fail : deactive failure of ont - ont-ploam-oam : loss of ploam for ont - ont-ploam-win-drift : drift of window alarm - ont-ploam-rdi : remote defect indication alarm - ont-ploam-loss-ks : loss of key synchronization alarm - ont-ploam-pwr-burst : power bursts on ont - ont-ploam-rog-disa : ont rogue disabled - ont-ploam-diff-reach : ont differential reach exceeded - ont-ploam-looc : Loss of OMCI channel due to persistent MIC failure - sfu-ploam-loss-sig : SFU ONT - loss of signal at ont - sfu-ploam-loss-ack : SFU ONT - loss of acknowledge from ont - sfu-ploam-loss-cd : SFU ONT - loss of channel delineation of ont - sfu-ploam-phy-eqpt-err: SFU ONT - physical equipment error of ont - sfu-ploam-startup-fail: SFU ONT - startup failure in ranging of ont - sfu-ploam-sig-degrade : SFU ONT - signal degrade from ont - sfu-ploam-disabled : SFU ONT - ont disabled alarm - sfu-ploam-err-msg : SFU ONT - error message from ont - sfu-ploam-inactive : SFU ONT - inactive ont - sfu-ploam-sig-fail : SFU ONT - signal fail alarm from ont - sfu-ploam-dying-gasp : SFU ONT - dying gasp alarm from ont - sfu-ploam-deact-fail : SFU ONT - deactive failure of ont - sfu-ploam-oam : SFU ONT - loss of ploam for ont - sfu-ploam-win-drift : SFU ONT - drift of window alarm - sfu-ploam-rdi : SFU ONT - remote defect indication alarm - sfu-ploam-loss-ks : SFU ONT - loss of key synchronization alarm - sfu-ploam-pwr-burst : SFU ONT - power bursts on ont - sfu-ploam-rog-disa : SFU ONT - ont rogue disabled - sfu-ploam-diff-reach : SFU ONT - ont differential reach exceeded - sfu-ploam-looc : SFU ONT - Loss of OMCI channel due to persistent MIC failure - soho-ploam-loss-sig : SOHO ONT - loss of signal at ont - soho-ploam-loss-ack : SOHO ONT - loss of acknowledge from ont - soho-ploam-loss-cd : SOHO ONT - loss of channel delineation of ont - soho-ploam-phy-eqpt-er: SOHO ONT - physical	

100 Alarm Delta Log Status Commands

name	Type	Description
	equipment error of ont - soho-ploam-startup-fai: SOHO ONT - startup failure in ranging of ont - soho-ploam-sig-degrade: SOHO ONT - signal degrade from ont - soho-ploam-disabled : SOHO ONT - ont disabled alarm - soho-ploam-err-msg : SOHO ONT - error message from ont - soho-ploam-inactive : SOHO ONT - inactive ont - soho-ploam-sig-fail : SOHO ONT - signal fail alarm from ont - soho-ploam-dying-gasp : SOHO ONT - dying gasp alarm from ont - soho-ploam-deact-fail : SOHO ONT - deactive failure of ont - soho-ploam-oam : SOHO ONT - loss of ploam for ont - soho-ploam-win-drift : SOHO ONT - drift of window alarm - soho-ploam-rdi : SOHO ONT - remote defect indication alarm - soho-ploam-loss-ks : SOHO ONT - loss of key synchronization alarm - soho-ploam-pwr-burst : SOHO ONT - power bursts on ont - soho-ploam-rog-disa : SOHO ONT - ont rogue disabled - soho-ploam-diff-reach : SOHO ONT - ont differential reach exceeded - soho-ploam-looc : SOHO ONT - Loss of OMCI channel due to persistent MIC failure - mdu-ploam-loss-sig : MDU ONT - loss of signal at ont - mdu-ploam-loss-ack : MDU ONT - loss of acknowledge from ont - mdu-ploam-loss-cd : MDU ONT - loss of channel delineation of ont - mdu-ploam-phy-eqpt-err: MDU ONT - physical equipment error of ont - mdu-ploam-startup-fail: MDU ONT - startup failure in ranging of ont - mdu-ploam-sig-degrade : MDU ONT - signal degrade from ont - mdu-ploam-disabled : MDU ONT - ont disabled alarm - mdu-ploam-err-msg : MDU ONT - error message from ont - mdu-ploam-inactive : MDU ONT - inactive ont - mdu-ploam-sig-fail : MDU ONT - signal fail alarm from ont - mdu-ploam-dying-gasp : MDU ONT - dying gasp alarm from ont - mdu-ploam-deact-fail : MDU ONT - deactive failure of ont - mdu-ploam-oam : MDU ONT - loss of ploam for ont - mdu-ploam-win-drift : MDU ONT - drift of window alarm - mdu-ploam-rdi : MDU ONT - remote defect indication alarm - mdu-ploam-loss-ks : MDU ONT - loss of key synchronization alarm - mdu-ploam-pwr-burst : MDU ONT - power bursts on ont - mdu-ploam-rog-disa : MDU ONT - ont rogue disabled - mdu-ploam-diff-reach : MDU ONT - ont differential reach exceeded	

name	Type	Description
	- mdu-ploam-looc : MDU ONT - Loss of OMCI channel due to persistent MIC failure - ont-hpna-ser-mis : hpna ont service mismatch - ont-hpna-los-sig : hpna loss of link - ont-moca-svc-mis : moca ont service mismatch - ont-moca-link-los : moca loss of link - ont-moca-min-bw : moca bw between nodes less than minimum bw - ont-moca-tca-rx-err-fr: moca rx errored frames threshold crossed - ont-sipa-reg-nm-fail : sipua registration name failed - ont-sipa-reg-rec-fail : sipua register reach failed - ont-sipa-reg-con-fail : sipua register connect failed - ont-sipa-reg-val-fail : sipua register validation failed - ont-sipa-reg-mis : sipua register mismatch - ont-vcd-cfg-nm-fail : vcd config name failed - ont-vcd-cfg-rech-fail : vcd config reach failed - ont-vcd-cfg-conn-fail : vcd config connect failed - ont-vcd-cfg-vali-fail : vcd config validation failed - ont-vcd-cfg-auth-fail : vcd config authentication failed - ont-vcd-cfg-resp-tmout: vcd config response timeout - ont-vcd-cfg-resp-err : vcd config response error - ont-vcd-cfg-file-err : vcd config file error - ont-vcd-sub-nm-fail : vcd subscription name failed - ont-vcd-sub-rech-fail : vcd subscription reach failed - ont-vcd-sub-conn-fail : vcd subscription connect failed - ont-vcd-sub-vali-fail : vcd subscription validation failed - ont-vcd-sub-auth-fail : vcd subscription authentication failed - ont-vcd-sub-resp-tmout: vcd subscription response timeout - ont-vcd-sub-resp-err : vcd subscription response error - ont-vcd-reb-requ : vcd reboot request - ont-vcd-mis : vcd mismatch - ont-mgc-mis : ont mgc mismatch - ont-mgc-timeout : ont mgc timeout - ont-sip-reg-dns : ont services pots sip registration failed (resolving domain name) - ont-sip-reg-fail : ont services pots sip registration authentication failed - ont-sip-reg-timeout : ont services pots sip registration timeout - ont-sip-reg-err-resps : ont services pots sip registration response error - ont-sip-inv-dns : ont services pots sip invitation failed (resolving domain name) - ont-sip-inv-auth : ont services pots sip invitation authentication failed - ont-sip-inv-timeout : ont services pots sip invitation timeout - ont-sip-inv-err : ont services pots sip invitation response error - ont-svc-pots-subs-refr: ont services pots iconfig subscription could not be refreshed - ont-svc-pots-not-refr : ont services pots iconfig notification could not be refreshed - ont-svc-pots-icfg-err : ont services pots service failed due to an unmapped iconfig error	

100 Alarm Delta Log Status Commands

name	Type	Description
	- ont-veip-mismatch : ont veip mismatch - ont-ip-host-mismatch : ont ip host mismatch - ont-ip-host-file : ont ip host file unavailable - ont-ip-host-ip-alloc : ont ip host IP allocation failure - olt-pon-up-bw-tca : OLT PON upstream bandwidth TCA - olt-pon-down-bw-tca : OLT PON downstream bandwidth TCA - ont-gen-omci-fail : loss of communication - ont-gen-eqpt-selftest : ont self-test failure - ont-gen-ac-pwr-fail : ac power failure on ont - ont-gen-bat-missing : battery missing - ont-gen-bat-low : battery low - ont-gen-bat-fail : battery failure - ont-gen-phys-intrusion: physical intrusion - ont-gen-sw-dnload-f : ont sw download failure - ont-gen-sw-dnload-p : ont sw download in progress - ont-gen-sw-act-fail : ont sw activation failure - ont-gen-eqpt-vers-mis : ont equipment version mismatch - ont-gen-sw-vers-mis : ont sw version mismatch - ont-gen-us-rate-mis : ont upstream rate mismatch - ont-gen-mdu-env1 : mdu environmental alarm#1 - ont-gen-mdu-env2 : mdu environmental alarm#2 - ont-gen-mdu-env3 : mdu environmental alarm#3 - ont-gen-nw-time-err : network timing protocol error - ont-gen-opt-sig-high : optical signal level too high - ont-gen-opt-sig-low : optical signal level too low - ont-gen-eqpt-prov-sa : service affecting mismatch btw equipment and provisioning attributes - ont-gen-eqpt-prov-nsa : non service affecting mismatch btw equipment and provisioning attributes - pon-t-txmcutilhi : pon utilization tx (downstream) multicast high threshold crossed - pon-t-txmcutilmd : pon utilization tx (downstream) multicast medium threshold crossed - pon-t-txmcutillo : pon utilization tx (downstream) multicast low threshold crossed - pon-t-txtotutilhi : pon utilization tx (downstream) total high threshold crossed - pon-t-txtotutilmd : pon utilization tx (downstream) total medium threshold crossed - pon-t-txtotutillo : pon utilization tx (downstream) total low threshold crossed - pon-t-rxtotutilhi : pon utilization rx (upstream) total high threshold crossed - pon-t-rxtotutilmd : pon utilization rx (upstream) total medium threshold crossed - pon-t-rxtotutillo : pon utilization rx (upstream) total low threshold crossed - pon-t-dbacongperiodhi : pon utilization rx (upstream) dbacongperiod high threshold crossed - pon-t-dbacongperiodmd : pon utilization rx (upstream) dbacongperiod medium threshold crossed - pon-t-dbacongperiodlo : pon utilization rx (upstream) dbacongperiod low threshold crossed - pon-t-txucdropfrmhi : pon utilization tx (downstream) unicast drop frame high threshold crossed - pon-t-txucdropfrmd : pon utilization tx (downstream)	

name	Type	Description
	unicast drop frame medium threshold crossed - pon-t-txucdropfrmlo : pon utilization tx (downstream) unicast drop frame low threshold crossed - pon-t-txmcdropfrmhi : pon utilization tx (downstream) multicast drop frame high threshold crossed - pon-t-txmcdropfrmmd : pon utilization tx (downstream) multicast drop frame medium threshold crossed - pon-t-txmcdropfrmlo : pon utilization tx (downstream) multicast drop frame low threshold crossed - pon-t-txbcdropfrmhi : pon utilization tx (downstream) broadcast drop frame high threshold crossed - pon-t-txbcdropfrmmd : pon utilization tx (downstream) broadcast drop frame medium threshold crossed - pon-t-txbcdropfrmlo : pon utilization tx (downstream) broadcast drop frame low threshold crossed - pon-t-rxtotdropfrmhi : pon utilization rx (upstream) total drop frame high threshold crossed - pon-t-rxtotdropfrmmd : pon utilization rx (upstream) total drop frame medium threshold crossed - pon-t-rxtotdropfrmlo : pon utilization rx (upstream) total drop frame low threshold crossed - chpr-t-txmcutilhi : channel-pair utilization tx (downstream) multicast high threshold crossed - chpr-t-txmcutilmd : channel-pair utilization tx (downstream) multicast medium threshold crossed - chpr-t-txmcutillo : channel-pair utilization tx (downstream) multicast low threshold crossed - chpr-t-txtotutilhi : channel-pair utilization tx (downstream) total high threshold crossed - chpr-t-txtotutilmd : channel-pair utilization tx (downstream) total medium threshold crossed - chpr-t-txtotutillo : channel-pair utilization tx (downstream) total low threshold crossed - chpr-t-rxtotutilhi : channel-pair utilization rx (upstream) total high threshold crossed - chpr-t-rxtotutilmd : channel-pair utilization rx (upstream) total medium threshold crossed - chpr-t-rxtotutillo : channel-pair utilization rx (upstream) total low threshold crossed - chpr-t-dbacongperiodhi: channel-pair utilization rx (upstream) dbacongperiod high threshold crossed - chpr-t-dbacongperiodmd: channel-pair utilization rx (upstream) dbacongperiod medium threshold crossed - chpr-t-dbacongperiodlo: channel-pair utilization rx (upstream) dbacongperiod low threshold crossed - chpr-t-txucdropfrmhi : channel-pair utilization tx (downstream) unicast drop frame high threshold crossed - chpr-t-txucdropfrmmd : channel-pair utilization tx (downstream) unicast drop frame medium threshold crossed - chpr-t-txucdropfrmlo : channel-pair utilization tx (downstream) unicast drop frame low threshold crossed - chpr-t-txmcdropfrmhi : channel-pair utilization tx (downstream) multicast drop frame high threshold crossed - chpr-t-txmcdropfrmmd : channel-pair utilization tx (downstream) multicast drop frame medium threshold crossed - chpr-t-txmcdropfrmlo : channel-pair utilization tx	

100 Alarm Delta Log Status Commands

name	Type	Description
	(downstream) multicast drop frame low threshold crossed - chpr-t-txbcdropfrmhi : channel-pair utilization tx (downstream) broadcast drop frame high threshold crossed - chpr-t-txbcdropfrmmd : channel-pair utilization tx (downstream) broadcast drop frame medium threshold crossed - chpr-t-txbcdropfrmlo : channel-pair utilization tx (downstream) broadcast drop frame low threshold crossed - chpr-t-rxtotdropfrmhi : channel-pair utilization rx (upstream) total drop frame high threshold crossed - chpr-t-rxtotdropfrmmd : channel-pair utilization rx (upstream) total drop frame medium threshold crossed - chpr-t-rxtotdropfrmlo : channel-pair utilization rx (upstream) total drop frame low threshold crossed - sfu-gen-omci-fail : SFU ONT - loss of communication - sfu-gen-eqpt-selftest : SFU ONT - ont self-test failure - sfu-gen-ac-pwr-fail : SFU ONT - ac power failure on ont - sfu-gen-bat-missing : SFU ONT - battery missing - sfu-gen-bat-low : SFU ONT - battery low - sfu-gen-bat-fail : SFU ONT - battery failure - sfu-gen-sw-dnload-f : SFU ONT - ont sw download failure - sfu-gen-sw-dnload-p : SFU ONT - ont sw download in progress - sfu-gen-sw-act-fail : SFU ONT - ont sw activation failure - sfu-gen-eqpt-vers-mis : SFU ONT - ont equipment version mismatch - sfu-gen-sw-vers-mis : SFU ONT - ont sw version mismatch - sfu-gen-us-rate-mis : SFU ONT - ont upstream rate mismatch - sfu-gen-tune-fail : SFU ONT - ont has failed to tune to Target-ChnlPair - sfu-gen-nw-time-err : SFU ONT - network timing protocol error - sfu-gen-opt-sig-high : SFU ONT - optical signal level too high - sfu-gen-opt-sig-low : SFU ONT - optical signal level too low - sfu-gen-eqpt-prov-sa : SFU ONT - service affecting mismatch btw equipment and provisioning attributes - sfu-gen-eqpt-prov-nsa : SFU ONT - non service affecting mismatch btw equipment and provisioning attributes - soho-gen-omci-fail : SOHO ONT - loss of communication - soho-gen-eqpt-selftest : SOHO ONT - ont self-test failure - soho-gen-ac-pwr-fail : SOHO ONT - ac power failure on ont - soho-gen-bat-missing : SOHO ONT - battery missing - soho-gen-bat-low : SOHO ONT - battery low - soho-gen-bat-fail : SOHO ONT - battery failure - soho-gen-sw-dnload-f : SOHO ONT - ont sw download failure - soho-gen-sw-dnload-p : SOHO ONT - ont sw download in progress - soho-gen-sw-act-fail : SOHO ONT - ont sw activation failure - soho-gen-eqpt-vers-mis : SOHO ONT - ont equipment version mismatch	

name	Type	Description
	- soho-gen-sw-vers-mis : SOHO ONT - ont sw version mismatch - soho-gen-us-rate-mis : SOHO ONT - ont upstream rate mismatch - soho-gen-tune-fail : SOHO ONT - ont has failed to tune to Target-ChnlPair - soho-gen-nw-time-err : SOHO ONT - network timing protocol error - soho-gen-opt-sig-high : SOHO ONT - optical signal level too high - soho-gen-opt-sig-low : SOHO ONT - optical signal level too low - soho-gen-eqpt-prov-sa : SOHO ONT - service affecting mismatch btw equipment and provisioning attributes - soho-gen-eqpt-prov-nsa: SOHO ONT - non service affecting mismatch btw equipment and provisioning attributes - mdu-gen-omci-fail : MDU ONT - loss of communication - mdu-gen-eqpt-selftest : MDU ONT - ont self-test failure - mdu-gen-ac-pwr-fail : MDU ONT - ac power failure on ont - mdu-gen-bat-missing : MDU ONT - battery missing - mdu-gen-bat-low : MDU ONT - battery low - mdu-gen-bat-fail : MDU ONT - battery failure - mdu-gen-phys-intrusion: MDU ONT - physical intrusion - mdu-gen-sw-dnload-f : MDU ONT - ont sw download failure - mdu-gen-sw-dnload-p : MDU ONT - ont sw download in progress - mdu-gen-sw-act-fail : MDU ONT - ont sw activation failure - mdu-gen-eqpt-vers-mis : MDU ONT - ont equipment version mismatch - mdu-gen-sw-vers-mis : MDU ONT - ont sw version mismatch - mdu-gen-us-rate-mis : MDU ONT - ont upstream rate mismatch - mdu-gen-tune-fail : MDU ONT - ont has failed to tune to Target-ChnlPair - mdu-gen-mdu-env1 : MDU ONT - mdu environmental alarm#1 - mdu-gen-mdu-env2 : MDU ONT - mdu environmental alarm#2 - mdu-gen-mdu-env3 : MDU ONT - mdu environmental alarm#3 - mdu-gen-nw-time-err : MDU ONT - network timing protocol error - mdu-gen-opt-sig-high : MDU ONT - optical signal level too high - mdu-gen-opt-sig-low : MDU ONT - optical signal level too low - mdu-gen-eqpt-prov-sa : MDU ONT - service affecting mismatch btw equipment and provisioning attributes - mdu-gen-eqpt-prov-nsa : MDU ONT - non service affecting mismatch btw equipment and provisioning attributes - ont-gen-sw-dnload-file: ont sw download file missing	

100 Alarm Delta Log Status Commands

name	Type	Description
	- ont-gen-fan-fail : ont fan failure - ont-gen-high-temp : ont high temperature - ont-gen-high-temp-ex : ont excessive high temperature - ont-gen-emergency-call: ont emergency call - ont-gen-sw-version : ont sw version control error - ont-poe-exceed-max : ont poe exceed max - ont-poe-overload-yell : ONU is nearing its maximum ability to supply the power - ont-opti-malfunc : malfunction of ONT's optical transceiver - ont-gen-cfgdld-fail : download of voice xml file to ont failed - ont-gen-rssi-mis : ONU RSSI configuration mismatch - ont-gen-tx-pwr-low : ONU SFP Tx Power is lower than configured Alarm low threshold - ont-gen-temp-high : ONU SFP Temperature is higher than configured Alarm high threshold - ont-gen-volt-high : ONU SFP Voltage is higher than configured Alarm high threshold - ont-gen-bias-high : ONU SFP Bias is higher than configured Alarm high threshold - ont-loopdetect-mis : ont loop detect mismatch - ont-olt-rx-pw-lo : olt side receive power from ont low - ont-olt-rx-pw-hig : olt side receive power from ont high - ont-olt-rx-pw-warnlo : olt side receive power from ont low warning - ont-olt-rx-pw-warnhig : olt side receive power from ont high warning - ont-gen-tod-out-sync : ONU TOD is out-sync with OLT - ont-gen-tune-fail : ONU has failed to tune to Target-ChnlPair - hgu-tr069-param-fail : hgu tr069 parameters mismatch - ont-gen-tod-mismatch : ONU TOD MISMATCH - sfu-sup-sw-file-error : SFU ONT - Software file has error or is missing - sfu-sup-fan-failure : SFU ONT - Fan failure - sfu-sup-temp-high-warn: SFU ONT - High temperature warning - sfu-sup-temp-shutoff : SFU ONT - Service disabled due to excessive temperature - sfu-sup-emergency-call: SFU ONT - Emergency call active - sfu-sup-swverctrl-err : SFU ONT - Software version control error - sfu-sup-poe-exceed-max: SFU ONT - Configured PoE feeding exceeds ONT maximum - sfu-sup-poe-over-yell : SFU ONT - ONU is nearing its maximum ability to supply the power - sfu-opti-malfunc : SFU ONT - Malfunction of ONT's optical transceiver - sfu-sup-cfg-dnld-fail : SFU ONT - Download of voice xml file to ONT failed - sfu-sup-rssi-cfg-mism : SFU ONT - RSSI configuration mismatch - sfu-sup-sfp-tx-low : SFU ONT - SFP Tx Power below configured low-level alarm threshold - sfu-sup-sfp-temp-high : SFU ONT - SFP Temperature above configured high-level alarm threshold	

name	Type	Description
	- sfu-sup-sfp-volt-high : SFU ONT - SFP Voltage above configured high-level alarm threshold - sfu-sup-sfp-bias-high : SFU ONT - SFP Bias above configured high-level alarm threshold - sfu-sup-ld-cfg-mism : SFU ONT - Loop detection configuration mismatch - sfu-sup-olt-rx-low : SFU ONT - OLT Rx power below receiver operating range - sfu-sup-olt-rx-high : SFU ONT - OLT Rx power above receiver operating range - sfu-sup-olt-rx-lo-warn: SFU ONT - OLT Rx power below low-level warning threshold - sfu-sup-olt-rx-hi-warn: SFU ONT - OLT Rx power above high-level warning threshold - sfu-sup-tod-out-sync : SFU ONT - ONU TOD is out-sync with OLT - sfu-sup-ont-tune-fail : SFU ONT - ONU has failed to tune to Target-ChnlPair - sfu-tr069-param-fail : SFU ONT - hgu tr069 parameters mismatch - sfu-sup-tod-mismatch : SFU ONT - ONU TOD MISMATCH - soho-sup-sw-file-error: SOHO ONT - Software file has error or is missing - soho-sup-fan-failure : SOHO ONT - Fan failure - soho-sup-temp-high-war: SOHO ONT - High temperature warning - soho-sup-temp-shutoff : SOHO ONT - Service disabled due to excessive temperature - soho-sup-emergency-cal: SOHO ONT - Emergency call active - soho-sup-swverctrl-err: SOHO ONT - Software version control error - soho-sup-poe-exceed-ma: SOHO ONT - Configured PoE feeding exceeds ONT maximum - soho-sup-poe-over-yell: SOHO ONT - ONU is nearing its maximum ability to supply the power - soho-opti-malfunc : SOHO ONT - Malfunction of ONT's optical transceiver - soho-sup-cfg-dnld-fail: SOHO ONT - Download of voice xml file to ONT failed - soho-sup-rssi-cfg-mism: SOHO ONT - RSSI configuration mismatch - soho-sup-sfp-tx-low : SOHO ONT - SFP Tx Power below configured low-level alarm threshold - soho-sup-sfp-temp-high: SOHO ONT - SFP Temperature above configured high-level alarm threshold - soho-sup-sfp-volt-high: SOHO ONT - SFP Voltage above configured high-level alarm threshold - soho-sup-sfp-bias-high: SOHO ONT - SFP Bias above configured high-level alarm threshold - soho-sup-ld-cfg-mism : SOHO ONT - Loop detection configuration mismatch - soho-sup-olt-rx-low : SOHO ONT - OLT Rx power below receiver operating range - soho-sup-olt-rx-high : SOHO ONT - OLT Rx power above receiver operating range	

100 Alarm Delta Log Status Commands

name	Type	Description
	- soho-sup-olt-rx-lo-war: SOHO ONT - OLT Rx power below low-level warning threshold - soho-sup-olt-rx-hi-war: SOHO ONT - OLT Rx power above high-level warning threshold - soho-sup-tod-out-sync : SOHO ONT - ONU TOD is out-sync with OLT - soho-sup-ont-tune-fail: SOHO ONT - ONU has failed to tune to Target-ChnlPair - soho-tr069-param-fail : SOHO ONT - hgu tr069 parameters mismatch - soho-sup-tod-mismatch : SOHO ONT - ONU TOD MISMATCH - mdu-sup-sw-file-error : MDU ONT - Software file has error or is missing - mdu-sup-fan-failure : MDU ONT - Fan failure - mdu-sup-temp-high-warn: MDU ONT - High temperature warning - mdu-sup-temp-shutoff : MDU ONT - Service disabled due to excessive temperature - mdu-sup-emergency-call: MDU ONT - Emergency call active - mdu-sup-swverctrl-err : MDU ONT - Software version control error - mdu-sup-poe-exceed-max: MDU ONT - Configured PoE feeding exceeds ONT maximum - mdu-sup-poe-over-yell : MDU ONT - ONU is nearing its maximum ability to supply the power - mdu-opti-malfunc : MDU ONT - Malfunction of ONT's optical transceiver - mdu-sup-cfg-dnld-fail : MDU ONT - Download of voice xml file to ONT failed - mdu-sup-rssi-cfg-mism : MDU ONT - RSSI configuration mismatch - mdu-sup-sfp-tx-low : MDU ONT - SFP Tx Power below configured low-level alarm threshold - mdu-sup-sfp-temp-high : MDU ONT - SFP Temperature above configured high-level alarm threshold - mdu-sup-sfp-volt-high : MDU ONT - SFP Voltage above configured high-level alarm threshold - mdu-sup-sfp-bias-high : MDU ONT - SFP Bias above configured high-level alarm threshold - mdu-sup-ld-cfg-mism : MDU ONT - Loop detection configuration mismatch - mdu-sup-olt-rx-low : MDU ONT - OLT Rx power below receiver operating range - mdu-sup-olt-rx-high : MDU ONT - OLT Rx power above receiver operating range - mdu-sup-olt-rx-lo-warn: MDU ONT - OLT Rx power below low-level warning threshold - mdu-sup-olt-rx-hi-warn: MDU ONT - OLT Rx power above high-level warning threshold - mdu-sup-tod-out-sync : MDU ONT - ONU TOD is out-sync with OLT - mdu-sup-ont-tune-fail : MDU ONT - ONU has failed to tune to Target-ChnlPair - mdu-tr069-param-fail : MDU ONT - hgu tr069 parameters mismatch	

name	Type	Description
	- mdu-sup-tod-mismatch : MDU ONT - ONU TOD MISMATCH - ont-sbscr-lim-missing : provisioned ont card missing - ont-sbscr-lim-type-mis: wrong type plug-in ont card - ont-sbscr-lim-removal : improper removal ont card - ont-sbscr-lim-fail : ont card failure - ont-sbscr-lim-svc-mis : ont service mismatch for provisioned onu card - ont-sbscr-lim-port-mis: port mismatch btw actual and planned ont card - ont-svc-video-conf-mis: config request failure for video service - ont-svc-video-pw-high : high power level for rf video signal - ont-svc-video-pw-low : low power level for rf video signal - ont-svc-pots-svc-mis : ont service mismatch for provisioned pots - ont-svc-pots-rtcp-lost: pots realtime transport control protocol stream lost - ont-svc-pots-icnf-subs: pots line iconfig subscription failure - ont-svc-pots-icnf-ntfy: pots line iconfig notify failure - ont-svc-pots-icnf-http: pots line iconfig http failure - ont-svc-pots-sip-reg : pots line sip registration failure - ont-svc-pots-sip-inv : pots line sip invite request failure - ont-svc-pots-sip-subsc: pots line sip subscribe failure - ont-svc-pots-sip-mt-tc: pots line sip message timeout threshold crossed - ont-svc-pots-pk-los-tc: pots line rtp bearer packets loss threshold crossed - ont-svc-pots-jitter-tc: pots line rtp jitter threshold crossed - ont-svc-pots-subs-dns : pots line iconfig subscription failed (DNS) - ont-svc-pots-subs-tcp : pots line iconfig subscription failed (TCP) - ont-svc-pots-subs-tls : pots line iconfig subscription failed (TLS) - ont-svc-pots-subs-auth: pots line iconfig subscription failed authentication - ont-svc-pots-subs-to : pots line iconfig subscription failed (timeout) - ont-svc-pots-subs-err : pots line iconfig subscription response error - ont-svc-pots-not-to : pots line iconfig notification failed (timeout) - ont-svc-pots-notref-to: pots line iconfig notification refresh failed - ont-svc-pots-not-mal : pots line iconfig notification failed (malformed) - ont-svc-pots-not-rej : pots line iconfig notification rejected - ont-svc-pots-http-dns : pots line iconfig doc retrieval failed (DNS) - ont-svc-pots-http-tcp : pots line iconfig doc retrieval failed (TCP) - ont-svc-pots-http-tls : pots line iconfig doc retrieval failed (TLS) - ont-svc-pots-http-auth: pots line iconfig doc retrieval failed	

100 Alarm Delta Log Status Commands

name	Type	Description
	(authentication) - ont-svc-pots-http-to : pots line iconfig doc retrieval failed (timeout) - ont-svc-pots-http-err : pots line iconfig doc retrieval response error - ont-svc-pots-http-mal : pots line iconfig doc retrieval failed (malformed) - ont-svc-pots-insuff : pots line iconfig service failed (insufficient data) - ont-svc-pots-poos : pots ports out of service - ont-svc-lan-mismatch : ont service mismatch for lan - ont-svc-lan-loss-sig : loss of signal on an ethernet port interface - ont-svc-enet-poos : Ethernet Ports out of Service - ont-svc-ces-ds1-mis : ont service mismatch for provisioned ces ds1 - ont-svc-ces-ds1-los : loss of signal at ds1 interface - ont-svc-ces-ds1-lof : loss of frame at ds1 interface - ont-svc-ces-ds1-rair : receiving rai at ds1 interface - ont-svc-ces-ds1-ais : receiving ais at ds1 interface - ont-svc-ces-ds1-lnlpbk: receiving line loopback at ds1 interface - ont-svc-ces-ds1-tmlpbk: receiving terminal loopback at ds1 interface - ont-svc-ces-e1-mis : ont service mismatch for provisioned ces e1 - ont-svc-ces-e1-los : loss of signal at e1 interface - ont-svc-ces-e1-lof : loss of frame at e1 interface - ont-svc-ces-e1-rair : receiving rai at e1 interface - ont-svc-ces-e1-ais : receiving ais at e1 interface - ont-svc-voip-cnf-file : voice configuration file error - ont-svc-voip-svc-mis : service mismatch for provisioned client service - ont-svc-voip-gw-comm : voice gateway communication failure - ont-svc-voip-dhcp-fail: voice dhcp server failure - ont-svc-voip-icnf-sub: voice iconfig subscription failure - ont-svc-voip-icnf-ntfy: voice iconfig notify failure - ont-svc-voip-icnf-http: voice iconfig http failure - ont-svc-voip-dhcp-to : DHCP server retransmissions timed out - ont-svc-voip-dhcp-mal : DHCP response was malformed - ont-svc-voip-dhcp-noad: DHCP server failed to issue the required parameters - ont-svc-voip-dhcp-leas: DHCP Server failure due to problem in lease renewal - ont-svc-voip-sub: iConfig Subscription failure due to DNS problem - ont-svc-voip-sub-tcp : iConfig Subscription failure due to TCP socket problem - ont-svc-voip-sub-tls : iConfig Subscription failure due to TLS session problem - ont-svc-voip-sub-auth: iConfig Subscription failure due to authentication error - ont-svc-voip-sub-to : iConfig Subscription failure due to retransmission timeout - ont-svc-voip-sub-err : iConfig Subscription failure due to	

name	Type	Description
	response error - ont-svc-voip-not-to : iConfig Notify response timeout for new subscription - ont-svc-voip-notref-to: iConfig Notify response timeout for subscription refresh - ont-svc-voip-not-mal : iConfig Notify response is malformed - ont-svc-voip-not-rej : iConfig subscription request rejected by configuration server - ont-svc-voip-http-dns : VOIP client can't retrieve config doc due to DNS problem - ont-svc-voip-http-tcp : VOIP client can't retrieve config doc due to TCP socket problem - ont-svc-voip-http-tls : VOIP client can't retrieve config doc due to TLS session problem - ont-svc-voip-http-auth: VOIP client can't retrieve config doc due to auth error - ont-svc-voip-http-to : VOIP client can't retrieve config doc due to re-tx timeout - ont-svc-voip-http-err : VOIP client can't retrieve config doc due to response error - ont-svc-voip-http-mal : iConfig configuration document is malformed - ont-svc-voip-subs-refr: iConfig Subscription refresh error - ont-svc-voip-not-refr : iConfig Notify response for refresh subscribe failed - ont-svc-voip-icfg-err : iConfig Configuration Error - ont-svc-v-ani-conf-mis: config request failure for video ani service - ont-svc-v-ani-loss-sig: video loss of signal on ani - ont-svc-v-ani-lv-high : high video optical signal level - ont-svc-v-ani-lv-low : low video optical signal level - ont-svc-pwe-mismatch : service mismatch for provisioned pseudowire - ont-svc-pwe-reordr-lof: pseudowire reordering and loss of frame - ont-svc-pwe-jitt-buf-o: pseudowire jitter buffer overrun - ont-svc-pwe-jitt-buf-u: pseudowire jitter buffer underrun - ont-svc-pwe-malf-frms : pseudowire malformed frames - ont-svc-pwe-late-frms : pseudowire late frames - ont-svc-pwe-link-loss : pseudowire link loss - ont-svc-pwe-arp-fail : pseudowire arp failure - ont-svc-xdsl-mismatch : service mismatch for provisioned xdsl - ont-svc-xdsl-ne-lof : near end loss of frame - ont-svc-xdsl-ne-los : near end loss of signal - ont-svc-xdsl-ne-line : near end line init - ont-svc-xdsl-ne-lol : near end loss of link - ont-svc-xdsl-fe-lof : far end loss of frame - ont-svc-xdsl-fe-los : far end loss of signal - ont-svc-xdsl-fe-lop : far end loss of power - ont-svc-xdsl-cnf-err : xdsl provisioning error - ont-svc-xdsl-ne-es-tc : near end errored seconds threshold crossed - ont-svc-xdsl-ne-ses-tc: near end severe errored seconds threshold crossed - ont-svc-xdsl-ne-uas-tc: ear end unavailable seconds	

100 Alarm Delta Log Status Commands

name	Type	Description
	threshold crossed - ont-svc-xdsl-fe-es-tc : far end errored seconds threshold crossed - ont-svc-xdsl-fe-ses-tc: far end severe errored seconds threshold crossed - ont-svc-xdsl-fe-uas-tc: far end unavailable seconds threshold crossed - ont-tc-rx-los-frag-tc : rx loss of gem fragments threshold crossed - ont-tc-tx-los-frag-tc : tx loss of gem fragments threshold crossed - ont-tc-bad-gem-hd-tc : bad gem header threshold crossed - ont-uni-ds-drpdp-fr-tc : downstream l2 dropped frames threshold crossed - ont-uni-up-drpdp-fr-tc : upstream l2 dropped frames threshold crossed - ont-uni-ds-crc-fr-tc : downstream l2 rx crc error frames threshold crossed - ont-uni-up-crc-fr-tc : upstream l2 rx crc error frames threshold crossed - ont-cpu-util-tca : ONT CPU utilization threshold crossed - ont-mem-util-tca : ONT memory utilization threshold crossed - pim-neighbor-down : pim neighbor down - pim-max-mcroutes : maximum routes reached - li-traffic-disabled : lawful interception of traffic disabled - li-bandwidth-limit : lawful intercept reached bandwidth limit - li-out-of-res : lawful intercept out of resources - otdr-cap-mismatch : otdr capability mismatch - login-successful : successful login via management access - login-failure : invalid login via management access has crossed the threshold limit - cfm-defrdiccm : rdi bit in ccm received - cfm-defmacstatus : ccm mac error status - cfm-defremoteccm : missing ccm from mep - cfm-deferrorccm : invalid ccm received - cfm-defxconccm : unexpected ccm received - cfm-defais : ethernet ais received - bfd-session-down : bfd session down - bfd-max-resource : bfd maximum resources reached - bfd-stale-entry : bfd stale entry present - tca-outputbw : tca output bandwidth - tca-inputbw : tca input bandwidth - tca-rxcrcalign : tca rxrc align errors - tca-txcrcalign : tca txrc align errors - tca-txcollisions : tca tx collision errors - tca-outputhighbw : tca output high bandwidth - tca-outputmedbw : tca output medium bandwidth - tca-outputlowbw : tca output low bandwidth - tca-inputhighbw : tca input high bandwidth - tca-inputmediumbw : tca input medium bandwidth - tca-inputlowbw : tca input low bandwidth - eth-cfm-defrdiccm : rdi bit in ccm received - eth-cfm-defmacstatus : ccm mac error status - eth-cfm-defremoteccm : missing ccm from mep - eth-cfm-deferrorccm : invalid ccm received	

name	Type	Description
	- eth-cfm-defxconccm : unexpected ccm received - rsvp-neighbor-down : rsvp neighbor down - rsvp-instance-down : rsvp instance down - eth-ring-path-block : eth ring path block - ai-platform-down : Application Intelligence Platform down - ai-appl-install-fail : Application installation failure - ip-assign-fail : Dhcp assigned address failure - ont-tr069-serv-mis : ont tr069 server config mismatch - ont-snmp-mis : ont snmp agent config mismatch - bsf-dhcpv4 : bulksync failed for dhcpv4 - bsf-dhcpv6 : bulksync failed for dhcpv6 - bsf-pon : bulksync failed for pon - bsf-vbridge : bulksync failed for vlan-bridge - bsf-qos : bulksync failed for qos - bsf-igmp : bulksync failed for igmp - bsf-lxfwd : bulksync failed for lxfwd - prot-not-available : no protection not available - prot-switchover-fail : port switch over failed - efm-oam-cpelinkfault : EFM-OAM CPE link fault - efm-oam-cpedyinggasp : EFM-OAM CPE dying gasp - efm-oam-cpecrevt : EFM-OAM CPE critical event - ont-loopdetect : ont loop detect - alm-tbl-overflow : alarm table has overflowed - auto-switch-status : auto-switch status - auswqueuefullatm : auto-switch queue Full for ATM - auswbkpfailatm : auto-switch config data backup failed for ATM - auswrecfgfailatm : auto-switch fallback reconfiguration failed for ATM - auswdataunatm : auto-switch backup config data unavailable for ATM - auswqueuefulptm : auto-switch queue Full for PTM - auswbkpfailptm : auto-switch config data backup failed for PTM - auswrecfgfailptm : auto-switch fallback reconfiguration failed for PTM - auswdataunptm : auto-switch backup config data unavailable for PTM - auswbakpfailatm : auto-switch backup fail for ATM - chpr-com-fail : channel pair communication failure on olt - chpr-tx-fail : transmitter failure on channel pair - chpr-unprov-ont : unprovisioned ont on channel pair - chpr-prov-mismatch : mismatch btw equipment and provisioning pon attributes - chpr-loss-sig : channel pair loss of signal - chpr-diagnostic : channel pair diagnostic test active - chpr-loid-conflict : loid conflict ont on channel pair - chpr-loid-pwd-err : loid password error ont on channel pair - chpr-stk-laser-dis : stuck laser disabled on channel pair - chpr-sfp-mismatch : channel pair sfp mismatch - chpr-rng-mismatch : channel pair ranging mismatch - chpr-alien-test : channel pair alien diagnostic test active - chpr-alien-detect : channel pair alien detect active - chpr-deact-hightca : channel pair deactivated ont hightca threshold crossed - chpr-deact-lowtca : channel pair deactivated ont lowtca threshold crossed	

100 Alarm Delta Log Status Commands

name	Type	Description
	- chpr-dp-integ : channel pair data path integrity failure - olt-chpr-tc-err-frag : channelpair errored fragments threshold crossed - olt-chpr-up-bw-tca : OLT CHANNELPAIR upstream bandwidth TCA - olt-chpr-down-bw-tca : OLT CHANNELPAIR downstream bandwidth TCA - cfg-dld-fail : download of configure file to ont failed - cfg-act-fail : activate the passive config file failed - cfg-dld-ip : ont configure file download in progress - cfg-ver-mismatch : the planned configure file does not match the active configure file - cfg-file-missing : ont configure file missing or has an error - cfg-verctrl-err : ont configure file version control error - cfg-not-supported : ont not support the configure file download function - ont-prot-not-available: ONT/ONU protection not available - ont-gen-temp-low : ONU SFP temperature is lower than configured Alarm low threshold - ont-gen-volt-low : ONU SFP Voltage is lower than configured Alarm low threshold - ont-gen-tx-pwr-high : ONU SFP Tx power is higher than configured Alarm high threshold - ont-gen-bias-low : ONU SFP bias is lower than configured Alarm low threshold - ont-gen-rx-hwarn : ONU SFP Rx power is higher than warn threshold - ont-gen-rx-lwarn : ONU SFP Rx power is lower than warn threshold - ont-gen-tx-hwarn : ONU SFP Tx power is higher than warn threshold - ont-gen-tx-lwarn : ONU SFP Tx power is lower than warn threshold - ont-gen-temp-hwarn : ONU SFP temperature is higher than warn threshold - ont-gen-temp-lwarn : ONU SFP temperature is lower than warn threshold - ont-gen-volt-hwarn : ONU SFP Voltage is higher than warn threshold - ont-gen-volt-lwarn : ONU SFP Voltage is lower than warn threshold - ont-gen-bias-hwarn : ONU SFP bias is higher than warn threshold - ont-gen-bias-lwarn : ONU SFP bias is lower than warn threshold - sfu-sup2-temp-low : SFU ONT - SFP temperature is lower than configured Alarm low threshold - sfu-sup2-volt-low : SFU ONT - SFP Voltage is lower than configured Alarm low threshold - sfu-sup2-tx-high : SFU ONT - SFP tx power is higher than configured Alarm high threshold - sfu-sup2-bias-low : SFU ONT - SFP bias is lower than configured Alarm low threshold - sfu-sup2-rx-hwarn : SFU ONT - SFP rx power is higher than configured warn threshold - sfu-sup2-rx-lwarn : SFU ONT - SFP rx power is lower than configured warn threshold	

name	Type	Description
	- sfu-sup2-tx-hwarn : SFU ONT - SFP tx power is higher than configured warn threshold - sfu-sup2-tx-lwarn : SFU ONT - SFP tx power is lower than configured warn threshold - sfu-sup2-temp-hwarn : SFU ONT - SFP temperature is higher than configured warn threshold - sfu-sup2-temp-lwarn : SFU ONT - SFP temperature is lower than configured warn threshold - sfu-sup2-volt-hwarn : SFU ONT - SFP Voltage is higher than configured warn threshold - sfu-sup2-volt-lwarn : SFU ONT - SFP Voltage is lower than configured warn threshold - sfu-sup2-bias-hwarn : SFU ONT - SFP bias is higher than configured warn threshold - sfu-sup2-bias-lwarn : SFU ONT - SFP bias is lower than configured warn threshold - soho-sup2-temp-low : SOHO ONT - SFP temperature is lower than configured Alarm low threshold - soho-sup2-volt-low : SOHO ONT - SFP Voltage is lower than configured Alarm low threshold - soho-sup2-tx-high : SOHO ONT - SFP tx power is higher than configured Alarm low threshold - soho-sup2-bias-low : SOHO ONT - SFP bias is lower than configured Alarm low threshold - soho-sup2-rx-hwarn : SOHO ONT - SFP rx power is higher than warn threshold - soho-sup2-rx-lwarn : SOHO ONT - SFP rx power is lower than warn threshold - soho-sup2-tx-hwarn : SOHO ONT - SFP tx power is higher than warn threshold - soho-sup2-tx-lwarn : SOHO ONT - SFP tx power is lower than warn threshold - soho-sup2-temp-hwarn : SOHO ONT - SFP temperature is higher than warn threshold - soho-sup2-temp-lwarn : SOHO ONT - SFP temperature is lower than warn threshold - soho-sup2-volt-hwarn : SOHO ONT - SFP Voltage is higher than warn threshold - soho-sup2-volt-lwarn : SOHO ONT - SFP Voltage is lower than warn threshold - soho-sup2-bias-hwarn : SOHO ONT - SFP bias is higher than warn threshold - soho-sup2-bias-lwarn : SOHO ONT - SFP bias is lower than warn threshold - mdu-sup2-temp-low : MDU ONT - SFP temperature is lower than configured alarm low threshold - mdu-sup2-volt-low : MDU ONT - SFP Voltage is lower than configured alarm low threshold - mdu-sup2-tx-high : MDU ONT - SFP tx power is higher than configured alarm low threshold - mdu-sup2-bias-low : MDU ONT - SFP bias is lower than configured alarm low threshold - mdu-sup2-rx-hwarn : MDU ONT - SFP rx power is higher than warn threshold - mdu-sup2-rx-lwarn : MDU ONT - SFP rx power is lower than warn threshold - mdu-sup2-tx-hwarn : MDU ONT - SFP tx power is higher	

100 Alarm Delta Log Status Commands

name	Type	Description
	than warn threshold - mdu-sup2-tx-lwarn : MDU ONT - SFP tx power is lower than warn threshold - mdu-sup2-temp-hwarn : MDU ONT - SFP temperature is higher than warn threshold - mdu-sup2-temp-lwarn : MDU ONT - SFP temperature is lower than warn threshold - mdu-sup2-volt-hwarn : MDU ONT - SFP voltage is higher than warn threshold - mdu-sup2-volt-lwarn : MDU ONT - SFP voltage is lower than warn threshold - mdu-sup2-bias-hwarn : MDU ONT - SFP bias is higher than warn threshold - mdu-sup2-bias-lwarn : MDU ONT - SFP bias is lower than warn threshold - cust-alm1 : customizable alarm 1 - cust-alm2 : customizable alarm 2 - cust-alm3 : customizable alarm 3 - cust-alm4 : customizable alarm 4 - cust-alm5 : customizable alarm 5 - cust-alm6 : customizable alarm 6 - cust-alm7 : customizable alarm 7 - cust-alm8 : customizable alarm 8 - cust-alm9 : customizable alarm 9 - cust-alm10 : customizable alarm 10 - cust-alm11 : customizable alarm 11 - cust-alm12 : customizable alarm 12 - cust-alm13 : customizable alarm 13 - cust-alm14 : customizable alarm 14 - cust-alm15 : customizable alarm 15 - cust-alm16 : customizable alarm 16 - cust-alm17 : customizable alarm 17 - cust-alm18 : customizable alarm 18 - cust-alm19 : customizable alarm 19 - cust-alm20 : customizable alarm 20 - cust-alm21 : customizable alarm 21 - cust-alm22 : customizable alarm 22 - cust-alm23 : customizable alarm 23 - cust-alm24 : customizable alarm 24 - cust-alm25 : customizable alarm 25 - cust-alm26 : customizable alarm 26 - cust-alm27 : customizable alarm 27 - cust-alm28 : customizable alarm 28 - cust-alm29 : customizable alarm 29 - cust-alm30 : customizable alarm 30 - cust-alm31 : customizable alarm 31 - ethernet-ring-pthfwst : ethernet ring path forward state - ethernet-ring-fop-to : ethernet ring fop-to failure of protocol timeout - ethernet-ring-fop-pm : ethernet ring fop-pm failure of protocol provision mismatch - fpm-depletion : failsafe fpm depletion - exp-seizureack : Channel was blocked due to failure in the reception of the SEIZURE ACK signal - exp-disconack : Channel was blocked due to failure in the reception of the DISCONNECTION ACK signal - exp-forcerelack : Channel was blocked due to failure in the	

name	Type	Description
	reception of the BACKWARD DISCONNECTION ACK signal - packet-loss : Pseudo Wire entered the Packet loss state - remote-packet-loss : Remote Packet loss detected - no-dsp-resource : DSP resource allocation failed - la-down : Link aggregation group link-status is down - la-standby-na : Cross-lt lag on standby slot part is not available - la-switch-fail : Cross-lt lag fail to do switchover - la-degrade : Link aggregation group degrade - melt-board-reset : MELT board reset - board-shelf-mismatch : board type and shelf type mismatch - fcs-thresh-exceed : FCS counter threshold exceeded	
state	Parameter type: <Alarm::AlarmState> (active non-active) Possible values: - active : alarm is active - non-active : alarm is not active	reflect's the state of the alarm as either active or non-active. <i>This element is always shown.</i>
last-updated-on	Parameter type: <Sys::timeInSecs> - the time (yyyy-mm-dd:hour:minutes:secs) - unit: UTC	network time in seconds when the alarm was logged. <i>This element is always shown.</i>
additional-info	Parameter type: <Alarm::AdditionalInfo> - string to identify the owner (example: Tom) - length: x<=512	AdditionalInfo <i>This element is always shown.</i>

Only Show Details: minor alarm table related generic information		
name	Type	Description
changes	Parameter type: <Counter> - 32 bit counter	total number of changes of all reported alarms with a severity level minor since startup. <i>This element is only shown in detail mode.</i>
last-entry-id	Parameter type: <SignedInteger> - a signed integer	last entry that was added to the minor delta log. <i>This element is only shown in detail mode.</i>
last-reset	Parameter type: <Sys::Time> - the time (yyyy-mm-dd:hour:minutes:secs) - unit: UTC	network time in seconds indicating when the minor delta log was last reset. <i>This element is only shown in detail mode.</i>
log-overflowed	Parameter type: <Alarm::OverflowStatus> (yes no) Possible values: - yes : buffer has overflowed - no : no buffer overflow	specifies whether the minor delta log is overflowed or not. <i>This element is only shown in detail mode.</i>

100.6 Major Alarm Delta Log Status Command

Command Description

This command displays alarm values for all reported alarms with a severity level major.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

> show alarm delta-log major [(index)]

Command Parameters

Table 100.6-1 "Major Alarm Delta Log Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	delta log alarm table index

Command Output

Table 100.6-2 "Major Alarm Delta Log Status Command" Display parameters

Specific Information		
name	Type	Description
type	Parameter type: <Alarm::alarmIndexExt> (all xtca-ne-es xtca-ne-ses xtca-ne-uas xtca-ne-day-es xtca-ne-day-ses xtca-ne-day-uas xtca-fe-es xtca-fe-ses xtca-fe-uas xtca-fe-day-es xtca-fe-day-ses xtca-fe-day-uas xtca-leftrs xtca-day-leftrs xtca-fe-leftrs xtca-fe-day-leftrs xtca-auto-port-reset xtca-reinit	unique id for an alarm. <i>This element is always shown.</i>

name	Type	Description
	xtca-day-reinit	
	xdsl-ne-los	
	xdsl-ne-lof	
	xdsl-ne-lom	
	xdsl-ne-ese	
	xdsl-act-cfg-error	
	xdsl-act-not-feas	
	xdsl-up-br-reach	
	xdsl-ne-ncd	
	xdsl-ne-lcd	
	xdsl-fe-los	
	xdsl-fe-lof	
	xdsl-fe-lpr	
	xdsl-fe-lol	
	xdsl-fe-lom	
	xdsl-fe-ese	
	xdsl-fe-upbo-vio	
	xdsl-fe-cpe-pol	
	xdsl-tpstc-mis	
	xdsl-act-comm	
	xdsl-act-modem	
	xdsl-do-br-reach	
	xdsl-fe-ncd	
	xdsl-fe-lcd	
	xdsl-frtx-init-fail	
	xdsl-vect-dle	
	xdsl-fe-mis-peer-35b	
	vectline-xtc-var-vict	
	vectline-xtc-var-dist	
	vectline-corp-errf	
	vect-cpe-cap-mismatch	
	vectline-conf_notfeas	
	vect-vp-lt-mismatch	
	vect-inv-qsf	
	vect-vp-lt-fail	
	vect-no-gain-at-init	
	sw-rollback	
	db-rollback	
	xvps-inv-dbase	
	inv-cde-file	
	miss-cde-file	
	cde-hash-error	
	auto-fetch-failure	
	low-disk-space	
	cell-discard-up	
	cell-discard-down	
	persist-data-loss	
	mac-conflict	
	vmac-full	
	sntp-comm-lost	
	preferred-mode	
	timing-reference	
	nt-disk-95%full	
	shub-loc	
	cf-error	
	back-pnl-inv	
	ihub-conf-loss	

100 Alarm Delta Log Status Commands

name	Type	Description
	rack-power rack-fan-unit1 rack-fan-unit2 shelf-mismatch shelf-missing shelf-install-missing door ac-power-fail board-mismatch waiting-for-sw temp-exceeded backplane-data-failure temp-shutdown board-missing board-instl-missing board-init board-reset-prot sem-power-fail sem-ups-fail board-reset-cf vlan-assign-fail vsa-info-invalid auth-mac-conflict user-pwd-fault up-plan-bitrate up-min-bitrate up-config-not-feas down-plan-bitrate down-min-bitrate down-config-not-feas non-bonding-cpe multiple-cpes register group-incomplete host-sfp-los host-sfp-tx-fail host-sfp-not-prst host-sfp-inv-id host-sfp-ctrl-fail host-sfp-rmtlt host-sfp-mismatch host-sfp-incompt exp-sfp-los exp-sfp-tx-fail exp-sfp-not-prst exp-sfp-inv-id exp-sfp-ctrl-fail exp-sfp-1-los exp-sfp-2-los ext-qsfv-invld tx-power-high-alarm tx-power-low-alarm rx-power-high-alarm rx-power-low-alarm tx-biascur-high-alarm tx-biascur-low-alarm volt-high-alarm	

name	Type	Description
	volt-low-alarm temp-high-alarm temp-low-alarm tx-power-high-warn tx-power-low-warn rx-power-high-warn rx-power-low-warn tx-biascur-high-warn tx-biascur-low-warn volt-high-warn volt-low-warn temp-high-warn temp-low-warn onu-unprovisioned signal-loss bitrate-high opmodule-mismatch key-fail-one-churn key-fail-three-churn oam-discov-fail report-timeout total-packets-exceed arp-packets-exceed dhcp-packets-exceed igmp-packets-exceed pppoe-packets-exceed nd-packets-exceed icmpv6-packets-exceed mld-packets-exceed dhcpv6-packets-exceed cfm-packets-exceed dsx1-serdes-fail dsx1-tributary1-fail dsx1-tributary2-fail dsx1-los-fail dsx1-ais-sync dsx1-lof-sync dsx1-los-sync dsx1-deg-fail dsx1-rei-from-liu dsx1-rdi-from-liu dsx1-crc6-from-liu dsx1-crc4-from-liu dsx1-crc4-th-from-liu dsx1-ais-from-liu dsx1-los-from-liu dsx1-lof-from-liu dsx1-lomf-from-liu dsx1-rei-from-iwf dsx1-rdi-from-iwf dsx1-crc6-from-iwf dsx1-crc4-from-iwf dsx1-crc4-th-from-iwf dsx1-ais-from-iwf dsx1-los-from-iwf dsx1-lof-from-iwf dsx1-lomf-from-iwf	

100 Alarm Delta Log Status Commands

name	Type	Description
	pppce-trans-15min-tca pppce-sess-15min-tca pppce-trans-1day-tca pppce-sess-1day-tca custom1 custom2 custom3 custom4 custom5 he-custom1 he-custom2 he-custom3 he-custom4 he-custom5 he-custom6 custom6 custom7 custom8 custom9 custom10 custom11 custom12 custom13 custom14 custom15 custom16 custom17 loss-swo-cap ping-check-fail der-temp1 der-temp2 der-temp3 der-temp4 der-temp5 der-temp6 der-temp7 der-temp8 der-temp9 der-temp10 der-temp11 der-temp12 der-temp13 der-temp14 der-temp15 der-temp16 der-temp17 der-temp18 der-temp19 der-temp20 der-temp21 der-temp22 der-temp23 der-temp24 der-temp25 der-temp26 der-temp27 der-temp28	

name	Type	Description
	der-temp29	
	der-temp30	
	der-temp31	
	der-spa1	
	der-spa2	
	der-spa3	
	der-spa4	
	der-spa5	
	der-spa6	
	der-spa7	
	der-spa8	
	der-spa9	
	der-spa10	
	der-spa11	
	der-spa12	
	der-spa13	
	der-spa14	
	der-spa15	
	der-spa16	
	der-spa17	
	der-spa18	
	der-spa19	
	der-spa20	
	der-spa21	
	der-spa22	
	der-spa23	
	der-spa24	
	der-spa25	
	der-spa26	
	der-spa27	
	der-spa28	
	der-spa29	
	der-spa30	
	der-spa31	
	apsf-alarm	
	custextalarm1	
	custextalarm2	
	custextalarm3	
	custextalarm4	
	custextalarm5	
	pluginfan	
	plugin-dc-a	
	plugin-dc-b	
	plugin-dg	
	ntr-a-loss	
	ntr-b-loss	
	xvps-conf-loss	
	mac-entry-nofree	
	fibre-conn-mismatch	
	link-cap-mismatch	
	eqpt-cap-mismatch	
	ctrl-dnld-failure	
	melt-hw-issue	
	melt-board-reset	
	board-shelf-mismatch	
	mgnt-type-mismatch	
	fileserv-unavail	

100 Alarm Delta Log Status Commands

name	Type	Description
	shdsl-n-loopback	
	shdsl-c-loopback	
	shdsl-conferr	
	shdsl-atm-lcd	
	shdsl-lpr	
	shdsl-secu-err	
	shdsl-dev-fault	
	shdsl-atm-ncd	
	shdsl-n-losw	
	shdsl-c-losw	
	shdsl-n-aten	
	shdsl-c-aten	
	shdsl-n-snr	
	shdsl-c-snr	
	shdsl-n-dccont	
	shdsl-c-dccont	
	shdsl-c-actfail	
	e1-fe-rai	
	e1-ne-rai	
	e1-fe-ais	
	e1-ne-ais	
	e1-lof	
	e1-los	
	e1-loopback	
	ima-grp-fe-su	
	ima-grp-fe-cfg	
	ima-grp-ne-cfg	
	ima-grp-fe-nl	
	ima-grp-ne-nl	
	ima-grp-fe-blk	
	ima-lnk-lif	
	ima-lnk-lods	
	ima-lnk-misc	
	ima-lnk-rfi	
	ima-lnk-fault	
	ima-lnk-txblk	
	ima-lnk-rxblk	
	bad-digitmap	
	dhcp-unreach	
	dhcp-no-srv	
	dhcp-inv-srv	
	norpniewithsoftdsp	
	unknown-sub	
	ground-key	
	port-hightemp	
	port-jbfltca	
	reg-domainname	
	reg-auth	
	reg-timeout	
	reg-srvfailresp	
	inv-domainname	
	inv-auth	
	inv-timeout	
	inv-srvfailresp	
	subs-srvfailresp	
	subs-domainname	
	subs-auth	

name	Type	Description
	subs-refreshfail subs-inittimeout emergency-call e1sip-reg-domainname e1sip-reg-auth e1sip-reg-timeout e1sip-reg-srvfailresp e1sip-inv-domainname e1sip-inv-auth e1sip-inv-timeout e1sip-inv-srvfailresp e1sip-emergency-call e1itf-ais-signal e1itf-los-signal e1itf-rai-signal e1sip-misconfig-mgc10 e1sip-nsmprf-missed e1t1itf-recv-ais e1t1itf-recv-los e1t1itf-recv-rai transport-mismatch dns-lookup-failure none-dns-srv no-dns-srv none-srv no-srv reg-srv-unreach proxy-srv-unreach dhcp-srv-unreach fo-trigger fb-trigger du-trigger ssp-missing dns-pool-exceed lsa-fo-trigger reg-domainname-sec reg-auth-sec reg-timeout-sec reg-srvfailresp-sec inv-domainname-sec inv-auth-sec inv-timeout-sec inv-srvfailresp-sec subs-srvfailresp-sec subs-domainname-sec subs-auth-sec subs-refreshfail-sec subs-inittimeout-sec emergency-call-sec fanout up-overflow upobc-overflow dwobc-overflow dw-overflow lwpri-overflow queue-drop queue-load	

100 Alarm Delta Log Status Commands

name	Type	Description
	queue-peak-usage mgc-unreachable failover-to-esamgc sgc-unreachable lcard-unreach-srvcard lcard-type-mismatch meg-unknown-sub meg-ground-key meg-high-temp meg-act-fail meg-over-current line-showering low-qos-packetloss low-qos-jitter low-qos-delay sig-brd-persist-loss sig-brd-disk-full sig-brd-db-rollback mg-overload meg-unknown-sub-sec line-showering-sec loss-env-mon etca-los etca-fcs etca-day-los etca-day-fcs etca-rx-octets etca-tx-octets etca-day-rx-octets etca-day-tx-octets user-sfp-los user-sfp-tx-fail user-sfp-not-prst user-sfp-inv-id user-sfp-t-exceed user-sfp-mismatch uplink-sfp-los uplink-sfp-tx-fail uplink-sfp-not-prst uplink-sfp-inv-id uplink-sfp-t-exceed uplink-sfp-mismatch loss-lmswp-cap inv-xvps-pair-data network-power-loss hw-fault bat-miss bat-fail bat-low bat-a-fail bat-b-fail ac-vol-out-range network-power-loss-b sem-ac-power-fail sem-ups-low-volt dc-a-fail dc-b-fail	

name	Type	Description
	plan-power-mismatch water-seepage-in-box sealed-box-open dc-a-vol-out-range dc-b-vol-out-range inlet-temp-major inlet-temp-critical psu-fail-crit psu-a-fail-presence psu-a-fail-vin-ac-nok psu-a-fail-vin-uv psu-a-fail-vin-ov psu-a-fail-vout-uv psu-a-fail-vout-ov psu-a-fail-iout-oc psu-a-fail-vertemp psu-b-fail-presence psu-b-fail-vin-ac-nok psu-b-fail-vin-uv psu-b-fail-vin-ov psu-b-fail-vout-uv psu-b-fail-vout-ov psu-b-fail-iout-oc psu-b-fail-vertemp synce-fail bits-fail bits-output-shutoff ieee1588-fail gnss-fail ieee1588-hybrid-fail signal-loss signal-efd esmc-loss bits-output-exceed ql-input-exceed holdover lti tod-reference-fail internal-clk-fail bgp-peer-down bgp-routes-mid-limit isis-adjacency-down isis-adjacency-reject isis-instance-down ospf-lsa-limit ospf-lsa-mid-limit ospf-neighbor-down ospf-instance-down ospf3-lsa-limit ospf3-lsa-mid-limit ospf3-neighbor-down ospf3-instance-down rip-instance-down lag-down lagsubgrp-thresh-reach lagsubgrp-switch-fail no-unpinned-free-ports	

100 Alarm Delta Log Status Commands

name	Type	Description
	general-arp-limit gen-switch-out-of-res ipv6-nc-limit dhcp-session-oor ihub-fdb-limit ihub-mac-limit l2fw-stp-exception l2fw-stp-root-guard vprn-routes-limit vprn-ipv6-routes-limit dhcpv6-lease-limit dhcpv4-lease-limit vpls-mfib-limit ihub-ipv6-dad-own ihub-ipv6-dad ihub-ipv6-dup-pd-route vpls-duplicate-mac vpls-fdb-limit vpls-self-duplic-mac vpls-sdp-self-dup-mac link-down link-lagport-add-fail link-conf-mismatch ihub-peer-comm ihub-sw-fail ihub-hw-fail ihub-link-fail ihub-proc-overload ihub-out-of-mem ntp-comm-lost ldp-instance-down ldp-session-down mpls-instance-down mpls-lsp-down mpls-lsp-path-down sdp-instance-down sdp-binding-down epipe-instance-down lldpmed-portcfg-mis lldpmed-mediapl-mis vlanport-svc-mismatch mcsrc-stream-lost eqptsupl-syslog-upload eqptsupl-ontsw-dnload cf-75%used cf-90%used olt-gen-pon-com-fail olt-gen-tx-fail olt-gen-unprov-ont olt-gen-pon-eqpt-prov olt-gen-pon-loss-sig olt-gen-pon-diagnostic olt-gen-loid-conflict olt-gen-loid-pwderr olt-gen-pon-alien-test olt-gen-alien-detect olt-gen-rng-mism	

name	Type	Description
	olt-gen-sfp-mism	
	olt-gen-deact-hightca	
	olt-gen-deact-lowtca	
	olt-gen-dp-integ	
	olt-gen-ddr-fault	
	olt-pon-tc-err-frag-tc	
	olt-ont-tc-err-frag-tc	
	ont-ploam-loss-sig	
	ont-ploam-loss-ack	
	ont-ploam-loss-cd	
	ont-ploam-phy-eqpt-err	
	ont-ploam-startup-fail	
	ont-ploam-sig-degrade	
	ont-ploam-disabled	
	ont-ploam-err-msg	
	ont-ploam-inactive	
	ont-ploam-sig-fail	
	ont-ploam-dying-gasp	
	ont-ploam-deact-fail	
	ont-ploam-oam	
	ont-ploam-win-drift	
	ont-ploam-rdi	
	ont-ploam-loss-ks	
	ont-ploam-pwr-burst	
	ont-ploam-roq-disa	
	ont-ploam-diff-reach	
	ont-ploam-looc	
	sfu-ploam-loss-sig	
	sfu-ploam-loss-ack	
	sfu-ploam-loss-cd	
	sfu-ploam-phy-eqpt-err	
	sfu-ploam-startup-fail	
	sfu-ploam-sig-degrade	
	sfu-ploam-disabled	
	sfu-ploam-err-msg	
	sfu-ploam-inactive	
	sfu-ploam-sig-fail	
	sfu-ploam-dying-gasp	
	sfu-ploam-deact-fail	
	sfu-ploam-oam	
	sfu-ploam-win-drift	
	sfu-ploam-rdi	
	sfu-ploam-loss-ks	
	sfu-ploam-pwr-burst	
	sfu-ploam-roq-disa	
	sfu-ploam-diff-reach	
	sfu-ploam-looc	
	soho-ploam-loss-sig	
	soho-ploam-loss-ack	
	soho-ploam-loss-cd	
	soho-ploam-phy-eqpt-er	
	soho-ploam-startup-fai	
	soho-ploam-sig-degrade	
	soho-ploam-disabled	
	soho-ploam-err-msg	
	soho-ploam-inactive	
	soho-ploam-sig-fail	

100 Alarm Delta Log Status Commands

name	Type	Description
	soho-ploam-dying-gasp	
	soho-ploam-deact-fail	
	soho-ploam-oam	
	soho-ploam-win-drift	
	soho-ploam-rdi	
	soho-ploam-loss-ks	
	soho-ploam-pwr-burst	
	soho-ploam-roq-disa	
	soho-ploam-diff-reach	
	soho-ploam-looc	
	mdu-ploam-loss-sig	
	mdu-ploam-loss-ack	
	mdu-ploam-loss-cd	
	mdu-ploam-phy-eqpt-err	
	mdu-ploam-startup-fail	
	mdu-ploam-sig-degrade	
	mdu-ploam-disabled	
	mdu-ploam-err-msg	
	mdu-ploam-inactive	
	mdu-ploam-sig-fail	
	mdu-ploam-dying-gasp	
	mdu-ploam-deact-fail	
	mdu-ploam-oam	
	mdu-ploam-win-drift	
	mdu-ploam-rdi	
	mdu-ploam-loss-ks	
	mdu-ploam-pwr-burst	
	mdu-ploam-roq-disa	
	mdu-ploam-diff-reach	
	mdu-ploam-looc	
	ont-hpna-ser-mis	
	ont-hpna-los-sig	
	ont-moca-svc-mis	
	ont-moca-link-los	
	ont-moca-min-bw	
	ont-moca-tca-rx-err-fr	
	ont-sipa-reg-nm-fail	
	ont-sipa-reg-rec-fail	
	ont-sipa-reg-con-fail	
	ont-sipa-reg-val-fail	
	ont-sipa-reg-mis	
	ont-vcd-cfg-nm-fail	
	ont-vcd-cfg-rech-fail	
	ont-vcd-cfg-conn-fail	
	ont-vcd-cfg-vali-fail	
	ont-vcd-cfg-auth-fail	
	ont-vcd-cfg-resp-tmout	
	ont-vcd-cfg-resp-err	
	ont-vcd-cfg-file-err	
	ont-vcd-sub-nm-fail	
	ont-vcd-sub-rech-fail	
	ont-vcd-sub-conn-fail	
	ont-vcd-sub-vali-fail	
	ont-vcd-sub-auth-fail	
	ont-vcd-sub-resp-tmout	
	ont-vcd-sub-resp-err	
	ont-vcd-reb-requ	

name	Type	Description
	ont-vcd-mis	
	ont-mgc-mis	
	ont-mgc-timeout	
	ont-sip-reg-dns	
	ont-sip-reg-fail	
	ont-sip-reg-timeout	
	ont-sip-reg-err-resps	
	ont-sip-inv-dns	
	ont-sip-inv-auth	
	ont-sip-inv-timeout	
	ont-sip-inv-err	
	ont-svc-pots-subs-refr	
	ont-svc-pots-not-refr	
	ont-svc-pots-icfg-err	
	ont-veip-mismatch	
	ont-ip-host-mismatch	
	ont-ip-host-file	
	ont-ip-host-ip-alloc	
	olt-pon-up-bw-tca	
	olt-pon-down-bw-tca	
	ont-gen-omci-fail	
	ont-gen-eqpt-selftest	
	ont-gen-ac-pwr-fail	
	ont-gen-bat-missing	
	ont-gen-bat-low	
	ont-gen-bat-fail	
	ont-gen-phys-intrusion	
	ont-gen-sw-dnload-f	
	ont-gen-sw-dnload-p	
	ont-gen-sw-act-fail	
	ont-gen-eqpt-vers-mis	
	ont-gen-sw-vers-mis	
	ont-gen-us-rate-mis	
	ont-gen-mdu-env1	
	ont-gen-mdu-env2	
	ont-gen-mdu-env3	
	ont-gen-nw-time-err	
	ont-gen-opt-sig-high	
	ont-gen-opt-sig-low	
	ont-gen-eqpt-prov-sa	
	ont-gen-eqpt-prov-nsa	
	pon-t-txmcutilhi	
	pon-t-txmcutilmd	
	pon-t-txmcutillo	
	pon-t-txtotutilhi	
	pon-t-txtotutilmd	
	pon-t-txtotutillo	
	pon-t-rxtotutilhi	
	pon-t-rxtotutilmd	
	pon-t-rxtotutillo	
	pon-t-dbacongperiodhi	
	pon-t-dbacongperiodmd	
	pon-t-dbacongperiodlo	
	pon-t-txucdropfrmhi	
	pon-t-txucdropfrmd	
	pon-t-txucdropfrmlo	
	pon-t-txmcdropfrmhi	

100 Alarm Delta Log Status Commands

name	Type	Description
	pon-t-txmcdropfrmmd	
	pon-t-txmcdropfrmlo	
	pon-t-txbcdropfrmhi	
	pon-t-txbcdropfrmmd	
	pon-t-txbcdropfrmlo	
	pon-t-rxtotdropfrmhi	
	pon-t-rxtotdropfrmmd	
	pon-t-rxtotdropfrmlo	
	chpr-t-txmcutilhi	
	chpr-t-txmcutilmd	
	chpr-t-txmcutillo	
	chpr-t-txtotutilhi	
	chpr-t-txtotutilmd	
	chpr-t-txtotutillo	
	chpr-t-rxtotutilhi	
	chpr-t-rxtotutilmd	
	chpr-t-rxtotutillo	
	chpr-t-dbacongperiodhi	
	chpr-t-dbacongperiodmd	
	chpr-t-dbacongperiodlo	
	chpr-t-txucdropfrmhi	
	chpr-t-txucdropfrmmd	
	chpr-t-txucdropfrmlo	
	chpr-t-txmcdropfrmhi	
	chpr-t-txmcdropfrmmd	
	chpr-t-txmcdropfrmlo	
	chpr-t-txbcdropfrmhi	
	chpr-t-txbcdropfrmmd	
	chpr-t-txbcdropfrmlo	
	chpr-t-rxtotdropfrmhi	
	chpr-t-rxtotdropfrmmd	
	chpr-t-rxtotdropfrmlo	
	sfu-gen-omci-fail	
	sfu-gen-eqpt-selftest	
	sfu-gen-ac-pwr-fail	
	sfu-gen-bat-missing	
	sfu-gen-bat-low	
	sfu-gen-bat-fail	
	sfu-gen-sw-dnload-f	
	sfu-gen-sw-dnload-p	
	sfu-gen-sw-act-fail	
	sfu-gen-eqpt-vers-mis	
	sfu-gen-sw-vers-mis	
	sfu-gen-us-rate-mis	
	sfu-gen-tune-fail	
	sfu-gen-nw-time-err	
	sfu-gen-opt-sig-high	
	sfu-gen-opt-sig-low	
	sfu-gen-eqpt-prov-sa	
	sfu-gen-eqpt-prov-nsa	
	soho-gen-omci-fail	
	soho-gen-eqpt-selftest	
	soho-gen-ac-pwr-fail	
	soho-gen-bat-missing	
	soho-gen-bat-low	
	soho-gen-bat-fail	
	soho-gen-sw-dnload-f	

name	Type	Description
	soho-gen-sw-dnload-p	
	soho-gen-sw-act-fail	
	soho-gen-eqpt-vers-mis	
	soho-gen-sw-vers-mis	
	soho-gen-us-rate-mis	
	soho-gen-tune-fail	
	soho-gen-nw-time-err	
	soho-gen-opt-sig-high	
	soho-gen-opt-sig-low	
	soho-gen-eqpt-prov-sa	
	soho-gen-eqpt-prov-nsa	
	mdu-gen-omci-fail	
	mdu-gen-eqpt-selftest	
	mdu-gen-ac-pwr-fail	
	mdu-gen-bat-missing	
	mdu-gen-bat-low	
	mdu-gen-bat-fail	
	mdu-gen-phys-intrusion	
	mdu-gen-sw-dnload-f	
	mdu-gen-sw-dnload-p	
	mdu-gen-sw-act-fail	
	mdu-gen-eqpt-vers-mis	
	mdu-gen-sw-vers-mis	
	mdu-gen-us-rate-mis	
	mdu-gen-tune-fail	
	mdu-gen-mdu-env1	
	mdu-gen-mdu-env2	
	mdu-gen-mdu-env3	
	mdu-gen-nw-time-err	
	mdu-gen-opt-sig-high	
	mdu-gen-opt-sig-low	
	mdu-gen-eqpt-prov-sa	
	mdu-gen-eqpt-prov-nsa	
	ont-gen-sw-dnload-file	
	ont-gen-fan-fail	
	ont-gen-high-temp	
	ont-gen-high-temp-ex	
	ont-gen-emergency-call	
	ont-gen-sw-version	
	ont-poe-exceed-max	
	ont-poe-overload-yell	
	ont-opti-malfunc	
	ont-gen-cfgdld-fail	
	ont-gen-rssi-mis	
	ont-gen-tx-pwr-low	
	ont-gen-temp-high	
	ont-gen-volt-high	
	ont-gen-bias-high	
	ont-loopdetect-mis	
	ont-olt-rx-pw-lo	
	ont-olt-rx-pw-hig	
	ont-olt-rx-pw-warnlo	
	ont-olt-rx-pw-warnhig	
	ont-gen-tod-out-sync	
	ont-gen-tune-fail	
	hgu-tr069-parm-fail	
	ont-gen-tod-mismatch	

100 Alarm Delta Log Status Commands

name	Type	Description
	sfu-sup-sw-file-error	
	sfu-sup-fan-failure	
	sfu-sup-temp-high-warn	
	sfu-sup-temp-shutoff	
	sfu-sup-emergency-call	
	sfu-sup-swverctrl-err	
	sfu-sup-poe-exceed-max	
	sfu-sup-poe-over-yell	
	sfu-opti-malfunc	
	sfu-sup-cfg-dnld-fail	
	sfu-sup-rssi-cfg-mism	
	sfu-sup-sfp-tx-low	
	sfu-sup-sfp-temp-high	
	sfu-sup-sfp-volt-high	
	sfu-sup-sfp-bias-high	
	sfu-sup-ld-cfg-mism	
	sfu-sup-olt-rx-low	
	sfu-sup-olt-rx-high	
	sfu-sup-olt-rx-lo-warn	
	sfu-sup-olt-rx-hi-warn	
	sfu-sup-tod-out-sync	
	sfu-sup-ont-tune-fail	
	sfu-tr069-parm-fail	
	sfu-sup-tod-mismatch	
	soho-sup-sw-file-error	
	soho-sup-fan-failure	
	soho-sup-temp-high-war	
	soho-sup-temp-shutoff	
	soho-sup-emergency-cal	
	soho-sup-swverctrl-err	
	soho-sup-poe-exceed-ma	
	soho-sup-poe-over-yell	
	soho-opti-malfunc	
	soho-sup-cfg-dnld-fail	
	soho-sup-rssi-cfg-mism	
	soho-sup-sfp-tx-low	
	soho-sup-sfp-temp-high	
	soho-sup-sfp-volt-high	
	soho-sup-sfp-bias-high	
	soho-sup-ld-cfg-mism	
	soho-sup-olt-rx-low	
	soho-sup-olt-rx-high	
	soho-sup-olt-rx-lo-war	
	soho-sup-olt-rx-hi-war	
	soho-sup-tod-out-sync	
	soho-sup-ont-tune-fail	
	soho-tr069-parm-fail	
	soho-sup-tod-mismatch	
	mdu-sup-sw-file-error	
	mdu-sup-fan-failure	
	mdu-sup-temp-high-warn	
	mdu-sup-temp-shutoff	
	mdu-sup-emergency-call	
	mdu-sup-swverctrl-err	
	mdu-sup-poe-exceed-max	
	mdu-sup-poe-over-yell	
	mdu-opti-malfunc	

name	Type	Description
	mdu-sup-cfg-dnld-fail mdu-sup-rssi-cfg-mism mdu-sup-sfp-tx-low mdu-sup-sfp-temp-high mdu-sup-sfp-volt-high mdu-sup-sfp-bias-high mdu-sup-ld-cfg-mism mdu-sup-olt-rx-low mdu-sup-olt-rx-high mdu-sup-olt-rx-lo-warn mdu-sup-olt-rx-hi-warn mdu-sup-tod-out-sync mdu-sup-ont-tune-fail mdu-tr069-parm-fail mdu-sup-tod-mismatch ont-sbscr-lim-missing ont-sbscr-lim-type-mis ont-sbscr-lim-removal ont-sbscr-lim-fail ont-sbscr-lim-svc-mis ont-sbscr-lim-port-mis ont-svc-video-conf-mis ont-svc-video-pw-high ont-svc-video-pw-low ont-svc-pots-svc-mis ont-svc-pots-rtcp-lost ont-svc-pots-icnf-subs ont-svc-pots-icnf-ntfy ont-svc-pots-icnf-http ont-svc-pots-sip-reg ont-svc-pots-sip-inv ont-svc-pots-sip-subsc ont-svc-pots-sip-mt-tc ont-svc-pots-pk-los-tc ont-svc-pots-jitter-tc ont-svc-pots-subs-dns ont-svc-pots-subs-tcp ont-svc-pots-subs-tls ont-svc-pots-subs-auth ont-svc-pots-subs-to ont-svc-pots-subs-err ont-svc-pots-not-to ont-svc-pots-notref-to ont-svc-pots-not-mal ont-svc-pots-not-rej ont-svc-pots-http-dns ont-svc-pots-http-tcp ont-svc-pots-http-tls ont-svc-pots-http-auth ont-svc-pots-http-to ont-svc-pots-http-err ont-svc-pots-http-mal ont-svc-pots-insuff ont-svc-pots-poos ont-svc-lan-mismatch ont-svc-lan-loss-sig ont-svc-enet-poos	

100 Alarm Delta Log Status Commands

name	Type	Description
	ont-svc-ces-ds1-mis	
	ont-svc-ces-ds1-los	
	ont-svc-ces-ds1-lof	
	ont-svc-ces-ds1-rair	
	ont-svc-ces-ds1-ais	
	ont-svc-ces-ds1-lnlpbk	
	ont-svc-ces-ds1-tmlpbk	
	ont-svc-ces-e1-mis	
	ont-svc-ces-e1-los	
	ont-svc-ces-e1-lof	
	ont-svc-ces-e1-rair	
	ont-svc-ces-e1-ais	
	ont-svc-voip-cnf-file	
	ont-svc-voip-svc-mis	
	ont-svc-voip-gw-comm	
	ont-svc-voip-dhcp-fail	
	ont-svc-voip-icnf-sub	
	ont-svc-voip-icnf-ntfy	
	ont-svc-voip-icnf-http	
	ont-svc-voip-dhcp-to	
	ont-svc-voip-dhcp-mal	
	ont-svc-voip-dhcp-noad	
	ont-svc-voip-dhcp-leas	
	ont-svc-voip-sub-dns	
	ont-svc-voip-sub-tcp	
	ont-svc-voip-sub-tls	
	ont-svc-voip-sub-auth	
	ont-svc-voip-sub-to	
	ont-svc-voip-sub-err	
	ont-svc-voip-not-to	
	ont-svc-voip-notref-to	
	ont-svc-voip-not-mal	
	ont-svc-voip-not-rej	
	ont-svc-voip-http-dns	
	ont-svc-voip-http-tcp	
	ont-svc-voip-http-tls	
	ont-svc-voip-http-auth	
	ont-svc-voip-http-to	
	ont-svc-voip-http-err	
	ont-svc-voip-http-mal	
	ont-svc-voip-sub-refr	
	ont-svc-voip-not-refr	
	ont-svc-voip-icfg-err	
	ont-svc-v-ani-conf-mis	
	ont-svc-v-ani-loss-sig	
	ont-svc-v-ani-lv-high	
	ont-svc-v-ani-lv-low	
	ont-svc-pwe-mismatch	
	ont-svc-pwe-reordr-lof	
	ont-svc-pwe-jitt-buf-o	
	ont-svc-pwe-jitt-buf-u	
	ont-svc-pwe-malf-frms	
	ont-svc-pwe-late-frms	
	ont-svc-pwe-link-loss	
	ont-svc-pwe-arp-fail	
	ont-svc-xdsl-mismatch	
	ont-svc-xdsl-ne-lof	

name	Type	Description
	ont-svc-xdsl-ne-los ont-svc-xdsl-ne-line ont-svc-xdsl-ne-lol ont-svc-xdsl-fe-lof ont-svc-xdsl-fe-los ont-svc-xdsl-fe-lop ont-svc-xdsl-cnf-err ont-svc-xdsl-ne-es-tc ont-svc-xdsl-ne-ses-tc ont-svc-xdsl-ne-uas-tc ont-svc-xdsl-fe-es-tc ont-svc-xdsl-fe-ses-tc ont-svc-xdsl-fe-uas-tc ont-tc-rx-los-frag-tc ont-tc-tx-los-frag-tc ont-tc-bad-gem-hd-tc ont-uni-ds-drp-d-fr-tc ont-uni-up-drp-d-fr-tc ont-uni-ds-crc-fr-tc ont-uni-up-crc-fr-tc ont-cpu-util-tca ont-mem-util-tca pim-neighbor-down pim-max-mcroutes li-traffic-disabled li-bandwidth-limit li-out-of-res otdr-cap-mismatch login-successful login-failure cfm-defrdiccm cfm-defmacstatus cfm-defremoteccm cfm-deferrorccm cfm-defxconccm cfm-defais bfd-session-down bfd-max-resource bfd-stale-entry tca-outputbw tca-inputbw tca-rxcrcalign tca-txcrcalign tca-txcollisions tca-outputhighbw tca-outputmedbw tca-outputlowbw tca-inputhighbw tca-inputmediumbw tca-inputlowbw eth-cfm-defrdiccm eth-cfm-defmacstatus eth-cfm-defremoteccm eth-cfm-deferrorccm eth-cfm-defxconccm rsvp-neighbor-down rsvp-instance-down	

100 Alarm Delta Log Status Commands

name	Type	Description
	eth-ring-path-block	
	ai-platform-down	
	ai-appl-install-fail	
	ip-assign-fail	
	ont-tr069-serv-mis	
	ont-snmp-mis	
	bsf-dhcpv4	
	bsf-dhcpv6	
	bsf-pon	
	bsf-vbridge	
	bsf-qos	
	bsf-igmp	
	bsf-lxfwd	
	prot-not-available	
	prot-switchover-fail	
	efm-oam-cpelinkfault	
	efm-oam-cpedyinggasp	
	efm-oam-cpecrevt	
	ont-loopdetect	
	alarm-tbl-overflow	
	auto-switch-status	
	auswqueuefullatm	
	auswbkpfailatm	
	auswrecfgfailatm	
	auswdataunatm	
	auswqueuefulptm	
	auswbkpfailptm	
	auswrecfgfailptm	
	auswdataunptm	
	auswbakpfailatm	
	chpr-com-fail	
	chpr-tx-fail	
	chpr-unprov-ont	
	chpr-prov-mismatch	
	chpr-loss-sig	
	chpr-diagnostic	
	chpr-loid-conflict	
	chpr-loid-pwd-err	
	chpr-stk-laser-dis	
	chpr-sfp-mismatch	
	chpr-rng-mismatch	
	chpr-alien-test	
	chpr-alien-detect	
	chpr-deact-hightca	
	chpr-deact-lowtca	
	chpr-dp-integ	
	olt-chpr-tc-err-frag	
	olt-chpr-up-bw-tca	
	olt-chpr-down-bw-tca	
	cfg-dld-fail	
	cfg-act-fail	
	cfg-dld-ip	
	cfg-ver-mismatch	
	cfg-file-missing	
	cfg-verctrl-err	
	cfg-not-supported	
	ont-prot-not-available	

name	Type	Description
	ont-gen-temp-low	
	ont-gen-volt-low	
	ont-gen-tx-pwr-high	
	ont-gen-bias-low	
	ont-gen-rx-hwarn	
	ont-gen-rx-lwarn	
	ont-gen-tx-hwarn	
	ont-gen-tx-lwarn	
	ont-gen-temp-hwarn	
	ont-gen-temp-lwarn	
	ont-gen-volt-hwarn	
	ont-gen-volt-lwarn	
	ont-gen-bias-hwarn	
	ont-gen-bias-lwarn	
	sfu-sup2-temp-low	
	sfu-sup2-volt-low	
	sfu-sup2-tx-high	
	sfu-sup2-bias-low	
	sfu-sup2-rx-hwarn	
	sfu-sup2-rx-lwarn	
	sfu-sup2-tx-hwarn	
	sfu-sup2-tx-lwarn	
	sfu-sup2-temp-hwarn	
	sfu-sup2-temp-lwarn	
	sfu-sup2-volt-hwarn	
	sfu-sup2-volt-lwarn	
	sfu-sup2-bias-hwarn	
	sfu-sup2-bias-lwarn	
	soho-sup2-temp-low	
	soho-sup2-volt-low	
	soho-sup2-tx-high	
	soho-sup2-bias-low	
	soho-sup2-rx-hwarn	
	soho-sup2-rx-lwarn	
	soho-sup2-tx-hwarn	
	soho-sup2-tx-lwarn	
	soho-sup2-temp-hwarn	
	soho-sup2-temp-lwarn	
	soho-sup2-volt-hwarn	
	soho-sup2-volt-lwarn	
	soho-sup2-bias-hwarn	
	soho-sup2-bias-lwarn	
	mdu-sup2-temp-low	
	mdu-sup2-volt-low	
	mdu-sup2-tx-high	
	mdu-sup2-bias-low	
	mdu-sup2-rx-hwarn	
	mdu-sup2-rx-lwarn	
	mdu-sup2-tx-hwarn	
	mdu-sup2-tx-lwarn	
	mdu-sup2-temp-hwarn	
	mdu-sup2-temp-lwarn	
	mdu-sup2-volt-hwarn	
	mdu-sup2-volt-lwarn	
	mdu-sup2-bias-hwarn	
	mdu-sup2-bias-lwarn	
	cust-alm1	

100 Alarm Delta Log Status Commands

name	Type	Description
	cust-alm2 cust-alm3 cust-alm4 cust-alm5 cust-alm6 cust-alm7 cust-alm8 cust-alm9 cust-alm10 cust-alm11 cust-alm12 cust-alm13 cust-alm14 cust-alm15 cust-alm16 cust-alm17 cust-alm18 cust-alm19 cust-alm20 cust-alm21 cust-alm22 cust-alm23 cust-alm24 cust-alm25 cust-alm26 cust-alm27 cust-alm28 cust-alm29 cust-alm30 cust-alm31 ethernet-ring-pthfwst ethernet-ring-fop-to ethernet-ring-fop-pm fpm-depletion exp-seizureack exp-disconack exp-forcerelack packet-loss remote-packet-loss no-dsp-resource la-down la-standby-na la-switch-fail la-degrade melt-board-reset board-shelf-mismatch fcs-thresh-exceed) Possible values: - all : all alarms for query - xtca-ne-es : errored seconds in 15 min - xtca-ne-ses : severely errored seconds in 15 min - xtca-ne-uas : unavailable seconds in 15 min - xtca-ne-day-es : errored seconds in 1 day - xtca-ne-day-ses : severely errored seconds in 1 day - xtca-ne-day-uas : unavailable seconds in 1 day - xtca-fe-es : errored seconds in 15 min - xtca-fe-ses : severely errored secs in 15 min	

name	Type	Description
	- xtca-fe-uas : unavailable seconds in 15 min - xtca-fe-day-es : errored seconds in 1 day - xtca-fe-day-ses : severely errored secs in 1 day - xtca-fe-day-uas : unavailable seconds in 1 day - xtca-leftrs : low error free throughput seconds in 15 min - xtca-day-leftrs : low error free throughput seconds in 1 day - xtca-fe-leftrs : far end low error free throughput seconds in 15 min - xtca-fe-day-leftrs : far end low error free throughput seconds in 1 day - xtca-auto-port-reset : auto-port-resets in 1 week - xtca-reinit : Reinitialization seconds in 15 min - xtca-day-reinit : Reinitialization seconds in 1 day - xdsl-ne-los : loss of signal - xdsl-ne-lof : loss of frame - xdsl-ne-lom : loss of margin - xdsl-ne-ese : excessive severe errors - xdsl-act-cfg-error : line configuration data cannot be used - xdsl-act-not-feas : line capacity not enough to setup requested profile - xdsl-up-br-reach : planned bitrate not reached after initialization - xdsl-ne-ncd : no cell delineation - xdsl-ne-lcd : loss of cell delineation - xdsl-fe-los : loss of signal - xdsl-fe-lof : loss of frame - xdsl-fe-lpr : loss of power - xdsl-fe-lol : loss of link - xdsl-fe-lom : loss of margin - xdsl-fe-ese : excessive severe errors - xdsl-fe-upbo-vio : upbo violation - xdsl-fe-cpe-pol : activation failure cpe policing - xdsl-tpstc-mis : mismatch between the configured tps-tc mode and the mode supported by the connected cpe - xdsl-act-comm : init not successful due to communications problem - xdsl-act-modem : no peer modem detected - xdsl-do-br-reach : planned bitrate not reached after init - xdsl-fe-ncd : no cell delineation - xdsl-fe-lcd : loss of cell delineation - xdsl-fctx-init-fail : init not successful due to forced rtx - xdsl-vect-dle : vectoring disorderly leaving event - xdsl-fe-mis-peer-35b : VDSL2 35b opmode mismatch between XTU-C and XTU-R - vectline-xtc-var-vict : excessive victim crosstalk coefficients variation - vectline-xtc-var-dist : excessive disturber crosstalk coefficients variation - vectline-corp-errf : corrupted or missing errorf-samples - vect-cpe-cap-mismatch : not allowed Vectoring CPE connected - vectline-conf_notfeas : vect line configuration not feasible - vect-vp-lt-mismatch : actual vp-lt connection(s) do not match expected vp-lt connection(s) or vp-lt connection lost - vect-inv-qsf : qsf has no valid Nokia ID - vect-vp-lt-fail : vp-lt connection not operational - vect-no-gain-at-init : Lines cannot train in gain-at-init	

100 Alarm Delta Log Status Commands

name	Type	Description
	mode - sw-rollback : non active oswp,db cannot be operational - will rollback - db-rollback : selected oswp,db cannot be operational - will rollback - xvps-inv-dbase : invalid xvps dbase - inv-cde-file : invalid xvps cde file - miss-cde-file : missing cde profile - cde-hash-error : cde profile hash error - auto-fetch-failure : not able to fetch file from specified server - low-disk-space : insufficient space for Sw storage - cell-discard-up : cell discarded in the upstream direction - cell-discard-down : cell discarded in the downstream direction - persist-data-loss : all data lost after restart - system not configured - mac-conflict : duplicate mac address on the bridge port - vmac-full : virtual mac address is full on the bridge port - sntp-comm-lost : sntp server not responding - preferred-mode : preferred mode not available - timing-reference : timing reference failure - nt-disk-95%full : nt disk 95% full - shub-loc : communication lost with shub - cf-error : compact flash access error - back-pnl-inv : BackPanel-type Invalid - ihub-conf-loss : iHub configuration loss - recent changes lost - rack-power : power fuse broken - rack-fan-unit1 : fan unit rack 1 failing - rack-fan-unit2 : fan unit rack 2 failing - shelf-mismatch : shelf type different from planned type - shelf-missing : detected shelf no longer detected - shelf-install-missing : shelf planned but not installed - door : open cabinet door - ac-power-fail : external power failure - shelf shutdown in 15 minutes - board-mismatch : board inserted different from planned - waiting-for-sw : not able to download all the applicable sw files - temp-exceeded : temperature threshold exceeded on the board - backplane-data-failure: It port on backplane data failure - temp-shutdown : board powered down itself - too high temperature - board-missing : board detected after planning - now missing - board-instl-missing : board never detected after planning - board-init : board initialisation failure - board-reset-prot : number of resets exceeded - sem-power-fail : SEM external power failure - sem-ups-fail : SEM external power supply failure - board-reset-cf : board reset and/or communication failure - vlan-assign-fail : failure to assign VLAN for a user session - vsa-info-invalid : radius fail to assign a valid vsa to a user session - auth-mac-conflict : failure to check mac conflict for a user	

name	Type	Description
	session - user-pwd-fault : failure to check user or password of a user session - up-plan-bitrate : upstream bitrate is above min and below planned - up-min-bitrate : upstream bitrate is below min bitrate - up-config-not-feas : upstream bitrate is not enough to set up config group - down-plan-bitrate : downstream bitrate is above min and below planned - down-min-bitrate : downstream bitrate is below min bitrate - down-config-not-feas : downstream bitrate is not enough to set up config group - non-bonding-cpe : no bonding cpe modem is connected - multiple-cpes : bonding group has multiple cpe modems connected - register : bonding group discovery or aggregation register failure - group-incomplete : bonding group is incomplete - host-sfp-los : loss of signal - host-sfp-tx-fail : Tx failure - host-sfp-not-prst : not present - host-sfp-inv-id : no valid Nokia ID - host-sfp-ctrl-fail : control failure - host-sfp-rmtlt : unexpected remote plug-in - host-sfp-mismatch : assignment does not match reported rack/shelf/slot - host-sfp-incompt : incompatible shelf type detected - exp-sfp-los : expansion side loss of signal - exp-sfp-tx-fail : Tx failure - exp-sfp-not-prst : not present - exp-sfp-inv-id : no valid Nokia ID - exp-sfp-ctrl-fail : control failure - exp-sfp-1-los : expansion side sfp1 loss of signal - exp-sfp-2-los : expansion side sfp2 loss of signal - ext-qsfp-invlid : Invalid Nokia ID - tx-power-high-alarm : tx power more than alarm range - tx-power-low-alarm : tx power less than alarm range - rx-power-high-alarm : rx power more than alarm range - rx-power-low-alarm : rx power less than alarm range - tx-biascur-high-alarm : tx bias current high alarm - tx-biascur-low-alarm : tx bias current low alarm - volt-high-alarm : voltage high alarm - volt-low-alarm : voltage low alarm - temp-high-alarm : temperature high alarm - temp-low-alarm : temperature low alarm - tx-power-high-warn : tx power more than warn range - tx-power-low-warn : tx power less than warn range - rx-power-high-warn : rx power more than warn range - rx-power-low-warn : rx power less than warn range - tx-biascur-high-warn : tx bias current high warn - tx-biascur-low-warn : tx bias current low warn - volt-high-warn : voltage high warn - volt-low-warn : voltage low warn - temp-high-warn : temperature high warn - temp-low-warn : temperature low warn - onu-unprovisioned : unprovisioned ont	

100 Alarm Delta Log Status Commands

name	Type	Description
	- signal-loss : pon loss of signal - bitrate-high : the error bit rate high at pon interface - opmodule-mismatch : the optical module mismatched at pon interface - key-fail-one-churn : key exchange failure during one churning time - key-fail-three-churn : key exchange failure during three churning time - oam-discov-fail : extend oam discovery failure - report-timeout : report timeout detecting - total-packets-exceed : total amount of protocol packets exceed threshold - arp-packets-exceed : protocol arp packets exceed threshold - dhcp-packets-exceed : protocol dhcp packets exceed threshold - igmp-packets-exceed : protocol igmp packets exceed threshold - pppoe-packets-exceed : protocol pppoe packets exceed threshold - nd-packets-exceed : protocol nd packets exceed threshold - icmpv6-packets-exceed : protocol icmpv6 packets exceed threshold - mld-packets-exceed : protocol mld packets exceed threshold - dhcpv6-packets-exceed : protocol dhcpv6 packets exceed threshold - cfm-packets-exceed : protocol cfm packets exceed threshold - dsx1-serdes-fail : SERDES clock alarm failure - dsx1-tributary1-fail : The tributary 1 clock is not present - dsx1-tributary2-fail : The tributary 2 clock is not present - dsx1-los-fail : All the selected tribs in Loss of Signal - dsx1-ais-sync : Alarm Indication signal on the tributary selected as sync source - dsx1-lof-sync : Loss of Framing on the tributary selected as sync source - dsx1-los-sync : Loss of signal on the tributary selected as sync source - dsx1-deg-fail : Signal degrade Alarm - dsx1-rei-from-liu : Remote Error Indication alarm from LIU - dsx1-rdi-from-liu : Remote Defect Alarm from LIU - dsx1-crc6-from-liu : Cyclic Redundancy check-6 alarm from LIU - dsx1-crc4-from-liu : Cyclic Redundancy check-4 alarm from LIU - dsx1-crc4-th-from-liu : Cyclic Redundancy check-4 threshold alarm from LIU - dsx1-ais-from-liu : Alarm Indication Signal alarm from LIU - dsx1-los-from-liu : Loss of signal alarm from LIU - dsx1-lof-from-liu : Loss of framing alarm from LIU - dsx1-lomf-from-liu : Loss of Multi-frame alarm from LIU - dsx1-rei-from-iwf : Remote Error Indication alarm from IWF - dsx1-rdi-from-iwf : Remote Defect Alarm from IWF - dsx1-crc6-from-iwf : Cyclic Redundancy check-6 alarm	

name	Type	Description
	from IWF - dsx1-crc4-from-iwf : Cyclic Redundancy check-4 alarm from IWF - dsx1-crc4-th-from-iwf : Cyclic Redundancy check-4 threshold alarm from IWF - dsx1-ais-from-iwf : Alarm Indication Signal alarm from IWF - dsx1-los-from-iwf : Loss of signal alarm from IWF - dsx1-lof-from-iwf : Loss of framing alarm from IWF - dsx1-lomf-from-iwf : Loss of Multi-frame alarm from IWF - pppce-trans-15min-tca : 15 minutes transaction timeout count exceeds configured TCA - pppce-sess-15min-tca : 15 minutes session timeout count exceeds configured TCA - pppce-trans-1day-tca : 1day transaction timeout count exceeds configured TCA - pppce-sess-1day-tca : 1day session timeout count exceeds configured TCA - custom1 : customizable alarm 1 - custom2 : customizable alarm 2 - custom3 : customizable alarm 3 - custom4 : customizable alarm 4 - custom5 : customizable alarm 5 - he-custom1 : host expansion customizable alarm 1 - he-custom2 : host expansion customizable alarm 2 - he-custom3 : host expansion customizable alarm 3 - he-custom4 : host expansion customizable alarm 4 - he-custom5 : host expansion customizable alarm 5 - he-custom6 : host expansion customizable alarm 6 - custom6 : customizable alarm 6 - custom7 : customizable alarm 7 - custom8 : customizable alarm 8 - custom9 : customizable alarm 9 - custom10 : customizable alarm 10 - custom11 : customizable alarm 11 - custom12 : customizable alarm 12 - custom13 : customizable alarm 13 - custom14 : customizable alarm 14 - custom15 : customizable alarm 15 - custom16 : customizable alarm 16 - custom17 : customizable alarm 17 - loss-swo-cap : switch over capability in a redundant system - ping-check-fail : ping check in a redundant system - der-temp1 : Derived Alarm for Temporal Filter 1 - der-temp2 : Derived Alarm for Temporal Filter 2 - der-temp3 : Derived Alarm for Temporal Filter 3 - der-temp4 : Derived Alarm for Temporal Filter 4 - der-temp5 : Derived Alarm for Temporal Filter 5 - der-temp6 : Derived Alarm for Temporal Filter 6 - der-temp7 : Derived Alarm for Temporal Filter 7 - der-temp8 : Derived Alarm for Temporal Filter 8 - der-temp9 : Derived Alarm for Temporal Filter 9 - der-temp10 : Derived Alarm for Temporal Filter 10 - der-temp11 : Derived Alarm for Temporal Filter 11 - der-temp12 : Derived Alarm for Temporal Filter 12 - der-temp13 : Derived Alarm for Temporal Filter 13 - der-temp14 : Derived Alarm for Temporal Filter 14	

100 Alarm Delta Log Status Commands

name	Type	Description
	- der-temp15 : Derived Alarm for Temporal Filter 15 - der-temp16 : Derived Alarm for Temporal Filter 16 - der-temp17 : Derived Alarm for Temporal Filter 17 - der-temp18 : Derived Alarm for Temporal Filter 18 - der-temp19 : Derived Alarm for Temporal Filter 19 - der-temp20 : Derived Alarm for Temporal Filter 20 - der-temp21 : Derived Alarm for Temporal Filter 21 - der-temp22 : Derived Alarm for Temporal Filter 22 - der-temp23 : Derived Alarm for Temporal Filter 23 - der-temp24 : Derived Alarm for Temporal Filter 24 - der-temp25 : Derived Alarm for Temporal Filter 25 - der-temp26 : Derived Alarm for Temporal Filter 26 - der-temp27 : Derived Alarm for Temporal Filter 27 - der-temp28 : Derived Alarm for Temporal Filter 28 - der-temp29 : Derived Alarm for Temporal Filter 29 - der-temp30 : Derived Alarm for Temporal Filter 30 - der-temp31 : Derived Alarm for Temporal Filter 31 - der-spa1 : Derived Alarm for Spatial Filter 1 - der-spa2 : Derived Alarm for Spatial Filter 2 - der-spa3 : Derived Alarm for Spatial Filter 3 - der-spa4 : Derived Alarm for Spatial Filter 4 - der-spa5 : Derived Alarm for Spatial Filter 5 - der-spa6 : Derived Alarm for Spatial Filter 6 - der-spa7 : Derived Alarm for Spatial Filter 7 - der-spa8 : Derived Alarm for Spatial Filter 8 - der-spa9 : Derived Alarm for Spatial Filter 9 - der-spa10 : Derived Alarm for Spatial Filter 10 - der-spa11 : Derived Alarm for Spatial Filter 11 - der-spa12 : Derived Alarm for Spatial Filter 12 - der-spa13 : Derived Alarm for Spatial Filter 13 - der-spa14 : Derived Alarm for Spatial Filter 14 - der-spa15 : Derived Alarm for Spatial Filter 15 - der-spa16 : Derived Alarm for Spatial Filter 16 - der-spa17 : Derived Alarm for Spatial Filter 17 - der-spa18 : Derived Alarm for Spatial Filter 18 - der-spa19 : Derived Alarm for Spatial Filter 19 - der-spa20 : Derived Alarm for Spatial Filter 20 - der-spa21 : Derived Alarm for Spatial Filter 21 - der-spa22 : Derived Alarm for Spatial Filter 22 - der-spa23 : Derived Alarm for Spatial Filter 23 - der-spa24 : Derived Alarm for Spatial Filter 24 - der-spa25 : Derived Alarm for Spatial Filter 25 - der-spa26 : Derived Alarm for Spatial Filter 26 - der-spa27 : Derived Alarm for Spatial Filter 27 - der-spa28 : Derived Alarm for Spatial Filter 28 - der-spa29 : Derived Alarm for Spatial Filter 29 - der-spa30 : Derived Alarm for Spatial Filter 30 - der-spa31 : Derived Alarm for Spatial Filter 31 - apsf-alarm : Applique Power Supply Failure - custextalarm1 : Customizable External Alarm Number 1 - custextalarm2 : Customizable External Alarm Number 2 - custextalarm3 : Customizable External Alarm Number 3 - custextalarm4 : Customizable External Alarm Number 4 - custextalarm5 : Customizable External Alarm Number 5 - pluginfan : REM Fan Alarm - plugin-dc-a : REM DC A Alarm - plugin-dc-b : REM DC B Alarm	

name	Type	Description
	- plugin-dg : Dying Gasp Alarm - ntr-a-loss : NTR-A signal is not available - ntr-b-loss : NTR-B signal is not available - xvps-conf-loss : xvps configuration loss - mac-entry-nofree : no free mac entry in the mac table on It board - fibre-conn-mismatch : REM Fibre Connection Mismatch Alarm - link-cap-mismatch : Link speed capability mismatch - eqpt-cap-mismatch : Link equipment capability mismatch - ctrl-dnld-failure : Controller card download failure - melt-hw-issue : MELT hardware issue - melt-board-reset : MELT board reset - board-shelf-mismatch : board type and shelf type mismatch - mgnt-type-mismatch : Board management type mismatch - fileserv-unavail : file transfer Server unavailable or file transfer failed - shdsl-n-loopback : loopback active at the network side - shdsl-c-loopback : loopback active at the customer side - shdsl-conferr : configuration error - shdsl-atm-lcd : loss of atm cell delineation - shdsl-lpr : loss of power at stu-r - shdsl-secu-err : unable to disable stu-r access - shdsl-dev-fault : device fault - shdsl-atm-ncd : no atm cell delineation - shdsl-n-losw : loss of sync word at the network side on each pair - shdsl-c-losw : loss of sync word at the customer side on each pair - shdsl-n-aten : loop attenuation alarm at the network side on each pair - shdsl-c-aten : loop attenuation alarm at the customer side on each pair - shdsl-n-snr : snr margin alarm at the network side each pair - shdsl-c-snr : snr margin alarm at the customer side on each pair - shdsl-n-dccont : dc continuity fault at the network side on each pair - shdsl-c-dccont : dc continuity fault at the customer side on each pair - shdsl-c-actfail : activation failure at the customer side on each pair - e1-fe-rai : Receiving Remote Alarm Indication - e1-ne-rai : Transmitting Remote Alarm Indication - e1-fe-ais : Receiving Alarm Indication Signal - e1-ne-ais : Transmitting Alarm Indication Signal - e1-lof : E1 Loss of frame - e1-los : E1 Loss of Signal - e1-loopback : E1 facility in loopback - ima-grp-fe-su : far-end starting up - ima-grp-fe-cfg : far-end failed configuration - ima-grp-ne-cfg : near-end failed configuration - ima-grp-fe-nl : insufficient number of links at far-end - ima-grp-ne-nl : insufficient number of links at near-end - ima-grp-fe-blk : far-end is blocked - ima-lnk-lif : loss of ima frame - ima-lnk-lods : link out of delay synchronization	

100 Alarm Delta Log Status Commands

name	Type	Description
	- ima-lnk-misc : link misconnect - ima-lnk-rfi : link remote failure indication - ima-lnk-fault : fault in link facility - ima-lnk-txblk : transmit blocked due to far-end - ima-lnk-rxblk : receive blocked due to far-end - bad-digitmap : Configured digitmap is unusable - dhcp-unreach : The DHCP server is unreachable - dhcp-no-srv : The address in DHCP reply is NULL - dhcp-inv-srv : The address in DHCP reply is invalid - norpniewithsoftdsp : do not plan / plug-in RPNI-E board with SoftDsp SW image - unknown-sub : subscriber exist in the POLT, but not in the appl server - ground-key : Return current to the ground - port-hightemp : Temperature threshold on user port exceeded. - port-jbfltca : JB fill level threshold on user port exceeded. - reg-domainname : Registration failure (resolving domain name). - reg-auth : Registration failure (authentication). - reg-timeout : Registration failure (message timeout). - reg-srvfailresp : Registration failure (failure response from server). - inv-domainname : Invitation failure (resolving domain name). - inv-auth : Invitation failure (authentication). - inv-timeout : Invitation failure (message timeout). - inv-srvfailresp : Invitation failure (failure response from server). - subs-srvfailresp : Subscribe failure (failure response from server). - subs-domainname : Subscribe failure (resolving domain name). - subs-auth : Subscribe failure (authentication). - subs-refreshfail : Subscribe failure (refresh failure). - subs-inittimeout : Subscribe failure (initial REQ timeout). - emergency-call : Emergency call for SIP POTS is ongoing. - e1sip-reg-domainname : E1 sip termination registration failure (resolving domain name). - e1sip-reg-auth : E1 sip termination registration failure (authentication). - e1sip-reg-timeout : E1 sip termination registration failure (message timeout). - e1sip-reg-srvfailresp : E1 sip termination registration failure (failure response from server). - e1sip-inv-domainname : E1 sip termination invitation failure (resolving domain name). - e1sip-inv-auth : E1 sip termination invitation failure (authentication). - e1sip-inv-timeout : E1 sip termination invitation failure (message timeout). - e1sip-inv-srvfailresp : E1 sip invitation failure (failure response from server). - e1sip-emergency-call : Emergency call for ISDN PRA/CAS R2 is ongoing. - e1itf-ais-signal : Alarm Indication Signal detected at E1 interface.	

name	Type	Description
	- e1itf-los-signal : Loss Of Signal detected at E1 interface. - e1itf-rai-signal : Remote Alarm Indication detected at E1 interface. - e1sip-misconfig-mgc10 : Configuration not conform with the core network entity. - e1sip-nsmprf-missed : The SIP termination requires a NSM profile. - e1t1itf-recv-ais : Alarm Indication Signal received at interface. - e1t1itf-recv-los : Loss Of Signal received at interface. - e1t1itf-recv-rai : Remote Alarm Indication received at interface. - transport-mismatch : Transport protocol mismatch - dns-lookup-failure : Dns look up failure - none-dns-srv : No reply for all DNS serverd - no-dns-srv : No DNS servers configured - none-srv : No reply for all SIP First Hops - no-srv : No SIP First Hop configured - reg-srv-unreach : All SIP register servers are unreachable - proxy-srv-unreach : All SIP proxy servers are unreachable - dhcp-srv-unreach : The DHCP server is unreachable on this board - fo-trigger : Fail Over Triggered - fb-trigger : Fail Back Triggered - du-trigger : Deliberate Update Triggered - ssp-missing : SSP Missing in CDE - dns-pool-exceed : Number of different SG associated DNS pools exceed - lsa-fo-trigger : SIP voice service degraded - fail-over to LSA server - reg-domainname-sec : Registration failure (resolving domain name). - reg-auth-sec : Registration failure (authentication). - reg-timeout-sec : Registration failure (message timeout). - reg-srvfailresp-sec : Registration failure (failure response from server). - inv-domainname-sec : Invitation failure (resolving domain name). - inv-auth-sec : Invitation failure (authentication). - inv-timeout-sec : Invitation failure (message timeout). - inv-srvfailresp-sec : Invitation failure (failure response from server). - subs-srvfailresp-sec : Subscribe failure (failure response from server). - subs-domainname-sec : Subscribe failure (resolving domain name). - subs-auth-sec : Subscribe failure (authentication). - subs-refreshfail-sec : Subscribe failure (refresh failure). - subs-inittimeout-sec : Subscribe failure (initial REQ timeout). - emergency-call-sec : Emergency call for Secondary Termination is ongoing. - fanout : Lt load overflow - up-overflow : Upstream load overflow - upobc-overflow : Upstream load to OBC overflow - dwobc-overflow : Downstream load to OBC overflow - dw-overflow : Downstream load overflow	

100 Alarm Delta Log Status Commands

name	Type	Description
	- lwpri-overflow : The number of BE and CL pkts dropped exceed threshold - queue-drop : The number of pkts dropped by queue exceeds threshold - queue-load : The queue load exceeds threshold - queue-peak-usage : The queue peak usage exceeds threshold - mgc-unreachable : loss of contact with the media gateway controller - failover-to-esamgc : failover to esa mgc - sgc-unreachable : loss of contac with signaling gateway controller - lcard-unreach-srvcard : line card unreachable with server card - lcard-type-mismatch : associate board of wrong type - meg-unknown-sub : the megaco subscriber is unknown - meg-ground-key : voice port ground key - meg-high-temp : voice port high temperature - meg-act-fail : the first link layer for isdn subscriber activation failure - meg-over-current : voice port over current - line-showering : line showering - low-qos-packetloss : the total packet loss has exceeded the configured threshold - low-qos-jitter : the rtp jitter has exceeded the configured threshold - low-qos-delay : the rtp delay has exceeded the configured threshold - sig-brd-persist-loss : voice signaling board persistent data loss - sig-brd-disk-full : voice signaling board disk 90% full - sig-brd-db-rollback : voice signaling board db rollback - mg-overload : mg overload - meg-unknown-sub-sec : The Megaco subscriber exists in voice signaling board but not in media gateway controller. - line-showering-sec : A subscriber line exceeds 20 off-hook / on-hook events / minute. - loss-env-mon : env-monitor box lost or not alive - etca-los : loss of signal errors in 15 min - etca-fcs : frame check sequence errors in 15 min - etca-day-los : loss of signal errors in 1 day - etca-day-fcs : frame check sequence errors in 1 day - etca-rx-octets : received octets in 15 min - etca-tx-octets : transmitted octets in 15 min - etca-day-rx-octets : received octets in 1 day - etca-day-tx-octets : transmitted octets in 1 day - user-sfp-los : user sfp loss of signal - user-sfp-tx-fail : user sfp tx failure - user-sfp-not-prst : user sfp not detected - user-sfp-inv-id : user sfp invalid id - user-sfp-t-exceed : user sfp temperature exceed - user-sfp-mismatch : user sfp mismatch the configured type - uplink-sfp-los : uplink sfp loss of signal - uplink-sfp-tx-fail : uplink sfp tx failure - uplink-sfp-not-prst : uplink sfp not detected - uplink-sfp-inv-id : uplink sfp invalid id - uplink-sfp-t-exceed : uplink sfp temperature exceed	

name	Type	Description
	- uplink-sfp-mismatch : uplink sfp mismatch the configured type - loss-lsmwp-cap : lsm redundancy - inv-xvps-pair-data : invalid xvps pair redundancy data - network-power-loss : Loss of Network Power - hw-fault : Hardware Failure - bat-miss : Power Source Battery Missing - bat-fail : Power Source Battery Failure - bat-low : Power Source Battery Charge LOW - bat-a-fail : Power Source BAT-A Fail - bat-b-fail : Power Source BAT-B Fail - ac-vol-out-range : AC Input Voltage Value Out of Range - network-power-loss-b : Loss of Network Power B - sem-ac-power-fail : External AC power supply failure - sem-ups-low-volt : External power supply low voltage - dc-a-fail : Local DC A power failure - dc-b-fail : Local DC B power failure - plan-power-mismatch : Planned and detected power mode mismatch - water-seepage-in-box : Detected water seepage in enclosure - sealed-box-open : Sealed box open detected - dc-a-vol-out-range : DC A Input Voltage Value Out of Range - dc-b-vol-out-range : DC B Input Voltage Value Out of Range - inlet-temp-major : The inlet temperature has exceeded a major level - inlet-temp-critical : The inlet temperature has exceeded a critical level - psu-fail-crit : Power Supply failure - psu-a-fail-presence : Power Supply A is not present - psu-a-fail-vin-ac-nok : Power Supply A has Vin AC fault - psu-a-fail-vin-uv : Power Supply A has Vin undervoltage - psu-a-fail-vin-ov : Power Supply A has Vin overvoltage - psu-a-fail-vout-uv : Power Supply A has Vout undervoltage - psu-a-fail-vout-ov : Power Supply A has Vout overvoltage - psu-a-fail-iout-oc : Power Supply A has Iout overcurrent - psu-a-fail-ovtemp : Power Supply A has over temperature - psu-b-fail-presence : Power Supply B is not present - psu-b-fail-vin-ac-nok : Power Supply B has Vin AC fault - psu-b-fail-vin-uv : Power Supply B has Vin undervoltage - psu-b-fail-vin-ov : Power Supply B has Vin overvoltage - psu-b-fail-vout-uv : Power Supply B has Vout undervoltage - psu-b-fail-vout-ov : Power Supply B has Vout overvoltage - psu-b-fail-iout-oc : Power Supply B has Iout overcurrent - psu-b-fail-ovtemp : Power Supply B has over temperature - synce-fail : synce clock source failure - bits-fail : bits clock source failure - bits-output-shutoff : bits output failure - ieee1588-fail : ieee1588 clock source failure - gnss-fail : gnss clock source failure - ieee1588-hybrid-fail : ieee1588 hybrid tod source failure	

100 Alarm Delta Log Status Commands

name	Type	Description
	- signal-loss : synce or bits clock signal loss - signal-efd : synce or bits clock signal exceed frequency deviation - esmc-loss : clock source loss SSM information - bits-output-exceed : exceed bits output threshold - ql-input-exceed : exceed input clock source threshold - holdover : clock system is in the holdover - lti : all clock source failed - tod-reference-fail : Timing ToD Reference failed - internal-clk-fail : Internal CLK failed - bgp-peer-down : peer operational state is down - bgp-routes-mid-limit : 90% of max nbr of routes BGP can learn from a peer is reached - isis-adjacency-down : isis adjacency is down - isis-adjacency-reject : isis adjacency is rejected - isis-instance-down : isis instance is down or not - ospf-lsa-limit : limit of received LSA's is reached - ospf-lsa-mid-limit : 90% of limit of received LSA's is reached - ospf-neighbor-down : OSPF neighbour is down - ospf-instance-down : OSPF instance is down or not - ospf3-lsa-limit : limit of received OSPFv3 LSAs is reached - ospf3-lsa-mid-limit : 90% of limit of received OSPFv3 LSAs is reached - ospf3-neighbor-down : OSPFv3 neighbour is down - ospf3-instance-down : OSPFv3 instance is down or not - rip-instance-down : rip instance down - lag-down : lag down - lagsubgrp-thresh-reach: lag subgroup threshold reached - lagsubgrp-switch-fail : lag subgroup switchover failed - no-unpinned-free-ports: No free ports available for unpinned traffic - general-arp-limit : arp limit exceeded - gen-switch-out-of-res : failure due to lack of resources on switch - ipv6-nc-limit : ipv6 neighbor cache limit exceeded - dhcp-session-oor : dhcp session out of resources - ihub-fdb-limit : layer 2 fdb limit reached - ihub-mac-limit : layer 2 mac limit reached - l2fw-stp-exception : STP exception condition is present in the SAP - l2fw-stp-root-guard : STP root guard violation is present - vprn-routes-limit : limit of ip is reached - vprn-ipv6-routes-limit: limit of ipv6 is reached - dhcpv6-lease-limit : limit of dhcpv6 leases is reached - dhcpv4-lease-limit : limit of dhcpv4 leases is reached - vpls-mfib-limit : limit of fib table is reached - ihub-ipv6-dad-own : duplicate IPV6 address is detected for IP address allotted to system - ihub-ipv6-dad : duplicate IPV6 address is detected for a user's IP address - ihub-ipv6-dup-pd-route: ipv6 duplicate pd detected - vpls-duplicate-mac : duplicate mac address is detected - vpls-fdb-limit : limit of fdb table is reached - vpls-self-dup-mac : duplicate of a system owned mac address detected on a sap - vpls-sdp-self-dup-mac : duplicate of a system owned mac	

name	Type	Description
	address detected on a sdp binding - link-down : link is down - link-lagport-add-fail : failure to add port to LAG - link-conf-mismatch : SFP+plugin-types does not match the planned speed and/or auto-negotiation for the port - ihub-peer-comm : ihub peer to peer communication failure - ihub-sw-fail : IHUB s/w error - ihub-hw-fail : IHUB h/w error - ihub-link-fail : IHUB link failure - ihub-proc-overload : IHUB processor exceeded - ihub-out-of-mem : IHUB processor out of memory - ntp-comm-lost : No response is received from the NTP servers - ldp-instance-down : ldp instance down - ldp-session-down : ldp session down - mpls-instance-down : mpls instance down - mpls-lsp-down : lsp down - mpls-lsp-path-down : lsp path down - sdp-instance-down : sdp instance down - sdp-binding-down : sdp binding down - epipe-instance-down : epipe instance down - lldpmed-portcfg-mis : config request failure for lldpmed portconfig - lldpmed-mediapl-mis : config request failure for lldpmed mediapolicy - vlanport-svc-mismatch : config request failure for the provisioned vlanport - mcsrc-stream-lost : multicast video stream lost - eqptsupl-syslog-upload: upload of log file to remote server failure - eqptsupl-ontsw-dnload : ont sw download in progress - cf-75%used : Compact flash exceeds 75% of life expectancy - cf-90%used : Compact flash exceeds 90% of life expectancy - olt-gen-pon-com-fail : pon communication failure on olt - olt-gen-tx-fail : transmitter failure on olt - olt-gen-unprov-ont : unprovisioned ont on pon - olt-gen-pon-eqpt-prov : mismatch btw equipment and provisioning pon attributes - olt-gen-pon-loss-sig : pon loss of signal - olt-gen-pon-diagnostic: pon diagnostic test active - olt-gen-loid-conflict : loid conflict ont on pon - olt-gen-loid-pwderr : loid password error ont on pon - olt-gen-pon-alien-test: pon alien diagnostic test active - olt-gen-alien-detect : pon alien detect active - olt-gen-rng-mism : pon ranging mismatch active - olt-gen-sfp-mism : pon sfp mismatch active - olt-gen-deact-hightca : deactivated ont hightca threshold crossed - olt-gen-deact-lowtca : deactivated ont lowtca threshold crossed - olt-gen-dp-integ : pon data path integriy failure - olt-gen-ddr-fault : pon failure due to ddr fault - olt-pon-tc-err-frag-tc: pon errored fragments threshold crossed - olt-ont-tc-err-frag-tc: ont errored fragments threshold	

100 Alarm Delta Log Status Commands

name	Type	Description
	crossed - ont-ploam-loss-sig : loss of signal at ont - ont-ploam-loss-ack : loss of acknowledge from ont - ont-ploam-loss-cd : loss of channel delineation of ont - ont-ploam-phy-eqpt-err: physical equipment error of ont - ont-ploam-startup-fail: startup failure in ranging of ont - ont-ploam-sig-degrade : signal degrade from ont - ont-ploam-disabled : ont disabled alarm - ont-ploam-err-msg : error message from ont - ont-ploam-inactive : inactive ont - ont-ploam-sig-fail : signal fail alarm from ont - ont-ploam-dying-gasp : dying gasp alarm from ont - ont-ploam-deact-fail : deactive failure of ont - ont-ploam-oam : loss of ploam for ont - ont-ploam-win-drift : drift of window alarm - ont-ploam-rdi : remote defect indication alarm - ont-ploam-loss-ks : loss of key synchronization alarm - ont-ploam-pwr-burst : power bursts on ont - ont-ploam-rog-disa : ont rogue disabled - ont-ploam-diff-reach : ont differential reach exceeded - ont-ploam-looc : Loss of OMCI channel due to persistent MIC failure - sfu-ploam-loss-sig : SFU ONT - loss of signal at ont - sfu-ploam-loss-ack : SFU ONT - loss of acknowledge from ont - sfu-ploam-loss-cd : SFU ONT - loss of channel delineation of ont - sfu-ploam-phy-eqpt-err: SFU ONT - physical equipment error of ont - sfu-ploam-startup-fail: SFU ONT - startup failure in ranging of ont - sfu-ploam-sig-degrade : SFU ONT - signal degrade from ont - sfu-ploam-disabled : SFU ONT - ont disabled alarm - sfu-ploam-err-msg : SFU ONT - error message from ont - sfu-ploam-inactive : SFU ONT - inactive ont - sfu-ploam-sig-fail : SFU ONT - signal fail alarm from ont - sfu-ploam-dying-gasp : SFU ONT - dying gasp alarm from ont - sfu-ploam-deact-fail : SFU ONT - deactive failure of ont - sfu-ploam-oam : SFU ONT - loss of ploam for ont - sfu-ploam-win-drift : SFU ONT - drift of window alarm - sfu-ploam-rdi : SFU ONT - remote defect indication alarm - sfu-ploam-loss-ks : SFU ONT - loss of key synchronization alarm - sfu-ploam-pwr-burst : SFU ONT - power bursts on ont - sfu-ploam-rog-disa : SFU ONT - ont rogue disabled - sfu-ploam-diff-reach : SFU ONT - ont differential reach exceeded - sfu-ploam-looc : SFU ONT - Loss of OMCI channel due to persistent MIC failure - soho-ploam-loss-sig : SOHO ONT - loss of signal at ont - soho-ploam-loss-ack : SOHO ONT - loss of acknowledge from ont - soho-ploam-loss-cd : SOHO ONT - loss of channel delineation of ont - soho-ploam-phy-eqpt-er: SOHO ONT - physical	

name	Type	Description
	equipment error of ont - soho-ploam-startup-fai: SOHO ONT - startup failure in ranging of ont - soho-ploam-sig-degrade: SOHO ONT - signal degrade from ont - soho-ploam-disabled : SOHO ONT - ont disabled alarm - soho-ploam-err-msg : SOHO ONT - error message from ont - soho-ploam-inactive : SOHO ONT - inactive ont - soho-ploam-sig-fail : SOHO ONT - signal fail alarm from ont - soho-ploam-dying-gasp : SOHO ONT - dying gasp alarm from ont - soho-ploam-deact-fail : SOHO ONT - deactive failure of ont - soho-ploam-oam : SOHO ONT - loss of ploam for ont - soho-ploam-win-drift : SOHO ONT - drift of window alarm - soho-ploam-rdi : SOHO ONT - remote defect indication alarm - soho-ploam-loss-ks : SOHO ONT - loss of key synchronization alarm - soho-ploam-pwr-burst : SOHO ONT - power bursts on ont - soho-ploam-rog-disa : SOHO ONT - ont rogue disabled - soho-ploam-diff-reach : SOHO ONT - ont differential reach exceeded - soho-ploam-looc : SOHO ONT - Loss of OMCI channel due to persistent MIC failure - mdu-ploam-loss-sig : MDU ONT - loss of signal at ont - mdu-ploam-loss-ack : MDU ONT - loss of acknowledge from ont - mdu-ploam-loss-cd : MDU ONT - loss of channel delineation of ont - mdu-ploam-phy-eqpt-err: MDU ONT - physical equipment error of ont - mdu-ploam-startup-fail: MDU ONT - startup failure in ranging of ont - mdu-ploam-sig-degrade : MDU ONT - signal degrade from ont - mdu-ploam-disabled : MDU ONT - ont disabled alarm - mdu-ploam-err-msg : MDU ONT - error message from ont - mdu-ploam-inactive : MDU ONT - inactive ont - mdu-ploam-sig-fail : MDU ONT - signal fail alarm from ont - mdu-ploam-dying-gasp : MDU ONT - dying gasp alarm from ont - mdu-ploam-deact-fail : MDU ONT - deactive failure of ont - mdu-ploam-oam : MDU ONT - loss of ploam for ont - mdu-ploam-win-drift : MDU ONT - drift of window alarm - mdu-ploam-rdi : MDU ONT - remote defect indication alarm - mdu-ploam-loss-ks : MDU ONT - loss of key synchronization alarm - mdu-ploam-pwr-burst : MDU ONT - power bursts on ont - mdu-ploam-rog-disa : MDU ONT - ont rogue disabled - mdu-ploam-diff-reach : MDU ONT - ont differential reach exceeded	

100 Alarm Delta Log Status Commands

name	Type	Description
	- mdu-ploam-looc : MDU ONT - Loss of OMCI channel due to persistent MIC failure - ont-hpna-ser-mis : hpna ont service mismatch - ont-hpna-los-sig : hpna loss of link - ont-moca-svc-mis : moca ont service mismatch - ont-moca-link-los : moca loss of link - ont-moca-min-bw : moca bw between nodes less than minimum bw - ont-moca-tca-rx-err-fr: moca rx errored frames threshold crossed - ont-sipa-reg-nm-fail : sipua registration name failed - ont-sipa-reg-rec-fail : sipua register reach failed - ont-sipa-reg-con-fail : sipua register connect failed - ont-sipa-reg-val-fail : sipua register validation failed - ont-sipa-reg-mis : sipua register mismatch - ont-vcd-cfg-nm-fail : vcd config name failed - ont-vcd-cfg-rech-fail : vcd config reach failed - ont-vcd-cfg-conn-fail : vcd config connect failed - ont-vcd-cfg-vali-fail : vcd config validation failed - ont-vcd-cfg-auth-fail : vcd config authentication failed - ont-vcd-cfg-resp-tmout: vcd config response timeout - ont-vcd-cfg-resp-err : vcd config response error - ont-vcd-cfg-file-err : vcd config file error - ont-vcd-sub-nm-fail : vcd subscription name failed - ont-vcd-sub-rech-fail : vcd subscription reach failed - ont-vcd-sub-conn-fail : vcd subscription connect failed - ont-vcd-sub-vali-fail : vcd subscription validation failed - ont-vcd-sub-auth-fail : vcd subscription authentication failed - ont-vcd-sub-resp-tmout: vcd subscription response timeout - ont-vcd-sub-resp-err : vcd subscription response error - ont-vcd-reb-requ : vcd reboot request - ont-vcd-mis : vcd mismatch - ont-mgc-mis : ont mgc mismatch - ont-mgc-timeout : ont mgc timeout - ont-sip-reg-dns : ont services pots sip registration failed (resolving domain name) - ont-sip-reg-fail : ont services pots sip registration authentication failed - ont-sip-reg-timeout : ont services pots sip registration timeout - ont-sip-reg-err-resps : ont services pots sip registration response error - ont-sip-inv-dns : ont services pots sip invitation failed (resolving domain name) - ont-sip-inv-auth : ont services pots sip invitation authentication failed - ont-sip-inv-timeout : ont services pots sip invitation timeout - ont-sip-inv-err : ont services pots sip invitation response error - ont-svc-pots-subs-refr: ont services pots iconfig subscription could not be refreshed - ont-svc-pots-not-refr : ont services pots iconfig notification could not be refreshed - ont-svc-pots-icfg-err : ont services pots service failed due to an unmapped iconfig error	

name	Type	Description
	- ont-veip-mismatch : ont veip mismatch - ont-ip-host-mismatch : ont ip host mismatch - ont-ip-host-file : ont ip host file unavailable - ont-ip-host-ip-alloc : ont ip host IP allocation failure - olt-pon-up-bw-tca : OLT PON upstream bandwidth TCA - olt-pon-down-bw-tca : OLT PON downstream bandwidth TCA - ont-gen-omci-fail : loss of communication - ont-gen-eqpt-selftest : ont self-test failure - ont-gen-ac-pwr-fail : ac power failure on ont - ont-gen-bat-missing : battery missing - ont-gen-bat-low : battery low - ont-gen-bat-fail : battery failure - ont-gen-phys-intrusion: physical intrusion - ont-gen-sw-dnload-f : ont sw download failure - ont-gen-sw-dnload-p : ont sw download in progress - ont-gen-sw-act-fail : ont sw activation failure - ont-gen-eqpt-vers-mis : ont equipment version mismatch - ont-gen-sw-vers-mis : ont sw version mismatch - ont-gen-us-rate-mis : ont upstream rate mismatch - ont-gen-mdu-env1 : mdu environmental alarm#1 - ont-gen-mdu-env2 : mdu environmental alarm#2 - ont-gen-mdu-env3 : mdu environmental alarm#3 - ont-gen-nw-time-err : network timing protocol error - ont-gen-opt-sig-high : optical signal level too high - ont-gen-opt-sig-low : optical signal level too low - ont-gen-eqpt-prov-sa : service affecting mismatch btw equipment and provisioning attributes - ont-gen-eqpt-prov-nsa : non service affecting mismatch btw equipment and provisioning attributes - pon-t-txmcutilhi : pon utilization tx (downstream) multicast high threshold crossed - pon-t-txmcutilmd : pon utilization tx (downstream) multicast medium threshold crossed - pon-t-txmcutillo : pon utilization tx (downstream) multicast low threshold crossed - pon-t-txtotutilhi : pon utilization tx (downstream) total high threshold crossed - pon-t-txtotutilmd : pon utilization tx (downstream) total medium threshold crossed - pon-t-txtotutillo : pon utilization tx (downstream) total low threshold crossed - pon-t-rxtotutilhi : pon utilization rx (upstream) total high threshold crossed - pon-t-rxtotutilmd : pon utilization rx (upstream) total medium threshold crossed - pon-t-rxtotutillo : pon utilization rx (upstream) total low threshold crossed - pon-t-dbacongperiodhi : pon utilization rx (upstream) dbacongperiod high threshold crossed - pon-t-dbacongperiodmd : pon utilization rx (upstream) dbacongperiod medium threshold crossed - pon-t-dbacongperiodlo : pon utilization rx (upstream) dbacongperiod low threshold crossed - pon-t-txucdropfrmhi : pon utilization tx (downstream) unicast drop frame high threshold crossed - pon-t-txucdropfrmd : pon utilization tx (downstream)	

name	Type	Description
	unicast drop frame medium threshold crossed - pon-t-txucdropfrmlo : pon utilization tx (downstream) unicast drop frame low threshold crossed - pon-t-txmcdropfrmhi : pon utilization tx (downstream) multicast drop frame high threshold crossed - pon-t-txmcdropfrmmd : pon utilization tx (downstream) multicast drop frame medium threshold crossed - pon-t-txmcdropfrmlo : pon utilization tx (downstream) multicast drop frame low threshold crossed - pon-t-txbcdropfrmhi : pon utilization tx (downstream) broadcast drop frame high threshold crossed - pon-t-txbcdropfrmmd : pon utilization tx (downstream) broadcast drop frame medium threshold crossed - pon-t-txbcdropfrmlo : pon utilization tx (downstream) broadcast drop frame low threshold crossed - pon-t-rxtotdropfrmhi : pon utilization rx (upstream) total drop frame high threshold crossed - pon-t-rxtotdropfrmmd : pon utilization rx (upstream) total drop frame medium threshold crossed - pon-t-rxtotdropfrmlo : pon utilization rx (upstream) total drop frame low threshold crossed - chpr-t-txmcutilhi : channel-pair utilization tx (downstream) multicast high threshold crossed - chpr-t-txmcutilmd : channel-pair utilization tx (downstream) multicast medium threshold crossed - chpr-t-txmcutillo : channel-pair utilization tx (downstream) multicast low threshold crossed - chpr-t-txtotutilhi : channel-pair utilization tx (downstream) total high threshold crossed - chpr-t-txtotutilmd : channel-pair utilization tx (downstream) total medium threshold crossed - chpr-t-txtotutillo : channel-pair utilization tx (downstream) total low threshold crossed - chpr-t-rxtotutilhi : channel-pair utilization rx (upstream) total high threshold crossed - chpr-t-rxtotutilmd : channel-pair utilization rx (upstream) total medium threshold crossed - chpr-t-rxtotutillo : channel-pair utilization rx (upstream) total low threshold crossed - chpr-t-dbacongperiodhi: channel-pair utilization rx (upstream) dbacongperiod high threshold crossed - chpr-t-dbacongperiodmd: channel-pair utilization rx (upstream) dbacongperiod medium threshold crossed - chpr-t-dbacongperiodlo: channel-pair utilization rx (upstream) dbacongperiod low threshold crossed - chpr-t-txucdropfrmhi : channel-pair utilization tx (downstream) unicast drop frame high threshold crossed - chpr-t-txucdropfrmmd : channel-pair utilization tx (downstream) unicast drop frame medium threshold crossed - chpr-t-txucdropfrmlo : channel-pair utilization tx (downstream) unicast drop frame low threshold crossed - chpr-t-txmcdropfrmhi : channel-pair utilization tx (downstream) multicast drop frame high threshold crossed - chpr-t-txmcdropfrmmd : channel-pair utilization tx (downstream) multicast drop frame medium threshold crossed - chpr-t-txmcdropfrmlo : channel-pair utilization tx	

name	Type	Description
	(downstream) multicast drop frame low threshold crossed - chpr-t-txbcdropfrmhi : channel-pair utilization tx (downstream) broadcast drop frame high threshold crossed - chpr-t-txbcdropfrmmd : channel-pair utilization tx (downstream) broadcast drop frame medium threshold crossed - chpr-t-txbcdropfrmlo : channel-pair utilization tx (downstream) broadcast drop frame low threshold crossed - chpr-t-rxtotdropfrmhi : channel-pair utilization rx (upstream) total drop frame high threshold crossed - chpr-t-rxtotdropfrmmd : channel-pair utilization rx (upstream) total drop frame medium threshold crossed - chpr-t-rxtotdropfrmlo : channel-pair utilization rx (upstream) total drop frame low threshold crossed - sfu-gen-omci-fail : SFU ONT - loss of communication - sfu-gen-eqpt-selftest : SFU ONT - ont self-test failure - sfu-gen-ac-pwr-fail : SFU ONT - ac power failure on ont - sfu-gen-bat-missing : SFU ONT - battery missing - sfu-gen-bat-low : SFU ONT - battery low - sfu-gen-bat-fail : SFU ONT - battery failure - sfu-gen-sw-dnload-f : SFU ONT - ont sw download failure - sfu-gen-sw-dnload-p : SFU ONT - ont sw download in progress - sfu-gen-sw-act-fail : SFU ONT - ont sw activation failure - sfu-gen-eqpt-vers-mis : SFU ONT - ont equipment version mismatch - sfu-gen-sw-vers-mis : SFU ONT - ont sw version mismatch - sfu-gen-us-rate-mis : SFU ONT - ont upstream rate mismatch - sfu-gen-tune-fail : SFU ONT - ont has failed to tune to Target-ChnlPair - sfu-gen-nw-time-err : SFU ONT - network timing protocol error - sfu-gen-opt-sig-high : SFU ONT - optical signal level too high - sfu-gen-opt-sig-low : SFU ONT - optical signal level too low - sfu-gen-eqpt-prov-sa : SFU ONT - service affecting mismatch btw equipment and provisioning attributes - sfu-gen-eqpt-prov-nsa : SFU ONT - non service affecting mismatch btw equipment and provisioning attributes - soho-gen-omci-fail : SOHO ONT - loss of communication - soho-gen-eqpt-selftest : SOHO ONT - ont self-test failure - soho-gen-ac-pwr-fail : SOHO ONT - ac power failure on ont - soho-gen-bat-missing : SOHO ONT - battery missing - soho-gen-bat-low : SOHO ONT - battery low - soho-gen-bat-fail : SOHO ONT - battery failure - soho-gen-sw-dnload-f : SOHO ONT - ont sw download failure - soho-gen-sw-dnload-p : SOHO ONT - ont sw download in progress - soho-gen-sw-act-fail : SOHO ONT - ont sw activation failure - soho-gen-eqpt-vers-mis : SOHO ONT - ont equipment version mismatch	

100 Alarm Delta Log Status Commands

name	Type	Description
	- soho-gen-sw-vers-mis : SOHO ONT - ont sw version mismatch - soho-gen-us-rate-mis : SOHO ONT - ont upstream rate mismatch - soho-gen-tune-fail : SOHO ONT - ont has failed to tune to Target-ChnlPair - soho-gen-nw-time-err : SOHO ONT - network timing protocol error - soho-gen-opt-sig-high : SOHO ONT - optical signal level too high - soho-gen-opt-sig-low : SOHO ONT - optical signal level too low - soho-gen-eqpt-prov-sa : SOHO ONT - service affecting mismatch btw equipment and provisioning attributes - soho-gen-eqpt-prov-nsa: SOHO ONT - non service affecting mismatch btw equipment and provisioning attributes - mdu-gen-omci-fail : MDU ONT - loss of communication - mdu-gen-eqpt-selftest : MDU ONT - ont self-test failure - mdu-gen-ac-pwr-fail : MDU ONT - ac power failure on ont - mdu-gen-bat-missing : MDU ONT - battery missing - mdu-gen-bat-low : MDU ONT - battery low - mdu-gen-bat-fail : MDU ONT - battery failure - mdu-gen-phys-intrusion: MDU ONT - physical intrusion - mdu-gen-sw-dnload-f : MDU ONT - ont sw download failure - mdu-gen-sw-dnload-p : MDU ONT - ont sw download in progress - mdu-gen-sw-act-fail : MDU ONT - ont sw activation failure - mdu-gen-eqpt-vers-mis : MDU ONT - ont equipment version mismatch - mdu-gen-sw-vers-mis : MDU ONT - ont sw version mismatch - mdu-gen-us-rate-mis : MDU ONT - ont upstream rate mismatch - mdu-gen-tune-fail : MDU ONT - ont has failed to tune to Target-ChnlPair - mdu-gen-mdu-env1 : MDU ONT - mdu environmental alarm#1 - mdu-gen-mdu-env2 : MDU ONT - mdu environmental alarm#2 - mdu-gen-mdu-env3 : MDU ONT - mdu environmental alarm#3 - mdu-gen-nw-time-err : MDU ONT - network timing protocol error - mdu-gen-opt-sig-high : MDU ONT - optical signal level too high - mdu-gen-opt-sig-low : MDU ONT - optical signal level too low - mdu-gen-eqpt-prov-sa : MDU ONT - service affecting mismatch btw equipment and provisioning attributes - mdu-gen-eqpt-prov-nsa : MDU ONT - non service affecting mismatch btw equipment and provisioning attributes - ont-gen-sw-dnload-file: ont sw download file missing	

name	Type	Description
	- ont-gen-fan-fail : ont fan failure - ont-gen-high-temp : ont high temperature - ont-gen-high-temp-ex : ont excessive high temperature - ont-gen-emergency-call: ont emergency call - ont-gen-sw-version : ont sw version control error - ont-poe-exceed-max : ont poe exceed max - ont-poe-overload-yell : ONU is nearing its maximum ability to supply the power - ont-opti-malfunc : malfunction of ONT's optical transceiver - ont-gen-cfgdld-fail : download of voice xml file to ont failed - ont-gen-rssi-mis : ONU RSSI configuration mismatch - ont-gen-tx-pwr-low : ONU SFP Tx Power is lower than configured Alarm low threshold - ont-gen-temp-high : ONU SFP Temperature is higher than configured Alarm high threshold - ont-gen-volt-high : ONU SFP Voltage is higher than configured Alarm high threshold - ont-gen-bias-high : ONU SFP Bias is higher than configured Alarm high threshold - ont-loopdetect-mis : ont loop detect mismatch - ont-olt-rx-pw-lo : olt side receive power from ont low - ont-olt-rx-pw-hig : olt side receive power from ont high - ont-olt-rx-pw-warnlo : olt side receive power from ont low warning - ont-olt-rx-pw-warnhig : olt side receive power from ont high warning - ont-gen-tod-out-sync : ONU TOD is out-sync with OLT - ont-gen-tune-fail : ONU has failed to tune to Target-ChnlPair - hgu-tr069-param-fail : hgu tr069 parameters mismatch - ont-gen-tod-mismatch : ONU TOD MISMATCH - sfu-sup-sw-file-error : SFU ONT - Software file has error or is missing - sfu-sup-fan-failure : SFU ONT - Fan failure - sfu-sup-temp-high-warn: SFU ONT - High temperature warning - sfu-sup-temp-shutoff : SFU ONT - Service disabled due to excessive temperature - sfu-sup-emergency-call: SFU ONT - Emergency call active - sfu-sup-swverctrl-err : SFU ONT - Software version control error - sfu-sup-poe-exceed-max: SFU ONT - Configured PoE feeding exceeds ONT maximum - sfu-sup-poe-over-yell : SFU ONT - ONU is nearing its maximum ability to supply the power - sfu-opti-malfunc : SFU ONT - Malfunction of ONT's optical transceiver - sfu-sup-cfg-dnld-fail : SFU ONT - Download of voice xml file to ONT failed - sfu-sup-rssi-cfg-mism : SFU ONT - RSSI configuration mismatch - sfu-sup-sfp-tx-low : SFU ONT - SFP Tx Power below configured low-level alarm threshold - sfu-sup-sfp-temp-high : SFU ONT - SFP Temperature above configured high-level alarm threshold	

100 Alarm Delta Log Status Commands

name	Type	Description
	- sfu-sup-sfp-volt-high : SFU ONT - SFP Voltage above configured high-level alarm threshold - sfu-sup-sfp-bias-high : SFU ONT - SFP Bias above configured high-level alarm threshold - sfu-sup-ld-cfg-mism : SFU ONT - Loop detection configuration mismatch - sfu-sup-olt-rx-low : SFU ONT - OLT Rx power below receiver operating range - sfu-sup-olt-rx-high : SFU ONT - OLT Rx power above receiver operating range - sfu-sup-olt-rx-lo-warn: SFU ONT - OLT Rx power below low-level warning threshold - sfu-sup-olt-rx-hi-warn: SFU ONT - OLT Rx power above high-level warning threshold - sfu-sup-tod-out-sync : SFU ONT - ONU TOD is out-sync with OLT - sfu-sup-ont-tune-fail : SFU ONT - ONU has failed to tune to Target-ChnlPair - sfu-tr069-param-fail : SFU ONT - hgu tr069 parameters mismatch - sfu-sup-tod-mismatch : SFU ONT - ONU TOD MISMATCH - soho-sup-sw-file-error: SOHO ONT - Software file has error or is missing - soho-sup-fan-failure : SOHO ONT - Fan failure - soho-sup-temp-high-war: SOHO ONT - High temperature warning - soho-sup-temp-shutoff : SOHO ONT - Service disabled due to excessive temperature - soho-sup-emergency-cal: SOHO ONT - Emergency call active - soho-sup-swverctrl-err: SOHO ONT - Software version control error - soho-sup-poe-exceed-ma: SOHO ONT - Configured PoE feeding exceeds ONT maximum - soho-sup-poe-over-yell: SOHO ONT - ONU is nearing its maximum ability to supply the power - soho-opti-malfunc : SOHO ONT - Malfunction of ONT's optical transceiver - soho-sup-cfg-dnld-fail: SOHO ONT - Download of voice xml file to ONT failed - soho-sup-rssi-cfg-mism: SOHO ONT - RSSI configuration mismatch - soho-sup-sfp-tx-low : SOHO ONT - SFP Tx Power below configured low-level alarm threshold - soho-sup-sfp-temp-high: SOHO ONT - SFP Temperature above configured high-level alarm threshold - soho-sup-sfp-volt-high: SOHO ONT - SFP Voltage above configured high-level alarm threshold - soho-sup-sfp-bias-high: SOHO ONT - SFP Bias above configured high-level alarm threshold - soho-sup-ld-cfg-mism : SOHO ONT - Loop detection configuration mismatch - soho-sup-olt-rx-low : SOHO ONT - OLT Rx power below receiver operating range - soho-sup-olt-rx-high : SOHO ONT - OLT Rx power above receiver operating range	

name	Type	Description
	- soho-sup-olt-rx-lo-war: SOHO ONT - OLT Rx power below low-level warning threshold - soho-sup-olt-rx-hi-war: SOHO ONT - OLT Rx power above high-level warning threshold - soho-sup-tod-out-sync : SOHO ONT - ONU TOD is out-sync with OLT - soho-sup-ont-tune-fail: SOHO ONT - ONU has failed to tune to Target-ChnlPair - soho-tr069-param-fail : SOHO ONT - hgu tr069 parameters mismatch - soho-sup-tod-mismatch : SOHO ONT - ONU TOD MISMATCH - mdu-sup-sw-file-error : MDU ONT - Software file has error or is missing - mdu-sup-fan-failure : MDU ONT - Fan failure - mdu-sup-temp-high-warn: MDU ONT - High temperature warning - mdu-sup-temp-shutoff : MDU ONT - Service disabled due to excessive temperature - mdu-sup-emergency-call: MDU ONT - Emergency call active - mdu-sup-swverctrl-err : MDU ONT - Software version control error - mdu-sup-poe-exceed-max: MDU ONT - Configured PoE feeding exceeds ONT maximum - mdu-sup-poe-over-yell : MDU ONT - ONU is nearing its maximum ability to supply the power - mdu-opti-malfunc : MDU ONT - Malfunction of ONT's optical transceiver - mdu-sup-cfg-dnld-fail : MDU ONT - Download of voice xml file to ONT failed - mdu-sup-rssi-cfg-mism : MDU ONT - RSSI configuration mismatch - mdu-sup-sfp-tx-low : MDU ONT - SFP Tx Power below configured low-level alarm threshold - mdu-sup-sfp-temp-high : MDU ONT - SFP Temperature above configured high-level alarm threshold - mdu-sup-sfp-volt-high : MDU ONT - SFP Voltage above configured high-level alarm threshold - mdu-sup-sfp-bias-high : MDU ONT - SFP Bias above configured high-level alarm threshold - mdu-sup-ld-cfg-mism : MDU ONT - Loop detection configuration mismatch - mdu-sup-olt-rx-low : MDU ONT - OLT Rx power below receiver operating range - mdu-sup-olt-rx-high : MDU ONT - OLT Rx power above receiver operating range - mdu-sup-olt-rx-lo-warn: MDU ONT - OLT Rx power below low-level warning threshold - mdu-sup-olt-rx-hi-warn: MDU ONT - OLT Rx power above high-level warning threshold - mdu-sup-tod-out-sync : MDU ONT - ONU TOD is out-sync with OLT - mdu-sup-ont-tune-fail : MDU ONT - ONU has failed to tune to Target-ChnlPair - mdu-tr069-param-fail : MDU ONT - hgu tr069 parameters mismatch	

100 Alarm Delta Log Status Commands

name	Type	Description
	- mdu-sup-tod-mismatch : MDU ONT - ONU TOD MISMATCH - ont-sbscr-lim-missing : provisioned ont card missing - ont-sbscr-lim-type-mis: wrong type plug-in ont card - ont-sbscr-lim-removal : improper removal ont card - ont-sbscr-lim-fail : ont card failure - ont-sbscr-lim-svc-mis : ont service mismatch for provisioned onu card - ont-sbscr-lim-port-mis: port mismatch btw actual and planned ont card - ont-svc-video-conf-mis: config request failure for video service - ont-svc-video-pw-high : high power level for rf video signal - ont-svc-video-pw-low : low power level for rf video signal - ont-svc-pots-svc-mis : ont service mismatch for provisioned pots - ont-svc-pots-rtcp-lost: pots realtime transport control protocol stream lost - ont-svc-pots-icnf-subs: pots line iconfig subscription failure - ont-svc-pots-icnf-ntfy: pots line iconfig notify failure - ont-svc-pots-icnf-http: pots line iconfig http failure - ont-svc-pots-sip-reg : pots line sip registration failure - ont-svc-pots-sip-inv : pots line sip invite request failure - ont-svc-pots-sip-subsc: pots line sip subscribe failure - ont-svc-pots-sip-mt-tc: pots line sip message timeout threshold crossed - ont-svc-pots-pk-los-tc: pots line rtp bearer packets loss threshold crossed - ont-svc-pots-jitter-tc: pots line rtp jitter threshold crossed - ont-svc-pots-subs-dns : pots line iconfig subscription failed (DNS) - ont-svc-pots-subs-tcp : pots line iconfig subscription failed (TCP) - ont-svc-pots-subs-tls : pots line iconfig subscription failed (TLS) - ont-svc-pots-subs-auth: pots line iconfig subscription failed authentication - ont-svc-pots-subs-to : pots line iconfig subscription failed (timeout) - ont-svc-pots-subs-err : pots line iconfig subscription response error - ont-svc-pots-not-to : pots line iconfig notification failed (timeout) - ont-svc-pots-notref-to: pots line iconfig notification refresh failed - ont-svc-pots-not-mal : pots line iconfig notification failed (malformed) - ont-svc-pots-not-rej : pots line iconfig notification rejected - ont-svc-pots-http-dns : pots line iconfig doc retrieval failed (DNS) - ont-svc-pots-http-tcp : pots line iconfig doc retrieval failed (TCP) - ont-svc-pots-http-tls : pots line iconfig doc retrieval failed (TLS) - ont-svc-pots-http-auth: pots line iconfig doc retrieval failed	

name	Type	Description
	(authentication) - ont-svc-pots-http-to : pots line iconfig doc retrieval failed (timeout) - ont-svc-pots-http-err : pots line iconfig doc retrieval response error - ont-svc-pots-http-mal : pots line iconfig doc retrieval failed (malformed) - ont-svc-pots-insuff : pots line iconfig service failed (insufficient data) - ont-svc-pots-poos : pots ports out of service - ont-svc-lan-mismatch : ont service mismatch for lan - ont-svc-lan-loss-sig : loss of signal on an ethernet port interface - ont-svc-enet-poos : Ethernet Ports out of Service - ont-svc-ces-ds1-mis : ont service mismatch for provisioned ces ds1 - ont-svc-ces-ds1-los : loss of signal at ds1 interface - ont-svc-ces-ds1-lof : loss of frame at ds1 interface - ont-svc-ces-ds1-rair : receiving rai at ds1 interface - ont-svc-ces-ds1-ais : receiving ais at ds1 interface - ont-svc-ces-ds1-lnlpbk: receiving line loopback at ds1 interface - ont-svc-ces-ds1-tmlpbk: receiving terminal loopback at ds1 interface - ont-svc-ces-e1-mis : ont service mismatch for provisioned ces e1 - ont-svc-ces-e1-los : loss of signal at e1 interface - ont-svc-ces-e1-lof : loss of frame at e1 interface - ont-svc-ces-e1-rair : receiving rai at e1 interface - ont-svc-ces-e1-ais : receiving ais at e1 interface - ont-svc-voip-cnf-file : voice configuration file error - ont-svc-voip-svc-mis : service mismatch for provisioned client service - ont-svc-voip-gw-comm : voice gateway communication failure - ont-svc-voip-dhcp-fail: voice dhcp server failure - ont-svc-voip-icnf-subs: voice iconfig subscription failure - ont-svc-voip-icnf-ntfy: voice iconfig notify failure - ont-svc-voip-icnf-http: voice iconfig http failure - ont-svc-voip-dhcp-to : DHCP server retransmissions timed out - ont-svc-voip-dhcp-mal : DHCP response was malformed - ont-svc-voip-dhcp-noad: DHCP server failed to issue the required parameters - ont-svc-voip-dhcp-leas: DHCP Server failure due to problem in lease renewal - ont-svc-voip-subs-dns : iConfig Subscription failure due to DNS problem - ont-svc-voip-subs-tcp : iConfig Subscription failure due to TCP socket problem - ont-svc-voip-subs-tls : iConfig Subscription failure due to TLS session problem - ont-svc-voip-subs-auth: iConfig Subscription failure due to authentication error - ont-svc-voip-subs-to : iConfig Subscription failure due to retransmission timeout - ont-svc-voip-subs-err : iConfig Subscription failure due to	

100 Alarm Delta Log Status Commands

name	Type	Description
	response error - ont-svc-voip-not-to : iConfig Notify response timeout for new subscription - ont-svc-voip-notref-to: iConfig Notify response timeout for subscription refresh - ont-svc-voip-not-mal : iConfig Notify response is malformed - ont-svc-voip-not-rej : iConfig subscription request rejected by configuration server - ont-svc-voip-http-dns : VOIP client can't retrieve config doc due to DNS problem - ont-svc-voip-http-tcp : VOIP client can't retrieve config doc due to TCP socket problem - ont-svc-voip-http-tls : VOIP client can't retrieve config doc due to TLS session problem - ont-svc-voip-http-auth: VOIP client can't retrieve config doc due to auth error - ont-svc-voip-http-to : VOIP client can't retrieve config doc due to re-tx timeout - ont-svc-voip-http-err : VOIP client can't retrieve config doc due to response error - ont-svc-voip-http-mal : iConfig configuration document is malformed - ont-svc-voip-subs-refr: iConfig Subscription refresh error - ont-svc-voip-not-refr : iConfig Notify response for refresh subscribe failed - ont-svc-voip-icfg-err : iConfig Configuration Error - ont-svc-v-ani-conf-mis: config request failure for video ani service - ont-svc-v-ani-loss-sig: video loss of signal on ani - ont-svc-v-ani-lv-high : high video optical signal level - ont-svc-v-ani-lv-low : low video optical signal level - ont-svc-pwe-mismatch : service mismatch for provisioned pseudowire - ont-svc-pwe-reordr-lof: pseudowire reordering and loss of frame - ont-svc-pwe-jitt-buf-o: pseudowire jitter buffer overrun - ont-svc-pwe-jitt-buf-u: pseudowire jitter buffer underrun - ont-svc-pwe-malf-frms : pseudowire malformed frames - ont-svc-pwe-late-frms : pseudowire late frames - ont-svc-pwe-link-loss : pseudowire link loss - ont-svc-pwe-arp-fail : pseudowire arp failure - ont-svc-xdsl-mismatch : service mismatch for provisioned xdsl - ont-svc-xdsl-ne-lof : near end loss of frame - ont-svc-xdsl-ne-los : near end loss of signal - ont-svc-xdsl-ne-line : near end line init - ont-svc-xdsl-ne-lol : near end loss of link - ont-svc-xdsl-fe-lof : far end loss of frame - ont-svc-xdsl-fe-los : far end loss of signal - ont-svc-xdsl-fe-lop : far end loss of power - ont-svc-xdsl-cnf-err : xdsl provisioning error - ont-svc-xdsl-ne-es-tc : near end errored seconds threshold crossed - ont-svc-xdsl-ne-ses-tc: near end severe errored seconds threshold crossed - ont-svc-xdsl-ne-uas-tc: ear end unavailable seconds	

name	Type	Description
	threshold crossed - ont-svc-xdsl-fe-es-tc : far end errored seconds threshold crossed - ont-svc-xdsl-fe-ses-tc: far end severe errored seconds threshold crossed - ont-svc-xdsl-fe-uas-tc: far end unavailable seconds threshold crossed - ont-tc-rx-los-frag-tc : rx loss of gem fragments threshold crossed - ont-tc-tx-los-frag-tc : tx loss of gem fragments threshold crossed - ont-tc-bad-gem-hd-tc : bad gem header threshold crossed - ont-uni-ds-drp-d-fr-tc : downstream l2 dropped frames threshold crossed - ont-uni-up-drp-d-fr-tc : upstream l2 dropped frames threshold crossed - ont-uni-ds-crc-fr-tc : downstream l2 rx crc error frames threshold crossed - ont-uni-up-crc-fr-tc : upstream l2 rx crc error frames threshold crossed - ont-cpu-util-tca : ONT CPU utilization threshold crossed - ont-mem-util-tca : ONT memory utilization threshold crossed - pim-neighbor-down : pim neighbor down - pim-max-mcroutes : maximum routes reached - li-traffic-disabled : lawful interception of traffic disabled - li-bandwidth-limit : lawful intercept reached bandwidth limit - li-out-of-res : lawful intercept out of resources - otdr-cap-mismatch : otdr capability mismatch - login-successful : successful login via management access - login-failure : invalid login via management access has crossed the threshold limit - cfm-defrdiccm : rdi bit in ccm received - cfm-defmacstatus : ccm mac error status - cfm-defremoteccm : missing ccm from mep - cfm-deferrorccm : invalid ccm received - cfm-defxconccm : unexpected ccm received - cfm-defais : ethernet ais received - bfd-session-down : bfd session down - bfd-max-resource : bfd maximum resources reached - bfd-stale-entry : bfd stale entry present - tca-outputbw : tca output bandwidth - tca-inputbw : tca input bandwidth - tca-rxcrcalign : tca rxrc align errors - tca-txcrcalign : tca txrc align errors - tca-txcollisions : tca tx collision errors - tca-outputhighbw : tca output high bandwidth - tca-outputmedbw : tca output medium bandwidth - tca-outputlowbw : tca output low bandwidth - tca-inputhighbw : tca input high bandwidth - tca-inputmediumbw : tca input medium bandwidth - tca-inputlowbw : tca input low bandwidth - eth-cfm-defrdiccm : rdi bit in ccm received - eth-cfm-defmacstatus : ccm mac error status - eth-cfm-defremoteccm : missing ccm from mep - eth-cfm-deferrorccm : invalid ccm received	

100 Alarm Delta Log Status Commands

name	Type	Description
	- eth-cfm-defxconccm : unexpected ccm received - rsvp-neighbor-down : rsvp neighbor down - rsvp-instance-down : rsvp instance down - eth-ring-path-block : eth ring path block - ai-platform-down : Application Intelligence Platform down - ai-appl-install-fail : Application installation failure - ip-assign-fail : Dhcp assigned address failure - ont-tr069-serv-mis : ont tr069 server config mismatch - ont-snmp-mis : ont snmp agent config mismatch - bsf-dhcpv4 : bulksync failed for dhcpv4 - bsf-dhcpv6 : bulksync failed for dhcpv6 - bsf-pon : bulksync failed for pon - bsf-vbridge : bulksync failed for vlan-bridge - bsf-qos : bulksync failed for qos - bsf-igmp : bulksync failed for igmp - bsf-lxfwd : bulksync failed for lxfwd - prot-not-available : no protection not available - prot-switchover-fail : port switch over failed - efm-oam-cpelinkfault : EFM-OAM CPE link fault - efm-oam-cpedyinggasp : EFM-OAM CPE dying gasp - efm-oam-cpecrevt : EFM-OAM CPE critical event - ont-loopdetect : ont loop detect - alm-tbl-overflow : alarm table has overflowed - auto-switch-status : auto-switch status - auswqueuefullatm : auto-switch queue Full for ATM - auswbkpfailatm : auto-switch config data backup failed for ATM - auswrecfgfailatm : auto-switch fallback reconfiguration failed for ATM - auswdataunatm : auto-switch backup config data unavailable for ATM - auswqueuefulptm : auto-switch queue Full for PTM - auswbkpfailptm : auto-switch config data backup failed for PTM - auswrecfgfailptm : auto-switch fallback reconfiguration failed for PTM - auswdataunptm : auto-switch backup config data unavailable for PTM - auswbakpfailatm : auto-switch backup fail for ATM - chpr-com-fail : channel pair communication failure on olt - chpr-tx-fail : transmitter failure on channel pair - chpr-unprov-ont : unprovisioned ont on channel pair - chpr-prov-mismatch : mismatch btw equipment and provisioning pon attributes - chpr-loss-sig : channel pair loss of signal - chpr-diagnostic : channel pair diagnostic test active - chpr-loid-conflict : loid conflict ont on channel pair - chpr-loid-pwd-err : loid password error ont on channel pair - chpr-stk-laser-dis : stuck laser disabled on channel pair - chpr-sfp-mismatch : channel pair sfp mismatch - chpr-rng-mismatch : channel pair ranging mismatch - chpr-alien-test : channel pair alien diagnostic test active - chpr-alien-detect : channel pair alien detect active - chpr-deact-hightca : channel pair deactivated ont hightca threshold crossed - chpr-deact-lowtca : channel pair deactivated ont lowtca threshold crossed	

name	Type	Description
	- chpr-dp-integ : channel pair data path integrity failure - olt-chpr-tc-err-frag : channelpair errored fragments threshold crossed - olt-chpr-up-bw-tca : OLT CHANNELPAIR upstream bandwidth TCA - olt-chpr-down-bw-tca : OLT CHANNELPAIR downstream bandwidth TCA - cfg-dld-fail : download of configure file to ont failed - cfg-act-fail : activate the passive config file failed - cfg-dld-ip : ont configure file download in progress - cfg-ver-mismatch : the planned configure file does not match the active configure file - cfg-file-missing : ont configure file missing or has an error - cfg-verctrl-err : ont configure file version control error - cfg-not-supported : ont not support the configure file download function - ont-prot-not-available: ONT/ONU protection not available - ont-gen-temp-low : ONU SFP temperature is lower than configured Alarm low threshold - ont-gen-volt-low : ONU SFP Voltage is lower than configured Alarm low threshold - ont-gen-tx-pwr-high : ONU SFP Tx power is higher than configured Alarm high threshold - ont-gen-bias-low : ONU SFP bias is lower than configured Alarm low threshold - ont-gen-rx-hwarn : ONU SFP Rx power is higher than warn threshold - ont-gen-rx-lwarn : ONU SFP Rx power is lower than warn threshold - ont-gen-tx-hwarn : ONU SFP Tx power is higher than warn threshold - ont-gen-tx-lwarn : ONU SFP Tx power is lower than warn threshold - ont-gen-temp-hwarn : ONU SFP temperature is higher than warn threshold - ont-gen-temp-lwarn : ONU SFP temperature is lower than warn threshold - ont-gen-volt-hwarn : ONU SFP Voltage is higher than warn threshold - ont-gen-volt-lwarn : ONU SFP Voltage is lower than warn threshold - ont-gen-bias-hwarn : ONU SFP bias is higher than warn threshold - ont-gen-bias-lwarn : ONU SFP bias is lower than warn threshold - sfu-sup2-temp-low : SFU ONT - SFP temperature is lower than configured Alarm low threshold - sfu-sup2-volt-low : SFU ONT - SFP Voltage is lower than configured Alarm low threshold - sfu-sup2-tx-high : SFU ONT - SFP tx power is higher than configured Alarm high threshold - sfu-sup2-bias-low : SFU ONT - SFP bias is lower than configured Alarm low threshold - sfu-sup2-rx-hwarn : SFU ONT - SFP rx power is higher than configured warn threshold - sfu-sup2-rx-lwarn : SFU ONT - SFP rx power is lower than configured warn threshold	

100 Alarm Delta Log Status Commands

name	Type	Description
	- sfu-sup2-tx-hwarn : SFU ONT - SFP tx power is higher than configured warn threshold - sfu-sup2-tx-lwarn : SFU ONT - SFP tx power is lower than configured warn threshold - sfu-sup2-temp-hwarn : SFU ONT - SFP temperature is higher than configured warn threshold - sfu-sup2-temp-lwarn : SFU ONT - SFP temperature is lower than configured warn threshold - sfu-sup2-volt-hwarn : SFU ONT - SFP Voltage is higher than configured warn threshold - sfu-sup2-volt-lwarn : SFU ONT - SFP Voltage is lower than configured warn threshold - sfu-sup2-bias-hwarn : SFU ONT - SFP bias is higher than configured warn threshold - sfu-sup2-bias-lwarn : SFU ONT - SFP bias is lower than configured warn threshold - soho-sup2-temp-low : SOHO ONT - SFP temperature is lower than configured Alarm low threshold - soho-sup2-volt-low : SOHO ONT - SFP Voltage is lower than configured Alarm low threshold - soho-sup2-tx-high : SOHO ONT - SFP tx power is higher than configured Alarm low threshold - soho-sup2-bias-low : SOHO ONT - SFP bias is lower than configured Alarm low threshold - soho-sup2-rx-hwarn : SOHO ONT - SFP rx power is higher than warn threshold - soho-sup2-rx-lwarn : SOHO ONT - SFP rx power is lower than warn threshold - soho-sup2-tx-hwarn : SOHO ONT - SFP tx power is higher than warn threshold - soho-sup2-tx-lwarn : SOHO ONT - SFP tx power is lower than warn threshold - soho-sup2-temp-hwarn : SOHO ONT - SFP temperature is higher than warn threshold - soho-sup2-temp-lwarn : SOHO ONT - SFP temperature is lower than warn threshold - soho-sup2-volt-hwarn : SOHO ONT - SFP Voltage is higher than warn threshold - soho-sup2-volt-lwarn : SOHO ONT - SFP Voltage is lower than warn threshold - soho-sup2-bias-hwarn : SOHO ONT - SFP bias is higher than warn threshold - soho-sup2-bias-lwarn : SOHO ONT - SFP bias is lower than warn threshold - mdu-sup2-temp-low : MDU ONT - SFP temperature is lower than configured alarm low threshold - mdu-sup2-volt-low : MDU ONT - SFP Voltage is lower than configured alarm low threshold - mdu-sup2-tx-high : MDU ONT - SFP tx power is higher than configured alarm low threshold - mdu-sup2-bias-low : MDU ONT - SFP bias is lower than configured alarm low threshold - mdu-sup2-rx-hwarn : MDU ONT - SFP rx power is higher than warn threshold - mdu-sup2-rx-lwarn : MDU ONT - SFP rx power is lower than warn threshold - mdu-sup2-tx-hwarn : MDU ONT - SFP tx power is higher	

name	Type	Description
	than warn threshold - mdu-sup2-tx-lwarn : MDU ONT - SFP tx power is lower than warn threshold - mdu-sup2-temp-hwarn : MDU ONT - SFP temperature is higher than warn threshold - mdu-sup2-temp-lwarn : MDU ONT - SFP temperature is lower than warn threshold - mdu-sup2-volt-hwarn : MDU ONT - SFP voltage is higher than warn threshold - mdu-sup2-volt-lwarn : MDU ONT - SFP voltage is lower than warn threshold - mdu-sup2-bias-hwarn : MDU ONT - SFP bias is higher than warn threshold - mdu-sup2-bias-lwarn : MDU ONT - SFP bias is lower than warn threshold - cust-alm1 : customizable alarm 1 - cust-alm2 : customizable alarm 2 - cust-alm3 : customizable alarm 3 - cust-alm4 : customizable alarm 4 - cust-alm5 : customizable alarm 5 - cust-alm6 : customizable alarm 6 - cust-alm7 : customizable alarm 7 - cust-alm8 : customizable alarm 8 - cust-alm9 : customizable alarm 9 - cust-alm10 : customizable alarm 10 - cust-alm11 : customizable alarm 11 - cust-alm12 : customizable alarm 12 - cust-alm13 : customizable alarm 13 - cust-alm14 : customizable alarm 14 - cust-alm15 : customizable alarm 15 - cust-alm16 : customizable alarm 16 - cust-alm17 : customizable alarm 17 - cust-alm18 : customizable alarm 18 - cust-alm19 : customizable alarm 19 - cust-alm20 : customizable alarm 20 - cust-alm21 : customizable alarm 21 - cust-alm22 : customizable alarm 22 - cust-alm23 : customizable alarm 23 - cust-alm24 : customizable alarm 24 - cust-alm25 : customizable alarm 25 - cust-alm26 : customizable alarm 26 - cust-alm27 : customizable alarm 27 - cust-alm28 : customizable alarm 28 - cust-alm29 : customizable alarm 29 - cust-alm30 : customizable alarm 30 - cust-alm31 : customizable alarm 31 - ethernet-ring-pthfwst : ethernet ring path forward state - ethernet-ring-fop-to : ethernet ring fop-to failure of protocol timeout - ethernet-ring-fop-pm : ethernet ring fop-pm failure of protocol provision mismatch - fpm-depletion : failsafe fpm depletion - exp-seizureack : Channel was blocked due to failure in the reception of the SEIZURE ACK signal - exp-disconack : Channel was blocked due to failure in the reception of the DISCONNECTION ACK signal - exp-forcerelack : Channel was blocked due to failure in the	

100 Alarm Delta Log Status Commands

name	Type	Description
	reception of the BACKWARD DISCONNECTION ACK signal - packet-loss : Pseudo Wire entered the Packet loss state - remote-packet-loss : Remote Packet loss detected - no-dsp-resource : DSP resource allocation failed - la-down : Link aggregation group link-status is down - la-standby-na : Cross-lt lag on standby slot part is not available - la-switch-fail : Cross-lt lag fail to do switchover - la-degrade : Link aggregation group degrade - melt-board-reset : MELT board reset - board-shelf-mismatch : board type and shelf type mismatch - fcs-thresh-exceed : FCS counter threshold exceeded	
state	Parameter type: <Alarm::AlarmState> (active non-active) Possible values: - active : alarm is active - non-active : alarm is not active	reflect's the state of the alarm as either active or non-active. <i>This element is always shown.</i>
last-updated-on	Parameter type: <Sys::timeInSecs> - the time (yyyy-mm-dd:hour:minutes:secs) - unit: UTC	network time in seconds when the alarm was logged. <i>This element is always shown.</i>
additional-info	Parameter type: <Alarm::AdditionalInfo> - string to identify the owner (example: Tom) - length: x<=512	AdditionalInfo <i>This element is always shown.</i>

Only Show Details: major alarm table related generic information		
name	Type	Description
changes	Parameter type: <Counter> - 32 bit counter	total number of changes of all reported alarms with a severity level major since startup. <i>This element is only shown in detail mode.</i>
last-entry-id	Parameter type: <SignedInteger> - a signed integer	last entry that was added to the major delta log. <i>This element is only shown in detail mode.</i>
last-reset	Parameter type: <Sys::Time> - the time (yyyy-mm-dd:hour:minutes:secs) - unit: UTC	network time in seconds indicating when the major delta log was last reset. <i>This element is only shown in detail mode.</i>
log-overflowed	Parameter type: <Alarm::OverflowStatus> (yes no) Possible values: - yes : buffer has overflowed - no : no buffer overflow	specifies whether the major delta log is overflowed or not. <i>This element is only shown in detail mode.</i>

100.7 Critical Alarm Delta Log Status Command

Command Description

This command displays alarm values for all reported alarms with a severity level critical.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

> show alarm delta-log critical [(index)]

Command Parameters

Table 100.7-1 "Critical Alarm Delta Log Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	delta log alarm table index

Command Output

Table 100.7-2 "Critical Alarm Delta Log Status Command" Display parameters

Specific Information		
name	Type	Description
type	Parameter type: <Alarm::alarmIndexExt> (all xtca-ne-es xtca-ne-ses xtca-ne-uas xtca-ne-day-es xtca-ne-day-ses xtca-ne-day-uas xtca-fe-es xtca-fe-ses xtca-fe-uas xtca-fe-day-es xtca-fe-day-ses xtca-fe-day-uas xtca-leftrs xtca-day-leftrs xtca-fe-leftrs xtca-fe-day-leftrs xtca-auto-port-reset xtca-reinit	unique id for an alarm. <i>This element is always shown.</i>

100 Alarm Delta Log Status Commands

name	Type	Description
	xtca-day-reinit xdsl-ne-los xdsl-ne-lof xdsl-ne-lom xdsl-ne-ese xdsl-act-cfg-error xdsl-act-not-feas xdsl-up-br-reach xdsl-ne-ncd xdsl-ne-lcd xdsl-fe-los xdsl-fe-lof xdsl-fe-lpr xdsl-fe-lol xdsl-fe-lom xdsl-fe-ese xdsl-fe-upbo-vio xdsl-fe-cpe-pol xdsl-tpstc-mis xdsl-act-comm xdsl-act-modem xdsl-do-br-reach xdsl-fe-ncd xdsl-fe-lcd xdsl-frtx-init-fail xdsl-vect-dle xdsl-fe-mis-peer-35b vectline-xtc-var-vict vectline-xtc-var-dist vectline-corp-errf vect-cpe-cap-mismatch vectline-conf_notfeas vect-vp-lt-mismatch vect-inv-qsf vect-vp-lt-fail vect-no-gain-at-init sw-rollback db-rollback xvps-inv-dbase inv-cde-file miss-cde-file cde-hash-error auto-fetch-failure low-disk-space cell-discard-up cell-discard-down persist-data-loss mac-conflict vmac-full sntp-comm-lost preferred-mode timing-reference nt-disk-95%full shub-loc cf-error back-pnl-inv ihub-conf-loss	

name	Type	Description
	rack-power rack-fan-unit1 rack-fan-unit2 shelf-mismatch shelf-missing shelf-install-missing door ac-power-fail board-mismatch waiting-for-sw temp-exceeded backplane-data-failure temp-shutdown board-missing board-instl-missing board-init board-reset-prot sem-power-fail sem-ups-fail board-reset-cf vlan-assign-fail vsa-info-invalid auth-mac-conflict user-pwd-fault up-plan-bitrate up-min-bitrate up-config-not-feas down-plan-bitrate down-min-bitrate down-config-not-feas non-bonding-cpe multiple-cpes register group-incomplete host-sfp-los host-sfp-tx-fail host-sfp-not-prst host-sfp-inv-id host-sfp-ctrl-fail host-sfp-rmtlt host-sfp-mismatch host-sfp-incompt exp-sfp-los exp-sfp-tx-fail exp-sfp-not-prst exp-sfp-inv-id exp-sfp-ctrl-fail exp-sfp-1-los exp-sfp-2-los ext-qsfv-invld tx-power-high-alarm tx-power-low-alarm rx-power-high-alarm rx-power-low-alarm tx-biascur-high-alarm tx-biascur-low-alarm volt-high-alarm	

100 Alarm Delta Log Status Commands

name	Type	Description
	volt-low-alarm	
	temp-high-alarm	
	temp-low-alarm	
	tx-power-high-warn	
	tx-power-low-warn	
	rx-power-high-warn	
	rx-power-low-warn	
	tx-biascur-high-warn	
	tx-biascur-low-warn	
	volt-high-warn	
	volt-low-warn	
	temp-high-warn	
	temp-low-warn	
	onu-unprovisioned	
	signal-loss	
	bitrate-high	
	opmodule-mismatch	
	key-fail-one-churn	
	key-fail-three-churn	
	oam-discov-fail	
	report-timeout	
	total-packets-exceed	
	arp-packets-exceed	
	dhcp-packets-exceed	
	igmp-packets-exceed	
	pppoe-packets-exceed	
	nd-packets-exceed	
	icmpv6-packets-exceed	
	mld-packets-exceed	
	dhcpv6-packets-exceed	
	cfm-packets-exceed	
	dsx1-serdes-fail	
	dsx1-tributary1-fail	
	dsx1-tributary2-fail	
	dsx1-los-fail	
	dsx1-ais-sync	
	dsx1-lof-sync	
	dsx1-los-sync	
	dsx1-deg-fail	
	dsx1-rei-from-liu	
	dsx1-rdi-from-liu	
	dsx1-crc6-from-liu	
	dsx1-crc4-from-liu	
	dsx1-crc4-th-from-liu	
	dsx1-ais-from-liu	
	dsx1-los-from-liu	
	dsx1-lof-from-liu	
	dsx1-lomf-from-liu	
	dsx1-rei-from-iwf	
	dsx1-rdi-from-iwf	
	dsx1-crc6-from-iwf	
	dsx1-crc4-from-iwf	
	dsx1-crc4-th-from-iwf	
	dsx1-ais-from-iwf	
	dsx1-los-from-iwf	
	dsx1-lof-from-iwf	
	dsx1-lomf-from-iwf	

name	Type	Description
	pppce-trans-15min-tca pppce-sess-15min-tca pppce-trans-1day-tca pppce-sess-1day-tca custom1 custom2 custom3 custom4 custom5 he-custom1 he-custom2 he-custom3 he-custom4 he-custom5 he-custom6 custom6 custom7 custom8 custom9 custom10 custom11 custom12 custom13 custom14 custom15 custom16 custom17 loss-swo-cap ping-check-fail der-temp1 der-temp2 der-temp3 der-temp4 der-temp5 der-temp6 der-temp7 der-temp8 der-temp9 der-temp10 der-temp11 der-temp12 der-temp13 der-temp14 der-temp15 der-temp16 der-temp17 der-temp18 der-temp19 der-temp20 der-temp21 der-temp22 der-temp23 der-temp24 der-temp25 der-temp26 der-temp27 der-temp28	

100 Alarm Delta Log Status Commands

name	Type	Description
	der-temp29	
	der-temp30	
	der-temp31	
	der-spa1	
	der-spa2	
	der-spa3	
	der-spa4	
	der-spa5	
	der-spa6	
	der-spa7	
	der-spa8	
	der-spa9	
	der-spa10	
	der-spa11	
	der-spa12	
	der-spa13	
	der-spa14	
	der-spa15	
	der-spa16	
	der-spa17	
	der-spa18	
	der-spa19	
	der-spa20	
	der-spa21	
	der-spa22	
	der-spa23	
	der-spa24	
	der-spa25	
	der-spa26	
	der-spa27	
	der-spa28	
	der-spa29	
	der-spa30	
	der-spa31	
	apsf-alarm	
	custextalarm1	
	custextalarm2	
	custextalarm3	
	custextalarm4	
	custextalarm5	
	pluginfan	
	plugin-dc-a	
	plugin-dc-b	
	plugin-dg	
	ntr-a-loss	
	ntr-b-loss	
	xvps-conf-loss	
	mac-entry-nofree	
	fibre-conn-mismatch	
	link-cap-mismatch	
	eqpt-cap-mismatch	
	ctrl-dnld-failure	
	melt-hw-issue	
	melt-board-reset	
	board-shelf-mismatch	
	mgnt-type-mismatch	
	fileserv-unavail	

name	Type	Description
	shdsl-n-loopback	
	shdsl-c-loopback	
	shdsl-conferr	
	shdsl-atm-lcd	
	shdsl-lpr	
	shdsl-secu-err	
	shdsl-dev-fault	
	shdsl-atm-ncd	
	shdsl-n-losw	
	shdsl-c-losw	
	shdsl-n-aten	
	shdsl-c-aten	
	shdsl-n-snr	
	shdsl-c-snr	
	shdsl-n-dccont	
	shdsl-c-dccont	
	shdsl-c-actfail	
	e1-fe-rai	
	e1-ne-rai	
	e1-fe-ais	
	e1-ne-ais	
	e1-lof	
	e1-los	
	e1-loopback	
	ima-grp-fe-su	
	ima-grp-fe-cfg	
	ima-grp-ne-cfg	
	ima-grp-fe-nl	
	ima-grp-ne-nl	
	ima-grp-fe-blk	
	ima-lnk-lif	
	ima-lnk-lods	
	ima-lnk-misc	
	ima-lnk-rfi	
	ima-lnk-fault	
	ima-lnk-txblk	
	ima-lnk-rxblk	
	bad-digitmap	
	dhcp-unreach	
	dhcp-no-srv	
	dhcp-inv-srv	
	norpniewithsoftdsp	
	unknown-sub	
	ground-key	
	port-hightemp	
	port-jbfltca	
	reg-domainname	
	reg-auth	
	reg-timeout	
	reg-srvfailresp	
	inv-domainname	
	inv-auth	
	inv-timeout	
	inv-srvfailresp	
	subs-srvfailresp	
	subs-domainname	
	subs-auth	

100 Alarm Delta Log Status Commands

name	Type	Description
	subs-refreshfail subs-inittimeout emergency-call e1sip-reg-domainname e1sip-reg-auth e1sip-reg-timeout e1sip-reg-srvfailresp e1sip-inv-domainname e1sip-inv-auth e1sip-inv-timeout e1sip-inv-srvfailresp e1sip-emergency-call e1l1tf-ais-signal e1l1tf-los-signal e1l1tf-rai-signal e1sip-misconfig-mgc10 e1sip-nsmprf-missed e1t1l1tf-recv-ais e1t1l1tf-recv-los e1t1l1tf-recv-rai transport-mismatch dns-lookup-failure none-dns-srv no-dns-srv none-srv no-srv reg-srv-unreach proxy-srv-unreach dhcp-srv-unreach fo-trigger fb-trigger du-trigger ssp-missing dns-pool-exceed lsa-fo-trigger reg-domainname-sec reg-auth-sec reg-timeout-sec reg-srvfailresp-sec inv-domainname-sec inv-auth-sec inv-timeout-sec inv-srvfailresp-sec subs-srvfailresp-sec subs-domainname-sec subs-auth-sec subs-refreshfail-sec subs-inittimeout-sec emergency-call-sec fanout up-overflow upobc-overflow dwobc-overflow dw-overflow lwpri-overflow queue-drop queue-load	

name	Type	Description
	queue-peak-usage mgc-unreachable failover-to-esamgc sgc-unreachable lcard-unreach-srvcard lcard-type-mismatch meg-unknown-sub meg-ground-key meg-high-temp meg-act-fail meg-over-current line-showering low-qos-packetloss low-qos-jitter low-qos-delay sig-brd-persist-loss sig-brd-disk-full sig-brd-db-rollback mg-overload meg-unknown-sub-sec line-showering-sec loss-env-mon etca-los etca-fcs etca-day-los etca-day-fcs etca-rx-octets etca-tx-octets etca-day-rx-octets etca-day-tx-octets user-sfp-los user-sfp-tx-fail user-sfp-not-prst user-sfp-inv-id user-sfp-t-exceed user-sfp-mismatch uplink-sfp-los uplink-sfp-tx-fail uplink-sfp-not-prst uplink-sfp-inv-id uplink-sfp-t-exceed uplink-sfp-mismatch loss-lmswp-cap inv-xvps-pair-data network-power-loss hw-fault bat-miss bat-fail bat-low bat-a-fail bat-b-fail ac-vol-out-range network-power-loss-b sem-ac-power-fail sem-ups-low-volt dc-a-fail dc-b-fail	

100 Alarm Delta Log Status Commands

name	Type	Description
	plan-power-mismatch water-seepage-in-box sealed-box-open dc-a-vol-out-range dc-b-vol-out-range inlet-temp-major inlet-temp-critical psu-fail-crit psu-a-fail-presence psu-a-fail-vin-ac-nok psu-a-fail-vin-uv psu-a-fail-vin-ov psu-a-fail-vout-uv psu-a-fail-vout-ov psu-a-fail-iout-oc psu-a-fail-overtemp psu-b-fail-presence psu-b-fail-vin-ac-nok psu-b-fail-vin-uv psu-b-fail-vin-ov psu-b-fail-vout-uv psu-b-fail-vout-ov psu-b-fail-iout-oc psu-b-fail-overtemp synce-fail bits-fail bits-output-shutoff ieee1588-fail gnss-fail ieee1588-hybrid-fail signal-loss signal-efd esmc-loss bits-output-exceed ql-input-exceed holdover lti tod-reference-fail internal-clk-fail bgp-peer-down bgp-routes-mid-limit isis-adjacency-down isis-adjacency-reject isis-instance-down ospf-lsa-limit ospf-lsa-mid-limit ospf-neighbor-down ospf-instance-down ospf3-lsa-limit ospf3-lsa-mid-limit ospf3-neighbor-down ospf3-instance-down rip-instance-down lag-down lagsubgrp-thresh-reach lagsubgrp-switch-fail no-unpinned-free-ports	

name	Type	Description
	general-arp-limit gen-switch-out-of-res ipv6-nc-limit dhcp-session-oor ihub-fdb-limit ihub-mac-limit l2fw-stp-exception l2fw-stp-root-guard vprn-routes-limit vprn-ipv6-routes-limit dhcpv6-lease-limit dhcpv4-lease-limit vpls-mfib-limit ihub-ipv6-dad-own ihub-ipv6-dad ihub-ipv6-dup-pd-route vpls-duplicate-mac vpls-fdb-limit vpls-self-duplic-mac vpls-sdp-self-dup-mac link-down link-lagport-add-fail link-conf-mismatch ihub-peer-comm ihub-sw-fail ihub-hw-fail ihub-link-fail ihub-proc-overload ihub-out-of-mem ntp-comm-lost ldp-instance-down ldp-session-down mpls-instance-down mpls-lsp-down mpls-lsp-path-down sdp-instance-down sdp-binding-down epipe-instance-down lldpmed-portcfg-mis lldpmed-mediapl-mis vlanport-svc-mismatch mcsrc-stream-lost eqptsupl-syslog-upload eqptsupl-ontsw-dnload cf-75%used cf-90%used olt-gen-pon-com-fail olt-gen-tx-fail olt-gen-unprov-ont olt-gen-pon-eqpt-prov olt-gen-pon-loss-sig olt-gen-pon-diagnostic olt-gen-lold-conflict olt-gen-lold-pwderr olt-gen-pon-alien-test olt-gen-alien-detect olt-gen-rng-mism	

100 Alarm Delta Log Status Commands

name	Type	Description
	olt-gen-sfp-mism	
	olt-gen-deact-hightca	
	olt-gen-deact-lowtca	
	olt-gen-dp-integ	
	olt-gen-ddr-fault	
	olt-pon-tc-err-frag-tc	
	olt-ont-tc-err-frag-tc	
	ont-ploam-loss-sig	
	ont-ploam-loss-ack	
	ont-ploam-loss-cd	
	ont-ploam-phy-eqpt-err	
	ont-ploam-startup-fail	
	ont-ploam-sig-degrade	
	ont-ploam-disabled	
	ont-ploam-err-msg	
	ont-ploam-inactive	
	ont-ploam-sig-fail	
	ont-ploam-dying-gasp	
	ont-ploam-deact-fail	
	ont-ploam-oam	
	ont-ploam-win-drift	
	ont-ploam-rdi	
	ont-ploam-loss-ks	
	ont-ploam-pwr-burst	
	ont-ploam-roq-disa	
	ont-ploam-diff-reach	
	ont-ploam-looc	
	sfu-ploam-loss-sig	
	sfu-ploam-loss-ack	
	sfu-ploam-loss-cd	
	sfu-ploam-phy-eqpt-err	
	sfu-ploam-startup-fail	
	sfu-ploam-sig-degrade	
	sfu-ploam-disabled	
	sfu-ploam-err-msg	
	sfu-ploam-inactive	
	sfu-ploam-sig-fail	
	sfu-ploam-dying-gasp	
	sfu-ploam-deact-fail	
	sfu-ploam-oam	
	sfu-ploam-win-drift	
	sfu-ploam-rdi	
	sfu-ploam-loss-ks	
	sfu-ploam-pwr-burst	
	sfu-ploam-roq-disa	
	sfu-ploam-diff-reach	
	sfu-ploam-looc	
	soho-ploam-loss-sig	
	soho-ploam-loss-ack	
	soho-ploam-loss-cd	
	soho-ploam-phy-eqpt-er	
	soho-ploam-startup-fai	
	soho-ploam-sig-degrade	
	soho-ploam-disabled	
	soho-ploam-err-msg	
	soho-ploam-inactive	
	soho-ploam-sig-fail	

name	Type	Description
	soho-ploam-dying-gasp	
	soho-ploam-deact-fail	
	soho-ploam-oam	
	soho-ploam-win-drift	
	soho-ploam-rdi	
	soho-ploam-loss-ks	
	soho-ploam-pwr-burst	
	soho-ploam-roq-disa	
	soho-ploam-diff-reach	
	soho-ploam-looc	
	mdu-ploam-loss-sig	
	mdu-ploam-loss-ack	
	mdu-ploam-loss-cd	
	mdu-ploam-phy-eqpt-err	
	mdu-ploam-startup-fail	
	mdu-ploam-sig-degrade	
	mdu-ploam-disabled	
	mdu-ploam-err-msg	
	mdu-ploam-inactive	
	mdu-ploam-sig-fail	
	mdu-ploam-dying-gasp	
	mdu-ploam-deact-fail	
	mdu-ploam-oam	
	mdu-ploam-win-drift	
	mdu-ploam-rdi	
	mdu-ploam-loss-ks	
	mdu-ploam-pwr-burst	
	mdu-ploam-roq-disa	
	mdu-ploam-diff-reach	
	mdu-ploam-looc	
	ont-hpna-ser-mis	
	ont-hpna-los-sig	
	ont-moca-svc-mis	
	ont-moca-link-los	
	ont-moca-min-bw	
	ont-moca-tca-rx-err-fr	
	ont-sipa-reg-nm-fail	
	ont-sipa-reg-rec-fail	
	ont-sipa-reg-con-fail	
	ont-sipa-reg-val-fail	
	ont-sipa-reg-mis	
	ont-vcd-cfg-nm-fail	
	ont-vcd-cfg-rech-fail	
	ont-vcd-cfg-conn-fail	
	ont-vcd-cfg-vali-fail	
	ont-vcd-cfg-auth-fail	
	ont-vcd-cfg-resp-tmout	
	ont-vcd-cfg-resp-err	
	ont-vcd-cfg-file-err	
	ont-vcd-sub-nm-fail	
	ont-vcd-sub-rech-fail	
	ont-vcd-sub-conn-fail	
	ont-vcd-sub-vali-fail	
	ont-vcd-sub-auth-fail	
	ont-vcd-sub-resp-tmout	
	ont-vcd-sub-resp-err	
	ont-vcd-reb-requ	

100 Alarm Delta Log Status Commands

name	Type	Description
	ont-vcd-mis	
	ont-mgc-mis	
	ont-mgc-timeout	
	ont-sip-reg-dns	
	ont-sip-reg-fail	
	ont-sip-reg-timeout	
	ont-sip-reg-err-resps	
	ont-sip-inv-dns	
	ont-sip-inv-auth	
	ont-sip-inv-timeout	
	ont-sip-inv-err	
	ont-svc-pots-subs-refr	
	ont-svc-pots-not-refr	
	ont-svc-pots-icfg-err	
	ont-veip-mismatch	
	ont-ip-host-mismatch	
	ont-ip-host-file	
	ont-ip-host-ip-alloc	
	olt-pon-up-bw-tca	
	olt-pon-down-bw-tca	
	ont-gen-omci-fail	
	ont-gen-eqpt-selftest	
	ont-gen-ac-pwr-fail	
	ont-gen-bat-missing	
	ont-gen-bat-low	
	ont-gen-bat-fail	
	ont-gen-phys-intrusion	
	ont-gen-sw-dnload-f	
	ont-gen-sw-dnload-p	
	ont-gen-sw-act-fail	
	ont-gen-eqpt-vers-mis	
	ont-gen-sw-vers-mis	
	ont-gen-us-rate-mis	
	ont-gen-mdu-env1	
	ont-gen-mdu-env2	
	ont-gen-mdu-env3	
	ont-gen-nw-time-err	
	ont-gen-opt-sig-high	
	ont-gen-opt-sig-low	
	ont-gen-eqpt-prov-sa	
	ont-gen-eqpt-prov-nsa	
	pon-t-txmcutilhi	
	pon-t-txmcutilmd	
	pon-t-txmcutillo	
	pon-t-txtotutilhi	
	pon-t-txtotutilmd	
	pon-t-txtotutillo	
	pon-t-rxtotutilhi	
	pon-t-rxtotutilmd	
	pon-t-rxtotutillo	
	pon-t-dbacongperiodhi	
	pon-t-dbacongperiodmd	
	pon-t-dbacongperiodlo	
	pon-t-txucdropfrmhi	
	pon-t-txucdropfrmd	
	pon-t-txucdropfrmlo	
	pon-t-txmcdropfrmhi	

name	Type	Description
	pon-t-txmcdropfrmmd	
	pon-t-txmcdropfrmlo	
	pon-t-txbcdropfrmhi	
	pon-t-txbcdropfrmmd	
	pon-t-txbcdropfrmlo	
	pon-t-rxtotdropfrmhi	
	pon-t-rxtotdropfrmmd	
	pon-t-rxtotdropfrmlo	
	chpr-t-txmcutilhi	
	chpr-t-txmcutilmd	
	chpr-t-txmcutillo	
	chpr-t-txtotutilhi	
	chpr-t-txtotutilmd	
	chpr-t-txtotutillo	
	chpr-t-rxtotutilhi	
	chpr-t-rxtotutilmd	
	chpr-t-rxtotutillo	
	chpr-t-dbacongperiodhi	
	chpr-t-dbacongperiodmd	
	chpr-t-dbacongperiodlo	
	chpr-t-txucdropfrmhi	
	chpr-t-txucdropfrmmd	
	chpr-t-txucdropfrmlo	
	chpr-t-txmcdropfrmhi	
	chpr-t-txmcdropfrmmd	
	chpr-t-txmcdropfrmlo	
	chpr-t-txbcdropfrmhi	
	chpr-t-txbcdropfrmmd	
	chpr-t-txbcdropfrmlo	
	chpr-t-rxtotdropfrmhi	
	chpr-t-rxtotdropfrmmd	
	chpr-t-rxtotdropfrmlo	
	sfu-gen-omci-fail	
	sfu-gen-eqpt-selftest	
	sfu-gen-ac-pwr-fail	
	sfu-gen-bat-missing	
	sfu-gen-bat-low	
	sfu-gen-bat-fail	
	sfu-gen-sw-dnload-f	
	sfu-gen-sw-dnload-p	
	sfu-gen-sw-act-fail	
	sfu-gen-eqpt-vers-mis	
	sfu-gen-sw-vers-mis	
	sfu-gen-us-rate-mis	
	sfu-gen-tune-fail	
	sfu-gen-nw-time-err	
	sfu-gen-opt-sig-high	
	sfu-gen-opt-sig-low	
	sfu-gen-eqpt-prov-sa	
	sfu-gen-eqpt-prov-nsa	
	soho-gen-omci-fail	
	soho-gen-eqpt-selftest	
	soho-gen-ac-pwr-fail	
	soho-gen-bat-missing	
	soho-gen-bat-low	
	soho-gen-bat-fail	
	soho-gen-sw-dnload-f	

100 Alarm Delta Log Status Commands

name	Type	Description
	soho-gen-sw-dnload-p	
	soho-gen-sw-act-fail	
	soho-gen-eqpt-vers-mis	
	soho-gen-sw-vers-mis	
	soho-gen-us-rate-mis	
	soho-gen-tune-fail	
	soho-gen-nw-time-err	
	soho-gen-opt-sig-high	
	soho-gen-opt-sig-low	
	soho-gen-eqpt-prov-sa	
	soho-gen-eqpt-prov-nsa	
	mdu-gen-omci-fail	
	mdu-gen-eqpt-selftest	
	mdu-gen-ac-pwr-fail	
	mdu-gen-bat-missing	
	mdu-gen-bat-low	
	mdu-gen-bat-fail	
	mdu-gen-phys-intrusion	
	mdu-gen-sw-dnload-f	
	mdu-gen-sw-dnload-p	
	mdu-gen-sw-act-fail	
	mdu-gen-eqpt-vers-mis	
	mdu-gen-sw-vers-mis	
	mdu-gen-us-rate-mis	
	mdu-gen-tune-fail	
	mdu-gen-mdu-env1	
	mdu-gen-mdu-env2	
	mdu-gen-mdu-env3	
	mdu-gen-nw-time-err	
	mdu-gen-opt-sig-high	
	mdu-gen-opt-sig-low	
	mdu-gen-eqpt-prov-sa	
	mdu-gen-eqpt-prov-nsa	
	ont-gen-sw-dnload-file	
	ont-gen-fan-fail	
	ont-gen-high-temp	
	ont-gen-high-temp-ex	
	ont-gen-emergency-call	
	ont-gen-sw-version	
	ont-poe-exceed-max	
	ont-poe-overload-yell	
	ont-opti-malfunc	
	ont-gen-cfgdld-fail	
	ont-gen-rssi-mis	
	ont-gen-tx-pwr-low	
	ont-gen-temp-high	
	ont-gen-volt-high	
	ont-gen-bias-high	
	ont-loopdetect-mis	
	ont-olt-rx-pw-lo	
	ont-olt-rx-pw-hig	
	ont-olt-rx-pw-warnlo	
	ont-olt-rx-pw-warnhig	
	ont-gen-tod-out-sync	
	ont-gen-tune-fail	
	hgu-tr069-parm-fail	
	ont-gen-tod-mismatch	

name	Type	Description
	sfu-sup-sw-file-error	
	sfu-sup-fan-failure	
	sfu-sup-temp-high-warn	
	sfu-sup-temp-shutoff	
	sfu-sup-emergency-call	
	sfu-sup-swverctrl-err	
	sfu-sup-poe-exceed-max	
	sfu-sup-poe-over-yell	
	sfu-opti-malfunc	
	sfu-sup-cfg-dnld-fail	
	sfu-sup-rssi-cfg-mism	
	sfu-sup-sfp-tx-low	
	sfu-sup-sfp-temp-high	
	sfu-sup-sfp-volt-high	
	sfu-sup-sfp-bias-high	
	sfu-sup-ld-cfg-mism	
	sfu-sup-olt-rx-low	
	sfu-sup-olt-rx-high	
	sfu-sup-olt-rx-lo-warn	
	sfu-sup-olt-rx-hi-warn	
	sfu-sup-tod-out-sync	
	sfu-sup-ont-tune-fail	
	sfu-tr069-parm-fail	
	sfu-sup-tod-mismatch	
	soho-sup-sw-file-error	
	soho-sup-fan-failure	
	soho-sup-temp-high-war	
	soho-sup-temp-shutoff	
	soho-sup-emergency-cal	
	soho-sup-swverctrl-err	
	soho-sup-poe-exceed-ma	
	soho-sup-poe-over-yell	
	soho-opti-malfunc	
	soho-sup-cfg-dnld-fail	
	soho-sup-rssi-cfg-mism	
	soho-sup-sfp-tx-low	
	soho-sup-sfp-temp-high	
	soho-sup-sfp-volt-high	
	soho-sup-sfp-bias-high	
	soho-sup-ld-cfg-mism	
	soho-sup-olt-rx-low	
	soho-sup-olt-rx-high	
	soho-sup-olt-rx-lo-war	
	soho-sup-olt-rx-hi-war	
	soho-sup-tod-out-sync	
	soho-sup-ont-tune-fail	
	soho-tr069-parm-fail	
	soho-sup-tod-mismatch	
	mdu-sup-sw-file-error	
	mdu-sup-fan-failure	
	mdu-sup-temp-high-warn	
	mdu-sup-temp-shutoff	
	mdu-sup-emergency-call	
	mdu-sup-swverctrl-err	
	mdu-sup-poe-exceed-max	
	mdu-sup-poe-over-yell	
	mdu-opti-malfunc	

100 Alarm Delta Log Status Commands

name	Type	Description
	mdu-sup-cfg-dnld-fail mdu-sup-rssi-cfg-mism mdu-sup-sfp-tx-low mdu-sup-sfp-temp-high mdu-sup-sfp-volt-high mdu-sup-sfp-bias-high mdu-sup-ld-cfg-mism mdu-sup-olt-rx-low mdu-sup-olt-rx-high mdu-sup-olt-rx-lo-warn mdu-sup-olt-rx-hi-warn mdu-sup-tod-out-sync mdu-sup-ont-tune-fail mdu-tr069-parm-fail mdu-sup-tod-mismatch ont-sbscr-lim-missing ont-sbscr-lim-type-mis ont-sbscr-lim-removal ont-sbscr-lim-fail ont-sbscr-lim-svc-mis ont-sbscr-lim-port-mis ont-svc-video-conf-mis ont-svc-video-pw-high ont-svc-video-pw-low ont-svc-pots-svc-mis ont-svc-pots-rtcp-lost ont-svc-pots-icnf-subs ont-svc-pots-icnf-ntfy ont-svc-pots-icnf-http ont-svc-pots-sip-reg ont-svc-pots-sip-inv ont-svc-pots-sip-subsc ont-svc-pots-sip-mt-tc ont-svc-pots-pk-los-tc ont-svc-pots-jitter-tc ont-svc-pots-subs-dns ont-svc-pots-subs-tcp ont-svc-pots-subs-tls ont-svc-pots-subs-auth ont-svc-pots-subs-to ont-svc-pots-subs-err ont-svc-pots-not-to ont-svc-pots-notref-to ont-svc-pots-not-mal ont-svc-pots-not-rej ont-svc-pots-http-dns ont-svc-pots-http-tcp ont-svc-pots-http-tls ont-svc-pots-http-auth ont-svc-pots-http-to ont-svc-pots-http-err ont-svc-pots-http-mal ont-svc-pots-insuff ont-svc-pots-poos ont-svc-lan-mismatch ont-svc-lan-loss-sig ont-svc-enet-poos	

name	Type	Description
	ont-svc-ces-ds1-mis	
	ont-svc-ces-ds1-los	
	ont-svc-ces-ds1-lof	
	ont-svc-ces-ds1-rair	
	ont-svc-ces-ds1-ais	
	ont-svc-ces-ds1-lnlpbk	
	ont-svc-ces-ds1-tmlpbk	
	ont-svc-ces-e1-mis	
	ont-svc-ces-e1-los	
	ont-svc-ces-e1-lof	
	ont-svc-ces-e1-rair	
	ont-svc-ces-e1-ais	
	ont-svc-voip-cnf-file	
	ont-svc-voip-svc-mis	
	ont-svc-voip-gw-comm	
	ont-svc-voip-dhcp-fail	
	ont-svc-voip-icnf-sub	
	ont-svc-voip-icnf-ntfy	
	ont-svc-voip-icnf-http	
	ont-svc-voip-dhcp-to	
	ont-svc-voip-dhcp-mal	
	ont-svc-voip-dhcp-noad	
	ont-svc-voip-dhcp-leas	
	ont-svc-voip-sub-dns	
	ont-svc-voip-sub-tcp	
	ont-svc-voip-sub-tls	
	ont-svc-voip-sub-auth	
	ont-svc-voip-sub-to	
	ont-svc-voip-sub-err	
	ont-svc-voip-not-to	
	ont-svc-voip-notref-to	
	ont-svc-voip-not-mal	
	ont-svc-voip-not-rej	
	ont-svc-voip-http-dns	
	ont-svc-voip-http-tcp	
	ont-svc-voip-http-tls	
	ont-svc-voip-http-auth	
	ont-svc-voip-http-to	
	ont-svc-voip-http-err	
	ont-svc-voip-http-mal	
	ont-svc-voip-sub-refr	
	ont-svc-voip-not-refr	
	ont-svc-voip-icfg-err	
	ont-svc-v-ani-conf-mis	
	ont-svc-v-ani-loss-sig	
	ont-svc-v-ani-lv-high	
	ont-svc-v-ani-lv-low	
	ont-svc-pwe-mismatch	
	ont-svc-pwe-reordr-lof	
	ont-svc-pwe-jitt-buf-o	
	ont-svc-pwe-jitt-buf-u	
	ont-svc-pwe-malf-frms	
	ont-svc-pwe-late-frms	
	ont-svc-pwe-link-loss	
	ont-svc-pwe-arp-fail	
	ont-svc-xdsl-mismatch	
	ont-svc-xdsl-ne-lof	

100 Alarm Delta Log Status Commands

name	Type	Description
	ont-svc-xdsl-ne-los ont-svc-xdsl-ne-line ont-svc-xdsl-ne-lol ont-svc-xdsl-fe-lof ont-svc-xdsl-fe-los ont-svc-xdsl-fe-lop ont-svc-xdsl-cnf-err ont-svc-xdsl-ne-es-tc ont-svc-xdsl-ne-ses-tc ont-svc-xdsl-ne-uas-tc ont-svc-xdsl-fe-es-tc ont-svc-xdsl-fe-ses-tc ont-svc-xdsl-fe-uas-tc ont-tc-rx-los-frag-tc ont-tc-tx-los-frag-tc ont-tc-bad-gem-hd-tc ont-uni-ds-drp-d-fr-tc ont-uni-up-drp-d-fr-tc ont-uni-ds-crc-fr-tc ont-uni-up-crc-fr-tc ont-cpu-util-tca ont-mem-util-tca pim-neighbor-down pim-max-mcroutes li-traffic-disabled li-bandwidth-limit li-out-of-res otdr-cap-mismatch login-successful login-failure cfm-defrdiccm cfm-defmacstatus cfm-defremoteccm cfm-deferrorccm cfm-defxconccm cfm-defais bfd-session-down bfd-max-resource bfd-stale-entry tca-outputbw tca-inputbw tca-rxcrcalign tca-txcrcalign tca-txcollisions tca-outputhighbw tca-outputmedbw tca-outputlowbw tca-inputhighbw tca-inputmediumbw tca-inputlowbw eth-cfm-defrdiccm eth-cfm-defmacstatus eth-cfm-defremoteccm eth-cfm-deferrorccm eth-cfm-defxconccm rsvp-neighbor-down rsvp-instance-down	

name	Type	Description
	eth-ring-path-block	
	ai-platform-down	
	ai-appl-install-fail	
	ip-assign-fail	
	ont-tr069-serv-mis	
	ont-snmp-mis	
	bsf-dhcpv4	
	bsf-dhcpv6	
	bsf-pon	
	bsf-vbridge	
	bsf-qos	
	bsf-igmp	
	bsf-lxfwd	
	prot-not-available	
	prot-switchover-fail	
	efm-oam-cpelinkfault	
	efm-oam-cpedyinggasp	
	efm-oam-cpecrevt	
	ont-loopdetect	
	alarm-tbl-overflow	
	auto-switch-status	
	auswqueuefullatm	
	auswbkpfailatm	
	auswrecfgfailatm	
	auswdataunatm	
	auswqueuefulptm	
	auswbkpfailptm	
	auswrecfgfailptm	
	auswdataunptm	
	auswbakpfailatm	
	chpr-com-fail	
	chpr-tx-fail	
	chpr-unprov-ont	
	chpr-prov-mismatch	
	chpr-loss-sig	
	chpr-diagnostic	
	chpr-loid-conflict	
	chpr-loid-pwd-err	
	chpr-stk-laser-dis	
	chpr-sfp-mismatch	
	chpr-rng-mismatch	
	chpr-alien-test	
	chpr-alien-detect	
	chpr-deact-hightca	
	chpr-deact-lowtca	
	chpr-dp-integ	
	olt-chpr-tc-err-frag	
	olt-chpr-up-bw-tca	
	olt-chpr-down-bw-tca	
	cfg-dld-fail	
	cfg-act-fail	
	cfg-dld-ip	
	cfg-ver-mismatch	
	cfg-file-missing	
	cfg-verctrl-err	
	cfg-not-supported	
	ont-prot-not-available	

100 Alarm Delta Log Status Commands

name	Type	Description
	ont-gen-temp-low	
	ont-gen-volt-low	
	ont-gen-tx-pwr-high	
	ont-gen-bias-low	
	ont-gen-rx-hwarn	
	ont-gen-rx-lwarn	
	ont-gen-tx-hwarn	
	ont-gen-tx-lwarn	
	ont-gen-temp-hwarn	
	ont-gen-temp-lwarn	
	ont-gen-volt-hwarn	
	ont-gen-volt-lwarn	
	ont-gen-bias-hwarn	
	ont-gen-bias-lwarn	
	sfu-sup2-temp-low	
	sfu-sup2-volt-low	
	sfu-sup2-tx-high	
	sfu-sup2-bias-low	
	sfu-sup2-rx-hwarn	
	sfu-sup2-rx-lwarn	
	sfu-sup2-tx-hwarn	
	sfu-sup2-tx-lwarn	
	sfu-sup2-temp-hwarn	
	sfu-sup2-temp-lwarn	
	sfu-sup2-volt-hwarn	
	sfu-sup2-volt-lwarn	
	sfu-sup2-bias-hwarn	
	sfu-sup2-bias-lwarn	
	soho-sup2-temp-low	
	soho-sup2-volt-low	
	soho-sup2-tx-high	
	soho-sup2-bias-low	
	soho-sup2-rx-hwarn	
	soho-sup2-rx-lwarn	
	soho-sup2-tx-hwarn	
	soho-sup2-tx-lwarn	
	soho-sup2-temp-hwarn	
	soho-sup2-temp-lwarn	
	soho-sup2-volt-hwarn	
	soho-sup2-volt-lwarn	
	soho-sup2-bias-hwarn	
	soho-sup2-bias-lwarn	
	mdu-sup2-temp-low	
	mdu-sup2-volt-low	
	mdu-sup2-tx-high	
	mdu-sup2-bias-low	
	mdu-sup2-rx-hwarn	
	mdu-sup2-rx-lwarn	
	mdu-sup2-tx-hwarn	
	mdu-sup2-tx-lwarn	
	mdu-sup2-temp-hwarn	
	mdu-sup2-temp-lwarn	
	mdu-sup2-volt-hwarn	
	mdu-sup2-volt-lwarn	
	mdu-sup2-bias-hwarn	
	mdu-sup2-bias-lwarn	
	cust-alm1	

name	Type	Description
	cust-alm2 cust-alm3 cust-alm4 cust-alm5 cust-alm6 cust-alm7 cust-alm8 cust-alm9 cust-alm10 cust-alm11 cust-alm12 cust-alm13 cust-alm14 cust-alm15 cust-alm16 cust-alm17 cust-alm18 cust-alm19 cust-alm20 cust-alm21 cust-alm22 cust-alm23 cust-alm24 cust-alm25 cust-alm26 cust-alm27 cust-alm28 cust-alm29 cust-alm30 cust-alm31 ethernet-ring-pthfwst ethernet-ring-fop-to ethernet-ring-fop-pm fpm-depletion exp-seizureack exp-disconack exp-forcerelack packet-loss remote-packet-loss no-dsp-resource la-down la-standby-na la-switch-fail la-degrade melt-board-reset board-shelf-mismatch fcs-thresh-exceed) Possible values: - all : all alarms for query - xtca-ne-es : errored seconds in 15 min - xtca-ne-ses : severely errored seconds in 15 min - xtca-ne-uas : unavailable seconds in 15 min - xtca-ne-day-es : errored seconds in 1 day - xtca-ne-day-ses : severely errored seconds in 1 day - xtca-ne-day-uas : unavailable seconds in 1 day - xtca-fe-es : errored seconds in 15 min - xtca-fe-ses : severely errored secs in 15 min	

100 Alarm Delta Log Status Commands

name	Type	Description
	- xtca-fe-uas : unavailable seconds in 15 min - xtca-fe-day-es : errored seconds in 1 day - xtca-fe-day-ses : severely errored secs in 1 day - xtca-fe-day-uas : unavailable seconds in 1 day - xtca-leftrs : low error free throughput seconds in 15 min - xtca-day-leftrs : low error free throughput seconds in 1 day - xtca-fe-leftrs : far end low error free throughput seconds in 15 min - xtca-fe-day-leftrs : far end low error free throughput seconds in 1 day - xtca-auto-port-reset : auto-port-resets in 1 week - xtca-reinit : Reinitialization seconds in 15 min - xtca-day-reinit : Reinitialization seconds in 1 day - xdsl-ne-los : loss of signal - xdsl-ne-lof : loss of frame - xdsl-ne-lom : loss of margin - xdsl-ne-ese : excessive severe errors - xdsl-act-cfg-error : line configuration data cannot be used - xdsl-act-not-feas : line capacity not enough to setup requested profile - xdsl-up-br-reach : planned bitrate not reached after initialization - xdsl-ne-ncd : no cell delineation - xdsl-ne-lcd : loss of cell delineation - xdsl-fe-los : loss of signal - xdsl-fe-lof : loss of frame - xdsl-fe-lpr : loss of power - xdsl-fe-lol : loss of link - xdsl-fe-lom : loss of margin - xdsl-fe-ese : excessive severe errors - xdsl-fe-upbo-vio : upbo violation - xdsl-fe-cpe-pol : activation failure cpe policing - xdsl-tpstc-mis : mismatch between the configured tps-tc mode and the mode supported by the connected cpe - xdsl-act-comm : init not successful due to communications problem - xdsl-act-modem : no peer modem detected - xdsl-do-br-reach : planned bitrate not reached after init - xdsl-fe-ncd : no cell delineation - xdsl-fe-lcd : loss of cell delineation - xdsl-fctx-init-fail : init not successful due to forced rtx - xdsl-vect-dle : vectoring disorderly leaving event - xdsl-fe-mis-peer-35b : VDSL2 35b opmode mismatch between XTU-C and XTU-R - vectline-xtc-var-vict : excessive victim crosstalk coefficients variation - vectline-xtc-var-dist : excessive disturber crosstalk coefficients variation - vectline-corp-errf : corrupted or missing errorf-samples - vect-cpe-cap-mismatch : not allowed Vectoring CPE connected - vectline-conf_notfeas : vect line configuration not feasible - vect-vp-lt-mismatch : actual vp-lt connection(s) do not match expected vp-lt connection(s) or vp-lt connection lost - vect-inv-qsf : qsf has no valid Nokia ID - vect-vp-lt-fail : vp-lt connection not operational - vect-no-gain-at-init : Lines cannot train in gain-at-init	

name	Type	Description
	mode - sw-rollback : non active oswp,db cannot be operational - will rollback - db-rollback : selected oswp,db cannot be operational - will rollback - xvps-inv-dbase : invalid xvps dbase - inv-cde-file : invalid xvps cde file - miss-cde-file : missing cde profile - cde-hash-error : cde profile hash error - auto-fetch-failure : not able to fetch file from specified server - low-disk-space : insufficient space for Sw storage - cell-discard-up : cell discarded in the upstream direction - cell-discard-down : cell discarded in the downstream direction - persist-data-loss : all data lost after restart - system not configured - mac-conflict : duplicate mac address on the bridge port - vmac-full : virtual mac address is full on the bridge port - sntp-comm-lost : sntp server not responding - preferred-mode : preferred mode not available - timing-reference : timing reference failure - nt-disk-95%full : nt disk 95% full - shub-loc : communication lost with shub - cf-error : compact flash access error - back-pnl-inv : BackPanel-type Invalid - ihub-conf-loss : iHub configuration loss - recent changes lost - rack-power : power fuse broken - rack-fan-unit1 : fan unit rack 1 failing - rack-fan-unit2 : fan unit rack 2 failing - shelf-mismatch : shelf type different from planned type - shelf-missing : detected shelf no longer detected - shelf-install-missing : shelf planned but not installed - door : open cabinet door - ac-power-fail : external power failure - shelf shutdown in 15 minutes - board-mismatch : board inserted different from planned - waiting-for-sw : not able to download all the applicable sw files - temp-exceeded : temperature threshold exceeded on the board - backplane-data-failure: It port on backplane data failure - temp-shutdown : board powered down itself - too high temperature - board-missing : board detected after planning - now missing - board-instl-missing : board never detected after planning - board-init : board initialisation failure - board-reset-prot : number of resets exceeded - sem-power-fail : SEM external power failure - sem-ups-fail : SEM external power supply failure - board-reset-cf : board reset and/or communication failure - vlan-assign-fail : failure to assign VLAN for a user session - vsa-info-invalid : radius fail to assign a valid vsa to a user session - auth-mac-conflict : failure to check mac conflict for a user	

100 Alarm Delta Log Status Commands

name	Type	Description
	- session - user-pwd-fault : failure to check user or password of a user session - up-plan-bitrate : upstream bitrate is above min and below planned - up-min-bitrate : upstream bitrate is below min bitrate - up-config-not-feas : upstream bitrate is not enough to set up config group - down-plan-bitrate : downstream bitrate is above min and below planned - down-min-bitrate : downstream bitrate is below min bitrate - down-config-not-feas : downstream bitrate is not enough to set up config group - non-bonding-cpe : no bonding cpe modem is connected - multiple-cpes : bonding group has multiple cpe modems connected - register : bonding group discovery or aggregation register failure - group-incomplete : bonding group is incomplete - host-sfp-los : loss of signal - host-sfp-tx-fail : Tx failure - host-sfp-not-prst : not present - host-sfp-inv-id : no valid Nokia ID - host-sfp-ctrl-fail : control failure - host-sfp-rmtlt : unexpected remote plug-in - host-sfp-mismatch : assignment does not match reported rack/shelf/slot - host-sfp-incompt : incompatible shelf type detected - exp-sfp-los : expansion side loss of signal - exp-sfp-tx-fail : Tx failure - exp-sfp-not-prst : not present - exp-sfp-inv-id : no valid Nokia ID - exp-sfp-ctrl-fail : control failure - exp-sfp-1-los : expansion side sfp1 loss of signal - exp-sfp-2-los : expansion side sfp2 loss of signal - ext-qsfp-invlid : Invalid Nokia ID - tx-power-high-alarm : tx power more than alarm range - tx-power-low-alarm : tx power less than alarm range - rx-power-high-alarm : rx power more than alarm range - rx-power-low-alarm : rx power less than alarm range - tx-biascur-high-alarm : tx bias current high alarm - tx-biascur-low-alarm : tx bias current low alarm - volt-high-alarm : voltage high alarm - volt-low-alarm : voltage low alarm - temp-high-alarm : temperature high alarm - temp-low-alarm : temperature low alarm - tx-power-high-warn : tx power more than warn range - tx-power-low-warn : tx power less than warn range - rx-power-high-warn : rx power more than warn range - rx-power-low-warn : rx power less than warn range - tx-biascur-high-warn : tx bias current high warn - tx-biascur-low-warn : tx bias current low warn - volt-high-warn : voltage high warn - volt-low-warn : voltage low warn - temp-high-warn : temperature high warn - temp-low-warn : temperature low warn - onu-unprovisioned : unprovisioned ont	

name	Type	Description
	- signal-loss : pon loss of signal - bitrate-high : the error bit rate high at pon interface - opmodule-mismatch : the optical module mismatched at pon interface - key-fail-one-churn : key exchange failure during one churning time - key-fail-three-churn : key exchange failure during three churning time - oam-discov-fail : extend oam discovery failure - report-timeout : report timeout detecting - total-packets-exceed : total amount of protocol packets exceed threshold - arp-packets-exceed : protocol arp packets exceed threshold - dhcp-packets-exceed : protocol dhcp packets exceed threshold - igmp-packets-exceed : protocol igmp packets exceed threshold - pppoe-packets-exceed : protocol pppoe packets exceed threshold - nd-packets-exceed : protocol nd packets exceed threshold - icmpv6-packets-exceed : protocol icmpv6 packets exceed threshold - mld-packets-exceed : protocol mld packets exceed threshold - dhcpv6-packets-exceed : protocol dhcpv6 packets exceed threshold - cfm-packets-exceed : protocol cfm packets exceed threshold - dsx1-serdes-fail : SERDES clock alarm failure - dsx1-tributary1-fail : The tributary 1 clock is not present - dsx1-tributary2-fail : The tributary 2 clock is not present - dsx1-los-fail : All the selected tribs in Loss of Signal - dsx1-ais-sync : Alarm Indication signal on the tributary selected as sync source - dsx1-lof-sync : Loss of Framing on the tributary selected as sync source - dsx1-los-sync : Loss of signal on the tributary selected as sync source - dsx1-deg-fail : Signal degrade Alarm - dsx1-rei-from-liu : Remote Error Indication alarm from LIU - dsx1-rdi-from-liu : Remote Defect Alarm from LIU - dsx1-crc6-from-liu : Cyclic Redundancy check-6 alarm from LIU - dsx1-crc4-from-liu : Cyclic Redundancy check-4 alarm from LIU - dsx1-crc4-th-from-liu : Cyclic Redundancy check-4 threshold alarm from LIU - dsx1-ais-from-liu : Alarm Indication Signal alarm from LIU - dsx1-los-from-liu : Loss of signal alarm from LIU - dsx1-lof-from-liu : Loss of framing alarm from LIU - dsx1-lomf-from-liu : Loss of Multi-frame alarm from LIU - dsx1-rei-from-iwf : Remote Error Indication alarm from IWF - dsx1-rdi-from-iwf : Remote Defect Alarm from IWF - dsx1-crc6-from-iwf : Cyclic Redundancy check-6 alarm	

100 Alarm Delta Log Status Commands

name	Type	Description
	from IWF - dsx1-crc4-from-iwf : Cyclic Redundancy check-4 alarm from IWF - dsx1-crc4-th-from-iwf : Cyclic Redundancy check-4 threshold alarm from IWF - dsx1-ais-from-iwf : Alarm Indication Signal alarm from IWF - dsx1-los-from-iwf : Loss of signal alarm from IWF - dsx1-lof-from-iwf : Loss of framing alarm from IWF - dsx1-lomf-from-iwf : Loss of Multi-frame alarm from IWF - pppce-trans-15min-tca : 15 minutes transaction timeout count exceeds configured TCA - pppce-sess-15min-tca : 15 minutes session timeout count exceeds configured TCA - pppce-trans-1day-tca : 1day transaction timeout count exceeds configured TCA - pppce-sess-1day-tca : 1day session timeout count exceeds configured TCA - custom1 : customizable alarm 1 - custom2 : customizable alarm 2 - custom3 : customizable alarm 3 - custom4 : customizable alarm 4 - custom5 : customizable alarm 5 - he-custom1 : host expansion customizable alarm 1 - he-custom2 : host expansion customizable alarm 2 - he-custom3 : host expansion customizable alarm 3 - he-custom4 : host expansion customizable alarm 4 - he-custom5 : host expansion customizable alarm 5 - he-custom6 : host expansion customizable alarm 6 - custom6 : customizable alarm 6 - custom7 : customizable alarm 7 - custom8 : customizable alarm 8 - custom9 : customizable alarm 9 - custom10 : customizable alarm 10 - custom11 : customizable alarm 11 - custom12 : customizable alarm 12 - custom13 : customizable alarm 13 - custom14 : customizable alarm 14 - custom15 : customizable alarm 15 - custom16 : customizable alarm 16 - custom17 : customizable alarm 17 - loss-swo-cap : switch over capability in a redundant system - ping-check-fail : ping check in a redundant system - der-temp1 : Derived Alarm for Temporal Filter 1 - der-temp2 : Derived Alarm for Temporal Filter 2 - der-temp3 : Derived Alarm for Temporal Filter 3 - der-temp4 : Derived Alarm for Temporal Filter 4 - der-temp5 : Derived Alarm for Temporal Filter 5 - der-temp6 : Derived Alarm for Temporal Filter 6 - der-temp7 : Derived Alarm for Temporal Filter 7 - der-temp8 : Derived Alarm for Temporal Filter 8 - der-temp9 : Derived Alarm for Temporal Filter 9 - der-temp10 : Derived Alarm for Temporal Filter 10 - der-temp11 : Derived Alarm for Temporal Filter 11 - der-temp12 : Derived Alarm for Temporal Filter 12 - der-temp13 : Derived Alarm for Temporal Filter 13 - der-temp14 : Derived Alarm for Temporal Filter 14	

name	Type	Description
	- der-temp15 : Derived Alarm for Temporal Filter 15 - der-temp16 : Derived Alarm for Temporal Filter 16 - der-temp17 : Derived Alarm for Temporal Filter 17 - der-temp18 : Derived Alarm for Temporal Filter 18 - der-temp19 : Derived Alarm for Temporal Filter 19 - der-temp20 : Derived Alarm for Temporal Filter 20 - der-temp21 : Derived Alarm for Temporal Filter 21 - der-temp22 : Derived Alarm for Temporal Filter 22 - der-temp23 : Derived Alarm for Temporal Filter 23 - der-temp24 : Derived Alarm for Temporal Filter 24 - der-temp25 : Derived Alarm for Temporal Filter 25 - der-temp26 : Derived Alarm for Temporal Filter 26 - der-temp27 : Derived Alarm for Temporal Filter 27 - der-temp28 : Derived Alarm for Temporal Filter 28 - der-temp29 : Derived Alarm for Temporal Filter 29 - der-temp30 : Derived Alarm for Temporal Filter 30 - der-temp31 : Derived Alarm for Temporal Filter 31 - der-spa1 : Derived Alarm for Spatial Filter 1 - der-spa2 : Derived Alarm for Spatial Filter 2 - der-spa3 : Derived Alarm for Spatial Filter 3 - der-spa4 : Derived Alarm for Spatial Filter 4 - der-spa5 : Derived Alarm for Spatial Filter 5 - der-spa6 : Derived Alarm for Spatial Filter 6 - der-spa7 : Derived Alarm for Spatial Filter 7 - der-spa8 : Derived Alarm for Spatial Filter 8 - der-spa9 : Derived Alarm for Spatial Filter 9 - der-spa10 : Derived Alarm for Spatial Filter 10 - der-spa11 : Derived Alarm for Spatial Filter 11 - der-spa12 : Derived Alarm for Spatial Filter 12 - der-spa13 : Derived Alarm for Spatial Filter 13 - der-spa14 : Derived Alarm for Spatial Filter 14 - der-spa15 : Derived Alarm for Spatial Filter 15 - der-spa16 : Derived Alarm for Spatial Filter 16 - der-spa17 : Derived Alarm for Spatial Filter 17 - der-spa18 : Derived Alarm for Spatial Filter 18 - der-spa19 : Derived Alarm for Spatial Filter 19 - der-spa20 : Derived Alarm for Spatial Filter 20 - der-spa21 : Derived Alarm for Spatial Filter 21 - der-spa22 : Derived Alarm for Spatial Filter 22 - der-spa23 : Derived Alarm for Spatial Filter 23 - der-spa24 : Derived Alarm for Spatial Filter 24 - der-spa25 : Derived Alarm for Spatial Filter 25 - der-spa26 : Derived Alarm for Spatial Filter 26 - der-spa27 : Derived Alarm for Spatial Filter 27 - der-spa28 : Derived Alarm for Spatial Filter 28 - der-spa29 : Derived Alarm for Spatial Filter 29 - der-spa30 : Derived Alarm for Spatial Filter 30 - der-spa31 : Derived Alarm for Spatial Filter 31 - apsf-alarm : Applique Power Supply Failure - custextalarm1 : Customizable External Alarm Number 1 - custextalarm2 : Customizable External Alarm Number 2 - custextalarm3 : Customizable External Alarm Number 3 - custextalarm4 : Customizable External Alarm Number 4 - custextalarm5 : Customizable External Alarm Number 5 - pluginfan : REM Fan Alarm - plugin-dc-a : REM DC A Alarm - plugin-dc-b : REM DC B Alarm	

100 Alarm Delta Log Status Commands

name	Type	Description
	- plugin-dg : Dying Gasp Alarm - ntr-a-loss : NTR-A signal is not available - ntr-b-loss : NTR-B signal is not available - xvps-conf-loss : xvps configuration loss - mac-entry-nofree : no free mac entry in the mac table on It board - fibre-conn-mismatch : REM Fibre Connection Mismatch Alarm - link-cap-mismatch : Link speed capability mismatch - eqpt-cap-mismatch : Link equipment capability mismatch - ctrl-dnld-failure : Controller card download failure - melt-hw-issue : MELT hardware issue - melt-board-reset : MELT board reset - board-shelf-mismatch : board type and shelf type mismatch - mgnt-type-mismatch : Board management type mismatch - fileserv-unavail : file transfer Server unavailable or file transfer failed - shdsl-n-loopback : loopback active at the network side - shdsl-c-loopback : loopback active at the customer side - shdsl-conferr : configuration error - shdsl-atm-lcd : loss of atm cell delineation - shdsl-lpr : loss of power at stu-r - shdsl-secu-err : unable to disable stu-r access - shdsl-dev-fault : device fault - shdsl-atm-ncd : no atm cell delineation - shdsl-n-losw : loss of sync word at the network side on each pair - shdsl-c-losw : loss of sync word at the customer side on each pair - shdsl-n-aten : loop attenuation alarm at the network side on each pair - shdsl-c-aten : loop attenuation alarm at the customer side on each pair - shdsl-n-snr : snr margin alarm at the network side each pair - shdsl-c-snr : snr margin alarm at the customer side on each pair - shdsl-n-dccont : dc continuity fault at the network side on each pair - shdsl-c-dccont : dc continuity fault at the customer side on each pair - shdsl-c-actfail : activation failure at the customer side on each pair - e1-fe-rai : Receiving Remote Alarm Indication - e1-ne-rai : Transmitting Remote Alarm Indication - e1-fe-ais : Receiving Alarm Indication Signal - e1-ne-ais : Transmitting Alarm Indication Signal - e1-lof : E1 Loss of frame - e1-los : E1 Loss of Signal - e1-loopback : E1 facility in loopback - ima-grp-fe-su : far-end starting up - ima-grp-fe-cfg : far-end failed configuration - ima-grp-ne-cfg : near-end failed configuration - ima-grp-fe-nl : insufficient number of links at far-end - ima-grp-ne-nl : insufficient number of links at near-end - ima-grp-fe-blk : far-end is blocked - ima-lnk-lif : loss of ima frame - ima-lnk-lods : link out of delay synchronization	

name	Type	Description
	- ima-lnk-misc : link misconnect - ima-lnk-rfi : link remote failure indication - ima-lnk-fault : fault in link facility - ima-lnk-txblk : transmit blocked due to far-end - ima-lnk-rxblk : receive blocked due to far-end - bad-digitmap : Configured digitmap is unusable - dhcp-unreach : The DHCP server is unreachable - dhcp-no-srv : The address in DHCP reply is NULL - dhcp-inv-srv : The address in DHCP reply is invalid - norpniewithsoftdsp : do not plan / plug-in RPNI-E board with SoftDsp SW image - unknown-sub : subscriber exist in the POLT, but not in the appl server - ground-key : Return current to the ground - port-hightemp : Temperature threshold on user port exceeded. - port-jbfltca : JB fill level threshold on user port exceeded. - reg-domainname : Registration failure (resolving domain name). - reg-auth : Registration failure (authentication). - reg-timeout : Registration failure (message timeout). - reg-srvfailresp : Registration failure (failure response from server). - inv-domainname : Invitation failure (resolving domain name). - inv-auth : Invitation failure (authentication). - inv-timeout : Invitation failure (message timeout). - inv-srvfailresp : Invitation failure (failure response from server). - subs-srvfailresp : Subscribe failure (failure response from server). - subs-domainname : Subscribe failure (resolving domain name). - subs-auth : Subscribe failure (authentication). - subs-refreshfail : Subscribe failure (refresh failure). - subs-inittimeout : Subscribe failure (initial REQ timeout). - emergency-call : Emergency call for SIP POTS is ongoing. - e1sip-reg-domainname : E1 sip termination registration failure (resolving domain name). - e1sip-reg-auth : E1 sip termination registration failure (authentication). - e1sip-reg-timeout : E1 sip termination registration failure (message timeout). - e1sip-reg-srvfailresp : E1 sip termination registration failure (failure response from server). - e1sip-inv-domainname : E1 sip termination invitation failure (resolving domain name). - e1sip-inv-auth : E1 sip termination invitation failure (authentication). - e1sip-inv-timeout : E1 sip termination invitation failure (message timeout). - e1sip-inv-srvfailresp : E1 sip invitation failure (failure response from server). - e1sip-emergency-call : Emergency call for ISDN PRA/CAS R2 is ongoing. - e1itf-ais-signal : Alarm Indication Signal detected at E1 interface.	

100 Alarm Delta Log Status Commands

name	Type	Description
	- e1itf-los-signal : Loss Of Signal detected at E1 interface. - e1itf-rai-signal : Remote Alarm Indication detected at E1 interface. - e1sip-misconfig-mgc10 : Configuration not conform with the core network entity. - e1sip-nsmprf-missed : The SIP termination requires a NSM profile. - e1t1itf-recv-ais : Alarm Indication Signal received at interface. - e1t1itf-recv-los : Loss Of Signal received at interface. - e1t1itf-recv-rai : Remote Alarm Indication received at interface. - transport-mismatch : Transport protocol mismatch - dns-lookup-failure : Dns look up failure - none-dns-srv : No reply for all DNS serverd - no-dns-srv : No DNS servers configured - none-srv : No reply for all SIP First Hops - no-srv : No SIP First Hop configured - reg-srv-unreach : All SIP register servers are unreachable - proxy-srv-unreach : All SIP proxy servers are unreachable - dhcp-srv-unreach : The DHCP server is unreachable on this board - fo-trigger : Fail Over Triggered - fb-trigger : Fail Back Triggered - du-trigger : Deliberate Update Triggered - ssp-missing : SSP Missing in CDE - dns-pool-exceed : Number of different SG associated DNS pools exceed - lsa-fo-trigger : SIP voice service degraded - fail-over to LSA server - reg-domainname-sec : Registration failure (resolving domain name). - reg-auth-sec : Registration failure (authentication). - reg-timeout-sec : Registration failure (message timeout). - reg-srvfailresp-sec : Registration failure (failure response from server). - inv-domainname-sec : Invitation failure (resolving domain name). - inv-auth-sec : Invitation failure (authentication). - inv-timeout-sec : Invitation failure (message timeout). - inv-srvfailresp-sec : Invitation failure (failure response from server). - subs-srvfailresp-sec : Subscribe failure (failure response from server). - subs-domainname-sec : Subscribe failure (resolving domain name). - subs-auth-sec : Subscribe failure (authentication). - subs-refreshfail-sec : Subscribe failure (refresh failure). - subs-inittimeout-sec : Subscribe failure (initial REQ timeout). - emergency-call-sec : Emergency call for Secondary Termination is ongoing. - fanout : Lt load overflow - up-overflow : Upstream load overflow - upobc-overflow : Upstream load to OBC overflow - dwobc-overflow : Downstream load to OBC overflow - dw-overflow : Downstream load overflow	

name	Type	Description
	- lwpri-overflow : The number of BE and CL pkts dropped exceed threshold - queue-drop : The number of pkts dropped by queue exceeds threshold - queue-load : The queue load exceeds threshold - queue-peak-usage : The queue peak usage exceeds threshold - mgc-unreachable : loss of contact with the media gateway controller - failover-to-esamgc : failover to esa mgc - sgc-unreachable : loss of contac with signaling gateway controller - lcard-unreach-srvcard : line card unreachable with server card - lcard-type-mismatch : associate board of wrong type - meg-unknown-sub : the megaco subscriber is unknown - meg-ground-key : voice port ground key - meg-high-temp : voice port high temperature - meg-act-fail : the first link layer for isdn subscriber activation failure - meg-over-current : voice port over current - line-showering : line showering - low-qos-packetloss : the total packet loss has exceeded the configured threshold - low-qos-jitter : the rtp jitter has exceeded the configured threshold - low-qos-delay : the rtp delay has exceeded the configured threshold - sig-brd-persist-loss : voice signaling board persistent data loss - sig-brd-disk-full : voice signaling board disk 90% full - sig-brd-db-rollback : voice signaling board db rollback - mg-overload : mg overload - meg-unknown-sub-sec : The Megaco subscriber exists in voice signaling board but not in media gateway controller. - line-showering-sec : A subscriber line exceeds 20 off-hook / on-hook events / minute. - loss-env-mon : env-monitor box lost or not alive - etca-los : loss of signal errors in 15 min - etca-fcs : frame check sequence errors in 15 min - etca-day-los : loss of signal errors in 1 day - etca-day-fcs : frame check sequence errors in 1 day - etca-rx-octets : received octets in 15 min - etca-tx-octets : transmitted octets in 15 min - etca-day-rx-octets : received octets in 1 day - etca-day-tx-octets : transmitted octets in 1 day - user-sfp-los : user sfp loss of signal - user-sfp-tx-fail : user sfp tx failure - user-sfp-not-prst : user sfp not detected - user-sfp-inv-id : user sfp invalid id - user-sfp-t-exceed : user sfp temperature exceed - user-sfp-mismatch : user sfp mismatch the configured type - uplink-sfp-los : uplink sfp loss of signal - uplink-sfp-tx-fail : uplink sfp tx failure - uplink-sfp-not-prst : uplink sfp not detected - uplink-sfp-inv-id : uplink sfp invalid id - uplink-sfp-t-exceed : uplink sfp temperature exceed	

100 Alarm Delta Log Status Commands

name	Type	Description
	- uplink-sfp-mismatch : uplink sfp mismatch the configured type - loss-lsmwp-cap : lsm redundancy - inv-xvps-pair-data : invalid xvps pair redundancy data - network-power-loss : Loss of Network Power - hw-fault : Hardware Failure - bat-miss : Power Source Battery Missing - bat-fail : Power Source Battery Failure - bat-low : Power Source Battery Charge LOW - bat-a-fail : Power Source BAT-A Fail - bat-b-fail : Power Source BAT-B Fail - ac-vol-out-range : AC Input Voltage Value Out of Range - network-power-loss-b : Loss of Network Power B - sem-ac-power-fail : External AC power supply failure - sem-ups-low-volt : External power supply low voltage - dc-a-fail : Local DC A power failure - dc-b-fail : Local DC B power failure - plan-power-mismatch : Planned and detected power mode mismatch - water-seepage-in-box : Detected water seepage in enclosure - sealed-box-open : Sealed box open detected - dc-a-vol-out-range : DC A Input Voltage Value Out of Range - dc-b-vol-out-range : DC B Input Voltage Value Out of Range - inlet-temp-major : The inlet temperature has exceeded a major level - inlet-temp-critical : The inlet temperature has exceeded a critical level - psu-fail-crit : Power Supply failure - psu-a-fail-presence : Power Supply A is not present - psu-a-fail-vin-ac-nok : Power Supply A has Vin AC fault - psu-a-fail-vin-uv : Power Supply A has Vin undervoltage - psu-a-fail-vin-ov : Power Supply A has Vin overvoltage - psu-a-fail-vout-uv : Power Supply A has Vout undervoltage - psu-a-fail-vout-ov : Power Supply A has Vout overvoltage - psu-a-fail-iout-oc : Power Supply A has Iout overcurrent - psu-a-fail-vertemp : Power Supply A has over temperature - psu-b-fail-presence : Power Supply B is not present - psu-b-fail-vin-ac-nok : Power Supply B has Vin AC fault - psu-b-fail-vin-uv : Power Supply B has Vin undervoltage - psu-b-fail-vin-ov : Power Supply B has Vin overvoltage - psu-b-fail-vout-uv : Power Supply B has Vout undervoltage - psu-b-fail-vout-ov : Power Supply B has Vout overvoltage - psu-b-fail-iout-oc : Power Supply B has Iout overcurrent - psu-b-fail-vertemp : Power Supply B has over temperature - synce-fail : synce clock source failure - bits-fail : bits clock source failure - bits-output-shutoff : bits output failure - ieee1588-fail : ieee1588 clock source failure - gnss-fail : gnss clock source failure - ieee1588-hybrid-fail : ieee1588 hybrid tod source failure	

name	Type	Description
	- signal-loss : synce or bits clock signal loss - signal-efd : synce or bits clock signal exceed frequency deviation - esmc-loss : clock source loss SSM information - bits-output-exceed : exceed bits output threshold - ql-input-exceed : exceed input clock source threshold - holdover : clock system is in the holdover - lti : all clock source failed - tod-reference-fail : Timing ToD Reference failed - internal-clk-fail : Internal CLK failed - bgp-peer-down : peer operational state is down - bgp-routes-mid-limit : 90% of max nbr of routes BGP can learn from a peer is reached - isis-adjacency-down : isis adjacency is down - isis-adjacency-reject : isis adjacency is rejected - isis-instance-down : isis instance is down or not - ospf-lsa-limit : limit of received LSA's is reached - ospf-lsa-mid-limit : 90% of limit of received LSA's is reached - ospf-neighbor-down : OSPF neighbour is down - ospf-instance-down : OSPF instance is down or not - ospf3-lsa-limit : limit of received OSPFv3 LSAs is reached - ospf3-lsa-mid-limit : 90% of limit of received OSPFv3 LSAs is reached - ospf3-neighbor-down : OSPFv3 neighbour is down - ospf3-instance-down : OSPFv3 instance is down or not - rip-instance-down : rip instance down - lag-down : lag down - lagsubgrp-thresh-reach: lag subgroup threshold reached - lagsubgrp-switch-fail : lag subgroup switchover failed - no-unpinned-free-ports: No free ports available for unpinned traffic - general-arp-limit : arp limit exceeded - gen-switch-out-of-res : failure due to lack of resources on switch - ipv6-nc-limit : ipv6 neighbor cache limit exceeded - dhcp-session-oor : dhcp session out of resources - ihub-fdb-limit : layer 2 fdb limit reached - ihub-mac-limit : layer 2 mac limit reached - l2fw-stp-exception : STP exception condition is present in the SAP - l2fw-stp-root-guard : STP root guard violation is present - vprn-routes-limit : limit of ip is reached - vprn-ipv6-routes-limit: limit of ipv6 is reached - dhcpv6-lease-limit : limit of dhcpv6 leases is reached - dhcpv4-lease-limit : limit of dhcpv4 leases is reached - vpls-mfib-limit : limit of fib table is reached - ihub-ipv6-dad-own : duplicate IPV6 address is detected for IP address allotted to system - ihub-ipv6-dad : duplicate IPV6 address is detected for a user's IP address - ihub-ipv6-dup-pd-route: ipv6 duplicate pd detected - vpls-duplicate-mac : duplicate mac address is detected - vpls-fdb-limit : limit of fdb table is reached - vpls-self-dup-mac : duplicate of a system owned mac address detected on a sap - vpls-sdp-self-dup-mac : duplicate of a system owned mac	

100 Alarm Delta Log Status Commands

name	Type	Description
	address detected on a sdp binding - link-down : link is down - link-lagport-add-fail : failure to add port to LAG - link-conf-mismatch : SFP+plugin-types does not match the planned speed and/or auto-negotiation for the port - ihub-peer-comm : ihub peer to peer communication failure - ihub-sw-fail : IHUB s/w error - ihub-hw-fail : IHUB h/w error - ihub-link-fail : IHUB link failure - ihub-proc-overload : IHUB processor exceeded - ihub-out-of-mem : IHUB processor out of memory - ntp-comm-lost : No response is received from the NTP servers - ldp-instance-down : ldp instance down - ldp-session-down : ldp session down - mpls-instance-down : mpls instance down - mpls-lsp-down : lsp down - mpls-lsp-path-down : lsp path down - sdp-instance-down : sdp instance down - sdp-binding-down : sdp binding down - epipe-instance-down : epipe instance down - lldpmed-portcfg-mis : config request failure for lldpmed portconfig - lldpmed-mediapl-mis : config request failure for lldpmed mediapolicy - vlanport-svc-mismatch : config request failure for the provisioned vlanport - mcsrc-stream-lost : multicast video stream lost - eqptsupl-syslog-upload: upload of log file to remote server failure - eqptsupl-ontsw-dnload : ont sw download in progress - cf-75%used : Compact flash exceeds 75% of life expectancy - cf-90%used : Compact flash exceeds 90% of life expectancy - olt-gen-pon-com-fail : pon communication failure on olt - olt-gen-tx-fail : transmitter failure on olt - olt-gen-unprov-ont : unprovisioned ont on pon - olt-gen-pon-eqpt-prov : mismatch btw equipment and provisioning pon attributes - olt-gen-pon-loss-sig : pon loss of signal - olt-gen-pon-diagnostic: pon diagnostic test active - olt-gen-loid-conflict : loid conflict ont on pon - olt-gen-loid-pwderr : loid password error ont on pon - olt-gen-pon-alien-test: pon alien diagnostic test active - olt-gen-alien-detect : pon alien detect active - olt-gen-rng-mism : pon ranging mismatch active - olt-gen-sfp-mism : pon sfp mismatch active - olt-gen-deact-hightca : deactivated ont hightca threshold crossed - olt-gen-deact-lowtca : deactivated ont lowtca threshold crossed - olt-gen-dp-integ : pon data path integriy failure - olt-gen-ddr-fault : pon failure due to ddr fault - olt-pon-tc-err-frag-tc: pon errored fragments threshold crossed - olt-ont-tc-err-frag-tc: ont errored fragments threshold	

name	Type	Description
	crossed - ont-ploam-loss-sig : loss of signal at ont - ont-ploam-loss-ack : loss of acknowledge from ont - ont-ploam-loss-cd : loss of channel delineation of ont - ont-ploam-phy-eqpt-err: physical equipment error of ont - ont-ploam-startup-fail: startup failure in ranging of ont - ont-ploam-sig-degrade : signal degrade from ont - ont-ploam-disabled : ont disabled alarm - ont-ploam-err-msg : error message from ont - ont-ploam-inactive : inactive ont - ont-ploam-sig-fail : signal fail alarm from ont - ont-ploam-dying-gasp : dying gasp alarm from ont - ont-ploam-deact-fail : deactive failure of ont - ont-ploam-oam : loss of ploam for ont - ont-ploam-win-drift : drift of window alarm - ont-ploam-rdi : remote defect indication alarm - ont-ploam-loss-ks : loss of key synchronization alarm - ont-ploam-pwr-burst : power bursts on ont - ont-ploam-rog-disa : ont rogue disabled - ont-ploam-diff-reach : ont differential reach exceeded - ont-ploam-looc : Loss of OMCI channel due to persistent MIC failure - sfu-ploam-loss-sig : SFU ONT - loss of signal at ont - sfu-ploam-loss-ack : SFU ONT - loss of acknowledge from ont - sfu-ploam-loss-cd : SFU ONT - loss of channel delineation of ont - sfu-ploam-phy-eqpt-err: SFU ONT - physical equipment error of ont - sfu-ploam-startup-fail: SFU ONT - startup failure in ranging of ont - sfu-ploam-sig-degrade : SFU ONT - signal degrade from ont - sfu-ploam-disabled : SFU ONT - ont disabled alarm - sfu-ploam-err-msg : SFU ONT - error message from ont - sfu-ploam-inactive : SFU ONT - inactive ont - sfu-ploam-sig-fail : SFU ONT - signal fail alarm from ont - sfu-ploam-dying-gasp : SFU ONT - dying gasp alarm from ont - sfu-ploam-deact-fail : SFU ONT - deactive failure of ont - sfu-ploam-oam : SFU ONT - loss of ploam for ont - sfu-ploam-win-drift : SFU ONT - drift of window alarm - sfu-ploam-rdi : SFU ONT - remote defect indication alarm - sfu-ploam-loss-ks : SFU ONT - loss of key synchronization alarm - sfu-ploam-pwr-burst : SFU ONT - power bursts on ont - sfu-ploam-rog-disa : SFU ONT - ont rogue disabled - sfu-ploam-diff-reach : SFU ONT - ont differential reach exceeded - sfu-ploam-looc : SFU ONT - Loss of OMCI channel due to persistent MIC failure - soho-ploam-loss-sig : SOHO ONT - loss of signal at ont - soho-ploam-loss-ack : SOHO ONT - loss of acknowledge from ont - soho-ploam-loss-cd : SOHO ONT - loss of channel delineation of ont - soho-ploam-phy-eqpt-er: SOHO ONT - physical	

100 Alarm Delta Log Status Commands

name	Type	Description
	equipment error of ont - soho-ploam-startup-fai: SOHO ONT - startup failure in ranging of ont - soho-ploam-sig-degrade: SOHO ONT - signal degrade from ont - soho-ploam-disabled : SOHO ONT - ont disabled alarm - soho-ploam-err-msg : SOHO ONT - error message from ont - soho-ploam-inactive : SOHO ONT - inactive ont - soho-ploam-sig-fail : SOHO ONT - signal fail alarm from ont - soho-ploam-dying-gasp : SOHO ONT - dying gasp alarm from ont - soho-ploam-deact-fail : SOHO ONT - deactive failure of ont - soho-ploam-oam : SOHO ONT - loss of ploam for ont - soho-ploam-win-drift : SOHO ONT - drift of window alarm - soho-ploam-rdi : SOHO ONT - remote defect indication alarm - soho-ploam-loss-ks : SOHO ONT - loss of key synchronization alarm - soho-ploam-pwr-burst : SOHO ONT - power bursts on ont - soho-ploam-rog-disa : SOHO ONT - ont rogue disabled - soho-ploam-diff-reach : SOHO ONT - ont differential reach exceeded - soho-ploam-looc : SOHO ONT - Loss of OMCI channel due to persistent MIC failure - mdu-ploam-loss-sig : MDU ONT - loss of signal at ont - mdu-ploam-loss-ack : MDU ONT - loss of acknowledge from ont - mdu-ploam-loss-cd : MDU ONT - loss of channel delineation of ont - mdu-ploam-phy-eqpt-err: MDU ONT - physical equipment error of ont - mdu-ploam-startup-fail: MDU ONT - startup failure in ranging of ont - mdu-ploam-sig-degrade : MDU ONT - signal degrade from ont - mdu-ploam-disabled : MDU ONT - ont disabled alarm - mdu-ploam-err-msg : MDU ONT - error message from ont - mdu-ploam-inactive : MDU ONT - inactive ont - mdu-ploam-sig-fail : MDU ONT - signal fail alarm from ont - mdu-ploam-dying-gasp : MDU ONT - dying gasp alarm from ont - mdu-ploam-deact-fail : MDU ONT - deactive failure of ont - mdu-ploam-oam : MDU ONT - loss of ploam for ont - mdu-ploam-win-drift : MDU ONT - drift of window alarm - mdu-ploam-rdi : MDU ONT - remote defect indication alarm - mdu-ploam-loss-ks : MDU ONT - loss of key synchronization alarm - mdu-ploam-pwr-burst : MDU ONT - power bursts on ont - mdu-ploam-rog-disa : MDU ONT - ont rogue disabled - mdu-ploam-diff-reach : MDU ONT - ont differential reach exceeded	

name	Type	Description
	- mdu-ploam-looc : MDU ONT - Loss of OMCI channel due to persistent MIC failure - ont-hpna-ser-mis : hpna ont service mismatch - ont-hpna-los-sig : hpna loss of link - ont-moca-svc-mis : moca ont service mismatch - ont-moca-link-los : moca loss of link - ont-moca-min-bw : moca bw between nodes less than minimum bw - ont-moca-tca-rx-err-fr: moca rx errored frames threshold crossed - ont-sipa-reg-nm-fail : sipua registration name failed - ont-sipa-reg-rec-fail : sipua register reach failed - ont-sipa-reg-con-fail : sipua register connect failed - ont-sipa-reg-val-fail : sipua register validation failed - ont-sipa-reg-mis : sipua register mismatch - ont-vcd-cfg-nm-fail : vcd config name failed - ont-vcd-cfg-rech-fail : vcd config reach failed - ont-vcd-cfg-conn-fail : vcd config connect failed - ont-vcd-cfg-vali-fail : vcd config validation failed - ont-vcd-cfg-auth-fail : vcd config authentication failed - ont-vcd-cfg-resp-tmout: vcd config response timeout - ont-vcd-cfg-resp-err : vcd config response error - ont-vcd-cfg-file-err : vcd config file error - ont-vcd-sub-nm-fail : vcd subscription name failed - ont-vcd-sub-rech-fail : vcd subscription reach failed - ont-vcd-sub-conn-fail : vcd subscription connect failed - ont-vcd-sub-vali-fail : vcd subscription validation failed - ont-vcd-sub-auth-fail : vcd subscription authentication failed - ont-vcd-sub-resp-tmout: vcd subscription response timeout - ont-vcd-sub-resp-err : vcd subscription response error - ont-vcd-reb-requ : vcd reboot request - ont-vcd-mis : vcd mismatch - ont-mgc-mis : ont mgc mismatch - ont-mgc-timeout : ont mgc timeout - ont-sip-reg-dns : ont services pots sip registration failed (resolving domain name) - ont-sip-reg-fail : ont services pots sip registration authentication failed - ont-sip-reg-timeout : ont services pots sip registration timeout - ont-sip-reg-err-resps : ont services pots sip registration response error - ont-sip-inv-dns : ont services pots sip invitation failed (resolving domain name) - ont-sip-inv-auth : ont services pots sip invitation authentication failed - ont-sip-inv-timeout : ont services pots sip invitation timeout - ont-sip-inv-err : ont services pots sip invitation response error - ont-svc-pots-subs-refr: ont services pots iconfig subscription could not be refreshed - ont-svc-pots-not-refr : ont services pots iconfig notification could not be refreshed - ont-svc-pots-icfg-err : ont services pots service failed due to an unmapped iconfig error	

100 Alarm Delta Log Status Commands

name	Type	Description
	- ont-veip-mismatch : ont veip mismatch - ont-ip-host-mismatch : ont ip host mismatch - ont-ip-host-file : ont ip host file unavailable - ont-ip-host-ip-alloc : ont ip host IP allocation failure - olt-pon-up-bw-tca : OLT PON upstream bandwidth TCA - olt-pon-down-bw-tca : OLT PON downstream bandwidth TCA - ont-gen-omci-fail : loss of communication - ont-gen-eqpt-selftest : ont self-test failure - ont-gen-ac-pwr-fail : ac power failure on ont - ont-gen-bat-missing : battery missing - ont-gen-bat-low : battery low - ont-gen-bat-fail : battery failure - ont-gen-phys-intrusion: physical intrusion - ont-gen-sw-dnload-f : ont sw download failure - ont-gen-sw-dnload-p : ont sw download in progress - ont-gen-sw-act-fail : ont sw activation failure - ont-gen-eqpt-vers-mis : ont equipment version mismatch - ont-gen-sw-vers-mis : ont sw version mismatch - ont-gen-us-rate-mis : ont upstream rate mismatch - ont-gen-mdv-env1 : mdu environmental alarm#1 - ont-gen-mdv-env2 : mdu environmental alarm#2 - ont-gen-mdv-env3 : mdu environmental alarm#3 - ont-gen-nw-time-err : network timing protocol error - ont-gen-opt-sig-high : optical signal level too high - ont-gen-opt-sig-low : optical signal level too low - ont-gen-eqpt-prov-sa : service affecting mismatch btw equipment and provisioning attributes - ont-gen-eqpt-prov-nsa : non service affecting mismatch btw equipment and provisioning attributes - pon-t-txmcutilhi : pon utilization tx (downstream) multicast high threshold crossed - pon-t-txmcutilmd : pon utilization tx (downstream) multicast medium threshold crossed - pon-t-txmcutillo : pon utilization tx (downstream) multicast low threshold crossed - pon-t-txtotutilhi : pon utilization tx (downstream) total high threshold crossed - pon-t-txtotutilmd : pon utilization tx (downstream) total medium threshold crossed - pon-t-txtotutillo : pon utilization tx (downstream) total low threshold crossed - pon-t-rxtotutilhi : pon utilization rx (upstream) total high threshold crossed - pon-t-rxtotutilmd : pon utilization rx (upstream) total medium threshold crossed - pon-t-rxtotutillo : pon utilization rx (upstream) total low threshold crossed - pon-t-dbacongperiodhi : pon utilization rx (upstream) dbacongperiod high threshold crossed - pon-t-dbacongperiodmd : pon utilization rx (upstream) dbacongperiod medium threshold crossed - pon-t-dbacongperiodlo : pon utilization rx (upstream) dbacongperiod low threshold crossed - pon-t-txucdropfrmhi : pon utilization tx (downstream) unicast drop frame high threshold crossed - pon-t-txucdropfrmd : pon utilization tx (downstream)	

name	Type	Description
	unicast drop frame medium threshold crossed - pon-t-txucdropfrmlo : pon utilization tx (downstream) unicast drop frame low threshold crossed - pon-t-txmcdropfrmhi : pon utilization tx (downstream) multicast drop frame high threshold crossed - pon-t-txmcdropfrmmd : pon utilization tx (downstream) multicast drop frame medium threshold crossed - pon-t-txmcdropfrmlo : pon utilization tx (downstream) multicast drop frame low threshold crossed - pon-t-txbcdropfrmhi : pon utilization tx (downstream) broadcast drop frame high threshold crossed - pon-t-txbcdropfrmmd : pon utilization tx (downstream) broadcast drop frame medium threshold crossed - pon-t-txbcdropfrmlo : pon utilization tx (downstream) broadcast drop frame low threshold crossed - pon-t-rxtotdropfrmhi : pon utilization rx (upstream) total drop frame high threshold crossed - pon-t-rxtotdropfrmmd : pon utilization rx (upstream) total drop frame medium threshold crossed - pon-t-rxtotdropfrmlo : pon utilization rx (upstream) total drop frame low threshold crossed - chpr-t-txmcutilhi : channel-pair utilization tx (downstream) multicast high threshold crossed - chpr-t-txmcutilmd : channel-pair utilization tx (downstream) multicast medium threshold crossed - chpr-t-txmcutillo : channel-pair utilization tx (downstream) multicast low threshold crossed - chpr-t-txtotutilhi : channel-pair utilization tx (downstream) total high threshold crossed - chpr-t-txtotutilmd : channel-pair utilization tx (downstream) total medium threshold crossed - chpr-t-txtotutillo : channel-pair utilization tx (downstream) total low threshold crossed - chpr-t-rxtotutilhi : channel-pair utilization rx (upstream) total high threshold crossed - chpr-t-rxtotutilmd : channel-pair utilization rx (upstream) total medium threshold crossed - chpr-t-rxtotutillo : channel-pair utilization rx (upstream) total low threshold crossed - chpr-t-dbacongperiodhi: channel-pair utilization rx (upstream) dbacongperiod high threshold crossed - chpr-t-dbacongperiodmd: channel-pair utilization rx (upstream) dbacongperiod medium threshold crossed - chpr-t-dbacongperiodlo: channel-pair utilization rx (upstream) dbacongperiod low threshold crossed - chpr-t-txucdropfrmhi : channel-pair utilization tx (downstream) unicast drop frame high threshold crossed - chpr-t-txucdropfrmmd : channel-pair utilization tx (downstream) unicast drop frame medium threshold crossed - chpr-t-txucdropfrmlo : channel-pair utilization tx (downstream) unicast drop frame low threshold crossed - chpr-t-txmcdropfrmhi : channel-pair utilization tx (downstream) multicast drop frame high threshold crossed - chpr-t-txmcdropfrmmd : channel-pair utilization tx (downstream) multicast drop frame medium threshold crossed - chpr-t-txmcdropfrmlo : channel-pair utilization tx	

100 Alarm Delta Log Status Commands

name	Type	Description
	(downstream) multicast drop frame low threshold crossed - chpr-t-txbcdropfrmhi : channel-pair utilization tx (downstream) broadcast drop frame high threshold crossed - chpr-t-txbcdropfrmmd : channel-pair utilization tx (downstream) broadcast drop frame medium threshold crossed - chpr-t-txbcdropfrmlo : channel-pair utilization tx (downstream) broadcast drop frame low threshold crossed - chpr-t-rxtotdropfrmhi : channel-pair utilization rx (upstream) total drop frame high threshold crossed - chpr-t-rxtotdropfrmmd : channel-pair utilization rx (upstream) total drop frame medium threshold crossed - chpr-t-rxtotdropfrmlo : channel-pair utilization rx (upstream) total drop frame low threshold crossed - sfu-gen-omci-fail : SFU ONT - loss of communication - sfu-gen-eqpt-selftest : SFU ONT - ont self-test failure - sfu-gen-ac-pwr-fail : SFU ONT - ac power failure on ont - sfu-gen-bat-missing : SFU ONT - battery missing - sfu-gen-bat-low : SFU ONT - battery low - sfu-gen-bat-fail : SFU ONT - battery failure - sfu-gen-sw-dnload-f : SFU ONT - ont sw download failure - sfu-gen-sw-dnload-p : SFU ONT - ont sw download in progress - sfu-gen-sw-act-fail : SFU ONT - ont sw activation failure - sfu-gen-eqpt-vers-mis : SFU ONT - ont equipment version mismatch - sfu-gen-sw-vers-mis : SFU ONT - ont sw version mismatch - sfu-gen-us-rate-mis : SFU ONT - ont upstream rate mismatch - sfu-gen-tune-fail : SFU ONT - ont has failed to tune to Target-ChnlPair - sfu-gen-nw-time-err : SFU ONT - network timing protocol error - sfu-gen-opt-sig-high : SFU ONT - optical signal level too high - sfu-gen-opt-sig-low : SFU ONT - optical signal level too low - sfu-gen-eqpt-prov-sa : SFU ONT - service affecting mismatch btw equipment and provisioning attributes - sfu-gen-eqpt-prov-nsa : SFU ONT - non service affecting mismatch btw equipment and provisioning attributes - soho-gen-omci-fail : SOHO ONT - loss of communication - soho-gen-eqpt-selftest : SOHO ONT - ont self-test failure - soho-gen-ac-pwr-fail : SOHO ONT - ac power failure on ont - soho-gen-bat-missing : SOHO ONT - battery missing - soho-gen-bat-low : SOHO ONT - battery low - soho-gen-bat-fail : SOHO ONT - battery failure - soho-gen-sw-dnload-f : SOHO ONT - ont sw download failure - soho-gen-sw-dnload-p : SOHO ONT - ont sw download in progress - soho-gen-sw-act-fail : SOHO ONT - ont sw activation failure - soho-gen-eqpt-vers-mis : SOHO ONT - ont equipment version mismatch	

name	Type	Description
	- soho-gen-sw-vers-mis : SOHO ONT - ont sw version mismatch - soho-gen-us-rate-mis : SOHO ONT - ont upstream rate mismatch - soho-gen-tune-fail : SOHO ONT - ont has failed to tune to Target-ChnlPair - soho-gen-nw-time-err : SOHO ONT - network timing protocol error - soho-gen-opt-sig-high : SOHO ONT - optical signal level too high - soho-gen-opt-sig-low : SOHO ONT - optical signal level too low - soho-gen-eqpt-prov-sa : SOHO ONT - service affecting mismatch btw equipment and provisioning attributes - soho-gen-eqpt-prov-nsa: SOHO ONT - non service affecting mismatch btw equipment and provisioning attributes - mdu-gen-omci-fail : MDU ONT - loss of communication - mdu-gen-eqpt-selftest : MDU ONT - ont self-test failure - mdu-gen-ac-pwr-fail : MDU ONT - ac power failure on ont - mdu-gen-bat-missing : MDU ONT - battery missing - mdu-gen-bat-low : MDU ONT - battery low - mdu-gen-bat-fail : MDU ONT - battery failure - mdu-gen-phys-intrusion: MDU ONT - physical intrusion - mdu-gen-sw-dnload-f : MDU ONT - ont sw download failure - mdu-gen-sw-dnload-p : MDU ONT - ont sw download in progress - mdu-gen-sw-act-fail : MDU ONT - ont sw activation failure - mdu-gen-eqpt-vers-mis : MDU ONT - ont equipment version mismatch - mdu-gen-sw-vers-mis : MDU ONT - ont sw version mismatch - mdu-gen-us-rate-mis : MDU ONT - ont upstream rate mismatch - mdu-gen-tune-fail : MDU ONT - ont has failed to tune to Target-ChnlPair - mdu-gen-mdu-env1 : MDU ONT - mdu environmental alarm#1 - mdu-gen-mdu-env2 : MDU ONT - mdu environmental alarm#2 - mdu-gen-mdu-env3 : MDU ONT - mdu environmental alarm#3 - mdu-gen-nw-time-err : MDU ONT - network timing protocol error - mdu-gen-opt-sig-high : MDU ONT - optical signal level too high - mdu-gen-opt-sig-low : MDU ONT - optical signal level too low - mdu-gen-eqpt-prov-sa : MDU ONT - service affecting mismatch btw equipment and provisioning attributes - mdu-gen-eqpt-prov-nsa : MDU ONT - non service affecting mismatch btw equipment and provisioning attributes - ont-gen-sw-dnload-file: ont sw download file missing	

100 Alarm Delta Log Status Commands

name	Type	Description
	- ont-gen-fan-fail : ont fan failure - ont-gen-high-temp : ont high temperature - ont-gen-high-temp-ex : ont excessive high temperature - ont-gen-emergency-call: ont emergency call - ont-gen-sw-version : ont sw version control error - ont-poe-exceed-max : ont poe exceed max - ont-poe-overload-yell : ONU is nearing its maximum ability to supply the power - ont-opti-malfunc : malfunction of ONT's optical transceiver - ont-gen-cfgdld-fail : download of voice xml file to ont failed - ont-gen-rssi-mis : ONU RSSI configuration mismatch - ont-gen-tx-pwr-low : ONU SFP Tx Power is lower than configured Alarm low threshold - ont-gen-temp-high : ONU SFP Temperature is higher than configured Alarm high threshold - ont-gen-volt-high : ONU SFP Voltage is higher than configured Alarm high threshold - ont-gen-bias-high : ONU SFP Bias is higher than configured Alarm high threshold - ont-loopdetect-mis : ont loop detect mismatch - ont-olt-rx-pw-lo : olt side receive power from ont low - ont-olt-rx-pw-hig : olt side receive power from ont high - ont-olt-rx-pw-warnlo : olt side receive power from ont low warning - ont-olt-rx-pw-warnhig : olt side receive power from ont high warning - ont-gen-tod-out-sync : ONU TOD is out-sync with OLT - ont-gen-tune-fail : ONU has failed to tune to Target-ChnlPair - hgu-tr069-param-fail : hgu tr069 parameters mismatch - ont-gen-tod-mismatch : ONU TOD MISMATCH - sfu-sup-sw-file-error : SFU ONT - Software file has error or is missing - sfu-sup-fan-failure : SFU ONT - Fan failure - sfu-sup-temp-high-warn: SFU ONT - High temperature warning - sfu-sup-temp-shutoff : SFU ONT - Service disabled due to excessive temperature - sfu-sup-emergency-call: SFU ONT - Emergency call active - sfu-sup-swverctrl-err : SFU ONT - Software version control error - sfu-sup-poe-exceed-max: SFU ONT - Configured PoE feeding exceeds ONT maximum - sfu-sup-poe-over-yell : SFU ONT - ONU is nearing its maximum ability to supply the power - sfu-opti-malfunc : SFU ONT - Malfunction of ONT's optical transceiver - sfu-sup-cfg-dnld-fail : SFU ONT - Download of voice xml file to ONT failed - sfu-sup-rssi-cfg-mism : SFU ONT - RSSI configuration mismatch - sfu-sup-sfp-tx-low : SFU ONT - SFP Tx Power below configured low-level alarm threshold - sfu-sup-sfp-temp-high : SFU ONT - SFP Temperature above configured high-level alarm threshold	

name	Type	Description
	- sfu-sup-sfp-volt-high : SFU ONT - SFP Voltage above configured high-level alarm threshold - sfu-sup-sfp-bias-high : SFU ONT - SFP Bias above configured high-level alarm threshold - sfu-sup-ld-cfg-mism : SFU ONT - Loop detection configuration mismatch - sfu-sup-olt-rx-low : SFU ONT - OLT Rx power below receiver operating range - sfu-sup-olt-rx-high : SFU ONT - OLT Rx power above receiver operating range - sfu-sup-olt-rx-lo-warn: SFU ONT - OLT Rx power below low-level warning threshold - sfu-sup-olt-rx-hi-warn: SFU ONT - OLT Rx power above high-level warning threshold - sfu-sup-tod-out-sync : SFU ONT - ONU TOD is out-sync with OLT - sfu-sup-ont-tune-fail : SFU ONT - ONU has failed to tune to Target-ChnlPair - sfu-tr069-param-fail : SFU ONT - hgu tr069 parameters mismatch - sfu-sup-tod-mismatch : SFU ONT - ONU TOD MISMATCH - soho-sup-sw-file-error: SOHO ONT - Software file has error or is missing - soho-sup-fan-failure : SOHO ONT - Fan failure - soho-sup-temp-high-war: SOHO ONT - High temperature warning - soho-sup-temp-shutoff : SOHO ONT - Service disabled due to excessive temperature - soho-sup-emergency-cal: SOHO ONT - Emergency call active - soho-sup-swverctrl-err: SOHO ONT - Software version control error - soho-sup-poe-exceed-ma: SOHO ONT - Configured PoE feeding exceeds ONT maximum - soho-sup-poe-over-yell: SOHO ONT - ONU is nearing its maximum ability to supply the power - soho-opti-malfunc : SOHO ONT - Malfunction of ONT's optical transceiver - soho-sup-cfg-dnld-fail: SOHO ONT - Download of voice xml file to ONT failed - soho-sup-rssi-cfg-mism: SOHO ONT - RSSI configuration mismatch - soho-sup-sfp-tx-low : SOHO ONT - SFP Tx Power below configured low-level alarm threshold - soho-sup-sfp-temp-high: SOHO ONT - SFP Temperature above configured high-level alarm threshold - soho-sup-sfp-volt-high: SOHO ONT - SFP Voltage above configured high-level alarm threshold - soho-sup-sfp-bias-high: SOHO ONT - SFP Bias above configured high-level alarm threshold - soho-sup-ld-cfg-mism : SOHO ONT - Loop detection configuration mismatch - soho-sup-olt-rx-low : SOHO ONT - OLT Rx power below receiver operating range - soho-sup-olt-rx-high : SOHO ONT - OLT Rx power above receiver operating range	

100 Alarm Delta Log Status Commands

name	Type	Description
	- soho-sup-olt-rx-lo-war: SOHO ONT - OLT Rx power below low-level warning threshold - soho-sup-olt-rx-hi-war: SOHO ONT - OLT Rx power above high-level warning threshold - soho-sup-tod-out-sync : SOHO ONT - ONU TOD is out-sync with OLT - soho-sup-ont-tune-fail: SOHO ONT - ONU has failed to tune to Target-ChnlPair - soho-tr069-param-fail : SOHO ONT - hgu tr069 parameters mismatch - soho-sup-tod-mismatch : SOHO ONT - ONU TOD MISMATCH - mdu-sup-sw-file-error : MDU ONT - Software file has error or is missing - mdu-sup-fan-failure : MDU ONT - Fan failure - mdu-sup-temp-high-warn: MDU ONT - High temperature warning - mdu-sup-temp-shutoff : MDU ONT - Service disabled due to excessive temperature - mdu-sup-emergency-call: MDU ONT - Emergency call active - mdu-sup-swverctrl-err : MDU ONT - Software version control error - mdu-sup-poe-exceed-max: MDU ONT - Configured PoE feeding exceeds ONT maximum - mdu-sup-poe-over-yell : MDU ONT - ONU is nearing its maximum ability to supply the power - mdu-opti-malfunc : MDU ONT - Malfunction of ONT's optical transceiver - mdu-sup-cfg-dnld-fail : MDU ONT - Download of voice xml file to ONT failed - mdu-sup-rssi-cfg-mism : MDU ONT - RSSI configuration mismatch - mdu-sup-sfp-tx-low : MDU ONT - SFP Tx Power below configured low-level alarm threshold - mdu-sup-sfp-temp-high : MDU ONT - SFP Temperature above configured high-level alarm threshold - mdu-sup-sfp-volt-high : MDU ONT - SFP Voltage above configured high-level alarm threshold - mdu-sup-sfp-bias-high : MDU ONT - SFP Bias above configured high-level alarm threshold - mdu-sup-ld-cfg-mism : MDU ONT - Loop detection configuration mismatch - mdu-sup-olt-rx-low : MDU ONT - OLT Rx power below receiver operating range - mdu-sup-olt-rx-high : MDU ONT - OLT Rx power above receiver operating range - mdu-sup-olt-rx-lo-warn: MDU ONT - OLT Rx power below low-level warning threshold - mdu-sup-olt-rx-hi-warn: MDU ONT - OLT Rx power above high-level warning threshold - mdu-sup-tod-out-sync : MDU ONT - ONU TOD is out-sync with OLT - mdu-sup-ont-tune-fail : MDU ONT - ONU has failed to tune to Target-ChnlPair - mdu-tr069-param-fail : MDU ONT - hgu tr069 parameters mismatch	

name	Type	Description
	- mdu-sup-tod-mismatch : MDU ONT - ONU TOD MISMATCH - ont-sbscr-lim-missing : provisioned ont card missing - ont-sbscr-lim-type-mis: wrong type plug-in ont card - ont-sbscr-lim-removal : improper removal ont card - ont-sbscr-lim-fail : ont card failure - ont-sbscr-lim-svc-mis : ont service mismatch for provisioned onu card - ont-sbscr-lim-port-mis: port mismatch btw actual and planned ont card - ont-svc-video-conf-mis: config request failure for video service - ont-svc-video-pw-high : high power level for rf video signal - ont-svc-video-pw-low : low power level for rf video signal - ont-svc-pots-svc-mis : ont service mismatch for provisioned pots - ont-svc-pots-rtcp-lost: pots realtime transport control protocol stream lost - ont-svc-pots-icnf-subs: pots line iconfig subscription failure - ont-svc-pots-icnf-ntfy: pots line iconfig notify failure - ont-svc-pots-icnf-http: pots line iconfig http failure - ont-svc-pots-sip-reg : pots line sip registration failure - ont-svc-pots-sip-inv : pots line sip invite request failure - ont-svc-pots-sip-subsc: pots line sip subscribe failure - ont-svc-pots-sip-mt-tc: pots line sip message timeout threshold crossed - ont-svc-pots-pk-los-tc: pots line rtp bearer packets loss threshold crossed - ont-svc-pots-jitter-tc: pots line rtp jitter threshold crossed - ont-svc-pots-subs-dns : pots line iconfig subscription failed (DNS) - ont-svc-pots-subs-tcp : pots line iconfig subscription failed (TCP) - ont-svc-pots-subs-tls : pots line iconfig subscription failed (TLS) - ont-svc-pots-subs-auth: pots line iconfig subscription failed authentication - ont-svc-pots-subs-to : pots line iconfig subscription failed (timeout) - ont-svc-pots-subs-err : pots line iconfig subscription response error - ont-svc-pots-not-to : pots line iconfig notification failed (timeout) - ont-svc-pots-notref-to: pots line iconfig notification refresh failed - ont-svc-pots-not-mal : pots line iconfig notification failed (malformed) - ont-svc-pots-not-rej : pots line iconfig notification rejected - ont-svc-pots-http-dns : pots line iconfig doc retrieval failed (DNS) - ont-svc-pots-http-tcp : pots line iconfig doc retrieval failed (TCP) - ont-svc-pots-http-tls : pots line iconfig doc retrieval failed (TLS) - ont-svc-pots-http-auth: pots line iconfig doc retrieval failed	

100 Alarm Delta Log Status Commands

name	Type	Description
	(authentication) - ont-svc-pots-http-to : pots line iconfig doc retrieval failed (timeout) - ont-svc-pots-http-err : pots line iconfig doc retrieval response error - ont-svc-pots-http-mal : pots line iconfig doc retrieval failed (malformed) - ont-svc-pots-insuff : pots line iconfig service failed (insufficient data) - ont-svc-pots-poos : pots ports out of service - ont-svc-lan-mismatch : ont service mismatch for lan - ont-svc-lan-loss-sig : loss of signal on an ethernet port interface - ont-svc-enet-poos : Ethernet Ports out of Service - ont-svc-ces-ds1-mis : ont service mismatch for provisioned ces ds1 - ont-svc-ces-ds1-los : loss of signal at ds1 interface - ont-svc-ces-ds1-lof : loss of frame at ds1 interface - ont-svc-ces-ds1-rair : receiving rai at ds1 interface - ont-svc-ces-ds1-ais : receiving ais at ds1 interface - ont-svc-ces-ds1-lnlpbk: receiving line loopback at ds1 interface - ont-svc-ces-ds1-tmlpbk: receiving terminal loopback at ds1 interface - ont-svc-ces-e1-mis : ont service mismatch for provisioned ces e1 - ont-svc-ces-e1-los : loss of signal at e1 interface - ont-svc-ces-e1-lof : loss of frame at e1 interface - ont-svc-ces-e1-rair : receiving rai at e1 interface - ont-svc-ces-e1-ais : receiving ais at e1 interface - ont-svc-voip-cnf-file : voice configuration file error - ont-svc-voip-svc-mis : service mismatch for provisioned client service - ont-svc-voip-gw-comm : voice gateway communication failure - ont-svc-voip-dhcp-fail: voice dhcp server failure - ont-svc-voip-icnf-subs: voice iconfig subscription failure - ont-svc-voip-icnf-ntfy: voice iconfig notify failure - ont-svc-voip-icnf-http: voice iconfig http failure - ont-svc-voip-dhcp-to : DHCP server retransmissions timed out - ont-svc-voip-dhcp-mal : DHCP response was malformed - ont-svc-voip-dhcp-noad: DHCP server failed to issue the required parameters - ont-svc-voip-dhcp-leas: DHCP Server failure due to problem in lease renewal - ont-svc-voip-subs-dns : iConfig Subscription failure due to DNS problem - ont-svc-voip-subs-tcp : iConfig Subscription failure due to TCP socket problem - ont-svc-voip-subs-tls : iConfig Subscription failure due to TLS session problem - ont-svc-voip-subs-auth: iConfig Subscription failure due to authentication error - ont-svc-voip-subs-to : iConfig Subscription failure due to retransmission timeout - ont-svc-voip-subs-err : iConfig Subscription failure due to	

name	Type	Description
	response error - ont-svc-voip-not-to : iConfig Notify response timeout for new subscription - ont-svc-voip-notref-to: iConfig Notify response timeout for subscription refresh - ont-svc-voip-not-mal : iConfig Notify response is malformed - ont-svc-voip-not-rej : iConfig subscription request rejected by configuration server - ont-svc-voip-http-dns : VOIP client can't retrieve config doc due to DNS problem - ont-svc-voip-http-tcp : VOIP client can't retrieve config doc due to TCP socket problem - ont-svc-voip-http-tls : VOIP client can't retrieve config doc due to TLS session problem - ont-svc-voip-http-auth: VOIP client can't retrieve config doc due to auth error - ont-svc-voip-http-to : VOIP client can't retrieve config doc due to re-tx timeout - ont-svc-voip-http-err : VOIP client can't retrieve config doc due to response error - ont-svc-voip-http-mal : iConfig configuration document is malformed - ont-svc-voip-subs-refr: iConfig Subscription refresh error - ont-svc-voip-not-refr : iConfig Notify response for refresh subscribe failed - ont-svc-voip-icfg-err : iConfig Configuration Error - ont-svc-v-ani-conf-mis: config request failure for video ani service - ont-svc-v-ani-loss-sig: video loss of signal on ani - ont-svc-v-ani-lv-high : high video optical signal level - ont-svc-v-ani-lv-low : low video optical signal level - ont-svc-pwe-mismatch : service mismatch for provisioned pseudowire - ont-svc-pwe-reordr-lof: pseudowire reordering and loss of frame - ont-svc-pwe-jitt-buf-o: pseudowire jitter buffer overrun - ont-svc-pwe-jitt-buf-u: pseudowire jitter buffer underrun - ont-svc-pwe-malf-frms : pseudowire malformed frames - ont-svc-pwe-late-frms : pseudowire late frames - ont-svc-pwe-link-loss : pseudowire link loss - ont-svc-pwe-arp-fail : pseudowire arp failure - ont-svc-xdsl-mismatch : service mismatch for provisioned xdsl - ont-svc-xdsl-ne-lof : near end loss of frame - ont-svc-xdsl-ne-los : near end loss of signal - ont-svc-xdsl-ne-line : near end line init - ont-svc-xdsl-ne-lol : near end loss of link - ont-svc-xdsl-fe-lof : far end loss of frame - ont-svc-xdsl-fe-los : far end loss of signal - ont-svc-xdsl-fe-lop : far end loss of power - ont-svc-xdsl-cnf-err : xdsl provisioning error - ont-svc-xdsl-ne-es-tc : near end errored seconds threshold crossed - ont-svc-xdsl-ne-ses-tc: near end severe errored seconds threshold crossed - ont-svc-xdsl-ne-uas-tc: ear end unavailable seconds	

100 Alarm Delta Log Status Commands

name	Type	Description
	threshold crossed - ont-svc-xdsl-fe-es-tc : far end errored seconds threshold crossed - ont-svc-xdsl-fe-ses-tc: far end severe errored seconds threshold crossed - ont-svc-xdsl-fe-uas-tc: far end unavailable seconds threshold crossed - ont-tc-rx-los-frag-tc : rx loss of gem fragments threshold crossed - ont-tc-tx-los-frag-tc : tx loss of gem fragments threshold crossed - ont-tc-bad-gem-hd-tc : bad gem header threshold crossed - ont-uni-ds-drpdp-fr-tc : downstream l2 dropped frames threshold crossed - ont-uni-up-drpdp-fr-tc : upstream l2 dropped frames threshold crossed - ont-uni-ds-crc-fr-tc : downstream l2 rx crc error frames threshold crossed - ont-uni-up-crc-fr-tc : upstream l2 rx crc error frames threshold crossed - ont-cpu-util-tca : ONT CPU utilization threshold crossed - ont-mem-util-tca : ONT memory utilization threshold crossed - pim-neighbor-down : pim neighbor down - pim-max-mcroutes : maximum routes reached - li-traffic-disabled : lawful interception of traffic disabled - li-bandwidth-limit : lawful intercept reached bandwidth limit - li-out-of-res : lawful intercept out of resources - otdr-cap-mismatch : otdr capability mismatch - login-successful : successful login via management access - login-failure : invalid login via management access has crossed the threshold limit - cfm-defrdiccm : rdi bit in ccm received - cfm-defmacstatus : ccm mac error status - cfm-defremoteccm : missing ccm from mep - cfm-deferrorccm : invalid ccm received - cfm-defxconccm : unexpected ccm received - cfm-defais : ethernet ais received - bfd-session-down : bfd session down - bfd-max-resource : bfd maximum resources reached - bfd-stale-entry : bfd stale entry present - tca-outputbw : tca output bandwidth - tca-inputbw : tca input bandwidth - tca-rxcrcalign : tca rxrc align errors - tca-txcrcalign : tca txrc align errors - tca-txcollisions : tca tx collision errors - tca-outputhighbw : tca output high bandwidth - tca-outputmedbw : tca output medium bandwidth - tca-outputlowbw : tca output low bandwidth - tca-inputhighbw : tca input high bandwidth - tca-inputmediumbw : tca input medium bandwidth - tca-inputlowbw : tca input low bandwidth - eth-cfm-defrdiccm : rdi bit in ccm received - eth-cfm-defmacstatus : ccm mac error status - eth-cfm-defremoteccm : missing ccm from mep - eth-cfm-deferrorccm : invalid ccm received	

name	Type	Description
	- eth-cfm-defxconccm : unexpected ccm received - rsvp-neighbor-down : rsvp neighbor down - rsvp-instance-down : rsvp instance down - eth-ring-path-block : eth ring path block - ai-platform-down : Application Intelligence Platform down - ai-appl-install-fail : Application installation failure - ip-assign-fail : Dhcp assigned address failure - ont-tr069-serv-mis : ont tr069 server config mismatch - ont-snmp-mis : ont snmp agent config mismatch - bsf-dhcpv4 : bulksync failed for dhcpv4 - bsf-dhcpv6 : bulksync failed for dhcpv6 - bsf-pon : bulksync failed for pon - bsf-vbridge : bulksync failed for vlan-bridge - bsf-qos : bulksync failed for qos - bsf-igmp : bulksync failed for igmp - bsf-lxfwd : bulksync failed for lxfwd - prot-not-available : no protection not available - prot-switchover-fail : port switch over failed - efm-oam-cpelinkfault : EFM-OAM CPE link fault - efm-oam-cpedyinggasp : EFM-OAM CPE dying gasp - efm-oam-cpecrevt : EFM-OAM CPE critical event - ont-loopdetect : ont loop detect - alm-tbl-overflow : alarm table has overflowed - auto-switch-status : auto-switch status - auswqueuefullatm : auto-switch queue Full for ATM - auswbkpfailatm : auto-switch config data backup failed for ATM - auswrecfgfailatm : auto-switch fallback reconfiguration failed for ATM - auswdataunatm : auto-switch backup config data unavailable for ATM - auswqueuefulptm : auto-switch queue Full for PTM - auswbkpfailptm : auto-switch config data backup failed for PTM - auswrecfgfailptm : auto-switch fallback reconfiguration failed for PTM - auswdataunptm : auto-switch backup config data unavailable for PTM - auswbakpfailatm : auto-switch backup fail for ATM - chpr-com-fail : channel pair communication failure on olt - chpr-tx-fail : transmitter failure on channel pair - chpr-unprov-ont : unprovisioned ont on channel pair - chpr-prov-mismatch : mismatch btw equipment and provisioning pon attributes - chpr-loss-sig : channel pair loss of signal - chpr-diagnostic : channel pair diagnostic test active - chpr-loid-conflict : loid conflict ont on channel pair - chpr-loid-pwd-err : loid password error ont on channel pair - chpr-stk-laser-dis : stuck laser disabled on channel pair - chpr-sfp-mismatch : channel pair sfp mismatch - chpr-rng-mismatch : channel pair ranging mismatch - chpr-alien-test : channel pair alien diagnostic test active - chpr-alien-detect : channel pair alien detect active - chpr-deact-hightca : channel pair deactivated ont hightca threshold crossed - chpr-deact-lowtca : channel pair deactivated ont lowtca threshold crossed	

100 Alarm Delta Log Status Commands

name	Type	Description
	- chpr-dp-integ : channel pair data path integrity failure - olt-chpr-tc-err-frag : channelpair errored fragments threshold crossed - olt-chpr-up-bw-tca : OLT CHANNELPAIR upstream bandwidth TCA - olt-chpr-down-bw-tca : OLT CHANNELPAIR downstream bandwidth TCA - cfg-dld-fail : download of configure file to ont failed - cfg-act-fail : activate the passive config file failed - cfg-dld-ip : ont configure file download in progress - cfg-ver-mismatch : the planned configure file does not match the active configure file - cfg-file-missing : ont configure file missing or has an error - cfg-verctrl-err : ont configure file version control error - cfg-not-supported : ont not support the configure file download function - ont-prot-not-available: ONT/ONU protection not available - ont-gen-temp-low : ONU SFP temperature is lower than configured Alarm low threshold - ont-gen-volt-low : ONU SFP Voltage is lower than configured Alarm low threshold - ont-gen-tx-pwr-high : ONU SFP Tx power is higher than configured Alarm high threshold - ont-gen-bias-low : ONU SFP bias is lower than configured Alarm low threshold - ont-gen-rx-hwarn : ONU SFP Rx power is higher than warn threshold - ont-gen-rx-lwarn : ONU SFP Rx power is lower than warn threshold - ont-gen-tx-hwarn : ONU SFP Tx power is higher than warn threshold - ont-gen-tx-lwarn : ONU SFP Tx power is lower than warn threshold - ont-gen-temp-hwarn : ONU SFP temperature is higher than warn threshold - ont-gen-temp-lwarn : ONU SFP temperature is lower than warn threshold - ont-gen-volt-hwarn : ONU SFP Voltage is higher than warn threshold - ont-gen-volt-lwarn : ONU SFP Voltage is lower than warn threshold - ont-gen-bias-hwarn : ONU SFP bias is higher than warn threshold - ont-gen-bias-lwarn : ONU SFP bias is lower than warn threshold - sfu-sup2-temp-low : SFU ONT - SFP temperature is lower than configured Alarm low threshold - sfu-sup2-volt-low : SFU ONT - SFP Voltage is lower than configured Alarm low threshold - sfu-sup2-tx-high : SFU ONT - SFP tx power is higher than configured Alarm high threshold - sfu-sup2-bias-low : SFU ONT - SFP bias is lower than configured Alarm low threshold - sfu-sup2-rx-hwarn : SFU ONT - SFP rx power is higher than configured warn threshold - sfu-sup2-rx-lwarn : SFU ONT - SFP rx power is lower than configured warn threshold	

name	Type	Description
	- sfu-sup2-tx-hwarn : SFU ONT - SFP tx power is higher than configured warn threshold - sfu-sup2-tx-lwarn : SFU ONT - SFP tx power is lower than configured warn threshold - sfu-sup2-temp-hwarn : SFU ONT - SFP temperature is higher than configured warn threshold - sfu-sup2-temp-lwarn : SFU ONT - SFP temperature is lower than configured warn threshold - sfu-sup2-volt-hwarn : SFU ONT - SFP Voltage is higher than configured warn threshold - sfu-sup2-volt-lwarn : SFU ONT - SFP Voltage is lower than configured warn threshold - sfu-sup2-bias-hwarn : SFU ONT - SFP bias is higher than configured warn threshold - sfu-sup2-bias-lwarn : SFU ONT - SFP bias is lower than configured warn threshold - soho-sup2-temp-low : SOHO ONT - SFP temperature is lower than configured Alarm low threshold - soho-sup2-volt-low : SOHO ONT - SFP Voltage is lower than configured Alarm low threshold - soho-sup2-tx-high : SOHO ONT - SFP tx power is higher than configured Alarm low threshold - soho-sup2-bias-low : SOHO ONT - SFP bias is lower than configured Alarm low threshold - soho-sup2-rx-hwarn : SOHO ONT - SFP rx power is higher than warn threshold - soho-sup2-rx-lwarn : SOHO ONT - SFP rx power is lower than warn threshold - soho-sup2-tx-hwarn : SOHO ONT - SFP tx power is higher than warn threshold - soho-sup2-tx-lwarn : SOHO ONT - SFP tx power is lower than warn threshold - soho-sup2-temp-hwarn : SOHO ONT - SFP temperature is higher than warn threshold - soho-sup2-temp-lwarn : SOHO ONT - SFP temperature is lower than warn threshold - soho-sup2-volt-hwarn : SOHO ONT - SFP Voltage is higher than warn threshold - soho-sup2-volt-lwarn : SOHO ONT - SFP Voltage is lower than warn threshold - soho-sup2-bias-hwarn : SOHO ONT - SFP bias is higher than warn threshold - soho-sup2-bias-lwarn : SOHO ONT - SFP bias is lower than warn threshold - mdu-sup2-temp-low : MDU ONT - SFP temperature is lower than configured alarm low threshold - mdu-sup2-volt-low : MDU ONT - SFP Voltage is lower than configured alarm low threshold - mdu-sup2-tx-high : MDU ONT - SFP tx power is higher than configured alarm low threshold - mdu-sup2-bias-low : MDU ONT - SFP bias is lower than configured alarm low threshold - mdu-sup2-rx-hwarn : MDU ONT - SFP rx power is higher than warn threshold - mdu-sup2-rx-lwarn : MDU ONT - SFP rx power is lower than warn threshold - mdu-sup2-tx-hwarn : MDU ONT - SFP tx power is higher	

100 Alarm Delta Log Status Commands

name	Type	Description
	than warn threshold - mdu-sup2-tx-lwarn : MDU ONT - SFP tx power is lower than warn threshold - mdu-sup2-temp-hwarn : MDU ONT - SFP temperature is higher than warn threshold - mdu-sup2-temp-lwarn : MDU ONT - SFP temperature is lower than warn threshold - mdu-sup2-volt-hwarn : MDU ONT - SFP voltage is higher than warn threshold - mdu-sup2-volt-lwarn : MDU ONT - SFP voltage is lower than warn threshold - mdu-sup2-bias-hwarn : MDU ONT - SFP bias is higher than warn threshold - mdu-sup2-bias-lwarn : MDU ONT - SFP bias is lower than warn threshold - cust-alm1 : customizable alarm 1 - cust-alm2 : customizable alarm 2 - cust-alm3 : customizable alarm 3 - cust-alm4 : customizable alarm 4 - cust-alm5 : customizable alarm 5 - cust-alm6 : customizable alarm 6 - cust-alm7 : customizable alarm 7 - cust-alm8 : customizable alarm 8 - cust-alm9 : customizable alarm 9 - cust-alm10 : customizable alarm 10 - cust-alm11 : customizable alarm 11 - cust-alm12 : customizable alarm 12 - cust-alm13 : customizable alarm 13 - cust-alm14 : customizable alarm 14 - cust-alm15 : customizable alarm 15 - cust-alm16 : customizable alarm 16 - cust-alm17 : customizable alarm 17 - cust-alm18 : customizable alarm 18 - cust-alm19 : customizable alarm 19 - cust-alm20 : customizable alarm 20 - cust-alm21 : customizable alarm 21 - cust-alm22 : customizable alarm 22 - cust-alm23 : customizable alarm 23 - cust-alm24 : customizable alarm 24 - cust-alm25 : customizable alarm 25 - cust-alm26 : customizable alarm 26 - cust-alm27 : customizable alarm 27 - cust-alm28 : customizable alarm 28 - cust-alm29 : customizable alarm 29 - cust-alm30 : customizable alarm 30 - cust-alm31 : customizable alarm 31 - ethernet-ring-pthfwst : ethernet ring path forward state - ethernet-ring-fop-to : ethernet ring fop-to failure of protocol timeout - ethernet-ring-fop-pm : ethernet ring fop-pm failure of protocol provision mismatch - fpm-depletion : failsafe fpm depletion - exp-seizureack : Channel was blocked due to failure in the reception of the SEIZURE ACK signal - exp-disconack : Channel was blocked due to failure in the reception of the DISCONNECTION ACK signal - exp-forcerelack : Channel was blocked due to failure in the	

name	Type	Description
	reception of the BACKWARD DISCONNECTION ACK signal - packet-loss : Pseudo Wire entered the Packet loss state - remote-packet-loss : Remote Packet loss detected - no-dsp-resource : DSP resource allocation failed - la-down : Link aggregation group link-status is down - la-standby-na : Cross-lt lag on standby slot part is not available - la-switch-fail : Cross-lt lag fail to do switchover - la-degrade : Link aggregation group degrade - melt-board-reset : MELT board reset - board-shelf-mismatch : board type and shelf type mismatch - fcs-thresh-exceed : FCS counter threshold exceeded	
state	Parameter type: <Alarm::AlarmState> (active non-active) Possible values: - active : alarm is active - non-active : alarm is not active	reflect's the state of the alarm as either active or non-active. <i>This element is always shown.</i>
last-updated-on	Parameter type: <Sys::timeInSecs> - the time (yyyy-mm-dd:hour:minutes:secs) - unit: UTC	network time in seconds when the alarm was logged. <i>This element is always shown.</i>
additional-info	Parameter type: <Alarm::AdditionalInfo> - string to identify the owner (example: Tom) - length: x<=512	AdditionalInfo <i>This element is always shown.</i>

Only Show Details: critical alarm table related generic information		
name	Type	Description
changes	Parameter type: <Counter> - 32 bit counter	total number of changes of all reported alarms with a severity level critical since startup. <i>This element is only shown in detail mode.</i>
last-entry-id	Parameter type: <SignedInteger> - a signed integer	last entry that was added to the warning delta log. <i>This element is only shown in detail mode.</i>
last-reset	Parameter type: <Sys::Time> - the time (yyyy-mm-dd:hour:minutes:secs) - unit: UTC	network time in seconds indicating when the warning delta log was last reset. <i>This element is only shown in detail mode.</i>
log-overflowed	Parameter type: <Alarm::OverflowStatus> (yes no) Possible values: - yes : buffer has overflowed - no : no buffer overflow	specifies whether the warning delta log is overflowed or not. <i>This element is only shown in detail mode.</i>

101- query current alarms by filters

101.1 query current alarms by filters Tree	101-2487
101.2 show current alarm by filters	101-2500
101.3 show current alarm by filters	101-2509
101.4 show current alarm by filters	101-2518
101.5 show current alarm by filters	101-2528
101.6 show current alarm by filters	101-2538
101.7 show current alarm by filters	101-2548
101.8 show current alarm by filters	101-2557
101.9 show current alarm by filters	101-2565
101.10 show current alarm by filters	101-2573
101.11 show current alarm by filters	101-2582
101.12 show current alarm by filters	101-2591
101.13 show current alarm by filters	101-2600
101.14 show current alarm by filters	101-2608
101.15 show current alarm by filters	101-2616
101.16 show current alarm by filters	101-2625
101.17 show current alarm by filters	101-2634
101.18 show current alarm by filters	101-2642
101.19 show current alarm by filters	101-2650
101.20 show current alarm by filters	101-2658
101.21 show current alarm by filters	101-2666
101.22 show current alarm by filters	101-2675
101.23 show current alarm by filters	101-2684
101.24 show current alarm by filters	101-2694
101.25 show current alarm by filters	101-2703
101.26 show current alarm by filters	101-2712
101.27 show current alarm by filters	101-2722
101.28 show current alarm by filters	101-2730
101.29 show current alarm by filters	101-2738
101.30 show current alarm by filters	101-2746
101.31 show current alarm by filters	101-2755
101.32 show current alarm by filters	101-2764
101.33 show current alarm by filters	101-2774
101.34 show current alarm by filters	101-2783
101.35 show current alarm by filters	101-2793
101.36 show current alarm by filters	101-2803
101.37 show current alarm by filters	101-2811
101.38 show current alarm by filters	101-2820
101.39 show current alarm by filters	101-2828
101.40 show current alarm by filters	101-2837
101.41 show current alarm by filters	101-2846
101.42 show current alarm by filters	101-2855
101.43 show current alarm by filters	101-2863
101.44 show current alarm by filters	101-2871
101.45 show current alarm by filters	101-2880
101.46 show current alarm by filters	101-2888
101.47 show current alarm by filters	101-2897
101.48 show current alarm by filters	101-2906
101.49 show current alarm by filters	101-2915
101.50 show current alarm by filters	101-2924

101.51 show current alarm by filters	101-2933
101.52 show current alarm by filters	101-2942
101.53 show current alarm by filters	101-2951
101.54 show current alarm by filters	101-2960
101.55 show current alarm by filters	101-2970
101.56 show current alarm by filters	101-2980
101.57 show current alarm by filters	101-2990
101.58 show current alarm by filters	101-3000
101.59 show current alarm by filters	101-3009
101.60 show current alarm by filters	101-3018
101.61 show current alarm by filters	101-3026
101.62 show current alarm by filters	101-3034
101.63 show current alarm by filters	101-3045
101.64 show current alarm by filters	101-3053
101.65 show current alarm by filters	101-3062
101.66 show current alarm by filters	101-3073
101.67 show current alarm by filters	101-3082
101.68 show current alarm by filters	101-3092
101.69 show current alarm by filters	101-3100
101.70 show current alarm by filters	101-3109
101.71 show current alarm by filters	101-3118
101.72 show current alarm by filters	101-3126
101.73 show current alarm by filters	101-3135
101.74 show current alarm by filters	101-3144
101.75 show current alarm by filters	101-3153
101.76 show current alarm by filters	101-3162
101.77 show current alarm by filters	101-3171
101.78 show current alarm by filters	101-3180
101.79 show current alarm by filters	101-3188
101.80 show current alarm by filters	101-3196
101.81 show current alarm by filters	101-3206
101.82 show current alarm by filters	101-3215
101.83 show current alarm by filters	101-3223
101.84 show current alarm by filters	101-3231
101.85 show current alarm by filters	101-3239
101.86 show current alarm by filters	101-3247
101.87 show current alarm by filters	101-3256
101.88 show current alarm by filters	101-3265
101.89 show current alarm by filters	101-3273
101.90 show current alarm by filters	101-3281
101.91 show current alarm by filters	101-3295
101.92 show current alarm by filters	101-3308
101.93 show current alarm by filters	101-3317
101.94 show current alarm by filters	101-3327
101.95 show current alarm by filters	101-3337
101.96 show current alarm by filters	101-3345
101.97 show current alarm by filters	101-3353
101.98 show current alarm by filters	101-3363
101.99 show current alarm by filters	101-3373
101.100 show current alarm by filters	101-3381
101.101 show current alarm by filters	101-3389
101.102 show current alarm by filters	101-3397
101.103 show current alarm by filters	101-3405
101.104 show current alarm by filters	101-3413
101.105 show current alarm by filters	101-3422
101.106 show current alarm by filters	101-3432
101.107 show current alarm by filters	101-3440
101.108 show current alarm by filters	101-3448
101.109 show current alarm by filters	101-3456
101.110 show current alarm by filters	101-3464
101.111 show current alarm by filters	101-3473
101.112 show current alarm by filters	101-3483

101.113 show current alarm by filters	101-3491
101.114 show current alarm by filters	101-3500
101.115 show current alarm by filters	101-3509
101.116 show current alarm by filters	101-3522
101.117 show current alarm by filters	101-3530
101.118 show current alarm by filters	101-3540
101.119 show current alarm by filters	101-3548
101.120 show current alarm by filters	101-3556
101.121 show current alarm by filters	101-3565
101.122 show current alarm by filters	101-3573
101.123 show current alarm by filters	101-3582
101.124 show current alarm by filters	101-3590
101.125 show current alarm by filters	101-3598
101.126 show current alarm by filters	101-3606
101.127 show current alarm by filters	101-3614
101.128 show current alarm by filters	101-3622
101.129 show current alarm by filters	101-3630
101.130 show current alarm by filters	101-3640
101.131 show current alarm by filters	101-3651
101.132 show current alarm by filters	101-3662
101.133 show current alarm by filters	101-3673
101.134 show current alarm by filters	101-3681
101.135 show current alarm by filters	101-3692
101.136 show current alarm by filters	101-3701
101.137 show current alarm by filters	101-3712
101.138 show current alarm by filters	101-3721
101.139 show current alarm by filters	101-3730
101.140 show current alarm by filters	101-3738
101.141 show current alarm by filters	101-3853
101.142 show current alarm by filters	101-3864
101.143 show current alarm by filters	101-3873
101.144 show current alarm by filters	101-3881
101.145 show current alarm by filters	101-3889

101.1 query current alarms by filters Tree

Description

This chapter gives an overview of nodes that are handled by "query current alarms by filters".

Command Tree

```

----show
  ----alarm
    ----query
      ----equipment
        - (name)
        - severity
        - servaff
        - defaultaid
      ----eqpt-holder
        - (name)
        - severity
        - servaff
        - shelf
      ----eqpt-holder-ext
        - (name)
        - severity
        - servaff
        - shelf
      ----plug-in-unit
        - (name)
        - severity
        - servaff
        - board
      ----plug-in-unit-ext
        - (name)
        - severity
        - servaff
        - board
      ----sw-mgmt
        - (name)
        - severity
        - servaff
        - board
      ----filetransfer
        - (name)
        - severity
        - servaff
        - server-id
      ----lsmredundancy
        - (name)
        - severity
        - servaff
        - board
      ----traffic-overflow
        - (name)
        - severity

```

- servaff
- board
- l2forward
- (name)
- severity
- servaff
- bridgeport
- sync
- (name)
- severity
- servaff
- board
- cfm
- (name)
- severity
- servaff
- cfm-mep-id
- efm-oam
- (name)
- severity
- servaff
- line
- auto-switch
- (name)
- severity
- servaff
- port
- atm
- (name)
- severity
- servaff
- port
- ether-itf
- (name)
- severity
- servaff
- ether-ifindex
- authentication
- (name)
- severity
- servaff
- defaultaid
- redundancy
- (name)
- severity
- servaff
- defaultaid
- external-device
- (name)
- severity
- servaff
- defaultaid
- sfp
- (name)
- severity
- servaff
- defaultaid
- custom-ext-alarm
- (name)

- severity
- servaff
- board
- sfprssi
 - (name)
 - severity
 - servaff
 - board
- pppcc-engine-tca
 - (name)
 - severity
 - servaff
 - engine
- sfpe1t1-clock
 - (name)
 - severity
 - servaff
 - board
- sfpe1t1-framer
 - (name)
 - severity
 - servaff
 - board
- sip-server
 - (name)
 - severity
 - servaff
 - server-index
- sip-vsp
 - (name)
 - severity
 - servaff
 - vsp-index
- sip-dial-plan
 - (name)
 - severity
 - servaff
 - dialplan-index
- sip-user-agent
 - (name)
 - severity
 - servaff
 - board
- sip-plugin-unit
 - (name)
 - severity
 - servaff
 - board
- sip-termination
 - (name)
 - severity
 - servaff
 - term-index
- secondary-sip-term
 - (name)
 - severity
 - servaff
 - term-index
- xdsi

- (name)
- severity
- servaff
- port
- xdsl-tca
 - (name)
 - severity
 - servaff
 - port
- vect-board
 - (name)
 - severity
 - servaff
 - board-index
- vect-line
 - (name)
 - severity
 - servaff
 - port
- eo-conversion
 - (name)
 - severity
 - servaff
 - port
- bonding-group
 - (name)
 - severity
 - servaff
 - group
- custom
 - (name)
 - severity
 - servaff
 - defaultaid
- megaco-media-gw
 - (name)
 - severity
 - servaff
 - board
- megaco-sig-gw
 - (name)
 - severity
 - servaff
 - board
- megaco-plug-unit
 - (name)
 - severity
 - servaff
 - defaultaid
- megaco-term
 - (name)
 - severity
 - servaff
 - port
- megaco-sig-lt
 - (name)
 - severity
 - servaff
 - board

- shdsl
 - (name)
 - severity
 - servaff
 - port
- shdsl-isam
 - (name)
 - severity
 - servaff
 - port
- ima-group
 - (name)
 - severity
 - servaff
 - port
- ima-link
 - (name)
 - severity
 - servaff
 - port
- ether-tca
 - (name)
 - severity
 - servaff
 - port
- ether-sfp
 - (name)
 - severity
 - servaff
 - port
- uplink-ether-sfp
 - (name)
 - severity
 - servaff
 - port
- qos-queue
 - (name)
 - severity
 - servaff
 - port
- temporal
 - (name)
 - severity
 - servaff
 - defaultaid
- spatial
 - (name)
 - severity
 - servaff
 - defaultaid
- ont-ploam
 - (name)
 - severity
 - servaff
 - ont
- ont-gen
 - (name)
 - severity
 - servaff

- ont
- ont-tca**
 - (name)
 - severity
 - servaff
 - ont
- olt-gen**
 - (name)
 - severity
 - servaff
 - port
- ont-card**
 - (name)
 - severity
 - servaff
 - ont-card
- ont-video**
 - (name)
 - severity
 - servaff
 - video-port
- ont-pots**
 - (name)
 - severity
 - servaff
 - ont-pots
- ont-lan**
 - (name)
 - severity
 - servaff
 - ont-port
- ont-ces**
 - (name)
 - severity
 - servaff
 - cesds1-port
- ont-voip**
 - (name)
 - severity
 - servaff
 - voip-uni
- ont-video-ani**
 - (name)
 - severity
 - servaff
 - ont
- ont-ani**
 - (name)
 - severity
 - servaff
 - ont
- ont-moca**
 - (name)
 - severity
 - servaff
 - uni-index
- ont-tc-tca**
 - (name)
 - severity

```

- servaff
- ont
----ont-l2uni-eth-tca
- (name)
- severity
- servaff
- ont-port
----ont-moca-tca
- (name)
- severity
- servaff
- uni-index
----olt-pon-tc-tca
- (name)
- severity
- servaff
- pon
----olt-ont-tc-tca
- (name)
- severity
- servaff
- ont
----ont-pwe
- (name)
- severity
- servaff
- ont-ces-uni
----ont-cese1
- (name)
- severity
- servaff
- ces-port
----ont-xdsl
- (name)
- severity
- servaff
- dsl-line-port
----ont-xdsl-tca
- (name)
- severity
- servaff
- dsl-line-port
----mcsrc
- (name)
- severity
- servaff
- grp-ip-addr
----eqpt-supplemental
- (name)
- severity
- servaff
- shelf
----ont
- (name)
- severity
- servaff
- ont
----ihub-l2forward
- (name)

```

- severity
- servaff
- port
- vprn**
 - (name)
 - severity
 - servaff
 - router-id
- ospf**
 - (name)
 - severity
 - servaff
 - router-id
- rip**
 - (name)
 - severity
 - servaff
 - router-id
- vpls**
 - (name)
 - severity
 - servaff
 - service-id
- ihub-link**
 - (name)
 - severity
 - servaff
 - port
- ihub-equip**
 - (name)
 - severity
 - servaff
 - board
- lag**
 - (name)
 - severity
 - servaff
 - lag-id
- ihub-general**
 - (name)
 - severity
 - servaff
 - defaultaid
- ellid**
 - (name)
 - severity
 - servaff
 - ellid-index
- epon**
 - (name)
 - severity
 - servaff
 - pon-index
- ont-pots-supplemental**
 - (name)
 - severity
 - servaff
 - ont-port
- sfu-ploam**

- (name)
- severity
- servaff
- ont
- sfu-gen
 - (name)
 - severity
 - servaff
 - ont
- soho-ploam
 - (name)
 - severity
 - servaff
 - ont
- soho-gen
 - (name)
 - severity
 - servaff
 - ont
- mdu-ploam
 - (name)
 - severity
 - servaff
 - ont
- mdu-gen
 - (name)
 - severity
 - servaff
 - ont
- ont-hpna
 - (name)
 - severity
 - servaff
 - ont-port
- ldp
 - (name)
 - severity
 - servaff
 - router-id
- mpls
 - (name)
 - severity
 - servaff
 - router-id
- sdp
 - (name)
 - severity
 - servaff
 - sdp-id
- epipe
 - (name)
 - severity
 - servaff
 - service-id
- lldpmed
 - (name)
 - severity
 - servaff
 - port

- vlanport
 - (name)
 - severity
 - servaff
 - vlanport
- pim
 - (name)
 - severity
 - servaff
 - router-id
- bgp
 - (name)
 - severity
 - servaff
 - router-id
- ihub-ipv6
 - (name)
 - severity
 - servaff
 - router-id
- li
 - (name)
 - severity
 - servaff
 - defaultaid
- ont-sip-agent-cfg
 - (name)
 - severity
 - servaff
 - port
- ont-voip-cfg
 - (name)
 - severity
 - servaff
 - port
- ont-veip
 - (name)
 - severity
 - servaff
 - ont-port
- ont-mgc
 - (name)
 - severity
 - servaff
 - port
- ont-iphost
 - (name)
 - severity
 - servaff
 - port
- otdr
 - (name)
 - severity
 - servaff
 - ponindex
- mgmt-sec-access
 - (name)
 - severity
 - servaff

- ip-address
- eoltrssi**
 - (name)
 - severity
 - servaff
 - epon-id
- bfd**
 - (name)
 - severity
 - servaff
 - vprn-id
- ai**
 - (name)
 - severity
 - servaff
 - board
- tr069serv**
 - (name)
 - severity
 - servaff
 - tr069serv
- ontsnmp**
 - (name)
 - severity
 - servaff
 - uni-index
- bulk-sync**
 - (name)
 - severity
 - servaff
 - port
- protection-group**
 - (name)
 - severity
 - servaff
 - port
- ont-protection**
 - (name)
 - severity
 - servaff
 - ont
- eth-cfm**
 - (name)
 - severity
 - servaff
 - cfm-mep-id
- ont-loopdetect**
 - (name)
 - severity
 - servaff
 - ont
- rsvp**
 - (name)
 - severity
 - servaff
 - router-id
- alarm-table**
 - (name)
 - severity

- servaff
- defaultaid
- ihub-tca
 - (name)
 - severity
 - servaff
 - port
- sfu-sup
 - (name)
 - severity
 - servaff
 - ont
- soho-sup
 - (name)
 - severity
 - servaff
 - ont
- mdu-sup
 - (name)
 - severity
 - servaff
 - ont
- eth-ring
 - (name)
 - severity
 - servaff
 - ring-id
- olt-pon-util-tca
 - (name)
 - severity
 - servaff
 - pon
- channel-pair
 - (name)
 - severity
 - servaff
 - channel-pair
- olt-chpr-util-tca
 - (name)
 - severity
 - servaff
 - channel-pair
- ont-cfg-dld
 - (name)
 - severity
 - servaff
 - ont
- olt-chpair-tc-tca
 - (name)
 - severity
 - servaff
 - channel-pair
- isis
 - (name)
 - severity
 - servaff
 - router-id
- name
 - (name)

- defaultaid
- severity
- servaff
- hgu-tr069
- (name)
- severity
- servaff
- ont
- eqpt-psu
- (name)
- severity
- servaff
- shelf
- secondary-megaco-term
- (name)
- severity
- servaff
- port
- link-agg
- (name)
- severity
- servaff
- group
- fcs-exceed
- (name)
- severity
- servaff
- board

101.2 show current alarm by filters

Command Description

show current alarms by filters

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm query equipment [ (name) [ severity <Alarm::querySeverity> ] [ servaff <Alarm::queryServAffect> ]  
[ defaultaid <Alarm::queryDefaultAid> ] ]
```

Command Parameters

Table 101.2-1 "show current alarm by filters" Resource Parameters

Resource Identifier	Type	Description
(name)	Format: (persist-data-loss sntp-comm-lost nt-disk-95%full preferred-mode timing-reference shub-loc back-pnl-inv shub-conf-loss all) Possible values: - persist-data-loss : all data lost after restart - system not configured - sntp-comm-lost : sntp server not responding - nt-disk-95%full : nt disk 95% full - preferred-mode : preferred mode not available - timing-reference : timing reference failure - shub-loc : communication lost with shub - back-pnl-inv : BackPanel-type Invalid - shub-conf-loss : SHub configuration loss - recent changes lost - all : show all equipment alarm	alarm name of Equipment
severity	Parameter type: <Alarm::querySeverity> Format: (indeterminate warning minor major	severity level of an alarm for reporting

Resource Identifier	Type	Description
	critical all) Possible values: - indeterminate : alarm severity is indeterminate - warning : alarm severity is warning - minor : alarm severity is minor - major : alarm severity is major - critical : alarm severity is critical - all : all alarm severity	
servaff	Parameter type: <Alarm::queryServAffect> Format: (service-affecting noservice-affecting all) Possible values: - service-affecting : query alarm service affecting - noservice-affecting : query alarm not service affecting - all : query service affecting and not affecting alarms	serviceaffecting no serviceaffecting
defaultaid	Parameter type: <Alarm::queryDefaultAid> Format: all Possible values: - all : default AID parameter	default AID param is all

Command Output

Table 101.2-2 "show current alarm by filters" Display parameters

Specific Information		
name	Type	Description
type	Parameter type: <Alarm::alarmIHUBType> (equipment eqpt-holder plug-in-unit atm custom e1 ima-group ima-link redundancy shdsl ether-itf traffic-overflow qos-queue temporal spatial (software-mngt sw-mgmt) xdsl xdsl-ext xdsl-tca olt-gen eo-conv authentication bonding sfp shdsl-isam custom-ext-alarm	type of the alarms that are active <i>This element is only shown in detail mode.</i>

101 query current alarms by filters

name	Type	Description
	plug-in-unit-ext sip-user-agent sip-plugin-unit sip-termination e1-sip-termination filetransfer external-device l2forward ether-tca ether-sfp megaco-media-gw megaco-sig-gw megaco-plug-unit megaco-term megaco-sig-lt eqpt-supplemental eqpt-holder-ext lsmredundancy sync mcsrc vlanport vect-line vect-board otdr sip-dial-plan sip-vsp sip-server bgp rip lag ihub-general vprn isis ospf ihub-l2forward vpls ihub-equip ihub-link eont-phyoam ellid epon eont-services-lan eolt-ont-tca eont-sw-dl ldp mpls sdp epipe ihub-ipv6 pim li mgmt-sec-access bfd ai tr069serv ontsnmp bulk-sync	

name	Type	Description
	protection-group ont sfu-sup soho-sup mdu-sup ont-ani sfu-sup2 soho-sup2 mdu-sup2 sfrssi eoltrssi cfm sfpe1t1-framer sfpe1t1-clock pppcc-engine-tca eth-cfm rsvp ihub-tca eth-ring efm-oam ont-loopdetect ont-video ont-ces ont-voip ont-video-ani ont-pwe ont-cese1 ont-xdsl ont-xdsl-tca ont-hpna ont-sip-agent-cfg ont-voip-cfg ont-mgc ont-ploam ont-gen ont-card ont-pots ont-lan ont-moca ont-tc-tca ont-moca-tca ont-l2uni-eth-tca olt-pon-tc-tca olt-pon-util-tca olt-chpr-util-tca olt-ont-tc-tca ont-tca ont-pots-supplemental sfu-ploam sfu-gen soho-ploam soho-gen mdu-ploam mdu-gen ont-veip ont-iphost alarm-table	

101 query current alarms by filters

name	Type	Description
	auto-switch channel-pair ont-cfg-dld olt-chpair-tc-tca hgu-tr069 eqpt-psu ont-protection secondary-megaco-term secondary-sip-term cas-r2-channel lldpmed pseudo-wire link-agg fcs-exceed e1t1-interface) Possible values: - equipment : equipment alarms - eqpt-holder : equipment holder alarms - plug-in-unit : plugin unit alarms - atm : ATM alarms - custom : customizable alarms - e1 : e1 alarms - ima-group : ima-group alarms - ima-link : ima-link alarms - redundancy : redundancy alarms - shdsl : shdsl alarms - ether-itf : ethernet interface alarms - traffic-overflow : Traffic overflow alarms - qos-queue : qos queue alarms - temporal : temporal alarms - spatial : spatial alarms - software-mngt : software management alarms - sw-mgmt : software management alarms - xdsl : xDSL alarms - xdsl-ext : other xDSL alarms - xdsl-tca : xDSL threshold cross alarms - olt-gen : OLT general alarms - eo-conv : E/O conversion related alarms - authentication : authentication related alarms - bonding : bonding-group related alarms - sfp : SFP related alarms - shdsl-isam : shdsl isam alarms - custom-ext-alarm : customizable external alarms - plug-in-unit-ext : other plugin unit alarms - sip-user-agent : sip user agent related alarms - sip-plugin-unit : sip plug in unit related alarms - sip-termination : sip termination related alarms - e1-sip-termination : E1 sip termination related alarms - filetransfer : file transfer server alarms - external-device : external device related alarms - l2forward : l2forward related alarms - ether-tca : ethernet threshold cross alarms - ether-sfp : ethernet SFP related alarms - megaco-media-gw : megaco media gateway related alarms - megaco-sig-gw : megaco signaling gateway related alarms - megaco-plug-unit : megaco plug unit related alarms - megaco-term : megaco termination related alarms	

name	Type	Description
	- megaco-sig-lt : megaco signaling lt related alarms - eqpt-supplemental : equipment supplemental alarms - eqpt-holder-ext : other equipment holder alarms - lsmredundancy : lsm redundancy alarms - sync : synce and bits alarms - mcsrc : multicast source alarms - vlanport : vlanport alarms - vect-line : xDSL vectoring line alarms - vect-board : xDSL vectoring board alarms - otdr : otdr alarms - sip-dial-plan : sip dial plan related alarms - sip-vsp : sip vsp related alarms - sip-server : sip server related alarms - bgp : bgp related alarms - rip : rip related alarms - lag : LAG related alarms - ihub-general : IHUB general related alarms - vprn : vprn related alarms - isis : isis related alarms - ospf : ospf related alarms - ihub-l2forward : ihub-l2forward alarms - vpls : vpls related alarms - ihub-equip : ihub-equip related alarms - ihub-link : ihub-link related alarms - eont-phyoam : eont phyoam related alarms - ellid : ellid related alarms - epon : epon related alarms - eont-services-lan : eon phyoam related alarms - eolt-ont-tca : eon phyoam related alarms - eont-sw-dl : eon phyoam related alarms - ldp : ldp related alarms - mpls : mpls related alarms - sdp : sdp related alarms - epipe : epipe related alarms - ihub-ipv6 : ihub-ipv6 related alarms - pim : pim related alarms - li : lawful intercept related alarms - mgmt-sec-access : management security related alarms - bfd : bfd related alarms - ai : Application Intelligence related alarms - tr069serv : tr069 server related alarms - ontsnmp : ont snmp related alarms - bulk-sync : bulk-sync related alarms - protection-group : port protection group related alarms - ont : ONT general supplemental related alarms - sfu-sup : SFU ONT general supplemental related alarms - soho-sup : SOHO ONT general supplemental related alarms - mdu-sup : MDU ONT general supplemental related alarms - ont-ani : ONT general supplemental 2 related alarms - sfu-sup2 : SFU ONT general supplemental 2 related alarms - soho-sup2 : SOHO ONT general supplemental 2 related alarms - mdu-sup2 : MDU ONT general supplemental 2 related alarms - sfprssi : SFP RSSI related alarms - eoltrssi : epon olt Sfp RSSI related alarms	

101 query current alarms by filters

name	Type	Description
	- cfm : Cfm related alarms - sfpe1t1-framer : SFP 2e1t1 framer alarms - sfpe1t1-clock : SFP 2e1t1 clock alarms - pppcc-engine-tca : PPPOE Cross Connect Engine TCA related alarm - eth-cfm : eth-cfm related alarms - rsvp : rsvp related alarms - ihub-tca : IHUB TCA related alarms - eth-ring : eth-ring related alarms - efm-oam : EFM-OAM related alarms - ont-loopdetect : ont loop detect related alarms - ont-video : ont services video related alarms - ont-ces : ont services ces related alarms - ont-voip : ont services voip related alarms - ont-video-ani : ont services video ani related alarms - ont-pwe : ont services pwe related alarms - ont-cese1 : ont services cese1 related alarms - ont-xdsl : ont services xdsl related alarms - ont-xdsl-tca : ont services xdsl tca related alarms - ont-hpna : ont hpna related alarms - ont-sip-agent-cfg : ont services voip sip agent config related alarms - ont-voip-cfg : ont services voip config related alarms - ont-mgc : ont mgc related alarms - ont-ploam : ONT PLOAM related alarms - ont-gen : ONT GENERAL related alarms - ont-card : ONT Subscriber Card related alarms - ont-pots : ONT Services POTS related alarms - ont-lan : ONT Services LAN related alarms - ont-moca : ONT MoCA related alarms - ont-tc-tca : ONT TC TCA related alarms - ont-moca-tca : ONT MoCA TCA related alarms - ont-l2uni-eth-tca : ONT L2 UNI Ethernet TCA related alarms - olt-pon-tc-tca : OLT PON TC TCA related alarms - olt-pon-util-tca : OLT PON utilization TCA related alarms - olt-chpr-util-tca : OLT channel-pair utilization TCA related alarms - olt-ont-tc-tca : OLT ONT TC TCA related alarms - ont-tca : ONT TCA related alarms - ont-pots-supplemental : ONT POTS Supplemental related alarms - sfu-ploam : SFU ONT PLOAM related alarms - sfu-gen : SFU ONT general related alarms - soho-ploam : SOHO ONT PLOAM related alarms - soho-gen : SOHO ONT general related alarms - mdm-ploam : MDU ONT PLOAM related alarms - mdm-gen : MDU ONT general related alarms - ont-veip : ONT VEIP related alarms - ont-iphost : ONT IP HOST related alarms - alarm-table : alarm table related alarms - auto-switch : auto-switch related alarms - channel-pair : channel pair related alarms - ont-cfg-dld : ont configure file download related alarms - olt-chpair-tc-tca : OLT CHANNELPAIR TC TCA related alarms - hgu-tr069 : hgu tr069 related alarms	

name	Type	Description
	- eqpt-psu : equipment psu alarms - ont-protection : ONT protection related alarms - secondary-megaco-term : secondary megaco termination related alarms - secondary-sip-term : secondary sip termination related alarms - cas-r2-channel : CAS R2 channel related alarms - lldpmed : lldpmed alarms - pseudo-wire : pseudo Wire related alarms - link-agg : Link aggregation related alarms - fcs-exceed : FCS auto-recovery related alarms - e1t1-interface : E1/T1 physical interfaces related alarms	
name	Parameter type: <Alarm::alarmTypeEquipment> (persist-data-loss sntp-comm-lost nt-disk-95%full preferred-mode timing-reference shub-loc back-pnl-inv shub-conf-loss all) Possible values: - persist-data-loss : all data lost after restart - system not configured - sntp-comm-lost : sntp server not responding - nt-disk-95%full : nt disk 95% full - preferred-mode : preferred mode not available - timing-reference : timing reference failure - shub-loc : communication lost with shub - back-pnl-inv : BackPanel-type Invalid - shub-conf-loss : SHub configuration loss - recent changes lost - all : show all equipment alarm	alarm name that are active <i>This element is only shown in detail mode.</i>
severity	Parameter type: <Alarm::AlarmSeverity> (indeterminate warning minor major critical) Possible values: - indeterminate : alarm severity is indeterminate - warning : alarm severity is warning - minor : alarm severity is minor - major : alarm severity is major - critical : alarm severity is critical	the alarms severity level <i>This element is only shown in detail mode.</i>
servaff	Parameter type: <Alarm::alarmServAffect> ((service-affecting yes) (noservice-affecting no)) Possible values: - service-affecting : make this alarm service affecting - yes : make this alarm service affecting - noservice-affecting : make this alarm not service affecting - no : make this alarm not service affecting	alarms affect service or not <i>This element is only shown in detail mode.</i>
time	Parameter type: <Sys::timeInSecs> - the time (yyyy-mm-dd:hour:minutes:secs) - unit: UTC	time in seconds when alarm was updated <i>This element is only shown in</i>

101 query current alarms by filters

name	Type	Description
		<i>detail mode.</i>
descript	Parameter type: <Alarm::AddInfoString> - additional alarm information	alarm description <i>This element is only shown in detail mode.</i>

101.3 show current alarm by filters

Command Description

show current alarms by filters

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm query eqpt-holder [ (name) [ severity <Alarm::querySeverity> ] [ servaff <Alarm::queryServAffect> ] [ shelf <Equipm::Shelf> ] ]
```

Command Parameters

Table 101.3-1 "show current alarm by filters" Resource Parameters

Resource Identifier	Type	Description
(name)	Format: (rack-power rack-fan-unit1 rack-fan-unit2 shelf-mismatch shelf-missing shelf-install-missing door ac-power-fail all) Possible values: - rack-power : power fuse broken - rack-fan-unit1 : fan unit rack 1 failing - rack-fan-unit2 : fan unit rack 2 failing - shelf-mismatch : shelf type different from planned type - shelf-missing : detected shelf no longer detected - shelf-install-missing : shelf planned but not installed - door : open cabinet door - ac-power-fail : external power failure - shelf shutdown in 15 minutes - all : show all sw-mgmt alarm	alarm name of eqpt-holder
severity	Parameter type: <Alarm::querySeverity> Format: (indeterminate warning minor major critical	severity level of alarm for reporting

101 query current alarms by filters

Resource Identifier	Type	Description
	all) Possible values: - indeterminate : alarm severity is indeterminate - warning : alarm severity is warning - minor : alarm severity is minor - major : alarm severity is major - critical : alarm severity is critical - all : all alarm severity	
servaff	Parameter type: <Alarm::queryServAffect> Format: (service-affecting noservice-affecting all) Possible values: - service-affecting : query alarm service affecting - noservice-affecting : query alarm not service affecting - all : query service affecting and not affecting alarms	serviceaffecting no serviceaffecting
shelf	Parameter type: <Equipm::Shelf> Format: <Eqpt::RackId> / <Eqpt::ShelfId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number	the shelf identifier of alarm

Command Output

Table 101.3-2 "show current alarm by filters" Display parameters

Specific Information		
name	Type	Description
aidinfo	Parameter type: <Alarm::AddInfoString> - additional alarm information	alarm AID parameters <i>This element is only shown in detail mode.</i>
type	Parameter type: <Alarm::alarmIHUBType> (equipment eqpt-holder plug-in-unit atm custom e1 ima-group ima-link redundancy shdsl ether-itf traffic-overflow qos-queue temporal spatial (software-mngt sw-mgmt) xdsl xdsl-ext xdsl-tca olt-gen eo-conv authentication	type of the alarms that are active <i>This element is only shown in detail mode.</i>

name	Type	Description
	bonding sfp shdsl-isam custom-ext-alarm plug-in-unit-ext sip-user-agent sip-plugin-unit sip-termination e1-sip-termination filetransfer external-device l2forward ether-tca ether-sfp megaco-media-gw megaco-sig-gw megaco-plug-unit megaco-term megaco-sig-lt eqpt-supplemental eqpt-holder-ext lsmredundancy sync mcsrc vlanport vect-line vect-board otdr sip-dial-plan sip-vsp sip-server bgp rip lag ihub-general vprn isis ospf ihub-l2forward vpls ihub-equip ihub-link eont-phyoam ellid epon eont-services-lan eolt-ont-tca eont-sw-dl ldp mpls sdp epipe ihub-ipv6 pim li mgmt-sec-access bfd	

101 query current alarms by filters

name	Type	Description
	ai	
	tr069serv	
	ontsnmp	
	bulk-sync	
	protection-group	
	ont	
	sfu-sup	
	soho-sup	
	mdu-sup	
	ont-ani	
	sfu-sup2	
	soho-sup2	
	mdu-sup2	
	sfprssi	
	eoltrssi	
	cfm	
	sfpe1t1-framer	
	sfpe1t1-clock	
	pppcc-engine-tca	
	eth-cfm	
	rsvp	
	ihub-tca	
	eth-ring	
	efm-oam	
	ont-loopdetect	
	ont-video	
	ont-ces	
	ont-voip	
	ont-video-ani	
	ont-pwe	
	ont-cese1	
	ont-xdsl	
	ont-xdsl-tca	
	ont-hpna	
	ont-sip-agent-cfg	
	ont-voip-cfg	
	ont-mgc	
	ont-ploam	
	ont-gen	
	ont-card	
	ont-pots	
	ont-lan	
	ont-moca	
	ont-tc-tca	
	ont-moca-tca	
	ont-l2uni-eth-tca	
	olt-pon-tc-tca	
	olt-pon-util-tca	
	olt-chpr-util-tca	
	olt-ont-tc-tca	
	ont-tca	
	ont-pots-supplemental	
	sfu-ploam	
	sfu-gen	
	soho-ploam	
	soho-gen	
	mdu-ploam	

name	Type	Description
	mdu-gen ont-veip ont-iphost alarm-table auto-switch channel-pair ont-cfg-dld olt-chpair-tc-tca hgu-tr069 eqpt-psu ont-protection secondary-megaco-term secondary-sip-term cas-r2-channel lldpmed pseudo-wire link-agg fcs-exceed e1t1-interface) Possible values: - equipment : equipment alarms - eqpt-holder : equipment holder alarms - plug-in-unit : plugin unit alarms - atm : ATM alarms - custom : customizable alarms - e1 : e1 alarms - ima-group : ima-group alarms - ima-link : ima-link alarms - redundancy : redundancy alarms - shdsl : shdsl alarms - ether-itf : ethernet interface alarms - traffic-overflow : Traffic overflow alarms - qos-queue : qos queue alarms - temporal : temporal alarms - spatial : spatial alarms - software-mngt : software management alarms - sw-mgmt : software management alarms - xdsl : xDSL alarms - xdsl-ext : other xDSL alarms - xdsl-tca : xDSL threshold cross alarms - olt-gen : OLT general alarms - eo-conv : E/O conversion related alarms - authentication : authentication related alarms - bonding : bonding-group related alarms - sfp : SFP related alarms - shdsl-isam : shdsl isam alarms - custom-ext-alarm : customizable external alarms - plug-in-unit-ext : other plugin unit alarms - sip-user-agent : sip user agent related alarms - sip-plugin-unit : sip plug in unit related alarms - sip-termination : sip termination related alarms - e1-sip-termination : E1 sip termination related alarms - filetransfer : file transfer server alarms - external-device : external device related alarms - l2forward : l2forward related alarms - ether-tca : ethernet threshold cross alarms - ether-sfp : ethernet SFP related alarms	

101 query current alarms by filters

name	Type	Description
	- megaco-media-gw : megaco media gateway related alarms - megaco-sig-gw : megaco signaling gateway related alarms - megaco-plug-unit : megaco plug unit related alarms - megaco-term : megaco termination related alarms - megaco-sig-lt : megaco signaling lt related alarms - eqpt-supplemental : equipment supplemental alarms - eqpt-holder-ext : other equipment holder alarms - lsmredundancy : lsm redundancy alarms - sync : synce and bits alarms - mcsrc : multicast source alarms - vlanport : vlanport alarms - vect-line : xDSL vectoring line alarms - vect-board : xDSL vectoring board alarms - otdr : otdr alarms - sip-dial-plan : sip dial plan related alarms - sip-vsp : sip vsp related alarms - sip-server : sip server related alarms - bgp : bgp related alarms - rip : rip related alarms - lag : LAG related alarms - ihub-general : IHUB general related alarms - vprn : vprn related alarms - isis : isis related alarms - ospf : ospf related alarms - ihub-l2forward : ihub-l2forward alarms - vpls : vpls related alarms - ihub-equip : ihub-equip related alarms - ihub-link : ihub-link related alarms - eont-phyoam : eont phyoam related alarms - ellid : ellid related alarms - epon : epon related alarms - eont-services-lan : eon phyoam related alarms - eolt-ont-tca : eon phyoam related alarms - eont-sw-dl : eon phyoam related alarms - ldp : ldp related alarms - mpls : mpls related alarms - sdp : sdp related alarms - epipe : epipe related alarms - ihub-ipv6 : ihub-ipv6 related alarms - pim : pim related alarms - li : lawful intercept related alarms - mgmt-sec-access : management security related alarms - bfd : bfd related alarms - ai : Application Intelligence related alarms - tr069serv : tr069 server related alarms - ontsnmp : ont snmp related alarms - bulk-sync : bulk-sync related alarms - protection-group : port protection group related alarms - ont : ONT general supplemental related alarms - sfu-sup : SFU ONT general supplemental related alarms - soho-sup : SOHO ONT general supplemental related alarms - mdu-sup : MDU ONT general supplemental related alarms - ont-ani : ONT general supplemental 2 related alarms - sfu-sup2 : SFU ONT general supplemental 2 related alarms - soho-sup2 : SOHO ONT general supplemental 2 related alarms	

name	Type	Description
	- mdu-sup2 : MDU ONT general supplemental 2 related alarms - sfrssi : SFP RSSI related alarms - eoltrssi : epon olt Sfp RSSI related alarms - cfm : Cfm related alarms - sfpe1t1-framer : SFP 2e1t1 framer alarms - sfpe1t1-clock : SFP 2e1t1 clock alarms - pppcc-engine-tca : PPPOE Cross Connect Engine TCA related alarm - eth-cfm : eth-cfm related alarms - rsvp : rsvp related alarms - ihub-tca : IHUB TCA related alarms - eth-ring : eth-ring related alarms - efm-oam : EFM-OAM related alarms - ont-loopdetect : ont loop detect related alarms - ont-video : ont services video related alarms - ont-ces : ont services ces related alarms - ont-voip : ont services voip related alarms - ont-video-ani : ont services video ani related alarms - ont-pwe : ont services pwe related alarms - ont-cese1 : ont services cese1 related alarms - ont-xdsl : ont services xdsl related alarms - ont-xdsl-tca : ont services xdsl tca related alarms - ont-hpna : ont hpna related alarms - ont-sip-agent-cfg : ont services voip sip agent config related alarms - ont-voip-cfg : ont services voip config related alarms - ont-mgc : ont mgc related alarms - ont-ploam : ONT PLOAM related alarms - ont-gen : ONT GENERAL related alarms - ont-card : ONT Subscriber Card related alarms - ont-pots : ONT Services POTS related alarms - ont-lan : ONT Services LAN related alarms - ont-moca : ONT MoCA related alarms - ont-tc-tca : ONT TC TCA related alarms - ont-moca-tca : ONT MoCA TCA related alarms - ont-l2uni-eth-tca : ONT L2 UNI Ethernet TCA related alarms - olt-pon-tc-tca : OLT PON TC TCA related alarms - olt-pon-util-tca : OLT PON utilization TCA related alarms - olt-chpr-util-tca : OLT channel-pair utilization TCA related alarms - olt-ont-tc-tca : OLT ONT TC TCA related alarms - ont-tca : ONT TCA related alarms - ont-pots-supplemental : ONT POTS Supplemental related alarms - sfu-ploam : SFU ONT PLOAM related alarms - sfu-gen : SFU ONT general related alarms - soho-ploam : SOHO ONT PLOAM related alarms - soho-gen : SOHO ONT general related alarms - mdu-ploam : MDU ONT PLOAM related alarms - mdu-gen : MDU ONT general related alarms - ont-veip : ONT VEIP related alarms - ont-iphost : ONT IP HOST related alarms - alarm-table : alarm table related alarms - auto-switch : auto-switch related alarms - channel-pair : channel pair related alarms	

101 query current alarms by filters

name	Type	Description
	- ont-cfg-dld : ont configure file download related alarms - olt-chpair-tc-tca : OLT CHANNELPAIR TC TCA related alarms - hgu-tr069 : hgu tr069 related alarms - eqpt-psu : equipment psu alarms - ont-protection : ONT protection related alarms - secondary-megaco-term : secondary megaco termination related alarms - secondary-sip-term : secondary sip termination related alarms - cas-r2-channel : CAS R2 channel related alarms - lldpmed : lldpmed alarms - pseudo-wire : pseudo Wire related alarms - link-agg : Link aggregation related alarms - fcs-exceed : FCS auto-recovery related alarms - e1t1-interface : E1/T1 physical interfaces related alarms	
name	Parameter type: <Alarm::almtypEqptholder> (rack-power rack-fan-unit1 rack-fan-unit2 shelf-mismatch shelf-missing shelf-install-missing door ac-power-fail all) Possible values: - rack-power : power fuse broken - rack-fan-unit1 : fan unit rack 1 failing - rack-fan-unit2 : fan unit rack 2 failing - shelf-mismatch : shelf type different from planned type - shelf-missing : detected shelf no longer detected - shelf-install-missing : shelf planned but not installed - door : open cabinet door - ac-power-fail : external power failure - shelf shutdown in 15 minutes - all : show all sw-mgmt alarm	alarm name that are active <i>This element is only shown in detail mode.</i>
severity	Parameter type: <Alarm::AlarmSeverity> (indeterminate warning minor major critical) Possible values: - indeterminate : alarm severity is indeterminate - warning : alarm severity is warning - minor : alarm severity is minor - major : alarm severity is major - critical : alarm severity is critical	the alarms severity level <i>This element is only shown in detail mode.</i>
servaff	Parameter type: <Alarm::alarmServAffect> ((service-affecting yes) (noservice-affecting no)) Possible values: - service-affecting : make this alarm service affecting - yes : make this alarm service affecting - noservice-affecting : make this alarm not service affecting - no : make this alarm not service affecting	alarms affect service or not <i>This element is only shown in detail mode.</i>

101 query current alarms by filters

name	Type	Description
time	Parameter type: <Sys::timeInSecs> - the time (yyyy-mm-dd:hour:minutes:secs) - unit: UTC	time in seconds when alarm was updated <i>This element is only shown in detail mode.</i>
descript	Parameter type: <Alarm::AddInfoString> - additional alarm information	alarm description <i>This element is only shown in detail mode.</i>

101.4 show current alarm by filters

Command Description

show current alarms by filters

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm query eqpt-holder-ext [ (name) [ severity <Alarm::querySeverity> ] [ servaff
<Alarm::queryServAffect> ] [ shelf <Equipm::Shelf> ] ]
```

Command Parameters

Table 101.4-1 "show current alarm by filters" Resource Parameters

Resource Identifier	Type	Description
(name)	Format: (network-power-loss hw-fault bat-miss bat-fail bat-low bat-a-fail bat-b-fail ac-vol-out-range network-power-loss-b sem-ac-power-fail sem-ups-low-volt dc-a-fail dc-b-fail plan-power-mismatch water-seepage-in-box sealed-box-open dc-a-vol-out-range dc-b-vol-out-range inlet-temp-major inlet-temp-critical all) Possible values: - network-power-loss : Loss of Network Power - hw-fault : Hardware Failure - bat-miss : Power Source Battery Missing - bat-fail : Power Source Battery Failure - bat-low : Power Source Battery Charge LOW	alarm name of eqpt-holder-ext

Resource Identifier	Type	Description
	- bat-a-fail : Power Source BAT-A Fail - bat-b-fail : Power Source BAT-B Fail - ac-vol-out-range : AC Input Voltage Value Out of Range - network-power-loss-b : Loss of Network Power B - sem-ac-power-fail : External AC power supply failure - sem-ups-low-volt : External power supply low voltage - dc-a-fail : Local DC A power failure - dc-b-fail : Local DC B power failure - plan-power-mismatch : Planned and detected power mode mismatch - water-seepage-in-box : Detected water seepage in enclosure - sealed-box-open : Sealed box open detected - dc-a-vol-out-range : DC A Input Voltage Value Out of Range - dc-b-vol-out-range : DC B Input Voltage Value Out of Range - inlet-temp-major : The inlet temperature has exceeded a major level - inlet-temp-critical : The inlet temperature has exceeded a critical level - all : show all equipment holder extent alarm	
severity	Parameter type: <Alarm::querySeverity> Format: (indeterminate warning minor major critical all) Possible values: - indeterminate : alarm severity is indeterminate - warning : alarm severity is warning - minor : alarm severity is minor - major : alarm severity is major - critical : alarm severity is critical - all : all alarm severity	severity level of alarm for reporting
servaff	Parameter type: <Alarm::queryServAffect> Format: (service-affecting noservice-affecting all) Possible values: - service-affecting : query alarm service affecting - noservice-affecting : query alarm not service affecting - all : query service affecting and not affecting alarms	serviceaffecting no serviceaffecting
shelf	Parameter type: <Equipm::Shelf> Format: <Eqpt::RackId> / <Eqpt::ShelfId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number	the shelf identifier of alarm

Command Output

Table 101.4-2 "show current alarm by filters" Display parameters

Specific Information		
name	Type	Description
aidinfo	Parameter type: <Alarm::AddInfoString> - additional alarm information	alarm AID parameters <i>This element is only shown in detail mode.</i>
type	Parameter type: <Alarm::alarmIHUBType> (equipment eqpt-holder plug-in-unit atm custom e1 ima-group ima-link redundancy shdsl ether-itf traffic-overflow qos-queue temporal spatial (software-mngt sw-mgmt) xdsl xdsl-ext xdsl-tca olt-gen eo-conv authentication bonding sfp shdsl-isam custom-ext-alarm plug-in-unit-ext sip-user-agent sip-plugin-unit sip-termination e1-sip-termination filetransfer external-device l2forward ether-tca ether-sfp megaco-media-gw megaco-sig-gw megaco-plug-unit megaco-term megaco-sig-lt eqpt-supplemental eqpt-holder-ext lsmredundancy sync mcsrc vlanport vect-line vect-board otdr	type of the alarms that are active <i>This element is only shown in detail mode.</i>

name	Type	Description
	sip-dial-plan sip-vsp sip-server bgp rip lag ihub-general vprn isis ospf ihub-l2forward vpls ihub-equip ihub-link eont-phyoam ellid epon eont-services-lan eolt-ont-tca eont-sw-dl ldp mpls sdp epipe ihub-ipv6 pim li mgmt-sec-access bfd ai tr069serv ontsnmp bulk-sync protection-group ont sfu-sup soho-sup mdu-sup ont-ani sfu-sup2 soho-sup2 mdu-sup2 sfprssi eoltrssi cfm sfpe1t1-framer sfpe1t1-clock pppcc-engine-tca eth-cfm rsvp ihub-tca eth-ring efm-oam ont-loopdetect ont-video ont-ces ont-voip	

101 query current alarms by filters

name	Type	Description
	ont-video-ani ont-pwe ont-cese1 ont-xdsl ont-xdsl-tca ont-hpna ont-sip-agent-cfg ont-voip-cfg ont-mgc ont-ploam ont-gen ont-card ont-pots ont-lan ont-moca ont-tc-tca ont-moca-tca ont-l2uni-eth-tca olt-pon-tc-tca olt-pon-util-tca olt-chpr-util-tca olt-ont-tc-tca ont-tca ont-pots-supplemental sfu-ploam sfu-gen soho-ploam soho-gen mdu-ploam mdu-gen ont-veip ont-iphost alarm-table auto-switch channel-pair ont-cfg-dld olt-chpair-tc-tca hgu-tr069 eqpt-psu ont-protection secondary-megaco-term secondary-sip-term cas-r2-channel lldpmed pseudo-wire link-agg fcs-exceed e1t1-interface) Possible values: - equipment : equipment alarms - eqpt-holder : equipment holder alarms - plug-in-unit : plugin unit alarms - atm : ATM alarms - custom : customizable alarms - e1 : e1 alarms - ima-group : ima-group alarms - ima-link : ima-link alarms	

name	Type	Description
	- redundancy : redundancy alarms - shdsl : shdsl alarms - ether-itf : ethernet interface alarms - traffic-overflow : Traffic overflow alarms - qos-queue : qos queue alarms - temporal : temporal alarms - spatial : spatial alarms - software-mngt : software management alarms - sw-mgmt : software management alarms - xdsl : xDSL alarms - xdsl-ext : other xDSL alarms - xdsl-tca : xDSL threshold cross alarms - olt-gen : OLT general alarms - eo-conv : E/O conversion related alarms - authentication : authentication related alarms - bonding : bonding-group related alarms - sfp : SFP related alarms - shdsl-isam : shdsl isam alarms - custom-ext-alarm : customizable external alarms - plug-in-unit-ext : other plugin unit alarms - sip-user-agent : sip user agent related alarms - sip-plugin-unit : sip plug in unit related alarms - sip-termination : sip termination related alarms - e1-sip-termination : E1 sip termination related alarms - filetransfer : file transfer server alarms - external-device : external device related alarms - l2forward : l2forward related alarms - ether-tca : ethernet threshold cross alarms - ether-sfp : ethernet SFP related alarms - megaco-media-gw : megaco media gateway related alarms - megaco-sig-gw : megaco signaling gateway related alarms - megaco-plug-unit : megaco plug unit related alarms - megaco-term : megaco termination related alarms - megaco-sig-lt : megaco signaling lt related alarms - eqpt-supplemental : equipment supplemental alarms - eqpt-holder-ext : other equipment holder alarms - lsmredundancy : lsm redundancy alarms - sync : synce and bits alarms - mcsrc : multicast source alarms - vlanport : vlanport alarms - vect-line : xDSL vectoring line alarms - vect-board : xDSL vectoring board alarms - otdr : otdr alarms - sip-dial-plan : sip dial plan related alarms - sip-vsp : sip vsp related alarms - sip-server : sip server related alarms - bgp : bgp related alarms - rip : rip related alarms - lag : LAG related alarms - ihub-general : IHUB general related alarms - vprn : vprn related alarms - isis : isis related alarms - ospf : ospf related alarms - ihub-l2forward : ihub-l2forward alarms - vpls : vpls related alarms - ihub-equip : ihub-equip related alarms - ihub-link : ihub-link related alarms	

101 query current alarms by filters

name	Type	Description
	- eont-phyoam : eont phyoam related alarms - ellid : ellid related alarms - epon : epon related alarms - eont-services-lan : eon phyoam related alarms - eolt-ont-tca : eon phyoam related alarms - eont-sw-dl : eon phyoam related alarms - ldp : ldp related alarms - mpls : mpls related alarms - sdp : sdp related alarms - epipe : epipe related alarms - ihub-ipv6 : ihub-ipv6 related alarms - pim : pim related alarms - li : lawful intercept related alarms - mgmt-sec-access : management security related alarms - bfd : bfd related alarms - ai : Application Intelligence related alarms - tr069serv : tr069 server related alarms - ontsnmp : ont snmp related alarms - bulk-sync : bulk-sync related alarms - protection-group : port protection group related alarms - ont : ONT general supplemental related alarms - sfu-sup : SFU ONT general supplemental related alarms - soho-sup : SOHO ONT general supplemental related alarms - mdu-sup : MDU ONT general supplemental related alarms - ont-ani : ONT general supplemental 2 related alarms - sfu-sup2 : SFU ONT general supplemental 2 related alarms - soho-sup2 : SOHO ONT general supplemental 2 related alarms - mdu-sup2 : MDU ONT general supplemental 2 related alarms - sfprssi : SFP RSSI related alarms - eoltrssi : epon olt Sfp RSSI related alarms - cfm : Cfm related alarms - sfpe1t1-framer : SFP 2e1t1 framer alarms - sfpe1t1-clock : SFP 2e1t1 clock alarms - pppcc-engine-tca : PPPOE Cross Connect Engine TCA related alarm - eth-cfm : eth-cfm related alarms - rsvp : rsvp related alarms - ihub-tca : IHUB TCA related alarms - eth-ring : eth-ring related alarms - efm-oam : EFM-OAM related alarms - ont-loopdetect : ont loop detect related alarms - ont-video : ont services video related alarms - ont-ces : ont services ces related alarms - ont-voip : ont services voip related alarms - ont-video-ani : ont services video ani related alarms - ont-pwe : ont services pwe related alarms - ont-cese1 : ont services cese1 related alarms - ont-xdsl : ont services xdsl related alarms - ont-xdsl-tca : ont services xdsl tca related alarms - ont-hpna : ont hpna related alarms - ont-sip-agent-cfg : ont services voip sip agent config related alarms - ont-voip-cfg : ont services voip config related alarms - ont-mgc : ont mgc related alarms	

name	Type	Description
	- ont-ploam : ONT PLOAM related alarms - ont-gen : ONT GENERAL related alarms - ont-card : ONT Subscriber Card related alarms - ont-pots : ONT Services POTS related alarms - ont-lan : ONT Services LAN related alarms - ont-moca : ONT MoCA related alarms - ont-tc-tca : ONT TC TCA related alarms - ont-moca-tca : ONT MoCA TCA related alarms - ont-l2uni-eth-tca : ONT L2 UNI Ethernet TCA related alarms - olt-pon-tc-tca : OLT PON TC TCA related alarms - olt-pon-util-tca : OLT PON utilization TCA related alarms - olt-chpr-util-tca : OLT channel-pair utilization TCA related alarms - olt-ont-tc-tca : OLT ONT TC TCA related alarms - ont-tca : ONT TCA related alarms - ont-pots-supplemental : ONT POTS Supplemental related alarms - sfu-ploam : SFU ONT PLOAM related alarms - sfu-gen : SFU ONT general related alarms - soho-ploam : SOHO ONT PLOAM related alarms - soho-gen : SOHO ONT general related alarms - mdu-ploam : MDU ONT PLOAM related alarms - mdu-gen : MDU ONT general related alarms - ont-veip : ONT VEIP related alarms - ont-iphost : ONT IP HOST related alarms - alarm-table : alarm table related alarms - auto-switch : auto-switch related alarms - channel-pair : channel pair related alarms - ont-cfg-dld : ont configure file download related alarms - olt-chpair-tc-tca : OLT CHANNELPAIR TC TCA related alarms - hgu-tr069 : hgu tr069 related alarms - eqpt-psu : equipment psu alarms - ont-protection : ONT protection related alarms - secondary-megaco-term : secondary megaco termination related alarms - secondary-sip-term : secondary sip termination related alarms - cas-r2-channel : CAS R2 channel related alarms - lldpmed : lldpmed alarms - pseudo-wire : pseudo Wire related alarms - link-agg : Link aggregation related alarms - fcs-exceed : FCS auto-recovery related alarms - e1t1-interface : E1/T1 physical interfaces related alarms	
name	Parameter type: <Alarm::almtypeEqptHoldExt> (network-power-loss hw-fault bat-miss bat-fail bat-low bat-a-fail bat-b-fail ac-vol-out-range network-power-loss-b sem-ac-power-fail sem-ups-low-volt)	alarm name that are active <i>This element is only shown in detail mode.</i>

101 query current alarms by filters

name	Type	Description
	dc-a-fail dc-b-fail plan-power-mismatch water-seepage-in-box sealed-box-open dc-a-vol-out-range dc-b-vol-out-range inlet-temp-major inlet-temp-critical all) Possible values: - network-power-loss : Loss of Network Power - hw-fault : Hardware Failure - bat-miss : Power Source Battery Missing - bat-fail : Power Source Battery Failure - bat-low : Power Source Battery Charge LOW - bat-a-fail : Power Source BAT-A Fail - bat-b-fail : Power Source BAT-B Fail - ac-vol-out-range : AC Input Voltage Value Out of Range - network-power-loss-b : Loss of Network Power B - sem-ac-power-fail : External AC power supply failure - sem-ups-low-volt : External power supply low voltage - dc-a-fail : Local DC A power failure - dc-b-fail : Local DC B power failure - plan-power-mismatch : Planned and detected power mode mismatch - water-seepage-in-box : Detected water seepage in enclosure - sealed-box-open : Sealed box open detected - dc-a-vol-out-range : DC A Input Voltage Value Out of Range - dc-b-vol-out-range : DC B Input Voltage Value Out of Range - inlet-temp-major : The inlet temperature has exceeded a major level - inlet-temp-critical : The inlet temperature has exceeded a critical level - all : show all equipment holder extent alarm	
severity	Parameter type: <Alarm::AlarmSeverity> (indeterminate warning minor major critical) Possible values: - indeterminate : alarm severity is indeterminate - warning : alarm severity is warning - minor : alarm severity is minor - major : alarm severity is major - critical : alarm severity is critical	the alarms severity level <i>This element is only shown in detail mode.</i>
servaff	Parameter type: <Alarm::alarmServAffect> ((service-affecting yes) (noservice-affecting no)) Possible values: - service-affecting : make this alarm service affecting - yes : make this alarm service affecting - noservice-affecting : make this alarm not service affecting	alarms affect service or not <i>This element is only shown in detail mode.</i>

101 query current alarms by filters

name	Type	Description
	- no : make this alarm not service affecting	
time	Parameter type: <Sys::timeInSecs> - the time (yyyy-mm-dd:hour:minutes:secs) - unit: UTC	time in seconds when alarm was updated <i>This element is only shown in detail mode.</i>
descript	Parameter type: <Alarm::AddInfoString> - additional alarm information	alarm description <i>This element is only shown in detail mode.</i>

101.5 show current alarm by filters

Command Description

show current alarms by filters

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm query plug-in-unit [ (name) [ severity <Alarm::querySeverity> ] [ servaff <Alarm::queryServAffect> ] [ board <Equipm::EqptSlotIndex> ] ]
```

Command Parameters

Table 101.5-1 "show current alarm by filters" Resource Parameters

Resource Identifier	Type	Description
(name)	Format: (board-mismatch waiting-for-sw temp-exceeded backplane-data-failure temp-shutdown board-missing board-instl-missing board-init board-reset-prot sem-power-fail sem-ups-fail board-reset-cf shub-uplink all) Possible values: - board-mismatch : board inserted different from planned - waiting-for-sw : not able to download all the applicable sw files - temp-exceeded : temperature threshold exceeded on the board - backplane-data-failure: It port on backplane data failure - temp-shutdown : board powered down itself - too high temperature - board-missing : board detected after planning - now missing - board-instl-missing : board never detected after planning - board-init : board initialisation failure	alarm name of plug-in-unit

Resource Identifier	Type	Description
	- board-reset-prot : number of resets exceeded - sem-power-fail : SEM external power failure - sem-ups-fail : SEM external power supply failure - board-reset-cf : board reset and/or communication failure - shub-uplink : lanx uplink breakdown or removal - all : show all equipment alarm	
severity	Parameter type: <Alarm::querySeverity> Format: (indeterminate warning minor major critical all) Possible values: - indeterminate : alarm severity is indeterminate - warning : alarm severity is warning - minor : alarm severity is minor - major : alarm severity is major - critical : alarm severity is critical - all : all alarm severity	severity level of alarm for reporting
servaff	Parameter type: <Alarm::queryServAffect> Format: (service-affecting noservice-affecting all) Possible values: - service-affecting : query alarm service affecting - noservice-affecting : query alarm not service affecting - all : query service affecting and not affecting alarms	serviceaffecting no
board	Parameter type: <Equipm::EqptSlotIndex> Format: (lt : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> nt-a nt-b nt acu : <Eqpt::RackId> / <Eqpt::ShelfId> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::EqSlotId> ext-a : <Eqpt::RackId> / <Eqpt::ShelfId> ext-b : <Eqpt::RackId> / <Eqpt::ShelfId> ctrl : <Eqpt::RackId> / <Eqpt::ShelfId> vlt : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::VirtualSlotId>) Possible values: - lt : lt-slot - vlt : virtual LT slot (VVPS board can only be planned at NANT-E / FANT-F) - nt-a : nt-a slot - nt-b : nt-b slot - nt : nt slot - ext-a : nt-a slot in an extension shelf - ext-b : nt-b slot in an extension shelf - acu : acu slot - ctrl : ctrl-slot Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId>	the physical number of the slot

101 query current alarms by filters

Resource Identifier	Type	Description
	- the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::VirtualSlotId> - the virtual LT slot number Field type <Eqpt::EqSlotId> - the equipment slot number	

Command Output

Table 101.5-2 "show current alarm by filters" Display parameters

Specific Information		
name	Type	Description
aidinfo	Parameter type: <Alarm::AddInfoString> - additional alarm information	alarm AID parameters <i>This element is only shown in detail mode.</i>
type	Parameter type: <Alarm::alarmIHUBType> (equipment eqpt-holder plug-in-unit atm custom e1 ima-group ima-link redundancy shdsl ether-itf traffic-overflow qos-queue temporal spatial (software-mngt sw-mgmt) xdsl xdsl-ext xdsl-tca olt-gen eo-conv authentication bonding sfp shdsl-isam custom-ext-alarm plug-in-unit-ext sip-user-agent sip-plugin-unit sip-termination e1-sip-termination filetransfer external-device l2forward ether-tca ether-sfp megaco-media-gw megaco-sig-gw megaco-plugin-unit)	type of the alarms that are active <i>This element is only shown in detail mode.</i>

name	Type	Description
	megaco-term megaco-sig-lt eqpt-supplemental eqpt-holder-ext lsmredundancy sync mcsrc vlanport vect-line vect-board otdr sip-dial-plan sip-vsp sip-server bgp rip lag ihub-general vprn isis ospf ihub-l2forward vpls ihub-equip ihub-link eont-phyoam ellid epon eont-services-lan eolt-ont-tca eont-sw-dl ldp mpls sdp epipe ihub-ipv6 pim li mgmt-sec-access bfd ai tr069serv ontsnmp bulk-sync protection-group ont sfu-sup soho-sup mdu-sup ont-ani sfu-sup2 soho-sup2 mdu-sup2 sfprssi eoltrssi cfm sfpe1t1-framer	

101 query current alarms by filters

name	Type	Description
	sfpe1t1-clock pppcc-engine-tca eth-cfm rsvp ihub-tca eth-ring efm-oam ont-loopdetect ont-video ont-ces ont-voip ont-video-ani ont-pwe ont-cese1 ont-xdsl ont-xdsl-tca ont-hpna ont-sip-agent-cfg ont-voip-cfg ont-mgc ont-ploam ont-gen ont-card ont-pots ont-lan ont-moca ont-tc-tca ont-moca-tca ont-l2uni-eth-tca olt-pon-tc-tca olt-pon-util-tca olt-chpr-util-tca olt-ont-tc-tca ont-tca ont-pots-supplemental sfu-ploam sfu-gen soho-ploam soho-gen mdu-ploam mdu-gen ont-veip ont-iphost alarm-table auto-switch channel-pair ont-cfg-dld olt-chpair-tc-tca hgu-tr069 eqpt-psu ont-protection secondary-megaco-term secondary-sip-term cas-r2-channel lldpmed pseudo-wire link-agg	

name	Type	Description
	fcs-exceed e1t1-interface) Possible values: - equipment : equipment alarms - eqpt-holder : equipment holder alarms - plug-in-unit : plugin unit alarms - atm : ATM alarms - custom : customizable alarms - e1 : e1 alarms - ima-group : ima-group alarms - ima-link : ima-link alarms - redundancy : redundancy alarms - shdsl : shdsl alarms - ether-itf : ethernet interface alarms - traffic-overflow : Traffic overflow alarms - qos-queue : qos queue alarms - temporal : temporal alarms - spatial : spatial alarms - software-mngt : software management alarms - sw-mgmt : software management alarms - xdsl : xDSL alarms - xdsl-ext : other xDSL alarms - xdsl-tca : xDSL threshold cross alarms - olt-gen : OLT general alarms - eo-conv : E/O conversion related alarms - authentication : authentication related alarms - bonding : bonding-group related alarms - sfp : SFP related alarms - shdsl-isam : shdsl isam alarms - custom-ext-alarm : customizable external alarms - plug-in-unit-ext : other plugin unit alarms - sip-user-agent : sip user agent related alarms - sip-plugin-unit : sip plug in unit related alarms - sip-termination : sip termination related alarms - e1-sip-termination : E1 sip termination related alarms - filetransfer : file transfer server alarms - external-device : external device related alarms - l2forward : l2forward related alarms - ether-tca : ethernet threshold cross alarms - ether-sfp : ethernet SFP related alarms - megaco-media-gw : megaco media gateway related alarms - megaco-sig-gw : megaco signaling gateway related alarms - megaco-plug-unit : megaco plug unit related alarms - megaco-term : megaco termination related alarms - megaco-sig-lt : megaco signaling lt related alarms - eqpt-supplemental : equipment supplemental alarms - eqpt-holder-ext : other equipment holder alarms - lsmredundancy : lsm redundancy alarms - sync : synce and bits alarms - mcsrc : multicast source alarms - vlanport : vlanport alarms - vect-line : xDSL vectoring line alarms - vect-board : xDSL vectoring board alarms - otdr : otdr alarms - sip-dial-plan : sip dial plan related alarms - sip-vsp : sip vsp related alarms - sip-server : sip server related alarms	

101 query current alarms by filters

name	Type	Description
	- bgp : bgp related alarms - rip : rip related alarms - lag : LAG related alarms - ihub-general : IHUB general related alarms - vprn : vprn related alarms - isis : isis related alarms - ospf : ospf related alarms - ihub-l2forward : ihub-l2forward alarms - vpls : vpls related alarms - ihub-equip : ihub-equip related alarms - ihub-link : ihub-link related alarms - eont-phyoam : eont phyoam related alarms - ellid : ellid related alarms - epon : epon related alarms - eont-services-lan : eon phyoam related alarms - eolt-ont-tca : eon phyoam related alarms - eont-sw-dl : eon phyoam related alarms - ldp : ldp related alarms - mpls : mpls related alarms - sdp : sdp related alarms - epipe : epipe related alarms - ihub-ipv6 : ihub-ipv6 related alarms - pim : pim related alarms - li : lawful intercept related alarms - mgmt-sec-access : management security related alarms - bfd : bfd related alarms - ai : Application Intelligence related alarms - tr069serv : tr069 server related alarms - ontsnmp : ont snmp related alarms - bulk-sync : bulk-sync related alarms - protection-group : port protection group related alarms - ont : ONT general supplemental related alarms - sfu-sup : SFU ONT general supplemental related alarms - soho-sup : SOHO ONT general supplemental related alarms - mdu-sup : MDU ONT general supplemental related alarms - ont-ani : ONT general supplemental 2 related alarms - sfu-sup2 : SFU ONT general supplemental 2 related alarms - soho-sup2 : SOHO ONT general supplemental 2 related alarms - mdu-sup2 : MDU ONT general supplemental 2 related alarms - sfprssi : SFP RSSI related alarms - eoltrssi : epon olt Sfp RSSI related alarms - cfm : Cfm related alarms - sfpe1t1-framer : SFP 2e1t1 framer alarms - sfpe1t1-clock : SFP 2e1t1 clock alarms - pppcc-engine-tca : PPPOE Cross Connect Engine TCA related alarm - eth-cfm : eth-cfm related alarms - rsvp : rsvp related alarms - ihub-tca : IHUB TCA related alarms - eth-ring : eth-ring related alarms - efm-oam : EFM-OAM related alarms - ont-loopdetect : ont loop detect related alarms - ont-video : ont services video related alarms - ont-ces : ont services ces related alarms	

name	Type	Description
	- ont-voip : ont services voip related alarms - ont-video-ani : ont services video ani related alarms - ont-pwe : ont services pwe related alarms - ont-cese1 : ont services cese1 related alarms - ont-xdsl : ont services xdsl related alarms - ont-xdsl-tca : ont services xdsl tca related alarms - ont-hpna : ont hpna related alarms - ont-sip-agent-cfg : ont services voip sip agent config related alarms - ont-voip-cfg : ont services voip config related alarms - ont-mgc : ont mgc related alarms - ont-ploam : ONT PLOAM related alarms - ont-gen : ONT GENERAL related alarms - ont-card : ONT Subscriber Card related alarms - ont-pots : ONT Services POTS related alarms - ont-lan : ONT Services LAN related alarms - ont-moca : ONT MoCA related alarms - ont-tc-tca : ONT TC TCA related alarms - ont-moca-tca : ONT MoCA TCA related alarms - ont-l2uni-eth-tca : ONT L2 UNI Ethernet TCA related alarms - olt-pon-tc-tca : OLT PON TC TCA related alarms - olt-pon-util-tca : OLT PON utilization TCA related alarms - olt-chpr-util-tca : OLT channel-pair utilization TCA related alarms - olt-ont-tc-tca : OLT ONT TC TCA related alarms - ont-tca : ONT TCA related alarms - ont-pots-supplemental : ONT POTS Supplemental related alarms - sfu-ploam : SFU ONT PLOAM related alarms - sfu-gen : SFU ONT general related alarms - soho-ploam : SOHO ONT PLOAM related alarms - soho-gen : SOHO ONT general related alarms - mdu-ploam : MDU ONT PLOAM related alarms - mdu-gen : MDU ONT general related alarms - ont-veip : ONT VEIP related alarms - ont-iphost : ONT IP HOST related alarms - alarm-table : alarm table related alarms - auto-switch : auto-switch related alarms - channel-pair : channel pair related alarms - ont-cfg-dld : ont configure file download related alarms - olt-chpair-tc-tca : OLT CHANNELPAIR TC TCA related alarms - hgu-tr069 : hgu tr069 related alarms - eqpt-psu : equipment psu alarms - ont-protection : ONT protection related alarms - secondary-megaco-term : secondary megaco termination related alarms - secondary-sip-term : secondary sip termination related alarms - cas-r2-channel : CAS R2 channel related alarms - lldpmed : lldpmed alarms - pseudo-wire : pseudo Wire related alarms - link-agg : Link aggregation related alarms - fcs-exceed : FCS auto-recovery related alarms - e1t1-interface : E1/T1 physical interfaces related alarms	
name	Parameter type: <Alarm::almtypPluginunit>	alarm name that are active

101 query current alarms by filters

name	Type	Description
	(board-mismatch waiting-for-sw temp-exceeded backplane-data-failure temp-shutdown board-missing board-instl-missing board-init board-reset-prot sem-power-fail sem-ups-fail board-reset-cf shub-uplink all) Possible values: - board-mismatch : board inserted different from planned - waiting-for-sw : not able to download all the applicable sw files - temp-exceeded : temperature threshold exceeded on the board - backplane-data-failure: It port on backplane data failure - temp-shutdown : board powered down itself - too high temperature - board-missing : board detected after planning - now missing - board-instl-missing : board never detected after planning - board-init : board initialisation failure - board-reset-prot : number of resets exceeded - sem-power-fail : SEM external power failure - sem-ups-fail : SEM external power supply failure - board-reset-cf : board reset and/or communication failure - shub-uplink : lanx uplink breakdown or removal - all : show all equipment alarm	<i>This element is only shown in detail mode.</i>
severity	Parameter type: <Alarm::AlarmSeverity> (indeterminate warning minor major critical) Possible values: - indeterminate : alarm severity is indeterminate - warning : alarm severity is warning - minor : alarm severity is minor - major : alarm severity is major - critical : alarm severity is critical	the alarms severity level <i>This element is only shown in detail mode.</i>
servaff	Parameter type: <Alarm::alarmServAffect> ((service-affecting yes) (noservice-affecting no)) Possible values: - service-affecting : make this alarm service affecting - yes : make this alarm service affecting - noservice-affecting : make this alarm not service affecting - no : make this alarm not service affecting	alarms affect service or not <i>This element is only shown in detail mode.</i>
time	Parameter type: <Sys::timeInSecs> - the time (yyyy-mm-dd:hour:minutes:secs) - unit: UTC	time in seconds when alarm was updated <i>This element is only shown in detail mode.</i>

101 query current alarms by filters

name	Type	Description
descript	Parameter type: <Alarm::AddInfoString> - additional alarm information	alarm description <i>This element is only shown in detail mode.</i>

101.6 show current alarm by filters

Command Description

show current alarms by filters

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm query plug-in-unit-ext [ (name) [ severity <Alarm::querySeverity> ] [ servaff
<Alarm::queryServAffect> ] [ board <Equipm::EqptSlotIndex> ] ]
```

Command Parameters

Table 101.6-1 "show current alarm by filters" Resource Parameters

Resource Identifier	Type	Description
(name)	Format: (pluginfan plugin-dc-a plugin-dc-b plugin-dg apsf-alarm ntr-a-loss ntr-b-loss xvps-conf-loss mac-entry-nofree fibre-conn-mismatch link-cap-mismatch eqpt-cap-mismatch ctrl-dnld-failure melt-hw-issue melt-board-reset board-shelf-mismatch mgnt-type-mismatch all) Possible values: - pluginfan : REM Fan Alarm - plugin-dc-a : REM DC A Alarm - plugin-dc-b : REM DC B Alarm - plugin-dg : Dying Gasp Alarm - apsf-alarm : Applique Power Supply Failure - ntr-a-loss : NTR-A signal is not available - ntr-b-loss : NTR-B signal is not available - xvps-conf-loss : xvps configuration loss	alarm name of plug-in-unit-ext

Resource Identifier	Type	Description
	- mac-entry-nofree : no free mac entry in the mac table on lt board - fibre-conn-mismatch : REM Fibre Connection Mismatch Alarm - link-cap-mismatch : Link speed capability mismatch - eqpt-cap-mismatch : Link equipment capability mismatch - ctrl-dnld-failure : Controller card download failure - melt-hw-issue : MELT hardware issue - melt-board-reset : MELT board reset - board-shelf-mismatch : board type and shelf type mismatch - mgnt-type-mismatch : Board management type mismatch - all : show all bgp alarm	
severity	Parameter type: <Alarm::querySeverity> Format: (indeterminate warning minor major critical all) Possible values: - indeterminate : alarm severity is indeterminate - warning : alarm severity is warning - minor : alarm severity is minor - major : alarm severity is major - critical : alarm severity is critical - all : all alarm severity	severity level of alarm for reporting
servaff	Parameter type: <Alarm::queryServAffect> Format: (service-affecting noservice-affecting all) Possible values: - service-affecting : query alarm service affecting - noservice-affecting : query alarm not service affecting - all : query service affecting and not affecting alarms	serviceaffecting no serviceaffecting
board	Parameter type: <Equipm::EqptSlotIndex> Format: (lt : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> nt-a nt-b nt acu : <Eqpt::RackId> / <Eqpt::ShelfId> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::EqSlotId> ext-a : <Eqpt::RackId> / <Eqpt::ShelfId> ext-b : <Eqpt::RackId> / <Eqpt::ShelfId> ctrl : <Eqpt::RackId> / <Eqpt::ShelfId> vlt : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::VirtualSlotId>) Possible values: - lt : lt-slot - vlt : virtual LT slot (VVPS board can only be planned at NANT-E / FANT-F) - nt-a : nt-a slot - nt-b : nt-b slot - nt : nt slot - ext-a : nt-a slot in an extension shelf	the physical number of the slot

101 query current alarms by filters

Resource Identifier	Type	Description
	- ext-b : nt-b slot in an extension shelf - acu : acu slot - ctrl : ctrl-slot Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::VirtualSlotId> - the virtual LT slot number Field type <Eqpt::EqSlotId> - the equipment slot number	

Command Output

Table 101.6-2 "show current alarm by filters" Display parameters

Specific Information		
name	Type	Description
aidinfo	Parameter type: <Alarm::AddInfoString> - additional alarm information	alarm AID parameters <i>This element is only shown in detail mode.</i>
type	Parameter type: <Alarm::alarmIHUBType> (equipment eqpt-holder plug-in-unit atm custom e1 ima-group ima-link redundancy shdsl ether-itf traffic-overflow qos-queue temporal spatial (software-mngt sw-mgmt) xdsl xdsl-ext xdsl-tca olt-gen eo-conv authentication bonding sfp shdsl-isam custom-ext-alarm plug-in-unit-ext sip-user-agent sip-plugin-unit sip-termination e1-sip-termination filetransfer external-device)	type of the alarms that are active <i>This element is only shown in detail mode.</i>

name	Type	Description
	l2forward	
	ether-tca	
	ether-sfp	
	megaco-media-gw	
	megaco-sig-gw	
	megaco-plug-unit	
	megaco-term	
	megaco-sig-lt	
	eqpt-supplemental	
	eqpt-holder-ext	
	lsmredundancy	
	sync	
	mcsrc	
	vlanport	
	vect-line	
	vect-board	
	otdr	
	sip-dial-plan	
	sip-vsp	
	sip-server	
	bgp	
	rip	
	lag	
	ihub-general	
	vprn	
	isis	
	ospf	
	ihub-l2forward	
	vpls	
	ihub-equip	
	ihub-link	
	eont-phyoam	
	ellid	
	epon	
	eont-services-lan	
	eolt-ont-tca	
	eont-sw-dl	
	ldp	
	mpls	
	sdp	
	epipe	
	ihub-ipv6	
	pim	
	li	
	mgmt-sec-access	
	bfd	
	ai	
	tr069serv	
	ontsnmp	
	bulk-sync	
	protection-group	
	ont	
	sfu-sup	
	soho-sup	
	mdu-sup	
	ont-ani	
	sfu-sup2	

101 query current alarms by filters

name	Type	Description
	soho-sup2	
	mdu-sup2	
	sfprssi	
	eoltrssi	
	cfm	
	sfpe1t1-framer	
	sfpe1t1-clock	
	pppcc-engine-tca	
	eth-cfm	
	rsvp	
	ihub-tca	
	eth-ring	
	efm-oam	
	ont-loopdetect	
	ont-video	
	ont-ces	
	ont-voip	
	ont-video-ani	
	ont-pwe	
	ont-cese1	
	ont-xdsl	
	ont-xdsl-tca	
	ont-hpna	
	ont-sip-agent-cfg	
	ont-voip-cfg	
	ont-mgc	
	ont-ploam	
	ont-gen	
	ont-card	
	ont-pots	
	ont-lan	
	ont-moca	
	ont-tc-tca	
	ont-moca-tca	
	ont-l2uni-eth-tca	
	olt-pon-tc-tca	
	olt-pon-util-tca	
	olt-chpr-util-tca	
	olt-ont-tc-tca	
	ont-tca	
	ont-pots-supplemental	
	sfu-ploam	
	sfu-gen	
	soho-ploam	
	soho-gen	
	mdu-ploam	
	mdu-gen	
	ont-veip	
	ont-iphost	
	alarm-table	
	auto-switch	
	channel-pair	
	ont-cfg-dld	
	olt-chpair-tc-tca	
	hgu-tr069	
	eqpt-psu	
	ont-protection	

name	Type	Description
	secondary-megaco-term secondary-sip-term cas-r2-channel lldpmed pseudo-wire link-agg fcs-exceed e1t1-interface) Possible values: - equipment : equipment alarms - eqpt-holder : equipment holder alarms - plug-in-unit : plugin unit alarms - atm : ATM alarms - custom : customizable alarms - e1 : e1 alarms - ima-group : ima-group alarms - ima-link : ima-link alarms - redundancy : redundancy alarms - shdsl : shdsl alarms - ether-itf : ethernet interface alarms - traffic-overflow : Traffic overflow alarms - qos-queue : qos queue alarms - temporal : temporal alarms - spatial : spatial alarms - software-mngt : software management alarms - sw-mgmt : software management alarms - xdsl : xDSL alarms - xdsl-ext : other xDSL alarms - xdsl-tca : xDSL threshold cross alarms - olt-gen : OLT general alarms - eo-conv : E/O conversion related alarms - authentication : authentication related alarms - bonding : bonding-group related alarms - sfp : SFP related alarms - shdsl-isam : shdsl isam alarms - custom-ext-alarm : customizable external alarms - plug-in-unit-ext : other plugin unit alarms - sip-user-agent : sip user agent related alarms - sip-plugin-unit : sip plug in unit related alarms - sip-termination : sip termination related alarms - e1-sip-termination : E1 sip termination related alarms - filetransfer : file transfer server alarms - external-device : external device related alarms - l2forward : l2forward related alarms - ether-tca : ethernet threshold cross alarms - ether-sfp : ethernet SFP related alarms - megaco-media-gw : megaco media gateway related alarms - megaco-sig-gw : megaco signaling gateway related alarms - megaco-plug-unit : megaco plug unit related alarms - megaco-term : megaco termination related alarms - megaco-sig-lt : megaco signaling lt related alarms - eqpt-supplemental : equipment supplemental alarms - eqpt-holder-ext : other equipment holder alarms - lsmredundancy : lsm redundancy alarms - sync : synce and bits alarms - mcsrc : multicast source alarms - vlanport : vlanport alarms	

101 query current alarms by filters

name	Type	Description
	- vect-line : xDSL vectoring line alarms - vect-board : xDSL vectoring board alarms - otdr : otdr alarms - sip-dial-plan : sip dial plan related alarms - sip-vsp : sip vsp related alarms - sip-server : sip server related alarms - bgp : bgp related alarms - rip : rip related alarms - lag : LAG related alarms - ihub-general : IHUB general related alarms - vprn : vprn related alarms - isis : isis related alarms - ospf : ospf related alarms - ihub-l2forward : ihub-l2forward alarms - vpls : vpls related alarms - ihub-equip : ihub-equip related alarms - ihub-link : ihub-link related alarms - eont-phyoam : eont phyoam related alarms - ellid : ellid related alarms - epon : epon related alarms - eont-services-lan : eon phyoam related alarms - eolt-ont-tca : eon phyoam related alarms - eont-sw-dl : eon phyoam related alarms - ldp : ldp related alarms - mpls : mpls related alarms - sdp : sdp related alarms - epipe : epipe related alarms - ihub-ipv6 : ihub-ipv6 related alarms - pim : pim related alarms - li : lawful intercept related alarms - mgmt-sec-access : management security related alarms - bfd : bfd related alarms - ai : Application Intelligence related alarms - tr069serv : tr069 server related alarms - ontsnmp : ont snmp related alarms - bulk-sync : bulk-sync related alarms - protection-group : port protection group related alarms - ont : ONT general supplemental related alarms - sfu-sup : SFU ONT general supplemental related alarms - soho-sup : SOHO ONT general supplemental related alarms - mdu-sup : MDU ONT general supplemental related alarms - ont-ani : ONT general supplemental 2 related alarms - sfu-sup2 : SFU ONT general supplemental 2 related alarms - soho-sup2 : SOHO ONT general supplemental 2 related alarms - mdu-sup2 : MDU ONT general supplemental 2 related alarms - sfprssi : SFP RSSI related alarms - eoltrssi : epon olt Sfp RSSI related alarms - cfm : Cfm related alarms - sfpe1t1-framer : SFP 2e1t1 framer alarms - sfpe1t1-clock : SFP 2e1t1 clock alarms - pppcc-engine-tca : PPPOE Cross Connect Engine TCA related alarm - eth-cfm : eth-cfm related alarms - rsvp : rsvp related alarms	

name	Type	Description
	- ihub-tca : IHUB TCA related alarms - eth-ring : eth-ring related alarms - efm-oam : EFM-OAM related alarms - ont-loopdetect : ont loop detect related alarms - ont-video : ont services video related alarms - ont-ces : ont services ces related alarms - ont-voip : ont services voip related alarms - ont-video-ani : ont services video ani related alarms - ont-pwe : ont services pwe related alarms - ont-cese1 : ont services cese1 related alarms - ont-xdsl : ont services xdsl related alarms - ont-xdsl-tca : ont services xdsl tca related alarms - ont-hpna : ont hpna related alarms - ont-sip-agent-cfg : ont services voip sip agent config related alarms - ont-voip-cfg : ont services voip config related alarms - ont-mgc : ont mgc related alarms - ont-ploam : ONT PLOAM related alarms - ont-gen : ONT GENERAL related alarms - ont-card : ONT Subscriber Card related alarms - ont-pots : ONT Services POTS related alarms - ont-lan : ONT Services LAN related alarms - ont-moca : ONT MoCA related alarms - ont-tc-tca : ONT TC TCA related alarms - ont-moca-tca : ONT MoCA TCA related alarms - ont-l2uni-eth-tca : ONT L2 UNI Ethernet TCA related alarms - olt-pon-tc-tca : OLT PON TC TCA related alarms - olt-pon-util-tca : OLT PON utilization TCA related alarms - olt-chpr-util-tca : OLT channel-pair utilization TCA related alarms - olt-ont-tc-tca : OLT ONT TC TCA related alarms - ont-tca : ONT TCA related alarms - ont-pots-supplemental : ONT POTS Supplemental related alarms - sfu-ploam : SFU ONT PLOAM related alarms - sfu-gen : SFU ONT general related alarms - soho-ploam : SOHO ONT PLOAM related alarms - soho-gen : SOHO ONT general related alarms - mdu-ploam : MDU ONT PLOAM related alarms - mdu-gen : MDU ONT general related alarms - ont-veip : ONT VEIP related alarms - ont-iphost : ONT IP HOST related alarms - alarm-table : alarm table related alarms - auto-switch : auto-switch related alarms - channel-pair : channel pair related alarms - ont-cfg-dld : ont configure file download related alarms - olt-chpair-tc-tca : OLT CHANNELPAIR TC TCA related alarms - hgu-tr069 : hgu tr069 related alarms - eqpt-psu : equipment psu alarms - ont-protection : ONT protection related alarms - secondary-megaco-term : secondary megaco termination related alarms - secondary-sip-term : secondary sip termination related alarms - cas-r2-channel : CAS R2 channel related alarms	

101 query current alarms by filters

name	Type	Description
	- lldpmed : lldpmed alarms - pseudo-wire : pseudo Wire related alarms - link-aggr : Link aggregation related alarms - fcs-exceed : FCS auto-recovery related alarms - e1t1-interface : E1/T1 physical interfaces related alarms	
name	Parameter type: <Alarm::almtypePluginunitext> (pluginfan plugin-dc-a plugin-dc-b plugin-dg apsf-alarm ntr-a-loss ntr-b-loss xvps-conf-loss mac-entry-nofree fibre-conn-mismatch link-cap-mismatch eqpt-cap-mismatch ctrl-dnld-failure melt-hw-issue melt-board-reset board-shelf-mismatch mgnt-type-mismatch all) Possible values: - pluginfan : REM Fan Alarm - plugin-dc-a : REM DC A Alarm - plugin-dc-b : REM DC B Alarm - plugin-dg : Dying Gasp Alarm - apsf-alarm : Applique Power Supply Failure - ntr-a-loss : NTR-A signal is not available - ntr-b-loss : NTR-B signal is not available - xvps-conf-loss : xvps configuration loss - mac-entry-nofree : no free mac entry in the mac table on lt board - fibre-conn-mismatch : REM Fibre Connection Mismatch Alarm - link-cap-mismatch : Link speed capability mismatch - eqpt-cap-mismatch : Link equipment capability mismatch - ctrl-dnld-failure : Controller card download failure - melt-hw-issue : MELT hardware issue - melt-board-reset : MELT board reset - board-shelf-mismatch : board type and shelf type mismatch - mgnt-type-mismatch : Board management type mismatch - all : show all bgp alarm	alarm name that are active <i>This element is only shown in detail mode.</i>
severity	Parameter type: <Alarm::AlarmSeverity> (indeterminate warning minor major critical) Possible values: - indeterminate : alarm severity is indeterminate - warning : alarm severity is warning - minor : alarm severity is minor - major : alarm severity is major - critical : alarm severity is critical	the alarms severity level <i>This element is only shown in detail mode.</i>

name	Type	Description
servaff	Parameter type: <Alarm::alarmServAffect> ((service-affecting yes) (noservice-affecting no)) Possible values: - service-affecting : make this alarm service affecting - yes : make this alarm service affecting - noservice-affecting : make this alarm not service affecting - no : make this alarm not service affecting	alarms affect service or not <i>This element is only shown in detail mode.</i>
time	Parameter type: <Sys::timeInSecs> - the time (yyyy-mm-dd:hour:minutes:secs) - unit: UTC	time in seconds when alarm was updated <i>This element is only shown in detail mode.</i>
descript	Parameter type: <Alarm::AddInfoString> - additional alarm information	alarm description <i>This element is only shown in detail mode.</i>

101.7 show current alarm by filters

Command Description

show current alarms by filters

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm query sw-mgmt [ (name) [ severity <Alarm::querySeverity> ] [ servaff <Alarm::queryServAffect> ] [ board <Equipm::EqptSlotIndex> ] ]
```

Command Parameters

Table 101.7-1 "show current alarm by filters" Resource Parameters

Resource Identifier	Type	Description
(name)	Format: (sw-rollback db-rollback xvps-inv-dbase inv-cde-file miss-cde-file cde-hash-error auto-fetch-failure low-disk-space all) Possible values: - sw-rollback : non active oswp,db cannot be operational - will rollback - db-rollback : selected oswp,db cannot be operational - will rollback - xvps-inv-dbase : invalid xvps dbase - inv-cde-file : invalid xvps cde file - miss-cde-file : missing cde profile - cde-hash-error : cde profile hash error - auto-fetch-failure : not able to fetch file from specified server - low-disk-space : insufficient space for Sw storage - all : show all sw-mgmt alarm	alarm name of sw-mgmt
severity	Parameter type: <Alarm::querySeverity> Format: (indeterminate warning minor	severity level of an alarm for reporting

Resource Identifier	Type	Description
	major critical all) Possible values: - indeterminate : alarm severity is indeterminate - warning : alarm severity is warning - minor : alarm severity is minor - major : alarm severity is major - critical : alarm severity is critical - all : all alarm severity	
servaff	Parameter type: <Alarm::queryServAffect> Format: (service-affecting noservice-affecting all) Possible values: - service-affecting : query alarm service affecting - noservice-affecting : query alarm not service affecting - all : query service affecting and not affecting alarms	serviceaffecting no serviceaffecting
board	Parameter type: <Equipm::EqptSlotIndex> Format: (lt : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> nt-a nt-b nt acu : <Eqpt::RackId> / <Eqpt::ShelfId> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::EqSlotId> ext-a : <Eqpt::RackId> / <Eqpt::ShelfId> ext-b : <Eqpt::RackId> / <Eqpt::ShelfId> ctrl : <Eqpt::RackId> / <Eqpt::ShelfId> vlt : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::VirtualSlotId>) Possible values: - lt : lt-slot - vlt : virtual LT slot (VVPS board can only be planned at NANT-E / FANT-F) - nt-a : nt-a slot - nt-b : nt-b slot - nt : nt slot - ext-a : nt-a slot in an extension shelf - ext-b : nt-b slot in an extension shelf - acu : acu slot - ctrl : ctrl-slot Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::VirtualSlotId> - the virtual LT slot number Field type <Eqpt::EqSlotId> - the equipment slot number	the physical number of the slot

Command Output

Table 101.7-2 "show current alarm by filters" Display parameters

Specific Information		
name	Type	Description
aidinfo	Parameter type: <Alarm::AddInfoString> - additional alarm information	alarm AID parameters <i>This element is only shown in detail mode.</i>
type	Parameter type: <Alarm::alarmIHUBType> (equipment eqpt-holder plug-in-unit atm custom e1 ima-group ima-link redundancy shdsl ether-itf traffic-overflow qos-queue temporal spatial (software-mngt sw-mgmt) xdsl xdsl-ext xdsl-tca olt-gen eo-conv authentication bonding sfp shdsl-isam custom-ext-alarm plug-in-unit-ext sip-user-agent sip-plugin-unit sip-termination e1-sip-termination filetransfer external-device l2forward ether-tca ether-sfp megaco-media-gw megaco-sig-gw megaco-plug-unit megaco-term megaco-sig-lt eqpt-supplemental eqpt-holder-ext lsmredundancy sync mcsrc vlanport vect-line vect-board otdr	type of the alarms that are active <i>This element is only shown in detail mode.</i>

name	Type	Description
	sip-dial-plan sip-vsp sip-server bgp rip lag ihub-general vprn isis ospf ihub-l2forward vpls ihub-equip ihub-link eont-phyoam ellid epon eont-services-lan eolt-ont-tca eont-sw-dl ldp mpls sdp epipe ihub-ipv6 pim li mgmt-sec-access bfd ai tr069serv ontsnmp bulk-sync protection-group ont sfu-sup soho-sup mdu-sup ont-ani sfu-sup2 soho-sup2 mdu-sup2 sfprssi eoltrssi cfm sfpe1t1-framer sfpe1t1-clock pppcc-engine-tca eth-cfm rsvp ihub-tca eth-ring efm-oam ont-loopdetect ont-video ont-ces ont-voip	

101 query current alarms by filters

name	Type	Description
	ont-video-ani ont-pwe ont-cese1 ont-xdsl ont-xdsl-tca ont-hpna ont-sip-agent-cfg ont-voip-cfg ont-mgc ont-ploam ont-gen ont-card ont-pots ont-lan ont-moca ont-tc-tca ont-moca-tca ont-l2uni-eth-tca olt-pon-tc-tca olt-pon-util-tca olt-chpr-util-tca olt-ont-tc-tca ont-tca ont-pots-supplemental sfu-ploam sfu-gen soho-ploam soho-gen mdu-ploam mdu-gen ont-veip ont-iphost alarm-table auto-switch channel-pair ont-cfg-dld olt-chpair-tc-tca hgu-tr069 eqpt-psu ont-protection secondary-megaco-term secondary-sip-term cas-r2-channel lldpmed pseudo-wire link-agg fcs-exceed e1t1-interface) Possible values: - equipment : equipment alarms - eqpt-holder : equipment holder alarms - plug-in-unit : plugin unit alarms - atm : ATM alarms - custom : customizable alarms - e1 : e1 alarms - ima-group : ima-group alarms - ima-link : ima-link alarms	

name	Type	Description
	- redundancy : redundancy alarms - shdsl : shdsl alarms - ether-itf : ethernet interface alarms - traffic-overflow : Traffic overflow alarms - qos-queue : qos queue alarms - temporal : temporal alarms - spatial : spatial alarms - software-mngt : software management alarms - sw-mgmt : software management alarms - xdsl : xDSL alarms - xdsl-ext : other xDSL alarms - xdsl-tca : xDSL threshold cross alarms - olt-gen : OLT general alarms - eo-conv : E/O conversion related alarms - authentication : authentication related alarms - bonding : bonding-group related alarms - sfp : SFP related alarms - shdsl-isam : shdsl isam alarms - custom-ext-alarm : customizable external alarms - plug-in-unit-ext : other plugin unit alarms - sip-user-agent : sip user agent related alarms - sip-plugin-unit : sip plug in unit related alarms - sip-termination : sip termination related alarms - e1-sip-termination : E1 sip termination related alarms - filetransfer : file transfer server alarms - external-device : external device related alarms - l2forward : l2forward related alarms - ether-tca : ethernet threshold cross alarms - ether-sfp : ethernet SFP related alarms - megaco-media-gw : megaco media gateway related alarms - megaco-sig-gw : megaco signaling gateway related alarms - megaco-plug-unit : megaco plug unit related alarms - megaco-term : megaco termination related alarms - megaco-sig-lt : megaco signaling lt related alarms - eqpt-supplemental : equipment supplemental alarms - eqpt-holder-ext : other equipment holder alarms - lsmredundancy : lsm redundancy alarms - sync : synce and bits alarms - mcsrc : multicast source alarms - vlanport : vlanport alarms - vect-line : xDSL vectoring line alarms - vect-board : xDSL vectoring board alarms - otdr : otdr alarms - sip-dial-plan : sip dial plan related alarms - sip-vsp : sip vsp related alarms - sip-server : sip server related alarms - bgp : bgp related alarms - rip : rip related alarms - lag : LAG related alarms - ihub-general : IHUB general related alarms - vprn : vprn related alarms - isis : isis related alarms - ospf : ospf related alarms - ihub-l2forward : ihub-l2forward alarms - vpls : vpls related alarms - ihub-equip : ihub-equip related alarms - ihub-link : ihub-link related alarms	

101 query current alarms by filters

name	Type	Description
	- eont-phyoam : eont phyoam related alarms - ellid : ellid related alarms - epon : epon related alarms - eont-services-lan : eon phyoam related alarms - eolt-ont-tca : eon phyoam related alarms - eont-sw-dl : eon phyoam related alarms - ldp : ldp related alarms - mpls : mpls related alarms - sdp : sdp related alarms - epipe : epipe related alarms - ihub-ipv6 : ihub-ipv6 related alarms - pim : pim related alarms - li : lawful intercept related alarms - mgmt-sec-access : management security related alarms - bfd : bfd related alarms - ai : Application Intelligence related alarms - tr069serv : tr069 server related alarms - ontsnmp : ont snmp related alarms - bulk-sync : bulk-sync related alarms - protection-group : port protection group related alarms - ont : ONT general supplemental related alarms - sfu-sup : SFU ONT general supplemental related alarms - soho-sup : SOHO ONT general supplemental related alarms - mdu-sup : MDU ONT general supplemental related alarms - ont-ani : ONT general supplemental 2 related alarms - sfu-sup2 : SFU ONT general supplemental 2 related alarms - soho-sup2 : SOHO ONT general supplemental 2 related alarms - mdu-sup2 : MDU ONT general supplemental 2 related alarms - sfprssi : SFP RSSI related alarms - eoltrssi : epon olt Sfp RSSI related alarms - cfm : Cfm related alarms - sfpe1t1-framer : SFP 2e1t1 framer alarms - sfpe1t1-clock : SFP 2e1t1 clock alarms - pppcc-engine-tca : PPPOE Cross Connect Engine TCA related alarm - eth-cfm : eth-cfm related alarms - rsvp : rsvp related alarms - ihub-tca : IHUB TCA related alarms - eth-ring : eth-ring related alarms - efm-oam : EFM-OAM related alarms - ont-loopdetect : ont loop detect related alarms - ont-video : ont services video related alarms - ont-ces : ont services ces related alarms - ont-voip : ont services voip related alarms - ont-video-ani : ont services video ani related alarms - ont-pwe : ont services pwe related alarms - ont-cese1 : ont services cese1 related alarms - ont-xdsl : ont services xdsl related alarms - ont-xdsl-tca : ont services xdsl tca related alarms - ont-hpna : ont hpna related alarms - ont-sip-agent-cfg : ont services voip sip agent config related alarms - ont-voip-cfg : ont services voip config related alarms - ont-mgc : ont mgc related alarms	

name	Type	Description
	- ont-ploam : ONT PLOAM related alarms - ont-gen : ONT GENERAL related alarms - ont-card : ONT Subscriber Card related alarms - ont-pots : ONT Services POTS related alarms - ont-lan : ONT Services LAN related alarms - ont-moca : ONT MoCA related alarms - ont-tc-tca : ONT TC TCA related alarms - ont-moca-tca : ONT MoCA TCA related alarms - ont-l2uni-eth-tca : ONT L2 UNI Ethernet TCA related alarms - olt-pon-tc-tca : OLT PON TC TCA related alarms - olt-pon-util-tca : OLT PON utilization TCA related alarms - olt-chpr-util-tca : OLT channel-pair utilization TCA related alarms - olt-ont-tc-tca : OLT ONT TC TCA related alarms - ont-tca : ONT TCA related alarms - ont-pots-supplemental : ONT POTS Supplemental related alarms - sfu-ploam : SFU ONT PLOAM related alarms - sfu-gen : SFU ONT general related alarms - soho-ploam : SOHO ONT PLOAM related alarms - soho-gen : SOHO ONT general related alarms - mdu-ploam : MDU ONT PLOAM related alarms - mdu-gen : MDU ONT general related alarms - ont-veip : ONT VEIP related alarms - ont-iphost : ONT IP HOST related alarms - alarm-table : alarm table related alarms - auto-switch : auto-switch related alarms - channel-pair : channel pair related alarms - ont-cfg-dld : ont configure file download related alarms - olt-chpair-tc-tca : OLT CHANNELPAIR TC TCA related alarms - hgu-tr069 : hgu tr069 related alarms - eqpt-psu : equipment psu alarms - ont-protection : ONT protection related alarms - secondary-megaco-term : secondary megaco termination related alarms - secondary-sip-term : secondary sip termination related alarms - cas-r2-channel : CAS R2 channel related alarms - lldpmed : lldpmed alarms - pseudo-wire : pseudo Wire related alarms - link-agg : Link aggregation related alarms - fcs-exceed : FCS auto-recovery related alarms - e1t1-interface : E1/T1 physical interfaces related alarms	
name	Parameter type: <Alarm::almtypeSwmgmt> (sw-rollback db-rollback xvps-inv-dbase inv-cde-file miss-cde-file cde-hash-error auto-fetch-failure low-disk-space all) Possible values: - sw-rollback : non active oswp,db cannot be operational -	alarm name that are active <i>This element is only shown in detail mode.</i>

101 query current alarms by filters

name	Type	Description
	will rollback - db-rollback : selected oswp,db cannot be operational - will rollback - xvps-inv-dbase : invalid xvps dbase - inv-cde-file : invalid xvps cde file - miss-cde-file : missing cde profile - cde-hash-error : cde profile hash error - auto-fetch-failure : not able to fetch file from specified server - low-disk-space : insufficient space for Sw storage - all : show all sw-mgmt alarm	
severity	Parameter type: <Alarm::AlarmSeverity> (indeterminate warning minor major critical) Possible values: - indeterminate : alarm severity is indeterminate - warning : alarm severity is warning - minor : alarm severity is minor - major : alarm severity is major - critical : alarm severity is critical	the alarms severity level <i>This element is only shown in detail mode.</i>
servaff	Parameter type: <Alarm::alarmServAffect> ((service-affecting yes) (noservice-affecting no)) Possible values: - service-affecting : make this alarm service affecting - yes : make this alarm service affecting - noservice-affecting : make this alarm not service affecting - no : make this alarm not service affecting	alarms affect service or not <i>This element is only shown in detail mode.</i>
time	Parameter type: <Sys::timeInSecs> - the time (yyyy-mm-dd:hour:minutes:secs) - unit: UTC	time in seconds when alarm was updated <i>This element is only shown in detail mode.</i>
descript	Parameter type: <Alarm::AddInfoString> - additional alarm information	alarm description <i>This element is only shown in detail mode.</i>

101.8 show current alarm by filters

Command Description

show current alarms by filters

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm query filetransfer [ (name) [ severity <Alarm::querySeverity> ] [ servaff <Alarm::queryServAffect> ]
[ server-id <Alarm::FileTransfer> ] ]
```

Command Parameters

Table 101.8-1 "show current alarm by filters" Resource Parameters

Resource Identifier	Type	Description
(name)	Format: (fileserv-unavail all) Possible values: - fileserv-unavail : file transfer Server unavailable or file transfer failed - all : show all filetransfer alarm	alarm name of filetransfer
severity	Parameter type: <Alarm::querySeverity> Format: (indeterminate warning minor major critical all) Possible values: - indeterminate : alarm severity is indeterminate - warning : alarm severity is warning - minor : alarm severity is minor - major : alarm severity is major - critical : alarm severity is critical - all : all alarm severity	severity level of an alarm for reporting
servaff	Parameter type: <Alarm::queryServAffect> Format: (service-affecting noservice-affecting all) Possible values:	serviceaffecting no

101 query current alarms by filters

Resource Identifier	Type	Description
	- service-affecting : query alarm service affecting - noservice-affecting : query alarm not service affecting - all : query service affecting and not affecting alarms	
server-id	Parameter type: <Alarm::FileTransfer> Format: - next hop IP address	the server id of file transfer

Command Output

Table 101.8-2 "show current alarm by filters" Display parameters

Specific Information		
name	Type	Description
aidinfo	Parameter type: <Alarm::AddInfoString> - additional alarm information	alarm AID parameters <i>This element is only shown in detail mode.</i>
type	Parameter type: <Alarm::alarmIHUBType> (equipment eqpt-holder plug-in-unit atm custom e1 ima-group ima-link redundancy shdsl ether-itf traffic-overflow qos-queue temporal spatial (software-mngt sw-mgmt) xdsl xdsl-ext xdsl-tca olt-gen eo-conv authentication bonding sfp shdsl-isam custom-ext-alarm plug-in-unit-ext sip-user-agent sip-plugin-unit sip-termination e1-sip-termination filetransfer external-device l2forward ether-tca ether-sfp megaco-media-gw megaco-sig-gw megaco-plug-unit megaco-term)	type of the alarms that are active <i>This element is only shown in detail mode.</i>

name	Type	Description
	megaco-sig-lt	
	eqpt-supplemental	
	eqpt-holder-ext	
	lsmredundancy	
	sync	
	mcsrc	
	vlanport	
	vect-line	
	vect-board	
	otdr	
	sip-dial-plan	
	sip-vsp	
	sip-server	
	bgp	
	rip	
	lag	
	ihub-general	
	vprn	
	isis	
	ospf	
	ihub-l2forward	
	vpls	
	ihub-equip	
	ihub-link	
	eont-phyoam	
	ellid	
	epon	
	eont-services-lan	
	eolt-ont-tca	
	eont-sw-dl	
	ldp	
	mpls	
	sdp	
	epipe	
	ihub-ipv6	
	pim	
	li	
	mgmt-sec-access	
	bfd	
	ai	
	tr069serv	
	ontsnmp	
	bulk-sync	
	protection-group	
	ont	
	sfu-sup	
	soho-sup	
	mdu-sup	
	ont-ani	
	sfu-sup2	
	soho-sup2	
	mdu-sup2	
	sfprssi	
	eoltrssi	
	cfm	
	sfpe1t1-framer	
	sfpe1t1-clock	

101 query current alarms by filters

name	Type	Description
	pppcc-engine-tca eth-cfm rsvp ihub-tca eth-ring efm-oam ont-loopdetect ont-video ont-ces ont-voip ont-video-ani ont-pwe ont-cese1 ont-xdsl ont-xdsl-tca ont-hpna ont-sip-agent-cfg ont-voip-cfg ont-mgc ont-ploam ont-gen ont-card ont-pots ont-lan ont-moca ont-tc-tca ont-moca-tca ont-l2uni-eth-tca olt-pon-tc-tca olt-pon-util-tca olt-chpr-util-tca olt-ont-tc-tca ont-tca ont-pots-supplemental sfu-ploam sfu-gen soho-ploam soho-gen mdu-ploam mdu-gen ont-veip ont-iphost alarm-table auto-switch channel-pair ont-cfg-dld olt-chpair-tc-tca hgu-tr069 eqpt-psu ont-protection secondary-megaco-term secondary-sip-term cas-r2-channel lldpmed pseudo-wire link-agg fcs-exceed	

name	Type	Description
	e1t1-interface) Possible values: - equipment : equipment alarms - eqpt-holder : equipment holder alarms - plug-in-unit : plugin unit alarms - atm : ATM alarms - custom : customizable alarms - e1 : e1 alarms - ima-group : ima-group alarms - ima-link : ima-link alarms - redundancy : redundancy alarms - shdsl : shdsl alarms - ether-itf : ethernet interface alarms - traffic-overflow : Traffic overflow alarms - qos-queue : qos queue alarms - temporal : temporal alarms - spatial : spatial alarms - software-mngt : software management alarms - sw-mgmt : software management alarms - xdsl : xDSL alarms - xdsl-ext : other xDSL alarms - xdsl-tca : xDSL threshold cross alarms - olt-gen : OLT general alarms - eo-conv : E/O conversion related alarms - authentication : authentication related alarms - bonding : bonding-group related alarms - sfp : SFP related alarms - shdsl-isam : shdsl isam alarms - custom-ext-alarm : customizable external alarms - plug-in-unit-ext : other plugin unit alarms - sip-user-agent : sip user agent related alarms - sip-plugin-unit : sip plug in unit related alarms - sip-termination : sip termination related alarms - e1-sip-termination : E1 sip termination related alarms - filetransfer : file transfer server alarms - external-device : external device related alarms - l2forward : l2forward related alarms - ether-tca : ethernet threshold cross alarms - ether-sfp : ethernet SFP related alarms - megaco-media-gw : megaco media gateway related alarms - megaco-sig-gw : megaco signaling gateway related alarms - megaco-plug-unit : megaco plug unit related alarms - megaco-term : megaco termination related alarms - megaco-sig-lt : megaco signaling lt related alarms - eqpt-supplemental : equipment supplemental alarms - eqpt-holder-ext : other equipment holder alarms - lsmredundancy : lsm redundancy alarms - sync : synce and bits alarms - mcsrc : multicast source alarms - vlanport : vlanport alarms - vect-line : xDSL vectoring line alarms - vect-board : xDSL vectoring board alarms - otdr : otdr alarms - sip-dial-plan : sip dial plan related alarms - sip-vsp : sip vsp related alarms - sip-server : sip server related alarms - bgp : bgp related alarms	

101 query current alarms by filters

name	Type	Description
	- rip : rip related alarms - lag : LAG related alarms - ihub-general : IHUB general related alarms - vprn : vprn related alarms - isis : isis related alarms - ospf : ospf related alarms - ihub-l2forward : ihub-l2forward alarms - vpls : vpls related alarms - ihub-equip : ihub-equip related alarms - ihub-link : ihub-link related alarms - eont-phyoam : eont phyoam related alarms - ellid : ellid related alarms - epon : epon related alarms - eont-services-lan : eon phyoam related alarms - eolt-ont-tca : eon phyoam related alarms - eont-sw-dl : eon phyoam related alarms - ldp : ldp related alarms - mpls : mpls related alarms - sdp : sdp related alarms - epipe : epipe related alarms - ihub-ipv6 : ihub-ipv6 related alarms - pim : pim related alarms - li : lawful intercept related alarms - mgmt-sec-access : management security related alarms - bfd : bfd related alarms - ai : Application Intelligence related alarms - tr069serv : tr069 server related alarms - ontsnmp : ont snmp related alarms - bulk-sync : bulk-sync related alarms - protection-group : port protection group related alarms - ont : ONT general supplemental related alarms - sfu-sup : SFU ONT general supplemental related alarms - soho-sup : SOHO ONT general supplemental related alarms - mdu-sup : MDU ONT general supplemental related alarms - ont-ani : ONT general supplemental 2 related alarms - sfu-sup2 : SFU ONT general supplemental 2 related alarms - soho-sup2 : SOHO ONT general supplemental 2 related alarms - mdu-sup2 : MDU ONT general supplemental 2 related alarms - sfprssi : SFP RSSI related alarms - eoltrssi : epon olt Sfp RSSI related alarms - cfm : Cfm related alarms - sfpe1t1-framer : SFP 2e1t1 framer alarms - sfpe1t1-clock : SFP 2e1t1 clock alarms - pppcc-engine-tca : PPPOE Cross Connect Engine TCA related alarm - eth-cfm : eth-cfm related alarms - rsvp : rsvp related alarms - ihub-tca : IHUB TCA related alarms - eth-ring : eth-ring related alarms - efm-oam : EFM-OAM related alarms - ont-loopdetect : ont loop detect related alarms - ont-video : ont services video related alarms - ont-ces : ont services ces related alarms - ont-voip : ont services voip related alarms	

name	Type	Description
	- ont-video-ani : ont services video ani related alarms - ont-pwe : ont services pwe related alarms - ont-cese1 : ont services cese1 related alarms - ont-xdsl : ont services xdsl related alarms - ont-xdsl-tca : ont services xdsl tca related alarms - ont-hpna : ont hpna related alarms - ont-sip-agent-cfg : ont services voip sip agent config related alarms - ont-voip-cfg : ont services voip config related alarms - ont-mgc : ont mgc related alarms - ont-ploam : ONT PLOAM related alarms - ont-gen : ONT GENERAL related alarms - ont-card : ONT Subscriber Card related alarms - ont-pots : ONT Services POTS related alarms - ont-lan : ONT Services LAN related alarms - ont-moca : ONT MoCA related alarms - ont-tc-tca : ONT TC TCA related alarms - ont-moca-tca : ONT MoCA TCA related alarms - ont-l2uni-eth-tca : ONT L2 UNI Ethernet TCA related alarms - olt-pon-tc-tca : OLT PON TC TCA related alarms - olt-pon-util-tca : OLT PON utilization TCA related alarms - olt-chpr-util-tca : OLT channel-pair utilization TCA related alarms - olt-ont-tc-tca : OLT ONT TC TCA related alarms - ont-tca : ONT TCA related alarms - ont-pots-supplemental : ONT POTS Supplemental related alarms - sfu-ploam : SFU ONT PLOAM related alarms - sfu-gen : SFU ONT general related alarms - soho-ploam : SOHO ONT PLOAM related alarms - soho-gen : SOHO ONT general related alarms - mdu-ploam : MDU ONT PLOAM related alarms - mdu-gen : MDU ONT general related alarms - ont-veip : ONT VEIP related alarms - ont-iphost : ONT IP HOST related alarms - alarm-table : alarm table related alarms - auto-switch : auto-switch related alarms - channel-pair : channel pair related alarms - ont-cfg-dld : ont configure file download related alarms - olt-chpair-tc-tca : OLT CHANNELPAIR TC TCA related alarms - hgu-tr069 : hgu tr069 related alarms - eqpt-psu : equipment psu alarms - ont-protection : ONT protection related alarms - secondary-megaco-term : secondary megaco termination related alarms - secondary-sip-term : secondary sip termination related alarms - cas-r2-channel : CAS R2 channel related alarms - lldpmed : lldpmed alarms - pseudo-wire : pseudo Wire related alarms - link-agg : Link aggregation related alarms - fcs-exceed : FCS auto-recovery related alarms - e1t1-interface : E1/T1 physical interfaces related alarms	
name	Parameter type: <Alarm::almtypFiletrans> (fileserv-unavail	alarm name that are active <i>This element is only shown in</i>

101 query current alarms by filters

name	Type	Description
	all) Possible values: - fileserv-unavail : file transfer Server unavailable or file transfer failed - all : show all filetransfer alarm	detail mode.
severity	Parameter type: <Alarm::AlarmSeverity> (indeterminate warning minor major critical) Possible values: - indeterminate : alarm severity is indeterminate - warning : alarm severity is warning - minor : alarm severity is minor - major : alarm severity is major - critical : alarm severity is critical	the alarms severity level <i>This element is only shown in detail mode.</i>
servaff	Parameter type: <Alarm::alarmServAffect> ((service-affecting yes) (noservice-affecting no)) Possible values: - service-affecting : make this alarm service affecting - yes : make this alarm service affecting - noservice-affecting : make this alarm not service affecting - no : make this alarm not service affecting	alarms affect service or not <i>This element is only shown in detail mode.</i>
time	Parameter type: <Sys::timeInSecs> - the time (yyyy-mm-dd:hour:minutes:secs) - unit: UTC	time in seconds when alarm was updated <i>This element is only shown in detail mode.</i>
descript	Parameter type: <Alarm::AddInfoString> - additional alarm information	alarm description <i>This element is only shown in detail mode.</i>

101.9 show current alarm by filters

Command Description

show current alarms by filters

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm query lsmredundancy [ (name) [ severity <Alarm::querySeverity> ] [ servaff
<Alarm::queryServAffect> ] [ board <Equipm::LtSlotIndex> ] ]
```

Command Parameters

Table 101.9-1 "show current alarm by filters" Resource Parameters

Resource Identifier	Type	Description
(name)	Format: (loss-lsmswp-cap inv-xvps-pair-data all) Possible values: - loss-lsmswp-cap : lsm redundancy - inv-xvps-pair-data : invalid xvps pair redundancy data - all : show all lsm redundancy alarm	alarm name of lsmredundancy
severity	Parameter type: <Alarm::querySeverity> Format: (indeterminate warning minor major critical all) Possible values: - indeterminate : alarm severity is indeterminate - warning : alarm severity is warning - minor : alarm severity is minor - major : alarm severity is major - critical : alarm severity is critical - all : all alarm severity	severity level of an alarm for reporting
servaff	Parameter type: <Alarm::queryServAffect> Format: (service-affecting noservice-affecting all)	serviceaffecting no

101 query current alarms by filters

Resource Identifier	Type	Description
	Possible values: - service-affecting : query alarm service affecting - noservice-affecting : query alarm not service affecting - all : query service affecting and not affecting alarms	
board	Parameter type: <Equipm::LtSlotIndex> Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId>) Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number	the physical number of the slot

Command Output

Table 101.9-2 "show current alarm by filters" Display parameters

Specific Information		
name	Type	Description
aidinfo	Parameter type: <Alarm::AddInfoString> - additional alarm information	alarm AID parameters <i>This element is only shown in detail mode.</i>
type	Parameter type: <Alarm::alarmIHUBType> (equipment eqpt-holder plug-in-unit atm custom e1 ima-group ima-link redundancy shdsl ether-itf traffic-overflow qos-queue temporal spatial (software-mngt sw-mgmt) xdsl xdsl-ext xdsl-tca olt-gen eo-conv authentication bonding sfp shdsl-isam custom-ext-alarm plug-in-unit-ext sip-user-agent sip-plugin-unit sip-termination e1-sip-termination filetransfer	type of the alarms that are active <i>This element is only shown in detail mode.</i>

name	Type	Description
	external-device	
	l2forward	
	ether-tca	
	ether-sfp	
	megaco-media-gw	
	megaco-sig-gw	
	megaco-plug-unit	
	megaco-term	
	megaco-sig-lt	
	eqpt-supplemental	
	eqpt-holder-ext	
	lsmredundancy	
	sync	
	mcsrc	
	vlanport	
	vect-line	
	vect-board	
	otdr	
	sip-dial-plan	
	sip-vsp	
	sip-server	
	bgp	
	rip	
	lag	
	ihub-general	
	vprn	
	isis	
	ospf	
	ihub-l2forward	
	vpls	
	ihub-equip	
	ihub-link	
	eont-phyoam	
	ellid	
	epon	
	eont-services-lan	
	eolt-ont-tca	
	eont-sw-dl	
	ldp	
	mpls	
	sdp	
	epipe	
	ihub-ipv6	
	pim	
	li	
	mgmt-sec-access	
	bfd	
	ai	
	tr069serv	
	ontsnmp	
	bulk-sync	
	protection-group	
	ont	
	sfu-sup	
	soho-sup	
	mdu-sup	
	ont-ani	

101 query current alarms by filters

name	Type	Description
	sfu-sup2	
	soho-sup2	
	mdu-sup2	
	sfprssi	
	eoltrssi	
	cfm	
	sfpe1t1-framer	
	sfpe1t1-clock	
	pppcc-engine-tca	
	eth-cfm	
	rsvp	
	ihub-tca	
	eth-ring	
	efm-oam	
	ont-loopdetect	
	ont-video	
	ont-ces	
	ont-voip	
	ont-video-ani	
	ont-pwe	
	ont-cese1	
	ont-xdsl	
	ont-xdsl-tca	
	ont-hpna	
	ont-sip-agent-cfg	
	ont-voip-cfg	
	ont-mgc	
	ont-ploam	
	ont-gen	
	ont-card	
	ont-pots	
	ont-lan	
	ont-moca	
	ont-tc-tca	
	ont-moca-tca	
	ont-l2uni-eth-tca	
	olt-pon-tc-tca	
	olt-pon-util-tca	
	olt-chpr-util-tca	
	olt-ont-tc-tca	
	ont-tca	
	ont-pots-supplemental	
	sfu-ploam	
	sfu-gen	
	soho-ploam	
	soho-gen	
	mdu-ploam	
	mdu-gen	
	ont-veip	
	ont-iphost	
	alarm-table	
	auto-switch	
	channel-pair	
	ont-cfg-dld	
	olt-chpair-tc-tca	
	hgu-tr069	
	eqpt-psu	

name	Type	Description
	ont-protection secondary-megaco-term secondary-sip-term cas-r2-channel lldpmed pseudo-wire link-agg fcs-exceed e1t1-interface) Possible values: - equipment : equipment alarms - eqpt-holder : equipment holder alarms - plug-in-unit : plugin unit alarms - atm : ATM alarms - custom : customizable alarms - e1 : e1 alarms - ima-group : ima-group alarms - ima-link : ima-link alarms - redundancy : redundancy alarms - shdsl : shdsl alarms - ether-itf : ethernet interface alarms - traffic-overflow : Traffic overflow alarms - qos-queue : qos queue alarms - temporal : temporal alarms - spatial : spatial alarms - software-mngt : software management alarms - sw-mgmt : software management alarms - xdsl : xDSL alarms - xdsl-ext : other xDSL alarms - xdsl-tca : xDSL threshold cross alarms - olt-gen : OLT general alarms - eo-conv : E/O conversion related alarms - authentication : authentication related alarms - bonding : bonding-group related alarms - sfp : SFP related alarms - shdsl-isam : shdsl isam alarms - custom-ext-alarm : customizable external alarms - plug-in-unit-ext : other plugin unit alarms - sip-user-agent : sip user agent related alarms - sip-plugin-unit : sip plug in unit related alarms - sip-termination : sip termination related alarms - e1-sip-termination : E1 sip termination related alarms - filetransfer : file transfer server alarms - external-device : external device related alarms - l2forward : l2forward related alarms - ether-tca : ethernet threshold cross alarms - ether-sfp : ethernet SFP related alarms - megaco-media-gw : megaco media gateway related alarms - megaco-sig-gw : megaco signaling gateway related alarms - megaco-plug-unit : megaco plug unit related alarms - megaco-term : megaco termination related alarms - megaco-sig-lt : megaco signaling lt related alarms - eqpt-supplemental : equipment supplemental alarms - eqpt-holder-ext : other equipment holder alarms - lsmredundancy : lsm redundancy alarms - sync : synce and bits alarms - mcsrc : multicast source alarms	

101 query current alarms by filters

name	Type	Description
	- vlanport : vlanport alarms - vect-line : xDSL vectoring line alarms - vect-board : xDSL vectoring board alarms - otdr : otdr alarms - sip-dial-plan : sip dial plan related alarms - sip-vsp : sip vsp related alarms - sip-server : sip server related alarms - bgp : bgp related alarms - rip : rip related alarms - lag : LAG related alarms - ihub-general : IHUB general related alarms - vprn : vprn related alarms - isis : isis related alarms - ospf : ospf related alarms - ihub-l2forward : ihub-l2forward alarms - vpls : vpls related alarms - ihub-equip : ihub-equip related alarms - ihub-link : ihub-link related alarms - eont-phyoam : eont phyoam related alarms - ellid : ellid related alarms - epon : epon related alarms - eont-services-lan : eon phyoam related alarms - eolt-ont-tca : eon phyoam related alarms - eont-sw-dl : eon phyoam related alarms - ldp : ldp related alarms - mpls : mpls related alarms - sdp : sdp related alarms - epipe : epipe related alarms - ihub-ipv6 : ihub-ipv6 related alarms - pim : pim related alarms - li : lawful intercept related alarms - mgmt-sec-access : management security related alarms - bfd : bfd related alarms - ai : Application Intelligence related alarms - tr069serv : tr069 server related alarms - ontsnmp : ont snmp related alarms - bulk-sync : bulk-sync related alarms - protection-group : port protection group related alarms - ont : ONT general supplemental related alarms - sfu-sup : SFU ONT general supplemental related alarms - soho-sup : SOHO ONT general supplemental related alarms - mdu-sup : MDU ONT general supplemental related alarms - ont-ani : ONT general supplemental 2 related alarms - sfu-sup2 : SFU ONT general supplemental 2 related alarms - soho-sup2 : SOHO ONT general supplemental 2 related alarms - mdu-sup2 : MDU ONT general supplemental 2 related alarms - sfprssi : SFP RSSI related alarms - eoltrssi : epon olt Sfp RSSI related alarms - cfm : Cfm related alarms - sfpe1t1-framer : SFP 2e1t1 framer alarms - sfpe1t1-clock : SFP 2e1t1 clock alarms - pppcc-engine-tca : PPPOE Cross Connect Engine TCA related alarm - eth-cfm : eth-cfm related alarms	

name	Type	Description
	- rsvp : rsvp related alarms - ihub-tca : IHUB TCA related alarms - eth-ring : eth-ring related alarms - efm-oam : EFM-OAM related alarms - ont-loopdetect : ont loop detect related alarms - ont-video : ont services video related alarms - ont-ces : ont services ces related alarms - ont-voip : ont services voip related alarms - ont-video-ani : ont services video ani related alarms - ont-pwe : ont services pwe related alarms - ont-cese1 : ont services cese1 related alarms - ont-xdsl : ont services xdsl related alarms - ont-xdsl-tca : ont services xdsl tca related alarms - ont-hpna : ont hpna related alarms - ont-sip-agent-cfg : ont services voip sip agent config related alarms - ont-voip-cfg : ont services voip config related alarms - ont-mgc : ont mgc related alarms - ont-ploam : ONT PLOAM related alarms - ont-gen : ONT GENERAL related alarms - ont-card : ONT Subscriber Card related alarms - ont-pots : ONT Services POTS related alarms - ont-lan : ONT Services LAN related alarms - ont-moca : ONT MoCA related alarms - ont-tc-tca : ONT TC TCA related alarms - ont-moca-tca : ONT MoCA TCA related alarms - ont-l2uni-eth-tca : ONT L2 UNI Ethernet TCA related alarms - olt-pon-tc-tca : OLT PON TC TCA related alarms - olt-pon-util-tca : OLT PON utilization TCA related alarms - olt-chpr-util-tca : OLT channel-pair utilization TCA related alarms - olt-ont-tc-tca : OLT ONT TC TCA related alarms - ont-tca : ONT TCA related alarms - ont-pots-supplemental : ONT POTS Supplemental related alarms - sfu-ploam : SFU ONT PLOAM related alarms - sfu-gen : SFU ONT general related alarms - soho-ploam : SOHO ONT PLOAM related alarms - soho-gen : SOHO ONT general related alarms - mdu-ploam : MDU ONT PLOAM related alarms - mdu-gen : MDU ONT general related alarms - ont-veip : ONT VEIP related alarms - ont-iphost : ONT IP HOST related alarms - alarm-table : alarm table related alarms - auto-switch : auto-switch related alarms - channel-pair : channel pair related alarms - ont-cfg-dld : ont configure file download related alarms - olt-chpair-tc-tca : OLT CHANNELPAIR TC TCA related alarms - hgu-tr069 : hgu tr069 related alarms - eqpt-psu : equipment psu alarms - ont-protection : ONT protection related alarms - secondary-megaco-term : secondary megaco termination related alarms - secondary-sip-term : secondary sip termination related alarms	

101 query current alarms by filters

name	Type	Description
	- cas-r2-channel : CAS R2 channel related alarms - lldpmed : lldpmed alarms - pseudo-wire : pseudo Wire related alarms - link-aggr : Link aggregation related alarms - fcs-exceed : FCS auto-recovery related alarms - e1t1-interface : E1/T1 physical interfaces related alarms	
name	Parameter type: <Alarm::alarmTypeLsmredundancy> (loss-lmswp-cap inv-xvps-pair-data all) Possible values: - loss-lmswp-cap : lsm redundancy - inv-xvps-pair-data : invalid xvps pair redundancy data - all : show all lsm redundancy alarm	alarm name that are active <i>This element is only shown in detail mode.</i>
severity	Parameter type: <Alarm::AlarmSeverity> (indeterminate warning minor major critical) Possible values: - indeterminate : alarm severity is indeterminate - warning : alarm severity is warning - minor : alarm severity is minor - major : alarm severity is major - critical : alarm severity is critical	the alarms severity level <i>This element is only shown in detail mode.</i>
servaff	Parameter type: <Alarm::alarmServAffect> ((service-affecting yes) (noservice-affecting no)) Possible values: - service-affecting : make this alarm service affecting - yes : make this alarm service affecting - noservice-affecting : make this alarm not service affecting - no : make this alarm not service affecting	alarms affect service or not <i>This element is only shown in detail mode.</i>
time	Parameter type: <Sys::timeInSecs> - the time (yyyy-mm-dd:hour:minutes:secs) - unit: UTC	time in seconds when alarm was updated <i>This element is only shown in detail mode.</i>
descript	Parameter type: <Alarm::AddInfoString> - additional alarm information	alarm description <i>This element is only shown in detail mode.</i>

101.10 show current alarm by filters

Command Description

show current alarms by filters

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm query traffic-overflow [ (name) [ severity <Alarm::querySeverity> ] [ servaff
<Alarm::queryServAffect> ] [ board <Equipm::SlotIndex> ] ]
```

Command Parameters

Table 101.10-1 "show current alarm by filters" Resource Parameters

Resource Identifier	Type	Description
(name)	Format: (fanout up-overflow upobc-overflow dwobc-overflow dw-overflow lwpri-overflow all) Possible values: - fanout : Lt load overflow - up-overflow : Upstream load overflow - upobc-overflow : Upstream load to OBC overflow - dwobc-overflow : Downstream load to OBC overflow - dw-overflow : Downstream load overflow - lwpri-overflow : The number of BE and CL pkts dropped exceed threshold - all : Traffic overflow alarms	alarm name of traffic-overflow
severity	Parameter type: <Alarm::querySeverity> Format: (indeterminate warning minor major critical all) Possible values: - indeterminate : alarm severity is indeterminate - warning : alarm severity is warning	severity level of an alarm for reporting

101 query current alarms by filters

Resource Identifier	Type	Description
	- minor : alarm severity is minor - major : alarm severity is major - critical : alarm severity is critical - all : all alarm severity	
servaff	Parameter type: <Alarm::queryServAffect> Format: (service-affecting noservice-affecting all) Possible values: - service-affecting : query alarm service affecting - noservice-affecting : query alarm not service affecting - all : query service affecting and not affecting alarms	serviceaffecting no serviceaffecting
board	Parameter type: <Equipm::SlotIndex> Format: (lt : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> nt-a nt-b nt acu : <Eqpt::RackId> / <Eqpt::ShelfId> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::EqSlotId> ext-a : <Eqpt::RackId> / <Eqpt::ShelfId> ext-b : <Eqpt::RackId> / <Eqpt::ShelfId> ctrl : <Eqpt::RackId> / <Eqpt::ShelfId> vlt : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::VirtualSlotId>) Possible values: - lt : lt-slot - vlt : virtual LT slot (VVPS board can only be planned at NANT-E / FANT-F) - nt-a : nt-a slot - nt-b : nt-b slot - nt : nt slot - ext-a : nt-a slot in an extension shelf - ext-b : nt-b slot in an extension shelf - acu : acu slot - ctrl : ctrl-slot Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::VirtualSlotId> - the virtual LT slot number Field type <Eqpt::EqSlotId> - the equipment slot number	the physical number of the board

Command Output

Table 101.10-2 "show current alarm by filters" Display parameters

Specific Information		
name	Type	Description
aidinfo	Parameter type: <Alarm::AddInfoString> - additional alarm information	alarm AID parameters <i>This element is only shown in detail mode.</i>

name	Type	Description
type	Parameter type: <Alarm::alarmIHUBType> (equipment eqpt-holder plug-in-unit atm custom e1 ima-group ima-link redundancy shdsl ether-itf traffic-overflow qos-queue temporal spatial (software-mngt sw-mgmt) xdsl xdsl-ext xdsl-tca olt-gen eo-conv authentication bonding sfp shdsl-isam custom-ext-alarm plug-in-unit-ext sip-user-agent sip-plugin-unit sip-termination e1-sip-termination filetransfer external-device l2forward ether-tca ether-sfp megaco-media-gw megaco-sig-gw megaco-plug-unit megaco-term megaco-sig-lt eqpt-supplemental eqpt-holder-ext lsmredundancy sync mcsrc vlanport vect-line vect-board otdr sip-dial-plan sip-vsp sip-server bgp rip lag	type of the alarms that are active <i>This element is only shown in detail mode.</i>

101 query current alarms by filters

name	Type	Description
	ihub-general	
	vprn	
	isis	
	ospf	
	ihub-l2forward	
	vpls	
	ihub-equip	
	ihub-link	
	eont-phyoam	
	ellid	
	epon	
	eont-services-lan	
	eolt-ont-tca	
	eont-sw-dl	
	ldp	
	mpls	
	sdp	
	epipe	
	ihub-ipv6	
	pim	
	li	
	mgmt-sec-access	
	bfd	
	ai	
	tr069serv	
	ontsnmp	
	bulk-sync	
	protection-group	
	ont	
	sfu-sup	
	soho-sup	
	mdu-sup	
	ont-ani	
	sfu-sup2	
	soho-sup2	
	mdu-sup2	
	sfprssi	
	eoltrssi	
	cfm	
	sfpe1t1-framer	
	sfpe1t1-clock	
	pppcc-engine-tca	
	eth-cfm	
	rsvp	
	ihub-tca	
	eth-ring	
	efm-oam	
	ont-loopdetect	
	ont-video	
	ont-ces	
	ont-voip	
	ont-video-ani	
	ont-pwe	
	ont-cese1	
	ont-xdsl	
	ont-xdsl-tca	
	ont-hpna	

name	Type	Description
	ont-sip-agent-cfg ont-voip-cfg ont-mgc ont-ploam ont-gen ont-card ont-pots ont-lan ont-moca ont-tc-tca ont-moca-tca ont-l2uni-eth-tca olt-pon-tc-tca olt-pon-util-tca olt-chpr-util-tca olt-ont-tc-tca ont-tca ont-pots-supplemental sfu-ploam sfu-gen soho-ploam soho-gen mdu-ploam mdu-gen ont-veip ont-iphost alarm-table auto-switch channel-pair ont-cfg-dld olt-chpair-tc-tca hgu-tr069 eqpt-psu ont-protection secondary-megaco-term secondary-sip-term cas-r2-channel lldpmed pseudo-wire link-agg fcs-exceed e1t1-interface) Possible values: - equipment : equipment alarms - eqpt-holder : equipment holder alarms - plug-in-unit : plugin unit alarms - atm : ATM alarms - custom : customizable alarms - e1 : e1 alarms - ima-group : ima-group alarms - ima-link : ima-link alarms - redundancy : redundancy alarms - shdsl : shdsl alarms - ether-itf : ethernet interface alarms - traffic-overflow : Traffic overflow alarms - qos-queue : qos queue alarms - temporal : temporal alarms	

101 query current alarms by filters

name	Type	Description
	- spatial : spatial alarms - software-mngt : software management alarms - sw-mgmt : software management alarms - xdsl : xDSL alarms - xdsl-ext : other xDSL alarms - xdsl-tca : xDSL threshold cross alarms - olt-gen : OLT general alarms - eo-conv : E/O conversion related alarms - authentication : authentication related alarms - bonding : bonding-group related alarms - sfp : SFP related alarms - shdsl-isam : shdsl isam alarms - custom-ext-alarm : customizable external alarms - plug-in-unit-ext : other plugin unit alarms - sip-user-agent : sip user agent related alarms - sip-plugin-unit : sip plug in unit related alarms - sip-termination : sip termination related alarms - e1-sip-termination : E1 sip termination related alarms - filetransfer : file transfer server alarms - external-device : external device related alarms - l2forward : l2forward related alarms - ether-tca : ethernet threshold cross alarms - ether-sfp : ethernet SFP related alarms - megaco-media-gw : megaco media gateway related alarms - megaco-sig-gw : megaco signaling gateway related alarms - megaco-plug-unit : megaco plug unit related alarms - megaco-term : megaco termination related alarms - megaco-sig-lt : megaco signaling lt related alarms - eqpt-supplemental : equipment supplemental alarms - eqpt-holder-ext : other equipment holder alarms - lsmredundancy : lsm redundancy alarms - sync : synce and bits alarms - mcsrc : multicast source alarms - vlanport : vlanport alarms - vect-line : xDSL vectoring line alarms - vect-board : xDSL vectoring board alarms - otdr : otdr alarms - sip-dial-plan : sip dial plan related alarms - sip-vsp : sip vsp related alarms - sip-server : sip server related alarms - bgp : bgp related alarms - rip : rip related alarms - lag : LAG related alarms - ihub-general : IHUB general related alarms - vprn : vprn related alarms - isis : isis related alarms - ospf : ospf related alarms - ihub-l2forward : ihub-l2forward alarms - vpls : vpls related alarms - ihub-equip : ihub-equip related alarms - ihub-link : ihub-link related alarms - eont-phyoam : eont phyoam related alarms - ellid : ellid related alarms - epon : epon related alarms - eont-services-lan : eon phyoam related alarms - eolt-ont-tca : eon phyoam related alarms - eont-sw-dl : eon phyoam related alarms	

name	Type	Description
	- ldp : ldp related alarms - mpls : mpls related alarms - sdp : sdp related alarms - epipe : epipe related alarms - ihub-ipv6 : ihub-ipv6 related alarms - pim : pim related alarms - li : lawful intercept related alarms - mgmt-sec-access : management security related alarms - bfd : bfd related alarms - ai : Application Intelligence related alarms - tr069serv : tr069 server related alarms - ontsnmp : ont snmp related alarms - bulk-sync : bulk-sync related alarms - protection-group : port protection group related alarms - ont : ONT general supplemental related alarms - sfu-sup : SFU ONT general supplemental related alarms - soho-sup : SOHO ONT general supplemental related alarms - mdu-sup : MDU ONT general supplemental related alarms - ont-ani : ONT general supplemental 2 related alarms - sfu-sup2 : SFU ONT general supplemental 2 related alarms - soho-sup2 : SOHO ONT general supplemental 2 related alarms - mdu-sup2 : MDU ONT general supplemental 2 related alarms - sfprssi : SFP RSSI related alarms - eoltrssi : epon olt Sfp RSSI related alarms - cfm : Cfm related alarms - sfpe1t1-framer : SFP 2e1t1 framer alarms - sfpe1t1-clock : SFP 2e1t1 clock alarms - pppcc-engine-tca : PPPOE Cross Connect Engine TCA related alarm - eth-cfm : eth-cfm related alarms - rsvp : rsvp related alarms - ihub-tca : IHUB TCA related alarms - eth-ring : eth-ring related alarms - efm-oam : EFM-OAM related alarms - ont-loopdetect : ont loop detect related alarms - ont-video : ont services video related alarms - ont-ces : ont services ces related alarms - ont-voip : ont services voip related alarms - ont-video-ani : ont services video ani related alarms - ont-pwe : ont services pwe related alarms - ont-cese1 : ont services cese1 related alarms - ont-xdsl : ont services xdsl related alarms - ont-xdsl-tca : ont services xdsl tca related alarms - ont-hpna : ont hpna related alarms - ont-sip-agent-cfg : ont services voip sip agent config related alarms - ont-voip-cfg : ont services voip config related alarms - ont-mgc : ont mgc related alarms - ont-ploam : ONT PLOAM related alarms - ont-gen : ONT GENERAL related alarms - ont-card : ONT Subscriber Card related alarms - ont-pots : ONT Services POTS related alarms - ont-lan : ONT Services LAN related alarms - ont-moca : ONT MoCA related alarms	

101 query current alarms by filters

name	Type	Description
	- ont-tc-tca : ONT TC TCA related alarms - ont-moca-tca : ONT MoCA TCA related alarms - ont-l2uni-eth-tca : ONT L2 UNI Ethernet TCA related alarms - olt-pon-tc-tca : OLT PON TC TCA related alarms - olt-pon-util-tca : OLT PON utilization TCA related alarms - olt-chpr-util-tca : OLT channel-pair utilization TCA related alarms - olt-ont-tc-tca : OLT ONT TC TCA related alarms - ont-tca : ONT TCA related alarms - ont-pots-supplemental : ONT POTS Supplemental related alarms - sfu-ploam : SFU ONT PLOAM related alarms - sfu-gen : SFU ONT general related alarms - soho-ploam : SOHO ONT PLOAM related alarms - soho-gen : SOHO ONT general related alarms - mdu-ploam : MDU ONT PLOAM related alarms - mdu-gen : MDU ONT general related alarms - ont-veip : ONT VEIP related alarms - ont-iphost : ONT IP HOST related alarms - alarm-table : alarm table related alarms - auto-switch : auto-switch related alarms - channel-pair : channel pair related alarms - ont-cfg-dld : ont configure file download related alarms - olt-chpair-tc-tca : OLT CHANNELPAIR TC TCA related alarms - hgu-tr069 : hgu tr069 related alarms - eqpt-psu : equipment psu alarms - ont-protection : ONT protection related alarms - secondary-megaco-term : secondary megaco termination related alarms - secondary-sip-term : secondary sip termination related alarms - cas-r2-channel : CAS R2 channel related alarms - lldpmed : lldpmed alarms - pseudo-wire : pseudo Wire related alarms - link-agg : Link aggregation related alarms - fcs-exceed : FCS auto-recovery related alarms - e1t1-interface : E1/T1 physical interfaces related alarms	
name	Parameter type: <Alarm::almtypeTrafficoverflow> (fanout up-overflow upobc-overflow dwobc-overflow dw-overflow lwpri-overflow all) Possible values: - fanout : Lt load overflow - up-overflow : Upstream load overflow - upobc-overflow : Upstream load to OBC overflow - dwobc-overflow : Downstream load to OBC overflow - dw-overflow : Downstream load overflow - lwpri-overflow : The number of BE and CL pkts dropped exceed threshold - all : Traffic overflow alarms	alarm name that are active <i>This element is only shown in detail mode.</i>
severity	Parameter type: <Alarm::AlarmSeverity>	the alarms severity level

name	Type	Description
	(indeterminate warning minor major critical) Possible values: - indeterminate : alarm severity is indeterminate - warning : alarm severity is warning - minor : alarm severity is minor - major : alarm severity is major - critical : alarm severity is critical	<i>This element is only shown in detail mode.</i>
servaff	Parameter type: <Alarm::alarmServAffect> ((service-affecting yes) (noservice-affecting no)) Possible values: - service-affecting : make this alarm service affecting - yes : make this alarm service affecting - noservice-affecting : make this alarm not service affecting - no : make this alarm not service affecting	alarms affect service or not <i>This element is only shown in detail mode.</i>
time	Parameter type: <Sys::timeInSecs> - the time (yyyy-mm-dd:hour:minutes:secs) - unit: UTC	time in seconds when alarm was updated <i>This element is only shown in detail mode.</i>
descript	Parameter type: <Alarm::AddInfoString> - additional alarm information	alarm description <i>This element is only shown in detail mode.</i>

101.11 show current alarm by filters

Command Description

show current alarms by filters

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm query l2forward [ (name) [ severity <Alarm::querySeverity> ] [ servaff <Alarm::queryServAffect> ]
[ bridgeport <Vlan::BridgePort> ] ]
```

Command Parameters

Table 101.11-1 "show current alarm by filters" Resource Parameters

Resource Identifier	Type	Description
(name)	Format: (mac-conflict vmac-full all) Possible values: - mac-conflict : duplicate mac address on the bridge port - vmac-full : virtual mac address is full on the bridge port - all : show all l2forward alarm	alarm name of l2forward
severity	Parameter type: <Alarm::querySeverity> Format: (indeterminate warning minor major critical all) Possible values: - indeterminate : alarm severity is indeterminate - warning : alarm severity is warning - minor : alarm severity is minor - major : alarm severity is major - critical : alarm severity is critical - all : all alarm severity	severity level of an alarm for reporting
servaff	Parameter type: <Alarm::queryServAffect> Format: (service-affecting noservice-affecting all)	serviceaffecting no

Resource Identifier	Type	Description
	Possible values: - service-affecting : query alarm service affecting - noservice-affecting : query alarm not service affecting - all : query service affecting and not affecting alarms	
bridgeport	Parameter type: <Vlan::BridgePort> Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::VpiId> : <Eqpt::VciId> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> / <Eqpt::OntPortId> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / voip <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / vuni <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::LLId> ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Ng2::OntId> / <Eqpt::Ng2OntSlotId> / <Eqpt::Ng2OntPortId> ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Ng2::OntId> / vuni) Possible values: - ng2 : ngpon2 vlan bridge port Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number Field type <Eqpt::VpiId> - atm VPI Field type <Eqpt::VciId> - atm VCI Field type <Eqpt::PonId> - the PON identifier Field type <Eqpt::ChannelGroupId> - the channel group identifier Field type <Eqpt::SubChannelGroupId> - the subchannel group identifier Field type <Eqpt::OntId> - the ONT identifier Field type <Ng2::OntId> - the ONT identifier Possible values: - voip : virtual uni identifier obsolete alternative replaced by vuni - vuni : virtual uni identifier Possible values: - vuni : virtual NGPON2 uni identifier Field type <Eqpt::OntSlotId> - the ONT SLOT identifier Field type <Eqpt::OntPortId>	the number of bridge port

101 query current alarms by filters

Resource Identifier	Type	Description
	- the ONT PORT identifier Field type <Eqpt::Ng2OntSlotId> - the NGPON2 ONT SLOT identifier Field type <Eqpt::Ng2OntPortId> - the NGPON2 ONT PORT identifier Field type <Eqpt::LLId> - the LLID identifier,range 1 for EPON,range 1-8 for DPOE	

Command Output

Table 101.11-2 "show current alarm by filters" Display parameters

Specific Information		
name	Type	Description
aidinfo	Parameter type: <Alarm::AddInfoString> - additional alarm information	alarm AID parameters <i>This element is only shown in detail mode.</i>
type	Parameter type: <Alarm::alarmIHUBType> (equipment eqpt-holder plug-in-unit atm custom e1 ima-group ima-link redundancy shdsl ether-itf traffic-overflow qos-queue temporal spatial (software-mngt sw-mgmt) xdsl xdsl-ext xdsl-tca olt-gen eo-conv authentication bonding sfp shdsl-isam custom-ext-alarm plug-in-unit-ext sip-user-agent sip-plugin-unit sip-termination e1-sip-termination filetransfer external-device l2forward ether-tca ether-sfp megaco-media-gw megaco-sig-gw megaco-plugin-unit)	type of the alarms that are active <i>This element is only shown in detail mode.</i>

name	Type	Description
	megaco-term megaco-sig-lt eqpt-supplemental eqpt-holder-ext lsmredundancy sync mcsrc vlanport vect-line vect-board otdr sip-dial-plan sip-vsp sip-server bgp rip lag ihub-general vprn isis ospf ihub-l2forward vpls ihub-equip ihub-link eont-phyoam ellid epon eont-services-lan eolt-ont-tca eont-sw-dl ldp mpls sdp epipe ihub-ipv6 pim li mgmt-sec-access bfd ai tr069serv ontsnmp bulk-sync protection-group ont sfu-sup soho-sup mdu-sup ont-ani sfu-sup2 soho-sup2 mdu-sup2 sfprssi eoltrssi cfm sfpe1t1-framer	

101 query current alarms by filters

name	Type	Description
	sfpe1t1-clock pppcc-engine-tca eth-cfm rsvp ihub-tca eth-ring efm-oam ont-loopdetect ont-video ont-ces ont-voip ont-video-ani ont-pwe ont-cese1 ont-xdsl ont-xdsl-tca ont-hpna ont-sip-agent-cfg ont-voip-cfg ont-mgc ont-ploam ont-gen ont-card ont-pots ont-lan ont-moca ont-tc-tca ont-moca-tca ont-l2uni-eth-tca olt-pon-tc-tca olt-pon-util-tca olt-chpr-util-tca olt-ont-tc-tca ont-tca ont-pots-supplemental sfu-ploam sfu-gen soho-ploam soho-gen mdu-ploam mdu-gen ont-veip ont-iphost alarm-table auto-switch channel-pair ont-cfg-dld olt-chpair-tc-tca hgu-tr069 eqpt-psu ont-protection secondary-megaco-term secondary-sip-term cas-r2-channel lldpmed pseudo-wire link-agg	

name	Type	Description
	fcs-exceed e1t1-interface) Possible values: - equipment : equipment alarms - eqpt-holder : equipment holder alarms - plug-in-unit : plugin unit alarms - atm : ATM alarms - custom : customizable alarms - e1 : e1 alarms - ima-group : ima-group alarms - ima-link : ima-link alarms - redundancy : redundancy alarms - shdsl : shdsl alarms - ether-itf : ethernet interface alarms - traffic-overflow : Traffic overflow alarms - qos-queue : qos queue alarms - temporal : temporal alarms - spatial : spatial alarms - software-mngt : software management alarms - sw-mgmt : software management alarms - xdsl : xDSL alarms - xdsl-ext : other xDSL alarms - xdsl-tca : xDSL threshold cross alarms - olt-gen : OLT general alarms - eo-conv : E/O conversion related alarms - authentication : authentication related alarms - bonding : bonding-group related alarms - sfp : SFP related alarms - shdsl-isam : shdsl isam alarms - custom-ext-alarm : customizable external alarms - plug-in-unit-ext : other plugin unit alarms - sip-user-agent : sip user agent related alarms - sip-plugin-unit : sip plug in unit related alarms - sip-termination : sip termination related alarms - e1-sip-termination : E1 sip termination related alarms - filetransfer : file transfer server alarms - external-device : external device related alarms - l2forward : l2forward related alarms - ether-tca : ethernet threshold cross alarms - ether-sfp : ethernet SFP related alarms - megaco-media-gw : megaco media gateway related alarms - megaco-sig-gw : megaco signaling gateway related alarms - megaco-plug-unit : megaco plug unit related alarms - megaco-term : megaco termination related alarms - megaco-sig-lt : megaco signaling lt related alarms - eqpt-supplemental : equipment supplemental alarms - eqpt-holder-ext : other equipment holder alarms - lsmredundancy : lsm redundancy alarms - sync : synce and bits alarms - mcsrc : multicast source alarms - vlanport : vlanport alarms - vect-line : xDSL vectoring line alarms - vect-board : xDSL vectoring board alarms - otdr : otdr alarms - sip-dial-plan : sip dial plan related alarms - sip-vsp : sip vsp related alarms - sip-server : sip server related alarms	

101 query current alarms by filters

name	Type	Description
	- bgp : bgp related alarms - rip : rip related alarms - lag : LAG related alarms - ihub-general : IHUB general related alarms - vprn : vprn related alarms - isis : isis related alarms - ospf : ospf related alarms - ihub-l2forward : ihub-l2forward alarms - vpls : vpls related alarms - ihub-equip : ihub-equip related alarms - ihub-link : ihub-link related alarms - eont-phyoam : eont phyoam related alarms - ellid : ellid related alarms - epon : epon related alarms - eont-services-lan : eon phyoam related alarms - eolt-ont-tca : eon phyoam related alarms - eont-sw-dl : eon phyoam related alarms - ldp : ldp related alarms - mpls : mpls related alarms - sdp : sdp related alarms - epipe : epipe related alarms - ihub-ipv6 : ihub-ipv6 related alarms - pim : pim related alarms - li : lawful intercept related alarms - mgmt-sec-access : management security related alarms - bfd : bfd related alarms - ai : Application Intelligence related alarms - tr069serv : tr069 server related alarms - ontsnmp : ont snmp related alarms - bulk-sync : bulk-sync related alarms - protection-group : port protection group related alarms - ont : ONT general supplemental related alarms - sfu-sup : SFU ONT general supplemental related alarms - soho-sup : SOHO ONT general supplemental related alarms - mdu-sup : MDU ONT general supplemental related alarms - ont-ani : ONT general supplemental 2 related alarms - sfu-sup2 : SFU ONT general supplemental 2 related alarms - soho-sup2 : SOHO ONT general supplemental 2 related alarms - mdu-sup2 : MDU ONT general supplemental 2 related alarms - sfprssi : SFP RSSI related alarms - eoltrssi : epon olt Sfp RSSI related alarms - cfm : Cfm related alarms - sfpe1t1-framer : SFP 2e1t1 framer alarms - sfpe1t1-clock : SFP 2e1t1 clock alarms - pppcc-engine-tca : PPPOE Cross Connect Engine TCA related alarm - eth-cfm : eth-cfm related alarms - rsvp : rsvp related alarms - ihub-tca : IHUB TCA related alarms - eth-ring : eth-ring related alarms - efm-oam : EFM-OAM related alarms - ont-loopdetect : ont loop detect related alarms - ont-video : ont services video related alarms - ont-ces : ont services ces related alarms	

name	Type	Description
	- ont-voip : ont services voip related alarms - ont-video-ani : ont services video ani related alarms - ont-pwe : ont services pwe related alarms - ont-cese1 : ont services cese1 related alarms - ont-xdsl : ont services xdsl related alarms - ont-xdsl-tca : ont services xdsl tca related alarms - ont-hpna : ont hpna related alarms - ont-sip-agent-cfg : ont services voip sip agent config related alarms - ont-voip-cfg : ont services voip config related alarms - ont-mgc : ont mgc related alarms - ont-ploam : ONT PLOAM related alarms - ont-gen : ONT GENERAL related alarms - ont-card : ONT Subscriber Card related alarms - ont-pots : ONT Services POTS related alarms - ont-lan : ONT Services LAN related alarms - ont-moca : ONT MoCA related alarms - ont-tc-tca : ONT TC TCA related alarms - ont-moca-tca : ONT MoCA TCA related alarms - ont-l2uni-eth-tca : ONT L2 UNI Ethernet TCA related alarms - olt-pon-tc-tca : OLT PON TC TCA related alarms - olt-pon-util-tca : OLT PON utilization TCA related alarms - olt-chpr-util-tca : OLT channel-pair utilization TCA related alarms - olt-ont-tc-tca : OLT ONT TC TCA related alarms - ont-tca : ONT TCA related alarms - ont-pots-supplemental : ONT POTS Supplemental related alarms - sfu-ploam : SFU ONT PLOAM related alarms - sfu-gen : SFU ONT general related alarms - soho-ploam : SOHO ONT PLOAM related alarms - soho-gen : SOHO ONT general related alarms - mdu-ploam : MDU ONT PLOAM related alarms - mdu-gen : MDU ONT general related alarms - ont-veip : ONT VEIP related alarms - ont-iphost : ONT IP HOST related alarms - alarm-table : alarm table related alarms - auto-switch : auto-switch related alarms - channel-pair : channel pair related alarms - ont-cfg-dld : ont configure file download related alarms - olt-chpair-tc-tca : OLT CHANNELPAIR TC TCA related alarms - hgu-tr069 : hgu tr069 related alarms - eqpt-psu : equipment psu alarms - ont-protection : ONT protection related alarms - secondary-megaco-term : secondary megaco termination related alarms - secondary-sip-term : secondary sip termination related alarms - cas-r2-channel : CAS R2 channel related alarms - lldpmed : lldpmed alarms - pseudo-wire : pseudo Wire related alarms - link-agg : Link aggregation related alarms - fcs-exceed : FCS auto-recovery related alarms - e1t1-interface : E1/T1 physical interfaces related alarms	
name	Parameter type: <Alarm::almtypeL2forward>	alarm name that are active

101 query current alarms by filters

name	Type	Description
	(mac-conflict vmac-full all) Possible values: - mac-conflict : duplicate mac address on the bridge port - vmac-full : virtual mac address is full on the bridge port - all : show all l2forward alarm	<i>This element is only shown in detail mode.</i>
severity	Parameter type: <Alarm::AlarmSeverity> (indeterminate warning minor major critical) Possible values: - indeterminate : alarm severity is indeterminate - warning : alarm severity is warning - minor : alarm severity is minor - major : alarm severity is major - critical : alarm severity is critical	the alarms severity level <i>This element is only shown in detail mode.</i>
servaff	Parameter type: <Alarm::alarmServAffect> ((service-affecting yes) (noservice-affecting no)) Possible values: - service-affecting : make this alarm service affecting - yes : make this alarm service affecting - noservice-affecting : make this alarm not service affecting - no : make this alarm not service affecting	alarms affect service or not <i>This element is only shown in detail mode.</i>
location	Parameter type: <Alarm::almLocation> (near-end far-end middle-end line null) Possible values: - near-end : alarm location is near - far-end : alarm location is far - middle-end : alarm location is middle - line : alarm location is line - null : alarm location not defined	alarm location: near, middle, far <i>This element is only shown in detail mode.</i>
time	Parameter type: <Sys::timeInSecs> - the time (yyyy-mm-dd:hour:minutes:secs) - unit: UTC	time in seconds when alarm was updated <i>This element is only shown in detail mode.</i>
direction	Parameter type: <Alarm::almDirection> (received transmit null) Possible values: - received : alarm is received - transmit : alarm is transmit - null : direction not defined	alarm direction: received or transmit <i>This element is only shown in detail mode.</i>
descript	Parameter type: <Alarm::AddInfoString> - additional alarm information	alarm description <i>This element is only shown in detail mode.</i>

101.12 show current alarm by filters

Command Description

show current alarms by filters

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm query sync [ (name) [ severity <Alarm::querySeverity> ] [ servaff <Alarm::queryServAffect> ] [ board <Alarm::SynceSlot> ] ]
```

Command Parameters

Table 101.12-1 "show current alarm by filters" Resource Parameters

Resource Identifier	Type	Description
(name)	Format: (synce-fail bits-fail bits-output-shutoff ieee1588-fail gnss-fail ieee1588-hybrid-fail holdover tod-reference-fail internal-clk-fail all) Possible values: - synce-fail : synce clock source failure - bits-fail : bits clock source failure - bits-output-shutoff : bits output failure - ieee1588-fail : ieee1588 clock source failure - gnss-fail : gnss clock source failure - ieee1588-hybrid-fail : ieee1588 hybrid tod source failure - holdover : clock system is in the holdover - tod-reference-fail : Timing ToD Reference failed - internal-clk-fail : Internal CLK failed - all : show all external device alarm	alarm name of sync
severity	Parameter type: <Alarm::querySeverity> Format: (indeterminate warning minor major	severity level of an alarm for reporting

101 query current alarms by filters

Resource Identifier	Type	Description
	critical all) Possible values: - indeterminate : alarm severity is indeterminate - warning : alarm severity is warning - minor : alarm severity is minor - major : alarm severity is major - critical : alarm severity is critical - all : all alarm severity	
servaff	Parameter type: <Alarm::queryServAffect> Format: (service-affecting noservice-affecting all) Possible values: - service-affecting : query alarm service affecting - noservice-affecting : query alarm not service affecting - all : query service affecting and not affecting alarms	serviceaffecting no serviceaffecting
board	Parameter type: <Alarm::SynceSlot> Format: (ntio-1 ntio-2 nt-a nt-b lt : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> not-used nt) Possible values: - ntio-1 : an nt applique slot in a single or multiple-ntio-shelf - ntio-2 : an nt applique slot in a multiple-ntio-shelf - nt-a : nt-a slot - nt-b : nt-b slot - nt : active nt slot - lt : lt slot - not-used : no interface Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number	the physical number of the slot

Command Output

Table 101.12-2 "show current alarm by filters" Display parameters

Specific Information		
name	Type	Description
aidinfo	Parameter type: <Alarm::AddInfoString> - additional alarm information	alarm AID parameters <i>This element is only shown in detail mode.</i>
type	Parameter type: <Alarm::alarmIHUBType> (equipment eqpt-holder plug-in-unit atm custom	type of the alarms that are active <i>This element is only shown in detail mode.</i>

name	Type	Description
	e1 ima-group ima-link redundancy shdsl ether-itf traffic-overflow qos-queue temporal spatial (software-mngt sw-mgmt) xdsl xdsl-ext xdsl-tca olt-gen eo-conv authentication bonding sfp shdsl-isam custom-ext-alarm plug-in-unit-ext sip-user-agent sip-plugin-unit sip-termination e1-sip-termination filetransfer external-device l2forward ether-tca ether-sfp megaco-media-gw megaco-sig-gw megaco-plugin-unit megaco-term megaco-sig-lt eqpt-supplemental eqpt-holder-ext lsmredundancy sync mcsrc vlanport vect-line vect-board otdr sip-dial-plan sip-vsp sip-server bgp rip lag ihub-general vpn isis ospf ihub-l2forward vpls	

101 query current alarms by filters

name	Type	Description
	ihub-equip ihub-link eont-phyoam ellid epon eont-services-lan eolt-ont-tca eont-sw-dl ldp mpls sdp epipe ihub-ipv6 pim li mgmt-sec-access bfd ai tr069serv ontsnmp bulk-sync protection-group ont sfu-sup soho-sup mdu-sup ont-ani sfu-sup2 soho-sup2 mdu-sup2 sfrssi eoltrssi cfm sfpe1t1-framer sfpe1t1-clock pppcc-engine-tca eth-cfm rsvp ihub-tca eth-ring efm-oam ont-loopdetect ont-video ont-ces ont-voip ont-video-ani ont-pwe ont-cese1 ont-xdsl ont-xdsl-tca ont-hpna ont-sip-agent-cfg ont-voip-cfg ont-mgc ont-ploam ont-gen ont-card	

name	Type	Description
	ont-pots ont-lan ont-moca ont-tc-tca ont-moca-tca ont-l2uni-eth-tca olt-pon-tc-tca olt-pon-util-tca olt-chpr-util-tca olt-ont-tc-tca ont-tca ont-pots-supplemental sfu-ploam sfu-gen soho-ploam soho-gen mdu-ploam mdu-gen ont-veip ont-iphost alarm-table auto-switch channel-pair ont-cfg-dld olt-chpair-tc-tca hgu-tr069 eqpt-psu ont-protection secondary-megaco-term secondary-sip-term cas-r2-channel lldpmed pseudo-wire link-agg fcs-exceed e1t1-interface) Possible values: - equipment : equipment alarms - eqpt-holder : equipment holder alarms - plug-in-unit : plugin unit alarms - atm : ATM alarms - custom : customizable alarms - e1 : e1 alarms - ima-group : ima-group alarms - ima-link : ima-link alarms - redundancy : redundancy alarms - shdsl : shdsl alarms - ether-itf : ethernet interface alarms - traffic-overflow : Traffic overflow alarms - qos-queue : qos queue alarms - temporal : temporal alarms - spatial : spatial alarms - software-mngt : software management alarms - sw-mgmt : software management alarms - xdsl : xDSL alarms - xdsl-ext : other xDSL alarms - xdsl-tca : xDSL threshold cross alarms	

101 query current alarms by filters

name	Type	Description
	- olt-gen : OLT general alarms - eo-conv : E/O conversion related alarms - authentication : authentication related alarms - bonding : bonding-group related alarms - sfp : SFP related alarms - shdsl-isam : shdsl isam alarms - custom-ext-alarm : customizable external alarms - plug-in-unit-ext : other plugin unit alarms - sip-user-agent : sip user agent related alarms - sip-plugin-unit : sip plug in unit related alarms - sip-termination : sip termination related alarms - e1-sip-termination : E1 sip termination related alarms - filetransfer : file transfer server alarms - external-device : external device related alarms - l2forward : l2forward related alarms - ether-tca : ethernet threshold cross alarms - ether-sfp : ethernet SFP related alarms - megaco-media-gw : megaco media gateway related alarms - megaco-sig-gw : megaco signaling gateway related alarms - megaco-plug-unit : megaco plug unit related alarms - megaco-term : megaco termination related alarms - megaco-sig-lt : megaco signaling lt related alarms - eqpt-supplemental : equipment supplemental alarms - eqpt-holder-ext : other equipment holder alarms - lsmredundancy : lsm redundancy alarms - sync : synce and bits alarms - mcsrc : multicast source alarms - vlanport : vlanport alarms - vect-line : xDSL vectoring line alarms - vect-board : xDSL vectoring board alarms - otdr : otdr alarms - sip-dial-plan : sip dial plan related alarms - sip-vsp : sip vsp related alarms - sip-server : sip server related alarms - bgp : bgp related alarms - rip : rip related alarms - lag : LAG related alarms - ihub-general : IHUB general related alarms - vprn : vprn related alarms - isis : isis related alarms - ospf : ospf related alarms - ihub-l2forward : ihub-l2forward alarms - vpls : vpls related alarms - ihub-equip : ihub-equip related alarms - ihub-link : ihub-link related alarms - eont-phyoam : eont phyoam related alarms - ellid : ellid related alarms - epon : epon related alarms - eont-services-lan : eon phyoam related alarms - eolt-ont-tca : eon phyoam related alarms - eont-sw-dl : eon phyoam related alarms - ldp : ldp related alarms - mpls : mpls related alarms - sdp : sdp related alarms - epipe : epipe related alarms - ihub-ipv6 : ihub-ipv6 related alarms - pim : pim related alarms	

name	Type	Description
	- li : lawful intercept related alarms - mgmt-sec-access : management security related alarms - bfd : bfd related alarms - ai : Application Intelligence related alarms - tr069serv : tr069 server related alarms - ontsnmp : ont snmp related alarms - bulk-sync : bulk-sync related alarms - protection-group : port protection group related alarms - ont : ONT general supplemental related alarms - sfu-sup : SFU ONT general supplemental related alarms - soho-sup : SOHO ONT general supplemental related alarms - mdu-sup : MDU ONT general supplemental related alarms - ont-ani : ONT general supplemental 2 related alarms - sfu-sup2 : SFU ONT general supplemental 2 related alarms - soho-sup2 : SOHO ONT general supplemental 2 related alarms - mdu-sup2 : MDU ONT general supplemental 2 related alarms - sfprssi : SFP RSSI related alarms - eoltrssi : epon olt Sfp RSSI related alarms - cfm : Cfm related alarms - sfpe1t1-framer : SFP 2e1t1 framer alarms - sfpe1t1-clock : SFP 2e1t1 clock alarms - pppcc-engine-tca : PPPOE Cross Connect Engine TCA related alarm - eth-cfm : eth-cfm related alarms - rsvp : rsvp related alarms - ihub-tca : IHUB TCA related alarms - eth-ring : eth-ring related alarms - efm-oam : EFM-OAM related alarms - ont-loopdetect : ont loop detect related alarms - ont-video : ont services video related alarms - ont-ces : ont services ces related alarms - ont-voip : ont services voip related alarms - ont-video-ani : ont services video ani related alarms - ont-pwe : ont services pwe related alarms - ont-cese1 : ont services cese1 related alarms - ont-xdsl : ont services xdsl related alarms - ont-xdsl-tca : ont services xdsl tca related alarms - ont-hpna : ont hpna related alarms - ont-sip-agent-cfg : ont services voip sip agent config related alarms - ont-voip-cfg : ont services voip config related alarms - ont-mgc : ont mgc related alarms - ont-ploam : ONT PLOAM related alarms - ont-gen : ONT GENERAL related alarms - ont-card : ONT Subscriber Card related alarms - ont-pots : ONT Services POTS related alarms - ont-lan : ONT Services LAN related alarms - ont-moca : ONT MoCA related alarms - ont-tc-tca : ONT TC TCA related alarms - ont-moca-tca : ONT MoCA TCA related alarms - ont-l2uni-eth-tca : ONT L2 UNI Ethernet TCA related alarms - olt-pon-tc-tca : OLT PON TC TCA related alarms - olt-pon-util-tca : OLT PON utilization TCA related alarms	

101 query current alarms by filters

name	Type	Description
	- olt-chpr-util-tca : OLT channel-pair utilization TCA related alarms - olt-ont-tc-tca : OLT ONT TC TCA related alarms - ont-tca : ONT TCA related alarms - ont-pots-supplemental : ONT POTS Supplemental related alarms - sfu-ploam : SFU ONT PLOAM related alarms - sfu-gen : SFU ONT general related alarms - soho-ploam : SOHO ONT PLOAM related alarms - soho-gen : SOHO ONT general related alarms - mdu-ploam : MDU ONT PLOAM related alarms - mdu-gen : MDU ONT general related alarms - ont-veip : ONT VEIP related alarms - ont-iphost : ONT IP HOST related alarms - alarm-table : alarm table related alarms - auto-switch : auto-switch related alarms - channel-pair : channel pair related alarms - ont-cfg-dld : ont configure file download related alarms - olt-chpair-tc-tca : OLT CHANNELPAIR TC TCA related alarms - hgu-tr069 : hgu tr069 related alarms - eqpt-psu : equipment psu alarms - ont-protection : ONT protection related alarms - secondary-megaco-term : secondary megaco termination related alarms - secondary-sip-term : secondary sip termination related alarms - cas-r2-channel : CAS R2 channel related alarms - lldpmed : lldpmed alarms - pseudo-wire : pseudo Wire related alarms - link-agg : Link aggregation related alarms - fcs-exceed : FCS auto-recovery related alarms - e1t1-interface : E1/T1 physical interfaces related alarms	
name	Parameter type: <Alarm::almtypeSync> (synce-fail bits-fail bits-output-shutoff ieee1588-fail gnss-fail ieee1588-hybrid-fail holdover tod-reference-fail internal-clk-fail all) Possible values: - synce-fail : synce clock source failure - bits-fail : bits clock source failure - bits-output-shutoff : bits output failure - ieee1588-fail : ieee1588 clock source failure - gnss-fail : gnss clock source failure - ieee1588-hybrid-fail : ieee1588 hybrid tod source failure - holdover : clock system is in the holdover - tod-reference-fail : Timing ToD Reference failed - internal-clk-fail : Internal CLK failed - all : show all external device alarm	alarm name that are active <i>This element is only shown in detail mode.</i>
severity	Parameter type: <Alarm::AlarmSeverity> (indeterminate	the alarms severity level <i>This element is only shown in</i>

name	Type	Description
	warning minor major critical) Possible values: - indeterminate : alarm severity is indeterminate - warning : alarm severity is warning - minor : alarm severity is minor - major : alarm severity is major - critical : alarm severity is critical	<i>detail mode.</i>
servaff	Parameter type: <Alarm::alarmServAffect> ((service-affecting yes) (noservice-affecting no)) Possible values: - service-affecting : make this alarm service affecting - yes : make this alarm service affecting - noservice-affecting : make this alarm not service affecting - no : make this alarm not service affecting	alarms affect service or not <i>This element is only shown in detail mode.</i>
time	Parameter type: <Sys::timeInSecs> - the time (yyyy-mm-dd:hour:minutes:secs) - unit: UTC	time in seconds when alarm was updated <i>This element is only shown in detail mode.</i>
descript	Parameter type: <Alarm::AddInfoString> - additional alarm information	alarm description <i>This element is only shown in detail mode.</i>

101.13 show current alarm by filters

Command Description

show current alarms by filters

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm query cfm [ (name) [ severity <Alarm::querySeverity> ] [ servaff <Alarm::queryServAffect> ] [ cfm-mep-id <UnsignedSignedInteger> ] ]
```

Command Parameters

Table 101.13-1 "show current alarm by filters" Resource Parameters

Resource Identifier	Type	Description
(name)	Format: (cfm-defrdiccm cfm-defmacstatus cfm-defremoteccm cfm-deferrorccm cfm-defxconccm cfm-defais all) Possible values: - cfm-defrdiccm : rdi bit in ccm received - cfm-defmacstatus : ccm mac error status - cfm-defremoteccm : missing ccm from mep - cfm-deferrorccm : invalid ccm received - cfm-defxconccm : unexpected ccm received - cfm-defais : ethernet ais received - all : show all multicast source alarm	alarm name of cfm
severity	Parameter type: <Alarm::querySeverity> Format: (indeterminate warning minor major critical all) Possible values: - indeterminate : alarm severity is indeterminate - warning : alarm severity is warning - minor : alarm severity is minor	severity level of an alarm for reporting

Resource Identifier	Type	Description
	- major : alarm severity is major - critical : alarm severity is critical - all : all alarm severity	
servaff	Parameter type: <Alarm::queryServAffect> Format: (service-affecting noservice-affecting all) Possible values: - service-affecting : query alarm service affecting - noservice-affecting : query alarm not service affecting - all : query service affecting and not affecting alarms	serviceaffecting no serviceaffecting
cfm-mep-id	Parameter type: <UnsignedSignedInteger> Format: - an unsigned integer	dot1agCfmMepIdentifier index

Command Output

Table 101.13-2 "show current alarm by filters" Display parameters

Specific Information		
name	Type	Description
aidinfo	Parameter type: <Alarm::AddInfoString> - additional alarm information	alarm AID parameters <i>This element is only shown in detail mode.</i>
type	Parameter type: <Alarm::alarmIHUBType> (equipment eqpt-holder plug-in-unit atm custom e1 ima-group ima-link redundancy shdsl ether-itf traffic-overflow qos-queue temporal spatial (software-mngt sw-mgmt) xdsl xdsl-ext xdsl-tca olt-gen eo-conv authentication bonding sfp shdsl-isam custom-ext-alarm plug-in-unit-ext sip-user-agent sip-plugin-unit sip-termination e1-sip-termination	type of the alarms that are active <i>This element is only shown in detail mode.</i>

101 query current alarms by filters

name	Type	Description
	filetransfer	
	external-device	
	l2forward	
	ether-tca	
	ether-sfp	
	megaco-media-gw	
	megaco-sig-gw	
	megaco-plug-unit	
	megaco-term	
	megaco-sig-lt	
	eqpt-supplemental	
	eqpt-holder-ext	
	lsmredundancy	
	sync	
	mcsrc	
	vlanport	
	vect-line	
	vect-board	
	otdr	
	sip-dial-plan	
	sip-vsp	
	sip-server	
	bgp	
	rip	
	lag	
	ihub-general	
	vprn	
	isis	
	ospf	
	ihub-l2forward	
	vpls	
	ihub-equip	
	ihub-link	
	eont-phyoam	
	ellid	
	epon	
	eont-services-lan	
	eolt-ont-tca	
	eont-sw-dl	
	ldp	
	mpls	
	sdp	
	epipe	
	ihub-ipv6	
	pim	
	li	
	mgmt-sec-access	
	bfd	
	ai	
	tr069serv	
	ontsnmp	
	bulk-sync	
	protection-group	
	ont	
	sfu-sup	
	soho-sup	
	mdu-sup	

name	Type	Description
	ont-ani sfu-sup2 soho-sup2 mdu-sup2 sfprssi eoltrssi cfm sfpe1t1-framer sfpe1t1-clock pppcc-engine-tca eth-cfm rsvp ihub-tca eth-ring efm-oam ont-loopdetect ont-video ont-ces ont-voip ont-video-ani ont-pwe ont-cese1 ont-xdsl ont-xdsl-tca ont-hpna ont-sip-agent-cfg ont-voip-cfg ont-mgc ont-ploam ont-gen ont-card ont-pots ont-lan ont-moca ont-tc-tca ont-moca-tca ont-l2uni-eth-tca olt-pon-tc-tca olt-pon-util-tca olt-chpr-util-tca olt-ont-tc-tca ont-tca ont-pots-supplemental sfu-ploam sfu-gen soho-ploam soho-gen mdu-ploam mdu-gen ont-veip ont-iphost alarm-table auto-switch channel-pair ont-cfg-dld olt-chpair-tc-tca hgu-tr069	

101 query current alarms by filters

name	Type	Description
	eqpt-psu ont-protection secondary-megaco-term secondary-sip-term cas-r2-channel lldpmed pseudo-wire link-agg fcs-exceed e1t1-interface) Possible values: - equipment : equipment alarms - eqpt-holder : equipment holder alarms - plug-in-unit : plugin unit alarms - atm : ATM alarms - custom : customizable alarms - e1 : e1 alarms - ima-group : ima-group alarms - ima-link : ima-link alarms - redundancy : redundancy alarms - shdsl : shdsl alarms - ether-itf : ethernet interface alarms - traffic-overflow : Traffic overflow alarms - qos-queue : qos queue alarms - temporal : temporal alarms - spatial : spatial alarms - software-mngt : software management alarms - sw-mgmt : software management alarms - xdsl : xDSL alarms - xdsl-ext : other xDSL alarms - xdsl-tca : xDSL threshold cross alarms - olt-gen : OLT general alarms - eo-conv : E/O conversion related alarms - authentication : authentication related alarms - bonding : bonding-group related alarms - sfp : SFP related alarms - shdsl-isam : shdsl isam alarms - custom-ext-alarm : customizable external alarms - plug-in-unit-ext : other plugin unit alarms - sip-user-agent : sip user agent related alarms - sip-plugin-unit : sip plug in unit related alarms - sip-termination : sip termination related alarms - e1-sip-termination : E1 sip termination related alarms - filetransfer : file transfer server alarms - external-device : external device related alarms - l2forward : l2forward related alarms - ether-tca : ethernet threshold cross alarms - ether-sfp : ethernet SFP related alarms - megaco-media-gw : megaco media gateway related alarms - megaco-sig-gw : megaco signaling gateway related alarms - megaco-plug-unit : megaco plug unit related alarms - megaco-term : megaco termination related alarms - megaco-sig-lt : megaco signaling lt related alarms - eqpt-supplemental : equipment supplemental alarms - eqpt-holder-ext : other equipment holder alarms - lsmredundancy : lsm redundancy alarms - sync : synce and bits alarms	

name	Type	Description
	- mcsrc : multicast source alarms - vlanport : vlanport alarms - vect-line : xDSL vectoring line alarms - vect-board : xDSL vectoring board alarms - otdr : otdr alarms - sip-dial-plan : sip dial plan related alarms - sip-vsp : sip vsp related alarms - sip-server : sip server related alarms - bgp : bgp related alarms - rip : rip related alarms - lag : LAG related alarms - ihub-general : IHUB general related alarms - vprn : vprn related alarms - isis : isis related alarms - ospf : ospf related alarms - ihub-l2forward : ihub-l2forward alarms - vpls : vpls related alarms - ihub-equip : ihub-equip related alarms - ihub-link : ihub-link related alarms - eont-phyoam : eont phyoam related alarms - ellid : ellid related alarms - epon : epon related alarms - eont-services-lan : eon phyoam related alarms - eolt-ont-tca : eon phyoam related alarms - eont-sw-dl : eon phyoam related alarms - ldp : ldp related alarms - mpls : mpls related alarms - sdp : sdp related alarms - epipe : epipe related alarms - ihub-ipv6 : ihub-ipv6 related alarms - pim : pim related alarms - li : lawful intercept related alarms - mgmt-sec-access : management security related alarms - bfd : bfd related alarms - ai : Application Intelligence related alarms - tr069serv : tr069 server related alarms - ontsnmp : ont snmp related alarms - bulk-sync : bulk-sync related alarms - protection-group : port protection group related alarms - ont : ONT general supplemental related alarms - sfu-sup : SFU ONT general supplemental related alarms - soho-sup : SOHO ONT general supplemental related alarms - mdu-sup : MDU ONT general supplemental related alarms - ont-ani : ONT general supplemental 2 related alarms - sfu-sup2 : SFU ONT general supplemental 2 related alarms - soho-sup2 : SOHO ONT general supplemental 2 related alarms - mdu-sup2 : MDU ONT general supplemental 2 related alarms - sfprssi : SFP RSSI related alarms - eoltrssi : epon olt Sfp RSSI related alarms - cfm : Cfm related alarms - sfpe1t1-framer : SFP 2e1t1 framer alarms - sfpe1t1-clock : SFP 2e1t1 clock alarms - pppcc-engine-tca : PPPOE Cross Connect Engine TCA related alarm	

101 query current alarms by filters

name	Type	Description
	- eth-cfm : eth-cfm related alarms - rsvp : rsvp related alarms - ihub-tca : IHUB TCA related alarms - eth-ring : eth-ring related alarms - efm-oam : EFM-OAM related alarms - ont-loopdetect : ont loop detect related alarms - ont-video : ont services video related alarms - ont-ces : ont services ces related alarms - ont-voip : ont services voip related alarms - ont-video-ani : ont services video ani related alarms - ont-pwe : ont services pwe related alarms - ont-cese1 : ont services cese1 related alarms - ont-xdsl : ont services xdsl related alarms - ont-xdsl-tca : ont services xdsl tca related alarms - ont-hpna : ont hpna related alarms - ont-sip-agent-cfg : ont services voip sip agent config related alarms - ont-voip-cfg : ont services voip config related alarms - ont-mgc : ont mgc related alarms - ont-ploam : ONT PLOAM related alarms - ont-gen : ONT GENERAL related alarms - ont-card : ONT Subscriber Card related alarms - ont-pots : ONT Services POTS related alarms - ont-lan : ONT Services LAN related alarms - ont-moca : ONT MoCA related alarms - ont-tc-tca : ONT TC TCA related alarms - ont-moca-tca : ONT MoCA TCA related alarms - ont-l2uni-eth-tca : ONT L2 UNI Ethernet TCA related alarms - olt-pon-tc-tca : OLT PON TC TCA related alarms - olt-pon-util-tca : OLT PON utilization TCA related alarms - olt-chpr-util-tca : OLT channel-pair utilization TCA related alarms - olt-ont-tc-tca : OLT ONT TC TCA related alarms - ont-tca : ONT TCA related alarms - ont-pots-supplemental : ONT POTS Supplemental related alarms - sfu-ploam : SFU ONT PLOAM related alarms - sfu-gen : SFU ONT general related alarms - soho-ploam : SOHO ONT PLOAM related alarms - soho-gen : SOHO ONT general related alarms - mdu-ploam : MDU ONT PLOAM related alarms - mdu-gen : MDU ONT general related alarms - ont-veip : ONT VEIP related alarms - ont-iphost : ONT IP HOST related alarms - alarm-table : alarm table related alarms - auto-switch : auto-switch related alarms - channel-pair : channel pair related alarms - ont-cfg-dld : ont configure file download related alarms - olt-chpair-tc-tca : OLT CHANNELPAIR TC TCA related alarms - hgu-tr069 : hgu tr069 related alarms - eqpt-psu : equipment psu alarms - ont-protection : ONT protection related alarms - secondary-megaco-term : secondary megaco termination related alarms - secondary-sip-term : secondary sip termination related	

name	Type	Description
	alarms - cas-r2-channel : CAS R2 channel related alarms - lldpmed : lldpmed alarms - pseudo-wire : pseudo Wire related alarms - link-agg : Link aggregation related alarms - fcs-exceed : FCS auto-recovery related alarms - e1t1-interface : E1/T1 physical interfaces related alarms	
name	Parameter type: <Alarm::alarmTypeCfm> (cfm-defrdiccm cfm-defmacstatus cfm-defremoteccm cfm-deferrorccm cfm-defxconccm cfm-defais all) Possible values: - cfm-defrdiccm : rdi bit in ccm received - cfm-defmacstatus : ccm mac error status - cfm-defremoteccm : missing ccm from mep - cfm-deferrorccm : invalid ccm received - cfm-defxconccm : unexpected ccm received - cfm-defais : ethernet ais received - all : show all multicast source alarm	alarm name that are active <i>This element is only shown in detail mode.</i>
severity	Parameter type: <Alarm::AlarmSeverity> (indeterminate warning minor major critical) Possible values: - indeterminate : alarm severity is indeterminate - warning : alarm severity is warning - minor : alarm severity is minor - major : alarm severity is major - critical : alarm severity is critical	the alarms severity level <i>This element is only shown in detail mode.</i>
servaff	Parameter type: <Alarm::alarmServAffect> ((service-affecting yes) (noservice-affecting no)) Possible values: - service-affecting : make this alarm service affecting - yes : make this alarm service affecting - noservice-affecting : make this alarm not service affecting - no : make this alarm not service affecting	alarms affect service or not <i>This element is only shown in detail mode.</i>
time	Parameter type: <Sys::timeInSecs> - the time (yyyy-mm-dd:hour:minutes:secs) - unit: UTC	time in seconds when alarm was updated <i>This element is only shown in detail mode.</i>
descript	Parameter type: <Alarm::AddInfoString> - additional alarm information	alarm description <i>This element is only shown in detail mode.</i>

101.14 show current alarm by filters

Command Description

show current alarms by filters

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm query efm-oam [ (name) [ severity <Alarm::querySeverity> ] [ servaff <Alarm::queryServAffect> ] [
line <Itf::EfmEthernetIndex> ] ]
```

Command Parameters

Table 101.14-1 "show current alarm by filters" Resource Parameters

Resource Identifier	Type	Description
(name)	Format: (efm-oam-cpelinkfault efm-oam-cpedyinggasp efm-oam-cpecrevt all) Possible values: - efm-oam-cpelinkfault : EFM-OAM CPE link fault - efm-oam-cpedyinggasp : EFM-OAM CPE dying gasp - efm-oam-cpecrevt : EFM-OAM CPE critical event - all : show all vlanport alarm	alarm name of efm-oam
severity	Parameter type: <Alarm::querySeverity> Format: (indeterminate warning minor major critical all) Possible values: - indeterminate : alarm severity is indeterminate - warning : alarm severity is warning - minor : alarm severity is minor - major : alarm severity is major - critical : alarm severity is critical - all : all alarm severity	severity level of an alarm for reporting
servaff	Parameter type: <Alarm::queryServAffect> Format: (service-affecting	serviceaffecting no

Resource Identifier	Type	Description
	noservice-affecting all) Possible values: - service-affecting : query alarm service affecting - noservice-affecting : query alarm not service affecting - all : query service affecting and not affecting alarms	
line	Parameter type: <Itf::EfmEthernetIndex> Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number	the number of ethernet line

Command Output

Table 101.14-2 "show current alarm by filters" Display parameters

Specific Information		
name	Type	Description
aidinfo	Parameter type: <Alarm::AddInfoString> - additional alarm information	alarm AID parameters <i>This element is only shown in detail mode.</i>
type	Parameter type: <Alarm::alarmIHUBType> (equipment eqpt-holder plug-in-unit atm custom e1 ima-group ima-link redundancy shdsl ether-itf traffic-overflow qos-queue temporal spatial (software-mngt sw-mgmt) xdsl xdsl-ext xdsl-tca olt-gen eo-conv authentication bonding sfp shdsl-isam custom-ext-alarm plug-in-unit-ext sip-user-agent	type of the alarms that are active <i>This element is only shown in detail mode.</i>

101 query current alarms by filters

name	Type	Description
	sip-plugin-unit sip-termination e1-sip-termination filetransfer external-device l2forward ether-tca ether-sfp megaco-media-gw megaco-sig-gw megaco-plug-unit megaco-term megaco-sig-lt eqpt-supplemental eqpt-holder-ext lsmredundancy sync mcsrc vlanport vect-line vect-board otdr sip-dial-plan sip-vsp sip-server bgp rip lag ihub-general vprn isis ospf ihub-l2forward vpls ihub-equip ihub-link eont-phyoam ellid epon eont-services-lan eolt-ont-tca eont-sw-dl ldp mpls sdp epipe ihub-ipv6 pim li mgmt-sec-access bfd ai tr069serv ontsnmp bulk-sync protection-group ont	

name	Type	Description
	sfu-sup	
	soho-sup	
	mdu-sup	
	ont-ani	
	sfu-sup2	
	soho-sup2	
	mdu-sup2	
	sfprssi	
	eoltrssi	
	cfm	
	sfpe1t1-framer	
	sfpe1t1-clock	
	pppcc-engine-tca	
	eth-cfm	
	rsvp	
	ihub-tca	
	eth-ring	
	efm-oam	
	ont-loopdetect	
	ont-video	
	ont-ces	
	ont-voip	
	ont-video-ani	
	ont-pwe	
	ont-cese1	
	ont-xdsl	
	ont-xdsl-tca	
	ont-hpna	
	ont-sip-agent-cfg	
	ont-voip-cfg	
	ont-mgc	
	ont-ploam	
	ont-gen	
	ont-card	
	ont-pots	
	ont-lan	
	ont-moca	
	ont-tc-tca	
	ont-moca-tca	
	ont-l2uni-eth-tca	
	olt-pon-tc-tca	
	olt-pon-util-tca	
	olt-chpr-util-tca	
	olt-ont-tc-tca	
	ont-tca	
	ont-pots-supplemental	
	sfu-ploam	
	sfu-gen	
	soho-ploam	
	soho-gen	
	mdu-ploam	
	mdu-gen	
	ont-veip	
	ont-iphost	
	alarm-table	
	auto-switch	
	channel-pair	

101 query current alarms by filters

name	Type	Description
	ont-cfg-dld olt-chpair-tc-tca hgu-tr069 eqpt-psu ont-protection secondary-megaco-term secondary-sip-term cas-r2-channel lldpmed pseudo-wire link-agg fcs-exceed e1t1-interface) Possible values: - equipment : equipment alarms - eqpt-holder : equipment holder alarms - plug-in-unit : plugin unit alarms - atm : ATM alarms - custom : customizable alarms - e1 : e1 alarms - ima-group : ima-group alarms - ima-link : ima-link alarms - redundancy : redundancy alarms - shdsl : shdsl alarms - ether-itf : ethernet interface alarms - traffic-overflow : Traffic overflow alarms - qos-queue : qos queue alarms - temporal : temporal alarms - spatial : spatial alarms - software-mngt : software management alarms - sw-mgmt : software management alarms - xdsl : xDSL alarms - xdsl-ext : other xDSL alarms - xdsl-tca : xDSL threshold cross alarms - olt-gen : OLT general alarms - eo-conv : E/O conversion related alarms - authentication : authentication related alarms - bonding : bonding-group related alarms - sfp : SFP related alarms - shdsl-isam : shdsl isam alarms - custom-ext-alarm : customizable external alarms - plug-in-unit-ext : other plugin unit alarms - sip-user-agent : sip user agent related alarms - sip-plugin-unit : sip plug in unit related alarms - sip-termination : sip termination related alarms - e1-sip-termination : E1 sip termination related alarms - filetransfer : file transfer server alarms - external-device : external device related alarms - l2forward : l2forward related alarms - ether-tca : ethernet threshold cross alarms - ether-sfp : ethernet SFP related alarms - megaco-media-gw : megaco media gateway related alarms - megaco-sig-gw : megaco signaling gateway related alarms - megaco-plug-unit : megaco plug unit related alarms - megaco-term : megaco termination related alarms - megaco-sig-lt : megaco signaling lt related alarms - eqpt-supplemental : equipment supplemental alarms	

name	Type	Description
	- eqpt-holder-ext : other equipment holder alarms - lsmredundancy : lsm redundancy alarms - sync : synce and bits alarms - mcsrsc : multicast source alarms - vlanport : vlanport alarms - vect-line : xDSL vectoring line alarms - vect-board : xDSL vectoring board alarms - otdr : otdr alarms - sip-dial-plan : sip dial plan related alarms - sip-vsp : sip vsp related alarms - sip-server : sip server related alarms - bgp : bgp related alarms - rip : rip related alarms - lag : LAG related alarms - ihub-general : IHUB general related alarms - vprn : vprn related alarms - isis : isis related alarms - ospf : ospf related alarms - ihub-l2forward : ihub-l2forward alarms - vpls : vpls related alarms - ihub-equip : ihub-equip related alarms - ihub-link : ihub-link related alarms - eont-phyoam : eont phyoam related alarms - ellid : ellid related alarms - epon : epon related alarms - eont-services-lan : eon phyoam related alarms - eolt-ont-tca : eon phyoam related alarms - eont-sw-dl : eon phyoam related alarms - ldp : ldp related alarms - mpls : mpls related alarms - sdp : sdp related alarms - epipe : epipe related alarms - ihub-ipv6 : ihub-ipv6 related alarms - pim : pim related alarms - li : lawful intercept related alarms - mgmt-sec-access : management security related alarms - bfd : bfd related alarms - ai : Application Intelligence related alarms - tr069serv : tr069 server related alarms - ontsnmp : ont snmp related alarms - bulk-sync : bulk-sync related alarms - protection-group : port protection group related alarms - ont : ONT general supplemental related alarms - sfu-sup : SFU ONT general supplemental related alarms - soho-sup : SOHO ONT general supplemental related alarms - mdu-sup : MDU ONT general supplemental related alarms - ont-ani : ONT general supplemental 2 related alarms - sfu-sup2 : SFU ONT general supplemental 2 related alarms - soho-sup2 : SOHO ONT general supplemental 2 related alarms - mdu-sup2 : MDU ONT general supplemental 2 related alarms - sfrssi : SFP RSSI related alarms - eoltrssi : epon olt Sfp RSSI related alarms - cfm : Cfm related alarms - sfpe1t1-framer : SFP 2e1t1 framer alarms	

101 query current alarms by filters

name	Type	Description
	- sfpe1t1-clock : SFP 2e1t1 clock alarms - pppcc-engine-tca : PPPOE Cross Connect Engine TCA related alarm - eth-cfm : eth-cfm related alarms - rsvp : rsvp related alarms - ihub-tca : IHUB TCA related alarms - eth-ring : eth-ring related alarms - efm-oam : EFM-OAM related alarms - ont-loopdetect : ont loop detect related alarms - ont-video : ont services video related alarms - ont-ces : ont services ces related alarms - ont-voip : ont services voip related alarms - ont-video-ani : ont services video ani related alarms - ont-pwe : ont services pwe related alarms - ont-cese1 : ont services cese1 related alarms - ont-xdsl : ont services xdsl related alarms - ont-xdsl-tca : ont services xdsl tca related alarms - ont-hpna : ont hpna related alarms - ont-sip-agent-cfg : ont services voip sip agent config related alarms - ont-voip-cfg : ont services voip config related alarms - ont-mgc : ont mgc related alarms - ont-ploam : ONT PLOAM related alarms - ont-gen : ONT GENERAL related alarms - ont-card : ONT Subscriber Card related alarms - ont-pots : ONT Services POTS related alarms - ont-lan : ONT Services LAN related alarms - ont-moca : ONT MoCA related alarms - ont-tc-tca : ONT TC TCA related alarms - ont-moca-tca : ONT MoCA TCA related alarms - ont-l2uni-eth-tca : ONT L2 UNI Ethernet TCA related alarms - olt-pon-tc-tca : OLT PON TC TCA related alarms - olt-pon-util-tca : OLT PON utilization TCA related alarms - olt-chpr-util-tca : OLT channel-pair utilization TCA related alarms - olt-ont-tc-tca : OLT ONT TC TCA related alarms - ont-tca : ONT TCA related alarms - ont-pots-supplemental : ONT POTS Supplemental related alarms - sfu-ploam : SFU ONT PLOAM related alarms - sfu-gen : SFU ONT general related alarms - soho-ploam : SOHO ONT PLOAM related alarms - soho-gen : SOHO ONT general related alarms - mdu-ploam : MDU ONT PLOAM related alarms - mdu-gen : MDU ONT general related alarms - ont-veip : ONT VEIP related alarms - ont-iphost : ONT IP HOST related alarms - alarm-table : alarm table related alarms - auto-switch : auto-switch related alarms - channel-pair : channel pair related alarms - ont-cfg-dld : ont configure file download related alarms - olt-chpair-tc-tca : OLT CHANNELPAIR TC TCA related alarms - hgu-tr069 : hgu tr069 related alarms - eqpt-psu : equipment psu alarms - ont-protection : ONT protection related alarms	

name	Type	Description
	- secondary-megaco-term : secondary megaco termination related alarms - secondary-sip-term : secondary sip termination related alarms - cas-r2-channel : CAS R2 channel related alarms - lldpmed : lldpmed alarms - pseudo-wire : pseudo Wire related alarms - link-agg : Link aggregation related alarms - fcs-exceed : FCS auto-recovery related alarms - e1t1-interface : E1/T1 physical interfaces related alarms	
name	Parameter type: <Alarm::alarmTypeEfmoam> (efm-oam-cpelinkfault efm-oam-cpedyinggasp efm-oam-cpecrevt all) Possible values: - efm-oam-cpelinkfault : EFM-OAM CPE link fault - efm-oam-cpedyinggasp : EFM-OAM CPE dying gasp - efm-oam-cpecrevt : EFM-OAM CPE critical event - all : show all vlanport alarm	alarm name that are active <i>This element is only shown in detail mode.</i>
severity	Parameter type: <Alarm::AlarmSeverity> (indeterminate warning minor major critical) Possible values: - indeterminate : alarm severity is indeterminate - warning : alarm severity is warning - minor : alarm severity is minor - major : alarm severity is major - critical : alarm severity is critical	the alarms severity level <i>This element is only shown in detail mode.</i>
servaff	Parameter type: <Alarm::alarmServAffect> ((service-affecting yes) (noservice-affecting no)) Possible values: - service-affecting : make this alarm service affecting - yes : make this alarm service affecting - noservice-affecting : make this alarm not service affecting - no : make this alarm not service affecting	alarms affect service or not <i>This element is only shown in detail mode.</i>
time	Parameter type: <Sys::timeInSecs> - the time (yyyy-mm-dd:hour:minutes:secs) - unit: UTC	time in seconds when alarm was updated <i>This element is only shown in detail mode.</i>
descript	Parameter type: <Alarm::AddInfoString> - additional alarm information	alarm description <i>This element is only shown in detail mode.</i>

101.15 show current alarm by filters

Command Description

show current alarms by filters

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm query auto-switch [ (name) [ severity <Alarm::querySeverity> ] [ servaff <Alarm::queryServAffect> ] [ port <Itf::XdslLine> ] ]
```

Command Parameters

Table 101.15-1 "show current alarm by filters" Resource Parameters

Resource Identifier	Type	Description
(name)	Format: (auto-switch-status all auswqueuefullatm auswbkpfailatm auswrecfgfailatm auswdataunatm auswqueuefulptm auswbkpfailptm auswrecfgfailptm auswdataunptm auswbakpfailatm) Possible values: - auto-switch-status : auto-switch status - all : show all bgp alarm - auswqueuefullatm : auto-switch queue Full for ATM - auswbkpfailatm : auto-switch config data backup failed for ATM - auswrecfgfailatm : auto-switch fallback reconfiguration failed for ATM - auswdataunatm : auto-switch backup config data unavailable for ATM - auswqueuefulptm : auto-switch queue Full for PTM - auswbkpfailptm : auto-switch config data backup failed for PTM - auswrecfgfailptm : auto-switch fallback reconfiguration failed for PTM - auswdataunptm : auto-switch backup config data	alarm name of auto-switch

Resource Identifier	Type	Description
	unavailable for PTM - auswbakpfailatm : auto-switch backup fail for ATM	
severity	Parameter type: <Alarm::querySeverity> Format: (indeterminate warning minor major critical all) Possible values: - indeterminate : alarm severity is indeterminate - warning : alarm severity is warning - minor : alarm severity is minor - major : alarm severity is major - critical : alarm severity is critical - all : all alarm severity	severity level of an alarm for reporting
servaff	Parameter type: <Alarm::queryServAffect> Format: (service-affecting noservice-affecting all) Possible values: - service-affecting : query alarm service affecting - noservice-affecting : query alarm not service affecting - all : query service affecting and not affecting alarms	serviceaffecting no serviceaffecting
port	Parameter type: <Itf::XdslLine> Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number	the physical number of the port

Command Output

Table 101.15-2 "show current alarm by filters" Display parameters

Specific Information		
name	Type	Description
aidinfo	Parameter type: <Alarm::AddInfoString> - additional alarm information	alarm AID parameters <i>This element is only shown in detail mode.</i>
type	Parameter type: <Alarm::alarmIHUBType> (equipment eqpt-holder plug-in-unit atm custom e1 ima-group ima-link	type of the alarms that are active <i>This element is only shown in detail mode.</i>

101 query current alarms by filters

name	Type	Description
	redundancy shdsl ether-itf traffic-overflow qos-queue temporal spatial (software-mngt sw-mgmt) xdsl xdsl-ext xdsl-tca olt-gen eo-conv authentication bonding sfp shdsl-isam custom-ext-alarm plug-in-unit-ext sip-user-agent sip-plugin-unit sip-termination e1-sip-termination filetransfer external-device l2forward ether-tca ether-sfp megaco-media-gw megaco-sig-gw megaco-plug-unit megaco-term megaco-sig-lt eqpt-supplemental eqpt-holder-ext lsmredundancy sync mcsrc vlanport vect-line vect-board otdr sip-dial-plan sip-vsp sip-server bgp rip lag ihub-general vprn isis ospf ihub-l2forward vpls ihub-equip ihub-link eont-phyoam	

name	Type	Description
	ellid epon eont-services-lan eolt-ont-tca eont-sw-dl ldp mpls sdp epipe ihub-ipv6 pim li mgmt-sec-access bfd ai tr069serv ontsnmp bulk-sync protection-group ont sfu-sup soho-sup mdu-sup ont-ani sfu-sup2 soho-sup2 mdu-sup2 sfprssi eoltrssi cfm sfpe1t1-framer sfpe1t1-clock pppcc-engine-tca eth-cfm rsvp ihub-tca eth-ring efm-oam ont-loopdetect ont-video ont-ces ont-voip ont-video-ani ont-pwe ont-cese1 ont-xdsl ont-xdsl-tca ont-hpna ont-sip-agent-cfg ont-voip-cfg ont-mgc ont-ploam ont-gen ont-card ont-pots ont-lan ont-moca	

101 query current alarms by filters

name	Type	Description
	ont-tc-tca ont-moca-tca ont-l2uni-eth-tca olt-pon-tc-tca olt-pon-util-tca olt-chpr-util-tca olt-ont-tc-tca ont-tca ont-pots-supplemental sfu-ploam sfu-gen soho-ploam soho-gen mdu-ploam mdu-gen ont-veip ont-iphost alarm-table auto-switch channel-pair ont-cfg-dld olt-chpair-tc-tca hgu-tr069 eqpt-psu ont-protection secondary-megaco-term secondary-sip-term cas-r2-channel lldpmed pseudo-wire link-agg fcs-exceed e1t1-interface) Possible values: - equipment : equipment alarms - eqpt-holder : equipment holder alarms - plug-in-unit : plugin unit alarms - atm : ATM alarms - custom : customizable alarms - e1 : e1 alarms - ima-group : ima-group alarms - ima-link : ima-link alarms - redundancy : redundancy alarms - shdsl : shdsl alarms - ether-itf : ethernet interface alarms - traffic-overflow : Traffic overflow alarms - qos-queue : qos queue alarms - temporal : temporal alarms - spatial : spatial alarms - software-mngt : software management alarms - sw-mgmt : software management alarms - xdsl : xDSL alarms - xdsl-ext : other xDSL alarms - xdsl-tca : xDSL threshold cross alarms - olt-gen : OLT general alarms - eo-conv : E/O conversion related alarms - authentication : authentication related alarms	

name	Type	Description
	- bonding : bonding-group related alarms - sfp : SFP related alarms - shdsl-isam : shdsl isam alarms - custom-ext-alarm : customizable external alarms - plug-in-unit-ext : other plugin unit alarms - sip-user-agent : sip user agent related alarms - sip-plugin-unit : sip plug in unit related alarms - sip-termination : sip termination related alarms - e1-sip-termination : E1 sip termination related alarms - filetransfer : file transfer server alarms - external-device : external device related alarms - l2forward : l2forward related alarms - ether-tca : ethernet threshold cross alarms - ether-sfp : ethernet SFP related alarms - megaco-media-gw : megaco media gateway related alarms - megaco-sig-gw : megaco signaling gateway related alarms - megaco-plug-unit : megaco plug unit related alarms - megaco-term : megaco termination related alarms - megaco-sig-lt : megaco signaling lt related alarms - eqpt-supplemental : equipment supplemental alarms - eqpt-holder-ext : other equipment holder alarms - lsmredundancy : lsm redundancy alarms - sync : synce and bits alarms - mcsrc : multicast source alarms - vlanport : vlanport alarms - vect-line : xDSL vectoring line alarms - vect-board : xDSL vectoring board alarms - otdr : otdr alarms - sip-dial-plan : sip dial plan related alarms - sip-vsp : sip vsp related alarms - sip-server : sip server related alarms - bgp : bgp related alarms - rip : rip related alarms - lag : LAG related alarms - ihub-general : IHUB general related alarms - vprn : vprn related alarms - isis : isis related alarms - ospf : ospf related alarms - ihub-l2forward : ihub-l2forward alarms - vpls : vpls related alarms - ihub-equip : ihub-equip related alarms - ihub-link : ihub-link related alarms - eont-phyoam : eont phyoam related alarms - ellid : ellid related alarms - epon : epon related alarms - eont-services-lan : eon phyoam related alarms - eolt-ont-tca : eon phyoam related alarms - eont-sw-dl : eon phyoam related alarms - ldp : ldp related alarms - mpls : mpls related alarms - sdp : sdp related alarms - epipe : epipe related alarms - ihub-ipv6 : ihub-ipv6 related alarms - pim : pim related alarms - li : lawful intercept related alarms - mgmt-sec-access : management security related alarms - bfd : bfd related alarms	

101 query current alarms by filters

name	Type	Description
	- ai : Application Intelligence related alarms - tr069serv : tr069 server related alarms - ontsnmp : ont snmp related alarms - bulk-sync : bulk-sync related alarms - protection-group : port protection group related alarms - ont : ONT general supplemental related alarms - sfu-sup : SFU ONT general supplemental related alarms - soho-sup : SOHO ONT general supplemental related alarms - mdu-sup : MDU ONT general supplemental related alarms - ont-ani : ONT general supplemental 2 related alarms - sfu-sup2 : SFU ONT general supplemental 2 related alarms - soho-sup2 : SOHO ONT general supplemental 2 related alarms - mdu-sup2 : MDU ONT general supplemental 2 related alarms - sfrssi : SFP RSSI related alarms - eoltrssi : epon olt Sfp RSSI related alarms - cfm : Cfm related alarms - sfpe1t1-framer : SFP 2e1t1 framer alarms - sfpe1t1-clock : SFP 2e1t1 clock alarms - pppcc-engine-tca : PPPOE Cross Connect Engine TCA related alarm - eth-cfm : eth-cfm related alarms - rsvp : rsvp related alarms - ihub-tca : IHUB TCA related alarms - eth-ring : eth-ring related alarms - efm-oam : EFM-OAM related alarms - ont-loopdetect : ont loop detect related alarms - ont-video : ont services video related alarms - ont-ces : ont services ces related alarms - ont-voip : ont services voip related alarms - ont-video-ani : ont services video ani related alarms - ont-pwe : ont services pwe related alarms - ont-cese1 : ont services cese1 related alarms - ont-xdsl : ont services xdsl related alarms - ont-xdsl-tca : ont services xdsl tca related alarms - ont-hpna : ont hpna related alarms - ont-sip-agent-cfg : ont services voip sip agent config related alarms - ont-voip-cfg : ont services voip config related alarms - ont-mgc : ont mgc related alarms - ont-ploam : ONT PLOAM related alarms - ont-gen : ONT GENERAL related alarms - ont-card : ONT Subscriber Card related alarms - ont-pots : ONT Services POTS related alarms - ont-lan : ONT Services LAN related alarms - ont-moca : ONT MoCA related alarms - ont-tc-tca : ONT TC TCA related alarms - ont-moca-tca : ONT MoCA TCA related alarms - ont-l2uni-eth-tca : ONT L2 UNI Ethernet TCA related alarms - olt-pon-tc-tca : OLT PON TC TCA related alarms - olt-pon-util-tca : OLT PON utilization TCA related alarms - olt-chpr-util-tca : OLT channel-pair utilization TCA related alarms - olt-ont-tc-tca : OLT ONT TC TCA related alarms	

name	Type	Description
	- ont-tca : ONT TCA related alarms - ont-pots-supplemental : ONT POTS Supplemental related alarms - sfu-ploam : SFU ONT PLOAM related alarms - sfu-gen : SFU ONT general related alarms - soho-ploam : SOHO ONT PLOAM related alarms - soho-gen : SOHO ONT general related alarms - mdu-ploam : MDU ONT PLOAM related alarms - mdu-gen : MDU ONT general related alarms - ont-veip : ONT VEIP related alarms - ont-iphost : ONT IP HOST related alarms - alarm-table : alarm table related alarms - auto-switch : auto-switch related alarms - channel-pair : channel pair related alarms - ont-cfg-dld : ont configure file download related alarms - olt-chpair-tc-tca : OLT CHANNELPAIR TC TCA related alarms - hgu-tr069 : hgu tr069 related alarms - eqpt-psu : equipment psu alarms - ont-protection : ONT protection related alarms - secondary-megaco-term : secondary megaco termination related alarms - secondary-sip-term : secondary sip termination related alarms - cas-r2-channel : CAS R2 channel related alarms - lldpmed : lldpmed alarms - pseudo-wire : pseudo Wire related alarms - link-agg : Link aggregation related alarms - fcs-exceed : FCS auto-recovery related alarms - e1t1-interface : E1/T1 physical interfaces related alarms	
name	Parameter type: <Alarm::almtypeAutoswitch> (auto-switch-status all auswqueuefullatm auswbkpfailatm auswrecfgfailatm auswdataunatm auswqueuefulptm auswbkpfailptm auswrecfgfailptm auswdataunptm auswbakpfailatm) Possible values: - auto-switch-status : auto-switch status - all : show all bgp alarm - auswqueuefullatm : auto-switch queue Full for ATM - auswbkpfailatm : auto-switch config data backup failed for ATM - auswrecfgfailatm : auto-switch fallback reconfiguration failed for ATM - auswdataunatm : auto-switch backup config data unavailable for ATM - auswqueuefulptm : auto-switch queue Full for PTM - auswbkpfailptm : auto-switch config data backup failed for PTM - auswrecfgfailptm : auto-switch fallback reconfiguration failed for PTM	alarm name that are active <i>This element is only shown in detail mode.</i>

101 query current alarms by filters

name	Type	Description
	- auswdataunptm : auto-switch backup config data unavailable for PTM - auswbakpfailatm : auto-switch backup fail for ATM	
severity	Parameter type: <Alarm::AlarmSeverity> (indeterminate warning minor major critical) Possible values: - indeterminate : alarm severity is indeterminate - warning : alarm severity is warning - minor : alarm severity is minor - major : alarm severity is major - critical : alarm severity is critical	the alarms severity level <i>This element is only shown in detail mode.</i>
servaff	Parameter type: <Alarm::alarmServAffect> ((service-affecting yes) (noservice-affecting no)) Possible values: - service-affecting : make this alarm service affecting - yes : make this alarm service affecting - noservice-affecting : make this alarm not service affecting - no : make this alarm not service affecting	alarms affect service or not <i>This element is only shown in detail mode.</i>
time	Parameter type: <Sys::timeInSecs> - the time (yyyy-mm-dd:hour:minutes:secs) - unit: UTC	time in seconds when alarm was updated <i>This element is only shown in detail mode.</i>
descript	Parameter type: <Alarm::AddInfoString> - additional alarm information	alarm description <i>This element is only shown in detail mode.</i>

101.16 show current alarm by filters

Command Description

show current alarms by filters

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm query atm [ (name) [ severity <Alarm::querySeverity> ] [ servaff <Alarm::queryServAffect> ] [ port
<Equipm::AtmIndex> ] ]
```

Command Parameters

Table 101.16-1 "show current alarm by filters" Resource Parameters

Resource Identifier	Type	Description
(name)	Format: (cell-discard-up cell-discard-down all) Possible values: - cell-discard-up : cell discarded in the upstream direction - cell-discard-down : cell discarded in the downstream direction - all : show all ATM alarm	alarm name of atm
severity	Parameter type: <Alarm::querySeverity> Format: (indeterminate warning minor major critical all) Possible values: - indeterminate : alarm severity is indeterminate - warning : alarm severity is warning - minor : alarm severity is minor - major : alarm severity is major - critical : alarm severity is critical - all : all alarm severity	severity level of an alarm for reporting
servaff	Parameter type: <Alarm::queryServAffect> Format: (service-affecting noservice-affecting	serviceaffecting no

101 query current alarms by filters

Resource Identifier	Type	Description
	all) Possible values: - service-affecting : query alarm service affecting - noservice-affecting : query alarm not service affecting - all : query service affecting and not affecting alarms	
port	Parameter type: <Equipm::AtmIndex> Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number	the physical number of the port

Command Output

Table 101.16-2 "show current alarm by filters" Display parameters

Specific Information		
name	Type	Description
aidinfo	Parameter type: <Alarm::AddInfoString> - additional alarm information	alarm AID parameters <i>This element is only shown in detail mode.</i>
type	Parameter type: <Alarm::alarmIHUBType> (equipment eqpt-holder plug-in-unit atm custom e1 ima-group ima-link redundancy shdsl ether-itf traffic-overflow qos-queue temporal spatial (software-mngt sw-mgmt) xdsl xdsl-ext xdsl-tca olt-gen eo-conv authentication bonding sfp shdsl-isam custom-ext-alarm plug-in-unit-ext sip-user-agent sip-plugin-unit	type of the alarms that are active <i>This element is only shown in detail mode.</i>

name	Type	Description
	sip-termination e1-sip-termination filetransfer external-device l2forward ether-tca ether-sfp megaco-media-gw megaco-sig-gw megaco-plug-unit megaco-term megaco-sig-lt eqpt-supplemental eqpt-holder-ext lsmredundancy sync mcsrc vlanport vect-line vect-board otdr sip-dial-plan sip-vsp sip-server bgp rip lag ihub-general vprn isis ospf ihub-l2forward vpls ihub-equip ihub-link eont-phyoam ellid epon eont-services-lan eolt-ont-tca eont-sw-dl ldp mpls sdp epipe ihub-ipv6 pim li mgmt-sec-access bfd ai tr069serv ontsnmp bulk-sync protection-group ont sfu-sup	

101 query current alarms by filters

name	Type	Description
	soho-sup	
	mdu-sup	
	ont-ani	
	sfu-sup2	
	soho-sup2	
	mdu-sup2	
	sfprssi	
	eoltrssi	
	cfm	
	sfpe1t1-framer	
	sfpe1t1-clock	
	pppcc-engine-tca	
	eth-cfm	
	rsvp	
	ihub-tca	
	eth-ring	
	efm-oam	
	ont-loopdetect	
	ont-video	
	ont-ces	
	ont-voip	
	ont-video-ani	
	ont-pwe	
	ont-cese1	
	ont-xdsl	
	ont-xdsl-tca	
	ont-hpna	
	ont-sip-agent-cfg	
	ont-voip-cfg	
	ont-mgc	
	ont-ploam	
	ont-gen	
	ont-card	
	ont-pots	
	ont-lan	
	ont-moca	
	ont-tc-tca	
	ont-moca-tca	
	ont-l2uni-eth-tca	
	olt-pon-tc-tca	
	olt-pon-util-tca	
	olt-chpr-util-tca	
	olt-ont-tc-tca	
	ont-tca	
	ont-pots-supplemental	
	sfu-ploam	
	sfu-gen	
	soho-ploam	
	soho-gen	
	mdu-ploam	
	mdu-gen	
	ont-veip	
	ont-iphost	
	alarm-table	
	auto-switch	
	channel-pair	
	ont-cfg-dld	

name	Type	Description
	olt-chpair-tc-tca hgu-tr069 eqpt-psu ont-protection secondary-megaco-term secondary-sip-term cas-r2-channel lldpmed pseudo-wire link-agg fcs-exceed e1t1-interface) Possible values: - equipment : equipment alarms - eqpt-holder : equipment holder alarms - plug-in-unit : plugin unit alarms - atm : ATM alarms - custom : customizable alarms - e1 : e1 alarms - ima-group : ima-group alarms - ima-link : ima-link alarms - redundancy : redundancy alarms - shdsl : shdsl alarms - ether-itf : ethernet interface alarms - traffic-overflow : Traffic overflow alarms - qos-queue : qos queue alarms - temporal : temporal alarms - spatial : spatial alarms - software-mngt : software management alarms - sw-mgmt : software management alarms - xdsl : xDSL alarms - xdsl-ext : other xDSL alarms - xdsl-tca : xDSL threshold cross alarms - olt-gen : OLT general alarms - eo-conv : E/O conversion related alarms - authentication : authentication related alarms - bonding : bonding-group related alarms - sfp : SFP related alarms - shdsl-isam : shdsl isam alarms - custom-ext-alarm : customizable external alarms - plug-in-unit-ext : other plugin unit alarms - sip-user-agent : sip user agent related alarms - sip-plugin-unit : sip plug in unit related alarms - sip-termination : sip termination related alarms - e1-sip-termination : E1 sip termination related alarms - filetransfer : file transfer server alarms - external-device : external device related alarms - l2forward : l2forward related alarms - ether-tca : ethernet threshold cross alarms - ether-sfp : ethernet SFP related alarms - megaco-media-gw : megaco media gateway related alarms - megaco-sig-gw : megaco signaling gateway related alarms - megaco-plug-unit : megaco plug unit related alarms - megaco-term : megaco termination related alarms - megaco-sig-lt : megaco signaling lt related alarms - eqpt-supplemental : equipment supplemental alarms - eqpt-holder-ext : other equipment holder alarms	

101 query current alarms by filters

name	Type	Description
	- lsmredundancy : lsm redundancy alarms - sync : synce and bits alarms - mcsrc : multicast source alarms - vlanport : vlanport alarms - vect-line : xDSL vectoring line alarms - vect-board : xDSL vectoring board alarms - otdr : otdr alarms - sip-dial-plan : sip dial plan related alarms - sip-vsp : sip vsp related alarms - sip-server : sip server related alarms - bgp : bgp related alarms - rip : rip related alarms - lag : LAG related alarms - ihub-general : IHUB general related alarms - vprn : vprn related alarms - isis : isis related alarms - ospf : ospf related alarms - ihub-l2forward : ihub-l2forward alarms - vpls : vpls related alarms - ihub-equip : ihub-equip related alarms - ihub-link : ihub-link related alarms - eont-phyoam : eont phyoam related alarms - ellid : ellid related alarms - epon : epon related alarms - eont-services-lan : eon phyoam related alarms - eolt-ont-tca : eon phyoam related alarms - eont-sw-dl : eon phyoam related alarms - ldp : ldp related alarms - mpls : mpls related alarms - sdp : sdp related alarms - epipe : epipe related alarms - ihub-ipv6 : ihub-ipv6 related alarms - pim : pim related alarms - li : lawful intercept related alarms - mgmt-sec-access : management security related alarms - bfd : bfd related alarms - ai : Application Intelligence related alarms - tr069serv : tr069 server related alarms - ontsnmp : ont snmp related alarms - bulk-sync : bulk-sync related alarms - protection-group : port protection group related alarms - ont : ONT general supplemental related alarms - sfu-sup : SFU ONT general supplemental related alarms - soho-sup : SOHO ONT general supplemental related alarms - mdu-sup : MDU ONT general supplemental related alarms - ont-ani : ONT general supplemental 2 related alarms - sfu-sup2 : SFU ONT general supplemental 2 related alarms - soho-sup2 : SOHO ONT general supplemental 2 related alarms - mdu-sup2 : MDU ONT general supplemental 2 related alarms - sfprssi : SFP RSSI related alarms - eoltrssi : epon olt Sfp RSSI related alarms - cfm : Cfm related alarms - sfpe1t1-framer : SFP 2e1t1 framer alarms - sfpe1t1-clock : SFP 2e1t1 clock alarms	

name	Type	Description
	- pppcc-engine-tca : PPPOE Cross Connect Engine TCA related alarm - eth-cfm : eth-cfm related alarms - rsvp : rsvp related alarms - ihub-tca : IHUB TCA related alarms - eth-ring : eth-ring related alarms - efm-oam : EFM-OAM related alarms - ont-loopdetect : ont loop detect related alarms - ont-video : ont services video related alarms - ont-ces : ont services ces related alarms - ont-voip : ont services voip related alarms - ont-video-ani : ont services video ani related alarms - ont-pwe : ont services pwe related alarms - ont-cese1 : ont services cese1 related alarms - ont-xdsl : ont services xdsl related alarms - ont-xdsl-tca : ont services xdsl tca related alarms - ont-hpna : ont hpna related alarms - ont-sip-agent-cfg : ont services voip sip agent config related alarms - ont-voip-cfg : ont services voip config related alarms - ont-mgc : ont mgc related alarms - ont-ploam : ONT PLOAM related alarms - ont-gen : ONT GENERAL related alarms - ont-card : ONT Subscriber Card related alarms - ont-pots : ONT Services POTS related alarms - ont-lan : ONT Services LAN related alarms - ont-moca : ONT MoCA related alarms - ont-tc-tca : ONT TC TCA related alarms - ont-moca-tca : ONT MoCA TCA related alarms - ont-l2uni-eth-tca : ONT L2 UNI Ethernet TCA related alarms - olt-pon-tc-tca : OLT PON TC TCA related alarms - olt-pon-util-tca : OLT PON utilization TCA related alarms - olt-chpr-util-tca : OLT channel-pair utilization TCA related alarms - olt-ont-tc-tca : OLT ONT TC TCA related alarms - ont-tca : ONT TCA related alarms - ont-pots-supplemental : ONT POTS Supplemental related alarms - sfu-ploam : SFU ONT PLOAM related alarms - sfu-gen : SFU ONT general related alarms - soho-ploam : SOHO ONT PLOAM related alarms - soho-gen : SOHO ONT general related alarms - mdu-ploam : MDU ONT PLOAM related alarms - mdu-gen : MDU ONT general related alarms - ont-veip : ONT VEIP related alarms - ont-iphost : ONT IP HOST related alarms - alarm-table : alarm table related alarms - auto-switch : auto-switch related alarms - channel-pair : channel pair related alarms - ont-cfg-dld : ont configure file download related alarms - olt-chpair-tc-tca : OLT CHANNELPAIR TC TCA related alarms - hgu-tr069 : hgu tr069 related alarms - eqpt-psu : equipment psu alarms - ont-protection : ONT protection related alarms - secondary-megaco-term : secondary megaco termination	

101 query current alarms by filters

name	Type	Description
	related alarms - secondary-sip-term : secondary sip termination related alarms - cas-r2-channel : CAS R2 channel related alarms - lldpmed : lldpmed alarms - pseudo-wire : pseudo Wire related alarms - link-agg : Link aggregation related alarms - fcs-exceed : FCS auto-recovery related alarms - e1t1-interface : E1/T1 physical interfaces related alarms	
name	Parameter type: <Alarm::almtypeAtm> (cell-discard-up cell-discard-down all) Possible values: - cell-discard-up : cell discarded in the upstream direction - cell-discard-down : cell discarded in the downstream direction - all : show all ATM alarm	alarm name that are active <i>This element is only shown in detail mode.</i>
severity	Parameter type: <Alarm::AlarmSeverity> (indeterminate warning minor major critical) Possible values: - indeterminate : alarm severity is indeterminate - warning : alarm severity is warning - minor : alarm severity is minor - major : alarm severity is major - critical : alarm severity is critical	the alarms severity level <i>This element is only shown in detail mode.</i>
servaff	Parameter type: <Alarm::alarmServAffect> ((service-affecting yes) (noservice-affecting no)) Possible values: - service-affecting : make this alarm service affecting - yes : make this alarm service affecting - noservice-affecting : make this alarm not service affecting - no : make this alarm not service affecting	alarms affect service or not <i>This element is only shown in detail mode.</i>
location	Parameter type: <Alarm::almLocation> (near-end far-end middle-end line null) Possible values: - near-end : alarm location is near - far-end : alarm location is far - middle-end : alarm location is middle - line : alarm location is line - null : alarm location not defined	alarm location: near, middle, far <i>This element is only shown in detail mode.</i>
time	Parameter type: <Sys::timeInSecs> - the time (yyyy-mm-dd:hour:minutes:secs) - unit: UTC	time in seconds when alarm was updated <i>This element is only shown in detail mode.</i>
direction	Parameter type: <Alarm::almDirection> (received transmit	alarm direction: received or transmit <i>This element is only shown in</i>

name	Type	Description
	null) Possible values: - received : alarm is received - transmit : alarm is transmit - null : direction not defined	<i>detail mode.</i>
descript	Parameter type: <Alarm::AddInfoString> - additional alarm information	alarm description <i>This element is only shown in detail mode.</i>

101.17 show current alarm by filters

Command Description

show current alarms by filters

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm query ether-itf [ (name) [ severity <Alarm::querySeverity> ] [ servaff <Alarm::queryServAffect> ] [ ether-ifindex <Ether::InterfaceIndex> ] ]
```

Command Parameters

Table 101.17-1 "show current alarm by filters" Resource Parameters

Resource Identifier	Type	Description
(name)	Format: all Possible values: - all : show all ethernet interface alarm	alarm name of ether-itf
severity	Parameter type: <Alarm::querySeverity> Format: (indeterminate warning minor major critical all) Possible values: - indeterminate : alarm severity is indeterminate - warning : alarm severity is warning - minor : alarm severity is minor - major : alarm severity is major - critical : alarm severity is critical - all : all alarm severity	severity level of an alarm for reporting
servaff	Parameter type: <Alarm::queryServAffect> Format: (service-affecting noservice-affecting all) Possible values: - service-affecting : query alarm service affecting - noservice-affecting : query alarm not service affecting - all : query service affecting and not affecting alarms	serviceaffecting no

Resource Identifier	Type	Description
ether-ifindex	Parameter type: <Ether::InterfaceIndex> Format: - index of the collision interface - range: [0...2147483647]	the number of ethernet interface

Command Output

Table 101.17-2 "show current alarm by filters" Display parameters

Specific Information		
name	Type	Description
aidinfo	Parameter type: <Alarm::AddInfoString> - additional alarm information	alarm AID parameters <i>This element is only shown in detail mode.</i>
type	Parameter type: <Alarm::alarmIHUBType> (equipment eqpt-holder plug-in-unit atm custom e1 ima-group ima-link redundancy shdsl ether-itf traffic-overflow qos-queue temporal spatial (software-mngt sw-mgmt) xdsl xdsl-ext xdsl-tca olt-gen eo-conv authentication bonding sfp shdsl-isam custom-ext-alarm plug-in-unit-ext sip-user-agent sip-plugin-unit sip-termination e1-sip-termination filetransfer external-device l2forward ether-tca ether-sfp megaco-media-gw megaco-sig-gw megaco-plugin-unit megaco-term megaco-sig-lt eqpt-supplemental	type of the alarms that are active <i>This element is only shown in detail mode.</i>

101 query current alarms by filters

name	Type	Description
	eqpt-holder-ext	
	lsmredundancy	
	sync	
	mcsrc	
	vlanport	
	vect-line	
	vect-board	
	otdr	
	sip-dial-plan	
	sip-vsp	
	sip-server	
	bgp	
	rip	
	lag	
	ihub-general	
	vprn	
	isis	
	ospf	
	ihub-l2forward	
	vpls	
	ihub-equip	
	ihub-link	
	eont-phyoam	
	ellid	
	epon	
	eont-services-lan	
	eolt-ont-tca	
	eont-sw-dl	
	ldp	
	mpls	
	sdp	
	epipe	
	ihub-ipv6	
	pim	
	li	
	mgmt-sec-access	
	bfd	
	ai	
	tr069serv	
	ontsnmp	
	bulk-sync	
	protection-group	
	ont	
	sfu-sup	
	soho-sup	
	mdu-sup	
	ont-ani	
	sfu-sup2	
	soho-sup2	
	mdu-sup2	
	sfprssi	
	eoltrssi	
	cfm	
	sfpe1t1-framer	
	sfpe1t1-clock	
	pppcc-engine-tca	
	eth-cfm	

name	Type	Description
	rsvp ihub-tca eth-ring efm-oam ont-loopdetect ont-video ont-ces ont-voip ont-video-ani ont-pwe ont-cese1 ont-xdsl ont-xdsl-tca ont-hpna ont-sip-agent-cfg ont-voip-cfg ont-mgc ont-ploam ont-gen ont-card ont-pots ont-lan ont-moca ont-tc-tca ont-moca-tca ont-l2uni-eth-tca olt-pon-tc-tca olt-pon-util-tca olt-chpr-util-tca olt-ont-tc-tca ont-tca ont-pots-supplemental sfu-ploam sfu-gen soho-ploam soho-gen mdu-ploam mdu-gen ont-veip ont-iphost alarm-table auto-switch channel-pair ont-cfg-dld olt-chpair-tc-tca hgu-tr069 eqpt-psu ont-protection secondary-megaco-term secondary-sip-term cas-r2-channel lldpmed pseudo-wire link-agg fcs-exceed elt1-interface) Possible values:	

101 query current alarms by filters

name	Type	Description
	- equipment : equipment alarms - eqpt-holder : equipment holder alarms - plug-in-unit : plugin unit alarms - atm : ATM alarms - custom : customizable alarms - e1 : e1 alarms - ima-group : ima-group alarms - ima-link : ima-link alarms - redundancy : redundancy alarms - shdsl : shdsl alarms - ether-itf : ethernet interface alarms - traffic-overflow : Traffic overflow alarms - qos-queue : qos queue alarms - temporal : temporal alarms - spatial : spatial alarms - software-mngt : software management alarms - sw-mgmt : software management alarms - xdsl : xDSL alarms - xdsl-ext : other xDSL alarms - xdsl-tca : xDSL threshold cross alarms - olt-gen : OLT general alarms - eo-conv : E/O conversion related alarms - authentication : authentication related alarms - bonding : bonding-group related alarms - sfp : SFP related alarms - shdsl-isam : shdsl isam alarms - custom-ext-alarm : customizable external alarms - plug-in-unit-ext : other plugin unit alarms - sip-user-agent : sip user agent related alarms - sip-plugin-unit : sip plug in unit related alarms - sip-termination : sip termination related alarms - e1-sip-termination : E1 sip termination related alarms - filetransfer : file transfer server alarms - external-device : external device related alarms - l2forward : l2forward related alarms - ether-tca : ethernet threshold cross alarms - ether-sfp : ethernet SFP related alarms - megaco-media-gw : megaco media gateway related alarms - megaco-sig-gw : megaco signaling gateway related alarms - megaco-plug-unit : megaco plug unit related alarms - megaco-term : megaco termination related alarms - megaco-sig-lt : megaco signaling lt related alarms - eqpt-supplemental : equipment supplemental alarms - eqpt-holder-ext : other equipment holder alarms - lsmredundancy : lsm redundancy alarms - sync : synce and bits alarms - mcsrc : multicast source alarms - vlanport : vlanport alarms - vect-line : xDSL vectoring line alarms - vect-board : xDSL vectoring board alarms - otdr : otdr alarms - sip-dial-plan : sip dial plan related alarms - sip-vsp : sip vsp related alarms - sip-server : sip server related alarms - bgp : bgp related alarms - rip : rip related alarms - lag : LAG related alarms	

name	Type	Description
	- ihub-general : IHUB general related alarms - vprn : vprn related alarms - isis : isis related alarms - ospf : ospf related alarms - ihub-l2forward : ihub-l2forward alarms - vpls : vpls related alarms - ihub-equip : ihub-equip related alarms - ihub-link : ihub-link related alarms - eont-phyoam : eont phyoam related alarms - ellid : ellid related alarms - epon : epon related alarms - eont-services-lan : eon phyoam related alarms - eolt-ont-tca : eon phyoam related alarms - eont-sw-dl : eon phyoam related alarms - ldp : ldp related alarms - mpls : mpls related alarms - sdp : sdp related alarms - epipe : epipe related alarms - ihub-ipv6 : ihub-ipv6 related alarms - pim : pim related alarms - li : lawful intercept related alarms - mgmt-sec-access : management security related alarms - bfd : bfd related alarms - ai : Application Intelligence related alarms - tr069serv : tr069 server related alarms - ontsnmp : ont snmp related alarms - bulk-sync : bulk-sync related alarms - protection-group : port protection group related alarms - ont : ONT general supplemental related alarms - sfu-sup : SFU ONT general supplemental related alarms - soho-sup : SOHO ONT general supplemental related alarms - mdu-sup : MDU ONT general supplemental related alarms - ont-ani : ONT general supplemental 2 related alarms - sfu-sup2 : SFU ONT general supplemental 2 related alarms - soho-sup2 : SOHO ONT general supplemental 2 related alarms - mdu-sup2 : MDU ONT general supplemental 2 related alarms - sfprssi : SFP RSSI related alarms - eoltrssi : epon olt Sfp RSSI related alarms - cfm : Cfm related alarms - sfpe1t1-framer : SFP 2e1t1 framer alarms - sfpe1t1-clock : SFP 2e1t1 clock alarms - pppcc-engine-tca : PPPOE Cross Connect Engine TCA related alarm - eth-cfm : eth-cfm related alarms - rsvp : rsvp related alarms - ihub-tca : IHUB TCA related alarms - eth-ring : eth-ring related alarms - efm-oam : EFM-OAM related alarms - ont-loopdetect : ont loop detect related alarms - ont-video : ont services video related alarms - ont-ces : ont services ces related alarms - ont-voip : ont services voip related alarms - ont-video-ani : ont services video ani related alarms - ont-pwe : ont services pwe related alarms	

101 query current alarms by filters

name	Type	Description
	- ont-cese1 : ont services cese1 related alarms - ont-xdsl : ont services xdsl related alarms - ont-xdsl-tca : ont services xdsl tca related alarms - ont-hpna : ont hpna related alarms - ont-sip-agent-cfg : ont services voip sip agent config related alarms - ont-voip-cfg : ont services voip config related alarms - ont-mgc : ont mgc related alarms - ont-ploam : ONT PLOAM related alarms - ont-gen : ONT GENERAL related alarms - ont-card : ONT Subscriber Card related alarms - ont-pots : ONT Services POTS related alarms - ont-lan : ONT Services LAN related alarms - ont-moca : ONT MoCA related alarms - ont-tc-tca : ONT TC TCA related alarms - ont-moca-tca : ONT MoCA TCA related alarms - ont-l2uni-eth-tca : ONT L2 UNI Ethernet TCA related alarms - olt-pon-tc-tca : OLT PON TC TCA related alarms - olt-pon-util-tca : OLT PON utilization TCA related alarms - olt-chpr-util-tca : OLT channel-pair utilization TCA related alarms - olt-ont-tc-tca : OLT ONT TC TCA related alarms - ont-tca : ONT TCA related alarms - ont-pots-supplemental : ONT POTS Supplemental related alarms - sfu-ploam : SFU ONT PLOAM related alarms - sfu-gen : SFU ONT general related alarms - soho-ploam : SOHO ONT PLOAM related alarms - soho-gen : SOHO ONT general related alarms - mdu-ploam : MDU ONT PLOAM related alarms - mdu-gen : MDU ONT general related alarms - ont-veip : ONT VEIP related alarms - ont-iphost : ONT IP HOST related alarms - alarm-table : alarm table related alarms - auto-switch : auto-switch related alarms - channel-pair : channel pair related alarms - ont-cfg-dld : ont configure file download related alarms - olt-chpair-tc-tca : OLT CHANNELPAIR TC TCA related alarms - hgu-tr069 : hgu tr069 related alarms - eqpt-psu : equipment psu alarms - ont-protection : ONT protection related alarms - secondary-megaco-term : secondary megaco termination related alarms - secondary-sip-term : secondary sip termination related alarms - cas-r2-channel : CAS R2 channel related alarms - lldpmed : lldpmed alarms - pseudo-wire : pseudo Wire related alarms - link-agg : Link aggregation related alarms - fcs-exceed : FCS auto-recovery related alarms - e1t1-interface : E1/T1 physical interfaces related alarms	
name	Parameter type: <Alarm::alarmTypeEtherIf> all Possible values: - all : show all ethernet interface alarm	alarm name that are active <i>This element is only shown in detail mode.</i>

name	Type	Description
severity	Parameter type: <Alarm::AlarmSeverity> (indeterminate warning minor major critical) Possible values: - indeterminate : alarm severity is indeterminate - warning : alarm severity is warning - minor : alarm severity is minor - major : alarm severity is major - critical : alarm severity is critical	the alarms severity level <i>This element is only shown in detail mode.</i>
servaff	Parameter type: <Alarm::alarmServAffect> ((service-affecting yes) (noservice-affecting no)) Possible values: - service-affecting : make this alarm service affecting - yes : make this alarm service affecting - noservice-affecting : make this alarm not service affecting - no : make this alarm not service affecting	alarms affect service or not <i>This element is only shown in detail mode.</i>
time	Parameter type: <Sys::timeInSecs> - the time (yyyy-mm-dd:hour:minutes:secs) - unit: UTC	time in seconds when alarm was updated <i>This element is only shown in detail mode.</i>
descript	Parameter type: <Alarm::AddInfoString> - additional alarm information	alarm description <i>This element is only shown in detail mode.</i>

101.18 show current alarm by filters

Command Description

show current alarms by filters

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm query authentication [ (name) [ severity <Alarm::querySeverity> ] [ servaff  
<Alarm::queryServAffect> ] [ defaultaid <Alarm::queryDefaultAid> ] ]
```

Command Parameters

Table 101.18-1 "show current alarm by filters" Resource Parameters

Resource Identifier	Type	Description
(name)	Format: (vlan-assign-fail vsa-info-invalid auth-mac-conflict user-pwd-fault all) Possible values: - vlan-assign-fail : failure to assign VLAN for a user session - vsa-info-invalid : radius fail to assign a valid vsa to a user session - auth-mac-conflict : failure to check mac conflict for a user session - user-pwd-fault : failure to check user or password of a user session - all : show all authentication alarm	alarm name of authentication
severity	Parameter type: <Alarm::querySeverity> Format: (indeterminate warning minor major critical all) Possible values: - indeterminate : alarm severity is indeterminate - warning : alarm severity is warning - minor : alarm severity is minor - major : alarm severity is major	severity level of an alarm for reporting

Resource Identifier	Type	Description
	- critical : alarm severity is critical - all : all alarm severity	
servaff	Parameter type: <Alarm::queryServAffect> Format: (service-affecting noservice-affecting all) Possible values: - service-affecting : query alarm service affecting - noservice-affecting : query alarm not service affecting - all : query service affecting and not affecting alarms	serviceaffecting no serviceaffecting
defaultaid	Parameter type: <Alarm::queryDefaultAid> Format: all Possible values: - all : default AID parameter	default AID param is all

Command Output

Table 101.18-2 "show current alarm by filters" Display parameters

Specific Information		
name	Type	Description
aidinfo	Parameter type: <Alarm::AddInfoString> - additional alarm information	alarm AID parameters <i>This element is only shown in detail mode.</i>
type	Parameter type: <Alarm::alarmIHUBType> (equipment eqpt-holder plug-in-unit atm custom e1 ima-group ima-link redundancy shdsl ether-itf traffic-overflow qos-queue temporal spatial (software-mngt sw-mgmt) xdsl xdsl-ext xdsl-tca olt-gen eo-conv authentication bonding sfp shdsl-isam custom-ext-alarm plug-in-unit-ext sip-user-agent sip-plugin-unit sip-termination	type of the alarms that are active <i>This element is only shown in detail mode.</i>

101 query current alarms by filters

name	Type	Description
	e1-sip-termination filetransfer external-device l2forward ether-tca ether-sfp megaco-media-gw megaco-sig-gw megaco-plug-unit megaco-term megaco-sig-lt eqpt-supplemental eqpt-holder-ext lsmredundancy sync mcsrc vlanport vect-line vect-board otdr sip-dial-plan sip-vsp sip-server bgp rip lag ihub-general vprn isis ospf ihub-l2forward vpls ihub-equip ihub-link eont-phyoam ellid epon eont-services-lan eolt-ont-tca eont-sw-dl ldp mpls sdp epipe ihub-ipv6 pim li mgmt-sec-access bfd ai tr069serv ontsnmp bulk-sync protection-group ont sfu-sup soho-sup	

name	Type	Description
	mdu-sup ont-ani sfu-sup2 soho-sup2 mdu-sup2 sfprssi eoltrssi cfm sfpe1t1-framer sfpe1t1-clock pppcc-engine-tca eth-cfm rsvp ihub-tca eth-ring efm-oam ont-loopdetect ont-video ont-ces ont-voip ont-video-ani ont-pwe ont-cese1 ont-xdsl ont-xdsl-tca ont-hpna ont-sip-agent-cfg ont-voip-cfg ont-mgc ont-ploam ont-gen ont-card ont-pots ont-lan ont-moca ont-tc-tca ont-moca-tca ont-l2uni-eth-tca olt-pon-tc-tca olt-pon-util-tca olt-chpr-util-tca olt-ont-tc-tca ont-tca ont-pots-supplemental sfu-ploam sfu-gen soho-ploam soho-gen mdu-ploam mdu-gen ont-veip ont-iphost alarm-table auto-switch channel-pair ont-cfg-dld olt-chpair-tc-tca	

101 query current alarms by filters

name	Type	Description
	hgu-tr069 eqpt-psu ont-protection secondary-megaco-term secondary-sip-term cas-r2-channel lldpmed pseudo-wire link-agg fcs-exceed e1t1-interface) Possible values: - equipment : equipment alarms - eqpt-holder : equipment holder alarms - plug-in-unit : plugin unit alarms - atm : ATM alarms - custom : customizable alarms - e1 : e1 alarms - ima-group : ima-group alarms - ima-link : ima-link alarms - redundancy : redundancy alarms - shdsl : shdsl alarms - ether-itf : ethernet interface alarms - traffic-overflow : Traffic overflow alarms - qos-queue : qos queue alarms - temporal : temporal alarms - spatial : spatial alarms - software-mngt : software management alarms - sw-mgmt : software management alarms - xdsl : xDSL alarms - xdsl-ext : other xDSL alarms - xdsl-tca : xDSL threshold cross alarms - olt-gen : OLT general alarms - eo-conv : E/O conversion related alarms - authentication : authentication related alarms - bonding : bonding-group related alarms - sfp : SFP related alarms - shdsl-isam : shdsl isam alarms - custom-ext-alarm : customizable external alarms - plug-in-unit-ext : other plugin unit alarms - sip-user-agent : sip user agent related alarms - sip-plugin-unit : sip plug in unit related alarms - sip-termination : sip termination related alarms - e1-sip-termination : E1 sip termination related alarms - filetransfer : file transfer server alarms - external-device : external device related alarms - l2forward : l2forward related alarms - ether-tca : ethernet threshold cross alarms - ether-sfp : ethernet SFP related alarms - megaco-media-gw : megaco media gateway related alarms - megaco-sig-gw : megaco signaling gateway related alarms - megaco-plug-unit : megaco plug unit related alarms - megaco-term : megaco termination related alarms - megaco-sig-lt : megaco signaling lt related alarms - eqpt-supplemental : equipment supplemental alarms - eqpt-holder-ext : other equipment holder alarms - lsmredundancy : lsm redundancy alarms	

name	Type	Description
	- sync : synce and bits alarms - mcsrc : multicast source alarms - vlanport : vlanport alarms - vect-line : xDSL vectoring line alarms - vect-board : xDSL vectoring board alarms - otdr : otdr alarms - sip-dial-plan : sip dial plan related alarms - sip-vsp : sip vsp related alarms - sip-server : sip server related alarms - bgp : bgp related alarms - rip : rip related alarms - lag : LAG related alarms - ihub-general : IHUB general related alarms - vprn : vprn related alarms - isis : isis related alarms - ospf : ospf related alarms - ihub-l2forward : ihub-l2forward alarms - vpls : vpls related alarms - ihub-equip : ihub-equip related alarms - ihub-link : ihub-link related alarms - eont-phyoam : eont phyoam related alarms - ellid : ellid related alarms - epon : epon related alarms - eont-services-lan : eon phyoam related alarms - eolt-ont-tca : eon phyoam related alarms - eont-sw-dl : eon phyoam related alarms - ldp : ldp related alarms - mpls : mpls related alarms - sdp : sdp related alarms - epipe : epipe related alarms - ihub-ipv6 : ihub-ipv6 related alarms - pim : pim related alarms - li : lawful intercept related alarms - mgmt-sec-access : management security related alarms - bfd : bfd related alarms - ai : Application Intelligence related alarms - tr069serv : tr069 server related alarms - ontsnmp : ont snmp related alarms - bulk-sync : bulk-sync related alarms - protection-group : port protection group related alarms - ont : ONT general supplemental related alarms - sfu-sup : SFU ONT general supplemental related alarms - soho-sup : SOHO ONT general supplemental related alarms - mdv-sup : MDU ONT general supplemental related alarms - ont-ani : ONT general supplemental 2 related alarms - sfu-sup2 : SFU ONT general supplemental 2 related alarms - soho-sup2 : SOHO ONT general supplemental 2 related alarms - mdv-sup2 : MDU ONT general supplemental 2 related alarms - sfprssi : SFP RSSI related alarms - eoltrssi : epon olt Sfp RSSI related alarms - cfm : Cfm related alarms - sfpe1t1-framer : SFP 2e1t1 framer alarms - sfpe1t1-clock : SFP 2e1t1 clock alarms - pppcc-engine-tca : PPPOE Cross Connect Engine TCA	

101 query current alarms by filters

name	Type	Description
	related alarm - eth-cfm : eth-cfm related alarms - rsvp : rsvp related alarms - ihub-tca : IHUB TCA related alarms - eth-ring : eth-ring related alarms - efm-oam : EFM-OAM related alarms - ont-loopdetect : ont loop detect related alarms - ont-video : ont services video related alarms - ont-ces : ont services ces related alarms - ont-voip : ont services voip related alarms - ont-video-ani : ont services video ani related alarms - ont-pwe : ont services pwe related alarms - ont-cese1 : ont services cese1 related alarms - ont-xdsl : ont services xdsl related alarms - ont-xdsl-tca : ont services xdsl tca related alarms - ont-hpna : ont hpna related alarms - ont-sip-agent-cfg : ont services voip sip agent config related alarms - ont-voip-cfg : ont services voip config related alarms - ont-mgc : ont mgc related alarms - ont-ploam : ONT PLOAM related alarms - ont-gen : ONT GENERAL related alarms - ont-card : ONT Subscriber Card related alarms - ont-pots : ONT Services POTS related alarms - ont-lan : ONT Services LAN related alarms - ont-moca : ONT MoCA related alarms - ont-tc-tca : ONT TC TCA related alarms - ont-moca-tca : ONT MoCA TCA related alarms - ont-l2uni-eth-tca : ONT L2 UNI Ethernet TCA related alarms - olt-pon-tc-tca : OLT PON TC TCA related alarms - olt-pon-util-tca : OLT PON utilization TCA related alarms - olt-chpr-util-tca : OLT channel-pair utilization TCA related alarms - olt-ont-tc-tca : OLT ONT TC TCA related alarms - ont-tca : ONT TCA related alarms - ont-pots-supplemental : ONT POTS Supplemental related alarms - sfu-ploam : SFU ONT PLOAM related alarms - sfu-gen : SFU ONT general related alarms - soho-ploam : SOHO ONT PLOAM related alarms - soho-gen : SOHO ONT general related alarms - mdu-ploam : MDU ONT PLOAM related alarms - mdu-gen : MDU ONT general related alarms - ont-veip : ONT VEIP related alarms - ont-iphost : ONT IP HOST related alarms - alarm-table : alarm table related alarms - auto-switch : auto-switch related alarms - channel-pair : channel pair related alarms - ont-cfg-dld : ont configure file download related alarms - olt-chpair-tc-tca : OLT CHANNELPAIR TC TCA related alarms - hgu-tr069 : hgu tr069 related alarms - eqpt-psu : equipment psu alarms - ont-protection : ONT protection related alarms - secondary-megaco-term : secondary megaco termination related alarms	

name	Type	Description
	- secondary-sip-term : secondary sip termination related alarms - cas-r2-channel : CAS R2 channel related alarms - lldpmed : lldpmed alarms - pseudo-wire : pseudo Wire related alarms - link-agg : Link aggregation related alarms - fcs-exceed : FCS auto-recovery related alarms - e1t1-interface : E1/T1 physical interfaces related alarms	
name	Parameter type: <Alarm::almtypeAuthentication> (vlan-assign-fail vsa-info-invalid auth-mac-conflict user-pwd-fault all) Possible values: - vlan-assign-fail : failure to assign VLAN for a user session - vsa-info-invalid : radius fail to assign a valid vsa to a user session - auth-mac-conflict : failure to check mac conflict for a user session - user-pwd-fault : failure to check user or password of a user session - all : show all authentication alarm	alarm name that are active <i>This element is only shown in detail mode.</i>
severity	Parameter type: <Alarm::AlarmSeverity> (indeterminate warning minor major critical) Possible values: - indeterminate : alarm severity is indeterminate - warning : alarm severity is warning - minor : alarm severity is minor - major : alarm severity is major - critical : alarm severity is critical	the alarms severity level <i>This element is only shown in detail mode.</i>
servaff	Parameter type: <Alarm::alarmServAffect> ((service-affecting yes) (noservice-affecting no)) Possible values: - service-affecting : make this alarm service affecting - yes : make this alarm service affecting - noservice-affecting : make this alarm not service affecting - no : make this alarm not service affecting	alarms affect service or not <i>This element is only shown in detail mode.</i>
time	Parameter type: <Sys::timeInSecs> - the time (yyyy-mm-dd:hour:minutes:secs) - unit: UTC	time in seconds when alarm was updated <i>This element is only shown in detail mode.</i>
descript	Parameter type: <Alarm::AddInfoString> - additional alarm information	alarm description <i>This element is only shown in detail mode.</i>

101.19 show current alarm by filters

Command Description

show current alarms by filters

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm query redundancy [ (name) [ severity <Alarm::querySeverity> ] [ servaff <Alarm::queryServAffect> ] [ defaultaid <Alarm::queryDefaultAid> ] ]
```

Command Parameters

Table 101.19-1 "show current alarm by filters" Resource Parameters

Resource Identifier	Type	Description
(name)	Format: (loss-over-cap ping-check-fail all) Possible values: - loss-over-cap : switch over capability in a redundant system - ping-check-fail : ping check in a redundant system - all : show all bgp alarm	alarm name of redundancy
severity	Parameter type: <Alarm::querySeverity> Format: (indeterminate warning minor major critical all) Possible values: - indeterminate : alarm severity is indeterminate - warning : alarm severity is warning - minor : alarm severity is minor - major : alarm severity is major - critical : alarm severity is critical - all : all alarm severity	severity level of an alarm for reporting
servaff	Parameter type: <Alarm::queryServAffect> Format: (service-affecting noservice-affecting	serviceaffecting no

Resource Identifier	Type	Description
	all) Possible values: - service-affecting : query alarm service affecting - noservice-affecting : query alarm not service affecting - all : query service affecting and not affecting alarms	
defaultaid	Parameter type: <Alarm::queryDefaultAid> Format: all Possible values: - all : default AID parameter	default AID param is all

Command Output

Table 101.19-2 "show current alarm by filters" Display parameters

Specific Information		
name	Type	Description
type	Parameter type: <Alarm::alarmIHUBType> (equipment eqpt-holder plug-in-unit atm custom e1 ima-group ima-link redundancy shdsl ether-itf traffic-overflow qos-queue temporal spatial (software-mngt sw-mgmt) xdsl xdsl-ext xdsl-tca olt-gen eo-conv authentication bonding sfp shdsl-isam custom-ext-alarm plug-in-unit-ext sip-user-agent sip-plugin-unit sip-termination e1-sip-termination filetransfer external-device l2forward ether-tca ether-sfp megaco-media-gw megaco-sig-gw megaco-plugin-unit	type of the alarms that are active <i>This element is only shown in detail mode.</i>

101 query current alarms by filters

name	Type	Description
	megaco-term megaco-sig-lt eqpt-supplemental eqpt-holder-ext lsmredundancy sync mcsrc vlanport vect-line vect-board otdr sip-dial-plan sip-vsp sip-server bgp rip lag ihub-general vprn isis ospf ihub-l2forward vpls ihub-equip ihub-link eont-phyoam ellid epon eont-services-lan eolt-ont-tca eont-sw-dl ldp mpls sdp epipe ihub-ipv6 pim li mgmt-sec-access bfd ai tr069serv ontsnmp bulk-sync protection-group ont sfu-sup soho-sup mdu-sup ont-ani sfu-sup2 soho-sup2 mdu-sup2 sfprssi eoltrssi cfm sfpe1t1-framer	

name	Type	Description
	sfpe1t1-clock pppcc-engine-tca eth-cfm rsvp ihub-tca eth-ring efm-oam ont-loopdetect ont-video ont-ces ont-voip ont-video-ani ont-pwe ont-cese1 ont-xdsl ont-xdsl-tca ont-hpna ont-sip-agent-cfg ont-voip-cfg ont-mgc ont-ploam ont-gen ont-card ont-pots ont-lan ont-moca ont-tc-tca ont-moca-tca ont-l2uni-eth-tca olt-pon-tc-tca olt-pon-util-tca olt-chpr-util-tca olt-ont-tc-tca ont-tca ont-pots-supplemental sfu-ploam sfu-gen soho-ploam soho-gen mdu-ploam mdu-gen ont-veip ont-iphost alarm-table auto-switch channel-pair ont-cfg-dld olt-chpair-tc-tca hgu-tr069 eqpt-psu ont-protection secondary-megaco-term secondary-sip-term cas-r2-channel lldpmed pseudo-wire link-agg	

101 query current alarms by filters

name	Type	Description
	fcs-exceed e1t1-interface) Possible values: - equipment : equipment alarms - eqpt-holder : equipment holder alarms - plug-in-unit : plugin unit alarms - atm : ATM alarms - custom : customizable alarms - e1 : e1 alarms - ima-group : ima-group alarms - ima-link : ima-link alarms - redundancy : redundancy alarms - shdsl : shdsl alarms - ether-itf : ethernet interface alarms - traffic-overflow : Traffic overflow alarms - qos-queue : qos queue alarms - temporal : temporal alarms - spatial : spatial alarms - software-mngt : software management alarms - sw-mgmt : software management alarms - xdsl : xDSL alarms - xdsl-ext : other xDSL alarms - xdsl-tca : xDSL threshold cross alarms - olt-gen : OLT general alarms - eo-conv : E/O conversion related alarms - authentication : authentication related alarms - bonding : bonding-group related alarms - sfp : SFP related alarms - shdsl-isam : shdsl isam alarms - custom-ext-alarm : customizable external alarms - plug-in-unit-ext : other plugin unit alarms - sip-user-agent : sip user agent related alarms - sip-plugin-unit : sip plug in unit related alarms - sip-termination : sip termination related alarms - e1-sip-termination : E1 sip termination related alarms - filetransfer : file transfer server alarms - external-device : external device related alarms - l2forward : l2forward related alarms - ether-tca : ethernet threshold cross alarms - ether-sfp : ethernet SFP related alarms - megaco-media-gw : megaco media gateway related alarms - megaco-sig-gw : megaco signaling gateway related alarms - megaco-plug-unit : megaco plug unit related alarms - megaco-term : megaco termination related alarms - megaco-sig-lt : megaco signaling lt related alarms - eqpt-supplemental : equipment supplemental alarms - eqpt-holder-ext : other equipment holder alarms - lsmredundancy : lsm redundancy alarms - sync : synce and bits alarms - mcsrc : multicast source alarms - vlanport : vlanport alarms - vect-line : xDSL vectoring line alarms - vect-board : xDSL vectoring board alarms - otdr : otdr alarms - sip-dial-plan : sip dial plan related alarms - sip-vsp : sip vsp related alarms - sip-server : sip server related alarms	

name	Type	Description
	- bgp : bgp related alarms - rip : rip related alarms - lag : LAG related alarms - ihub-general : IHUB general related alarms - vprn : vprn related alarms - isis : isis related alarms - ospf : ospf related alarms - ihub-l2forward : ihub-l2forward alarms - vpls : vpls related alarms - ihub-equip : ihub-equip related alarms - ihub-link : ihub-link related alarms - eont-phyoam : eont phyoam related alarms - ellid : ellid related alarms - epon : epon related alarms - eont-services-lan : eon phyoam related alarms - eolt-ont-tca : eon phyoam related alarms - eont-sw-dl : eon phyoam related alarms - ldp : ldp related alarms - mpls : mpls related alarms - sdp : sdp related alarms - epipe : epipe related alarms - ihub-ipv6 : ihub-ipv6 related alarms - pim : pim related alarms - li : lawful intercept related alarms - mgmt-sec-access : management security related alarms - bfd : bfd related alarms - ai : Application Intelligence related alarms - tr069serv : tr069 server related alarms - ontsnmp : ont snmp related alarms - bulk-sync : bulk-sync related alarms - protection-group : port protection group related alarms - ont : ONT general supplemental related alarms - sfu-sup : SFU ONT general supplemental related alarms - soho-sup : SOHO ONT general supplemental related alarms - mdu-sup : MDU ONT general supplemental related alarms - ont-ani : ONT general supplemental 2 related alarms - sfu-sup2 : SFU ONT general supplemental 2 related alarms - soho-sup2 : SOHO ONT general supplemental 2 related alarms - mdu-sup2 : MDU ONT general supplemental 2 related alarms - sfprssi : SFP RSSI related alarms - eoltrssi : epon olt Sfp RSSI related alarms - cfm : Cfm related alarms - sfpe1t1-framer : SFP 2e1t1 framer alarms - sfpe1t1-clock : SFP 2e1t1 clock alarms - pppcc-engine-tca : PPPOE Cross Connect Engine TCA related alarm - eth-cfm : eth-cfm related alarms - rsvp : rsvp related alarms - ihub-tca : IHUB TCA related alarms - eth-ring : eth-ring related alarms - efm-oam : EFM-OAM related alarms - ont-loopdetect : ont loop detect related alarms - ont-video : ont services video related alarms - ont-ces : ont services ces related alarms	

101 query current alarms by filters

name	Type	Description
	- ont-voip : ont services voip related alarms - ont-video-ani : ont services video ani related alarms - ont-pwe : ont services pwe related alarms - ont-cese1 : ont services cese1 related alarms - ont-xdsl : ont services xdsl related alarms - ont-xdsl-tca : ont services xdsl tca related alarms - ont-hpna : ont hpna related alarms - ont-sip-agent-cfg : ont services voip sip agent config related alarms - ont-voip-cfg : ont services voip config related alarms - ont-mgc : ont mgc related alarms - ont-ploam : ONT PLOAM related alarms - ont-gen : ONT GENERAL related alarms - ont-card : ONT Subscriber Card related alarms - ont-pots : ONT Services POTS related alarms - ont-lan : ONT Services LAN related alarms - ont-moca : ONT MoCA related alarms - ont-tc-tca : ONT TC TCA related alarms - ont-moca-tca : ONT MoCA TCA related alarms - ont-l2uni-eth-tca : ONT L2 UNI Ethernet TCA related alarms - olt-pon-tc-tca : OLT PON TC TCA related alarms - olt-pon-util-tca : OLT PON utilization TCA related alarms - olt-chpr-util-tca : OLT channel-pair utilization TCA related alarms - olt-ont-tc-tca : OLT ONT TC TCA related alarms - ont-tca : ONT TCA related alarms - ont-pots-supplemental : ONT POTS Supplemental related alarms - sfu-ploam : SFU ONT PLOAM related alarms - sfu-gen : SFU ONT general related alarms - soho-ploam : SOHO ONT PLOAM related alarms - soho-gen : SOHO ONT general related alarms - mdu-ploam : MDU ONT PLOAM related alarms - mdu-gen : MDU ONT general related alarms - ont-veip : ONT VEIP related alarms - ont-iphost : ONT IP HOST related alarms - alarm-table : alarm table related alarms - auto-switch : auto-switch related alarms - channel-pair : channel pair related alarms - ont-cfg-dld : ont configure file download related alarms - olt-chpair-tc-tca : OLT CHANNELPAIR TC TCA related alarms - hgu-tr069 : hgu tr069 related alarms - eqpt-psu : equipment psu alarms - ont-protection : ONT protection related alarms - secondary-megaco-term : secondary megaco termination related alarms - secondary-sip-term : secondary sip termination related alarms - cas-r2-channel : CAS R2 channel related alarms - lldpmed : lldpmed alarms - pseudo-wire : pseudo Wire related alarms - link-agg : Link aggregation related alarms - fcs-exceed : FCS auto-recovery related alarms - e1t1-interface : E1/T1 physical interfaces related alarms	
name	Parameter type: <Alarm::almtypeRedundancy>	alarm name that are active

name	Type	Description
	(loss-over-cap ping-check-fail all) Possible values: - loss-over-cap : switch over capability in a redundant system - ping-check-fail : ping check in a redundant system - all : show all bgp alarm	<i>This element is only shown in detail mode.</i>
severity	Parameter type: <Alarm::AlarmSeverity> (indeterminate warning minor major critical) Possible values: - indeterminate : alarm severity is indeterminate - warning : alarm severity is warning - minor : alarm severity is minor - major : alarm severity is major - critical : alarm severity is critical	the alarms severity level <i>This element is only shown in detail mode.</i>
servaff	Parameter type: <Alarm::alarmServAffect> ((service-affecting yes) (noservice-affecting no)) Possible values: - service-affecting : make this alarm service affecting - yes : make this alarm service affecting - noservice-affecting : make this alarm not service affecting - no : make this alarm not service affecting	alarms affect service or not <i>This element is only shown in detail mode.</i>
time	Parameter type: <Sys::timeInSecs> - the time (yyyy-mm-dd:hour:minutes:secs) - unit: UTC	time in seconds when alarm was updated <i>This element is only shown in detail mode.</i>
descript	Parameter type: <Alarm::AddInfoString> - additional alarm information	alarm description <i>This element is only shown in detail mode.</i>

101.20 show current alarm by filters

Command Description

show current alarms by filters

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm query external-device [ (name) [ severity <Alarm::querySeverity> ] [ servaff
<Alarm::queryServAffect> ] [ defaultaid <Alarm::queryDefaultAid> ] ]
```

Command Parameters

Table 101.20-1 "show current alarm by filters" Resource Parameters

Resource Identifier	Type	Description
(name)	Format: (loss-env-mon all) Possible values: - loss-env-mon : env-monitor box lost or not alive - all : show all external device alarm	alarm name of external-device
severity	Parameter type: <Alarm::querySeverity> Format: (indeterminate warning minor major critical all) Possible values: - indeterminate : alarm severity is indeterminate - warning : alarm severity is warning - minor : alarm severity is minor - major : alarm severity is major - critical : alarm severity is critical - all : all alarm severity	severity level of an alarm for reporting
servaff	Parameter type: <Alarm::queryServAffect> Format: (service-affecting noservice-affecting all) Possible values: - service-affecting : query alarm service affecting	serviceaffecting no

Resource Identifier	Type	Description
	- noservice-affecting : query alarm not service affecting - all : query service affecting and not affecting alarms	
defaultaid	Parameter type: <Alarm::queryDefaultAid> Format: all Possible values: - all : default AID parameter	default AID param is all

Command Output

Table 101.20-2 "show current alarm by filters" Display parameters

Specific Information		
name	Type	Description
type	Parameter type: <Alarm::alarmIHUBType> (equipment eqpt-holder plug-in-unit atm custom e1 ima-group ima-link redundancy shdsl ether-itf traffic-overflow qos-queue temporal spatial (software-mngt sw-mgmt) xdsl xdsl-ext xdsl-tca olt-gen eo-conv authentication bonding sfp shdsl-isam custom-ext-alarm plug-in-unit-ext sip-user-agent sip-plugin-unit sip-termination e1-sip-termination filetransfer external-device l2forward ether-tca ether-sfp megaco-media-gw megaco-sig-gw megaco-plug-unit megaco-term megaco-sig-lt eqpt-supplemental	type of the alarms that are active <i>This element is only shown in detail mode.</i>

101 query current alarms by filters

name	Type	Description
	eqpt-holder-ext	
	lsmredundancy	
	sync	
	mcsrc	
	vlanport	
	vect-line	
	vect-board	
	otdr	
	sip-dial-plan	
	sip-vsp	
	sip-server	
	bgp	
	rip	
	lag	
	ihub-general	
	vprn	
	isis	
	ospf	
	ihub-l2forward	
	vpls	
	ihub-equip	
	ihub-link	
	eont-phyoam	
	ellid	
	epon	
	eont-services-lan	
	eolt-ont-tca	
	eont-sw-dl	
	ldp	
	mpls	
	sdp	
	epipe	
	ihub-ipv6	
	pim	
	li	
	mgmt-sec-access	
	bfd	
	ai	
	tr069serv	
	ontsnmp	
	bulk-sync	
	protection-group	
	ont	
	sfu-sup	
	soho-sup	
	mdu-sup	
	ont-ani	
	sfu-sup2	
	soho-sup2	
	mdu-sup2	
	sfprssi	
	eoltrssi	
	cfm	
	sfpe1t1-framer	
	sfpe1t1-clock	
	pppcc-engine-tca	
	eth-cfm	

name	Type	Description
	rsvp ihub-tca eth-ring efm-oam ont-loopdetect ont-video ont-ces ont-voip ont-video-ani ont-pwe ont-cese1 ont-xdsl ont-xdsl-tca ont-hpna ont-sip-agent-cfg ont-voip-cfg ont-mgc ont-ploam ont-gen ont-card ont-pots ont-lan ont-moca ont-tc-tca ont-moca-tca ont-l2uni-eth-tca olt-pon-tc-tca olt-pon-util-tca olt-chpr-util-tca olt-ont-tc-tca ont-tca ont-pots-supplemental sfu-ploam sfu-gen soho-ploam soho-gen mdu-ploam mdu-gen ont-veip ont-iphost alarm-table auto-switch channel-pair ont-cfg-dld olt-chpair-tc-tca hgu-tr069 eqpt-psu ont-protection secondary-megaco-term secondary-sip-term cas-r2-channel lldpmed pseudo-wire link-agg fcs-exceed e1t1-interface) Possible values:	

101 query current alarms by filters

name	Type	Description
	- equipment : equipment alarms - eqpt-holder : equipment holder alarms - plug-in-unit : plugin unit alarms - atm : ATM alarms - custom : customizable alarms - e1 : e1 alarms - ima-group : ima-group alarms - ima-link : ima-link alarms - redundancy : redundancy alarms - shdsl : shdsl alarms - ether-itf : ethernet interface alarms - traffic-overflow : Traffic overflow alarms - qos-queue : qos queue alarms - temporal : temporal alarms - spatial : spatial alarms - software-mngt : software management alarms - sw-mgmt : software management alarms - xdsl : xDSL alarms - xdsl-ext : other xDSL alarms - xdsl-tca : xDSL threshold cross alarms - olt-gen : OLT general alarms - eo-conv : E/O conversion related alarms - authentication : authentication related alarms - bonding : bonding-group related alarms - sfp : SFP related alarms - shdsl-isam : shdsl isam alarms - custom-ext-alarm : customizable external alarms - plug-in-unit-ext : other plugin unit alarms - sip-user-agent : sip user agent related alarms - sip-plugin-unit : sip plug in unit related alarms - sip-termination : sip termination related alarms - e1-sip-termination : E1 sip termination related alarms - filetransfer : file transfer server alarms - external-device : external device related alarms - l2forward : l2forward related alarms - ether-tca : ethernet threshold cross alarms - ether-sfp : ethernet SFP related alarms - megaco-media-gw : megaco media gateway related alarms - megaco-sig-gw : megaco signaling gateway related alarms - megaco-plug-unit : megaco plug unit related alarms - megaco-term : megaco termination related alarms - megaco-sig-lt : megaco signaling lt related alarms - eqpt-supplemental : equipment supplemental alarms - eqpt-holder-ext : other equipment holder alarms - lsmredundancy : lsm redundancy alarms - sync : synce and bits alarms - mcsrc : multicast source alarms - vlanport : vlanport alarms - vect-line : xDSL vectoring line alarms - vect-board : xDSL vectoring board alarms - otdr : otdr alarms - sip-dial-plan : sip dial plan related alarms - sip-vsp : sip vsp related alarms - sip-server : sip server related alarms - bgp : bgp related alarms - rip : rip related alarms - lag : LAG related alarms	

name	Type	Description
	- ihub-general : IHUB general related alarms - vprn : vprn related alarms - isis : isis related alarms - ospf : ospf related alarms - ihub-l2forward : ihub-l2forward alarms - vpls : vpls related alarms - ihub-equip : ihub-equip related alarms - ihub-link : ihub-link related alarms - eont-phyoam : eont phyoam related alarms - ellid : ellid related alarms - epon : epon related alarms - eont-services-lan : eon phyoam related alarms - eolt-ont-tca : eon phyoam related alarms - eont-sw-dl : eon phyoam related alarms - ldp : ldp related alarms - mpls : mpls related alarms - sdp : sdp related alarms - epipe : epipe related alarms - ihub-ipv6 : ihub-ipv6 related alarms - pim : pim related alarms - li : lawful intercept related alarms - mgmt-sec-access : management security related alarms - bfd : bfd related alarms - ai : Application Intelligence related alarms - tr069serv : tr069 server related alarms - ontsnmp : ont snmp related alarms - bulk-sync : bulk-sync related alarms - protection-group : port protection group related alarms - ont : ONT general supplemental related alarms - sfu-sup : SFU ONT general supplemental related alarms - soho-sup : SOHO ONT general supplemental related alarms - mdu-sup : MDU ONT general supplemental related alarms - ont-ani : ONT general supplemental 2 related alarms - sfu-sup2 : SFU ONT general supplemental 2 related alarms - soho-sup2 : SOHO ONT general supplemental 2 related alarms - mdu-sup2 : MDU ONT general supplemental 2 related alarms - sfprssi : SFP RSSI related alarms - eoltrssi : epon olt Sfp RSSI related alarms - cfm : Cfm related alarms - sfpe1t1-framer : SFP 2e1t1 framer alarms - sfpe1t1-clock : SFP 2e1t1 clock alarms - pppcc-engine-tca : PPPOE Cross Connect Engine TCA related alarm - eth-cfm : eth-cfm related alarms - rsvp : rsvp related alarms - ihub-tca : IHUB TCA related alarms - eth-ring : eth-ring related alarms - efm-oam : EFM-OAM related alarms - ont-loopdetect : ont loop detect related alarms - ont-video : ont services video related alarms - ont-ces : ont services ces related alarms - ont-voip : ont services voip related alarms - ont-video-ani : ont services video ani related alarms - ont-pwe : ont services pwe related alarms	

101 query current alarms by filters

name	Type	Description
	- ont-cese1 : ont services cese1 related alarms - ont-xdsl : ont services xdsl related alarms - ont-xdsl-tca : ont services xdsl tca related alarms - ont-hpna : ont hpna related alarms - ont-sip-agent-cfg : ont services voip sip agent config related alarms - ont-voip-cfg : ont services voip config related alarms - ont-mgc : ont mgc related alarms - ont-ploam : ONT PLOAM related alarms - ont-gen : ONT GENERAL related alarms - ont-card : ONT Subscriber Card related alarms - ont-pots : ONT Services POTS related alarms - ont-lan : ONT Services LAN related alarms - ont-moca : ONT MoCA related alarms - ont-tc-tca : ONT TC TCA related alarms - ont-moca-tca : ONT MoCA TCA related alarms - ont-l2uni-eth-tca : ONT L2 UNI Ethernet TCA related alarms - olt-pon-tc-tca : OLT PON TC TCA related alarms - olt-pon-util-tca : OLT PON utilization TCA related alarms - olt-chpr-util-tca : OLT channel-pair utilization TCA related alarms - olt-ont-tc-tca : OLT ONT TC TCA related alarms - ont-tca : ONT TCA related alarms - ont-pots-supplemental : ONT POTS Supplemental related alarms - sfu-ploam : SFU ONT PLOAM related alarms - sfu-gen : SFU ONT general related alarms - soho-ploam : SOHO ONT PLOAM related alarms - soho-gen : SOHO ONT general related alarms - mdu-ploam : MDU ONT PLOAM related alarms - mdu-gen : MDU ONT general related alarms - ont-veip : ONT VEIP related alarms - ont-iphost : ONT IP HOST related alarms - alarm-table : alarm table related alarms - auto-switch : auto-switch related alarms - channel-pair : channel pair related alarms - ont-cfg-dld : ont configure file download related alarms - olt-chpair-tc-tca : OLT CHANNELPAIR TC TCA related alarms - hgu-tr069 : hgu tr069 related alarms - eqpt-psu : equipment psu alarms - ont-protection : ONT protection related alarms - secondary-megaco-term : secondary megaco termination related alarms - secondary-sip-term : secondary sip termination related alarms - cas-r2-channel : CAS R2 channel related alarms - lldpmed : lldpmed alarms - pseudo-wire : pseudo Wire related alarms - link-agg : Link aggregation related alarms - fcs-exceed : FCS auto-recovery related alarms - e1t1-interface : E1/T1 physical interfaces related alarms	
name	Parameter type: <Alarm::alarmtypeExternaldevice> (loss-env-mon all) Possible values:	alarm name that are active <i>This element is only shown in detail mode.</i>

name	Type	Description
	- loss-env-mon : env-monitor box lost or not alive - all : show all external device alarm	
severity	Parameter type: <Alarm::AlarmSeverity> (indeterminate warning minor major critical) Possible values: - indeterminate : alarm severity is indeterminate - warning : alarm severity is warning - minor : alarm severity is minor - major : alarm severity is major - critical : alarm severity is critical	the alarms severity level <i>This element is only shown in detail mode.</i>
servaff	Parameter type: <Alarm::alarmServAffect> ((service-affecting yes) (noservice-affecting no)) Possible values: - service-affecting : make this alarm service affecting - yes : make this alarm service affecting - noservice-affecting : make this alarm not service affecting - no : make this alarm not service affecting	alarms affect service or not <i>This element is only shown in detail mode.</i>
time	Parameter type: <Sys::timeInSecs> - the time (yyyy-mm-dd:hour:minutes:secs) - unit: UTC	time in seconds when alarm was updated <i>This element is only shown in detail mode.</i>
descript	Parameter type: <Alarm::AddInfoString> - additional alarm information	alarm description <i>This element is only shown in detail mode.</i>

101.21 show current alarm by filters

Command Description

show current alarms by filters

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm query sfp [ (name) [ severity <Alarm::querySeverity> ] [ servaff <Alarm::queryServAffect> ] [ defaultaid <Alarm::queryDefaultAid> ] ]
```

Command Parameters

Table 101.21-1 "show current alarm by filters" Resource Parameters

Resource Identifier	Type	Description
(name)	Format: (host-sfp-los host-sfp-tx-fail host-sfp-not-prst host-sfp-inv-id host-sfp-ctrl-fail host-sfp-rmtlt host-sfp-mismatch host-sfp-incompt exp-sfp-los exp-sfp-tx-fail exp-sfp-not-prst exp-sfp-inv-id exp-sfp-ctrl-fail exp-sfp-1-los exp-sfp-2-los all) Possible values: - host-sfp-los : loss of signal - host-sfp-tx-fail : Tx failure - host-sfp-not-prst : not present - host-sfp-inv-id : no valid Nokia ID - host-sfp-ctrl-fail : control failure - host-sfp-rmtlt : unexpected remote plug-in - host-sfp-mismatch : assignment does not match reported rack/shelf/slot - host-sfp-incompt : incompatible shelf type detected - exp-sfp-los : expansion side loss of signal	alarm name of sfp

Resource Identifier	Type	Description
	- exp-sfp-tx-fail : Tx failure - exp-sfp-not-prst : not present - exp-sfp-inv-id : no valid Nokia ID - exp-sfp-ctrl-fail : control failure - exp-sfp-1-los : expansion side sfp1 loss of signal - exp-sfp-2-los : expansion side sfp2 loss of signal - all : show all SFP alarm	
severity	Parameter type: <Alarm::querySeverity> Format: (indeterminate warning minor major critical all) Possible values: - indeterminate : alarm severity is indeterminate - warning : alarm severity is warning - minor : alarm severity is minor - major : alarm severity is major - critical : alarm severity is critical - all : all alarm severity	severity level of an alarm for reporting
servaff	Parameter type: <Alarm::queryServAffect> Format: (service-affecting noservice-affecting all) Possible values: - service-affecting : query alarm service affecting - noservice-affecting : query alarm not service affecting - all : query service affecting and not affecting alarms	serviceaffecting no serviceaffecting
defaultaid	Parameter type: <Alarm::queryDefaultAid> Format: all Possible values: - all : default AID parameter	default AID param is all

Command Output

Table 101.21-2 "show current alarm by filters" Display parameters

Specific Information		
name	Type	Description
aidinfo	Parameter type: <Alarm::AddInfoString> - additional alarm information	alarm AID parameters <i>This element is only shown in detail mode.</i>
type	Parameter type: <Alarm::alarmIHUBType> (equipment eqpt-holder plug-in-unit atm custom e1 ima-group ima-link redundancy shdsl	type of the alarms that are active <i>This element is only shown in detail mode.</i>

101 query current alarms by filters

name	Type	Description
	ether-itf traffic-overflow qos-queue temporal spatial (software-mngt sw-mgmt) xdsl xdsl-ext xdsl-tca olt-gen eo-conv authentication bonding sfp shdsl-isam custom-ext-alarm plug-in-unit-ext sip-user-agent sip-plugin-unit sip-termination e1-sip-termination filetransfer external-device l2forward ether-tca ether-sfp megaco-media-gw megaco-sig-gw megaco-plug-unit megaco-term megaco-sig-lt eqpt-supplemental eqpt-holder-ext lsmredundancy sync mcsrc vlanport vect-line vect-board otdr sip-dial-plan sip-vsp sip-server bgp rip lag ihub-general vpn isis ospf ihub-l2forward vpls ihub-equip ihub-link eont-phyoam ellid epon	

name	Type	Description
	eont-services-lan eolt-ont-tca eont-sw-dl ldp mpls sdp epipe ihub-ipv6 pim li mgmt-sec-access bfd ai tr069serv ontsnmp bulk-sync protection-group ont sfu-sup soho-sup mdu-sup ont-ani sfu-sup2 soho-sup2 mdu-sup2 sfprssi eoltrssi cfm sfpe1t1-framer sfpe1t1-clock pppcc-engine-tca eth-cfm rsvp ihub-tca eth-ring efm-oam ont-loopdetect ont-video ont-ces ont-voip ont-video-ani ont-pwe ont-cese1 ont-xdsl ont-xdsl-tca ont-hpna ont-sip-agent-cfg ont-voip-cfg ont-mgc ont-ploam ont-gen ont-card ont-pots ont-lan ont-moca ont-tc-tca ont-moca-tca	

101 query current alarms by filters

name	Type	Description
	ont-l2uni-eth-tca olt-pon-tc-tca olt-pon-util-tca olt-chpr-util-tca olt-ont-tc-tca ont-tca ont-pots-supplemental sfu-ploam sfu-gen soho-ploam soho-gen mdu-ploam mdu-gen ont-veip ont-iphost alarm-table auto-switch channel-pair ont-cfg-dld olt-chpair-tc-tca hgu-tr069 eqpt-psu ont-protection secondary-megaco-term secondary-sip-term cas-r2-channel lldpmed pseudo-wire link-agg fcs-exceed e1t1-interface) Possible values: - equipment : equipment alarms - eqpt-holder : equipment holder alarms - plug-in-unit : plugin unit alarms - atm : ATM alarms - custom : customizable alarms - e1 : e1 alarms - ima-group : ima-group alarms - ima-link : ima-link alarms - redundancy : redundancy alarms - shdsl : shdsl alarms - ether-itf : ethernet interface alarms - traffic-overflow : Traffic overflow alarms - qos-queue : qos queue alarms - temporal : temporal alarms - spatial : spatial alarms - software-mngt : software management alarms - sw-mgmt : software management alarms - xdsl : xDSL alarms - xdsl-ext : other xDSL alarms - xdsl-tca : xDSL threshold cross alarms - olt-gen : OLT general alarms - eo-conv : E/O conversion related alarms - authentication : authentication related alarms - bonding : bonding-group related alarms - sfp : SFP related alarms	

name	Type	Description
	- shdsl-isam : shdsl isam alarms - custom-ext-alarm : customizable external alarms - plug-in-unit-ext : other plugin unit alarms - sip-user-agent : sip user agent related alarms - sip-plugin-unit : sip plug in unit related alarms - sip-termination : sip termination related alarms - e1-sip-termination : E1 sip termination related alarms - filetransfer : file transfer server alarms - external-device : external device related alarms - l2forward : l2forward related alarms - ether-tca : ethernet threshold cross alarms - ether-sfp : ethernet SFP related alarms - megaco-media-gw : megaco media gateway related alarms - megaco-sig-gw : megaco signaling gateway related alarms - megaco-plug-unit : megaco plug unit related alarms - megaco-term : megaco termination related alarms - megaco-sig-lt : megaco signaling lt related alarms - eqpt-supplemental : equipment supplemental alarms - eqpt-holder-ext : other equipment holder alarms - lsmredundancy : lsm redundancy alarms - sync : synce and bits alarms - mcsrc : multicast source alarms - vlanport : vlanport alarms - vect-line : xDSL vectoring line alarms - vect-board : xDSL vectoring board alarms - otdr : otdr alarms - sip-dial-plan : sip dial plan related alarms - sip-vsp : sip vsp related alarms - sip-server : sip server related alarms - bgp : bgp related alarms - rip : rip related alarms - lag : LAG related alarms - ihub-general : IHUB general related alarms - vprn : vprn related alarms - isis : isis related alarms - ospf : ospf related alarms - ihub-l2forward : ihub-l2forward alarms - vpls : vpls related alarms - ihub-equip : ihub-equip related alarms - ihub-link : ihub-link related alarms - eont-phyoam : eont phyoam related alarms - ellid : ellid related alarms - epon : epon related alarms - eont-services-lan : eon phyoam related alarms - eolt-ont-tca : eon phyoam related alarms - eont-sw-dl : eon phyoam related alarms - ldp : ldp related alarms - mpls : mpls related alarms - sdp : sdp related alarms - epipe : epipe related alarms - ihub-ipv6 : ihub-ipv6 related alarms - pim : pim related alarms - li : lawful intercept related alarms - mgmt-sec-access : management security related alarms - bfd : bfd related alarms - ai : Application Intelligence related alarms - tr069serv : tr069 server related alarms	

101 query current alarms by filters

name	Type	Description
	- ontsnmp : ont snmp related alarms - bulk-sync : bulk-sync related alarms - protection-group : port protection group related alarms - ont : ONT general supplemental related alarms - sfu-sup : SFU ONT general supplemental related alarms - soho-sup : SOHO ONT general supplemental related alarms - mdu-sup : MDU ONT general supplemental related alarms - ont-ani : ONT general supplemental 2 related alarms - sfu-sup2 : SFU ONT general supplemental 2 related alarms - soho-sup2 : SOHO ONT general supplemental 2 related alarms - mdu-sup2 : MDU ONT general supplemental 2 related alarms - sfprssi : SFP RSSI related alarms - eoltrssi : epon olt Sfp RSSI related alarms - cfm : Cfm related alarms - sfpe1t1-framer : SFP 2e1t1 framer alarms - sfpe1t1-clock : SFP 2e1t1 clock alarms - pppcc-engine-tca : PPPOE Cross Connect Engine TCA related alarm - eth-cfm : eth-cfm related alarms - rsvp : rsvp related alarms - ihub-tca : IHUB TCA related alarms - eth-ring : eth-ring related alarms - efm-oam : EFM-OAM related alarms - ont-loopdetect : ont loop detect related alarms - ont-video : ont services video related alarms - ont-ces : ont services ces related alarms - ont-voip : ont services voip related alarms - ont-video-ani : ont services video ani related alarms - ont-pwe : ont services pwe related alarms - ont-cese1 : ont services cese1 related alarms - ont-xdsl : ont services xdsl related alarms - ont-xdsl-tca : ont services xdsl tca related alarms - ont-hpna : ont hpna related alarms - ont-sip-agent-cfg : ont services voip sip agent config related alarms - ont-voip-cfg : ont services voip config related alarms - ont-mgc : ont mgc related alarms - ont-ploam : ONT PLOAM related alarms - ont-gen : ONT GENERAL related alarms - ont-card : ONT Subscriber Card related alarms - ont-pots : ONT Services POTS related alarms - ont-lan : ONT Services LAN related alarms - ont-moca : ONT MoCA related alarms - ont-tc-tca : ONT TC TCA related alarms - ont-moca-tca : ONT MoCA TCA related alarms - ont-l2uni-eth-tca : ONT L2 UNI Ethernet TCA related alarms - olt-pon-tc-tca : OLT PON TC TCA related alarms - olt-pon-util-tca : OLT PON utilization TCA related alarms - olt-chpr-util-tca : OLT channel-pair utilization TCA related alarms - olt-ont-tc-tca : OLT ONT TC TCA related alarms - ont-tca : ONT TCA related alarms - ont-pots-supplemental : ONT POTS Supplemental related	

name	Type	Description
	alarms - sfu-ploam : SFU ONT PLOAM related alarms - sfu-gen : SFU ONT general related alarms - soho-ploam : SOHO ONT PLOAM related alarms - soho-gen : SOHO ONT general related alarms - mdu-ploam : MDU ONT PLOAM related alarms - mdu-gen : MDU ONT general related alarms - ont-veip : ONT VEIP related alarms - ont-iphost : ONT IP HOST related alarms - alarm-table : alarm table related alarms - auto-switch : auto-switch related alarms - channel-pair : channel pair related alarms - ont-cfg-dld : ont configure file download related alarms - olt-chpair-tc-tca : OLT CHANNELPAIR TC TCA related alarms - hgu-tr069 : hgu tr069 related alarms - eqpt-psu : equipment psu alarms - ont-protection : ONT protection related alarms - secondary-megaco-term : secondary megaco termination related alarms - secondary-sip-term : secondary sip termination related alarms - cas-r2-channel : CAS R2 channel related alarms - lldpmed : lldpmed alarms - pseudo-wire : pseudo Wire related alarms - link-agg : Link aggregation related alarms - fcs-exceed : FCS auto-recovery related alarms - e1t1-interface : E1/T1 physical interfaces related alarms	
name	Parameter type: <Alarm::almtypeSfp> (host-sfp-los host-sfp-tx-fail host-sfp-not-prst host-sfp-inv-id host-sfp-ctrl-fail host-sfp-rmtlt host-sfp-mismatch host-sfp-incompt exp-sfp-los exp-sfp-tx-fail exp-sfp-not-prst exp-sfp-inv-id exp-sfp-ctrl-fail exp-sfp-1-los exp-sfp-2-los all) Possible values: - host-sfp-los : loss of signal - host-sfp-tx-fail : Tx failure - host-sfp-not-prst : not present - host-sfp-inv-id : no valid Nokia ID - host-sfp-ctrl-fail : control failure - host-sfp-rmtlt : unexpected remote plug-in - host-sfp-mismatch : assignment does not match reported rack/shelf/slot - host-sfp-incompt : incompatible shelf type detected - exp-sfp-los : expansion side loss of signal - exp-sfp-tx-fail : Tx failure	alarm name that are active <i>This element is only shown in detail mode.</i>

101 query current alarms by filters

name	Type	Description
	- exp-sfp-not-prst : not present - exp-sfp-inv-id : no valid Nokia ID - exp-sfp-ctrl-fail : control failure - exp-sfp-1-los : expansion side sfp1 loss of signal - exp-sfp-2-los : expansion side sfp2 loss of signal - all : show all SFP alarm	
severity	Parameter type: <Alarm::AlarmSeverity> (indeterminate warning minor major critical) Possible values: - indeterminate : alarm severity is indeterminate - warning : alarm severity is warning - minor : alarm severity is minor - major : alarm severity is major - critical : alarm severity is critical	the alarms severity level <i>This element is only shown in detail mode.</i>
servaff	Parameter type: <Alarm::alarmServAffect> ((service-affecting yes) (noservice-affecting no)) Possible values: - service-affecting : make this alarm service affecting - yes : make this alarm service affecting - noservice-affecting : make this alarm not service affecting - no : make this alarm not service affecting	alarms affect service or not <i>This element is only shown in detail mode.</i>
time	Parameter type: <Sys::timeInSecs> - the time (yyyy-mm-dd:hour:minutes:secs) - unit: UTC	time in seconds when alarm was updated <i>This element is only shown in detail mode.</i>
descript	Parameter type: <Alarm::AddInfoString> - additional alarm information	alarm description <i>This element is only shown in detail mode.</i>

101.22 show current alarm by filters

Command Description

show current alarms by filters

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm query custom-ext-alarm [ (name) [ severity <Alarm::querySeverity> ] [ servaff
<Alarm::queryServAffect> ] [ board <Equipm::EqptSlotIndex> ] ]
```

Command Parameters

Table 101.22-1 "show current alarm by filters" Resource Parameters

Resource Identifier	Type	Description
(name)	Format: (custextalarm1 custextalarm2 custextalarm3 custextalarm4 custextalarm5 all) Possible values: - custextalarm1 : Customizable External Alarm Number 1 - custextalarm2 : Customizable External Alarm Number 2 - custextalarm3 : Customizable External Alarm Number 3 - custextalarm4 : Customizable External Alarm Number 4 - custextalarm5 : Customizable External Alarm Number 5 - all : show all customizable external alarm	alarm name of custom-ext-alarm
severity	Parameter type: <Alarm::querySeverity> Format: (indeterminate warning minor major critical all) Possible values: - indeterminate : alarm severity is indeterminate - warning : alarm severity is warning - minor : alarm severity is minor - major : alarm severity is major - critical : alarm severity is critical	severity level of an alarm for reporting

101 query current alarms by filters

Resource Identifier	Type	Description
servaff	Parameter type: <Alarm::queryServAffect> Format: (service-affecting noservice-affecting all) Possible values: - service-affecting : query alarm service affecting - noservice-affecting : query alarm not service affecting - all : query service affecting and not affecting alarms	serviceaffecting no serviceaffecting
board	Parameter type: <Equipm::EqptSlotIndex> Format: (lt : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> nt-a nt-b nt acu : <Eqpt::RackId> / <Eqpt::ShelfId> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::EqSlotId> ext-a : <Eqpt::RackId> / <Eqpt::ShelfId> ext-b : <Eqpt::RackId> / <Eqpt::ShelfId> ctrl : <Eqpt::RackId> / <Eqpt::ShelfId> vlt : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::VirtualSlotId>) Possible values: - lt : lt-slot - vlt : virtual LT slot (VVPS board can only be planned at NANT-E / FANT-F) - nt-a : nt-a slot - nt-b : nt-b slot - nt : nt slot - ext-a : nt-a slot in an extension shelf - ext-b : nt-b slot in an extension shelf - acu : acu slot - ctrl : ctrl-slot Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::VirtualSlotId> - the virtual LT slot number Field type <Eqpt::EqSlotId> - the equipment slot number	the physical number of the slot

Command Output

Table 101.22-2 "show current alarm by filters" Display parameters

Specific Information		
name	Type	Description
aidinfo	Parameter type: <Alarm::AddInfoString> - additional alarm information	alarm AID parameters <i>This element is only shown in detail mode.</i>
type	Parameter type: <Alarm::alarmIHUBType> (equipment eqpt-holder	type of the alarms that are active <i>This element is only shown in detail mode.</i>

name	Type	Description
	plug-in-unit atm custom e1 ima-group ima-link redundancy shdsl ether-itf traffic-overflow qos-queue temporal spatial (software-mngt sw-mgmt) xdsl xdsl-ext xdsl-tca olt-gen eo-conv authentication bonding sfp shdsl-isam custom-ext-alarm plug-in-unit-ext sip-user-agent sip-plugin-unit sip-termination e1-sip-termination filetransfer external-device l2forward ether-tca ether-sfp megaco-media-gw megaco-sig-gw megaco-plugin-unit megaco-term megaco-sig-lt eqpt-supplemental eqpt-holder-ext lsmredundancy sync mcsrc vlanport vect-line vect-board otdr sip-dial-plan sip-vsp sip-server bgp rip lag ihub-general vprn isis	

101 query current alarms by filters

name	Type	Description
	ospf	
	ihub-l2forward	
	vpls	
	ihub-equip	
	ihub-link	
	eont-phyoam	
	ellid	
	epon	
	eont-services-lan	
	eolt-ont-tca	
	eont-sw-dl	
	ldp	
	mpls	
	sdp	
	epipe	
	ihub-ipv6	
	pim	
	li	
	mgmt-sec-access	
	bfd	
	ai	
	tr069serv	
	ontsnmp	
	bulk-sync	
	protection-group	
	ont	
	sfu-sup	
	soho-sup	
	mdu-sup	
	ont-ani	
	sfu-sup2	
	soho-sup2	
	mdu-sup2	
	sfprssi	
	eoltrssi	
	cfm	
	sfpe1t1-framer	
	sfpe1t1-clock	
	pppcc-engine-tca	
	eth-cfm	
	rsvp	
	ihub-tca	
	eth-ring	
	efm-oam	
	ont-loopdetect	
	ont-video	
	ont-ces	
	ont-voip	
	ont-video-ani	
	ont-pwe	
	ont-cese1	
	ont-xdsl	
	ont-xdsl-tca	
	ont-hpna	
	ont-sip-agent-cfg	
	ont-voip-cfg	
	ont-mgc	

name	Type	Description
	ont-ploam ont-gen ont-card ont-pots ont-lan ont-moca ont-tc-tca ont-moca-tca ont-l2uni-eth-tca olt-pon-tc-tca olt-pon-util-tca olt-chpr-util-tca olt-ont-tc-tca ont-tca ont-pots-supplemental sfu-ploam sfu-gen soho-ploam soho-gen mdu-ploam mdu-gen ont-veip ont-iphost alarm-table auto-switch channel-pair ont-cfg-dld olt-chpair-tc-tca hgu-tr069 eqpt-psu ont-protection secondary-megaco-term secondary-sip-term cas-r2-channel lldpmed pseudo-wire link-agg fcs-exceed e1t1-interface) Possible values: - equipment : equipment alarms - eqpt-holder : equipment holder alarms - plug-in-unit : plugin unit alarms - atm : ATM alarms - custom : customizable alarms - e1 : e1 alarms - ima-group : ima-group alarms - ima-link : ima-link alarms - redundancy : redundancy alarms - shdsl : shdsl alarms - ether-itf : ethernet interface alarms - traffic-overflow : Traffic overflow alarms - qos-queue : qos queue alarms - temporal : temporal alarms - spatial : spatial alarms - software-mngt : software management alarms - sw-mgmt : software management alarms	

101 query current alarms by filters

name	Type	Description
	- xdsl : xDSL alarms - xdsl-ext : other xDSL alarms - xdsl-tca : xDSL threshold cross alarms - olt-gen : OLT general alarms - eo-conv : E/O conversion related alarms - authentication : authentication related alarms - bonding : bonding-group related alarms - sfp : SFP related alarms - shdsl-isam : shdsl isam alarms - custom-ext-alarm : customizable external alarms - plug-in-unit-ext : other plugin unit alarms - sip-user-agent : sip user agent related alarms - sip-plugin-unit : sip plug in unit related alarms - sip-termination : sip termination related alarms - e1-sip-termination : E1 sip termination related alarms - filetransfer : file transfer server alarms - external-device : external device related alarms - l2forward : l2forward related alarms - ether-tca : ethernet threshold cross alarms - ether-sfp : ethernet SFP related alarms - megaco-media-gw : megaco media gateway related alarms - megaco-sig-gw : megaco signaling gateway related alarms - megaco-plug-unit : megaco plug unit related alarms - megaco-term : megaco termination related alarms - megaco-sig-lt : megaco signaling lt related alarms - eqpt-supplemental : equipment supplemental alarms - eqpt-holder-ext : other equipment holder alarms - lsmredundancy : lsm redundancy alarms - sync : synce and bits alarms - mcsrc : multicast source alarms - vlanport : vlanport alarms - vect-line : xDSL vectoring line alarms - vect-board : xDSL vectoring board alarms - otdr : otdr alarms - sip-dial-plan : sip dial plan related alarms - sip-vsp : sip vsp related alarms - sip-server : sip server related alarms - bgp : bgp related alarms - rip : rip related alarms - lag : LAG related alarms - ihub-general : IHUB general related alarms - vprn : vprn related alarms - isis : isis related alarms - ospf : ospf related alarms - ihub-l2forward : ihub-l2forward alarms - vpls : vpls related alarms - ihub-equip : ihub-equip related alarms - ihub-link : ihub-link related alarms - eont-phyoam : eont phyoam related alarms - ellid : ellid related alarms - epon : epon related alarms - eont-services-lan : eon phyoam related alarms - eolt-ont-tca : eon phyoam related alarms - eont-sw-dl : eon phyoam related alarms - ldp : ldp related alarms - mpls : mpls related alarms - sdp : sdp related alarms	

name	Type	Description
	- epipe : epipe related alarms - ihub-ipv6 : ihub-ipv6 related alarms - pim : pim related alarms - li : lawful intercept related alarms - mgmt-sec-access : management security related alarms - bfd : bfd related alarms - ai : Application Intelligence related alarms - tr069serv : tr069 server related alarms - ontsnmp : ont snmp related alarms - bulk-sync : bulk-sync related alarms - protection-group : port protection group related alarms - ont : ONT general supplemental related alarms - sfu-sup : SFU ONT general supplemental related alarms - soho-sup : SOHO ONT general supplemental related alarms - mdu-sup : MDU ONT general supplemental related alarms - ont-ani : ONT general supplemental 2 related alarms - sfu-sup2 : SFU ONT general supplemental 2 related alarms - soho-sup2 : SOHO ONT general supplemental 2 related alarms - mdu-sup2 : MDU ONT general supplemental 2 related alarms - sfprssi : SFP RSSI related alarms - eoltrssi : epon olt Sfp RSSI related alarms - cfm : Cfm related alarms - sfpe1t1-framer : SFP 2e1t1 framer alarms - sfpe1t1-clock : SFP 2e1t1 clock alarms - pppcc-engine-tca : PPPOE Cross Connect Engine TCA related alarm - eth-cfm : eth-cfm related alarms - rsvp : rsvp related alarms - ihub-tca : IHUB TCA related alarms - eth-ring : eth-ring related alarms - efm-oam : EFM-OAM related alarms - ont-loopdetect : ont loop detect related alarms - ont-video : ont services video related alarms - ont-ces : ont services ces related alarms - ont-voip : ont services voip related alarms - ont-video-ani : ont services video ani related alarms - ont-pwe : ont services pwe related alarms - ont-cese1 : ont services cese1 related alarms - ont-xdsl : ont services xdsl related alarms - ont-xdsl-tca : ont services xdsl tca related alarms - ont-hpna : ont hpna related alarms - ont-sip-agent-cfg : ont services voip sip agent config related alarms - ont-voip-cfg : ont services voip config related alarms - ont-mgc : ont mgc related alarms - ont-ploam : ONT PLOAM related alarms - ont-gen : ONT GENERAL related alarms - ont-card : ONT Subscriber Card related alarms - ont-pots : ONT Services POTS related alarms - ont-lan : ONT Services LAN related alarms - ont-moca : ONT MoCA related alarms - ont-tc-tca : ONT TC TCA related alarms - ont-moca-tca : ONT MoCA TCA related alarms - ont-l2uni-eth-tca : ONT L2 UNI Ethernet TCA related	

101 query current alarms by filters

name	Type	Description
	alarms - olt-pon-tc-tca : OLT PON TC TCA related alarms - olt-pon-util-tca : OLT PON utilization TCA related alarms - olt-chpr-util-tca : OLT channel-pair utilization TCA related alarms - olt-ont-tc-tca : OLT ONT TC TCA related alarms - ont-tca : ONT TCA related alarms - ont-pots-supplemental : ONT POTS Supplemental related alarms - sfu-ploam : SFU ONT PLOAM related alarms - sfu-gen : SFU ONT general related alarms - soho-ploam : SOHO ONT PLOAM related alarms - soho-gen : SOHO ONT general related alarms - mdu-ploam : MDU ONT PLOAM related alarms - mdu-gen : MDU ONT general related alarms - ont-veip : ONT VEIP related alarms - ont-iphost : ONT IP HOST related alarms - alarm-table : alarm table related alarms - auto-switch : auto-switch related alarms - channel-pair : channel pair related alarms - ont-cfg-dld : ont configure file download related alarms - olt-chpair-tc-tca : OLT CHANNELPAIR TC TCA related alarms - hgu-tr069 : hgu tr069 related alarms - eqpt-psu : equipment psu alarms - ont-protection : ONT protection related alarms - secondary-megaco-term : secondary megaco termination related alarms - secondary-sip-term : secondary sip termination related alarms - cas-r2-channel : CAS R2 channel related alarms - lldpmed : lldpmed alarms - pseudo-wire : pseudo Wire related alarms - link-agg : Link aggregation related alarms - fcs-exceed : FCS auto-recovery related alarms - e1t1-interface : E1/T1 physical interfaces related alarms	
name	Parameter type: <Alarm::alarmtypeCustomext> (custextalarm1 custextalarm2 custextalarm3 custextalarm4 custextalarm5 all) Possible values: - custextalarm1 : Customizable External Alarm Number 1 - custextalarm2 : Customizable External Alarm Number 2 - custextalarm3 : Customizable External Alarm Number 3 - custextalarm4 : Customizable External Alarm Number 4 - custextalarm5 : Customizable External Alarm Number 5 - all : show all customizable external alarm	alarm name that are active <i>This element is only shown in detail mode.</i>
severity	Parameter type: <Alarm::AlarmSeverity> (indeterminate warning minor major critical) Possible values:	the alarms severity level <i>This element is only shown in detail mode.</i>

name	Type	Description
	- indeterminate : alarm severity is indeterminate - warning : alarm severity is warning - minor : alarm severity is minor - major : alarm severity is major - critical : alarm severity is critical	
servaff	Parameter type: <Alarm::alarmServAffect> ((service-affecting yes) (noservice-affecting no)) Possible values: - service-affecting : make this alarm service affecting - yes : make this alarm service affecting - noservice-affecting : make this alarm not service affecting - no : make this alarm not service affecting	alarms affect service or not <i>This element is only shown in detail mode.</i>
time	Parameter type: <Sys::timeInSecs> - the time (yyyy-mm-dd:hour:minutes:secs) - unit: UTC	time in seconds when alarm was updated <i>This element is only shown in detail mode.</i>
descript	Parameter type: <Alarm::AddInfoString> - additional alarm information	alarm description <i>This element is only shown in detail mode.</i>

101.23 show current alarm by filters

Command Description

show current alarms by filters

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm query sfrssi [ (name) [ severity <Alarm::querySeverity> ] [ servaff <Alarm::queryServAffect> ] [ board <Alarm::SlotIndex> ] ]
```

Command Parameters

Table 101.23-1 "show current alarm by filters" Resource Parameters

Resource Identifier	Type	Description
(name)	Format: (tx-power-high-alarm tx-power-low-alarm rx-power-high-alarm rx-power-low-alarm tx-biascur-high-alarm tx-biascur-low-alarm volt-high-alarm volt-low-alarm temp-high-alarm temp-low-alarm tx-power-high-warn tx-power-low-warn rx-power-high-warn rx-power-low-warn tx-biascur-high-warn tx-biascur-low-warn volt-high-warn volt-low-warn temp-high-warn temp-low-warn all) Possible values: - tx-power-high-alarm : tx power more than alarm range - tx-power-low-alarm : tx power less than alarm range - rx-power-high-alarm : rx power more than alarm range - rx-power-low-alarm : rx power less than alarm range - tx-biascur-high-alarm : tx bias current high alarm	alarm name of sfrssi

Resource Identifier	Type	Description
	- tx-biascur-low-alarm : tx bias current low alarm - volt-high-alarm : voltage high alarm - volt-low-alarm : voltage low alarm - temp-high-alarm : temperature high alarm - temp-low-alarm : temperature low alarm - tx-power-high-warn : tx power more than warn range - tx-power-low-warn : tx power less than warn range - rx-power-high-warn : rx power more than warn range - rx-power-low-warn : rx power less than warn range - tx-biascur-high-warn : tx bias current high warn - tx-biascur-low-warn : tx bias current low warn - volt-high-warn : voltage high warn - volt-low-warn : voltage low warn - temp-high-warn : temperature high warn - temp-low-warn : temperature low warn - all : show all SFP RSSI alarm	
severity	Parameter type: <Alarm::querySeverity> Format: (indeterminate warning minor major critical all) Possible values: - indeterminate : alarm severity is indeterminate - warning : alarm severity is warning - minor : alarm severity is minor - major : alarm severity is major - critical : alarm severity is critical - all : all alarm severity	severity level of an alarm for reporting
servaff	Parameter type: <Alarm::queryServAffect> Format: (service-affecting noservice-affecting all) Possible values: - service-affecting : query alarm service affecting - noservice-affecting : query alarm not service affecting - all : query service affecting and not affecting alarms	serviceaffecting no serviceaffecting
board	Parameter type: <Alarm::SlotIndex> Format: (lt : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> nt-a nt-b nt acu : <Eqpt::RackId> / <Eqpt::ShelfId> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::EqSlotId> ext-a : <Eqpt::RackId> / <Eqpt::ShelfId> ext-b : <Eqpt::RackId> / <Eqpt::ShelfId> ctrl : <Eqpt::RackId> / <Eqpt::ShelfId> iont : <Eqpt::RackId> / <Eqpt::ShelfId> lp : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::LtAppliqueSlotId> ntio-1 ntio-2 vlt : <Eqpt::RackId> / <Eqpt::ShelfId> /	the physical number of the slot

101 query current alarms by filters

Resource Identifier	Type	Description
	<Eqpt::VirtualSlotId>) Possible values: - lt : lt-slot - vlt : virtual LT slot (VVPS board can only be planned at NANT-E/FANT-F) - nt-a : nt-a slot - nt-b : nt-b slot - nt : nt slot - ext-a : nt-a slot in an extension shelf - ext-b : nt-b slot in an extension shelf - acu : acu slot - ctrl : ctrl-slot - iont : an nt applique slot - lp : an lt applique slot - ntio-1 : an nt applique slot in a single or multiple-ntio-shelf - ntio-2 : an nt applique slot in a multiple-ntio-shelf Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::LtAppliqueSlotId> - the LT Applique slot number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::VirtualSlotId> - the virtual LT slot number Field type <Eqpt::EqSlotId> - the equipment slot number	

Command Output

Table 101.23-2 "show current alarm by filters" Display parameters

Specific Information		
name	Type	Description
aidinfo	Parameter type: <Alarm::AddInfoString> - additional alarm information	alarm AID parameters <i>This element is only shown in detail mode.</i>
type	Parameter type: <Alarm::alarmIHUBType> (equipment eqpt-holder plug-in-unit atm custom e1 ima-group ima-link redundancy shdsl ether-itf traffic-overflow qos-queue temporal spatial (software-mngt sw-mgmt) xdsl xdsl-ext	type of the alarms that are active <i>This element is only shown in detail mode.</i>

name	Type	Description
	xds1-tca olt-gen eo-conv authentication bonding sfp shdsl-isam custom-ext-alarm plug-in-unit-ext sip-user-agent sip-plugin-unit sip-termination e1-sip-termination filetransfer external-device l2forward ether-tca ether-sfp megaco-media-gw megaco-sig-gw megaco-plug-unit megaco-term megaco-sig-lt eqpt-supplemental eqpt-holder-ext lsmredundancy sync mcsrc vlanport vect-line vect-board otdr sip-dial-plan sip-vsp sip-server bgp rip lag ihub-general vprn isis ospf ihub-l2forward vpls ihub-equip ihub-link eont-phyoam ellid epon eont-services-lan eolt-ont-tca eont-sw-dl ldp mpls sdp epipe ihub-ipv6	

101 query current alarms by filters

name	Type	Description
	pim li mgmt-sec-access bfd ai tr069serv ontsnmp bulk-sync protection-group ont sfu-sup soho-sup mdu-sup ont-ani sfu-sup2 soho-sup2 mdu-sup2 sfprssi eoltrssi cfm sfpe1t1-framer sfpe1t1-clock pppcc-engine-tca eth-cfm rsvp ihub-tca eth-ring efm-oam ont-loopdetect ont-video ont-ces ont-voip ont-video-ani ont-pwe ont-cese1 ont-xdsl ont-xdsl-tca ont-hpna ont-sip-agent-cfg ont-voip-cfg ont-mgc ont-ploam ont-gen ont-card ont-pots ont-lan ont-moca ont-tc-tca ont-moca-tca ont-l2uni-eth-tca olt-pon-tc-tca olt-pon-util-tca olt-chpr-util-tca olt-ont-tc-tca ont-tca ont-pots-supplemental sfu-ploam	

name	Type	Description
	sfu-gen soho-ploam soho-gen mdu-ploam mdu-gen ont-veip ont-iphost alarm-table auto-switch channel-pair ont-cfg-dld olt-chpair-tc-tca hgu-tr069 eqpt-psu ont-protection secondary-megaco-term secondary-sip-term cas-r2-channel lldpmed pseudo-wire link-agg fcs-exceed e1t1-interface) Possible values: - equipment : equipment alarms - eqpt-holder : equipment holder alarms - plug-in-unit : plugin unit alarms - atm : ATM alarms - custom : customizable alarms - e1 : e1 alarms - ima-group : ima-group alarms - ima-link : ima-link alarms - redundancy : redundancy alarms - shdsl : shdsl alarms - ether-itf : ethernet interface alarms - traffic-overflow : Traffic overflow alarms - qos-queue : qos queue alarms - temporal : temporal alarms - spatial : spatial alarms - software-mngt : software management alarms - sw-mgmt : software management alarms - xdsl : xDSL alarms - xdsl-ext : other xDSL alarms - xdsl-tca : xDSL threshold cross alarms - olt-gen : OLT general alarms - eo-conv : E/O conversion related alarms - authentication : authentication related alarms - bonding : bonding-group related alarms - sfp : SFP related alarms - shdsl-isam : shdsl isam alarms - custom-ext-alarm : customizable external alarms - plug-in-unit-ext : other plugin unit alarms - sip-user-agent : sip user agent related alarms - sip-plugin-unit : sip plug in unit related alarms - sip-termination : sip termination related alarms - e1-sip-termination : E1 sip termination related alarms - filetransfer : file transfer server alarms	

101 query current alarms by filters

name	Type	Description
	- external-device : external device related alarms - l2forward : l2forward related alarms - ether-tca : ethernet threshold cross alarms - ether-sfp : ethernet SFP related alarms - megaco-media-gw : megaco media gateway related alarms - megaco-sig-gw : megaco signaling gateway related alarms - megaco-plug-unit : megaco plug unit related alarms - megaco-term : megaco termination related alarms - megaco-sig-lt : megaco signaling lt related alarms - eqpt-supplemental : equipment supplemental alarms - eqpt-holder-ext : other equipment holder alarms - lsmredundancy : lsm redundancy alarms - sync : synce and bits alarms - mcsrc : multicast source alarms - vlanport : vlanport alarms - vect-line : xDSL vectoring line alarms - vect-board : xDSL vectoring board alarms - otdr : otdr alarms - sip-dial-plan : sip dial plan related alarms - sip-vsp : sip vsp related alarms - sip-server : sip server related alarms - bgp : bgp related alarms - rip : rip related alarms - lag : LAG related alarms - ihub-general : IHUB general related alarms - vprn : vprn related alarms - isis : isis related alarms - ospf : ospf related alarms - ihub-l2forward : ihub-l2forward alarms - vpls : vpls related alarms - ihub-equip : ihub-equip related alarms - ihub-link : ihub-link related alarms - eont-phyoam : eont phyoam related alarms - ellid : ellid related alarms - epon : epon related alarms - eont-services-lan : eon phyoam related alarms - eolt-ont-tca : eon phyoam related alarms - eont-sw-dl : eon phyoam related alarms - ldp : ldp related alarms - mpls : mpls related alarms - sdp : sdp related alarms - epipe : epipe related alarms - ihub-ipv6 : ihub-ipv6 related alarms - pim : pim related alarms - li : lawful intercept related alarms - mgmt-sec-access : management security related alarms - bfd : bfd related alarms - ai : Application Intelligence related alarms - tr069serv : tr069 server related alarms - ontsnmp : ont snmp related alarms - bulk-sync : bulk-sync related alarms - protection-group : port protection group related alarms - ont : ONT general supplemental related alarms - sfu-sup : SFU ONT general supplemental related alarms - soho-sup : SOHO ONT general supplemental related alarms - mdm-sup : MDU ONT general supplemental related alarms	

name	Type	Description
	- ont-ani : ONT general supplemental 2 related alarms - sfu-sup2 : SFU ONT general supplemental 2 related alarms - soho-sup2 : SOHO ONT general supplemental 2 related alarms - mdu-sup2 : MDU ONT general supplemental 2 related alarms - sfprssi : SFP RSSI related alarms - eoltrssi : epon olt Sfp RSSI related alarms - cfm : Cfm related alarms - sfpe1t1-framer : SFP 2e1t1 framer alarms - sfpe1t1-clock : SFP 2e1t1 clock alarms - pppcc-engine-tca : PPPOE Cross Connect Engine TCA related alarm - eth-cfm : eth-cfm related alarms - rsvp : rsvp related alarms - ihub-tca : IHUB TCA related alarms - eth-ring : eth-ring related alarms - efm-oam : EFM-OAM related alarms - ont-loopdetect : ont loop detect related alarms - ont-video : ont services video related alarms - ont-ces : ont services ces related alarms - ont-voip : ont services voip related alarms - ont-video-ani : ont services video ani related alarms - ont-pwe : ont services pwe related alarms - ont-cese1 : ont services cese1 related alarms - ont-xdsl : ont services xdsl related alarms - ont-xdsl-tca : ont services xdsl tca related alarms - ont-hpna : ont hpna related alarms - ont-sip-agent-cfg : ont services voip sip agent config related alarms - ont-voip-cfg : ont services voip config related alarms - ont-mgc : ont mgc related alarms - ont-ploam : ONT PLOAM related alarms - ont-gen : ONT GENERAL related alarms - ont-card : ONT Subscriber Card related alarms - ont-pots : ONT Services POTS related alarms - ont-lan : ONT Services LAN related alarms - ont-moca : ONT MoCA related alarms - ont-tc-tca : ONT TC TCA related alarms - ont-moca-tca : ONT MoCA TCA related alarms - ont-l2uni-eth-tca : ONT L2 UNI Ethernet TCA related alarms - olt-pon-tc-tca : OLT PON TC TCA related alarms - olt-pon-util-tca : OLT PON utilization TCA related alarms - olt-chpr-util-tca : OLT channel-pair utilization TCA related alarms - olt-ont-tc-tca : OLT ONT TC TCA related alarms - ont-tca : ONT TCA related alarms - ont-pots-supplemental : ONT POTS Supplemental related alarms - sfu-ploam : SFU ONT PLOAM related alarms - sfu-gen : SFU ONT general related alarms - soho-ploam : SOHO ONT PLOAM related alarms - soho-gen : SOHO ONT general related alarms - mdu-ploam : MDU ONT PLOAM related alarms - mdu-gen : MDU ONT general related alarms - ont-veip : ONT VEIP related alarms	

101 query current alarms by filters

name	Type	Description
	- ont-iphost : ONT IP HOST related alarms - alarm-table : alarm table related alarms - auto-switch : auto-switch related alarms - channel-pair : channel pair related alarms - ont-cfg-dld : ont configure file download related alarms - olt-chpair-tc-tca : OLT CHANNELPAIR TC TCA related alarms - hgu-tr069 : hgu tr069 related alarms - eqpt-psu : equipment psu alarms - ont-protection : ONT protection related alarms - secondary-megaco-term : secondary megaco termination related alarms - secondary-sip-term : secondary sip termination related alarms - cas-r2-channel : CAS R2 channel related alarms - lldpmed : lldpmed alarms - pseudo-wire : pseudo Wire related alarms - link-agg : Link aggregation related alarms - fcs-exceed : FCS auto-recovery related alarms - elt1-interface : E1/T1 physical interfaces related alarms	
name	Parameter type: <Alarm::almtypeSfprssi> (tx-power-high-alarm tx-power-low-alarm rx-power-high-alarm rx-power-low-alarm tx-biascur-high-alarm tx-biascur-low-alarm volt-high-alarm volt-low-alarm temp-high-alarm temp-low-alarm tx-power-high-warn tx-power-low-warn rx-power-high-warn rx-power-low-warn tx-biascur-high-warn tx-biascur-low-warn volt-high-warn volt-low-warn temp-high-warn temp-low-warn all) Possible values: - tx-power-high-alarm : tx power more than alarm range - tx-power-low-alarm : tx power less than alarm range - rx-power-high-alarm : rx power more than alarm range - rx-power-low-alarm : rx power less than alarm range - tx-biascur-high-alarm : tx bias current high alarm - tx-biascur-low-alarm : tx bias current low alarm - volt-high-alarm : voltage high alarm - volt-low-alarm : voltage low alarm - temp-high-alarm : temperature high alarm - temp-low-alarm : temperature low alarm - tx-power-high-warn : tx power more than warn range - tx-power-low-warn : tx power less than warn range - rx-power-high-warn : rx power more than warn range - rx-power-low-warn : rx power less than warn range	alarm name that are active <i>This element is only shown in detail mode.</i>

name	Type	Description
	- tx-biascur-high-warn : tx bias current high warn - tx-biascur-low-warn : tx bias current low warn - volt-high-warn : voltage high warn - volt-low-warn : voltage low warn - temp-high-warn : temperature high warn - temp-low-warn : temperature low warn - all : show all SFP RSSI alarm	
severity	Parameter type: <Alarm::AlarmSeverity> (indeterminate warning minor major critical) Possible values: - indeterminate : alarm severity is indeterminate - warning : alarm severity is warning - minor : alarm severity is minor - major : alarm severity is major - critical : alarm severity is critical	the alarms severity level <i>This element is only shown in detail mode.</i>
servaff	Parameter type: <Alarm::alarmServAffect> ((service-affecting yes) (noservice-affecting no)) Possible values: - service-affecting : make this alarm service affecting - yes : make this alarm service affecting - noservice-affecting : make this alarm not service affecting - no : make this alarm not service affecting	alarms affect service or not <i>This element is only shown in detail mode.</i>
time	Parameter type: <Sys::timeInSecs> - the time (yyyy-mm-dd:hour:minutes:secs) - unit: UTC	time in seconds when alarm was updated <i>This element is only shown in detail mode.</i>
descript	Parameter type: <Alarm::AddInfoString> - additional alarm information	alarm description <i>This element is only shown in detail mode.</i>

101.24 show current alarm by filters

Command Description

show current alarms by filters

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm query pppcc-engine-tca [ (name) [ severity <Alarm::querySeverity> ] [ servaff
<Alarm::queryServAffect> ] [ engine <Vlan::StackedVlanSigned> ] ]
```

Command Parameters

Table 101.24-1 "show current alarm by filters" Resource Parameters

Resource Identifier	Type	Description
(name)	Format: (pppce-trans-15min-tca pppce-sess-15min-tca pppce-trans-1day-tca pppce-sess-1day-tca all) Possible values: - pppce-trans-15min-tca : 15 minutes transaction timeout count exceeds configured TCA - pppce-sess-15min-tca : 15 minutes session timeout count exceeds configured TCA - pppce-trans-1day-tca : 1day transaction timeout count exceeds configured TCA - pppce-sess-1day-tca : 1day session timeout count exceeds configured TCA - all : show all PPPOE Cross Connect Engine TCA alarm	alarm name of pppcc-engine-tca
severity	Parameter type: <Alarm::querySeverity> Format: (indeterminate warning minor major critical all) Possible values: - indeterminate : alarm severity is indeterminate - warning : alarm severity is warning - minor : alarm severity is minor	severity level of an alarm for reporting

Resource Identifier	Type	Description
	- major : alarm severity is major - critical : alarm severity is critical - all : all alarm severity	
servaff	Parameter type: <Alarm::queryServAffect> Format: (service-affecting noservice-affecting all) Possible values: - service-affecting : query alarm service affecting - noservice-affecting : query alarm not service affecting - all : query service affecting and not affecting alarms	serviceaffecting no serviceaffecting
engine	Parameter type: <Vlan::StackedVlanSigned> Format: (<Vlan::UVlanIndex> stacked : <Vlan::SVlanIndex> : <Vlan::CVlanIndex>) Possible values: - stacked : stacked vlan identity Field type <Vlan::UVlanIndex> - unstacked vlan identity - range: [1...4093,4096] Field type <Vlan::SVlanIndex> - service vlan identity - range: [2...4093] Field type <Vlan::CVlanIndex> - customer vlan identity - range: [0...4093]	the ppp-cc engine number

Command Output

Table 101.24-2 "show current alarm by filters" Display parameters

Specific Information		
name	Type	Description
aidinfo	Parameter type: <Alarm::AddInfoString> - additional alarm information	alarm AID parameters <i>This element is only shown in detail mode.</i>
type	Parameter type: <Alarm::alarmIHUBType> (equipment eqpt-holder plug-in-unit atm custom e1 ima-group ima-link redundancy shdsl ether-itf traffic-overflow qos-queue temporal spatial (software-mngt sw-mgmt) xdsl xdsl-ext xdsl-tca	type of the alarms that are active <i>This element is only shown in detail mode.</i>

101 query current alarms by filters

name	Type	Description
	olt-gen	
	eo-conv	
	authentication	
	bonding	
	sfp	
	shdsl-isam	
	custom-ext-alarm	
	plug-in-unit-ext	
	sip-user-agent	
	sip-plugin-unit	
	sip-termination	
	e1-sip-termination	
	filetransfer	
	external-device	
	l2forward	
	ether-tca	
	ether-sfp	
	megaco-media-gw	
	megaco-sig-gw	
	megaco-plug-unit	
	megaco-term	
	megaco-sig-lt	
	eqpt-supplemental	
	eqpt-holder-ext	
	lsmredundancy	
	sync	
	mcsrc	
	vlanport	
	vect-line	
	vect-board	
	otdr	
	sip-dial-plan	
	sip-vsp	
	sip-server	
	bgp	
	rip	
	lag	
	ihub-general	
	vprn	
	isis	
	ospf	
	ihub-l2forward	
	vpls	
	ihub-equip	
	ihub-link	
	eont-phyoam	
	ellid	
	epon	
	eont-services-lan	
	eolt-ont-tca	
	eont-sw-dl	
	ldp	
	mpls	
	sdp	
	epipe	
	ihub-ipv6	
	pim	

name	Type	Description
	li	
	mgmt-sec-access	
	bfd	
	ai	
	tr069serv	
	ontsnmp	
	bulk-sync	
	protection-group	
	ont	
	sfu-sup	
	soho-sup	
	mdu-sup	
	ont-ani	
	sfu-sup2	
	soho-sup2	
	mdu-sup2	
	sfprssi	
	eoltrssi	
	cfm	
	sfpe1t1-framer	
	sfpe1t1-clock	
	pppcc-engine-tca	
	eth-cfm	
	rsvp	
	ihub-tca	
	eth-ring	
	efm-oam	
	ont-loopdetect	
	ont-video	
	ont-ces	
	ont-voip	
	ont-video-ani	
	ont-pwe	
	ont-cese1	
	ont-xdsl	
	ont-xdsl-tca	
	ont-hpna	
	ont-sip-agent-cfg	
	ont-voip-cfg	
	ont-mgc	
	ont-ploam	
	ont-gen	
	ont-card	
	ont-pots	
	ont-lan	
	ont-moca	
	ont-tc-tca	
	ont-moca-tca	
	ont-l2uni-eth-tca	
	olt-pon-tc-tca	
	olt-pon-util-tca	
	olt-chpr-util-tca	
	olt-ont-tc-tca	
	ont-tca	
	ont-pots-supplemental	
	sfu-ploam	
	sfu-gen	

101 query current alarms by filters

name	Type	Description
	soho-ploam soho-gen mdu-ploam mdu-gen ont-veip ont-iphost alarm-table auto-switch channel-pair ont-cfg-dld olt-chpair-tc-tca hgu-tr069 eqpt-psu ont-protection secondary-megaco-term secondary-sip-term cas-r2-channel lldpmed pseudo-wire link-agg fcs-exceed e1t1-interface) Possible values: - equipment : equipment alarms - eqpt-holder : equipment holder alarms - plug-in-unit : plugin unit alarms - atm : ATM alarms - custom : customizable alarms - e1 : e1 alarms - ima-group : ima-group alarms - ima-link : ima-link alarms - redundancy : redundancy alarms - shdsl : shdsl alarms - ether-itf : ethernet interface alarms - traffic-overflow : Traffic overflow alarms - qos-queue : qos queue alarms - temporal : temporal alarms - spatial : spatial alarms - software-mngt : software management alarms - sw-mgmt : software management alarms - xdsl : xDSL alarms - xdsl-ext : other xDSL alarms - xdsl-tca : xDSL threshold cross alarms - olt-gen : OLT general alarms - eo-conv : E/O conversion related alarms - authentication : authentication related alarms - bonding : bonding-group related alarms - sfp : SFP related alarms - shdsl-isam : shdsl isam alarms - custom-ext-alarm : customizable external alarms - plug-in-unit-ext : other plugin unit alarms - sip-user-agent : sip user agent related alarms - sip-plugin-unit : sip plug in unit related alarms - sip-termination : sip termination related alarms - e1-sip-termination : E1 sip termination related alarms - filetransfer : file transfer server alarms - external-device : external device related alarms	

name	Type	Description
	- l2forward : l2forward related alarms - ether-tca : ethernet threshold cross alarms - ether-sfp : ethernet SFP related alarms - megaco-media-gw : megaco media gateway related alarms - megaco-sig-gw : megaco signaling gateway related alarms - megaco-plug-unit : megaco plug unit related alarms - megaco-term : megaco termination related alarms - megaco-sig-lt : megaco signaling lt related alarms - eqpt-supplemental : equipment supplemental alarms - eqpt-holder-ext : other equipment holder alarms - lsmredundancy : lsm redundancy alarms - sync : synce and bits alarms - mcsrc : multicast source alarms - vlanport : vlanport alarms - vect-line : xDSL vectoring line alarms - vect-board : xDSL vectoring board alarms - otdr : otdr alarms - sip-dial-plan : sip dial plan related alarms - sip-vsp : sip vsp related alarms - sip-server : sip server related alarms - bgp : bgp related alarms - rip : rip related alarms - lag : LAG related alarms - ihub-general : IHUB general related alarms - vprn : vprn related alarms - isis : isis related alarms - ospf : ospf related alarms - ihub-l2forward : ihub-l2forward alarms - vpls : vpls related alarms - ihub-equip : ihub-equip related alarms - ihub-link : ihub-link related alarms - eont-phyoam : eont phyoam related alarms - ellid : ellid related alarms - epon : epon related alarms - eont-services-lan : eon phyoam related alarms - eolt-ont-tca : eon phyoam related alarms - eont-sw-dl : eon phyoam related alarms - ldp : ldp related alarms - mpls : mpls related alarms - sdp : sdp related alarms - epipe : epipe related alarms - ihub-ipv6 : ihub-ipv6 related alarms - pim : pim related alarms - li : lawful intercept related alarms - mgmt-sec-access : management security related alarms - bfd : bfd related alarms - ai : Application Intelligence related alarms - tr069serv : tr069 server related alarms - ontsnmp : ont snmp related alarms - bulk-sync : bulk-sync related alarms - protection-group : port protection group related alarms - ont : ONT general supplemental related alarms - sfu-sup : SFU ONT general supplemental related alarms - soho-sup : SOHO ONT general supplemental related alarms - mdu-sup : MDU ONT general supplemental related alarms - ont-ani : ONT general supplemental 2 related alarms	

101 query current alarms by filters

name	Type	Description
	- sfu-sup2 : SFU ONT general supplemental 2 related alarms - soho-sup2 : SOHO ONT general supplemental 2 related alarms - mdu-sup2 : MDU ONT general supplemental 2 related alarms - sfprssi : SFP RSSI related alarms - eoltrssi : epon olt Sfp RSSI related alarms - cfm : Cfm related alarms - sfpe1t1-framer : SFP 2e1t1 framer alarms - sfpe1t1-clock : SFP 2e1t1 clock alarms - pppcc-engine-tca : PPPOE Cross Connect Engine TCA related alarm - eth-cfm : eth-cfm related alarms - rsvp : rsvp related alarms - ihub-tca : IHUB TCA related alarms - eth-ring : eth-ring related alarms - efm-oam : EFM-OAM related alarms - ont-loopdetect : ont loop detect related alarms - ont-video : ont services video related alarms - ont-ces : ont services ces related alarms - ont-voip : ont services voip related alarms - ont-video-ani : ont services video ani related alarms - ont-pwe : ont services pwe related alarms - ont-cese1 : ont services cese1 related alarms - ont-xdsl : ont services xdsl related alarms - ont-xdsl-tca : ont services xdsl tca related alarms - ont-hpna : ont hpna related alarms - ont-sip-agent-cfg : ont services voip sip agent config related alarms - ont-voip-cfg : ont services voip config related alarms - ont-mgc : ont mgc related alarms - ont-ploam : ONT PLOAM related alarms - ont-gen : ONT GENERAL related alarms - ont-card : ONT Subscriber Card related alarms - ont-pots : ONT Services POTS related alarms - ont-lan : ONT Services LAN related alarms - ont-moca : ONT MoCA related alarms - ont-tc-tca : ONT TC TCA related alarms - ont-moca-tca : ONT MoCA TCA related alarms - ont-l2uni-eth-tca : ONT L2 UNI Ethernet TCA related alarms - olt-pon-tc-tca : OLT PON TC TCA related alarms - olt-pon-util-tca : OLT PON utilization TCA related alarms - olt-chpr-util-tca : OLT channel-pair utilization TCA related alarms - olt-ont-tc-tca : OLT ONT TC TCA related alarms - ont-tca : ONT TCA related alarms - ont-pots-supplemental : ONT POTS Supplemental related alarms - sfu-ploam : SFU ONT PLOAM related alarms - sfu-gen : SFU ONT general related alarms - soho-ploam : SOHO ONT PLOAM related alarms - soho-gen : SOHO ONT general related alarms - mdu-ploam : MDU ONT PLOAM related alarms - mdu-gen : MDU ONT general related alarms - ont-veip : ONT VEIP related alarms - ont-iphost : ONT IP HOST related alarms	

name	Type	Description
	- alarm-table : alarm table related alarms - auto-switch : auto-switch related alarms - channel-pair : channel pair related alarms - ont-cfg-dld : ont configure file download related alarms - olt-chpair-tc-tca : OLT CHANNELPAIR TC TCA related alarms - hgu-tr069 : hgu tr069 related alarms - eqpt-psu : equipment psu alarms - ont-protection : ONT protection related alarms - secondary-megaco-term : secondary megaco termination related alarms - secondary-sip-term : secondary sip termination related alarms - cas-r2-channel : CAS R2 channel related alarms - lldpmed : lldpmed alarms - pseudo-wire : pseudo Wire related alarms - link-agg : Link aggregation related alarms - fcs-exceed : FCS auto-recovery related alarms - e1t1-interface : E1/T1 physical interfaces related alarms	
name	Parameter type: <Alarm::alarmTypePppccengineTca> (pppce-trans-15min-tca pppce-sess-15min-tca pppce-trans-1day-tca pppce-sess-1day-tca all) Possible values: - pppce-trans-15min-tca : 15 minutes transaction timeout count exceeds configured TCA - pppce-sess-15min-tca : 15 minutes session timeout count exceeds configured TCA - pppce-trans-1day-tca : 1day transaction timeout count exceeds configured TCA - pppce-sess-1day-tca : 1day session timeout count exceeds configured TCA - all : show all PPPOE Cross Connect Engine TCA alarm	alarm name that are active <i>This element is only shown in detail mode.</i>
severity	Parameter type: <Alarm::AlarmSeverity> (indeterminate warning minor major critical) Possible values: - indeterminate : alarm severity is indeterminate - warning : alarm severity is warning - minor : alarm severity is minor - major : alarm severity is major - critical : alarm severity is critical	the alarms severity level <i>This element is only shown in detail mode.</i>
servaff	Parameter type: <Alarm::alarmServAffect> ((service-affecting yes) (noservice-affecting no)) Possible values: - service-affecting : make this alarm service affecting - yes : make this alarm service affecting - noservice-affecting : make this alarm not service affecting - no : make this alarm not service affecting	alarms affect service or not <i>This element is only shown in detail mode.</i>
time	Parameter type: <Sys::timeInSecs> - the time (yyyy-mm-dd:hour:minutes:secs)	time in seconds when alarm was updated

101 query current alarms by filters

name	Type	Description
	- unit: UTC	<i>This element is only shown in detail mode.</i>
descript	Parameter type: <Alarm::AddInfoString> - additional alarm information	alarm description <i>This element is only shown in detail mode.</i>

101.25 show current alarm by filters

Command Description

show current alarms by filters

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm query sfpe1t1-clock [ (name) [ severity <Alarm::querySeverity> ] [ servaff
<Alarm::queryServAffect> ] [ board <Alarm::SlotIndex> ] ]
```

Command Parameters

Table 101.25-1 "show current alarm by filters" Resource Parameters

Resource Identifier	Type	Description
(name)	Format: (dsx1-serdes-fail dsx1-tributary1-fail dsx1-tributary2-fail dsx1-los-fail dsx1-ais-sync dsx1-lof-sync dsx1-los-sync dsx1-deg-fail all) Possible values: - dsx1-serdes-fail : SERDES clock alarm failure - dsx1-tributary1-fail : The tributary 1 clock is not present - dsx1-tributary2-fail : The tributary 2 clock is not present - dsx1-los-fail : All the selected tribs in Loss of Signal - dsx1-ais-sync : Alarm Indication signal on the tributary selected as sync source - dsx1-lof-sync : Loss of Framing on the tributary selected as sync source - dsx1-los-sync : Loss of signal on the tributary selected as sync source - dsx1-deg-fail : Signal degrade Alarm - all : show all SFP 2e1t1 clock alarm	alarm name of sfpe1t1-clock
severity	Parameter type: <Alarm::querySeverity> Format: (indeterminate warning minor	severity level of an alarm for reporting

101 query current alarms by filters

Resource Identifier	Type	Description
	major critical all) Possible values: - indeterminate : alarm severity is indeterminate - warning : alarm severity is warning - minor : alarm severity is minor - major : alarm severity is major - critical : alarm severity is critical - all : all alarm severity	
servaff	Parameter type: <Alarm::queryServAffect> Format: (service-affecting noservice-affecting all) Possible values: - service-affecting : query alarm service affecting - noservice-affecting : query alarm not service affecting - all : query service affecting and not affecting alarms	serviceaffecting no serviceaffecting
board	Parameter type: <Alarm::SlotIndex> Format: (lt : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> nt-a nt-b nt acu : <Eqpt::RackId> / <Eqpt::ShelfId> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::EqSlotId> ext-a : <Eqpt::RackId> / <Eqpt::ShelfId> ext-b : <Eqpt::RackId> / <Eqpt::ShelfId> ctrl : <Eqpt::RackId> / <Eqpt::ShelfId> iont : <Eqpt::RackId> / <Eqpt::ShelfId> lp : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::LtAppliqueSlotId> ntio-1 ntio-2 vlt : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::VirtualSlotId>) Possible values: - lt : lt-slot - vlt : virtual LT slot (VVPS board can only be planned at NANT-E/FANT-F) - nt-a : nt-a slot - nt-b : nt-b slot - nt : nt slot - ext-a : nt-a slot in an extension shelf - ext-b : nt-b slot in an extension shelf - acu : acu slot - ctrl : ctrl-slot - iont : an nt applique slot - lp : an lt applique slot - ntio-1 : an nt applique slot in a single or multiple-ntio-shelf - ntio-2 : an nt applique slot in a multiple-ntio-shelf Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::LtAppliqueSlotId>	the physical number of the slot

Resource Identifier	Type	Description
	- the LT Applique slot number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::VirtualSlotId> - the virtual LT slot number Field type <Eqpt::EqSlotId> - the equipment slot number	

Command Output

Table 101.25-2 "show current alarm by filters" Display parameters

Specific Information		
name	Type	Description
aidinfo	Parameter type: <Alarm::AddInfoString> - additional alarm information	alarm AID parameters <i>This element is only shown in detail mode.</i>
type	Parameter type: <Alarm::alarmIHUBType> (equipment eqpt-holder plug-in-unit atm custom e1 ima-group ima-link redundancy shdsl ether-itf traffic-overflow qos-queue temporal spatial (software-mngt sw-mgmt) xdsl xdsl-ext xdsl-tca olt-gen eo-conv authentication bonding sfp shdsl-isam custom-ext-alarm plug-in-unit-ext sip-user-agent sip-plugin-unit sip-termination e1-sip-termination filetransfer external-device l2forward ether-tca ether-sfp megaco-media-gw megaco-sig-gw megaco-plugin-unit	type of the alarms that are active <i>This element is only shown in detail mode.</i>

101 query current alarms by filters

name	Type	Description
	megaco-term megaco-sig-lt eqpt-supplemental eqpt-holder-ext lsmredundancy sync mcsrc vlanport vect-line vect-board otdr sip-dial-plan sip-vsp sip-server bgp rip lag ihub-general vprn isis ospf ihub-l2forward vpls ihub-equip ihub-link eont-phyoam ellid epon eont-services-lan eolt-ont-tca eont-sw-dl ldp mpls sdp epipe ihub-ipv6 pim li mgmt-sec-access bfd ai tr069serv ontsnmp bulk-sync protection-group ont sfu-sup soho-sup mdu-sup ont-ani sfu-sup2 soho-sup2 mdu-sup2 sfprssi eoltrssi cfm sfpe1t1-framer	

name	Type	Description
	sfpe1t1-clock pppcc-engine-tca eth-cfm rsvp ihub-tca eth-ring efm-oam ont-loopdetect ont-video ont-ces ont-voip ont-video-ani ont-pwe ont-cese1 ont-xdsl ont-xdsl-tca ont-hpna ont-sip-agent-cfg ont-voip-cfg ont-mgc ont-ploam ont-gen ont-card ont-pots ont-lan ont-moca ont-tc-tca ont-moca-tca ont-l2uni-eth-tca olt-pon-tc-tca olt-pon-util-tca olt-chpr-util-tca olt-ont-tc-tca ont-tca ont-pots-supplemental sfu-ploam sfu-gen soho-ploam soho-gen mdu-ploam mdu-gen ont-veip ont-iphost alarm-table auto-switch channel-pair ont-cfg-dld olt-chpair-tc-tca hgu-tr069 eqpt-psu ont-protection secondary-megaco-term secondary-sip-term cas-r2-channel lldpmed pseudo-wire link-agg	

101 query current alarms by filters

name	Type	Description
	fcs-exceed e1t1-interface) Possible values: - equipment : equipment alarms - eqpt-holder : equipment holder alarms - plug-in-unit : plugin unit alarms - atm : ATM alarms - custom : customizable alarms - e1 : e1 alarms - ima-group : ima-group alarms - ima-link : ima-link alarms - redundancy : redundancy alarms - shdsl : shdsl alarms - ether-itf : ethernet interface alarms - traffic-overflow : Traffic overflow alarms - qos-queue : qos queue alarms - temporal : temporal alarms - spatial : spatial alarms - software-mngt : software management alarms - sw-mgmt : software management alarms - xdsl : xDSL alarms - xdsl-ext : other xDSL alarms - xdsl-tca : xDSL threshold cross alarms - olt-gen : OLT general alarms - eo-conv : E/O conversion related alarms - authentication : authentication related alarms - bonding : bonding-group related alarms - sfp : SFP related alarms - shdsl-isam : shdsl isam alarms - custom-ext-alarm : customizable external alarms - plug-in-unit-ext : other plugin unit alarms - sip-user-agent : sip user agent related alarms - sip-plugin-unit : sip plug in unit related alarms - sip-termination : sip termination related alarms - e1-sip-termination : E1 sip termination related alarms - filetransfer : file transfer server alarms - external-device : external device related alarms - l2forward : l2forward related alarms - ether-tca : ethernet threshold cross alarms - ether-sfp : ethernet SFP related alarms - megaco-media-gw : megaco media gateway related alarms - megaco-sig-gw : megaco signaling gateway related alarms - megaco-plug-unit : megaco plug unit related alarms - megaco-term : megaco termination related alarms - megaco-sig-lt : megaco signaling lt related alarms - eqpt-supplemental : equipment supplemental alarms - eqpt-holder-ext : other equipment holder alarms - lsmredundancy : lsm redundancy alarms - sync : synce and bits alarms - mcsrc : multicast source alarms - vlanport : vlanport alarms - vect-line : xDSL vectoring line alarms - vect-board : xDSL vectoring board alarms - otdr : otdr alarms - sip-dial-plan : sip dial plan related alarms - sip-vsp : sip vsp related alarms - sip-server : sip server related alarms	

name	Type	Description
	- bgp : bgp related alarms - rip : rip related alarms - lag : LAG related alarms - ihub-general : IHUB general related alarms - vprn : vprn related alarms - isis : isis related alarms - ospf : ospf related alarms - ihub-l2forward : ihub-l2forward alarms - vpls : vpls related alarms - ihub-equip : ihub-equip related alarms - ihub-link : ihub-link related alarms - eont-phyoam : eont phyoam related alarms - ellid : ellid related alarms - epon : epon related alarms - eont-services-lan : eon phyoam related alarms - eolt-ont-tca : eon phyoam related alarms - eont-sw-dl : eon phyoam related alarms - ldp : ldp related alarms - mpls : mpls related alarms - sdp : sdp related alarms - epipe : epipe related alarms - ihub-ipv6 : ihub-ipv6 related alarms - pim : pim related alarms - li : lawful intercept related alarms - mgmt-sec-access : management security related alarms - bfd : bfd related alarms - ai : Application Intelligence related alarms - tr069serv : tr069 server related alarms - ontsnmp : ont snmp related alarms - bulk-sync : bulk-sync related alarms - protection-group : port protection group related alarms - ont : ONT general supplemental related alarms - sfu-sup : SFU ONT general supplemental related alarms - soho-sup : SOHO ONT general supplemental related alarms - mdu-sup : MDU ONT general supplemental related alarms - ont-ani : ONT general supplemental 2 related alarms - sfu-sup2 : SFU ONT general supplemental 2 related alarms - soho-sup2 : SOHO ONT general supplemental 2 related alarms - mdu-sup2 : MDU ONT general supplemental 2 related alarms - sfprssi : SFP RSSI related alarms - eoltrssi : epon olt Sfp RSSI related alarms - cfm : Cfm related alarms - sfpe1t1-framer : SFP 2e1t1 framer alarms - sfpe1t1-clock : SFP 2e1t1 clock alarms - pppcc-engine-tca : PPPOE Cross Connect Engine TCA related alarm - eth-cfm : eth-cfm related alarms - rsvp : rsvp related alarms - ihub-tca : IHUB TCA related alarms - eth-ring : eth-ring related alarms - efm-oam : EFM-OAM related alarms - ont-loopdetect : ont loop detect related alarms - ont-video : ont services video related alarms - ont-ces : ont services ces related alarms	

101 query current alarms by filters

name	Type	Description
	- ont-voip : ont services voip related alarms - ont-video-ani : ont services video ani related alarms - ont-pwe : ont services pwe related alarms - ont-cese1 : ont services cese1 related alarms - ont-xdsl : ont services xdsl related alarms - ont-xdsl-tca : ont services xdsl tca related alarms - ont-hpna : ont hpna related alarms - ont-sip-agent-cfg : ont services voip sip agent config related alarms - ont-voip-cfg : ont services voip config related alarms - ont-mgc : ont mgc related alarms - ont-ploam : ONT PLOAM related alarms - ont-gen : ONT GENERAL related alarms - ont-card : ONT Subscriber Card related alarms - ont-pots : ONT Services POTS related alarms - ont-lan : ONT Services LAN related alarms - ont-moca : ONT MoCA related alarms - ont-tc-tca : ONT TC TCA related alarms - ont-moca-tca : ONT MoCA TCA related alarms - ont-l2uni-eth-tca : ONT L2 UNI Ethernet TCA related alarms - olt-pon-tc-tca : OLT PON TC TCA related alarms - olt-pon-util-tca : OLT PON utilization TCA related alarms - olt-chpr-util-tca : OLT channel-pair utilization TCA related alarms - olt-ont-tc-tca : OLT ONT TC TCA related alarms - ont-tca : ONT TCA related alarms - ont-pots-supplemental : ONT POTS Supplemental related alarms - sfu-ploam : SFU ONT PLOAM related alarms - sfu-gen : SFU ONT general related alarms - soho-ploam : SOHO ONT PLOAM related alarms - soho-gen : SOHO ONT general related alarms - mdu-ploam : MDU ONT PLOAM related alarms - mdu-gen : MDU ONT general related alarms - ont-veip : ONT VEIP related alarms - ont-iphost : ONT IP HOST related alarms - alarm-table : alarm table related alarms - auto-switch : auto-switch related alarms - channel-pair : channel pair related alarms - ont-cfg-dld : ont configure file download related alarms - olt-chpair-tc-tca : OLT CHANNELPAIR TC TCA related alarms - hgu-tr069 : hgu tr069 related alarms - eqpt-psu : equipment psu alarms - ont-protection : ONT protection related alarms - secondary-megaco-term : secondary megaco termination related alarms - secondary-sip-term : secondary sip termination related alarms - cas-r2-channel : CAS R2 channel related alarms - lldpmed : lldpmed alarms - pseudo-wire : pseudo Wire related alarms - link-agg : Link aggregation related alarms - fcs-exceed : FCS auto-recovery related alarms - e1t1-interface : E1/T1 physical interfaces related alarms	
name	Parameter type: <Alarm::alarmtypeSfpe1t1clock>	alarm name that are active

name	Type	Description
	(dsx1-serdes-fail dsx1-tributary1-fail dsx1-tributary2-fail dsx1-los-fail dsx1-ais-sync dsx1-lof-sync dsx1-los-sync dsx1-deg-fail all) Possible values: - dsx1-serdes-fail : SERDES clock alarm failure - dsx1-tributary1-fail : The tributary 1 clock is not present - dsx1-tributary2-fail : The tributary 2 clock is not present - dsx1-los-fail : All the selected tribs in Loss of Signal - dsx1-ais-sync : Alarm Indication signal on the tributary selected as sync source - dsx1-lof-sync : Loss of Framing on the tributary selected as sync source - dsx1-los-sync : Loss of signal on the tributary selected as sync source - dsx1-deg-fail : Signal degrade Alarm - all : show all SFP 2e1t1 clock alarm	<i>This element is only shown in detail mode.</i>
severity	Parameter type: <Alarm::AlarmSeverity> (indeterminate warning minor major critical) Possible values: - indeterminate : alarm severity is indeterminate - warning : alarm severity is warning - minor : alarm severity is minor - major : alarm severity is major - critical : alarm severity is critical	the alarms severity level <i>This element is only shown in detail mode.</i>
servaff	Parameter type: <Alarm::alarmServAffect> ((service-affecting yes) (noservice-affecting no)) Possible values: - service-affecting : make this alarm service affecting - yes : make this alarm service affecting - noservice-affecting : make this alarm not service affecting - no : make this alarm not service affecting	alarms affect service or not <i>This element is only shown in detail mode.</i>
time	Parameter type: <Sys::timeInSecs> - the time (yyyy-mm-dd:hour:minutes:secs) - unit: UTC	time in seconds when alarm was updated <i>This element is only shown in detail mode.</i>
descript	Parameter type: <Alarm::AddInfoString> - additional alarm information	alarm description <i>This element is only shown in detail mode.</i>

101.26 show current alarm by filters

Command Description

show current alarms by filters

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm query sfpe1t1-framer [ (name) [ severity <Alarm::querySeverity> ] [ servaff
<Alarm::queryServAffect> ] [ board <Alarm::SlotIndex> ] ]
```

Command Parameters

Table 101.26-1 "show current alarm by filters" Resource Parameters

Resource Identifier	Type	Description
(name)	Format: (dsx1-rei-from-liu dsx1-rdi-from-liu dsx1-crc6-from-liu dsx1-crc4-from-liu dsx1-crc4-th-from-liu dsx1-ais-from-liu dsx1-los-from-liu dsx1-lof-from-liu dsx1-lomf-from-liu dsx1-rei-from-iwf dsx1-rdi-from-iwf dsx1-crc6-from-iwf dsx1-crc4-from-iwf dsx1-crc4-th-from-iwf dsx1-ais-from-iwf dsx1-los-from-iwf dsx1-lof-from-iwf dsx1-lomf-from-iwf all) Possible values: - dsx1-rei-from-liu : Remote Error Indication alarm from LIU - dsx1-rdi-from-liu : Remote Defect Alarm from LIU - dsx1-crc6-from-liu : Cyclic Redundancy check-6 alarm from LIU - dsx1-crc4-from-liu : Cyclic Redundancy check-4 alarm from LIU	alarm name of sfpe1t1-framer

Resource Identifier	Type	Description
	- dsx1-crc4-th-from-liu : Cyclic Redundancy check-4 threshold alarm from LIU - dsx1-ais-from-liu : Alarm Indication Signal alarm from LIU - dsx1-los-from-liu : Loss of signal alarm from LIU - dsx1-lof-from-liu : Loss of framing alarm from LIU - dsx1-lomf-from-liu : Loss of Multi-frame alarm from LIU - dsx1-rei-from-iwf : Remote Error Indication alarm from IWF - dsx1-rdi-from-iwf : Remote Defect Alarm from IWF - dsx1-crc6-from-iwf : Cyclic Redundancy check-6 alarm from IWF - dsx1-crc4-from-iwf : Cyclic Redundancy check-4 alarm from IWF - dsx1-crc4-th-from-iwf : Cyclic Redundancy check-4 threshold alarm from IWF - dsx1-ais-from-iwf : Alarm Indication Signal alarm from IWF - dsx1-los-from-iwf : Loss of signal alarm from IWF - dsx1-lof-from-iwf : Loss of framing alarm from IWF - dsx1-lomf-from-iwf : Loss of Multi-frame alarm from IWF - all : show all SFP 2e1t1 framer alarm	
severity	Parameter type: <Alarm::querySeverity> Format: (indeterminate warning minor major critical all) Possible values: - indeterminate : alarm severity is indeterminate - warning : alarm severity is warning - minor : alarm severity is minor - major : alarm severity is major - critical : alarm severity is critical - all : all alarm severity	severity level of an alarm for reporting
servaff	Parameter type: <Alarm::queryServAffect> Format: (service-affecting noservice-affecting all) Possible values: - service-affecting : query alarm service affecting - noservice-affecting : query alarm not service affecting - all : query service affecting and not affecting alarms	serviceaffecting no serviceaffecting
board	Parameter type: <Alarm::SlotIndex> Format: (lt : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> nt-a nt-b nt acu : <Eqpt::RackId> / <Eqpt::ShelfId> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::EqSlotId> ext-a : <Eqpt::RackId> / <Eqpt::ShelfId> ext-b : <Eqpt::RackId> / <Eqpt::ShelfId> ctrl : <Eqpt::RackId> / <Eqpt::ShelfId>	the physical number of the slot

101 query current alarms by filters

Resource Identifier	Type	Description
	iont : <Eqpt::RackId> / <Eqpt::ShelfId> lp : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::LtAppliqueSlotId> ntio-1 ntio-2 vlt : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::VirtualSlotId>) Possible values: - lt : lt-slot - vlt : virtual LT slot (VVPS board can only be planned at NANT-E/FANT-F) - nt-a : nt-a slot - nt-b : nt-b slot - nt : nt slot - ext-a : nt-a slot in an extension shelf - ext-b : nt-b slot in an extension shelf - acu : acu slot - ctrl : ctrl-slot - iont : an nt applique slot - lp : an lt applique slot - ntio-1 : an nt applique slot in a single or multiple-ntio-shelf - ntio-2 : an nt applique slot in a multiple-ntio-shelf Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::LtAppliqueSlotId> - the LT Applique slot number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::VirtualSlotId> - the virtual LT slot number Field type <Eqpt::EqSlotId> - the equipment slot number	

Command Output

Table 101.26-2 "show current alarm by filters" Display parameters

Specific Information		
name	Type	Description
aidinfo	Parameter type: <Alarm::AddInfoString> - additional alarm information	alarm AID parameters <i>This element is only shown in detail mode.</i>
type	Parameter type: <Alarm::alarmIHUBType> (equipment eqpt-holder plug-in-unit atm custom e1 ima-group ima-link redundancy shdsl ether-itf traffic-overflow	type of the alarms that are active <i>This element is only shown in detail mode.</i>

name	Type	Description
	qos-queue temporal spatial (software-mngt sw-mgmt) xdsl xdsl-ext xdsl-tca olt-gen eo-conv authentication bonding sfp shdsl-isam custom-ext-alarm plug-in-unit-ext sip-user-agent sip-plugin-unit sip-termination e1-sip-termination filetransfer external-device l2forward ether-tca ether-sfp megaco-media-gw megaco-sig-gw megaco-plug-unit megaco-term megaco-sig-lt eqpt-supplemental eqpt-holder-ext lsmredundancy sync mcsrc vlanport vect-line vect-board otdr sip-dial-plan sip-vsp sip-server bgp rip lag ihub-general vprn isis ospf ihub-l2forward vpls ihub-equip ihub-link eont-phyoam ellid epon eont-services-lan eolt-ont-tca	

101 query current alarms by filters

name	Type	Description
	eont-sw-dl ldp mpls sdp epipe ihub-ipv6 pim li mgmt-sec-access bfd ai tr069serv ontsnmp bulk-sync protection-group ont sfu-sup soho-sup mdu-sup ont-ani sfu-sup2 soho-sup2 mdu-sup2 sfprssi eoltrssi cfm sfpe1t1-framer sfpe1t1-clock pppcc-engine-tca eth-cfm rsvp ihub-tca eth-ring efm-oam ont-loopdetect ont-video ont-ces ont-voip ont-video-ani ont-pwe ont-cese1 ont-xdsl ont-xdsl-tca ont-hpna ont-sip-agent-cfg ont-voip-cfg ont-mgc ont-ploam ont-gen ont-card ont-pots ont-lan ont-moca ont-tc-tca ont-moca-tca ont-l2uni-eth-tca olt-pon-tc-tca	

name	Type	Description
	olt-pon-util-tca olt-chpr-util-tca olt-ont-tc-tca ont-tca ont-pots-supplemental sfu-ploam sfu-gen soho-ploam soho-gen mdu-ploam mdu-gen ont-veip ont-iphost alarm-table auto-switch channel-pair ont-cfg-dld olt-chpair-tc-tca hgu-tr069 eqpt-psu ont-protection secondary-megaco-term secondary-sip-term cas-r2-channel lldpmed pseudo-wire link-agg fcs-exceed e1t1-interface) Possible values: - equipment : equipment alarms - eqpt-holder : equipment holder alarms - plug-in-unit : plugin unit alarms - atm : ATM alarms - custom : customizable alarms - e1 : e1 alarms - ima-group : ima-group alarms - ima-link : ima-link alarms - redundancy : redundancy alarms - shdsl : shdsl alarms - ether-itf : ethernet interface alarms - traffic-overflow : Traffic overflow alarms - qos-queue : qos queue alarms - temporal : temporal alarms - spatial : spatial alarms - software-mngt : software management alarms - sw-mgmt : software management alarms - xdsl : xDSL alarms - xdsl-ext : other xDSL alarms - xdsl-tca : xDSL threshold cross alarms - olt-gen : OLT general alarms - eo-conv : E/O conversion related alarms - authentication : authentication related alarms - bonding : bonding-group related alarms - sfp : SFP related alarms - shdsl-isam : shdsl isam alarms - custom-ext-alarm : customizable external alarms	

101 query current alarms by filters

name	Type	Description
	- plug-in-unit-ext : other plugin unit alarms - sip-user-agent : sip user agent related alarms - sip-plugin-unit : sip plug in unit related alarms - sip-termination : sip termination related alarms - e1-sip-termination : E1 sip termination related alarms - filetransfer : file transfer server alarms - external-device : external device related alarms - l2forward : l2forward related alarms - ether-tca : ethernet threshold cross alarms - ether-sfp : ethernet SFP related alarms - megaco-media-gw : megaco media gateway related alarms - megaco-sig-gw : megaco signaling gateway related alarms - megaco-plug-unit : megaco plug unit related alarms - megaco-term : megaco termination related alarms - megaco-sig-lt : megaco signaling lt related alarms - eqpt-supplemental : equipment supplemental alarms - eqpt-holder-ext : other equipment holder alarms - lsmredundancy : lsm redundancy alarms - sync : synce and bits alarms - mcsrc : multicast source alarms - vlanport : vlanport alarms - vect-line : xDSL vectoring line alarms - vect-board : xDSL vectoring board alarms - otdr : otdr alarms - sip-dial-plan : sip dial plan related alarms - sip-vsp : sip vsp related alarms - sip-server : sip server related alarms - bgp : bgp related alarms - rip : rip related alarms - lag : LAG related alarms - ihub-general : IHUB general related alarms - vprn : vprn related alarms - isis : isis related alarms - ospf : ospf related alarms - ihub-l2forward : ihub-l2forward alarms - vpls : vpls related alarms - ihub-equip : ihub-equip related alarms - ihub-link : ihub-link related alarms - eont-phyoam : eont phyoam related alarms - ellid : ellid related alarms - epon : epon related alarms - eont-services-lan : eon phyoam related alarms - eolt-ont-tca : eon phyoam related alarms - eont-sw-dl : eon phyoam related alarms - ldp : ldp related alarms - mpls : mpls related alarms - sdp : sdp related alarms - epipe : epipe related alarms - ihub-ipv6 : ihub-ipv6 related alarms - pim : pim related alarms - li : lawful intercept related alarms - mgmt-sec-access : management security related alarms - bfd : bfd related alarms - ai : Application Intelligence related alarms - tr069serv : tr069 server related alarms - ontsnmp : ont snmp related alarms - bulk-sync : bulk-sync related alarms	

name	Type	Description
	- protection-group : port protection group related alarms - ont : ONT general supplemental related alarms - sfu-sup : SFU ONT general supplemental related alarms - soho-sup : SOHO ONT general supplemental related alarms - mdu-sup : MDU ONT general supplemental related alarms - ont-ani : ONT general supplemental 2 related alarms - sfu-sup2 : SFU ONT general supplemental 2 related alarms - soho-sup2 : SOHO ONT general supplemental 2 related alarms - mdu-sup2 : MDU ONT general supplemental 2 related alarms - sfprssi : SFP RSSI related alarms - eoltrssi : epon olt Sfp RSSI related alarms - cfm : Cfm related alarms - sfpe1t1-framer : SFP 2e1t1 framer alarms - sfpe1t1-clock : SFP 2e1t1 clock alarms - pppcc-engine-tca : PPPOE Cross Connect Engine TCA related alarm - eth-cfm : eth-cfm related alarms - rsvp : rsvp related alarms - ihub-tca : IHUB TCA related alarms - eth-ring : eth-ring related alarms - efm-oam : EFM-OAM related alarms - ont-loopdetect : ont loop detect related alarms - ont-video : ont services video related alarms - ont-ces : ont services ces related alarms - ont-voip : ont services voip related alarms - ont-video-ani : ont services video ani related alarms - ont-pwe : ont services pwe related alarms - ont-cese1 : ont services cese1 related alarms - ont-xdsl : ont services xdsl related alarms - ont-xdsl-tca : ont services xdsl tca related alarms - ont-hpna : ont hpna related alarms - ont-sip-agent-cfg : ont services voip sip agent config related alarms - ont-voip-cfg : ont services voip config related alarms - ont-mgc : ont mgc related alarms - ont-ploam : ONT PLOAM related alarms - ont-gen : ONT GENERAL related alarms - ont-card : ONT Subscriber Card related alarms - ont-pots : ONT Services POTS related alarms - ont-lan : ONT Services LAN related alarms - ont-moca : ONT MoCA related alarms - ont-tc-tca : ONT TC TCA related alarms - ont-moca-tca : ONT MoCA TCA related alarms - ont-l2uni-eth-tca : ONT L2 UNI Ethernet TCA related alarms - olt-pon-tc-tca : OLT PON TC TCA related alarms - olt-pon-util-tca : OLT PON utilization TCA related alarms - olt-chpr-util-tca : OLT channel-pair utilization TCA related alarms - olt-ont-tc-tca : OLT ONT TC TCA related alarms - ont-tca : ONT TCA related alarms - ont-pots-supplemental : ONT POTS Supplemental related alarms - sfu-ploam : SFU ONT PLOAM related alarms	

101 query current alarms by filters

name	Type	Description
	- sfu-gen : SFU ONT general related alarms - soho-ploam : SOHO ONT PLOAM related alarms - soho-gen : SOHO ONT general related alarms - mdu-ploam : MDU ONT PLOAM related alarms - mdu-gen : MDU ONT general related alarms - ont-veip : ONT VEIP related alarms - ont-iphost : ONT IP HOST related alarms - alarm-table : alarm table related alarms - auto-switch : auto-switch related alarms - channel-pair : channel pair related alarms - ont-cfg-dld : ont configure file download related alarms - olt-chpair-tc-tca : OLT CHANNELPAIR TC TCA related alarms - hgu-tr069 : hgu tr069 related alarms - eqpt-psu : equipment psu alarms - ont-protection : ONT protection related alarms - secondary-megaco-term : secondary megaco termination related alarms - secondary-sip-term : secondary sip termination related alarms - cas-r2-channel : CAS R2 channel related alarms - lldpmed : lldpmed alarms - pseudo-wire : pseudo Wire related alarms - link-agg : Link aggregation related alarms - fcs-exceed : FCS auto-recovery related alarms - e1t1-interface : E1/T1 physical interfaces related alarms	
name	Parameter type: <Alarm::almtypeSfpe1t1framer> (dsx1-rei-from-liu dsx1-rdi-from-liu dsx1-crc6-from-liu dsx1-crc4-from-liu dsx1-crc4-th-from-liu dsx1-ais-from-liu dsx1-los-from-liu dsx1-lof-from-liu dsx1-lomf-from-liu dsx1-rei-from-iwf dsx1-rdi-from-iwf dsx1-crc6-from-iwf dsx1-crc4-from-iwf dsx1-crc4-th-from-iwf dsx1-ais-from-iwf dsx1-los-from-iwf dsx1-lof-from-iwf dsx1-lomf-from-iwf all) Possible values: - dsx1-rei-from-liu : Remote Error Indication alarm from LIU - dsx1-rdi-from-liu : Remote Defect Alarm from LIU - dsx1-crc6-from-liu : Cyclic Redundancy check-6 alarm from LIU - dsx1-crc4-from-liu : Cyclic Redundancy check-4 alarm from LIU - dsx1-crc4-th-from-liu : Cyclic Redundancy check-4 threshold alarm from LIU - dsx1-ais-from-liu : Alarm Indication Signal alarm from	alarm name that are active <i>This element is only shown in detail mode.</i>

name	Type	Description
	LIU - dsx1-los-from-liu : Loss of signal alarm from LIU - dsx1-lof-from-liu : Loss of framing alarm from LIU - dsx1-lomf-from-liu : Loss of Multi-frame alarm from LIU - dsx1-rei-from-iwf : Remote Error Indication alarm from IWF - dsx1-rdi-from-iwf : Remote Defect Alarm from IWF - dsx1-crc6-from-iwf : Cyclic Redundancy check-6 alarm from IWF - dsx1-crc4-from-iwf : Cyclic Redundancy check-4 alarm from IWF - dsx1-crc4-th-from-iwf : Cyclic Redundancy check-4 threshold alarm from IWF - dsx1-ais-from-iwf : Alarm Indication Signal alarm from IWF - dsx1-los-from-iwf : Loss of signal alarm from IWF - dsx1-lof-from-iwf : Loss of framing alarm from IWF - dsx1-lomf-from-iwf : Loss of Multi-frame alarm from IWF - all : show all SFP 2e1t1 framer alarm	
severity	Parameter type: <Alarm::AlarmSeverity> (indeterminate warning minor major critical) Possible values: - indeterminate : alarm severity is indeterminate - warning : alarm severity is warning - minor : alarm severity is minor - major : alarm severity is major - critical : alarm severity is critical	the alarms severity level <i>This element is only shown in detail mode.</i>
servaff	Parameter type: <Alarm::alarmServAffect> ((service-affecting yes) (noservice-affecting no)) Possible values: - service-affecting : make this alarm service affecting - yes : make this alarm service affecting - noservice-affecting : make this alarm not service affecting - no : make this alarm not service affecting	alarms affect service or not <i>This element is only shown in detail mode.</i>
time	Parameter type: <Sys::timeInSecs> - the time (yyyy-mm-dd:hour:minutes:secs) - unit: UTC	time in seconds when alarm was updated <i>This element is only shown in detail mode.</i>
descript	Parameter type: <Alarm::AddInfoString> - additional alarm information	alarm description <i>This element is only shown in detail mode.</i>

101.27 show current alarm by filters

Command Description

show current alarms by filters

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm query sip-server [ (name) [ severity <Alarm::querySeverity> ] [ servaff <Alarm::queryServAffect> ]
[ server-index <Sip::ServerId> ] ]
```

Command Parameters

Table 101.27-1 "show current alarm by filters" Resource Parameters

Resource Identifier	Type	Description
(name)	Format: (transport-mismatch dns-lookup-failure all) Possible values: - transport-mismatch : Transport protocol mismatch - dns-lookup-failure : Dns look up failure - all : show all sip server alarm	alarm name of sip-server
severity	Parameter type: <Alarm::querySeverity> Format: (indeterminate warning minor major critical all) Possible values: - indeterminate : alarm severity is indeterminate - warning : alarm severity is warning - minor : alarm severity is minor - major : alarm severity is major - critical : alarm severity is critical - all : all alarm severity	severity level of an alarm for reporting
servaff	Parameter type: <Alarm::queryServAffect> Format: (service-affecting noservice-affecting all)	serviceaffecting no

Resource Identifier	Type	Description
	Possible values: - service-affecting : query alarm service affecting - noservice-affecting : query alarm not service affecting - all : query service affecting and not affecting alarms	
server-index	Parameter type: <Sip::ServerId> Format: - the SIP server table index - range: [1...128]	sip server index

Command Output

Table 101.27-2 "show current alarm by filters" Display parameters

Specific Information		
name	Type	Description
aidinfo	Parameter type: <Alarm::AddInfoString> - additional alarm information	alarm AID parameters <i>This element is only shown in detail mode.</i>
type	Parameter type: <Alarm::alarmIHUBType> (equipment eqpt-holder plug-in-unit atm custom e1 ima-group ima-link redundancy shdsl ether-itf traffic-overflow qos-queue temporal spatial (software-mngt sw-mgmt) xdsl xdsl-ext xdsl-tca olt-gen eo-conv authentication bonding sfp shdsl-isam custom-ext-alarm plug-in-unit-ext sip-user-agent sip-plugin-unit sip-termination e1-sip-termination filetransfer external-device l2forward ether-tca ether-sfp megaco-media-gw megaco-sig-gw	type of the alarms that are active <i>This element is only shown in detail mode.</i>

101 query current alarms by filters

name	Type	Description
	megaco-plug-unit megaco-term megaco-sig-lt eqpt-supplemental eqpt-holder-ext lsmredundancy sync mcsrc vlanport vect-line vect-board otdr sip-dial-plan sip-vsp sip-server bgp rip lag ihub-general vprn isis ospf ihub-l2forward vpls ihub-equip ihub-link eont-phyoam ellid epon eont-services-lan eolt-ont-tca eont-sw-dl ldp mpls sdp epipe ihub-ipv6 pim li mgmt-sec-access bfd ai tr069serv ontsnmp bulk-sync protection-group ont sfu-sup soho-sup mdu-sup ont-ani sfu-sup2 soho-sup2 mdu-sup2 sfprssi eoltrssi cfm	

name	Type	Description
	sfpe1t1-framer sfpe1t1-clock pppcc-engine-tca eth-cfm rsvp ihub-tca eth-ring efm-oam ont-loopdetect ont-video ont-ces ont-voip ont-video-ani ont-pwe ont-cese1 ont-xdsl ont-xdsl-tca ont-hpna ont-sip-agent-cfg ont-voip-cfg ont-mgc ont-ploam ont-gen ont-card ont-pots ont-lan ont-moca ont-tc-tca ont-moca-tca ont-l2uni-eth-tca olt-pon-tc-tca olt-pon-util-tca olt-chpr-util-tca olt-ont-tc-tca ont-tca ont-pots-supplemental sfu-ploam sfu-gen soho-ploam soho-gen mdu-ploam mdu-gen ont-veip ont-iphost alarm-table auto-switch channel-pair ont-cfg-dld olt-chpair-tc-tca hgu-tr069 eqpt-psu ont-protection secondary-megaco-term secondary-sip-term cas-r2-channel lldpmed pseudo-wire	

101 query current alarms by filters

name	Type	Description
	link-agg fcs-exceed e1t1-interface) Possible values: - equipment : equipment alarms - eqpt-holder : equipment holder alarms - plug-in-unit : plugin unit alarms - atm : ATM alarms - custom : customizable alarms - e1 : e1 alarms - ima-group : ima-group alarms - ima-link : ima-link alarms - redundancy : redundancy alarms - shdsl : shdsl alarms - ether-itf : ethernet interface alarms - traffic-overflow : Traffic overflow alarms - qos-queue : qos queue alarms - temporal : temporal alarms - spatial : spatial alarms - software-mngt : software management alarms - sw-mgmt : software management alarms - xdsl : xDSL alarms - xdsl-ext : other xDSL alarms - xdsl-tca : xDSL threshold cross alarms - olt-gen : OLT general alarms - eo-conv : E/O conversion related alarms - authentication : authentication related alarms - bonding : bonding-group related alarms - sfp : SFP related alarms - shdsl-isam : shdsl isam alarms - custom-ext-alarm : customizable external alarms - plug-in-unit-ext : other plugin unit alarms - sip-user-agent : sip user agent related alarms - sip-plugin-unit : sip plug in unit related alarms - sip-termination : sip termination related alarms - e1-sip-termination : E1 sip termination related alarms - filetransfer : file transfer server alarms - external-device : external device related alarms - l2forward : l2forward related alarms - ether-tca : ethernet threshold cross alarms - ether-sfp : ethernet SFP related alarms - megaco-media-gw : megaco media gateway related alarms - megaco-sig-gw : megaco signaling gateway related alarms - megaco-plug-unit : megaco plug unit related alarms - megaco-term : megaco termination related alarms - megaco-sig-lt : megaco signaling lt related alarms - eqpt-supplemental : equipment supplemental alarms - eqpt-holder-ext : other equipment holder alarms - lsmredundancy : lsm redundancy alarms - sync : synce and bits alarms - mcsrc : multicast source alarms - vlanport : vlanport alarms - vect-line : xDSL vectoring line alarms - vect-board : xDSL vectoring board alarms - otdr : otdr alarms - sip-dial-plan : sip dial plan related alarms - sip-vsp : sip vsp related alarms	

name	Type	Description
	- sip-server : sip server related alarms - bgp : bgp related alarms - rip : rip related alarms - lag : LAG related alarms - ihub-general : IHUB general related alarms - vprn : vprn related alarms - isis : isis related alarms - ospf : ospf related alarms - ihub-l2forward : ihub-l2forward alarms - vpls : vpls related alarms - ihub-equip : ihub-equip related alarms - ihub-link : ihub-link related alarms - eont-phyoam : eont phyoam related alarms - ellid : ellid related alarms - epon : epon related alarms - eont-services-lan : eon phyoam related alarms - eolt-ont-tca : eon phyoam related alarms - eont-sw-dl : eon phyoam related alarms - ldp : ldp related alarms - mpls : mpls related alarms - sdp : sdp related alarms - epipe : epipe related alarms - ihub-ipv6 : ihub-ipv6 related alarms - pim : pim related alarms - li : lawful intercept related alarms - mgmt-sec-access : management security related alarms - bfd : bfd related alarms - ai : Application Intelligence related alarms - tr069serv : tr069 server related alarms - ontsnmp : ont snmp related alarms - bulk-sync : bulk-sync related alarms - protection-group : port protection group related alarms - ont : ONT general supplemental related alarms - sfu-sup : SFU ONT general supplemental related alarms - soho-sup : SOHO ONT general supplemental related alarms - mdu-sup : MDU ONT general supplemental related alarms - ont-ani : ONT general supplemental 2 related alarms - sfu-sup2 : SFU ONT general supplemental 2 related alarms - soho-sup2 : SOHO ONT general supplemental 2 related alarms - mdu-sup2 : MDU ONT general supplemental 2 related alarms - sfprssi : SFP RSSI related alarms - eoltrssi : epon olt Sfp RSSI related alarms - cfm : Cfm related alarms - sfpe1t1-framer : SFP 2e1t1 framer alarms - sfpe1t1-clock : SFP 2e1t1 clock alarms - pppcc-engine-tca : PPPOE Cross Connect Engine TCA related alarm - eth-cfm : eth-cfm related alarms - rsvp : rsvp related alarms - ihub-tca : IHUB TCA related alarms - eth-ring : eth-ring related alarms - efm-oam : EFM-OAM related alarms - ont-loopdetect : ont loop detect related alarms - ont-video : ont services video related alarms	

101 query current alarms by filters

name	Type	Description
	- ont-ces : ont services ces related alarms - ont-voip : ont services voip related alarms - ont-video-ani : ont services video ani related alarms - ont-pwe : ont services pwe related alarms - ont-cese1 : ont services cese1 related alarms - ont-xdsl : ont services xdsl related alarms - ont-xdsl-tca : ont services xdsl tca related alarms - ont-hpna : ont hpna related alarms - ont-sip-agent-cfg : ont services voip sip agent config related alarms - ont-voip-cfg : ont services voip config related alarms - ont-mgc : ont mgc related alarms - ont-ploam : ONT PLOAM related alarms - ont-gen : ONT GENERAL related alarms - ont-card : ONT Subscriber Card related alarms - ont-pots : ONT Services POTS related alarms - ont-lan : ONT Services LAN related alarms - ont-moca : ONT MoCA related alarms - ont-tc-tca : ONT TC TCA related alarms - ont-moca-tca : ONT MoCA TCA related alarms - ont-l2uni-eth-tca : ONT L2 UNI Ethernet TCA related alarms - olt-pon-tc-tca : OLT PON TC TCA related alarms - olt-pon-util-tca : OLT PON utilization TCA related alarms - olt-chpr-util-tca : OLT channel-pair utilization TCA related alarms - olt-ont-tc-tca : OLT ONT TC TCA related alarms - ont-tca : ONT TCA related alarms - ont-pots-supplemental : ONT POTS Supplemental related alarms - sfu-ploam : SFU ONT PLOAM related alarms - sfu-gen : SFU ONT general related alarms - soho-ploam : SOHO ONT PLOAM related alarms - soho-gen : SOHO ONT general related alarms - mdu-ploam : MDU ONT PLOAM related alarms - mdu-gen : MDU ONT general related alarms - ont-veip : ONT VEIP related alarms - ont-iphost : ONT IP HOST related alarms - alarm-table : alarm table related alarms - auto-switch : auto-switch related alarms - channel-pair : channel pair related alarms - ont-cfg-dld : ont configure file download related alarms - olt-chpair-tc-tca : OLT CHANNELPAIR TC TCA related alarms - hgu-tr069 : hgu tr069 related alarms - eqpt-psu : equipment psu alarms - ont-protection : ONT protection related alarms - secondary-megaco-term : secondary megaco termination related alarms - secondary-sip-term : secondary sip termination related alarms - cas-r2-channel : CAS R2 channel related alarms - lldpmed : lldpmed alarms - pseudo-wire : pseudo Wire related alarms - link-agg : Link aggregation related alarms - fcs-exceed : FCS auto-recovery related alarms - e1t1-interface : E1/T1 physical interfaces related alarms	

name	Type	Description
name	Parameter type: <Alarm::alarmTypeSipserver> (transport-mismatch dns-lookup-failure all) Possible values: - transport-mismatch : Transport protocol mismatch - dns-lookup-failure : Dns look up failure - all : show all sip server alarm	alarm name that are active <i>This element is only shown in detail mode.</i>
severity	Parameter type: <Alarm::AlarmSeverity> (indeterminate warning minor major critical) Possible values: - indeterminate : alarm severity is indeterminate - warning : alarm severity is warning - minor : alarm severity is minor - major : alarm severity is major - critical : alarm severity is critical	the alarms severity level <i>This element is only shown in detail mode.</i>
servaff	Parameter type: <Alarm::alarmServAffect> ((service-affecting yes) (noservice-affecting no)) Possible values: - service-affecting : make this alarm service affecting - yes : make this alarm service affecting - noservice-affecting : make this alarm not service affecting - no : make this alarm not service affecting	alarms affect service or not <i>This element is only shown in detail mode.</i>
time	Parameter type: <Sys::timeInSecs> - the time (yyyy-mm-dd:hour:minutes:secs) - unit: UTC	time in seconds when alarm was updated <i>This element is only shown in detail mode.</i>
descript	Parameter type: <Alarm::AddInfoString> - additional alarm information	alarm description <i>This element is only shown in detail mode.</i>

101.28 show current alarm by filters

Command Description

show current alarms by filters

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm query sip-vsp [ (name) [ severity <Alarm::querySeverity> ] [ servaff <Alarm::queryServAffect> ] [ vsp-index <Sip::DialPlanId> ] ]
```

Command Parameters

Table 101.28-1 "show current alarm by filters" Resource Parameters

Resource Identifier	Type	Description
(name)	Format: (none-dns-srv no-dns-srv none-srv no-srv reg-srv-unreach proxy-srv-unreach all) Possible values: - none-dns-srv : No reply for all DNS serverd - no-dns-srv : No DNS servers configured - none-srv : No reply for all SIP First Hops - no-srv : No SIP First Hop configured - reg-srv-unreach : All SIP register servers are unreachable - proxy-srv-unreach : All SIP proxy servers are unreachable - all : show all sip vsp alarm	alarm name of sip-vsp
severity	Parameter type: <Alarm::querySeverity> Format: (indeterminate warning minor major critical all) Possible values: - indeterminate : alarm severity is indeterminate - warning : alarm severity is warning - minor : alarm severity is minor	severity level of an alarm for reporting

Resource Identifier	Type	Description
	- major : alarm severity is major - critical : alarm severity is critical - all : all alarm severity	
servaff	Parameter type: <Alarm::queryServAffect> Format: (service-affecting noservice-affecting all) Possible values: - service-affecting : query alarm service affecting - noservice-affecting : query alarm not service affecting - all : query service affecting and not affecting alarms	serviceaffecting no serviceaffecting
vsp-index	Parameter type: <Sip::DialPlanId> Format: - the dial plan table index - range: [1...255]	sip vsp index

Command Output

Table 101.28-2 "show current alarm by filters" Display parameters

Specific Information		
name	Type	Description
aidinfo	Parameter type: <Alarm::AddInfoString> - additional alarm information	alarm AID parameters <i>This element is only shown in detail mode.</i>
type	Parameter type: <Alarm::alarmIHUBType> (equipment eqpt-holder plug-in-unit atm custom e1 ima-group ima-link redundancy shdsl ether-itf traffic-overflow qos-queue temporal spatial (software-mngt sw-mgmt) xdsl xdsl-ext xdsl-tca olt-gen eo-conv authentication bonding sfp shdsl-isam custom-ext-alarm plug-in-unit-ext sip-user-agent sip-plugin-unit sip-termination	type of the alarms that are active <i>This element is only shown in detail mode.</i>

101 query current alarms by filters

name	Type	Description
	e1-sip-termination filetransfer external-device l2forward ether-tca ether-sfp megaco-media-gw megaco-sig-gw megaco-plug-unit megaco-term megaco-sig-lt eqpt-supplemental eqpt-holder-ext lsmredundancy sync mcsrc vlanport vect-line vect-board otdr sip-dial-plan sip-vsp sip-server bgp rip lag ihub-general vprn isis ospf ihub-l2forward vpls ihub-equip ihub-link eont-phyoam ellid epon eont-services-lan eolt-ont-tca eont-sw-dl ldp mpls sdp epipe ihub-ipv6 pim li mgmt-sec-access bfd ai tr069serv ontsnmp bulk-sync protection-group ont sfu-sup soho-sup	

name	Type	Description
	mdu-sup ont-ani sfu-sup2 soho-sup2 mdu-sup2 sfprssi eoltrssi cfm sfpe1t1-framer sfpe1t1-clock pppcc-engine-tca eth-cfm rsvp ihub-tca eth-ring efm-oam ont-loopdetect ont-video ont-ces ont-voip ont-video-ani ont-pwe ont-cese1 ont-xdsl ont-xdsl-tca ont-hpna ont-sip-agent-cfg ont-voip-cfg ont-mgc ont-ploam ont-gen ont-card ont-pots ont-lan ont-moca ont-tc-tca ont-moca-tca ont-l2uni-eth-tca olt-pon-tc-tca olt-pon-util-tca olt-chpr-util-tca olt-ont-tc-tca ont-tca ont-pots-supplemental sfu-ploam sfu-gen soho-ploam soho-gen mdu-ploam mdu-gen ont-veip ont-iphost alarm-table auto-switch channel-pair ont-cfg-dld olt-chpair-tc-tca	

101 query current alarms by filters

name	Type	Description
	hgu-tr069 eqpt-psu ont-protection secondary-megaco-term secondary-sip-term cas-r2-channel lldpmed pseudo-wire link-agg fcs-exceed e1t1-interface) Possible values: - equipment : equipment alarms - eqpt-holder : equipment holder alarms - plug-in-unit : plugin unit alarms - atm : ATM alarms - custom : customizable alarms - e1 : e1 alarms - ima-group : ima-group alarms - ima-link : ima-link alarms - redundancy : redundancy alarms - shdsl : shdsl alarms - ether-itf : ethernet interface alarms - traffic-overflow : Traffic overflow alarms - qos-queue : qos queue alarms - temporal : temporal alarms - spatial : spatial alarms - software-mngt : software management alarms - sw-mgmt : software management alarms - xdsl : xDSL alarms - xdsl-ext : other xDSL alarms - xdsl-tca : xDSL threshold cross alarms - olt-gen : OLT general alarms - eo-conv : E/O conversion related alarms - authentication : authentication related alarms - bonding : bonding-group related alarms - sfp : SFP related alarms - shdsl-isam : shdsl isam alarms - custom-ext-alarm : customizable external alarms - plug-in-unit-ext : other plugin unit alarms - sip-user-agent : sip user agent related alarms - sip-plugin-unit : sip plug in unit related alarms - sip-termination : sip termination related alarms - e1-sip-termination : E1 sip termination related alarms - filetransfer : file transfer server alarms - external-device : external device related alarms - l2forward : l2forward related alarms - ether-tca : ethernet threshold cross alarms - ether-sfp : ethernet SFP related alarms - megaco-media-gw : megaco media gateway related alarms - megaco-sig-gw : megaco signaling gateway related alarms - megaco-plug-unit : megaco plug unit related alarms - megaco-term : megaco termination related alarms - megaco-sig-lt : megaco signaling lt related alarms - eqpt-supplemental : equipment supplemental alarms - eqpt-holder-ext : other equipment holder alarms - lsmredundancy : lsm redundancy alarms	

name	Type	Description
	- sync : synce and bits alarms - mcsrc : multicast source alarms - vlanport : vlanport alarms - vect-line : xDSL vectoring line alarms - vect-board : xDSL vectoring board alarms - otdr : otdr alarms - sip-dial-plan : sip dial plan related alarms - sip-vsp : sip vsp related alarms - sip-server : sip server related alarms - bgp : bgp related alarms - rip : rip related alarms - lag : LAG related alarms - ihub-general : IHUB general related alarms - vprn : vprn related alarms - isis : isis related alarms - ospf : ospf related alarms - ihub-l2forward : ihub-l2forward alarms - vpls : vpls related alarms - ihub-equip : ihub-equip related alarms - ihub-link : ihub-link related alarms - eont-phyoam : eont phyoam related alarms - ellid : ellid related alarms - epon : epon related alarms - eont-services-lan : eon phyoam related alarms - eolt-ont-tca : eon phyoam related alarms - eont-sw-dl : eon phyoam related alarms - ldp : ldp related alarms - mpls : mpls related alarms - sdp : sdp related alarms - epipe : epipe related alarms - ihub-ipv6 : ihub-ipv6 related alarms - pim : pim related alarms - li : lawful intercept related alarms - mgmt-sec-access : management security related alarms - bfd : bfd related alarms - ai : Application Intelligence related alarms - tr069serv : tr069 server related alarms - ontsnmp : ont snmp related alarms - bulk-sync : bulk-sync related alarms - protection-group : port protection group related alarms - ont : ONT general supplemental related alarms - sfu-sup : SFU ONT general supplemental related alarms - soho-sup : SOHO ONT general supplemental related alarms - mdv-sup : MDU ONT general supplemental related alarms - ont-ani : ONT general supplemental 2 related alarms - sfu-sup2 : SFU ONT general supplemental 2 related alarms - soho-sup2 : SOHO ONT general supplemental 2 related alarms - mdv-sup2 : MDU ONT general supplemental 2 related alarms - sfprssi : SFP RSSI related alarms - eoltrssi : epon olt Sfp RSSI related alarms - cfm : Cfm related alarms - sfpe1t1-framer : SFP 2e1t1 framer alarms - sfpe1t1-clock : SFP 2e1t1 clock alarms - pppcc-engine-tca : PPPOE Cross Connect Engine TCA	

101 query current alarms by filters

name	Type	Description
	related alarm - eth-cfm : eth-cfm related alarms - rsvp : rsvp related alarms - ihub-tca : IHUB TCA related alarms - eth-ring : eth-ring related alarms - efm-oam : EFM-OAM related alarms - ont-loopdetect : ont loop detect related alarms - ont-video : ont services video related alarms - ont-ces : ont services ces related alarms - ont-voip : ont services voip related alarms - ont-video-ani : ont services video ani related alarms - ont-pwe : ont services pwe related alarms - ont-cese1 : ont services cese1 related alarms - ont-xdsl : ont services xdsl related alarms - ont-xdsl-tca : ont services xdsl tca related alarms - ont-hpna : ont hpna related alarms - ont-sip-agent-cfg : ont services voip sip agent config related alarms - ont-voip-cfg : ont services voip config related alarms - ont-mgc : ont mgc related alarms - ont-ploam : ONT PLOAM related alarms - ont-gen : ONT GENERAL related alarms - ont-card : ONT Subscriber Card related alarms - ont-pots : ONT Services POTS related alarms - ont-lan : ONT Services LAN related alarms - ont-moca : ONT MoCA related alarms - ont-tc-tca : ONT TC TCA related alarms - ont-moca-tca : ONT MoCA TCA related alarms - ont-l2uni-eth-tca : ONT L2 UNI Ethernet TCA related alarms - olt-pon-tc-tca : OLT PON TC TCA related alarms - olt-pon-util-tca : OLT PON utilization TCA related alarms - olt-chpr-util-tca : OLT channel-pair utilization TCA related alarms - olt-ont-tc-tca : OLT ONT TC TCA related alarms - ont-tca : ONT TCA related alarms - ont-pots-supplemental : ONT POTS Supplemental related alarms - sfu-ploam : SFU ONT PLOAM related alarms - sfu-gen : SFU ONT general related alarms - soho-ploam : SOHO ONT PLOAM related alarms - soho-gen : SOHO ONT general related alarms - mdu-ploam : MDU ONT PLOAM related alarms - mdu-gen : MDU ONT general related alarms - ont-veip : ONT VEIP related alarms - ont-iphost : ONT IP HOST related alarms - alarm-table : alarm table related alarms - auto-switch : auto-switch related alarms - channel-pair : channel pair related alarms - ont-cfg-dld : ont configure file download related alarms - olt-chpair-tc-tca : OLT CHANNELPAIR TC TCA related alarms - hgu-tr069 : hgu tr069 related alarms - eqpt-psu : equipment psu alarms - ont-protection : ONT protection related alarms - secondary-megaco-term : secondary megaco termination related alarms	

name	Type	Description
	- secondary-sip-term : secondary sip termination related alarms - cas-r2-channel : CAS R2 channel related alarms - lldpmed : lldpmed alarms - pseudo-wire : pseudo Wire related alarms - link-agg : Link aggregation related alarms - fcs-exceed : FCS auto-recovery related alarms - e1t1-interface : E1/T1 physical interfaces related alarms	
name	Parameter type: <Alarm::almtypeSipvsp> (none-dns-srv no-dns-srv none-srv no-srv reg-srv-unreach proxy-srv-unreach all) Possible values: - none-dns-srv : No reply for all DNS serverd - no-dns-srv : No DNS servers configured - none-srv : No reply for all SIP First Hops - no-srv : No SIP First Hop configured - reg-srv-unreach : All SIP register servers are unreachable - proxy-srv-unreach : All SIP proxy servers are unreachable - all : show all sip vsp alarm	alarm name that are active <i>This element is only shown in detail mode.</i>
severity	Parameter type: <Alarm::AlarmSeverity> (indeterminate warning minor major critical) Possible values: - indeterminate : alarm severity is indeterminate - warning : alarm severity is warning - minor : alarm severity is minor - major : alarm severity is major - critical : alarm severity is critical	the alarms severity level <i>This element is only shown in detail mode.</i>
servaff	Parameter type: <Alarm::alarmServAffect> ((service-affecting yes) (noservice-affecting no)) Possible values: - service-affecting : make this alarm service affecting - yes : make this alarm service affecting - noservice-affecting : make this alarm not service affecting - no : make this alarm not service affecting	alarms affect service or not <i>This element is only shown in detail mode.</i>
time	Parameter type: <Sys::timeInSecs> - the time (yyyy-mm-dd:hour:minutes:secs) - unit: UTC	time in seconds when alarm was updated <i>This element is only shown in detail mode.</i>
descript	Parameter type: <Alarm::AddInfoString> - additional alarm information	alarm description <i>This element is only shown in detail mode.</i>

101.29 show current alarm by filters

Command Description

show current alarms by filters

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm query sip-dial-plan [ (name) [ severity <Alarm::querySeverity> ] [ servaff <Alarm::queryServAffect> ] [ dialplan-index <Sip::DialPlanId> ] ]
```

Command Parameters

Table 101.29-1 "show current alarm by filters" Resource Parameters

Resource Identifier	Type	Description
(name)	Format: (bad-digitmap all) Possible values: - bad-digitmap : Configured digitmap is unusable - all : show all sip dial plan alarm	alarm name of sip-dial-plan
severity	Parameter type: <Alarm::querySeverity> Format: (indeterminate warning minor major critical all) Possible values: - indeterminate : alarm severity is indeterminate - warning : alarm severity is warning - minor : alarm severity is minor - major : alarm severity is major - critical : alarm severity is critical - all : all alarm severity	severity level of an alarm for reporting
servaff	Parameter type: <Alarm::queryServAffect> Format: (service-affecting noservice-affecting all) Possible values: - service-affecting : query alarm service affecting	serviceaffecting no

Resource Identifier	Type	Description
	- noservice-affecting : query alarm not service affecting - all : query service affecting and not affecting alarms	
dialplan-index	Parameter type: <Sip::DialPlanId> Format: - the dial plan table index - range: [1...255]	index of the dial plan

Command Output

Table 101.29-2 "show current alarm by filters" Display parameters

Specific Information		
name	Type	Description
aidinfo	Parameter type: <Alarm::AddInfoString> - additional alarm information	alarm AID parameters <i>This element is only shown in detail mode.</i>
type	Parameter type: <Alarm::alarmIHUBType> (equipment eqpt-holder plug-in-unit atm custom e1 ima-group ima-link redundancy shdsl ether-itf traffic-overflow qos-queue temporal spatial (software-mngt sw-mgmt) xdsl xdsl-ext xdsl-tca olt-gen eo-conv authentication bonding sfp shdsl-isam custom-ext-alarm plug-in-unit-ext sip-user-agent sip-plugin-unit sip-termination e1-sip-termination filetransfer external-device l2forward ether-tca ether-sfp megaco-media-gw megaco-sig-gw megaco-plug-unit megaco-term	type of the alarms that are active <i>This element is only shown in detail mode.</i>

101 query current alarms by filters

name	Type	Description
	megaco-sig-lt	
	eqpt-supplemental	
	eqpt-holder-ext	
	lsmredundancy	
	sync	
	mcsrc	
	vlanport	
	vect-line	
	vect-board	
	otdr	
	sip-dial-plan	
	sip-vsp	
	sip-server	
	bgp	
	rip	
	lag	
	ihub-general	
	vprn	
	isis	
	ospf	
	ihub-l2forward	
	vpls	
	ihub-equip	
	ihub-link	
	eont-phyoam	
	ellid	
	epon	
	eont-services-lan	
	eolt-ont-tca	
	eont-sw-dl	
	ldp	
	mpls	
	sdp	
	epipe	
	ihub-ipv6	
	pim	
	li	
	mgmt-sec-access	
	bfd	
	ai	
	tr069serv	
	ontsnmp	
	bulk-sync	
	protection-group	
	ont	
	sfu-sup	
	soho-sup	
	mdu-sup	
	ont-ani	
	sfu-sup2	
	soho-sup2	
	mdu-sup2	
	sfprssi	
	eoltrssi	
	cfm	
	sfpe1t1-framer	
	sfpe1t1-clock	

name	Type	Description
	pppcc-engine-tca eth-cfm rsvp ihub-tca eth-ring efm-oam ont-loopdetect ont-video ont-ces ont-voip ont-video-ani ont-pwe ont-cese1 ont-xdsl ont-xdsl-tca ont-hpna ont-sip-agent-cfg ont-voip-cfg ont-mgc ont-ploam ont-gen ont-card ont-pots ont-lan ont-moca ont-tc-tca ont-moca-tca ont-l2uni-eth-tca olt-pon-tc-tca olt-pon-util-tca olt-chpr-util-tca olt-ont-tc-tca ont-tca ont-pots-supplemental sfu-ploam sfu-gen soho-ploam soho-gen mdu-ploam mdu-gen ont-veip ont-iphost alarm-table auto-switch channel-pair ont-cfg-dld olt-chpair-tc-tca hgu-tr069 eqpt-psu ont-protection secondary-megaco-term secondary-sip-term cas-r2-channel lldpmed pseudo-wire link-agg fcs-exceed	

101 query current alarms by filters

name	Type	Description
	e1t1-interface) Possible values: - equipment : equipment alarms - eqpt-holder : equipment holder alarms - plug-in-unit : plugin unit alarms - atm : ATM alarms - custom : customizable alarms - e1 : e1 alarms - ima-group : ima-group alarms - ima-link : ima-link alarms - redundancy : redundancy alarms - shdsl : shdsl alarms - ether-itf : ethernet interface alarms - traffic-overflow : Traffic overflow alarms - qos-queue : qos queue alarms - temporal : temporal alarms - spatial : spatial alarms - software-mngt : software management alarms - sw-mgmt : software management alarms - xdsl : xDSL alarms - xdsl-ext : other xDSL alarms - xdsl-tca : xDSL threshold cross alarms - olt-gen : OLT general alarms - eo-conv : E/O conversion related alarms - authentication : authentication related alarms - bonding : bonding-group related alarms - sfp : SFP related alarms - shdsl-isam : shdsl isam alarms - custom-ext-alarm : customizable external alarms - plug-in-unit-ext : other plugin unit alarms - sip-user-agent : sip user agent related alarms - sip-plugin-unit : sip plug in unit related alarms - sip-termination : sip termination related alarms - e1-sip-termination : E1 sip termination related alarms - filetransfer : file transfer server alarms - external-device : external device related alarms - l2forward : l2forward related alarms - ether-tca : ethernet threshold cross alarms - ether-sfp : ethernet SFP related alarms - megaco-media-gw : megaco media gateway related alarms - megaco-sig-gw : megaco signaling gateway related alarms - megaco-plug-unit : megaco plug unit related alarms - megaco-term : megaco termination related alarms - megaco-sig-lt : megaco signaling lt related alarms - eqpt-supplemental : equipment supplemental alarms - eqpt-holder-ext : other equipment holder alarms - lsmredundancy : lsm redundancy alarms - sync : synce and bits alarms - mcsrc : multicast source alarms - vlanport : vlanport alarms - vect-line : xDSL vectoring line alarms - vect-board : xDSL vectoring board alarms - otdr : otdr alarms - sip-dial-plan : sip dial plan related alarms - sip-vsp : sip vsp related alarms - sip-server : sip server related alarms - bgp : bgp related alarms	

name	Type	Description
	- rip : rip related alarms - lag : LAG related alarms - ihub-general : IHUB general related alarms - vprn : vprn related alarms - isis : isis related alarms - ospf : ospf related alarms - ihub-l2forward : ihub-l2forward alarms - vpls : vpls related alarms - ihub-equip : ihub-equip related alarms - ihub-link : ihub-link related alarms - eont-phyoam : eont phyoam related alarms - ellid : ellid related alarms - epon : epon related alarms - eont-services-lan : eon phyoam related alarms - eolt-ont-tca : eon phyoam related alarms - eont-sw-dl : eon phyoam related alarms - ldp : ldp related alarms - mpls : mpls related alarms - sdp : sdp related alarms - epipe : epipe related alarms - ihub-ipv6 : ihub-ipv6 related alarms - pim : pim related alarms - li : lawful intercept related alarms - mgmt-sec-access : management security related alarms - bfd : bfd related alarms - ai : Application Intelligence related alarms - tr069serv : tr069 server related alarms - ontsnmp : ont snmp related alarms - bulk-sync : bulk-sync related alarms - protection-group : port protection group related alarms - ont : ONT general supplemental related alarms - sfu-sup : SFU ONT general supplemental related alarms - soho-sup : SOHO ONT general supplemental related alarms - mdu-sup : MDU ONT general supplemental related alarms - ont-ani : ONT general supplemental 2 related alarms - sfu-sup2 : SFU ONT general supplemental 2 related alarms - soho-sup2 : SOHO ONT general supplemental 2 related alarms - mdu-sup2 : MDU ONT general supplemental 2 related alarms - sfrssi : SFP RSSI related alarms - eoltrssi : epon olt Sfp RSSI related alarms - cfm : Cfm related alarms - sfpe1t1-framer : SFP 2e1t1 framer alarms - sfpe1t1-clock : SFP 2e1t1 clock alarms - pppcc-engine-tca : PPPOE Cross Connect Engine TCA related alarm - eth-cfm : eth-cfm related alarms - rsvp : rsvp related alarms - ihub-tca : IHUB TCA related alarms - eth-ring : eth-ring related alarms - efm-oam : EFM-OAM related alarms - ont-loopdetect : ont loop detect related alarms - ont-video : ont services video related alarms - ont-ces : ont services ces related alarms - ont-voip : ont services voip related alarms	

101 query current alarms by filters

name	Type	Description
	- ont-video-ani : ont services video ani related alarms - ont-pwe : ont services pwe related alarms - ont-cese1 : ont services cese1 related alarms - ont-xdsl : ont services xdsl related alarms - ont-xdsl-tca : ont services xdsl tca related alarms - ont-hpna : ont hpna related alarms - ont-sip-agent-cfg : ont services voip sip agent config related alarms - ont-voip-cfg : ont services voip config related alarms - ont-mgc : ont mgc related alarms - ont-ploam : ONT PLOAM related alarms - ont-gen : ONT GENERAL related alarms - ont-card : ONT Subscriber Card related alarms - ont-pots : ONT Services POTS related alarms - ont-lan : ONT Services LAN related alarms - ont-moca : ONT MoCA related alarms - ont-tc-tca : ONT TC TCA related alarms - ont-moca-tca : ONT MoCA TCA related alarms - ont-l2uni-eth-tca : ONT L2 UNI Ethernet TCA related alarms - olt-pon-tc-tca : OLT PON TC TCA related alarms - olt-pon-util-tca : OLT PON utilization TCA related alarms - olt-chpr-util-tca : OLT channel-pair utilization TCA related alarms - olt-ont-tc-tca : OLT ONT TC TCA related alarms - ont-tca : ONT TCA related alarms - ont-pots-supplemental : ONT POTS Supplemental related alarms - sfu-ploam : SFU ONT PLOAM related alarms - sfu-gen : SFU ONT general related alarms - soho-ploam : SOHO ONT PLOAM related alarms - soho-gen : SOHO ONT general related alarms - mdu-ploam : MDU ONT PLOAM related alarms - mdu-gen : MDU ONT general related alarms - ont-veip : ONT VEIP related alarms - ont-iphost : ONT IP HOST related alarms - alarm-table : alarm table related alarms - auto-switch : auto-switch related alarms - channel-pair : channel pair related alarms - ont-cfg-dld : ont configure file download related alarms - olt-chpair-tc-tca : OLT CHANNELPAIR TC TCA related alarms - hgu-tr069 : hgu tr069 related alarms - eqpt-psu : equipment psu alarms - ont-protection : ONT protection related alarms - secondary-megaco-term : secondary megaco termination related alarms - secondary-sip-term : secondary sip termination related alarms - cas-r2-channel : CAS R2 channel related alarms - lldpmed : lldpmed alarms - pseudo-wire : pseudo Wire related alarms - link-agg : Link aggregation related alarms - fcs-exceed : FCS auto-recovery related alarms - e1t1-interface : E1/T1 physical interfaces related alarms	
name	Parameter type: <Alarm::alarmTypeSipdialplan> (bad-digitmap	alarm name that are active <i>This element is only shown in</i>

name	Type	Description
	all) Possible values: - bad-digitmap : Configured digitmap is unusable - all : show all sip dial plan alarm	detail mode.
severity	Parameter type: <Alarm::AlarmSeverity> (indeterminate warning minor major critical) Possible values: - indeterminate : alarm severity is indeterminate - warning : alarm severity is warning - minor : alarm severity is minor - major : alarm severity is major - critical : alarm severity is critical	the alarms severity level <i>This element is only shown in detail mode.</i>
servaff	Parameter type: <Alarm::alarmServAffect> ((service-affecting yes) (noservice-affecting no)) Possible values: - service-affecting : make this alarm service affecting - yes : make this alarm service affecting - noservice-affecting : make this alarm not service affecting - no : make this alarm not service affecting	alarms affect service or not <i>This element is only shown in detail mode.</i>
time	Parameter type: <Sys::timeInSecs> - the time (yyyy-mm-dd:hour:minutes:secs) - unit: UTC	time in seconds when alarm was updated <i>This element is only shown in detail mode.</i>
descript	Parameter type: <Alarm::AddInfoString> - additional alarm information	alarm description <i>This element is only shown in detail mode.</i>

101.30 show current alarm by filters

Command Description

show current alarms by filters

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm query sip-user-agent [ (name) [ severity <Alarm::querySeverity> ] [ servaff
<Alarm::queryServAffect> ] [ board <Equipm::EqptSlotIndex> ] ]
```

Command Parameters

Table 101.30-1 "show current alarm by filters" Resource Parameters

Resource Identifier	Type	Description
(name)	Format: (dhcp-unreach dhcp-no-srv dhcp-inv-srv all) Possible values: - dhcp-unreach : The DHCP server is unreachable - dhcp-no-srv : The address in DHCP reply is NULL - dhcp-inv-srv : The address in DHCP reply is invalid - all : show all sip user agent alarm	alarm name of sip-user-agent
severity	Parameter type: <Alarm::querySeverity> Format: (indeterminate warning minor major critical all) Possible values: - indeterminate : alarm severity is indeterminate - warning : alarm severity is warning - minor : alarm severity is minor - major : alarm severity is major - critical : alarm severity is critical - all : all alarm severity	severity level of an alarm for reporting
servaff	Parameter type: <Alarm::queryServAffect> Format: (service-affecting	serviceaffecting no

Resource Identifier	Type	Description
	noservice-affecting all) Possible values: - service-affecting : query alarm service affecting - noservice-affecting : query alarm not service affecting - all : query service affecting and not affecting alarms	
board	Parameter type: <Equipm::EqptSlotIndex> Format: (lt : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> nt-a nt-b nt acu : <Eqpt::RackId> / <Eqpt::ShelfId> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::EqSlotId> ext-a : <Eqpt::RackId> / <Eqpt::ShelfId> ext-b : <Eqpt::RackId> / <Eqpt::ShelfId> ctrl : <Eqpt::RackId> / <Eqpt::ShelfId> vlt : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::VirtualSlotId>) Possible values: - lt : lt-slot - vlt : virtual LT slot (VVPS board can only be planned at NANT-E / FANT-F) - nt-a : nt-a slot - nt-b : nt-b slot - nt : nt slot - ext-a : nt-a slot in an extension shelf - ext-b : nt-b slot in an extension shelf - acu : acu slot - ctrl : ctrl-slot Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::VirtualSlotId> - the virtual LT slot number Field type <Eqpt::EqSlotId> - the equipment slot number	the physical number of the slot

Command Output

Table 101.30-2 "show current alarm by filters" Display parameters

Specific Information		
name	Type	Description
aidinfo	Parameter type: <Alarm::AddInfoString> - additional alarm information	alarm AID parameters <i>This element is only shown in detail mode.</i>
type	Parameter type: <Alarm::alarmIHUBType> (equipment eqpt-holder plug-in-unit atm custom el	type of the alarms that are active <i>This element is only shown in detail mode.</i>

101 query current alarms by filters

name	Type	Description
	ima-group ima-link redundancy shdsl ether-itf traffic-overflow qos-queue temporal spatial (software-mngt sw-mgmt) xdsl xdsl-ext xdsl-tca olt-gen eo-conv authentication bonding sfp shdsl-isam custom-ext-alarm plug-in-unit-ext sip-user-agent sip-plugin-unit sip-termination e1-sip-termination filetransfer external-device l2forward ether-tca ether-sfp megaco-media-gw megaco-sig-gw megaco-plug-unit megaco-term megaco-sig-lt eqpt-supplemental eqpt-holder-ext lsmredundancy sync mcsrc vlanport vect-line vect-board otdr sip-dial-plan sip-vsp sip-server bgp rip lag ihub-general vprn isis ospf ihub-l2forward vpls ihub-equip	

name	Type	Description
	ihub-link	
	eont-phyoam	
	ellid	
	epon	
	eont-services-lan	
	eolt-ont-tca	
	eont-sw-dl	
	ldp	
	mpls	
	sdp	
	epipe	
	ihub-ipv6	
	pim	
	li	
	mgmt-sec-access	
	bfd	
	ai	
	tr069serv	
	ontsnmp	
	bulk-sync	
	protection-group	
	ont	
	sfu-sup	
	soho-sup	
	mdu-sup	
	ont-ani	
	sfu-sup2	
	soho-sup2	
	mdu-sup2	
	sfprssi	
	eoltrssi	
	cfm	
	sfpe1t1-framer	
	sfpe1t1-clock	
	pppcc-engine-tca	
	eth-cfm	
	rsvp	
	ihub-tca	
	eth-ring	
	efm-oam	
	ont-loopdetect	
	ont-video	
	ont-ces	
	ont-voip	
	ont-video-ani	
	ont-pwe	
	ont-cese1	
	ont-xdsl	
	ont-xdsl-tca	
	ont-hpna	
	ont-sip-agent-cfg	
	ont-voip-cfg	
	ont-mgc	
	ont-ploam	
	ont-gen	
	ont-card	
	ont-pots	

101 query current alarms by filters

name	Type	Description
	ont-lan ont-moca ont-tc-tca ont-moca-tca ont-l2uni-eth-tca olt-pon-tc-tca olt-pon-util-tca olt-chpr-util-tca olt-ont-tc-tca ont-tca ont-pots-supplemental sfu-ploam sfu-gen soho-ploam soho-gen mdu-ploam mdu-gen ont-veip ont-iphost alarm-table auto-switch channel-pair ont-cfg-dld olt-chpair-tc-tca hgu-tr069 eqpt-psu ont-protection secondary-megaco-term secondary-sip-term cas-r2-channel lldpmed pseudo-wire link-agg fcs-exceed e1t1-interface) Possible values: - equipment : equipment alarms - eqpt-holder : equipment holder alarms - plug-in-unit : plugin unit alarms - atm : ATM alarms - custom : customizable alarms - e1 : e1 alarms - ima-group : ima-group alarms - ima-link : ima-link alarms - redundancy : redundancy alarms - shdsl : shdsl alarms - ether-itf : ethernet interface alarms - traffic-overflow : Traffic overflow alarms - qos-queue : qos queue alarms - temporal : temporal alarms - spatial : spatial alarms - software-mngt : software management alarms - sw-mgmt : software management alarms - xdsl : xDSL alarms - xdsl-ext : other xDSL alarms - xdsl-tca : xDSL threshold cross alarms - olt-gen : OLT general alarms	

name	Type	Description
	- eo-conv : E/O conversion related alarms - authentication : authentication related alarms - bonding : bonding-group related alarms - sfp : SFP related alarms - shdsl-isam : shdsl isam alarms - custom-ext-alarm : customizable external alarms - plug-in-unit-ext : other plugin unit alarms - sip-user-agent : sip user agent related alarms - sip-plugin-unit : sip plug in unit related alarms - sip-termination : sip termination related alarms - e1-sip-termination : E1 sip termination related alarms - filetransfer : file transfer server alarms - external-device : external device related alarms - l2forward : l2forward related alarms - ether-tca : ethernet threshold cross alarms - ether-sfp : ethernet SFP related alarms - megaco-media-gw : megaco media gateway related alarms - megaco-sig-gw : megaco signaling gateway related alarms - megaco-plug-unit : megaco plug unit related alarms - megaco-term : megaco termination related alarms - megaco-sig-lt : megaco signaling lt related alarms - eqpt-supplemental : equipment supplemental alarms - eqpt-holder-ext : other equipment holder alarms - lsmredundancy : lsm redundancy alarms - sync : synce and bits alarms - mcsrc : multicast source alarms - vlanport : vlanport alarms - vect-line : xDSL vectoring line alarms - vect-board : xDSL vectoring board alarms - otdr : otdr alarms - sip-dial-plan : sip dial plan related alarms - sip-vsp : sip vsp related alarms - sip-server : sip server related alarms - bgp : bgp related alarms - rip : rip related alarms - lag : LAG related alarms - ihub-general : IHUB general related alarms - vprn : vprn related alarms - isis : isis related alarms - ospf : ospf related alarms - ihub-l2forward : ihub-l2forward alarms - vpls : vpls related alarms - ihub-equip : ihub-equip related alarms - ihub-link : ihub-link related alarms - eont-phyoam : eont phyoam related alarms - ellid : ellid related alarms - epon : epon related alarms - eont-services-lan : eon phyoam related alarms - eolt-ont-tca : eon phyoam related alarms - eont-sw-dl : eon phyoam related alarms - ldp : ldp related alarms - mpls : mpls related alarms - sdp : sdp related alarms - epipe : epipe related alarms - ihub-ipv6 : ihub-ipv6 related alarms - pim : pim related alarms - li : lawful intercept related alarms	

101 query current alarms by filters

name	Type	Description
	- mgmt-sec-access : management security related alarms - bfd : bfd related alarms - ai : Application Intelligence related alarms - tr069serv : tr069 server related alarms - ontsnmp : ont snmp related alarms - bulk-sync : bulk-sync related alarms - protection-group : port protection group related alarms - ont : ONT general supplemental related alarms - sfu-sup : SFU ONT general supplemental related alarms - soho-sup : SOHO ONT general supplemental related alarms - mdu-sup : MDU ONT general supplemental related alarms - ont-ani : ONT general supplemental 2 related alarms - sfu-sup2 : SFU ONT general supplemental 2 related alarms - soho-sup2 : SOHO ONT general supplemental 2 related alarms - mdu-sup2 : MDU ONT general supplemental 2 related alarms - sfprssi : SFP RSSI related alarms - eoltrssi : epon olt Sfp RSSI related alarms - cfm : Cfm related alarms - sfpe1t1-framer : SFP 2e1t1 framer alarms - sfpe1t1-clock : SFP 2e1t1 clock alarms - pppcc-engine-tca : PPPOE Cross Connect Engine TCA related alarm - eth-cfm : eth-cfm related alarms - rsvp : rsvp related alarms - ihub-tca : IHUB TCA related alarms - eth-ring : eth-ring related alarms - efm-oam : EFM-OAM related alarms - ont-loopdetect : ont loop detect related alarms - ont-video : ont services video related alarms - ont-ces : ont services ces related alarms - ont-voip : ont services voip related alarms - ont-video-ani : ont services video ani related alarms - ont-pwe : ont services pwe related alarms - ont-cese1 : ont services cese1 related alarms - ont-xdsl : ont services xdsl related alarms - ont-xdsl-tca : ont services xdsl tca related alarms - ont-hpna : ont hpna related alarms - ont-sip-agent-cfg : ont services voip sip agent config related alarms - ont-voip-cfg : ont services voip config related alarms - ont-mgc : ont mgc related alarms - ont-ploam : ONT PLOAM related alarms - ont-gen : ONT GENERAL related alarms - ont-card : ONT Subscriber Card related alarms - ont-pots : ONT Services POTS related alarms - ont-lan : ONT Services LAN related alarms - ont-moca : ONT MoCA related alarms - ont-tc-tca : ONT TC TCA related alarms - ont-moca-tca : ONT MoCA TCA related alarms - ont-l2uni-eth-tca : ONT L2 UNI Ethernet TCA related alarms - olt-pon-tc-tca : OLT PON TC TCA related alarms - olt-pon-util-tca : OLT PON utilization TCA related alarms - olt-chpr-util-tca : OLT channel-pair utilization TCA related	

name	Type	Description
	alarms - olt-ont-tc-tca : OLT ONT TC TCA related alarms - ont-tca : ONT TCA related alarms - ont-pots-supplemental : ONT POTS Supplemental related alarms - sfu-ploam : SFU ONT PLOAM related alarms - sfu-gen : SFU ONT general related alarms - soho-ploam : SOHO ONT PLOAM related alarms - soho-gen : SOHO ONT general related alarms - mdv-ploam : MDU ONT PLOAM related alarms - mdv-gen : MDU ONT general related alarms - ont-veip : ONT VEIP related alarms - ont-iphost : ONT IP HOST related alarms - alarm-table : alarm table related alarms - auto-switch : auto-switch related alarms - channel-pair : channel pair related alarms - ont-cfg-dld : ont configure file download related alarms - olt-chpair-tc-tca : OLT CHANNELPAIR TC TCA related alarms - hgu-tr069 : hgu tr069 related alarms - eqpt-psu : equipment psu alarms - ont-protection : ONT protection related alarms - secondary-megaco-term : secondary megaco termination related alarms - secondary-sip-term : secondary sip termination related alarms - cas-r2-channel : CAS R2 channel related alarms - lldpmed : lldpmed alarms - pseudo-wire : pseudo Wire related alarms - link-agg : Link aggregation related alarms - fcs-exceed : FCS auto-recovery related alarms - e1t1-interface : E1/T1 physical interfaces related alarms	
name	Parameter type: <Alarm::almTypesSipuseragent> (dhcp-unreach dhcp-no-srv dhcp-inv-srv all) Possible values: - dhcp-unreach : The DHCP server is unreachable - dhcp-no-srv : The address in DHCP reply is NULL - dhcp-inv-srv : The address in DHCP reply is invalid - all : show all sip user agent alarm	alarm name that are active <i>This element is only shown in detail mode.</i>
severity	Parameter type: <Alarm::AlarmSeverity> (indeterminate warning minor major critical) Possible values: - indeterminate : alarm severity is indeterminate - warning : alarm severity is warning - minor : alarm severity is minor - major : alarm severity is major - critical : alarm severity is critical	the alarms severity level <i>This element is only shown in detail mode.</i>
servaff	Parameter type: <Alarm::alarmServAffect> ((service-affecting yes) (noservice-affecting no))	alarms affect service or not <i>This element is only shown in detail mode.</i>

101 query current alarms by filters

name	Type	Description
	Possible values: - service-affecting : make this alarm service affecting - yes : make this alarm service affecting - noservice-affecting : make this alarm not service affecting - no : make this alarm not service affecting	
time	Parameter type: <Sys::timeInSecs> - the time (yyyy-mm-dd:hour:minutes:secs) - unit: UTC	time in seconds when alarm was updated <i>This element is only shown in detail mode.</i>
descript	Parameter type: <Alarm::AddInfoString> - additional alarm information	alarm description <i>This element is only shown in detail mode.</i>

101.31 show current alarm by filters

Command Description

show current alarms by filters

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm query sip-plugin-unit [ (name) [ severity <Alarm::querySeverity> ] [ servaff
<Alarm::queryServAffect> ] [ board <Equipm::EqptSlotIndex> ] ]
```

Command Parameters

Table 101.31-1 "show current alarm by filters" Resource Parameters

Resource Identifier	Type	Description
(name)	Format: (norpniewwithsoftdsp all) Possible values: - norpniewwithsoftdsp : do not plan / plug-in RPNI-E board with SoftDsp SW image - all : show all sip plug in unit alarm	alarm name of sip-plugin-unit
severity	Parameter type: <Alarm::querySeverity> Format: (indeterminate warning minor major critical all) Possible values: - indeterminate : alarm severity is indeterminate - warning : alarm severity is warning - minor : alarm severity is minor - major : alarm severity is major - critical : alarm severity is critical - all : all alarm severity	severity level of an alarm for reporting
servaff	Parameter type: <Alarm::queryServAffect> Format: (service-affecting noservice-affecting all) Possible values:	serviceaffecting no

101 query current alarms by filters

Resource Identifier	Type	Description
	- service-affecting : query alarm service affecting - noservice-affecting : query alarm not service affecting - all : query service affecting and not affecting alarms	
board	Parameter type: <Equipm::EqptSlotIndex> Format: (lt : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> nt-a nt-b nt acu : <Eqpt::RackId> / <Eqpt::ShelfId> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::EqSlotId> ext-a : <Eqpt::RackId> / <Eqpt::ShelfId> ext-b : <Eqpt::RackId> / <Eqpt::ShelfId> ctrl : <Eqpt::RackId> / <Eqpt::ShelfId> vlt : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::VirtualSlotId>) Possible values: - lt : lt-slot - vlt : virtual LT slot (VVPS board can only be planned at NANT-E / FANT-F) - nt-a : nt-a slot - nt-b : nt-b slot - nt : nt slot - ext-a : nt-a slot in an extension shelf - ext-b : nt-b slot in an extension shelf - acu : acu slot - ctrl : ctrl-slot Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::VirtualSlotId> - the virtual LT slot number Field type <Eqpt::EqSlotId> - the equipment slot number	the physical number of the slot

Command Output

Table 101.31-2 "show current alarm by filters" Display parameters

Specific Information		
name	Type	Description
aidinfo	Parameter type: <Alarm::AddInfoString> - additional alarm information	alarm AID parameters <i>This element is only shown in detail mode.</i>
type	Parameter type: <Alarm::alarmIHUBType> (equipment eqpt-holder plug-in-unit atm custom e1 ima-group ima-link redundancy	type of the alarms that are active <i>This element is only shown in detail mode.</i>

name	Type	Description
	shdsl	
	ether-itf	
	traffic-overflow	
	qos-queue	
	temporal	
	spatial	
	(software-mngt sw-mgmt)	
	xdsl	
	xdsl-ext	
	xdsl-tca	
	olt-gen	
	eo-conv	
	authentication	
	bonding	
	sfp	
	shdsl-isam	
	custom-ext-alarm	
	plug-in-unit-ext	
	sip-user-agent	
	sip-plugin-unit	
	sip-termination	
	e1-sip-termination	
	filetransfer	
	external-device	
	l2forward	
	ether-tca	
	ether-sfp	
	megaco-media-gw	
	megaco-sig-gw	
	megaco-plug-unit	
	megaco-term	
	megaco-sig-lt	
	eqpt-supplemental	
	eqpt-holder-ext	
	lsmredundancy	
	sync	
	mcsrc	
	vlanport	
	vect-line	
	vect-board	
	otdr	
	sip-dial-plan	
	sip-vsp	
	sip-server	
	bgp	
	rip	
	lag	
	ihub-general	
	vprn	
	isis	
	ospf	
	ihub-l2forward	
	vpls	
	ihub-equip	
	ihub-link	
	eont-phyoam	
	ellid	

101 query current alarms by filters

name	Type	Description
	epon eont-services-lan eolt-ont-tca eont-sw-dl ldp mpls sdp epipe ihub-ipv6 pim li mgmt-sec-access bfd ai tr069serv ontsnmp bulk-sync protection-group ont sfu-sup soho-sup mdu-sup ont-ani sfu-sup2 soho-sup2 mdu-sup2 sfprssi eoltrssi cfm sfpe1t1-framer sfpe1t1-clock pppcc-engine-tca eth-cfm rsvp ihub-tca eth-ring efm-oam ont-loopdetect ont-video ont-ces ont-voip ont-video-ani ont-pwe ont-cese1 ont-xdsl ont-xdsl-tca ont-hpna ont-sip-agent-cfg ont-voip-cfg ont-mgc ont-ploam ont-gen ont-card ont-pots ont-lan ont-moca ont-tc-tca	

name	Type	Description
	ont-moca-tca ont-l2uni-eth-tca olt-pon-tc-tca olt-pon-util-tca olt-chpr-util-tca olt-ont-tc-tca ont-tca ont-pots-supplemental sfu-ploam sfu-gen soho-ploam soho-gen mdu-ploam mdu-gen ont-veip ont-iphost alarm-table auto-switch channel-pair ont-cfg-dld olt-chpair-tc-tca hgu-tr069 eqpt-psu ont-protection secondary-megaco-term secondary-sip-term cas-r2-channel lldpmed pseudo-wire link-agg fcs-exceed e1t1-interface) Possible values: - equipment : equipment alarms - eqpt-holder : equipment holder alarms - plug-in-unit : plugin unit alarms - atm : ATM alarms - custom : customizable alarms - e1 : e1 alarms - ima-group : ima-group alarms - ima-link : ima-link alarms - redundancy : redundancy alarms - shdsl : shdsl alarms - ether-itf : ethernet interface alarms - traffic-overflow : Traffic overflow alarms - qos-queue : qos queue alarms - temporal : temporal alarms - spatial : spatial alarms - software-mngt : software management alarms - sw-mgmt : software management alarms - xdsl : xDSL alarms - xdsl-ext : other xDSL alarms - xdsl-tca : xDSL threshold cross alarms - olt-gen : OLT general alarms - eo-conv : E/O conversion related alarms - authentication : authentication related alarms - bonding : bonding-group related alarms	

101 query current alarms by filters

name	Type	Description
	- sfp : SFP related alarms - shdsl-isam : shdsl isam alarms - custom-ext-alarm : customizable external alarms - plug-in-unit-ext : other plugin unit alarms - sip-user-agent : sip user agent related alarms - sip-plugin-unit : sip plug in unit related alarms - sip-termination : sip termination related alarms - e1-sip-termination : E1 sip termination related alarms - filetransfer : file transfer server alarms - external-device : external device related alarms - l2forward : l2forward related alarms - ether-tca : ethernet threshold cross alarms - ether-sfp : ethernet SFP related alarms - megaco-media-gw : megaco media gateway related alarms - megaco-sig-gw : megaco signaling gateway related alarms - megaco-plug-unit : megaco plug unit related alarms - megaco-term : megaco termination related alarms - megaco-sig-lt : megaco signaling lt related alarms - eqpt-supplemental : equipment supplemental alarms - eqpt-holder-ext : other equipment holder alarms - lsmredundancy : lsm redundancy alarms - sync : synce and bits alarms - mcsrc : multicast source alarms - vlanport : vlanport alarms - vect-line : xDSL vectoring line alarms - vect-board : xDSL vectoring board alarms - otdr : otdr alarms - sip-dial-plan : sip dial plan related alarms - sip-vsp : sip vsp related alarms - sip-server : sip server related alarms - bgp : bgp related alarms - rip : rip related alarms - lag : LAG related alarms - ihub-general : IHUB general related alarms - vprn : vprn related alarms - isis : isis related alarms - ospf : ospf related alarms - ihub-l2forward : ihub-l2forward alarms - vpls : vpls related alarms - ihub-equip : ihub-equip related alarms - ihub-link : ihub-link related alarms - eont-phyoam : eont phyoam related alarms - ellid : ellid related alarms - epon : epon related alarms - eont-services-lan : eon phyoam related alarms - eolt-ont-tca : eon phyoam related alarms - eont-sw-dl : eon phyoam related alarms - ldp : ldp related alarms - mpls : mpls related alarms - sdp : sdp related alarms - epipe : epipe related alarms - ihub-ipv6 : ihub-ipv6 related alarms - pim : pim related alarms - li : lawful intercept related alarms - mgmt-sec-access : management security related alarms - bfd : bfd related alarms - ai : Application Intelligence related alarms	

name	Type	Description
	- tr069serv : tr069 server related alarms - ontsnmp : ont snmp related alarms - bulk-sync : bulk-sync related alarms - protection-group : port protection group related alarms - ont : ONT general supplemental related alarms - sfu-sup : SFU ONT general supplemental related alarms - soho-sup : SOHO ONT general supplemental related alarms - mdu-sup : MDU ONT general supplemental related alarms - ont-ani : ONT general supplemental 2 related alarms - sfu-sup2 : SFU ONT general supplemental 2 related alarms - soho-sup2 : SOHO ONT general supplemental 2 related alarms - mdu-sup2 : MDU ONT general supplemental 2 related alarms - sfrssi : SFP RSSI related alarms - eoltrssi : epon olt Sfp RSSI related alarms - cfm : Cfm related alarms - sfpe1t1-framer : SFP 2e1t1 framer alarms - sfpe1t1-clock : SFP 2e1t1 clock alarms - pppcc-engine-tca : PPPOE Cross Connect Engine TCA related alarm - eth-cfm : eth-cfm related alarms - rsvp : rsvp related alarms - ihub-tca : IHUB TCA related alarms - eth-ring : eth-ring related alarms - efm-oam : EFM-OAM related alarms - ont-loopdetect : ont loop detect related alarms - ont-video : ont services video related alarms - ont-ces : ont services ces related alarms - ont-voip : ont services voip related alarms - ont-video-ani : ont services video ani related alarms - ont-pwe : ont services pwe related alarms - ont-cese1 : ont services cese1 related alarms - ont-xdsl : ont services xdsl related alarms - ont-xdsl-tca : ont services xdsl tca related alarms - ont-hpna : ont hpna related alarms - ont-sip-agent-cfg : ont services voip sip agent config related alarms - ont-voip-cfg : ont services voip config related alarms - ont-mgc : ont mgc related alarms - ont-ploam : ONT PLOAM related alarms - ont-gen : ONT GENERAL related alarms - ont-card : ONT Subscriber Card related alarms - ont-pots : ONT Services POTS related alarms - ont-lan : ONT Services LAN related alarms - ont-moca : ONT MoCA related alarms - ont-tc-tca : ONT TC TCA related alarms - ont-moca-tca : ONT MoCA TCA related alarms - ont-l2uni-eth-tca : ONT L2 UNI Ethernet TCA related alarms - olt-pon-tc-tca : OLT PON TC TCA related alarms - olt-pon-util-tca : OLT PON utilization TCA related alarms - olt-chpr-util-tca : OLT channel-pair utilization TCA related alarms - olt-ont-tc-tca : OLT ONT TC TCA related alarms - ont-tca : ONT TCA related alarms	

101 query current alarms by filters

name	Type	Description
	- ont-pots-supplemental : ONT POTS Supplemental related alarms - sfu-ploam : SFU ONT PLOAM related alarms - sfu-gen : SFU ONT general related alarms - soho-ploam : SOHO ONT PLOAM related alarms - soho-gen : SOHO ONT general related alarms - mdu-ploam : MDU ONT PLOAM related alarms - mdu-gen : MDU ONT general related alarms - ont-veip : ONT VEIP related alarms - ont-iphost : ONT IP HOST related alarms - alarm-table : alarm table related alarms - auto-switch : auto-switch related alarms - channel-pair : channel pair related alarms - ont-cfg-dld : ont configure file download related alarms - olt-chpair-tc-tca : OLT CHANNELPAIR TC TCA related alarms - hgu-tr069 : hgu tr069 related alarms - eqpt-psu : equipment psu alarms - ont-protection : ONT protection related alarms - secondary-megaco-term : secondary megaco termination related alarms - secondary-sip-term : secondary sip termination related alarms - cas-r2-channel : CAS R2 channel related alarms - lldpmed : lldpmed alarms - pseudo-wire : pseudo Wire related alarms - link-agg : Link aggregation related alarms - fcs-exceed : FCS auto-recovery related alarms - e1t1-interface : E1/T1 physical interfaces related alarms	
name	Parameter type: <Alarm::alarmtypesSippluginunit> (norpniewithsoftdsp all) Possible values: - norpniewithsoftdsp : do not plan / plug-in RPNI-E board with SoftDsp SW image - all : show all sip plug in unit alarm	alarm name that are active <i>This element is only shown in detail mode.</i>
severity	Parameter type: <Alarm::AlarmSeverity> (indeterminate warning minor major critical) Possible values: - indeterminate : alarm severity is indeterminate - warning : alarm severity is warning - minor : alarm severity is minor - major : alarm severity is major - critical : alarm severity is critical	the alarms severity level <i>This element is only shown in detail mode.</i>
servaff	Parameter type: <Alarm::alarmServAffect> ((service-affecting yes) (noservice-affecting no)) Possible values: - service-affecting : make this alarm service affecting - yes : make this alarm service affecting - noservice-affecting : make this alarm not service affecting - no : make this alarm not service affecting	alarms affect service or not <i>This element is only shown in detail mode.</i>
time	Parameter type: <Sys::timeInSecs>	time in seconds when alarm was

name	Type	Description
	- the time (yyyy-mm-dd:hour:minutes:secs) - unit: UTC	updated <i>This element is only shown in detail mode.</i>
descript	Parameter type: <Alarm::AddInfoString> - additional alarm information	alarm description <i>This element is only shown in detail mode.</i>

101.32 show current alarm by filters

Command Description

show current alarms by filters

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm query sip-termination [ (name) [ severity <Alarm::querySeverity> ] [ servaff
<Alarm::queryServAffect> ] [ term-index <Itf::PotsLine> ] ]
```

Command Parameters

Table 101.32-1 "show current alarm by filters" Resource Parameters

Resource Identifier	Type	Description
(name)	Format: (unknown-sub ground-key port-hightemp port-jbfltca reg-domainname reg-auth reg-timeout reg-srvfailresp inv-domainname inv-auth inv-timeout inv-srvfailresp subs-srvfailresp subs-domainname subs-auth subs-refreshfail subs-inittimeout emergency-call all) Possible values: - unknown-sub : subscriber exist in the POLT, but not in the appl server - ground-key : Return current to the ground - port-hightemp : Temperature threshold on user port exceeded. - port-jbfltca : JB fill level threshold on user port exceeded. - reg-domainname : Registration failure (resolving domain	alarm name of sip-termination

Resource Identifier	Type	Description
	name). - reg-auth : Registration failure (authentication). - reg-timeout : Registration failure (message timeout). - reg-srvfailresp : Registration failure (failure response from server). - inv-domainname : Invitation failure (resolving domain name). - inv-auth : Invitation failure (authentication). - inv-timeout : Invitation failure (message timeout). - inv-srvfailresp : Invitation failure (failure response from server). - subs-srvfailresp : Subscribe failure (failure response from server). - subs-domainname : Subscribe failure (resolving domain name). - subs-auth : Subscribe failure (authentication). - subs-refreshfail : Subscribe failure (refresh failure). - subs-inittimeout : Subscribe failure (initial REQ timeout). - emergency-call : Emergency call for SIP POTS is ongoing. - all : show all sip termination alarm	
severity	Parameter type: <Alarm::querySeverity> Format: (indeterminate warning minor major critical all) Possible values: - indeterminate : alarm severity is indeterminate - warning : alarm severity is warning - minor : alarm severity is minor - major : alarm severity is major - critical : alarm severity is critical - all : all alarm severity	severity level of an alarm for reporting
servaff	Parameter type: <Alarm::queryServAffect> Format: (service-affecting noservice-affecting all) Possible values: - service-affecting : query alarm service affecting - noservice-affecting : query alarm not service affecting - all : query service affecting and not affecting alarms	serviceaffecting no serviceaffecting
term-index	Parameter type: <Itf::PotsLine> Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number	the termination index

Command Output

Table 101.32-2 "show current alarm by filters" Display parameters

Specific Information		
name	Type	Description
aidinfo	Parameter type: <Alarm::AddInfoString> - additional alarm information	alarm AID parameters <i>This element is only shown in detail mode.</i>
type	Parameter type: <Alarm::alarmIHUBType> (equipment eqpt-holder plug-in-unit atm custom e1 ima-group ima-link redundancy shdsl ether-itf traffic-overflow qos-queue temporal spatial (software-mngt sw-mgmt) xdsl xdsl-ext xdsl-tca olt-gen eo-conv authentication bonding sfp shdsl-isam custom-ext-alarm plug-in-unit-ext sip-user-agent sip-plugin-unit sip-termination e1-sip-termination filetransfer external-device l2forward ether-tca ether-sfp megaco-media-gw megaco-sig-gw megaco-plug-unit megaco-term megaco-sig-lt eqpt-supplemental eqpt-holder-ext lsmredundancy sync mcsrc vlanport	type of the alarms that are active <i>This element is only shown in detail mode.</i>

name	Type	Description
	vect-line	
	vect-board	
	otdr	
	sip-dial-plan	
	sip-vsp	
	sip-server	
	bgp	
	rip	
	lag	
	ihub-general	
	vprn	
	isis	
	ospf	
	ihub-l2forward	
	vpls	
	ihub-equip	
	ihub-link	
	eont-phyoam	
	ellid	
	epon	
	eont-services-lan	
	eolt-ont-tca	
	eont-sw-dl	
	ldp	
	mpls	
	sdp	
	epipe	
	ihub-ipv6	
	pim	
	li	
	mgmt-sec-access	
	bfd	
	ai	
	tr069serv	
	ontsnmp	
	bulk-sync	
	protection-group	
	ont	
	sfu-sup	
	soho-sup	
	mdu-sup	
	ont-ani	
	sfu-sup2	
	soho-sup2	
	mdu-sup2	
	sfprssi	
	eoltrssi	
	cfm	
	sfpe1t1-framer	
	sfpe1t1-clock	
	pppcc-engine-tca	
	eth-cfm	
	rsvp	
	ihub-tca	
	eth-ring	
	efm-oam	
	ont-loopdetect	

101 query current alarms by filters

name	Type	Description
	ont-video ont-ces ont-voip ont-video-ani ont-pwe ont-cese1 ont-xdsl ont-xdsl-tca ont-hpna ont-sip-agent-cfg ont-voip-cfg ont-mgc ont-ploam ont-gen ont-card ont-pots ont-lan ont-moca ont-tc-tca ont-moca-tca ont-l2uni-eth-tca olt-pon-tc-tca olt-pon-util-tca olt-chpr-util-tca olt-ont-tc-tca ont-tca ont-pots-supplemental sfu-ploam sfu-gen soho-ploam soho-gen mdu-ploam mdu-gen ont-veip ont-iphost alarm-table auto-switch channel-pair ont-cfg-dld olt-chpair-tc-tca hgu-tr069 eqpt-psu ont-protection secondary-megaco-term secondary-sip-term cas-r2-channel lldpmed pseudo-wire link-agg fcs-exceed e1t1-interface) Possible values: - equipment : equipment alarms - eqpt-holder : equipment holder alarms - plug-in-unit : plugin unit alarms - atm : ATM alarms - custom : customizable alarms	

name	Type	Description
	- e1 : e1 alarms - ima-group : ima-group alarms - ima-link : ima-link alarms - redundancy : redundancy alarms - shdsl : shdsl alarms - ether-itf : ethernet interface alarms - traffic-overflow : Traffic overflow alarms - qos-queue : qos queue alarms - temporal : temporal alarms - spatial : spatial alarms - software-mngt : software management alarms - sw-mgmt : software management alarms - xdsl : xDSL alarms - xdsl-ext : other xDSL alarms - xdsl-tca : xDSL threshold cross alarms - olt-gen : OLT general alarms - eo-conv : E/O conversion related alarms - authentication : authentication related alarms - bonding : bonding-group related alarms - sfp : SFP related alarms - shdsl-isam : shdsl isam alarms - custom-ext-alarm : customizable external alarms - plug-in-unit-ext : other plugin unit alarms - sip-user-agent : sip user agent related alarms - sip-plugin-unit : sip plug in unit related alarms - sip-termination : sip termination related alarms - e1-sip-termination : E1 sip termination related alarms - filetransfer : file transfer server alarms - external-device : external device related alarms - l2forward : l2forward related alarms - ether-tca : ethernet threshold cross alarms - ether-sfp : ethernet SFP related alarms - megaco-media-gw : megaco media gateway related alarms - megaco-sig-gw : megaco signaling gateway related alarms - megaco-plug-unit : megaco plug unit related alarms - megaco-term : megaco termination related alarms - megaco-sig-lt : megaco signaling lt related alarms - eqpt-supplemental : equipment supplemental alarms - eqpt-holder-ext : other equipment holder alarms - lsmredundancy : lsm redundancy alarms - sync : synce and bits alarms - mcsrc : multicast source alarms - vlanport : vlanport alarms - vect-line : xDSL vectoring line alarms - vect-board : xDSL vectoring board alarms - otdr : otdr alarms - sip-dial-plan : sip dial plan related alarms - sip-vsp : sip vsp related alarms - sip-server : sip server related alarms - bgp : bgp related alarms - rip : rip related alarms - lag : LAG related alarms - ihub-general : IHUB general related alarms - vprn : vprn related alarms - isis : isis related alarms - ospf : ospf related alarms - ihub-l2forward : ihub-l2forward alarms	

101 query current alarms by filters

name	Type	Description
	- vpls : vpls related alarms - ihub-equip : ihub-equip related alarms - ihub-link : ihub-link related alarms - eont-phyoam : eont phyoam related alarms - ellid : ellid related alarms - epon : epon related alarms - eont-services-lan : eon phyoam related alarms - eolt-ont-tca : eon phyoam related alarms - eont-sw-dl : eon phyoam related alarms - ldp : ldp related alarms - mpls : mpls related alarms - sdp : sdp related alarms - epipe : epipe related alarms - ihub-ipv6 : ihub-ipv6 related alarms - pim : pim related alarms - li : lawful intercept related alarms - mgmt-sec-access : management security related alarms - bfd : bfd related alarms - ai : Application Intelligence related alarms - tr069serv : tr069 server related alarms - ontsnmp : ont snmp related alarms - bulk-sync : bulk-sync related alarms - protection-group : port protection group related alarms - ont : ONT general supplemental related alarms - sfu-sup : SFU ONT general supplemental related alarms - soho-sup : SOHO ONT general supplemental related alarms - mdu-sup : MDU ONT general supplemental related alarms - ont-ani : ONT general supplemental 2 related alarms - sfu-sup2 : SFU ONT general supplemental 2 related alarms - soho-sup2 : SOHO ONT general supplemental 2 related alarms - mdu-sup2 : MDU ONT general supplemental 2 related alarms - sfprssi : SFP RSSI related alarms - eoltrssi : epon olt Sfp RSSI related alarms - cfm : Cfm related alarms - sfpe1t1-framer : SFP 2e1t1 framer alarms - sfpe1t1-clock : SFP 2e1t1 clock alarms - pppcc-engine-tca : PPPOE Cross Connect Engine TCA related alarm - eth-cfm : eth-cfm related alarms - rsvp : rsvp related alarms - ihub-tca : IHUB TCA related alarms - eth-ring : eth-ring related alarms - efm-oam : EFM-OAM related alarms - ont-loopdetect : ont loop detect related alarms - ont-video : ont services video related alarms - ont-ces : ont services ces related alarms - ont-voip : ont services voip related alarms - ont-video-ani : ont services video ani related alarms - ont-pwe : ont services pwe related alarms - ont-cese1 : ont services cese1 related alarms - ont-xdsl : ont services xdsl related alarms - ont-xdsl-tca : ont services xdsl tca related alarms - ont-hpna : ont hpna related alarms - ont-sip-agent-cfg : ont services voip sip agent config	

name	Type	Description
	related alarms - ont-voip-cfg : ont services voip config related alarms - ont-mgc : ont mgc related alarms - ont-ploam : ONT PLOAM related alarms - ont-gen : ONT GENERAL related alarms - ont-card : ONT Subscriber Card related alarms - ont-pots : ONT Services POTS related alarms - ont-lan : ONT Services LAN related alarms - ont-moca : ONT MoCA related alarms - ont-tc-tca : ONT TC TCA related alarms - ont-moca-tca : ONT MoCA TCA related alarms - ont-l2uni-eth-tca : ONT L2 UNI Ethernet TCA related alarms - olt-pon-tc-tca : OLT PON TC TCA related alarms - olt-pon-util-tca : OLT PON utilization TCA related alarms - olt-chpr-util-tca : OLT channel-pair utilization TCA related alarms - olt-ont-tc-tca : OLT ONT TC TCA related alarms - ont-tca : ONT TCA related alarms - ont-pots-supplemental : ONT POTS Supplemental related alarms - sfu-ploam : SFU ONT PLOAM related alarms - sfu-gen : SFU ONT general related alarms - soho-ploam : SOHO ONT PLOAM related alarms - soho-gen : SOHO ONT general related alarms - mdu-ploam : MDU ONT PLOAM related alarms - mdu-gen : MDU ONT general related alarms - ont-veip : ONT VEIP related alarms - ont-iphost : ONT IP HOST related alarms - alarm-table : alarm table related alarms - auto-switch : auto-switch related alarms - channel-pair : channel pair related alarms - ont-cfg-dld : ont configure file download related alarms - olt-chpair-tc-tca : OLT CHANNELPAIR TC TCA related alarms - hgu-tr069 : hgu tr069 related alarms - eqpt-psu : equipment psu alarms - ont-protection : ONT protection related alarms - secondary-megaco-term : secondary megaco termination related alarms - secondary-sip-term : secondary sip termination related alarms - cas-r2-channel : CAS R2 channel related alarms - lldpmed : lldpmed alarms - pseudo-wire : pseudo Wire related alarms - link-agg : Link aggregation related alarms - fcs-exceed : FCS auto-recovery related alarms - e1t1-interface : E1/T1 physical interfaces related alarms	
name	Parameter type: <Alarm::alarmtypeSiptermination> - unknown-sub - ground-key - port-hightemp - port-jbfltca - reg-domainname - reg-auth - reg-timeout - reg-srvfailresp	alarm name that are active <i>This element is only shown in detail mode.</i>

101 query current alarms by filters

name	Type	Description
	inv-domainname inv-auth inv-timeout inv-srvfailresp subs-srvfailresp subs-domainname subs-auth subs-refreshfail subs-inittimeout emergency-call all) Possible values: - unknown-sub : subscriber exist in the POLT, but not in the appl server - ground-key : Return current to the ground - port-hightemp : Temperature threshold on user port exceeded. - port-jbfltca : JB fill level threshold on user port exceeded. - reg-domainname : Registration failure (resolving domain name). - reg-auth : Registration failure (authentication). - reg-timeout : Registration failure (message timeout). - reg-srvfailresp : Registration failure (failure response from server). - inv-domainname : Invitation failure (resolving domain name). - inv-auth : Invitation failure (authentication). - inv-timeout : Invitation failure (message timeout). - inv-srvfailresp : Invitation failure (failure response from server). - subs-srvfailresp : Subscribe failure (failure response from server). - subs-domainname : Subscribe failure (resolving domain name). - subs-auth : Subscribe failure (authentication). - subs-refreshfail : Subscribe failure (refresh failure). - subs-inittimeout : Subscribe failure (initial REQ timeout). - emergency-call : Emergency call for SIP POTS is ongoing. - all : show all sip termination alarm	
severity	Parameter type: <Alarm::AlarmSeverity> (indeterminate warning minor major critical) Possible values: - indeterminate : alarm severity is indeterminate - warning : alarm severity is warning - minor : alarm severity is minor - major : alarm severity is major - critical : alarm severity is critical	the alarms severity level <i>This element is only shown in detail mode.</i>
servaff	Parameter type: <Alarm::alarmServAffect> ((service-affecting yes) (noservice-affecting no)) Possible values: - service-affecting : make this alarm service affecting - yes : make this alarm service affecting	alarms affect service or not <i>This element is only shown in detail mode.</i>

name	Type	Description
	- noservice-affecting : make this alarm not service affecting - no : make this alarm not service affecting	
time	Parameter type: <Sys::timeInSecs> - the time (yyyy-mm-dd:hour:minutes:secs) - unit: UTC	time in seconds when alarm was updated <i>This element is only shown in detail mode.</i>
descript	Parameter type: <Alarm::AddInfoString> - additional alarm information	alarm description <i>This element is only shown in detail mode.</i>

101.33 show current alarm by filters

Command Description

show current alarms by filters

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm query secondary-sip-term [ (name) [ severity <Alarm::querySeverity> ] [ servaff
<Alarm::queryServAffect> ] [ term-index <Itf::PotsLine> ] ]
```

Command Parameters

Table 101.33-1 "show current alarm by filters" Resource Parameters

Resource Identifier	Type	Description
(name)	Format: (reg-domainname-sec reg-auth-sec reg-timeout-sec reg-srvfailresp-sec inv-domainname-sec inv-auth-sec inv-timeout-sec inv-srvfailresp-sec subs-srvfailresp-sec subs-domainname-sec subs-auth-sec subs-refreshfail-sec subs-inittimeout-sec emergency-call-sec all) Possible values: - reg-domainname-sec : Registration failure (resolving domain name). - reg-auth-sec : Registration failure (authentication). - reg-timeout-sec : Registration failure (message timeout). - reg-srvfailresp-sec : Registration failure (failure response from server). - inv-domainname-sec : Invitation failure (resolving domain name). - inv-auth-sec : Invitation failure (authentication). - inv-timeout-sec : Invitation failure (message timeout). - inv-srvfailresp-sec : Invitation failure (failure response	alarm name of secondary sip term

Resource Identifier	Type	Description
	from server). - subs-srvfailresp-sec : Subscribe failure (failure response from server). - subs-domainname-sec : Subscribe failure (resolving domain name). - subs-auth-sec : Subscribe failure (authentication). - subs-refreshfail-sec : Subscribe failure (refresh failure). - subs-inittimeout-sec : Subscribe failure (initial REQ timeout). - emergency-call-sec : Emergency call for Secondary Termination is ongoing. - all : show all secondary sip termination alarm	
severity	Parameter type: <Alarm::querySeverity> Format: (indeterminate warning minor major critical all) Possible values: - indeterminate : alarm severity is indeterminate - warning : alarm severity is warning - minor : alarm severity is minor - major : alarm severity is major - critical : alarm severity is critical - all : all alarm severity	severity level of an alarm for reporting
servaff	Parameter type: <Alarm::queryServAffect> Format: (service-affecting noservice-affecting all) Possible values: - service-affecting : query alarm service affecting - noservice-affecting : query alarm not service affecting - all : query service affecting and not affecting alarms	serviceaffecting no serviceaffecting
term-index	Parameter type: <Itf::PotsLine> Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number	identifies the termination

Command Output

Table 101.33-2 "show current alarm by filters" Display parameters

Specific Information		
name	Type	Description
aidinfo	Parameter type: <Alarm::AddInfoString> - additional alarm information	alarm AID parameters <i>This element is only shown in</i>

101 query current alarms by filters

name	Type	Description
		<i>detail mode.</i>
type	Parameter type: <Alarm::alarmIHUBType> (equipment eqpt-holder plug-in-unit atm custom e1 ima-group ima-link redundancy shdsl ether-itf traffic-overflow qos-queue temporal spatial (software-mngt sw-mgmt) xdsl xdsl-ext xdsl-tca olt-gen eo-conv authentication bonding sfp shdsl-isam custom-ext-alarm plug-in-unit-ext sip-user-agent sip-plugin-unit sip-termination e1-sip-termination filetransfer external-device l2forward ether-tca ether-sfp megaco-media-gw megaco-sig-gw megaco-plugin-unit megaco-term megaco-sig-lt eqpt-supplemental eqpt-holder-ext lsmredundancy sync mcsrc vlanport vect-line vect-board otdr sip-dial-plan sip-vsp sip-server bgp rip)	type of the alarms that are active <i>This element is only shown in detail mode.</i>

name	Type	Description
	lag	
	ihub-general	
	vprn	
	isis	
	ospf	
	ihub-l2forward	
	vpls	
	ihub-equip	
	ihub-link	
	eont-phyoam	
	ellid	
	epon	
	eont-services-lan	
	eolt-ont-tca	
	eont-sw-dl	
	ldp	
	mpls	
	sdp	
	epipe	
	ihub-ipv6	
	pim	
	li	
	mgmt-sec-access	
	bfd	
	ai	
	tr069serv	
	ontsnmp	
	bulk-sync	
	protection-group	
	ont	
	sfu-sup	
	soho-sup	
	mdu-sup	
	ont-ani	
	sfu-sup2	
	soho-sup2	
	mdu-sup2	
	sfprssi	
	eoltrssi	
	cfm	
	sfpe1t1-framer	
	sfpe1t1-clock	
	pppcc-engine-tca	
	eth-cfm	
	rsvp	
	ihub-tca	
	eth-ring	
	efm-oam	
	ont-loopdetect	
	ont-video	
	ont-ces	
	ont-voip	
	ont-video-ani	
	ont-pwe	
	ont-cese1	
	ont-xdsl	
	ont-xdsl-tca	

101 query current alarms by filters

name	Type	Description
	ont-hpna ont-sip-agent-cfg ont-voip-cfg ont-mgc ont-ploam ont-gen ont-card ont-pots ont-lan ont-moca ont-tc-tca ont-moca-tca ont-l2uni-eth-tca olt-pon-tc-tca olt-pon-util-tca olt-chpr-util-tca olt-ont-tc-tca ont-tca ont-pots-supplemental sfu-ploam sfu-gen soho-ploam soho-gen mdu-ploam mdu-gen ont-veip ont-iphost alarm-table auto-switch channel-pair ont-cfg-dld olt-chpair-tc-tca hgu-tr069 eqpt-psu ont-protection secondary-megaco-term secondary-sip-term cas-r2-channel lldpmed pseudo-wire link-agg fcs-exceed e1t1-interface) Possible values: - equipment : equipment alarms - eqpt-holder : equipment holder alarms - plug-in-unit : plugin unit alarms - atm : ATM alarms - custom : customizable alarms - e1 : e1 alarms - ima-group : ima-group alarms - ima-link : ima-link alarms - redundancy : redundancy alarms - shdsl : shdsl alarms - ether-itf : ethernet interface alarms - traffic-overflow : Traffic overflow alarms - qos-queue : qos queue alarms	

name	Type	Description
	- temporal : temporal alarms - spatial : spatial alarms - software-mngt : software management alarms - sw-mgmt : software management alarms - xdsl : xDSL alarms - xdsl-ext : other xDSL alarms - xdsl-tca : xDSL threshold cross alarms - olt-gen : OLT general alarms - eo-conv : E/O conversion related alarms - authentication : authentication related alarms - bonding : bonding-group related alarms - sfp : SFP related alarms - shdsl-isam : shdsl isam alarms - custom-ext-alarm : customizable external alarms - plug-in-unit-ext : other plugin unit alarms - sip-user-agent : sip user agent related alarms - sip-plugin-unit : sip plug in unit related alarms - sip-termination : sip termination related alarms - e1-sip-termination : E1 sip termination related alarms - filetransfer : file transfer server alarms - external-device : external device related alarms - l2forward : l2forward related alarms - ether-tca : ethernet threshold cross alarms - ether-sfp : ethernet SFP related alarms - megaco-media-gw : megaco media gateway related alarms - megaco-sig-gw : megaco signaling gateway related alarms - megaco-plug-unit : megaco plug unit related alarms - megaco-term : megaco termination related alarms - megaco-sig-lt : megaco signaling lt related alarms - eqpt-supplemental : equipment supplemental alarms - eqpt-holder-ext : other equipment holder alarms - lsmredundancy : lsm redundancy alarms - sync : synce and bits alarms - mcsrc : multicast source alarms - vlanport : vlanport alarms - vect-line : xDSL vectoring line alarms - vect-board : xDSL vectoring board alarms - otdr : otdr alarms - sip-dial-plan : sip dial plan related alarms - sip-vsp : sip vsp related alarms - sip-server : sip server related alarms - bgp : bgp related alarms - rip : rip related alarms - lag : LAG related alarms - ihub-general : IHUB general related alarms - vprn : vprn related alarms - isis : isis related alarms - ospf : ospf related alarms - ihub-l2forward : ihub-l2forward alarms - vpls : vpls related alarms - ihub-equip : ihub-equip related alarms - ihub-link : ihub-link related alarms - eont-phyoam : eont phyoam related alarms - ellid : ellid related alarms - epon : epon related alarms - eont-services-lan : eon phyoam related alarms - eolt-ont-tca : eon phyoam related alarms	

101 query current alarms by filters

name	Type	Description
	- eont-sw-dl : eon phyoom related alarms - ldp : ldp related alarms - mpls : mpls related alarms - sdp : sdp related alarms - epipe : epipe related alarms - ihub-ipv6 : ihub-ipv6 related alarms - pim : pim related alarms - li : lawful intercept related alarms - mgmt-sec-access : management security related alarms - bfd : bfd related alarms - ai : Application Intelligence related alarms - tr069serv : tr069 server related alarms - ontsnmp : ont snmp related alarms - bulk-sync : bulk-sync related alarms - protection-group : port protection group related alarms - ont : ONT general supplemental related alarms - sfu-sup : SFU ONT general supplemental related alarms - soho-sup : SOHO ONT general supplemental related alarms - mdu-sup : MDU ONT general supplemental related alarms - ont-ani : ONT general supplemental 2 related alarms - sfu-sup2 : SFU ONT general supplemental 2 related alarms - soho-sup2 : SOHO ONT general supplemental 2 related alarms - mdu-sup2 : MDU ONT general supplemental 2 related alarms - sfprssi : SFP RSSI related alarms - eoltrssi : epon olt Sfp RSSI related alarms - cfm : Cfm related alarms - sfpe1t1-framer : SFP 2e1t1 framer alarms - sfpe1t1-clock : SFP 2e1t1 clock alarms - pppcc-engine-tca : PPPOE Cross Connect Engine TCA related alarm - eth-cfm : eth-cfm related alarms - rsvp : rsvp related alarms - ihub-tca : IHUB TCA related alarms - eth-ring : eth-ring related alarms - efm-oam : EFM-OAM related alarms - ont-loopdetect : ont loop detect related alarms - ont-video : ont services video related alarms - ont-ces : ont services ces related alarms - ont-voip : ont services voip related alarms - ont-video-ani : ont services video ani related alarms - ont-pwe : ont services pwe related alarms - ont-cese1 : ont services cese1 related alarms - ont-xdsl : ont services xdsl related alarms - ont-xdsl-tca : ont services xdsl tca related alarms - ont-hpna : ont hpna related alarms - ont-sip-agent-cfg : ont services voip sip agent config related alarms - ont-voip-cfg : ont services voip config related alarms - ont-mgc : ont mgc related alarms - ont-ploam : ONT PLOAM related alarms - ont-gen : ONT GENERAL related alarms - ont-card : ONT Subscriber Card related alarms - ont-pots : ONT Services POTS related alarms - ont-lan : ONT Services LAN related alarms	

name	Type	Description
	- ont-moca : ONT MoCA related alarms - ont-tc-tca : ONT TC TCA related alarms - ont-moca-tca : ONT MoCA TCA related alarms - ont-l2uni-eth-tca : ONT L2 UNI Ethernet TCA related alarms - olt-pon-tc-tca : OLT PON TC TCA related alarms - olt-pon-util-tca : OLT PON utilization TCA related alarms - olt-chpr-util-tca : OLT channel-pair utilization TCA related alarms - olt-ont-tc-tca : OLT ONT TC TCA related alarms - ont-tca : ONT TCA related alarms - ont-pots-supplemental : ONT POTS Supplemental related alarms - sfu-ploam : SFU ONT PLOAM related alarms - sfu-gen : SFU ONT general related alarms - soho-ploam : SOHO ONT PLOAM related alarms - soho-gen : SOHO ONT general related alarms - mdu-ploam : MDU ONT PLOAM related alarms - mdu-gen : MDU ONT general related alarms - ont-veip : ONT VEIP related alarms - ont-iphost : ONT IP HOST related alarms - alarm-table : alarm table related alarms - auto-switch : auto-switch related alarms - channel-pair : channel pair related alarms - ont-cfg-dld : ont configure file download related alarms - olt-chpair-tc-tca : OLT CHANNELPAIR TC TCA related alarms - hgu-tr069 : hgu tr069 related alarms - eqpt-psu : equipment psu alarms - ont-protection : ONT protection related alarms - secondary-megaco-term : secondary megaco termination related alarms - secondary-sip-term : secondary sip termination related alarms - cas-r2-channel : CAS R2 channel related alarms - lldpmed : lldpmed alarms - pseudo-wire : pseudo Wire related alarms - link-agg : Link aggregation related alarms - fcs-exceed : FCS auto-recovery related alarms - e1t1-interface : E1/T1 physical interfaces related alarms	
name	Parameter type: <Alarm::almtypeSecondarySIPTerm> (reg-domainname-sec reg-auth-sec reg-timeout-sec reg-srvfailresp-sec inv-domainname-sec inv-auth-sec inv-timeout-sec inv-srvfailresp-sec subs-srvfailresp-sec subs-domainname-sec subs-auth-sec subs-refreshfail-sec subs-inittimeout-sec emergency-call-sec all) Possible values:	alarm name that are active <i>This element is only shown in detail mode.</i>

101 query current alarms by filters

name	Type	Description
	- reg-domainname-sec : Registration failure (resolving domain name). - reg-auth-sec : Registration failure (authentication). - reg-timeout-sec : Registration failure (message timeout). - reg-srvfailresp-sec : Registration failure (failure response from server). - inv-domainname-sec : Invitation failure (resolving domain name). - inv-auth-sec : Invitation failure (authentication). - inv-timeout-sec : Invitation failure (message timeout). - inv-srvfailresp-sec : Invitation failure (failure response from server). - subs-srvfailresp-sec : Subscribe failure (failure response from server). - subs-domainname-sec : Subscribe failure (resolving domain name). - subs-auth-sec : Subscribe failure (authentication). - subs-refreshfail-sec : Subscribe failure (refresh failure). - subs-inittimeout-sec : Subscribe failure (initial REQ timeout). - emergency-call-sec : Emergency call for Secondary Termination is ongoing. - all : show all secondary sip termination alarm	
severity	Parameter type: <Alarm::AlarmSeverity> (indeterminate warning minor major critical) Possible values: - indeterminate : alarm severity is indeterminate - warning : alarm severity is warning - minor : alarm severity is minor - major : alarm severity is major - critical : alarm severity is critical	the alarms severity level <i>This element is only shown in detail mode.</i>
servaff	Parameter type: <Alarm::alarmServAffect> ((service-affecting yes) (noservice-affecting no)) Possible values: - service-affecting : make this alarm service affecting - yes : make this alarm service affecting - noservice-affecting : make this alarm not service affecting - no : make this alarm not service affecting	alarms affect service or not <i>This element is only shown in detail mode.</i>
time	Parameter type: <Sys::timeInSecs> - the time (yyyy-mm-dd:hour:minutes:secs) - unit: UTC	time in seconds when alarm was updated <i>This element is only shown in detail mode.</i>
descript	Parameter type: <Alarm::AddInfoString> - additional alarm information	alarm description <i>This element is only shown in detail mode.</i>

101.34 show current alarm by filters

Command Description

show current alarms by filters

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm query xdsl [ (name) [ severity <Alarm::querySeverity> ] [ servaff <Alarm::queryServAffect> ] [ port
<Itf::XdslLine> ] ]
```

Command Parameters

Table 101.34-1 "show current alarm by filters" Resource Parameters

Resource Identifier	Type	Description
(name)	Format: (xdsl-ne-los xdsl-ne-lof xdsl-ne-lom xdsl-ne-ese xdsl-act-cfg-error xdsl-act-not-feas xdsl-up-br-reach xdsl-ne-ncd xdsl-ne-lcd xdsl-fe-los xdsl-fe-lof xdsl-fe-lpr xdsl-fe-lol xdsl-fe-lom xdsl-fe-ese xdsl-fe-upbo-vio xdsl-fe-cpe-pol xdsl-tpstc-mis xdsl-act-comm xdsl-act-modem xdsl-do-br-reach xdsl-fe-ncd xdsl-fe-lcd xdsl-frtx-init-fail xdsl-vect-dle all) Possible values:	alarm name of xdsl

101 query current alarms by filters

Resource Identifier	Type	Description
	- xdsl-ne-los : loss of signal - xdsl-ne-lof : loss of frame - xdsl-ne-lom : loss of margin - xdsl-ne-ese : excessive severe errors - xdsl-act-cfg-error : line configuration data cannot be used - xdsl-act-not-feas : line capacity not enough to setup requested profile - xdsl-up-br-reach : planned bitrate not reached after initialization - xdsl-ne-ncd : no cell delineation - xdsl-ne-lcd : loss of cell delineation - xdsl-fe-los : loss of signal - xdsl-fe-lof : loss of frame - xdsl-fe-lpr : loss of power - xdsl-fe-lol : loss of link - xdsl-fe-lom : loss of margin - xdsl-fe-ese : excessive severe errors - xdsl-fe-upbo-vio : upbo violation - xdsl-fe-cpe-pol : activation failure cpe policing - xdsl-tpstc-mis : mismatch between the configured tps-tc mode and the mode supported by the connected cpe - xdsl-act-comm : init not successful due to communications problem - xdsl-act-modem : no peer modem detected - xdsl-do-br-reach : planned bitrate not reached after init - xdsl-fe-ncd : no cell delineation - xdsl-fe-lcd : loss of cell delineation - xdsl-frtx-init-fail : init not successful due to forced rtx - xdsl-vect-dle : vectoring disorderly leaving event - all : show all xDSL alarm alarm	
severity	Parameter type: <Alarm::querySeverity> Format: (indeterminate warning minor major critical all) Possible values: - indeterminate : alarm severity is indeterminate - warning : alarm severity is warning - minor : alarm severity is minor - major : alarm severity is major - critical : alarm severity is critical - all : all alarm severity	severity level of an alarm for reporting
servaff	Parameter type: <Alarm::queryServAffect> Format: (service-affecting noservice-affecting all) Possible values: - service-affecting : query alarm service affecting - noservice-affecting : query alarm not service affecting - all : query service affecting and not affecting alarms	serviceaffecting no serviceaffecting
port	Parameter type: <Itf::XdslLine> Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> /	identifies the physical position of the port

Resource Identifier	Type	Description
	<Eqpt::PortId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number	

Command Output

Table 101.34-2 "show current alarm by filters" Display parameters

Specific Information		
name	Type	Description
aidinfo	Parameter type: <Alarm::AddInfoString> - additional alarm information	alarm AID parameters <i>This element is only shown in detail mode.</i>
type	Parameter type: <Alarm::alarmIHUBType> (equipment eqpt-holder plug-in-unit atm custom e1 ima-group ima-link redundancy shdsl ether-itf traffic-overflow qos-queue temporal spatial (software-mngt sw-mgmt) xdsl xdsl-ext xdsl-tca olt-gen eo-conv authentication bonding sfp shdsl-isam custom-ext-alarm plug-in-unit-ext sip-user-agent sip-plugin-unit sip-termination e1-sip-termination filetransfer external-device l2forward ether-tca ether-sfp megaco-media-gw	type of the alarms that are active <i>This element is only shown in detail mode.</i>

101 query current alarms by filters

name	Type	Description
	megaco-sig-gw megaco-plug-unit megaco-term megaco-sig-lt eqpt-supplemental eqpt-holder-ext lsmredundancy sync mcsrc vlanport vect-line vect-board otdr sip-dial-plan sip-vsp sip-server bgp rip lag ihub-general vprn isis ospf ihub-l2forward vpls ihub-equip ihub-link eont-phyoam ellid epon eont-services-lan eolt-ont-tca eont-sw-dl ldp mpls sdp epipe ihub-ipv6 pim li mgmt-sec-access bfd ai tr069serv ontsnmp bulk-sync protection-group ont sfu-sup soho-sup mdu-sup ont-ani sfu-sup2 soho-sup2 mdu-sup2 sfprssi eoltrssi	

name	Type	Description
	cfm	
	sfpe1t1-framer	
	sfpe1t1-clock	
	pppcc-engine-tca	
	eth-cfm	
	rsvp	
	ihub-tca	
	eth-ring	
	efm-oam	
	ont-loopdetect	
	ont-video	
	ont-ces	
	ont-voip	
	ont-video-ani	
	ont-pwe	
	ont-cese1	
	ont-xdsl	
	ont-xdsl-tca	
	ont-hpna	
	ont-sip-agent-cfg	
	ont-voip-cfg	
	ont-mgc	
	ont-ploam	
	ont-gen	
	ont-card	
	ont-pots	
	ont-lan	
	ont-moca	
	ont-tc-tca	
	ont-moca-tca	
	ont-l2uni-eth-tca	
	olt-pon-tc-tca	
	olt-pon-util-tca	
	olt-chpr-util-tca	
	olt-ont-tc-tca	
	ont-tca	
	ont-pots-supplemental	
	sfu-ploam	
	sfu-gen	
	soho-ploam	
	soho-gen	
	mdu-ploam	
	mdu-gen	
	ont-veip	
	ont-iphost	
	alarm-table	
	auto-switch	
	channel-pair	
	ont-cfg-dld	
	olt-chpair-tc-tca	
	hgu-tr069	
	eqpt-psu	
	ont-protection	
	secondary-megaco-term	
	secondary-sip-term	
	cas-r2-channel	
	lldpmed	

101 query current alarms by filters

name	Type	Description
	pseudo-wire link-agg fcs-exceed e1t1-interface) Possible values: - equipment : equipment alarms - eqpt-holder : equipment holder alarms - plug-in-unit : plugin unit alarms - atm : ATM alarms - custom : customizable alarms - e1 : e1 alarms - ima-group : ima-group alarms - ima-link : ima-link alarms - redundancy : redundancy alarms - shdsl : shdsl alarms - ether-itf : ethernet interface alarms - traffic-overflow : Traffic overflow alarms - qos-queue : qos queue alarms - temporal : temporal alarms - spatial : spatial alarms - software-mngt : software management alarms - sw-mgmt : software management alarms - xdsl : xDSL alarms - xdsl-ext : other xDSL alarms - xdsl-tca : xDSL threshold cross alarms - olt-gen : OLT general alarms - eo-conv : E/O conversion related alarms - authentication : authentication related alarms - bonding : bonding-group related alarms - sfp : SFP related alarms - shdsl-isam : shdsl isam alarms - custom-ext-alarm : customizable external alarms - plug-in-unit-ext : other plugin unit alarms - sip-user-agent : sip user agent related alarms - sip-plugin-unit : sip plug in unit related alarms - sip-termination : sip termination related alarms - e1-sip-termination : E1 sip termination related alarms - filetransfer : file transfer server alarms - external-device : external device related alarms - l2forward : l2forward related alarms - ether-tca : ethernet threshold cross alarms - ether-sfp : ethernet SFP related alarms - megaco-media-gw : megaco media gateway related alarms - megaco-sig-gw : megaco signaling gateway related alarms - megaco-plug-unit : megaco plug unit related alarms - megaco-term : megaco termination related alarms - megaco-sig-lt : megaco signaling lt related alarms - eqpt-supplemental : equipment supplemental alarms - eqpt-holder-ext : other equipment holder alarms - lsmredundancy : lsm redundancy alarms - sync : synce and bits alarms - mcsrc : multicast source alarms - vlanport : vlanport alarms - vect-line : xDSL vectoring line alarms - vect-board : xDSL vectoring board alarms - otdr : otdr alarms - sip-dial-plan : sip dial plan related alarms	

name	Type	Description
	- sip-vsp : sip vsp related alarms - sip-server : sip server related alarms - bgp : bgp related alarms - rip : rip related alarms - lag : LAG related alarms - ihub-general : IHUB general related alarms - vprn : vprn related alarms - isis : isis related alarms - ospf : ospf related alarms - ihub-l2forward : ihub-l2forward alarms - vpls : vpls related alarms - ihub-equip : ihub-equip related alarms - ihub-link : ihub-link related alarms - eont-phyoam : eont phyoam related alarms - ellid : ellid related alarms - epon : epon related alarms - eont-services-lan : eon phyoam related alarms - eolt-ont-tca : eon phyoam related alarms - eont-sw-dl : eon phyoam related alarms - ldp : ldp related alarms - mpls : mpls related alarms - sdp : sdp related alarms - epipe : epipe related alarms - ihub-ipv6 : ihub-ipv6 related alarms - pim : pim related alarms - li : lawful intercept related alarms - mgmt-sec-access : management security related alarms - bfd : bfd related alarms - ai : Application Intelligence related alarms - tr069serv : tr069 server related alarms - ontsnmp : ont snmp related alarms - bulk-sync : bulk-sync related alarms - protection-group : port protection group related alarms - ont : ONT general supplemental related alarms - sfu-sup : SFU ONT general supplemental related alarms - soho-sup : SOHO ONT general supplemental related alarms - mdu-sup : MDU ONT general supplemental related alarms - ont-ani : ONT general supplemental 2 related alarms - sfu-sup2 : SFU ONT general supplemental 2 related alarms - soho-sup2 : SOHO ONT general supplemental 2 related alarms - mdu-sup2 : MDU ONT general supplemental 2 related alarms - sfprssi : SFP RSSI related alarms - eoltrssi : epon olt Sfp RSSI related alarms - cfm : Cfm related alarms - sfpe1t1-framer : SFP 2e1t1 framer alarms - sfpe1t1-clock : SFP 2e1t1 clock alarms - pppcc-engine-tca : PPPOE Cross Connect Engine TCA related alarm - eth-cfm : eth-cfm related alarms - rsvp : rsvp related alarms - ihub-tca : IHUB TCA related alarms - eth-ring : eth-ring related alarms - efm-oam : EFM-OAM related alarms - ont-loopdetect : ont loop detect related alarms	

101 query current alarms by filters

name	Type	Description
	- ont-video : ont services video related alarms - ont-ces : ont services ces related alarms - ont-voip : ont services voip related alarms - ont-video-ani : ont services video ani related alarms - ont-pwe : ont services pwe related alarms - ont-cese1 : ont services cese1 related alarms - ont-xdsl : ont services xdsl related alarms - ont-xdsl-tca : ont services xdsl tca related alarms - ont-hpna : ont hpna related alarms - ont-sip-agent-cfg : ont services voip sip agent config related alarms - ont-voip-cfg : ont services voip config related alarms - ont-mgc : ont mgc related alarms - ont-ploam : ONT PLOAM related alarms - ont-gen : ONT GENERAL related alarms - ont-card : ONT Subscriber Card related alarms - ont-pots : ONT Services POTS related alarms - ont-lan : ONT Services LAN related alarms - ont-moca : ONT MoCA related alarms - ont-tc-tca : ONT TC TCA related alarms - ont-moca-tca : ONT MoCA TCA related alarms - ont-l2uni-eth-tca : ONT L2 UNI Ethernet TCA related alarms - olt-pon-tc-tca : OLT PON TC TCA related alarms - olt-pon-util-tca : OLT PON utilization TCA related alarms - olt-chpr-util-tca : OLT channel-pair utilization TCA related alarms - olt-ont-tc-tca : OLT ONT TC TCA related alarms - ont-tca : ONT TCA related alarms - ont-pots-supplemental : ONT POTS Supplemental related alarms - sfu-ploam : SFU ONT PLOAM related alarms - sfu-gen : SFU ONT general related alarms - soho-ploam : SOHO ONT PLOAM related alarms - soho-gen : SOHO ONT general related alarms - mdu-ploam : MDU ONT PLOAM related alarms - mdu-gen : MDU ONT general related alarms - ont-veip : ONT VEIP related alarms - ont-iphost : ONT IP HOST related alarms - alarm-table : alarm table related alarms - auto-switch : auto-switch related alarms - channel-pair : channel pair related alarms - ont-cfg-dld : ont configure file download related alarms - olt-chpair-tc-tca : OLT CHANNELPAIR TC TCA related alarms - hgu-tr069 : hgu tr069 related alarms - eqpt-psu : equipment psu alarms - ont-protection : ONT protection related alarms - secondary-megaco-term : secondary megaco termination related alarms - secondary-sip-term : secondary sip termination related alarms - cas-r2-channel : CAS R2 channel related alarms - lldpmed : lldpmed alarms - pseudo-wire : pseudo Wire related alarms - link-agg : Link aggregation related alarms - fcs-exceed : FCS auto-recovery related alarms	

name	Type	Description
	- e1t1-interface : E1/T1 physical interfaces related alarms	
name	Parameter type: <Alarm::alarmTypeXdsl> (xdsl-ne-los xdsl-ne-lof xdsl-ne-lom xdsl-ne-ese xdsl-act-cfg-error xdsl-act-not-feas xdsl-up-br-reach xdsl-ne-ncd xdsl-ne-lcd xdsl-fe-los xdsl-fe-lof xdsl-fe-lpr xdsl-fe-lol xdsl-fe-lom xdsl-fe-ese xdsl-fe-upbo-vio xdsl-fe-cpe-pol xdsl-tpstc-mis xdsl-act-comm xdsl-act-modem xdsl-do-br-reach xdsl-fe-ncd xdsl-fe-lcd xdsl-frtx-init-fail xdsl-vect-dle all) Possible values: - xdsl-ne-los : loss of signal - xdsl-ne-lof : loss of frame - xdsl-ne-lom : loss of margin - xdsl-ne-ese : excessive severe errors - xdsl-act-cfg-error : line configuration data cannot be used - xdsl-act-not-feas : line capacity not enough to setup requested profile - xdsl-up-br-reach : planned bitrate not reached after initialization - xdsl-ne-ncd : no cell delineation - xdsl-ne-lcd : loss of cell delineation - xdsl-fe-los : loss of signal - xdsl-fe-lof : loss of frame - xdsl-fe-lpr : loss of power - xdsl-fe-lol : loss of link - xdsl-fe-lom : loss of margin - xdsl-fe-ese : excessive severe errors - xdsl-fe-upbo-vio : upbo violation - xdsl-fe-cpe-pol : activation failure cpe policing - xdsl-tpstc-mis : mismatch between the configured tps-tc mode and the mode supported by the connected cpe - xdsl-act-comm : init not successful due to communications problem - xdsl-act-modem : no peer modem detected - xdsl-do-br-reach : planned bitrate not reached after init - xdsl-fe-ncd : no cell delineation - xdsl-fe-lcd : loss of cell delineation - xdsl-frtx-init-fail : init not successful due to forced rtx	alarm name that are active <i>This element is only shown in detail mode.</i>

101 query current alarms by filters

name	Type	Description
	- xdsl-vect-dle : vectoring disorderly leaving event - all : show all xDSL alarm alarm	
severity	Parameter type: <Alarm::AlarmSeverity> (indeterminate warning minor major critical) Possible values: - indeterminate : alarm severity is indeterminate - warning : alarm severity is warning - minor : alarm severity is minor - major : alarm severity is major - critical : alarm severity is critical	the alarms severity level <i>This element is only shown in detail mode.</i>
servaff	Parameter type: <Alarm::alarmServAffect> ((service-affecting yes) (noservice-affecting no)) Possible values: - service-affecting : make this alarm service affecting - yes : make this alarm service affecting - noservice-affecting : make this alarm not service affecting - no : make this alarm not service affecting	alarms affect service or not <i>This element is only shown in detail mode.</i>
location	Parameter type: <Alarm::almLocation> (near-end far-end middle-end line null) Possible values: - near-end : alarm location is near - far-end : alarm location is far - middle-end : alarm location is middle - line : alarm location is line - null : alarm location not defined	alarm location: near, middle, far <i>This element is only shown in detail mode.</i>
time	Parameter type: <Sys::timeInSecs> - the time (yyyy-mm-dd:hour:minutes:secs) - unit: UTC	time in seconds when alarm was updated <i>This element is only shown in detail mode.</i>
direction	Parameter type: <Alarm::almDirection> (received transmit null) Possible values: - received : alarm is received - transmit : alarm is transmit - null : direction not defined	alarm direction: received or transmit <i>This element is only shown in detail mode.</i>
descript	Parameter type: <Alarm::AddInfoString> - additional alarm information	alarm description <i>This element is only shown in detail mode.</i>

101.35 show current alarm by filters

Command Description

show current alarms by filters

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm query xdsl-tca [ (name) [ severity <Alarm::querySeverity> ] [ servaff <Alarm::queryServAffect> ] [ port <Itf::XdslLine> ] ]
```

Command Parameters

Table 101.35-1 "show current alarm by filters" Resource Parameters

Resource Identifier	Type	Description
(name)	Format: (xtca-ne-es xtca-ne-ses xtca-ne-uas xtca-ne-day-es xtca-ne-day-ses xtca-ne-day-uas xtca-fe-es xtca-fe-ses xtca-fe-uas xtca-fe-day-es xtca-fe-day-ses xtca-fe-day-uas xtca-leftrs xtca-day-leftrs xtca-fe-leftrs xtca-fe-day-leftrs xtca-reinit xtca-day-reinit xtca-spontintrpt xtca-day-spontintrpt all) Possible values: - xtca-ne-es : errored seconds in 15 min - xtca-ne-ses : severely errored seconds in 15 min - xtca-ne-uas : unavailable seconds in 15 min - xtca-ne-day-es : errored seconds in 1 day - xtca-ne-day-ses : severely errored seconds in 1 day	alarm name of xdsl-tca

101 query current alarms by filters

Resource Identifier	Type	Description
	- xtca-ne-day-uas : unavailable seconds in 1 day - xtca-fe-es : errored seconds in 15 min - xtca-fe-ses : severely errored secs in 15 min - xtca-fe-uas : unavailable seconds in 15 min - xtca-fe-day-es : errored seconds in 1 day - xtca-fe-day-ses : severely errored secs in 1 day - xtca-fe-day-uas : unavailable seconds in 1 day - xtca-leftrs : low error free throughput seconds in 15 min - xtca-day-leftrs : low error free throughput seconds in 1 day - xtca-fe-leftrs : far end low error free throughput seconds in 15 min - xtca-fe-day-leftrs : far end low error free throughput seconds in 1 day - xtca-reinit : Reinitialization seconds in 15 min - xtca-day-reinit : Reinitialization seconds in 1 day - xtca-spontintrpt : spontaneous interrupt seconds in 15 min - xtca-day-spontintrpt : spontaneous interrupt seconds in 1 day - all : show all xDSL threshold cross alarm	
severity	Parameter type: <Alarm::querySeverity> Format: (indeterminate warning minor major critical all) Possible values: - indeterminate : alarm severity is indeterminate - warning : alarm severity is warning - minor : alarm severity is minor - major : alarm severity is major - critical : alarm severity is critical - all : all alarm severity	severity level of an alarm for reporting
servaff	Parameter type: <Alarm::queryServAffect> Format: (service-affecting noservice-affecting all) Possible values: - service-affecting : query alarm service affecting - noservice-affecting : query alarm not service affecting - all : query service affecting and not affecting alarms	serviceaffecting no
port	Parameter type: <Itf::XdslLine> Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number	identifies the physical position of the port

Command Output

Table 101.35-2 "show current alarm by filters" Display parameters

Specific Information		
name	Type	Description
aidinfo	Parameter type: <Alarm::AddInfoString> - additional alarm information	alarm AID parameters <i>This element is only shown in detail mode.</i>
type	Parameter type: <Alarm::alarmIHUBType> (equipment eqpt-holder plug-in-unit atm custom e1 ima-group ima-link redundancy shdsl ether-itf traffic-overflow qos-queue temporal spatial (software-mngt sw-mgmt) xdsl xdsl-ext xdsl-tca olt-gen eo-conv authentication bonding sfp shdsl-isam custom-ext-alarm plug-in-unit-ext sip-user-agent sip-plugin-unit sip-termination e1-sip-termination filetransfer external-device l2forward ether-tca ether-sfp megaco-media-gw megaco-sig-gw megaco-plug-unit megaco-term megaco-sig-lt eqpt-supplemental eqpt-holder-ext lsmredundancy sync mcsrc vlanport vect-line vect-board otdr)	type of the alarms that are active <i>This element is only shown in detail mode.</i>

101 query current alarms by filters

name	Type	Description
	sip-dial-plan sip-vsp sip-server bgp rip lag ihub-general vprn isis ospf ihub-l2forward vpls ihub-equip ihub-link eont-phyoam ellid epon eont-services-lan eolt-ont-tca eont-sw-dl ldp mpls sdp epipe ihub-ipv6 pim li mgmt-sec-access bfd ai tr069serv ontsnmp bulk-sync protection-group ont sfu-sup soho-sup mdu-sup ont-ani sfu-sup2 soho-sup2 mdu-sup2 sfprssi eoltrssi cfm sfpe1t1-framer sfpe1t1-clock pppcc-engine-tca eth-cfm rsvp ihub-tca eth-ring efm-oam ont-loopdetect ont-video ont-ces ont-voip	

name	Type	Description
	ont-video-ani ont-pwe ont-cese1 ont-xdsl ont-xdsl-tca ont-hpna ont-sip-agent-cfg ont-voip-cfg ont-mgc ont-ploam ont-gen ont-card ont-pots ont-lan ont-moca ont-tc-tca ont-moca-tca ont-l2uni-eth-tca olt-pon-tc-tca olt-pon-util-tca olt-chpr-util-tca olt-ont-tc-tca ont-tca ont-pots-supplemental sfu-ploam sfu-gen soho-ploam soho-gen mdu-ploam mdu-gen ont-veip ont-iphost alarm-table auto-switch channel-pair ont-cfg-dld olt-chpair-tc-tca hgu-tr069 eqpt-psu ont-protection secondary-megaco-term secondary-sip-term cas-r2-channel lldpmed pseudo-wire link-agg fcs-exceed e1t1-interface) Possible values: - equipment : equipment alarms - eqpt-holder : equipment holder alarms - plug-in-unit : plugin unit alarms - atm : ATM alarms - custom : customizable alarms - e1 : e1 alarms - ima-group : ima-group alarms - ima-link : ima-link alarms	

101 query current alarms by filters

name	Type	Description
	- redundancy : redundancy alarms - shdsl : shdsl alarms - ether-itf : ethernet interface alarms - traffic-overflow : Traffic overflow alarms - qos-queue : qos queue alarms - temporal : temporal alarms - spatial : spatial alarms - software-mngt : software management alarms - sw-mgmt : software management alarms - xdsl : xDSL alarms - xdsl-ext : other xDSL alarms - xdsl-tca : xDSL threshold cross alarms - olt-gen : OLT general alarms - eo-conv : E/O conversion related alarms - authentication : authentication related alarms - bonding : bonding-group related alarms - sfp : SFP related alarms - shdsl-isam : shdsl isam alarms - custom-ext-alarm : customizable external alarms - plug-in-unit-ext : other plugin unit alarms - sip-user-agent : sip user agent related alarms - sip-plugin-unit : sip plug in unit related alarms - sip-termination : sip termination related alarms - e1-sip-termination : E1 sip termination related alarms - filetransfer : file transfer server alarms - external-device : external device related alarms - l2forward : l2forward related alarms - ether-tca : ethernet threshold cross alarms - ether-sfp : ethernet SFP related alarms - megaco-media-gw : megaco media gateway related alarms - megaco-sig-gw : megaco signaling gateway related alarms - megaco-plug-unit : megaco plug unit related alarms - megaco-term : megaco termination related alarms - megaco-sig-lt : megaco signaling lt related alarms - eqpt-supplemental : equipment supplemental alarms - eqpt-holder-ext : other equipment holder alarms - lsmredundancy : lsm redundancy alarms - sync : synce and bits alarms - mcsrc : multicast source alarms - vlanport : vlanport alarms - vect-line : xDSL vectoring line alarms - vect-board : xDSL vectoring board alarms - otdr : otdr alarms - sip-dial-plan : sip dial plan related alarms - sip-vsp : sip vsp related alarms - sip-server : sip server related alarms - bgp : bgp related alarms - rip : rip related alarms - lag : LAG related alarms - ihub-general : IHUB general related alarms - vprn : vprn related alarms - isis : isis related alarms - ospf : ospf related alarms - ihub-l2forward : ihub-l2forward alarms - vpls : vpls related alarms - ihub-equip : ihub-equip related alarms - ihub-link : ihub-link related alarms	

name	Type	Description
	- eont-phyoam : eont phyoam related alarms - ellid : ellid related alarms - epon : epon related alarms - eont-services-lan : eon phyoam related alarms - eolt-ont-tca : eon phyoam related alarms - eont-sw-dl : eon phyoam related alarms - ldp : ldp related alarms - mpls : mpls related alarms - sdp : sdp related alarms - epipe : epipe related alarms - ihub-ipv6 : ihub-ipv6 related alarms - pim : pim related alarms - li : lawful intercept related alarms - mgmt-sec-access : management security related alarms - bfd : bfd related alarms - ai : Application Intelligence related alarms - tr069serv : tr069 server related alarms - ontsnmp : ont snmp related alarms - bulk-sync : bulk-sync related alarms - protection-group : port protection group related alarms - ont : ONT general supplemental related alarms - sfu-sup : SFU ONT general supplemental related alarms - soho-sup : SOHO ONT general supplemental related alarms - mdu-sup : MDU ONT general supplemental related alarms - ont-ani : ONT general supplemental 2 related alarms - sfu-sup2 : SFU ONT general supplemental 2 related alarms - soho-sup2 : SOHO ONT general supplemental 2 related alarms - mdu-sup2 : MDU ONT general supplemental 2 related alarms - sfprssi : SFP RSSI related alarms - eoltrssi : epon olt Sfp RSSI related alarms - cfm : Cfm related alarms - sfpe1t1-framer : SFP 2e1t1 framer alarms - sfpe1t1-clock : SFP 2e1t1 clock alarms - pppcc-engine-tca : PPPOE Cross Connect Engine TCA related alarm - eth-cfm : eth-cfm related alarms - rsvp : rsvp related alarms - ihub-tca : IHUB TCA related alarms - eth-ring : eth-ring related alarms - efm-oam : EFM-OAM related alarms - ont-loopdetect : ont loop detect related alarms - ont-video : ont services video related alarms - ont-ces : ont services ces related alarms - ont-voip : ont services voip related alarms - ont-video-ani : ont services video ani related alarms - ont-pwe : ont services pwe related alarms - ont-cese1 : ont services cese1 related alarms - ont-xdsl : ont services xdsl related alarms - ont-xdsl-tca : ont services xdsl tca related alarms - ont-hpna : ont hpna related alarms - ont-sip-agent-cfg : ont services voip sip agent config related alarms - ont-voip-cfg : ont services voip config related alarms - ont-mgc : ont mgc related alarms	

101 query current alarms by filters

name	Type	Description
	- ont-ploam : ONT PLOAM related alarms - ont-gen : ONT GENERAL related alarms - ont-card : ONT Subscriber Card related alarms - ont-pots : ONT Services POTS related alarms - ont-lan : ONT Services LAN related alarms - ont-moca : ONT MoCA related alarms - ont-tc-tca : ONT TC TCA related alarms - ont-moca-tca : ONT MoCA TCA related alarms - ont-l2uni-eth-tca : ONT L2 UNI Ethernet TCA related alarms - olt-pon-tc-tca : OLT PON TC TCA related alarms - olt-pon-util-tca : OLT PON utilization TCA related alarms - olt-chpr-util-tca : OLT channel-pair utilization TCA related alarms - olt-ont-tc-tca : OLT ONT TC TCA related alarms - ont-tca : ONT TCA related alarms - ont-pots-supplemental : ONT POTS Supplemental related alarms - sfu-ploam : SFU ONT PLOAM related alarms - sfu-gen : SFU ONT general related alarms - soho-ploam : SOHO ONT PLOAM related alarms - soho-gen : SOHO ONT general related alarms - mdu-ploam : MDU ONT PLOAM related alarms - mdu-gen : MDU ONT general related alarms - ont-veip : ONT VEIP related alarms - ont-iphost : ONT IP HOST related alarms - alarm-table : alarm table related alarms - auto-switch : auto-switch related alarms - channel-pair : channel pair related alarms - ont-cfg-dld : ont configure file download related alarms - olt-chpair-tc-tca : OLT CHANNELPAIR TC TCA related alarms - hgu-tr069 : hgu tr069 related alarms - eqpt-psu : equipment psu alarms - ont-protection : ONT protection related alarms - secondary-megaco-term : secondary megaco termination related alarms - secondary-sip-term : secondary sip termination related alarms - cas-r2-channel : CAS R2 channel related alarms - lldpmed : lldpmed alarms - pseudo-wire : pseudo Wire related alarms - link-agg : Link aggregation related alarms - fcs-exceed : FCS auto-recovery related alarms - e1t1-interface : E1/T1 physical interfaces related alarms	
name	Parameter type: <Alarm::almtypeXdsltca> (xtca-ne-es xtca-ne-ses xtca-ne-uas xtca-ne-day-es xtca-ne-day-ses xtca-ne-day-uas xtca-fe-es xtca-fe-ses xtca-fe-uas xtca-fe-day-es xtca-fe-day-ses)	alarm name that are active <i>This element is only shown in detail mode.</i>

name	Type	Description
	xtca-fe-day-uas xtca-leftrs xtca-day-leftrs xtca-fe-leftrs xtca-fe-day-leftrs xtca-reinit xtca-day-reinit xtca-spontintrpt xtca-day-spontintrpt all) Possible values: - xtca-ne-es : errored seconds in 15 min - xtca-ne-ses : severely errored seconds in 15 min - xtca-ne-uas : unavailable seconds in 15 min - xtca-ne-day-es : errored seconds in 1 day - xtca-ne-day-ses : severely errored seconds in 1 day - xtca-ne-day-uas : unavailable seconds in 1 day - xtca-fe-es : errored seconds in 15 min - xtca-fe-ses : severely errored secs in 15 min - xtca-fe-uas : unavailable seconds in 15 min - xtca-fe-day-es : errored seconds in 1 day - xtca-fe-day-ses : severely errored secs in 1 day - xtca-fe-day-uas : unavailable seconds in 1 day - xtca-leftrs : low error free throughput seconds in 15 min - xtca-day-leftrs : low error free throughput seconds in 1 day - xtca-fe-leftrs : far end low error free throughput seconds in 15 min - xtca-fe-day-leftrs : far end low error free throughput seconds in 1 day - xtca-reinit : Reinitialization seconds in 15 min - xtca-day-reinit : Reinitialization seconds in 1 day - xtca-spontintrpt : spontaneous interrupt seconds in 15 min - xtca-day-spontintrpt : spontaneous interrupt seconds in 1 day - all : show all xDSL threshold cross alarm	
severity	Parameter type: <Alarm::AlarmSeverity> (indeterminate warning minor major critical) Possible values: - indeterminate : alarm severity is indeterminate - warning : alarm severity is warning - minor : alarm severity is minor - major : alarm severity is major - critical : alarm severity is critical	the alarms severity level <i>This element is only shown in detail mode.</i>
servaff	Parameter type: <Alarm::alarmServAffect> ((service-affecting yes) (noservice-affecting no)) Possible values: - service-affecting : make this alarm service affecting - yes : make this alarm service affecting - noservice-affecting : make this alarm not service affecting - no : make this alarm not service affecting	alarms affect service or not <i>This element is only shown in detail mode.</i>
location	Parameter type: <Alarm::almLocation> (near-end	alarm location: near, middle, far <i>This element is only shown in</i>

101 query current alarms by filters

name	Type	Description
	far-end middle-end line null) Possible values: - near-end : alarm location is near - far-end : alarm location is far - middle-end : alarm location is middle - line : alarm location is line - null : alarm location not defined	<i>detail mode.</i>
time	Parameter type: <Sys::timeInSecs> - the time (yyyy-mm-dd:hour:minutes:secs) - unit: UTC	time in seconds when alarm was updated <i>This element is only shown in detail mode.</i>
direction	Parameter type: <Alarm::almDirection> (received transmit null) Possible values: - received : alarm is received - transmit : alarm is transmit - null : direction not defined	alarm direction: received or transmit <i>This element is only shown in detail mode.</i>
descript	Parameter type: <Alarm::AddInfoString> - additional alarm information	alarm description <i>This element is only shown in detail mode.</i>

101.36 show current alarm by filters

Command Description

show current alarms by filters

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm query vect-board [ (name) [ severity <Alarm::querySeverity> ] [ servaff <Alarm::queryServAffect> ]
[ board-index <Equipm::EqptVpSlotIndex> ] ]
```

Command Parameters

Table 101.36-1 "show current alarm by filters" Resource Parameters

Resource Identifier	Type	Description
(name)	Format: (vect-vp-lt-mismatch vect-inv-qsf vect-vp-lt-fail vect-no-gain-at-init all) Possible values: - vect-vp-lt-mismatch : actual vp-lt connection(s) do not match expected vp-lt connection(s) or vp-lt connection lost - vect-inv-qsf : qsf has no valid Nokia ID - vect-vp-lt-fail : vp-lt connection not operational - vect-no-gain-at-init : Lines cannot train in gain-at-init mode - all : show all vectoring board alarm	alarm name of vect-board
severity	Parameter type: <Alarm::querySeverity> Format: (indeterminate warning minor major critical all) Possible values: - indeterminate : alarm severity is indeterminate - warning : alarm severity is warning - minor : alarm severity is minor - major : alarm severity is major - critical : alarm severity is critical	severity level of an alarm for reporting

101 query current alarms by filters

Resource Identifier	Type	Description
	- all : all alarm severity	
servaff	Parameter type: <Alarm::queryServAffect> Format: (service-affecting noservice-affecting all) Possible values: - service-affecting : query alarm service affecting - noservice-affecting : query alarm not service affecting - all : query service affecting and not affecting alarms	serviceaffecting no serviceaffecting
board-index	Parameter type: <Equipm::EqptVpSlotIndex> Format: (ctrl : <Eqpt::RackId> / <Eqpt::ShelfId> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId>) Possible values: - ctrl : ctrl-slot Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number	the index of the board

Command Output

Table 101.36-2 "show current alarm by filters" Display parameters

Specific Information		
name	Type	Description
aidinfo	Parameter type: <Alarm::AddInfoString> - additional alarm information	alarm AID parameters <i>This element is only shown in detail mode.</i>
type	Parameter type: <Alarm::alarmIHUBType> (equipment eqpt-holder plug-in-unit atm custom e1 ima-group ima-link redundancy shdsl ether-itf traffic-overflow qos-queue temporal spatial (software-mngt sw-mgmt) xdsl xdsl-ext xdsl-tca olt-gen eo-conv authentication bonding sfp	type of the alarms that are active <i>This element is only shown in detail mode.</i>

name	Type	Description
	shdsl-isam	
	custom-ext-alarm	
	plug-in-unit-ext	
	sip-user-agent	
	sip-plugin-unit	
	sip-termination	
	e1-sip-termination	
	filetransfer	
	external-device	
	l2forward	
	ether-tca	
	ether-sfp	
	megaco-media-gw	
	megaco-sig-gw	
	megaco-plug-unit	
	megaco-term	
	megaco-sig-lt	
	eqpt-supplemental	
	eqpt-holder-ext	
	lsmredundancy	
	sync	
	mcsrc	
	vlanport	
	vect-line	
	vect-board	
	otdr	
	sip-dial-plan	
	sip-vsp	
	sip-server	
	bgp	
	rip	
	lag	
	ihub-general	
	vprn	
	isis	
	ospf	
	ihub-l2forward	
	vpls	
	ihub-equip	
	ihub-link	
	eont-phyoam	
	ellid	
	epon	
	eont-services-lan	
	eolt-ont-tca	
	eont-sw-dl	
	ldp	
	mpls	
	sdp	
	epipe	
	ihub-ipv6	
	pim	
	li	
	mgmt-sec-access	
	bfd	
	ai	
	tr069serv	

101 query current alarms by filters

name	Type	Description
	ontsnmp bulk-sync protection-group ont sfu-sup soho-sup mdu-sup ont-ani sfu-sup2 soho-sup2 mdu-sup2 sfprssi eoltrssi cfm sfpe1t1-framer sfpe1t1-clock pppcc-engine-tca eth-cfm rsvp ihub-tca eth-ring efm-oam ont-loopdetect ont-video ont-ces ont-voip ont-video-ani ont-pwe ont-cese1 ont-xdsl ont-xdsl-tca ont-hpna ont-sip-agent-cfg ont-voip-cfg ont-mgc ont-ploam ont-gen ont-card ont-pots ont-lan ont-moca ont-tc-tca ont-moca-tca ont-l2uni-eth-tca olt-pon-tc-tca olt-pon-util-tca olt-chpr-util-tca olt-ont-tc-tca ont-tca ont-pots-supplemental sfu-ploam sfu-gen soho-ploam soho-gen mdu-ploam mdu-gen ont-veip	

name	Type	Description
	ont-iphost alarm-table auto-switch channel-pair ont-cfg-dld olt-chpair-tc-tca hgu-tr069 eqpt-psu ont-protection secondary-megaco-term secondary-sip-term cas-r2-channel lldpmed pseudo-wire link-agg fcs-exceed e1t1-interface) Possible values: - equipment : equipment alarms - eqpt-holder : equipment holder alarms - plug-in-unit : plugin unit alarms - atm : ATM alarms - custom : customizable alarms - e1 : e1 alarms - ima-group : ima-group alarms - ima-link : ima-link alarms - redundancy : redundancy alarms - shdsl : shdsl alarms - ether-itf : ethernet interface alarms - traffic-overflow : Traffic overflow alarms - qos-queue : qos queue alarms - temporal : temporal alarms - spatial : spatial alarms - software-mngt : software management alarms - sw-mgmt : software management alarms - xdsl : xDSL alarms - xdsl-ext : other xDSL alarms - xdsl-tca : xDSL threshold cross alarms - olt-gen : OLT general alarms - eo-conv : E/O conversion related alarms - authentication : authentication related alarms - bonding : bonding-group related alarms - sfp : SFP related alarms - shdsl-isam : shdsl isam alarms - custom-ext-alarm : customizable external alarms - plug-in-unit-ext : other plugin unit alarms - sip-user-agent : sip user agent related alarms - sip-plugin-unit : sip plug in unit related alarms - sip-termination : sip termination related alarms - e1-sip-termination : E1 sip termination related alarms - filetransfer : file transfer server alarms - external-device : external device related alarms - l2forward : l2forward related alarms - ether-tca : ethernet threshold cross alarms - ether-sfp : ethernet SFP related alarms - megaco-media-gw : megaco media gateway related alarms - megaco-sig-gw : megaco signaling gateway related alarms	

101 query current alarms by filters

name	Type	Description
	- megaco-plug-unit : megaco plug unit related alarms - megaco-term : megaco termination related alarms - megaco-sig-lt : megaco signaling lt related alarms - eqpt-supplemental : equipment supplemental alarms - eqpt-holder-ext : other equipment holder alarms - lsmredundancy : lsm redundancy alarms - sync : synce and bits alarms - mcsrc : multicast source alarms - vlanport : vlanport alarms - vect-line : xDSL vectoring line alarms - vect-board : xDSL vectoring board alarms - otdr : otdr alarms - sip-dial-plan : sip dial plan related alarms - sip-vsp : sip vsp related alarms - sip-server : sip server related alarms - bgp : bgp related alarms - rip : rip related alarms - lag : LAG related alarms - ihub-general : IHUB general related alarms - vprn : vprn related alarms - isis : isis related alarms - ospf : ospf related alarms - ihub-l2forward : ihub-l2forward alarms - vpls : vpls related alarms - ihub-equip : ihub-equip related alarms - ihub-link : ihub-link related alarms - eont-phyoam : eont phyoam related alarms - ellid : ellid related alarms - epon : epon related alarms - eont-services-lan : eon phyoam related alarms - eolt-ont-tca : eon phyoam related alarms - eont-sw-dl : eon phyoam related alarms - ldp : ldp related alarms - mpls : mpls related alarms - sdp : sdp related alarms - epipe : epipe related alarms - ihub-ipv6 : ihub-ipv6 related alarms - pim : pim related alarms - li : lawful intercept related alarms - mgmt-sec-access : management security related alarms - bfd : bfd related alarms - ai : Application Intelligence related alarms - tr069serv : tr069 server related alarms - ontsnmp : ont snmp related alarms - bulk-sync : bulk-sync related alarms - protection-group : port protection group related alarms - ont : ONT general supplemental related alarms - sfu-sup : SFU ONT general supplemental related alarms - soho-sup : SOHO ONT general supplemental related alarms - mdu-sup : MDU ONT general supplemental related alarms - ont-ani : ONT general supplemental 2 related alarms - sfu-sup2 : SFU ONT general supplemental 2 related alarms - soho-sup2 : SOHO ONT general supplemental 2 related alarms - mdu-sup2 : MDU ONT general supplemental 2 related alarms	

name	Type	Description
	- sfprssi : SFP RSSI related alarms - eoltrssi : epon olt Sfp RSSI related alarms - cfm : Cfm related alarms - sfpe1t1-framer : SFP 2e1t1 framer alarms - sfpe1t1-clock : SFP 2e1t1 clock alarms - pppcc-engine-tca : PPPOE Cross Connect Engine TCA related alarm - eth-cfm : eth-cfm related alarms - rsvp : rsvp related alarms - ihub-tca : IHUB TCA related alarms - eth-ring : eth-ring related alarms - efm-oam : EFM-OAM related alarms - ont-loopdetect : ont loop detect related alarms - ont-video : ont services video related alarms - ont-ces : ont services ces related alarms - ont-voip : ont services voip related alarms - ont-video-ani : ont services video ani related alarms - ont-pwe : ont services pwe related alarms - ont-cese1 : ont services cese1 related alarms - ont-xdsl : ont services xdsl related alarms - ont-xdsl-tca : ont services xdsl tca related alarms - ont-hpna : ont hpna related alarms - ont-sip-agent-cfg : ont services voip sip agent config related alarms - ont-voip-cfg : ont services voip config related alarms - ont-mgc : ont mgc related alarms - ont-ploam : ONT PLOAM related alarms - ont-gen : ONT GENERAL related alarms - ont-card : ONT Subscriber Card related alarms - ont-pots : ONT Services POTS related alarms - ont-lan : ONT Services LAN related alarms - ont-moca : ONT MoCA related alarms - ont-tc-tca : ONT TC TCA related alarms - ont-moca-tca : ONT MoCA TCA related alarms - ont-l2uni-eth-tca : ONT L2 UNI Ethernet TCA related alarms - olt-pon-tc-tca : OLT PON TC TCA related alarms - olt-pon-util-tca : OLT PON utilization TCA related alarms - olt-chpr-util-tca : OLT channel-pair utilization TCA related alarms - olt-ont-tc-tca : OLT ONT TC TCA related alarms - ont-tca : ONT TCA related alarms - ont-pots-supplemental : ONT POTS Supplemental related alarms - sfu-ploam : SFU ONT PLOAM related alarms - sfu-gen : SFU ONT general related alarms - soho-ploam : SOHO ONT PLOAM related alarms - soho-gen : SOHO ONT general related alarms - mdu-ploam : MDU ONT PLOAM related alarms - mdu-gen : MDU ONT general related alarms - ont-veip : ONT VEIP related alarms - ont-iphost : ONT IP HOST related alarms - alarm-table : alarm table related alarms - auto-switch : auto-switch related alarms - channel-pair : channel pair related alarms - ont-cfg-dld : ont configure file download related alarms - olt-chpair-tc-tca : OLT CHANNELPAIR TC TCA related	

101 query current alarms by filters

name	Type	Description
	alarms - hgu-tr069 : hgu tr069 related alarms - eqpt-psu : equipment psu alarms - ont-protection : ONT protection related alarms - secondary-megaco-term : secondary megaco termination related alarms - secondary-sip-term : secondary sip termination related alarms - cas-r2-channel : CAS R2 channel related alarms - lldpmed : lldpmed alarms - pseudo-wire : pseudo Wire related alarms - link-agg : Link aggregation related alarms - fcs-exceed : FCS auto-recovery related alarms - e1t1-interface : E1/T1 physical interfaces related alarms	
name	Parameter type: <Alarm::almtypeVectboard> (vect-vp-lt-mismatch vect-inv-qsfp vect-vp-lt-fail vect-no-gain-at-init all) Possible values: - vect-vp-lt-mismatch : actual vp-lt connection(s) do not match expected vp-lt connection(s) or vp-lt connection lost - vect-inv-qsfp : qsfp has no valid Nokia ID - vect-vp-lt-fail : vp-lt connection not operational - vect-no-gain-at-init : Lines cannot train in gain-at-init mode - all : show all vectoring board alarm	alarm name that are active <i>This element is only shown in detail mode.</i>
severity	Parameter type: <Alarm::AlarmSeverity> (indeterminate warning minor major critical) Possible values: - indeterminate : alarm severity is indeterminate - warning : alarm severity is warning - minor : alarm severity is minor - major : alarm severity is major - critical : alarm severity is critical	the alarms severity level <i>This element is only shown in detail mode.</i>
servaff	Parameter type: <Alarm::alarmServAffect> ((service-affecting yes) (noservice-affecting no)) Possible values: - service-affecting : make this alarm service affecting - yes : make this alarm service affecting - noservice-affecting : make this alarm not service affecting - no : make this alarm not service affecting	alarms affect service or not <i>This element is only shown in detail mode.</i>
time	Parameter type: <Sys::timeInSecs> - the time (yyyy-mm-dd:hour:minutes:secs) - unit: UTC	time in seconds when alarm was updated <i>This element is only shown in detail mode.</i>
descript	Parameter type: <Alarm::AddInfoString> - additional alarm information	alarm description <i>This element is only shown in detail mode.</i>

101.37 show current alarm by filters

Command Description

show current alarms by filters

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm query vect-line [ (name) [ severity <Alarm::querySeverity> ] [ servaff <Alarm::queryServAffect> ] [ port <Itf::XdslLine> ] ]
```

Command Parameters

Table 101.37-1 "show current alarm by filters" Resource Parameters

Resource Identifier	Type	Description
(name)	Format: (vectline-xtc-var-vict vectline-xtc-var-dist vectline-corp-errf vect-cpe-cap-mismatch vectline-conf_notfeas all) Possible values: - vectline-xtc-var-vict : excessive victim crosstalk coefficients variation - vectline-xtc-var-dist : excessive disturber crosstalk coefficients variation - vectline-corp-errf : corrupted or missing errorf-samples - vect-cpe-cap-mismatch : not allowed Vectoring CPE connected - vectline-conf_notfeas : vect line configuration not feasible - all : show all vectoring line alarm	alarm name of vect-line
severity	Parameter type: <Alarm::querySeverity> Format: (indeterminate warning minor major critical all) Possible values: - indeterminate : alarm severity is indeterminate - warning : alarm severity is warning	severity level of an alarm for reporting

101 query current alarms by filters

Resource Identifier	Type	Description
	- minor : alarm severity is minor - major : alarm severity is major - critical : alarm severity is critical - all : all alarm severity	
servaff	Parameter type: <Alarm::queryServAffect> Format: (service-affecting noservice-affecting all) Possible values: - service-affecting : query alarm service affecting - noservice-affecting : query alarm not service affecting - all : query service affecting and not affecting alarms	serviceaffecting no serviceaffecting
port	Parameter type: <Itf::XdslLine> Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number	the physical position of the port

Command Output

Table 101.37-2 "show current alarm by filters" Display parameters

Specific Information		
name	Type	Description
aidinfo	Parameter type: <Alarm::AddInfoString> - additional alarm information	alarm AID parameters <i>This element is only shown in detail mode.</i>
type	Parameter type: <Alarm::alarmIHUBType> (equipment eqpt-holder plug-in-unit atm custom e1 ima-group ima-link redundancy shdsl ether-itf traffic-overflow qos-queue temporal spatial (software-mngt sw-mgmt) xdsl xdsl-ext xdsl-tca olt-gen eo-conv	type of the alarms that are active <i>This element is only shown in detail mode.</i>

name	Type	Description
	authentication bonding sfp shdsl-isam custom-ext-alarm plug-in-unit-ext sip-user-agent sip-plugin-unit sip-termination e1-sip-termination filetransfer external-device l2forward ether-tca ether-sfp megaco-media-gw megaco-sig-gw megaco-plug-unit megaco-term megaco-sig-lt eqpt-supplemental eqpt-holder-ext lsmredundancy sync mcsrc vlanport vect-line vect-board otdr sip-dial-plan sip-vsp sip-server bgp rip lag ihub-general vprn isis ospf ihub-l2forward vpls ihub-equip ihub-link eont-phyoam ellid epon eont-services-lan eolt-ont-tca eont-sw-dl ldp mpls sdp epipe ihub-ipv6 pim li mgmt-sec-access	

101 query current alarms by filters

name	Type	Description
	bfd	
	ai	
	tr069serv	
	ontsnmp	
	bulk-sync	
	protection-group	
	ont	
	sfu-sup	
	soho-sup	
	mdu-sup	
	ont-ani	
	sfu-sup2	
	soho-sup2	
	mdu-sup2	
	sfprssi	
	eoltrssi	
	cfm	
	sfpe1t1-framer	
	sfpe1t1-clock	
	pppcc-engine-tca	
	eth-cfm	
	rsvp	
	ihub-tca	
	eth-ring	
	efm-oam	
	ont-loopdetect	
	ont-video	
	ont-ces	
	ont-voip	
	ont-video-ani	
	ont-pwe	
	ont-cese1	
	ont-xdsl	
	ont-xdsl-tca	
	ont-hpna	
	ont-sip-agent-cfg	
	ont-voip-cfg	
	ont-mgc	
	ont-ploam	
	ont-gen	
	ont-card	
	ont-pots	
	ont-lan	
	ont-moca	
	ont-tc-tca	
	ont-moca-tca	
	ont-l2uni-eth-tca	
	olt-pon-tc-tca	
	olt-pon-util-tca	
	olt-chpr-util-tca	
	olt-ont-tc-tca	
	ont-tca	
	ont-pots-supplemental	
	sfu-ploam	
	sfu-gen	
	soho-ploam	
	soho-gen	

name	Type	Description
	mdu-ploam mdu-gen ont-veip ont-iphost alarm-table auto-switch channel-pair ont-cfg-dld olt-chpair-tc-tca hgu-tr069 eqpt-psu ont-protection secondary-megaco-term secondary-sip-term cas-r2-channel lldpmed pseudo-wire link-agg fcs-exceed e1t1-interface) Possible values: - equipment : equipment alarms - eqpt-holder : equipment holder alarms - plug-in-unit : plugin unit alarms - atm : ATM alarms - custom : customizable alarms - e1 : e1 alarms - ima-group : ima-group alarms - ima-link : ima-link alarms - redundancy : redundancy alarms - shdsl : shdsl alarms - ether-itf : ethernet interface alarms - traffic-overflow : Traffic overflow alarms - qos-queue : qos queue alarms - temporal : temporal alarms - spatial : spatial alarms - software-mngt : software management alarms - sw-mgmt : software management alarms - xdsl : xDSL alarms - xdsl-ext : other xDSL alarms - xdsl-tca : xDSL threshold cross alarms - olt-gen : OLT general alarms - eo-conv : E/O conversion related alarms - authentication : authentication related alarms - bonding : bonding-group related alarms - sfp : SFP related alarms - shdsl-isam : shdsl isam alarms - custom-ext-alarm : customizable external alarms - plug-in-unit-ext : other plugin unit alarms - sip-user-agent : sip user agent related alarms - sip-plugin-unit : sip plug in unit related alarms - sip-termination : sip termination related alarms - e1-sip-termination : E1 sip termination related alarms - filetransfer : file transfer server alarms - external-device : external device related alarms - l2forward : l2forward related alarms - ether-tca : ethernet threshold cross alarms	

101 query current alarms by filters

name	Type	Description
	- ether-sfp : ethernet SFP related alarms - megaco-media-gw : megaco media gateway related alarms - megaco-sig-gw : megaco signaling gateway related alarms - megaco-plug-unit : megaco plug unit related alarms - megaco-term : megaco termination related alarms - megaco-sig-lt : megaco signaling lt related alarms - eqpt-supplemental : equipment supplemental alarms - eqpt-holder-ext : other equipment holder alarms - lsmredundancy : lsm redundancy alarms - sync : synce and bits alarms - mcsrc : multicast source alarms - vlanport : vlanport alarms - vect-line : xDSL vectoring line alarms - vect-board : xDSL vectoring board alarms - otdr : otdr alarms - sip-dial-plan : sip dial plan related alarms - sip-vsp : sip vsp related alarms - sip-server : sip server related alarms - bgp : bgp related alarms - rip : rip related alarms - lag : LAG related alarms - ihub-general : IHUB general related alarms - vprn : vprn related alarms - isis : isis related alarms - ospf : ospf related alarms - ihub-l2forward : ihub-l2forward alarms - vpls : vpls related alarms - ihub-equip : ihub-equip related alarms - ihub-link : ihub-link related alarms - eont-phyoam : eont phyoam related alarms - ellid : ellid related alarms - epon : epon related alarms - eont-services-lan : eon phyoam related alarms - eolt-ont-tca : eon phyoam related alarms - eont-sw-dl : eon phyoam related alarms - ldp : ldp related alarms - mpls : mpls related alarms - sdp : sdp related alarms - epipe : epipe related alarms - ihub-ipv6 : ihub-ipv6 related alarms - pim : pim related alarms - li : lawful intercept related alarms - mgmt-sec-access : management security related alarms - bfd : bfd related alarms - ai : Application Intelligence related alarms - tr069serv : tr069 server related alarms - ontsnmp : ont snmp related alarms - bulk-sync : bulk-sync related alarms - protection-group : port protection group related alarms - ont : ONT general supplemental related alarms - sfu-sup : SFU ONT general supplemental related alarms - soho-sup : SOHO ONT general supplemental related alarms - mdu-sup : MDU ONT general supplemental related alarms - ont-ani : ONT general supplemental 2 related alarms - sfu-sup2 : SFU ONT general supplemental 2 related alarms - soho-sup2 : SOHO ONT general supplemental 2 related	

name	Type	Description
	alarms - mdu-sup2 : MDU ONT general supplemental 2 related alarms - sfrssi : SFP RSSI related alarms - eoltrssi : epon olt Sfp RSSI related alarms - cfm : Cfm related alarms - sfpe1t1-framer : SFP 2e1t1 framer alarms - sfpe1t1-clock : SFP 2e1t1 clock alarms - pppcc-engine-tca : PPPOE Cross Connect Engine TCA related alarm - eth-cfm : eth-cfm related alarms - rsvp : rsvp related alarms - ihub-tca : IHUB TCA related alarms - eth-ring : eth-ring related alarms - efm-oam : EFM-OAM related alarms - ont-loopdetect : ont loop detect related alarms - ont-video : ont services video related alarms - ont-ces : ont services ces related alarms - ont-voip : ont services voip related alarms - ont-video-ani : ont services video ani related alarms - ont-pwe : ont services pwe related alarms - ont-cese1 : ont services cese1 related alarms - ont-xdsl : ont services xdsl related alarms - ont-xdsl-tca : ont services xdsl tca related alarms - ont-hpna : ont hpna related alarms - ont-sip-agent-cfg : ont services voip sip agent config related alarms - ont-voip-cfg : ont services voip config related alarms - ont-mgc : ont mgc related alarms - ont-ploam : ONT PLOAM related alarms - ont-gen : ONT GENERAL related alarms - ont-card : ONT Subscriber Card related alarms - ont-pots : ONT Services POTS related alarms - ont-lan : ONT Services LAN related alarms - ont-moca : ONT MoCA related alarms - ont-tc-tca : ONT TC TCA related alarms - ont-moca-tca : ONT MoCA TCA related alarms - ont-l2uni-eth-tca : ONT L2 UNI Ethernet TCA related alarms - olt-pon-tc-tca : OLT PON TC TCA related alarms - olt-pon-util-tca : OLT PON utilization TCA related alarms - olt-chpr-util-tca : OLT channel-pair utilization TCA related alarms - olt-ont-tc-tca : OLT ONT TC TCA related alarms - ont-tca : ONT TCA related alarms - ont-pots-supplemental : ONT POTS Supplemental related alarms - sfu-ploam : SFU ONT PLOAM related alarms - sfu-gen : SFU ONT general related alarms - soho-ploam : SOHO ONT PLOAM related alarms - soho-gen : SOHO ONT general related alarms - mdu-ploam : MDU ONT PLOAM related alarms - mdu-gen : MDU ONT general related alarms - ont-veip : ONT VEIP related alarms - ont-iphost : ONT IP HOST related alarms - alarm-table : alarm table related alarms - auto-switch : auto-switch related alarms	

101 query current alarms by filters

name	Type	Description
	- channel-pair : channel pair related alarms - ont-cfg-dld : ont configure file download related alarms - olt-chpair-tc-tca : OLT CHANNELPAIR TC TCA related alarms - hgu-tr069 : hgu tr069 related alarms - eqpt-psu : equipment psu alarms - ont-protection : ONT protection related alarms - secondary-megaco-term : secondary megaco termination related alarms - secondary-sip-term : secondary sip termination related alarms - cas-r2-channel : CAS R2 channel related alarms - lldpmed : lldpmed alarms - pseudo-wire : pseudo Wire related alarms - link-agg : Link aggregation related alarms - fcs-exceed : FCS auto-recovery related alarms - e1t1-interface : E1/T1 physical interfaces related alarms	
name	Parameter type: <Alarm::alarmTypeVectline> (vectline-xtc-var-vict vectline-xtc-var-dist vectline-corp-errf vect-cpe-cap-mismatch vectline-conf_notfeas all) Possible values: - vectline-xtc-var-vict : excessive victim crosstalk coefficients variation - vectline-xtc-var-dist : excessive disturber crosstalk coefficients variation - vectline-corp-errf : corrupted or missing errorf-samples - vect-cpe-cap-mismatch : not allowed Vectoring CPE connected - vectline-conf_notfeas : vect line configuration not feasible - all : show all vectoring line alarm	alarm name that are active <i>This element is only shown in detail mode.</i>
severity	Parameter type: <Alarm::AlarmSeverity> (indeterminate warning minor major critical) Possible values: - indeterminate : alarm severity is indeterminate - warning : alarm severity is warning - minor : alarm severity is minor - major : alarm severity is major - critical : alarm severity is critical	the alarms severity level <i>This element is only shown in detail mode.</i>
servaff	Parameter type: <Alarm::alarmServAffect> ((service-affecting yes) (noservice-affecting no)) Possible values: - service-affecting : make this alarm service affecting - yes : make this alarm service affecting - noservice-affecting : make this alarm not service affecting - no : make this alarm not service affecting	alarms affect service or not <i>This element is only shown in detail mode.</i>
time	Parameter type: <Sys::timeInSecs> - the time (yyyy-mm-dd:hour:minutes:secs) - unit: UTC	time in seconds when alarm was updated <i>This element is only shown in</i>

101 query current alarms by filters

name	Type	Description
		<i>detail mode.</i>
descript	Parameter type: <Alarm::AddInfoString> - additional alarm information	alarm description <i>This element is only shown in detail mode.</i>

101.38 show current alarm by filters

Command Description

show current alarms by filters

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm query eo-conversion [ (name) [ severity <Alarm::querySeverity> ] [ servaff
<Alarm::queryServAffect> ] [ port <SignedInteger> ] ]
```

Command Parameters

Table 101.38-1 "show current alarm by filters" Resource Parameters

Resource Identifier	Type	Description
(name)	Format: all Possible values: - all : show all E/O conversion alarm	alarm name of eo-conversion
severity	Parameter type: <Alarm::querySeverity> Format: (indeterminate warning minor major critical all) Possible values: - indeterminate : alarm severity is indeterminate - warning : alarm severity is warning - minor : alarm severity is minor - major : alarm severity is major - critical : alarm severity is critical - all : all alarm severity	severity level of an alarm for reporting
servaff	Parameter type: <Alarm::queryServAffect> Format: (service-affecting noservice-affecting all) Possible values: - service-affecting : query alarm service affecting - noservice-affecting : query alarm not service affecting - all : query service affecting and not affecting alarms	serviceaffecting no

Resource Identifier	Type	Description
port	Parameter type: <SignedInteger> Format: - a signed integer	the number of the port

Command Output

Table 101.38-2 "show current alarm by filters" Display parameters

Specific Information		
name	Type	Description
aidinfo	Parameter type: <Alarm::AddInfoString> - additional alarm information	alarm AID parameters <i>This element is only shown in detail mode.</i>
type	Parameter type: <Alarm::alarmIHUBType> (equipment eqpt-holder plug-in-unit atm custom e1 ima-group ima-link redundancy shdsl ether-itf traffic-overflow qos-queue temporal spatial (software-mngt sw-mgmt) xdsl xdsl-ext xdsl-tca olt-gen eo-conv authentication bonding sfp shdsl-isam custom-ext-alarm plug-in-unit-ext sip-user-agent sip-plugin-unit sip-termination e1-sip-termination filetransfer external-device l2forward ether-tca ether-sfp megaco-media-gw megaco-sig-gw megaco-plug-unit megaco-term megaco-sig-lt eqpt-supplemental eqpt-holder-ext	type of the alarms that are active <i>This element is only shown in detail mode.</i>

101 query current alarms by filters

name	Type	Description
	lsmredundancy	
	sync	
	mcsrc	
	vlanport	
	vect-line	
	vect-board	
	otdr	
	sip-dial-plan	
	sip-vsp	
	sip-server	
	bgp	
	rip	
	lag	
	ihub-general	
	vprn	
	isis	
	ospf	
	ihub-l2forward	
	vpls	
	ihub-equip	
	ihub-link	
	eont-phyoam	
	ellid	
	epon	
	eont-services-lan	
	eolt-ont-tca	
	eont-sw-dl	
	ldp	
	mpls	
	sdp	
	epipe	
	ihub-ipv6	
	pim	
	li	
	mgmt-sec-access	
	bfd	
	ai	
	tr069serv	
	ontsnmp	
	bulk-sync	
	protection-group	
	ont	
	sfu-sup	
	soho-sup	
	mdu-sup	
	ont-ani	
	sfu-sup2	
	soho-sup2	
	mdu-sup2	
	sfprssi	
	eoltrssi	
	cfm	
	sfpe1t1-framer	
	sfpe1t1-clock	
	pppcc-engine-tca	
	eth-cfm	
	rsvp	

name	Type	Description
	ihub-tca eth-ring efm-oam ont-loopdetect ont-video ont-ces ont-voip ont-video-ani ont-pwe ont-cese1 ont-xdsl ont-xdsl-tca ont-hpna ont-sip-agent-cfg ont-voip-cfg ont-mgc ont-ploam ont-gen ont-card ont-pots ont-lan ont-moca ont-tc-tca ont-moca-tca ont-l2uni-eth-tca olt-pon-tc-tca olt-pon-util-tca olt-chpr-util-tca olt-ont-tc-tca ont-tca ont-pots-supplemental sfu-ploam sfu-gen soho-ploam soho-gen mdu-ploam mdu-gen ont-veip ont-iphost alarm-table auto-switch channel-pair ont-cfg-dld olt-chpair-tc-tca hgu-tr069 eqpt-psu ont-protection secondary-megaco-term secondary-sip-term cas-r2-channel lldpmed pseudo-wire link-agg fcs-exceed e1t1-interface) Possible values: - equipment : equipment alarms	

101 query current alarms by filters

name	Type	Description
	- eqpt-holder : equipment holder alarms - plug-in-unit : plugin unit alarms - atm : ATM alarms - custom : customizable alarms - e1 : e1 alarms - ima-group : ima-group alarms - ima-link : ima-link alarms - redundancy : redundancy alarms - shdsl : shdsl alarms - ether-itf : ethernet interface alarms - traffic-overflow : Traffic overflow alarms - qos-queue : qos queue alarms - temporal : temporal alarms - spatial : spatial alarms - software-mngt : software management alarms - sw-mgmt : software management alarms - xdsl : xDSL alarms - xdsl-ext : other xDSL alarms - xdsl-tca : xDSL threshold cross alarms - olt-gen : OLT general alarms - eo-conv : E/O conversion related alarms - authentication : authentication related alarms - bonding : bonding-group related alarms - sfp : SFP related alarms - shdsl-isam : shdsl isam alarms - custom-ext-alarm : customizable external alarms - plug-in-unit-ext : other plugin unit alarms - sip-user-agent : sip user agent related alarms - sip-plugin-unit : sip plug in unit related alarms - sip-termination : sip termination related alarms - e1-sip-termination : E1 sip termination related alarms - filetransfer : file transfer server alarms - external-device : external device related alarms - l2forward : l2forward related alarms - ether-tca : ethernet threshold cross alarms - ether-sfp : ethernet SFP related alarms - megaco-media-gw : megaco media gateway related alarms - megaco-sig-gw : megaco signaling gateway related alarms - megaco-plug-unit : megaco plug unit related alarms - megaco-term : megaco termination related alarms - megaco-sig-lt : megaco signaling lt related alarms - eqpt-supplemental : equipment supplemental alarms - eqpt-holder-ext : other equipment holder alarms - lsmredundancy : lsm redundancy alarms - sync : synce and bits alarms - mcsrc : multicast source alarms - vlanport : vlanport alarms - vect-line : xDSL vectoring line alarms - vect-board : xDSL vectoring board alarms - otdr : otdr alarms - sip-dial-plan : sip dial plan related alarms - sip-vsp : sip vsp related alarms - sip-server : sip server related alarms - bgp : bgp related alarms - rip : rip related alarms - lag : LAG related alarms - ihub-general : IHUB general related alarms	

name	Type	Description
	- vprn : vprn related alarms - isis : isis related alarms - ospf : ospf related alarms - ihub-l2forward : ihub-l2forward alarms - vpls : vpls related alarms - ihub-equip : ihub-equip related alarms - ihub-link : ihub-link related alarms - eont-phyoam : eont phyoam related alarms - ellid : ellid related alarms - epon : epon related alarms - eont-services-lan : eon phyoam related alarms - eolt-ont-tca : eon phyoam related alarms - eont-sw-dl : eon phyoam related alarms - ldp : ldp related alarms - mpls : mpls related alarms - sdp : sdp related alarms - epipe : epipe related alarms - ihub-ipv6 : ihub-ipv6 related alarms - pim : pim related alarms - li : lawful intercept related alarms - mgmt-sec-access : management security related alarms - bfd : bfd related alarms - ai : Application Intelligence related alarms - tr069serv : tr069 server related alarms - ontsnmp : ont snmp related alarms - bulk-sync : bulk-sync related alarms - protection-group : port protection group related alarms - ont : ONT general supplemental related alarms - sfu-sup : SFU ONT general supplemental related alarms - soho-sup : SOHO ONT general supplemental related alarms - mdu-sup : MDU ONT general supplemental related alarms - ont-ani : ONT general supplemental 2 related alarms - sfu-sup2 : SFU ONT general supplemental 2 related alarms - soho-sup2 : SOHO ONT general supplemental 2 related alarms - mdu-sup2 : MDU ONT general supplemental 2 related alarms - sfprssi : SFP RSSI related alarms - eoltrssi : epon olt Sfp RSSI related alarms - cfm : Cfm related alarms - sfpe1t1-framer : SFP 2e1t1 framer alarms - sfpe1t1-clock : SFP 2e1t1 clock alarms - pppcc-engine-tca : PPPOE Cross Connect Engine TCA related alarm - eth-cfm : eth-cfm related alarms - rsvp : rsvp related alarms - ihub-tca : IHUB TCA related alarms - eth-ring : eth-ring related alarms - efm-oam : EFM-OAM related alarms - ont-loopdetect : ont loop detect related alarms - ont-video : ont services video related alarms - ont-ces : ont services ces related alarms - ont-voip : ont services voip related alarms - ont-video-ani : ont services video ani related alarms - ont-pwe : ont services pwe related alarms - ont-cese1 : ont services cese1 related alarms	

101 query current alarms by filters

name	Type	Description
	- ont-xdsl : ont services xdsl related alarms - ont-xdsl-tca : ont services xdsl tca related alarms - ont-hpna : ont hpna related alarms - ont-sip-agent-cfg : ont services voip sip agent config related alarms - ont-voip-cfg : ont services voip config related alarms - ont-mgc : ont mgc related alarms - ont-ploam : ONT PLOAM related alarms - ont-gen : ONT GENERAL related alarms - ont-card : ONT Subscriber Card related alarms - ont-pots : ONT Services POTS related alarms - ont-lan : ONT Services LAN related alarms - ont-moca : ONT MoCA related alarms - ont-tc-tca : ONT TC TCA related alarms - ont-moca-tca : ONT MoCA TCA related alarms - ont-l2uni-eth-tca : ONT L2 UNI Ethernet TCA related alarms - olt-pon-tc-tca : OLT PON TC TCA related alarms - olt-pon-util-tca : OLT PON utilization TCA related alarms - olt-chpr-util-tca : OLT channel-pair utilization TCA related alarms - olt-ont-tc-tca : OLT ONT TC TCA related alarms - ont-tca : ONT TCA related alarms - ont-pots-supplemental : ONT POTS Supplemental related alarms - sfu-ploam : SFU ONT PLOAM related alarms - sfu-gen : SFU ONT general related alarms - soho-ploam : SOHO ONT PLOAM related alarms - soho-gen : SOHO ONT general related alarms - mdu-ploam : MDU ONT PLOAM related alarms - mdu-gen : MDU ONT general related alarms - ont-veip : ONT VEIP related alarms - ont-iphost : ONT IP HOST related alarms - alarm-table : alarm table related alarms - auto-switch : auto-switch related alarms - channel-pair : channel pair related alarms - ont-cfg-dld : ont configure file download related alarms - olt-chpair-tc-tca : OLT CHANNELPAIR TC TCA related alarms - hgu-tr069 : hgu tr069 related alarms - eqpt-psu : equipment psu alarms - ont-protection : ONT protection related alarms - secondary-megaco-term : secondary megaco termination related alarms - secondary-sip-term : secondary sip termination related alarms - cas-r2-channel : CAS R2 channel related alarms - lldpmed : lldpmed alarms - pseudo-wire : pseudo Wire related alarms - link-agg : Link aggregation related alarms - fcs-exceed : FCS auto-recovery related alarms - e1t1-interface : E1/T1 physical interfaces related alarms	
name	Parameter type: <Alarm::alarmTypeEoconversion> all Possible values: - all : show all E/O conversion alarm	alarm name that are active <i>This element is only shown in detail mode.</i>
severity	Parameter type: <Alarm::AlarmSeverity>	the alarms severity level

name	Type	Description
	(indeterminate warning minor major critical) Possible values: - indeterminate : alarm severity is indeterminate - warning : alarm severity is warning - minor : alarm severity is minor - major : alarm severity is major - critical : alarm severity is critical	<i>This element is only shown in detail mode.</i>
servaff	Parameter type: <Alarm::alarmServAffect> ((service-affecting yes) (noservice-affecting no)) Possible values: - service-affecting : make this alarm service affecting - yes : make this alarm service affecting - noservice-affecting : make this alarm not service affecting - no : make this alarm not service affecting	alarms affect service or not <i>This element is only shown in detail mode.</i>
time	Parameter type: <Sys::timeInSecs> - the time (yyyy-mm-dd:hour:minutes:secs) - unit: UTC	time in seconds when alarm was updated <i>This element is only shown in detail mode.</i>
descript	Parameter type: <Alarm::AddInfoString> - additional alarm information	alarm description <i>This element is only shown in detail mode.</i>

101.39 show current alarm by filters

Command Description

show current alarms by filters

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm query bonding-group [ (name) [ severity <Alarm::querySeverity> ] [ servaff
<Alarm::queryServAffect> ] [ group <Xdsl::BondingInterfaceIndex> ] ]
```

Command Parameters

Table 101.39-1 "show current alarm by filters" Resource Parameters

Resource Identifier	Type	Description
(name)	Format: (up-plan-bitrate up-min-bitrate up-config-not-feas down-plan-bitrate down-min-bitrate down-config-not-feas non-bonding-cpe multiple-cpes register group-incomplete all) Possible values: - up-plan-bitrate : upstream bitrate is above min and below planned - up-min-bitrate : upstream bitrate is below min bitrate - up-config-not-feas : upstream bitrate is not enough to set up config group - down-plan-bitrate : downstream bitrate is above min and below planned - down-min-bitrate : downstream bitrate is below min bitrate - down-config-not-feas : downstream bitrate is not enough to set up config group - non-bonding-cpe : no bonding cpe modem is connected - multiple-cpes : bonding group has multiple cpe modems connected - register : bonding group discovery or aggregation register failure	alarm name of bonding-group

Resource Identifier	Type	Description
	- group-incomplete : bonding group is incomplete - all : show all bonding-group alarm	
severity	Parameter type: <Alarm::querySeverity> Format: (indeterminate warning minor major critical all) Possible values: - indeterminate : alarm severity is indeterminate - warning : alarm severity is warning - minor : alarm severity is minor - major : alarm severity is major - critical : alarm severity is critical - all : all alarm severity	severity level of an alarm for reporting
servaff	Parameter type: <Alarm::queryServAffect> Format: (service-affecting noservice-affecting all) Possible values: - service-affecting : query alarm service affecting - noservice-affecting : query alarm not service affecting - all : query service affecting and not affecting alarms	serviceaffecting no serviceaffecting
group	Parameter type: <Xdsl::BondingInterfaceIndex> Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number	bonding group interface index

Command Output

Table 101.39-2 "show current alarm by filters" Display parameters

Specific Information		
name	Type	Description
aidinfo	Parameter type: <Alarm::AddInfoString> - additional alarm information	alarm AID parameters <i>This element is only shown in detail mode.</i>
type	Parameter type: <Alarm::alarmIHUBType> (equipment eqpt-holder plug-in-unit atm custom e1 ima-group ima-link	type of the alarms that are active <i>This element is only shown in detail mode.</i>

101 query current alarms by filters

name	Type	Description
	redundancy shdsl ether-itf traffic-overflow qos-queue temporal spatial (software-mngt sw-mgmt) xdsl xdsl-ext xdsl-tca olt-gen eo-conv authentication bonding sfp shdsl-isam custom-ext-alarm plug-in-unit-ext sip-user-agent sip-plugin-unit sip-termination e1-sip-termination filetransfer external-device l2forward ether-tca ether-sfp megaco-media-gw megaco-sig-gw megaco-plug-unit megaco-term megaco-sig-lt eqpt-supplemental eqpt-holder-ext lsmredundancy sync mcsrc vlanport vect-line vect-board otdr sip-dial-plan sip-vsp sip-server bgp rip lag ihub-general vprn isis ospf ihub-l2forward vpls ihub-equip ihub-link eont-phyoam	

name	Type	Description
	ellid	
	epon	
	eont-services-lan	
	eolt-ont-tca	
	eont-sw-dl	
	ldp	
	mpls	
	sdp	
	epipe	
	ihub-ipv6	
	pim	
	li	
	mgmt-sec-access	
	bfd	
	ai	
	tr069serv	
	ontsnmp	
	bulk-sync	
	protection-group	
	ont	
	sfu-sup	
	soho-sup	
	mdu-sup	
	ont-ani	
	sfu-sup2	
	soho-sup2	
	mdu-sup2	
	sfprssi	
	eoltrssi	
	cfm	
	sfpe1t1-framer	
	sfpe1t1-clock	
	pppcc-engine-tca	
	eth-cfm	
	rsvp	
	ihub-tca	
	eth-ring	
	efm-oam	
	ont-loopdetect	
	ont-video	
	ont-ces	
	ont-voip	
	ont-video-ani	
	ont-pwe	
	ont-cese1	
	ont-xdsl	
	ont-xdsl-tca	
	ont-hpna	
	ont-sip-agent-cfg	
	ont-voip-cfg	
	ont-mgc	
	ont-ploam	
	ont-gen	
	ont-card	
	ont-pots	
	ont-lan	
	ont-moca	

101 query current alarms by filters

name	Type	Description
	ont-tc-tca ont-moca-tca ont-l2uni-eth-tca olt-pon-tc-tca olt-pon-util-tca olt-chpr-util-tca olt-ont-tc-tca ont-tca ont-pots-supplemental sfu-ploam sfu-gen soho-ploam soho-gen mdu-ploam mdu-gen ont-veip ont-iphost alarm-table auto-switch channel-pair ont-cfg-dld olt-chpair-tc-tca hgu-tr069 eqpt-psu ont-protection secondary-megaco-term secondary-sip-term cas-r2-channel lldpmed pseudo-wire link-agg fcs-exceed e1t1-interface) Possible values: - equipment : equipment alarms - eqpt-holder : equipment holder alarms - plug-in-unit : plugin unit alarms - atm : ATM alarms - custom : customizable alarms - e1 : e1 alarms - ima-group : ima-group alarms - ima-link : ima-link alarms - redundancy : redundancy alarms - shdsl : shdsl alarms - ether-itf : ethernet interface alarms - traffic-overflow : Traffic overflow alarms - qos-queue : qos queue alarms - temporal : temporal alarms - spatial : spatial alarms - software-mngt : software management alarms - sw-mgmt : software management alarms - xdsl : xDSL alarms - xdsl-ext : other xDSL alarms - xdsl-tca : xDSL threshold cross alarms - olt-gen : OLT general alarms - eo-conv : E/O conversion related alarms - authentication : authentication related alarms	

name	Type	Description
	- bonding : bonding-group related alarms - sfp : SFP related alarms - shdsl-isam : shdsl isam alarms - custom-ext-alarm : customizable external alarms - plug-in-unit-ext : other plugin unit alarms - sip-user-agent : sip user agent related alarms - sip-plugin-unit : sip plug in unit related alarms - sip-termination : sip termination related alarms - e1-sip-termination : E1 sip termination related alarms - filetransfer : file transfer server alarms - external-device : external device related alarms - l2forward : l2forward related alarms - ether-tca : ethernet threshold cross alarms - ether-sfp : ethernet SFP related alarms - megaco-media-gw : megaco media gateway related alarms - megaco-sig-gw : megaco signaling gateway related alarms - megaco-plug-unit : megaco plug unit related alarms - megaco-term : megaco termination related alarms - megaco-sig-lt : megaco signaling lt related alarms - eqpt-supplemental : equipment supplemental alarms - eqpt-holder-ext : other equipment holder alarms - lsmredundancy : lsm redundancy alarms - sync : synce and bits alarms - mcsrc : multicast source alarms - vlanport : vlanport alarms - vect-line : xDSL vectoring line alarms - vect-board : xDSL vectoring board alarms - otdr : otdr alarms - sip-dial-plan : sip dial plan related alarms - sip-vsp : sip vsp related alarms - sip-server : sip server related alarms - bgp : bgp related alarms - rip : rip related alarms - lag : LAG related alarms - ihub-general : IHUB general related alarms - vprn : vprn related alarms - isis : isis related alarms - ospf : ospf related alarms - ihub-l2forward : ihub-l2forward alarms - vpls : vpls related alarms - ihub-equip : ihub-equip related alarms - ihub-link : ihub-link related alarms - eont-phyoam : eont phyoam related alarms - ellid : ellid related alarms - epon : epon related alarms - eont-services-lan : eon phyoam related alarms - eolt-ont-tca : eon phyoam related alarms - eont-sw-dl : eon phyoam related alarms - ldp : ldp related alarms - mpls : mpls related alarms - sdp : sdp related alarms - epipe : epipe related alarms - ihub-ipv6 : ihub-ipv6 related alarms - pim : pim related alarms - li : lawful intercept related alarms - mgmt-sec-access : management security related alarms - bfd : bfd related alarms	

101 query current alarms by filters

name	Type	Description
	- ai : Application Intelligence related alarms - tr069serv : tr069 server related alarms - ontsnmp : ont snmp related alarms - bulk-sync : bulk-sync related alarms - protection-group : port protection group related alarms - ont : ONT general supplemental related alarms - sfu-sup : SFU ONT general supplemental related alarms - soho-sup : SOHO ONT general supplemental related alarms - mdu-sup : MDU ONT general supplemental related alarms - ont-ani : ONT general supplemental 2 related alarms - sfu-sup2 : SFU ONT general supplemental 2 related alarms - soho-sup2 : SOHO ONT general supplemental 2 related alarms - mdu-sup2 : MDU ONT general supplemental 2 related alarms - sfrssi : SFP RSSI related alarms - eoltrssi : epon olt Sfp RSSI related alarms - cfm : Cfm related alarms - sfpe1t1-framer : SFP 2e1t1 framer alarms - sfpe1t1-clock : SFP 2e1t1 clock alarms - pppcc-engine-tca : PPPOE Cross Connect Engine TCA related alarm - eth-cfm : eth-cfm related alarms - rsvp : rsvp related alarms - ihub-tca : IHUB TCA related alarms - eth-ring : eth-ring related alarms - efm-oam : EFM-OAM related alarms - ont-loopdetect : ont loop detect related alarms - ont-video : ont services video related alarms - ont-ces : ont services ces related alarms - ont-voip : ont services voip related alarms - ont-video-ani : ont services video ani related alarms - ont-pwe : ont services pwe related alarms - ont-cese1 : ont services cese1 related alarms - ont-xdsl : ont services xdsl related alarms - ont-xdsl-tca : ont services xdsl tca related alarms - ont-hpna : ont hpna related alarms - ont-sip-agent-cfg : ont services voip sip agent config related alarms - ont-voip-cfg : ont services voip config related alarms - ont-mgc : ont mgc related alarms - ont-ploam : ONT PLOAM related alarms - ont-gen : ONT GENERAL related alarms - ont-card : ONT Subscriber Card related alarms - ont-pots : ONT Services POTS related alarms - ont-lan : ONT Services LAN related alarms - ont-moca : ONT MoCA related alarms - ont-tc-tca : ONT TC TCA related alarms - ont-moca-tca : ONT MoCA TCA related alarms - ont-l2uni-eth-tca : ONT L2 UNI Ethernet TCA related alarms - olt-pon-tc-tca : OLT PON TC TCA related alarms - olt-pon-util-tca : OLT PON utilization TCA related alarms - olt-chpr-util-tca : OLT channel-pair utilization TCA related alarms - olt-ont-tc-tca : OLT ONT TC TCA related alarms	

name	Type	Description
	- ont-tca : ONT TCA related alarms - ont-pots-supplemental : ONT POTS Supplemental related alarms - sfu-ploam : SFU ONT PLOAM related alarms - sfu-gen : SFU ONT general related alarms - soho-ploam : SOHO ONT PLOAM related alarms - soho-gen : SOHO ONT general related alarms - mdu-ploam : MDU ONT PLOAM related alarms - mdu-gen : MDU ONT general related alarms - ont-veip : ONT VEIP related alarms - ont-iphost : ONT IP HOST related alarms - alarm-table : alarm table related alarms - auto-switch : auto-switch related alarms - channel-pair : channel pair related alarms - ont-cfg-dld : ont configure file download related alarms - olt-chpair-tc-tca : OLT CHANNELPAIR TC TCA related alarms - hgu-tr069 : hgu tr069 related alarms - eqpt-psu : equipment psu alarms - ont-protection : ONT protection related alarms - secondary-megaco-term : secondary megaco termination related alarms - secondary-sip-term : secondary sip termination related alarms - cas-r2-channel : CAS R2 channel related alarms - lldpmed : lldpmed alarms - pseudo-wire : pseudo Wire related alarms - link-agg : Link aggregation related alarms - fcs-exceed : FCS auto-recovery related alarms - e1t1-interface : E1/T1 physical interfaces related alarms	
name	Parameter type: <Alarm::alarmtypeBondinggroup> (up-plan-bitrate up-min-bitrate up-config-not-feas down-plan-bitrate down-min-bitrate down-config-not-feas non-bonding-cpe multiple-cpes register group-incomplete all) Possible values: - up-plan-bitrate : upstream bitrate is above min and below planned - up-min-bitrate : upstream bitrate is below min bitrate - up-config-not-feas : upstream bitrate is not enough to set up config group - down-plan-bitrate : downstream bitrate is above min and below planned - down-min-bitrate : downstream bitrate is below min bitrate - down-config-not-feas : downstream bitrate is not enough to set up config group - non-bonding-cpe : no bonding cpe modem is connected - multiple-cpes : bonding group has multiple cpe modems connected - register : bonding group discovery or aggregation register	alarm name that are active <i>This element is only shown in detail mode.</i>

101 query current alarms by filters

name	Type	Description
	failure - group-incomplete : bonding group is incomplete - all : show all bonding-group alarm	
severity	Parameter type: <Alarm::AlarmSeverity> (indeterminate warning minor major critical) Possible values: - indeterminate : alarm severity is indeterminate - warning : alarm severity is warning - minor : alarm severity is minor - major : alarm severity is major - critical : alarm severity is critical	the alarms severity level <i>This element is only shown in detail mode.</i>
servaff	Parameter type: <Alarm::alarmServAffect> ((service-affecting yes) (noservice-affecting no)) Possible values: - service-affecting : make this alarm service affecting - yes : make this alarm service affecting - noservice-affecting : make this alarm not service affecting - no : make this alarm not service affecting	alarms affect service or not <i>This element is only shown in detail mode.</i>
location	Parameter type: <Alarm::almLocation> (near-end far-end middle-end line null) Possible values: - near-end : alarm location is near - far-end : alarm location is far - middle-end : alarm location is middle - line : alarm location is line - null : alarm location not defined	alarm location: near, middle, far <i>This element is only shown in detail mode.</i>
time	Parameter type: <Sys::timeInSecs> - the time (yyyy-mm-dd:hour:minutes:secs) - unit: UTC	time in seconds when alarm was updated <i>This element is only shown in detail mode.</i>
direction	Parameter type: <Alarm::almDirection> (received transmit null) Possible values: - received : alarm is received - transmit : alarm is transmit - null : direction not defined	alarm direction: received or transmit <i>This element is only shown in detail mode.</i>
descript	Parameter type: <Alarm::AddInfoString> - additional alarm information	alarm description <i>This element is only shown in detail mode.</i>

101.40 show current alarm by filters

Command Description

show current alarms by filters

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm query custom [ (name) [ severity <Alarm::querySeverity> ] [ servaff <Alarm::queryServAffect> ] [ defaultaid <Alarm::queryDefaultAid> ] ]
```

Command Parameters

Table 101.40-1 "show current alarm by filters" Resource Parameters

Resource Identifier	Type	Description
(name)	Format: (custom1 custom2 custom3 custom4 custom5 he-custom1 he-custom2 he-custom3 he-custom4 he-custom5 he-custom6 all) Possible values: - custom1 : customizable alarm 1 - custom2 : customizable alarm 2 - custom3 : customizable alarm 3 - custom4 : customizable alarm 4 - custom5 : customizable alarm 5 - he-custom1 : host expansion customizable alarm 1 - he-custom2 : host expansion customizable alarm 2 - he-custom3 : host expansion customizable alarm 3 - he-custom4 : host expansion customizable alarm 4 - he-custom5 : host expansion customizable alarm 5 - he-custom6 : host expansion customizable alarm 6 - all : show all customizable alarm	alarm name of custom
severity	Parameter type: <Alarm::querySeverity> Format:	severity level of an alarm for reporting

101 query current alarms by filters

Resource Identifier	Type	Description
	(indeterminate warning minor major critical all) Possible values: - indeterminate : alarm severity is indeterminate - warning : alarm severity is warning - minor : alarm severity is minor - major : alarm severity is major - critical : alarm severity is critical - all : all alarm severity	
servaff	Parameter type: <Alarm::queryServAffect> Format: (service-affecting noservice-affecting all) Possible values: - service-affecting : query alarm service affecting - noservice-affecting : query alarm not service affecting - all : query service affecting and not affecting alarms	serviceaffecting no serviceaffecting
defaultaid	Parameter type: <Alarm::queryDefaultAid> Format: all Possible values: - all : default AID parameter	default AID param is all

Command Output

Table 101.40-2 "show current alarm by filters" Display parameters

Specific Information		
name	Type	Description
aidinfo	Parameter type: <Alarm::AddInfoString> - additional alarm information	alarm AID parameters <i>This element is only shown in detail mode.</i>
type	Parameter type: <Alarm::alarmIHUBType> (equipment eqpt-holder plug-in-unit atm custom e1 ima-group ima-link redundancy shdsl ether-itf traffic-overflow qos-queue temporal spatial (software-mngt sw-mgmt) xdsl xdsl-ext xdsl-tca	type of the alarms that are active <i>This element is only shown in detail mode.</i>

name	Type	Description
	olt-gen	
	eo-conv	
	authentication	
	bonding	
	sfp	
	shdsl-isam	
	custom-ext-alarm	
	plug-in-unit-ext	
	sip-user-agent	
	sip-plugin-unit	
	sip-termination	
	e1-sip-termination	
	filetransfer	
	external-device	
	l2forward	
	ether-tca	
	ether-sfp	
	megaco-media-gw	
	megaco-sig-gw	
	megaco-plug-unit	
	megaco-term	
	megaco-sig-lt	
	eqpt-supplemental	
	eqpt-holder-ext	
	lsmredundancy	
	sync	
	mcsrc	
	vlanport	
	vect-line	
	vect-board	
	otdr	
	sip-dial-plan	
	sip-vsp	
	sip-server	
	bgp	
	rip	
	lag	
	ihub-general	
	vprn	
	isis	
	ospf	
	ihub-l2forward	
	vpls	
	ihub-equip	
	ihub-link	
	eont-phyoam	
	ellid	
	epon	
	eont-services-lan	
	eolt-ont-tca	
	eont-sw-dl	
	ldp	
	mpls	
	sdp	
	epipe	
	ihub-ipv6	
	pim	

101 query current alarms by filters

name	Type	Description
	li	
	mgmt-sec-access	
	bfd	
	ai	
	tr069serv	
	ontsnmp	
	bulk-sync	
	protection-group	
	ont	
	sfu-sup	
	soho-sup	
	mdu-sup	
	ont-ani	
	sfu-sup2	
	soho-sup2	
	mdu-sup2	
	sfprssi	
	eoltrssi	
	cfm	
	sfpe1t1-framer	
	sfpe1t1-clock	
	pppcc-engine-tca	
	eth-cfm	
	rsvp	
	ihub-tca	
	eth-ring	
	efm-oam	
	ont-loopdetect	
	ont-video	
	ont-ces	
	ont-voip	
	ont-video-ani	
	ont-pwe	
	ont-cese1	
	ont-xdsl	
	ont-xdsl-tca	
	ont-hpna	
	ont-sip-agent-cfg	
	ont-voip-cfg	
	ont-mgc	
	ont-ploam	
	ont-gen	
	ont-card	
	ont-pots	
	ont-lan	
	ont-moca	
	ont-tc-tca	
	ont-moca-tca	
	ont-l2uni-eth-tca	
	olt-pon-tc-tca	
	olt-pon-util-tca	
	olt-chpr-util-tca	
	olt-ont-tc-tca	
	ont-tca	
	ont-pots-supplemental	
	sfu-ploam	
	sfu-gen	

name	Type	Description
	soho-ploam soho-gen mdu-ploam mdu-gen ont-veip ont-iphost alarm-table auto-switch channel-pair ont-cfg-dld olt-chpair-tc-tca hgu-tr069 eqpt-psu ont-protection secondary-megaco-term secondary-sip-term cas-r2-channel lldpmed pseudo-wire link-agg fcs-exceed e1t1-interface) Possible values: - equipment : equipment alarms - eqpt-holder : equipment holder alarms - plug-in-unit : plugin unit alarms - atm : ATM alarms - custom : customizable alarms - e1 : e1 alarms - ima-group : ima-group alarms - ima-link : ima-link alarms - redundancy : redundancy alarms - shdsl : shdsl alarms - ether-itf : ethernet interface alarms - traffic-overflow : Traffic overflow alarms - qos-queue : qos queue alarms - temporal : temporal alarms - spatial : spatial alarms - software-mngt : software management alarms - sw-mgmt : software management alarms - xdsl : xDSL alarms - xdsl-ext : other xDSL alarms - xdsl-tca : xDSL threshold cross alarms - olt-gen : OLT general alarms - eo-conv : E/O conversion related alarms - authentication : authentication related alarms - bonding : bonding-group related alarms - sfp : SFP related alarms - shdsl-isam : shdsl isam alarms - custom-ext-alarm : customizable external alarms - plug-in-unit-ext : other plugin unit alarms - sip-user-agent : sip user agent related alarms - sip-plugin-unit : sip plug in unit related alarms - sip-termination : sip termination related alarms - e1-sip-termination : E1 sip termination related alarms - filetransfer : file transfer server alarms - external-device : external device related alarms	

101 query current alarms by filters

name	Type	Description
	- l2forward : l2forward related alarms - ether-tca : ethernet threshold cross alarms - ether-sfp : ethernet SFP related alarms - megaco-media-gw : megaco media gateway related alarms - megaco-sig-gw : megaco signaling gateway related alarms - megaco-plug-unit : megaco plug unit related alarms - megaco-term : megaco termination related alarms - megaco-sig-lt : megaco signaling lt related alarms - eqpt-supplemental : equipment supplemental alarms - eqpt-holder-ext : other equipment holder alarms - lsmredundancy : lsm redundancy alarms - sync : synce and bits alarms - mcsrc : multicast source alarms - vlanport : vlanport alarms - vect-line : xDSL vectoring line alarms - vect-board : xDSL vectoring board alarms - otdr : otdr alarms - sip-dial-plan : sip dial plan related alarms - sip-vsp : sip vsp related alarms - sip-server : sip server related alarms - bgp : bgp related alarms - rip : rip related alarms - lag : LAG related alarms - ihub-general : IHUB general related alarms - vprn : vprn related alarms - isis : isis related alarms - ospf : ospf related alarms - ihub-l2forward : ihub-l2forward alarms - vpls : vpls related alarms - ihub-equip : ihub-equip related alarms - ihub-link : ihub-link related alarms - eont-phyoam : eont phyoam related alarms - ellid : ellid related alarms - epon : epon related alarms - eont-services-lan : eon phyoam related alarms - eolt-ont-tca : eon phyoam related alarms - eont-sw-dl : eon phyoam related alarms - ldp : ldp related alarms - mpls : mpls related alarms - sdp : sdp related alarms - epipe : epipe related alarms - ihub-ipv6 : ihub-ipv6 related alarms - pim : pim related alarms - li : lawful intercept related alarms - mgmt-sec-access : management security related alarms - bfd : bfd related alarms - ai : Application Intelligence related alarms - tr069serv : tr069 server related alarms - ontsnmp : ont snmp related alarms - bulk-sync : bulk-sync related alarms - protection-group : port protection group related alarms - ont : ONT general supplemental related alarms - sfu-sup : SFU ONT general supplemental related alarms - soho-sup : SOHO ONT general supplemental related alarms - mdu-sup : MDU ONT general supplemental related alarms - ont-ani : ONT general supplemental 2 related alarms	

name	Type	Description
	- sfu-sup2 : SFU ONT general supplemental 2 related alarms - soho-sup2 : SOHO ONT general supplemental 2 related alarms - mdu-sup2 : MDU ONT general supplemental 2 related alarms - sfprssi : SFP RSSI related alarms - eoltrssi : epon olt Sfp RSSI related alarms - cfm : Cfm related alarms - sfpe1t1-framer : SFP 2e1t1 framer alarms - sfpe1t1-clock : SFP 2e1t1 clock alarms - pppcc-engine-tca : PPPOE Cross Connect Engine TCA related alarm - eth-cfm : eth-cfm related alarms - rsvp : rsvp related alarms - ihub-tca : IHUB TCA related alarms - eth-ring : eth-ring related alarms - efm-oam : EFM-OAM related alarms - ont-loopdetect : ont loop detect related alarms - ont-video : ont services video related alarms - ont-ces : ont services ces related alarms - ont-voip : ont services voip related alarms - ont-video-ani : ont services video ani related alarms - ont-pwe : ont services pwe related alarms - ont-cese1 : ont services cese1 related alarms - ont-xdsl : ont services xdsl related alarms - ont-xdsl-tca : ont services xdsl tca related alarms - ont-hpna : ont hpna related alarms - ont-sip-agent-cfg : ont services voip sip agent config related alarms - ont-voip-cfg : ont services voip config related alarms - ont-mgc : ont mgc related alarms - ont-ploam : ONT PLOAM related alarms - ont-gen : ONT GENERAL related alarms - ont-card : ONT Subscriber Card related alarms - ont-pots : ONT Services POTS related alarms - ont-lan : ONT Services LAN related alarms - ont-moca : ONT MoCA related alarms - ont-tc-tca : ONT TC TCA related alarms - ont-moca-tca : ONT MoCA TCA related alarms - ont-l2uni-eth-tca : ONT L2 UNI Ethernet TCA related alarms - olt-pon-tc-tca : OLT PON TC TCA related alarms - olt-pon-util-tca : OLT PON utilization TCA related alarms - olt-chpr-util-tca : OLT channel-pair utilization TCA related alarms - olt-ont-tc-tca : OLT ONT TC TCA related alarms - ont-tca : ONT TCA related alarms - ont-pots-supplemental : ONT POTS Supplemental related alarms - sfu-ploam : SFU ONT PLOAM related alarms - sfu-gen : SFU ONT general related alarms - soho-ploam : SOHO ONT PLOAM related alarms - soho-gen : SOHO ONT general related alarms - mdu-ploam : MDU ONT PLOAM related alarms - mdu-gen : MDU ONT general related alarms - ont-veip : ONT VEIP related alarms - ont-iphost : ONT IP HOST related alarms	

101 query current alarms by filters

name	Type	Description
	- alarm-table : alarm table related alarms - auto-switch : auto-switch related alarms - channel-pair : channel pair related alarms - ont-cfg-dld : ont configure file download related alarms - olt-chpair-tc-tca : OLT CHANNELPAIR TC TCA related alarms - hgu-tr069 : hgu tr069 related alarms - eqpt-psu : equipment psu alarms - ont-protection : ONT protection related alarms - secondary-megaco-term : secondary megaco termination related alarms - secondary-sip-term : secondary sip termination related alarms - cas-r2-channel : CAS R2 channel related alarms - lldpmed : lldpmed alarms - pseudo-wire : pseudo Wire related alarms - link-agg : Link aggregation related alarms - fcs-exceed : FCS auto-recovery related alarms - e1t1-interface : E1/T1 physical interfaces related alarms	
name	Parameter type: <Alarm::alarmTypeCustom> (custom1 custom2 custom3 custom4 custom5 he-custom1 he-custom2 he-custom3 he-custom4 he-custom5 he-custom6 all) Possible values: - custom1 : customizable alarm 1 - custom2 : customizable alarm 2 - custom3 : customizable alarm 3 - custom4 : customizable alarm 4 - custom5 : customizable alarm 5 - he-custom1 : host expansion customizable alarm 1 - he-custom2 : host expansion customizable alarm 2 - he-custom3 : host expansion customizable alarm 3 - he-custom4 : host expansion customizable alarm 4 - he-custom5 : host expansion customizable alarm 5 - he-custom6 : host expansion customizable alarm 6 - all : show all customizable alarm	alarm name that are active <i>This element is only shown in detail mode.</i>
severity	Parameter type: <Alarm::AlarmSeverity> (indeterminate warning minor major critical) Possible values: - indeterminate : alarm severity is indeterminate - warning : alarm severity is warning - minor : alarm severity is minor - major : alarm severity is major - critical : alarm severity is critical	the alarms severity level <i>This element is only shown in detail mode.</i>

name	Type	Description
servaff	Parameter type: <Alarm::alarmServAffect> ((service-affecting yes) (noservice-affecting no)) Possible values: - service-affecting : make this alarm service affecting - yes : make this alarm service affecting - noservice-affecting : make this alarm not service affecting - no : make this alarm not service affecting	alarms affect service or not <i>This element is only shown in detail mode.</i>
time	Parameter type: <Sys::timeInSecs> - the time (yyyy-mm-dd:hour:minutes:secs) - unit: UTC	time in seconds when alarm was updated <i>This element is only shown in detail mode.</i>
descript	Parameter type: <Alarm::AddInfoString> - additional alarm information	alarm description <i>This element is only shown in detail mode.</i>

101.41 show current alarm by filters

Command Description

show current alarms by filters

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm query megaco-media-gw [ (name) [ severity <Alarm::querySeverity> ] [ servaff
<Alarm::queryServAffect> ] [ board <Equipm::EqptSlotIndex> ] ]
```

Command Parameters

Table 101.41-1 "show current alarm by filters" Resource Parameters

Resource Identifier	Type	Description
(name)	Format: (mgc-unreachable failover-to-esamgc all) Possible values: - mgc-unreachable : loss of contact with the media gateway controller - failover-to-esamgc : failover to esa mgc - all : show all megaco media gateway alarm	alarm name of megaco-media-gw
severity	Parameter type: <Alarm::querySeverity> Format: (indeterminate warning minor major critical all) Possible values: - indeterminate : alarm severity is indeterminate - warning : alarm severity is warning - minor : alarm severity is minor - major : alarm severity is major - critical : alarm severity is critical - all : all alarm severity	severity level of an alarm for reporting
servaff	Parameter type: <Alarm::queryServAffect> Format: (service-affecting noservice-affecting	serviceaffecting no

Resource Identifier	Type	Description
	all) Possible values: - service-affecting : query alarm service affecting - noservice-affecting : query alarm not service affecting - all : query service affecting and not affecting alarms	
board	Parameter type: <Equipm::EqptSlotIndex> Format: (lt : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> nt-a nt-b nt acu : <Eqpt::RackId> / <Eqpt::ShelfId> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::EqSlotId> ext-a : <Eqpt::RackId> / <Eqpt::ShelfId> ext-b : <Eqpt::RackId> / <Eqpt::ShelfId> ctrl : <Eqpt::RackId> / <Eqpt::ShelfId> vlt : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::VirtualSlotId>) Possible values: - lt : lt-slot - vlt : virtual LT slot (VVPS board can only be planned at NANT-E / FANT-F) - nt-a : nt-a slot - nt-b : nt-b slot - nt : nt slot - ext-a : nt-a slot in an extension shelf - ext-b : nt-b slot in an extension shelf - acu : acu slot - ctrl : ctrl-slot Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::VirtualSlotId> - the virtual LT slot number Field type <Eqpt::EqSlotId> - the equipment slot number	the physical number of slot

Command Output

Table 101.41-2 "show current alarm by filters" Display parameters

Specific Information		
name	Type	Description
aidinfo	Parameter type: <Alarm::AddInfoString> - additional alarm information	alarm AID parameters <i>This element is only shown in detail mode.</i>
type	Parameter type: <Alarm::alarmIHUBType> (equipment eqpt-holder plug-in-unit atm custom e1 ima-group	type of the alarms that are active <i>This element is only shown in detail mode.</i>

101 query current alarms by filters

name	Type	Description
	ima-link redundancy shdsl ether-itf traffic-overflow qos-queue temporal spatial (software-mngt sw-mgmt) xdsl xdsl-ext xdsl-tca olt-gen eo-conv authentication bonding sfp shdsl-isam custom-ext-alarm plug-in-unit-ext sip-user-agent sip-plugin-unit sip-termination e1-sip-termination filetransfer external-device l2forward ether-tca ether-sfp megaco-media-gw megaco-sig-gw megaco-plug-unit megaco-term megaco-sig-lt eqpt-supplemental eqpt-holder-ext lsmredundancy sync mcsrc vlanport vect-line vect-board otdr sip-dial-plan sip-vsp sip-server bgp rip lag ihub-general vprn isis ospf ihub-l2forward vpls ihub-equip ihub-link	

name	Type	Description
	eont-phyoam ellid epon eont-services-lan eolt-ont-tca eont-sw-dl ldp mpls sdp epipe ihub-ipv6 pim li mgmt-sec-access bfd ai tr069serv ontsnmp bulk-sync protection-group ont sfu-sup soho-sup mdu-sup ont-ani sfu-sup2 soho-sup2 mdu-sup2 sfprssi eoltrssi cfm sfpe1t1-framer sfpe1t1-clock pppcc-engine-tca eth-cfm rsvp ihub-tca eth-ring efm-oam ont-loopdetect ont-video ont-ces ont-voip ont-video-ani ont-pwe ont-cese1 ont-xdsl ont-xdsl-tca ont-hpna ont-sip-agent-cfg ont-voip-cfg ont-mgc ont-ploam ont-gen ont-card ont-pots ont-lan	

101 query current alarms by filters

name	Type	Description
	ont-moca ont-tc-tca ont-moca-tca ont-l2uni-eth-tca olt-pon-tc-tca olt-pon-util-tca olt-chpr-util-tca olt-ont-tc-tca ont-tca ont-pots-supplemental sfu-ploam sfu-gen soho-ploam soho-gen mdu-ploam mdu-gen ont-veip ont-iphost alarm-table auto-switch channel-pair ont-cfg-dld olt-chpair-tc-tca hgu-tr069 eqpt-psu ont-protection secondary-megaco-term secondary-sip-term cas-r2-channel lldpmed pseudo-wire link-agg fcs-exceed e1t1-interface) Possible values: - equipment : equipment alarms - eqpt-holder : equipment holder alarms - plug-in-unit : plugin unit alarms - atm : ATM alarms - custom : customizable alarms - e1 : e1 alarms - ima-group : ima-group alarms - ima-link : ima-link alarms - redundancy : redundancy alarms - shdsl : shdsl alarms - ether-itf : ethernet interface alarms - traffic-overflow : Traffic overflow alarms - qos-queue : qos queue alarms - temporal : temporal alarms - spatial : spatial alarms - software-mngt : software management alarms - sw-mgmt : software management alarms - xdsl : xDSL alarms - xdsl-ext : other xDSL alarms - xdsl-tca : xDSL threshold cross alarms - olt-gen : OLT general alarms - eo-conv : E/O conversion related alarms	

name	Type	Description
	- authentication : authentication related alarms - bonding : bonding-group related alarms - sfp : SFP related alarms - shdsl-isam : shdsl isam alarms - custom-ext-alarm : customizable external alarms - plug-in-unit-ext : other plugin unit alarms - sip-user-agent : sip user agent related alarms - sip-plugin-unit : sip plug in unit related alarms - sip-termination : sip termination related alarms - e1-sip-termination : E1 sip termination related alarms - filetransfer : file transfer server alarms - external-device : external device related alarms - l2forward : l2forward related alarms - ether-tca : ethernet threshold cross alarms - ether-sfp : ethernet SFP related alarms - megaco-media-gw : megaco media gateway related alarms - megaco-sig-gw : megaco signaling gateway related alarms - megaco-plug-unit : megaco plug unit related alarms - megaco-term : megaco termination related alarms - megaco-sig-lt : megaco signaling lt related alarms - eqpt-supplemental : equipment supplemental alarms - eqpt-holder-ext : other equipment holder alarms - lsmredundancy : lsm redundancy alarms - sync : synce and bits alarms - mcsrc : multicast source alarms - vlanport : vlanport alarms - vect-line : xDSL vectoring line alarms - vect-board : xDSL vectoring board alarms - otdr : otdr alarms - sip-dial-plan : sip dial plan related alarms - sip-vsp : sip vsp related alarms - sip-server : sip server related alarms - bgp : bgp related alarms - rip : rip related alarms - lag : LAG related alarms - ihub-general : IHUB general related alarms - vprn : vprn related alarms - isis : isis related alarms - ospf : ospf related alarms - ihub-l2forward : ihub-l2forward alarms - vpls : vpls related alarms - ihub-equip : ihub-equip related alarms - ihub-link : ihub-link related alarms - eont-phyoam : eont phyoam related alarms - ellid : ellid related alarms - epon : epon related alarms - eont-services-lan : eon phyoam related alarms - eolt-ont-tca : eon phyoam related alarms - eont-sw-dl : eon phyoam related alarms - ldp : ldp related alarms - mpls : mpls related alarms - sdp : sdp related alarms - epipe : epipe related alarms - ihub-ipv6 : ihub-ipv6 related alarms - pim : pim related alarms - li : lawful intercept related alarms - mgmt-sec-access : management security related alarms	

101 query current alarms by filters

name	Type	Description
	- bfd : bfd related alarms - ai : Application Intelligence related alarms - tr069serv : tr069 server related alarms - ontsnmp : ont snmp related alarms - bulk-sync : bulk-sync related alarms - protection-group : port protection group related alarms - ont : ONT general supplemental related alarms - sfu-sup : SFU ONT general supplemental related alarms - soho-sup : SOHO ONT general supplemental related alarms - mdu-sup : MDU ONT general supplemental related alarms - ont-ani : ONT general supplemental 2 related alarms - sfu-sup2 : SFU ONT general supplemental 2 related alarms - soho-sup2 : SOHO ONT general supplemental 2 related alarms - mdu-sup2 : MDU ONT general supplemental 2 related alarms - sfrssi : SFP RSSI related alarms - eoltrssi : epon olt Sfp RSSI related alarms - cfm : Cfm related alarms - sfpe1t1-framer : SFP 2e1t1 framer alarms - sfpe1t1-clock : SFP 2e1t1 clock alarms - pppcc-engine-tca : PPPOE Cross Connect Engine TCA related alarm - eth-cfm : eth-cfm related alarms - rsvp : rsvp related alarms - ihub-tca : IHUB TCA related alarms - eth-ring : eth-ring related alarms - efm-oam : EFM-OAM related alarms - ont-loopdetect : ont loop detect related alarms - ont-video : ont services video related alarms - ont-ces : ont services ces related alarms - ont-voip : ont services voip related alarms - ont-video-ani : ont services video ani related alarms - ont-pwe : ont services pwe related alarms - ont-cese1 : ont services cese1 related alarms - ont-xdsl : ont services xdsl related alarms - ont-xdsl-tca : ont services xdsl tca related alarms - ont-hpna : ont hpna related alarms - ont-sip-agent-cfg : ont services voip sip agent config related alarms - ont-voip-cfg : ont services voip config related alarms - ont-mgc : ont mgc related alarms - ont-ploam : ONT PLOAM related alarms - ont-gen : ONT GENERAL related alarms - ont-card : ONT Subscriber Card related alarms - ont-pots : ONT Services POTS related alarms - ont-lan : ONT Services LAN related alarms - ont-moca : ONT MoCA related alarms - ont-tc-tca : ONT TC TCA related alarms - ont-moca-tca : ONT MoCA TCA related alarms - ont-l2uni-eth-tca : ONT L2 UNI Ethernet TCA related alarms - olt-pon-tc-tca : OLT PON TC TCA related alarms - olt-pon-util-tca : OLT PON utilization TCA related alarms - olt-chpr-util-tca : OLT channel-pair utilization TCA related alarms	

name	Type	Description
	- olt-ont-tc-tca : OLT ONT TC TCA related alarms - ont-tca : ONT TCA related alarms - ont-pots-supplemental : ONT POTS Supplemental related alarms - sfu-ploam : SFU ONT PLOAM related alarms - sfu-gen : SFU ONT general related alarms - soho-ploam : SOHO ONT PLOAM related alarms - soho-gen : SOHO ONT general related alarms - mdu-ploam : MDU ONT PLOAM related alarms - mdu-gen : MDU ONT general related alarms - ont-veip : ONT VEIP related alarms - ont-iphost : ONT IP HOST related alarms - alarm-table : alarm table related alarms - auto-switch : auto-switch related alarms - channel-pair : channel pair related alarms - ont-cfg-dld : ont configure file download related alarms - olt-chpair-tc-tca : OLT CHANNELPAIR TC TCA related alarms - hgu-tr069 : hgu tr069 related alarms - eqpt-psu : equipment psu alarms - ont-protection : ONT protection related alarms - secondary-megaco-term : secondary megaco termination related alarms - secondary-sip-term : secondary sip termination related alarms - cas-r2-channel : CAS R2 channel related alarms - lldpmed : lldpmed alarms - pseudo-wire : pseudo Wire related alarms - link-agg : Link aggregation related alarms - fcs-exceed : FCS auto-recovery related alarms - e1t1-interface : E1/T1 physical interfaces related alarms	
name	Parameter type: <Alarm::alarmTypeMegacomediagw> (mgc-unreachable failover-to-esamgc all) Possible values: - mgc-unreachable : loss of contact with the media gateway controller - failover-to-esamgc : failover to esa mgc - all : show all megaco media gateway alarm	alarm name that are active <i>This element is only shown in detail mode.</i>
severity	Parameter type: <Alarm::AlarmSeverity> (indeterminate warning minor major critical) Possible values: - indeterminate : alarm severity is indeterminate - warning : alarm severity is warning - minor : alarm severity is minor - major : alarm severity is major - critical : alarm severity is critical	the alarms severity level <i>This element is only shown in detail mode.</i>
servaff	Parameter type: <Alarm::alarmServAffect> ((service-affecting yes) (noservice-affecting no)) Possible values: - service-affecting : make this alarm service affecting	alarms affect service or not <i>This element is only shown in detail mode.</i>

101 query current alarms by filters

name	Type	Description
	- yes : make this alarm service affecting - noservice-affecting : make this alarm not service affecting - no : make this alarm not service affecting	
time	Parameter type: <Sys::timeInSecs> - the time (yyyy-mm-dd:hour:minutes:secs) - unit: UTC	time in seconds when alarm was updated <i>This element is only shown in detail mode.</i>
descript	Parameter type: <Alarm::AddInfoString> - additional alarm information	alarm description <i>This element is only shown in detail mode.</i>

101.42 show current alarm by filters

Command Description

show current alarms by filters

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm query megaco-sig-gw [ (name) [ severity <Alarm::querySeverity> ] [ servaff
<Alarm::queryServAffect> ] [ board <Equipm::LtSlotIndex> ] ]
```

Command Parameters

Table 101.42-1 "show current alarm by filters" Resource Parameters

Resource Identifier	Type	Description
(name)	Format: (sgc-unreachable all) Possible values: - sgc-unreachable : loss of contact with signaling gateway controller - all : show all megaco signaling gateway alarm	alarm name of megaco-sig-gw
severity	Parameter type: <Alarm::querySeverity> Format: (indeterminate warning minor major critical all) Possible values: - indeterminate : alarm severity is indeterminate - warning : alarm severity is warning - minor : alarm severity is minor - major : alarm severity is major - critical : alarm severity is critical - all : all alarm severity	severity level of an alarm for reporting
servaff	Parameter type: <Alarm::queryServAffect> Format: (service-affecting noservice-affecting all) Possible values:	serviceaffecting no

101 query current alarms by filters

Resource Identifier	Type	Description
	- service-affecting : query alarm service affecting - noservice-affecting : query alarm not service affecting - all : query service affecting and not affecting alarms	
board	Parameter type: <Equipm::LtSlotIndex> Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId>) Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number	the physical number of slot

Command Output

Table 101.42-2 "show current alarm by filters" Display parameters

Specific Information		
name	Type	Description
aidinfo	Parameter type: <Alarm::AddInfoString> - additional alarm information	alarm AID parameters <i>This element is only shown in detail mode.</i>
type	Parameter type: <Alarm::alarmIHUBType> (equipment eqpt-holder plug-in-unit atm custom e1 ima-group ima-link redundancy shdsl ether-itf traffic-overflow qos-queue temporal spatial (software-mngt sw-mgmt) xdsl xdsl-ext xdsl-tca olt-gen eo-conv authentication bonding sfp shdsl-isam custom-ext-alarm plug-in-unit-ext sip-user-agent sip-plugin-unit sip-termination e1-sip-termination filetransfer external-device	type of the alarms that are active <i>This element is only shown in detail mode.</i>

name	Type	Description
	l2forward	
	ether-tca	
	ether-sfp	
	megaco-media-gw	
	megaco-sig-gw	
	megaco-plug-unit	
	megaco-term	
	megaco-sig-lt	
	eqpt-supplemental	
	eqpt-holder-ext	
	lsmredundancy	
	sync	
	mcsrc	
	vlanport	
	vect-line	
	vect-board	
	otdr	
	sip-dial-plan	
	sip-vsp	
	sip-server	
	bgp	
	rip	
	lag	
	ihub-general	
	vprn	
	isis	
	ospf	
	ihub-l2forward	
	vpls	
	ihub-equip	
	ihub-link	
	eont-phyoam	
	ellid	
	epon	
	eont-services-lan	
	eolt-ont-tca	
	eont-sw-dl	
	ldp	
	mpls	
	sdp	
	epipe	
	ihub-ipv6	
	pim	
	li	
	mgmt-sec-access	
	bfd	
	ai	
	tr069serv	
	ontsnmp	
	bulk-sync	
	protection-group	
	ont	
	sfu-sup	
	soho-sup	
	mdu-sup	
	ont-ani	
	sfu-sup2	

101 query current alarms by filters

name	Type	Description
	soho-sup2	
	mdu-sup2	
	sfprssi	
	eoltrssi	
	cfm	
	sfpe1t1-framer	
	sfpe1t1-clock	
	pppcc-engine-tca	
	eth-cfm	
	rsvp	
	ihub-tca	
	eth-ring	
	efm-oam	
	ont-loopdetect	
	ont-video	
	ont-ces	
	ont-voip	
	ont-video-ani	
	ont-pwe	
	ont-cese1	
	ont-xdsl	
	ont-xdsl-tca	
	ont-hpna	
	ont-sip-agent-cfg	
	ont-voip-cfg	
	ont-mgc	
	ont-ploam	
	ont-gen	
	ont-card	
	ont-pots	
	ont-lan	
	ont-moca	
	ont-tc-tca	
	ont-moca-tca	
	ont-l2uni-eth-tca	
	olt-pon-tc-tca	
	olt-pon-util-tca	
	olt-chpr-util-tca	
	olt-ont-tc-tca	
	ont-tca	
	ont-pots-supplemental	
	sfu-ploam	
	sfu-gen	
	soho-ploam	
	soho-gen	
	mdu-ploam	
	mdu-gen	
	ont-veip	
	ont-iphost	
	alarm-table	
	auto-switch	
	channel-pair	
	ont-cfg-dld	
	olt-chpair-tc-tca	
	hgu-tr069	
	eqpt-psu	
	ont-protection	

name	Type	Description
	secondary-megaco-term secondary-sip-term cas-r2-channel lldpmed pseudo-wire link-agg fcs-exceed e1t1-interface) Possible values: - equipment : equipment alarms - eqpt-holder : equipment holder alarms - plug-in-unit : plugin unit alarms - atm : ATM alarms - custom : customizable alarms - e1 : e1 alarms - ima-group : ima-group alarms - ima-link : ima-link alarms - redundancy : redundancy alarms - shdsl : shdsl alarms - ether-itf : ethernet interface alarms - traffic-overflow : Traffic overflow alarms - qos-queue : qos queue alarms - temporal : temporal alarms - spatial : spatial alarms - software-mngt : software management alarms - sw-mgmt : software management alarms - xdsl : xDSL alarms - xdsl-ext : other xDSL alarms - xdsl-tca : xDSL threshold cross alarms - olt-gen : OLT general alarms - eo-conv : E/O conversion related alarms - authentication : authentication related alarms - bonding : bonding-group related alarms - sfp : SFP related alarms - shdsl-isam : shdsl isam alarms - custom-ext-alarm : customizable external alarms - plug-in-unit-ext : other plugin unit alarms - sip-user-agent : sip user agent related alarms - sip-plugin-unit : sip plug in unit related alarms - sip-termination : sip termination related alarms - e1-sip-termination : E1 sip termination related alarms - filetransfer : file transfer server alarms - external-device : external device related alarms - l2forward : l2forward related alarms - ether-tca : ethernet threshold cross alarms - ether-sfp : ethernet SFP related alarms - megaco-media-gw : megaco media gateway related alarms - megaco-sig-gw : megaco signaling gateway related alarms - megaco-plug-unit : megaco plug unit related alarms - megaco-term : megaco termination related alarms - megaco-sig-lt : megaco signaling lt related alarms - eqpt-supplemental : equipment supplemental alarms - eqpt-holder-ext : other equipment holder alarms - lsmredundancy : lsm redundancy alarms - sync : synce and bits alarms - mcsrc : multicast source alarms - vlanport : vlanport alarms	

101 query current alarms by filters

name	Type	Description
	- vect-line : xDSL vectoring line alarms - vect-board : xDSL vectoring board alarms - otdr : otdr alarms - sip-dial-plan : sip dial plan related alarms - sip-vsp : sip vsp related alarms - sip-server : sip server related alarms - bgp : bgp related alarms - rip : rip related alarms - lag : LAG related alarms - ihub-general : IHUB general related alarms - vprn : vprn related alarms - isis : isis related alarms - ospf : ospf related alarms - ihub-l2forward : ihub-l2forward alarms - vpls : vpls related alarms - ihub-equip : ihub-equip related alarms - ihub-link : ihub-link related alarms - eont-phyoam : eont phyoam related alarms - ellid : ellid related alarms - epon : epon related alarms - eont-services-lan : eon phyoam related alarms - eolt-ont-tca : eon phyoam related alarms - eont-sw-dl : eon phyoam related alarms - ldp : ldp related alarms - mpls : mpls related alarms - sdp : sdp related alarms - epipe : epipe related alarms - ihub-ipv6 : ihub-ipv6 related alarms - pim : pim related alarms - li : lawful intercept related alarms - mgmt-sec-access : management security related alarms - bfd : bfd related alarms - ai : Application Intelligence related alarms - tr069serv : tr069 server related alarms - ontsnmp : ont snmp related alarms - bulk-sync : bulk-sync related alarms - protection-group : port protection group related alarms - ont : ONT general supplemental related alarms - sfu-sup : SFU ONT general supplemental related alarms - soho-sup : SOHO ONT general supplemental related alarms - mdu-sup : MDU ONT general supplemental related alarms - ont-ani : ONT general supplemental 2 related alarms - sfu-sup2 : SFU ONT general supplemental 2 related alarms - soho-sup2 : SOHO ONT general supplemental 2 related alarms - mdu-sup2 : MDU ONT general supplemental 2 related alarms - sfprssi : SFP RSSI related alarms - eoltrssi : epon olt Sfp RSSI related alarms - cfm : Cfm related alarms - sfpe1t1-framer : SFP 2e1t1 framer alarms - sfpe1t1-clock : SFP 2e1t1 clock alarms - pppcc-engine-tca : PPPOE Cross Connect Engine TCA related alarm - eth-cfm : eth-cfm related alarms - rsvp : rsvp related alarms	

name	Type	Description
	- ihub-tca : IHUB TCA related alarms - eth-ring : eth-ring related alarms - efm-oam : EFM-OAM related alarms - ont-loopdetect : ont loop detect related alarms - ont-video : ont services video related alarms - ont-ces : ont services ces related alarms - ont-voip : ont services voip related alarms - ont-video-ani : ont services video ani related alarms - ont-pwe : ont services pwe related alarms - ont-cese1 : ont services cese1 related alarms - ont-xdsl : ont services xdsl related alarms - ont-xdsl-tca : ont services xdsl tca related alarms - ont-hpna : ont hpna related alarms - ont-sip-agent-cfg : ont services voip sip agent config related alarms - ont-voip-cfg : ont services voip config related alarms - ont-mgc : ont mgc related alarms - ont-ploam : ONT PLOAM related alarms - ont-gen : ONT GENERAL related alarms - ont-card : ONT Subscriber Card related alarms - ont-pots : ONT Services POTS related alarms - ont-lan : ONT Services LAN related alarms - ont-moca : ONT MoCA related alarms - ont-tc-tca : ONT TC TCA related alarms - ont-moca-tca : ONT MoCA TCA related alarms - ont-l2uni-eth-tca : ONT L2 UNI Ethernet TCA related alarms - olt-pon-tc-tca : OLT PON TC TCA related alarms - olt-pon-util-tca : OLT PON utilization TCA related alarms - olt-chpr-util-tca : OLT channel-pair utilization TCA related alarms - olt-ont-tc-tca : OLT ONT TC TCA related alarms - ont-tca : ONT TCA related alarms - ont-pots-supplemental : ONT POTS Supplemental related alarms - sfu-ploam : SFU ONT PLOAM related alarms - sfu-gen : SFU ONT general related alarms - soho-ploam : SOHO ONT PLOAM related alarms - soho-gen : SOHO ONT general related alarms - mdu-ploam : MDU ONT PLOAM related alarms - mdu-gen : MDU ONT general related alarms - ont-veip : ONT VEIP related alarms - ont-iphost : ONT IP HOST related alarms - alarm-table : alarm table related alarms - auto-switch : auto-switch related alarms - channel-pair : channel pair related alarms - ont-cfg-dld : ont configure file download related alarms - olt-chpair-tc-tca : OLT CHANNELPAIR TC TCA related alarms - hgu-tr069 : hgu tr069 related alarms - eqpt-psu : equipment psu alarms - ont-protection : ONT protection related alarms - secondary-megaco-term : secondary megaco termination related alarms - secondary-sip-term : secondary sip termination related alarms - cas-r2-channel : CAS R2 channel related alarms	

101 query current alarms by filters

name	Type	Description
	- lldpmed : lldpmed alarms - pseudo-wire : pseudo Wire related alarms - link-aggr : Link aggregation related alarms - fcs-exceed : FCS auto-recovery related alarms - e1t1-interface : E1/T1 physical interfaces related alarms	
name	Parameter type: <Alarm::alarmTypeMegacosigw> (sgc-unreachable all) Possible values: - sgc-unreachable : loss of contact with signaling gateway controller - all : show all megaco signaling gateway alarm	alarm name that are active <i>This element is only shown in detail mode.</i>
severity	Parameter type: <Alarm::AlarmSeverity> (indeterminate warning minor major critical) Possible values: - indeterminate : alarm severity is indeterminate - warning : alarm severity is warning - minor : alarm severity is minor - major : alarm severity is major - critical : alarm severity is critical	the alarms severity level <i>This element is only shown in detail mode.</i>
servaff	Parameter type: <Alarm::alarmServAffect> ((service-affecting yes) (noservice-affecting no)) Possible values: - service-affecting : make this alarm service affecting - yes : make this alarm service affecting - noservice-affecting : make this alarm not service affecting - no : make this alarm not service affecting	alarms affect service or not <i>This element is only shown in detail mode.</i>
time	Parameter type: <Sys::timeInSecs> - the time (yyyy-mm-dd:hour:minutes:secs) - unit: UTC	time in seconds when alarm was updated <i>This element is only shown in detail mode.</i>
descript	Parameter type: <Alarm::AddInfoString> - additional alarm information	alarm description <i>This element is only shown in detail mode.</i>

101.43 show current alarm by filters

Command Description

show current alarms by filters

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm query megaco-plug-unit [ (name) [ severity <Alarm::querySeverity> ] [ servaff
<Alarm::queryServAffect> ] [ defaultaid <Alarm::queryDefaultAid> ] ]
```

Command Parameters

Table 101.43-1 "show current alarm by filters" Resource Parameters

Resource Identifier	Type	Description
(name)	Format: (lcard-unreach-srvcard lcard-type-mismatch all) Possible values: - lcard-unreach-srvcard : line card unreachable with server card - lcard-type-mismatch : associate board of wrong type - all : show all megaco plug unit alarm	alarm name of megaco-plug-unit
severity	Parameter type: <Alarm::querySeverity> Format: (indeterminate warning minor major critical all) Possible values: - indeterminate : alarm severity is indeterminate - warning : alarm severity is warning - minor : alarm severity is minor - major : alarm severity is major - critical : alarm severity is critical - all : all alarm severity	severity level of an alarm for reporting
servaff	Parameter type: <Alarm::queryServAffect> Format: (service-affecting noservice-affecting	serviceaffecting no

101 query current alarms by filters

Resource Identifier	Type	Description
	all) Possible values: - service-affecting : query alarm service affecting - noservice-affecting : query alarm not service affecting - all : query service affecting and not affecting alarms	
defaultaid	Parameter type: <Alarm::queryDefaultAid> Format: all Possible values: - all : default AID parameter	default AID param is all

Command Output

Table 101.43-2 "show current alarm by filters" Display parameters

Specific Information		
name	Type	Description
aidinfo	Parameter type: <Alarm::AddInfoString> - additional alarm information	alarm AID parameters <i>This element is only shown in detail mode.</i>
type	Parameter type: <Alarm::alarmIHUBType> (equipment eqpt-holder plug-in-unit atm custom e1 ima-group ima-link redundancy shdsl ether-itf traffic-overflow qos-queue temporal spatial (software-mngt sw-mgmt) xdsl xdsl-ext xdsl-tca olt-gen eo-conv authentication bonding sfp shdsl-isam custom-ext-alarm plug-in-unit-ext sip-user-agent sip-plugin-unit sip-termination e1-sip-termination filetransfer external-device l2forward ether-tca ether-sfp)	type of the alarms that are active <i>This element is only shown in detail mode.</i>

name	Type	Description
	megaco-media-gw megaco-sig-gw megaco-plug-unit megaco-term megaco-sig-lt eqpt-supplemental eqpt-holder-ext lsmredundancy sync mcsrc vlanport vect-line vect-board otdr sip-dial-plan sip-vsp sip-server bgp rip lag ihub-general vprn isis ospf ihub-l2forward vpls ihub-equip ihub-link eont-phyoam ellid epon eont-services-lan eolt-ont-tca eont-sw-dl ldp mpls sdp epipe ihub-ipv6 pim li mgmt-sec-access bfd ai tr069serv ontsnmp bulk-sync protection-group ont sfu-sup soho-sup mdu-sup ont-ani sfu-sup2 soho-sup2 mdu-sup2 sfprssi	

101 query current alarms by filters

name	Type	Description
	eoltrssi cfm sfpe1t1-framer sfpe1t1-clock pppcc-engine-tca eth-cfm rsvp ihub-tca eth-ring efm-oam ont-loopdetect ont-video ont-ces ont-voip ont-video-ani ont-pwe ont-cese1 ont-xdsl ont-xdsl-tca ont-hpna ont-sip-agent-cfg ont-voip-cfg ont-mgc ont-ploam ont-gen ont-card ont-pots ont-lan ont-moca ont-tc-tca ont-moca-tca ont-l2uni-eth-tca olt-pon-tc-tca olt-pon-util-tca olt-chpr-util-tca olt-ont-tc-tca ont-tca ont-pots-supplemental sfu-ploam sfu-gen soho-ploam soho-gen mdu-ploam mdu-gen ont-veip ont-iphost alarm-table auto-switch channel-pair ont-cfg-dld olt-chpair-tc-tca hgu-tr069 eqpt-psu ont-protection secondary-megaco-term secondary-sip-term cas-r2-channel	

name	Type	Description
	lldpmed pseudo-wire link-agg fcs-exceed e1t1-interface) Possible values: - equipment : equipment alarms - eqpt-holder : equipment holder alarms - plug-in-unit : plugin unit alarms - atm : ATM alarms - custom : customizable alarms - e1 : e1 alarms - ima-group : ima-group alarms - ima-link : ima-link alarms - redundancy : redundancy alarms - shdsl : shdsl alarms - ether-itf : ethernet interface alarms - traffic-overflow : Traffic overflow alarms - qos-queue : qos queue alarms - temporal : temporal alarms - spatial : spatial alarms - software-mngt : software management alarms - sw-mgmt : software management alarms - xdsl : xDSL alarms - xdsl-ext : other xDSL alarms - xdsl-tca : xDSL threshold cross alarms - olt-gen : OLT general alarms - eo-conv : E/O conversion related alarms - authentication : authentication related alarms - bonding : bonding-group related alarms - sfp : SFP related alarms - shdsl-isam : shdsl isam alarms - custom-ext-alarm : customizable external alarms - plug-in-unit-ext : other plugin unit alarms - sip-user-agent : sip user agent related alarms - sip-plugin-unit : sip plug in unit related alarms - sip-termination : sip termination related alarms - e1-sip-termination : E1 sip termination related alarms - filetransfer : file transfer server alarms - external-device : external device related alarms - l2forward : l2forward related alarms - ether-tca : ethernet threshold cross alarms - ether-sfp : ethernet SFP related alarms - megaco-media-gw : megaco media gateway related alarms - megaco-sig-gw : megaco signaling gateway related alarms - megaco-plug-unit : megaco plug unit related alarms - megaco-term : megaco termination related alarms - megaco-sig-lt : megaco signaling lt related alarms - eqpt-supplemental : equipment supplemental alarms - eqpt-holder-ext : other equipment holder alarms - lsmredundancy : lsm redundancy alarms - sync : synce and bits alarms - mcsrc : multicast source alarms - vlanport : vlanport alarms - vect-line : xDSL vectoring line alarms - vect-board : xDSL vectoring board alarms - otdr : otdr alarms	

101 query current alarms by filters

name	Type	Description
	- sip-dial-plan : sip dial plan related alarms - sip-vsp : sip vsp related alarms - sip-server : sip server related alarms - bgp : bgp related alarms - rip : rip related alarms - lag : LAG related alarms - ihub-general : IHUB general related alarms - vprn : vprn related alarms - isis : isis related alarms - ospf : ospf related alarms - ihub-l2forward : ihub-l2forward alarms - vpls : vpls related alarms - ihub-equip : ihub-equip related alarms - ihub-link : ihub-link related alarms - eont-phyoam : eont phyoam related alarms - ellid : ellid related alarms - epon : epon related alarms - eont-services-lan : eon phyoam related alarms - eolt-ont-tca : eon phyoam related alarms - eont-sw-dl : eon phyoam related alarms - ldp : ldp related alarms - mpls : mpls related alarms - sdp : sdp related alarms - epipe : epipe related alarms - ihub-ipv6 : ihub-ipv6 related alarms - pim : pim related alarms - li : lawful intercept related alarms - mgmt-sec-access : management security related alarms - bfd : bfd related alarms - ai : Application Intelligence related alarms - tr069serv : tr069 server related alarms - ontsnmp : ont snmp related alarms - bulk-sync : bulk-sync related alarms - protection-group : port protection group related alarms - ont : ONT general supplemental related alarms - sfu-sup : SFU ONT general supplemental related alarms - soho-sup : SOHO ONT general supplemental related alarms - mdu-sup : MDU ONT general supplemental related alarms - ont-ani : ONT general supplemental 2 related alarms - sfu-sup2 : SFU ONT general supplemental 2 related alarms - soho-sup2 : SOHO ONT general supplemental 2 related alarms - mdu-sup2 : MDU ONT general supplemental 2 related alarms - sfprssi : SFP RSSI related alarms - eoltrssi : epon olt Sfp RSSI related alarms - cfm : Cfm related alarms - sfpe1t1-framer : SFP 2e1t1 framer alarms - sfpe1t1-clock : SFP 2e1t1 clock alarms - pppcc-engine-tca : PPPOE Cross Connect Engine TCA related alarm - eth-cfm : eth-cfm related alarms - rsvp : rsvp related alarms - ihub-tca : IHUB TCA related alarms - eth-ring : eth-ring related alarms - efm-oam : EFM-OAM related alarms	

name	Type	Description
	- ont-loopdetect : ont loop detect related alarms - ont-video : ont services video related alarms - ont-ces : ont services ces related alarms - ont-voip : ont services voip related alarms - ont-video-ani : ont services video ani related alarms - ont-pwe : ont services pwe related alarms - ont-cese1 : ont services cese1 related alarms - ont-xdsl : ont services xdsl related alarms - ont-xdsl-tca : ont services xdsl tca related alarms - ont-hpna : ont hpna related alarms - ont-sip-agent-cfg : ont services voip sip agent config related alarms - ont-voip-cfg : ont services voip config related alarms - ont-mgc : ont mgc related alarms - ont-ploam : ONT PLOAM related alarms - ont-gen : ONT GENERAL related alarms - ont-card : ONT Subscriber Card related alarms - ont-pots : ONT Services POTS related alarms - ont-lan : ONT Services LAN related alarms - ont-moca : ONT MoCA related alarms - ont-tc-tca : ONT TC TCA related alarms - ont-moca-tca : ONT MoCA TCA related alarms - ont-l2uni-eth-tca : ONT L2 UNI Ethernet TCA related alarms - olt-pon-tc-tca : OLT PON TC TCA related alarms - olt-pon-util-tca : OLT PON utilization TCA related alarms - olt-chpr-util-tca : OLT channel-pair utilization TCA related alarms - olt-ont-tc-tca : OLT ONT TC TCA related alarms - ont-tca : ONT TCA related alarms - ont-pots-supplemental : ONT POTS Supplemental related alarms - sfu-ploam : SFU ONT PLOAM related alarms - sfu-gen : SFU ONT general related alarms - soho-ploam : SOHO ONT PLOAM related alarms - soho-gen : SOHO ONT general related alarms - mdu-ploam : MDU ONT PLOAM related alarms - mdu-gen : MDU ONT general related alarms - ont-veip : ONT VEIP related alarms - ont-iphost : ONT IP HOST related alarms - alarm-table : alarm table related alarms - auto-switch : auto-switch related alarms - channel-pair : channel pair related alarms - ont-cfg-dld : ont configure file download related alarms - olt-chpair-tc-tca : OLT CHANNELPAIR TC TCA related alarms - hgu-tr069 : hgu tr069 related alarms - eqpt-psu : equipment psu alarms - ont-protection : ONT protection related alarms - secondary-megaco-term : secondary megaco termination related alarms - secondary-sip-term : secondary sip termination related alarms - cas-r2-channel : CAS R2 channel related alarms - lldpmed : lldpmed alarms - pseudo-wire : pseudo Wire related alarms - link-aggr : Link aggregation related alarms	

101 query current alarms by filters

name	Type	Description
	- fcs-exceed : FCS auto-recovery related alarms - e1t1-interface : E1/T1 physical interfaces related alarms	
name	Parameter type: <Alarm::almtypeMegacoplugin> (lcard-unreach-srvcard lcard-type-mismatch all) Possible values: - lcard-unreach-srvcard : line card unreachable with server card - lcard-type-mismatch : associate board of wrong type - all : show all megaco plug unit alarm	alarm name that are active <i>This element is only shown in detail mode.</i>
severity	Parameter type: <Alarm::AlarmSeverity> (indeterminate warning minor major critical) Possible values: - indeterminate : alarm severity is indeterminate - warning : alarm severity is warning - minor : alarm severity is minor - major : alarm severity is major - critical : alarm severity is critical	the alarms severity level <i>This element is only shown in detail mode.</i>
servaff	Parameter type: <Alarm::alarmServAffect> ((service-affecting yes) (noservice-affecting no)) Possible values: - service-affecting : make this alarm service affecting - yes : make this alarm service affecting - noservice-affecting : make this alarm not service affecting - no : make this alarm not service affecting	alarms affect service or not <i>This element is only shown in detail mode.</i>
time	Parameter type: <Sys::timeInSecs> - the time (yyyy-mm-dd:hour:minutes:secs) - unit: UTC	time in seconds when alarm was updated <i>This element is only shown in detail mode.</i>
descript	Parameter type: <Alarm::AddInfoString> - additional alarm information	alarm description <i>This element is only shown in detail mode.</i>

101.44 show current alarm by filters

Command Description

show current alarms by filters

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm query megaco-term [ (name) [ severity <Alarm::querySeverity> ] [ servaff
<Alarm::queryServAffect> ] [ port <Itf::MegacoPotsLine> ] ]
```

Command Parameters

Table 101.44-1 "show current alarm by filters" Resource Parameters

Resource Identifier	Type	Description
(name)	Format: (meg-unknown-sub meg-ground-key meg-high-temp meg-act-fail meg-over-current line-showering low-qos-packetloss low-qos-jitter low-qos-delay all) Possible values: - meg-unknown-sub : the megaco subscriber is unknown - meg-ground-key : voice port ground key - meg-high-temp : voice port high temperature - meg-act-fail : the first link layer for isdn subscriber activation failure - meg-over-current : voice port over current - line-showering : line showering - low-qos-packetloss : the total packet loss has exceeded the configured threshold - low-qos-jitter : the rtp jitter has exceeded the configured threshold - low-qos-delay : the rtp delay has exceeded the configured threshold - all : show all megaco termination alarm	alarm name of megaco-term
severity	Parameter type: <Alarm::querySeverity> Format:	severity level of an alarm for reporting

101 query current alarms by filters

Resource Identifier	Type	Description
	(indeterminate warning minor major critical all) Possible values: - indeterminate : alarm severity is indeterminate - warning : alarm severity is warning - minor : alarm severity is minor - major : alarm severity is major - critical : alarm severity is critical - all : all alarm severity	
servaff	Parameter type: <Alarm::queryServAffect> Format: (service-affecting noservice-affecting all) Possible values: - service-affecting : query alarm service affecting - noservice-affecting : query alarm not service affecting - all : query service affecting and not affecting alarms	serviceaffecting no serviceaffecting
port	Parameter type: <Itf::MegacoPotsLine> Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::NewSlotId> / <Eqpt::MegacoPortId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::NewSlotId> - the LT slot number Field type <Eqpt::MegacoPortId> - the port number of Megaco	the physical number of the port

Command Output

Table 101.44-2 "show current alarm by filters" Display parameters

Specific Information		
name	Type	Description
aidinfo	Parameter type: <Alarm::AddInfoString> - additional alarm information	alarm AID parameters <i>This element is only shown in detail mode.</i>
type	Parameter type: <Alarm::alarmIHUBType> (equipment eqpt-holder plug-in-unit atm custom e1 ima-group ima-link redundancy shdsl ether-itf traffic-overflow	type of the alarms that are active <i>This element is only shown in detail mode.</i>

name	Type	Description
	qos-queue temporal spatial (software-mngt sw-mgmt) xdsl xdsl-ext xdsl-tca olt-gen eo-conv authentication bonding sfp shdsl-isam custom-ext-alarm plug-in-unit-ext sip-user-agent sip-plugin-unit sip-termination e1-sip-termination filetransfer external-device l2forward ether-tca ether-sfp megaco-media-gw megaco-sig-gw megaco-plug-unit megaco-term megaco-sig-lt eqpt-supplemental eqpt-holder-ext lsmredundancy sync mcsrc vlanport vect-line vect-board otdr sip-dial-plan sip-vsp sip-server bgp rip lag ihub-general vprn isis ospf ihub-l2forward vpls ihub-equip ihub-link eont-phyoam ellid epon eont-services-lan eolt-ont-tca	

101 query current alarms by filters

name	Type	Description
	eont-sw-dl ldp mpls sdp epipe ihub-ipv6 pim li mgmt-sec-access bfd ai tr069serv ontsnmp bulk-sync protection-group ont sfu-sup soho-sup mdu-sup ont-ani sfu-sup2 soho-sup2 mdu-sup2 sfprssi eoltrssi cfm sfpe1t1-framer sfpe1t1-clock pppcc-engine-tca eth-cfm rsvp ihub-tca eth-ring efm-oam ont-loopdetect ont-video ont-ces ont-voip ont-video-ani ont-pwe ont-cese1 ont-xdsl ont-xdsl-tca ont-hpna ont-sip-agent-cfg ont-voip-cfg ont-mgc ont-ploam ont-gen ont-card ont-pots ont-lan ont-moca ont-tc-tca ont-moca-tca ont-l2uni-eth-tca olt-pon-tc-tca	

name	Type	Description
	olt-pon-util-tca olt-chpr-util-tca olt-ont-tc-tca ont-tca ont-pots-supplemental sfu-ploam sfu-gen soho-ploam soho-gen mdu-ploam mdu-gen ont-veip ont-iphost alarm-table auto-switch channel-pair ont-cfg-dld olt-chpair-tc-tca hgu-tr069 eqpt-psu ont-protection secondary-megaco-term secondary-sip-term cas-r2-channel lldpmed pseudo-wire link-agg fcs-exceed e1t1-interface) Possible values: - equipment : equipment alarms - eqpt-holder : equipment holder alarms - plug-in-unit : plugin unit alarms - atm : ATM alarms - custom : customizable alarms - e1 : e1 alarms - ima-group : ima-group alarms - ima-link : ima-link alarms - redundancy : redundancy alarms - shdsl : shdsl alarms - ether-itf : ethernet interface alarms - traffic-overflow : Traffic overflow alarms - qos-queue : qos queue alarms - temporal : temporal alarms - spatial : spatial alarms - software-mngt : software management alarms - sw-mgmt : software management alarms - xdsl : xDSL alarms - xdsl-ext : other xDSL alarms - xdsl-tca : xDSL threshold cross alarms - olt-gen : OLT general alarms - eo-conv : E/O conversion related alarms - authentication : authentication related alarms - bonding : bonding-group related alarms - sfp : SFP related alarms - shdsl-isam : shdsl isam alarms - custom-ext-alarm : customizable external alarms	

101 query current alarms by filters

name	Type	Description
	- plug-in-unit-ext : other plugin unit alarms - sip-user-agent : sip user agent related alarms - sip-plugin-unit : sip plug in unit related alarms - sip-termination : sip termination related alarms - e1-sip-termination : E1 sip termination related alarms - filetransfer : file transfer server alarms - external-device : external device related alarms - l2forward : l2forward related alarms - ether-tca : ethernet threshold cross alarms - ether-sfp : ethernet SFP related alarms - megaco-media-gw : megaco media gateway related alarms - megaco-sig-gw : megaco signaling gateway related alarms - megaco-plug-unit : megaco plug unit related alarms - megaco-term : megaco termination related alarms - megaco-sig-lt : megaco signaling lt related alarms - eqpt-supplemental : equipment supplemental alarms - eqpt-holder-ext : other equipment holder alarms - lsmredundancy : lsm redundancy alarms - sync : synce and bits alarms - mcsrc : multicast source alarms - vlanport : vlanport alarms - vect-line : xDSL vectoring line alarms - vect-board : xDSL vectoring board alarms - otdr : otdr alarms - sip-dial-plan : sip dial plan related alarms - sip-vsp : sip vsp related alarms - sip-server : sip server related alarms - bgp : bgp related alarms - rip : rip related alarms - lag : LAG related alarms - ihub-general : IHUB general related alarms - vprn : vprn related alarms - isis : isis related alarms - ospf : ospf related alarms - ihub-l2forward : ihub-l2forward alarms - vpls : vpls related alarms - ihub-equip : ihub-equip related alarms - ihub-link : ihub-link related alarms - eont-phyoam : eont phyoam related alarms - ellid : ellid related alarms - epon : epon related alarms - eont-services-lan : eon phyoam related alarms - eolt-ont-tca : eon phyoam related alarms - eont-sw-dl : eon phyoam related alarms - ldp : ldp related alarms - mpls : mpls related alarms - sdp : sdp related alarms - epipe : epipe related alarms - ihub-ipv6 : ihub-ipv6 related alarms - pim : pim related alarms - li : lawful intercept related alarms - mgmt-sec-access : management security related alarms - bfd : bfd related alarms - ai : Application Intelligence related alarms - tr069serv : tr069 server related alarms - ontsnmp : ont snmp related alarms - bulk-sync : bulk-sync related alarms	

name	Type	Description
	- protection-group : port protection group related alarms - ont : ONT general supplemental related alarms - sfu-sup : SFU ONT general supplemental related alarms - soho-sup : SOHO ONT general supplemental related alarms - mdu-sup : MDU ONT general supplemental related alarms - ont-ani : ONT general supplemental 2 related alarms - sfu-sup2 : SFU ONT general supplemental 2 related alarms - soho-sup2 : SOHO ONT general supplemental 2 related alarms - mdu-sup2 : MDU ONT general supplemental 2 related alarms - sfprssi : SFP RSSI related alarms - eoltrssi : epon olt Sfp RSSI related alarms - cfm : Cfm related alarms - sfpe1t1-framer : SFP 2e1t1 framer alarms - sfpe1t1-clock : SFP 2e1t1 clock alarms - pppcc-engine-tca : PPPOE Cross Connect Engine TCA related alarm - eth-cfm : eth-cfm related alarms - rsvp : rsvp related alarms - ihub-tca : IHUB TCA related alarms - eth-ring : eth-ring related alarms - efm-oam : EFM-OAM related alarms - ont-loopdetect : ont loop detect related alarms - ont-video : ont services video related alarms - ont-ces : ont services ces related alarms - ont-voip : ont services voip related alarms - ont-video-ani : ont services video ani related alarms - ont-pwe : ont services pwe related alarms - ont-cese1 : ont services cese1 related alarms - ont-xdsl : ont services xdsl related alarms - ont-xdsl-tca : ont services xdsl tca related alarms - ont-hpna : ont hpna related alarms - ont-sip-agent-cfg : ont services voip sip agent config related alarms - ont-voip-cfg : ont services voip config related alarms - ont-mgc : ont mgc related alarms - ont-ploam : ONT PLOAM related alarms - ont-gen : ONT GENERAL related alarms - ont-card : ONT Subscriber Card related alarms - ont-pots : ONT Services POTS related alarms - ont-lan : ONT Services LAN related alarms - ont-moca : ONT MoCA related alarms - ont-tc-tca : ONT TC TCA related alarms - ont-moca-tca : ONT MoCA TCA related alarms - ont-l2uni-eth-tca : ONT L2 UNI Ethernet TCA related alarms - olt-pon-tc-tca : OLT PON TC TCA related alarms - olt-pon-util-tca : OLT PON utilization TCA related alarms - olt-chpr-util-tca : OLT channel-pair utilization TCA related alarms - olt-ont-tc-tca : OLT ONT TC TCA related alarms - ont-tca : ONT TCA related alarms - ont-pots-supplemental : ONT POTS Supplemental related alarms - sfu-ploam : SFU ONT PLOAM related alarms	

101 query current alarms by filters

name	Type	Description
	- sfu-gen : SFU ONT general related alarms - soho-ploam : SOHO ONT PLOAM related alarms - soho-gen : SOHO ONT general related alarms - mdu-ploam : MDU ONT PLOAM related alarms - mdu-gen : MDU ONT general related alarms - ont-veip : ONT VEIP related alarms - ont-iphost : ONT IP HOST related alarms - alarm-table : alarm table related alarms - auto-switch : auto-switch related alarms - channel-pair : channel pair related alarms - ont-cfg-dld : ont configure file download related alarms - olt-chpair-tc-tca : OLT CHANNELPAIR TC TCA related alarms - hgu-tr069 : hgu tr069 related alarms - eqpt-psu : equipment psu alarms - ont-protection : ONT protection related alarms - secondary-megaco-term : secondary megaco termination related alarms - secondary-sip-term : secondary sip termination related alarms - cas-r2-channel : CAS R2 channel related alarms - lldpmed : lldpmed alarms - pseudo-wire : pseudo Wire related alarms - link-agg : Link aggregation related alarms - fcs-exceed : FCS auto-recovery related alarms - e1t1-interface : E1/T1 physical interfaces related alarms	
name	Parameter type: <Alarm::almtypeMegacoterm> (meg-unknown-sub meg-ground-key meg-high-temp meg-act-fail meg-over-current line-showering low-qos-packetloss low-qos-jitter low-qos-delay all) Possible values: - meg-unknown-sub : the megaco subscriber is unknown - meg-ground-key : voice port ground key - meg-high-temp : voice port high temperature - meg-act-fail : the first link layer for isdn subscriber activation failure - meg-over-current : voice port over current - line-showering : line showering - low-qos-packetloss : the total packet loss has exceeded the configured threshold - low-qos-jitter : the rtp jitter has exceeded the configured threshold - low-qos-delay : the rtp delay has exceeded the configured threshold - all : show all megaco termination alarm	alarm name that are active <i>This element is only shown in detail mode.</i>
severity	Parameter type: <Alarm::AlarmSeverity> (indeterminate warning minor major	the alarms severity level <i>This element is only shown in detail mode.</i>

name	Type	Description
	critical) Possible values: - indeterminate : alarm severity is indeterminate - warning : alarm severity is warning - minor : alarm severity is minor - major : alarm severity is major - critical : alarm severity is critical	
servaff	Parameter type: <Alarm::alarmServAffect> ((service-affecting yes) (noservice-affecting no)) Possible values: - service-affecting : make this alarm service affecting - yes : make this alarm service affecting - noservice-affecting : make this alarm not service affecting - no : make this alarm not service affecting	alarms affect service or not <i>This element is only shown in detail mode.</i>
time	Parameter type: <Sys::timeInSecs> - the time (yyyy-mm-dd:hour:minutes:secs) - unit: UTC	time in seconds when alarm was updated <i>This element is only shown in detail mode.</i>
descript	Parameter type: <Alarm::AddInfoString> - additional alarm information	alarm description <i>This element is only shown in detail mode.</i>

101.45 show current alarm by filters

Command Description

show current alarms by filters

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm query megaco-sig-lt [ (name) [ severity <Alarm::querySeverity> ] [ servaff
<Alarm::queryServAffect> ] [ board <Equipm::LtSlotIndex> ] ]
```

Command Parameters

Table 101.45-1 "show current alarm by filters" Resource Parameters

Resource Identifier	Type	Description
(name)	Format: (sig-brd-persist-loss sig-brd-disk-full sig-brd-db-rollback mg-overload all) Possible values: - sig-brd-persist-loss : voice signaling board persistent data loss - sig-brd-disk-full : voice signaling board disk 90% full - sig-brd-db-rollback : voice signaling board db rollback - mg-overload : mg overload - all : show all megaco signaling lt alarm	alarm name of megaco-sig-lt
severity	Parameter type: <Alarm::querySeverity> Format: (indeterminate warning minor major critical all) Possible values: - indeterminate : alarm severity is indeterminate - warning : alarm severity is warning - minor : alarm severity is minor - major : alarm severity is major - critical : alarm severity is critical - all : all alarm severity	severity level of an alarm for reporting

Resource Identifier	Type	Description
servaff	Parameter type: <Alarm::queryServAffect> Format: (service-affecting noservice-affecting all) Possible values: - service-affecting : query alarm service affecting - noservice-affecting : query alarm not service affecting - all : query service affecting and not affecting alarms	serviceaffecting no serviceaffecting
board	Parameter type: <Equipm::LtSlotIndex> Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId>) Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number	the physical number of the slot

Command Output

Table 101.45-2 "show current alarm by filters" Display parameters

Specific Information		
name	Type	Description
aidinfo	Parameter type: <Alarm::AddInfoString> - additional alarm information	alarm AID parameters <i>This element is only shown in detail mode.</i>
type	Parameter type: <Alarm::alarmIHUBType> (equipment eqpt-holder plug-in-unit atm custom e1 ima-group ima-link redundancy shdsl ether-itf traffic-overflow qos-queue temporal spatial (software-mngt sw-mgmt) xdsl xdsl-ext xdsl-tca olt-gen eo-conv authentication bonding sfp shdsl-isam custom-ext-alarm plug-in-unit-ext	type of the alarms that are active <i>This element is only shown in detail mode.</i>

101 query current alarms by filters

name	Type	Description
	sip-user-agent sip-plugin-unit sip-termination e1-sip-termination filetransfer external-device l2forward ether-tca ether-sfp megaco-media-gw megaco-sig-gw megaco-plug-unit megaco-term megaco-sig-lt eqpt-supplemental eqpt-holder-ext lsmredundancy sync mcsrc vlanport vect-line vect-board otdr sip-dial-plan sip-vsp sip-server bgp rip lag ihub-general vprn isis ospf ihub-l2forward vpls ihub-equip ihub-link eont-phyoam ellid epon eont-services-lan eolt-ont-tca eont-sw-dl ldp mpls sdp epipe ihub-ipv6 pim li mgmt-sec-access bfd ai tr069serv ontsnmp bulk-sync protection-group	

name	Type	Description
	ont sfu-sup soho-sup mdu-sup ont-ani sfu-sup2 soho-sup2 mdu-sup2 sfrssi eoltrssi cfm sfpe1t1-framer sfpe1t1-clock pppcc-engine-tca eth-cfm rsvp ihub-tca eth-ring efm-oam ont-loopdetect ont-video ont-ces ont-voip ont-video-ani ont-pwe ont-cese1 ont-xdsl ont-xdsl-tca ont-hpna ont-sip-agent-cfg ont-voip-cfg ont-mgc ont-ploam ont-gen ont-card ont-pots ont-lan ont-moca ont-tc-tca ont-moca-tca ont-l2uni-eth-tca olt-pon-tc-tca olt-pon-util-tca olt-chpr-util-tca olt-ont-tc-tca ont-tca ont-pots-supplemental sfu-ploam sfu-gen soho-ploam soho-gen mdu-ploam mdu-gen ont-veip ont-iphost alarm-table auto-switch	

101 query current alarms by filters

name	Type	Description
	channel-pair ont-cfg-dld olt-chpair-tc-tca hgu-tr069 eqpt-psu ont-protection secondary-megaco-term secondary-sip-term cas-r2-channel lldpmed pseudo-wire link-agg fcs-exceed e1t1-interface) Possible values: - equipment : equipment alarms - eqpt-holder : equipment holder alarms - plug-in-unit : plugin unit alarms - atm : ATM alarms - custom : customizable alarms - e1 : e1 alarms - ima-group : ima-group alarms - ima-link : ima-link alarms - redundancy : redundancy alarms - shdsl : shdsl alarms - ether-itf : ethernet interface alarms - traffic-overflow : Traffic overflow alarms - qos-queue : qos queue alarms - temporal : temporal alarms - spatial : spatial alarms - software-mngt : software management alarms - sw-mgmt : software management alarms - xdsl : xDSL alarms - xdsl-ext : other xDSL alarms - xdsl-tca : xDSL threshold cross alarms - olt-gen : OLT general alarms - eo-conv : E/O conversion related alarms - authentication : authentication related alarms - bonding : bonding-group related alarms - sfp : SFP related alarms - shdsl-isam : shdsl isam alarms - custom-ext-alarm : customizable external alarms - plug-in-unit-ext : other plugin unit alarms - sip-user-agent : sip user agent related alarms - sip-plugin-unit : sip plug in unit related alarms - sip-termination : sip termination related alarms - e1-sip-termination : E1 sip termination related alarms - filetransfer : file transfer server alarms - external-device : external device related alarms - l2forward : l2forward related alarms - ether-tca : ethernet threshold cross alarms - ether-sfp : ethernet SFP related alarms - megaco-media-gw : megaco media gateway related alarms - megaco-sig-gw : megaco signaling gateway related alarms - megaco-plug-unit : megaco plug unit related alarms - megaco-term : megaco termination related alarms - megaco-sig-lt : megaco signaling lt related alarms	

name	Type	Description
	- eqpt-supplemental : equipment supplemental alarms - eqpt-holder-ext : other equipment holder alarms - lsmredundancy : lsm redundancy alarms - sync : synce and bits alarms - mcsrc : multicast source alarms - vlanport : vlanport alarms - vect-line : xDSL vectoring line alarms - vect-board : xDSL vectoring board alarms - otdr : otdr alarms - sip-dial-plan : sip dial plan related alarms - sip-vsp : sip vsp related alarms - sip-server : sip server related alarms - bgp : bgp related alarms - rip : rip related alarms - lag : LAG related alarms - ihub-general : IHUB general related alarms - vprn : vprn related alarms - isis : isis related alarms - ospf : ospf related alarms - ihub-l2forward : ihub-l2forward alarms - vpls : vpls related alarms - ihub-equip : ihub-equip related alarms - ihub-link : ihub-link related alarms - eont-phyoam : eont phyoam related alarms - ellid : ellid related alarms - epon : epon related alarms - eont-services-lan : eon phyoam related alarms - eolt-ont-tca : eon phyoam related alarms - eont-sw-dl : eon phyoam related alarms - ldp : ldp related alarms - mpls : mpls related alarms - sdp : sdp related alarms - epipe : epipe related alarms - ihub-ipv6 : ihub-ipv6 related alarms - pim : pim related alarms - li : lawful intercept related alarms - mgmt-sec-access : management security related alarms - bfd : bfd related alarms - ai : Application Intelligence related alarms - tr069serv : tr069 server related alarms - ontsnmp : ont snmp related alarms - bulk-sync : bulk-sync related alarms - protection-group : port protection group related alarms - ont : ONT general supplemental related alarms - sfu-sup : SFU ONT general supplemental related alarms - soho-sup : SOHO ONT general supplemental related alarms - mdu-sup : MDU ONT general supplemental related alarms - ont-ani : ONT general supplemental 2 related alarms - sfu-sup2 : SFU ONT general supplemental 2 related alarms - soho-sup2 : SOHO ONT general supplemental 2 related alarms - mdu-sup2 : MDU ONT general supplemental 2 related alarms - sfrssi : SFP RSSI related alarms - eoltrssi : epon olt Sfp RSSI related alarms - cfm : Cfm related alarms	

101 query current alarms by filters

name	Type	Description
	- sfpe1t1-framer : SFP 2e1t1 framer alarms - sfpe1t1-clock : SFP 2e1t1 clock alarms - pppcc-engine-tca : PPPOE Cross Connect Engine TCA related alarm - eth-cfm : eth-cfm related alarms - rsvp : rsvp related alarms - ihub-tca : IHUB TCA related alarms - eth-ring : eth-ring related alarms - efm-oam : EFM-OAM related alarms - ont-loopdetect : ont loop detect related alarms - ont-video : ont services video related alarms - ont-ces : ont services ces related alarms - ont-voip : ont services voip related alarms - ont-video-ani : ont services video ani related alarms - ont-pwe : ont services pwe related alarms - ont-cese1 : ont services cese1 related alarms - ont-xdsl : ont services xdsl related alarms - ont-xdsl-tca : ont services xdsl tca related alarms - ont-hpna : ont hpna related alarms - ont-sip-agent-cfg : ont services voip sip agent config related alarms - ont-voip-cfg : ont services voip config related alarms - ont-mgc : ont mgc related alarms - ont-ploam : ONT PLOAM related alarms - ont-gen : ONT GENERAL related alarms - ont-card : ONT Subscriber Card related alarms - ont-pots : ONT Services POTS related alarms - ont-lan : ONT Services LAN related alarms - ont-moca : ONT MoCA related alarms - ont-tc-tca : ONT TC TCA related alarms - ont-moca-tca : ONT MoCA TCA related alarms - ont-l2uni-eth-tca : ONT L2 UNI Ethernet TCA related alarms - olt-pon-tc-tca : OLT PON TC TCA related alarms - olt-pon-util-tca : OLT PON utilization TCA related alarms - olt-chpr-util-tca : OLT channel-pair utilization TCA related alarms - olt-ont-tc-tca : OLT ONT TC TCA related alarms - ont-tca : ONT TCA related alarms - ont-pots-supplemental : ONT POTS Supplemental related alarms - sfu-ploam : SFU ONT PLOAM related alarms - sfu-gen : SFU ONT general related alarms - soho-ploam : SOHO ONT PLOAM related alarms - soho-gen : SOHO ONT general related alarms - mdu-ploam : MDU ONT PLOAM related alarms - mdu-gen : MDU ONT general related alarms - ont-veip : ONT VEIP related alarms - ont-iphost : ONT IP HOST related alarms - alarm-table : alarm table related alarms - auto-switch : auto-switch related alarms - channel-pair : channel pair related alarms - ont-cfg-dld : ont configure file download related alarms - olt-chpair-tc-tca : OLT CHANNELPAIR TC TCA related alarms - hgu-tr069 : hgu tr069 related alarms - eqpt-psu : equipment psu alarms	

name	Type	Description
	- ont-protection : ONT protection related alarms - secondary-megaco-term : secondary megaco termination related alarms - secondary-sip-term : secondary sip termination related alarms - cas-r2-channel : CAS R2 channel related alarms - lldpmed : lldpmed alarms - pseudo-wire : pseudo Wire related alarms - link-agg : Link aggregation related alarms - fcs-exceed : FCS auto-recovery related alarms - e1t1-interface : E1/T1 physical interfaces related alarms	
name	Parameter type: <Alarm::alarmTypeMegaco> (sig-brd-persist-loss sig-brd-disk-full sig-brd-db-rollback mg-overload all) Possible values: - sig-brd-persist-loss : voice signaling board persistent data loss - sig-brd-disk-full : voice signaling board disk 90% full - sig-brd-db-rollback : voice signaling board db rollback - mg-overload : mg overload - all : show all megaco signaling lt alarm	alarm name that are active <i>This element is only shown in detail mode.</i>
severity	Parameter type: <Alarm::AlarmSeverity> (indeterminate warning minor major critical) Possible values: - indeterminate : alarm severity is indeterminate - warning : alarm severity is warning - minor : alarm severity is minor - major : alarm severity is major - critical : alarm severity is critical	the alarms severity level <i>This element is only shown in detail mode.</i>
servaff	Parameter type: <Alarm::alarmServAffect> ((service-affecting yes) (noservice-affecting no)) Possible values: - service-affecting : make this alarm service affecting - yes : make this alarm service affecting - noservice-affecting : make this alarm not service affecting - no : make this alarm not service affecting	alarms affect service or not <i>This element is only shown in detail mode.</i>
time	Parameter type: <Sys::timeInSecs> - the time (yyyy-mm-dd:hour:minutes:secs) - unit: UTC	time in seconds when alarm was updated <i>This element is only shown in detail mode.</i>
descript	Parameter type: <Alarm::AddInfoString> - additional alarm information	alarm description <i>This element is only shown in detail mode.</i>

101.46 show current alarm by filters

Command Description

show current alarms by filters

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm query shdsl [ (name) [ severity <Alarm::querySeverity> ] [ servaff <Alarm::queryServAffect> ] [ port
<Itf::ShdslLine> ] ]
```

Command Parameters

Table 101.46-1 "show current alarm by filters" Resource Parameters

Resource Identifier	Type	Description
(name)	Format: (shdsl-n-loopback shdsl-c-loopback shdsl-conferr shdsl-atm-lcd shdsl-lpr shdsl-secu-err shdsl-dev-fault shdsl-atm-ncd all) Possible values: - shdsl-n-loopback : loopback active at the network side - shdsl-c-loopback : loopback active at the customer side - shdsl-conferr : configuration error - shdsl-atm-lcd : loss of atm cell delineation - shdsl-lpr : loss of power at stu-r - shdsl-secu-err : unable to disable stu-r access - shdsl-dev-fault : device fault - shdsl-atm-ncd : no atm cell delineation - all : show all shdsl alarm	alarm name of Shdsl
severity	Parameter type: <Alarm::querySeverity> Format: (indeterminate warning minor major critical all)	severity level of an alarm for reporting

Resource Identifier	Type	Description
	Possible values: - indeterminate : alarm severity is indeterminate - warning : alarm severity is warning - minor : alarm severity is minor - major : alarm severity is major - critical : alarm severity is critical - all : all alarm severity	
servaff	Parameter type: <Alarm::queryServAffect> Format: (service-affecting noservice-affecting all) Possible values: - service-affecting : query alarm service affecting - noservice-affecting : query alarm not service affecting - all : query service affecting and not affecting alarms	serviceaffecting no serviceaffecting
port	Parameter type: <Itf::ShdslLine> Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number	the physical port number of the slot

Command Output

Table 101.46-2 "show current alarm by filters" Display parameters

Specific Information		
name	Type	Description
aidinfo	Parameter type: <Alarm::AddInfoString> - additional alarm information	alarm AID parameters <i>This element is only shown in detail mode.</i>
type	Parameter type: <Alarm::alarmIHUBType> (equipment eqpt-holder plug-in-unit atm custom e1 ima-group ima-link redundancy shdsl ether-itf traffic-overflow qos-queue temporal spatial (software-mngt sw-mgmt) xdsl xdsl-ext	type of the alarms that are active <i>This element is only shown in detail mode.</i>

101 query current alarms by filters

name	Type	Description
	xds1-tca olt-gen eo-conv authentication bonding sfp shdsl-isam custom-ext-alarm plug-in-unit-ext sip-user-agent sip-plugin-unit sip-termination e1-sip-termination filetransfer external-device l2forward ether-tca ether-sfp megaco-media-gw megaco-sig-gw megaco-plug-unit megaco-term megaco-sig-lt eqpt-supplemental eqpt-holder-ext lsmredundancy sync mcsrc vlanport vect-line vect-board otdr sip-dial-plan sip-vsp sip-server bgp rip lag ihub-general vprn isis ospf ihub-l2forward vpls ihub-equip ihub-link eont-phyoam ellid epon eont-services-lan eolt-ont-tca eont-sw-dl ldp mpls sdp epipe ihub-ipv6	

name	Type	Description
	pim li mgmt-sec-access bfd ai tr069serv ontsnmp bulk-sync protection-group ont sfu-sup soho-sup mdu-sup ont-ani sfu-sup2 soho-sup2 mdu-sup2 sfprssi eoltrssi cfm sfpe1t1-framer sfpe1t1-clock pppcc-engine-tca eth-cfm rsvp ihub-tca eth-ring efm-oam ont-loopdetect ont-video ont-ces ont-voip ont-video-ani ont-pwe ont-cese1 ont-xdsl ont-xdsl-tca ont-hpna ont-sip-agent-cfg ont-voip-cfg ont-mgc ont-ploam ont-gen ont-card ont-pots ont-lan ont-moca ont-tc-tca ont-moca-tca ont-l2uni-eth-tca olt-pon-tc-tca olt-pon-util-tca olt-chpr-util-tca olt-ont-tc-tca ont-tca ont-pots-supplemental sfu-ploam	

101 query current alarms by filters

name	Type	Description
	sfu-gen soho-ploam soho-gen mdu-ploam mdu-gen ont-veip ont-iphost alarm-table auto-switch channel-pair ont-cfg-dld olt-chpair-tc-tca hgu-tr069 eqpt-psu ont-protection secondary-megaco-term secondary-sip-term cas-r2-channel lldpmed pseudo-wire link-agg fcs-exceed e1t1-interface) Possible values: - equipment : equipment alarms - eqpt-holder : equipment holder alarms - plug-in-unit : plugin unit alarms - atm : ATM alarms - custom : customizable alarms - e1 : e1 alarms - ima-group : ima-group alarms - ima-link : ima-link alarms - redundancy : redundancy alarms - shdsl : shdsl alarms - ether-itf : ethernet interface alarms - traffic-overflow : Traffic overflow alarms - qos-queue : qos queue alarms - temporal : temporal alarms - spatial : spatial alarms - software-mngt : software management alarms - sw-mgmt : software management alarms - xdsl : xDSL alarms - xdsl-ext : other xDSL alarms - xdsl-tca : xDSL threshold cross alarms - olt-gen : OLT general alarms - eo-conv : E/O conversion related alarms - authentication : authentication related alarms - bonding : bonding-group related alarms - sfp : SFP related alarms - shdsl-isam : shdsl isam alarms - custom-ext-alarm : customizable external alarms - plug-in-unit-ext : other plugin unit alarms - sip-user-agent : sip user agent related alarms - sip-plugin-unit : sip plug in unit related alarms - sip-termination : sip termination related alarms - e1-sip-termination : E1 sip termination related alarms - filetransfer : file transfer server alarms	

name	Type	Description
	- external-device : external device related alarms - l2forward : l2forward related alarms - ether-tca : ethernet threshold cross alarms - ether-sfp : ethernet SFP related alarms - megaco-media-gw : megaco media gateway related alarms - megaco-sig-gw : megaco signaling gateway related alarms - megaco-plug-unit : megaco plug unit related alarms - megaco-term : megaco termination related alarms - megaco-sig-lt : megaco signaling lt related alarms - eqpt-supplemental : equipment supplemental alarms - eqpt-holder-ext : other equipment holder alarms - lsmredundancy : lsm redundancy alarms - sync : synce and bits alarms - mcsrc : multicast source alarms - vlanport : vlanport alarms - vect-line : xDSL vectoring line alarms - vect-board : xDSL vectoring board alarms - otdr : otdr alarms - sip-dial-plan : sip dial plan related alarms - sip-vsp : sip vsp related alarms - sip-server : sip server related alarms - bgp : bgp related alarms - rip : rip related alarms - lag : LAG related alarms - ihub-general : IHUB general related alarms - vprn : vprn related alarms - isis : isis related alarms - ospf : ospf related alarms - ihub-l2forward : ihub-l2forward alarms - vpls : vpls related alarms - ihub-equip : ihub-equip related alarms - ihub-link : ihub-link related alarms - eont-phyoam : eont phyoam related alarms - ellid : ellid related alarms - epon : epon related alarms - eont-services-lan : eon phyoam related alarms - eolt-ont-tca : eon phyoam related alarms - eont-sw-dl : eon phyoam related alarms - ldp : ldp related alarms - mpls : mpls related alarms - sdp : sdp related alarms - epipe : epipe related alarms - ihub-ipv6 : ihub-ipv6 related alarms - pim : pim related alarms - li : lawful intercept related alarms - mgmt-sec-access : management security related alarms - bfd : bfd related alarms - ai : Application Intelligence related alarms - tr069serv : tr069 server related alarms - ontsnmp : ont snmp related alarms - bulk-sync : bulk-sync related alarms - protection-group : port protection group related alarms - ont : ONT general supplemental related alarms - sfu-sup : SFU ONT general supplemental related alarms - soho-sup : SOHO ONT general supplemental related alarms - mdm-sup : MDU ONT general supplemental related alarms	

101 query current alarms by filters

name	Type	Description
	- ont-ani : ONT general supplemental 2 related alarms - sfu-sup2 : SFU ONT general supplemental 2 related alarms - soho-sup2 : SOHO ONT general supplemental 2 related alarms - mdu-sup2 : MDU ONT general supplemental 2 related alarms - sfprssi : SFP RSSI related alarms - eoltrssi : epon olt Sfp RSSI related alarms - cfm : Cfm related alarms - sfpe1t1-framer : SFP 2e1t1 framer alarms - sfpe1t1-clock : SFP 2e1t1 clock alarms - pppcc-engine-tca : PPPOE Cross Connect Engine TCA related alarm - eth-cfm : eth-cfm related alarms - rsvp : rsvp related alarms - ihub-tca : IHUB TCA related alarms - eth-ring : eth-ring related alarms - efm-oam : EFM-OAM related alarms - ont-loopdetect : ont loop detect related alarms - ont-video : ont services video related alarms - ont-ces : ont services ces related alarms - ont-voip : ont services voip related alarms - ont-video-ani : ont services video ani related alarms - ont-pwe : ont services pwe related alarms - ont-cese1 : ont services cese1 related alarms - ont-xdsl : ont services xdsl related alarms - ont-xdsl-tca : ont services xdsl tca related alarms - ont-hpna : ont hpna related alarms - ont-sip-agent-cfg : ont services voip sip agent config related alarms - ont-voip-cfg : ont services voip config related alarms - ont-mgc : ont mgc related alarms - ont-ploam : ONT PLOAM related alarms - ont-gen : ONT GENERAL related alarms - ont-card : ONT Subscriber Card related alarms - ont-pots : ONT Services POTS related alarms - ont-lan : ONT Services LAN related alarms - ont-moca : ONT MoCA related alarms - ont-tc-tca : ONT TC TCA related alarms - ont-moca-tca : ONT MoCA TCA related alarms - ont-l2uni-eth-tca : ONT L2 UNI Ethernet TCA related alarms - olt-pon-tc-tca : OLT PON TC TCA related alarms - olt-pon-util-tca : OLT PON utilization TCA related alarms - olt-chpr-util-tca : OLT channel-pair utilization TCA related alarms - olt-ont-tc-tca : OLT ONT TC TCA related alarms - ont-tca : ONT TCA related alarms - ont-pots-supplemental : ONT POTS Supplemental related alarms - sfu-ploam : SFU ONT PLOAM related alarms - sfu-gen : SFU ONT general related alarms - soho-ploam : SOHO ONT PLOAM related alarms - soho-gen : SOHO ONT general related alarms - mdu-ploam : MDU ONT PLOAM related alarms - mdu-gen : MDU ONT general related alarms - ont-veip : ONT VEIP related alarms	

name	Type	Description
	- ont-iphost : ONT IP HOST related alarms - alarm-table : alarm table related alarms - auto-switch : auto-switch related alarms - channel-pair : channel pair related alarms - ont-cfg-dld : ont configure file download related alarms - olt-chpair-tc-tca : OLT CHANNELPAIR TC TCA related alarms - hgu-tr069 : hgu tr069 related alarms - eqpt-psu : equipment psu alarms - ont-protection : ONT protection related alarms - secondary-megaco-term : secondary megaco termination related alarms - secondary-sip-term : secondary sip termination related alarms - cas-r2-channel : CAS R2 channel related alarms - lldpmed : lldpmed alarms - pseudo-wire : pseudo Wire related alarms - link-agg : Link aggregation related alarms - fcs-exceed : FCS auto-recovery related alarms - elt1-interface : E1/T1 physical interfaces related alarms	
name	Parameter type: <Alarm::almtypeShdsl> (shdsl-n-loopback shdsl-c-loopback shdsl-conferr shdsl-atm-lcd shdsl-lpr shdsl-secu-err shdsl-dev-fault shdsl-atm-ncd all) Possible values: - shdsl-n-loopback : loopback active at the network side - shdsl-c-loopback : loopback active at the customer side - shdsl-conferr : configuration error - shdsl-atm-lcd : loss of atm cell delineation - shdsl-lpr : loss of power at stu-r - shdsl-secu-err : unable to disable stu-r access - shdsl-dev-fault : device fault - shdsl-atm-ncd : no atm cell delineation - all : show all shdsl alarm	alarm name that are active <i>This element is only shown in detail mode.</i>
severity	Parameter type: <Alarm::AlarmSeverity> (indeterminate warning minor major critical) Possible values: - indeterminate : alarm severity is indeterminate - warning : alarm severity is warning - minor : alarm severity is minor - major : alarm severity is major - critical : alarm severity is critical	the alarms severity level <i>This element is only shown in detail mode.</i>
servaff	Parameter type: <Alarm::alarmServAffect> ((service-affecting yes) (noservice-affecting no)) Possible values: - service-affecting : make this alarm service affecting	alarms affect service or not <i>This element is only shown in detail mode.</i>

101 query current alarms by filters

name	Type	Description
	- yes : make this alarm service affecting - noservice-affecting : make this alarm not service affecting - no : make this alarm not service affecting	
location	Parameter type: <Alarm::almLocation> (near-end far-end middle-end line null) Possible values: - near-end : alarm location is near - far-end : alarm location is far - middle-end : alarm location is middle - line : alarm location is line - null : alarm location not defined	alarm location: near, middle, far <i>This element is only shown in detail mode.</i>
time	Parameter type: <Sys::timeInSecs> - the time (yyyy-mm-dd:hour:minutes:secs) - unit: UTC	time in seconds when alarm was updated <i>This element is only shown in detail mode.</i>
direction	Parameter type: <Alarm::almDirection> (received transmit null) Possible values: - received : alarm is received - transmit : alarm is transmit - null : direction not defined	alarm direction: received or transmit <i>This element is only shown in detail mode.</i>
descript	Parameter type: <Alarm::AddInfoString> - additional alarm information	alarm description <i>This element is only shown in detail mode.</i>

101.47 show current alarm by filters

Command Description

show current alarms by filters

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm query shdsl-isam [ (name) [ severity <Alarm::querySeverity> ] [ servaff <Alarm::queryServAffect> ]
[ port <Itf::ShdslLine> ] ]
```

Command Parameters

Table 101.47-1 "show current alarm by filters" Resource Parameters

Resource Identifier	Type	Description
(name)	Format: (shdsl-n-losw shdsl-c-losw shdsl-n-aten shdsl-c-aten shdsl-n-snr shdsl-c-snr shdsl-n-dccont shdsl-c-dccont shdsl-c-actfail all) Possible values: - shdsl-n-losw : loss of sync word at the network side on each pair - shdsl-c-losw : loss of sync word at the customer side on each pair - shdsl-n-aten : loop attenuation alarm at the network side on each pair - shdsl-c-aten : loop attenuation alarm at the customer side on each pair - shdsl-n-snr : snr margin alarm at the network side each pair - shdsl-c-snr : snr margin alarm at the customer side on each pair - shdsl-n-dccont : dc continuity fault at the network side on each pair - shdsl-c-dccont : dc continuity fault at the customer side on each pair - shdsl-c-actfail : activation failure at the customer side on	alarm name of shdsl-isam

101 query current alarms by filters

Resource Identifier	Type	Description
	each pair - all : show all shdsl isam alarm	
severity	Parameter type: <Alarm::querySeverity> Format: (indeterminate warning minor major critical all) Possible values: - indeterminate : alarm severity is indeterminate - warning : alarm severity is warning - minor : alarm severity is minor - major : alarm severity is major - critical : alarm severity is critical - all : all alarm severity	severity level of an alarm for reporting
servaff	Parameter type: <Alarm::queryServAffect> Format: (service-affecting noservice-affecting all) Possible values: - service-affecting : query alarm service affecting - noservice-affecting : query alarm not service affecting - all : query service affecting and not affecting alarms	serviceaffecting no serviceaffecting
port	Parameter type: <Itf::ShdslLine> Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number	identifies the physical position of the port

Command Output

Table 101.47-2 "show current alarm by filters" Display parameters

Specific Information		
name	Type	Description
aidinfo	Parameter type: <Alarm::AddInfoString> - additional alarm information	alarm AID parameters <i>This element is only shown in detail mode.</i>
type	Parameter type: <Alarm::alarmIHUBType> (equipment eqpt-holder plug-in-unit atm custom e1 ima-group ima-link	type of the alarms that are active <i>This element is only shown in detail mode.</i>

name	Type	Description
	redundancy shdsl ether-itf traffic-overflow qos-queue temporal spatial (software-mngt sw-mgmt) xdsl xdsl-ext xdsl-tca olt-gen eo-conv authentication bonding sfp shdsl-isam custom-ext-alarm plug-in-unit-ext sip-user-agent sip-plugin-unit sip-termination e1-sip-termination filetransfer external-device l2forward ether-tca ether-sfp megaco-media-gw megaco-sig-gw megaco-plug-unit megaco-term megaco-sig-lt eqpt-supplemental eqpt-holder-ext lsmredundancy sync mcsrc vlanport vect-line vect-board otdr sip-dial-plan sip-vsp sip-server bgp rip lag ihub-general vprn isis ospf ihub-l2forward vpls ihub-equip ihub-link eont-phyoam	

101 query current alarms by filters

name	Type	Description
	ellid epon eont-services-lan eolt-ont-tca eont-sw-dl ldp mpls sdp epipe ihub-ipv6 pim li mgmt-sec-access bfd ai tr069serv ontsnmp bulk-sync protection-group ont sfu-sup soho-sup mdu-sup ont-ani sfu-sup2 soho-sup2 mdu-sup2 sfprssi eoltrssi cfm sfpe1t1-framer sfpe1t1-clock pppcc-engine-tca eth-cfm rsvp ihub-tca eth-ring efm-oam ont-loopdetect ont-video ont-ces ont-voip ont-video-ani ont-pwe ont-cese1 ont-xdsl ont-xdsl-tca ont-hpna ont-sip-agent-cfg ont-voip-cfg ont-mgc ont-ploam ont-gen ont-card ont-pots ont-lan ont-moca	

name	Type	Description
	ont-tc-tca ont-moca-tca ont-l2uni-eth-tca olt-pon-tc-tca olt-pon-util-tca olt-chpr-util-tca olt-ont-tc-tca ont-tca ont-pots-supplemental sfu-ploam sfu-gen soho-ploam soho-gen mdu-ploam mdu-gen ont-veip ont-iphost alarm-table auto-switch channel-pair ont-cfg-dld olt-chpair-tc-tca hgu-tr069 eqpt-psu ont-protection secondary-megaco-term secondary-sip-term cas-r2-channel lldpmed pseudo-wire link-agg fcs-exceed e1t1-interface) Possible values: - equipment : equipment alarms - eqpt-holder : equipment holder alarms - plug-in-unit : plugin unit alarms - atm : ATM alarms - custom : customizable alarms - e1 : e1 alarms - ima-group : ima-group alarms - ima-link : ima-link alarms - redundancy : redundancy alarms - shdsl : shdsl alarms - ether-itf : ethernet interface alarms - traffic-overflow : Traffic overflow alarms - qos-queue : qos queue alarms - temporal : temporal alarms - spatial : spatial alarms - software-mngt : software management alarms - sw-mgmt : software management alarms - xdsl : xDSL alarms - xdsl-ext : other xDSL alarms - xdsl-tca : xDSL threshold cross alarms - olt-gen : OLT general alarms - eo-conv : E/O conversion related alarms - authentication : authentication related alarms	

101 query current alarms by filters

name	Type	Description
	- bonding : bonding-group related alarms - sfp : SFP related alarms - shdsl-isam : shdsl isam alarms - custom-ext-alarm : customizable external alarms - plug-in-unit-ext : other plugin unit alarms - sip-user-agent : sip user agent related alarms - sip-plugin-unit : sip plug in unit related alarms - sip-termination : sip termination related alarms - e1-sip-termination : E1 sip termination related alarms - filetransfer : file transfer server alarms - external-device : external device related alarms - l2forward : l2forward related alarms - ether-tca : ethernet threshold cross alarms - ether-sfp : ethernet SFP related alarms - megaco-media-gw : megaco media gateway related alarms - megaco-sig-gw : megaco signaling gateway related alarms - megaco-plug-unit : megaco plug unit related alarms - megaco-term : megaco termination related alarms - megaco-sig-lt : megaco signaling lt related alarms - eqpt-supplemental : equipment supplemental alarms - eqpt-holder-ext : other equipment holder alarms - lsmredundancy : lsm redundancy alarms - sync : synce and bits alarms - mcsrc : multicast source alarms - vlanport : vlanport alarms - vect-line : xDSL vectoring line alarms - vect-board : xDSL vectoring board alarms - otdr : otdr alarms - sip-dial-plan : sip dial plan related alarms - sip-vsp : sip vsp related alarms - sip-server : sip server related alarms - bgp : bgp related alarms - rip : rip related alarms - lag : LAG related alarms - ihub-general : IHUB general related alarms - vprn : vprn related alarms - isis : isis related alarms - ospf : ospf related alarms - ihub-l2forward : ihub-l2forward alarms - vpls : vpls related alarms - ihub-equip : ihub-equip related alarms - ihub-link : ihub-link related alarms - eont-phyoam : eont phyoam related alarms - ellid : ellid related alarms - epon : epon related alarms - eont-services-lan : eon phyoam related alarms - eolt-ont-tca : eon phyoam related alarms - eont-sw-dl : eon phyoam related alarms - ldp : ldp related alarms - mpls : mpls related alarms - sdp : sdp related alarms - epipe : epipe related alarms - ihub-ipv6 : ihub-ipv6 related alarms - pim : pim related alarms - li : lawful intercept related alarms - mgmt-sec-access : management security related alarms - bfd : bfd related alarms	

name	Type	Description
	- ai : Application Intelligence related alarms - tr069serv : tr069 server related alarms - ontsnmp : ont snmp related alarms - bulk-sync : bulk-sync related alarms - protection-group : port protection group related alarms - ont : ONT general supplemental related alarms - sfu-sup : SFU ONT general supplemental related alarms - soho-sup : SOHO ONT general supplemental related alarms - mdu-sup : MDU ONT general supplemental related alarms - ont-ani : ONT general supplemental 2 related alarms - sfu-sup2 : SFU ONT general supplemental 2 related alarms - soho-sup2 : SOHO ONT general supplemental 2 related alarms - mdu-sup2 : MDU ONT general supplemental 2 related alarms - sfrssi : SFP RSSI related alarms - eoltrssi : epon olt Sfp RSSI related alarms - cfm : Cfm related alarms - sfpe1t1-framer : SFP 2e1t1 framer alarms - sfpe1t1-clock : SFP 2e1t1 clock alarms - pppcc-engine-tca : PPPOE Cross Connect Engine TCA related alarm - eth-cfm : eth-cfm related alarms - rsvp : rsvp related alarms - ihub-tca : IHUB TCA related alarms - eth-ring : eth-ring related alarms - efm-oam : EFM-OAM related alarms - ont-loopdetect : ont loop detect related alarms - ont-video : ont services video related alarms - ont-ces : ont services ces related alarms - ont-voip : ont services voip related alarms - ont-video-ani : ont services video ani related alarms - ont-pwe : ont services pwe related alarms - ont-cese1 : ont services cese1 related alarms - ont-xdsl : ont services xdsl related alarms - ont-xdsl-tca : ont services xdsl tca related alarms - ont-hpna : ont hpna related alarms - ont-sip-agent-cfg : ont services voip sip agent config related alarms - ont-voip-cfg : ont services voip config related alarms - ont-mgc : ont mgc related alarms - ont-ploam : ONT PLOAM related alarms - ont-gen : ONT GENERAL related alarms - ont-card : ONT Subscriber Card related alarms - ont-pots : ONT Services POTS related alarms - ont-lan : ONT Services LAN related alarms - ont-moca : ONT MoCA related alarms - ont-tc-tca : ONT TC TCA related alarms - ont-moca-tca : ONT MoCA TCA related alarms - ont-l2uni-eth-tca : ONT L2 UNI Ethernet TCA related alarms - olt-pon-tc-tca : OLT PON TC TCA related alarms - olt-pon-util-tca : OLT PON utilization TCA related alarms - olt-chpr-util-tca : OLT channel-pair utilization TCA related alarms - olt-ont-tc-tca : OLT ONT TC TCA related alarms	

101 query current alarms by filters

name	Type	Description
	- ont-tca : ONT TCA related alarms - ont-pots-supplemental : ONT POTS Supplemental related alarms - sfu-ploam : SFU ONT PLOAM related alarms - sfu-gen : SFU ONT general related alarms - soho-ploam : SOHO ONT PLOAM related alarms - soho-gen : SOHO ONT general related alarms - mdu-ploam : MDU ONT PLOAM related alarms - mdu-gen : MDU ONT general related alarms - ont-veip : ONT VEIP related alarms - ont-iphost : ONT IP HOST related alarms - alarm-table : alarm table related alarms - auto-switch : auto-switch related alarms - channel-pair : channel pair related alarms - ont-cfg-dld : ont configure file download related alarms - olt-chpair-tc-tca : OLT CHANNELPAIR TC TCA related alarms - hgu-tr069 : hgu tr069 related alarms - eqpt-psu : equipment psu alarms - ont-protection : ONT protection related alarms - secondary-megaco-term : secondary megaco termination related alarms - secondary-sip-term : secondary sip termination related alarms - cas-r2-channel : CAS R2 channel related alarms - lldpmed : lldpmed alarms - pseudo-wire : pseudo Wire related alarms - link-agg : Link aggregation related alarms - fcs-exceed : FCS auto-recovery related alarms - e1t1-interface : E1/T1 physical interfaces related alarms	
name	Parameter type: <Alarm::alarmtypeShdslisam> (shdsl-n-losw shdsl-c-losw shdsl-n-aten shdsl-c-aten shdsl-n-snr shdsl-c-snr shdsl-n-dccont shdsl-c-dccont shdsl-c-actfail all) Possible values: - shdsl-n-losw : loss of sync word at the network side on each pair - shdsl-c-losw : loss of sync word at the customer side on each pair - shdsl-n-aten : loop attenuation alarm at the network side on each pair - shdsl-c-aten : loop attenuation alarm at the customer side on each pair - shdsl-n-snr : snr margin alarm at the network side each pair - shdsl-c-snr : snr margin alarm at the customer side on each pair - shdsl-n-dccont : dc continuity fault at the network side on each pair - shdsl-c-dccont : dc continuity fault at the customer side on each pair	alarm name that are active <i>This element is only shown in detail mode.</i>

name	Type	Description
	- shdsl-c-actfail : activation failure at the customer side on each pair - all : show all shdsl isam alarm	
severity	Parameter type: <Alarm::AlarmSeverity> (indeterminate warning minor major critical) Possible values: - indeterminate : alarm severity is indeterminate - warning : alarm severity is warning - minor : alarm severity is minor - major : alarm severity is major - critical : alarm severity is critical	the alarms severity level <i>This element is only shown in detail mode.</i>
servaff	Parameter type: <Alarm::alarmServAffect> ((service-affecting yes) (noservice-affecting no)) Possible values: - service-affecting : make this alarm service affecting - yes : make this alarm service affecting - noservice-affecting : make this alarm not service affecting - no : make this alarm not service affecting	alarms affect service or not <i>This element is only shown in detail mode.</i>
location	Parameter type: <Alarm::almLocation> (near-end far-end middle-end line null) Possible values: - near-end : alarm location is near - far-end : alarm location is far - middle-end : alarm location is middle - line : alarm location is line - null : alarm location not defined	alarm location: near, middle, far <i>This element is only shown in detail mode.</i>
time	Parameter type: <Sys::timeInSecs> - the time (yyyy-mm-dd:hour:minutes:secs) - unit: UTC	time in seconds when alarm was updated <i>This element is only shown in detail mode.</i>
direction	Parameter type: <Alarm::almDirection> (received transmit null) Possible values: - received : alarm is received - transmit : alarm is transmit - null : direction not defined	alarm direction: received or transmit <i>This element is only shown in detail mode.</i>
descript	Parameter type: <Alarm::AddInfoString> - additional alarm information	alarm description <i>This element is only shown in detail mode.</i>

101.48 show current alarm by filters

Command Description

show current alarms by filters

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm query ima-group [ (name) [ severity <Alarm::querySeverity> ] [ servaff <Alarm::queryServAffect> ]  
[ port <Equipm::AtmImaIndex> ] ]
```

Command Parameters

Table 101.48-1 "show current alarm by filters" Resource Parameters

Resource Identifier	Type	Description
(name)	Format: (ima-grp-fe-su ima-grp-fe-cfg ima-grp-ne-cfg ima-grp-fe-nl ima-grp-ne-nl ima-grp-fe-blk all) Possible values: - ima-grp-fe-su : far-end starting up - ima-grp-fe-cfg : far-end failed configuration - ima-grp-ne-cfg : near-end failed configuration - ima-grp-fe-nl : insufficient number of links at far-end - ima-grp-ne-nl : insufficient number of links at near-end - ima-grp-fe-blk : far-end is blocked - all : show all ima-group alarm	alarm name of ima-group
severity	Parameter type: <Alarm::querySeverity> Format: (indeterminate warning minor major critical all) Possible values: - indeterminate : alarm severity is indeterminate - warning : alarm severity is warning - minor : alarm severity is minor	severity level of an alarm for reporting

Resource Identifier	Type	Description
	- major : alarm severity is major - critical : alarm severity is critical - all : all alarm severity	
servaff	Parameter type: <Alarm::queryServAffect> Format: (service-affecting noservice-affecting all) Possible values: - service-affecting : query alarm service affecting - noservice-affecting : query alarm not service affecting - all : query service affecting and not affecting alarms	serviceaffecting no serviceaffecting
port	Parameter type: <Equipm::AtmImaIndex> Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number	the physical number of the port

Command Output

Table 101.48-2 "show current alarm by filters" Display parameters

Specific Information		
name	Type	Description
aidinfo	Parameter type: <Alarm::AddInfoString> - additional alarm information	alarm AID parameters <i>This element is only shown in detail mode.</i>
type	Parameter type: <Alarm::alarmIHUBType> (equipment eqpt-holder plug-in-unit atm custom e1 ima-group ima-link redundancy shdsl ether-itf traffic-overflow qos-queue temporal spatial (software-mngt sw-mgmt) xdsl xdsl-ext xdsl-tca olt-gen eo-conv authentication	type of the alarms that are active <i>This element is only shown in detail mode.</i>

101 query current alarms by filters

name	Type	Description
	bonding sfp shdsl-isam custom-ext-alarm plug-in-unit-ext sip-user-agent sip-plugin-unit sip-termination e1-sip-termination filetransfer external-device l2forward ether-tca ether-sfp megaco-media-gw megaco-sig-gw megaco-plug-unit megaco-term megaco-sig-lt eqpt-supplemental eqpt-holder-ext lsmredundancy sync mcsrc vlanport vect-line vect-board otdr sip-dial-plan sip-vsp sip-server bgp rip lag ihub-general vprn isis ospf ihub-l2forward vpls ihub-equip ihub-link eont-phyoam ellid epon eont-services-lan eolt-ont-tca eont-sw-dl ldp mpls sdp epipe ihub-ipv6 pim li mgmt-sec-access bfd	

name	Type	Description
	ai	
	tr069serv	
	ontsnmp	
	bulk-sync	
	protection-group	
	ont	
	sfu-sup	
	soho-sup	
	mdu-sup	
	ont-ani	
	sfu-sup2	
	soho-sup2	
	mdu-sup2	
	sfprssi	
	eoltrssi	
	cfm	
	sfpe1t1-framer	
	sfpe1t1-clock	
	pppcc-engine-tca	
	eth-cfm	
	rsvp	
	ihub-tca	
	eth-ring	
	efm-oam	
	ont-loopdetect	
	ont-video	
	ont-ces	
	ont-voip	
	ont-video-ani	
	ont-pwe	
	ont-cese1	
	ont-xdsl	
	ont-xdsl-tca	
	ont-hpna	
	ont-sip-agent-cfg	
	ont-voip-cfg	
	ont-mgc	
	ont-ploam	
	ont-gen	
	ont-card	
	ont-pots	
	ont-lan	
	ont-moca	
	ont-tc-tca	
	ont-moca-tca	
	ont-l2uni-eth-tca	
	olt-pon-tc-tca	
	olt-pon-util-tca	
	olt-chpr-util-tca	
	olt-ont-tc-tca	
	ont-tca	
	ont-pots-supplemental	
	sfu-ploam	
	sfu-gen	
	soho-ploam	
	soho-gen	
	mdu-ploam	

101 query current alarms by filters

name	Type	Description
	mdu-gen ont-veip ont-iphost alarm-table auto-switch channel-pair ont-cfg-dld olt-chpair-tc-tca hgu-tr069 eqpt-psu ont-protection secondary-megaco-term secondary-sip-term cas-r2-channel lldpmed pseudo-wire link-agg fcs-exceed e1t1-interface) Possible values: - equipment : equipment alarms - eqpt-holder : equipment holder alarms - plug-in-unit : plugin unit alarms - atm : ATM alarms - custom : customizable alarms - e1 : e1 alarms - ima-group : ima-group alarms - ima-link : ima-link alarms - redundancy : redundancy alarms - shdsl : shdsl alarms - ether-itf : ethernet interface alarms - traffic-overflow : Traffic overflow alarms - qos-queue : qos queue alarms - temporal : temporal alarms - spatial : spatial alarms - software-mngt : software management alarms - sw-mgmt : software management alarms - xdsl : xDSL alarms - xdsl-ext : other xDSL alarms - xdsl-tca : xDSL threshold cross alarms - olt-gen : OLT general alarms - eo-conv : E/O conversion related alarms - authentication : authentication related alarms - bonding : bonding-group related alarms - sfp : SFP related alarms - shdsl-isam : shdsl isam alarms - custom-ext-alarm : customizable external alarms - plug-in-unit-ext : other plugin unit alarms - sip-user-agent : sip user agent related alarms - sip-plugin-unit : sip plug in unit related alarms - sip-termination : sip termination related alarms - e1-sip-termination : E1 sip termination related alarms - filetransfer : file transfer server alarms - external-device : external device related alarms - l2forward : l2forward related alarms - ether-tca : ethernet threshold cross alarms - ether-sfp : ethernet SFP related alarms	

name	Type	Description
	- megaco-media-gw : megaco media gateway related alarms - megaco-sig-gw : megaco signaling gateway related alarms - megaco-plug-unit : megaco plug unit related alarms - megaco-term : megaco termination related alarms - megaco-sig-lt : megaco signaling lt related alarms - eqpt-supplemental : equipment supplemental alarms - eqpt-holder-ext : other equipment holder alarms - lsmredundancy : lsm redundancy alarms - sync : synce and bits alarms - mcsrc : multicast source alarms - vlanport : vlanport alarms - vect-line : xDSL vectoring line alarms - vect-board : xDSL vectoring board alarms - otdr : otdr alarms - sip-dial-plan : sip dial plan related alarms - sip-vsp : sip vsp related alarms - sip-server : sip server related alarms - bgp : bgp related alarms - rip : rip related alarms - lag : LAG related alarms - ihub-general : IHUB general related alarms - vprn : vprn related alarms - isis : isis related alarms - ospf : ospf related alarms - ihub-l2forward : ihub-l2forward alarms - vpls : vpls related alarms - ihub-equip : ihub-equip related alarms - ihub-link : ihub-link related alarms - eont-phyoam : eont phyoam related alarms - ellid : ellid related alarms - epon : epon related alarms - eont-services-lan : eon phyoam related alarms - eolt-ont-tca : eon phyoam related alarms - eont-sw-dl : eon phyoam related alarms - ldp : ldp related alarms - mpls : mpls related alarms - sdp : sdp related alarms - epipe : epipe related alarms - ihub-ipv6 : ihub-ipv6 related alarms - pim : pim related alarms - li : lawful intercept related alarms - mgmt-sec-access : management security related alarms - bfd : bfd related alarms - ai : Application Intelligence related alarms - tr069serv : tr069 server related alarms - ontsnmp : ont snmp related alarms - bulk-sync : bulk-sync related alarms - protection-group : port protection group related alarms - ont : ONT general supplemental related alarms - sfu-sup : SFU ONT general supplemental related alarms - soho-sup : SOHO ONT general supplemental related alarms - mdu-sup : MDU ONT general supplemental related alarms - ont-ani : ONT general supplemental 2 related alarms - sfu-sup2 : SFU ONT general supplemental 2 related alarms - soho-sup2 : SOHO ONT general supplemental 2 related alarms	

101 query current alarms by filters

name	Type	Description
	- mdu-sup2 : MDU ONT general supplemental 2 related alarms - sfrprssi : SFP RSSI related alarms - eoltrssi : epon olt Sfp RSSI related alarms - cfm : Cfm related alarms - sfpe1t1-framer : SFP 2e1t1 framer alarms - sfpe1t1-clock : SFP 2e1t1 clock alarms - pppcc-engine-tca : PPPOE Cross Connect Engine TCA related alarm - eth-cfm : eth-cfm related alarms - rsvp : rsvp related alarms - ihub-tca : IHUB TCA related alarms - eth-ring : eth-ring related alarms - efm-oam : EFM-OAM related alarms - ont-loopdetect : ont loop detect related alarms - ont-video : ont services video related alarms - ont-ces : ont services ces related alarms - ont-voip : ont services voip related alarms - ont-video-ani : ont services video ani related alarms - ont-pwe : ont services pwe related alarms - ont-cese1 : ont services cese1 related alarms - ont-xdsl : ont services xdsl related alarms - ont-xdsl-tca : ont services xdsl tca related alarms - ont-hpna : ont hpna related alarms - ont-sip-agent-cfg : ont services voip sip agent config related alarms - ont-voip-cfg : ont services voip config related alarms - ont-mgc : ont mgc related alarms - ont-ploam : ONT PLOAM related alarms - ont-gen : ONT GENERAL related alarms - ont-card : ONT Subscriber Card related alarms - ont-pots : ONT Services POTS related alarms - ont-lan : ONT Services LAN related alarms - ont-moca : ONT MoCA related alarms - ont-tc-tca : ONT TC TCA related alarms - ont-moca-tca : ONT MoCA TCA related alarms - ont-l2uni-eth-tca : ONT L2 UNI Ethernet TCA related alarms - olt-pon-tc-tca : OLT PON TC TCA related alarms - olt-pon-util-tca : OLT PON utilization TCA related alarms - olt-chpr-util-tca : OLT channel-pair utilization TCA related alarms - olt-ont-tc-tca : OLT ONT TC TCA related alarms - ont-tca : ONT TCA related alarms - ont-pots-supplemental : ONT POTS Supplemental related alarms - sfu-ploam : SFU ONT PLOAM related alarms - sfu-gen : SFU ONT general related alarms - soho-ploam : SOHO ONT PLOAM related alarms - soho-gen : SOHO ONT general related alarms - mdu-ploam : MDU ONT PLOAM related alarms - mdu-gen : MDU ONT general related alarms - ont-veip : ONT VEIP related alarms - ont-iphost : ONT IP HOST related alarms - alarm-table : alarm table related alarms - auto-switch : auto-switch related alarms - channel-pair : channel pair related alarms	

name	Type	Description
	- ont-cfg-dld : ont configure file download related alarms - olt-chpair-tc-tca : OLT CHANNELPAIR TC TCA related alarms - hgu-tr069 : hgu tr069 related alarms - eqpt-psu : equipment psu alarms - ont-protection : ONT protection related alarms - secondary-megaco-term : secondary megaco termination related alarms - secondary-sip-term : secondary sip termination related alarms - cas-r2-channel : CAS R2 channel related alarms - lldpmed : lldpmed alarms - pseudo-wire : pseudo Wire related alarms - link-agg : Link aggregation related alarms - fcs-exceed : FCS auto-recovery related alarms - e1t1-interface : E1/T1 physical interfaces related alarms	
name	Parameter type: <Alarm::almtypeImagroup> (ima-grp-fe-su ima-grp-fe-cfg ima-grp-ne-cfg ima-grp-fe-nl ima-grp-ne-nl ima-grp-fe-blk all) Possible values: - ima-grp-fe-su : far-end starting up - ima-grp-fe-cfg : far-end failed configuration - ima-grp-ne-cfg : near-end failed configuration - ima-grp-fe-nl : insufficient number of links at far-end - ima-grp-ne-nl : insufficient number of links at near-end - ima-grp-fe-blk : far-end is blocked - all : show all ima-group alarm	alarm name that are active <i>This element is only shown in detail mode.</i>
severity	Parameter type: <Alarm::AlarmSeverity> (indeterminate warning minor major critical) Possible values: - indeterminate : alarm severity is indeterminate - warning : alarm severity is warning - minor : alarm severity is minor - major : alarm severity is major - critical : alarm severity is critical	the alarms severity level <i>This element is only shown in detail mode.</i>
servaff	Parameter type: <Alarm::alarmServAffect> ((service-affecting yes) (noservice-affecting no)) Possible values: - service-affecting : make this alarm service affecting - yes : make this alarm service affecting - noservice-affecting : make this alarm not service affecting - no : make this alarm not service affecting	alarms affect service or not <i>This element is only shown in detail mode.</i>
location	Parameter type: <Alarm::almLocation> (near-end far-end middle-end line)	alarm location: near, middle, far <i>This element is only shown in detail mode.</i>

101 query current alarms by filters

name	Type	Description
	null) Possible values: - near-end : alarm location is near - far-end : alarm location is far - middle-end : alarm location is middle - line : alarm location is line - null : alarm location not defined	
time	Parameter type: <Sys::timeInSecs> - the time (yyyy-mm-dd:hour:minutes:secs) - unit: UTC	time in seconds when alarm was updated <i>This element is only shown in detail mode.</i>
direction	Parameter type: <Alarm::almDirection> (received transmit null) Possible values: - received : alarm is received - transmit : alarm is transmit - null : direction not defined	alarm direction: received or transmit <i>This element is only shown in detail mode.</i>
descript	Parameter type: <Alarm::AddInfoString> - additional alarm information	alarm description <i>This element is only shown in detail mode.</i>

101.49 show current alarm by filters

Command Description

show current alarms by filters

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm query ima-link [ (name) [ severity <Alarm::querySeverity> ] [ servaff <Alarm::queryServAffect> ] [ port <Itf::ShdslLine> ] ]
```

Command Parameters

Table 101.49-1 "show current alarm by filters" Resource Parameters

Resource Identifier	Type	Description
(name)	Format: (ima-lnk-lif ima-lnk-lods ima-lnk-misc ima-lnk-rfi ima-lnk-fault ima-lnk-txblk ima-lnk-rxblk all) Possible values: - ima-lnk-lif : loss of ima frame - ima-lnk-lods : link out of delay synchronization - ima-lnk-misc : link misconnect - ima-lnk-rfi : link remote failure indication - ima-lnk-fault : fault in link facility - ima-lnk-txblk : transmit blocked due to far-end - ima-lnk-rxblk : receive blocked due to far-end - all : show all ima-link alarm	alarm name of ima-link
severity	Parameter type: <Alarm::querySeverity> Format: (indeterminate warning minor major critical all) Possible values: - indeterminate : alarm severity is indeterminate	severity level of an alarm for reporting

101 query current alarms by filters

Resource Identifier	Type	Description
	- warning : alarm severity is warning - minor : alarm severity is minor - major : alarm severity is major - critical : alarm severity is critical - all : all alarm severity	
servaff	Parameter type: <Alarm::queryServAffect> Format: (service-affecting noservice-affecting all) Possible values: - service-affecting : query alarm service affecting - noservice-affecting : query alarm not service affecting - all : query service affecting and not affecting alarms	serviceaffecting no serviceaffecting
port	Parameter type: <Itf::ShdslLine> Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number	the physical number of the port

Command Output

Table 101.49-2 "show current alarm by filters" Display parameters

Specific Information		
name	Type	Description
aidinfo	Parameter type: <Alarm::AddInfoString> - additional alarm information	alarm AID parameters <i>This element is only shown in detail mode.</i>
type	Parameter type: <Alarm::alarmIHUBType> (equipment eqpt-holder plug-in-unit atm custom e1 ima-group ima-link redundancy shdsl ether-itf traffic-overflow qos-queue temporal spatial (software-mngt sw-mgmt) xdsl xdsl-ext xdsl-tca olt-gen	type of the alarms that are active <i>This element is only shown in detail mode.</i>

name	Type	Description
	eo-conv	
	authentication	
	bonding	
	sfp	
	shdsl-isam	
	custom-ext-alarm	
	plug-in-unit-ext	
	sip-user-agent	
	sip-plugin-unit	
	sip-termination	
	e1-sip-termination	
	filetransfer	
	external-device	
	l2forward	
	ether-tca	
	ether-sfp	
	megaco-media-gw	
	megaco-sig-gw	
	megaco-plug-unit	
	megaco-term	
	megaco-sig-lt	
	eqpt-supplemental	
	eqpt-holder-ext	
	lsmredundancy	
	sync	
	mcsrc	
	vlanport	
	vect-line	
	vect-board	
	otdr	
	sip-dial-plan	
	sip-vsp	
	sip-server	
	bgp	
	rip	
	lag	
	ihub-general	
	vprn	
	isis	
	ospf	
	ihub-l2forward	
	vpls	
	ihub-equip	
	ihub-link	
	eont-phyoam	
	ellid	
	epon	
	eont-services-lan	
	eolt-ont-tca	
	eont-sw-dl	
	ldp	
	mpls	
	sdp	
	epipe	
	ihub-ipv6	
	pim	
	li	

101 query current alarms by filters

name	Type	Description
	mgmt-sec-access bfd ai tr069serv ontsnmp bulk-sync protection-group ont sfu-sup soho-sup mdu-sup ont-ani sfu-sup2 soho-sup2 mdu-sup2 sfprssi eoltrssi cfm sfpe1t1-framer sfpe1t1-clock pppcc-engine-tca eth-cfm rsvp ihub-tca eth-ring efm-oam ont-loopdetect ont-video ont-ces ont-voip ont-video-ani ont-pwe ont-cese1 ont-xdsl ont-xdsl-tca ont-hpna ont-sip-agent-cfg ont-voip-cfg ont-mgc ont-ploam ont-gen ont-card ont-pots ont-lan ont-moca ont-tc-tca ont-moca-tca ont-l2uni-eth-tca olt-pon-tc-tca olt-pon-util-tca olt-chpr-util-tca olt-ont-tc-tca ont-tca ont-pots-supplemental sfu-ploam sfu-gen soho-ploam	

name	Type	Description
	soho-gen mdu-ploam mdu-gen ont-veip ont-iphost alarm-table auto-switch channel-pair ont-cfg-dld olt-chpair-tc-tca hgu-tr069 eqpt-psu ont-protection secondary-megaco-term secondary-sip-term cas-r2-channel lldpmed pseudo-wire link-agg fcs-exceed e1t1-interface) Possible values: - equipment : equipment alarms - eqpt-holder : equipment holder alarms - plug-in-unit : plugin unit alarms - atm : ATM alarms - custom : customizable alarms - e1 : e1 alarms - ima-group : ima-group alarms - ima-link : ima-link alarms - redundancy : redundancy alarms - shdsl : shdsl alarms - ether-itf : ethernet interface alarms - traffic-overflow : Traffic overflow alarms - qos-queue : qos queue alarms - temporal : temporal alarms - spatial : spatial alarms - software-mngt : software management alarms - sw-mgmt : software management alarms - xdsl : xDSL alarms - xdsl-ext : other xDSL alarms - xdsl-tca : xDSL threshold cross alarms - olt-gen : OLT general alarms - eo-conv : E/O conversion related alarms - authentication : authentication related alarms - bonding : bonding-group related alarms - sfp : SFP related alarms - shdsl-isam : shdsl isam alarms - custom-ext-alarm : customizable external alarms - plug-in-unit-ext : other plugin unit alarms - sip-user-agent : sip user agent related alarms - sip-plugin-unit : sip plug in unit related alarms - sip-termination : sip termination related alarms - e1-sip-termination : E1 sip termination related alarms - filetransfer : file transfer server alarms - external-device : external device related alarms - l2forward : l2forward related alarms	

101 query current alarms by filters

name	Type	Description
	- ether-tca : ethernet threshold cross alarms - ether-sfp : ethernet SFP related alarms - megaco-media-gw : megaco media gateway related alarms - megaco-sig-gw : megaco signaling gateway related alarms - megaco-plug-unit : megaco plug unit related alarms - megaco-term : megaco termination related alarms - megaco-sig-lt : megaco signaling lt related alarms - eqpt-supplemental : equipment supplemental alarms - eqpt-holder-ext : other equipment holder alarms - lsmredundancy : lsm redundancy alarms - sync : synce and bits alarms - mcsrc : multicast source alarms - vlanport : vlanport alarms - vect-line : xDSL vectoring line alarms - vect-board : xDSL vectoring board alarms - otdr : otdr alarms - sip-dial-plan : sip dial plan related alarms - sip-vsp : sip vsp related alarms - sip-server : sip server related alarms - bgp : bgp related alarms - rip : rip related alarms - lag : LAG related alarms - ihub-general : IHUB general related alarms - vprn : vprn related alarms - isis : isis related alarms - ospf : ospf related alarms - ihub-l2forward : ihub-l2forward alarms - vpls : vpls related alarms - ihub-equip : ihub-equip related alarms - ihub-link : ihub-link related alarms - eont-phyoam : eont phyoam related alarms - ellid : ellid related alarms - epon : epon related alarms - eont-services-lan : eon phyoam related alarms - eolt-ont-tca : eon phyoam related alarms - eont-sw-dl : eon phyoam related alarms - ldp : ldp related alarms - mpls : mpls related alarms - sdp : sdp related alarms - epipe : epipe related alarms - ihub-ipv6 : ihub-ipv6 related alarms - pim : pim related alarms - li : lawful intercept related alarms - mgmt-sec-access : management security related alarms - bfd : bfd related alarms - ai : Application Intelligence related alarms - tr069serv : tr069 server related alarms - ontsnmp : ont snmp related alarms - bulk-sync : bulk-sync related alarms - protection-group : port protection group related alarms - ont : ONT general supplemental related alarms - sfu-sup : SFU ONT general supplemental related alarms - soho-sup : SOHO ONT general supplemental related alarms - mdu-sup : MDU ONT general supplemental related alarms - ont-ani : ONT general supplemental 2 related alarms - sfu-sup2 : SFU ONT general supplemental 2 related alarms	

name	Type	Description
	- soho-sup2 : SOHO ONT general supplemental 2 related alarms - mdu-sup2 : MDU ONT general supplemental 2 related alarms - sfrprssi : SFP RSSI related alarms - eoltrssi : epon olt Sfp RSSI related alarms - cfm : Cfm related alarms - sfpe1t1-framer : SFP 2e1t1 framer alarms - sfpe1t1-clock : SFP 2e1t1 clock alarms - pppcc-engine-tca : PPPOE Cross Connect Engine TCA related alarm - eth-cfm : eth-cfm related alarms - rsvp : rsvp related alarms - ihub-tca : IHUB TCA related alarms - eth-ring : eth-ring related alarms - efm-oam : EFM-OAM related alarms - ont-loopdetect : ont loop detect related alarms - ont-video : ont services video related alarms - ont-ces : ont services ces related alarms - ont-voip : ont services voip related alarms - ont-video-ani : ont services video ani related alarms - ont-pwe : ont services pwe related alarms - ont-cese1 : ont services cese1 related alarms - ont-xdsl : ont services xdsl related alarms - ont-xdsl-tca : ont services xdsl tca related alarms - ont-hpna : ont hpna related alarms - ont-sip-agent-cfg : ont services voip sip agent config related alarms - ont-voip-cfg : ont services voip config related alarms - ont-mgc : ont mgc related alarms - ont-ploam : ONT PLOAM related alarms - ont-gen : ONT GENERAL related alarms - ont-card : ONT Subscriber Card related alarms - ont-pots : ONT Services POTS related alarms - ont-lan : ONT Services LAN related alarms - ont-moca : ONT MoCA related alarms - ont-tc-tca : ONT TC TCA related alarms - ont-moca-tca : ONT MoCA TCA related alarms - ont-l2uni-eth-tca : ONT L2 UNI Ethernet TCA related alarms - olt-pon-tc-tca : OLT PON TC TCA related alarms - olt-pon-util-tca : OLT PON utilization TCA related alarms - olt-chpr-util-tca : OLT channel-pair utilization TCA related alarms - olt-ont-tc-tca : OLT ONT TC TCA related alarms - ont-tca : ONT TCA related alarms - ont-pots-supplemental : ONT POTS Supplemental related alarms - sfu-ploam : SFU ONT PLOAM related alarms - sfu-gen : SFU ONT general related alarms - soho-ploam : SOHO ONT PLOAM related alarms - soho-gen : SOHO ONT general related alarms - mdu-ploam : MDU ONT PLOAM related alarms - mdu-gen : MDU ONT general related alarms - ont-veip : ONT VEIP related alarms - ont-iphost : ONT IP HOST related alarms - alarm-table : alarm table related alarms	

101 query current alarms by filters

name	Type	Description
	- auto-switch : auto-switch related alarms - channel-pair : channel pair related alarms - ont-cfg-dld : ont configure file download related alarms - olt-chpair-tc-tca : OLT CHANNELPAIR TC TCA related alarms - hgu-tr069 : hgu tr069 related alarms - eqpt-psu : equipment psu alarms - ont-protection : ONT protection related alarms - secondary-megaco-term : secondary megaco termination related alarms - secondary-sip-term : secondary sip termination related alarms - cas-r2-channel : CAS R2 channel related alarms - lldpmed : lldpmed alarms - pseudo-wire : pseudo Wire related alarms - link-agg : Link aggregation related alarms - fcs-exceed : FCS auto-recovery related alarms - e1t1-interface : E1/T1 physical interfaces related alarms	
name	Parameter type: <Alarm::almTypeImalink> (ima-lnk-lif ima-lnk-lods ima-lnk-misc ima-lnk-rfi ima-lnk-fault ima-lnk-txblk ima-lnk-rxblk all) Possible values: - ima-lnk-lif : loss of ima frame - ima-lnk-lods : link out of delay synchronization - ima-lnk-misc : link misconnect - ima-lnk-rfi : link remote failure indication - ima-lnk-fault : fault in link facility - ima-lnk-txblk : transmit blocked due to far-end - ima-lnk-rxblk : receive blocked due to far-end - all : show all ima-link alarm	alarm name that are active <i>This element is only shown in detail mode.</i>
severity	Parameter type: <Alarm::AlarmSeverity> (indeterminate warning minor major critical) Possible values: - indeterminate : alarm severity is indeterminate - warning : alarm severity is warning - minor : alarm severity is minor - major : alarm severity is major - critical : alarm severity is critical	the alarms severity level <i>This element is only shown in detail mode.</i>
servaff	Parameter type: <Alarm::alarmServAffect> ((service-affecting yes) (noservice-affecting no)) Possible values: - service-affecting : make this alarm service affecting - yes : make this alarm service affecting - noservice-affecting : make this alarm not service affecting - no : make this alarm not service affecting	alarms affect service or not <i>This element is only shown in detail mode.</i>
location	Parameter type: <Alarm::almLocation>	alarm location: near, middle, far

name	Type	Description
	(near-end far-end middle-end line null) Possible values: - near-end : alarm location is near - far-end : alarm location is far - middle-end : alarm location is middle - line : alarm location is line - null : alarm location not defined	<i>This element is only shown in detail mode.</i>
time	Parameter type: <Sys::timeInSecs> - the time (yyyy-mm-dd:hour:minutes:secs) - unit: UTC	time in seconds when alarm was updated <i>This element is only shown in detail mode.</i>
direction	Parameter type: <Alarm::almDirection> (received transmit null) Possible values: - received : alarm is received - transmit : alarm is transmit - null : direction not defined	alarm direction: received or transmit <i>This element is only shown in detail mode.</i>
descript	Parameter type: <Alarm::AddInfoString> - additional alarm information	alarm description <i>This element is only shown in detail mode.</i>

101.50 show current alarm by filters

Command Description

show current alarms by filters

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm query ether-tca [ (name) [ severity <Alarm::querySeverity> ] [ servaff <Alarm::queryServAffect> ] [ port <If::EthernetPortIndex> ] ]
```

Command Parameters

Table 101.50-1 "show current alarm by filters" Resource Parameters

Resource Identifier	Type	Description
(name)	Format: (etca-los etca-fcs etca-day-los etca-day-fcs etca-rx-octets etca-tx-octets etca-day-rx-octets etca-day-tx-octets all) Possible values: - etca-los : loss of signal errors in 15 min - etca-fcs : frame check sequence errors in 15 min - etca-day-los : loss of signal errors in 1 day - etca-day-fcs : frame check sequence errors in 1 day - etca-rx-octets : received octets in 15 min - etca-tx-octets : transmitted octets in 15 min - etca-day-rx-octets : received octets in 1 day - etca-day-tx-octets : transmitted octets in 1 day - all : show all ethernet threshold cross alarm	alarm name of ether-tca
severity	Parameter type: <Alarm::querySeverity> Format: (indeterminate warning minor major critical all)	severity level of an alarm for reporting

Resource Identifier	Type	Description
	Possible values: - indeterminate : alarm severity is indeterminate - warning : alarm severity is warning - minor : alarm severity is minor - major : alarm severity is major - critical : alarm severity is critical - all : all alarm severity	
servaff	Parameter type: <Alarm::queryServAffect> Format: (service-affecting noservice-affecting all) Possible values: - service-affecting : query alarm service affecting - noservice-affecting : query alarm not service affecting - all : query service affecting and not affecting alarms	serviceaffecting no serviceaffecting
port	Parameter type: <Itf::EthernetPortIndex> Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number	the physical number of the port

Command Output

Table 101.50-2 "show current alarm by filters" Display parameters

Specific Information		
name	Type	Description
aidinfo	Parameter type: <Alarm::AddInfoString> - additional alarm information	alarm AID parameters <i>This element is only shown in detail mode.</i>
type	Parameter type: <Alarm::alarmIHUBType> (equipment eqpt-holder plug-in-unit atm custom e1 ima-group ima-link redundancy shdsl ether-itf traffic-overflow qos-queue temporal spatial (software-mngt sw-mgmt) xdsl xdsl-ext	type of the alarms that are active <i>This element is only shown in detail mode.</i>

101 query current alarms by filters

name	Type	Description
	xds1-tca olt-gen eo-conv authentication bonding sfp shdsl-isam custom-ext-alarm plug-in-unit-ext sip-user-agent sip-plugin-unit sip-termination e1-sip-termination filetransfer external-device l2forward ether-tca ether-sfp megaco-media-gw megaco-sig-gw megaco-plug-unit megaco-term megaco-sig-lt eqpt-supplemental eqpt-holder-ext lsmredundancy sync mcsrc vlanport vect-line vect-board otdr sip-dial-plan sip-vsp sip-server bgp rip lag ihub-general vprn isis ospf ihub-l2forward vpls ihub-equip ihub-link eont-phyoam ellid epon eont-services-lan eolt-ont-tca eont-sw-dl ldp mpls sdp epipe ihub-ipv6	

name	Type	Description
	pim li mgmt-sec-access bfd ai tr069serv ontsnmp bulk-sync protection-group ont sfu-sup soho-sup mdu-sup ont-ani sfu-sup2 soho-sup2 mdu-sup2 sfprssi eoltrssi cfm sfpe1t1-framer sfpe1t1-clock pppcc-engine-tca eth-cfm rsvp ihub-tca eth-ring efm-oam ont-loopdetect ont-video ont-ces ont-voip ont-video-ani ont-pwe ont-cese1 ont-xdsl ont-xdsl-tca ont-hpna ont-sip-agent-cfg ont-voip-cfg ont-mgc ont-ploam ont-gen ont-card ont-pots ont-lan ont-moca ont-tc-tca ont-moca-tca ont-l2uni-eth-tca olt-pon-tc-tca olt-pon-util-tca olt-chpr-util-tca olt-ont-tc-tca ont-tca ont-pots-supplemental sfu-ploam	

101 query current alarms by filters

name	Type	Description
	sfu-gen soho-ploam soho-gen mdu-ploam mdu-gen ont-veip ont-iphost alarm-table auto-switch channel-pair ont-cfg-dld olt-chpair-tc-tca hgu-tr069 eqpt-psu ont-protection secondary-megaco-term secondary-sip-term cas-r2-channel lldpmed pseudo-wire link-agg fcs-exceed e1t1-interface) Possible values: - equipment : equipment alarms - eqpt-holder : equipment holder alarms - plug-in-unit : plugin unit alarms - atm : ATM alarms - custom : customizable alarms - e1 : e1 alarms - ima-group : ima-group alarms - ima-link : ima-link alarms - redundancy : redundancy alarms - shdsl : shdsl alarms - ether-itf : ethernet interface alarms - traffic-overflow : Traffic overflow alarms - qos-queue : qos queue alarms - temporal : temporal alarms - spatial : spatial alarms - software-mngt : software management alarms - sw-mgmt : software management alarms - xdsl : xDSL alarms - xdsl-ext : other xDSL alarms - xdsl-tca : xDSL threshold cross alarms - olt-gen : OLT general alarms - eo-conv : E/O conversion related alarms - authentication : authentication related alarms - bonding : bonding-group related alarms - sfp : SFP related alarms - shdsl-isam : shdsl isam alarms - custom-ext-alarm : customizable external alarms - plug-in-unit-ext : other plugin unit alarms - sip-user-agent : sip user agent related alarms - sip-plugin-unit : sip plug in unit related alarms - sip-termination : sip termination related alarms - e1-sip-termination : E1 sip termination related alarms - filetransfer : file transfer server alarms	

name	Type	Description
	- external-device : external device related alarms - l2forward : l2forward related alarms - ether-tca : ethernet threshold cross alarms - ether-sfp : ethernet SFP related alarms - megaco-media-gw : megaco media gateway related alarms - megaco-sig-gw : megaco signaling gateway related alarms - megaco-plug-unit : megaco plug unit related alarms - megaco-term : megaco termination related alarms - megaco-sig-lt : megaco signaling lt related alarms - eqpt-supplemental : equipment supplemental alarms - eqpt-holder-ext : other equipment holder alarms - lsmredundancy : lsm redundancy alarms - sync : synce and bits alarms - mcsrc : multicast source alarms - vlanport : vlanport alarms - vect-line : xDSL vectoring line alarms - vect-board : xDSL vectoring board alarms - otdr : otdr alarms - sip-dial-plan : sip dial plan related alarms - sip-vsp : sip vsp related alarms - sip-server : sip server related alarms - bgp : bgp related alarms - rip : rip related alarms - lag : LAG related alarms - ihub-general : IHUB general related alarms - vprn : vprn related alarms - isis : isis related alarms - ospf : ospf related alarms - ihub-l2forward : ihub-l2forward alarms - vpls : vpls related alarms - ihub-equip : ihub-equip related alarms - ihub-link : ihub-link related alarms - eont-phyoam : eont phyoam related alarms - ellid : ellid related alarms - epon : epon related alarms - eont-services-lan : eon phyoam related alarms - eolt-ont-tca : eon phyoam related alarms - eont-sw-dl : eon phyoam related alarms - ldp : ldp related alarms - mpls : mpls related alarms - sdp : sdp related alarms - epipe : epipe related alarms - ihub-ipv6 : ihub-ipv6 related alarms - pim : pim related alarms - li : lawful intercept related alarms - mgmt-sec-access : management security related alarms - bfd : bfd related alarms - ai : Application Intelligence related alarms - tr069serv : tr069 server related alarms - ontsnmp : ont snmp related alarms - bulk-sync : bulk-sync related alarms - protection-group : port protection group related alarms - ont : ONT general supplemental related alarms - sfu-sup : SFU ONT general supplemental related alarms - soho-sup : SOHO ONT general supplemental related alarms - mdm-sup : MDU ONT general supplemental related alarms	

101 query current alarms by filters

name	Type	Description
	- ont-ani : ONT general supplemental 2 related alarms - sfu-sup2 : SFU ONT general supplemental 2 related alarms - soho-sup2 : SOHO ONT general supplemental 2 related alarms - mdu-sup2 : MDU ONT general supplemental 2 related alarms - sfprssi : SFP RSSI related alarms - eoltrssi : epon olt Sfp RSSI related alarms - cfm : Cfm related alarms - sfpe1t1-framer : SFP 2e1t1 framer alarms - sfpe1t1-clock : SFP 2e1t1 clock alarms - pppcc-engine-tca : PPPOE Cross Connect Engine TCA related alarm - eth-cfm : eth-cfm related alarms - rsvp : rsvp related alarms - ihub-tca : IHUB TCA related alarms - eth-ring : eth-ring related alarms - efm-oam : EFM-OAM related alarms - ont-loopdetect : ont loop detect related alarms - ont-video : ont services video related alarms - ont-ces : ont services ces related alarms - ont-voip : ont services voip related alarms - ont-video-ani : ont services video ani related alarms - ont-pwe : ont services pwe related alarms - ont-cese1 : ont services cese1 related alarms - ont-xdsl : ont services xdsl related alarms - ont-xdsl-tca : ont services xdsl tca related alarms - ont-hpna : ont hpna related alarms - ont-sip-agent-cfg : ont services voip sip agent config related alarms - ont-voip-cfg : ont services voip config related alarms - ont-mgc : ont mgc related alarms - ont-ploam : ONT PLOAM related alarms - ont-gen : ONT GENERAL related alarms - ont-card : ONT Subscriber Card related alarms - ont-pots : ONT Services POTS related alarms - ont-lan : ONT Services LAN related alarms - ont-moca : ONT MoCA related alarms - ont-tc-tca : ONT TC TCA related alarms - ont-moca-tca : ONT MoCA TCA related alarms - ont-l2uni-eth-tca : ONT L2 UNI Ethernet TCA related alarms - olt-pon-tc-tca : OLT PON TC TCA related alarms - olt-pon-util-tca : OLT PON utilization TCA related alarms - olt-chpr-util-tca : OLT channel-pair utilization TCA related alarms - olt-ont-tc-tca : OLT ONT TC TCA related alarms - ont-tca : ONT TCA related alarms - ont-pots-supplemental : ONT POTS Supplemental related alarms - sfu-ploam : SFU ONT PLOAM related alarms - sfu-gen : SFU ONT general related alarms - soho-ploam : SOHO ONT PLOAM related alarms - soho-gen : SOHO ONT general related alarms - mdu-ploam : MDU ONT PLOAM related alarms - mdu-gen : MDU ONT general related alarms - ont-veip : ONT VEIP related alarms	

name	Type	Description
	- ont-iphost : ONT IP HOST related alarms - alarm-table : alarm table related alarms - auto-switch : auto-switch related alarms - channel-pair : channel pair related alarms - ont-cfg-dld : ont configure file download related alarms - olt-chpair-tc-tca : OLT CHANNELPAIR TC TCA related alarms - hgu-tr069 : hgu tr069 related alarms - eqpt-psu : equipment psu alarms - ont-protection : ONT protection related alarms - secondary-megaco-term : secondary megaco termination related alarms - secondary-sip-term : secondary sip termination related alarms - cas-r2-channel : CAS R2 channel related alarms - lldpmed : lldpmed alarms - pseudo-wire : pseudo Wire related alarms - link-agg : Link aggregation related alarms - fcs-exceed : FCS auto-recovery related alarms - e1t1-interface : E1/T1 physical interfaces related alarms	
name	Parameter type: <Alarm::almtypeEthertca> (etca-los etca-fcs etca-day-los etca-day-fcs etca-rx-octets etca-tx-octets etca-day-rx-octets etca-day-tx-octets all) Possible values: - etca-los : loss of signal errors in 15 min - etca-fcs : frame check sequence errors in 15 min - etca-day-los : loss of signal errors in 1 day - etca-day-fcs : frame check sequence errors in 1 day - etca-rx-octets : received octets in 15 min - etca-tx-octets : transmitted octets in 15 min - etca-day-rx-octets : received octets in 1 day - etca-day-tx-octets : transmitted octets in 1 day - all : show all ethernet threshold cross alarm	alarm name that are active <i>This element is only shown in detail mode.</i>
severity	Parameter type: <Alarm::AlarmSeverity> (indeterminate warning minor major critical) Possible values: - indeterminate : alarm severity is indeterminate - warning : alarm severity is warning - minor : alarm severity is minor - major : alarm severity is major - critical : alarm severity is critical	the alarms severity level <i>This element is only shown in detail mode.</i>
servaff	Parameter type: <Alarm::alarmServAffect> ((service-affecting yes) (noservice-affecting no)) Possible values: - service-affecting : make this alarm service affecting	alarms affect service or not <i>This element is only shown in detail mode.</i>

101 query current alarms by filters

name	Type	Description
	- yes : make this alarm service affecting - noservice-affecting : make this alarm not service affecting - no : make this alarm not service affecting	
time	Parameter type: <Sys::timeInSecs> - the time (yyyy-mm-dd:hour:minutes:secs) - unit: UTC	time in seconds when alarm was updated <i>This element is only shown in detail mode.</i>
descript	Parameter type: <Alarm::AddInfoString> - additional alarm information	alarm description <i>This element is only shown in detail mode.</i>

101.51 show current alarm by filters

Command Description

show current alarms by filters

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm query ether-sfp [ (name) [ severity <Alarm::querySeverity> ] [ servaff <Alarm::queryServAffect> ] [ port <If::EthernetPortIndex> ] ]
```

Command Parameters

Table 101.51-1 "show current alarm by filters" Resource Parameters

Resource Identifier	Type	Description
(name)	Format: (user-sfp-los user-sfp-tx-fail user-sfp-not-prst user-sfp-inv-id user-sfp-t-exceed user-sfp-mismatch all) Possible values: - user-sfp-los : user sfp loss of signal - user-sfp-tx-fail : user sfp tx failure - user-sfp-not-prst : user sfp not detected - user-sfp-inv-id : user sfp invalid id - user-sfp-t-exceed : user sfp temperature exceed - user-sfp-mismatch : user sfp mismatch the configured type - all : show all ethernet SFP alarm	alarm name of ether-sfp
severity	Parameter type: <Alarm::querySeverity> Format: (indeterminate warning minor major critical all) Possible values: - indeterminate : alarm severity is indeterminate - warning : alarm severity is warning - minor : alarm severity is minor	severity level of an alarm for reporting

101 query current alarms by filters

Resource Identifier	Type	Description
	- major : alarm severity is major - critical : alarm severity is critical - all : all alarm severity	
servaff	Parameter type: <Alarm::queryServAffect> Format: (service-affecting noservice-affecting all) Possible values: - service-affecting : query alarm service affecting - noservice-affecting : query alarm not service affecting - all : query service affecting and not affecting alarms	serviceaffecting no serviceaffecting
port	Parameter type: <Itf::EthernetPortIndex> Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number	the physical number of the port

Command Output

Table 101.51-2 "show current alarm by filters" Display parameters

Specific Information		
name	Type	Description
aidinfo	Parameter type: <Alarm::AddInfoString> - additional alarm information	alarm AID parameters <i>This element is only shown in detail mode.</i>
type	Parameter type: <Alarm::alarmIHUBType> (equipment eqpt-holder plug-in-unit atm custom e1 ima-group ima-link redundancy shdsl ether-itf traffic-overflow qos-queue temporal spatial (software-mngt sw-mgmt) xdsl xdsl-ext xdsl-tca olt-gen eo-conv authentication	type of the alarms that are active <i>This element is only shown in detail mode.</i>

name	Type	Description
	bonding sfp shdsl-isam custom-ext-alarm plug-in-unit-ext sip-user-agent sip-plugin-unit sip-termination e1-sip-termination filetransfer external-device l2forward ether-tca ether-sfp megaco-media-gw megaco-sig-gw megaco-plug-unit megaco-term megaco-sig-lt eqpt-supplemental eqpt-holder-ext lsmredundancy sync mcsrc vlanport vect-line vect-board otdr sip-dial-plan sip-vsp sip-server bgp rip lag ihub-general vprn isis ospf ihub-l2forward vpls ihub-equip ihub-link eont-phyoam ellid epon eont-services-lan eolt-ont-tca eont-sw-dl ldp mpls sdp epipe ihub-ipv6 pim li mgmt-sec-access bfd	

101 query current alarms by filters

name	Type	Description
	ai	
	tr069serv	
	ontsnmp	
	bulk-sync	
	protection-group	
	ont	
	sfu-sup	
	soho-sup	
	mdu-sup	
	ont-ani	
	sfu-sup2	
	soho-sup2	
	mdu-sup2	
	sfprssi	
	eoltrssi	
	cfm	
	sfpe1t1-framer	
	sfpe1t1-clock	
	pppcc-engine-tca	
	eth-cfm	
	rsvp	
	ihub-tca	
	eth-ring	
	efm-oam	
	ont-loopdetect	
	ont-video	
	ont-ces	
	ont-voip	
	ont-video-ani	
	ont-pwe	
	ont-cese1	
	ont-xdsl	
	ont-xdsl-tca	
	ont-hpna	
	ont-sip-agent-cfg	
	ont-voip-cfg	
	ont-mgc	
	ont-ploam	
	ont-gen	
	ont-card	
	ont-pots	
	ont-lan	
	ont-moca	
	ont-tc-tca	
	ont-moca-tca	
	ont-l2uni-eth-tca	
	olt-pon-tc-tca	
	olt-pon-util-tca	
	olt-chpr-util-tca	
	olt-ont-tc-tca	
	ont-tca	
	ont-pots-supplemental	
	sfu-ploam	
	sfu-gen	
	soho-ploam	
	soho-gen	
	mdu-ploam	

name	Type	Description
	mdu-gen ont-veip ont-iphost alarm-table auto-switch channel-pair ont-cfg-dld olt-chpair-tc-tca hgu-tr069 eqpt-psu ont-protection secondary-megaco-term secondary-sip-term cas-r2-channel lldpmed pseudo-wire link-agg fcs-exceed e1t1-interface) Possible values: - equipment : equipment alarms - eqpt-holder : equipment holder alarms - plug-in-unit : plugin unit alarms - atm : ATM alarms - custom : customizable alarms - e1 : e1 alarms - ima-group : ima-group alarms - ima-link : ima-link alarms - redundancy : redundancy alarms - shdsl : shdsl alarms - ether-itf : ethernet interface alarms - traffic-overflow : Traffic overflow alarms - qos-queue : qos queue alarms - temporal : temporal alarms - spatial : spatial alarms - software-mngt : software management alarms - sw-mgmt : software management alarms - xdsl : xDSL alarms - xdsl-ext : other xDSL alarms - xdsl-tca : xDSL threshold cross alarms - olt-gen : OLT general alarms - eo-conv : E/O conversion related alarms - authentication : authentication related alarms - bonding : bonding-group related alarms - sfp : SFP related alarms - shdsl-isam : shdsl isam alarms - custom-ext-alarm : customizable external alarms - plug-in-unit-ext : other plugin unit alarms - sip-user-agent : sip user agent related alarms - sip-plugin-unit : sip plug in unit related alarms - sip-termination : sip termination related alarms - e1-sip-termination : E1 sip termination related alarms - filetransfer : file transfer server alarms - external-device : external device related alarms - l2forward : l2forward related alarms - ether-tca : ethernet threshold cross alarms - ether-sfp : ethernet SFP related alarms	

101 query current alarms by filters

name	Type	Description
	- megaco-media-gw : megaco media gateway related alarms - megaco-sig-gw : megaco signaling gateway related alarms - megaco-plug-unit : megaco plug unit related alarms - megaco-term : megaco termination related alarms - megaco-sig-lt : megaco signaling lt related alarms - eqpt-supplemental : equipment supplemental alarms - eqpt-holder-ext : other equipment holder alarms - lsmredundancy : lsm redundancy alarms - sync : synce and bits alarms - mcsrc : multicast source alarms - vlanport : vlanport alarms - vect-line : xDSL vectoring line alarms - vect-board : xDSL vectoring board alarms - otdr : otdr alarms - sip-dial-plan : sip dial plan related alarms - sip-vsp : sip vsp related alarms - sip-server : sip server related alarms - bgp : bgp related alarms - rip : rip related alarms - lag : LAG related alarms - ihub-general : IHUB general related alarms - vprn : vprn related alarms - isis : isis related alarms - ospf : ospf related alarms - ihub-l2forward : ihub-l2forward alarms - vpls : vpls related alarms - ihub-equip : ihub-equip related alarms - ihub-link : ihub-link related alarms - eont-phyoam : eont phyoam related alarms - ellid : ellid related alarms - epon : epon related alarms - eont-services-lan : eon phyoam related alarms - eolt-ont-tca : eon phyoam related alarms - eont-sw-dl : eon phyoam related alarms - ldp : ldp related alarms - mpls : mpls related alarms - sdp : sdp related alarms - epipe : epipe related alarms - ihub-ipv6 : ihub-ipv6 related alarms - pim : pim related alarms - li : lawful intercept related alarms - mgmt-sec-access : management security related alarms - bfd : bfd related alarms - ai : Application Intelligence related alarms - tr069serv : tr069 server related alarms - ontsnmp : ont snmp related alarms - bulk-sync : bulk-sync related alarms - protection-group : port protection group related alarms - ont : ONT general supplemental related alarms - sfu-sup : SFU ONT general supplemental related alarms - soho-sup : SOHO ONT general supplemental related alarms - mdu-sup : MDU ONT general supplemental related alarms - ont-ani : ONT general supplemental 2 related alarms - sfu-sup2 : SFU ONT general supplemental 2 related alarms - soho-sup2 : SOHO ONT general supplemental 2 related alarms	

name	Type	Description
	- mdu-sup2 : MDU ONT general supplemental 2 related alarms - sfrssi : SFP RSSI related alarms - eoltrssi : epon olt Sfp RSSI related alarms - cfm : Cfm related alarms - sfpe1t1-framer : SFP 2e1t1 framer alarms - sfpe1t1-clock : SFP 2e1t1 clock alarms - pppcc-engine-tca : PPPOE Cross Connect Engine TCA related alarm - eth-cfm : eth-cfm related alarms - rsvp : rsvp related alarms - ihub-tca : IHUB TCA related alarms - eth-ring : eth-ring related alarms - efm-oam : EFM-OAM related alarms - ont-loopdetect : ont loop detect related alarms - ont-video : ont services video related alarms - ont-ces : ont services ces related alarms - ont-voip : ont services voip related alarms - ont-video-ani : ont services video ani related alarms - ont-pwe : ont services pwe related alarms - ont-cese1 : ont services cese1 related alarms - ont-xdsl : ont services xdsl related alarms - ont-xdsl-tca : ont services xdsl tca related alarms - ont-hpna : ont hpna related alarms - ont-sip-agent-cfg : ont services voip sip agent config related alarms - ont-voip-cfg : ont services voip config related alarms - ont-mgc : ont mgc related alarms - ont-ploam : ONT PLOAM related alarms - ont-gen : ONT GENERAL related alarms - ont-card : ONT Subscriber Card related alarms - ont-pots : ONT Services POTS related alarms - ont-lan : ONT Services LAN related alarms - ont-moca : ONT MoCA related alarms - ont-tc-tca : ONT TC TCA related alarms - ont-moca-tca : ONT MoCA TCA related alarms - ont-l2uni-eth-tca : ONT L2 UNI Ethernet TCA related alarms - olt-pon-tc-tca : OLT PON TC TCA related alarms - olt-pon-util-tca : OLT PON utilization TCA related alarms - olt-chpr-util-tca : OLT channel-pair utilization TCA related alarms - olt-ont-tc-tca : OLT ONT TC TCA related alarms - ont-tca : ONT TCA related alarms - ont-pots-supplemental : ONT POTS Supplemental related alarms - sfu-ploam : SFU ONT PLOAM related alarms - sfu-gen : SFU ONT general related alarms - soho-ploam : SOHO ONT PLOAM related alarms - soho-gen : SOHO ONT general related alarms - mdu-ploam : MDU ONT PLOAM related alarms - mdu-gen : MDU ONT general related alarms - ont-veip : ONT VEIP related alarms - ont-iphost : ONT IP HOST related alarms - alarm-table : alarm table related alarms - auto-switch : auto-switch related alarms - channel-pair : channel pair related alarms	

101 query current alarms by filters

name	Type	Description
	- ont-cfg-dld : ont configure file download related alarms - olt-chpair-tc-tca : OLT CHANNELPAIR TC TCA related alarms - hgu-tr069 : hgu tr069 related alarms - eqpt-psu : equipment psu alarms - ont-protection : ONT protection related alarms - secondary-megaco-term : secondary megaco termination related alarms - secondary-sip-term : secondary sip termination related alarms - cas-r2-channel : CAS R2 channel related alarms - lldpmed : lldpmed alarms - pseudo-wire : pseudo Wire related alarms - link-agg : Link aggregation related alarms - fcs-exceed : FCS auto-recovery related alarms - e1t1-interface : E1/T1 physical interfaces related alarms	
name	Parameter type: <Alarm::alarmTypeEthersfp> (user-sfp-los user-sfp-tx-fail user-sfp-not-prst user-sfp-inv-id user-sfp-t-exceed user-sfp-mismatch all) Possible values: - user-sfp-los : user sfp loss of signal - user-sfp-tx-fail : user sfp tx failure - user-sfp-not-prst : user sfp not detected - user-sfp-inv-id : user sfp invalid id - user-sfp-t-exceed : user sfp temperature exceed - user-sfp-mismatch : user sfp mismatch the configured type - all : show all ethernet SFP alarm	alarm name that are active <i>This element is only shown in detail mode.</i>
severity	Parameter type: <Alarm::AlarmSeverity> (indeterminate warning minor major critical) Possible values: - indeterminate : alarm severity is indeterminate - warning : alarm severity is warning - minor : alarm severity is minor - major : alarm severity is major - critical : alarm severity is critical	the alarms severity level <i>This element is only shown in detail mode.</i>
servaff	Parameter type: <Alarm::alarmServAffect> ((service-affecting yes) (noservice-affecting no)) Possible values: - service-affecting : make this alarm service affecting - yes : make this alarm service affecting - noservice-affecting : make this alarm not service affecting - no : make this alarm not service affecting	alarms affect service or not <i>This element is only shown in detail mode.</i>
time	Parameter type: <Sys::timeInSecs> - the time (yyyy-mm-dd:hour:minutes:secs) - unit: UTC	time in seconds when alarm was updated <i>This element is only shown in detail mode.</i>
descript	Parameter type: <Alarm::AddInfoString>	alarm description

101 query current alarms by filters

name	Type	Description
	- additional alarm information	<i>This element is only shown in detail mode.</i>

101.52 show current alarm by filters

Command Description

show current alarms by filters

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm query uplink-ether-sfp [ (name) [ severity <Alarm::querySeverity> ] [ servaff
<Alarm::queryServAffect> ] [ port <Itf::EthernetPortIndex> ] ]
```

Command Parameters

Table 101.52-1 "show current alarm by filters" Resource Parameters

Resource Identifier	Type	Description
(name)	Format: (uplink-sfp-loss uplink-sfp-tx-fail uplink-sfp-not-prst uplink-sfp-inv-id uplink-sfp-t-exceed uplink-sfp-mismatch all) Possible values: - uplink-sfp-loss : uplink sfp loss of signal - uplink-sfp-tx-fail : uplink sfp tx failure - uplink-sfp-not-prst : uplink sfp is not detected - uplink-sfp-inv-id : uplink sfp invalid id - uplink-sfp-t-exceed : uplink sfp temperature exceed - uplink-sfp-mismatch : uplink sfp mismatch the configured type - all : show all uplink ethsfp alarm	alarm name of uplink-ether-sfp
severity	Parameter type: <Alarm::querySeverity> Format: (indeterminate warning minor major critical all) Possible values: - indeterminate : alarm severity is indeterminate - warning : alarm severity is warning	severity level of an alarm for reporting

Resource Identifier	Type	Description
	- minor : alarm severity is minor - major : alarm severity is major - critical : alarm severity is critical - all : all alarm severity	
servaff	Parameter type: <Alarm::queryServAffect> Format: (service-affecting noservice-affecting all) Possible values: - service-affecting : query alarm service affecting - noservice-affecting : query alarm not service affecting - all : query service affecting and not affecting alarms	serviceaffecting no serviceaffecting
port	Parameter type: <Itf::EthernetPortIndex> Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number	the physical number of the port

Command Output

Table 101.52-2 "show current alarm by filters" Display parameters

Specific Information		
name	Type	Description
aidinfo	Parameter type: <Alarm::AddInfoString> - additional alarm information	alarm AID parameters <i>This element is only shown in detail mode.</i>
type	Parameter type: <Alarm::alarmIHUBType> (equipment eqpt-holder plug-in-unit atm custom e1 ima-group ima-link redundancy shdsl ether-itf traffic-overflow qos-queue temporal spatial (software-mngt sw-mgmt) xdsl xdsl-ext xdsl-tca olt-gen eo-conv	type of the alarms that are active <i>This element is only shown in detail mode.</i>

101 query current alarms by filters

name	Type	Description
	authentication bonding sfp shdsl-isam custom-ext-alarm plug-in-unit-ext sip-user-agent sip-plugin-unit sip-termination e1-sip-termination filetransfer external-device l2forward ether-tca ether-sfp megaco-media-gw megaco-sig-gw megaco-plug-unit megaco-term megaco-sig-lt eqpt-supplemental eqpt-holder-ext lsmredundancy sync mcsrc vlanport vect-line vect-board otdr sip-dial-plan sip-vsp sip-server bgp rip lag ihub-general vprn isis ospf ihub-l2forward vpls ihub-equip ihub-link eont-phyoam ellid epon eont-services-lan eolt-ont-tca eont-sw-dl ldp mpls sdp epipe ihub-ipv6 pim li mgmt-sec-access	

name	Type	Description
	bfd	
	ai	
	tr069serv	
	ontsnmp	
	bulk-sync	
	protection-group	
	ont	
	sfu-sup	
	soho-sup	
	mdu-sup	
	ont-ani	
	sfu-sup2	
	soho-sup2	
	mdu-sup2	
	sfprssi	
	eoltrssi	
	cfm	
	sfpe1t1-framer	
	sfpe1t1-clock	
	pppcc-engine-tca	
	eth-cfm	
	rsvp	
	ihub-tca	
	eth-ring	
	efm-oam	
	ont-loopdetect	
	ont-video	
	ont-ces	
	ont-voip	
	ont-video-ani	
	ont-pwe	
	ont-cese1	
	ont-xdsl	
	ont-xdsl-tca	
	ont-hpna	
	ont-sip-agent-cfg	
	ont-voip-cfg	
	ont-mgc	
	ont-ploam	
	ont-gen	
	ont-card	
	ont-pots	
	ont-lan	
	ont-moca	
	ont-tc-tca	
	ont-moca-tca	
	ont-l2uni-eth-tca	
	olt-pon-tc-tca	
	olt-pon-util-tca	
	olt-chpr-util-tca	
	olt-ont-tc-tca	
	ont-tca	
	ont-pots-supplemental	
	sfu-ploam	
	sfu-gen	
	soho-ploam	
	soho-gen	

101 query current alarms by filters

name	Type	Description
	mdu-ploam mdu-gen ont-veip ont-iphost alarm-table auto-switch channel-pair ont-cfg-dld olt-chpair-tc-tca hgu-tr069 eqpt-psu ont-protection secondary-megaco-term secondary-sip-term cas-r2-channel lldpmed pseudo-wire link-agg fcs-exceed e1t1-interface) Possible values: - equipment : equipment alarms - eqpt-holder : equipment holder alarms - plug-in-unit : plugin unit alarms - atm : ATM alarms - custom : customizable alarms - e1 : e1 alarms - ima-group : ima-group alarms - ima-link : ima-link alarms - redundancy : redundancy alarms - shdsl : shdsl alarms - ether-itf : ethernet interface alarms - traffic-overflow : Traffic overflow alarms - qos-queue : qos queue alarms - temporal : temporal alarms - spatial : spatial alarms - software-mngt : software management alarms - sw-mgmt : software management alarms - xdsl : xDSL alarms - xdsl-ext : other xDSL alarms - xdsl-tca : xDSL threshold cross alarms - olt-gen : OLT general alarms - eo-conv : E/O conversion related alarms - authentication : authentication related alarms - bonding : bonding-group related alarms - sfp : SFP related alarms - shdsl-isam : shdsl isam alarms - custom-ext-alarm : customizable external alarms - plug-in-unit-ext : other plugin unit alarms - sip-user-agent : sip user agent related alarms - sip-plugin-unit : sip plug in unit related alarms - sip-termination : sip termination related alarms - e1-sip-termination : E1 sip termination related alarms - filetransfer : file transfer server alarms - external-device : external device related alarms - l2forward : l2forward related alarms - ether-tca : ethernet threshold cross alarms	

name	Type	Description
	- ether-sfp : ethernet SFP related alarms - megaco-media-gw : megaco media gateway related alarms - megaco-sig-gw : megaco signaling gateway related alarms - megaco-plug-unit : megaco plug unit related alarms - megaco-term : megaco termination related alarms - megaco-sig-lt : megaco signaling lt related alarms - eqpt-supplemental : equipment supplemental alarms - eqpt-holder-ext : other equipment holder alarms - lsmredundancy : lsm redundancy alarms - sync : synce and bits alarms - mcsrc : multicast source alarms - vlanport : vlanport alarms - vect-line : xDSL vectoring line alarms - vect-board : xDSL vectoring board alarms - otdr : otdr alarms - sip-dial-plan : sip dial plan related alarms - sip-vsp : sip vsp related alarms - sip-server : sip server related alarms - bgp : bgp related alarms - rip : rip related alarms - lag : LAG related alarms - ihub-general : IHUB general related alarms - vprn : vprn related alarms - isis : isis related alarms - ospf : ospf related alarms - ihub-l2forward : ihub-l2forward alarms - vpls : vpls related alarms - ihub-equip : ihub-equip related alarms - ihub-link : ihub-link related alarms - eont-phyoam : eont phyoam related alarms - ellid : ellid related alarms - epon : epon related alarms - eont-services-lan : eon phyoam related alarms - eolt-ont-tca : eon phyoam related alarms - eont-sw-dl : eon phyoam related alarms - ldp : ldp related alarms - mpls : mpls related alarms - sdp : sdp related alarms - epipe : epipe related alarms - ihub-ipv6 : ihub-ipv6 related alarms - pim : pim related alarms - li : lawful intercept related alarms - mgmt-sec-access : management security related alarms - bfd : bfd related alarms - ai : Application Intelligence related alarms - tr069serv : tr069 server related alarms - ontsnmp : ont snmp related alarms - bulk-sync : bulk-sync related alarms - protection-group : port protection group related alarms - ont : ONT general supplemental related alarms - sfu-sup : SFU ONT general supplemental related alarms - soho-sup : SOHO ONT general supplemental related alarms - mdu-sup : MDU ONT general supplemental related alarms - ont-ani : ONT general supplemental 2 related alarms - sfu-sup2 : SFU ONT general supplemental 2 related alarms - soho-sup2 : SOHO ONT general supplemental 2 related	

101 query current alarms by filters

name	Type	Description
	alarms - mdu-sup2 : MDU ONT general supplemental 2 related alarms - sfrprssi : SFP RSSI related alarms - eoltrssi : epon olt Sfp RSSI related alarms - cfm : Cfm related alarms - sfpe1t1-framer : SFP 2e1t1 framer alarms - sfpe1t1-clock : SFP 2e1t1 clock alarms - pppcc-engine-tca : PPPOE Cross Connect Engine TCA related alarm - eth-cfm : eth-cfm related alarms - rsvp : rsvp related alarms - ihub-tca : IHUB TCA related alarms - eth-ring : eth-ring related alarms - efm-oam : EFM-OAM related alarms - ont-loopdetect : ont loop detect related alarms - ont-video : ont services video related alarms - ont-ces : ont services ces related alarms - ont-voip : ont services voip related alarms - ont-video-ani : ont services video ani related alarms - ont-pwe : ont services pwe related alarms - ont-cese1 : ont services cese1 related alarms - ont-xdsl : ont services xdsl related alarms - ont-xdsl-tca : ont services xdsl tca related alarms - ont-hpna : ont hpna related alarms - ont-sip-agent-cfg : ont services voip sip agent config related alarms - ont-voip-cfg : ont services voip config related alarms - ont-mgc : ont mgc related alarms - ont-ploam : ONT PLOAM related alarms - ont-gen : ONT GENERAL related alarms - ont-card : ONT Subscriber Card related alarms - ont-pots : ONT Services POTS related alarms - ont-lan : ONT Services LAN related alarms - ont-moca : ONT MoCA related alarms - ont-tc-tca : ONT TC TCA related alarms - ont-moca-tca : ONT MoCA TCA related alarms - ont-l2uni-eth-tca : ONT L2 UNI Ethernet TCA related alarms - olt-pon-tc-tca : OLT PON TC TCA related alarms - olt-pon-util-tca : OLT PON utilization TCA related alarms - olt-chpr-util-tca : OLT channel-pair utilization TCA related alarms - olt-ont-tc-tca : OLT ONT TC TCA related alarms - ont-tca : ONT TCA related alarms - ont-pots-supplemental : ONT POTS Supplemental related alarms - sfu-ploam : SFU ONT PLOAM related alarms - sfu-gen : SFU ONT general related alarms - soho-ploam : SOHO ONT PLOAM related alarms - soho-gen : SOHO ONT general related alarms - mdu-ploam : MDU ONT PLOAM related alarms - mdu-gen : MDU ONT general related alarms - ont-veip : ONT VEIP related alarms - ont-iphost : ONT IP HOST related alarms - alarm-table : alarm table related alarms - auto-switch : auto-switch related alarms	

name	Type	Description
	- channel-pair : channel pair related alarms - ont-cfg-dld : ont configure file download related alarms - olt-chpair-tc-tca : OLT CHANNELPAIR TC TCA related alarms - hgu-tr069 : hgu tr069 related alarms - eqpt-psu : equipment psu alarms - ont-protection : ONT protection related alarms - secondary-megaco-term : secondary megaco termination related alarms - secondary-sip-term : secondary sip termination related alarms - cas-r2-channel : CAS R2 channel related alarms - lldpmed : lldpmed alarms - pseudo-wire : pseudo Wire related alarms - link-agg : Link aggregation related alarms - fcs-exceed : FCS auto-recovery related alarms - e1t1-interface : E1/T1 physical interfaces related alarms	
name	Parameter type: <Alarm::alarmTypeUpLinkEthSfp> (uplink-sfp-loss uplink-sfp-tx-fail uplink-sfp-not-prst uplink-sfp-inv-id uplink-sfp-t-exceed uplink-sfp-mismatch all) Possible values: - uplink-sfp-loss : uplink sfp loss of signal - uplink-sfp-tx-fail : uplink sfp tx failure - uplink-sfp-not-prst : uplink sfp is not detected - uplink-sfp-inv-id : uplink sfp invalid id - uplink-sfp-t-exceed : uplink sfp temperature exceed - uplink-sfp-mismatch : uplink sfp mismatch the configured type - all : show all uplink ethsfp alarm	alarm name that are active <i>This element is only shown in detail mode.</i>
severity	Parameter type: <Alarm::AlarmSeverity> (indeterminate warning minor major critical) Possible values: - indeterminate : alarm severity is indeterminate - warning : alarm severity is warning - minor : alarm severity is minor - major : alarm severity is major - critical : alarm severity is critical	the alarms severity level <i>This element is only shown in detail mode.</i>
servaff	Parameter type: <Alarm::alarmServAffect> ((service-affecting yes) (noservice-affecting no)) Possible values: - service-affecting : make this alarm service affecting - yes : make this alarm service affecting - noservice-affecting : make this alarm not service affecting - no : make this alarm not service affecting	alarms affect service or not <i>This element is only shown in detail mode.</i>
time	Parameter type: <Sys::timeInSecs> - the time (yyyy-mm-dd:hour:minutes:secs) - unit: UTC	time in seconds when alarm was updated <i>This element is only shown in</i>

101 query current alarms by filters

name	Type	Description
		<i>detail mode.</i>
descript	Parameter type: <Alarm::AddInfoString> - additional alarm information	alarm description <i>This element is only shown in detail mode.</i>

101.53 show current alarm by filters

Command Description

show current alarms by filters

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm query qos-queue [ (name) [ severity <Alarm::querySeverity> ] [ servaff <Alarm::queryServAffect> ]
[ port <If::PhyLine> ] ]
```

Command Parameters

Table 101.53-1 "show current alarm by filters" Resource Parameters

Resource Identifier	Type	Description
(name)	Format: (queue-drop queue-load queue-peak-usage all) Possible values: - queue-drop : The number of pkts dropped by queue exceeds threshold - queue-load : The queue load exceeds threshold - queue-peak-usage : The queue peak usage exceeds threshold - all : show all qos queue alarm	alarm name of qos-queue
severity	Parameter type: <Alarm::querySeverity> Format: (indeterminate warning minor major critical all) Possible values: - indeterminate : alarm severity is indeterminate - warning : alarm severity is warning - minor : alarm severity is minor - major : alarm severity is major - critical : alarm severity is critical - all : all alarm severity	severity level of an alarm for reporting
servaff	Parameter type: <Alarm::queryServAffect>	serviceaffecting no

101 query current alarms by filters

Resource Identifier	Type	Description
	Format: (service-affecting noservice-affecting all) Possible values: - service-affecting : query alarm service affecting - noservice-affecting : query alarm not service affecting - all : query service affecting and not affecting alarms	serviceaffecting
port	Parameter type: <Itf::PhyLine> Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> / <Eqpt::OntPortId> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / voip <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / vuni ont : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> ont.ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> uni.ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / <Eqpt::Ng2OntSlotId> / <Eqpt::Ng2OntPortId> uni.ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / vuni) Possible values: - ont : ont - ont.ng2 : ngpon2 ONT style identification - uni.ng2 : ngpon2 UNI style identification Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number Field type <Eqpt::PonId> - the PON identifier Field type <Eqpt::OntId> - the ONT identifier Field type <Eqpt::ChannelGroupId> - the channel group identifier Field type <Eqpt::SubChannelGroupId> - the subchannel group identifier Field type <Eqpt::Ng2OntId> - the NG2 ONT identifier Possible values: - voip : virtual uni identifier obsolete alternative replaced by vuni - vuni : virtual uni identifier Possible values: - vuni : virtual NGPON2 uni identifier Field type <Eqpt::OntSlotId>	the physical number of the port

Resource Identifier	Type	Description
	- the ONT SLOT identifier Field type <Eqpt::OntPortId> - the ONT PORT identifier Field type <Eqpt::Ng2OntSlotId> - the NGPON2 ONT SLOT identifier Field type <Eqpt::Ng2OntPortId> - the NGPON2 ONT PORT identifier	

Command Output

Table 101.53-2 "show current alarm by filters" Display parameters

Specific Information		
name	Type	Description
aidinfo	Parameter type: <Alarm::AddInfoString> - additional alarm information	alarm AID parameters <i>This element is only shown in detail mode.</i>
type	Parameter type: <Alarm::alarmIHUBType> (equipment eqpt-holder plug-in-unit atm custom e1 ima-group ima-link redundancy shdsl ether-itf traffic-overflow qos-queue temporal spatial (software-mngt sw-mgmt) xdsl xdsl-ext xdsl-tca olt-gen eo-conv authentication bonding sfp shdsl-isam custom-ext-alarm plug-in-unit-ext sip-user-agent sip-plugin-unit sip-termination e1-sip-termination filetransfer external-device l2forward ether-tca ether-sfp megaco-media-gw megaco-sig-gw megaco-plugin-unit	type of the alarms that are active <i>This element is only shown in detail mode.</i>

101 query current alarms by filters

name	Type	Description
	megaco-term megaco-sig-lt eqpt-supplemental eqpt-holder-ext lsmredundancy sync mcsrc vlanport vect-line vect-board otdr sip-dial-plan sip-vsp sip-server bgp rip lag ihub-general vprn isis ospf ihub-l2forward vpls ihub-equip ihub-link eont-phyoam ellid epon eont-services-lan eolt-ont-tca eont-sw-dl ldp mpls sdp epipe ihub-ipv6 pim li mgmt-sec-access bfd ai tr069serv ontsnmp bulk-sync protection-group ont sfu-sup soho-sup mdu-sup ont-ani sfu-sup2 soho-sup2 mdu-sup2 sfprssi eoltrssi cfm sfpe1t1-framer	

name	Type	Description
	sfpe1t1-clock pppcc-engine-tca eth-cfm rsvp ihub-tca eth-ring efm-oam ont-loopdetect ont-video ont-ces ont-voip ont-video-ani ont-pwe ont-cese1 ont-xdsl ont-xdsl-tca ont-hpna ont-sip-agent-cfg ont-voip-cfg ont-mgc ont-ploam ont-gen ont-card ont-pots ont-lan ont-moca ont-tc-tca ont-moca-tca ont-l2uni-eth-tca olt-pon-tc-tca olt-pon-util-tca olt-chpr-util-tca olt-ont-tc-tca ont-tca ont-pots-supplemental sfu-ploam sfu-gen soho-ploam soho-gen mdu-ploam mdu-gen ont-veip ont-iphost alarm-table auto-switch channel-pair ont-cfg-dld olt-chpair-tc-tca hgu-tr069 eqpt-psu ont-protection secondary-megaco-term secondary-sip-term cas-r2-channel lldpmed pseudo-wire link-agg	

101 query current alarms by filters

name	Type	Description
	fcs-exceed e1t1-interface) Possible values: - equipment : equipment alarms - eqpt-holder : equipment holder alarms - plug-in-unit : plugin unit alarms - atm : ATM alarms - custom : customizable alarms - e1 : e1 alarms - ima-group : ima-group alarms - ima-link : ima-link alarms - redundancy : redundancy alarms - shdsl : shdsl alarms - ether-itf : ethernet interface alarms - traffic-overflow : Traffic overflow alarms - qos-queue : qos queue alarms - temporal : temporal alarms - spatial : spatial alarms - software-mngt : software management alarms - sw-mgmt : software management alarms - xdsl : xDSL alarms - xdsl-ext : other xDSL alarms - xdsl-tca : xDSL threshold cross alarms - olt-gen : OLT general alarms - eo-conv : E/O conversion related alarms - authentication : authentication related alarms - bonding : bonding-group related alarms - sfp : SFP related alarms - shdsl-isam : shdsl isam alarms - custom-ext-alarm : customizable external alarms - plug-in-unit-ext : other plugin unit alarms - sip-user-agent : sip user agent related alarms - sip-plugin-unit : sip plug in unit related alarms - sip-termination : sip termination related alarms - e1-sip-termination : E1 sip termination related alarms - filetransfer : file transfer server alarms - external-device : external device related alarms - l2forward : l2forward related alarms - ether-tca : ethernet threshold cross alarms - ether-sfp : ethernet SFP related alarms - megaco-media-gw : megaco media gateway related alarms - megaco-sig-gw : megaco signaling gateway related alarms - megaco-plug-unit : megaco plug unit related alarms - megaco-term : megaco termination related alarms - megaco-sig-lt : megaco signaling lt related alarms - eqpt-supplemental : equipment supplemental alarms - eqpt-holder-ext : other equipment holder alarms - lsmredundancy : lsm redundancy alarms - sync : synce and bits alarms - mcsrc : multicast source alarms - vlanport : vlanport alarms - vect-line : xDSL vectoring line alarms - vect-board : xDSL vectoring board alarms - otdr : otdr alarms - sip-dial-plan : sip dial plan related alarms - sip-vsp : sip vsp related alarms - sip-server : sip server related alarms	

name	Type	Description
	- bgp : bgp related alarms - rip : rip related alarms - lag : LAG related alarms - ihub-general : IHUB general related alarms - vprn : vprn related alarms - isis : isis related alarms - ospf : ospf related alarms - ihub-l2forward : ihub-l2forward alarms - vpls : vpls related alarms - ihub-equip : ihub-equip related alarms - ihub-link : ihub-link related alarms - eont-phyoam : eont phyoam related alarms - ellid : ellid related alarms - epon : epon related alarms - eont-services-lan : eon phyoam related alarms - eolt-ont-tca : eon phyoam related alarms - eont-sw-dl : eon phyoam related alarms - ldp : ldp related alarms - mpls : mpls related alarms - sdp : sdp related alarms - epipe : epipe related alarms - ihub-ipv6 : ihub-ipv6 related alarms - pim : pim related alarms - li : lawful intercept related alarms - mgmt-sec-access : management security related alarms - bfd : bfd related alarms - ai : Application Intelligence related alarms - tr069serv : tr069 server related alarms - ontsnmp : ont snmp related alarms - bulk-sync : bulk-sync related alarms - protection-group : port protection group related alarms - ont : ONT general supplemental related alarms - sfu-sup : SFU ONT general supplemental related alarms - soho-sup : SOHO ONT general supplemental related alarms - mdu-sup : MDU ONT general supplemental related alarms - ont-ani : ONT general supplemental 2 related alarms - sfu-sup2 : SFU ONT general supplemental 2 related alarms - soho-sup2 : SOHO ONT general supplemental 2 related alarms - mdu-sup2 : MDU ONT general supplemental 2 related alarms - sfprssi : SFP RSSI related alarms - eoltrssi : epon olt Sfp RSSI related alarms - cfm : Cfm related alarms - sfpe1t1-framer : SFP 2e1t1 framer alarms - sfpe1t1-clock : SFP 2e1t1 clock alarms - pppcc-engine-tca : PPPOE Cross Connect Engine TCA related alarm - eth-cfm : eth-cfm related alarms - rsvp : rsvp related alarms - ihub-tca : IHUB TCA related alarms - eth-ring : eth-ring related alarms - efm-oam : EFM-OAM related alarms - ont-loopdetect : ont loop detect related alarms - ont-video : ont services video related alarms - ont-ces : ont services ces related alarms	

101 query current alarms by filters

name	Type	Description
	- ont-voip : ont services voip related alarms - ont-video-ani : ont services video ani related alarms - ont-pwe : ont services pwe related alarms - ont-cese1 : ont services cese1 related alarms - ont-xdsl : ont services xdsl related alarms - ont-xdsl-tca : ont services xdsl tca related alarms - ont-hpna : ont hpna related alarms - ont-sip-agent-cfg : ont services voip sip agent config related alarms - ont-voip-cfg : ont services voip config related alarms - ont-mgc : ont mgc related alarms - ont-ploam : ONT PLOAM related alarms - ont-gen : ONT GENERAL related alarms - ont-card : ONT Subscriber Card related alarms - ont-pots : ONT Services POTS related alarms - ont-lan : ONT Services LAN related alarms - ont-moca : ONT MoCA related alarms - ont-tc-tca : ONT TC TCA related alarms - ont-moca-tca : ONT MoCA TCA related alarms - ont-l2uni-eth-tca : ONT L2 UNI Ethernet TCA related alarms - olt-pon-tc-tca : OLT PON TC TCA related alarms - olt-pon-util-tca : OLT PON utilization TCA related alarms - olt-chpr-util-tca : OLT channel-pair utilization TCA related alarms - olt-ont-tc-tca : OLT ONT TC TCA related alarms - ont-tca : ONT TCA related alarms - ont-pots-supplemental : ONT POTS Supplemental related alarms - sfu-ploam : SFU ONT PLOAM related alarms - sfu-gen : SFU ONT general related alarms - soho-ploam : SOHO ONT PLOAM related alarms - soho-gen : SOHO ONT general related alarms - mdu-ploam : MDU ONT PLOAM related alarms - mdu-gen : MDU ONT general related alarms - ont-veip : ONT VEIP related alarms - ont-iphost : ONT IP HOST related alarms - alarm-table : alarm table related alarms - auto-switch : auto-switch related alarms - channel-pair : channel pair related alarms - ont-cfg-dld : ont configure file download related alarms - olt-chpair-tc-tca : OLT CHANNELPAIR TC TCA related alarms - hgu-tr069 : hgu tr069 related alarms - eqpt-psu : equipment psu alarms - ont-protection : ONT protection related alarms - secondary-megaco-term : secondary megaco termination related alarms - secondary-sip-term : secondary sip termination related alarms - cas-r2-channel : CAS R2 channel related alarms - lldpmed : lldpmed alarms - pseudo-wire : pseudo Wire related alarms - link-agg : Link aggregation related alarms - fcs-exceed : FCS auto-recovery related alarms - e1t1-interface : E1/T1 physical interfaces related alarms	
name	Parameter type: <Alarm::alarmtypeQosqueue>	alarm name that are active

name	Type	Description
	(queue-drop queue-load queue-peak-usage all) Possible values: - queue-drop : The number of pkts dropped by queue exceeds threshold - queue-load : The queue load exceeds threshold - queue-peak-usage : The queue peak usage exceeds threshold - all : show all qos queue alarm	<i>This element is only shown in detail mode.</i>
severity	Parameter type: <Alarm::AlarmSeverity> (indeterminate warning minor major critical) Possible values: - indeterminate : alarm severity is indeterminate - warning : alarm severity is warning - minor : alarm severity is minor - major : alarm severity is major - critical : alarm severity is critical	the alarms severity level <i>This element is only shown in detail mode.</i>
servaff	Parameter type: <Alarm::alarmServAffect> ((service-affecting yes) (noservice-affecting no)) Possible values: - service-affecting : make this alarm service affecting - yes : make this alarm service affecting - noservice-affecting : make this alarm not service affecting - no : make this alarm not service affecting	alarms affect service or not <i>This element is only shown in detail mode.</i>
time	Parameter type: <Sys::timeInSecs> - the time (yyyy-mm-dd:hour:minutes:secs) - unit: UTC	time in seconds when alarm was updated <i>This element is only shown in detail mode.</i>
descript	Parameter type: <Alarm::AddInfoString> - additional alarm information	alarm description <i>This element is only shown in detail mode.</i>

101.54 show current alarm by filters

Command Description

show current alarms by filters

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm query temporal [ (name) [ severity <Alarm::querySeverity> ] [ servaff <Alarm::queryServAffect> ] [ defaultaid <Alarm::queryDefaultAid> ] ]
```

Command Parameters

Table 101.54-1 "show current alarm by filters" Resource Parameters

Resource Identifier	Type	Description
(name)	Format: (der-temp1 der-temp2 der-temp3 der-temp4 der-temp5 der-temp6 der-temp7 der-temp8 der-temp9 der-temp10 der-temp11 der-temp12 der-temp13 der-temp14 der-temp15 der-temp16 der-temp17 der-temp18 der-temp19 der-temp20 der-temp21 der-temp22 der-temp23 der-temp24 der-temp25 der-temp26 der-temp27	alarm name of temporal filter

Resource Identifier	Type	Description
	der-temp28 der-temp29 der-temp30 der-temp31 all) Possible values: - der-temp1 : derived alarm for temporal filter 1 - der-temp2 : derived alarm for temporal filter 2 - der-temp3 : derived alarm for temporal filter 3 - der-temp4 : derived alarm for temporal filter 4 - der-temp5 : derived alarm for temporal filter 5 - der-temp6 : derived alarm for temporal filter 6 - der-temp7 : derived alarm for temporal filter 7 - der-temp8 : derived alarm for temporal filter 8 - der-temp9 : derived alarm for temporal filter 9 - der-temp10 : derived alarm for temporal filter 10 - der-temp11 : derived alarm for temporal filter 11 - der-temp12 : derived alarm for temporal filter 12 - der-temp13 : derived alarm for temporal filter 13 - der-temp14 : derived alarm for temporal filter 14 - der-temp15 : derived alarm for temporal filter 15 - der-temp16 : derived alarm for temporal filter 16 - der-temp17 : derived alarm for temporal filter 17 - der-temp18 : derived alarm for temporal filter 18 - der-temp19 : derived alarm for temporal filter 19 - der-temp20 : derived alarm for temporal filter 20 - der-temp21 : derived alarm for temporal filter 21 - der-temp22 : derived alarm for temporal filter 22 - der-temp23 : derived alarm for temporal filter 23 - der-temp24 : derived alarm for temporal filter 24 - der-temp25 : derived alarm for temporal filter 25 - der-temp26 : derived alarm for temporal filter 26 - der-temp27 : derived alarm for temporal filter 27 - der-temp28 : derived alarm for temporal filter 28 - der-temp29 : derived alarm for temporal filter 29 - der-temp30 : derived alarm for temporal filter 30 - der-temp31 : derived alarm for temporal filter 31 - all : temporal alarms	
severity	Parameter type: <Alarm::querySeverity> Format: (indeterminate warning minor major critical all) Possible values: - indeterminate : alarm severity is indeterminate - warning : alarm severity is warning - minor : alarm severity is minor - major : alarm severity is major - critical : alarm severity is critical - all : all alarm severity	severity level of an alarm for reporting
servaff	Parameter type: <Alarm::queryServAffect> Format: (service-affecting noservice-affecting	serviceaffecting no

101 query current alarms by filters

Resource Identifier	Type	Description
	all) Possible values: - service-affecting : query alarm service affecting - noservice-affecting : query alarm not service affecting - all : query service affecting and not affecting alarms	
defaultaid	Parameter type: <Alarm::queryDefaultAid> Format: all Possible values: - all : default AID parameter	default AID param is all

Command Output

Table 101.54-2 "show current alarm by filters" Display parameters

Specific Information		
name	Type	Description
aidinfo	Parameter type: <Alarm::AddInfoString> - additional alarm information	alarm AID parameters <i>This element is only shown in detail mode.</i>
type	Parameter type: <Alarm::alarmIHUBType> (equipment eqpt-holder plug-in-unit atm custom e1 ima-group ima-link redundancy shdsl ether-itf traffic-overflow qos-queue temporal spatial (software-mngt sw-mgmt) xdsl xdsl-ext xdsl-tca olt-gen eo-conv authentication bonding sfp shdsl-isam custom-ext-alarm plug-in-unit-ext sip-user-agent sip-plugin-unit sip-termination e1-sip-termination filetransfer external-device l2forward ether-tca ether-sfp)	type of the alarms that are active <i>This element is only shown in detail mode.</i>

name	Type	Description
	megaco-media-gw megaco-sig-gw megaco-plug-unit megaco-term megaco-sig-lt eqpt-supplemental eqpt-holder-ext lsmredundancy sync mcsrc vlanport vect-line vect-board otdr sip-dial-plan sip-vsp sip-server bgp rip lag ihub-general vprn isis ospf ihub-l2forward vpls ihub-equip ihub-link eont-phyoam ellid epon eont-services-lan eolt-ont-tca eont-sw-dl ldp mpls sdp epipe ihub-ipv6 pim li mgmt-sec-access bfd ai tr069serv ontsnmp bulk-sync protection-group ont sfu-sup soho-sup mdu-sup ont-ani sfu-sup2 soho-sup2 mdu-sup2 sfprssi	

101 query current alarms by filters

name	Type	Description
	eoltrssi cfm sfpe1t1-framer sfpe1t1-clock pppcc-engine-tca eth-cfm rsvp ihub-tca eth-ring efm-oam ont-loopdetect ont-video ont-ces ont-voip ont-video-ani ont-pwe ont-cese1 ont-xdsl ont-xdsl-tca ont-hpna ont-sip-agent-cfg ont-voip-cfg ont-mgc ont-ploam ont-gen ont-card ont-pots ont-lan ont-moca ont-tc-tca ont-moca-tca ont-l2uni-eth-tca olt-pon-tc-tca olt-pon-util-tca olt-chpr-util-tca olt-ont-tc-tca ont-tca ont-pots-supplemental sfu-ploam sfu-gen soho-ploam soho-gen mdu-ploam mdu-gen ont-veip ont-iphost alarm-table auto-switch channel-pair ont-cfg-dld olt-chpair-tc-tca hgu-tr069 eqpt-psu ont-protection secondary-megaco-term secondary-sip-term cas-r2-channel	

name	Type	Description
	lldpmed pseudo-wire link-agg fcs-exceed e1t1-interface) Possible values: - equipment : equipment alarms - eqpt-holder : equipment holder alarms - plug-in-unit : plugin unit alarms - atm : ATM alarms - custom : customizable alarms - e1 : e1 alarms - ima-group : ima-group alarms - ima-link : ima-link alarms - redundancy : redundancy alarms - shdsl : shdsl alarms - ether-itf : ethernet interface alarms - traffic-overflow : Traffic overflow alarms - qos-queue : qos queue alarms - temporal : temporal alarms - spatial : spatial alarms - software-mngt : software management alarms - sw-mgmt : software management alarms - xdsl : xDSL alarms - xdsl-ext : other xDSL alarms - xdsl-tca : xDSL threshold cross alarms - olt-gen : OLT general alarms - eo-conv : E/O conversion related alarms - authentication : authentication related alarms - bonding : bonding-group related alarms - sfp : SFP related alarms - shdsl-isam : shdsl isam alarms - custom-ext-alarm : customizable external alarms - plug-in-unit-ext : other plugin unit alarms - sip-user-agent : sip user agent related alarms - sip-plugin-unit : sip plug in unit related alarms - sip-termination : sip termination related alarms - e1-sip-termination : E1 sip termination related alarms - filetransfer : file transfer server alarms - external-device : external device related alarms - l2forward : l2forward related alarms - ether-tca : ethernet threshold cross alarms - ether-sfp : ethernet SFP related alarms - megaco-media-gw : megaco media gateway related alarms - megaco-sig-gw : megaco signaling gateway related alarms - megaco-plug-unit : megaco plug unit related alarms - megaco-term : megaco termination related alarms - megaco-sig-lt : megaco signaling lt related alarms - eqpt-supplemental : equipment supplemental alarms - eqpt-holder-ext : other equipment holder alarms - lsmredundancy : lsm redundancy alarms - sync : synce and bits alarms - mcsrc : multicast source alarms - vlanport : vlanport alarms - vect-line : xDSL vectoring line alarms - vect-board : xDSL vectoring board alarms - otdr : otdr alarms	

101 query current alarms by filters

name	Type	Description
	- sip-dial-plan : sip dial plan related alarms - sip-vsp : sip vsp related alarms - sip-server : sip server related alarms - bgp : bgp related alarms - rip : rip related alarms - lag : LAG related alarms - ihub-general : IHUB general related alarms - vprn : vprn related alarms - isis : isis related alarms - ospf : ospf related alarms - ihub-l2forward : ihub-l2forward alarms - vpls : vpls related alarms - ihub-equip : ihub-equip related alarms - ihub-link : ihub-link related alarms - eont-phyoam : eont phyoam related alarms - ellid : ellid related alarms - epon : epon related alarms - eont-services-lan : eon phyoam related alarms - eolt-ont-tca : eon phyoam related alarms - eont-sw-dl : eon phyoam related alarms - ldp : ldp related alarms - mpls : mpls related alarms - sdp : sdp related alarms - epipe : epipe related alarms - ihub-ipv6 : ihub-ipv6 related alarms - pim : pim related alarms - li : lawful intercept related alarms - mgmt-sec-access : management security related alarms - bfd : bfd related alarms - ai : Application Intelligence related alarms - tr069serv : tr069 server related alarms - ontsnmp : ont snmp related alarms - bulk-sync : bulk-sync related alarms - protection-group : port protection group related alarms - ont : ONT general supplemental related alarms - sfu-sup : SFU ONT general supplemental related alarms - soho-sup : SOHO ONT general supplemental related alarms - mdu-sup : MDU ONT general supplemental related alarms - ont-ani : ONT general supplemental 2 related alarms - sfu-sup2 : SFU ONT general supplemental 2 related alarms - soho-sup2 : SOHO ONT general supplemental 2 related alarms - mdu-sup2 : MDU ONT general supplemental 2 related alarms - sfprssi : SFP RSSI related alarms - eoltrssi : epon olt Sfp RSSI related alarms - cfm : Cfm related alarms - sfpe1t1-framer : SFP 2e1t1 framer alarms - sfpe1t1-clock : SFP 2e1t1 clock alarms - pppcc-engine-tca : PPPOE Cross Connect Engine TCA related alarm - eth-cfm : eth-cfm related alarms - rsvp : rsvp related alarms - ihub-tca : IHUB TCA related alarms - eth-ring : eth-ring related alarms - efm-oam : EFM-OAM related alarms	

name	Type	Description
	- ont-loopdetect : ont loop detect related alarms - ont-video : ont services video related alarms - ont-ces : ont services ces related alarms - ont-voip : ont services voip related alarms - ont-video-ani : ont services video ani related alarms - ont-pwe : ont services pwe related alarms - ont-cese1 : ont services cese1 related alarms - ont-xdsl : ont services xdsl related alarms - ont-xdsl-tca : ont services xdsl tca related alarms - ont-hpna : ont hpna related alarms - ont-sip-agent-cfg : ont services voip sip agent config related alarms - ont-voip-cfg : ont services voip config related alarms - ont-mgc : ont mgc related alarms - ont-ploam : ONT PLOAM related alarms - ont-gen : ONT GENERAL related alarms - ont-card : ONT Subscriber Card related alarms - ont-pots : ONT Services POTS related alarms - ont-lan : ONT Services LAN related alarms - ont-moca : ONT MoCA related alarms - ont-tc-tca : ONT TC TCA related alarms - ont-moca-tca : ONT MoCA TCA related alarms - ont-l2uni-eth-tca : ONT L2 UNI Ethernet TCA related alarms - olt-pon-tc-tca : OLT PON TC TCA related alarms - olt-pon-util-tca : OLT PON utilization TCA related alarms - olt-chpr-util-tca : OLT channel-pair utilization TCA related alarms - olt-ont-tc-tca : OLT ONT TC TCA related alarms - ont-tca : ONT TCA related alarms - ont-pots-supplemental : ONT POTS Supplemental related alarms - sfu-ploam : SFU ONT PLOAM related alarms - sfu-gen : SFU ONT general related alarms - soho-ploam : SOHO ONT PLOAM related alarms - soho-gen : SOHO ONT general related alarms - mdu-ploam : MDU ONT PLOAM related alarms - mdu-gen : MDU ONT general related alarms - ont-veip : ONT VEIP related alarms - ont-iphost : ONT IP HOST related alarms - alarm-table : alarm table related alarms - auto-switch : auto-switch related alarms - channel-pair : channel pair related alarms - ont-cfg-dld : ont configure file download related alarms - olt-chpair-tc-tca : OLT CHANNELPAIR TC TCA related alarms - hgu-tr069 : hgu tr069 related alarms - eqpt-psu : equipment psu alarms - ont-protection : ONT protection related alarms - secondary-megaco-term : secondary megaco termination related alarms - secondary-sip-term : secondary sip termination related alarms - cas-r2-channel : CAS R2 channel related alarms - lldpmed : lldpmed alarms - pseudo-wire : pseudo Wire related alarms - link-aggr : Link aggregation related alarms	

101 query current alarms by filters

name	Type	Description
	- fcs-exceed : FCS auto-recovery related alarms - e1t1-interface : E1/T1 physical interfaces related alarms	
name	Parameter type: <Alarm::almtypeTemporal> (der-temp1 der-temp2 der-temp3 der-temp4 der-temp5 der-temp6 der-temp7 der-temp8 der-temp9 der-temp10 der-temp11 der-temp12 der-temp13 der-temp14 der-temp15 der-temp16 der-temp17 der-temp18 der-temp19 der-temp20 der-temp21 der-temp22 der-temp23 der-temp24 der-temp25 der-temp26 der-temp27 der-temp28 der-temp29 der-temp30 der-temp31 all) Possible values: - der-temp1 : derived alarm for temporal filter 1 - der-temp2 : derived alarm for temporal filter 2 - der-temp3 : derived alarm for temporal filter 3 - der-temp4 : derived alarm for temporal filter 4 - der-temp5 : derived alarm for temporal filter 5 - der-temp6 : derived alarm for temporal filter 6 - der-temp7 : derived alarm for temporal filter 7 - der-temp8 : derived alarm for temporal filter 8 - der-temp9 : derived alarm for temporal filter 9 - der-temp10 : derived alarm for temporal filter 10 - der-temp11 : derived alarm for temporal filter 11 - der-temp12 : derived alarm for temporal filter 12 - der-temp13 : derived alarm for temporal filter 13 - der-temp14 : derived alarm for temporal filter 14 - der-temp15 : derived alarm for temporal filter 15 - der-temp16 : derived alarm for temporal filter 16 - der-temp17 : derived alarm for temporal filter 17 - der-temp18 : derived alarm for temporal filter 18 - der-temp19 : derived alarm for temporal filter 19 - der-temp20 : derived alarm for temporal filter 20 - der-temp21 : derived alarm for temporal filter 21	alarm name that are active <i>This element is only shown in detail mode.</i>

name	Type	Description
	- der-temp22 : derived alarm for temporal filter 22 - der-temp23 : derived alarm for temporal filter 23 - der-temp24 : derived alarm for temporal filter 24 - der-temp25 : derived alarm for temporal filter 25 - der-temp26 : derived alarm for temporal filter 26 - der-temp27 : derived alarm for temporal filter 27 - der-temp28 : derived alarm for temporal filter 28 - der-temp29 : derived alarm for temporal filter 29 - der-temp30 : derived alarm for temporal filter 30 - der-temp31 : derived alarm for temporal filter 31 - all : temporal alarms	
severity	Parameter type: <Alarm::AlarmSeverity> (indeterminate warning minor major critical) Possible values: - indeterminate : alarm severity is indeterminate - warning : alarm severity is warning - minor : alarm severity is minor - major : alarm severity is major - critical : alarm severity is critical	the alarms severity level <i>This element is only shown in detail mode.</i>
servaff	Parameter type: <Alarm::alarmServAffect> ((service-affecting yes) (noservice-affecting no)) Possible values: - service-affecting : make this alarm service affecting - yes : make this alarm service affecting - noservice-affecting : make this alarm not service affecting - no : make this alarm not service affecting	alarms affect service or not <i>This element is only shown in detail mode.</i>
time	Parameter type: <Sys::timeInSecs> - the time (yyyy-mm-dd:hour:minutes:secs) - unit: UTC	time in seconds when alarm was updated <i>This element is only shown in detail mode.</i>
descript	Parameter type: <Alarm::AddInfoString> - additional alarm information	alarm description <i>This element is only shown in detail mode.</i>

101.55 show current alarm by filters

Command Description

show current alarms by filters

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm query spatial [ (name) [ severity <Alarm::querySeverity> ] [ servaff <Alarm::queryServAffect> ] [ defaultaid <Alarm::queryDefaultAid> ] ]
```

Command Parameters

Table 101.55-1 "show current alarm by filters" Resource Parameters

Resource Identifier	Type	Description
(name)	Format: (der-spa1 der-spa2 der-spa3 der-spa4 der-spa5 der-spa6 der-spa7 der-spa8 der-spa9 der-spa10 der-spa11 der-spa12 der-spa13 der-spa14 der-spa15 der-spa16 der-spa17 der-spa18 der-spa19 der-spa20 der-spa21 der-spa22 der-spa23 der-spa24 der-spa25 der-spa26 der-spa27	alarm name of spatial filter

Resource Identifier	Type	Description
	der-spa28 der-spa29 der-spa30 der-spa31 all) Possible values: - der-spa1 : derived alarm for spatial filter 1 - der-spa2 : derived alarm for spatial filter 2 - der-spa3 : derived alarm for spatial filter 3 - der-spa4 : derived alarm for spatial filter 4 - der-spa5 : derived alarm for spatial filter 5 - der-spa6 : derived alarm for spatial filter 6 - der-spa7 : derived alarm for spatial filter 7 - der-spa8 : derived alarm for spatial filter 8 - der-spa9 : derived alarm for spatial filter 9 - der-spa10 : derived alarm for spatial filter 10 - der-spa11 : derived alarm for spatial filter 11 - der-spa12 : derived alarm for spatial filter 12 - der-spa13 : derived alarm for spatial filter 13 - der-spa14 : derived alarm for spatial filter 14 - der-spa15 : derived alarm for spatial filter 15 - der-spa16 : derived alarm for spatial filter 16 - der-spa17 : derived alarm for spatial filter 17 - der-spa18 : derived alarm for spatial filter 18 - der-spa19 : derived alarm for spatial filter 19 - der-spa20 : derived alarm for spatial filter 20 - der-spa21 : derived alarm for spatial filter 21 - der-spa22 : derived alarm for spatial filter 22 - der-spa23 : derived alarm for spatial filter 23 - der-spa24 : derived alarm for spatial filter 24 - der-spa25 : derived alarm for spatial filter 25 - der-spa26 : derived alarm for spatial filter 26 - der-spa27 : derived alarm for spatial filter 27 - der-spa28 : derived alarm for spatial filter 28 - der-spa29 : derived alarm for spatial filter 29 - der-spa30 : derived alarm for spatial filter 30 - der-spa31 : derived alarm for spatial filter 31 - all : spatial alarms	
severity	Parameter type: <Alarm::querySeverity> Format: (indeterminate warning minor major critical all) Possible values: - indeterminate : alarm severity is indeterminate - warning : alarm severity is warning - minor : alarm severity is minor - major : alarm severity is major - critical : alarm severity is critical - all : all alarm severity	severity level of an alarm for reporting
servaff	Parameter type: <Alarm::queryServAffect> Format: (service-affecting noservice-affecting	serviceaffecting no

101 query current alarms by filters

Resource Identifier	Type	Description
	all) Possible values: - service-affecting : query alarm service affecting - noservice-affecting : query alarm not service affecting - all : query service affecting and not affecting alarms	
defaultaid	Parameter type: <Alarm::queryDefaultAid> Format: all Possible values: - all : default AID parameter	default AID param is all

Command Output

Table 101.55-2 "show current alarm by filters" Display parameters

Specific Information		
name	Type	Description
type	Parameter type: <Alarm::alarmIHUBType> (equipment eqpt-holder plug-in-unit atm custom e1 ima-group ima-link redundancy shdsl ether-itf traffic-overflow qos-queue temporal spatial (software-mngt sw-mgmt) xdsl xdsl-ext xdsl-tca olt-gen eo-conv authentication bonding sfp shdsl-isam custom-ext-alarm plug-in-unit-ext sip-user-agent sip-plugin-unit sip-termination e1-sip-termination filetransfer external-device l2forward ether-tca ether-sfp megaco-media-gw megaco-sig-gw megaco-plugin-unit	type of the alarms that are active <i>This element is only shown in detail mode.</i>

name	Type	Description
	megaco-term megaco-sig-lt eqpt-supplemental eqpt-holder-ext lsmredundancy sync mcsrc vlanport vect-line vect-board otdr sip-dial-plan sip-vsp sip-server bgp rip lag ihub-general vprn isis ospf ihub-l2forward vpls ihub-equip ihub-link eont-phyoam ellid epon eont-services-lan eolt-ont-tca eont-sw-dl ldp mpls sdp epipe ihub-ipv6 pim li mgmt-sec-access bfd ai tr069serv ontsnmp bulk-sync protection-group ont sfu-sup soho-sup mdu-sup ont-ani sfu-sup2 soho-sup2 mdu-sup2 sfprssi eoltrssi cfm sfpe1t1-framer	

101 query current alarms by filters

name	Type	Description
	sfpe1t1-clock pppcc-engine-tca eth-cfm rsvp ihub-tca eth-ring efm-oam ont-loopdetect ont-video ont-ces ont-voip ont-video-ani ont-pwe ont-cese1 ont-xdsl ont-xdsl-tca ont-hpna ont-sip-agent-cfg ont-voip-cfg ont-mgc ont-ploam ont-gen ont-card ont-pots ont-lan ont-moca ont-tc-tca ont-moca-tca ont-l2uni-eth-tca olt-pon-tc-tca olt-pon-util-tca olt-chpr-util-tca olt-ont-tc-tca ont-tca ont-pots-supplemental sfu-ploam sfu-gen soho-ploam soho-gen mdu-ploam mdu-gen ont-veip ont-iphost alarm-table auto-switch channel-pair ont-cfg-dld olt-chpair-tc-tca hgu-tr069 eqpt-psu ont-protection secondary-megaco-term secondary-sip-term cas-r2-channel lldpmed pseudo-wire link-agg	

name	Type	Description
	fcs-exceed e1t1-interface) Possible values: - equipment : equipment alarms - eqpt-holder : equipment holder alarms - plug-in-unit : plugin unit alarms - atm : ATM alarms - custom : customizable alarms - e1 : e1 alarms - ima-group : ima-group alarms - ima-link : ima-link alarms - redundancy : redundancy alarms - shdsl : shdsl alarms - ether-itf : ethernet interface alarms - traffic-overflow : Traffic overflow alarms - qos-queue : qos queue alarms - temporal : temporal alarms - spatial : spatial alarms - software-mngt : software management alarms - sw-mgmt : software management alarms - xdsl : xDSL alarms - xdsl-ext : other xDSL alarms - xdsl-tca : xDSL threshold cross alarms - olt-gen : OLT general alarms - eo-conv : E/O conversion related alarms - authentication : authentication related alarms - bonding : bonding-group related alarms - sfp : SFP related alarms - shdsl-isam : shdsl isam alarms - custom-ext-alarm : customizable external alarms - plug-in-unit-ext : other plugin unit alarms - sip-user-agent : sip user agent related alarms - sip-plugin-unit : sip plug in unit related alarms - sip-termination : sip termination related alarms - e1-sip-termination : E1 sip termination related alarms - filetransfer : file transfer server alarms - external-device : external device related alarms - l2forward : l2forward related alarms - ether-tca : ethernet threshold cross alarms - ether-sfp : ethernet SFP related alarms - megaco-media-gw : megaco media gateway related alarms - megaco-sig-gw : megaco signaling gateway related alarms - megaco-plug-unit : megaco plug unit related alarms - megaco-term : megaco termination related alarms - megaco-sig-lt : megaco signaling lt related alarms - eqpt-supplemental : equipment supplemental alarms - eqpt-holder-ext : other equipment holder alarms - lsmredundancy : lsm redundancy alarms - sync : synce and bits alarms - mcsrc : multicast source alarms - vlanport : vlanport alarms - vect-line : xDSL vectoring line alarms - vect-board : xDSL vectoring board alarms - otdr : otdr alarms - sip-dial-plan : sip dial plan related alarms - sip-vsp : sip vsp related alarms - sip-server : sip server related alarms	

101 query current alarms by filters

name	Type	Description
	- bgp : bgp related alarms - rip : rip related alarms - lag : LAG related alarms - ihub-general : IHUB general related alarms - vprn : vprn related alarms - isis : isis related alarms - ospf : ospf related alarms - ihub-l2forward : ihub-l2forward alarms - vpls : vpls related alarms - ihub-equip : ihub-equip related alarms - ihub-link : ihub-link related alarms - eont-phyoam : eont phyoam related alarms - ellid : ellid related alarms - epon : epon related alarms - eont-services-lan : eon phyoam related alarms - eolt-ont-tca : eon phyoam related alarms - eont-sw-dl : eon phyoam related alarms - ldp : ldp related alarms - mpls : mpls related alarms - sdp : sdp related alarms - epipe : epipe related alarms - ihub-ipv6 : ihub-ipv6 related alarms - pim : pim related alarms - li : lawful intercept related alarms - mgmt-sec-access : management security related alarms - bfd : bfd related alarms - ai : Application Intelligence related alarms - tr069serv : tr069 server related alarms - ontsnmp : ont snmp related alarms - bulk-sync : bulk-sync related alarms - protection-group : port protection group related alarms - ont : ONT general supplemental related alarms - sfu-sup : SFU ONT general supplemental related alarms - soho-sup : SOHO ONT general supplemental related alarms - mdu-sup : MDU ONT general supplemental related alarms - ont-ani : ONT general supplemental 2 related alarms - sfu-sup2 : SFU ONT general supplemental 2 related alarms - soho-sup2 : SOHO ONT general supplemental 2 related alarms - mdu-sup2 : MDU ONT general supplemental 2 related alarms - sfprssi : SFP RSSI related alarms - eoltrssi : epon olt Sfp RSSI related alarms - cfm : Cfm related alarms - sfpe1t1-framer : SFP 2e1t1 framer alarms - sfpe1t1-clock : SFP 2e1t1 clock alarms - pppcc-engine-tca : PPPOE Cross Connect Engine TCA related alarm - eth-cfm : eth-cfm related alarms - rsvp : rsvp related alarms - ihub-tca : IHUB TCA related alarms - eth-ring : eth-ring related alarms - efm-oam : EFM-OAM related alarms - ont-loopdetect : ont loop detect related alarms - ont-video : ont services video related alarms - ont-ces : ont services ces related alarms	

name	Type	Description
	- ont-voip : ont services voip related alarms - ont-video-ani : ont services video ani related alarms - ont-pwe : ont services pwe related alarms - ont-cese1 : ont services cese1 related alarms - ont-xdsl : ont services xdsl related alarms - ont-xdsl-tca : ont services xdsl tca related alarms - ont-hpna : ont hpna related alarms - ont-sip-agent-cfg : ont services voip sip agent config related alarms - ont-voip-cfg : ont services voip config related alarms - ont-mgc : ont mgc related alarms - ont-ploam : ONT PLOAM related alarms - ont-gen : ONT GENERAL related alarms - ont-card : ONT Subscriber Card related alarms - ont-pots : ONT Services POTS related alarms - ont-lan : ONT Services LAN related alarms - ont-moca : ONT MoCA related alarms - ont-tc-tca : ONT TC TCA related alarms - ont-moca-tca : ONT MoCA TCA related alarms - ont-l2uni-eth-tca : ONT L2 UNI Ethernet TCA related alarms - olt-pon-tc-tca : OLT PON TC TCA related alarms - olt-pon-util-tca : OLT PON utilization TCA related alarms - olt-chpr-util-tca : OLT channel-pair utilization TCA related alarms - olt-ont-tc-tca : OLT ONT TC TCA related alarms - ont-tca : ONT TCA related alarms - ont-pots-supplemental : ONT POTS Supplemental related alarms - sfu-ploam : SFU ONT PLOAM related alarms - sfu-gen : SFU ONT general related alarms - soho-ploam : SOHO ONT PLOAM related alarms - soho-gen : SOHO ONT general related alarms - mdu-ploam : MDU ONT PLOAM related alarms - mdu-gen : MDU ONT general related alarms - ont-veip : ONT VEIP related alarms - ont-iphost : ONT IP HOST related alarms - alarm-table : alarm table related alarms - auto-switch : auto-switch related alarms - channel-pair : channel pair related alarms - ont-cfg-dld : ont configure file download related alarms - olt-chpair-tc-tca : OLT CHANNELPAIR TC TCA related alarms - hgu-tr069 : hgu tr069 related alarms - eqpt-psu : equipment psu alarms - ont-protection : ONT protection related alarms - secondary-megaco-term : secondary megaco termination related alarms - secondary-sip-term : secondary sip termination related alarms - cas-r2-channel : CAS R2 channel related alarms - lldpmed : lldpmed alarms - pseudo-wire : pseudo Wire related alarms - link-agg : Link aggregation related alarms - fcs-exceed : FCS auto-recovery related alarms - e1t1-interface : E1/T1 physical interfaces related alarms	
name	Parameter type: <Alarm::almtypeSpatial>	alarm name that are active

101 query current alarms by filters

name	Type	Description
	(der-spa1 der-spa2 der-spa3 der-spa4 der-spa5 der-spa6 der-spa7 der-spa8 der-spa9 der-spa10 der-spa11 der-spa12 der-spa13 der-spa14 der-spa15 der-spa16 der-spa17 der-spa18 der-spa19 der-spa20 der-spa21 der-spa22 der-spa23 der-spa24 der-spa25 der-spa26 der-spa27 der-spa28 der-spa29 der-spa30 der-spa31 all) Possible values: - der-spa1 : derived alarm for spatial filter 1 - der-spa2 : derived alarm for spatial filter 2 - der-spa3 : derived alarm for spatial filter 3 - der-spa4 : derived alarm for spatial filter 4 - der-spa5 : derived alarm for spatial filter 5 - der-spa6 : derived alarm for spatial filter 6 - der-spa7 : derived alarm for spatial filter 7 - der-spa8 : derived alarm for spatial filter 8 - der-spa9 : derived alarm for spatial filter 9 - der-spa10 : derived alarm for spatial filter 10 - der-spa11 : derived alarm for spatial filter 11 - der-spa12 : derived alarm for spatial filter 12 - der-spa13 : derived alarm for spatial filter 13 - der-spa14 : derived alarm for spatial filter 14 - der-spa15 : derived alarm for spatial filter 15 - der-spa16 : derived alarm for spatial filter 16 - der-spa17 : derived alarm for spatial filter 17 - der-spa18 : derived alarm for spatial filter 18 - der-spa19 : derived alarm for spatial filter 19 - der-spa20 : derived alarm for spatial filter 20 - der-spa21 : derived alarm for spatial filter 21 - der-spa22 : derived alarm for spatial filter 22 - der-spa23 : derived alarm for spatial filter 23 - der-spa24 : derived alarm for spatial filter 24	<i>This element is only shown in detail mode.</i>

name	Type	Description
	- der-spa25 : derived alarm for spatial filter 25 - der-spa26 : derived alarm for spatial filter 26 - der-spa27 : derived alarm for spatial filter 27 - der-spa28 : derived alarm for spatial filter 28 - der-spa29 : derived alarm for spatial filter 29 - der-spa30 : derived alarm for spatial filter 30 - der-spa31 : derived alarm for spatial filter 31 - all : spatial alarms	
severity	Parameter type: <Alarm::AlarmSeverity> (indeterminate warning minor major critical) Possible values: - indeterminate : alarm severity is indeterminate - warning : alarm severity is warning - minor : alarm severity is minor - major : alarm severity is major - critical : alarm severity is critical	the alarms severity level <i>This element is only shown in detail mode.</i>
servaff	Parameter type: <Alarm::alarmServAffect> ((service-affecting yes) (noservice-affecting no)) Possible values: - service-affecting : make this alarm service affecting - yes : make this alarm service affecting - noservice-affecting : make this alarm not service affecting - no : make this alarm not service affecting	alarms affect service or not <i>This element is only shown in detail mode.</i>
time	Parameter type: <Sys::timeInSecs> - the time (yyyy-mm-dd:hour:minutes:secs) - unit: UTC	time in seconds when alarm was updated <i>This element is only shown in detail mode.</i>
descript	Parameter type: <Alarm::AddInfoString> - additional alarm information	alarm description <i>This element is only shown in detail mode.</i>

101.56 show current alarm by filters

Command Description

show current alarms by filters

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm query ont-ploam [ (name) [ severity <Alarm::querySeverity> ] [ servaff <Alarm::queryServAffect> ]
[ ont <Gpon::OntIndex> ] ]
```

Command Parameters

Table 101.56-1 "show current alarm by filters" Resource Parameters

Resource Identifier	Type	Description
(name)	Format: (ont-ploam-loss-sig ont-ploam-loss-ack ont-ploam-loss-cd ont-ploam-phy-eqpt-err ont-ploam-startup-fail ont-ploam-sig-degrade ont-ploam-disabled ont-ploam-err-msg ont-ploam-inactive ont-ploam-sig-fail ont-ploam-dying-gasp ont-ploam-deact-fail ont-ploam-oam ont-ploam-win-drift ont-ploam-rdi ont-ploam-loss-ks ont-ploam-pwr-burst ont-ploam-rog-disa ont-ploam-diff-reach ont-ploam-looc all) Possible values: - ont-ploam-loss-sig : loss of signal at ont - ont-ploam-loss-ack : loss of acknowledge from ont - ont-ploam-loss-cd : loss of channel delineation of ont - ont-ploam-phy-eqpt-err: physical equipment error of ont - ont-ploam-startup-fail: startup failure in ranging of ont	alarm name of ONT PLOAM

Resource Identifier	Type	Description
	- ont-ploam-sig-degrade : signal degrade from ont - ont-ploam-disabled : ont disabled alarm - ont-ploam-err-msg : error message from ont - ont-ploam-inactive : inactive ont - ont-ploam-sig-fail : signal fail alarm from ont - ont-ploam-dying-gasp : dying gasp alarm from ont - ont-ploam-deact-fail : deactive failure of ont - ont-ploam-oam : loss of ploam for ont - ont-ploam-win-drift : drift of window alarm - ont-ploam-rdi : remote defect indication alarm - ont-ploam-loss-ks : loss of key synchronization alarm - ont-ploam-pwr-burst : power bursts on ont - ont-ploam-rog-disa : ont rogue disabled - ont-ploam-diff-reach : ont differential reach exceeded - ont-ploam-looc : Loss of OMCI channel due to persistent MIC failure - all : show ont ploam related alarms	
severity	Parameter type: <Alarm::querySeverity> Format: (indeterminate warning minor major critical all) Possible values: - indeterminate : alarm severity is indeterminate - warning : alarm severity is warning - minor : alarm severity is minor - major : alarm severity is major - critical : alarm severity is critical - all : all alarm severity	severity level of an alarm for reporting
servaff	Parameter type: <Alarm::queryServAffect> Format: (service-affecting noservice-affecting all) Possible values: - service-affecting : query alarm service affecting - noservice-affecting : query alarm not service affecting - all : query service affecting and not affecting alarms	serviceaffecting no serviceaffecting
ont	Parameter type: <Gpon::OntIndex> Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> ng2 : <Ng2::ChannelGroup> / <Ng2::SubchannelGroup> / <Ng2::OntId>) Possible values: - ng2 : ngpon2 style identification Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier	gpon ont equipment ifindex of ont

101 query current alarms by filters

Resource Identifier	Type	Description
	Field type <Ng2::ChannelGroup> - channel group number Field type <Ng2::SubchannelGroup> - subchannel group number Field type <Eqpt::OntId> - the ONT identifier Field type <Ng2::OntId> - the ONT identifier	

Command Output

Table 101.56-2 "show current alarm by filters" Display parameters

Specific Information		
name	Type	Description
aidinfo	Parameter type: <Alarm::AddInfoString> - additional alarm information	alarm AID parameters <i>This element is only shown in detail mode.</i>
type	Parameter type: <Alarm::alarmIHUBType> (equipment eqpt-holder plug-in-unit atm custom e1 ima-group ima-link redundancy shdsl ether-itf traffic-overflow qos-queue temporal spatial (software-mngt sw-mgmt) xdsl xdsl-ext xdsl-tca olt-gen eo-conv authentication bonding sfp shdsl-isam custom-ext-alarm plug-in-unit-ext sip-user-agent sip-plugin-unit sip-termination e1-sip-termination filetransfer external-device l2forward ether-tca ether-sfp megaco-media-gw megaco-sig-gw)	type of the alarms that are active <i>This element is only shown in detail mode.</i>

name	Type	Description
	megaco-plug-unit	
	megaco-term	
	megaco-sig-lt	
	eqpt-supplemental	
	eqpt-holder-ext	
	lsmredundancy	
	sync	
	mcsrc	
	vlanport	
	vect-line	
	vect-board	
	otdr	
	sip-dial-plan	
	sip-vsp	
	sip-server	
	bgp	
	rip	
	lag	
	ihub-general	
	vprn	
	isis	
	ospf	
	ihub-l2forward	
	vpls	
	ihub-equip	
	ihub-link	
	eont-phyoam	
	ellid	
	epon	
	eont-services-lan	
	eolt-ont-tca	
	eont-sw-dl	
	ldp	
	mpls	
	sdp	
	epipe	
	ihub-ipv6	
	pim	
	li	
	mgmt-sec-access	
	bfd	
	ai	
	tr069serv	
	ontsnmp	
	bulk-sync	
	protection-group	
	ont	
	sfu-sup	
	soho-sup	
	mdu-sup	
	ont-ani	
	sfu-sup2	
	soho-sup2	
	mdu-sup2	
	sfprssi	
	eoltrssi	
	cfm	

101 query current alarms by filters

name	Type	Description
	sfpe1t1-framer sfpe1t1-clock pppcc-engine-tca eth-cfm rsvp ihub-tca eth-ring efm-oam ont-loopdetect ont-video ont-ces ont-voip ont-video-ani ont-pwe ont-cese1 ont-xdsl ont-xdsl-tca ont-hpna ont-sip-agent-cfg ont-voip-cfg ont-mgc ont-ploam ont-gen ont-card ont-pots ont-lan ont-moca ont-tc-tca ont-moca-tca ont-l2uni-eth-tca olt-pon-tc-tca olt-pon-util-tca olt-chpr-util-tca olt-ont-tc-tca ont-tca ont-pots-supplemental sfu-ploam sfu-gen soho-ploam soho-gen mdu-ploam mdu-gen ont-veip ont-iphost alarm-table auto-switch channel-pair ont-cfg-dld olt-chpair-tc-tca hgu-tr069 eqpt-psu ont-protection secondary-megaco-term secondary-sip-term cas-r2-channel lldpmed pseudo-wire	

name	Type	Description
	link-agg fcs-exceed e1t1-interface) Possible values: - equipment : equipment alarms - eqpt-holder : equipment holder alarms - plug-in-unit : plugin unit alarms - atm : ATM alarms - custom : customizable alarms - e1 : e1 alarms - ima-group : ima-group alarms - ima-link : ima-link alarms - redundancy : redundancy alarms - shdsl : shdsl alarms - ether-itf : ethernet interface alarms - traffic-overflow : Traffic overflow alarms - qos-queue : qos queue alarms - temporal : temporal alarms - spatial : spatial alarms - software-mngt : software management alarms - sw-mgmt : software management alarms - xdsl : xDSL alarms - xdsl-ext : other xDSL alarms - xdsl-tca : xDSL threshold cross alarms - olt-gen : OLT general alarms - eo-conv : E/O conversion related alarms - authentication : authentication related alarms - bonding : bonding-group related alarms - sfp : SFP related alarms - shdsl-isam : shdsl isam alarms - custom-ext-alarm : customizable external alarms - plug-in-unit-ext : other plugin unit alarms - sip-user-agent : sip user agent related alarms - sip-plugin-unit : sip plug in unit related alarms - sip-termination : sip termination related alarms - e1-sip-termination : E1 sip termination related alarms - filetransfer : file transfer server alarms - external-device : external device related alarms - l2forward : l2forward related alarms - ether-tca : ethernet threshold cross alarms - ether-sfp : ethernet SFP related alarms - megaco-media-gw : megaco media gateway related alarms - megaco-sig-gw : megaco signaling gateway related alarms - megaco-plug-unit : megaco plug unit related alarms - megaco-term : megaco termination related alarms - megaco-sig-lt : megaco signaling lt related alarms - eqpt-supplemental : equipment supplemental alarms - eqpt-holder-ext : other equipment holder alarms - lsmredundancy : lsm redundancy alarms - sync : synce and bits alarms - mcsrc : multicast source alarms - vlanport : vlanport alarms - vect-line : xDSL vectoring line alarms - vect-board : xDSL vectoring board alarms - otdr : otdr alarms - sip-dial-plan : sip dial plan related alarms - sip-vsp : sip vsp related alarms	

101 query current alarms by filters

name	Type	Description
	- sip-server : sip server related alarms - bgp : bgp related alarms - rip : rip related alarms - lag : LAG related alarms - ihub-general : IHUB general related alarms - vprn : vprn related alarms - isis : isis related alarms - ospf : ospf related alarms - ihub-l2forward : ihub-l2forward alarms - vpls : vpls related alarms - ihub-equip : ihub-equip related alarms - ihub-link : ihub-link related alarms - eont-phyoam : eont phyoam related alarms - ellid : ellid related alarms - epon : epon related alarms - eont-services-lan : eon phyoam related alarms - eolt-ont-tca : eon phyoam related alarms - eont-sw-dl : eon phyoam related alarms - ldp : ldp related alarms - mpls : mpls related alarms - sdp : sdp related alarms - epipe : epipe related alarms - ihub-ipv6 : ihub-ipv6 related alarms - pim : pim related alarms - li : lawful intercept related alarms - mgmt-sec-access : management security related alarms - bfd : bfd related alarms - ai : Application Intelligence related alarms - tr069serv : tr069 server related alarms - ontsnmp : ont snmp related alarms - bulk-sync : bulk-sync related alarms - protection-group : port protection group related alarms - ont : ONT general supplemental related alarms - sfu-sup : SFU ONT general supplemental related alarms - soho-sup : SOHO ONT general supplemental related alarms - mdu-sup : MDU ONT general supplemental related alarms - ont-ani : ONT general supplemental 2 related alarms - sfu-sup2 : SFU ONT general supplemental 2 related alarms - soho-sup2 : SOHO ONT general supplemental 2 related alarms - mdu-sup2 : MDU ONT general supplemental 2 related alarms - sfprssi : SFP RSSI related alarms - eoltrssi : epon olt Sfp RSSI related alarms - cfm : Cfm related alarms - sfpe1t1-framer : SFP 2e1t1 framer alarms - sfpe1t1-clock : SFP 2e1t1 clock alarms - pppcc-engine-tca : PPPOE Cross Connect Engine TCA related alarm - eth-cfm : eth-cfm related alarms - rsvp : rsvp related alarms - ihub-tca : IHUB TCA related alarms - eth-ring : eth-ring related alarms - efm-oam : EFM-OAM related alarms - ont-loopdetect : ont loop detect related alarms - ont-video : ont services video related alarms	

name	Type	Description
	- ont-ces : ont services ces related alarms - ont-voip : ont services voip related alarms - ont-video-ani : ont services video ani related alarms - ont-pwe : ont services pwe related alarms - ont-cese1 : ont services cese1 related alarms - ont-xdsl : ont services xdsl related alarms - ont-xdsl-tca : ont services xdsl tca related alarms - ont-hpna : ont hpna related alarms - ont-sip-agent-cfg : ont services voip sip agent config related alarms - ont-voip-cfg : ont services voip config related alarms - ont-mgc : ont mgc related alarms - ont-ploam : ONT PLOAM related alarms - ont-gen : ONT GENERAL related alarms - ont-card : ONT Subscriber Card related alarms - ont-pots : ONT Services POTS related alarms - ont-lan : ONT Services LAN related alarms - ont-moca : ONT MoCA related alarms - ont-tc-tca : ONT TC TCA related alarms - ont-moca-tca : ONT MoCA TCA related alarms - ont-l2uni-eth-tca : ONT L2 UNI Ethernet TCA related alarms - olt-pon-tc-tca : OLT PON TC TCA related alarms - olt-pon-util-tca : OLT PON utilization TCA related alarms - olt-chpr-util-tca : OLT channel-pair utilization TCA related alarms - olt-ont-tc-tca : OLT ONT TC TCA related alarms - ont-tca : ONT TCA related alarms - ont-pots-supplemental : ONT POTS Supplemental related alarms - sfu-ploam : SFU ONT PLOAM related alarms - sfu-gen : SFU ONT general related alarms - soho-ploam : SOHO ONT PLOAM related alarms - soho-gen : SOHO ONT general related alarms - mdu-ploam : MDU ONT PLOAM related alarms - mdu-gen : MDU ONT general related alarms - ont-veip : ONT VEIP related alarms - ont-iphost : ONT IP HOST related alarms - alarm-table : alarm table related alarms - auto-switch : auto-switch related alarms - channel-pair : channel pair related alarms - ont-cfg-dld : ont configure file download related alarms - olt-chpair-tc-tca : OLT CHANNELPAIR TC TCA related alarms - hgu-tr069 : hgu tr069 related alarms - eqpt-psu : equipment psu alarms - ont-protection : ONT protection related alarms - secondary-megaco-term : secondary megaco termination related alarms - secondary-sip-term : secondary sip termination related alarms - cas-r2-channel : CAS R2 channel related alarms - lldpmed : lldpmed alarms - pseudo-wire : pseudo Wire related alarms - link-agg : Link aggregation related alarms - fcs-exceed : FCS auto-recovery related alarms - e1t1-interface : E1/T1 physical interfaces related alarms	

101 query current alarms by filters

name	Type	Description
name	Parameter type: <Alarm::alMtypeOntploamihub> (ont-ploam-loss-sig ont-ploam-loss-ack ont-ploam-loss-cd ont-ploam-phy-eqpt-err ont-ploam-startup-fail ont-ploam-sig-degrade ont-ploam-disabled ont-ploam-err-msg ont-ploam-inactive ont-ploam-sig-fail ont-ploam-dying-gasp ont-ploam-deact-fail ont-ploam-oam ont-ploam-win-drift ont-ploam-rdi ont-ploam-loss-ks ont-ploam-pwr-burst ont-ploam-rog-disa ont-ploam-diff-reach ont-ploam-looc all) Possible values: - ont-ploam-loss-sig : loss of signal at ont - ont-ploam-loss-ack : loss of acknowledge from ont - ont-ploam-loss-cd : loss of channel delineation of ont - ont-ploam-phy-eqpt-err: physical equipment error of ont - ont-ploam-startup-fail: startup failure in ranging of ont - ont-ploam-sig-degrade : signal degrade from ont - ont-ploam-disabled : ont disabled alarm - ont-ploam-err-msg : error message from ont - ont-ploam-inactive : inactive ont - ont-ploam-sig-fail : signal fail alarm from ont - ont-ploam-dying-gasp : dying gasp alarm from ont - ont-ploam-deact-fail : deactive failure of ont - ont-ploam-oam : loss of ploam for ont - ont-ploam-win-drift : drift of window alarm - ont-ploam-rdi : remote defect indication alarm - ont-ploam-loss-ks : loss of key synchronization alarm - ont-ploam-pwr-burst : power bursts on ont - ont-ploam-rog-disa : ont rogue disabled - ont-ploam-diff-reach : ont differential reach exceeded - ont-ploam-looc : Loss of OMCI channel due to persistent MIC failure - all : show ont ploam related alarms	alarm name that are active <i>This element is only shown in detail mode.</i>
severity	Parameter type: <Alarm::AlarmSeverity> (indeterminate warning minor major critical) Possible values: - indeterminate : alarm severity is indeterminate - warning : alarm severity is warning - minor : alarm severity is minor - major : alarm severity is major - critical : alarm severity is critical	the alarms severity level <i>This element is only shown in detail mode.</i>

name	Type	Description
servaff	Parameter type: <Alarm::alarmServAffect> ((service-affecting yes) (noservice-affecting no)) Possible values: - service-affecting : make this alarm service affecting - yes : make this alarm service affecting - noservice-affecting : make this alarm not service affecting - no : make this alarm not service affecting	alarms affect service or not <i>This element is only shown in detail mode.</i>
time	Parameter type: <Sys::timeInSecs> - the time (yyyy-mm-dd:hour:minutes:secs) - unit: UTC	time in seconds when alarm was updated <i>This element is only shown in detail mode.</i>
descript	Parameter type: <Alarm::AddInfoString> - additional alarm information	alarm description <i>This element is only shown in detail mode.</i>

101.57 show current alarm by filters

Command Description

show current alarms by filters

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm query ont-gen [ (name) [ severity <Alarm::querySeverity> ] [ servaff <Alarm::queryServAffect> ] [
ont <Gpon::OntIndex> ] ]
```

Command Parameters

Table 101.57-1 "show current alarm by filters" Resource Parameters

Resource Identifier	Type	Description
(name)	Format: (ont-gen-omci-fail ont-gen-eqpt-selftest ont-gen-ac-pwr-fail ont-gen-bat-missing ont-gen-bat-low ont-gen-bat-fail ont-gen-phys-intrusion ont-gen-sw-dnload-f ont-gen-sw-dnload-p ont-gen-sw-act-fail ont-gen-eqpt-vers-mis ont-gen-sw-vers-mis ont-gen-us-rate-mis ont-gen-mdu-env1 ont-gen-mdu-env2 ont-gen-mdu-env3 ont-gen-nw-time-err ont-gen-opt-sig-high ont-gen-opt-sig-low ont-gen-eqpt-prov-sa ont-gen-eqpt-prov-nsa all) Possible values: - ont-gen-omci-fail : loss of communication - ont-gen-eqpt-selftest : ont self-test failure - ont-gen-ac-pwr-fail : ac power failure on ont - ont-gen-bat-missing : battery missing	alarm name of ONT general

Resource Identifier	Type	Description
	- ont-gen-bat-low : battery low - ont-gen-bat-fail : battery failure - ont-gen-phys-intrusion: physical intrusion - ont-gen-sw-dnload-f : ont sw download failure - ont-gen-sw-dnload-p : ont sw download in progress - ont-gen-sw-act-fail : ont sw activation failure - ont-gen-eqpt-vers-mis : ont equipment version mismatch - ont-gen-sw-vers-mis : ont sw version mismatch - ont-gen-us-rate-mis : ont upstream rate mismatch - ont-gen-mdu-env1 : mdu environmental alarm#1 - ont-gen-mdu-env2 : mdu environmental alarm#2 - ont-gen-mdu-env3 : mdu environmental alarm#3 - ont-gen-nw-time-err : network timing protocol error - ont-gen-opt-sig-high : optical signal level too high - ont-gen-opt-sig-low : optical signal level too low - ont-gen-eqpt-prov-sa : service affecting mismatch btw equipment and provisioning attributes - ont-gen-eqpt-prov-nsa : non service affecting mismatch btw equipment and provisioning attributes - all : show ont general related alarms	
severity	Parameter type: <Alarm::querySeverity> Format: (indeterminate warning minor major critical all) Possible values: - indeterminate : alarm severity is indeterminate - warning : alarm severity is warning - minor : alarm severity is minor - major : alarm severity is major - critical : alarm severity is critical - all : all alarm severity	severity level of an alarm for reporting
servaff	Parameter type: <Alarm::queryServAffect> Format: (service-affecting noservice-affecting all) Possible values: - service-affecting : query alarm service affecting - noservice-affecting : query alarm not service affecting - all : query service affecting and not affecting alarms	serviceaffecting no serviceaffecting
ont	Parameter type: <Gpon::OntIndex> Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> ng2 : <Ng2::ChannelGroup> / <Ng2::SubchannelGroup> / <Ng2::OntId>) Possible values: - ng2 : ngpon2 style identification Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId>	gpon ont equipment ifindex of ont

101 query current alarms by filters

Resource Identifier	Type	Description
	- the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Ng2::ChannelGroup> - channel group number Field type <Ng2::SubchannelGroup> - subchannel group number Field type <Eqpt::OntId> - the ONT identifier Field type <Ng2::OntId> - the ONT identifier	

Command Output

Table 101.57-2 "show current alarm by filters" Display parameters

Specific Information		
name	Type	Description
aidinfo	Parameter type: <Alarm::AddInfoString> - additional alarm information	alarm AID parameters <i>This element is only shown in detail mode.</i>
type	Parameter type: <Alarm::alarmIHUBType> (equipment eqpt-holder plug-in-unit atm custom e1 ima-group ima-link redundancy shdsl ether-itf traffic-overflow qos-queue temporal spatial (software-mngt sw-mgmt) xdsl xdsl-ext xdsl-tca olt-gen eo-conv authentication bonding sfp shdsl-isam custom-ext-alarm plug-in-unit-ext sip-user-agent sip-plugin-unit sip-termination e1-sip-termination filetransfer external-device l2forward ether-tca)	type of the alarms that are active <i>This element is only shown in detail mode.</i>

name	Type	Description
	ether-sfp	
	megaco-media-gw	
	megaco-sig-gw	
	megaco-plug-unit	
	megaco-term	
	megaco-sig-lt	
	eqpt-supplemental	
	eqpt-holder-ext	
	lsmredundancy	
	sync	
	mcsrc	
	vlanport	
	vect-line	
	vect-board	
	otdr	
	sip-dial-plan	
	sip-vsp	
	sip-server	
	bgp	
	rip	
	lag	
	ihub-general	
	vprn	
	isis	
	ospf	
	ihub-l2forward	
	vpls	
	ihub-equip	
	ihub-link	
	eont-phyoam	
	ellid	
	epon	
	eont-services-lan	
	eolt-ont-tca	
	eont-sw-dl	
	ldp	
	mpls	
	sdp	
	epipe	
	ihub-ipv6	
	pim	
	li	
	mgmt-sec-access	
	bfd	
	ai	
	tr069serv	
	ontsnmp	
	bulk-sync	
	protection-group	
	ont	
	sfu-sup	
	soho-sup	
	mdu-sup	
	ont-ani	
	sfu-sup2	
	soho-sup2	
	mdu-sup2	

101 query current alarms by filters

name	Type	Description
	sfprssi	
	eoltrssi	
	cfm	
	sfpe1t1-framer	
	sfpe1t1-clock	
	pppcc-engine-tca	
	eth-cfm	
	rsvp	
	ihub-tca	
	eth-ring	
	efm-oam	
	ont-loopdetect	
	ont-video	
	ont-ces	
	ont-voip	
	ont-video-ani	
	ont-pwe	
	ont-cese1	
	ont-xdsl	
	ont-xdsl-tca	
	ont-hpna	
	ont-sip-agent-cfg	
	ont-voip-cfg	
	ont-mgc	
	ont-ploam	
	ont-gen	
	ont-card	
	ont-pots	
	ont-lan	
	ont-moca	
	ont-tc-tca	
	ont-moca-tca	
	ont-l2uni-eth-tca	
	olt-pon-tc-tca	
	olt-pon-util-tca	
	olt-chpr-util-tca	
	olt-ont-tc-tca	
	ont-tca	
	ont-pots-supplemental	
	sfu-ploam	
	sfu-gen	
	soho-ploam	
	soho-gen	
	mdu-ploam	
	mdu-gen	
	ont-veip	
	ont-iphost	
	alarm-table	
	auto-switch	
	channel-pair	
	ont-cfg-dld	
	olt-chpair-tc-tca	
	hgu-tr069	
	eqpt-psu	
	ont-protection	
	secondary-megaco-term	
	secondary-sip-term	

name	Type	Description
	cas-r2-channel lldpmed pseudo-wire link-agg fcs-exceed e1t1-interface) Possible values: - equipment : equipment alarms - eqpt-holder : equipment holder alarms - plug-in-unit : plugin unit alarms - atm : ATM alarms - custom : customizable alarms - e1 : e1 alarms - ima-group : ima-group alarms - ima-link : ima-link alarms - redundancy : redundancy alarms - shdsl : shdsl alarms - ether-itf : ethernet interface alarms - traffic-overflow : Traffic overflow alarms - qos-queue : qos queue alarms - temporal : temporal alarms - spatial : spatial alarms - software-mngt : software management alarms - sw-mgmt : software management alarms - xdsl : xDSL alarms - xdsl-ext : other xDSL alarms - xdsl-tca : xDSL threshold cross alarms - olt-gen : OLT general alarms - eo-conv : E/O conversion related alarms - authentication : authentication related alarms - bonding : bonding-group related alarms - sfp : SFP related alarms - shdsl-isam : shdsl isam alarms - custom-ext-alarm : customizable external alarms - plug-in-unit-ext : other plugin unit alarms - sip-user-agent : sip user agent related alarms - sip-plugin-unit : sip plug in unit related alarms - sip-termination : sip termination related alarms - e1-sip-termination : E1 sip termination related alarms - filetransfer : file transfer server alarms - external-device : external device related alarms - l2forward : l2forward related alarms - ether-tca : ethernet threshold cross alarms - ether-sfp : ethernet SFP related alarms - megaco-media-gw : megaco media gateway related alarms - megaco-sig-gw : megaco signaling gateway related alarms - megaco-plug-unit : megaco plug unit related alarms - megaco-term : megaco termination related alarms - megaco-sig-lt : megaco signaling lt related alarms - eqpt-supplemental : equipment supplemental alarms - eqpt-holder-ext : other equipment holder alarms - lsmredundancy : lsm redundancy alarms - sync : synce and bits alarms - mcsrc : multicast source alarms - vlanport : vlanport alarms - vect-line : xDSL vectoring line alarms - vect-board : xDSL vectoring board alarms	

101 query current alarms by filters

name	Type	Description
	- otdr : otdr alarms - sip-dial-plan : sip dial plan related alarms - sip-vsp : sip vsp related alarms - sip-server : sip server related alarms - bgp : bgp related alarms - rip : rip related alarms - lag : LAG related alarms - ihub-general : IHUB general related alarms - vprn : vprn related alarms - isis : isis related alarms - ospf : ospf related alarms - ihub-l2forward : ihub-l2forward alarms - vpls : vpls related alarms - ihub-equip : ihub-equip related alarms - ihub-link : ihub-link related alarms - eont-phyoam : eont phyoam related alarms - ellid : ellid related alarms - epon : epon related alarms - eont-services-lan : eon phyoam related alarms - eolt-ont-tca : eon phyoam related alarms - eont-sw-dl : eon phyoam related alarms - ldp : ldp related alarms - mpls : mpls related alarms - sdp : sdp related alarms - epipe : epipe related alarms - ihub-ipv6 : ihub-ipv6 related alarms - pim : pim related alarms - li : lawful intercept related alarms - mgmt-sec-access : management security related alarms - bfd : bfd related alarms - ai : Application Intelligence related alarms - tr069serv : tr069 server related alarms - ontsnmp : ont snmp related alarms - bulk-sync : bulk-sync related alarms - protection-group : port protection group related alarms - ont : ONT general supplemental related alarms - sfu-sup : SFU ONT general supplemental related alarms - soho-sup : SOHO ONT general supplemental related alarms - mdu-sup : MDU ONT general supplemental related alarms - ont-ani : ONT general supplemental 2 related alarms - sfu-sup2 : SFU ONT general supplemental 2 related alarms - soho-sup2 : SOHO ONT general supplemental 2 related alarms - mdu-sup2 : MDU ONT general supplemental 2 related alarms - sfprssi : SFP RSSI related alarms - eoltrssi : epon olt Sfp RSSI related alarms - cfm : Cfm related alarms - sfpe1t1-framer : SFP 2e1t1 framer alarms - sfpe1t1-clock : SFP 2e1t1 clock alarms - pppcc-engine-tca : PPPOE Cross Connect Engine TCA related alarm - eth-cfm : eth-cfm related alarms - rsvp : rsvp related alarms - ihub-tca : IHUB TCA related alarms - eth-ring : eth-ring related alarms	

name	Type	Description
	- efm-oam : EFM-OAM related alarms - ont-loopdetect : ont loop detect related alarms - ont-video : ont services video related alarms - ont-ces : ont services ces related alarms - ont-voip : ont services voip related alarms - ont-video-ani : ont services video ani related alarms - ont-pwe : ont services pwe related alarms - ont-cese1 : ont services cese1 related alarms - ont-xdsl : ont services xdsl related alarms - ont-xdsl-tca : ont services xdsl tca related alarms - ont-hpna : ont hpna related alarms - ont-sip-agent-cfg : ont services voip sip agent config related alarms - ont-voip-cfg : ont services voip config related alarms - ont-mgc : ont mgc related alarms - ont-ploam : ONT PLOAM related alarms - ont-gen : ONT GENERAL related alarms - ont-card : ONT Subscriber Card related alarms - ont-pots : ONT Services POTS related alarms - ont-lan : ONT Services LAN related alarms - ont-moca : ONT MoCA related alarms - ont-tc-tca : ONT TC TCA related alarms - ont-moca-tca : ONT MoCA TCA related alarms - ont-l2uni-eth-tca : ONT L2 UNI Ethernet TCA related alarms - olt-pon-tc-tca : OLT PON TC TCA related alarms - olt-pon-util-tca : OLT PON utilization TCA related alarms - olt-chpr-util-tca : OLT channel-pair utilization TCA related alarms - olt-ont-tc-tca : OLT ONT TC TCA related alarms - ont-tca : ONT TCA related alarms - ont-pots-supplemental : ONT POTS Supplemental related alarms - sfu-ploam : SFU ONT PLOAM related alarms - sfu-gen : SFU ONT general related alarms - soho-ploam : SOHO ONT PLOAM related alarms - soho-gen : SOHO ONT general related alarms - mdu-ploam : MDU ONT PLOAM related alarms - mdu-gen : MDU ONT general related alarms - ont-veip : ONT VEIP related alarms - ont-iphost : ONT IP HOST related alarms - alarm-table : alarm table related alarms - auto-switch : auto-switch related alarms - channel-pair : channel pair related alarms - ont-cfg-dld : ont configure file download related alarms - olt-chpair-tc-tca : OLT CHANNELPAIR TC TCA related alarms - hgu-tr069 : hgu tr069 related alarms - eqpt-psu : equipment psu alarms - ont-protection : ONT protection related alarms - secondary-megaco-term : secondary megaco termination related alarms - secondary-sip-term : secondary sip termination related alarms - cas-r2-channel : CAS R2 channel related alarms - lldpmed : lldpmed alarms - pseudo-wire : pseudo Wire related alarms	

101 query current alarms by filters

name	Type	Description
	- link-agg : Link aggregation related alarms - fcs-exceed : FCS auto-recovery related alarms - e1t1-interface : E1/T1 physical interfaces related alarms	
name	Parameter type: <Alarm::almtypeOntgenihub> (ont-gen-omci-fail ont-gen-eqpt-selftest ont-gen-ac-pwr-fail ont-gen-bat-missing ont-gen-bat-low ont-gen-bat-fail ont-gen-phys-intrusion ont-gen-sw-dnload-f ont-gen-sw-dnload-p ont-gen-sw-act-fail ont-gen-eqpt-vers-mis ont-gen-sw-vers-mis ont-gen-us-rate-mis ont-gen-mdu-env1 ont-gen-mdu-env2 ont-gen-mdu-env3 ont-gen-nw-time-err ont-gen-opt-sig-high ont-gen-opt-sig-low ont-gen-eqpt-prov-sa ont-gen-eqpt-prov-nsa all) Possible values: - ont-gen-omci-fail : loss of communication - ont-gen-eqpt-selftest : ont self-test failure - ont-gen-ac-pwr-fail : ac power failure on ont - ont-gen-bat-missing : battery missing - ont-gen-bat-low : battery low - ont-gen-bat-fail : battery failure - ont-gen-phys-intrusion: physical intrusion - ont-gen-sw-dnload-f : ont sw download failure - ont-gen-sw-dnload-p : ont sw download in progress - ont-gen-sw-act-fail : ont sw activation failure - ont-gen-eqpt-vers-mis : ont equipment version mismatch - ont-gen-sw-vers-mis : ont sw version mismatch - ont-gen-us-rate-mis : ont upstream rate mismatch - ont-gen-mdu-env1 : mdu environmental alarm#1 - ont-gen-mdu-env2 : mdu environmental alarm#2 - ont-gen-mdu-env3 : mdu environmental alarm#3 - ont-gen-nw-time-err : network timing protocol error - ont-gen-opt-sig-high : optical signal level too high - ont-gen-opt-sig-low : optical signal level too low - ont-gen-eqpt-prov-sa : service affecting mismatch btw equipment and provisioning attributes - ont-gen-eqpt-prov-nsa : non service affecting mismatch btw equipment and provisioning attributes - all : show ont general related alarms	alarm name that are active <i>This element is only shown in detail mode.</i>
severity	Parameter type: <Alarm::AlarmSeverity> (indeterminate warning minor major critical)	the alarms severity level <i>This element is only shown in detail mode.</i>

name	Type	Description
	Possible values: - indeterminate : alarm severity is indeterminate - warning : alarm severity is warning - minor : alarm severity is minor - major : alarm severity is major - critical : alarm severity is critical	
servaff	Parameter type: <Alarm::alarmServAffect> ((service-affecting yes) (noservice-affecting no)) Possible values: - service-affecting : make this alarm service affecting - yes : make this alarm service affecting - noservice-affecting : make this alarm not service affecting - no : make this alarm not service affecting	alarms affect service or not <i>This element is only shown in detail mode.</i>
time	Parameter type: <Sys::timeInSecs> - the time (yyyy-mm-dd:hour:minutes:secs) - unit: UTC	time in seconds when alarm was updated <i>This element is only shown in detail mode.</i>
descript	Parameter type: <Alarm::AddInfoString> - additional alarm information	alarm description <i>This element is only shown in detail mode.</i>

101.58 show current alarm by filters

Command Description

show current alarms by filters

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm query ont-tca [ (name) [ severity <Alarm::querySeverity> ] [ servaff <Alarm::queryServAffect> ] [ ont <Gpon::OntIndex> ] ]
```

Command Parameters

Table 101.58-1 "show current alarm by filters" Resource Parameters

Resource Identifier	Type	Description
(name)	Format: (ont-cpu-util-tca ont-mem-util-tca all) Possible values: - ont-cpu-util-tca : ONT CPU utilization threshold crossed - ont-mem-util-tca : ONT memory utilization threshold crossed - all : ONT TCA related alarms	alarm name of ont tca
severity	Parameter type: <Alarm::querySeverity> Format: (indeterminate warning minor major critical all) Possible values: - indeterminate : alarm severity is indeterminate - warning : alarm severity is warning - minor : alarm severity is minor - major : alarm severity is major - critical : alarm severity is critical - all : all alarm severity	severity level of an alarm for reporting
servaff	Parameter type: <Alarm::queryServAffect> Format: (service-affecting noservice-affecting	serviceaffecting no

Resource Identifier	Type	Description
	all) Possible values: - service-affecting : query alarm service affecting - noservice-affecting : query alarm not service affecting - all : query service affecting and not affecting alarms	
ont	Parameter type: <Gpon::OntIndex> Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> ng2 : <Ng2::ChannelGroup> / <Ng2::SubchannelGroup> / <Ng2::OntId>) Possible values: - ng2 : ngpon2 style identification Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Ng2::ChannelGroup> - channel group number Field type <Ng2::SubchannelGroup> - subchannel group number Field type <Eqpt::OntId> - the ONT identifier Field type <Ng2::OntId> - the ONT identifier	gpon ont equipment ifindex of ont

Command Output

Table 101.58-2 "show current alarm by filters" Display parameters

Specific Information		
name	Type	Description
aidinfo	Parameter type: <Alarm::AddInfoString> - additional alarm information	alarm AID parameters <i>This element is only shown in detail mode.</i>
type	Parameter type: <Alarm::alarmIHUBType> (equipment eqpt-holder plug-in-unit atm custom e1 ima-group ima-link redundancy shdsl ether-itf traffic-overflow qos-queue temporal spatial (software-mngt sw-mgmt) xdsl	type of the alarms that are active <i>This element is only shown in detail mode.</i>

101 query current alarms by filters

name	Type	Description
	xds1-ext xds1-tca olt-gen eo-conv authentication bonding sfp shdsl-isam custom-ext-alarm plug-in-unit-ext sip-user-agent sip-plugin-unit sip-termination e1-sip-termination filetransfer external-device l2forward ether-tca ether-sfp megaco-media-gw megaco-sig-gw megaco-plugin-unit megaco-term megaco-sig-lt eqpt-supplemental eqpt-holder-ext lsmredundancy sync mcsrc vlanport vect-line vect-board otdr sip-dial-plan sip-vsp sip-server bgp rip lag ihub-general vprn isis ospf ihub-l2forward vpls ihub-equip ihub-link eont-phyoam ellid epon eont-services-lan eolt-ont-tca eont-sw-dl ldp mpls sdp epipe	

name	Type	Description
	ihub-ipv6	
	pim	
	li	
	mgmt-sec-access	
	bfd	
	ai	
	tr069serv	
	ontsnmp	
	bulk-sync	
	protection-group	
	ont	
	sfu-sup	
	soho-sup	
	mdu-sup	
	ont-ani	
	sfu-sup2	
	soho-sup2	
	mdu-sup2	
	sfprssi	
	eoltrssi	
	cfm	
	sfpe1t1-framer	
	sfpe1t1-clock	
	pppcc-engine-tca	
	eth-cfm	
	rsvp	
	ihub-tca	
	eth-ring	
	efm-oam	
	ont-loopdetect	
	ont-video	
	ont-ces	
	ont-voip	
	ont-video-ani	
	ont-pwe	
	ont-cese1	
	ont-xdsl	
	ont-xdsl-tca	
	ont-hpna	
	ont-sip-agent-cfg	
	ont-voip-cfg	
	ont-mgc	
	ont-ploam	
	ont-gen	
	ont-card	
	ont-pots	
	ont-lan	
	ont-moca	
	ont-tc-tca	
	ont-moca-tca	
	ont-l2uni-eth-tca	
	olt-pon-tc-tca	
	olt-pon-util-tca	
	olt-chpr-util-tca	
	olt-ont-tc-tca	
	ont-tca	
	ont-pots-supplemental	

101 query current alarms by filters

name	Type	Description
	sfu-ploam sfu-gen soho-ploam soho-gen mdu-ploam mdu-gen ont-veip ont-iphost alarm-table auto-switch channel-pair ont-cfg-dld olt-chpair-tc-tca hgu-tr069 eqpt-psu ont-protection secondary-megaco-term secondary-sip-term cas-r2-channel lldpmed pseudo-wire link-agg fcs-exceed e1t1-interface) Possible values: - equipment : equipment alarms - eqpt-holder : equipment holder alarms - plug-in-unit : plugin unit alarms - atm : ATM alarms - custom : customizable alarms - e1 : e1 alarms - ima-group : ima-group alarms - ima-link : ima-link alarms - redundancy : redundancy alarms - shdsl : shdsl alarms - ether-itf : ethernet interface alarms - traffic-overflow : Traffic overflow alarms - qos-queue : qos queue alarms - temporal : temporal alarms - spatial : spatial alarms - software-mngt : software management alarms - sw-mgmt : software management alarms - xdsl : xDSL alarms - xdsl-ext : other xDSL alarms - xdsl-tca : xDSL threshold cross alarms - olt-gen : OLT general alarms - eo-conv : E/O conversion related alarms - authentication : authentication related alarms - bonding : bonding-group related alarms - sfp : SFP related alarms - shdsl-isam : shdsl isam alarms - custom-ext-alarm : customizable external alarms - plug-in-unit-ext : other plugin unit alarms - sip-user-agent : sip user agent related alarms - sip-plugin-unit : sip plug in unit related alarms - sip-termination : sip termination related alarms - e1-sip-termination : E1 sip termination related alarms	

name	Type	Description
	- filetransfer : file transfer server alarms - external-device : external device related alarms - l2forward : l2forward related alarms - ether-tca : ethernet threshold cross alarms - ether-sfp : ethernet SFP related alarms - megaco-media-gw : megaco media gateway related alarms - megaco-sig-gw : megaco signaling gateway related alarms - megaco-plug-unit : megaco plug unit related alarms - megaco-term : megaco termination related alarms - megaco-sig-lt : megaco signaling lt related alarms - eqpt-supplemental : equipment supplemental alarms - eqpt-holder-ext : other equipment holder alarms - lsmredundancy : lsm redundancy alarms - sync : synce and bits alarms - mcsrc : multicast source alarms - vlanport : vlanport alarms - vect-line : xDSL vectoring line alarms - vect-board : xDSL vectoring board alarms - otdr : otdr alarms - sip-dial-plan : sip dial plan related alarms - sip-vsp : sip vsp related alarms - sip-server : sip server related alarms - bgp : bgp related alarms - rip : rip related alarms - lag : LAG related alarms - ihub-general : IHUB general related alarms - vprn : vprn related alarms - isis : isis related alarms - ospf : ospf related alarms - ihub-l2forward : ihub-l2forward alarms - vpls : vpls related alarms - ihub-equip : ihub-equip related alarms - ihub-link : ihub-link related alarms - eont-phyoam : eont phyoam related alarms - ellid : ellid related alarms - epon : epon related alarms - eont-services-lan : eon phyoam related alarms - eolt-ont-tca : eon phyoam related alarms - eont-sw-dl : eon phyoam related alarms - ldp : ldp related alarms - mpls : mpls related alarms - sdp : sdp related alarms - epipe : epipe related alarms - ihub-ipv6 : ihub-ipv6 related alarms - pim : pim related alarms - li : lawful intercept related alarms - mgmt-sec-access : management security related alarms - bfd : bfd related alarms - ai : Application Intelligence related alarms - tr069serv : tr069 server related alarms - ontsnmp : ont snmp related alarms - bulk-sync : bulk-sync related alarms - protection-group : port protection group related alarms - ont : ONT general supplemental related alarms - sfu-sup : SFU ONT general supplemental related alarms - soho-sup : SOHO ONT general supplemental related alarms	

101 query current alarms by filters

name	Type	Description
	- mdu-sup : MDU ONT general supplemental related alarms - ont-ani : ONT general supplemental 2 related alarms - sfu-sup2 : SFU ONT general supplemental 2 related alarms - soho-sup2 : SOHO ONT general supplemental 2 related alarms - mdu-sup2 : MDU ONT general supplemental 2 related alarms - sfprssi : SFP RSSI related alarms - eoltrssi : epon olt Sfp RSSI related alarms - cfm : Cfm related alarms - sfpe1t1-framer : SFP 2e1t1 framer alarms - sfpe1t1-clock : SFP 2e1t1 clock alarms - pppcc-engine-tca : PPPOE Cross Connect Engine TCA related alarm - eth-cfm : eth-cfm related alarms - rsvp : rsvp related alarms - ihub-tca : IHUB TCA related alarms - eth-ring : eth-ring related alarms - efm-oam : EFM-OAM related alarms - ont-loopdetect : ont loop detect related alarms - ont-video : ont services video related alarms - ont-ces : ont services ces related alarms - ont-voip : ont services voip related alarms - ont-video-ani : ont services video ani related alarms - ont-pwe : ont services pwe related alarms - ont-cese1 : ont services cese1 related alarms - ont-xdsl : ont services xdsl related alarms - ont-xdsl-tca : ont services xdsl tca related alarms - ont-hpna : ont hpna related alarms - ont-sip-agent-cfg : ont services voip sip agent config related alarms - ont-voip-cfg : ont services voip config related alarms - ont-mgc : ont mgc related alarms - ont-ploam : ONT PLOAM related alarms - ont-gen : ONT GENERAL related alarms - ont-card : ONT Subscriber Card related alarms - ont-pots : ONT Services POTS related alarms - ont-lan : ONT Services LAN related alarms - ont-moca : ONT MoCA related alarms - ont-tc-tca : ONT TC TCA related alarms - ont-moca-tca : ONT MoCA TCA related alarms - ont-l2uni-eth-tca : ONT L2 UNI Ethernet TCA related alarms - olt-pon-tc-tca : OLT PON TC TCA related alarms - olt-pon-util-tca : OLT PON utilization TCA related alarms - olt-chpr-util-tca : OLT channel-pair utilization TCA related alarms - olt-ont-tc-tca : OLT ONT TC TCA related alarms - ont-tca : ONT TCA related alarms - ont-pots-supplemental : ONT POTS Supplemental related alarms - sfu-ploam : SFU ONT PLOAM related alarms - sfu-gen : SFU ONT general related alarms - soho-ploam : SOHO ONT PLOAM related alarms - soho-gen : SOHO ONT general related alarms - mdu-ploam : MDU ONT PLOAM related alarms - mdu-gen : MDU ONT general related alarms	

name	Type	Description
	- ont-veip : ONT VEIP related alarms - ont-iphost : ONT IP HOST related alarms - alarm-table : alarm table related alarms - auto-switch : auto-switch related alarms - channel-pair : channel pair related alarms - ont-cfg-dld : ont configure file download related alarms - olt-chpair-tc-tca : OLT CHANNELPAIR TC TCA related alarms - hgu-tr069 : hgu tr069 related alarms - eqpt-psu : equipment psu alarms - ont-protection : ONT protection related alarms - secondary-megaco-term : secondary megaco termination related alarms - secondary-sip-term : secondary sip termination related alarms - cas-r2-channel : CAS R2 channel related alarms - lldpmed : lldpmed alarms - pseudo-wire : pseudo Wire related alarms - link-agg : Link aggregation related alarms - fcs-exceed : FCS auto-recovery related alarms - e1t1-interface : E1/T1 physical interfaces related alarms	
name	Parameter type: <Alarm::almtypeOnttcaihub> (ont-cpu-util-tca ont-mem-util-tca all) Possible values: - ont-cpu-util-tca : ONT CPU utilization threshold crossed - ont-mem-util-tca : ONT memory utilization threshold crossed - all : ONT TCA related alarms	alarm name that are active <i>This element is only shown in detail mode.</i>
severity	Parameter type: <Alarm::AlarmSeverity> (indeterminate warning minor major critical) Possible values: - indeterminate : alarm severity is indeterminate - warning : alarm severity is warning - minor : alarm severity is minor - major : alarm severity is major - critical : alarm severity is critical	the alarms severity level <i>This element is only shown in detail mode.</i>
servaff	Parameter type: <Alarm::alarmServAffect> ((service-affecting yes) (noservice-affecting no)) Possible values: - service-affecting : make this alarm service affecting - yes : make this alarm service affecting - noservice-affecting : make this alarm not service affecting - no : make this alarm not service affecting	alarms affect service or not <i>This element is only shown in detail mode.</i>
time	Parameter type: <Sys::timeInSecs> - the time (yyyy-mm-dd:hour:minutes:secs) - unit: UTC	time in seconds when alarm was updated <i>This element is only shown in detail mode.</i>
descript	Parameter type: <Alarm::AddInfoString> - additional alarm information	alarm description <i>This element is only shown in detail mode.</i>

101.59 show current alarm by filters

Command Description

show current alarms by filters

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm query olt-gen [ (name) [ severity <Alarm::querySeverity> ] [ servaff <Alarm::queryServAffect> ] [ port <Gpon::PonId> ] ]
```

Command Parameters

Table 101.59-1 "show current alarm by filters" Resource Parameters

Resource Identifier	Type	Description
(name)	Format: (olt-gen-pon-com-fail olt-gen-tx-fail olt-gen-unprov-ont olt-gen-pon-eqpt-prov olt-gen-pon-loss-sig olt-gen-pon-diagnostic olt-gen-loid-conflict olt-gen-loid-pwderr olt-gen-pon-alien-test olt-gen-alien-detect olt-gen-rng-mism olt-gen-sfp-mism olt-gen-deact-hightca olt-gen-deact-lowtca olt-gen-dp-integ olt-gen-ddr-fault all) Possible values: - olt-gen-pon-com-fail : pon communication failure on olt - olt-gen-tx-fail : transmitter failure on olt - olt-gen-unprov-ont : unprovisioned ont on pon - olt-gen-pon-eqpt-prov : mismatch btw equipment and provisioning pon attributes - olt-gen-pon-loss-sig : pon loss of signal - olt-gen-pon-diagnostic: pon diagnostic test active - olt-gen-loid-conflict : loid conflict ont on pon - olt-gen-loid-pwderr : loid password error ont on pon	alarm name of olt general

101 query current alarms by filters

Resource Identifier	Type	Description
	- olt-gen-pon-alien-test: pon alien diagnostic test active - olt-gen-alien-detect : pon alien detect active - olt-gen-rng-mism : pon ranging mismatch active - olt-gen-sfp-mism : pon sfp mismatch active - olt-gen-deact-hightca : deactivated ont hightca active - olt-gen-deact-lowtca : deactivated ont lowtca active - olt-gen-dp-integ : pon data path integrity failure - olt-gen-ddr-fault : pon failure due to ddr fault - all : OLT general alarms	
severity	Parameter type: <Alarm::querySeverity> Format: (indeterminate warning minor major critical all) Possible values: - indeterminate : alarm severity is indeterminate - warning : alarm severity is warning - minor : alarm severity is minor - major : alarm severity is major - critical : alarm severity is critical - all : all alarm severity	severity level of an alarm for reporting
servaff	Parameter type: <Alarm::queryServAffect> Format: (service-affecting noservice-affecting all) Possible values: - service-affecting : query alarm service affecting - noservice-affecting : query alarm not service affecting - all : query service affecting and not affecting alarms	serviceaffecting no serviceaffecting
port	Parameter type: <Gpon::PonId> Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> x-pon : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::XPonId> 25g-pon : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::M25GPonId>) Possible values: - 25g-pon : 25g pon - x-pon : Xgs pon Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Eqpt::XPonId> - the XGS PON identifier Field type <Eqpt::M25GPonId> - the 25G PON identifier	specify which port the alarm occurred on

Command Output

Table 101.59-2 "show current alarm by filters" Display parameters

Specific Information		
name	Type	Description
aidinfo	Parameter type: <Alarm::AddInfoString> - additional alarm information	alarm AID parameters <i>This element is only shown in detail mode.</i>
type	Parameter type: <Alarm::alarmIHUBType> (equipment eqpt-holder plug-in-unit atm custom e1 ima-group ima-link redundancy shdsl ether-itf traffic-overflow qos-queue temporal spatial (software-mngt sw-mgmt) xdsl xdsl-ext xdsl-tca olt-gen eo-conv authentication bonding sfp shdsl-isam custom-ext-alarm plug-in-unit-ext sip-user-agent sip-plugin-unit sip-termination e1-sip-termination filetransfer external-device l2forward ether-tca ether-sfp megaco-media-gw megaco-sig-gw megaco-plug-unit megaco-term megaco-sig-lt eqpt-supplemental eqpt-holder-ext lsmredundancy sync mcsrc vlanport	type of the alarms that are active <i>This element is only shown in detail mode.</i>

101 query current alarms by filters

name	Type	Description
	vect-line	
	vect-board	
	otdr	
	sip-dial-plan	
	sip-vsp	
	sip-server	
	bgp	
	rip	
	lag	
	ihub-general	
	vprn	
	isis	
	ospf	
	ihub-l2forward	
	vpls	
	ihub-equip	
	ihub-link	
	eont-phyoam	
	ellid	
	epon	
	eont-services-lan	
	eolt-ont-tca	
	eont-sw-dl	
	ldp	
	mpls	
	sdp	
	epipe	
	ihub-ipv6	
	pim	
	li	
	mgmt-sec-access	
	bfd	
	ai	
	tr069serv	
	ontsnmp	
	bulk-sync	
	protection-group	
	ont	
	sfu-sup	
	soho-sup	
	mdu-sup	
	ont-ani	
	sfu-sup2	
	soho-sup2	
	mdu-sup2	
	sfprssi	
	eoltrssi	
	cfm	
	sfpe1t1-framer	
	sfpe1t1-clock	
	pppcc-engine-tca	
	eth-cfm	
	rsvp	
	ihub-tca	
	eth-ring	
	efm-oam	
	ont-loopdetect	

name	Type	Description
	ont-video ont-ces ont-voip ont-video-ani ont-pwe ont-cese1 ont-xdsl ont-xdsl-tca ont-hpna ont-sip-agent-cfg ont-voip-cfg ont-mgc ont-ploam ont-gen ont-card ont-pots ont-lan ont-moca ont-tc-tca ont-moca-tca ont-l2uni-eth-tca olt-pon-tc-tca olt-pon-util-tca olt-chpr-util-tca olt-ont-tc-tca ont-tca ont-pots-supplemental sfu-ploam sfu-gen soho-ploam soho-gen mdu-ploam mdu-gen ont-veip ont-iphost alarm-table auto-switch channel-pair ont-cfg-dld olt-chpair-tc-tca hgu-tr069 eqpt-psu ont-protection secondary-megaco-term secondary-sip-term cas-r2-channel lldpmed pseudo-wire link-agg fcs-exceed e1t1-interface) Possible values: - equipment : equipment alarms - eqpt-holder : equipment holder alarms - plug-in-unit : plugin unit alarms - atm : ATM alarms - custom : customizable alarms	

101 query current alarms by filters

name	Type	Description
	- e1 : e1 alarms - ima-group : ima-group alarms - ima-link : ima-link alarms - redundancy : redundancy alarms - shdsl : shdsl alarms - ether-itf : ethernet interface alarms - traffic-overflow : Traffic overflow alarms - qos-queue : qos queue alarms - temporal : temporal alarms - spatial : spatial alarms - software-mngt : software management alarms - sw-mgmt : software management alarms - xdsl : xDSL alarms - xdsl-ext : other xDSL alarms - xdsl-tca : xDSL threshold cross alarms - olt-gen : OLT general alarms - eo-conv : E/O conversion related alarms - authentication : authentication related alarms - bonding : bonding-group related alarms - sfp : SFP related alarms - shdsl-isam : shdsl isam alarms - custom-ext-alarm : customizable external alarms - plug-in-unit-ext : other plugin unit alarms - sip-user-agent : sip user agent related alarms - sip-plugin-unit : sip plug in unit related alarms - sip-termination : sip termination related alarms - e1-sip-termination : E1 sip termination related alarms - filetransfer : file transfer server alarms - external-device : external device related alarms - l2forward : l2forward related alarms - ether-tca : ethernet threshold cross alarms - ether-sfp : ethernet SFP related alarms - megaco-media-gw : megaco media gateway related alarms - megaco-sig-gw : megaco signaling gateway related alarms - megaco-plug-unit : megaco plug unit related alarms - megaco-term : megaco termination related alarms - megaco-sig-lt : megaco signaling lt related alarms - eqpt-supplemental : equipment supplemental alarms - eqpt-holder-ext : other equipment holder alarms - lsmredundancy : lsm redundancy alarms - sync : synce and bits alarms - mcsrc : multicast source alarms - vlanport : vlanport alarms - vect-line : xDSL vectoring line alarms - vect-board : xDSL vectoring board alarms - otdr : otdr alarms - sip-dial-plan : sip dial plan related alarms - sip-vsp : sip vsp related alarms - sip-server : sip server related alarms - bgp : bgp related alarms - rip : rip related alarms - lag : LAG related alarms - ihub-general : IHUB general related alarms - vprn : vprn related alarms - isis : isis related alarms - ospf : ospf related alarms - ihub-l2forward : ihub-l2forward alarms	

name	Type	Description
	- vpls : vpls related alarms - ihub-equip : ihub-equip related alarms - ihub-link : ihub-link related alarms - eont-phyoam : eont phyoam related alarms - ellid : ellid related alarms - epon : epon related alarms - eont-services-lan : eon phyoam related alarms - eolt-ont-tca : eon phyoam related alarms - eont-sw-dl : eon phyoam related alarms - ldp : ldp related alarms - mpls : mpls related alarms - sdp : sdp related alarms - epipe : epipe related alarms - ihub-ipv6 : ihub-ipv6 related alarms - pim : pim related alarms - li : lawful intercept related alarms - mgmt-sec-access : management security related alarms - bfd : bfd related alarms - ai : Application Intelligence related alarms - tr069serv : tr069 server related alarms - ontsnmp : ont snmp related alarms - bulk-sync : bulk-sync related alarms - protection-group : port protection group related alarms - ont : ONT general supplemental related alarms - sfu-sup : SFU ONT general supplemental related alarms - soho-sup : SOHO ONT general supplemental related alarms - mdu-sup : MDU ONT general supplemental related alarms - ont-ani : ONT general supplemental 2 related alarms - sfu-sup2 : SFU ONT general supplemental 2 related alarms - soho-sup2 : SOHO ONT general supplemental 2 related alarms - mdu-sup2 : MDU ONT general supplemental 2 related alarms - sfprssi : SFP RSSI related alarms - eoltrssi : epon olt Sfp RSSI related alarms - cfm : Cfm related alarms - sfpe1t1-framer : SFP 2e1t1 framer alarms - sfpe1t1-clock : SFP 2e1t1 clock alarms - pppcc-engine-tca : PPPOE Cross Connect Engine TCA related alarm - eth-cfm : eth-cfm related alarms - rsvp : rsvp related alarms - ihub-tca : IHUB TCA related alarms - eth-ring : eth-ring related alarms - efm-oam : EFM-OAM related alarms - ont-loopdetect : ont loop detect related alarms - ont-video : ont services video related alarms - ont-ces : ont services ces related alarms - ont-voip : ont services voip related alarms - ont-video-ani : ont services video ani related alarms - ont-pwe : ont services pwe related alarms - ont-cese1 : ont services cese1 related alarms - ont-xdsl : ont services xdsl related alarms - ont-xdsl-tca : ont services xdsl tca related alarms - ont-hpna : ont hpna related alarms - ont-sip-agent-cfg : ont services voip sip agent config	

101 query current alarms by filters

name	Type	Description
	related alarms - ont-voip-cfg : ont services voip config related alarms - ont-mgc : ont mgc related alarms - ont-ploam : ONT PLOAM related alarms - ont-gen : ONT GENERAL related alarms - ont-card : ONT Subscriber Card related alarms - ont-pots : ONT Services POTS related alarms - ont-lan : ONT Services LAN related alarms - ont-moca : ONT MoCA related alarms - ont-tc-tca : ONT TC TCA related alarms - ont-moca-tca : ONT MoCA TCA related alarms - ont-l2uni-eth-tca : ONT L2 UNI Ethernet TCA related alarms - olt-pon-tc-tca : OLT PON TC TCA related alarms - olt-pon-util-tca : OLT PON utilization TCA related alarms - olt-chpr-util-tca : OLT channel-pair utilization TCA related alarms - olt-ont-tc-tca : OLT ONT TC TCA related alarms - ont-tca : ONT TCA related alarms - ont-pots-supplemental : ONT POTS Supplemental related alarms - sfu-ploam : SFU ONT PLOAM related alarms - sfu-gen : SFU ONT general related alarms - soho-ploam : SOHO ONT PLOAM related alarms - soho-gen : SOHO ONT general related alarms - mdu-ploam : MDU ONT PLOAM related alarms - mdu-gen : MDU ONT general related alarms - ont-veip : ONT VEIP related alarms - ont-iphost : ONT IP HOST related alarms - alarm-table : alarm table related alarms - auto-switch : auto-switch related alarms - channel-pair : channel pair related alarms - ont-cfg-dld : ont configure file download related alarms - olt-chpair-tc-tca : OLT CHANNELPAIR TC TCA related alarms - hgu-tr069 : hgu tr069 related alarms - eqpt-psu : equipment psu alarms - ont-protection : ONT protection related alarms - secondary-megaco-term : secondary megaco termination related alarms - secondary-sip-term : secondary sip termination related alarms - cas-r2-channel : CAS R2 channel related alarms - lldpmed : lldpmed alarms - pseudo-wire : pseudo Wire related alarms - link-agg : Link aggregation related alarms - fcs-exceed : FCS auto-recovery related alarms - e1t1-interface : E1/T1 physical interfaces related alarms	
name	Parameter type: <Alarm::almtypeltgenihub> - olt-gen-pon-com-fail - olt-gen-tx-fail - olt-gen-unprov-ont - olt-gen-pon-eqpt-prov - olt-gen-pon-loss-sig - olt-gen-pon-diagnostic - olt-gen-loid-conflict - olt-gen-loid-pwderr	alarm name that are active <i>This element is only shown in detail mode.</i>

name	Type	Description
	olt-gen-pon-alien-test olt-gen-alien-detect olt-gen-rng-mism olt-gen-sfp-mism olt-gen-deact-hightca olt-gen-deact-lowtca olt-gen-dp-integ olt-gen-ddr-fault all) Possible values: - olt-gen-pon-com-fail : pon communication failure on olt - olt-gen-tx-fail : transmitter failure on olt - olt-gen-unprov-ont : unprovisioned ont on pon - olt-gen-pon-eqpt-prov : mismatch btw equipment and provisioning pon attributes - olt-gen-pon-loss-sig : pon loss of signal - olt-gen-pon-diagnostic: pon diagnostic test active - olt-gen-loid-conflict : loid conflict ont on pon - olt-gen-loid-pwderr : loid password error ont on pon - olt-gen-pon-alien-test: pon alien diagnostic test active - olt-gen-alien-detect : pon alien detect active - olt-gen-rng-mism : pon ranging mismatch active - olt-gen-sfp-mism : pon sfp mismatch active - olt-gen-deact-hightca : deactivated ont hightca active - olt-gen-deact-lowtca : deactivated ont lowtca active - olt-gen-dp-integ : pon data path integrity failure - olt-gen-ddr-fault : pon failure due to ddr fault - all : OLT general alarms	
severity	Parameter type: <Alarm::AlarmSeverity> (indeterminate warning minor major critical) Possible values: - indeterminate : alarm severity is indeterminate - warning : alarm severity is warning - minor : alarm severity is minor - major : alarm severity is major - critical : alarm severity is critical	the alarms severity level <i>This element is only shown in detail mode.</i>
servaff	Parameter type: <Alarm::alarmServAffect> ((service-affecting yes) (noservice-affecting no)) Possible values: - service-affecting : make this alarm service affecting - yes : make this alarm service affecting - noservice-affecting : make this alarm not service affecting - no : make this alarm not service affecting	alarms affect service or not <i>This element is only shown in detail mode.</i>
time	Parameter type: <Sys::timeInSecs> - the time (yyyy-mm-dd:hour:minutes:secs) - unit: UTC	time in seconds when alarm was updated <i>This element is only shown in detail mode.</i>
descript	Parameter type: <Alarm::AddInfoString> - additional alarm information	alarm description <i>This element is only shown in detail mode.</i>

101.60 show current alarm by filters

Command Description

show current alarms by filters

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm query ont-card [ (name) [ severity <Alarm::querySeverity> ] [ servaff <Alarm::queryServAffect> ] [
ont-card <Alarm::queryDefaultAid> ] ]
```

Command Parameters

Table 101.60-1 "show current alarm by filters" Resource Parameters

Resource Identifier	Type	Description
(name)	Format: (ont-sbscr-lim-missing ont-sbscr-lim-type-mis ont-sbscr-lim-removal ont-sbscr-lim-fail ont-sbscr-lim-svc-mis ont-sbscr-lim-port-mis all) Possible values: - ont-sbscr-lim-missing : provisioned ont card missing - ont-sbscr-lim-type-mis: wrong type plug-in ont card - ont-sbscr-lim-removal : improper removal ont card - ont-sbscr-lim-fail : ont card failure - ont-sbscr-lim-svc-mis : ont service mismatch for provisioned onu card - ont-sbscr-lim-port-mis: port mismatch btw actual and planned ont card - all : ONT Subscriber Card related alarms	alarm name of ont subscriber card
severity	Parameter type: <Alarm::querySeverity> Format: (indeterminate warning minor major critical all) Possible values: - indeterminate : alarm severity is indeterminate	severity level of an alarm for reporting

Resource Identifier	Type	Description
	- warning : alarm severity is warning - minor : alarm severity is minor - major : alarm severity is major - critical : alarm severity is critical - all : all alarm severity	
servaff	Parameter type: <Alarm::queryServAffect> Format: (service-affecting noservice-affecting all) Possible values: - service-affecting : query alarm service affecting - noservice-affecting : query alarm not service affecting - all : query service affecting and not affecting alarms	serviceaffecting no serviceaffecting
ont-card	Parameter type: <Alarm::queryDefaultAid> Format: all Possible values: - all : default AID parameter	all gpon ont plan card

Command Output

Table 101.60-2 "show current alarm by filters" Display parameters

Specific Information		
name	Type	Description
aidinfo	Parameter type: <Alarm::AddInfoString> - additional alarm information	alarm AID parameters <i>This element is only shown in detail mode.</i>
type	Parameter type: <Alarm::alarmIHUBType> (equipment eqpt-holder plug-in-unit atm custom e1 ima-group ima-link redundancy shdsl ether-itf traffic-overflow qos-queue temporal spatial (software-mngt sw-mgmt) xdsl xdsl-ext xdsl-tca olt-gen eo-conv authentication bonding sfp shdsl-isam custom-ext-alarm plug-in-unit-ext	type of the alarms that are active <i>This element is only shown in detail mode.</i>

101 query current alarms by filters

name	Type	Description
	sip-user-agent sip-plugin-unit sip-termination e1-sip-termination filetransfer external-device l2forward ether-tca ether-sfp megaco-media-gw megaco-sig-gw megaco-plug-unit megaco-term megaco-sig-lt eqpt-supplemental eqpt-holder-ext lsmredundancy sync mcsrc vlanport vect-line vect-board otdr sip-dial-plan sip-vsp sip-server bgp rip lag ihub-general vprn isis ospf ihub-l2forward vpls ihub-equip ihub-link eont-phyoam ellid epon eont-services-lan eolt-ont-tca eont-sw-dl ldp mpls sdp epipe ihub-ipv6 pim li mgmt-sec-access bfd ai tr069serv ontsnmp bulk-sync protection-group	

name	Type	Description
	ont sfu-sup soho-sup mdu-sup ont-ani sfu-sup2 soho-sup2 mdu-sup2 sfprssi eoltrssi cfm sfpe1t1-framer sfpe1t1-clock pppcc-engine-tca eth-cfm rsvp ihub-tca eth-ring efm-oam ont-loopdetect ont-video ont-ces ont-voip ont-video-ani ont-pwe ont-cese1 ont-xdsl ont-xdsl-tca ont-hpna ont-sip-agent-cfg ont-voip-cfg ont-mgc ont-ploam ont-gen ont-card ont-pots ont-lan ont-moca ont-tc-tca ont-moca-tca ont-l2uni-eth-tca olt-pon-tc-tca olt-pon-util-tca olt-chpr-util-tca olt-ont-tc-tca ont-tca ont-pots-supplemental sfu-ploam sfu-gen soho-ploam soho-gen mdu-ploam mdu-gen ont-veip ont-iphost alarm-table auto-switch	

101 query current alarms by filters

name	Type	Description
	- channel-pair - ont-cfg-dld - olt-chpair-tc-tca - hgu-tr069 - eqpt-psu - ont-protection - secondary-megaco-term - secondary-sip-term - cas-r2-channel - lldpmed - pseudo-wire - link-agg - fcs-exceed - e1t1-interface) Possible values: - equipment : equipment alarms - eqpt-holder : equipment holder alarms - plug-in-unit : plugin unit alarms - atm : ATM alarms - custom : customizable alarms - e1 : e1 alarms - ima-group : ima-group alarms - ima-link : ima-link alarms - redundancy : redundancy alarms - shdsl : shdsl alarms - ether-itf : ethernet interface alarms - traffic-overflow : Traffic overflow alarms - qos-queue : qos queue alarms - temporal : temporal alarms - spatial : spatial alarms - software-mngt : software management alarms - sw-mgmt : software management alarms - xdsl : xDSL alarms - xdsl-ext : other xDSL alarms - xdsl-tca : xDSL threshold cross alarms - olt-gen : OLT general alarms - eo-conv : E/O conversion related alarms - authentication : authentication related alarms - bonding : bonding-group related alarms - sfp : SFP related alarms - shdsl-isam : shdsl isam alarms - custom-ext-alarm : customizable external alarms - plug-in-unit-ext : other plugin unit alarms - sip-user-agent : sip user agent related alarms - sip-plugin-unit : sip plug in unit related alarms - sip-termination : sip termination related alarms - e1-sip-termination : E1 sip termination related alarms - filetransfer : file transfer server alarms - external-device : external device related alarms - l2forward : l2forward related alarms - ether-tca : ethernet threshold cross alarms - ether-sfp : ethernet SFP related alarms - megaco-media-gw : megaco media gateway related alarms - megaco-sig-gw : megaco signaling gateway related alarms - megaco-plug-unit : megaco plug unit related alarms - megaco-term : megaco termination related alarms - megaco-sig-lt : megaco signaling lt related alarms	

name	Type	Description
	- eqpt-supplemental : equipment supplemental alarms - eqpt-holder-ext : other equipment holder alarms - lsmredundancy : lsm redundancy alarms - sync : synce and bits alarms - mcsrc : multicast source alarms - vlanport : vlanport alarms - vect-line : xDSL vectoring line alarms - vect-board : xDSL vectoring board alarms - otdr : otdr alarms - sip-dial-plan : sip dial plan related alarms - sip-vsp : sip vsp related alarms - sip-server : sip server related alarms - bgp : bgp related alarms - rip : rip related alarms - lag : LAG related alarms - ihub-general : IHUB general related alarms - vprn : vprn related alarms - isis : isis related alarms - ospf : ospf related alarms - ihub-l2forward : ihub-l2forward alarms - vpls : vpls related alarms - ihub-equip : ihub-equip related alarms - ihub-link : ihub-link related alarms - eont-phyoam : eont phyoam related alarms - ellid : ellid related alarms - epon : epon related alarms - eont-services-lan : eon phyoam related alarms - eolt-ont-tca : eon phyoam related alarms - eont-sw-dl : eon phyoam related alarms - ldp : ldp related alarms - mpls : mpls related alarms - sdp : sdp related alarms - epipe : epipe related alarms - ihub-ipv6 : ihub-ipv6 related alarms - pim : pim related alarms - li : lawful intercept related alarms - mgmt-sec-access : management security related alarms - bfd : bfd related alarms - ai : Application Intelligence related alarms - tr069serv : tr069 server related alarms - ontsnmp : ont snmp related alarms - bulk-sync : bulk-sync related alarms - protection-group : port protection group related alarms - ont : ONT general supplemental related alarms - sfu-sup : SFU ONT general supplemental related alarms - soho-sup : SOHO ONT general supplemental related alarms - mdu-sup : MDU ONT general supplemental related alarms - ont-ani : ONT general supplemental 2 related alarms - sfu-sup2 : SFU ONT general supplemental 2 related alarms - soho-sup2 : SOHO ONT general supplemental 2 related alarms - mdu-sup2 : MDU ONT general supplemental 2 related alarms - sfrssi : SFP RSSI related alarms - eoltrssi : epon olt Sfp RSSI related alarms - cfm : Cfm related alarms	

101 query current alarms by filters

name	Type	Description
	- sfpe1t1-framer : SFP 2e1t1 framer alarms - sfpe1t1-clock : SFP 2e1t1 clock alarms - pppcc-engine-tca : PPPOE Cross Connect Engine TCA related alarm - eth-cfm : eth-cfm related alarms - rsvp : rsvp related alarms - ihub-tca : IHUB TCA related alarms - eth-ring : eth-ring related alarms - efm-oam : EFM-OAM related alarms - ont-loopdetect : ont loop detect related alarms - ont-video : ont services video related alarms - ont-ces : ont services ces related alarms - ont-voip : ont services voip related alarms - ont-video-ani : ont services video ani related alarms - ont-pwe : ont services pwe related alarms - ont-cese1 : ont services cese1 related alarms - ont-xdsl : ont services xdsl related alarms - ont-xdsl-tca : ont services xdsl tca related alarms - ont-hpna : ont hpna related alarms - ont-sip-agent-cfg : ont services voip sip agent config related alarms - ont-voip-cfg : ont services voip config related alarms - ont-mgc : ont mgc related alarms - ont-ploam : ONT PLOAM related alarms - ont-gen : ONT GENERAL related alarms - ont-card : ONT Subscriber Card related alarms - ont-pots : ONT Services POTS related alarms - ont-lan : ONT Services LAN related alarms - ont-moca : ONT MoCA related alarms - ont-tc-tca : ONT TC TCA related alarms - ont-moca-tca : ONT MoCA TCA related alarms - ont-l2uni-eth-tca : ONT L2 UNI Ethernet TCA related alarms - olt-pon-tc-tca : OLT PON TC TCA related alarms - olt-pon-util-tca : OLT PON utilization TCA related alarms - olt-chpr-util-tca : OLT channel-pair utilization TCA related alarms - olt-ont-tc-tca : OLT ONT TC TCA related alarms - ont-tca : ONT TCA related alarms - ont-pots-supplemental : ONT POTS Supplemental related alarms - sfu-ploam : SFU ONT PLOAM related alarms - sfu-gen : SFU ONT general related alarms - soho-ploam : SOHO ONT PLOAM related alarms - soho-gen : SOHO ONT general related alarms - mdu-ploam : MDU ONT PLOAM related alarms - mdu-gen : MDU ONT general related alarms - ont-veip : ONT VEIP related alarms - ont-iphost : ONT IP HOST related alarms - alarm-table : alarm table related alarms - auto-switch : auto-switch related alarms - channel-pair : channel pair related alarms - ont-cfg-dld : ont configure file download related alarms - olt-chpair-tc-tca : OLT CHANNELPAIR TC TCA related alarms - hgu-tr069 : hgu tr069 related alarms - eqpt-psu : equipment psu alarms	

name	Type	Description
	- ont-protection : ONT protection related alarms - secondary-megaco-term : secondary megaco termination related alarms - secondary-sip-term : secondary sip termination related alarms - cas-r2-channel : CAS R2 channel related alarms - lldpmed : lldpmed alarms - pseudo-wire : pseudo Wire related alarms - link-agg : Link aggregation related alarms - fcs-exceed : FCS auto-recovery related alarms - e1t1-interface : E1/T1 physical interfaces related alarms	
name	Parameter type: <Alarm::alarmTypeOntcardihub> (ont-sbscr-lim-missing ont-sbscr-lim-type-mis ont-sbscr-lim-removal ont-sbscr-lim-fail ont-sbscr-lim-svc-mis ont-sbscr-lim-port-mis all) Possible values: - ont-sbscr-lim-missing : provisioned ont card missing - ont-sbscr-lim-type-mis: wrong type plug-in ont card - ont-sbscr-lim-removal : improper removal ont card - ont-sbscr-lim-fail : ont card failure - ont-sbscr-lim-svc-mis : ont service mismatch for provisioned onu card - ont-sbscr-lim-port-mis: port mismatch btw actual and planned ont card - all : ONT Subscriber Card related alarms	alarm name that are active <i>This element is only shown in detail mode.</i>
severity	Parameter type: <Alarm::AlarmSeverity> (indeterminate warning minor major critical) Possible values: - indeterminate : alarm severity is indeterminate - warning : alarm severity is warning - minor : alarm severity is minor - major : alarm severity is major - critical : alarm severity is critical	the alarms severity level <i>This element is only shown in detail mode.</i>
servaff	Parameter type: <Alarm::alarmServAffect> ((service-affecting yes) (noservice-affecting no)) Possible values: - service-affecting : make this alarm service affecting - yes : make this alarm service affecting - noservice-affecting : make this alarm not service affecting - no : make this alarm not service affecting	alarms affect service or not <i>This element is only shown in detail mode.</i>
time	Parameter type: <Sys::timeInSecs> - the time (yyyy-mm-dd:hour:minutes:secs) - unit: UTC	time in seconds when alarm was updated <i>This element is only shown in detail mode.</i>
descript	Parameter type: <Alarm::AddInfoString> - additional alarm information	alarm description <i>This element is only shown in detail mode.</i>

101.61 show current alarm by filters

Command Description

show current alarms by filters

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm query ont-video [ (name) [ severity <Alarm::querySeverity> ] [ servaff <Alarm::queryServAffect> ] [ video-port <Alarm::queryDefaultAid> ] ]
```

Command Parameters

Table 101.61-1 "show current alarm by filters" Resource Parameters

Resource Identifier	Type	Description
(name)	Format: (ont-svc-video-conf-mis ont-svc-video-pw-high ont-svc-video-pw-low all) Possible values: - ont-svc-video-conf-mis: config request failure for video service - ont-svc-video-pw-high : high power level for rf video signal - ont-svc-video-pw-low : low power level for rf video signal - all : ont services video related alarms	alarm name of ont video
severity	Parameter type: <Alarm::querySeverity> Format: (indeterminate warning minor major critical all) Possible values: - indeterminate : alarm severity is indeterminate - warning : alarm severity is warning - minor : alarm severity is minor - major : alarm severity is major - critical : alarm severity is critical - all : all alarm severity	severity level of an alarm for reporting
servaff	Parameter type: <Alarm::queryServAffect>	serviceaffecting no

Resource Identifier	Type	Description
	Format: (service-affecting noservice-affecting all) Possible values: - service-affecting : query alarm service affecting - noservice-affecting : query alarm not service affecting - all : query service affecting and not affecting alarms	serviceaffecting
video-port	Parameter type: <Alarm::queryDefaultAid> Format: all Possible values: - all : default AID parameter	all video port

Command Output

Table 101.61-2 "show current alarm by filters" Display parameters

Specific Information		
name	Type	Description
aidinfo	Parameter type: <Alarm::AddInfoString> - additional alarm information	alarm AID parameters <i>This element is only shown in detail mode.</i>
type	Parameter type: <Alarm::alarmIHUBType> (equipment eqpt-holder plug-in-unit atm custom e1 ima-group ima-link redundancy shdsl ether-itf traffic-overflow qos-queue temporal spatial (software-mngt sw-mgmt) xdsl xdsl-ext xdsl-tca olt-gen eo-conv authentication bonding sfp shdsl-isam custom-ext-alarm plug-in-unit-ext sip-user-agent sip-plugin-unit sip-termination e1-sip-termination filetransfer external-device	type of the alarms that are active <i>This element is only shown in detail mode.</i>

101 query current alarms by filters

name	Type	Description
	l2forward	
	ether-tca	
	ether-sfp	
	megaco-media-gw	
	megaco-sig-gw	
	megaco-plug-unit	
	megaco-term	
	megaco-sig-lt	
	eqpt-supplemental	
	eqpt-holder-ext	
	lsmredundancy	
	sync	
	mcsrc	
	vlanport	
	vect-line	
	vect-board	
	otdr	
	sip-dial-plan	
	sip-vsp	
	sip-server	
	bgp	
	rip	
	lag	
	ihub-general	
	vprn	
	isis	
	ospf	
	ihub-l2forward	
	vpls	
	ihub-equip	
	ihub-link	
	eont-phyoam	
	ellid	
	epon	
	eont-services-lan	
	eolt-ont-tca	
	eont-sw-dl	
	ldp	
	mpls	
	sdp	
	epipe	
	ihub-ipv6	
	pim	
	li	
	mgmt-sec-access	
	bfd	
	ai	
	tr069serv	
	ontsnmp	
	bulk-sync	
	protection-group	
	ont	
	sfu-sup	
	soho-sup	
	mdu-sup	
	ont-ani	
	sfu-sup2	

name	Type	Description
	soho-sup2	
	mdu-sup2	
	sfprssi	
	eoltrssi	
	cfm	
	sfpe1t1-framer	
	sfpe1t1-clock	
	pppcc-engine-tca	
	eth-cfm	
	rsvp	
	ihub-tca	
	eth-ring	
	efm-oam	
	ont-loopdetect	
	ont-video	
	ont-ces	
	ont-voip	
	ont-video-ani	
	ont-pwe	
	ont-cese1	
	ont-xdsl	
	ont-xdsl-tca	
	ont-hpna	
	ont-sip-agent-cfg	
	ont-voip-cfg	
	ont-mgc	
	ont-ploam	
	ont-gen	
	ont-card	
	ont-pots	
	ont-lan	
	ont-moca	
	ont-tc-tca	
	ont-moca-tca	
	ont-l2uni-eth-tca	
	olt-pon-tc-tca	
	olt-pon-util-tca	
	olt-chpr-util-tca	
	olt-ont-tc-tca	
	ont-tca	
	ont-pots-supplemental	
	sfu-ploam	
	sfu-gen	
	soho-ploam	
	soho-gen	
	mdu-ploam	
	mdu-gen	
	ont-veip	
	ont-iphost	
	alarm-table	
	auto-switch	
	channel-pair	
	ont-cfg-dld	
	olt-chpair-tc-tca	
	hgu-tr069	
	eqpt-psu	
	ont-protection	

101 query current alarms by filters

name	Type	Description
	secondary-megaco-term secondary-sip-term cas-r2-channel lldpmed pseudo-wire link-agg fcs-exceed e1t1-interface) Possible values: - equipment : equipment alarms - eqpt-holder : equipment holder alarms - plug-in-unit : plugin unit alarms - atm : ATM alarms - custom : customizable alarms - e1 : e1 alarms - ima-group : ima-group alarms - ima-link : ima-link alarms - redundancy : redundancy alarms - shdsl : shdsl alarms - ether-itf : ethernet interface alarms - traffic-overflow : Traffic overflow alarms - qos-queue : qos queue alarms - temporal : temporal alarms - spatial : spatial alarms - software-mngt : software management alarms - sw-mgmt : software management alarms - xdsl : xDSL alarms - xdsl-ext : other xDSL alarms - xdsl-tca : xDSL threshold cross alarms - olt-gen : OLT general alarms - eo-conv : E/O conversion related alarms - authentication : authentication related alarms - bonding : bonding-group related alarms - sfp : SFP related alarms - shdsl-isam : shdsl isam alarms - custom-ext-alarm : customizable external alarms - plug-in-unit-ext : other plugin unit alarms - sip-user-agent : sip user agent related alarms - sip-plugin-unit : sip plug in unit related alarms - sip-termination : sip termination related alarms - e1-sip-termination : E1 sip termination related alarms - filetransfer : file transfer server alarms - external-device : external device related alarms - l2forward : l2forward related alarms - ether-tca : ethernet threshold cross alarms - ether-sfp : ethernet SFP related alarms - megaco-media-gw : megaco media gateway related alarms - megaco-sig-gw : megaco signaling gateway related alarms - megaco-plug-unit : megaco plug unit related alarms - megaco-term : megaco termination related alarms - megaco-sig-lt : megaco signaling lt related alarms - eqpt-supplemental : equipment supplemental alarms - eqpt-holder-ext : other equipment holder alarms - lsmredundancy : lsm redundancy alarms - sync : synce and bits alarms - mcsrc : multicast source alarms - vlanport : vlanport alarms	

name	Type	Description
	- vect-line : xDSL vectoring line alarms - vect-board : xDSL vectoring board alarms - otdr : otdr alarms - sip-dial-plan : sip dial plan related alarms - sip-vsp : sip vsp related alarms - sip-server : sip server related alarms - bgp : bgp related alarms - rip : rip related alarms - lag : LAG related alarms - ihub-general : IHUB general related alarms - vprn : vprn related alarms - isis : isis related alarms - ospf : ospf related alarms - ihub-l2forward : ihub-l2forward alarms - vpls : vpls related alarms - ihub-equip : ihub-equip related alarms - ihub-link : ihub-link related alarms - eont-phyoam : eont phyoam related alarms - ellid : ellid related alarms - epon : epon related alarms - eont-services-lan : eon phyoam related alarms - eolt-ont-tca : eon phyoam related alarms - eont-sw-dl : eon phyoam related alarms - ldp : ldp related alarms - mpls : mpls related alarms - sdp : sdp related alarms - epipe : epipe related alarms - ihub-ipv6 : ihub-ipv6 related alarms - pim : pim related alarms - li : lawful intercept related alarms - mgmt-sec-access : management security related alarms - bfd : bfd related alarms - ai : Application Intelligence related alarms - tr069serv : tr069 server related alarms - ontsnmp : ont snmp related alarms - bulk-sync : bulk-sync related alarms - protection-group : port protection group related alarms - ont : ONT general supplemental related alarms - sfu-sup : SFU ONT general supplemental related alarms - soho-sup : SOHO ONT general supplemental related alarms - mdu-sup : MDU ONT general supplemental related alarms - ont-ani : ONT general supplemental 2 related alarms - sfu-sup2 : SFU ONT general supplemental 2 related alarms - soho-sup2 : SOHO ONT general supplemental 2 related alarms - mdu-sup2 : MDU ONT general supplemental 2 related alarms - sfprssi : SFP RSSI related alarms - eoltrssi : epon olt Sfp RSSI related alarms - cfm : Cfm related alarms - sfpe1t1-framer : SFP 2e1t1 framer alarms - sfpe1t1-clock : SFP 2e1t1 clock alarms - pppcc-engine-tca : PPPOE Cross Connect Engine TCA related alarm - eth-cfm : eth-cfm related alarms - rsvp : rsvp related alarms	

101 query current alarms by filters

name	Type	Description
	- ihub-tca : IHUB TCA related alarms - eth-ring : eth-ring related alarms - efm-oam : EFM-OAM related alarms - ont-loopdetect : ont loop detect related alarms - ont-video : ont services video related alarms - ont-ces : ont services ces related alarms - ont-voip : ont services voip related alarms - ont-video-ani : ont services video ani related alarms - ont-pwe : ont services pwe related alarms - ont-cese1 : ont services cese1 related alarms - ont-xdsl : ont services xdsl related alarms - ont-xdsl-tca : ont services xdsl tca related alarms - ont-hpna : ont hpna related alarms - ont-sip-agent-cfg : ont services voip sip agent config related alarms - ont-voip-cfg : ont services voip config related alarms - ont-mgc : ont mgc related alarms - ont-ploam : ONT PLOAM related alarms - ont-gen : ONT GENERAL related alarms - ont-card : ONT Subscriber Card related alarms - ont-pots : ONT Services POTS related alarms - ont-lan : ONT Services LAN related alarms - ont-moca : ONT MoCA related alarms - ont-tc-tca : ONT TC TCA related alarms - ont-moca-tca : ONT MoCA TCA related alarms - ont-l2uni-eth-tca : ONT L2 UNI Ethernet TCA related alarms - olt-pon-tc-tca : OLT PON TC TCA related alarms - olt-pon-util-tca : OLT PON utilization TCA related alarms - olt-chpr-util-tca : OLT channel-pair utilization TCA related alarms - olt-ont-tc-tca : OLT ONT TC TCA related alarms - ont-tca : ONT TCA related alarms - ont-pots-supplemental : ONT POTS Supplemental related alarms - sfu-ploam : SFU ONT PLOAM related alarms - sfu-gen : SFU ONT general related alarms - soho-ploam : SOHO ONT PLOAM related alarms - soho-gen : SOHO ONT general related alarms - mdu-ploam : MDU ONT PLOAM related alarms - mdu-gen : MDU ONT general related alarms - ont-veip : ONT VEIP related alarms - ont-iphost : ONT IP HOST related alarms - alarm-table : alarm table related alarms - auto-switch : auto-switch related alarms - channel-pair : channel pair related alarms - ont-cfg-dld : ont configure file download related alarms - olt-chpair-tc-tca : OLT CHANNELPAIR TC TCA related alarms - hgu-tr069 : hgu tr069 related alarms - eqpt-psu : equipment psu alarms - ont-protection : ONT protection related alarms - secondary-megaco-term : secondary megaco termination related alarms - secondary-sip-term : secondary sip termination related alarms - cas-r2-channel : CAS R2 channel related alarms	

name	Type	Description
	- lldpmed : lldpmed alarms - pseudo-wire : pseudo Wire related alarms - link-aggr : Link aggregation related alarms - fcs-exceed : FCS auto-recovery related alarms - e1t1-interface : E1/T1 physical interfaces related alarms	
name	Parameter type: <Alarm::alarmTypeOntvideoihub> (ont-svc-video-conf-mis ont-svc-video-pw-high ont-svc-video-pw-low all) Possible values: - ont-svc-video-conf-mis: config request failure for video service - ont-svc-video-pw-high : high power level for rf video signal - ont-svc-video-pw-low : low power level for rf video signal - all : ont services video related alarms	alarm name that are active <i>This element is only shown in detail mode.</i>
severity	Parameter type: <Alarm::AlarmSeverity> (indeterminate warning minor major critical) Possible values: - indeterminate : alarm severity is indeterminate - warning : alarm severity is warning - minor : alarm severity is minor - major : alarm severity is major - critical : alarm severity is critical	the alarms severity level <i>This element is only shown in detail mode.</i>
servaff	Parameter type: <Alarm::alarmServAffect> ((service-affecting yes) (noservice-affecting no)) Possible values: - service-affecting : make this alarm service affecting - yes : make this alarm service affecting - noservice-affecting : make this alarm not service affecting - no : make this alarm not service affecting	alarms affect service or not <i>This element is only shown in detail mode.</i>
time	Parameter type: <Sys::timeInSecs> - the time (yyyy-mm-dd:hour:minutes:secs) - unit: UTC	time in seconds when alarm was updated <i>This element is only shown in detail mode.</i>
descript	Parameter type: <Alarm::AddInfoString> - additional alarm information	alarm description <i>This element is only shown in detail mode.</i>

101.62 show current alarm by filters

Command Description

show current alarms by filters

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm query ont-pots [ (name) [ severity <Alarm::querySeverity> ] [ servaff <Alarm::queryServAffect> ] [ ont-pots <Alarm::queryDefaultAid> ] ]
```

Command Parameters

Table 101.62-1 "show current alarm by filters" Resource Parameters

Resource Identifier	Type	Description
(name)	Format: (ont-svc-pots-svc-mis ont-svc-pots-rtcp-lost ont-svc-pots-icnf-subs ont-svc-pots-icnf-ntfy ont-svc-pots-icnf-http ont-svc-pots-sip-reg ont-svc-pots-sip-inv ont-svc-pots-sip-subsc ont-svc-pots-sip-mt-tc ont-svc-pots-pk-los-tc ont-svc-pots-jitter-tc ont-svc-pots-subs-dns ont-svc-pots-subs-tcp ont-svc-pots-subs-tls ont-svc-pots-subs-auth ont-svc-pots-subs-to ont-svc-pots-subs-err ont-svc-pots-not-to ont-svc-pots-notref-to ont-svc-pots-not-mal ont-svc-pots-not-rej ont-svc-pots-http-dns ont-svc-pots-http-tcp ont-svc-pots-http-tls ont-svc-pots-http-auth ont-svc-pots-http-to ont-svc-pots-http-err	alarm name of ont pots

Resource Identifier	Type	Description
	ont-svc-pots-http-mal ont-svc-pots-insuff ont-svc-pots-poos all) Possible values: - ont-svc-pots-svc-mis : ont service mismatch for provisioned pots - ont-svc-pots-rtcp-lost: pots realtime transport control protocol stream lost - ont-svc-pots-icnf-subsc: pots line iconfig subscription failure - ont-svc-pots-icnf-ntfy: pots line iconfig notify failure - ont-svc-pots-icnf-http: pots line iconfig http failure - ont-svc-pots-sip-reg : pots line sip registration failure - ont-svc-pots-sip-inv : pots line sip invite request failure - ont-svc-pots-sip-subsc: pots line sip subscribe failure - ont-svc-pots-sip-mt-tc: pots line sip message timeout threshold crossed - ont-svc-pots-pk-los-tc: pots line rtp bearer packets loss threshold crossed - ont-svc-pots-jitter-tc: pots line rtp jitter threshold crossed - ont-svc-pots-subsc-dns : pots line iconfig subscription failed (DNS) - ont-svc-pots-subsc-tcp : pots line iconfig subscription failed (TCP) - ont-svc-pots-subsc-tls : pots line iconfig subscription failed (TLS) - ont-svc-pots-subsc-auth: pots line iconfig subscription failed authentication - ont-svc-pots-subsc-to : pots line iconfig subscription failed (timeout) - ont-svc-pots-subsc-err : pots line iconfig subscription response error - ont-svc-pots-not-to : pots line iconfig notification failed (timeout) - ont-svc-pots-notref-to: pots line iconfig notification refresh failed - ont-svc-pots-not-mal : pots line iconfig notification failed (malformed) - ont-svc-pots-not-rej : pots line iconfig notification rejected - ont-svc-pots-http-dns : pots line iconfig doc retrieval failed (DNS) - ont-svc-pots-http-tcp : pots line iconfig doc retrieval failed (TCP) - ont-svc-pots-http-tls : pots line iconfig doc retrieval failed (TLS) - ont-svc-pots-http-auth: pots line iconfig doc retrieval failed (authentication) - ont-svc-pots-http-to : pots line iconfig doc retrieval failed (timeout) - ont-svc-pots-http-err : pots line iconfig doc retrieval response error - ont-svc-pots-http-mal : pots line iconfig doc retrieval failed (malformed) - ont-svc-pots-insuff : pots line iconfig service failed (insufficient data) - ont-svc-pots-poos : pots ports out of service	

101 query current alarms by filters

Resource Identifier	Type	Description
severity	- all : ONT Services POTS related alarms Parameter type: <Alarm::querySeverity> Format: (indeterminate warning minor major critical all) Possible values: - indeterminate : alarm severity is indeterminate - warning : alarm severity is warning - minor : alarm severity is minor - major : alarm severity is major - critical : alarm severity is critical - all : all alarm severity	severity level of an alarm for reporting
servaff	Parameter type: <Alarm::queryServAffect> Format: (service-affecting noservice-affecting all) Possible values: - service-affecting : query alarm service affecting - noservice-affecting : query alarm not service affecting - all : query service affecting and not affecting alarms	serviceaffecting no serviceaffecting
ont-pots	Parameter type: <Alarm::queryDefaultAid> Format: all Possible values: - all : default AID parameter	all gpon ont pots port index

Command Output

Table 101.62-2 "show current alarm by filters" Display parameters

Specific Information		
name	Type	Description
aidinfo	Parameter type: <Alarm::AddInfoString> - additional alarm information	alarm AID parameters <i>This element is only shown in detail mode.</i>
type	Parameter type: <Alarm::alarmIHUBType> (equipment eqpt-holder plug-in-unit atm custom e1 ima-group ima-link redundancy shdsl ether-itf traffic-overflow qos-queue temporal spatial (software-mngt sw-mgmt)	type of the alarms that are active <i>This element is only shown in detail mode.</i>

name	Type	Description
	xdsl xdsl-ext xdsl-tca olt-gen eo-conv authentication bonding sfp shdsl-isam custom-ext-alarm plug-in-unit-ext sip-user-agent sip-plugin-unit sip-termination e1-sip-termination filetransfer external-device l2forward ether-tca ether-sfp megaco-media-gw megaco-sig-gw megaco-plug-unit megaco-term megaco-sig-lt eqpt-supplemental eqpt-holder-ext lsmredundancy sync mcsrc vlanport vect-line vect-board otdr sip-dial-plan sip-vsp sip-server bgp rip lag ihub-general vprn isis ospf ihub-l2forward vpls ihub-equip ihub-link eont-phyoam ellid epon eont-services-lan eolt-ont-tca eont-sw-dl ldp mpls sdp	

101 query current alarms by filters

name	Type	Description
	epipe ihub-ipv6 pim li mgmt-sec-access bfd ai tr069serv ontsnmp bulk-sync protection-group ont sfu-sup soho-sup mdu-sup ont-ani sfu-sup2 soho-sup2 mdu-sup2 sfprssi eoltrssi cfm sfpe1t1-framer sfpe1t1-clock pppcc-engine-tca eth-cfm rsvp ihub-tca eth-ring efm-oam ont-loopdetect ont-video ont-ces ont-voip ont-video-ani ont-pwe ont-cese1 ont-xdsl ont-xdsl-tca ont-hpna ont-sip-agent-cfg ont-voip-cfg ont-mgc ont-ploam ont-gen ont-card ont-pots ont-lan ont-moca ont-tc-tca ont-moca-tca ont-l2uni-eth-tca olt-pon-tc-tca olt-pon-util-tca olt-chpr-util-tca olt-ont-tc-tca ont-tca	

name	Type	Description
	ont-pots-supplemental sfu-ploam sfu-gen soho-ploam soho-gen mdu-ploam mdu-gen ont-veip ont-iphost alarm-table auto-switch channel-pair ont-cfg-dld olt-chpair-tc-tca hgu-tr069 eqpt-psu ont-protection secondary-megaco-term secondary-sip-term cas-r2-channel lldpmed pseudo-wire link-agg fcs-exceed e1t1-interface) Possible values: - equipment : equipment alarms - eqpt-holder : equipment holder alarms - plug-in-unit : plugin unit alarms - atm : ATM alarms - custom : customizable alarms - e1 : e1 alarms - ima-group : ima-group alarms - ima-link : ima-link alarms - redundancy : redundancy alarms - shdsl : shdsl alarms - ether-itf : ethernet interface alarms - traffic-overflow : Traffic overflow alarms - qos-queue : qos queue alarms - temporal : temporal alarms - spatial : spatial alarms - software-mngt : software management alarms - sw-mgmt : software management alarms - xdsl : xDSL alarms - xdsl-ext : other xDSL alarms - xdsl-tca : xDSL threshold cross alarms - olt-gen : OLT general alarms - eo-conv : E/O conversion related alarms - authentication : authentication related alarms - bonding : bonding-group related alarms - sfp : SFP related alarms - shdsl-isam : shdsl isam alarms - custom-ext-alarm : customizable external alarms - plug-in-unit-ext : other plugin unit alarms - sip-user-agent : sip user agent related alarms - sip-plugin-unit : sip plug in unit related alarms - sip-termination : sip termination related alarms	

101 query current alarms by filters

name	Type	Description
	- e1-sip-termination : E1 sip termination related alarms - filetransfer : file transfer server alarms - external-device : external device related alarms - l2forward : l2forward related alarms - ether-tca : ethernet threshold cross alarms - ether-sfp : ethernet SFP related alarms - megaco-media-gw : megaco media gateway related alarms - megaco-sig-gw : megaco signaling gateway related alarms - megaco-plug-unit : megaco plug unit related alarms - megaco-term : megaco termination related alarms - megaco-sig-lt : megaco signaling lt related alarms - eqpt-supplemental : equipment supplemental alarms - eqpt-holder-ext : other equipment holder alarms - lsmredundancy : lsm redundancy alarms - sync : synce and bits alarms - mcsrc : multicast source alarms - vlanport : vlanport alarms - vect-line : xDSL vectoring line alarms - vect-board : xDSL vectoring board alarms - otdr : otdr alarms - sip-dial-plan : sip dial plan related alarms - sip-vsp : sip vsp related alarms - sip-server : sip server related alarms - bgp : bgp related alarms - rip : rip related alarms - lag : LAG related alarms - ihub-general : IHUB general related alarms - vprn : vprn related alarms - isis : isis related alarms - ospf : ospf related alarms - ihub-l2forward : ihub-l2forward alarms - vpls : vpls related alarms - ihub-equip : ihub-equip related alarms - ihub-link : ihub-link related alarms - eont-phyoam : eont phyoam related alarms - ellid : ellid related alarms - epon : epon related alarms - eont-services-lan : eon phyoam related alarms - eolt-ont-tca : eon phyoam related alarms - eont-sw-dl : eon phyoam related alarms - ldp : ldp related alarms - mpls : mpls related alarms - sdp : sdp related alarms - epipe : epipe related alarms - ihub-ipv6 : ihub-ipv6 related alarms - pim : pim related alarms - li : lawful intercept related alarms - mgmt-sec-access : management security related alarms - bfd : bfd related alarms - ai : Application Intelligence related alarms - tr069serv : tr069 server related alarms - ontsnmp : ont snmp related alarms - bulk-sync : bulk-sync related alarms - protection-group : port protection group related alarms - ont : ONT general supplemental related alarms - sfu-sup : SFU ONT general supplemental related alarms - soho-sup : SOHO ONT general supplemental related	

name	Type	Description
	alarms - mdu-sup : MDU ONT general supplemental related alarms - ont-ani : ONT general supplemental 2 related alarms - sfu-sup2 : SFU ONT general supplemental 2 related alarms - soho-sup2 : SOHO ONT general supplemental 2 related alarms - mdu-sup2 : MDU ONT general supplemental 2 related alarms - sfprssi : SFP RSSI related alarms - eoltrssi : epon olt Sfp RSSI related alarms - cfm : Cfm related alarms - sfpe1t1-framer : SFP 2e1t1 framer alarms - sfpe1t1-clock : SFP 2e1t1 clock alarms - pppcc-engine-tca : PPPOE Cross Connect Engine TCA related alarm - eth-cfm : eth-cfm related alarms - rsvp : rsvp related alarms - ihub-tca : IHUB TCA related alarms - eth-ring : eth-ring related alarms - efm-oam : EFM-OAM related alarms - ont-loopdetect : ont loop detect related alarms - ont-video : ont services video related alarms - ont-ces : ont services ces related alarms - ont-voip : ont services voip related alarms - ont-video-ani : ont services video ani related alarms - ont-pwe : ont services pwe related alarms - ont-cese1 : ont services cese1 related alarms - ont-xdsl : ont services xdsl related alarms - ont-xdsl-tca : ont services xdsl tca related alarms - ont-hpna : ont hpna related alarms - ont-sip-agent-cfg : ont services voip sip agent config related alarms - ont-voip-cfg : ont services voip config related alarms - ont-mgc : ont mgc related alarms - ont-ploam : ONT PLOAM related alarms - ont-gen : ONT GENERAL related alarms - ont-card : ONT Subscriber Card related alarms - ont-pots : ONT Services POTS related alarms - ont-lan : ONT Services LAN related alarms - ont-moca : ONT MoCA related alarms - ont-tc-tca : ONT TC TCA related alarms - ont-moca-tca : ONT MoCA TCA related alarms - ont-l2uni-eth-tca : ONT L2 UNI Ethernet TCA related alarms - olt-pon-tc-tca : OLT PON TC TCA related alarms - olt-pon-util-tca : OLT PON utilization TCA related alarms - olt-chpr-util-tca : OLT channel-pair utilization TCA related alarms - olt-ont-tc-tca : OLT ONT TC TCA related alarms - ont-tca : ONT TCA related alarms - ont-pots-supplemental : ONT POTS Supplemental related alarms - sfu-ploam : SFU ONT PLOAM related alarms - sfu-gen : SFU ONT general related alarms - soho-ploam : SOHO ONT PLOAM related alarms - soho-gen : SOHO ONT general related alarms - mdu-ploam : MDU ONT PLOAM related alarms	

101 query current alarms by filters

name	Type	Description
	- mdu-gen : MDU ONT general related alarms - ont-veip : ONT VEIP related alarms - ont-iphost : ONT IP HOST related alarms - alarm-table : alarm table related alarms - auto-switch : auto-switch related alarms - channel-pair : channel pair related alarms - ont-cfg-dld : ont configure file download related alarms - olt-chpair-tc-tca : OLT CHANNELPAIR TC TCA related alarms - hgu-tr069 : hgu tr069 related alarms - eqpt-psu : equipment psu alarms - ont-protection : ONT protection related alarms - secondary-megaco-term : secondary megaco termination related alarms - secondary-sip-term : secondary sip termination related alarms - cas-r2-channel : CAS R2 channel related alarms - lldpmed : lldpmed alarms - pseudo-wire : pseudo Wire related alarms - link-agg : Link aggregation related alarms - fcs-exceed : FCS auto-recovery related alarms - e1t1-interface : E1/T1 physical interfaces related alarms	
name	Parameter type: <Alarm::almtypeOntpotsihub> (ont-svc-pots-svc-mis ont-svc-pots-rtcp-lost ont-svc-pots-icnf-subs ont-svc-pots-icnf-ntfy ont-svc-pots-icnf-http ont-svc-pots-sip-reg ont-svc-pots-sip-inv ont-svc-pots-sip-subsc ont-svc-pots-sip-mt-tc ont-svc-pots-pk-los-tc ont-svc-pots-jitter-tc ont-svc-pots-subs-dns ont-svc-pots-subs-tcp ont-svc-pots-subs-tls ont-svc-pots-subs-auth ont-svc-pots-subs-to ont-svc-pots-subs-err ont-svc-pots-not-to ont-svc-pots-notref-to ont-svc-pots-not-mal ont-svc-pots-not-rej ont-svc-pots-http-dns ont-svc-pots-http-tcp ont-svc-pots-http-tls ont-svc-pots-http-auth ont-svc-pots-http-to ont-svc-pots-http-err ont-svc-pots-http-mal ont-svc-pots-insuff ont-svc-pots-poos all) Possible values: - ont-svc-pots-svc-mis : ont service mismatch for provisioned pots	alarm name that are active <i>This element is only shown in detail mode.</i>

name	Type	Description
	- ont-svc-pots-rtcp-lost: pots realtime transport control protocol stream lost - ont-svc-pots-icnf-subsc: pots line iconfig subscription failure - ont-svc-pots-icnf-ntfy: pots line iconfig notify failure - ont-svc-pots-icnf-http: pots line iconfig http failure - ont-svc-pots-sip-reg : pots line sip registration failure - ont-svc-pots-sip-inv : pots line sip invite request failure - ont-svc-pots-sip-subsc: pots line sip subscribe failure - ont-svc-pots-sip-mt-tc: pots line sip message timeout threshold crossed - ont-svc-pots-pk-los-tc: pots line rtp bearer packets loss threshold crossed - ont-svc-pots-jitter-tc: pots line rtp jitter threshold crossed - ont-svc-pots-subsc-dns : pots line iconfig subscription failed (DNS) - ont-svc-pots-subsc-tcp : pots line iconfig subscription failed (TCP) - ont-svc-pots-subsc-tls : pots line iconfig subscription failed (TLS) - ont-svc-pots-subsc-auth: pots line iconfig subscription failed authentication - ont-svc-pots-subsc-to : pots line iconfig subscription failed (timeout) - ont-svc-pots-subsc-err : pots line iconfig subscription response error - ont-svc-pots-not-to : pots line iconfig notification failed (timeout) - ont-svc-pots-notref-to: pots line iconfig notification refresh failed - ont-svc-pots-not-mal : pots line iconfig notification failed (malformed) - ont-svc-pots-not-rej : pots line iconfig notification rejected - ont-svc-pots-http-dns : pots line iconfig doc retrieval failed (DNS) - ont-svc-pots-http-tcp : pots line iconfig doc retrieval failed (TCP) - ont-svc-pots-http-tls : pots line iconfig doc retrieval failed (TLS) - ont-svc-pots-http-auth: pots line iconfig doc retrieval failed (authentication) - ont-svc-pots-http-to : pots line iconfig doc retrieval failed (timeout) - ont-svc-pots-http-err : pots line iconfig doc retrieval response error - ont-svc-pots-http-mal : pots line iconfig doc retrieval failed (malformed) - ont-svc-pots-insuff : pots line iconfig service failed (insufficient data) - ont-svc-pots-poos : pots ports out of service - all : ONT Services POTS related alarms	
severity	Parameter type: <Alarm::AlarmSeverity> (indeterminate warning minor major critical)	the alarms severity level <i>This element is only shown in detail mode.</i>

101 query current alarms by filters

name	Type	Description
	Possible values: - indeterminate : alarm severity is indeterminate - warning : alarm severity is warning - minor : alarm severity is minor - major : alarm severity is major - critical : alarm severity is critical	
servaff	Parameter type: <Alarm::alarmServAffect> ((service-affecting yes) (noservice-affecting no)) Possible values: - service-affecting : make this alarm service affecting - yes : make this alarm service affecting - noservice-affecting : make this alarm not service affecting - no : make this alarm not service affecting	alarms affect service or not <i>This element is only shown in detail mode.</i>
time	Parameter type: <Sys::timeInSecs> - the time (yyyy-mm-dd:hour:minutes:secs) - unit: UTC	time in seconds when alarm was updated <i>This element is only shown in detail mode.</i>
descript	Parameter type: <Alarm::AddInfoString> - additional alarm information	alarm description <i>This element is only shown in detail mode.</i>

101.63 show current alarm by filters

Command Description

show current alarms by filters

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm query ont-lan [ (name) [ severity <Alarm::querySeverity> ] [ servaff <Alarm::queryServAffect> ] [ ont-port <Alarm::queryDefaultAid> ] ]
```

Command Parameters

Table 101.63-1 "show current alarm by filters" Resource Parameters

Resource Identifier	Type	Description
(name)	Format: (ont-svc-lan-mismatch ont-svc-lan-loss-sig ont-svc-enet-poos all) Possible values: - ont-svc-lan-mismatch : ont service mismatch for lan - ont-svc-lan-loss-sig : loss of signal on an ethernet port interface - ont-svc-enet-poos : Ethernet Ports out of Service - all : ONT Services LAN related alarms	alarm name of ont lan
severity	Parameter type: <Alarm::querySeverity> Format: (indeterminate warning minor major critical all) Possible values: - indeterminate : alarm severity is indeterminate - warning : alarm severity is warning - minor : alarm severity is minor - major : alarm severity is major - critical : alarm severity is critical - all : all alarm severity	severity level of an alarm for reporting
servaff	Parameter type: <Alarm::queryServAffect> Format:	serviceaffecting no

101 query current alarms by filters

Resource Identifier	Type	Description
	(service-affecting noservice-affecting all) Possible values: - service-affecting : query alarm service affecting - noservice-affecting : query alarm not service affecting - all : query service affecting and not affecting alarms	
ont-port	Parameter type: <Alarm::queryDefaultAid> Format: all Possible values: - all : default AID parameter	all gpon ont port

Command Output

Table 101.63-2 "show current alarm by filters" Display parameters

Specific Information		
name	Type	Description
aidinfo	Parameter type: <Alarm::AddInfoString> - additional alarm information	alarm AID parameters <i>This element is only shown in detail mode.</i>
type	Parameter type: <Alarm::alarmIHUBType> (equipment eqpt-holder plug-in-unit atm custom e1 ima-group ima-link redundancy shdsl ether-itf traffic-overflow qos-queue temporal spatial (software-mngt sw-mgmt) xdsl xdsl-ext xdsl-tca olt-gen eo-conv authentication bonding sfp shdsl-isam custom-ext-alarm plug-in-unit-ext sip-user-agent sip-plugin-unit sip-termination e1-sip-termination filetransfer external-device l2forward	type of the alarms that are active <i>This element is only shown in detail mode.</i>

name	Type	Description
	ether-tca ether-sfp megaco-media-gw megaco-sig-gw megaco-plug-unit megaco-term megaco-sig-lt eqpt-supplemental eqpt-holder-ext lsmredundancy sync mcsrc vlanport vect-line vect-board otdr sip-dial-plan sip-vsp sip-server bgp rip lag ihub-general vprn isis ospf ihub-l2forward vpls ihub-equip ihub-link eont-phyoam ellid epon eont-services-lan eolt-ont-tca eont-sw-dl ldp mpls sdp epipe ihub-ipv6 pim li mgmt-sec-access bfd ai tr069serv ontsnmp bulk-sync protection-group ont sfu-sup soho-sup mdu-sup ont-ani sfu-sup2 soho-sup2	

101 query current alarms by filters

name	Type	Description
	mdu-sup2 sfprssi eoltrssi cfm sfpe1t1-framer sfpe1t1-clock pppcc-engine-tca eth-cfm rsvp ihub-tca eth-ring efm-oam ont-loopdetect ont-video ont-ces ont-voip ont-video-ani ont-pwe ont-cese1 ont-xdsl ont-xdsl-tca ont-hpna ont-sip-agent-cfg ont-voip-cfg ont-mgc ont-ploam ont-gen ont-card ont-pots ont-lan ont-moca ont-tc-tca ont-moca-tca ont-l2uni-eth-tca olt-pon-tc-tca olt-pon-util-tca olt-chpr-util-tca olt-ont-tc-tca ont-tca ont-pots-supplemental sfu-ploam sfu-gen soho-ploam soho-gen mdu-ploam mdu-gen ont-veip ont-iphost alarm-table auto-switch channel-pair ont-cfg-dld olt-chpair-tc-tca hgu-tr069 eqpt-psu ont-protection secondary-megaco-term	

name	Type	Description
	secondary-sip-term cas-r2-channel lldpmed pseudo-wire link-agg fcs-exceed e1t1-interface) Possible values: - equipment : equipment alarms - eqpt-holder : equipment holder alarms - plug-in-unit : plugin unit alarms - atm : ATM alarms - custom : customizable alarms - e1 : e1 alarms - ima-group : ima-group alarms - ima-link : ima-link alarms - redundancy : redundancy alarms - shdsl : shdsl alarms - ether-itf : ethernet interface alarms - traffic-overflow : Traffic overflow alarms - qos-queue : qos queue alarms - temporal : temporal alarms - spatial : spatial alarms - software-mngt : software management alarms - sw-mgmt : software management alarms - xdsl : xDSL alarms - xdsl-ext : other xDSL alarms - xdsl-tca : xDSL threshold cross alarms - olt-gen : OLT general alarms - eo-conv : E/O conversion related alarms - authentication : authentication related alarms - bonding : bonding-group related alarms - sfp : SFP related alarms - shdsl-isam : shdsl isam alarms - custom-ext-alarm : customizable external alarms - plug-in-unit-ext : other plugin unit alarms - sip-user-agent : sip user agent related alarms - sip-plugin-unit : sip plug in unit related alarms - sip-termination : sip termination related alarms - e1-sip-termination : E1 sip termination related alarms - filetransfer : file transfer server alarms - external-device : external device related alarms - l2forward : l2forward related alarms - ether-tca : ethernet threshold cross alarms - ether-sfp : ethernet SFP related alarms - megaco-media-gw : megaco media gateway related alarms - megaco-sig-gw : megaco signaling gateway related alarms - megaco-plug-unit : megaco plug unit related alarms - megaco-term : megaco termination related alarms - megaco-sig-lt : megaco signaling lt related alarms - eqpt-supplemental : equipment supplemental alarms - eqpt-holder-ext : other equipment holder alarms - lsmredundancy : lsm redundancy alarms - sync : synce and bits alarms - mcsrc : multicast source alarms - vlanport : vlanport alarms - vect-line : xDSL vectoring line alarms	

101 query current alarms by filters

name	Type	Description
	- vect-board : xDSL vectoring board alarms - otdr : otdr alarms - sip-dial-plan : sip dial plan related alarms - sip-vsp : sip vsp related alarms - sip-server : sip server related alarms - bgp : bgp related alarms - rip : rip related alarms - lag : LAG related alarms - ihub-general : IHUB general related alarms - vprn : vprn related alarms - isis : isis related alarms - ospf : ospf related alarms - ihub-l2forward : ihub-l2forward alarms - vpls : vpls related alarms - ihub-equip : ihub-equip related alarms - ihub-link : ihub-link related alarms - eont-phyoam : eont phyoam related alarms - ellid : ellid related alarms - epon : epon related alarms - eont-services-lan : eon phyoam related alarms - eolt-ont-tca : eon phyoam related alarms - eont-sw-dl : eon phyoam related alarms - ldp : ldp related alarms - mpls : mpls related alarms - sdp : sdp related alarms - epipe : epipe related alarms - ihub-ipv6 : ihub-ipv6 related alarms - pim : pim related alarms - li : lawful intercept related alarms - mgmt-sec-access : management security related alarms - bfd : bfd related alarms - ai : Application Intelligence related alarms - tr069serv : tr069 server related alarms - ontsnmp : ont snmp related alarms - bulk-sync : bulk-sync related alarms - protection-group : port protection group related alarms - ont : ONT general supplemental related alarms - sfu-sup : SFU ONT general supplemental related alarms - soho-sup : SOHO ONT general supplemental related alarms - mdu-sup : MDU ONT general supplemental related alarms - ont-ani : ONT general supplemental 2 related alarms - sfu-sup2 : SFU ONT general supplemental 2 related alarms - soho-sup2 : SOHO ONT general supplemental 2 related alarms - mdu-sup2 : MDU ONT general supplemental 2 related alarms - sfprssi : SFP RSSI related alarms - eoltrssi : epon olt Sfp RSSI related alarms - cfm : Cfm related alarms - sfpe1t1-framer : SFP 2e1t1 framer alarms - sfpe1t1-clock : SFP 2e1t1 clock alarms - pppcc-engine-tca : PPPOE Cross Connect Engine TCA related alarm - eth-cfm : eth-cfm related alarms - rsvp : rsvp related alarms - ihub-tca : IHUB TCA related alarms	

name	Type	Description
	- eth-ring : eth-ring related alarms - efm-oam : EFM-OAM related alarms - ont-loopdetect : ont loop detect related alarms - ont-video : ont services video related alarms - ont-ces : ont services ces related alarms - ont-voip : ont services voip related alarms - ont-video-ani : ont services video ani related alarms - ont-pwe : ont services pwe related alarms - ont-cese1 : ont services cese1 related alarms - ont-xdsl : ont services xdsl related alarms - ont-xdsl-tca : ont services xdsl tca related alarms - ont-hpna : ont hpna related alarms - ont-sip-agent-cfg : ont services voip sip agent config related alarms - ont-voip-cfg : ont services voip config related alarms - ont-mgc : ont mgc related alarms - ont-ploam : ONT PLOAM related alarms - ont-gen : ONT GENERAL related alarms - ont-card : ONT Subscriber Card related alarms - ont-pots : ONT Services POTS related alarms - ont-lan : ONT Services LAN related alarms - ont-moca : ONT MoCA related alarms - ont-tc-tca : ONT TC TCA related alarms - ont-moca-tca : ONT MoCA TCA related alarms - ont-l2uni-eth-tca : ONT L2 UNI Ethernet TCA related alarms - olt-pon-tc-tca : OLT PON TC TCA related alarms - olt-pon-util-tca : OLT PON utilization TCA related alarms - olt-chpr-util-tca : OLT channel-pair utilization TCA related alarms - olt-ont-tc-tca : OLT ONT TC TCA related alarms - ont-tca : ONT TCA related alarms - ont-pots-supplemental : ONT POTS Supplemental related alarms - sfu-ploam : SFU ONT PLOAM related alarms - sfu-gen : SFU ONT general related alarms - soho-ploam : SOHO ONT PLOAM related alarms - soho-gen : SOHO ONT general related alarms - mdu-ploam : MDU ONT PLOAM related alarms - mdu-gen : MDU ONT general related alarms - ont-veip : ONT VEIP related alarms - ont-iphost : ONT IP HOST related alarms - alarm-table : alarm table related alarms - auto-switch : auto-switch related alarms - channel-pair : channel pair related alarms - ont-cfg-dld : ont configure file download related alarms - olt-chpair-tc-tca : OLT CHANNELPAIR TC TCA related alarms - hgu-tr069 : hgu tr069 related alarms - eqpt-psu : equipment psu alarms - ont-protection : ONT protection related alarms - secondary-megaco-term : secondary megaco termination related alarms - secondary-sip-term : secondary sip termination related alarms - cas-r2-channel : CAS R2 channel related alarms - lldpmed : lldpmed alarms	

101 query current alarms by filters

name	Type	Description
	- pseudo-wire : pseudo Wire related alarms - link-aggr : Link aggregation related alarms - fcs-exceed : FCS auto-recovery related alarms - e1t1-interface : E1/T1 physical interfaces related alarms	
name	Parameter type: <Alarm::almtypeOntlanihub> (ont-svc-lan-mismatch ont-svc-lan-loss-sig ont-svc-enet-poos all) Possible values: - ont-svc-lan-mismatch : ont service mismatch for lan - ont-svc-lan-loss-sig : loss of signal on an ethernet port interface - ont-svc-enet-poos : Ethernet Ports out of Service - all : ONT Services LAN related alarms	alarm name that are active <i>This element is only shown in detail mode.</i>
severity	Parameter type: <Alarm::AlarmSeverity> (indeterminate warning minor major critical) Possible values: - indeterminate : alarm severity is indeterminate - warning : alarm severity is warning - minor : alarm severity is minor - major : alarm severity is major - critical : alarm severity is critical	the alarms severity level <i>This element is only shown in detail mode.</i>
servaff	Parameter type: <Alarm::alarmServAffect> ((service-affecting yes) (noservice-affecting no)) Possible values: - service-affecting : make this alarm service affecting - yes : make this alarm service affecting - noservice-affecting : make this alarm not service affecting - no : make this alarm not service affecting	alarms affect service or not <i>This element is only shown in detail mode.</i>
time	Parameter type: <Sys::timeInSecs> - the time (yyyy-mm-dd:hour:minutes:secs) - unit: UTC	time in seconds when alarm was updated <i>This element is only shown in detail mode.</i>
descript	Parameter type: <Alarm::AddInfoString> - additional alarm information	alarm description <i>This element is only shown in detail mode.</i>

101.64 show current alarm by filters

Command Description

show current alarms by filters

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm query ont-ces [ (name) [ severity <Alarm::querySeverity> ] [ servaff <Alarm::queryServAffect> ] [ cesds1-port <Alarm::queryDefaultAid> ] ]
```

Command Parameters

Table 101.64-1 "show current alarm by filters" Resource Parameters

Resource Identifier	Type	Description
(name)	Format: (ont-svc-ces-ds1-mis ont-svc-ces-ds1-los ont-svc-ces-ds1-lof ont-svc-ces-ds1-rair ont-svc-ces-ds1-ais ont-svc-ces-ds1-lnlpbk ont-svc-ces-ds1-tmlpbk all) Possible values: - ont-svc-ces-ds1-mis : ont service mismatch for provisioned ces ds1 - ont-svc-ces-ds1-los : loss of signal at ds1 interface - ont-svc-ces-ds1-lof : loss of frame at ds1 interface - ont-svc-ces-ds1-rair : receiving rai at ds1 interface - ont-svc-ces-ds1-ais : receiving ais at ds1 interface - ont-svc-ces-ds1-lnlpbk: receiving line loopback at ds1 interface - ont-svc-ces-ds1-tmlpbk: receiving terminal loopback at ds1 interface - all : ont services ces related alarms	alarm name of ont ces
severity	Parameter type: <Alarm::querySeverity> Format: (indeterminate warning minor major critical	severity level of an alarm for reporting

101 query current alarms by filters

Resource Identifier	Type	Description
	all) Possible values: - indeterminate : alarm severity is indeterminate - warning : alarm severity is warning - minor : alarm severity is minor - major : alarm severity is major - critical : alarm severity is critical - all : all alarm severity	
servaff	Parameter type: <Alarm::queryServAffect> Format: (service-affecting noservice-affecting all) Possible values: - service-affecting : query alarm service affecting - noservice-affecting : query alarm not service affecting - all : query service affecting and not affecting alarms	serviceaffecting no serviceaffecting
cesds1-port	Parameter type: <Alarm::queryDefaultAid> Format: all Possible values: - all : default AID parameter	all ces port

Command Output

Table 101.64-2 "show current alarm by filters" Display parameters

Specific Information		
name	Type	Description
aidinfo	Parameter type: <Alarm::AddInfoString> - additional alarm information	alarm AID parameters <i>This element is only shown in detail mode.</i>
type	Parameter type: <Alarm::alarmIHUBType> (equipment eqpt-holder plug-in-unit atm custom e1 ima-group ima-link redundancy shdsl ether-itf traffic-overflow qos-queue temporal spatial (software-mngt sw-mgmt) xdsl xdsl-ext xdsl-tca olt-gen eo-conv authentication bonding sfp	type of the alarms that are active <i>This element is only shown in detail mode.</i>

name	Type	Description
	shdsl-isam	
	custom-ext-alarm	
	plug-in-unit-ext	
	sip-user-agent	
	sip-plugin-unit	
	sip-termination	
	e1-sip-termination	
	filetransfer	
	external-device	
	l2forward	
	ether-tca	
	ether-sfp	
	megaco-media-gw	
	megaco-sig-gw	
	megaco-plug-unit	
	megaco-term	
	megaco-sig-lt	
	eqpt-supplemental	
	eqpt-holder-ext	
	lsmredundancy	
	sync	
	mcsrc	
	vlanport	
	vect-line	
	vect-board	
	otdr	
	sip-dial-plan	
	sip-vsp	
	sip-server	
	bgp	
	rip	
	lag	
	ihub-general	
	vprn	
	isis	
	ospf	
	ihub-l2forward	
	vpls	
	ihub-equip	
	ihub-link	
	eont-phyoam	
	ellid	
	epon	
	eont-services-lan	
	eolt-ont-tca	
	eont-sw-dl	
	ldp	
	mpls	
	sdp	
	epipe	
	ihub-ipv6	
	pim	
	li	
	mgmt-sec-access	
	bfd	
	ai	
	tr069serv	

101 query current alarms by filters

name	Type	Description
	ontsnmp bulk-sync protection-group ont sfu-sup soho-sup mdu-sup ont-ani sfu-sup2 soho-sup2 mdu-sup2 sfprssi eoltrssi cfm sfpe1t1-framer sfpe1t1-clock pppcc-engine-tca eth-cfm rsvp ihub-tca eth-ring efm-oam ont-loopdetect ont-video ont-ces ont-voip ont-video-ani ont-pwe ont-cese1 ont-xdsl ont-xdsl-tca ont-hpna ont-sip-agent-cfg ont-voip-cfg ont-mgc ont-ploam ont-gen ont-card ont-pots ont-lan ont-moca ont-tc-tca ont-moca-tca ont-l2uni-eth-tca olt-pon-tc-tca olt-pon-util-tca olt-chpr-util-tca olt-ont-tc-tca ont-tca ont-pots-supplemental sfu-ploam sfu-gen soho-ploam soho-gen mdu-ploam mdu-gen ont-veip	

name	Type	Description
	ont-iphost alarm-table auto-switch channel-pair ont-cfg-dld olt-chpair-tc-tca hgu-tr069 eqpt-psu ont-protection secondary-megaco-term secondary-sip-term cas-r2-channel lldpmed pseudo-wire link-agg fcs-exceed e1t1-interface) Possible values: - equipment : equipment alarms - eqpt-holder : equipment holder alarms - plug-in-unit : plugin unit alarms - atm : ATM alarms - custom : customizable alarms - e1 : e1 alarms - ima-group : ima-group alarms - ima-link : ima-link alarms - redundancy : redundancy alarms - shdsl : shdsl alarms - ether-itf : ethernet interface alarms - traffic-overflow : Traffic overflow alarms - qos-queue : qos queue alarms - temporal : temporal alarms - spatial : spatial alarms - software-mngt : software management alarms - sw-mgmt : software management alarms - xdsl : xDSL alarms - xdsl-ext : other xDSL alarms - xdsl-tca : xDSL threshold cross alarms - olt-gen : OLT general alarms - eo-conv : E/O conversion related alarms - authentication : authentication related alarms - bonding : bonding-group related alarms - sfp : SFP related alarms - shdsl-isam : shdsl isam alarms - custom-ext-alarm : customizable external alarms - plug-in-unit-ext : other plugin unit alarms - sip-user-agent : sip user agent related alarms - sip-plugin-unit : sip plug in unit related alarms - sip-termination : sip termination related alarms - e1-sip-termination : E1 sip termination related alarms - filetransfer : file transfer server alarms - external-device : external device related alarms - l2forward : l2forward related alarms - ether-tca : ethernet threshold cross alarms - ether-sfp : ethernet SFP related alarms - megaco-media-gw : megaco media gateway related alarms - megaco-sig-gw : megaco signaling gateway related alarms	

101 query current alarms by filters

name	Type	Description
	- megaco-plug-unit : megaco plug unit related alarms - megaco-term : megaco termination related alarms - megaco-sig-lt : megaco signaling lt related alarms - eqpt-supplemental : equipment supplemental alarms - eqpt-holder-ext : other equipment holder alarms - lsmredundancy : lsm redundancy alarms - sync : synce and bits alarms - mcsrc : multicast source alarms - vlanport : vlanport alarms - vect-line : xDSL vectoring line alarms - vect-board : xDSL vectoring board alarms - otdr : otdr alarms - sip-dial-plan : sip dial plan related alarms - sip-vsp : sip vsp related alarms - sip-server : sip server related alarms - bgp : bgp related alarms - rip : rip related alarms - lag : LAG related alarms - ihub-general : IHUB general related alarms - vprn : vprn related alarms - isis : isis related alarms - ospf : ospf related alarms - ihub-l2forward : ihub-l2forward alarms - vpls : vpls related alarms - ihub-equip : ihub-equip related alarms - ihub-link : ihub-link related alarms - eont-phyoam : eont phyoam related alarms - ellid : ellid related alarms - epon : epon related alarms - eont-services-lan : eon phyoam related alarms - eolt-ont-tca : eon phyoam related alarms - eont-sw-dl : eon phyoam related alarms - ldp : ldp related alarms - mpls : mpls related alarms - sdp : sdp related alarms - epipe : epipe related alarms - ihub-ipv6 : ihub-ipv6 related alarms - pim : pim related alarms - li : lawful intercept related alarms - mgmt-sec-access : management security related alarms - bfd : bfd related alarms - ai : Application Intelligence related alarms - tr069serv : tr069 server related alarms - ontsnmp : ont snmp related alarms - bulk-sync : bulk-sync related alarms - protection-group : port protection group related alarms - ont : ONT general supplemental related alarms - sfu-sup : SFU ONT general supplemental related alarms - soho-sup : SOHO ONT general supplemental related alarms - mdu-sup : MDU ONT general supplemental related alarms - ont-ani : ONT general supplemental 2 related alarms - sfu-sup2 : SFU ONT general supplemental 2 related alarms - soho-sup2 : SOHO ONT general supplemental 2 related alarms - mdu-sup2 : MDU ONT general supplemental 2 related alarms	

name	Type	Description
	- sfprssi : SFP RSSI related alarms - eoltrssi : epon olt Sfp RSSI related alarms - cfm : Cfm related alarms - sfpe1t1-framer : SFP 2e1t1 framer alarms - sfpe1t1-clock : SFP 2e1t1 clock alarms - pppcc-engine-tca : PPPOE Cross Connect Engine TCA related alarm - eth-cfm : eth-cfm related alarms - rsvp : rsvp related alarms - ihub-tca : IHUB TCA related alarms - eth-ring : eth-ring related alarms - efm-oam : EFM-OAM related alarms - ont-loopdetect : ont loop detect related alarms - ont-video : ont services video related alarms - ont-ces : ont services ces related alarms - ont-voip : ont services voip related alarms - ont-video-ani : ont services video ani related alarms - ont-pwe : ont services pwe related alarms - ont-cese1 : ont services cese1 related alarms - ont-xdsl : ont services xdsl related alarms - ont-xdsl-tca : ont services xdsl tca related alarms - ont-hpna : ont hpna related alarms - ont-sip-agent-cfg : ont services voip sip agent config related alarms - ont-voip-cfg : ont services voip config related alarms - ont-mgc : ont mgc related alarms - ont-ploam : ONT PLOAM related alarms - ont-gen : ONT GENERAL related alarms - ont-card : ONT Subscriber Card related alarms - ont-pots : ONT Services POTS related alarms - ont-lan : ONT Services LAN related alarms - ont-moca : ONT MoCA related alarms - ont-tc-tca : ONT TC TCA related alarms - ont-moca-tca : ONT MoCA TCA related alarms - ont-l2uni-eth-tca : ONT L2 UNI Ethernet TCA related alarms - olt-pon-tc-tca : OLT PON TC TCA related alarms - olt-pon-util-tca : OLT PON utilization TCA related alarms - olt-chpr-util-tca : OLT channel-pair utilization TCA related alarms - olt-ont-tc-tca : OLT ONT TC TCA related alarms - ont-tca : ONT TCA related alarms - ont-pots-supplemental : ONT POTS Supplemental related alarms - sfu-ploam : SFU ONT PLOAM related alarms - sfu-gen : SFU ONT general related alarms - soho-ploam : SOHO ONT PLOAM related alarms - soho-gen : SOHO ONT general related alarms - mdw-ploam : MDU ONT PLOAM related alarms - mdw-gen : MDU ONT general related alarms - ont-veip : ONT VEIP related alarms - ont-iphost : ONT IP HOST related alarms - alarm-table : alarm table related alarms - auto-switch : auto-switch related alarms - channel-pair : channel pair related alarms - ont-cfg-dld : ont configure file download related alarms - olt-chpair-tc-tca : OLT CHANNELPAIR TC TCA related	

101 query current alarms by filters

name	Type	Description
	alarms - hgu-tr069 : hgu tr069 related alarms - eqpt-psu : equipment psu alarms - ont-protection : ONT protection related alarms - secondary-megaco-term : secondary megaco termination related alarms - secondary-sip-term : secondary sip termination related alarms - cas-r2-channel : CAS R2 channel related alarms - lldpmed : lldpmed alarms - pseudo-wire : pseudo Wire related alarms - link-agg : Link aggregation related alarms - fcs-exceed : FCS auto-recovery related alarms - e1t1-interface : E1/T1 physical interfaces related alarms	
name	Parameter type: <Alarm::almtypeOntcesihub> (ont-svc-ces-ds1-mis ont-svc-ces-ds1-los ont-svc-ces-ds1-lof ont-svc-ces-ds1-rair ont-svc-ces-ds1-ais ont-svc-ces-ds1-lnlpbk ont-svc-ces-ds1-tmlpbk all) Possible values: - ont-svc-ces-ds1-mis : ont service mismatch for provisioned ces ds1 - ont-svc-ces-ds1-los : loss of signal at ds1 interface - ont-svc-ces-ds1-lof : loss of frame at ds1 interface - ont-svc-ces-ds1-rair : receiving rai at ds1 interface - ont-svc-ces-ds1-ais : receiving ais at ds1 interface - ont-svc-ces-ds1-lnlpbk: receiving line loopback at ds1 interface - ont-svc-ces-ds1-tmlpbk: receiving terminal loopback at ds1 interface - all : ont services ces related alarms	alarm name that are active <i>This element is only shown in detail mode.</i>
severity	Parameter type: <Alarm::AlarmSeverity> (indeterminate warning minor major critical) Possible values: - indeterminate : alarm severity is indeterminate - warning : alarm severity is warning - minor : alarm severity is minor - major : alarm severity is major - critical : alarm severity is critical	the alarms severity level <i>This element is only shown in detail mode.</i>
servaff	Parameter type: <Alarm::alarmServAffect> ((service-affecting yes) (noservice-affecting no)) Possible values: - service-affecting : make this alarm service affecting - yes : make this alarm service affecting - noservice-affecting : make this alarm not service affecting - no : make this alarm not service affecting	alarms affect service or not <i>This element is only shown in detail mode.</i>
location	Parameter type: <Alarm::almLocation> (near-end	alarm location: near, middle, far <i>This element is only shown in</i>

name	Type	Description
	far-end middle-end line null) Possible values: - near-end : alarm location is near - far-end : alarm location is far - middle-end : alarm location is middle - line : alarm location is line - null : alarm location not defined	<i>detail mode.</i>
time	Parameter type: <Sys::timeInSecs> - the time (yyyy-mm-dd:hour:minutes:secs) - unit: UTC	time in seconds when alarm was updated <i>This element is only shown in detail mode.</i>
direction	Parameter type: <Alarm::almDirection> (received transmit null) Possible values: - received : alarm is received - transmit : alarm is transmit - null : direction not defined	alarm direction: received or transmit <i>This element is only shown in detail mode.</i>
descript	Parameter type: <Alarm::AddInfoString> - additional alarm information	alarm description <i>This element is only shown in detail mode.</i>

101.65 show current alarm by filters

Command Description

show current alarms by filters

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm query ont-voip [ (name) [ severity <Alarm::querySeverity> ] [ servaff <Alarm::queryServAffect> ] [ voip-uni <Gpon::VoipOntIndex> ] ]
```

Command Parameters

Table 101.65-1 "show current alarm by filters" Resource Parameters

Resource Identifier	Type	Description
(name)	Format: (ont-svc-voip-cnf-file ont-svc-voip-svc-mis ont-svc-voip-gw-comm ont-svc-voip-dhcp-fail ont-svc-voip-icnf-subs ont-svc-voip-icnf-ntfy ont-svc-voip-icnf-http ont-svc-voip-dhcp-to ont-svc-voip-dhcp-mal ont-svc-voip-dhcp-noad ont-svc-voip-dhcp-leas ont-svc-voip-subs-dns ont-svc-voip-subs-tcp ont-svc-voip-subs-tls ont-svc-voip-subs-auth ont-svc-voip-subs-to ont-svc-voip-subs-err ont-svc-voip-not-to ont-svc-voip-notref-to ont-svc-voip-not-mal ont-svc-voip-not-rej ont-svc-voip-http-dns ont-svc-voip-http-tcp ont-svc-voip-http-tls ont-svc-voip-http-auth ont-svc-voip-http-to ont-svc-voip-http-err	alarm name of ont voip

Resource Identifier	Type	Description
	ont-svc-voip-http-mal ont-svc-voip-subscription-refr ont-svc-voip-not-refr ont-svc-voip-icfg-err all) Possible values: - ont-svc-voip-cnf-file : voice configuration file error - ont-svc-voip-svc-mis : service mismatch for provisioned client service - ont-svc-voip-gw-comm : voice gateway communication failure - ont-svc-voip-dhcp-fail: voice dhcp server failure - ont-svc-voip-icnf-subscription: voice iconfig subscription failure - ont-svc-voip-icnf-notify: voice iconfig notify failure - ont-svc-voip-icnf-http: voice iconfig http failure - ont-svc-voip-dhcp-to : DHCP server retransmissions timed out - ont-svc-voip-dhcp-mal : DHCP response was malformed - ont-svc-voip-dhcp-noad: DHCP server failed to issue the required parameters - ont-svc-voip-dhcp-leas: DHCP Server failure due to problem in lease renewal - ont-svc-voip-subscription-dns : iConfig Subscription failure due to DNS problem - ont-svc-voip-subscription-tcp : iConfig Subscription failure due to TCP socket problem - ont-svc-voip-subscription-tls : iConfig Subscription failure due to TLS session problem - ont-svc-voip-subscription-auth: iConfig Subscription failure due to authentication error - ont-svc-voip-subscription-to : iConfig Subscription failure due to retransmission timeout - ont-svc-voip-subscription-err : iConfig Subscription failure due to response error - ont-svc-voip-not-to : iConfig Notify response timeout for new subscription - ont-svc-voip-notref-to: iConfig Notify response timeout for subscription refresh - ont-svc-voip-not-mal : iConfig Notify response is malformed - ont-svc-voip-not-rej : iConfig subscription request rejected by configuration server - ont-svc-voip-http-dns : VOIP client can't retrieve config doc due to DNS problem - ont-svc-voip-http-tcp : VOIP client can't retrieve config doc due to TCP socket problem - ont-svc-voip-http-tls : VOIP client can't retrieve config doc due to TLS session problem - ont-svc-voip-http-auth: VOIP client can't retrieve config doc due to auth error - ont-svc-voip-http-to : VOIP client can't retrieve config doc due to re-tx timeout - ont-svc-voip-http-err : VOIP client can't retrieve config doc due to response error - ont-svc-voip-http-mal : iConfig configuration document is malformed - ont-svc-voip-subscription-refr: iConfig Subscription refresh error	

101 query current alarms by filters

Resource Identifier	Type	Description
	- ont-svc-voip-not-refr : iConfig Notify response for refresh subscribe failed - ont-svc-voip-icfg-err : iConfig Configuration Error - all : ont services voip related alarms	
severity	Parameter type: <Alarm::querySeverity> Format: (indeterminate warning minor major critical all) Possible values: - indeterminate : alarm severity is indeterminate - warning : alarm severity is warning - minor : alarm severity is minor - major : alarm severity is major - critical : alarm severity is critical - all : all alarm severity	severity level of an alarm for reporting
servaff	Parameter type: <Alarm::queryServAffect> Format: (service-affecting noservice-affecting all) Possible values: - service-affecting : query alarm service affecting - noservice-affecting : query alarm not service affecting - all : query service affecting and not affecting alarms	serviceaffecting no serviceaffecting
voip-uni	Parameter type: <Gpon::VoipOntIndex> Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / 1 ng2 : <Ng2::ChannelGroup> / <Ng2::SubchannelGroup> / <Ng2::OntId> / 1) Possible values: - ng2 : ngpon2 style identification Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Eqpt::OntId> - the ONT identifier Possible values: - 1 : Gpon voip Port Field type <Ng2::ChannelGroup> - channel group number Field type <Ng2::SubchannelGroup> - subchannel group number Field type <Ng2::OntId> - the ONT identifier Possible values: - 1 : Gpon voip Port	uni ifindex

Command Output

Table 101.65-2 "show current alarm by filters" Display parameters

Specific Information		
name	Type	Description
aidinfo	Parameter type: <Alarm::AddInfoString> - additional alarm information	alarm AID parameters <i>This element is only shown in detail mode.</i>
type	Parameter type: <Alarm::alarmIHUBType> (equipment eqpt-holder plug-in-unit atm custom e1 ima-group ima-link redundancy shdsl ether-itf traffic-overflow qos-queue temporal spatial (software-mngt sw-mgmt) xdsl xdsl-ext xdsl-tca olt-gen eo-conv authentication bonding sfp shdsl-isam custom-ext-alarm plug-in-unit-ext sip-user-agent sip-plugin-unit sip-termination e1-sip-termination filetransfer external-device l2forward ether-tca ether-sfp megaco-media-gw megaco-sig-gw megaco-plug-unit megaco-term megaco-sig-lt eqpt-supplemental eqpt-holder-ext lsmredundancy sync mcsrc vlanport	type of the alarms that are active <i>This element is only shown in detail mode.</i>

101 query current alarms by filters

name	Type	Description
	vect-line	
	vect-board	
	otdr	
	sip-dial-plan	
	sip-vsp	
	sip-server	
	bgp	
	rip	
	lag	
	ihub-general	
	vprn	
	isis	
	ospf	
	ihub-l2forward	
	vpls	
	ihub-equip	
	ihub-link	
	eont-phyoam	
	ellid	
	epon	
	eont-services-lan	
	eolt-ont-tca	
	eont-sw-dl	
	ldp	
	mpls	
	sdp	
	epipe	
	ihub-ipv6	
	pim	
	li	
	mgmt-sec-access	
	bfd	
	ai	
	tr069serv	
	ontsnmp	
	bulk-sync	
	protection-group	
	ont	
	sfu-sup	
	soho-sup	
	mdu-sup	
	ont-ani	
	sfu-sup2	
	soho-sup2	
	mdu-sup2	
	sfprssi	
	eoltrssi	
	cfm	
	sfpe1t1-framer	
	sfpe1t1-clock	
	pppcc-engine-tca	
	eth-cfm	
	rsvp	
	ihub-tca	
	eth-ring	
	efm-oam	
	ont-loopdetect	

name	Type	Description
	ont-video ont-ces ont-voip ont-video-ani ont-pwe ont-cese1 ont-xdsl ont-xdsl-tca ont-hpna ont-sip-agent-cfg ont-voip-cfg ont-mgc ont-ploam ont-gen ont-card ont-pots ont-lan ont-moca ont-tc-tca ont-moca-tca ont-l2uni-eth-tca olt-pon-tc-tca olt-pon-util-tca olt-chpr-util-tca olt-ont-tc-tca ont-tca ont-pots-supplemental sfu-ploam sfu-gen soho-ploam soho-gen mdu-ploam mdu-gen ont-veip ont-iphost alarm-table auto-switch channel-pair ont-cfg-dld olt-chpair-tc-tca hgu-tr069 eqpt-psu ont-protection secondary-megaco-term secondary-sip-term cas-r2-channel lldpmed pseudo-wire link-agg fcs-exceed e1t1-interface) Possible values: - equipment : equipment alarms - eqpt-holder : equipment holder alarms - plug-in-unit : plugin unit alarms - atm : ATM alarms - custom : customizable alarms	

101 query current alarms by filters

name	Type	Description
	- e1 : e1 alarms - ima-group : ima-group alarms - ima-link : ima-link alarms - redundancy : redundancy alarms - shdsl : shdsl alarms - ether-itf : ethernet interface alarms - traffic-overflow : Traffic overflow alarms - qos-queue : qos queue alarms - temporal : temporal alarms - spatial : spatial alarms - software-mngt : software management alarms - sw-mgmt : software management alarms - xdsl : xDSL alarms - xdsl-ext : other xDSL alarms - xdsl-tca : xDSL threshold cross alarms - olt-gen : OLT general alarms - eo-conv : E/O conversion related alarms - authentication : authentication related alarms - bonding : bonding-group related alarms - sfp : SFP related alarms - shdsl-isam : shdsl isam alarms - custom-ext-alarm : customizable external alarms - plug-in-unit-ext : other plugin unit alarms - sip-user-agent : sip user agent related alarms - sip-plugin-unit : sip plug in unit related alarms - sip-termination : sip termination related alarms - e1-sip-termination : E1 sip termination related alarms - filetransfer : file transfer server alarms - external-device : external device related alarms - l2forward : l2forward related alarms - ether-tca : ethernet threshold cross alarms - ether-sfp : ethernet SFP related alarms - megaco-media-gw : megaco media gateway related alarms - megaco-sig-gw : megaco signaling gateway related alarms - megaco-plug-unit : megaco plug unit related alarms - megaco-term : megaco termination related alarms - megaco-sig-lt : megaco signaling lt related alarms - eqpt-supplemental : equipment supplemental alarms - eqpt-holder-ext : other equipment holder alarms - lsmredundancy : lsm redundancy alarms - sync : synce and bits alarms - mcsrc : multicast source alarms - vlanport : vlanport alarms - vect-line : xDSL vectoring line alarms - vect-board : xDSL vectoring board alarms - otdr : otdr alarms - sip-dial-plan : sip dial plan related alarms - sip-vsp : sip vsp related alarms - sip-server : sip server related alarms - bgp : bgp related alarms - rip : rip related alarms - lag : LAG related alarms - ihub-general : IHUB general related alarms - vprn : vprn related alarms - isis : isis related alarms - ospf : ospf related alarms - ihub-l2forward : ihub-l2forward alarms	

name	Type	Description
	- vpls : vpls related alarms - ihub-equip : ihub-equip related alarms - ihub-link : ihub-link related alarms - eont-phyoam : eont phyoam related alarms - ellid : ellid related alarms - epon : epon related alarms - eont-services-lan : eon phyoam related alarms - eolt-ont-tca : eon phyoam related alarms - eont-sw-dl : eon phyoam related alarms - ldp : ldp related alarms - mpls : mpls related alarms - sdp : sdp related alarms - epipe : epipe related alarms - ihub-ipv6 : ihub-ipv6 related alarms - pim : pim related alarms - li : lawful intercept related alarms - mgmt-sec-access : management security related alarms - bfd : bfd related alarms - ai : Application Intelligence related alarms - tr069serv : tr069 server related alarms - ontsnmp : ont snmp related alarms - bulk-sync : bulk-sync related alarms - protection-group : port protection group related alarms - ont : ONT general supplemental related alarms - sfu-sup : SFU ONT general supplemental related alarms - soho-sup : SOHO ONT general supplemental related alarms - mdu-sup : MDU ONT general supplemental related alarms - ont-ani : ONT general supplemental 2 related alarms - sfu-sup2 : SFU ONT general supplemental 2 related alarms - soho-sup2 : SOHO ONT general supplemental 2 related alarms - mdu-sup2 : MDU ONT general supplemental 2 related alarms - sfprssi : SFP RSSI related alarms - eoltrssi : epon olt Sfp RSSI related alarms - cfm : Cfm related alarms - sfpe1t1-framer : SFP 2e1t1 framer alarms - sfpe1t1-clock : SFP 2e1t1 clock alarms - pppcc-engine-tca : PPPOE Cross Connect Engine TCA related alarm - eth-cfm : eth-cfm related alarms - rsvp : rsvp related alarms - ihub-tca : IHUB TCA related alarms - eth-ring : eth-ring related alarms - efm-oam : EFM-OAM related alarms - ont-loopdetect : ont loop detect related alarms - ont-video : ont services video related alarms - ont-ces : ont services ces related alarms - ont-voip : ont services voip related alarms - ont-video-ani : ont services video ani related alarms - ont-pwe : ont services pwe related alarms - ont-cese1 : ont services cese1 related alarms - ont-xdsl : ont services xdsl related alarms - ont-xdsl-tca : ont services xdsl tca related alarms - ont-hpna : ont hpna related alarms - ont-sip-agent-cfg : ont services voip sip agent config	

101 query current alarms by filters

name	Type	Description
	related alarms - ont-voip-cfg : ont services voip config related alarms - ont-mgc : ont mgc related alarms - ont-ploam : ONT PLOAM related alarms - ont-gen : ONT GENERAL related alarms - ont-card : ONT Subscriber Card related alarms - ont-pots : ONT Services POTS related alarms - ont-lan : ONT Services LAN related alarms - ont-moca : ONT MoCA related alarms - ont-tc-tca : ONT TC TCA related alarms - ont-moca-tca : ONT MoCA TCA related alarms - ont-l2uni-eth-tca : ONT L2 UNI Ethernet TCA related alarms - olt-pon-tc-tca : OLT PON TC TCA related alarms - olt-pon-util-tca : OLT PON utilization TCA related alarms - olt-chpr-util-tca : OLT channel-pair utilization TCA related alarms - olt-ont-tc-tca : OLT ONT TC TCA related alarms - ont-tca : ONT TCA related alarms - ont-pots-supplemental : ONT POTS Supplemental related alarms - sfu-ploam : SFU ONT PLOAM related alarms - sfu-gen : SFU ONT general related alarms - soho-ploam : SOHO ONT PLOAM related alarms - soho-gen : SOHO ONT general related alarms - mdu-ploam : MDU ONT PLOAM related alarms - mdu-gen : MDU ONT general related alarms - ont-veip : ONT VEIP related alarms - ont-iphost : ONT IP HOST related alarms - alarm-table : alarm table related alarms - auto-switch : auto-switch related alarms - channel-pair : channel pair related alarms - ont-cfg-dld : ont configure file download related alarms - olt-chpair-tc-tca : OLT CHANNELPAIR TC TCA related alarms - hgu-tr069 : hgu tr069 related alarms - eqpt-psu : equipment psu alarms - ont-protection : ONT protection related alarms - secondary-megaco-term : secondary megaco termination related alarms - secondary-sip-term : secondary sip termination related alarms - cas-r2-channel : CAS R2 channel related alarms - lldpmed : lldpmed alarms - pseudo-wire : pseudo Wire related alarms - link-agg : Link aggregation related alarms - fcs-exceed : FCS auto-recovery related alarms - e1t1-interface : E1/T1 physical interfaces related alarms	
name	Parameter type: <Alarm::alarmtypeOntvoipihub> (ont-svc-voip-cnfile ont-svc-voip-svc-mis ont-svc-voip-gw-comm ont-svc-voip-dhcp-fail ont-svc-voip-icnf-subs ont-svc-voip-icnf-ntfy ont-svc-voip-icnf-http ont-svc-voip-dhcp-to	alarm name that are active <i>This element is only shown in detail mode.</i>

name	Type	Description
	ont-svc-voip-dhcp-mal ont-svc-voip-dhcp-noad ont-svc-voip-dhcp-leas ont-svc-voip-subscription-dns ont-svc-voip-subscription-tcp ont-svc-voip-subscription-tls ont-svc-voip-subscription-auth ont-svc-voip-subscription-to ont-svc-voip-subscription-err ont-svc-voip-not-to ont-svc-voip-notref-to ont-svc-voip-not-mal ont-svc-voip-not-rej ont-svc-voip-http-dns ont-svc-voip-http-tcp ont-svc-voip-http-tls ont-svc-voip-http-auth ont-svc-voip-http-to ont-svc-voip-http-err ont-svc-voip-http-mal ont-svc-voip-subscription-refr ont-svc-voip-not-refr ont-svc-voip-icfg-err all) Possible values: - ont-svc-voip-cnfg-file : voice configuration file error - ont-svc-voip-svc-mis : service mismatch for provisioned client service - ont-svc-voip-gw-comm : voice gateway communication failure - ont-svc-voip-dhcp-fail: voice dhcp server failure - ont-svc-voip-icnf-subscription: voice iconfig subscription failure - ont-svc-voip-icnf-notify: voice iconfig notify failure - ont-svc-voip-icnf-http: voice iconfig http failure - ont-svc-voip-dhcp-to : DHCP server retransmissions timed out - ont-svc-voip-dhcp-mal : DHCP response was malformed - ont-svc-voip-dhcp-noad: DHCP server failed to issue the required parameters - ont-svc-voip-dhcp-leas: DHCP Server failure due to problem in lease renewal - ont-svc-voip-subscription-dns : iConfig Subscription failure due to DNS problem - ont-svc-voip-subscription-tcp : iConfig Subscription failure due to TCP socket problem - ont-svc-voip-subscription-tls : iConfig Subscription failure due to TLS session problem - ont-svc-voip-subscription-auth: iConfig Subscription failure due to authentication error - ont-svc-voip-subscription-to : iConfig Subscription failure due to retransmission timeout - ont-svc-voip-subscription-err : iConfig Subscription failure due to response error - ont-svc-voip-not-to : iConfig Notify response timeout for new subscription - ont-svc-voip-notref-to: iConfig Notify response timeout for subscription refresh	

101 query current alarms by filters

name	Type	Description
	- ont-svc-voip-not-mal : iConfig Notify response is malformed - ont-svc-voip-not-rej : iConfig subscription request rejected by configuration server - ont-svc-voip-http-dns : VOIP client can't retrieve config doc due to DNS problem - ont-svc-voip-http-tcp : VOIP client can't retrieve config doc due to TCP socket problem - ont-svc-voip-http-tls : VOIP client can't retrieve config doc due to TLS session problem - ont-svc-voip-http-auth: VOIP client can't retrieve config doc due to auth error - ont-svc-voip-http-to : VOIP client can't retrieve config doc due to re-tx timeout - ont-svc-voip-http-err : VOIP client can't retrieve config doc due to response error - ont-svc-voip-http-mal : iConfig configuration document is malformed - ont-svc-voip-sub-refr: iConfig Subscription refresh error - ont-svc-voip-not-refr : iConfig Notify response for refresh subscribe failed - ont-svc-voip-icfg-err : iConfig Configuration Error - all : ont services voip related alarms	
severity	Parameter type: <Alarm::AlarmSeverity> (indeterminate warning minor major critical) Possible values: - indeterminate : alarm severity is indeterminate - warning : alarm severity is warning - minor : alarm severity is minor - major : alarm severity is major - critical : alarm severity is critical	the alarms severity level <i>This element is only shown in detail mode.</i>
servaff	Parameter type: <Alarm::alarmServAffect> ((service-affecting yes) (noservice-affecting no)) Possible values: - service-affecting : make this alarm service affecting - yes : make this alarm service affecting - noservice-affecting : make this alarm not service affecting - no : make this alarm not service affecting	alarms affect service or not <i>This element is only shown in detail mode.</i>
time	Parameter type: <Sys::timeInSecs> - the time (yyyy-mm-dd:hour:minutes:secs) - unit: UTC	time in seconds when alarm was updated <i>This element is only shown in detail mode.</i>
descript	Parameter type: <Alarm::AddInfoString> - additional alarm information	alarm description <i>This element is only shown in detail mode.</i>

101.66 show current alarm by filters

Command Description

show current alarms by filters

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm query ont-video-ani [ (name) [ severity <Alarm::querySeverity> ] [ servaff
<Alarm::queryServAffect> ] [ ont <Gpon::OntIndex> ] ]
```

Command Parameters

Table 101.66-1 "show current alarm by filters" Resource Parameters

Resource Identifier	Type	Description
(name)	Format: (ont-svc-v-ani-conf-mis ont-svc-v-ani-loss-sig ont-svc-v-ani-lv-high ont-svc-v-ani-lv-low all) Possible values: - ont-svc-v-ani-conf-mis: config request failure for video ani service - ont-svc-v-ani-loss-sig: video loss of signal on ani - ont-svc-v-ani-lv-high : high video optical signal level - ont-svc-v-ani-lv-low : low video optical signal level - all : ont services video ani related alarms	alarm name of ont video ani
severity	Parameter type: <Alarm::querySeverity> Format: (indeterminate warning minor major critical all) Possible values: - indeterminate : alarm severity is indeterminate - warning : alarm severity is warning - minor : alarm severity is minor - major : alarm severity is major - critical : alarm severity is critical - all : all alarm severity	severity level of an alarm for reporting

101 query current alarms by filters

Resource Identifier	Type	Description
servaff	Parameter type: <Alarm::queryServAffect> Format: (service-affecting noservice-affecting all) Possible values: - service-affecting : query alarm service affecting - noservice-affecting : query alarm not service affecting - all : query service affecting and not affecting alarms	serviceaffecting no serviceaffecting
ont	Parameter type: <Gpon::OntIndex> Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> ng2 : <Ng2::ChannelGroup> / <Ng2::SubchannelGroup> / <Ng2::OntId>) Possible values: - ng2 : ngpon2 style identification Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Ng2::ChannelGroup> - channel group number Field type <Ng2::SubchannelGroup> - subchannel group number Field type <Eqpt::OntId> - the ONT identifier Field type <Ng2::OntId> - the ONT identifier	gpon ont equipment ifindex of ont

Command Output

Table 101.66-2 "show current alarm by filters" Display parameters

Specific Information		
name	Type	Description
aidinfo	Parameter type: <Alarm::AddInfoString> - additional alarm information	alarm AID parameters <i>This element is only shown in detail mode.</i>
type	Parameter type: <Alarm::alarmIHUBType> (equipment eqpt-holder plug-in-unit atm custom e1 ima-group ima-link redundancy shdsl ether-itf traffic-overflow qos-queue	type of the alarms that are active <i>This element is only shown in detail mode.</i>

name	Type	Description
	temporal	
	spatial	
	(software-mngt sw-mgmt)	
	xdsl	
	xdsl-ext	
	xdsl-tca	
	olt-gen	
	eo-conv	
	authentication	
	bonding	
	sfp	
	shdsl-isam	
	custom-ext-alarm	
	plug-in-unit-ext	
	sip-user-agent	
	sip-plugin-unit	
	sip-termination	
	e1-sip-termination	
	filetransfer	
	external-device	
	l2forward	
	ether-tca	
	ether-sfp	
	megaco-media-gw	
	megaco-sig-gw	
	megaco-plug-unit	
	megaco-term	
	megaco-sig-lt	
	eqpt-supplemental	
	eqpt-holder-ext	
	lsmredundancy	
	sync	
	mcsrc	
	vlanport	
	vect-line	
	vect-board	
	otdr	
	sip-dial-plan	
	sip-vsp	
	sip-server	
	bgp	
	rip	
	lag	
	ihub-general	
	vprn	
	isis	
	ospf	
	ihub-l2forward	
	vpls	
	ihub-equip	
	ihub-link	
	eont-phyoam	
	ellid	
	epon	
	eont-services-lan	
	eolt-ont-tca	
	eont-sw-dl	

101 query current alarms by filters

name	Type	Description
	ldp	
	mpls	
	sdp	
	epipe	
	ihub-ipv6	
	pim	
	li	
	mgmt-sec-access	
	bfd	
	ai	
	tr069serv	
	ontsnmp	
	bulk-sync	
	protection-group	
	ont	
	sfu-sup	
	soho-sup	
	mdu-sup	
	ont-ani	
	sfu-sup2	
	soho-sup2	
	mdu-sup2	
	sfprssi	
	eoltrssi	
	cfm	
	sfpe1t1-framer	
	sfpe1t1-clock	
	pppcc-engine-tca	
	eth-cfm	
	rsvp	
	ihub-tca	
	eth-ring	
	efm-oam	
	ont-loopdetect	
	ont-video	
	ont-ces	
	ont-voip	
	ont-video-ani	
	ont-pwe	
	ont-cese1	
	ont-xdsl	
	ont-xdsl-tca	
	ont-hpna	
	ont-sip-agent-cfg	
	ont-voip-cfg	
	ont-mgc	
	ont-ploam	
	ont-gen	
	ont-card	
	ont-pots	
	ont-lan	
	ont-moca	
	ont-tc-tca	
	ont-moca-tca	
	ont-l2uni-eth-tca	
	olt-pon-tc-tca	
	olt-pon-util-tca	

name	Type	Description
	olt-chpr-util-tca olt-ont-tc-tca ont-tca ont-pots-supplemental sfu-ploam sfu-gen soho-ploam soho-gen mdu-ploam mdu-gen ont-veip ont-iphost alarm-table auto-switch channel-pair ont-cfg-dld olt-chpair-tc-tca hgu-tr069 eqpt-psu ont-protection secondary-megaco-term secondary-sip-term cas-r2-channel lldpmed pseudo-wire link-agg fcs-exceed e1t1-interface) Possible values: - equipment : equipment alarms - eqpt-holder : equipment holder alarms - plug-in-unit : plugin unit alarms - atm : ATM alarms - custom : customizable alarms - e1 : e1 alarms - ima-group : ima-group alarms - ima-link : ima-link alarms - redundancy : redundancy alarms - shdsl : shdsl alarms - ether-itf : ethernet interface alarms - traffic-overflow : Traffic overflow alarms - qos-queue : qos queue alarms - temporal : temporal alarms - spatial : spatial alarms - software-mngt : software management alarms - sw-mgmt : software management alarms - xdsl : xDSL alarms - xdsl-ext : other xDSL alarms - xdsl-tca : xDSL threshold cross alarms - olt-gen : OLT general alarms - eo-conv : E/O conversion related alarms - authentication : authentication related alarms - bonding : bonding-group related alarms - sfp : SFP related alarms - shdsl-isam : shdsl isam alarms - custom-ext-alarm : customizable external alarms - plug-in-unit-ext : other plugin unit alarms	

101 query current alarms by filters

name	Type	Description
	- sip-user-agent : sip user agent related alarms - sip-plugin-unit : sip plug in unit related alarms - sip-termination : sip termination related alarms - e1-sip-termination : E1 sip termination related alarms - filetransfer : file transfer server alarms - external-device : external device related alarms - l2forward : l2forward related alarms - ether-tca : ethernet threshold cross alarms - ether-sfp : ethernet SFP related alarms - megaco-media-gw : megaco media gateway related alarms - megaco-sig-gw : megaco signaling gateway related alarms - megaco-plug-unit : megaco plug unit related alarms - megaco-term : megaco termination related alarms - megaco-sig-lt : megaco signaling lt related alarms - eqpt-supplemental : equipment supplemental alarms - eqpt-holder-ext : other equipment holder alarms - lsmredundancy : lsm redundancy alarms - sync : synce and bits alarms - mcsrc : multicast source alarms - vlanport : vlanport alarms - vect-line : xDSL vectoring line alarms - vect-board : xDSL vectoring board alarms - otdr : otdr alarms - sip-dial-plan : sip dial plan related alarms - sip-vsp : sip vsp related alarms - sip-server : sip server related alarms - bgp : bgp related alarms - rip : rip related alarms - lag : LAG related alarms - ihub-general : IHUB general related alarms - vprn : vprn related alarms - isis : isis related alarms - ospf : ospf related alarms - ihub-l2forward : ihub-l2forward alarms - vpls : vpls related alarms - ihub-equip : ihub-equip related alarms - ihub-link : ihub-link related alarms - eont-phyoam : eont phyoam related alarms - ellid : ellid related alarms - epon : epon related alarms - eont-services-lan : eon phyoam related alarms - eolt-ont-tca : eon phyoam related alarms - eont-sw-dl : eon phyoam related alarms - ldp : ldp related alarms - mpls : mpls related alarms - sdp : sdp related alarms - epipe : epipe related alarms - ihub-ipv6 : ihub-ipv6 related alarms - pim : pim related alarms - li : lawful intercept related alarms - mgmt-sec-access : management security related alarms - bfd : bfd related alarms - ai : Application Intelligence related alarms - tr069serv : tr069 server related alarms - ontsnmp : ont snmp related alarms - bulk-sync : bulk-sync related alarms - protection-group : port protection group related alarms	

name	Type	Description
	- ont : ONT general supplemental related alarms - sfu-sup : SFU ONT general supplemental related alarms - soho-sup : SOHO ONT general supplemental related alarms - mdu-sup : MDU ONT general supplemental related alarms - ont-ani : ONT general supplemental 2 related alarms - sfu-sup2 : SFU ONT general supplemental 2 related alarms - soho-sup2 : SOHO ONT general supplemental 2 related alarms - mdu-sup2 : MDU ONT general supplemental 2 related alarms - sfprssi : SFP RSSI related alarms - eoltrssi : epon olt Sfp RSSI related alarms - cfm : Cfm related alarms - sfpe1t1-framer : SFP 2e1t1 framer alarms - sfpe1t1-clock : SFP 2e1t1 clock alarms - pppcc-engine-tca : PPPOE Cross Connect Engine TCA related alarm - eth-cfm : eth-cfm related alarms - rsvp : rsvp related alarms - ihub-tca : IHUB TCA related alarms - eth-ring : eth-ring related alarms - efm-oam : EFM-OAM related alarms - ont-loopdetect : ont loop detect related alarms - ont-video : ont services video related alarms - ont-ces : ont services ces related alarms - ont-voip : ont services voip related alarms - ont-video-ani : ont services video ani related alarms - ont-pwe : ont services pwe related alarms - ont-cese1 : ont services cese1 related alarms - ont-xdsl : ont services xdsl related alarms - ont-xdsl-tca : ont services xdsl tca related alarms - ont-hpna : ont hpna related alarms - ont-sip-agent-cfg : ont services voip sip agent config related alarms - ont-voip-cfg : ont services voip config related alarms - ont-mgc : ont mgc related alarms - ont-ploam : ONT PLOAM related alarms - ont-gen : ONT GENERAL related alarms - ont-card : ONT Subscriber Card related alarms - ont-pots : ONT Services POTS related alarms - ont-lan : ONT Services LAN related alarms - ont-moca : ONT MoCA related alarms - ont-tc-tca : ONT TC TCA related alarms - ont-moca-tca : ONT MoCA TCA related alarms - ont-l2uni-eth-tca : ONT L2 UNI Ethernet TCA related alarms - olt-pon-tc-tca : OLT PON TC TCA related alarms - olt-pon-util-tca : OLT PON utilization TCA related alarms - olt-chpr-util-tca : OLT channel-pair utilization TCA related alarms - olt-ont-tc-tca : OLT ONT TC TCA related alarms - ont-tca : ONT TCA related alarms - ont-pots-supplemental : ONT POTS Supplemental related alarms - sfu-ploam : SFU ONT PLOAM related alarms - sfu-gen : SFU ONT general related alarms	

101 query current alarms by filters

name	Type	Description
	- soho-ploam : SOHO ONT PLOAM related alarms - soho-gen : SOHO ONT general related alarms - mdu-ploam : MDU ONT PLOAM related alarms - mdu-gen : MDU ONT general related alarms - ont-veip : ONT VEIP related alarms - ont-iphost : ONT IP HOST related alarms - alarm-table : alarm table related alarms - auto-switch : auto-switch related alarms - channel-pair : channel pair related alarms - ont-cfg-dld : ont configure file download related alarms - olt-chpair-tc-tca : OLT CHANNELPAIR TC TCA related alarms - hgu-tr069 : hgu tr069 related alarms - eqpt-psu : equipment psu alarms - ont-protection : ONT protection related alarms - secondary-megaco-term : secondary megaco termination related alarms - secondary-sip-term : secondary sip termination related alarms - cas-r2-channel : CAS R2 channel related alarms - lldpmed : lldpmed alarms - pseudo-wire : pseudo Wire related alarms - link-agg : Link aggregation related alarms - fcs-exceed : FCS auto-recovery related alarms - e1t1-interface : E1/T1 physical interfaces related alarms	
name	Parameter type: <Alarm::alarmTypeOntvideoanihub> (ont-svc-v-ani-conf-mis ont-svc-v-ani-loss-sig ont-svc-v-ani-lv-high ont-svc-v-ani-lv-low all) Possible values: - ont-svc-v-ani-conf-mis: config request failure for video ani service - ont-svc-v-ani-loss-sig: video loss of signal on ani - ont-svc-v-ani-lv-high : high video optical signal level - ont-svc-v-ani-lv-low : low video optical signal level - all : ont services video ani related alarms	alarm name that are active <i>This element is only shown in detail mode.</i>
severity	Parameter type: <Alarm::AlarmSeverity> (indeterminate warning minor major critical) Possible values: - indeterminate : alarm severity is indeterminate - warning : alarm severity is warning - minor : alarm severity is minor - major : alarm severity is major - critical : alarm severity is critical	the alarms severity level <i>This element is only shown in detail mode.</i>
servaff	Parameter type: <Alarm::alarmServAffect> ((service-affecting yes) (noservice-affecting no)) Possible values: - service-affecting : make this alarm service affecting - yes : make this alarm service affecting - noservice-affecting : make this alarm not service affecting	alarms affect service or not <i>This element is only shown in detail mode.</i>

101 query current alarms by filters

name	Type	Description
	- no : make this alarm not service affecting	
time	Parameter type: <Sys::timeInSecs> - the time (yyyy-mm-dd:hour:minutes:secs) - unit: UTC	time in seconds when alarm was updated <i>This element is only shown in detail mode.</i>
descript	Parameter type: <Alarm::AddInfoString> - additional alarm information	alarm description <i>This element is only shown in detail mode.</i>

101.67 show current alarm by filters

Command Description

show current alarms by filters

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm query ont-ani [ (name) [ severity <Alarm::querySeverity> ] [ servaff <Alarm::queryServAffect> ] [ ont <Gpon::OntIndex> ] ]
```

Command Parameters

Table 101.67-1 "show current alarm by filters" Resource Parameters

Resource Identifier	Type	Description
(name)	Format: (ont-gen-temp-low ont-gen-volt-low ont-gen-tx-pwr-high ont-gen-bias-low ont-gen-rx-hwarn ont-gen-rx-lwarn ont-gen-tx-hwarn ont-gen-tx-lwarn ont-gen-temp-hwarn ont-gen-temp-lwarn ont-gen-volt-hwarn ont-gen-volt-lwarn ont-gen-bias-hwarn ont-gen-bias-lwarn all) Possible values: - ont-gen-temp-low : ONU SFP temperature is lower than configured Alarm low threshold - ont-gen-volt-low : ONU SFP Voltage is lower than configured Alarm low threshold - ont-gen-tx-pwr-high : ONU SFP Tx power is higher than configured Alarm high threshold - ont-gen-bias-low : ONU SFP bias is lower than configured Alarm low threshold - ont-gen-rx-hwarn : ONU SFP Rx power is higher than warn threshold - ont-gen-rx-lwarn : ONU SFP Rx power is lower than warn	alarm name of ont ani

Resource Identifier	Type	Description
	threshold - ont-gen-tx-hwarn : ONU SFP Tx power is higher than warn threshold - ont-gen-tx-lwarn : ONU SFP Tx power is lower than warn threshold - ont-gen-temp-hwarn : ONU SFP temperature is higher than warn threshold - ont-gen-temp-lwarn : ONU SFP temperature is lower than warn threshold - ont-gen-volt-hwarn : ONU SFP Voltage is higher than warn threshold - ont-gen-volt-lwarn : ONU SFP Voltage is lower than warn threshold - ont-gen-bias-hwarn : ONU SFP bias is higher than warn threshold - ont-gen-bias-lwarn : ONU SFP bias is lower than warn threshold - all : ont services video ani related alarms	
severity	Parameter type: <Alarm::querySeverity> Format: (indeterminate warning minor major critical all) Possible values: - indeterminate : alarm severity is indeterminate - warning : alarm severity is warning - minor : alarm severity is minor - major : alarm severity is major - critical : alarm severity is critical - all : all alarm severity	severity level of an alarm for reporting
servaff	Parameter type: <Alarm::queryServAffect> Format: (service-affecting noservice-affecting all) Possible values: - service-affecting : query alarm service affecting - noservice-affecting : query alarm not service affecting - all : query service affecting and not affecting alarms	serviceaffecting no serviceaffecting
ont	Parameter type: <Gpon::OntIndex> Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> ng2 : <Ng2::ChannelGroup> / <Ng2::SubchannelGroup> / <Ng2::OntId>) Possible values: - ng2 : ngpon2 style identification Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId>	gpon ont equipment ifindex of ont

Resource Identifier	Type	Description
	- the PON identifier Field type <Ng2::ChannelGroup> - channel group number Field type <Ng2::SubchannelGroup> - subchannel group number Field type <Eqpt::OntId> - the ONT identifier Field type <Ng2::OntId> - the ONT identifier	

Command Output

Table 101.67-2 "show current alarm by filters" Display parameters

Specific Information		
name	Type	Description
aidinfo	Parameter type: <Alarm::AddInfoString> - additional alarm information	alarm AID parameters <i>This element is only shown in detail mode.</i>
type	Parameter type: <Alarm::alarmIHUBType> (equipment eqpt-holder plug-in-unit atm custom e1 ima-group ima-link redundancy shdsl ether-itf traffic-overflow qos-queue temporal spatial (software-mngt sw-mgmt) xdsl xdsl-ext xdsl-tca olt-gen eo-conv authentication bonding sfp shdsl-isam custom-ext-alarm plug-in-unit-ext sip-user-agent sip-plugin-unit sip-termination e1-sip-termination filetransfer external-device l2forward ether-tca ether-sfp megaco-media-gw)	type of the alarms that are active <i>This element is only shown in detail mode.</i>

name	Type	Description
	megaco-sig-gw	
	megaco-plug-unit	
	megaco-term	
	megaco-sig-lt	
	eqpt-supplemental	
	eqpt-holder-ext	
	lsmredundancy	
	sync	
	mcsrc	
	vlanport	
	vect-line	
	vect-board	
	otdr	
	sip-dial-plan	
	sip-vsp	
	sip-server	
	bgp	
	rip	
	lag	
	ihub-general	
	vprn	
	isis	
	ospf	
	ihub-l2forward	
	vpls	
	ihub-equip	
	ihub-link	
	eont-phyoam	
	ellid	
	epon	
	eont-services-lan	
	eolt-ont-tca	
	eont-sw-dl	
	ldp	
	mpls	
	sdp	
	epipe	
	ihub-ipv6	
	pim	
	li	
	mgmt-sec-access	
	bfd	
	ai	
	tr069serv	
	ontsnmp	
	bulk-sync	
	protection-group	
	ont	
	sfu-sup	
	soho-sup	
	mdu-sup	
	ont-ani	
	sfu-sup2	
	soho-sup2	
	mdu-sup2	
	sfprssi	
	eoltrssi	

101 query current alarms by filters

name	Type	Description
	cfm sfpe1t1-framer sfpe1t1-clock pppcc-engine-tca eth-cfm rsvp ihub-tca eth-ring efm-oam ont-loopdetect ont-video ont-ces ont-voip ont-video-ani ont-pwe ont-cese1 ont-xdsl ont-xdsl-tca ont-hpna ont-sip-agent-cfg ont-voip-cfg ont-mgc ont-ploam ont-gen ont-card ont-pots ont-lan ont-moca ont-tc-tca ont-moca-tca ont-l2uni-eth-tca olt-pon-tc-tca olt-pon-util-tca olt-chpr-util-tca olt-ont-tc-tca ont-tca ont-pots-supplemental sfu-ploam sfu-gen soho-ploam soho-gen mdu-ploam mdu-gen ont-veip ont-iphost alarm-table auto-switch channel-pair ont-cfg-dld olt-chpair-tc-tca hgu-tr069 eqpt-psu ont-protection secondary-megaco-term secondary-sip-term cas-r2-channel lldpmed	

name	Type	Description
	pseudo-wire link-agg fcs-exceed e1t1-interface) Possible values: - equipment : equipment alarms - eqpt-holder : equipment holder alarms - plug-in-unit : plugin unit alarms - atm : ATM alarms - custom : customizable alarms - e1 : e1 alarms - ima-group : ima-group alarms - ima-link : ima-link alarms - redundancy : redundancy alarms - shdsl : shdsl alarms - ether-itf : ethernet interface alarms - traffic-overflow : Traffic overflow alarms - qos-queue : qos queue alarms - temporal : temporal alarms - spatial : spatial alarms - software-mngt : software management alarms - sw-mgmt : software management alarms - xdsl : xDSL alarms - xdsl-ext : other xDSL alarms - xdsl-tca : xDSL threshold cross alarms - olt-gen : OLT general alarms - eo-conv : E/O conversion related alarms - authentication : authentication related alarms - bonding : bonding-group related alarms - sfp : SFP related alarms - shdsl-isam : shdsl isam alarms - custom-ext-alarm : customizable external alarms - plug-in-unit-ext : other plugin unit alarms - sip-user-agent : sip user agent related alarms - sip-plugin-unit : sip plug in unit related alarms - sip-termination : sip termination related alarms - e1-sip-termination : E1 sip termination related alarms - filetransfer : file transfer server alarms - external-device : external device related alarms - l2forward : l2forward related alarms - ether-tca : ethernet threshold cross alarms - ether-sfp : ethernet SFP related alarms - megaco-media-gw : megaco media gateway related alarms - megaco-sig-gw : megaco signaling gateway related alarms - megaco-plug-unit : megaco plug unit related alarms - megaco-term : megaco termination related alarms - megaco-sig-lt : megaco signaling lt related alarms - eqpt-supplemental : equipment supplemental alarms - eqpt-holder-ext : other equipment holder alarms - lsmredundancy : lsm redundancy alarms - sync : synce and bits alarms - mcsrc : multicast source alarms - vlanport : vlanport alarms - vect-line : xDSL vectoring line alarms - vect-board : xDSL vectoring board alarms - otdr : otdr alarms - sip-dial-plan : sip dial plan related alarms	

101 query current alarms by filters

name	Type	Description
	- sip-vsp : sip vsp related alarms - sip-server : sip server related alarms - bgp : bgp related alarms - rip : rip related alarms - lag : LAG related alarms - ihub-general : IHUB general related alarms - vprn : vprn related alarms - isis : isis related alarms - ospf : ospf related alarms - ihub-l2forward : ihub-l2forward alarms - vpls : vpls related alarms - ihub-equip : ihub-equip related alarms - ihub-link : ihub-link related alarms - eont-phyoam : eont phyoam related alarms - ellid : ellid related alarms - epon : epon related alarms - eont-services-lan : eon phyoam related alarms - eolt-ont-tca : eon phyoam related alarms - eont-sw-dl : eon phyoam related alarms - ldp : ldp related alarms - mpls : mpls related alarms - sdp : sdp related alarms - epipe : epipe related alarms - ihub-ipv6 : ihub-ipv6 related alarms - pim : pim related alarms - li : lawful intercept related alarms - mgmt-sec-access : management security related alarms - bfd : bfd related alarms - ai : Application Intelligence related alarms - tr069serv : tr069 server related alarms - ontsnmp : ont snmp related alarms - bulk-sync : bulk-sync related alarms - protection-group : port protection group related alarms - ont : ONT general supplemental related alarms - sfu-sup : SFU ONT general supplemental related alarms - soho-sup : SOHO ONT general supplemental related alarms - mdu-sup : MDU ONT general supplemental related alarms - ont-ani : ONT general supplemental 2 related alarms - sfu-sup2 : SFU ONT general supplemental 2 related alarms - soho-sup2 : SOHO ONT general supplemental 2 related alarms - mdu-sup2 : MDU ONT general supplemental 2 related alarms - sfprssi : SFP RSSI related alarms - eoltrssi : epon olt Sfp RSSI related alarms - cfm : Cfm related alarms - sfpe1t1-framer : SFP 2e1t1 framer alarms - sfpe1t1-clock : SFP 2e1t1 clock alarms - pppcc-engine-tca : PPPOE Cross Connect Engine TCA related alarm - eth-cfm : eth-cfm related alarms - rsvp : rsvp related alarms - ihub-tca : IHUB TCA related alarms - eth-ring : eth-ring related alarms - efm-oam : EFM-OAM related alarms - ont-loopdetect : ont loop detect related alarms	

name	Type	Description
	- ont-video : ont services video related alarms - ont-ces : ont services ces related alarms - ont-voip : ont services voip related alarms - ont-video-ani : ont services video ani related alarms - ont-pwe : ont services pwe related alarms - ont-cese1 : ont services cese1 related alarms - ont-xdsl : ont services xdsl related alarms - ont-xdsl-tca : ont services xdsl tca related alarms - ont-hpna : ont hpna related alarms - ont-sip-agent-cfg : ont services voip sip agent config related alarms - ont-voip-cfg : ont services voip config related alarms - ont-mgc : ont mgc related alarms - ont-ploam : ONT PLOAM related alarms - ont-gen : ONT GENERAL related alarms - ont-card : ONT Subscriber Card related alarms - ont-pots : ONT Services POTS related alarms - ont-lan : ONT Services LAN related alarms - ont-moca : ONT MoCA related alarms - ont-tc-tca : ONT TC TCA related alarms - ont-moca-tca : ONT MoCA TCA related alarms - ont-l2uni-eth-tca : ONT L2 UNI Ethernet TCA related alarms - olt-pon-tc-tca : OLT PON TC TCA related alarms - olt-pon-util-tca : OLT PON utilization TCA related alarms - olt-chpr-util-tca : OLT channel-pair utilization TCA related alarms - olt-ont-tc-tca : OLT ONT TC TCA related alarms - ont-tca : ONT TCA related alarms - ont-pots-supplemental : ONT POTS Supplemental related alarms - sfu-ploam : SFU ONT PLOAM related alarms - sfu-gen : SFU ONT general related alarms - soho-ploam : SOHO ONT PLOAM related alarms - soho-gen : SOHO ONT general related alarms - mdu-ploam : MDU ONT PLOAM related alarms - mdu-gen : MDU ONT general related alarms - ont-veip : ONT VEIP related alarms - ont-iphost : ONT IP HOST related alarms - alarm-table : alarm table related alarms - auto-switch : auto-switch related alarms - channel-pair : channel pair related alarms - ont-cfg-dld : ont configure file download related alarms - olt-chpair-tc-tca : OLT CHANNELPAIR TC TCA related alarms - hgu-tr069 : hgu tr069 related alarms - eqpt-psu : equipment psu alarms - ont-protection : ONT protection related alarms - secondary-megaco-term : secondary megaco termination related alarms - secondary-sip-term : secondary sip termination related alarms - cas-r2-channel : CAS R2 channel related alarms - lldpmed : lldpmed alarms - pseudo-wire : pseudo Wire related alarms - link-agg : Link aggregation related alarms - fcs-exceed : FCS auto-recovery related alarms	

101 query current alarms by filters

name	Type	Description
	- e1t1-interface : E1/T1 physical interfaces related alarms	
name	Parameter type: <Alarm::alarmTypeOntaniihub> (ont-gen-temp-low ont-gen-volt-low ont-gen-tx-pwr-high ont-gen-bias-low ont-gen-rx-hwarn ont-gen-rx-lwarn ont-gen-tx-hwarn ont-gen-tx-lwarn ont-gen-temp-hwarn ont-gen-temp-lwarn ont-gen-volt-hwarn ont-gen-volt-lwarn ont-gen-bias-hwarn ont-gen-bias-lwarn all) Possible values: - ont-gen-temp-low : ONU SFP temperature is lower than configured Alarm low threshold - ont-gen-volt-low : ONU SFP Voltage is lower than configured Alarm low threshold - ont-gen-tx-pwr-high : ONU SFP Tx power is higher than configured Alarm high threshold - ont-gen-bias-low : ONU SFP bias is lower than configured Alarm low threshold - ont-gen-rx-hwarn : ONU SFP Rx power is higher than warn threshold - ont-gen-rx-lwarn : ONU SFP Rx power is lower than warn threshold - ont-gen-tx-hwarn : ONU SFP Tx power is higher than warn threshold - ont-gen-tx-lwarn : ONU SFP Tx power is lower than warn threshold - ont-gen-temp-hwarn : ONU SFP temperature is higher than warn threshold - ont-gen-temp-lwarn : ONU SFP temperature is lower than warn threshold - ont-gen-volt-hwarn : ONU SFP Voltage is higher than warn threshold - ont-gen-volt-lwarn : ONU SFP Voltage is lower than warn threshold - ont-gen-bias-hwarn : ONU SFP bias is higher than warn threshold - ont-gen-bias-lwarn : ONU SFP bias is lower than warn threshold - all : ont services video ani related alarms	alarm name that are active <i>This element is only shown in detail mode.</i>
severity	Parameter type: <Alarm::AlarmSeverity> (indeterminate warning minor major critical) Possible values: - indeterminate : alarm severity is indeterminate - warning : alarm severity is warning - minor : alarm severity is minor	the alarms severity level <i>This element is only shown in detail mode.</i>

name	Type	Description
	- major : alarm severity is major - critical : alarm severity is critical	
servaff	Parameter type: <Alarm::alarmServAffect> ((service-affecting yes) (noservice-affecting no)) Possible values: - service-affecting : make this alarm service affecting - yes : make this alarm service affecting - noservice-affecting : make this alarm not service affecting - no : make this alarm not service affecting	alarms affect service or not <i>This element is only shown in detail mode.</i>
time	Parameter type: <Sys::timeInSecs> - the time (yyyy-mm-dd:hour:minutes:secs) - unit: UTC	time in seconds when alarm was updated <i>This element is only shown in detail mode.</i>
descript	Parameter type: <Alarm::AddInfoString> - additional alarm information	alarm description <i>This element is only shown in detail mode.</i>

101.68 show current alarm by filters

Command Description

show current alarms by filters

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm query ont-moca [ (name) [ severity <Alarm::querySeverity> ] [ servaff <Alarm::queryServAffect> ] [
uni-index <Alarm::queryDefaultAid> ] ]
```

Command Parameters

Table 101.68-1 "show current alarm by filters" Resource Parameters

Resource Identifier	Type	Description
(name)	Format: (ont-moca-svc-mis ont-moca-link-los ont-moca-min-bw all) Possible values: - ont-moca-svc-mis : moca ont service mismatch - ont-moca-link-los : moca loss of link - ont-moca-min-bw : moca bw between nodes less than minimum bw - all : ONT MoCA related alarms	alarm name of ont moca
severity	Parameter type: <Alarm::querySeverity> Format: (indeterminate warning minor major critical all) Possible values: - indeterminate : alarm severity is indeterminate - warning : alarm severity is warning - minor : alarm severity is minor - major : alarm severity is major - critical : alarm severity is critical - all : all alarm severity	severity level of an alarm for reporting
servaff	Parameter type: <Alarm::queryServAffect> Format:	serviceaffecting no

Resource Identifier	Type	Description
	(service-affecting noservice-affecting all) Possible values: - service-affecting : query alarm service affecting - noservice-affecting : query alarm not service affecting - all : query service affecting and not affecting alarms	
uni-index	Parameter type: <Alarm::queryDefaultAid> Format: all Possible values: - all : default AID parameter	all ont port

Command Output

Table 101.68-2 "show current alarm by filters" Display parameters

Specific Information		
name	Type	Description
aidinfo	Parameter type: <Alarm::AddInfoString> - additional alarm information	alarm AID parameters <i>This element is only shown in detail mode.</i>
type	Parameter type: <Alarm::alarmIHUBType> (equipment eqpt-holder plug-in-unit atm custom e1 ima-group ima-link redundancy shdsl ether-itf traffic-overflow qos-queue temporal spatial (software-mngt sw-mgmt) xdsl xdsl-ext xdsl-tca olt-gen eo-conv authentication bonding sfp shdsl-isam custom-ext-alarm plug-in-unit-ext sip-user-agent sip-plugin-unit sip-termination e1-sip-termination filetransfer external-device l2forward	type of the alarms that are active <i>This element is only shown in detail mode.</i>

101 query current alarms by filters

name	Type	Description
	ether-tca	
	ether-sfp	
	megaco-media-gw	
	megaco-sig-gw	
	megaco-plug-unit	
	megaco-term	
	megaco-sig-lt	
	eqpt-supplemental	
	eqpt-holder-ext	
	lsmredundancy	
	sync	
	mcsrc	
	vlanport	
	vect-line	
	vect-board	
	otdr	
	sip-dial-plan	
	sip-vsp	
	sip-server	
	bgp	
	rip	
	lag	
	ihub-general	
	vprn	
	isis	
	ospf	
	ihub-l2forward	
	vppls	
	ihub-equip	
	ihub-link	
	eont-phyoam	
	ellid	
	epon	
	eont-services-lan	
	eolt-ont-tca	
	eont-sw-dl	
	ldp	
	mpls	
	sdp	
	epipe	
	ihub-ipv6	
	pim	
	li	
	mgmt-sec-access	
	bfd	
	ai	
	tr069serv	
	ontsnmp	
	bulk-sync	
	protection-group	
	ont	
	sfu-sup	
	soho-sup	
	mdu-sup	
	ont-ani	
	sfu-sup2	
	soho-sup2	

name	Type	Description
	mdu-sup2 sfprssi eoltrssi cfm sfpe1t1-framer sfpe1t1-clock pppcc-engine-tca eth-cfm rsvp ihub-tca eth-ring efm-oam ont-loopdetect ont-video ont-ces ont-voip ont-video-ani ont-pwe ont-cese1 ont-xdsl ont-xdsl-tca ont-hpna ont-sip-agent-cfg ont-voip-cfg ont-mgc ont-ploam ont-gen ont-card ont-pots ont-lan ont-moca ont-tc-tca ont-moca-tca ont-l2uni-eth-tca olt-pon-tc-tca olt-pon-util-tca olt-chpr-util-tca olt-ont-tc-tca ont-tca ont-pots-supplemental sfu-ploam sfu-gen soho-ploam soho-gen mdu-ploam mdu-gen ont-veip ont-iphost alarm-table auto-switch channel-pair ont-cfg-dld olt-chpair-tc-tca hgu-tr069 eqpt-psu ont-protection secondary-megaco-term	

101 query current alarms by filters

name	Type	Description
	secondary-sip-term cas-r2-channel lldpmed pseudo-wire link-agg fcs-exceed e1t1-interface) Possible values: - equipment : equipment alarms - eqpt-holder : equipment holder alarms - plug-in-unit : plugin unit alarms - atm : ATM alarms - custom : customizable alarms - e1 : e1 alarms - ima-group : ima-group alarms - ima-link : ima-link alarms - redundancy : redundancy alarms - shdsl : shdsl alarms - ether-itf : ethernet interface alarms - traffic-overflow : Traffic overflow alarms - qos-queue : qos queue alarms - temporal : temporal alarms - spatial : spatial alarms - software-mngt : software management alarms - sw-mgmt : software management alarms - xdsl : xDSL alarms - xdsl-ext : other xDSL alarms - xdsl-tca : xDSL threshold cross alarms - olt-gen : OLT general alarms - eo-conv : E/O conversion related alarms - authentication : authentication related alarms - bonding : bonding-group related alarms - sfp : SFP related alarms - shdsl-isam : shdsl isam alarms - custom-ext-alarm : customizable external alarms - plug-in-unit-ext : other plugin unit alarms - sip-user-agent : sip user agent related alarms - sip-plugin-unit : sip plug in unit related alarms - sip-termination : sip termination related alarms - e1-sip-termination : E1 sip termination related alarms - filetransfer : file transfer server alarms - external-device : external device related alarms - l2forward : l2forward related alarms - ether-tca : ethernet threshold cross alarms - ether-sfp : ethernet SFP related alarms - megaco-media-gw : megaco media gateway related alarms - megaco-sig-gw : megaco signaling gateway related alarms - megaco-plug-unit : megaco plug unit related alarms - megaco-term : megaco termination related alarms - megaco-sig-lt : megaco signaling lt related alarms - eqpt-supplemental : equipment supplemental alarms - eqpt-holder-ext : other equipment holder alarms - lsmredundancy : lsm redundancy alarms - sync : synce and bits alarms - mcsrc : multicast source alarms - vlanport : vlanport alarms - vect-line : xDSL vectoring line alarms	

name	Type	Description
	- vect-board : xDSL vectoring board alarms - otdr : otdr alarms - sip-dial-plan : sip dial plan related alarms - sip-vsp : sip vsp related alarms - sip-server : sip server related alarms - bgp : bgp related alarms - rip : rip related alarms - lag : LAG related alarms - ihub-general : IHUB general related alarms - vprn : vprn related alarms - isis : isis related alarms - ospf : ospf related alarms - ihub-l2forward : ihub-l2forward alarms - vpls : vpls related alarms - ihub-equip : ihub-equip related alarms - ihub-link : ihub-link related alarms - eont-phyoam : eont phyoam related alarms - ellid : ellid related alarms - epon : epon related alarms - eont-services-lan : eon phyoam related alarms - eolt-ont-tca : eon phyoam related alarms - eont-sw-dl : eon phyoam related alarms - ldp : ldp related alarms - mpls : mpls related alarms - sdp : sdp related alarms - epipe : epipe related alarms - ihub-ipv6 : ihub-ipv6 related alarms - pim : pim related alarms - li : lawful intercept related alarms - mgmt-sec-access : management security related alarms - bfd : bfd related alarms - ai : Application Intelligence related alarms - tr069serv : tr069 server related alarms - ontsnmp : ont snmp related alarms - bulk-sync : bulk-sync related alarms - protection-group : port protection group related alarms - ont : ONT general supplemental related alarms - sfu-sup : SFU ONT general supplemental related alarms - soho-sup : SOHO ONT general supplemental related alarms - mdu-sup : MDU ONT general supplemental related alarms - ont-ani : ONT general supplemental 2 related alarms - sfu-sup2 : SFU ONT general supplemental 2 related alarms - soho-sup2 : SOHO ONT general supplemental 2 related alarms - mdu-sup2 : MDU ONT general supplemental 2 related alarms - sfprssi : SFP RSSI related alarms - eoltrssi : epon olt Sfp RSSI related alarms - cfm : Cfm related alarms - sfpe1t1-framer : SFP 2e1t1 framer alarms - sfpe1t1-clock : SFP 2e1t1 clock alarms - pppcc-engine-tca : PPPOE Cross Connect Engine TCA related alarm - eth-cfm : eth-cfm related alarms - rsvp : rsvp related alarms - ihub-tca : IHUB TCA related alarms	

101 query current alarms by filters

name	Type	Description
	- eth-ring : eth-ring related alarms - efm-oam : EFM-OAM related alarms - ont-loopdetect : ont loop detect related alarms - ont-video : ont services video related alarms - ont-ces : ont services ces related alarms - ont-voip : ont services voip related alarms - ont-video-ani : ont services video ani related alarms - ont-pwe : ont services pwe related alarms - ont-cese1 : ont services cese1 related alarms - ont-xdsl : ont services xdsl related alarms - ont-xdsl-tca : ont services xdsl tca related alarms - ont-hpna : ont hpna related alarms - ont-sip-agent-cfg : ont services voip sip agent config related alarms - ont-voip-cfg : ont services voip config related alarms - ont-mgc : ont mgc related alarms - ont-ploam : ONT PLOAM related alarms - ont-gen : ONT GENERAL related alarms - ont-card : ONT Subscriber Card related alarms - ont-pots : ONT Services POTS related alarms - ont-lan : ONT Services LAN related alarms - ont-moca : ONT MoCA related alarms - ont-tc-tca : ONT TC TCA related alarms - ont-moca-tca : ONT MoCA TCA related alarms - ont-l2uni-eth-tca : ONT L2 UNI Ethernet TCA related alarms - olt-pon-tc-tca : OLT PON TC TCA related alarms - olt-pon-util-tca : OLT PON utilization TCA related alarms - olt-chpr-util-tca : OLT channel-pair utilization TCA related alarms - olt-ont-tc-tca : OLT ONT TC TCA related alarms - ont-tca : ONT TCA related alarms - ont-pots-supplemental : ONT POTS Supplemental related alarms - sfu-ploam : SFU ONT PLOAM related alarms - sfu-gen : SFU ONT general related alarms - soho-ploam : SOHO ONT PLOAM related alarms - soho-gen : SOHO ONT general related alarms - mdu-ploam : MDU ONT PLOAM related alarms - mdu-gen : MDU ONT general related alarms - ont-veip : ONT VEIP related alarms - ont-iphost : ONT IP HOST related alarms - alarm-table : alarm table related alarms - auto-switch : auto-switch related alarms - channel-pair : channel pair related alarms - ont-cfg-dld : ont configure file download related alarms - olt-chpair-tc-tca : OLT CHANNELPAIR TC TCA related alarms - hgu-tr069 : hgu tr069 related alarms - eqpt-psu : equipment psu alarms - ont-protection : ONT protection related alarms - secondary-megaco-term : secondary megaco termination related alarms - secondary-sip-term : secondary sip termination related alarms - cas-r2-channel : CAS R2 channel related alarms - lldpmed : lldpmed alarms	

name	Type	Description
	- pseudo-wire : pseudo Wire related alarms - link-aggr : Link aggregation related alarms - fcs-exceed : FCS auto-recovery related alarms - e1t1-interface : E1/T1 physical interfaces related alarms	
name	Parameter type: <Alarm::alarmTypeOntmocaHub> (ont-moca-svc-mis ont-moca-link-los ont-moca-min-bw all) Possible values: - ont-moca-svc-mis : moca ont service mismatch - ont-moca-link-los : moca loss of link - ont-moca-min-bw : moca bw between nodes less than minimum bw - all : ONT MoCA related alarms	alarm name that are active <i>This element is only shown in detail mode.</i>
severity	Parameter type: <Alarm::AlarmSeverity> (indeterminate warning minor major critical) Possible values: - indeterminate : alarm severity is indeterminate - warning : alarm severity is warning - minor : alarm severity is minor - major : alarm severity is major - critical : alarm severity is critical	the alarms severity level <i>This element is only shown in detail mode.</i>
servaff	Parameter type: <Alarm::alarmServAffect> ((service-affecting yes) (noservice-affecting no)) Possible values: - service-affecting : make this alarm service affecting - yes : make this alarm service affecting - noservice-affecting : make this alarm not service affecting - no : make this alarm not service affecting	alarms affect service or not <i>This element is only shown in detail mode.</i>
time	Parameter type: <Sys::timeInSecs> - the time (yyyy-mm-dd:hour:minutes:secs) - unit: UTC	time in seconds when alarm was updated <i>This element is only shown in detail mode.</i>
descript	Parameter type: <Alarm::AddInfoString> - additional alarm information	alarm description <i>This element is only shown in detail mode.</i>

101.69 show current alarm by filters

Command Description

show current alarms by filters

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm query ont-tc-tca [ (name) [ severity <Alarm::querySeverity> ] [ servaff <Alarm::queryServAffect> ] [ ont <Gpon::OntIndex> ] ]
```

Command Parameters

Table 101.69-1 "show current alarm by filters" Resource Parameters

Resource Identifier	Type	Description
(name)	Format: (ont-tc-rx-los-frag-tc ont-tc-tx-los-frag-tc ont-tc-bad-gem-hd-tc all) Possible values: - ont-tc-rx-los-frag-tc : rx loss of gem fragments threshold crossed - ont-tc-tx-los-frag-tc : tx loss of gem fragments threshold crossed - ont-tc-bad-gem-hd-tc : bad gem header threshold crossed - all : ONT TC TCA related alarms	alarm name of ont tc tca
severity	Parameter type: <Alarm::querySeverity> Format: (indeterminate warning minor major critical all) Possible values: - indeterminate : alarm severity is indeterminate - warning : alarm severity is warning - minor : alarm severity is minor - major : alarm severity is major - critical : alarm severity is critical - all : all alarm severity	severity level of an alarm for reporting
servaff	Parameter type: <Alarm::queryServAffect>	serviceaffecting no

Resource Identifier	Type	Description
	Format: (service-affecting noservice-affecting all) Possible values: - service-affecting : query alarm service affecting - noservice-affecting : query alarm not service affecting - all : query service affecting and not affecting alarms	serviceaffecting
ont	Parameter type: <Gpon::OntIndex> Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> ng2 : <Ng2::ChannelGroup> / <Ng2::SubchannelGroup> / <Ng2::OntId>) Possible values: - ng2 : ngpon2 style identification Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Ng2::ChannelGroup> - channel group number Field type <Ng2::SubchannelGroup> - subchannel group number Field type <Eqpt::OntId> - the ONT identifier Field type <Ng2::OntId> - the ONT identifier	gpon ont equipment ifindex of ont

Command Output

Table 101.69-2 "show current alarm by filters" Display parameters

Specific Information		
name	Type	Description
aidinfo	Parameter type: <Alarm::AddInfoString> - additional alarm information	alarm AID parameters <i>This element is only shown in detail mode.</i>
type	Parameter type: <Alarm::alarmIHUBType> (equipment eqpt-holder plug-in-unit atm custom e1 ima-group ima-link redundancy shdsl ether-itf traffic-overflow qos-queue temporal	type of the alarms that are active <i>This element is only shown in detail mode.</i>

101 query current alarms by filters

name	Type	Description
	spatial (software-mngt sw-mgmt) xdsl xdsl-ext xdsl-tca olt-gen eo-conv authentication bonding sfp shdsl-isam custom-ext-alarm plug-in-unit-ext sip-user-agent sip-plugin-unit sip-termination e1-sip-termination filetransfer external-device l2forward ether-tca ether-sfp megaco-media-gw megaco-sig-gw megaco-plug-unit megaco-term megaco-sig-lt eqpt-supplemental eqpt-holder-ext lsmredundancy sync mcsrc vlanport vect-line vect-board otdr sip-dial-plan sip-vsp sip-server bgp rip lag ihub-general vprn isis ospf ihub-l2forward vpls ihub-equip ihub-link eont-phyoam ellid epon eont-services-lan eolt-ont-tca eont-sw-dl ldp	

name	Type	Description
	mpls	
	sdp	
	epipe	
	ihub-ipv6	
	pim	
	li	
	mgmt-sec-access	
	bfd	
	ai	
	tr069serv	
	ontsnmp	
	bulk-sync	
	protection-group	
	ont	
	sfu-sup	
	soho-sup	
	mdu-sup	
	ont-ani	
	sfu-sup2	
	soho-sup2	
	mdu-sup2	
	sfprssi	
	eoltrssi	
	cfm	
	sfpe1t1-framer	
	sfpe1t1-clock	
	pppcc-engine-tca	
	eth-cfm	
	rsvp	
	ihub-tca	
	eth-ring	
	efm-oam	
	ont-loopdetect	
	ont-video	
	ont-ces	
	ont-voip	
	ont-video-ani	
	ont-pwe	
	ont-cese1	
	ont-xdsl	
	ont-xdsl-tca	
	ont-hpna	
	ont-sip-agent-cfg	
	ont-voip-cfg	
	ont-mgc	
	ont-ploam	
	ont-gen	
	ont-card	
	ont-pots	
	ont-lan	
	ont-moca	
	ont-tc-tca	
	ont-moca-tca	
	ont-l2uni-eth-tca	
	olt-pon-tc-tca	
	olt-pon-util-tca	
	olt-chpr-util-tca	

101 query current alarms by filters

name	Type	Description
	olt-ont-tc-tca ont-tca ont-pots-supplemental sfu-ploam sfu-gen soho-ploam soho-gen mdu-ploam mdu-gen ont-veip ont-iphost alarm-table auto-switch channel-pair ont-cfg-dld olt-chpair-tc-tca hgu-tr069 eqpt-psu ont-protection secondary-megaco-term secondary-sip-term cas-r2-channel lldpmed pseudo-wire link-agg fcs-exceed e1t1-interface) Possible values: - equipment : equipment alarms - eqpt-holder : equipment holder alarms - plug-in-unit : plugin unit alarms - atm : ATM alarms - custom : customizable alarms - e1 : e1 alarms - ima-group : ima-group alarms - ima-link : ima-link alarms - redundancy : redundancy alarms - shdsl : shdsl alarms - ether-itf : ethernet interface alarms - traffic-overflow : Traffic overflow alarms - qos-queue : qos queue alarms - temporal : temporal alarms - spatial : spatial alarms - software-mngt : software management alarms - sw-mgmt : software management alarms - xdsl : xDSL alarms - xdsl-ext : other xDSL alarms - xdsl-tca : xDSL threshold cross alarms - olt-gen : OLT general alarms - eo-conv : E/O conversion related alarms - authentication : authentication related alarms - bonding : bonding-group related alarms - sfp : SFP related alarms - shdsl-isam : shdsl isam alarms - custom-ext-alarm : customizable external alarms - plug-in-unit-ext : other plugin unit alarms - sip-user-agent : sip user agent related alarms	

name	Type	Description
	- sip-plugin-unit : sip plug in unit related alarms - sip-termination : sip termination related alarms - e1-sip-termination : E1 sip termination related alarms - filetransfer : file transfer server alarms - external-device : external device related alarms - l2forward : l2forward related alarms - ether-tca : ethernet threshold cross alarms - ether-sfp : ethernet SFP related alarms - megaco-media-gw : megaco media gateway related alarms - megaco-sig-gw : megaco signaling gateway related alarms - megaco-plug-unit : megaco plug unit related alarms - megaco-term : megaco termination related alarms - megaco-sig-lt : megaco signaling lt related alarms - eqpt-supplemental : equipment supplemental alarms - eqpt-holder-ext : other equipment holder alarms - lsmredundancy : lsm redundancy alarms - sync : synce and bits alarms - mcsrc : multicast source alarms - vlanport : vlanport alarms - vect-line : xDSL vectoring line alarms - vect-board : xDSL vectoring board alarms - otdr : otdr alarms - sip-dial-plan : sip dial plan related alarms - sip-vsp : sip vsp related alarms - sip-server : sip server related alarms - bgp : bgp related alarms - rip : rip related alarms - lag : LAG related alarms - ihub-general : IHUB general related alarms - vprn : vprn related alarms - isis : isis related alarms - ospf : ospf related alarms - ihub-l2forward : ihub-l2forward alarms - vpls : vpls related alarms - ihub-equip : ihub-equip related alarms - ihub-link : ihub-link related alarms - eont-phyoam : eont phyoam related alarms - ellid : ellid related alarms - epon : epon related alarms - eont-services-lan : eon phyoam related alarms - eolt-ont-tca : eon phyoam related alarms - eont-sw-dl : eon phyoam related alarms - ldp : ldp related alarms - mpls : mpls related alarms - sdp : sdp related alarms - epipe : epipe related alarms - ihub-ipv6 : ihub-ipv6 related alarms - pim : pim related alarms - li : lawful intercept related alarms - mgmt-sec-access : management security related alarms - bfd : bfd related alarms - ai : Application Intelligence related alarms - tr069serv : tr069 server related alarms - ontsnmp : ont snmp related alarms - bulk-sync : bulk-sync related alarms - protection-group : port protection group related alarms - ont : ONT general supplemental related alarms	

101 query current alarms by filters

name	Type	Description
	- sfu-sup : SFU ONT general supplemental related alarms - soho-sup : SOHO ONT general supplemental related alarms - mdu-sup : MDU ONT general supplemental related alarms - ont-ani : ONT general supplemental 2 related alarms - sfu-sup2 : SFU ONT general supplemental 2 related alarms - soho-sup2 : SOHO ONT general supplemental 2 related alarms - mdu-sup2 : MDU ONT general supplemental 2 related alarms - sfprssi : SFP RSSI related alarms - eoltrssi : epon olt Sfp RSSI related alarms - cfm : Cfm related alarms - sfpe1t1-framer : SFP 2e1t1 framer alarms - sfpe1t1-clock : SFP 2e1t1 clock alarms - pppcc-engine-tca : PPPOE Cross Connect Engine TCA related alarm - eth-cfm : eth-cfm related alarms - rsvp : rsvp related alarms - ihub-tca : IHUB TCA related alarms - eth-ring : eth-ring related alarms - efm-oam : EFM-OAM related alarms - ont-loopdetect : ont loop detect related alarms - ont-video : ont services video related alarms - ont-ces : ont services ces related alarms - ont-voip : ont services voip related alarms - ont-video-ani : ont services video ani related alarms - ont-pwe : ont services pwe related alarms - ont-cese1 : ont services cese1 related alarms - ont-xdsl : ont services xdsl related alarms - ont-xdsl-tca : ont services xdsl tca related alarms - ont-hpna : ont hpna related alarms - ont-sip-agent-cfg : ont services voip sip agent config related alarms - ont-voip-cfg : ont services voip config related alarms - ont-mgc : ont mgc related alarms - ont-ploam : ONT PLOAM related alarms - ont-gen : ONT GENERAL related alarms - ont-card : ONT Subscriber Card related alarms - ont-pots : ONT Services POTS related alarms - ont-lan : ONT Services LAN related alarms - ont-moca : ONT MoCA related alarms - ont-tc-tca : ONT TC TCA related alarms - ont-moca-tca : ONT MoCA TCA related alarms - ont-l2uni-eth-tca : ONT L2 UNI Ethernet TCA related alarms - olt-pon-tc-tca : OLT PON TC TCA related alarms - olt-pon-util-tca : OLT PON utilization TCA related alarms - olt-chpr-util-tca : OLT channel-pair utilization TCA related alarms - olt-ont-tc-tca : OLT ONT TC TCA related alarms - ont-tca : ONT TCA related alarms - ont-pots-supplemental : ONT POTS Supplemental related alarms - sfu-ploam : SFU ONT PLOAM related alarms - sfu-gen : SFU ONT general related alarms - soho-ploam : SOHO ONT PLOAM related alarms	

name	Type	Description
	- soho-gen : SOHO ONT general related alarms - mdu-ploam : MDU ONT PLOAM related alarms - mdu-gen : MDU ONT general related alarms - ont-veip : ONT VEIP related alarms - ont-iphost : ONT IP HOST related alarms - alarm-table : alarm table related alarms - auto-switch : auto-switch related alarms - channel-pair : channel pair related alarms - ont-cfg-dld : ont configure file download related alarms - olt-chpair-tc-tca : OLT CHANNELPAIR TC TCA related alarms - hgu-tr069 : hgu tr069 related alarms - eqpt-psu : equipment psu alarms - ont-protection : ONT protection related alarms - secondary-megaco-term : secondary megaco termination related alarms - secondary-sip-term : secondary sip termination related alarms - cas-r2-channel : CAS R2 channel related alarms - lldpmed : lldpmed alarms - pseudo-wire : pseudo Wire related alarms - link-agg : Link aggregation related alarms - fcs-exceed : FCS auto-recovery related alarms - e1t1-interface : E1/T1 physical interfaces related alarms	
name	Parameter type: <Alarm::almtypeOnttctcaihub> (ont-tc-rx-los-frag-tc ont-tc-tx-los-frag-tc ont-tc-bad-gem-hd-tc all) Possible values: - ont-tc-rx-los-frag-tc : rx loss of gem fragments threshold crossed - ont-tc-tx-los-frag-tc : tx loss of gem fragments threshold crossed - ont-tc-bad-gem-hd-tc : bad gem header threshold crossed - all : ONT TC TCA related alarms	alarm name that are active <i>This element is only shown in detail mode.</i>
severity	Parameter type: <Alarm::AlarmSeverity> (indeterminate warning minor major critical) Possible values: - indeterminate : alarm severity is indeterminate - warning : alarm severity is warning - minor : alarm severity is minor - major : alarm severity is major - critical : alarm severity is critical	the alarms severity level <i>This element is only shown in detail mode.</i>
servaff	Parameter type: <Alarm::alarmServAffect> ((service-affecting yes) (noservice-affecting no)) Possible values: - service-affecting : make this alarm service affecting - yes : make this alarm service affecting - noservice-affecting : make this alarm not service affecting - no : make this alarm not service affecting	alarms affect service or not <i>This element is only shown in detail mode.</i>
location	Parameter type: <Alarm::almLocation>	alarm location: near, middle, far

101 query current alarms by filters

name	Type	Description
	(near-end far-end middle-end line null) Possible values: - near-end : alarm location is near - far-end : alarm location is far - middle-end : alarm location is middle - line : alarm location is line - null : alarm location not defined	<i>This element is only shown in detail mode.</i>
time	Parameter type: <Sys::timeInSecs> - the time (yyyy-mm-dd:hour:minutes:secs) - unit: UTC	time in seconds when alarm was updated <i>This element is only shown in detail mode.</i>
direction	Parameter type: <Alarm::almDirection> (received transmit null) Possible values: - received : alarm is received - transmit : alarm is transmit - null : direction not defined	alarm direction: received or transmit <i>This element is only shown in detail mode.</i>
descript	Parameter type: <Alarm::AddInfoString> - additional alarm information	alarm description <i>This element is only shown in detail mode.</i>

101.70 show current alarm by filters

Command Description

show current alarms by filters

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm query ont-l2uni-eth-tca [ (name) [ severity <Alarm::querySeverity> ] [ servaff
<Alarm::queryServAffect> ] [ ont-port <Alarm::queryDefaultAid> ] ]
```

Command Parameters

Table 101.70-1 "show current alarm by filters" Resource Parameters

Resource Identifier	Type	Description
(name)	Format: (ont-uni-ds-drpdp-fr-tc ont-uni-up-drpdp-fr-tc ont-uni-ds-crc-fr-tc ont-uni-up-crc-fr-tc all) Possible values: - ont-uni-ds-drpdp-fr-tc : downstream l2 dropped frames threshold crossed - ont-uni-up-drpdp-fr-tc : upstream l2 dropped frames threshold crossed - ont-uni-ds-crc-fr-tc : downstream l2 rx crc error frames threshold crossed - ont-uni-up-crc-fr-tc : upstream l2 rx crc error frames threshold crossed - all : ONT L2 UNI Ethernet TCA related alarms	alarm name of ont l2uni eth tca
severity	Parameter type: <Alarm::querySeverity> Format: (indeterminate warning minor major critical all) Possible values: - indeterminate : alarm severity is indeterminate - warning : alarm severity is warning - minor : alarm severity is minor	severity level of an alarm for reporting

101 query current alarms by filters

Resource Identifier	Type	Description
	- major : alarm severity is major - critical : alarm severity is critical - all : all alarm severity	
servaff	Parameter type: <Alarm::queryServAffect> Format: (service-affecting noservice-affecting all) Possible values: - service-affecting : query alarm service affecting - noservice-affecting : query alarm not service affecting - all : query service affecting and not affecting alarms	serviceaffecting no serviceaffecting
ont-port	Parameter type: <Alarm::queryDefaultAid> Format: all Possible values: - all : default AID parameter	all gpon ont port spindex

Command Output

Table 101.70-2 "show current alarm by filters" Display parameters

Specific Information		
name	Type	Description
aidinfo	Parameter type: <Alarm::AddInfoString> - additional alarm information	alarm AID parameters <i>This element is only shown in detail mode.</i>
type	Parameter type: <Alarm::alarmIHUBType> (equipment eqpt-holder plug-in-unit atm custom e1 ima-group ima-link redundancy shdsl ether-itf traffic-overflow qos-queue temporal spatial (software-mngt sw-mgmt) xdsl xdsl-ext xdsl-tca olt-gen eo-conv authentication bonding sfp shdsl-isam custom-ext-alarm plug-in-unit-ext sip-user-agent sip-plugin-unit	type of the alarms that are active <i>This element is only shown in detail mode.</i>

name	Type	Description
	sip-termination e1-sip-termination filetransfer external-device l2forward ether-tca ether-sfp megaco-media-gw megaco-sig-gw megaco-plug-unit megaco-term megaco-sig-lt eqpt-supplemental eqpt-holder-ext lsmredundancy sync mcsrc vlanport vect-line vect-board otdr sip-dial-plan sip-vsp sip-server bgp rip lag ihub-general vprn isis ospf ihub-l2forward vpls ihub-equip ihub-link eont-phyoam ellid epon eont-services-lan eolt-ont-tca eont-sw-dl ldp mpls sdp epipe ihub-ipv6 pim li mgmt-sec-access bfd ai tr069serv ontsnmp bulk-sync protection-group ont sfu-sup	

101 query current alarms by filters

name	Type	Description
	soho-sup	
	mdu-sup	
	ont-ani	
	sfu-sup2	
	soho-sup2	
	mdu-sup2	
	sfprssi	
	eoltrssi	
	cfm	
	sfpe1t1-framer	
	sfpe1t1-clock	
	pppcc-engine-tca	
	eth-cfm	
	rsvp	
	ihub-tca	
	eth-ring	
	efm-oam	
	ont-loopdetect	
	ont-video	
	ont-ces	
	ont-voip	
	ont-video-ani	
	ont-pwe	
	ont-cese1	
	ont-xdsl	
	ont-xdsl-tca	
	ont-hpna	
	ont-sip-agent-cfg	
	ont-voip-cfg	
	ont-mgc	
	ont-ploam	
	ont-gen	
	ont-card	
	ont-pots	
	ont-lan	
	ont-moca	
	ont-tc-tca	
	ont-moca-tca	
	ont-l2uni-eth-tca	
	olt-pon-tc-tca	
	olt-pon-util-tca	
	olt-chpr-util-tca	
	olt-ont-tc-tca	
	ont-tca	
	ont-pots-supplemental	
	sfu-ploam	
	sfu-gen	
	soho-ploam	
	soho-gen	
	mdu-ploam	
	mdu-gen	
	ont-veip	
	ont-iphost	
	alarm-table	
	auto-switch	
	channel-pair	
	ont-cfg-dld	

name	Type	Description
	olt-chpair-tc-tca hgu-tr069 eqpt-psu ont-protection secondary-megaco-term secondary-sip-term cas-r2-channel lldpmed pseudo-wire link-agg fcs-exceed e1t1-interface) Possible values: - equipment : equipment alarms - eqpt-holder : equipment holder alarms - plug-in-unit : plugin unit alarms - atm : ATM alarms - custom : customizable alarms - e1 : e1 alarms - ima-group : ima-group alarms - ima-link : ima-link alarms - redundancy : redundancy alarms - shdsl : shdsl alarms - ether-itf : ethernet interface alarms - traffic-overflow : Traffic overflow alarms - qos-queue : qos queue alarms - temporal : temporal alarms - spatial : spatial alarms - software-mngt : software management alarms - sw-mgmt : software management alarms - xdsl : xDSL alarms - xdsl-ext : other xDSL alarms - xdsl-tca : xDSL threshold cross alarms - olt-gen : OLT general alarms - eo-conv : E/O conversion related alarms - authentication : authentication related alarms - bonding : bonding-group related alarms - sfp : SFP related alarms - shdsl-isam : shdsl isam alarms - custom-ext-alarm : customizable external alarms - plug-in-unit-ext : other plugin unit alarms - sip-user-agent : sip user agent related alarms - sip-plugin-unit : sip plug in unit related alarms - sip-termination : sip termination related alarms - e1-sip-termination : E1 sip termination related alarms - filetransfer : file transfer server alarms - external-device : external device related alarms - l2forward : l2forward related alarms - ether-tca : ethernet threshold cross alarms - ether-sfp : ethernet SFP related alarms - megaco-media-gw : megaco media gateway related alarms - megaco-sig-gw : megaco signaling gateway related alarms - megaco-plug-unit : megaco plug unit related alarms - megaco-term : megaco termination related alarms - megaco-sig-lt : megaco signaling lt related alarms - eqpt-supplemental : equipment supplemental alarms - eqpt-holder-ext : other equipment holder alarms	

101 query current alarms by filters

name	Type	Description
	- lsmredundancy : lsm redundancy alarms - sync : synce and bits alarms - mcsrc : multicast source alarms - vlanport : vlanport alarms - vect-line : xDSL vectoring line alarms - vect-board : xDSL vectoring board alarms - otdr : otdr alarms - sip-dial-plan : sip dial plan related alarms - sip-vsp : sip vsp related alarms - sip-server : sip server related alarms - bgp : bgp related alarms - rip : rip related alarms - lag : LAG related alarms - ihub-general : IHUB general related alarms - vprn : vprn related alarms - isis : isis related alarms - ospf : ospf related alarms - ihub-l2forward : ihub-l2forward alarms - vpls : vpls related alarms - ihub-equip : ihub-equip related alarms - ihub-link : ihub-link related alarms - eont-phyoam : eont phyoam related alarms - ellid : ellid related alarms - epon : epon related alarms - eont-services-lan : eon phyoam related alarms - eolt-ont-tca : eon phyoam related alarms - eont-sw-dl : eon phyoam related alarms - ldp : ldp related alarms - mpls : mpls related alarms - sdp : sdp related alarms - epipe : epipe related alarms - ihub-ipv6 : ihub-ipv6 related alarms - pim : pim related alarms - li : lawful intercept related alarms - mgmt-sec-access : management security related alarms - bfd : bfd related alarms - ai : Application Intelligence related alarms - tr069serv : tr069 server related alarms - ontsnmp : ont snmp related alarms - bulk-sync : bulk-sync related alarms - protection-group : port protection group related alarms - ont : ONT general supplemental related alarms - sfu-sup : SFU ONT general supplemental related alarms - soho-sup : SOHO ONT general supplemental related alarms - mdu-sup : MDU ONT general supplemental related alarms - ont-ani : ONT general supplemental 2 related alarms - sfu-sup2 : SFU ONT general supplemental 2 related alarms - soho-sup2 : SOHO ONT general supplemental 2 related alarms - mdu-sup2 : MDU ONT general supplemental 2 related alarms - sfprssi : SFP RSSI related alarms - eoltrssi : epon olt Sfp RSSI related alarms - cfm : Cfm related alarms - sfpe1t1-framer : SFP 2e1t1 framer alarms - sfpe1t1-clock : SFP 2e1t1 clock alarms	

name	Type	Description
	- pppcc-engine-tca : PPPOE Cross Connect Engine TCA related alarm - eth-cfm : eth-cfm related alarms - rsvp : rsvp related alarms - ihub-tca : IHUB TCA related alarms - eth-ring : eth-ring related alarms - efm-oam : EFM-OAM related alarms - ont-loopdetect : ont loop detect related alarms - ont-video : ont services video related alarms - ont-ces : ont services ces related alarms - ont-voip : ont services voip related alarms - ont-video-ani : ont services video ani related alarms - ont-pwe : ont services pwe related alarms - ont-cese1 : ont services cese1 related alarms - ont-xdsl : ont services xdsl related alarms - ont-xdsl-tca : ont services xdsl tca related alarms - ont-hpna : ont hpna related alarms - ont-sip-agent-cfg : ont services voip sip agent config related alarms - ont-voip-cfg : ont services voip config related alarms - ont-mgc : ont mgc related alarms - ont-ploam : ONT PLOAM related alarms - ont-gen : ONT GENERAL related alarms - ont-card : ONT Subscriber Card related alarms - ont-pots : ONT Services POTS related alarms - ont-lan : ONT Services LAN related alarms - ont-moca : ONT MoCA related alarms - ont-tc-tca : ONT TC TCA related alarms - ont-moca-tca : ONT MoCA TCA related alarms - ont-l2uni-eth-tca : ONT L2 UNI Ethernet TCA related alarms - olt-pon-tc-tca : OLT PON TC TCA related alarms - olt-pon-util-tca : OLT PON utilization TCA related alarms - olt-chpr-util-tca : OLT channel-pair utilization TCA related alarms - olt-ont-tc-tca : OLT ONT TC TCA related alarms - ont-tca : ONT TCA related alarms - ont-pots-supplemental : ONT POTS Supplemental related alarms - sfu-ploam : SFU ONT PLOAM related alarms - sfu-gen : SFU ONT general related alarms - soho-ploam : SOHO ONT PLOAM related alarms - soho-gen : SOHO ONT general related alarms - mdu-ploam : MDU ONT PLOAM related alarms - mdu-gen : MDU ONT general related alarms - ont-veip : ONT VEIP related alarms - ont-iphost : ONT IP HOST related alarms - alarm-table : alarm table related alarms - auto-switch : auto-switch related alarms - channel-pair : channel pair related alarms - ont-cfg-dld : ont configure file download related alarms - olt-chpair-tc-tca : OLT CHANNELPAIR TC TCA related alarms - hgu-tr069 : hgu tr069 related alarms - eqpt-psu : equipment psu alarms - ont-protection : ONT protection related alarms - secondary-megaco-term : secondary megaco termination	

101 query current alarms by filters

name	Type	Description
	related alarms - secondary-sip-term : secondary sip termination related alarms - cas-r2-channel : CAS R2 channel related alarms - lldpmed : lldpmed alarms - pseudo-wire : pseudo Wire related alarms - link-agg : Link aggregation related alarms - fcs-exceed : FCS auto-recovery related alarms - e1t1-interface : E1/T1 physical interfaces related alarms	
name	Parameter type: <Alarm::almtypeOntl2unieththcaihub> (ont-uni-ds-drpdp-fr-tc ont-uni-up-drpdp-fr-tc ont-uni-ds-crc-fr-tc ont-uni-up-crc-fr-tc all) Possible values: - ont-uni-ds-drpdp-fr-tc : downstream l2 dropped frames threshold crossed - ont-uni-up-drpdp-fr-tc : upstream l2 dropped frames threshold crossed - ont-uni-ds-crc-fr-tc : downstream l2 rx crc error frames threshold crossed - ont-uni-up-crc-fr-tc : upstream l2 rx crc error frames threshold crossed - all : ONT L2 UNI Ethernet TCA related alarms	alarm name that are active <i>This element is only shown in detail mode.</i>
severity	Parameter type: <Alarm::AlarmSeverity> (indeterminate warning minor major critical) Possible values: - indeterminate : alarm severity is indeterminate - warning : alarm severity is warning - minor : alarm severity is minor - major : alarm severity is major - critical : alarm severity is critical	the alarms severity level <i>This element is only shown in detail mode.</i>
servaff	Parameter type: <Alarm::alarmServAffect> ((service-affecting yes) (noservice-affecting no)) Possible values: - service-affecting : make this alarm service affecting - yes : make this alarm service affecting - noservice-affecting : make this alarm not service affecting - no : make this alarm not service affecting	alarms affect service or not <i>This element is only shown in detail mode.</i>
location	Parameter type: <Alarm::almLocation> (near-end far-end middle-end line null) Possible values: - near-end : alarm location is near - far-end : alarm location is far - middle-end : alarm location is middle - line : alarm location is line - null : alarm location not defined	alarm location: near, middle, far <i>This element is only shown in detail mode.</i>

101 query current alarms by filters

name	Type	Description
time	Parameter type: <Sys::timeInSecs> - the time (yyyy-mm-dd:hour:minutes:secs) - unit: UTC	time in seconds when alarm was updated <i>This element is only shown in detail mode.</i>
direction	Parameter type: <Alarm::almDirection> (received transmit null) Possible values: - received : alarm is received - transmit : alarm is transmit - null : direction not defined	alarm direction: received or transmit <i>This element is only shown in detail mode.</i>
descript	Parameter type: <Alarm::AddInfoString> - additional alarm information	alarm description <i>This element is only shown in detail mode.</i>

101.71 show current alarm by filters

Command Description

show current alarms by filters

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm query ont-moca-tca [ (name) [ severity <Alarm::querySeverity> ] [ servaff
<Alarm::queryServAffect> ] [ uni-index <Alarm::queryDefaultAid> ] ]
```

Command Parameters

Table 101.71-1 "show current alarm by filters" Resource Parameters

Resource Identifier	Type	Description
(name)	Format: (ont-moca-tca-rx-err-fr all) Possible values: - ont-moca-tca-rx-err-fr: moca rx errored frames threshold crossed - all : ONT MoCA TCA related alarms	alarm name of ont moca threshold crossing alert
severity	Parameter type: <Alarm::querySeverity> Format: (indeterminate warning minor major critical all) Possible values: - indeterminate : alarm severity is indeterminate - warning : alarm severity is warning - minor : alarm severity is minor - major : alarm severity is major - critical : alarm severity is critical - all : all alarm severity	severity level of an alarm for reporting
servaff	Parameter type: <Alarm::queryServAffect> Format: (service-affecting noservice-affecting all) Possible values:	serviceaffecting no

Resource Identifier	Type	Description
	- service-affecting : query alarm service affecting - noservice-affecting : query alarm not service affecting - all : query service affecting and not affecting alarms	
uni-index	Parameter type: <Alarm::queryDefaultAid> Format: all Possible values: - all : default AID parameter	all ont port

Command Output

Table 101.71-2 "show current alarm by filters" Display parameters

Specific Information		
name	Type	Description
aidinfo	Parameter type: <Alarm::AddInfoString> - additional alarm information	alarm AID parameters <i>This element is only shown in detail mode.</i>
type	Parameter type: <Alarm::alarmIHUBType> (equipment eqpt-holder plug-in-unit atm custom e1 ima-group ima-link redundancy shdsl ether-itf traffic-overflow qos-queue temporal spatial (software-mngt sw-mgmt) xdsl xdsl-ext xdsl-tca olt-gen eo-conv authentication bonding sfp shdsl-isam custom-ext-alarm plug-in-unit-ext sip-user-agent sip-plugin-unit sip-termination e1-sip-termination filetransfer external-device l2forward ether-tca ether-sfp megaco-media-gw megaco-sig-gw)	type of the alarms that are active <i>This element is only shown in detail mode.</i>

101 query current alarms by filters

name	Type	Description
	megaco-plug-unit	
	megaco-term	
	megaco-sig-lt	
	eqpt-supplemental	
	eqpt-holder-ext	
	lsmredundancy	
	sync	
	mcsrc	
	vlanport	
	vect-line	
	vect-board	
	otdr	
	sip-dial-plan	
	sip-vsp	
	sip-server	
	bgp	
	rip	
	lag	
	ihub-general	
	vprn	
	isis	
	ospf	
	ihub-l2forward	
	vpls	
	ihub-equip	
	ihub-link	
	eont-phyoam	
	ellid	
	epon	
	eont-services-lan	
	eolt-ont-tca	
	eont-sw-dl	
	ldp	
	mpls	
	sdp	
	epipe	
	ihub-ipv6	
	pim	
	li	
	mgmt-sec-access	
	bfd	
	ai	
	tr069serv	
	ontsnmp	
	bulk-sync	
	protection-group	
	ont	
	sfu-sup	
	soho-sup	
	mdu-sup	
	ont-ani	
	sfu-sup2	
	soho-sup2	
	mdu-sup2	
	sfprssi	
	eoltrssi	
	cfm	

name	Type	Description
	sfpe1t1-framer sfpe1t1-clock pppcc-engine-tca eth-cfm rsvp ihub-tca eth-ring efm-oam ont-loopdetect ont-video ont-ces ont-voip ont-video-ani ont-pwe ont-cese1 ont-xdsl ont-xdsl-tca ont-hpna ont-sip-agent-cfg ont-voip-cfg ont-mgc ont-ploam ont-gen ont-card ont-pots ont-lan ont-moca ont-tc-tca ont-moca-tca ont-l2uni-eth-tca olt-pon-tc-tca olt-pon-util-tca olt-chpr-util-tca olt-ont-tc-tca ont-tca ont-pots-supplemental sfu-ploam sfu-gen soho-ploam soho-gen mdu-ploam mdu-gen ont-veip ont-iphost alarm-table auto-switch channel-pair ont-cfg-dld olt-chpair-tc-tca hgu-tr069 eqpt-psu ont-protection secondary-megaco-term secondary-sip-term cas-r2-channel lldpmed pseudo-wire	

101 query current alarms by filters

name	Type	Description
	link-agg fcs-exceed e1t1-interface) Possible values: - equipment : equipment alarms - eqpt-holder : equipment holder alarms - plug-in-unit : plugin unit alarms - atm : ATM alarms - custom : customizable alarms - e1 : e1 alarms - ima-group : ima-group alarms - ima-link : ima-link alarms - redundancy : redundancy alarms - shdsl : shdsl alarms - ether-itf : ethernet interface alarms - traffic-overflow : Traffic overflow alarms - qos-queue : qos queue alarms - temporal : temporal alarms - spatial : spatial alarms - software-mngt : software management alarms - sw-mgmt : software management alarms - xdsl : xDSL alarms - xdsl-ext : other xDSL alarms - xdsl-tca : xDSL threshold cross alarms - olt-gen : OLT general alarms - eo-conv : E/O conversion related alarms - authentication : authentication related alarms - bonding : bonding-group related alarms - sfp : SFP related alarms - shdsl-isam : shdsl isam alarms - custom-ext-alarm : customizable external alarms - plug-in-unit-ext : other plugin unit alarms - sip-user-agent : sip user agent related alarms - sip-plugin-unit : sip plug in unit related alarms - sip-termination : sip termination related alarms - e1-sip-termination : E1 sip termination related alarms - filetransfer : file transfer server alarms - external-device : external device related alarms - l2forward : l2forward related alarms - ether-tca : ethernet threshold cross alarms - ether-sfp : ethernet SFP related alarms - megaco-media-gw : megaco media gateway related alarms - megaco-sig-gw : megaco signaling gateway related alarms - megaco-plug-unit : megaco plug unit related alarms - megaco-term : megaco termination related alarms - megaco-sig-lt : megaco signaling lt related alarms - eqpt-supplemental : equipment supplemental alarms - eqpt-holder-ext : other equipment holder alarms - lsmredundancy : lsm redundancy alarms - sync : synce and bits alarms - mcsrc : multicast source alarms - vlanport : vlanport alarms - vect-line : xDSL vectoring line alarms - vect-board : xDSL vectoring board alarms - otdr : otdr alarms - sip-dial-plan : sip dial plan related alarms - sip-vsp : sip vsp related alarms	

name	Type	Description
	- sip-server : sip server related alarms - bgp : bgp related alarms - rip : rip related alarms - lag : LAG related alarms - ihub-general : IHUB general related alarms - vprn : vprn related alarms - isis : isis related alarms - ospf : ospf related alarms - ihub-l2forward : ihub-l2forward alarms - vpls : vpls related alarms - ihub-equip : ihub-equip related alarms - ihub-link : ihub-link related alarms - eont-phyoam : eont phyoam related alarms - ellid : ellid related alarms - epon : epon related alarms - eont-services-lan : eon phyoam related alarms - eolt-ont-tca : eon phyoam related alarms - eont-sw-dl : eon phyoam related alarms - ldp : ldp related alarms - mpls : mpls related alarms - sdp : sdp related alarms - epipe : epipe related alarms - ihub-ipv6 : ihub-ipv6 related alarms - pim : pim related alarms - li : lawful intercept related alarms - mgmt-sec-access : management security related alarms - bfd : bfd related alarms - ai : Application Intelligence related alarms - tr069serv : tr069 server related alarms - ontsnmp : ont snmp related alarms - bulk-sync : bulk-sync related alarms - protection-group : port protection group related alarms - ont : ONT general supplemental related alarms - sfu-sup : SFU ONT general supplemental related alarms - soho-sup : SOHO ONT general supplemental related alarms - mdu-sup : MDU ONT general supplemental related alarms - ont-ani : ONT general supplemental 2 related alarms - sfu-sup2 : SFU ONT general supplemental 2 related alarms - soho-sup2 : SOHO ONT general supplemental 2 related alarms - mdu-sup2 : MDU ONT general supplemental 2 related alarms - sfprssi : SFP RSSI related alarms - eoltrssi : epon olt Sfp RSSI related alarms - cfm : Cfm related alarms - sfpe1t1-framer : SFP 2e1t1 framer alarms - sfpe1t1-clock : SFP 2e1t1 clock alarms - pppcc-engine-tca : PPPOE Cross Connect Engine TCA related alarm - eth-cfm : eth-cfm related alarms - rsvp : rsvp related alarms - ihub-tca : IHUB TCA related alarms - eth-ring : eth-ring related alarms - efm-oam : EFM-OAM related alarms - ont-loopdetect : ont loop detect related alarms - ont-video : ont services video related alarms	

101 query current alarms by filters

name	Type	Description
	- ont-ces : ont services ces related alarms - ont-voip : ont services voip related alarms - ont-video-ani : ont services video ani related alarms - ont-pwe : ont services pwe related alarms - ont-cese1 : ont services cese1 related alarms - ont-xdsl : ont services xdsl related alarms - ont-xdsl-tca : ont services xdsl tca related alarms - ont-hpna : ont hpna related alarms - ont-sip-agent-cfg : ont services voip sip agent config related alarms - ont-voip-cfg : ont services voip config related alarms - ont-mgc : ont mgc related alarms - ont-ploam : ONT PLOAM related alarms - ont-gen : ONT GENERAL related alarms - ont-card : ONT Subscriber Card related alarms - ont-pots : ONT Services POTS related alarms - ont-lan : ONT Services LAN related alarms - ont-moca : ONT MoCA related alarms - ont-tc-tca : ONT TC TCA related alarms - ont-moca-tca : ONT MoCA TCA related alarms - ont-l2uni-eth-tca : ONT L2 UNI Ethernet TCA related alarms - olt-pon-tc-tca : OLT PON TC TCA related alarms - olt-pon-util-tca : OLT PON utilization TCA related alarms - olt-chpr-util-tca : OLT channel-pair utilization TCA related alarms - olt-ont-tc-tca : OLT ONT TC TCA related alarms - ont-tca : ONT TCA related alarms - ont-pots-supplemental : ONT POTS Supplemental related alarms - sfu-ploam : SFU ONT PLOAM related alarms - sfu-gen : SFU ONT general related alarms - soho-ploam : SOHO ONT PLOAM related alarms - soho-gen : SOHO ONT general related alarms - mdu-ploam : MDU ONT PLOAM related alarms - mdu-gen : MDU ONT general related alarms - ont-veip : ONT VEIP related alarms - ont-iphost : ONT IP HOST related alarms - alarm-table : alarm table related alarms - auto-switch : auto-switch related alarms - channel-pair : channel pair related alarms - ont-cfg-dld : ont configure file download related alarms - olt-chpair-tc-tca : OLT CHANNELPAIR TC TCA related alarms - hgu-tr069 : hgu tr069 related alarms - eqpt-psu : equipment psu alarms - ont-protection : ONT protection related alarms - secondary-megaco-term : secondary megaco termination related alarms - secondary-sip-term : secondary sip termination related alarms - cas-r2-channel : CAS R2 channel related alarms - lldpmed : lldpmed alarms - pseudo-wire : pseudo Wire related alarms - link-agg : Link aggregation related alarms - fcs-exceed : FCS auto-recovery related alarms - e1t1-interface : E1/T1 physical interfaces related alarms	

name	Type	Description
name	Parameter type: <Alarm::almTypeOntmocatcai> (ont-moca-tca-rx-err-fr all) Possible values: - ont-moca-tca-rx-err-fr: moca rx errored frames threshold crossed - all : ONT MoCA TCA related alarms	alarm name that are active <i>This element is only shown in detail mode.</i>
severity	Parameter type: <Alarm::AlarmSeverity> (indeterminate warning minor major critical) Possible values: - indeterminate : alarm severity is indeterminate - warning : alarm severity is warning - minor : alarm severity is minor - major : alarm severity is major - critical : alarm severity is critical	the alarms severity level <i>This element is only shown in detail mode.</i>
servaff	Parameter type: <Alarm::alarmServAffect> ((service-affecting yes) (noservice-affecting no)) Possible values: - service-affecting : make this alarm service affecting - yes : make this alarm service affecting - noservice-affecting : make this alarm not service affecting - no : make this alarm not service affecting	alarms affect service or not <i>This element is only shown in detail mode.</i>
location	Parameter type: <Alarm::almLocation> (near-end far-end middle-end line null) Possible values: - near-end : alarm location is near - far-end : alarm location is far - middle-end : alarm location is middle - line : alarm location is line - null : alarm location not defined	alarm location: near, middle, far <i>This element is only shown in detail mode.</i>
time	Parameter type: <Sys::timeInSecs> - the time (yyyy-mm-dd:hour:minutes:secs) - unit: UTC	time in seconds when alarm was updated <i>This element is only shown in detail mode.</i>
direction	Parameter type: <Alarm::almDirection> (received transmit null) Possible values: - received : alarm is received - transmit : alarm is transmit - null : direction not defined	alarm direction: received or transmit <i>This element is only shown in detail mode.</i>
descript	Parameter type: <Alarm::AddInfoString> - additional alarm information	alarm description <i>This element is only shown in detail mode.</i>

101.72 show current alarm by filters

Command Description

show current alarms by filters

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm query olt-pon-tc-tca [ (name) [ severity <Alarm::querySeverity> ] [ servaff
<Alarm::queryServAffect> ] [ pon <Gpon::PonId> ] ]
```

Command Parameters

Table 101.72-1 "show current alarm by filters" Resource Parameters

Resource Identifier	Type	Description
(name)	Format: (olt-pon-tc-err-frag-tc olt-pon-up-bw-tca olt-pon-down-bw-tca all) Possible values: - olt-pon-tc-err-frag-tc: pon errored fragments threshold crossed - olt-pon-up-bw-tca : OLT PON upstream bandwidth TCA - olt-pon-down-bw-tca : OLT PON downstream bandwidth TCA - all : OLT PON TC TCA related alarms	alarm name of olt pon tc tca
severity	Parameter type: <Alarm::querySeverity> Format: (indeterminate warning minor major critical all) Possible values: - indeterminate : alarm severity is indeterminate - warning : alarm severity is warning - minor : alarm severity is minor - major : alarm severity is major - critical : alarm severity is critical - all : all alarm severity	severity level of an alarm for reporting
servaff	Parameter type: <Alarm::queryServAffect>	serviceaffecting no

Resource Identifier	Type	Description
	Format: (service-affecting noservice-affecting all) Possible values: - service-affecting : query alarm service affecting - noservice-affecting : query alarm not service affecting - all : query service affecting and not affecting alarms	serviceaffecting
pon	Parameter type: <Gpon::PonId> Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> x-pon : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::XPonId> 25g-pon : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::M25GPonId>) Possible values: - 25g-pon : 25g pon - x-pon : Xgs pon Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Eqpt::XPonId> - the XGS PON identifier Field type <Eqpt::M25GPonId> - the 25G PON identifier	gpon pon ifindex

Command Output

Table 101.72-2 "show current alarm by filters" Display parameters

Specific Information		
name	Type	Description
aidinfo	Parameter type: <Alarm::AddInfoString> - additional alarm information	alarm AID parameters <i>This element is only shown in detail mode.</i>
type	Parameter type: <Alarm::alarmIHUBType> (equipment eqpt-holder plug-in-unit atm custom e1 ima-group ima-link redundancy shdsl ether-itf traffic-overflow qos-queue temporal spatial	type of the alarms that are active <i>This element is only shown in detail mode.</i>

101 query current alarms by filters

name	Type	Description
	(software-mngt sw-mgmt)	
	xdsl	
	xdsl-ext	
	xdsl-tca	
	olt-gen	
	eo-conv	
	authentication	
	bonding	
	sfp	
	shdsl-isam	
	custom-ext-alarm	
	plug-in-unit-ext	
	sip-user-agent	
	sip-plugin-unit	
	sip-termination	
	e1-sip-termination	
	filetransfer	
	external-device	
	l2forward	
	ether-tca	
	ether-sfp	
	megaco-media-gw	
	megaco-sig-gw	
	megaco-plug-unit	
	megaco-term	
	megaco-sig-lt	
	eqpt-supplemental	
	eqpt-holder-ext	
	lsmredundancy	
	sync	
	mcsrc	
	vlanport	
	vect-line	
	vect-board	
	otdr	
	sip-dial-plan	
	sip-vsp	
	sip-server	
	bgp	
	rip	
	lag	
	ihub-general	
	vprn	
	isis	
	ospf	
	ihub-l2forward	
	vpls	
	ihub-equip	
	ihub-link	
	eont-phyoam	
	ellid	
	epon	
	eont-services-lan	
	eolt-ont-tca	
	eont-sw-dl	
	ldp	
	mpls	

name	Type	Description
	sdp	
	epipe	
	ihub-ipv6	
	pim	
	li	
	mgmt-sec-access	
	bfd	
	ai	
	tr069serv	
	ontsnmp	
	bulk-sync	
	protection-group	
	ont	
	sfu-sup	
	soho-sup	
	mdu-sup	
	ont-ani	
	sfu-sup2	
	soho-sup2	
	mdu-sup2	
	sfprssi	
	eoltrssi	
	cfm	
	sfpe1t1-framer	
	sfpe1t1-clock	
	pppcc-engine-tca	
	eth-cfm	
	rsvp	
	ihub-tca	
	eth-ring	
	efm-oam	
	ont-loopdetect	
	ont-video	
	ont-ces	
	ont-voip	
	ont-video-ani	
	ont-pwe	
	ont-cese1	
	ont-xdsl	
	ont-xdsl-tca	
	ont-hpna	
	ont-sip-agent-cfg	
	ont-voip-cfg	
	ont-mgc	
	ont-ploam	
	ont-gen	
	ont-card	
	ont-pots	
	ont-lan	
	ont-moca	
	ont-tc-tca	
	ont-moca-tca	
	ont-l2uni-eth-tca	
	olt-pon-tc-tca	
	olt-pon-util-tca	
	olt-chpr-util-tca	
	olt-ont-tc-tca	

101 query current alarms by filters

name	Type	Description
	ont-tca ont-pots-supplemental sfu-ploam sfu-gen soho-ploam soho-gen mdu-ploam mdu-gen ont-veip ont-iphost alarm-table auto-switch channel-pair ont-cfg-dld olt-chpair-tc-tca hgu-tr069 eqpt-psu ont-protection secondary-megaco-term secondary-sip-term cas-r2-channel lldpmed pseudo-wire link-agg fcs-exceed e1t1-interface) Possible values: - equipment : equipment alarms - eqpt-holder : equipment holder alarms - plug-in-unit : plugin unit alarms - atm : ATM alarms - custom : customizable alarms - e1 : e1 alarms - ima-group : ima-group alarms - ima-link : ima-link alarms - redundancy : redundancy alarms - shdsl : shdsl alarms - ether-itf : ethernet interface alarms - traffic-overflow : Traffic overflow alarms - qos-queue : qos queue alarms - temporal : temporal alarms - spatial : spatial alarms - software-mngt : software management alarms - sw-mgmt : software management alarms - xdsl : xDSL alarms - xdsl-ext : other xDSL alarms - xdsl-tca : xDSL threshold cross alarms - olt-gen : OLT general alarms - eo-conv : E/O conversion related alarms - authentication : authentication related alarms - bonding : bonding-group related alarms - sfp : SFP related alarms - shdsl-isam : shdsl isam alarms - custom-ext-alarm : customizable external alarms - plug-in-unit-ext : other plugin unit alarms - sip-user-agent : sip user agent related alarms - sip-plugin-unit : sip plug in unit related alarms	

name	Type	Description
	- sip-termination : sip termination related alarms - e1-sip-termination : E1 sip termination related alarms - filetransfer : file transfer server alarms - external-device : external device related alarms - l2forward : l2forward related alarms - ether-tca : ethernet threshold cross alarms - ether-sfp : ethernet SFP related alarms - megaco-media-gw : megaco media gateway related alarms - megaco-sig-gw : megaco signaling gateway related alarms - megaco-plug-unit : megaco plug unit related alarms - megaco-term : megaco termination related alarms - megaco-sig-lt : megaco signaling lt related alarms - eqpt-supplemental : equipment supplemental alarms - eqpt-holder-ext : other equipment holder alarms - lsmredundancy : lsm redundancy alarms - sync : synce and bits alarms - mcsrc : multicast source alarms - vlanport : vlanport alarms - vect-line : xDSL vectoring line alarms - vect-board : xDSL vectoring board alarms - otdr : otdr alarms - sip-dial-plan : sip dial plan related alarms - sip-vsp : sip vsp related alarms - sip-server : sip server related alarms - bgp : bgp related alarms - rip : rip related alarms - lag : LAG related alarms - ihub-general : IHUB general related alarms - vprn : vprn related alarms - isis : isis related alarms - ospf : ospf related alarms - ihub-l2forward : ihub-l2forward alarms - vpls : vpls related alarms - ihub-equip : ihub-equip related alarms - ihub-link : ihub-link related alarms - eont-phyoam : eont phyoam related alarms - ellid : ellid related alarms - epon : epon related alarms - eont-services-lan : eon phyoam related alarms - eolt-ont-tca : eon phyoam related alarms - eont-sw-dl : eon phyoam related alarms - ldp : ldp related alarms - mpls : mpls related alarms - sdp : sdp related alarms - epipe : epipe related alarms - ihub-ipv6 : ihub-ipv6 related alarms - pim : pim related alarms - li : lawful intercept related alarms - mgmt-sec-access : management security related alarms - bfd : bfd related alarms - ai : Application Intelligence related alarms - tr069serv : tr069 server related alarms - ontsnmp : ont snmp related alarms - bulk-sync : bulk-sync related alarms - protection-group : port protection group related alarms - ont : ONT general supplemental related alarms - sfu-sup : SFU ONT general supplemental related alarms	

101 query current alarms by filters

name	Type	Description
	- soho-sup : SOHO ONT general supplemental related alarms - mdu-sup : MDU ONT general supplemental related alarms - ont-ani : ONT general supplemental 2 related alarms - sfu-sup2 : SFU ONT general supplemental 2 related alarms - soho-sup2 : SOHO ONT general supplemental 2 related alarms - mdu-sup2 : MDU ONT general supplemental 2 related alarms - sfprssi : SFP RSSI related alarms - eoltrssi : epon olt Sfp RSSI related alarms - cfm : Cfm related alarms - sfpe1t1-framer : SFP 2e1t1 framer alarms - sfpe1t1-clock : SFP 2e1t1 clock alarms - pppcc-engine-tca : PPPOE Cross Connect Engine TCA related alarm - eth-cfm : eth-cfm related alarms - rsvp : rsvp related alarms - ihub-tca : IHUB TCA related alarms - eth-ring : eth-ring related alarms - efm-oam : EFM-OAM related alarms - ont-loopdetect : ont loop detect related alarms - ont-video : ont services video related alarms - ont-ces : ont services ces related alarms - ont-voip : ont services voip related alarms - ont-video-ani : ont services video ani related alarms - ont-pwe : ont services pwe related alarms - ont-cese1 : ont services cese1 related alarms - ont-xdsl : ont services xdsl related alarms - ont-xdsl-tca : ont services xdsl tca related alarms - ont-hpna : ont hpna related alarms - ont-sip-agent-cfg : ont services voip sip agent config related alarms - ont-voip-cfg : ont services voip config related alarms - ont-mgc : ont mgc related alarms - ont-ploam : ONT PLOAM related alarms - ont-gen : ONT GENERAL related alarms - ont-card : ONT Subscriber Card related alarms - ont-pots : ONT Services POTS related alarms - ont-lan : ONT Services LAN related alarms - ont-moca : ONT MoCA related alarms - ont-tc-tca : ONT TC TCA related alarms - ont-moca-tca : ONT MoCA TCA related alarms - ont-l2uni-eth-tca : ONT L2 UNI Ethernet TCA related alarms - olt-pon-tc-tca : OLT PON TC TCA related alarms - olt-pon-util-tca : OLT PON utilization TCA related alarms - olt-chpr-util-tca : OLT channel-pair utilization TCA related alarms - olt-ont-tc-tca : OLT ONT TC TCA related alarms - ont-tca : ONT TCA related alarms - ont-pots-supplemental : ONT POTS Supplemental related alarms - sfu-ploam : SFU ONT PLOAM related alarms - sfu-gen : SFU ONT general related alarms - soho-ploam : SOHO ONT PLOAM related alarms - soho-gen : SOHO ONT general related alarms	

name	Type	Description
	- mdu-ploam : MDU ONT PLOAM related alarms - mdu-gen : MDU ONT general related alarms - ont-veip : ONT VEIP related alarms - ont-iphost : ONT IP HOST related alarms - alarm-table : alarm table related alarms - auto-switch : auto-switch related alarms - channel-pair : channel pair related alarms - ont-cfg-dld : ont configure file download related alarms - olt-chpair-tc-tca : OLT CHANNELPAIR TC TCA related alarms - hgu-tr069 : hgu tr069 related alarms - eqpt-psu : equipment psu alarms - ont-protection : ONT protection related alarms - secondary-megaco-term : secondary megaco termination related alarms - secondary-sip-term : secondary sip termination related alarms - cas-r2-channel : CAS R2 channel related alarms - lldpmed : lldpmed alarms - pseudo-wire : pseudo Wire related alarms - link-agg : Link aggregation related alarms - fcs-exceed : FCS auto-recovery related alarms - e1t1-interface : E1/T1 physical interfaces related alarms	
name	Parameter type: <Alarm::almtypeOltpontctcaihub> (olt-pon-tc-err-frag-tc olt-pon-up-bw-tca olt-pon-down-bw-tca all) Possible values: - olt-pon-tc-err-frag-tc: pon errored fragments threshold crossed - olt-pon-up-bw-tca : OLT PON upstream bandwidth TCA - olt-pon-down-bw-tca : OLT PON downstream bandwidth TCA - all : OLT PON TC TCA related alarms	alarm name that are active <i>This element is only shown in detail mode.</i>
severity	Parameter type: <Alarm::AlarmSeverity> (indeterminate warning minor major critical) Possible values: - indeterminate : alarm severity is indeterminate - warning : alarm severity is warning - minor : alarm severity is minor - major : alarm severity is major - critical : alarm severity is critical	the alarms severity level <i>This element is only shown in detail mode.</i>
servaff	Parameter type: <Alarm::alarmServAffect> ((service-affecting yes) (noservice-affecting no)) Possible values: - service-affecting : make this alarm service affecting - yes : make this alarm service affecting - noservice-affecting : make this alarm not service affecting - no : make this alarm not service affecting	alarms affect service or not <i>This element is only shown in detail mode.</i>
location	Parameter type: <Alarm::almLocation> (near-end	alarm location: near, middle, far <i>This element is only shown in</i>

101 query current alarms by filters

name	Type	Description
	far-end middle-end line null) Possible values: - near-end : alarm location is near - far-end : alarm location is far - middle-end : alarm location is middle - line : alarm location is line - null : alarm location not defined	<i>detail mode.</i>
time	Parameter type: <Sys::timeInSecs> - the time (yyyy-mm-dd:hour:minutes:secs) - unit: UTC	time in seconds when alarm was updated <i>This element is only shown in detail mode.</i>
direction	Parameter type: <Alarm::almDirection> (received transmit null) Possible values: - received : alarm is received - transmit : alarm is transmit - null : direction not defined	alarm direction: received or transmit <i>This element is only shown in detail mode.</i>
descript	Parameter type: <Alarm::AddInfoString> - additional alarm information	alarm description <i>This element is only shown in detail mode.</i>

101.73 show current alarm by filters

Command Description

show current alarms by filters

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm query olt-ont-tc-tca [ (name) [ severity <Alarm::querySeverity> ] [ servaff
<Alarm::queryServAffect> ] [ ont <Gpon::OntIndex> ] ]
```

Command Parameters

Table 101.73-1 "show current alarm by filters" Resource Parameters

Resource Identifier	Type	Description
(name)	Format: (olt-ont-tc-err-frag-tc all) Possible values: - olt-ont-tc-err-frag-tc: ont errored fragments threshold crossed - all : OLT ONT TC TCA related alarms	alarm name of olt ont tc tca
severity	Parameter type: <Alarm::querySeverity> Format: (indeterminate warning minor major critical all) Possible values: - indeterminate : alarm severity is indeterminate - warning : alarm severity is warning - minor : alarm severity is minor - major : alarm severity is major - critical : alarm severity is critical - all : all alarm severity	severity level of an alarm for reporting
servaff	Parameter type: <Alarm::queryServAffect> Format: (service-affecting noservice-affecting all) Possible values:	serviceaffecting no

101 query current alarms by filters

Resource Identifier	Type	Description
	- service-affecting : query alarm service affecting - noservice-affecting : query alarm not service affecting - all : query service affecting and not affecting alarms	
ont	Parameter type: <Gpon::OntIndex> Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> ng2 : <Ng2::ChannelGroup> / <Ng2::SubchannelGroup> / <Ng2::OntId>) Possible values: - ng2 : ngpon2 style identification Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Ng2::ChannelGroup> - channel group number Field type <Ng2::SubchannelGroup> - subchannel group number Field type <Eqpt::OntId> - the ONT identifier Field type <Ng2::OntId> - the ONT identifier	gpon ont equipment ifindex of ont

Command Output

Table 101.73-2 "show current alarm by filters" Display parameters

Specific Information		
name	Type	Description
aidinfo	Parameter type: <Alarm::AddInfoString> - additional alarm information	alarm AID parameters <i>This element is only shown in detail mode.</i>
type	Parameter type: <Alarm::alarmIHUBType> (equipment eqpt-holder plug-in-unit atm custom e1 ima-group ima-link redundancy shdsl ether-itf traffic-overflow qos-queue temporal spatial (software-mngt sw-mgmt) xdsl xdsl-ext xdsl-tca	type of the alarms that are active <i>This element is only shown in detail mode.</i>

name	Type	Description
	olt-gen	
	eo-conv	
	authentication	
	bonding	
	sfp	
	shdsl-isam	
	custom-ext-alarm	
	plug-in-unit-ext	
	sip-user-agent	
	sip-plugin-unit	
	sip-termination	
	e1-sip-termination	
	filetransfer	
	external-device	
	l2forward	
	ether-tca	
	ether-sfp	
	megaco-media-gw	
	megaco-sig-gw	
	megaco-plug-unit	
	megaco-term	
	megaco-sig-lt	
	eqpt-supplemental	
	eqpt-holder-ext	
	lsmredundancy	
	sync	
	mcsrc	
	vlanport	
	vect-line	
	vect-board	
	otdr	
	sip-dial-plan	
	sip-vsp	
	sip-server	
	bgp	
	rip	
	lag	
	ihub-general	
	vprn	
	isis	
	ospf	
	ihub-l2forward	
	vpls	
	ihub-equip	
	ihub-link	
	eont-phyoam	
	ellid	
	epon	
	eont-services-lan	
	eolt-ont-tca	
	eont-sw-dl	
	ldp	
	mpls	
	sdp	
	epipe	
	ihub-ipv6	
	pim	

101 query current alarms by filters

name	Type	Description
	li	
	mgmt-sec-access	
	bfd	
	ai	
	tr069serv	
	ontsnmp	
	bulk-sync	
	protection-group	
	ont	
	sfu-sup	
	soho-sup	
	mdu-sup	
	ont-ani	
	sfu-sup2	
	soho-sup2	
	mdu-sup2	
	sfprssi	
	eoltrssi	
	cfm	
	sfpe1t1-framer	
	sfpe1t1-clock	
	pppcc-engine-tca	
	eth-cfm	
	rsvp	
	ihub-tca	
	eth-ring	
	efm-oam	
	ont-loopdetect	
	ont-video	
	ont-ces	
	ont-voip	
	ont-video-ani	
	ont-pwe	
	ont-cese1	
	ont-xdsl	
	ont-xdsl-tca	
	ont-hpna	
	ont-sip-agent-cfg	
	ont-voip-cfg	
	ont-mgc	
	ont-ploam	
	ont-gen	
	ont-card	
	ont-pots	
	ont-lan	
	ont-moca	
	ont-tc-tca	
	ont-moca-tca	
	ont-l2uni-eth-tca	
	olt-pon-tc-tca	
	olt-pon-util-tca	
	olt-chpr-util-tca	
	olt-ont-tc-tca	
	ont-tca	
	ont-pots-supplemental	
	sfu-ploam	
	sfu-gen	

name	Type	Description
	soho-ploam soho-gen mdu-ploam mdu-gen ont-veip ont-iphost alarm-table auto-switch channel-pair ont-cfg-dld olt-chpair-tc-tca hgu-tr069 eqpt-psu ont-protection secondary-megaco-term secondary-sip-term cas-r2-channel lldpmed pseudo-wire link-agg fcs-exceed e1t1-interface) Possible values: - equipment : equipment alarms - eqpt-holder : equipment holder alarms - plug-in-unit : plugin unit alarms - atm : ATM alarms - custom : customizable alarms - e1 : e1 alarms - ima-group : ima-group alarms - ima-link : ima-link alarms - redundancy : redundancy alarms - shdsl : shdsl alarms - ether-itf : ethernet interface alarms - traffic-overflow : Traffic overflow alarms - qos-queue : qos queue alarms - temporal : temporal alarms - spatial : spatial alarms - software-mngt : software management alarms - sw-mgmt : software management alarms - xdsl : xDSL alarms - xdsl-ext : other xDSL alarms - xdsl-tca : xDSL threshold cross alarms - olt-gen : OLT general alarms - eo-conv : E/O conversion related alarms - authentication : authentication related alarms - bonding : bonding-group related alarms - sfp : SFP related alarms - shdsl-isam : shdsl isam alarms - custom-ext-alarm : customizable external alarms - plug-in-unit-ext : other plugin unit alarms - sip-user-agent : sip user agent related alarms - sip-plugin-unit : sip plug in unit related alarms - sip-termination : sip termination related alarms - e1-sip-termination : E1 sip termination related alarms - filetransfer : file transfer server alarms - external-device : external device related alarms	

101 query current alarms by filters

name	Type	Description
	- l2forward : l2forward related alarms - ether-tca : ethernet threshold cross alarms - ether-sfp : ethernet SFP related alarms - megaco-media-gw : megaco media gateway related alarms - megaco-sig-gw : megaco signaling gateway related alarms - megaco-plug-unit : megaco plug unit related alarms - megaco-term : megaco termination related alarms - megaco-sig-lt : megaco signaling lt related alarms - eqpt-supplemental : equipment supplemental alarms - eqpt-holder-ext : other equipment holder alarms - lsmredundancy : lsm redundancy alarms - sync : synce and bits alarms - mcsrc : multicast source alarms - vlanport : vlanport alarms - vect-line : xDSL vectoring line alarms - vect-board : xDSL vectoring board alarms - otdr : otdr alarms - sip-dial-plan : sip dial plan related alarms - sip-vsp : sip vsp related alarms - sip-server : sip server related alarms - bgp : bgp related alarms - rip : rip related alarms - lag : LAG related alarms - ihub-general : IHUB general related alarms - vprn : vprn related alarms - isis : isis related alarms - ospf : ospf related alarms - ihub-l2forward : ihub-l2forward alarms - vpls : vpls related alarms - ihub-equip : ihub-equip related alarms - ihub-link : ihub-link related alarms - eont-phyoam : eont phyoam related alarms - ellid : ellid related alarms - epon : epon related alarms - eont-services-lan : eon phyoam related alarms - eolt-ont-tca : eon phyoam related alarms - eont-sw-dl : eon phyoam related alarms - ldp : ldp related alarms - mpls : mpls related alarms - sdp : sdp related alarms - epipe : epipe related alarms - ihub-ipv6 : ihub-ipv6 related alarms - pim : pim related alarms - li : lawful intercept related alarms - mgmt-sec-access : management security related alarms - bfd : bfd related alarms - ai : Application Intelligence related alarms - tr069serv : tr069 server related alarms - ontsnmp : ont snmp related alarms - bulk-sync : bulk-sync related alarms - protection-group : port protection group related alarms - ont : ONT general supplemental related alarms - sfu-sup : SFU ONT general supplemental related alarms - soho-sup : SOHO ONT general supplemental related alarms - mdu-sup : MDU ONT general supplemental related alarms - ont-ani : ONT general supplemental 2 related alarms	

name	Type	Description
	- sfu-sup2 : SFU ONT general supplemental 2 related alarms - soho-sup2 : SOHO ONT general supplemental 2 related alarms - mdu-sup2 : MDU ONT general supplemental 2 related alarms - sfprssi : SFP RSSI related alarms - eoltrssi : epon olt Sfp RSSI related alarms - cfm : Cfm related alarms - sfpe1t1-framer : SFP 2e1t1 framer alarms - sfpe1t1-clock : SFP 2e1t1 clock alarms - pppcc-engine-tca : PPPOE Cross Connect Engine TCA related alarm - eth-cfm : eth-cfm related alarms - rsvp : rsvp related alarms - ihub-tca : IHUB TCA related alarms - eth-ring : eth-ring related alarms - efm-oam : EFM-OAM related alarms - ont-loopdetect : ont loop detect related alarms - ont-video : ont services video related alarms - ont-ces : ont services ces related alarms - ont-voip : ont services voip related alarms - ont-video-ani : ont services video ani related alarms - ont-pwe : ont services pwe related alarms - ont-cese1 : ont services cese1 related alarms - ont-xdsl : ont services xdsl related alarms - ont-xdsl-tca : ont services xdsl tca related alarms - ont-hpna : ont hpna related alarms - ont-sip-agent-cfg : ont services voip sip agent config related alarms - ont-voip-cfg : ont services voip config related alarms - ont-mgc : ont mgc related alarms - ont-ploam : ONT PLOAM related alarms - ont-gen : ONT GENERAL related alarms - ont-card : ONT Subscriber Card related alarms - ont-pots : ONT Services POTS related alarms - ont-lan : ONT Services LAN related alarms - ont-moca : ONT MoCA related alarms - ont-tc-tca : ONT TC TCA related alarms - ont-moca-tca : ONT MoCA TCA related alarms - ont-l2uni-eth-tca : ONT L2 UNI Ethernet TCA related alarms - olt-pon-tc-tca : OLT PON TC TCA related alarms - olt-pon-util-tca : OLT PON utilization TCA related alarms - olt-chpr-util-tca : OLT channel-pair utilization TCA related alarms - olt-ont-tc-tca : OLT ONT TC TCA related alarms - ont-tca : ONT TCA related alarms - ont-pots-supplemental : ONT POTS Supplemental related alarms - sfu-ploam : SFU ONT PLOAM related alarms - sfu-gen : SFU ONT general related alarms - soho-ploam : SOHO ONT PLOAM related alarms - soho-gen : SOHO ONT general related alarms - mdu-ploam : MDU ONT PLOAM related alarms - mdu-gen : MDU ONT general related alarms - ont-veip : ONT VEIP related alarms - ont-iphost : ONT IP HOST related alarms	

101 query current alarms by filters

name	Type	Description
	- alarm-table : alarm table related alarms - auto-switch : auto-switch related alarms - channel-pair : channel pair related alarms - ont-cfg-dld : ont configure file download related alarms - olt-chpair-tc-tca : OLT CHANNELPAIR TC TCA related alarms - hgu-tr069 : hgu tr069 related alarms - eqpt-psu : equipment psu alarms - ont-protection : ONT protection related alarms - secondary-megaco-term : secondary megaco termination related alarms - secondary-sip-term : secondary sip termination related alarms - cas-r2-channel : CAS R2 channel related alarms - lldpmed : lldpmed alarms - pseudo-wire : pseudo Wire related alarms - link-agg : Link aggregation related alarms - fcs-exceed : FCS auto-recovery related alarms - e1t1-interface : E1/T1 physical interfaces related alarms	
name	Parameter type: <Alarm::almTypeOltonttctcai> (olt-ont-tc-err-frag-tc all) Possible values: - olt-ont-tc-err-frag-tc: ont errored fragments threshold crossed - all : OLT ONT TC TCA related alarms	alarm name that are active <i>This element is only shown in detail mode.</i>
severity	Parameter type: <Alarm::AlarmSeverity> (indeterminate warning minor major critical) Possible values: - indeterminate : alarm severity is indeterminate - warning : alarm severity is warning - minor : alarm severity is minor - major : alarm severity is major - critical : alarm severity is critical	the alarms severity level <i>This element is only shown in detail mode.</i>
servaff	Parameter type: <Alarm::alarmServAffect> ((service-affecting yes) (noservice-affecting no)) Possible values: - service-affecting : make this alarm service affecting - yes : make this alarm service affecting - noservice-affecting : make this alarm not service affecting - no : make this alarm not service affecting	alarms affect service or not <i>This element is only shown in detail mode.</i>
location	Parameter type: <Alarm::almLocation> (near-end far-end middle-end line null) Possible values: - near-end : alarm location is near - far-end : alarm location is far - middle-end : alarm location is middle - line : alarm location is line	alarm location: near, middle, far <i>This element is only shown in detail mode.</i>

101 query current alarms by filters

name	Type	Description
	- null : alarm location not defined	
time	Parameter type: <Sys::timeInSecs> - the time (yyyy-mm-dd:hour:minutes:secs) - unit: UTC	time in seconds when alarm was updated <i>This element is only shown in detail mode.</i>
direction	Parameter type: <Alarm::almDirection> (received transmit null) Possible values: - received : alarm is received - transmit : alarm is transmit - null : direction not defined	alarm direction: received or transmit <i>This element is only shown in detail mode.</i>
descript	Parameter type: <Alarm::AddInfoString> - additional alarm information	alarm description <i>This element is only shown in detail mode.</i>

101.74 show current alarm by filters

Command Description

show current alarms by filters

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm query ont-pwe [ (name) [ severity <Alarm::querySeverity> ] [ servaff <Alarm::queryServAffect> ] [
ont-ces-uni <Ces::InterfaceIndex> ] ]
```

Command Parameters

Table 101.74-1 "show current alarm by filters" Resource Parameters

Resource Identifier	Type	Description
(name)	Format: (ont-svc-pwe-mismatch ont-svc-pwe-reordr-lof ont-svc-pwe-jitt-buf-o ont-svc-pwe-jitt-buf-u ont-svc-pwe-malf-frms ont-svc-pwe-late-frms ont-svc-pwe-link-loss ont-svc-pwe-arp-fail all) Possible values: - ont-svc-pwe-mismatch : service mismatch for provisioned pseudowire - ont-svc-pwe-reordr-lof: pseudowire reordering and loss of frame - ont-svc-pwe-jitt-buf-o: pseudowire jitter buffer overrun - ont-svc-pwe-jitt-buf-u: pseudowire jitter buffer underrun - ont-svc-pwe-malf-frms : pseudowire malformed frames - ont-svc-pwe-late-frms : pseudowire late frames - ont-svc-pwe-link-loss : pseudowire link loss - ont-svc-pwe-arp-fail : pseudowire arp failure - all : ont services pwe related alarms	alarm name of ont pwe
severity	Parameter type: <Alarm::querySeverity> Format: (indeterminate warning minor major	severity level of an alarm for reporting

Resource Identifier	Type	Description
	critical all) Possible values: - indeterminate : alarm severity is indeterminate - warning : alarm severity is warning - minor : alarm severity is minor - major : alarm severity is major - critical : alarm severity is critical - all : all alarm severity	
servaff	Parameter type: <Alarm::queryServAffect> Format: (service-affecting noservice-affecting all) Possible values: - service-affecting : query alarm service affecting - noservice-affecting : query alarm not service affecting - all : query service affecting and not affecting alarms	serviceaffecting no serviceaffecting
ont-ces-uni	Parameter type: <Ces::InterfaceIndex> Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> / <Eqpt::OntPortId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Eqpt::OntId> - the ONT identifier Field type <Eqpt::OntSlotId> - the ONT SLOT identifier Field type <Eqpt::OntPortId> - the ONT PORT identifier	the physical number of the port

Command Output

Table 101.74-2 "show current alarm by filters" Display parameters

Specific Information		
name	Type	Description
aidinfo	Parameter type: <Alarm::AddInfoString> - additional alarm information	alarm AID parameters <i>This element is only shown in detail mode.</i>
type	Parameter type: <Alarm::alarmIHUBType> (equipment eqpt-holder plug-in-unit atm custom e1 ima-group ima-link redundancy	type of the alarms that are active <i>This element is only shown in detail mode.</i>

101 query current alarms by filters

name	Type	Description
	shdsl	
	ether-itf	
	traffic-overflow	
	qos-queue	
	temporal	
	spatial	
	(software-mngt sw-mgmt)	
	xdsl	
	xdsl-ext	
	xdsl-tca	
	olt-gen	
	eo-conv	
	authentication	
	bonding	
	sfp	
	shdsl-isam	
	custom-ext-alarm	
	plug-in-unit-ext	
	sip-user-agent	
	sip-plugin-unit	
	sip-termination	
	e1-sip-termination	
	filetransfer	
	external-device	
	l2forward	
	ether-tca	
	ether-sfp	
	megaco-media-gw	
	megaco-sig-gw	
	megaco-plug-unit	
	megaco-term	
	megaco-sig-lt	
	eqpt-supplemental	
	eqpt-holder-ext	
	lsmredundancy	
	sync	
	mcsrc	
	vlanport	
	vect-line	
	vect-board	
	otdr	
	sip-dial-plan	
	sip-vsp	
	sip-server	
	bgp	
	rip	
	lag	
	ihub-general	
	vprn	
	isis	
	ospf	
	ihub-l2forward	
	vpls	
	ihub-equip	
	ihub-link	
	eont-phyoam	
	ellid	

name	Type	Description
	epon eont-services-lan eolt-ont-tca eont-sw-dl ldp mpls sdp epipe ihub-ipv6 pim li mgmt-sec-access bfd ai tr069serv ontsnmp bulk-sync protection-group ont sfu-sup soho-sup mdu-sup ont-ani sfu-sup2 soho-sup2 mdu-sup2 sfprssi eoltrssi cfm sfpe1t1-framer sfpe1t1-clock pppcc-engine-tca eth-cfm rsvp ihub-tca eth-ring efm-oam ont-loopdetect ont-video ont-ces ont-voip ont-video-ani ont-pwe ont-cese1 ont-xdsl ont-xdsl-tca ont-hpna ont-sip-agent-cfg ont-voip-cfg ont-mgc ont-ploam ont-gen ont-card ont-pots ont-lan ont-moca ont-tc-tca	

101 query current alarms by filters

name	Type	Description
	ont-moca-tca ont-l2uni-eth-tca olt-pon-tc-tca olt-pon-util-tca olt-chpr-util-tca olt-ont-tc-tca ont-tca ont-pots-supplemental sfu-ploam sfu-gen soho-ploam soho-gen mdu-ploam mdu-gen ont-veip ont-iphost alarm-table auto-switch channel-pair ont-cfg-dld olt-chpair-tc-tca hgu-tr069 eqpt-psu ont-protection secondary-megaco-term secondary-sip-term cas-r2-channel lldpmed pseudo-wire link-agg fcs-exceed e1t1-interface) Possible values: - equipment : equipment alarms - eqpt-holder : equipment holder alarms - plug-in-unit : plugin unit alarms - atm : ATM alarms - custom : customizable alarms - e1 : e1 alarms - ima-group : ima-group alarms - ima-link : ima-link alarms - redundancy : redundancy alarms - shdsl : shdsl alarms - ether-itf : ethernet interface alarms - traffic-overflow : Traffic overflow alarms - qos-queue : qos queue alarms - temporal : temporal alarms - spatial : spatial alarms - software-mngt : software management alarms - sw-mgmt : software management alarms - xdsl : xDSL alarms - xdsl-ext : other xDSL alarms - xdsl-tca : xDSL threshold cross alarms - olt-gen : OLT general alarms - eo-conv : E/O conversion related alarms - authentication : authentication related alarms - bonding : bonding-group related alarms	

name	Type	Description
	- sfp : SFP related alarms - shdsl-isam : shdsl isam alarms - custom-ext-alarm : customizable external alarms - plug-in-unit-ext : other plugin unit alarms - sip-user-agent : sip user agent related alarms - sip-plugin-unit : sip plug in unit related alarms - sip-termination : sip termination related alarms - e1-sip-termination : E1 sip termination related alarms - filetransfer : file transfer server alarms - external-device : external device related alarms - l2forward : l2forward related alarms - ether-tca : ethernet threshold cross alarms - ether-sfp : ethernet SFP related alarms - megaco-media-gw : megaco media gateway related alarms - megaco-sig-gw : megaco signaling gateway related alarms - megaco-plug-unit : megaco plug unit related alarms - megaco-term : megaco termination related alarms - megaco-sig-lt : megaco signaling lt related alarms - eqpt-supplemental : equipment supplemental alarms - eqpt-holder-ext : other equipment holder alarms - lsmredundancy : lsm redundancy alarms - sync : synce and bits alarms - mcsrc : multicast source alarms - vlanport : vlanport alarms - vect-line : xDSL vectoring line alarms - vect-board : xDSL vectoring board alarms - otdr : otdr alarms - sip-dial-plan : sip dial plan related alarms - sip-vsp : sip vsp related alarms - sip-server : sip server related alarms - bgp : bgp related alarms - rip : rip related alarms - lag : LAG related alarms - ihub-general : IHUB general related alarms - vprn : vprn related alarms - isis : isis related alarms - ospf : ospf related alarms - ihub-l2forward : ihub-l2forward alarms - vpls : vpls related alarms - ihub-equip : ihub-equip related alarms - ihub-link : ihub-link related alarms - eont-phyoam : eont phyoam related alarms - ellid : ellid related alarms - epon : epon related alarms - eont-services-lan : eon phyoam related alarms - eolt-ont-tca : eon phyoam related alarms - eont-sw-dl : eon phyoam related alarms - ldp : ldp related alarms - mpls : mpls related alarms - sdp : sdp related alarms - epipe : epipe related alarms - ihub-ipv6 : ihub-ipv6 related alarms - pim : pim related alarms - li : lawful intercept related alarms - mgmt-sec-access : management security related alarms - bfd : bfd related alarms - ai : Application Intelligence related alarms	

101 query current alarms by filters

name	Type	Description
	- tr069serv : tr069 server related alarms - ontsnmp : ont snmp related alarms - bulk-sync : bulk-sync related alarms - protection-group : port protection group related alarms - ont : ONT general supplemental related alarms - sfu-sup : SFU ONT general supplemental related alarms - soho-sup : SOHO ONT general supplemental related alarms - mdu-sup : MDU ONT general supplemental related alarms - ont-ani : ONT general supplemental 2 related alarms - sfu-sup2 : SFU ONT general supplemental 2 related alarms - soho-sup2 : SOHO ONT general supplemental 2 related alarms - mdu-sup2 : MDU ONT general supplemental 2 related alarms - sfrssi : SFP RSSI related alarms - eoltrssi : epon olt Sfp RSSI related alarms - cfm : Cfm related alarms - sfpe1t1-framer : SFP 2e1t1 framer alarms - sfpe1t1-clock : SFP 2e1t1 clock alarms - pppcc-engine-tca : PPPOE Cross Connect Engine TCA related alarm - eth-cfm : eth-cfm related alarms - rsvp : rsvp related alarms - ihub-tca : IHUB TCA related alarms - eth-ring : eth-ring related alarms - efm-oam : EFM-OAM related alarms - ont-loopdetect : ont loop detect related alarms - ont-video : ont services video related alarms - ont-ces : ont services ces related alarms - ont-voip : ont services voip related alarms - ont-video-ani : ont services video ani related alarms - ont-pwe : ont services pwe related alarms - ont-cese1 : ont services cese1 related alarms - ont-xdsl : ont services xdsl related alarms - ont-xdsl-tca : ont services xdsl tca related alarms - ont-hpna : ont hpna related alarms - ont-sip-agent-cfg : ont services voip sip agent config related alarms - ont-voip-cfg : ont services voip config related alarms - ont-mgc : ont mgc related alarms - ont-ploam : ONT PLOAM related alarms - ont-gen : ONT GENERAL related alarms - ont-card : ONT Subscriber Card related alarms - ont-pots : ONT Services POTS related alarms - ont-lan : ONT Services LAN related alarms - ont-moca : ONT MoCA related alarms - ont-tc-tca : ONT TC TCA related alarms - ont-moca-tca : ONT MoCA TCA related alarms - ont-l2uni-eth-tca : ONT L2 UNI Ethernet TCA related alarms - olt-pon-tc-tca : OLT PON TC TCA related alarms - olt-pon-util-tca : OLT PON utilization TCA related alarms - olt-chpr-util-tca : OLT channel-pair utilization TCA related alarms - olt-ont-tc-tca : OLT ONT TC TCA related alarms - ont-tca : ONT TCA related alarms	

name	Type	Description
	- ont-pots-supplemental : ONT POTS Supplemental related alarms - sfu-ploam : SFU ONT PLOAM related alarms - sfu-gen : SFU ONT general related alarms - soho-ploam : SOHO ONT PLOAM related alarms - soho-gen : SOHO ONT general related alarms - mdu-ploam : MDU ONT PLOAM related alarms - mdu-gen : MDU ONT general related alarms - ont-veip : ONT VEIP related alarms - ont-iphost : ONT IP HOST related alarms - alarm-table : alarm table related alarms - auto-switch : auto-switch related alarms - channel-pair : channel pair related alarms - ont-cfg-dld : ont configure file download related alarms - olt-chpair-tc-tca : OLT CHANNELPAIR TC TCA related alarms - hgu-tr069 : hgu tr069 related alarms - eqpt-psu : equipment psu alarms - ont-protection : ONT protection related alarms - secondary-megaco-term : secondary megaco termination related alarms - secondary-sip-term : secondary sip termination related alarms - cas-r2-channel : CAS R2 channel related alarms - lldpmed : lldpmed alarms - pseudo-wire : pseudo Wire related alarms - link-agg : Link aggregation related alarms - fcs-exceed : FCS auto-recovery related alarms - e1t1-interface : E1/T1 physical interfaces related alarms	
name	Parameter type: <Alarm::almtypOntpweihub> (ont-svc-pwe-mismatch ont-svc-pwe-reordr-lof ont-svc-pwe-jitt-buf-o ont-svc-pwe-jitt-buf-u ont-svc-pwe-malf-frms ont-svc-pwe-late-frms ont-svc-pwe-link-loss ont-svc-pwe-arp-fail all) Possible values: - ont-svc-pwe-mismatch : service mismatch for provisioned pseudowire - ont-svc-pwe-reordr-lof: pseudowire reordering and loss of frame - ont-svc-pwe-jitt-buf-o: pseudowire jitter buffer overrun - ont-svc-pwe-jitt-buf-u: pseudowire jitter buffer underrun - ont-svc-pwe-malf-frms : pseudowire malformed frames - ont-svc-pwe-late-frms : pseudowire late frames - ont-svc-pwe-link-loss : pseudowire link loss - ont-svc-pwe-arp-fail : pseudowire arp failure - all : ont services pwe related alarms	alarm name that are active <i>This element is only shown in detail mode.</i>
severity	Parameter type: <Alarm::AlarmSeverity> (indeterminate warning minor major critical)	the alarms severity level <i>This element is only shown in detail mode.</i>

101 query current alarms by filters

name	Type	Description
	Possible values: - indeterminate : alarm severity is indeterminate - warning : alarm severity is warning - minor : alarm severity is minor - major : alarm severity is major - critical : alarm severity is critical	
servaff	Parameter type: <Alarm::alarmServAffect> ((service-affecting yes) (noservice-affecting no)) Possible values: - service-affecting : make this alarm service affecting - yes : make this alarm service affecting - noservice-affecting : make this alarm not service affecting - no : make this alarm not service affecting	alarms affect service or not <i>This element is only shown in detail mode.</i>
time	Parameter type: <Sys::timeInSecs> - the time (yyyy-mm-dd:hour:minutes:secs) - unit: UTC	time in seconds when alarm was updated <i>This element is only shown in detail mode.</i>
descript	Parameter type: <Alarm::AddInfoString> - additional alarm information	alarm description <i>This element is only shown in detail mode.</i>

101.75 show current alarm by filters

Command Description

show current alarms by filters

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm query ont-cese1 [ (name) [ severity <Alarm::querySeverity> ] [ servaff <Alarm::queryServAffect> ] [ ces-port <Alarm::queryDefaultAid> ] ]
```

Command Parameters

Table 101.75-1 "show current alarm by filters" Resource Parameters

Resource Identifier	Type	Description
(name)	Format: (ont-svc-ces-e1-mis ont-svc-ces-e1-los ont-svc-ces-e1-lof ont-svc-ces-e1-rair ont-svc-ces-e1-ais all) Possible values: - ont-svc-ces-e1-mis : ont service mismatch for provisioned ces e1 - ont-svc-ces-e1-los : loss of signal at e1 interface - ont-svc-ces-e1-lof : loss of frame at e1 interface - ont-svc-ces-e1-rair : receiving rai at e1 interface - ont-svc-ces-e1-ais : receiving ais at e1 interface - all : ont services cese1 related alarms	alarm name of ont cese1
severity	Parameter type: <Alarm::querySeverity> Format: (indeterminate warning minor major critical all) Possible values: - indeterminate : alarm severity is indeterminate - warning : alarm severity is warning - minor : alarm severity is minor - major : alarm severity is major	severity level of an alarm for reporting

101 query current alarms by filters

Resource Identifier	Type	Description
	- critical : alarm severity is critical - all : all alarm severity	
servaff	Parameter type: <Alarm::queryServAffect> Format: (service-affecting noservice-affecting all) Possible values: - service-affecting : query alarm service affecting - noservice-affecting : query alarm not service affecting - all : query service affecting and not affecting alarms	serviceaffecting no serviceaffecting
ces-port	Parameter type: <Alarm::queryDefaultAid> Format: all Possible values: - all : default AID parameter	all ces port

Command Output

Table 101.75-2 "show current alarm by filters" Display parameters

Specific Information		
name	Type	Description
aidinfo	Parameter type: <Alarm::AddInfoString> - additional alarm information	alarm AID parameters <i>This element is only shown in detail mode.</i>
type	Parameter type: <Alarm::alarmIHUBType> (equipment eqpt-holder plug-in-unit atm custom e1 ima-group ima-link redundancy shdsl ether-itf traffic-overflow qos-queue temporal spatial (software-mngt sw-mgmt) xdsl xdsl-ext xdsl-tca olt-gen eo-conv authentication bonding sfp shdsl-isam custom-ext-alarm plug-in-unit-ext sip-user-agent sip-plugin-unit sip-termination	type of the alarms that are active <i>This element is only shown in detail mode.</i>

name	Type	Description
	e1-sip-termination filetransfer external-device l2forward ether-tca ether-sfp megaco-media-gw megaco-sig-gw megaco-plug-unit megaco-term megaco-sig-lt eqpt-supplemental eqpt-holder-ext lsmredundancy sync mcsrc vlanport vect-line vect-board otdr sip-dial-plan sip-vsp sip-server bgp rip lag ihub-general vprn isis ospf ihub-l2forward vpls ihub-equip ihub-link eont-phyoam ellid epon eont-services-lan eolt-ont-tca eont-sw-dl ldp mpls sdp epipe ihub-ipv6 pim li mgmt-sec-access bfd ai tr069serv ontsnmp bulk-sync protection-group ont sfu-sup soho-sup	

101 query current alarms by filters

name	Type	Description
	mdu-sup ont-ani sfu-sup2 soho-sup2 mdu-sup2 sfprssi eoltrssi cfm sfpe1t1-framer sfpe1t1-clock pppcc-engine-tca eth-cfm rsvp ihub-tca eth-ring efm-oam ont-loopdetect ont-video ont-ces ont-voip ont-video-ani ont-pwe ont-cese1 ont-xdsl ont-xdsl-tca ont-hpna ont-sip-agent-cfg ont-voip-cfg ont-mgc ont-ploam ont-gen ont-card ont-pots ont-lan ont-moca ont-tc-tca ont-moca-tca ont-l2uni-eth-tca olt-pon-tc-tca olt-pon-util-tca olt-chpr-util-tca olt-ont-tc-tca ont-tca ont-pots-supplemental sfu-ploam sfu-gen soho-ploam soho-gen mdu-ploam mdu-gen ont-veip ont-iphost alarm-table auto-switch channel-pair ont-cfg-dld olt-chpair-tc-tca	

name	Type	Description
	hgu-tr069 eqpt-psu ont-protection secondary-megaco-term secondary-sip-term cas-r2-channel lldpmed pseudo-wire link-agg fcs-exceed e1t1-interface) Possible values: - equipment : equipment alarms - eqpt-holder : equipment holder alarms - plug-in-unit : plugin unit alarms - atm : ATM alarms - custom : customizable alarms - e1 : e1 alarms - ima-group : ima-group alarms - ima-link : ima-link alarms - redundancy : redundancy alarms - shdsl : shdsl alarms - ether-itf : ethernet interface alarms - traffic-overflow : Traffic overflow alarms - qos-queue : qos queue alarms - temporal : temporal alarms - spatial : spatial alarms - software-mngt : software management alarms - sw-mgmt : software management alarms - xdsl : xDSL alarms - xdsl-ext : other xDSL alarms - xdsl-tca : xDSL threshold cross alarms - olt-gen : OLT general alarms - eo-conv : E/O conversion related alarms - authentication : authentication related alarms - bonding : bonding-group related alarms - sfp : SFP related alarms - shdsl-isam : shdsl isam alarms - custom-ext-alarm : customizable external alarms - plug-in-unit-ext : other plugin unit alarms - sip-user-agent : sip user agent related alarms - sip-plugin-unit : sip plug in unit related alarms - sip-termination : sip termination related alarms - e1-sip-termination : E1 sip termination related alarms - filetransfer : file transfer server alarms - external-device : external device related alarms - l2forward : l2forward related alarms - ether-tca : ethernet threshold cross alarms - ether-sfp : ethernet SFP related alarms - megaco-media-gw : megaco media gateway related alarms - megaco-sig-gw : megaco signaling gateway related alarms - megaco-plug-unit : megaco plug unit related alarms - megaco-term : megaco termination related alarms - megaco-sig-lt : megaco signaling lt related alarms - eqpt-supplemental : equipment supplemental alarms - eqpt-holder-ext : other equipment holder alarms - lsmredundancy : lsm redundancy alarms	

101 query current alarms by filters

name	Type	Description
	- sync : synce and bits alarms - msrc : multicast source alarms - vlanport : vlanport alarms - vect-line : xDSL vectoring line alarms - vect-board : xDSL vectoring board alarms - otdr : otdr alarms - sip-dial-plan : sip dial plan related alarms - sip-vsp : sip vsp related alarms - sip-server : sip server related alarms - bgp : bgp related alarms - rip : rip related alarms - lag : LAG related alarms - ihub-general : IHUB general related alarms - vprn : vprn related alarms - isis : isis related alarms - ospf : ospf related alarms - ihub-l2forward : ihub-l2forward alarms - vpls : vpls related alarms - ihub-equip : ihub-equip related alarms - ihub-link : ihub-link related alarms - eont-phyoam : eont phyoam related alarms - ellid : ellid related alarms - epon : epon related alarms - eont-services-lan : eon phyoam related alarms - eolt-ont-tca : eon phyoam related alarms - eont-sw-dl : eon phyoam related alarms - ldp : ldp related alarms - mpls : mpls related alarms - sdp : sdp related alarms - epipe : epipe related alarms - ihub-ipv6 : ihub-ipv6 related alarms - pim : pim related alarms - li : lawful intercept related alarms - mgmt-sec-access : management security related alarms - bfd : bfd related alarms - ai : Application Intelligence related alarms - tr069serv : tr069 server related alarms - ontsnmp : ont snmp related alarms - bulk-sync : bulk-sync related alarms - protection-group : port protection group related alarms - ont : ONT general supplemental related alarms - sfu-sup : SFU ONT general supplemental related alarms - soho-sup : SOHO ONT general supplemental related alarms - mdu-sup : MDU ONT general supplemental related alarms - ont-ani : ONT general supplemental 2 related alarms - sfu-sup2 : SFU ONT general supplemental 2 related alarms - soho-sup2 : SOHO ONT general supplemental 2 related alarms - mdu-sup2 : MDU ONT general supplemental 2 related alarms - sfprssi : SFP RSSI related alarms - eoltrssi : epon olt Sfp RSSI related alarms - cfm : Cfm related alarms - sfpe1t1-framer : SFP 2e1t1 framer alarms - sfpe1t1-clock : SFP 2e1t1 clock alarms - pppcc-engine-tca : PPPOE Cross Connect Engine TCA	

name	Type	Description
	related alarm - eth-cfm : eth-cfm related alarms - rsvp : rsvp related alarms - ihub-tca : IHUB TCA related alarms - eth-ring : eth-ring related alarms - efm-oam : EFM-OAM related alarms - ont-loopdetect : ont loop detect related alarms - ont-video : ont services video related alarms - ont-ces : ont services ces related alarms - ont-voip : ont services voip related alarms - ont-video-ani : ont services video ani related alarms - ont-pwe : ont services pwe related alarms - ont-cese1 : ont services cese1 related alarms - ont-xdsl : ont services xdsl related alarms - ont-xdsl-tca : ont services xdsl tca related alarms - ont-hpna : ont hpna related alarms - ont-sip-agent-cfg : ont services voip sip agent config related alarms - ont-voip-cfg : ont services voip config related alarms - ont-mgc : ont mgc related alarms - ont-ploam : ONT PLOAM related alarms - ont-gen : ONT GENERAL related alarms - ont-card : ONT Subscriber Card related alarms - ont-pots : ONT Services POTS related alarms - ont-lan : ONT Services LAN related alarms - ont-moca : ONT MoCA related alarms - ont-tc-tca : ONT TC TCA related alarms - ont-moca-tca : ONT MoCA TCA related alarms - ont-l2uni-eth-tca : ONT L2 UNI Ethernet TCA related alarms - olt-pon-tc-tca : OLT PON TC TCA related alarms - olt-pon-util-tca : OLT PON utilization TCA related alarms - olt-chpr-util-tca : OLT channel-pair utilization TCA related alarms - olt-ont-tc-tca : OLT ONT TC TCA related alarms - ont-tca : ONT TCA related alarms - ont-pots-supplemental : ONT POTS Supplemental related alarms - sfu-ploam : SFU ONT PLOAM related alarms - sfu-gen : SFU ONT general related alarms - soho-ploam : SOHO ONT PLOAM related alarms - soho-gen : SOHO ONT general related alarms - mdu-ploam : MDU ONT PLOAM related alarms - mdu-gen : MDU ONT general related alarms - ont-veip : ONT VEIP related alarms - ont-iphost : ONT IP HOST related alarms - alarm-table : alarm table related alarms - auto-switch : auto-switch related alarms - channel-pair : channel pair related alarms - ont-cfg-dld : ont configure file download related alarms - olt-chpair-tc-tca : OLT CHANNELPAIR TC TCA related alarms - hgu-tr069 : hgu tr069 related alarms - eqpt-psu : equipment psu alarms - ont-protection : ONT protection related alarms - secondary-megaco-term : secondary megaco termination related alarms	

101 query current alarms by filters

name	Type	Description
	- secondary-sip-term : secondary sip termination related alarms - cas-r2-channel : CAS R2 channel related alarms - lldpmed : lldpmed alarms - pseudo-wire : pseudo Wire related alarms - link-agg : Link aggregation related alarms - fcs-exceed : FCS auto-recovery related alarms - e1t1-interface : E1/T1 physical interfaces related alarms	
name	Parameter type: <Alarm::almtypeOntcese1ihub> (ont-svc-ces-e1-mis ont-svc-ces-e1-los ont-svc-ces-e1-lof ont-svc-ces-e1-rair ont-svc-ces-e1-ais all) Possible values: - ont-svc-ces-e1-mis : ont service mismatch for provisioned ces e1 - ont-svc-ces-e1-los : loss of signal at e1 interface - ont-svc-ces-e1-lof : loss of frame at e1 interface - ont-svc-ces-e1-rair : receiving rai at e1 interface - ont-svc-ces-e1-ais : receiving ais at e1 interface - all : ont services cese1 related alarms	alarm name that are active <i>This element is only shown in detail mode.</i>
severity	Parameter type: <Alarm::AlarmSeverity> (indeterminate warning minor major critical) Possible values: - indeterminate : alarm severity is indeterminate - warning : alarm severity is warning - minor : alarm severity is minor - major : alarm severity is major - critical : alarm severity is critical	the alarms severity level <i>This element is only shown in detail mode.</i>
servaff	Parameter type: <Alarm::alarmServAffect> ((service-affecting yes) (noservice-affecting no)) Possible values: - service-affecting : make this alarm service affecting - yes : make this alarm service affecting - noservice-affecting : make this alarm not service affecting - no : make this alarm not service affecting	alarms affect service or not <i>This element is only shown in detail mode.</i>
location	Parameter type: <Alarm::almLocation> (near-end far-end middle-end line null) Possible values: - near-end : alarm location is near - far-end : alarm location is far - middle-end : alarm location is middle - line : alarm location is line - null : alarm location not defined	alarm location: near, middle, far <i>This element is only shown in detail mode.</i>
time	Parameter type: <Sys::timeInSecs> - the time (yyyy-mm-dd:hour:minutes:secs)	time in seconds when alarm was updated

101 query current alarms by filters

name	Type	Description
	- unit: UTC	<i>This element is only shown in detail mode.</i>
direction	Parameter type: <Alarm::almDirection> (received transmit null) Possible values: - received : alarm is received - transmit : alarm is transmit - null : direction not defined	alarm direction: received or transmit <i>This element is only shown in detail mode.</i>
descript	Parameter type: <Alarm::AddInfoString> - additional alarm information	alarm description <i>This element is only shown in detail mode.</i>

101.76 show current alarm by filters

Command Description

show current alarms by filters

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm query ont-xdsl [ (name) [ severity <Alarm::querySeverity> ] [ servaff <Alarm::queryServAffect> ] [ dsl-line-port <Alarm::queryDefaultAid> ] ]
```

Command Parameters

Table 101.76-1 "show current alarm by filters" Resource Parameters

Resource Identifier	Type	Description
(name)	Format: (ont-svc-xdsl-mismatch ont-svc-xdsl-ne-lof ont-svc-xdsl-ne-los ont-svc-xdsl-ne-line ont-svc-xdsl-ne-lol ont-svc-xdsl-fe-lof ont-svc-xdsl-fe-los ont-svc-xdsl-fe-lop ont-svc-xdsl-cnf-err all) Possible values: - ont-svc-xdsl-mismatch : service mismatch for provisioned xdsl - ont-svc-xdsl-ne-lof : near end loss of frame - ont-svc-xdsl-ne-los : near end loss of signal - ont-svc-xdsl-ne-line : near end line init - ont-svc-xdsl-ne-lol : near end loss of link - ont-svc-xdsl-fe-lof : far end loss of frame - ont-svc-xdsl-fe-los : far end loss of signal - ont-svc-xdsl-fe-lop : far end loss of power - ont-svc-xdsl-cnf-err : xdsl provisioning error - all : ont services xdsl related alarms	alarm name of ont xdsl
severity	Parameter type: <Alarm::querySeverity> Format: (indeterminate warning minor	severity level of an alarm for reporting

Resource Identifier	Type	Description
	major critical all) Possible values: - indeterminate : alarm severity is indeterminate - warning : alarm severity is warning - minor : alarm severity is minor - major : alarm severity is major - critical : alarm severity is critical - all : all alarm severity	
servaff	Parameter type: <Alarm::queryServAffect> Format: (service-affecting noservice-affecting all) Possible values: - service-affecting : query alarm service affecting - noservice-affecting : query alarm not service affecting - all : query service affecting and not affecting alarms	serviceaffecting no serviceaffecting
dsl-line-port	Parameter type: <Alarm::queryDefaultAid> Format: all Possible values: - all : default AID parameter	all dsl line port

Command Output

Table 101.76-2 "show current alarm by filters" Display parameters

Specific Information		
name	Type	Description
aidinfo	Parameter type: <Alarm::AddInfoString> - additional alarm information	alarm AID parameters <i>This element is only shown in detail mode.</i>
type	Parameter type: <Alarm::alarmIHUBType> (equipment eqpt-holder plug-in-unit atm custom e1 ima-group ima-link redundancy shdsl ether-itf traffic-overflow qos-queue temporal spatial (software-mngt sw-mgmt) xdsl xdsl-ext xdsl-tca olt-gen eo-conv authentication	type of the alarms that are active <i>This element is only shown in detail mode.</i>

101 query current alarms by filters

name	Type	Description
	bonding sfp shdsl-isam custom-ext-alarm plug-in-unit-ext sip-user-agent sip-plugin-unit sip-termination e1-sip-termination filetransfer external-device l2forward ether-tca ether-sfp megaco-media-gw megaco-sig-gw megaco-plug-unit megaco-term megaco-sig-lt eqpt-supplemental eqpt-holder-ext lsmredundancy sync mcsrc vlanport vect-line vect-board otdr sip-dial-plan sip-vsp sip-server bgp rip lag ihub-general vprn isis ospf ihub-l2forward vpls ihub-equip ihub-link eont-phyoam ellid epon eont-services-lan eolt-ont-tca eont-sw-dl ldp mpls sdp epipe ihub-ipv6 pim li mgmt-sec-access bfd	

name	Type	Description
	ai	
	tr069serv	
	ontsnmp	
	bulk-sync	
	protection-group	
	ont	
	sfu-sup	
	soho-sup	
	mdu-sup	
	ont-ani	
	sfu-sup2	
	soho-sup2	
	mdu-sup2	
	sfprssi	
	eoltrssi	
	cfm	
	sfpe1t1-framer	
	sfpe1t1-clock	
	pppcc-engine-tca	
	eth-cfm	
	rsvp	
	ihub-tca	
	eth-ring	
	efm-oam	
	ont-loopdetect	
	ont-video	
	ont-ces	
	ont-voip	
	ont-video-ani	
	ont-pwe	
	ont-cese1	
	ont-xdsl	
	ont-xdsl-tca	
	ont-hpna	
	ont-sip-agent-cfg	
	ont-voip-cfg	
	ont-mgc	
	ont-ploam	
	ont-gen	
	ont-card	
	ont-pots	
	ont-lan	
	ont-moca	
	ont-tc-tca	
	ont-moca-tca	
	ont-l2uni-eth-tca	
	olt-pon-tc-tca	
	olt-pon-util-tca	
	olt-chpr-util-tca	
	olt-ont-tc-tca	
	ont-tca	
	ont-pots-supplemental	
	sfu-ploam	
	sfu-gen	
	soho-ploam	
	soho-gen	
	mdu-ploam	

101 query current alarms by filters

name	Type	Description
	mdu-gen ont-veip ont-iphost alarm-table auto-switch channel-pair ont-cfg-dld olt-chpair-tc-tca hgu-tr069 eqpt-psu ont-protection secondary-megaco-term secondary-sip-term cas-r2-channel lldpmed pseudo-wire link-agg fcs-exceed e1t1-interface) Possible values: - equipment : equipment alarms - eqpt-holder : equipment holder alarms - plug-in-unit : plugin unit alarms - atm : ATM alarms - custom : customizable alarms - e1 : e1 alarms - ima-group : ima-group alarms - ima-link : ima-link alarms - redundancy : redundancy alarms - shdsl : shdsl alarms - ether-itf : ethernet interface alarms - traffic-overflow : Traffic overflow alarms - qos-queue : qos queue alarms - temporal : temporal alarms - spatial : spatial alarms - software-mngt : software management alarms - sw-mgmt : software management alarms - xdsl : xDSL alarms - xdsl-ext : other xDSL alarms - xdsl-tca : xDSL threshold cross alarms - olt-gen : OLT general alarms - eo-conv : E/O conversion related alarms - authentication : authentication related alarms - bonding : bonding-group related alarms - sfp : SFP related alarms - shdsl-isam : shdsl isam alarms - custom-ext-alarm : customizable external alarms - plug-in-unit-ext : other plugin unit alarms - sip-user-agent : sip user agent related alarms - sip-plugin-unit : sip plug in unit related alarms - sip-termination : sip termination related alarms - e1-sip-termination : E1 sip termination related alarms - filetransfer : file transfer server alarms - external-device : external device related alarms - l2forward : l2forward related alarms - ether-tca : ethernet threshold cross alarms - ether-sfp : ethernet SFP related alarms	

name	Type	Description
	- megaco-media-gw : megaco media gateway related alarms - megaco-sig-gw : megaco signaling gateway related alarms - megaco-plug-unit : megaco plug unit related alarms - megaco-term : megaco termination related alarms - megaco-sig-lt : megaco signaling lt related alarms - eqpt-supplemental : equipment supplemental alarms - eqpt-holder-ext : other equipment holder alarms - lsmredundancy : lsm redundancy alarms - sync : synce and bits alarms - mcsrc : multicast source alarms - vlanport : vlanport alarms - vect-line : xDSL vectoring line alarms - vect-board : xDSL vectoring board alarms - otdr : otdr alarms - sip-dial-plan : sip dial plan related alarms - sip-vsp : sip vsp related alarms - sip-server : sip server related alarms - bgp : bgp related alarms - rip : rip related alarms - lag : LAG related alarms - ihub-general : IHUB general related alarms - vprn : vprn related alarms - isis : isis related alarms - ospf : ospf related alarms - ihub-l2forward : ihub-l2forward alarms - vpls : vpls related alarms - ihub-equip : ihub-equip related alarms - ihub-link : ihub-link related alarms - eont-phyoam : eont phyoam related alarms - ellid : ellid related alarms - epon : epon related alarms - eont-services-lan : eon phyoam related alarms - eolt-ont-tca : eon phyoam related alarms - eont-sw-dl : eon phyoam related alarms - ldp : ldp related alarms - mpls : mpls related alarms - sdp : sdp related alarms - epipe : epipe related alarms - ihub-ipv6 : ihub-ipv6 related alarms - pim : pim related alarms - li : lawful intercept related alarms - mgmt-sec-access : management security related alarms - bfd : bfd related alarms - ai : Application Intelligence related alarms - tr069serv : tr069 server related alarms - ontsnmp : ont snmp related alarms - bulk-sync : bulk-sync related alarms - protection-group : port protection group related alarms - ont : ONT general supplemental related alarms - sfu-sup : SFU ONT general supplemental related alarms - soho-sup : SOHO ONT general supplemental related alarms - mdu-sup : MDU ONT general supplemental related alarms - ont-ani : ONT general supplemental 2 related alarms - sfu-sup2 : SFU ONT general supplemental 2 related alarms - soho-sup2 : SOHO ONT general supplemental 2 related alarms	

101 query current alarms by filters

name	Type	Description
	- mdu-sup2 : MDU ONT general supplemental 2 related alarms - sfrprssi : SFP RSSI related alarms - eoltrssi : epon olt Sfp RSSI related alarms - cfm : Cfm related alarms - sfpe1t1-framer : SFP 2e1t1 framer alarms - sfpe1t1-clock : SFP 2e1t1 clock alarms - pppcc-engine-tca : PPPOE Cross Connect Engine TCA related alarm - eth-cfm : eth-cfm related alarms - rsvp : rsvp related alarms - ihub-tca : IHUB TCA related alarms - eth-ring : eth-ring related alarms - efm-oam : EFM-OAM related alarms - ont-loopdetect : ont loop detect related alarms - ont-video : ont services video related alarms - ont-ces : ont services ces related alarms - ont-voip : ont services voip related alarms - ont-video-ani : ont services video ani related alarms - ont-pwe : ont services pwe related alarms - ont-cese1 : ont services cese1 related alarms - ont-xdsl : ont services xdsl related alarms - ont-xdsl-tca : ont services xdsl tca related alarms - ont-hpna : ont hpna related alarms - ont-sip-agent-cfg : ont services voip sip agent config related alarms - ont-voip-cfg : ont services voip config related alarms - ont-mgc : ont mgc related alarms - ont-ploam : ONT PLOAM related alarms - ont-gen : ONT GENERAL related alarms - ont-card : ONT Subscriber Card related alarms - ont-pots : ONT Services POTS related alarms - ont-lan : ONT Services LAN related alarms - ont-moca : ONT MoCA related alarms - ont-tc-tca : ONT TC TCA related alarms - ont-moca-tca : ONT MoCA TCA related alarms - ont-l2uni-eth-tca : ONT L2 UNI Ethernet TCA related alarms - olt-pon-tc-tca : OLT PON TC TCA related alarms - olt-pon-util-tca : OLT PON utilization TCA related alarms - olt-chpr-util-tca : OLT channel-pair utilization TCA related alarms - olt-ont-tc-tca : OLT ONT TC TCA related alarms - ont-tca : ONT TCA related alarms - ont-pots-supplemental : ONT POTS Supplemental related alarms - sfu-ploam : SFU ONT PLOAM related alarms - sfu-gen : SFU ONT general related alarms - soho-ploam : SOHO ONT PLOAM related alarms - soho-gen : SOHO ONT general related alarms - mdu-ploam : MDU ONT PLOAM related alarms - mdu-gen : MDU ONT general related alarms - ont-veip : ONT VEIP related alarms - ont-iphost : ONT IP HOST related alarms - alarm-table : alarm table related alarms - auto-switch : auto-switch related alarms - channel-pair : channel pair related alarms	

name	Type	Description
	- ont-cfg-dld : ont configure file download related alarms - olt-chpair-tc-tca : OLT CHANNELPAIR TC TCA related alarms - hgu-tr069 : hgu tr069 related alarms - eqpt-psu : equipment psu alarms - ont-protection : ONT protection related alarms - secondary-megaco-term : secondary megaco termination related alarms - secondary-sip-term : secondary sip termination related alarms - cas-r2-channel : CAS R2 channel related alarms - lldpmed : lldpmed alarms - pseudo-wire : pseudo Wire related alarms - link-agg : Link aggregation related alarms - fcs-exceed : FCS auto-recovery related alarms - e1t1-interface : E1/T1 physical interfaces related alarms	
name	Parameter type: <Alarm::almtypeOntxdslhub> (ont-svc-xdsl-mismatch ont-svc-xdsl-ne-lof ont-svc-xdsl-ne-los ont-svc-xdsl-ne-line ont-svc-xdsl-ne-lol ont-svc-xdsl-fe-lof ont-svc-xdsl-fe-los ont-svc-xdsl-fe-lop ont-svc-xdsl-cnf-err all) Possible values: - ont-svc-xdsl-mismatch : service mismatch for provisioned xdsl - ont-svc-xdsl-ne-lof : near end loss of frame - ont-svc-xdsl-ne-los : near end loss of signal - ont-svc-xdsl-ne-line : near end line init - ont-svc-xdsl-ne-lol : near end loss of link - ont-svc-xdsl-fe-lof : far end loss of frame - ont-svc-xdsl-fe-los : far end loss of signal - ont-svc-xdsl-fe-lop : far end loss of power - ont-svc-xdsl-cnf-err : xdsl provisioning error - all : ont services xdsl related alarms	alarm name that are active <i>This element is only shown in detail mode.</i>
severity	Parameter type: <Alarm::AlarmSeverity> (indeterminate warning minor major critical) Possible values: - indeterminate : alarm severity is indeterminate - warning : alarm severity is warning - minor : alarm severity is minor - major : alarm severity is major - critical : alarm severity is critical	the alarms severity level <i>This element is only shown in detail mode.</i>
servaff	Parameter type: <Alarm::alarmServAffect> ((service-affecting yes) (noservice-affecting no)) Possible values: - service-affecting : make this alarm service affecting - yes : make this alarm service affecting	alarms affect service or not <i>This element is only shown in detail mode.</i>

101 query current alarms by filters

name	Type	Description
	- noservice-affecting : make this alarm not service affecting - no : make this alarm not service affecting	
location	Parameter type: <Alarm::almLocation> (near-end far-end middle-end line null) Possible values: - near-end : alarm location is near - far-end : alarm location is far - middle-end : alarm location is middle - line : alarm location is line - null : alarm location not defined	alarm location: near, middle, far <i>This element is only shown in detail mode.</i>
time	Parameter type: <Sys::timeInSecs> - the time (yyyy-mm-dd:hour:minutes:secs) - unit: UTC	time in seconds when alarm was updated <i>This element is only shown in detail mode.</i>
direction	Parameter type: <Alarm::almDirection> (received transmit null) Possible values: - received : alarm is received - transmit : alarm is transmit - null : direction not defined	alarm direction: received or transmit <i>This element is only shown in detail mode.</i>
descript	Parameter type: <Alarm::AddInfoString> - additional alarm information	alarm description <i>This element is only shown in detail mode.</i>

101.77 show current alarm by filters

Command Description

show current alarms by filters

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm query ont-xdsl-tca [ (name) [ severity <Alarm::querySeverity> ] [ servaff <Alarm::queryServAffect> ] [ dsl-line-port <Alarm::queryDefaultAid> ] ]
```

Command Parameters

Table 101.77-1 "show current alarm by filters" Resource Parameters

Resource Identifier	Type	Description
(name)	Format: (ont-svc-xdsl-ne-es-tc ont-svc-xdsl-ne-ses-tc ont-svc-xdsl-ne-uas-tc ont-svc-xdsl-fe-es-tc ont-svc-xdsl-fe-ses-tc ont-svc-xdsl-fe-uas-tc all) Possible values: - ont-svc-xdsl-ne-es-tc : near end errored seconds threshold crossed - ont-svc-xdsl-ne-ses-tc: near end severe errored seconds threshold crossed - ont-svc-xdsl-ne-uas-tc: ear end unavailable seconds threshold crossed - ont-svc-xdsl-fe-es-tc : far end errored seconds threshold crossed - ont-svc-xdsl-fe-ses-tc: far end severe errored seconds threshold crossed - ont-svc-xdsl-fe-uas-tc: far end unavailable seconds threshold crossed - all : ont services xdsl tca related alarms	alarm name of ont xdsl tca
severity	Parameter type: <Alarm::querySeverity> Format: (indeterminate warning minor major	severity level of an alarm for reporting

101 query current alarms by filters

Resource Identifier	Type	Description
	critical all) Possible values: - indeterminate : alarm severity is indeterminate - warning : alarm severity is warning - minor : alarm severity is minor - major : alarm severity is major - critical : alarm severity is critical - all : all alarm severity	
servaff	Parameter type: <Alarm::queryServAffect> Format: (service-affecting noservice-affecting all) Possible values: - service-affecting : query alarm service affecting - noservice-affecting : query alarm not service affecting - all : query service affecting and not affecting alarms	serviceaffecting no serviceaffecting
dsl-line-port	Parameter type: <Alarm::queryDefaultAid> Format: all Possible values: - all : default AID parameter	all dsl line port

Command Output

Table 101.77-2 "show current alarm by filters" Display parameters

Specific Information		
name	Type	Description
aidinfo	Parameter type: <Alarm::AddInfoString> - additional alarm information	alarm AID parameters <i>This element is only shown in detail mode.</i>
type	Parameter type: <Alarm::alarmIHUBType> (equipment eqpt-holder plug-in-unit atm custom e1 ima-group ima-link redundancy shdsl ether-itf traffic-overflow qos-queue temporal spatial (software-mngt sw-mgmt) xdsl xdsl-ext xdsl-tca olt-gen eo-conv authentication bonding	type of the alarms that are active <i>This element is only shown in detail mode.</i>

name	Type	Description
	sfp	
	shdsl-isam	
	custom-ext-alarm	
	plug-in-unit-ext	
	sip-user-agent	
	sip-plugin-unit	
	sip-termination	
	e1-sip-termination	
	filetransfer	
	external-device	
	l2forward	
	ether-tca	
	ether-sfp	
	megaco-media-gw	
	megaco-sig-gw	
	megaco-plug-unit	
	megaco-term	
	megaco-sig-lt	
	eqpt-supplemental	
	eqpt-holder-ext	
	lsmredundancy	
	sync	
	mcsrc	
	vlanport	
	vect-line	
	vect-board	
	otdr	
	sip-dial-plan	
	sip-vsp	
	sip-server	
	bgp	
	rip	
	lag	
	ihub-general	
	vprn	
	isis	
	ospf	
	ihub-l2forward	
	vpls	
	ihub-equip	
	ihub-link	
	eont-phyoam	
	ellid	
	epon	
	eont-services-lan	
	eolt-ont-tca	
	eont-sw-dl	
	ldp	
	mpls	
	sdp	
	epipe	
	ihub-ipv6	
	pim	
	li	
	mgmt-sec-access	
	bfd	
	ai	

101 query current alarms by filters

name	Type	Description
	tr069serv	
	ontsnmp	
	bulk-sync	
	protection-group	
	ont	
	sfu-sup	
	soho-sup	
	mdu-sup	
	ont-ani	
	sfu-sup2	
	soho-sup2	
	mdu-sup2	
	sfprssi	
	eoltrssi	
	cfm	
	sfpe1t1-framer	
	sfpe1t1-clock	
	pppcc-engine-tca	
	eth-cfm	
	rsvp	
	ihub-tca	
	eth-ring	
	efm-oam	
	ont-loopdetect	
	ont-video	
	ont-ces	
	ont-voip	
	ont-video-ani	
	ont-pwe	
	ont-cese1	
	ont-xdsl	
	ont-xdsl-tca	
	ont-hpna	
	ont-sip-agent-cfg	
	ont-voip-cfg	
	ont-mgc	
	ont-ploam	
	ont-gen	
	ont-card	
	ont-pots	
	ont-lan	
	ont-moca	
	ont-tc-tca	
	ont-moca-tca	
	ont-l2uni-eth-tca	
	olt-pon-tc-tca	
	olt-pon-util-tca	
	olt-chpr-util-tca	
	olt-ont-tc-tca	
	ont-tca	
	ont-pots-supplemental	
	sfu-ploam	
	sfu-gen	
	soho-ploam	
	soho-gen	
	mdu-ploam	
	mdu-gen	

name	Type	Description
	ont-veip ont-iphost alarm-table auto-switch channel-pair ont-cfg-dld olt-chpair-tc-tca hgu-tr069 eqpt-psu ont-protection secondary-megaco-term secondary-sip-term cas-r2-channel lldpmed pseudo-wire link-agg fcs-exceed e1t1-interface) Possible values: - equipment : equipment alarms - eqpt-holder : equipment holder alarms - plug-in-unit : plugin unit alarms - atm : ATM alarms - custom : customizable alarms - e1 : e1 alarms - ima-group : ima-group alarms - ima-link : ima-link alarms - redundancy : redundancy alarms - shdsl : shdsl alarms - ether-itf : ethernet interface alarms - traffic-overflow : Traffic overflow alarms - qos-queue : qos queue alarms - temporal : temporal alarms - spatial : spatial alarms - software-mngt : software management alarms - sw-mgmt : software management alarms - xdsl : xDSL alarms - xdsl-ext : other xDSL alarms - xdsl-tca : xDSL threshold cross alarms - olt-gen : OLT general alarms - eo-conv : E/O conversion related alarms - authentication : authentication related alarms - bonding : bonding-group related alarms - sfp : SFP related alarms - shdsl-isam : shdsl isam alarms - custom-ext-alarm : customizable external alarms - plug-in-unit-ext : other plugin unit alarms - sip-user-agent : sip user agent related alarms - sip-plugin-unit : sip plug in unit related alarms - sip-termination : sip termination related alarms - e1-sip-termination : E1 sip termination related alarms - filetransfer : file transfer server alarms - external-device : external device related alarms - l2forward : l2forward related alarms - ether-tca : ethernet threshold cross alarms - ether-sfp : ethernet SFP related alarms - megaco-media-gw : megaco media gateway related alarms	

101 query current alarms by filters

name	Type	Description
	- megaco-sig-gw : megaco signaling gateway related alarms - megaco-plug-unit : megaco plug unit related alarms - megaco-term : megaco termination related alarms - megaco-sig-lt : megaco signaling lt related alarms - eqpt-supplemental : equipment supplemental alarms - eqpt-holder-ext : other equipment holder alarms - lsmredundancy : lsm redundancy alarms - sync : synce and bits alarms - mcsrc : multicast source alarms - vlanport : vlanport alarms - vect-line : xDSL vectoring line alarms - vect-board : xDSL vectoring board alarms - otdr : otdr alarms - sip-dial-plan : sip dial plan related alarms - sip-vsp : sip vsp related alarms - sip-server : sip server related alarms - bgp : bgp related alarms - rip : rip related alarms - lag : LAG related alarms - ihub-general : IHUB general related alarms - vprn : vprn related alarms - isis : isis related alarms - ospf : ospf related alarms - ihub-l2forward : ihub-l2forward alarms - vpls : vpls related alarms - ihub-equip : ihub-equip related alarms - ihub-link : ihub-link related alarms - eont-phyoam : eont phyoam related alarms - ellid : ellid related alarms - epon : epon related alarms - eont-services-lan : eon phyoam related alarms - eolt-ont-tca : eon phyoam related alarms - eont-sw-dl : eon phyoam related alarms - ldp : ldp related alarms - mpls : mpls related alarms - sdp : sdp related alarms - epipe : epipe related alarms - ihub-ipv6 : ihub-ipv6 related alarms - pim : pim related alarms - li : lawful intercept related alarms - mgmt-sec-access : management security related alarms - bfd : bfd related alarms - ai : Application Intelligence related alarms - tr069serv : tr069 server related alarms - ontsnmp : ont snmp related alarms - bulk-sync : bulk-sync related alarms - protection-group : port protection group related alarms - ont : ONT general supplemental related alarms - sfu-sup : SFU ONT general supplemental related alarms - soho-sup : SOHO ONT general supplemental related alarms - mdu-sup : MDU ONT general supplemental related alarms - ont-ani : ONT general supplemental 2 related alarms - sfu-sup2 : SFU ONT general supplemental 2 related alarms - soho-sup2 : SOHO ONT general supplemental 2 related alarms - mdu-sup2 : MDU ONT general supplemental 2 related	

name	Type	Description
	alarms - sfprssi : SFP RSSI related alarms - eoltrssi : epon olt Sfp RSSI related alarms - cfm : Cfm related alarms - sfpe1t1-framer : SFP 2e1t1 framer alarms - sfpe1t1-clock : SFP 2e1t1 clock alarms - pppcc-engine-tca : PPPOE Cross Connect Engine TCA related alarm - eth-cfm : eth-cfm related alarms - rsvp : rsvp related alarms - ihub-tca : IHUB TCA related alarms - eth-ring : eth-ring related alarms - efm-oam : EFM-OAM related alarms - ont-loopdetect : ont loop detect related alarms - ont-video : ont services video related alarms - ont-ces : ont services ces related alarms - ont-voip : ont services voip related alarms - ont-video-ani : ont services video ani related alarms - ont-pwe : ont services pwe related alarms - ont-cese1 : ont services cese1 related alarms - ont-xdsl : ont services xdsl related alarms - ont-xdsl-tca : ont services xdsl tca related alarms - ont-hpna : ont hpna related alarms - ont-sip-agent-cfg : ont services voip sip agent config related alarms - ont-voip-cfg : ont services voip config related alarms - ont-mgc : ont mgc related alarms - ont-ploam : ONT PLOAM related alarms - ont-gen : ONT GENERAL related alarms - ont-card : ONT Subscriber Card related alarms - ont-pots : ONT Services POTS related alarms - ont-lan : ONT Services LAN related alarms - ont-moca : ONT MoCA related alarms - ont-tc-tca : ONT TC TCA related alarms - ont-moca-tca : ONT MoCA TCA related alarms - ont-l2uni-eth-tca : ONT L2 UNI Ethernet TCA related alarms - olt-pon-tc-tca : OLT PON TC TCA related alarms - olt-pon-util-tca : OLT PON utilization TCA related alarms - olt-chpr-util-tca : OLT channel-pair utilization TCA related alarms - olt-ont-tc-tca : OLT ONT TC TCA related alarms - ont-tca : ONT TCA related alarms - ont-pots-supplemental : ONT POTS Supplemental related alarms - sfu-ploam : SFU ONT PLOAM related alarms - sfu-gen : SFU ONT general related alarms - soho-ploam : SOHO ONT PLOAM related alarms - soho-gen : SOHO ONT general related alarms - mdu-ploam : MDU ONT PLOAM related alarms - mdu-gen : MDU ONT general related alarms - ont-veip : ONT VEIP related alarms - ont-iphost : ONT IP HOST related alarms - alarm-table : alarm table related alarms - auto-switch : auto-switch related alarms - channel-pair : channel pair related alarms - ont-cfg-dld : ont configure file download related alarms	

101 query current alarms by filters

name	Type	Description
	- olt-chpair-tc-tca : OLT CHANNELPAIR TC TCA related alarms - hgu-tr069 : hgu tr069 related alarms - eqpt-psu : equipment psu alarms - ont-protection : ONT protection related alarms - secondary-megaco-term : secondary megaco termination related alarms - secondary-sip-term : secondary sip termination related alarms - cas-r2-channel : CAS R2 channel related alarms - lldpmed : lldpmed alarms - pseudo-wire : pseudo Wire related alarms - link-agg : Link aggregation related alarms - fcs-exceed : FCS auto-recovery related alarms - e1t1-interface : E1/T1 physical interfaces related alarms	
name	Parameter type: <Alarm::almtypeOntxdsltcailhub> (ont-svc-xdsl-ne-es-tc ont-svc-xdsl-ne-ses-tc ont-svc-xdsl-ne-uas-tc ont-svc-xdsl-fe-es-tc ont-svc-xdsl-fe-ses-tc ont-svc-xdsl-fe-uas-tc all) Possible values: - ont-svc-xdsl-ne-es-tc : near end errored seconds threshold crossed - ont-svc-xdsl-ne-ses-tc: near end severe errored seconds threshold crossed - ont-svc-xdsl-ne-uas-tc: ear end unavailable seconds threshold crossed - ont-svc-xdsl-fe-es-tc : far end errored seconds threshold crossed - ont-svc-xdsl-fe-ses-tc: far end severe errored seconds threshold crossed - ont-svc-xdsl-fe-uas-tc: far end unavailable seconds threshold crossed - all : ont services xdsl tca related alarms	alarm name that are active <i>This element is only shown in detail mode.</i>
severity	Parameter type: <Alarm::AlarmSeverity> (indeterminate warning minor major critical) Possible values: - indeterminate : alarm severity is indeterminate - warning : alarm severity is warning - minor : alarm severity is minor - major : alarm severity is major - critical : alarm severity is critical	the alarms severity level <i>This element is only shown in detail mode.</i>
servaff	Parameter type: <Alarm::alarmServAffect> ((service-affecting yes) (noservice-affecting no)) Possible values: - service-affecting : make this alarm service affecting - yes : make this alarm service affecting - noservice-affecting : make this alarm not service affecting - no : make this alarm not service affecting	alarms affect service or not <i>This element is only shown in detail mode.</i>

name	Type	Description
location	Parameter type: <Alarm::almLocation> (near-end far-end middle-end line null) Possible values: - near-end : alarm location is near - far-end : alarm location is far - middle-end : alarm location is middle - line : alarm location is line - null : alarm location not defined	alarm location: near, middle, far <i>This element is only shown in detail mode.</i>
time	Parameter type: <Sys::timeInSecs> - the time (yyyy-mm-dd:hour:minutes:secs) - unit: UTC	time in seconds when alarm was updated <i>This element is only shown in detail mode.</i>
direction	Parameter type: <Alarm::almDirection> (received transmit null) Possible values: - received : alarm is received - transmit : alarm is transmit - null : direction not defined	alarm direction: received or transmit <i>This element is only shown in detail mode.</i>
descript	Parameter type: <Alarm::AddInfoString> - additional alarm information	alarm description <i>This element is only shown in detail mode.</i>

101.78 show current alarm by filters

Command Description

show current alarms by filters

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm query mcsrc [ (name) [ severity <Alarm::querySeverity> ] [ servaff <Alarm::queryServAffect> ] [ grp-ip-addr <Alarm::IpAddress> ] ]
```

Command Parameters

Table 101.78-1 "show current alarm by filters" Resource Parameters

Resource Identifier	Type	Description
(name)	Format: (mcsrc-stream-lost all) Possible values: - mcsrc-stream-lost : multicast video stream lost - all : multicast source alarms	alarm name of multicast source
severity	Parameter type: <Alarm::querySeverity> Format: (indeterminate warning minor major critical all) Possible values: - indeterminate : alarm severity is indeterminate - warning : alarm severity is warning - minor : alarm severity is minor - major : alarm severity is major - critical : alarm severity is critical - all : all alarm severity	severity level of an alarm for reporting
servaff	Parameter type: <Alarm::queryServAffect> Format: (service-affecting noservice-affecting all) Possible values: - service-affecting : query alarm service affecting	serviceaffecting no

Resource Identifier	Type	Description
	- noservice-affecting : query alarm not service affecting - all : query service affecting and not affecting alarms	
grp-ip-addr	Parameter type: <Alarm::IpAddress> Format: - IPv4-address	identify the mcast address where the alarm has occurred

Command Output

Table 101.78-2 "show current alarm by filters" Display parameters

Specific Information		
name	Type	Description
aidinfo	Parameter type: <Alarm::AddInfoString> - additional alarm information	alarm AID parameters <i>This element is only shown in detail mode.</i>
type	Parameter type: <Alarm::alarmIHUBType> (equipment eqpt-holder plug-in-unit atm custom e1 ima-group ima-link redundancy shdsl ether-itf traffic-overflow qos-queue temporal spatial (software-mngt sw-mgmt) xdsl xdsl-ext xdsl-tca olt-gen eo-conv authentication bonding sfp shdsl-isam custom-ext-alarm plug-in-unit-ext sip-user-agent sip-plugin-unit sip-termination e1-sip-termination filetransfer external-device l2forward ether-tca ether-sfp megaco-media-gw megaco-sig-gw megaco-plugin-unit megaco-term megaco-sig-lt	type of the alarms that are active <i>This element is only shown in detail mode.</i>

101 query current alarms by filters

name	Type	Description
	eqpt-supplemental	
	eqpt-holder-ext	
	lsmredundancy	
	sync	
	mcsrc	
	vlanport	
	vect-line	
	vect-board	
	otdr	
	sip-dial-plan	
	sip-vsp	
	sip-server	
	bgp	
	rip	
	lag	
	ihub-general	
	vpn	
	isis	
	ospf	
	ihub-l2forward	
	vpls	
	ihub-equip	
	ihub-link	
	eont-phyoam	
	ellid	
	epon	
	eont-services-lan	
	eolt-ont-tca	
	eont-sw-dl	
	ldp	
	mpls	
	sdp	
	epipe	
	ihub-ipv6	
	pim	
	li	
	mgmt-sec-access	
	bfd	
	ai	
	tr069serv	
	ontsnmp	
	bulk-sync	
	protection-group	
	ont	
	sfu-sup	
	soho-sup	
	mdu-sup	
	ont-ani	
	sfu-sup2	
	soho-sup2	
	mdu-sup2	
	sfprssi	
	eoltrssi	
	cfm	
	sfpe1t1-framer	
	sfpe1t1-clock	
	pppcc-engine-tca	

name	Type	Description
	eth-cfm	
	rsvp	
	ihub-tca	
	eth-ring	
	efm-oam	
	ont-loopdetect	
	ont-video	
	ont-ces	
	ont-voip	
	ont-video-ani	
	ont-pwe	
	ont-cese1	
	ont-xdsl	
	ont-xdsl-tca	
	ont-hpna	
	ont-sip-agent-cfg	
	ont-voip-cfg	
	ont-mgc	
	ont-ploam	
	ont-gen	
	ont-card	
	ont-pots	
	ont-lan	
	ont-moca	
	ont-tc-tca	
	ont-moca-tca	
	ont-l2uni-eth-tca	
	olt-pon-tc-tca	
	olt-pon-util-tca	
	olt-chpr-util-tca	
	olt-ont-tc-tca	
	ont-tca	
	ont-pots-supplemental	
	sfu-ploam	
	sfu-gen	
	soho-ploam	
	soho-gen	
	mdu-ploam	
	mdu-gen	
	ont-veip	
	ont-iphost	
	alarm-table	
	auto-switch	
	channel-pair	
	ont-cfg-dld	
	olt-chpair-tc-tca	
	hgu-tr069	
	eqpt-psu	
	ont-protection	
	secondary-megaco-term	
	secondary-sip-term	
	cas-r2-channel	
	lldpmed	
	pseudo-wire	
	link-agg	
	fcs-exceed	
	e1t1-interface)	

101 query current alarms by filters

name	Type	Description
	Possible values: - equipment : equipment alarms - eqpt-holder : equipment holder alarms - plug-in-unit : plugin unit alarms - atm : ATM alarms - custom : customizable alarms - e1 : e1 alarms - ima-group : ima-group alarms - ima-link : ima-link alarms - redundancy : redundancy alarms - shdsl : shdsl alarms - ether-itf : ethernet interface alarms - traffic-overflow : Traffic overflow alarms - qos-queue : qos queue alarms - temporal : temporal alarms - spatial : spatial alarms - software-mngt : software management alarms - sw-mgmt : software management alarms - xdsl : xDSL alarms - xdsl-ext : other xDSL alarms - xdsl-tca : xDSL threshold cross alarms - olt-gen : OLT general alarms - eo-conv : E/O conversion related alarms - authentication : authentication related alarms - bonding : bonding-group related alarms - sfp : SFP related alarms - shdsl-isam : shdsl isam alarms - custom-ext-alarm : customizable external alarms - plug-in-unit-ext : other plugin unit alarms - sip-user-agent : sip user agent related alarms - sip-plugin-unit : sip plug in unit related alarms - sip-termination : sip termination related alarms - e1-sip-termination : E1 sip termination related alarms - filetransfer : file transfer server alarms - external-device : external device related alarms - l2forward : l2forward related alarms - ether-tca : ethernet threshold cross alarms - ether-sfp : ethernet SFP related alarms - megaco-media-gw : megaco media gateway related alarms - megaco-sig-gw : megaco signaling gateway related alarms - megaco-plug-unit : megaco plug unit related alarms - megaco-term : megaco termination related alarms - megaco-sig-lt : megaco signaling lt related alarms - eqpt-supplemental : equipment supplemental alarms - eqpt-holder-ext : other equipment holder alarms - lsmredundancy : lsm redundancy alarms - sync : synce and bits alarms - mcsrc : multicast source alarms - vlanport : vlanport alarms - vect-line : xDSL vectoring line alarms - vect-board : xDSL vectoring board alarms - otdr : otdr alarms - sip-dial-plan : sip dial plan related alarms - sip-vsp : sip vsp related alarms - sip-server : sip server related alarms - bgp : bgp related alarms - rip : rip related alarms	

name	Type	Description
	- lag : LAG related alarms - ihub-general : IHUB general related alarms - vprn : vprn related alarms - isis : isis related alarms - ospf : ospf related alarms - ihub-l2forward : ihub-l2forward alarms - vpls : vpls related alarms - ihub-equip : ihub-equip related alarms - ihub-link : ihub-link related alarms - eont-phyoam : eont phyoam related alarms - ellid : ellid related alarms - epon : epon related alarms - eont-services-lan : eon phyoam related alarms - eolt-ont-tca : eon phyoam related alarms - eont-sw-dl : eon phyoam related alarms - ldp : ldp related alarms - mpls : mpls related alarms - sdp : sdp related alarms - epipe : epipe related alarms - ihub-ipv6 : ihub-ipv6 related alarms - pim : pim related alarms - li : lawful intercept related alarms - mgmt-sec-access : management security related alarms - bfd : bfd related alarms - ai : Application Intelligence related alarms - tr069serv : tr069 server related alarms - ontsnmp : ont snmp related alarms - bulk-sync : bulk-sync related alarms - protection-group : port protection group related alarms - ont : ONT general supplemental related alarms - sfu-sup : SFU ONT general supplemental related alarms - soho-sup : SOHO ONT general supplemental related alarms - mdu-sup : MDU ONT general supplemental related alarms - ont-ani : ONT general supplemental 2 related alarms - sfu-sup2 : SFU ONT general supplemental 2 related alarms - soho-sup2 : SOHO ONT general supplemental 2 related alarms - mdu-sup2 : MDU ONT general supplemental 2 related alarms - sfprssi : SFP RSSI related alarms - eoltrssi : epon olt Sfp RSSI related alarms - cfm : Cfm related alarms - sfpe1t1-framer : SFP 2e1t1 framer alarms - sfpe1t1-clock : SFP 2e1t1 clock alarms - pppcc-engine-tca : PPPOE Cross Connect Engine TCA related alarm - eth-cfm : eth-cfm related alarms - rsvp : rsvp related alarms - ihub-tca : IHUB TCA related alarms - eth-ring : eth-ring related alarms - efm-oam : EFM-OAM related alarms - ont-loopdetect : ont loop detect related alarms - ont-video : ont services video related alarms - ont-ces : ont services ces related alarms - ont-voip : ont services voip related alarms - ont-video-ani : ont services video ani related alarms	

101 query current alarms by filters

name	Type	Description
	- ont-pwe : ont services pwe related alarms - ont-cese1 : ont services cese1 related alarms - ont-xdsl : ont services xdsl related alarms - ont-xdsl-tca : ont services xdsl tca related alarms - ont-hpna : ont hpna related alarms - ont-sip-agent-cfg : ont services voip sip agent config related alarms - ont-voip-cfg : ont services voip config related alarms - ont-mgc : ont mgc related alarms - ont-ploam : ONT PLOAM related alarms - ont-gen : ONT GENERAL related alarms - ont-card : ONT Subscriber Card related alarms - ont-pots : ONT Services POTS related alarms - ont-lan : ONT Services LAN related alarms - ont-moca : ONT MoCA related alarms - ont-tc-tca : ONT TC TCA related alarms - ont-moca-tca : ONT MoCA TCA related alarms - ont-l2uni-eth-tca : ONT L2 UNI Ethernet TCA related alarms - olt-pon-tc-tca : OLT PON TC TCA related alarms - olt-pon-util-tca : OLT PON utilization TCA related alarms - olt-chpr-util-tca : OLT channel-pair utilization TCA related alarms - olt-ont-tc-tca : OLT ONT TC TCA related alarms - ont-tca : ONT TCA related alarms - ont-pots-supplemental : ONT POTS Supplemental related alarms - sfu-ploam : SFU ONT PLOAM related alarms - sfu-gen : SFU ONT general related alarms - soho-ploam : SOHO ONT PLOAM related alarms - soho-gen : SOHO ONT general related alarms - mdu-ploam : MDU ONT PLOAM related alarms - mdu-gen : MDU ONT general related alarms - ont-veip : ONT VEIP related alarms - ont-iphost : ONT IP HOST related alarms - alarm-table : alarm table related alarms - auto-switch : auto-switch related alarms - channel-pair : channel pair related alarms - ont-cfg-dld : ont configure file download related alarms - olt-chpair-tc-tca : OLT CHANNELPAIR TC TCA related alarms - hgu-tr069 : hgu tr069 related alarms - eqpt-psu : equipment psu alarms - ont-protection : ONT protection related alarms - secondary-megaco-term : secondary megaco termination related alarms - secondary-sip-term : secondary sip termination related alarms - cas-r2-channel : CAS R2 channel related alarms - lldpmed : lldpmed alarms - pseudo-wire : pseudo Wire related alarms - link-agg : Link aggregation related alarms - fcs-exceed : FCS auto-recovery related alarms - e1t1-interface : E1/T1 physical interfaces related alarms	
name	Parameter type: <Alarm::almtypemcsrcthub> (mcsrct-stream-lost all)	alarm name that are active <i>This element is only shown in detail mode.</i>

name	Type	Description
	Possible values: - mcsrc-stream-lost : multicast video stream lost - all : multicast source alarms	
severity	Parameter type: <Alarm::AlarmSeverity> (indeterminate warning minor major critical) Possible values: - indeterminate : alarm severity is indeterminate - warning : alarm severity is warning - minor : alarm severity is minor - major : alarm severity is major - critical : alarm severity is critical	the alarms severity level <i>This element is only shown in detail mode.</i>
servaff	Parameter type: <Alarm::alarmServAffect> ((service-affecting yes) (noservice-affecting no)) Possible values: - service-affecting : make this alarm service affecting - yes : make this alarm service affecting - noservice-affecting : make this alarm not service affecting - no : make this alarm not service affecting	alarms affect service or not <i>This element is only shown in detail mode.</i>
time	Parameter type: <Sys::timeInSecs> - the time (yyyy-mm-dd:hour:minutes:secs) - unit: UTC	time in seconds when alarm was updated <i>This element is only shown in detail mode.</i>
descript	Parameter type: <Alarm::AddInfoString> - additional alarm information	alarm description <i>This element is only shown in detail mode.</i>

101.79 show current alarm by filters

Command Description

show current alarms by filters

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm query eqpt-supplemental [ (name) [ severity <Alarm::querySeverity> ] [ servaff  
<Alarm::queryServAffect> ] [ shelf <Equipm::Shelf> ] ]
```

Command Parameters

Table 101.79-1 "show current alarm by filters" Resource Parameters

Resource Identifier	Type	Description
(name)	Format: (eqptsupl-syslog-upload eqptsupl-ontsw-dnload cf-75%used cf-90%used all) Possible values: - eqptsupl-syslog-upload: upload of log file to remote server failure - eqptsupl-ontsw-dnload : ont sw download in progress - cf-75%used : Compact flash exceeds 75% of life expectancy - cf-90%used : Compact flash exceeds 90% of life expectancy - all : equipment supplemental alarms	alarm name of equipment supplemental
severity	Parameter type: <Alarm::querySeverity> Format: (indeterminate warning minor major critical all) Possible values: - indeterminate : alarm severity is indeterminate - warning : alarm severity is warning - minor : alarm severity is minor - major : alarm severity is major	severity level of an alarm for reporting

Resource Identifier	Type	Description
	- critical : alarm severity is critical - all : all alarm severity	
servaff	Parameter type: <Alarm::queryServAffect> Format: (service-affecting noservice-affecting all) Possible values: - service-affecting : query alarm service affecting - noservice-affecting : query alarm not service affecting - all : query service affecting and not affecting alarms	serviceaffecting no serviceaffecting
shelf	Parameter type: <Equipm::Shelf> Format: <Eqpt::RackId> / <Eqpt::ShelfId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number	specify which shelf the alarm occurred on

Command Output

Table 101.79-2 "show current alarm by filters" Display parameters

Specific Information		
name	Type	Description
aidinfo	Parameter type: <Alarm::AddInfoString> - additional alarm information	alarm AID parameters <i>This element is only shown in detail mode.</i>
type	Parameter type: <Alarm::alarmIHUBType> (equipment eqpt-holder plug-in-unit atm custom e1 ima-group ima-link redundancy shdsl ether-itf traffic-overflow qos-queue temporal spatial (software-mngt sw-mgmt) xdsl xdsl-ext xdsl-tca olt-gen eo-conv authentication bonding sfp shdsl-isam custom-ext-alarm plug-in-unit-ext sip-user-agent	type of the alarms that are active <i>This element is only shown in detail mode.</i>

101 query current alarms by filters

name	Type	Description
	sip-plugin-unit sip-termination e1-sip-termination filetransfer external-device l2forward ether-tca ether-sfp megaco-media-gw megaco-sig-gw megaco-plug-unit megaco-term megaco-sig-lt eqpt-supplemental eqpt-holder-ext lsmredundancy sync mcsrc vlanport vect-line vect-board otdr sip-dial-plan sip-vsp sip-server bgp rip lag ihub-general vprn isis ospf ihub-l2forward vpls ihub-equip ihub-link eont-phyoam ellid epon eont-services-lan eolt-ont-tca eont-sw-dl ldp mpls sdp epipe ihub-ipv6 pim li mgmt-sec-access bfd ai tr069serv ontsnmp bulk-sync protection-group ont	

name	Type	Description
	sfu-sup	
	soho-sup	
	mdu-sup	
	ont-ani	
	sfu-sup2	
	soho-sup2	
	mdu-sup2	
	sfprssi	
	eoltrssi	
	cfm	
	sfpe1t1-framer	
	sfpe1t1-clock	
	pppcc-engine-tca	
	eth-cfm	
	rsvp	
	ihub-tca	
	eth-ring	
	efm-oam	
	ont-loopdetect	
	ont-video	
	ont-ces	
	ont-voip	
	ont-video-ani	
	ont-pwe	
	ont-cese1	
	ont-xdsl	
	ont-xdsl-tca	
	ont-hpna	
	ont-sip-agent-cfg	
	ont-voip-cfg	
	ont-mgc	
	ont-ploam	
	ont-gen	
	ont-card	
	ont-pots	
	ont-lan	
	ont-moca	
	ont-tc-tca	
	ont-moca-tca	
	ont-l2uni-eth-tca	
	olt-pon-tc-tca	
	olt-pon-util-tca	
	olt-chpr-util-tca	
	olt-ont-tc-tca	
	ont-tca	
	ont-pots-supplemental	
	sfu-ploam	
	sfu-gen	
	soho-ploam	
	soho-gen	
	mdu-ploam	
	mdu-gen	
	ont-veip	
	ont-iphost	
	alarm-table	
	auto-switch	
	channel-pair	

101 query current alarms by filters

name	Type	Description
	ont-cfg-dld olt-chpair-tc-tca hgu-tr069 eqpt-psu ont-protection secondary-megaco-term secondary-sip-term cas-r2-channel lldpmed pseudo-wire link-agg fcs-exceed e1t1-interface) Possible values: - equipment : equipment alarms - eqpt-holder : equipment holder alarms - plug-in-unit : plugin unit alarms - atm : ATM alarms - custom : customizable alarms - e1 : e1 alarms - ima-group : ima-group alarms - ima-link : ima-link alarms - redundancy : redundancy alarms - shdsl : shdsl alarms - ether-itf : ethernet interface alarms - traffic-overflow : Traffic overflow alarms - qos-queue : qos queue alarms - temporal : temporal alarms - spatial : spatial alarms - software-mngt : software management alarms - sw-mgmt : software management alarms - xdsl : xDSL alarms - xdsl-ext : other xDSL alarms - xdsl-tca : xDSL threshold cross alarms - olt-gen : OLT general alarms - eo-conv : E/O conversion related alarms - authentication : authentication related alarms - bonding : bonding-group related alarms - sfp : SFP related alarms - shdsl-isam : shdsl isam alarms - custom-ext-alarm : customizable external alarms - plug-in-unit-ext : other plugin unit alarms - sip-user-agent : sip user agent related alarms - sip-plugin-unit : sip plug in unit related alarms - sip-termination : sip termination related alarms - e1-sip-termination : E1 sip termination related alarms - filetransfer : file transfer server alarms - external-device : external device related alarms - l2forward : l2forward related alarms - ether-tca : ethernet threshold cross alarms - ether-sfp : ethernet SFP related alarms - megaco-media-gw : megaco media gateway related alarms - megaco-sig-gw : megaco signaling gateway related alarms - megaco-plug-unit : megaco plug unit related alarms - megaco-term : megaco termination related alarms - megaco-sig-lt : megaco signaling lt related alarms - eqpt-supplemental : equipment supplemental alarms	

name	Type	Description
	- eqpt-holder-ext : other equipment holder alarms - lsmredundancy : lsm redundancy alarms - sync : synce and bits alarms - mcsrsc : multicast source alarms - vlanport : vlanport alarms - vect-line : xDSL vectoring line alarms - vect-board : xDSL vectoring board alarms - otdr : otdr alarms - sip-dial-plan : sip dial plan related alarms - sip-vsp : sip vsp related alarms - sip-server : sip server related alarms - bgp : bgp related alarms - rip : rip related alarms - lag : LAG related alarms - ihub-general : IHUB general related alarms - vprn : vprn related alarms - isis : isis related alarms - ospf : ospf related alarms - ihub-l2forward : ihub-l2forward alarms - vpls : vpls related alarms - ihub-equip : ihub-equip related alarms - ihub-link : ihub-link related alarms - eont-phyoam : eont phyoam related alarms - ellid : ellid related alarms - epon : epon related alarms - eont-services-lan : eon phyoam related alarms - eolt-ont-tca : eon phyoam related alarms - eont-sw-dl : eon phyoam related alarms - ldp : ldp related alarms - mpls : mpls related alarms - sdp : sdp related alarms - epipe : epipe related alarms - ihub-ipv6 : ihub-ipv6 related alarms - pim : pim related alarms - li : lawful intercept related alarms - mgmt-sec-access : management security related alarms - bfd : bfd related alarms - ai : Application Intelligence related alarms - tr069serv : tr069 server related alarms - ontsnmp : ont snmp related alarms - bulk-sync : bulk-sync related alarms - protection-group : port protection group related alarms - ont : ONT general supplemental related alarms - sfu-sup : SFU ONT general supplemental related alarms - soho-sup : SOHO ONT general supplemental related alarms - mdu-sup : MDU ONT general supplemental related alarms - ont-ani : ONT general supplemental 2 related alarms - sfu-sup2 : SFU ONT general supplemental 2 related alarms - soho-sup2 : SOHO ONT general supplemental 2 related alarms - mdu-sup2 : MDU ONT general supplemental 2 related alarms - sfrssi : SFP RSSI related alarms - eoltrssi : epon olt Sfp RSSI related alarms - cfm : Cfm related alarms - sfpe1t1-framer : SFP 2e1t1 framer alarms	

101 query current alarms by filters

name	Type	Description
	- sfpe1t1-clock : SFP 2e1t1 clock alarms - pppcc-engine-tca : PPPOE Cross Connect Engine TCA related alarm - eth-cfm : eth-cfm related alarms - rsvp : rsvp related alarms - ihub-tca : IHUB TCA related alarms - eth-ring : eth-ring related alarms - efm-oam : EFM-OAM related alarms - ont-loopdetect : ont loop detect related alarms - ont-video : ont services video related alarms - ont-ces : ont services ces related alarms - ont-voip : ont services voip related alarms - ont-video-ani : ont services video ani related alarms - ont-pwe : ont services pwe related alarms - ont-cese1 : ont services cese1 related alarms - ont-xdsl : ont services xdsl related alarms - ont-xdsl-tca : ont services xdsl tca related alarms - ont-hpna : ont hpna related alarms - ont-sip-agent-cfg : ont services voip sip agent config related alarms - ont-voip-cfg : ont services voip config related alarms - ont-mgc : ont mgc related alarms - ont-ploam : ONT PLOAM related alarms - ont-gen : ONT GENERAL related alarms - ont-card : ONT Subscriber Card related alarms - ont-pots : ONT Services POTS related alarms - ont-lan : ONT Services LAN related alarms - ont-moca : ONT MoCA related alarms - ont-tc-tca : ONT TC TCA related alarms - ont-moca-tca : ONT MoCA TCA related alarms - ont-l2uni-eth-tca : ONT L2 UNI Ethernet TCA related alarms - olt-pon-tc-tca : OLT PON TC TCA related alarms - olt-pon-util-tca : OLT PON utilization TCA related alarms - olt-chpr-util-tca : OLT channel-pair utilization TCA related alarms - olt-ont-tc-tca : OLT ONT TC TCA related alarms - ont-tca : ONT TCA related alarms - ont-pots-supplemental : ONT POTS Supplemental related alarms - sfu-ploam : SFU ONT PLOAM related alarms - sfu-gen : SFU ONT general related alarms - soho-ploam : SOHO ONT PLOAM related alarms - soho-gen : SOHO ONT general related alarms - mdu-ploam : MDU ONT PLOAM related alarms - mdu-gen : MDU ONT general related alarms - ont-veip : ONT VEIP related alarms - ont-iphost : ONT IP HOST related alarms - alarm-table : alarm table related alarms - auto-switch : auto-switch related alarms - channel-pair : channel pair related alarms - ont-cfg-dld : ont configure file download related alarms - olt-chpair-tc-tca : OLT CHANNELPAIR TC TCA related alarms - hgu-tr069 : hgu tr069 related alarms - eqpt-psu : equipment psu alarms - ont-protection : ONT protection related alarms	

name	Type	Description
	- secondary-megaco-term : secondary megaco termination related alarms - secondary-sip-term : secondary sip termination related alarms - cas-r2-channel : CAS R2 channel related alarms - lldpmed : lldpmed alarms - pseudo-wire : pseudo Wire related alarms - link-agg : Link aggregation related alarms - fcs-exceed : FCS auto-recovery related alarms - e1t1-interface : E1/T1 physical interfaces related alarms	
name	Parameter type: <Alarm::alarmTypeEqptsupplementalhub> (eqptsupl-syslog-upload eqptsupl-ontsw-dnload cf-75%used cf-90%used all) Possible values: - eqptsupl-syslog-upload: upload of log file to remote server failure - eqptsupl-ontsw-dnload : ont sw download in progress - cf-75%used : Compact flash exceeds 75% of life expectancy - cf-90%used : Compact flash exceeds 90% of life expectancy - all : equipment supplemental alarms	alarm name that are active <i>This element is only shown in detail mode.</i>
severity	Parameter type: <Alarm::AlarmSeverity> (indeterminate warning minor major critical) Possible values: - indeterminate : alarm severity is indeterminate - warning : alarm severity is warning - minor : alarm severity is minor - major : alarm severity is major - critical : alarm severity is critical	the alarms severity level <i>This element is only shown in detail mode.</i>
servaff	Parameter type: <Alarm::alarmServAffect> ((service-affecting yes) (noservice-affecting no)) Possible values: - service-affecting : make this alarm service affecting - yes : make this alarm service affecting - noservice-affecting : make this alarm not service affecting - no : make this alarm not service affecting	alarms affect service or not <i>This element is only shown in detail mode.</i>
time	Parameter type: <Sys::timeInSecs> - the time (yyyy-mm-dd:hour:minutes:secs) - unit: UTC	time in seconds when alarm was updated <i>This element is only shown in detail mode.</i>
descript	Parameter type: <Alarm::AddInfoString> - additional alarm information	alarm description <i>This element is only shown in detail mode.</i>

101.80 show current alarm by filters

Command Description

show current alarms by filters

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm query ont [ (name) [ severity <Alarm::querySeverity> ] [ servaff <Alarm::queryServAffect> ] [ ont
<Gpon::OntIndex> ] ]
```

Command Parameters

Table 101.80-1 "show current alarm by filters" Resource Parameters

Resource Identifier	Type	Description
(name)	Format: (ont-gen-sw-dnload-file ont-gen-fan-fail ont-gen-high-temp ont-gen-high-temp-ex ont-gen-emergency-call ont-gen-sw-version ont-poe-exceed-max ont-poe-overload-yell ont-opti-malfunc ont-gen-cfgdld-fail ont-gen-rssi-mis ont-gen-tx-pwr-low ont-gen-temp-high ont-gen-volt-high ont-gen-bias-high ont-loopdetect-mis ont-olt-rx-pw-lo ont-olt-rx-pw-hig ont-olt-rx-pw-warnlo ont-olt-rx-pw-warnhig ont-gen-tod-out-sync ont-gen-tune-fail hgu-tr069-parm-fail ont-gen-tod-mismatch all) Possible values: - ont-gen-sw-dnload-file: ont sw download file missing	alarm name of ONT general supplemental

Resource Identifier	Type	Description
	- ont-gen-fan-fail : ont fan failure - ont-gen-high-temp : ont high temperature - ont-gen-high-temp-ex : ont excessive high temperature - ont-gen-emergency-call: ont emergency call - ont-gen-sw-version : ont sw version control error - ont-poe-exceed-max : ont poe exceed max - ont-poe-overload-yell : ONU is nearing its maximum ability to supply the power - ont-opti-malfunc : Malfunction of ONT's optical transceiver - ont-gen-cfgdld-fail : download of voice xml file to ont failed - ont-gen-rssi-mis : ONU RSSI configuration mismatch - ont-gen-tx-pwr-low : ONU SFP Tx Power is lower than configured Alarm low threshold - ont-gen-temp-high : ONU SFP Temperature is higher than configured Alarm high threshold - ont-gen-volt-high : ONU SFP Voltage is higher than configured Alarm high threshold - ont-gen-bias-high : ONU SFP Bias is higher than configured Alarm high threshold - ont-loopdetect-mis : ont loop detect mismatch - ont-olt-rx-pw-lo : olt side receive power from ont low - ont-olt-rx-pw-hig : olt side receive power from ont high - ont-olt-rx-pw-warnlo : olt side receive power from ont low warning - ont-olt-rx-pw-warnhig : olt side receive power from ont high warning - ont-gen-tod-out-sync : ONU TOD is out-sync with OLT - ont-gen-tune-fail : ONU has failed to tune to Target-ChnlPair - hgu-tr069-param-fail : hgu tr069 parameters mismatch - ont-gen-tod-mismatch : ONU TOD MISMATCH - all : ONT general supplemental related alarms	
severity	Parameter type: <Alarm::querySeverity> Format: (indeterminate warning minor major critical all) Possible values: - indeterminate : alarm severity is indeterminate - warning : alarm severity is warning - minor : alarm severity is minor - major : alarm severity is major - critical : alarm severity is critical - all : all alarm severity	severity level of an alarm for reporting
servaff	Parameter type: <Alarm::queryServAffect> Format: (service-affecting noservice-affecting all) Possible values: - service-affecting : query alarm service affecting - noservice-affecting : query alarm not service affecting	serviceaffecting no

101 query current alarms by filters

Resource Identifier	Type	Description
	- all : query service affecting and not affecting alarms	
ont	Parameter type: <Gpon::OntIndex> Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> ng2 : <Ng2::ChannelGroup> / <Ng2::SubchannelGroup> / <Ng2::OntId>) Possible values: - ng2 : ngpon2 style identification Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Ng2::ChannelGroup> - channel group number Field type <Ng2::SubchannelGroup> - subchannel group number Field type <Eqpt::OntId> - the ONT identifier Field type <Ng2::OntId> - the ONT identifier	identifies the ont entry

Command Output

Table 101.80-2 "show current alarm by filters" Display parameters

Specific Information		
name	Type	Description
aidinfo	Parameter type: <Alarm::AddInfoString> - additional alarm information	alarm AID parameters <i>This element is only shown in detail mode.</i>
type	Parameter type: <Alarm::alarmIHUBType> (equipment eqpt-holder plug-in-unit atm custom e1 ima-group ima-link redundancy shdsl ether-itf traffic-overflow qos-queue temporal spatial (software-mngt sw-mgmt) xdsl xdsl-ext xdsl-tca olt-gen eo-conv	type of the alarms that are active <i>This element is only shown in detail mode.</i>

name	Type	Description
	authentication bonding sfp shdsl-isam custom-ext-alarm plug-in-unit-ext sip-user-agent sip-plugin-unit sip-termination e1-sip-termination filetransfer external-device l2forward ether-tca ether-sfp megaco-media-gw megaco-sig-gw megaco-plug-unit megaco-term megaco-sig-lt eqpt-supplemental eqpt-holder-ext lsmredundancy sync mcsrc vlanport vect-line vect-board otdr sip-dial-plan sip-vsp sip-server bgp rip lag ihub-general vprn isis ospf ihub-l2forward vpls ihub-equip ihub-link eont-phyoam ellid epon eont-services-lan eolt-ont-tca eont-sw-dl ldp mpls sdp epipe ihub-ipv6 pim li mgmt-sec-access	

101 query current alarms by filters

name	Type	Description
	bfd	
	ai	
	tr069serv	
	ontsnmp	
	bulk-sync	
	protection-group	
	ont	
	sfu-sup	
	soho-sup	
	mdu-sup	
	ont-ani	
	sfu-sup2	
	soho-sup2	
	mdu-sup2	
	sfprssi	
	eoltrssi	
	cfm	
	sfpe1t1-framer	
	sfpe1t1-clock	
	pppcc-engine-tca	
	eth-cfm	
	rsvp	
	ihub-tca	
	eth-ring	
	efm-oam	
	ont-loopdetect	
	ont-video	
	ont-ces	
	ont-voip	
	ont-video-ani	
	ont-pwe	
	ont-cese1	
	ont-xdsl	
	ont-xdsl-tca	
	ont-hpna	
	ont-sip-agent-cfg	
	ont-voip-cfg	
	ont-mgc	
	ont-ploam	
	ont-gen	
	ont-card	
	ont-pots	
	ont-lan	
	ont-moca	
	ont-tc-tca	
	ont-moca-tca	
	ont-l2uni-eth-tca	
	olt-pon-tc-tca	
	olt-pon-util-tca	
	olt-chpr-util-tca	
	olt-ont-tc-tca	
	ont-tca	
	ont-pots-supplemental	
	sfu-ploam	
	sfu-gen	
	soho-ploam	
	soho-gen	

name	Type	Description
	- mdu-ploam - mdu-gen - ont-veip - ont-iphost - alarm-table - auto-switch - channel-pair - ont-cfg-dld - olt-chpair-tc-tca - hgu-tr069 - eqpt-psu - ont-protection - secondary-megaco-term - secondary-sip-term - cas-r2-channel - lldpmed - pseudo-wire - link-agg - fcs-exceed - e1t1-interface) Possible values: - equipment : equipment alarms - eqpt-holder : equipment holder alarms - plug-in-unit : plugin unit alarms - atm : ATM alarms - custom : customizable alarms - e1 : e1 alarms - ima-group : ima-group alarms - ima-link : ima-link alarms - redundancy : redundancy alarms - shdsl : shdsl alarms - ether-itf : ethernet interface alarms - traffic-overflow : Traffic overflow alarms - qos-queue : qos queue alarms - temporal : temporal alarms - spatial : spatial alarms - software-mngt : software management alarms - sw-mgmt : software management alarms - xdsl : xDSL alarms - xdsl-ext : other xDSL alarms - xdsl-tca : xDSL threshold cross alarms - olt-gen : OLT general alarms - eo-conv : E/O conversion related alarms - authentication : authentication related alarms - bonding : bonding-group related alarms - sfp : SFP related alarms - shdsl-isam : shdsl isam alarms - custom-ext-alarm : customizable external alarms - plug-in-unit-ext : other plugin unit alarms - sip-user-agent : sip user agent related alarms - sip-plugin-unit : sip plug in unit related alarms - sip-termination : sip termination related alarms - e1-sip-termination : E1 sip termination related alarms - filetransfer : file transfer server alarms - external-device : external device related alarms - l2forward : l2forward related alarms - ether-tca : ethernet threshold cross alarms	

101 query current alarms by filters

name	Type	Description
	- ether-sfp : ethernet SFP related alarms - megaco-media-gw : megaco media gateway related alarms - megaco-sig-gw : megaco signaling gateway related alarms - megaco-plug-unit : megaco plug unit related alarms - megaco-term : megaco termination related alarms - megaco-sig-lt : megaco signaling lt related alarms - eqpt-supplemental : equipment supplemental alarms - eqpt-holder-ext : other equipment holder alarms - lsmredundancy : lsm redundancy alarms - sync : synce and bits alarms - mcsrc : multicast source alarms - vlanport : vlanport alarms - vect-line : xDSL vectoring line alarms - vect-board : xDSL vectoring board alarms - otdr : otdr alarms - sip-dial-plan : sip dial plan related alarms - sip-vsp : sip vsp related alarms - sip-server : sip server related alarms - bgp : bgp related alarms - rip : rip related alarms - lag : LAG related alarms - ihub-general : IHUB general related alarms - vprn : vprn related alarms - isis : isis related alarms - ospf : ospf related alarms - ihub-l2forward : ihub-l2forward alarms - vpls : vpls related alarms - ihub-equip : ihub-equip related alarms - ihub-link : ihub-link related alarms - eont-phyoam : eont phyoam related alarms - ellid : ellid related alarms - epon : epon related alarms - eont-services-lan : eon phyoam related alarms - eolt-ont-tca : eon phyoam related alarms - eont-sw-dl : eon phyoam related alarms - ldp : ldp related alarms - mpls : mpls related alarms - sdp : sdp related alarms - epipe : epipe related alarms - ihub-ipv6 : ihub-ipv6 related alarms - pim : pim related alarms - li : lawful intercept related alarms - mgmt-sec-access : management security related alarms - bfd : bfd related alarms - ai : Application Intelligence related alarms - tr069serv : tr069 server related alarms - ontsnmp : ont snmp related alarms - bulk-sync : bulk-sync related alarms - protection-group : port protection group related alarms - ont : ONT general supplemental related alarms - sfu-sup : SFU ONT general supplemental related alarms - soho-sup : SOHO ONT general supplemental related alarms - mdu-sup : MDU ONT general supplemental related alarms - ont-ani : ONT general supplemental 2 related alarms - sfu-sup2 : SFU ONT general supplemental 2 related alarms - soho-sup2 : SOHO ONT general supplemental 2 related	

name	Type	Description
	alarms - mdu-sup2 : MDU ONT general supplemental 2 related alarms - sfrprssi : SFP RSSI related alarms - eoltrssi : epon olt Sfp RSSI related alarms - cfm : Cfm related alarms - sfpe1t1-framer : SFP 2e1t1 framer alarms - sfpe1t1-clock : SFP 2e1t1 clock alarms - pppcc-engine-tca : PPPOE Cross Connect Engine TCA related alarm - eth-cfm : eth-cfm related alarms - rsvp : rsvp related alarms - ihub-tca : IHUB TCA related alarms - eth-ring : eth-ring related alarms - efm-oam : EFM-OAM related alarms - ont-loopdetect : ont loop detect related alarms - ont-video : ont services video related alarms - ont-ces : ont services ces related alarms - ont-voip : ont services voip related alarms - ont-video-ani : ont services video ani related alarms - ont-pwe : ont services pwe related alarms - ont-cese1 : ont services cese1 related alarms - ont-xdsl : ont services xdsl related alarms - ont-xdsl-tca : ont services xdsl tca related alarms - ont-hpna : ont hpna related alarms - ont-sip-agent-cfg : ont services voip sip agent config related alarms - ont-voip-cfg : ont services voip config related alarms - ont-mgc : ont mgc related alarms - ont-ploam : ONT PLOAM related alarms - ont-gen : ONT GENERAL related alarms - ont-card : ONT Subscriber Card related alarms - ont-pots : ONT Services POTS related alarms - ont-lan : ONT Services LAN related alarms - ont-moca : ONT MoCA related alarms - ont-tc-tca : ONT TC TCA related alarms - ont-moca-tca : ONT MoCA TCA related alarms - ont-l2uni-eth-tca : ONT L2 UNI Ethernet TCA related alarms - olt-pon-tc-tca : OLT PON TC TCA related alarms - olt-pon-util-tca : OLT PON utilization TCA related alarms - olt-chpr-util-tca : OLT channel-pair utilization TCA related alarms - olt-ont-tc-tca : OLT ONT TC TCA related alarms - ont-tca : ONT TCA related alarms - ont-pots-supplemental : ONT POTS Supplemental related alarms - sfu-ploam : SFU ONT PLOAM related alarms - sfu-gen : SFU ONT general related alarms - soho-ploam : SOHO ONT PLOAM related alarms - soho-gen : SOHO ONT general related alarms - mdu-ploam : MDU ONT PLOAM related alarms - mdu-gen : MDU ONT general related alarms - ont-veip : ONT VEIP related alarms - ont-iphost : ONT IP HOST related alarms - alarm-table : alarm table related alarms - auto-switch : auto-switch related alarms	

101 query current alarms by filters

name	Type	Description
	- channel-pair : channel pair related alarms - ont-cfg-dld : ont configure file download related alarms - olt-chpair-tc-tca : OLT CHANNELPAIR TC TCA related alarms - hgu-tr069 : hgu tr069 related alarms - eqpt-psu : equipment psu alarms - ont-protection : ONT protection related alarms - secondary-megaco-term : secondary megaco termination related alarms - secondary-sip-term : secondary sip termination related alarms - cas-r2-channel : CAS R2 channel related alarms - lldpmed : lldpmed alarms - pseudo-wire : pseudo Wire related alarms - link-agg : Link aggregation related alarms - fcs-exceed : FCS auto-recovery related alarms - e1t1-interface : E1/T1 physical interfaces related alarms	
name	Parameter type: <Alarm::alarmtypeOntihub> (ont-gen-sw-dnload-file ont-gen-fan-fail ont-gen-high-temp ont-gen-high-temp-ex ont-gen-emergency-call ont-gen-sw-version ont-poe-exceed-max ont-poe-overload-yell ont-opti-malfunc ont-gen-cfgdld-fail ont-gen-rssi-mis ont-gen-tx-pwr-low ont-gen-temp-high ont-gen-volt-high ont-gen-bias-high ont-loopdetect-mis ont-olt-rx-pw-lo ont-olt-rx-pw-hig ont-olt-rx-pw-warnlo ont-olt-rx-pw-warnhig ont-gen-tod-out-sync ont-gen-tune-fail hgu-tr069-parm-fail ont-gen-tod-mismatch all) Possible values: - ont-gen-sw-dnload-file: ont sw download file missing - ont-gen-fan-fail : ont fan failure - ont-gen-high-temp : ont high temperature - ont-gen-high-temp-ex : ont excessive high temperature - ont-gen-emergency-call: ont emergency call - ont-gen-sw-version : ont sw version control error - ont-poe-exceed-max : ont poe exceed max - ont-poe-overload-yell : ONU is nearing its maximum ability to supply the power - ont-opti-malfunc : Malfunction of ONT's optical transceiver - ont-gen-cfgdld-fail : download of voice xml file to ont failed	alarm name that are active <i>This element is only shown in detail mode.</i>

name	Type	Description
	- ont-gen-rssi-mis : ONU RSSI configuration mismatch - ont-gen-tx-pwr-low : ONU SFP Tx Power is lower than configured Alarm low threshold - ont-gen-temp-high : ONU SFP Temperature is higher than configured Alarm high threshold - ont-gen-volt-high : ONU SFP Voltage is higher than configured Alarm high threshold - ont-gen-bias-high : ONU SFP Bias is higher than configured Alarm high threshold - ont-loopdetect-mis : ont loop detect mismatch - ont-olt-rx-pw-lo : olt side receive power from ont low - ont-olt-rx-pw-hig : olt side receive power from ont high - ont-olt-rx-pw-warnlo : olt side receive power from ont low warning - ont-olt-rx-pw-warnhig : olt side receive power from ont high warning - ont-gen-tod-out-sync : ONU TOD is out-sync with OLT - ont-gen-tune-fail : ONU has failed to tune to Target-ChnlPair - hgu-tr069-param-fail : hgu tr069 parameters mismatch - ont-gen-tod-mismatch : ONU TOD MISMATCH - all : ONT general supplemental related alarms	
severity	Parameter type: <Alarm::AlarmSeverity> (indeterminate warning minor major critical) Possible values: - indeterminate : alarm severity is indeterminate - warning : alarm severity is warning - minor : alarm severity is minor - major : alarm severity is major - critical : alarm severity is critical	the alarms severity level <i>This element is only shown in detail mode.</i>
servaff	Parameter type: <Alarm::alarmServAffect> ((service-affecting yes) (noservice-affecting no)) Possible values: - service-affecting : make this alarm service affecting - yes : make this alarm service affecting - noservice-affecting : make this alarm not service affecting - no : make this alarm not service affecting	alarms affect service or not <i>This element is only shown in detail mode.</i>
time	Parameter type: <Sys::timeInSecs> - the time (yyyy-mm-dd:hour:minutes:secs) - unit: UTC	time in seconds when alarm was updated <i>This element is only shown in detail mode.</i>
descript	Parameter type: <Alarm::AddInfoString> - additional alarm information	alarm description <i>This element is only shown in detail mode.</i>

101.81 show current alarm by filters

Command Description

show current alarms by filters

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm query ihub-l2forward [ (name) [ severity <Alarm::querySeverity> ] [ servaff
<Alarm::queryServAffect> ] [ port <Ihub::EtherPortAndLag> ] ]
```

Command Parameters

Table 101.81-1 "show current alarm by filters" Resource Parameters

Resource Identifier	Type	Description
(name)	Format: (l2fw-stp-exception l2fw-stp-root-guard all) Possible values: - l2fw-stp-exception : STP exception condition is present in the SAP - l2fw-stp-root-guard : STP root gaurd violation is present - all : ihub-l2forward alarms	alarm name of ihub-l2forward
severity	Parameter type: <Alarm::querySeverity> Format: (indeterminate warning minor major critical all) Possible values: - indeterminate : alarm severity is indeterminate - warning : alarm severity is warning - minor : alarm severity is minor - major : alarm severity is major - critical : alarm severity is critical - all : all alarm severity	severity level of an alarm for reporting
servaff	Parameter type: <Alarm::queryServAffect> Format: (service-affecting noservice-affecting	serviceaffecting no

Resource Identifier	Type	Description
	all) Possible values: - service-affecting : query alarm service affecting - noservice-affecting : query alarm not service affecting - all : query service affecting and not affecting alarms	
port	Parameter type: <Ihub::EtherPortAndLag> Format: (nt-a : sfp : <Alarm::FacePlatePortIndex> nt-a : xfp : <Alarm::FacePlatePortIndex> nt-a : qsfp : <Alarm::FacePlatePortIndex> nt-a : eth : <Alarm::FacePlatePortIndex> nt-b : sfp : <Alarm::FacePlatePortIndex> nt-b : xfp : <Alarm::FacePlatePortIndex> nt-b : qsfp : <Alarm::FacePlatePortIndex> nt-b : eth : <Alarm::FacePlatePortIndex> ntio-1 : sfp : <Alarm::FacePlatePortIndex> ntio-1 : xfp : <Alarm::FacePlatePortIndex> ntio-1 : qsfp : <Alarm::FacePlatePortIndex> ntio-2 : sfp : <Alarm::FacePlatePortIndex> ntio-2 : xfp : <Alarm::FacePlatePortIndex> ntio-2 : qsfp : <Alarm::FacePlatePortIndex> lt : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> lag : <Alarm::IhubLagId> nt-a : qsfp : <Alarm::QsfpPortIndex> - <Alarm::LaneIndex> nt-b : qsfp : <Alarm::QsfpPortIndex> - <Alarm::LaneIndex>) Possible values: - nt-a : the nt-a slot - nt-b : the nt-b slot - ntio-1 : an nt applique slot in a single or multiple-ntio-shelf - ntio-2 : an nt applique slot in a multiple-ntio-shelf - lt : the lt slot - lag : key word to specify link aggregation group - nt-a : the nt-a slot - nt-b : the nt-b slot Possible values: - sfp : SFP port - xfp : XFP port - qsfp : QSFP port - eth : RJ45 or lemi port Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Alarm::IhubLagId> - link aggregation group id Field type <Alarm::FacePlatePortIndex> - the faceplate port number Field type <Alarm::QsfpPortIndex> - the qsfp port number Field type <Alarm::LaneIndex> - the lane number of qsfp port	identifies the physical position of the port

Command Output

Table 101.81-2 "show current alarm by filters" Display parameters

Specific Information		
name	Type	Description
aidinfo	Parameter type: <Alarm::AddInfoString> - additional alarm information	alarm AID parameters <i>This element is only shown in detail mode.</i>
type	Parameter type: <Alarm::alarmIHUBType> (equipment eqpt-holder plug-in-unit atm custom e1 ima-group ima-link redundancy shdsl ether-itf traffic-overflow qos-queue temporal spatial (software-mngt sw-mgmt) xdsl xdsl-ext xdsl-tca olt-gen eo-conv authentication bonding sfp shdsl-isam custom-ext-alarm plug-in-unit-ext sip-user-agent sip-plugin-unit sip-termination e1-sip-termination filetransfer external-device l2forward ether-tca ether-sfp megaco-media-gw megaco-sig-gw megaco-plug-unit megaco-term megaco-sig-lt eqpt-supplemental eqpt-holder-ext lsmredundancy sync mcsrc vlanport vect-line vect-board otdr	type of the alarms that are active <i>This element is only shown in detail mode.</i>

name	Type	Description
	sip-dial-plan sip-vsp sip-server bgp rip lag ihub-general vprn isis ospf ihub-l2forward vpls ihub-equip ihub-link eont-phyoam ellid epon eont-services-lan eolt-ont-tca eont-sw-dl ldp mpls sdp epipe ihub-ipv6 pim li mgmt-sec-access bfd ai tr069serv ontsnmp bulk-sync protection-group ont sfu-sup soho-sup mdu-sup ont-ani sfu-sup2 soho-sup2 mdu-sup2 sfprssi eoltrssi cfm sfpe1t1-framer sfpe1t1-clock pppcc-engine-tca eth-cfm rsvp ihub-tca eth-ring efm-oam ont-loopdetect ont-video ont-ces ont-voip	

101 query current alarms by filters

name	Type	Description
	ont-video-ani ont-pwe ont-cese1 ont-xdsl ont-xdsl-tca ont-hpna ont-sip-agent-cfg ont-voip-cfg ont-mgc ont-ploam ont-gen ont-card ont-pots ont-lan ont-moca ont-tc-tca ont-moca-tca ont-l2uni-eth-tca olt-pon-tc-tca olt-pon-util-tca olt-chpr-util-tca olt-ont-tc-tca ont-tca ont-pots-supplemental sfu-ploam sfu-gen soho-ploam soho-gen mdu-ploam mdu-gen ont-veip ont-iphost alarm-table auto-switch channel-pair ont-cfg-dld olt-chpair-tc-tca hgu-tr069 eqpt-psu ont-protection secondary-megaco-term secondary-sip-term cas-r2-channel lldpmed pseudo-wire link-agg fcs-exceed e1t1-interface) Possible values: - equipment : equipment alarms - eqpt-holder : equipment holder alarms - plug-in-unit : plugin unit alarms - atm : ATM alarms - custom : customizable alarms - e1 : e1 alarms - ima-group : ima-group alarms - ima-link : ima-link alarms	

name	Type	Description
	- redundancy : redundancy alarms - shdsl : shdsl alarms - ether-itf : ethernet interface alarms - traffic-overflow : Traffic overflow alarms - qos-queue : qos queue alarms - temporal : temporal alarms - spatial : spatial alarms - software-mngt : software management alarms - sw-mgmt : software management alarms - xdsl : xDSL alarms - xdsl-ext : other xDSL alarms - xdsl-tca : xDSL threshold cross alarms - olt-gen : OLT general alarms - eo-conv : E/O conversion related alarms - authentication : authentication related alarms - bonding : bonding-group related alarms - sfp : SFP related alarms - shdsl-isam : shdsl isam alarms - custom-ext-alarm : customizable external alarms - plug-in-unit-ext : other plugin unit alarms - sip-user-agent : sip user agent related alarms - sip-plugin-unit : sip plug in unit related alarms - sip-termination : sip termination related alarms - e1-sip-termination : E1 sip termination related alarms - filetransfer : file transfer server alarms - external-device : external device related alarms - l2forward : l2forward related alarms - ether-tca : ethernet threshold cross alarms - ether-sfp : ethernet SFP related alarms - megaco-media-gw : megaco media gateway related alarms - megaco-sig-gw : megaco signaling gateway related alarms - megaco-plug-unit : megaco plug unit related alarms - megaco-term : megaco termination related alarms - megaco-sig-lt : megaco signaling lt related alarms - eqpt-supplemental : equipment supplemental alarms - eqpt-holder-ext : other equipment holder alarms - lsmredundancy : lsm redundancy alarms - sync : synce and bits alarms - mcsrc : multicast source alarms - vlanport : vlanport alarms - vect-line : xDSL vectoring line alarms - vect-board : xDSL vectoring board alarms - otdr : otdr alarms - sip-dial-plan : sip dial plan related alarms - sip-vsp : sip vsp related alarms - sip-server : sip server related alarms - bgp : bgp related alarms - rip : rip related alarms - lag : LAG related alarms - ihub-general : IHUB general related alarms - vprn : vprn related alarms - isis : isis related alarms - ospf : ospf related alarms - ihub-l2forward : ihub-l2forward alarms - vpls : vpls related alarms - ihub-equip : ihub-equip related alarms - ihub-link : ihub-link related alarms	

101 query current alarms by filters

name	Type	Description
	- eont-phyoam : eont phyoam related alarms - ellid : ellid related alarms - epon : epon related alarms - eont-services-lan : eon phyoam related alarms - eolt-ont-tca : eon phyoam related alarms - eont-sw-dl : eon phyoam related alarms - ldp : ldp related alarms - mpls : mpls related alarms - sdp : sdp related alarms - epipe : epipe related alarms - ihub-ipv6 : ihub-ipv6 related alarms - pim : pim related alarms - li : lawful intercept related alarms - mgmt-sec-access : management security related alarms - bfd : bfd related alarms - ai : Application Intelligence related alarms - tr069serv : tr069 server related alarms - ontsnmp : ont snmp related alarms - bulk-sync : bulk-sync related alarms - protection-group : port protection group related alarms - ont : ONT general supplemental related alarms - sfu-sup : SFU ONT general supplemental related alarms - soho-sup : SOHO ONT general supplemental related alarms - mdu-sup : MDU ONT general supplemental related alarms - ont-ani : ONT general supplemental 2 related alarms - sfu-sup2 : SFU ONT general supplemental 2 related alarms - soho-sup2 : SOHO ONT general supplemental 2 related alarms - mdu-sup2 : MDU ONT general supplemental 2 related alarms - sfprssi : SFP RSSI related alarms - eoltrssi : epon olt Sfp RSSI related alarms - cfm : Cfm related alarms - sfpe1t1-framer : SFP 2e1t1 framer alarms - sfpe1t1-clock : SFP 2e1t1 clock alarms - pppcc-engine-tca : PPPOE Cross Connect Engine TCA related alarm - eth-cfm : eth-cfm related alarms - rsvp : rsvp related alarms - ihub-tca : IHUB TCA related alarms - eth-ring : eth-ring related alarms - efm-oam : EFM-OAM related alarms - ont-loopdetect : ont loop detect related alarms - ont-video : ont services video related alarms - ont-ces : ont services ces related alarms - ont-voip : ont services voip related alarms - ont-video-ani : ont services video ani related alarms - ont-pwe : ont services pwe related alarms - ont-cese1 : ont services cese1 related alarms - ont-xdsl : ont services xdsl related alarms - ont-xdsl-tca : ont services xdsl tca related alarms - ont-hpna : ont hpna related alarms - ont-sip-agent-cfg : ont services voip sip agent config related alarms - ont-voip-cfg : ont services voip config related alarms - ont-mgc : ont mgc related alarms	

name	Type	Description
	- ont-ploam : ONT PLOAM related alarms - ont-gen : ONT GENERAL related alarms - ont-card : ONT Subscriber Card related alarms - ont-pots : ONT Services POTS related alarms - ont-lan : ONT Services LAN related alarms - ont-moca : ONT MoCA related alarms - ont-tc-tca : ONT TC TCA related alarms - ont-moca-tca : ONT MoCA TCA related alarms - ont-l2uni-eth-tca : ONT L2 UNI Ethernet TCA related alarms - olt-pon-tc-tca : OLT PON TC TCA related alarms - olt-pon-util-tca : OLT PON utilization TCA related alarms - olt-chpr-util-tca : OLT channel-pair utilization TCA related alarms - olt-ont-tc-tca : OLT ONT TC TCA related alarms - ont-tca : ONT TCA related alarms - ont-pots-supplemental : ONT POTS Supplemental related alarms - sfu-ploam : SFU ONT PLOAM related alarms - sfu-gen : SFU ONT general related alarms - soho-ploam : SOHO ONT PLOAM related alarms - soho-gen : SOHO ONT general related alarms - mdu-ploam : MDU ONT PLOAM related alarms - mdu-gen : MDU ONT general related alarms - ont-veip : ONT VEIP related alarms - ont-iphost : ONT IP HOST related alarms - alarm-table : alarm table related alarms - auto-switch : auto-switch related alarms - channel-pair : channel pair related alarms - ont-cfg-dld : ont configure file download related alarms - olt-chpair-tc-tca : OLT CHANNELPAIR TC TCA related alarms - hgu-tr069 : hgu tr069 related alarms - eqpt-psu : equipment psu alarms - ont-protection : ONT protection related alarms - secondary-megaco-term : secondary megaco termination related alarms - secondary-sip-term : secondary sip termination related alarms - cas-r2-channel : CAS R2 channel related alarms - lldpmed : lldpmed alarms - pseudo-wire : pseudo Wire related alarms - link-agg : Link aggregation related alarms - fcs-exceed : FCS auto-recovery related alarms - e1t1-interface : E1/T1 physical interfaces related alarms	
name	Parameter type: <Alarm::almtypeL2forwardihub> (l2fw-stp-exception l2fw-stp-root-guard all) Possible values: - l2fw-stp-exception : STP exception condition is present in the SAP - l2fw-stp-root-guard : STP root gaurd violation is present - all : ihub-l2forward alarms	alarm name that are active <i>This element is only shown in detail mode.</i>
severity	Parameter type: <Alarm::AlarmSeverity> (indeterminate warning	the alarms severity level <i>This element is only shown in detail mode.</i>

101 query current alarms by filters

name	Type	Description
	minor major critical) Possible values: - indeterminate : alarm severity is indeterminate - warning : alarm severity is warning - minor : alarm severity is minor - major : alarm severity is major - critical : alarm severity is critical	
servaff	Parameter type: <Alarm::alarmServAffect> ((service-affecting yes) (noservice-affecting no)) Possible values: - service-affecting : make this alarm service affecting - yes : make this alarm service affecting - noservice-affecting : make this alarm not service affecting - no : make this alarm not service affecting	alarms affect service or not <i>This element is only shown in detail mode.</i>
time	Parameter type: <Sys::timeInSecs> - the time (yyyy-mm-dd:hour:minutes:secs) - unit: UTC	time in seconds when alarm was updated <i>This element is only shown in detail mode.</i>
descript	Parameter type: <Alarm::AddInfoString> - additional alarm information	alarm description <i>This element is only shown in detail mode.</i>

101.82 show current alarm by filters

Command Description

show current alarms by filters

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm query vprn [ (name) [ severity <Alarm::querySeverity> ] [ servaff <Alarm::queryServAffect> ] [
router-id <lhub::Router> ] ]
```

Command Parameters

Table 101.82-1 "show current alarm by filters" Resource Parameters

Resource Identifier	Type	Description
(name)	Format: (vprn-routes-limit vprn-ipv6-routes-limit dhcpv6-lease-limit dhcpv4-lease-limit all) Possible values: - vprn-routes-limit : limit of ip is reached - vprn-ipv6-routes-limit: limit of ipv6 is reached - dhcpv6-lease-limit : limit of dhcpv6 leases is reached - dhcpv4-lease-limit : limit of dhcpv4 leases is reached - all : vprn related alarms	alarm name of vprn
severity	Parameter type: <Alarm::querySeverity> Format: (indeterminate warning minor major critical all) Possible values: - indeterminate : alarm severity is indeterminate - warning : alarm severity is warning - minor : alarm severity is minor - major : alarm severity is major - critical : alarm severity is critical - all : all alarm severity	severity level of an alarm for reporting
servaff	Parameter type: <Alarm::queryServAffect>	serviceaffecting no

101 query current alarms by filters

Resource Identifier	Type	Description
	Format: (service-affecting noservice-affecting all) Possible values: - service-affecting : query alarm service affecting - noservice-affecting : query alarm not service affecting - all : query service affecting and not affecting alarms	serviceaffecting
router-id	Parameter type: <Ihub::Router> Format: (base <Ihub::Router>) Possible values: - base : base router Field type <Ihub::Router> - vprn service-id - range: [1...2147483647]	identifies the vprn service-id or the base router where the alarm has occurred

Command Output

Table 101.82-2 "show current alarm by filters" Display parameters

Specific Information		
name	Type	Description
aidinfo	Parameter type: <Alarm::AddInfoString> - additional alarm information	alarm AID parameters <i>This element is only shown in detail mode.</i>
type	Parameter type: <Alarm::alarmIHUBType> (equipment eqpt-holder plug-in-unit atm custom e1 ima-group ima-link redundancy shdsl ether-itf traffic-overflow qos-queue temporal spatial (software-mngt sw-mgmt) xdsl xdsl-ext xdsl-tca olt-gen eo-conv authentication bonding sfp shdsl-isam custom-ext-alarm plug-in-unit-ext sip-user-agent sip-plugin-unit	type of the alarms that are active <i>This element is only shown in detail mode.</i>

name	Type	Description
	sip-termination e1-sip-termination filetransfer external-device l2forward ether-tca ether-sfp megaco-media-gw megaco-sig-gw megaco-plug-unit megaco-term megaco-sig-lt eqpt-supplemental eqpt-holder-ext lsmredundancy sync mcsrc vlanport vect-line vect-board otdr sip-dial-plan sip-vsp sip-server bgp rip lag ihub-general vprn isis ospf ihub-l2forward vpls ihub-equip ihub-link eont-phyoam ellid epon eont-services-lan eolt-ont-tca eont-sw-dl ldp mpls sdp epipe ihub-ipv6 pim li mgmt-sec-access bfd ai tr069serv ontsnmp bulk-sync protection-group ont sfu-sup	

101 query current alarms by filters

name	Type	Description
	soho-sup	
	mdu-sup	
	ont-ani	
	sfu-sup2	
	soho-sup2	
	mdu-sup2	
	sfprssi	
	eoltrssi	
	cfm	
	sfpe1t1-framer	
	sfpe1t1-clock	
	pppcc-engine-tca	
	eth-cfm	
	rsvp	
	ihub-tca	
	eth-ring	
	efm-oam	
	ont-loopdetect	
	ont-video	
	ont-ces	
	ont-voip	
	ont-video-ani	
	ont-pwe	
	ont-cese1	
	ont-xdsl	
	ont-xdsl-tca	
	ont-hpna	
	ont-sip-agent-cfg	
	ont-voip-cfg	
	ont-mgc	
	ont-ploam	
	ont-gen	
	ont-card	
	ont-pots	
	ont-lan	
	ont-moca	
	ont-tc-tca	
	ont-moca-tca	
	ont-l2uni-eth-tca	
	olt-pon-tc-tca	
	olt-pon-util-tca	
	olt-chpr-util-tca	
	olt-ont-tc-tca	
	ont-tca	
	ont-pots-supplemental	
	sfu-ploam	
	sfu-gen	
	soho-ploam	
	soho-gen	
	mdu-ploam	
	mdu-gen	
	ont-veip	
	ont-iphost	
	alarm-table	
	auto-switch	
	channel-pair	
	ont-cfg-dld	

name	Type	Description
	olt-chpair-tc-tca hgu-tr069 eqpt-psu ont-protection secondary-megaco-term secondary-sip-term cas-r2-channel lldpmed pseudo-wire link-agg fcs-exceed e1t1-interface) Possible values: - equipment : equipment alarms - eqpt-holder : equipment holder alarms - plug-in-unit : plugin unit alarms - atm : ATM alarms - custom : customizable alarms - e1 : e1 alarms - ima-group : ima-group alarms - ima-link : ima-link alarms - redundancy : redundancy alarms - shdsl : shdsl alarms - ether-itf : ethernet interface alarms - traffic-overflow : Traffic overflow alarms - qos-queue : qos queue alarms - temporal : temporal alarms - spatial : spatial alarms - software-mngt : software management alarms - sw-mgmt : software management alarms - xdsl : xDSL alarms - xdsl-ext : other xDSL alarms - xdsl-tca : xDSL threshold cross alarms - olt-gen : OLT general alarms - eo-conv : E/O conversion related alarms - authentication : authentication related alarms - bonding : bonding-group related alarms - sfp : SFP related alarms - shdsl-isam : shdsl isam alarms - custom-ext-alarm : customizable external alarms - plug-in-unit-ext : other plugin unit alarms - sip-user-agent : sip user agent related alarms - sip-plugin-unit : sip plug in unit related alarms - sip-termination : sip termination related alarms - e1-sip-termination : E1 sip termination related alarms - filetransfer : file transfer server alarms - external-device : external device related alarms - l2forward : l2forward related alarms - ether-tca : ethernet threshold cross alarms - ether-sfp : ethernet SFP related alarms - megaco-media-gw : megaco media gateway related alarms - megaco-sig-gw : megaco signaling gateway related alarms - megaco-plug-unit : megaco plug unit related alarms - megaco-term : megaco termination related alarms - megaco-sig-lt : megaco signaling lt related alarms - eqpt-supplemental : equipment supplemental alarms - eqpt-holder-ext : other equipment holder alarms	

101 query current alarms by filters

name	Type	Description
	- lsmredundancy : lsm redundancy alarms - sync : synce and bits alarms - mcsrc : multicast source alarms - vlanport : vlanport alarms - vect-line : xDSL vectoring line alarms - vect-board : xDSL vectoring board alarms - otdr : otdr alarms - sip-dial-plan : sip dial plan related alarms - sip-vsp : sip vsp related alarms - sip-server : sip server related alarms - bgp : bgp related alarms - rip : rip related alarms - lag : LAG related alarms - ihub-general : IHUB general related alarms - vprn : vprn related alarms - isis : isis related alarms - ospf : ospf related alarms - ihub-l2forward : ihub-l2forward alarms - vpls : vpls related alarms - ihub-equip : ihub-equip related alarms - ihub-link : ihub-link related alarms - eont-phyoam : eont phyoam related alarms - ellid : ellid related alarms - epon : epon related alarms - eont-services-lan : eon phyoam related alarms - eolt-ont-tca : eon phyoam related alarms - eont-sw-dl : eon phyoam related alarms - ldp : ldp related alarms - mpls : mpls related alarms - sdp : sdp related alarms - epipe : epipe related alarms - ihub-ipv6 : ihub-ipv6 related alarms - pim : pim related alarms - li : lawful intercept related alarms - mgmt-sec-access : management security related alarms - bfd : bfd related alarms - ai : Application Intelligence related alarms - tr069serv : tr069 server related alarms - ontsnmp : ont snmp related alarms - bulk-sync : bulk-sync related alarms - protection-group : port protection group related alarms - ont : ONT general supplemental related alarms - sfu-sup : SFU ONT general supplemental related alarms - soho-sup : SOHO ONT general supplemental related alarms - mdu-sup : MDU ONT general supplemental related alarms - ont-ani : ONT general supplemental 2 related alarms - sfu-sup2 : SFU ONT general supplemental 2 related alarms - soho-sup2 : SOHO ONT general supplemental 2 related alarms - mdu-sup2 : MDU ONT general supplemental 2 related alarms - sfprssi : SFP RSSI related alarms - eoltrssi : epon olt Sfp RSSI related alarms - cfm : Cfm related alarms - sfpe1t1-framer : SFP 2e1t1 framer alarms - sfpe1t1-clock : SFP 2e1t1 clock alarms	

name	Type	Description
	- pppcc-engine-tca : PPPOE Cross Connect Engine TCA related alarm - eth-cfm : eth-cfm related alarms - rsvp : rsvp related alarms - ihub-tca : IHUB TCA related alarms - eth-ring : eth-ring related alarms - efm-oam : EFM-OAM related alarms - ont-loopdetect : ont loop detect related alarms - ont-video : ont services video related alarms - ont-ces : ont services ces related alarms - ont-voip : ont services voip related alarms - ont-video-ani : ont services video ani related alarms - ont-pwe : ont services pwe related alarms - ont-cese1 : ont services cese1 related alarms - ont-xdsl : ont services xdsl related alarms - ont-xdsl-tca : ont services xdsl tca related alarms - ont-hpna : ont hpna related alarms - ont-sip-agent-cfg : ont services voip sip agent config related alarms - ont-voip-cfg : ont services voip config related alarms - ont-mgc : ont mgc related alarms - ont-ploam : ONT PLOAM related alarms - ont-gen : ONT GENERAL related alarms - ont-card : ONT Subscriber Card related alarms - ont-pots : ONT Services POTS related alarms - ont-lan : ONT Services LAN related alarms - ont-moca : ONT MoCA related alarms - ont-tc-tca : ONT TC TCA related alarms - ont-moca-tca : ONT MoCA TCA related alarms - ont-l2uni-eth-tca : ONT L2 UNI Ethernet TCA related alarms - olt-pon-tc-tca : OLT PON TC TCA related alarms - olt-pon-util-tca : OLT PON utilization TCA related alarms - olt-chpr-util-tca : OLT channel-pair utilization TCA related alarms - olt-ont-tc-tca : OLT ONT TC TCA related alarms - ont-tca : ONT TCA related alarms - ont-pots-supplemental : ONT POTS Supplemental related alarms - sfu-ploam : SFU ONT PLOAM related alarms - sfu-gen : SFU ONT general related alarms - soho-ploam : SOHO ONT PLOAM related alarms - soho-gen : SOHO ONT general related alarms - mdu-ploam : MDU ONT PLOAM related alarms - mdu-gen : MDU ONT general related alarms - ont-veip : ONT VEIP related alarms - ont-iphost : ONT IP HOST related alarms - alarm-table : alarm table related alarms - auto-switch : auto-switch related alarms - channel-pair : channel pair related alarms - ont-cfg-dld : ont configure file download related alarms - olt-chpair-tc-tca : OLT CHANNELPAIR TC TCA related alarms - hgu-tr069 : hgu tr069 related alarms - eqpt-psu : equipment psu alarms - ont-protection : ONT protection related alarms - secondary-megaco-term : secondary megaco termination	

101 query current alarms by filters

name	Type	Description
	related alarms - secondary-sip-term : secondary sip termination related alarms - cas-r2-channel : CAS R2 channel related alarms - lldpmed : lldpmed alarms - pseudo-wire : pseudo Wire related alarms - link-agg : Link aggregation related alarms - fcs-exceed : FCS auto-recovery related alarms - e1t1-interface : E1/T1 physical interfaces related alarms	
name	Parameter type: <Alarm::almtypeVprnihub> (vprn-routes-limit vprn-ipv6-routes-limit dhcpv6-lease-limit dhcpv4-lease-limit all) Possible values: - vprn-routes-limit : limit of ip is reached - vprn-ipv6-routes-limit: limit of ipv6 is reached - dhcpv6-lease-limit : limit of dhcpv6 leases is reached - dhcpv4-lease-limit : limit of dhcpv4 leases is reached - all : vprn related alarms	alarm name that are active <i>This element is only shown in detail mode.</i>
severity	Parameter type: <Alarm::AlarmSeverity> (indeterminate warning minor major critical) Possible values: - indeterminate : alarm severity is indeterminate - warning : alarm severity is warning - minor : alarm severity is minor - major : alarm severity is major - critical : alarm severity is critical	the alarms severity level <i>This element is only shown in detail mode.</i>
servaff	Parameter type: <Alarm::alarmServAffect> ((service-affecting yes) (noservice-affecting no)) Possible values: - service-affecting : make this alarm service affecting - yes : make this alarm service affecting - noservice-affecting : make this alarm not service affecting - no : make this alarm not service affecting	alarms affect service or not <i>This element is only shown in detail mode.</i>
time	Parameter type: <Sys::timeInSecs> - the time (yyyy-mm-dd:hour:minutes:secs) - unit: UTC	time in seconds when alarm was updated <i>This element is only shown in detail mode.</i>
descript	Parameter type: <Alarm::AddInfoString> - additional alarm information	alarm description <i>This element is only shown in detail mode.</i>

101.83 show current alarm by filters

Command Description

show current alarms by filters

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm query ospf [ (name) [ severity <Alarm::querySeverity> ] [ servaff <Alarm::queryServAffect> ] [
router-id <lhub::Router> ] ]
```

Command Parameters

Table 101.83-1 "show current alarm by filters" Resource Parameters

Resource Identifier	Type	Description
(name)	Format: (ospf-lsa-limit ospf-lsa-mid-limit ospf-neighbor-down ospf-instance-down all) Possible values: - ospf-lsa-limit : limit of received LSA's is reached - ospf-lsa-mid-limit : 90% of limit of received LSA's is reached - ospf-neighbor-down : OSPF neighbour is down - ospf-instance-down : OSPF instance is down or not - all : ospf related alarms	alarm name of ospf
severity	Parameter type: <Alarm::querySeverity> Format: (indeterminate warning minor major critical all) Possible values: - indeterminate : alarm severity is indeterminate - warning : alarm severity is warning - minor : alarm severity is minor - major : alarm severity is major - critical : alarm severity is critical - all : all alarm severity	severity level of an alarm for reporting

101 query current alarms by filters

Resource Identifier	Type	Description
servaff	Parameter type: <Alarm::queryServAffect> Format: (service-affecting noservice-affecting all) Possible values: - service-affecting : query alarm service affecting - noservice-affecting : query alarm not service affecting - all : query service affecting and not affecting alarms	serviceaffecting no serviceaffecting
router-id	Parameter type: <Ihub::Router> Format: (base <Ihub::Router>) Possible values: - base : base router Field type <Ihub::Router> - vprn service-id - range: [1...2147483647]	identifies the vprn service-id or the base router where the alarm has occurred

Command Output

Table 101.83-2 "show current alarm by filters" Display parameters

Specific Information		
name	Type	Description
aidinfo	Parameter type: <Alarm::AddInfoString> - additional alarm information	alarm AID parameters <i>This element is only shown in detail mode.</i>
type	Parameter type: <Alarm::alarmIHUBType> (equipment eqpt-holder plug-in-unit atm custom e1 ima-group ima-link redundancy shdsl ether-itf traffic-overflow qos-queue temporal spatial (software-mngt sw-mgmt) xdsl xdsl-ext xdsl-tca olt-gen eo-conv authentication bonding sfp shdsl-isam custom-ext-alarm plug-in-unit-ext sip-user-agent	type of the alarms that are active <i>This element is only shown in detail mode.</i>

name	Type	Description
	sip-plugin-unit sip-termination e1-sip-termination filetransfer external-device l2forward ether-tca ether-sfp megaco-media-gw megaco-sig-gw megaco-plug-unit megaco-term megaco-sig-lt eqpt-supplemental eqpt-holder-ext lsmredundancy sync mcsrc vlanport vect-line vect-board otdr sip-dial-plan sip-vsp sip-server bgp rip lag ihub-general vprn isis ospf ihub-l2forward vpls ihub-equip ihub-link eont-phyoam ellid epon eont-services-lan eolt-ont-tca eont-sw-dl ldp mpls sdp epipe ihub-ipv6 pim li mgmt-sec-access bfd ai tr069serv ontsnmp bulk-sync protection-group ont	

101 query current alarms by filters

name	Type	Description
	sfu-sup	
	soho-sup	
	mdu-sup	
	ont-ani	
	sfu-sup2	
	soho-sup2	
	mdu-sup2	
	sfprssi	
	eoltrssi	
	cfm	
	sfpe1t1-framer	
	sfpe1t1-clock	
	pppcc-engine-tca	
	eth-cfm	
	rsvp	
	ihub-tca	
	eth-ring	
	efm-oam	
	ont-loopdetect	
	ont-video	
	ont-ces	
	ont-voip	
	ont-video-ani	
	ont-pwe	
	ont-cese1	
	ont-xdsl	
	ont-xdsl-tca	
	ont-hpna	
	ont-sip-agent-cfg	
	ont-voip-cfg	
	ont-mgc	
	ont-ploam	
	ont-gen	
	ont-card	
	ont-pots	
	ont-lan	
	ont-moca	
	ont-tc-tca	
	ont-moca-tca	
	ont-l2uni-eth-tca	
	olt-pon-tc-tca	
	olt-pon-util-tca	
	olt-chpr-util-tca	
	olt-ont-tc-tca	
	ont-tca	
	ont-pots-supplemental	
	sfu-ploam	
	sfu-gen	
	soho-ploam	
	soho-gen	
	mdu-ploam	
	mdu-gen	
	ont-veip	
	ont-iphost	
	alarm-table	
	auto-switch	
	channel-pair	

name	Type	Description
	ont-cfg-dld olt-chpair-tc-tca hgu-tr069 eqpt-psu ont-protection secondary-megaco-term secondary-sip-term cas-r2-channel lldpmed pseudo-wire link-agg fcs-exceed e1t1-interface) Possible values: - equipment : equipment alarms - eqpt-holder : equipment holder alarms - plug-in-unit : plugin unit alarms - atm : ATM alarms - custom : customizable alarms - e1 : e1 alarms - ima-group : ima-group alarms - ima-link : ima-link alarms - redundancy : redundancy alarms - shdsl : shdsl alarms - ether-itf : ethernet interface alarms - traffic-overflow : Traffic overflow alarms - qos-queue : qos queue alarms - temporal : temporal alarms - spatial : spatial alarms - software-mngt : software management alarms - sw-mgmt : software management alarms - xdsl : xDSL alarms - xdsl-ext : other xDSL alarms - xdsl-tca : xDSL threshold cross alarms - olt-gen : OLT general alarms - eo-conv : E/O conversion related alarms - authentication : authentication related alarms - bonding : bonding-group related alarms - sfp : SFP related alarms - shdsl-isam : shdsl isam alarms - custom-ext-alarm : customizable external alarms - plug-in-unit-ext : other plugin unit alarms - sip-user-agent : sip user agent related alarms - sip-plugin-unit : sip plug in unit related alarms - sip-termination : sip termination related alarms - e1-sip-termination : E1 sip termination related alarms - filetransfer : file transfer server alarms - external-device : external device related alarms - l2forward : l2forward related alarms - ether-tca : ethernet threshold cross alarms - ether-sfp : ethernet SFP related alarms - megaco-media-gw : megaco media gateway related alarms - megaco-sig-gw : megaco signaling gateway related alarms - megaco-plug-unit : megaco plug unit related alarms - megaco-term : megaco termination related alarms - megaco-sig-lt : megaco signaling lt related alarms - eqpt-supplemental : equipment supplemental alarms	

101 query current alarms by filters

name	Type	Description
	- eqpt-holder-ext : other equipment holder alarms - lsmredundancy : lsm redundancy alarms - sync : synce and bits alarms - mcsrsc : multicast source alarms - vlanport : vlanport alarms - vect-line : xDSL vectoring line alarms - vect-board : xDSL vectoring board alarms - otdr : otdr alarms - sip-dial-plan : sip dial plan related alarms - sip-vsp : sip vsp related alarms - sip-server : sip server related alarms - bgp : bgp related alarms - rip : rip related alarms - lag : LAG related alarms - ihub-general : IHUB general related alarms - vprn : vprn related alarms - isis : isis related alarms - ospf : ospf related alarms - ihub-l2forward : ihub-l2forward alarms - vpls : vpls related alarms - ihub-equip : ihub-equip related alarms - ihub-link : ihub-link related alarms - eont-phyoam : eont phyoam related alarms - ellid : ellid related alarms - epon : epon related alarms - eont-services-lan : eon phyoam related alarms - eolt-ont-tca : eon phyoam related alarms - eont-sw-dl : eon phyoam related alarms - ldp : ldp related alarms - mpls : mpls related alarms - sdp : sdp related alarms - epipe : epipe related alarms - ihub-ipv6 : ihub-ipv6 related alarms - pim : pim related alarms - li : lawful intercept related alarms - mgmt-sec-access : management security related alarms - bfd : bfd related alarms - ai : Application Intelligence related alarms - tr069serv : tr069 server related alarms - ontsnmp : ont snmp related alarms - bulk-sync : bulk-sync related alarms - protection-group : port protection group related alarms - ont : ONT general supplemental related alarms - sfu-sup : SFU ONT general supplemental related alarms - soho-sup : SOHO ONT general supplemental related alarms - mdu-sup : MDU ONT general supplemental related alarms - ont-ani : ONT general supplemental 2 related alarms - sfu-sup2 : SFU ONT general supplemental 2 related alarms - soho-sup2 : SOHO ONT general supplemental 2 related alarms - mdu-sup2 : MDU ONT general supplemental 2 related alarms - sfrssi : SFP RSSI related alarms - eoltrssi : epon olt Sfp RSSI related alarms - cfm : Cfm related alarms - sfpe1t1-framer : SFP 2e1t1 framer alarms	

name	Type	Description
	- sfpe1t1-clock : SFP 2e1t1 clock alarms - pppcc-engine-tca : PPPOE Cross Connect Engine TCA related alarm - eth-cfm : eth-cfm related alarms - rsvp : rsvp related alarms - ihub-tca : IHUB TCA related alarms - eth-ring : eth-ring related alarms - efm-oam : EFM-OAM related alarms - ont-loopdetect : ont loop detect related alarms - ont-video : ont services video related alarms - ont-ces : ont services ces related alarms - ont-voip : ont services voip related alarms - ont-video-ani : ont services video ani related alarms - ont-pwe : ont services pwe related alarms - ont-cese1 : ont services cese1 related alarms - ont-xdsl : ont services xdsl related alarms - ont-xdsl-tca : ont services xdsl tca related alarms - ont-hpna : ont hpna related alarms - ont-sip-agent-cfg : ont services voip sip agent config related alarms - ont-voip-cfg : ont services voip config related alarms - ont-mgc : ont mgc related alarms - ont-ploam : ONT PLOAM related alarms - ont-gen : ONT GENERAL related alarms - ont-card : ONT Subscriber Card related alarms - ont-pots : ONT Services POTS related alarms - ont-lan : ONT Services LAN related alarms - ont-moca : ONT MoCA related alarms - ont-tc-tca : ONT TC TCA related alarms - ont-moca-tca : ONT MoCA TCA related alarms - ont-l2uni-eth-tca : ONT L2 UNI Ethernet TCA related alarms - olt-pon-tc-tca : OLT PON TC TCA related alarms - olt-pon-util-tca : OLT PON utilization TCA related alarms - olt-chpr-util-tca : OLT channel-pair utilization TCA related alarms - olt-ont-tc-tca : OLT ONT TC TCA related alarms - ont-tca : ONT TCA related alarms - ont-pots-supplemental : ONT POTS Supplemental related alarms - sfu-ploam : SFU ONT PLOAM related alarms - sfu-gen : SFU ONT general related alarms - soho-ploam : SOHO ONT PLOAM related alarms - soho-gen : SOHO ONT general related alarms - mdu-ploam : MDU ONT PLOAM related alarms - mdu-gen : MDU ONT general related alarms - ont-veip : ONT VEIP related alarms - ont-iphost : ONT IP HOST related alarms - alarm-table : alarm table related alarms - auto-switch : auto-switch related alarms - channel-pair : channel pair related alarms - ont-cfg-dld : ont configure file download related alarms - olt-chpair-tc-tca : OLT CHANNELPAIR TC TCA related alarms - hgu-tr069 : hgu tr069 related alarms - eqpt-psu : equipment psu alarms - ont-protection : ONT protection related alarms	

101 query current alarms by filters

name	Type	Description
	- secondary-megaco-term : secondary megaco termination related alarms - secondary-sip-term : secondary sip termination related alarms - cas-r2-channel : CAS R2 channel related alarms - lldpmed : lldpmed alarms - pseudo-wire : pseudo Wire related alarms - link-agg : Link aggregation related alarms - fcs-exceed : FCS auto-recovery related alarms - e1t1-interface : E1/T1 physical interfaces related alarms	
name	Parameter type: <Alarm::alarmTypeOspfihub> (ospf-lsa-limit ospf-lsa-mid-limit ospf-neighbor-down ospf-instance-down all) Possible values: - ospf-lsa-limit : limit of received LSA's is reached - ospf-lsa-mid-limit : 90% of limit of received LSA's is reached - ospf-neighbor-down : OSPF neighbour is down - ospf-instance-down : OSPF instance is down or not - all : ospf related alarms	alarm name that are active <i>This element is only shown in detail mode.</i>
severity	Parameter type: <Alarm::AlarmSeverity> (indeterminate warning minor major critical) Possible values: - indeterminate : alarm severity is indeterminate - warning : alarm severity is warning - minor : alarm severity is minor - major : alarm severity is major - critical : alarm severity is critical	the alarms severity level <i>This element is only shown in detail mode.</i>
servaff	Parameter type: <Alarm::alarmServAffect> ((service-affecting yes) (noservice-affecting no)) Possible values: - service-affecting : make this alarm service affecting - yes : make this alarm service affecting - noservice-affecting : make this alarm not service affecting - no : make this alarm not service affecting	alarms affect service or not <i>This element is only shown in detail mode.</i>
time	Parameter type: <Sys::timeInSecs> - the time (yyyy-mm-dd:hour:minutes:secs) - unit: UTC	time in seconds when alarm was updated <i>This element is only shown in detail mode.</i>
descript	Parameter type: <Alarm::AddInfoString> - additional alarm information	alarm description <i>This element is only shown in detail mode.</i>

101.84 show current alarm by filters

Command Description

show current alarms by filters

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm query rip [ (name) [ severity <Alarm::querySeverity> ] [ servaff <Alarm::queryServAffect> ] [
router-id <lhub::Router> ] ]
```

Command Parameters

Table 101.84-1 "show current alarm by filters" Resource Parameters

Resource Identifier	Type	Description
(name)	Format: (rip-instance-down all) Possible values: - rip-instance-down : rip instance down - all : rip related alarms	alarm name of rip
severity	Parameter type: <Alarm::querySeverity> Format: (indeterminate warning minor major critical all) Possible values: - indeterminate : alarm severity is indeterminate - warning : alarm severity is warning - minor : alarm severity is minor - major : alarm severity is major - critical : alarm severity is critical - all : all alarm severity	severity level of an alarm for reporting
servaff	Parameter type: <Alarm::queryServAffect> Format: (service-affecting noservice-affecting all) Possible values: - service-affecting : query alarm service affecting	serviceaffecting no

101 query current alarms by filters

Resource Identifier	Type	Description
	- noservice-affecting : query alarm not service affecting - all : query service affecting and not affecting alarms	
router-id	Parameter type: <Ihub::Router> Format: (base <Ihub::Router>) Possible values: - base : base router Field type <Ihub::Router> - vprn service-id - range: [1...2147483647]	identifies the vprn service-id or the base router where the alarm has occurred

Command Output

Table 101.84-2 "show current alarm by filters" Display parameters

Specific Information		
name	Type	Description
aidinfo	Parameter type: <Alarm::AddInfoString> - additional alarm information	alarm AID parameters <i>This element is only shown in detail mode.</i>
type	Parameter type: <Alarm::alarmIHUBType> (equipment eqpt-holder plug-in-unit atm custom e1 ima-group ima-link redundancy shdsl ether-itf traffic-overflow qos-queue temporal spatial (software-mngt sw-mgmt) xdsl xdsl-ext xdsl-tca olt-gen eo-conv authentication bonding sfp shdsl-isam custom-ext-alarm plug-in-unit-ext sip-user-agent sip-plugin-unit sip-termination e1-sip-termination filetransfer external-device l2forward ether-tca	type of the alarms that are active <i>This element is only shown in detail mode.</i>

name	Type	Description
	ether-sfp	
	megaco-media-gw	
	megaco-sig-gw	
	megaco-plug-unit	
	megaco-term	
	megaco-sig-lt	
	eqpt-supplemental	
	eqpt-holder-ext	
	lsmredundancy	
	sync	
	mcsrc	
	vlanport	
	vect-line	
	vect-board	
	otdr	
	sip-dial-plan	
	sip-vsp	
	sip-server	
	bgp	
	rip	
	lag	
	ihub-general	
	vprn	
	isis	
	ospf	
	ihub-l2forward	
	vpls	
	ihub-equip	
	ihub-link	
	eont-phyoam	
	ellid	
	epon	
	eont-services-lan	
	eolt-ont-tca	
	eont-sw-dl	
	ldp	
	mpls	
	sdp	
	epipe	
	ihub-ipv6	
	pim	
	li	
	mgmt-sec-access	
	bfd	
	ai	
	tr069serv	
	ontsnmp	
	bulk-sync	
	protection-group	
	ont	
	sfu-sup	
	soho-sup	
	mdu-sup	
	ont-ani	
	sfu-sup2	
	soho-sup2	
	mdu-sup2	

101 query current alarms by filters

name	Type	Description
	sfrssi eoltrssi cfm sfpe1t1-framer sfpe1t1-clock pppcc-engine-tca eth-cfm rsvp ihub-tca eth-ring efm-oam ont-loopdetect ont-video ont-ces ont-voip ont-video-ani ont-pwe ont-cese1 ont-xdsl ont-xdsl-tca ont-hpna ont-sip-agent-cfg ont-voip-cfg ont-mgc ont-ploam ont-gen ont-card ont-pots ont-lan ont-moca ont-tc-tca ont-moca-tca ont-l2uni-eth-tca olt-pon-tc-tca olt-pon-util-tca olt-chpr-util-tca olt-ont-tc-tca ont-tca ont-pots-supplemental sfu-ploam sfu-gen soho-ploam soho-gen mdu-ploam mdu-gen ont-veip ont-iphost alarm-table auto-switch channel-pair ont-cfg-dld olt-chpair-tc-tca hgu-tr069 eqpt-psu ont-protection secondary-megaco-term secondary-sip-term	

name	Type	Description
	cas-r2-channel lldpmed pseudo-wire link-agg fcs-exceed e1t1-interface) Possible values: - equipment : equipment alarms - eqpt-holder : equipment holder alarms - plug-in-unit : plugin unit alarms - atm : ATM alarms - custom : customizable alarms - e1 : e1 alarms - ima-group : ima-group alarms - ima-link : ima-link alarms - redundancy : redundancy alarms - shdsl : shdsl alarms - ether-itf : ethernet interface alarms - traffic-overflow : Traffic overflow alarms - qos-queue : qos queue alarms - temporal : temporal alarms - spatial : spatial alarms - software-mngt : software management alarms - sw-mgmt : software management alarms - xdsl : xDSL alarms - xdsl-ext : other xDSL alarms - xdsl-tca : xDSL threshold cross alarms - olt-gen : OLT general alarms - eo-conv : E/O conversion related alarms - authentication : authentication related alarms - bonding : bonding-group related alarms - sfp : SFP related alarms - shdsl-isam : shdsl isam alarms - custom-ext-alarm : customizable external alarms - plug-in-unit-ext : other plugin unit alarms - sip-user-agent : sip user agent related alarms - sip-plugin-unit : sip plug in unit related alarms - sip-termination : sip termination related alarms - e1-sip-termination : E1 sip termination related alarms - filetransfer : file transfer server alarms - external-device : external device related alarms - l2forward : l2forward related alarms - ether-tca : ethernet threshold cross alarms - ether-sfp : ethernet SFP related alarms - megaco-media-gw : megaco media gateway related alarms - megaco-sig-gw : megaco signaling gateway related alarms - megaco-plug-unit : megaco plug unit related alarms - megaco-term : megaco termination related alarms - megaco-sig-lt : megaco signaling lt related alarms - eqpt-supplemental : equipment supplemental alarms - eqpt-holder-ext : other equipment holder alarms - lsmredundancy : lsm redundancy alarms - sync : synce and bits alarms - mcsrc : multicast source alarms - vlanport : vlanport alarms - vect-line : xDSL vectoring line alarms - vect-board : xDSL vectoring board alarms	

101 query current alarms by filters

name	Type	Description
	- otdr : otdr alarms - sip-dial-plan : sip dial plan related alarms - sip-vsp : sip vsp related alarms - sip-server : sip server related alarms - bgp : bgp related alarms - rip : rip related alarms - lag : LAG related alarms - ihub-general : IHUB general related alarms - vprn : vprn related alarms - isis : isis related alarms - ospf : ospf related alarms - ihub-l2forward : ihub-l2forward alarms - vpls : vpls related alarms - ihub-equip : ihub-equip related alarms - ihub-link : ihub-link related alarms - eont-phyoam : eont phyoam related alarms - ellid : ellid related alarms - epon : epon related alarms - eont-services-lan : eon phyoam related alarms - eolt-ont-tca : eon phyoam related alarms - eont-sw-dl : eon phyoam related alarms - ldp : ldp related alarms - mpls : mpls related alarms - sdp : sdp related alarms - epipe : epipe related alarms - ihub-ipv6 : ihub-ipv6 related alarms - pim : pim related alarms - li : lawful intercept related alarms - mgmt-sec-access : management security related alarms - bfd : bfd related alarms - ai : Application Intelligence related alarms - tr069serv : tr069 server related alarms - ontsnmp : ont snmp related alarms - bulk-sync : bulk-sync related alarms - protection-group : port protection group related alarms - ont : ONT general supplemental related alarms - sfu-sup : SFU ONT general supplemental related alarms - soho-sup : SOHO ONT general supplemental related alarms - mdu-sup : MDU ONT general supplemental related alarms - ont-ani : ONT general supplemental 2 related alarms - sfu-sup2 : SFU ONT general supplemental 2 related alarms - soho-sup2 : SOHO ONT general supplemental 2 related alarms - mdu-sup2 : MDU ONT general supplemental 2 related alarms - sfprssi : SFP RSSI related alarms - eoltrssi : epon olt Sfp RSSI related alarms - cfm : Cfm related alarms - sfpe1t1-framer : SFP 2e1t1 framer alarms - sfpe1t1-clock : SFP 2e1t1 clock alarms - pppcc-engine-tca : PPPOE Cross Connect Engine TCA related alarm - eth-cfm : eth-cfm related alarms - rsvp : rsvp related alarms - ihub-tca : IHUB TCA related alarms - eth-ring : eth-ring related alarms	

name	Type	Description
	- efm-oam : EFM-OAM related alarms - ont-loopdetect : ont loop detect related alarms - ont-video : ont services video related alarms - ont-ces : ont services ces related alarms - ont-voip : ont services voip related alarms - ont-video-ani : ont services video ani related alarms - ont-pwe : ont services pwe related alarms - ont-cese1 : ont services cese1 related alarms - ont-xdsl : ont services xdsl related alarms - ont-xdsl-tca : ont services xdsl tca related alarms - ont-hpna : ont hpna related alarms - ont-sip-agent-cfg : ont services voip sip agent config related alarms - ont-voip-cfg : ont services voip config related alarms - ont-mgc : ont mgc related alarms - ont-ploam : ONT PLOAM related alarms - ont-gen : ONT GENERAL related alarms - ont-card : ONT Subscriber Card related alarms - ont-pots : ONT Services POTS related alarms - ont-lan : ONT Services LAN related alarms - ont-moca : ONT MoCA related alarms - ont-tc-tca : ONT TC TCA related alarms - ont-moca-tca : ONT MoCA TCA related alarms - ont-l2uni-eth-tca : ONT L2 UNI Ethernet TCA related alarms - olt-pon-tc-tca : OLT PON TC TCA related alarms - olt-pon-util-tca : OLT PON utilization TCA related alarms - olt-chpr-util-tca : OLT channel-pair utilization TCA related alarms - olt-ont-tc-tca : OLT ONT TC TCA related alarms - ont-tca : ONT TCA related alarms - ont-pots-supplemental : ONT POTS Supplemental related alarms - sfu-ploam : SFU ONT PLOAM related alarms - sfu-gen : SFU ONT general related alarms - soho-ploam : SOHO ONT PLOAM related alarms - soho-gen : SOHO ONT general related alarms - mdu-ploam : MDU ONT PLOAM related alarms - mdu-gen : MDU ONT general related alarms - ont-veip : ONT VEIP related alarms - ont-iphost : ONT IP HOST related alarms - alarm-table : alarm table related alarms - auto-switch : auto-switch related alarms - channel-pair : channel pair related alarms - ont-cfg-dld : ont configure file download related alarms - olt-chpair-tc-tca : OLT CHANNELPAIR TC TCA related alarms - hgu-tr069 : hgu tr069 related alarms - eqpt-psu : equipment psu alarms - ont-protection : ONT protection related alarms - secondary-megaco-term : secondary megaco termination related alarms - secondary-sip-term : secondary sip termination related alarms - cas-r2-channel : CAS R2 channel related alarms - lldpmed : lldpmed alarms - pseudo-wire : pseudo Wire related alarms	

101 query current alarms by filters

name	Type	Description
	- link-agg : Link aggregation related alarms - fcs-exceed : FCS auto-recovery related alarms - e1t1-interface : E1/T1 physical interfaces related alarms	
name	Parameter type: <Alarm::almtypeRipihub> (rip-instance-down all) Possible values: - rip-instance-down : rip instance down - all : rip related alarms	alarm name that are active <i>This element is only shown in detail mode.</i>
severity	Parameter type: <Alarm::AlarmSeverity> (indeterminate warning minor major critical) Possible values: - indeterminate : alarm severity is indeterminate - warning : alarm severity is warning - minor : alarm severity is minor - major : alarm severity is major - critical : alarm severity is critical	the alarms severity level <i>This element is only shown in detail mode.</i>
servaff	Parameter type: <Alarm::alarmServAffect> ((service-affecting yes) (noservice-affecting no)) Possible values: - service-affecting : make this alarm service affecting - yes : make this alarm service affecting - noservice-affecting : make this alarm not service affecting - no : make this alarm not service affecting	alarms affect service or not <i>This element is only shown in detail mode.</i>
time	Parameter type: <Sys::timeInSecs> - the time (yyyy-mm-dd:hour:minutes:secs) - unit: UTC	time in seconds when alarm was updated <i>This element is only shown in detail mode.</i>
descript	Parameter type: <Alarm::AddInfoString> - additional alarm information	alarm description <i>This element is only shown in detail mode.</i>

101.85 show current alarm by filters

Command Description

show current alarms by filters

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm query vpls [ (name) [ severity <Alarm::querySeverity> ] [ servaff <Alarm::queryServAffect> ] [ service-id <Alarm::ServiceId> ] ]
```

Command Parameters

Table 101.85-1 "show current alarm by filters" Resource Parameters

Resource Identifier	Type	Description
(name)	Format: (vpls-mfib-limit vpls-duplicate-mac vpls-fdb-limit vpls-self-duplic-mac vpls-sdp-self-dup-mac all) Possible values: - vpls-mfib-limit : limit of fib table is reached - vpls-duplicate-mac : duplicate mac address is detected - vpls-fdb-limit : limit of fdb table is reached - vpls-self-duplic-mac : duplicate of a system owned mac address detected on a sap - vpls-sdp-self-dup-mac : duplicate of a system owned mac address detected on a sdp binding - all : vpls related alarms	alarm name of vpls
severity	Parameter type: <Alarm::querySeverity> Format: (indeterminate warning minor major critical all) Possible values: - indeterminate : alarm severity is indeterminate - warning : alarm severity is warning - minor : alarm severity is minor	severity level of an alarm for reporting

101 query current alarms by filters

Resource Identifier	Type	Description
	- major : alarm severity is major - critical : alarm severity is critical - all : all alarm severity	
servaff	Parameter type: <Alarm::queryServAffect> Format: (service-affecting noservice-affecting all) Possible values: - service-affecting : query alarm service affecting - noservice-affecting : query alarm not service affecting - all : query service affecting and not affecting alarms	serviceaffecting no serviceaffecting
service-id	Parameter type: <Alarm::ServiceId> Format: - a profile index value - range: [1...2147483647]	identifies the vpls service-id where the alarm has occurred

Command Output

Table 101.85-2 "show current alarm by filters" Display parameters

Specific Information		
name	Type	Description
aidinfo	Parameter type: <Alarm::AddInfoString> - additional alarm information	alarm AID parameters <i>This element is only shown in detail mode.</i>
type	Parameter type: <Alarm::alarmIHUBType> (equipment eqpt-holder plug-in-unit atm custom e1 ima-group ima-link redundancy shdsl ether-itf traffic-overflow qos-queue temporal spatial (software-mngt sw-mgmt) xdsl xdsl-ext xdsl-tca olt-gen eo-conv authentication bonding sfp shdsl-isam custom-ext-alarm plug-in-unit-ext sip-user-agent sip-plugin-unit sip-termination	type of the alarms that are active <i>This element is only shown in detail mode.</i>

name	Type	Description
	e1-sip-termination filetransfer external-device l2forward ether-tca ether-sfp megaco-media-gw megaco-sig-gw megaco-plug-unit megaco-term megaco-sig-lt eqpt-supplemental eqpt-holder-ext lsmredundancy sync mcsrc vlanport vect-line vect-board otdr sip-dial-plan sip-vsp sip-server bgp rip lag ihub-general vprn isis ospf ihub-l2forward vpls ihub-equip ihub-link eont-phyoam ellid epon eont-services-lan eolt-ont-tca eont-sw-dl ldp mpls sdp epipe ihub-ipv6 pim li mgmt-sec-access bfd ai tr069serv ontsnmp bulk-sync protection-group ont sfu-sup soho-sup	

101 query current alarms by filters

name	Type	Description
	mdu-sup ont-ani sfu-sup2 soho-sup2 mdu-sup2 sfprssi eoltrssi cfm sfpe1t1-framer sfpe1t1-clock pppcc-engine-tca eth-cfm rsvp ihub-tca eth-ring efm-oam ont-loopdetect ont-video ont-ces ont-voip ont-video-ani ont-pwe ont-cese1 ont-xdsl ont-xdsl-tca ont-hpna ont-sip-agent-cfg ont-voip-cfg ont-mgc ont-ploam ont-gen ont-card ont-pots ont-lan ont-moca ont-tc-tca ont-moca-tca ont-l2uni-eth-tca olt-pon-tc-tca olt-pon-util-tca olt-chpr-util-tca olt-ont-tc-tca ont-tca ont-pots-supplemental sfu-ploam sfu-gen soho-ploam soho-gen mdu-ploam mdu-gen ont-veip ont-iphost alarm-table auto-switch channel-pair ont-cfg-dld olt-chpair-tc-tca	

name	Type	Description
	hgu-tr069 eqpt-psu ont-protection secondary-megaco-term secondary-sip-term cas-r2-channel lldpmed pseudo-wire link-agg fcs-exceed e1t1-interface) Possible values: - equipment : equipment alarms - eqpt-holder : equipment holder alarms - plug-in-unit : plugin unit alarms - atm : ATM alarms - custom : customizable alarms - e1 : e1 alarms - ima-group : ima-group alarms - ima-link : ima-link alarms - redundancy : redundancy alarms - shdsl : shdsl alarms - ether-itf : ethernet interface alarms - traffic-overflow : Traffic overflow alarms - qos-queue : qos queue alarms - temporal : temporal alarms - spatial : spatial alarms - software-mngt : software management alarms - sw-mgmt : software management alarms - xdsl : xDSL alarms - xdsl-ext : other xDSL alarms - xdsl-tca : xDSL threshold cross alarms - olt-gen : OLT general alarms - eo-conv : E/O conversion related alarms - authentication : authentication related alarms - bonding : bonding-group related alarms - sfp : SFP related alarms - shdsl-isam : shdsl isam alarms - custom-ext-alarm : customizable external alarms - plug-in-unit-ext : other plugin unit alarms - sip-user-agent : sip user agent related alarms - sip-plugin-unit : sip plug in unit related alarms - sip-termination : sip termination related alarms - e1-sip-termination : E1 sip termination related alarms - filetransfer : file transfer server alarms - external-device : external device related alarms - l2forward : l2forward related alarms - ether-tca : ethernet threshold cross alarms - ether-sfp : ethernet SFP related alarms - megaco-media-gw : megaco media gateway related alarms - megaco-sig-gw : megaco signaling gateway related alarms - megaco-plug-unit : megaco plug unit related alarms - megaco-term : megaco termination related alarms - megaco-sig-lt : megaco signaling lt related alarms - eqpt-supplemental : equipment supplemental alarms - eqpt-holder-ext : other equipment holder alarms - lsmredundancy : lsm redundancy alarms	

101 query current alarms by filters

name	Type	Description
	- sync : synce and bits alarms - mcsrc : multicast source alarms - vlanport : vlanport alarms - vect-line : xDSL vectoring line alarms - vect-board : xDSL vectoring board alarms - otdr : otdr alarms - sip-dial-plan : sip dial plan related alarms - sip-vsp : sip vsp related alarms - sip-server : sip server related alarms - bgp : bgp related alarms - rip : rip related alarms - lag : LAG related alarms - ihub-general : IHUB general related alarms - vprn : vprn related alarms - isis : isis related alarms - ospf : ospf related alarms - ihub-l2forward : ihub-l2forward alarms - vpls : vpls related alarms - ihub-equip : ihub-equip related alarms - ihub-link : ihub-link related alarms - eont-phyoam : eont phyoam related alarms - ellid : ellid related alarms - epon : epon related alarms - eont-services-lan : eon phyoam related alarms - eolt-ont-tca : eon phyoam related alarms - eont-sw-dl : eon phyoam related alarms - ldp : ldp related alarms - mpls : mpls related alarms - sdp : sdp related alarms - epipe : epipe related alarms - ihub-ipv6 : ihub-ipv6 related alarms - pim : pim related alarms - li : lawful intercept related alarms - mgmt-sec-access : management security related alarms - bfd : bfd related alarms - ai : Application Intelligence related alarms - tr069serv : tr069 server related alarms - ontsnmp : ont snmp related alarms - bulk-sync : bulk-sync related alarms - protection-group : port protection group related alarms - ont : ONT general supplemental related alarms - sfu-sup : SFU ONT general supplemental related alarms - soho-sup : SOHO ONT general supplemental related alarms - mdu-sup : MDU ONT general supplemental related alarms - ont-ani : ONT general supplemental 2 related alarms - sfu-sup2 : SFU ONT general supplemental 2 related alarms - soho-sup2 : SOHO ONT general supplemental 2 related alarms - mdu-sup2 : MDU ONT general supplemental 2 related alarms - sfprssi : SFP RSSI related alarms - eoltrssi : epon olt Sfp RSSI related alarms - cfm : Cfm related alarms - sfpe1t1-framer : SFP 2e1t1 framer alarms - sfpe1t1-clock : SFP 2e1t1 clock alarms - pppcc-engine-tca : PPPOE Cross Connect Engine TCA	

name	Type	Description
	- related alarm - eth-cfm : eth-cfm related alarms - rsvp : rsvp related alarms - ihub-tca : IHUB TCA related alarms - eth-ring : eth-ring related alarms - efm-oam : EFM-OAM related alarms - ont-loopdetect : ont loop detect related alarms - ont-video : ont services video related alarms - ont-ces : ont services ces related alarms - ont-voip : ont services voip related alarms - ont-video-ani : ont services video ani related alarms - ont-pwe : ont services pwe related alarms - ont-cese1 : ont services cese1 related alarms - ont-xdsl : ont services xdsl related alarms - ont-xdsl-tca : ont services xdsl tca related alarms - ont-hpna : ont hpna related alarms - ont-sip-agent-cfg : ont services voip sip agent config related alarms - ont-voip-cfg : ont services voip config related alarms - ont-mgc : ont mgc related alarms - ont-ploam : ONT PLOAM related alarms - ont-gen : ONT GENERAL related alarms - ont-card : ONT Subscriber Card related alarms - ont-pots : ONT Services POTS related alarms - ont-lan : ONT Services LAN related alarms - ont-moca : ONT MoCA related alarms - ont-tc-tca : ONT TC TCA related alarms - ont-moca-tca : ONT MoCA TCA related alarms - ont-l2uni-eth-tca : ONT L2 UNI Ethernet TCA related alarms - olt-pon-tc-tca : OLT PON TC TCA related alarms - olt-pon-util-tca : OLT PON utilization TCA related alarms - olt-chpr-util-tca : OLT channel-pair utilization TCA related alarms - olt-ont-tc-tca : OLT ONT TC TCA related alarms - ont-tca : ONT TCA related alarms - ont-pots-supplemental : ONT POTS Supplemental related alarms - sfu-ploam : SFU ONT PLOAM related alarms - sfu-gen : SFU ONT general related alarms - soho-ploam : SOHO ONT PLOAM related alarms - soho-gen : SOHO ONT general related alarms - mdu-ploam : MDU ONT PLOAM related alarms - mdu-gen : MDU ONT general related alarms - ont-veip : ONT VEIP related alarms - ont-iphost : ONT IP HOST related alarms - alarm-table : alarm table related alarms - auto-switch : auto-switch related alarms - channel-pair : channel pair related alarms - ont-cfg-dld : ont configure file download related alarms - olt-chpair-tc-tca : OLT CHANNELPAIR TC TCA related alarms - hgu-tr069 : hgu tr069 related alarms - eqpt-psu : equipment psu alarms - ont-protection : ONT protection related alarms - secondary-megaco-term : secondary megaco termination related alarms	

101 query current alarms by filters

name	Type	Description
	- secondary-sip-term : secondary sip termination related alarms - cas-r2-channel : CAS R2 channel related alarms - lldpmed : lldpmed alarms - pseudo-wire : pseudo Wire related alarms - link-agg : Link aggregation related alarms - fcs-exceed : FCS auto-recovery related alarms - e1t1-interface : E1/T1 physical interfaces related alarms	
name	Parameter type: <Alarm::almtypeVplsHub> (vpls-mfib-limit vpls-duplicate-mac vpls-fdb-limit vpls-self-duplic-mac vpls-sdp-self-dup-mac all) Possible values: - vpls-mfib-limit : limit of fib table is reached - vpls-duplicate-mac : duplicate mac address is detected - vpls-fdb-limit : limit of fdb table is reached - vpls-self-duplic-mac : duplicate of a system owned mac address detected on a sap - vpls-sdp-self-dup-mac : duplicate of a system owned mac address detected on a sdp binding - all : vpls related alarms	alarm name that are active <i>This element is only shown in detail mode.</i>
severity	Parameter type: <Alarm::AlarmSeverity> (indeterminate warning minor major critical) Possible values: - indeterminate : alarm severity is indeterminate - warning : alarm severity is warning - minor : alarm severity is minor - major : alarm severity is major - critical : alarm severity is critical	the alarms severity level <i>This element is only shown in detail mode.</i>
servaff	Parameter type: <Alarm::alarmServAffect> ((service-affecting yes) (noservice-affecting no)) Possible values: - service-affecting : make this alarm service affecting - yes : make this alarm service affecting - noservice-affecting : make this alarm not service affecting - no : make this alarm not service affecting	alarms affect service or not <i>This element is only shown in detail mode.</i>
time	Parameter type: <Sys::timeInSecs> - the time (yyyy-mm-dd:hour:minutes:secs) - unit: UTC	time in seconds when alarm was updated <i>This element is only shown in detail mode.</i>
descript	Parameter type: <Alarm::AddInfoString> - additional alarm information	alarm description <i>This element is only shown in detail mode.</i>

101.86 show current alarm by filters

Command Description

show current alarms by filters

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm query ihub-link [ (name) [ severity <Alarm::querySeverity> ] [ servaff <Alarm::queryServAffect> ] [ port <Ihub::EtherPort> ] ]
```

Command Parameters

Table 101.86-1 "show current alarm by filters" Resource Parameters

Resource Identifier	Type	Description
(name)	Format: (link-down link-lagport-add-fail link-conf-mismatch all) Possible values: - link-down : link is down - link-lagport-add-fail : failure to add port to LAG - link-conf-mismatch : SFP+plugin-types does not match the planned speed and/or auto-negotiation for the port - all : ihub-link related alarms	alarm name of ihub-link
severity	Parameter type: <Alarm::querySeverity> Format: (indeterminate warning minor major critical all) Possible values: - indeterminate : alarm severity is indeterminate - warning : alarm severity is warning - minor : alarm severity is minor - major : alarm severity is major - critical : alarm severity is critical - all : all alarm severity	severity level of an alarm for reporting
servaff	Parameter type: <Alarm::queryServAffect> Format:	serviceaffecting no

101 query current alarms by filters

Resource Identifier	Type	Description
	(service-affecting noservice-affecting all) Possible values: - service-affecting : query alarm service affecting - noservice-affecting : query alarm not service affecting - all : query service affecting and not affecting alarms	
port	Parameter type: <Ihub::EtherPort> Format: (nt-a : sfp : <Alarm::FacePlatePortIndex> nt-a : xfp : <Alarm::FacePlatePortIndex> nt-a : qsfp : <Alarm::FacePlatePortIndex> nt-a : cfp : <Alarm::FacePlatePortIndex> nt-a : eth : <Alarm::FacePlatePortIndex> nt-a : ieee1588 : <Alarm::FacePlatePortIndex> nt-a : ai : <Alarm::FacePlatePortIndex> nt-b : sfp : <Alarm::FacePlatePortIndex> nt-b : xfp : <Alarm::FacePlatePortIndex> nt-b : qsfp : <Alarm::FacePlatePortIndex> nt-b : cfp : <Alarm::FacePlatePortIndex> nt-b : eth : <Alarm::FacePlatePortIndex> nt-b : ieee1588 : <Alarm::FacePlatePortIndex> nt-b : ai : <Alarm::FacePlatePortIndex> ntio-1 : sfp : <Alarm::FacePlatePortIndex> ntio-1 : xfp : <Alarm::FacePlatePortIndex> ntio-1 : qsfp : <Alarm::FacePlatePortIndex> ntio-1 : cfp : <Alarm::FacePlatePortIndex> ntio-2 : sfp : <Alarm::FacePlatePortIndex> ntio-2 : xfp : <Alarm::FacePlatePortIndex> ntio-2 : qsfp : <Alarm::FacePlatePortIndex> ntio-2 : cfp : <Alarm::FacePlatePortIndex> lt : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> nt-a : qsfp : <Alarm::QsfpPortIndex> - <Alarm::LaneIndex> nt-b : qsfp : <Alarm::QsfpPortIndex> - <Alarm::LaneIndex> ntio-1 : qsfp : <Alarm::QsfpPortIndex> - <Alarm::LaneIndex>) Possible values: - nt-a : the nt-a slot - nt-b : the nt-b slot - ntio-1 : an nt applique slot in a single or multiple-ntio-shelf - ntio-2 : an nt applique slot in a multiple-ntio-shelf - lt : the lt slot - nt-a : the nt-a slot - nt-b : the nt-b slot - ntio-1 : the nt-b slot Possible values: - sfp : SFP port - xfp : XFP port - qsfp : QSFP port - cfp : CFP port - eth : RJ45 or lemi port - ieee1588 : IEEE1588 port - ai : AI port Field type <Eqpt::RackId> - the rack number	identifies the ihub port where the alarm has occurred

Resource Identifier	Type	Description
	Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Alarm::FacePlatePortIndex> - the faceplate port number Field type <Alarm::QsfpPortIndex> - the qsfp port number Field type <Alarm::LaneIndex> - the lane number of qsfp port	

Command Output

Table 101.86-2 "show current alarm by filters" Display parameters

Specific Information		
name	Type	Description
aidinfo	Parameter type: <Alarm::AddInfoString> - additional alarm information	alarm AID parameters <i>This element is only shown in detail mode.</i>
type	Parameter type: <Alarm::alarmIHUBType> (equipment eqpt-holder plug-in-unit atm custom e1 ima-group ima-link redundancy shdsl ether-itf traffic-overflow qos-queue temporal spatial (software-mngt sw-mgmt) xdsl xdsl-ext xdsl-tca olt-gen eo-conv authentication bonding sfp shdsl-isam custom-ext-alarm plug-in-unit-ext sip-user-agent sip-plugin-unit sip-termination e1-sip-termination filetransfer external-device l2forward ether-tca ether-sfp	type of the alarms that are active <i>This element is only shown in detail mode.</i>

101 query current alarms by filters

name	Type	Description
	megaco-media-gw megaco-sig-gw megaco-plug-unit megaco-term megaco-sig-lt eqpt-supplemental eqpt-holder-ext lsmredundancy sync mcsrc vlanport vect-line vect-board otdr sip-dial-plan sip-vsp sip-server bgp rip lag ihub-general vprn isis ospf ihub-l2forward vpls ihub-equip ihub-link eont-phyoam ellid epon eont-services-lan eolt-ont-tca eont-sw-dl ldp mpls sdp epipe ihub-ipv6 pim li mgmt-sec-access bfd ai tr069serv ontsnmp bulk-sync protection-group ont sfu-sup soho-sup mdu-sup ont-ani sfu-sup2 soho-sup2 mdu-sup2 sfprssi	

name	Type	Description
	eoltrssi cfm sfpe1t1-framer sfpe1t1-clock pppcc-engine-tca eth-cfm rsvp ihub-tca eth-ring efm-oam ont-loopdetect ont-video ont-ces ont-voip ont-video-ani ont-pwe ont-cese1 ont-xdsl ont-xdsl-tca ont-hpna ont-sip-agent-cfg ont-voip-cfg ont-mgc ont-ploam ont-gen ont-card ont-pots ont-lan ont-moca ont-tc-tca ont-moca-tca ont-l2uni-eth-tca olt-pon-tc-tca olt-pon-util-tca olt-chpr-util-tca olt-ont-tc-tca ont-tca ont-pots-supplemental sfu-ploam sfu-gen soho-ploam soho-gen mdu-ploam mdu-gen ont-veip ont-iphost alarm-table auto-switch channel-pair ont-cfg-dld olt-chpair-tc-tca hgu-tr069 eqpt-psu ont-protection secondary-megaco-term secondary-sip-term cas-r2-channel	

101 query current alarms by filters

name	Type	Description
	lldpmed pseudo-wire link-agg fcs-exceed e1t1-interface) Possible values: - equipment : equipment alarms - eqpt-holder : equipment holder alarms - plug-in-unit : plugin unit alarms - atm : ATM alarms - custom : customizable alarms - e1 : e1 alarms - ima-group : ima-group alarms - ima-link : ima-link alarms - redundancy : redundancy alarms - shdsl : shdsl alarms - ether-itf : ethernet interface alarms - traffic-overflow : Traffic overflow alarms - qos-queue : qos queue alarms - temporal : temporal alarms - spatial : spatial alarms - software-mngt : software management alarms - sw-mgmt : software management alarms - xdsl : xDSL alarms - xdsl-ext : other xDSL alarms - xdsl-tca : xDSL threshold cross alarms - olt-gen : OLT general alarms - eo-conv : E/O conversion related alarms - authentication : authentication related alarms - bonding : bonding-group related alarms - sfp : SFP related alarms - shdsl-isam : shdsl isam alarms - custom-ext-alarm : customizable external alarms - plug-in-unit-ext : other plugin unit alarms - sip-user-agent : sip user agent related alarms - sip-plugin-unit : sip plug in unit related alarms - sip-termination : sip termination related alarms - e1-sip-termination : E1 sip termination related alarms - filetransfer : file transfer server alarms - external-device : external device related alarms - l2forward : l2forward related alarms - ether-tca : ethernet threshold cross alarms - ether-sfp : ethernet SFP related alarms - megaco-media-gw : megaco media gateway related alarms - megaco-sig-gw : megaco signaling gateway related alarms - megaco-plug-unit : megaco plug unit related alarms - megaco-term : megaco termination related alarms - megaco-sig-lt : megaco signaling lt related alarms - eqpt-supplemental : equipment supplemental alarms - eqpt-holder-ext : other equipment holder alarms - lsmredundancy : lsm redundancy alarms - sync : synce and bits alarms - mcsrc : multicast source alarms - vlanport : vlanport alarms - vect-line : xDSL vectoring line alarms - vect-board : xDSL vectoring board alarms - otdr : otdr alarms	

name	Type	Description
	- sip-dial-plan : sip dial plan related alarms - sip-vsp : sip vsp related alarms - sip-server : sip server related alarms - bgp : bgp related alarms - rip : rip related alarms - lag : LAG related alarms - ihub-general : IHUB general related alarms - vprn : vprn related alarms - isis : isis related alarms - ospf : ospf related alarms - ihub-l2forward : ihub-l2forward alarms - vpls : vpls related alarms - ihub-equip : ihub-equip related alarms - ihub-link : ihub-link related alarms - eont-phyoam : eont phyoam related alarms - ellid : ellid related alarms - epon : epon related alarms - eont-services-lan : eon phyoam related alarms - eolt-ont-tca : eon phyoam related alarms - eont-sw-dl : eon phyoam related alarms - ldp : ldp related alarms - mpls : mpls related alarms - sdp : sdp related alarms - epipe : epipe related alarms - ihub-ipv6 : ihub-ipv6 related alarms - pim : pim related alarms - li : lawful intercept related alarms - mgmt-sec-access : management security related alarms - bfd : bfd related alarms - ai : Application Intelligence related alarms - tr069serv : tr069 server related alarms - ontsnmp : ont snmp related alarms - bulk-sync : bulk-sync related alarms - protection-group : port protection group related alarms - ont : ONT general supplemental related alarms - sfu-sup : SFU ONT general supplemental related alarms - soho-sup : SOHO ONT general supplemental related alarms - mdu-sup : MDU ONT general supplemental related alarms - ont-ani : ONT general supplemental 2 related alarms - sfu-sup2 : SFU ONT general supplemental 2 related alarms - soho-sup2 : SOHO ONT general supplemental 2 related alarms - mdu-sup2 : MDU ONT general supplemental 2 related alarms - sfprssi : SFP RSSI related alarms - eoltrssi : epon olt Sfp RSSI related alarms - cfm : Cfm related alarms - sfpe1t1-framer : SFP 2e1t1 framer alarms - sfpe1t1-clock : SFP 2e1t1 clock alarms - pppcc-engine-tca : PPPOE Cross Connect Engine TCA related alarm - eth-cfm : eth-cfm related alarms - rsvp : rsvp related alarms - ihub-tca : IHUB TCA related alarms - eth-ring : eth-ring related alarms - efm-oam : EFM-OAM related alarms	

101 query current alarms by filters

name	Type	Description
	- ont-loopdetect : ont loop detect related alarms - ont-video : ont services video related alarms - ont-ces : ont services ces related alarms - ont-voip : ont services voip related alarms - ont-video-ani : ont services video ani related alarms - ont-pwe : ont services pwe related alarms - ont-cese1 : ont services cese1 related alarms - ont-xdsl : ont services xdsl related alarms - ont-xdsl-tca : ont services xdsl tca related alarms - ont-hpna : ont hpna related alarms - ont-sip-agent-cfg : ont services voip sip agent config related alarms - ont-voip-cfg : ont services voip config related alarms - ont-mgc : ont mgc related alarms - ont-ploam : ONT PLOAM related alarms - ont-gen : ONT GENERAL related alarms - ont-card : ONT Subscriber Card related alarms - ont-pots : ONT Services POTS related alarms - ont-lan : ONT Services LAN related alarms - ont-moca : ONT MoCA related alarms - ont-tc-tca : ONT TC TCA related alarms - ont-moca-tca : ONT MoCA TCA related alarms - ont-l2uni-eth-tca : ONT L2 UNI Ethernet TCA related alarms - olt-pon-tc-tca : OLT PON TC TCA related alarms - olt-pon-util-tca : OLT PON utilization TCA related alarms - olt-chpr-util-tca : OLT channel-pair utilization TCA related alarms - olt-ont-tc-tca : OLT ONT TC TCA related alarms - ont-tca : ONT TCA related alarms - ont-pots-supplemental : ONT POTS Supplemental related alarms - sfu-ploam : SFU ONT PLOAM related alarms - sfu-gen : SFU ONT general related alarms - soho-ploam : SOHO ONT PLOAM related alarms - soho-gen : SOHO ONT general related alarms - mdu-ploam : MDU ONT PLOAM related alarms - mdu-gen : MDU ONT general related alarms - ont-veip : ONT VEIP related alarms - ont-iphost : ONT IP HOST related alarms - alarm-table : alarm table related alarms - auto-switch : auto-switch related alarms - channel-pair : channel pair related alarms - ont-cfg-dld : ont configure file download related alarms - olt-chpair-tc-tca : OLT CHANNELPAIR TC TCA related alarms - hgu-tr069 : hgu tr069 related alarms - eqpt-psu : equipment psu alarms - ont-protection : ONT protection related alarms - secondary-megaco-term : secondary megaco termination related alarms - secondary-sip-term : secondary sip termination related alarms - cas-r2-channel : CAS R2 channel related alarms - lldpmed : lldpmed alarms - pseudo-wire : pseudo Wire related alarms - link-aggr : Link aggregation related alarms	

name	Type	Description
	- fcs-exceed : FCS auto-recovery related alarms - e1t1-interface : E1/T1 physical interfaces related alarms	
name	Parameter type: <Alarm::almtypeIhublink> (link-down link-lagport-add-fail link-conf-mismatch all) Possible values: - link-down : link is down - link-lagport-add-fail : failure to add port to LAG - link-conf-mismatch : SFP+plugin-types does not match the planned speed and/or auto-negotiation for the port - all : ihub-link related alarms	alarm name that are active <i>This element is only shown in detail mode.</i>
severity	Parameter type: <Alarm::AlarmSeverity> (indeterminate warning minor major critical) Possible values: - indeterminate : alarm severity is indeterminate - warning : alarm severity is warning - minor : alarm severity is minor - major : alarm severity is major - critical : alarm severity is critical	the alarms severity level <i>This element is only shown in detail mode.</i>
servaff	Parameter type: <Alarm::alarmServAffect> ((service-affecting yes) (noservice-affecting no)) Possible values: - service-affecting : make this alarm service affecting - yes : make this alarm service affecting - noservice-affecting : make this alarm not service affecting - no : make this alarm not service affecting	alarms affect service or not <i>This element is only shown in detail mode.</i>
time	Parameter type: <Sys::timeInSecs> - the time (yyyy-mm-dd:hour:minutes:secs) - unit: UTC	time in seconds when alarm was updated <i>This element is only shown in detail mode.</i>
descript	Parameter type: <Alarm::AddInfoString> - additional alarm information	alarm description <i>This element is only shown in detail mode.</i>

101.87 show current alarm by filters

Command Description

show current alarms by filters

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm query ihub-equip [ (name) [ severity <Alarm::querySeverity> ] [ servaff <Alarm::queryServAffect> ]  
[ board <Alarm::NtSlotId> ] ]
```

Command Parameters

Table 101.87-1 "show current alarm by filters" Resource Parameters

Resource Identifier	Type	Description
(name)	Format: (ihub-peer-comm ihub-sw-fail ihub-hw-fail ihub-link-fail ihub-proc-overload ihub-out-of-mem ntp-comm-lost all) Possible values: - ihub-peer-comm : ihub peer to peer communication failure - ihub-sw-fail : IHUB s/w error - ihub-hw-fail : IHUB h/w error - ihub-link-fail : IHUB link failure - ihub-proc-overload : IHUB processor exceeded - ihub-out-of-mem : IHUB processor out of memory - ntp-comm-lost : No response is received from the NTP servers - all : ihub-equip related alarms	alarm name of ihub-equip
severity	Parameter type: <Alarm::querySeverity> Format: (indeterminate warning minor major critical all) Possible values:	severity level of an alarm for reporting

Resource Identifier	Type	Description
	- indeterminate : alarm severity is indeterminate - warning : alarm severity is warning - minor : alarm severity is minor - major : alarm severity is major - critical : alarm severity is critical - all : all alarm severity	
servaff	Parameter type: <Alarm::queryServAffect> Format: (service-affecting noservice-affecting all) Possible values: - service-affecting : query alarm service affecting - noservice-affecting : query alarm not service affecting - all : query service affecting and not affecting alarms	serviceaffecting no serviceaffecting
board	Parameter type: <Alarm::NtSlotId> Format: (nt-a nt-b) Possible values: - nt-a : nt-a slot - nt-b : nt-b slot	identifies the slot where the alarm has been detected

Command Output

Table 101.87-2 "show current alarm by filters" Display parameters

Specific Information		
name	Type	Description
aidinfo	Parameter type: <Alarm::AddInfoString> - additional alarm information	alarm AID parameters <i>This element is only shown in detail mode.</i>
type	Parameter type: <Alarm::alarmIHUBType> (equipment eqpt-holder plug-in-unit atm custom e1 ima-group ima-link redundancy shdsl ether-itf traffic-overflow qos-queue temporal spatial (software-mngt sw-mgmt) xdsl xdsl-ext xdsl-tca olt-gen eo-conv authentication bonding sfp)	type of the alarms that are active <i>This element is only shown in detail mode.</i>

101 query current alarms by filters

name	Type	Description
	shdsl-isam	
	custom-ext-alarm	
	plug-in-unit-ext	
	sip-user-agent	
	sip-plugin-unit	
	sip-termination	
	e1-sip-termination	
	filetransfer	
	external-device	
	l2forward	
	ether-tca	
	ether-sfp	
	megaco-media-gw	
	megaco-sig-gw	
	megaco-plug-unit	
	megaco-term	
	megaco-sig-lt	
	eqpt-supplemental	
	eqpt-holder-ext	
	lsmredundancy	
	sync	
	mcsrc	
	vlanport	
	vect-line	
	vect-board	
	otdr	
	sip-dial-plan	
	sip-vsp	
	sip-server	
	bgp	
	rip	
	lag	
	ihub-general	
	vprn	
	isis	
	ospf	
	ihub-l2forward	
	vpls	
	ihub-equip	
	ihub-link	
	eont-phyoam	
	ellid	
	epon	
	eont-services-lan	
	eolt-ont-tca	
	eont-sw-dl	
	ldp	
	mpls	
	sdp	
	epipe	
	ihub-ipv6	
	pim	
	li	
	mgmt-sec-access	
	bfd	
	ai	
	tr069serv	

name	Type	Description
	ontsnmp bulk-sync protection-group ont sfu-sup soho-sup mdu-sup ont-ani sfu-sup2 soho-sup2 mdu-sup2 sfprssi eoltrssi cfm sfpe1t1-framer sfpe1t1-clock pppcc-engine-tca eth-cfm rsvp ihub-tca eth-ring efm-oam ont-loopdetect ont-video ont-ces ont-voip ont-video-ani ont-pwe ont-cese1 ont-xdsl ont-xdsl-tca ont-hpna ont-sip-agent-cfg ont-voip-cfg ont-mgc ont-ploam ont-gen ont-card ont-pots ont-lan ont-moca ont-tc-tca ont-moca-tca ont-l2uni-eth-tca olt-pon-tc-tca olt-pon-util-tca olt-chpr-util-tca olt-ont-tc-tca ont-tca ont-pots-supplemental sfu-ploam sfu-gen soho-ploam soho-gen mdu-ploam mdu-gen ont-veip	

101 query current alarms by filters

name	Type	Description
	ont-iphost alarm-table auto-switch channel-pair ont-cfg-dld olt-chpair-tc-tca hgu-tr069 eqpt-psu ont-protection secondary-megaco-term secondary-sip-term cas-r2-channel lldpmed pseudo-wire link-agg fcs-exceed e1t1-interface) Possible values: - equipment : equipment alarms - eqpt-holder : equipment holder alarms - plug-in-unit : plugin unit alarms - atm : ATM alarms - custom : customizable alarms - e1 : e1 alarms - ima-group : ima-group alarms - ima-link : ima-link alarms - redundancy : redundancy alarms - shdsl : shdsl alarms - ether-itf : ethernet interface alarms - traffic-overflow : Traffic overflow alarms - qos-queue : qos queue alarms - temporal : temporal alarms - spatial : spatial alarms - software-mngt : software management alarms - sw-mgmt : software management alarms - xdsl : xDSL alarms - xdsl-ext : other xDSL alarms - xdsl-tca : xDSL threshold cross alarms - olt-gen : OLT general alarms - eo-conv : E/O conversion related alarms - authentication : authentication related alarms - bonding : bonding-group related alarms - sfp : SFP related alarms - shdsl-isam : shdsl isam alarms - custom-ext-alarm : customizable external alarms - plug-in-unit-ext : other plugin unit alarms - sip-user-agent : sip user agent related alarms - sip-plugin-unit : sip plug in unit related alarms - sip-termination : sip termination related alarms - e1-sip-termination : E1 sip termination related alarms - filetransfer : file transfer server alarms - external-device : external device related alarms - l2forward : l2forward related alarms - ether-tca : ethernet threshold cross alarms - ether-sfp : ethernet SFP related alarms - megaco-media-gw : megaco media gateway related alarms - megaco-sig-gw : megaco signaling gateway related alarms	

name	Type	Description
	- megaco-plug-unit : megaco plug unit related alarms - megaco-term : megaco termination related alarms - megaco-sig-lt : megaco signaling lt related alarms - eqpt-supplemental : equipment supplemental alarms - eqpt-holder-ext : other equipment holder alarms - lsmredundancy : lsm redundancy alarms - sync : synce and bits alarms - mcsrc : multicast source alarms - vlanport : vlanport alarms - vect-line : xDSL vectoring line alarms - vect-board : xDSL vectoring board alarms - otdr : otdr alarms - sip-dial-plan : sip dial plan related alarms - sip-vsp : sip vsp related alarms - sip-server : sip server related alarms - bgp : bgp related alarms - rip : rip related alarms - lag : LAG related alarms - ihub-general : IHUB general related alarms - vprn : vprn related alarms - isis : isis related alarms - ospf : ospf related alarms - ihub-l2forward : ihub-l2forward alarms - vpls : vpls related alarms - ihub-equip : ihub-equip related alarms - ihub-link : ihub-link related alarms - eont-phyoam : eont phyoam related alarms - ellid : ellid related alarms - epon : epon related alarms - eont-services-lan : eon phyoam related alarms - eolt-ont-tca : eon phyoam related alarms - eont-sw-dl : eon phyoam related alarms - ldp : ldp related alarms - mpls : mpls related alarms - sdp : sdp related alarms - epipe : epipe related alarms - ihub-ipv6 : ihub-ipv6 related alarms - pim : pim related alarms - li : lawful intercept related alarms - mgmt-sec-access : management security related alarms - bfd : bfd related alarms - ai : Application Intelligence related alarms - tr069serv : tr069 server related alarms - ontsnmp : ont snmp related alarms - bulk-sync : bulk-sync related alarms - protection-group : port protection group related alarms - ont : ONT general supplemental related alarms - sfu-sup : SFU ONT general supplemental related alarms - soho-sup : SOHO ONT general supplemental related alarms - mdu-sup : MDU ONT general supplemental related alarms - ont-ani : ONT general supplemental 2 related alarms - sfu-sup2 : SFU ONT general supplemental 2 related alarms - soho-sup2 : SOHO ONT general supplemental 2 related alarms - mdu-sup2 : MDU ONT general supplemental 2 related alarms	

101 query current alarms by filters

name	Type	Description
	- sfprssi : SFP RSSI related alarms - eoltrssi : epon olt Sfp RSSI related alarms - cfm : Cfm related alarms - sfpe1t1-framer : SFP 2e1t1 framer alarms - sfpe1t1-clock : SFP 2e1t1 clock alarms - pppcc-engine-tca : PPPOE Cross Connect Engine TCA related alarm - eth-cfm : eth-cfm related alarms - rsvp : rsvp related alarms - ihub-tca : IHUB TCA related alarms - eth-ring : eth-ring related alarms - efm-oam : EFM-OAM related alarms - ont-loopdetect : ont loop detect related alarms - ont-video : ont services video related alarms - ont-ces : ont services ces related alarms - ont-voip : ont services voip related alarms - ont-video-ani : ont services video ani related alarms - ont-pwe : ont services pwe related alarms - ont-cese1 : ont services cese1 related alarms - ont-xdsl : ont services xdsl related alarms - ont-xdsl-tca : ont services xdsl tca related alarms - ont-hpna : ont hpna related alarms - ont-sip-agent-cfg : ont services voip sip agent config related alarms - ont-voip-cfg : ont services voip config related alarms - ont-mgc : ont mgc related alarms - ont-ploam : ONT PLOAM related alarms - ont-gen : ONT GENERAL related alarms - ont-card : ONT Subscriber Card related alarms - ont-pots : ONT Services POTS related alarms - ont-lan : ONT Services LAN related alarms - ont-moca : ONT MoCA related alarms - ont-tc-tca : ONT TC TCA related alarms - ont-moca-tca : ONT MoCA TCA related alarms - ont-l2uni-eth-tca : ONT L2 UNI Ethernet TCA related alarms - olt-pont-tc-tca : OLT PON TC TCA related alarms - olt-pont-util-tca : OLT PON utilization TCA related alarms - olt-chpr-util-tca : OLT channel-pair utilization TCA related alarms - olt-ont-tc-tca : OLT ONT TC TCA related alarms - ont-tca : ONT TCA related alarms - ont-pots-supplemental : ONT POTS Supplemental related alarms - sfu-ploam : SFU ONT PLOAM related alarms - sfu-gen : SFU ONT general related alarms - soho-ploam : SOHO ONT PLOAM related alarms - soho-gen : SOHO ONT general related alarms - mduploam : MDU ONT PLOAM related alarms - mdugen : MDU ONT general related alarms - ont-veip : ONT VEIP related alarms - ont-iphost : ONT IP HOST related alarms - alarm-table : alarm table related alarms - auto-switch : auto-switch related alarms - channel-pair : channel pair related alarms - ont-cfg-dld : ont configure file download related alarms - olt-chpair-tc-tca : OLT CHANNELPAIR TC TCA related	

name	Type	Description
	alarms - hgu-tr069 : hgu tr069 related alarms - eqpt-psu : equipment psu alarms - ont-protection : ONT protection related alarms - secondary-megaco-term : secondary megaco termination related alarms - secondary-sip-term : secondary sip termination related alarms - cas-r2-channel : CAS R2 channel related alarms - lldpmed : lldpmed alarms - pseudo-wire : pseudo Wire related alarms - link-agg : Link aggregation related alarms - fcs-exceed : FCS auto-recovery related alarms - e1t1-interface : E1/T1 physical interfaces related alarms	
name	Parameter type: <Alarm::alarmTypeIhubequip> (ihub-peer-comm ihub-sw-fail ihub-hw-fail ihub-link-fail ihub-proc-overload ihub-out-of-mem ntp-comm-lost all) Possible values: - ihub-peer-comm : ihub peer to peer communication failure - ihub-sw-fail : IHUB s/w error - ihub-hw-fail : IHUB h/w error - ihub-link-fail : IHUB link failure - ihub-proc-overload : IHUB processor exceeded - ihub-out-of-mem : IHUB processor out of memory - ntp-comm-lost : No response is received from the NTP servers - all : ihub-equip related alarms	alarm name that are active <i>This element is only shown in detail mode.</i>
severity	Parameter type: <Alarm::AlarmSeverity> (indeterminate warning minor major critical) Possible values: - indeterminate : alarm severity is indeterminate - warning : alarm severity is warning - minor : alarm severity is minor - major : alarm severity is major - critical : alarm severity is critical	the alarms severity level <i>This element is only shown in detail mode.</i>
servaff	Parameter type: <Alarm::alarmServAffect> ((service-affecting yes) (noservice-affecting no)) Possible values: - service-affecting : make this alarm service affecting - yes : make this alarm service affecting - noservice-affecting : make this alarm not service affecting - no : make this alarm not service affecting	alarms affect service or not <i>This element is only shown in detail mode.</i>
time	Parameter type: <Sys::timeInSecs> - the time (yyyy-mm-dd:hour:minutes:secs) - unit: UTC	time in seconds when alarm was updated <i>This element is only shown in detail mode.</i>

101 query current alarms by filters

name	Type	Description
descript	Parameter type: <Alarm::AddInfoString> - additional alarm information	alarm description <i>This element is only shown in detail mode.</i>

101.88 show current alarm by filters

Command Description

show current alarms by filters

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm query lag [ (name) [ severity <Alarm::querySeverity> ] [ servaff <Alarm::queryServAffect> ] [ lag-id <Alarm::LagId> ] ]
```

Command Parameters

Table 101.88-1 "show current alarm by filters" Resource Parameters

Resource Identifier	Type	Description
(name)	Format: (lag-down lagsubgrp-thresh-reach lagsubgrp-switch-fail no-unpinned-free-ports all) Possible values: - lag-down : lag down - lagsubgrp-thresh-reach: lag subgroup threshold reached - lagsubgrp-switch-fail : lag subgroup switchover failed - no-unpinned-free-ports: No free ports available for unpinned traffic - all : LAG related alarms	alarm name of lag
severity	Parameter type: <Alarm::querySeverity> Format: (indeterminate warning minor major critical all) Possible values: - indeterminate : alarm severity is indeterminate - warning : alarm severity is warning - minor : alarm severity is minor - major : alarm severity is major - critical : alarm severity is critical - all : all alarm severity	severity level of an alarm for reporting

101 query current alarms by filters

Resource Identifier	Type	Description
servaff	Parameter type: <Alarm::queryServAffect> Format: (service-affecting noservice-affecting all) Possible values: - service-affecting : query alarm service affecting - noservice-affecting : query alarm not service affecting - all : query service affecting and not affecting alarms	serviceaffecting no serviceaffecting
lag-id	Parameter type: <Alarm::LagId> Format: - link aggregation group id - range: [1...64]	Identifies the lag where the alarm has occurred

Command Output

Table 101.88-2 "show current alarm by filters" Display parameters

Specific Information		
name	Type	Description
aidinfo	Parameter type: <Alarm::AddInfoString> - additional alarm information	alarm AID parameters <i>This element is only shown in detail mode.</i>
type	Parameter type: <Alarm::alarmIHUBType> (equipment eqpt-holder plug-in-unit atm custom e1 ima-group ima-link redundancy shdsl ether-itf traffic-overflow qos-queue temporal spatial (software-mngt sw-mgmt) xdsl xdsl-ext xdsl-tca olt-gen eo-conv authentication bonding sfp shdsl-isam custom-ext-alarm plug-in-unit-ext sip-user-agent sip-plugin-unit sip-termination e1-sip-termination filetransfer external-device	type of the alarms that are active <i>This element is only shown in detail mode.</i>

name	Type	Description
	l2forward	
	ether-tca	
	ether-sfp	
	megaco-media-gw	
	megaco-sig-gw	
	megaco-plug-unit	
	megaco-term	
	megaco-sig-lt	
	eqpt-supplemental	
	eqpt-holder-ext	
	lsmredundancy	
	sync	
	mcsrc	
	vlanport	
	vect-line	
	vect-board	
	otdr	
	sip-dial-plan	
	sip-vsp	
	sip-server	
	bgp	
	rip	
	lag	
	ihub-general	
	vprn	
	isis	
	ospf	
	ihub-l2forward	
	vpls	
	ihub-equip	
	ihub-link	
	eont-phyoam	
	ellid	
	epon	
	eont-services-lan	
	eolt-ont-tca	
	eont-sw-dl	
	ldp	
	mpls	
	sdp	
	epipe	
	ihub-ipv6	
	pim	
	li	
	mgmt-sec-access	
	bfd	
	ai	
	tr069serv	
	ontsnmp	
	bulk-sync	
	protection-group	
	ont	
	sfu-sup	
	soho-sup	
	mdu-sup	
	ont-ani	
	sfu-sup2	

101 query current alarms by filters

name	Type	Description
	soho-sup2	
	mdu-sup2	
	sfprssi	
	eoltrssi	
	cfm	
	sfpe1t1-framer	
	sfpe1t1-clock	
	pppcc-engine-tca	
	eth-cfm	
	rsvp	
	ihub-tca	
	eth-ring	
	efm-oam	
	ont-loopdetect	
	ont-video	
	ont-ces	
	ont-voip	
	ont-video-ani	
	ont-pwe	
	ont-cese1	
	ont-xdsl	
	ont-xdsl-tca	
	ont-hpna	
	ont-sip-agent-cfg	
	ont-voip-cfg	
	ont-mgc	
	ont-ploam	
	ont-gen	
	ont-card	
	ont-pots	
	ont-lan	
	ont-moca	
	ont-tc-tca	
	ont-moca-tca	
	ont-l2uni-eth-tca	
	olt-pon-tc-tca	
	olt-pon-util-tca	
	olt-chpr-util-tca	
	olt-ont-tc-tca	
	ont-tca	
	ont-pots-supplemental	
	sfu-ploam	
	sfu-gen	
	soho-ploam	
	soho-gen	
	mdu-ploam	
	mdu-gen	
	ont-veip	
	ont-iphost	
	alarm-table	
	auto-switch	
	channel-pair	
	ont-cfg-dld	
	olt-chpair-tc-tca	
	hgu-tr069	
	eqpt-psu	
	ont-protection	

name	Type	Description
	secondary-megaco-term secondary-sip-term cas-r2-channel lldpmed pseudo-wire link-agg fcs-exceed e1t1-interface) Possible values: - equipment : equipment alarms - eqpt-holder : equipment holder alarms - plug-in-unit : plugin unit alarms - atm : ATM alarms - custom : customizable alarms - e1 : e1 alarms - ima-group : ima-group alarms - ima-link : ima-link alarms - redundancy : redundancy alarms - shdsl : shdsl alarms - ether-itf : ethernet interface alarms - traffic-overflow : Traffic overflow alarms - qos-queue : qos queue alarms - temporal : temporal alarms - spatial : spatial alarms - software-mngt : software management alarms - sw-mgmt : software management alarms - xdsl : xDSL alarms - xdsl-ext : other xDSL alarms - xdsl-tca : xDSL threshold cross alarms - olt-gen : OLT general alarms - eo-conv : E/O conversion related alarms - authentication : authentication related alarms - bonding : bonding-group related alarms - sfp : SFP related alarms - shdsl-isam : shdsl isam alarms - custom-ext-alarm : customizable external alarms - plug-in-unit-ext : other plugin unit alarms - sip-user-agent : sip user agent related alarms - sip-plugin-unit : sip plug in unit related alarms - sip-termination : sip termination related alarms - e1-sip-termination : E1 sip termination related alarms - filetransfer : file transfer server alarms - external-device : external device related alarms - l2forward : l2forward related alarms - ether-tca : ethernet threshold cross alarms - ether-sfp : ethernet SFP related alarms - megaco-media-gw : megaco media gateway related alarms - megaco-sig-gw : megaco signaling gateway related alarms - megaco-plug-unit : megaco plug unit related alarms - megaco-term : megaco termination related alarms - megaco-sig-lt : megaco signaling lt related alarms - eqpt-supplemental : equipment supplemental alarms - eqpt-holder-ext : other equipment holder alarms - lsmredundancy : lsm redundancy alarms - sync : synce and bits alarms - mcsrc : multicast source alarms - vlanport : vlanport alarms	

101 query current alarms by filters

name	Type	Description
	- vect-line : xDSL vectoring line alarms - vect-board : xDSL vectoring board alarms - otdr : otdr alarms - sip-dial-plan : sip dial plan related alarms - sip-vsp : sip vsp related alarms - sip-server : sip server related alarms - bgp : bgp related alarms - rip : rip related alarms - lag : LAG related alarms - ihub-general : IHUB general related alarms - vprn : vprn related alarms - isis : isis related alarms - ospf : ospf related alarms - ihub-l2forward : ihub-l2forward alarms - vpls : vpls related alarms - ihub-equip : ihub-equip related alarms - ihub-link : ihub-link related alarms - eont-phyoam : eont phyoam related alarms - ellid : ellid related alarms - epon : epon related alarms - eont-services-lan : eon phyoam related alarms - eolt-ont-tca : eon phyoam related alarms - eont-sw-dl : eon phyoam related alarms - ldp : ldp related alarms - mpls : mpls related alarms - sdp : sdp related alarms - epipe : epipe related alarms - ihub-ipv6 : ihub-ipv6 related alarms - pim : pim related alarms - li : lawful intercept related alarms - mgmt-sec-access : management security related alarms - bfd : bfd related alarms - ai : Application Intelligence related alarms - tr069serv : tr069 server related alarms - ontsnmp : ont snmp related alarms - bulk-sync : bulk-sync related alarms - protection-group : port protection group related alarms - ont : ONT general supplemental related alarms - sfu-sup : SFU ONT general supplemental related alarms - soho-sup : SOHO ONT general supplemental related alarms - mdu-sup : MDU ONT general supplemental related alarms - ont-ani : ONT general supplemental 2 related alarms - sfu-sup2 : SFU ONT general supplemental 2 related alarms - soho-sup2 : SOHO ONT general supplemental 2 related alarms - mdu-sup2 : MDU ONT general supplemental 2 related alarms - sfprssi : SFP RSSI related alarms - eoltrssi : epon olt Sfp RSSI related alarms - cfm : Cfm related alarms - sfpe1t1-framer : SFP 2e1t1 framer alarms - sfpe1t1-clock : SFP 2e1t1 clock alarms - pppcc-engine-tca : PPPOE Cross Connect Engine TCA related alarm - eth-cfm : eth-cfm related alarms - rsvp : rsvp related alarms	

name	Type	Description
	- ihub-tca : IHUB TCA related alarms - eth-ring : eth-ring related alarms - efm-oam : EFM-OAM related alarms - ont-loopdetect : ont loop detect related alarms - ont-video : ont services video related alarms - ont-ces : ont services ces related alarms - ont-voip : ont services voip related alarms - ont-video-ani : ont services video ani related alarms - ont-pwe : ont services pwe related alarms - ont-cese1 : ont services cese1 related alarms - ont-xdsl : ont services xdsl related alarms - ont-xdsl-tca : ont services xdsl tca related alarms - ont-hpna : ont hpna related alarms - ont-sip-agent-cfg : ont services voip sip agent config related alarms - ont-voip-cfg : ont services voip config related alarms - ont-mgc : ont mgc related alarms - ont-ploam : ONT PLOAM related alarms - ont-gen : ONT GENERAL related alarms - ont-card : ONT Subscriber Card related alarms - ont-pots : ONT Services POTS related alarms - ont-lan : ONT Services LAN related alarms - ont-moca : ONT MoCA related alarms - ont-tc-tca : ONT TC TCA related alarms - ont-moca-tca : ONT MoCA TCA related alarms - ont-l2uni-eth-tca : ONT L2 UNI Ethernet TCA related alarms - olt-pon-tc-tca : OLT PON TC TCA related alarms - olt-pon-util-tca : OLT PON utilization TCA related alarms - olt-chpr-util-tca : OLT channel-pair utilization TCA related alarms - olt-ont-tc-tca : OLT ONT TC TCA related alarms - ont-tca : ONT TCA related alarms - ont-pots-supplemental : ONT POTS Supplemental related alarms - sfu-ploam : SFU ONT PLOAM related alarms - sfu-gen : SFU ONT general related alarms - soho-ploam : SOHO ONT PLOAM related alarms - soho-gen : SOHO ONT general related alarms - mdu-ploam : MDU ONT PLOAM related alarms - mdu-gen : MDU ONT general related alarms - ont-veip : ONT VEIP related alarms - ont-iphost : ONT IP HOST related alarms - alarm-table : alarm table related alarms - auto-switch : auto-switch related alarms - channel-pair : channel pair related alarms - ont-cfg-dld : ont configure file download related alarms - olt-chpair-tc-tca : OLT CHANNELPAIR TC TCA related alarms - hgu-tr069 : hgu tr069 related alarms - eqpt-psu : equipment psu alarms - ont-protection : ONT protection related alarms - secondary-megaco-term : secondary megaco termination related alarms - secondary-sip-term : secondary sip termination related alarms - cas-r2-channel : CAS R2 channel related alarms	

101 query current alarms by filters

name	Type	Description
	- lldpmed : lldpmed alarms - pseudo-wire : pseudo Wire related alarms - link-agg : Link aggregation related alarms - fcs-exceed : FCS auto-recovery related alarms - e1t1-interface : E1/T1 physical interfaces related alarms	
name	Parameter type: <Alarm::almtypeLagihub> (lag-down lagsubgrp-thresh-reach lagsubgrp-switch-fail no-unpinned-free-ports all) Possible values: - lag-down : lag down - lagsubgrp-thresh-reach: lag subgroup threshold reached - lagsubgrp-switch-fail : lag subgroup switchover failed - no-unpinned-free-ports: No free ports available for unpinned traffic - all : LAG related alarms	alarm name that are active <i>This element is only shown in detail mode.</i>
severity	Parameter type: <Alarm::AlarmSeverity> (indeterminate warning minor major critical) Possible values: - indeterminate : alarm severity is indeterminate - warning : alarm severity is warning - minor : alarm severity is minor - major : alarm severity is major - critical : alarm severity is critical	the alarms severity level <i>This element is only shown in detail mode.</i>
servaff	Parameter type: <Alarm::alarmServAffect> ((service-affecting yes) (noservice-affecting no)) Possible values: - service-affecting : make this alarm service affecting - yes : make this alarm service affecting - noservice-affecting : make this alarm not service affecting - no : make this alarm not service affecting	alarms affect service or not <i>This element is only shown in detail mode.</i>
time	Parameter type: <Sys::timeInSecs> - the time (yyyy-mm-dd:hour:minutes:secs) - unit: UTC	time in seconds when alarm was updated <i>This element is only shown in detail mode.</i>
descript	Parameter type: <Alarm::AddInfoString> - additional alarm information	alarm description <i>This element is only shown in detail mode.</i>

101.89 show current alarm by filters

Command Description

show current alarms by filters

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm query ihub-general [ (name) [ severity <Alarm::querySeverity> ] [ servaff <Alarm::queryServAffect> ] [ defaultaid <Alarm::queryDefaultAid> ] ]
```

Command Parameters

Table 101.89-1 "show current alarm by filters" Resource Parameters

Resource Identifier	Type	Description
(name)	Format: (general-arp-limit gen-switch-out-of-res ipv6-nc-limit dhcp-session-oor ihub-fdb-limit ihub-mac-limit all) Possible values: - general-arp-limit : arp limit exceeded - gen-switch-out-of-res : failure due to lack of resources on switch - ipv6-nc-limit : ipv6 neighbor cache limit exceeded - dhcp-session-oor : dhcp session out of resources - ihub-fdb-limit : layer 2 fdb limit reached - ihub-mac-limit : layer 2 mac limit reached - all : IHUB general related alarms	alarm name of ihub-general
severity	Parameter type: <Alarm::querySeverity> Format: (indeterminate warning minor major critical all) Possible values: - indeterminate : alarm severity is indeterminate - warning : alarm severity is warning	severity level of an alarm for reporting

101 query current alarms by filters

Resource Identifier	Type	Description
	- minor : alarm severity is minor - major : alarm severity is major - critical : alarm severity is critical - all : all alarm severity	
servaff	Parameter type: <Alarm::queryServAffect> Format: (service-affecting noservice-affecting all) Possible values: - service-affecting : query alarm service affecting - noservice-affecting : query alarm not service affecting - all : query service affecting and not affecting alarms	serviceaffecting no serviceaffecting
defaultaid	Parameter type: <Alarm::queryDefaultAid> Format: all Possible values: - all : default AID parameter	default AID param is all

Command Output

Table 101.89-2 "show current alarm by filters" Display parameters

Specific Information		
name	Type	Description
type	Parameter type: <Alarm::alarmIHUBType> (equipment eqpt-holder plug-in-unit atm custom e1 ima-group ima-link redundancy shdsl ether-itf traffic-overflow qos-queue temporal spatial (software-mngt sw-mgmt) xdsl xdsl-ext xdsl-tca olt-gen eo-conv authentication bonding sfp shdsl-isam custom-ext-alarm plug-in-unit-ext sip-user-agent sip-plugin-unit sip-termination e1-sip-termination	type of the alarms that are active <i>This element is only shown in detail mode.</i>

name	Type	Description
	filetransfer	
	external-device	
	l2forward	
	ether-tca	
	ether-sfp	
	megaco-media-gw	
	megaco-sig-gw	
	megaco-plug-unit	
	megaco-term	
	megaco-sig-lt	
	eqpt-supplemental	
	eqpt-holder-ext	
	lsmredundancy	
	sync	
	mcsrc	
	vlanport	
	vect-line	
	vect-board	
	otdr	
	sip-dial-plan	
	sip-vsp	
	sip-server	
	bgp	
	rip	
	lag	
	ihub-general	
	vprn	
	isis	
	ospf	
	ihub-l2forward	
	vpls	
	ihub-equip	
	ihub-link	
	eont-phyoam	
	ellid	
	epon	
	eont-services-lan	
	eolt-ont-tca	
	eont-sw-dl	
	ldp	
	mpls	
	sdp	
	epipe	
	ihub-ipv6	
	pim	
	li	
	mgmt-sec-access	
	bfd	
	ai	
	tr069serv	
	ontsnmp	
	bulk-sync	
	protection-group	
	ont	
	sfu-sup	
	soho-sup	
	mdu-sup	

101 query current alarms by filters

name	Type	Description
	ont-ani sfu-sup2 soho-sup2 mdu-sup2 sfprssi eoltrssi cfm sfpe1t1-framer sfpe1t1-clock pppcc-engine-tca eth-cfm rsvp ihub-tca eth-ring efm-oam ont-loopdetect ont-video ont-ces ont-voip ont-video-ani ont-pwe ont-cese1 ont-xdsl ont-xdsl-tca ont-hpna ont-sip-agent-cfg ont-voip-cfg ont-mgc ont-ploam ont-gen ont-card ont-pots ont-lan ont-moca ont-tc-tca ont-moca-tca ont-l2uni-eth-tca olt-pon-tc-tca olt-pon-util-tca olt-chpr-util-tca olt-ont-tc-tca ont-tca ont-pots-supplemental sfu-ploam sfu-gen soho-ploam soho-gen mdu-ploam mdu-gen ont-veip ont-iphost alarm-table auto-switch channel-pair ont-cfg-dld olt-chpair-tc-tca hgu-tr069	

name	Type	Description
	eqpt-psu ont-protection secondary-megaco-term secondary-sip-term cas-r2-channel lldpmed pseudo-wire link-agg fcs-exceed e1t1-interface) Possible values: - equipment : equipment alarms - eqpt-holder : equipment holder alarms - plug-in-unit : plugin unit alarms - atm : ATM alarms - custom : customizable alarms - e1 : e1 alarms - ima-group : ima-group alarms - ima-link : ima-link alarms - redundancy : redundancy alarms - shdsl : shdsl alarms - ether-itf : ethernet interface alarms - traffic-overflow : Traffic overflow alarms - qos-queue : qos queue alarms - temporal : temporal alarms - spatial : spatial alarms - software-mngt : software management alarms - sw-mgmt : software management alarms - xdsl : xDSL alarms - xdsl-ext : other xDSL alarms - xdsl-tca : xDSL threshold cross alarms - olt-gen : OLT general alarms - eo-conv : E/O conversion related alarms - authentication : authentication related alarms - bonding : bonding-group related alarms - sfp : SFP related alarms - shdsl-isam : shdsl isam alarms - custom-ext-alarm : customizable external alarms - plug-in-unit-ext : other plugin unit alarms - sip-user-agent : sip user agent related alarms - sip-plugin-unit : sip plug in unit related alarms - sip-termination : sip termination related alarms - e1-sip-termination : E1 sip termination related alarms - filetransfer : file transfer server alarms - external-device : external device related alarms - l2forward : l2forward related alarms - ether-tca : ethernet threshold cross alarms - ether-sfp : ethernet SFP related alarms - megaco-media-gw : megaco media gateway related alarms - megaco-sig-gw : megaco signaling gateway related alarms - megaco-plug-unit : megaco plug unit related alarms - megaco-term : megaco termination related alarms - megaco-sig-lt : megaco signaling lt related alarms - eqpt-supplemental : equipment supplemental alarms - eqpt-holder-ext : other equipment holder alarms - lsmredundancy : lsm redundancy alarms - sync : synce and bits alarms	

101 query current alarms by filters

name	Type	Description
	- mcsrc : multicast source alarms - vlanport : vlanport alarms - vect-line : xDSL vectoring line alarms - vect-board : xDSL vectoring board alarms - otdr : otdr alarms - sip-dial-plan : sip dial plan related alarms - sip-vsp : sip vsp related alarms - sip-server : sip server related alarms - bgp : bgp related alarms - rip : rip related alarms - lag : LAG related alarms - ihub-general : IHUB general related alarms - vprn : vprn related alarms - isis : isis related alarms - ospf : ospf related alarms - ihub-l2forward : ihub-l2forward alarms - vpls : vpls related alarms - ihub-equip : ihub-equip related alarms - ihub-link : ihub-link related alarms - eont-phyoam : eont phyoam related alarms - ellid : ellid related alarms - epon : epon related alarms - eont-services-lan : eon phyoam related alarms - eolt-ont-tca : eon phyoam related alarms - eont-sw-dl : eon phyoam related alarms - ldp : ldp related alarms - mpls : mpls related alarms - sdp : sdp related alarms - epipe : epipe related alarms - ihub-ipv6 : ihub-ipv6 related alarms - pim : pim related alarms - li : lawful intercept related alarms - mgmt-sec-access : management security related alarms - bfd : bfd related alarms - ai : Application Intelligence related alarms - tr069serv : tr069 server related alarms - ontsnmp : ont snmp related alarms - bulk-sync : bulk-sync related alarms - protection-group : port protection group related alarms - ont : ONT general supplemental related alarms - sfu-sup : SFU ONT general supplemental related alarms - soho-sup : SOHO ONT general supplemental related alarms - mdu-sup : MDU ONT general supplemental related alarms - ont-ani : ONT general supplemental 2 related alarms - sfu-sup2 : SFU ONT general supplemental 2 related alarms - soho-sup2 : SOHO ONT general supplemental 2 related alarms - mdu-sup2 : MDU ONT general supplemental 2 related alarms - sfprssi : SFP RSSI related alarms - eoltrssi : epon olt Sfp RSSI related alarms - cfm : Cfm related alarms - sfpe1t1-framer : SFP 2e1t1 framer alarms - sfpe1t1-clock : SFP 2e1t1 clock alarms - pppcc-engine-tca : PPPOE Cross Connect Engine TCA related alarm	

name	Type	Description
	- eth-cfm : eth-cfm related alarms - rsvp : rsvp related alarms - ihub-tca : IHUB TCA related alarms - eth-ring : eth-ring related alarms - efm-oam : EFM-OAM related alarms - ont-loopdetect : ont loop detect related alarms - ont-video : ont services video related alarms - ont-ces : ont services ces related alarms - ont-voip : ont services voip related alarms - ont-video-ani : ont services video ani related alarms - ont-pwe : ont services pwe related alarms - ont-cese1 : ont services cese1 related alarms - ont-xdsl : ont services xdsl related alarms - ont-xdsl-tca : ont services xdsl tca related alarms - ont-hpna : ont hpna related alarms - ont-sip-agent-cfg : ont services voip sip agent config related alarms - ont-voip-cfg : ont services voip config related alarms - ont-mgc : ont mgc related alarms - ont-ploam : ONT PLOAM related alarms - ont-gen : ONT GENERAL related alarms - ont-card : ONT Subscriber Card related alarms - ont-pots : ONT Services POTS related alarms - ont-lan : ONT Services LAN related alarms - ont-moca : ONT MoCA related alarms - ont-tc-tca : ONT TC TCA related alarms - ont-moca-tca : ONT MoCA TCA related alarms - ont-l2uni-eth-tca : ONT L2 UNI Ethernet TCA related alarms - olt-pon-tc-tca : OLT PON TC TCA related alarms - olt-pon-util-tca : OLT PON utilization TCA related alarms - olt-chpr-util-tca : OLT channel-pair utilization TCA related alarms - olt-ont-tc-tca : OLT ONT TC TCA related alarms - ont-tca : ONT TCA related alarms - ont-pots-supplemental : ONT POTS Supplemental related alarms - sfu-ploam : SFU ONT PLOAM related alarms - sfu-gen : SFU ONT general related alarms - soho-ploam : SOHO ONT PLOAM related alarms - soho-gen : SOHO ONT general related alarms - mdu-ploam : MDU ONT PLOAM related alarms - mdu-gen : MDU ONT general related alarms - ont-veip : ONT VEIP related alarms - ont-iphost : ONT IP HOST related alarms - alarm-table : alarm table related alarms - auto-switch : auto-switch related alarms - channel-pair : channel pair related alarms - ont-cfg-dld : ont configure file download related alarms - olt-chpair-tc-tca : OLT CHANNELPAIR TC TCA related alarms - hgu-tr069 : hgu tr069 related alarms - eqpt-psu : equipment psu alarms - ont-protection : ONT protection related alarms - secondary-megaco-term : secondary megaco termination related alarms - secondary-sip-term : secondary sip termination related	

101 query current alarms by filters

name	Type	Description
	alarms - cas-r2-channel : CAS R2 channel related alarms - lldpmed : lldpmed alarms - pseudo-wire : pseudo Wire related alarms - link-agg : Link aggregation related alarms - fcs-exceed : FCS auto-recovery related alarms - e1t1-interface : E1/T1 physical interfaces related alarms	
name	Parameter type: <Alarm::alarmTypeIhubgeneral> (general-arp-limit gen-switch-out-of-res ipv6-nc-limit dhcp-session-oor ihub-fdb-limit ihub-mac-limit all) Possible values: - general-arp-limit : arp limit exceeded - gen-switch-out-of-res : failure due to lack of resources on switch - ipv6-nc-limit : ipv6 neighbor cache limit exceeded - dhcp-session-oor : dhcp session out of resources - ihub-fdb-limit : layer 2 fdb limit reached - ihub-mac-limit : layer 2 mac limit reached - all : IHUB general related alarms	alarm name that are active <i>This element is only shown in detail mode.</i>
severity	Parameter type: <Alarm::AlarmSeverity> (indeterminate warning minor major critical) Possible values: - indeterminate : alarm severity is indeterminate - warning : alarm severity is warning - minor : alarm severity is minor - major : alarm severity is major - critical : alarm severity is critical	the alarms severity level <i>This element is only shown in detail mode.</i>
servaff	Parameter type: <Alarm::alarmServAffect> ((service-affecting yes) (noservice-affecting no)) Possible values: - service-affecting : make this alarm service affecting - yes : make this alarm service affecting - noservice-affecting : make this alarm not service affecting - no : make this alarm not service affecting	alarms affect service or not <i>This element is only shown in detail mode.</i>
time	Parameter type: <Sys::timeInSecs> - the time (yyyy-mm-dd:hour:minutes:secs) - unit: UTC	time in seconds when alarm was updated <i>This element is only shown in detail mode.</i>
descript	Parameter type: <Alarm::AddInfoString> - additional alarm information	alarm description <i>This element is only shown in detail mode.</i>

101.90 show current alarm by filters

Command Description

show current alarms by filters

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm query ellid [ (name) [ severity <Alarm::querySeverity> ] [ servaff <Alarm::queryServAffect> ] [ ellid-index <Itf::ComplexPortType> ] ]
```

Command Parameters

Table 101.90-1 "show current alarm by filters" Resource Parameters

Resource Identifier	Type	Description
(name)	Format: (key-fail-one-churn key-fail-three-churn oam-discov-fail report-timeout total-packets-exceed arp-packets-exceed dhcp-packets-exceed igmp-packets-exceed pppoe-packets-exceed nd-packets-exceed icmpv6-packets-exceed mld-packets-exceed dhcpv6-packets-exceed cfm-packets-exceed all) Possible values: - key-fail-one-churn : key exchange failure during one churning time - key-fail-three-churn : key exchange failure during three churning time - oam-discov-fail : extend oam discovery failure - report-timeout : report timeout detecting - total-packets-exceed : total amount of protocol packets exceed threshold - arp-packets-exceed : protocol arp packets exceed threshold - dhcp-packets-exceed : protocol dhcp packets exceed threshold	alarm name of ellid

101 query current alarms by filters

Resource Identifier	Type	Description
	- igmp-packets-exceed : protocol igmp packets exceed threshold - pppoe-packets-exceed : protocol pppoe packets exceed threshold - nd-packets-exceed : protocol nd packets exceed threshold - icmpv6-packets-exceed : protocol icmpv6 packets exceed threshold - mld-packets-exceed : protocol mld packets exceed threshold - dhcpv6-packets-exceed : protocol dhcpv6 packets exceed threshold - cfm-packets-exceed : protocol cfm packets exceed threshold - all : ellid related alarms	
severity	Parameter type: <Alarm::querySeverity> Format: (indeterminate warning minor major critical all) Possible values: - indeterminate : alarm severity is indeterminate - warning : alarm severity is warning - minor : alarm severity is minor - major : alarm severity is major - critical : alarm severity is critical - all : all alarm severity	severity level of an alarm for reporting
servaff	Parameter type: <Alarm::queryServAffect> Format: (service-affecting noservice-affecting all) Possible values: - service-affecting : query alarm service affecting - noservice-affecting : query alarm not service affecting - all : query service affecting and not affecting alarms	serviceaffecting no serviceaffecting
ellid-index	Parameter type: <Itf::ComplexPortType> Format: (xdsl-line : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> voicefxs : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> xdsl-channel : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> atm-if : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> atm-pvc : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::VpiId> : <Eqpt::VciId> bridge-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::VpiId> : <Eqpt::VciId> vlan-port:ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / <Eqpt::Ng2OntSlotId> / <Eqpt::Ng2OntPortId> :	identifies the ellid where the alarm has occurred

Resource Identifier	Type	Description
	<pre> <Eqpt::UnstackedVlan> l2-vlan : <Eqpt::VlanId> ip : <Eqpt::LogicalId> sw-loopback slip uni:ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / <Eqpt::Ng2OntSlotId> / <Eqpt::Ng2OntPortId> vlan-port:ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / <Eqpt::Ng2OntSlotId> / <Eqpt::Ng2OntPortId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> atm-bonding : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> bonding : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> ip-gateway : <Eqpt::VrfId> ip-line : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::VpiId> : <Eqpt::VciId> ip-line : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> shdsl-line : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> e1-line : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> atm-ima : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> ethernet-line : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> bridge-port:ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / vuni vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::VpiId> : <Eqpt::VciId> : <Eqpt::UnstackedVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::UnstackedVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::VpiId> : <Eqpt::VciId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> voip:ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> ip-line : vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::VpiId> : <Eqpt::VciId> : <Eqpt::UnstackedVlan> ip-line : vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::UnstackedVlan> ip-line : vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::VpiId> : <Eqpt::VciId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> ip-line : vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan-port:ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / vuni : </pre>	

Resource Identifier	Type	Description
	stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan-port.ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / vuni : <Eqpt::UnstackedVlan> chgroup : <Eqpt::ChannelGroupId> subchgroup : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> bridge-port.ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / <Eqpt::Ng2OntSlotId> / <Eqpt::Ng2OntPortId> atm-pvc : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> bridge-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> bridge-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> / <Eqpt::OntPortId> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> / <Eqpt::OntPortId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> / <Eqpt::OntPortId> : <Eqpt::UnstackedVlan> pon : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> ont : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> uni : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> / <Eqpt::OntPortId> bridge-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / voip bridge-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / vuni vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / voip : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / vuni : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / voip : <Eqpt::UnstackedVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / vuni : <Eqpt::UnstackedVlan> voip : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> la-group : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::LLId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> bridge-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> /	

Resource Identifier	Type	Description
	<Eqpt::LLId> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::LLId> : <Eqpt::UnstackedVlan> mpm : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::ComboPonId> x-pon : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::XPonId> 25g-pon : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::M25GPonId> dist-router-interface : slot-stacked : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::SVlan> : <Eqpt::CVlan> dist-router-interface : slot-vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::UnstackedVlan> bundle : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::BundleId> chpair : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::ChannelPairId> ont.ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId>) Possible values: - xdsl-line : a static xdsl line interface - xdsl-channel : a static xdsl channel interface - atm-if : a static atm interface - atm-pvc : an atm pvc interface - bridge-port : a vlan bridge-port - bridge-port:ng2 : a ngpon2 vlan bridge-port - l2-vlan : a l2-vlan interface - ip : an ip interface - sw-loopback : a software loopback interface - slip : a slip interface - atm-bonding : atm bonding obsolete alternative replaced by bonding - bonding : bonding - ip-gateway : ip user gateway interface - ip-line : ip line interface - shdsl-line : a static shdsl line interface - e1-line : a e1 line interface - atm-ima : atm ima - ethernet-line : an ethernet line interface - vlan-port : vlan port - vlan-port:ng2 : a ngpon2 vlan port - pon : pon - x-pon : xgs pon - 25g-pon : 25g pon - chpair : channelpair - chgroup : channelgroup - subchgroup : subchannelgroup - bundle : bundle - ont : ont - ont:ng2 : ngpon2 ONT style identification - uni : uni - uni:ng2 : ngpon2 UNI style identification - voip : voip - voip:ng2 : voip - la-group : link aggregation group	

101 query current alarms by filters

Resource Identifier	Type	Description
	- dist-router-interface : dist router interface - voicefxs : voicefxs - mpm : multi-pon module Possible values: - vlan : vlan port Possible values: - slot-vlan : slot unstacked - slot-stacked : slot vlan port Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number Field type <Eqpt::VpiId> - atm VPI Field type <Eqpt::Vcild> - atm VCI Field type <Eqpt::PonId> - the PON identifier Field type <Eqpt::XPonId> - the XGS PON identifier Field type <Eqpt::M25GPonId> - the 25G PON identifier Field type <Eqpt::ComboPonId> - the comboPON identifier Field type <Eqpt::ChannelPairId> - the channel pair identifier Field type <Eqpt::ChannelGroupId> - the channel group identifier Field type <Eqpt::SubChannelGroupId> - the subchannel group identifier Field type <Eqpt::BundleId> - the BUNDLE identifier Field type <Eqpt::OntId> - the ONT identifier Field type <Eqpt::Ng2OntId> - the NG2 ONT identifier Possible values: - voip : virtual uni identifier obsolete alternative replaced by vuni - vuni : virtual uni identifier Possible values: - vuni : virtual NGPON2 uni identifier Field type <Eqpt::OntSlotId> - the ONT SLOT identifier Field type <Eqpt::OntPortId> - the ONT PORT identifier Field type <Eqpt::Ng2OntSlotId> - the NGPON2 ONT SLOT identifier Field type <Eqpt::Ng2OntPortId> - the NGPON2 ONT PORT identifier Field type <Eqpt::LLId> - the LLID identifier,range 1 for EPON,range 1-8 for DPOE Possible values:	

Resource Identifier	Type	Description
	- stacked : stacked vlan identity Field type <Eqpt::UnstackedVlan> - unstacked vlan id Field type <Eqpt::SVlan> - service vlan id Field type <Eqpt::CVlan> - customer vlan id Field type <Eqpt::VlanId> - VLAN id Field type <Eqpt::LogicalId> - logical id Field type <Eqpt::VrflId> - VRF id	

Command Output

Table 101.90-2 "show current alarm by filters" Display parameters

Specific Information		
name	Type	Description
aidinfo	Parameter type: <Alarm::AddInfoString> - additional alarm information	alarm AID parameters <i>This element is only shown in detail mode.</i>
type	Parameter type: <Alarm::alarmIHUBType> (equipment eqpt-holder plug-in-unit atm custom e1 ima-group ima-link redundancy shdsl ether-itf traffic-overflow qos-queue temporal spatial (software-mngt sw-mgmt) xdsl xdsl-ext xdsl-tca olt-gen eo-conv authentication bonding sfp shdsl-isam custom-ext-alarm plug-in-unit-ext sip-user-agent sip-plugin-unit sip-termination e1-sip-termination filetransfer external-device)	type of the alarms that are active <i>This element is only shown in detail mode.</i>

101 query current alarms by filters

name	Type	Description
	l2forward	
	ether-tca	
	ether-sfp	
	megaco-media-gw	
	megaco-sig-gw	
	megaco-plug-unit	
	megaco-term	
	megaco-sig-lt	
	eqpt-supplemental	
	eqpt-holder-ext	
	lsmredundancy	
	sync	
	mcsrc	
	vlanport	
	vect-line	
	vect-board	
	otdr	
	sip-dial-plan	
	sip-vsp	
	sip-server	
	bgp	
	rip	
	lag	
	ihub-general	
	vprn	
	isis	
	ospf	
	ihub-l2forward	
	vpls	
	ihub-equip	
	ihub-link	
	eont-phyoam	
	ellid	
	epon	
	eont-services-lan	
	eolt-ont-tca	
	eont-sw-dl	
	ldp	
	mpls	
	sdp	
	epipe	
	ihub-ipv6	
	pim	
	li	
	mgmt-sec-access	
	bfd	
	ai	
	tr069serv	
	ontsnmp	
	bulk-sync	
	protection-group	
	ont	
	sfu-sup	
	soho-sup	
	mdu-sup	
	ont-ani	
	sfu-sup2	

name	Type	Description
	soho-sup2	
	mdu-sup2	
	sfprssi	
	eoltrssi	
	cfm	
	sfpe1t1-framer	
	sfpe1t1-clock	
	pppcc-engine-tca	
	eth-cfm	
	rsvp	
	ihub-tca	
	eth-ring	
	efm-oam	
	ont-loopdetect	
	ont-video	
	ont-ces	
	ont-voip	
	ont-video-ani	
	ont-pwe	
	ont-cese1	
	ont-xdsl	
	ont-xdsl-tca	
	ont-hpna	
	ont-sip-agent-cfg	
	ont-voip-cfg	
	ont-mgc	
	ont-ploam	
	ont-gen	
	ont-card	
	ont-pots	
	ont-lan	
	ont-moca	
	ont-tc-tca	
	ont-moca-tca	
	ont-l2uni-eth-tca	
	olt-pon-tc-tca	
	olt-pon-util-tca	
	olt-chpr-util-tca	
	olt-ont-tc-tca	
	ont-tca	
	ont-pots-supplemental	
	sfu-ploam	
	sfu-gen	
	soho-ploam	
	soho-gen	
	mdu-ploam	
	mdu-gen	
	ont-veip	
	ont-iphost	
	alarm-table	
	auto-switch	
	channel-pair	
	ont-cfg-dld	
	olt-chpair-tc-tca	
	hgu-tr069	
	eqpt-psu	
	ont-protection	

101 query current alarms by filters

name	Type	Description
	secondary-megaco-term secondary-sip-term cas-r2-channel lldpmed pseudo-wire link-agg fcs-exceed e1t1-interface) Possible values: - equipment : equipment alarms - eqpt-holder : equipment holder alarms - plug-in-unit : plugin unit alarms - atm : ATM alarms - custom : customizable alarms - e1 : e1 alarms - ima-group : ima-group alarms - ima-link : ima-link alarms - redundancy : redundancy alarms - shdsl : shdsl alarms - ether-itf : ethernet interface alarms - traffic-overflow : Traffic overflow alarms - qos-queue : qos queue alarms - temporal : temporal alarms - spatial : spatial alarms - software-mngt : software management alarms - sw-mgmt : software management alarms - xdsl : xDSL alarms - xdsl-ext : other xDSL alarms - xdsl-tca : xDSL threshold cross alarms - olt-gen : OLT general alarms - eo-conv : E/O conversion related alarms - authentication : authentication related alarms - bonding : bonding-group related alarms - sfp : SFP related alarms - shdsl-isam : shdsl isam alarms - custom-ext-alarm : customizable external alarms - plug-in-unit-ext : other plugin unit alarms - sip-user-agent : sip user agent related alarms - sip-plugin-unit : sip plug in unit related alarms - sip-termination : sip termination related alarms - e1-sip-termination : E1 sip termination related alarms - filetransfer : file transfer server alarms - external-device : external device related alarms - l2forward : l2forward related alarms - ether-tca : ethernet threshold cross alarms - ether-sfp : ethernet SFP related alarms - megaco-media-gw : megaco media gateway related alarms - megaco-sig-gw : megaco signaling gateway related alarms - megaco-plug-unit : megaco plug unit related alarms - megaco-term : megaco termination related alarms - megaco-sig-lt : megaco signaling lt related alarms - eqpt-supplemental : equipment supplemental alarms - eqpt-holder-ext : other equipment holder alarms - lsmredundancy : lsm redundancy alarms - sync : synce and bits alarms - mcsrc : multicast source alarms - vlanport : vlanport alarms	

name	Type	Description
	- vect-line : xDSL vectoring line alarms - vect-board : xDSL vectoring board alarms - otdr : otdr alarms - sip-dial-plan : sip dial plan related alarms - sip-vsp : sip vsp related alarms - sip-server : sip server related alarms - bgp : bgp related alarms - rip : rip related alarms - lag : LAG related alarms - ihub-general : IHUB general related alarms - vprn : vprn related alarms - isis : isis related alarms - ospf : ospf related alarms - ihub-l2forward : ihub-l2forward alarms - vpls : vpls related alarms - ihub-equip : ihub-equip related alarms - ihub-link : ihub-link related alarms - eont-phyoam : eont phyoam related alarms - ellid : ellid related alarms - epon : epon related alarms - eont-services-lan : eon phyoam related alarms - eolt-ont-tca : eon phyoam related alarms - eont-sw-dl : eon phyoam related alarms - ldp : ldp related alarms - mpls : mpls related alarms - sdp : sdp related alarms - epipe : epipe related alarms - ihub-ipv6 : ihub-ipv6 related alarms - pim : pim related alarms - li : lawful intercept related alarms - mgmt-sec-access : management security related alarms - bfd : bfd related alarms - ai : Application Intelligence related alarms - tr069serv : tr069 server related alarms - ontsnmp : ont snmp related alarms - bulk-sync : bulk-sync related alarms - protection-group : port protection group related alarms - ont : ONT general supplemental related alarms - sfu-sup : SFU ONT general supplemental related alarms - soho-sup : SOHO ONT general supplemental related alarms - mdu-sup : MDU ONT general supplemental related alarms - ont-ani : ONT general supplemental 2 related alarms - sfu-sup2 : SFU ONT general supplemental 2 related alarms - soho-sup2 : SOHO ONT general supplemental 2 related alarms - mdu-sup2 : MDU ONT general supplemental 2 related alarms - sfprssi : SFP RSSI related alarms - eoltrssi : epon olt Sfp RSSI related alarms - cfm : Cfm related alarms - sfpe1t1-framer : SFP 2e1t1 framer alarms - sfpe1t1-clock : SFP 2e1t1 clock alarms - pppcc-engine-tca : PPPOE Cross Connect Engine TCA related alarm - eth-cfm : eth-cfm related alarms - rsvp : rsvp related alarms	

101 query current alarms by filters

name	Type	Description
	- ihub-tca : IHUB TCA related alarms - eth-ring : eth-ring related alarms - efm-oam : EFM-OAM related alarms - ont-loopdetect : ont loop detect related alarms - ont-video : ont services video related alarms - ont-ces : ont services ces related alarms - ont-voip : ont services voip related alarms - ont-video-ani : ont services video ani related alarms - ont-pwe : ont services pwe related alarms - ont-cese1 : ont services cese1 related alarms - ont-xdsl : ont services xdsl related alarms - ont-xdsl-tca : ont services xdsl tca related alarms - ont-hpna : ont hpna related alarms - ont-sip-agent-cfg : ont services voip sip agent config related alarms - ont-voip-cfg : ont services voip config related alarms - ont-mgc : ont mgc related alarms - ont-ploam : ONT PLOAM related alarms - ont-gen : ONT GENERAL related alarms - ont-card : ONT Subscriber Card related alarms - ont-pots : ONT Services POTS related alarms - ont-lan : ONT Services LAN related alarms - ont-moca : ONT MoCA related alarms - ont-tc-tca : ONT TC TCA related alarms - ont-moca-tca : ONT MoCA TCA related alarms - ont-l2uni-eth-tca : ONT L2 UNI Ethernet TCA related alarms - olt-pon-tc-tca : OLT PON TC TCA related alarms - olt-pon-util-tca : OLT PON utilization TCA related alarms - olt-chpr-util-tca : OLT channel-pair utilization TCA related alarms - olt-ont-tc-tca : OLT ONT TC TCA related alarms - ont-tca : ONT TCA related alarms - ont-pots-supplemental : ONT POTS Supplemental related alarms - sfu-ploam : SFU ONT PLOAM related alarms - sfu-gen : SFU ONT general related alarms - soho-ploam : SOHO ONT PLOAM related alarms - soho-gen : SOHO ONT general related alarms - mdu-ploam : MDU ONT PLOAM related alarms - mdu-gen : MDU ONT general related alarms - ont-veip : ONT VEIP related alarms - ont-iphost : ONT IP HOST related alarms - alarm-table : alarm table related alarms - auto-switch : auto-switch related alarms - channel-pair : channel pair related alarms - ont-cfg-dld : ont configure file download related alarms - olt-chpair-tc-tca : OLT CHANNELPAIR TC TCA related alarms - hgu-tr069 : hgu tr069 related alarms - eqpt-psu : equipment psu alarms - ont-protection : ONT protection related alarms - secondary-megaco-term : secondary megaco termination related alarms - secondary-sip-term : secondary sip termination related alarms - cas-r2-channel : CAS R2 channel related alarms	

name	Type	Description
	- lldpmed : lldpmed alarms - pseudo-wire : pseudo Wire related alarms - link-aggr : Link aggregation related alarms - fcs-exceed : FCS auto-recovery related alarms - e1t1-interface : E1/T1 physical interfaces related alarms	
name	Parameter type: <Alarm::almtypellidihub> (key-fail-one-churn key-fail-three-churn oam-discov-fail report-timeout total-packets-exceed arp-packets-exceed dhcp-packets-exceed igmp-packets-exceed pppoe-packets-exceed nd-packets-exceed icmpv6-packets-exceed mld-packets-exceed dhcpv6-packets-exceed cfm-packets-exceed all) Possible values: - key-fail-one-churn : key exchange failure during one churning time - key-fail-three-churn : key exchange failure during three churning time - oam-discov-fail : extend oam discovery failure - report-timeout : report timeout detecting - total-packets-exceed : total amount of protocol packets exceed threshold - arp-packets-exceed : protocol arp packets exceed threshold - dhcp-packets-exceed : protocol dhcp packets exceed threshold - igmp-packets-exceed : protocol igmp packets exceed threshold - pppoe-packets-exceed : protocol pppoe packets exceed threshold - nd-packets-exceed : protocol nd packets exceed threshold - icmpv6-packets-exceed : protocol icmpv6 packets exceed threshold - mld-packets-exceed : protocol mld packets exceed threshold - dhcpv6-packets-exceed : protocol dhcpv6 packets exceed threshold - cfm-packets-exceed : protocol cfm packets exceed threshold - all : ellid related alarms	alarm name that are active <i>This element is only shown in detail mode.</i>
severity	Parameter type: <Alarm::AlarmSeverity> (indeterminate warning minor major critical) Possible values: - indeterminate : alarm severity is indeterminate - warning : alarm severity is warning - minor : alarm severity is minor	the alarms severity level <i>This element is only shown in detail mode.</i>

101 query current alarms by filters

name	Type	Description
	- major : alarm severity is major - critical : alarm severity is critical	
servaff	Parameter type: <Alarm::alarmServAffect> ((service-affecting yes) (noservice-affecting no)) Possible values: - service-affecting : make this alarm service affecting - yes : make this alarm service affecting - noservice-affecting : make this alarm not service affecting - no : make this alarm not service affecting	alarms affect service or not <i>This element is only shown in detail mode.</i>
time	Parameter type: <Sys::timeInSecs> - the time (yyyy-mm-dd:hour:minutes:secs) - unit: UTC	time in seconds when alarm was updated <i>This element is only shown in detail mode.</i>
descript	Parameter type: <Alarm::AddInfoString> - additional alarm information	alarm description <i>This element is only shown in detail mode.</i>

101.91 show current alarm by filters

Command Description

show current alarms by filters

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm query epon [ (name) [ severity <Alarm::querySeverity> ] [ servaff <Alarm::queryServAffect> ] [
pon-index <Itf::ComplexPortType> ] ]
```

Command Parameters

Table 101.91-1 "show current alarm by filters" Resource Parameters

Resource Identifier	Type	Description
(name)	Format: (onu-unprovisioned signal-loss bitrate-high opmodule-mismatch all) Possible values: - onu-unprovisioned : unprovisioned ont - signal-loss : pon loss of signal - bitrate-high : the error bit rate high at pon interface - opmodule-mismatch : the optical module mismatched at pon interface - all : epon related alarms	alarm name of pon
severity	Parameter type: <Alarm::querySeverity> Format: (indeterminate warning minor major critical all) Possible values: - indeterminate : alarm severity is indeterminate - warning : alarm severity is warning - minor : alarm severity is minor - major : alarm severity is major - critical : alarm severity is critical - all : all alarm severity	severity level of an alarm for reporting

101 query current alarms by filters

Resource Identifier	Type	Description
servaff	Parameter type: <Alarm::queryServAffect> Format: (service-affecting noservice-affecting all) Possible values: - service-affecting : query alarm service affecting - noservice-affecting : query alarm not service affecting - all : query service affecting and not affecting alarms	serviceaffecting no serviceaffecting
pon-index	Parameter type: <Itf::ComplexPortType> Format: (xdsl-line : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> voicefxs : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> xdsl-channel : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> atm-if : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> atm-pvc : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::VpiId> : <Eqpt::VciId> bridge-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::VpiId> : <Eqpt::VciId> vlan-port:ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / <Eqpt::Ng2OntSlotId> / <Eqpt::Ng2OntPortId> : <Eqpt::UnstackedVlan> l2-vlan : <Eqpt::VlanId> ip : <Eqpt::LogicalId> sw-loopback slip uni:ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / <Eqpt::Ng2OntSlotId> / <Eqpt::Ng2OntPortId> vlan-port:ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / <Eqpt::Ng2OntSlotId> / <Eqpt::Ng2OntPortId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> atm-bonding : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> bonding : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> ip-gateway : <Eqpt::VrfId> ip-line : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::VpiId> : <Eqpt::VciId> ip-line : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> shdsl-line : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> e1-line : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> atm-ima : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> ethernet-line : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId>	identifies the epon where the alarm has occurred

Resource Identifier	Type	Description
	bridge-port:ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / vuni vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::VpiId> : <Eqpt::VciId> : <Eqpt::UnstackedVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::UnstackedVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::VpiId> : <Eqpt::VciId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> voip:ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> ip-line : vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::VpiId> : <Eqpt::VciId> : <Eqpt::UnstackedVlan> ip-line : vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::UnstackedVlan> ip-line : vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::VpiId> : <Eqpt::VciId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> ip-line : vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan-port:ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / vuni : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan-port:ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / vuni : <Eqpt::UnstackedVlan> chgroup : <Eqpt::ChannelGroupId> subchgroup : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> bridge-port:ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / <Eqpt::Ng2OntSlotId> / <Eqpt::Ng2OntPortId> atm-pvc : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> bridge-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> bridge-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> / <Eqpt::OntPortId> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> / <Eqpt::OntPortId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> / <Eqpt::OntPortId> : <Eqpt::UnstackedVlan> pon : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> ont : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId>	

Resource Identifier	Type	Description
	uni : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> / <Eqpt::OntPortId> bridge-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / voip bridge-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / vuni vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / voip : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / vuni : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / voip : <Eqpt::UnstackedVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / vuni : <Eqpt::UnstackedVlan> voip : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> la-group : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::LLId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> bridge-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::LLId> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::LLId> : <Eqpt::UnstackedVlan> mpm : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::ComboPonId> x-pon : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::XPonId> 25g-pon : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::M25GPonId> dist-router-interface : slot-stacked : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::SVlan> : <Eqpt::CVlan> dist-router-interface : slot-vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::UnstackedVlan> bundle : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::BundleId> chpair : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::ChannelPairId> ont.ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId>) Possible values: - xdsl-line : a static xdsl line interface - xdsl-channel : a static xdsl channel interface - atm-if : a static atm interface - atm-pvc : an atm pvc interface - bridge-port : a vlan bridge-port - bridge-port:ng2 : a ngpon2 vlan bridge-port - l2-vlan : a l2-vlan interface	

Resource Identifier	Type	Description
	- ip : an ip interface - sw-loopback : a software loopback interface - slip : a slip interface - atm-bonding : atm bonding obsolete alternative replaced by bonding - bonding : bonding - ip-gateway : ip user gateway interface - ip-line : ip line interface - shdsl-line : a static shdsl line interface - e1-line : a e1 line interface - atm-ima : atm ima - ethernet-line : an ethernet line interface - vlan-port : vlan port - vlan-port:ng2 : a ngpon2 vlan port - pon : pon - x-pon : xgs pon - 25g-pon : 25g pon - chpair : channelpair - chgroup : channelgroup - subchgroup : subchannelgroup - bundle : bundle - ont : ont - ont:ng2 : ngpon2 ONT style identification - uni : uni - uni:ng2 : ngpon2 UNI style identification - voip : voip - voip:ng2 : voip - la-group : link aggregation group - dist-router-interface : dist router interface - voicefxs : voicefxs - mpm : multi-pon module Possible values: - vlan : vlan port Possible values: - slot-vlan : slot unstacked - slot-stacked : slot vlan port Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number Field type <Eqpt::VpiId> - atm VPI Field type <Eqpt::VciId> - atm VCI Field type <Eqpt::PonId> - the PON identifier Field type <Eqpt::XPonId> - the XGS PON identifier Field type <Eqpt::M25GPonId> - the 25G PON identifier Field type <Eqpt::ComboPonId> - the comboPON identifier Field type <Eqpt::ChannelPairId>	

Resource Identifier	Type	Description
	- the channel pair identifier Field type <Eqpt::ChannelGroupId> - the channel group identifier Field type <Eqpt::SubChannelGroupId> - the subchannel group identifier Field type <Eqpt::BundleId> - the BUNDLE identifier Field type <Eqpt::OntId> - the ONT identifier Field type <Eqpt::Ng2OntId> - the NG2 ONT identifier Possible values: - voip : virtual uni identifier obsolete alternative replaced by vuni - vuni : virtual uni identifier Possible values: - vuni : virtual NGPON2 uni identifier - Field type <Eqpt::OntSlotId> - the ONT SLOT identifier Field type <Eqpt::OntPortId> - the ONT PORT identifier Field type <Eqpt::Ng2OntSlotId> - the NGPON2 ONT SLOT identifier Field type <Eqpt::Ng2OntPortId> - the NGPON2 ONT PORT identifier Field type <Eqpt::LLId> - the LLID identifier, range 1 for EPON, range 1-8 for DPOE Possible values: - stacked : stacked vlan identity Field type <Eqpt::UnstackedVlan> - unstacked vlan id Field type <Eqpt::SVlan> - service vlan id Field type <Eqpt::CVlan> - customer vlan id Field type <Eqpt::VlanId> - VLAN id Field type <Eqpt::LogicalId> - logical id Field type <Eqpt::VrfId> - VRF id	

Command Output

Table 101.91-2 "show current alarm by filters" Display parameters

Specific Information		
name	Type	Description
aidinfo	Parameter type: <Alarm::AddInfoString> - additional alarm information	alarm AID parameters <i>This element is only shown in detail mode.</i>
type	Parameter type: <Alarm::alarmIHUBType> (equipment eqpt-holder plug-in-unit atm custom	type of the alarms that are active <i>This element is only shown in detail mode.</i>

name	Type	Description
	e1 ima-group ima-link redundancy shdsl ether-itf traffic-overflow qos-queue temporal spatial (software-mngt sw-mgmt) xdsl xdsl-ext xdsl-tca olt-gen eo-conv authentication bonding sfp shdsl-isam custom-ext-alarm plug-in-unit-ext sip-user-agent sip-plugin-unit sip-termination e1-sip-termination filetransfer external-device l2forward ether-tca ether-sfp megaco-media-gw megaco-sig-gw megaco-plugin-unit megaco-term megaco-sig-lt eqpt-supplemental eqpt-holder-ext lsmredundancy sync mcsrc vlanport vect-line vect-board otdr sip-dial-plan sip-vsp sip-server bgp rip lag ihub-general vprn isis ospf ihub-l2forward vpls	

101 query current alarms by filters

name	Type	Description
	ihub-equip	
	ihub-link	
	eont-phyoam	
	ellid	
	epon	
	eont-services-lan	
	eolt-ont-tca	
	eont-sw-dl	
	ldp	
	mpls	
	sdp	
	epipe	
	ihub-ipv6	
	pim	
	li	
	mgmt-sec-access	
	bfd	
	ai	
	tr069serv	
	ontsnmp	
	bulk-sync	
	protection-group	
	ont	
	sfu-sup	
	soho-sup	
	mdu-sup	
	ont-ani	
	sfu-sup2	
	soho-sup2	
	mdu-sup2	
	sfprssi	
	eoltrssi	
	cfm	
	sfpe1t1-framer	
	sfpe1t1-clock	
	pppcc-engine-tca	
	eth-cfm	
	rsvp	
	ihub-tca	
	eth-ring	
	efm-oam	
	ont-loopdetect	
	ont-video	
	ont-ces	
	ont-voip	
	ont-video-ani	
	ont-pwe	
	ont-cese1	
	ont-xdsl	
	ont-xdsl-tca	
	ont-hpna	
	ont-sip-agent-cfg	
	ont-voip-cfg	
	ont-mgc	
	ont-ploam	
	ont-gen	
	ont-card	

name	Type	Description
	ont-pots ont-lan ont-moca ont-tc-tca ont-moca-tca ont-l2uni-eth-tca olt-pon-tc-tca olt-pon-util-tca olt-chpr-util-tca olt-ont-tc-tca ont-tca ont-pots-supplemental sfu-ploam sfu-gen soho-ploam soho-gen mdu-ploam mdu-gen ont-veip ont-iphost alarm-table auto-switch channel-pair ont-cfg-dld olt-chpair-tc-tca hgu-tr069 eqpt-psu ont-protection secondary-megaco-term secondary-sip-term cas-r2-channel lldpmed pseudo-wire link-agg fcs-exceed e1t1-interface) Possible values: - equipment : equipment alarms - eqpt-holder : equipment holder alarms - plug-in-unit : plugin unit alarms - atm : ATM alarms - custom : customizable alarms - e1 : e1 alarms - ima-group : ima-group alarms - ima-link : ima-link alarms - redundancy : redundancy alarms - shdsl : shdsl alarms - ether-itf : ethernet interface alarms - traffic-overflow : Traffic overflow alarms - qos-queue : qos queue alarms - temporal : temporal alarms - spatial : spatial alarms - software-mngt : software management alarms - sw-mgmt : software management alarms - xdsl : xDSL alarms - xdsl-ext : other xDSL alarms - xdsl-tca : xDSL threshold cross alarms	

101 query current alarms by filters

name	Type	Description
	- olt-gen : OLT general alarms - eo-conv : E/O conversion related alarms - authentication : authentication related alarms - bonding : bonding-group related alarms - sfp : SFP related alarms - shdsl-isam : shdsl isam alarms - custom-ext-alarm : customizable external alarms - plug-in-unit-ext : other plugin unit alarms - sip-user-agent : sip user agent related alarms - sip-plugin-unit : sip plug in unit related alarms - sip-termination : sip termination related alarms - e1-sip-termination : E1 sip termination related alarms - filetransfer : file transfer server alarms - external-device : external device related alarms - l2forward : l2forward related alarms - ether-tca : ethernet threshold cross alarms - ether-sfp : ethernet SFP related alarms - megaco-media-gw : megaco media gateway related alarms - megaco-sig-gw : megaco signaling gateway related alarms - megaco-plug-unit : megaco plug unit related alarms - megaco-term : megaco termination related alarms - megaco-sig-lt : megaco signaling lt related alarms - eqpt-supplemental : equipment supplemental alarms - eqpt-holder-ext : other equipment holder alarms - lsmredundancy : lsm redundancy alarms - sync : synce and bits alarms - mcsrc : multicast source alarms - vlanport : vlanport alarms - vect-line : xDSL vectoring line alarms - vect-board : xDSL vectoring board alarms - otdr : otdr alarms - sip-dial-plan : sip dial plan related alarms - sip-vsp : sip vsp related alarms - sip-server : sip server related alarms - bgp : bgp related alarms - rip : rip related alarms - lag : LAG related alarms - ihub-general : IHUB general related alarms - vprn : vprn related alarms - isis : isis related alarms - ospf : ospf related alarms - ihub-l2forward : ihub-l2forward alarms - vpls : vpls related alarms - ihub-equip : ihub-equip related alarms - ihub-link : ihub-link related alarms - eont-phyoam : eont phyoam related alarms - ellid : ellid related alarms - epon : epon related alarms - eont-services-lan : eon phyoam related alarms - eolt-ont-tca : eon phyoam related alarms - eont-sw-dl : eon phyoam related alarms - ldp : ldp related alarms - mpls : mpls related alarms - sdp : sdp related alarms - epipe : epipe related alarms - ihub-ipv6 : ihub-ipv6 related alarms - pim : pim related alarms	

name	Type	Description
	- li : lawful intercept related alarms - mgmt-sec-access : management security related alarms - bfd : bfd related alarms - ai : Application Intelligence related alarms - tr069serv : tr069 server related alarms - ontsnmp : ont snmp related alarms - bulk-sync : bulk-sync related alarms - protection-group : port protection group related alarms - ont : ONT general supplemental related alarms - sfu-sup : SFU ONT general supplemental related alarms - soho-sup : SOHO ONT general supplemental related alarms - mdu-sup : MDU ONT general supplemental related alarms - ont-ani : ONT general supplemental 2 related alarms - sfu-sup2 : SFU ONT general supplemental 2 related alarms - soho-sup2 : SOHO ONT general supplemental 2 related alarms - mdu-sup2 : MDU ONT general supplemental 2 related alarms - sfprssi : SFP RSSI related alarms - eoltrssi : epon olt Sfp RSSI related alarms - cfm : Cfm related alarms - sfpe1t1-framer : SFP 2e1t1 framer alarms - sfpe1t1-clock : SFP 2e1t1 clock alarms - pppcc-engine-tca : PPPOE Cross Connect Engine TCA related alarm - eth-cfm : eth-cfm related alarms - rsvp : rsvp related alarms - ihub-tca : IHUB TCA related alarms - eth-ring : eth-ring related alarms - efm-oam : EFM-OAM related alarms - ont-loopdetect : ont loop detect related alarms - ont-video : ont services video related alarms - ont-ces : ont services ces related alarms - ont-voip : ont services voip related alarms - ont-video-ani : ont services video ani related alarms - ont-pwe : ont services pwe related alarms - ont-cese1 : ont services cese1 related alarms - ont-xdsl : ont services xdsl related alarms - ont-xdsl-tca : ont services xdsl tca related alarms - ont-hpna : ont hpna related alarms - ont-sip-agent-cfg : ont services voip sip agent config related alarms - ont-voip-cfg : ont services voip config related alarms - ont-mgc : ont mgc related alarms - ont-ploam : ONT PLOAM related alarms - ont-gen : ONT GENERAL related alarms - ont-card : ONT Subscriber Card related alarms - ont-pots : ONT Services POTS related alarms - ont-lan : ONT Services LAN related alarms - ont-moca : ONT MoCA related alarms - ont-tc-tca : ONT TC TCA related alarms - ont-moca-tca : ONT MoCA TCA related alarms - ont-l2uni-eth-tca : ONT L2 UNI Ethernet TCA related alarms - olt-pon-tc-tca : OLT PON TC TCA related alarms - olt-pon-util-tca : OLT PON utilization TCA related alarms	

101 query current alarms by filters

name	Type	Description
	- olt-chpr-util-tca : OLT channel-pair utilization TCA related alarms - olt-ont-tc-tca : OLT ONT TC TCA related alarms - ont-tca : ONT TCA related alarms - ont-pots-supplemental : ONT POTS Supplemental related alarms - sfu-ploam : SFU ONT PLOAM related alarms - sfu-gen : SFU ONT general related alarms - soho-ploam : SOHO ONT PLOAM related alarms - soho-gen : SOHO ONT general related alarms - mdu-ploam : MDU ONT PLOAM related alarms - mdu-gen : MDU ONT general related alarms - ont-veip : ONT VEIP related alarms - ont-iphost : ONT IP HOST related alarms - alarm-table : alarm table related alarms - auto-switch : auto-switch related alarms - channel-pair : channel pair related alarms - ont-cfg-dld : ont configure file download related alarms - olt-chpair-tc-tca : OLT CHANNELPAIR TC TCA related alarms - hgu-tr069 : hgu tr069 related alarms - eqpt-psu : equipment psu alarms - ont-protection : ONT protection related alarms - secondary-megaco-term : secondary megaco termination related alarms - secondary-sip-term : secondary sip termination related alarms - cas-r2-channel : CAS R2 channel related alarms - lldpmed : lldpmed alarms - pseudo-wire : pseudo Wire related alarms - link-agg : Link aggregation related alarms - fcs-exceed : FCS auto-recovery related alarms - e1t1-interface : E1/T1 physical interfaces related alarms	
name	Parameter type: <Alarm::almtypeEponihub> (onu-unprovisioned signal-loss bitrate-high opmodule-mismatch all) Possible values: - onu-unprovisioned : unprovisioned ont - signal-loss : pon loss of signal - bitrate-high : the error bit rate high at pon interface - opmodule-mismatch : the optical module mismatched at pon interface - all : epon related alarms	alarm name that are active <i>This element is only shown in detail mode.</i>
severity	Parameter type: <Alarm::AlarmSeverity> (indeterminate warning minor major critical) Possible values: - indeterminate : alarm severity is indeterminate - warning : alarm severity is warning - minor : alarm severity is minor - major : alarm severity is major	the alarms severity level <i>This element is only shown in detail mode.</i>

name	Type	Description
	- critical : alarm severity is critical	
servaff	Parameter type: <Alarm::alarmServAffect> ((service-affecting yes) (noservice-affecting no)) Possible values: - service-affecting : make this alarm service affecting - yes : make this alarm service affecting - noservice-affecting : make this alarm not service affecting - no : make this alarm not service affecting	alarms affect service or not <i>This element is only shown in detail mode.</i>
time	Parameter type: <Sys::timeInSecs> - the time (yyyy-mm-dd:hour:minutes:secs) - unit: UTC	time in seconds when alarm was updated <i>This element is only shown in detail mode.</i>
descript	Parameter type: <Alarm::AddInfoString> - additional alarm information	alarm description <i>This element is only shown in detail mode.</i>

101.92 show current alarm by filters

Command Description

show current alarms by filters

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm query ont-pots-supplemental [ (name) [ severity <Alarm::querySeverity> ] [ servaff
<Alarm::queryServAffect> ] [ ont-port <Alarm::queryDefaultAid> ] ]
```

Command Parameters

Table 101.92-1 "show current alarm by filters" Resource Parameters

Resource Identifier	Type	Description
(name)	Format: (ont-sip-reg-dns ont-sip-reg-fail ont-sip-reg-timeout ont-sip-reg-err-resps ont-sip-inv-dns ont-sip-inv-auth ont-sip-inv-timeout ont-sip-inv-err ont-svc-pots-subs-refr ont-svc-pots-not-refr ont-svc-pots-icfg-err all) Possible values: - ont-sip-reg-dns : ont services pots sip registration failed (resolving domain name) - ont-sip-reg-fail : ont services pots sip registration authentication failed - ont-sip-reg-timeout : ont services pots sip registration timeout - ont-sip-reg-err-resps : ont services pots sip registration response error - ont-sip-inv-dns : ont services pots sip invitation failed (resolving domain name) - ont-sip-inv-auth : ont services pots sip invitation authentication failed - ont-sip-inv-timeout : ont services pots sip invitation timeout	alarm name of ONT POTS Supplemental

Resource Identifier	Type	Description
	- ont-sip-inv-err : ont services pots sip invitation response error - ont-svc-pots-subscr-refr: ont services pots iconfig subscription could not be refreshed - ont-svc-pots-not-refr : ont services pots iconfig notification could not be refreshed - ont-svc-pots-icfg-err : ont services pots service failed due to an unmapped iconfig error - all : ONT POTS Supplemental related alarms	
severity	Parameter type: <Alarm::querySeverity> Format: (indeterminate warning minor major critical all) Possible values: - indeterminate : alarm severity is indeterminate - warning : alarm severity is warning - minor : alarm severity is minor - major : alarm severity is major - critical : alarm severity is critical - all : all alarm severity	severity level of an alarm for reporting
servaff	Parameter type: <Alarm::queryServAffect> Format: (service-affecting noservice-affecting all) Possible values: - service-affecting : query alarm service affecting - noservice-affecting : query alarm not service affecting - all : query service affecting and not affecting alarms	serviceaffecting no serviceaffecting
ont-port	Parameter type: <Alarm::queryDefaultAid> Format: all Possible values: - all : default AID parameter	all of gpon ont port

Command Output

Table 101.92-2 "show current alarm by filters" Display parameters

Specific Information		
name	Type	Description
aidinfo	Parameter type: <Alarm::AddInfoString> - additional alarm information	alarm AID parameters <i>This element is only shown in detail mode.</i>
type	Parameter type: <Alarm::alarmIHUBType> (equipment eqpt-holder plug-in-unit atm custom e1 ima-group ima-link	type of the alarms that are active <i>This element is only shown in detail mode.</i>

101 query current alarms by filters

name	Type	Description
	redundancy shdsl ether-itf traffic-overflow qos-queue temporal spatial (software-mngt sw-mgmt) xdsl xdsl-ext xdsl-tca olt-gen eo-conv authentication bonding sfp shdsl-isam custom-ext-alarm plug-in-unit-ext sip-user-agent sip-plugin-unit sip-termination e1-sip-termination filetransfer external-device l2forward ether-tca ether-sfp megaco-media-gw megaco-sig-gw megaco-plug-unit megaco-term megaco-sig-lt eqpt-supplemental eqpt-holder-ext lsmredundancy sync mcsrc vlanport vect-line vect-board otdr sip-dial-plan sip-vsp sip-server bgp rip lag ihub-general vprn isis ospf ihub-l2forward vpls ihub-equip ihub-link eont-phyoam	

name	Type	Description
	ellid epon eont-services-lan eolt-ont-tca eont-sw-dl ldp mpls sdp epipe ihub-ipv6 pim li mgmt-sec-access bfd ai tr069serv ontsnmp bulk-sync protection-group ont sfu-sup soho-sup mdu-sup ont-ani sfu-sup2 soho-sup2 mdu-sup2 sfprssi eoltrssi cfm sfpe1t1-framer sfpe1t1-clock pppcc-engine-tca eth-cfm rsvp ihub-tca eth-ring efm-oam ont-loopdetect ont-video ont-ces ont-voip ont-video-ani ont-pwe ont-cese1 ont-xdsl ont-xdsl-tca ont-hpna ont-sip-agent-cfg ont-voip-cfg ont-mgc ont-ploam ont-gen ont-card ont-pots ont-lan ont-moca	

101 query current alarms by filters

name	Type	Description
	ont-tc-tca ont-moca-tca ont-l2uni-eth-tca olt-pon-tc-tca olt-pon-util-tca olt-chpr-util-tca olt-ont-tc-tca ont-tca ont-pots-supplemental sfu-ploam sfu-gen soho-ploam soho-gen mdu-ploam mdu-gen ont-veip ont-iphost alarm-table auto-switch channel-pair ont-cfg-dld olt-chpair-tc-tca hgu-tr069 eqpt-psu ont-protection secondary-megaco-term secondary-sip-term cas-r2-channel lldpmed pseudo-wire link-agg fcs-exceed e1t1-interface) Possible values: - equipment : equipment alarms - eqpt-holder : equipment holder alarms - plug-in-unit : plugin unit alarms - atm : ATM alarms - custom : customizable alarms - e1 : e1 alarms - ima-group : ima-group alarms - ima-link : ima-link alarms - redundancy : redundancy alarms - shdsl : shdsl alarms - ether-itf : ethernet interface alarms - traffic-overflow : Traffic overflow alarms - qos-queue : qos queue alarms - temporal : temporal alarms - spatial : spatial alarms - software-mngt : software management alarms - sw-mgmt : software management alarms - xdsl : xDSL alarms - xdsl-ext : other xDSL alarms - xdsl-tca : xDSL threshold cross alarms - olt-gen : OLT general alarms - eo-conv : E/O conversion related alarms - authentication : authentication related alarms	

name	Type	Description
	- bonding : bonding-group related alarms - sfp : SFP related alarms - shdsl-isam : shdsl isam alarms - custom-ext-alarm : customizable external alarms - plug-in-unit-ext : other plugin unit alarms - sip-user-agent : sip user agent related alarms - sip-plugin-unit : sip plug in unit related alarms - sip-termination : sip termination related alarms - e1-sip-termination : E1 sip termination related alarms - filetransfer : file transfer server alarms - external-device : external device related alarms - l2forward : l2forward related alarms - ether-tca : ethernet threshold cross alarms - ether-sfp : ethernet SFP related alarms - megaco-media-gw : megaco media gateway related alarms - megaco-sig-gw : megaco signaling gateway related alarms - megaco-plug-unit : megaco plug unit related alarms - megaco-term : megaco termination related alarms - megaco-sig-lt : megaco signaling lt related alarms - eqpt-supplemental : equipment supplemental alarms - eqpt-holder-ext : other equipment holder alarms - lsmredundancy : lsm redundancy alarms - sync : synce and bits alarms - mcsrc : multicast source alarms - vlanport : vlanport alarms - vect-line : xDSL vectoring line alarms - vect-board : xDSL vectoring board alarms - otdr : otdr alarms - sip-dial-plan : sip dial plan related alarms - sip-vsp : sip vsp related alarms - sip-server : sip server related alarms - bgp : bgp related alarms - rip : rip related alarms - lag : LAG related alarms - ihub-general : IHUB general related alarms - vprn : vprn related alarms - isis : isis related alarms - ospf : ospf related alarms - ihub-l2forward : ihub-l2forward alarms - vpls : vpls related alarms - ihub-equip : ihub-equip related alarms - ihub-link : ihub-link related alarms - eont-phyoam : eont phyoam related alarms - ellid : ellid related alarms - epon : epon related alarms - eont-services-lan : eon phyoam related alarms - eolt-ont-tca : eon phyoam related alarms - eont-sw-dl : eon phyoam related alarms - ldp : ldp related alarms - mpls : mpls related alarms - sdp : sdp related alarms - epipe : epipe related alarms - ihub-ipv6 : ihub-ipv6 related alarms - pim : pim related alarms - li : lawful intercept related alarms - mgmt-sec-access : management security related alarms - bfd : bfd related alarms	

101 query current alarms by filters

name	Type	Description
	- ai : Application Intelligence related alarms - tr069serv : tr069 server related alarms - ontsnmp : ont snmp related alarms - bulk-sync : bulk-sync related alarms - protection-group : port protection group related alarms - ont : ONT general supplemental related alarms - sfu-sup : SFU ONT general supplemental related alarms - soho-sup : SOHO ONT general supplemental related alarms - mdu-sup : MDU ONT general supplemental related alarms - ont-ani : ONT general supplemental 2 related alarms - sfu-sup2 : SFU ONT general supplemental 2 related alarms - soho-sup2 : SOHO ONT general supplemental 2 related alarms - mdu-sup2 : MDU ONT general supplemental 2 related alarms - sfrssi : SFP RSSI related alarms - eoltrssi : epon olt Sfp RSSI related alarms - cfm : Cfm related alarms - sfpe1t1-framer : SFP 2e1t1 framer alarms - sfpe1t1-clock : SFP 2e1t1 clock alarms - pppcc-engine-tca : PPPOE Cross Connect Engine TCA related alarm - eth-cfm : eth-cfm related alarms - rsvp : rsvp related alarms - ihub-tca : IHUB TCA related alarms - eth-ring : eth-ring related alarms - efm-oam : EFM-OAM related alarms - ont-loopdetect : ont loop detect related alarms - ont-video : ont services video related alarms - ont-ces : ont services ces related alarms - ont-voip : ont services voip related alarms - ont-video-ani : ont services video ani related alarms - ont-pwe : ont services pwe related alarms - ont-cese1 : ont services cese1 related alarms - ont-xdsl : ont services xdsl related alarms - ont-xdsl-tca : ont services xdsl tca related alarms - ont-hpna : ont hpna related alarms - ont-sip-agent-cfg : ont services voip sip agent config related alarms - ont-voip-cfg : ont services voip config related alarms - ont-mgc : ont mgc related alarms - ont-ploam : ONT PLOAM related alarms - ont-gen : ONT GENERAL related alarms - ont-card : ONT Subscriber Card related alarms - ont-pots : ONT Services POTS related alarms - ont-lan : ONT Services LAN related alarms - ont-moca : ONT MoCA related alarms - ont-tc-tca : ONT TC TCA related alarms - ont-moca-tca : ONT MoCA TCA related alarms - ont-l2uni-eth-tca : ONT L2 UNI Ethernet TCA related alarms - olt-pon-tc-tca : OLT PON TC TCA related alarms - olt-pon-util-tca : OLT PON utilization TCA related alarms - olt-chpr-util-tca : OLT channel-pair utilization TCA related alarms - olt-ont-tc-tca : OLT ONT TC TCA related alarms	

name	Type	Description
	- ont-tca : ONT TCA related alarms - ont-pots-supplemental : ONT POTS Supplemental related alarms - sfu-ploam : SFU ONT PLOAM related alarms - sfu-gen : SFU ONT general related alarms - soho-ploam : SOHO ONT PLOAM related alarms - soho-gen : SOHO ONT general related alarms - mdu-ploam : MDU ONT PLOAM related alarms - mdu-gen : MDU ONT general related alarms - ont-veip : ONT VEIP related alarms - ont-iphost : ONT IP HOST related alarms - alarm-table : alarm table related alarms - auto-switch : auto-switch related alarms - channel-pair : channel pair related alarms - ont-cfg-dld : ont configure file download related alarms - olt-chpair-tc-tca : OLT CHANNELPAIR TC TCA related alarms - hgu-tr069 : hgu tr069 related alarms - eqpt-psu : equipment psu alarms - ont-protection : ONT protection related alarms - secondary-megaco-term : secondary megaco termination related alarms - secondary-sip-term : secondary sip termination related alarms - cas-r2-channel : CAS R2 channel related alarms - lldpmed : lldpmed alarms - pseudo-wire : pseudo Wire related alarms - link-agg : Link aggregation related alarms - fcs-exceed : FCS auto-recovery related alarms - e1t1-interface : E1/T1 physical interfaces related alarms	
name	Parameter type: <Alarm::almtypeOntpotssupplementalhub> (ont-sip-reg-dns ont-sip-reg-fail ont-sip-reg-timeout ont-sip-reg-err-resps ont-sip-inv-dns ont-sip-inv-auth ont-sip-inv-timeout ont-sip-inv-err ont-svc-pots-subs-refr ont-svc-pots-not-refr ont-svc-pots-icfg-err all) Possible values: - ont-sip-reg-dns : ont services pots sip registration failed (resolving domain name) - ont-sip-reg-fail : ont services pots sip registration authentication failed - ont-sip-reg-timeout : ont services pots sip registration timeout - ont-sip-reg-err-resps : ont services pots sip registration response error - ont-sip-inv-dns : ont services pots sip invitation failed (resolving domain name) - ont-sip-inv-auth : ont services pots sip invitation authentication failed - ont-sip-inv-timeout : ont services pots sip invitation	alarm name that are active <i>This element is only shown in detail mode.</i>

101 query current alarms by filters

name	Type	Description
	timeout - ont-sip-inv-err : ont services pots sip invitation response error - ont-svc-pots-subs-refr: ont services pots iconfig subscription could not be refreshed - ont-svc-pots-not-refr : ont services pots iconfig notification could not be refreshed - ont-svc-pots-icfg-err : ont services pots service failed due to an unmapped iconfig error - all : ONT POTS Supplemental related alarms	
severity	Parameter type: <Alarm::AlarmSeverity> (indeterminate warning minor major critical) Possible values: - indeterminate : alarm severity is indeterminate - warning : alarm severity is warning - minor : alarm severity is minor - major : alarm severity is major - critical : alarm severity is critical	the alarms severity level <i>This element is only shown in detail mode.</i>
servaff	Parameter type: <Alarm::alarmServAffect> ((service-affecting yes) (noservice-affecting no)) Possible values: - service-affecting : make this alarm service affecting - yes : make this alarm service affecting - noservice-affecting : make this alarm not service affecting - no : make this alarm not service affecting	alarms affect service or not <i>This element is only shown in detail mode.</i>
time	Parameter type: <Sys::timeInSecs> - the time (yyyy-mm-dd:hour:minutes:secs) - unit: UTC	time in seconds when alarm was updated <i>This element is only shown in detail mode.</i>
descript	Parameter type: <Alarm::AddInfoString> - additional alarm information	alarm description <i>This element is only shown in detail mode.</i>

101.93 show current alarm by filters

Command Description

show current alarms by filters

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm query sfu-ploam [ (name) [ severity <Alarm::querySeverity> ] [ servaff <Alarm::queryServAffect> ]
[ ont <Gpon::OntIndex> ] ]
```

Command Parameters

Table 101.93-1 "show current alarm by filters" Resource Parameters

Resource Identifier	Type	Description
(name)	Format: (sfu-ploam-loss-sig sfu-ploam-loss-ack sfu-ploam-loss-cd sfu-ploam-phy-eqpt-err sfu-ploam-startup-fail sfu-ploam-sig-degrade sfu-ploam-disabled sfu-ploam-err-msg sfu-ploam-inactive sfu-ploam-sig-fail sfu-ploam-dying-gasp sfu-ploam-deact-fail sfu-ploam-oam sfu-ploam-win-drift sfu-ploam-rdi sfu-ploam-loss-ks sfu-ploam-pwr-burst sfu-ploam-rog-disa sfu-ploam-diff-reach sfu-ploam-looc all) Possible values: - sfu-ploam-loss-sig : SFU ONT - loss of signal at ont - sfu-ploam-loss-ack : SFU ONT - loss of acknowledge from ont - sfu-ploam-loss-cd : SFU ONT - loss of channel delineation of ont	alarm name of sfu-ploam

101 query current alarms by filters

Resource Identifier	Type	Description
	- sfu-ploam-phy-eqpt-err: SFU ONT - physical equipment error of ont - sfu-ploam-startup-fail: SFU ONT - startup failure in ranging of ont - sfu-ploam-sig-degrade : SFU ONT - signal degrade from ont - sfu-ploam-disabled : SFU ONT - ont disabled alarm - sfu-ploam-err-msg : SFU ONT - error message from ont - sfu-ploam-inactive : SFU ONT - inactive ont - sfu-ploam-sig-fail : SFU ONT - signal fail alarm from ont - sfu-ploam-dying-gasp : SFU ONT - dying gasp alarm from ont - sfu-ploam-deact-fail : SFU ONT - deactive failure of ont - sfu-ploam-oam : SFU ONT - loss of ploam for ont - sfu-ploam-win-drift : SFU ONT - drift of window alarm - sfu-ploam-rdi : SFU ONT - remote defect indication alarm - sfu-ploam-loss-ks : SFU ONT - loss of key synchronization alarm - sfu-ploam-pwr-burst : SFU ONT - power bursts on ont - sfu-ploam-roq-disa : SFU ONT - ont rogue disabled - sfu-ploam-diff-reach : SFU ONT - ont differential reach exceeded - sfu-ploam-looc : SFU ONT - Loss of OMCI channel due to persistent MIC failure - all : SFU ONT PLOAM related alarms	
severity	Parameter type: <Alarm::querySeverity> Format: (indeterminate warning minor major critical all) Possible values: - indeterminate : alarm severity is indeterminate - warning : alarm severity is warning - minor : alarm severity is minor - major : alarm severity is major - critical : alarm severity is critical - all : all alarm severity	severity level of an alarm for reporting
servaff	Parameter type: <Alarm::queryServAffect> Format: (service-affecting noservice-affecting all) Possible values: - service-affecting : query alarm service affecting - noservice-affecting : query alarm not service affecting - all : query service affecting and not affecting alarms	serviceaffecting no serviceaffecting
ont	Parameter type: <Gpon::OntIndex> Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> ng2 : <Ng2::ChannelGroup> / <Ng2::SubchannelGroup> / <Ng2::OntId>) Possible values: - ng2 : ngpon2 style identification	gpon ont equipment ifindex

Resource Identifier	Type	Description
	Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Ng2::ChannelGroup> - channel group number Field type <Ng2::SubchannelGroup> - subchannel group number Field type <Eqpt::OntId> - the ONT identifier Field type <Ng2::OntId> - the ONT identifier	

Command Output

Table 101.93-2 "show current alarm by filters" Display parameters

Specific Information		
name	Type	Description
aidinfo	Parameter type: <Alarm::AddInfoString> - additional alarm information	alarm AID parameters <i>This element is only shown in detail mode.</i>
type	Parameter type: <Alarm::alarmIHUBType> (equipment eqpt-holder plug-in-unit atm custom e1 ima-group ima-link redundancy shdsl ether-itf traffic-overflow qos-queue temporal spatial (software-mngt sw-mgmt) xdsl xdsl-ext xdsl-tca olt-gen eo-conv authentication bonding sfp shdsl-isam custom-ext-alarm plug-in-unit-ext sip-user-agent sip-plugin-unit sip-termination)	type of the alarms that are active <i>This element is only shown in detail mode.</i>

101 query current alarms by filters

name	Type	Description
	e1-sip-termination filetransfer external-device l2forward ether-tca ether-sfp megaco-media-gw megaco-sig-gw megaco-plug-unit megaco-term megaco-sig-lt eqpt-supplemental eqpt-holder-ext lsmredundancy sync mcsrc vlanport vect-line vect-board otdr sip-dial-plan sip-vsp sip-server bgp rip lag ihub-general vprn isis ospf ihub-l2forward vpls ihub-equip ihub-link eont-phyoam ellid epon eont-services-lan eolt-ont-tca eont-sw-dl ldp mpls sdp epipe ihub-ipv6 pim li mgmt-sec-access bfd ai tr069serv ontsnmp bulk-sync protection-group ont sfu-sup soho-sup	

name	Type	Description
	mdu-sup ont-ani sfu-sup2 soho-sup2 mdu-sup2 sfprssi eoltrssi cfm sfpe1t1-framer sfpe1t1-clock pppcc-engine-tca eth-cfm rsvp ihub-tca eth-ring efm-oam ont-loopdetect ont-video ont-ces ont-voip ont-video-ani ont-pwe ont-cese1 ont-xdsl ont-xdsl-tca ont-hpna ont-sip-agent-cfg ont-voip-cfg ont-mgc ont-ploam ont-gen ont-card ont-pots ont-lan ont-moca ont-tc-tca ont-moca-tca ont-l2uni-eth-tca olt-pon-tc-tca olt-pon-util-tca olt-chpr-util-tca olt-ont-tc-tca ont-tca ont-pots-supplemental sfu-ploam sfu-gen soho-ploam soho-gen mdu-ploam mdu-gen ont-veip ont-iphost alarm-table auto-switch channel-pair ont-cfg-dld olt-chpair-tc-tca	

101 query current alarms by filters

name	Type	Description
	hgu-tr069 eqpt-psu ont-protection secondary-megaco-term secondary-sip-term cas-r2-channel lldpmed pseudo-wire link-agg fcs-exceed e1t1-interface) Possible values: - equipment : equipment alarms - eqpt-holder : equipment holder alarms - plug-in-unit : plugin unit alarms - atm : ATM alarms - custom : customizable alarms - e1 : e1 alarms - ima-group : ima-group alarms - ima-link : ima-link alarms - redundancy : redundancy alarms - shdsl : shdsl alarms - ether-itf : ethernet interface alarms - traffic-overflow : Traffic overflow alarms - qos-queue : qos queue alarms - temporal : temporal alarms - spatial : spatial alarms - software-mngt : software management alarms - sw-mgmt : software management alarms - xdsl : xDSL alarms - xdsl-ext : other xDSL alarms - xdsl-tca : xDSL threshold cross alarms - olt-gen : OLT general alarms - eo-conv : E/O conversion related alarms - authentication : authentication related alarms - bonding : bonding-group related alarms - sfp : SFP related alarms - shdsl-isam : shdsl isam alarms - custom-ext-alarm : customizable external alarms - plug-in-unit-ext : other plugin unit alarms - sip-user-agent : sip user agent related alarms - sip-plugin-unit : sip plug in unit related alarms - sip-termination : sip termination related alarms - e1-sip-termination : E1 sip termination related alarms - filetransfer : file transfer server alarms - external-device : external device related alarms - l2forward : l2forward related alarms - ether-tca : ethernet threshold cross alarms - ether-sfp : ethernet SFP related alarms - megaco-media-gw : megaco media gateway related alarms - megaco-sig-gw : megaco signaling gateway related alarms - megaco-plug-unit : megaco plug unit related alarms - megaco-term : megaco termination related alarms - megaco-sig-lt : megaco signaling lt related alarms - eqpt-supplemental : equipment supplemental alarms - eqpt-holder-ext : other equipment holder alarms - lsmredundancy : lsm redundancy alarms	

name	Type	Description
	- sync : synce and bits alarms - mcsrc : multicast source alarms - vlanport : vlanport alarms - vect-line : xDSL vectoring line alarms - vect-board : xDSL vectoring board alarms - otdr : otdr alarms - sip-dial-plan : sip dial plan related alarms - sip-vsp : sip vsp related alarms - sip-server : sip server related alarms - bgp : bgp related alarms - rip : rip related alarms - lag : LAG related alarms - ihub-general : IHUB general related alarms - vprn : vprn related alarms - isis : isis related alarms - ospf : ospf related alarms - ihub-l2forward : ihub-l2forward alarms - vpls : vpls related alarms - ihub-equip : ihub-equip related alarms - ihub-link : ihub-link related alarms - eont-phyoam : eont phyoam related alarms - ellid : ellid related alarms - epon : epon related alarms - eont-services-lan : eon phyoam related alarms - eolt-ont-tca : eon phyoam related alarms - eont-sw-dl : eon phyoam related alarms - ldp : ldp related alarms - mpls : mpls related alarms - sdp : sdp related alarms - epipe : epipe related alarms - ihub-ipv6 : ihub-ipv6 related alarms - pim : pim related alarms - li : lawful intercept related alarms - mgmt-sec-access : management security related alarms - bfd : bfd related alarms - ai : Application Intelligence related alarms - tr069serv : tr069 server related alarms - ontsnmp : ont snmp related alarms - bulk-sync : bulk-sync related alarms - protection-group : port protection group related alarms - ont : ONT general supplemental related alarms - sfu-sup : SFU ONT general supplemental related alarms - soho-sup : SOHO ONT general supplemental related alarms - mdv-sup : MDU ONT general supplemental related alarms - ont-ani : ONT general supplemental 2 related alarms - sfu-sup2 : SFU ONT general supplemental 2 related alarms - soho-sup2 : SOHO ONT general supplemental 2 related alarms - mdv-sup2 : MDU ONT general supplemental 2 related alarms - sfprssi : SFP RSSI related alarms - eoltrssi : epon olt Sfp RSSI related alarms - cfm : Cfm related alarms - sfpe1t1-framer : SFP 2e1t1 framer alarms - sfpe1t1-clock : SFP 2e1t1 clock alarms - pppcc-engine-tca : PPPOE Cross Connect Engine TCA	

101 query current alarms by filters

name	Type	Description
	related alarm - eth-cfm : eth-cfm related alarms - rsvp : rsvp related alarms - ihub-tca : IHUB TCA related alarms - eth-ring : eth-ring related alarms - efm-oam : EFM-OAM related alarms - ont-loopdetect : ont loop detect related alarms - ont-video : ont services video related alarms - ont-ces : ont services ces related alarms - ont-voip : ont services voip related alarms - ont-video-ani : ont services video ani related alarms - ont-pwe : ont services pwe related alarms - ont-cese1 : ont services cese1 related alarms - ont-xdsl : ont services xdsl related alarms - ont-xdsl-tca : ont services xdsl tca related alarms - ont-hpna : ont hpna related alarms - ont-sip-agent-cfg : ont services voip sip agent config related alarms - ont-voip-cfg : ont services voip config related alarms - ont-mgc : ont mgc related alarms - ont-ploam : ONT PLOAM related alarms - ont-gen : ONT GENERAL related alarms - ont-card : ONT Subscriber Card related alarms - ont-pots : ONT Services POTS related alarms - ont-lan : ONT Services LAN related alarms - ont-moca : ONT MoCA related alarms - ont-tc-tca : ONT TC TCA related alarms - ont-moca-tca : ONT MoCA TCA related alarms - ont-l2uni-eth-tca : ONT L2 UNI Ethernet TCA related alarms - olt-pon-tc-tca : OLT PON TC TCA related alarms - olt-pon-util-tca : OLT PON utilization TCA related alarms - olt-chpr-util-tca : OLT channel-pair utilization TCA related alarms - olt-ont-tc-tca : OLT ONT TC TCA related alarms - ont-tca : ONT TCA related alarms - ont-pots-supplemental : ONT POTS Supplemental related alarms - sfu-ploam : SFU ONT PLOAM related alarms - sfu-gen : SFU ONT general related alarms - soho-ploam : SOHO ONT PLOAM related alarms - soho-gen : SOHO ONT general related alarms - mdu-ploam : MDU ONT PLOAM related alarms - mdu-gen : MDU ONT general related alarms - ont-veip : ONT VEIP related alarms - ont-iphost : ONT IP HOST related alarms - alarm-table : alarm table related alarms - auto-switch : auto-switch related alarms - channel-pair : channel pair related alarms - ont-cfg-dld : ont configure file download related alarms - olt-chpair-tc-tca : OLT CHANNELPAIR TC TCA related alarms - hgu-tr069 : hgu tr069 related alarms - eqpt-psu : equipment psu alarms - ont-protection : ONT protection related alarms - secondary-megaco-term : secondary megaco termination related alarms	

name	Type	Description
	- secondary-sip-term : secondary sip termination related alarms - cas-r2-channel : CAS R2 channel related alarms - lldpmed : lldpmed alarms - pseudo-wire : pseudo Wire related alarms - link-agg : Link aggregation related alarms - fcs-exceed : FCS auto-recovery related alarms - e1t1-interface : E1/T1 physical interfaces related alarms	
name	Parameter type: <Alarm::almtypeSfploamihub> (sfu-ploam-loss-sig sfu-ploam-loss-ack sfu-ploam-loss-cd sfu-ploam-phy-eqpt-err sfu-ploam-startup-fail sfu-ploam-sig-degrade sfu-ploam-disabled sfu-ploam-err-msg sfu-ploam-inactive sfu-ploam-sig-fail sfu-ploam-dying-gasp sfu-ploam-deact-fail sfu-ploam-oam sfu-ploam-win-drift sfu-ploam-rdi sfu-ploam-loss-ks sfu-ploam-pwr-burst sfu-ploam-rog-disa sfu-ploam-diff-reach sfu-ploam-looc all) Possible values: - sfu-ploam-loss-sig : SFU ONT - loss of signal at ont - sfu-ploam-loss-ack : SFU ONT - loss of acknowledge from ont - sfu-ploam-loss-cd : SFU ONT - loss of channel delineation of ont - sfu-ploam-phy-eqpt-err: SFU ONT - physical equipment error of ont - sfu-ploam-startup-fail: SFU ONT - startup failure in ranging of ont - sfu-ploam-sig-degrade : SFU ONT - signal degrade from ont - sfu-ploam-disabled : SFU ONT - ont disabled alarm - sfu-ploam-err-msg : SFU ONT - error message from ont - sfu-ploam-inactive : SFU ONT - inactive ont - sfu-ploam-sig-fail : SFU ONT - signal fail alarm from ont - sfu-ploam-dying-gasp : SFU ONT - dying gasp alarm from ont - sfu-ploam-deact-fail : SFU ONT - deactive failure of ont - sfu-ploam-oam : SFU ONT - loss of ploam for ont - sfu-ploam-win-drift : SFU ONT - drift of window alarm - sfu-ploam-rdi : SFU ONT - remote defect indication alarm - sfu-ploam-loss-ks : SFU ONT - loss of key synchronization alarm - sfu-ploam-pwr-burst : SFU ONT - power bursts on ont - sfu-ploam-rog-disa : SFU ONT - ont rogue disabled - sfu-ploam-diff-reach : SFU ONT - ont differential reach	alarm name that are active <i>This element is only shown in detail mode.</i>

101 query current alarms by filters

name	Type	Description
	exceeded - sfu-ploam-looc : SFU ONT - Loss of OMCI channel due to persistent MIC failure - all : SFU ONT PLOAM related alarms	
severity	Parameter type: <Alarm::AlarmSeverity> (indeterminate warning minor major critical) Possible values: - indeterminate : alarm severity is indeterminate - warning : alarm severity is warning - minor : alarm severity is minor - major : alarm severity is major - critical : alarm severity is critical	the alarms severity level <i>This element is only shown in detail mode.</i>
servaff	Parameter type: <Alarm::alarmServAffect> ((service-affecting yes) (noservice-affecting no)) Possible values: - service-affecting : make this alarm service affecting - yes : make this alarm service affecting - noservice-affecting : make this alarm not service affecting - no : make this alarm not service affecting	alarms affect service or not <i>This element is only shown in detail mode.</i>
time	Parameter type: <Sys::timeInSecs> - the time (yyyy-mm-dd:hour:minutes:secs) - unit: UTC	time in seconds when alarm was updated <i>This element is only shown in detail mode.</i>
descript	Parameter type: <Alarm::AddInfoString> - additional alarm information	alarm description <i>This element is only shown in detail mode.</i>

101.94 show current alarm by filters

Command Description

show current alarms by filters

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm query sfu-gen [ (name) [ severity <Alarm::querySeverity> ] [ servaff <Alarm::queryServAffect> ] [ ont <Gpon::OntIndex> ] ]
```

Command Parameters

Table 101.94-1 "show current alarm by filters" Resource Parameters

Resource Identifier	Type	Description
(name)	Format: (sfu-gen-omci-fail sfu-gen-eqpt-selftest sfu-gen-ac-pwr-fail sfu-gen-bat-missing sfu-gen-bat-low sfu-gen-bat-fail sfu-gen-sw-dnload-f sfu-gen-sw-dnload-p sfu-gen-sw-act-fail sfu-gen-eqpt-vers-mis sfu-gen-sw-vers-mis sfu-gen-us-rate-mis sfu-gen-tune-fail sfu-gen-nw-time-err sfu-gen-opt-sig-high sfu-gen-opt-sig-low sfu-gen-eqpt-prov-sa sfu-gen-eqpt-prov-nsa all) Possible values: - sfu-gen-omci-fail : SFU ONT - loss of communication - sfu-gen-eqpt-selftest : SFU ONT - ont self-test failure - sfu-gen-ac-pwr-fail : SFU ONT - ac power failure on ont - sfu-gen-bat-missing : SFU ONT - battery missing - sfu-gen-bat-low : SFU ONT - battery low - sfu-gen-bat-fail : SFU ONT - battery failure - sfu-gen-sw-dnload-f : SFU ONT - ont sw download failure	alarm name of sfu-gen

101 query current alarms by filters

Resource Identifier	Type	Description
	- sfu-gen-sw-dnload-p : SFU ONT - ont sw download in progress - sfu-gen-sw-act-fail : SFU ONT - ont sw activation failure - sfu-gen-eqpt-vers-mis : SFU ONT - ont equipment version mismatch - sfu-gen-sw-vers-mis : SFU ONT - ont sw version mismatch - sfu-gen-us-rate-mis : SFU ONT - ont upstream rate mismatch - sfu-gen-tune-fail : SFU ONT - ont has failed to tune to Target-ChnlPair - sfu-gen-nw-time-err : SFU ONT - network timing protocol error - sfu-gen-opt-sig-high : SFU ONT - optical signal level too high - sfu-gen-opt-sig-low : SFU ONT - optical signal level too low - sfu-gen-eqpt-prov-sa : SFU ONT - service affecting mismatch btw equipment and provisioning attributes - sfu-gen-eqpt-prov-nsa : SFU ONT - non service affecting mismatch btw equipment and provisioning attributes - all : SFU ONT general related alarm	
severity	Parameter type: <Alarm::querySeverity> Format: (indeterminate warning minor major critical all) Possible values: - indeterminate : alarm severity is indeterminate - warning : alarm severity is warning - minor : alarm severity is minor - major : alarm severity is major - critical : alarm severity is critical - all : all alarm severity	severity level of an alarm for reporting
servaff	Parameter type: <Alarm::queryServAffect> Format: (service-affecting noservice-affecting all) Possible values: - service-affecting : query alarm service affecting - noservice-affecting : query alarm not service affecting - all : query service affecting and not affecting alarms	serviceaffecting no serviceaffecting
ont	Parameter type: <Gpon::OntIndex> Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> ng2 : <Ng2::ChannelGroup> / <Ng2::SubchannelGroup> / <Ng2::OntId>) Possible values: - ng2 : ngpon2 style identification Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId>	gpon ont equipment ifindex

Resource Identifier	Type	Description
	- the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Ng2::ChannelGroup> - channel group number Field type <Ng2::SubchannelGroup> - subchannel group number Field type <Eqpt::OntId> - the ONT identifier Field type <Ng2::OntId> - the ONT identifier	

Command Output

Table 101.94-2 "show current alarm by filters" Display parameters

Specific Information		
name	Type	Description
aidinfo	Parameter type: <Alarm::AddInfoString> - additional alarm information	alarm AID parameters <i>This element is only shown in detail mode.</i>
type	Parameter type: <Alarm::alarmIHUBType> (equipment eqpt-holder plug-in-unit atm custom e1 ima-group ima-link redundancy shdsl ether-itf traffic-overflow qos-queue temporal spatial (software-mngt sw-mgmt) xdsl xdsl-ext xdsl-tca olt-gen eo-conv authentication bonding sfp shdsl-isam custom-ext-alarm plug-in-unit-ext sip-user-agent sip-plugin-unit sip-termination e1-sip-termination filetransfer external-device)	type of the alarms that are active <i>This element is only shown in detail mode.</i>

101 query current alarms by filters

name	Type	Description
	l2forward	
	ether-tca	
	ether-sfp	
	megaco-media-gw	
	megaco-sig-gw	
	megaco-plug-unit	
	megaco-term	
	megaco-sig-lt	
	eqpt-supplemental	
	eqpt-holder-ext	
	lsmredundancy	
	sync	
	mcsrc	
	vlanport	
	vect-line	
	vect-board	
	otdr	
	sip-dial-plan	
	sip-vsp	
	sip-server	
	bgp	
	rip	
	lag	
	ihub-general	
	vprn	
	isis	
	ospf	
	ihub-l2forward	
	vpls	
	ihub-equip	
	ihub-link	
	eont-phyoam	
	ellid	
	epon	
	eont-services-lan	
	eolt-ont-tca	
	eont-sw-dl	
	ldp	
	mpls	
	sdp	
	epipe	
	ihub-ipv6	
	pim	
	li	
	mgmt-sec-access	
	bfd	
	ai	
	tr069serv	
	ontsnmp	
	bulk-sync	
	protection-group	
	ont	
	sfu-sup	
	soho-sup	
	mdu-sup	
	ont-ani	
	sfu-sup2	

name	Type	Description
	soho-sup2	
	mdu-sup2	
	sfprssi	
	eoltrssi	
	cfm	
	sfpe1t1-framer	
	sfpe1t1-clock	
	pppcc-engine-tca	
	eth-cfm	
	rsvp	
	ihub-tca	
	eth-ring	
	efm-oam	
	ont-loopdetect	
	ont-video	
	ont-ces	
	ont-voip	
	ont-video-ani	
	ont-pwe	
	ont-cese1	
	ont-xdsl	
	ont-xdsl-tca	
	ont-hpna	
	ont-sip-agent-cfg	
	ont-voip-cfg	
	ont-mgc	
	ont-ploam	
	ont-gen	
	ont-card	
	ont-pots	
	ont-lan	
	ont-moca	
	ont-tc-tca	
	ont-moca-tca	
	ont-l2uni-eth-tca	
	olt-pon-tc-tca	
	olt-pon-util-tca	
	olt-chpr-util-tca	
	olt-ont-tc-tca	
	ont-tca	
	ont-pots-supplemental	
	sfu-ploam	
	sfu-gen	
	soho-ploam	
	soho-gen	
	mdu-ploam	
	mdu-gen	
	ont-veip	
	ont-iphost	
	alarm-table	
	auto-switch	
	channel-pair	
	ont-cfg-dld	
	olt-chpair-tc-tca	
	hgu-tr069	
	eqpt-psu	
	ont-protection	

101 query current alarms by filters

name	Type	Description
	secondary-megaco-term secondary-sip-term cas-r2-channel lldpmed pseudo-wire link-agg fcs-exceed e1t1-interface) Possible values: - equipment : equipment alarms - eqpt-holder : equipment holder alarms - plug-in-unit : plugin unit alarms - atm : ATM alarms - custom : customizable alarms - e1 : e1 alarms - ima-group : ima-group alarms - ima-link : ima-link alarms - redundancy : redundancy alarms - shdsl : shdsl alarms - ether-itf : ethernet interface alarms - traffic-overflow : Traffic overflow alarms - qos-queue : qos queue alarms - temporal : temporal alarms - spatial : spatial alarms - software-mngt : software management alarms - sw-mgmt : software management alarms - xdsl : xDSL alarms - xdsl-ext : other xDSL alarms - xdsl-tca : xDSL threshold cross alarms - olt-gen : OLT general alarms - eo-conv : E/O conversion related alarms - authentication : authentication related alarms - bonding : bonding-group related alarms - sfp : SFP related alarms - shdsl-isam : shdsl isam alarms - custom-ext-alarm : customizable external alarms - plug-in-unit-ext : other plugin unit alarms - sip-user-agent : sip user agent related alarms - sip-plugin-unit : sip plug in unit related alarms - sip-termination : sip termination related alarms - e1-sip-termination : E1 sip termination related alarms - filetransfer : file transfer server alarms - external-device : external device related alarms - l2forward : l2forward related alarms - ether-tca : ethernet threshold cross alarms - ether-sfp : ethernet SFP related alarms - megaco-media-gw : megaco media gateway related alarms - megaco-sig-gw : megaco signaling gateway related alarms - megaco-plug-unit : megaco plug unit related alarms - megaco-term : megaco termination related alarms - megaco-sig-lt : megaco signaling lt related alarms - eqpt-supplemental : equipment supplemental alarms - eqpt-holder-ext : other equipment holder alarms - lsmredundancy : lsm redundancy alarms - sync : synce and bits alarms - mcsrc : multicast source alarms - vlanport : vlanport alarms	

name	Type	Description
	- vect-line : xDSL vectoring line alarms - vect-board : xDSL vectoring board alarms - otdr : otdr alarms - sip-dial-plan : sip dial plan related alarms - sip-vsp : sip vsp related alarms - sip-server : sip server related alarms - bgp : bgp related alarms - rip : rip related alarms - lag : LAG related alarms - ihub-general : IHUB general related alarms - vprn : vprn related alarms - isis : isis related alarms - ospf : ospf related alarms - ihub-l2forward : ihub-l2forward alarms - vpls : vpls related alarms - ihub-equip : ihub-equip related alarms - ihub-link : ihub-link related alarms - eont-phyoam : eont phyoam related alarms - ellid : ellid related alarms - epon : epon related alarms - eont-services-lan : eon phyoam related alarms - eolt-ont-tca : eon phyoam related alarms - eont-sw-dl : eon phyoam related alarms - ldp : ldp related alarms - mpls : mpls related alarms - sdp : sdp related alarms - epipe : epipe related alarms - ihub-ipv6 : ihub-ipv6 related alarms - pim : pim related alarms - li : lawful intercept related alarms - mgmt-sec-access : management security related alarms - bfd : bfd related alarms - ai : Application Intelligence related alarms - tr069serv : tr069 server related alarms - ontsnmp : ont snmp related alarms - bulk-sync : bulk-sync related alarms - protection-group : port protection group related alarms - ont : ONT general supplemental related alarms - sfu-sup : SFU ONT general supplemental related alarms - soho-sup : SOHO ONT general supplemental related alarms - mdu-sup : MDU ONT general supplemental related alarms - ont-ani : ONT general supplemental 2 related alarms - sfu-sup2 : SFU ONT general supplemental 2 related alarms - soho-sup2 : SOHO ONT general supplemental 2 related alarms - mdu-sup2 : MDU ONT general supplemental 2 related alarms - sfprssi : SFP RSSI related alarms - eoltrssi : epon olt Sfp RSSI related alarms - cfm : Cfm related alarms - sfpe1t1-framer : SFP 2e1t1 framer alarms - sfpe1t1-clock : SFP 2e1t1 clock alarms - pppcc-engine-tca : PPPOE Cross Connect Engine TCA related alarm - eth-cfm : eth-cfm related alarms - rsvp : rsvp related alarms	

101 query current alarms by filters

name	Type	Description
	- ihub-tca : IHUB TCA related alarms - eth-ring : eth-ring related alarms - efm-oam : EFM-OAM related alarms - ont-loopdetect : ont loop detect related alarms - ont-video : ont services video related alarms - ont-ces : ont services ces related alarms - ont-voip : ont services voip related alarms - ont-video-ani : ont services video ani related alarms - ont-pwe : ont services pwe related alarms - ont-cese1 : ont services cese1 related alarms - ont-xdsl : ont services xdsl related alarms - ont-xdsl-tca : ont services xdsl tca related alarms - ont-hpna : ont hpna related alarms - ont-sip-agent-cfg : ont services voip sip agent config related alarms - ont-voip-cfg : ont services voip config related alarms - ont-mgc : ont mgc related alarms - ont-ploam : ONT PLOAM related alarms - ont-gen : ONT GENERAL related alarms - ont-card : ONT Subscriber Card related alarms - ont-pots : ONT Services POTS related alarms - ont-lan : ONT Services LAN related alarms - ont-moca : ONT MoCA related alarms - ont-tc-tca : ONT TC TCA related alarms - ont-moca-tca : ONT MoCA TCA related alarms - ont-l2uni-eth-tca : ONT L2 UNI Ethernet TCA related alarms - olt-pon-tc-tca : OLT PON TC TCA related alarms - olt-pon-util-tca : OLT PON utilization TCA related alarms - olt-chpr-util-tca : OLT channel-pair utilization TCA related alarms - olt-ont-tc-tca : OLT ONT TC TCA related alarms - ont-tca : ONT TCA related alarms - ont-pots-supplemental : ONT POTS Supplemental related alarms - sfu-ploam : SFU ONT PLOAM related alarms - sfu-gen : SFU ONT general related alarms - soho-ploam : SOHO ONT PLOAM related alarms - soho-gen : SOHO ONT general related alarms - mdu-ploam : MDU ONT PLOAM related alarms - mdu-gen : MDU ONT general related alarms - ont-veip : ONT VEIP related alarms - ont-iphost : ONT IP HOST related alarms - alarm-table : alarm table related alarms - auto-switch : auto-switch related alarms - channel-pair : channel pair related alarms - ont-cfg-dld : ont configure file download related alarms - olt-chpair-tc-tca : OLT CHANNELPAIR TC TCA related alarms - hgu-tr069 : hgu tr069 related alarms - eqpt-psu : equipment psu alarms - ont-protection : ONT protection related alarms - secondary-megaco-term : secondary megaco termination related alarms - secondary-sip-term : secondary sip termination related alarms - cas-r2-channel : CAS R2 channel related alarms	

name	Type	Description
	- lldpmed : lldpmed alarms - pseudo-wire : pseudo Wire related alarms - link-aggr : Link aggregation related alarms - fcs-exceed : FCS auto-recovery related alarms - e1t1-interface : E1/T1 physical interfaces related alarms	
name	Parameter type: <Alarm::almtypeSfugenihub> (sfu-gen-omci-fail sfu-gen-eqpt-selftest sfu-gen-ac-pwr-fail sfu-gen-bat-missing sfu-gen-bat-low sfu-gen-bat-fail sfu-gen-sw-dnload-f sfu-gen-sw-dnload-p sfu-gen-sw-act-fail sfu-gen-eqpt-vers-mis sfu-gen-sw-vers-mis sfu-gen-us-rate-mis sfu-gen-tune-fail sfu-gen-nw-time-err sfu-gen-opt-sig-high sfu-gen-opt-sig-low sfu-gen-eqpt-prov-sa sfu-gen-eqpt-prov-nsa all) Possible values: - sfu-gen-omci-fail : SFU ONT - loss of communication - sfu-gen-eqpt-selftest : SFU ONT - ont self-test failure - sfu-gen-ac-pwr-fail : SFU ONT - ac power failure on ont - sfu-gen-bat-missing : SFU ONT - battery missing - sfu-gen-bat-low : SFU ONT - battery low - sfu-gen-bat-fail : SFU ONT - battery failure - sfu-gen-sw-dnload-f : SFU ONT - ont sw download failure - sfu-gen-sw-dnload-p : SFU ONT - ont sw download in progress - sfu-gen-sw-act-fail : SFU ONT - ont sw activation failure - sfu-gen-eqpt-vers-mis : SFU ONT - ont equipment version mismatch - sfu-gen-sw-vers-mis : SFU ONT - ont sw version mismatch - sfu-gen-us-rate-mis : SFU ONT - ont upstream rate mismatch - sfu-gen-tune-fail : SFU ONT - ont has failed to tune to Target-ChnlPair - sfu-gen-nw-time-err : SFU ONT - network timing protocol error - sfu-gen-opt-sig-high : SFU ONT - optical signal level too high - sfu-gen-opt-sig-low : SFU ONT - optical signal level too low - sfu-gen-eqpt-prov-sa : SFU ONT - service affecting mismatch btw equipment and provisioning attributes - sfu-gen-eqpt-prov-nsa : SFU ONT - non service affecting mismatch btw equipment and provisioning attributes - all : SFU ONT general related alarm	alarm name that are active <i>This element is only shown in detail mode.</i>
severity	Parameter type: <Alarm::AlarmSeverity> (indeterminate	the alarms severity level <i>This element is only shown in</i>

101 query current alarms by filters

name	Type	Description
	warning minor major critical) Possible values: - indeterminate : alarm severity is indeterminate - warning : alarm severity is warning - minor : alarm severity is minor - major : alarm severity is major - critical : alarm severity is critical	<i>detail mode.</i>
servaff	Parameter type: <Alarm::alarmServAffect> ((service-affecting yes) (noservice-affecting no)) Possible values: - service-affecting : make this alarm service affecting - yes : make this alarm service affecting - noservice-affecting : make this alarm not service affecting - no : make this alarm not service affecting	alarms affect service or not <i>This element is only shown in detail mode.</i>
time	Parameter type: <Sys::timeInSecs> - the time (yyyy-mm-dd:hour:minutes:secs) - unit: UTC	time in seconds when alarm was updated <i>This element is only shown in detail mode.</i>
descript	Parameter type: <Alarm::AddInfoString> - additional alarm information	alarm description <i>This element is only shown in detail mode.</i>

101.95 show current alarm by filters

Command Description

show current alarms by filters

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm query soho-ploam [ (name) [ severity <Alarm::querySeverity> ] [ servaff <Alarm::queryServAffect> ] [ ont <Gpon::OntIndex> ] ]
```

Command Parameters

Table 101.95-1 "show current alarm by filters" Resource Parameters

Resource Identifier	Type	Description
(name)	Format: all Possible values: - all : SOHO ONT PLOAM related alarms	alarm name of soho-ploam
severity	Parameter type: <Alarm::querySeverity> Format: (indeterminate warning minor major critical all) Possible values: - indeterminate : alarm severity is indeterminate - warning : alarm severity is warning - minor : alarm severity is minor - major : alarm severity is major - critical : alarm severity is critical - all : all alarm severity	severity level of an alarm for reporting
servaff	Parameter type: <Alarm::queryServAffect> Format: (service-affecting noservice-affecting all) Possible values: - service-affecting : query alarm service affecting - noservice-affecting : query alarm not service affecting - all : query service affecting and not affecting alarms	serviceaffecting no

101 query current alarms by filters

Resource Identifier	Type	Description
ont	Parameter type: <Gpon::OntIndex> Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> ng2 : <Ng2::ChannelGroup> / <Ng2::SubchannelGroup> / <Ng2::OntId>) Possible values: - ng2 : ngpon2 style identification Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Ng2::ChannelGroup> - channel group number Field type <Ng2::SubchannelGroup> - subchannel group number Field type <Eqpt::OntId> - the ONT identifier Field type <Ng2::OntId> - the ONT identifier	gpon ont equipment ifindex

Command Output

Table 101.95-2 "show current alarm by filters" Display parameters

Specific Information		
name	Type	Description
aidinfo	Parameter type: <Alarm::AddInfoString> - additional alarm information	alarm AID parameters <i>This element is only shown in detail mode.</i>
type	Parameter type: <Alarm::alarmIHUBType> (equipment eqpt-holder plug-in-unit atm custom e1 ima-group ima-link redundancy shdsl ether-itf traffic-overflow qos-queue temporal spatial (software-mngt sw-mgmt) xdsl xdsl-ext xdsl-tca olt-gen eo-conv authentication	type of the alarms that are active <i>This element is only shown in detail mode.</i>

name	Type	Description
	bonding sfp shdsl-isam custom-ext-alarm plug-in-unit-ext sip-user-agent sip-plugin-unit sip-termination e1-sip-termination filetransfer external-device l2forward ether-tca ether-sfp megaco-media-gw megaco-sig-gw megaco-plug-unit megaco-term megaco-sig-lt eqpt-supplemental eqpt-holder-ext lsmredundancy sync mcsrc vlanport vect-line vect-board otdr sip-dial-plan sip-vsp sip-server bgp rip lag ihub-general vprn isis ospf ihub-l2forward vpls ihub-equip ihub-link eont-phyoam ellid epon eont-services-lan eolt-ont-tca eont-sw-dl ldp mpls sdp epipe ihub-ipv6 pim li mgmt-sec-access bfd	

101 query current alarms by filters

name	Type	Description
	ai	
	tr069serv	
	ontsnmp	
	bulk-sync	
	protection-group	
	ont	
	sfu-sup	
	soho-sup	
	mdu-sup	
	ont-ani	
	sfu-sup2	
	soho-sup2	
	mdu-sup2	
	sfprssi	
	eoltrssi	
	cfm	
	sfpe1t1-framer	
	sfpe1t1-clock	
	pppcc-engine-tca	
	eth-cfm	
	rsvp	
	ihub-tca	
	eth-ring	
	efm-oam	
	ont-loopdetect	
	ont-video	
	ont-ces	
	ont-voip	
	ont-video-ani	
	ont-pwe	
	ont-cese1	
	ont-xdsl	
	ont-xdsl-tca	
	ont-hpna	
	ont-sip-agent-cfg	
	ont-voip-cfg	
	ont-mgc	
	ont-ploam	
	ont-gen	
	ont-card	
	ont-pots	
	ont-lan	
	ont-moca	
	ont-tc-tca	
	ont-moca-tca	
	ont-l2uni-eth-tca	
	olt-pon-tc-tca	
	olt-pon-util-tca	
	olt-chpr-util-tca	
	olt-ont-tc-tca	
	ont-tca	
	ont-pots-supplemental	
	sfu-ploam	
	sfu-gen	
	soho-ploam	
	soho-gen	
	mdu-ploam	

name	Type	Description
	mdu-gen ont-veip ont-iphost alarm-table auto-switch channel-pair ont-cfg-dld olt-chpair-tc-tca hgu-tr069 eqpt-psu ont-protection secondary-megaco-term secondary-sip-term cas-r2-channel lldpmed pseudo-wire link-agg fcs-exceed e1t1-interface) Possible values: - equipment : equipment alarms - eqpt-holder : equipment holder alarms - plug-in-unit : plugin unit alarms - atm : ATM alarms - custom : customizable alarms - e1 : e1 alarms - ima-group : ima-group alarms - ima-link : ima-link alarms - redundancy : redundancy alarms - shdsl : shdsl alarms - ether-itf : ethernet interface alarms - traffic-overflow : Traffic overflow alarms - qos-queue : qos queue alarms - temporal : temporal alarms - spatial : spatial alarms - software-mngt : software management alarms - sw-mgmt : software management alarms - xdsl : xDSL alarms - xdsl-ext : other xDSL alarms - xdsl-tca : xDSL threshold cross alarms - olt-gen : OLT general alarms - eo-conv : E/O conversion related alarms - authentication : authentication related alarms - bonding : bonding-group related alarms - sfp : SFP related alarms - shdsl-isam : shdsl isam alarms - custom-ext-alarm : customizable external alarms - plug-in-unit-ext : other plugin unit alarms - sip-user-agent : sip user agent related alarms - sip-plugin-unit : sip plug in unit related alarms - sip-termination : sip termination related alarms - e1-sip-termination : E1 sip termination related alarms - filetransfer : file transfer server alarms - external-device : external device related alarms - l2forward : l2forward related alarms - ether-tca : ethernet threshold cross alarms - ether-sfp : ethernet SFP related alarms	

101 query current alarms by filters

name	Type	Description
	- megaco-media-gw : megaco media gateway related alarms - megaco-sig-gw : megaco signaling gateway related alarms - megaco-plug-unit : megaco plug unit related alarms - megaco-term : megaco termination related alarms - megaco-sig-lt : megaco signaling lt related alarms - eqpt-supplemental : equipment supplemental alarms - eqpt-holder-ext : other equipment holder alarms - lsmredundancy : lsm redundancy alarms - sync : synce and bits alarms - mcsrc : multicast source alarms - vlanport : vlanport alarms - vect-line : xDSL vectoring line alarms - vect-board : xDSL vectoring board alarms - otdr : otdr alarms - sip-dial-plan : sip dial plan related alarms - sip-vsp : sip vsp related alarms - sip-server : sip server related alarms - bgp : bgp related alarms - rip : rip related alarms - lag : LAG related alarms - ihub-general : IHUB general related alarms - vprn : vprn related alarms - isis : isis related alarms - ospf : ospf related alarms - ihub-l2forward : ihub-l2forward alarms - vpls : vpls related alarms - ihub-equip : ihub-equip related alarms - ihub-link : ihub-link related alarms - eont-phyoam : eont phyoam related alarms - ellid : ellid related alarms - epon : epon related alarms - eont-services-lan : eon phyoam related alarms - eolt-ont-tca : eon phyoam related alarms - eont-sw-dl : eon phyoam related alarms - ldp : ldp related alarms - mpls : mpls related alarms - sdp : sdp related alarms - epipe : epipe related alarms - ihub-ipv6 : ihub-ipv6 related alarms - pim : pim related alarms - li : lawful intercept related alarms - mgmt-sec-access : management security related alarms - bfd : bfd related alarms - ai : Application Intelligence related alarms - tr069serv : tr069 server related alarms - ontsnmp : ont snmp related alarms - bulk-sync : bulk-sync related alarms - protection-group : port protection group related alarms - ont : ONT general supplemental related alarms - sfu-sup : SFU ONT general supplemental related alarms - soho-sup : SOHO ONT general supplemental related alarms - mdu-sup : MDU ONT general supplemental related alarms - ont-ani : ONT general supplemental 2 related alarms - sfu-sup2 : SFU ONT general supplemental 2 related alarms - soho-sup2 : SOHO ONT general supplemental 2 related alarms	

name	Type	Description
	- mdu-sup2 : MDU ONT general supplemental 2 related alarms - sfrssi : SFP RSSI related alarms - eoltrssi : epon olt Sfp RSSI related alarms - cfm : Cfm related alarms - sfpe1t1-framer : SFP 2e1t1 framer alarms - sfpe1t1-clock : SFP 2e1t1 clock alarms - pppcc-engine-tca : PPPOE Cross Connect Engine TCA related alarm - eth-cfm : eth-cfm related alarms - rsvp : rsvp related alarms - ihub-tca : IHUB TCA related alarms - eth-ring : eth-ring related alarms - efm-oam : EFM-OAM related alarms - ont-loopdetect : ont loop detect related alarms - ont-video : ont services video related alarms - ont-ces : ont services ces related alarms - ont-voip : ont services voip related alarms - ont-video-ani : ont services video ani related alarms - ont-pwe : ont services pwe related alarms - ont-cese1 : ont services cese1 related alarms - ont-xdsl : ont services xdsl related alarms - ont-xdsl-tca : ont services xdsl tca related alarms - ont-hpna : ont hpna related alarms - ont-sip-agent-cfg : ont services voip sip agent config related alarms - ont-voip-cfg : ont services voip config related alarms - ont-mgc : ont mgc related alarms - ont-ploam : ONT PLOAM related alarms - ont-gen : ONT GENERAL related alarms - ont-card : ONT Subscriber Card related alarms - ont-pots : ONT Services POTS related alarms - ont-lan : ONT Services LAN related alarms - ont-moca : ONT MoCA related alarms - ont-tc-tca : ONT TC TCA related alarms - ont-moca-tca : ONT MoCA TCA related alarms - ont-l2uni-eth-tca : ONT L2 UNI Ethernet TCA related alarms - olt-pon-tc-tca : OLT PON TC TCA related alarms - olt-pon-util-tca : OLT PON utilization TCA related alarms - olt-chpr-util-tca : OLT channel-pair utilization TCA related alarms - olt-ont-tc-tca : OLT ONT TC TCA related alarms - ont-tca : ONT TCA related alarms - ont-pots-supplemental : ONT POTS Supplemental related alarms - sfu-ploam : SFU ONT PLOAM related alarms - sfu-gen : SFU ONT general related alarms - soho-ploam : SOHO ONT PLOAM related alarms - soho-gen : SOHO ONT general related alarms - mdu-ploam : MDU ONT PLOAM related alarms - mdu-gen : MDU ONT general related alarms - ont-veip : ONT VEIP related alarms - ont-iphost : ONT IP HOST related alarms - alarm-table : alarm table related alarms - auto-switch : auto-switch related alarms - channel-pair : channel pair related alarms	

101 query current alarms by filters

name	Type	Description
	- ont-cfg-dld : ont configure file download related alarms - olt-chpair-tc-tca : OLT CHANNELPAIR TC TCA related alarms - hgu-tr069 : hgu tr069 related alarms - eqpt-psu : equipment psu alarms - ont-protection : ONT protection related alarms - secondary-megaco-term : secondary megaco termination related alarms - secondary-sip-term : secondary sip termination related alarms - cas-r2-channel : CAS R2 channel related alarms - lldpmed : lldpmed alarms - pseudo-wire : pseudo Wire related alarms - link-agg : Link aggregation related alarms - fcs-exceed : FCS auto-recovery related alarms - e1t1-interface : E1/T1 physical interfaces related alarms	
name	Parameter type: <Alarm::almtypeSohoploamihub> all Possible values: - all : SOHO ONT PLOAM related alarms	alarm name that are active <i>This element is only shown in detail mode.</i>
severity	Parameter type: <Alarm::AlarmSeverity> (indeterminate warning minor major critical) Possible values: - indeterminate : alarm severity is indeterminate - warning : alarm severity is warning - minor : alarm severity is minor - major : alarm severity is major - critical : alarm severity is critical	the alarms severity level <i>This element is only shown in detail mode.</i>
servaff	Parameter type: <Alarm::alarmServAffect> ((service-affecting yes) (noservice-affecting no)) Possible values: - service-affecting : make this alarm service affecting - yes : make this alarm service affecting - noservice-affecting : make this alarm not service affecting - no : make this alarm not service affecting	alarms affect service or not <i>This element is only shown in detail mode.</i>
time	Parameter type: <Sys::timeInSecs> - the time (yyyy-mm-dd:hour:minutes:secs) - unit: UTC	time in seconds when alarm was updated <i>This element is only shown in detail mode.</i>
descript	Parameter type: <Alarm::AddInfoString> - additional alarm information	alarm description <i>This element is only shown in detail mode.</i>

101.96 show current alarm by filters

Command Description

show current alarms by filters

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm query soho-gen [ (name) [ severity <Alarm::querySeverity> ] [ servaff <Alarm::queryServAffect> ] [
ont <Gpon::OntIndex> ] ]
```

Command Parameters

Table 101.96-1 "show current alarm by filters" Resource Parameters

Resource Identifier	Type	Description
(name)	Format: all Possible values: - all : SOHO ONT general related alarms	alarm name of soho-gen
severity	Parameter type: <Alarm::querySeverity> Format: (indeterminate warning minor major critical all) Possible values: - indeterminate : alarm severity is indeterminate - warning : alarm severity is warning - minor : alarm severity is minor - major : alarm severity is major - critical : alarm severity is critical - all : all alarm severity	severity level of an alarm for reporting
servaff	Parameter type: <Alarm::queryServAffect> Format: (service-affecting noservice-affecting all) Possible values: - service-affecting : query alarm service affecting - noservice-affecting : query alarm not service affecting - all : query service affecting and not affecting alarms	serviceaffecting no serviceaffecting

101 query current alarms by filters

Resource Identifier	Type	Description
ont	Parameter type: <Gpon::OntIndex> Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> ng2 : <Ng2::ChannelGroup> / <Ng2::SubchannelGroup> / <Ng2::OntId>) Possible values: - ng2 : ngpon2 style identification Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Ng2::ChannelGroup> - channel group number Field type <Ng2::SubchannelGroup> - subchannel group number Field type <Eqpt::OntId> - the ONT identifier Field type <Ng2::OntId> - the ONT identifier	gpon ont equipment ifindex

Command Output

Table 101.96-2 "show current alarm by filters" Display parameters

Specific Information		
name	Type	Description
aidinfo	Parameter type: <Alarm::AddInfoString> - additional alarm information	alarm AID parameters <i>This element is only shown in detail mode.</i>
type	Parameter type: <Alarm::alarmIHUBType> (equipment eqpt-holder plug-in-unit atm custom e1 ima-group ima-link redundancy shdsl ether-itf traffic-overflow qos-queue temporal spatial (software-mngt sw-mgmt) xdsl xdsl-ext xdsl-tca olt-gen eo-conv authentication	type of the alarms that are active <i>This element is only shown in detail mode.</i>

name	Type	Description
	bonding sfp shdsl-isam custom-ext-alarm plug-in-unit-ext sip-user-agent sip-plugin-unit sip-termination e1-sip-termination filetransfer external-device l2forward ether-tca ether-sfp megaco-media-gw megaco-sig-gw megaco-plug-unit megaco-term megaco-sig-lt eqpt-supplemental eqpt-holder-ext lsmredundancy sync mcsrc vlanport vect-line vect-board otdr sip-dial-plan sip-vsp sip-server bgp rip lag ihub-general vprn isis ospf ihub-l2forward vpls ihub-equip ihub-link eont-phyoam ellid epon eont-services-lan eolt-ont-tca eont-sw-dl ldp mpls sdp epipe ihub-ipv6 pim li mgmt-sec-access bfd	

101 query current alarms by filters

name	Type	Description
	ai	
	tr069serv	
	ontsnmp	
	bulk-sync	
	protection-group	
	ont	
	sfu-sup	
	soho-sup	
	mdu-sup	
	ont-ani	
	sfu-sup2	
	soho-sup2	
	mdu-sup2	
	sfprssi	
	eoltrssi	
	cfm	
	sfpe1t1-framer	
	sfpe1t1-clock	
	pppcc-engine-tca	
	eth-cfm	
	rsvp	
	ihub-tca	
	eth-ring	
	efm-oam	
	ont-loopdetect	
	ont-video	
	ont-ces	
	ont-voip	
	ont-video-ani	
	ont-pwe	
	ont-cese1	
	ont-xdsl	
	ont-xdsl-tca	
	ont-hpna	
	ont-sip-agent-cfg	
	ont-voip-cfg	
	ont-mgc	
	ont-ploam	
	ont-gen	
	ont-card	
	ont-pots	
	ont-lan	
	ont-moca	
	ont-tc-tca	
	ont-moca-tca	
	ont-l2uni-eth-tca	
	olt-pon-tc-tca	
	olt-pon-util-tca	
	olt-chpr-util-tca	
	olt-ont-tc-tca	
	ont-tca	
	ont-pots-supplemental	
	sfu-ploam	
	sfu-gen	
	soho-ploam	
	soho-gen	
	mdu-ploam	

name	Type	Description
	mdu-gen ont-veip ont-iphost alarm-table auto-switch channel-pair ont-cfg-dld olt-chpair-tc-tca hgu-tr069 eqpt-psu ont-protection secondary-megaco-term secondary-sip-term cas-r2-channel lldpmed pseudo-wire link-agg fcs-exceed e1t1-interface) Possible values: - equipment : equipment alarms - eqpt-holder : equipment holder alarms - plug-in-unit : plugin unit alarms - atm : ATM alarms - custom : customizable alarms - e1 : e1 alarms - ima-group : ima-group alarms - ima-link : ima-link alarms - redundancy : redundancy alarms - shdsl : shdsl alarms - ether-itf : ethernet interface alarms - traffic-overflow : Traffic overflow alarms - qos-queue : qos queue alarms - temporal : temporal alarms - spatial : spatial alarms - software-mngt : software management alarms - sw-mgmt : software management alarms - xdsl : xDSL alarms - xdsl-ext : other xDSL alarms - xdsl-tca : xDSL threshold cross alarms - olt-gen : OLT general alarms - eo-conv : E/O conversion related alarms - authentication : authentication related alarms - bonding : bonding-group related alarms - sfp : SFP related alarms - shdsl-isam : shdsl isam alarms - custom-ext-alarm : customizable external alarms - plug-in-unit-ext : other plugin unit alarms - sip-user-agent : sip user agent related alarms - sip-plugin-unit : sip plug in unit related alarms - sip-termination : sip termination related alarms - e1-sip-termination : E1 sip termination related alarms - filetransfer : file transfer server alarms - external-device : external device related alarms - l2forward : l2forward related alarms - ether-tca : ethernet threshold cross alarms - ether-sfp : ethernet SFP related alarms	

101 query current alarms by filters

name	Type	Description
	- megaco-media-gw : megaco media gateway related alarms - megaco-sig-gw : megaco signaling gateway related alarms - megaco-plug-unit : megaco plug unit related alarms - megaco-term : megaco termination related alarms - megaco-sig-lt : megaco signaling lt related alarms - eqpt-supplemental : equipment supplemental alarms - eqpt-holder-ext : other equipment holder alarms - lsmredundancy : lsm redundancy alarms - sync : synce and bits alarms - mcsrc : multicast source alarms - vlanport : vlanport alarms - vect-line : xDSL vectoring line alarms - vect-board : xDSL vectoring board alarms - otdr : otdr alarms - sip-dial-plan : sip dial plan related alarms - sip-vsp : sip vsp related alarms - sip-server : sip server related alarms - bgp : bgp related alarms - rip : rip related alarms - lag : LAG related alarms - ihub-general : IHUB general related alarms - vprn : vprn related alarms - isis : isis related alarms - ospf : ospf related alarms - ihub-l2forward : ihub-l2forward alarms - vpls : vpls related alarms - ihub-equip : ihub-equip related alarms - ihub-link : ihub-link related alarms - eont-phyoam : eont phyoam related alarms - ellid : ellid related alarms - epon : epon related alarms - eont-services-lan : eon phyoam related alarms - eolt-ont-tca : eon phyoam related alarms - eont-sw-dl : eon phyoam related alarms - ldp : ldp related alarms - mpls : mpls related alarms - sdp : sdp related alarms - epipe : epipe related alarms - ihub-ipv6 : ihub-ipv6 related alarms - pim : pim related alarms - li : lawful intercept related alarms - mgmt-sec-access : management security related alarms - bfd : bfd related alarms - ai : Application Intelligence related alarms - tr069serv : tr069 server related alarms - ontsnmp : ont snmp related alarms - bulk-sync : bulk-sync related alarms - protection-group : port protection group related alarms - ont : ONT general supplemental related alarms - sfu-sup : SFU ONT general supplemental related alarms - soho-sup : SOHO ONT general supplemental related alarms - mdu-sup : MDU ONT general supplemental related alarms - ont-ani : ONT general supplemental 2 related alarms - sfu-sup2 : SFU ONT general supplemental 2 related alarms - soho-sup2 : SOHO ONT general supplemental 2 related alarms	

name	Type	Description
	- mdu-sup2 : MDU ONT general supplemental 2 related alarms - sfrssi : SFP RSSI related alarms - eoltrssi : epon olt Sfp RSSI related alarms - cfm : Cfm related alarms - sfpe1t1-framer : SFP 2e1t1 framer alarms - sfpe1t1-clock : SFP 2e1t1 clock alarms - pppcc-engine-tca : PPPOE Cross Connect Engine TCA related alarm - eth-cfm : eth-cfm related alarms - rsvp : rsvp related alarms - ihub-tca : IHUB TCA related alarms - eth-ring : eth-ring related alarms - efm-oam : EFM-OAM related alarms - ont-loopdetect : ont loop detect related alarms - ont-video : ont services video related alarms - ont-ces : ont services ces related alarms - ont-voip : ont services voip related alarms - ont-video-ani : ont services video ani related alarms - ont-pwe : ont services pwe related alarms - ont-cese1 : ont services cese1 related alarms - ont-xdsl : ont services xdsl related alarms - ont-xdsl-tca : ont services xdsl tca related alarms - ont-hpna : ont hpna related alarms - ont-sip-agent-cfg : ont services voip sip agent config related alarms - ont-voip-cfg : ont services voip config related alarms - ont-mgc : ont mgc related alarms - ont-ploam : ONT PLOAM related alarms - ont-gen : ONT GENERAL related alarms - ont-card : ONT Subscriber Card related alarms - ont-pots : ONT Services POTS related alarms - ont-lan : ONT Services LAN related alarms - ont-moca : ONT MoCA related alarms - ont-tc-tca : ONT TC TCA related alarms - ont-moca-tca : ONT MoCA TCA related alarms - ont-l2uni-eth-tca : ONT L2 UNI Ethernet TCA related alarms - olt-pon-tc-tca : OLT PON TC TCA related alarms - olt-pon-util-tca : OLT PON utilization TCA related alarms - olt-chpr-util-tca : OLT channel-pair utilization TCA related alarms - olt-ont-tc-tca : OLT ONT TC TCA related alarms - ont-tca : ONT TCA related alarms - ont-pots-supplemental : ONT POTS Supplemental related alarms - sfu-ploam : SFU ONT PLOAM related alarms - sfu-gen : SFU ONT general related alarms - soho-ploam : SOHO ONT PLOAM related alarms - soho-gen : SOHO ONT general related alarms - mdu-ploam : MDU ONT PLOAM related alarms - mdu-gen : MDU ONT general related alarms - ont-veip : ONT VEIP related alarms - ont-iphost : ONT IP HOST related alarms - alarm-table : alarm table related alarms - auto-switch : auto-switch related alarms - channel-pair : channel pair related alarms	

101 query current alarms by filters

name	Type	Description
	- ont-cfg-dld : ont configure file download related alarms - olt-chpair-tc-tca : OLT CHANNELPAIR TC TCA related alarms - hgu-tr069 : hgu tr069 related alarms - eqpt-psu : equipment psu alarms - ont-protection : ONT protection related alarms - secondary-megaco-term : secondary megaco termination related alarms - secondary-sip-term : secondary sip termination related alarms - cas-r2-channel : CAS R2 channel related alarms - lldpmed : lldpmed alarms - pseudo-wire : pseudo Wire related alarms - link-agg : Link aggregation related alarms - fcs-exceed : FCS auto-recovery related alarms - e1t1-interface : E1/T1 physical interfaces related alarms	
name	Parameter type: <Alarm::almtypeSohogenihub> all Possible values: - all : SOHO ONT general related alarms	alarm name that are active <i>This element is only shown in detail mode.</i>
severity	Parameter type: <Alarm::AlarmSeverity> (indeterminate warning minor major critical) Possible values: - indeterminate : alarm severity is indeterminate - warning : alarm severity is warning - minor : alarm severity is minor - major : alarm severity is major - critical : alarm severity is critical	the alarms severity level <i>This element is only shown in detail mode.</i>
servaff	Parameter type: <Alarm::alarmServAffect> ((service-affecting yes) (noservice-affecting no)) Possible values: - service-affecting : make this alarm service affecting - yes : make this alarm service affecting - noservice-affecting : make this alarm not service affecting - no : make this alarm not service affecting	alarms affect service or not <i>This element is only shown in detail mode.</i>
time	Parameter type: <Sys::timeInSecs> - the time (yyyy-mm-dd:hour:minutes:secs) - unit: UTC	time in seconds when alarm was updated <i>This element is only shown in detail mode.</i>
descript	Parameter type: <Alarm::AddInfoString> - additional alarm information	alarm description <i>This element is only shown in detail mode.</i>

101.97 show current alarm by filters

Command Description

show current alarms by filters

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm query mdu-ploam [ (name) [ severity <Alarm::querySeverity> ] [ servaff <Alarm::queryServAffect> ] [ ont <Gpon::OntIndex> ] ]
```

Command Parameters

Table 101.97-1 "show current alarm by filters" Resource Parameters

Resource Identifier	Type	Description
(name)	Format: (mdu-ploam-loss-sig mdu-ploam-loss-ack mdu-ploam-loss-cd mdu-ploam-phy-eqpt-err mdu-ploam-startup-fail mdu-ploam-sig-degrade mdu-ploam-disabled mdu-ploam-err-msg mdu-ploam-inactive mdu-ploam-sig-fail mdu-ploam-dying-gasp mdu-ploam-deact-fail mdu-ploam-oam mdu-ploam-win-drift mdu-ploam-rdi mdu-ploam-loss-ks mdu-ploam-pwr-burst mdu-ploam-roq-disa mdu-ploam-diff-reach mdu-ploam-looc all) Possible values: - mdu-ploam-loss-sig : MDU ONT - loss of signal at ont - mdu-ploam-loss-ack : MDU ONT - loss of acknowledge from ont - mdu-ploam-loss-cd : MDU ONT - loss of channel delineation of ont	alarm name of mdu-ploam

101 query current alarms by filters

Resource Identifier	Type	Description
	- mdu-ploam-phy-eqpt-err: MDU ONT - physical equipment error of ont - mdu-ploam-startup-fail: MDU ONT - startup failure in ranging of ont - mdu-ploam-sig-degrade : MDU ONT - signal degrade from ont - mdu-ploam-disabled : MDU ONT - ont disabled alarm - mdu-ploam-err-msg : MDU ONT - error message from ont - mdu-ploam-inactive : MDU ONT - inactive ont - mdu-ploam-sig-fail : MDU ONT - signal fail alarm from ont - mdu-ploam-dying-gasp : MDU ONT - dying gasp alarm from ont - mdu-ploam-deact-fail : MDU ONT - deactive failure of ont - mdu-ploam-oam : MDU ONT - loss of ploam for ont - mdu-ploam-win-drift : MDU ONT - drift of window alarm - mdu-ploam-rdi : MDU ONT - remote defect indication alarm - mdu-ploam-loss-ks : MDU ONT - loss of key synchronization alarm - mdu-ploam-pwr-burst : MDU ONT - power bursts on ont - mdu-ploam-rog-disa : MDU ONT - ont rogue disabled - mdu-ploam-diff-reach : MDU ONT - ont differential reach exceeded - mdu-ploam-looc : MDU ONT - Loss of OMCI channel due to persistent MIC failure - all : MDU ONT PLOAM related alarms	
severity	Parameter type: <Alarm::querySeverity> Format: (indeterminate warning minor major critical all) Possible values: - indeterminate : alarm severity is indeterminate - warning : alarm severity is warning - minor : alarm severity is minor - major : alarm severity is major - critical : alarm severity is critical - all : all alarm severity	severity level of an alarm for reporting
servaff	Parameter type: <Alarm::queryServAffect> Format: (service-affecting noservice-affecting all) Possible values: - service-affecting : query alarm service affecting - noservice-affecting : query alarm not service affecting - all : query service affecting and not affecting alarms	serviceaffecting no serviceaffecting
ont	Parameter type: <Gpon::OntIndex> Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> ng2 : <Ng2::ChannelGroup> / <Ng2::SubchannelGroup> / <Ng2::OntId>)	gpon ont equipment ifindex

Resource Identifier	Type	Description
	Possible values: - ng2 : ngpon2 style identification Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Ng2::ChannelGroup> - channel group number Field type <Ng2::SubchannelGroup> - subchannel group number Field type <Eqpt::OntId> - the ONT identifier Field type <Ng2::OntId> - the ONT identifier	

Command Output

Table 101.97-2 "show current alarm by filters" Display parameters

Specific Information		
name	Type	Description
aidinfo	Parameter type: <Alarm::AddInfoString> - additional alarm information	alarm AID parameters <i>This element is only shown in detail mode.</i>
type	Parameter type: <Alarm::alarmIHUBType> (equipment eqpt-holder plug-in-unit atm custom e1 ima-group ima-link redundancy shdsl ether-itf traffic-overflow qos-queue temporal spatial (software-mngt sw-mgmt) xdsl xdsl-ext xdsl-tca olt-gen eo-conv authentication bonding sfp shdsl-isam custom-ext-alarm plug-in-unit-ext sip-user-agent	type of the alarms that are active <i>This element is only shown in detail mode.</i>

101 query current alarms by filters

name	Type	Description
	sip-plugin-unit sip-termination e1-sip-termination filetransfer external-device l2forward ether-tca ether-sfp megaco-media-gw megaco-sig-gw megaco-plug-unit megaco-term megaco-sig-lt eqpt-supplemental eqpt-holder-ext lsmredundancy sync mcsrc vlanport vect-line vect-board otdr sip-dial-plan sip-vsp sip-server bgp rip lag ihub-general vprn isis ospf ihub-l2forward vpls ihub-equip ihub-link eont-phyoam ellid epon eont-services-lan eolt-ont-tca eont-sw-dl ldp mpls sdp epipe ihub-ipv6 pim li mgmt-sec-access bfd ai tr069serv ontsnmp bulk-sync protection-group ont	

name	Type	Description
	sfu-sup	
	soho-sup	
	mdu-sup	
	ont-ani	
	sfu-sup2	
	soho-sup2	
	mdu-sup2	
	sfprssi	
	eoltrssi	
	cfm	
	sfpe1t1-framer	
	sfpe1t1-clock	
	pppcc-engine-tca	
	eth-cfm	
	rsvp	
	ihub-tca	
	eth-ring	
	efm-oam	
	ont-loopdetect	
	ont-video	
	ont-ces	
	ont-voip	
	ont-video-ani	
	ont-pwe	
	ont-cese1	
	ont-xdsl	
	ont-xdsl-tca	
	ont-hpna	
	ont-sip-agent-cfg	
	ont-voip-cfg	
	ont-mgc	
	ont-ploam	
	ont-gen	
	ont-card	
	ont-pots	
	ont-lan	
	ont-moca	
	ont-tc-tca	
	ont-moca-tca	
	ont-l2uni-eth-tca	
	olt-pon-tc-tca	
	olt-pon-util-tca	
	olt-chpr-util-tca	
	olt-ont-tc-tca	
	ont-tca	
	ont-pots-supplemental	
	sfu-ploam	
	sfu-gen	
	soho-ploam	
	soho-gen	
	mdu-ploam	
	mdu-gen	
	ont-veip	
	ont-iphost	
	alarm-table	
	auto-switch	
	channel-pair	

101 query current alarms by filters

name	Type	Description
	ont-cfg-dld olt-chpair-tc-tca hgu-tr069 eqpt-psu ont-protection secondary-megaco-term secondary-sip-term cas-r2-channel lldpmed pseudo-wire link-agg fcs-exceed e1t1-interface) Possible values: - equipment : equipment alarms - eqpt-holder : equipment holder alarms - plug-in-unit : plugin unit alarms - atm : ATM alarms - custom : customizable alarms - e1 : e1 alarms - ima-group : ima-group alarms - ima-link : ima-link alarms - redundancy : redundancy alarms - shdsl : shdsl alarms - ether-itf : ethernet interface alarms - traffic-overflow : Traffic overflow alarms - qos-queue : qos queue alarms - temporal : temporal alarms - spatial : spatial alarms - software-mngt : software management alarms - sw-mgmt : software management alarms - xdsl : xDSL alarms - xdsl-ext : other xDSL alarms - xdsl-tca : xDSL threshold cross alarms - olt-gen : OLT general alarms - eo-conv : E/O conversion related alarms - authentication : authentication related alarms - bonding : bonding-group related alarms - sfp : SFP related alarms - shdsl-isam : shdsl isam alarms - custom-ext-alarm : customizable external alarms - plug-in-unit-ext : other plugin unit alarms - sip-user-agent : sip user agent related alarms - sip-plugin-unit : sip plug in unit related alarms - sip-termination : sip termination related alarms - e1-sip-termination : E1 sip termination related alarms - filetransfer : file transfer server alarms - external-device : external device related alarms - l2forward : l2forward related alarms - ether-tca : ethernet threshold cross alarms - ether-sfp : ethernet SFP related alarms - megaco-media-gw : megaco media gateway related alarms - megaco-sig-gw : megaco signaling gateway related alarms - megaco-plug-unit : megaco plug unit related alarms - megaco-term : megaco termination related alarms - megaco-sig-lt : megaco signaling lt related alarms - eqpt-supplemental : equipment supplemental alarms	

name	Type	Description
	- eqpt-holder-ext : other equipment holder alarms - lsmredundancy : lsm redundancy alarms - sync : synce and bits alarms - mcsrsc : multicast source alarms - vlanport : vlanport alarms - vect-line : xDSL vectoring line alarms - vect-board : xDSL vectoring board alarms - otdr : otdr alarms - sip-dial-plan : sip dial plan related alarms - sip-vsp : sip vsp related alarms - sip-server : sip server related alarms - bgp : bgp related alarms - rip : rip related alarms - lag : LAG related alarms - ihub-general : IHUB general related alarms - vprn : vprn related alarms - isis : isis related alarms - ospf : ospf related alarms - ihub-l2forward : ihub-l2forward alarms - vpls : vpls related alarms - ihub-equip : ihub-equip related alarms - ihub-link : ihub-link related alarms - eont-phyoam : eont phyoam related alarms - ellid : ellid related alarms - epon : epon related alarms - eont-services-lan : eon phyoam related alarms - eolt-ont-tca : eon phyoam related alarms - eont-sw-dl : eon phyoam related alarms - ldp : ldp related alarms - mpls : mpls related alarms - sdp : sdp related alarms - epipe : epipe related alarms - ihub-ipv6 : ihub-ipv6 related alarms - pim : pim related alarms - li : lawful intercept related alarms - mgmt-sec-access : management security related alarms - bfd : bfd related alarms - ai : Application Intelligence related alarms - tr069serv : tr069 server related alarms - ontsnmp : ont snmp related alarms - bulk-sync : bulk-sync related alarms - protection-group : port protection group related alarms - ont : ONT general supplemental related alarms - sfu-sup : SFU ONT general supplemental related alarms - soho-sup : SOHO ONT general supplemental related alarms - mdu-sup : MDU ONT general supplemental related alarms - ont-ani : ONT general supplemental 2 related alarms - sfu-sup2 : SFU ONT general supplemental 2 related alarms - soho-sup2 : SOHO ONT general supplemental 2 related alarms - mdu-sup2 : MDU ONT general supplemental 2 related alarms - sfrssi : SFP RSSI related alarms - eoltrssi : epon olt Sfp RSSI related alarms - cfm : Cfm related alarms - sfpe1t1-framer : SFP 2e1t1 framer alarms	

101 query current alarms by filters

name	Type	Description
	- sfpe1t1-clock : SFP 2e1t1 clock alarms - pppcc-engine-tca : PPPOE Cross Connect Engine TCA related alarm - eth-cfm : eth-cfm related alarms - rsvp : rsvp related alarms - ihub-tca : IHUB TCA related alarms - eth-ring : eth-ring related alarms - efm-oam : EFM-OAM related alarms - ont-loopdetect : ont loop detect related alarms - ont-video : ont services video related alarms - ont-ces : ont services ces related alarms - ont-voip : ont services voip related alarms - ont-video-ani : ont services video ani related alarms - ont-pwe : ont services pwe related alarms - ont-cese1 : ont services cese1 related alarms - ont-xdsl : ont services xdsl related alarms - ont-xdsl-tca : ont services xdsl tca related alarms - ont-hpna : ont hpna related alarms - ont-sip-agent-cfg : ont services voip sip agent config related alarms - ont-voip-cfg : ont services voip config related alarms - ont-mgc : ont mgc related alarms - ont-ploam : ONT PLOAM related alarms - ont-gen : ONT GENERAL related alarms - ont-card : ONT Subscriber Card related alarms - ont-pots : ONT Services POTS related alarms - ont-lan : ONT Services LAN related alarms - ont-moca : ONT MoCA related alarms - ont-tc-tca : ONT TC TCA related alarms - ont-moca-tca : ONT MoCA TCA related alarms - ont-l2uni-eth-tca : ONT L2 UNI Ethernet TCA related alarms - olt-pon-tc-tca : OLT PON TC TCA related alarms - olt-pon-util-tca : OLT PON utilization TCA related alarms - olt-chpr-util-tca : OLT channel-pair utilization TCA related alarms - olt-ont-tc-tca : OLT ONT TC TCA related alarms - ont-tca : ONT TCA related alarms - ont-pots-supplemental : ONT POTS Supplemental related alarms - sfu-ploam : SFU ONT PLOAM related alarms - sfu-gen : SFU ONT general related alarms - soho-ploam : SOHO ONT PLOAM related alarms - soho-gen : SOHO ONT general related alarms - mdu-ploam : MDU ONT PLOAM related alarms - mdu-gen : MDU ONT general related alarms - ont-veip : ONT VEIP related alarms - ont-iphost : ONT IP HOST related alarms - alarm-table : alarm table related alarms - auto-switch : auto-switch related alarms - channel-pair : channel pair related alarms - ont-cfg-dld : ont configure file download related alarms - olt-chpair-tc-tca : OLT CHANNELPAIR TC TCA related alarms - hgu-tr069 : hgu tr069 related alarms - eqpt-psu : equipment psu alarms - ont-protection : ONT protection related alarms	

name	Type	Description
	- secondary-megaco-term : secondary megaco termination related alarms - secondary-sip-term : secondary sip termination related alarms - cas-r2-channel : CAS R2 channel related alarms - lldpmed : lldpmed alarms - pseudo-wire : pseudo Wire related alarms - link-agg : Link aggregation related alarms - fcs-exceed : FCS auto-recovery related alarms - e1t1-interface : E1/T1 physical interfaces related alarms	
name	Parameter type: <Alarm::almtypeMduploamihub> (mdu-ploam-loss-sig mdu-ploam-loss-ack mdu-ploam-loss-cd mdu-ploam-phy-eqpt-err mdu-ploam-startup-fail mdu-ploam-sig-degrade mdu-ploam-disabled mdu-ploam-err-msg mdu-ploam-inactive mdu-ploam-sig-fail mdu-ploam-dying-gasp mdu-ploam-deact-fail mdu-ploam-oam mdu-ploam-win-drift mdu-ploam-rdi mdu-ploam-loss-ks mdu-ploam-pwr-burst mdu-ploam-roq-disa mdu-ploam-diff-reach mdu-ploam-looc all) Possible values: - mdu-ploam-loss-sig : MDU ONT - loss of signal at ont - mdu-ploam-loss-ack : MDU ONT - loss of acknowledge from ont - mdu-ploam-loss-cd : MDU ONT - loss of channel delineation of ont - mdu-ploam-phy-eqpt-err: MDU ONT - physical equipment error of ont - mdu-ploam-startup-fail: MDU ONT - startup failure in ranging of ont - mdu-ploam-sig-degrade : MDU ONT - signal degrade from ont - mdu-ploam-disabled : MDU ONT - ont disabled alarm - mdu-ploam-err-msg : MDU ONT - error message from ont - mdu-ploam-inactive : MDU ONT - inactive ont - mdu-ploam-sig-fail : MDU ONT - signal fail alarm from ont - mdu-ploam-dying-gasp : MDU ONT - dying gasp alarm from ont - mdu-ploam-deact-fail : MDU ONT - deactive failure of ont - mdu-ploam-oam : MDU ONT - loss of ploam for ont - mdu-ploam-win-drift : MDU ONT - drift of window alarm - mdu-ploam-rdi : MDU ONT - remote defect indication alarm - mdu-ploam-loss-ks : MDU ONT - loss of key	alarm name that are active <i>This element is only shown in detail mode.</i>

101 query current alarms by filters

name	Type	Description
	synchronization alarm - mdu-ploam-pwr-burst : MDU ONT - power bursts on ont - mdu-ploam-roq-disa : MDU ONT - ont rogue disabled - mdu-ploam-diff-reach : MDU ONT - ont differential reach exceeded - mdu-ploam-looc : MDU ONT - Loss of OMCI channel due to persistent MIC failure - all : MDU ONT PLOAM related alarms	
severity	Parameter type: <Alarm::AlarmSeverity> (indeterminate warning minor major critical) Possible values: - indeterminate : alarm severity is indeterminate - warning : alarm severity is warning - minor : alarm severity is minor - major : alarm severity is major - critical : alarm severity is critical	the alarms severity level <i>This element is only shown in detail mode.</i>
servaff	Parameter type: <Alarm::alarmServAffect> ((service-affecting yes) (noservice-affecting no)) Possible values: - service-affecting : make this alarm service affecting - yes : make this alarm service affecting - noservice-affecting : make this alarm not service affecting - no : make this alarm not service affecting	alarms affect service or not <i>This element is only shown in detail mode.</i>
time	Parameter type: <Sys::timeInSecs> - the time (yyyy-mm-dd:hour:minutes:secs) - unit: UTC	time in seconds when alarm was updated <i>This element is only shown in detail mode.</i>
descript	Parameter type: <Alarm::AddInfoString> - additional alarm information	alarm description <i>This element is only shown in detail mode.</i>

101.98 show current alarm by filters

Command Description

show current alarms by filters

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm query mdu-gen [ (name) [ severity <Alarm::querySeverity> ] [ servaff <Alarm::queryServAffect> ] [
ont <Gpon::OntIndex> ] ]
```

Command Parameters

Table 101.98-1 "show current alarm by filters" Resource Parameters

Resource Identifier	Type	Description
(name)	Format: (mdu-gen-omci-fail mdu-gen-eqpt-selftest mdu-gen-ac-pwr-fail mdu-gen-bat-missing mdu-gen-bat-low mdu-gen-bat-fail mdu-gen-phys-intrusion mdu-gen-sw-dnload-f mdu-gen-sw-dnload-p mdu-gen-sw-act-fail mdu-gen-eqpt-vers-mis mdu-gen-sw-vers-mis mdu-gen-us-rate-mis mdu-gen-tune-fail mdu-gen-mdu-env1 mdu-gen-mdu-env2 mdu-gen-mdu-env3 mdu-gen-nw-time-err mdu-gen-opt-sig-high mdu-gen-opt-sig-low mdu-gen-eqpt-prov-sa mdu-gen-eqpt-prov-nsa all) Possible values: - mdu-gen-omci-fail : MDU ONT - loss of communication - mdu-gen-eqpt-selftest : MDU ONT - ont self-test failure - mdu-gen-ac-pwr-fail : MDU ONT - ac power failure on	alarm name of mdu-gen

101 query current alarms by filters

Resource Identifier	Type	Description
	ont - mdu-gen-bat-missing : MDU ONT - battery missing - mdu-gen-bat-low : MDU ONT - battery low - mdu-gen-bat-fail : MDU ONT - battery failure - mdu-gen-phys-intrusion: MDU ONT - physical intrusion - mdu-gen-sw-dnload-f : MDU ONT - ont sw download failure - mdu-gen-sw-dnload-p : MDU ONT - ont sw download in progress - mdu-gen-sw-act-fail : MDU ONT - ont sw activation failure - mdu-gen-eqpt-vers-mis : MDU ONT - ont equipment version mismatch - mdu-gen-sw-vers-mis : MDU ONT - ont sw version mismatch - mdu-gen-us-rate-mis : MDU ONT - ont upstream rate mismatch - mdu-gen-tune-fail : MDU ONT - ont has failed to tune to Target-ChnlPair - mdu-gen-mdu-env1 : MDU ONT - mdu environmental alarm#1 - mdu-gen-mdu-env2 : MDU ONT - mdu environmental alarm#2 - mdu-gen-mdu-env3 : MDU ONT - mdu environmental alarm#3 - mdu-gen-nw-time-err : MDU ONT - network timing protocol error - mdu-gen-opt-sig-high : MDU ONT - optical signal level too high - mdu-gen-opt-sig-low : MDU ONT - optical signal level too low - mdu-gen-eqpt-prov-sa : MDU ONT - service affecting mismatch btw equipment and provisioning attributes - mdu-gen-eqpt-prov-nsa : MDU ONT - non service affecting mismatch btw equipment and provisioning attributes - all : DU ONT general related alarms	
severity	Parameter type: <Alarm::querySeverity> Format: (indeterminate warning minor major critical all) Possible values: - indeterminate : alarm severity is indeterminate - warning : alarm severity is warning - minor : alarm severity is minor - major : alarm severity is major - critical : alarm severity is critical - all : all alarm severity	severity level of an alarm for reporting
servaff	Parameter type: <Alarm::queryServAffect> Format: (service-affecting noservice-affecting all)	serviceaffecting no

Resource Identifier	Type	Description
	Possible values: - service-affecting : query alarm service affecting - noservice-affecting : query alarm not service affecting - all : query service affecting and not affecting alarms	
ont	Parameter type: <Gpon::OntIndex> Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> ng2 : <Ng2::ChannelGroup> / <Ng2::SubchannelGroup> / <Ng2::OntId>) Possible values: - ng2 : ngpon2 style identification Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Ng2::ChannelGroup> - channel group number Field type <Ng2::SubchannelGroup> - subchannel group number Field type <Eqpt::OntId> - the ONT identifier Field type <Ng2::OntId> - the ONT identifier	gpon ont equipment ifindex of ont

Command Output

Table 101.98-2 "show current alarm by filters" Display parameters

Specific Information		
name	Type	Description
aidinfo	Parameter type: <Alarm::AddInfoString> - additional alarm information	alarm AID parameters <i>This element is only shown in detail mode.</i>
type	Parameter type: <Alarm::alarmIHUBType> (equipment eqpt-holder plug-in-unit atm custom e1 ima-group ima-link redundancy shdsl ether-itf traffic-overflow qos-queue temporal spatial (software-mngt sw-mgmt) xdsl xdsl-ext	type of the alarms that are active <i>This element is only shown in detail mode.</i>

101 query current alarms by filters

name	Type	Description
	xds1-tca olt-gen eo-conv authentication bonding sfp shdsl-isam custom-ext-alarm plug-in-unit-ext sip-user-agent sip-plugin-unit sip-termination e1-sip-termination filetransfer external-device l2forward ether-tca ether-sfp megaco-media-gw megaco-sig-gw megaco-plug-unit megaco-term megaco-sig-lt eqpt-supplemental eqpt-holder-ext lsmredundancy sync mcsrc vlanport vect-line vect-board otdr sip-dial-plan sip-vsp sip-server bgp rip lag ihub-general vprn isis ospf ihub-l2forward vpls ihub-equip ihub-link eont-phyoam ellid epon eont-services-lan eolt-ont-tca eont-sw-dl ldp mpls sdp epipe ihub-ipv6	

name	Type	Description
	pim li mgmt-sec-access bfd ai tr069serv ontsnmp bulk-sync protection-group ont sfu-sup soho-sup mdu-sup ont-ani sfu-sup2 soho-sup2 mdu-sup2 sfprssi eoltrssi cfm sfpe1t1-framer sfpe1t1-clock pppcc-engine-tca eth-cfm rsvp ihub-tca eth-ring efm-oam ont-loopdetect ont-video ont-ces ont-voip ont-video-ani ont-pwe ont-cese1 ont-xdsl ont-xdsl-tca ont-hpna ont-sip-agent-cfg ont-voip-cfg ont-mgc ont-ploam ont-gen ont-card ont-pots ont-lan ont-moca ont-tc-tca ont-moca-tca ont-l2uni-eth-tca olt-pon-tc-tca olt-pon-util-tca olt-chpr-util-tca olt-ont-tc-tca ont-tca ont-pots-supplemental sfu-ploam	

101 query current alarms by filters

name	Type	Description
	sfu-gen soho-ploam soho-gen mdu-ploam mdu-gen ont-veip ont-iphost alarm-table auto-switch channel-pair ont-cfg-dld olt-chpair-tc-tca hgu-tr069 eqpt-psu ont-protection secondary-megaco-term secondary-sip-term cas-r2-channel lldpmed pseudo-wire link-agg fcs-exceed e1t1-interface) Possible values: - equipment : equipment alarms - eqpt-holder : equipment holder alarms - plug-in-unit : plugin unit alarms - atm : ATM alarms - custom : customizable alarms - e1 : e1 alarms - ima-group : ima-group alarms - ima-link : ima-link alarms - redundancy : redundancy alarms - shdsl : shdsl alarms - ether-itf : ethernet interface alarms - traffic-overflow : Traffic overflow alarms - qos-queue : qos queue alarms - temporal : temporal alarms - spatial : spatial alarms - software-mngt : software management alarms - sw-mgmt : software management alarms - xdsl : xDSL alarms - xdsl-ext : other xDSL alarms - xdsl-tca : xDSL threshold cross alarms - olt-gen : OLT general alarms - eo-conv : E/O conversion related alarms - authentication : authentication related alarms - bonding : bonding-group related alarms - sfp : SFP related alarms - shdsl-isam : shdsl isam alarms - custom-ext-alarm : customizable external alarms - plug-in-unit-ext : other plugin unit alarms - sip-user-agent : sip user agent related alarms - sip-plugin-unit : sip plug in unit related alarms - sip-termination : sip termination related alarms - e1-sip-termination : E1 sip termination related alarms - filetransfer : file transfer server alarms	

name	Type	Description
	- external-device : external device related alarms - l2forward : l2forward related alarms - ether-tca : ethernet threshold cross alarms - ether-sfp : ethernet SFP related alarms - megaco-media-gw : megaco media gateway related alarms - megaco-sig-gw : megaco signaling gateway related alarms - megaco-plug-unit : megaco plug unit related alarms - megaco-term : megaco termination related alarms - megaco-sig-lt : megaco signaling lt related alarms - eqpt-supplemental : equipment supplemental alarms - eqpt-holder-ext : other equipment holder alarms - lsmredundancy : lsm redundancy alarms - sync : synce and bits alarms - mcsrc : multicast source alarms - vlanport : vlanport alarms - vect-line : xDSL vectoring line alarms - vect-board : xDSL vectoring board alarms - otdr : otdr alarms - sip-dial-plan : sip dial plan related alarms - sip-vsp : sip vsp related alarms - sip-server : sip server related alarms - bgp : bgp related alarms - rip : rip related alarms - lag : LAG related alarms - ihub-general : IHUB general related alarms - vprn : vprn related alarms - isis : isis related alarms - ospf : ospf related alarms - ihub-l2forward : ihub-l2forward alarms - vpls : vpls related alarms - ihub-equip : ihub-equip related alarms - ihub-link : ihub-link related alarms - eont-phyoam : eont phyoam related alarms - ellid : ellid related alarms - epon : epon related alarms - eont-services-lan : eon phyoam related alarms - eolt-ont-tca : eon phyoam related alarms - eont-sw-dl : eon phyoam related alarms - ldp : ldp related alarms - mpls : mpls related alarms - sdp : sdp related alarms - epipe : epipe related alarms - ihub-ipv6 : ihub-ipv6 related alarms - pim : pim related alarms - li : lawful intercept related alarms - mgmt-sec-access : management security related alarms - bfd : bfd related alarms - ai : Application Intelligence related alarms - tr069serv : tr069 server related alarms - ontsnmp : ont snmp related alarms - bulk-sync : bulk-sync related alarms - protection-group : port protection group related alarms - ont : ONT general supplemental related alarms - sfu-sup : SFU ONT general supplemental related alarms - soho-sup : SOHO ONT general supplemental related alarms - mdm-sup : MDU ONT general supplemental related alarms	

101 query current alarms by filters

name	Type	Description
	- ont-ani : ONT general supplemental 2 related alarms - sfu-sup2 : SFU ONT general supplemental 2 related alarms - soho-sup2 : SOHO ONT general supplemental 2 related alarms - mdu-sup2 : MDU ONT general supplemental 2 related alarms - sfprssi : SFP RSSI related alarms - eoltrssi : epon olt Sfp RSSI related alarms - cfm : Cfm related alarms - sfpe1t1-framer : SFP 2e1t1 framer alarms - sfpe1t1-clock : SFP 2e1t1 clock alarms - pppcc-engine-tca : PPPOE Cross Connect Engine TCA related alarm - eth-cfm : eth-cfm related alarms - rsvp : rsvp related alarms - ihub-tca : IHUB TCA related alarms - eth-ring : eth-ring related alarms - efm-oam : EFM-OAM related alarms - ont-loopdetect : ont loop detect related alarms - ont-video : ont services video related alarms - ont-ces : ont services ces related alarms - ont-voip : ont services voip related alarms - ont-video-ani : ont services video ani related alarms - ont-pwe : ont services pwe related alarms - ont-cese1 : ont services cese1 related alarms - ont-xdsl : ont services xdsl related alarms - ont-xdsl-tca : ont services xdsl tca related alarms - ont-hpna : ont hpna related alarms - ont-sip-agent-cfg : ont services voip sip agent config related alarms - ont-voip-cfg : ont services voip config related alarms - ont-mgc : ont mgc related alarms - ont-ploam : ONT PLOAM related alarms - ont-gen : ONT GENERAL related alarms - ont-card : ONT Subscriber Card related alarms - ont-pots : ONT Services POTS related alarms - ont-lan : ONT Services LAN related alarms - ont-moca : ONT MoCA related alarms - ont-tc-tca : ONT TC TCA related alarms - ont-moca-tca : ONT MoCA TCA related alarms - ont-l2uni-eth-tca : ONT L2 UNI Ethernet TCA related alarms - olt-pon-tc-tca : OLT PON TC TCA related alarms - olt-pon-util-tca : OLT PON utilization TCA related alarms - olt-chpr-util-tca : OLT channel-pair utilization TCA related alarms - olt-ont-tc-tca : OLT ONT TC TCA related alarms - ont-tca : ONT TCA related alarms - ont-pots-supplemental : ONT POTS Supplemental related alarms - sfu-ploam : SFU ONT PLOAM related alarms - sfu-gen : SFU ONT general related alarms - soho-ploam : SOHO ONT PLOAM related alarms - soho-gen : SOHO ONT general related alarms - mdu-ploam : MDU ONT PLOAM related alarms - mdu-gen : MDU ONT general related alarms - ont-veip : ONT VEIP related alarms	

name	Type	Description
	- ont-iphost : ONT IP HOST related alarms - alarm-table : alarm table related alarms - auto-switch : auto-switch related alarms - channel-pair : channel pair related alarms - ont-cfg-dld : ont configure file download related alarms - olt-chpair-tc-tca : OLT CHANNELPAIR TC TCA related alarms - hgu-tr069 : hgu tr069 related alarms - eqpt-psu : equipment psu alarms - ont-protection : ONT protection related alarms - secondary-megaco-term : secondary megaco termination related alarms - secondary-sip-term : secondary sip termination related alarms - cas-r2-channel : CAS R2 channel related alarms - lldpmed : lldpmed alarms - pseudo-wire : pseudo Wire related alarms - link-agg : Link aggregation related alarms - fcs-exceed : FCS auto-recovery related alarms - elt1-interface : E1/T1 physical interfaces related alarms	
name	Parameter type: <Alarm::almtypeMdugenihub> (mdu-gen-omci-fail mdu-gen-eqpt-selftest mdu-gen-ac-pwr-fail mdu-gen-bat-missing mdu-gen-bat-low mdu-gen-bat-fail mdu-gen-phys-intrusion mdu-gen-sw-dnload-f mdu-gen-sw-dnload-p mdu-gen-sw-act-fail mdu-gen-eqpt-vers-mis mdu-gen-sw-vers-mis mdu-gen-us-rate-mis mdu-gen-tune-fail mdu-gen-mdu-env1 mdu-gen-mdu-env2 mdu-gen-mdu-env3 mdu-gen-nw-time-err mdu-gen-opt-sig-high mdu-gen-opt-sig-low mdu-gen-eqpt-prov-sa mdu-gen-eqpt-prov-nsa all) Possible values: - mdu-gen-omci-fail : MDU ONT - loss of communication - mdu-gen-eqpt-selftest : MDU ONT - ont self-test failure - mdu-gen-ac-pwr-fail : MDU ONT - ac power failure on ont - mdu-gen-bat-missing : MDU ONT - battery missing - mdu-gen-bat-low : MDU ONT - battery low - mdu-gen-bat-fail : MDU ONT - battery failure - mdu-gen-phys-intrusion: MDU ONT - physical intrusion - mdu-gen-sw-dnload-f : MDU ONT - ont sw download failure - mdu-gen-sw-dnload-p : MDU ONT - ont sw download in progress	alarm name that are active <i>This element is only shown in detail mode.</i>

101 query current alarms by filters

name	Type	Description
	- mdu-gen-sw-act-fail : MDU ONT - ont sw activation failure - mdu-gen-eqpt-vers-mis : MDU ONT - ont equipment version mismatch - mdu-gen-sw-vers-mis : MDU ONT - ont sw version mismatch - mdu-gen-us-rate-mis : MDU ONT - ont upstream rate mismatch - mdu-gen-tune-fail : MDU ONT - ont has failed to tune to Target-ChnlPair - mdu-gen-mdt-env1 : MDU ONT - mdu environmental alarm#1 - mdu-gen-mdt-env2 : MDU ONT - mdu environmental alarm#2 - mdu-gen-mdt-env3 : MDU ONT - mdu environmental alarm#3 - mdu-gen-nw-time-err : MDU ONT - network timing protocol error - mdu-gen-opt-sig-high : MDU ONT - optical signal level too high - mdu-gen-opt-sig-low : MDU ONT - optical signal level too low - mdu-gen-eqpt-prov-sa : MDU ONT - service affecting mismatch btw equipment and provisioning attributes - mdu-gen-eqpt-prov-nsa : MDU ONT - non service affecting mismatch btw equipment and provisioning attributes - all : DU ONT general related alarms	
severity	Parameter type: <Alarm::AlarmSeverity> (indeterminate warning minor major critical) Possible values: - indeterminate : alarm severity is indeterminate - warning : alarm severity is warning - minor : alarm severity is minor - major : alarm severity is major - critical : alarm severity is critical	the alarms severity level <i>This element is only shown in detail mode.</i>
servaff	Parameter type: <Alarm::alarmServAffect> ((service-affecting yes) (noservice-affecting no)) Possible values: - service-affecting : make this alarm service affecting - yes : make this alarm service affecting - noservice-affecting : make this alarm not service affecting - no : make this alarm not service affecting	alarms affect service or not <i>This element is only shown in detail mode.</i>
time	Parameter type: <Sys::timeInSecs> - the time (yyyy-mm-dd:hour:minutes:secs) - unit: UTC	time in seconds when alarm was updated <i>This element is only shown in detail mode.</i>
descript	Parameter type: <Alarm::AddInfoString> - additional alarm information	alarm description <i>This element is only shown in detail mode.</i>

101.99 show current alarm by filters

Command Description

show current alarms by filters

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm query ont-hpna [ (name) [ severity <Alarm::querySeverity> ] [ servaff <Alarm::queryServAffect> ] [ ont-port <Alarm::queryDefaultAid> ] ]
```

Command Parameters

Table 101.99-1 "show current alarm by filters" Resource Parameters

Resource Identifier	Type	Description
(name)	Format: (ont-hpna-ser-mis ont-hpna-los-sig all) Possible values: - ont-hpna-ser-mis : hpna ont service mismatch - ont-hpna-los-sig : hpna loss of link - all : ont hpna related alarms	alarm name of ont-hpna
severity	Parameter type: <Alarm::querySeverity> Format: (indeterminate warning minor major critical all) Possible values: - indeterminate : alarm severity is indeterminate - warning : alarm severity is warning - minor : alarm severity is minor - major : alarm severity is major - critical : alarm severity is critical - all : all alarm severity	severity level of an alarm for reporting
servaff	Parameter type: <Alarm::queryServAffect> Format: (service-affecting noservice-affecting all)	serviceaffecting no

101 query current alarms by filters

Resource Identifier	Type	Description
	Possible values: - service-affecting : query alarm service affecting - noservice-affecting : query alarm not service affecting - all : query service affecting and not affecting alarms	
ont-port	Parameter type: <Alarm::queryDefaultAid> Format: all Possible values: - all : default AID parameter	all the ont port

Command Output

Table 101.99-2 "show current alarm by filters" Display parameters

Specific Information		
name	Type	Description
aidinfo	Parameter type: <Alarm::AddInfoString> - additional alarm information	alarm AID parameters <i>This element is only shown in detail mode.</i>
type	Parameter type: <Alarm::alarmIHUBType> (equipment eqpt-holder plug-in-unit atm custom e1 ima-group ima-link redundancy shdsl ether-itf traffic-overflow qos-queue temporal spatial (software-mngt sw-mgmt) xdsl xdsl-ext xdsl-tca olt-gen eo-conv authentication bonding sfp shdsl-isam custom-ext-alarm plug-in-unit-ext sip-user-agent sip-plugin-unit sip-termination e1-sip-termination filetransfer external-device l2forward ether-tca ether-sfp megaco-media-gw	type of the alarms that are active <i>This element is only shown in detail mode.</i>

name	Type	Description
	megaco-sig-gw	
	megaco-plug-unit	
	megaco-term	
	megaco-sig-lt	
	eqpt-supplemental	
	eqpt-holder-ext	
	lsmredundancy	
	sync	
	mcsrc	
	vlanport	
	vect-line	
	vect-board	
	otdr	
	sip-dial-plan	
	sip-vsp	
	sip-server	
	bgp	
	rip	
	lag	
	ihub-general	
	vprn	
	isis	
	ospf	
	ihub-l2forward	
	vpls	
	ihub-equip	
	ihub-link	
	eont-phyoam	
	ellid	
	epon	
	eont-services-lan	
	eolt-ont-tca	
	eont-sw-dl	
	ldp	
	mpls	
	sdp	
	epipe	
	ihub-ipv6	
	pim	
	li	
	mgmt-sec-access	
	bfd	
	ai	
	tr069serv	
	ontsnmp	
	bulk-sync	
	protection-group	
	ont	
	sfu-sup	
	soho-sup	
	mdu-sup	
	ont-ani	
	sfu-sup2	
	soho-sup2	
	mdu-sup2	
	sfprssi	
	eoltrssi	

101 query current alarms by filters

name	Type	Description
	cfm sfpe1t1-framer sfpe1t1-clock pppcc-engine-tca eth-cfm rsvp ihub-tca eth-ring efm-oam ont-loopdetect ont-video ont-ces ont-voip ont-video-ani ont-pwe ont-cese1 ont-xdsl ont-xdsl-tca ont-hpna ont-sip-agent-cfg ont-voip-cfg ont-mgc ont-ploam ont-gen ont-card ont-pots ont-lan ont-moca ont-tc-tca ont-moca-tca ont-l2uni-eth-tca olt-pon-tc-tca olt-pon-util-tca olt-chpr-util-tca olt-ont-tc-tca ont-tca ont-pots-supplemental sfu-ploam sfu-gen soho-ploam soho-gen mdu-ploam mdu-gen ont-veip ont-iphost alarm-table auto-switch channel-pair ont-cfg-dld olt-chpair-tc-tca hgu-tr069 eqpt-psu ont-protection secondary-megaco-term secondary-sip-term cas-r2-channel lldpmed	

name	Type	Description
	pseudo-wire link-agg fcs-exceed e1t1-interface) Possible values: - equipment : equipment alarms - eqpt-holder : equipment holder alarms - plug-in-unit : plugin unit alarms - atm : ATM alarms - custom : customizable alarms - e1 : e1 alarms - ima-group : ima-group alarms - ima-link : ima-link alarms - redundancy : redundancy alarms - shdsl : shdsl alarms - ether-itf : ethernet interface alarms - traffic-overflow : Traffic overflow alarms - qos-queue : qos queue alarms - temporal : temporal alarms - spatial : spatial alarms - software-mngt : software management alarms - sw-mgmt : software management alarms - xdsl : xDSL alarms - xdsl-ext : other xDSL alarms - xdsl-tca : xDSL threshold cross alarms - olt-gen : OLT general alarms - eo-conv : E/O conversion related alarms - authentication : authentication related alarms - bonding : bonding-group related alarms - sfp : SFP related alarms - shdsl-isam : shdsl isam alarms - custom-ext-alarm : customizable external alarms - plug-in-unit-ext : other plugin unit alarms - sip-user-agent : sip user agent related alarms - sip-plugin-unit : sip plug in unit related alarms - sip-termination : sip termination related alarms - e1-sip-termination : E1 sip termination related alarms - filetransfer : file transfer server alarms - external-device : external device related alarms - l2forward : l2forward related alarms - ether-tca : ethernet threshold cross alarms - ether-sfp : ethernet SFP related alarms - megaco-media-gw : megaco media gateway related alarms - megaco-sig-gw : megaco signaling gateway related alarms - megaco-plug-unit : megaco plug unit related alarms - megaco-term : megaco termination related alarms - megaco-sig-lt : megaco signaling lt related alarms - eqpt-supplemental : equipment supplemental alarms - eqpt-holder-ext : other equipment holder alarms - lsmredundancy : lsm redundancy alarms - sync : synce and bits alarms - mcsrc : multicast source alarms - vlanport : vlanport alarms - vect-line : xDSL vectoring line alarms - vect-board : xDSL vectoring board alarms - otdr : otdr alarms - sip-dial-plan : sip dial plan related alarms	

101 query current alarms by filters

name	Type	Description
	- sip-vsp : sip vsp related alarms - sip-server : sip server related alarms - bgp : bgp related alarms - rip : rip related alarms - lag : LAG related alarms - ihub-general : IHUB general related alarms - vprn : vprn related alarms - isis : isis related alarms - ospf : ospf related alarms - ihub-l2forward : ihub-l2forward alarms - vpls : vpls related alarms - ihub-equip : ihub-equip related alarms - ihub-link : ihub-link related alarms - eont-phyoam : eont phyoam related alarms - ellid : ellid related alarms - epon : epon related alarms - eont-services-lan : eon phyoam related alarms - eolt-ont-tca : eon phyoam related alarms - eont-sw-dl : eon phyoam related alarms - ldp : ldp related alarms - mpls : mpls related alarms - sdp : sdp related alarms - epipe : epipe related alarms - ihub-ipv6 : ihub-ipv6 related alarms - pim : pim related alarms - li : lawful intercept related alarms - mgmt-sec-access : management security related alarms - bfd : bfd related alarms - ai : Application Intelligence related alarms - tr069serv : tr069 server related alarms - ontsnmp : ont snmp related alarms - bulk-sync : bulk-sync related alarms - protection-group : port protection group related alarms - ont : ONT general supplemental related alarms - sfu-sup : SFU ONT general supplemental related alarms - soho-sup : SOHO ONT general supplemental related alarms - mdu-sup : MDU ONT general supplemental related alarms - ont-ani : ONT general supplemental 2 related alarms - sfu-sup2 : SFU ONT general supplemental 2 related alarms - soho-sup2 : SOHO ONT general supplemental 2 related alarms - mdu-sup2 : MDU ONT general supplemental 2 related alarms - sfprssi : SFP RSSI related alarms - eoltrssi : epon olt Sfp RSSI related alarms - cfm : Cfm related alarms - sfpe1t1-framer : SFP 2e1t1 framer alarms - sfpe1t1-clock : SFP 2e1t1 clock alarms - pppcc-engine-tca : PPPOE Cross Connect Engine TCA related alarm - eth-cfm : eth-cfm related alarms - rsvp : rsvp related alarms - ihub-tca : IHUB TCA related alarms - eth-ring : eth-ring related alarms - efm-oam : EFM-OAM related alarms - ont-loopdetect : ont loop detect related alarms	

name	Type	Description
	- ont-video : ont services video related alarms - ont-ces : ont services ces related alarms - ont-voip : ont services voip related alarms - ont-video-ani : ont services video ani related alarms - ont-pwe : ont services pwe related alarms - ont-cese1 : ont services cese1 related alarms - ont-xdsl : ont services xdsl related alarms - ont-xdsl-tca : ont services xdsl tca related alarms - ont-hpna : ont hpna related alarms - ont-sip-agent-cfg : ont services voip sip agent config related alarms - ont-voip-cfg : ont services voip config related alarms - ont-mgc : ont mgc related alarms - ont-ploam : ONT PLOAM related alarms - ont-gen : ONT GENERAL related alarms - ont-card : ONT Subscriber Card related alarms - ont-pots : ONT Services POTS related alarms - ont-lan : ONT Services LAN related alarms - ont-moca : ONT MoCA related alarms - ont-tc-tca : ONT TC TCA related alarms - ont-moca-tca : ONT MoCA TCA related alarms - ont-l2uni-eth-tca : ONT L2 UNI Ethernet TCA related alarms - olt-pon-tc-tca : OLT PON TC TCA related alarms - olt-pon-util-tca : OLT PON utilization TCA related alarms - olt-chpr-util-tca : OLT channel-pair utilization TCA related alarms - olt-ont-tc-tca : OLT ONT TC TCA related alarms - ont-tca : ONT TCA related alarms - ont-pots-supplemental : ONT POTS Supplemental related alarms - sfu-ploam : SFU ONT PLOAM related alarms - sfu-gen : SFU ONT general related alarms - soho-ploam : SOHO ONT PLOAM related alarms - soho-gen : SOHO ONT general related alarms - mdu-ploam : MDU ONT PLOAM related alarms - mdu-gen : MDU ONT general related alarms - ont-veip : ONT VEIP related alarms - ont-iphost : ONT IP HOST related alarms - alarm-table : alarm table related alarms - auto-switch : auto-switch related alarms - channel-pair : channel pair related alarms - ont-cfg-dld : ont configure file download related alarms - olt-chpair-tc-tca : OLT CHANNELPAIR TC TCA related alarms - hgu-tr069 : hgu tr069 related alarms - eqpt-psu : equipment psu alarms - ont-protection : ONT protection related alarms - secondary-megaco-term : secondary megaco termination related alarms - secondary-sip-term : secondary sip termination related alarms - cas-r2-channel : CAS R2 channel related alarms - lldpmed : lldpmed alarms - pseudo-wire : pseudo Wire related alarms - link-agg : Link aggregation related alarms - fcs-exceed : FCS auto-recovery related alarms	

101 query current alarms by filters

name	Type	Description
	- e1t1-interface : E1/T1 physical interfaces related alarms	
name	Parameter type: <Alarm::alarmTypeOnHpnaIhub> (ont-hpna-ser-mis ont-hpna-los-sig all) Possible values: - ont-hpna-ser-mis : hpna ont service mismatch - ont-hpna-los-sig : hpna loss of link - all : ont hpna related alarms	alarm name that are active <i>This element is only shown in detail mode.</i>
severity	Parameter type: <Alarm::AlarmSeverity> (indeterminate warning minor major critical) Possible values: - indeterminate : alarm severity is indeterminate - warning : alarm severity is warning - minor : alarm severity is minor - major : alarm severity is major - critical : alarm severity is critical	the alarms severity level <i>This element is only shown in detail mode.</i>
servaff	Parameter type: <Alarm::alarmServAffect> ((service-affecting yes) (noservice-affecting no)) Possible values: - service-affecting : make this alarm service affecting - yes : make this alarm service affecting - noservice-affecting : make this alarm not service affecting - no : make this alarm not service affecting	alarms affect service or not <i>This element is only shown in detail mode.</i>
time	Parameter type: <Sys::timeInSecs> - the time (yyyy-mm-dd:hour:minutes:secs) - unit: UTC	time in seconds when alarm was updated <i>This element is only shown in detail mode.</i>
descript	Parameter type: <Alarm::AddInfoString> - additional alarm information	alarm description <i>This element is only shown in detail mode.</i>

101.100 show current alarm by filters

Command Description

show current alarms by filters

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm query ldp [ (name) [ severity <Alarm::querySeverity> ] [ servaff <Alarm::queryServAffect> ] [
router-id <lhub::baseRouter> ] ]
```

Command Parameters

Table 101.100-1 "show current alarm by filters" Resource Parameters

Resource Identifier	Type	Description
(name)	Format: (ldp-instance-down ldp-session-down all) Possible values: - ldp-instance-down : ldp instance down - ldp-session-down : ldp session down - all : ldp related alarms	alarm name of ldp
severity	Parameter type: <Alarm::querySeverity> Format: (indeterminate warning minor major critical all) Possible values: - indeterminate : alarm severity is indeterminate - warning : alarm severity is warning - minor : alarm severity is minor - major : alarm severity is major - critical : alarm severity is critical - all : all alarm severity	severity level of an alarm for reporting
servaff	Parameter type: <Alarm::queryServAffect> Format: (service-affecting noservice-affecting all)	serviceaffecting no

101 query current alarms by filters

Resource Identifier	Type	Description
	Possible values: - service-affecting : query alarm service affecting - noservice-affecting : query alarm not service affecting - all : query service affecting and not affecting alarms	
router-id	Parameter type: <Ihub::baseRouter> Format: base Possible values: - base : base router	identifies the base router

Command Output

Table 101.100-2 "show current alarm by filters" Display parameters

Specific Information		
name	Type	Description
aidinfo	Parameter type: <Alarm::AddInfoString> - additional alarm information	alarm AID parameters <i>This element is only shown in detail mode.</i>
type	Parameter type: <Alarm::alarmIHUBType> (equipment eqpt-holder plug-in-unit atm custom e1 ima-group ima-link redundancy shdsl ether-itf traffic-overflow qos-queue temporal spatial (software-mngt sw-mgmt) xdsl xdsl-ext xdsl-tca olt-gen eo-conv authentication bonding sfp shdsl-isam custom-ext-alarm plug-in-unit-ext sip-user-agent sip-plugin-unit sip-termination e1-sip-termination filetransfer external-device l2forward ether-tca ether-sfp megaco-media-gw	type of the alarms that are active <i>This element is only shown in detail mode.</i>

name	Type	Description
	megaco-sig-gw megaco-plug-unit megaco-term megaco-sig-lt eqpt-supplemental eqpt-holder-ext lsmredundancy sync mcsrc vlanport vect-line vect-board otdr sip-dial-plan sip-vsp sip-server bgp rip lag ihub-general vprn isis ospf ihub-l2forward vpls ihub-equip ihub-link eont-phyoam ellid epon eont-services-lan eolt-ont-tca eont-sw-dl ldp mpls sdp epipe ihub-ipv6 pim li mgmt-sec-access bfd ai tr069serv ontsnmp bulk-sync protection-group ont sfu-sup soho-sup mdu-sup ont-ani sfu-sup2 soho-sup2 mdu-sup2 sfprssi eoltrssi	

101 query current alarms by filters

name	Type	Description
	cfm	
	sfpe1t1-framer	
	sfpe1t1-clock	
	pppcc-engine-tca	
	eth-cfm	
	rsvp	
	ihub-tca	
	eth-ring	
	efm-oam	
	ont-loopdetect	
	ont-video	
	ont-ces	
	ont-voip	
	ont-video-ani	
	ont-pwe	
	ont-cese1	
	ont-xdsl	
	ont-xdsl-tca	
	ont-hpna	
	ont-sip-agent-cfg	
	ont-voip-cfg	
	ont-mgc	
	ont-ploam	
	ont-gen	
	ont-card	
	ont-pots	
	ont-lan	
	ont-moca	
	ont-tc-tca	
	ont-moca-tca	
	ont-l2uni-eth-tca	
	olt-pon-tc-tca	
	olt-pon-util-tca	
	olt-chpr-util-tca	
	olt-ont-tc-tca	
	ont-tca	
	ont-pots-supplemental	
	sfu-ploam	
	sfu-gen	
	soho-ploam	
	soho-gen	
	mdu-ploam	
	mdu-gen	
	ont-veip	
	ont-iphost	
	alarm-table	
	auto-switch	
	channel-pair	
	ont-cfg-dld	
	olt-chpair-tc-tca	
	hgu-tr069	
	eqpt-psu	
	ont-protection	
	secondary-megaco-term	
	secondary-sip-term	
	cas-r2-channel	
	lldpmed	

name	Type	Description
	pseudo-wire link-agg fcs-exceed e1t1-interface) Possible values: - equipment : equipment alarms - eqpt-holder : equipment holder alarms - plug-in-unit : plugin unit alarms - atm : ATM alarms - custom : customizable alarms - e1 : e1 alarms - ima-group : ima-group alarms - ima-link : ima-link alarms - redundancy : redundancy alarms - shdsl : shdsl alarms - ether-itf : ethernet interface alarms - traffic-overflow : Traffic overflow alarms - qos-queue : qos queue alarms - temporal : temporal alarms - spatial : spatial alarms - software-mngt : software management alarms - sw-mgmt : software management alarms - xdsl : xDSL alarms - xdsl-ext : other xDSL alarms - xdsl-tca : xDSL threshold cross alarms - olt-gen : OLT general alarms - eo-conv : E/O conversion related alarms - authentication : authentication related alarms - bonding : bonding-group related alarms - sfp : SFP related alarms - shdsl-isam : shdsl isam alarms - custom-ext-alarm : customizable external alarms - plug-in-unit-ext : other plugin unit alarms - sip-user-agent : sip user agent related alarms - sip-plugin-unit : sip plug in unit related alarms - sip-termination : sip termination related alarms - e1-sip-termination : E1 sip termination related alarms - filetransfer : file transfer server alarms - external-device : external device related alarms - l2forward : l2forward related alarms - ether-tca : ethernet threshold cross alarms - ether-sfp : ethernet SFP related alarms - megaco-media-gw : megaco media gateway related alarms - megaco-sig-gw : megaco signaling gateway related alarms - megaco-plug-unit : megaco plug unit related alarms - megaco-term : megaco termination related alarms - megaco-sig-lt : megaco signaling lt related alarms - eqpt-supplemental : equipment supplemental alarms - eqpt-holder-ext : other equipment holder alarms - lsmredundancy : lsm redundancy alarms - sync : synce and bits alarms - mcsrc : multicast source alarms - vlanport : vlanport alarms - vect-line : xDSL vectoring line alarms - vect-board : xDSL vectoring board alarms - otdr : otdr alarms - sip-dial-plan : sip dial plan related alarms	

101 query current alarms by filters

name	Type	Description
	- sip-vsp : sip vsp related alarms - sip-server : sip server related alarms - bgp : bgp related alarms - rip : rip related alarms - lag : LAG related alarms - ihub-general : IHUB general related alarms - vprn : vprn related alarms - isis : isis related alarms - ospf : ospf related alarms - ihub-l2forward : ihub-l2forward alarms - vpls : vpls related alarms - ihub-equip : ihub-equip related alarms - ihub-link : ihub-link related alarms - eont-phyoam : eont phyoam related alarms - ellid : ellid related alarms - epon : epon related alarms - eont-services-lan : eon phyoam related alarms - eolt-ont-tca : eon phyoam related alarms - eont-sw-dl : eon phyoam related alarms - ldp : ldp related alarms - mpls : mpls related alarms - sdp : sdp related alarms - epipe : epipe related alarms - ihub-ipv6 : ihub-ipv6 related alarms - pim : pim related alarms - li : lawful intercept related alarms - mgmt-sec-access : management security related alarms - bfd : bfd related alarms - ai : Application Intelligence related alarms - tr069serv : tr069 server related alarms - ontsnmp : ont snmp related alarms - bulk-sync : bulk-sync related alarms - protection-group : port protection group related alarms - ont : ONT general supplemental related alarms - sfu-sup : SFU ONT general supplemental related alarms - soho-sup : SOHO ONT general supplemental related alarms - mdu-sup : MDU ONT general supplemental related alarms - ont-ani : ONT general supplemental 2 related alarms - sfu-sup2 : SFU ONT general supplemental 2 related alarms - soho-sup2 : SOHO ONT general supplemental 2 related alarms - mdu-sup2 : MDU ONT general supplemental 2 related alarms - sfprssi : SFP RSSI related alarms - eoltrssi : epon olt Sfp RSSI related alarms - cfm : Cfm related alarms - sfpe1t1-framer : SFP 2e1t1 framer alarms - sfpe1t1-clock : SFP 2e1t1 clock alarms - pppcc-engine-tca : PPPOE Cross Connect Engine TCA related alarm - eth-cfm : eth-cfm related alarms - rsvp : rsvp related alarms - ihub-tca : IHUB TCA related alarms - eth-ring : eth-ring related alarms - efm-oam : EFM-OAM related alarms - ont-loopdetect : ont loop detect related alarms	

name	Type	Description
	- ont-video : ont services video related alarms - ont-ces : ont services ces related alarms - ont-voip : ont services voip related alarms - ont-video-ani : ont services video ani related alarms - ont-pwe : ont services pwe related alarms - ont-cese1 : ont services cese1 related alarms - ont-xdsl : ont services xdsl related alarms - ont-xdsl-tca : ont services xdsl tca related alarms - ont-hpna : ont hpna related alarms - ont-sip-agent-cfg : ont services voip sip agent config related alarms - ont-voip-cfg : ont services voip config related alarms - ont-mgc : ont mgc related alarms - ont-ploam : ONT PLOAM related alarms - ont-gen : ONT GENERAL related alarms - ont-card : ONT Subscriber Card related alarms - ont-pots : ONT Services POTS related alarms - ont-lan : ONT Services LAN related alarms - ont-moca : ONT MoCA related alarms - ont-tc-tca : ONT TC TCA related alarms - ont-moca-tca : ONT MoCA TCA related alarms - ont-l2uni-eth-tca : ONT L2 UNI Ethernet TCA related alarms - olt-pon-tc-tca : OLT PON TC TCA related alarms - olt-pon-util-tca : OLT PON utilization TCA related alarms - olt-chpr-util-tca : OLT channel-pair utilization TCA related alarms - olt-ont-tc-tca : OLT ONT TC TCA related alarms - ont-tca : ONT TCA related alarms - ont-pots-supplemental : ONT POTS Supplemental related alarms - sfu-ploam : SFU ONT PLOAM related alarms - sfu-gen : SFU ONT general related alarms - soho-ploam : SOHO ONT PLOAM related alarms - soho-gen : SOHO ONT general related alarms - mdu-ploam : MDU ONT PLOAM related alarms - mdu-gen : MDU ONT general related alarms - ont-veip : ONT VEIP related alarms - ont-iphost : ONT IP HOST related alarms - alarm-table : alarm table related alarms - auto-switch : auto-switch related alarms - channel-pair : channel pair related alarms - ont-cfg-dld : ont configure file download related alarms - olt-chpair-tc-tca : OLT CHANNELPAIR TC TCA related alarms - hgu-tr069 : hgu tr069 related alarms - eqpt-psu : equipment psu alarms - ont-protection : ONT protection related alarms - secondary-megaco-term : secondary megaco termination related alarms - secondary-sip-term : secondary sip termination related alarms - cas-r2-channel : CAS R2 channel related alarms - lldpmed : lldpmed alarms - pseudo-wire : pseudo Wire related alarms - link-agg : Link aggregation related alarms - fcs-exceed : FCS auto-recovery related alarms	

101 query current alarms by filters

name	Type	Description
	- e1t1-interface : E1/T1 physical interfaces related alarms	
name	Parameter type: <Alarm::alarmTypeLdpHub> (ldp-instance-down ldp-session-down all) Possible values: - ldp-instance-down : ldp instance down - ldp-session-down : ldp session down - all : ldp related alarms	alarm name that are active <i>This element is only shown in detail mode.</i>
severity	Parameter type: <Alarm::AlarmSeverity> (indeterminate warning minor major critical) Possible values: - indeterminate : alarm severity is indeterminate - warning : alarm severity is warning - minor : alarm severity is minor - major : alarm severity is major - critical : alarm severity is critical	the alarms severity level <i>This element is only shown in detail mode.</i>
servaff	Parameter type: <Alarm::alarmServAffect> ((service-affecting yes) (noservice-affecting no)) Possible values: - service-affecting : make this alarm service affecting - yes : make this alarm service affecting - noservice-affecting : make this alarm not service affecting - no : make this alarm not service affecting	alarms affect service or not <i>This element is only shown in detail mode.</i>
time	Parameter type: <Sys::timeInSecs> - the time (yyyy-mm-dd:hour:minutes:secs) - unit: UTC	time in seconds when alarm was updated <i>This element is only shown in detail mode.</i>
descript	Parameter type: <Alarm::AddInfoString> - additional alarm information	alarm description <i>This element is only shown in detail mode.</i>

101.101 show current alarm by filters

Command Description

show current alarms by filters

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm query mpls [ (name) [ severity <Alarm::querySeverity> ] [ servaff <Alarm::queryServAffect> ] [
router-id <lhub::baseRouter> ] ]
```

Command Parameters

Table 101.101-1 "show current alarm by filters" Resource Parameters

Resource Identifier	Type	Description
(name)	Format: (mpls-instance-down mpls-lsp-down mpls-lsp-path-down all) Possible values: - mpls-instance-down : mpls instance down - mpls-lsp-down : lsp down - mpls-lsp-path-down : lsp path down - all : mpls related alarms	alarm name of mpls
severity	Parameter type: <Alarm::querySeverity> Format: (indeterminate warning minor major critical all) Possible values: - indeterminate : alarm severity is indeterminate - warning : alarm severity is warning - minor : alarm severity is minor - major : alarm severity is major - critical : alarm severity is critical - all : all alarm severity	severity level of an alarm for reporting
servaff	Parameter type: <Alarm::queryServAffect> Format: (service-affecting	serviceaffecting no

101 query current alarms by filters

Resource Identifier	Type	Description
	noservice-affecting all) Possible values: - service-affecting : query alarm service affecting - noservice-affecting : query alarm not service affecting - all : query service affecting and not affecting alarms	
router-id	Parameter type: <Ihub::baseRouter> Format: base Possible values: - base : base router	identifies the base router

Command Output

Table 101.101-2 "show current alarm by filters" Display parameters

Specific Information		
name	Type	Description
aidinfo	Parameter type: <Alarm::AddInfoString> - additional alarm information	alarm AID parameters <i>This element is only shown in detail mode.</i>
type	Parameter type: <Alarm::alarmIHUBType> (equipment eqpt-holder plug-in-unit atm custom e1 ima-group ima-link redundancy shdsl ether-itf traffic-overflow qos-queue temporal spatial (software-mngt sw-mgmt) xdsl xdsl-ext xdsl-tca olt-gen eo-conv authentication bonding sfp shdsl-isam custom-ext-alarm plug-in-unit-ext sip-user-agent sip-plugin-unit sip-termination e1-sip-termination filetransfer external-device l2forward ether-tca	type of the alarms that are active <i>This element is only shown in detail mode.</i>

name	Type	Description
	ether-sfp	
	megaco-media-gw	
	megaco-sig-gw	
	megaco-plug-unit	
	megaco-term	
	megaco-sig-lt	
	eqpt-supplemental	
	eqpt-holder-ext	
	lsmredundancy	
	sync	
	mcsrc	
	vlanport	
	vect-line	
	vect-board	
	otdr	
	sip-dial-plan	
	sip-vsp	
	sip-server	
	bgp	
	rip	
	lag	
	ihub-general	
	vprn	
	isis	
	ospf	
	ihub-l2forward	
	vpls	
	ihub-equip	
	ihub-link	
	eont-phyoam	
	ellid	
	epon	
	eont-services-lan	
	eolt-ont-tca	
	eont-sw-dl	
	ldp	
	mpls	
	sdp	
	epipe	
	ihub-ipv6	
	pim	
	li	
	mgmt-sec-access	
	bfd	
	ai	
	tr069serv	
	ontsnmp	
	bulk-sync	
	protection-group	
	ont	
	sfu-sup	
	soho-sup	
	mdu-sup	
	ont-ani	
	sfu-sup2	
	soho-sup2	
	mdu-sup2	

101 query current alarms by filters

name	Type	Description
	sfrssi eoltrssi cfm sfpe1t1-framer sfpe1t1-clock pppcc-engine-tca eth-cfm rsvp ihub-tca eth-ring efm-oam ont-loopdetect ont-video ont-ces ont-voip ont-video-ani ont-pwe ont-cese1 ont-xdsl ont-xdsl-tca ont-hpna ont-sip-agent-cfg ont-voip-cfg ont-mgc ont-ploam ont-gen ont-card ont-pots ont-lan ont-moca ont-tc-tca ont-moca-tca ont-l2uni-eth-tca olt-pon-tc-tca olt-pon-util-tca olt-chpr-util-tca olt-ont-tc-tca ont-tca ont-pots-supplemental sfu-ploam sfu-gen soho-ploam soho-gen mdu-ploam mdu-gen ont-veip ont-iphost alarm-table auto-switch channel-pair ont-cfg-dld olt-chpair-tc-tca hgu-tr069 eqpt-psu ont-protection secondary-megaco-term secondary-sip-term	

name	Type	Description
	cas-r2-channel lldpmed pseudo-wire link-agg fcs-exceed e1t1-interface) Possible values: - equipment : equipment alarms - eqpt-holder : equipment holder alarms - plug-in-unit : plugin unit alarms - atm : ATM alarms - custom : customizable alarms - e1 : e1 alarms - ima-group : ima-group alarms - ima-link : ima-link alarms - redundancy : redundancy alarms - shdsl : shdsl alarms - ether-itf : ethernet interface alarms - traffic-overflow : Traffic overflow alarms - qos-queue : qos queue alarms - temporal : temporal alarms - spatial : spatial alarms - software-mngt : software management alarms - sw-mgmt : software management alarms - xdsl : xDSL alarms - xdsl-ext : other xDSL alarms - xdsl-tca : xDSL threshold cross alarms - olt-gen : OLT general alarms - eo-conv : E/O conversion related alarms - authentication : authentication related alarms - bonding : bonding-group related alarms - sfp : SFP related alarms - shdsl-isam : shdsl isam alarms - custom-ext-alarm : customizable external alarms - plug-in-unit-ext : other plugin unit alarms - sip-user-agent : sip user agent related alarms - sip-plugin-unit : sip plug in unit related alarms - sip-termination : sip termination related alarms - e1-sip-termination : E1 sip termination related alarms - filetransfer : file transfer server alarms - external-device : external device related alarms - l2forward : l2forward related alarms - ether-tca : ethernet threshold cross alarms - ether-sfp : ethernet SFP related alarms - megaco-media-gw : megaco media gateway related alarms - megaco-sig-gw : megaco signaling gateway related alarms - megaco-plug-unit : megaco plug unit related alarms - megaco-term : megaco termination related alarms - megaco-sig-lt : megaco signaling lt related alarms - eqpt-supplemental : equipment supplemental alarms - eqpt-holder-ext : other equipment holder alarms - lsmredundancy : lsm redundancy alarms - sync : synce and bits alarms - mcsrc : multicast source alarms - vlanport : vlanport alarms - vect-line : xDSL vectoring line alarms - vect-board : xDSL vectoring board alarms	

101 query current alarms by filters

name	Type	Description
	- otdr : otdr alarms - sip-dial-plan : sip dial plan related alarms - sip-vsp : sip vsp related alarms - sip-server : sip server related alarms - bgp : bgp related alarms - rip : rip related alarms - lag : LAG related alarms - ihub-general : IHUB general related alarms - vprn : vprn related alarms - isis : isis related alarms - ospf : ospf related alarms - ihub-l2forward : ihub-l2forward alarms - vpls : vpls related alarms - ihub-equip : ihub-equip related alarms - ihub-link : ihub-link related alarms - eont-phyoam : eont phyoam related alarms - ellid : ellid related alarms - epon : epon related alarms - eont-services-lan : eon phyoam related alarms - eolt-ont-tca : eon phyoam related alarms - eont-sw-dl : eon phyoam related alarms - ldp : ldp related alarms - mpls : mpls related alarms - sdp : sdp related alarms - epipe : epipe related alarms - ihub-ipv6 : ihub-ipv6 related alarms - pim : pim related alarms - li : lawful intercept related alarms - mgmt-sec-access : management security related alarms - bfd : bfd related alarms - ai : Application Intelligence related alarms - tr069serv : tr069 server related alarms - ontsnmp : ont snmp related alarms - bulk-sync : bulk-sync related alarms - protection-group : port protection group related alarms - ont : ONT general supplemental related alarms - sfu-sup : SFU ONT general supplemental related alarms - soho-sup : SOHO ONT general supplemental related alarms - mdu-sup : MDU ONT general supplemental related alarms - ont-ani : ONT general supplemental 2 related alarms - sfu-sup2 : SFU ONT general supplemental 2 related alarms - soho-sup2 : SOHO ONT general supplemental 2 related alarms - mdu-sup2 : MDU ONT general supplemental 2 related alarms - sfprssi : SFP RSSI related alarms - eoltrssi : epon olt Sfp RSSI related alarms - cfm : Cfm related alarms - sfpe1t1-framer : SFP 2e1t1 framer alarms - sfpe1t1-clock : SFP 2e1t1 clock alarms - pppcc-engine-tca : PPPOE Cross Connect Engine TCA related alarm - eth-cfm : eth-cfm related alarms - rsvp : rsvp related alarms - ihub-tca : IHUB TCA related alarms - eth-ring : eth-ring related alarms	

name	Type	Description
	- efm-oam : EFM-OAM related alarms - ont-loopdetect : ont loop detect related alarms - ont-video : ont services video related alarms - ont-ces : ont services ces related alarms - ont-voip : ont services voip related alarms - ont-video-ani : ont services video ani related alarms - ont-pwe : ont services pwe related alarms - ont-cese1 : ont services cese1 related alarms - ont-xdsl : ont services xdsl related alarms - ont-xdsl-tca : ont services xdsl tca related alarms - ont-hpna : ont hpna related alarms - ont-sip-agent-cfg : ont services voip sip agent config related alarms - ont-voip-cfg : ont services voip config related alarms - ont-mgc : ont mgc related alarms - ont-ploam : ONT PLOAM related alarms - ont-gen : ONT GENERAL related alarms - ont-card : ONT Subscriber Card related alarms - ont-pots : ONT Services POTS related alarms - ont-lan : ONT Services LAN related alarms - ont-moca : ONT MoCA related alarms - ont-tc-tca : ONT TC TCA related alarms - ont-moca-tca : ONT MoCA TCA related alarms - ont-l2uni-eth-tca : ONT L2 UNI Ethernet TCA related alarms - olt-pon-tc-tca : OLT PON TC TCA related alarms - olt-pon-util-tca : OLT PON utilization TCA related alarms - olt-chpr-util-tca : OLT channel-pair utilization TCA related alarms - olt-ont-tc-tca : OLT ONT TC TCA related alarms - ont-tca : ONT TCA related alarms - ont-pots-supplemental : ONT POTS Supplemental related alarms - sfu-ploam : SFU ONT PLOAM related alarms - sfu-gen : SFU ONT general related alarms - soho-ploam : SOHO ONT PLOAM related alarms - soho-gen : SOHO ONT general related alarms - mdu-ploam : MDU ONT PLOAM related alarms - mdu-gen : MDU ONT general related alarms - ont-veip : ONT VEIP related alarms - ont-iphost : ONT IP HOST related alarms - alarm-table : alarm table related alarms - auto-switch : auto-switch related alarms - channel-pair : channel pair related alarms - ont-cfg-dld : ont configure file download related alarms - olt-chpair-tc-tca : OLT CHANNELPAIR TC TCA related alarms - hgu-tr069 : hgu tr069 related alarms - eqpt-psu : equipment psu alarms - ont-protection : ONT protection related alarms - secondary-megaco-term : secondary megaco termination related alarms - secondary-sip-term : secondary sip termination related alarms - cas-r2-channel : CAS R2 channel related alarms - lldpmed : lldpmed alarms - pseudo-wire : pseudo Wire related alarms	

101 query current alarms by filters

name	Type	Description
	- link-aggr : Link aggregation related alarms - fcs-exceed : FCS auto-recovery related alarms - e1t1-interface : E1/T1 physical interfaces related alarms	
name	Parameter type: <Alarm::almtypeMplsihub> (mpls-instance-down mpls-lsp-down mpls-lsp-path-down all) Possible values: - mpls-instance-down : mpls instance down - mpls-lsp-down : lsp down - mpls-lsp-path-down : lsp path down - all : mpls related alarms	alarm name that are active <i>This element is only shown in detail mode.</i>
severity	Parameter type: <Alarm::AlarmSeverity> (indeterminate warning minor major critical) Possible values: - indeterminate : alarm severity is indeterminate - warning : alarm severity is warning - minor : alarm severity is minor - major : alarm severity is major - critical : alarm severity is critical	the alarms severity level <i>This element is only shown in detail mode.</i>
servaff	Parameter type: <Alarm::alarmServAffect> ((service-affecting yes) (noservice-affecting no)) Possible values: - service-affecting : make this alarm service affecting - yes : make this alarm service affecting - noservice-affecting : make this alarm not service affecting - no : make this alarm not service affecting	alarms affect service or not <i>This element is only shown in detail mode.</i>
time	Parameter type: <Sys::timeInSecs> - the time (yyyy-mm-dd:hour:minutes:secs) - unit: UTC	time in seconds when alarm was updated <i>This element is only shown in detail mode.</i>
descript	Parameter type: <Alarm::AddInfoString> - additional alarm information	alarm description <i>This element is only shown in detail mode.</i>

101.102 show current alarm by filters

Command Description

show current alarms by filters

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm query sdp [ (name) [ severity <Alarm::querySeverity> ] [ servaff <Alarm::queryServAffect> ] [ sdp-id <Alarm::SdpId> ] ]
```

Command Parameters

Table 101.102-1 "show current alarm by filters" Resource Parameters

Resource Identifier	Type	Description
(name)	Format: (sdp-instance-down sdp-binding-down all) Possible values: - sdp-instance-down : sdp instance down - sdp-binding-down : sdp binding down - all : sdp related alarms	alarm name of sdp
severity	Parameter type: <Alarm::querySeverity> Format: (indeterminate warning minor major critical all) Possible values: - indeterminate : alarm severity is indeterminate - warning : alarm severity is warning - minor : alarm severity is minor - major : alarm severity is major - critical : alarm severity is critical - all : all alarm severity	severity level of an alarm for reporting
servaff	Parameter type: <Alarm::queryServAffect> Format: (service-affecting noservice-affecting all)	serviceaffecting no

101 query current alarms by filters

Resource Identifier	Type	Description
	Possible values: - service-affecting : query alarm service affecting - noservice-affecting : query alarm not service affecting - all : query service affecting and not affecting alarms	
sdp-id	Parameter type: <Alarm::SdpId> Format: - sdp-id value - range: [1...17407]	identifies the sdp-id of the sdp binding

Command Output

Table 101.102-2 "show current alarm by filters" Display parameters

Specific Information		
name	Type	Description
aidinfo	Parameter type: <Alarm::AddInfoString> - additional alarm information	alarm AID parameters <i>This element is only shown in detail mode.</i>
type	Parameter type: <Alarm::alarmIHUBType> (equipment eqpt-holder plug-in-unit atm custom e1 ima-group ima-link redundancy shdsl ether-itf traffic-overflow qos-queue temporal spatial (software-mngt sw-mgmt) xdsl xdsl-ext xdsl-tca olt-gen eo-conv authentication bonding sfp shdsl-isam custom-ext-alarm plug-in-unit-ext sip-user-agent sip-plugin-unit sip-termination e1-sip-termination filetransfer external-device l2forward ether-tca ether-sfp megaco-media-gw megaco-sig-gw	type of the alarms that are active <i>This element is only shown in detail mode.</i>

name	Type	Description
	megaco-plug-unit	
	megaco-term	
	megaco-sig-lt	
	eqpt-supplemental	
	eqpt-holder-ext	
	lsmredundancy	
	sync	
	mcsrc	
	vlanport	
	vect-line	
	vect-board	
	otdr	
	sip-dial-plan	
	sip-vsp	
	sip-server	
	bgp	
	rip	
	lag	
	ihub-general	
	vprn	
	isis	
	ospf	
	ihub-l2forward	
	vpls	
	ihub-equip	
	ihub-link	
	eont-phyoam	
	ellid	
	epon	
	eont-services-lan	
	eolt-ont-tca	
	eont-sw-dl	
	ldp	
	mpls	
	sdp	
	epipe	
	ihub-ipv6	
	pim	
	li	
	mgmt-sec-access	
	bfd	
	ai	
	tr069serv	
	ontsnmp	
	bulk-sync	
	protection-group	
	ont	
	sfu-sup	
	soho-sup	
	mdu-sup	
	ont-ani	
	sfu-sup2	
	soho-sup2	
	mdu-sup2	
	sfprssi	
	eoltrssi	
	cfm	

101 query current alarms by filters

name	Type	Description
	sfpe1t1-framer sfpe1t1-clock pppcc-engine-tca eth-cfm rsvp ihub-tca eth-ring efm-oam ont-loopdetect ont-video ont-ces ont-voip ont-video-ani ont-pwe ont-cese1 ont-xdsl ont-xdsl-tca ont-hpna ont-sip-agent-cfg ont-voip-cfg ont-mgc ont-ploam ont-gen ont-card ont-pots ont-lan ont-moca ont-tc-tca ont-moca-tca ont-l2uni-eth-tca olt-pon-tc-tca olt-pon-util-tca olt-chpr-util-tca olt-ont-tc-tca ont-tca ont-pots-supplemental sfu-ploam sfu-gen soho-ploam soho-gen mdu-ploam mdu-gen ont-veip ont-iphost alarm-table auto-switch channel-pair ont-cfg-dld olt-chpair-tc-tca hgu-tr069 eqpt-psu ont-protection secondary-megaco-term secondary-sip-term cas-r2-channel lldpmed pseudo-wire	

name	Type	Description
	link-agg fcs-exceed e1t1-interface) Possible values: - equipment : equipment alarms - eqpt-holder : equipment holder alarms - plug-in-unit : plugin unit alarms - atm : ATM alarms - custom : customizable alarms - e1 : e1 alarms - ima-group : ima-group alarms - ima-link : ima-link alarms - redundancy : redundancy alarms - shdsl : shdsl alarms - ether-itf : ethernet interface alarms - traffic-overflow : Traffic overflow alarms - qos-queue : qos queue alarms - temporal : temporal alarms - spatial : spatial alarms - software-mngt : software management alarms - sw-mgmt : software management alarms - xdsl : xDSL alarms - xdsl-ext : other xDSL alarms - xdsl-tca : xDSL threshold cross alarms - olt-gen : OLT general alarms - eo-conv : E/O conversion related alarms - authentication : authentication related alarms - bonding : bonding-group related alarms - sfp : SFP related alarms - shdsl-isam : shdsl isam alarms - custom-ext-alarm : customizable external alarms - plug-in-unit-ext : other plugin unit alarms - sip-user-agent : sip user agent related alarms - sip-plugin-unit : sip plug in unit related alarms - sip-termination : sip termination related alarms - e1-sip-termination : E1 sip termination related alarms - filetransfer : file transfer server alarms - external-device : external device related alarms - l2forward : l2forward related alarms - ether-tca : ethernet threshold cross alarms - ether-sfp : ethernet SFP related alarms - megaco-media-gw : megaco media gateway related alarms - megaco-sig-gw : megaco signaling gateway related alarms - megaco-plug-unit : megaco plug unit related alarms - megaco-term : megaco termination related alarms - megaco-sig-lt : megaco signaling lt related alarms - eqpt-supplemental : equipment supplemental alarms - eqpt-holder-ext : other equipment holder alarms - lsmredundancy : lsm redundancy alarms - sync : synce and bits alarms - mcsrc : multicast source alarms - vlanport : vlanport alarms - vect-line : xDSL vectoring line alarms - vect-board : xDSL vectoring board alarms - otdr : otdr alarms - sip-dial-plan : sip dial plan related alarms - sip-vsp : sip vsp related alarms	

101 query current alarms by filters

name	Type	Description
	- sip-server : sip server related alarms - bgp : bgp related alarms - rip : rip related alarms - lag : LAG related alarms - ihub-general : IHUB general related alarms - vprn : vprn related alarms - isis : isis related alarms - ospf : ospf related alarms - ihub-l2forward : ihub-l2forward alarms - vpls : vpls related alarms - ihub-equip : ihub-equip related alarms - ihub-link : ihub-link related alarms - eont-phyoam : eont phyoam related alarms - ellid : ellid related alarms - epon : epon related alarms - eont-services-lan : eon phyoam related alarms - eolt-ont-tca : eon phyoam related alarms - eont-sw-dl : eon phyoam related alarms - ldp : ldp related alarms - mpls : mpls related alarms - sdp : sdp related alarms - epipe : epipe related alarms - ihub-ipv6 : ihub-ipv6 related alarms - pim : pim related alarms - li : lawful intercept related alarms - mgmt-sec-access : management security related alarms - bfd : bfd related alarms - ai : Application Intelligence related alarms - tr069serv : tr069 server related alarms - ontsnmp : ont snmp related alarms - bulk-sync : bulk-sync related alarms - protection-group : port protection group related alarms - ont : ONT general supplemental related alarms - sfu-sup : SFU ONT general supplemental related alarms - soho-sup : SOHO ONT general supplemental related alarms - mdu-sup : MDU ONT general supplemental related alarms - ont-ani : ONT general supplemental 2 related alarms - sfu-sup2 : SFU ONT general supplemental 2 related alarms - soho-sup2 : SOHO ONT general supplemental 2 related alarms - mdu-sup2 : MDU ONT general supplemental 2 related alarms - sfprssi : SFP RSSI related alarms - eoltrssi : epon olt Sfp RSSI related alarms - cfm : Cfm related alarms - sfpe1t1-framer : SFP 2e1t1 framer alarms - sfpe1t1-clock : SFP 2e1t1 clock alarms - pppcc-engine-tca : PPPOE Cross Connect Engine TCA related alarm - eth-cfm : eth-cfm related alarms - rsvp : rsvp related alarms - ihub-tca : IHUB TCA related alarms - eth-ring : eth-ring related alarms - efm-oam : EFM-OAM related alarms - ont-loopdetect : ont loop detect related alarms - ont-video : ont services video related alarms	

name	Type	Description
	- ont-ces : ont services ces related alarms - ont-voip : ont services voip related alarms - ont-video-ani : ont services video ani related alarms - ont-pwe : ont services pwe related alarms - ont-cese1 : ont services cese1 related alarms - ont-xdsl : ont services xdsl related alarms - ont-xdsl-tca : ont services xdsl tca related alarms - ont-hpna : ont hpna related alarms - ont-sip-agent-cfg : ont services voip sip agent config related alarms - ont-voip-cfg : ont services voip config related alarms - ont-mgc : ont mgc related alarms - ont-ploam : ONT PLOAM related alarms - ont-gen : ONT GENERAL related alarms - ont-card : ONT Subscriber Card related alarms - ont-pots : ONT Services POTS related alarms - ont-lan : ONT Services LAN related alarms - ont-moca : ONT MoCA related alarms - ont-tc-tca : ONT TC TCA related alarms - ont-moca-tca : ONT MoCA TCA related alarms - ont-l2uni-eth-tca : ONT L2 UNI Ethernet TCA related alarms - olt-pon-tc-tca : OLT PON TC TCA related alarms - olt-pon-util-tca : OLT PON utilization TCA related alarms - olt-chpr-util-tca : OLT channel-pair utilization TCA related alarms - olt-ont-tc-tca : OLT ONT TC TCA related alarms - ont-tca : ONT TCA related alarms - ont-pots-supplemental : ONT POTS Supplemental related alarms - sfu-ploam : SFU ONT PLOAM related alarms - sfu-gen : SFU ONT general related alarms - soho-ploam : SOHO ONT PLOAM related alarms - soho-gen : SOHO ONT general related alarms - mdu-ploam : MDU ONT PLOAM related alarms - mdu-gen : MDU ONT general related alarms - ont-veip : ONT VEIP related alarms - ont-iphost : ONT IP HOST related alarms - alarm-table : alarm table related alarms - auto-switch : auto-switch related alarms - channel-pair : channel pair related alarms - ont-cfg-dld : ont configure file download related alarms - olt-chpair-tc-tca : OLT CHANNELPAIR TC TCA related alarms - hgu-tr069 : hgu tr069 related alarms - eqpt-psu : equipment psu alarms - ont-protection : ONT protection related alarms - secondary-megaco-term : secondary megaco termination related alarms - secondary-sip-term : secondary sip termination related alarms - cas-r2-channel : CAS R2 channel related alarms - lldpmed : lldpmed alarms - pseudo-wire : pseudo Wire related alarms - link-agg : Link aggregation related alarms - fcs-exceed : FCS auto-recovery related alarms - e1t1-interface : E1/T1 physical interfaces related alarms	

101 query current alarms by filters

name	Type	Description
name	Parameter type: <Alarm::almltypeSdpihub> (sdp-instance-down sdp-binding-down all) Possible values: - sdp-instance-down : sdp instance down - sdp-binding-down : sdp binding down - all : sdp related alarms	alarm name that are active <i>This element is only shown in detail mode.</i>
severity	Parameter type: <Alarm::AlarmSeverity> (indeterminate warning minor major critical) Possible values: - indeterminate : alarm severity is indeterminate - warning : alarm severity is warning - minor : alarm severity is minor - major : alarm severity is major - critical : alarm severity is critical	the alarms severity level <i>This element is only shown in detail mode.</i>
servaff	Parameter type: <Alarm::alarmServAffect> ((service-affecting yes) (noservice-affecting no)) Possible values: - service-affecting : make this alarm service affecting - yes : make this alarm service affecting - noservice-affecting : make this alarm not service affecting - no : make this alarm not service affecting	alarms affect service or not <i>This element is only shown in detail mode.</i>
time	Parameter type: <Sys::timeInSecs> - the time (yyyy-mm-dd:hour:minutes:secs) - unit: UTC	time in seconds when alarm was updated <i>This element is only shown in detail mode.</i>
descript	Parameter type: <Alarm::AddInfoString> - additional alarm information	alarm description <i>This element is only shown in detail mode.</i>

101.103 show current alarm by filters

Command Description

show current alarms by filters

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm query epipe [ (name) [ severity <Alarm::querySeverity> ] [ servaff <Alarm::queryServAffect> ] [ service-id <Alarm::ServiceId> ] ]
```

Command Parameters

Table 101.103-1 "show current alarm by filters" Resource Parameters

Resource Identifier	Type	Description
(name)	Format: (epipe-instance-down all) Possible values: - epipe-instance-down : epipe instance down - all : epipe related alarms	alarm name of epipe
severity	Parameter type: <Alarm::querySeverity> Format: (indeterminate warning minor major critical all) Possible values: - indeterminate : alarm severity is indeterminate - warning : alarm severity is warning - minor : alarm severity is minor - major : alarm severity is major - critical : alarm severity is critical - all : all alarm severity	severity level of an alarm for reporting
servaff	Parameter type: <Alarm::queryServAffect> Format: (service-affecting noservice-affecting all) Possible values: - service-affecting : query alarm service affecting	serviceaffecting no

101 query current alarms by filters

Resource Identifier	Type	Description
	- noservice-affecting : query alarm not service affecting - all : query service affecting and not affecting alarms	
service-id	Parameter type: <Alarm::ServiceId> Format: - a profile index value - range: [1...2147483647]	identifies the epipe service-id

Command Output

Table 101.103-2 "show current alarm by filters" Display parameters

Specific Information		
name	Type	Description
aidinfo	Parameter type: <Alarm::AddInfoString> - additional alarm information	alarm AID parameters <i>This element is only shown in detail mode.</i>
type	Parameter type: <Alarm::alarmIHUBType> (equipment eqpt-holder plug-in-unit atm custom e1 ima-group ima-link redundancy shdsl ether-itf traffic-overflow qos-queue temporal spatial (software-mngt sw-mgmt) xdsl xdsl-ext xdsl-tca olt-gen eo-conv authentication bonding sfp shdsl-isam custom-ext-alarm plug-in-unit-ext sip-user-agent sip-plugin-unit sip-termination e1-sip-termination filetransfer external-device l2forward ether-tca ether-sfp megaco-media-gw megaco-sig-gw megaco-plug-unit megaco-term	type of the alarms that are active <i>This element is only shown in detail mode.</i>

name	Type	Description
	megaco-sig-lt	
	eqpt-supplemental	
	eqpt-holder-ext	
	lsmredundancy	
	sync	
	mcsrc	
	vlanport	
	vect-line	
	vect-board	
	otdr	
	sip-dial-plan	
	sip-vsp	
	sip-server	
	bgp	
	rip	
	lag	
	ihub-general	
	vprn	
	isis	
	ospf	
	ihub-l2forward	
	vpls	
	ihub-equip	
	ihub-link	
	eont-phyoam	
	ellid	
	epon	
	eont-services-lan	
	eolt-ont-tca	
	eont-sw-dl	
	ldp	
	mpls	
	sdp	
	epipe	
	ihub-ipv6	
	pim	
	li	
	mgmt-sec-access	
	bfd	
	ai	
	tr069serv	
	ontsnmp	
	bulk-sync	
	protection-group	
	ont	
	sfu-sup	
	soho-sup	
	mdu-sup	
	ont-ani	
	sfu-sup2	
	soho-sup2	
	mdu-sup2	
	sfprssi	
	eoltrssi	
	cfm	
	sfpe1t1-framer	
	sfpe1t1-clock	

101 query current alarms by filters

name	Type	Description
	pppcc-engine-tca eth-cfm rsvp ihub-tca eth-ring efm-oam ont-loopdetect ont-video ont-ces ont-voip ont-video-ani ont-pwe ont-cese1 ont-xdsl ont-xdsl-tca ont-hpna ont-sip-agent-cfg ont-voip-cfg ont-mgc ont-ploam ont-gen ont-card ont-pots ont-lan ont-moca ont-tc-tca ont-moca-tca ont-l2uni-eth-tca olt-pon-tc-tca olt-pon-util-tca olt-chpr-util-tca olt-ont-tc-tca ont-tca ont-pots-supplemental sfu-ploam sfu-gen soho-ploam soho-gen mdu-ploam mdu-gen ont-veip ont-iphost alarm-table auto-switch channel-pair ont-cfg-dld olt-chpair-tc-tca hgu-tr069 eqpt-psu ont-protection secondary-megaco-term secondary-sip-term cas-r2-channel lldpmed pseudo-wire link-agg fcs-exceed	

name	Type	Description
	e1t1-interface) Possible values: - equipment : equipment alarms - eqpt-holder : equipment holder alarms - plug-in-unit : plugin unit alarms - atm : ATM alarms - custom : customizable alarms - e1 : e1 alarms - ima-group : ima-group alarms - ima-link : ima-link alarms - redundancy : redundancy alarms - shdsl : shdsl alarms - ether-itf : ethernet interface alarms - traffic-overflow : Traffic overflow alarms - qos-queue : qos queue alarms - temporal : temporal alarms - spatial : spatial alarms - software-mngt : software management alarms - sw-mgmt : software management alarms - xdsl : xDSL alarms - xdsl-ext : other xDSL alarms - xdsl-tca : xDSL threshold cross alarms - olt-gen : OLT general alarms - eo-conv : E/O conversion related alarms - authentication : authentication related alarms - bonding : bonding-group related alarms - sfp : SFP related alarms - shdsl-isam : shdsl isam alarms - custom-ext-alarm : customizable external alarms - plug-in-unit-ext : other plugin unit alarms - sip-user-agent : sip user agent related alarms - sip-plugin-unit : sip plug in unit related alarms - sip-termination : sip termination related alarms - e1-sip-termination : E1 sip termination related alarms - filetransfer : file transfer server alarms - external-device : external device related alarms - l2forward : l2forward related alarms - ether-tca : ethernet threshold cross alarms - ether-sfp : ethernet SFP related alarms - megaco-media-gw : megaco media gateway related alarms - megaco-sig-gw : megaco signaling gateway related alarms - megaco-plug-unit : megaco plug unit related alarms - megaco-term : megaco termination related alarms - megaco-sig-lt : megaco signaling lt related alarms - eqpt-supplemental : equipment supplemental alarms - eqpt-holder-ext : other equipment holder alarms - lsmredundancy : lsm redundancy alarms - sync : synce and bits alarms - mcsrc : multicast source alarms - vlanport : vlanport alarms - vect-line : xDSL vectoring line alarms - vect-board : xDSL vectoring board alarms - otdr : otdr alarms - sip-dial-plan : sip dial plan related alarms - sip-vsp : sip vsp related alarms - sip-server : sip server related alarms - bgp : bgp related alarms	

101 query current alarms by filters

name	Type	Description
	- rip : rip related alarms - lag : LAG related alarms - ihub-general : IHUB general related alarms - vprn : vprn related alarms - isis : isis related alarms - ospf : ospf related alarms - ihub-l2forward : ihub-l2forward alarms - vpls : vpls related alarms - ihub-equip : ihub-equip related alarms - ihub-link : ihub-link related alarms - eont-phyoam : eont phyoam related alarms - ellid : ellid related alarms - epon : epon related alarms - eont-services-lan : eon phyoam related alarms - eolt-ont-tca : eon phyoam related alarms - eont-sw-dl : eon phyoam related alarms - ldp : ldp related alarms - mpls : mpls related alarms - sdp : sdp related alarms - epipe : epipe related alarms - ihub-ipv6 : ihub-ipv6 related alarms - pim : pim related alarms - li : lawful intercept related alarms - mgmt-sec-access : management security related alarms - bfd : bfd related alarms - ai : Application Intelligence related alarms - tr069serv : tr069 server related alarms - ontsnmp : ont snmp related alarms - bulk-sync : bulk-sync related alarms - protection-group : port protection group related alarms - ont : ONT general supplemental related alarms - sfu-sup : SFU ONT general supplemental related alarms - soho-sup : SOHO ONT general supplemental related alarms - mdu-sup : MDU ONT general supplemental related alarms - ont-ani : ONT general supplemental 2 related alarms - sfu-sup2 : SFU ONT general supplemental 2 related alarms - soho-sup2 : SOHO ONT general supplemental 2 related alarms - mdu-sup2 : MDU ONT general supplemental 2 related alarms - sfprssi : SFP RSSI related alarms - eoltrssi : epon olt Sfp RSSI related alarms - cfm : Cfm related alarms - sfpe1t1-framer : SFP 2e1t1 framer alarms - sfpe1t1-clock : SFP 2e1t1 clock alarms - pppcc-engine-tca : PPPOE Cross Connect Engine TCA related alarm - eth-cfm : eth-cfm related alarms - rsvp : rsvp related alarms - ihub-tca : IHUB TCA related alarms - eth-ring : eth-ring related alarms - efm-oam : EFM-OAM related alarms - ont-loopdetect : ont loop detect related alarms - ont-video : ont services video related alarms - ont-ces : ont services ces related alarms - ont-voip : ont services voip related alarms	

name	Type	Description
	- ont-video-ani : ont services video ani related alarms - ont-pwe : ont services pwe related alarms - ont-cese1 : ont services cese1 related alarms - ont-xdsl : ont services xdsl related alarms - ont-xdsl-tca : ont services xdsl tca related alarms - ont-hpna : ont hpna related alarms - ont-sip-agent-cfg : ont services voip sip agent config related alarms - ont-voip-cfg : ont services voip config related alarms - ont-mgc : ont mgc related alarms - ont-ploam : ONT PLOAM related alarms - ont-gen : ONT GENERAL related alarms - ont-card : ONT Subscriber Card related alarms - ont-pots : ONT Services POTS related alarms - ont-lan : ONT Services LAN related alarms - ont-moca : ONT MoCA related alarms - ont-tc-tca : ONT TC TCA related alarms - ont-moca-tca : ONT MoCA TCA related alarms - ont-l2uni-eth-tca : ONT L2 UNI Ethernet TCA related alarms - olt-pon-tc-tca : OLT PON TC TCA related alarms - olt-pon-util-tca : OLT PON utilization TCA related alarms - olt-chpr-util-tca : OLT channel-pair utilization TCA related alarms - olt-ont-tc-tca : OLT ONT TC TCA related alarms - ont-tca : ONT TCA related alarms - ont-pots-supplemental : ONT POTS Supplemental related alarms - sfu-ploam : SFU ONT PLOAM related alarms - sfu-gen : SFU ONT general related alarms - soho-ploam : SOHO ONT PLOAM related alarms - soho-gen : SOHO ONT general related alarms - mdu-ploam : MDU ONT PLOAM related alarms - mdu-gen : MDU ONT general related alarms - ont-veip : ONT VEIP related alarms - ont-iphost : ONT IP HOST related alarms - alarm-table : alarm table related alarms - auto-switch : auto-switch related alarms - channel-pair : channel pair related alarms - ont-cfg-dld : ont configure file download related alarms - olt-chpair-tc-tca : OLT CHANNELPAIR TC TCA related alarms - hgu-tr069 : hgu tr069 related alarms - eqpt-psu : equipment psu alarms - ont-protection : ONT protection related alarms - secondary-megaco-term : secondary megaco termination related alarms - secondary-sip-term : secondary sip termination related alarms - cas-r2-channel : CAS R2 channel related alarms - lldpmed : lldpmed alarms - pseudo-wire : pseudo Wire related alarms - link-agg : Link aggregation related alarms - fcs-exceed : FCS auto-recovery related alarms - e1t1-interface : E1/T1 physical interfaces related alarms	
name	Parameter type: <Alarm::alarmTypeEpipeiHub> (epipe-instance-down	alarm name that are active <i>This element is only shown in</i>

101 query current alarms by filters

name	Type	Description
	all) Possible values: - epipe-instance-down : epipe instance down - all : epipe related alarms	detail mode.
severity	Parameter type: <Alarm::AlarmSeverity> (indeterminate warning minor major critical) Possible values: - indeterminate : alarm severity is indeterminate - warning : alarm severity is warning - minor : alarm severity is minor - major : alarm severity is major - critical : alarm severity is critical	the alarms severity level <i>This element is only shown in detail mode.</i>
servaff	Parameter type: <Alarm::alarmServAffect> ((service-affecting yes) (noservice-affecting no)) Possible values: - service-affecting : make this alarm service affecting - yes : make this alarm service affecting - noservice-affecting : make this alarm not service affecting - no : make this alarm not service affecting	alarms affect service or not <i>This element is only shown in detail mode.</i>
time	Parameter type: <Sys::timeInSecs> - the time (yyyy-mm-dd:hour:minutes:secs) - unit: UTC	time in seconds when alarm was updated <i>This element is only shown in detail mode.</i>
descript	Parameter type: <Alarm::AddInfoString> - additional alarm information	alarm description <i>This element is only shown in detail mode.</i>

101.104 show current alarm by filters

Command Description

show current alarms by filters

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm query lldpmed [ (name) [ severity <Alarm::querySeverity> ] [ servaff <Alarm::queryServAffect> ] [
port <LLDPMed::LLDPMedPort> ] ]
```

Command Parameters

Table 101.104-1 "show current alarm by filters" Resource Parameters

Resource Identifier	Type	Description
(name)	Format: (lldpmed-portcfg-mis lldpmed-mediapl-mis all) Possible values: - lldpmed-portcfg-mis : config request failure for lldpmed portconfig - lldpmed-mediapl-mis : config request failure for lldpmed mediapolicy - all : lldpmed alarms	alarm name of lldpmed
severity	Parameter type: <Alarm::querySeverity> Format: (indeterminate warning minor major critical all) Possible values: - indeterminate : alarm severity is indeterminate - warning : alarm severity is warning - minor : alarm severity is minor - major : alarm severity is major - critical : alarm severity is critical - all : all alarm severity	severity level of an alarm for reporting
servaff	Parameter type: <Alarm::queryServAffect> Format: (service-affecting	serviceaffecting no

Resource Identifier	Type	Description
	noservice-affecting all) Possible values: - service-affecting : query alarm service affecting - noservice-affecting : query alarm not service affecting - all : query service affecting and not affecting alarms	
port	Parameter type: <LLDPMed::LLDPMedPort> Format: (uni : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> / <Eqpt::OntPortId> uni.ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / <Eqpt::Ng2OntSlotId> / <Eqpt::Ng2OntPortId> uni.ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / vuni) Possible values: - uni : uni - uni.ng2 : ngpon2 UNI style identification Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Eqpt::OntId> - the ONT identifier Field type <Eqpt::ChannelGroupId> - the channel group identifier Field type <Eqpt::SubChannelGroupId> - the subchannel group identifier Field type <Eqpt::Ng2OntId> - the NG2 ONT identifier Possible values: - vuni : virtual NGPON2 uni identifier Field type <Eqpt::OntSlotId> - the ONT SLOT identifier Field type <Eqpt::OntPortId> - the ONT PORT identifier Field type <Eqpt::Ng2OntSlotId> - the NGPON2 ONT SLOT identifier Field type <Eqpt::Ng2OntPortId> - the NGPON2 ONT PORT identifier	identify the lldpmed port

Command Output

Table 101.104-2 "show current alarm by filters" Display parameters

Specific Information		
name	Type	Description
aidinfo	Parameter type: <Alarm::AddInfoString> - additional alarm information	alarm AID parameters <i>This element is only shown in detail mode.</i>
type	Parameter type: <Alarm::alarmIHUBType> (equipment	type of the alarms that are active <i>This element is only shown in</i>

name	Type	Description
	eqpt-holder plug-in-unit atm custom e1 ima-group ima-link redundancy shdsl ether-itf traffic-overflow qos-queue temporal spatial (software-mngt sw-mgmt) xdsl xdsl-ext xdsl-tca olt-gen eo-conv authentication bonding sfp shdsl-isam custom-ext-alarm plug-in-unit-ext sip-user-agent sip-plugin-unit sip-termination e1-sip-termination filetransfer external-device l2forward ether-tca ether-sfp megaco-media-gw megaco-sig-gw megaco-plug-unit megaco-term megaco-sig-lt eqpt-supplemental eqpt-holder-ext lsmredundancy sync mcsrc vlanport vect-line vect-board otdr sip-dial-plan sip-vsp sip-server bgp rip lag ihub-general vprn	detail mode.

101 query current alarms by filters

name	Type	Description
	isis	
	ospf	
	ihub-l2forward	
	vpls	
	ihub-equip	
	ihub-link	
	eont-phyoam	
	ellid	
	epon	
	eont-services-lan	
	eolt-ont-tca	
	eont-sw-dl	
	ldp	
	mpls	
	sdp	
	epipe	
	ihub-ipv6	
	pim	
	li	
	mgmt-sec-access	
	bfd	
	ai	
	tr069serv	
	ontsnmp	
	bulk-sync	
	protection-group	
	ont	
	sfu-sup	
	soho-sup	
	mdu-sup	
	ont-ani	
	sfu-sup2	
	soho-sup2	
	mdu-sup2	
	sfprssi	
	eoltrssi	
	cfm	
	sfpe1t1-framer	
	sfpe1t1-clock	
	pppcc-engine-tca	
	eth-cfm	
	rsvp	
	ihub-tca	
	eth-ring	
	efm-oam	
	ont-loopdetect	
	ont-video	
	ont-ces	
	ont-voip	
	ont-video-ani	
	ont-pwe	
	ont-cese1	
	ont-xdsl	
	ont-xdsl-tca	
	ont-hpna	
	ont-sip-agent-cfg	
	ont-voip-cfg	

name	Type	Description
	ont-mgc ont-ploam ont-gen ont-card ont-pots ont-lan ont-moca ont-tc-tca ont-moca-tca ont-l2uni-eth-tca olt-pon-tc-tca olt-pon-util-tca olt-chpr-util-tca olt-ont-tc-tca ont-tca ont-pots-supplemental sfu-ploam sfu-gen soho-ploam soho-gen mdu-ploam mdu-gen ont-veip ont-iphost alarm-table auto-switch channel-pair ont-cfg-dld olt-chpair-tc-tca hgu-tr069 eqpt-psu ont-protection secondary-megaco-term secondary-sip-term cas-r2-channel lldpmed pseudo-wire link-agg fcs-exceed e1t1-interface) Possible values: - equipment : equipment alarms - eqpt-holder : equipment holder alarms - plug-in-unit : plugin unit alarms - atm : ATM alarms - custom : customizable alarms - e1 : e1 alarms - ima-group : ima-group alarms - ima-link : ima-link alarms - redundancy : redundancy alarms - shdsl : shdsl alarms - ether-itf : ethernet interface alarms - traffic-overflow : Traffic overflow alarms - qos-queue : qos queue alarms - temporal : temporal alarms - spatial : spatial alarms - software-mngt : software management alarms	

101 query current alarms by filters

name	Type	Description
	- sw-mgmt : software management alarms - xdsl : xDSL alarms - xdsl-ext : other xDSL alarms - xdsl-tca : xDSL threshold cross alarms - olt-gen : OLT general alarms - eo-conv : E/O conversion related alarms - authentication : authentication related alarms - bonding : bonding-group related alarms - sfp : SFP related alarms - shdsl-isam : shdsl isam alarms - custom-ext-alarm : customizable external alarms - plug-in-unit-ext : other plugin unit alarms - sip-user-agent : sip user agent related alarms - sip-plugin-unit : sip plug in unit related alarms - sip-termination : sip termination related alarms - e1-sip-termination : E1 sip termination related alarms - filetransfer : file transfer server alarms - external-device : external device related alarms - l2forward : l2forward related alarms - ether-tca : ethernet threshold cross alarms - ether-sfp : ethernet SFP related alarms - megaco-media-gw : megaco media gateway related alarms - megaco-sig-gw : megaco signaling gateway related alarms - megaco-plug-unit : megaco plug unit related alarms - megaco-term : megaco termination related alarms - megaco-sig-lt : megaco signaling lt related alarms - eqpt-supplemental : equipment supplemental alarms - eqpt-holder-ext : other equipment holder alarms - lsmredundancy : lsm redundancy alarms - sync : synce and bits alarms - mcsrc : multicast source alarms - vlanport : vlanport alarms - vect-line : xDSL vectoring line alarms - vect-board : xDSL vectoring board alarms - otdr : otdr alarms - sip-dial-plan : sip dial plan related alarms - sip-vsp : sip vsp related alarms - sip-server : sip server related alarms - bgp : bgp related alarms - rip : rip related alarms - lag : LAG related alarms - ihub-general : IHUB general related alarms - vprn : vprn related alarms - isis : isis related alarms - ospf : ospf related alarms - ihub-l2forward : ihub-l2forward alarms - vpls : vpls related alarms - ihub-equip : ihub-equip related alarms - ihub-link : ihub-link related alarms - eont-phyoam : eont phyoam related alarms - ellid : ellid related alarms - epon : epon related alarms - eont-services-lan : eon phyoam related alarms - eolt-ont-tca : eon phyoam related alarms - eont-sw-dl : eon phyoam related alarms - ldp : ldp related alarms - mpls : mpls related alarms	

name	Type	Description
	- sdp : sdp related alarms - epipe : epipe related alarms - ihub-ipv6 : ihub-ipv6 related alarms - pim : pim related alarms - li : lawful intercept related alarms - mgmt-sec-access : management security related alarms - bfd : bfd related alarms - ai : Application Intelligence related alarms - tr069serv : tr069 server related alarms - ontsnmp : ont snmp related alarms - bulk-sync : bulk-sync related alarms - protection-group : port protection group related alarms - ont : ONT general supplemental related alarms - sfu-sup : SFU ONT general supplemental related alarms - soho-sup : SOHO ONT general supplemental related alarms - mdu-sup : MDU ONT general supplemental related alarms - ont-ani : ONT general supplemental 2 related alarms - sfu-sup2 : SFU ONT general supplemental 2 related alarms - soho-sup2 : SOHO ONT general supplemental 2 related alarms - mdu-sup2 : MDU ONT general supplemental 2 related alarms - sfprssi : SFP RSSI related alarms - eoltrssi : epon olt Sfp RSSI related alarms - cfm : Cfm related alarms - sfpe1t1-framer : SFP 2e1t1 framer alarms - sfpe1t1-clock : SFP 2e1t1 clock alarms - pppcc-engine-tca : PPPOE Cross Connect Engine TCA related alarm - eth-cfm : eth-cfm related alarms - rsvp : rsvp related alarms - ihub-tca : IHUB TCA related alarms - eth-ring : eth-ring related alarms - efm-oam : EFM-OAM related alarms - ont-loopdetect : ont loop detect related alarms - ont-video : ont services video related alarms - ont-ces : ont services ces related alarms - ont-voip : ont services voip related alarms - ont-video-ani : ont services video ani related alarms - ont-pwe : ont services pwe related alarms - ont-cese1 : ont services cese1 related alarms - ont-xdsl : ont services xdsl related alarms - ont-xdsl-tca : ont services xdsl tca related alarms - ont-hpna : ont hpna related alarms - ont-sip-agent-cfg : ont services voip sip agent config related alarms - ont-voip-cfg : ont services voip config related alarms - ont-mgc : ont mgc related alarms - ont-ploam : ONT PLOAM related alarms - ont-gen : ONT GENERAL related alarms - ont-card : ONT Subscriber Card related alarms - ont-pots : ONT Services POTS related alarms - ont-lan : ONT Services LAN related alarms - ont-moca : ONT MoCA related alarms - ont-tc-tca : ONT TC TCA related alarms - ont-moca-tca : ONT MoCA TCA related alarms	

101 query current alarms by filters

name	Type	Description
	- ont-l2uni-eth-tca : ONT L2 UNI Ethernet TCA related alarms - olt-pon-tc-tca : OLT PON TC TCA related alarms - olt-pon-util-tca : OLT PON utilization TCA related alarms - olt-chpr-util-tca : OLT channel-pair utilization TCA related alarms - olt-ont-tc-tca : OLT ONT TC TCA related alarms - ont-tca : ONT TCA related alarms - ont-pots-supplemental : ONT POTS Supplemental related alarms - sfu-ploam : SFU ONT PLOAM related alarms - sfu-gen : SFU ONT general related alarms - soho-ploam : SOHO ONT PLOAM related alarms - soho-gen : SOHO ONT general related alarms - mdu-ploam : MDU ONT PLOAM related alarms - mdu-gen : MDU ONT general related alarms - ont-veip : ONT VEIP related alarms - ont-iphost : ONT IP HOST related alarms - alarm-table : alarm table related alarms - auto-switch : auto-switch related alarms - channel-pair : channel pair related alarms - ont-cfg-dld : ont configure file download related alarms - olt-chpair-tc-tca : OLT CHANNELPAIR TC TCA related alarms - hgu-tr069 : hgu tr069 related alarms - eqpt-psu : equipment psu alarms - ont-protection : ONT protection related alarms - secondary-megaco-term : secondary megaco termination related alarms - secondary-sip-term : secondary sip termination related alarms - cas-r2-channel : CAS R2 channel related alarms - lldpmed : lldpmed alarms - pseudo-wire : pseudo Wire related alarms - link-agg : Link aggregation related alarms - fcs-exceed : FCS auto-recovery related alarms - e1t1-interface : E1/T1 physical interfaces related alarms	
name	Parameter type: <Alarm::alarmTypeLldpmedihub> (lldpmed-portcfg-mis lldpmed-mediapl-mis all) Possible values: - lldpmed-portcfg-mis : config request failure for lldpmed portconfig - lldpmed-mediapl-mis : config request failure for lldpmed mediapolicy - all : lldpmed alarms	alarm name that are active <i>This element is only shown in detail mode.</i>
severity	Parameter type: <Alarm::AlarmSeverity> (indeterminate warning minor major critical) Possible values: - indeterminate : alarm severity is indeterminate - warning : alarm severity is warning - minor : alarm severity is minor	the alarms severity level <i>This element is only shown in detail mode.</i>

name	Type	Description
	- major : alarm severity is major - critical : alarm severity is critical	
servaff	Parameter type: <Alarm::alarmServAffect> ((service-affecting yes) (noservice-affecting no)) Possible values: - service-affecting : make this alarm service affecting - yes : make this alarm service affecting - noservice-affecting : make this alarm not service affecting - no : make this alarm not service affecting	alarms affect service or not <i>This element is only shown in detail mode.</i>
time	Parameter type: <Sys::timeInSecs> - the time (yyyy-mm-dd:hour:minutes:secs) - unit: UTC	time in seconds when alarm was updated <i>This element is only shown in detail mode.</i>
descript	Parameter type: <Alarm::AddInfoString> - additional alarm information	alarm description <i>This element is only shown in detail mode.</i>

101.105 show current alarm by filters

Command Description

show current alarms by filters

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm query vlanport [ (name) [ severity <Alarm::querySeverity> ] [ servaff <Alarm::queryServAffect> ] [
vlanport <If::VlanPortInterface> ] ]
```

Command Parameters

Table 101.105-1 "show current alarm by filters" Resource Parameters

Resource Identifier	Type	Description
(name)	Format: (vlanport-svc-mismatch all) Possible values: - vlanport-svc-mismatch : config request failure for the provisioned vlanport - all : vlanport alarms	alarm name of vlanport
severity	Parameter type: <Alarm::querySeverity> Format: (indeterminate warning minor major critical all) Possible values: - indeterminate : alarm severity is indeterminate - warning : alarm severity is warning - minor : alarm severity is minor - major : alarm severity is major - critical : alarm severity is critical - all : all alarm severity	severity level of an alarm for reporting
servaff	Parameter type: <Alarm::queryServAffect> Format: (service-affecting noservice-affecting all) Possible values:	serviceaffecting no

Resource Identifier	Type	Description
	- service-affecting : query alarm service affecting - noservice-affecting : query alarm not service affecting - all : query service affecting and not affecting alarms	
vlanport	Parameter type: <Itf::VlanPortInterface> Format: <pre>(vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::VpiId> : <Eqpt::VciId> : <Eqpt::UnstackedVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::UnstackedVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::VpiId> : <Eqpt::VciId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> / <Eqpt::OntPortId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> / <Eqpt::OntPortId> : <Eqpt::UnstackedVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / voip : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / vuni : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / voip : <Eqpt::UnstackedVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / vuni : <Eqpt::UnstackedVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::LLId> : <Eqpt::UnstackedVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::LLId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan-port:ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Ng2::OntId> / <Eqpt::Ng2OntSlotId> / <Eqpt::Ng2OntPortId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan-port:ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Ng2::OntId> / <Eqpt::Ng2OntSlotId> / <Eqpt::Ng2OntPortId> : <Eqpt::UnstackedVlan> vlan-port:ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Ng2::OntId> / vuni : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan-port:ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Ng2::OntId> / vuni : <Eqpt::UnstackedVlan>)</pre> Possible values:	identify the vlan port

101 query current alarms by filters

Resource Identifier	Type	Description
	- vlan-port : vlan port - vlan-port:ng2 : ngpon2 vlan port - Field type <Eqpt::RackId> - the rack number - Field type <Eqpt::ShelfId> - the shelf number - Field type <Eqpt::SlotId> - the LT slot number - Field type <Eqpt::PortId> - the port number - Field type <Eqpt::VpiId> - atm VPI - Field type <Eqpt::VcId> - atm VCI - Field type <Eqpt::PonId> - the PON identifier - Field type <Eqpt::OntId> - the ONT identifier - Field type <Eqpt::ChannelGroupId> - the channel group identifier - Field type <Eqpt::SubChannelGroupId> - the subchannel group identifier - Field type <Ng2::OntId> - the ONT identifier - Possible values: - voip : virtual uni identifier - obsolete alternative replaced by vuni - vuni : virtual uni identifier - Possible values: - vuni : virtual NGPON2 uni identifier - Field type <Eqpt::OntSlotId> - the ONT SLOT identifier - Field type <Eqpt::OntPortId> - the ONT PORT identifier - Field type <Eqpt::Ng2OntSlotId> - the NGPON2 ONT SLOT identifier - Field type <Eqpt::Ng2OntPortId> - the NGPON2 ONT PORT identifier - Field type <Eqpt::LLId> - the LLID identifier,range 1 for EPON,range 1-8 for DPOE - Possible values: - stacked : stacked vlan identity - Field type <Eqpt::UnstackedVlan> - unstacked vlan id - Field type <Eqpt::SVlan> - service vlan id - Field type <Eqpt::CVlan> - customer vlan id	

Command Output

Table 101.105-2 "show current alarm by filters" Display parameters

Specific Information		
name	Type	Description
aidinfo	Parameter type: <Alarm::AddInfoString> - additional alarm information	alarm AID parameters <i>This element is only shown in</i>

name	Type	Description
		<i>detail mode.</i>
type	Parameter type: <Alarm::alarmIHUBType> (equipment eqpt-holder plug-in-unit atm custom e1 ima-group ima-link redundancy shdsl ether-itf traffic-overflow qos-queue temporal spatial (software-mngt sw-mgmt) xdsl xdsl-ext xdsl-tca olt-gen eo-conv authentication bonding sfp shdsl-isam custom-ext-alarm plug-in-unit-ext sip-user-agent sip-plugin-unit sip-termination e1-sip-termination filetransfer external-device l2forward ether-tca ether-sfp megaco-media-gw megaco-sig-gw megaco-plugin-unit megaco-term megaco-sig-lt eqpt-supplemental eqpt-holder-ext lsmredundancy sync mcsrc vlanport vect-line vect-board otdr sip-dial-plan sip-vsp sip-server bgp rip)	type of the alarms that are active <i>This element is only shown in detail mode.</i>

101 query current alarms by filters

name	Type	Description
	lag	
	ihub-general	
	vprn	
	isis	
	ospf	
	ihub-l2forward	
	vpls	
	ihub-equip	
	ihub-link	
	eont-phyoam	
	ellid	
	epon	
	eont-services-lan	
	eolt-ont-tca	
	eont-sw-dl	
	ldp	
	mpls	
	sdp	
	epipe	
	ihub-ipv6	
	pim	
	li	
	mgmt-sec-access	
	bfd	
	ai	
	tr069serv	
	ontsnmp	
	bulk-sync	
	protection-group	
	ont	
	sfu-sup	
	soho-sup	
	mdu-sup	
	ont-ani	
	sfu-sup2	
	soho-sup2	
	mdu-sup2	
	sfprssi	
	eoltrssi	
	cfm	
	sfpe1t1-framer	
	sfpe1t1-clock	
	pppcc-engine-tca	
	eth-cfm	
	rsvp	
	ihub-tca	
	eth-ring	
	efm-oam	
	ont-loopdetect	
	ont-video	
	ont-ces	
	ont-voip	
	ont-video-ani	
	ont-pwe	
	ont-cese1	
	ont-xdsl	
	ont-xdsl-tca	

name	Type	Description
	ont-hpna ont-sip-agent-cfg ont-voip-cfg ont-mgc ont-ploam ont-gen ont-card ont-pots ont-lan ont-moca ont-tc-tca ont-moca-tca ont-l2uni-eth-tca olt-pon-tc-tca olt-pon-util-tca olt-chpr-util-tca olt-ont-tc-tca ont-tca ont-pots-supplemental sfu-ploam sfu-gen soho-ploam soho-gen mdu-ploam mdu-gen ont-veip ont-iphost alarm-table auto-switch channel-pair ont-cfg-dld olt-chpair-tc-tca hgu-tr069 eqpt-psu ont-protection secondary-megaco-term secondary-sip-term cas-r2-channel lldpmed pseudo-wire link-agg fcs-exceed e1t1-interface) Possible values: - equipment : equipment alarms - eqpt-holder : equipment holder alarms - plug-in-unit : plugin unit alarms - atm : ATM alarms - custom : customizable alarms - e1 : e1 alarms - ima-group : ima-group alarms - ima-link : ima-link alarms - redundancy : redundancy alarms - shdsl : shdsl alarms - ether-itf : ethernet interface alarms - traffic-overflow : Traffic overflow alarms - qos-queue : qos queue alarms	

101 query current alarms by filters

name	Type	Description
	- temporal : temporal alarms - spatial : spatial alarms - software-mngt : software management alarms - sw-mgmt : software management alarms - xdsl : xDSL alarms - xdsl-ext : other xDSL alarms - xdsl-tca : xDSL threshold cross alarms - olt-gen : OLT general alarms - eo-conv : E/O conversion related alarms - authentication : authentication related alarms - bonding : bonding-group related alarms - sfp : SFP related alarms - shdsl-isam : shdsl isam alarms - custom-ext-alarm : customizable external alarms - plug-in-unit-ext : other plugin unit alarms - sip-user-agent : sip user agent related alarms - sip-plugin-unit : sip plug in unit related alarms - sip-termination : sip termination related alarms - e1-sip-termination : E1 sip termination related alarms - filetransfer : file transfer server alarms - external-device : external device related alarms - l2forward : l2forward related alarms - ether-tca : ethernet threshold cross alarms - ether-sfp : ethernet SFP related alarms - megaco-media-gw : megaco media gateway related alarms - megaco-sig-gw : megaco signaling gateway related alarms - megaco-plug-unit : megaco plug unit related alarms - megaco-term : megaco termination related alarms - megaco-sig-lt : megaco signaling lt related alarms - eqpt-supplemental : equipment supplemental alarms - eqpt-holder-ext : other equipment holder alarms - lsmredundancy : lsm redundancy alarms - sync : synce and bits alarms - mcsrc : multicast source alarms - vlanport : vlanport alarms - vect-line : xDSL vectoring line alarms - vect-board : xDSL vectoring board alarms - otdr : otdr alarms - sip-dial-plan : sip dial plan related alarms - sip-vsp : sip vsp related alarms - sip-server : sip server related alarms - bgp : bgp related alarms - rip : rip related alarms - lag : LAG related alarms - ihub-general : IHUB general related alarms - vprn : vprn related alarms - isis : isis related alarms - ospf : ospf related alarms - ihub-l2forward : ihub-l2forward alarms - vpls : vpls related alarms - ihub-equip : ihub-equip related alarms - ihub-link : ihub-link related alarms - eont-phyoam : eont phyoam related alarms - ellid : ellid related alarms - epon : epon related alarms - eont-services-lan : eon phyoam related alarms - eolt-ont-tca : eon phyoam related alarms	

name	Type	Description
	- eont-sw-dl : eon phyoom related alarms - ldp : ldp related alarms - mpls : mpls related alarms - sdp : sdp related alarms - epipe : epipe related alarms - ihub-ipv6 : ihub-ipv6 related alarms - pim : pim related alarms - li : lawful intercept related alarms - mgmt-sec-access : management security related alarms - bfd : bfd related alarms - ai : Application Intelligence related alarms - tr069serv : tr069 server related alarms - ontsnmp : ont snmp related alarms - bulk-sync : bulk-sync related alarms - protection-group : port protection group related alarms - ont : ONT general supplemental related alarms - sfu-sup : SFU ONT general supplemental related alarms - soho-sup : SOHO ONT general supplemental related alarms - mdv-sup : MDU ONT general supplemental related alarms - ont-ani : ONT general supplemental 2 related alarms - sfu-sup2 : SFU ONT general supplemental 2 related alarms - soho-sup2 : SOHO ONT general supplemental 2 related alarms - mdv-sup2 : MDU ONT general supplemental 2 related alarms - sfprrsi : SFP RSSI related alarms - eoltrssi : epon olt Sfp RSSI related alarms - cfm : Cfm related alarms - sfpe1t1-framer : SFP 2e1t1 framer alarms - sfpe1t1-clock : SFP 2e1t1 clock alarms - pppcc-engine-tca : PPPOE Cross Connect Engine TCA related alarm - eth-cfm : eth-cfm related alarms - rsvp : rsvp related alarms - ihub-tca : IHUB TCA related alarms - eth-ring : eth-ring related alarms - efm-oam : EFM-OAM related alarms - ont-loopdetect : ont loop detect related alarms - ont-video : ont services video related alarms - ont-ces : ont services ces related alarms - ont-voip : ont services voip related alarms - ont-video-ani : ont services video ani related alarms - ont-pwe : ont services pwe related alarms - ont-cese1 : ont services cese1 related alarms - ont-xdsl : ont services xdsl related alarms - ont-xdsl-tca : ont services xdsl tca related alarms - ont-hpna : ont hpna related alarms - ont-sip-agent-cfg : ont services voip sip agent config related alarms - ont-voip-cfg : ont services voip config related alarms - ont-mgc : ont mgc related alarms - ont-ploam : ONT PLOAM related alarms - ont-gen : ONT GENERAL related alarms - ont-card : ONT Subscriber Card related alarms - ont-pots : ONT Services POTS related alarms - ont-lan : ONT Services LAN related alarms	

101 query current alarms by filters

name	Type	Description
	- ont-moca : ONT MoCA related alarms - ont-tc-tca : ONT TC TCA related alarms - ont-moca-tca : ONT MoCA TCA related alarms - ont-l2uni-eth-tca : ONT L2 UNI Ethernet TCA related alarms - olt-pon-tc-tca : OLT PON TC TCA related alarms - olt-pon-util-tca : OLT PON utilization TCA related alarms - olt-chpr-util-tca : OLT channel-pair utilization TCA related alarms - olt-ont-tc-tca : OLT ONT TC TCA related alarms - ont-tca : ONT TCA related alarms - ont-pots-supplemental : ONT POTS Supplemental related alarms - sfu-ploam : SFU ONT PLOAM related alarms - sfu-gen : SFU ONT general related alarms - soho-ploam : SOHO ONT PLOAM related alarms - soho-gen : SOHO ONT general related alarms - mdu-ploam : MDU ONT PLOAM related alarms - mdu-gen : MDU ONT general related alarms - ont-veip : ONT VEIP related alarms - ont-iphost : ONT IP HOST related alarms - alarm-table : alarm table related alarms - auto-switch : auto-switch related alarms - channel-pair : channel pair related alarms - ont-cfg-dld : ont configure file download related alarms - olt-chpair-tc-tca : OLT CHANNELPAIR TC TCA related alarms - hgu-tr069 : hgu tr069 related alarms - eqpt-psu : equipment psu alarms - ont-protection : ONT protection related alarms - secondary-megaco-term : secondary megaco termination related alarms - secondary-sip-term : secondary sip termination related alarms - cas-r2-channel : CAS R2 channel related alarms - lldpmed : lldpmed alarms - pseudo-wire : pseudo Wire related alarms - link-agg : Link aggregation related alarms - fcs-exceed : FCS auto-recovery related alarms - e1t1-interface : E1/T1 physical interfaces related alarms	
name	Parameter type: <Alarm::almtypeVlanportihub> (vlanport-svc-mismatch all) Possible values: - vlanport-svc-mismatch : config request failure for the provisioned vlanport - all : vlanport alarms	alarm name that are active <i>This element is only shown in detail mode.</i>
severity	Parameter type: <Alarm::AlarmSeverity> (indeterminate warning minor major critical) Possible values: - indeterminate : alarm severity is indeterminate - warning : alarm severity is warning - minor : alarm severity is minor	the alarms severity level <i>This element is only shown in detail mode.</i>

name	Type	Description
	- major : alarm severity is major - critical : alarm severity is critical	
servaff	Parameter type: <Alarm::alarmServAffect> ((service-affecting yes) (noservice-affecting no)) Possible values: - service-affecting : make this alarm service affecting - yes : make this alarm service affecting - noservice-affecting : make this alarm not service affecting - no : make this alarm not service affecting	alarms affect service or not <i>This element is only shown in detail mode.</i>
time	Parameter type: <Sys::timeInSecs> - the time (yyyy-mm-dd:hour:minutes:secs) - unit: UTC	time in seconds when alarm was updated <i>This element is only shown in detail mode.</i>
descript	Parameter type: <Alarm::AddInfoString> - additional alarm information	alarm description <i>This element is only shown in detail mode.</i>

101.106 show current alarm by filters

Command Description

show current alarms by filters

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm query pim [ (name) [ severity <Alarm::querySeverity> ] [ servaff <Alarm::queryServAffect> ] [
router-id <lhub::Router> ] ]
```

Command Parameters

Table 101.106-1 "show current alarm by filters" Resource Parameters

Resource Identifier	Type	Description
(name)	Format: (pim-neighbor-down pim-max-mcroutes all) Possible values: - pim-neighbor-down : pim neighbor down - pim-max-mcroutes : maximum routes reached - all : pim related alarms	alarm name of Pim
severity	Parameter type: <Alarm::querySeverity> Format: (indeterminate warning minor major critical all) Possible values: - indeterminate : alarm severity is indeterminate - warning : alarm severity is warning - minor : alarm severity is minor - major : alarm severity is major - critical : alarm severity is critical - all : all alarm severity	severity level of an alarm for reporting
servaff	Parameter type: <Alarm::queryServAffect> Format: (service-affecting noservice-affecting all)	serviceaffecting no

Resource Identifier	Type	Description
	Possible values: - service-affecting : query alarm service affecting - noservice-affecting : query alarm not service affecting - all : query service affecting and not affecting alarms	
router-id	Parameter type: <Ihub::Router> Format: (base <Ihub::Router>) Possible values: - base : base router Field type <Ihub::Router> - vprn service-id - range: [1...2147483647]	identifies the base router

Command Output

Table 101.106-2 "show current alarm by filters" Display parameters

Specific Information		
name	Type	Description
aidinfo	Parameter type: <Alarm::AddInfoString> - additional alarm information	alarm AID parameters <i>This element is only shown in detail mode.</i>
type	Parameter type: <Alarm::alarmIHUBType> (equipment eqpt-holder plug-in-unit atm custom e1 ima-group ima-link redundancy shdsl ether-itf traffic-overflow qos-queue temporal spatial (software-mngt sw-mgmt) xdsl xdsl-ext xdsl-tca olt-gen eo-conv authentication bonding sfp shdsl-isam custom-ext-alarm plug-in-unit-ext sip-user-agent sip-plugin-unit sip-termination e1-sip-termination filetransfer external-device	type of the alarms that are active <i>This element is only shown in detail mode.</i>

101 query current alarms by filters

name	Type	Description
	l2forward	
	ether-tca	
	ether-sfp	
	megaco-media-gw	
	megaco-sig-gw	
	megaco-plug-unit	
	megaco-term	
	megaco-sig-lt	
	eqpt-supplemental	
	eqpt-holder-ext	
	lsmredundancy	
	sync	
	mcsrc	
	vlanport	
	vect-line	
	vect-board	
	otdr	
	sip-dial-plan	
	sip-vsp	
	sip-server	
	bgp	
	rip	
	lag	
	ihub-general	
	vprn	
	isis	
	ospf	
	ihub-l2forward	
	vpls	
	ihub-equip	
	ihub-link	
	eont-phyoam	
	ellid	
	epon	
	eont-services-lan	
	eolt-ont-tca	
	eont-sw-dl	
	ldp	
	mpls	
	sdp	
	epipe	
	ihub-ipv6	
	pim	
	li	
	mgmt-sec-access	
	bfd	
	ai	
	tr069serv	
	ontsnmp	
	bulk-sync	
	protection-group	
	ont	
	sfu-sup	
	soho-sup	
	mdu-sup	
	ont-ani	
	sfu-sup2	

name	Type	Description
	soho-sup2	
	mdu-sup2	
	sfprssi	
	eoltrssi	
	cfm	
	sfpe1t1-framer	
	sfpe1t1-clock	
	pppcc-engine-tca	
	eth-cfm	
	rsvp	
	ihub-tca	
	eth-ring	
	efm-oam	
	ont-loopdetect	
	ont-video	
	ont-ces	
	ont-voip	
	ont-video-ani	
	ont-pwe	
	ont-cese1	
	ont-xdsl	
	ont-xdsl-tca	
	ont-hpna	
	ont-sip-agent-cfg	
	ont-voip-cfg	
	ont-mgc	
	ont-ploam	
	ont-gen	
	ont-card	
	ont-pots	
	ont-lan	
	ont-moca	
	ont-tc-tca	
	ont-moca-tca	
	ont-l2uni-eth-tca	
	olt-pon-tc-tca	
	olt-pon-util-tca	
	olt-chpr-util-tca	
	olt-ont-tc-tca	
	ont-tca	
	ont-pots-supplemental	
	sfu-ploam	
	sfu-gen	
	soho-ploam	
	soho-gen	
	mdu-ploam	
	mdu-gen	
	ont-veip	
	ont-iphost	
	alarm-table	
	auto-switch	
	channel-pair	
	ont-cfg-dld	
	olt-chpair-tc-tca	
	hgu-tr069	
	eqpt-psu	
	ont-protection	

101 query current alarms by filters

name	Type	Description
	secondary-megaco-term secondary-sip-term cas-r2-channel lldpmed pseudo-wire link-agg fcs-exceed e1t1-interface) Possible values: - equipment : equipment alarms - eqpt-holder : equipment holder alarms - plug-in-unit : plugin unit alarms - atm : ATM alarms - custom : customizable alarms - e1 : e1 alarms - ima-group : ima-group alarms - ima-link : ima-link alarms - redundancy : redundancy alarms - shdsl : shdsl alarms - ether-itf : ethernet interface alarms - traffic-overflow : Traffic overflow alarms - qos-queue : qos queue alarms - temporal : temporal alarms - spatial : spatial alarms - software-mngt : software management alarms - sw-mgmt : software management alarms - xdsl : xDSL alarms - xdsl-ext : other xDSL alarms - xdsl-tca : xDSL threshold cross alarms - olt-gen : OLT general alarms - eo-conv : E/O conversion related alarms - authentication : authentication related alarms - bonding : bonding-group related alarms - sfp : SFP related alarms - shdsl-isam : shdsl isam alarms - custom-ext-alarm : customizable external alarms - plug-in-unit-ext : other plugin unit alarms - sip-user-agent : sip user agent related alarms - sip-plugin-unit : sip plug in unit related alarms - sip-termination : sip termination related alarms - e1-sip-termination : E1 sip termination related alarms - filetransfer : file transfer server alarms - external-device : external device related alarms - l2forward : l2forward related alarms - ether-tca : ethernet threshold cross alarms - ether-sfp : ethernet SFP related alarms - megaco-media-gw : megaco media gateway related alarms - megaco-sig-gw : megaco signaling gateway related alarms - megaco-plug-unit : megaco plug unit related alarms - megaco-term : megaco termination related alarms - megaco-sig-lt : megaco signaling lt related alarms - eqpt-supplemental : equipment supplemental alarms - eqpt-holder-ext : other equipment holder alarms - lsmredundancy : lsm redundancy alarms - sync : synce and bits alarms - mcsrc : multicast source alarms - vlanport : vlanport alarms	

name	Type	Description
	- vect-line : xDSL vectoring line alarms - vect-board : xDSL vectoring board alarms - otdr : otdr alarms - sip-dial-plan : sip dial plan related alarms - sip-vsp : sip vsp related alarms - sip-server : sip server related alarms - bgp : bgp related alarms - rip : rip related alarms - lag : LAG related alarms - ihub-general : IHUB general related alarms - vprn : vprn related alarms - isis : isis related alarms - ospf : ospf related alarms - ihub-l2forward : ihub-l2forward alarms - vpls : vpls related alarms - ihub-equip : ihub-equip related alarms - ihub-link : ihub-link related alarms - eont-phyoam : eont phyoam related alarms - ellid : ellid related alarms - epon : epon related alarms - eont-services-lan : eon phyoam related alarms - eolt-ont-tca : eon phyoam related alarms - eont-sw-dl : eon phyoam related alarms - ldp : ldp related alarms - mpls : mpls related alarms - sdp : sdp related alarms - epipe : epipe related alarms - ihub-ipv6 : ihub-ipv6 related alarms - pim : pim related alarms - li : lawful intercept related alarms - mgmt-sec-access : management security related alarms - bfd : bfd related alarms - ai : Application Intelligence related alarms - tr069serv : tr069 server related alarms - ontsnmp : ont snmp related alarms - bulk-sync : bulk-sync related alarms - protection-group : port protection group related alarms - ont : ONT general supplemental related alarms - sfu-sup : SFU ONT general supplemental related alarms - soho-sup : SOHO ONT general supplemental related alarms - mdu-sup : MDU ONT general supplemental related alarms - ont-ani : ONT general supplemental 2 related alarms - sfu-sup2 : SFU ONT general supplemental 2 related alarms - soho-sup2 : SOHO ONT general supplemental 2 related alarms - mdu-sup2 : MDU ONT general supplemental 2 related alarms - sfprssi : SFP RSSI related alarms - eoltrssi : epon olt Sfp RSSI related alarms - cfm : Cfm related alarms - sfpe1t1-framer : SFP 2e1t1 framer alarms - sfpe1t1-clock : SFP 2e1t1 clock alarms - pppcc-engine-tca : PPPOE Cross Connect Engine TCA related alarm - eth-cfm : eth-cfm related alarms - rsvp : rsvp related alarms	

101 query current alarms by filters

name	Type	Description
	- ihub-tca : IHUB TCA related alarms - eth-ring : eth-ring related alarms - efm-oam : EFM-OAM related alarms - ont-loopdetect : ont loop detect related alarms - ont-video : ont services video related alarms - ont-ces : ont services ces related alarms - ont-voip : ont services voip related alarms - ont-video-ani : ont services video ani related alarms - ont-pwe : ont services pwe related alarms - ont-cese1 : ont services cese1 related alarms - ont-xdsl : ont services xdsl related alarms - ont-xdsl-tca : ont services xdsl tca related alarms - ont-hpna : ont hpna related alarms - ont-sip-agent-cfg : ont services voip sip agent config related alarms - ont-voip-cfg : ont services voip config related alarms - ont-mgc : ont mgc related alarms - ont-ploam : ONT PLOAM related alarms - ont-gen : ONT GENERAL related alarms - ont-card : ONT Subscriber Card related alarms - ont-pots : ONT Services POTS related alarms - ont-lan : ONT Services LAN related alarms - ont-moca : ONT MoCA related alarms - ont-tc-tca : ONT TC TCA related alarms - ont-moca-tca : ONT MoCA TCA related alarms - ont-l2uni-eth-tca : ONT L2 UNI Ethernet TCA related alarms - olt-pon-tc-tca : OLT PON TC TCA related alarms - olt-pon-util-tca : OLT PON utilization TCA related alarms - olt-chpr-util-tca : OLT channel-pair utilization TCA related alarms - olt-ont-tc-tca : OLT ONT TC TCA related alarms - ont-tca : ONT TCA related alarms - ont-pots-supplemental : ONT POTS Supplemental related alarms - sfu-ploam : SFU ONT PLOAM related alarms - sfu-gen : SFU ONT general related alarms - soho-ploam : SOHO ONT PLOAM related alarms - soho-gen : SOHO ONT general related alarms - mdu-ploam : MDU ONT PLOAM related alarms - mdu-gen : MDU ONT general related alarms - ont-veip : ONT VEIP related alarms - ont-iphost : ONT IP HOST related alarms - alarm-table : alarm table related alarms - auto-switch : auto-switch related alarms - channel-pair : channel pair related alarms - ont-cfg-dld : ont configure file download related alarms - olt-chpair-tc-tca : OLT CHANNELPAIR TC TCA related alarms - hgu-tr069 : hgu tr069 related alarms - eqpt-psu : equipment psu alarms - ont-protection : ONT protection related alarms - secondary-megaco-term : secondary megaco termination related alarms - secondary-sip-term : secondary sip termination related alarms - cas-r2-channel : CAS R2 channel related alarms	

name	Type	Description
	- lldpmed : lldpmed alarms - pseudo-wire : pseudo Wire related alarms - link-agg : Link aggregation related alarms - fcs-exceed : FCS auto-recovery related alarms - e1t1-interface : E1/T1 physical interfaces related alarms	
name	Parameter type: <Alarm::alarmTypePimihub> (pim-neighbor-down pim-max-mcroutes all) Possible values: - pim-neighbor-down : pim neighbor down - pim-max-mcroutes : maximum routes reached - all : pim related alarms	alarm name that are active <i>This element is only shown in detail mode.</i>
severity	Parameter type: <Alarm::AlarmSeverity> (indeterminate warning minor major critical) Possible values: - indeterminate : alarm severity is indeterminate - warning : alarm severity is warning - minor : alarm severity is minor - major : alarm severity is major - critical : alarm severity is critical	the alarms severity level <i>This element is only shown in detail mode.</i>
servaff	Parameter type: <Alarm::alarmServAffect> ((service-affecting yes) (noservice-affecting no)) Possible values: - service-affecting : make this alarm service affecting - yes : make this alarm service affecting - noservice-affecting : make this alarm not service affecting - no : make this alarm not service affecting	alarms affect service or not <i>This element is only shown in detail mode.</i>
time	Parameter type: <Sys::timeInSecs> - the time (yyyy-mm-dd:hour:minutes:secs) - unit: UTC	time in seconds when alarm was updated <i>This element is only shown in detail mode.</i>
descript	Parameter type: <Alarm::AddInfoString> - additional alarm information	alarm description <i>This element is only shown in detail mode.</i>

101.107 show current alarm by filters

Command Description

show current alarms by filters

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm query bgp [ (name) [ severity <Alarm::querySeverity> ] [ servaff <Alarm::queryServAffect> ] [ router-id <lhub::Router> ] ]
```

Command Parameters

Table 101.107-1 "show current alarm by filters" Resource Parameters

Resource Identifier	Type	Description
(name)	Format: (bgp-peer-down bgp-routes-mid-limit all) Possible values: - bgp-peer-down : peer operational state is down - bgp-routes-mid-limit : 90% of max nbr of routes BGP can learn from a peer is reached - all : bgp related alarms	alarm name of bgp
severity	Parameter type: <Alarm::querySeverity> Format: (indeterminate warning minor major critical all) Possible values: - indeterminate : alarm severity is indeterminate - warning : alarm severity is warning - minor : alarm severity is minor - major : alarm severity is major - critical : alarm severity is critical - all : all alarm severity	severity level of an alarm for reporting
servaff	Parameter type: <Alarm::queryServAffect> Format: (service-affecting noservice-affecting	serviceaffecting no

Resource Identifier	Type	Description
	all) Possible values: - service-affecting : query alarm service affecting - noservice-affecting : query alarm not service affecting - all : query service affecting and not affecting alarms	
router-id	Parameter type: <Ihub::Router> Format: (base <Ihub::Router>) Possible values: - base : base router Field type <Ihub::Router> - vprn service-id - range: [1...2147483647]	identifies the vprn service-id or the base router

Command Output

Table 101.107-2 "show current alarm by filters" Display parameters

Specific Information		
name	Type	Description
aidinfo	Parameter type: <Alarm::AddInfoString> - additional alarm information	alarm AID parameters <i>This element is only shown in detail mode.</i>
type	Parameter type: <Alarm::alarmIHUBType> (equipment eqpt-holder plug-in-unit atm custom e1 ima-group ima-link redundancy shdsl ether-itf traffic-overflow qos-queue temporal spatial (software-mngt sw-mgmt) xdsl xdsl-ext xdsl-tca olt-gen eo-conv authentication bonding sfp shdsl-isam custom-ext-alarm plug-in-unit-ext sip-user-agent sip-plugin-unit sip-termination e1-sip-termination filetransfer	type of the alarms that are active <i>This element is only shown in detail mode.</i>

101 query current alarms by filters

name	Type	Description
	external-device	
	l2forward	
	ether-tca	
	ether-sfp	
	megaco-media-gw	
	megaco-sig-gw	
	megaco-plug-unit	
	megaco-term	
	megaco-sig-lt	
	eqpt-supplemental	
	eqpt-holder-ext	
	lsmredundancy	
	sync	
	mcsrc	
	vlanport	
	vect-line	
	vect-board	
	otdr	
	sip-dial-plan	
	sip-vsp	
	sip-server	
	bgp	
	rip	
	lag	
	ihub-general	
	vprn	
	isis	
	ospf	
	ihub-l2forward	
	vpls	
	ihub-equip	
	ihub-link	
	eont-phyoam	
	ellid	
	epon	
	eont-services-lan	
	eolt-ont-tca	
	eont-sw-dl	
	ldp	
	mpls	
	sdp	
	epipe	
	ihub-ipv6	
	pim	
	li	
	mgmt-sec-access	
	bfd	
	ai	
	tr069serv	
	ontsnmp	
	bulk-sync	
	protection-group	
	ont	
	sfu-sup	
	soho-sup	
	mdu-sup	
	ont-ani	

name	Type	Description
	sfu-sup2	
	soho-sup2	
	mdu-sup2	
	sfprssi	
	eoltrssi	
	cfm	
	sfpe1t1-framer	
	sfpe1t1-clock	
	pppcc-engine-tca	
	eth-cfm	
	rsvp	
	ihub-tca	
	eth-ring	
	efm-oam	
	ont-loopdetect	
	ont-video	
	ont-ces	
	ont-voip	
	ont-video-ani	
	ont-pwe	
	ont-cese1	
	ont-xdsl	
	ont-xdsl-tca	
	ont-hpna	
	ont-sip-agent-cfg	
	ont-voip-cfg	
	ont-mgc	
	ont-ploam	
	ont-gen	
	ont-card	
	ont-pots	
	ont-lan	
	ont-moca	
	ont-tc-tca	
	ont-moca-tca	
	ont-l2uni-eth-tca	
	olt-pon-tc-tca	
	olt-pon-util-tca	
	olt-chpr-util-tca	
	olt-ont-tc-tca	
	ont-tca	
	ont-pots-supplemental	
	sfu-ploam	
	sfu-gen	
	soho-ploam	
	soho-gen	
	mdu-ploam	
	mdu-gen	
	ont-veip	
	ont-iphost	
	alarm-table	
	auto-switch	
	channel-pair	
	ont-cfg-dld	
	olt-chpair-tc-tca	
	hgu-tr069	
	eqpt-psu	

101 query current alarms by filters

name	Type	Description
	ont-protection secondary-megaco-term secondary-sip-term cas-r2-channel lldpmed pseudo-wire link-agg fcs-exceed e1t1-interface) Possible values: - equipment : equipment alarms - eqpt-holder : equipment holder alarms - plug-in-unit : plugin unit alarms - atm : ATM alarms - custom : customizable alarms - e1 : e1 alarms - ima-group : ima-group alarms - ima-link : ima-link alarms - redundancy : redundancy alarms - shdsl : shdsl alarms - ether-itf : ethernet interface alarms - traffic-overflow : Traffic overflow alarms - qos-queue : qos queue alarms - temporal : temporal alarms - spatial : spatial alarms - software-mngt : software management alarms - sw-mgmt : software management alarms - xdsl : xDSL alarms - xdsl-ext : other xDSL alarms - xdsl-tca : xDSL threshold cross alarms - olt-gen : OLT general alarms - eo-conv : E/O conversion related alarms - authentication : authentication related alarms - bonding : bonding-group related alarms - sfp : SFP related alarms - shdsl-isam : shdsl isam alarms - custom-ext-alarm : customizable external alarms - plug-in-unit-ext : other plugin unit alarms - sip-user-agent : sip user agent related alarms - sip-plugin-unit : sip plug in unit related alarms - sip-termination : sip termination related alarms - e1-sip-termination : E1 sip termination related alarms - filetransfer : file transfer server alarms - external-device : external device related alarms - l2forward : l2forward related alarms - ether-tca : ethernet threshold cross alarms - ether-sfp : ethernet SFP related alarms - megaco-media-gw : megaco media gateway related alarms - megaco-sig-gw : megaco signaling gateway related alarms - megaco-plug-unit : megaco plug unit related alarms - megaco-term : megaco termination related alarms - megaco-sig-lt : megaco signaling lt related alarms - eqpt-supplemental : equipment supplemental alarms - eqpt-holder-ext : other equipment holder alarms - lsmredundancy : lsm redundancy alarms - sync : synce and bits alarms - mcsrc : multicast source alarms	

name	Type	Description
	- vlanport : vlanport alarms - vect-line : xDSL vectoring line alarms - vect-board : xDSL vectoring board alarms - otdr : otdr alarms - sip-dial-plan : sip dial plan related alarms - sip-vsp : sip vsp related alarms - sip-server : sip server related alarms - bgp : bgp related alarms - rip : rip related alarms - lag : LAG related alarms - ihub-general : IHUB general related alarms - vprn : vprn related alarms - isis : isis related alarms - ospf : ospf related alarms - ihub-l2forward : ihub-l2forward alarms - vpls : vpls related alarms - ihub-equip : ihub-equip related alarms - ihub-link : ihub-link related alarms - eont-phyoam : eont phyoam related alarms - ellid : ellid related alarms - epon : epon related alarms - eont-services-lan : eon phyoam related alarms - eolt-ont-tca : eon phyoam related alarms - eont-sw-dl : eon phyoam related alarms - ldp : ldp related alarms - mpls : mpls related alarms - sdp : sdp related alarms - epipe : epipe related alarms - ihub-ipv6 : ihub-ipv6 related alarms - pim : pim related alarms - li : lawful intercept related alarms - mgmt-sec-access : management security related alarms - bfd : bfd related alarms - ai : Application Intelligence related alarms - tr069serv : tr069 server related alarms - ontsnmp : ont snmp related alarms - bulk-sync : bulk-sync related alarms - protection-group : port protection group related alarms - ont : ONT general supplemental related alarms - sfu-sup : SFU ONT general supplemental related alarms - soho-sup : SOHO ONT general supplemental related alarms - mdu-sup : MDU ONT general supplemental related alarms - ont-ani : ONT general supplemental 2 related alarms - sfu-sup2 : SFU ONT general supplemental 2 related alarms - soho-sup2 : SOHO ONT general supplemental 2 related alarms - mdu-sup2 : MDU ONT general supplemental 2 related alarms - sfprssi : SFP RSSI related alarms - eoltrssi : epon olt Sfp RSSI related alarms - cfm : Cfm related alarms - sfpe1t1-framer : SFP 2e1t1 framer alarms - sfpe1t1-clock : SFP 2e1t1 clock alarms - pppcc-engine-tca : PPPOE Cross Connect Engine TCA related alarm - eth-cfm : eth-cfm related alarms	

101 query current alarms by filters

name	Type	Description
	- rsvp : rsvp related alarms - ihub-tca : IHUB TCA related alarms - eth-ring : eth-ring related alarms - efm-oam : EFM-OAM related alarms - ont-loopdetect : ont loop detect related alarms - ont-video : ont services video related alarms - ont-ces : ont services ces related alarms - ont-voip : ont services voip related alarms - ont-video-ani : ont services video ani related alarms - ont-pwe : ont services pwe related alarms - ont-cese1 : ont services cese1 related alarms - ont-xdsl : ont services xdsl related alarms - ont-xdsl-tca : ont services xdsl tca related alarms - ont-hpna : ont hpna related alarms - ont-sip-agent-cfg : ont services voip sip agent config related alarms - ont-voip-cfg : ont services voip config related alarms - ont-mgc : ont mgc related alarms - ont-ploam : ONT PLOAM related alarms - ont-gen : ONT GENERAL related alarms - ont-card : ONT Subscriber Card related alarms - ont-pots : ONT Services POTS related alarms - ont-lan : ONT Services LAN related alarms - ont-moca : ONT MoCA related alarms - ont-tc-tca : ONT TC TCA related alarms - ont-moca-tca : ONT MoCA TCA related alarms - ont-l2uni-eth-tca : ONT L2 UNI Ethernet TCA related alarms - olt-pon-tc-tca : OLT PON TC TCA related alarms - olt-pon-util-tca : OLT PON utilization TCA related alarms - olt-chpr-util-tca : OLT channel-pair utilization TCA related alarms - olt-ont-tc-tca : OLT ONT TC TCA related alarms - ont-tca : ONT TCA related alarms - ont-pots-supplemental : ONT POTS Supplemental related alarms - sfu-ploam : SFU ONT PLOAM related alarms - sfu-gen : SFU ONT general related alarms - soho-ploam : SOHO ONT PLOAM related alarms - soho-gen : SOHO ONT general related alarms - mdu-ploam : MDU ONT PLOAM related alarms - mdu-gen : MDU ONT general related alarms - ont-veip : ONT VEIP related alarms - ont-iphost : ONT IP HOST related alarms - alarm-table : alarm table related alarms - auto-switch : auto-switch related alarms - channel-pair : channel pair related alarms - ont-cfg-dld : ont configure file download related alarms - olt-chpair-tc-tca : OLT CHANNELPAIR TC TCA related alarms - hgu-tr069 : hgu tr069 related alarms - eqpt-psu : equipment psu alarms - ont-protection : ONT protection related alarms - secondary-megaco-term : secondary megaco termination related alarms - secondary-sip-term : secondary sip termination related alarms	

name	Type	Description
	- cas-r2-channel : CAS R2 channel related alarms - lldpmed : lldpmed alarms - pseudo-wire : pseudo Wire related alarms - link-agg : Link aggregation related alarms - fcs-exceed : FCS auto-recovery related alarms - e1t1-interface : E1/T1 physical interfaces related alarms	
name	Parameter type: <Alarm::alarmTypeBgpIhub> (bgp-peer-down bgp-routes-mid-limit all) Possible values: - bgp-peer-down : peer operational state is down - bgp-routes-mid-limit : 90% of max nbr of routes BGP can learn from a peer is reached - all : bgp related alarms	alarm name that are active <i>This element is only shown in detail mode.</i>
severity	Parameter type: <Alarm::AlarmSeverity> (indeterminate warning minor major critical) Possible values: - indeterminate : alarm severity is indeterminate - warning : alarm severity is warning - minor : alarm severity is minor - major : alarm severity is major - critical : alarm severity is critical	the alarms severity level <i>This element is only shown in detail mode.</i>
servaff	Parameter type: <Alarm::alarmServAffect> ((service-affecting yes) (noservice-affecting no)) Possible values: - service-affecting : make this alarm service affecting - yes : make this alarm service affecting - noservice-affecting : make this alarm not service affecting - no : make this alarm not service affecting	alarms affect service or not <i>This element is only shown in detail mode.</i>
time	Parameter type: <Sys::timeInSecs> - the time (yyyy-mm-dd:hour:minutes:secs) - unit: UTC	time in seconds when alarm was updated <i>This element is only shown in detail mode.</i>
descript	Parameter type: <Alarm::AddInfoString> - additional alarm information	alarm description <i>This element is only shown in detail mode.</i>

101.108 show current alarm by filters

Command Description

show current alarms by filters

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm query ihub-ipv6 [ (name) [ severity <Alarm::querySeverity> ] [ servaff <Alarm::queryServAffect> ] [ router-id <lhub::Router> ] ]
```

Command Parameters

Table 101.108-1 "show current alarm by filters" Resource Parameters

Resource Identifier	Type	Description
(name)	Format: (ihub-ipv6-dad-own ihub-ipv6-dad ihub-ipv6-dup-pd-route all) Possible values: - ihub-ipv6-dad-own : duplicate IPV6 address is detected for IP address allotted to system - ihub-ipv6-dad : duplicate IPV6 address is detected for a user's IP address - ihub-ipv6-dup-pd-route: ipv6 duplicate pd route detected - all : ihub-ipv6 related alarms	alarm name of ihub-ipv6
severity	Parameter type: <Alarm::querySeverity> Format: (indeterminate warning minor major critical all) Possible values: - indeterminate : alarm severity is indeterminate - warning : alarm severity is warning - minor : alarm severity is minor - major : alarm severity is major - critical : alarm severity is critical - all : all alarm severity	severity level of an alarm for reporting
servaff	Parameter type: <Alarm::queryServAffect>	serviceaffecting no

Resource Identifier	Type	Description
	Format: (service-affecting noservice-affecting all) Possible values: - service-affecting : query alarm service affecting - noservice-affecting : query alarm not service affecting - all : query service affecting and not affecting alarms	serviceaffecting
router-id	Parameter type: <Ihub::Router> Format: (base <Ihub::Router>) Possible values: - base : base router Field type <Ihub::Router> - vprn service-id - range: [1...2147483647]	identifies the vprn service-id or the base router

Command Output

Table 101.108-2 "show current alarm by filters" Display parameters

Specific Information		
name	Type	Description
aidinfo	Parameter type: <Alarm::AddInfoString> - additional alarm information	alarm AID parameters <i>This element is only shown in detail mode.</i>
type	Parameter type: <Alarm::alarmIHUBType> (equipment eqpt-holder plug-in-unit atm custom e1 ima-group ima-link redundancy shdsl ether-itf traffic-overflow qos-queue temporal spatial (software-mngt sw-mgmt) xdsl xdsl-ext xdsl-tca olt-gen eo-conv authentication bonding sfp shdsl-isam custom-ext-alarm plug-in-unit-ext sip-user-agent sip-plug-in-unit	type of the alarms that are active <i>This element is only shown in detail mode.</i>

101 query current alarms by filters

name	Type	Description
	sip-termination e1-sip-termination filetransfer external-device l2forward ether-tca ether-sfp megaco-media-gw megaco-sig-gw megaco-plug-unit megaco-term megaco-sig-lt eqpt-supplemental eqpt-holder-ext lsmredundancy sync mcsrc vlanport vect-line vect-board otdr sip-dial-plan sip-vsp sip-server bgp rip lag ihub-general vprn isis ospf ihub-l2forward vpls ihub-equip ihub-link eont-phyoam ellid epon eont-services-lan eolt-ont-tca eont-sw-dl ldp mpls sdp epipe ihub-ipv6 pim li mgmt-sec-access bfd ai tr069serv ontsnmp bulk-sync protection-group ont sfu-sup	

name	Type	Description
	soho-sup	
	mdu-sup	
	ont-ani	
	sfu-sup2	
	soho-sup2	
	mdu-sup2	
	sfprssi	
	eoltrssi	
	cfm	
	sfpe1t1-framer	
	sfpe1t1-clock	
	pppcc-engine-tca	
	eth-cfm	
	rsvp	
	ihub-tca	
	eth-ring	
	efm-oam	
	ont-loopdetect	
	ont-video	
	ont-ces	
	ont-voip	
	ont-video-ani	
	ont-pwe	
	ont-cese1	
	ont-xdsl	
	ont-xdsl-tca	
	ont-hpna	
	ont-sip-agent-cfg	
	ont-voip-cfg	
	ont-mgc	
	ont-ploam	
	ont-gen	
	ont-card	
	ont-pots	
	ont-lan	
	ont-moca	
	ont-tc-tca	
	ont-moca-tca	
	ont-l2uni-eth-tca	
	olt-pon-tc-tca	
	olt-pon-util-tca	
	olt-chpr-util-tca	
	olt-ont-tc-tca	
	ont-tca	
	ont-pots-supplemental	
	sfu-ploam	
	sfu-gen	
	soho-ploam	
	soho-gen	
	mdu-ploam	
	mdu-gen	
	ont-veip	
	ont-iphost	
	alarm-table	
	auto-switch	
	channel-pair	
	ont-cfg-dld	

101 query current alarms by filters

name	Type	Description
	olt-chpair-tc-tca hgu-tr069 eqpt-psu ont-protection secondary-megaco-term secondary-sip-term cas-r2-channel lldpmed pseudo-wire link-agg fcs-exceed e1t1-interface) Possible values: - equipment : equipment alarms - eqpt-holder : equipment holder alarms - plug-in-unit : plugin unit alarms - atm : ATM alarms - custom : customizable alarms - e1 : e1 alarms - ima-group : ima-group alarms - ima-link : ima-link alarms - redundancy : redundancy alarms - shdsl : shdsl alarms - ether-itf : ethernet interface alarms - traffic-overflow : Traffic overflow alarms - qos-queue : qos queue alarms - temporal : temporal alarms - spatial : spatial alarms - software-mngt : software management alarms - sw-mgmt : software management alarms - xdsl : xDSL alarms - xdsl-ext : other xDSL alarms - xdsl-tca : xDSL threshold cross alarms - olt-gen : OLT general alarms - eo-conv : E/O conversion related alarms - authentication : authentication related alarms - bonding : bonding-group related alarms - sfp : SFP related alarms - shdsl-isam : shdsl isam alarms - custom-ext-alarm : customizable external alarms - plug-in-unit-ext : other plugin unit alarms - sip-user-agent : sip user agent related alarms - sip-plugin-unit : sip plug in unit related alarms - sip-termination : sip termination related alarms - e1-sip-termination : E1 sip termination related alarms - filetransfer : file transfer server alarms - external-device : external device related alarms - l2forward : l2forward related alarms - ether-tca : ethernet threshold cross alarms - ether-sfp : ethernet SFP related alarms - megaco-media-gw : megaco media gateway related alarms - megaco-sig-gw : megaco signaling gateway related alarms - megaco-plug-unit : megaco plug unit related alarms - megaco-term : megaco termination related alarms - megaco-sig-lt : megaco signaling lt related alarms - eqpt-supplemental : equipment supplemental alarms - eqpt-holder-ext : other equipment holder alarms	

name	Type	Description
	- lsmredundancy : lsm redundancy alarms - sync : synce and bits alarms - mcsrc : multicast source alarms - vlanport : vlanport alarms - vect-line : xDSL vectoring line alarms - vect-board : xDSL vectoring board alarms - otdr : otdr alarms - sip-dial-plan : sip dial plan related alarms - sip-vsp : sip vsp related alarms - sip-server : sip server related alarms - bgp : bgp related alarms - rip : rip related alarms - lag : LAG related alarms - ihub-general : IHUB general related alarms - vprn : vprn related alarms - isis : isis related alarms - ospf : ospf related alarms - ihub-l2forward : ihub-l2forward alarms - vpls : vpls related alarms - ihub-equip : ihub-equip related alarms - ihub-link : ihub-link related alarms - eont-phyoam : eont phyoam related alarms - ellid : ellid related alarms - epon : epon related alarms - eont-services-lan : eon phyoam related alarms - eolt-ont-tca : eon phyoam related alarms - eont-sw-dl : eon phyoam related alarms - ldp : ldp related alarms - mpls : mpls related alarms - sdp : sdp related alarms - epipe : epipe related alarms - ihub-ipv6 : ihub-ipv6 related alarms - pim : pim related alarms - li : lawful intercept related alarms - mgmt-sec-access : management security related alarms - bfd : bfd related alarms - ai : Application Intelligence related alarms - tr069serv : tr069 server related alarms - ontsnmp : ont snmp related alarms - bulk-sync : bulk-sync related alarms - protection-group : port protection group related alarms - ont : ONT general supplemental related alarms - sfu-sup : SFU ONT general supplemental related alarms - soho-sup : SOHO ONT general supplemental related alarms - mdu-sup : MDU ONT general supplemental related alarms - ont-ani : ONT general supplemental 2 related alarms - sfu-sup2 : SFU ONT general supplemental 2 related alarms - soho-sup2 : SOHO ONT general supplemental 2 related alarms - mdu-sup2 : MDU ONT general supplemental 2 related alarms - sfprssi : SFP RSSI related alarms - eoltrssi : epon olt Sfp RSSI related alarms - cfm : Cfm related alarms - sfpe1t1-framer : SFP 2e1t1 framer alarms - sfpe1t1-clock : SFP 2e1t1 clock alarms	

101 query current alarms by filters

name	Type	Description
	- pppcc-engine-tca : PPPOE Cross Connect Engine TCA related alarm - eth-cfm : eth-cfm related alarms - rsvp : rsvp related alarms - ihub-tca : IHUB TCA related alarms - eth-ring : eth-ring related alarms - efm-oam : EFM-OAM related alarms - ont-loopdetect : ont loop detect related alarms - ont-video : ont services video related alarms - ont-ces : ont services ces related alarms - ont-voip : ont services voip related alarms - ont-video-ani : ont services video ani related alarms - ont-pwe : ont services pwe related alarms - ont-cese1 : ont services cese1 related alarms - ont-xdsl : ont services xdsl related alarms - ont-xdsl-tca : ont services xdsl tca related alarms - ont-hpna : ont hpna related alarms - ont-sip-agent-cfg : ont services voip sip agent config related alarms - ont-voip-cfg : ont services voip config related alarms - ont-mgc : ont mgc related alarms - ont-ploam : ONT PLOAM related alarms - ont-gen : ONT GENERAL related alarms - ont-card : ONT Subscriber Card related alarms - ont-pots : ONT Services POTS related alarms - ont-lan : ONT Services LAN related alarms - ont-moca : ONT MoCA related alarms - ont-tc-tca : ONT TC TCA related alarms - ont-moca-tca : ONT MoCA TCA related alarms - ont-l2uni-eth-tca : ONT L2 UNI Ethernet TCA related alarms - olt-pon-tc-tca : OLT PON TC TCA related alarms - olt-pon-util-tca : OLT PON utilization TCA related alarms - olt-chpr-util-tca : OLT channel-pair utilization TCA related alarms - olt-ont-tc-tca : OLT ONT TC TCA related alarms - ont-tca : ONT TCA related alarms - ont-pots-supplemental : ONT POTS Supplemental related alarms - sfu-ploam : SFU ONT PLOAM related alarms - sfu-gen : SFU ONT general related alarms - soho-ploam : SOHO ONT PLOAM related alarms - soho-gen : SOHO ONT general related alarms - mdu-ploam : MDU ONT PLOAM related alarms - mdu-gen : MDU ONT general related alarms - ont-veip : ONT VEIP related alarms - ont-iphost : ONT IP HOST related alarms - alarm-table : alarm table related alarms - auto-switch : auto-switch related alarms - channel-pair : channel pair related alarms - ont-cfg-dld : ont configure file download related alarms - olt-chpair-tc-tca : OLT CHANNELPAIR TC TCA related alarms - hgu-tr069 : hgu tr069 related alarms - eqpt-psu : equipment psu alarms - ont-protection : ONT protection related alarms - secondary-megaco-term : secondary megaco termination	

name	Type	Description
	related alarms - secondary-sip-term : secondary sip termination related alarms - cas-r2-channel : CAS R2 channel related alarms - lldpmed : lldpmed alarms - pseudo-wire : pseudo Wire related alarms - link-agg : Link aggregation related alarms - fcs-exceed : FCS auto-recovery related alarms - e1t1-interface : E1/T1 physical interfaces related alarms	
name	Parameter type: <Alarm::almtypeIhubipv6> (ihub-ipv6-dad-own ihub-ipv6-dad ihub-ipv6-dup-pd-route all) Possible values: - ihub-ipv6-dad-own : duplicate IPV6 address is detected for IP address allotted to system - ihub-ipv6-dad : duplicate IPV6 address is detected for a user's IP address - ihub-ipv6-dup-pd-route: ipv6 duplicate pd route detected - all : ihub-ipv6 related alarms	alarm name that are active <i>This element is only shown in detail mode.</i>
severity	Parameter type: <Alarm::AlarmSeverity> (indeterminate warning minor major critical) Possible values: - indeterminate : alarm severity is indeterminate - warning : alarm severity is warning - minor : alarm severity is minor - major : alarm severity is major - critical : alarm severity is critical	the alarms severity level <i>This element is only shown in detail mode.</i>
servaff	Parameter type: <Alarm::alarmServAffect> ((service-affecting yes) (noservice-affecting no)) Possible values: - service-affecting : make this alarm service affecting - yes : make this alarm service affecting - noservice-affecting : make this alarm not service affecting - no : make this alarm not service affecting	alarms affect service or not <i>This element is only shown in detail mode.</i>
time	Parameter type: <Sys::timeInSecs> - the time (yyyy-mm-dd:hour:minutes:secs) - unit: UTC	time in seconds when alarm was updated <i>This element is only shown in detail mode.</i>
descript	Parameter type: <Alarm::AddInfoString> - additional alarm information	alarm description <i>This element is only shown in detail mode.</i>

101.109 show current alarm by filters

Command Description

show current alarms by filters

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm query li [ (name) [ severity <Alarm::querySeverity> ] [ servaff <Alarm::queryServAffect> ] [ defaultaid <Alarm::queryDefaultAid> ] ]
```

Command Parameters

Table 101.109-1 "show current alarm by filters" Resource Parameters

Resource Identifier	Type	Description
(name)	Format: (li-traffic-disabled li-bandwidth-limit li-out-of-res all) Possible values: - li-traffic-disabled : lawful interception of traffic disabled - li-bandwidth-limit : lawful intercept reached bandwidth limit - li-out-of-res : lawful intercept out of resources - all : lawful intercept related alarms	alarm name of lawful intercept
severity	Parameter type: <Alarm::querySeverity> Format: (indeterminate warning minor major critical all) Possible values: - indeterminate : alarm severity is indeterminate - warning : alarm severity is warning - minor : alarm severity is minor - major : alarm severity is major - critical : alarm severity is critical - all : all alarm severity	severity level of an alarm for reporting
servaff	Parameter type: <Alarm::queryServAffect> Format:	serviceaffecting no

Resource Identifier	Type	Description
	(service-affecting noservice-affecting all) Possible values: - service-affecting : query alarm service affecting - noservice-affecting : query alarm not service affecting - all : query service affecting and not affecting alarms	
defaultaid	Parameter type: <Alarm::queryDefaultAid> Format: all Possible values: - all : default AID parameter	the default AID param is all

Command Output

Table 101.109-2 "show current alarm by filters" Display parameters

Specific Information		
name	Type	Description
type	Parameter type: <Alarm::alarmIHUBType> (equipment eqpt-holder plug-in-unit atm custom e1 ima-group ima-link redundancy shdsl ether-itf traffic-overflow qos-queue temporal spatial (software-mngt sw-mgmt) xdsl xdsl-ext xdsl-tca olt-gen eo-conv authentication bonding sfp shdsl-isam custom-ext-alarm plug-in-unit-ext sip-user-agent sip-plugin-unit sip-termination e1-sip-termination filetransfer external-device l2forward ether-tca ether-sfp megaco-media-gw	type of the alarms that are active <i>This element is only shown in detail mode.</i>

101 query current alarms by filters

name	Type	Description
	megaco-sig-gw megaco-plug-unit megaco-term megaco-sig-lt eqpt-supplemental eqpt-holder-ext lsmredundancy sync mcsrc vlanport vect-line vect-board otdr sip-dial-plan sip-vsp sip-server bgp rip lag ihub-general vprn isis ospf ihub-l2forward vpls ihub-equip ihub-link eont-phyoam ellid epon eont-services-lan eolt-ont-tca eont-sw-dl ldp mpls sdp epipe ihub-ipv6 pim li mgmt-sec-access bfd ai tr069serv ontsnmp bulk-sync protection-group ont sfu-sup soho-sup mdu-sup ont-ani sfu-sup2 soho-sup2 mdu-sup2 sfprssi eoltrssi	

name	Type	Description
	cfm	
	sfpe1t1-framer	
	sfpe1t1-clock	
	pppcc-engine-tca	
	eth-cfm	
	rsvp	
	ihub-tca	
	eth-ring	
	efm-oam	
	ont-loopdetect	
	ont-video	
	ont-ces	
	ont-voip	
	ont-video-ani	
	ont-pwe	
	ont-cese1	
	ont-xdsl	
	ont-xdsl-tca	
	ont-hpna	
	ont-sip-agent-cfg	
	ont-voip-cfg	
	ont-mgc	
	ont-ploam	
	ont-gen	
	ont-card	
	ont-pots	
	ont-lan	
	ont-moca	
	ont-tc-tca	
	ont-moca-tca	
	ont-l2uni-eth-tca	
	olt-pon-tc-tca	
	olt-pon-util-tca	
	olt-chpr-util-tca	
	olt-ont-tc-tca	
	ont-tca	
	ont-pots-supplemental	
	sfu-ploam	
	sfu-gen	
	soho-ploam	
	soho-gen	
	mdu-ploam	
	mdu-gen	
	ont-veip	
	ont-iphost	
	alarm-table	
	auto-switch	
	channel-pair	
	ont-cfg-dld	
	olt-chpair-tc-tca	
	hgu-tr069	
	eqpt-psu	
	ont-protection	
	secondary-megaco-term	
	secondary-sip-term	
	cas-r2-channel	
	lldpmed	

101 query current alarms by filters

name	Type	Description
	pseudo-wire link-agg fcs-exceed e1t1-interface) Possible values: - equipment : equipment alarms - eqpt-holder : equipment holder alarms - plug-in-unit : plugin unit alarms - atm : ATM alarms - custom : customizable alarms - e1 : e1 alarms - ima-group : ima-group alarms - ima-link : ima-link alarms - redundancy : redundancy alarms - shdsl : shdsl alarms - ether-itf : ethernet interface alarms - traffic-overflow : Traffic overflow alarms - qos-queue : qos queue alarms - temporal : temporal alarms - spatial : spatial alarms - software-mngt : software management alarms - sw-mgmt : software management alarms - xdsl : xDSL alarms - xdsl-ext : other xDSL alarms - xdsl-tca : xDSL threshold cross alarms - olt-gen : OLT general alarms - eo-conv : E/O conversion related alarms - authentication : authentication related alarms - bonding : bonding-group related alarms - sfp : SFP related alarms - shdsl-isam : shdsl isam alarms - custom-ext-alarm : customizable external alarms - plug-in-unit-ext : other plugin unit alarms - sip-user-agent : sip user agent related alarms - sip-plugin-unit : sip plug in unit related alarms - sip-termination : sip termination related alarms - e1-sip-termination : E1 sip termination related alarms - filetransfer : file transfer server alarms - external-device : external device related alarms - l2forward : l2forward related alarms - ether-tca : ethernet threshold cross alarms - ether-sfp : ethernet SFP related alarms - megaco-media-gw : megaco media gateway related alarms - megaco-sig-gw : megaco signaling gateway related alarms - megaco-plug-unit : megaco plug unit related alarms - megaco-term : megaco termination related alarms - megaco-sig-lt : megaco signaling lt related alarms - eqpt-supplemental : equipment supplemental alarms - eqpt-holder-ext : other equipment holder alarms - lsmredundancy : lsm redundancy alarms - sync : synce and bits alarms - mcsrc : multicast source alarms - vlanport : vlanport alarms - vect-line : xDSL vectoring line alarms - vect-board : xDSL vectoring board alarms - otdr : otdr alarms - sip-dial-plan : sip dial plan related alarms	

name	Type	Description
	- sip-vsp : sip vsp related alarms - sip-server : sip server related alarms - bgp : bgp related alarms - rip : rip related alarms - lag : LAG related alarms - ihub-general : IHUB general related alarms - vprn : vprn related alarms - isis : isis related alarms - ospf : ospf related alarms - ihub-l2forward : ihub-l2forward alarms - vpls : vpls related alarms - ihub-equip : ihub-equip related alarms - ihub-link : ihub-link related alarms - eont-phyoam : eont phyoam related alarms - ellid : ellid related alarms - epon : epon related alarms - eont-services-lan : eon phyoam related alarms - eolt-ont-tca : eon phyoam related alarms - eont-sw-dl : eon phyoam related alarms - ldp : ldp related alarms - mpls : mpls related alarms - sdp : sdp related alarms - epipe : epipe related alarms - ihub-ipv6 : ihub-ipv6 related alarms - pim : pim related alarms - li : lawful intercept related alarms - mgmt-sec-access : management security related alarms - bfd : bfd related alarms - ai : Application Intelligence related alarms - tr069serv : tr069 server related alarms - ontsnmp : ont snmp related alarms - bulk-sync : bulk-sync related alarms - protection-group : port protection group related alarms - ont : ONT general supplemental related alarms - sfu-sup : SFU ONT general supplemental related alarms - soho-sup : SOHO ONT general supplemental related alarms - mdu-sup : MDU ONT general supplemental related alarms - ont-ani : ONT general supplemental 2 related alarms - sfu-sup2 : SFU ONT general supplemental 2 related alarms - soho-sup2 : SOHO ONT general supplemental 2 related alarms - mdu-sup2 : MDU ONT general supplemental 2 related alarms - sfprssi : SFP RSSI related alarms - eoltrssi : epon olt Sfp RSSI related alarms - cfm : Cfm related alarms - sfpe1t1-framer : SFP 2e1t1 framer alarms - sfpe1t1-clock : SFP 2e1t1 clock alarms - pppcc-engine-tca : PPPOE Cross Connect Engine TCA related alarm - eth-cfm : eth-cfm related alarms - rsvp : rsvp related alarms - ihub-tca : IHUB TCA related alarms - eth-ring : eth-ring related alarms - efm-oam : EFM-OAM related alarms - ont-loopdetect : ont loop detect related alarms	

101 query current alarms by filters

name	Type	Description
	- ont-video : ont services video related alarms - ont-ces : ont services ces related alarms - ont-voip : ont services voip related alarms - ont-video-ani : ont services video ani related alarms - ont-pwe : ont services pwe related alarms - ont-cese1 : ont services cese1 related alarms - ont-xdsl : ont services xdsl related alarms - ont-xdsl-tca : ont services xdsl tca related alarms - ont-hpna : ont hpna related alarms - ont-sip-agent-cfg : ont services voip sip agent config related alarms - ont-voip-cfg : ont services voip config related alarms - ont-mgc : ont mgc related alarms - ont-ploam : ONT PLOAM related alarms - ont-gen : ONT GENERAL related alarms - ont-card : ONT Subscriber Card related alarms - ont-pots : ONT Services POTS related alarms - ont-lan : ONT Services LAN related alarms - ont-moca : ONT MoCA related alarms - ont-tc-tca : ONT TC TCA related alarms - ont-moca-tca : ONT MoCA TCA related alarms - ont-l2uni-eth-tca : ONT L2 UNI Ethernet TCA related alarms - olt-pon-tc-tca : OLT PON TC TCA related alarms - olt-pon-util-tca : OLT PON utilization TCA related alarms - olt-chpr-util-tca : OLT channel-pair utilization TCA related alarms - olt-ont-tc-tca : OLT ONT TC TCA related alarms - ont-tca : ONT TCA related alarms - ont-pots-supplemental : ONT POTS Supplemental related alarms - sfu-ploam : SFU ONT PLOAM related alarms - sfu-gen : SFU ONT general related alarms - soho-ploam : SOHO ONT PLOAM related alarms - soho-gen : SOHO ONT general related alarms - mdu-ploam : MDU ONT PLOAM related alarms - mdu-gen : MDU ONT general related alarms - ont-veip : ONT VEIP related alarms - ont-iphost : ONT IP HOST related alarms - alarm-table : alarm table related alarms - auto-switch : auto-switch related alarms - channel-pair : channel pair related alarms - ont-cfg-dld : ont configure file download related alarms - olt-chpair-tc-tca : OLT CHANNELPAIR TC TCA related alarms - hgu-tr069 : hgu tr069 related alarms - eqpt-psu : equipment psu alarms - ont-protection : ONT protection related alarms - secondary-megaco-term : secondary megaco termination related alarms - secondary-sip-term : secondary sip termination related alarms - cas-r2-channel : CAS R2 channel related alarms - lldpmed : lldpmed alarms - pseudo-wire : pseudo Wire related alarms - link-agg : Link aggregation related alarms - fcs-exceed : FCS auto-recovery related alarms	

name	Type	Description
	- e1t1-interface : E1/T1 physical interfaces related alarms	
name	Parameter type: <Alarm::alarmTypeLiihub> (li-traffic-disabled li-bandwidth-limit li-out-of-res all) Possible values: - li-traffic-disabled : lawful interception of traffic disabled - li-bandwidth-limit : lawful intercept reached bandwidth limit - li-out-of-res : lawful intercept out of resources - all : lawful intercept related alarms	alarm name that are active <i>This element is only shown in detail mode.</i>
severity	Parameter type: <Alarm::AlarmSeverity> (indeterminate warning minor major critical) Possible values: - indeterminate : alarm severity is indeterminate - warning : alarm severity is warning - minor : alarm severity is minor - major : alarm severity is major - critical : alarm severity is critical	the alarms severity level <i>This element is only shown in detail mode.</i>
servaff	Parameter type: <Alarm::alarmServAffect> ((service-affecting yes) (noservice-affecting no)) Possible values: - service-affecting : make this alarm service affecting - yes : make this alarm service affecting - noservice-affecting : make this alarm not service affecting - no : make this alarm not service affecting	alarms affect service or not <i>This element is only shown in detail mode.</i>
time	Parameter type: <Sys::timeInSecs> - the time (yyyy-mm-dd:hour:minutes:secs) - unit: UTC	time in seconds when alarm was updated <i>This element is only shown in detail mode.</i>
descript	Parameter type: <Alarm::AddInfoString> - additional alarm information	alarm description <i>This element is only shown in detail mode.</i>

101.110 show current alarm by filters

Command Description

show current alarms by filters

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm query ont-sip-agent-cfg [ (name) [ severity <Alarm::querySeverity> ] [ servaff
<Alarm::queryServAffect> ] [ port <Gpon::IpHostCommonIndex> ] ]
```

Command Parameters

Table 101.110-1 "show current alarm by filters" Resource Parameters

Resource Identifier	Type	Description
(name)	Format: (ont-sipa-reg-nm-fail ont-sipa-reg-rec-fail ont-sipa-reg-con-fail ont-sipa-reg-val-fail ont-sipa-reg-mis all) Possible values: - ont-sipa-reg-nm-fail : sipua registration name failed - ont-sipa-reg-rec-fail : sipua register reach failed - ont-sipa-reg-con-fail : sipua register connect failed - ont-sipa-reg-val-fail : sipua register validation failed - ont-sipa-reg-mis : sipua register mismatch - all : ont services voip sip agent config related alarms	alarm name of ont-sip-agent-cfg
severity	Parameter type: <Alarm::querySeverity> Format: (indeterminate warning minor major critical all) Possible values: - indeterminate : alarm severity is indeterminate - warning : alarm severity is warning - minor : alarm severity is minor - major : alarm severity is major - critical : alarm severity is critical	severity level of an alarm for reporting

Resource Identifier	Type	Description
servaff	- all : all alarm severity Parameter type: <Alarm::queryServAffect> Format: (service-affecting noservice-affecting all) Possible values: - service-affecting : query alarm service affecting - noservice-affecting : query alarm not service affecting - all : query service affecting and not affecting alarms	serviceaffecting no serviceaffecting
port	Parameter type: <Gpon::IpHostCommonIndex> Format: (ont : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Gpon::IpHostId> vlanport : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / vuni : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlanport : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / vuni : <Eqpt::UnstackedVlan> ont.ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / <Ng2::IpHostId> vlanport.ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / vuni : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlanport.ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / vuni : <Eqpt::UnstackedVlan>) Possible values: - ont.ng2 : ngpon2 ont - vlanport.ng2 : ngpon2 vlanport - ont : ont - vlanport : vlanport Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Eqpt::OntId> - the ONT identifier Field type <Eqpt::ChannelGroupId> - the channel group identifier Field type <Eqpt::SubChannelGroupId> - the subchannel group identifier Field type <Eqpt::Ng2OntId> - the NG2 ONT identifier Possible values: - vuni : virtual uni identifier Possible values: - vuni : virtual NGPON2 uni identifier Field type <Gpon::IpHostId> - iphost id Field type <Ng2::IpHostId>	gpon iphost port

101 query current alarms by filters

Resource Identifier	Type	Description
	- iphost id (ngpon2) Possible values: - stacked : stacked vlan identity Field type <Eqpt::UnstackedVlan> - unstacked vlan id Field type <Eqpt::SVlan> - service vlan id Field type <Eqpt::CVlan> - customer vlan id	

Command Output

Table 101.110-2 "show current alarm by filters" Display parameters

Specific Information		
name	Type	Description
aidinfo	Parameter type: <Alarm::AddInfoString> - additional alarm information	alarm AID parameters <i>This element is only shown in detail mode.</i>
type	Parameter type: <Alarm::alarmIHUBType> (equipment eqpt-holder plug-in-unit atm custom e1 ima-group ima-link redundancy shdsl ether-itf traffic-overflow qos-queue temporal spatial (software-mngt sw-mgmt) xdsl xdsl-ext xdsl-tca olt-gen eo-conv authentication bonding sfp shdsl-isam custom-ext-alarm plug-in-unit-ext sip-user-agent sip-plugin-unit sip-termination e1-sip-termination filetransfer external-device l2forward ether-tca ether-sfp megaco-media-gw)	type of the alarms that are active <i>This element is only shown in detail mode.</i>

name	Type	Description
	megaco-sig-gw megaco-plug-unit megaco-term megaco-sig-lt eqpt-supplemental eqpt-holder-ext lsmredundancy sync mcsrc vlanport vect-line vect-board otdr sip-dial-plan sip-vsp sip-server bgp rip lag ihub-general vprn isis ospf ihub-l2forward vpls ihub-equip ihub-link eont-phyoam ellid epon eont-services-lan eolt-ont-tca eont-sw-dl ldp mpls sdp epipe ihub-ipv6 pim li mgmt-sec-access bfd ai tr069serv ontsnmp bulk-sync protection-group ont sfu-sup soho-sup mdu-sup ont-ani sfu-sup2 soho-sup2 mdu-sup2 sfprssi eoltrssi	

101 query current alarms by filters

name	Type	Description
	cfm sfpe1t1-framer sfpe1t1-clock pppcc-engine-tca eth-cfm rsvp ihub-tca eth-ring efm-oam ont-loopdetect ont-video ont-ces ont-voip ont-video-ani ont-pwe ont-cese1 ont-xdsl ont-xdsl-tca ont-hpna ont-sip-agent-cfg ont-voip-cfg ont-mgc ont-ploam ont-gen ont-card ont-pots ont-lan ont-moca ont-tc-tca ont-moca-tca ont-l2uni-eth-tca olt-pon-tc-tca olt-pon-util-tca olt-chpr-util-tca olt-ont-tc-tca ont-tca ont-pots-supplemental sfu-ploam sfu-gen soho-ploam soho-gen mdu-ploam mdu-gen ont-veip ont-iphost alarm-table auto-switch channel-pair ont-cfg-dld olt-chpair-tc-tca hgu-tr069 eqpt-psu ont-protection secondary-megaco-term secondary-sip-term cas-r2-channel lldpmed	

name	Type	Description
	pseudo-wire link-agg fcs-exceed e1t1-interface) Possible values: - equipment : equipment alarms - eqpt-holder : equipment holder alarms - plug-in-unit : plugin unit alarms - atm : ATM alarms - custom : customizable alarms - e1 : e1 alarms - ima-group : ima-group alarms - ima-link : ima-link alarms - redundancy : redundancy alarms - shdsl : shdsl alarms - ether-itf : ethernet interface alarms - traffic-overflow : Traffic overflow alarms - qos-queue : qos queue alarms - temporal : temporal alarms - spatial : spatial alarms - software-mngt : software management alarms - sw-mgmt : software management alarms - xdsl : xDSL alarms - xdsl-ext : other xDSL alarms - xdsl-tca : xDSL threshold cross alarms - olt-gen : OLT general alarms - eo-conv : E/O conversion related alarms - authentication : authentication related alarms - bonding : bonding-group related alarms - sfp : SFP related alarms - shdsl-isam : shdsl isam alarms - custom-ext-alarm : customizable external alarms - plug-in-unit-ext : other plugin unit alarms - sip-user-agent : sip user agent related alarms - sip-plugin-unit : sip plug in unit related alarms - sip-termination : sip termination related alarms - e1-sip-termination : E1 sip termination related alarms - filetransfer : file transfer server alarms - external-device : external device related alarms - l2forward : l2forward related alarms - ether-tca : ethernet threshold cross alarms - ether-sfp : ethernet SFP related alarms - megaco-media-gw : megaco media gateway related alarms - megaco-sig-gw : megaco signaling gateway related alarms - megaco-plug-unit : megaco plug unit related alarms - megaco-term : megaco termination related alarms - megaco-sig-lt : megaco signaling lt related alarms - eqpt-supplemental : equipment supplemental alarms - eqpt-holder-ext : other equipment holder alarms - lsmredundancy : lsm redundancy alarms - sync : synce and bits alarms - mcsrc : multicast source alarms - vlanport : vlanport alarms - vect-line : xDSL vectoring line alarms - vect-board : xDSL vectoring board alarms - otdr : otdr alarms - sip-dial-plan : sip dial plan related alarms	

101 query current alarms by filters

name	Type	Description
	- sip-vsp : sip vsp related alarms - sip-server : sip server related alarms - bgp : bgp related alarms - rip : rip related alarms - lag : LAG related alarms - ihub-general : IHUB general related alarms - vprn : vprn related alarms - isis : isis related alarms - ospf : ospf related alarms - ihub-l2forward : ihub-l2forward alarms - vpls : vpls related alarms - ihub-equip : ihub-equip related alarms - ihub-link : ihub-link related alarms - eont-phyoam : eont phyoam related alarms - ellid : ellid related alarms - epon : epon related alarms - eont-services-lan : eon phyoam related alarms - eolt-ont-tca : eon phyoam related alarms - eont-sw-dl : eon phyoam related alarms - ldp : ldp related alarms - mpls : mpls related alarms - sdp : sdp related alarms - epipe : epipe related alarms - ihub-ipv6 : ihub-ipv6 related alarms - pim : pim related alarms - li : lawful intercept related alarms - mgmt-sec-access : management security related alarms - bfd : bfd related alarms - ai : Application Intelligence related alarms - tr069serv : tr069 server related alarms - ontsnmp : ont snmp related alarms - bulk-sync : bulk-sync related alarms - protection-group : port protection group related alarms - ont : ONT general supplemental related alarms - sfu-sup : SFU ONT general supplemental related alarms - soho-sup : SOHO ONT general supplemental related alarms - mdu-sup : MDU ONT general supplemental related alarms - ont-ani : ONT general supplemental 2 related alarms - sfu-sup2 : SFU ONT general supplemental 2 related alarms - soho-sup2 : SOHO ONT general supplemental 2 related alarms - mdu-sup2 : MDU ONT general supplemental 2 related alarms - sfprssi : SFP RSSI related alarms - eoltrssi : epon olt Sfp RSSI related alarms - cfm : Cfm related alarms - sfpe1t1-framer : SFP 2e1t1 framer alarms - sfpe1t1-clock : SFP 2e1t1 clock alarms - pppcc-engine-tca : PPPOE Cross Connect Engine TCA related alarm - eth-cfm : eth-cfm related alarms - rsvp : rsvp related alarms - ihub-tca : IHUB TCA related alarms - eth-ring : eth-ring related alarms - efm-oam : EFM-OAM related alarms - ont-loopdetect : ont loop detect related alarms	

name	Type	Description
	- ont-video : ont services video related alarms - ont-ces : ont services ces related alarms - ont-voip : ont services voip related alarms - ont-video-ani : ont services video ani related alarms - ont-pwe : ont services pwe related alarms - ont-cese1 : ont services cese1 related alarms - ont-xdsl : ont services xdsl related alarms - ont-xdsl-tca : ont services xdsl tca related alarms - ont-hpna : ont hpna related alarms - ont-sip-agent-cfg : ont services voip sip agent config related alarms - ont-voip-cfg : ont services voip config related alarms - ont-mgc : ont mgc related alarms - ont-ploam : ONT PLOAM related alarms - ont-gen : ONT GENERAL related alarms - ont-card : ONT Subscriber Card related alarms - ont-pots : ONT Services POTS related alarms - ont-lan : ONT Services LAN related alarms - ont-moca : ONT MoCA related alarms - ont-tc-tca : ONT TC TCA related alarms - ont-moca-tca : ONT MoCA TCA related alarms - ont-l2uni-eth-tca : ONT L2 UNI Ethernet TCA related alarms - olt-pon-tc-tca : OLT PON TC TCA related alarms - olt-pon-util-tca : OLT PON utilization TCA related alarms - olt-chpr-util-tca : OLT channel-pair utilization TCA related alarms - olt-ont-tc-tca : OLT ONT TC TCA related alarms - ont-tca : ONT TCA related alarms - ont-pots-supplemental : ONT POTS Supplemental related alarms - sfu-ploam : SFU ONT PLOAM related alarms - sfu-gen : SFU ONT general related alarms - soho-ploam : SOHO ONT PLOAM related alarms - soho-gen : SOHO ONT general related alarms - mdu-ploam : MDU ONT PLOAM related alarms - mdu-gen : MDU ONT general related alarms - ont-veip : ONT VEIP related alarms - ont-iphost : ONT IP HOST related alarms - alarm-table : alarm table related alarms - auto-switch : auto-switch related alarms - channel-pair : channel pair related alarms - ont-cfg-dld : ont configure file download related alarms - olt-chpair-tc-tca : OLT CHANNELPAIR TC TCA related alarms - hgu-tr069 : hgu tr069 related alarms - eqpt-psu : equipment psu alarms - ont-protection : ONT protection related alarms - secondary-megaco-term : secondary megaco termination related alarms - secondary-sip-term : secondary sip termination related alarms - cas-r2-channel : CAS R2 channel related alarms - lldpmed : lldpmed alarms - pseudo-wire : pseudo Wire related alarms - link-agg : Link aggregation related alarms - fcs-exceed : FCS auto-recovery related alarms	

101 query current alarms by filters

name	Type	Description
	- e1t1-interface : E1/T1 physical interfaces related alarms	
name	Parameter type: <Alarm::alarmTypeOntsipagentcfgithub> (ont-sipa-reg-nm-fail ont-sipa-reg-rec-fail ont-sipa-reg-con-fail ont-sipa-reg-val-fail ont-sipa-reg-mis all) Possible values: - ont-sipa-reg-nm-fail : sipua registration name failed - ont-sipa-reg-rec-fail : sipua register reach failed - ont-sipa-reg-con-fail : sipua register connect failed - ont-sipa-reg-val-fail : sipua register validation failed - ont-sipa-reg-mis : sipua register mismatch - all : ont services voip sip agent config related alarms	alarm name that are active <i>This element is only shown in detail mode.</i>
severity	Parameter type: <Alarm::AlarmSeverity> (indeterminate warning minor major critical) Possible values: - indeterminate : alarm severity is indeterminate - warning : alarm severity is warning - minor : alarm severity is minor - major : alarm severity is major - critical : alarm severity is critical	the alarms severity level <i>This element is only shown in detail mode.</i>
servaff	Parameter type: <Alarm::alarmServAffect> ((service-affecting yes) (noservice-affecting no)) Possible values: - service-affecting : make this alarm service affecting - yes : make this alarm service affecting - noservice-affecting : make this alarm not service affecting - no : make this alarm not service affecting	alarms affect service or not <i>This element is only shown in detail mode.</i>
time	Parameter type: <Sys::timeInSecs> - the time (yyyy-mm-dd:hour:minutes:secs) - unit: UTC	time in seconds when alarm was updated <i>This element is only shown in detail mode.</i>
descript	Parameter type: <Alarm::AddInfoString> - additional alarm information	alarm description <i>This element is only shown in detail mode.</i>

101.111 show current alarm by filters

Command Description

show current alarms by filters

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm query ont-voip-cfg [ (name) [ severity <Alarm::querySeverity> ] [ servaff <Alarm::queryServAffect> ] [ port <Gpon::IpHostCommonIndex> ] ]
```

Command Parameters

Table 101.111-1 "show current alarm by filters" Resource Parameters

Resource Identifier	Type	Description
(name)	Format: (ont-vcd-cfg-nm-fail ont-vcd-cfg-rech-fail ont-vcd-cfg-conn-fail ont-vcd-cfg-vali-fail ont-vcd-cfg-auth-fail ont-vcd-cfg-resp-tmout ont-vcd-cfg-resp-err ont-vcd-cfg-file-err ont-vcd-sub-nm-fail ont-vcd-sub-rech-fail ont-vcd-sub-conn-fail ont-vcd-sub-vali-fail ont-vcd-sub-auth-fail ont-vcd-sub-resp-tmout ont-vcd-sub-resp-err ont-vcd-reb-requ ont-vcd-mis all) Possible values: - ont-vcd-cfg-nm-fail : vcd config name failed - ont-vcd-cfg-rech-fail : vcd config reach failed - ont-vcd-cfg-conn-fail : vcd config connect failed - ont-vcd-cfg-vali-fail : vcd config validation failed - ont-vcd-cfg-auth-fail : vcd config authentication failed - ont-vcd-cfg-resp-tmout: vcd config response timeout - ont-vcd-cfg-resp-err : vcd config response error - ont-vcd-cfg-file-err : vcd config file error	alarm name of ont-voip-cfg

101 query current alarms by filters

Resource Identifier	Type	Description
	- ont-vcd-sub-nm-fail : vcd subscription name failed - ont-vcd-sub-rech-fail : vcd subscription reach failed - ont-vcd-sub-conn-fail : vcd subscription connect failed - ont-vcd-sub-vali-fail : vcd subscription validation failed - ont-vcd-sub-auth-fail : vcd subscription authentication failed - ont-vcd-sub-resp-tmout: vcd subscription response timeout - ont-vcd-sub-resp-err : vcd subscription response error - ont-vcd-reb-requ : vcd reboot request - ont-vcd-mis : vcd mismatch - all : ont services voip config related alarms	
severity	Parameter type: <Alarm::querySeverity> Format: (indeterminate warning minor major critical all) Possible values: - indeterminate : alarm severity is indeterminate - warning : alarm severity is warning - minor : alarm severity is minor - major : alarm severity is major - critical : alarm severity is critical - all : all alarm severity	severity level of an alarm for reporting
servaff	Parameter type: <Alarm::queryServAffect> Format: (service-affecting noservice-affecting all) Possible values: - service-affecting : query alarm service affecting - noservice-affecting : query alarm not service affecting - all : query service affecting and not affecting alarms	serviceaffecting no serviceaffecting
port	Parameter type: <Gpon::IpHostCommonIndex> Format: (ont : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Gpon::IpHostId> vlanport : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / vuni : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlanport : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / vuni : <Eqpt::UnstackedVlan> ont:ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / <Ng2::IpHostId> vlanport:ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / vuni : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlanport:ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / vuni : <Eqpt::UnstackedVlan>) Possible values: - ont:ng2 : ngpon2 ont - vlanport:ng2 : ngpon2 vlanport	gpon iphost port

Resource Identifier	Type	Description
	- ont : ont - vlanport : vlanport - Field type <Eqpt::RackId> - the rack number - Field type <Eqpt::ShelfId> - the shelf number - Field type <Eqpt::SlotId> - the LT slot number - Field type <Eqpt::PonId> - the PON identifier - Field type <Eqpt::OntId> - the ONT identifier - Field type <Eqpt::ChannelGroupId> - the channel group identifier - Field type <Eqpt::SubChannelGroupId> - the subchannel group identifier - Field type <Eqpt::Ng2OntId> - the NG2 ONT identifier - Possible values: - vuni : virtual uni identifier - Possible values: - vuni : virtual NGPON2 uni identifier - Field type <Gpon::IpHostID> - iphost id - Field type <Ng2::IpHostID> - iphost id (ngpon2) - Possible values: - stacked : stacked vlan identity - Field type <Eqpt::UnstackedVlan> - unstacked vlan id - Field type <Eqpt::SVlan> - service vlan id - Field type <Eqpt::CVlan> - customer vlan id	

Command Output

Table 101.111-2 "show current alarm by filters" Display parameters

Specific Information		
name	Type	Description
aidinfo	Parameter type: <Alarm::AddInfoString> - additional alarm information	alarm AID parameters <i>This element is only shown in detail mode.</i>
type	Parameter type: <Alarm::alarmIHUBType> (- equipment - eqpt-holder - plug-in-unit - atm - custom - e1 - ima-group - ima-link - redundancy - shdsl - ether-itf - traffic-overflow)	type of the alarms that are active <i>This element is only shown in detail mode.</i>

101 query current alarms by filters

name	Type	Description
	qos-queue temporal spatial (software-mngt sw-mgmt) xdsl xdsl-ext xdsl-tca olt-gen eo-conv authentication bonding sfp shdsl-isam custom-ext-alarm plug-in-unit-ext sip-user-agent sip-plugin-unit sip-termination e1-sip-termination filetransfer external-device l2forward ether-tca ether-sfp megaco-media-gw megaco-sig-gw megaco-plug-unit megaco-term megaco-sig-lt eqpt-supplemental eqpt-holder-ext lsmredundancy sync mcsrc vlanport vect-line vect-board otdr sip-dial-plan sip-vsp sip-server bgp rip lag ihub-general vprn isis ospf ihub-l2forward vpls ihub-equip ihub-link eont-phyoam ellid epon eont-services-lan eolt-ont-tca	

name	Type	Description
	eont-sw-dl ldp mpls sdp epipe ihub-ipv6 pim li mgmt-sec-access bfd ai tr069serv ontsnmp bulk-sync protection-group ont sfu-sup soho-sup mdu-sup ont-ani sfu-sup2 soho-sup2 mdu-sup2 sfprssi eoltrssi cfm sfpe1t1-framer sfpe1t1-clock pppcc-engine-tca eth-cfm rsvp ihub-tca eth-ring efm-oam ont-loopdetect ont-video ont-ces ont-voip ont-video-ani ont-pwe ont-cese1 ont-xdsl ont-xdsl-tca ont-hpna ont-sip-agent-cfg ont-voip-cfg ont-mgc ont-ploam ont-gen ont-card ont-pots ont-lan ont-moca ont-tc-tca ont-moca-tca ont-l2uni-eth-tca olt-pon-tc-tca	

101 query current alarms by filters

name	Type	Description
	olt-pon-util-tca olt-chpr-util-tca olt-ont-tc-tca ont-tca ont-pots-supplemental sfu-ploam sfu-gen soho-ploam soho-gen mdu-ploam mdu-gen ont-veip ont-iphost alarm-table auto-switch channel-pair ont-cfg-dld olt-chpair-tc-tca hgu-tr069 eqpt-psu ont-protection secondary-megaco-term secondary-sip-term cas-r2-channel lldpmed pseudo-wire link-agg fcs-exceed e1t1-interface) Possible values: - equipment : equipment alarms - eqpt-holder : equipment holder alarms - plug-in-unit : plugin unit alarms - atm : ATM alarms - custom : customizable alarms - e1 : e1 alarms - ima-group : ima-group alarms - ima-link : ima-link alarms - redundancy : redundancy alarms - shdsl : shdsl alarms - ether-itf : ethernet interface alarms - traffic-overflow : Traffic overflow alarms - qos-queue : qos queue alarms - temporal : temporal alarms - spatial : spatial alarms - software-mngt : software management alarms - sw-mgmt : software management alarms - xdsl : xDSL alarms - xdsl-ext : other xDSL alarms - xdsl-tca : xDSL threshold cross alarms - olt-gen : OLT general alarms - eo-conv : E/O conversion related alarms - authentication : authentication related alarms - bonding : bonding-group related alarms - sfp : SFP related alarms - shdsl-isam : shdsl isam alarms - custom-ext-alarm : customizable external alarms	

name	Type	Description
	- plug-in-unit-ext : other plugin unit alarms - sip-user-agent : sip user agent related alarms - sip-plugin-unit : sip plug in unit related alarms - sip-termination : sip termination related alarms - e1-sip-termination : E1 sip termination related alarms - filetransfer : file transfer server alarms - external-device : external device related alarms - l2forward : l2forward related alarms - ether-tca : ethernet threshold cross alarms - ether-sfp : ethernet SFP related alarms - megaco-media-gw : megaco media gateway related alarms - megaco-sig-gw : megaco signaling gateway related alarms - megaco-plug-unit : megaco plug unit related alarms - megaco-term : megaco termination related alarms - megaco-sig-lt : megaco signaling lt related alarms - eqpt-supplemental : equipment supplemental alarms - eqpt-holder-ext : other equipment holder alarms - lsmredundancy : lsm redundancy alarms - sync : synce and bits alarms - mcsrc : multicast source alarms - vlanport : vlanport alarms - vect-line : xDSL vectoring line alarms - vect-board : xDSL vectoring board alarms - otdr : otdr alarms - sip-dial-plan : sip dial plan related alarms - sip-vsp : sip vsp related alarms - sip-server : sip server related alarms - bgp : bgp related alarms - rip : rip related alarms - lag : LAG related alarms - ihub-general : IHUB general related alarms - vprn : vprn related alarms - isis : isis related alarms - ospf : ospf related alarms - ihub-l2forward : ihub-l2forward alarms - vpls : vpls related alarms - ihub-equip : ihub-equip related alarms - ihub-link : ihub-link related alarms - eont-phyoam : eont phyoam related alarms - ellid : ellid related alarms - epon : epon related alarms - eont-services-lan : eon phyoam related alarms - eolt-ont-tca : eon phyoam related alarms - eont-sw-dl : eon phyoam related alarms - ldp : ldp related alarms - mpls : mpls related alarms - sdp : sdp related alarms - epipe : epipe related alarms - ihub-ipv6 : ihub-ipv6 related alarms - pim : pim related alarms - li : lawful intercept related alarms - mgmt-sec-access : management security related alarms - bfd : bfd related alarms - ai : Application Intelligence related alarms - tr069serv : tr069 server related alarms - ontsnmp : ont snmp related alarms - bulk-sync : bulk-sync related alarms	

101 query current alarms by filters

name	Type	Description
	- protection-group : port protection group related alarms - ont : ONT general supplemental related alarms - sfu-sup : SFU ONT general supplemental related alarms - soho-sup : SOHO ONT general supplemental related alarms - mdu-sup : MDU ONT general supplemental related alarms - ont-ani : ONT general supplemental 2 related alarms - sfu-sup2 : SFU ONT general supplemental 2 related alarms - soho-sup2 : SOHO ONT general supplemental 2 related alarms - mdu-sup2 : MDU ONT general supplemental 2 related alarms - sfprssi : SFP RSSI related alarms - eoltrssi : epon olt Sfp RSSI related alarms - cfm : Cfm related alarms - sfpe1t1-framer : SFP 2e1t1 framer alarms - sfpe1t1-clock : SFP 2e1t1 clock alarms - pppcc-engine-tca : PPPOE Cross Connect Engine TCA related alarm - eth-cfm : eth-cfm related alarms - rsvp : rsvp related alarms - ihub-tca : IHUB TCA related alarms - eth-ring : eth-ring related alarms - efm-oam : EFM-OAM related alarms - ont-loopdetect : ont loop detect related alarms - ont-video : ont services video related alarms - ont-ces : ont services ces related alarms - ont-voip : ont services voip related alarms - ont-video-ani : ont services video ani related alarms - ont-pwe : ont services pwe related alarms - ont-cese1 : ont services cese1 related alarms - ont-xdsl : ont services xdsl related alarms - ont-xdsl-tca : ont services xdsl tca related alarms - ont-hpna : ont hpna related alarms - ont-sip-agent-cfg : ont services voip sip agent config related alarms - ont-voip-cfg : ont services voip config related alarms - ont-mgc : ont mgc related alarms - ont-ploam : ONT PLOAM related alarms - ont-gen : ONT GENERAL related alarms - ont-card : ONT Subscriber Card related alarms - ont-pots : ONT Services POTS related alarms - ont-lan : ONT Services LAN related alarms - ont-moca : ONT MoCA related alarms - ont-tc-tca : ONT TC TCA related alarms - ont-moca-tca : ONT MoCA TCA related alarms - ont-l2uni-eth-tca : ONT L2 UNI Ethernet TCA related alarms - olt-pon-tc-tca : OLT PON TC TCA related alarms - olt-pon-util-tca : OLT PON utilization TCA related alarms - olt-chpr-util-tca : OLT channel-pair utilization TCA related alarms - olt-ont-tc-tca : OLT ONT TC TCA related alarms - ont-tca : ONT TCA related alarms - ont-pots-supplemental : ONT POTS Supplemental related alarms - sfu-ploam : SFU ONT PLOAM related alarms	

name	Type	Description
	- sfu-gen : SFU ONT general related alarms - soho-ploam : SOHO ONT PLOAM related alarms - soho-gen : SOHO ONT general related alarms - mdu-ploam : MDU ONT PLOAM related alarms - mdu-gen : MDU ONT general related alarms - ont-veip : ONT VEIP related alarms - ont-iphost : ONT IP HOST related alarms - alarm-table : alarm table related alarms - auto-switch : auto-switch related alarms - channel-pair : channel pair related alarms - ont-cfg-dld : ont configure file download related alarms - olt-chpair-tc-tca : OLT CHANNELPAIR TC TCA related alarms - hgu-tr069 : hgu tr069 related alarms - eqpt-psu : equipment psu alarms - ont-protection : ONT protection related alarms - secondary-megaco-term : secondary megaco termination related alarms - secondary-sip-term : secondary sip termination related alarms - cas-r2-channel : CAS R2 channel related alarms - lldpmed : lldpmed alarms - pseudo-wire : pseudo Wire related alarms - link-agg : Link aggregation related alarms - fcs-exceed : FCS auto-recovery related alarms - e1t1-interface : E1/T1 physical interfaces related alarms	
name	Parameter type: <Alarm::almtypeOntvoipcfgihub> (ont-vcd-cfg-nm-fail ont-vcd-cfg-rech-fail ont-vcd-cfg-conn-fail ont-vcd-cfg-vali-fail ont-vcd-cfg-auth-fail ont-vcd-cfg-resp-tmout ont-vcd-cfg-resp-err ont-vcd-cfg-file-err ont-vcd-sub-nm-fail ont-vcd-sub-rech-fail ont-vcd-sub-conn-fail ont-vcd-sub-vali-fail ont-vcd-sub-auth-fail ont-vcd-sub-resp-tmout ont-vcd-sub-resp-err ont-vcd-reb-requ ont-vcd-mis all) Possible values: - ont-vcd-cfg-nm-fail : vcd config name failed - ont-vcd-cfg-rech-fail : vcd config reach failed - ont-vcd-cfg-conn-fail : vcd config connect failed - ont-vcd-cfg-vali-fail : vcd config validation failed - ont-vcd-cfg-auth-fail : vcd config authentication failed - ont-vcd-cfg-resp-tmout: vcd config response timeout - ont-vcd-cfg-resp-err : vcd config response error - ont-vcd-cfg-file-err : vcd config file error - ont-vcd-sub-nm-fail : vcd subscription name failed - ont-vcd-sub-rech-fail : vcd subscription reach failed - ont-vcd-sub-conn-fail : vcd subscription connect failed	alarm name that are active <i>This element is only shown in detail mode.</i>

101 query current alarms by filters

name	Type	Description
	- ont-vcd-sub-vali-fail : vcd subscription validation failed - ont-vcd-sub-auth-fail : vcd subscription authentication failed - ont-vcd-sub-resp-tmout: vcd subscription response timeout - ont-vcd-sub-resp-err : vcd subscription response error - ont-vcd-reb-requ : vcd reboot request - ont-vcd-mis : vcd mismatch - all : ont services voip config related alarms	
severity	Parameter type: <Alarm::AlarmSeverity> (indeterminate warning minor major critical) Possible values: - indeterminate : alarm severity is indeterminate - warning : alarm severity is warning - minor : alarm severity is minor - major : alarm severity is major - critical : alarm severity is critical	the alarms severity level <i>This element is only shown in detail mode.</i>
servaff	Parameter type: <Alarm::alarmServAffect> ((service-affecting yes) (noservice-affecting no)) Possible values: - service-affecting : make this alarm service affecting - yes : make this alarm service affecting - noservice-affecting : make this alarm not service affecting - no : make this alarm not service affecting	alarms affect service or not <i>This element is only shown in detail mode.</i>
time	Parameter type: <Sys::timeInSecs> - the time (yyyy-mm-dd:hour:minutes:secs) - unit: UTC	time in seconds when alarm was updated <i>This element is only shown in detail mode.</i>
descript	Parameter type: <Alarm::AddInfoString> - additional alarm information	alarm description <i>This element is only shown in detail mode.</i>

101.112 show current alarm by filters

Command Description

show current alarms by filters

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm query ont-veip [ (name) [ severity <Alarm::querySeverity> ] [ servaff <Alarm::queryServAffect> ] [
ont-port <Alarm::queryDefaultAid> ] ]
```

Command Parameters

Table 101.112-1 "show current alarm by filters" Resource Parameters

Resource Identifier	Type	Description
(name)	Format: (ont-veip-mismatch all) Possible values: - ont-veip-mismatch : ont veip mismatch - all : ONT VEIP related alarms	alarm name of ont-veip
severity	Parameter type: <Alarm::querySeverity> Format: (indeterminate warning minor major critical all) Possible values: - indeterminate : alarm severity is indeterminate - warning : alarm severity is warning - minor : alarm severity is minor - major : alarm severity is major - critical : alarm severity is critical - all : all alarm severity	severity level of an alarm for reporting
servaff	Parameter type: <Alarm::queryServAffect> Format: (service-affecting noservice-affecting all) Possible values: - service-affecting : query alarm service affecting	serviceaffecting no

101 query current alarms by filters

Resource Identifier	Type	Description
	- noservice-affecting : query alarm not service affecting - all : query service affecting and not affecting alarms	
ont-port	Parameter type: <Alarm::queryDefaultAid> Format: all Possible values: - all : default AID parameter	gpon ont port is all

Command Output

Table 101.112-2 "show current alarm by filters" Display parameters

Specific Information		
name	Type	Description
aidinfo	Parameter type: <Alarm::AddInfoString> - additional alarm information	alarm AID parameters <i>This element is only shown in detail mode.</i>
type	Parameter type: <Alarm::alarmIHUBType> (equipment eqpt-holder plug-in-unit atm custom e1 ima-group ima-link redundancy shdsl ether-itf traffic-overflow qos-queue temporal spatial (software-mngt sw-mgmt) xdsl xdsl-ext xdsl-tca olt-gen eo-conv authentication bonding sfp shdsl-isam custom-ext-alarm plug-in-unit-ext sip-user-agent sip-plugin-unit sip-termination e1-sip-termination filetransfer external-device l2forward ether-tca ether-sfp megaco-media-gw megaco-sig-gw megaco-plugin-unit	type of the alarms that are active <i>This element is only shown in detail mode.</i>

name	Type	Description
	megaco-term megaco-sig-lt eqpt-supplemental eqpt-holder-ext lsmredundancy sync mcsrc vlanport vect-line vect-board otdr sip-dial-plan sip-vsp sip-server bgp rip lag ihub-general vprn isis ospf ihub-l2forward vpls ihub-equip ihub-link eont-phyoam ellid epon eont-services-lan eolt-ont-tca eont-sw-dl ldp mpls sdp epipe ihub-ipv6 pim li mgmt-sec-access bfd ai tr069serv ontsnmp bulk-sync protection-group ont sfu-sup soho-sup mdu-sup ont-ani sfu-sup2 soho-sup2 mdu-sup2 sfprssi eoltrssi cfm sfpe1t1-framer	

101 query current alarms by filters

name	Type	Description
	sfpe1t1-clock pppcc-engine-tca eth-cfm rsvp ihub-tca eth-ring efm-oam ont-loopdetect ont-video ont-ces ont-voip ont-video-ani ont-pwe ont-cese1 ont-xdsl ont-xdsl-tca ont-hpna ont-sip-agent-cfg ont-voip-cfg ont-mgc ont-ploam ont-gen ont-card ont-pots ont-lan ont-moca ont-tc-tca ont-moca-tca ont-l2uni-eth-tca olt-pon-tc-tca olt-pon-util-tca olt-chpr-util-tca olt-ont-tc-tca ont-tca ont-pots-supplemental sfu-ploam sfu-gen soho-ploam soho-gen mdu-ploam mdu-gen ont-veip ont-iphost alarm-table auto-switch channel-pair ont-cfg-dld olt-chpair-tc-tca hgu-tr069 eqpt-psu ont-protection secondary-megaco-term secondary-sip-term cas-r2-channel lldpmed pseudo-wire link-agg	

name	Type	Description
	fcs-exceed e1t1-interface) Possible values: - equipment : equipment alarms - eqpt-holder : equipment holder alarms - plug-in-unit : plugin unit alarms - atm : ATM alarms - custom : customizable alarms - e1 : e1 alarms - ima-group : ima-group alarms - ima-link : ima-link alarms - redundancy : redundancy alarms - shdsl : shdsl alarms - ether-itf : ethernet interface alarms - traffic-overflow : Traffic overflow alarms - qos-queue : qos queue alarms - temporal : temporal alarms - spatial : spatial alarms - software-mngt : software management alarms - sw-mgmt : software management alarms - xdsl : xDSL alarms - xdsl-ext : other xDSL alarms - xdsl-tca : xDSL threshold cross alarms - olt-gen : OLT general alarms - eo-conv : E/O conversion related alarms - authentication : authentication related alarms - bonding : bonding-group related alarms - sfp : SFP related alarms - shdsl-isam : shdsl isam alarms - custom-ext-alarm : customizable external alarms - plug-in-unit-ext : other plugin unit alarms - sip-user-agent : sip user agent related alarms - sip-plugin-unit : sip plug in unit related alarms - sip-termination : sip termination related alarms - e1-sip-termination : E1 sip termination related alarms - filetransfer : file transfer server alarms - external-device : external device related alarms - l2forward : l2forward related alarms - ether-tca : ethernet threshold cross alarms - ether-sfp : ethernet SFP related alarms - megaco-media-gw : megaco media gateway related alarms - megaco-sig-gw : megaco signaling gateway related alarms - megaco-plug-unit : megaco plug unit related alarms - megaco-term : megaco termination related alarms - megaco-sig-lt : megaco signaling lt related alarms - eqpt-supplemental : equipment supplemental alarms - eqpt-holder-ext : other equipment holder alarms - lsmredundancy : lsm redundancy alarms - sync : synce and bits alarms - mcsrc : multicast source alarms - vlanport : vlanport alarms - vect-line : xDSL vectoring line alarms - vect-board : xDSL vectoring board alarms - otdr : otdr alarms - sip-dial-plan : sip dial plan related alarms - sip-vsp : sip vsp related alarms - sip-server : sip server related alarms	

101 query current alarms by filters

name	Type	Description
	- bgp : bgp related alarms - rip : rip related alarms - lag : LAG related alarms - ihub-general : IHUB general related alarms - vprn : vprn related alarms - isis : isis related alarms - ospf : ospf related alarms - ihub-l2forward : ihub-l2forward alarms - vpls : vpls related alarms - ihub-equip : ihub-equip related alarms - ihub-link : ihub-link related alarms - eont-phyoam : eont phyoam related alarms - ellid : ellid related alarms - epon : epon related alarms - eont-services-lan : eon phyoam related alarms - eolt-ont-tca : eon phyoam related alarms - eont-sw-dl : eon phyoam related alarms - ldp : ldp related alarms - mpls : mpls related alarms - sdp : sdp related alarms - epipe : epipe related alarms - ihub-ipv6 : ihub-ipv6 related alarms - pim : pim related alarms - li : lawful intercept related alarms - mgmt-sec-access : management security related alarms - bfd : bfd related alarms - ai : Application Intelligence related alarms - tr069serv : tr069 server related alarms - ontsnmp : ont snmp related alarms - bulk-sync : bulk-sync related alarms - protection-group : port protection group related alarms - ont : ONT general supplemental related alarms - sfu-sup : SFU ONT general supplemental related alarms - soho-sup : SOHO ONT general supplemental related alarms - mdu-sup : MDU ONT general supplemental related alarms - ont-ani : ONT general supplemental 2 related alarms - sfu-sup2 : SFU ONT general supplemental 2 related alarms - soho-sup2 : SOHO ONT general supplemental 2 related alarms - mdu-sup2 : MDU ONT general supplemental 2 related alarms - sfprssi : SFP RSSI related alarms - eoltrssi : epon olt Sfp RSSI related alarms - cfm : Cfm related alarms - sfpe1t1-framer : SFP 2e1t1 framer alarms - sfpe1t1-clock : SFP 2e1t1 clock alarms - pppcc-engine-tca : PPPOE Cross Connect Engine TCA related alarm - eth-cfm : eth-cfm related alarms - rsvp : rsvp related alarms - ihub-tca : IHUB TCA related alarms - eth-ring : eth-ring related alarms - efm-oam : EFM-OAM related alarms - ont-loopdetect : ont loop detect related alarms - ont-video : ont services video related alarms - ont-ces : ont services ces related alarms	

name	Type	Description
	- ont-voip : ont services voip related alarms - ont-video-ani : ont services video ani related alarms - ont-pwe : ont services pwe related alarms - ont-cese1 : ont services cese1 related alarms - ont-xdsl : ont services xdsl related alarms - ont-xdsl-tca : ont services xdsl tca related alarms - ont-hpna : ont hpna related alarms - ont-sip-agent-cfg : ont services voip sip agent config related alarms - ont-voip-cfg : ont services voip config related alarms - ont-mgc : ont mgc related alarms - ont-ploam : ONT PLOAM related alarms - ont-gen : ONT GENERAL related alarms - ont-card : ONT Subscriber Card related alarms - ont-pots : ONT Services POTS related alarms - ont-lan : ONT Services LAN related alarms - ont-moca : ONT MoCA related alarms - ont-tc-tca : ONT TC TCA related alarms - ont-moca-tca : ONT MoCA TCA related alarms - ont-l2uni-eth-tca : ONT L2 UNI Ethernet TCA related alarms - olt-pon-tc-tca : OLT PON TC TCA related alarms - olt-pon-util-tca : OLT PON utilization TCA related alarms - olt-chpr-util-tca : OLT channel-pair utilization TCA related alarms - olt-ont-tc-tca : OLT ONT TC TCA related alarms - ont-tca : ONT TCA related alarms - ont-pots-supplemental : ONT POTS Supplemental related alarms - sfu-ploam : SFU ONT PLOAM related alarms - sfu-gen : SFU ONT general related alarms - soho-ploam : SOHO ONT PLOAM related alarms - soho-gen : SOHO ONT general related alarms - mdu-ploam : MDU ONT PLOAM related alarms - mdu-gen : MDU ONT general related alarms - ont-veip : ONT VEIP related alarms - ont-iphost : ONT IP HOST related alarms - alarm-table : alarm table related alarms - auto-switch : auto-switch related alarms - channel-pair : channel pair related alarms - ont-cfg-dld : ont configure file download related alarms - olt-chpair-tc-tca : OLT CHANNELPAIR TC TCA related alarms - hgu-tr069 : hgu tr069 related alarms - eqpt-psu : equipment psu alarms - ont-protection : ONT protection related alarms - secondary-megaco-term : secondary megaco termination related alarms - secondary-sip-term : secondary sip termination related alarms - cas-r2-channel : CAS R2 channel related alarms - lldpmed : lldpmed alarms - pseudo-wire : pseudo Wire related alarms - link-agg : Link aggregation related alarms - fcs-exceed : FCS auto-recovery related alarms - e1t1-interface : E1/T1 physical interfaces related alarms	
name	Parameter type: <Alarm::almltypeOntveipihub>	alarm name that are active

101 query current alarms by filters

name	Type	Description
	(ont-veip-mismatch all) Possible values: - ont-veip-mismatch : ont veip mismatch - all : ONT VEIP related alarms	<i>This element is only shown in detail mode.</i>
severity	Parameter type: <Alarm::AlarmSeverity> (indeterminate warning minor major critical) Possible values: - indeterminate : alarm severity is indeterminate - warning : alarm severity is warning - minor : alarm severity is minor - major : alarm severity is major - critical : alarm severity is critical	the alarms severity level <i>This element is only shown in detail mode.</i>
servaff	Parameter type: <Alarm::alarmServAffect> ((service-affecting yes) (noservice-affecting no)) Possible values: - service-affecting : make this alarm service affecting - yes : make this alarm service affecting - noservice-affecting : make this alarm not service affecting - no : make this alarm not service affecting	alarms affect service or not <i>This element is only shown in detail mode.</i>
time	Parameter type: <Sys::timeInSecs> - the time (yyyy-mm-dd:hour:minutes:secs) - unit: UTC	time in seconds when alarm was updated <i>This element is only shown in detail mode.</i>
descript	Parameter type: <Alarm::AddInfoString> - additional alarm information	alarm description <i>This element is only shown in detail mode.</i>

101.113 show current alarm by filters

Command Description

show current alarms by filters

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm query ont-mgc [ (name) [ severity <Alarm::querySeverity> ] [ servaff <Alarm::queryServAffect> ] [ port <Gpon::IpHostCommonIndex> ] ]
```

Command Parameters

Table 101.113-1 "show current alarm by filters" Resource Parameters

Resource Identifier	Type	Description
(name)	Format: (ont-mgc-mis ont-mgc-timeout all) Possible values: - ont-mgc-mis : ont mgc mismatch - ont-mgc-timeout : ont mgc timeout - all : ont mgc related alarms	alarm name of ont-mgc
severity	Parameter type: <Alarm::querySeverity> Format: (indeterminate warning minor major critical all) Possible values: - indeterminate : alarm severity is indeterminate - warning : alarm severity is warning - minor : alarm severity is minor - major : alarm severity is major - critical : alarm severity is critical - all : all alarm severity	severity level of an alarm for reporting
servaff	Parameter type: <Alarm::queryServAffect> Format: (service-affecting noservice-affecting all)	serviceaffecting no

101 query current alarms by filters

Resource Identifier	Type	Description
	Possible values: - service-affecting : query alarm service affecting - noservice-affecting : query alarm not service affecting - all : query service affecting and not affecting alarms	
port	Parameter type: <Gpon::IpHostCommonIndex> Format: (ont : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Gpon::IpHostID> vlanport : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / vuni : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlanport : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / vuni : <Eqpt::UnstackedVlan> ont.ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / <Ng2::IpHostID> vlanport.ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / vuni : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlanport.ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / vuni : <Eqpt::UnstackedVlan>) Possible values: - ont.ng2 : ngpon2 ont - vlanport.ng2 : ngpon2 vlanport - ont : ont - vlanport : vlanport Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Eqpt::OntId> - the ONT identifier Field type <Eqpt::ChannelGroupId> - the channel group identifier Field type <Eqpt::SubChannelGroupId> - the subchannel group identifier Field type <Eqpt::Ng2OntId> - the NG2 ONT identifier Possible values: - vuni : virtual uni identifier Possible values: - vuni : virtual NGPON2 uni identifier Field type <Gpon::IpHostID> - iphost id Field type <Ng2::IpHostID> - iphost id (ngpon2) Possible values: - stacked : stacked vlan identity Field type <Eqpt::UnstackedVlan> - unstacked vlan id Field type <Eqpt::SVlan>	gpon iphost port

Resource Identifier	Type	Description
	- service vlan id Field type <Eqpt::CVlan> - customer vlan id	

Command Output

Table 101.113-2 "show current alarm by filters" Display parameters

Specific Information		
name	Type	Description
aidinfo	Parameter type: <Alarm::AddInfoString> - additional alarm information	alarm AID parameters <i>This element is only shown in detail mode.</i>
type	Parameter type: <Alarm::alarmIHUBType> (equipment eqpt-holder plug-in-unit atm custom e1 ima-group ima-link redundancy shdsl ether-itf traffic-overflow qos-queue temporal spatial (software-mngt sw-mgmt) xdsl xdsl-ext xdsl-tca olt-gen eo-conv authentication bonding sfp shdsl-isam custom-ext-alarm plug-in-unit-ext sip-user-agent sip-plugin-unit sip-termination e1-sip-termination filetransfer external-device l2forward ether-tca ether-sfp megaco-media-gw megaco-sig-gw megaco-plug-unit megaco-term megaco-sig-lt eqpt-supplemental eqpt-holder-ext	type of the alarms that are active <i>This element is only shown in detail mode.</i>

101 query current alarms by filters

name	Type	Description
	lsmredundancy	
	sync	
	mcsrc	
	vlanport	
	vect-line	
	vect-board	
	otdr	
	sip-dial-plan	
	sip-vsp	
	sip-server	
	bgp	
	rip	
	lag	
	ihub-general	
	vprn	
	isis	
	ospf	
	ihub-l2forward	
	vpls	
	ihub-equip	
	ihub-link	
	eont-phyoam	
	ellid	
	epon	
	eont-services-lan	
	eolt-ont-tca	
	eont-sw-dl	
	ldp	
	mpls	
	sdp	
	epipe	
	ihub-ipv6	
	pim	
	li	
	mgmt-sec-access	
	bfd	
	ai	
	tr069serv	
	ontsnmp	
	bulk-sync	
	protection-group	
	ont	
	sfu-sup	
	soho-sup	
	mdu-sup	
	ont-ani	
	sfu-sup2	
	soho-sup2	
	mdu-sup2	
	sfprssi	
	eoltrssi	
	cfm	
	sfpe1t1-framer	
	sfpe1t1-clock	
	pppcc-engine-tca	
	eth-cfm	
	rsvp	

name	Type	Description
	ihub-tca eth-ring efm-oam ont-loopdetect ont-video ont-ces ont-voip ont-video-ani ont-pwe ont-cese1 ont-xdsl ont-xdsl-tca ont-hpna ont-sip-agent-cfg ont-voip-cfg ont-mgc ont-ploam ont-gen ont-card ont-pots ont-lan ont-moca ont-tc-tca ont-moca-tca ont-l2uni-eth-tca olt-pon-tc-tca olt-pon-util-tca olt-chpr-util-tca olt-ont-tc-tca ont-tca ont-pots-supplemental sfu-ploam sfu-gen soho-ploam soho-gen mdu-ploam mdu-gen ont-veip ont-iphost alarm-table auto-switch channel-pair ont-cfg-dld olt-chpair-tc-tca hgu-tr069 eqpt-psu ont-protection secondary-megaco-term secondary-sip-term cas-r2-channel lldpmed pseudo-wire link-agg fcs-exceed e1t1-interface) Possible values: - equipment : equipment alarms	

101 query current alarms by filters

name	Type	Description
	- eqpt-holder : equipment holder alarms - plug-in-unit : plugin unit alarms - atm : ATM alarms - custom : customizable alarms - e1 : e1 alarms - ima-group : ima-group alarms - ima-link : ima-link alarms - redundancy : redundancy alarms - shdsl : shdsl alarms - ether-itf : ethernet interface alarms - traffic-overflow : Traffic overflow alarms - qos-queue : qos queue alarms - temporal : temporal alarms - spatial : spatial alarms - software-mngt : software management alarms - sw-mgmt : software management alarms - xdsl : xDSL alarms - xdsl-ext : other xDSL alarms - xdsl-tca : xDSL threshold cross alarms - olt-gen : OLT general alarms - eo-conv : E/O conversion related alarms - authentication : authentication related alarms - bonding : bonding-group related alarms - sfp : SFP related alarms - shdsl-isam : shdsl isam alarms - custom-ext-alarm : customizable external alarms - plug-in-unit-ext : other plugin unit alarms - sip-user-agent : sip user agent related alarms - sip-plugin-unit : sip plug in unit related alarms - sip-termination : sip termination related alarms - e1-sip-termination : E1 sip termination related alarms - filetransfer : file transfer server alarms - external-device : external device related alarms - l2forward : l2forward related alarms - ether-tca : ethernet threshold cross alarms - ether-sfp : ethernet SFP related alarms - megaco-media-gw : megaco media gateway related alarms - megaco-sig-gw : megaco signaling gateway related alarms - megaco-plug-unit : megaco plug unit related alarms - megaco-term : megaco termination related alarms - megaco-sig-lt : megaco signaling lt related alarms - eqpt-supplemental : equipment supplemental alarms - eqpt-holder-ext : other equipment holder alarms - lsmredundancy : lsm redundancy alarms - sync : synce and bits alarms - mcsrc : multicast source alarms - vlanport : vlanport alarms - vect-line : xDSL vectoring line alarms - vect-board : xDSL vectoring board alarms - otdr : otdr alarms - sip-dial-plan : sip dial plan related alarms - sip-vsp : sip vsp related alarms - sip-server : sip server related alarms - bgp : bgp related alarms - rip : rip related alarms - lag : LAG related alarms - ihub-general : IHUB general related alarms	

name	Type	Description
	- vprn : vprn related alarms - isis : isis related alarms - ospf : ospf related alarms - ihub-l2forward : ihub-l2forward alarms - vpls : vpls related alarms - ihub-equip : ihub-equip related alarms - ihub-link : ihub-link related alarms - eont-phyoam : eont phyoam related alarms - ellid : ellid related alarms - epon : epon related alarms - eont-services-lan : eon phyoam related alarms - eolt-ont-tca : eon phyoam related alarms - eont-sw-dl : eon phyoam related alarms - ldp : ldp related alarms - mpls : mpls related alarms - sdp : sdp related alarms - epipe : epipe related alarms - ihub-ipv6 : ihub-ipv6 related alarms - pim : pim related alarms - li : lawful intercept related alarms - mgmt-sec-access : management security related alarms - bfd : bfd related alarms - ai : Application Intelligence related alarms - tr069serv : tr069 server related alarms - ontsnmp : ont snmp related alarms - bulk-sync : bulk-sync related alarms - protection-group : port protection group related alarms - ont : ONT general supplemental related alarms - sfu-sup : SFU ONT general supplemental related alarms - soho-sup : SOHO ONT general supplemental related alarms - mdu-sup : MDU ONT general supplemental related alarms - ont-ani : ONT general supplemental 2 related alarms - sfu-sup2 : SFU ONT general supplemental 2 related alarms - soho-sup2 : SOHO ONT general supplemental 2 related alarms - mdu-sup2 : MDU ONT general supplemental 2 related alarms - sfprssi : SFP RSSI related alarms - eoltrssi : epon olt Sfp RSSI related alarms - cfm : Cfm related alarms - sfpe1t1-framer : SFP 2e1t1 framer alarms - sfpe1t1-clock : SFP 2e1t1 clock alarms - pppcc-engine-tca : PPPOE Cross Connect Engine TCA related alarm - eth-cfm : eth-cfm related alarms - rsvp : rsvp related alarms - ihub-tca : IHUB TCA related alarms - eth-ring : eth-ring related alarms - efm-oam : EFM-OAM related alarms - ont-loopdetect : ont loop detect related alarms - ont-video : ont services video related alarms - ont-ces : ont services ces related alarms - ont-voip : ont services voip related alarms - ont-video-ani : ont services video ani related alarms - ont-pwe : ont services pwe related alarms - ont-cese1 : ont services cese1 related alarms	

101 query current alarms by filters

name	Type	Description
	- ont-xdsl : ont services xdsl related alarms - ont-xdsl-tca : ont services xdsl tca related alarms - ont-hpna : ont hpna related alarms - ont-sip-agent-cfg : ont services voip sip agent config related alarms - ont-voip-cfg : ont services voip config related alarms - ont-mgc : ont mgc related alarms - ont-ploam : ONT PLOAM related alarms - ont-gen : ONT GENERAL related alarms - ont-card : ONT Subscriber Card related alarms - ont-pots : ONT Services POTS related alarms - ont-lan : ONT Services LAN related alarms - ont-moca : ONT MoCA related alarms - ont-tc-tca : ONT TC TCA related alarms - ont-moca-tca : ONT MoCA TCA related alarms - ont-l2uni-eth-tca : ONT L2 UNI Ethernet TCA related alarms - olt-pon-tc-tca : OLT PON TC TCA related alarms - olt-pon-util-tca : OLT PON utilization TCA related alarms - olt-chpr-util-tca : OLT channel-pair utilization TCA related alarms - olt-ont-tc-tca : OLT ONT TC TCA related alarms - ont-tca : ONT TCA related alarms - ont-pots-supplemental : ONT POTS Supplemental related alarms - sfu-ploam : SFU ONT PLOAM related alarms - sfu-gen : SFU ONT general related alarms - soho-ploam : SOHO ONT PLOAM related alarms - soho-gen : SOHO ONT general related alarms - mdu-ploam : MDU ONT PLOAM related alarms - mdu-gen : MDU ONT general related alarms - ont-veip : ONT VEIP related alarms - ont-iphost : ONT IP HOST related alarms - alarm-table : alarm table related alarms - auto-switch : auto-switch related alarms - channel-pair : channel pair related alarms - ont-cfg-dld : ont configure file download related alarms - olt-chpair-tc-tca : OLT CHANNELPAIR TC TCA related alarms - hgu-tr069 : hgu tr069 related alarms - eqpt-psu : equipment psu alarms - ont-protection : ONT protection related alarms - secondary-megaco-term : secondary megaco termination related alarms - secondary-sip-term : secondary sip termination related alarms - cas-r2-channel : CAS R2 channel related alarms - lldpmed : lldpmed alarms - pseudo-wire : pseudo Wire related alarms - link-agg : Link aggregation related alarms - fcs-exceed : FCS auto-recovery related alarms - e1t1-interface : E1/T1 physical interfaces related alarms	
name	Parameter type: <Alarm::almtypOntmgcihub> (ont-mgc-mis ont-mgc-timeout all) Possible values:	alarm name that are active <i>This element is only shown in detail mode.</i>

name	Type	Description
	- ont-mgc-mis : ont mgc mismatch - ont-mgc-timeout : ont mgc timeout - all : ont mgc related alarms	
severity	Parameter type: <Alarm::AlarmSeverity> (indeterminate warning minor major critical) Possible values: - indeterminate : alarm severity is indeterminate - warning : alarm severity is warning - minor : alarm severity is minor - major : alarm severity is major - critical : alarm severity is critical	the alarms severity level <i>This element is only shown in detail mode.</i>
servaff	Parameter type: <Alarm::alarmServAffect> ((service-affecting yes) (noservice-affecting no)) Possible values: - service-affecting : make this alarm service affecting - yes : make this alarm service affecting - noservice-affecting : make this alarm not service affecting - no : make this alarm not service affecting	alarms affect service or not <i>This element is only shown in detail mode.</i>
time	Parameter type: <Sys::timeInSecs> - the time (yyyy-mm-dd:hour:minutes:secs) - unit: UTC	time in seconds when alarm was updated <i>This element is only shown in detail mode.</i>
descript	Parameter type: <Alarm::AddInfoString> - additional alarm information	alarm description <i>This element is only shown in detail mode.</i>

101.114 show current alarm by filters

Command Description

show current alarms by filters

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm query ont-iphost [ (name) [ severity <Alarm::querySeverity> ] [ servaff <Alarm::queryServAffect> ]  
[ port <Gpon::IpHostCommonIndex> ] ]
```

Command Parameters

Table 101.114-1 "show current alarm by filters" Resource Parameters

Resource Identifier	Type	Description
(name)	Format: (ont-ip-host-mismatch ont-ip-host-file ont-ip-host-ip-alloc all) Possible values: - ont-ip-host-mismatch : ont ip host mismatch - ont-ip-host-file : ont ip host file unavailable - ont-ip-host-ip-alloc : ont ip host IP allocation failure - all : ONT IP HOST related alarms	alarm name of ont-iphost
severity	Parameter type: <Alarm::querySeverity> Format: (indeterminate warning minor major critical all) Possible values: - indeterminate : alarm severity is indeterminate - warning : alarm severity is warning - minor : alarm severity is minor - major : alarm severity is major - critical : alarm severity is critical - all : all alarm severity	severity level of an alarm for reporting
servaff	Parameter type: <Alarm::queryServAffect> Format: (service-affecting	serviceaffecting no

Resource Identifier	Type	Description
	noservice-affecting all) Possible values: - service-affecting : query alarm service affecting - noservice-affecting : query alarm not service affecting - all : query service affecting and not affecting alarms	
port	Parameter type: <Gpon::IpHostCommonIndex> Format: (ont : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Gpon::IpHostId> vlanport : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / vuni : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlanport : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / vuni : <Eqpt::UnstackedVlan> ont:ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / <Ng2::IpHostId> vlanport:ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / vuni : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlanport:ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / vuni : <Eqpt::UnstackedVlan>) Possible values: - ont:ng2 : ngpon2 ont - vlanport:ng2 : ngpon2 vlanport - ont : ont - vlanport : vlanport Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Eqpt::OntId> - the ONT identifier Field type <Eqpt::ChannelGroupId> - the channel group identifier Field type <Eqpt::SubChannelGroupId> - the subchannel group identifier Field type <Eqpt::Ng2OntId> - the NG2 ONT identifier Possible values: - vuni : virtual uni identifier Possible values: - vuni : virtual NGPON2 uni identifier Field type <Gpon::IpHostId> - iphost id Field type <Ng2::IpHostId> - iphost id (ngpon2) Possible values: - stacked : stacked vlan identity Field type <Eqpt::UnstackedVlan>	gpon iphost port

101 query current alarms by filters

Resource Identifier	Type	Description
	- unstacked vlan id Field type <Eqpt::SVlan> - service vlan id Field type <Eqpt::CVlan> - customer vlan id	

Command Output

Table 101.114-2 "show current alarm by filters" Display parameters

Specific Information		
name	Type	Description
aidinfo	Parameter type: <Alarm::AddInfoString> - additional alarm information	alarm AID parameters <i>This element is only shown in detail mode.</i>
type	Parameter type: <Alarm::alarmIHUBType> (equipment eqpt-holder plug-in-unit atm custom e1 ima-group ima-link redundancy shdsl ether-itf traffic-overflow qos-queue temporal spatial (software-mngt sw-mgmt) xdsl xdsl-ext xdsl-tca olt-gen eo-conv authentication bonding sfp shdsl-isam custom-ext-alarm plug-in-unit-ext sip-user-agent sip-plugin-unit sip-termination e1-sip-termination filetransfer external-device l2forward ether-tca ether-sfp megaco-media-gw megaco-sig-gw megaco-plug-unit megaco-term megaco-sig-lt)	type of the alarms that are active <i>This element is only shown in detail mode.</i>

name	Type	Description
	eqpt-supplemental	
	eqpt-holder-ext	
	lsmredundancy	
	sync	
	mcsrc	
	vlanport	
	vect-line	
	vect-board	
	otdr	
	sip-dial-plan	
	sip-vsp	
	sip-server	
	bgp	
	rip	
	lag	
	ihub-general	
	vprn	
	isis	
	ospf	
	ihub-l2forward	
	vpls	
	ihub-equip	
	ihub-link	
	eont-phyoam	
	ellid	
	epon	
	eont-services-lan	
	eolt-ont-tca	
	eont-sw-dl	
	ldp	
	mpls	
	sdp	
	epipe	
	ihub-ipv6	
	pim	
	li	
	mgmt-sec-access	
	bfd	
	ai	
	tr069serv	
	ontsnmp	
	bulk-sync	
	protection-group	
	ont	
	sfu-sup	
	soho-sup	
	mdu-sup	
	ont-ani	
	sfu-sup2	
	soho-sup2	
	mdu-sup2	
	sfprssi	
	eoltrssi	
	cfm	
	sfpe1t1-framer	
	sfpe1t1-clock	
	pppcc-engine-tca	

101 query current alarms by filters

name	Type	Description
	eth-cfm	
	rsvp	
	ihub-tca	
	eth-ring	
	efm-oam	
	ont-loopdetect	
	ont-video	
	ont-ces	
	ont-voip	
	ont-video-ani	
	ont-pwe	
	ont-cese1	
	ont-xdsl	
	ont-xdsl-tca	
	ont-hpna	
	ont-sip-agent-cfg	
	ont-voip-cfg	
	ont-mgc	
	ont-ploam	
	ont-gen	
	ont-card	
	ont-pots	
	ont-lan	
	ont-moca	
	ont-tc-tca	
	ont-moca-tca	
	ont-l2uni-eth-tca	
	olt-pon-tc-tca	
	olt-pon-util-tca	
	olt-chpr-util-tca	
	olt-ont-tc-tca	
	ont-tca	
	ont-pots-supplemental	
	sfu-ploam	
	sfu-gen	
	soho-ploam	
	soho-gen	
	mdu-ploam	
	mdu-gen	
	ont-veip	
	ont-iphost	
	alarm-table	
	auto-switch	
	channel-pair	
	ont-cfg-dld	
	olt-chpair-tc-tca	
	hgu-tr069	
	eqpt-psu	
	ont-protection	
	secondary-megaco-term	
	secondary-sip-term	
	cas-r2-channel	
	lldpmed	
	pseudo-wire	
	link-agg	
	fcs-exceed	
	e1t1-interface)	

name	Type	Description
	Possible values: - equipment : equipment alarms - eqpt-holder : equipment holder alarms - plug-in-unit : plugin unit alarms - atm : ATM alarms - custom : customizable alarms - e1 : e1 alarms - ima-group : ima-group alarms - ima-link : ima-link alarms - redundancy : redundancy alarms - shdsl : shdsl alarms - ether-itf : ethernet interface alarms - traffic-overflow : Traffic overflow alarms - qos-queue : qos queue alarms - temporal : temporal alarms - spatial : spatial alarms - software-mngt : software management alarms - sw-mgmt : software management alarms - xdsl : xDSL alarms - xdsl-ext : other xDSL alarms - xdsl-tca : xDSL threshold cross alarms - olt-gen : OLT general alarms - eo-conv : E/O conversion related alarms - authentication : authentication related alarms - bonding : bonding-group related alarms - sfp : SFP related alarms - shdsl-isam : shdsl isam alarms - custom-ext-alarm : customizable external alarms - plug-in-unit-ext : other plugin unit alarms - sip-user-agent : sip user agent related alarms - sip-plugin-unit : sip plug in unit related alarms - sip-termination : sip termination related alarms - e1-sip-termination : E1 sip termination related alarms - filetransfer : file transfer server alarms - external-device : external device related alarms - l2forward : l2forward related alarms - ether-tca : ethernet threshold cross alarms - ether-sfp : ethernet SFP related alarms - megaco-media-gw : megaco media gateway related alarms - megaco-sig-gw : megaco signaling gateway related alarms - megaco-plug-unit : megaco plug unit related alarms - megaco-term : megaco termination related alarms - megaco-sig-lt : megaco signaling lt related alarms - eqpt-supplemental : equipment supplemental alarms - eqpt-holder-ext : other equipment holder alarms - lsmredundancy : lsm redundancy alarms - sync : synce and bits alarms - mcsrc : multicast source alarms - vlanport : vlanport alarms - vect-line : xDSL vectoring line alarms - vect-board : xDSL vectoring board alarms - otdr : otdr alarms - sip-dial-plan : sip dial plan related alarms - sip-vsp : sip vsp related alarms - sip-server : sip server related alarms - bgp : bgp related alarms - rip : rip related alarms	

101 query current alarms by filters

name	Type	Description
	- lag : LAG related alarms - ihub-general : IHUB general related alarms - vprn : vprn related alarms - isis : isis related alarms - ospf : ospf related alarms - ihub-l2forward : ihub-l2forward alarms - vpls : vpls related alarms - ihub-equip : ihub-equip related alarms - ihub-link : ihub-link related alarms - eont-phyoam : eont phyoam related alarms - ellid : ellid related alarms - epon : epon related alarms - eont-services-lan : eon phyoam related alarms - eolt-ont-tca : eon phyoam related alarms - eont-sw-dl : eon phyoam related alarms - ldp : ldp related alarms - mpls : mpls related alarms - sdp : sdp related alarms - epipe : epipe related alarms - ihub-ipv6 : ihub-ipv6 related alarms - pim : pim related alarms - li : lawful intercept related alarms - mgmt-sec-access : management security related alarms - bfd : bfd related alarms - ai : Application Intelligence related alarms - tr069serv : tr069 server related alarms - ontsnmp : ont snmp related alarms - bulk-sync : bulk-sync related alarms - protection-group : port protection group related alarms - ont : ONT general supplemental related alarms - sfu-sup : SFU ONT general supplemental related alarms - soho-sup : SOHO ONT general supplemental related alarms - mdu-sup : MDU ONT general supplemental related alarms - ont-ani : ONT general supplemental 2 related alarms - sfu-sup2 : SFU ONT general supplemental 2 related alarms - soho-sup2 : SOHO ONT general supplemental 2 related alarms - mdu-sup2 : MDU ONT general supplemental 2 related alarms - sfrssi : SFP RSSI related alarms - eoltrssi : epon olt Sfp RSSI related alarms - cfm : Cfm related alarms - sfpe1t1-framer : SFP 2e1t1 framer alarms - sfpe1t1-clock : SFP 2e1t1 clock alarms - pppcc-engine-tca : PPPOE Cross Connect Engine TCA related alarm - eth-cfm : eth-cfm related alarms - rsvp : rsvp related alarms - ihub-tca : IHUB TCA related alarms - eth-ring : eth-ring related alarms - efm-oam : EFM-OAM related alarms - ont-loopdetect : ont loop detect related alarms - ont-video : ont services video related alarms - ont-ces : ont services ces related alarms - ont-voip : ont services voip related alarms - ont-video-ani : ont services video ani related alarms	

name	Type	Description
	- ont-pwe : ont services pwe related alarms - ont-cese1 : ont services cese1 related alarms - ont-xdsl : ont services xdsl related alarms - ont-xdsl-tca : ont services xdsl tca related alarms - ont-hpna : ont hpna related alarms - ont-sip-agent-cfg : ont services voip sip agent config related alarms - ont-voip-cfg : ont services voip config related alarms - ont-mgc : ont mgc related alarms - ont-ploam : ONT PLOAM related alarms - ont-gen : ONT GENERAL related alarms - ont-card : ONT Subscriber Card related alarms - ont-pots : ONT Services POTS related alarms - ont-lan : ONT Services LAN related alarms - ont-moca : ONT MoCA related alarms - ont-tc-tca : ONT TC TCA related alarms - ont-moca-tca : ONT MoCA TCA related alarms - ont-l2uni-eth-tca : ONT L2 UNI Ethernet TCA related alarms - olt-pon-tc-tca : OLT PON TC TCA related alarms - olt-pon-util-tca : OLT PON utilization TCA related alarms - olt-chpr-util-tca : OLT channel-pair utilization TCA related alarms - olt-ont-tc-tca : OLT ONT TC TCA related alarms - ont-tca : ONT TCA related alarms - ont-pots-supplemental : ONT POTS Supplemental related alarms - sfu-ploam : SFU ONT PLOAM related alarms - sfu-gen : SFU ONT general related alarms - soho-ploam : SOHO ONT PLOAM related alarms - soho-gen : SOHO ONT general related alarms - mdu-ploam : MDU ONT PLOAM related alarms - mdu-gen : MDU ONT general related alarms - ont-veip : ONT VEIP related alarms - ont-iphost : ONT IP HOST related alarms - alarm-table : alarm table related alarms - auto-switch : auto-switch related alarms - channel-pair : channel pair related alarms - ont-cfg-dld : ont configure file download related alarms - olt-chpair-tc-tca : OLT CHANNELPAIR TC TCA related alarms - hgu-tr069 : hgu tr069 related alarms - eqpt-psu : equipment psu alarms - ont-protection : ONT protection related alarms - secondary-megaco-term : secondary megaco termination related alarms - secondary-sip-term : secondary sip termination related alarms - cas-r2-channel : CAS R2 channel related alarms - lldpmed : lldpmed alarms - pseudo-wire : pseudo Wire related alarms - link-agg : Link aggregation related alarms - fcs-exceed : FCS auto-recovery related alarms - e1t1-interface : E1/T1 physical interfaces related alarms	
name	Parameter type: <Alarm::alarmtypeOntiphostihub> (ont-ip-host-mismatch ont-ip-host-file	alarm name that are active <i>This element is only shown in detail mode.</i>

101 query current alarms by filters

name	Type	Description
	ont-ip-host-ip-alloc all) Possible values: - ont-ip-host-mismatch : ont ip host mismatch - ont-ip-host-file : ont ip host file unavailable - ont-ip-host-ip-alloc : ont ip host IP allocation failure - all : ONT IP HOST related alarms	
severity	Parameter type: <Alarm::AlarmSeverity> (indeterminate warning minor major critical) Possible values: - indeterminate : alarm severity is indeterminate - warning : alarm severity is warning - minor : alarm severity is minor - major : alarm severity is major - critical : alarm severity is critical	the alarms severity level <i>This element is only shown in detail mode.</i>
servaff	Parameter type: <Alarm::alarmServAffect> ((service-affecting yes) (noservice-affecting no)) Possible values: - service-affecting : make this alarm service affecting - yes : make this alarm service affecting - noservice-affecting : make this alarm not service affecting - no : make this alarm not service affecting	alarms affect service or not <i>This element is only shown in detail mode.</i>
time	Parameter type: <Sys::timeInSecs> - the time (yyyy-mm-dd:hour:minutes:secs) - unit: UTC	time in seconds when alarm was updated <i>This element is only shown in detail mode.</i>
descript	Parameter type: <Alarm::AddInfoString> - additional alarm information	alarm description <i>This element is only shown in detail mode.</i>

101.115 show current alarm by filters

Command Description

show current alarms by filters

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm query otdr [ (name) [ severity <Alarm::querySeverity> ] [ servaff <Alarm::queryServAffect> ] [ ponindex <Itf::ComplexPortType> ] ]
```

Command Parameters

Table 101.115-1 "show current alarm by filters" Resource Parameters

Resource Identifier	Type	Description
(name)	Format: (otdr-cap-mismatch all) Possible values: - otdr-cap-mismatch : otdr capability mismatch - all : otdr alarms	alarm name of otdr
severity	Parameter type: <Alarm::querySeverity> Format: (indeterminate warning minor major critical all) Possible values: - indeterminate : alarm severity is indeterminate - warning : alarm severity is warning - minor : alarm severity is minor - major : alarm severity is major - critical : alarm severity is critical - all : all alarm severity	severity level of an alarm for reporting
servaff	Parameter type: <Alarm::queryServAffect> Format: (service-affecting noservice-affecting all) Possible values: - service-affecting : query alarm service affecting	serviceaffecting no

101 query current alarms by filters

Resource Identifier	Type	Description
	- noservice-affecting : query alarm not service affecting - all : query service affecting and not affecting alarms	
ponindex	Parameter type: <If::ComplexPortType> Format: (xdsl-line : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> voicefxs : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> xdsl-channel : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> atm-if : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> atm-pvc : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::VpiId> : <Eqpt::VciId> bridge-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::VpiId> : <Eqpt::VciId> vlan-port:ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / <Eqpt::Ng2OntSlotId> / <Eqpt::Ng2OntPortId> : <Eqpt::UnstackedVlan> l2-vlan : <Eqpt::VlanId> ip : <Eqpt::LogicalId> sw-loopback slip uni:ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / <Eqpt::Ng2OntSlotId> / <Eqpt::Ng2OntPortId> vlan-port:ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / <Eqpt::Ng2OntSlotId> / <Eqpt::Ng2OntPortId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> atm-bonding : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> bonding : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> ip-gateway : <Eqpt::VrId> ip-line : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::VpiId> : <Eqpt::VciId> ip-line : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> shdsl-line : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> e1-line : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> atm-ima : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> ethernet-line : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> bridge-port:ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / vuni vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::VpiId> : <Eqpt::VciId> : <Eqpt::UnstackedVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::UnstackedVlan>	identifies the spf where the alarm has occurred

Resource Identifier	Type	Description
	vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::VpiId> : <Eqpt::VciId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> voip-ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> ip-line : vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::VpiId> : <Eqpt::VciId> : <Eqpt::UnstackedVlan> ip-line : vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::UnstackedVlan> ip-line : vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::VpiId> : <Eqpt::VciId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> ip-line : vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan-port-ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / vuni : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan-port-ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / vuni : <Eqpt::UnstackedVlan> chgroup : <Eqpt::ChannelGroupId> subchgroup : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> bridge-port-ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / <Eqpt::Ng2OntSlotId> / <Eqpt::Ng2OntPortId> atm-pvc : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> bridge-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> bridge-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> / <Eqpt::OntPortId> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> / <Eqpt::OntPortId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> / <Eqpt::OntPortId> : <Eqpt::UnstackedVlan> pon : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> ont : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> uni : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> / <Eqpt::OntPortId> bridge-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / voip bridge-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / vuni	

Resource Identifier	Type	Description
	vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / voip : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / vuni : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / voip : <Eqpt::UnstackedVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / vuni : <Eqpt::UnstackedVlan> voip : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> la-group : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::LLId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> bridge-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::LLId> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::LLId> : <Eqpt::UnstackedVlan> mpm : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::ComboPonId> x-pon : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::XPonId> 25g-pon : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::M25GPonId> dist-router-interface : slot-stacked : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::SVlan> : <Eqpt::CVlan> dist-router-interface : slot-vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::UnstackedVlan> bundle : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::BundleId> chpair : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::ChannelPairId> ont:ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId>) Possible values: - xdsl-line : a static xdsl line interface - xdsl-channel : a static xdsl channel interface - atm-if : a static atm interface - atm-pvc : an atm pvc interface - bridge-port : a vlan bridge-port - bridge-port:ng2 : a ngpon2 vlan bridge-port - l2-vlan : a l2-vlan interface - ip : an ip interface - sw-loopback : a software loopback interface - slip : a slip interface - atm-bonding : atm bonding obsolete alternative replaced by bonding - bonding : bonding - ip-gateway : ip user gateway interface	

Resource Identifier	Type	Description
	- ip-line : ip line interface - shdsl-line : a static shdsl line interface - e1-line : a e1 line interface - atm-ima : atm ima - ethernet-line : an ethernet line interface - vlan-port : vlan port - vlan-port:ng2 : a ngpon2 vlan port - pon : pon - x-pon : xgs pon - 25g-pon : 25g pon - chpair : channelpair - chgroup : channelgroup - subchgroup : subchannelgroup - bundle : bundle - ont : ont - ont:ng2 : ngpon2 ONT style identification - uni : uni - uni:ng2 : ngpon2 UNI style identification - voip : voip - voip:ng2 : voip - la-group : link aggregation group - dist-router-interface : dist router interface - voicefxs : voicefxs - mpm : multi-pon module Possible values: - vlan : vlan port Possible values: - slot-vlan : slot unstacked - slot-stacked : slot vlan port Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number Field type <Eqpt::VpiId> - atm VPI Field type <Eqpt::VciId> - atm VCI Field type <Eqpt::PonId> - the PON identifier Field type <Eqpt::XPonId> - the XGS PON identifier Field type <Eqpt::M25GPonId> - the 25G PON identifier Field type <Eqpt::ComboPonId> - the comboPON identifier Field type <Eqpt::ChannelPairId> - the channel pair identifier Field type <Eqpt::ChannelGroupId> - the channel group identifier Field type <Eqpt::SubChannelGroupId> - the subchannel group identifier Field type <Eqpt::BundleId> - the BUNDLE identifier	

101 query current alarms by filters

Resource Identifier	Type	Description
	Field type <Eqpt::OntId> - the ONT identifier Field type <Eqpt::Ng2OntId> - the NG2 ONT identifier Possible values: - voip : virtual uni identifier obsolete alternative replaced by vuni - vuni : virtual uni identifier Possible values: - vuni : virtual NGPON2 uni identifier Field type <Eqpt::OntSlotId> - the ONT SLOT identifier Field type <Eqpt::OntPortId> - the ONT PORT identifier Field type <Eqpt::Ng2OntSlotId> - the NGPON2 ONT SLOT identifier Field type <Eqpt::Ng2OntPortId> - the NGPON2 ONT PORT identifier Field type <Eqpt::LLId> - the LLID identifier,range 1 for EPON,range 1-8 for DPOE Possible values: - stacked : stacked vlan identity Field type <Eqpt::UnstackedVlan> - unstacked vlan id Field type <Eqpt::SVlan> - service vlan id Field type <Eqpt::CVlan> - customer vlan id Field type <Eqpt::VlanId> - VLAN id Field type <Eqpt::LogicalId> - logical id Field type <Eqpt::VrflId> - VRF id	

Command Output

Table 101.115-2 "show current alarm by filters" Display parameters

Specific Information		
name	Type	Description
aidinfo	Parameter type: <Alarm::AddInfoString> - additional alarm information	alarm AID parameters <i>This element is only shown in detail mode.</i>
type	Parameter type: <Alarm::alarmIHUBType> (equipment eqpt-holder plug-in-unit atm custom e1 ima-group ima-link redundancy shdsl ether-itf traffic-overflow	type of the alarms that are active <i>This element is only shown in detail mode.</i>

name	Type	Description
	qos-queue temporal spatial (software-mngt sw-mgmt) xdsl xdsl-ext xdsl-tca olt-gen eo-conv authentication bonding sfp shdsl-isam custom-ext-alarm plug-in-unit-ext sip-user-agent sip-plugin-unit sip-termination e1-sip-termination filetransfer external-device l2forward ether-tca ether-sfp megaco-media-gw megaco-sig-gw megaco-plug-unit megaco-term megaco-sig-lt eqpt-supplemental eqpt-holder-ext lsmredundancy sync mcsrc vlanport vect-line vect-board otdr sip-dial-plan sip-vsp sip-server bgp rip lag ihub-general vprn isis ospf ihub-l2forward vpls ihub-equip ihub-link eont-phyoam ellid epon eont-services-lan eolt-ont-tca	

101 query current alarms by filters

name	Type	Description
	eont-sw-dl ldp mpls sdp epipe ihub-ipv6 pim li mgmt-sec-access bfd ai tr069serv ontsnmp bulk-sync protection-group ont sfu-sup soho-sup mdu-sup ont-ani sfu-sup2 soho-sup2 mdu-sup2 sfprssi eoltrssi cfm sfpe1t1-framer sfpe1t1-clock pppcc-engine-tca eth-cfm rsvp ihub-tca eth-ring efm-oam ont-loopdetect ont-video ont-ces ont-voip ont-video-ani ont-pwe ont-cese1 ont-xdsl ont-xdsl-tca ont-hpna ont-sip-agent-cfg ont-voip-cfg ont-mgc ont-ploam ont-gen ont-card ont-pots ont-lan ont-moca ont-tc-tca ont-moca-tca ont-l2uni-eth-tca olt-pon-tc-tca	

name	Type	Description
	olt-pon-util-tca olt-chpr-util-tca olt-ont-tc-tca ont-tca ont-pots-supplemental sfu-ploam sfu-gen soho-ploam soho-gen mdu-ploam mdu-gen ont-veip ont-iphost alarm-table auto-switch channel-pair ont-cfg-dld olt-chpair-tc-tca hgu-tr069 eqpt-psu ont-protection secondary-megaco-term secondary-sip-term cas-r2-channel lldpmed pseudo-wire link-agg fcs-exceed e1t1-interface) Possible values: - equipment : equipment alarms - eqpt-holder : equipment holder alarms - plug-in-unit : plugin unit alarms - atm : ATM alarms - custom : customizable alarms - e1 : e1 alarms - ima-group : ima-group alarms - ima-link : ima-link alarms - redundancy : redundancy alarms - shdsl : shdsl alarms - ether-itf : ethernet interface alarms - traffic-overflow : Traffic overflow alarms - qos-queue : qos queue alarms - temporal : temporal alarms - spatial : spatial alarms - software-mngt : software management alarms - sw-mgmt : software management alarms - xdsl : xDSL alarms - xdsl-ext : other xDSL alarms - xdsl-tca : xDSL threshold cross alarms - olt-gen : OLT general alarms - eo-conv : E/O conversion related alarms - authentication : authentication related alarms - bonding : bonding-group related alarms - sfp : SFP related alarms - shdsl-isam : shdsl isam alarms - custom-ext-alarm : customizable external alarms	

101 query current alarms by filters

name	Type	Description
	- plug-in-unit-ext : other plugin unit alarms - sip-user-agent : sip user agent related alarms - sip-plugin-unit : sip plug in unit related alarms - sip-termination : sip termination related alarms - e1-sip-termination : E1 sip termination related alarms - filetransfer : file transfer server alarms - external-device : external device related alarms - l2forward : l2forward related alarms - ether-tca : ethernet threshold cross alarms - ether-sfp : ethernet SFP related alarms - megaco-media-gw : megaco media gateway related alarms - megaco-sig-gw : megaco signaling gateway related alarms - megaco-plug-unit : megaco plug unit related alarms - megaco-term : megaco termination related alarms - megaco-sig-lt : megaco signaling lt related alarms - eqpt-supplemental : equipment supplemental alarms - eqpt-holder-ext : other equipment holder alarms - lsmredundancy : lsm redundancy alarms - sync : synce and bits alarms - mcsrc : multicast source alarms - vlanport : vlanport alarms - vect-line : xDSL vectoring line alarms - vect-board : xDSL vectoring board alarms - otdr : otdr alarms - sip-dial-plan : sip dial plan related alarms - sip-vsp : sip vsp related alarms - sip-server : sip server related alarms - bgp : bgp related alarms - rip : rip related alarms - lag : LAG related alarms - ihub-general : IHUB general related alarms - vprn : vprn related alarms - isis : isis related alarms - ospf : ospf related alarms - ihub-l2forward : ihub-l2forward alarms - vpls : vpls related alarms - ihub-equip : ihub-equip related alarms - ihub-link : ihub-link related alarms - eont-phyoam : eont phyoam related alarms - ellid : ellid related alarms - epon : epon related alarms - eont-services-lan : eon phyoam related alarms - eolt-ont-tca : eon phyoam related alarms - eont-sw-dl : eon phyoam related alarms - ldp : ldp related alarms - mpls : mpls related alarms - sdp : sdp related alarms - epipe : epipe related alarms - ihub-ipv6 : ihub-ipv6 related alarms - pim : pim related alarms - li : lawful intercept related alarms - mgmt-sec-access : management security related alarms - bfd : bfd related alarms - ai : Application Intelligence related alarms - tr069serv : tr069 server related alarms - ontsnmp : ont snmp related alarms - bulk-sync : bulk-sync related alarms	

name	Type	Description
	- protection-group : port protection group related alarms - ont : ONT general supplemental related alarms - sfu-sup : SFU ONT general supplemental related alarms - soho-sup : SOHO ONT general supplemental related alarms - mdu-sup : MDU ONT general supplemental related alarms - ont-ani : ONT general supplemental 2 related alarms - sfu-sup2 : SFU ONT general supplemental 2 related alarms - soho-sup2 : SOHO ONT general supplemental 2 related alarms - mdu-sup2 : MDU ONT general supplemental 2 related alarms - sfprssi : SFP RSSI related alarms - eoltrssi : epon olt Sfp RSSI related alarms - cfm : Cfm related alarms - sfpe1t1-framer : SFP 2e1t1 framer alarms - sfpe1t1-clock : SFP 2e1t1 clock alarms - pppcc-engine-tca : PPPOE Cross Connect Engine TCA related alarm - eth-cfm : eth-cfm related alarms - rsvp : rsvp related alarms - ihub-tca : IHUB TCA related alarms - eth-ring : eth-ring related alarms - efm-oam : EFM-OAM related alarms - ont-loopdetect : ont loop detect related alarms - ont-video : ont services video related alarms - ont-ces : ont services ces related alarms - ont-voip : ont services voip related alarms - ont-video-ani : ont services video ani related alarms - ont-pwe : ont services pwe related alarms - ont-cese1 : ont services cese1 related alarms - ont-xdsl : ont services xdsl related alarms - ont-xdsl-tca : ont services xdsl tca related alarms - ont-hpna : ont hpna related alarms - ont-sip-agent-cfg : ont services voip sip agent config related alarms - ont-voip-cfg : ont services voip config related alarms - ont-mgc : ont mgc related alarms - ont-ploam : ONT PLOAM related alarms - ont-gen : ONT GENERAL related alarms - ont-card : ONT Subscriber Card related alarms - ont-pots : ONT Services POTS related alarms - ont-lan : ONT Services LAN related alarms - ont-moca : ONT MoCA related alarms - ont-tc-tca : ONT TC TCA related alarms - ont-moca-tca : ONT MoCA TCA related alarms - ont-l2uni-eth-tca : ONT L2 UNI Ethernet TCA related alarms - olt-pon-tc-tca : OLT PON TC TCA related alarms - olt-pon-util-tca : OLT PON utilization TCA related alarms - olt-chpr-util-tca : OLT channel-pair utilization TCA related alarms - olt-ont-tc-tca : OLT ONT TC TCA related alarms - ont-tca : ONT TCA related alarms - ont-pots-supplemental : ONT POTS Supplemental related alarms - sfu-ploam : SFU ONT PLOAM related alarms	

101 query current alarms by filters

name	Type	Description
	- sfu-gen : SFU ONT general related alarms - soho-ploam : SOHO ONT PLOAM related alarms - soho-gen : SOHO ONT general related alarms - mdu-ploam : MDU ONT PLOAM related alarms - mdu-gen : MDU ONT general related alarms - ont-veip : ONT VEIP related alarms - ont-iphost : ONT IP HOST related alarms - alarm-table : alarm table related alarms - auto-switch : auto-switch related alarms - channel-pair : channel pair related alarms - ont-cfg-dld : ont configure file download related alarms - olt-chpair-tc-tca : OLT CHANNELPAIR TC TCA related alarms - hgu-tr069 : hgu tr069 related alarms - eqpt-psu : equipment psu alarms - ont-protection : ONT protection related alarms - secondary-megaco-term : secondary megaco termination related alarms - secondary-sip-term : secondary sip termination related alarms - cas-r2-channel : CAS R2 channel related alarms - lldpmed : lldpmed alarms - pseudo-wire : pseudo Wire related alarms - link-agg : Link aggregation related alarms - fcs-exceed : FCS auto-recovery related alarms - e1t1-interface : E1/T1 physical interfaces related alarms	
name	Parameter type: <Alarm::almtypeOtdrihub> (otdr-cap-mismatch all) Possible values: - otdr-cap-mismatch : otdr capability mismatch - all : otdr alarms	alarm name that are active <i>This element is only shown in detail mode.</i>
severity	Parameter type: <Alarm::AlarmSeverity> (indeterminate warning minor major critical) Possible values: - indeterminate : alarm severity is indeterminate - warning : alarm severity is warning - minor : alarm severity is minor - major : alarm severity is major - critical : alarm severity is critical	the alarms severity level <i>This element is only shown in detail mode.</i>
servaff	Parameter type: <Alarm::alarmServAffect> ((service-affecting yes) (noservice-affecting no)) Possible values: - service-affecting : make this alarm service affecting - yes : make this alarm service affecting - noservice-affecting : make this alarm not service affecting - no : make this alarm not service affecting	alarms affect service or not <i>This element is only shown in detail mode.</i>
time	Parameter type: <Sys::timeInSecs> - the time (yyyy-mm-dd:hour:minutes:secs) - unit: UTC	time in seconds when alarm was updated <i>This element is only shown in detail mode.</i>
descript	Parameter type: <Alarm::AddInfoString>	alarm description

101 query current alarms by filters

name	Type	Description
	- additional alarm information	<i>This element is only shown in detail mode.</i>

101.116 show current alarm by filters

Command Description

show current alarms by filters

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm query mgmt-sec-access [ (name) [ severity <Alarm::querySeverity> ] [ servaff  
<Alarm::queryServAffect> ] [ ip-address <Alarm::IpAddress> ] ]
```

Command Parameters

Table 101.116-1 "show current alarm by filters" Resource Parameters

Resource Identifier	Type	Description
(name)	Format: (login-successful login-failure all) Possible values: - login-successful : successful login via management access - login-failure : invalid login via management access has crossed the threshold - all : management security related alarms	alarm name of mgmt-sec-access
severity	Parameter type: <Alarm::querySeverity> Format: (indeterminate warning minor major critical all) Possible values: - indeterminate : alarm severity is indeterminate - warning : alarm severity is warning - minor : alarm severity is minor - major : alarm severity is major - critical : alarm severity is critical - all : all alarm severity	severity level of an alarm for reporting
servaff	Parameter type: <Alarm::queryServAffect> Format: (service-affecting noservice-affecting	serviceaffecting no

Resource Identifier	Type	Description
	all) Possible values: - service-affecting : query alarm service affecting - noservice-affecting : query alarm not service affecting - all : query service affecting and not affecting alarms	
ip-address	Parameter type: <Alarm::IpAddress> Format: - IPv4-address	address of the operator

Command Output

Table 101.116-2 "show current alarm by filters" Display parameters

Specific Information		
name	Type	Description
aidinfo	Parameter type: <Alarm::AddInfoString> - additional alarm information	alarm AID parameters <i>This element is only shown in detail mode.</i>
type	Parameter type: <Alarm::alarmIHUBType> (equipment eqpt-holder plug-in-unit atm custom e1 ima-group ima-link redundancy shdsl ether-itf traffic-overflow qos-queue temporal spatial (software-mngt sw-mgmt) xdsl xdsl-ext xdsl-tca olt-gen eo-conv authentication bonding sfp shdsl-isam custom-ext-alarm plug-in-unit-ext sip-user-agent sip-plugin-unit sip-termination e1-sip-termination filetransfer external-device l2forward ether-tca ether-sfp megaco-media-gw megaco-sig-gw	type of the alarms that are active <i>This element is only shown in detail mode.</i>

101 query current alarms by filters

name	Type	Description
	megaco-plug-unit megaco-term megaco-sig-lt eqpt-supplemental eqpt-holder-ext lsmredundancy sync mcsrc vlanport vect-line vect-board otdr sip-dial-plan sip-vsp sip-server bgp rip lag ihub-general vprn isis ospf ihub-l2forward vpls ihub-equip ihub-link eont-phyoam ellid epon eont-services-lan eolt-ont-tca eont-sw-dl ldp mpls sdp epipe ihub-ipv6 pim li mgmt-sec-access bfd ai tr069serv ontsnmp bulk-sync protection-group ont sfu-sup soho-sup mdu-sup ont-ani sfu-sup2 soho-sup2 mdu-sup2 sfprssi eoltrssi cfm	

name	Type	Description
	sfpe1t1-framer sfpe1t1-clock pppcc-engine-tca eth-cfm rsvp ihub-tca eth-ring efm-oam ont-loopdetect ont-video ont-ces ont-voip ont-video-ani ont-pwe ont-cese1 ont-xdsl ont-xdsl-tca ont-hpna ont-sip-agent-cfg ont-voip-cfg ont-mgc ont-ploam ont-gen ont-card ont-pots ont-lan ont-moca ont-tc-tca ont-moca-tca ont-l2uni-eth-tca olt-pon-tc-tca olt-pon-util-tca olt-chpr-util-tca olt-ont-tc-tca ont-tca ont-pots-supplemental sfu-ploam sfu-gen soho-ploam soho-gen mdu-ploam mdu-gen ont-veip ont-iphost alarm-table auto-switch channel-pair ont-cfg-dld olt-chpair-tc-tca hgu-tr069 eqpt-psu ont-protection secondary-megaco-term secondary-sip-term cas-r2-channel lldpmed pseudo-wire	

101 query current alarms by filters

name	Type	Description
	link-agg fcs-exceed e1t1-interface) Possible values: - equipment : equipment alarms - eqpt-holder : equipment holder alarms - plug-in-unit : plugin unit alarms - atm : ATM alarms - custom : customizable alarms - e1 : e1 alarms - ima-group : ima-group alarms - ima-link : ima-link alarms - redundancy : redundancy alarms - shdsl : shdsl alarms - ether-itf : ethernet interface alarms - traffic-overflow : Traffic overflow alarms - qos-queue : qos queue alarms - temporal : temporal alarms - spatial : spatial alarms - software-mngt : software management alarms - sw-mgmt : software management alarms - xdsl : xDSL alarms - xdsl-ext : other xDSL alarms - xdsl-tca : xDSL threshold cross alarms - olt-gen : OLT general alarms - eo-conv : E/O conversion related alarms - authentication : authentication related alarms - bonding : bonding-group related alarms - sfp : SFP related alarms - shdsl-isam : shdsl isam alarms - custom-ext-alarm : customizable external alarms - plug-in-unit-ext : other plugin unit alarms - sip-user-agent : sip user agent related alarms - sip-plugin-unit : sip plug in unit related alarms - sip-termination : sip termination related alarms - e1-sip-termination : E1 sip termination related alarms - filetransfer : file transfer server alarms - external-device : external device related alarms - l2forward : l2forward related alarms - ether-tca : ethernet threshold cross alarms - ether-sfp : ethernet SFP related alarms - megaco-media-gw : megaco media gateway related alarms - megaco-sig-gw : megaco signaling gateway related alarms - megaco-plug-unit : megaco plug unit related alarms - megaco-term : megaco termination related alarms - megaco-sig-lt : megaco signaling lt related alarms - eqpt-supplemental : equipment supplemental alarms - eqpt-holder-ext : other equipment holder alarms - lsmredundancy : lsm redundancy alarms - sync : synce and bits alarms - mcsrc : multicast source alarms - vlanport : vlanport alarms - vect-line : xDSL vectoring line alarms - vect-board : xDSL vectoring board alarms - otdr : otdr alarms - sip-dial-plan : sip dial plan related alarms - sip-vsp : sip vsp related alarms	

name	Type	Description
	- sip-server : sip server related alarms - bgp : bgp related alarms - rip : rip related alarms - lag : LAG related alarms - ihub-general : IHUB general related alarms - vprn : vprn related alarms - isis : isis related alarms - ospf : ospf related alarms - ihub-l2forward : ihub-l2forward alarms - vpls : vpls related alarms - ihub-equip : ihub-equip related alarms - ihub-link : ihub-link related alarms - eont-phyoam : eont phyoam related alarms - ellid : ellid related alarms - epon : epon related alarms - eont-services-lan : eon phyoam related alarms - eolt-ont-tca : eon phyoam related alarms - eont-sw-dl : eon phyoam related alarms - ldp : ldp related alarms - mpls : mpls related alarms - sdp : sdp related alarms - epipe : epipe related alarms - ihub-ipv6 : ihub-ipv6 related alarms - pim : pim related alarms - li : lawful intercept related alarms - mgmt-sec-access : management security related alarms - bfd : bfd related alarms - ai : Application Intelligence related alarms - tr069serv : tr069 server related alarms - ontsnmp : ont snmp related alarms - bulk-sync : bulk-sync related alarms - protection-group : port protection group related alarms - ont : ONT general supplemental related alarms - sfu-sup : SFU ONT general supplemental related alarms - soho-sup : SOHO ONT general supplemental related alarms - mdu-sup : MDU ONT general supplemental related alarms - ont-ani : ONT general supplemental 2 related alarms - sfu-sup2 : SFU ONT general supplemental 2 related alarms - soho-sup2 : SOHO ONT general supplemental 2 related alarms - mdu-sup2 : MDU ONT general supplemental 2 related alarms - sfprssi : SFP RSSI related alarms - eoltrssi : epon olt Sfp RSSI related alarms - cfm : Cfm related alarms - sfpe1t1-framer : SFP 2e1t1 framer alarms - sfpe1t1-clock : SFP 2e1t1 clock alarms - pppcc-engine-tca : PPPOE Cross Connect Engine TCA related alarm - eth-cfm : eth-cfm related alarms - rsvp : rsvp related alarms - ihub-tca : IHUB TCA related alarms - eth-ring : eth-ring related alarms - efm-oam : EFM-OAM related alarms - ont-loopdetect : ont loop detect related alarms - ont-video : ont services video related alarms	

101 query current alarms by filters

name	Type	Description
	- ont-ces : ont services ces related alarms - ont-voip : ont services voip related alarms - ont-video-ani : ont services video ani related alarms - ont-pwe : ont services pwe related alarms - ont-cese1 : ont services cese1 related alarms - ont-xdsl : ont services xdsl related alarms - ont-xdsl-tca : ont services xdsl tca related alarms - ont-hpna : ont hpna related alarms - ont-sip-agent-cfg : ont services voip sip agent config related alarms - ont-voip-cfg : ont services voip config related alarms - ont-mgc : ont mgc related alarms - ont-ploam : ONT PLOAM related alarms - ont-gen : ONT GENERAL related alarms - ont-card : ONT Subscriber Card related alarms - ont-pots : ONT Services POTS related alarms - ont-lan : ONT Services LAN related alarms - ont-moca : ONT MoCA related alarms - ont-tc-tca : ONT TC TCA related alarms - ont-moca-tca : ONT MoCA TCA related alarms - ont-l2uni-eth-tca : ONT L2 UNI Ethernet TCA related alarms - olt-pon-tc-tca : OLT PON TC TCA related alarms - olt-pon-util-tca : OLT PON utilization TCA related alarms - olt-chpr-util-tca : OLT channel-pair utilization TCA related alarms - olt-ont-tc-tca : OLT ONT TC TCA related alarms - ont-tca : ONT TCA related alarms - ont-pots-supplemental : ONT POTS Supplemental related alarms - sfu-ploam : SFU ONT PLOAM related alarms - sfu-gen : SFU ONT general related alarms - soho-ploam : SOHO ONT PLOAM related alarms - soho-gen : SOHO ONT general related alarms - mdu-ploam : MDU ONT PLOAM related alarms - mdu-gen : MDU ONT general related alarms - ont-veip : ONT VEIP related alarms - ont-iphost : ONT IP HOST related alarms - alarm-table : alarm table related alarms - auto-switch : auto-switch related alarms - channel-pair : channel pair related alarms - ont-cfg-dld : ont configure file download related alarms - olt-chpair-tc-tca : OLT CHANNELPAIR TC TCA related alarms - hgu-tr069 : hgu tr069 related alarms - eqpt-psu : equipment psu alarms - ont-protection : ONT protection related alarms - secondary-megaco-term : secondary megaco termination related alarms - secondary-sip-term : secondary sip termination related alarms - cas-r2-channel : CAS R2 channel related alarms - lldpmed : lldpmed alarms - pseudo-wire : pseudo Wire related alarms - link-agg : Link aggregation related alarms - fcs-exceed : FCS auto-recovery related alarms - e1t1-interface : E1/T1 physical interfaces related alarms	

name	Type	Description
name	Parameter type: <Alarm::alMtypeMgmtsecaccessihub> (login-successful login-failure all) Possible values: - login-successful : successful login via management access - login-failure : invalid login via management access has crossed the threshold - all : management security related alarms	alarm name that are active <i>This element is only shown in detail mode.</i>
severity	Parameter type: <Alarm::AlarmSeverity> (indeterminate warning minor major critical) Possible values: - indeterminate : alarm severity is indeterminate - warning : alarm severity is warning - minor : alarm severity is minor - major : alarm severity is major - critical : alarm severity is critical	the alarms severity level <i>This element is only shown in detail mode.</i>
servaff	Parameter type: <Alarm::alarmServAffect> ((service-affecting yes) (noservice-affecting no)) Possible values: - service-affecting : make this alarm service affecting - yes : make this alarm service affecting - noservice-affecting : make this alarm not service affecting - no : make this alarm not service affecting	alarms affect service or not <i>This element is only shown in detail mode.</i>
time	Parameter type: <Sys::timeInSecs> - the time (yyyy-mm-dd:hour:minutes:secs) - unit: UTC	time in seconds when alarm was updated <i>This element is only shown in detail mode.</i>
descript	Parameter type: <Alarm::AddInfoString> - additional alarm information	alarm description <i>This element is only shown in detail mode.</i>

101.117 show current alarm by filters

Command Description

show current alarms by filters

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm query eoltrssi [ (name) [ severity <Alarm::querySeverity> ] [ servaff <Alarm::queryServAffect> ] [ epon-id <Epon::PonId> ] ]
```

Command Parameters

Table 101.117-1 "show current alarm by filters" Resource Parameters

Resource Identifier	Type	Description
(name)	Format: (eolt-txpwr-hi-alm eolt-txpwr-lw-alm eolt-txbias-hi-alm eolt-txbias-lw-alm eolt-volt-hi-alm eolt-volt-lw-alm eolt-temp-hi-alm eolt-temp-lw-alm eolt-txpwr-hi-warn eolt-txpwr-lw-warn eolt-txbias-hi-warn eolt-txbias-lw-warn eolt-volt-hi-warn eolt-volt-lw-warn eolt-temp-hi-warn eolt-temp-lw-warn eolt-xfp-txpwr-hi-alm eolt-xfp-txpwr-lw-alm eolt-xfp-bias-hi-alm eolt-xfp-bias-lw-alm eolt-xfp-txpwr-hi-warn eolt-xfp-txpwr-lw-warn eolt-xfp-bias-hi-warn eolt-xfp-bias-lw-warn all) Possible values: - eolt-txpwr-hi-alm : Olt sfp tx power high alarm	alarm name of eoltrssi

Resource Identifier	Type	Description
	- eolt-txpwr-lw-alm : Olt sfp tx power low alarm - eolt-txbias-hi-alm : Olt sfp tx bias high alarm - eolt-txbias-lw-alm : Olt sfp tx bias low alarm - eolt-volt-hi-alm : Olt sfp voltage high alarm - eolt-volt-lw-alm : Olt sfp voltage low alarm - eolt-temp-hi-alm : Olt sfp temperature high alarm - eolt-temp-lw-alm : Olt sfp temperature low alarm - eolt-txpwr-hi-warn : Olt sfp tx power high warn - eolt-txpwr-lw-warn : Olt sfp tx power low warn - eolt-txbias-hi-warn : Olt sfp tx bias high warn - eolt-txbias-lw-warn : Olt sfp tx bias low warn - eolt-volt-hi-warn : Olt sfp voltage high warn - eolt-volt-lw-warn : Olt sfp voltage low warn - eolt-temp-hi-warn : Olt sfp temperature high warn - eolt-temp-lw-warn : Olt sfp temperature low warn - eolt-xfp-txpwr-hi-alm: Olt Xfp tx power high alarm - eolt-xfp-txpwr-lw-alm: Olt Xfp tx power low alarm - eolt-xfp-bias-hi-alm : Olt Xfp tx bias high alarm - eolt-xfp-bias-lw-alm : Olt Xfp tx bias low alarm - eolt-xfp-txpwr-hi-warn: Olt Xfp tx power high alarm - eolt-xfp-txpwr-lw-warn: Olt Xfp tx power low alarm - eolt-xfp-bias-hi-warn : Olt Xfp tx bias high alarm - eolt-xfp-bias-lw-warn : Olt Xfp tx bias low alarm - all : show all epon olt Sfp RSSI alarm	
severity	Parameter type: <Alarm::querySeverity> Format: (indeterminate warning minor major critical all) Possible values: - indeterminate : alarm severity is indeterminate - warning : alarm severity is warning - minor : alarm severity is minor - major : alarm severity is major - critical : alarm severity is critical - all : all alarm severity	severity level of an alarm for reporting
servaff	Parameter type: <Alarm::queryServAffect> Format: (service-affecting noservice-affecting all) Possible values: - service-affecting : query alarm service affecting - noservice-affecting : query alarm not service affecting - all : query service affecting and not affecting alarms	serviceaffecting no
epon-id	Parameter type: <Epon::PonId> Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId>	the epon id for Current alarms

Resource Identifier	Type	Description
	- the LT slot number Field type <Eqpt::PonId> - the PON identifier	

Command Output

Table 101.117-2 "show current alarm by filters" Display parameters

Specific Information		
name	Type	Description
aidinfo	Parameter type: <Alarm::AddInfoString> - additional alarm information	alarm AID parameters <i>This element is only shown in detail mode.</i>
type	Parameter type: <Alarm::alarmIHUBType> (equipment eqpt-holder plug-in-unit atm custom e1 ima-group ima-link redundancy shdsl ether-itf traffic-overflow qos-queue temporal spatial (software-mngt sw-mgmt) xdsl xdsl-ext xdsl-tca olt-gen eo-conv authentication bonding sfp shdsl-isam custom-ext-alarm plug-in-unit-ext sip-user-agent sip-plugin-unit sip-termination e1-sip-termination filetransfer external-device l2forward ether-tca ether-sfp megaco-media-gw megaco-sig-gw megaco-plug-unit megaco-term megaco-sig-lt eqpt-supplemental eqpt-holder-ext	type of the alarms that are active <i>This element is only shown in detail mode.</i>

name	Type	Description
	lsmredundancy	
	sync	
	mcsrc	
	vlanport	
	vect-line	
	vect-board	
	otdr	
	sip-dial-plan	
	sip-vsp	
	sip-server	
	bgp	
	rip	
	lag	
	ihub-general	
	vprn	
	isis	
	ospf	
	ihub-l2forward	
	vpls	
	ihub-equip	
	ihub-link	
	eont-phyoam	
	ellid	
	epon	
	eont-services-lan	
	eolt-ont-tca	
	eont-sw-dl	
	ldp	
	mpls	
	sdp	
	epipe	
	ihub-ipv6	
	pim	
	li	
	mgmt-sec-access	
	bfd	
	ai	
	tr069serv	
	ontsnmp	
	bulk-sync	
	protection-group	
	ont	
	sfu-sup	
	soho-sup	
	mdu-sup	
	ont-ani	
	sfu-sup2	
	soho-sup2	
	mdu-sup2	
	sfprssi	
	eoltrssi	
	cfm	
	sfpe1t1-framer	
	sfpe1t1-clock	
	pppcc-engine-tca	
	eth-cfm	
	rsvp	

101 query current alarms by filters

name	Type	Description
	ihub-tca eth-ring efm-oam ont-loopdetect ont-video ont-ces ont-voip ont-video-ani ont-pwe ont-cese1 ont-xdsl ont-xdsl-tca ont-hpna ont-sip-agent-cfg ont-voip-cfg ont-mgc ont-ploam ont-gen ont-card ont-pots ont-lan ont-moca ont-tc-tca ont-moca-tca ont-l2uni-eth-tca olt-pon-tc-tca olt-pon-util-tca olt-chpr-util-tca olt-ont-tc-tca ont-tca ont-pots-supplemental sfu-ploam sfu-gen soho-ploam soho-gen mdu-ploam mdu-gen ont-veip ont-iphost alarm-table auto-switch channel-pair ont-cfg-dld olt-chpair-tc-tca hgu-tr069 eqpt-psu ont-protection secondary-megaco-term secondary-sip-term cas-r2-channel lldpmed pseudo-wire link-agg fcs-exceed e1t1-interface) Possible values: - equipment : equipment alarms	

name	Type	Description
	- eqpt-holder : equipment holder alarms - plug-in-unit : plugin unit alarms - atm : ATM alarms - custom : customizable alarms - e1 : e1 alarms - ima-group : ima-group alarms - ima-link : ima-link alarms - redundancy : redundancy alarms - shdsl : shdsl alarms - ether-itf : ethernet interface alarms - traffic-overflow : Traffic overflow alarms - qos-queue : qos queue alarms - temporal : temporal alarms - spatial : spatial alarms - software-mngt : software management alarms - sw-mgmt : software management alarms - xdsl : xDSL alarms - xdsl-ext : other xDSL alarms - xdsl-tca : xDSL threshold cross alarms - olt-gen : OLT general alarms - eo-conv : E/O conversion related alarms - authentication : authentication related alarms - bonding : bonding-group related alarms - sfp : SFP related alarms - shdsl-isam : shdsl isam alarms - custom-ext-alarm : customizable external alarms - plug-in-unit-ext : other plugin unit alarms - sip-user-agent : sip user agent related alarms - sip-plugin-unit : sip plug in unit related alarms - sip-termination : sip termination related alarms - e1-sip-termination : E1 sip termination related alarms - filetransfer : file transfer server alarms - external-device : external device related alarms - l2forward : l2forward related alarms - ether-tca : ethernet threshold cross alarms - ether-sfp : ethernet SFP related alarms - megaco-media-gw : megaco media gateway related alarms - megaco-sig-gw : megaco signaling gateway related alarms - megaco-plug-unit : megaco plug unit related alarms - megaco-term : megaco termination related alarms - megaco-sig-lt : megaco signaling lt related alarms - eqpt-supplemental : equipment supplemental alarms - eqpt-holder-ext : other equipment holder alarms - lsmredundancy : lsm redundancy alarms - sync : synce and bits alarms - mcsrc : multicast source alarms - vlanport : vlanport alarms - vect-line : xDSL vectoring line alarms - vect-board : xDSL vectoring board alarms - otdr : otdr alarms - sip-dial-plan : sip dial plan related alarms - sip-vsp : sip vsp related alarms - sip-server : sip server related alarms - bgp : bgp related alarms - rip : rip related alarms - lag : LAG related alarms - ihub-general : IHUB general related alarms	

101 query current alarms by filters

name	Type	Description
	- vprn : vprn related alarms - isis : isis related alarms - ospf : ospf related alarms - ihub-l2forward : ihub-l2forward alarms - vpls : vpls related alarms - ihub-equip : ihub-equip related alarms - ihub-link : ihub-link related alarms - eont-phyoam : eont phyoam related alarms - ellid : ellid related alarms - epon : epon related alarms - eont-services-lan : eon phyoam related alarms - eolt-ont-tca : eon phyoam related alarms - eont-sw-dl : eon phyoam related alarms - ldp : ldp related alarms - mpls : mpls related alarms - sdp : sdp related alarms - epipe : epipe related alarms - ihub-ipv6 : ihub-ipv6 related alarms - pim : pim related alarms - li : lawful intercept related alarms - mgmt-sec-access : management security related alarms - bfd : bfd related alarms - ai : Application Intelligence related alarms - tr069serv : tr069 server related alarms - ontsnmp : ont snmp related alarms - bulk-sync : bulk-sync related alarms - protection-group : port protection group related alarms - ont : ONT general supplemental related alarms - sfu-sup : SFU ONT general supplemental related alarms - soho-sup : SOHO ONT general supplemental related alarms - mdu-sup : MDU ONT general supplemental related alarms - ont-ani : ONT general supplemental 2 related alarms - sfu-sup2 : SFU ONT general supplemental 2 related alarms - soho-sup2 : SOHO ONT general supplemental 2 related alarms - mdu-sup2 : MDU ONT general supplemental 2 related alarms - sfprssi : SFP RSSI related alarms - eoltrssi : epon olt Sfp RSSI related alarms - cfm : Cfm related alarms - sfpe1t1-framer : SFP 2e1t1 framer alarms - sfpe1t1-clock : SFP 2e1t1 clock alarms - pppcc-engine-tca : PPPOE Cross Connect Engine TCA related alarm - eth-cfm : eth-cfm related alarms - rsvp : rsvp related alarms - ihub-tca : IHUB TCA related alarms - eth-ring : eth-ring related alarms - efm-oam : EFM-OAM related alarms - ont-loopdetect : ont loop detect related alarms - ont-video : ont services video related alarms - ont-ces : ont services ces related alarms - ont-voip : ont services voip related alarms - ont-video-ani : ont services video ani related alarms - ont-pwe : ont services pwe related alarms - ont-cese1 : ont services cese1 related alarms	

name	Type	Description
	- ont-xdsl : ont services xdsl related alarms - ont-xdsl-tca : ont services xdsl tca related alarms - ont-hpna : ont hpna related alarms - ont-sip-agent-cfg : ont services voip sip agent config related alarms - ont-voip-cfg : ont services voip config related alarms - ont-mgc : ont mgc related alarms - ont-ploam : ONT PLOAM related alarms - ont-gen : ONT GENERAL related alarms - ont-card : ONT Subscriber Card related alarms - ont-pots : ONT Services POTS related alarms - ont-lan : ONT Services LAN related alarms - ont-moca : ONT MoCA related alarms - ont-tc-tca : ONT TC TCA related alarms - ont-moca-tca : ONT MoCA TCA related alarms - ont-l2uni-eth-tca : ONT L2 UNI Ethernet TCA related alarms - olt-pon-tc-tca : OLT PON TC TCA related alarms - olt-pon-util-tca : OLT PON utilization TCA related alarms - olt-chpr-util-tca : OLT channel-pair utilization TCA related alarms - olt-ont-tc-tca : OLT ONT TC TCA related alarms - ont-tca : ONT TCA related alarms - ont-pots-supplemental : ONT POTS Supplemental related alarms - sfu-ploam : SFU ONT PLOAM related alarms - sfu-gen : SFU ONT general related alarms - soho-ploam : SOHO ONT PLOAM related alarms - soho-gen : SOHO ONT general related alarms - mdu-ploam : MDU ONT PLOAM related alarms - mdu-gen : MDU ONT general related alarms - ont-veip : ONT VEIP related alarms - ont-iphost : ONT IP HOST related alarms - alarm-table : alarm table related alarms - auto-switch : auto-switch related alarms - channel-pair : channel pair related alarms - ont-cfg-dld : ont configure file download related alarms - olt-chpair-tc-tca : OLT CHANNELPAIR TC TCA related alarms - hgu-tr069 : hgu tr069 related alarms - eqpt-psu : equipment psu alarms - ont-protection : ONT protection related alarms - secondary-megaco-term : secondary megaco termination related alarms - secondary-sip-term : secondary sip termination related alarms - cas-r2-channel : CAS R2 channel related alarms - lldpmed : lldpmed alarms - pseudo-wire : pseudo Wire related alarms - link-agg : Link aggregation related alarms - fcs-exceed : FCS auto-recovery related alarms - e1t1-interface : E1/T1 physical interfaces related alarms	
name	Parameter type: <Alarm::almtypEoltrssi> (eolt-tpwr-hi-alm eolt-tpwr-lw-alm eolt-txbias-hi-alm eolt-txbias-lw-alm	alarm name that are active <i>This element is only shown in detail mode.</i>

101 query current alarms by filters

name	Type	Description
	eolt-volt-hi-alm eolt-volt-lw-alm eolt-temp-hi-alm eolt-temp-lw-alm eolt-tpwr-hi-warn eolt-tpwr-lw-warn eolt-txbias-hi-warn eolt-txbias-lw-warn eolt-volt-hi-warn eolt-volt-lw-warn eolt-temp-hi-warn eolt-temp-lw-warn eolt-xfp-tpwr-hi-alm eolt-xfp-tpwr-lw-alm eolt-xfp-bias-hi-alm eolt-xfp-bias-lw-alm eolt-xfp-tpwr-hi-warn eolt-xfp-tpwr-lw-warn eolt-xfp-bias-hi-warn eolt-xfp-bias-lw-warn all) Possible values: - eolt-tpwr-hi-alm : Olt sfp tx power high alarm - eolt-tpwr-lw-alm : Olt sfp tx power low alarm - eolt-txbias-hi-alm : Olt sfp tx bias high alarm - eolt-txbias-lw-alm : Olt sfp tx bias low alarm - eolt-volt-hi-alm : Olt sfp voltage high alarm - eolt-volt-lw-alm : Olt sfp voltage low alarm - eolt-temp-hi-alm : Olt sfp temperature high alarm - eolt-temp-lw-alm : Olt sfp temperature low alarm - eolt-tpwr-hi-warn : Olt sfp tx power high warn - eolt-tpwr-lw-warn : Olt sfp tx power low warn - eolt-txbias-hi-warn : Olt sfp tx bias high warn - eolt-txbias-lw-warn : Olt sfp tx bias low warn - eolt-volt-hi-warn : Olt sfp voltage high warn - eolt-volt-lw-warn : Olt sfp voltage low warn - eolt-temp-hi-warn : Olt sfp temperature high warn - eolt-temp-lw-warn : Olt sfp temperature low warn - eolt-xfp-tpwr-hi-alm: Olt Xfp tx power high alarm - eolt-xfp-tpwr-lw-alm: Olt Xfp tx power low alarm - eolt-xfp-bias-hi-alm : Olt Xfp tx bias high alarm - eolt-xfp-bias-lw-alm : Olt Xfp tx bias low alarm - eolt-xfp-tpwr-hi-warn: Olt Xfp tx power high alarm - eolt-xfp-tpwr-lw-warn: Olt Xfp tx power low alarm - eolt-xfp-bias-hi-warn : Olt Xfp tx bias high alarm - eolt-xfp-bias-lw-warn : Olt Xfp tx bias low alarm - all : show all epon olt Sfp RSSI alarm	
severity	Parameter type: <Alarm::AlarmSeverity> (indeterminate warning minor major critical) Possible values: - indeterminate : alarm severity is indeterminate - warning : alarm severity is warning - minor : alarm severity is minor	the alarms severity level <i>This element is only shown in detail mode.</i>

name	Type	Description
	- major : alarm severity is major - critical : alarm severity is critical	
servaff	Parameter type: <Alarm::alarmServAffect> ((service-affecting yes) (noservice-affecting no)) Possible values: - service-affecting : make this alarm service affecting - yes : make this alarm service affecting - noservice-affecting : make this alarm not service affecting - no : make this alarm not service affecting	alarms affect service or not <i>This element is only shown in detail mode.</i>
time	Parameter type: <Sys::timeInSecs> - the time (yyyy-mm-dd:hour:minutes:secs) - unit: UTC	time in seconds when alarm was updated <i>This element is only shown in detail mode.</i>
descript	Parameter type: <Alarm::AddInfoString> - additional alarm information	alarm description <i>This element is only shown in detail mode.</i>

101.118 show current alarm by filters

Command Description

show current alarms by filters

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm query bfd [ (name) [ severity <Alarm::querySeverity> ] [ servaff <Alarm::queryServAffect> ] [ vprn-id <lhub::Router> ] ]
```

Command Parameters

Table 101.118-1 "show current alarm by filters" Resource Parameters

Resource Identifier	Type	Description
(name)	Format: all Possible values: - all : bfd related alarms	alarm name of bfd
severity	Parameter type: <Alarm::querySeverity> Format: (indeterminate warning minor major critical all) Possible values: - indeterminate : alarm severity is indeterminate - warning : alarm severity is warning - minor : alarm severity is minor - major : alarm severity is major - critical : alarm severity is critical - all : all alarm severity	severity level of an alarm for reporting
servaff	Parameter type: <Alarm::queryServAffect> Format: (service-affecting noservice-affecting all) Possible values: - service-affecting : query alarm service affecting - noservice-affecting : query alarm not service affecting - all : query service affecting and not affecting alarms	serviceaffecting no

Resource Identifier	Type	Description
vprn-id	Parameter type: <Ihub::Router> Format: (base <Ihub::Router>) Possible values: - base : base router Field type <Ihub::Router> - vprn service-id - range: [1...2147483647]	identifies the vprn service-id or the base router

Command Output

Table 101.118-2 "show current alarm by filters" Display parameters

Specific Information		
name	Type	Description
aidinfo	Parameter type: <Alarm::AddInfoString> - additional alarm information	alarm AID parameters <i>This element is only shown in detail mode.</i>
type	Parameter type: <Alarm::alarmIHUBType> (equipment eqpt-holder plug-in-unit atm custom e1 ima-group ima-link redundancy shdsl ether-itf traffic-overflow qos-queue temporal spatial (software-mngt sw-mgmt) xdsl xdsl-ext xdsl-tca olt-gen eo-conv authentication bonding sfp shdsl-isam custom-ext-alarm plug-in-unit-ext sip-user-agent sip-plugin-unit sip-termination e1-sip-termination filetransfer external-device l2forward ether-tca ether-sfp megaco-media-gw	type of the alarms that are active <i>This element is only shown in detail mode.</i>

101 query current alarms by filters

name	Type	Description
	megaco-sig-gw megaco-plug-unit megaco-term megaco-sig-lt eqpt-supplemental eqpt-holder-ext lsmredundancy sync mcsrc vlanport vect-line vect-board otdr sip-dial-plan sip-vsp sip-server bgp rip lag ihub-general vprn isis ospf ihub-l2forward vpls ihub-equip ihub-link eont-phyoam ellid epon eont-services-lan eolt-ont-tca eont-sw-dl ldp mpls sdp epipe ihub-ipv6 pim li mgmt-sec-access bfd ai tr069serv ontsnmp bulk-sync protection-group ont sfu-sup soho-sup mdu-sup ont-ani sfu-sup2 soho-sup2 mdu-sup2 sfprssi eoltrssi	

name	Type	Description
	cfm	
	sfpe1t1-framer	
	sfpe1t1-clock	
	pppcc-engine-tca	
	eth-cfm	
	rsvp	
	ihub-tca	
	eth-ring	
	efm-oam	
	ont-loopdetect	
	ont-video	
	ont-ces	
	ont-voip	
	ont-video-ani	
	ont-pwe	
	ont-cese1	
	ont-xdsl	
	ont-xdsl-tca	
	ont-hpna	
	ont-sip-agent-cfg	
	ont-voip-cfg	
	ont-mgc	
	ont-ploam	
	ont-gen	
	ont-card	
	ont-pots	
	ont-lan	
	ont-moca	
	ont-tc-tca	
	ont-moca-tca	
	ont-l2uni-eth-tca	
	olt-pon-tc-tca	
	olt-pon-util-tca	
	olt-chpr-util-tca	
	olt-ont-tc-tca	
	ont-tca	
	ont-pots-supplemental	
	sfu-ploam	
	sfu-gen	
	soho-ploam	
	soho-gen	
	mdu-ploam	
	mdu-gen	
	ont-veip	
	ont-iphost	
	alarm-table	
	auto-switch	
	channel-pair	
	ont-cfg-dld	
	olt-chpair-tc-tca	
	hgu-tr069	
	eqpt-psu	
	ont-protection	
	secondary-megaco-term	
	secondary-sip-term	
	cas-r2-channel	
	lldpmed	

101 query current alarms by filters

name	Type	Description
	pseudo-wire link-agg fcs-exceed e1t1-interface) Possible values: - equipment : equipment alarms - eqpt-holder : equipment holder alarms - plug-in-unit : plugin unit alarms - atm : ATM alarms - custom : customizable alarms - e1 : e1 alarms - ima-group : ima-group alarms - ima-link : ima-link alarms - redundancy : redundancy alarms - shdsl : shdsl alarms - ether-itf : ethernet interface alarms - traffic-overflow : Traffic overflow alarms - qos-queue : qos queue alarms - temporal : temporal alarms - spatial : spatial alarms - software-mngt : software management alarms - sw-mgmt : software management alarms - xdsl : xDSL alarms - xdsl-ext : other xDSL alarms - xdsl-tca : xDSL threshold cross alarms - olt-gen : OLT general alarms - eo-conv : E/O conversion related alarms - authentication : authentication related alarms - bonding : bonding-group related alarms - sfp : SFP related alarms - shdsl-isam : shdsl isam alarms - custom-ext-alarm : customizable external alarms - plug-in-unit-ext : other plugin unit alarms - sip-user-agent : sip user agent related alarms - sip-plugin-unit : sip plug in unit related alarms - sip-termination : sip termination related alarms - e1-sip-termination : E1 sip termination related alarms - filetransfer : file transfer server alarms - external-device : external device related alarms - l2forward : l2forward related alarms - ether-tca : ethernet threshold cross alarms - ether-sfp : ethernet SFP related alarms - megaco-media-gw : megaco media gateway related alarms - megaco-sig-gw : megaco signaling gateway related alarms - megaco-plug-unit : megaco plug unit related alarms - megaco-term : megaco termination related alarms - megaco-sig-lt : megaco signaling lt related alarms - eqpt-supplemental : equipment supplemental alarms - eqpt-holder-ext : other equipment holder alarms - lsmredundancy : lsm redundancy alarms - sync : synce and bits alarms - mcsrc : multicast source alarms - vlanport : vlanport alarms - vect-line : xDSL vectoring line alarms - vect-board : xDSL vectoring board alarms - otdr : otdr alarms - sip-dial-plan : sip dial plan related alarms	

name	Type	Description
	- sip-vsp : sip vsp related alarms - sip-server : sip server related alarms - bgp : bgp related alarms - rip : rip related alarms - lag : LAG related alarms - ihub-general : IHUB general related alarms - vprn : vprn related alarms - isis : isis related alarms - ospf : ospf related alarms - ihub-l2forward : ihub-l2forward alarms - vpls : vpls related alarms - ihub-equip : ihub-equip related alarms - ihub-link : ihub-link related alarms - eont-phyoam : eont phyoam related alarms - ellid : ellid related alarms - epon : epon related alarms - eont-services-lan : eon phyoam related alarms - eolt-ont-tca : eon phyoam related alarms - eont-sw-dl : eon phyoam related alarms - ldp : ldp related alarms - mpls : mpls related alarms - sdp : sdp related alarms - epipe : epipe related alarms - ihub-ipv6 : ihub-ipv6 related alarms - pim : pim related alarms - li : lawful intercept related alarms - mgmt-sec-access : management security related alarms - bfd : bfd related alarms - ai : Application Intelligence related alarms - tr069serv : tr069 server related alarms - ontsnmp : ont snmp related alarms - bulk-sync : bulk-sync related alarms - protection-group : port protection group related alarms - ont : ONT general supplemental related alarms - sfu-sup : SFU ONT general supplemental related alarms - soho-sup : SOHO ONT general supplemental related alarms - mdu-sup : MDU ONT general supplemental related alarms - ont-ani : ONT general supplemental 2 related alarms - sfu-sup2 : SFU ONT general supplemental 2 related alarms - soho-sup2 : SOHO ONT general supplemental 2 related alarms - mdu-sup2 : MDU ONT general supplemental 2 related alarms - sfprssi : SFP RSSI related alarms - eoltrssi : epon olt Sfp RSSI related alarms - cfm : Cfm related alarms - sfpe1t1-framer : SFP 2e1t1 framer alarms - sfpe1t1-clock : SFP 2e1t1 clock alarms - pppcc-engine-tca : PPPOE Cross Connect Engine TCA related alarm - eth-cfm : eth-cfm related alarms - rsvp : rsvp related alarms - ihub-tca : IHUB TCA related alarms - eth-ring : eth-ring related alarms - efm-oam : EFM-OAM related alarms - ont-loopdetect : ont loop detect related alarms	

101 query current alarms by filters

name	Type	Description
	- ont-video : ont services video related alarms - ont-ces : ont services ces related alarms - ont-voip : ont services voip related alarms - ont-video-ani : ont services video ani related alarms - ont-pwe : ont services pwe related alarms - ont-cese1 : ont services cese1 related alarms - ont-xdsl : ont services xdsl related alarms - ont-xdsl-tca : ont services xdsl tca related alarms - ont-hpna : ont hpna related alarms - ont-sip-agent-cfg : ont services voip sip agent config related alarms - ont-voip-cfg : ont services voip config related alarms - ont-mgc : ont mgc related alarms - ont-ploam : ONT PLOAM related alarms - ont-gen : ONT GENERAL related alarms - ont-card : ONT Subscriber Card related alarms - ont-pots : ONT Services POTS related alarms - ont-lan : ONT Services LAN related alarms - ont-moca : ONT MoCA related alarms - ont-tc-tca : ONT TC TCA related alarms - ont-moca-tca : ONT MoCA TCA related alarms - ont-l2uni-eth-tca : ONT L2 UNI Ethernet TCA related alarms - olt-pon-tc-tca : OLT PON TC TCA related alarms - olt-pon-util-tca : OLT PON utilization TCA related alarms - olt-chpr-util-tca : OLT channel-pair utilization TCA related alarms - olt-ont-tc-tca : OLT ONT TC TCA related alarms - ont-tca : ONT TCA related alarms - ont-pots-supplemental : ONT POTS Supplemental related alarms - sfu-ploam : SFU ONT PLOAM related alarms - sfu-gen : SFU ONT general related alarms - soho-ploam : SOHO ONT PLOAM related alarms - soho-gen : SOHO ONT general related alarms - mdu-ploam : MDU ONT PLOAM related alarms - mdu-gen : MDU ONT general related alarms - ont-veip : ONT VEIP related alarms - ont-iphost : ONT IP HOST related alarms - alarm-table : alarm table related alarms - auto-switch : auto-switch related alarms - channel-pair : channel pair related alarms - ont-cfg-dld : ont configure file download related alarms - olt-chpair-tc-tca : OLT CHANNELPAIR TC TCA related alarms - hgu-tr069 : hgu tr069 related alarms - eqpt-psu : equipment psu alarms - ont-protection : ONT protection related alarms - secondary-megaco-term : secondary megaco termination related alarms - secondary-sip-term : secondary sip termination related alarms - cas-r2-channel : CAS R2 channel related alarms - lldpmed : lldpmed alarms - pseudo-wire : pseudo Wire related alarms - link-agg : Link aggregation related alarms - fcs-exceed : FCS auto-recovery related alarms	

name	Type	Description
	- e1t1-interface : E1/T1 physical interfaces related alarms	
name	Parameter type: <Alarm::alarmTypeBfd> all Possible values: - all : bfd related alarms	alarm name that are active <i>This element is only shown in detail mode.</i>
severity	Parameter type: <Alarm::AlarmSeverity> (indeterminate warning minor major critical) Possible values: - indeterminate : alarm severity is indeterminate - warning : alarm severity is warning - minor : alarm severity is minor - major : alarm severity is major - critical : alarm severity is critical	the alarms severity level <i>This element is only shown in detail mode.</i>
servaff	Parameter type: <Alarm::alarmServAffect> ((service-affecting yes) (noservice-affecting no)) Possible values: - service-affecting : make this alarm service affecting - yes : make this alarm service affecting - noservice-affecting : make this alarm not service affecting - no : make this alarm not service affecting	alarms affect service or not <i>This element is only shown in detail mode.</i>
time	Parameter type: <Sys::timeInSecs> - the time (yyyy-mm-dd:hour:minutes:secs) - unit: UTC	time in seconds when alarm was updated <i>This element is only shown in detail mode.</i>
descript	Parameter type: <Alarm::AddInfoString> - additional alarm information	alarm description <i>This element is only shown in detail mode.</i>

101.119 show current alarm by filters

Command Description

show current alarms by filters

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm query ai [ (name) [ severity <Alarm::querySeverity> ] [ servaff <Alarm::queryServAffect> ] [ board  
<Equipm::NtSlotIndex> ] ]
```

Command Parameters

Table 101.119-1 "show current alarm by filters" Resource Parameters

Resource Identifier	Type	Description
(name)	Format: (ai-platform-down ai-appl-install-fail ip-assign-fail all) Possible values: - ai-platform-down : Application Intelligence Platform down - ai-appl-install-fail : Application installation failure - ip-assign-fail : Dhcp assigned address failure - all : Application Intelligence related alarms	alarm name of ai
severity	Parameter type: <Alarm::querySeverity> Format: (indeterminate warning minor major critical all) Possible values: - indeterminate : alarm severity is indeterminate - warning : alarm severity is warning - minor : alarm severity is minor - major : alarm severity is major - critical : alarm severity is critical - all : all alarm severity	severity level of an alarm for reporting
servaff	Parameter type: <Alarm::queryServAffect> Format: (service-affecting	serviceaffecting no

Resource Identifier	Type	Description
	noservice-affecting all) Possible values: - service-affecting : query alarm service affecting - noservice-affecting : query alarm not service affecting - all : query service affecting and not affecting alarms	
board	Parameter type: <Equipm::NtSlotIndex> Format: (nt-a nt-b) Possible values: - nt-a : nt-a slot - nt-b : nt-b slot	identifies the board hosting the AI Platform

Command Output

Table 101.119-2 "show current alarm by filters" Display parameters

Specific Information		
name	Type	Description
aidinfo	Parameter type: <Alarm::AddInfoString> - additional alarm information	alarm AID parameters <i>This element is only shown in detail mode.</i>
type	Parameter type: <Alarm::alarmIHUBType> (equipment eqpt-holder plug-in-unit atm custom e1 ima-group ima-link redundancy shdsl ether-itf traffic-overflow qos-queue temporal spatial (software-mngt sw-mgmt) xdsl xdsl-ext xdsl-tca olt-gen eo-conv authentication bonding sfp shdsl-isam custom-ext-alarm plug-in-unit-ext sip-user-agent sip-plugin-unit sip-termination e1-sip-termination filetransfer external-device	type of the alarms that are active <i>This element is only shown in detail mode.</i>

101 query current alarms by filters

name	Type	Description
	l2forward	
	ether-tca	
	ether-sfp	
	megaco-media-gw	
	megaco-sig-gw	
	megaco-plug-unit	
	megaco-term	
	megaco-sig-lt	
	eqpt-supplemental	
	eqpt-holder-ext	
	lsmredundancy	
	sync	
	mcsrc	
	vlanport	
	vect-line	
	vect-board	
	otdr	
	sip-dial-plan	
	sip-vsp	
	sip-server	
	bgp	
	rip	
	lag	
	ihub-general	
	vprn	
	isis	
	ospf	
	ihub-l2forward	
	vpls	
	ihub-equip	
	ihub-link	
	eont-phyoam	
	ellid	
	epon	
	eont-services-lan	
	eolt-ont-tca	
	eont-sw-dl	
	ldp	
	mpls	
	sdp	
	epipe	
	ihub-ipv6	
	pim	
	li	
	mgmt-sec-access	
	bfd	
	ai	
	tr069serv	
	ontsnmp	
	bulk-sync	
	protection-group	
	ont	
	sfu-sup	
	soho-sup	
	mdu-sup	
	ont-ani	
	sfu-sup2	

name	Type	Description
	soho-sup2	
	mdu-sup2	
	sfprssi	
	eoltrssi	
	cfm	
	sfpe1t1-framer	
	sfpe1t1-clock	
	pppcc-engine-tca	
	eth-cfm	
	rsvp	
	ihub-tca	
	eth-ring	
	efm-oam	
	ont-loopdetect	
	ont-video	
	ont-ces	
	ont-voip	
	ont-video-ani	
	ont-pwe	
	ont-cese1	
	ont-xdsl	
	ont-xdsl-tca	
	ont-hpna	
	ont-sip-agent-cfg	
	ont-voip-cfg	
	ont-mgc	
	ont-ploam	
	ont-gen	
	ont-card	
	ont-pots	
	ont-lan	
	ont-moca	
	ont-tc-tca	
	ont-moca-tca	
	ont-l2uni-eth-tca	
	olt-pon-tc-tca	
	olt-pon-util-tca	
	olt-chpr-util-tca	
	olt-ont-tc-tca	
	ont-tca	
	ont-pots-supplemental	
	sfu-ploam	
	sfu-gen	
	soho-ploam	
	soho-gen	
	mdu-ploam	
	mdu-gen	
	ont-veip	
	ont-iphost	
	alarm-table	
	auto-switch	
	channel-pair	
	ont-cfg-dld	
	olt-chpair-tc-tca	
	hgu-tr069	
	eqpt-psu	
	ont-protection	

101 query current alarms by filters

name	Type	Description
	secondary-megaco-term secondary-sip-term cas-r2-channel lldpmed pseudo-wire link-agg fcs-exceed e1t1-interface) Possible values: - equipment : equipment alarms - eqpt-holder : equipment holder alarms - plug-in-unit : plugin unit alarms - atm : ATM alarms - custom : customizable alarms - e1 : e1 alarms - ima-group : ima-group alarms - ima-link : ima-link alarms - redundancy : redundancy alarms - shdsl : shdsl alarms - ether-itf : ethernet interface alarms - traffic-overflow : Traffic overflow alarms - qos-queue : qos queue alarms - temporal : temporal alarms - spatial : spatial alarms - software-mngt : software management alarms - sw-mgmt : software management alarms - xdsl : xDSL alarms - xdsl-ext : other xDSL alarms - xdsl-tca : xDSL threshold cross alarms - olt-gen : OLT general alarms - eo-conv : E/O conversion related alarms - authentication : authentication related alarms - bonding : bonding-group related alarms - sfp : SFP related alarms - shdsl-isam : shdsl isam alarms - custom-ext-alarm : customizable external alarms - plug-in-unit-ext : other plugin unit alarms - sip-user-agent : sip user agent related alarms - sip-plugin-unit : sip plug in unit related alarms - sip-termination : sip termination related alarms - e1-sip-termination : E1 sip termination related alarms - filetransfer : file transfer server alarms - external-device : external device related alarms - l2forward : l2forward related alarms - ether-tca : ethernet threshold cross alarms - ether-sfp : ethernet SFP related alarms - megaco-media-gw : megaco media gateway related alarms - megaco-sig-gw : megaco signaling gateway related alarms - megaco-plug-unit : megaco plug unit related alarms - megaco-term : megaco termination related alarms - megaco-sig-lt : megaco signaling lt related alarms - eqpt-supplemental : equipment supplemental alarms - eqpt-holder-ext : other equipment holder alarms - lsmredundancy : lsm redundancy alarms - sync : synce and bits alarms - mcsrc : multicast source alarms - vlanport : vlanport alarms	

name	Type	Description
	- vect-line : xDSL vectoring line alarms - vect-board : xDSL vectoring board alarms - otdr : otdr alarms - sip-dial-plan : sip dial plan related alarms - sip-vsp : sip vsp related alarms - sip-server : sip server related alarms - bgp : bgp related alarms - rip : rip related alarms - lag : LAG related alarms - ihub-general : IHUB general related alarms - vprn : vprn related alarms - isis : isis related alarms - ospf : ospf related alarms - ihub-l2forward : ihub-l2forward alarms - vpls : vpls related alarms - ihub-equip : ihub-equip related alarms - ihub-link : ihub-link related alarms - eont-phyoam : eont phyoam related alarms - ellid : ellid related alarms - epon : epon related alarms - eont-services-lan : eon phyoam related alarms - eolt-ont-tca : eon phyoam related alarms - eont-sw-dl : eon phyoam related alarms - ldp : ldp related alarms - mpls : mpls related alarms - sdp : sdp related alarms - epipe : epipe related alarms - ihub-ipv6 : ihub-ipv6 related alarms - pim : pim related alarms - li : lawful intercept related alarms - mgmt-sec-access : management security related alarms - bfd : bfd related alarms - ai : Application Intelligence related alarms - tr069serv : tr069 server related alarms - ontsnmp : ont snmp related alarms - bulk-sync : bulk-sync related alarms - protection-group : port protection group related alarms - ont : ONT general supplemental related alarms - sfu-sup : SFU ONT general supplemental related alarms - soho-sup : SOHO ONT general supplemental related alarms - mdu-sup : MDU ONT general supplemental related alarms - ont-ani : ONT general supplemental 2 related alarms - sfu-sup2 : SFU ONT general supplemental 2 related alarms - soho-sup2 : SOHO ONT general supplemental 2 related alarms - mdu-sup2 : MDU ONT general supplemental 2 related alarms - sfprssi : SFP RSSI related alarms - eoltrssi : epon olt Sfp RSSI related alarms - cfm : Cfm related alarms - sfpe1t1-framer : SFP 2e1t1 framer alarms - sfpe1t1-clock : SFP 2e1t1 clock alarms - pppcc-engine-tca : PPPOE Cross Connect Engine TCA related alarm - eth-cfm : eth-cfm related alarms - rsvp : rsvp related alarms	

101 query current alarms by filters

name	Type	Description
	- ihub-tca : IHUB TCA related alarms - eth-ring : eth-ring related alarms - efm-oam : EFM-OAM related alarms - ont-loopdetect : ont loop detect related alarms - ont-video : ont services video related alarms - ont-ces : ont services ces related alarms - ont-voip : ont services voip related alarms - ont-video-ani : ont services video ani related alarms - ont-pwe : ont services pwe related alarms - ont-cese1 : ont services cese1 related alarms - ont-xdsl : ont services xdsl related alarms - ont-xdsl-tca : ont services xdsl tca related alarms - ont-hpna : ont hpna related alarms - ont-sip-agent-cfg : ont services voip sip agent config related alarms - ont-voip-cfg : ont services voip config related alarms - ont-mgc : ont mgc related alarms - ont-ploam : ONT PLOAM related alarms - ont-gen : ONT GENERAL related alarms - ont-card : ONT Subscriber Card related alarms - ont-pots : ONT Services POTS related alarms - ont-lan : ONT Services LAN related alarms - ont-moca : ONT MoCA related alarms - ont-tc-tca : ONT TC TCA related alarms - ont-moca-tca : ONT MoCA TCA related alarms - ont-l2uni-eth-tca : ONT L2 UNI Ethernet TCA related alarms - olt-pon-tc-tca : OLT PON TC TCA related alarms - olt-pon-util-tca : OLT PON utilization TCA related alarms - olt-chpr-util-tca : OLT channel-pair utilization TCA related alarms - olt-ont-tc-tca : OLT ONT TC TCA related alarms - ont-tca : ONT TCA related alarms - ont-pots-supplemental : ONT POTS Supplemental related alarms - sfu-ploam : SFU ONT PLOAM related alarms - sfu-gen : SFU ONT general related alarms - soho-ploam : SOHO ONT PLOAM related alarms - soho-gen : SOHO ONT general related alarms - mdu-ploam : MDU ONT PLOAM related alarms - mdu-gen : MDU ONT general related alarms - ont-veip : ONT VEIP related alarms - ont-iphost : ONT IP HOST related alarms - alarm-table : alarm table related alarms - auto-switch : auto-switch related alarms - channel-pair : channel pair related alarms - ont-cfg-dld : ont configure file download related alarms - olt-chpair-tc-tca : OLT CHANNELPAIR TC TCA related alarms - hgu-tr069 : hgu tr069 related alarms - eqpt-psu : equipment psu alarms - ont-protection : ONT protection related alarms - secondary-megaco-term : secondary megaco termination related alarms - secondary-sip-term : secondary sip termination related alarms - cas-r2-channel : CAS R2 channel related alarms	

name	Type	Description
	- lldpmed : lldpmed alarms - pseudo-wire : pseudo Wire related alarms - link-aggr : Link aggregation related alarms - fcs-exceed : FCS auto-recovery related alarms - e1t1-interface : E1/T1 physical interfaces related alarms	
name	Parameter type: <Alarm::alarmTypeAiihub> (ai-platform-down ai-appl-install-fail ip-assign-fail all) Possible values: - ai-platform-down : Application Intelligence Platform down - ai-appl-install-fail : Application installation failure - ip-assign-fail : Dhcp assigned address failure - all : Application Intelligence related alarms	alarm name that are active <i>This element is only shown in detail mode.</i>
severity	Parameter type: <Alarm::AlarmSeverity> (indeterminate warning minor major critical) Possible values: - indeterminate : alarm severity is indeterminate - warning : alarm severity is warning - minor : alarm severity is minor - major : alarm severity is major - critical : alarm severity is critical	the alarms severity level <i>This element is only shown in detail mode.</i>
servaff	Parameter type: <Alarm::alarmServAffect> ((service-affecting yes) (noservice-affecting no)) Possible values: - service-affecting : make this alarm service affecting - yes : make this alarm service affecting - noservice-affecting : make this alarm not service affecting - no : make this alarm not service affecting	alarms affect service or not <i>This element is only shown in detail mode.</i>
time	Parameter type: <Sys::timeInSecs> - the time (yyyy-mm-dd:hour:minutes:secs) - unit: UTC	time in seconds when alarm was updated <i>This element is only shown in detail mode.</i>
descript	Parameter type: <Alarm::AddInfoString> - additional alarm information	alarm description <i>This element is only shown in detail mode.</i>

101.120 show current alarm by filters

Command Description

show current alarms by filters

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm query tr069serv [ (name) [ severity <Alarm::querySeverity> ] [ servaff <Alarm::queryServAffect> ] [ tr069serv <Gpon::UniInterfaceIndexSnmAgent> ] ]
```

Command Parameters

Table 101.120-1 "show current alarm by filters" Resource Parameters

Resource Identifier	Type	Description
(name)	Format: (ont-tr069-serv-mis all) Possible values: - ont-tr069-serv-mis : ont tr069 server config mismatch - all : tr069 server related alarms	alarm name of tr069serv
severity	Parameter type: <Alarm::querySeverity> Format: (indeterminate warning minor major critical all) Possible values: - indeterminate : alarm severity is indeterminate - warning : alarm severity is warning - minor : alarm severity is minor - major : alarm severity is major - critical : alarm severity is critical - all : all alarm severity	severity level of an alarm for reporting
servaff	Parameter type: <Alarm::queryServAffect> Format: (service-affecting noservice-affecting all) Possible values: - service-affecting : query alarm service affecting	serviceaffecting no

Resource Identifier	Type	Description
	- noservice-affecting : query alarm not service affecting - all : query service affecting and not affecting alarms	
tr069serv	Parameter type: <Gpon::UniInterfaceIndexSnmpAgent> Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> / <Eqpt::OntPortId> ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / <Eqpt::Ng2OntSlotId> / <Eqpt::Ng2OntPortId> ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / vuni) Possible values: - ng2 : ngpon2 style identification Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Eqpt::ChannelGroupId> - the channel group identifier Field type <Eqpt::SubChannelGroupId> - the subchannel group identifier Field type <Eqpt::OntId> - the ONT identifier Field type <Eqpt::Ng2OntId> - the NG2 ONT identifier Possible values: - vuni : virtual NGPON2 uni identifier Field type <Eqpt::OntSlotId> - the ONT SLOT identifier Field type <Eqpt::OntPortId> - the ONT PORT identifier Field type <Eqpt::Ng2OntSlotId> - the NGPON2 ONT SLOT identifier Field type <Eqpt::Ng2OntPortId> - the NGPON2 ONT PORT identifier	identifies the tr069 serv entry

Command Output

Table 101.120-2 "show current alarm by filters" Display parameters

Specific Information		
name	Type	Description
aidinfo	Parameter type: <Alarm::AddInfoString> - additional alarm information	alarm AID parameters <i>This element is only shown in detail mode.</i>
type	Parameter type: <Alarm::alarmIHUBType> (equipment eqpt-holder plug-in-unit atm custom e1	type of the alarms that are active <i>This element is only shown in detail mode.</i>

101 query current alarms by filters

name	Type	Description
	ima-group ima-link redundancy shdsl ether-itf traffic-overflow qos-queue temporal spatial (software-mngt sw-mgmt) xdsl xdsl-ext xdsl-tca olt-gen eo-conv authentication bonding sfp shdsl-isam custom-ext-alarm plug-in-unit-ext sip-user-agent sip-plugin-unit sip-termination e1-sip-termination filetransfer external-device l2forward ether-tca ether-sfp megaco-media-gw megaco-sig-gw megaco-plug-unit megaco-term megaco-sig-lt eqpt-supplemental eqpt-holder-ext lsmredundancy sync mcsrc vlanport vect-line vect-board otdr sip-dial-plan sip-vsp sip-server bgp rip lag ihub-general vprn isis ospf ihub-l2forward vpls ihub-equip	

name	Type	Description
	ihub-link	
	eont-phyoam	
	ellid	
	epon	
	eont-services-lan	
	eolt-ont-tca	
	eont-sw-dl	
	ldp	
	mpls	
	sdp	
	epipe	
	ihub-ipv6	
	pim	
	li	
	mgmt-sec-access	
	bfd	
	ai	
	tr069serv	
	ontsnmp	
	bulk-sync	
	protection-group	
	ont	
	sfu-sup	
	soho-sup	
	mdu-sup	
	ont-ani	
	sfu-sup2	
	soho-sup2	
	mdu-sup2	
	sfprssi	
	eoltrssi	
	cfm	
	sfpe1t1-framer	
	sfpe1t1-clock	
	pppcc-engine-tca	
	eth-cfm	
	rsvp	
	ihub-tca	
	eth-ring	
	efm-oam	
	ont-loopdetect	
	ont-video	
	ont-ces	
	ont-voip	
	ont-video-ani	
	ont-pwe	
	ont-cese1	
	ont-xdsl	
	ont-xdsl-tca	
	ont-hpna	
	ont-sip-agent-cfg	
	ont-voip-cfg	
	ont-mgc	
	ont-ploam	
	ont-gen	
	ont-card	
	ont-pots	

101 query current alarms by filters

name	Type	Description
	ont-lan ont-moca ont-tc-tca ont-moca-tca ont-l2uni-eth-tca olt-pon-tc-tca olt-pon-util-tca olt-chpr-util-tca olt-ont-tc-tca ont-tca ont-pots-supplemental sfu-ploam sfu-gen soho-ploam soho-gen mdu-ploam mdu-gen ont-veip ont-iphost alarm-table auto-switch channel-pair ont-cfg-dld olt-chpair-tc-tca hgu-tr069 eqpt-psu ont-protection secondary-megaco-term secondary-sip-term cas-r2-channel lldpmed pseudo-wire link-agg fcs-exceed e1t1-interface) Possible values: - equipment : equipment alarms - eqpt-holder : equipment holder alarms - plug-in-unit : plugin unit alarms - atm : ATM alarms - custom : customizable alarms - e1 : e1 alarms - ima-group : ima-group alarms - ima-link : ima-link alarms - redundancy : redundancy alarms - shdsl : shdsl alarms - ether-itf : ethernet interface alarms - traffic-overflow : Traffic overflow alarms - qos-queue : qos queue alarms - temporal : temporal alarms - spatial : spatial alarms - software-mngt : software management alarms - sw-mgmt : software management alarms - xdsl : xDSL alarms - xdsl-ext : other xDSL alarms - xdsl-tca : xDSL threshold cross alarms - olt-gen : OLT general alarms	

name	Type	Description
	- eo-conv : E/O conversion related alarms - authentication : authentication related alarms - bonding : bonding-group related alarms - sfp : SFP related alarms - shdsl-isam : shdsl isam alarms - custom-ext-alarm : customizable external alarms - plug-in-unit-ext : other plugin unit alarms - sip-user-agent : sip user agent related alarms - sip-plugin-unit : sip plug in unit related alarms - sip-termination : sip termination related alarms - e1-sip-termination : E1 sip termination related alarms - filetransfer : file transfer server alarms - external-device : external device related alarms - l2forward : l2forward related alarms - ether-tca : ethernet threshold cross alarms - ether-sfp : ethernet SFP related alarms - megaco-media-gw : megaco media gateway related alarms - megaco-sig-gw : megaco signaling gateway related alarms - megaco-plug-unit : megaco plug unit related alarms - megaco-term : megaco termination related alarms - megaco-sig-lt : megaco signaling lt related alarms - eqpt-supplemental : equipment supplemental alarms - eqpt-holder-ext : other equipment holder alarms - lsmredundancy : lsm redundancy alarms - sync : synce and bits alarms - mcsrc : multicast source alarms - vlanport : vlanport alarms - vect-line : xDSL vectoring line alarms - vect-board : xDSL vectoring board alarms - otdr : otdr alarms - sip-dial-plan : sip dial plan related alarms - sip-vsp : sip vsp related alarms - sip-server : sip server related alarms - bgp : bgp related alarms - rip : rip related alarms - lag : LAG related alarms - ihub-general : IHUB general related alarms - vprn : vprn related alarms - isis : isis related alarms - ospf : ospf related alarms - ihub-l2forward : ihub-l2forward alarms - vpls : vpls related alarms - ihub-equip : ihub-equip related alarms - ihub-link : ihub-link related alarms - eont-phyoam : eont phyoam related alarms - ellid : ellid related alarms - epon : epon related alarms - eont-services-lan : eon phyoam related alarms - eolt-ont-tca : eon phyoam related alarms - eont-sw-dl : eon phyoam related alarms - ldp : ldp related alarms - mpls : mpls related alarms - sdp : sdp related alarms - epipe : epipe related alarms - ihub-ipv6 : ihub-ipv6 related alarms - pim : pim related alarms - li : lawful intercept related alarms	

101 query current alarms by filters

name	Type	Description
	- mgmt-sec-access : management security related alarms - bfd : bfd related alarms - ai : Application Intelligence related alarms - tr069serv : tr069 server related alarms - ontsnmp : ont snmp related alarms - bulk-sync : bulk-sync related alarms - protection-group : port protection group related alarms - ont : ONT general supplemental related alarms - sfu-sup : SFU ONT general supplemental related alarms - soho-sup : SOHO ONT general supplemental related alarms - mdu-sup : MDU ONT general supplemental related alarms - ont-ani : ONT general supplemental 2 related alarms - sfu-sup2 : SFU ONT general supplemental 2 related alarms - soho-sup2 : SOHO ONT general supplemental 2 related alarms - mdu-sup2 : MDU ONT general supplemental 2 related alarms - sfprssi : SFP RSSI related alarms - eoltrssi : epon olt Sfp RSSI related alarms - cfm : Cfm related alarms - sfpe1t1-framer : SFP 2e1t1 framer alarms - sfpe1t1-clock : SFP 2e1t1 clock alarms - pppcc-engine-tca : PPPOE Cross Connect Engine TCA related alarm - eth-cfm : eth-cfm related alarms - rsvp : rsvp related alarms - ihub-tca : IHUB TCA related alarms - eth-ring : eth-ring related alarms - efm-oam : EFM-OAM related alarms - ont-loopdetect : ont loop detect related alarms - ont-video : ont services video related alarms - ont-ces : ont services ces related alarms - ont-voip : ont services voip related alarms - ont-video-ani : ont services video ani related alarms - ont-pwe : ont services pwe related alarms - ont-cese1 : ont services cese1 related alarms - ont-xdsl : ont services xdsl related alarms - ont-xdsl-tca : ont services xdsl tca related alarms - ont-hpna : ont hpna related alarms - ont-sip-agent-cfg : ont services voip sip agent config related alarms - ont-voip-cfg : ont services voip config related alarms - ont-mgc : ont mgc related alarms - ont-ploam : ONT PLOAM related alarms - ont-gen : ONT GENERAL related alarms - ont-card : ONT Subscriber Card related alarms - ont-pots : ONT Services POTS related alarms - ont-lan : ONT Services LAN related alarms - ont-moca : ONT MoCA related alarms - ont-tc-tca : ONT TC TCA related alarms - ont-moca-tca : ONT MoCA TCA related alarms - ont-l2uni-eth-tca : ONT L2 UNI Ethernet TCA related alarms - olt-pon-tc-tca : OLT PON TC TCA related alarms - olt-pon-util-tca : OLT PON utilization TCA related alarms - olt-chpr-util-tca : OLT channel-pair utilization TCA related	

name	Type	Description
	alarms - olt-ont-tc-tca : OLT ONT TC TCA related alarms - ont-tca : ONT TCA related alarms - ont-pots-supplemental : ONT POTS Supplemental related alarms - sfu-ploam : SFU ONT PLOAM related alarms - sfu-gen : SFU ONT general related alarms - soho-ploam : SOHO ONT PLOAM related alarms - soho-gen : SOHO ONT general related alarms - mdu-ploam : MDU ONT PLOAM related alarms - mdu-gen : MDU ONT general related alarms - ont-veip : ONT VEIP related alarms - ont-iphost : ONT IP HOST related alarms - alarm-table : alarm table related alarms - auto-switch : auto-switch related alarms - channel-pair : channel pair related alarms - ont-cfg-dld : ont configure file download related alarms - olt-chpair-tc-tca : OLT CHANNELPAIR TC TCA related alarms - hgu-tr069 : hgu tr069 related alarms - eqpt-psu : equipment psu alarms - ont-protection : ONT protection related alarms - secondary-megaco-term : secondary megaco termination related alarms - secondary-sip-term : secondary sip termination related alarms - cas-r2-channel : CAS R2 channel related alarms - lldpmed : lldpmed alarms - pseudo-wire : pseudo Wire related alarms - link-agg : Link aggregation related alarms - fcs-exceed : FCS auto-recovery related alarms - e1t1-interface : E1/T1 physical interfaces related alarms	
name	Parameter type: <Alarm::almtypeTr069servihub> (ont-tr069-serv-mis all) Possible values: - ont-tr069-serv-mis : ont tr069 server config mismatch - all : tr069 server related alarms	alarm name that are active <i>This element is only shown in detail mode.</i>
severity	Parameter type: <Alarm::AlarmSeverity> (indeterminate warning minor major critical) Possible values: - indeterminate : alarm severity is indeterminate - warning : alarm severity is warning - minor : alarm severity is minor - major : alarm severity is major - critical : alarm severity is critical	the alarms severity level <i>This element is only shown in detail mode.</i>
servaff	Parameter type: <Alarm::alarmServAffect> ((service-affecting yes) (noservice-affecting no)) Possible values: - service-affecting : make this alarm service affecting - yes : make this alarm service affecting - noservice-affecting : make this alarm not service affecting	alarms affect service or not <i>This element is only shown in detail mode.</i>

101 query current alarms by filters

name	Type	Description
	- no : make this alarm not service affecting	
time	Parameter type: <Sys::timeInSecs> - the time (yyyy-mm-dd:hour:minutes:secs) - unit: UTC	time in seconds when alarm was updated <i>This element is only shown in detail mode.</i>
descript	Parameter type: <Alarm::AddInfoString> - additional alarm information	alarm description <i>This element is only shown in detail mode.</i>

101.121 show current alarm by filters

Command Description

show current alarms by filters

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm query ontsnmp [ (name) [ severity <Alarm::querySeverity> ] [ servaff <Alarm::queryServAffect> ] [
uni-index <Ces::InterfaceIndex> ] ]
```

Command Parameters

Table 101.121-1 "show current alarm by filters" Resource Parameters

Resource Identifier	Type	Description
(name)	Format: (ont-snmis all) Possible values: - ont-snmis : ont snmp agent config mismatch - all : ont snmp related alarmsont snmp related alarms	alarm name of ontsnmp
severity	Parameter type: <Alarm::querySeverity> Format: (indeterminate warning minor major critical all) Possible values: - indeterminate : alarm severity is indeterminate - warning : alarm severity is warning - minor : alarm severity is minor - major : alarm severity is major - critical : alarm severity is critical - all : all alarm severity	severity level of an alarm for reporting
servaff	Parameter type: <Alarm::queryServAffect> Format: (service-affecting noservice-affecting all) Possible values: - service-affecting : query alarm service affecting	serviceaffecting no

101 query current alarms by filters

Resource Identifier	Type	Description
	- noservice-affecting : query alarm not service affecting - all : query service affecting and not affecting alarms	
uni-index	Parameter type: <Ces::InterfaceIndex> Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> / <Eqpt::OntPortId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Eqpt::OntId> - the ONT identifier Field type <Eqpt::OntSlotId> - the ONT SLOT identifier Field type <Eqpt::OntPortId> - the ONT PORT identifier	identification of the uni interface index

Command Output

Table 101.121-2 "show current alarm by filters" Display parameters

Specific Information		
name	Type	Description
aidinfo	Parameter type: <Alarm::AddInfoString> - additional alarm information	alarm AID parameters <i>This element is only shown in detail mode.</i>
type	Parameter type: <Alarm::alarmIHUBType> (equipment eqpt-holder plug-in-unit atm custom e1 ima-group ima-link redundancy shdsl ether-itf traffic-overflow qos-queue temporal spatial (software-mngt sw-mgmt) xdsl xdsl-ext xdsl-tca olt-gen eo-conv authentication bonding sfp shdsl-isam)	type of the alarms that are active <i>This element is only shown in detail mode.</i>

name	Type	Description
	custom-ext-alarm plug-in-unit-ext sip-user-agent sip-plugin-unit sip-termination e1-sip-termination filetransfer external-device l2forward ether-tca ether-sfp megaco-media-gw megaco-sig-gw megaco-plug-unit megaco-term megaco-sig-lt eqpt-supplemental eqpt-holder-ext lsmredundancy sync mcsrc vlanport vect-line vect-board otdr sip-dial-plan sip-vsp sip-server bgp rip lag ihub-general vprn isis ospf ihub-l2forward vpls ihub-equip ihub-link eont-phyoam ellid epon eont-services-lan eolt-ont-tca eont-sw-dl ldp mpls sdp epipe ihub-ipv6 pim li mgmt-sec-access bfd ai tr069serv ontsnmp	

101 query current alarms by filters

name	Type	Description
	bulk-sync	
	protection-group	
	ont	
	sfu-sup	
	soho-sup	
	mdu-sup	
	ont-ani	
	sfu-sup2	
	soho-sup2	
	mdu-sup2	
	sfprssi	
	eoltrssi	
	cfm	
	sfpe1t1-framer	
	sfpe1t1-clock	
	pppcc-engine-tca	
	eth-cfm	
	rsvp	
	ihub-tca	
	eth-ring	
	efm-oam	
	ont-loopdetect	
	ont-video	
	ont-ces	
	ont-voip	
	ont-video-ani	
	ont-pwe	
	ont-cese1	
	ont-xdsl	
	ont-xdsl-tca	
	ont-hpna	
	ont-sip-agent-cfg	
	ont-voip-cfg	
	ont-mgc	
	ont-ploam	
	ont-gen	
	ont-card	
	ont-pots	
	ont-lan	
	ont-moca	
	ont-tc-tca	
	ont-moca-tca	
	ont-l2uni-eth-tca	
	olt-pon-tc-tca	
	olt-pon-util-tca	
	olt-chpr-util-tca	
	olt-ont-tc-tca	
	ont-tca	
	ont-pots-supplemental	
	sfu-ploam	
	sfu-gen	
	soho-ploam	
	soho-gen	
	mdu-ploam	
	mdu-gen	
	ont-veip	
	ont-iphost	

name	Type	Description
	alarm-table auto-switch channel-pair ont-cfg-dld olt-chpair-tc-tca hgu-tr069 eqpt-psu ont-protection secondary-megaco-term secondary-sip-term cas-r2-channel lldpmed pseudo-wire link-agg fcs-exceed e1t1-interface) Possible values: - equipment : equipment alarms - eqpt-holder : equipment holder alarms - plug-in-unit : plugin unit alarms - atm : ATM alarms - custom : customizable alarms - e1 : e1 alarms - ima-group : ima-group alarms - ima-link : ima-link alarms - redundancy : redundancy alarms - shdsl : shdsl alarms - ether-itf : ethernet interface alarms - traffic-overflow : Traffic overflow alarms - qos-queue : qos queue alarms - temporal : temporal alarms - spatial : spatial alarms - software-mngt : software management alarms - sw-mgmt : software management alarms - xdsl : xDSL alarms - xdsl-ext : other xDSL alarms - xdsl-tca : xDSL threshold cross alarms - olt-gen : OLT general alarms - eo-conv : E/O conversion related alarms - authentication : authentication related alarms - bonding : bonding-group related alarms - sfp : SFP related alarms - shdsl-isam : shdsl isam alarms - custom-ext-alarm : customizable external alarms - plug-in-unit-ext : other plugin unit alarms - sip-user-agent : sip user agent related alarms - sip-plugin-unit : sip plug in unit related alarms - sip-termination : sip termination related alarms - e1-sip-termination : E1 sip termination related alarms - filetransfer : file transfer server alarms - external-device : external device related alarms - l2forward : l2forward related alarms - ether-tca : ethernet threshold cross alarms - ether-sfp : ethernet SFP related alarms - megaco-media-gw : megaco media gateway related alarms - megaco-sig-gw : megaco signaling gateway related alarms - megaco-plug-unit : megaco plug unit related alarms	

101 query current alarms by filters

name	Type	Description
	- megaco-term : megaco termination related alarms - megaco-sig-lt : megaco signaling lt related alarms - eqpt-supplemental : equipment supplemental alarms - eqpt-holder-ext : other equipment holder alarms - lsmredundancy : lsm redundancy alarms - sync : synce and bits alarms - mcsrc : multicast source alarms - vlanport : vlanport alarms - vect-line : xDSL vectoring line alarms - vect-board : xDSL vectoring board alarms - otdr : otdr alarms - sip-dial-plan : sip dial plan related alarms - sip-vsp : sip vsp related alarms - sip-server : sip server related alarms - bgp : bgp related alarms - rip : rip related alarms - lag : LAG related alarms - ihub-general : IHUB general related alarms - vprn : vprn related alarms - isis : isis related alarms - ospf : ospf related alarms - ihub-l2forward : ihub-l2forward alarms - vpls : vpls related alarms - ihub-equip : ihub-equip related alarms - ihub-link : ihub-link related alarms - eont-phyoam : eont phyoam related alarms - ellid : ellid related alarms - epon : epon related alarms - eont-services-lan : eon phyoam related alarms - eolt-ont-tca : eon phyoam related alarms - eont-sw-dl : eon phyoam related alarms - ldp : ldp related alarms - mpls : mpls related alarms - sdp : sdp related alarms - epipe : epipe related alarms - ihub-ipv6 : ihub-ipv6 related alarms - pim : pim related alarms - li : lawful intercept related alarms - mgmt-sec-access : management security related alarms - bfd : bfd related alarms - ai : Application Intelligence related alarms - tr069serv : tr069 server related alarms - ontsnmp : ont snmp related alarms - bulk-sync : bulk-sync related alarms - protection-group : port protection group related alarms - ont : ONT general supplemental related alarms - sfu-sup : SFU ONT general supplemental related alarms - soho-sup : SOHO ONT general supplemental related alarms - mdu-sup : MDU ONT general supplemental related alarms - ont-ani : ONT general supplemental 2 related alarms - sfu-sup2 : SFU ONT general supplemental 2 related alarms - soho-sup2 : SOHO ONT general supplemental 2 related alarms - mdu-sup2 : MDU ONT general supplemental 2 related alarms - sfrssi : SFP RSSI related alarms	

name	Type	Description
	- eoltrssi : epon olt Sfp RSSI related alarms - cfm : Cfm related alarms - sfpe1t1-framer : SFP 2e1t1 framer alarms - sfpe1t1-clock : SFP 2e1t1 clock alarms - pppcc-engine-tca : PPPOE Cross Connect Engine TCA related alarm - eth-cfm : eth-cfm related alarms - rsvp : rsvp related alarms - ihub-tca : IHUB TCA related alarms - eth-ring : eth-ring related alarms - efm-oam : EFM-OAM related alarms - ont-loopdetect : ont loop detect related alarms - ont-video : ont services video related alarms - ont-ces : ont services ces related alarms - ont-voip : ont services voip related alarms - ont-video-ani : ont services video ani related alarms - ont-pwe : ont services pwe related alarms - ont-cese1 : ont services cese1 related alarms - ont-xdsl : ont services xdsl related alarms - ont-xdsl-tca : ont services xdsl tca related alarms - ont-hpna : ont hpna related alarms - ont-sip-agent-cfg : ont services voip sip agent config related alarms - ont-voip-cfg : ont services voip config related alarms - ont-mgc : ont mgc related alarms - ont-ploam : ONT PLOAM related alarms - ont-gen : ONT GENERAL related alarms - ont-card : ONT Subscriber Card related alarms - ont-pots : ONT Services POTS related alarms - ont-lan : ONT Services LAN related alarms - ont-moca : ONT MoCA related alarms - ont-tc-tca : ONT TC TCA related alarms - ont-moca-tca : ONT MoCA TCA related alarms - ont-l2uni-eth-tca : ONT L2 UNI Ethernet TCA related alarms - olt-pon-tc-tca : OLT PON TC TCA related alarms - olt-pon-util-tca : OLT PON utilization TCA related alarms - olt-chpr-util-tca : OLT channel-pair utilization TCA related alarms - olt-ont-tc-tca : OLT ONT TC TCA related alarms - ont-tca : ONT TCA related alarms - ont-pots-supplemental : ONT POTS Supplemental related alarms - sfu-ploam : SFU ONT PLOAM related alarms - sfu-gen : SFU ONT general related alarms - soho-ploam : SOHO ONT PLOAM related alarms - soho-gen : SOHO ONT general related alarms - mdu-ploam : MDU ONT PLOAM related alarms - mdu-gen : MDU ONT general related alarms - ont-veip : ONT VEIP related alarms - ont-iphost : ONT IP HOST related alarms - alarm-table : alarm table related alarms - auto-switch : auto-switch related alarms - channel-pair : channel pair related alarms - ont-cfg-dld : ont configure file download related alarms - olt-chpair-tc-tca : OLT CHANNELPAIR TC TCA related alarms	

101 query current alarms by filters

name	Type	Description
	- hgu-tr069 : hgu tr069 related alarms - eqpt-psu : equipment psu alarms - ont-protection : ONT protection related alarms - secondary-megaco-term : secondary megaco termination related alarms - secondary-sip-term : secondary sip termination related alarms - cas-r2-channel : CAS R2 channel related alarms - lldpmed : lldpmed alarms - pseudo-wire : pseudo Wire related alarms - link-agg : Link aggregation related alarms - fcs-exceed : FCS auto-recovery related alarms - e1t1-interface : E1/T1 physical interfaces related alarms	
name	Parameter type: <Alarm::alarmTypeOntsnmpihub> (ont-snmpp-mis all) Possible values: - ont-snmpp-mis : ont snmp agent config mismatch - all : ont snmp related alarmsont snmp related alarms	alarm name that are active <i>This element is only shown in detail mode.</i>
severity	Parameter type: <Alarm::AlarmSeverity> (indeterminate warning minor major critical) Possible values: - indeterminate : alarm severity is indeterminate - warning : alarm severity is warning - minor : alarm severity is minor - major : alarm severity is major - critical : alarm severity is critical	the alarms severity level <i>This element is only shown in detail mode.</i>
servaff	Parameter type: <Alarm::alarmServAffect> ((service-affecting yes) (noservice-affecting no)) Possible values: - service-affecting : make this alarm service affecting - yes : make this alarm service affecting - noservice-affecting : make this alarm not service affecting - no : make this alarm not service affecting	alarms affect service or not <i>This element is only shown in detail mode.</i>
time	Parameter type: <Sys::timeInSecs> - the time (yyyy-mm-dd:hour:minutes:secs) - unit: UTC	time in seconds when alarm was updated <i>This element is only shown in detail mode.</i>
descript	Parameter type: <Alarm::AddInfoString> - additional alarm information	alarm description <i>This element is only shown in detail mode.</i>

101.122 show current alarm by filters

Command Description

show current alarms by filters

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm query bulk-sync [ (name) [ severity <Alarm::querySeverity> ] [ servaff <Alarm::queryServAffect> ]
[ port <RedPort::PortIndex> ] ]
```

Command Parameters

Table 101.122-1 "show current alarm by filters" Resource Parameters

Resource Identifier	Type	Description
(name)	Format: (bsf-dhcpv4 bsf-dhcpv6 bsf-pon bsf-vbridge bsf-qos bsf-igmp bsf-lxfwd all) Possible values: - bsf-dhcpv4 : bulksync failed for dhcpv4 - bsf-dhcpv6 : bulksync failed for dhcpv6 - bsf-pon : bulksync failed for pon - bsf-vbridge : bulksync failed for vlan-bridge - bsf-qos : bulksync failed for qos - bsf-igmp : bulksync failed for igmp - bsf-lxfwd : bulksync failed for lxfwd - all : port protection group related alarms	alarm name of bulk-sync
severity	Parameter type: <Alarm::querySeverity> Format: (indeterminate warning minor major critical all) Possible values: - indeterminate : alarm severity is indeterminate	severity level of an alarm for reporting

101 query current alarms by filters

Resource Identifier	Type	Description
	- warning : alarm severity is warning - minor : alarm severity is minor - major : alarm severity is major - critical : alarm severity is critical - all : all alarm severity	
servaff	Parameter type: <Alarm::queryServAffect> Format: (service-affecting noservice-affecting all) Possible values: - service-affecting : query alarm service affecting - noservice-affecting : query alarm not service affecting - all : query service affecting and not affecting alarms	serviceaffecting no
port	Parameter type: <RedPort::PortIndex> Format: (pon : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> chpair : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::ChannelPairId>) Possible values: - pon : pon-aid - chpair : chpair-aid Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Eqpt::ChannelPairId> - the channel pair identifier	specify which port the alarm occurred

Command Output

Table 101.122-2 "show current alarm by filters" Display parameters

Specific Information		
name	Type	Description
aidinfo	Parameter type: <Alarm::AddInfoString> - additional alarm information	alarm AID parameters <i>This element is only shown in detail mode.</i>
type	Parameter type: <Alarm::alarmIHUBType> (equipment eqpt-holder plug-in-unit atm custom e1 ima-group ima-link redundancy shdsl ether-itf traffic-overflow qos-queue	type of the alarms that are active <i>This element is only shown in detail mode.</i>

name	Type	Description
	temporal	
	spatial	
	(software-mngt sw-mgmt)	
	xdsl	
	xdsl-ext	
	xdsl-tca	
	olt-gen	
	eo-conv	
	authentication	
	bonding	
	sfp	
	shdsl-isam	
	custom-ext-alarm	
	plug-in-unit-ext	
	sip-user-agent	
	sip-plugin-unit	
	sip-termination	
	e1-sip-termination	
	filetransfer	
	external-device	
	l2forward	
	ether-tca	
	ether-sfp	
	megaco-media-gw	
	megaco-sig-gw	
	megaco-plug-unit	
	megaco-term	
	megaco-sig-lt	
	eqpt-supplemental	
	eqpt-holder-ext	
	lsmredundancy	
	sync	
	mcsrc	
	vlanport	
	vect-line	
	vect-board	
	otdr	
	sip-dial-plan	
	sip-vsp	
	sip-server	
	bgp	
	rip	
	lag	
	ihub-general	
	vprn	
	isis	
	ospf	
	ihub-l2forward	
	vpls	
	ihub-equip	
	ihub-link	
	eont-phyoam	
	ellid	
	epon	
	eont-services-lan	
	eolt-ont-tca	
	eont-sw-dl	

101 query current alarms by filters

name	Type	Description
	ldp	
	mpls	
	sdp	
	epipe	
	ihub-ipv6	
	pim	
	li	
	mgmt-sec-access	
	bfd	
	ai	
	tr069serv	
	ontsnmp	
	bulk-sync	
	protection-group	
	ont	
	sfu-sup	
	soho-sup	
	mdu-sup	
	ont-ani	
	sfu-sup2	
	soho-sup2	
	mdu-sup2	
	sfprssi	
	eoltrssi	
	cfm	
	sfpe1t1-framer	
	sfpe1t1-clock	
	pppcc-engine-tca	
	eth-cfm	
	rsvp	
	ihub-tca	
	eth-ring	
	efm-oam	
	ont-loopdetect	
	ont-video	
	ont-ces	
	ont-voip	
	ont-video-ani	
	ont-pwe	
	ont-cese1	
	ont-xdsl	
	ont-xdsl-tca	
	ont-hpna	
	ont-sip-agent-cfg	
	ont-voip-cfg	
	ont-mgc	
	ont-ploam	
	ont-gen	
	ont-card	
	ont-pots	
	ont-lan	
	ont-moca	
	ont-tc-tca	
	ont-moca-tca	
	ont-l2uni-eth-tca	
	olt-pon-tc-tca	
	olt-pon-util-tca	

name	Type	Description
	olt-chpr-util-tca olt-ont-tc-tca ont-tca ont-pots-supplemental sfu-ploam sfu-gen soho-ploam soho-gen mdu-ploam mdu-gen ont-veip ont-iphost alarm-table auto-switch channel-pair ont-cfg-dld olt-chpair-tc-tca hgu-tr069 eqpt-psu ont-protection secondary-megaco-term secondary-sip-term cas-r2-channel lldpmed pseudo-wire link-agg fcs-exceed e1t1-interface) Possible values: - equipment : equipment alarms - eqpt-holder : equipment holder alarms - plug-in-unit : plugin unit alarms - atm : ATM alarms - custom : customizable alarms - e1 : e1 alarms - ima-group : ima-group alarms - ima-link : ima-link alarms - redundancy : redundancy alarms - shdsl : shdsl alarms - ether-itf : ethernet interface alarms - traffic-overflow : Traffic overflow alarms - qos-queue : qos queue alarms - temporal : temporal alarms - spatial : spatial alarms - software-mngt : software management alarms - sw-mgmt : software management alarms - xdsl : xDSL alarms - xdsl-ext : other xDSL alarms - xdsl-tca : xDSL threshold cross alarms - olt-gen : OLT general alarms - eo-conv : E/O conversion related alarms - authentication : authentication related alarms - bonding : bonding-group related alarms - sfp : SFP related alarms - shdsl-isam : shdsl isam alarms - custom-ext-alarm : customizable external alarms - plug-in-unit-ext : other plugin unit alarms	

101 query current alarms by filters

name	Type	Description
	- sip-user-agent : sip user agent related alarms - sip-plugin-unit : sip plug in unit related alarms - sip-termination : sip termination related alarms - e1-sip-termination : E1 sip termination related alarms - filetransfer : file transfer server alarms - external-device : external device related alarms - l2forward : l2forward related alarms - ether-tca : ethernet threshold cross alarms - ether-sfp : ethernet SFP related alarms - megaco-media-gw : megaco media gateway related alarms - megaco-sig-gw : megaco signaling gateway related alarms - megaco-plug-unit : megaco plug unit related alarms - megaco-term : megaco termination related alarms - megaco-sig-lt : megaco signaling lt related alarms - eqpt-supplemental : equipment supplemental alarms - eqpt-holder-ext : other equipment holder alarms - lsmredundancy : lsm redundancy alarms - sync : synce and bits alarms - mcsrc : multicast source alarms - vlanport : vlanport alarms - vect-line : xDSL vectoring line alarms - vect-board : xDSL vectoring board alarms - otdr : otdr alarms - sip-dial-plan : sip dial plan related alarms - sip-vsp : sip vsp related alarms - sip-server : sip server related alarms - bgp : bgp related alarms - rip : rip related alarms - lag : LAG related alarms - ihub-general : IHUB general related alarms - vprn : vprn related alarms - isis : isis related alarms - ospf : ospf related alarms - ihub-l2forward : ihub-l2forward alarms - vpls : vpls related alarms - ihub-equip : ihub-equip related alarms - ihub-link : ihub-link related alarms - eont-phyoam : eont phyoam related alarms - ellid : ellid related alarms - epon : epon related alarms - eont-services-lan : eon phyoam related alarms - eolt-ont-tca : eon phyoam related alarms - eont-sw-dl : eon phyoam related alarms - ldp : ldp related alarms - mpls : mpls related alarms - sdp : sdp related alarms - epipe : epipe related alarms - ihub-ipv6 : ihub-ipv6 related alarms - pim : pim related alarms - li : lawful intercept related alarms - mgmt-sec-access : management security related alarms - bfd : bfd related alarms - ai : Application Intelligence related alarms - tr069serv : tr069 server related alarms - ontsnmp : ont snmp related alarms - bulk-sync : bulk-sync related alarms - protection-group : port protection group related alarms	

name	Type	Description
	- ont : ONT general supplemental related alarms - sfu-sup : SFU ONT general supplemental related alarms - soho-sup : SOHO ONT general supplemental related alarms - mdu-sup : MDU ONT general supplemental related alarms - ont-ani : ONT general supplemental 2 related alarms - sfu-sup2 : SFU ONT general supplemental 2 related alarms - soho-sup2 : SOHO ONT general supplemental 2 related alarms - mdu-sup2 : MDU ONT general supplemental 2 related alarms - sfprssi : SFP RSSI related alarms - eoltrssi : epon olt Sfp RSSI related alarms - cfm : Cfm related alarms - sfpe1t1-framer : SFP 2e1t1 framer alarms - sfpe1t1-clock : SFP 2e1t1 clock alarms - pppcc-engine-tca : PPPOE Cross Connect Engine TCA related alarm - eth-cfm : eth-cfm related alarms - rsvp : rsvp related alarms - ihub-tca : IHUB TCA related alarms - eth-ring : eth-ring related alarms - efm-oam : EFM-OAM related alarms - ont-loopdetect : ont loop detect related alarms - ont-video : ont services video related alarms - ont-ces : ont services ces related alarms - ont-voip : ont services voip related alarms - ont-video-ani : ont services video ani related alarms - ont-pwe : ont services pwe related alarms - ont-cese1 : ont services cese1 related alarms - ont-xdsl : ont services xdsl related alarms - ont-xdsl-tca : ont services xdsl tca related alarms - ont-hpna : ont hpna related alarms - ont-sip-agent-cfg : ont services voip sip agent config related alarms - ont-voip-cfg : ont services voip config related alarms - ont-mgc : ont mgc related alarms - ont-ploam : ONT PLOAM related alarms - ont-gen : ONT GENERAL related alarms - ont-card : ONT Subscriber Card related alarms - ont-pots : ONT Services POTS related alarms - ont-lan : ONT Services LAN related alarms - ont-moca : ONT MoCA related alarms - ont-tc-tca : ONT TC TCA related alarms - ont-moca-tca : ONT MoCA TCA related alarms - ont-l2uni-eth-tca : ONT L2 UNI Ethernet TCA related alarms - olt-pon-tc-tca : OLT PON TC TCA related alarms - olt-pon-util-tca : OLT PON utilization TCA related alarms - olt-chpr-util-tca : OLT channel-pair utilization TCA related alarms - olt-ont-tc-tca : OLT ONT TC TCA related alarms - ont-tca : ONT TCA related alarms - ont-pots-supplemental : ONT POTS Supplemental related alarms - sfu-ploam : SFU ONT PLOAM related alarms - sfu-gen : SFU ONT general related alarms	

101 query current alarms by filters

name	Type	Description
	- soho-ploam : SOHO ONT PLOAM related alarms - soho-gen : SOHO ONT general related alarms - mdu-ploam : MDU ONT PLOAM related alarms - mdu-gen : MDU ONT general related alarms - ont-veip : ONT VEIP related alarms - ont-iphost : ONT IP HOST related alarms - alarm-table : alarm table related alarms - auto-switch : auto-switch related alarms - channel-pair : channel pair related alarms - ont-cfg-dld : ont configure file download related alarms - olt-chpair-tc-tca : OLT CHANNELPAIR TC TCA related alarms - hgu-tr069 : hgu tr069 related alarms - eqpt-psu : equipment psu alarms - ont-protection : ONT protection related alarms - secondary-megaco-term : secondary megaco termination related alarms - secondary-sip-term : secondary sip termination related alarms - cas-r2-channel : CAS R2 channel related alarms - lldpmed : lldpmed alarms - pseudo-wire : pseudo Wire related alarms - link-agg : Link aggregation related alarms - fcs-exceed : FCS auto-recovery related alarms - e1t1-interface : E1/T1 physical interfaces related alarms	
name	Parameter type: <Alarm::alarmtypeBulksyncihub> (bsf-dhcpv4 bsf-dhcpv6 bsf-pon bsf-vbridge bsf-qos bsf-igmp bsf-lxfwd all) Possible values: - bsf-dhcpv4 : bulksync failed for dhcpv4 - bsf-dhcpv6 : bulksync failed for dhcpv6 - bsf-pon : bulksync failed for pon - bsf-vbridge : bulksync failed for vlan-bridge - bsf-qos : bulksync failed for qos - bsf-igmp : bulksync failed for igmp - bsf-lxfwd : bulksync failed for lxfwd - all : port protection group related alarms	alarm name that are active <i>This element is only shown in detail mode.</i>
severity	Parameter type: <Alarm::AlarmSeverity> (indeterminate warning minor major critical) Possible values: - indeterminate : alarm severity is indeterminate - warning : alarm severity is warning - minor : alarm severity is minor - major : alarm severity is major - critical : alarm severity is critical	the alarms severity level <i>This element is only shown in detail mode.</i>
servaff	Parameter type: <Alarm::alarmServAffect> ((service-affecting yes)	alarms affect service or not <i>This element is only shown in</i>

name	Type	Description
	(noservice-affecting no)) Possible values: - service-affecting : make this alarm service affecting - yes : make this alarm service affecting - noservice-affecting : make this alarm not service affecting - no : make this alarm not service affecting	<i>detail mode.</i>
time	Parameter type: <Sys::timeInSecs> - the time (yyyy-mm-dd:hour:minutes:secs) - unit: UTC	time in seconds when alarm was updated <i>This element is only shown in detail mode.</i>
descript	Parameter type: <Alarm::AddInfoString> - additional alarm information	alarm description <i>This element is only shown in detail mode.</i>

101.123 show current alarm by filters

Command Description

show current alarms by filters

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm query protection-group [ (name) [ severity <Alarm::querySeverity> ] [ servaff  
<Alarm::queryServAffect> ] [ port <RedPort::PortIndex> ] ]
```

Command Parameters

Table 101.123-1 "show current alarm by filters" Resource Parameters

Resource Identifier	Type	Description
(name)	Format: (prot-not-available prot-switchover-fail all) Possible values: - prot-not-available : no protection not available - prot-switchover-fail : port switch over failed - all : port protection group related alarms	alarm name of protection-group
severity	Parameter type: <Alarm::querySeverity> Format: (indeterminate warning minor major critical all) Possible values: - indeterminate : alarm severity is indeterminate - warning : alarm severity is warning - minor : alarm severity is minor - major : alarm severity is major - critical : alarm severity is critical - all : all alarm severity	severity level of an alarm for reporting
servaff	Parameter type: <Alarm::queryServAffect> Format: (service-affecting noservice-affecting all)	serviceaffecting no

Resource Identifier	Type	Description
	Possible values: - service-affecting : query alarm service affecting - noservice-affecting : query alarm not service affecting - all : query service affecting and not affecting alarms	
port	Parameter type: <RedPort::PortIndex> Format: (pon : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> chpair : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::ChannelPairId>) Possible values: - pon : pon-aid - chpair : chpair-aid Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Eqpt::ChannelPairId> - the channel pair identifier	specify which port the alarm occurred

Command Output

Table 101.123-2 "show current alarm by filters" Display parameters

Specific Information		
name	Type	Description
aidinfo	Parameter type: <Alarm::AddInfoString> - additional alarm information	alarm AID parameters <i>This element is only shown in detail mode.</i>
type	Parameter type: <Alarm::alarmIHUBType> (equipment eqpt-holder plug-in-unit atm custom e1 ima-group ima-link redundancy shdsl ether-itf traffic-overflow qos-queue temporal spatial (software-mngt sw-mgmt) xdsl xdsl-ext xdsl-tca olt-gen eo-conv authentication bonding	type of the alarms that are active <i>This element is only shown in detail mode.</i>

101 query current alarms by filters

name	Type	Description
	sfp shdsl-isam custom-ext-alarm plug-in-unit-ext sip-user-agent sip-plugin-unit sip-termination e1-sip-termination filetransfer external-device l2forward ether-tca ether-sfp megaco-media-gw megaco-sig-gw megaco-plugin-unit megaco-term megaco-sig-lt eqpt-supplemental eqpt-holder-ext lsmredundancy sync mcsrc vlanport vect-line vect-board otdr sip-dial-plan sip-vsp sip-server bgp rip lag ihub-general vprn isis ospf ihub-l2forward vpls ihub-equip ihub-link eont-phyoam ellid epon eont-services-lan eolt-ont-tca eont-sw-dl ldp mpls sdp epipe ihub-ipv6 pim li mgmt-sec-access bfd ai	

name	Type	Description
	tr069serv	
	ontsnmp	
	bulk-sync	
	protection-group	
	ont	
	sfu-sup	
	soho-sup	
	mdu-sup	
	ont-ani	
	sfu-sup2	
	soho-sup2	
	mdu-sup2	
	sfprssi	
	eoltrssi	
	cfm	
	sfpe1t1-framer	
	sfpe1t1-clock	
	pppcc-engine-tca	
	eth-cfm	
	rsvp	
	ihub-tca	
	eth-ring	
	efm-oam	
	ont-loopdetect	
	ont-video	
	ont-ces	
	ont-voip	
	ont-video-ani	
	ont-pwe	
	ont-cese1	
	ont-xdsl	
	ont-xdsl-tca	
	ont-hpna	
	ont-sip-agent-cfg	
	ont-voip-cfg	
	ont-mgc	
	ont-ploam	
	ont-gen	
	ont-card	
	ont-pots	
	ont-lan	
	ont-moca	
	ont-tc-tca	
	ont-moca-tca	
	ont-l2uni-eth-tca	
	olt-pon-tc-tca	
	olt-pon-util-tca	
	olt-chpr-util-tca	
	olt-ont-tc-tca	
	ont-tca	
	ont-pots-supplemental	
	sfu-ploam	
	sfu-gen	
	soho-ploam	
	soho-gen	
	mdu-ploam	
	mdu-gen	

101 query current alarms by filters

name	Type	Description
	ont-veip ont-iphost alarm-table auto-switch channel-pair ont-cfg-dld olt-chpair-tc-tca hgu-tr069 eqpt-psu ont-protection secondary-megaco-term secondary-sip-term cas-r2-channel lldpmed pseudo-wire link-agg fcs-exceed e1t1-interface) Possible values: - equipment : equipment alarms - eqpt-holder : equipment holder alarms - plug-in-unit : plugin unit alarms - atm : ATM alarms - custom : customizable alarms - e1 : e1 alarms - ima-group : ima-group alarms - ima-link : ima-link alarms - redundancy : redundancy alarms - shdsl : shdsl alarms - ether-itf : ethernet interface alarms - traffic-overflow : Traffic overflow alarms - qos-queue : qos queue alarms - temporal : temporal alarms - spatial : spatial alarms - software-mngt : software management alarms - sw-mgmt : software management alarms - xdsl : xDSL alarms - xdsl-ext : other xDSL alarms - xdsl-tca : xDSL threshold cross alarms - olt-gen : OLT general alarms - eo-conv : E/O conversion related alarms - authentication : authentication related alarms - bonding : bonding-group related alarms - sfp : SFP related alarms - shdsl-isam : shdsl isam alarms - custom-ext-alarm : customizable external alarms - plug-in-unit-ext : other plugin unit alarms - sip-user-agent : sip user agent related alarms - sip-plugin-unit : sip plug in unit related alarms - sip-termination : sip termination related alarms - e1-sip-termination : E1 sip termination related alarms - filetransfer : file transfer server alarms - external-device : external device related alarms - l2forward : l2forward related alarms - ether-tca : ethernet threshold cross alarms - ether-sfp : ethernet SFP related alarms - megaco-media-gw : megaco media gateway related alarms	

name	Type	Description
	- megaco-sig-gw : megaco signaling gateway related alarms - megaco-plug-unit : megaco plug unit related alarms - megaco-term : megaco termination related alarms - megaco-sig-lt : megaco signaling lt related alarms - eqpt-supplemental : equipment supplemental alarms - eqpt-holder-ext : other equipment holder alarms - lsmredundancy : lsm redundancy alarms - sync : synce and bits alarms - mcsrc : multicast source alarms - vlanport : vlanport alarms - vect-line : xDSL vectoring line alarms - vect-board : xDSL vectoring board alarms - otdr : otdr alarms - sip-dial-plan : sip dial plan related alarms - sip-vsp : sip vsp related alarms - sip-server : sip server related alarms - bgp : bgp related alarms - rip : rip related alarms - lag : LAG related alarms - ihub-general : IHUB general related alarms - vprn : vprn related alarms - isis : isis related alarms - ospf : ospf related alarms - ihub-l2forward : ihub-l2forward alarms - vpls : vpls related alarms - ihub-equip : ihub-equip related alarms - ihub-link : ihub-link related alarms - eont-phyoam : eont phyoam related alarms - ellid : ellid related alarms - epon : epon related alarms - eont-services-lan : eon phyoam related alarms - eolt-ont-tca : eon phyoam related alarms - eont-sw-dl : eon phyoam related alarms - ldp : ldp related alarms - mpls : mpls related alarms - sdp : sdp related alarms - epipe : epipe related alarms - ihub-ipv6 : ihub-ipv6 related alarms - pim : pim related alarms - li : lawful intercept related alarms - mgmt-sec-access : management security related alarms - bfd : bfd related alarms - ai : Application Intelligence related alarms - tr069serv : tr069 server related alarms - ontsnmp : ont snmp related alarms - bulk-sync : bulk-sync related alarms - protection-group : port protection group related alarms - ont : ONT general supplemental related alarms - sfu-sup : SFU ONT general supplemental related alarms - soho-sup : SOHO ONT general supplemental related alarms - mdu-sup : MDU ONT general supplemental related alarms - ont-ani : ONT general supplemental 2 related alarms - sfu-sup2 : SFU ONT general supplemental 2 related alarms - soho-sup2 : SOHO ONT general supplemental 2 related alarms - mdu-sup2 : MDU ONT general supplemental 2 related	

101 query current alarms by filters

name	Type	Description
	alarms - sfprssi : SFP RSSI related alarms - eoltrssi : epon olt Sfp RSSI related alarms - cfm : Cfm related alarms - sfpe1t1-framer : SFP 2e1t1 framer alarms - sfpe1t1-clock : SFP 2e1t1 clock alarms - pppcc-engine-tca : PPPOE Cross Connect Engine TCA related alarm - eth-cfm : eth-cfm related alarms - rsvp : rsvp related alarms - ihub-tca : IHUB TCA related alarms - eth-ring : eth-ring related alarms - efm-oam : EFM-OAM related alarms - ont-loopdetect : ont loop detect related alarms - ont-video : ont services video related alarms - ont-ces : ont services ces related alarms - ont-voip : ont services voip related alarms - ont-video-ani : ont services video ani related alarms - ont-pwe : ont services pwe related alarms - ont-cese1 : ont services cese1 related alarms - ont-xdsl : ont services xdsl related alarms - ont-xdsl-tca : ont services xdsl tca related alarms - ont-hpna : ont hpna related alarms - ont-sip-agent-cfg : ont services voip sip agent config related alarms - ont-voip-cfg : ont services voip config related alarms - ont-mgc : ont mgc related alarms - ont-ploam : ONT PLOAM related alarms - ont-gen : ONT GENERAL related alarms - ont-card : ONT Subscriber Card related alarms - ont-pots : ONT Services POTS related alarms - ont-lan : ONT Services LAN related alarms - ont-moca : ONT MoCA related alarms - ont-tc-tca : ONT TC TCA related alarms - ont-moca-tca : ONT MoCA TCA related alarms - ont-l2uni-eth-tca : ONT L2 UNI Ethernet TCA related alarms - olt-pon-tc-tca : OLT PON TC TCA related alarms - olt-pon-util-tca : OLT PON utilization TCA related alarms - olt-chpr-util-tca : OLT channel-pair utilization TCA related alarms - olt-ont-tc-tca : OLT ONT TC TCA related alarms - ont-tca : ONT TCA related alarms - ont-pots-supplemental : ONT POTS Supplemental related alarms - sfu-ploam : SFU ONT PLOAM related alarms - sfu-gen : SFU ONT general related alarms - soho-ploam : SOHO ONT PLOAM related alarms - soho-gen : SOHO ONT general related alarms - mdu-ploam : MDU ONT PLOAM related alarms - mdu-gen : MDU ONT general related alarms - ont-veip : ONT VEIP related alarms - ont-iphost : ONT IP HOST related alarms - alarm-table : alarm table related alarms - auto-switch : auto-switch related alarms - channel-pair : channel pair related alarms - ont-cfg-dld : ont configure file download related alarms	

name	Type	Description
	- olt-chpair-tc-tca : OLT CHANNELPAIR TC TCA related alarms - hgu-tr069 : hgu tr069 related alarms - eqpt-psu : equipment psu alarms - ont-protection : ONT protection related alarms - secondary-megaco-term : secondary megaco termination related alarms - secondary-sip-term : secondary sip termination related alarms - cas-r2-channel : CAS R2 channel related alarms - lldpmed : lldpmed alarms - pseudo-wire : pseudo Wire related alarms - link-agg : Link aggregation related alarms - fcs-exceed : FCS auto-recovery related alarms - e1t1-interface : E1/T1 physical interfaces related alarms	
name	Parameter type: <Alarm::almtypeProtectiongroupithub> (prot-not-available prot-switchover-fail all) Possible values: - prot-not-available : no protection not available - prot-switchover-fail : port switch over failed - all : port protection group related alarms	alarm name that are active <i>This element is only shown in detail mode.</i>
severity	Parameter type: <Alarm::AlarmSeverity> (indeterminate warning minor major critical) Possible values: - indeterminate : alarm severity is indeterminate - warning : alarm severity is warning - minor : alarm severity is minor - major : alarm severity is major - critical : alarm severity is critical	the alarms severity level <i>This element is only shown in detail mode.</i>
servaff	Parameter type: <Alarm::alarmServAffect> ((service-affecting yes) (noservice-affecting no)) Possible values: - service-affecting : make this alarm service affecting - yes : make this alarm service affecting - noservice-affecting : make this alarm not service affecting - no : make this alarm not service affecting	alarms affect service or not <i>This element is only shown in detail mode.</i>
time	Parameter type: <Sys::timeInSecs> - the time (yyyy-mm-dd:hour:minutes:secs) - unit: UTC	time in seconds when alarm was updated <i>This element is only shown in detail mode.</i>
descript	Parameter type: <Alarm::AddInfoString> - additional alarm information	alarm description <i>This element is only shown in detail mode.</i>

101.124 show current alarm by filters

Command Description

show current alarms by filters

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm query ont-protection [ (name) [ severity <Alarm::querySeverity> ] [ servaff
<Alarm::queryServAffect> ] [ ont <Gpon::OntIndex> ] ]
```

Command Parameters

Table 101.124-1 "show current alarm by filters" Resource Parameters

Resource Identifier	Type	Description
(name)	Format: (ont-prot-not-available all) Possible values: - ont-prot-not-available: no ont protection available - all : ont protection related alarms	alarm name of protection-group
severity	Parameter type: <Alarm::querySeverity> Format: (indeterminate warning minor major critical all) Possible values: - indeterminate : alarm severity is indeterminate - warning : alarm severity is warning - minor : alarm severity is minor - major : alarm severity is major - critical : alarm severity is critical - all : all alarm severity	severity level of an alarm for reporting
servaff	Parameter type: <Alarm::queryServAffect> Format: (service-affecting noservice-affecting all) Possible values: - service-affecting : query alarm service affecting	serviceaffecting no

Resource Identifier	Type	Description
	- noservice-affecting : query alarm not service affecting - all : query service affecting and not affecting alarms	
ont	Parameter type: <Gpon::OntIndex> Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> ng2 : <Ng2::ChannelGroup> / <Ng2::SubchannelGroup> / <Ng2::OntId>) Possible values: - ng2 : ngpon2 style identification Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Ng2::ChannelGroup> - channel group number Field type <Ng2::SubchannelGroup> - subchannel group number Field type <Eqpt::OntId> - the ONT identifier Field type <Ng2::OntId> - the ONT identifier	specify which ont the alarm occurred

Command Output

Table 101.124-2 "show current alarm by filters" Display parameters

Specific Information		
name	Type	Description
aidinfo	Parameter type: <Alarm::AddInfoString> - additional alarm information	alarm AID parameters <i>This element is only shown in detail mode.</i>
type	Parameter type: <Alarm::alarmIHUBType> (equipment eqpt-holder plug-in-unit atm custom e1 ima-group ima-link redundancy shdsl ether-itf traffic-overflow qos-queue temporal spatial (software-mngt sw-mgmt) xdsl xdsl-ext xdsl-tca olt-gen	type of the alarms that are active <i>This element is only shown in detail mode.</i>

101 query current alarms by filters

name	Type	Description
	eo-conv	
	authentication	
	bonding	
	sfp	
	shdsl-isam	
	custom-ext-alarm	
	plug-in-unit-ext	
	sip-user-agent	
	sip-plugin-unit	
	sip-termination	
	e1-sip-termination	
	filetransfer	
	external-device	
	l2forward	
	ether-tca	
	ether-sfp	
	megaco-media-gw	
	megaco-sig-gw	
	megaco-plug-unit	
	megaco-term	
	megaco-sig-lt	
	eqpt-supplemental	
	eqpt-holder-ext	
	lsmredundancy	
	sync	
	mcsrc	
	vlanport	
	vect-line	
	vect-board	
	otdr	
	sip-dial-plan	
	sip-vsp	
	sip-server	
	bgp	
	rip	
	lag	
	ihub-general	
	vprn	
	isis	
	ospf	
	ihub-l2forward	
	vpls	
	ihub-equip	
	ihub-link	
	eont-phyoam	
	ellid	
	epon	
	eont-services-lan	
	eolt-ont-tca	
	eont-sw-dl	
	ldp	
	mpls	
	sdp	
	epipe	
	ihub-ipv6	
	pim	
	li	

name	Type	Description
	mgmt-sec-access bfd ai tr069serv ontsnmp bulk-sync protection-group ont sfu-sup soho-sup mdu-sup ont-ani sfu-sup2 soho-sup2 mdu-sup2 sfprssi eoltrssi cfm sfpe1t1-framer sfpe1t1-clock pppcc-engine-tca eth-cfm rsvp ihub-tca eth-ring efm-oam ont-loopdetect ont-video ont-ces ont-voip ont-video-ani ont-pwe ont-cese1 ont-xdsl ont-xdsl-tca ont-hpna ont-sip-agent-cfg ont-voip-cfg ont-mgc ont-ploam ont-gen ont-card ont-pots ont-lan ont-moca ont-tc-tca ont-moca-tca ont-l2uni-eth-tca olt-pon-tc-tca olt-pon-util-tca olt-chpr-util-tca olt-ont-tc-tca ont-tca ont-pots-supplemental sfu-ploam sfu-gen soho-ploam	

101 query current alarms by filters

name	Type	Description
	soho-gen mdu-ploam mdu-gen ont-veip ont-iphost alarm-table auto-switch channel-pair ont-cfg-dld olt-chpair-tc-tca hgu-tr069 eqpt-psu ont-protection secondary-megaco-term secondary-sip-term cas-r2-channel lldpmed pseudo-wire link-agg fcs-exceed e1t1-interface) Possible values: - equipment : equipment alarms - eqpt-holder : equipment holder alarms - plug-in-unit : plugin unit alarms - atm : ATM alarms - custom : customizable alarms - e1 : e1 alarms - ima-group : ima-group alarms - ima-link : ima-link alarms - redundancy : redundancy alarms - shdsl : shdsl alarms - ether-itf : ethernet interface alarms - traffic-overflow : Traffic overflow alarms - qos-queue : qos queue alarms - temporal : temporal alarms - spatial : spatial alarms - software-mngt : software management alarms - sw-mgmt : software management alarms - xdsl : xDSL alarms - xdsl-ext : other xDSL alarms - xdsl-tca : xDSL threshold cross alarms - olt-gen : OLT general alarms - eo-conv : E/O conversion related alarms - authentication : authentication related alarms - bonding : bonding-group related alarms - sfp : SFP related alarms - shdsl-isam : shdsl isam alarms - custom-ext-alarm : customizable external alarms - plug-in-unit-ext : other plugin unit alarms - sip-user-agent : sip user agent related alarms - sip-plugin-unit : sip plug in unit related alarms - sip-termination : sip termination related alarms - e1-sip-termination : E1 sip termination related alarms - filetransfer : file transfer server alarms - external-device : external device related alarms - l2forward : l2forward related alarms	

name	Type	Description
	- ether-tca : ethernet threshold cross alarms - ether-sfp : ethernet SFP related alarms - megaco-media-gw : megaco media gateway related alarms - megaco-sig-gw : megaco signaling gateway related alarms - megaco-plug-unit : megaco plug unit related alarms - megaco-term : megaco termination related alarms - megaco-sig-lt : megaco signaling lt related alarms - eqpt-supplemental : equipment supplemental alarms - eqpt-holder-ext : other equipment holder alarms - lsmredundancy : lsm redundancy alarms - sync : synce and bits alarms - mcsrc : multicast source alarms - vlanport : vlanport alarms - vect-line : xDSL vectoring line alarms - vect-board : xDSL vectoring board alarms - otdr : otdr alarms - sip-dial-plan : sip dial plan related alarms - sip-vsp : sip vsp related alarms - sip-server : sip server related alarms - bgp : bgp related alarms - rip : rip related alarms - lag : LAG related alarms - ihub-general : IHUB general related alarms - vprn : vprn related alarms - isis : isis related alarms - ospf : ospf related alarms - ihub-l2forward : ihub-l2forward alarms - vpls : vpls related alarms - ihub-equip : ihub-equip related alarms - ihub-link : ihub-link related alarms - eont-phyoam : eont phyoam related alarms - ellid : ellid related alarms - epon : epon related alarms - eont-services-lan : eon phyoam related alarms - eolt-ont-tca : eon phyoam related alarms - eont-sw-dl : eon phyoam related alarms - ldp : ldp related alarms - mpls : mpls related alarms - sdp : sdp related alarms - epipe : epipe related alarms - ihub-ipv6 : ihub-ipv6 related alarms - pim : pim related alarms - li : lawful intercept related alarms - mgmt-sec-access : management security related alarms - bfd : bfd related alarms - ai : Application Intelligence related alarms - tr069serv : tr069 server related alarms - ontsnmp : ont snmp related alarms - bulk-sync : bulk-sync related alarms - protection-group : port protection group related alarms - ont : ONT general supplemental related alarms - sfu-sup : SFU ONT general supplemental related alarms - soho-sup : SOHO ONT general supplemental related alarms - mdu-sup : MDU ONT general supplemental related alarms - ont-ani : ONT general supplemental 2 related alarms - sfu-sup2 : SFU ONT general supplemental 2 related alarms	

101 query current alarms by filters

name	Type	Description
	- soho-sup2 : SOHO ONT general supplemental 2 related alarms - mdu-sup2 : MDU ONT general supplemental 2 related alarms - sfrssi : SFP RSSI related alarms - eoltrssi : epon olt Sfp RSSI related alarms - cfm : Cfm related alarms - sfpe1t1-framer : SFP 2e1t1 framer alarms - sfpe1t1-clock : SFP 2e1t1 clock alarms - pppcc-engine-tca : PPPOE Cross Connect Engine TCA related alarm - eth-cfm : eth-cfm related alarms - rsvp : rsvp related alarms - ihub-tca : IHUB TCA related alarms - eth-ring : eth-ring related alarms - efm-oam : EFM-OAM related alarms - ont-loopdetect : ont loop detect related alarms - ont-video : ont services video related alarms - ont-ces : ont services ces related alarms - ont-voip : ont services voip related alarms - ont-video-ani : ont services video ani related alarms - ont-pwe : ont services pwe related alarms - ont-cese1 : ont services cese1 related alarms - ont-xdsl : ont services xdsl related alarms - ont-xdsl-tca : ont services xdsl tca related alarms - ont-hpna : ont hpna related alarms - ont-sip-agent-cfg : ont services voip sip agent config related alarms - ont-voip-cfg : ont services voip config related alarms - ont-mgc : ont mgc related alarms - ont-ploam : ONT PLOAM related alarms - ont-gen : ONT GENERAL related alarms - ont-card : ONT Subscriber Card related alarms - ont-pots : ONT Services POTS related alarms - ont-lan : ONT Services LAN related alarms - ont-moca : ONT MoCA related alarms - ont-tc-tca : ONT TC TCA related alarms - ont-moca-tca : ONT MoCA TCA related alarms - ont-l2uni-eth-tca : ONT L2 UNI Ethernet TCA related alarms - olt-pon-tc-tca : OLT PON TC TCA related alarms - olt-pon-util-tca : OLT PON utilization TCA related alarms - olt-chpr-util-tca : OLT channel-pair utilization TCA related alarms - olt-ont-tc-tca : OLT ONT TC TCA related alarms - ont-tca : ONT TCA related alarms - ont-pots-supplemental : ONT POTS Supplemental related alarms - sfu-ploam : SFU ONT PLOAM related alarms - sfu-gen : SFU ONT general related alarms - soho-ploam : SOHO ONT PLOAM related alarms - soho-gen : SOHO ONT general related alarms - mdu-ploam : MDU ONT PLOAM related alarms - mdu-gen : MDU ONT general related alarms - ont-veip : ONT VEIP related alarms - ont-iphost : ONT IP HOST related alarms - alarm-table : alarm table related alarms	

name	Type	Description
	- auto-switch : auto-switch related alarms - channel-pair : channel pair related alarms - ont-cfg-dld : ont configure file download related alarms - olt-chpair-tc-tca : OLT CHANNELPAIR TC TCA related alarms - hgu-tr069 : hgu tr069 related alarms - eqpt-psu : equipment psu alarms - ont-protection : ONT protection related alarms - secondary-megaco-term : secondary megaco termination related alarms - secondary-sip-term : secondary sip termination related alarms - cas-r2-channel : CAS R2 channel related alarms - lldpmed : lldpmed alarms - pseudo-wire : pseudo Wire related alarms - link-agg : Link aggregation related alarms - fcs-exceed : FCS auto-recovery related alarms - e1t1-interface : E1/T1 physical interfaces related alarms	
name	Parameter type: <Alarm::alarmTypeOntProtectionihub> (ont-prot-not-available all) Possible values: - ont-prot-not-available: no ont protection available - all : ont protection related alarms	alarm name that are active <i>This element is only shown in detail mode.</i>
severity	Parameter type: <Alarm::AlarmSeverity> (indeterminate warning minor major critical) Possible values: - indeterminate : alarm severity is indeterminate - warning : alarm severity is warning - minor : alarm severity is minor - major : alarm severity is major - critical : alarm severity is critical	the alarms severity level <i>This element is only shown in detail mode.</i>
servaff	Parameter type: <Alarm::alarmServAffect> ((service-affecting yes) (noservice-affecting no)) Possible values: - service-affecting : make this alarm service affecting - yes : make this alarm service affecting - noservice-affecting : make this alarm not service affecting - no : make this alarm not service affecting	alarms affect service or not <i>This element is only shown in detail mode.</i>
time	Parameter type: <Sys::timeInSecs> - the time (yyyy-mm-dd:hour:minutes:secs) - unit: UTC	time in seconds when alarm was updated <i>This element is only shown in detail mode.</i>
descript	Parameter type: <Alarm::AddInfoString> - additional alarm information	alarm description <i>This element is only shown in detail mode.</i>

101.125 show current alarm by filters

Command Description

show current alarms by filters

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm query eth-cfm [ (name) [ severity <Alarm::querySeverity> ] [ servaff <Alarm::queryServAffect> ] [ cfm-mep-id <UnsignedSignedInteger> ] ]
```

Command Parameters

Table 101.125-1 "show current alarm by filters" Resource Parameters

Resource Identifier	Type	Description
(name)	Format: (eth-cfm-defrdiccm eth-cfm-defmacstatus eth-cfm-defremoteccm eth-cfm-deferrorccm eth-cfm-defxconccm all) Possible values: - eth-cfm-defrdiccm : rdi bit in ccm received - eth-cfm-defmacstatus : ccm mac error status - eth-cfm-defremoteccm : missing ccm from mep - eth-cfm-deferrorccm : invalid ccm received - eth-cfm-defxconccm : unexpected ccm received - all : eth-cfm related alarms	alarm name of eth-cfm
severity	Parameter type: <Alarm::querySeverity> Format: (indeterminate warning minor major critical all) Possible values: - indeterminate : alarm severity is indeterminate - warning : alarm severity is warning - minor : alarm severity is minor - major : alarm severity is major - critical : alarm severity is critical	severity level of an alarm for reporting

Resource Identifier	Type	Description
	- all : all alarm severity	
servaff	Parameter type: <Alarm::queryServAffect> Format: (service-affecting noservice-affecting all) Possible values: - service-affecting : query alarm service affecting - noservice-affecting : query alarm not service affecting - all : query service affecting and not affecting alarms	serviceaffecting no serviceaffecting
cfm-mep-id	Parameter type: <UnsignedSignedInteger> Format: - an unsigned integer	dot1agCfmMepIdentifier index where the alarm has occurred

Command Output

Table 101.125-2 "show current alarm by filters" Display parameters

Specific Information		
name	Type	Description
aidinfo	Parameter type: <Alarm::AddInfoString> - additional alarm information	alarm AID parameters <i>This element is only shown in detail mode.</i>
type	Parameter type: <Alarm::alarmIHUBType> (equipment eqpt-holder plug-in-unit atm custom e1 ima-group ima-link redundancy shdsl ether-itf traffic-overflow qos-queue temporal spatial (software-mngt sw-mgmt) xdsl xdsl-ext xdsl-tca olt-gen eo-conv authentication bonding sfp shdsl-isam custom-ext-alarm plug-in-unit-ext sip-user-agent sip-plugin-unit sip-termination e1-sip-termination filetransfer external-device	type of the alarms that are active <i>This element is only shown in detail mode.</i>

101 query current alarms by filters

name	Type	Description
	l2forward	
	ether-tca	
	ether-sfp	
	megaco-media-gw	
	megaco-sig-gw	
	megaco-plug-unit	
	megaco-term	
	megaco-sig-lt	
	eqpt-supplemental	
	eqpt-holder-ext	
	lsmredundancy	
	sync	
	mcsrc	
	vlanport	
	vect-line	
	vect-board	
	otdr	
	sip-dial-plan	
	sip-vsp	
	sip-server	
	bgp	
	rip	
	lag	
	ihub-general	
	vprn	
	isis	
	ospf	
	ihub-l2forward	
	vpls	
	ihub-equip	
	ihub-link	
	eont-phyoam	
	ellid	
	epon	
	eont-services-lan	
	eolt-ont-tca	
	eont-sw-dl	
	ldp	
	mpls	
	sdp	
	epipe	
	ihub-ipv6	
	pim	
	li	
	mgmt-sec-access	
	bfd	
	ai	
	tr069serv	
	ontsnmp	
	bulk-sync	
	protection-group	
	ont	
	sfu-sup	
	soho-sup	
	mdu-sup	
	ont-ani	
	sfu-sup2	

name	Type	Description
	soho-sup2	
	mdu-sup2	
	sfprssi	
	eoltrssi	
	cfm	
	sfpe1t1-framer	
	sfpe1t1-clock	
	pppcc-engine-tca	
	eth-cfm	
	rsvp	
	ihub-tca	
	eth-ring	
	efm-oam	
	ont-loopdetect	
	ont-video	
	ont-ces	
	ont-voip	
	ont-video-ani	
	ont-pwe	
	ont-cese1	
	ont-xdsl	
	ont-xdsl-tca	
	ont-hpna	
	ont-sip-agent-cfg	
	ont-voip-cfg	
	ont-mgc	
	ont-ploam	
	ont-gen	
	ont-card	
	ont-pots	
	ont-lan	
	ont-moca	
	ont-tc-tca	
	ont-moca-tca	
	ont-l2uni-eth-tca	
	olt-pon-tc-tca	
	olt-pon-util-tca	
	olt-chpr-util-tca	
	olt-ont-tc-tca	
	ont-tca	
	ont-pots-supplemental	
	sfu-ploam	
	sfu-gen	
	soho-ploam	
	soho-gen	
	mdu-ploam	
	mdu-gen	
	ont-veip	
	ont-iphost	
	alarm-table	
	auto-switch	
	channel-pair	
	ont-cfg-dld	
	olt-chpair-tc-tca	
	hgu-tr069	
	eqpt-psu	
	ont-protection	

101 query current alarms by filters

name	Type	Description
	secondary-megaco-term secondary-sip-term cas-r2-channel lldpmed pseudo-wire link-agg fcs-exceed e1t1-interface) Possible values: - equipment : equipment alarms - eqpt-holder : equipment holder alarms - plug-in-unit : plugin unit alarms - atm : ATM alarms - custom : customizable alarms - e1 : e1 alarms - ima-group : ima-group alarms - ima-link : ima-link alarms - redundancy : redundancy alarms - shdsl : shdsl alarms - ether-itf : ethernet interface alarms - traffic-overflow : Traffic overflow alarms - qos-queue : qos queue alarms - temporal : temporal alarms - spatial : spatial alarms - software-mngt : software management alarms - sw-mgmt : software management alarms - xdsl : xDSL alarms - xdsl-ext : other xDSL alarms - xdsl-tca : xDSL threshold cross alarms - olt-gen : OLT general alarms - eo-conv : E/O conversion related alarms - authentication : authentication related alarms - bonding : bonding-group related alarms - sfp : SFP related alarms - shdsl-isam : shdsl isam alarms - custom-ext-alarm : customizable external alarms - plug-in-unit-ext : other plugin unit alarms - sip-user-agent : sip user agent related alarms - sip-plugin-unit : sip plug in unit related alarms - sip-termination : sip termination related alarms - e1-sip-termination : E1 sip termination related alarms - filetransfer : file transfer server alarms - external-device : external device related alarms - l2forward : l2forward related alarms - ether-tca : ethernet threshold cross alarms - ether-sfp : ethernet SFP related alarms - megaco-media-gw : megaco media gateway related alarms - megaco-sig-gw : megaco signaling gateway related alarms - megaco-plug-unit : megaco plug unit related alarms - megaco-term : megaco termination related alarms - megaco-sig-lt : megaco signaling lt related alarms - eqpt-supplemental : equipment supplemental alarms - eqpt-holder-ext : other equipment holder alarms - lsmredundancy : lsm redundancy alarms - sync : synce and bits alarms - mcsrc : multicast source alarms - vlanport : vlanport alarms	

name	Type	Description
	- vect-line : xDSL vectoring line alarms - vect-board : xDSL vectoring board alarms - otdr : otdr alarms - sip-dial-plan : sip dial plan related alarms - sip-vsp : sip vsp related alarms - sip-server : sip server related alarms - bgp : bgp related alarms - rip : rip related alarms - lag : LAG related alarms - ihub-general : IHUB general related alarms - vprn : vprn related alarms - isis : isis related alarms - ospf : ospf related alarms - ihub-l2forward : ihub-l2forward alarms - vpls : vpls related alarms - ihub-equip : ihub-equip related alarms - ihub-link : ihub-link related alarms - eont-phyoam : eont phyoam related alarms - ellid : ellid related alarms - epon : epon related alarms - eont-services-lan : eon phyoam related alarms - eolt-ont-tca : eon phyoam related alarms - eont-sw-dl : eon phyoam related alarms - ldp : ldp related alarms - mpls : mpls related alarms - sdp : sdp related alarms - epipe : epipe related alarms - ihub-ipv6 : ihub-ipv6 related alarms - pim : pim related alarms - li : lawful intercept related alarms - mgmt-sec-access : management security related alarms - bfd : bfd related alarms - ai : Application Intelligence related alarms - tr069serv : tr069 server related alarms - ontsnmp : ont snmp related alarms - bulk-sync : bulk-sync related alarms - protection-group : port protection group related alarms - ont : ONT general supplemental related alarms - sfu-sup : SFU ONT general supplemental related alarms - soho-sup : SOHO ONT general supplemental related alarms - mdu-sup : MDU ONT general supplemental related alarms - ont-ani : ONT general supplemental 2 related alarms - sfu-sup2 : SFU ONT general supplemental 2 related alarms - soho-sup2 : SOHO ONT general supplemental 2 related alarms - mdu-sup2 : MDU ONT general supplemental 2 related alarms - sfprssi : SFP RSSI related alarms - eoltrssi : epon olt Sfp RSSI related alarms - cfm : Cfm related alarms - sfpe1t1-framer : SFP 2e1t1 framer alarms - sfpe1t1-clock : SFP 2e1t1 clock alarms - pppcc-engine-tca : PPPOE Cross Connect Engine TCA related alarm - eth-cfm : eth-cfm related alarms - rsvp : rsvp related alarms	

101 query current alarms by filters

name	Type	Description
	- ihub-tca : IHUB TCA related alarms - eth-ring : eth-ring related alarms - efm-oam : EFM-OAM related alarms - ont-loopdetect : ont loop detect related alarms - ont-video : ont services video related alarms - ont-ces : ont services ces related alarms - ont-voip : ont services voip related alarms - ont-video-ani : ont services video ani related alarms - ont-pwe : ont services pwe related alarms - ont-cese1 : ont services cese1 related alarms - ont-xdsl : ont services xdsl related alarms - ont-xdsl-tca : ont services xdsl tca related alarms - ont-hpna : ont hpna related alarms - ont-sip-agent-cfg : ont services voip sip agent config related alarms - ont-voip-cfg : ont services voip config related alarms - ont-mgc : ont mgc related alarms - ont-ploam : ONT PLOAM related alarms - ont-gen : ONT GENERAL related alarms - ont-card : ONT Subscriber Card related alarms - ont-pots : ONT Services POTS related alarms - ont-lan : ONT Services LAN related alarms - ont-moca : ONT MoCA related alarms - ont-tc-tca : ONT TC TCA related alarms - ont-moca-tca : ONT MoCA TCA related alarms - ont-l2uni-eth-tca : ONT L2 UNI Ethernet TCA related alarms - olt-pon-tc-tca : OLT PON TC TCA related alarms - olt-pon-util-tca : OLT PON utilization TCA related alarms - olt-chpr-util-tca : OLT channel-pair utilization TCA related alarms - olt-ont-tc-tca : OLT ONT TC TCA related alarms - ont-tca : ONT TCA related alarms - ont-pots-supplemental : ONT POTS Supplemental related alarms - sfu-ploam : SFU ONT PLOAM related alarms - sfu-gen : SFU ONT general related alarms - soho-ploam : SOHO ONT PLOAM related alarms - soho-gen : SOHO ONT general related alarms - mdu-ploam : MDU ONT PLOAM related alarms - mdu-gen : MDU ONT general related alarms - ont-veip : ONT VEIP related alarms - ont-iphost : ONT IP HOST related alarms - alarm-table : alarm table related alarms - auto-switch : auto-switch related alarms - channel-pair : channel pair related alarms - ont-cfg-dld : ont configure file download related alarms - olt-chpair-tc-tca : OLT CHANNELPAIR TC TCA related alarms - hgu-tr069 : hgu tr069 related alarms - eqpt-psu : equipment psu alarms - ont-protection : ONT protection related alarms - secondary-megaco-term : secondary megaco termination related alarms - secondary-sip-term : secondary sip termination related alarms - cas-r2-channel : CAS R2 channel related alarms	

name	Type	Description
	- lldpmed : lldpmed alarms - pseudo-wire : pseudo Wire related alarms - link-aggr : Link aggregation related alarms - fcs-exceed : FCS auto-recovery related alarms - e1t1-interface : E1/T1 physical interfaces related alarms	
name	Parameter type: <Alarm::alarmTypeEthcfmihub> (eth-cfm-defrdiccm eth-cfm-defmacstatus eth-cfm-defremoteccm eth-cfm-deferrorccm eth-cfm-defxconccm all) Possible values: - eth-cfm-defrdiccm : rdi bit in ccm received - eth-cfm-defmacstatus : ccm mac error status - eth-cfm-defremoteccm : missing ccm from mep - eth-cfm-deferrorccm : invalid ccm received - eth-cfm-defxconccm : unexpected ccm received - all : eth-cfm related alarms	alarm name that are active <i>This element is only shown in detail mode.</i>
severity	Parameter type: <Alarm::AlarmSeverity> (indeterminate warning minor major critical) Possible values: - indeterminate : alarm severity is indeterminate - warning : alarm severity is warning - minor : alarm severity is minor - major : alarm severity is major - critical : alarm severity is critical	the alarms severity level <i>This element is only shown in detail mode.</i>
servaff	Parameter type: <Alarm::alarmServAffect> ((service-affecting yes) (noservice-affecting no)) Possible values: - service-affecting : make this alarm service affecting - yes : make this alarm service affecting - noservice-affecting : make this alarm not service affecting - no : make this alarm not service affecting	alarms affect service or not <i>This element is only shown in detail mode.</i>
time	Parameter type: <Sys::timeInSecs> - the time (yyyy-mm-dd:hour:minutes:secs) - unit: UTC	time in seconds when alarm was updated <i>This element is only shown in detail mode.</i>
descript	Parameter type: <Alarm::AddInfoString> - additional alarm information	alarm description <i>This element is only shown in detail mode.</i>

101.126 show current alarm by filters

Command Description

show current alarms by filters

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm query ont-loopdetect [ (name) [ severity <Alarm::querySeverity> ] [ servaff  
<Alarm::queryServAffect> ] [ ont <Gpon::OntIndex> ] ]
```

Command Parameters

Table 101.126-1 "show current alarm by filters" Resource Parameters

Resource Identifier	Type	Description
(name)	Format: (ont-loopdetect all) Possible values: - ont-loopdetect : ont loop detect - all : ont loop detect related alarms	alarm name of ont-loopdetect
severity	Parameter type: <Alarm::querySeverity> Format: (indeterminate warning minor major critical all) Possible values: - indeterminate : alarm severity is indeterminate - warning : alarm severity is warning - minor : alarm severity is minor - major : alarm severity is major - critical : alarm severity is critical - all : all alarm severity	severity level of an alarm for reporting
servaff	Parameter type: <Alarm::queryServAffect> Format: (service-affecting noservice-affecting all) Possible values: - service-affecting : query alarm service affecting	serviceaffecting no

Resource Identifier	Type	Description
	- noservice-affecting : query alarm not service affecting - all : query service affecting and not affecting alarms	
ont	Parameter type: <Gpon::OntIndex> Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> ng2 : <Ng2::ChannelGroup> / <Ng2::SubchannelGroup> / <Ng2::OntId>) Possible values: - ng2 : ngpon2 style identification Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Ng2::ChannelGroup> - channel group number Field type <Ng2::SubchannelGroup> - subchannel group number Field type <Eqpt::OntId> - the ONT identifier Field type <Ng2::OntId> - the ONT identifier	identifies the ont entry

Command Output

Table 101.126-2 "show current alarm by filters" Display parameters

Specific Information		
name	Type	Description
aidinfo	Parameter type: <Alarm::AddInfoString> - additional alarm information	alarm AID parameters <i>This element is only shown in detail mode.</i>
type	Parameter type: <Alarm::alarmIHUBType> (equipment eqpt-holder plug-in-unit atm custom e1 ima-group ima-link redundancy shdsl ether-itf traffic-overflow qos-queue temporal spatial (software-mngt sw-mgmt) xdsl xdsl-ext xdsl-tca olt-gen	type of the alarms that are active <i>This element is only shown in detail mode.</i>

101 query current alarms by filters

name	Type	Description
	eo-conv	
	authentication	
	bonding	
	sfp	
	shdsl-isam	
	custom-ext-alarm	
	plug-in-unit-ext	
	sip-user-agent	
	sip-plugin-unit	
	sip-termination	
	e1-sip-termination	
	filetransfer	
	external-device	
	l2forward	
	ether-tca	
	ether-sfp	
	megaco-media-gw	
	megaco-sig-gw	
	megaco-plug-unit	
	megaco-term	
	megaco-sig-lt	
	eqpt-supplemental	
	eqpt-holder-ext	
	lsmredundancy	
	sync	
	mcsrc	
	vlanport	
	vect-line	
	vect-board	
	otdr	
	sip-dial-plan	
	sip-vsp	
	sip-server	
	bgp	
	rip	
	lag	
	ihub-general	
	vprn	
	isis	
	ospf	
	ihub-l2forward	
	vpls	
	ihub-equip	
	ihub-link	
	eont-phyoam	
	ellid	
	epon	
	eont-services-lan	
	eolt-ont-tca	
	eont-sw-dl	
	ldp	
	mpls	
	sdp	
	epipe	
	ihub-ipv6	
	pim	
	li	

name	Type	Description
	mgmt-sec-access bfd ai tr069serv ontsnmp bulk-sync protection-group ont sfu-sup soho-sup mdu-sup ont-ani sfu-sup2 soho-sup2 mdu-sup2 sfprssi eoltrssi cfm sfpe1t1-framer sfpe1t1-clock pppcc-engine-tca eth-cfm rsvp ihub-tca eth-ring efm-oam ont-loopdetect ont-video ont-ces ont-voip ont-video-ani ont-pwe ont-cese1 ont-xdsl ont-xdsl-tca ont-hpna ont-sip-agent-cfg ont-voip-cfg ont-mgc ont-ploam ont-gen ont-card ont-pots ont-lan ont-moca ont-tc-tca ont-moca-tca ont-l2uni-eth-tca olt-pon-tc-tca olt-pon-util-tca olt-chpr-util-tca olt-ont-tc-tca ont-tca ont-pots-supplemental sfu-ploam sfu-gen soho-ploam	

101 query current alarms by filters

name	Type	Description
	soho-gen mdu-ploam mdu-gen ont-veip ont-iphost alarm-table auto-switch channel-pair ont-cfg-dld olt-chpair-tc-tca hgu-tr069 eqpt-psu ont-protection secondary-megaco-term secondary-sip-term cas-r2-channel lldpmed pseudo-wire link-agg fcs-exceed e1t1-interface) Possible values: - equipment : equipment alarms - eqpt-holder : equipment holder alarms - plug-in-unit : plugin unit alarms - atm : ATM alarms - custom : customizable alarms - e1 : e1 alarms - ima-group : ima-group alarms - ima-link : ima-link alarms - redundancy : redundancy alarms - shdsl : shdsl alarms - ether-itf : ethernet interface alarms - traffic-overflow : Traffic overflow alarms - qos-queue : qos queue alarms - temporal : temporal alarms - spatial : spatial alarms - software-mngt : software management alarms - sw-mgmt : software management alarms - xdsl : xDSL alarms - xdsl-ext : other xDSL alarms - xdsl-tca : xDSL threshold cross alarms - olt-gen : OLT general alarms - eo-conv : E/O conversion related alarms - authentication : authentication related alarms - bonding : bonding-group related alarms - sfp : SFP related alarms - shdsl-isam : shdsl isam alarms - custom-ext-alarm : customizable external alarms - plug-in-unit-ext : other plugin unit alarms - sip-user-agent : sip user agent related alarms - sip-plugin-unit : sip plug in unit related alarms - sip-termination : sip termination related alarms - e1-sip-termination : E1 sip termination related alarms - filetransfer : file transfer server alarms - external-device : external device related alarms - l2forward : l2forward related alarms	

name	Type	Description
	- ether-tca : ethernet threshold cross alarms - ether-sfp : ethernet SFP related alarms - megaco-media-gw : megaco media gateway related alarms - megaco-sig-gw : megaco signaling gateway related alarms - megaco-plug-unit : megaco plug unit related alarms - megaco-term : megaco termination related alarms - megaco-sig-lt : megaco signaling lt related alarms - eqpt-supplemental : equipment supplemental alarms - eqpt-holder-ext : other equipment holder alarms - lsmredundancy : lsm redundancy alarms - sync : synce and bits alarms - mcsrc : multicast source alarms - vlanport : vlanport alarms - vect-line : xDSL vectoring line alarms - vect-board : xDSL vectoring board alarms - otdr : otdr alarms - sip-dial-plan : sip dial plan related alarms - sip-vsp : sip vsp related alarms - sip-server : sip server related alarms - bgp : bgp related alarms - rip : rip related alarms - lag : LAG related alarms - ihub-general : IHUB general related alarms - vprn : vprn related alarms - isis : isis related alarms - ospf : ospf related alarms - ihub-l2forward : ihub-l2forward alarms - vpls : vpls related alarms - ihub-equip : ihub-equip related alarms - ihub-link : ihub-link related alarms - eont-phyoam : eont phyoam related alarms - ellid : ellid related alarms - epon : epon related alarms - eont-services-lan : eon phyoam related alarms - eolt-ont-tca : eon phyoam related alarms - eont-sw-dl : eon phyoam related alarms - ldp : ldp related alarms - mpls : mpls related alarms - sdp : sdp related alarms - epipe : epipe related alarms - ihub-ipv6 : ihub-ipv6 related alarms - pim : pim related alarms - li : lawful intercept related alarms - mgmt-sec-access : management security related alarms - bfd : bfd related alarms - ai : Application Intelligence related alarms - tr069serv : tr069 server related alarms - ontsnmp : ont snmp related alarms - bulk-sync : bulk-sync related alarms - protection-group : port protection group related alarms - ont : ONT general supplemental related alarms - sfu-sup : SFU ONT general supplemental related alarms - soho-sup : SOHO ONT general supplemental related alarms - mdu-sup : MDU ONT general supplemental related alarms - ont-ani : ONT general supplemental 2 related alarms - sfu-sup2 : SFU ONT general supplemental 2 related alarms	

101 query current alarms by filters

name	Type	Description
	- soho-sup2 : SOHO ONT general supplemental 2 related alarms - mdu-sup2 : MDU ONT general supplemental 2 related alarms - sfrprssi : SFP RSSI related alarms - eoltrssi : epon olt Sfp RSSI related alarms - cfm : Cfm related alarms - sfpe1t1-framer : SFP 2e1t1 framer alarms - sfpe1t1-clock : SFP 2e1t1 clock alarms - pppcc-engine-tca : PPPOE Cross Connect Engine TCA related alarm - eth-cfm : eth-cfm related alarms - rsvp : rsvp related alarms - ihub-tca : IHUB TCA related alarms - eth-ring : eth-ring related alarms - efm-oam : EFM-OAM related alarms - ont-loopdetect : ont loop detect related alarms - ont-video : ont services video related alarms - ont-ces : ont services ces related alarms - ont-voip : ont services voip related alarms - ont-video-ani : ont services video ani related alarms - ont-pwe : ont services pwe related alarms - ont-cese1 : ont services cese1 related alarms - ont-xdsl : ont services xdsl related alarms - ont-xdsl-tca : ont services xdsl tca related alarms - ont-hpna : ont hpna related alarms - ont-sip-agent-cfg : ont services voip sip agent config related alarms - ont-voip-cfg : ont services voip config related alarms - ont-mgc : ont mgc related alarms - ont-ploam : ONT PLOAM related alarms - ont-gen : ONT GENERAL related alarms - ont-card : ONT Subscriber Card related alarms - ont-pots : ONT Services POTS related alarms - ont-lan : ONT Services LAN related alarms - ont-moca : ONT MoCA related alarms - ont-tc-tca : ONT TC TCA related alarms - ont-moca-tca : ONT MoCA TCA related alarms - ont-l2uni-eth-tca : ONT L2 UNI Ethernet TCA related alarms - olt-pon-tc-tca : OLT PON TC TCA related alarms - olt-pon-util-tca : OLT PON utilization TCA related alarms - olt-chpr-util-tca : OLT channel-pair utilization TCA related alarms - olt-ont-tc-tca : OLT ONT TC TCA related alarms - ont-tca : ONT TCA related alarms - ont-pots-supplemental : ONT POTS Supplemental related alarms - sfu-ploam : SFU ONT PLOAM related alarms - sfu-gen : SFU ONT general related alarms - soho-ploam : SOHO ONT PLOAM related alarms - soho-gen : SOHO ONT general related alarms - mdu-ploam : MDU ONT PLOAM related alarms - mdu-gen : MDU ONT general related alarms - ont-veip : ONT VEIP related alarms - ont-iphost : ONT IP HOST related alarms - alarm-table : alarm table related alarms	

name	Type	Description
	- auto-switch : auto-switch related alarms - channel-pair : channel pair related alarms - ont-cfg-dld : ont configure file download related alarms - olt-chpair-tc-tca : OLT CHANNELPAIR TC TCA related alarms - hgu-tr069 : hgu tr069 related alarms - eqpt-psu : equipment psu alarms - ont-protection : ONT protection related alarms - secondary-megaco-term : secondary megaco termination related alarms - secondary-sip-term : secondary sip termination related alarms - cas-r2-channel : CAS R2 channel related alarms - lldpmed : lldpmed alarms - pseudo-wire : pseudo Wire related alarms - link-agg : Link aggregation related alarms - fcs-exceed : FCS auto-recovery related alarms - e1t1-interface : E1/T1 physical interfaces related alarms	
name	Parameter type: <Alarm::alarmTypeOntloopdetectihub> (ont-loopdetect all) Possible values: - ont-loopdetect : ont loop detect - all : ont loop detect related alarms	alarm name that are active <i>This element is only shown in detail mode.</i>
severity	Parameter type: <Alarm::AlarmSeverity> (indeterminate warning minor major critical) Possible values: - indeterminate : alarm severity is indeterminate - warning : alarm severity is warning - minor : alarm severity is minor - major : alarm severity is major - critical : alarm severity is critical	the alarms severity level <i>This element is only shown in detail mode.</i>
servaff	Parameter type: <Alarm::alarmServAffect> ((service-affecting yes) (noservice-affecting no)) Possible values: - service-affecting : make this alarm service affecting - yes : make this alarm service affecting - noservice-affecting : make this alarm not service affecting - no : make this alarm not service affecting	alarms affect service or not <i>This element is only shown in detail mode.</i>
time	Parameter type: <Sys::timeInSecs> - the time (yyyy-mm-dd:hour:minutes:secs) - unit: UTC	time in seconds when alarm was updated <i>This element is only shown in detail mode.</i>
descript	Parameter type: <Alarm::AddInfoString> - additional alarm information	alarm description <i>This element is only shown in detail mode.</i>

101.127 show current alarm by filters

Command Description

show current alarms by filters

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm query rsvp [ (name) [ severity <Alarm::querySeverity> ] [ servaff <Alarm::queryServAffect> ] [
router-id <lhub::baseRouter> ] ]
```

Command Parameters

Table 101.127-1 "show current alarm by filters" Resource Parameters

Resource Identifier	Type	Description
(name)	Format: (rsvp-neighbor-down rsvp-instance-down all) Possible values: - rsvp-neighbor-down : rsvp neighbor down - rsvp-instance-down : rsvp instance down - all : rsvp related alarms	alarm name of rsvp
severity	Parameter type: <Alarm::querySeverity> Format: (indeterminate warning minor major critical all) Possible values: - indeterminate : alarm severity is indeterminate - warning : alarm severity is warning - minor : alarm severity is minor - major : alarm severity is major - critical : alarm severity is critical - all : all alarm severity	severity level of an alarm for reporting
servaff	Parameter type: <Alarm::queryServAffect> Format: (service-affecting noservice-affecting all)	serviceaffecting no

Resource Identifier	Type	Description
	Possible values: - service-affecting : query alarm service affecting - noservice-affecting : query alarm not service affecting - all : query service affecting and not affecting alarms	
router-id	Parameter type: <Ihub::baseRouter> Format: base Possible values: - base : base router	identifies the base router

Command Output

Table 101.127-2 "show current alarm by filters" Display parameters

Specific Information		
name	Type	Description
aidinfo	Parameter type: <Alarm::AddInfoString> - additional alarm information	alarm AID parameters <i>This element is only shown in detail mode.</i>
type	Parameter type: <Alarm::alarmIHUBType> (equipment eqpt-holder plug-in-unit atm custom e1 ima-group ima-link redundancy shdsl ether-itf traffic-overflow qos-queue temporal spatial (software-mngt sw-mgmt) xdsl xdsl-ext xdsl-tca olt-gen eo-conv authentication bonding sfp shdsl-isam custom-ext-alarm plug-in-unit-ext sip-user-agent sip-plugin-unit sip-termination e1-sip-termination filetransfer external-device l2forward ether-tca ether-sfp megaco-media-gw	type of the alarms that are active <i>This element is only shown in detail mode.</i>

101 query current alarms by filters

name	Type	Description
	megaco-sig-gw megaco-plug-unit megaco-term megaco-sig-lt eqpt-supplemental eqpt-holder-ext lsmredundancy sync mcsrc vlanport vect-line vect-board otdr sip-dial-plan sip-vsp sip-server bgp rip lag ihub-general vprn isis ospf ihub-l2forward vpls ihub-equip ihub-link eont-phyoam ellid epon eont-services-lan eolt-ont-tca eont-sw-dl ldp mpls sdp epipe ihub-ipv6 pim li mgmt-sec-access bfd ai tr069serv ontsnmp bulk-sync protection-group ont sfu-sup soho-sup mdu-sup ont-ani sfu-sup2 soho-sup2 mdu-sup2 sfprssi eoltrssi	

name	Type	Description
	cfm	
	sfpe1t1-framer	
	sfpe1t1-clock	
	pppcc-engine-tca	
	eth-cfm	
	rsvp	
	ihub-tca	
	eth-ring	
	efm-oam	
	ont-loopdetect	
	ont-video	
	ont-ces	
	ont-voip	
	ont-video-ani	
	ont-pwe	
	ont-cese1	
	ont-xdsl	
	ont-xdsl-tca	
	ont-hpna	
	ont-sip-agent-cfg	
	ont-voip-cfg	
	ont-mgc	
	ont-ploam	
	ont-gen	
	ont-card	
	ont-pots	
	ont-lan	
	ont-moca	
	ont-tc-tca	
	ont-moca-tca	
	ont-l2uni-eth-tca	
	olt-pon-tc-tca	
	olt-pon-util-tca	
	olt-chpr-util-tca	
	olt-ont-tc-tca	
	ont-tca	
	ont-pots-supplemental	
	sfu-ploam	
	sfu-gen	
	soho-ploam	
	soho-gen	
	mdu-ploam	
	mdu-gen	
	ont-veip	
	ont-iphost	
	alarm-table	
	auto-switch	
	channel-pair	
	ont-cfg-dld	
	olt-chpair-tc-tca	
	hgu-tr069	
	eqpt-psu	
	ont-protection	
	secondary-megaco-term	
	secondary-sip-term	
	cas-r2-channel	
	lldpmed	

101 query current alarms by filters

name	Type	Description
	pseudo-wire link-agg fcs-exceed e1t1-interface) Possible values: - equipment : equipment alarms - eqpt-holder : equipment holder alarms - plug-in-unit : plugin unit alarms - atm : ATM alarms - custom : customizable alarms - e1 : e1 alarms - ima-group : ima-group alarms - ima-link : ima-link alarms - redundancy : redundancy alarms - shdsl : shdsl alarms - ether-itf : ethernet interface alarms - traffic-overflow : Traffic overflow alarms - qos-queue : qos queue alarms - temporal : temporal alarms - spatial : spatial alarms - software-mngt : software management alarms - sw-mgmt : software management alarms - xdsl : xDSL alarms - xdsl-ext : other xDSL alarms - xdsl-tca : xDSL threshold cross alarms - olt-gen : OLT general alarms - eo-conv : E/O conversion related alarms - authentication : authentication related alarms - bonding : bonding-group related alarms - sfp : SFP related alarms - shdsl-isam : shdsl isam alarms - custom-ext-alarm : customizable external alarms - plug-in-unit-ext : other plugin unit alarms - sip-user-agent : sip user agent related alarms - sip-plugin-unit : sip plug in unit related alarms - sip-termination : sip termination related alarms - e1-sip-termination : E1 sip termination related alarms - filetransfer : file transfer server alarms - external-device : external device related alarms - l2forward : l2forward related alarms - ether-tca : ethernet threshold cross alarms - ether-sfp : ethernet SFP related alarms - megaco-media-gw : megaco media gateway related alarms - megaco-sig-gw : megaco signaling gateway related alarms - megaco-plug-unit : megaco plug unit related alarms - megaco-term : megaco termination related alarms - megaco-sig-lt : megaco signaling lt related alarms - eqpt-supplemental : equipment supplemental alarms - eqpt-holder-ext : other equipment holder alarms - lsmredundancy : lsm redundancy alarms - sync : synce and bits alarms - mcsrc : multicast source alarms - vlanport : vlanport alarms - vect-line : xDSL vectoring line alarms - vect-board : xDSL vectoring board alarms - otdr : otdr alarms - sip-dial-plan : sip dial plan related alarms	

name	Type	Description
	- sip-vsp : sip vsp related alarms - sip-server : sip server related alarms - bgp : bgp related alarms - rip : rip related alarms - lag : LAG related alarms - ihub-general : IHUB general related alarms - vprn : vprn related alarms - isis : isis related alarms - ospf : ospf related alarms - ihub-l2forward : ihub-l2forward alarms - vpls : vpls related alarms - ihub-equip : ihub-equip related alarms - ihub-link : ihub-link related alarms - eont-phyoam : eont phyoam related alarms - ellid : ellid related alarms - epon : epon related alarms - eont-services-lan : eon phyoam related alarms - eolt-ont-tca : eon phyoam related alarms - eont-sw-dl : eon phyoam related alarms - ldp : ldp related alarms - mpls : mpls related alarms - sdp : sdp related alarms - epipe : epipe related alarms - ihub-ipv6 : ihub-ipv6 related alarms - pim : pim related alarms - li : lawful intercept related alarms - mgmt-sec-access : management security related alarms - bfd : bfd related alarms - ai : Application Intelligence related alarms - tr069serv : tr069 server related alarms - ontsnmp : ont snmp related alarms - bulk-sync : bulk-sync related alarms - protection-group : port protection group related alarms - ont : ONT general supplemental related alarms - sfu-sup : SFU ONT general supplemental related alarms - soho-sup : SOHO ONT general supplemental related alarms - mdu-sup : MDU ONT general supplemental related alarms - ont-ani : ONT general supplemental 2 related alarms - sfu-sup2 : SFU ONT general supplemental 2 related alarms - soho-sup2 : SOHO ONT general supplemental 2 related alarms - mdu-sup2 : MDU ONT general supplemental 2 related alarms - sfprssi : SFP RSSI related alarms - eoltrssi : epon olt Sfp RSSI related alarms - cfm : Cfm related alarms - sfpe1t1-framer : SFP 2e1t1 framer alarms - sfpe1t1-clock : SFP 2e1t1 clock alarms - pppcc-engine-tca : PPPOE Cross Connect Engine TCA related alarm - eth-cfm : eth-cfm related alarms - rsvp : rsvp related alarms - ihub-tca : IHUB TCA related alarms - eth-ring : eth-ring related alarms - efm-oam : EFM-OAM related alarms - ont-loopdetect : ont loop detect related alarms	

101 query current alarms by filters

name	Type	Description
	- ont-video : ont services video related alarms - ont-ces : ont services ces related alarms - ont-voip : ont services voip related alarms - ont-video-ani : ont services video ani related alarms - ont-pwe : ont services pwe related alarms - ont-cese1 : ont services cese1 related alarms - ont-xdsl : ont services xdsl related alarms - ont-xdsl-tca : ont services xdsl tca related alarms - ont-hpna : ont hpna related alarms - ont-sip-agent-cfg : ont services voip sip agent config related alarms - ont-voip-cfg : ont services voip config related alarms - ont-mgc : ont mgc related alarms - ont-ploam : ONT PLOAM related alarms - ont-gen : ONT GENERAL related alarms - ont-card : ONT Subscriber Card related alarms - ont-pots : ONT Services POTS related alarms - ont-lan : ONT Services LAN related alarms - ont-moca : ONT MoCA related alarms - ont-tc-tca : ONT TC TCA related alarms - ont-moca-tca : ONT MoCA TCA related alarms - ont-l2uni-eth-tca : ONT L2 UNI Ethernet TCA related alarms - olt-pon-tc-tca : OLT PON TC TCA related alarms - olt-pon-util-tca : OLT PON utilization TCA related alarms - olt-chpr-util-tca : OLT channel-pair utilization TCA related alarms - olt-ont-tc-tca : OLT ONT TC TCA related alarms - ont-tca : ONT TCA related alarms - ont-pots-supplemental : ONT POTS Supplemental related alarms - sfu-ploam : SFU ONT PLOAM related alarms - sfu-gen : SFU ONT general related alarms - soho-ploam : SOHO ONT PLOAM related alarms - soho-gen : SOHO ONT general related alarms - mdu-ploam : MDU ONT PLOAM related alarms - mdu-gen : MDU ONT general related alarms - ont-veip : ONT VEIP related alarms - ont-iphost : ONT IP HOST related alarms - alarm-table : alarm table related alarms - auto-switch : auto-switch related alarms - channel-pair : channel pair related alarms - ont-cfg-dld : ont configure file download related alarms - olt-chpair-tc-tca : OLT CHANNELPAIR TC TCA related alarms - hgu-tr069 : hgu tr069 related alarms - eqpt-psu : equipment psu alarms - ont-protection : ONT protection related alarms - secondary-megaco-term : secondary megaco termination related alarms - secondary-sip-term : secondary sip termination related alarms - cas-r2-channel : CAS R2 channel related alarms - lldpmed : lldpmed alarms - pseudo-wire : pseudo Wire related alarms - link-agg : Link aggregation related alarms - fcs-exceed : FCS auto-recovery related alarms	

name	Type	Description
	- e1t1-interface : E1/T1 physical interfaces related alarms	
name	Parameter type: <Alarm::alarmTypeRsvpihub> (rsvp-neighbor-down rsvp-instance-down all) Possible values: - rsvp-neighbor-down : rsvp neighbor down - rsvp-instance-down : rsvp instance down - all : rsvp related alarms	alarm name that are active <i>This element is only shown in detail mode.</i>
severity	Parameter type: <Alarm::AlarmSeverity> (indeterminate warning minor major critical) Possible values: - indeterminate : alarm severity is indeterminate - warning : alarm severity is warning - minor : alarm severity is minor - major : alarm severity is major - critical : alarm severity is critical	the alarms severity level <i>This element is only shown in detail mode.</i>
servaff	Parameter type: <Alarm::alarmServAffect> ((service-affecting yes) (noservice-affecting no)) Possible values: - service-affecting : make this alarm service affecting - yes : make this alarm service affecting - noservice-affecting : make this alarm not service affecting - no : make this alarm not service affecting	alarms affect service or not <i>This element is only shown in detail mode.</i>
time	Parameter type: <Sys::timeInSecs> - the time (yyyy-mm-dd:hour:minutes:secs) - unit: UTC	time in seconds when alarm was updated <i>This element is only shown in detail mode.</i>
descript	Parameter type: <Alarm::AddInfoString> - additional alarm information	alarm description <i>This element is only shown in detail mode.</i>

101.128 show current alarm by filters

Command Description

show current alarms by filters

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm query alarm-table [ (name) [ severity <Alarm::querySeverity> ] [ servaff <Alarm::queryServAffect> ] [ defaultaid <Alarm::queryDefaultAid> ] ]
```

Command Parameters

Table 101.128-1 "show current alarm by filters" Resource Parameters

Resource Identifier	Type	Description
(name)	Format: (alarm-tbl-overflow all) Possible values: - alarm-tbl-overflow : alarm table has overflowed - all : alarm table related alarms	alarm name of alarm-table
severity	Parameter type: <Alarm::querySeverity> Format: (indeterminate warning minor major critical all) Possible values: - indeterminate : alarm severity is indeterminate - warning : alarm severity is warning - minor : alarm severity is minor - major : alarm severity is major - critical : alarm severity is critical - all : all alarm severity	severity level of an alarm for reporting
servaff	Parameter type: <Alarm::queryServAffect> Format: (service-affecting noservice-affecting all) Possible values: - service-affecting : query alarm service affecting	serviceaffecting no

Resource Identifier	Type	Description
	- noservice-affecting : query alarm not service affecting - all : query service affecting and not affecting alarms	
defaultaid	Parameter type: <Alarm::queryDefaultAid> Format: all Possible values: - all : default AID parameter	the default AID param is all

Command Output

Table 101.128-2 "show current alarm by filters" Display parameters

Specific Information		
name	Type	Description
type	Parameter type: <Alarm::alarmIHUBType> (equipment eqpt-holder plug-in-unit atm custom e1 ima-group ima-link redundancy shdsl ether-itf traffic-overflow qos-queue temporal spatial (software-mngt sw-mgmt) xdsl xdsl-ext xdsl-tca olt-gen eo-conv authentication bonding sfp shdsl-isam custom-ext-alarm plug-in-unit-ext sip-user-agent sip-plugin-unit sip-termination e1-sip-termination filetransfer external-device l2forward ether-tca ether-sfp megaco-media-gw megaco-sig-gw megaco-plugin-unit megaco-term megaco-sig-lt eqpt-supplemental	type of the alarms that are active <i>This element is only shown in detail mode.</i>

101 query current alarms by filters

name	Type	Description
	eqpt-holder-ext	
	lsmredundancy	
	sync	
	mcsrc	
	vlanport	
	vect-line	
	vect-board	
	otdr	
	sip-dial-plan	
	sip-vsp	
	sip-server	
	bgp	
	rip	
	lag	
	ihub-general	
	vprn	
	isis	
	ospf	
	ihub-l2forward	
	vpls	
	ihub-equip	
	ihub-link	
	eont-phyoam	
	ellid	
	epon	
	eont-services-lan	
	eolt-ont-tca	
	eont-sw-dl	
	ldp	
	mpls	
	sdp	
	epipe	
	ihub-ipv6	
	pim	
	li	
	mgmt-sec-access	
	bfd	
	ai	
	tr069serv	
	ontsnmp	
	bulk-sync	
	protection-group	
	ont	
	sfu-sup	
	soho-sup	
	mdu-sup	
	ont-ani	
	sfu-sup2	
	soho-sup2	
	mdu-sup2	
	sfprssi	
	eoltrssi	
	cfm	
	sfpe1t1-framer	
	sfpe1t1-clock	
	pppcc-engine-tca	
	eth-cfm	

name	Type	Description
	rsvp ihub-tca eth-ring efm-oam ont-loopdetect ont-video ont-ces ont-voip ont-video-ani ont-pwe ont-cese1 ont-xdsl ont-xdsl-tca ont-hpna ont-sip-agent-cfg ont-voip-cfg ont-mgc ont-ploam ont-gen ont-card ont-pots ont-lan ont-moca ont-tc-tca ont-moca-tca ont-l2uni-eth-tca olt-pon-tc-tca olt-pon-util-tca olt-chpr-util-tca olt-ont-tc-tca ont-tca ont-pots-supplemental sfu-ploam sfu-gen soho-ploam soho-gen mdu-ploam mdu-gen ont-veip ont-iphost alarm-table auto-switch channel-pair ont-cfg-dld olt-chpair-tc-tca hgu-tr069 eqpt-psu ont-protection secondary-megaco-term secondary-sip-term cas-r2-channel lldpmed pseudo-wire link-agg fcs-exceed elt1-interface) Possible values:	

101 query current alarms by filters

name	Type	Description
	- equipment : equipment alarms - eqpt-holder : equipment holder alarms - plug-in-unit : plugin unit alarms - atm : ATM alarms - custom : customizable alarms - e1 : e1 alarms - ima-group : ima-group alarms - ima-link : ima-link alarms - redundancy : redundancy alarms - shdsl : shdsl alarms - ether-itf : ethernet interface alarms - traffic-overflow : Traffic overflow alarms - qos-queue : qos queue alarms - temporal : temporal alarms - spatial : spatial alarms - software-mngt : software management alarms - sw-mgmt : software management alarms - xdsl : xDSL alarms - xdsl-ext : other xDSL alarms - xdsl-tca : xDSL threshold cross alarms - olt-gen : OLT general alarms - eo-conv : E/O conversion related alarms - authentication : authentication related alarms - bonding : bonding-group related alarms - sfp : SFP related alarms - shdsl-isam : shdsl isam alarms - custom-ext-alarm : customizable external alarms - plug-in-unit-ext : other plugin unit alarms - sip-user-agent : sip user agent related alarms - sip-plugin-unit : sip plug in unit related alarms - sip-termination : sip termination related alarms - e1-sip-termination : E1 sip termination related alarms - filetransfer : file transfer server alarms - external-device : external device related alarms - l2forward : l2forward related alarms - ether-tca : ethernet threshold cross alarms - ether-sfp : ethernet SFP related alarms - megaco-media-gw : megaco media gateway related alarms - megaco-sig-gw : megaco signaling gateway related alarms - megaco-plug-unit : megaco plug unit related alarms - megaco-term : megaco termination related alarms - megaco-sig-lt : megaco signaling lt related alarms - eqpt-supplemental : equipment supplemental alarms - eqpt-holder-ext : other equipment holder alarms - lsmredundancy : lsm redundancy alarms - sync : synce and bits alarms - mcsrc : multicast source alarms - vlanport : vlanport alarms - vect-line : xDSL vectoring line alarms - vect-board : xDSL vectoring board alarms - otdr : otdr alarms - sip-dial-plan : sip dial plan related alarms - sip-vsp : sip vsp related alarms - sip-server : sip server related alarms - bgp : bgp related alarms - rip : rip related alarms - lag : LAG related alarms	

name	Type	Description
	- ihub-general : IHUB general related alarms - vprn : vprn related alarms - isis : isis related alarms - ospf : ospf related alarms - ihub-l2forward : ihub-l2forward alarms - vpls : vpls related alarms - ihub-equip : ihub-equip related alarms - ihub-link : ihub-link related alarms - eont-phyoam : eont phyoam related alarms - ellid : ellid related alarms - epon : epon related alarms - eont-services-lan : eon phyoam related alarms - eolt-ont-tca : eon phyoam related alarms - eont-sw-dl : eon phyoam related alarms - ldp : ldp related alarms - mpls : mpls related alarms - sdp : sdp related alarms - epipe : epipe related alarms - ihub-ipv6 : ihub-ipv6 related alarms - pim : pim related alarms - li : lawful intercept related alarms - mgmt-sec-access : management security related alarms - bfd : bfd related alarms - ai : Application Intelligence related alarms - tr069serv : tr069 server related alarms - ontsnmp : ont snmp related alarms - bulk-sync : bulk-sync related alarms - protection-group : port protection group related alarms - ont : ONT general supplemental related alarms - sfu-sup : SFU ONT general supplemental related alarms - soho-sup : SOHO ONT general supplemental related alarms - mdu-sup : MDU ONT general supplemental related alarms - ont-ani : ONT general supplemental 2 related alarms - sfu-sup2 : SFU ONT general supplemental 2 related alarms - soho-sup2 : SOHO ONT general supplemental 2 related alarms - mdu-sup2 : MDU ONT general supplemental 2 related alarms - sfprssi : SFP RSSI related alarms - eoltrssi : epon olt Sfp RSSI related alarms - cfm : Cfm related alarms - sfpe1t1-framer : SFP 2e1t1 framer alarms - sfpe1t1-clock : SFP 2e1t1 clock alarms - pppcc-engine-tca : PPPOE Cross Connect Engine TCA related alarm - eth-cfm : eth-cfm related alarms - rsvp : rsvp related alarms - ihub-tca : IHUB TCA related alarms - eth-ring : eth-ring related alarms - efm-oam : EFM-OAM related alarms - ont-loopdetect : ont loop detect related alarms - ont-video : ont services video related alarms - ont-ces : ont services ces related alarms - ont-voip : ont services voip related alarms - ont-video-ani : ont services video ani related alarms - ont-pwe : ont services pwe related alarms	

101 query current alarms by filters

name	Type	Description
	- ont-cese1 : ont services cese1 related alarms - ont-xdsl : ont services xdsl related alarms - ont-xdsl-tca : ont services xdsl tca related alarms - ont-hpna : ont hpna related alarms - ont-sip-agent-cfg : ont services voip sip agent config related alarms - ont-voip-cfg : ont services voip config related alarms - ont-mgc : ont mgc related alarms - ont-ploam : ONT PLOAM related alarms - ont-gen : ONT GENERAL related alarms - ont-card : ONT Subscriber Card related alarms - ont-pots : ONT Services POTS related alarms - ont-lan : ONT Services LAN related alarms - ont-moca : ONT MoCA related alarms - ont-tc-tca : ONT TC TCA related alarms - ont-moca-tca : ONT MoCA TCA related alarms - ont-l2uni-eth-tca : ONT L2 UNI Ethernet TCA related alarms - olt-pon-tc-tca : OLT PON TC TCA related alarms - olt-pon-util-tca : OLT PON utilization TCA related alarms - olt-chpr-util-tca : OLT channel-pair utilization TCA related alarms - olt-ont-tc-tca : OLT ONT TC TCA related alarms - ont-tca : ONT TCA related alarms - ont-pots-supplemental : ONT POTS Supplemental related alarms - sfu-ploam : SFU ONT PLOAM related alarms - sfu-gen : SFU ONT general related alarms - soho-ploam : SOHO ONT PLOAM related alarms - soho-gen : SOHO ONT general related alarms - mdu-ploam : MDU ONT PLOAM related alarms - mdu-gen : MDU ONT general related alarms - ont-veip : ONT VEIP related alarms - ont-iphost : ONT IP HOST related alarms - alarm-table : alarm table related alarms - auto-switch : auto-switch related alarms - channel-pair : channel pair related alarms - ont-cfg-dld : ont configure file download related alarms - olt-chpair-tc-tca : OLT CHANNELPAIR TC TCA related alarms - hgu-tr069 : hgu tr069 related alarms - eqpt-psu : equipment psu alarms - ont-protection : ONT protection related alarms - secondary-megaco-term : secondary megaco termination related alarms - secondary-sip-term : secondary sip termination related alarms - cas-r2-channel : CAS R2 channel related alarms - lldpmed : lldpmed alarms - pseudo-wire : pseudo Wire related alarms - link-agg : Link aggregation related alarms - fcs-exceed : FCS auto-recovery related alarms - e1t1-interface : E1/T1 physical interfaces related alarms	
name	Parameter type: <Alarm::almtypAlarmtable> (alarm-tbl-overflow all) Possible values:	alarm name that are active <i>This element is only shown in detail mode.</i>

name	Type	Description
	- alrm-tbl-overflow : alarm table has overflowed - all : alarm table related alarms	
severity	Parameter type: <Alarm::AlarmSeverity> (indeterminate warning minor major critical) Possible values: - indeterminate : alarm severity is indeterminate - warning : alarm severity is warning - minor : alarm severity is minor - major : alarm severity is major - critical : alarm severity is critical	the alarms severity level <i>This element is only shown in detail mode.</i>
servaff	Parameter type: <Alarm::alarmServAffect> ((service-affecting yes) (noservice-affecting no)) Possible values: - service-affecting : make this alarm service affecting - yes : make this alarm service affecting - noservice-affecting : make this alarm not service affecting - no : make this alarm not service affecting	alarms affect service or not <i>This element is only shown in detail mode.</i>
time	Parameter type: <Sys::timeInSecs> - the time (yyyy-mm-dd:hour:minutes:secs) - unit: UTC	time in seconds when alarm was updated <i>This element is only shown in detail mode.</i>
descript	Parameter type: <Alarm::AddInfoString> - additional alarm information	alarm description <i>This element is only shown in detail mode.</i>

101.129 show current alarm by filters

Command Description

show current alarms by filters

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm query ihub-tca [ (name) [ severity <Alarm::querySeverity> ] [ servaff <Alarm::queryServAffect> ] [ port <Ihub::EtherPort> ] ]
```

Command Parameters

Table 101.129-1 "show current alarm by filters" Resource Parameters

Resource Identifier	Type	Description
(name)	Format: (tca-outputbw tca-inputbw tca-rxcrcalign tca-txcrcalign tca-txcollisions tca-outputhighbw tca-outputmedbw tca-outputlowbw tca-inputhighbw tca-inputmediumbw tca-inputlowbw all) Possible values: - tca-outputbw : tca output bandwidth - tca-inputbw : tca input bandwidth - tca-rxcrcalign : tca rxcrc align errors - tca-txcrcalign : tca txcrc align errors - tca-txcollisions : tca tx collision errors - tca-outputhighbw : tca output high bandwidth - tca-outputmedbw : tca output medium bandwidth - tca-outputlowbw : tca output low bandwidth - tca-inputhighbw : tca input high bandwidth - tca-inputmediumbw : tca input medium bandwidth - tca-inputlowbw : tca input low bandwidth - all : IHUB TCA related alarms	alarm name of ihub-tca
severity	Parameter type: <Alarm::querySeverity> Format:	severity level of an alarm for reporting

Resource Identifier	Type	Description
	(indeterminate warning minor major critical all) Possible values: - indeterminate : alarm severity is indeterminate - warning : alarm severity is warning - minor : alarm severity is minor - major : alarm severity is major - critical : alarm severity is critical - all : all alarm severity	
servaff	Parameter type: <Alarm::queryServAffect> Format: (service-affecting noservice-affecting all) Possible values: - service-affecting : query alarm service affecting - noservice-affecting : query alarm not service affecting - all : query service affecting and not affecting alarms	serviceaffecting no serviceaffecting
port	Parameter type: <Ihub::EtherPort> Format: (nt-a : sfp : <Alarm::FacePlatePortIndex> nt-a : xfp : <Alarm::FacePlatePortIndex> nt-a : qsfp : <Alarm::FacePlatePortIndex> nt-a : cfp : <Alarm::FacePlatePortIndex> nt-a : eth : <Alarm::FacePlatePortIndex> nt-a : ieee1588 : <Alarm::FacePlatePortIndex> nt-a : ai : <Alarm::FacePlatePortIndex> nt-b : sfp : <Alarm::FacePlatePortIndex> nt-b : xfp : <Alarm::FacePlatePortIndex> nt-b : qsfp : <Alarm::FacePlatePortIndex> nt-b : cfp : <Alarm::FacePlatePortIndex> nt-b : eth : <Alarm::FacePlatePortIndex> nt-b : ieee1588 : <Alarm::FacePlatePortIndex> nt-b : ai : <Alarm::FacePlatePortIndex> ntio-1 : sfp : <Alarm::FacePlatePortIndex> ntio-1 : xfp : <Alarm::FacePlatePortIndex> ntio-1 : qsfp : <Alarm::FacePlatePortIndex> ntio-1 : cfp : <Alarm::FacePlatePortIndex> ntio-2 : sfp : <Alarm::FacePlatePortIndex> ntio-2 : xfp : <Alarm::FacePlatePortIndex> ntio-2 : qsfp : <Alarm::FacePlatePortIndex> ntio-2 : cfp : <Alarm::FacePlatePortIndex> lt : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> nt-a : qsfp : <Alarm::QsfpPortIndex> - <Alarm::LaneIndex> nt-b : qsfp : <Alarm::QsfpPortIndex> - <Alarm::LaneIndex> ntio-1 : qsfp : <Alarm::QsfpPortIndex> - <Alarm::LaneIndex>) Possible values: - nt-a : the nt-a slot - nt-b : the nt-b slot - ntio-1 : an nt applique slot in a single or multiple-ntio-shelf	identifies the ihub port where the alarm has occurred

101 query current alarms by filters

Resource Identifier	Type	Description
	- ntio-2 : an nt applique slot in a multiple-ntio-shelf - lt : the lt slot - nt-a : the nt-a slot - nt-b : the nt-b slot - ntio-1 : the nt-b slot Possible values: - sfp : SFP port - xfp : XFP port - qsfp : QSFP port - cfp : CFP port - eth : RJ45 or lemi port - ieee1588 : IEEE1588 port - ai : AI port Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Alarm::FacePlatePortIndex> - the faceplate port number Field type <Alarm::QsfpPortIndex> - the qsfp port number Field type <Alarm::LaneIndex> - the lane number of qsfp port	

Command Output

Table 101.129-2 "show current alarm by filters" Display parameters

Specific Information		
name	Type	Description
aidinfo	Parameter type: <Alarm::AddInfoString> - additional alarm information	alarm AID parameters <i>This element is only shown in detail mode.</i>
type	Parameter type: <Alarm::alarmIHUBType> (equipment eqpt-holder plug-in-unit atm custom e1 ima-group ima-link redundancy shdsl ether-itf traffic-overflow qos-queue temporal spatial (software-mngt sw-mgmt) xdsl xdsl-ext xdsl-tca olt-gen eo-conv	type of the alarms that are active <i>This element is only shown in detail mode.</i>

name	Type	Description
	authentication	
	bonding	
	sfp	
	shdsl-isam	
	custom-ext-alarm	
	plug-in-unit-ext	
	sip-user-agent	
	sip-plugin-unit	
	sip-termination	
	e1-sip-termination	
	filetransfer	
	external-device	
	l2forward	
	ether-tca	
	ether-sfp	
	megaco-media-gw	
	megaco-sig-gw	
	megaco-plug-unit	
	megaco-term	
	megaco-sig-lt	
	eqpt-supplemental	
	eqpt-holder-ext	
	lsmredundancy	
	sync	
	mcsrc	
	vlanport	
	vect-line	
	vect-board	
	otdr	
	sip-dial-plan	
	sip-vsp	
	sip-server	
	bgp	
	rip	
	lag	
	ihub-general	
	vprn	
	isis	
	ospf	
	ihub-l2forward	
	vpls	
	ihub-equip	
	ihub-link	
	eont-phyoam	
	ellid	
	epon	
	eont-services-lan	
	eolt-ont-tca	
	eont-sw-dl	
	ldp	
	mpls	
	sdp	
	epipe	
	ihub-ipv6	
	pim	
	li	
	mgmt-sec-access	

101 query current alarms by filters

name	Type	Description
	bfd	
	ai	
	tr069serv	
	ontsnmp	
	bulk-sync	
	protection-group	
	ont	
	sfu-sup	
	soho-sup	
	mdu-sup	
	ont-ani	
	sfu-sup2	
	soho-sup2	
	mdu-sup2	
	sfprssi	
	eoltrssi	
	cfm	
	sfpe1t1-framer	
	sfpe1t1-clock	
	pppcc-engine-tca	
	eth-cfm	
	rsvp	
	ihub-tca	
	eth-ring	
	efm-oam	
	ont-loopdetect	
	ont-video	
	ont-ces	
	ont-voip	
	ont-video-ani	
	ont-pwe	
	ont-cese1	
	ont-xdsl	
	ont-xdsl-tca	
	ont-hpna	
	ont-sip-agent-cfg	
	ont-voip-cfg	
	ont-mgc	
	ont-ploam	
	ont-gen	
	ont-card	
	ont-pots	
	ont-lan	
	ont-moca	
	ont-tc-tca	
	ont-moca-tca	
	ont-l2uni-eth-tca	
	olt-pon-tc-tca	
	olt-pon-util-tca	
	olt-chpr-util-tca	
	olt-ont-tc-tca	
	ont-tca	
	ont-pots-supplemental	
	sfu-ploam	
	sfu-gen	
	soho-ploam	
	soho-gen	

name	Type	Description
	mdu-ploam mdu-gen ont-veip ont-iphost alarm-table auto-switch channel-pair ont-cfg-dld olt-chpair-tc-tca hgu-tr069 eqpt-psu ont-protection secondary-megaco-term secondary-sip-term cas-r2-channel lldpmed pseudo-wire link-agg fcs-exceed e1t1-interface) Possible values: - equipment : equipment alarms - eqpt-holder : equipment holder alarms - plug-in-unit : plugin unit alarms - atm : ATM alarms - custom : customizable alarms - e1 : e1 alarms - ima-group : ima-group alarms - ima-link : ima-link alarms - redundancy : redundancy alarms - shdsl : shdsl alarms - ether-itf : ethernet interface alarms - traffic-overflow : Traffic overflow alarms - qos-queue : qos queue alarms - temporal : temporal alarms - spatial : spatial alarms - software-mngt : software management alarms - sw-mgmt : software management alarms - xdsl : xDSL alarms - xdsl-ext : other xDSL alarms - xdsl-tca : xDSL threshold cross alarms - olt-gen : OLT general alarms - eo-conv : E/O conversion related alarms - authentication : authentication related alarms - bonding : bonding-group related alarms - sfp : SFP related alarms - shdsl-isam : shdsl isam alarms - custom-ext-alarm : customizable external alarms - plug-in-unit-ext : other plugin unit alarms - sip-user-agent : sip user agent related alarms - sip-plugin-unit : sip plug in unit related alarms - sip-termination : sip termination related alarms - e1-sip-termination : E1 sip termination related alarms - filetransfer : file transfer server alarms - external-device : external device related alarms - l2forward : l2forward related alarms - ether-tca : ethernet threshold cross alarms	

101 query current alarms by filters

name	Type	Description
	- ether-sfp : ethernet SFP related alarms - megaco-media-gw : megaco media gateway related alarms - megaco-sig-gw : megaco signaling gateway related alarms - megaco-plug-unit : megaco plug unit related alarms - megaco-term : megaco termination related alarms - megaco-sig-lt : megaco signaling lt related alarms - eqpt-supplemental : equipment supplemental alarms - eqpt-holder-ext : other equipment holder alarms - lsmredundancy : lsm redundancy alarms - sync : synce and bits alarms - mcsrc : multicast source alarms - vlanport : vlanport alarms - vect-line : xDSL vectoring line alarms - vect-board : xDSL vectoring board alarms - otdr : otdr alarms - sip-dial-plan : sip dial plan related alarms - sip-vsp : sip vsp related alarms - sip-server : sip server related alarms - bgp : bgp related alarms - rip : rip related alarms - lag : LAG related alarms - ihub-general : IHUB general related alarms - vprn : vprn related alarms - isis : isis related alarms - ospf : ospf related alarms - ihub-l2forward : ihub-l2forward alarms - vpls : vpls related alarms - ihub-equip : ihub-equip related alarms - ihub-link : ihub-link related alarms - eont-phyoam : eont phyoam related alarms - ellid : ellid related alarms - epon : epon related alarms - eont-services-lan : eon phyoam related alarms - eolt-ont-tca : eon phyoam related alarms - eont-sw-dl : eon phyoam related alarms - ldp : ldp related alarms - mpls : mpls related alarms - sdp : sdp related alarms - epipe : epipe related alarms - ihub-ipv6 : ihub-ipv6 related alarms - pim : pim related alarms - li : lawful intercept related alarms - mgmt-sec-access : management security related alarms - bfd : bfd related alarms - ai : Application Intelligence related alarms - tr069serv : tr069 server related alarms - ontsnmp : ont snmp related alarms - bulk-sync : bulk-sync related alarms - protection-group : port protection group related alarms - ont : ONT general supplemental related alarms - sfu-sup : SFU ONT general supplemental related alarms - soho-sup : SOHO ONT general supplemental related alarms - mdu-sup : MDU ONT general supplemental related alarms - ont-ani : ONT general supplemental 2 related alarms - sfu-sup2 : SFU ONT general supplemental 2 related alarms - soho-sup2 : SOHO ONT general supplemental 2 related	

name	Type	Description
	alarms - mdu-sup2 : MDU ONT general supplemental 2 related alarms - sfrssi : SFP RSSI related alarms - eoltrssi : epon olt Sfp RSSI related alarms - cfm : Cfm related alarms - sfpe1t1-framer : SFP 2e1t1 framer alarms - sfpe1t1-clock : SFP 2e1t1 clock alarms - pppcc-engine-tca : PPPOE Cross Connect Engine TCA related alarm - eth-cfm : eth-cfm related alarms - rsvp : rsvp related alarms - ihub-tca : IHUB TCA related alarms - eth-ring : eth-ring related alarms - efm-oam : EFM-OAM related alarms - ont-loopdetect : ont loop detect related alarms - ont-video : ont services video related alarms - ont-ces : ont services ces related alarms - ont-voip : ont services voip related alarms - ont-video-ani : ont services video ani related alarms - ont-pwe : ont services pwe related alarms - ont-cese1 : ont services cese1 related alarms - ont-xdsl : ont services xdsl related alarms - ont-xdsl-tca : ont services xdsl tca related alarms - ont-hpna : ont hpna related alarms - ont-sip-agent-cfg : ont services voip sip agent config related alarms - ont-voip-cfg : ont services voip config related alarms - ont-mgc : ont mgc related alarms - ont-ploam : ONT PLOAM related alarms - ont-gen : ONT GENERAL related alarms - ont-card : ONT Subscriber Card related alarms - ont-pots : ONT Services POTS related alarms - ont-lan : ONT Services LAN related alarms - ont-moca : ONT MoCA related alarms - ont-tc-tca : ONT TC TCA related alarms - ont-moca-tca : ONT MoCA TCA related alarms - ont-l2uni-eth-tca : ONT L2 UNI Ethernet TCA related alarms - olt-pon-tc-tca : OLT PON TC TCA related alarms - olt-pon-util-tca : OLT PON utilization TCA related alarms - olt-chpr-util-tca : OLT channel-pair utilization TCA related alarms - olt-ont-tc-tca : OLT ONT TC TCA related alarms - ont-tca : ONT TCA related alarms - ont-pots-supplemental : ONT POTS Supplemental related alarms - sfu-ploam : SFU ONT PLOAM related alarms - sfu-gen : SFU ONT general related alarms - soho-ploam : SOHO ONT PLOAM related alarms - soho-gen : SOHO ONT general related alarms - mdu-ploam : MDU ONT PLOAM related alarms - mdu-gen : MDU ONT general related alarms - ont-veip : ONT VEIP related alarms - ont-iphost : ONT IP HOST related alarms - alarm-table : alarm table related alarms - auto-switch : auto-switch related alarms	

101 query current alarms by filters

name	Type	Description
	- channel-pair : channel pair related alarms - ont-cfg-dld : ont configure file download related alarms - olt-chpair-tc-tca : OLT CHANNELPAIR TC TCA related alarms - hgu-tr069 : hgu tr069 related alarms - eqpt-psu : equipment psu alarms - ont-protection : ONT protection related alarms - secondary-megaco-term : secondary megaco termination related alarms - secondary-sip-term : secondary sip termination related alarms - cas-r2-channel : CAS R2 channel related alarms - lldpmed : lldpmed alarms - pseudo-wire : pseudo Wire related alarms - link-agg : Link aggregation related alarms - fcs-exceed : FCS auto-recovery related alarms - e1t1-interface : E1/T1 physical interfaces related alarms	
name	Parameter type: <Alarm::almtypeIhubtca> (tca-outputbw tca-inputbw tca-rxcrcalign tca-txcrcalign tca-txcollisions tca-outputhighbw tca-outputmedbw tca-outputlowbw tca-inputhighbw tca-inputmediumbw tca-inputlowbw all) Possible values: - tca-outputbw : tca output bandwidth - tca-inputbw : tca input bandwidth - tca-rxcrcalign : tca rxrc align errors - tca-txcrcalign : tca txrc align errors - tca-txcollisions : tca tx collision errors - tca-outputhighbw : tca output high bandwidth - tca-outputmedbw : tca output medium bandwidth - tca-outputlowbw : tca output low bandwidth - tca-inputhighbw : tca input high bandwidth - tca-inputmediumbw : tca input medium bandwidth - tca-inputlowbw : tca input low bandwidth - all : IHUB TCA related alarms	alarm name that are active <i>This element is only shown in detail mode.</i>
severity	Parameter type: <Alarm::AlarmSeverity> (indeterminate warning minor major critical) Possible values: - indeterminate : alarm severity is indeterminate - warning : alarm severity is warning - minor : alarm severity is minor - major : alarm severity is major - critical : alarm severity is critical	the alarms severity level <i>This element is only shown in detail mode.</i>
servaff	Parameter type: <Alarm::alarmServAffect> ((service-affecting yes)	alarms affect service or not <i>This element is only shown in</i>

name	Type	Description
	(noservice-affecting no)) Possible values: - service-affecting : make this alarm service affecting - yes : make this alarm service affecting - noservice-affecting : make this alarm not service affecting - no : make this alarm not service affecting	<i>detail mode.</i>
time	Parameter type: <Sys::timeInSecs> - the time (yyyy-mm-dd:hour:minutes:secs) - unit: UTC	time in seconds when alarm was updated <i>This element is only shown in detail mode.</i>
descript	Parameter type: <Alarm::AddInfoString> - additional alarm information	alarm description <i>This element is only shown in detail mode.</i>

101.130 show current alarm by filters

Command Description

show current alarms by filters

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm query sfu-sup [ (name) [ severity <Alarm::querySeverity> ] [ servaff <Alarm::queryServAffect> ] [ ont <Gpon::OntIndex> ] ]
```

Command Parameters

Table 101.130-1 "show current alarm by filters" Resource Parameters

Resource Identifier	Type	Description
(name)	Format: (sfu-sup-sw-file-error sfu-sup-fan-failure sfu-sup-temp-high-warn sfu-sup-temp-shutoff sfu-sup-emergency-call sfu-sup-swverctrl-err sfu-sup-poe-exceed-max sfu-sup-poe-over-yell sfu-opti-malfunc sfu-sup-cfg-dnld-fail sfu-sup-rssi-cfg-mism sfu-sup-sfp-tx-low sfu-sup-sfp-temp-high sfu-sup-sfp-volt-high sfu-sup-sfp-bias-high sfu-sup-ld-cfg-mism sfu-sup-olt-rx-low sfu-sup-olt-rx-high sfu-sup-olt-rx-lo-warn sfu-sup-olt-rx-hi-warn sfu-sup-tod-out-sync sfu-sup-ont-tune-fail sfu-tr069-parm-fail sfu-sup-tod-mismatch all) Possible values: - sfu-sup-sw-file-error : SFU ONT - Software file has error	alarm name of sfu-sup

Resource Identifier	Type	Description
	or is missing - sfu-sup-fan-failure : SFU ONT - Fan failure - sfu-sup-temp-high-warn: SFU ONT - High temperature warning - sfu-sup-temp-shutoff : SFU ONT - Service disabled due to excessive temperature - sfu-sup-emergency-call: SFU ONT - Emergency call active - sfu-sup-swverctrl-err : SFU ONT - Software version control error - sfu-sup-poe-exceed-max: SFU ONT - Configured PoE feeding exceeds ONT maximum - sfu-sup-poe-over-yell : SFU ONT - ONU is nearing its maximum ability to supply the power - sfu-opti-malfunc : SFU ONT - Malfunction of ONT's optical transceiver - sfu-sup-cfg-dnld-fail : SFU ONT - Download of voice xml file to ONT failed - sfu-sup-rssi-cfg-mism : SFU ONT - RSSI configuration mismatch - sfu-sup-sfp-tx-low : SFU ONT - SFP Tx Power below configured low-level alarm threshold - sfu-sup-sfp-temp-high : SFU ONT - SFP Temperature above configured high-level alarm threshold - sfu-sup-sfp-volt-high : SFU ONT - SFP Voltage above configured high-level alarm threshold - sfu-sup-sfp-bias-high : SFU ONT - SFP Bias above configured high-level alarm threshold - sfu-sup-ld-cfg-mism : SFU ONT - Loop detection configuration mismatch - sfu-sup-olt-rx-low : SFU ONT - OLT Rx power below receiver operating range - sfu-sup-olt-rx-high : SFU ONT - OLT Rx power above receiver operating range - sfu-sup-olt-rx-lo-warn: SFU ONT - OLT Rx power below low-level warning threshold - sfu-sup-olt-rx-hi-warn: SFU ONT - OLT Rx power above high-level warning threshold - sfu-sup-tod-out-sync : SFU ONT - ONU TOD is out-sync with OLT - sfu-sup-ont-tune-fail : SFU ONT - ONU has failed to tune to Target-ChnlPair - sfu-tr069-param-fail : SFU ONT - hgu tr069 parameters mismatch - sfu-sup-tod-mismatch : SFU ONT - ONU TOD MISMATCH - all : SFU ONT general supplemental related alarms	
severity	Parameter type: <Alarm::querySeverity> Format: (indeterminate warning minor major critical all) Possible values: - indeterminate : alarm severity is indeterminate - warning : alarm severity is warning	severity level of an alarm for reporting

101 query current alarms by filters

Resource Identifier	Type	Description
	- minor : alarm severity is minor - major : alarm severity is major - critical : alarm severity is critical - all : all alarm severity	
servaff	Parameter type: <Alarm::queryServAffect> Format: (service-affecting noservice-affecting all) Possible values: - service-affecting : query alarm service affecting - noservice-affecting : query alarm not service affecting - all : query service affecting and not affecting alarms	serviceaffecting no serviceaffecting
ont	Parameter type: <Gpon::OntIndex> Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> ng2 : <Ng2::ChannelGroup> / <Ng2::SubchannelGroup> / <Ng2::OntId>) Possible values: - ng2 : ngpon2 style identification Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Ng2::ChannelGroup> - channel group number Field type <Ng2::SubchannelGroup> - subchannel group number Field type <Eqpt::OntId> - the ONT identifier Field type <Ng2::OntId> - the ONT identifier	identifies the ont entry

Command Output

Table 101.130-2 "show current alarm by filters" Display parameters

Specific Information		
name	Type	Description
aidinfo	Parameter type: <Alarm::AddInfoString> - additional alarm information	alarm AID parameters <i>This element is only shown in detail mode.</i>
type	Parameter type: <Alarm::alarmIHUBType> (equipment eqpt-holder plug-in-unit atm custom e1 ima-group ima-link redundancy	type of the alarms that are active <i>This element is only shown in detail mode.</i>

name	Type	Description
	shdsl	
	ether-itf	
	traffic-overflow	
	qos-queue	
	temporal	
	spatial	
	(software-mngt sw-mgmt)	
	xdsl	
	xdsl-ext	
	xdsl-tca	
	olt-gen	
	eo-conv	
	authentication	
	bonding	
	sfp	
	shdsl-isam	
	custom-ext-alarm	
	plug-in-unit-ext	
	sip-user-agent	
	sip-plugin-unit	
	sip-termination	
	e1-sip-termination	
	filetransfer	
	external-device	
	l2forward	
	ether-tca	
	ether-sfp	
	megaco-media-gw	
	megaco-sig-gw	
	megaco-plug-unit	
	megaco-term	
	megaco-sig-lt	
	eqpt-supplemental	
	eqpt-holder-ext	
	lsmredundancy	
	sync	
	mcsrc	
	vlanport	
	vect-line	
	vect-board	
	otdr	
	sip-dial-plan	
	sip-vsp	
	sip-server	
	bgp	
	rip	
	lag	
	ihub-general	
	vprn	
	isis	
	ospf	
	ihub-l2forward	
	vpls	
	ihub-equip	
	ihub-link	
	eont-phyoam	
	ellid	

101 query current alarms by filters

name	Type	Description
	epon eont-services-lan eolt-ont-tca eont-sw-dl ldp mpls sdp epipe ihub-ipv6 pim li mgmt-sec-access bfd ai tr069serv ontsnmp bulk-sync protection-group ont sfu-sup soho-sup mdu-sup ont-ani sfu-sup2 soho-sup2 mdu-sup2 sfprssi eoltrssi cfm sfpe1t1-framer sfpe1t1-clock pppcc-engine-tca eth-cfm rsvp ihub-tca eth-ring efm-oam ont-loopdetect ont-video ont-ces ont-voip ont-video-ani ont-pwe ont-cese1 ont-xdsl ont-xdsl-tca ont-hpna ont-sip-agent-cfg ont-voip-cfg ont-mgc ont-ploam ont-gen ont-card ont-pots ont-lan ont-moca ont-tc-tca	

name	Type	Description
	ont-moca-tca ont-l2uni-eth-tca olt-pon-tc-tca olt-pon-util-tca olt-chpr-util-tca olt-ont-tc-tca ont-tca ont-pots-supplemental sfu-ploam sfu-gen soho-ploam soho-gen mdu-ploam mdu-gen ont-veip ont-iphost alarm-table auto-switch channel-pair ont-cfg-dld olt-chpair-tc-tca hgu-tr069 eqpt-psu ont-protection secondary-megaco-term secondary-sip-term cas-r2-channel lldpmed pseudo-wire link-agg fcs-exceed e1t1-interface) Possible values: - equipment : equipment alarms - eqpt-holder : equipment holder alarms - plug-in-unit : plugin unit alarms - atm : ATM alarms - custom : customizable alarms - e1 : e1 alarms - ima-group : ima-group alarms - ima-link : ima-link alarms - redundancy : redundancy alarms - shdsl : shdsl alarms - ether-itf : ethernet interface alarms - traffic-overflow : Traffic overflow alarms - qos-queue : qos queue alarms - temporal : temporal alarms - spatial : spatial alarms - software-mngt : software management alarms - sw-mgmt : software management alarms - xdsl : xDSL alarms - xdsl-ext : other xDSL alarms - xdsl-tca : xDSL threshold cross alarms - olt-gen : OLT general alarms - eo-conv : E/O conversion related alarms - authentication : authentication related alarms - bonding : bonding-group related alarms	

101 query current alarms by filters

name	Type	Description
	- sfp : SFP related alarms - shdsl-isam : shdsl isam alarms - custom-ext-alarm : customizable external alarms - plug-in-unit-ext : other plugin unit alarms - sip-user-agent : sip user agent related alarms - sip-plugin-unit : sip plug in unit related alarms - sip-termination : sip termination related alarms - e1-sip-termination : E1 sip termination related alarms - filetransfer : file transfer server alarms - external-device : external device related alarms - l2forward : l2forward related alarms - ether-tca : ethernet threshold cross alarms - ether-sfp : ethernet SFP related alarms - megaco-media-gw : megaco media gateway related alarms - megaco-sig-gw : megaco signaling gateway related alarms - megaco-plug-unit : megaco plug unit related alarms - megaco-term : megaco termination related alarms - megaco-sig-lt : megaco signaling lt related alarms - eqpt-supplemental : equipment supplemental alarms - eqpt-holder-ext : other equipment holder alarms - lsmredundancy : lsm redundancy alarms - sync : synce and bits alarms - mcsrc : multicast source alarms - vlanport : vlanport alarms - vect-line : xDSL vectoring line alarms - vect-board : xDSL vectoring board alarms - otdr : otdr alarms - sip-dial-plan : sip dial plan related alarms - sip-vsp : sip vsp related alarms - sip-server : sip server related alarms - bgp : bgp related alarms - rip : rip related alarms - lag : LAG related alarms - ihub-general : IHUB general related alarms - vprn : vprn related alarms - isis : isis related alarms - ospf : ospf related alarms - ihub-l2forward : ihub-l2forward alarms - vpls : vpls related alarms - ihub-equip : ihub-equip related alarms - ihub-link : ihub-link related alarms - eont-phyoam : eont phyoam related alarms - ellid : ellid related alarms - epon : epon related alarms - eont-services-lan : eon phyoam related alarms - eolt-ont-tca : eon phyoam related alarms - eont-sw-dl : eon phyoam related alarms - ldp : ldp related alarms - mpls : mpls related alarms - sdp : sdp related alarms - epipe : epipe related alarms - ihub-ipv6 : ihub-ipv6 related alarms - pim : pim related alarms - li : lawful intercept related alarms - mgmt-sec-access : management security related alarms - bfd : bfd related alarms - ai : Application Intelligence related alarms	

name	Type	Description
	- tr069serv : tr069 server related alarms - ontsnmp : ont snmp related alarms - bulk-sync : bulk-sync related alarms - protection-group : port protection group related alarms - ont : ONT general supplemental related alarms - sfu-sup : SFU ONT general supplemental related alarms - soho-sup : SOHO ONT general supplemental related alarms - mdu-sup : MDU ONT general supplemental related alarms - ont-ani : ONT general supplemental 2 related alarms - sfu-sup2 : SFU ONT general supplemental 2 related alarms - soho-sup2 : SOHO ONT general supplemental 2 related alarms - mdu-sup2 : MDU ONT general supplemental 2 related alarms - sfrssi : SFP RSSI related alarms - eoltrssi : epon olt Sfp RSSI related alarms - cfm : Cfm related alarms - sfpe1t1-framer : SFP 2e1t1 framer alarms - sfpe1t1-clock : SFP 2e1t1 clock alarms - pppcc-engine-tca : PPPOE Cross Connect Engine TCA related alarm - eth-cfm : eth-cfm related alarms - rsvp : rsvp related alarms - ihub-tca : IHUB TCA related alarms - eth-ring : eth-ring related alarms - efm-oam : EFM-OAM related alarms - ont-loopdetect : ont loop detect related alarms - ont-video : ont services video related alarms - ont-ces : ont services ces related alarms - ont-voip : ont services voip related alarms - ont-video-ani : ont services video ani related alarms - ont-pwe : ont services pwe related alarms - ont-cese1 : ont services cese1 related alarms - ont-xdsl : ont services xdsl related alarms - ont-xdsl-tca : ont services xdsl tca related alarms - ont-hpna : ont hpna related alarms - ont-sip-agent-cfg : ont services voip sip agent config related alarms - ont-voip-cfg : ont services voip config related alarms - ont-mgc : ont mgc related alarms - ont-ploam : ONT PLOAM related alarms - ont-gen : ONT GENERAL related alarms - ont-card : ONT Subscriber Card related alarms - ont-pots : ONT Services POTS related alarms - ont-lan : ONT Services LAN related alarms - ont-moca : ONT MoCA related alarms - ont-tc-tca : ONT TC TCA related alarms - ont-moca-tca : ONT MoCA TCA related alarms - ont-l2uni-eth-tca : ONT L2 UNI Ethernet TCA related alarms - olt-pon-tc-tca : OLT PON TC TCA related alarms - olt-pon-util-tca : OLT PON utilization TCA related alarms - olt-chpr-util-tca : OLT channel-pair utilization TCA related alarms - olt-ont-tc-tca : OLT ONT TC TCA related alarms - ont-tca : ONT TCA related alarms	

101 query current alarms by filters

name	Type	Description
	- ont-pots-supplemental : ONT POTS Supplemental related alarms - sfu-ploam : SFU ONT PLOAM related alarms - sfu-gen : SFU ONT general related alarms - soho-ploam : SOHO ONT PLOAM related alarms - soho-gen : SOHO ONT general related alarms - mdu-ploam : MDU ONT PLOAM related alarms - mdu-gen : MDU ONT general related alarms - ont-veip : ONT VEIP related alarms - ont-iphost : ONT IP HOST related alarms - alarm-table : alarm table related alarms - auto-switch : auto-switch related alarms - channel-pair : channel pair related alarms - ont-cfg-dld : ont configure file download related alarms - olt-chpair-tc-tca : OLT CHANNELPAIR TC TCA related alarms - hgu-tr069 : hgu tr069 related alarms - eqpt-psu : equipment psu alarms - ont-protection : ONT protection related alarms - secondary-megaco-term : secondary megaco termination related alarms - secondary-sip-term : secondary sip termination related alarms - cas-r2-channel : CAS R2 channel related alarms - lldpmed : lldpmed alarms - pseudo-wire : pseudo Wire related alarms - link-aggr : Link aggregation related alarms - fcs-exceed : FCS auto-recovery related alarms - e1t1-interface : E1/T1 physical interfaces related alarms	
name	Parameter type: <Alarm::almtypeSfusupihub> (sfu-sup-sw-file-error sfu-sup-fan-failure sfu-sup-temp-high-warn sfu-sup-temp-shutoff sfu-sup-emergency-call sfu-sup-swverctrl-err sfu-sup-poe-exceed-max sfu-sup-poe-over-yell sfu-opti-malfunc sfu-sup-cfg-dnld-fail sfu-sup-rssi-cfg-mism sfu-sup-sfp-tx-low sfu-sup-sfp-temp-high sfu-sup-sfp-volt-high sfu-sup-sfp-bias-high sfu-sup-ld-cfg-mism sfu-sup-olt-rx-low sfu-sup-olt-rx-high sfu-sup-olt-rx-lo-warn sfu-sup-olt-rx-hi-warn sfu-sup-tod-out-sync sfu-sup-ont-tune-fail sfu-tr069-param-fail sfu-sup-tod-mismatch all) Possible values: - sfu-sup-sw-file-error : SFU ONT - Software file has error	alarm name that are active <i>This element is only shown in detail mode.</i>

name	Type	Description
	or is missing - sfu-sup-fan-failure : SFU ONT - Fan failure - sfu-sup-temp-high-warn: SFU ONT - High temperature warning - sfu-sup-temp-shutoff : SFU ONT - Service disabled due to excessive temperature - sfu-sup-emergency-call: SFU ONT - Emergency call active - sfu-sup-swverctrl-err : SFU ONT - Software version control error - sfu-sup-poe-exceed-max: SFU ONT - Configured PoE feeding exceeds ONT maximum - sfu-sup-poe-over-yell : SFU ONT - ONU is nearing its maximum ability to supply the power - sfu-opti-malfunc : SFU ONT - Malfunction of ONT's optical transceiver - sfu-sup-cfg-dnld-fail : SFU ONT - Download of voice xml file to ONT failed - sfu-sup-rssi-cfg-mism : SFU ONT - RSSI configuration mismatch - sfu-sup-sfp-tx-low : SFU ONT - SFP Tx Power below configured low-level alarm threshold - sfu-sup-sfp-temp-high : SFU ONT - SFP Temperature above configured high-level alarm threshold - sfu-sup-sfp-volt-high : SFU ONT - SFP Voltage above configured high-level alarm threshold - sfu-sup-sfp-bias-high : SFU ONT - SFP Bias above configured high-level alarm threshold - sfu-sup-ld-cfg-mism : SFU ONT - Loop detection configuration mismatch - sfu-sup-olt-rx-low : SFU ONT - OLT Rx power below receiver operating range - sfu-sup-olt-rx-high : SFU ONT - OLT Rx power above receiver operating range - sfu-sup-olt-rx-lo-warn: SFU ONT - OLT Rx power below low-level warning threshold - sfu-sup-olt-rx-hi-warn: SFU ONT - OLT Rx power above high-level warning threshold - sfu-sup-tod-out-sync : SFU ONT - ONU TOD is out-sync with OLT - sfu-sup-ont-tune-fail : SFU ONT - ONU has failed to tune to Target-ChnlPair - sfu-tr069-param-fail : SFU ONT - hgu tr069 parameters mismatch - sfu-sup-tod-mismatch : SFU ONT - ONU TOD MISMATCH - all : SFU ONT general supplemental related alarms	
severity	Parameter type: <Alarm::AlarmSeverity> (indeterminate warning minor major critical) Possible values: - indeterminate : alarm severity is indeterminate - warning : alarm severity is warning - minor : alarm severity is minor - major : alarm severity is major	the alarms severity level <i>This element is only shown in detail mode.</i>

101 query current alarms by filters

name	Type	Description
	- critical : alarm severity is critical	
servaff	Parameter type: <Alarm::alarmServAffect> ((service-affecting yes) (noservice-affecting no)) Possible values: - service-affecting : make this alarm service affecting - yes : make this alarm service affecting - noservice-affecting : make this alarm not service affecting - no : make this alarm not service affecting	alarms affect service or not <i>This element is only shown in detail mode.</i>
time	Parameter type: <Sys::timeInSecs> - the time (yyyy-mm-dd:hour:minutes:secs) - unit: UTC	time in seconds when alarm was updated <i>This element is only shown in detail mode.</i>
descript	Parameter type: <Alarm::AddInfoString> - additional alarm information	alarm description <i>This element is only shown in detail mode.</i>

101.131 show current alarm by filters

Command Description

show current alarms by filters

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm query soho-sup [ (name) [ severity <Alarm::querySeverity> ] [ servaff <Alarm::queryServAffect> ] [
ont <Gpon::OntIndex> ] ]
```

Command Parameters

Table 101.131-1 "show current alarm by filters" Resource Parameters

Resource Identifier	Type	Description
(name)	Format: (soho-sup-sw-file-error soho-sup-fan-failure soho-sup-temp-high-war soho-sup-temp-shutoff soho-sup-emergency-cal soho-sup-swverctrl-err soho-sup-poe-exceed-ma soho-sup-poe-over-yell soho-opti-malfunc soho-sup-cfg-dnld-fail soho-sup-rssi-cfg-mism soho-sup-sfp-tx-low soho-sup-sfp-temp-high soho-sup-sfp-volt-high soho-sup-sfp-bias-high soho-sup-ld-cfg-mism soho-sup-olt-rx-low soho-sup-olt-rx-high soho-sup-olt-rx-lo-war soho-sup-olt-rx-hi-war soho-sup-tod-out-sync soho-sup-ont-tune-fail soho-tr069-parm-fail soho-sup-tod-mismatch all) Possible values: - soho-sup-sw-file-error: SOHO ONT - Software file has	alarm name of soho-sup

101 query current alarms by filters

Resource Identifier	Type	Description
	error or is missing - soho-sup-fan-failure : SOHO ONT - Fan failure - soho-sup-temp-high-war: SOHO ONT - High temperature warning - soho-sup-temp-shutoff : SOHO ONT - Service disabled due to excessive temperature - soho-sup-emergency-cal: SOHO ONT - Emergency call active - soho-sup-swverctrl-err: SOHO ONT - Software version control error - soho-sup-poe-exceed-ma: SOHO ONT - Configured PoE feeding exceeds ONT maximum - soho-sup-poe-over-yell: SOHO ONT - ONU is nearing its maximum ability to supply the power - soho-opti-malfunc : SOHO ONT - Malfunction of ONT's optical transceiver - soho-sup-cfg-dnld-fail: SOHO ONT - Download of voice xml file to ONT failed - soho-sup-rssi-cfg-mism: SOHO ONT - RSSI configuration mismatch - soho-sup-sfp-tx-low : SOHO ONT - SFP Tx Power below configured low-level alarm threshold - soho-sup-sfp-temp-high: SOHO ONT - SFP Temperature above configured high-level alarm threshold - soho-sup-sfp-volt-high: SOHO ONT - SFP Voltage above configured high-level alarm threshold - soho-sup-sfp-bias-high: SOHO ONT - SFP Bias above configured high-level alarm threshold - soho-sup-ld-cfg-mism : SOHO ONT - Loop detection configuration mismatch - soho-sup-olt-rx-low : SOHO ONT - OLT Rx power below receiver operating range - soho-sup-olt-rx-high : SOHO ONT - OLT Rx power above receiver operating range - soho-sup-olt-rx-lo-war: SOHO ONT - OLT Rx power below low-level warning threshold - soho-sup-olt-rx-hi-war: SOHO ONT - OLT Rx power above high-level warning threshold - soho-sup-tod-out-sync : SOHO ONT - ONU TOD is out-sync with OLT - soho-sup-ont-tune-fail: SOHO ONT - ONU has failed to tune to Target-ChnlPair - soho-tr069-param-fail : SOHO ONT - hgu tr069 parameters mismatch - soho-sup-tod-mismatch : SOHO ONT - ONU TOD MISMATCH - all : SOHO ONT general supplemental related alarms	
severity	Parameter type: <Alarm::querySeverity> Format: (indeterminate warning minor major critical all) Possible values: - indeterminate : alarm severity is indeterminate	severity level of an alarm for reporting

Resource Identifier	Type	Description
	- warning : alarm severity is warning - minor : alarm severity is minor - major : alarm severity is major - critical : alarm severity is critical - all : all alarm severity	
servaff	Parameter type: <Alarm::queryServAffect> Format: (service-affecting noservice-affecting all) Possible values: - service-affecting : query alarm service affecting - noservice-affecting : query alarm not service affecting - all : query service affecting and not affecting alarms	serviceaffecting no
ont	Parameter type: <Gpon::OntIndex> Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> ng2 : <Ng2::ChannelGroup> / <Ng2::SubchannelGroup> / <Ng2::OntId>) Possible values: - ng2 : ngpon2 style identification Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Ng2::ChannelGroup> - channel group number Field type <Ng2::SubchannelGroup> - subchannel group number Field type <Eqpt::OntId> - the ONT identifier Field type <Ng2::OntId> - the ONT identifier	identifies the ont entry

Command Output

Table 101.131-2 "show current alarm by filters" Display parameters

Specific Information		
name	Type	Description
aidinfo	Parameter type: <Alarm::AddInfoString> - additional alarm information	alarm AID parameters <i>This element is only shown in detail mode.</i>
type	Parameter type: <Alarm::alarmIHUBType> (equipment eqpt-holder plug-in-unit atm custom e1 ima-group ima-link	type of the alarms that are active <i>This element is only shown in detail mode.</i>

101 query current alarms by filters

name	Type	Description
	redundancy shdsl ether-itf traffic-overflow qos-queue temporal spatial (software-mngt sw-mgmt) xdsl xdsl-ext xdsl-tca olt-gen eo-conv authentication bonding sfp shdsl-isam custom-ext-alarm plug-in-unit-ext sip-user-agent sip-plugin-unit sip-termination e1-sip-termination filetransfer external-device l2forward ether-tca ether-sfp megaco-media-gw megaco-sig-gw megaco-plug-unit megaco-term megaco-sig-lt eqpt-supplemental eqpt-holder-ext lsmredundancy sync mcsrc vlanport vect-line vect-board otdr sip-dial-plan sip-vsp sip-server bgp rip lag ihub-general vprn isis ospf ihub-l2forward vpls ihub-equip ihub-link eont-phyoam	

name	Type	Description
	ellid	
	epon	
	eont-services-lan	
	eolt-ont-tca	
	eont-sw-dl	
	ldp	
	mpls	
	sdp	
	epipe	
	ihub-ipv6	
	pim	
	li	
	mgmt-sec-access	
	bfd	
	ai	
	tr069serv	
	ontsnmp	
	bulk-sync	
	protection-group	
	ont	
	sfu-sup	
	soho-sup	
	mdu-sup	
	ont-ani	
	sfu-sup2	
	soho-sup2	
	mdu-sup2	
	sfprssi	
	eoltrssi	
	cfm	
	sfpe1t1-framer	
	sfpe1t1-clock	
	pppcc-engine-tca	
	eth-cfm	
	rsvp	
	ihub-tca	
	eth-ring	
	efm-oam	
	ont-loopdetect	
	ont-video	
	ont-ces	
	ont-voip	
	ont-video-ani	
	ont-pwe	
	ont-cese1	
	ont-xdsl	
	ont-xdsl-tca	
	ont-hpna	
	ont-sip-agent-cfg	
	ont-voip-cfg	
	ont-mgc	
	ont-ploam	
	ont-gen	
	ont-card	
	ont-pots	
	ont-lan	
	ont-moca	

101 query current alarms by filters

name	Type	Description
	ont-tc-tca ont-moca-tca ont-l2uni-eth-tca olt-pon-tc-tca olt-pon-util-tca olt-chpr-util-tca olt-ont-tc-tca ont-tca ont-pots-supplemental sfu-ploam sfu-gen soho-ploam soho-gen mdu-ploam mdu-gen ont-veip ont-iphost alarm-table auto-switch channel-pair ont-cfg-dld olt-chpair-tc-tca hgu-tr069 eqpt-psu ont-protection secondary-megaco-term secondary-sip-term cas-r2-channel lldpmed pseudo-wire link-agg fcs-exceed e1t1-interface) Possible values: - equipment : equipment alarms - eqpt-holder : equipment holder alarms - plug-in-unit : plugin unit alarms - atm : ATM alarms - custom : customizable alarms - e1 : e1 alarms - ima-group : ima-group alarms - ima-link : ima-link alarms - redundancy : redundancy alarms - shdsl : shdsl alarms - ether-itf : ethernet interface alarms - traffic-overflow : Traffic overflow alarms - qos-queue : qos queue alarms - temporal : temporal alarms - spatial : spatial alarms - software-mngt : software management alarms - sw-mgmt : software management alarms - xdsl : xDSL alarms - xdsl-ext : other xDSL alarms - xdsl-tca : xDSL threshold cross alarms - olt-gen : OLT general alarms - eo-conv : E/O conversion related alarms - authentication : authentication related alarms	

name	Type	Description
	- bonding : bonding-group related alarms - sfp : SFP related alarms - shdsl-isam : shdsl isam alarms - custom-ext-alarm : customizable external alarms - plug-in-unit-ext : other plugin unit alarms - sip-user-agent : sip user agent related alarms - sip-plugin-unit : sip plug in unit related alarms - sip-termination : sip termination related alarms - e1-sip-termination : E1 sip termination related alarms - filetransfer : file transfer server alarms - external-device : external device related alarms - l2forward : l2forward related alarms - ether-tca : ethernet threshold cross alarms - ether-sfp : ethernet SFP related alarms - megaco-media-gw : megaco media gateway related alarms - megaco-sig-gw : megaco signaling gateway related alarms - megaco-plug-unit : megaco plug unit related alarms - megaco-term : megaco termination related alarms - megaco-sig-lt : megaco signaling lt related alarms - eqpt-supplemental : equipment supplemental alarms - eqpt-holder-ext : other equipment holder alarms - lsmredundancy : lsm redundancy alarms - sync : synce and bits alarms - mcsrc : multicast source alarms - vlanport : vlanport alarms - vect-line : xDSL vectoring line alarms - vect-board : xDSL vectoring board alarms - otdr : otdr alarms - sip-dial-plan : sip dial plan related alarms - sip-vsp : sip vsp related alarms - sip-server : sip server related alarms - bgp : bgp related alarms - rip : rip related alarms - lag : LAG related alarms - ihub-general : IHUB general related alarms - vprn : vprn related alarms - isis : isis related alarms - ospf : ospf related alarms - ihub-l2forward : ihub-l2forward alarms - vpls : vpls related alarms - ihub-equip : ihub-equip related alarms - ihub-link : ihub-link related alarms - eont-phyoam : eont phyoam related alarms - ellid : ellid related alarms - epon : epon related alarms - eont-services-lan : eon phyoam related alarms - eolt-ont-tca : eon phyoam related alarms - eont-sw-dl : eon phyoam related alarms - ldp : ldp related alarms - mpls : mpls related alarms - sdp : sdp related alarms - epipe : epipe related alarms - ihub-ipv6 : ihub-ipv6 related alarms - pim : pim related alarms - li : lawful intercept related alarms - mgmt-sec-access : management security related alarms - bfd : bfd related alarms	

101 query current alarms by filters

name	Type	Description
	- ai : Application Intelligence related alarms - tr069serv : tr069 server related alarms - ontsnmp : ont snmp related alarms - bulk-sync : bulk-sync related alarms - protection-group : port protection group related alarms - ont : ONT general supplemental related alarms - sfu-sup : SFU ONT general supplemental related alarms - soho-sup : SOHO ONT general supplemental related alarms - mdu-sup : MDU ONT general supplemental related alarms - ont-ani : ONT general supplemental 2 related alarms - sfu-sup2 : SFU ONT general supplemental 2 related alarms - soho-sup2 : SOHO ONT general supplemental 2 related alarms - mdu-sup2 : MDU ONT general supplemental 2 related alarms - sfrssi : SFP RSSI related alarms - eoltrssi : epon olt Sfp RSSI related alarms - cfm : Cfm related alarms - sfpe1t1-framer : SFP 2e1t1 framer alarms - sfpe1t1-clock : SFP 2e1t1 clock alarms - pppcc-engine-tca : PPPOE Cross Connect Engine TCA related alarm - eth-cfm : eth-cfm related alarms - rsvp : rsvp related alarms - ihub-tca : IHUB TCA related alarms - eth-ring : eth-ring related alarms - efm-oam : EFM-OAM related alarms - ont-loopdetect : ont loop detect related alarms - ont-video : ont services video related alarms - ont-ces : ont services ces related alarms - ont-voip : ont services voip related alarms - ont-video-ani : ont services video ani related alarms - ont-pwe : ont services pwe related alarms - ont-cese1 : ont services cese1 related alarms - ont-xdsl : ont services xdsl related alarms - ont-xdsl-tca : ont services xdsl tca related alarms - ont-hpna : ont hpna related alarms - ont-sip-agent-cfg : ont services voip sip agent config related alarms - ont-voip-cfg : ont services voip config related alarms - ont-mgc : ont mgc related alarms - ont-ploam : ONT PLOAM related alarms - ont-gen : ONT GENERAL related alarms - ont-card : ONT Subscriber Card related alarms - ont-pots : ONT Services POTS related alarms - ont-lan : ONT Services LAN related alarms - ont-moca : ONT MoCA related alarms - ont-tc-tca : ONT TC TCA related alarms - ont-moca-tca : ONT MoCA TCA related alarms - ont-l2uni-eth-tca : ONT L2 UNI Ethernet TCA related alarms - olt-pon-tc-tca : OLT PON TC TCA related alarms - olt-pon-util-tca : OLT PON utilization TCA related alarms - olt-chpr-util-tca : OLT channel-pair utilization TCA related alarms - olt-ont-tc-tca : OLT ONT TC TCA related alarms	

name	Type	Description
	- ont-tca : ONT TCA related alarms - ont-pots-supplemental : ONT POTS Supplemental related alarms - sfu-ploam : SFU ONT PLOAM related alarms - sfu-gen : SFU ONT general related alarms - soho-ploam : SOHO ONT PLOAM related alarms - soho-gen : SOHO ONT general related alarms - mdu-ploam : MDU ONT PLOAM related alarms - mdu-gen : MDU ONT general related alarms - ont-veip : ONT VEIP related alarms - ont-iphost : ONT IP HOST related alarms - alarm-table : alarm table related alarms - auto-switch : auto-switch related alarms - channel-pair : channel pair related alarms - ont-cfg-dld : ont configure file download related alarms - olt-chpair-tc-tca : OLT CHANNELPAIR TC TCA related alarms - hgu-tr069 : hgu tr069 related alarms - eqpt-psu : equipment psu alarms - ont-protection : ONT protection related alarms - secondary-megaco-term : secondary megaco termination related alarms - secondary-sip-term : secondary sip termination related alarms - cas-r2-channel : CAS R2 channel related alarms - lldpmed : lldpmed alarms - pseudo-wire : pseudo Wire related alarms - link-agg : Link aggregation related alarms - fcs-exceed : FCS auto-recovery related alarms - e1t1-interface : E1/T1 physical interfaces related alarms	
name	Parameter type: <Alarm::almttypeSohosupihub> (soho-sup-sw-file-error soho-sup-fan-failure soho-sup-temp-high-war soho-sup-temp-shutoff soho-sup-emergency-cal soho-sup-swverctrl-err soho-sup-poe-exceed-ma soho-sup-poe-over-yell soho-opti-malfunc soho-sup-cfg-dnld-fail soho-sup-rssi-cfg-mism soho-sup-sfp-tx-low soho-sup-sfp-temp-high soho-sup-sfp-volt-high soho-sup-sfp-bias-high soho-sup-ld-cfg-mism soho-sup-olt-rx-low soho-sup-olt-rx-high soho-sup-olt-rx-lo-war soho-sup-olt-rx-hi-war soho-sup-tod-out-sync soho-sup-ont-tune-fail soho-tr069-parm-fail soho-sup-tod-mismatch all) Possible values:	alarm name that are active <i>This element is only shown in detail mode.</i>

101 query current alarms by filters

name	Type	Description
	- soho-sup-sw-file-error: SOHO ONT - Software file has error or is missing - soho-sup-fan-failure : SOHO ONT - Fan failure - soho-sup-temp-high-war: SOHO ONT - High temperature warning - soho-sup-temp-shutoff : SOHO ONT - Service disabled due to excessive temperature - soho-sup-emergency-cal: SOHO ONT - Emergency call active - soho-sup-swverctrl-err: SOHO ONT - Software version control error - soho-sup-poe-exceed-ma: SOHO ONT - Configured PoE feeding exceeds ONT maximum - soho-sup-poe-over-yell: SOHO ONT - ONU is nearing its maximum ability to supply the power - soho-opti-malfunc : SOHO ONT - Malfunction of ONT's optical transceiver - soho-sup-cfg-dnld-fail: SOHO ONT - Download of voice xml file to ONT failed - soho-sup-rssi-cfg-mism: SOHO ONT - RSSI configuration mismatch - soho-sup-sfp-tx-low : SOHO ONT - SFP Tx Power below configured low-level alarm threshold - soho-sup-sfp-temp-high: SOHO ONT - SFP Temperature above configured high-level alarm threshold - soho-sup-sfp-volt-high: SOHO ONT - SFP Voltage above configured high-level alarm threshold - soho-sup-sfp-bias-high: SOHO ONT - SFP Bias above configured high-level alarm threshold - soho-sup-ld-cfg-mism : SOHO ONT - Loop detection configuration mismatch - soho-sup-olt-rx-low : SOHO ONT - OLT Rx power below receiver operating range - soho-sup-olt-rx-high : SOHO ONT - OLT Rx power above receiver operating range - soho-sup-olt-rx-lo-war: SOHO ONT - OLT Rx power below low-level warning threshold - soho-sup-olt-rx-hi-war: SOHO ONT - OLT Rx power above high-level warning threshold - soho-sup-tod-out-sync : SOHO ONT - ONU TOD is out-sync with OLT - soho-sup-ont-tune-fail: SOHO ONT - ONU has failed to tune to Target-ChnlPair - soho-tr069-parm-fail : SOHO ONT - hgu tr069 parameters mismatch - soho-sup-tod-mismatch : SOHO ONT - ONU TOD MISMATCH - all : SOHO ONT general supplemental related alarms	
severity	Parameter type: <Alarm::AlarmSeverity> (indeterminate warning minor major critical) Possible values: - indeterminate : alarm severity is indeterminate - warning : alarm severity is warning	the alarms severity level <i>This element is only shown in detail mode.</i>

name	Type	Description
	- minor : alarm severity is minor - major : alarm severity is major - critical : alarm severity is critical	
servaff	Parameter type: <Alarm::alarmServAffect> ((service-affecting yes) (noservice-affecting no)) Possible values: - service-affecting : make this alarm service affecting - yes : make this alarm service affecting - noservice-affecting : make this alarm not service affecting - no : make this alarm not service affecting	alarms affect service or not <i>This element is only shown in detail mode.</i>
time	Parameter type: <Sys::timeInSecs> - the time (yyyy-mm-dd:hour:minutes:secs) - unit: UTC	time in seconds when alarm was updated <i>This element is only shown in detail mode.</i>
descript	Parameter type: <Alarm::AddInfoString> - additional alarm information	alarm description <i>This element is only shown in detail mode.</i>

101.132 show current alarm by filters

Command Description

show current alarms by filters

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm query mdu-sup [ (name) [ severity <Alarm::querySeverity> ] [ servaff <Alarm::queryServAffect> ] [
ont <Gpon::OntIndex> ] ]
```

Command Parameters

Table 101.132-1 "show current alarm by filters" Resource Parameters

Resource Identifier	Type	Description
(name)	Format: (mdu-sup-sw-file-error mdu-sup-fan-failure mdu-sup-temp-high-warn mdu-sup-temp-shutoff mdu-sup-emergency-call mdu-sup-swverctrl-err mdu-sup-poe-exceed-max mdu-sup-poe-over-yell mdu-opti-malfunc mdu-sup-cfg-dnld-fail mdu-sup-rssi-cfg-mism mdu-sup-sfp-tx-low mdu-sup-sfp-temp-high mdu-sup-sfp-volt-high mdu-sup-sfp-bias-high mdu-sup-ld-cfg-mism mdu-sup-olt-rx-low mdu-sup-olt-rx-high mdu-sup-olt-rx-lo-warn mdu-sup-olt-rx-hi-warn mdu-sup-tod-out-sync mdu-sup-ont-tune-fail mdu-tr069-parm-fail mdu-sup-tod-mismatch all) Possible values: - mdu-sup-sw-file-error : MDU ONT - Software file has	alarm name of MDU ONT

Resource Identifier	Type	Description
	error or is missing - mdu-sup-fan-failure : MDU ONT - Fan failure - mdu-sup-temp-high-warn: MDU ONT - High temperature warning - mdu-sup-temp-shutoff : MDU ONT - Service disabled due to excessive temperature - mdu-sup-emergency-call: MDU ONT - Emergency call active - mdu-sup-swverctrl-err : MDU ONT - Software version control error - mdu-sup-poe-exceed-max: MDU ONT - Configured PoE feeding exceeds ONT maximum - mdu-sup-poe-over-yell : MDU ONT - ONU is nearing its maximum ability to supply the power - mdu-opti-malfunc : MDU ONT - Malfunction of ONT's optical transceiver - mdu-sup-cfg-dnld-fail : MDU ONT - Download of voice xml file to ONT failed - mdu-sup-rssi-cfg-mism : MDU ONT - RSSI configuration mismatch - mdu-sup-sfp-tx-low : MDU ONT - SFP Tx Power below configured low-level alarm threshold - mdu-sup-sfp-temp-high : MDU ONT - SFP Temperature above configured high-level alarm threshold - mdu-sup-sfp-volt-high : MDU ONT - SFP Voltage above configured high-level alarm threshold - mdu-sup-sfp-bias-high : MDU ONT - SFP Bias above configured high-level alarm threshold - mdu-sup-ld-cfg-mism : MDU ONT - Loop detection configuration mismatch - mdu-sup-olt-rx-low : MDU ONT - OLT Rx power below receiver operating range - mdu-sup-olt-rx-high : MDU ONT - OLT Rx power above receiver operating range - mdu-sup-olt-rx-lo-warn: MDU ONT - OLT Rx power below low-level warning threshold - mdu-sup-olt-rx-hi-warn: MDU ONT - OLT Rx power above high-level warning threshold - mdu-sup-tod-out-sync : MDU ONT - ONU TOD is out-sync with OLT - mdu-sup-ont-tune-fail : MDU ONT - ONU has failed to tune to Target-ChnlPair - mdu-tr069-param-fail : MDU ONT - hgu tr069 parameters mismatch - mdu-sup-tod-mismatch : MDU ONT - ONU TOD MISMATCH - all : MDU ONT general supplemental related alarms	
severity	Parameter type: <Alarm::querySeverity> Format: (indeterminate warning minor major critical all) Possible values: - indeterminate : alarm severity is indeterminate	severity level of an alarm for reporting

101 query current alarms by filters

Resource Identifier	Type	Description
	- warning : alarm severity is warning - minor : alarm severity is minor - major : alarm severity is major - critical : alarm severity is critical - all : all alarm severity	
servaff	Parameter type: <Alarm::queryServAffect> Format: (service-affecting noservice-affecting all) Possible values: - service-affecting : query alarm service affecting - noservice-affecting : query alarm not service affecting - all : query service affecting and not affecting alarms	serviceaffecting no
ont	Parameter type: <Gpon::OntIndex> Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> ng2 : <Ng2::ChannelGroup> / <Ng2::SubchannelGroup> / <Ng2::OntId>) Possible values: - ng2 : ngpon2 style identification Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Ng2::ChannelGroup> - channel group number Field type <Ng2::SubchannelGroup> - subchannel group number Field type <Eqpt::OntId> - the ONT identifier Field type <Ng2::OntId> - the ONT identifier	identifies the ont entry

Command Output

Table 101.132-2 "show current alarm by filters" Display parameters

Specific Information		
name	Type	Description
aidinfo	Parameter type: <Alarm::AddInfoString> - additional alarm information	alarm AID parameters <i>This element is only shown in detail mode.</i>
type	Parameter type: <Alarm::alarmIHUBType> (equipment eqpt-holder plug-in-unit atm custom e1 ima-group ima-link	type of the alarms that are active <i>This element is only shown in detail mode.</i>

name	Type	Description
	redundancy shdsl ether-itf traffic-overflow qos-queue temporal spatial (software-mngt sw-mgmt) xdsl xdsl-ext xdsl-tca olt-gen eo-conv authentication bonding sfp shdsl-isam custom-ext-alarm plug-in-unit-ext sip-user-agent sip-plugin-unit sip-termination e1-sip-termination filetransfer external-device l2forward ether-tca ether-sfp megaco-media-gw megaco-sig-gw megaco-plug-unit megaco-term megaco-sig-lt eqpt-supplemental eqpt-holder-ext lsmredundancy sync mcsrc vlanport vect-line vect-board otdr sip-dial-plan sip-vsp sip-server bgp rip lag ihub-general vprn isis ospf ihub-l2forward vpls ihub-equip ihub-link eont-phyoam	

101 query current alarms by filters

name	Type	Description
	ellid	
	epon	
	eont-services-lan	
	eolt-ont-tca	
	eont-sw-dl	
	ldp	
	mpls	
	sdp	
	epipe	
	ihub-ipv6	
	pim	
	li	
	mgmt-sec-access	
	bfd	
	ai	
	tr069serv	
	ontsnmp	
	bulk-sync	
	protection-group	
	ont	
	sfu-sup	
	soho-sup	
	mdu-sup	
	ont-ani	
	sfu-sup2	
	soho-sup2	
	mdu-sup2	
	sfprssi	
	eoltrssi	
	cfm	
	sfpe1t1-framer	
	sfpe1t1-clock	
	pppcc-engine-tca	
	eth-cfm	
	rsvp	
	ihub-tca	
	eth-ring	
	efm-oam	
	ont-loopdetect	
	ont-video	
	ont-ces	
	ont-voip	
	ont-video-ani	
	ont-pwe	
	ont-cese1	
	ont-xdsl	
	ont-xdsl-tca	
	ont-hpna	
	ont-sip-agent-cfg	
	ont-voip-cfg	
	ont-mgc	
	ont-ploam	
	ont-gen	
	ont-card	
	ont-pots	
	ont-lan	
	ont-moca	

name	Type	Description
	ont-tc-tca ont-moca-tca ont-l2uni-eth-tca olt-pon-tc-tca olt-pon-util-tca olt-chpr-util-tca olt-ont-tc-tca ont-tca ont-pots-supplemental sfu-ploam sfu-gen soho-ploam soho-gen mdu-ploam mdu-gen ont-veip ont-iphost alarm-table auto-switch channel-pair ont-cfg-dld olt-chpair-tc-tca hgu-tr069 eqpt-psu ont-protection secondary-megaco-term secondary-sip-term cas-r2-channel lldpmed pseudo-wire link-agg fcs-exceed e1t1-interface) Possible values: - equipment : equipment alarms - eqpt-holder : equipment holder alarms - plug-in-unit : plugin unit alarms - atm : ATM alarms - custom : customizable alarms - e1 : e1 alarms - ima-group : ima-group alarms - ima-link : ima-link alarms - redundancy : redundancy alarms - shdsl : shdsl alarms - ether-itf : ethernet interface alarms - traffic-overflow : Traffic overflow alarms - qos-queue : qos queue alarms - temporal : temporal alarms - spatial : spatial alarms - software-mngt : software management alarms - sw-mgmt : software management alarms - xdsl : xDSL alarms - xdsl-ext : other xDSL alarms - xdsl-tca : xDSL threshold cross alarms - olt-gen : OLT general alarms - eo-conv : E/O conversion related alarms - authentication : authentication related alarms	

101 query current alarms by filters

name	Type	Description
	- bonding : bonding-group related alarms - sfp : SFP related alarms - shdsl-isam : shdsl isam alarms - custom-ext-alarm : customizable external alarms - plug-in-unit-ext : other plugin unit alarms - sip-user-agent : sip user agent related alarms - sip-plugin-unit : sip plug in unit related alarms - sip-termination : sip termination related alarms - e1-sip-termination : E1 sip termination related alarms - filetransfer : file transfer server alarms - external-device : external device related alarms - l2forward : l2forward related alarms - ether-tca : ethernet threshold cross alarms - ether-sfp : ethernet SFP related alarms - megaco-media-gw : megaco media gateway related alarms - megaco-sig-gw : megaco signaling gateway related alarms - megaco-plug-unit : megaco plug unit related alarms - megaco-term : megaco termination related alarms - megaco-sig-lt : megaco signaling lt related alarms - eqpt-supplemental : equipment supplemental alarms - eqpt-holder-ext : other equipment holder alarms - lsmredundancy : lsm redundancy alarms - sync : synce and bits alarms - mcsrc : multicast source alarms - vlanport : vlanport alarms - vect-line : xDSL vectoring line alarms - vect-board : xDSL vectoring board alarms - otdr : otdr alarms - sip-dial-plan : sip dial plan related alarms - sip-vsp : sip vsp related alarms - sip-server : sip server related alarms - bgp : bgp related alarms - rip : rip related alarms - lag : LAG related alarms - ihub-general : IHUB general related alarms - vprn : vprn related alarms - isis : isis related alarms - ospf : ospf related alarms - ihub-l2forward : ihub-l2forward alarms - vpls : vpls related alarms - ihub-equip : ihub-equip related alarms - ihub-link : ihub-link related alarms - eont-phyoam : eont phyoam related alarms - ellid : ellid related alarms - epon : epon related alarms - eont-services-lan : eon phyoam related alarms - eolt-ont-tca : eon phyoam related alarms - eont-sw-dl : eon phyoam related alarms - ldp : ldp related alarms - mpls : mpls related alarms - sdp : sdp related alarms - epipe : epipe related alarms - ihub-ipv6 : ihub-ipv6 related alarms - pim : pim related alarms - li : lawful intercept related alarms - mgmt-sec-access : management security related alarms - bfd : bfd related alarms	

name	Type	Description
	- ai : Application Intelligence related alarms - tr069serv : tr069 server related alarms - ontsnmp : ont snmp related alarms - bulk-sync : bulk-sync related alarms - protection-group : port protection group related alarms - ont : ONT general supplemental related alarms - sfu-sup : SFU ONT general supplemental related alarms - soho-sup : SOHO ONT general supplemental related alarms - mdu-sup : MDU ONT general supplemental related alarms - ont-ani : ONT general supplemental 2 related alarms - sfu-sup2 : SFU ONT general supplemental 2 related alarms - soho-sup2 : SOHO ONT general supplemental 2 related alarms - mdu-sup2 : MDU ONT general supplemental 2 related alarms - sfrssi : SFP RSSI related alarms - eoltrssi : epon olt Sfp RSSI related alarms - cfm : Cfm related alarms - sfpe1t1-framer : SFP 2e1t1 framer alarms - sfpe1t1-clock : SFP 2e1t1 clock alarms - pppcc-engine-tca : PPPOE Cross Connect Engine TCA related alarm - eth-cfm : eth-cfm related alarms - rsvp : rsvp related alarms - ihub-tca : IHUB TCA related alarms - eth-ring : eth-ring related alarms - efm-oam : EFM-OAM related alarms - ont-loopdetect : ont loop detect related alarms - ont-video : ont services video related alarms - ont-ces : ont services ces related alarms - ont-voip : ont services voip related alarms - ont-video-ani : ont services video ani related alarms - ont-pwe : ont services pwe related alarms - ont-cese1 : ont services cese1 related alarms - ont-xdsl : ont services xdsl related alarms - ont-xdsl-tca : ont services xdsl tca related alarms - ont-hpna : ont hpna related alarms - ont-sip-agent-cfg : ont services voip sip agent config related alarms - ont-voip-cfg : ont services voip config related alarms - ont-mgc : ont mgc related alarms - ont-ploam : ONT PLOAM related alarms - ont-gen : ONT GENERAL related alarms - ont-card : ONT Subscriber Card related alarms - ont-pots : ONT Services POTS related alarms - ont-lan : ONT Services LAN related alarms - ont-moca : ONT MoCA related alarms - ont-tc-tca : ONT TC TCA related alarms - ont-moca-tca : ONT MoCA TCA related alarms - ont-l2uni-eth-tca : ONT L2 UNI Ethernet TCA related alarms - olt-pon-tc-tca : OLT PON TC TCA related alarms - olt-pon-util-tca : OLT PON utilization TCA related alarms - olt-chpr-util-tca : OLT channel-pair utilization TCA related alarms - olt-ont-tc-tca : OLT ONT TC TCA related alarms	

101 query current alarms by filters

name	Type	Description
	- ont-tca : ONT TCA related alarms - ont-pots-supplemental : ONT POTS Supplemental related alarms - sfu-ploam : SFU ONT PLOAM related alarms - sfu-gen : SFU ONT general related alarms - soho-ploam : SOHO ONT PLOAM related alarms - soho-gen : SOHO ONT general related alarms - mdu-ploam : MDU ONT PLOAM related alarms - mdu-gen : MDU ONT general related alarms - ont-veip : ONT VEIP related alarms - ont-iphost : ONT IP HOST related alarms - alarm-table : alarm table related alarms - auto-switch : auto-switch related alarms - channel-pair : channel pair related alarms - ont-cfg-dld : ont configure file download related alarms - olt-chpair-tc-tca : OLT CHANNELPAIR TC TCA related alarms - hgu-tr069 : hgu tr069 related alarms - eqpt-psu : equipment psu alarms - ont-protection : ONT protection related alarms - secondary-megaco-term : secondary megaco termination related alarms - secondary-sip-term : secondary sip termination related alarms - cas-r2-channel : CAS R2 channel related alarms - lldpmed : lldpmed alarms - pseudo-wire : pseudo Wire related alarms - link-agg : Link aggregation related alarms - fcs-exceed : FCS auto-recovery related alarms - e1t1-interface : E1/T1 physical interfaces related alarms	
name	Parameter type: <Alarm::alarmtypeMduSupiHub> (mdu-sup-sw-file-error mdu-sup-fan-failure mdu-sup-temp-high-warn mdu-sup-temp-shutoff mdu-sup-emergency-call mdu-sup-swverctrl-err mdu-sup-poe-exceed-max mdu-sup-poe-over-yell mdu-opti-malfunc mdu-sup-cfg-dnld-fail mdu-sup-rssi-cfg-mism mdu-sup-sfp-tx-low mdu-sup-sfp-temp-high mdu-sup-sfp-volt-high mdu-sup-sfp-bias-high mdu-sup-ld-cfg-mism mdu-sup-olt-rx-low mdu-sup-olt-rx-high mdu-sup-olt-rx-lo-warn mdu-sup-olt-rx-hi-warn mdu-sup-tod-out-sync mdu-sup-ont-tune-fail mdu-tr069-parm-fail mdu-sup-tod-mismatch all) Possible values:	alarm name that are active <i>This element is only shown in detail mode.</i>

name	Type	Description
	- mdu-sup-sw-file-error : MDU ONT - Software file has error or is missing - mdu-sup-fan-failure : MDU ONT - Fan failure - mdu-sup-temp-high-warn: MDU ONT - High temperature warning - mdu-sup-temp-shutoff : MDU ONT - Service disabled due to excessive temperature - mdu-sup-emergency-call: MDU ONT - Emergency call active - mdu-sup-swverctrl-err : MDU ONT - Software version control error - mdu-sup-poe-exceed-max: MDU ONT - Configured PoE feeding exceeds ONT maximum - mdu-sup-poe-over-yell : MDU ONT - ONU is nearing its maximum ability to supply the power - mdu-opti-malfunc : MDU ONT - Malfunction of ONT's optical transceiver - mdu-sup-cfg-dnld-fail : MDU ONT - Download of voice xml file to ONT failed - mdu-sup-rssi-cfg-mism : MDU ONT - RSSI configuration mismatch - mdu-sup-sfp-tx-low : MDU ONT - SFP Tx Power below configured low-level alarm threshold - mdu-sup-sfp-temp-high : MDU ONT - SFP Temperature above configured high-level alarm threshold - mdu-sup-sfp-volt-high : MDU ONT - SFP Voltage above configured high-level alarm threshold - mdu-sup-sfp-bias-high : MDU ONT - SFP Bias above configured high-level alarm threshold - mdu-sup-ld-cfg-mism : MDU ONT - Loop detection configuration mismatch - mdu-sup-olt-rx-low : MDU ONT - OLT Rx power below receiver operating range - mdu-sup-olt-rx-high : MDU ONT - OLT Rx power above receiver operating range - mdu-sup-olt-rx-lo-warn: MDU ONT - OLT Rx power below low-level warning threshold - mdu-sup-olt-rx-hi-warn: MDU ONT - OLT Rx power above high-level warning threshold - mdu-sup-tod-out-sync : MDU ONT - ONU TOD is out-sync with OLT - mdu-sup-ont-tune-fail : MDU ONT - ONU has failed to tune to Target-ChnlPair - mdu-tr069-param-fail : MDU ONT - hgu tr069 parameters mismatch - mdu-sup-tod-mismatch : MDU ONT - ONU TOD MISMATCH - all : MDU ONT general supplemental related alarms	
severity	Parameter type: <Alarm::AlarmSeverity> (indeterminate warning minor major critical) Possible values: - indeterminate : alarm severity is indeterminate - warning : alarm severity is warning	the alarms severity level <i>This element is only shown in detail mode.</i>

101 query current alarms by filters

name	Type	Description
	- minor : alarm severity is minor - major : alarm severity is major - critical : alarm severity is critical	
servaff	Parameter type: <Alarm::alarmServAffect> ((service-affecting yes) (noservice-affecting no)) Possible values: - service-affecting : make this alarm service affecting - yes : make this alarm service affecting - noservice-affecting : make this alarm not service affecting - no : make this alarm not service affecting	alarms affect service or not <i>This element is only shown in detail mode.</i>
time	Parameter type: <Sys::timeInSecs> - the time (yyyy-mm-dd:hour:minutes:secs) - unit: UTC	time in seconds when alarm was updated <i>This element is only shown in detail mode.</i>
descript	Parameter type: <Alarm::AddInfoString> - additional alarm information	alarm description <i>This element is only shown in detail mode.</i>

101.133 show current alarm by filters

Command Description

show current alarms by filters

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm query eth-ring [ (name) [ severity <Alarm::querySeverity> ] [ servaff <Alarm::queryServAffect> ] [ ring-id <Alarm::genAlarmIndex> ] ]
```

Command Parameters

Table 101.133-1 "show current alarm by filters" Resource Parameters

Resource Identifier	Type	Description
(name)	Format: (eth-ring-path-block all) Possible values: - eth-ring-path-block : eth ring path block - all : eth ring related alarms	alarm name of eth-ring path
severity	Parameter type: <Alarm::querySeverity> Format: (indeterminate warning minor major critical all) Possible values: - indeterminate : alarm severity is indeterminate - warning : alarm severity is warning - minor : alarm severity is minor - major : alarm severity is major - critical : alarm severity is critical - all : all alarm severity	severity level of an alarm for reporting
servaff	Parameter type: <Alarm::queryServAffect> Format: (service-affecting noservice-affecting all) Possible values: - service-affecting : query alarm service affecting	serviceaffecting no

101 query current alarms by filters

Resource Identifier	Type	Description
	- noservice-affecting : query alarm not service affecting - all : query service affecting and not affecting alarms	
ring-id	Parameter type: <Alarm::genAlarmIndex> Format: - index of a current alarm entry	identifies the eth-ring-instance

Command Output

Table 101.133-2 "show current alarm by filters" Display parameters

Specific Information		
name	Type	Description
aidinfo	Parameter type: <Alarm::AddInfoString> - additional alarm information	alarm AID parameters <i>This element is only shown in detail mode.</i>
type	Parameter type: <Alarm::alarmIHUBType> (equipment eqpt-holder plug-in-unit atm custom e1 ima-group ima-link redundancy shdsl ether-itf traffic-overflow qos-queue temporal spatial (software-mngt sw-mgmt) xdsl xdsl-ext xdsl-tca olt-gen eo-conv authentication bonding sfp shdsl-isam custom-ext-alarm plug-in-unit-ext sip-user-agent sip-plugin-unit sip-termination e1-sip-termination filetransfer external-device l2forward ether-tca ether-sfp megaco-media-gw megaco-sig-gw megaco-plugin-unit megaco-term megaco-sig-lt	type of the alarms that are active <i>This element is only shown in detail mode.</i>

name	Type	Description
	eqpt-supplemental	
	eqpt-holder-ext	
	lsmredundancy	
	sync	
	mcsrc	
	vlanport	
	vect-line	
	vect-board	
	otdr	
	sip-dial-plan	
	sip-vsp	
	sip-server	
	bgp	
	rip	
	lag	
	ihub-general	
	vprn	
	isis	
	ospf	
	ihub-l2forward	
	vpls	
	ihub-equip	
	ihub-link	
	eont-phyoam	
	ellid	
	epon	
	eont-services-lan	
	eolt-ont-tca	
	eont-sw-dl	
	ldp	
	mpls	
	sdp	
	epipe	
	ihub-ipv6	
	pim	
	li	
	mgmt-sec-access	
	bfd	
	ai	
	tr069serv	
	ontsnmp	
	bulk-sync	
	protection-group	
	ont	
	sfu-sup	
	soho-sup	
	mdu-sup	
	ont-ani	
	sfu-sup2	
	soho-sup2	
	mdu-sup2	
	sfprssi	
	eoltrssi	
	cfm	
	sfpe1t1-framer	
	sfpe1t1-clock	
	pppcc-engine-tca	

101 query current alarms by filters

name	Type	Description
	eth-cfm	
	rsvp	
	ihub-tca	
	eth-ring	
	efm-oam	
	ont-loopdetect	
	ont-video	
	ont-ces	
	ont-voip	
	ont-video-ani	
	ont-pwe	
	ont-cese1	
	ont-xdsl	
	ont-xdsl-tca	
	ont-hpna	
	ont-sip-agent-cfg	
	ont-voip-cfg	
	ont-mgc	
	ont-ploam	
	ont-gen	
	ont-card	
	ont-pots	
	ont-lan	
	ont-moca	
	ont-tc-tca	
	ont-moca-tca	
	ont-l2uni-eth-tca	
	olt-pon-tc-tca	
	olt-pon-util-tca	
	olt-chpr-util-tca	
	olt-ont-tc-tca	
	ont-tca	
	ont-pots-supplemental	
	sfu-ploam	
	sfu-gen	
	soho-ploam	
	soho-gen	
	mdu-ploam	
	mdu-gen	
	ont-veip	
	ont-iphost	
	alarm-table	
	auto-switch	
	channel-pair	
	ont-cfg-dld	
	olt-chpair-tc-tca	
	hgu-tr069	
	eqpt-psu	
	ont-protection	
	secondary-megaco-term	
	secondary-sip-term	
	cas-r2-channel	
	lldpmed	
	pseudo-wire	
	link-agg	
	fcs-exceed	
	e1t1-interface)	

name	Type	Description
	Possible values: - equipment : equipment alarms - eqpt-holder : equipment holder alarms - plug-in-unit : plugin unit alarms - atm : ATM alarms - custom : customizable alarms - e1 : e1 alarms - ima-group : ima-group alarms - ima-link : ima-link alarms - redundancy : redundancy alarms - shdsl : shdsl alarms - ether-itf : ethernet interface alarms - traffic-overflow : Traffic overflow alarms - qos-queue : qos queue alarms - temporal : temporal alarms - spatial : spatial alarms - software-mngt : software management alarms - sw-mgmt : software management alarms - xdsl : xDSL alarms - xdsl-ext : other xDSL alarms - xdsl-tca : xDSL threshold cross alarms - olt-gen : OLT general alarms - eo-conv : E/O conversion related alarms - authentication : authentication related alarms - bonding : bonding-group related alarms - sfp : SFP related alarms - shdsl-isam : shdsl isam alarms - custom-ext-alarm : customizable external alarms - plug-in-unit-ext : other plugin unit alarms - sip-user-agent : sip user agent related alarms - sip-plugin-unit : sip plug in unit related alarms - sip-termination : sip termination related alarms - e1-sip-termination : E1 sip termination related alarms - filetransfer : file transfer server alarms - external-device : external device related alarms - l2forward : l2forward related alarms - ether-tca : ethernet threshold cross alarms - ether-sfp : ethernet SFP related alarms - megaco-media-gw : megaco media gateway related alarms - megaco-sig-gw : megaco signaling gateway related alarms - megaco-plug-unit : megaco plug unit related alarms - megaco-term : megaco termination related alarms - megaco-sig-lt : megaco signaling lt related alarms - eqpt-supplemental : equipment supplemental alarms - eqpt-holder-ext : other equipment holder alarms - lsmredundancy : lsm redundancy alarms - sync : synce and bits alarms - mcsrc : multicast source alarms - vlanport : vlanport alarms - vect-line : xDSL vectoring line alarms - vect-board : xDSL vectoring board alarms - otdr : otdr alarms - sip-dial-plan : sip dial plan related alarms - sip-vsp : sip vsp related alarms - sip-server : sip server related alarms - bgp : bgp related alarms - rip : rip related alarms	

101 query current alarms by filters

name	Type	Description
	- lag : LAG related alarms - ihub-general : IHUB general related alarms - vprn : vprn related alarms - isis : isis related alarms - ospf : ospf related alarms - ihub-l2forward : ihub-l2forward alarms - vpls : vpls related alarms - ihub-equip : ihub-equip related alarms - ihub-link : ihub-link related alarms - eont-phyoam : eont phyoam related alarms - ellid : ellid related alarms - epon : epon related alarms - eont-services-lan : eon phyoam related alarms - eolt-ont-tca : eon phyoam related alarms - eont-sw-dl : eon phyoam related alarms - ldp : ldp related alarms - mpls : mpls related alarms - sdp : sdp related alarms - epipe : epipe related alarms - ihub-ipv6 : ihub-ipv6 related alarms - pim : pim related alarms - li : lawful intercept related alarms - mgmt-sec-access : management security related alarms - bfd : bfd related alarms - ai : Application Intelligence related alarms - tr069serv : tr069 server related alarms - ontsnmp : ont snmp related alarms - bulk-sync : bulk-sync related alarms - protection-group : port protection group related alarms - ont : ONT general supplemental related alarms - sfu-sup : SFU ONT general supplemental related alarms - soho-sup : SOHO ONT general supplemental related alarms - mdu-sup : MDU ONT general supplemental related alarms - ont-ani : ONT general supplemental 2 related alarms - sfu-sup2 : SFU ONT general supplemental 2 related alarms - soho-sup2 : SOHO ONT general supplemental 2 related alarms - mdu-sup2 : MDU ONT general supplemental 2 related alarms - sfrssi : SFP RSSI related alarms - eoltrssi : epon olt Sfp RSSI related alarms - cfm : Cfm related alarms - sfpe1t1-framer : SFP 2e1t1 framer alarms - sfpe1t1-clock : SFP 2e1t1 clock alarms - pppcc-engine-tca : PPPOE Cross Connect Engine TCA related alarm - eth-cfm : eth-cfm related alarms - rsvp : rsvp related alarms - ihub-tca : IHUB TCA related alarms - eth-ring : eth-ring related alarms - efm-oam : EFM-OAM related alarms - ont-loopdetect : ont loop detect related alarms - ont-video : ont services video related alarms - ont-ces : ont services ces related alarms - ont-voip : ont services voip related alarms - ont-video-ani : ont services video ani related alarms	

name	Type	Description
	- ont-pwe : ont services pwe related alarms - ont-cese1 : ont services cese1 related alarms - ont-xdsl : ont services xdsl related alarms - ont-xdsl-tca : ont services xdsl tca related alarms - ont-hpna : ont hpna related alarms - ont-sip-agent-cfg : ont services voip sip agent config related alarms - ont-voip-cfg : ont services voip config related alarms - ont-mgc : ont mgc related alarms - ont-ploam : ONT PLOAM related alarms - ont-gen : ONT GENERAL related alarms - ont-card : ONT Subscriber Card related alarms - ont-pots : ONT Services POTS related alarms - ont-lan : ONT Services LAN related alarms - ont-moca : ONT MoCA related alarms - ont-tc-tca : ONT TC TCA related alarms - ont-moca-tca : ONT MoCA TCA related alarms - ont-l2uni-eth-tca : ONT L2 UNI Ethernet TCA related alarms - olt-pon-tc-tca : OLT PON TC TCA related alarms - olt-pon-util-tca : OLT PON utilization TCA related alarms - olt-chpr-util-tca : OLT channel-pair utilization TCA related alarms - olt-ont-tc-tca : OLT ONT TC TCA related alarms - ont-tca : ONT TCA related alarms - ont-pots-supplemental : ONT POTS Supplemental related alarms - sfu-ploam : SFU ONT PLOAM related alarms - sfu-gen : SFU ONT general related alarms - soho-ploam : SOHO ONT PLOAM related alarms - soho-gen : SOHO ONT general related alarms - mdu-ploam : MDU ONT PLOAM related alarms - mdu-gen : MDU ONT general related alarms - ont-veip : ONT VEIP related alarms - ont-iphost : ONT IP HOST related alarms - alarm-table : alarm table related alarms - auto-switch : auto-switch related alarms - channel-pair : channel pair related alarms - ont-cfg-dld : ont configure file download related alarms - olt-chpair-tc-tca : OLT CHANNELPAIR TC TCA related alarms - hgu-tr069 : hgu tr069 related alarms - eqpt-psu : equipment psu alarms - ont-protection : ONT protection related alarms - secondary-megaco-term : secondary megaco termination related alarms - secondary-sip-term : secondary sip termination related alarms - cas-r2-channel : CAS R2 channel related alarms - lldpmed : lldpmed alarms - pseudo-wire : pseudo Wire related alarms - link-agg : Link aggregation related alarms - fcs-exceed : FCS auto-recovery related alarms - e1t1-interface : E1/T1 physical interfaces related alarms	
name	Parameter type: <Alarm::almltypeEthringihub> (eth-ring-path-block all)	alarm name that are active <i>This element is only shown in detail mode.</i>

101 query current alarms by filters

name	Type	Description
	Possible values: - eth-ring-path-block : eth ring path block - all : eth ring related alarms	
severity	Parameter type: <Alarm::AlarmSeverity> (indeterminate warning minor major critical) Possible values: - indeterminate : alarm severity is indeterminate - warning : alarm severity is warning - minor : alarm severity is minor - major : alarm severity is major - critical : alarm severity is critical	the alarms severity level <i>This element is only shown in detail mode.</i>
servaff	Parameter type: <Alarm::alarmServAffect> ((service-affecting yes) (noservice-affecting no)) Possible values: - service-affecting : make this alarm service affecting - yes : make this alarm service affecting - noservice-affecting : make this alarm not service affecting - no : make this alarm not service affecting	alarms affect service or not <i>This element is only shown in detail mode.</i>
time	Parameter type: <Sys::timeInSecs> - the time (yyyy-mm-dd:hour:minutes:secs) - unit: UTC	time in seconds when alarm was updated <i>This element is only shown in detail mode.</i>
descript	Parameter type: <Alarm::AddInfoString> - additional alarm information	alarm description <i>This element is only shown in detail mode.</i>

101.134 show current alarm by filters

Command Description

show current alarms by filters

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm query olt-pon-util-tca [ (name) [ severity <Alarm::querySeverity> ] [ servaff
<Alarm::queryServAffect> ] [ pon <Gpon::PonId> ] ]
```

Command Parameters

Table 101.134-1 "show current alarm by filters" Resource Parameters

Resource Identifier	Type	Description
(name)	Format: (pon-t-txmcutilhi pon-t-txmcutilmd pon-t-txmcutillo pon-t-txtotutilhi pon-t-txtotutilmd pon-t-txtotutillo pon-t-rxtotutilhi pon-t-rxtotutilmd pon-t-rxtotutillo pon-t-dbacongperiodhi pon-t-dbacongperiodmd pon-t-dbacongperiodlo pon-t-txucdropfrmhi pon-t-txucdropfrmmd pon-t-txucdropfrmlo pon-t-txmcdropfrmhi pon-t-txmcdropfrmmd pon-t-txmcdropfrmlo pon-t-txbcdropfrmhi pon-t-txbcdropfrmmd pon-t-txbcdropfrmlo pon-t-rxtotdropfrmhi pon-t-rxtotdropfrmmd pon-t-rxtotdropfrmlo all) Possible values: - pon-t-txmcutilhi : pon util tx (downstream) multicast util	alarm name of olt-pon-util-tca

101 query current alarms by filters

Resource Identifier	Type	Description
	high threshold crossed - pon-t-txmcutilmd : pon util tx (downstream) multicast util medium threshold crossed - pon-t-txmcutillo : pon util tx (downstream) multicast util low threshold crossed - pon-t-txtotutilhi : pon util tx (downstream) total util high threshold crossed - pon-t-txtotutilmd : pon util tx (downstream) total util medium threshold crossed - pon-t-txtotutillo : pon util tx (downstream) total util low threshold crossed - pon-t-rxtotutilhi : pon util rx (upstream) total util high threshold crossed - pon-t-rxtotutilmd : pon util rx (upstream) total util medium threshold crossed - pon-t-rxtotutillo : pon util rx (upstream) total util low threshold crossed - pon-t-dbacongperiodhi : pon util rx (upstream) dbacongperiod high threshold crossed - pon-t-dbacongperiodmd : pon util rx (upstream) dbacongperiod medium threshold crossed - pon-t-dbacongperiodlo : pon util rx (upstream) dbacongperiod low threshold crossed - pon-t-txucdropfrmhi : pon util tx (downstream) unicast drop frame high threshold crossed - pon-t-txucdropfrmmd : pon util tx (downstream) unicast drop frame medium threshold crossed - pon-t-txucdropfrmlo : pon util tx (downstream) unicast drop frame low threshold crossed - pon-t-txmcdropfrmhi : pon util tx (downstream) multicast drop frame high threshold crossed - pon-t-txmcdropfrmmd : pon util tx (downstream) multicast drop frame medium threshold crossed - pon-t-txmcdropfrmlo : pon util tx (downstream) multicast drop frame low threshold crossed - pon-t-txbcdropfrmhi : pon util tx (downstream) broadcast drop frame high threshold crossed - pon-t-txbcdropfrmmd : pon util tx (downstream) broadcast drop frame medium threshold crossed - pon-t-txbcdropfrmlo : pon util tx (downstream) broadcast drop frame low threshold crossed - pon-t-rxtotdropfrmhi : pon util tx (upstream) total drop frame high threshold crossed - pon-t-rxtotdropfrmmd : pon util tx (upstream) total drop frame medium threshold crossed - pon-t-rxtotdropfrmlo : pon util tx (upstream) total drop frame low threshold crossed - all : OLT PON UTIL TCA related alarms	
severity	Parameter type: <Alarm::querySeverity> Format: (indeterminate warning minor major critical all) Possible values:	severity level of an alarm for reporting

Resource Identifier	Type	Description
	- indeterminate : alarm severity is indeterminate - warning : alarm severity is warning - minor : alarm severity is minor - major : alarm severity is major - critical : alarm severity is critical - all : all alarm severity	
servaff	Parameter type: <Alarm::queryServAffect> Format: (service-affecting noservice-affecting all) Possible values: - service-affecting : query alarm service affecting - noservice-affecting : query alarm not service affecting - all : query service affecting and not affecting alarms	serviceaffecting no serviceaffecting
pon	Parameter type: <Gpon::PonId> Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> x-pon : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::XPonId> 25g-pon : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::M25GPonId>) Possible values: - 25g-pon : 25g pon - x-pon : Xgs pon Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Eqpt::XPonId> - the XGS PON identifier Field type <Eqpt::M25GPonId> - the 25G PON identifier	gpon pon ifindex

Command Output

Table 101.134-2 "show current alarm by filters" Display parameters

Specific Information		
name	Type	Description
aidinfo	Parameter type: <Alarm::AddInfoString> - additional alarm information	alarm AID parameters <i>This element is only shown in detail mode.</i>
type	Parameter type: <Alarm::alarmIHUBType> (equipment eqpt-holder plug-in-unit atm custom e1 ima-group ima-link	type of the alarms that are active <i>This element is only shown in detail mode.</i>

101 query current alarms by filters

name	Type	Description
	redundancy shdsl ether-itf traffic-overflow qos-queue temporal spatial (software-mngt sw-mgmt) xdsl xdsl-ext xdsl-tca olt-gen eo-conv authentication bonding sfp shdsl-isam custom-ext-alarm plug-in-unit-ext sip-user-agent sip-plugin-unit sip-termination e1-sip-termination filetransfer external-device l2forward ether-tca ether-sfp megaco-media-gw megaco-sig-gw megaco-plug-unit megaco-term megaco-sig-lt eqpt-supplemental eqpt-holder-ext lsmredundancy sync mcsrc vlanport vect-line vect-board otdr sip-dial-plan sip-vsp sip-server bgp rip lag ihub-general vprn isis ospf ihub-l2forward vpls ihub-equip ihub-link eont-phyoam	

name	Type	Description
	ellid epon eont-services-lan eolt-ont-tca eont-sw-dl ldp mpls sdp epipe ihub-ipv6 pim li mgmt-sec-access bfd ai tr069serv ontsnmp bulk-sync protection-group ont sfu-sup soho-sup mdu-sup ont-ani sfu-sup2 soho-sup2 mdu-sup2 sfprssi eoltrssi cfm sfpe1t1-framer sfpe1t1-clock pppcc-engine-tca eth-cfm rsvp ihub-tca eth-ring efm-oam ont-loopdetect ont-video ont-ces ont-voip ont-video-ani ont-pwe ont-cese1 ont-xdsl ont-xdsl-tca ont-hpna ont-sip-agent-cfg ont-voip-cfg ont-mgc ont-ploam ont-gen ont-card ont-pots ont-lan ont-moca	

101 query current alarms by filters

name	Type	Description
	ont-tc-tca ont-moca-tca ont-l2uni-eth-tca olt-pon-tc-tca olt-pon-util-tca olt-chpr-util-tca olt-ont-tc-tca ont-tca ont-pots-supplemental sfu-ploam sfu-gen soho-ploam soho-gen mdu-ploam mdu-gen ont-veip ont-iphost alarm-table auto-switch channel-pair ont-cfg-dld olt-chpair-tc-tca hgu-tr069 eqpt-psu ont-protection secondary-megaco-term secondary-sip-term cas-r2-channel lldpmed pseudo-wire link-agg fcs-exceed e1t1-interface) Possible values: - equipment : equipment alarms - eqpt-holder : equipment holder alarms - plug-in-unit : plugin unit alarms - atm : ATM alarms - custom : customizable alarms - e1 : e1 alarms - ima-group : ima-group alarms - ima-link : ima-link alarms - redundancy : redundancy alarms - shdsl : shdsl alarms - ether-itf : ethernet interface alarms - traffic-overflow : Traffic overflow alarms - qos-queue : qos queue alarms - temporal : temporal alarms - spatial : spatial alarms - software-mngt : software management alarms - sw-mgmt : software management alarms - xdsl : xDSL alarms - xdsl-ext : other xDSL alarms - xdsl-tca : xDSL threshold cross alarms - olt-gen : OLT general alarms - eo-conv : E/O conversion related alarms - authentication : authentication related alarms	

name	Type	Description
	- bonding : bonding-group related alarms - sfp : SFP related alarms - shdsl-isam : shdsl isam alarms - custom-ext-alarm : customizable external alarms - plug-in-unit-ext : other plugin unit alarms - sip-user-agent : sip user agent related alarms - sip-plugin-unit : sip plug in unit related alarms - sip-termination : sip termination related alarms - e1-sip-termination : E1 sip termination related alarms - filetransfer : file transfer server alarms - external-device : external device related alarms - l2forward : l2forward related alarms - ether-tca : ethernet threshold cross alarms - ether-sfp : ethernet SFP related alarms - megaco-media-gw : megaco media gateway related alarms - megaco-sig-gw : megaco signaling gateway related alarms - megaco-plug-unit : megaco plug unit related alarms - megaco-term : megaco termination related alarms - megaco-sig-lt : megaco signaling lt related alarms - eqpt-supplemental : equipment supplemental alarms - eqpt-holder-ext : other equipment holder alarms - lsmredundancy : lsm redundancy alarms - sync : synce and bits alarms - mcsrc : multicast source alarms - vlanport : vlanport alarms - vect-line : xDSL vectoring line alarms - vect-board : xDSL vectoring board alarms - otdr : otdr alarms - sip-dial-plan : sip dial plan related alarms - sip-vsp : sip vsp related alarms - sip-server : sip server related alarms - bgp : bgp related alarms - rip : rip related alarms - lag : LAG related alarms - ihub-general : IHUB general related alarms - vprn : vprn related alarms - isis : isis related alarms - ospf : ospf related alarms - ihub-l2forward : ihub-l2forward alarms - vpls : vpls related alarms - ihub-equip : ihub-equip related alarms - ihub-link : ihub-link related alarms - eont-phyoam : eont phyoam related alarms - ellid : ellid related alarms - epon : epon related alarms - eont-services-lan : eon phyoam related alarms - eolt-ont-tca : eon phyoam related alarms - eont-sw-dl : eon phyoam related alarms - ldp : ldp related alarms - mpls : mpls related alarms - sdp : sdp related alarms - epipe : epipe related alarms - ihub-ipv6 : ihub-ipv6 related alarms - pim : pim related alarms - li : lawful intercept related alarms - mgmt-sec-access : management security related alarms - bfd : bfd related alarms	

101 query current alarms by filters

name	Type	Description
	- ai : Application Intelligence related alarms - tr069serv : tr069 server related alarms - ontsnmp : ont snmp related alarms - bulk-sync : bulk-sync related alarms - protection-group : port protection group related alarms - ont : ONT general supplemental related alarms - sfu-sup : SFU ONT general supplemental related alarms - soho-sup : SOHO ONT general supplemental related alarms - mdu-sup : MDU ONT general supplemental related alarms - ont-ani : ONT general supplemental 2 related alarms - sfu-sup2 : SFU ONT general supplemental 2 related alarms - soho-sup2 : SOHO ONT general supplemental 2 related alarms - mdu-sup2 : MDU ONT general supplemental 2 related alarms - sfrssi : SFP RSSI related alarms - eoltrssi : epon olt Sfp RSSI related alarms - cfm : Cfm related alarms - sfpe1t1-framer : SFP 2e1t1 framer alarms - sfpe1t1-clock : SFP 2e1t1 clock alarms - pppcc-engine-tca : PPPOE Cross Connect Engine TCA related alarm - eth-cfm : eth-cfm related alarms - rsvp : rsvp related alarms - ihub-tca : IHUB TCA related alarms - eth-ring : eth-ring related alarms - efm-oam : EFM-OAM related alarms - ont-loopdetect : ont loop detect related alarms - ont-video : ont services video related alarms - ont-ces : ont services ces related alarms - ont-voip : ont services voip related alarms - ont-video-ani : ont services video ani related alarms - ont-pwe : ont services pwe related alarms - ont-cese1 : ont services cese1 related alarms - ont-xdsl : ont services xdsl related alarms - ont-xdsl-tca : ont services xdsl tca related alarms - ont-hpna : ont hpna related alarms - ont-sip-agent-cfg : ont services voip sip agent config related alarms - ont-voip-cfg : ont services voip config related alarms - ont-mgc : ont mgc related alarms - ont-ploam : ONT PLOAM related alarms - ont-gen : ONT GENERAL related alarms - ont-card : ONT Subscriber Card related alarms - ont-pots : ONT Services POTS related alarms - ont-lan : ONT Services LAN related alarms - ont-moca : ONT MoCA related alarms - ont-tc-tca : ONT TC TCA related alarms - ont-moca-tca : ONT MoCA TCA related alarms - ont-l2uni-eth-tca : ONT L2 UNI Ethernet TCA related alarms - olt-pon-tc-tca : OLT PON TC TCA related alarms - olt-pon-util-tca : OLT PON utilization TCA related alarms - olt-chpr-util-tca : OLT channel-pair utilization TCA related alarms - olt-ont-tc-tca : OLT ONT TC TCA related alarms	

name	Type	Description
	- ont-tca : ONT TCA related alarms - ont-pots-supplemental : ONT POTS Supplemental related alarms - sfu-ploam : SFU ONT PLOAM related alarms - sfu-gen : SFU ONT general related alarms - soho-ploam : SOHO ONT PLOAM related alarms - soho-gen : SOHO ONT general related alarms - mdu-ploam : MDU ONT PLOAM related alarms - mdu-gen : MDU ONT general related alarms - ont-veip : ONT VEIP related alarms - ont-iphost : ONT IP HOST related alarms - alarm-table : alarm table related alarms - auto-switch : auto-switch related alarms - channel-pair : channel pair related alarms - ont-cfg-dld : ont configure file download related alarms - olt-chpair-tc-tca : OLT CHANNELPAIR TC TCA related alarms - hgu-tr069 : hgu tr069 related alarms - eqpt-psu : equipment psu alarms - ont-protection : ONT protection related alarms - secondary-megaco-term : secondary megaco termination related alarms - secondary-sip-term : secondary sip termination related alarms - cas-r2-channel : CAS R2 channel related alarms - lldpmed : lldpmed alarms - pseudo-wire : pseudo Wire related alarms - link-agg : Link aggregation related alarms - fcs-exceed : FCS auto-recovery related alarms - e1t1-interface : E1/T1 physical interfaces related alarms	
name	Parameter type: <Alarm::almtypeltponutiltcai> (pon-t-txmcutilhi pon-t-txmcutilmd pon-t-txmcutillo pon-t-txtotutilhi pon-t-txtotutilmd pon-t-txtotutillo pon-t-rxtotutilhi pon-t-rxtotutilmd pon-t-rxtotutillo pon-t-dbacongperiodhi pon-t-dbacongperiodmd pon-t-dbacongperiodlo pon-t-txucdropfrmhi pon-t-txucdropfrmmd pon-t-txucdropfrmlo pon-t-txmcdropfrmhi pon-t-txmcdropfrmmd pon-t-txmcdropfrmlo pon-t-txbcdropfrmhi pon-t-txbcdropfrmmd pon-t-txbcdropfrmlo pon-t-rxtotdropfrmhi pon-t-rxtotdropfrmmd pon-t-rxtotdropfrmlo all) Possible values:	alarm name that are active <i>This element is only shown in detail mode.</i>

101 query current alarms by filters

name	Type	Description
	- pon-t-txmcutilhi : pon util tx (downstream) multicast util high threshold crossed - pon-t-txmcutilmd : pon util tx (downstream) multicast util medium threshold crossed - pon-t-txmcutillo : pon util tx (downstream) multicast util low threshold crossed - pon-t-txtotutilhi : pon util tx (downstream) total util high threshold crossed - pon-t-txtotutilmd : pon util tx (downstream) total util medium threshold crossed - pon-t-txtotutillo : pon util tx (downstream) total util low threshold crossed - pon-t-rxtotutilhi : pon util rx (upstream) total util high threshold crossed - pon-t-rxtotutilmd : pon util rx (upstream) total util medium threshold crossed - pon-t-rxtotutillo : pon util rx (upstream) total util low threshold crossed - pon-t-dbacongperiodhi : pon util rx (upstream) dbacongperiod high threshold crossed - pon-t-dbacongperiodmd : pon util rx (upstream) dbacongperiod medium threshold crossed - pon-t-dbacongperiodlo : pon util rx (upstream) dbacongperiod low threshold crossed - pon-t-txucdropfrmhi : pon util tx (downstream) unicast drop frame high threshold crossed - pon-t-txucdropfrmmd : pon util tx (downstream) unicast drop frame medium threshold crossed - pon-t-txucdropfrmlo : pon util tx (downstream) unicast drop frame low threshold crossed - pon-t-txmcdropfrmhi : pon util tx (downstream) multicast drop frame high threshold crossed - pon-t-txmcdropfrmmd : pon util tx (downstream) multicast drop frame medium threshold crossed - pon-t-txmcdropfrmlo : pon util tx (downstream) multicast drop frame low threshold crossed - pon-t-txbcdropfrmhi : pon util tx (downstream) broadcast drop frame high threshold crossed - pon-t-txbcdropfrmmd : pon util tx (downstream) broadcast drop frame medium threshold crossed - pon-t-txbcdropfrmlo : pon util tx (downstream) broadcast drop frame low threshold crossed - pon-t-rxtotdropfrmhi : pon util tx (upstream) total drop frame high threshold crossed - pon-t-rxtotdropfrmmd : pon util tx (upstream) total drop frame medium threshold crossed - pon-t-rxtotdropfrmlo : pon util tx (upstream) total drop frame low threshold crossed - all : OLT PON UTIL TCA related alarms	
severity	Parameter type: <Alarm::AlarmSeverity> (indeterminate warning minor major critical) Possible values: - indeterminate : alarm severity is indeterminate	the alarms severity level <i>This element is only shown in detail mode.</i>

name	Type	Description
	- warning : alarm severity is warning - minor : alarm severity is minor - major : alarm severity is major - critical : alarm severity is critical	
servaff	Parameter type: <Alarm::alarmServAffect> ((service-affecting yes) (noservice-affecting no)) Possible values: - service-affecting : make this alarm service affecting - yes : make this alarm service affecting - noservice-affecting : make this alarm not service affecting - no : make this alarm not service affecting	alarms affect service or not <i>This element is only shown in detail mode.</i>
location	Parameter type: <Alarm::almLocation> (near-end far-end middle-end line null) Possible values: - near-end : alarm location is near - far-end : alarm location is far - middle-end : alarm location is middle - line : alarm location is line - null : alarm location not defined	alarm location: near, middle, far <i>This element is only shown in detail mode.</i>
time	Parameter type: <Sys::timeInSecs> - the time (yyyy-mm-dd:hour:minutes:secs) - unit: UTC	time in seconds when alarm was updated <i>This element is only shown in detail mode.</i>
direction	Parameter type: <Alarm::almDirection> (received transmit null) Possible values: - received : alarm is received - transmit : alarm is transmit - null : direction not defined	alarm direction: received or transmit <i>This element is only shown in detail mode.</i>
descript	Parameter type: <Alarm::AddInfoString> - additional alarm information	alarm description <i>This element is only shown in detail mode.</i>

101.135 show current alarm by filters

Command Description

show current alarms by filters

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm query channel-pair [ (name) [ severity <Alarm::querySeverity> ] [ servaff <Alarm::queryServAffect> ] [ channel-pair <Gpon::ChannelPairId> ] ]
```

Command Parameters

Table 101.135-1 "show current alarm by filters" Resource Parameters

Resource Identifier	Type	Description
(name)	Format: (chpr-com-fail chpr-tx-fail chpr-unprov-ont chpr-prov-mismatch chpr-loss-sig chpr-diagnostic chpr-loid-conflict chpr-loid-pwd-err chpr-stk-laser-dis chpr-sfp-mismatch chpr-rng-mismatch chpr-alien-test chpr-alien-detect chpr-deact-hightca chpr-deact-lowtca chpr-dp-integ all) Possible values: - chpr-com-fail : channel pair communication failure on olt - chpr-tx-fail : transmitter failure on channel pair - chpr-unprov-ont : unprovisioned ont on channel pair - chpr-prov-mismatch : mismatch btw equipment and provisioning pon attributes - chpr-loss-sig : channel pair loss of signal - chpr-diagnostic : channel pair diagnostic test active - chpr-loid-conflict : loid conflict ont on channel pair - chpr-loid-pwd-err : loid password error ont on channel pair	alarm name of channel-pair

Resource Identifier	Type	Description
	- chpr-stk-laser-dis : stuck laser disabled on channel pair - chpr-sfp-mismatch : channel pair sfp mismatch - chpr-rng-mismatch : channel pair ranging mismatch - chpr-alien-test : channel pair alien diagnostic test active - chpr-alien-detect : channel pair alien detect active - chpr-deact-hightca : channel pair deactivated ont hightca active - chpr-deact-lowtca : channel pair deactivated ont lowtca active - chpr-dp-integ : channel pair data path integrity failure - all : channel pair related alarms	
severity	Parameter type: <Alarm::querySeverity> Format: (indeterminate warning minor major critical all) Possible values: - indeterminate : alarm severity is indeterminate - warning : alarm severity is warning - minor : alarm severity is minor - major : alarm severity is major - critical : alarm severity is critical - all : all alarm severity	severity level of an alarm for reporting
servaff	Parameter type: <Alarm::queryServAffect> Format: (service-affecting noservice-affecting all) Possible values: - service-affecting : query alarm service affecting - noservice-affecting : query alarm not service affecting - all : query service affecting and not affecting alarms	serviceaffecting no serviceaffecting
channel-pair	Parameter type: <Gpon::ChannelPairId> Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::ChannelPairId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::ChannelPairId> - the channel pair identifier	specify which port the alarm occurred on

Command Output

Table 101.135-2 "show current alarm by filters" Display parameters

Specific Information		
name	Type	Description
aidinfo	Parameter type: <Alarm::AddInfoString> - additional alarm information	alarm AID parameters <i>This element is only shown in detail mode.</i>

101 query current alarms by filters

name	Type	Description
type	Parameter type: <Alarm::alarmIHUBType> (equipment eqpt-holder plug-in-unit atm custom e1 ima-group ima-link redundancy shdsl ether-itf traffic-overflow qos-queue temporal spatial (software-mngt sw-mgmt) xdsl xdsl-ext xdsl-tca olt-gen eo-conv authentication bonding sfp shdsl-isam custom-ext-alarm plug-in-unit-ext sip-user-agent sip-plugin-unit sip-termination e1-sip-termination filetransfer external-device l2forward ether-tca ether-sfp megaco-media-gw megaco-sig-gw megaco-plug-unit megaco-term megaco-sig-lt eqpt-supplemental eqpt-holder-ext lsmredundancy sync mcsrc vlanport vect-line vect-board otdr sip-dial-plan sip-vsp sip-server bgp rip lag)	type of the alarms that are active <i>This element is only shown in detail mode.</i>

name	Type	Description
	ihub-general	
	vprn	
	isis	
	ospf	
	ihub-l2forward	
	vpls	
	ihub-equip	
	ihub-link	
	eont-phyoam	
	ellid	
	epon	
	eont-services-lan	
	eolt-ont-tca	
	eont-sw-dl	
	ldp	
	mpls	
	sdp	
	epipe	
	ihub-ipv6	
	pim	
	li	
	mgmt-sec-access	
	bfd	
	ai	
	tr069serv	
	ontsnmp	
	bulk-sync	
	protection-group	
	ont	
	sfu-sup	
	soho-sup	
	mdu-sup	
	ont-ani	
	sfu-sup2	
	soho-sup2	
	mdu-sup2	
	sfprssi	
	eoltrssi	
	cfm	
	sfpe1t1-framer	
	sfpe1t1-clock	
	pppcc-engine-tca	
	eth-cfm	
	rsvp	
	ihub-tca	
	eth-ring	
	efm-oam	
	ont-loopdetect	
	ont-video	
	ont-ces	
	ont-voip	
	ont-video-ani	
	ont-pwe	
	ont-cese1	
	ont-xdsl	
	ont-xdsl-tca	
	ont-hpna	

101 query current alarms by filters

name	Type	Description
	ont-sip-agent-cfg ont-voip-cfg ont-mgc ont-ploam ont-gen ont-card ont-pots ont-lan ont-moca ont-tc-tca ont-moca-tca ont-l2uni-eth-tca olt-pon-tc-tca olt-pon-util-tca olt-chpr-util-tca olt-ont-tc-tca ont-tca ont-pots-supplemental sfu-ploam sfu-gen soho-ploam soho-gen mdu-ploam mdu-gen ont-veip ont-iphost alarm-table auto-switch channel-pair ont-cfg-dld olt-chpair-tc-tca hgu-tr069 eqpt-psu ont-protection secondary-megaco-term secondary-sip-term cas-r2-channel lldpmed pseudo-wire link-agg fcs-exceed e1t1-interface) Possible values: - equipment : equipment alarms - eqpt-holder : equipment holder alarms - plug-in-unit : plugin unit alarms - atm : ATM alarms - custom : customizable alarms - e1 : e1 alarms - ima-group : ima-group alarms - ima-link : ima-link alarms - redundancy : redundancy alarms - shdsl : shdsl alarms - ether-itf : ethernet interface alarms - traffic-overflow : Traffic overflow alarms - qos-queue : qos queue alarms - temporal : temporal alarms	

name	Type	Description
	- spatial : spatial alarms - software-mngt : software management alarms - sw-mgmt : software management alarms - xdsl : xDSL alarms - xdsl-ext : other xDSL alarms - xdsl-tca : xDSL threshold cross alarms - olt-gen : OLT general alarms - eo-conv : E/O conversion related alarms - authentication : authentication related alarms - bonding : bonding-group related alarms - sfp : SFP related alarms - shdsl-isam : shdsl isam alarms - custom-ext-alarm : customizable external alarms - plug-in-unit-ext : other plugin unit alarms - sip-user-agent : sip user agent related alarms - sip-plugin-unit : sip plug in unit related alarms - sip-termination : sip termination related alarms - e1-sip-termination : E1 sip termination related alarms - filetransfer : file transfer server alarms - external-device : external device related alarms - l2forward : l2forward related alarms - ether-tca : ethernet threshold cross alarms - ether-sfp : ethernet SFP related alarms - megaco-media-gw : megaco media gateway related alarms - megaco-sig-gw : megaco signaling gateway related alarms - megaco-plug-unit : megaco plug unit related alarms - megaco-term : megaco termination related alarms - megaco-sig-lt : megaco signaling lt related alarms - eqpt-supplemental : equipment supplemental alarms - eqpt-holder-ext : other equipment holder alarms - lsmredundancy : lsm redundancy alarms - sync : synce and bits alarms - mcsrc : multicast source alarms - vlanport : vlanport alarms - vect-line : xDSL vectoring line alarms - vect-board : xDSL vectoring board alarms - otdr : otdr alarms - sip-dial-plan : sip dial plan related alarms - sip-vsp : sip vsp related alarms - sip-server : sip server related alarms - bgp : bgp related alarms - rip : rip related alarms - lag : LAG related alarms - ihub-general : IHUB general related alarms - vprn : vprn related alarms - isis : isis related alarms - ospf : ospf related alarms - ihub-l2forward : ihub-l2forward alarms - vpls : vpls related alarms - ihub-equip : ihub-equip related alarms - ihub-link : ihub-link related alarms - eont-phyoam : eont phyoam related alarms - ellid : ellid related alarms - epon : epon related alarms - eont-services-lan : eon phyoam related alarms - eolt-ont-tca : eon phyoam related alarms - eont-sw-dl : eon phyoam related alarms	

101 query current alarms by filters

name	Type	Description
	- ldp : ldp related alarms - mpls : mpls related alarms - sdp : sdp related alarms - epipe : epipe related alarms - ihub-ipv6 : ihub-ipv6 related alarms - pim : pim related alarms - li : lawful intercept related alarms - mgmt-sec-access : management security related alarms - bfd : bfd related alarms - ai : Application Intelligence related alarms - tr069serv : tr069 server related alarms - ontsnmp : ont snmp related alarms - bulk-sync : bulk-sync related alarms - protection-group : port protection group related alarms - ont : ONT general supplemental related alarms - sfu-sup : SFU ONT general supplemental related alarms - soho-sup : SOHO ONT general supplemental related alarms - mdu-sup : MDU ONT general supplemental related alarms - ont-ani : ONT general supplemental 2 related alarms - sfu-sup2 : SFU ONT general supplemental 2 related alarms - soho-sup2 : SOHO ONT general supplemental 2 related alarms - mdu-sup2 : MDU ONT general supplemental 2 related alarms - sfprssi : SFP RSSI related alarms - eoltrssi : epon olt Sfp RSSI related alarms - cfm : Cfm related alarms - sfpe1t1-framer : SFP 2e1t1 framer alarms - sfpe1t1-clock : SFP 2e1t1 clock alarms - pppcc-engine-tca : PPPOE Cross Connect Engine TCA related alarm - eth-cfm : eth-cfm related alarms - rsvp : rsvp related alarms - ihub-tca : IHUB TCA related alarms - eth-ring : eth-ring related alarms - efm-oam : EFM-OAM related alarms - ont-loopdetect : ont loop detect related alarms - ont-video : ont services video related alarms - ont-ces : ont services ces related alarms - ont-voip : ont services voip related alarms - ont-video-ani : ont services video ani related alarms - ont-pwe : ont services pwe related alarms - ont-cese1 : ont services cese1 related alarms - ont-xdsl : ont services xdsl related alarms - ont-xdsl-tca : ont services xdsl tca related alarms - ont-hpna : ont hpna related alarms - ont-sip-agent-cfg : ont services voip sip agent config related alarms - ont-voip-cfg : ont services voip config related alarms - ont-mgc : ont mgc related alarms - ont-ploam : ONT PLOAM related alarms - ont-gen : ONT GENERAL related alarms - ont-card : ONT Subscriber Card related alarms - ont-pots : ONT Services POTS related alarms - ont-lan : ONT Services LAN related alarms - ont-moca : ONT MoCA related alarms	

name	Type	Description
	- ont-tc-tca : ONT TC TCA related alarms - ont-moca-tca : ONT MoCA TCA related alarms - ont-l2uni-eth-tca : ONT L2 UNI Ethernet TCA related alarms - olt-pon-tc-tca : OLT PON TC TCA related alarms - olt-pon-util-tca : OLT PON utilization TCA related alarms - olt-chpr-util-tca : OLT channel-pair utilization TCA related alarms - olt-ont-tc-tca : OLT ONT TC TCA related alarms - ont-tca : ONT TCA related alarms - ont-pots-supplemental : ONT POTS Supplemental related alarms - sfu-ploam : SFU ONT PLOAM related alarms - sfu-gen : SFU ONT general related alarms - soho-ploam : SOHO ONT PLOAM related alarms - soho-gen : SOHO ONT general related alarms - mdu-ploam : MDU ONT PLOAM related alarms - mdu-gen : MDU ONT general related alarms - ont-veip : ONT VEIP related alarms - ont-iphost : ONT IP HOST related alarms - alarm-table : alarm table related alarms - auto-switch : auto-switch related alarms - channel-pair : channel pair related alarms - ont-cfg-dld : ont configure file download related alarms - olt-chpair-tc-tca : OLT CHANNELPAIR TC TCA related alarms - hgu-tr069 : hgu tr069 related alarms - eqpt-psu : equipment psu alarms - ont-protection : ONT protection related alarms - secondary-megaco-term : secondary megaco termination related alarms - secondary-sip-term : secondary sip termination related alarms - cas-r2-channel : CAS R2 channel related alarms - lldpmed : lldpmed alarms - pseudo-wire : pseudo Wire related alarms - link-agg : Link aggregation related alarms - fcs-exceed : FCS auto-recovery related alarms - e1t1-interface : E1/T1 physical interfaces related alarms	
name	Parameter type: <Alarm::almtypeChannelpairhub> (chpr-com-fail chpr-tx-fail chpr-unprov-ont chpr-prov-mismatch chpr-loss-sig chpr-diagnostic chpr-loid-conflict chpr-loid-pwd-err chpr-stk-laser-dis chpr-sfp-mismatch chpr-rng-mismatch chpr-alien-test chpr-alien-detect chpr-deact-hightca chpr-deact-lowtca chpr-dp-integ all)	alarm name that are active <i>This element is only shown in detail mode.</i>

101 query current alarms by filters

name	Type	Description
	Possible values: - chpr-com-fail : channel pair communication failure on olt - chpr-tx-fail : transmitter failure on channel pair - chpr-unprov-ont : unprovisioned ont on channel pair - chpr-prov-mismatch : mismatch btw equipment and provisioning pon attributes - chpr-loss-sig : channel pair loss of signal - chpr-diagnostic : channel pair diagnostic test active - chpr-loid-conflict : loid conflict ont on channel pair - chpr-loid-pwd-err : loid password error ont on channel pair - chpr-stk-laser-dis : stuck laser disabled on channel pair - chpr-sfp-mismatch : channel pair sfp mismatch - chpr-rng-mismatch : channel pair ranging mismatch - chpr-alien-test : channel pair alien diagnostic test active - chpr-alien-detect : channel pair alien detect active - chpr-deact-hightca : channel pair deactivated ont hightca active - chpr-deact-lowtca : channel pair deactivated ont lowtca active - chpr-dp-integ : channel pair data path integrity failure - all : channel pair related alarms	
severity	Parameter type: <Alarm::AlarmSeverity> (indeterminate warning minor major critical) Possible values: - indeterminate : alarm severity is indeterminate - warning : alarm severity is warning - minor : alarm severity is minor - major : alarm severity is major - critical : alarm severity is critical	the alarms severity level <i>This element is only shown in detail mode.</i>
servaff	Parameter type: <Alarm::alarmServAffect> ((service-affecting yes) (noservice-affecting no)) Possible values: - service-affecting : make this alarm service affecting - yes : make this alarm service affecting - noservice-affecting : make this alarm not service affecting - no : make this alarm not service affecting	alarms affect service or not <i>This element is only shown in detail mode.</i>
time	Parameter type: <Sys::timeInSecs> - the time (yyyy-mm-dd:hour:minutes:secs) - unit: UTC	time in seconds when alarm was updated <i>This element is only shown in detail mode.</i>
descript	Parameter type: <Alarm::AddInfoString> - additional alarm information	alarm description <i>This element is only shown in detail mode.</i>

101.136 show current alarm by filters

Command Description

show current alarms by filters

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm query olt-chpr-util-tca [ (name) [ severity <Alarm::querySeverity> ] [ servaff
<Alarm::queryServAffect> ] [ channel-pair <Gpon::ChannelPairId> ] ]
```

Command Parameters

Table 101.136-1 "show current alarm by filters" Resource Parameters

Resource Identifier	Type	Description
(name)	Format: (chpr-t-txmcutilhi chpr-t-txmcutilmd chpr-t-txmcutillo chpr-t-txtotutilhi chpr-t-txtotutilmd chpr-t-txtotutillo chpr-t-rxtotutilhi chpr-t-rxtotutilmd chpr-t-rxtotutillo chpr-t-dbacongperiodhi chpr-t-dbacongperiodmd chpr-t-dbacongperiodlo chpr-t-txucdropfrmhi chpr-t-txucdropfrmmmd chpr-t-txucdropfrmlo chpr-t-txmcdropfrmhi chpr-t-txmcdropfrmmmd chpr-t-txmcdropfrmlo chpr-t-txbcdropfrmhi chpr-t-txbcdropfrmmmd chpr-t-txbcdropfrmlo chpr-t-rxtotdropfrmhi chpr-t-rxtotdropfrmmmd chpr-t-rxtotdropfrmlo all) Possible values: - chpr-t-txmcutilhi : channel-pair utilization tx (downstream)	alarm name of olt channel-pair utilization tca

101 query current alarms by filters

Resource Identifier	Type	Description
	multicast high threshold crossed - chpr-t-txmcutilmd : channel-pair utilization tx (downstream) multicast medium threshold crossed - chpr-t-txmcutillo : channel-pair utilization tx (downstream) multicast low threshold crossed - chpr-t-txtotutilhi : channel-pair utilization tx (downstream) total high threshold crossed - chpr-t-txtotutilmd : channel-pair utilization tx (downstream) total medium threshold crossed - chpr-t-txtotutillo : channel-pair utilization tx (downstream) total low threshold crossed - chpr-t-rxtotutilhi : channel-pair utilization rx (upstream) total high threshold crossed - chpr-t-rxtotutilmd : channel-pair utilization rx (upstream) total medium threshold crossed - chpr-t-rxtotutillo : channel-pair utilization rx (upstream) total low threshold crossed - chpr-t-dbacongperiodhi: channel-pair utilization rx (upstream) dbacongperiod high threshold crossed - chpr-t-dbacongperiodmd: channel-pair utilization rx (upstream) dbacongperiod medium threshold crossed - chpr-t-dbacongperiodlo: channel-pair utilization rx (upstream) dbacongperiod low threshold crossed - chpr-t-txucdropfrmhi : channel-pair utilization tx (downstream) unicast drop frame high threshold crossed - chpr-t-txucdropfrmmd : channel-pair utilization tx (downstream) unicast drop frame medium threshold crossed - chpr-t-txucdropfrmlo : channel-pair utilization tx (downstream) unicast drop frame low threshold crossed - chpr-t-txmcdropfrmhi : channel-pair utilization tx (downstream) multicast drop frame high threshold crossed - chpr-t-txmcdropfrmmd : channel-pair utilization tx (downstream) multicast drop frame medium threshold crossed - chpr-t-txmcdropfrmlo : channel-pair utilization tx (downstream) multicast drop frame low threshold crossed - chpr-t-txbcdropfrmhi : channel-pair utilization tx (downstream) broadcast drop frame high threshold crossed - chpr-t-txbcdropfrmmd : channel-pair utilization tx (downstream) broadcast drop frame medium threshold crossed - chpr-t-txbcdropfrmlo : channel-pair utilization tx (downstream) broadcast drop frame low threshold crossed - chpr-t-rxtotdropfrmhi : channel-pair utilization rx (upstream) total drop frame high threshold crossed - chpr-t-rxtotdropfrmmd : channel-pair utilization rx (upstream) total drop frame medium threshold crossed - chpr-t-rxtotdropfrmlo : channel-pair utilization rx (upstream) total drop frame low threshold crossed - all : OLT channel-pair utilization TCA related alarms	
severity	Parameter type: <Alarm::querySeverity> Format: - indeterminate - warning - minor - major - critical	severity level of an alarm for reporting

Resource Identifier	Type	Description
	all) Possible values: - indeterminate : alarm severity is indeterminate - warning : alarm severity is warning - minor : alarm severity is minor - major : alarm severity is major - critical : alarm severity is critical - all : all alarm severity	
servaff	Parameter type: <Alarm::queryServAffect> Format: (service-affecting noservice-affecting all) Possible values: - service-affecting : query alarm service affecting - noservice-affecting : query alarm not service affecting - all : query service affecting and not affecting alarms	serviceaffecting no serviceaffecting
channel-pair	Parameter type: <Gpon::ChannelPairId> Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::ChannelPairId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::ChannelPairId> - the channel pair identifier	specify which port the alarm occurred on

Command Output

Table 101.136-2 "show current alarm by filters" Display parameters

Specific Information		
name	Type	Description
aidinfo	Parameter type: <Alarm::AddInfoString> - additional alarm information	alarm AID parameters <i>This element is only shown in detail mode.</i>
type	Parameter type: <Alarm::alarmIHUBType> (equipment eqpt-holder plug-in-unit atm custom e1 ima-group ima-link redundancy shdsl ether-itf traffic-overflow qos-queue temporal spatial (software-mngt sw-mgmt) xdsl	type of the alarms that are active <i>This element is only shown in detail mode.</i>

101 query current alarms by filters

name	Type	Description
	xds1-ext xds1-tca olt-gen eo-conv authentication bonding sfp shdsl-isam custom-ext-alarm plug-in-unit-ext sip-user-agent sip-plugin-unit sip-termination e1-sip-termination filetransfer external-device l2forward ether-tca ether-sfp megaco-media-gw megaco-sig-gw megaco-plug-unit megaco-term megaco-sig-lt eqpt-supplemental eqpt-holder-ext lsmredundancy sync mcsrc vlanport vect-line vect-board otdr sip-dial-plan sip-vsp sip-server bgp rip lag ihub-general vprn isis ospf ihub-l2forward vpls ihub-equip ihub-link eont-phyoam ellid epon eont-services-lan eolt-ont-tca eont-sw-dl ldp mpls sdp epipe	

name	Type	Description
	ihub-ipv6	
	pim	
	li	
	mgmt-sec-access	
	bfd	
	ai	
	tr069serv	
	ontsnmp	
	bulk-sync	
	protection-group	
	ont	
	sfu-sup	
	soho-sup	
	mdu-sup	
	ont-ani	
	sfu-sup2	
	soho-sup2	
	mdu-sup2	
	sfprssi	
	eoltrssi	
	cfm	
	sfpe1t1-framer	
	sfpe1t1-clock	
	pppcc-engine-tca	
	eth-cfm	
	rsvp	
	ihub-tca	
	eth-ring	
	efm-oam	
	ont-loopdetect	
	ont-video	
	ont-ces	
	ont-voip	
	ont-video-ani	
	ont-pwe	
	ont-cese1	
	ont-xdsl	
	ont-xdsl-tca	
	ont-hpna	
	ont-sip-agent-cfg	
	ont-voip-cfg	
	ont-mgc	
	ont-ploam	
	ont-gen	
	ont-card	
	ont-pots	
	ont-lan	
	ont-moca	
	ont-tc-tca	
	ont-moca-tca	
	ont-l2uni-eth-tca	
	olt-pon-tc-tca	
	olt-pon-util-tca	
	olt-chpr-util-tca	
	olt-ont-tc-tca	
	ont-tca	
	ont-pots-supplemental	

101 query current alarms by filters

name	Type	Description
	sfu-ploam sfu-gen soho-ploam soho-gen mdu-ploam mdu-gen ont-veip ont-iphost alarm-table auto-switch channel-pair ont-cfg-dld olt-chpair-tc-tca hgu-tr069 eqpt-psu ont-protection secondary-megaco-term secondary-sip-term cas-r2-channel lldpmed pseudo-wire link-agg fcs-exceed e1t1-interface) Possible values: - equipment : equipment alarms - eqpt-holder : equipment holder alarms - plug-in-unit : plugin unit alarms - atm : ATM alarms - custom : customizable alarms - e1 : e1 alarms - ima-group : ima-group alarms - ima-link : ima-link alarms - redundancy : redundancy alarms - shdsl : shdsl alarms - ether-itf : ethernet interface alarms - traffic-overflow : Traffic overflow alarms - qos-queue : qos queue alarms - temporal : temporal alarms - spatial : spatial alarms - software-mngt : software management alarms - sw-mgmt : software management alarms - xdsl : xDSL alarms - xdsl-ext : other xDSL alarms - xdsl-tca : xDSL threshold cross alarms - olt-gen : OLT general alarms - eo-conv : E/O conversion related alarms - authentication : authentication related alarms - bonding : bonding-group related alarms - sfp : SFP related alarms - shdsl-isam : shdsl isam alarms - custom-ext-alarm : customizable external alarms - plug-in-unit-ext : other plugin unit alarms - sip-user-agent : sip user agent related alarms - sip-plugin-unit : sip plug in unit related alarms - sip-termination : sip termination related alarms - e1-sip-termination : E1 sip termination related alarms	

name	Type	Description
	- filetransfer : file transfer server alarms - external-device : external device related alarms - l2forward : l2forward related alarms - ether-tca : ethernet threshold cross alarms - ether-sfp : ethernet SFP related alarms - megaco-media-gw : megaco media gateway related alarms - megaco-sig-gw : megaco signaling gateway related alarms - megaco-plug-unit : megaco plug unit related alarms - megaco-term : megaco termination related alarms - megaco-sig-lt : megaco signaling lt related alarms - eqpt-supplemental : equipment supplemental alarms - eqpt-holder-ext : other equipment holder alarms - lsmredundancy : lsm redundancy alarms - sync : synce and bits alarms - mcsrc : multicast source alarms - vlanport : vlanport alarms - vect-line : xDSL vectoring line alarms - vect-board : xDSL vectoring board alarms - otdr : otdr alarms - sip-dial-plan : sip dial plan related alarms - sip-vsp : sip vsp related alarms - sip-server : sip server related alarms - bgp : bgp related alarms - rip : rip related alarms - lag : LAG related alarms - ihub-general : IHUB general related alarms - vprn : vprn related alarms - isis : isis related alarms - ospf : ospf related alarms - ihub-l2forward : ihub-l2forward alarms - vpls : vpls related alarms - ihub-equip : ihub-equip related alarms - ihub-link : ihub-link related alarms - eont-phyoam : eont phyoam related alarms - ellid : ellid related alarms - epon : epon related alarms - eont-services-lan : eon phyoam related alarms - eolt-ont-tca : eon phyoam related alarms - eont-sw-dl : eon phyoam related alarms - ldp : ldp related alarms - mpls : mpls related alarms - sdp : sdp related alarms - epipe : epipe related alarms - ihub-ipv6 : ihub-ipv6 related alarms - pim : pim related alarms - li : lawful intercept related alarms - mgmt-sec-access : management security related alarms - bfd : bfd related alarms - ai : Application Intelligence related alarms - tr069serv : tr069 server related alarms - ontsnmp : ont snmp related alarms - bulk-sync : bulk-sync related alarms - protection-group : port protection group related alarms - ont : ONT general supplemental related alarms - sfu-sup : SFU ONT general supplemental related alarms - soho-sup : SOHO ONT general supplemental related alarms	

101 query current alarms by filters

name	Type	Description
	- mdu-sup : MDU ONT general supplemental related alarms - ont-ani : ONT general supplemental 2 related alarms - sfu-sup2 : SFU ONT general supplemental 2 related alarms - soho-sup2 : SOHO ONT general supplemental 2 related alarms - mdu-sup2 : MDU ONT general supplemental 2 related alarms - sfprssi : SFP RSSI related alarms - eoltrssi : epon olt Sfp RSSI related alarms - cfm : Cfm related alarms - sfpe1t1-framer : SFP 2e1t1 framer alarms - sfpe1t1-clock : SFP 2e1t1 clock alarms - pppcc-engine-tca : PPPOE Cross Connect Engine TCA related alarm - eth-cfm : eth-cfm related alarms - rsvp : rsvp related alarms - ihub-tca : IHUB TCA related alarms - eth-ring : eth-ring related alarms - efm-oam : EFM-OAM related alarms - ont-loopdetect : ont loop detect related alarms - ont-video : ont services video related alarms - ont-ces : ont services ces related alarms - ont-voip : ont services voip related alarms - ont-video-ani : ont services video ani related alarms - ont-pwe : ont services pwe related alarms - ont-cese1 : ont services cese1 related alarms - ont-xdsl : ont services xdsl related alarms - ont-xdsl-tca : ont services xdsl tca related alarms - ont-hpna : ont hpna related alarms - ont-sip-agent-cfg : ont services voip sip agent config related alarms - ont-voip-cfg : ont services voip config related alarms - ont-mgc : ont mgc related alarms - ont-ploam : ONT PLOAM related alarms - ont-gen : ONT GENERAL related alarms - ont-card : ONT Subscriber Card related alarms - ont-pots : ONT Services POTS related alarms - ont-lan : ONT Services LAN related alarms - ont-moca : ONT MoCA related alarms - ont-tc-tca : ONT TC TCA related alarms - ont-moca-tca : ONT MoCA TCA related alarms - ont-l2uni-eth-tca : ONT L2 UNI Ethernet TCA related alarms - olt-pon-tc-tca : OLT PON TC TCA related alarms - olt-pon-util-tca : OLT PON utilization TCA related alarms - olt-chpr-util-tca : OLT channel-pair utilization TCA related alarms - olt-ont-tc-tca : OLT ONT TC TCA related alarms - ont-tca : ONT TCA related alarms - ont-pots-supplemental : ONT POTS Supplemental related alarms - sfu-ploam : SFU ONT PLOAM related alarms - sfu-gen : SFU ONT general related alarms - soho-ploam : SOHO ONT PLOAM related alarms - soho-gen : SOHO ONT general related alarms - mdu-ploam : MDU ONT PLOAM related alarms - mdu-gen : MDU ONT general related alarms	

name	Type	Description
	- ont-veip : ONT VEIP related alarms - ont-iphost : ONT IP HOST related alarms - alarm-table : alarm table related alarms - auto-switch : auto-switch related alarms - channel-pair : channel pair related alarms - ont-cfg-dld : ont configure file download related alarms - olt-chpair-tc-tca : OLT CHANNELPAIR TC TCA related alarms - hgu-tr069 : hgu tr069 related alarms - eqpt-psu : equipment psu alarms - ont-protection : ONT protection related alarms - secondary-megaco-term : secondary megaco termination related alarms - secondary-sip-term : secondary sip termination related alarms - cas-r2-channel : CAS R2 channel related alarms - lldpmed : lldpmed alarms - pseudo-wire : pseudo Wire related alarms - link-agg : Link aggregation related alarms - fcs-exceed : FCS auto-recovery related alarms - e1t1-interface : E1/T1 physical interfaces related alarms	
name	Parameter type: <Alarm::almtypeOltchprutiltcaihib> (chpr-t-txmcutilhi chpr-t-txmcutilm chpr-t-txmcutillo chpr-t-txtotutilhi chpr-t-txtotutilmd chpr-t-txtotutillo chpr-t-rxtotutilhi chpr-t-rxtotutilmd chpr-t-rxtotutillo chpr-t-dbacongperiodhi chpr-t-dbacongperiodmd chpr-t-dbacongperiodlo chpr-t-txucdropfrmhi chpr-t-txucdropfrmmd chpr-t-txucdropfrmlo chpr-t-txmcdropfrmhi chpr-t-txmcdropfrmmd chpr-t-txmcdropfrmlo chpr-t-txbcdropfrmhi chpr-t-txbcdropfrmmd chpr-t-txbcdropfrmlo chpr-t-rxtotdropfrmhi chpr-t-rxtotdropfrmmd chpr-t-rxtotdropfrmlo all) Possible values: - chpr-t-txmcutilhi : channel-pair utilization tx (downstream) multicast high threshold crossed - chpr-t-txmcutilm : channel-pair utilization tx (downstream) multicast medium threshold crossed - chpr-t-txmcutillo : channel-pair utilization tx (downstream) multicast low threshold crossed - chpr-t-txtotutilhi : channel-pair utilization tx (downstream) total high threshold crossed - chpr-t-txtotutilmd : channel-pair utilization tx	alarm name that are active <i>This element is only shown in detail mode.</i>

101 query current alarms by filters

name	Type	Description
	(downstream) total medium threshold crossed - chpr-t-txtotutillo : channel-pair utilization tx (downstream) total low threshold crossed - chpr-t-rxtotutilhi : channel-pair utilization rx (upstream) total high threshold crossed - chpr-t-rxtotutilmd : channel-pair utilization rx (upstream) total medium threshold crossed - chpr-t-rxtotutillo : channel-pair utilization rx (upstream) total low threshold crossed - chpr-t-dbacongperiodhi: channel-pair utilization rx (upstream) dbacongperiod high threshold crossed - chpr-t-dbacongperiodmd: channel-pair utilization rx (upstream) dbacongperiod medium threshold crossed - chpr-t-dbacongperiodlo: channel-pair utilization rx (upstream) dbacongperiod low threshold crossed - chpr-t-txucdropfrmhi : channel-pair utilization tx (downstream) unicast drop frame high threshold crossed - chpr-t-txucdropfrmmd : channel-pair utilization tx (downstream) unicast drop frame medium threshold crossed - chpr-t-txucdropfrmlo : channel-pair utilization tx (downstream) unicast drop frame low threshold crossed - chpr-t-txmcdropfrmhi : channel-pair utilization tx (downstream) multicast drop frame high threshold crossed - chpr-t-txmcdropfrmmd : channel-pair utilization tx (downstream) multicast drop frame medium threshold crossed - chpr-t-txmcdropfrmlo : channel-pair utilization tx (downstream) multicast drop frame low threshold crossed - chpr-t-txbcdropfrmhi : channel-pair utilization tx (downstream) broadcast drop frame high threshold crossed - chpr-t-txbcdropfrmmd : channel-pair utilization tx (downstream) broadcast drop frame medium threshold crossed - chpr-t-txbcdropfrmlo : channel-pair utilization tx (downstream) broadcast drop frame low threshold crossed - chpr-t-rxtotdropfrmhi : channel-pair utilization rx (upstream) total drop frame high threshold crossed - chpr-t-rxtotdropfrmmd : channel-pair utilization rx (upstream) total drop frame medium threshold crossed - chpr-t-rxtotdropfrmlo : channel-pair utilization rx (upstream) total drop frame low threshold crossed - all : OLT channel-pair utilization TCA related alarms	
severity	Parameter type: <Alarm::AlarmSeverity> (indeterminate warning minor major critical) Possible values: - indeterminate : alarm severity is indeterminate - warning : alarm severity is warning - minor : alarm severity is minor - major : alarm severity is major - critical : alarm severity is critical	the alarms severity level <i>This element is only shown in detail mode.</i>
servaff	Parameter type: <Alarm::alarmServAffect> ((service-affecting yes) (noservice-affecting no))	alarms affect service or not <i>This element is only shown in detail mode.</i>

name	Type	Description
	Possible values: - service-affecting : make this alarm service affecting - yes : make this alarm service affecting - noservice-affecting : make this alarm not service affecting - no : make this alarm not service affecting	
location	Parameter type: <Alarm::almLocation> (near-end far-end middle-end line null) Possible values: - near-end : alarm location is near - far-end : alarm location is far - middle-end : alarm location is middle - line : alarm location is line - null : alarm location not defined	alarm location: near, middle, far <i>This element is only shown in detail mode.</i>
time	Parameter type: <Sys::timeInSecs> - the time (yyyy-mm-dd:hour:minutes:secs) - unit: UTC	time in seconds when alarm was updated <i>This element is only shown in detail mode.</i>
direction	Parameter type: <Alarm::almDirection> (received transmit null) Possible values: - received : alarm is received - transmit : alarm is transmit - null : direction not defined	alarm direction: received or transmit <i>This element is only shown in detail mode.</i>
descript	Parameter type: <Alarm::AddInfoString> - additional alarm information	alarm description <i>This element is only shown in detail mode.</i>

101.137 show current alarm by filters

Command Description

show current alarms by filters

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm query ont-cfg-dld [ (name) [ severity <Alarm::querySeverity> ] [ servaff <Alarm::queryServAffect> ]
[ ont <Gpon::OntIndex> ] ]
```

Command Parameters

Table 101.137-1 "show current alarm by filters" Resource Parameters

Resource Identifier	Type	Description
(name)	Format: (cfg-dld-fail cfg-act-fail cfg-dld-ip cfg-ver-mismatch cfg-file-missing cfg-verctrl-err cfg-not-supported all) Possible values: - cfg-dld-fail : download of configure file to ont failed - cfg-act-fail : activate the passive config file failed - cfg-dld-ip : ont configure file download in progress - cfg-ver-mismatch : the planned configure file does not match the active configure file - cfg-file-missing : ont configure file missing or has an error - cfg-verctrl-err : ont configure file version control error - cfg-not-supported : ont not support the configure file download function - all : ont configure file download related alarms	alarm name of ont-cfg-dld
severity	Parameter type: <Alarm::querySeverity> Format: (indeterminate warning minor major critical all)	severity level of an alarm for reporting

Resource Identifier	Type	Description
	Possible values: - indeterminate : alarm severity is indeterminate - warning : alarm severity is warning - minor : alarm severity is minor - major : alarm severity is major - critical : alarm severity is critical - all : all alarm severity	
servaff	Parameter type: <Alarm::queryServAffect> Format: (service-affecting noservice-affecting all) Possible values: - service-affecting : query alarm service affecting - noservice-affecting : query alarm not service affecting - all : query service affecting and not affecting alarms	serviceaffecting no serviceaffecting
ont	Parameter type: <Gpon::OntIndex> Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> ng2 : <Ng2::ChannelGroup> / <Ng2::SubchannelGroup> / <Ng2::OntId>) Possible values: - ng2 : ngpon2 style identification Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Ng2::ChannelGroup> - channel group number Field type <Ng2::SubchannelGroup> - subchannel group number Field type <Eqpt::OntId> - the ONT identifier Field type <Ng2::OntId> - the ONT identifier	identifies the ont entry

Command Output

Table 101.137-2 "show current alarm by filters" Display parameters

Specific Information		
name	Type	Description
aidinfo	Parameter type: <Alarm::AddInfoString> - additional alarm information	alarm AID parameters <i>This element is only shown in detail mode.</i>
type	Parameter type: <Alarm::alarmIHUBType> (equipment eqpt-holder plug-in-unit atm custom el	type of the alarms that are active <i>This element is only shown in detail mode.</i>

101 query current alarms by filters

name	Type	Description
	ima-group ima-link redundancy shdsl ether-itf traffic-overflow qos-queue temporal spatial (software-mngt sw-mgmt) xdsl xdsl-ext xdsl-tca olt-gen eo-conv authentication bonding sfp shdsl-isam custom-ext-alarm plug-in-unit-ext sip-user-agent sip-plugin-unit sip-termination e1-sip-termination filetransfer external-device l2forward ether-tca ether-sfp megaco-media-gw megaco-sig-gw megaco-plug-unit megaco-term megaco-sig-lt eqpt-supplemental eqpt-holder-ext lsmredundancy sync mcsrc vlanport vect-line vect-board otdr sip-dial-plan sip-vsp sip-server bgp rip lag ihub-general vprn isis ospf ihub-l2forward vpls ihub-equip	

name	Type	Description
	ihub-link	
	eont-phyoam	
	ellid	
	epon	
	eont-services-lan	
	eolt-ont-tca	
	eont-sw-dl	
	ldp	
	mpls	
	sdp	
	epipe	
	ihub-ipv6	
	pim	
	li	
	mgmt-sec-access	
	bfd	
	ai	
	tr069serv	
	ontsnmp	
	bulk-sync	
	protection-group	
	ont	
	sfu-sup	
	soho-sup	
	mdu-sup	
	ont-ani	
	sfu-sup2	
	soho-sup2	
	mdu-sup2	
	sfprssi	
	eoltrssi	
	cfm	
	sfpe1t1-framer	
	sfpe1t1-clock	
	pppcc-engine-tca	
	eth-cfm	
	rsvp	
	ihub-tca	
	eth-ring	
	efm-oam	
	ont-loopdetect	
	ont-video	
	ont-ces	
	ont-voip	
	ont-video-ani	
	ont-pwe	
	ont-cese1	
	ont-xdsl	
	ont-xdsl-tca	
	ont-hpna	
	ont-sip-agent-cfg	
	ont-voip-cfg	
	ont-mgc	
	ont-ploam	
	ont-gen	
	ont-card	
	ont-pots	

101 query current alarms by filters

name	Type	Description
	ont-lan ont-moca ont-tc-tca ont-moca-tca ont-l2uni-eth-tca olt-pon-tc-tca olt-pon-util-tca olt-chpr-util-tca olt-ont-tc-tca ont-tca ont-pots-supplemental sfu-ploam sfu-gen soho-ploam soho-gen mdu-ploam mdu-gen ont-veip ont-iphost alarm-table auto-switch channel-pair ont-cfg-dld olt-chpair-tc-tca hgu-tr069 eqpt-psu ont-protection secondary-megaco-term secondary-sip-term cas-r2-channel lldpmed pseudo-wire link-agg fcs-exceed e1t1-interface) Possible values: - equipment : equipment alarms - eqpt-holder : equipment holder alarms - plug-in-unit : plugin unit alarms - atm : ATM alarms - custom : customizable alarms - e1 : e1 alarms - ima-group : ima-group alarms - ima-link : ima-link alarms - redundancy : redundancy alarms - shdsl : shdsl alarms - ether-itf : ethernet interface alarms - traffic-overflow : Traffic overflow alarms - qos-queue : qos queue alarms - temporal : temporal alarms - spatial : spatial alarms - software-mngt : software management alarms - sw-mgmt : software management alarms - xdsl : xDSL alarms - xdsl-ext : other xDSL alarms - xdsl-tca : xDSL threshold cross alarms - olt-gen : OLT general alarms	

name	Type	Description
	- eo-conv : E/O conversion related alarms - authentication : authentication related alarms - bonding : bonding-group related alarms - sfp : SFP related alarms - shdsl-isam : shdsl isam alarms - custom-ext-alarm : customizable external alarms - plug-in-unit-ext : other plugin unit alarms - sip-user-agent : sip user agent related alarms - sip-plugin-unit : sip plug in unit related alarms - sip-termination : sip termination related alarms - e1-sip-termination : E1 sip termination related alarms - filetransfer : file transfer server alarms - external-device : external device related alarms - l2forward : l2forward related alarms - ether-tca : ethernet threshold cross alarms - ether-sfp : ethernet SFP related alarms - megaco-media-gw : megaco media gateway related alarms - megaco-sig-gw : megaco signaling gateway related alarms - megaco-plug-unit : megaco plug unit related alarms - megaco-term : megaco termination related alarms - megaco-sig-lt : megaco signaling lt related alarms - eqpt-supplemental : equipment supplemental alarms - eqpt-holder-ext : other equipment holder alarms - lsmredundancy : lsm redundancy alarms - sync : synce and bits alarms - mcsrc : multicast source alarms - vlanport : vlanport alarms - vect-line : xDSL vectoring line alarms - vect-board : xDSL vectoring board alarms - otdr : otdr alarms - sip-dial-plan : sip dial plan related alarms - sip-vsp : sip vsp related alarms - sip-server : sip server related alarms - bgp : bgp related alarms - rip : rip related alarms - lag : LAG related alarms - ihub-general : IHUB general related alarms - vprn : vprn related alarms - isis : isis related alarms - ospf : ospf related alarms - ihub-l2forward : ihub-l2forward alarms - vpls : vpls related alarms - ihub-equip : ihub-equip related alarms - ihub-link : ihub-link related alarms - eont-phyoam : eont phyoam related alarms - ellid : ellid related alarms - epon : epon related alarms - eont-services-lan : eon phyoam related alarms - eolt-ont-tca : eon phyoam related alarms - eont-sw-dl : eon phyoam related alarms - ldp : ldp related alarms - mpls : mpls related alarms - sdp : sdp related alarms - epipe : epipe related alarms - ihub-ipv6 : ihub-ipv6 related alarms - pim : pim related alarms - li : lawful intercept related alarms	

101 query current alarms by filters

name	Type	Description
	- mgmt-sec-access : management security related alarms - bfd : bfd related alarms - ai : Application Intelligence related alarms - tr069serv : tr069 server related alarms - ontsnmp : ont snmp related alarms - bulk-sync : bulk-sync related alarms - protection-group : port protection group related alarms - ont : ONT general supplemental related alarms - sfu-sup : SFU ONT general supplemental related alarms - soho-sup : SOHO ONT general supplemental related alarms - mdu-sup : MDU ONT general supplemental related alarms - ont-ani : ONT general supplemental 2 related alarms - sfu-sup2 : SFU ONT general supplemental 2 related alarms - soho-sup2 : SOHO ONT general supplemental 2 related alarms - mdu-sup2 : MDU ONT general supplemental 2 related alarms - sfprssi : SFP RSSI related alarms - eoltrssi : epon olt Sfp RSSI related alarms - cfm : Cfm related alarms - sfpe1t1-framer : SFP 2e1t1 framer alarms - sfpe1t1-clock : SFP 2e1t1 clock alarms - pppcc-engine-tca : PPPOE Cross Connect Engine TCA related alarm - eth-cfm : eth-cfm related alarms - rsvp : rsvp related alarms - ihub-tca : IHUB TCA related alarms - eth-ring : eth-ring related alarms - efm-oam : EFM-OAM related alarms - ont-loopdetect : ont loop detect related alarms - ont-video : ont services video related alarms - ont-ces : ont services ces related alarms - ont-voip : ont services voip related alarms - ont-video-ani : ont services video ani related alarms - ont-pwe : ont services pwe related alarms - ont-cese1 : ont services cese1 related alarms - ont-xdsl : ont services xdsl related alarms - ont-xdsl-tca : ont services xdsl tca related alarms - ont-hpna : ont hpna related alarms - ont-sip-agent-cfg : ont services voip sip agent config related alarms - ont-voip-cfg : ont services voip config related alarms - ont-mgc : ont mgc related alarms - ont-ploam : ONT PLOAM related alarms - ont-gen : ONT GENERAL related alarms - ont-card : ONT Subscriber Card related alarms - ont-pots : ONT Services POTS related alarms - ont-lan : ONT Services LAN related alarms - ont-moca : ONT MoCA related alarms - ont-tc-tca : ONT TC TCA related alarms - ont-moca-tca : ONT MoCA TCA related alarms - ont-l2uni-eth-tca : ONT L2 UNI Ethernet TCA related alarms - olt-pon-tc-tca : OLT PON TC TCA related alarms - olt-pon-util-tca : OLT PON utilization TCA related alarms - olt-chpr-util-tca : OLT channel-pair utilization TCA related	

name	Type	Description
	alarms - olt-ont-tc-tca : OLT ONT TC TCA related alarms - ont-tca : ONT TCA related alarms - ont-pots-supplemental : ONT POTS Supplemental related alarms - sfu-ploam : SFU ONT PLOAM related alarms - sfu-gen : SFU ONT general related alarms - soho-ploam : SOHO ONT PLOAM related alarms - soho-gen : SOHO ONT general related alarms - mdu-ploam : MDU ONT PLOAM related alarms - mdu-gen : MDU ONT general related alarms - ont-veip : ONT VEIP related alarms - ont-iphost : ONT IP HOST related alarms - alarm-table : alarm table related alarms - auto-switch : auto-switch related alarms - channel-pair : channel pair related alarms - ont-cfg-dld : ont configure file download related alarms - olt-chpair-tc-tca : OLT CHANNELPAIR TC TCA related alarms - hgu-tr069 : hgu tr069 related alarms - eqpt-psu : equipment psu alarms - ont-protection : ONT protection related alarms - secondary-megaco-term : secondary megaco termination related alarms - secondary-sip-term : secondary sip termination related alarms - cas-r2-channel : CAS R2 channel related alarms - lldpmed : lldpmed alarms - pseudo-wire : pseudo Wire related alarms - link-agg : Link aggregation related alarms - fcs-exceed : FCS auto-recovery related alarms - e1t1-interface : E1/T1 physical interfaces related alarms	
name	Parameter type: <Alarm::almtypeOntcfgdldihub> (cfg-dld-fail cfg-act-fail cfg-dld-ip cfg-ver-mismatch cfg-file-missing cfg-verctrl-err cfg-not-supported all) Possible values: - cfg-dld-fail : download of configure file to ont failed - cfg-act-fail : activate the passive config file failed - cfg-dld-ip : ont configure file download in progress - cfg-ver-mismatch : the planned configure file does not match the active configure file - cfg-file-missing : ont configure file missing or has an error - cfg-verctrl-err : ont configure file version control error - cfg-not-supported : ont not support the configure file download function - all : ont configure file download related alarms	alarm name that are active <i>This element is only shown in detail mode.</i>
severity	Parameter type: <Alarm::AlarmSeverity> (indeterminate warning minor major	the alarms severity level <i>This element is only shown in detail mode.</i>

101 query current alarms by filters

name	Type	Description
	critical) Possible values: - indeterminate : alarm severity is indeterminate - warning : alarm severity is warning - minor : alarm severity is minor - major : alarm severity is major - critical : alarm severity is critical	
servaff	Parameter type: <Alarm::alarmServAffect> ((service-affecting yes) (noservice-affecting no)) Possible values: - service-affecting : make this alarm service affecting - yes : make this alarm service affecting - noservice-affecting : make this alarm not service affecting - no : make this alarm not service affecting	alarms affect service or not <i>This element is only shown in detail mode.</i>
time	Parameter type: <Sys::timeInSecs> - the time (yyyy-mm-dd:hour:minutes:secs) - unit: UTC	time in seconds when alarm was updated <i>This element is only shown in detail mode.</i>
descript	Parameter type: <Alarm::AddInfoString> - additional alarm information	alarm description <i>This element is only shown in detail mode.</i>

101.138 show current alarm by filters

Command Description

show current alarms by filters

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm query olt-chpair-tc-tca [ (name) [ severity <Alarm::querySeverity> ] [ servaff
<Alarm::queryServAffect> ] [ channel-pair <Gpon::ChannelPairId> ] ]
```

Command Parameters

Table 101.138-1 "show current alarm by filters" Resource Parameters

Resource Identifier	Type	Description
(name)	Format: (olt-chpr-tc-err-frag olt-chpr-up-bw-tca olt-chpr-down-bw-tca all) Possible values: - olt-chpr-tc-err-frag : channelpair errored fragments threshold crossed - olt-chpr-up-bw-tca : OLT CHANNELPAIR upstream bandwidth TCA - olt-chpr-down-bw-tca : OLT CHANNELPAIR downstream bandwidth TCA - all : OLT CHANNELPAIR TC TCA related alarms	alarm name of OLT CHANNELPAIR TC TCA
severity	Parameter type: <Alarm::querySeverity> Format: (indeterminate warning minor major critical all) Possible values: - indeterminate : alarm severity is indeterminate - warning : alarm severity is warning - minor : alarm severity is minor - major : alarm severity is major - critical : alarm severity is critical - all : all alarm severity	severity level of an alarm for reporting

101 query current alarms by filters

Resource Identifier	Type	Description
servaff	Parameter type: <Alarm::queryServAffect> Format: (service-affecting noservice-affecting all) Possible values: - service-affecting : query alarm service affecting - noservice-affecting : query alarm not service affecting - all : query service affecting and not affecting alarms	serviceaffecting no serviceaffecting
channel-pair	Parameter type: <Gpon::ChannelPairId> Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::ChannelPairId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::ChannelPairId> - the channel pair identifier	gpon channelpair ifindex

Command Output

Table 101.138-2 "show current alarm by filters" Display parameters

Specific Information		
name	Type	Description
aidinfo	Parameter type: <Alarm::AddInfoString> - additional alarm information	alarm AID parameters <i>This element is only shown in detail mode.</i>
type	Parameter type: <Alarm::alarmIHUBType> (equipment eqpt-holder plug-in-unit atm custom e1 ima-group ima-link redundancy shdsl ether-itf traffic-overflow qos-queue temporal spatial (software-mngt sw-mgmt) xdsl xdsl-ext xdsl-tca olt-gen eo-conv authentication bonding sfp shdsl-isam	type of the alarms that are active <i>This element is only shown in detail mode.</i>

name	Type	Description
	custom-ext-alarm plug-in-unit-ext sip-user-agent sip-plugin-unit sip-termination e1-sip-termination filetransfer external-device l2forward ether-tca ether-sfp megaco-media-gw megaco-sig-gw megaco-plug-unit megaco-term megaco-sig-lt eqpt-supplemental eqpt-holder-ext lsmredundancy sync mcsrc vlanport vect-line vect-board otdr sip-dial-plan sip-vsp sip-server bgp rip lag ihub-general vprn isis ospf ihub-l2forward vpls ihub-equip ihub-link eont-phyoam ellid epon eont-services-lan eolt-ont-tca eont-sw-dl ldp mpls sdp epipe ihub-ipv6 pim li mgmt-sec-access bfd ai tr069serv ontsnmp	

101 query current alarms by filters

name	Type	Description
	bulk-sync	
	protection-group	
	ont	
	sfu-sup	
	soho-sup	
	mdu-sup	
	ont-ani	
	sfu-sup2	
	soho-sup2	
	mdu-sup2	
	sfprssi	
	eoltrssi	
	cfm	
	sfpe1t1-framer	
	sfpe1t1-clock	
	pppcc-engine-tca	
	eth-cfm	
	rsvp	
	ihub-tca	
	eth-ring	
	efm-oam	
	ont-loopdetect	
	ont-video	
	ont-ces	
	ont-voip	
	ont-video-ani	
	ont-pwe	
	ont-cese1	
	ont-xdsl	
	ont-xdsl-tca	
	ont-hpna	
	ont-sip-agent-cfg	
	ont-voip-cfg	
	ont-mgc	
	ont-ploam	
	ont-gen	
	ont-card	
	ont-pots	
	ont-lan	
	ont-moca	
	ont-tc-tca	
	ont-moca-tca	
	ont-l2uni-eth-tca	
	olt-pon-tc-tca	
	olt-pon-util-tca	
	olt-chpr-util-tca	
	olt-ont-tc-tca	
	ont-tca	
	ont-pots-supplemental	
	sfu-ploam	
	sfu-gen	
	soho-ploam	
	soho-gen	
	mdu-ploam	
	mdu-gen	
	ont-veip	
	ont-iphost	

name	Type	Description
	alarm-table auto-switch channel-pair ont-cfg-dld olt-chpair-tc-tca hgu-tr069 eqpt-psu ont-protection secondary-megaco-term secondary-sip-term cas-r2-channel lldpmed pseudo-wire link-agg fcs-exceed e1t1-interface) Possible values: - equipment : equipment alarms - eqpt-holder : equipment holder alarms - plug-in-unit : plugin unit alarms - atm : ATM alarms - custom : customizable alarms - e1 : e1 alarms - ima-group : ima-group alarms - ima-link : ima-link alarms - redundancy : redundancy alarms - shdsl : shdsl alarms - ether-itf : ethernet interface alarms - traffic-overflow : Traffic overflow alarms - qos-queue : qos queue alarms - temporal : temporal alarms - spatial : spatial alarms - software-mngt : software management alarms - sw-mgmt : software management alarms - xdsl : xDSL alarms - xdsl-ext : other xDSL alarms - xdsl-tca : xDSL threshold cross alarms - olt-gen : OLT general alarms - eo-conv : E/O conversion related alarms - authentication : authentication related alarms - bonding : bonding-group related alarms - sfp : SFP related alarms - shdsl-isam : shdsl isam alarms - custom-ext-alarm : customizable external alarms - plug-in-unit-ext : other plugin unit alarms - sip-user-agent : sip user agent related alarms - sip-plugin-unit : sip plug in unit related alarms - sip-termination : sip termination related alarms - e1-sip-termination : E1 sip termination related alarms - filetransfer : file transfer server alarms - external-device : external device related alarms - l2forward : l2forward related alarms - ether-tca : ethernet threshold cross alarms - ether-sfp : ethernet SFP related alarms - megaco-media-gw : megaco media gateway related alarms - megaco-sig-gw : megaco signaling gateway related alarms - megaco-plug-unit : megaco plug unit related alarms	

101 query current alarms by filters

name	Type	Description
	- megaco-term : megaco termination related alarms - megaco-sig-lt : megaco signaling lt related alarms - eqpt-supplemental : equipment supplemental alarms - eqpt-holder-ext : other equipment holder alarms - lsmredundancy : lsm redundancy alarms - sync : synce and bits alarms - mcsrc : multicast source alarms - vlanport : vlanport alarms - vect-line : xDSL vectoring line alarms - vect-board : xDSL vectoring board alarms - otdr : otdr alarms - sip-dial-plan : sip dial plan related alarms - sip-vsp : sip vsp related alarms - sip-server : sip server related alarms - bgp : bgp related alarms - rip : rip related alarms - lag : LAG related alarms - ihub-general : IHUB general related alarms - vprn : vprn related alarms - isis : isis related alarms - ospf : ospf related alarms - ihub-l2forward : ihub-l2forward alarms - vpls : vpls related alarms - ihub-equip : ihub-equip related alarms - ihub-link : ihub-link related alarms - eont-phyoam : eont phyoam related alarms - ellid : ellid related alarms - epon : epon related alarms - eont-services-lan : eon phyoam related alarms - eolt-ont-tca : eon phyoam related alarms - eont-sw-dl : eon phyoam related alarms - ldp : ldp related alarms - mpls : mpls related alarms - sdp : sdp related alarms - epipe : epipe related alarms - ihub-ipv6 : ihub-ipv6 related alarms - pim : pim related alarms - li : lawful intercept related alarms - mgmt-sec-access : management security related alarms - bfd : bfd related alarms - ai : Application Intelligence related alarms - tr069serv : tr069 server related alarms - ontsnmp : ont snmp related alarms - bulk-sync : bulk-sync related alarms - protection-group : port protection group related alarms - ont : ONT general supplemental related alarms - sfu-sup : SFU ONT general supplemental related alarms - soho-sup : SOHO ONT general supplemental related alarms - mdu-sup : MDU ONT general supplemental related alarms - ont-ani : ONT general supplemental 2 related alarms - sfu-sup2 : SFU ONT general supplemental 2 related alarms - soho-sup2 : SOHO ONT general supplemental 2 related alarms - mdu-sup2 : MDU ONT general supplemental 2 related alarms - sfrprsi : SFP RSSI related alarms	

name	Type	Description
	- eoltrssi : epon olt Sfp RSSI related alarms - cfm : Cfm related alarms - sfpe1t1-framer : SFP 2e1t1 framer alarms - sfpe1t1-clock : SFP 2e1t1 clock alarms - pppcc-engine-tca : PPPOE Cross Connect Engine TCA related alarm - eth-cfm : eth-cfm related alarms - rsvp : rsvp related alarms - ihub-tca : IHUB TCA related alarms - eth-ring : eth-ring related alarms - efm-oam : EFM-OAM related alarms - ont-loopdetect : ont loop detect related alarms - ont-video : ont services video related alarms - ont-ces : ont services ces related alarms - ont-voip : ont services voip related alarms - ont-video-ani : ont services video ani related alarms - ont-pwe : ont services pwe related alarms - ont-cese1 : ont services cese1 related alarms - ont-xdsl : ont services xdsl related alarms - ont-xdsl-tca : ont services xdsl tca related alarms - ont-hpna : ont hpna related alarms - ont-sip-agent-cfg : ont services voip sip agent config related alarms - ont-voip-cfg : ont services voip config related alarms - ont-mgc : ont mgc related alarms - ont-ploam : ONT PLOAM related alarms - ont-gen : ONT GENERAL related alarms - ont-card : ONT Subscriber Card related alarms - ont-pots : ONT Services POTS related alarms - ont-lan : ONT Services LAN related alarms - ont-moca : ONT MoCA related alarms - ont-tc-tca : ONT TC TCA related alarms - ont-moca-tca : ONT MoCA TCA related alarms - ont-l2uni-eth-tca : ONT L2 UNI Ethernet TCA related alarms - olt-pon-tc-tca : OLT PON TC TCA related alarms - olt-pon-util-tca : OLT PON utilization TCA related alarms - olt-chpr-util-tca : OLT channel-pair utilization TCA related alarms - olt-ont-tc-tca : OLT ONT TC TCA related alarms - ont-tca : ONT TCA related alarms - ont-pots-supplemental : ONT POTS Supplemental related alarms - sfu-ploam : SFU ONT PLOAM related alarms - sfu-gen : SFU ONT general related alarms - soho-ploam : SOHO ONT PLOAM related alarms - soho-gen : SOHO ONT general related alarms - mdu-ploam : MDU ONT PLOAM related alarms - mdu-gen : MDU ONT general related alarms - ont-veip : ONT VEIP related alarms - ont-iphost : ONT IP HOST related alarms - alarm-table : alarm table related alarms - auto-switch : auto-switch related alarms - channel-pair : channel pair related alarms - ont-cfg-dld : ont configure file download related alarms - olt-chpair-tc-tca : OLT CHANNELPAIR TC TCA related alarms	

101 query current alarms by filters

name	Type	Description
	- hgu-tr069 : hgu tr069 related alarms - eqpt-psu : equipment psu alarms - ont-protection : ONT protection related alarms - secondary-megaco-term : secondary megaco termination related alarms - secondary-sip-term : secondary sip termination related alarms - cas-r2-channel : CAS R2 channel related alarms - lldpmed : lldpmed alarms - pseudo-wire : pseudo Wire related alarms - link-agg : Link aggregation related alarms - fcs-exceed : FCS auto-recovery related alarms - e1t1-interface : E1/T1 physical interfaces related alarms	
name	Parameter type: <Alarm::almtypeOltchpairtctcai> (olt-chpr-tc-err-frag olt-chpr-up-bw-tca olt-chpr-down-bw-tca all) Possible values: - olt-chpr-tc-err-frag : channelpair errored fragments threshold crossed - olt-chpr-up-bw-tca : OLT CHANNELPAIR upstream bandwidth TCA - olt-chpr-down-bw-tca : OLT CHANNELPAIR downstream bandwidth TCA - all : OLT CHANNELPAIR TC TCA related alarms	alarm name that are active <i>This element is only shown in detail mode.</i>
severity	Parameter type: <Alarm::AlarmSeverity> (indeterminate warning minor major critical) Possible values: - indeterminate : alarm severity is indeterminate - warning : alarm severity is warning - minor : alarm severity is minor - major : alarm severity is major - critical : alarm severity is critical	the alarms severity level <i>This element is only shown in detail mode.</i>
servaff	Parameter type: <Alarm::alarmServAffect> ((service-affecting yes) (noservice-affecting no)) Possible values: - service-affecting : make this alarm service affecting - yes : make this alarm service affecting - noservice-affecting : make this alarm not service affecting - no : make this alarm not service affecting	alarms affect service or not <i>This element is only shown in detail mode.</i>
location	Parameter type: <Alarm::almLocation> (near-end far-end middle-end line null) Possible values: - near-end : alarm location is near - far-end : alarm location is far - middle-end : alarm location is middle - line : alarm location is line	alarm location: near, middle, far <i>This element is only shown in detail mode.</i>

101 query current alarms by filters

name	Type	Description
	- null : alarm location not defined	
time	Parameter type: <Sys::timeInSecs> - the time (yyyy-mm-dd:hour:minutes:secs) - unit: UTC	time in seconds when alarm was updated <i>This element is only shown in detail mode.</i>
direction	Parameter type: <Alarm::almDirection> (received transmit null) Possible values: - received : alarm is received - transmit : alarm is transmit - null : direction not defined	alarm direction: received or transmit <i>This element is only shown in detail mode.</i>
descript	Parameter type: <Alarm::AddInfoString> - additional alarm information	alarm description <i>This element is only shown in detail mode.</i>

101.139 show current alarm by filters

Command Description

show current alarms by filters

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm query isis [ (name) [ severity <Alarm::querySeverity> ] [ servaff <Alarm::queryServAffect> ] [
router-id <lhub::Router> ] ]
```

Command Parameters

Table 101.139-1 "show current alarm by filters" Resource Parameters

Resource Identifier	Type	Description
(name)	Format: (isis-adjacency-down isis-adjacency-reject isis-instance-down all) Possible values: - isis-adjacency-down : isis adjacency is down - isis-adjacency-reject : isis adjacency is rejected - isis-instance-down : isis instance is down or not - all : isis related alarms	alarm name of isis
severity	Parameter type: <Alarm::querySeverity> Format: (indeterminate warning minor major critical all) Possible values: - indeterminate : alarm severity is indeterminate - warning : alarm severity is warning - minor : alarm severity is minor - major : alarm severity is major - critical : alarm severity is critical - all : all alarm severity	severity level of an alarm for reporting
servaff	Parameter type: <Alarm::queryServAffect> Format: (service-affecting	serviceaffecting no

Resource Identifier	Type	Description
	noservice-affecting all) Possible values: - service-affecting : query alarm service affecting - noservice-affecting : query alarm not service affecting - all : query service affecting and not affecting alarms	
router-id	Parameter type: <Ihub::Router> Format: (base <Ihub::Router>) Possible values: - base : base router Field type <Ihub::Router> - vprn service-id - range: [1...2147483647]	the number of ethernet interface

Command Output

Table 101.139-2 "show current alarm by filters" Display parameters

Specific Information		
name	Type	Description
aidinfo	Parameter type: <Alarm::AddInfoString> - additional alarm information	alarm AID parameters <i>This element is only shown in detail mode.</i>
type	Parameter type: <Alarm::alarmIHUBType> (equipment eqpt-holder plug-in-unit atm custom e1 ima-group ima-link redundancy shdsl ether-itf traffic-overflow qos-queue temporal spatial (software-mngt sw-mgmt) xdsl xdsl-ext xdsl-tca olt-gen eo-conv authentication bonding sfp shdsl-isam custom-ext-alarm plug-in-unit-ext sip-user-agent sip-plugin-unit sip-termination e1-sip-termination	type of the alarms that are active <i>This element is only shown in detail mode.</i>

101 query current alarms by filters

name	Type	Description
	filetransfer	
	external-device	
	l2forward	
	ether-tca	
	ether-sfp	
	megaco-media-gw	
	megaco-sig-gw	
	megaco-plug-unit	
	megaco-term	
	megaco-sig-lt	
	eqpt-supplemental	
	eqpt-holder-ext	
	lsmredundancy	
	sync	
	mcsrc	
	vlanport	
	vect-line	
	vect-board	
	otdr	
	sip-dial-plan	
	sip-vsp	
	sip-server	
	bgp	
	rip	
	lag	
	ihub-general	
	vprn	
	isis	
	ospf	
	ihub-l2forward	
	vpls	
	ihub-equip	
	ihub-link	
	eont-phyoam	
	ellid	
	epon	
	eont-services-lan	
	eolt-ont-tca	
	eont-sw-dl	
	ldp	
	mpls	
	sdp	
	epipe	
	ihub-ipv6	
	pim	
	li	
	mgmt-sec-access	
	bfd	
	ai	
	tr069serv	
	ontsnmp	
	bulk-sync	
	protection-group	
	ont	
	sfu-sup	
	soho-sup	
	mdu-sup	

name	Type	Description
	ont-ani sfu-sup2 soho-sup2 mdu-sup2 sfprssi eoltrssi cfm sfpe1t1-framer sfpe1t1-clock pppcc-engine-tca eth-cfm rsvp ihub-tca eth-ring efm-oam ont-loopdetect ont-video ont-ces ont-voip ont-video-ani ont-pwe ont-cese1 ont-xdsl ont-xdsl-tca ont-hpna ont-sip-agent-cfg ont-voip-cfg ont-mgc ont-ploam ont-gen ont-card ont-pots ont-lan ont-moca ont-tc-tca ont-moca-tca ont-l2uni-eth-tca olt-pon-tc-tca olt-pon-util-tca olt-chpr-util-tca olt-ont-tc-tca ont-tca ont-pots-supplemental sfu-ploam sfu-gen soho-ploam soho-gen mdu-ploam mdu-gen ont-veip ont-iphost alarm-table auto-switch channel-pair ont-cfg-dld olt-chpair-tc-tca hgu-tr069	

101 query current alarms by filters

name	Type	Description
	eqpt-psu ont-protection secondary-megaco-term secondary-sip-term cas-r2-channel lldpmed pseudo-wire link-agg fcs-exceed e1t1-interface) Possible values: - equipment : equipment alarms - eqpt-holder : equipment holder alarms - plug-in-unit : plugin unit alarms - atm : ATM alarms - custom : customizable alarms - e1 : e1 alarms - ima-group : ima-group alarms - ima-link : ima-link alarms - redundancy : redundancy alarms - shdsl : shdsl alarms - ether-itf : ethernet interface alarms - traffic-overflow : Traffic overflow alarms - qos-queue : qos queue alarms - temporal : temporal alarms - spatial : spatial alarms - software-mngt : software management alarms - sw-mgmt : software management alarms - xdsl : xDSL alarms - xdsl-ext : other xDSL alarms - xdsl-tca : xDSL threshold cross alarms - olt-gen : OLT general alarms - eo-conv : E/O conversion related alarms - authentication : authentication related alarms - bonding : bonding-group related alarms - sfp : SFP related alarms - shdsl-isam : shdsl isam alarms - custom-ext-alarm : customizable external alarms - plug-in-unit-ext : other plugin unit alarms - sip-user-agent : sip user agent related alarms - sip-plugin-unit : sip plug in unit related alarms - sip-termination : sip termination related alarms - e1-sip-termination : E1 sip termination related alarms - filetransfer : file transfer server alarms - external-device : external device related alarms - l2forward : l2forward related alarms - ether-tca : ethernet threshold cross alarms - ether-sfp : ethernet SFP related alarms - megaco-media-gw : megaco media gateway related alarms - megaco-sig-gw : megaco signaling gateway related alarms - megaco-plug-unit : megaco plug unit related alarms - megaco-term : megaco termination related alarms - megaco-sig-lt : megaco signaling lt related alarms - eqpt-supplemental : equipment supplemental alarms - eqpt-holder-ext : other equipment holder alarms - lsmredundancy : lsm redundancy alarms - sync : synce and bits alarms	

name	Type	Description
	- mcsrc : multicast source alarms - vlanport : vlanport alarms - vect-line : xDSL vectoring line alarms - vect-board : xDSL vectoring board alarms - otdr : otdr alarms - sip-dial-plan : sip dial plan related alarms - sip-vsp : sip vsp related alarms - sip-server : sip server related alarms - bgp : bgp related alarms - rip : rip related alarms - lag : LAG related alarms - ihub-general : IHUB general related alarms - vprn : vprn related alarms - isis : isis related alarms - ospf : ospf related alarms - ihub-l2forward : ihub-l2forward alarms - vpls : vpls related alarms - ihub-equip : ihub-equip related alarms - ihub-link : ihub-link related alarms - eont-phyoam : eont phyoam related alarms - ellid : ellid related alarms - epon : epon related alarms - eont-services-lan : eon phyoam related alarms - eolt-ont-tca : eon phyoam related alarms - eont-sw-dl : eon phyoam related alarms - ldp : ldp related alarms - mpls : mpls related alarms - sdp : sdp related alarms - epipe : epipe related alarms - ihub-ipv6 : ihub-ipv6 related alarms - pim : pim related alarms - li : lawful intercept related alarms - mgmt-sec-access : management security related alarms - bfd : bfd related alarms - ai : Application Intelligence related alarms - tr069serv : tr069 server related alarms - ontsnmp : ont snmp related alarms - bulk-sync : bulk-sync related alarms - protection-group : port protection group related alarms - ont : ONT general supplemental related alarms - sfu-sup : SFU ONT general supplemental related alarms - soho-sup : SOHO ONT general supplemental related alarms - mdu-sup : MDU ONT general supplemental related alarms - ont-ani : ONT general supplemental 2 related alarms - sfu-sup2 : SFU ONT general supplemental 2 related alarms - soho-sup2 : SOHO ONT general supplemental 2 related alarms - mdu-sup2 : MDU ONT general supplemental 2 related alarms - sfprssi : SFP RSSI related alarms - eoltrssi : epon olt Sfp RSSI related alarms - cfm : Cfm related alarms - sfpe1t1-framer : SFP 2e1t1 framer alarms - sfpe1t1-clock : SFP 2e1t1 clock alarms - pppcc-engine-tca : PPPOE Cross Connect Engine TCA related alarm	

101 query current alarms by filters

name	Type	Description
	- eth-cfm : eth-cfm related alarms - rsvp : rsvp related alarms - ihub-tca : IHUB TCA related alarms - eth-ring : eth-ring related alarms - efm-oam : EFM-OAM related alarms - ont-loopdetect : ont loop detect related alarms - ont-video : ont services video related alarms - ont-ces : ont services ces related alarms - ont-voip : ont services voip related alarms - ont-video-ani : ont services video ani related alarms - ont-pwe : ont services pwe related alarms - ont-cese1 : ont services cese1 related alarms - ont-xdsl : ont services xdsl related alarms - ont-xdsl-tca : ont services xdsl tca related alarms - ont-hpna : ont hpna related alarms - ont-sip-agent-cfg : ont services voip sip agent config related alarms - ont-voip-cfg : ont services voip config related alarms - ont-mgc : ont mgc related alarms - ont-ploam : ONT PLOAM related alarms - ont-gen : ONT GENERAL related alarms - ont-card : ONT Subscriber Card related alarms - ont-pots : ONT Services POTS related alarms - ont-lan : ONT Services LAN related alarms - ont-moca : ONT MoCA related alarms - ont-tc-tca : ONT TC TCA related alarms - ont-moca-tca : ONT MoCA TCA related alarms - ont-l2uni-eth-tca : ONT L2 UNI Ethernet TCA related alarms - olt-pon-tc-tca : OLT PON TC TCA related alarms - olt-pon-util-tca : OLT PON utilization TCA related alarms - olt-chpr-util-tca : OLT channel-pair utilization TCA related alarms - olt-ont-tc-tca : OLT ONT TC TCA related alarms - ont-tca : ONT TCA related alarms - ont-pots-supplemental : ONT POTS Supplemental related alarms - sfu-ploam : SFU ONT PLOAM related alarms - sfu-gen : SFU ONT general related alarms - soho-ploam : SOHO ONT PLOAM related alarms - soho-gen : SOHO ONT general related alarms - mdu-ploam : MDU ONT PLOAM related alarms - mdu-gen : MDU ONT general related alarms - ont-veip : ONT VEIP related alarms - ont-iphost : ONT IP HOST related alarms - alarm-table : alarm table related alarms - auto-switch : auto-switch related alarms - channel-pair : channel pair related alarms - ont-cfg-dld : ont configure file download related alarms - olt-chpair-tc-tca : OLT CHANNELPAIR TC TCA related alarms - hgu-tr069 : hgu tr069 related alarms - eqpt-psu : equipment psu alarms - ont-protection : ONT protection related alarms - secondary-megaco-term : secondary megaco termination related alarms - secondary-sip-term : secondary sip termination related	

name	Type	Description
	alarms - cas-r2-channel : CAS R2 channel related alarms - lldpmed : lldpmed alarms - pseudo-wire : pseudo Wire related alarms - link-agg : Link aggregation related alarms - fcs-exceed : FCS auto-recovery related alarms - e1t1-interface : E1/T1 physical interfaces related alarms	
name	Parameter type: <Alarm::alarmTypeisisihub> (isis-adjacency-down isis-adjacency-reject isis-instance-down all) Possible values: - isis-adjacency-down : isis adjacency is down - isis-adjacency-reject : isis adjacency is rejected - isis-instance-down : isis instance is down or not - all : isis related alarms	alarm name that are active <i>This element is only shown in detail mode.</i>
severity	Parameter type: <Alarm::AlarmSeverity> (indeterminate warning minor major critical) Possible values: - indeterminate : alarm severity is indeterminate - warning : alarm severity is warning - minor : alarm severity is minor - major : alarm severity is major - critical : alarm severity is critical	the alarms severity level <i>This element is only shown in detail mode.</i>
servaff	Parameter type: <Alarm::alarmServAffect> ((service-affecting yes) (noservice-affecting no)) Possible values: - service-affecting : make this alarm service affecting - yes : make this alarm service affecting - noservice-affecting : make this alarm not service affecting - no : make this alarm not service affecting	alarms affect service or not <i>This element is only shown in detail mode.</i>
time	Parameter type: <Sys::timeInSecs> - the time (yyyy-mm-dd:hour:minutes:secs) - unit: UTC	time in seconds when alarm was updated <i>This element is only shown in detail mode.</i>
descript	Parameter type: <Alarm::AddInfoString> - additional alarm information	alarm description <i>This element is only shown in detail mode.</i>

101.140 show current alarm by filters

Command Description

show current alarms by filters

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm query name [ (name) [ defaultaid <Alarm::queryDefaultAid> ] [ severity <Alarm::querySeverity> ] [ servaff <Alarm::queryServAffect> ] ]
```

Command Parameters

Table 101.140-1 "show current alarm by filters" Resource Parameters

Resource Identifier	Type	Description
(name)	Format: (all xtca-ne-es xtca-ne-ses xtca-ne-uas xtca-ne-day-es xtca-ne-day-ses xtca-ne-day-uas xtca-fe-es xtca-fe-ses xtca-fe-uas xtca-fe-day-es xtca-fe-day-ses xtca-fe-day-uas xtca-leftrs xtca-day-leftrs xtca-fe-leftrs xtca-fe-day-leftrs xtca-auto-port-reset xtca-reinit xtca-day-reinit xdsl-ne-los xdsl-ne-lof xdsl-ne-lom xdsl-ne-ese xdsl-act-cfg-error xdsl-act-not-feas xdsl-up-br-reach	alarm names of all

Resource Identifier	Type	Description
	xdsl-ne-ncd xdsl-ne-lcd xdsl-fe-los xdsl-fe-lof xdsl-fe-lpr xdsl-fe-lol xdsl-fe-lom xdsl-fe-ese xdsl-fe-upbo-vio xdsl-fe-cpe-pol xdsl-tpstc-mis xdsl-act-comm xdsl-act-modem xdsl-do-br-reach xdsl-fe-ncd xdsl-fe-lcd xdsl-frtx-init-fail xdsl-vect-dle xdsl-fe-mis-peer-35b vectline-xtc-var-vict vectline-xtc-var-dist vectline-corp-errf vect-cpe-cap-mismatch vectline-conf_notfeas vect-vp-lt-mismatch vect-inv-qsf vect-vp-lt-fail vect-no-gain-at-init sw-rollback db-rollback xvps-inv-dbase inv-cde-file miss-cde-file cde-hash-error low-disk-space cell-discard-up cell-discard-down persist-data-loss mac-conflict vmac-full snmp-comm-lost preferred-mode timing-reference nt-disk-95%full shub-loc cf-error back-pnl-inv ihub-conf-loss rack-power rack-fan-unit1 rack-fan-unit2 shelf-mismatch shelf-missing shelf-install-missing door ac-power-fail board-mismatch	

101 query current alarms by filters

Resource Identifier	Type	Description
	waiting-for-sw	
	temp-exceeded	
	backplane-data-failure	
	temp-shutdown	
	board-missing	
	board-instl-missing	
	board-init	
	board-reset-prot	
	sem-power-fail	
	sem-ups-fail	
	board-reset-cf	
	vlan-assign-fail	
	vsa-info-invalid	
	auth-mac-conflict	
	user-pwd-fault	
	up-plan-bitrate	
	up-min-bitrate	
	up-config-not-feas	
	down-plan-bitrate	
	down-min-bitrate	
	down-config-not-feas	
	non-bonding-cpe	
	multiple-cpes	
	register	
	group-incomplete	
	host-sfp-los	
	host-sfp-tx-fail	
	host-sfp-not-prst	
	host-sfp-inv-id	
	host-sfp-ctrl-fail	
	host-sfp-rmtlt	
	host-sfp-mismatch	
	host-sfp-incompt	
	exp-sfp-los	
	exp-sfp-tx-fail	
	exp-sfp-not-prst	
	exp-sfp-inv-id	
	exp-sfp-ctrl-fail	
	exp-sfp-1-los	
	exp-sfp-2-los	
	ext-qsfp-invld	
	tx-power-high-alarm	
	tx-power-low-alarm	
	rx-power-high-alarm	
	rx-power-low-alarm	
	tx-biascur-high-alarm	
	tx-biascur-low-alarm	
	volt-high-alarm	
	volt-low-alarm	
	temp-high-alarm	
	temp-low-alarm	
	tx-power-high-warn	
	tx-power-low-warn	
	rx-power-high-warn	
	rx-power-low-warn	
	tx-biascur-high-warn	
	tx-biascur-low-warn	

Resource Identifier	Type	Description
	volt-high-warn volt-low-warn temp-high-warn temp-low-warn onu-unprovisioned signal-loss bitrate-high opmodule-mismatch key-fail-one-churn key-fail-three-churn oam-discov-fail report-timeout total-packets-exceed arp-packets-exceed dhcp-packets-exceed igmp-packets-exceed pppoe-packets-exceed nd-packets-exceed icmpv6-packets-exceed mld-packets-exceed dhcpv6-packets-exceed cfm-packets-exceed dsx1-serdes-fail dsx1-tributary1-fail dsx1-tributary2-fail dsx1-los-fail dsx1-ais-sync dsx1-lof-sync dsx1-los-sync dsx1-deg-fail dsx1-rei-from-liu dsx1-rdi-from-liu dsx1-crc6-from-liu dsx1-crc4-from-liu dsx1-crc4-th-from-liu dsx1-ais-from-liu dsx1-los-from-liu dsx1-lof-from-liu dsx1-lomf-from-liu dsx1-rei-from-iwf dsx1-rdi-from-iwf dsx1-crc6-from-iwf dsx1-crc4-from-iwf dsx1-crc4-th-from-iwf dsx1-ais-from-iwf dsx1-los-from-iwf dsx1-lof-from-iwf dsx1-lomf-from-iwf pppce-trans-15min-tca pppce-sess-15min-tca pppce-trans-1day-tca pppce-sess-1day-tca custom1 custom2 custom3 custom4 custom5	

101 query current alarms by filters

Resource Identifier	Type	Description
	he-custom1	
	he-custom2	
	he-custom3	
	he-custom4	
	he-custom5	
	he-custom6	
	custom6	
	custom7	
	custom8	
	custom9	
	custom10	
	custom11	
	custom12	
	custom13	
	custom14	
	custom15	
	custom16	
	custom17	
	loss-swo-cap	
	ping-check-fail	
	der-temp1	
	der-temp2	
	der-temp3	
	der-temp4	
	der-temp5	
	der-temp6	
	der-temp7	
	der-temp8	
	der-temp9	
	der-temp10	
	der-temp11	
	der-temp12	
	der-temp13	
	der-temp14	
	der-temp15	
	der-temp16	
	der-temp17	
	der-temp18	
	der-temp19	
	der-temp20	
	der-temp21	
	der-temp22	
	der-temp23	
	der-temp24	
	der-temp25	
	der-temp26	
	der-temp27	
	der-temp28	
	der-temp29	
	der-temp30	
	der-temp31	
	der-spa1	
	der-spa2	
	der-spa3	
	der-spa4	
	der-spa5	
	der-spa6	

Resource Identifier	Type	Description
	der-spa7	
	der-spa8	
	der-spa9	
	der-spa10	
	der-spa11	
	der-spa12	
	der-spa13	
	der-spa14	
	der-spa15	
	der-spa16	
	der-spa17	
	der-spa18	
	der-spa19	
	der-spa20	
	der-spa21	
	der-spa22	
	der-spa23	
	der-spa24	
	der-spa25	
	der-spa26	
	der-spa27	
	der-spa28	
	der-spa29	
	der-spa30	
	der-spa31	
	apfs-alarm	
	custextalarm1	
	custextalarm2	
	custextalarm3	
	custextalarm4	
	custextalarm5	
	pluginfan	
	plugin-dc-a	
	plugin-dc-b	
	plugin-dg	
	ntr-a-loss	
	ntr-b-loss	
	xvps-conf-loss	
	mac-entry-nofree	
	fibre-conn-mismatch	
	link-cap-mismatch	
	eqpt-cap-mismatch	
	ctrl-dnld-failure	
	melt-hw-issue	
	melt-board-reset	
	board-shelf-mismatch	
	mgnt-type-mismatch	
	fileserv-unavail	
	shdsl-n-loopback	
	shdsl-c-loopback	
	shdsl-conferr	
	shdsl-atm-lcd	
	shdsl-lpr	
	shdsl-secu-err	
	shdsl-dev-fault	
	shdsl-atm-ncd	
	shdsl-n-losw	

101 query current alarms by filters

Resource Identifier	Type	Description
	shdsl-c-losw	
	shdsl-n-aten	
	shdsl-c-aten	
	shdsl-n-snr	
	shdsl-c-snr	
	shdsl-n-dccont	
	shdsl-c-dccont	
	shdsl-c-actfail	
	e1-fe-rai	
	e1-ne-rai	
	e1-fe-ais	
	e1-ne-ais	
	e1-lof	
	e1-los	
	e1-loopback	
	ima-grp-fe-su	
	ima-grp-fe-cfg	
	ima-grp-ne-cfg	
	ima-grp-fe-nl	
	ima-grp-ne-nl	
	ima-grp-fe-blk	
	ima-lnk-lif	
	ima-lnk-lods	
	ima-lnk-misc	
	ima-lnk-rfi	
	ima-lnk-fault	
	ima-lnk-txblk	
	ima-lnk-rxblk	
	bad-digitmap	
	dhcp-unreach	
	dhcp-no-srv	
	dhcp-inv-srv	
	norpniewwithsoftdsp	
	unknown-sub	
	ground-key	
	port-hightemp	
	port-jbfltca	
	reg-domainname	
	reg-auth	
	reg-timeout	
	reg-srvfailresp	
	inv-domainname	
	inv-auth	
	inv-timeout	
	inv-srvfailresp	
	subs-srvfailresp	
	subs-domainname	
	subs-auth	
	subs-refreshfail	
	subs-inittimeout	
	emergency-call	
	e1sip-reg-domainname	
	e1sip-reg-auth	
	e1sip-reg-timeout	
	e1sip-reg-srvfailresp	
	e1sip-inv-domainname	
	e1sip-inv-auth	

Resource Identifier	Type	Description
	e1sip-inv-timeout e1sip-inv-srvfailresp e1sip-emergency-call e1itf-ais-signal e1itf-los-signal e1itf-rai-signal e1sip-misconfig-mgc10 e1sip-nsmprf-missed e1t1itf-recv-ais e1t1itf-recv-los e1t1itf-recv-rai transport-mismatch dns-lookup-failure none-dns-srv no-dns-srv none-srv no-srv reg-srv-unreach proxy-srv-unreach dhcp-srv-unreach fo-trigger fb-trigger du-trigger ssp-missing dns-pool-exceed lsa-fo-trigger reg-domainname-sec reg-auth-sec reg-timeout-sec reg-srvfailresp-sec inv-domainname-sec inv-auth-sec inv-timeout-sec inv-srvfailresp-sec subs-srvfailresp-sec subs-domainname-sec subs-auth-sec subs-refreshfail-sec subs-inittimeout-sec emergency-call-sec fanout up-overflow upobc-overflow dwobc-overflow dw-overflow lwpri-overflow queue-drop queue-load queue-peak-usage mgc-unreachable failover-to-esamgc sgc-unreachable lcard-unreach-srvcard lcard-type-mismatch meg-unknown-sub meg-ground-key meg-high-temp	

101 query current alarms by filters

Resource Identifier	Type	Description
	meg-act-fail meg-over-current line-showering low-qos-packetloss low-qos-jitter low-qos-delay sig-brd-persist-loss sig-brd-disk-full sig-brd-db-rollback mg-overload meg-unknown-sub-sec line-showering-sec loss-env-mon etca-los etca-fcs etca-day-los etca-day-fcs etca-rx-octets etca-tx-octets etca-day-rx-octets etca-day-tx-octets user-sfp-los user-sfp-tx-fail user-sfp-not-prst user-sfp-inv-id user-sfp-t-exceed user-sfp-mismatch uplink-sfp-los uplink-sfp-tx-fail uplink-sfp-not-prst uplink-sfp-inv-id uplink-sfp-t-exceed uplink-sfp-mismatch loss-lmswp-cap inv-xvps-pair-data network-power-loss hw-fault bat-miss bat-fail bat-low bat-a-fail bat-b-fail ac-vol-out-range network-power-loss-b sem-ac-power-fail sem-ups-low-volt dc-a-fail dc-b-fail plan-power-mismatch water-seepage-in-box sealed-box-open dc-a-vol-out-range dc-b-vol-out-range inlet-temp-major inlet-temp-critical psu-fail-crit psu-a-fail-presence	

Resource Identifier	Type	Description
	psu-a-fail-vin-ac-nok psu-a-fail-vin-uv psu-a-fail-vin-ov psu-a-fail-vout-uv psu-a-fail-vout-ov psu-a-fail-iout-oc psu-a-fail-overtemp psu-b-fail-presence psu-b-fail-vin-ac-nok psu-b-fail-vin-uv psu-b-fail-vin-ov psu-b-fail-vout-uv psu-b-fail-vout-ov psu-b-fail-iout-oc psu-b-fail-overtemp synce-fail bits-fail bits-output-shutoff ieee1588-fail gnss-fail ieee1588-hybrid-fail signal-loss signal-efd esmc-loss bits-output-exceed ql-input-exceed holdover lti tod-reference-fail internal-clk-fail bgp-peer-down bgp-routes-mid-limit isis-adjacency-down isis-adjacency-reject isis-instance-down ospf-lsa-limit ospf-lsa-mid-limit ospf-neighbor-down ospf-instance-down ospf3-lsa-limit ospf3-lsa-mid-limit ospf3-neighbor-down ospf3-instance-down rip-instance-down lag-down lagsubgrp-thresh-reach lagsubgrp-switch-fail no-unpinned-free-ports general-arp-limit gen-switch-out-of-res ipv6-nc-limit dhcp-session-oor ihub-fdb-limit ihub-mac-limit l2fw-stp-exception l2fw-stp-root-guard vprn-routes-limit	

101 query current alarms by filters

Resource Identifier	Type	Description
	vprn-ipv6-routes-limit dhcipv6-lease-limit dhcipv4-lease-limit vpls-mfib-limit ihub-ipv6-dad-own ihub-ipv6-dad ihub-ipv6-dup-pd-route vpls-duplicate-mac vpls-fdb-limit vpls-self-duplic-mac vpls-sdp-self-dup-mac link-down link-lagport-add-fail link-conf-mismatch ihub-peer-comm ihub-sw-fail ihub-hw-fail ihub-link-fail ihub-proc-overload ihub-out-of-mem ntp-comm-lost ldp-instance-down ldp-session-down mpls-instance-down mpls-lsp-down mpls-lsp-path-down sdp-instance-down sdp-binding-down epipe-instance-down lldpmed-portcfg-mis lldpmed-mediapl-mis vlanport-svc-mismatch mcsrc-stream-lost eqptsupl-syslog-upload eqptsupl-ontsw-dnload cf-75%used cf-90%used olt-gen-pon-com-fail olt-gen-tx-fail olt-gen-unprov-ont olt-gen-pon-eqpt-prov olt-gen-pon-loss-sig olt-gen-pon-diagnostic olt-gen-lold-conflict olt-gen-lold-pwderr olt-gen-pon-alien-test olt-gen-alien-detect olt-gen-rng-mism olt-gen-sfp-mism olt-gen-deact-hightca olt-gen-deact-lowtca olt-gen-dp-integ olt-gen-ddr-fault olt-pon-tc-err-frag-tc olt-ont-tc-err-frag-tc ont-ploam-loss-sig ont-ploam-loss-ack	

Resource Identifier	Type	Description
	ont-ploam-loss-cd	
	ont-ploam-phy-eqpt-err	
	ont-ploam-startup-fail	
	ont-ploam-sig-degrade	
	ont-ploam-disabled	
	ont-ploam-err-msg	
	ont-ploam-inactive	
	ont-ploam-sig-fail	
	ont-ploam-dying-gasp	
	ont-ploam-deact-fail	
	ont-ploam-oam	
	ont-ploam-win-drift	
	ont-ploam-rdi	
	ont-ploam-loss-ks	
	ont-ploam-pwr-burst	
	ont-ploam-rog-disa	
	ont-ploam-diff-reach	
	ont-ploam-looc	
	sfu-ploam-loss-sig	
	sfu-ploam-loss-ack	
	sfu-ploam-loss-cd	
	sfu-ploam-phy-eqpt-err	
	sfu-ploam-startup-fail	
	sfu-ploam-sig-degrade	
	sfu-ploam-disabled	
	sfu-ploam-err-msg	
	sfu-ploam-inactive	
	sfu-ploam-sig-fail	
	sfu-ploam-dying-gasp	
	sfu-ploam-deact-fail	
	sfu-ploam-oam	
	sfu-ploam-win-drift	
	sfu-ploam-rdi	
	sfu-ploam-loss-ks	
	sfu-ploam-pwr-burst	
	sfu-ploam-rog-disa	
	sfu-ploam-diff-reach	
	sfu-ploam-looc	
	soho-ploam-loss-sig	
	soho-ploam-loss-ack	
	soho-ploam-loss-cd	
	soho-ploam-phy-eqpt-er	
	soho-ploam-startup-fai	
	soho-ploam-sig-degrade	
	soho-ploam-disabled	
	soho-ploam-err-msg	
	soho-ploam-inactive	
	soho-ploam-sig-fail	
	soho-ploam-dying-gasp	
	soho-ploam-deact-fail	
	soho-ploam-oam	
	soho-ploam-win-drift	
	soho-ploam-rdi	
	soho-ploam-loss-ks	
	soho-ploam-pwr-burst	
	soho-ploam-rog-disa	
	soho-ploam-diff-reach	

101 query current alarms by filters

Resource Identifier	Type	Description
	soho-ploam-looc	
	mdu-ploam-loss-sig	
	mdu-ploam-loss-ack	
	mdu-ploam-loss-cd	
	mdu-ploam-phy-eqpt-err	
	mdu-ploam-startup-fail	
	mdu-ploam-sig-degrade	
	mdu-ploam-disabled	
	mdu-ploam-err-msg	
	mdu-ploam-inactive	
	mdu-ploam-sig-fail	
	mdu-ploam-dying-gasp	
	mdu-ploam-deact-fail	
	mdu-ploam-oam	
	mdu-ploam-win-drift	
	mdu-ploam-rdi	
	mdu-ploam-loss-ks	
	mdu-ploam-pwr-burst	
	mdu-ploam-roq-disa	
	mdu-ploam-diff-reach	
	mdu-ploam-looc	
	ont-hpna-ser-mis	
	ont-hpna-los-sig	
	ont-moca-svc-mis	
	ont-moca-link-los	
	ont-moca-min-bw	
	ont-moca-tca-rx-err-fr	
	ont-sipa-reg-nm-fail	
	ont-sipa-reg-rec-fail	
	ont-sipa-reg-con-fail	
	ont-sipa-reg-val-fail	
	ont-sipa-reg-mis	
	ont-vcd-cfg-nm-fail	
	ont-vcd-cfg-rech-fail	
	ont-vcd-cfg-conn-fail	
	ont-vcd-cfg-vali-fail	
	ont-vcd-cfg-auth-fail	
	ont-vcd-cfg-resp-tmout	
	ont-vcd-cfg-resp-err	
	ont-vcd-cfg-file-err	
	ont-vcd-sub-nm-fail	
	ont-vcd-sub-rech-fail	
	ont-vcd-sub-conn-fail	
	ont-vcd-sub-vali-fail	
	ont-vcd-sub-auth-fail	
	ont-vcd-sub-resp-tmout	
	ont-vcd-sub-resp-err	
	ont-vcd-reb-requ	
	ont-vcd-mis	
	ont-mgc-mis	
	ont-mgc-timeout	
	ont-sip-reg-dns	
	ont-sip-reg-fail	
	ont-sip-reg-timeout	
	ont-sip-reg-err-resps	
	ont-sip-inv-dns	
	ont-sip-inv-auth	

Resource Identifier	Type	Description
	ont-sip-inv-timeout	
	ont-sip-inv-err	
	ont-svc-pots-subs-refr	
	ont-svc-pots-not-refr	
	ont-svc-pots-icfg-err	
	ont-veip-mismatch	
	ont-ip-host-mismatch	
	ont-ip-host-file	
	ont-ip-host-ip-alloc	
	olt-pon-up-bw-tca	
	olt-pon-down-bw-tca	
	ont-gen-omci-fail	
	ont-gen-eqpt-selftest	
	ont-gen-ac-pwr-fail	
	ont-gen-bat-missing	
	ont-gen-bat-low	
	ont-gen-bat-fail	
	ont-gen-phys-intrusion	
	ont-gen-sw-dnload-f	
	ont-gen-sw-dnload-p	
	ont-gen-sw-act-fail	
	ont-gen-eqpt-vers-mis	
	ont-gen-sw-vers-mis	
	ont-gen-us-rate-mis	
	ont-gen-mdu-env1	
	ont-gen-mdu-env2	
	ont-gen-mdu-env3	
	ont-gen-nw-time-err	
	ont-gen-opt-sig-high	
	ont-gen-opt-sig-low	
	ont-gen-eqpt-prov-sa	
	ont-gen-eqpt-prov-nsa	
	pon-t-txmcutilhi	
	pon-t-txmcutilmd	
	pon-t-txmcutillo	
	pon-t-txtotutilhi	
	pon-t-txtotutilmd	
	pon-t-txtotutillo	
	pon-t-rxtotutilhi	
	pon-t-rxtotutilmd	
	pon-t-rxtotutillo	
	pon-t-dbacongperiodhi	
	pon-t-dbacongperiodmd	
	pon-t-dbacongperiodlo	
	pon-t-txucdropfrmhi	
	pon-t-txucdropfrmmd	
	pon-t-txucdropfrmlo	
	pon-t-txmcdropfrmhi	
	pon-t-txmcdropfrmmd	
	pon-t-txmcdropfrmlo	
	pon-t-txbcdropfrmhi	
	pon-t-txbcdropfrmmd	
	pon-t-txbcdropfrmlo	
	pon-t-rxtotdropfrmhi	
	pon-t-rxtotdropfrmmd	
	pon-t-rxtotdropfrmlo	
	chpr-t-txmcutilhi	

101 query current alarms by filters

Resource Identifier	Type	Description
	chpr-t-txmcutilm	
	chpr-t-txmcutillo	
	chpr-t-txtotutilhi	
	chpr-t-txtotutilmd	
	chpr-t-txtotutillo	
	chpr-t-rxtotutilhi	
	chpr-t-rxtotutilmd	
	chpr-t-rxtotutillo	
	chpr-t-dbacongperiodhi	
	chpr-t-dbacongperiodmd	
	chpr-t-dbacongperiodlo	
	chpr-t-txucdropfrmhi	
	chpr-t-txucdropfrmmd	
	chpr-t-txucdropfrmlo	
	chpr-t-txmcdropfrmhi	
	chpr-t-txmcdropfrmmd	
	chpr-t-txmcdropfrmlo	
	chpr-t-txbcdropfrmhi	
	chpr-t-txbcdropfrmmd	
	chpr-t-txbcdropfrmlo	
	chpr-t-rxtotdropfrmhi	
	chpr-t-rxtotdropfrmmd	
	chpr-t-rxtotdropfrmlo	
	sfu-gen-omci-fail	
	sfu-gen-eqpt-selftest	
	sfu-gen-ac-pwr-fail	
	sfu-gen-bat-missing	
	sfu-gen-bat-low	
	sfu-gen-bat-fail	
	sfu-gen-sw-dnload-f	
	sfu-gen-sw-dnload-p	
	sfu-gen-sw-act-fail	
	sfu-gen-eqpt-vers-mis	
	sfu-gen-sw-vers-mis	
	sfu-gen-us-rate-mis	
	sfu-gen-tune-fail	
	sfu-gen-nw-time-err	
	sfu-gen-opt-sig-high	
	sfu-gen-opt-sig-low	
	sfu-gen-eqpt-prov-sa	
	sfu-gen-eqpt-prov-nsa	
	soho-gen-omci-fail	
	soho-gen-eqpt-selftest	
	soho-gen-ac-pwr-fail	
	soho-gen-bat-missing	
	soho-gen-bat-low	
	soho-gen-bat-fail	
	soho-gen-sw-dnload-f	
	soho-gen-sw-dnload-p	
	soho-gen-sw-act-fail	
	soho-gen-eqpt-vers-mis	
	soho-gen-sw-vers-mis	
	soho-gen-us-rate-mis	
	soho-gen-tune-fail	
	soho-gen-nw-time-err	
	soho-gen-opt-sig-high	
	soho-gen-opt-sig-low	

Resource Identifier	Type	Description
	soho-gen-eqpt-prov-sa	
	soho-gen-eqpt-prov-nsa	
	mdu-gen-omci-fail	
	mdu-gen-eqpt-selftest	
	mdu-gen-ac-pwr-fail	
	mdu-gen-bat-missing	
	mdu-gen-bat-low	
	mdu-gen-bat-fail	
	mdu-gen-phys-intrusion	
	mdu-gen-sw-dnload-f	
	mdu-gen-sw-dnload-p	
	mdu-gen-sw-act-fail	
	mdu-gen-eqpt-vers-mis	
	mdu-gen-sw-vers-mis	
	mdu-gen-us-rate-mis	
	mdu-gen-tune-fail	
	mdu-gen-mdu-env1	
	mdu-gen-mdu-env2	
	mdu-gen-mdu-env3	
	mdu-gen-nw-time-err	
	mdu-gen-opt-sig-high	
	mdu-gen-opt-sig-low	
	mdu-gen-eqpt-prov-sa	
	mdu-gen-eqpt-prov-nsa	
	ont-gen-sw-dnload-file	
	ont-gen-fan-fail	
	ont-gen-high-temp	
	ont-gen-high-temp-ex	
	ont-gen-emergency-call	
	ont-gen-sw-version	
	ont-poe-exceed-max	
	ont-poe-overload-yell	
	ont-opti-malfunc	
	ont-gen-cfgdld-fail	
	ont-gen-rssi-mis	
	ont-gen-tx-pwr-low	
	ont-gen-temp-high	
	ont-gen-volt-high	
	ont-gen-bias-high	
	ont-loopdetect-mis	
	ont-olt-rx-pw-lo	
	ont-olt-rx-pw-hig	
	ont-olt-rx-pw-warnlo	
	ont-olt-rx-pw-warnhig	
	ont-gen-tod-out-sync	
	ont-gen-tune-fail	
	hgu-tr069-parm-fail	
	ont-gen-tod-mismatch	
	sfu-sup-sw-file-error	
	sfu-sup-fan-failure	
	sfu-sup-temp-high-warn	
	sfu-sup-temp-shutoff	
	sfu-sup-emergency-call	
	sfu-sup-swverctrl-err	
	sfu-sup-poe-exceed-max	
	sfu-sup-poe-over-yell	
	sfu-opti-malfunc	

101 query current alarms by filters

Resource Identifier	Type	Description
	sfu-sup-cfg-dnld-fail	
	sfu-sup-rssi-cfg-mism	
	sfu-sup-sfp-tx-low	
	sfu-sup-sfp-temp-high	
	sfu-sup-sfp-volt-high	
	sfu-sup-sfp-bias-high	
	sfu-sup-ld-cfg-mism	
	sfu-sup-olt-rx-low	
	sfu-sup-olt-rx-high	
	sfu-sup-olt-rx-lo-warn	
	sfu-sup-olt-rx-hi-warn	
	sfu-sup-tod-out-sync	
	sfu-sup-ont-tune-fail	
	sfu-tr069-parm-fail	
	sfu-sup-tod-mismatch	
	soho-sup-sw-file-error	
	soho-sup-fan-failure	
	soho-sup-temp-high-war	
	soho-sup-temp-shutoff	
	soho-sup-emergency-cal	
	soho-sup-swverctrl-err	
	soho-sup-poe-exceed-ma	
	soho-sup-poe-over-yell	
	soho-opti-malfunc	
	soho-sup-cfg-dnld-fail	
	soho-sup-rssi-cfg-mism	
	soho-sup-sfp-tx-low	
	soho-sup-sfp-temp-high	
	soho-sup-sfp-volt-high	
	soho-sup-sfp-bias-high	
	soho-sup-ld-cfg-mism	
	soho-sup-olt-rx-low	
	soho-sup-olt-rx-high	
	soho-sup-olt-rx-lo-war	
	soho-sup-olt-rx-hi-war	
	soho-sup-tod-out-sync	
	soho-sup-ont-tune-fail	
	soho-tr069-parm-fail	
	soho-sup-tod-mismatch	
	mdu-sup-sw-file-error	
	mdu-sup-fan-failure	
	mdu-sup-temp-high-warn	
	mdu-sup-temp-shutoff	
	mdu-sup-emergency-call	
	mdu-sup-swverctrl-err	
	mdu-sup-poe-exceed-max	
	mdu-sup-poe-over-yell	
	mdu-opti-malfunc	
	mdu-sup-cfg-dnld-fail	
	mdu-sup-rssi-cfg-mism	
	mdu-sup-sfp-tx-low	
	mdu-sup-sfp-temp-high	
	mdu-sup-sfp-volt-high	
	mdu-sup-sfp-bias-high	
	mdu-sup-ld-cfg-mism	
	mdu-sup-olt-rx-low	
	mdu-sup-olt-rx-high	

Resource Identifier	Type	Description
	mdu-sup-olt-rx-lo-warn mdu-sup-olt-rx-hi-warn mdu-sup-tod-out-sync mdu-sup-ont-tune-fail mdu-tr069-parm-fail mdu-sup-tod-mismatch ont-sbscr-lim-missing ont-sbscr-lim-type-mis ont-sbscr-lim-removal ont-sbscr-lim-fail ont-sbscr-lim-svc-mis ont-sbscr-lim-port-mis ont-svc-video-conf-mis ont-svc-video-pw-high ont-svc-video-pw-low ont-svc-pots-svc-mis ont-svc-pots-rtcp-lost ont-svc-pots-icnf-subs ont-svc-pots-icnf-ntfy ont-svc-pots-icnf-http ont-svc-pots-sip-reg ont-svc-pots-sip-inv ont-svc-pots-sip-subsc ont-svc-pots-sip-mt-tc ont-svc-pots-pk-los-tc ont-svc-pots-jitter-tc ont-svc-pots-subs-dns ont-svc-pots-subs-tcp ont-svc-pots-subs-tls ont-svc-pots-subs-auth ont-svc-pots-subs-to ont-svc-pots-subs-err ont-svc-pots-not-to ont-svc-pots-notref-to ont-svc-pots-not-mal ont-svc-pots-not-rej ont-svc-pots-http-dns ont-svc-pots-http-tcp ont-svc-pots-http-tls ont-svc-pots-http-auth ont-svc-pots-http-to ont-svc-pots-http-err ont-svc-pots-http-mal ont-svc-pots-insuff ont-svc-pots-poos ont-svc-lan-mismatch ont-svc-lan-loss-sig ont-svc-enet-poos ont-svc-ces-ds1-mis ont-svc-ces-ds1-los ont-svc-ces-ds1-lof ont-svc-ces-ds1-rair ont-svc-ces-ds1-ais ont-svc-ces-ds1-lnlpbk ont-svc-ces-ds1-tmlpbk ont-svc-ces-e1-mis ont-svc-ces-e1-los	

101 query current alarms by filters

Resource Identifier	Type	Description
	ont-svc-ces-e1-lof	
	ont-svc-ces-e1-rair	
	ont-svc-ces-e1-ais	
	ont-svc-voip-cnf-file	
	ont-svc-voip-svc-mis	
	ont-svc-voip-gw-comm	
	ont-svc-voip-dhcp-fail	
	ont-svc-voip-icnf-sub	
	ont-svc-voip-icnf-ntfy	
	ont-svc-voip-icnf-http	
	ont-svc-voip-dhcp-to	
	ont-svc-voip-dhcp-mal	
	ont-svc-voip-dhcp-noad	
	ont-svc-voip-dhcp-leas	
	ont-svc-voip-sub-dns	
	ont-svc-voip-sub-tcp	
	ont-svc-voip-sub-tls	
	ont-svc-voip-sub-auth	
	ont-svc-voip-sub-to	
	ont-svc-voip-sub-err	
	ont-svc-voip-not-to	
	ont-svc-voip-notref-to	
	ont-svc-voip-not-mal	
	ont-svc-voip-not-rej	
	ont-svc-voip-http-dns	
	ont-svc-voip-http-tcp	
	ont-svc-voip-http-tls	
	ont-svc-voip-http-auth	
	ont-svc-voip-http-to	
	ont-svc-voip-http-err	
	ont-svc-voip-http-mal	
	ont-svc-voip-sub-refr	
	ont-svc-voip-not-refr	
	ont-svc-voip-icfg-err	
	ont-svc-v-ani-conf-mis	
	ont-svc-v-ani-loss-sig	
	ont-svc-v-ani-lv-high	
	ont-svc-v-ani-lv-low	
	ont-svc-pwe-mismatch	
	ont-svc-pwe-reordr-lof	
	ont-svc-pwe-jitt-buf-o	
	ont-svc-pwe-jitt-buf-u	
	ont-svc-pwe-malf-frms	
	ont-svc-pwe-late-frms	
	ont-svc-pwe-link-loss	
	ont-svc-pwe-arp-fail	
	ont-svc-xdsl-mismatch	
	ont-svc-xdsl-ne-lof	
	ont-svc-xdsl-ne-los	
	ont-svc-xdsl-ne-line	
	ont-svc-xdsl-ne-lol	
	ont-svc-xdsl-fe-lof	
	ont-svc-xdsl-fe-los	
	ont-svc-xdsl-fe-lop	
	ont-svc-xdsl-cnf-err	
	ont-svc-xdsl-ne-es-tc	
	ont-svc-xdsl-ne-ses-tc	

Resource Identifier	Type	Description
	ont-svc-xdsl-ne-uas-tc ont-svc-xdsl-fe-es-tc ont-svc-xdsl-fe-ses-tc ont-svc-xdsl-fe-uas-tc ont-tc-rx-los-frag-tc ont-tc-tx-los-frag-tc ont-tc-bad-gem-hd-tc ont-uni-ds-drpdp-fr-tc ont-uni-up-drpdp-fr-tc ont-uni-ds-crc-fr-tc ont-uni-up-crc-fr-tc ont-cpu-util-tca ont-mem-util-tca pim-neighbor-down pim-max-mcroutes li-traffic-disabled li-bandwidth-limit li-out-of-res otdr-cap-mismatch login-successful login-failure cfm-defrdrccm cfm-defmacstatus cfm-defremoteccm cfm-deferrorccm cfm-defxconccm cfm-defais bfd-session-down bfd-max-resource bfd-stale-entry tca-outputbw tca-inputbw tca-rxcrcalign tca-txcrcalign tca-txcollisions tca-outputhighbw tca-outputmedbw tca-outputlowbw tca-inpuhighbw tca-inputmediumbw tca-inputlowbw eth-cfm-defrdrccm eth-cfm-defmacstatus eth-cfm-defremoteccm eth-cfm-deferrorccm eth-cfm-defxconccm rsvp-neighbor-down rsvp-instance-down eth-ring-path-block ai-platform-down ai-appl-install-fail ip-assign-fail ont-tr069-serv-mis ont-snmp-mis bsf-dhcpv4 bsf-dhcpv6 bsf-pon	

101 query current alarms by filters

Resource Identifier	Type	Description
	bsf-vbridge	
	bsf-qos	
	bsf-igmp	
	bsf-lxfwd	
	prot-not-available	
	prot-switchover-fail	
	efm-oam-cpelinkfault	
	efm-oam-cpedyinggasp	
	efm-oam-cpecrevt	
	ont-loopdetect	
	alm-tbl-overflow	
	auto-switch-status	
	auswqueuefullatm	
	auswbkpfailatm	
	auswrecfgfailatm	
	auswdataunatm	
	auswqueuefulptm	
	auswbkpfailptm	
	auswrecfgfailptm	
	auswdataunptm	
	auswbakpfailatm	
	chpr-com-fail	
	chpr-tx-fail	
	chpr-unprov-ont	
	chpr-prov-mismatch	
	chpr-loss-sig	
	chpr-diagnostic	
	chpr-loid-conflict	
	chpr-loid-pwd-err	
	chpr-stk-laser-dis	
	chpr-sfp-mismatch	
	chpr-rng-mismatch	
	chpr-alien-test	
	chpr-alien-detect	
	chpr-deact-hightca	
	chpr-deact-lowtca	
	chpr-dp-integ	
	olt-chpr-tc-err-frag	
	olt-chpr-up-bw-tca	
	olt-chpr-down-bw-tca	
	cfg-dld-fail	
	cfg-act-fail	
	cfg-dld-ip	
	cfg-ver-mismatch	
	cfg-file-missing	
	cfg-verctrl-err	
	cfg-not-supported	
	ont-prot-not-available	
	ont-gen-temp-low	
	ont-gen-volt-low	
	ont-gen-tx-pwr-high	
	ont-gen-bias-low	
	ont-gen-rx-hwarn	
	ont-gen-rx-lwarn	
	ont-gen-tx-hwarn	
	ont-gen-tx-lwarn	
	ont-gen-temp-hwarn	

Resource Identifier	Type	Description
	ont-gen-temp-lwarn	
	ont-gen-volt-hwarn	
	ont-gen-volt-lwarn	
	ont-gen-bias-hwarn	
	ont-gen-bias-lwarn	
	sfu-sup2-temp-low	
	sfu-sup2-volt-low	
	sfu-sup2-tx-high	
	sfu-sup2-bias-low	
	sfu-sup2-rx-hwarn	
	sfu-sup2-rx-lwarn	
	sfu-sup2-tx-hwarn	
	sfu-sup2-tx-lwarn	
	sfu-sup2-temp-hwarn	
	sfu-sup2-temp-lwarn	
	sfu-sup2-volt-hwarn	
	sfu-sup2-volt-lwarn	
	sfu-sup2-bias-hwarn	
	sfu-sup2-bias-lwarn	
	soho-sup2-temp-low	
	soho-sup2-volt-low	
	soho-sup2-tx-high	
	soho-sup2-bias-low	
	soho-sup2-rx-hwarn	
	soho-sup2-rx-lwarn	
	soho-sup2-tx-hwarn	
	soho-sup2-tx-lwarn	
	soho-sup2-temp-hwarn	
	soho-sup2-temp-lwarn	
	soho-sup2-volt-hwarn	
	soho-sup2-volt-lwarn	
	soho-sup2-bias-hwarn	
	soho-sup2-bias-lwarn	
	mdu-sup2-temp-low	
	mdu-sup2-volt-low	
	mdu-sup2-tx-high	
	mdu-sup2-bias-low	
	mdu-sup2-rx-hwarn	
	mdu-sup2-rx-lwarn	
	mdu-sup2-tx-hwarn	
	mdu-sup2-tx-lwarn	
	mdu-sup2-temp-hwarn	
	mdu-sup2-temp-lwarn	
	mdu-sup2-volt-hwarn	
	mdu-sup2-volt-lwarn	
	mdu-sup2-bias-hwarn	
	mdu-sup2-bias-lwarn	
	cust-alm1	
	cust-alm2	
	cust-alm3	
	cust-alm4	
	cust-alm5	
	cust-alm6	
	cust-alm7	
	cust-alm8	
	cust-alm9	
	cust-alm10	

101 query current alarms by filters

Resource Identifier	Type	Description
	cust-alm11 cust-alm12 cust-alm13 cust-alm14 cust-alm15 cust-alm16 cust-alm17 cust-alm18 cust-alm19 cust-alm20 cust-alm21 cust-alm22 cust-alm23 cust-alm24 cust-alm25 cust-alm26 cust-alm27 cust-alm28 cust-alm29 cust-alm30 cust-alm31 ethernet-ring-pthfwst ethernet-ring-fop-to ethernet-ring-fop-pm fpm-depletion exp-seizureack exp-disconack exp-forcerelack packet-loss remote-packet-loss no-dsp-resource la-down la-standby-na la-switch-fail la-degrade melt-board-reset board-shelf-mismatch fcs-thresh-exceed) Possible values: - all : all alarms for query - xtca-ne-es : errored seconds in 15 min - xtca-ne-ses : severely errored seconds in 15 min - xtca-ne-uas : unavailable seconds in 15 min - xtca-ne-day-es : errored seconds in 1 day - xtca-ne-day-ses : severely errored seconds in 1 day - xtca-ne-day-uas : unavailable seconds in 1 day - xtca-fe-es : errored seconds in 15 min - xtca-fe-ses : severely errored secs in 15 min - xtca-fe-uas : unavailable seconds in 15 min - xtca-fe-day-es : errored seconds in 1 day - xtca-fe-day-ses : severely errored secs in 1 day - xtca-fe-day-uas : unavailable seconds in 1 day - xtca-leftrs : low error free throughput seconds in 15 min - xtca-day-leftrs : low error free throughput seconds in 1 day - xtca-fe-leftrs : far end low error free throughput seconds in 15 min - xtca-fe-day-leftrs : far end low error free throughput	

Resource Identifier	Type	Description
	seconds in 1 day - xtca-auto-port-reset : auto-port-resets in 1 week - xtca-reinit : Reinitialization seconds in 15 min - xtca-day-reinit : Reinitialization seconds in 1 day - xdsl-ne-los : loss of signal - xdsl-ne-lof : loss of frame - xdsl-ne-lom : loss of margin - xdsl-ne-ese : excessive severe errors - xdsl-act-cfg-error : line configuration data cannot be used - xdsl-act-not-feas : line capacity not enough to setup requested profile - xdsl-up-br-reach : planned bitrate not reached after initialization - xdsl-ne-ncd : no cell delineation - xdsl-ne-lcd : loss of cell delineation - xdsl-fe-los : loss of signal - xdsl-fe-lof : loss of frame - xdsl-fe-lpr : loss of power - xdsl-fe-lol : loss of link - xdsl-fe-lom : loss of margin - xdsl-fe-ese : excessive severe errors - xdsl-fe-upbo-vio : upbo violation - xdsl-fe-cpe-pol : activation failure cpe policing - xdsl-tpstc-mis : mismatch between the configured tps-tc mode and the mode supported by the connected cpe - xdsl-act-comm : init not successful due to communications problem - xdsl-act-modem : no peer modem detected - xdsl-do-br-reach : planned bitrate not reached after init - xdsl-fe-ncd : no cell delineation - xdsl-fe-lcd : loss of cell delineation - xdsl-frtx-init-fail : init not successful due to forced rtx - xdsl-vect-dle : vectoring disorderly leaving event - xdsl-fe-mis-peer-35b : VDSL2 35b opmode mismatch between XTU-C and XTU-R - vectline-xtc-var-vict : excessive victim crosstalk coefficients variation - vectline-xtc-var-dist : excessive disturber crosstalk coefficients variation - vectline-corp-errf : corrupted or missing errorf-samples - vect-cpe-cap-mismatch : not allowed Vectoring CPE connected - vectline-conf_notfeas : vect line configuration not feasible - vect-vp-lt-mismatch : actual vp-lt connection(s) do not match expected vp-lt connection(s) or vp-lt connection lost - vect-inv-qsf : qsf has no valid Nokia ID - vect-vp-lt-fail : vp-lt connection not operational - vect-no-gain-at-init : Lines cannot train in gain-at-init mode - sw-rollback : non active oswp,db cannot be operational - will rollback - db-rollback : selected oswp,db cannot be operational - will rollback - xvps-inv-dbase : invalid xvps dbase - inv-cde-file : invalid xvps cde file - miss-cde-file : missing cde profile - cde-hash-error : cde profile hash error	

101 query current alarms by filters

Resource Identifier	Type	Description
	- low-disk-space : insufficient space for Sw storage - cell-discard-up : cell discarded in the upstream direction - cell-discard-down : cell discarded in the downstream direction - persist-data-loss : all data lost after restart - system not configured - mac-conflict : duplicate mac address on the bridge port - vmac-full : virtual mac address is full on the bridge port - snmp-comm-lost : snmp server not responding - preferred-mode : preferred mode not available - timing-reference : timing reference failure - nt-disk-95%full : nt disk 95% full - shub-loc : communication lost with shub - cf-error : compact flash access error - back-pnl-inv : BackPanel-type Invalid - ihub-conf-loss : iHub configuration loss - recent changes lost - rack-power : power fuse broken - rack-fan-unit1 : fan unit rack 1 failing - rack-fan-unit2 : fan unit rack 2 failing - shelf-mismatch : shelf type different from planned type - shelf-missing : detected shelf no longer detected - shelf-install-missing : shelf planned but not installed - door : open cabinet door - ac-power-fail : external power failure - shelf shutdown in 15 minutes - board-mismatch : board inserted different from planned - waiting-for-sw : not able to download all the applicable sw files - temp-exceeded : temperature threshold exceeded on the board - backplane-data-failure: It port on backplane data failure - temp-shutdown : board powered down itself - too high temperature - board-missing : board detected after planning - now missing - board-instl-missing : board never detected after planning - board-init : board initialisation failure - board-reset-prot : number of resets exceeded - sem-power-fail : SEM external power failure - sem-ups-fail : SEM external power supply failure - board-reset-cf : board reset and/or communication failure - vlan-assign-fail : failure to assign VLAN for a user session - vsa-info-invalid : radius fail to assign a valid vsa to a user session - auth-mac-conflict : failure to check mac conflict for a user session - user-pwd-fault : failure to check user or password of a user session - up-plan-bitrate : upstream bitrate is above min and below planned - up-min-bitrate : upstream bitrate is below min bitrate - up-config-not-feas : upstream bitrate is not enough to set up config group - down-plan-bitrate : downstream bitrate is above min and below planned - down-min-bitrate : downstream bitrate is below min bitrate	

Resource Identifier	Type	Description
	- down-config-not-feas : downstream bitrate is not enough to set up config group - non-bonding-cpe : no bonding cpe modem is connected - multiple-cpes : bonding group has multiple cpe modems connected - register : bonding group discovery or aggregation register failure - group-incomplete : bonding group is incomplete - host-sfp-los : loss of signal - host-sfp-tx-fail : Tx failure - host-sfp-not-prst : not present - host-sfp-inv-id : no valid Nokia ID - host-sfp-ctrl-fail : control failure - host-sfp-rmtlt : unexpected remote plug-in - host-sfp-mismatch : assignment does not match reported rack/shelf/slot - host-sfp-incompt : incompatible shelf type detected - exp-sfp-los : expansion side loss of signal - exp-sfp-tx-fail : Tx failure - exp-sfp-not-prst : not present - exp-sfp-inv-id : no valid Nokia ID - exp-sfp-ctrl-fail : control failure - exp-sfp-1-los : expansion side sfp1 loss of signal - exp-sfp-2-los : expansion side sfp2 loss of signal - ext-qsfps-invld : Invalid Nokia ID - tx-power-high-alarm : tx power more than alarm range - tx-power-low-alarm : tx power less than alarm range - rx-power-high-alarm : rx power more than alarm range - rx-power-low-alarm : rx power less than alarm range - tx-biascur-high-alarm : tx bias current high alarm - tx-biascur-low-alarm : tx bias current low alarm - volt-high-alarm : voltage high alarm - volt-low-alarm : voltage low alarm - temp-high-alarm : temperature high alarm - temp-low-alarm : temperature low alarm - tx-power-high-warn : tx power more than warn range - tx-power-low-warn : tx power less than warn range - rx-power-high-warn : rx power more than warn range - rx-power-low-warn : rx power less than warn range - tx-biascur-high-warn : tx bias current high warn - tx-biascur-low-warn : tx bias current low warn - volt-high-warn : voltage high warn - volt-low-warn : voltage low warn - temp-high-warn : temperature high warn - temp-low-warn : temperature low warn - onu-unprovisioned : unprovisioned ont - signal-loss : pon loss of signal - bitrate-high : the error bit rate high at pon interface - opmodule-mismatch : the optical module mismatched at pon interface - key-fail-one-churn : key exchange failure during one churning time - key-fail-three-churn : key exchange failure during three churning time - oam-discov-fail : extend oam discovery failure - report-timeout : report timeout detecting - total-packets-exceed : total amount of protocol packets	

101 query current alarms by filters

Resource Identifier	Type	Description
	exceed threshold - arp-packets-exceed : protocol arp packets exceed threshold - dhcp-packets-exceed : protocol dhcp packets exceed threshold - igmp-packets-exceed : protocol igmp packets exceed threshold - pppoe-packets-exceed : protocol pppoe packets exceed threshold - nd-packets-exceed : protocol nd packets exceed threshold - icmpv6-packets-exceed : protocol icmpv6 packets exceed threshold - mld-packets-exceed : protocol mld packets exceed threshold - dhcpv6-packets-exceed : protocol dhcpv6 packets exceed threshold - cfm-packets-exceed : protocol cfm packets exceed threshold - dsx1-serdes-fail : SERDES clock alarm failure - dsx1-tributary1-fail : The tributary 1 clock is not present - dsx1-tributary2-fail : The tributary 2 clock is not present - dsx1-los-fail : All the selected tribs in Loss of Signal - dsx1-ais-sync : Alarm Indication signal on the tributary selected as sync source - dsx1-lof-sync : Loss of Framing on the tributary selected as sync source - dsx1-los-sync : Loss of signal on the tributary selected as sync source - dsx1-deg-fail : Signal degrade Alarm - dsx1-rei-from-liu : Remote Error Indication alarm from LIU - dsx1-rdi-from-liu : Remote Defect Alarm from LIU - dsx1-crc6-from-liu : Cyclic Redundancy check-6 alarm from LIU - dsx1-crc4-from-liu : Cyclic Redundancy check-4 alarm from LIU - dsx1-crc4-th-from-liu : Cyclic Redundancy check-4 threshold alarm from LIU - dsx1-ais-from-liu : Alarm Indication Signal alarm from LIU - dsx1-los-from-liu : Loss of signal alarm from LIU - dsx1-lof-from-liu : Loss of framing alarm from LIU - dsx1-lomf-from-liu : Loss of Multi-frame alarm from LIU - dsx1-rei-from-iwf : Remote Error Indication alarm from IWF - dsx1-rdi-from-iwf : Remote Defect Alarm from IWF - dsx1-crc6-from-iwf : Cyclic Redundancy check-6 alarm from IWF - dsx1-crc4-from-iwf : Cyclic Redundancy check-4 alarm from IWF - dsx1-crc4-th-from-iwf : Cyclic Redundancy check-4 threshold alarm from IWF - dsx1-ais-from-iwf : Alarm Indication Signal alarm from IWF - dsx1-los-from-iwf : Loss of signal alarm from IWF - dsx1-lof-from-iwf : Loss of framing alarm from IWF - dsx1-lomf-from-iwf : Loss of Multi-frame alarm from IWF - pppce-trans-15min-tca : 15 minutes transaction timeout	

Resource Identifier	Type	Description
	- count exceeds configured TCA - pppce-sess-15min-tca : 15 minutes session timeout count exceeds configured TCA - pppce-trans-1day-tca : 1day transaction timeout count exceeds configured TCA - pppce-sess-1day-tca : 1day session timeout count exceeds configured TCA - custom1 : customizable alarm 1 - custom2 : customizable alarm 2 - custom3 : customizable alarm 3 - custom4 : customizable alarm 4 - custom5 : customizable alarm 5 - he-custom1 : host expansion customizable alarm 1 - he-custom2 : host expansion customizable alarm 2 - he-custom3 : host expansion customizable alarm 3 - he-custom4 : host expansion customizable alarm 4 - he-custom5 : host expansion customizable alarm 5 - he-custom6 : host expansion customizable alarm 6 - custom6 : customizable alarm 6 - custom7 : customizable alarm 7 - custom8 : customizable alarm 8 - custom9 : customizable alarm 9 - custom10 : customizable alarm 10 - custom11 : customizable alarm 11 - custom12 : customizable alarm 12 - custom13 : customizable alarm 13 - custom14 : customizable alarm 14 - custom15 : customizable alarm 15 - custom16 : customizable alarm 16 - custom17 : customizable alarm 17 - loss-swo-cap : switch over capability in a redundant system - ping-check-fail : ping check in a redundant system - der-temp1 : Derived Alarm for Temporal Filter 1 - der-temp2 : Derived Alarm for Temporal Filter 2 - der-temp3 : Derived Alarm for Temporal Filter 3 - der-temp4 : Derived Alarm for Temporal Filter 4 - der-temp5 : Derived Alarm for Temporal Filter 5 - der-temp6 : Derived Alarm for Temporal Filter 6 - der-temp7 : Derived Alarm for Temporal Filter 7 - der-temp8 : Derived Alarm for Temporal Filter 8 - der-temp9 : Derived Alarm for Temporal Filter 9 - der-temp10 : Derived Alarm for Temporal Filter 10 - der-temp11 : Derived Alarm for Temporal Filter 11 - der-temp12 : Derived Alarm for Temporal Filter 12 - der-temp13 : Derived Alarm for Temporal Filter 13 - der-temp14 : Derived Alarm for Temporal Filter 14 - der-temp15 : Derived Alarm for Temporal Filter 15 - der-temp16 : Derived Alarm for Temporal Filter 16 - der-temp17 : Derived Alarm for Temporal Filter 17 - der-temp18 : Derived Alarm for Temporal Filter 18 - der-temp19 : Derived Alarm for Temporal Filter 19 - der-temp20 : Derived Alarm for Temporal Filter 20 - der-temp21 : Derived Alarm for Temporal Filter 21 - der-temp22 : Derived Alarm for Temporal Filter 22 - der-temp23 : Derived Alarm for Temporal Filter 23 - der-temp24 : Derived Alarm for Temporal Filter 24 - der-temp25 : Derived Alarm for Temporal Filter 25	

101 query current alarms by filters

Resource Identifier	Type	Description
	- der-temp26 : Derived Alarm for Temporal Filter 26 - der-temp27 : Derived Alarm for Temporal Filter 27 - der-temp28 : Derived Alarm for Temporal Filter 28 - der-temp29 : Derived Alarm for Temporal Filter 29 - der-temp30 : Derived Alarm for Temporal Filter 30 - der-temp31 : Derived Alarm for Temporal Filter 31 - der-spa1 : Derived Alarm for Spatial Filter 1 - der-spa2 : Derived Alarm for Spatial Filter 2 - der-spa3 : Derived Alarm for Spatial Filter 3 - der-spa4 : Derived Alarm for Spatial Filter 4 - der-spa5 : Derived Alarm for Spatial Filter 5 - der-spa6 : Derived Alarm for Spatial Filter 6 - der-spa7 : Derived Alarm for Spatial Filter 7 - der-spa8 : Derived Alarm for Spatial Filter 8 - der-spa9 : Derived Alarm for Spatial Filter 9 - der-spa10 : Derived Alarm for Spatial Filter 10 - der-spa11 : Derived Alarm for Spatial Filter 11 - der-spa12 : Derived Alarm for Spatial Filter 12 - der-spa13 : Derived Alarm for Spatial Filter 13 - der-spa14 : Derived Alarm for Spatial Filter 14 - der-spa15 : Derived Alarm for Spatial Filter 15 - der-spa16 : Derived Alarm for Spatial Filter 16 - der-spa17 : Derived Alarm for Spatial Filter 17 - der-spa18 : Derived Alarm for Spatial Filter 18 - der-spa19 : Derived Alarm for Spatial Filter 19 - der-spa20 : Derived Alarm for Spatial Filter 20 - der-spa21 : Derived Alarm for Spatial Filter 21 - der-spa22 : Derived Alarm for Spatial Filter 22 - der-spa23 : Derived Alarm for Spatial Filter 23 - der-spa24 : Derived Alarm for Spatial Filter 24 - der-spa25 : Derived Alarm for Spatial Filter 25 - der-spa26 : Derived Alarm for Spatial Filter 26 - der-spa27 : Derived Alarm for Spatial Filter 27 - der-spa28 : Derived Alarm for Spatial Filter 28 - der-spa29 : Derived Alarm for Spatial Filter 29 - der-spa30 : Derived Alarm for Spatial Filter 30 - der-spa31 : Derived Alarm for Spatial Filter 31 - apsf-alarm : Applique Power Supply Failure - custextalarm1 : Customizable External Alarm Number 1 - custextalarm2 : Customizable External Alarm Number 2 - custextalarm3 : Customizable External Alarm Number 3 - custextalarm4 : Customizable External Alarm Number 4 - custextalarm5 : Customizable External Alarm Number 5 - pluginfan : REM Fan Alarm - plugin-dc-a : REM DC A Alarm - plugin-dc-b : REM DC B Alarm - plugin-dg : Dying Gasp Alarm - ntr-a-loss : NTR-A signal is not available - ntr-b-loss : NTR-B signal is not available - xvps-conf-loss : xvps configuration loss - mac-entry-nofree : no free mac entry in the mac table on It board - fibre-conn-mismatch : REM Fibre Connection Mismatch Alarm - link-cap-mismatch : Link speed capability mismatch - eqpt-cap-mismatch : Link equipment capability mismatch - ctrl-dnld-failure : Controller card download failure	

Resource Identifier	Type	Description
	- melt-hw-issue : MELT hardware issue - melt-board-reset : MELT board reset - board-shelf-mismatch : board type and shelf type mismatch - mgnt-type-mismatch : Board management type mismatch - fileserv-unavail : file transfer Server unavailable or file transfer failed - shdsl-n-loopback : loopback active at the network side - shdsl-c-loopback : loopback active at the customer side - shdsl-conferr : configuration error - shdsl-atm-lcd : loss of atm cell delineation - shdsl-lpr : loss of power at stu-r - shdsl-secu-err : unable to disable stu-r access - shdsl-dev-fault : device fault - shdsl-atm-ncd : no atm cell delineation - shdsl-n-losw : loss of sync word at the network side on each pair - shdsl-c-losw : loss of sync word at the customer side on each pair - shdsl-n-aten : loop attenuation alarm at the network side on each pair - shdsl-c-aten : loop attenuation alarm at the customer side on each pair - shdsl-n-snr : snr margin alarm at the network side each pair - shdsl-c-snr : snr margin alarm at the customer side on each pair - shdsl-n-dccont : dc continuity fault at the network side on each pair - shdsl-c-dccont : dc continuity fault at the customer side on each pair - shdsl-c-actfail : activation failure at the customer side on each pair - e1-fe-rai : Receiving Remote Alarm Indication - e1-ne-rai : Transmitting Remote Alarm Indication - e1-fe-ais : Receiving Alarm Indication Signal - e1-ne-ais : Transmitting Alarm Indication Signal - e1-lof : E1 Loss of frame - e1-los : E1 Loss of Signal - e1-loopback : E1 facility in loopback - ima-grp-fe-su : far-end starting up - ima-grp-fe-cfg : far-end failed configuration - ima-grp-ne-cfg : near-end failed configuration - ima-grp-fe-nl : insufficient number of links at far-end - ima-grp-ne-nl : insufficient number of links at near-end - ima-grp-fe-blk : far-end is blocked - ima-lnk-lif : loss of ima frame - ima-lnk-lods : link out of delay synchronization - ima-lnk-misc : link misconnect - ima-lnk-rfi : link remote failure indication - ima-lnk-fault : fault in link facility - ima-lnk-txblk : transmit blocked due to far-end - ima-lnk-rxblk : receive blocked due to far-end - bad-digitmap : Configured digitmap is unusable - dhcp-unreach : The DHCP server is unreachable - dhcp-no-srv : The address in DHCP reply is NULL - dhcp-inv-srv : The address in DHCP reply is invalid - norpniewithsoftdsp : do not plan / plug-in RPNI-E board with SoftDsp SW image	

101 query current alarms by filters

Resource Identifier	Type	Description
	- unknown-sub : subscriber exist in the POLT, but not in the appl server - ground-key : Return current to the ground - port-hightemp : Temperature threshold on user port exceeded. - port-jbfltca : JB fill level threshold on user port exceeded. - reg-domainname : Registration failure (resolving domain name). - reg-auth : Registration failure (authentication). - reg-timeout : Registration failure (message timeout). - reg-srvfailresp : Registration failure (failure response from server). - inv-domainname : Invitation failure (resolving domain name). - inv-auth : Invitation failure (authentication). - inv-timeout : Invitation failure (message timeout). - inv-srvfailresp : Invitation failure (failure response from server). - subs-srvfailresp : Subscribe failure (failure response from server). - subs-domainname : Subscribe failure (resolving domain name). - subs-auth : Subscribe failure (authentication). - subs-refreshfail : Subscribe failure (refresh failure). - subs-inittimeout : Subscribe failure (initial REQ timeout). - emergency-call : Emergency call for SIP POTS is ongoing. - e1sip-reg-domainname : E1 sip termination registration failure (resolving domain name). - e1sip-reg-auth : E1 sip termination registration failure (authentication). - e1sip-reg-timeout : E1 sip termination registration failure (message timeout). - e1sip-reg-srvfailresp : E1 sip termination registration failure (failure response from server). - e1sip-inv-domainname : E1 sip termination invitation failure (resolving domain name). - e1sip-inv-auth : E1 sip termination invitation failure (authentication). - e1sip-inv-timeout : E1 sip termination invitation failure (message timeout). - e1sip-inv-srvfailresp : E1 sip invitation failure (failure response from server). - e1sip-emergency-call : Emergency call for ISDN PRA/CAS R2 is ongoing. - e1itf-ais-signal : Alarm Indication Signal detected at E1 interface. - e1itf-los-signal : Loss Of Signal detected at E1 interface. - e1itf-rai-signal : Remote Alarm Indication detected at E1 interface. - e1sip-misconfig-mgc10 : Configuration not conform with the core network entity. - e1sip-nsmprf-missed : The SIP termination requires a NSM profile. - e1t1itf-recv-ais : Alarm Indication Signal received at interface. - e1t1itf-recv-los : Loss Of Signal received at interface. - e1t1itf-recv-rai : Remote Alarm Indication received at	

Resource Identifier	Type	Description
	interface. - transport-mismatch : Transport protocol mismatch - dns-lookup-failure : Dns look up failure - none-dns-srv : No reply for all DNS serverd - no-dns-srv : No DNS servers configured - none-srv : No reply for all SIP First Hops - no-srv : No SIP First Hop configured - reg-srv-unreach : All SIP register servers are unreachable - proxy-srv-unreach : All SIP proxy servers are unreachable - dhcp-srv-unreach : The DHCP server is unreachable on this board - fo-trigger : Fail Over Triggered - fb-trigger : Fail Back Triggered - du-trigger : Deliberate Update Triggered - ssp-missing : SSP Missing in CDE - dns-pool-exceed : Number of different SG associated DNS pools exceed - lsa-fo-trigger : SIP voice service degraded - fail-over to LSA server - reg-domainname-sec : Registration failure (resolving domain name). - reg-auth-sec : Registration failure (authentication). - reg-timeout-sec : Registration failure (message timeout). - reg-srvfailresp-sec : Registration failure (failure response from server). - inv-domainname-sec : Invitation failure (resolving domain name). - inv-auth-sec : Invitation failure (authentication). - inv-timeout-sec : Invitation failure (message timeout). - inv-srvfailresp-sec : Invitation failure (failure response from server). - subs-srvfailresp-sec : Subscribe failure (failure response from server). - subs-domainname-sec : Subscribe failure (resolving domain name). - subs-auth-sec : Subscribe failure (authentication). - subs-refreshfail-sec : Subscribe failure (refresh failure). - subs-inittimeout-sec : Subscribe failure (initial REQ timeout). - emergency-call-sec : Emergency call for Secondary Termination is ongoing. - fanout : Lt load overflow - up-overflow : Upstream load overflow - upobc-overflow : Upstream load to OBC overflow - dwobc-overflow : Downstream load to OBC overflow - dw-overflow : Downstream load overflow - lwpri-overflow : The number of BE and CL pkts dropped exceed threshold - queue-drop : The number of pkts dropped by queue exceeds threshold - queue-load : The queue load exceeds threshold - queue-peak-usage : The queue peak usage exceeds threshold - mgc-unreachable : loss of contact with the media gateway controller - failover-to-esamgc : failover to esa mgc - sgc-unreachable : loss of contac with signaling gateway	

101 query current alarms by filters

Resource Identifier	Type	Description
	controller - lcard-unreach-srvcard : line card unreachable with server card - lcard-type-mismatch : associate board of wrong type - meg-unknown-sub : the megaco subscriber is unknown - meg-ground-key : voice port ground key - meg-high-temp : voice port high temperature - meg-act-fail : the first link layer for isdn subscriber activation failure - meg-over-current : voice port over current - line-showering : line showering - low-qos-packetloss : the total packet loss has exceeded the configured threshold - low-qos-jitter : the rtp jitter has exceeded the configured threshold - low-qos-delay : the rtp delay has exceeded the configured threshold - sig-brd-persist-loss : voice signaling board persistent data loss - sig-brd-disk-full : voice signaling board disk 90% full - sig-brd-db-rollback : voice signaling board db rollback - mg-overload : mg overload - meg-unknown-sub-sec : The Megaco subscriber exists in voice signaling board but not in media gateway controller. - line-showering-sec : A subscriber line exceeds 20 off-hook / on-hook events / minute. - loss-env-mon : env-monitor box lost or not alive - etca-los : loss of signal errors in 15 min - etca-fcs : frame check sequence errors in 15 min - etca-day-los : loss of signal errors in 1 day - etca-day-fcs : frame check sequence errors in 1 day - etca-rx-octets : received octets in 15 min - etca-tx-octets : transmitted octets in 15 min - etca-day-rx-octets : received octets in 1 day - etca-day-tx-octets : transmitted octets in 1 day - user-sfp-los : user sfp loss of signal - user-sfp-tx-fail : user sfp tx failure - user-sfp-not-prst : user sfp not detected - user-sfp-inv-id : user sfp invalid id - user-sfp-t-exceed : user sfp temperature exceed - user-sfp-mismatch : user sfp mismatch the configured type - uplink-sfp-los : uplink sfp loss of signal - uplink-sfp-tx-fail : uplink sfp tx failure - uplink-sfp-not-prst : uplink sfp not detected - uplink-sfp-inv-id : uplink sfp invalid id - uplink-sfp-t-exceed : uplink sfp temperature exceed - uplink-sfp-mismatch : uplink sfp mismatch the configured type - loss-lsmwp-cap : lsm redundancy - inv-xvps-pair-data : invalid xvps pair redundancy data - network-power-loss : Loss of Network Power - hw-fault : Hardware Failure - bat-miss : Power Source Battery Missing - bat-fail : Power Source Battery Failure - bat-low : Power Source Battery Charge LOW - bat-a-fail : Power Source BAT-A Fail - bat-b-fail : Power Source BAT-B Fail	

Resource Identifier	Type	Description
	- ac-vol-out-range : AC Input Voltage Value Out of Range - network-power-loss-b : Loss of Network Power B - sem-ac-power-fail : External AC power supply failure - sem-ups-low-volt : External power supply low voltage - dc-a-fail : Local DC A power failure - dc-b-fail : Local DC B power failure - plan-power-mismatch : Planned and detected power mode mismatch - water-seepage-in-box : Detected water seepage in enclosure - sealed-box-open : Sealed box open detected - dc-a-vol-out-range : DC A Input Voltage Value Out of Range - dc-b-vol-out-range : DC B Input Voltage Value Out of Range - inlet-temp-major : The inlet temperature has exceeded a major level - inlet-temp-critical : The inlet temperature has exceeded a critical level - psu-fail-crit : Power Supply failure - psu-a-fail-presence : Power Supply A is not present - psu-a-fail-vin-ac-nok : Power Supply A has Vin AC fault - psu-a-fail-vin-uv : Power Supply A has Vin undervoltage - psu-a-fail-vin-ov : Power Supply A has Vin overvoltage - psu-a-fail-vout-uv : Power Supply A has Vout undervoltage - psu-a-fail-vout-ov : Power Supply A has Vout overvoltage - psu-a-fail-iout-oc : Power Supply A has Iout overcurrent - psu-a-fail-ovtemp : Power Supply A has over temperature - psu-b-fail-presence : Power Supply B is not present - psu-b-fail-vin-ac-nok : Power Supply B has Vin AC fault - psu-b-fail-vin-uv : Power Supply B has Vin undervoltage - psu-b-fail-vin-ov : Power Supply B has Vin overvoltage - psu-b-fail-vout-uv : Power Supply B has Vout undervoltage - psu-b-fail-vout-ov : Power Supply B has Vout overvoltage - psu-b-fail-iout-oc : Power Supply B has Iout overcurrent - psu-b-fail-ovtemp : Power Supply B has over temperature - synce-fail : synce clock source failure - bits-fail : bits clock source failure - bits-output-shutoff : bits output failure - ieee1588-fail : ieee1588 clock source failure - gnss-fail : gnss clock source failure - ieee1588-hybrid-fail : ieee1588 hybrid tod source failure - signal-loss : synce or bits clock signal loss - signal-efd : synce or bits clock signal exceed frequency deviation - esmc-loss : clock source loss SSM information - bits-output-exceed : exceed bits output threshold - ql-input-exceed : exceed input clock source threshold - holdover : clock system is in the holdover - lti : all clock source failed - tod-reference-fail : Timing ToD Reference failed - internal-clk-fail : Internal CLK failed - bgp-peer-down : peer operational state is down	

101 query current alarms by filters

Resource Identifier	Type	Description
	- bgp-routes-mid-limit : 90% of max nbr of routes BGP can learn from a peer is reached - isis-adjacency-down : isis adjacency is down - isis-adjacency-reject : isis adjacency is rejected - isis-instance-down : isis instance is down or not - ospf-lsa-limit : limit of received LSA's is reached - ospf-lsa-mid-limit : 90% of limit of received LSA's is reached - ospf-neighbor-down : OSPF neighbour is down - ospf-instance-down : OSPF instance is down or not - ospf3-lsa-limit : limit of received OSPFv3 LSAs is reached - ospf3-lsa-mid-limit : 90% of limit of received OSPFv3 LSAs is reached - ospf3-neighbor-down : OSPFv3 neighbour is down - ospf3-instance-down : OSPFv3 instance is down or not - rip-instance-down : rip instance down - lag-down : lag down - lagsubgrp-thresh-reach: lag subgroup threshold reached - lagsubgrp-switch-fail : lag subgroup switchover failed - no-unpinned-free-ports: No free ports available for unpinned traffic - general-arp-limit : arp limit exceeded - gen-switch-out-of-res : failure due to lack of resources on switch - ipv6-nc-limit : ipv6 neighbor cache limit exceeded - dhcp-session-oor : dhcp session out of resources - ihub-fdb-limit : layer 2 fdb limit reached - ihub-mac-limit : layer 2 mac limit reached - l2fw-stp-exception : STP exception condition is present in the SAP - l2fw-stp-root-guard : STP root guard violation is present - vprn-routes-limit : limit of ip is reached - vprn-ipv6-routes-limit: limit of ipv6 is reached - dhcpv6-lease-limit : limit of dhcpv6 leases is reached - dhcpv4-lease-limit : limit of dhcpv4 leases is reached - vpls-mfib-limit : limit of fib table is reached - ihub-ipv6-dad-own : duplicate IPV6 address is detected for IP address allotted to system - ihub-ipv6-dad : duplicate IPV6 address is detected for a user's IP address - ihub-ipv6-dup-pd-route: ipv6 duplicate pd detected - vpls-duplicate-mac : duplicate mac address is detected - vpls-fdb-limit : limit of fdb table is reached - vpls-self-duplic-mac : duplicate of a system owned mac address detected on a sap - vpls-sdp-self-dup-mac : duplicate of a system owned mac address detected on a sdp binding - link-down : link is down - link-lagport-add-fail : failure to add port to LAG - link-conf-mismatch : SFP+plugin-types does not match the planned speed and/or auto-negotiation for the port - ihub-peer-comm : ihub peer to peer communication failure - ihub-sw-fail : IHUB s/w error - ihub-hw-fail : IHUB h/w error - ihub-link-fail : IHUB link failure - ihub-proc-overload : IHUB processor exceeded - ihub-out-of-mem : IHUB processor out of memory	

Resource Identifier	Type	Description
	- ntp-comm-lost : No response is received from the NTP servers - ldp-instance-down : ldp instance down - ldp-session-down : ldp session down - mpls-instance-down : mpls instance down - mpls-lsp-down : lsp down - mpls-lsp-path-down : lsp path down - sdp-instance-down : sdp instance down - sdp-binding-down : sdp binding down - epipe-instance-down : epipe instance down - lldpmed-portcfg-mis : config request failure for lldpmed portconfig - lldpmed-mediapl-mis : config request failure for lldpmed mediapolicy - vlanport-svc-mismatch : config request failure for the provisioned vlanport - mcsrsrc-stream-lost : multicast video stream lost - eqptsupl-syslog-upload: upload of log file to remote server failure - eqptsupl-ontsw-dnload : ont sw download in progress - cf-75%used : Compact flash exceeds 75% of life expectancy - cf-90%used : Compact flash exceeds 90% of life expectancy - olt-gen-pon-com-fail : pon communication failure on olt - olt-gen-tx-fail : transmitter failure on olt - olt-gen-unprov-ont : unprovisioned ont on pon - olt-gen-pon-eqpt-prov : mismatch btw equipment and provisioning pon attributes - olt-gen-pon-loss-sig : pon loss of signal - olt-gen-pon-diagnostic: pon diagnostic test active - olt-gen-loid-conflict : loid conflict ont on pon - olt-gen-loid-pwderr : loid password error ont on pon - olt-gen-pon-alien-test: pon alien diagnostic test active - olt-gen-alien-detect : pon alien detect active - olt-gen-rng-mism : pon ranging mismatch active - olt-gen-sfp-mism : pon sfp mismatch active - olt-gen-deact-hightca : deactivated ont hightca threshold crossed - olt-gen-deact-lowtca : deactivated ont lowtca threshold crossed - olt-gen-dp-integ : pon data path integriy failure - olt-gen-ddr-fault : pon failure due to ddr fault - olt-pon-tc-err-frag-tc: pon errored fragments threshold crossed - olt-ont-tc-err-frag-tc: ont errored fragments threshold crossed - ont-ploam-loss-sig : loss of signal at ont - ont-ploam-loss-ack : loss of acknowledge from ont - ont-ploam-loss-cd : loss of channel delineation of ont - ont-ploam-phy-eqpt-err: physical equipment error of ont - ont-ploam-startup-fail: startup failure in ranging of ont - ont-ploam-sig-degrade : signal degrade from ont - ont-ploam-disabled : ont disabled alarm - ont-ploam-err-msg : error message from ont - ont-ploam-inactive : inactive ont - ont-ploam-sig-fail : signal fail alarm from ont	

101 query current alarms by filters

Resource Identifier	Type	Description
	- ont-ploam-dying-gasp : dying gasp alarm from ont - ont-ploam-deact-fail : deactive failure of ont - ont-ploam-oam : loss of ploam for ont - ont-ploam-win-drift : drift of window alarm - ont-ploam-rdi : remote defect indication alarm - ont-ploam-loss-ks : loss of key synchronization alarm - ont-ploam-pwr-burst : power bursts on ont - ont-ploam-rog-disa : ont rogue disabled - ont-ploam-diff-reach : ont differential reach exceeded - ont-ploam-looc : Loss of OMCI channel due to persistent MIC failure - sfu-ploam-loss-sig : SFU ONT - loss of signal at ont - sfu-ploam-loss-ack : SFU ONT - loss of acknowledge from ont - sfu-ploam-loss-cd : SFU ONT - loss of channel delineation of ont - sfu-ploam-phy-eqpt-err: SFU ONT - physical equipment error of ont - sfu-ploam-startup-fail: SFU ONT - startup failure in ranging of ont - sfu-ploam-sig-degrade : SFU ONT - signal degrade from ont - sfu-ploam-disabled : SFU ONT - ont disabled alarm - sfu-ploam-err-msg : SFU ONT - error message from ont - sfu-ploam-inactive : SFU ONT - inactive ont - sfu-ploam-sig-fail : SFU ONT - signal fail alarm from ont - sfu-ploam-dying-gasp : SFU ONT - dying gasp alarm from ont - sfu-ploam-deact-fail : SFU ONT - deactive failure of ont - sfu-ploam-oam : SFU ONT - loss of ploam for ont - sfu-ploam-win-drift : SFU ONT - drift of window alarm - sfu-ploam-rdi : SFU ONT - remote defect indication alarm - sfu-ploam-loss-ks : SFU ONT - loss of key synchronization alarm - sfu-ploam-pwr-burst : SFU ONT - power bursts on ont - sfu-ploam-rog-disa : SFU ONT - ont rogue disabled - sfu-ploam-diff-reach : SFU ONT - ont differential reach exceeded - sfu-ploam-looc : SFU ONT - Loss of OMCI channel due to persistent MIC failure - soho-ploam-loss-sig : SOHO ONT - loss of signal at ont - soho-ploam-loss-ack : SOHO ONT - loss of acknowledge from ont - soho-ploam-loss-cd : SOHO ONT - loss of channel delineation of ont - soho-ploam-phy-eqpt-er: SOHO ONT - physical equipment error of ont - soho-ploam-startup-fai: SOHO ONT - startup failure in ranging of ont - soho-ploam-sig-degrade: SOHO ONT - signal degrade from ont - soho-ploam-disabled : SOHO ONT - ont disabled alarm - soho-ploam-err-msg : SOHO ONT - error message from ont - soho-ploam-inactive : SOHO ONT - inactive ont - soho-ploam-sig-fail : SOHO ONT - signal fail alarm from ont	

Resource Identifier	Type	Description
	- soho-ploam-dying-gasp : SOHO ONT - dying gasp alarm from ont - soho-ploam-deact-fail : SOHO ONT - deactive failure of ont - soho-ploam-oam : SOHO ONT - loss of ploam for ont - soho-ploam-win-drift : SOHO ONT - drift of window alarm - soho-ploam-rdi : SOHO ONT - remote defect indication alarm - soho-ploam-loss-ks : SOHO ONT - loss of key synchronization alarm - soho-ploam-pwr-burst : SOHO ONT - power bursts on ont - soho-ploam-rog-disa : SOHO ONT - ont rogue disabled - soho-ploam-diff-reach : SOHO ONT - ont differential reach exceeded - soho-ploam-looc : SOHO ONT - Loss of OMCI channel due to persistent MIC failure - mdu-ploam-loss-sig : MDU ONT - loss of signal at ont - mdu-ploam-loss-ack : MDU ONT - loss of acknowledge from ont - mdu-ploam-loss-cd : MDU ONT - loss of channel delineation of ont - mdu-ploam-phy-eqpt-err: MDU ONT - physical equipment error of ont - mdu-ploam-startup-fail: MDU ONT - startup failure in ranging of ont - mdu-ploam-sig-degrade : MDU ONT - signal degrade from ont - mdu-ploam-disabled : MDU ONT - ont disabled alarm - mdu-ploam-err-msg : MDU ONT - error message from ont - mdu-ploam-inactive : MDU ONT - inactive ont - mdu-ploam-sig-fail : MDU ONT - signal fail alarm from ont - mdu-ploam-dying-gasp : MDU ONT - dying gasp alarm from ont - mdu-ploam-deact-fail : MDU ONT - deactive failure of ont - mdu-ploam-oam : MDU ONT - loss of ploam for ont - mdu-ploam-win-drift : MDU ONT - drift of window alarm - mdu-ploam-rdi : MDU ONT - remote defect indication alarm - mdu-ploam-loss-ks : MDU ONT - loss of key synchronization alarm - mdu-ploam-pwr-burst : MDU ONT - power bursts on ont - mdu-ploam-rog-disa : MDU ONT - ont rogue disabled - mdu-ploam-diff-reach : MDU ONT - ont differential reach exceeded - mdu-ploam-looc : MDU ONT - Loss of OMCI channel due to persistent MIC failure - ont-hpna-ser-mis : hpna ont service mismatch - ont-hpna-los-sig : hpna loss of link - ont-moca-svc-mis : moca ont service mismatch - ont-moca-link-los : moca loss of link - ont-moca-min-bw : moca bw between nodes less than minimum bw - ont-moca-tca-rx-err-fr: moca rx errored frames threshold crossed - ont-sipa-reg-nm-fail : sipua registration name failed	

101 query current alarms by filters

Resource Identifier	Type	Description
	- ont-sipa-reg-rec-fail : sipua register reach failed - ont-sipa-reg-con-fail : sipua register connect failed - ont-sipa-reg-val-fail : sipua register validation failed - ont-sipa-reg-mis : sipua register mismatch - ont-vcd-cfg-nm-fail : vcd config name failed - ont-vcd-cfg-rech-fail : vcd config reach failed - ont-vcd-cfg-conn-fail : vcd config connect failed - ont-vcd-cfg-vali-fail : vcd config validation failed - ont-vcd-cfg-auth-fail : vcd config authentication failed - ont-vcd-cfg-resp-tmout: vcd config response timeout - ont-vcd-cfg-resp-err : vcd config response error - ont-vcd-cfg-file-err : vcd config file error - ont-vcd-sub-nm-fail : vcd subscription name failed - ont-vcd-sub-rech-fail : vcd subscription reach failed - ont-vcd-sub-conn-fail : vcd subscription connect failed - ont-vcd-sub-vali-fail : vcd subscription validation failed - ont-vcd-sub-auth-fail : vcd subscription authentication failed - ont-vcd-sub-resp-tmout: vcd subscription response timeout - ont-vcd-sub-resp-err : vcd subscription response error - ont-vcd-reb-requ : vcd reboot request - ont-vcd-mis : vcd mismatch - ont-mgc-mis : ont mgc mismatch - ont-mgc-timeout : ont mgc timeout - ont-sip-reg-dns : ont services pots sip registration failed (resolving domain name) - ont-sip-reg-fail : ont services pots sip registration authentication failed - ont-sip-reg-timeout : ont services pots sip registration timeout - ont-sip-reg-err-resps : ont services pots sip registration response error - ont-sip-inv-dns : ont services pots sip invitation failed (resolving domain name) - ont-sip-inv-auth : ont services pots sip invitation authentication failed - ont-sip-inv-timeout : ont services pots sip invitation timeout - ont-sip-inv-err : ont services pots sip invitation response error - ont-svc-pots-subs-refr: ont services pots iconfig subscription could not be refreshed - ont-svc-pots-not-refr : ont services pots iconfig notification could not be refreshed - ont-svc-pots-icfg-err : ont services pots service failed due to an unmapped iconfig error - ont-veip-mismatch : ont veip mismatch - ont-ip-host-mismatch : ont ip host mismatch - ont-ip-host-file : ont ip host file unavailable - ont-ip-host-ip-alloc : ont ip host IP allocation failure - olt-pon-up-bw-tca : OLT PON upstream bandwidth TCA - olt-pon-down-bw-tca : OLT PON downstream bandwidth TCA - ont-gen-omci-fail : loss of communication - ont-gen-eqpt-selftest : ont self-test failure - ont-gen-ac-pwr-fail : ac power failure on ont - ont-gen-bat-missing : battery missing	

Resource Identifier	Type	Description
	- ont-gen-bat-low : battery low - ont-gen-bat-fail : battery failure - ont-gen-phys-intrusion: physical intrusion - ont-gen-sw-dnload-f : ont sw download failure - ont-gen-sw-dnload-p : ont sw download in progress - ont-gen-sw-act-fail : ont sw activation failure - ont-gen-eqpt-vers-mis : ont equipment version mismatch - ont-gen-sw-vers-mis : ont sw version mismatch - ont-gen-us-rate-mis : ont upstream rate mismatch - ont-gen-mdu-env1 : mdu environmental alarm#1 - ont-gen-mdu-env2 : mdu environmental alarm#2 - ont-gen-mdu-env3 : mdu environmental alarm#3 - ont-gen-nw-time-err : network timing protocol error - ont-gen-opt-sig-high : optical signal level too high - ont-gen-opt-sig-low : optical signal level too low - ont-gen-eqpt-prov-sa : service affecting mismatch btw equipment and provisioning attributes - ont-gen-eqpt-prov-nsa : non service affecting mismatch btw equipment and provisioning attributes - pon-t-txmcutilhi : pon utilization tx (downstream) multicast high threshold crossed - pon-t-txmcutilmd : pon utilization tx (downstream) multicast medium threshold crossed - pon-t-txmcutillo : pon utilization tx (downstream) multicast low threshold crossed - pon-t-txtotutilhi : pon utilization tx (downstream) total high threshold crossed - pon-t-txtotutilmd : pon utilization tx (downstream) total medium threshold crossed - pon-t-txtotutillo : pon utilization tx (downstream) total low threshold crossed - pon-t-rxtotutilhi : pon utilization rx (upstream) total high threshold crossed - pon-t-rxtotutilmd : pon utilization rx (upstream) total medium threshold crossed - pon-t-rxtotutillo : pon utilization rx (upstream) total low threshold crossed - pon-t-dbacongperiodhi : pon utilization rx (upstream) dbacongperiod high threshold crossed - pon-t-dbacongperiodmd : pon utilization rx (upstream) dbacongperiod medium threshold crossed - pon-t-dbacongperiodlo : pon utilization rx (upstream) dbacongperiod low threshold crossed - pon-t-txucdropfrmhi : pon utilization tx (downstream) unicast drop frame high threshold crossed - pon-t-txucdropfrmmd : pon utilization tx (downstream) unicast drop frame medium threshold crossed - pon-t-txucdropfrmlo : pon utilization tx (downstream) unicast drop frame low threshold crossed - pon-t-txmcdropfrmhi : pon utilization tx (downstream) multicast drop frame high threshold crossed - pon-t-txmcdropfrmmd : pon utilization tx (downstream) multicast drop frame medium threshold crossed - pon-t-txmcdropfrmlo : pon utilization tx (downstream) multicast drop frame low threshold crossed - pon-t-txbcdropfrmhi : pon utilization tx (downstream) broadcast drop frame high threshold crossed	

101 query current alarms by filters

Resource Identifier	Type	Description
	- pon-t-txbcdropfrmmd : pon utilization tx (downstream) broadcast drop frame medium threshold crossed - pon-t-txbcdropfrmlo : pon utilization tx (downstream) broadcast drop frame low threshold crossed - pon-t-rxtotdropfrmhi : pon utilization rx (upstream) total drop frame high threshold crossed - pon-t-rxtotdropfrmmd : pon utilization rx (upstream) total drop frame medium threshold crossed - pon-t-rxtotdropfrmlo : pon utilization rx (upstream) total drop frame low threshold crossed - chpr-t-txmcutilhi : channel-pair utilization tx (downstream) multicast high threshold crossed - chpr-t-txmcutilmd : channel-pair utilization tx (downstream) multicast medium threshold crossed - chpr-t-txmcutillo : channel-pair utilization tx (downstream) multicast low threshold crossed - chpr-t-txtotutilhi : channel-pair utilization tx (downstream) total high threshold crossed - chpr-t-txtotutilmd : channel-pair utilization tx (downstream) total medium threshold crossed - chpr-t-txtotutillo : channel-pair utilization tx (downstream) total low threshold crossed - chpr-t-rxtotutilhi : channel-pair utilization rx (upstream) total high threshold crossed - chpr-t-rxtotutilmd : channel-pair utilization rx (upstream) total medium threshold crossed - chpr-t-rxtotutillo : channel-pair utilization rx (upstream) total low threshold crossed - chpr-t-dbacongperiodhi: channel-pair utilization rx (upstream) dbacongperiod high threshold crossed - chpr-t-dbacongperiodmd: channel-pair utilization rx (upstream) dbacongperiod medium threshold crossed - chpr-t-dbacongperiodlo: channel-pair utilization rx (upstream) dbacongperiod low threshold crossed - chpr-t-txucdropfrmhi : channel-pair utilization tx (downstream) unicast drop frame high threshold crossed - chpr-t-txucdropfrmmd : channel-pair utilization tx (downstream) unicast drop frame medium threshold crossed - chpr-t-txucdropfrmlo : channel-pair utilization tx (downstream) unicast drop frame low threshold crossed - chpr-t-txmcdropfrmhi : channel-pair utilization tx (downstream) multicast drop frame high threshold crossed - chpr-t-txmcdropfrmmd : channel-pair utilization tx (downstream) multicast drop frame medium threshold crossed - chpr-t-txmcdropfrmlo : channel-pair utilization tx (downstream) multicast drop frame low threshold crossed - chpr-t-txbcdropfrmhi : channel-pair utilization tx (downstream) broadcast drop frame high threshold crossed - chpr-t-txbcdropfrmmd : channel-pair utilization tx (downstream) broadcast drop frame medium threshold crossed - chpr-t-txbcdropfrmlo : channel-pair utilization tx (downstream) broadcast drop frame low threshold crossed - chpr-t-rxtotdropfrmhi : channel-pair utilization rx (upstream) total drop frame high threshold crossed - chpr-t-rxtotdropfrmmd : channel-pair utilization rx (upstream) total drop frame medium threshold crossed	

Resource Identifier	Type	Description
	(upstream) total drop frame medium threshold crossed - chpr-t-rxtotdropfrmlo : channel-pair utilization rx (upstream) total drop frame low threshold crossed - sfu-gen-omci-fail : SFU ONT - loss of communication - sfu-gen-eqpt-selftest : SFU ONT - ont self-test failure - sfu-gen-ac-pwr-fail : SFU ONT - ac power failure on ont - sfu-gen-bat-missing : SFU ONT - battery missing - sfu-gen-bat-low : SFU ONT - battery low - sfu-gen-bat-fail : SFU ONT - battery failure - sfu-gen-sw-dnload-f : SFU ONT - ont sw download failure - sfu-gen-sw-dnload-p : SFU ONT - ont sw download in progress - sfu-gen-sw-act-fail : SFU ONT - ont sw activation failure - sfu-gen-eqpt-vers-mis : SFU ONT - ont equipment version mismatch - sfu-gen-sw-vers-mis : SFU ONT - ont sw version mismatch - sfu-gen-us-rate-mis : SFU ONT - ont upstream rate mismatch - sfu-gen-tune-fail : SFU ONT - ont has failed to tune to Target-ChnlPair - sfu-gen-nw-time-err : SFU ONT - network timing protocol error - sfu-gen-opt-sig-high : SFU ONT - optical signal level too high - sfu-gen-opt-sig-low : SFU ONT - optical signal level too low - sfu-gen-eqpt-prov-sa : SFU ONT - service affecting mismatch btw equipment and provisioning attributes - sfu-gen-eqpt-prov-nsa : SFU ONT - non service affecting mismatch btw equipment and provisioning attributes - soho-gen-omci-fail : SOHO ONT - loss of communication - soho-gen-eqpt-selftest : SOHO ONT - ont self-test failure - soho-gen-ac-pwr-fail : SOHO ONT - ac power failure on ont - soho-gen-bat-missing : SOHO ONT - battery missing - soho-gen-bat-low : SOHO ONT - battery low - soho-gen-bat-fail : SOHO ONT - battery failure - soho-gen-sw-dnload-f : SOHO ONT - ont sw download failure - soho-gen-sw-dnload-p : SOHO ONT - ont sw download in progress - soho-gen-sw-act-fail : SOHO ONT - ont sw activation failure - soho-gen-eqpt-vers-mis : SOHO ONT - ont equipment version mismatch - soho-gen-sw-vers-mis : SOHO ONT - ont sw version mismatch - soho-gen-us-rate-mis : SOHO ONT - ont upstream rate mismatch - soho-gen-tune-fail : SOHO ONT - ont has failed to tune to Target-ChnlPair - soho-gen-nw-time-err : SOHO ONT - network timing protocol error - soho-gen-opt-sig-high : SOHO ONT - optical signal level too high - soho-gen-opt-sig-low : SOHO ONT - optical signal level	

101 query current alarms by filters

Resource Identifier	Type	Description
	too low - soho-gen-eqpt-prov-sa : SOHO ONT - service affecting mismatch btw equipment and provisioning attributes - soho-gen-eqpt-prov-nsa: SOHO ONT - non service affecting mismatch btw equipment and provisioning attributes - mdu-gen-omci-fail : MDU ONT - loss of communication - mdu-gen-eqpt-selftest : MDU ONT - ont self-test failure - mdu-gen-ac-pwr-fail : MDU ONT - ac power failure on ont - mdu-gen-bat-missing : MDU ONT - battery missing - mdu-gen-bat-low : MDU ONT - battery low - mdu-gen-bat-fail : MDU ONT - battery failure - mdu-gen-phys-intrusion: MDU ONT - physical intrusion - mdu-gen-sw-dnload-f : MDU ONT - ont sw download failure - mdu-gen-sw-dnload-p : MDU ONT - ont sw download in progress - mdu-gen-sw-act-fail : MDU ONT - ont sw activation failure - mdu-gen-eqpt-vers-mis : MDU ONT - ont equipment version mismatch - mdu-gen-sw-vers-mis : MDU ONT - ont sw version mismatch - mdu-gen-us-rate-mis : MDU ONT - ont upstream rate mismatch - mdu-gen-tune-fail : MDU ONT - ont has failed to tune to Target-ChnlPair - mdu-gen-mdu-env1 : MDU ONT - mdu environmental alarm#1 - mdu-gen-mdu-env2 : MDU ONT - mdu environmental alarm#2 - mdu-gen-mdu-env3 : MDU ONT - mdu environmental alarm#3 - mdu-gen-nw-time-err : MDU ONT - network timing protocol error - mdu-gen-opt-sig-high : MDU ONT - optical signal level too high - mdu-gen-opt-sig-low : MDU ONT - optical signal level too low - mdu-gen-eqpt-prov-sa : MDU ONT - service affecting mismatch btw equipment and provisioning attributes - mdu-gen-eqpt-prov-nsa : MDU ONT - non service affecting mismatch btw equipment and provisioning attributes - ont-gen-sw-dnload-file: ont sw download file missing - ont-gen-fan-fail : ont fan failure - ont-gen-high-temp : ont high temperature - ont-gen-high-temp-ex : ont excessive high temperature - ont-gen-emergency-call: ont emergency call - ont-gen-sw-version : ont sw version control error - ont-poe-exceed-max : ont poe exceed max - ont-poe-overload-yell : ONU is nearing its maximum ability to supply the power - ont-opti-malfunc : malfunction of ONT's optical transceiver - ont-gen-cfgdld-fail : download of voice xml file to ont	

Resource Identifier	Type	Description
	failed - ont-gen-rssi-mis : ONU RSSI configuration mismatch - ont-gen-tx-pwr-low : ONU SFP Tx Power is lower than configured Alarm low threshold - ont-gen-temp-high : ONU SFP Temperature is higher than configured Alarm high threshold - ont-gen-volt-high : ONU SFP Voltage is higher than configured Alarm high threshold - ont-gen-bias-high : ONU SFP Bias is higher than configured Alarm high threshold - ont-loopdetect-mis : ont loop detect mismatch - ont-olt-rx-pw-lo : olt side receive power from ont low - ont-olt-rx-pw-hig : olt side receive power from ont high - ont-olt-rx-pw-warnlo : olt side receive power from ont low warning - ont-olt-rx-pw-warnhig : olt side receive power from ont high warning - ont-gen-tod-out-sync : ONU TOD is out-sync with OLT - ont-gen-tune-fail : ONU has failed to tune to Target-ChnlPair - hgu-tr069-param-fail : hgu tr069 parameters mismatch - ont-gen-tod-mismatch : ONU TOD MISMATCH - sfu-sup-sw-file-error : SFU ONT - Software file has error or is missing - sfu-sup-fan-failure : SFU ONT - Fan failure - sfu-sup-temp-high-warn: SFU ONT - High temperature warning - sfu-sup-temp-shutoff : SFU ONT - Service disabled due to excessive temperature - sfu-sup-emergency-call: SFU ONT - Emergency call active - sfu-sup-swverctrl-err : SFU ONT - Software version control error - sfu-sup-poe-exceed-max: SFU ONT - Configured PoE feeding exceeds ONT maximum - sfu-sup-poe-over-yell : SFU ONT - ONU is nearing its maximum ability to supply the power - sfu-opti-malfunc : SFU ONT - Malfunction of ONT's optical transceiver - sfu-sup-cfg-dnld-fail : SFU ONT - Download of voice xml file to ONT failed - sfu-sup-rssi-cfg-mism : SFU ONT - RSSI configuration mismatch - sfu-sup-sfp-tx-low : SFU ONT - SFP Tx Power below configured low-level alarm threshold - sfu-sup-sfp-temp-high : SFU ONT - SFP Temperature above configured high-level alarm threshold - sfu-sup-sfp-volt-high : SFU ONT - SFP Voltage above configured high-level alarm threshold - sfu-sup-sfp-bias-high : SFU ONT - SFP Bias above configured high-level alarm threshold - sfu-sup-ld-cfg-mism : SFU ONT - Loop detection configuration mismatch - sfu-sup-olt-rx-low : SFU ONT - OLT Rx power below receiver operating range - sfu-sup-olt-rx-high : SFU ONT - OLT Rx power above receiver operating range - sfu-sup-olt-rx-lo-warn: SFU ONT - OLT Rx power below	

101 query current alarms by filters

Resource Identifier	Type	Description
	low-level warning threshold - sfu-sup-olt-rx-hi-warn: SFU ONT - OLT Rx power above high-level warning threshold - sfu-sup-tod-out-sync : SFU ONT - ONU TOD is out-sync with OLT - sfu-sup-ont-tune-fail : SFU ONT - ONU has failed to tune to Target-ChnlPair - sfu-tr069-param-fail : SFU ONT - hgu tr069 parameters mismatch - sfu-sup-tod-mismatch : SFU ONT - ONU TOD MISMATCH - soho-sup-sw-file-error: SOHO ONT - Software file has error or is missing - soho-sup-fan-failure : SOHO ONT - Fan failure - soho-sup-temp-high-war: SOHO ONT - High temperature warning - soho-sup-temp-shutoff : SOHO ONT - Service disabled due to excessive temperature - soho-sup-emergency-cal: SOHO ONT - Emergency call active - soho-sup-swverctrl-err: SOHO ONT - Software version control error - soho-sup-poe-exceed-ma: SOHO ONT - Configured PoE feeding exceeds ONT maximum - soho-sup-poe-over-yell: SOHO ONT - ONU is nearing its maximum ability to supply the power - soho-opti-malfunc : SOHO ONT - Malfunction of ONT's optical transceiver - soho-sup-cfg-dnld-fail: SOHO ONT - Download of voice xml file to ONT failed - soho-sup-rssi-cfg-mism: SOHO ONT - RSSI configuration mismatch - soho-sup-sfp-tx-low : SOHO ONT - SFP Tx Power below configured low-level alarm threshold - soho-sup-sfp-temp-high: SOHO ONT - SFP Temperature above configured high-level alarm threshold - soho-sup-sfp-volt-high: SOHO ONT - SFP Voltage above configured high-level alarm threshold - soho-sup-sfp-bias-high: SOHO ONT - SFP Bias above configured high-level alarm threshold - soho-sup-ld-cfg-mism : SOHO ONT - Loop detection configuration mismatch - soho-sup-olt-rx-low : SOHO ONT - OLT Rx power below receiver operating range - soho-sup-olt-rx-high : SOHO ONT - OLT Rx power above receiver operating range - soho-sup-olt-rx-lo-war: SOHO ONT - OLT Rx power below low-level warning threshold - soho-sup-olt-rx-hi-war: SOHO ONT - OLT Rx power above high-level warning threshold - soho-sup-tod-out-sync : SOHO ONT - ONU TOD is out-sync with OLT - soho-sup-ont-tune-fail: SOHO ONT - ONU has failed to tune to Target-ChnlPair - soho-tr069-param-fail : SOHO ONT - hgu tr069 parameters mismatch - soho-sup-tod-mismatch : SOHO ONT - ONU TOD	

Resource Identifier	Type	Description
	MISMATCH - mdu-sup-sw-file-error : MDU ONT - Software file has error or is missing - mdu-sup-fan-failure : MDU ONT - Fan failure - mdu-sup-temp-high-warn: MDU ONT - High temperature warning - mdu-sup-temp-shutoff : MDU ONT - Service disabled due to excessive temperature - mdu-sup-emergency-call: MDU ONT - Emergency call active - mdu-sup-swverctrl-err : MDU ONT - Software version control error - mdu-sup-poe-exceed-max: MDU ONT - Configured PoE feeding exceeds ONT maximum - mdu-sup-poe-over-yell : MDU ONT - ONU is nearing its maximum ability to supply the power - mdu-opti-malfunc : MDU ONT - Malfunction of ONT's optical transceiver - mdu-sup-cfg-dnld-fail : MDU ONT - Download of voice xml file to ONT failed - mdu-sup-rssi-cfg-mism : MDU ONT - RSSI configuration mismatch - mdu-sup-sfp-tx-low : MDU ONT - SFP Tx Power below configured low-level alarm threshold - mdu-sup-sfp-temp-high : MDU ONT - SFP Temperature above configured high-level alarm threshold - mdu-sup-sfp-volt-high : MDU ONT - SFP Voltage above configured high-level alarm threshold - mdu-sup-sfp-bias-high : MDU ONT - SFP Bias above configured high-level alarm threshold - mdu-sup-ld-cfg-mism : MDU ONT - Loop detection configuration mismatch - mdu-sup-olt-rx-low : MDU ONT - OLT Rx power below receiver operating range - mdu-sup-olt-rx-high : MDU ONT - OLT Rx power above receiver operating range - mdu-sup-olt-rx-lo-warn: MDU ONT - OLT Rx power below low-level warning threshold - mdu-sup-olt-rx-hi-warn: MDU ONT - OLT Rx power above high-level warning threshold - mdu-sup-tod-out-sync : MDU ONT - ONU TOD is out-sync with OLT - mdu-sup-ont-tune-fail : MDU ONT - ONU has failed to tune to Target-ChnlPair - mdu-tr069-parm-fail : MDU ONT - hgu tr069 parameters mismatch - mdu-sup-tod-mismatch : MDU ONT - ONU TOD MISMATCH - ont-sbscr-lim-missing : provisioned ont card missing - ont-sbscr-lim-type-mis: wrong type plug-in ont card - ont-sbscr-lim-removal : improper removal ont card - ont-sbscr-lim-fail : ont card failure - ont-sbscr-lim-svc-mis : ont service mismatch for provisioned onu card - ont-sbscr-lim-port-mis: port mismatch btw actual and planned ont card - ont-svc-video-conf-mis: config request failure for video	

101 query current alarms by filters

Resource Identifier	Type	Description
	service - ont-svc-video-pw-high : high power level for rf video signal - ont-svc-video-pw-low : low power level for rf video signal - ont-svc-pots-svc-mis : ont service mismatch for provisioned pots - ont-svc-pots-rtcp-lost: pots realtime transport control protocol stream lost - ont-svc-pots-icnf-subsc: pots line iconfig subscription failure - ont-svc-pots-icnf-ntfy: pots line iconfig notify failure - ont-svc-pots-icnf-http: pots line iconfig http failure - ont-svc-pots-sip-reg : pots line sip registration failure - ont-svc-pots-sip-inv : pots line sip invite request failure - ont-svc-pots-sip-subsc: pots line sip subscribe failure - ont-svc-pots-sip-mt-tc: pots line sip message timeout threshold crossed - ont-svc-pots-pk-los-tc: pots line rtp bearer packets loss threshold crossed - ont-svc-pots-jitter-tc: pots line rtp jitter threshold crossed - ont-svc-pots-subsc-dns : pots line iconfig subscription failed (DNS) - ont-svc-pots-subsc-tcp : pots line iconfig subscription failed (TCP) - ont-svc-pots-subsc-tls : pots line iconfig subscription failed (TLS) - ont-svc-pots-subsc-auth: pots line iconfig subscription failed authentication - ont-svc-pots-subsc-to : pots line iconfig subscription failed (timeout) - ont-svc-pots-subsc-err : pots line iconfig subscription response error - ont-svc-pots-not-to : pots line iconfig notification failed (timeout) - ont-svc-pots-notref-to: pots line iconfig notification refresh failed - ont-svc-pots-not-mal : pots line iconfig notification failed (malformed) - ont-svc-pots-not-rej : pots line iconfig notification rejected - ont-svc-pots-http-dns : pots line iconfig doc retrieval failed (DNS) - ont-svc-pots-http-tcp : pots line iconfig doc retrieval failed (TCP) - ont-svc-pots-http-tls : pots line iconfig doc retrieval failed (TLS) - ont-svc-pots-http-auth: pots line iconfig doc retrieval failed (authentication) - ont-svc-pots-http-to : pots line iconfig doc retrieval failed (timeout) - ont-svc-pots-http-err : pots line iconfig doc retrieval response error - ont-svc-pots-http-mal : pots line iconfig doc retrieval failed (malformed) - ont-svc-pots-insuff : pots line iconfig service failed (insufficient data) - ont-svc-pots-poos : pots ports out of service - ont-svc-lan-mismatch : ont service mismatch for lan	

Resource Identifier	Type	Description
	- ont-svc-lan-loss-sig : loss of signal on an ethernet port interface - ont-svc-enet-poos : Ethernet Ports out of Service - ont-svc-ces-ds1-mis : ont service mismatch for provisioned ces ds1 - ont-svc-ces-ds1-los : loss of signal at ds1 interface - ont-svc-ces-ds1-lof : loss of frame at ds1 interface - ont-svc-ces-ds1-rair : receiving rai at ds1 interface - ont-svc-ces-ds1-ais : receiving ais at ds1 interface - ont-svc-ces-ds1-lnlpbk: receiving line loopback at ds1 interface - ont-svc-ces-ds1-tmlpbk: receiving terminal loopback at ds1 interface - ont-svc-ces-e1-mis : ont service mismatch for provisioned ces e1 - ont-svc-ces-e1-los : loss of signal at e1 interface - ont-svc-ces-e1-lof : loss of frame at e1 interface - ont-svc-ces-e1-rair : receiving rai at e1 interface - ont-svc-ces-e1-ais : receiving ais at e1 interface - ont-svc-voip-cnf-file : voice configuration file error - ont-svc-voip-svc-mis : service mismatch for provisioned client service - ont-svc-voip-gw-comm : voice gateway communication failure - ont-svc-voip-dhcp-fail: voice dhcp server failure - ont-svc-voip-icnf-subst: voice iconfig subscription failure - ont-svc-voip-icnf-ntfy: voice iconfig notify failure - ont-svc-voip-icnf-http: voice iconfig http failure - ont-svc-voip-dhcp-to : DHCP server retransmissions timed out - ont-svc-voip-dhcp-mal : DHCP response was malformed - ont-svc-voip-dhcp-noad: DHCP server failed to issue the required parameters - ont-svc-voip-dhcp-leas: DHCP Server failure due to problem in lease renewal - ont-svc-voip-subst-dns : iConfig Subscription failure due to DNS problem - ont-svc-voip-subst-tcp : iConfig Subscription failure due to TCP socket problem - ont-svc-voip-subst-tls : iConfig Subscription failure due to TLS session problem - ont-svc-voip-subst-auth: iConfig Subscription failure due to authentication error - ont-svc-voip-subst-to : iConfig Subscription failure due to retransmission timeout - ont-svc-voip-subst-err : iConfig Subscription failure due to response error - ont-svc-voip-not-to : iConfig Notify response timeout for new subscription - ont-svc-voip-notref-to: iConfig Notify response timeout for subscription refresh - ont-svc-voip-not-mal : iConfig Notify response is malformed - ont-svc-voip-not-rej : iConfig subscription request rejected by configuration server - ont-svc-voip-http-dns : VOIP client can't retrieve config doc due to DNS problem	

101 query current alarms by filters

Resource Identifier	Type	Description
	- ont-svc-voip-http-tcp : VOIP client can't retrieve config doc due to TCP socket problem - ont-svc-voip-http-tls : VOIP client can't retrieve config doc due to TLS session problem - ont-svc-voip-http-auth: VOIP client can't retrieve config doc due to auth error - ont-svc-voip-http-to : VOIP client can't retrieve config doc due to re-tx timeout - ont-svc-voip-http-err : VOIP client can't retrieve config doc due to response error - ont-svc-voip-http-mal : iConfig configuration document is malformed - ont-svc-voip-subs-refr: iConfig Subscription refresh error - ont-svc-voip-not-refr : iConfig Notify response for refresh subscribe failed - ont-svc-voip-icfg-err : iConfig Configuration Error - ont-svc-v-ani-conf-mis: config request failure for video ani service - ont-svc-v-ani-loss-sig: video loss of signal on ani - ont-svc-v-ani-lv-high : high video optical signal level - ont-svc-v-ani-lv-low : low video optical signal level - ont-svc-pwe-mismatch : service mismatch for provisioned pseudowire - ont-svc-pwe-reordr-lof: pseudowire reordering and loss of frame - ont-svc-pwe-jitt-buf-o: pseudowire jitter buffer overrun - ont-svc-pwe-jitt-buf-u: pseudowire jitter buffer underrun - ont-svc-pwe-malf-frms : pseudowire malformed frames - ont-svc-pwe-late-frms : pseudowire late frames - ont-svc-pwe-link-loss : pseudowire link loss - ont-svc-pwe-arp-fail : pseudowire arp failure - ont-svc-xdsl-mismatch : service mismatch for provisioned xdsl - ont-svc-xdsl-ne-lof : near end loss of frame - ont-svc-xdsl-ne-los : near end loss of signal - ont-svc-xdsl-ne-line : near end line init - ont-svc-xdsl-ne-lol : near end loss of link - ont-svc-xdsl-fe-lof : far end loss of frame - ont-svc-xdsl-fe-los : far end loss of signal - ont-svc-xdsl-fe-lop : far end loss of power - ont-svc-xdsl-cnf-err : xdsl provisioning error - ont-svc-xdsl-ne-es-tc : near end errored seconds threshold crossed - ont-svc-xdsl-ne-ses-tc: near end severe errored seconds threshold crossed - ont-svc-xdsl-ne-uas-tc: ear end unavailable seconds threshold crossed - ont-svc-xdsl-fe-es-tc : far end errored seconds threshold crossed - ont-svc-xdsl-fe-ses-tc: far end severe errored seconds threshold crossed - ont-svc-xdsl-fe-uas-tc: far end unavailable seconds threshold crossed - ont-tc-rx-los-frag-tc : rx loss of gem fragments threshold crossed - ont-tc-tx-los-frag-tc : tx loss of gem fragments threshold crossed	

Resource Identifier	Type	Description
	- ont-tc-bad-gem-hd-tc : bad gem header threshold crossed - ont-uni-ds-drpdp-fr-tc : downstream l2 dropped frames threshold crossed - ont-uni-up-drpdp-fr-tc : upstream l2 dropped frames threshold crossed - ont-uni-ds-crc-fr-tc : downstream l2 rx crc error frames threshold crossed - ont-uni-up-crc-fr-tc : upstream l2 rx crc error frames threshold crossed - ont-cpu-util-tca : ONT CPU utilization threshold crossed - ont-mem-util-tca : ONT memory utilization threshold crossed - pim-neighbor-down : pim neighbor down - pim-max-mcroutes : maximum routes reached - li-traffic-disabled : lawful interception of traffic disabled - li-bandwidth-limit : lawful intercept reached bandwidth limit - li-out-of-res : lawful intercept out of resources - otdr-cap-mismatch : otdr capability mismatch - login-successful : successful login via management access - login-failure : invalid login via management access has crossed the threshold limit - cfm-defrdiccm : rdi bit in ccm received - cfm-defmacstatus : ccm mac error status - cfm-defremoteccm : missing ccm from mep - cfm-deferrorccm : invalid ccm received - cfm-defxconccm : unexpected ccm received - cfm-defais : ethernet ais received - bfd-session-down : bfd session down - bfd-max-resource : bfd maximum resources reached - bfd-stale-entry : bfd stale entry present - tca-outputbw : tca output bandwidth - tca-inputbw : tca input bandwidth - tca-rxcrcalign : tca rxrc align errors - tca-txcrcalign : tca txrc align errors - tca-txcollisions : tca tx collision errors - tca-outputhighbw : tca output high bandwidth - tca-outputmedbw : tca output medium bandwidth - tca-outputlowbw : tca output low bandwidth - tca-inputhighbw : tca input high bandwidth - tca-inputmediumbw : tca input medium bandwidth - tca-inputlowbw : tca input low bandwidth - eth-cfm-defrdiccm : rdi bit in ccm received - eth-cfm-defmacstatus : ccm mac error status - eth-cfm-defremoteccm : missing ccm from mep - eth-cfm-deferrorccm : invalid ccm received - eth-cfm-defxconccm : unexpected ccm received - rsvp-neighbor-down : rsvp neighbor down - rsvp-instance-down : rsvp instance down - eth-ring-path-block : eth ring path block - ai-platform-down : Application Intelligence Platform down - ai-appl-install-fail : Application installation failure - ip-assign-fail : Dhcp assigned address failure - ont-tr069-serv-mis : ont tr069 server config mismatch - ont-snmp-mis : ont snmp agent config mismatch - bsf-dhcpv4 : bulksync failed for dhcpv4 - bsf-dhcpv6 : bulksync failed for dhcpv6	

101 query current alarms by filters

Resource Identifier	Type	Description
	- bsf-pon : bulksync failed for pon - bsf-vbridge : bulksync failed for vlan-bridge - bsf-qos : bulksync failed for qos - bsf-igmp : bulksync failed for igmp - bsf-lxfwd : bulksync failed for lxfwd - prot-not-available : no protection not available - prot-switchover-fail : port switch over failed - efm-oam-cpelinkfault : EFM-OAM CPE link fault - efm-oam-cpedyinggasp : EFM-OAM CPE dying gasp - efm-oam-cpecrevt : EFM-OAM CPE critical event - ont-loopdetect : ont loop detect - alrm-tbl-overflow : alarm table has overflowed - auto-switch-status : auto-switch status - auswqueuefullatm : auto-switch queue Full for ATM - auswbkpfailatm : auto-switch config data backup failed for ATM - auswrecfgfailatm : auto-switch fallback reconfiguration failed for ATM - auswdataunatm : auto-switch backup config data unavailable for ATM - auswqueuefulptm : auto-switch queue Full for PTM - auswbkpfailptm : auto-switch config data backup failed for PTM - auswrecfgfailptm : auto-switch fallback reconfiguration failed for PTM - auswdataunptm : auto-switch backup config data unavailable for PTM - auswbakpfailatm : auto-switch backup fail for ATM - chpr-com-fail : channel pair communication failure on olt - chpr-tx-fail : transmitter failure on channel pair - chpr-unprov-ont : unprovisioned ont on channel pair - chpr-prov-mismatch : mismatch btw equipment and provisioning pon attributes - chpr-loss-sig : channel pair loss of signal - chpr-diagnostic : channel pair diagnostic test active - chpr-loid-conflict : loid conflict ont on channel pair - chpr-loid-pwd-err : loid password error ont on channel pair - chpr-stk-laser-dis : stuck laser disabled on channel pair - chpr-sfp-mismatch : channel pair sfp mismatch - chpr-rng-mismatch : channel pair ranging mismatch - chpr-alien-test : channel pair alien diagnostic test active - chpr-alien-detect : channel pair alien detect active - chpr-deact-hightca : channel pair deactivated ont hightca threshold crossed - chpr-deact-lowtca : channel pair deactivated ont lowtca threshold crossed - chpr-dp-integ : channel pair data path integrity failure - olt-chpr-tc-err-frag : channelpair errored fragments threshold crossed - olt-chpr-up-bw-tca : OLT CHANNELPAIR upstream bandwidth TCA - olt-chpr-down-bw-tca : OLT CHANNELPAIR downstream bandwidth TCA - cfg-dld-fail : download of configure file to ont failed - cfg-act-fail : activate the passive config file failed - cfg-dld-ip : ont configure file download in progress - cfg-ver-mismatch : the planned configure file does not	

Resource Identifier	Type	Description
	match the active configure file - cfg-file-missing : ont configure file missing or has an error - cfg-verctrl-err : ont configure file version control error - cfg-not-supported : ont not support the configure file download function - ont-prot-not-available: ONT/ONU protection not available - ont-gen-temp-low : ONU SFP temperature is lower than configured Alarm low threshold - ont-gen-volt-low : ONU SFP Voltage is lower than configured Alarm low threshold - ont-gen-tx-pwr-high : ONU SFP Tx power is higher than configured Alarm high threshold - ont-gen-bias-low : ONU SFP bias is lower than configured Alarm low threshold - ont-gen-rx-hwarn : ONU SFP Rx power is higher than warn threshold - ont-gen-rx-lwarn : ONU SFP Rx power is lower than warn threshold - ont-gen-tx-hwarn : ONU SFP Tx power is higher than warn threshold - ont-gen-tx-lwarn : ONU SFP Tx power is lower than warn threshold - ont-gen-temp-hwarn : ONU SFP temperature is higher than warn threshold - ont-gen-temp-lwarn : ONU SFP temperature is lower than warn threshold - ont-gen-volt-hwarn : ONU SFP Voltage is higher than warn threshold - ont-gen-volt-lwarn : ONU SFP Voltage is lower than warn threshold - ont-gen-bias-hwarn : ONU SFP bias is higher than warn threshold - ont-gen-bias-lwarn : ONU SFP bias is lower than warn threshold - sfu-sup2-temp-low : SFU ONT - SFP temperature is lower than configured Alarm low threshold - sfu-sup2-volt-low : SFU ONT - SFP Voltage is lower than configured Alarm low threshold - sfu-sup2-tx-high : SFU ONT - SFP tx power is higher than configured Alarm high threshold - sfu-sup2-bias-low : SFU ONT - SFP bias is lower than configured Alarm low threshold - sfu-sup2-rx-hwarn : SFU ONT - SFP rx power is higher than configured warn threshold - sfu-sup2-rx-lwarn : SFU ONT - SFP rx power is lower than configured warn threshold - sfu-sup2-tx-hwarn : SFU ONT - SFP tx power is higher than configured warn threshold - sfu-sup2-tx-lwarn : SFU ONT - SFP tx power is lower than configured warn threshold - sfu-sup2-temp-hwarn : SFU ONT - SFP temperature is higher than configured warn threshold - sfu-sup2-temp-lwarn : SFU ONT - SFP temperature is lower than configured warn threshold - sfu-sup2-volt-hwarn : SFU ONT - SFP Voltage is higher than configured warn threshold - sfu-sup2-volt-lwarn : SFU ONT - SFP Voltage is lower	

101 query current alarms by filters

Resource Identifier	Type	Description
	than configured warn threshold - sfu-sup2-bias-hwarn : SFU ONT - SFP bias is higher than configured warn threshold - sfu-sup2-bias-lwarn : SFU ONT - SFP bias is lower than configured warn threshold - soho-sup2-temp-low : SOHO ONT - SFP temperature is lower than configured Alarm low threshold - soho-sup2-volt-low : SOHO ONT - SFP Voltage is lower than configured Alarm low threshold - soho-sup2-tx-high : SOHO ONT - SFP tx power is higher than configured Alarm low threshold - soho-sup2-bias-low : SOHO ONT - SFP bias is lower than configured Alarm low threshold - soho-sup2-rx-hwarn : SOHO ONT - SFP rx power is higher than warn threshold - soho-sup2-rx-lwarn : SOHO ONT - SFP rx power is lower than warn threshold - soho-sup2-tx-hwarn : SOHO ONT - SFP tx power is higher than warn threshold - soho-sup2-tx-lwarn : SOHO ONT - SFP tx power is lower than warn threshold - soho-sup2-temp-hwarn : SOHO ONT - SFP temperature is higher than warn threshold - soho-sup2-temp-lwarn : SOHO ONT - SFP temperature is lower than warn threshold - soho-sup2-volt-hwarn : SOHO ONT - SFP Voltage is higher than warn threshold - soho-sup2-volt-lwarn : SOHO ONT - SFP Voltage is lower than warn threshold - soho-sup2-bias-hwarn : SOHO ONT - SFP bias is higher than warn threshold - soho-sup2-bias-lwarn : SOHO ONT - SFP bias is lower than warn threshold - mdu-sup2-temp-low : MDU ONT - SFP temperature is lower than configured alarm low threshold - mdu-sup2-volt-low : MDU ONT - SFP Voltage is lower than configured alarm low threshold - mdu-sup2-tx-high : MDU ONT - SFP tx power is higher than configured alarm low threshold - mdu-sup2-bias-low : MDU ONT - SFP bias is lower than configured alarm low threshold - mdu-sup2-rx-hwarn : MDU ONT - SFP rx power is higher than warn threshold - mdu-sup2-rx-lwarn : MDU ONT - SFP rx power is lower than warn threshold - mdu-sup2-tx-hwarn : MDU ONT - SFP tx power is higher than warn threshold - mdu-sup2-tx-lwarn : MDU ONT - SFP tx power is lower than warn threshold - mdu-sup2-temp-hwarn : MDU ONT - SFP temperature is higher than warn threshold - mdu-sup2-temp-lwarn : MDU ONT - SFP temperature is lower than warn threshold - mdu-sup2-volt-hwarn : MDU ONT - SFP voltage is higher than warn threshold - mdu-sup2-volt-lwarn : MDU ONT - SFP voltage is lower than warn threshold	

Resource Identifier	Type	Description
	- mdu-sup2-bias-hwarn : MDU ONT - SFP bias is higher than warn threshold - mdu-sup2-bias-lwarn : MDU ONT - SFP bias is lower than warn threshold - cust-alm1 : customizable alarm 1 - cust-alm2 : customizable alarm 2 - cust-alm3 : customizable alarm 3 - cust-alm4 : customizable alarm 4 - cust-alm5 : customizable alarm 5 - cust-alm6 : customizable alarm 6 - cust-alm7 : customizable alarm 7 - cust-alm8 : customizable alarm 8 - cust-alm9 : customizable alarm 9 - cust-alm10 : customizable alarm 10 - cust-alm11 : customizable alarm 11 - cust-alm12 : customizable alarm 12 - cust-alm13 : customizable alarm 13 - cust-alm14 : customizable alarm 14 - cust-alm15 : customizable alarm 15 - cust-alm16 : customizable alarm 16 - cust-alm17 : customizable alarm 17 - cust-alm18 : customizable alarm 18 - cust-alm19 : customizable alarm 19 - cust-alm20 : customizable alarm 20 - cust-alm21 : customizable alarm 21 - cust-alm22 : customizable alarm 22 - cust-alm23 : customizable alarm 23 - cust-alm24 : customizable alarm 24 - cust-alm25 : customizable alarm 25 - cust-alm26 : customizable alarm 26 - cust-alm27 : customizable alarm 27 - cust-alm28 : customizable alarm 28 - cust-alm29 : customizable alarm 29 - cust-alm30 : customizable alarm 30 - cust-alm31 : customizable alarm 31 - ethernet-ring-pthfwst : ethernet ring path forward state - ethernet-ring-fop-to : ethernet ring fop-to failure of protocol timeout - ethernet-ring-fop-pm : ethernet ring fop-pm failure of protocol provision mismatch - fpm-depletion : failsafe fpm depletion - exp-seizureack : Channel was blocked due to failure in the reception of the SEIZURE ACK signal - exp-disconack : Channel was blocked due to failure in the reception of the DISCONNECTION ACK signal - exp-forcerelack : Channel was blocked due to failure in the reception of the BACKWARD DISCONNECTION ACK signal - packet-loss : Pseudo Wire entered the Packet loss state - remote-packet-loss : Remote Packet loss detected - no-dsp-resource : DSP resource allocation failed - la-down : Link aggregation group link-status is down - la-standby-na : Cross-lt lag on standby slot part is not available - la-switch-fail : Cross-lt lag fail to do switchover - la-degrade : Link aggregation group degrade - melt-board-reset : MELT board reset	

101 query current alarms by filters

Resource Identifier	Type	Description
	- board-shelf-mismatch : board type and shelf type mismatch - fcs-thresh-exceed : FCS counter threshold exceeded	
defaultaid	Parameter type: <Alarm::queryDefaultAid> Format: all Possible values: - all : default AID parameter	the default AID param is all
severity	Parameter type: <Alarm::querySeverity> Format: (indeterminate warning minor major critical all) Possible values: - indeterminate : alarm severity is indeterminate - warning : alarm severity is warning - minor : alarm severity is minor - major : alarm severity is major - critical : alarm severity is critical - all : all alarm severity	severity level of an alarm for reporting
servaff	Parameter type: <Alarm::queryServAffect> Format: (service-affecting noservice-affecting all) Possible values: - service-affecting : query alarm service affecting - noservice-affecting : query alarm not service affecting - all : query service affecting and not affecting alarms	serviceaffecting no serviceaffecting

Command Output

Table 101.140-2 "show current alarm by filters" Display parameters

Specific Information		
name	Type	Description
aidinfo	Parameter type: <Alarm::AddInfoString> - additional alarm information	alarm AID parameters <i>This element is only shown in detail mode.</i>
type	Parameter type: <Alarm::alarmIHUBType> (equipment eqpt-holder plug-in-unit atm custom e1 ima-group ima-link redundancy shdsl ether-itf traffic-overflow qos-queue temporal spatial	type of the alarms that are active <i>This element is only shown in detail mode.</i>

name	Type	Description
	(software-mngt sw-mgmt)	
	xdsl	
	xdsl-ext	
	xdsl-tca	
	olt-gen	
	eo-conv	
	authentication	
	bonding	
	sfp	
	shdsl-isam	
	custom-ext-alarm	
	plug-in-unit-ext	
	sip-user-agent	
	sip-plugin-unit	
	sip-termination	
	e1-sip-termination	
	filetransfer	
	external-device	
	l2forward	
	ether-tca	
	ether-sfp	
	megaco-media-gw	
	megaco-sig-gw	
	megaco-plug-unit	
	megaco-term	
	megaco-sig-lt	
	eqpt-supplemental	
	eqpt-holder-ext	
	lsmredundancy	
	sync	
	mcsrc	
	vlanport	
	vect-line	
	vect-board	
	otdr	
	sip-dial-plan	
	sip-vsp	
	sip-server	
	bgp	
	rip	
	lag	
	ihub-general	
	vprn	
	isis	
	ospf	
	ihub-l2forward	
	vpls	
	ihub-equip	
	ihub-link	
	eont-phyoam	
	ellid	
	epon	
	eont-services-lan	
	eolt-ont-tca	
	eont-sw-dl	
	ldp	
	mpls	

101 query current alarms by filters

name	Type	Description
	sdp epipe ihub-ipv6 pim li mgmt-sec-access bfd ai tr069serv ontsnmp bulk-sync protection-group ont sfu-sup soho-sup mdu-sup ont-ani sfu-sup2 soho-sup2 mdu-sup2 sfprssi eoltrssi cfm sfpe1t1-framer sfpe1t1-clock pppcc-engine-tca eth-cfm rsvp ihub-tca eth-ring efm-oam ont-loopdetect ont-video ont-ces ont-voip ont-video-ani ont-pwe ont-cese1 ont-xdsl ont-xdsl-tca ont-hpna ont-sip-agent-cfg ont-voip-cfg ont-mgc ont-ploam ont-gen ont-card ont-pots ont-lan ont-moca ont-tc-tca ont-moca-tca ont-l2uni-eth-tca olt-pon-tc-tca olt-pon-util-tca olt-chpr-util-tca olt-ont-tc-tca	

name	Type	Description
	ont-tca ont-pots-supplemental sfu-ploam sfu-gen soho-ploam soho-gen mdu-ploam mdu-gen ont-veip ont-iphost alarm-table auto-switch channel-pair ont-cfg-dld olt-chpair-tc-tca hgu-tr069 eqpt-psu ont-protection secondary-megaco-term secondary-sip-term cas-r2-channel lldpmed pseudo-wire link-agg fcs-exceed e1t1-interface) Possible values: - equipment : equipment alarms - eqpt-holder : equipment holder alarms - plug-in-unit : plugin unit alarms - atm : ATM alarms - custom : customizable alarms - e1 : e1 alarms - ima-group : ima-group alarms - ima-link : ima-link alarms - redundancy : redundancy alarms - shdsl : shdsl alarms - ether-itf : ethernet interface alarms - traffic-overflow : Traffic overflow alarms - qos-queue : qos queue alarms - temporal : temporal alarms - spatial : spatial alarms - software-mngt : software management alarms - sw-mgmt : software management alarms - xdsl : xDSL alarms - xdsl-ext : other xDSL alarms - xdsl-tca : xDSL threshold cross alarms - olt-gen : OLT general alarms - eo-conv : E/O conversion related alarms - authentication : authentication related alarms - bonding : bonding-group related alarms - sfp : SFP related alarms - shdsl-isam : shdsl isam alarms - custom-ext-alarm : customizable external alarms - plug-in-unit-ext : other plugin unit alarms - sip-user-agent : sip user agent related alarms - sip-plugin-unit : sip plug in unit related alarms	

101 query current alarms by filters

name	Type	Description
	- sip-termination : sip termination related alarms - e1-sip-termination : E1 sip termination related alarms - filetransfer : file transfer server alarms - external-device : external device related alarms - l2forward : l2forward related alarms - ether-tca : ethernet threshold cross alarms - ether-sfp : ethernet SFP related alarms - megaco-media-gw : megaco media gateway related alarms - megaco-sig-gw : megaco signaling gateway related alarms - megaco-plug-unit : megaco plug unit related alarms - megaco-term : megaco termination related alarms - megaco-sig-lt : megaco signaling lt related alarms - eqpt-supplemental : equipment supplemental alarms - eqpt-holder-ext : other equipment holder alarms - lsmredundancy : lsm redundancy alarms - sync : synce and bits alarms - mcsrc : multicast source alarms - vlanport : vlanport alarms - vect-line : xDSL vectoring line alarms - vect-board : xDSL vectoring board alarms - otdr : otdr alarms - sip-dial-plan : sip dial plan related alarms - sip-vsp : sip vsp related alarms - sip-server : sip server related alarms - bgp : bgp related alarms - rip : rip related alarms - lag : LAG related alarms - ihub-general : IHUB general related alarms - vprn : vprn related alarms - isis : isis related alarms - ospf : ospf related alarms - ihub-l2forward : ihub-l2forward alarms - vpls : vpls related alarms - ihub-equip : ihub-equip related alarms - ihub-link : ihub-link related alarms - eont-phyoam : eont phyoam related alarms - ellid : ellid related alarms - epon : epon related alarms - eont-services-lan : eon phyoam related alarms - eolt-ont-tca : eon phyoam related alarms - eont-sw-dl : eon phyoam related alarms - ldp : ldp related alarms - mpls : mpls related alarms - sdp : sdp related alarms - epipe : epipe related alarms - ihub-ipv6 : ihub-ipv6 related alarms - pim : pim related alarms - li : lawful intercept related alarms - mgmt-sec-access : management security related alarms - bfd : bfd related alarms - ai : Application Intelligence related alarms - tr069serv : tr069 server related alarms - ontsnmp : ont snmp related alarms - bulk-sync : bulk-sync related alarms - protection-group : port protection group related alarms - ont : ONT general supplemental related alarms - sfu-sup : SFU ONT general supplemental related alarms	

name	Type	Description
	- soho-sup : SOHO ONT general supplemental related alarms - mdu-sup : MDU ONT general supplemental related alarms - ont-ani : ONT general supplemental 2 related alarms - sfu-sup2 : SFU ONT general supplemental 2 related alarms - soho-sup2 : SOHO ONT general supplemental 2 related alarms - mdu-sup2 : MDU ONT general supplemental 2 related alarms - sfprssi : SFP RSSI related alarms - eoltrssi : epon olt Sfp RSSI related alarms - cfm : Cfm related alarms - sfpe1t1-framer : SFP 2e1t1 framer alarms - sfpe1t1-clock : SFP 2e1t1 clock alarms - pppcc-engine-tca : PPPOE Cross Connect Engine TCA related alarm - eth-cfm : eth-cfm related alarms - rsvp : rsvp related alarms - ihub-tca : IHUB TCA related alarms - eth-ring : eth-ring related alarms - efm-oam : EFM-OAM related alarms - ont-loopdetect : ont loop detect related alarms - ont-video : ont services video related alarms - ont-ces : ont services ces related alarms - ont-voip : ont services voip related alarms - ont-video-ani : ont services video ani related alarms - ont-pwe : ont services pwe related alarms - ont-cese1 : ont services cese1 related alarms - ont-xdsl : ont services xdsl related alarms - ont-xdsl-tca : ont services xdsl tca related alarms - ont-hpna : ont hpna related alarms - ont-sip-agent-cfg : ont services voip sip agent config related alarms - ont-voip-cfg : ont services voip config related alarms - ont-mgc : ont mgc related alarms - ont-ploam : ONT PLOAM related alarms - ont-gen : ONT GENERAL related alarms - ont-card : ONT Subscriber Card related alarms - ont-pots : ONT Services POTS related alarms - ont-lan : ONT Services LAN related alarms - ont-moca : ONT MoCA related alarms - ont-tc-tca : ONT TC TCA related alarms - ont-moca-tca : ONT MoCA TCA related alarms - ont-l2uni-eth-tca : ONT L2 UNI Ethernet TCA related alarms - olt-pon-tc-tca : OLT PON TC TCA related alarms - olt-pon-util-tca : OLT PON utilization TCA related alarms - olt-chpr-util-tca : OLT channel-pair utilization TCA related alarms - olt-ont-tc-tca : OLT ONT TC TCA related alarms - ont-tca : ONT TCA related alarms - ont-pots-supplemental : ONT POTS Supplemental related alarms - sfu-ploam : SFU ONT PLOAM related alarms - sfu-gen : SFU ONT general related alarms - soho-ploam : SOHO ONT PLOAM related alarms - soho-gen : SOHO ONT general related alarms	

101 query current alarms by filters

name	Type	Description
	- mdu-ploam : MDU ONT PLOAM related alarms - mdu-gen : MDU ONT general related alarms - ont-veip : ONT VEIP related alarms - ont-iphost : ONT IP HOST related alarms - alarm-table : alarm table related alarms - auto-switch : auto-switch related alarms - channel-pair : channel pair related alarms - ont-cfg-dld : ont configure file download related alarms - olt-chpair-tc-tca : OLT CHANNELPAIR TC TCA related alarms - hgu-tr069 : hgu tr069 related alarms - eqpt-psu : equipment psu alarms - ont-protection : ONT protection related alarms - secondary-megaco-term : secondary megaco termination related alarms - secondary-sip-term : secondary sip termination related alarms - cas-r2-channel : CAS R2 channel related alarms - lldpmed : lldpmed alarms - pseudo-wire : pseudo Wire related alarms - link-agg : Link aggregation related alarms - fcs-exceed : FCS auto-recovery related alarms - e1t1-interface : E1/T1 physical interfaces related alarms	
name	Parameter type: <Alarm::alarmIndexExt> (all xtca-ne-es xtca-ne-ses xtca-ne-uas xtca-ne-day-es xtca-ne-day-ses xtca-ne-day-uas xtca-fe-es xtca-fe-ses xtca-fe-uas xtca-fe-day-es xtca-fe-day-ses xtca-fe-day-uas xtca-leftrs xtca-day-leftrs xtca-fe-leftrs xtca-fe-day-leftrs xtca-auto-port-reset xtca-reinit xtca-day-reinit xdsl-ne-los xdsl-ne-lof xdsl-ne-lom xdsl-ne-ese xdsl-act-cfg-error xdsl-act-not-feas xdsl-up-br-reach xdsl-ne-ncd xdsl-ne-lcd xdsl-fe-los xdsl-fe-lof xdsl-fe-lpr xdsl-fe-lol	alarm name that are active <i>This element is only shown in detail mode.</i>

name	Type	Description
	xdsl-fe-lom xdsl-fe-ese xdsl-fe-upbo-vio xdsl-fe-cpe-pol xdsl-tpstc-mis xdsl-act-comm xdsl-act-modem xdsl-do-br-reach xdsl-fe-ncd xdsl-fe-lcd xdsl-frtx-init-fail xdsl-vect-dle xdsl-fe-mis-peer-35b vectline-xtc-var-vict vectline-xtc-var-dist vectline-corp-errf vect-cpe-cap-mismatch vectline-conf_notfeas vect-vp-lt-mismatch vect-inv-qsf vect-vp-lt-fail vect-no-gain-at-init sw-rollback db-rollback xvps-inv-dbase inv-cde-file miss-cde-file cde-hash-error auto-fetch-failure low-disk-space cell-discard-up cell-discard-down persist-data-loss mac-conflict vmac-full sntp-comm-lost preferred-mode timing-reference nt-disk-95%full shub-loc cf-error back-pnl-inv ihub-conf-loss rack-power rack-fan-unit1 rack-fan-unit2 shelf-mismatch shelf-missing shelf-install-missing door ac-power-fail board-mismatch waiting-for-sw temp-exceeded backplane-data-failure temp-shutdown board-missing	

101 query current alarms by filters

name	Type	Description
	board-instl-missing	
	board-init	
	board-reset-prot	
	sem-power-fail	
	sem-ups-fail	
	board-reset-cf	
	vlan-assign-fail	
	vsa-info-invalid	
	auth-mac-conflict	
	user-pwd-fault	
	up-plan-bitrate	
	up-min-bitrate	
	up-config-not-feas	
	down-plan-bitrate	
	down-min-bitrate	
	down-config-not-feas	
	non-bonding-cpe	
	multiple-cpes	
	register	
	group-incomplete	
	host-sfp-los	
	host-sfp-tx-fail	
	host-sfp-not-prst	
	host-sfp-inv-id	
	host-sfp-ctrl-fail	
	host-sfp-rmtlt	
	host-sfp-mismatch	
	host-sfp-incompt	
	exp-sfp-los	
	exp-sfp-tx-fail	
	exp-sfp-not-prst	
	exp-sfp-inv-id	
	exp-sfp-ctrl-fail	
	exp-sfp-1-los	
	exp-sfp-2-los	
	ext-qsfp-invld	
	tx-power-high-alarm	
	tx-power-low-alarm	
	rx-power-high-alarm	
	rx-power-low-alarm	
	tx-biascur-high-alarm	
	tx-biascur-low-alarm	
	volt-high-alarm	
	volt-low-alarm	
	temp-high-alarm	
	temp-low-alarm	
	tx-power-high-warn	
	tx-power-low-warn	
	rx-power-high-warn	
	rx-power-low-warn	
	tx-biascur-high-warn	
	tx-biascur-low-warn	
	volt-high-warn	
	volt-low-warn	
	temp-high-warn	
	temp-low-warn	
	onu-unprovisioned	

name	Type	Description
	signal-loss bitrate-high opmodule-mismatch key-fail-one-churn key-fail-three-churn oam-discov-fail report-timeout total-packets-exceed arp-packets-exceed dhcp-packets-exceed igmp-packets-exceed pppoe-packets-exceed nd-packets-exceed icmpv6-packets-exceed mld-packets-exceed dhcpv6-packets-exceed cfm-packets-exceed dsx1-serdes-fail dsx1-tributary1-fail dsx1-tributary2-fail dsx1-los-fail dsx1-ais-sync dsx1-lof-sync dsx1-los-sync dsx1-deg-fail dsx1-rei-from-liu dsx1-rdi-from-liu dsx1-crc6-from-liu dsx1-crc4-from-liu dsx1-crc4-th-from-liu dsx1-ais-from-liu dsx1-los-from-liu dsx1-lof-from-liu dsx1-lomf-from-liu dsx1-rei-from-iwf dsx1-rdi-from-iwf dsx1-crc6-from-iwf dsx1-crc4-from-iwf dsx1-crc4-th-from-iwf dsx1-ais-from-iwf dsx1-los-from-iwf dsx1-lof-from-iwf dsx1-lomf-from-iwf pppce-trans-15min-tca pppce-sess-15min-tca pppce-trans-1day-tca pppce-sess-1day-tca custom1 custom2 custom3 custom4 custom5 he-custom1 he-custom2 he-custom3 he-custom4 he-custom5	

101 query current alarms by filters

name	Type	Description
	he-custom6	
	custom6	
	custom7	
	custom8	
	custom9	
	custom10	
	custom11	
	custom12	
	custom13	
	custom14	
	custom15	
	custom16	
	custom17	
	loss-swo-cap	
	ping-check-fail	
	der-temp1	
	der-temp2	
	der-temp3	
	der-temp4	
	der-temp5	
	der-temp6	
	der-temp7	
	der-temp8	
	der-temp9	
	der-temp10	
	der-temp11	
	der-temp12	
	der-temp13	
	der-temp14	
	der-temp15	
	der-temp16	
	der-temp17	
	der-temp18	
	der-temp19	
	der-temp20	
	der-temp21	
	der-temp22	
	der-temp23	
	der-temp24	
	der-temp25	
	der-temp26	
	der-temp27	
	der-temp28	
	der-temp29	
	der-temp30	
	der-temp31	
	der-spa1	
	der-spa2	
	der-spa3	
	der-spa4	
	der-spa5	
	der-spa6	
	der-spa7	
	der-spa8	
	der-spa9	
	der-spa10	
	der-spa11	

name	Type	Description
	der-spa12	
	der-spa13	
	der-spa14	
	der-spa15	
	der-spa16	
	der-spa17	
	der-spa18	
	der-spa19	
	der-spa20	
	der-spa21	
	der-spa22	
	der-spa23	
	der-spa24	
	der-spa25	
	der-spa26	
	der-spa27	
	der-spa28	
	der-spa29	
	der-spa30	
	der-spa31	
	apsf-alarm	
	custextalarm1	
	custextalarm2	
	custextalarm3	
	custextalarm4	
	custextalarm5	
	pluginfan	
	plugin-dc-a	
	plugin-dc-b	
	plugin-dg	
	ntr-a-loss	
	ntr-b-loss	
	xvps-conf-loss	
	mac-entry-nofree	
	fibre-conn-mismatch	
	link-cap-mismatch	
	eqpt-cap-mismatch	
	ctrl-dnld-failure	
	melt-hw-issue	
	melt-board-reset	
	board-shelf-mismatch	
	mgnt-type-mismatch	
	fileserv-unavail	
	shdsl-n-loopback	
	shdsl-c-loopback	
	shdsl-conferr	
	shdsl-atm-lcd	
	shdsl-lpr	
	shdsl-secu-err	
	shdsl-dev-fault	
	shdsl-atm-ncd	
	shdsl-n-losw	
	shdsl-c-losw	
	shdsl-n-aten	
	shdsl-c-aten	
	shdsl-n-snr	
	shdsl-c-snr	

101 query current alarms by filters

name	Type	Description
	shdsl-n-dccont	
	shdsl-c-dccont	
	shdsl-c-actfail	
	e1-fe-rai	
	e1-ne-rai	
	e1-fe-ais	
	e1-ne-ais	
	e1-lof	
	e1-los	
	e1-loopback	
	ima-grp-fe-su	
	ima-grp-fe-cfg	
	ima-grp-ne-cfg	
	ima-grp-fe-nl	
	ima-grp-ne-nl	
	ima-grp-fe-blk	
	ima-lnk-lif	
	ima-lnk-lods	
	ima-lnk-misc	
	ima-lnk-rfi	
	ima-lnk-fault	
	ima-lnk-txblk	
	ima-lnk-rxblk	
	bad-digitmap	
	dhcp-unreach	
	dhcp-no-srv	
	dhcp-inv-srv	
	norpniewithsoftdsp	
	unknown-sub	
	ground-key	
	port-hightemp	
	port-jbfltca	
	reg-domainname	
	reg-auth	
	reg-timeout	
	reg-srvfailresp	
	inv-domainname	
	inv-auth	
	inv-timeout	
	inv-srvfailresp	
	subs-srvfailresp	
	subs-domainname	
	subs-auth	
	subs-refreshfail	
	subs-inittimeout	
	emergency-call	
	e1sip-reg-domainname	
	e1sip-reg-auth	
	e1sip-reg-timeout	
	e1sip-reg-srvfailresp	
	e1sip-inv-domainname	
	e1sip-inv-auth	
	e1sip-inv-timeout	
	e1sip-inv-srvfailresp	
	e1sip-emergency-call	
	e1itf-ais-signal	
	e1itf-los-signal	

name	Type	Description
	e1itf-rai-signal e1sip-misconfig-mgc10 e1sip-nsmprf-missed e1t1itf-recv-ais e1t1itf-recv-los e1t1itf-recv-rai transport-mismatch dns-lookup-failure none-dns-srv no-dns-srv none-srv no-srv reg-srv-unreach proxy-srv-unreach dhcp-srv-unreach fo-trigger fb-trigger du-trigger ssp-missing dns-pool-exceed lsa-fo-trigger reg-domainname-sec reg-auth-sec reg-timeout-sec reg-srvfailresp-sec inv-domainname-sec inv-auth-sec inv-timeout-sec inv-srvfailresp-sec subs-srvfailresp-sec subs-domainname-sec subs-auth-sec subs-refreshfail-sec subs-inittimeout-sec emergency-call-sec fanout up-overflow upobc-overflow dwobc-overflow dw-overflow lwpri-overflow queue-drop queue-load queue-peak-usage mgc-unreachable failover-to-esamgc sgc-unreachable lcard-unreach-srvcard lcard-type-mismatch meg-unknown-sub meg-ground-key meg-high-temp meg-act-fail meg-over-current line-showering low-qos-packetloss low-qos-jitter	

101 query current alarms by filters

name	Type	Description
	low-qos-delay sig-brd-persist-loss sig-brd-disk-full sig-brd-db-rollback mg-overload meg-unknown-sub-sec line-showering-sec loss-env-mon etca-los etca-fcs etca-day-los etca-day-fcs etca-rx-octets etca-tx-octets etca-day-rx-octets etca-day-tx-octets user-sfp-los user-sfp-tx-fail user-sfp-not-prst user-sfp-inv-id user-sfp-t-exceed user-sfp-mismatch uplink-sfp-los uplink-sfp-tx-fail uplink-sfp-not-prst uplink-sfp-inv-id uplink-sfp-t-exceed uplink-sfp-mismatch loss-lsmswp-cap inv-xvps-pair-data network-power-loss hw-fault bat-miss bat-fail bat-low bat-a-fail bat-b-fail ac-vol-out-range network-power-loss-b sem-ac-power-fail sem-ups-low-volt dc-a-fail dc-b-fail plan-power-mismatch water-seepage-in-box sealed-box-open dc-a-vol-out-range dc-b-vol-out-range inlet-temp-major inlet-temp-critical psu-fail-crit psu-a-fail-presence psu-a-fail-vin-ac-nok psu-a-fail-vin-uv psu-a-fail-vin-ov psu-a-fail-vout-uv psu-a-fail-vout-ov	

name	Type	Description
	psu-a-fail-iout-oc psu-a-fail-overtemp psu-b-fail-presence psu-b-fail-vin-ac-nok psu-b-fail-vin-uv psu-b-fail-vin-ov psu-b-fail-vout-uv psu-b-fail-vout-ov psu-b-fail-iout-oc psu-b-fail-overtemp synce-fail bits-fail bits-output-shutoff ieee1588-fail gnss-fail ieee1588-hybrid-fail signal-loss signal-efd esmc-loss bits-output-exceed ql-input-exceed holdover lti tod-reference-fail internal-clk-fail bgp-peer-down bgp-routes-mid-limit isis-adjacency-down isis-adjacency-reject isis-instance-down ospf-lsa-limit ospf-lsa-mid-limit ospf-neighbor-down ospf-instance-down ospf3-lsa-limit ospf3-lsa-mid-limit ospf3-neighbor-down ospf3-instance-down rip-instance-down lag-down lagsubgrp-thresh-reach lagsubgrp-switch-fail no-unpinned-free-ports general-arp-limit gen-switch-out-of-res ipv6-nc-limit dhcp-session-oor ihub-fdb-limit ihub-mac-limit l2fw-stp-exception l2fw-stp-root-guard vprn-routes-limit vprn-ipv6-routes-limit dhcpv6-lease-limit dhcpv4-lease-limit vpls-mfib-limit ihub-ipv6-dad-own	

101 query current alarms by filters

name	Type	Description
	ihub-ipv6-dad	
	ihub-ipv6-dup-pd-route	
	vpls-duplicate-mac	
	vpls-fdb-limit	
	vpls-self-duplic-mac	
	vpls-sdp-self-dup-mac	
	link-down	
	link-lagport-add-fail	
	link-conf-mismatch	
	ihub-peer-comm	
	ihub-sw-fail	
	ihub-hw-fail	
	ihub-link-fail	
	ihub-proc-overload	
	ihub-out-of-mem	
	ntp-comm-lost	
	ldp-instance-down	
	ldp-session-down	
	mpls-instance-down	
	mpls-lsp-down	
	mpls-lsp-path-down	
	sdp-instance-down	
	sdp-binding-down	
	epipe-instance-down	
	lldpmed-portcfg-mis	
	lldpmed-mediapl-mis	
	vlanport-svc-mismatch	
	mcsrc-stream-lost	
	eqptsupl-syslog-upload	
	eqptsupl-ontsw-dnload	
	cf-75%used	
	cf-90%used	
	olt-gen-pon-com-fail	
	olt-gen-tx-fail	
	olt-gen-unprov-ont	
	olt-gen-pon-eqpt-prov	
	olt-gen-pon-loss-sig	
	olt-gen-pon-diagnostic	
	olt-gen-loid-conflict	
	olt-gen-loid-pwderr	
	olt-gen-pon-alien-test	
	olt-gen-alien-detect	
	olt-gen-rng-mism	
	olt-gen-sfp-mism	
	olt-gen-deact-hightca	
	olt-gen-deact-lowtca	
	olt-gen-dp-integ	
	olt-gen-ddr-fault	
	olt-pon-tc-err-frag-tc	
	olt-ont-tc-err-frag-tc	
	ont-ploam-loss-sig	
	ont-ploam-loss-ack	
	ont-ploam-loss-cd	
	ont-ploam-phy-eqpt-err	
	ont-ploam-startup-fail	
	ont-ploam-sig-degrade	
	ont-ploam-disabled	

name	Type	Description
	ont-ploam-err-msg ont-ploam-inactive ont-ploam-sig-fail ont-ploam-dying-gasp ont-ploam-deact-fail ont-ploam-oam ont-ploam-win-drift ont-ploam-rdi ont-ploam-loss-ks ont-ploam-pwr-burst ont-ploam-rog-disa ont-ploam-diff-reach ont-ploam-looc sfu-ploam-loss-sig sfu-ploam-loss-ack sfu-ploam-loss-cd sfu-ploam-phy-eqpt-err sfu-ploam-startup-fail sfu-ploam-sig-degrade sfu-ploam-disabled sfu-ploam-err-msg sfu-ploam-inactive sfu-ploam-sig-fail sfu-ploam-dying-gasp sfu-ploam-deact-fail sfu-ploam-oam sfu-ploam-win-drift sfu-ploam-rdi sfu-ploam-loss-ks sfu-ploam-pwr-burst sfu-ploam-rog-disa sfu-ploam-diff-reach sfu-ploam-looc soho-ploam-loss-sig soho-ploam-loss-ack soho-ploam-loss-cd soho-ploam-phy-eqpt-er soho-ploam-startup-fai soho-ploam-sig-degrade soho-ploam-disabled soho-ploam-err-msg soho-ploam-inactive soho-ploam-sig-fail soho-ploam-dying-gasp soho-ploam-deact-fail soho-ploam-oam soho-ploam-win-drift soho-ploam-rdi soho-ploam-loss-ks soho-ploam-pwr-burst soho-ploam-rog-disa soho-ploam-diff-reach soho-ploam-looc mdu-ploam-loss-sig mdu-ploam-loss-ack mdu-ploam-loss-cd mdu-ploam-phy-eqpt-err	

101 query current alarms by filters

name	Type	Description
	mdu-ploam-startup-fail mdu-ploam-sig-degrade mdu-ploam-disabled mdu-ploam-err-msg mdu-ploam-inactive mdu-ploam-sig-fail mdu-ploam-dying-gasp mdu-ploam-deact-fail mdu-ploam-oam mdu-ploam-win-drift mdu-ploam-rdi mdu-ploam-loss-ks mdu-ploam-pwr-burst mdu-ploam-roq-disa mdu-ploam-diff-reach mdu-ploam-looc ont-hpna-ser-mis ont-hpna-los-sig ont-moca-svc-mis ont-moca-link-los ont-moca-min-bw ont-moca-tca-rx-err-fr ont-sipa-reg-nm-fail ont-sipa-reg-rec-fail ont-sipa-reg-con-fail ont-sipa-reg-val-fail ont-sipa-reg-mis ont-vcd-cfg-nm-fail ont-vcd-cfg-rech-fail ont-vcd-cfg-conn-fail ont-vcd-cfg-vali-fail ont-vcd-cfg-auth-fail ont-vcd-cfg-resp-tmout ont-vcd-cfg-resp-err ont-vcd-cfg-file-err ont-vcd-sub-nm-fail ont-vcd-sub-rech-fail ont-vcd-sub-conn-fail ont-vcd-sub-vali-fail ont-vcd-sub-auth-fail ont-vcd-sub-resp-tmout ont-vcd-sub-resp-err ont-vcd-reb-requ ont-vcd-mis ont-mgc-mis ont-mgc-timeout ont-sip-reg-dns ont-sip-reg-fail ont-sip-reg-timeout ont-sip-reg-err-resps ont-sip-inv-dns ont-sip-inv-auth ont-sip-inv-timeout ont-sip-inv-err ont-svc-pots-subs-refr ont-svc-pots-not-refr ont-svc-pots-icfg-err	

name	Type	Description
	ont-veip-mismatch	
	ont-ip-host-mismatch	
	ont-ip-host-file	
	ont-ip-host-ip-alloc	
	olt-pon-up-bw-tca	
	olt-pon-down-bw-tca	
	ont-gen-omci-fail	
	ont-gen-eqpt-selftest	
	ont-gen-ac-pwr-fail	
	ont-gen-bat-missing	
	ont-gen-bat-low	
	ont-gen-bat-fail	
	ont-gen-phys-intrusion	
	ont-gen-sw-dnload-f	
	ont-gen-sw-dnload-p	
	ont-gen-sw-act-fail	
	ont-gen-eqpt-vers-mis	
	ont-gen-sw-vers-mis	
	ont-gen-us-rate-mis	
	ont-gen-mdu-env1	
	ont-gen-mdu-env2	
	ont-gen-mdu-env3	
	ont-gen-nw-time-err	
	ont-gen-opt-sig-high	
	ont-gen-opt-sig-low	
	ont-gen-eqpt-prov-sa	
	ont-gen-eqpt-prov-nsa	
	pon-t-txmcutilhi	
	pon-t-txmcutilm	
	pon-t-txmcutillo	
	pon-t-txtotutilhi	
	pon-t-txtotutilmd	
	pon-t-txtotutillo	
	pon-t-rxtotutilhi	
	pon-t-rxtotutilmd	
	pon-t-rxtotutillo	
	pon-t-dbacongperiodhi	
	pon-t-dbacongperiodmd	
	pon-t-dbacongperiodlo	
	pon-t-txucdropfrmhi	
	pon-t-txucdropfrmmd	
	pon-t-txucdropfrmlo	
	pon-t-txmcdropfrmhi	
	pon-t-txmcdropfrmmd	
	pon-t-txmcdropfrmlo	
	pon-t-txbcdropfrmhi	
	pon-t-txbcdropfrmmd	
	pon-t-txbcdropfrmlo	
	pon-t-rxtotdropfrmhi	
	pon-t-rxtotdropfrmmd	
	pon-t-rxtotdropfrmlo	
	chpr-t-txmcutilhi	
	chpr-t-txmcutilm	
	chpr-t-txmcutillo	
	chpr-t-txtotutilhi	
	chpr-t-txtotutilmd	
	chpr-t-txtotutillo	

101 query current alarms by filters

name	Type	Description
	chpr-t-rxtotutilhi	
	chpr-t-rxtotutilmd	
	chpr-t-rxtotutillo	
	chpr-t-dbacongperiodhi	
	chpr-t-dbacongperiodmd	
	chpr-t-dbacongperiodlo	
	chpr-t-txucdropfrmhi	
	chpr-t-txucdropfrmmd	
	chpr-t-txucdropfrmlo	
	chpr-t-txmcdropfrmhi	
	chpr-t-txmcdropfrmmd	
	chpr-t-txmcdropfrmlo	
	chpr-t-txbcdropfrmhi	
	chpr-t-txbcdropfrmmd	
	chpr-t-txbcdropfrmlo	
	chpr-t-rxtotdropfrmhi	
	chpr-t-rxtotdropfrmmd	
	chpr-t-rxtotdropfrmlo	
	sfu-gen-omci-fail	
	sfu-gen-eqpt-selftest	
	sfu-gen-ac-pwr-fail	
	sfu-gen-bat-missing	
	sfu-gen-bat-low	
	sfu-gen-bat-fail	
	sfu-gen-sw-dnload-f	
	sfu-gen-sw-dnload-p	
	sfu-gen-sw-act-fail	
	sfu-gen-eqpt-vers-mis	
	sfu-gen-sw-vers-mis	
	sfu-gen-us-rate-mis	
	sfu-gen-tune-fail	
	sfu-gen-nw-time-err	
	sfu-gen-opt-sig-high	
	sfu-gen-opt-sig-low	
	sfu-gen-eqpt-prov-sa	
	sfu-gen-eqpt-prov-nsa	
	soho-gen-omci-fail	
	soho-gen-eqpt-selftest	
	soho-gen-ac-pwr-fail	
	soho-gen-bat-missing	
	soho-gen-bat-low	
	soho-gen-bat-fail	
	soho-gen-sw-dnload-f	
	soho-gen-sw-dnload-p	
	soho-gen-sw-act-fail	
	soho-gen-eqpt-vers-mis	
	soho-gen-sw-vers-mis	
	soho-gen-us-rate-mis	
	soho-gen-tune-fail	
	soho-gen-nw-time-err	
	soho-gen-opt-sig-high	
	soho-gen-opt-sig-low	
	soho-gen-eqpt-prov-sa	
	soho-gen-eqpt-prov-nsa	
	mdu-gen-omci-fail	
	mdu-gen-eqpt-selftest	
	mdu-gen-ac-pwr-fail	

name	Type	Description
	mdu-gen-bat-missing mdu-gen-bat-low mdu-gen-bat-fail mdu-gen-phys-intrusion mdu-gen-sw-dnload-f mdu-gen-sw-dnload-p mdu-gen-sw-act-fail mdu-gen-eqpt-vers-mis mdu-gen-sw-vers-mis mdu-gen-us-rate-mis mdu-gen-tune-fail mdu-gen-mdu-env1 mdu-gen-mdu-env2 mdu-gen-mdu-env3 mdu-gen-nw-time-err mdu-gen-opt-sig-high mdu-gen-opt-sig-low mdu-gen-eqpt-prov-sa mdu-gen-eqpt-prov-nsa ont-gen-sw-dnload-file ont-gen-fan-fail ont-gen-high-temp ont-gen-high-temp-ex ont-gen-emergency-call ont-gen-sw-version ont-poe-exceed-max ont-poe-overload-yell ont-opti-malfunc ont-gen-cfgdld-fail ont-gen-rssi-mis ont-gen-tx-pwr-low ont-gen-temp-high ont-gen-volt-high ont-gen-bias-high ont-loopdetect-mis ont-olt-rx-pw-lo ont-olt-rx-pw-hig ont-olt-rx-pw-warnlo ont-olt-rx-pw-warnhig ont-gen-tod-out-sync ont-gen-tune-fail hgu-tr069-parm-fail ont-gen-tod-mismatch sfu-sup-sw-file-error sfu-sup-fan-failure sfu-sup-temp-high-warn sfu-sup-temp-shutoff sfu-sup-emergency-call sfu-sup-swverctrl-err sfu-sup-poe-exceed-max sfu-sup-poe-over-yell sfu-opti-malfunc sfu-sup-cfg-dnld-fail sfu-sup-rssi-cfg-mism sfu-sup-sfp-tx-low sfu-sup-sfp-temp-high sfu-sup-sfp-volt-high	

101 query current alarms by filters

name	Type	Description
	sfu-sup-sfp-bias-high	
	sfu-sup-ld-cfg-mism	
	sfu-sup-olt-rx-low	
	sfu-sup-olt-rx-high	
	sfu-sup-olt-rx-lo-warn	
	sfu-sup-olt-rx-hi-warn	
	sfu-sup-tod-out-sync	
	sfu-sup-ont-tune-fail	
	sfu-tr069-parm-fail	
	sfu-sup-tod-mismatch	
	soho-sup-sw-file-error	
	soho-sup-fan-failure	
	soho-sup-temp-high-war	
	soho-sup-temp-shutoff	
	soho-sup-emergency-cal	
	soho-sup-swverctrl-err	
	soho-sup-poe-exceed-ma	
	soho-sup-poe-over-yell	
	soho-opti-malfunc	
	soho-sup-cfg-dnld-fail	
	soho-sup-rssi-cfg-mism	
	soho-sup-sfp-tx-low	
	soho-sup-sfp-temp-high	
	soho-sup-sfp-volt-high	
	soho-sup-sfp-bias-high	
	soho-sup-ld-cfg-mism	
	soho-sup-olt-rx-low	
	soho-sup-olt-rx-high	
	soho-sup-olt-rx-lo-war	
	soho-sup-olt-rx-hi-war	
	soho-sup-tod-out-sync	
	soho-sup-ont-tune-fail	
	soho-tr069-parm-fail	
	soho-sup-tod-mismatch	
	mdu-sup-sw-file-error	
	mdu-sup-fan-failure	
	mdu-sup-temp-high-warn	
	mdu-sup-temp-shutoff	
	mdu-sup-emergency-call	
	mdu-sup-swverctrl-err	
	mdu-sup-poe-exceed-max	
	mdu-sup-poe-over-yell	
	mdu-opti-malfunc	
	mdu-sup-cfg-dnld-fail	
	mdu-sup-rssi-cfg-mism	
	mdu-sup-sfp-tx-low	
	mdu-sup-sfp-temp-high	
	mdu-sup-sfp-volt-high	
	mdu-sup-sfp-bias-high	
	mdu-sup-ld-cfg-mism	
	mdu-sup-olt-rx-low	
	mdu-sup-olt-rx-high	
	mdu-sup-olt-rx-lo-warn	
	mdu-sup-olt-rx-hi-warn	
	mdu-sup-tod-out-sync	
	mdu-sup-ont-tune-fail	
	mdu-tr069-parm-fail	

name	Type	Description
	mdu-sup-tod-mismatch ont-sbscr-lim-missing ont-sbscr-lim-type-mis ont-sbscr-lim-removal ont-sbscr-lim-fail ont-sbscr-lim-svc-mis ont-sbscr-lim-port-mis ont-svc-video-conf-mis ont-svc-video-pw-high ont-svc-video-pw-low ont-svc-pots-svc-mis ont-svc-pots-rtcp-lost ont-svc-pots-icnf-subs ont-svc-pots-icnf-ntfy ont-svc-pots-icnf-http ont-svc-pots-sip-reg ont-svc-pots-sip-inv ont-svc-pots-sip-subsc ont-svc-pots-sip-mt-tc ont-svc-pots-pk-los-tc ont-svc-pots-jitter-tc ont-svc-pots-subs-dns ont-svc-pots-subs-tcp ont-svc-pots-subs-tls ont-svc-pots-subs-auth ont-svc-pots-subs-to ont-svc-pots-subs-err ont-svc-pots-not-to ont-svc-pots-notref-to ont-svc-pots-not-mal ont-svc-pots-not-rej ont-svc-pots-http-dns ont-svc-pots-http-tcp ont-svc-pots-http-tls ont-svc-pots-http-auth ont-svc-pots-http-to ont-svc-pots-http-err ont-svc-pots-http-mal ont-svc-pots-insuff ont-svc-pots-poos ont-svc-lan-mismatch ont-svc-lan-loss-sig ont-svc-enet-poos ont-svc-ces-ds1-mis ont-svc-ces-ds1-los ont-svc-ces-ds1-lof ont-svc-ces-ds1-rair ont-svc-ces-ds1-ais ont-svc-ces-ds1-lnlpbk ont-svc-ces-ds1-tmlpbk ont-svc-ces-e1-mis ont-svc-ces-e1-los ont-svc-ces-e1-lof ont-svc-ces-e1-rair ont-svc-ces-e1-ais ont-svc-voip-cnf-file ont-svc-voip-svc-mis	

101 query current alarms by filters

name	Type	Description
	ont-svc-voip-gw-comm ont-svc-voip-dhcp-fail ont-svc-voip-icnf-sub ont-svc-voip-icnf-ntfy ont-svc-voip-icnf-http ont-svc-voip-dhcp-to ont-svc-voip-dhcp-mal ont-svc-voip-dhcp-noad ont-svc-voip-dhcp-leas ont-svc-voip-sub-dns ont-svc-voip-sub-tcp ont-svc-voip-sub-tls ont-svc-voip-sub-auth ont-svc-voip-sub-to ont-svc-voip-sub-err ont-svc-voip-not-to ont-svc-voip-notref-to ont-svc-voip-not-mal ont-svc-voip-not-rej ont-svc-voip-http-dns ont-svc-voip-http-tcp ont-svc-voip-http-tls ont-svc-voip-http-auth ont-svc-voip-http-to ont-svc-voip-http-err ont-svc-voip-http-mal ont-svc-voip-sub-refr ont-svc-voip-not-refr ont-svc-voip-icfg-err ont-svc-v-ani-conf-mis ont-svc-v-ani-loss-sig ont-svc-v-ani-lv-high ont-svc-v-ani-lv-low ont-svc-pwe-mismatch ont-svc-pwe-reordr-lof ont-svc-pwe-jitt-buf-o ont-svc-pwe-jitt-buf-u ont-svc-pwe-malf-frms ont-svc-pwe-late-frms ont-svc-pwe-link-loss ont-svc-pwe-arp-fail ont-svc-xdsl-mismatch ont-svc-xdsl-ne-lof ont-svc-xdsl-ne-los ont-svc-xdsl-ne-line ont-svc-xdsl-ne-lol ont-svc-xdsl-fe-lof ont-svc-xdsl-fe-los ont-svc-xdsl-fe-lop ont-svc-xdsl-cnfr-err ont-svc-xdsl-ne-es-tc ont-svc-xdsl-ne-ses-tc ont-svc-xdsl-ne-uas-tc ont-svc-xdsl-fe-es-tc ont-svc-xdsl-fe-ses-tc ont-svc-xdsl-fe-uas-tc ont-tc-rx-los-frag-tc	

name	Type	Description
	ont-tc-tx-los-frag-tc ont-tc-bad-gem-hd-tc ont-uni-ds-drpdp-fr-tc ont-uni-up-drpdp-fr-tc ont-uni-ds-crc-fr-tc ont-uni-up-crc-fr-tc ont-cpu-util-tca ont-mem-util-tca pim-neighbor-down pim-max-mcroutes li-traffic-disabled li-bandwidth-limit li-out-of-res otdr-cap-mismatch login-successful login-failure cfm-defrdiccm cfm-defmacstatus cfm-defremoteccm cfm-deferrorccm cfm-defxconccm cfm-defais bfd-session-down bfd-max-resource bfd-stale-entry tca-outputbw tca-inputbw tca-rxcrcalign tca-txcrcalign tca-txcollisions tca-outpuhighbw tca-outputmedbw tca-outputlowbw tca-inpuhighbw tca-inputmediumbw tca-inputlowbw eth-cfm-defrdiccm eth-cfm-defmacstatus eth-cfm-defremoteccm eth-cfm-deferrorccm eth-cfm-defxconccm rsvp-neighbor-down rsvp-instance-down eth-ring-path-block ai-platform-down ai-appl-install-fail ip-assign-fail ont-tr069-serv-mis ont-snmp-mis bsf-dhcpv4 bsf-dhcpv6 bsf-pon bsf-vbridge bsf-qos bsf-igmp bsf-lxfwd prot-not-available	

101 query current alarms by filters

name	Type	Description
	prot-switchover-fail efm-oam-cpelinkfault efm-oam-cpedyinggasp efm-oam-cpecrevt ont-loopdetect alrm-tbl-overflow auto-switch-status auswqueuefullatm auswbkpfailatm auswrecfgfailatm auswdataunatm auswqueuefulptm auswbkpfailptm auswrecfgfailptm auswdataunptm auswbakpfailatm chpr-com-fail chpr-tx-fail chpr-unprov-ont chpr-prov-mismatch chpr-loss-sig chpr-diagnostic chpr-loid-conflict chpr-loid-pwd-err chpr-stk-laser-dis chpr-sfp-mismatch chpr-rng-mismatch chpr-alien-test chpr-alien-detect chpr-deact-hightca chpr-deact-lowtca chpr-dp-integ olt-chpr-tc-err-frag olt-chpr-up-bw-tca olt-chpr-down-bw-tca cfg-dld-fail cfg-act-fail cfg-dld-ip cfg-ver-mismatch cfg-file-missing cfg-verctrl-err cfg-not-supported ont-prot-not-available ont-gen-temp-low ont-gen-volt-low ont-gen-tx-pwr-high ont-gen-bias-low ont-gen-rx-hwarn ont-gen-rx-lwarn ont-gen-tx-hwarn ont-gen-tx-lwarn ont-gen-temp-hwarn ont-gen-temp-lwarn ont-gen-volt-hwarn ont-gen-volt-lwarn ont-gen-bias-hwarn ont-gen-bias-lwarn	

name	Type	Description
	sfu-sup2-temp-low	
	sfu-sup2-volt-low	
	sfu-sup2-tx-high	
	sfu-sup2-bias-low	
	sfu-sup2-rx-hwarn	
	sfu-sup2-rx-lwarn	
	sfu-sup2-tx-hwarn	
	sfu-sup2-tx-lwarn	
	sfu-sup2-temp-hwarn	
	sfu-sup2-temp-lwarn	
	sfu-sup2-volt-hwarn	
	sfu-sup2-volt-lwarn	
	sfu-sup2-bias-hwarn	
	sfu-sup2-bias-lwarn	
	soho-sup2-temp-low	
	soho-sup2-volt-low	
	soho-sup2-tx-high	
	soho-sup2-bias-low	
	soho-sup2-rx-hwarn	
	soho-sup2-rx-lwarn	
	soho-sup2-tx-hwarn	
	soho-sup2-tx-lwarn	
	soho-sup2-temp-hwarn	
	soho-sup2-temp-lwarn	
	soho-sup2-volt-hwarn	
	soho-sup2-volt-lwarn	
	soho-sup2-bias-hwarn	
	soho-sup2-bias-lwarn	
	mdu-sup2-temp-low	
	mdu-sup2-volt-low	
	mdu-sup2-tx-high	
	mdu-sup2-bias-low	
	mdu-sup2-rx-hwarn	
	mdu-sup2-rx-lwarn	
	mdu-sup2-tx-hwarn	
	mdu-sup2-tx-lwarn	
	mdu-sup2-temp-hwarn	
	mdu-sup2-temp-lwarn	
	mdu-sup2-volt-hwarn	
	mdu-sup2-volt-lwarn	
	mdu-sup2-bias-hwarn	
	mdu-sup2-bias-lwarn	
	cust-alm1	
	cust-alm2	
	cust-alm3	
	cust-alm4	
	cust-alm5	
	cust-alm6	
	cust-alm7	
	cust-alm8	
	cust-alm9	
	cust-alm10	
	cust-alm11	
	cust-alm12	
	cust-alm13	
	cust-alm14	
	cust-alm15	

101 query current alarms by filters

name	Type	Description
	cust-alm16 cust-alm17 cust-alm18 cust-alm19 cust-alm20 cust-alm21 cust-alm22 cust-alm23 cust-alm24 cust-alm25 cust-alm26 cust-alm27 cust-alm28 cust-alm29 cust-alm30 cust-alm31 ethernet-ring-ptfwst ethernet-ring-fop-to ethernet-ring-fop-pm fpm-depletion exp-seizureack exp-disconack exp-forcerelack packet-loss remote-packet-loss no-dsp-resource la-down la-standby-na la-switch-fail la-degrade melt-board-reset board-shelf-mismatch fcs-thresh-exceed) Possible values: - all : all alarms for query - xtca-ne-es : errored seconds in 15 min - xtca-ne-ses : severely errored seconds in 15 min - xtca-ne-uas : unavailable seconds in 15 min - xtca-ne-day-es : errored seconds in 1 day - xtca-ne-day-ses : severely errored seconds in 1 day - xtca-ne-day-uas : unavailable seconds in 1 day - xtca-fe-es : errored seconds in 15 min - xtca-fe-ses : severely errored secs in 15 min - xtca-fe-uas : unavailable seconds in 15 min - xtca-fe-day-es : errored seconds in 1 day - xtca-fe-day-ses : severely errored secs in 1 day - xtca-fe-day-uas : unavailable seconds in 1 day - xtca-leftrs : low error free throughput seconds in 15 min - xtca-day-leftrs : low error free throughput seconds in 1 day - xtca-fe-leftrs : far end low error free throughput seconds in 15 min - xtca-fe-day-leftrs : far end low error free throughput seconds in 1 day - xtca-auto-port-reset : auto-port-resets in 1 week - xtca-reinit : Reinitialization seconds in 15 min - xtca-day-reinit : Reinitialization seconds in 1 day - xdsl-ne-los : loss of signal	

name	Type	Description
	- xdsl-ne-lof : loss of frame - xdsl-ne-lom : loss of margin - xdsl-ne-ese : excessive severe errors - xdsl-act-cfg-error : line configuration data cannot be used - xdsl-act-not-feas : line capacity not enough to setup requested profile - xdsl-up-br-reach : planned bitrate not reached after initialization - xdsl-ne-ncd : no cell delineation - xdsl-ne-lcd : loss of cell delineation - xdsl-fe-los : loss of signal - xdsl-fe-lof : loss of frame - xdsl-fe-lpr : loss of power - xdsl-fe-lol : loss of link - xdsl-fe-lom : loss of margin - xdsl-fe-ese : excessive severe errors - xdsl-fe-upbo-vio : upbo violation - xdsl-fe-cpe-pol : activation failure cpe policing - xdsl-tpstc-mis : mismatch between the configured tps-tc mode and the mode supported by the connected cpe - xdsl-act-comm : init not successful due to communications problem - xdsl-act-modem : no peer modem detected - xdsl-do-br-reach : planned bitrate not reached after init - xdsl-fe-ncd : no cell delineation - xdsl-fe-lcd : loss of cell delineation - xdsl-frtx-init-fail : init not successful due to forced rtx - xdsl-vect-dle : vectoring disorderly leaving event - xdsl-fe-mis-peer-35b : VDSL2 35b opmode mismatch between XTU-C and XTU-R - vectline-xtc-var-vict : excessive victim crosstalk coefficients variation - vectline-xtc-var-dist : excessive disturber crosstalk coefficients variation - vectline-corp-errf : corrupted or missing errorf-samples - vect-cpe-cap-mismatch : not allowed Vectoring CPE connected - vectline-conf_notfeas : vect line configuration not feasible - vect-vp-lt-mismatch : actual vp-lt connection(s) do not match expected vp-lt connection(s) or vp-lt connection lost - vect-inv-qsf : qsf has no valid Nokia ID - vect-vp-lt-fail : vp-lt connection not operational - vect-no-gain-at-init : Lines cannot train in gain-at-init mode - sw-rollback : non active oswp,db cannot be operational - will rollback - db-rollback : selected oswp,db cannot be operational - will rollback - xvps-inv-dbase : invalid xvps dbase - inv-cde-file : invalid xvps cde file - miss-cde-file : missing cde profile - cde-hash-error : cde profile hash error - auto-fetch-failure : not able to fetch file from specified server - low-disk-space : insufficient space for Sw storage - cell-discard-up : cell discarded in the upstream direction - cell-discard-down : cell discarded in the downstream	

101 query current alarms by filters

name	Type	Description
	direction - persist-data-loss : all data lost after restart - system not configured - mac-conflict : duplicate mac address on the bridge port - vmac-full : virtual mac address is full on the bridge port - snmp-comm-lost : snmp server not responding - preferred-mode : preferred mode not available - timing-reference : timing reference failure - nt-disk-95%full : nt disk 95% full - shub-loc : communication lost with shub - cf-error : compact flash access error - back-pnl-inv : BackPanel-type Invalid - ihub-conf-loss : iHub configuration loss - recent changes lost - rack-power : power fuse broken - rack-fan-unit1 : fan unit rack 1 failing - rack-fan-unit2 : fan unit rack 2 failing - shelf-mismatch : shelf type different from planned type - shelf-missing : detected shelf no longer detected - shelf-install-missing : shelf planned but not installed - door : open cabinet door - ac-power-fail : external power failure - shelf shutdown in 15 minutes - board-mismatch : board inserted different from planned - waiting-for-sw : not able to download all the applicable sw files - temp-exceeded : temperature threshold exceeded on the board - backplane-data-failure: lt port on backplane data failure - temp-shutdown : board powered down itself - too high temperature - board-missing : board detected after planning - now missing - board-instl-missing : board never detected after planning - board-init : board initialisation failure - board-reset-prot : number of resets exceeded - sem-power-fail : SEM external power failure - sem-ups-fail : SEM external power supply failure - board-reset-cf : board reset and/or communication failure - vlan-assign-fail : failure to assign VLAN for a user session - vsa-info-invalid : radius fail to assign a valid vsa to a user session - auth-mac-conflict : failure to check mac conflict for a user session - user-pwd-fault : failure to check user or password of a user session - up-plan-bitrate : upstream bitrate is above min and below planned - up-min-bitrate : upstream bitrate is below min bitrate - up-config-not-feas : upstream bitrate is not enough to set up config group - down-plan-bitrate : downstream bitrate is above min and below planned - down-min-bitrate : downstream bitrate is below min bitrate - down-config-not-feas : downstream bitrate is not enough to set up config group - non-bonding-cpe : no bonding cpe modem is connected	

name	Type	Description
	- multiple-cpes : bonding group has multiple cpe modems connected - register : bonding group discovery or aggregation register failure - group-incomplete : bonding group is incomplete - host-sfp-los : loss of signal - host-sfp-tx-fail : Tx failure - host-sfp-not-prst : not present - host-sfp-inv-id : no valid Nokia ID - host-sfp-ctrl-fail : control failure - host-sfp-rmtlt : unexpected remote plug-in - host-sfp-mismatch : assignment does not match reported rack/shelf/slot - host-sfp-incompt : incompatible shelf type detected - exp-sfp-los : expansion side loss of signal - exp-sfp-tx-fail : Tx failure - exp-sfp-not-prst : not present - exp-sfp-inv-id : no valid Nokia ID - exp-sfp-ctrl-fail : control failure - exp-sfp-1-los : expansion side sfp1 loss of signal - exp-sfp-2-los : expansion side sfp2 loss of signal - ext-qsfp-invld : Invalid Nokia ID - tx-power-high-alarm : tx power more than alarm range - tx-power-low-alarm : tx power less than alarm range - rx-power-high-alarm : rx power more than alarm range - rx-power-low-alarm : rx power less than alarm range - tx-biascur-high-alarm : tx bias current high alarm - tx-biascur-low-alarm : tx bias current low alarm - volt-high-alarm : voltage high alarm - volt-low-alarm : voltage low alarm - temp-high-alarm : temperature high alarm - temp-low-alarm : temperature low alarm - tx-power-high-warn : tx power more than warn range - tx-power-low-warn : tx power less than warn range - rx-power-high-warn : rx power more than warn range - rx-power-low-warn : rx power less than warn range - tx-biascur-high-warn : tx bias current high warn - tx-biascur-low-warn : tx bias current low warn - volt-high-warn : voltage high warn - volt-low-warn : voltage low warn - temp-high-warn : temperature high warn - temp-low-warn : temperature low warn - onu-unprovisioned : unprovisioned ont - signal-loss : pon loss of signal - bitrate-high : the error bit rate high at pon interface - opmodule-mismatch : the optical module mismatched at pon interface - key-fail-one-churn : key exchange failure during one churning time - key-fail-three-churn : key exchange failure during three churning time - oam-discov-fail : extend oam discovery failure - report-timeout : report timeout detecting - total-packets-exceed : total amount of protocol packets exceed threshold - arp-packets-exceed : protocol arp packets exceed threshold - dhcp-packets-exceed : protocol dhcp packets exceed	

101 query current alarms by filters

name	Type	Description
	threshold - igmp-packets-exceed : protocol igmp packets exceed threshold - pppoe-packets-exceed : protocol pppoe packets exceed threshold - nd-packets-exceed : protocol nd packets exceed threshold - icmpv6-packets-exceed : protocol icmpv6 packets exceed threshold - mld-packets-exceed : protocol mld packets exceed threshold - dhcpv6-packets-exceed : protocol dhcpv6 packets exceed threshold - cfm-packets-exceed : protocol cfm packets exceed threshold - dsx1-serdes-fail : SERDES clock alarm failure - dsx1-tributary1-fail : The tributary 1 clock is not present - dsx1-tributary2-fail : The tributary 2 clock is not present - dsx1-los-fail : All the selected tribs in Loss of Signal - dsx1-ais-sync : Alarm Indication signal on the tributary selected as sync source - dsx1-lof-sync : Loss of Framing on the tributary selected as sync source - dsx1-los-sync : Loss of signal on the tributary selected as sync source - dsx1-deg-fail : Signal degrade Alarm - dsx1-rei-from-liu : Remote Error Indication alarm from LIU - dsx1-rdi-from-liu : Remote Defect Alarm from LIU - dsx1-crc6-from-liu : Cyclic Redundancy check-6 alarm from LIU - dsx1-crc4-from-liu : Cyclic Redundancy check-4 alarm from LIU - dsx1-crc4-th-from-liu : Cyclic Redundancy check-4 threshold alarm from LIU - dsx1-ais-from-liu : Alarm Indication Signal alarm from LIU - dsx1-los-from-liu : Loss of signal alarm from LIU - dsx1-lof-from-liu : Loss of framing alarm from LIU - dsx1-lomf-from-liu : Loss of Multi-frame alarm from LIU - dsx1-rei-from-iwf : Remote Error Indication alarm from IWF - dsx1-rdi-from-iwf : Remote Defect Alarm from IWF - dsx1-crc6-from-iwf : Cyclic Redundancy check-6 alarm from IWF - dsx1-crc4-from-iwf : Cyclic Redundancy check-4 alarm from IWF - dsx1-crc4-th-from-iwf : Cyclic Redundancy check-4 threshold alarm from IWF - dsx1-ais-from-iwf : Alarm Indication Signal alarm from IWF - dsx1-los-from-iwf : Loss of signal alarm from IWF - dsx1-lof-from-iwf : Loss of framing alarm from IWF - dsx1-lomf-from-iwf : Loss of Multi-frame alarm from IWF - pppce-trans-15min-tca : 15 minutes transaction timeout count exceeds configured TCA - pppce-sess-15min-tca : 15 minutes session timeout count exceeds configured TCA	

name	Type	Description
	- pppce-trans-1day-tca : 1day transaction timeout count exceeds configured TCA - pppce-sess-1day-tca : 1day session timeout count exceeds configured TCA - custom1 : customizable alarm 1 - custom2 : customizable alarm 2 - custom3 : customizable alarm 3 - custom4 : customizable alarm 4 - custom5 : customizable alarm 5 - he-custom1 : host expansion customizable alarm 1 - he-custom2 : host expansion customizable alarm 2 - he-custom3 : host expansion customizable alarm 3 - he-custom4 : host expansion customizable alarm 4 - he-custom5 : host expansion customizable alarm 5 - he-custom6 : host expansion customizable alarm 6 - custom6 : customizable alarm 6 - custom7 : customizable alarm 7 - custom8 : customizable alarm 8 - custom9 : customizable alarm 9 - custom10 : customizable alarm 10 - custom11 : customizable alarm 11 - custom12 : customizable alarm 12 - custom13 : customizable alarm 13 - custom14 : customizable alarm 14 - custom15 : customizable alarm 15 - custom16 : customizable alarm 16 - custom17 : customizable alarm 17 - loss-swo-cap : switch over capability in a redundant system - ping-check-fail : ping check in a redundant system - der-temp1 : Derived Alarm for Temporal Filter 1 - der-temp2 : Derived Alarm for Temporal Filter 2 - der-temp3 : Derived Alarm for Temporal Filter 3 - der-temp4 : Derived Alarm for Temporal Filter 4 - der-temp5 : Derived Alarm for Temporal Filter 5 - der-temp6 : Derived Alarm for Temporal Filter 6 - der-temp7 : Derived Alarm for Temporal Filter 7 - der-temp8 : Derived Alarm for Temporal Filter 8 - der-temp9 : Derived Alarm for Temporal Filter 9 - der-temp10 : Derived Alarm for Temporal Filter 10 - der-temp11 : Derived Alarm for Temporal Filter 11 - der-temp12 : Derived Alarm for Temporal Filter 12 - der-temp13 : Derived Alarm for Temporal Filter 13 - der-temp14 : Derived Alarm for Temporal Filter 14 - der-temp15 : Derived Alarm for Temporal Filter 15 - der-temp16 : Derived Alarm for Temporal Filter 16 - der-temp17 : Derived Alarm for Temporal Filter 17 - der-temp18 : Derived Alarm for Temporal Filter 18 - der-temp19 : Derived Alarm for Temporal Filter 19 - der-temp20 : Derived Alarm for Temporal Filter 20 - der-temp21 : Derived Alarm for Temporal Filter 21 - der-temp22 : Derived Alarm for Temporal Filter 22 - der-temp23 : Derived Alarm for Temporal Filter 23 - der-temp24 : Derived Alarm for Temporal Filter 24 - der-temp25 : Derived Alarm for Temporal Filter 25 - der-temp26 : Derived Alarm for Temporal Filter 26 - der-temp27 : Derived Alarm for Temporal Filter 27 - der-temp28 : Derived Alarm for Temporal Filter 28	

101 query current alarms by filters

name	Type	Description
	- der-temp29 : Derived Alarm for Temporal Filter 29 - der-temp30 : Derived Alarm for Temporal Filter 30 - der-temp31 : Derived Alarm for Temporal Filter 31 - der-spa1 : Derived Alarm for Spatial Filter 1 - der-spa2 : Derived Alarm for Spatial Filter 2 - der-spa3 : Derived Alarm for Spatial Filter 3 - der-spa4 : Derived Alarm for Spatial Filter 4 - der-spa5 : Derived Alarm for Spatial Filter 5 - der-spa6 : Derived Alarm for Spatial Filter 6 - der-spa7 : Derived Alarm for Spatial Filter 7 - der-spa8 : Derived Alarm for Spatial Filter 8 - der-spa9 : Derived Alarm for Spatial Filter 9 - der-spa10 : Derived Alarm for Spatial Filter 10 - der-spa11 : Derived Alarm for Spatial Filter 11 - der-spa12 : Derived Alarm for Spatial Filter 12 - der-spa13 : Derived Alarm for Spatial Filter 13 - der-spa14 : Derived Alarm for Spatial Filter 14 - der-spa15 : Derived Alarm for Spatial Filter 15 - der-spa16 : Derived Alarm for Spatial Filter 16 - der-spa17 : Derived Alarm for Spatial Filter 17 - der-spa18 : Derived Alarm for Spatial Filter 18 - der-spa19 : Derived Alarm for Spatial Filter 19 - der-spa20 : Derived Alarm for Spatial Filter 20 - der-spa21 : Derived Alarm for Spatial Filter 21 - der-spa22 : Derived Alarm for Spatial Filter 22 - der-spa23 : Derived Alarm for Spatial Filter 23 - der-spa24 : Derived Alarm for Spatial Filter 24 - der-spa25 : Derived Alarm for Spatial Filter 25 - der-spa26 : Derived Alarm for Spatial Filter 26 - der-spa27 : Derived Alarm for Spatial Filter 27 - der-spa28 : Derived Alarm for Spatial Filter 28 - der-spa29 : Derived Alarm for Spatial Filter 29 - der-spa30 : Derived Alarm for Spatial Filter 30 - der-spa31 : Derived Alarm for Spatial Filter 31 - apsf-alarm : Applique Power Supply Failure - custextalarm1 : Customizable External Alarm Number 1 - custextalarm2 : Customizable External Alarm Number 2 - custextalarm3 : Customizable External Alarm Number 3 - custextalarm4 : Customizable External Alarm Number 4 - custextalarm5 : Customizable External Alarm Number 5 - pluginfan : REM Fan Alarm - plugin-dc-a : REM DC A Alarm - plugin-dc-b : REM DC B Alarm - plugin-dg : Dying Gasp Alarm - ntr-a-loss : NTR-A signal is not available - ntr-b-loss : NTR-B signal is not available - xvps-conf-loss : xvps configuration loss - mac-entry-nofree : no free mac entry in the mac table on lt board - fibre-conn-mismatch : REM Fibre Connection Mismatch Alarm - link-cap-mismatch : Link speed capability mismatch - eqpt-cap-mismatch : Link equipment capability mismatch - ctrl-dnld-failure : Controller card download failure - melt-hw-issue : MELT hardware issue - melt-board-reset : MELT board reset - board-shelf-mismatch : board type and shelf type mismatch	

name	Type	Description
	- mgnt-type-mismatch : Board management type mismatch - fileserv-unavail : file transfer Server unavailable or file transfer failed - shdsl-n-loopback : loopback active at the network side - shdsl-c-loopback : loopback active at the customer side - shdsl-conferr : configuration error - shdsl-atm-lcd : loss of atm cell delineation - shdsl-lpr : loss of power at stu-r - shdsl-secu-err : unable to disable stu-r access - shdsl-dev-fault : device fault - shdsl-atm-ncd : no atm cell delineation - shdsl-n-losw : loss of sync word at the network side on each pair - shdsl-c-losw : loss of sync word at the customer side on each pair - shdsl-n-aten : loop attenuation alarm at the network side on each pair - shdsl-c-aten : loop attenuation alarm at the customer side on each pair - shdsl-n-snr : snr margin alarm at the network side each pair - shdsl-c-snr : snr margin alarm at the customer side on each pair - shdsl-n-dccont : dc continuity fault at the network side on each pair - shdsl-c-dccont : dc continuity fault at the customer side on each pair - shdsl-c-actfail : activation failure at the customer side on each pair - e1-fe-rai : Receiving Remote Alarm Indication - e1-ne-rai : Transmitting Remote Alarm Indication - e1-fe-ais : Receiving Alarm Indication Signal - e1-ne-ais : Transmitting Alarm Indication Signal - e1-lof : E1 Loss of frame - e1-los : E1 Loss of Signal - e1-loopback : E1 facility in loopback - ima-grp-fe-su : far-end starting up - ima-grp-fe-cfg : far-end failed configuration - ima-grp-ne-cfg : near-end failed configuration - ima-grp-fe-nl : insufficient number of links at far-end - ima-grp-ne-nl : insufficient number of links at near-end - ima-grp-fe-blk : far-end is blocked - ima-lnk-lif : loss of ima frame - ima-lnk-lods : link out of delay synchronization - ima-lnk-misc : link misconnect - ima-lnk-rfi : link remote failure indication - ima-lnk-fault : fault in link facility - ima-lnk-txblk : transmit blocked due to far-end - ima-lnk-rxblk : receive blocked due to far-end - bad-digitmap : Configured digitmap is unusable - dhcp-unreach : The DHCP server is unreachable - dhcp-no-srv : The address in DHCP reply is NULL - dhcp-inv-srv : The address in DHCP reply is invalid - norpniewithsoftdsp : do not plan / plug-in RPNI-E board with SoftDsp SW image - unknown-sub : subscriber exist in the POLT, but not in the appl server - ground-key : Return current to the ground	

101 query current alarms by filters

name	Type	Description
	- port-hightemp : Temperature threshold on user port exceeded. - port-jbfltca : JB fill level threshold on user port exceeded. - reg-domainname : Registration failure (resolving domain name). - reg-auth : Registration failure (authentication). - reg-timeout : Registration failure (message timeout). - reg-srvfailresp : Registration failure (failure response from server). - inv-domainname : Invitation failure (resolving domain name). - inv-auth : Invitation failure (authentication). - inv-timeout : Invitation failure (message timeout). - inv-srvfailresp : Invitation failure (failure response from server). - subs-srvfailresp : Subscribe failure (failure response from server). - subs-domainname : Subscribe failure (resolving domain name). - subs-auth : Subscribe failure (authentication). - subs-refreshfail : Subscribe failure (refresh failure). - subs-inittimeout : Subscribe failure (initial REQ timeout). - emergency-call : Emergency call for SIP POTS is ongoing. - e1sip-reg-domainname : E1 sip termination registration failure (resolving domain name). - e1sip-reg-auth : E1 sip termination registration failure (authentication). - e1sip-reg-timeout : E1 sip termination registration failure (message timeout). - e1sip-reg-srvfailresp : E1 sip termination registration failure (failure response from server). - e1sip-inv-domainname : E1 sip termination invitation failure (resolving domain name). - e1sip-inv-auth : E1 sip termination invitation failure (authentication). - e1sip-inv-timeout : E1 sip termination invitation failure (message timeout). - e1sip-inv-srvfailresp : E1 sip invitation failure (failure response from server). - e1sip-emergency-call : Emergency call for ISDN PRA/CAS R2 is ongoing. - e1itf-ais-signal : Alarm Indication Signal detected at E1 interface. - e1itf-los-signal : Loss Of Signal detected at E1 interface. - e1itf-rai-signal : Remote Alarm Indication detected at E1 interface. - e1sip-misconfig-mgc10 : Configuration not conform with the core network entity. - e1sip-nsmprf-missed : The SIP termination requires a NSM profile. - e1t1itf-recv-ais : Alarm Indication Signal received at interface. - e1t1itf-recv-los : Loss Of Signal received at interface. - e1t1itf-recv-rai : Remote Alarm Indication received at interface. - transport-mismatch : Transport protocol mismatch - dns-lookup-failure : Dns look up failure	

name	Type	Description
	- none-dns-srv : No reply for all DNS serverd - no-dns-srv : No DNS servers configured - none-srv : No reply for all SIP First Hops - no-srv : No SIP First Hop configured - reg-srv-unreach : All SIP register servers are unreachable - proxy-srv-unreach : All SIP proxy servers are unreachable - dhcp-srv-unreach : The DHCP server is unreachable on this board - fo-trigger : Fail Over Triggered - fb-trigger : Fail Back Triggered - du-trigger : Deliberate Update Triggered - ssp-missing : SSP Missing in CDE - dns-pool-exceed : Number of different SG associated DNS pools exceed - lsa-fo-trigger : SIP voice service degraded - fail-over to LSA server - reg-domainname-sec : Registration failure (resolving domain name). - reg-auth-sec : Registration failure (authentication). - reg-timeout-sec : Registration failure (message timeout). - reg-srvfailresp-sec : Registration failure (failure response from server). - inv-domainname-sec : Invitation failure (resolving domain name). - inv-auth-sec : Invitation failure (authentication). - inv-timeout-sec : Invitation failure (message timeout). - inv-srvfailresp-sec : Invitation failure (failure response from server). - subs-srvfailresp-sec : Subscribe failure (failure response from server). - subs-domainname-sec : Subscribe failure (resolving domain name). - subs-auth-sec : Subscribe failure (authentication). - subs-refreshfail-sec : Subscribe failure (refresh failure). - subs-inittimeout-sec : Subscribe failure (initial REQ timeout). - emergency-call-sec : Emergency call for Secondary Termination is ongoing. - fanout : Lt load overflow - up-overflow : Upstream load overflow - upobc-overflow : Upstream load to OBC overflow - dwobc-overflow : Downstream load to OBC overflow - dw-overflow : Downstream load overflow - lwpri-overflow : The number of BE and CL pkts dropped exceed threshold - queue-drop : The number of pkts dropped by queue exceeds threshold - queue-load : The queue load exceeds threshold - queue-peak-usage : The queue peak usage exceeds threshold - mgc-unreachable : loss of contact with the media gateway controller - failover-to-esamgc : failover to esa mgc - sgc-unreachable : loss of contac with signaling gateway controller - lcard-unreach-srvcard : line card unreachable with server card	

101 query current alarms by filters

name	Type	Description
	- lcard-type-mismatch : associate board of wrong type - meg-unknown-sub : the megaco subscriber is unknown - meg-ground-key : voice port ground key - meg-high-temp : voice port high temperature - meg-act-fail : the first link layer for isdn subscriber activation failure - meg-over-current : voice port over current - line-showering : line showering - low-qos-packetloss : the total packet loss has exceeded the configured threshold - low-qos-jitter : the rtp jitter has exceeded the configured threshold - low-qos-delay : the rtp delay has exceeded the configured threshold - sig-brd-persist-loss : voice signaling board persistent data loss - sig-brd-disk-full : voice signaling board disk 90% full - sig-brd-db-rollback : voice signaling board db rollback - mg-overload : mg overload - meg-unknown-sub-sec : The Megaco subscriber exists in voice signaling board but not in media gateway controller. - line-showering-sec : A subscriber line exceeds 20 off-hook / on-hook events / minute. - loss-env-mon : env-monitor box lost or not alive - etca-los : loss of signal errors in 15 min - etca-fcs : frame check sequence errors in 15 min - etca-day-los : loss of signal errors in 1 day - etca-day-fcs : frame check sequence errors in 1 day - etca-rx-octets : received octets in 15 min - etca-tx-octets : transmitted octets in 15 min - etca-day-rx-octets : received octets in 1 day - etca-day-tx-octets : transmitted octets in 1 day - user-sfp-los : user sfp loss of signal - user-sfp-tx-fail : user sfp tx failure - user-sfp-not-prst : user sfp not detected - user-sfp-inv-id : user sfp invalid id - user-sfp-t-exceed : user sfp temperature exceed - user-sfp-mismatch : user sfp mismatch the configured type - uplink-sfp-los : uplink sfp loss of signal - uplink-sfp-tx-fail : uplink sfp tx failure - uplink-sfp-not-prst : uplink sfp not detected - uplink-sfp-inv-id : uplink sfp invalid id - uplink-sfp-t-exceed : uplink sfp temperature exceed - uplink-sfp-mismatch : uplink sfp mismatch the configured type - loss-lsmswp-cap : lsm redundancy - inv-xvps-pair-data : invalid xvps pair redundancy data - network-power-loss : Loss of Network Power - hw-fault : Hardware Failure - bat-miss : Power Source Battery Missing - bat-fail : Power Source Battery Failure - bat-low : Power Source Battery Charge LOW - bat-a-fail : Power Source BAT-A Fail - bat-b-fail : Power Source BAT-B Fail - ac-vol-out-range : AC Input Voltage Value Out of Range - network-power-loss-b : Loss of Network Power B - sem-ac-power-fail : External AC power supply failure	

name	Type	Description
	- sem-ups-low-volt : External power supply low voltage - dc-a-fail : Local DC A power failure - dc-b-fail : Local DC B power failure - plan-power-mismatch : Planned and detected power mode mismatch - water-seepage-in-box : Detected water seepage in enclosure - sealed-box-open : Sealed box open detected - dc-a-vol-out-range : DC A Input Voltage Value Out of Range - dc-b-vol-out-range : DC B Input Voltage Value Out of Range - inlet-temp-major : The inlet temperature has exceeded a major level - inlet-temp-critical : The inlet temperature has exceeded a critical level - psu-fail-crit : Power Supply failure - psu-a-fail-presence : Power Supply A is not present - psu-a-fail-vin-ac-nok : Power Supply A has Vin AC fault - psu-a-fail-vin-uv : Power Supply A has Vin undervoltage - psu-a-fail-vin-ov : Power Supply A has Vin overvoltage - psu-a-fail-vout-uv : Power Supply A has Vout undervoltage - psu-a-fail-vout-ov : Power Supply A has Vout overvoltage - psu-a-fail-iout-oc : Power Supply A has Iout overcurrent - psu-a-fail-ovtemp : Power Supply A has over temperature - psu-b-fail-presence : Power Supply B is not present - psu-b-fail-vin-ac-nok : Power Supply B has Vin AC fault - psu-b-fail-vin-uv : Power Supply B has Vin undervoltage - psu-b-fail-vin-ov : Power Supply B has Vin overvoltage - psu-b-fail-vout-uv : Power Supply B has Vout undervoltage - psu-b-fail-vout-ov : Power Supply B has Vout overvoltage - psu-b-fail-iout-oc : Power Supply B has Iout overcurrent - psu-b-fail-ovtemp : Power Supply B has over temperature - synce-fail : synce clock source failure - bits-fail : bits clock source failure - bits-output-shutoff : bits output failure - ieee1588-fail : ieee1588 clock source failure - gnss-fail : gnss clock source failure - ieee1588-hybrid-fail : ieee1588 hybrid tod source failure - signal-loss : synce or bits clock signal loss - signal-efd : synce or bits clock signal exceed frequency deviation - esmc-loss : clock source loss SSM information - bits-output-exceed : exceed bits output threshold - ql-input-exceed : exceed input clock source threshold - holdover : clock system is in the holdover - lti : all clock source failed - tod-reference-fail : Timing ToD Reference failed - internal-clk-fail : Internal CLK failed - bgp-peer-down : peer operational state is down - bgp-routes-mid-limit : 90% of max nbr of routes BGP can learn from a peer is reached - isis-adjacency-down : isis adjacency is down	

101 query current alarms by filters

name	Type	Description
	- isis-adjacency-reject : isis adjacency is rejected - isis-instance-down : isis instance is down or not - ospf-lsa-limit : limit of received LSA's is reached - ospf-lsa-mid-limit : 90% of limit of received LSA's is reached - ospf-neighbor-down : OSPF neighbour is down - ospf-instance-down : OSPF instance is down or not - ospf3-lsa-limit : limit of received OSPFv3 LSAs is reached - ospf3-lsa-mid-limit : 90% of limit of received OSPFv3 LSAs is reached - ospf3-neighbor-down : OSPFv3 neighbour is down - ospf3-instance-down : OSPFv3 instance is down or not - rip-instance-down : rip instance down - lag-down : lag down - lagsubgrp-thresh-reach: lag subgroup threshold reached - lagsubgrp-switch-fail : lag subgroup switchover failed - no-unpinned-free-ports: No free ports available for unpinned traffic - general-arp-limit : arp limit exceeded - gen-switch-out-of-res : failure due to lack of resources on switch - ipv6-nc-limit : ipv6 neighbor cache limit exceeded - dhcp-session-oor : dhcp session out of resources - ihub-fdb-limit : layer 2 fdb limit reached - ihub-mac-limit : layer 2 mac limit reached - l2fw-stp-exception : STP exception condition is present in the SAP - l2fw-stp-root-guard : STP root guard violation is present - vprn-routes-limit : limit of ip is reached - vprn-ipv6-routes-limit: limit of ipv6 is reached - dhcpv6-lease-limit : limit of dhcpv6 leases is reached - dhcpv4-lease-limit : limit of dhcpv4 leases is reached - vpls-mfib-limit : limit of fib table is reached - ihub-ipv6-dad-own : duplicate IPV6 address is detected for IP address allotted to system - ihub-ipv6-dad : duplicate IPV6 address is detected for a user's IP address - ihub-ipv6-dup-pd-route: ipv6 duplicate pd detected - vpls-duplicate-mac : duplicate mac address is detected - vpls-fdb-limit : limit of fdb table is reached - vpls-self-duplic-mac : duplicate of a system owned mac address detected on a sap - vpls-sdp-self-dup-mac : duplicate of a system owned mac address detected on a sdp binding - link-down : link is down - link-lagport-add-fail : failure to add port to LAG - link-conf-mismatch : SFP+plugin-types does not match the planned speed and/or auto-negotiation for the port - ihub-peer-comm : ihub peer to peer communication failure - ihub-sw-fail : IHUB s/w error - ihub-hw-fail : IHUB h/w error - ihub-link-fail : IHUB link failure - ihub-proc-overload : IHUB processor exceeded - ihub-out-of-mem : IHUB processor out of memory - ntp-comm-lost : No response is received from the NTP servers - ldp-instance-down : ldp instance down	

name	Type	Description
	- ldp-session-down : ldp session down - mpls-instance-down : mpls instance down - mpls-lsp-down : lsp down - mpls-lsp-path-down : lsp path down - sdp-instance-down : sdp instance down - sdp-binding-down : sdp binding down - epipe-instance-down : epipe instance down - lldpmed-portcfg-mis : config request failure for lldpmed portconfig - lldpmed-mediapl-mis : config request failure for lldpmed mediapolicy - vlanport-svc-mismatch : config request failure for the provisioned vlanport - mcsrc-stream-lost : multicast video stream lost - eqptsupl-syslog-upload: upload of log file to remote server failure - eqptsupl-ontsw-dnload : ont sw download in progress - cf-75%used : Compact flash exceeds 75% of life expectancy - cf-90%used : Compact flash exceeds 90% of life expectancy - olt-gen-pon-com-fail : pon communication failure on olt - olt-gen-tx-fail : transmitter failure on olt - olt-gen-unprov-ont : unprovisioned ont on pon - olt-gen-pon-eqpt-prov : mismatch btw equipment and provisioning pon attributes - olt-gen-pon-loss-sig : pon loss of signal - olt-gen-pon-diagnostic: pon diagnostic test active - olt-gen-loid-conflict : loid conflict ont on pon - olt-gen-loid-pwderr : loid password error ont on pon - olt-gen-pon-alien-test: pon alien diagnostic test active - olt-gen-alien-detect : pon alien detect active - olt-gen-rng-mism : pon ranging mismatch active - olt-gen-sfp-mism : pon sfp mismatch active - olt-gen-deact-hightca : deactivated ont hightca threshold crossed - olt-gen-deact-lowtca : deactivated ont lowtca threshold crossed - olt-gen-dp-integ : pon data path integrity failure - olt-gen-ddr-fault : pon failure due to ddr fault - olt-pon-tc-err-frag-tc: pon errored fragments threshold crossed - olt-ont-tc-err-frag-tc: ont errored fragments threshold crossed - ont-ploam-loss-sig : loss of signal at ont - ont-ploam-loss-ack : loss of acknowledge from ont - ont-ploam-loss-cd : loss of channel delineation of ont - ont-ploam-phy-eqpt-err: physical equipment error of ont - ont-ploam-startup-fail: startup failure in ranging of ont - ont-ploam-sig-degrade : signal degrade from ont - ont-ploam-disabled : ont disabled alarm - ont-ploam-err-msg : error message from ont - ont-ploam-inactive : inactive ont - ont-ploam-sig-fail : signal fail alarm from ont - ont-ploam-dying-gasp : dying gasp alarm from ont - ont-ploam-deact-fail : deactive failure of ont - ont-ploam-oam : loss of ploam for ont	

101 query current alarms by filters

name	Type	Description
	- ont-ploam-win-drift : drift of window alarm - ont-ploam-rdi : remote defect indication alarm - ont-ploam-loss-ks : loss of key synchronization alarm - ont-ploam-pwr-burst : power bursts on ont - ont-ploam-rog-disa : ont rogue disabled - ont-ploam-diff-reach : ont differential reach exceeded - ont-ploam-looc : Loss of OMCI channel due to persistent MIC failure - sfu-ploam-loss-sig : SFU ONT - loss of signal at ont - sfu-ploam-loss-ack : SFU ONT - loss of acknowledge from ont - sfu-ploam-loss-cd : SFU ONT - loss of channel delineation of ont - sfu-ploam-phy-eqpt-err: SFU ONT - physical equipment error of ont - sfu-ploam-startup-fail: SFU ONT - startup failure in ranging of ont - sfu-ploam-sig-degrade : SFU ONT - signal degrade from ont - sfu-ploam-disabled : SFU ONT - ont disabled alarm - sfu-ploam-err-msg : SFU ONT - error message from ont - sfu-ploam-inactive : SFU ONT - inactive ont - sfu-ploam-sig-fail : SFU ONT - signal fail alarm from ont - sfu-ploam-dying-gasp : SFU ONT - dying gasp alarm from ont - sfu-ploam-deact-fail : SFU ONT - deactive failure of ont - sfu-ploam-oam : SFU ONT - loss of ploam for ont - sfu-ploam-win-drift : SFU ONT - drift of window alarm - sfu-ploam-rdi : SFU ONT - remote defect indication alarm - sfu-ploam-loss-ks : SFU ONT - loss of key synchronization alarm - sfu-ploam-pwr-burst : SFU ONT - power bursts on ont - sfu-ploam-rog-disa : SFU ONT - ont rogue disabled - sfu-ploam-diff-reach : SFU ONT - ont differential reach exceeded - sfu-ploam-looc : SFU ONT - Loss of OMCI channel due to persistent MIC failure - soho-ploam-loss-sig : SOHO ONT - loss of signal at ont - soho-ploam-loss-ack : SOHO ONT - loss of acknowledge from ont - soho-ploam-loss-cd : SOHO ONT - loss of channel delineation of ont - soho-ploam-phy-eqpt-er: SOHO ONT - physical equipment error of ont - soho-ploam-startup-fai: SOHO ONT - startup failure in ranging of ont - soho-ploam-sig-degrade: SOHO ONT - signal degrade from ont - soho-ploam-disabled : SOHO ONT - ont disabled alarm - soho-ploam-err-msg : SOHO ONT - error message from ont - soho-ploam-inactive : SOHO ONT - inactive ont - soho-ploam-sig-fail : SOHO ONT - signal fail alarm from ont - soho-ploam-dying-gasp : SOHO ONT - dying gasp alarm from ont - soho-ploam-deact-fail : SOHO ONT - deactive failure of	

name	Type	Description
	ont - soho-ploam-oam : SOHO ONT - loss of ploam for ont - soho-ploam-win-drift : SOHO ONT - drift of window alarm - soho-ploam-rdi : SOHO ONT - remote defect indication alarm - soho-ploam-loss-ks : SOHO ONT - loss of key synchronization alarm - soho-ploam-pwr-burst : SOHO ONT - power bursts on ont - soho-ploam-rog-disa : SOHO ONT - ont rogue disabled - soho-ploam-diff-reach : SOHO ONT - ont differential reach exceeded - soho-ploam-looc : SOHO ONT - Loss of OMCI channel due to persistent MIC failure - mdu-ploam-loss-sig : MDU ONT - loss of signal at ont - mdu-ploam-loss-ack : MDU ONT - loss of acknowledge from ont - mdu-ploam-loss-cd : MDU ONT - loss of channel delineation of ont - mdu-ploam-phy-eqpt-err: MDU ONT - physical equipment error of ont - mdu-ploam-startup-fail: MDU ONT - startup failure in ranging of ont - mdu-ploam-sig-degrade : MDU ONT - signal degrade from ont - mdu-ploam-disabled : MDU ONT - ont disabled alarm - mdu-ploam-err-msg : MDU ONT - error message from ont - mdu-ploam-inactive : MDU ONT - inactive ont - mdu-ploam-sig-fail : MDU ONT - signal fail alarm from ont - mdu-ploam-dying-gasp : MDU ONT - dying gasp alarm from ont - mdu-ploam-deact-fail : MDU ONT - deactive failure of ont - mdu-ploam-oam : MDU ONT - loss of ploam for ont - mdu-ploam-win-drift : MDU ONT - drift of window alarm - mdu-ploam-rdi : MDU ONT - remote defect indication alarm - mdu-ploam-loss-ks : MDU ONT - loss of key synchronization alarm - mdu-ploam-pwr-burst : MDU ONT - power bursts on ont - mdu-ploam-rog-disa : MDU ONT - ont rogue disabled - mdu-ploam-diff-reach : MDU ONT - ont differential reach exceeded - mdu-ploam-looc : MDU ONT - Loss of OMCI channel due to persistent MIC failure - ont-hpna-ser-mis : hpna ont service mismatch - ont-hpna-los-sig : hpna loss of link - ont-moca-svc-mis : moca ont service mismatch - ont-moca-link-los : moca loss of link - ont-moca-min-bw : moca bw between nodes less than minimum bw - ont-moca-tca-rx-err-fr: moca rx errored frames threshold crossed - ont-sipa-reg-nm-fail : sipua registration name failed - ont-sipa-reg-rec-fail : sipua register reach failed - ont-sipa-reg-con-fail : sipua register connect failed - ont-sipa-reg-val-fail : sipua register validation failed	

101 query current alarms by filters

name	Type	Description
	- ont-sipa-reg-mis : sipua register mismatch - ont-vcd-cfg-nm-fail : vcd config name failed - ont-vcd-cfg-rech-fail : vcd config reach failed - ont-vcd-cfg-conn-fail : vcd config connect failed - ont-vcd-cfg-vali-fail : vcd config validation failed - ont-vcd-cfg-auth-fail : vcd config authentication failed - ont-vcd-cfg-resp-tmout: vcd config response timeout - ont-vcd-cfg-resp-err : vcd config response error - ont-vcd-cfg-file-err : vcd config file error - ont-vcd-sub-nm-fail : vcd subscription name failed - ont-vcd-sub-rech-fail : vcd subscription reach failed - ont-vcd-sub-conn-fail : vcd subscription connect failed - ont-vcd-sub-vali-fail : vcd subscription validation failed - ont-vcd-sub-auth-fail : vcd subscription authentication failed - ont-vcd-sub-resp-tmout: vcd subscription response timeout - ont-vcd-sub-resp-err : vcd subscription response error - ont-vcd-reb-requ : vcd reboot request - ont-vcd-mis : vcd mismatch - ont-mgc-mis : ont mgc mismatch - ont-mgc-timeout : ont mgc timeout - ont-sip-reg-dns : ont services pots sip registration failed (resolving domain name) - ont-sip-reg-fail : ont services pots sip registration authentication failed - ont-sip-reg-timeout : ont services pots sip registration timeout - ont-sip-reg-err-resps : ont services pots sip registration response error - ont-sip-inv-dns : ont services pots sip invitation failed (resolving domain name) - ont-sip-inv-auth : ont services pots sip invitation authentication failed - ont-sip-inv-timeout : ont services pots sip invitation timeout - ont-sip-inv-err : ont services pots sip invitation response error - ont-svc-pots-subs-refr: ont services pots iconfig subscription could not be refreshed - ont-svc-pots-not-refr : ont services pots iconfig notification could not be refreshed - ont-svc-pots-icfg-err : ont services pots service failed due to an unmapped iconfig error - ont-veip-mismatch : ont veip mismatch - ont-ip-host-mismatch : ont ip host mismatch - ont-ip-host-file : ont ip host file unavailable - ont-ip-host-ip-alloc : ont ip host IP allocation failure - olt-pon-up-bw-tca : OLT PON upstream bandwidth TCA - olt-pon-down-bw-tca : OLT PON downstream bandwidth TCA - ont-gen-omci-fail : loss of communication - ont-gen-eqpt-selftest : ont self-test failure - ont-gen-ac-pwr-fail : ac power failure on ont - ont-gen-bat-missing : battery missing - ont-gen-bat-low : battery low - ont-gen-bat-fail : battery failure - ont-gen-phys-intrusion: physical intrusion	

name	Type	Description
	- ont-gen-sw-dnload-f : ont sw download failure - ont-gen-sw-dnload-p : ont sw download in progress - ont-gen-sw-act-fail : ont sw activation failure - ont-gen-eqpt-vers-mis : ont equipment version mismatch - ont-gen-sw-vers-mis : ont sw version mismatch - ont-gen-us-rate-mis : ont upstream rate mismatch - ont-gen-mdu-env1 : mdu environmental alarm#1 - ont-gen-mdu-env2 : mdu environmental alarm#2 - ont-gen-mdu-env3 : mdu environmental alarm#3 - ont-gen-nw-time-err : network timing protocol error - ont-gen-opt-sig-high : optical signal level too high - ont-gen-opt-sig-low : optical signal level too low - ont-gen-eqpt-prov-sa : service affecting mismatch btw equipment and provisioning attributes - ont-gen-eqpt-prov-nsa : non service affecting mismatch btw equipment and provisioning attributes - pon-t-txmcutilhi : pon utilization tx (downstream) multicast high threshold crossed - pon-t-txmcutilmd : pon utilization tx (downstream) multicast medium threshold crossed - pon-t-txmcutillo : pon utilization tx (downstream) multicast low threshold crossed - pon-t-txtotutilhi : pon utilization tx (downstream) total high threshold crossed - pon-t-txtotutilmd : pon utilization tx (downstream) total medium threshold crossed - pon-t-txtotutillo : pon utilization tx (downstream) total low threshold crossed - pon-t-rxtotutilhi : pon utilization rx (upstream) total high threshold crossed - pon-t-rxtotutilmd : pon utilization rx (upstream) total medium threshold crossed - pon-t-rxtotutillo : pon utilization rx (upstream) total low threshold crossed - pon-t-dbacongperiodhi : pon utilization rx (upstream) dbacongperiod high threshold crossed - pon-t-dbacongperiodmd : pon utilization rx (upstream) dbacongperiod medium threshold crossed - pon-t-dbacongperiodlo : pon utilization rx (upstream) dbacongperiod low threshold crossed - pon-t-txucdropfrmhi : pon utilization tx (downstream) unicast drop frame high threshold crossed - pon-t-txucdropfrmmd : pon utilization tx (downstream) unicast drop frame medium threshold crossed - pon-t-txucdropfrmlo : pon utilization tx (downstream) unicast drop frame low threshold crossed - pon-t-txmcdropfrmhi : pon utilization tx (downstream) multicast drop frame high threshold crossed - pon-t-txmcdropfrmmd : pon utilization tx (downstream) multicast drop frame medium threshold crossed - pon-t-txmcdropfrmlo : pon utilization tx (downstream) multicast drop frame low threshold crossed - pon-t-txbcdropfrmhi : pon utilization tx (downstream) broadcast drop frame high threshold crossed - pon-t-txbcdropfrmmd : pon utilization tx (downstream) broadcast drop frame medium threshold crossed - pon-t-txbcdropfrmlo : pon utilization tx (downstream)	

101 query current alarms by filters

name	Type	Description
	broadcast drop frame low threshold crossed - pon-t-rxtotdropfrmhi : pon utilization rx (upstream) total drop frame high threshold crossed - pon-t-rxtotdropfrmmd : pon utilization rx (upstream) total drop frame medium threshold crossed - pon-t-rxtotdropfrmlo : pon utilization rx (upstream) total drop frame low threshold crossed - chpr-t-txmcutilhi : channel-pair utilization tx (downstream) multicast high threshold crossed - chpr-t-txmcutilmd : channel-pair utilization tx (downstream) multicast medium threshold crossed - chpr-t-txmcutillo : channel-pair utilization tx (downstream) multicast low threshold crossed - chpr-t-txtotutilhi : channel-pair utilization tx (downstream) total high threshold crossed - chpr-t-txtotutilmd : channel-pair utilization tx (downstream) total medium threshold crossed - chpr-t-txtotutillo : channel-pair utilization tx (downstream) total low threshold crossed - chpr-t-rxtotutilhi : channel-pair utilization rx (upstream) total high threshold crossed - chpr-t-rxtotutilmd : channel-pair utilization rx (upstream) total medium threshold crossed - chpr-t-rxtotutillo : channel-pair utilization rx (upstream) total low threshold crossed - chpr-t-dbacongperiodhi: channel-pair utilization rx (upstream) dbacongperiod high threshold crossed - chpr-t-dbacongperiodmd: channel-pair utilization rx (upstream) dbacongperiod medium threshold crossed - chpr-t-dbacongperiodlo: channel-pair utilization rx (upstream) dbacongperiod low threshold crossed - chpr-t-txucdropfrmhi : channel-pair utilization tx (downstream) unicast drop frame high threshold crossed - chpr-t-txucdropfrmmd : channel-pair utilization tx (downstream) unicast drop frame medium threshold crossed - chpr-t-txucdropfrmlo : channel-pair utilization tx (downstream) unicast drop frame low threshold crossed - chpr-t-txmcdropfrmhi : channel-pair utilization tx (downstream) multicast drop frame high threshold crossed - chpr-t-txmcdropfrmmd : channel-pair utilization tx (downstream) multicast drop frame medium threshold crossed - chpr-t-txmcdropfrmlo : channel-pair utilization tx (downstream) multicast drop frame low threshold crossed - chpr-t-txbcdropfrmhi : channel-pair utilization tx (downstream) broadcast drop frame high threshold crossed - chpr-t-txbcdropfrmmd : channel-pair utilization tx (downstream) broadcast drop frame medium threshold crossed - chpr-t-txbcdropfrmlo : channel-pair utilization tx (downstream) broadcast drop frame low threshold crossed - chpr-t-rxtotdropfrmhi : channel-pair utilization rx (upstream) total drop frame high threshold crossed - chpr-t-rxtotdropfrmmd : channel-pair utilization rx (upstream) total drop frame medium threshold crossed - chpr-t-rxtotdropfrmlo : channel-pair utilization rx (upstream) total drop frame low threshold crossed	

name	Type	Description
	- sfu-gen-omci-fail : SFU ONT - loss of communication - sfu-gen-eqpt-selftest : SFU ONT - ont self-test failure - sfu-gen-ac-pwr-fail : SFU ONT - ac power failure on ont - sfu-gen-bat-missing : SFU ONT - battery missing - sfu-gen-bat-low : SFU ONT - battery low - sfu-gen-bat-fail : SFU ONT - battery failure - sfu-gen-sw-dnload-f : SFU ONT - ont sw download failure - sfu-gen-sw-dnload-p : SFU ONT - ont sw download in progress - sfu-gen-sw-act-fail : SFU ONT - ont sw activation failure - sfu-gen-eqpt-vers-mis : SFU ONT - ont equipment version mismatch - sfu-gen-sw-vers-mis : SFU ONT - ont sw version mismatch - sfu-gen-us-rate-mis : SFU ONT - ont upstream rate mismatch - sfu-gen-tune-fail : SFU ONT - ont has failed to tune to Target-ChnlPair - sfu-gen-nw-time-err : SFU ONT - network timing protocol error - sfu-gen-opt-sig-high : SFU ONT - optical signal level too high - sfu-gen-opt-sig-low : SFU ONT - optical signal level too low - sfu-gen-eqpt-prov-sa : SFU ONT - service affecting mismatch btw equipment and provisioning attributes - sfu-gen-eqpt-prov-nsa : SFU ONT - non service affecting mismatch btw equipment and provisioning attributes - soho-gen-omci-fail : SOHO ONT - loss of communication - soho-gen-eqpt-selftest : SOHO ONT - ont self-test failure - soho-gen-ac-pwr-fail : SOHO ONT - ac power failure on ont - soho-gen-bat-missing : SOHO ONT - battery missing - soho-gen-bat-low : SOHO ONT - battery low - soho-gen-bat-fail : SOHO ONT - battery failure - soho-gen-sw-dnload-f : SOHO ONT - ont sw download failure - soho-gen-sw-dnload-p : SOHO ONT - ont sw download in progress - soho-gen-sw-act-fail : SOHO ONT - ont sw activation failure - soho-gen-eqpt-vers-mis : SOHO ONT - ont equipment version mismatch - soho-gen-sw-vers-mis : SOHO ONT - ont sw version mismatch - soho-gen-us-rate-mis : SOHO ONT - ont upstream rate mismatch - soho-gen-tune-fail : SOHO ONT - ont has failed to tune to Target-ChnlPair - soho-gen-nw-time-err : SOHO ONT - network timing protocol error - soho-gen-opt-sig-high : SOHO ONT - optical signal level too high - soho-gen-opt-sig-low : SOHO ONT - optical signal level too low - soho-gen-eqpt-prov-sa : SOHO ONT - service affecting mismatch btw equipment and provisioning attributes	

101 query current alarms by filters

name	Type	Description
	- soho-gen-eqpt-prov-nsa: SOHO ONT - non service affecting mismatch btw equipment and provisioning attributes - mdu-gen-omci-fail : MDU ONT - loss of communication - mdu-gen-eqpt-selftest : MDU ONT - ont self-test failure - mdu-gen-ac-pwr-fail : MDU ONT - ac power failure on ont - mdu-gen-bat-missing : MDU ONT - battery missing - mdu-gen-bat-low : MDU ONT - battery low - mdu-gen-bat-fail : MDU ONT - battery failure - mdu-gen-phys-intrusion: MDU ONT - physical intrusion - mdu-gen-sw-dnload-f : MDU ONT - ont sw download failure - mdu-gen-sw-dnload-p : MDU ONT - ont sw download in progress - mdu-gen-sw-act-fail : MDU ONT - ont sw activation failure - mdu-gen-eqpt-vers-mis : MDU ONT - ont equipment version mismatch - mdu-gen-sw-vers-mis : MDU ONT - ont sw version mismatch - mdu-gen-us-rate-mis : MDU ONT - ont upstream rate mismatch - mdu-gen-tune-fail : MDU ONT - ont has failed to tune to Target-ChnlPair - mdu-gen-mdu-env1 : MDU ONT - mdu environmental alarm#1 - mdu-gen-mdu-env2 : MDU ONT - mdu environmental alarm#2 - mdu-gen-mdu-env3 : MDU ONT - mdu environmental alarm#3 - mdu-gen-nw-time-err : MDU ONT - network timing protocol error - mdu-gen-opt-sig-high : MDU ONT - optical signal level too high - mdu-gen-opt-sig-low : MDU ONT - optical signal level too low - mdu-gen-eqpt-prov-sa : MDU ONT - service affecting mismatch btw equipment and provisioning attributes - mdu-gen-eqpt-prov-nsa : MDU ONT - non service affecting mismatch btw equipment and provisioning attributes - ont-gen-sw-dnload-file: ont sw download file missing - ont-gen-fan-fail : ont fan failure - ont-gen-high-temp : ont high temperature - ont-gen-high-temp-ex : ont excessive high temperature - ont-gen-emergency-call: ont emergency call - ont-gen-sw-version : ont sw version control error - ont-poe-exceed-max : ont poe exceed max - ont-poe-overload-yell : ONU is nearing its maximum ability to supply the power - ont-opti-malfunc : malfunction of ONT's optical transceiver - ont-gen-cfgdld-fail : download of voice xml file to ont failed - ont-gen-rssi-mis : ONU RSSI configuration mismatch - ont-gen-tx-pwr-low : ONU SFP Tx Power is lower than	

name	Type	Description
	configured Alarm low threshold - ont-gen-temp-high : ONU SFP Temperature is higher than configured Alarm high threshold - ont-gen-volt-high : ONU SFP Voltage is higher than configured Alarm high threshold - ont-gen-bias-high : ONU SFP Bias is higher than configured Alarm high threshold - ont-loopdetect-mis : ont loop detect mismatch - ont-olt-rx-pw-lo : olt side receive power from ont low - ont-olt-rx-pw-hig : olt side receive power from ont high - ont-olt-rx-pw-warnlo : olt side receive power from ont low warning - ont-olt-rx-pw-warnhig : olt side receive power from ont high warning - ont-gen-tod-out-sync : ONU TOD is out-sync with OLT - ont-gen-tune-fail : ONU has failed to tune to Target-ChnlPair - hgu-tr069-param-fail : hgu tr069 parameters mismatch - ont-gen-tod-mismatch : ONU TOD MISMATCH - sfu-sup-sw-file-error : SFU ONT - Software file has error or is missing - sfu-sup-fan-failure : SFU ONT - Fan failure - sfu-sup-temp-high-warn: SFU ONT - High temperature warning - sfu-sup-temp-shutoff : SFU ONT - Service disabled due to excessive temperature - sfu-sup-emergency-call: SFU ONT - Emergency call active - sfu-sup-swverctrl-err : SFU ONT - Software version control error - sfu-sup-poe-exceed-max: SFU ONT - Configured PoE feeding exceeds ONT maximum - sfu-sup-poe-over-yell : SFU ONT - ONU is nearing its maximum ability to supply the power - sfu-opti-malfunc : SFU ONT - Malfunction of ONT's optical transceiver - sfu-sup-cfg-dnld-fail : SFU ONT - Download of voice xml file to ONT failed - sfu-sup-rssi-cfg-mism : SFU ONT - RSSI configuration mismatch - sfu-sup-sfp-tx-low : SFU ONT - SFP Tx Power below configured low-level alarm threshold - sfu-sup-sfp-temp-high : SFU ONT - SFP Temperature above configured high-level alarm threshold - sfu-sup-sfp-volt-high : SFU ONT - SFP Voltage above configured high-level alarm threshold - sfu-sup-sfp-bias-high : SFU ONT - SFP Bias above configured high-level alarm threshold - sfu-sup-ld-cfg-mism : SFU ONT - Loop detection configuration mismatch - sfu-sup-olt-rx-low : SFU ONT - OLT Rx power below receiver operating range - sfu-sup-olt-rx-high : SFU ONT - OLT Rx power above receiver operating range - sfu-sup-olt-rx-lo-warn: SFU ONT - OLT Rx power below low-level warning threshold - sfu-sup-olt-rx-hi-warn: SFU ONT - OLT Rx power above high-level warning threshold	

101 query current alarms by filters

name	Type	Description
	- sfu-sup-tod-out-sync : SFU ONT - ONU TOD is out-sync with OLT - sfu-sup-ont-tune-fail : SFU ONT - ONU has failed to tune to Target-ChnlPair - sfu-tr069-param-fail : SFU ONT - hgu tr069 parameters mismatch - sfu-sup-tod-mismatch : SFU ONT - ONU TOD MISMATCH - soho-sup-sw-file-error: SOHO ONT - Software file has error or is missing - soho-sup-fan-failure : SOHO ONT - Fan failure - soho-sup-temp-high-war: SOHO ONT - High temperature warning - soho-sup-temp-shutoff : SOHO ONT - Service disabled due to excessive temperature - soho-sup-emergency-cal: SOHO ONT - Emergency call active - soho-sup-swverctrl-err: SOHO ONT - Software version control error - soho-sup-poe-exceed-ma: SOHO ONT - Configured PoE feeding exceeds ONT maximum - soho-sup-poe-over-yell: SOHO ONT - ONU is nearing its maximum ability to supply the power - soho-opti-malfunc : SOHO ONT - Malfunction of ONT's optical transceiver - soho-sup-cfg-dnld-fail: SOHO ONT - Download of voice xml file to ONT failed - soho-sup-rssi-cfg-mism: SOHO ONT - RSSI configuration mismatch - soho-sup-sfp-tx-low : SOHO ONT - SFP Tx Power below configured low-level alarm threshold - soho-sup-sfp-temp-high: SOHO ONT - SFP Temperature above configured high-level alarm threshold - soho-sup-sfp-volt-high: SOHO ONT - SFP Voltage above configured high-level alarm threshold - soho-sup-sfp-bias-high: SOHO ONT - SFP Bias above configured high-level alarm threshold - soho-sup-ld-cfg-mism : SOHO ONT - Loop detection configuration mismatch - soho-sup-olt-rx-low : SOHO ONT - OLT Rx power below receiver operating range - soho-sup-olt-rx-high : SOHO ONT - OLT Rx power above receiver operating range - soho-sup-olt-rx-lo-war: SOHO ONT - OLT Rx power below low-level warning threshold - soho-sup-olt-rx-hi-war: SOHO ONT - OLT Rx power above high-level warning threshold - soho-sup-tod-out-sync : SOHO ONT - ONU TOD is out-sync with OLT - soho-sup-ont-tune-fail: SOHO ONT - ONU has failed to tune to Target-ChnlPair - soho-tr069-param-fail : SOHO ONT - hgu tr069 parameters mismatch - soho-sup-tod-mismatch : SOHO ONT - ONU TOD MISMATCH - mdu-sup-sw-file-error : MDU ONT - Software file has error or is missing	

name	Type	Description
	- mdu-sup-fan-failure : MDU ONT - Fan failure - mdu-sup-temp-high-warn: MDU ONT - High temperature warning - mdu-sup-temp-shutoff : MDU ONT - Service disabled due to excessive temperature - mdu-sup-emergency-call: MDU ONT - Emergency call active - mdu-sup-swverctrl-err : MDU ONT - Software version control error - mdu-sup-poe-exceed-max: MDU ONT - Configured PoE feeding exceeds ONT maximum - mdu-sup-poe-over-yell : MDU ONT - ONU is nearing its maximum ability to supply the power - mdu-opti-malfunc : MDU ONT - Malfunction of ONT's optical transceiver - mdu-sup-cfg-dnld-fail : MDU ONT - Download of voice xml file to ONT failed - mdu-sup-rssi-cfg-mism : MDU ONT - RSSI configuration mismatch - mdu-sup-sfp-tx-low : MDU ONT - SFP Tx Power below configured low-level alarm threshold - mdu-sup-sfp-temp-high : MDU ONT - SFP Temperature above configured high-level alarm threshold - mdu-sup-sfp-volt-high : MDU ONT - SFP Voltage above configured high-level alarm threshold - mdu-sup-sfp-bias-high : MDU ONT - SFP Bias above configured high-level alarm threshold - mdu-sup-ld-cfg-mism : MDU ONT - Loop detection configuration mismatch - mdu-sup-olt-rx-low : MDU ONT - OLT Rx power below receiver operating range - mdu-sup-olt-rx-high : MDU ONT - OLT Rx power above receiver operating range - mdu-sup-olt-rx-lo-warn: MDU ONT - OLT Rx power below low-level warning threshold - mdu-sup-olt-rx-hi-warn: MDU ONT - OLT Rx power above high-level warning threshold - mdu-sup-tod-out-sync : MDU ONT - ONU TOD is out-sync with OLT - mdu-sup-ont-tune-fail : MDU ONT - ONU has failed to tune to Target-ChnlPair - mdu-tr069-parm-fail : MDU ONT - hgu tr069 parameters mismatch - mdu-sup-tod-mismatch : MDU ONT - ONU TOD MISMATCH - ont-sbscr-lim-missing : provisioned ont card missing - ont-sbscr-lim-type-mis: wrong type plug-in ont card - ont-sbscr-lim-removal : improper removal ont card - ont-sbscr-lim-fail : ont card failure - ont-sbscr-lim-svc-mis : ont service mismatch for provisioned onu card - ont-sbscr-lim-port-mis: port mismatch btw actual and planned ont card - ont-svc-video-conf-mis: config request failure for video service - ont-svc-video-pw-high : high power level for rf video signal	

101 query current alarms by filters

name	Type	Description
	- ont-svc-video-pw-low : low power level for rf video signal - ont-svc-pots-svc-mis : ont service mismatch for provisioned pots - ont-svc-pots-rtcp-lost: pots realtime transport control protocol stream lost - ont-svc-pots-icnf-subs: pots line iconfig subscription failure - ont-svc-pots-icnf-ntfy: pots line iconfig notify failure - ont-svc-pots-icnf-http: pots line iconfig http failure - ont-svc-pots-sip-reg : pots line sip registration failure - ont-svc-pots-sip-inv : pots line sip invite request failure - ont-svc-pots-sip-subsc: pots line sip subscribe failure - ont-svc-pots-sip-mt-tc: pots line sip message timeout threshold crossed - ont-svc-pots-pk-los-tc: pots line rtp bearer packets loss threshold crossed - ont-svc-pots-jitter-tc: pots line rtp jitter threshold crossed - ont-svc-pots-subs-dns : pots line iconfig subscription failed (DNS) - ont-svc-pots-subs-tcp : pots line iconfig subscription failed (TCP) - ont-svc-pots-subs-tls : pots line iconfig subscription failed (TLS) - ont-svc-pots-subs-auth: pots line iconfig subscription failed authentication - ont-svc-pots-subs-to : pots line iconfig subscription failed (timeout) - ont-svc-pots-subs-err : pots line iconfig subscription response error - ont-svc-pots-not-to : pots line iconfig notification failed (timeout) - ont-svc-pots-notref-to: pots line iconfig notification refresh failed - ont-svc-pots-not-mal : pots line iconfig notification failed (malformed) - ont-svc-pots-not-rej : pots line iconfig notification rejected - ont-svc-pots-http-dns : pots line iconfig doc retrieval failed (DNS) - ont-svc-pots-http-tcp : pots line iconfig doc retrieval failed (TCP) - ont-svc-pots-http-tls : pots line iconfig doc retrieval failed (TLS) - ont-svc-pots-http-auth: pots line iconfig doc retrieval failed (authentication) - ont-svc-pots-http-to : pots line iconfig doc retrieval failed (timeout) - ont-svc-pots-http-err : pots line iconfig doc retrieval response error - ont-svc-pots-http-mal : pots line iconfig doc retrieval failed (malformed) - ont-svc-pots-insuff : pots line iconfig service failed (insufficient data) - ont-svc-pots-poos : pots ports out of service - ont-svc-lan-mismatch : ont service mismatch for lan - ont-svc-lan-loss-sig : loss of signal on an ethernet port interface - ont-svc-enet-poos : Ethernet Ports out of Service	

name	Type	Description
	- ont-svc-ces-ds1-mis : ont service mismatch for provisioned ces ds1 - ont-svc-ces-ds1-los : loss of signal at ds1 interface - ont-svc-ces-ds1-lof : loss of frame at ds1 interface - ont-svc-ces-ds1-rair : receiving rai at ds1 interface - ont-svc-ces-ds1-ais : receiving ais at ds1 interface - ont-svc-ces-ds1-lnlpbk: receiving line loopback at ds1 interface - ont-svc-ces-ds1-tmlpbk: receiving terminal loopback at ds1 interface - ont-svc-ces-e1-mis : ont service mismatch for provisioned ces e1 - ont-svc-ces-e1-los : loss of signal at e1 interface - ont-svc-ces-e1-lof : loss of frame at e1 interface - ont-svc-ces-e1-rair : receiving rai at e1 interface - ont-svc-ces-e1-ais : receiving ais at e1 interface - ont-svc-voip-cnf-file : voice configuration file error - ont-svc-voip-svc-mis : service mismatch for provisioned client service - ont-svc-voip-gw-comm : voice gateway communication failure - ont-svc-voip-dhcp-fail: voice dhcp server failure - ont-svc-voip-icnf-subst: voice iconfig subscription failure - ont-svc-voip-icnf-ntfy: voice iconfig notify failure - ont-svc-voip-icnf-http: voice iconfig http failure - ont-svc-voip-dhcp-to : DHCP server retransmissions timed out - ont-svc-voip-dhcp-mal : DHCP response was malformed - ont-svc-voip-dhcp-noad: DHCP server failed to issue the required parameters - ont-svc-voip-dhcp-leas: DHCP Server failure due to problem in lease renewal - ont-svc-voip-subst-dns : iConfig Subscription failure due to DNS problem - ont-svc-voip-subst-tcp : iConfig Subscription failure due to TCP socket problem - ont-svc-voip-subst-tls : iConfig Subscription failure due to TLS session problem - ont-svc-voip-subst-auth: iConfig Subscription failure due to authentication error - ont-svc-voip-subst-to : iConfig Subscription failure due to retransmission timeout - ont-svc-voip-subst-err : iConfig Subscription failure due to response error - ont-svc-voip-not-to : iConfig Notify response timeout for new subscription - ont-svc-voip-notref-to: iConfig Notify response timeout for subscription refresh - ont-svc-voip-not-mal : iConfig Notify response is malformed - ont-svc-voip-not-rej : iConfig subscription request rejected by configuration server - ont-svc-voip-http-dns : VOIP client can't retrieve config doc due to DNS problem - ont-svc-voip-http-tcp : VOIP client can't retrieve config doc due to TCP socket problem - ont-svc-voip-http-tls : VOIP client can't retrieve config doc	

101 query current alarms by filters

name	Type	Description
	due to TLS session problem - ont-svc-voip-http-auth: VOIP client can't retrieve config doc due to auth error - ont-svc-voip-http-to : VOIP client can't retrieve config doc due to re-tx timeout - ont-svc-voip-http-err : VOIP client can't retrieve config doc due to response error - ont-svc-voip-http-mal : iConfig configuration document is malformed - ont-svc-voip-subscr-refr: iConfig Subscription refresh error - ont-svc-voip-not-refr : iConfig Notify response for refresh subscribe failed - ont-svc-voip-icfg-err : iConfig Configuration Error - ont-svc-v-ani-conf-mis: config request failure for video ani service - ont-svc-v-ani-loss-sig: video loss of signal on ani - ont-svc-v-ani-lv-high : high video optical signal level - ont-svc-v-ani-lv-low : low video optical signal level - ont-svc-pwe-mismatch : service mismatch for provisioned pseudowire - ont-svc-pwe-reordr-lof: pseudowire reordering and loss of frame - ont-svc-pwe-jitt-buf-o: pseudowire jitter buffer overrun - ont-svc-pwe-jitt-buf-u: pseudowire jitter buffer underrun - ont-svc-pwe-malf-frms : pseudowire malformed frames - ont-svc-pwe-late-frms : pseudowire late frames - ont-svc-pwe-link-loss : pseudowire link loss - ont-svc-pwe-arp-fail : pseudowire arp failure - ont-svc-xdsl-mismatch : service mismatch for provisioned xdsl - ont-svc-xdsl-ne-lof : near end loss of frame - ont-svc-xdsl-ne-los : near end loss of signal - ont-svc-xdsl-ne-line : near end line init - ont-svc-xdsl-ne-lol : near end loss of link - ont-svc-xdsl-fe-lof : far end loss of frame - ont-svc-xdsl-fe-los : far end loss of signal - ont-svc-xdsl-fe-lop : far end loss of power - ont-svc-xdsl-cnfr-err : xdsl provisioning error - ont-svc-xdsl-ne-es-tc : near end errored seconds threshold crossed - ont-svc-xdsl-ne-ses-tc: near end severe errored seconds threshold crossed - ont-svc-xdsl-ne-uas-tc: ear end unavailable seconds threshold crossed - ont-svc-xdsl-fe-es-tc : far end errored seconds threshold crossed - ont-svc-xdsl-fe-ses-tc: far end severe errored seconds threshold crossed - ont-svc-xdsl-fe-uas-tc: far end unavailable seconds threshold crossed - ont-tc-rx-los-frag-tc : rx loss of gem fragments threshold crossed - ont-tc-tx-los-frag-tc : tx loss of gem fragments threshold crossed - ont-tc-bad-gem-hd-tc : bad gem header threshold crossed - ont-uni-ds-drpdr-fr-tc : downstream l2 dropped frames threshold crossed	

name	Type	Description
	- ont-uni-up-drpdc-fr-tc : upstream l2 dropped frames threshold crossed - ont-uni-ds-crc-fr-tc : downstream l2 rx crc error frames threshold crossed - ont-uni-up-crc-fr-tc : upstream l2 rx crc error frames threshold crossed - ont-cpu-util-tca : ONT CPU utilization threshold crossed - ont-mem-util-tca : ONT memory utilization threshold crossed - pim-neighbor-down : pim neighbor down - pim-max-mcroutes : maximum routes reached - li-traffic-disabled : lawful interception of traffic disabled - li-bandwidth-limit : lawful intercept reached bandwidth limit - li-out-of-res : lawful intercept out of resources - otdr-cap-mismatch : otdr capability mismatch - login-successful : successful login via management access - login-failure : invalid login via management access has crossed the threshold limit - cfm-defrdiccm : rdi bit in ccm received - cfm-defmacstatus : ccm mac error status - cfm-defremoteccm : missing ccm from mep - cfm-deferrorccm : invalid ccm received - cfm-defxconccm : unexpected ccm received - cfm-defais : ethernet ais received - bfd-session-down : bfd session down - bfd-max-resource : bfd maximum resources reached - bfd-stale-entry : bfd stale entry present - tca-outputbw : tca output bandwidth - tca-inputbw : tca input bandwidth - tca-rxcrcalign : tca rxcrc align errors - tca-txcrcalign : tca txcrc align errors - tca-txcollisions : tca tx collision errors - tca-outputhighbw : tca output high bandwidth - tca-outputmedbw : tca output medium bandwidth - tca-outputlowbw : tca output low bandwidth - tca-inputhighbw : tca input high bandwidth - tca-inputmediumbw : tca input medium bandwidth - tca-inputlowbw : tca input low bandwidth - eth-cfm-defrdiccm : rdi bit in ccm received - eth-cfm-defmacstatus : ccm mac error status - eth-cfm-defremoteccm : missing ccm from mep - eth-cfm-deferrorccm : invalid ccm received - eth-cfm-defxconccm : unexpected ccm received - rsvp-neighbor-down : rsvp neighbor down - rsvp-instance-down : rsvp instance down - eth-ring-path-block : eth ring path block - ai-platform-down : Application Intelligence Platform down - ai-appl-install-fail : Application installation failure - ip-assign-fail : Dhcp assigned address failure - ont-tr069-serv-mis : ont tr069 server config mismatch - ont-snmp-mis : ont snmp agent config mismatch - bsf-dhcpv4 : bulksync failed for dhcpv4 - bsf-dhcpv6 : bulksync failed for dhcpv6 - bsf-pon : bulksync failed for pon - bsf-vbridge : bulksync failed for vlan-bridge - bsf-qos : bulksync failed for qos	

101 query current alarms by filters

name	Type	Description
	- bsf-igmp : bulksync failed for igmp - bsf-lxfwd : bulksync failed for lxfwd - prot-not-available : no protection not available - prot-switchover-fail : port switch over failed - efm-oam-cpelinkfault : EFM-OAM CPE link fault - efm-oam-cpedyinggasp : EFM-OAM CPE dying gasp - efm-oam-cpecrevt : EFM-OAM CPE critical event - ont-loopdetect : ont loop detect - alarm-tbl-overflow : alarm table has overflowed - auto-switch-status : auto-switch status - auswqueuefullatm : auto-switch queue Full for ATM - auswbkpfailatm : auto-switch config data backup failed for ATM - auswrecfgfailatm : auto-switch fallback reconfiguration failed for ATM - auswdataunatm : auto-switch backup config data unavailable for ATM - auswqueuefulptm : auto-switch queue Full for PTM - auswbkpfailptm : auto-switch config data backup failed for PTM - auswrecfgfailptm : auto-switch fallback reconfiguration failed for PTM - auswdataunptm : auto-switch backup config data unavailable for PTM - auswbakpfailatm : auto-switch backup fail for ATM - chpr-com-fail : channel pair communication failure on olt - chpr-tx-fail : transmitter failure on channel pair - chpr-unprov-ont : unprovisioned ont on channel pair - chpr-prov-mismatch : mismatch btw equipment and provisioning pon attributes - chpr-loss-sig : channel pair loss of signal - chpr-diagnostic : channel pair diagnostic test active - chpr-loid-conflict : loid conflict ont on channel pair - chpr-loid-pwd-err : loid password error ont on channel pair - chpr-stk-laser-dis : stuck laser disabled on channel pair - chpr-sfp-mismatch : channel pair sfp mismatch - chpr-rng-mismatch : channel pair ranging mismatch - chpr-alien-test : channel pair alien diagnostic test active - chpr-alien-detect : channel pair alien detect active - chpr-deact-hightca : channel pair deactivated ont hightca threshold crossed - chpr-deact-lowtca : channel pair deactivated ont lowtca threshold crossed - chpr-dp-integ : channel pair data path integrity failure - olt-chpr-tc-err-frag : channelpair errored fragments threshold crossed - olt-chpr-up-bw-tca : OLT CHANNELPAIR upstream bandwidth TCA - olt-chpr-down-bw-tca : OLT CHANNELPAIR downstream bandwidth TCA - cfg-dld-fail : download of configure file to ont failed - cfg-act-fail : activate the passive config file failed - cfg-dld-ip : ont configure file download in progress - cfg-ver-mismatch : the planned configure file does not match the active configure file - cfg-file-missing : ont configure file missing or has an error - cfg-verctrl-err : ont configure file version control error	

name	Type	Description
	- cfg-not-supported : ont not support the configure file download function - ont-prot-not-available: ONT/ONU protection not available - ont-gen-temp-low : ONU SFP temperature is lower than configured Alarm low threshold - ont-gen-volt-low : ONU SFP Voltage is lower than configured Alarm low threshold - ont-gen-tx-pwr-high : ONU SFP Tx power is higher than configured Alarm high threshold - ont-gen-bias-low : ONU SFP bias is lower than configured Alarm low threshold - ont-gen-rx-hwarn : ONU SFP Rx power is higher than warn threshold - ont-gen-rx-lwarn : ONU SFP Rx power is lower than warn threshold - ont-gen-tx-hwarn : ONU SFP Tx power is higher than warn threshold - ont-gen-tx-lwarn : ONU SFP Tx power is lower than warn threshold - ont-gen-temp-hwarn : ONU SFP temperature is higher than warn threshold - ont-gen-temp-lwarn : ONU SFP temperature is lower than warn threshold - ont-gen-volt-hwarn : ONU SFP Voltage is higher than warn threshold - ont-gen-volt-lwarn : ONU SFP Voltage is lower than warn threshold - ont-gen-bias-hwarn : ONU SFP bias is higher than warn threshold - ont-gen-bias-lwarn : ONU SFP bias is lower than warn threshold - sfu-sup2-temp-low : SFU ONT - SFP temperature is lower than configured Alarm low threshold - sfu-sup2-volt-low : SFU ONT - SFP Voltage is lower than configured Alarm low threshold - sfu-sup2-tx-high : SFU ONT - SFP tx power is higher than configured Alarm high threshold - sfu-sup2-bias-low : SFU ONT - SFP bias is lower than configured Alarm low threshold - sfu-sup2-rx-hwarn : SFU ONT - SFP rx power is higher than configured warn threshold - sfu-sup2-rx-lwarn : SFU ONT - SFP rx power is lower than configured warn threshold - sfu-sup2-tx-hwarn : SFU ONT - SFP tx power is higher than configured warn threshold - sfu-sup2-tx-lwarn : SFU ONT - SFP tx power is lower than configured warn threshold - sfu-sup2-temp-hwarn : SFU ONT - SFP temperature is higher than configured warn threshold - sfu-sup2-temp-lwarn : SFU ONT - SFP temperature is lower than configured warn threshold - sfu-sup2-volt-hwarn : SFU ONT - SFP Voltage is higher than configured warn threshold - sfu-sup2-volt-lwarn : SFU ONT - SFP Voltage is lower than configured warn threshold - sfu-sup2-bias-hwarn : SFU ONT - SFP bias is higher than configured warn threshold	

101 query current alarms by filters

name	Type	Description
	- sfu-sup2-bias-lwarn : SFU ONT - SFP bias is lower than configured warn threshold - soho-sup2-temp-low : SOHO ONT - SFP temperature is lower than configured Alarm low threshold - soho-sup2-volt-low : SOHO ONT - SFP Voltage is lower than configured Alarm low threshold - soho-sup2-tx-high : SOHO ONT - SFP tx power is higher than configured Alarm low threshold - soho-sup2-bias-low : SOHO ONT - SFP bias is lower than configured Alarm low threshold - soho-sup2-rx-hwarn : SOHO ONT - SFP rx power is higher than warn threshold - soho-sup2-rx-lwarn : SOHO ONT - SFP rx power is lower than warn threshold - soho-sup2-tx-hwarn : SOHO ONT - SFP tx power is higher than warn threshold - soho-sup2-tx-lwarn : SOHO ONT - SFP tx power is lower than warn threshold - soho-sup2-temp-hwarn : SOHO ONT - SFP temperature is higher than warn threshold - soho-sup2-temp-lwarn : SOHO ONT - SFP temperature is lower than warn threshold - soho-sup2-volt-hwarn : SOHO ONT - SFP Voltage is higher than warn threshold - soho-sup2-volt-lwarn : SOHO ONT - SFP Voltage is lower than warn threshold - soho-sup2-bias-hwarn : SOHO ONT - SFP bias is higher than warn threshold - soho-sup2-bias-lwarn : SOHO ONT - SFP bias is lower than warn threshold - mdu-sup2-temp-low : MDU ONT - SFP temperature is lower than configured alarm low threshold - mdu-sup2-volt-low : MDU ONT - SFP Voltage is lower than configured alarm low threshold - mdu-sup2-tx-high : MDU ONT - SFP tx power is higher than configured alarm low threshold - mdu-sup2-bias-low : MDU ONT - SFP bias is lower than configured alarm low threshold - mdu-sup2-rx-hwarn : MDU ONT - SFP rx power is higher than warn threshold - mdu-sup2-rx-lwarn : MDU ONT - SFP rx power is lower than warn threshold - mdu-sup2-tx-hwarn : MDU ONT - SFP tx power is higher than warn threshold - mdu-sup2-tx-lwarn : MDU ONT - SFP tx power is lower than warn threshold - mdu-sup2-temp-hwarn : MDU ONT - SFP temperature is higher than warn threshold - mdu-sup2-temp-lwarn : MDU ONT - SFP temperature is lower than warn threshold - mdu-sup2-volt-hwarn : MDU ONT - SFP voltage is higher than warn threshold - mdu-sup2-volt-lwarn : MDU ONT - SFP voltage is lower than warn threshold - mdu-sup2-bias-hwarn : MDU ONT - SFP bias is higher than warn threshold - mdu-sup2-bias-lwarn : MDU ONT - SFP bias is lower than	

name	Type	Description
	warn threshold - cust-alm1 : customizable alarm 1 - cust-alm2 : customizable alarm 2 - cust-alm3 : customizable alarm 3 - cust-alm4 : customizable alarm 4 - cust-alm5 : customizable alarm 5 - cust-alm6 : customizable alarm 6 - cust-alm7 : customizable alarm 7 - cust-alm8 : customizable alarm 8 - cust-alm9 : customizable alarm 9 - cust-alm10 : customizable alarm 10 - cust-alm11 : customizable alarm 11 - cust-alm12 : customizable alarm 12 - cust-alm13 : customizable alarm 13 - cust-alm14 : customizable alarm 14 - cust-alm15 : customizable alarm 15 - cust-alm16 : customizable alarm 16 - cust-alm17 : customizable alarm 17 - cust-alm18 : customizable alarm 18 - cust-alm19 : customizable alarm 19 - cust-alm20 : customizable alarm 20 - cust-alm21 : customizable alarm 21 - cust-alm22 : customizable alarm 22 - cust-alm23 : customizable alarm 23 - cust-alm24 : customizable alarm 24 - cust-alm25 : customizable alarm 25 - cust-alm26 : customizable alarm 26 - cust-alm27 : customizable alarm 27 - cust-alm28 : customizable alarm 28 - cust-alm29 : customizable alarm 29 - cust-alm30 : customizable alarm 30 - cust-alm31 : customizable alarm 31 - ethernet-ring-pthfwst : ethernet ring path forward state - ethernet-ring-fop-to : ethernet ring fop-to failure of protocol timeout - ethernet-ring-fop-pm : ethernet ring fop-pm failure of protocol provision mismatch - fpm-depletion : failsafe fpm depletion - exp-seizureack : Channel was blocked due to failure in the reception of the SEIZURE ACK signal - exp-disconack : Channel was blocked due to failure in the reception of the DISCONNECTION ACK signal - exp-forcerelack : Channel was blocked due to failure in the reception of the BACKWARD DISCONNECTION ACK signal - packet-loss : Pseudo Wire entered the Packet loss state - remote-packet-loss : Remote Packet loss detected - no-dsp-resource : DSP resource allocation failed - la-down : Link aggregation group link-status is down - la-standby-na : Cross-lt lag on standby slot part is not available - la-switch-fail : Cross-lt lag fail to do switchover - la-degrade : Link aggregation group degrade - melt-board-reset : MELT board reset - board-shelf-mismatch : board type and shelf type mismatch - fcs-thresh-exceed : FCS counter threshold exceeded	
severity	Parameter type: <Alarm::AlarmSeverity>	the alarms severity level

101 query current alarms by filters

name	Type	Description
	(indeterminate warning minor major critical) Possible values: - indeterminate : alarm severity is indeterminate - warning : alarm severity is warning - minor : alarm severity is minor - major : alarm severity is major - critical : alarm severity is critical	<i>This element is only shown in detail mode.</i>
servaff	Parameter type: <Alarm::alarmServAffect> ((service-affecting yes) (noservice-affecting no)) Possible values: - service-affecting : make this alarm service affecting - yes : make this alarm service affecting - noservice-affecting : make this alarm not service affecting - no : make this alarm not service affecting	alarms affect service or not <i>This element is only shown in detail mode.</i>
location	Parameter type: <Alarm::almLocation> (near-end far-end middle-end line null) Possible values: - near-end : alarm location is near - far-end : alarm location is far - middle-end : alarm location is middle - line : alarm location is line - null : alarm location not defined	alarm location: near, middle, far <i>This element is only shown in detail mode.</i>
time	Parameter type: <Sys::timeInSecs> - the time (yyyy-mm-dd:hour:minutes:secs) - unit: UTC	time in seconds when alarm was updated <i>This element is only shown in detail mode.</i>
direction	Parameter type: <Alarm::almDirection> (received transmit null) Possible values: - received : alarm is received - transmit : alarm is transmit - null : direction not defined	alarm direction: received or transmit <i>This element is only shown in detail mode.</i>
descript	Parameter type: <Alarm::AddInfoString> - additional alarm information	alarm description <i>This element is only shown in detail mode.</i>

101.141 show current alarm by filters

Command Description

show current alarms by filters

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm query hgu-tr069 [ (name) [ severity <Alarm::querySeverity> ] [ servaff <Alarm::queryServAffect> ]  
[ ont <Gpon::OntIndex> ] ]
```

Command Parameters

Table 101.141-1 "show current alarm by filters" Resource Parameters

Resource Identifier	Type	Description
(name)	Format: (cust-alm1 cust-alm2 cust-alm3 cust-alm4 cust-alm5 cust-alm6 cust-alm7 cust-alm8 cust-alm9 cust-alm10 cust-alm11 cust-alm12 cust-alm13 cust-alm14 cust-alm15 cust-alm16 cust-alm17 cust-alm18 cust-alm19 cust-alm20 cust-alm21 cust-alm22 cust-alm23 cust-alm24 cust-alm25 cust-alm26 cust-alm27	alarm name of hgu-tr069

101 query current alarms by filters

Resource Identifier	Type	Description
	cust-alm28 cust-alm29 cust-alm30 cust-alm31 all) Possible values: - cust-alm1 : customizable alarm 1 - cust-alm2 : customizable alarm 2 - cust-alm3 : customizable alarm 3 - cust-alm4 : customizable alarm 4 - cust-alm5 : customizable alarm 5 - cust-alm6 : customizable alarm 6 - cust-alm7 : customizable alarm 7 - cust-alm8 : customizable alarm 8 - cust-alm9 : customizable alarm 9 - cust-alm10 : customizable alarm 10 - cust-alm11 : customizable alarm 11 - cust-alm12 : customizable alarm 12 - cust-alm13 : customizable alarm 13 - cust-alm14 : customizable alarm 14 - cust-alm15 : customizable alarm 15 - cust-alm16 : customizable alarm 16 - cust-alm17 : customizable alarm 17 - cust-alm18 : customizable alarm 18 - cust-alm19 : customizable alarm 19 - cust-alm20 : customizable alarm 20 - cust-alm21 : customizable alarm 21 - cust-alm22 : customizable alarm 22 - cust-alm23 : customizable alarm 23 - cust-alm24 : customizable alarm 24 - cust-alm25 : customizable alarm 25 - cust-alm26 : customizable alarm 26 - cust-alm27 : customizable alarm 27 - cust-alm28 : customizable alarm 28 - cust-alm29 : customizable alarm 29 - cust-alm30 : customizable alarm 30 - cust-alm31 : customizable alarm 31 - all : hgu tr069 related alarms	
severity	Parameter type: <Alarm::querySeverity> Format: (indeterminate warning minor major critical all) Possible values: - indeterminate : alarm severity is indeterminate - warning : alarm severity is warning - minor : alarm severity is minor - major : alarm severity is major - critical : alarm severity is critical - all : all alarm severity	severity level of an alarm for reporting
servaff	Parameter type: <Alarm::queryServAffect> Format: (service-affecting noservice-affecting	serviceaffecting no

Resource Identifier	Type	Description
	all) Possible values: - service-affecting : query alarm service affecting - noservice-affecting : query alarm not service affecting - all : query service affecting and not affecting alarms	
ont	Parameter type: <Gpon::OntIndex> Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> ng2 : <Ng2::ChannelGroup> / <Ng2::SubchannelGroup> / <Ng2::OntId>) Possible values: - ng2 : ngpon2 style identification Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Ng2::ChannelGroup> - channel group number Field type <Ng2::SubchannelGroup> - subchannel group number Field type <Eqpt::OntId> - the ONT identifier Field type <Ng2::OntId> - the ONT identifier	identifies the ont entry

Command Output

Table 101.141-2 "show current alarm by filters" Display parameters

Specific Information		
name	Type	Description
aidinfo	Parameter type: <Alarm::AddInfoString> - additional alarm information	alarm AID parameters <i>This element is only shown in detail mode.</i>
type	Parameter type: <Alarm::alarmIHUBType> (equipment eqpt-holder plug-in-unit atm custom e1 ima-group ima-link redundancy shdsl ether-itf traffic-overflow qos-queue temporal spatial (software-mngt sw-mgmt) xdsl	type of the alarms that are active <i>This element is only shown in detail mode.</i>

101 query current alarms by filters

name	Type	Description
	xds1-ext xds1-tca olt-gen eo-conv authentication bonding sfp shdsl-isam custom-ext-alarm plug-in-unit-ext sip-user-agent sip-plugin-unit sip-termination e1-sip-termination filetransfer external-device l2forward ether-tca ether-sfp megaco-media-gw megaco-sig-gw megaco-plug-unit megaco-term megaco-sig-lt eqpt-supplemental eqpt-holder-ext lsmredundancy sync mcsrc vlanport vect-line vect-board otdr sip-dial-plan sip-vsp sip-server bgp rip lag ihub-general vprn isis ospf ihub-l2forward vpls ihub-equip ihub-link eont-phyoam ellid epon eont-services-lan eolt-ont-tca eont-sw-dl ldp mpls sdp epipe	

name	Type	Description
	ihub-ipv6	
	pim	
	li	
	mgmt-sec-access	
	bfd	
	ai	
	tr069serv	
	ontsnmp	
	bulk-sync	
	protection-group	
	ont	
	sfu-sup	
	soho-sup	
	mdu-sup	
	ont-ani	
	sfu-sup2	
	soho-sup2	
	mdu-sup2	
	sfprssi	
	eoltrssi	
	cfm	
	sfpe1t1-framer	
	sfpe1t1-clock	
	pppcc-engine-tca	
	eth-cfm	
	rsvp	
	ihub-tca	
	eth-ring	
	efm-oam	
	ont-loopdetect	
	ont-video	
	ont-ces	
	ont-voip	
	ont-video-ani	
	ont-pwe	
	ont-cese1	
	ont-xdsl	
	ont-xdsl-tca	
	ont-hpna	
	ont-sip-agent-cfg	
	ont-voip-cfg	
	ont-mgc	
	ont-ploam	
	ont-gen	
	ont-card	
	ont-pots	
	ont-lan	
	ont-moca	
	ont-tc-tca	
	ont-moca-tca	
	ont-l2uni-eth-tca	
	olt-pon-tc-tca	
	olt-pon-util-tca	
	olt-chpr-util-tca	
	olt-ont-tc-tca	
	ont-tca	
	ont-pots-supplemental	

101 query current alarms by filters

name	Type	Description
	sfu-ploam sfu-gen soho-ploam soho-gen mdu-ploam mdu-gen ont-veip ont-iphost alarm-table auto-switch channel-pair ont-cfg-dld olt-chpair-tc-tca hgu-tr069 eqpt-psu ont-protection secondary-megaco-term secondary-sip-term cas-r2-channel lldpmed pseudo-wire link-agg fcs-exceed e1t1-interface) Possible values: - equipment : equipment alarms - eqpt-holder : equipment holder alarms - plug-in-unit : plugin unit alarms - atm : ATM alarms - custom : customizable alarms - e1 : e1 alarms - ima-group : ima-group alarms - ima-link : ima-link alarms - redundancy : redundancy alarms - shdsl : shdsl alarms - ether-itf : ethernet interface alarms - traffic-overflow : Traffic overflow alarms - qos-queue : qos queue alarms - temporal : temporal alarms - spatial : spatial alarms - software-mngt : software management alarms - sw-mgmt : software management alarms - xdsl : xDSL alarms - xdsl-ext : other xDSL alarms - xdsl-tca : xDSL threshold cross alarms - olt-gen : OLT general alarms - eo-conv : E/O conversion related alarms - authentication : authentication related alarms - bonding : bonding-group related alarms - sfp : SFP related alarms - shdsl-isam : shdsl isam alarms - custom-ext-alarm : customizable external alarms - plug-in-unit-ext : other plugin unit alarms - sip-user-agent : sip user agent related alarms - sip-plugin-unit : sip plug in unit related alarms - sip-termination : sip termination related alarms - e1-sip-termination : E1 sip termination related alarms	

name	Type	Description
	- filetransfer : file transfer server alarms - external-device : external device related alarms - l2forward : l2forward related alarms - ether-tca : ethernet threshold cross alarms - ether-sfp : ethernet SFP related alarms - megaco-media-gw : megaco media gateway related alarms - megaco-sig-gw : megaco signaling gateway related alarms - megaco-plug-unit : megaco plug unit related alarms - megaco-term : megaco termination related alarms - megaco-sig-lt : megaco signaling lt related alarms - eqpt-supplemental : equipment supplemental alarms - eqpt-holder-ext : other equipment holder alarms - lsmredundancy : lsm redundancy alarms - sync : synce and bits alarms - mcsrc : multicast source alarms - vlanport : vlanport alarms - vect-line : xDSL vectoring line alarms - vect-board : xDSL vectoring board alarms - otdr : otdr alarms - sip-dial-plan : sip dial plan related alarms - sip-vsp : sip vsp related alarms - sip-server : sip server related alarms - bgp : bgp related alarms - rip : rip related alarms - lag : LAG related alarms - ihub-general : IHUB general related alarms - vprn : vprn related alarms - isis : isis related alarms - ospf : ospf related alarms - ihub-l2forward : ihub-l2forward alarms - vpls : vpls related alarms - ihub-equip : ihub-equip related alarms - ihub-link : ihub-link related alarms - eont-phyoam : eont phyoam related alarms - ellid : ellid related alarms - epon : epon related alarms - eont-services-lan : eon phyoam related alarms - eolt-ont-tca : eon phyoam related alarms - eont-sw-dl : eon phyoam related alarms - ldp : ldp related alarms - mpls : mpls related alarms - sdp : sdp related alarms - epipe : epipe related alarms - ihub-ipv6 : ihub-ipv6 related alarms - pim : pim related alarms - li : lawful intercept related alarms - mgmt-sec-access : management security related alarms - bfd : bfd related alarms - ai : Application Intelligence related alarms - tr069serv : tr069 server related alarms - ontsnmp : ont snmp related alarms - bulk-sync : bulk-sync related alarms - protection-group : port protection group related alarms - ont : ONT general supplemental related alarms - sfu-sup : SFU ONT general supplemental related alarms - soho-sup : SOHO ONT general supplemental related alarms	

101 query current alarms by filters

name	Type	Description
	- mdu-sup : MDU ONT general supplemental related alarms - ont-ani : ONT general supplemental 2 related alarms - sfu-sup2 : SFU ONT general supplemental 2 related alarms - soho-sup2 : SOHO ONT general supplemental 2 related alarms - mdu-sup2 : MDU ONT general supplemental 2 related alarms - sfprssi : SFP RSSI related alarms - eoltrssi : epon olt Sfp RSSI related alarms - cfm : Cfm related alarms - sfpe1t1-framer : SFP 2e1t1 framer alarms - sfpe1t1-clock : SFP 2e1t1 clock alarms - pppcc-engine-tca : PPPOE Cross Connect Engine TCA related alarm - eth-cfm : eth-cfm related alarms - rsvp : rsvp related alarms - ihub-tca : IHUB TCA related alarms - eth-ring : eth-ring related alarms - efm-oam : EFM-OAM related alarms - ont-loopdetect : ont loop detect related alarms - ont-video : ont services video related alarms - ont-ces : ont services ces related alarms - ont-voip : ont services voip related alarms - ont-video-ani : ont services video ani related alarms - ont-pwe : ont services pwe related alarms - ont-cese1 : ont services cese1 related alarms - ont-xdsl : ont services xdsl related alarms - ont-xdsl-tca : ont services xdsl tca related alarms - ont-hpna : ont hpna related alarms - ont-sip-agent-cfg : ont services voip sip agent config related alarms - ont-voip-cfg : ont services voip config related alarms - ont-mgc : ont mgc related alarms - ont-ploam : ONT PLOAM related alarms - ont-gen : ONT GENERAL related alarms - ont-card : ONT Subscriber Card related alarms - ont-pots : ONT Services POTS related alarms - ont-lan : ONT Services LAN related alarms - ont-moca : ONT MoCA related alarms - ont-tc-tca : ONT TC TCA related alarms - ont-moca-tca : ONT MoCA TCA related alarms - ont-l2uni-eth-tca : ONT L2 UNI Ethernet TCA related alarms - olt-pon-tc-tca : OLT PON TC TCA related alarms - olt-pon-util-tca : OLT PON utilization TCA related alarms - olt-chpr-util-tca : OLT channel-pair utilization TCA related alarms - olt-ont-tc-tca : OLT ONT TC TCA related alarms - ont-tca : ONT TCA related alarms - ont-pots-supplemental : ONT POTS Supplemental related alarms - sfu-ploam : SFU ONT PLOAM related alarms - sfu-gen : SFU ONT general related alarms - soho-ploam : SOHO ONT PLOAM related alarms - soho-gen : SOHO ONT general related alarms - mdu-ploam : MDU ONT PLOAM related alarms - mdu-gen : MDU ONT general related alarms	

name	Type	Description
	- ont-veip : ONT VEIP related alarms - ont-iphost : ONT IP HOST related alarms - alarm-table : alarm table related alarms - auto-switch : auto-switch related alarms - channel-pair : channel pair related alarms - ont-cfg-dld : ont configure file download related alarms - olt-chpair-tc-tca : OLT CHANNELPAIR TC TCA related alarms - hgu-tr069 : hgu tr069 related alarms - eqpt-psu : equipment psu alarms - ont-protection : ONT protection related alarms - secondary-megaco-term : secondary megaco termination related alarms - secondary-sip-term : secondary sip termination related alarms - cas-r2-channel : CAS R2 channel related alarms - lldpmed : lldpmed alarms - pseudo-wire : pseudo Wire related alarms - link-agg : Link aggregation related alarms - fcs-exceed : FCS auto-recovery related alarms - e1t1-interface : E1/T1 physical interfaces related alarms	
name	Parameter type: <Alarm::almtypeHguTr069ihub> (cust-alm1 cust-alm2 cust-alm3 cust-alm4 cust-alm5 cust-alm6 cust-alm7 cust-alm8 cust-alm9 cust-alm10 cust-alm11 cust-alm12 cust-alm13 cust-alm14 cust-alm15 cust-alm16 cust-alm17 cust-alm18 cust-alm19 cust-alm20 cust-alm21 cust-alm22 cust-alm23 cust-alm24 cust-alm25 cust-alm26 cust-alm27 cust-alm28 cust-alm29 cust-alm30 cust-alm31 all) Possible values: - cust-alm1 : customizable alarm 1 - cust-alm2 : customizable alarm 2	alarm name that are active <i>This element is only shown in detail mode.</i>

101 query current alarms by filters

name	Type	Description
	- cust-alm3 : customizable alarm 3 - cust-alm4 : customizable alarm 4 - cust-alm5 : customizable alarm 5 - cust-alm6 : customizable alarm 6 - cust-alm7 : customizable alarm 7 - cust-alm8 : customizable alarm 8 - cust-alm9 : customizable alarm 9 - cust-alm10 : customizable alarm 10 - cust-alm11 : customizable alarm 11 - cust-alm12 : customizable alarm 12 - cust-alm13 : customizable alarm 13 - cust-alm14 : customizable alarm 14 - cust-alm15 : customizable alarm 15 - cust-alm16 : customizable alarm 16 - cust-alm17 : customizable alarm 17 - cust-alm18 : customizable alarm 18 - cust-alm19 : customizable alarm 19 - cust-alm20 : customizable alarm 20 - cust-alm21 : customizable alarm 21 - cust-alm22 : customizable alarm 22 - cust-alm23 : customizable alarm 23 - cust-alm24 : customizable alarm 24 - cust-alm25 : customizable alarm 25 - cust-alm26 : customizable alarm 26 - cust-alm27 : customizable alarm 27 - cust-alm28 : customizable alarm 28 - cust-alm29 : customizable alarm 29 - cust-alm30 : customizable alarm 30 - cust-alm31 : customizable alarm 31 - all : hgu tr069 related alarms	
severity	Parameter type: <Alarm::AlarmSeverity> (indeterminate warning minor major critical) Possible values: - indeterminate : alarm severity is indeterminate - warning : alarm severity is warning - minor : alarm severity is minor - major : alarm severity is major - critical : alarm severity is critical	the alarms severity level <i>This element is only shown in detail mode.</i>
servaff	Parameter type: <Alarm::alarmServAffect> ((service-affecting yes) (noservice-affecting no)) Possible values: - service-affecting : make this alarm service affecting - yes : make this alarm service affecting - noservice-affecting : make this alarm not service affecting - no : make this alarm not service affecting	alarms affect service or not <i>This element is only shown in detail mode.</i>
time	Parameter type: <Sys::timeInSecs> - the time (yyyy-mm-dd:hour:minutes:secs) - unit: UTC	time in seconds when alarm was updated <i>This element is only shown in detail mode.</i>
descript	Parameter type: <Alarm::AddInfoString> - additional alarm information	alarm description <i>This element is only shown in detail mode.</i>

101.142 show current alarm by filters

Command Description

show current alarms by filters

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm query eqpt-psu [ (name) [ severity <Alarm::querySeverity> ] [ servaff <Alarm::queryServAffect> ] [ shelf <Equipm::Shelf> ] ]
```

Command Parameters

Table 101.142-1 "show current alarm by filters" Resource Parameters

Resource Identifier	Type	Description
(name)	Format: (psu-fail-crit psu-a-fail-presence psu-a-fail-vin-ac-nok psu-a-fail-vin-uv psu-a-fail-vin-ov psu-a-fail-vout-uv psu-a-fail-vout-ov psu-a-fail-iout-oc psu-a-fail-overtemp psu-b-fail-presence psu-b-fail-vin-ac-nok psu-b-fail-vin-uv psu-b-fail-vin-ov psu-b-fail-vout-uv psu-b-fail-vout-ov psu-b-fail-iout-oc psu-b-fail-overtemp all) Possible values: - psu-fail-crit : Power Supply failure - psu-a-fail-presence : Power Supply A is not present - psu-a-fail-vin-ac-nok : Power Supply A has Vin AC fault - psu-a-fail-vin-uv : Power Supply A has Vin undervoltage - psu-a-fail-vin-ov : Power Supply A has Vin overvoltage - psu-a-fail-vout-uv : Power Supply A has Vout undervoltage - psu-a-fail-vout-ov : Power Supply A has Vout overvoltage	alarm name of eqpt-psu

Resource Identifier	Type	Description
	- psu-a-fail-iout-oc : Power Supply A has Iout overcurrent - psu-a-fail-ovtemp : Power Supply A has over temperature - psu-b-fail-presence : Power Supply B is not present - psu-b-fail-vin-ac-nok : Power Supply B has Vin AC fault - psu-b-fail-vin-uv : Power Supply B has Vin undervoltage - psu-b-fail-vin-ov : Power Supply B has Vin overvoltage - psu-b-fail-vout-uv : Power Supply B has Vout undervoltage - psu-b-fail-vout-ov : Power Supply B has Vout overvoltage - psu-b-fail-iout-oc : Power Supply B has Iout overcurrent - psu-b-fail-ovtemp : Power Supply B has over temperature - all : eqpt-psu related alarms	
severity	Parameter type: <Alarm::querySeverity> Format: (indeterminate warning minor major critical all) Possible values: - indeterminate : alarm severity is indeterminate - warning : alarm severity is warning - minor : alarm severity is minor - major : alarm severity is major - critical : alarm severity is critical - all : all alarm severity	severity level of alarm for reporting
servaff	Parameter type: <Alarm::queryServAffect> Format: (service-affecting noservice-affecting all) Possible values: - service-affecting : query alarm service affecting - noservice-affecting : query alarm not service affecting - all : query service affecting and not affecting alarms	serviceaffecting no serviceaffecting
shelf	Parameter type: <Equipm::Shelf> Format: <Eqpt::RackId> / <Eqpt::ShelfId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number	the shelf identifier of alarm

Command Output

Table 101.142-2 "show current alarm by filters" Display parameters

Specific Information		
name	Type	Description
aidinfo	Parameter type: <Alarm::AddInfoString> - additional alarm information	alarm AID parameters <i>This element is only shown in detail mode.</i>
type	Parameter type: <Alarm::alarmIHUBType> (equipment	type of the alarms that are active <i>This element is only shown in</i>

101 query current alarms by filters

name	Type	Description
	eqpt-holder plug-in-unit atm custom e1 ima-group ima-link redundancy shdsl ether-itf traffic-overflow qos-queue temporal spatial (software-mngt sw-mgmt) xdsl xdsl-ext xdsl-tca olt-gen eo-conv authentication bonding sfp shdsl-isam custom-ext-alarm plug-in-unit-ext sip-user-agent sip-plugin-unit sip-termination e1-sip-termination filetransfer external-device l2forward ether-tca ether-sfp megaco-media-gw megaco-sig-gw megaco-plug-unit megaco-term megaco-sig-lt eqpt-supplemental eqpt-holder-ext lsmredundancy sync mcsrc vlanport vect-line vect-board otdr sip-dial-plan sip-vsp sip-server bgp rip lag ihub-general vprn	<i>detail mode.</i>

name	Type	Description
	isis	
	ospf	
	ihub-l2forward	
	vpls	
	ihub-equip	
	ihub-link	
	eont-phyoam	
	ellid	
	epon	
	eont-services-lan	
	eolt-ont-tca	
	eont-sw-dl	
	ldp	
	mpls	
	sdp	
	epipe	
	ihub-ipv6	
	pim	
	li	
	mgmt-sec-access	
	bfd	
	ai	
	tr069serv	
	ontsnmp	
	bulk-sync	
	protection-group	
	ont	
	sfu-sup	
	soho-sup	
	mdu-sup	
	ont-ani	
	sfu-sup2	
	soho-sup2	
	mdu-sup2	
	sfprssi	
	eoltrssi	
	cfm	
	sfpe1t1-framer	
	sfpe1t1-clock	
	pppcc-engine-tca	
	eth-cfm	
	rsvp	
	ihub-tca	
	eth-ring	
	efm-oam	
	ont-loopdetect	
	ont-video	
	ont-ces	
	ont-voip	
	ont-video-ani	
	ont-pwe	
	ont-cese1	
	ont-xdsl	
	ont-xdsl-tca	
	ont-hpna	
	ont-sip-agent-cfg	
	ont-voip-cfg	

101 query current alarms by filters

name	Type	Description
	ont-mgc ont-ploam ont-gen ont-card ont-pots ont-lan ont-moca ont-tc-tca ont-moca-tca ont-l2uni-eth-tca olt-pon-tc-tca olt-pon-util-tca olt-chpr-util-tca olt-ont-tc-tca ont-tca ont-pots-supplemental sfu-ploam sfu-gen soho-ploam soho-gen mdu-ploam mdu-gen ont-veip ont-iphost alarm-table auto-switch channel-pair ont-cfg-dld olt-chpair-tc-tca hgu-tr069 eqpt-psu ont-protection secondary-megaco-term secondary-sip-term cas-r2-channel lldpmed pseudo-wire link-agg fcs-exceed e1t1-interface) Possible values: - equipment : equipment alarms - eqpt-holder : equipment holder alarms - plug-in-unit : plugin unit alarms - atm : ATM alarms - custom : customizable alarms - e1 : e1 alarms - ima-group : ima-group alarms - ima-link : ima-link alarms - redundancy : redundancy alarms - shdsl : shdsl alarms - ether-itf : ethernet interface alarms - traffic-overflow : Traffic overflow alarms - qos-queue : qos queue alarms - temporal : temporal alarms - spatial : spatial alarms - software-mngt : software management alarms	

name	Type	Description
	- sw-mgmt : software management alarms - xdsl : xDSL alarms - xdsl-ext : other xDSL alarms - xdsl-tca : xDSL threshold cross alarms - olt-gen : OLT general alarms - eo-conv : E/O conversion related alarms - authentication : authentication related alarms - bonding : bonding-group related alarms - sfp : SFP related alarms - shdsl-isam : shdsl isam alarms - custom-ext-alarm : customizable external alarms - plug-in-unit-ext : other plugin unit alarms - sip-user-agent : sip user agent related alarms - sip-plugin-unit : sip plug in unit related alarms - sip-termination : sip termination related alarms - e1-sip-termination : E1 sip termination related alarms - filetransfer : file transfer server alarms - external-device : external device related alarms - l2forward : l2forward related alarms - ether-tca : ethernet threshold cross alarms - ether-sfp : ethernet SFP related alarms - megaco-media-gw : megaco media gateway related alarms - megaco-sig-gw : megaco signaling gateway related alarms - megaco-plug-unit : megaco plug unit related alarms - megaco-term : megaco termination related alarms - megaco-sig-lt : megaco signaling lt related alarms - eqpt-supplemental : equipment supplemental alarms - eqpt-holder-ext : other equipment holder alarms - lsmredundancy : lsm redundancy alarms - sync : synce and bits alarms - mcsrc : multicast source alarms - vlanport : vlanport alarms - vect-line : xDSL vectoring line alarms - vect-board : xDSL vectoring board alarms - otdr : otdr alarms - sip-dial-plan : sip dial plan related alarms - sip-vsp : sip vsp related alarms - sip-server : sip server related alarms - bgp : bgp related alarms - rip : rip related alarms - lag : LAG related alarms - ihub-general : IHUB general related alarms - vprn : vprn related alarms - isis : isis related alarms - ospf : ospf related alarms - ihub-l2forward : ihub-l2forward alarms - vpls : vpls related alarms - ihub-equip : ihub-equip related alarms - ihub-link : ihub-link related alarms - eont-phyoam : eont phyoam related alarms - ellid : ellid related alarms - epon : epon related alarms - eont-services-lan : eon phyoam related alarms - eolt-ont-tca : eon phyoam related alarms - eont-sw-dl : eon phyoam related alarms - ldp : ldp related alarms - mpls : mpls related alarms	

101 query current alarms by filters

name	Type	Description
	- sdp : sdp related alarms - epipe : epipe related alarms - ihub-ipv6 : ihub-ipv6 related alarms - pim : pim related alarms - li : lawful intercept related alarms - mgmt-sec-access : management security related alarms - bfd : bfd related alarms - ai : Application Intelligence related alarms - tr069serv : tr069 server related alarms - ontsnmp : ont snmp related alarms - bulk-sync : bulk-sync related alarms - protection-group : port protection group related alarms - ont : ONT general supplemental related alarms - sfu-sup : SFU ONT general supplemental related alarms - soho-sup : SOHO ONT general supplemental related alarms - mdu-sup : MDU ONT general supplemental related alarms - ont-ani : ONT general supplemental 2 related alarms - sfu-sup2 : SFU ONT general supplemental 2 related alarms - soho-sup2 : SOHO ONT general supplemental 2 related alarms - mdu-sup2 : MDU ONT general supplemental 2 related alarms - sfprssi : SFP RSSI related alarms - eoltrssi : epon olt Sfp RSSI related alarms - cfm : Cfm related alarms - sfpe1t1-framer : SFP 2e1t1 framer alarms - sfpe1t1-clock : SFP 2e1t1 clock alarms - pppcc-engine-tca : PPPOE Cross Connect Engine TCA related alarm - eth-cfm : eth-cfm related alarms - rsvp : rsvp related alarms - ihub-tca : IHUB TCA related alarms - eth-ring : eth-ring related alarms - efm-oam : EFM-OAM related alarms - ont-loopdetect : ont loop detect related alarms - ont-video : ont services video related alarms - ont-ces : ont services ces related alarms - ont-voip : ont services voip related alarms - ont-video-ani : ont services video ani related alarms - ont-pwe : ont services pwe related alarms - ont-cese1 : ont services cese1 related alarms - ont-xdsl : ont services xdsl related alarms - ont-xdsl-tca : ont services xdsl tca related alarms - ont-hpna : ont hpna related alarms - ont-sip-agent-cfg : ont services voip sip agent config related alarms - ont-voip-cfg : ont services voip config related alarms - ont-mgc : ont mgc related alarms - ont-ploam : ONT PLOAM related alarms - ont-gen : ONT GENERAL related alarms - ont-card : ONT Subscriber Card related alarms - ont-pots : ONT Services POTS related alarms - ont-lan : ONT Services LAN related alarms - ont-moca : ONT MoCA related alarms - ont-tc-tca : ONT TC TCA related alarms - ont-moca-tca : ONT MoCA TCA related alarms	

name	Type	Description
	- ont-l2uni-eth-tca : ONT L2 UNI Ethernet TCA related alarms - olt-pon-tc-tca : OLT PON TC TCA related alarms - olt-pon-util-tca : OLT PON utilization TCA related alarms - olt-chpr-util-tca : OLT channel-pair utilization TCA related alarms - olt-ont-tc-tca : OLT ONT TC TCA related alarms - ont-tca : ONT TCA related alarms - ont-pots-supplemental : ONT POTS Supplemental related alarms - sfu-ploam : SFU ONT PLOAM related alarms - sfu-gen : SFU ONT general related alarms - soho-ploam : SOHO ONT PLOAM related alarms - soho-gen : SOHO ONT general related alarms - mdu-ploam : MDU ONT PLOAM related alarms - mdu-gen : MDU ONT general related alarms - ont-veip : ONT VEIP related alarms - ont-iphost : ONT IP HOST related alarms - alarm-table : alarm table related alarms - auto-switch : auto-switch related alarms - channel-pair : channel pair related alarms - ont-cfg-dld : ont configure file download related alarms - olt-chpair-tc-tca : OLT CHANNELPAIR TC TCA related alarms - hgu-tr069 : hgu tr069 related alarms - eqpt-psu : equipment psu alarms - ont-protection : ONT protection related alarms - secondary-megaco-term : secondary megaco termination related alarms - secondary-sip-term : secondary sip termination related alarms - cas-r2-channel : CAS R2 channel related alarms - lldpmed : lldpmed alarms - pseudo-wire : pseudo Wire related alarms - link-agg : Link aggregation related alarms - fcs-exceed : FCS auto-recovery related alarms - e1t1-interface : E1/T1 physical interfaces related alarms	
name	Parameter type: <Alarm::alarmtypeEqptPsu> (psu-fail-crit psu-a-fail-presence psu-a-fail-vin-ac-nok psu-a-fail-vin-uv psu-a-fail-vin-ov psu-a-fail-vout-uv psu-a-fail-vout-ov psu-a-fail-iout-oc psu-a-fail-overtemp psu-b-fail-presence psu-b-fail-vin-ac-nok psu-b-fail-vin-uv psu-b-fail-vin-ov psu-b-fail-vout-uv psu-b-fail-vout-ov psu-b-fail-iout-oc psu-b-fail-overtemp all) Possible values:	alarm name that are active <i>This element is only shown in detail mode.</i>

101 query current alarms by filters

name	Type	Description
	- psu-fail-crit : Power Supply failure - psu-a-fail-presence : Power Supply A is not present - psu-a-fail-vin-ac-nok : Power Supply A has Vin AC fault - psu-a-fail-vin-uv : Power Supply A has Vin undervoltage - psu-a-fail-vin-ov : Power Supply A has Vin overvoltage - psu-a-fail-vout-uv : Power Supply A has Vout undervoltage - psu-a-fail-vout-ov : Power Supply A has Vout overvoltage - psu-a-fail-iout-oc : Power Supply A has Iout overcurrent - psu-a-fail-ovtemp : Power Supply A has over temperature - psu-b-fail-presence : Power Supply B is not present - psu-b-fail-vin-ac-nok : Power Supply B has Vin AC fault - psu-b-fail-vin-uv : Power Supply B has Vin undervoltage - psu-b-fail-vin-ov : Power Supply B has Vin overvoltage - psu-b-fail-vout-uv : Power Supply B has Vout undervoltage - psu-b-fail-vout-ov : Power Supply B has Vout overvoltage - psu-b-fail-iout-oc : Power Supply B has Iout overcurrent - psu-b-fail-ovtemp : Power Supply B has over temperature - all : eqpt-psu related alarms	
severity	Parameter type: <Alarm::AlarmSeverity> (indeterminate warning minor major critical) Possible values: - indeterminate : alarm severity is indeterminate - warning : alarm severity is warning - minor : alarm severity is minor - major : alarm severity is major - critical : alarm severity is critical	the alarms severity level <i>This element is only shown in detail mode.</i>
servaff	Parameter type: <Alarm::alarmServAffect> ((service-affecting yes) (noservice-affecting no)) Possible values: - service-affecting : make this alarm service affecting - yes : make this alarm service affecting - noservice-affecting : make this alarm not service affecting - no : make this alarm not service affecting	alarms affect service or not <i>This element is only shown in detail mode.</i>
time	Parameter type: <Sys::timeInSecs> - the time (yyyy-mm-dd:hour:minutes:secs) - unit: UTC	time in seconds when alarm was updated <i>This element is only shown in detail mode.</i>
descript	Parameter type: <Alarm::AddInfoString> - additional alarm information	alarm description <i>This element is only shown in detail mode.</i>

101.143 show current alarm by filters

Command Description

show current alarms by filters

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm query secondary-megaco-term [ (name) [ severity <Alarm::querySeverity> ] [ servaff
<Alarm::queryServAffect> ] [ port <Itf::MegacoPotsLine> ] ]
```

Command Parameters

Table 101.143-1 "show current alarm by filters" Resource Parameters

Resource Identifier	Type	Description
(name)	Format: (meg-unknown-sub-sec line-showering-sec all) Possible values: - meg-unknown-sub-sec : The Megaco subscriber exists in voice signaling board but not in media gateway controller. - line-showering-sec : A subscriber line exceeds 20 off-hook / on-hook events / minute. - all : show all secondary megaco termination alarm	alarm name of secondary megaco term
severity	Parameter type: <Alarm::querySeverity> Format: (indeterminate warning minor major critical all) Possible values: - indeterminate : alarm severity is indeterminate - warning : alarm severity is warning - minor : alarm severity is minor - major : alarm severity is major - critical : alarm severity is critical - all : all alarm severity	severity level of an alarm for reporting
servaff	Parameter type: <Alarm::queryServAffect> Format: (service-affecting	serviceaffecting no

101 query current alarms by filters

Resource Identifier	Type	Description
	noservice-affecting all) Possible values: - service-affecting : query alarm service affecting - noservice-affecting : query alarm not service affecting - all : query service affecting and not affecting alarms	
port	Parameter type: <Itf::MegacoPotsLine> Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::NewSlotId> / <Eqpt::MegacoPortId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::NewSlotId> - the LT slot number Field type <Eqpt::MegacoPortId> - the port number of Megaco	the number of the port

Command Output

Table 101.143-2 "show current alarm by filters" Display parameters

Specific Information		
name	Type	Description
aidinfo	Parameter type: <Alarm::AddInfoString> - additional alarm information	alarm AID parameters <i>This element is only shown in detail mode.</i>
type	Parameter type: <Alarm::alarmIHUBType> (equipment eqpt-holder plug-in-unit atm custom e1 ima-group ima-link redundancy shdsl ether-itf traffic-overflow qos-queue temporal spatial (software-mngt sw-mgmt) xdsl xdsl-ext xdsl-tca olt-gen eo-conv authentication bonding sfp shdsl-isam custom-ext-alarm plug-in-unit-ext sip-user-agent	type of the alarms that are active <i>This element is only shown in detail mode.</i>

name	Type	Description
	sip-plugin-unit sip-termination e1-sip-termination filetransfer external-device l2forward ether-tca ether-sfp megaco-media-gw megaco-sig-gw megaco-plug-unit megaco-term megaco-sig-lt eqpt-supplemental eqpt-holder-ext lsmredundancy sync mcsrc vlanport vect-line vect-board otdr sip-dial-plan sip-vsp sip-server bgp rip lag ihub-general vprn isis ospf ihub-l2forward vpls ihub-equip ihub-link eont-phyoam ellid epon eont-services-lan eolt-ont-tca eont-sw-dl ldp mpls sdp epipe ihub-ipv6 pim li mgmt-sec-access bfd ai tr069serv ontsnmp bulk-sync protection-group ont	

101 query current alarms by filters

name	Type	Description
	sfu-sup	
	soho-sup	
	mdu-sup	
	ont-ani	
	sfu-sup2	
	soho-sup2	
	mdu-sup2	
	sfprssi	
	eoltrssi	
	cfm	
	sfpe1t1-framer	
	sfpe1t1-clock	
	pppcc-engine-tca	
	eth-cfm	
	rsvp	
	ihub-tca	
	eth-ring	
	efm-oam	
	ont-loopdetect	
	ont-video	
	ont-ces	
	ont-voip	
	ont-video-ani	
	ont-pwe	
	ont-cese1	
	ont-xdsl	
	ont-xdsl-tca	
	ont-hpna	
	ont-sip-agent-cfg	
	ont-voip-cfg	
	ont-mgc	
	ont-ploam	
	ont-gen	
	ont-card	
	ont-pots	
	ont-lan	
	ont-moca	
	ont-tc-tca	
	ont-moca-tca	
	ont-l2uni-eth-tca	
	olt-pon-tc-tca	
	olt-pon-util-tca	
	olt-chpr-util-tca	
	olt-ont-tc-tca	
	ont-tca	
	ont-pots-supplemental	
	sfu-ploam	
	sfu-gen	
	soho-ploam	
	soho-gen	
	mdu-ploam	
	mdu-gen	
	ont-veip	
	ont-iphost	
	alarm-table	
	auto-switch	
	channel-pair	

name	Type	Description
	ont-cfg-dld olt-chpair-tc-tca hgu-tr069 eqpt-psu ont-protection secondary-megaco-term secondary-sip-term cas-r2-channel lldpmed pseudo-wire link-agg fcs-exceed e1t1-interface) Possible values: - equipment : equipment alarms - eqpt-holder : equipment holder alarms - plug-in-unit : plugin unit alarms - atm : ATM alarms - custom : customizable alarms - e1 : e1 alarms - ima-group : ima-group alarms - ima-link : ima-link alarms - redundancy : redundancy alarms - shdsl : shdsl alarms - ether-itf : ethernet interface alarms - traffic-overflow : Traffic overflow alarms - qos-queue : qos queue alarms - temporal : temporal alarms - spatial : spatial alarms - software-mngt : software management alarms - sw-mgmt : software management alarms - xdsl : xDSL alarms - xdsl-ext : other xDSL alarms - xdsl-tca : xDSL threshold cross alarms - olt-gen : OLT general alarms - eo-conv : E/O conversion related alarms - authentication : authentication related alarms - bonding : bonding-group related alarms - sfp : SFP related alarms - shdsl-isam : shdsl isam alarms - custom-ext-alarm : customizable external alarms - plug-in-unit-ext : other plugin unit alarms - sip-user-agent : sip user agent related alarms - sip-plugin-unit : sip plug in unit related alarms - sip-termination : sip termination related alarms - e1-sip-termination : E1 sip termination related alarms - filetransfer : file transfer server alarms - external-device : external device related alarms - l2forward : l2forward related alarms - ether-tca : ethernet threshold cross alarms - ether-sfp : ethernet SFP related alarms - megaco-media-gw : megaco media gateway related alarms - megaco-sig-gw : megaco signaling gateway related alarms - megaco-plug-unit : megaco plug unit related alarms - megaco-term : megaco termination related alarms - megaco-sig-lt : megaco signaling lt related alarms - eqpt-supplemental : equipment supplemental alarms	

101 query current alarms by filters

name	Type	Description
	- eqpt-holder-ext : other equipment holder alarms - lsmredundancy : lsm redundancy alarms - sync : synce and bits alarms - mcsrc : multicast source alarms - vlanport : vlanport alarms - vect-line : xDSL vectoring line alarms - vect-board : xDSL vectoring board alarms - otdr : otdr alarms - sip-dial-plan : sip dial plan related alarms - sip-vsp : sip vsp related alarms - sip-server : sip server related alarms - bgp : bgp related alarms - rip : rip related alarms - lag : LAG related alarms - ihub-general : IHUB general related alarms - vprn : vprn related alarms - isis : isis related alarms - ospf : ospf related alarms - ihub-l2forward : ihub-l2forward alarms - vpls : vpls related alarms - ihub-equip : ihub-equip related alarms - ihub-link : ihub-link related alarms - eont-phyoam : eont phyoam related alarms - ellid : ellid related alarms - epon : epon related alarms - eont-services-lan : eon phyoam related alarms - eolt-ont-tca : eon phyoam related alarms - eont-sw-dl : eon phyoam related alarms - ldp : ldp related alarms - mpls : mpls related alarms - sdp : sdp related alarms - epipe : epipe related alarms - ihub-ipv6 : ihub-ipv6 related alarms - pim : pim related alarms - li : lawful intercept related alarms - mgmt-sec-access : management security related alarms - bfd : bfd related alarms - ai : Application Intelligence related alarms - tr069serv : tr069 server related alarms - ontsnmp : ont snmp related alarms - bulk-sync : bulk-sync related alarms - protection-group : port protection group related alarms - ont : ONT general supplemental related alarms - sfu-sup : SFU ONT general supplemental related alarms - soho-sup : SOHO ONT general supplemental related alarms - mdu-sup : MDU ONT general supplemental related alarms - ont-ani : ONT general supplemental 2 related alarms - sfu-sup2 : SFU ONT general supplemental 2 related alarms - soho-sup2 : SOHO ONT general supplemental 2 related alarms - mdu-sup2 : MDU ONT general supplemental 2 related alarms - sfrssi : SFP RSSI related alarms - eoltrssi : epon olt Sfp RSSI related alarms - cfm : Cfm related alarms - sfpe1t1-framer : SFP 2e1t1 framer alarms	

name	Type	Description
	- sfpe1t1-clock : SFP 2e1t1 clock alarms - pppcc-engine-tca : PPPOE Cross Connect Engine TCA related alarm - eth-cfm : eth-cfm related alarms - rsvp : rsvp related alarms - ihub-tca : IHUB TCA related alarms - eth-ring : eth-ring related alarms - efm-oam : EFM-OAM related alarms - ont-loopdetect : ont loop detect related alarms - ont-video : ont services video related alarms - ont-ces : ont services ces related alarms - ont-voip : ont services voip related alarms - ont-video-ani : ont services video ani related alarms - ont-pwe : ont services pwe related alarms - ont-cese1 : ont services cese1 related alarms - ont-xdsl : ont services xdsl related alarms - ont-xdsl-tca : ont services xdsl tca related alarms - ont-hpna : ont hpna related alarms - ont-sip-agent-cfg : ont services voip sip agent config related alarms - ont-voip-cfg : ont services voip config related alarms - ont-mgc : ont mgc related alarms - ont-ploam : ONT PLOAM related alarms - ont-gen : ONT GENERAL related alarms - ont-card : ONT Subscriber Card related alarms - ont-pots : ONT Services POTS related alarms - ont-lan : ONT Services LAN related alarms - ont-moca : ONT MoCA related alarms - ont-tc-tca : ONT TC TCA related alarms - ont-moca-tca : ONT MoCA TCA related alarms - ont-l2uni-eth-tca : ONT L2 UNI Ethernet TCA related alarms - olt-pon-tc-tca : OLT PON TC TCA related alarms - olt-pon-util-tca : OLT PON utilization TCA related alarms - olt-chpr-util-tca : OLT channel-pair utilization TCA related alarms - olt-ont-tc-tca : OLT ONT TC TCA related alarms - ont-tca : ONT TCA related alarms - ont-pots-supplemental : ONT POTS Supplemental related alarms - sfu-ploam : SFU ONT PLOAM related alarms - sfu-gen : SFU ONT general related alarms - soho-ploam : SOHO ONT PLOAM related alarms - soho-gen : SOHO ONT general related alarms - mdu-ploam : MDU ONT PLOAM related alarms - mdu-gen : MDU ONT general related alarms - ont-veip : ONT VEIP related alarms - ont-iphost : ONT IP HOST related alarms - alarm-table : alarm table related alarms - auto-switch : auto-switch related alarms - channel-pair : channel pair related alarms - ont-cfg-dld : ont configure file download related alarms - olt-chpair-tc-tca : OLT CHANNELPAIR TC TCA related alarms - hgu-tr069 : hgu tr069 related alarms - eqpt-psu : equipment psu alarms - ont-protection : ONT protection related alarms	

101 query current alarms by filters

name	Type	Description
	- secondary-megaco-term : secondary megaco termination related alarms - secondary-sip-term : secondary sip termination related alarms - cas-r2-channel : CAS R2 channel related alarms - lldpmed : lldpmed alarms - pseudo-wire : pseudo Wire related alarms - link-agg : Link aggregation related alarms - fcs-exceed : FCS auto-recovery related alarms - e1t1-interface : E1/T1 physical interfaces related alarms	
name	Parameter type: <Alarm::alarmTypeSecondaryMegacoTerm> (meg-unknown-sub-sec line-showering-sec all) Possible values: - meg-unknown-sub-sec : The Megaco subscriber exists in voice signaling board but not in media gateway controller. - line-showering-sec : A subscriber line exceeds 20 off-hook / on-hook events / minute. - all : show all secondary megaco termination alarm	alarm name that are active <i>This element is only shown in detail mode.</i>
severity	Parameter type: <Alarm::AlarmSeverity> (indeterminate warning minor major critical) Possible values: - indeterminate : alarm severity is indeterminate - warning : alarm severity is warning - minor : alarm severity is minor - major : alarm severity is major - critical : alarm severity is critical	the alarms severity level <i>This element is only shown in detail mode.</i>
servaff	Parameter type: <Alarm::alarmServAffect> ((service-affecting yes) (noservice-affecting no)) Possible values: - service-affecting : make this alarm service affecting - yes : make this alarm service affecting - noservice-affecting : make this alarm not service affecting - no : make this alarm not service affecting	alarms affect service or not <i>This element is only shown in detail mode.</i>
time	Parameter type: <Sys::timeInSecs> - the time (yyyy-mm-dd:hour:minutes:secs) - unit: UTC	time in seconds when alarm was updated <i>This element is only shown in detail mode.</i>
descript	Parameter type: <Alarm::AddInfoString> - additional alarm information	alarm description <i>This element is only shown in detail mode.</i>

101.144 show current alarm by filters

Command Description

show current alarms by filters

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm query link-agg [ (name) [ severity <Alarm::querySeverity> ] [ servaff <Alarm::queryServAffect> ] [ group <If::LaGroupIndex> ] ]
```

Command Parameters

Table 101.144-1 "show current alarm by filters" Resource Parameters

Resource Identifier	Type	Description
(name)	Format: (la-down la-standby-na la-switch-fail la-degrade all) Possible values: - la-down : Link aggregation link-status is down - la-standby-na : Cross-lt lag on standby slot part is not available - la-switch-fail : Cross-lt lag fail to do switchover - la-degrade : Link aggregation group degrade - all : show all Link aggregation group alarm	alarm name of link-agg
severity	Parameter type: <Alarm::querySeverity> Format: (indeterminate warning minor major critical all) Possible values: - indeterminate : alarm severity is indeterminate - warning : alarm severity is warning - minor : alarm severity is minor - major : alarm severity is major - critical : alarm severity is critical - all : all alarm severity	severity level of an alarm for reporting

101 query current alarms by filters

Resource Identifier	Type	Description
servaff	Parameter type: <Alarm::queryServAffect> Format: (service-affecting noservice-affecting all) Possible values: - service-affecting : query alarm service affecting - noservice-affecting : query alarm not service affecting - all : query service affecting and not affecting alarms	serviceaffecting no serviceaffecting
group	Parameter type: <Itf::LaGroupIndex> Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number	lag group index

Command Output

Table 101.144-2 "show current alarm by filters" Display parameters

Specific Information		
name	Type	Description
type	Parameter type: <Alarm::alarmIHUBType> (equipment eqpt-holder plug-in-unit atm custom e1 ima-group ima-link redundancy shdsl ether-itf traffic-overflow qos-queue temporal spatial (software-mngt sw-mgmt) xdsl xdsl-ext xdsl-tca olt-gen eo-conv authentication bonding sfp shdsl-isam custom-ext-alarm plug-in-unit-ext sip-user-agent	type of the alarms that are active <i>This element is only shown in detail mode.</i>

name	Type	Description
	sip-plugin-unit sip-termination e1-sip-termination filetransfer external-device l2forward ether-tca ether-sfp megaco-media-gw megaco-sig-gw megaco-plug-unit megaco-term megaco-sig-lt eqpt-supplemental eqpt-holder-ext lsmredundancy sync mcsrc vlanport vect-line vect-board otdr sip-dial-plan sip-vsp sip-server bgp rip lag ihub-general vprn isis ospf ihub-l2forward vpls ihub-equip ihub-link eont-phyoam ellid epon eont-services-lan eolt-ont-tca eont-sw-dl ldp mpls sdp epipe ihub-ipv6 pim li mgmt-sec-access bfd ai tr069serv ontsnmp bulk-sync protection-group ont	

101 query current alarms by filters

name	Type	Description
	sfu-sup	
	soho-sup	
	mdu-sup	
	ont-ani	
	sfu-sup2	
	soho-sup2	
	mdu-sup2	
	sfprssi	
	eoltrssi	
	cfm	
	sfpe1t1-framer	
	sfpe1t1-clock	
	pppcc-engine-tca	
	eth-cfm	
	rsvp	
	ihub-tca	
	eth-ring	
	efm-oam	
	ont-loopdetect	
	ont-video	
	ont-ces	
	ont-voip	
	ont-video-ani	
	ont-pwe	
	ont-cese1	
	ont-xdsl	
	ont-xdsl-tca	
	ont-hpna	
	ont-sip-agent-cfg	
	ont-voip-cfg	
	ont-mgc	
	ont-ploam	
	ont-gen	
	ont-card	
	ont-pots	
	ont-lan	
	ont-moca	
	ont-tc-tca	
	ont-moca-tca	
	ont-l2uni-eth-tca	
	olt-pon-tc-tca	
	olt-pon-util-tca	
	olt-chpr-util-tca	
	olt-ont-tc-tca	
	ont-tca	
	ont-pots-supplemental	
	sfu-ploam	
	sfu-gen	
	soho-ploam	
	soho-gen	
	mdu-ploam	
	mdu-gen	
	ont-veip	
	ont-iphost	
	alarm-table	
	auto-switch	
	channel-pair	

name	Type	Description
	ont-cfg-dld olt-chpair-tc-tca hgu-tr069 eqpt-psu ont-protection secondary-megaco-term secondary-sip-term cas-r2-channel lldpmed pseudo-wire link-agg fcs-exceed e1t1-interface) Possible values: - equipment : equipment alarms - eqpt-holder : equipment holder alarms - plug-in-unit : plugin unit alarms - atm : ATM alarms - custom : customizable alarms - e1 : e1 alarms - ima-group : ima-group alarms - ima-link : ima-link alarms - redundancy : redundancy alarms - shdsl : shdsl alarms - ether-itf : ethernet interface alarms - traffic-overflow : Traffic overflow alarms - qos-queue : qos queue alarms - temporal : temporal alarms - spatial : spatial alarms - software-mngt : software management alarms - sw-mgmt : software management alarms - xdsl : xDSL alarms - xdsl-ext : other xDSL alarms - xdsl-tca : xDSL threshold cross alarms - olt-gen : OLT general alarms - eo-conv : E/O conversion related alarms - authentication : authentication related alarms - bonding : bonding-group related alarms - sfp : SFP related alarms - shdsl-isam : shdsl isam alarms - custom-ext-alarm : customizable external alarms - plug-in-unit-ext : other plugin unit alarms - sip-user-agent : sip user agent related alarms - sip-plugin-unit : sip plug in unit related alarms - sip-termination : sip termination related alarms - e1-sip-termination : E1 sip termination related alarms - filetransfer : file transfer server alarms - external-device : external device related alarms - l2forward : l2forward related alarms - ether-tca : ethernet threshold cross alarms - ether-sfp : ethernet SFP related alarms - megaco-media-gw : megaco media gateway related alarms - megaco-sig-gw : megaco signaling gateway related alarms - megaco-plug-unit : megaco plug unit related alarms - megaco-term : megaco termination related alarms - megaco-sig-lt : megaco signaling lt related alarms - eqpt-supplemental : equipment supplemental alarms	

101 query current alarms by filters

name	Type	Description
	- eqpt-holder-ext : other equipment holder alarms - lsmredundancy : lsm redundancy alarms - sync : synce and bits alarms - mcsrsc : multicast source alarms - vlanport : vlanport alarms - vect-line : xDSL vectoring line alarms - vect-board : xDSL vectoring board alarms - otdr : otdr alarms - sip-dial-plan : sip dial plan related alarms - sip-vsp : sip vsp related alarms - sip-server : sip server related alarms - bgp : bgp related alarms - rip : rip related alarms - lag : LAG related alarms - ihub-general : IHUB general related alarms - vprn : vprn related alarms - isis : isis related alarms - ospf : ospf related alarms - ihub-l2forward : ihub-l2forward alarms - vpls : vpls related alarms - ihub-equip : ihub-equip related alarms - ihub-link : ihub-link related alarms - eont-phyoam : eont phyoam related alarms - ellid : ellid related alarms - epon : epon related alarms - eont-services-lan : eon phyoam related alarms - eolt-ont-tca : eon phyoam related alarms - eont-sw-dl : eon phyoam related alarms - ldp : ldp related alarms - mpls : mpls related alarms - sdp : sdp related alarms - epipe : epipe related alarms - ihub-ipv6 : ihub-ipv6 related alarms - pim : pim related alarms - li : lawful intercept related alarms - mgmt-sec-access : management security related alarms - bfd : bfd related alarms - ai : Application Intelligence related alarms - tr069serv : tr069 server related alarms - ontsnmp : ont snmp related alarms - bulk-sync : bulk-sync related alarms - protection-group : port protection group related alarms - ont : ONT general supplemental related alarms - sfu-sup : SFU ONT general supplemental related alarms - soho-sup : SOHO ONT general supplemental related alarms - mdu-sup : MDU ONT general supplemental related alarms - ont-ani : ONT general supplemental 2 related alarms - sfu-sup2 : SFU ONT general supplemental 2 related alarms - soho-sup2 : SOHO ONT general supplemental 2 related alarms - mdu-sup2 : MDU ONT general supplemental 2 related alarms - sfprssi : SFP RSSI related alarms - eoltrssi : epon olt Sfp RSSI related alarms - cfm : Cfm related alarms - sfpe1t1-framer : SFP 2e1t1 framer alarms	

name	Type	Description
	- sfpe1t1-clock : SFP 2e1t1 clock alarms - pppcc-engine-tca : PPPOE Cross Connect Engine TCA related alarm - eth-cfm : eth-cfm related alarms - rsvp : rsvp related alarms - ihub-tca : IHUB TCA related alarms - eth-ring : eth-ring related alarms - efm-oam : EFM-OAM related alarms - ont-loopdetect : ont loop detect related alarms - ont-video : ont services video related alarms - ont-ces : ont services ces related alarms - ont-voip : ont services voip related alarms - ont-video-ani : ont services video ani related alarms - ont-pwe : ont services pwe related alarms - ont-cese1 : ont services cese1 related alarms - ont-xdsl : ont services xdsl related alarms - ont-xdsl-tca : ont services xdsl tca related alarms - ont-hpna : ont hpna related alarms - ont-sip-agent-cfg : ont services voip sip agent config related alarms - ont-voip-cfg : ont services voip config related alarms - ont-mgc : ont mgc related alarms - ont-ploam : ONT PLOAM related alarms - ont-gen : ONT GENERAL related alarms - ont-card : ONT Subscriber Card related alarms - ont-pots : ONT Services POTS related alarms - ont-lan : ONT Services LAN related alarms - ont-moca : ONT MoCA related alarms - ont-tc-tca : ONT TC TCA related alarms - ont-moca-tca : ONT MoCA TCA related alarms - ont-l2uni-eth-tca : ONT L2 UNI Ethernet TCA related alarms - olt-pon-tc-tca : OLT PON TC TCA related alarms - olt-pon-util-tca : OLT PON utilization TCA related alarms - olt-chpr-util-tca : OLT channel-pair utilization TCA related alarms - olt-ont-tc-tca : OLT ONT TC TCA related alarms - ont-tca : ONT TCA related alarms - ont-pots-supplemental : ONT POTS Supplemental related alarms - sfu-ploam : SFU ONT PLOAM related alarms - sfu-gen : SFU ONT general related alarms - soho-ploam : SOHO ONT PLOAM related alarms - soho-gen : SOHO ONT general related alarms - mdu-ploam : MDU ONT PLOAM related alarms - mdu-gen : MDU ONT general related alarms - ont-veip : ONT VEIP related alarms - ont-iphost : ONT IP HOST related alarms - alarm-table : alarm table related alarms - auto-switch : auto-switch related alarms - channel-pair : channel pair related alarms - ont-cfg-dld : ont configure file download related alarms - olt-chpair-tc-tca : OLT CHANNELPAIR TC TCA related alarms - hgu-tr069 : hgu tr069 related alarms - eqpt-psu : equipment psu alarms - ont-protection : ONT protection related alarms	

101 query current alarms by filters

name	Type	Description
	- secondary-megaco-term : secondary megaco termination related alarms - secondary-sip-term : secondary sip termination related alarms - cas-r2-channel : CAS R2 channel related alarms - lldpmed : lldpmed alarms - pseudo-wire : pseudo Wire related alarms - link-agg : Link aggregation related alarms - fcs-exceed : FCS auto-recovery related alarms - e1t1-interface : E1/T1 physical interfaces related alarms	
name	Parameter type: <Alarm::alarmTypeLinkGroup> (la-down la-standby-na la-switch-fail la-degrade all) Possible values: - la-down : Link aggregation link-status is down - la-standby-na : Cross-lt lag on standby slot part is not available - la-switch-fail : Cross-lt lag fail to do switchover - la-degrade : Link aggregation group degrade - all : show all Link aggregation group alarm	alarm name that are active <i>This element is only shown in detail mode.</i>
severity	Parameter type: <Alarm::AlarmSeverity> (indeterminate warning minor major critical) Possible values: - indeterminate : alarm severity is indeterminate - warning : alarm severity is warning - minor : alarm severity is minor - major : alarm severity is major - critical : alarm severity is critical	the alarms severity level <i>This element is only shown in detail mode.</i>
servaff	Parameter type: <Alarm::alarmServAffect> ((service-affecting yes) (noservice-affecting no)) Possible values: - service-affecting : make this alarm service affecting - yes : make this alarm service affecting - noservice-affecting : make this alarm not service affecting - no : make this alarm not service affecting	alarms affect service or not <i>This element is only shown in detail mode.</i>
time	Parameter type: <Sys::timeInSecs> - the time (yyyy-mm-dd:hour:minutes:secs) - unit: UTC	time in seconds when alarm was updated <i>This element is only shown in detail mode.</i>
descript	Parameter type: <Alarm::AddInfoString> - additional alarm information	alarm description <i>This element is only shown in detail mode.</i>

101.145 show current alarm by filters

Command Description

show current alarms by filters

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm query fcs-exceed [ (name) [ severity <Alarm::querySeverity> ] [ servaff <Alarm::queryServAffect> ]
[ board <Equipm::EqptSlotIndex> ] ]
```

Command Parameters

Table 101.145-1 "show current alarm by filters" Resource Parameters

Resource Identifier	Type	Description
(name)	Format: (fcs-thresh-exceed all) Possible values: - fcs-thresh-exceed : FCS counter threshold exceeded - all : show all FCS exceed alarm	alarm name of fcs-exceed
severity	Parameter type: <Alarm::querySeverity> Format: (indeterminate warning minor major critical all) Possible values: - indeterminate : alarm severity is indeterminate - warning : alarm severity is warning - minor : alarm severity is minor - major : alarm severity is major - critical : alarm severity is critical - all : all alarm severity	severity level of alarm for reporting
servaff	Parameter type: <Alarm::queryServAffect> Format: (service-affecting noservice-affecting all) Possible values: - service-affecting : query alarm service affecting	serviceaffecting no

101 query current alarms by filters

Resource Identifier	Type	Description
	- noservice-affecting : query alarm not service affecting - all : query service affecting and not affecting alarms	
board	Parameter type: <Equipm::EqptSlotIndex> Format: (lt : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> nt-a nt-b nt acu : <Eqpt::RackId> / <Eqpt::ShelfId> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::EqSlotId> ext-a : <Eqpt::RackId> / <Eqpt::ShelfId> ext-b : <Eqpt::RackId> / <Eqpt::ShelfId> ctrl : <Eqpt::RackId> / <Eqpt::ShelfId> vlt : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::VirtualSlotId>) Possible values: - lt : lt-slot - vlt : virtual LT slot (VVPS board can only be planned at NANT-E / FANT-F) - nt-a : nt-a slot - nt-b : nt-b slot - nt : nt slot - ext-a : nt-a slot in an extension shelf - ext-b : nt-b slot in an extension shelf - acu : acu slot - ctrl : ctrl-slot Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::VirtualSlotId> - the virtual LT slot number Field type <Eqpt::EqSlotId> - the equipment slot number	the physical number of the slot

Command Output

Table 101.145-2 "show current alarm by filters" Display parameters

Specific Information		
name	Type	Description
aidinfo	Parameter type: <Alarm::AddInfoString> - additional alarm information	alarm AID parameters <i>This element is only shown in detail mode.</i>
type	Parameter type: <Alarm::alarmIHUBType> (equipment eqpt-holder plug-in-unit atm custom e1 ima-group ima-link redundancy shdsl	type of the alarms that are active <i>This element is only shown in detail mode.</i>

name	Type	Description
	ether-itf traffic-overflow qos-queue temporal spatial (software-mngt sw-mgmt) xdsl xdsl-ext xdsl-tca olt-gen eo-conv authentication bonding sfp shdsl-isam custom-ext-alarm plug-in-unit-ext sip-user-agent sip-plugin-unit sip-termination e1-sip-termination filetransfer external-device l2forward ether-tca ether-sfp megaco-media-gw megaco-sig-gw megaco-plug-unit megaco-term megaco-sig-lt eqpt-supplemental eqpt-holder-ext lsmredundancy sync mcsrc vlanport vect-line vect-board otdr sip-dial-plan sip-vsp sip-server bgp rip lag ihub-general vprn isis ospf ihub-l2forward vpls ihub-equip ihub-link eont-phyoam ellid epon	

101 query current alarms by filters

name	Type	Description
	eont-services-lan eolt-ont-tca eont-sw-dl ldp mpls sdp epipe ihub-ipv6 pim li mgmt-sec-access bfd ai tr069serv ontsnmp bulk-sync protection-group ont sfu-sup soho-sup mdu-sup ont-ani sfu-sup2 soho-sup2 mdu-sup2 sfprssi eoltrssi cfm sfpe1t1-framer sfpe1t1-clock pppcc-engine-tca eth-cfm rsvp ihub-tca eth-ring efm-oam ont-loopdetect ont-video ont-ces ont-voip ont-video-ani ont-pwe ont-cese1 ont-xdsl ont-xdsl-tca ont-hpna ont-sip-agent-cfg ont-voip-cfg ont-mgc ont-ploam ont-gen ont-card ont-pots ont-lan ont-moca ont-tc-tca ont-moca-tca	

name	Type	Description
	ont-l2uni-eth-tca olt-pon-tc-tca olt-pon-util-tca olt-chpr-util-tca olt-ont-tc-tca ont-tca ont-pots-supplemental sfu-ploam sfu-gen soho-ploam soho-gen mdu-ploam mdu-gen ont-veip ont-iphost alarm-table auto-switch channel-pair ont-cfg-dld olt-chpair-tc-tca hgu-tr069 eqpt-psu ont-protection secondary-megaco-term secondary-sip-term cas-r2-channel lldpmed pseudo-wire link-agg fcs-exceed e1t1-interface) Possible values: - equipment : equipment alarms - eqpt-holder : equipment holder alarms - plug-in-unit : plugin unit alarms - atm : ATM alarms - custom : customizable alarms - e1 : e1 alarms - ima-group : ima-group alarms - ima-link : ima-link alarms - redundancy : redundancy alarms - shdsl : shdsl alarms - ether-itf : ethernet interface alarms - traffic-overflow : Traffic overflow alarms - qos-queue : qos queue alarms - temporal : temporal alarms - spatial : spatial alarms - software-mngt : software management alarms - sw-mgmt : software management alarms - xdsl : xDSL alarms - xdsl-ext : other xDSL alarms - xdsl-tca : xDSL threshold cross alarms - olt-gen : OLT general alarms - eo-conv : E/O conversion related alarms - authentication : authentication related alarms - bonding : bonding-group related alarms - sfp : SFP related alarms	

101 query current alarms by filters

name	Type	Description
	- shdsl-isam : shdsl isam alarms - custom-ext-alarm : customizable external alarms - plug-in-unit-ext : other plugin unit alarms - sip-user-agent : sip user agent related alarms - sip-plugin-unit : sip plug in unit related alarms - sip-termination : sip termination related alarms - e1-sip-termination : E1 sip termination related alarms - filetransfer : file transfer server alarms - external-device : external device related alarms - l2forward : l2forward related alarms - ether-tca : ethernet threshold cross alarms - ether-sfp : ethernet SFP related alarms - megaco-media-gw : megaco media gateway related alarms - megaco-sig-gw : megaco signaling gateway related alarms - megaco-plug-unit : megaco plug unit related alarms - megaco-term : megaco termination related alarms - megaco-sig-lt : megaco signaling lt related alarms - eqpt-supplemental : equipment supplemental alarms - eqpt-holder-ext : other equipment holder alarms - lsmredundancy : lsm redundancy alarms - sync : synce and bits alarms - mcsrc : multicast source alarms - vlanport : vlanport alarms - vect-line : xDSL vectoring line alarms - vect-board : xDSL vectoring board alarms - otdr : otdr alarms - sip-dial-plan : sip dial plan related alarms - sip-vsp : sip vsp related alarms - sip-server : sip server related alarms - bgp : bgp related alarms - rip : rip related alarms - lag : LAG related alarms - ihub-general : IHUB general related alarms - vprn : vprn related alarms - isis : isis related alarms - ospf : ospf related alarms - ihub-l2forward : ihub-l2forward alarms - vpls : vpls related alarms - ihub-equip : ihub-equip related alarms - ihub-link : ihub-link related alarms - eont-phyoam : eont phyoam related alarms - ellid : ellid related alarms - epon : epon related alarms - eont-services-lan : eon phyoam related alarms - eolt-ont-tca : eon phyoam related alarms - eont-sw-dl : eon phyoam related alarms - ldp : ldp related alarms - mpls : mpls related alarms - sdp : sdp related alarms - epipe : epipe related alarms - ihub-ipv6 : ihub-ipv6 related alarms - pim : pim related alarms - li : lawful intercept related alarms - mgmt-sec-access : management security related alarms - bfd : bfd related alarms - ai : Application Intelligence related alarms - tr069serv : tr069 server related alarms	

name	Type	Description
	- ontsnmp : ont snmp related alarms - bulk-sync : bulk-sync related alarms - protection-group : port protection group related alarms - ont : ONT general supplemental related alarms - sfu-sup : SFU ONT general supplemental related alarms - soho-sup : SOHO ONT general supplemental related alarms - mdu-sup : MDU ONT general supplemental related alarms - ont-ani : ONT general supplemental 2 related alarms - sfu-sup2 : SFU ONT general supplemental 2 related alarms - soho-sup2 : SOHO ONT general supplemental 2 related alarms - mdu-sup2 : MDU ONT general supplemental 2 related alarms - sfprssi : SFP RSSI related alarms - eoltrssi : epon olt Sfp RSSI related alarms - cfm : Cfm related alarms - sfpe1t1-framer : SFP 2e1t1 framer alarms - sfpe1t1-clock : SFP 2e1t1 clock alarms - pppcc-engine-tca : PPPOE Cross Connect Engine TCA related alarm - eth-cfm : eth-cfm related alarms - rsvp : rsvp related alarms - ihub-tca : IHUB TCA related alarms - eth-ring : eth-ring related alarms - efm-oam : EFM-OAM related alarms - ont-loopdetect : ont loop detect related alarms - ont-video : ont services video related alarms - ont-ces : ont services ces related alarms - ont-voip : ont services voip related alarms - ont-video-ani : ont services video ani related alarms - ont-pwe : ont services pwe related alarms - ont-cese1 : ont services cese1 related alarms - ont-xdsl : ont services xdsl related alarms - ont-xdsl-tca : ont services xdsl tca related alarms - ont-hpna : ont hpna related alarms - ont-sip-agent-cfg : ont services voip sip agent config related alarms - ont-voip-cfg : ont services voip config related alarms - ont-mgc : ont mgc related alarms - ont-ploam : ONT PLOAM related alarms - ont-gen : ONT GENERAL related alarms - ont-card : ONT Subscriber Card related alarms - ont-pots : ONT Services POTS related alarms - ont-lan : ONT Services LAN related alarms - ont-moca : ONT MoCA related alarms - ont-tc-tca : ONT TC TCA related alarms - ont-moca-tca : ONT MoCA TCA related alarms - ont-l2uni-eth-tca : ONT L2 UNI Ethernet TCA related alarms - olt-pon-tc-tca : OLT PON TC TCA related alarms - olt-pon-util-tca : OLT PON utilization TCA related alarms - olt-chpr-util-tca : OLT channel-pair utilization TCA related alarms - olt-ont-tc-tca : OLT ONT TC TCA related alarms - ont-tca : ONT TCA related alarms - ont-pots-supplemental : ONT POTS Supplemental related	

101 query current alarms by filters

name	Type	Description
	alarms - sfu-ploam : SFU ONT PLOAM related alarms - sfu-gen : SFU ONT general related alarms - soho-ploam : SOHO ONT PLOAM related alarms - soho-gen : SOHO ONT general related alarms - mdu-ploam : MDU ONT PLOAM related alarms - mdu-gen : MDU ONT general related alarms - ont-veip : ONT VEIP related alarms - ont-iphost : ONT IP HOST related alarms - alarm-table : alarm table related alarms - auto-switch : auto-switch related alarms - channel-pair : channel pair related alarms - ont-cfg-dld : ont configure file download related alarms - olt-chpair-tc-tca : OLT CHANNELPAIR TC TCA related alarms - hgu-tr069 : hgu tr069 related alarms - eqpt-psu : equipment psu alarms - ont-protection : ONT protection related alarms - secondary-megaco-term : secondary megaco termination related alarms - secondary-sip-term : secondary sip termination related alarms - cas-r2-channel : CAS R2 channel related alarms - lldpmed : lldpmed alarms - pseudo-wire : pseudo Wire related alarms - link-agg : Link aggregation related alarms - fcs-exceed : FCS auto-recovery related alarms - e1t1-interface : E1/T1 physical interfaces related alarms	
name	Parameter type: <Alarm::alarmTypeFCSexceed> (fcs-thresh-exceed all) Possible values: - fcs-thresh-exceed : FCS counter threshold exceeded - all : show all FCS exceed alarm	alarm name that are active <i>This element is only shown in detail mode.</i>
severity	Parameter type: <Alarm::AlarmSeverity> (indeterminate warning minor major critical) Possible values: - indeterminate : alarm severity is indeterminate - warning : alarm severity is warning - minor : alarm severity is minor - major : alarm severity is major - critical : alarm severity is critical	the alarms severity level <i>This element is only shown in detail mode.</i>
servaff	Parameter type: <Alarm::alarmServAffect> ((service-affecting yes) (noservice-affecting no)) Possible values: - service-affecting : make this alarm service affecting - yes : make this alarm service affecting - noservice-affecting : make this alarm not service affecting - no : make this alarm not service affecting	alarms affect service or not <i>This element is only shown in detail mode.</i>
time	Parameter type: <Sys::timeInSecs> - the time (yyyy-mm-dd:hour:minutes:secs) - unit: UTC	time in seconds when alarm was updated <i>This element is only shown in</i>

101 query current alarms by filters

name	Type	Description
		<i>detail mode.</i>
descript	Parameter type: <Alarm::AddInfoString> - additional alarm information	alarm description <i>This element is only shown in detail mode.</i>

102- Alarm Log Status Commands

102.1 Alarm Log Status Command Tree	102-3902
102.2 Alarm Log Status Command	102-3908
102.3 Equipment Alarm Log Status Command	102-3915
102.4 Equipment Holder Alarm Log Status Command	102-3919
102.5 Equipment Holder Extended Alarm Log Status Command	102-3923
102.6 Plug-in Unit Alarm Log Status Command	102-3926
102.7 ATM Alarm Log Status Command	102-3931
102.8 Ethernet Interface Alarm Log Status Command	102-3933
102.9 Software Management Alarm Log Status Command	102-3935
102.10 Temporal Filter Alarm Log Status Command	102-3938
102.11 Spatial Filter Alarm Log Status Command	102-3946
102.12 xDSL Common Alarm Log Status Command	102-3954
102.13 xDSL Near-end Alarm Log Status Command	102-3957
102.14 xDSL Far-end Alarm Log Status Command	102-3960
102.15 TCA xDSL Alarm Log Status Command	102-3964
102.16 Protection Group Alarm Log Status Command	102-3971
102.17 Vectoring Line Alarm Log Status Command	102-3975
102.18 Vectoring Board Alarm Log Status Command	102-3978
102.19 Electrical-to-Optical Conversion Alarm Log Status Command	102-3981
102.20 Authentication Alarm Log Status Command	102-3983
102.21 xDSL Bonding Alarm Log Status Command	102-3986
102.22 Redundancy Alarm Log Status Command	102-3990
102.23 Custom Alarm Log Status Command	102-3992
102.24 SFP Alarm Log Status Command	102-3998
102.25 Custom External Alarm Log Status Command	102-4002
102.26 SFP RSSI for NT Alarm Log Status Command	102-4004
102.27 PPP Cross-Connect Engine TCA Alarm Log Status Command	102-4009
102.28 Epon Olt Sfp RSSI Log Alarm Status Command	102-4011
102.29 2xE1/DS1 SFP Clock Alarm Log Status Command	102-4015
102.30 2xE1/DS1 SFP Framer Alarm Log Status Command	102-4018
102.31 Plug In Unit Extended Alarm Log Status Command	102-4022
102.32 SIP Server Alarm Log Status Commands	102-4027
102.33 SIP VSP Alarm Log Status Commands	102-4029
102.34 SIP Dial Plan Alarm Log Status Commands	102-4033
102.35 SIP User Agent Alarm Log Status Commands	102-4034
102.36 SIP Slot Alarm Log Status Commands	102-4036
102.37 SIP Termination Alarm Log Status Commands	102-4038
102.38 Secondary SIP Termination Alarm Log Status Command	102-4043
102.39 SIP Termination Alarm Log Status Commands	102-4047
102.40 E1/T1 Interface Alarm Log Status Commands	102-4051
102.41 SIP Termination Alarm Log Status Commands	102-4053
102.42 Pseudo Wire Alarm Log Status Command	102-4055
102.43 E1 Alarm Log Status Command	102-4057
102.44 Shdsl Alarm Log Status Command	102-4060
102.45 Shdsl Alarm Log Status Command	102-4063
102.46 Megaco Media Gateway Alarm Log Status	102-4066

Command	
102.47 Megaco Signaling Gateway Alarm Log Status Command	102-4068
102.48 Megaco Plug Unit Alarm Log Status Command	102-4069
102.49 Megaco Termination Alarm Log Status Command	102-4071
102.50 Secondary Megaco Termination Alarm Log Status Command	102-4074
102.51 Megaco Signaling Lt Alarm Log Status Command	102-4076
102.52 Ima-Group Alarm Log Status Command	102-4078
102.53 Ima-Link Alarm Log Status Command	102-4081
102.54 Ether-Tca Alarm Log Status Command	102-4084
102.55 Ether-Sfp Alarm Log Status Command	102-4087
102.56 Ether-Sfp Alarm Log Status Command	102-4090
102.57 Alarm Qos Slot Log Status Commands	102-4093
102.58 Ellid Alarm Status Command	102-4096
102.59 Alarm Qos Queue Log Status Commands	102-4105
102.60 Log File Transfer Server Alarm Log Status Command	102-4108
102.61 Log Lsm Redundancy Alarm Log Status Command	102-4110
102.62 Log L2 Forward Alarm Log Status Command	102-4112
102.63 External Device Alarm Log Status Command	102-4115
102.64 Multicast Source Alarm Log Status Command	102-4117
102.65 Vlanport Alarm Log Status Command	102-4119
102.66 BGP Alarm Log Status Command	102-4122
102.67 RIP Alarm Log Status Command	102-4124
102.68 LAG Alarm Log Status Command	102-4126
102.69 ihub-general Alarm Log Status Command	102-4128
102.70 VPRN Alarm Log Status Command	102-4131
102.71 ISIS Alarm Log Status Command	102-4133
102.72 Ospf Alarm Log Status Command	102-4135
102.73 ihub-l2forward Alarm Log Status Command	102-4138
102.74 Vpls Alarm Log Status Command	102-4141
102.75 IHUB-Eqip Alarm Log Status Command	102-4144
102.76 IHUB-Link Alarm Log Status Command	102-4147
102.77 IHUB-Tca Alarm Log Status Command	102-4150
102.78 LDP Alarm Log Status Command	102-4155
102.79 MPLS Alarm Log Status Command	102-4157
102.80 SDP Alarm Log Status Command	102-4159
102.81 IHUB IPV6 Alarm Log Status Command	102-4161
102.82 EPIPE Alarm Log Status Command	102-4163
102.83 PIM Alarm Log Status Command	102-4165
102.84 IHUB Lawful Intercept Alarm Log Status Command	102-4167
102.85 Sync Clock Alarm Log Status Command	102-4169
102.86 Equipment Supplemental Alarm Log Status Command	102-4175
102.87 Otdr Alarm Log Status Command	102-4177
102.88 Management Security Access Alarm Log Status Command	102-4183
102.89 IHUB BFD Alarm Log Status Command	102-4185
102.90 Application Intelligence Alarm Log Status Command	102-4187
102.91 ONT SNMP Alarm Log Status Command	102-4189
102.92 Tr069 Alarm Status Command	102-4191
102.93 Bulk Sync Alarm Log Status Command	102-4193
102.94 Protection Group Alarm Log Status Command	102-4195
102.95 Ont protection Alarm Log Status Command	102-4197
102.96 ONT General Supplemental Alarm Log Status Command	102-4199
102.97 SFU ONT General Supplemental Alarm Log Status Command	102-4203
102.98 SOHO ONT General Supplemental Alarm Log Status Command	102-4207

102.99 MDU ONT General Supplemental Alarm Log Status Command	102-4211
102.100 ONT General Supplemental 2 Alarm Log Status Command	102-4215
102.101 SFU ONT General Supplemental 2 Alarm Log Status Command	102-4218
102.102 SOHO ONT General Supplemental 2 Alarm Log Status Command	102-4221
102.103 MDU ONT General Supplemental 2 Alarm Log Status Command	102-4224
102.104 Ima-Group Alarm Log Status Command	102-4227
102.105 LT CFM Alarm Log Status Command	102-4234
102.106 IHUB CFM Alarm Log Status Command	102-4236
102.107 RSVP Alarm Log Status Command	102-4238
102.108 IPD eth-ring Alarm Log Status Command	102-4240
102.109 EFM-OAM Alarm Log Status Command	102-4242
102.110 ont loop detect Alarm Log Status Command	102-4244
102.111 ONT PLOAM Alarm Log Status Command	102-4247
102.112 SFU ONT PLOAM Alarm Log Status Command	102-4251
102.113 SOHO ONT PLOAM Alarm Log Status Command	102-4255
102.114 MDU ONT PLOAM Alarm Log Status Command	102-4259
102.115 ONT General Alarm Log Status Command	102-4263
102.116 SFU ONT General Alarm Log Status Command	102-4267
102.117 SOHO ONT General Alarm Log Status Command	102-4271
102.118 MDU ONT General Alarm Log Status Command	102-4275
102.119 ONT SUBSCRIBER CARD Alarm Log Status Command	102-4279
102.120 ONT SERVICES POTS Alarm Log Status Command	102-4282
102.121 ONT SERVICES LAN Alarm Log Status Command	102-4287
102.122 ONT TC TCA Alarm Log Status Command	102-4289
102.123 ONT TCA Alarm Log Status Command	102-4291
102.124 ONT L2 UNI Ethernet TCA Alarm Log Status Command	102-4293
102.125 OLT PON TC TCA Alarm Log Status Command	102-4295
102.126 OLT PON Utilization TCA Alarm Log Status Command	102-4297
102.127 OLT Channel Pair Utilization TCA Alarm Log Status Command	102-4301
102.128 OLT ONT TC TCA Alarm Log Status Command	102-4305
102.129 ONT POTS SUPPLEMENTAL Alarm Log Status Command	102-4307
102.130 ONT VEIP Alarm Log Status Command	102-4310
102.131 ONT IP HOST Alarm Log Status Command	102-4312
102.132 Alarm Table Alarm Log Status Command	102-4314
102.133 ONT VIDEO Alarm Log Status Command	102-4316
102.134 ONT CES Alarm Log Status Command	102-4318
102.135 ONT VOIP Alarm Log Status Command	102-4321
102.136 ONT VIDEO ANI Alarm Log Status Command	102-4326
102.137 ONT PWE Alarm Log Status Command	102-4328
102.138 ONT CESE1 Alarm Log Status Command	102-4331
102.139 ONT XDSL Alarm Log Status Command	102-4333
102.140 ONT XDSL TCA Alarm Log Status Command	102-4336
102.141 ONT HPNA Alarm Log Status Command	102-4339
102.142 ONT SIP AGENT CFG Alarm Log Status Command	102-4341
102.143 ONT VOIP CFG Alarm Log Status Command	102-4344
102.144 ONT MGC Alarm Log Status Command	102-4348
102.145 ONT MoCA Alarm Log Status Command	102-4350
102.146 ONT MoCA Threshold Crossing Alert (TCA) Alarm Log Command	102-4352
102.147 Auto-Switch Alarm Log Status command	102-4354
102.148 Channel Pair Alarm Log Status Command	102-4358

102.149 Channel Pair OLT TC TCA Alarm Log Status Command	102-4362
102.150 Ont Configuration Download Alarm Log Status Command	102-4364
102.151 HGU TR069 Alarm Log Status Command	102-4367
102.152 Equipment Holder Extended Alarm Log Status Command	102-4375
102.153 Ethernet Ring Alarm Log Status Command	102-4378
102.154 Lldpmed Alarm Log Status Command	102-4380
102.155 Lag group Alarm Log Status Command	102-4382
102.156 40GBase-KR4 fcs exceed Alarm Log Status Command	102-4384

102.1 Alarm Log Status Command Tree

Description

This chapter gives an overview of nodes that are handled by "Alarm Log Status Commands".

Command Tree

```
----show
  ----alarm
    ----log
      ----table
        - (index)
      ----equipment
        - (index)
      ----eqpt-holder
        - (index)
      ----eqpt-holder-ext
        - (index)
      ----plug-in-unit
        - (index)
      ----atm
        - (index)
      ----ether-itf
        - (index)
      ----sw-mgmt
        - (index)
      ----temporal
        - (index)
      ----spatial
        - (index)
      ----xdsl
        ----misc
          - (index)
        ----near-end
          - (index)
        ----far-end
          - (index)
      ----xdsl-tca
        - (index)
      ----olt-gen
        - (index)
      ----vect-line
        - (index)
      ----vect-board
        - (index)
      ----eo-conversion
        - (index)
      ----authentication
        - (index)
      ----bonding-group
        - (index)
      ----redundancy
        - (index)
```


- custom**
 - (index)
- sfp**
 - (index)
- custom-ext-alarm**
 - (index)
- sfprssi**
 - (index)
- pppcc-engine-tca**
 - (index)
- eoltrssi**
 - (index)
- sfpe1t1-clock**
 - (index)
- sfpe1t1-framer**
 - (index)
- plug-in-unit-ext**
 - (index)
- sip-server**
 - (index)
- sip-vsp**
 - (index)
- sip-dial-plan**
 - (index)
- sip-user-agent**
 - (index)
- sip-plugin-unit**
 - (index)
- sip-termination**
 - (index)
- secondary-sip-term**
 - (index)
- e1-sip-termination**
 - (index)
- e1t1-interface**
 - (index)
- cas-r2-channel**
 - (index)
- pseudo-wire**
 - (index)
- e1**
 - (index)
- shdsl**
 - (index)
- shdsl-isam**
 - (index)
- megaco-media-gw**
 - (index)
- megaco-sig-gw**
 - (index)
- megaco-plug-unit**
 - (index)
- megaco-term**
 - (index)
- secondary-megaco-term**
 - (index)
- megaco-sig-lt**
 - (index)
- ima-group**

- (index)
- ima-link**
- (index)
- ether-tca**
- (index)
- ether-sfp**
- (index)
- uplink-ether-sfp**
- (index)
- qos-slot**
- (index)
- ellid**
- (alarm-index)
- qos-queue**
- (index)
- filetransfer**
- (index)
- lsmredundancy**
- (index)
- l2forward**
- (index)
- external-device**
- (index)
- mcsrc**
- (index)
- vlanport**
- (index)
- bgp**
- (index)
- rip**
- (index)
- lag**
- (index)
- ihub-general**
- (index)
- vpn**
- (index)
- isis**
- (index)
- ospf**
- (index)
- ihub-l2forward**
- (index)
- vpls**
- (index)
- ihub-equip**
- (index)
- ihub-link**
- (index)
- ihub-tca**
- (index)
- ldp**
- (index)
- mpls**
- (index)
- sdp**
- (index)
- ihub-ipv6**
- (index)

- epipe**
 - (index)
- pim**
 - (index)
- li**
 - (index)
- sync**
 - (index)
- eqpt-supplemental**
 - (index)
- otdr**
 - (index)
- mgmt-sec-access**
 - (index)
- bfd**
 - (index)
- ai**
 - (index)
- ontsnmp**
 - (index)
- tr069serv**
 - (index)
- bulk-sync**
 - (index)
- protection-group**
 - (index)
- ont-protection**
 - (index)
- ont**
 - (index)
- sfu-sup**
 - (index)
- soho-sup**
 - (index)
- mdu-sup**
 - (index)
- ont-ani**
 - (index)
- sfu-sup2**
 - (index)
- soho-sup2**
 - (index)
- mdu-sup2**
 - (index)
- epon**
 - (alarm-index)
- cfm**
 - (index)
- eth-cfm**
 - (index)
- rsvp**
 - (index)
- eth-ring**
 - (index)
- efm-oam**
 - (index)
- ont-loopdetect**
 - (index)
- ont-ploam**

- (index)
- sfu-ploam
 - (index)
- soho-ploam
 - (index)
- mdu-ploam
 - (index)
- ont-gen
 - (index)
- sfu-gen
 - (index)
- soho-gen
 - (index)
- mdu-gen
 - (index)
- ont-card
 - (index)
- ont-pots
 - (index)
- ont-lan
 - (index)
- ont-tc-tca
 - (index)
- ont-tca
 - (index)
- ont-l2uni-eth-tca
 - (index)
- olt-pon-tc-tca
 - (index)
- olt-pon-util-tca
 - (index)
- olt-chpr-util-tca
 - (index)
- olt-ont-tc-tca
 - (index)
- ont-pots-supplemental
 - (index)
- ont-veip
 - (index)
- ont-iphost
 - (index)
- alarm-table
 - (index)
- ont-video
 - (index)
- ont-ces
 - (index)
- ont-voip
 - (index)
- ont-video-ani
 - (index)
- ont-pwe
 - (index)
- ont-cese1
 - (index)
- ont-xdsl
 - (index)
- ont-xdsl-tca
 - (index)

- ont-hpna
 - (index)
- ont-sip-agent-cfg
 - (index)
- ont-voip-cfg
 - (index)
- ont-mgc
 - (index)
- ont-moca
 - (index)
- ont-moca-tca
 - (index)
- auto-switch
 - (index)
- channel-pair
 - (index)
- olt-chpair-tc-tca
 - (index)
- ont-cfg-dld
 - (index)
- hgu-tr069
 - (index)
- eqpt-psu
 - (index)
- ethernet-ring
 - (index)
- lldpmed
 - (index)
- link-agg
 - (index)
- fcs-exceed
 - (index)

102.2 Alarm Log Status Command

Command Description

This command displays the alarm log entries.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

> show alarm log table [(index)]

Command Parameters

Table 102.2-1 "Alarm Log Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm log table index

Command Output

Table 102.2-2 "Alarm Log Status Command" Display parameters

Specific Information		
name	Type	Description
type	Parameter type: <Alarm::alarmIHUBType> (equipment eqpt-holder plug-in-unit atm custom e1 ima-group ima-link redundancy shdsl ether-itf traffic-overflow qos-queue temporal spatial (software-mngt sw-mgmt) xdsl xdsl-ext xdsl-tca	unique id for an alarm. <i>This element is always shown.</i>

name	Type	Description
	olt-gen	
	eo-conv	
	authentication	
	bonding	
	sfp	
	shdsl-isam	
	custom-ext-alarm	
	plug-in-unit-ext	
	sip-user-agent	
	sip-plugin-unit	
	sip-termination	
	e1-sip-termination	
	filetransfer	
	external-device	
	l2forward	
	ether-tca	
	ether-sfp	
	megaco-media-gw	
	megaco-sig-gw	
	megaco-plug-unit	
	megaco-term	
	megaco-sig-lt	
	eqpt-supplemental	
	eqpt-holder-ext	
	lsmredundancy	
	sync	
	mcsrc	
	vlanport	
	vect-line	
	vect-board	
	otdr	
	sip-dial-plan	
	sip-vsp	
	sip-server	
	bgp	
	rip	
	lag	
	ihub-general	
	vprn	
	isis	
	ospf	
	ihub-l2forward	
	vpls	
	ihub-equip	
	ihub-link	
	eont-phyoam	
	ellid	
	epon	
	eont-services-lan	
	eolt-ont-tca	
	eont-sw-dl	
	ldp	
	mpls	
	sdp	
	epipe	
	ihub-ipv6	
	pim	

102 Alarm Log Status Commands

name	Type	Description
	li	
	mgmt-sec-access	
	bfd	
	ai	
	tr069serv	
	ontsnmp	
	bulk-sync	
	protection-group	
	ont	
	sfu-sup	
	soho-sup	
	mdu-sup	
	ont-ani	
	sfu-sup2	
	soho-sup2	
	mdu-sup2	
	sfprssi	
	eoltrssi	
	cfm	
	sfpe1t1-framer	
	sfpe1t1-clock	
	pppcc-engine-tca	
	eth-cfm	
	rsvp	
	ihub-tca	
	eth-ring	
	efm-oam	
	ont-loopdetect	
	ont-video	
	ont-ces	
	ont-voip	
	ont-video-ani	
	ont-pwe	
	ont-cese1	
	ont-xdsl	
	ont-xdsl-tca	
	ont-hpna	
	ont-sip-agent-cfg	
	ont-voip-cfg	
	ont-mgc	
	ont-ploam	
	ont-gen	
	ont-card	
	ont-pots	
	ont-lan	
	ont-moca	
	ont-tc-tca	
	ont-moca-tca	
	ont-l2uni-eth-tca	
	olt-pon-tc-tca	
	olt-pon-util-tca	
	olt-chpr-util-tca	
	olt-ont-tc-tca	
	ont-tca	
	ont-pots-supplemental	
	sfu-ploam	
	sfu-gen	

name	Type	Description
	soho-ploam soho-gen mdu-ploam mdu-gen ont-veip ont-iphost alarm-table auto-switch channel-pair ont-cfg-dld olt-chpair-tc-tca hgu-tr069 eqpt-psu ont-protection secondary-megaco-term secondary-sip-term cas-r2-channel lldpmed pseudo-wire link-agg fcs-exceed e1t1-interface) Possible values: - equipment : equipment alarms - eqpt-holder : equipment holder alarms - plug-in-unit : plugin unit alarms - atm : ATM alarms - custom : customizable alarms - e1 : e1 alarms - ima-group : ima-group alarms - ima-link : ima-link alarms - redundancy : redundancy alarms - shdsl : shdsl alarms - ether-itf : ethernet interface alarms - traffic-overflow : Traffic overflow alarms - qos-queue : qos queue alarms - temporal : temporal alarms - spatial : spatial alarms - software-mngt : software management alarms - sw-mgmt : software management alarms - xdsl : xDSL alarms - xdsl-ext : other xDSL alarms - xdsl-tca : xDSL threshold cross alarms - olt-gen : OLT general alarms - eo-conv : E/O conversion related alarms - authentication : authentication related alarms - bonding : bonding-group related alarms - sfp : SFP related alarms - shdsl-isam : shdsl isam alarms - custom-ext-alarm : customizable external alarms - plug-in-unit-ext : other plugin unit alarms - sip-user-agent : sip user agent related alarms - sip-plugin-unit : sip plug in unit related alarms - sip-termination : sip termination related alarms - e1-sip-termination : E1 sip termination related alarms - filetransfer : file transfer server alarms - external-device : external device related alarms	

102 Alarm Log Status Commands

name	Type	Description
	- l2forward : l2forward related alarms - ether-tca : ethernet threshold cross alarms - ether-sfp : ethernet SFP related alarms - megaco-media-gw : megaco media gateway related alarms - megaco-sig-gw : megaco signaling gateway related alarms - megaco-plug-unit : megaco plug unit related alarms - megaco-term : megaco termination related alarms - megaco-sig-lt : megaco signaling lt related alarms - eqpt-supplemental : equipment supplemental alarms - eqpt-holder-ext : other equipment holder alarms - lsmredundancy : lsm redundancy alarms - sync : synce and bits alarms - mcsrc : multicast source alarms - vlanport : vlanport alarms - vect-line : xDSL vectoring line alarms - vect-board : xDSL vectoring board alarms - otdr : otdr alarms - sip-dial-plan : sip dial plan related alarms - sip-vsp : sip vsp related alarms - sip-server : sip server related alarms - bgp : bgp related alarms - rip : rip related alarms - lag : LAG related alarms - ihub-general : IHUB general related alarms - vprn : vprn related alarms - isis : isis related alarms - ospf : ospf related alarms - ihub-l2forward : ihub-l2forward alarms - vpls : vpls related alarms - ihub-equip : ihub-equip related alarms - ihub-link : ihub-link related alarms - eont-phyoam : eont phyoam related alarms - ellid : ellid related alarms - epon : epon related alarms - eont-services-lan : eon phyoam related alarms - eolt-ont-tca : eon phyoam related alarms - eont-sw-dl : eon phyoam related alarms - ldp : ldp related alarms - mpls : mpls related alarms - sdp : sdp related alarms - epipe : epipe related alarms - ihub-ipv6 : ihub-ipv6 related alarms - pim : pim related alarms - li : lawful intercept related alarms - mgmt-sec-access : management security related alarms - bfd : bfd related alarms - ai : Application Intelligence related alarms - tr069serv : tr069 server related alarms - ontsnmp : ont snmp related alarms - bulk-sync : bulk-sync related alarms - protection-group : port protection group related alarms - ont : ONT general supplemental related alarms - sfu-sup : SFU ONT general supplemental related alarms - soho-sup : SOHO ONT general supplemental related alarms - mdv-sup : MDU ONT general supplemental related alarms - ont-ani : ONT general supplemental 2 related alarms	

name	Type	Description
	- sfu-sup2 : SFU ONT general supplemental 2 related alarms - soho-sup2 : SOHO ONT general supplemental 2 related alarms - mdu-sup2 : MDU ONT general supplemental 2 related alarms - sfprssi : SFP RSSI related alarms - eoltrssi : epon olt Sfp RSSI related alarms - cfm : Cfm related alarms - sfpe1t1-framer : SFP 2e1t1 framer alarms - sfpe1t1-clock : SFP 2e1t1 clock alarms - pppcc-engine-tca : PPPOE Cross Connect Engine TCA related alarm - eth-cfm : eth-cfm related alarms - rsvp : rsvp related alarms - ihub-tca : IHUB TCA related alarms - eth-ring : eth-ring related alarms - efm-oam : EFM-OAM related alarms - ont-loopdetect : ont loop detect related alarms - ont-video : ont services video related alarms - ont-ces : ont services ces related alarms - ont-voip : ont services voip related alarms - ont-video-ani : ont services video ani related alarms - ont-pwe : ont services pwe related alarms - ont-cese1 : ont services cese1 related alarms - ont-xdsl : ont services xdsl related alarms - ont-xdsl-tca : ont services xdsl tca related alarms - ont-hpna : ont hpna related alarms - ont-sip-agent-cfg : ont services voip sip agent config related alarms - ont-voip-cfg : ont services voip config related alarms - ont-mgc : ont mgc related alarms - ont-ploam : ONT PLOAM related alarms - ont-gen : ONT GENERAL related alarms - ont-card : ONT Subscriber Card related alarms - ont-pots : ONT Services POTS related alarms - ont-lan : ONT Services LAN related alarms - ont-moca : ONT MoCA related alarms - ont-tc-tca : ONT TC TCA related alarms - ont-moca-tca : ONT MoCA TCA related alarms - ont-l2uni-eth-tca : ONT L2 UNI Ethernet TCA related alarms - olt-pon-tc-tca : OLT PON TC TCA related alarms - olt-pon-util-tca : OLT PON utilization TCA related alarms - olt-chpr-util-tca : OLT channel-pair utilization TCA related alarms - olt-ont-tc-tca : OLT ONT TC TCA related alarms - ont-tca : ONT TCA related alarms - ont-pots-supplemental : ONT POTS Supplemental related alarms - sfu-ploam : SFU ONT PLOAM related alarms - sfu-gen : SFU ONT general related alarms - soho-ploam : SOHO ONT PLOAM related alarms - soho-gen : SOHO ONT general related alarms - mdu-ploam : MDU ONT PLOAM related alarms - mdu-gen : MDU ONT general related alarms - ont-veip : ONT VEIP related alarms - ont-iphost : ONT IP HOST related alarms	

102 Alarm Log Status Commands

name	Type	Description
	- alarm-table : alarm table related alarms - auto-switch : auto-switch related alarms - channel-pair : channel pair related alarms - ont-cfg-dld : ont configure file download related alarms - olt-chpair-tc-tca : OLT CHANNELPAIR TC TCA related alarms - hgu-tr069 : hgu tr069 related alarms - eqpt-psu : equipment psu alarms - ont-protection : ONT protection related alarms - secondary-megaco-term : secondary megaco termination related alarms - secondary-sip-term : secondary sip termination related alarms - cas-r2-channel : CAS R2 channel related alarms - lldpmed : lldpmed alarms - pseudo-wire : pseudo Wire related alarms - link-agg : Link aggregation related alarms - fcs-exceed : FCS auto-recovery related alarms - e1t1-interface : E1/T1 physical interfaces related alarms	
last-updated-on	Parameter type: <Sys::timeInSecs> - the time (yyyy-mm-dd:hour:minutes:secs) - unit: UTC	network time in seconds when the alarm was logged. <i>This element is always shown.</i>

Only Show Details: alarm log table related information		
name	Type	Description
last-entry-index	Parameter type: <SignedInteger> - a signed integer	index of the last entry that was added to the log table. <i>This element is only shown in detail mode.</i>
log-was-reset-on	Parameter type: <Sys::Time> - the time (yyyy-mm-dd:hour:minutes:secs) - unit: UTC	time when the alarm log was last reset. <i>This element is only shown in detail mode.</i>
log-buffer-size	Parameter type: <UnsignedSignedInteger> - an unsigned integer	size of the internal log buffer. <i>This element is only shown in detail mode.</i>
log-overflowed	Parameter type: <Alarm::OverflowStatus> (yes no) Possible values: - yes : buffer has overflowed - no : no buffer overflow	specifies whether log table is overflowed or not. <i>This element is only shown in detail mode.</i>

102.3 Equipment Alarm Log Status Command

Command Description

This command displays the equipment alarm log status.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

> show alarm log equipment [(index)]

Command Parameters

Table 102.3-1 "Equipment Alarm Log Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm log table index

Command Output

Table 102.3-2 "Equipment Alarm Log Status Command" Display parameters

Specific Information		
name	Type	Description
last-updated-on	Parameter type: <Sys::timeInSecs> - the time (yyyy-mm-dd:hour:minutes:secs) - unit: UTC	network time in seconds when the alarm was logged. <i>This element is only shown in detail mode.</i>

Only Show Details: current and previous alarm log status		
name	Type	Description
cf-error	Parameter type: <Alarm::cfError> ((error cfError) (no-error cfNoError)) Possible values: - error : CF access error - cfError : CF access error - no-error : CF no access error - cfNoError : CF no access error	Compact flash read or write error occurred <i>This element is only shown in detail mode.</i>
board-with-cf-error	Parameter type: <Equipm::EqptNtSlotIndexOrNone> (nt-a nt-b nt <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::EqSlotId>	Board identification with cf-error <i>This element is only shown in detail mode.</i>

102 Alarm Log Status Commands

name	Type	Description
	none none) Possible values: - nt-a : nt-a slot - nt-b : nt-b slot - nt : nt slot - none : board not specified - none : board not specified Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::EqSlotId> - the equipment slot number	
nt-disk	Parameter type: <Alarm::ntDiskSpace> ((nintyfive-perc 95%-full) (less-nintyfive-perc less-than-95%)) Possible values: - nintyfive-perc : NT disk space is 95% full - 95%-full : NT disk space is 95% full - less-nintyfive-perc : NT disk space usage less that 95% - less-than-95% : NT disk space usage less that 95%	current status of nt disk space is 95% full or less than that <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::ntDiskSpace> ((nintyfive-perc 95%-full) (less-nintyfive-perc less-than-95%)) Possible values: - nintyfive-perc : NT disk space is 95% full - 95%-full : NT disk space is 95% full - less-nintyfive-perc : NT disk space usage less that 95% - less-than-95% : NT disk space usage less that 95%	status of nt disk space with its previous logged value. <i>This element is only shown in detail mode.</i>
persist-data	Parameter type: <Alarm::persistDataLoss> (lost not-lost) Possible values: - lost : persistant data is lost - not-lost : persistant data is not lost	current status specifying persistant data is lost or not <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::persistDataLoss> (lost not-lost) Possible values: - lost : persistant data is lost - not-lost : persistant data is not lost	status of persist-data with its previous logged value. <i>This element is only shown in detail mode.</i>
sntp-comm	Parameter type: <Alarm::sntpCommLoss> (lost not-lost) Possible values: - lost : SNTP communication lost - not-lost : SNTP communication is not lost	current status of sntp communication is lost or not <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::sntpCommLoss> (lost not-lost) Possible values: - lost : SNTP communication lost - not-lost : SNTP communication is not lost	status of sntp communication with its previous logged value. <i>This element is only shown in detail mode.</i>
preferred-mode short name: pref-mode	Parameter type: <Alarm::clkPrefMode> (not-available available)	current status of preferred timing mode <i>This element is only shown in</i>

name	Type	Description
	Possible values: - not-available : Preferred timing mode is not available - available : Preferred Timing mode available	<i>detail mode.</i>
prev-status	Parameter type: <Alarm::clkPrefMode> (not-available available) Possible values: - not-available : Preferred timing mode is not available - available : Preferred Timing mode available	status of preferred timing mode with its previous logged value. <i>This element is only shown in detail mode.</i>
timing-reference short name: time-ref	Parameter type: <Alarm::clkFreeMode> (failed available) Possible values: - failed : System is in holdover or free-run mode - available : System is not in holdover or free-run mode	current status of timing reference <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::clkFreeMode> (failed available) Possible values: - failed : System is in holdover or free-run mode - available : System is not in holdover or free-run mode	status of timing reference with its previous logged value <i>This element is only shown in detail mode.</i>
connection-lost short name: conn-lost	Parameter type: <Alarm::ShubLoc> (lost not-lost) Possible values: - lost : NT shub communication lost - not-lost : NT shub communication intact	current status of nt shub communication is lost or intact <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::ShubLoc> (lost not-lost) Possible values: - lost : NT shub communication lost - not-lost : NT shub communication intact	status of nt shub communication with its previous logged value. <i>This element is only shown in detail mode.</i>
back-pnl-inv short name: bpnl-inv	Parameter type: <Alarm::BackPnlInv> (invalid valid) Possible values: - invalid : BackPanel-type Invalid - valid : BackPanel-type Valid	current status of BackPanel-type Invalid alarm. <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::BackPnlInv> (invalid valid) Possible values: - invalid : BackPanel-type Invalid - valid : BackPanel-type Valid	status of BackPanel-type Invalid alarm with its previous logged value. <i>This element is only shown in detail mode.</i>
shub-conf-lost short name: conf-lost	Parameter type: <Alarm::SHubCfgLost> (lost not-lost) Possible values: - lost : SHub configuration loss - recent changes lost - not-lost : SHub configuration up to date	actual shub configuration may differ from lanx database on nt <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::SHubCfgLost> (lost not-lost) Possible values: - lost : SHub configuration loss - recent changes lost - not-lost : SHub configuration up to date	status of shub configuration lost with its previous logged value. <i>This element is only shown in detail mode.</i>

102.4 Equipment Holder Alarm Log Status Command

Command Description

This command displays the equipment holder alarm log status.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm log eqpt-holder [ (index) ]
```

Command Parameters

Table 102.4-1 "Equipment Holder Alarm Log Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm log table index

Command Output

Table 102.4-2 "Equipment Holder Alarm Log Status Command" Display parameters

Specific Information		
name	Type	Description
last-updated-on	Parameter type: <Sys::timeInSecs> - the time (yyyy-mm-dd:hour:minutes:secs) - unit: UTC	network time in seconds when the alarm was logged. <i>This element is only shown in detail mode.</i>
shelf	Parameter type: <Equipm::Shelf> <Eqpt::RackId> / <Eqpt::ShelfId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number	specify which shelf the alarm occurred on. <i>This element is only shown in detail mode.</i>
Only Show Details: current and previous alarm log status		
name	Type	Description
rack-power	Parameter type: <Alarm::rackPower> (failing ok) Possible values:	current status of rack power alarm, indicating fuse is broken or intact <i>This element is only shown in</i>

102 Alarm Log Status Commands

name	Type	Description
	- failing : the fuse is broken - ok : the fuse is intact	<i>detail mode.</i>
prev-status	Parameter type: <Alarm::rackPower> (failing ok) Possible values: - failing : the fuse is broken - ok : the fuse is intact	status of rack power alarm with its previous logged value. <i>This element is only shown in detail mode.</i>
fan-unit1 short name: fan1	Parameter type: <Alarm::fanUnit1> ((failing fail) ok) Possible values: - failing : fan unit 1 is failing - fail : fan unit 1 is failing - ok : fan unit 1 is ok	current status of fan-unit1 <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::fanUnit1> ((failing fail) ok) Possible values: - failing : fan unit 1 is failing - fail : fan unit 1 is failing - ok : fan unit 1 is ok	status of fan-unit1 with its previous logged value. <i>This element is only shown in detail mode.</i>
fan-unit2 short name: fan2	Parameter type: <Alarm::fanUnit2> ((failing fail) ok) Possible values: - failing : fan unit 2 is failing - fail : fan unit 2 is failing - ok : fan unit 2 is ok	current status of fan-unit2 <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::fanUnit2> ((failing fail) ok) Possible values: - failing : fan unit 2 is failing - fail : fan unit 2 is failing - ok : fan unit 2 is ok	status of fan-unit2 with its previous logged value. <i>This element is only shown in detail mode.</i>
shelf-mismatch	Parameter type: <Alarm::shelfTypeMismatch> (mismatch no-mismatch) Possible values: - mismatch : installed and planned shelf types are different - no-mismatch : installed and planned shelf types are the same	current status specifies installed and planned shelf types are different <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::shelfTypeMismatch> (mismatch no-mismatch) Possible values: - mismatch : installed and planned shelf types are different - no-mismatch : installed and planned shelf types are the same	status of shelf-mismatch with its previous logged value. <i>This element is only shown in detail mode.</i>
ext-chain-instl	Parameter type: <Alarm::extChainInstl> ((consistancy-problem inconsistant) (no-consistancy-problem ok)) Possible values: - consistancy-problem : consistency problem detected for installation of extension chain - inconsistant : consistency problem detected for installation	current alarm status of consistency problem detected for installation of extension chain <i>This element is only shown in detail mode.</i>

name	Type	Description
	of extension chain - no-consistency-problem: no consistency problem - ok : no consistency problem	
prev-status	Parameter type: <Alarm::extChainInstl> ((consistency-problem inconsistent) (no-consistency-problem ok)) Possible values: - consistency-problem : consistency problem detected for installation of extension chain - inconsistent : consistency problem detected for installation of extension chain - no-consistency-problem: no consistency problem - ok : no consistency problem	status of consistency problem with its previous logged value. <i>This element is only shown in detail mode.</i>
shelf-missing	Parameter type: <Alarm::shelfMissing> (missing not-missing) Possible values: - missing : detected shelf now missing - not-missing : detected shelf was missing, now reinserted	current status specifies once inserted shelf has gone missing <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::shelfMissing> (missing not-missing) Possible values: - missing : detected shelf now missing - not-missing : detected shelf was missing, now reinserted	status of shelf-missing with its previous logged value. <i>This element is only shown in detail mode.</i>
shelf-install-missing	Parameter type: <Alarm::shelfInstall> (yes no) Possible values: - yes : shelf now installed - no : shelf now not installed	log status specifies shelf is planned but not installed <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::shelfInstall> (yes no) Possible values: - yes : shelf now installed - no : shelf now not installed	status of shelf-install-missing alarm with its previous logged value. <i>This element is only shown in detail mode.</i>
door	Parameter type: <Alarm::door> ((failing fail) ok) Possible values: - failing : the cabinet door is opened - fail : the cabinet door is opened - ok : the cabinet door is closed	current status of door alarm, indicating the cabinet door is opened <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::door> ((failing fail) ok) Possible values: - failing : the cabinet door is opened - fail : the cabinet door is opened - ok : the cabinet door is closed	status of door power alarm with its previous logged value. <i>This element is only shown in detail mode.</i>
ac-power-fail short name: ac-pwr	Parameter type: <Alarm::acPowerFail> ((failing fail) ok) Possible values: - failing : system AC power fails - fail : system AC power fails	current status of AC power failure alarm, indicating the AC Power is broken <i>This element is only shown in detail mode.</i>

102 Alarm Log Status Commands

name	Type	Description
	- ok : the system AC power works properly	
prev-status	Parameter type: <Alarm::acPowerFail> ((failing fail) ok) Possible values: - failing : system AC power fails - fail : system AC power fails - ok : the system AC power works properly	status of AC power failure alarm with its previous logged value. <i>This element is only shown in detail mode.</i>

102.5 Equipment Holder Extended Alarm Log Status Command

Command Description

This command displays the equipment holder extended alarm log status.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm log eqpt-holder-ext [ (index) ]
```

Command Parameters

Table 102.5-1 "Equipment Holder Extended Alarm Log Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm log table index

Command Output

Table 102.5-2 "Equipment Holder Extended Alarm Log Status Command" Display parameters

Specific Information		
name	Type	Description
last-updated-on	Parameter type: <Sys::timeInSecs> - the time (yyyy-mm-dd:hour:minutes:secs) - unit: UTC	network time in seconds when the alarm was logged. <i>This element is only shown in detail mode.</i>
shelf	Parameter type: <Equipm::Shelf> <Eqpt::RackId> / <Eqpt::ShelfId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number	specify which shelf the alarm occurred on. <i>This element is only shown in detail mode.</i>
Only Show Details: current and previous alarm log status		
name	Type	Description
ctl-com-fail	Parameter type: <Alarm::ctlComFail> ((failing fail) ok) Possible values:	current status of shelf controller communication failure. <i>This element is only shown in detail mode.</i>

102 Alarm Log Status Commands

name	Type	Description
	- failing : shelf controller communication is failing - fail : shelf controller communication is failing - ok : shelf controller communication is ok	
prev-status	Parameter type: <Alarm::ctlComFail> ((failing fail) ok) Possible values: - failing : shelf controller communication is failing - fail : shelf controller communication is failing - ok : shelf controller communication is ok	status of shelf controller communication failure. <i>This element is only shown in detail mode.</i>
bat-a-fail	Parameter type: <Alarm::batAFail> (yes no) Possible values: - yes : Power Source Battery A Failure - no : Power Source Battery A is OK	current status of shelf power source battery A failure. <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::batAFail> (yes no) Possible values: - yes : Power Source Battery A Failure - no : Power Source Battery A is OK	status of shelf power source battery A failure. <i>This element is only shown in detail mode.</i>
bat-b-fail	Parameter type: <Alarm::batBFail> (yes no) Possible values: - yes : Power Source Battery B Failure - no : bfd stale entry not present	current status of shelf power source battery B failure. <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::batBFail> (yes no) Possible values: - yes : Power Source Battery B Failure - no : bfd stale entry not present	status of shelf power source battery B failure. <i>This element is only shown in detail mode.</i>
water-seepage-in-box	Parameter type: <Alarm::waterSeepageInBox> (detected not-detected) Possible values: - detected : detected water seepage in the enclosure - not-detected : no water seepage detected in the enclosure	current status of detected water seepage in the enclosure <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::waterSeepageInBox> (detected not-detected) Possible values: - detected : detected water seepage in the enclosure - not-detected : no water seepage detected in the enclosure	status of detected water seepage in the enclosure <i>This element is only shown in detail mode.</i>
sealed-box-open	Parameter type: <Alarm::sealedBoxOpen> (detected not-detected) Possible values: - detected : detected open sealed box - not-detected : closed sealed box	current status of detected open sealed box <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::sealedBoxOpen> (detected not-detected) Possible values: - detected : detected open sealed box	status of detected open sealed box <i>This element is only shown in detail mode.</i>

name	Type	Description
	- not-detected : closed sealed box	

102.6 Plug-in Unit Alarm Log Status Command

Command Description

This command displays the plug-in unit alarm log status.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

> show alarm log plug-in-unit [(index)]

Command Parameters

Table 102.6-1 "Plug-in Unit Alarm Log Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm log table index

Command Output

Table 102.6-2 "Plug-in Unit Alarm Log Status Command" Display parameters

Specific Information		
name	Type	Description
last-updated-on	Parameter type: <Sys::timeInSecs> - the time (yyyy-mm-dd:hour:minutes:secs) - unit: UTC	network time in seconds when the alarm was logged. <i>This element is only shown in detail mode.</i>
board-position	Parameter type: <Alarm::SlotIndex> (lt : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> nt-a nt-b nt acu : <Eqpt::RackId> / <Eqpt::ShelfId> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::EqSlotId> ext-a : <Eqpt::RackId> / <Eqpt::ShelfId> ext-b : <Eqpt::RackId> / <Eqpt::ShelfId> ctrl : <Eqpt::RackId> / <Eqpt::ShelfId> iont : <Eqpt::RackId> / <Eqpt::ShelfId> lp : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::LtAppliqueSlotId> ntio-1 ntio-2	identify where the alarm has occurred. <i>This element is only shown in detail mode.</i>

name	Type	Description
	vlt : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::VirtualSlotId>) Possible values: - lt : lt-slot - vlt : virtual LT slot (VVPS board can only be planned at NANT-E/FANT-F) - nt-a : nt-a slot - nt-b : nt-b slot - nt : nt slot - ext-a : nt-a slot in an extension shelf - ext-b : nt-b slot in an extension shelf - acu : acu slot - ctrl : ctrl-slot - iont : an nt applique slot - lp : an lt applique slot - ntio-1 : an nt applique slot in a single or multiple-ntio-shelf - ntio-2 : an nt applique slot in a multiple-ntio-shelf Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::LtAppliqueSlotId> - the LT Applique slot number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::VirtualSlotId> - the virtual LT slot number Field type <Eqpt::EqSlotId> - the equipment slot number	

Only Show Details: current and previous alarm log status		
name	Type	Description
board-mismatch	Parameter type: <Alarm::boardMismatch> (yes no) Possible values: - yes : planned and plugged-in types are different - no : planned and plugged-in types are same	alarm specifying the planned and plugged-in types are different <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::boardMismatch> (yes no) Possible values: - yes : planned and plugged-in types are different - no : planned and plugged-in types are same	status of board-mismatch with its previous logged value. <i>This element is only shown in detail mode.</i>
sw-download	Parameter type: <Alarm::swStatus> (waiting completed) Possible values: - waiting : not able to download all the applicable SW files - completed : download completed	alarm specifying download of the software is completed or not. <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::swStatus> (waiting completed) Possible values: - waiting : not able to download all the applicable SW files - completed : download completed	status of sw-download with its previous logged value. <i>This element is only shown in detail mode.</i>
temperature	Parameter type: <Alarm::tempStatus> (above-thres	alarm specifying board temperature is crossed the

102 Alarm Log Status Commands

name	Type	Description
	below-thres) Possible values: - above-thres : temperature threshold on board exceeded - below-thres : board temperature within threshold	threshold or not. <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::tempStatus> (above-thres below-thres) Possible values: - above-thres : temperature threshold on board exceeded - below-thres : board temperature within threshold	status of board temperature with its previous logged value. <i>This element is only shown in detail mode.</i>
sem-power-fail	Parameter type: <Alarm::extPowerStatus> (sem-power-fail sem-power-ok) Possible values: - sem-power-fail : SEM external power failure - sem-power-ok : SEM external power ok	alarm specifying SEM external power failure. <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::extPowerStatus> (sem-power-fail sem-power-ok) Possible values: - sem-power-fail : SEM external power failure - sem-power-ok : SEM external power ok	status of SEM external power with its previous logged value. <i>This element is only shown in detail mode.</i>
sem-ups-fail	Parameter type: <Alarm::powerSupplyStatus> (sem-ups-fail sem-ups-ok) Possible values: - sem-ups-fail : SEM external power supply failure - sem-ups-ok : SEM external power supply ok	alarm specifying SEM external power supply failure. <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::powerSupplyStatus> (sem-ups-fail sem-ups-ok) Possible values: - sem-ups-fail : SEM external power supply failure - sem-ups-ok : SEM external power supply ok	status of SEM external power supply with its previous logged value. <i>This element is only shown in detail mode.</i>
temp-shutoff	Parameter type: <Alarm::tempShutoffStatus> (board-switched-off board-switched-on) Possible values: - board-switched-off : board switched off - excess temperature - board-switched-on : board switched on	alarm specifying board is switched off because of excess temperature. <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::tempShutoffStatus> (board-switched-off board-switched-on) Possible values: - board-switched-off : board switched off - excess temperature - board-switched-on : board switched on	status of temp-shutoff with its previous logged value. <i>This element is only shown in detail mode.</i>
board-present	Parameter type: <Alarm::boardPresence> (missing yes) Possible values: - missing : board was present, but now missing - yes : board present	indicates the presence of the board. <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::boardPresence> (missing yes)	status of board-present with its previous logged value. <i>This element is only shown in</i>

name	Type	Description
	Possible values: - missing : board was present, but now missing - yes : board present	<i>detail mode.</i>
board-inserted	Parameter type: <Alarm::boardInsertion> (never-inserted inserted) Possible values: - never-inserted : board was never inserted - inserted : board was inserted	indicates the status of board was inserted or not. <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::boardInsertion> (never-inserted inserted) Possible values: - never-inserted : board was never inserted - inserted : board was inserted	status of board-inserted with its previous logged value. <i>This element is only shown in detail mode.</i>
board-init	Parameter type: <Alarm::boardInit> (failed completed) Possible values: - failed : board initialization failed - completed : board initialization completed	specifies board initializaion is sucessful or failed. <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::boardInit> (failed completed) Possible values: - failed : board initialization failed - completed : board initialization completed	status of board-init with its previous logged value. <i>This element is only shown in detail mode.</i>
board-reset-cf	Parameter type: <Alarm::boardResetCommFail> (yes ok) Possible values: - yes : board reset/communication failure occurred - ok : no board reset/communication failure	indicates there has been a reset and/or communication failure of the board. <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::boardResetCommFail> (yes ok) Possible values: - yes : board reset/communication failure occurred - ok : no board reset/communication failure	status of board-reset-cf with its previous logged value. <i>This element is only shown in detail mode.</i>
shub-uplink	Parameter type: <Alarm::lanxuplinkbrkdwn> (failure ok) Possible values: - failure : lanx uplink breakdown or removal - ok : no breakdown or removal of lanx uplink	indicates that lanx uplink breakdown or removal. <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::lanxuplinkbrkdwn> (failure ok) Possible values: - failure : lanx uplink breakdown or removal - ok : no breakdown or removal of lanx uplink	status of shub-uplink with its previous logged value. <i>This element is only shown in detail mode.</i>
backplane-data-failure	Parameter type: <Alarm::BackplaneMismatch> (yes no) Possible values: - yes : LT backplane ports data failure - no : LT backplane ports data normal	indicates the lt backplane data status <i>This element is only shown in detail mode.</i>

102 Alarm Log Status Commands

name	Type	Description
prev-status	Parameter type: <Alarm::BackplaneMismatch> (yes no) Possible values: - yes : LT backplane ports data failure - no : LT backplane ports data normal	status of the lt backplane data with its previous logged value <i>This element is only shown in detail mode.</i>

102.7 ATM Alarm Log Status Command

Command Description

This command displays the ATM alarm log status.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm log atm [ (index) ]
```

Command Parameters

Table 102.7-1 "ATM Alarm Log Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm log table index

Command Output

Table 102.7-2 "ATM Alarm Log Status Command" Display parameters

Specific Information		
name	Type	Description
last-updated-on	Parameter type: <Sys::timeInSecs> - the time (yyyy-mm-dd:hour:minutes:secs) - unit: UTC	network time in seconds when the alarm was logged. <i>This element is only shown in detail mode.</i>
port	Parameter type: <Equipm::AtmIndex> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number	identify where the alarm has occurred. <i>This element is only shown in detail mode.</i>
vpi-vci	Parameter type: <Alarm::VpiVciValues> - the vpi and vci value (vpi/vci)	identify where the alarm has occurred. <i>This element is only shown in detail mode.</i>

102 Alarm Log Status Commands

Only Show Details: current and previous alarm log status		
name	Type	Description
cell-dis-up	Parameter type: <Alarm::CellDiscardUpstream> (discarded no-discard) Possible values: - discarded : ATM cell discarded in upstream direction - no-discard : no ATM cell discarded in upstream direction	specifies ATM cell is discarded or not in upstream direction. <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::CellDiscardUpstream> (discarded no-discard) Possible values: - discarded : ATM cell discarded in upstream direction - no-discard : no ATM cell discarded in upstream direction	status of cell-dis-up with its previous logged value. <i>This element is only shown in detail mode.</i>
cell-dis-down	Parameter type: <Alarm::CellDiscardDownstream> (discarded no-discard) Possible values: - discarded : ATM cell discarded in downstream direction - no-discard : no ATM cell discarded in downstream direction	specifies ATM cell is discarded or not in downstream direction. <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::CellDiscardDownstream> (discarded no-discard) Possible values: - discarded : ATM cell discarded in downstream direction - no-discard : no ATM cell discarded in downstream direction	status of cell-dis-down with its previous logged value. <i>This element is only shown in detail mode.</i>

102.8 Ethernet Interface Alarm Log Status Command

Command Description

This command displays the ethernet interface alarm log status.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm log ether-itf [ (index) ]
```

Command Parameters

Table 102.8-1 "Ethernet Interface Alarm Log Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm log table index

Command Output

Table 102.8-2 "Ethernet Interface Alarm Log Status Command" Display parameters

Specific Information		
name	Type	Description
last-updated-on	Parameter type: <Sys::timeInSecs> - the time (yyyy-mm-dd:hour:minutes:secs) - unit: UTC	network time in seconds when the alarm was logged. <i>This element is only shown in detail mode.</i>
ether-ifindex	Parameter type: <Ether::InterfaceIndex> - index of the collision interface - range: [0...2147483647]	identify where the alarm has occurred. <i>This element is only shown in detail mode.</i>

Only Show Details: current and previous alarm log status		
name	Type	Description
prev-status	Parameter type: <Alarm::EtherLinkStatus> (yes no) Possible values: - yes : board switched off - excess temperature - no : board switched on	status of link-down with its previous logged value. <i>This element is only shown in detail mode.</i>

102.9 Software Management Alarm Log Status Command

Command Description

This command displays the software management Alarm log status.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm log sw-mgmt [ (index) ]
```

Command Parameters

Table 102.9-1 "Software Management Alarm Log Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm log table index

Command Output

Table 102.9-2 "Software Management Alarm Log Status Command" Display parameters

Specific Information		
name	Type	Description
last-updated-on	Parameter type: <Sys::timeInSecs> - the time (yyyy-mm-dd:hour:minutes:secs) - unit: UTC	network time in seconds when the alarm was logged. <i>This element is only shown in detail mode.</i>
board-position	Parameter type: <Equipm::SlotIndex> (lt : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> nt-a nt-b nt acu : <Eqpt::RackId> / <Eqpt::ShelfId> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::EqSlotId> ext-a : <Eqpt::RackId> / <Eqpt::ShelfId> ext-b : <Eqpt::RackId> / <Eqpt::ShelfId> ctrl : <Eqpt::RackId> / <Eqpt::ShelfId> vlt : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::VirtualSlotId>)	identifies the physical position of the slot <i>This element is only shown in detail mode.</i>

102 Alarm Log Status Commands

name	Type	Description
	Possible values: - lt : lt-slot - vlt : virtual LT slot (VVPS board can only be planned at NANT-E / FANT-F) - nt-a : nt-a slot - nt-b : nt-b slot - nt : nt slot - ext-a : nt-a slot in an extension shelf - ext-b : nt-b slot in an extension shelf - acu : acu slot - ctrl : ctrl-slot Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::VirtualSlotId> - the virtual LT slot number Field type <Eqpt::EqSlotId> - the equipment slot number	

Only Show Details: current and previous alarm log status		
name	Type	Description
sw-rollback	Parameter type: <Alarm::SwRollback> (yes no) Possible values: - yes : implicit software rollback performed - no : no implicit software rollback	specifies implicit software rollback is performed or not. <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::SwRollback> (yes no) Possible values: - yes : implicit software rollback performed - no : no implicit software rollback	status of sw-rollback with its previous logged value. <i>This element is only shown in detail mode.</i>
db-rollback	Parameter type: <Alarm::DbRollback> (yes no) Possible values: - yes : implicit database rollback performed - no : no implicit database rollback	specifies implicit database rollback is performed or not. <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::DbRollback> (yes no) Possible values: - yes : implicit database rollback performed - no : no implicit database rollback	status of db-rollback with its previous logged value. <i>This element is only shown in detail mode.</i>
xvps-inv-dbase	Parameter type: <Alarm::XvpsInvalidDataBase> (invalid valid) Possible values: - invalid : invalid xvps dbbase is detected - valid : xvps dbbase is valid	specifies implicit xvps dbase is valid or not. <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::XvpsInvalidDataBase> (invalid valid) Possible values:	status of xvps-inv-dbase with its previous logged value. <i>This element is only shown in detail mode.</i>

name	Type	Description
	- invalid : invalid xvps dbbase is detected - valid : xvps dbbase is valid	
inv-cde-file	Parameter type: <Alarm::XvpsInvalidCDEFile> (invalid valid) Possible values: - invalid : invalid xvps cde file is detected - valid : xvps cde file is valid	specifies implicit xvps dbase is valid or not. <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::XvpsInvalidCDEFile> (invalid valid) Possible values: - invalid : invalid xvps cde file is detected - valid : xvps cde file is valid	status of inv-cde-file with its previous logged value. <i>This element is only shown in detail mode.</i>
miss-cde-file	Parameter type: <Alarm::MissingCDEProfile> (yes no) Possible values: - yes : cde profile is missed - no : cde profile is exist	specifies cde profile is missed or not. <i>This element is only shown in detail mode.</i>

102.10 Temporal Filter Alarm Log Status Command

Command Description

This command displays the temporal filter alarm log status.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

> show alarm log temporal [(index)]

Command Parameters

Table 102.10-1 "Temporal Filter Alarm Log Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm log table index

Command Output

Table 102.10-2 "Temporal Filter Alarm Log Status Command" Display parameters

Specific Information		
name	Type	Description
last-updated-on	Parameter type: <Sys::timeInSecs> - the time (yyyy-mm-dd:hour:minutes:secs) - unit: UTC	network time in seconds when the alarm was logged. <i>This element is only shown in detail mode.</i>

Only Show Details: current and previous alarm log status		
name	Type	Description
tmp-filter1	Parameter type: <Alarm::almFilter1> (yes no) Possible values: - yes : derived filter1 alarm - no : not derived filter1 alarm	current status of temporal filter1 alarm is derived or not <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::almFilter1> (yes no) Possible values: - yes : derived filter1 alarm - no : not derived filter1 alarm	status of temporal filter1 alarm with its previous logged value. <i>This element is only shown in detail mode.</i>
tmp-filter2	Parameter type: <Alarm::almFilter2>	current status of temporal filter2

name	Type	Description
	(yes no) Possible values: - yes : derived filter2 alarm - no : not derived filter2 alarm	alarm is derived or not <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::almFilter2> (yes no) Possible values: - yes : derived filter2 alarm - no : not derived filter2 alarm	status of temporal filter2 alarm with its previous logged value. <i>This element is only shown in detail mode.</i>
tmp-filter3	Parameter type: <Alarm::almFilter3> (yes no) Possible values: - yes : derived filter3 alarm - no : not derived filter3 alarm	current status of temporal filter3 alarm is derived or not <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::almFilter3> (yes no) Possible values: - yes : derived filter3 alarm - no : not derived filter3 alarm	status of temporal filter3 alarm with its previous logged value. <i>This element is only shown in detail mode.</i>
tmp-filter4	Parameter type: <Alarm::almFilter4> (yes no) Possible values: - yes : derived filter4 alarm - no : not derived filter4 alarm	current status of temporal filter4 alarm is derived or not <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::almFilter4> (yes no) Possible values: - yes : derived filter4 alarm - no : not derived filter4 alarm	status of temporal filter4 alarm with its previous logged value. <i>This element is only shown in detail mode.</i>
tmp-filter5	Parameter type: <Alarm::almFilter5> (yes no) Possible values: - yes : derived filter5 alarm - no : not derived filter5 alarm	current status of temporal filter5 alarm is derived or not <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::almFilter5> (yes no) Possible values: - yes : derived filter5 alarm - no : not derived filter5 alarm	status of temporal filter5 alarm with its previous logged value. <i>This element is only shown in detail mode.</i>
tmp-filter6	Parameter type: <Alarm::almFilter6> (yes no) Possible values: - yes : derived filter6 alarm - no : not derived filter6 alarm	current status of temporal filter6 alarm is derived or not <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::almFilter6> (yes no) Possible values:	status of temporal filter6 alarm with its previous logged value. <i>This element is only shown in detail mode.</i>

102 Alarm Log Status Commands

name	Type	Description
	- yes : derived filter6 alarm - no : not derived filter6 alarm	
tmp-filter7	Parameter type: <Alarm::alarmFilter7> (yes no) Possible values: - yes : derived filter7 alarm - no : not derived filter7 alarm	current status of temporal filter7 alarm is derived or not <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::alarmFilter7> (yes no) Possible values: - yes : derived filter7 alarm - no : not derived filter7 alarm	status of temporal filter7 alarm with its previous logged value. <i>This element is only shown in detail mode.</i>
tmp-filter8	Parameter type: <Alarm::alarmFilter8> (yes no) Possible values: - yes : derived filter alarm - no : not derived filter alarm	current status of temporal filter8 alarm is derived or not <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::alarmFilter8> (yes no) Possible values: - yes : derived filter alarm - no : not derived filter alarm	status of temporal filter8 alarm with its previous logged value. <i>This element is only shown in detail mode.</i>
tmp-filter9	Parameter type: <Alarm::alarmFilter9> (yes no) Possible values: - yes : derived filter9 alarm - no : not derived filter9 alarm	current status of temporal filter9 alarm is derived or not <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::alarmFilter9> (yes no) Possible values: - yes : derived filter9 alarm - no : not derived filter9 alarm	status of temporal filter9 alarm with its previous logged value. <i>This element is only shown in detail mode.</i>
tmp-filter10	Parameter type: <Alarm::alarmFilter10> (yes no) Possible values: - yes : derived filter10 alarm - no : not derived filter alarm	current status of temporal filter10 alarm is derived or not <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::alarmFilter10> (yes no) Possible values: - yes : derived filter10 alarm - no : not derived filter alarm	status of temporal filter10 alarm with its previous logged value. <i>This element is only shown in detail mode.</i>
tmp-filter11	Parameter type: <Alarm::alarmFilter11> (yes no) Possible values: - yes : derived filter11 alarm - no : not derived filter11 alarm	current status of temporal filter11 alarm is derived or not <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::alarmFilter11>	status of temporal filter11 alarm

name	Type	Description
	(yes no) Possible values: - yes : derived filter11 alarm - no : not derived filter11 alarm	with its previous logged value. <i>This element is only shown in detail mode.</i>
tmp-filter12	Parameter type: <Alarm::almFilter12> (yes no) Possible values: - yes : derived filter12 alarm - no : not derived filter12 alarm	current status of temporal filter12 alarm is derived or not <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::almFilter12> (yes no) Possible values: - yes : derived filter12 alarm - no : not derived filter12 alarm	status of temporal filter12 alarm with its previous logged value. <i>This element is only shown in detail mode.</i>
tmp-filter13	Parameter type: <Alarm::almFilter13> (yes no) Possible values: - yes : derived filter13 alarm - no : not derived filter13 alarm	current status of temporal filter13 alarm is derived or not <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::almFilter13> (yes no) Possible values: - yes : derived filter13 alarm - no : not derived filter13 alarm	status of temporal filter13 alarm with its previous logged value. <i>This element is only shown in detail mode.</i>
tmp-filter14	Parameter type: <Alarm::almFilter14> (yes no) Possible values: - yes : derived filter14 alarm - no : not derived filter14 alarm	current status of temporal filter14 alarm is derived or not <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::almFilter14> (yes no) Possible values: - yes : derived filter14 alarm - no : not derived filter14 alarm	status of temporal filter14 alarm with its previous logged value. <i>This element is only shown in detail mode.</i>
tmp-filter15	Parameter type: <Alarm::almFilter15> (yes no) Possible values: - yes : derived filter15 alarm - no : not derived filter15 alarm	current status of temporal filter15 alarm is derived or not <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::almFilter15> (yes no) Possible values: - yes : derived filter15 alarm - no : not derived filter15 alarm	status of temporal filter15 alarm with its previous logged value. <i>This element is only shown in detail mode.</i>
tmp-filter16	Parameter type: <Alarm::almFilter16> (yes no) Possible values:	current status of temporal filter16 alarm is derived or not <i>This element is only shown in detail mode.</i>

102 Alarm Log Status Commands

name	Type	Description
	- yes : derived filter16 alarm - no : not derived filter16 alarm	
prev-status	Parameter type: <Alarm::almFilter16> (yes no) Possible values: - yes : derived filter16 alarm - no : not derived filter16 alarm	status of temporal filter16 alarm with its previous logged value. <i>This element is only shown in detail mode.</i>
tmp-filter17	Parameter type: <Alarm::almFilter17> (yes no) Possible values: - yes : derived filter17 alarm - no : not derived filter17 alarm	current status of temporal filter17 alarm is derived or not <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::almFilter17> (yes no) Possible values: - yes : derived filter17 alarm - no : not derived filter17 alarm	status of temporal filter17 alarm with its previous logged value. <i>This element is only shown in detail mode.</i>
tmp-filter18	Parameter type: <Alarm::almFilter18> (yes no) Possible values: - yes : derived filter18 alarm - no : not derived filter18 alarm	current status of temporal filter18 alarm is derived or not <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::almFilter18> (yes no) Possible values: - yes : derived filter18 alarm - no : not derived filter18 alarm	status of temporal filter18 alarm with its previous logged value. <i>This element is only shown in detail mode.</i>
tmp-filter19	Parameter type: <Alarm::almFilter19> (yes no) Possible values: - yes : derived filter19 alarm - no : not derived filter19 alarm	current status of temporal filter19 alarm is derived or not <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::almFilter19> (yes no) Possible values: - yes : derived filter19 alarm - no : not derived filter19 alarm	status of temporal filter19 alarm with its previous logged value. <i>This element is only shown in detail mode.</i>
tmp-filter20	Parameter type: <Alarm::almFilter20> (yes no) Possible values: - yes : derived filter20 alarm - no : not derived filter20 alarm	current status of temporal filter20 alarm is derived or not <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::almFilter20> (yes no) Possible values: - yes : derived filter20 alarm - no : not derived filter20 alarm	status of temporal filter20 alarm with its previous logged value. <i>This element is only shown in detail mode.</i>
tmp-filter21	Parameter type: <Alarm::almFilter21>	current status of temporal filter21

name	Type	Description
	(yes no) Possible values: - yes : derived filter21 alarm - no : not derived filter21 alarm	alarm is derived or not <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::almFilter21> (yes no) Possible values: - yes : derived filter21 alarm - no : not derived filter21 alarm	status of temporal filter21 alarm with its previous logged value. <i>This element is only shown in detail mode.</i>
tmp-filter22	Parameter type: <Alarm::almFilter22> (yes no) Possible values: - yes : derived filter22 alarm - no : not derived filter22 alarm	current status of temporal filter22 alarm is derived or not <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::almFilter22> (yes no) Possible values: - yes : derived filter22 alarm - no : not derived filter22 alarm	status of temporal filter22 alarm with its previous logged value. <i>This element is only shown in detail mode.</i>
tmp-filter23	Parameter type: <Alarm::almFilter23> (yes no) Possible values: - yes : derived filter23 alarm - no : not derived filter23 alarm	current status of temporal filter23 alarm is derived or not <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::almFilter23> (yes no) Possible values: - yes : derived filter23 alarm - no : not derived filter23 alarm	status of temporal filter23 alarm with its previous logged value. <i>This element is only shown in detail mode.</i>
tmp-filter24	Parameter type: <Alarm::almFilter24> (yes no) Possible values: - yes : derived filter24 alarm - no : not derived filter24 alarm	current status of temporal filter24 alarm is derived or not <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::almFilter24> (yes no) Possible values: - yes : derived filter24 alarm - no : not derived filter24 alarm	status of temporal filter24 alarm with its previous logged value. <i>This element is only shown in detail mode.</i>
tmp-filter25	Parameter type: <Alarm::almFilter25> (yes no) Possible values: - yes : derived filter25 alarm - no : not derived filter25 alarm	current status of temporal filter25 alarm is derived or not <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::almFilter25> (yes no) Possible values:	status of temporal filter25 alarm with its previous logged value. <i>This element is only shown in detail mode.</i>

102 Alarm Log Status Commands

name	Type	Description
	- yes : derived filter25 alarm - no : not derived filter25 alarm	
tmp-filter26	Parameter type: <Alarm::alarmFilter26> (yes no) Possible values: - yes : derived filter26 alarm - no : not derived filter26 alarm	current status of temporal filter26 alarm is derived or not <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::alarmFilter26> (yes no) Possible values: - yes : derived filter26 alarm - no : not derived filter26 alarm	status of temporal filter26 alarm with its previous logged value. <i>This element is only shown in detail mode.</i>
tmp-filter27	Parameter type: <Alarm::alarmFilter27> (yes no) Possible values: - yes : derived filter27 alarm - no : not derived filter27 alarm	current status of temporal filter27 alarm is derived or not <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::alarmFilter27> (yes no) Possible values: - yes : derived filter27 alarm - no : not derived filter27 alarm	status of temporal filter27 alarm with its previous logged value. <i>This element is only shown in detail mode.</i>
tmp-filter28	Parameter type: <Alarm::alarmFilter28> (yes no) Possible values: - yes : derived filter28 alarm - no : not derived filter28 alarm	current status of temporal filter28 alarm is derived or not <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::alarmFilter28> (yes no) Possible values: - yes : derived filter28 alarm - no : not derived filter28 alarm	status of temporal filter28 alarm with its previous logged value. <i>This element is only shown in detail mode.</i>
tmp-filter29	Parameter type: <Alarm::alarmFilter29> (yes no) Possible values: - yes : derived filter29 alarm - no : not derived filter29 alarm	current status of temporal filter29 alarm is derived or not <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::alarmFilter29> (yes no) Possible values: - yes : derived filter29 alarm - no : not derived filter29 alarm	status of temporal filter29 alarm with its previous logged value. <i>This element is only shown in detail mode.</i>
tmp-filter30	Parameter type: <Alarm::alarmFilter30> (yes no) Possible values: - yes : derived filter30 alarm - no : not derived filter30 alarm	current status of temporal filter30 alarm is derived or not <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::alarmFilter30>	status of temporal filter30 alarm

name	Type	Description
	(yes no) Possible values: - yes : derived filter30 alarm - no : not derived filter30 alarm	with its previous logged value. <i>This element is only shown in detail mode.</i>
tmp-filter31	Parameter type: <Alarm::almFilter31> (yes no) Possible values: - yes : derived filter31 alarm - no : not derived filter31 alarm	current status of temporal filter31 alarm is derived or not <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::almFilter31> (yes no) Possible values: - yes : derived filter31 alarm - no : not derived filter31 alarm	status of temporal filter31 alarm with its previous logged value. <i>This element is only shown in detail mode.</i>

102.11 Spatial Filter Alarm Log Status Command

Command Description

This command displays the spatial filter alarm log status.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm log spatial [ (index) ]
```

Command Parameters

Table 102.11-1 "Spatial Filter Alarm Log Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm log table index

Command Output

Table 102.11-2 "Spatial Filter Alarm Log Status Command" Display parameters

Specific Information		
name	Type	Description
last-updated-on	Parameter type: <Sys::timeInSecs> - the time (yyyy-mm-dd:hour:minutes:secs) - unit: UTC	network time in seconds when the alarm was logged. <i>This element is only shown in detail mode.</i>
Only Show Details: current and previous alarm log status		
name	Type	Description
spa-filter1	Parameter type: <Alarm::almFilter1> (yes no) Possible values: - yes : derived filter1 alarm - no : not derived filter1 alarm	current status of spatial filter1 alarm is derived or not <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::almFilter1> (yes no) Possible values: - yes : derived filter1 alarm - no : not derived filter1 alarm	status of spatial filter1 alarm with its previous logged value. <i>This element is only shown in detail mode.</i>
spa-filter2	Parameter type: <Alarm::almFilter2>	current status of spatial filter2

name	Type	Description
	(yes no) Possible values: - yes : derived filter2 alarm - no : not derived filter2 alarm	alarm is derived or not <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::almFilter2> (yes no) Possible values: - yes : derived filter2 alarm - no : not derived filter2 alarm	status of spatial filter2 alarm with its previous logged value. <i>This element is only shown in detail mode.</i>
spa-filter3	Parameter type: <Alarm::almFilter3> (yes no) Possible values: - yes : derived filter3 alarm - no : not derived filter3 alarm	current status of spatial filter3 alarm is derived or not <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::almFilter3> (yes no) Possible values: - yes : derived filter3 alarm - no : not derived filter3 alarm	status of spatial filter3 alarm with its previous logged value. <i>This element is only shown in detail mode.</i>
spa-filter4	Parameter type: <Alarm::almFilter4> (yes no) Possible values: - yes : derived filter4 alarm - no : not derived filter4 alarm	current status of spatial filter4 alarm is derived or not <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::almFilter4> (yes no) Possible values: - yes : derived filter4 alarm - no : not derived filter4 alarm	status of spatial filter4 alarm with its previous logged value. <i>This element is only shown in detail mode.</i>
spa-filter5	Parameter type: <Alarm::almFilter5> (yes no) Possible values: - yes : derived filter5 alarm - no : not derived filter5 alarm	current status of spatial filter5 alarm is derived or not <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::almFilter5> (yes no) Possible values: - yes : derived filter5 alarm - no : not derived filter5 alarm	status of spatial filter5 alarm with its previous logged value. <i>This element is only shown in detail mode.</i>
spa-filter6	Parameter type: <Alarm::almFilter6> (yes no) Possible values: - yes : derived filter6 alarm - no : not derived filter6 alarm	current status of spatial filter6 alarm is derived or not <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::almFilter6> (yes no) Possible values:	status of spatial filter6 alarm with its previous logged value. <i>This element is only shown in detail mode.</i>

102 Alarm Log Status Commands

name	Type	Description
	- yes : derived filter6 alarm - no : not derived filter6 alarm	
spa-filter7	Parameter type: <Alarm::alarmFilter7> (yes no) Possible values: - yes : derived filter7 alarm - no : not derived filter7 alarm	current status of spatial filter7 alarm is derived or not <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::alarmFilter7> (yes no) Possible values: - yes : derived filter7 alarm - no : not derived filter7 alarm	status of spatial filter7 alarm with its previous logged value. <i>This element is only shown in detail mode.</i>
spa-filter8	Parameter type: <Alarm::alarmFilter8> (yes no) Possible values: - yes : derived filter alarm - no : not derived filter alarm	current status of spatial filter8 alarm is derived or not <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::alarmFilter8> (yes no) Possible values: - yes : derived filter alarm - no : not derived filter alarm	status of spatial filter8 alarm with its previous logged value. <i>This element is only shown in detail mode.</i>
spa-filter9	Parameter type: <Alarm::alarmFilter9> (yes no) Possible values: - yes : derived filter9 alarm - no : not derived filter9 alarm	current status of spatial filter9 alarm is derived or not <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::alarmFilter9> (yes no) Possible values: - yes : derived filter9 alarm - no : not derived filter9 alarm	status of spatial filter9 alarm with its previous logged value. <i>This element is only shown in detail mode.</i>
spa-filter10	Parameter type: <Alarm::alarmFilter10> (yes no) Possible values: - yes : derived filter10 alarm - no : not derived filter alarm	current status of spatial filter10 alarm is derived or not <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::alarmFilter10> (yes no) Possible values: - yes : derived filter10 alarm - no : not derived filter alarm	status of spatial filter10 alarm with its previous logged value. <i>This element is only shown in detail mode.</i>
spa-filter11	Parameter type: <Alarm::alarmFilter11> (yes no) Possible values: - yes : derived filter11 alarm - no : not derived filter11 alarm	current status of spatial filter11 alarm is derived or not <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::alarmFilter11>	status of spatial filter11 alarm

name	Type	Description
	(yes no) Possible values: - yes : derived filter11 alarm - no : not derived filter11 alarm	with its previous logged value. <i>This element is only shown in detail mode.</i>
spa-filter12	Parameter type: <Alarm::almFilter12> (yes no) Possible values: - yes : derived filter12 alarm - no : not derived filter12 alarm	current status of spatial filter12 alarm is derived or not <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::almFilter12> (yes no) Possible values: - yes : derived filter12 alarm - no : not derived filter12 alarm	status of spatial filter12 alarm with its previous logged value. <i>This element is only shown in detail mode.</i>
spa-filter13	Parameter type: <Alarm::almFilter13> (yes no) Possible values: - yes : derived filter13 alarm - no : not derived filter13 alarm	current status of spatial filter13 alarm is derived or not <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::almFilter13> (yes no) Possible values: - yes : derived filter13 alarm - no : not derived filter13 alarm	status of spatial filter13 alarm with its previous logged value. <i>This element is only shown in detail mode.</i>
spa-filter14	Parameter type: <Alarm::almFilter14> (yes no) Possible values: - yes : derived filter14 alarm - no : not derived filter14 alarm	current status of spatial filter14 alarm is derived or not <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::almFilter14> (yes no) Possible values: - yes : derived filter14 alarm - no : not derived filter14 alarm	status of spatial filter14 alarm with its previous logged value. <i>This element is only shown in detail mode.</i>
spa-filter15	Parameter type: <Alarm::almFilter15> (yes no) Possible values: - yes : derived filter15 alarm - no : not derived filter15 alarm	current status of spatial filter15 alarm is derived or not <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::almFilter15> (yes no) Possible values: - yes : derived filter15 alarm - no : not derived filter15 alarm	status of spatial filter15 alarm with its previous logged value. <i>This element is only shown in detail mode.</i>
spa-filter16	Parameter type: <Alarm::almFilter16> (yes no) Possible values:	current status of spatial filter16 alarm is derived or not <i>This element is only shown in detail mode.</i>

102 Alarm Log Status Commands

name	Type	Description
	- yes : derived filter16 alarm - no : not derived filter16 alarm	
prev-status	Parameter type: <Alarm::alarmFilter16> (yes no) Possible values: - yes : derived filter16 alarm - no : not derived filter16 alarm	status of spatial filter16 alarm with its previous logged value. <i>This element is only shown in detail mode.</i>
spa-filter17	Parameter type: <Alarm::alarmFilter17> (yes no) Possible values: - yes : derived filter17 alarm - no : not derived filter17 alarm	current status of spatial filter17 alarm is derived or not <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::alarmFilter17> (yes no) Possible values: - yes : derived filter17 alarm - no : not derived filter17 alarm	status of spatial filter17 alarm with its previous logged value. <i>This element is only shown in detail mode.</i>
spa-filter18	Parameter type: <Alarm::alarmFilter18> (yes no) Possible values: - yes : derived filter18 alarm - no : not derived filter18 alarm	current status of spatial filter18 alarm is derived or not <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::alarmFilter18> (yes no) Possible values: - yes : derived filter18 alarm - no : not derived filter18 alarm	status of spatial filter18 alarm with its previous logged value. <i>This element is only shown in detail mode.</i>
spa-filter19	Parameter type: <Alarm::alarmFilter19> (yes no) Possible values: - yes : derived filter19 alarm - no : not derived filter19 alarm	current status of spatial filter19 alarm is derived or not <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::alarmFilter19> (yes no) Possible values: - yes : derived filter19 alarm - no : not derived filter19 alarm	status of spatial filter19 alarm with its previous logged value. <i>This element is only shown in detail mode.</i>
spa-filter20	Parameter type: <Alarm::alarmFilter20> (yes no) Possible values: - yes : derived filter20 alarm - no : not derived filter20 alarm	current status of spatial filter20 alarm is derived or not <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::alarmFilter20> (yes no) Possible values: - yes : derived filter20 alarm - no : not derived filter20 alarm	status of spatial filter20 alarm with its previous logged value. <i>This element is only shown in detail mode.</i>
spa-filter21	Parameter type: <Alarm::alarmFilter21>	current status of spatial filter21

name	Type	Description
	(yes no) Possible values: - yes : derived filter21 alarm - no : not derived filter21 alarm	alarm is derived or not <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::almFilter21> (yes no) Possible values: - yes : derived filter21 alarm - no : not derived filter21 alarm	status of spatial filter21 alarm with its previous logged value. <i>This element is only shown in detail mode.</i>
spa-filter22	Parameter type: <Alarm::almFilter22> (yes no) Possible values: - yes : derived filter22 alarm - no : not derived filter22 alarm	current status of spatial filter22 alarm is derived or not <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::almFilter22> (yes no) Possible values: - yes : derived filter22 alarm - no : not derived filter22 alarm	status of spatial filter22 alarm with its previous logged value. <i>This element is only shown in detail mode.</i>
spa-filter23	Parameter type: <Alarm::almFilter23> (yes no) Possible values: - yes : derived filter23 alarm - no : not derived filter23 alarm	current status of spatial filter23 alarm is derived or not <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::almFilter23> (yes no) Possible values: - yes : derived filter23 alarm - no : not derived filter23 alarm	status of spatial filter23 alarm with its previous logged value. <i>This element is only shown in detail mode.</i>
spa-filter24	Parameter type: <Alarm::almFilter24> (yes no) Possible values: - yes : derived filter24 alarm - no : not derived filter24 alarm	current status of spatial filter24 alarm is derived or not <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::almFilter24> (yes no) Possible values: - yes : derived filter24 alarm - no : not derived filter24 alarm	status of spatial filter24 alarm with its previous logged value. <i>This element is only shown in detail mode.</i>
spa-filter25	Parameter type: <Alarm::almFilter25> (yes no) Possible values: - yes : derived filter25 alarm - no : not derived filter25 alarm	current status of spatial filter25 alarm is derived or not <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::almFilter25> (yes no) Possible values:	status of spatial filter25 alarm with its previous logged value. <i>This element is only shown in detail mode.</i>

102 Alarm Log Status Commands

name	Type	Description
	- yes : derived filter25 alarm - no : not derived filter25 alarm	
spa-filter26	Parameter type: <Alarm::alarmFilter26> (yes no) Possible values: - yes : derived filter26 alarm - no : not derived filter26 alarm	current status of spatial filter26 alarm is derived or not <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::alarmFilter26> (yes no) Possible values: - yes : derived filter26 alarm - no : not derived filter26 alarm	status of spatial filter26 alarm with its previous logged value. <i>This element is only shown in detail mode.</i>
spa-filter27	Parameter type: <Alarm::alarmFilter27> (yes no) Possible values: - yes : derived filter27 alarm - no : not derived filter27 alarm	current status of spatial filter27 alarm is derived or not <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::alarmFilter27> (yes no) Possible values: - yes : derived filter27 alarm - no : not derived filter27 alarm	status of spatial filter27 alarm with its previous logged value. <i>This element is only shown in detail mode.</i>
spa-filter28	Parameter type: <Alarm::alarmFilter28> (yes no) Possible values: - yes : derived filter28 alarm - no : not derived filter28 alarm	current status of spatial filter28 alarm is derived or not <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::alarmFilter28> (yes no) Possible values: - yes : derived filter28 alarm - no : not derived filter28 alarm	status of spatial filter28 alarm with its previous logged value. <i>This element is only shown in detail mode.</i>
spa-filter29	Parameter type: <Alarm::alarmFilter29> (yes no) Possible values: - yes : derived filter29 alarm - no : not derived filter29 alarm	current status of spatial filter29 alarm is derived or not <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::alarmFilter29> (yes no) Possible values: - yes : derived filter29 alarm - no : not derived filter29 alarm	status of spatial filter29 alarm with its previous logged value. <i>This element is only shown in detail mode.</i>
spa-filter30	Parameter type: <Alarm::alarmFilter30> (yes no) Possible values: - yes : derived filter30 alarm - no : not derived filter30 alarm	current status of spatial filter30 alarm is derived or not <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::alarmFilter30>	status of spatial filter30 alarm

name	Type	Description
	(yes no) Possible values: - yes : derived filter30 alarm - no : not derived filter30 alarm	with its previous logged value. <i>This element is only shown in detail mode.</i>
spa-filter31	Parameter type: <Alarm::almFilter31> (yes no) Possible values: - yes : derived filter31 alarm - no : not derived filter31 alarm	current status of spatial filter31 alarm is derived or not <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::almFilter31> (yes no) Possible values: - yes : derived filter31 alarm - no : not derived filter31 alarm	status of spatial filter31 alarm with its previous logged value. <i>This element is only shown in detail mode.</i>

102.12 xDSL Common Alarm Log Status Command

Command Description

This command displays the xDSL common alarm log status.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm log xdsl misc [ (index) ]
```

Command Parameters

Table 102.12-1 "xDSL Common Alarm Log Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm log table index

Command Output

Table 102.12-2 "xDSL Common Alarm Log Status Command" Display parameters

Specific Information		
name	Type	Description
last-updated-on	Parameter type: <Sys::timeInSecs> - the time (yyyy-mm-dd:hour:minutes:secs) - unit: UTC	network time in seconds when the alarm was logged. <i>This element is only shown in detail mode.</i>
port	Parameter type: <Itf::XdslLine> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number	identifies the physical position of the port <i>This element is only shown in detail mode.</i>

Only Show Details: current and previous alarm log status		
name	Type	Description
line-config	Parameter type: <Alarm::LineConfig> (config-error	specifies whether line configuration data is used or not.

name	Type	Description
	config-ok) Possible values: - config-error : line configuration data cannot be used - config-ok : Line configuration data OK	<i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::LineConfig> (config-error config-ok) Possible values: - config-error : line configuration data cannot be used - config-ok : Line configuration data OK	status of line-config with its previous logged value. <i>This element is only shown in detail mode.</i>
line-capacity	Parameter type: <Alarm::LineCapacity> (below-requirement meets-requirement) Possible values: - below-requirement : line capacity not enough to set up requested profile - meets-requirement : line capacity enough to set up requested profile	specifies whether line capacity is set up or not. <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::LineCapacity> (below-requirement meets-requirement) Possible values: - below-requirement : line capacity not enough to set up requested profile - meets-requirement : line capacity enough to set up requested profile	status of line-capacity with its previous logged value. <i>This element is only shown in detail mode.</i>
xdsl-init	Parameter type: <Alarm::Initialization> (failed successful) Possible values: - failed : initialization unsuccessful due to communication problem - successful : initialization successful	specifies xdsl line initialization is successful or not. <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::Initialization> (failed successful) Possible values: - failed : initialization unsuccessful due to communication problem - successful : initialization successful	status of xdsl-init with its previous logged value. <i>This element is only shown in detail mode.</i>
peer-modem	Parameter type: <Alarm::PeerModem> (no yes) Possible values: - no : no peer modem detected - yes : peer modem detected	specifies whether peer modem detected or not. <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::PeerModem> (no yes) Possible values: - no : no peer modem detected - yes : peer modem detected	status of peer-modem with its previous logged value. <i>This element is only shown in detail mode.</i>
tpstc-mis	Parameter type: <Alarm::TpstcMis> (yes no) Possible values: - yes : mismatch between the configured tps-tc mode and the	mismatch between the configured tps-tc mode and the mode supported by the connected cpe <i>This element is only shown in detail mode.</i>

102 Alarm Log Status Commands

name	Type	Description
	mode supported by the connected cpe - no : no mismatch between the configured and the tpstc mode supported by connected cpe	
prev-status	Parameter type: <Alarm::TpstcMis> (yes no) Possible values: - yes : mismatch between the configured tps-tc mode and the mode supported by the connected cpe - no : no mismatch between the configured and the tpstc mode supported by connected cpe	status of tpstc mismatch with its previous logged value. <i>This element is only shown in detail mode.</i>
forced-rtx-init	Parameter type: <Alarm::ForcedRtxInit> (failed successful) Possible values: - failed : initialization unsuccessful due to forced retransmission - successful : initialization successful	specifies forced rtx initialization is successful or not <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::ForcedRtxInit> (failed successful) Possible values: - failed : initialization unsuccessful due to forced retransmission - successful : initialization successful	status of forced-rtx-init with its previous logged value <i>This element is only shown in detail mode.</i>

102.13 xDSL Near-end Alarm Log Status Command

Command Description

This command displays the xDSL near-end alarm log status.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm log xdsl near-end [ (index) ]
```

Command Parameters

Table 102.13-1 "xDSL Near-end Alarm Log Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm log table index

Command Output

Table 102.13-2 "xDSL Near-end Alarm Log Status Command" Display parameters

Specific Information		
name	Type	Description
last-updated-on	Parameter type: <Sys::timeInSecs> - the time (yyyy-mm-dd:hour:minutes:secs) - unit: UTC	network time in seconds when the alarm was logged. <i>This element is only shown in detail mode.</i>
port	Parameter type: <Itf::XdslLine> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number	Specifies where the alarm occurred. <i>This element is only shown in detail mode.</i>

Only Show Details: current and previous alarm log status		
name	Type	Description
los	Parameter type: <Alarm::NearEndLOS> (yes	specifies near end loss of signal occurred or not.

102 Alarm Log Status Commands

name	Type	Description
	no) Possible values: - yes : near end loss of signal occurred - no : no near end loss of signal	<i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::NearEndLOS> (yes no) Possible values: - yes : near end loss of signal occurred - no : no near end loss of signal	status of los with its previous logged value. <i>This element is only shown in detail mode.</i>
lof	Parameter type: <Alarm::NearEndLOF> (yes no) Possible values: - yes : near end loss of frame occurred - no : no near end loss of frame	specifies near end loss of frame occurred or not. <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::NearEndLOF> (yes no) Possible values: - yes : near end loss of frame occurred - no : no near end loss of frame	status of lof with its previous logged value. <i>This element is only shown in detail mode.</i>
lom	Parameter type: <Alarm::NearEndLOM> (yes no) Possible values: - yes : near end loss of margin occurred - no : no near end loss of margin	specifies near end loss of margin occurred or not. <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::NearEndLOM> (yes no) Possible values: - yes : near end loss of margin occurred - no : no near end loss of margin	status of lom with its previous logged value. <i>This element is only shown in detail mode.</i>
ese	Parameter type: <Alarm::NearEndESE> (yes no) Possible values: - yes : near end excessive severe errors occurred - no : no near end excessive severe errors occurred	specifies near end excessive severe errors occurred or not. <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::NearEndESE> (yes no) Possible values: - yes : near end excessive severe errors occurred - no : no near end excessive severe errors occurred	status of ese with its previous logged value. <i>This element is only shown in detail mode.</i>
bitrate	Parameter type: <Alarm::NearEndBRthres> (below-plan meets-plan) Possible values: - below-plan : upstream planned bitrate not reached after initialization - meets-plan : upstream planned bitrate reached	specifies whether upstream planned bitrate reached or not after initialization. <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::NearEndBRthres> (below-plan meets-plan) Possible values:	status of bitrate with its previous logged value. <i>This element is only shown in detail mode.</i>

name	Type	Description
	- below-plan : upstream planned bitrate not reached after initialization - meets-plan : upstream planned bitrate reached	
ncd	Parameter type: <Alarm::NearEndNCD> (no-cell-deline cell-deline-occurred) Possible values: - no-cell-deline : no near end cell delineation - cell-deline-occurred : near end cell delineation occurred	specifies whether near end cell delineation is occurred or not. <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::NearEndNCD> (no-cell-deline cell-deline-occurred) Possible values: - no-cell-deline : no near end cell delineation - cell-deline-occurred : near end cell delineation occurred	status of ncd with its previous logged value. <i>This element is only shown in detail mode.</i>
lcd	Parameter type: <Alarm::NearEndLCD> (yes no) Possible values: - yes : loss of near end cell deliniation - no : no loss of near end cell deliniation	specifies whether loss of near end cell deliniation is occurred or not. <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::NearEndLCD> (yes no) Possible values: - yes : loss of near end cell deliniation - no : no loss of near end cell deliniation	status of lcd with its previous logged value. <i>This element is only shown in detail mode.</i>
vect-dle	Parameter type: <Alarm::NearEndVectDle> (yes no) Possible values: - yes : loss of us signal due to disorderly leaving event - no : no disorderly leaving detected	specifies whether a disorderly leaving event occurred or not. <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::NearEndVectDle> (yes no) Possible values: - yes : loss of us signal due to disorderly leaving event - no : no disorderly leaving detected	status of vect-dle with its previous logged value. <i>This element is only shown in detail mode.</i>

102.14 xDSL Far-end Alarm Log Status Command

Command Description

This command displays the xDSL far-end alarm log status.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm log xdsl far-end [ (index) ]
```

Command Parameters

Table 102.14-1 "xDSL Far-end Alarm Log Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm log table index

Command Output

Table 102.14-2 "xDSL Far-end Alarm Log Status Command" Display parameters

Specific Information		
name	Type	Description
last-updated-on	Parameter type: <Sys::timeInSecs> - the time (yyyy-mm-dd:hour:minutes:secs) - unit: UTC	network time in seconds when the alarm was logged. <i>This element is only shown in detail mode.</i>
port	Parameter type: <Itf::XdslLine> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number	identifies where the alarm occurred <i>This element is only shown in detail mode.</i>

Only Show Details: current and previous alarm log status		
name	Type	Description
los	Parameter type: <Alarm::FarEndLOS> (yes	specifies whether far end loss of signal occurred or not.

name	Type	Description
	no) Possible values: - yes : far end loss of signal occurred - no : no far end loss of signal	<i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::FarEndLOS> (yes no) Possible values: - yes : far end loss of signal occurred - no : no far end loss of signal	status of los with its previous logged value. <i>This element is only shown in detail mode.</i>
lof	Parameter type: <Alarm::FarEndLOF> (yes no) Possible values: - yes : far end loss of frame occurred - no : no far end loss of frame	specifies whether far end loss of frame occurred or not. <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::FarEndLOF> (yes no) Possible values: - yes : far end loss of frame occurred - no : no far end loss of frame	status of lof with its previous logged value. <i>This element is only shown in detail mode.</i>
lpr	Parameter type: <Alarm::FarEndLPR> (yes no) Possible values: - yes : far end loss of power detected - no : no far end loss of power	specifies whether far end loss of power detected or not. <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::FarEndLPR> (yes no) Possible values: - yes : far end loss of power detected - no : no far end loss of power	status of lpr with its previous logged value. <i>This element is only shown in detail mode.</i>
lol	Parameter type: <Alarm::FarEndLOL> (yes no) Possible values: - yes : far end loss of link detected - no : no far end loss of link	specifies whether far end loss of link detected or not. <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::FarEndLOL> (yes no) Possible values: - yes : far end loss of link detected - no : no far end loss of link	status of lol with its previous logged value. <i>This element is only shown in detail mode.</i>
lom	Parameter type: <Alarm::FarEndLOM> (yes no) Possible values: - yes : far end loss of margin occurred - no : no far end loss of margin	specifies whether far end loss of margin occurred or not. <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::FarEndLOM> (yes no) Possible values: - yes : far end loss of margin occurred	status of lom with its previous logged value. <i>This element is only shown in detail mode.</i>

102 Alarm Log Status Commands

name	Type	Description
	- no : no far end loss of margin	
ese	Parameter type: <Alarm::FarEndESE> (yes no) Possible values: - yes : far end excessive severe errors occurred - no : no far end excessive severe errors occurred	specifies whether far end excessive severe errors occurred or not. <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::FarEndESE> (yes no) Possible values: - yes : far end excessive severe errors occurred - no : no far end excessive severe errors occurred	status of ese with its previous logged value. <i>This element is only shown in detail mode.</i>
bitrate	Parameter type: <Alarm::FarEndBRthres> (below-plan meets-plan) Possible values: - below-plan : downstream planned bitrate not reached after initialization - meets-plan : downstream planned bitrate reached	specifies whether downstream planned bitrate reached or not. <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::FarEndBRthres> (below-plan meets-plan) Possible values: - below-plan : downstream planned bitrate not reached after initialization - meets-plan : downstream planned bitrate reached	status of bitrate with its previous logged value. <i>This element is only shown in detail mode.</i>
ncd	Parameter type: <Alarm::FarEndNCD> (no-cell-deline cell-deline-occurred) Possible values: - no-cell-deline : no far end cell delineation - cell-deline-occurred : far end cell delineation occurred	specifies whether far end cell delineation occurred or not. <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::FarEndNCD> (no-cell-deline cell-deline-occurred) Possible values: - no-cell-deline : no far end cell delineation - cell-deline-occurred : far end cell delineation occurred	status of ncd with its previous logged value. <i>This element is only shown in detail mode.</i>
lcd	Parameter type: <Alarm::FarEndLCD> (yes no) Possible values: - yes : loss of far end cell deliniation - no : no loss of far end cell deliniation	specifies there is loss of far end cell deliniation or not. <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::FarEndLCD> (yes no) Possible values: - yes : loss of far end cell deliniation - no : no loss of far end cell deliniation	status of lcd with its previous logged value. <i>This element is only shown in detail mode.</i>
upbo-vio	Parameter type: <Alarm::FarEndUPBO> (yes no) Possible values: - yes : UPBO violation - no : no UPBO violation	UPBO violation <i>This element is only shown in detail mode.</i>

name	Type	Description
cpe-pol	Parameter type: <Alarm::FarEndActFail> (yes no) Possible values: - yes : activation failure due to CPE policing - no : no activation failure due to CPE policing	activation failure due to CPE policing <i>This element is only shown in detail mode.</i>
mis-peer-35b	Parameter type: <Alarm::FarEndMismatchPeer35B> (yes no) Possible values: - yes : VDSL2 35b opmode mismatch between XTU-C and XTU-R - no : No VDSL2 35b opmode mismatch between XTU-C and XTU-R	VDSL2 35b opmode mismatch between XTU-C and XTU-R <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::FarEndMismatchPeer35B> (yes no) Possible values: - yes : VDSL2 35b opmode mismatch between XTU-C and XTU-R - no : No VDSL2 35b opmode mismatch between XTU-C and XTU-R	status of mismatch-peer-35b with its previous logged value. <i>This element is only shown in detail mode.</i>

102.15 TCA xDSL Alarm Log Status Command

Command Description

This command displays the xDSL threshold cross alarm log status.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm log xdsl-tca [ (index) ]
```

Command Parameters

Table 102.15-1 "TCA xDSL Alarm Log Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm log table index

Command Output

Table 102.15-2 "TCA xDSL Alarm Log Status Command" Display parameters

Specific Information		
name	Type	Description
last-updated-on	Parameter type: <Sys::timeInSecs> - the time (yyyy-mm-dd:hour:minutes:secs) - unit: UTC	network time in seconds when the alarm was logged. <i>This element is only shown in detail mode.</i>
port	Parameter type: <Itf::XdslLine> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number	identifies where the alarm occurred <i>This element is only shown in detail mode.</i>

Only Show Details: current and previous alarm log status		
name	Type	Description
errored-secs	Parameter type: <Alarm::ErroredSeconds> (above-thres	number of errored seconds exceeded or below threshold

name	Type	Description
	below-thres) Possible values: - above-thres : number of errored seconds exceeded threshold - below-thres : number of errored seconds below threshold	<i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::ErroredSeconds> (above-thres below-thres) Possible values: - above-thres : number of errored seconds exceeded threshold - below-thres : number of errored seconds below threshold	status of errored-secs with its previous logged value. <i>This element is only shown in detail mode.</i>
es-in-a-day	Parameter type: <Alarm::ErroredSecondsInAday> (above-thres below-thres) Possible values: - above-thres : number of errored seconds in a day, exceeded threshold - below-thres : number of errored seconds in a day, below threshold	errored seconds in a day exceeded or below threshold <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::ErroredSecondsInAday> (above-thres below-thres) Possible values: - above-thres : number of errored seconds in a day, exceeded threshold - below-thres : number of errored seconds in a day, below threshold	status of es-in-a-day with its previous logged value. <i>This element is only shown in detail mode.</i>
severely-es	Parameter type: <Alarm::SeverelyErroredSeconds> (above-thres below-thres) Possible values: - above-thres : number of severely errored seconds exceeded threshold - below-thres : number of severely errored seconds below threshold	number of severely errored seconds exceeded or below threshold <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::SeverelyErroredSeconds> (above-thres below-thres) Possible values: - above-thres : number of severely errored seconds exceeded threshold - below-thres : number of severely errored seconds below threshold	status of severely-es with its previous logged value. <i>This element is only shown in detail mode.</i>
severely-es-in-a-day	Parameter type: <Alarm::SevErroredSecsInAday> (above-thres below-thres) Possible values: - above-thres : number of severely errored seconds in a day, exceeded threshold - below-thres : number of severely errored seconds in a day, below threshold	number of severely errored seconds in a day, exceeded or below threshold <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::SevErroredSecsInAday> (above-thres below-thres) Possible values: - above-thres : number of severely errored seconds in a day,	status of severely-es-in-a-day with its previous logged value. <i>This element is only shown in detail mode.</i>

102 Alarm Log Status Commands

name	Type	Description
	exceeded threshold - below-thres : number of severely errored seconds in a day, below threshold	
unavail-secs	Parameter type: <Alarm::UnavailableSeconds> (above-thres below-thres) Possible values: - above-thres : number of unavailable seconds exceeded threshold - below-thres : number of unavailable seconds below threshold	number of unavailable seconds exceeded or below threshold <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::UnavailableSeconds> (above-thres below-thres) Possible values: - above-thres : number of unavailable seconds exceeded threshold - below-thres : number of unavailable seconds below threshold	status of unavail-secs with its previous logged value. <i>This element is only shown in detail mode.</i>
unavail-secs-in-a-day	Parameter type: <Alarm::UnavailSecsInAday> (above-thres below-thres) Possible values: - above-thres : number of unavailable seconds in a day, exceeded threshold - below-thres : number of unavailable seconds in a day, below threshold	number of far end unavailable seconds in a day, exceeded or below threshold <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::UnavailSecsInAday> (above-thres below-thres) Possible values: - above-thres : number of unavailable seconds in a day, exceeded threshold - below-thres : number of unavailable seconds in a day, below threshold	status of unavail-secs-in-a-day with its previous logged value. <i>This element is only shown in detail mode.</i>
es	Parameter type: <Alarm::FarEndErroredSeconds> (above-thres below-thres) Possible values: - above-thres : number of far end errored seconds exceeded threshold - below-thres : number of far end errored seconds below threshold	number of far end errored seconds exceeded or below threshold <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::FarEndErroredSeconds> (above-thres below-thres) Possible values: - above-thres : number of far end errored seconds exceeded threshold - below-thres : number of far end errored seconds below threshold	status of es with its previous logged value. <i>This element is only shown in detail mode.</i>
fe-severely-es	Parameter type: <Alarm::FarEndSevErroredSecs> (above-thres below-thres) Possible values: - above-thres : number of far end severely errored seconds exceeded threshold	number of far end severely errored seconds exceeded or below threshold <i>This element is only shown in detail mode.</i>

name	Type	Description
	- below-thres : number of far end severely errored seconds below threshold	
prev-status	Parameter type: <Alarm::FarEndSevErroredSecs> (above-thres below-thres) Possible values: - above-thres : number of far end severely errored seconds exceeded threshold - below-thres : number of far end severely errored seconds below threshold	status of fe-severely-es with its previous logged value. <i>This element is only shown in detail mode.</i>
fe-sev-es/day	Parameter type: <Alarm::FarEndSevErroredSecsInAday> (above-thres below-thres) Possible values: - above-thres : number of far end severely errored seconds in a day, exceeded threshold - below-thres : number of far end severely errored seconds in a day, below threshold	number of far end severely errored seconds in a day, exceeded or below threshold <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::FarEndSevErroredSecsInAday> (above-thres below-thres) Possible values: - above-thres : number of far end severely errored seconds in a day, exceeded threshold - below-thres : number of far end severely errored seconds in a day, below threshold	status of fe-sev-es/day with its previous logged value. <i>This element is only shown in detail mode.</i>
fe-unavail-secs	Parameter type: <Alarm::FarEndUnavailSecs> (above-thres below-thres) Possible values: - above-thres : number of far end unavailable seconds exceeded threshold - below-thres : number of far end unavailable seconds below threshold	number of far end unavailable seconds in a day, exceeded or below threshold <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::FarEndUnavailSecs> (above-thres below-thres) Possible values: - above-thres : number of far end unavailable seconds exceeded threshold - below-thres : number of far end unavailable seconds below threshold	status of fe-unavail-secs with its previous logged value. <i>This element is only shown in detail mode.</i>
fe-unavail-sec/day	Parameter type: <Alarm::FarEndUnavailSecsInAday> (above-thres below-thres) Possible values: - above-thres : number of far end unavailable seconds in a day, exceeded threshold - below-thres : number of far end unavailable seconds in a day, below threshold	number of far end unavailable seconds in a day, exceeded or below threshold <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::FarEndUnavailSecsInAday> (above-thres below-thres) Possible values: - above-thres : number of far end unavailable seconds in a day, exceeded threshold - below-thres : number of far end unavailable seconds in a	status of fe-unavail-sec/day with its previous logged value. <i>This element is only shown in detail mode.</i>

102 Alarm Log Status Commands

name	Type	Description
	day, below threshold	
fe-es-in-a-day	Parameter type: <Alarm::FarEndErroredSecsInAday> (above-thres below-thres) Possible values: - above-thres : number of far end errored seconds in a day, exceeded threshold - below-thres : number of far end errored seconds in a day, below threshold	number of far end errored seconds in a day, exceeded or below threshold <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::FarEndErroredSecsInAday> (above-thres below-thres) Possible values: - above-thres : number of far end errored seconds in a day, exceeded threshold - below-thres : number of far end errored seconds in a day, below threshold	status of fe-es-in-a-day with its previous logged value. <i>This element is only shown in detail mode.</i>
leftrs	Parameter type: <Alarm::LeftrSeconds> (above-thres below-thres) Possible values: - above-thres : number of low error free throughput seconds exceeded threshold - below-thres : number of low error free throughput seconds below threshold	number of low error free throughput seconds exceeded or below threshold <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::LeftrSeconds> (above-thres below-thres) Possible values: - above-thres : number of low error free throughput seconds exceeded threshold - below-thres : number of low error free throughput seconds below threshold	status of leftrs with its previous logged value <i>This element is only shown in detail mode.</i>
leftrs-in-a-day	Parameter type: <Alarm::LeftrSecondsInAday> (above-thres below-thres) Possible values: - above-thres : number of low error free throughput seconds in a day, exceeded threshold - below-thres : number of low error free throughput seconds in a day, below threshold	number of low error free throughput seconds in a day, exceeded or below threshold <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::LeftrSecondsInAday> (above-thres below-thres) Possible values: - above-thres : number of low error free throughput seconds in a day, exceeded threshold - below-thres : number of low error free throughput seconds in a day, below threshold	status of leftrs-in-a-day with its previous logged value <i>This element is only shown in detail mode.</i>
fe-leftrs	Parameter type: <Alarm::FarEndLeftrSeconds> (above-thres below-thres) Possible values: - above-thres : number of far end low error free throughput seconds exceeded threshold - below-thres : number of far end low error free throughput seconds below threshold	number of far end low error free throughput seconds exceeded or below threshold <i>This element is only shown in detail mode.</i>

name	Type	Description
prev-status	Parameter type: <Alarm::FarEndLeftSeconds> (above-thres below-thres) Possible values: - above-thres : number of far end low error free throughput seconds exceeded threshold - below-thres : number of far end low error free throughput seconds below threshold	status of fe-lefts with its previous logged value <i>This element is only shown in detail mode.</i>
fe-lefts-in-a-day	Parameter type: <Alarm::FarEndLeftSecondsInAday> (above-thres below-thres) Possible values: - above-thres : number of far end low error free throughput seconds in a day, exceeded threshold - below-thres : number of far end low error free throughput seconds in a day, below threshold	number of far end low error free throughput seconds in a day, exceeded or below threshold <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::FarEndLeftSecondsInAday> (above-thres below-thres) Possible values: - above-thres : number of far end low error free throughput seconds in a day, exceeded threshold - below-thres : number of far end low error free throughput seconds in a day, below threshold	status of fe-lefts-in-a-day with its previous logged value <i>This element is only shown in detail mode.</i>
xtca-auto-port-reset	Parameter type: <Alarm::AutoPortResetInAweek> (above-thres below-thres) Possible values: - above-thres : number of auto-port-resets reached threshold with in a week - below-thres : number of auto-port-resets below threshold	number of auto port resets reached threshold in a week <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::AutoPortResetInAweek> (above-thres below-thres) Possible values: - above-thres : number of auto-port-resets reached threshold with in a week - below-thres : number of auto-port-resets below threshold	status of xtca-auto-port-reset with its previous logged value <i>This element is only shown in detail mode.</i>
reinit	Parameter type: <Alarm::Reinit> (above-thres below-thres) Possible values: - above-thres : number of reinit counter exceeded threshold - below-thres : number of reinit counter below threshold	number of Reinitialization count in 15min, exceeded or below threshold <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::Reinit> (above-thres below-thres) Possible values: - above-thres : number of reinit counter exceeded threshold - below-thres : number of reinit counter below threshold	status of reinit with its previous logged value <i>This element is only shown in detail mode.</i>
reinit-in-a-day	Parameter type: <Alarm::ReinitInAday> (above-thres below-thres) Possible values: - above-thres : number of reinit counter exceeded threshold - below-thres : number of reinit counter below threshold	number of Reinitialization count in a day, exceeded or below threshold <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::ReinitInAday>	status of reinit-in-a-day with its

102 Alarm Log Status Commands

name	Type	Description
	(above-thres below-thres) Possible values: - above-thres : number of renint counter exceeded threshold - below-thres : number of reinit counter below threshold	previous logged value <i>This element is only shown in detail mode.</i>

102.16 Protection Group Alarm Log Status Command

Command Description

This command displays the protection group alarm log status.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm log olt-gen [ (index) ]
```

Command Parameters

Table 102.16-1 "Protection Group Alarm Log Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm log table index

Command Output

Table 102.16-2 "Protection Group Alarm Log Status Command" Display parameters

Specific Information		
name	Type	Description
last-updated-on	Parameter type: <Sys::timeInSecs> - the time (yyyy-mm-dd:hour:minutes:secs) - unit: UTC	network time in seconds when the alarm was logged. <i>This element is only shown in detail mode.</i>
port	Parameter type: <Gpon::PonId> (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> x-pon : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::XPonId> 25g-pon : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::M25GPonId>) Possible values: - 25g-pon : 25g pon - x-pon : Xgs pon Field type <Eqpt::RackId> - the rack number	specify which port the alarm occurred on. <i>This element is only shown in detail mode.</i>

102 Alarm Log Status Commands

name	Type	Description
	Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Eqpt::XPonId> - the XGS PON identifier Field type <Eqpt::M25GPonId> - the 25G PON identifier	

Only Show Details: current alarm log status		
name	Type	Description
olt-pon-comm	Parameter type: <Alarm::OltPonComm> ((failing fail) ok) Possible values: - failing : OLT port communication is failing - fail : OLT port communication is failing - ok : port protection is ok	current status of PON Communication failure on OLT Port <i>This element is only shown in detail mode.</i>
olt-gen-tf	Parameter type: <Alarm::OltGenTf> ((failing fail) ok) Possible values: - failing : port protection is failing - fail : port protection is failing - ok : port protection is ok	current status of transmit failure on OLT port <i>This element is only shown in detail mode.</i>
olt-new-ont	Parameter type: <Alarm::OltNewOnt> ((failing fail) ok) Possible values: - failing : port protection is failing - fail : port protection is failing - ok : port protection is ok	current status of unprovisioned ont appearance <i>This element is only shown in detail mode.</i>
olt-pon-mea	Parameter type: <Alarm::OltPonMea> ((failing fail) ok) Possible values: - failing : port protection is failing - fail : port protection is failing - ok : port protection is ok	current status of pon provision failure. <i>This element is only shown in detail mode.</i>
olt-pon-loss	Parameter type: <Alarm::OltPonLoss> ((failing fail) ok) Possible values: - failing : port protection is failing - fail : port protection is failing - ok : port protection is ok	current status of pon loss. <i>This element is only shown in detail mode.</i>
pon-rogue-test	Parameter type: <Alarm::PonRogueTest> ((failing fail) ok) Possible values: - failing : Rogue ONT detection mechanism effective is failing - fail : Rogue ONT detection mechanism effective is failing - ok : Rogue ONT detection mechanism effective is ok	current status of diagnostic tests <i>This element is only shown in detail mode.</i>
onu-loid-conflict	Parameter type: <Alarm::OnuLoidConflict> ((failing fail)	current status of loid conflict ont. <i>This element is only shown in</i>

name	Type	Description
	ok) Possible values: - failing : port protection is failing - fail : port protection is failing - ok : port protection is ok	<i>detail mode.</i>
onu-loid-pwd-err	Parameter type: <Alarm::OnuLoidPwdErr> ((failing fail) ok) Possible values: - failing : port protection is failing - fail : port protection is failing - ok : port protection is ok	current status of loid password error. <i>This element is only shown in detail mode.</i>
stk-laser-dis	Parameter type: <Alarm::StkLaserDis> ((failing fail) ok) Possible values: - failing : port protection is failing - fail : port protection is failing - ok : port protection is ok	current status of stuck laser disabled. <i>This element is only shown in detail mode.</i>
pon-alien-test	Parameter type: <Alarm::PonAlienTest> ((failing fail) ok) Possible values: - failing : Alien ONT detection mechanism is active - fail : Alien ONT detection mechanism is active - ok : Alien ONT detection mechanism is not active	current status of alien diagnostic tests <i>This element is only shown in detail mode.</i>
pon-alien-detect	Parameter type: <Alarm::AlienDetected> ((failing fail) ok) Possible values: - failing : Alien ONT detected - fail : Alien ONT detected - ok : No alien ONT detected	current status of alien detect <i>This element is only shown in detail mode.</i>
pon-rng-mismatch	Parameter type: <Alarm::PonRngMismatch> ((failing fail) ok) Possible values: - failing : ranging mismatch detection mechanism effective is failing - fail : ranging mismatch detection mechanism effective is failing - ok : ranging mismatch detection mechanism effective is ok	current status of ranging mismatch <i>This element is only shown in detail mode.</i>
pon-sfp-mismatch	Parameter type: <Alarm::PonSfpMismatch> ((failing fail) ok) Possible values: - failing : pon sfp mismatch is failing - fail : pon sfp mismatch is failing - ok : pon sfp mismatch is ok	current status of sfp mismatch <i>This element is only shown in detail mode.</i>
deactont-high-tca	Parameter type: <Alarm::DeactOntHighTca> (failing ok) Possible values: - failing : pon deactivated ont amount exceed high threshold occurred - ok : pon deactivated ont amount is less than high threshold occurred	current status of deactont high tca <i>This element is only shown in detail mode.</i>

102 Alarm Log Status Commands

name	Type	Description
deactont-low-tca	Parameter type: <Alarm::DeactOntLowTca> (failing ok) Possible values: - failing : pon deactivated ont amount exceed low threshold occurred - ok : pon deactivated ont amount is less than low threshold occurred	current status of deactont low tca <i>This element is only shown in detail mode.</i>
datapath-integ	Parameter type: <Alarm::DataPathInteg> (failing ok) Possible values: - failing : number of ONTs with SIPREGTO alarm exceeds threshold - ok : number of ONTs with SIPREGTO alarm does not exceed the threshold	current status of PON Data Path Integrity <i>This element is only shown in detail mode.</i>
pon-ddr-fault	Parameter type: <Alarm::DdrFault> (failing ok) Possible values: - failing : pon failure due to ddr fault - ok : ddr ok	pon failure due to ddr fault <i>This element is only shown in detail mode.</i>

102.17 Vectoring Line Alarm Log Status Command

Command Description

This command displays the vectoring line alarm log status.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm log vect-line [ (index) ]
```

Command Parameters

Table 102.17-1 "Vectoring Line Alarm Log Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm log table index

Command Output

Table 102.17-2 "Vectoring Line Alarm Log Status Command" Display parameters

Specific Information		
name	Type	Description
last-updated-on	Parameter type: <Sys::timeInSecs> - the time (yyyy-mm-dd:hour:minutes:secs) - unit: UTC	network time in seconds when the alarm was logged. <i>This element is only shown in detail mode.</i>
port	Parameter type: <Itf::XdslLine> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number	specifies where the alarm has occurred. <i>This element is only shown in detail mode.</i>

Only Show Details: current and previous alarm log status		
name	Type	Description
xtc-variation-vict	Parameter type: <Alarm::VectXtcVariation> (excessive	excessive : abnormal amplitude variation in xtc coefficients

102 Alarm Log Status Commands

name	Type	Description
	normal) Possible values: - excessive : abnormal amplitude variation in xtc coefficients - normal : no excessive xtc coefficients variation	<i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::VectXtcVariation> (excessive normal) Possible values: - excessive : abnormal amplitude variation in xtc coefficients - normal : no excessive xtc coefficients variation	status of xtc-variation-vict with its previous logged value <i>This element is only shown in detail mode.</i>
xtc-variation-dist	Parameter type: <Alarm::VectXtcVariationDist> (excessive normal) Possible values: - excessive : abnormal amplitude variation in xtc coefficients - normal : no excessive xtc coefficients variation	specifies if excessive disturber crosstalk coefficient variation occurred or not <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::VectXtcVariationDist> (excessive normal) Possible values: - excessive : abnormal amplitude variation in xtc coefficients - normal : no excessive xtc coefficients variation	status of xtc-variation-dist with its previous logged value <i>This element is only shown in detail mode.</i>
corrupted-errf	Parameter type: <Alarm::VectCorptErrf> (yes no) Possible values: - yes : at least 10% corrupted or missing errorf samples received - no : received errorf samples ok	specifies if corrupted or at least 10% missing errorf samples received occurred or not <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::VectCorptErrf> (yes no) Possible values: - yes : at least 10% corrupted or missing errorf samples received - no : received errorf samples ok	status of corrupted-errf with its previous logged value <i>This element is only shown in detail mode.</i>
vect-cpe-cap-mismatch	Parameter type: <Alarm::VectCpeCapMism> (yes no) Possible values: - yes : not allowed Vectoring CPE connected - no : allowed Vectoring CPE connected	specifies if an allowed Vectoring CPE is connected or not <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::VectCpeCapMism> (yes no) Possible values: - yes : not allowed Vectoring CPE connected - no : allowed Vectoring CPE connected	status of vect-cpe-cap-mismatch with its previous logged value <i>This element is only shown in detail mode.</i>
vect-conf-not-feas	Parameter type: <Alarm::VectConfNotFeas> (yes no) Possible values: - yes : vectoring configuration not feasible	specifies if the vectoring configuration is feasible <i>This element is only shown in detail mode.</i>

name	Type	Description
	- no : vectoring configuration feasible	
prev-status	Parameter type: <Alarm::VectConfNotFeas> (yes no) Possible values: - yes : vectoring configuration not feasible - no : vectoring configuration feasible	status of vect-conf-not-feas with its previous logged value <i>This element is only shown in detail mode.</i>

102.18 Vectoring Board Alarm Log Status Command

Command Description

This command displays the vectoring board alarm log status.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm log vect-board [ (index) ]
```

Command Parameters

Table 102.18-1 "Vectoring Board Alarm Log Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm log table index

Command Output

Table 102.18-2 "Vectoring Board Alarm Log Status Command" Display parameters

Specific Information		
name	Type	Description
last-updated-on	Parameter type: <Sys::timeInSecs> - the time (yyyy-mm-dd:hour:minutes:secs) - unit: UTC	network time in seconds when the alarm was logged. <i>This element is only shown in detail mode.</i>
board-index	Parameter type: <Equipm::EqptVpSlotIndex> (ctrl : <Eqpt::RackId> / <Eqpt::ShelfId> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId>) Possible values: - ctrl : ctrl-slot Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number	specifies where the alarm has occurred. <i>This element is only shown in detail mode.</i>
vp-link-index	Parameter type: <Alarm::VectVpLinkId2>	this is the vplink id. This index

name	Type	Description
	- specifies the soft-link or the vp-link on the vp-board, or zero - range: [0,1...16]	has value zero when it is not used <i>This element is only shown in detail mode.</i>

Only Show Details: current and previous alarm log status

name	Type	Description
vp-lt-mismatch	Parameter type: <Alarm::VectVpLtMism> (yes no) Possible values: - yes : mismatch between expected and actual vp-lt mapping or incompatible sw version on vp and lt - no : expected and actual vp-lt in line or vp and lt have compatible sw versions, OR autodiscovery enabled on vp, autodiscovery disabled on lt	specifies if a mismatch between expected and actual vp-lt mapping OR incompatible sw version on vp and lt is detected or not. In case vplt-autodiscovery disabled on vp, failure reported on vp-board. In case vplt-autodiscovery enabled on lt, failure reported on lt-board. <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::VectVpLtMism> (yes no) Possible values: - yes : mismatch between expected and actual vp-lt mapping or incompatible sw version on vp and lt - no : expected and actual vp-lt in line or vp and lt have compatible sw versions, OR autodiscovery enabled on vp, autodiscovery disabled on lt	status of vp-lt-mismatch with its previous logged value <i>This element is only shown in detail mode.</i>
qsfp-id	Parameter type: <Alarm::VectQsfpInvalidNokiaID> (invalid valid) Possible values: - invalid : QSFP does not have valid Nokia ID - valid : QSFP has valid Nokia ID OR no QSFP detected.	specifies if detected QSFP of the frontcable has a valid Nokia ID or not <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::VectQsfpInvalidNokiaID> (invalid valid) Possible values: - invalid : QSFP does not have valid Nokia ID - valid : QSFP has valid Nokia ID OR no QSFP detected.	status of qsfp-id with its previous logged value <i>This element is only shown in detail mode.</i>
vp-lt-link	Parameter type: <Alarm::VPLTLINKFAIL> (linkdown linkup) Possible values: - linkdown : vp-lt link problem - linkup : vp-lt link ok or no lt-expected OR autodiscovery enabled on vp, autodiscovery disabled on lt	specifies if a VP-LT link failure is detected or not. In case vplt-autodiscovery disabled on vp, failure reported on vp-board when an lt was expected but no valid connection between vp-lt. In case vplt-autodiscovery enabled on lt, failure reported on lt-board when no valid connection between vp-lt. <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::VPLTLINKFAIL> (linkdown linkup) Possible values: - linkdown : vp-lt link problem - linkup : vp-lt link ok or no lt-expected OR autodiscovery enabled on vp, autodiscovery disabled on lt	status of VP-LT Link Failure with its previous logged value <i>This element is only shown in detail mode.</i>
vect-no-gain-at-init	Parameter type: <Alarm::VECTNOGAINATINIT>	vectoring gain-at-init mode is not

102 Alarm Log Status Commands

name	Type	Description
	(yes no) Possible values: - yes : Lines cannot train in gain-at-init mode - no : Lines can train in gain-at-init mode	feasible due to excessive number of non-FDPS capable CPEs <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::VECTNOGAINATINIT> (yes no) Possible values: - yes : Lines cannot train in gain-at-init mode - no : Lines can train in gain-at-init mode	status of vect-no-gain-at-init with its previous logged value <i>This element is only shown in detail mode.</i>

102.19 Electrical-to-Optical Conversion Alarm Log Status Command

Command Description

This command displays the electrical-to-optical conversion alarm log status.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

> show alarm log eo-conversion [(index)]

Command Parameters

Table 102.19-1 " Electrical-to-Optical Conversion Alarm Log Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm log table index

Command Output

Table 102.19-2 " Electrical-to-Optical Conversion Alarm Log Status Command" Display parameters

Specific Information		
name	Type	Description
last-updated-on	Parameter type: <Sys::timeInSecs> - the time (yyyy-mm-dd:hour:minutes:secs) - unit: UTC	network time in seconds when the alarm was logged. <i>This element is only shown in detail mode.</i>
port	Parameter type: <SignedInteger> - a signed integer	identifies where the alarm occurred <i>This element is only shown in detail mode.</i>

Only Show Details: current and previous alarm log status		
name	Type	Description
loss-of-signal	Parameter type: <Alarm::EoConvLOS> (yes no) Possible values:	specifies whether loss of signal detected or not in the EO conversion module <i>This element is only shown in</i>

102 Alarm Log Status Commands

name	Type	Description
	- yes : loss of signal detected in the EO conversion module - no : no loss of signal detected in the EO conversion module	<i>detail mode.</i>
prev-status	Parameter type: <Alarm::EoConvLOS> (yes no) Possible values: - yes : loss of signal detected in the EO conversion module - no : no loss of signal detected in the EO conversion module	status of loss-of-signal with its previous logged value. <i>This element is only shown in detail mode.</i>
transmission	Parameter type: <Alarm::EoConvTx> (faulty ok) Possible values: - faulty : transmission fault in the EO module - ok : transmission OK	specifies whether transmission fault is occurred or not in the EO module <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::EoConvTx> (faulty ok) Possible values: - faulty : transmission fault in the EO module - ok : transmission OK	status of transmission with its previous logged value. <i>This element is only shown in detail mode.</i>

102.20 Authentication Alarm Log Status Command

Command Description

This command displays the authentication-related alarm log status.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

> show alarm log authentication [(index)]

Command Parameters

Table 102.20-1 "Authentication Alarm Log Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm log table index

Command Output

Table 102.20-2 "Authentication Alarm Log Status Command" Display parameters

Specific Information		
name	Type	Description
last-updated-on	Parameter type: <Sys::timeInSecs> - the time (yyyy-mm-dd:hour:minutes:secs) - unit: UTC	network time in seconds when the alarm was logged. <i>This element is only shown in detail mode.</i>
uni	Parameter type: <Itf::BridgePortItf> (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::VpiId> : <Eqpt::VciId> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> / <Eqpt::OntPortId> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / voip <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / vuni <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::LLId> ng2 : <Eqpt::ChannelGroupId> /	specify which uni the alarm occurred on. <i>This element is only shown in detail mode.</i>

name	Type	Description
	<Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / <Eqpt::Ng2OntSlotId> / <Eqpt::Ng2OntPortId> ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / vuni) Possible values: - ng2 : ngpon2 style identification Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number Field type <Eqpt::VpiId> - atm VPI Field type <Eqpt::VciId> - atm VCI Field type <Eqpt::ChannelGroupId> - the channel group identifier Field type <Eqpt::SubChannelGroupId> - the subchannel group identifier Field type <Eqpt::PonId> - the PON identifier Field type <Eqpt::OntId> - the ONT identifier Field type <Eqpt::Ng2OntId> - the NG2 ONT identifier Possible values: - voip : virtual uni identifier obsolete alternative replaced by vuni - vuni : virtual uni identifier Possible values: - vuni : virtual NGPON2 uni identifier Field type <Eqpt::OntSlotId> - the ONT SLOT identifier Field type <Eqpt::OntPortId> - the ONT PORT identifier Field type <Eqpt::Ng2OntSlotId> - the NGPON2 ONT SLOT identifier Field type <Eqpt::Ng2OntPortId> - the NGPON2 ONT PORT identifier Field type <Eqpt::LLId> - the LLID identifier, range 1 for EPON, range 1-8 for DPOE	

Only Show Details: current and previous alarm log status		
name	Type	Description
vlan-assignment short name: vlan-assign	Parameter type: <Alarm::VLANassignment> (failed successful) Possible values: - failed : failure to assign a VLAN for a user session - successful : assigned a VLAN for a user session	specifies whether a VLAN for a user session is assigned or failed <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::VLANassignment> (failed successful) Possible values: - failed : failure to assign a VLAN for a user session	status of vlan-assignment with its previous logged value. <i>This element is only shown in detail mode.</i>

name	Type	Description
	- successful : assigned a VLAN for a user session	
vsa-info-invalid short name: vsa-invalid	Parameter type: <Alarm::VSAValid> (yes no) Possible values: - yes : invalid VSA info alarm from RADIUS - no : valid VSA info from RADIUS and no alarm	specifies whether vsa information valid or not from RADIUS server. <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::VSAValid> (yes no) Possible values: - yes : invalid VSA info alarm from RADIUS - no : valid VSA info from RADIUS and no alarm	status of vsa-info-invalid with its previous logged value. <i>This element is only shown in detail mode.</i>
mac-conflict short name: mac-cflict	Parameter type: <Alarm::MACConflict> (yes no) Possible values: - yes : status of auth-mac-conflict alarm occurred - no : no status of auth-mac-conflict alarm occurred	specifies whether mac conflict occurred or not in mac based authentication. <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::MACConflict> (yes no) Possible values: - yes : status of auth-mac-conflict alarm occurred - no : no status of auth-mac-conflict alarm occurred	status of mac-conflict with its previous logged value. <i>This element is only shown in detail mode.</i>
user-pwd-fault short name: usrpwd-falt	Parameter type: <Alarm::USRPWDFault> (yes no) Possible values: - yes : invalid user or password alarm occurred - no : valid user and password and no alarm	specifies whether user or password valid or not in mac based authentication. <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::USRPWDFault> (yes no) Possible values: - yes : invalid user or password alarm occurred - no : valid user and password and no alarm	status of user-pwd-fault with its previous logged value. <i>This element is only shown in detail mode.</i>

102.21 xDSL Bonding Alarm Log Status Command

Command Description

This command displays the xDSL bonding-related alarm log status.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm log bonding-group [ (index) ]
```

Command Parameters

Table 102.21-1 "xDSL Bonding Alarm Log Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm log table index

Command Output

Table 102.21-2 "xDSL Bonding Alarm Log Status Command" Display parameters

Specific Information		
name	Type	Description
last-updated-on	Parameter type: <Sys::timeInSecs> - the time (yyyy-mm-dd:hour:minutes:secs) - unit: UTC	network time in seconds when the alarm was logged. <i>This element is only shown in detail mode.</i>
group	Parameter type: <Xdsl::BondingInterfaceIndex> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number	identifies the bonding group interface index <i>This element is only shown in detail mode.</i>

Only Show Details: current and previous alarm log status		
name	Type	Description
up-plan-bitrate	Parameter type: <Alarm::UpPlannedBitrate> (failure	specifies whether the actual group upstream bit rate is above

name	Type	Description
	ok) Possible values: - failure : actual group bitrate is above the minimum upstream bitrate but below the group upstream planned bitrate - ok : actual group bitrate is above the group upstream planned bitrate	the group upstream planned bit rate or not <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::UpPlannedBitrate> (failure ok) Possible values: - failure : actual group bitrate is above the minimum upstream bitrate but below the group upstream planned bitrate - ok : actual group bitrate is above the group upstream planned bitrate	status of up-plan-bitrate with its previous logged value. <i>This element is only shown in detail mode.</i>
down-plan-bitrate	Parameter type: <Alarm::DownPlanBitrate> (failure ok) Possible values: - failure : actual group bitrate is above the minimum downstream bitrate but below the group downstream planned bitrate - ok : actual group bitrate is above the group downstream planned bitrate	specifies whether the actual group downstream bit rate is above the group downstream planned bit rate or not <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::DownPlanBitrate> (failure ok) Possible values: - failure : actual group bitrate is above the minimum downstream bitrate but below the group downstream planned bitrate - ok : actual group bitrate is above the group downstream planned bitrate	status of down-plan-bitrate with its previous logged value. <i>This element is only shown in detail mode.</i>
up-min-bitrate	Parameter type: <Alarm::UpMinBitrate> (failure ok) Possible values: - failure : actual group bitrate is below the group upstream minimum bitrate - ok : actual group bitrate is above the group upstream minimum bitrate	specifies whether the actual group upstream bit rate is above the group upstream minimum bit rate or not <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::UpMinBitrate> (failure ok) Possible values: - failure : actual group bitrate is below the group upstream minimum bitrate - ok : actual group bitrate is above the group upstream minimum bitrate	status of up-min-bitrate with its previous logged value. <i>This element is only shown in detail mode.</i>
down-min-bitrate	Parameter type: <Alarm::DownMinBitrate> (failure ok) Possible values: - failure : actual group bitrate is below the group downstream minimum bitrate - ok : actual group bitrate is above the group downstream	specifies whether the actual group downstream bit rate is above the group downstream minimum bit rate or not <i>This element is only shown in detail mode.</i>

102 Alarm Log Status Commands

name	Type	Description
	minimum bitrate	
prev-status	Parameter type: <Alarm::DownMinBitrate> (failure ok) Possible values: - failure : actual group bitrate is below the group downstream minimum bitrate - ok : actual group bitrate is above the group downstream minimum bitrate	status of down-min-bitrate with its previous logged value. <i>This element is only shown in detail mode.</i>
up-config	Parameter type: <Alarm::UpConfig> (not-feasible feasible) Possible values: - not-feasible : upstream configuration not feasible - feasible : upstream configuration feasible	specifies whether the upstream configuration is feasible or not <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::UpConfig> (not-feasible feasible) Possible values: - not-feasible : upstream configuration not feasible - feasible : upstream configuration feasible	status of up-config with its previous logged value. <i>This element is only shown in detail mode.</i>
down-config	Parameter type: <Alarm::DownConfig> (not-feasible feasible) Possible values: - not-feasible : downstream configuration not feasible - feasible : downstream configuration feasible	specifies whether the downstream configuration is feasible or not <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::DownConfig> (not-feasible feasible) Possible values: - not-feasible : downstream configuration not feasible - feasible : downstream configuration feasible	status of down-config with its previous logged value. <i>This element is only shown in detail mode.</i>
bond-cpe-conn	Parameter type: <Alarm::BondCPE> (not-connected connected) Possible values: - not-connected : bonding cpe modem not connected - connected : bonding cpe modem connected	specifies whether a bonding CPE modem is connected or not <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::BondCPE> (not-connected connected) Possible values: - not-connected : bonding cpe modem not connected - connected : bonding cpe modem connected	status of bond-cpe-conn with its previous logged value. <i>This element is only shown in detail mode.</i>
multiple-cpes	Parameter type: <Alarm::BgConnCPE> (true false) Possible values: - true : bonding group has multiple cpe modems connected - false : bonding group has one cpe modem connected	specifies whether the lines of a bonding group are connected to multiple CPEs or only one <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::BgConnCPE> (true false) Possible values: - true : bonding group has multiple cpe modems connected - false : bonding group has one cpe modem connected	status of bg-conn-cpes with its previous logged value. <i>This element is only shown in detail mode.</i>

name	Type	Description
register	Parameter type: <Alarm::BgRegFail> (failure ok) Possible values: - failure : bonding group discovery or aggregation register failure detected - ok : bonding group discovery or aggregation register failure not detected	specifies whether a discovery or aggregation failure is encountered or not <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::BgRegFail> (failure ok) Possible values: - failure : bonding group discovery or aggregation register failure detected - ok : bonding group discovery or aggregation register failure not detected	status of bg-reg-fail with its previous logged value. <i>This element is only shown in detail mode.</i>
group-incomplete	Parameter type: <Alarm::BgNotCompl> (true false) Possible values: - true : bonding group is incomplete - false : bonding group is complete	specifies whether all configured lines of the bonding group are part of the bonding group <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::BgNotCompl> (true false) Possible values: - true : bonding group is incomplete - false : bonding group is complete	status of bg-not-compl with its previous logged value. <i>This element is only shown in detail mode.</i>

102.22 Redundancy Alarm Log Status Command

Command Description

This command displays the redundancy alarm log status.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

> show alarm log redundancy [(index)]

Command Parameters

Table 102.22-1 "Redundancy Alarm Log Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm log table index

Command Output

Table 102.22-2 "Redundancy Alarm Log Status Command" Display parameters

Specific Information		
name	Type	Description
last-updated-on	Parameter type: <Sys::timeInSecs> - the time (yyyy-mm-dd:hour:minutes:secs) - unit: UTC	network time in seconds when the alarm was logged. <i>This element is only shown in detail mode.</i>

Only Show Details: current and previous alarm log status		
name	Type	Description
loss-swo-cap	Parameter type: <Alarm::SwoCap> (loss not-loss) Possible values: - loss : system loss of the swichover capability - not-loss : system not loss of the swichover capability	identify the swichover capability in a redundant system. <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::SwoCap> (loss not-loss) Possible values: - loss : system loss of the swichover capability - not-loss : system not loss of the swichover capability	status of the swichover capability with its previous logged value. <i>This element is only shown in detail mode.</i>
ping-check	Parameter type: <Alarm::PingCheck>	identify the ping check in a

name	Type	Description
	(failure successful) Possible values: - failure : system failure of ping check - successful : system successful of ping check	redundant system. <i>This element is only shown in detail mode.</i>

102.23 Custom Alarm Log Status Command

Command Description

This command displays the custom alarm log status.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm log custom [ (index) ]
```

Command Parameters

Table 102.23-1 "Custom Alarm Log Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm log table index

Command Output

Table 102.23-2 "Custom Alarm Log Status Command" Display parameters

Specific Information		
name	Type	Description
last-updated-on	Parameter type: <Sys::timeInSecs> - the time (yyyy-mm-dd:hour:minutes:secs) - unit: UTC	network time in seconds when the alarm was logged. <i>This element is only shown in detail mode.</i>
custom-alarm1	Parameter type: <Alarm::custom1> (yes no) Possible values: - yes : Miscellaneous environment alarm - no : no Miscellaneous environment alarm	identify the customizableAlarm1 . <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::custom1> (yes no) Possible values: - yes : Miscellaneous environment alarm - no : no Miscellaneous environment alarm	status of customizableAlarm1 with its previous logged value. <i>This element is only shown in detail mode.</i>
custom-alarm2	Parameter type: <Alarm::custom2> (yes no)	identify the customizableAlarm2 . <i>This element is only shown in</i>

name	Type	Description
	Possible values: - yes : Miscellaneous environment alarm - no : no Miscellaneous environment alarm	<i>detail mode.</i>
prev-status	Parameter type: <Alarm::custom2> (yes no) Possible values: - yes : Miscellaneous environment alarm - no : no Miscellaneous environment alarm	status of customizableAlarm2 with its previous logged value. <i>This element is only shown in detail mode.</i>
custom-alarm3	Parameter type: <Alarm::custom3> (yes no) Possible values: - yes : Miscellaneous environment alarm - no : no Miscellaneous environment alarm	identify the customizableAlarm3. <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::custom3> (yes no) Possible values: - yes : Miscellaneous environment alarm - no : no Miscellaneous environment alarm	status of customizableAlarm3 with its previous logged value. <i>This element is only shown in detail mode.</i>
custom-alarm4	Parameter type: <Alarm::custom4> (yes no) Possible values: - yes : Miscellaneous environment alarm - no : no Miscellaneous environment alarm	identify the customizableAlarm4. <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::custom4> (yes no) Possible values: - yes : Miscellaneous environment alarm - no : no Miscellaneous environment alarm	status of customizableAlarm4 with its previous logged value. <i>This element is only shown in detail mode.</i>
custom-alarm5	Parameter type: <Alarm::custom5> (yes no) Possible values: - yes : Miscellaneous environment alarm - no : no Miscellaneous environment alarm	identify the customizableAlarm5. <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::custom5> (yes no) Possible values: - yes : Miscellaneous environment alarm - no : no Miscellaneous environment alarm	status of customizableAlarm5 with its previous logged value. <i>This element is only shown in detail mode.</i>
custom-alarm6	Parameter type: <Alarm::custom6> (yes no) Possible values: - yes : Miscellaneous environment alarm - no : no Miscellaneous environment alarm	identify the customizableAlarm6. <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::custom6> (yes no) Possible values: - yes : Miscellaneous environment alarm - no : no Miscellaneous environment alarm	status of customizableAlarm6 with its previous logged value. <i>This element is only shown in detail mode.</i>

102 Alarm Log Status Commands

name	Type	Description
custom-alarm7	Parameter type: <Alarm::custom7> (yes no) Possible values: - yes : Miscellaneous environment alarm - no : no Miscellaneous environment alarm	identify the customizableAlarm7 . <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::custom7> (yes no) Possible values: - yes : Miscellaneous environment alarm - no : no Miscellaneous environment alarm	status of customizableAlarm7 with its previous logged value. <i>This element is only shown in detail mode.</i>
custom-alarm8	Parameter type: <Alarm::custom8> (yes no) Possible values: - yes : Miscellaneous environment alarm - no : no Miscellaneous environment alarm	identify the customizableAlarm8 . <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::custom8> (yes no) Possible values: - yes : Miscellaneous environment alarm - no : no Miscellaneous environment alarm	status of customizableAlarm8 with its previous logged value. <i>This element is only shown in detail mode.</i>
custom-alarm9	Parameter type: <Alarm::custom9> (yes no) Possible values: - yes : Miscellaneous environment alarm - no : no Miscellaneous environment alarm	identify the customizableAlarm9 . <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::custom9> (yes no) Possible values: - yes : Miscellaneous environment alarm - no : no Miscellaneous environment alarm	status of customizableAlarm9 with its previous logged value. <i>This element is only shown in detail mode.</i>
custom-alarm10	Parameter type: <Alarm::custom10> (yes no) Possible values: - yes : Miscellaneous environment alarm - no : no Miscellaneous environment alarm	identify the customizableAlarm10 . <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::custom10> (yes no) Possible values: - yes : Miscellaneous environment alarm - no : no Miscellaneous environment alarm	status of customizableAlarm10 with its previous logged value. <i>This element is only shown in detail mode.</i>
custom-alarm11	Parameter type: <Alarm::custom11> (yes no) Possible values: - yes : Miscellaneous environment alarm - no : no Miscellaneous environment alarm	identify the customizableAlarm11 . <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::custom11> (yes no)	status of customizableAlarm11 with its previous logged value. <i>This element is only shown in detail mode.</i>

name	Type	Description
	Possible values: - yes : Miscellaneous environment alarm - no : no Miscellaneous environment alarm	<i>detail mode.</i>
custom-alarm12	Parameter type: <Alarm::custom12> (yes no) Possible values: - yes : Miscellaneous environment alarm - no : no Miscellaneous environment alarm	identify the customizableAlarm12 . <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::custom12> (yes no) Possible values: - yes : Miscellaneous environment alarm - no : no Miscellaneous environment alarm	status of customizableAlarm12 with its previous logged value. <i>This element is only shown in detail mode.</i>
custom-alarm13	Parameter type: <Alarm::custom13> (yes no) Possible values: - yes : Miscellaneous environment alarm - no : no Miscellaneous environment alarm	identify the customizableAlarm13 . <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::custom13> (yes no) Possible values: - yes : Miscellaneous environment alarm - no : no Miscellaneous environment alarm	status of customizableAlarm13 with its previous logged value. <i>This element is only shown in detail mode.</i>
custom-alarm14	Parameter type: <Alarm::custom14> (yes no) Possible values: - yes : Miscellaneous environment alarm - no : no Miscellaneous environment alarm	identify the customizableAlarm14 . <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::custom14> (yes no) Possible values: - yes : Miscellaneous environment alarm - no : no Miscellaneous environment alarm	status of customizableAlarm14 with its previous logged value. <i>This element is only shown in detail mode.</i>
custom-alarm15	Parameter type: <Alarm::custom15> (yes no) Possible values: - yes : Miscellaneous environment alarm - no : no Miscellaneous environment alarm	identify the customizableAlarm15 . <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::custom15> (yes no) Possible values: - yes : Miscellaneous environment alarm - no : no Miscellaneous environment alarm	status of customizableAlarm15 with its previous logged value. <i>This element is only shown in detail mode.</i>
custom-alarm16	Parameter type: <Alarm::custom16> (yes no) Possible values: - yes : Miscellaneous environment alarm - no : no Miscellaneous environment alarm	identify the customizableAlarm16 . <i>This element is only shown in detail mode.</i>

102 Alarm Log Status Commands

name	Type	Description
prev-status	Parameter type: <Alarm::custom16> (yes no) Possible values: - yes : Miscellaneous environment alarm - no : no Miscellaneous environment alarm	status of customizableAlarm16 with its previous logged value. <i>This element is only shown in detail mode.</i>
custom-alarm17	Parameter type: <Alarm::custom17> (yes no) Possible values: - yes : Miscellaneous environment alarm - no : no Miscellaneous environment alarm	identify the customizableAlarm17 . <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::custom17> (yes no) Possible values: - yes : Miscellaneous environment alarm - no : no Miscellaneous environment alarm	status of customizableAlarm17 with its previous logged value. <i>This element is only shown in detail mode.</i>

Only Show Details: host expansion shelves customizable alarms		
name	Type	Description
shelf	Parameter type: <Equipm::HolderId> (<Eqpt::RackId> / <Eqpt::ShelfId> not-applicable) Possible values: - not-applicable : not applicable Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number	this is the shelf id (equipment holder id) for host expansion alarms, otherwise it is the rack ID <i>This element is only shown in detail mode.</i>
he-custom-alarm1	Parameter type: <Alarm::he-custom1> (yes no) Possible values: - yes : Miscellaneous environment alarm - no : no Miscellaneous environment alarm	identify the host expansion shelf's customizableAlarm1 . <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::he-custom1> (yes no) Possible values: - yes : Miscellaneous environment alarm - no : no Miscellaneous environment alarm	status of the host expansion shelf's customizableAlarm1 with its previous logged value. <i>This element is only shown in detail mode.</i>
he-custom-alarm2	Parameter type: <Alarm::he-custom2> (yes no) Possible values: - yes : Miscellaneous environment alarm - no : no Miscellaneous environment alarm	identify the host expansion shelf's customizableAlarm2 . <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::he-custom2> (yes no) Possible values: - yes : Miscellaneous environment alarm - no : no Miscellaneous environment alarm	status of the host expansion shelf's customizableAlarm2 with its previous logged value. <i>This element is only shown in detail mode.</i>
he-custom-alarm3	Parameter type: <Alarm::he-custom3> (yes no) Possible values:	identify the host expansion shelf's customizableAlarm3 . <i>This element is only shown in detail mode.</i>

name	Type	Description
	- yes : Miscellaneous environment alarm - no : no Miscellaneous environment alarm	
prev-status	Parameter type: <Alarm::he-custom3> (yes no) Possible values: - yes : Miscellaneous environment alarm - no : no Miscellaneous environment alarm	status of the host expansion shelf's customizableAlarm3 with its previous logged value. <i>This element is only shown in detail mode.</i>
he-custom-alarm4	Parameter type: <Alarm::he-custom4> (yes no) Possible values: - yes : Miscellaneous environment alarm - no : no Miscellaneous environment alarm	identify the host expansion shelf's customizableAlarm4 . <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::he-custom4> (yes no) Possible values: - yes : Miscellaneous environment alarm - no : no Miscellaneous environment alarm	status of the host expansion shelf's customizableAlarm4 with its previous logged value. <i>This element is only shown in detail mode.</i>
he-custom-alarm5	Parameter type: <Alarm::he-custom5> (yes no) Possible values: - yes : Miscellaneous environment alarm - no : no Miscellaneous environment alarm	identify the host expansion shelf's customizableAlarm5 . <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::he-custom5> (yes no) Possible values: - yes : Miscellaneous environment alarm - no : no Miscellaneous environment alarm	status of the host expansion shelf's customizableAlarm5 with its previous logged value. <i>This element is only shown in detail mode.</i>
he-custom-alarm6	Parameter type: <Alarm::he-custom6> (yes no) Possible values: - yes : Miscellaneous environment alarm - no : no Miscellaneous environment alarm	identify the host expansion shelf's customizableAlarm6 . <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::he-custom6> (yes no) Possible values: - yes : Miscellaneous environment alarm - no : no Miscellaneous environment alarm	status of the host expansion shelf's customizableAlarm6 with its previous logged value. <i>This element is only shown in detail mode.</i>

102.24 SFP Alarm Log Status Command

Command Description

This command displays the SFP alarm log status.

For Expander card SFP alarms, the remote LT slot-identifier that corresponds to the SFP is displayed in the output parameter "alarm index 1", and not the SFP faceplate cage-number identifier.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm log sfp [ (index) ]
```

Command Parameters

Table 102.24-1 "SFP Alarm Log Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm log table index

Command Output

Table 102.24-2 "SFP Alarm Log Status Command" Display parameters

Specific Information		
name	Type	Description
last-updated-on	Parameter type: <Sys::timeInSecs> - the time (yyyy-mm-dd:hour:minutes:secs) - unit: UTC	network time in seconds when the alarm was logged. <i>This element is only shown in detail mode.</i>
alarm index 1	Parameter type: <Alarm::SfpAlarmIdx1Type> (<Alarm::SfpAlarmIdx1> lt : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId>) Possible values: - lt : the lt-slot Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Alarm::SfpAlarmIdx1> - the host port faceplate number or the equipment slot-id for	this is the host sfp faceplate number for host alarms or it is the equipment slot id for expansion shelf alarms <i>This element is only shown in detail mode.</i>

name	Type	Description
alarm index 2	expansion shelf alarm Parameter type: <Ihub::EthernetPort> (nt-a : sfp : <Alarm::FacePlatePortIndex> nt-a : xfp : <Alarm::FacePlatePortIndex> nt-a : eth : <Alarm::FacePlatePortIndex> nt-b : sfp : <Alarm::FacePlatePortIndex> nt-b : xfp : <Alarm::FacePlatePortIndex> nt-b : eth : <Alarm::FacePlatePortIndex> ntio-1 : sfp : <Alarm::FacePlatePortIndex> ntio-1 : xfp : <Alarm::FacePlatePortIndex> ntio-2 : sfp : <Alarm::FacePlatePortIndex> ntio-2 : xfp : <Alarm::FacePlatePortIndex> lt : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> not-applicable lt-slot : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId>) Possible values: - nt-a : the nt-a slot - nt-b : the nt-b slot - ntio-1 : an nt applique slot in a single or multiple-ntio-shelf - ntio-2 : an nt applique slot in a multiple-ntio-shelf - lt : the lt slot - lt-slot : the port in lt slot - not-applicable : no port Possible values: - sfp : SFP port - xfp : XFP port - eth : RJ45 or lemi port Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Alarm::FacePlatePortIndex> - the faceplate port number	this is the ethernet port id or LT slot for host alarms. this index is not used for expansion shelf alarms <i>This element is only shown in detail mode.</i>

Only Show Details: host shelf alarms		
name	Type	Description
host-sfp-loss	Parameter type: <Alarm::hostSFPLOS> (failing ok) Possible values: - failing : host downlink SFP loss of signal - ok : host downlink SFP signal ok	current status host downlink SFP loss of signal <i>This element is only shown in detail mode.</i>
host-sfp-tx	Parameter type: <Alarm::hostSFPTxFail> (failing ok) Possible values: - failing : host downlink SFP tx failure - ok : host downlink SFP tx ok	status host downlink SFP tx failure <i>This element is only shown in detail mode.</i>
host-sfp-pres	Parameter type: <Alarm::hostSFPMissing> (not-present present) Possible values: - not-present : host downlink SFP not present - present : host downlink SFP present	current status host downlink SFP not present <i>This element is only shown in detail mode.</i>
host-sfp-id	Parameter type: <Alarm::hostSFPInvalidNokiaID>	status host downlink SFP does

102 Alarm Log Status Commands

name	Type	Description
	(invalid valid) Possible values: - invalid : host downlink SFP does not have valid Nokia ID - valid : host downlink SFP has valid Nokia ID	not have valid Nokia ID <i>This element is only shown in detail mode.</i>
host-sfp-ctrl	Parameter type: <Alarm::hostSFPControlFail> (failing ok) Possible values: - failing : host downlink SFP control failure - ok : host downlink SFP control ok	status host downlink SFP control failure <i>This element is only shown in detail mode.</i>
host-sfp-rmtlt	Parameter type: <Alarm::hostSFPUnexpectedRemoteLT> (yes no) Possible values: - yes : host shelf SFP unexpected remote LT plug-in - no : host shelf SFP expected remote LT plug-in	host downlink SFP unexpected remote plug-in <i>This element is only shown in detail mode.</i>
host-sfp-mismatch	Parameter type: <Alarm::hostSFPAssignmentMismatch> (yes no) Possible values: - yes : host shelf SFP assignment does not match reported rack/shelf/slot - no : host shelf SFP assignment matches reported rack/shelf/slot	host downlink SFP assignment does not match reported rack/shelf/slot <i>This element is only shown in detail mode.</i>
host-sfp-incompt	Parameter type: <Alarm::hostSFPIncompatibleShelf> (yes no) Possible values: - yes : host shelf SFP incompatible shelf type detected - no : host shelf SFP compatible shelf type detected	host downlink SFP incompatible shelf type detected <i>This element is only shown in detail mode.</i>

Only Show Details: expansion shelf alarms		
name	Type	Description
exp-sfp-los	Parameter type: <Alarm::expansionShelfSFPLos> (failing ok) Possible values: - failing : expansion shelf downlink SFP loss of signal - ok : expansion shelf downlink SFP signal ok	current status expansion side downlink SFP loss of signal <i>This element is only shown in detail mode.</i>
exp-sfp-tx	Parameter type: <Alarm::expansionShelfSFPTxFail> (failing ok) Possible values: - failing : expansion shelf host downlink SFP tx failure - ok : expansion shelf downlink SFP tx ok	status expansion shelf downlink SFP tx failure <i>This element is only shown in detail mode.</i>
exp-sfp-pres	Parameter type: <Alarm::expansionShelfSFPMissing> (not-present present) Possible values: - not-present : expansion shelf downlink SFP not present - present : expansion shelf downlink SFP present	current status expansion shelf downlink SFP not present <i>This element is only shown in detail mode.</i>
exp-sfp-id	Parameter type: <Alarm::expShelfSFPInvalidNokiaID> (invalid valid) Possible values: - invalid : expansion shelf downlink SFP does not have valid Nokia ID	status expansion shelf downlink SFP does not have valid Nokia ID <i>This element is only shown in detail mode.</i>

name	Type	Description
	- valid : expansion shelf downlink SFP has valid Nokia ID	
exp-sfp-ctrl	Parameter type: <Alarm::expansionShelfSFPControlFail> (failing ok) Possible values: - failing : expansion shelf downlink SFP control failure - ok : expansion shelf downlink SFP control ok	status expansion shelf downlink SFP control failure <i>This element is only shown in detail mode.</i>
exp-sfp-1-los	Parameter type: <Alarm::expansionShelfSFP1Los> (failing ok) Possible values: - failing : expansion shelf downlink SFP1 loss of signal - ok : expansion shelf downlink SFP1 signal ok	current status expansion side downlink SFP1 loss of signal <i>This element is only shown in detail mode.</i>
exp-sfp-2-los	Parameter type: <Alarm::expansionShelfSFP2Los> (failing ok) Possible values: - failing : expansion shelf downlink SFP2 loss of signal - ok : expansion shelf downlink SFP2 signal ok	current status expansion side downlink SFP2 loss of signal <i>This element is only shown in detail mode.</i>

102.25 Custom External Alarm Log Status Command

Command Description

This command displays the customizable external alarm log status.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

> show alarm log custom-ext-alarm [(index)]

Command Parameters

Table 102.25-1 "Custom External Alarm Log Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm log table index

Command Output

Table 102.25-2 "Custom External Alarm Log Status Command" Display parameters

Specific Information		
name	Type	Description
board-position	Parameter type: <Equipm::SlotIndex> (lt : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> nt-a nt-b nt acu : <Eqpt::RackId> / <Eqpt::ShelfId> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::EqSlotId> ext-a : <Eqpt::RackId> / <Eqpt::ShelfId> ext-b : <Eqpt::RackId> / <Eqpt::ShelfId> ctrl : <Eqpt::RackId> / <Eqpt::ShelfId> vlt : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::VirtualSlotId>) Possible values: - lt : lt-slot - vlt : virtual LT slot (VVPS board can only be planned at NANT-E / FANT-F)	identify where the alarm has occurred. <i>This element is always shown.</i>

name	Type	Description
	- nt-a : nt-a slot - nt-b : nt-b slot - nt : nt slot - ext-a : nt-a slot in an extension shelf - ext-b : nt-b slot in an extension shelf - acu : acu slot - ctrl : ctrl-slot Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::VirtualSlotId> - the virtual LT slot number Field type <Eqpt::EqSlotId> - the equipment slot number	
last-updated-on	Parameter type: <Sys::timeInSecs> - the time (yyyy-mm-dd:hour:minutes:secs) - unit: UTC	network time in seconds when the alarm was logged. <i>This element is always shown.</i>
ext-alarm1	Parameter type: <Alarm::custExtAlarm1> (yes no) Possible values: - yes : customizable external alarm 1 - no : no customizable external alarm 1	current status specifying external alarm 1 is present or not <i>This element is always shown.</i>
ext-alarm2	Parameter type: <Alarm::custExtAlarm2> (yes no) Possible values: - yes : customizable external alarm 2 - no : no customizable external alarm 2	current status specifying external alarm 2 is present or not <i>This element is always shown.</i>
ext-alarm3	Parameter type: <Alarm::custExtAlarm3> (yes no) Possible values: - yes : customizable external alarm 3 - no : no customizable external alarm 3	current status specifying external alarm 3 is present or not <i>This element is always shown.</i>
ext-alarm4	Parameter type: <Alarm::custExtAlarm4> (yes no) Possible values: - yes : customizable external alarm 4 - no : no customizable external alarm 4	current status specifying external alarm 4 is present or not <i>This element is always shown.</i>
ext-alarm5	Parameter type: <Alarm::custExtAlarm5> (yes no) Possible values: - yes : customizable external alarm 5 - no : no customizable external alarm 5	current status specifying external alarm 5 is present or not <i>This element is always shown.</i>

102.26 SFP RSSI for NT Alarm Log Status

Command

Command Description

This command displays the SFP RSSI alarm log status.

For NT card SFP alarms, the remote LT slot-identifier that corresponds to the SFP is displayed in the output

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm log sfrssi [ (index) ]
```

Command Parameters

Table 102.26-1 "SFP RSSI for NT Alarm Log Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm log table index

Command Output

Table 102.26-2 "SFP RSSI for NT Alarm Log Status Command" Display parameters

Specific Information		
name	Type	Description
last-updated-on	Parameter type: <Sys::timeInSecs> - the time (yyyy-mm-dd:hour:minutes:secs) - unit: UTC	network time in seconds when the alarm was logged. <i>This element is only shown in detail mode.</i>
alarm index 1	Parameter type: <Alarm::SlotIndex> (lt : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> nt-a nt-b nt acu : <Eqpt::RackId> / <Eqpt::ShelfId> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::EqSlotId> ext-a : <Eqpt::RackId> / <Eqpt::ShelfId> ext-b : <Eqpt::RackId> / <Eqpt::ShelfId> ctrl : <Eqpt::RackId> / <Eqpt::ShelfId> iont : <Eqpt::RackId> / <Eqpt::ShelfId>	this is the nt/ntio slot id for host alarms. <i>This element is only shown in detail mode.</i>

name	Type	Description
	lp : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::LtAppliqueSlotId> ntio-1 ntio-2 vlt : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::VirtualSlotId>) Possible values: - lt : lt-slot - vlt : virtual LT slot (VVPS board can only be planned at NANT-E/FANT-F) - nt-a : nt-a slot - nt-b : nt-b slot - nt : nt slot - ext-a : nt-a slot in an extension shelf - ext-b : nt-b slot in an extension shelf - acu : acu slot - ctrl : ctrl-slot - iont : an nt applique slot - lp : an lt applique slot - ntio-1 : an nt applique slot in a single or multiple-ntio-shelf - ntio-2 : an nt applique slot in a multiple-ntio-shelf Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::LtAppliqueSlotId> - the LT Applique slot number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::VirtualSlotId> - the virtual LT slot number Field type <Eqpt::EqSlotId> - the equipment slot number	
alarm index 2	Parameter type: <Alarm::RssiPort> (sfp : <Alarm::RssiPort> xfp : <Alarm::RssiPort> cfp : <Alarm::RssiPort> qsfp : <Alarm::RssiPort> sfp1 : <Alarm::RssiPort> sfp2 : <Alarm::RssiPort> xfp1 : <Alarm::RssiPort> xfp2 : <Alarm::RssiPort>) Possible values: - sfp : rssi sfp port - xfp : rssi xfp port - cfp : rssi cfp port - qsfp : rssi qsfp port - sfp1 : rssi sfp port 1 - sfp2 : rssi sfp port 2 - xfp1 : rssi xfp port 1 - xfp2 : rssi xfp port 2 Field type <Alarm::RssiPort> - value - range: [0...36]	this is the nt/ntio sfp faceplate number <i>This element is only shown in detail mode.</i>

Only Show Details: sfp rssi diagnostic threshold control alarms

name	Type	Description
tx-power-high-alarm	Parameter type: <Alarm::NTNTIOTXPWHI>	current status optical power is too

102 Alarm Log Status Commands

name	Type	Description
	(yes no) Possible values: - yes : TX optical power is too high than configured alarm high threshold - no : The TX optical power is ok	high than the configured alarm high threshold <i>This element is only shown in detail mode.</i>
tx-power-low-alarm	Parameter type: <Alarm::NTNTIOTXPWLO> (yes no) Possible values: - yes : TX optical power is too low than the configured alarm low threshold - no : TX optical power is ok	current status Tx optical power is too low than the configured alarm low threshold <i>This element is only shown in detail mode.</i>
rx-power-high-alarm	Parameter type: <Alarm::NTNTIORXPWHI> (yes no) Possible values: - yes : RX optical power is too high than the configured alarm high threshold - no : RX optical power is ok	current status Rx optical power is too high than the configured alarm high threshold <i>This element is only shown in detail mode.</i>
rx-power-low-alarm	Parameter type: <Alarm::NTNTIORXPWLO> (yes no) Possible values: - yes : RX optical power is too low than the configured alarm low threshold - no : RX optical power is ok	current status Rx optical power is too low than the configured alarm low threshold <i>This element is only shown in detail mode.</i>
tx-biascur-high-alarm	Parameter type: <Alarm::NTNTIOTXBIASHI> (yes no) Possible values: - yes : TX bias is too high than the configured alarm low threshold - no : TX bias current is ok	current status Tx bias is too high than the configured alarm low threshold <i>This element is only shown in detail mode.</i>
tx-biascur-low-alarm	Parameter type: <Alarm::NTNTIOTXBIASLO> (yes no) Possible values: - yes : TX bias is too low than the configured alarm low threshold - no : TX bias current is ok	current status Tx bias is too low than the configured alarm low threshold <i>This element is only shown in detail mode.</i>
volt-high-alarm	Parameter type: <Alarm::NTNTIOVOLHI> (yes no) Possible values: - yes : voltage is too high than the configured alarm high threshold - no : voltage is ok	current status voltage is too high than the configured alarm high threshold <i>This element is only shown in detail mode.</i>
volt-low-alarm	Parameter type: <Alarm::NTNTIOVOLLO> (yes no) Possible values: - yes : voltage is too low than the configured alarm low threshold - no : voltage is ok	current status voltage is too low than the configured alarm low threshold <i>This element is only shown in detail mode.</i>
temp-high-alarm	Parameter type: <Alarm::NTNTIOTEMPHI> (yes	current status temperature is too high than the configured alarm

name	Type	Description
	no) Possible values: - yes : temperature is too high than the configured alarm high threshold - no : temperature is ok	high threshold <i>This element is only shown in detail mode.</i>
temp-low-alarm	Parameter type: <Alarm::NTNTIOTEMPLO> (yes no) Possible values: - yes : temperature is too low than the configured alarm low threshold - no : temperature is ok	current status temperature is too low than the configured alarm low threshold <i>This element is only shown in detail mode.</i>
tx-power-high-warn	Parameter type: <Alarm::NTNTIOTXPWHIWARN> (yes no) Possible values: - yes : TX optical power is too high than the configured warning high threshold - no : TX optical power is ok	current status Tx optical power is too high than the configured warning high threshold <i>This element is only shown in detail mode.</i>
tx-power-low-warn	Parameter type: <Alarm::NTNTIOTXPWLOWARN> (yes no) Possible values: - yes : TX optical power is too low than the configured warning low threshold - no : TX optical power is ok	current status Tx optical power is too low than the configured warning low threshold <i>This element is only shown in detail mode.</i>
rx-power-high-warn	Parameter type: <Alarm::NTNTIORXPWHIWARN> (yes no) Possible values: - yes : RX optical power is too low than the configured warning high threshold - no : RX optical power is ok	current status Rx optical power is too low than the configured warning high threshold <i>This element is only shown in detail mode.</i>
rx-power-low-warn	Parameter type: <Alarm::NTNTIORXPWLOWARN> (yes no) Possible values: - yes : RX optical power is too low than the configured warning low threshold - no : RX optical power is ok	current status Rx optical power is too low than the configured warning low threshold <i>This element is only shown in detail mode.</i>
tx-biascur-high-warn	Parameter type: <Alarm::NTNTIOTXBIASHIWARN> (yes no) Possible values: - yes : TX bias is too high than the configured warning high threshold - no : TX bias current is ok	current status Tx bias is too high than the configured warning high threshold <i>This element is only shown in detail mode.</i>
tx-biascur-low-warn	Parameter type: <Alarm::NTNTIOTXBIASLOWARN> (yes no) Possible values: - yes : TX bias is too low than the configured warning low threshold - no : TX bias current is ok	current status Tx bias is too low than the configured warning low threshold <i>This element is only shown in detail mode.</i>
volt-high-warn	Parameter type: <Alarm::NTNTIOVOLHIWARN> (yes no)	current status voltage is too high than the configured warning high threshold

102 Alarm Log Status Commands

name	Type	Description
	Possible values: - yes : voltage is too high than the configured warning high threshold - no : no Miscellaneous environment alarm	<i>This element is only shown in detail mode.</i>
volt-low-warn	Parameter type: <Alarm::NTNTIOVOLLOWARN> (yes no) Possible values: - yes : voltage is too low than the configured warning low threshold - no : voltage is ok	current status voltage is too low than the configured warning low threshold <i>This element is only shown in detail mode.</i>
temp-high-warn	Parameter type: <Alarm::NTNTIOTEMPEHIWARN> (yes no) Possible values: - yes : temperature is too high than the configured warning high threshold - no : temperature is ok	current status temperature is too high than the configured warning high threshold <i>This element is only shown in detail mode.</i>
temp-low-warn	Parameter type: <Alarm::NTNTIOTEMPELOWARN> (yes no) Possible values: - yes : temperature is too high than the configured warning low threshold - no : temperature is ok	current status temperature is too low than the configured warning low threshold <i>This element is only shown in detail mode.</i>

102.27 PPP Cross-Connect Engine TCA Alarm Log Status Command

Command Description

This command displays the PPP cross-connect engine TCA alarm log status.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm log pppcc-engine-tca [ (index) ]
```

Command Parameters

Table 102.27-1 "PPP Cross-Connect Engine TCA Alarm Log Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm log table index

Command Output

Table 102.27-2 "PPP Cross-Connect Engine TCA Alarm Log Status Command" Display parameters

Specific Information		
name	Type	Description
last-updated-on	Parameter type: <Sys::timeInSecs> - the time (yyyy-mm-dd:hour:minutes:secs) - unit: UTC	network time in seconds when the alarm was logged. <i>This element is only shown in detail mode.</i>
engine	Parameter type: <Vlan::StackedVlanSigned> (<Vlan::UVlanIndex> stacked : <Vlan::SVlanIndex> : <Vlan::CVlanIndex>) Possible values: - stacked : stacked vlan identity Field type <Vlan::UVlanIndex> - unstacked vlan identity - range: [1...4093,4096] Field type <Vlan::SVlanIndex> - service vlan identity	this is the ppp-cc engine number <i>This element is only shown in detail mode.</i>

102 Alarm Log Status Commands

name	Type	Description
	- range: [2...4093,4094] - Field type <Vlan::CVlanIndex> - customer vlan identity - range: [0...4093,4094,4095,4096]	

Only Show Details: pppoe cross-connect engine tca alarms		
name	Type	Description
pppcce-trans-15min-tca	Parameter type: <Alarm::PPPCCETRANS15MIN> (yes no) Possible values: - yes : 15 minutes transaction timeout count exceeds configured TCA - no : 15 minutes transaction timeout count is OK	current 15 minutes transaction timeout count exceeds configured tca <i>This element is only shown in detail mode.</i>
pppcce-sess-15min-tca	Parameter type: <Alarm::PPPCCESESS15MIN> (yes no) Possible values: - yes : 15 minutes session timeout count exceeds configured TCA - no : 15 minutes session timeout count is OK	15 minutes session timeout count exceeds configured TCA <i>This element is only shown in detail mode.</i>
pppcce-trans-1day-tca	Parameter type: <Alarm::PPPCCETRANS1DAY> (yes no) Possible values: - yes : 1day transaction timeout count exceeds configured TCA - no : 1day transaction timeout count is OK	1day transaction timeout count exceeds configured TCA <i>This element is only shown in detail mode.</i>
pppcce-sess-1day-tca	Parameter type: <Alarm::PPPCCESESS1DAY> (yes no) Possible values: - yes : 1day session timeout count exceeds configured TCA - no : 1day session timeout count is OK	1day session timeout count exceeds configured TCA <i>This element is only shown in detail mode.</i>

102.28 Epon Olt Sfp RSSI Log Alarm Status Command

Command Description

This command displays the Epon Olt Sfp RSSI Log alarm.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm log eoltrssi [ (index) ]
```

Command Parameters

Table 102.28-1 "Epon Olt Sfp RSSI Log Alarm Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm log table index

Command Output

Table 102.28-2 "Epon Olt Sfp RSSI Log Alarm Status Command" Display parameters

Specific Information		
name	Type	Description
last-updated-on	Parameter type: <Sys::timeInSecs> - the time (yyyy-mm-dd:hour:minutes:secs) - unit: UTC	network time in seconds when the alarm was logged. <i>This element is only shown in detail mode.</i>
epon id	Parameter type: <Epon::PonId> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier	this is the epon id for Log alarms. <i>This element is only shown in detail mode.</i>

Only Show Details: epon olt sfp rssi diagnostic threshold control alarms

102 Alarm Log Status Commands

name	Type	Description
eolt-tpwr-hi-alm	Parameter type: <Alarm::OLTTPWHI> (yes no) Possible values: - yes : Olt sfp Tx power is higher than the configured alarm high threshold - no : Olt sfp Tx power current is ok	Log status Tx optical power is too high than the configured alarm high threshold <i>This element is only shown in detail mode.</i>
eolt-tpwr-lw-alm	Parameter type: <Alarm::OLTTPWLO> (yes no) Possible values: - yes : Olt sfp Tx power is lower than the configured alarm low threshold - no : Olt sfp Tx power current is ok	Log status Tx optical power is too low than the configured alarm low threshold <i>This element is only shown in detail mode.</i>
eolt-txbias-hi-alm	Parameter type: <Alarm::OLTTXBIASHI> (yes no) Possible values: - yes : Olt sfp Bias is higher than the configured alarm high threshold - no : Olt sfp Bias current is ok	Log status Bias is too high than the configured alarm high threshold <i>This element is only shown in detail mode.</i>
eolt-txbias-lw-alm	Parameter type: <Alarm::OLTTXBIASLO> (yes no) Possible values: - yes : Olt sfp Bias is lower than the configured alarm low threshold - no : Olt sfp Bias current is ok	Log status Bias is too low than the configured alarm low threshold <i>This element is only shown in detail mode.</i>
eolt-volt-hi-alm	Parameter type: <Alarm::OLTVOLHI> (yes no) Possible values: - yes : Olt sfp voltage is higher than the configured alarm high threshold - no : Olt sfp voltage current is ok	Log status voltage is too high than the configured alarm high threshold <i>This element is only shown in detail mode.</i>
eolt-volt-lw-alm	Parameter type: <Alarm::OLTVOLLO> (yes no) Possible values: - yes : Olt sfp voltage is lower than the configured alarm low threshold - no : Olt sfp voltage current is ok	Log status voltage is too low than the configured alarm low threshold <i>This element is only shown in detail mode.</i>
eolt-temp-hi-alm	Parameter type: <Alarm::OLTTEMPEHI> (yes no) Possible values: - yes : Olt sfp temperature is higher than the configured alarm high threshold - no : Olt sfp temperature current is ok	Log status temperature is too high than the configured alarm high threshold <i>This element is only shown in detail mode.</i>
eolt-temp-lw-alm	Parameter type: <Alarm::OLTTEMPELO> (yes no) Possible values: - yes : Olt sfp temperature is lower than the configured alarm low threshold - no : Olt sfp temperature current is ok	Log status temperature is too low than the configured alarm low threshold <i>This element is only shown in detail mode.</i>
eolt-tpwr-hi-warn	Parameter type: <Alarm::OLTTPWHIWARN>	Log status Tx optical power is

name	Type	Description
	(yes no) Possible values: - yes : Olt sfp Tx power is higher than the configured warning high threshold - no : Olt sfp Tx power current is ok	too high than the configured warning high threshold <i>This element is only shown in detail mode.</i>
eolt-txpwr-lw-warn	Parameter type: <Alarm::OLTTPWLOWARN> (yes no) Possible values: - yes : Olt sfp Tx power is lower than the configured warning low threshold - no : Olt sfp Tx power current is ok	Log status Tx optical power is too low than the configured warning low threshold <i>This element is only shown in detail mode.</i>
eolt-txbias-hi-warn	Parameter type: <Alarm::OLTTXBIASHIWARN> (yes no) Possible values: - yes : Olt sfp Bias is higher than the configured warning high threshold - no : Olt sfp Bias current is ok	Log status bias is too high than the configured warning high threshold <i>This element is only shown in detail mode.</i>
eolt-txbias-lw-warn	Parameter type: <Alarm::OLTTXBIASLOWARN> (yes no) Possible values: - yes : Olt sfp Bias is lower than the configured warning low threshold - no : Olt sfp Bias current is ok	Log status bias is too low than the configured warning low threshold <i>This element is only shown in detail mode.</i>
eolt-volt-hi-warn	Parameter type: <Alarm::OLTVOLHIWARN> (yes no) Possible values: - yes : Olt sfp voltage is higher than the configured warning high threshold - no : Olt sfp voltage current is ok	Log status voltage is too low than the configured warning high threshold <i>This element is only shown in detail mode.</i>
eolt-volt-lw-warn	Parameter type: <Alarm::OLTVOLLOWARN> (yes no) Possible values: - yes : Olt sfp voltage is lower than the configured warning low threshold - no : Olt sfp voltage current is ok	Log status voltage is too low than the configured warning low threshold <i>This element is only shown in detail mode.</i>
eolt-temp-hi-warn	Parameter type: <Alarm::OLTTEMPEHIWARN> (yes no) Possible values: - yes : Olt sfp temperature is higher than the configured warning high threshold - no : Olt sfp temperature current is ok	Log status temperature is too high than the configured warning high threshold <i>This element is only shown in detail mode.</i>
eolt-temp-lw-warn	Parameter type: <Alarm::OLTTEMPELOWARN> (yes no) Possible values: - yes : Olt sfp temperature is lower than the configured warning low threshold - no : Olt sfp temperature current is ok	Log status temperature is too low than the configured warning low threshold <i>This element is only shown in detail mode.</i>
eolt-xfp-txpwr-hi-alm	Parameter type: <Alarm::OLTEXTTPWHI> (yes	Log status Xfp Tx optical power is too high than the configured

102 Alarm Log Status Commands

name	Type	Description
	no) Possible values: - yes : Olt xfp Tx power is higher than the configured alarm high threshold - no : Olt xfp Tx power current is ok	alarm high threshold <i>This element is only shown in detail mode.</i>
eolt-xfp-txpwr-lw-alm	Parameter type: <Alarm::OLTEXTTXPWLO> (yes no) Possible values: - yes : Olt xfp Tx power is lower than the configured alarm low threshold - no : Olt xfp Tx power current is ok	Log status Xfp Tx optical power is too low than the configured alarm low threshold <i>This element is only shown in detail mode.</i>
eolt-xfp-bias-hi-alm	Parameter type: <Alarm::OLTEXTTXBIASHI> (yes no) Possible values: - yes : Olt xfp Bias is higher than the configured alarm high threshold - no : Olt xfp Bias current is ok	Log status Xfp bias is too high than the configured alarm high threshold <i>This element is only shown in detail mode.</i>
eolt-xfp-bias-lw-alm	Parameter type: <Alarm::OLTEXTTXBIASLO> (yes no) Possible values: - yes : Olt xfp Bias is lower than the configured alarm low threshold - no : Olt xfp Bias current is ok	Log status Xfp bias is too low than the configured alarm low threshold <i>This element is only shown in detail mode.</i>
eolt-xfp-txpwr-hi-warn	Parameter type: <Alarm::OLTEXTTXPWHIWARN> (yes no) Possible values: - yes : Olt xfp Tx power is higher than the configured warning high threshold - no : Olt xfp Tx power current is ok	Log status Xfp Tx optical power is too high than the configured warning high threshold <i>This element is only shown in detail mode.</i>
eolt-xfp-txpwr-lw-warn	Parameter type: <Alarm::OLTEXTTXPWLOWARN> (yes no) Possible values: - yes : Olt xfp Tx power is lower than the configured warning low threshold - no : Olt xfp Tx power current is ok	Log status Xfp Tx optical power is too low than the configured warning low threshold <i>This element is only shown in detail mode.</i>
eolt-xfp-bias-hi-warn	Parameter type: <Alarm::OLTEXTTXBIASHIWARN> (yes no) Possible values: - yes : Olt xfp Bias is higher than the configured warning high threshold - no : Olt xfp Bias current is ok	Log status Xfp bias is too high than the configured warning high threshold <i>This element is only shown in detail mode.</i>
eolt-xfp-bias-lw-warn	Parameter type: <Alarm::OLTEXTTXBIASLOWARN> (yes no) Possible values: - yes : Olt xfp Bias is lower than the configured warning low threshold - no : Olt xfp Bias current is ok	Log status Xfp bias is too low than the configured warning low threshold <i>This element is only shown in detail mode.</i>

102.29 2xE1/DS1 SFP Clock Alarm Log Status Command

Command Description

This command displays the 2xE1/DS1 SFP Clock Alarm log status.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm log sfpe1t1-clock [ (index) ]
```

Command Parameters

Table 102.29-1 "2xE1/DS1 SFP Clock Alarm Log Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm type

Command Output

Table 102.29-2 "2xE1/DS1 SFP Clock Alarm Log Status Command" Display parameters

Specific Information		
name	Type	Description
alarm index 1	Parameter type: <Alarm::SlotIndex> (lt : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> nt-a nt-b nt acu : <Eqpt::RackId> / <Eqpt::ShelfId> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::EqSlotId> ext-a : <Eqpt::RackId> / <Eqpt::ShelfId> ext-b : <Eqpt::RackId> / <Eqpt::ShelfId> ctrl : <Eqpt::RackId> / <Eqpt::ShelfId> iont : <Eqpt::RackId> / <Eqpt::ShelfId> lp : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::LtAppliqueSlotId> ntio-1 ntio-2 vlt : <Eqpt::RackId> / <Eqpt::ShelfId> /	this is the nt/ntio slot id for host alarms. <i>This element is only shown in detail mode.</i>

102 Alarm Log Status Commands

name	Type	Description
	<Eqpt::VirtualSlotId>) Possible values: - lt : lt-slot - vlt : virtual LT slot (VVPS board can only be planned at NANT-E/FANT-F) - nt-a : nt-a slot - nt-b : nt-b slot - nt : nt slot - ext-a : nt-a slot in an extension shelf - ext-b : nt-b slot in an extension shelf - acu : acu slot - ctrl : ctrl-slot - iont : an nt applique slot - lp : an lt applique slot - ntio-1 : an nt applique slot in a single or multiple-ntio-shelf - ntio-2 : an nt applique slot in a multiple-ntio-shelf Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::LtAppliqueSlotId> - the LT Applique slot number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::VirtualSlotId> - the virtual LT slot number Field type <Eqpt::EqSlotId> - the equipment slot number	
alarm index 2	Parameter type: <Alarm::e1t1Port> (sfp : <Alarm::E1t1FramerPort> xfp : <Alarm::E1t1FramerPort>) Possible values: - sfp : e1t1 sfp port - xfp : e1t1 xfp port Field type <Alarm::E1t1FramerPort> - value - range: [0...35]	this is the host sfp faceplate number <i>This element is only shown in detail mode.</i>

Only Show Details: e1t1 sfp clock alarms		
name	Type	Description
dsx1-serdes-fail	Parameter type: <Alarm::DSX1SERDESFAIL> (yes no) Possible values: - yes : SERDES clock failure alarm - no : SERDES Clock no failure	SERDES clock failure alarm <i>This element is only shown in detail mode.</i>
dsx1-tributary1-fail	Parameter type: <Alarm::DSX1TRIB1FAIL> (yes no) Possible values: - yes : Tributary 1 clock failure alarm - no : Tributary 1 clock no failure	tributary 1 clock failure alarm <i>This element is only shown in detail mode.</i>
dsx1-tributary2-fail	Parameter type: <Alarm::DSX1TRIB2FAIL> (yes no) Possible values: - yes : Tributary 2 clock failure alarm - no : Tributary 2 clock no failure	tributary 2 clock failure alarm <i>This element is only shown in detail mode.</i>

name	Type	Description
dsx1-los-fail	Parameter type: <Alarm::DSX1LOSFAIL> (yes no) Possible values: - yes : All selected tributaries in Loss Of Signal - no : No All selected tributaries in Loss Of Signal	all selected tributaries in loss of signal <i>This element is only shown in detail mode.</i>
dsx1-ais-sync	Parameter type: <Alarm::DSX1AISFAIL> (yes no) Possible values: - yes : Alarm Indication Signal on the tributary selected sync source - no : No Alarm Indication Signal on the tributary selected sync source	alarm indication signal on the tributary selected as sync source <i>This element is only shown in detail mode.</i>
dsx1-lof-sync	Parameter type: <Alarm::DSX1LOFSYNCFAIL> (yes no) Possible values: - yes : Loss of Frame on the tributary selected sync source - no : No Loss of Frame on the tributary selected sync source	loss of frame on the tributary selected as sync source <i>This element is only shown in detail mode.</i>
dsx1-los-sync	Parameter type: <Alarm::DSX1LOSSYNCFAIL> (yes no) Possible values: - yes : Loss of Signal on the tributary selected sync source - no : No Loss of Signal on the tributary selected sync source	loss of signal on the tributary selected as sync source <i>This element is only shown in detail mode.</i>
dsx1-deg-fail	Parameter type: <Alarm::DSX1DEGFAIL> (yes no) Possible values: - yes : Signal degrade alarm - no : Signal degrade alarm	signal degrade alarm <i>This element is only shown in detail mode.</i>

102.30 2xE1/DS1 SFP Framer Alarm Log Status Command

Command Description

This command displays the 2xE1/DS1 SFP Framer alarm log status.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm log sfpe1t1-framer [ (index) ]
```

Command Parameters

Table 102.30-1 "2xE1/DS1 SFP Framer Alarm Log Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm type

Command Output

Table 102.30-2 "2xE1/DS1 SFP Framer Alarm Log Status Command" Display parameters

Specific Information		
name	Type	Description
alarm index 1	Parameter type: <Alarm::SlotIndex> (lt : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> nt-a nt-b nt acu : <Eqpt::RackId> / <Eqpt::ShelfId> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::EqSlotId> ext-a : <Eqpt::RackId> / <Eqpt::ShelfId> ext-b : <Eqpt::RackId> / <Eqpt::ShelfId> ctrl : <Eqpt::RackId> / <Eqpt::ShelfId> iont : <Eqpt::RackId> / <Eqpt::ShelfId> lp : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::LtAppliqueSlotId> ntio-1 ntio-2 vlt : <Eqpt::RackId> / <Eqpt::ShelfId> /	this is the nt/ntio slot id for host alarms. <i>This element is only shown in detail mode.</i>

name	Type	Description
	<Eqpt::VirtualSlotId>) Possible values: - lt : lt-slot - vlt : virtual LT slot (VVPS board can only be planned at NANT-E/FANT-F) - nt-a : nt-a slot - nt-b : nt-b slot - nt : nt slot - ext-a : nt-a slot in an extension shelf - ext-b : nt-b slot in an extension shelf - acu : acu slot - ctrl : ctrl-slot - iont : an nt applique slot - lp : an lt applique slot - ntio-1 : an nt applique slot in a single or multiple-ntio-shelf - ntio-2 : an nt applique slot in a multiple-ntio-shelf Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::LtAppliqueSlotId> - the LT Applique slot number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::VirtualSlotId> - the virtual LT slot number Field type <Eqpt::EqSlotId> - the equipment slot number	
alarm index 2	Parameter type: <Alarm::e1t1framerPort> (sfp : <Alarm::E1t1FramerPort> : <Alarm::tributary> xfp : <Alarm::E1t1FramerPort> : <Alarm::tributary>) Possible values: - sfp : e1t1 sfp port - xfp : e1t1 xfp port Field type <Alarm::E1t1FramerPort> - value - range: [0...35] Field type <Alarm::tributary> - value - range: [1...2]	this is the host sfp faceplate number <i>This element is only shown in detail mode.</i>

Only Show Details: e1t1 framer alarms		
name	Type	Description
rei-from-liu	Parameter type: <Alarm::DSX1REILIU> (yes no) Possible values: - yes : e1t1 sfp Remote Error Indication Alarm from LIU - no : No e1t1 sfp Remote Error Indication Alarm from LIU	remote error indication alarm from LIU <i>This element is only shown in detail mode.</i>
rdi-from-liu	Parameter type: <Alarm::DSX1RDILIU> (yes no) Possible values: - yes : e1t1 sfp Remote Defect Alarmn from LIU - no : No e1t1 sfp Remote Defect Alarmn from LIU	remote defect indication alarm from LIU <i>This element is only shown in detail mode.</i>
crc6-from-liu	Parameter type: <Alarm::DSX1CRC6LIU> (yes no)	cyclic redundancy check 6 from LIU <i>This element is only shown in</i>

102 Alarm Log Status Commands

name	Type	Description
	Possible values: - yes : e1t1 sfp Cyclic Redundancy Check 6 from LIU - no : No e1t1 sfp Cyclic Redundancy Check 6 from LIU	<i>detail mode.</i>
crc4-from-liu	Parameter type: <Alarm::DSX1CRC4LIU> (yes no) Possible values: - yes : e1t1 sfp Cyclic Redundancy Check 4 from LIU - no : No e1t1 sfp Cyclic Redundancy Check 4 from LIU	cyclic redundancy check 4 from LIU <i>This element is only shown in detail mode.</i>
crc4-threshold-from-liu	Parameter type: <Alarm::DSX1CRC4THLIU> (yes no) Possible values: - yes : e1t1 sfp Cyclic Redundancy Check 4 threshold alarm from LIU - no : No e1t1 sfp Cyclic Redundancy Check 4 threshold alarm from LIU	cyclic redundancy check 4 threshold alarm from LIU <i>This element is only shown in detail mode.</i>
ais-from-liu	Parameter type: <Alarm::DSX1AISLIU> (yes no) Possible values: - yes : e1t1 sfp Alarm Indication Signal alarm from LIU - no : No e1t1 sfp Alarm Indication Signal alarm from LIU	alarm indication signal alarm from LIU <i>This element is only shown in detail mode.</i>
los-from-liu	Parameter type: <Alarm::DSX1LOSLIU> (yes no) Possible values: - yes : e1t1 sfp Loss of signal alarm from LIU - no : No e1t1 sfp Loss of signal alarm from LIU	loss of signal alarm from LIU <i>This element is only shown in detail mode.</i>
lof-from-liu	Parameter type: <Alarm::DSX1LOFLIU> (yes no) Possible values: - yes : e1t1 sfp Loss of frame alarm from LIU - no : No e1t1 sfp Loss of frame alarm from LIU	loss of frame alarm from LIU <i>This element is only shown in detail mode.</i>
lomf-from-liu	Parameter type: <Alarm::DSX1LOMFLIU> (yes no) Possible values: - yes : e1t1 sfp Loss of multi frame alarm from LIU - no : No e1t1 sfp Loss of multi frame alarm from LIU	loss of multi frame alarm from LIU <i>This element is only shown in detail mode.</i>
rei-from-iwf	Parameter type: <Alarm::DSX1REIIWF> (yes no) Possible values: - yes : e1t1 sfp Remote Error Indication Alarm from IWF - no : No e1t1 sfp Remote Error Indication Alarm from IWF	remote error indication alarm from IWF <i>This element is only shown in detail mode.</i>
rdi-from-iwf	Parameter type: <Alarm::DSX1RDIIWF> (yes no) Possible values: - yes : e1t1 sfp Remote Defect Alarm from IWF - no : No e1t1 sfp Remote Defect Alarm from IWF	remote defect indication alarm from IWF <i>This element is only shown in detail mode.</i>
crc6-from-iwf	Parameter type: <Alarm::DSX1CRC6IWF> (yes no) Possible values:	cyclic redundancy check 6 from IWF <i>This element is only shown in detail mode.</i>

name	Type	Description
	- yes : e1t1 sfp Cyclic Redundancy Check 6 from IWF - no : No e1t1 sfp Cyclic Redundancy Check 6 from IWF	
crc4-from-iwf	Parameter type: <Alarm::DSX1CRC4IWF> (yes no) Possible values: - yes : e1t1 sfp Cyclic Redundancy Check 4 from IWF - no : No e1t1 sfp Cyclic Redundancy Check 4 from IWF	cyclic redundancy check 4 from IWF <i>This element is only shown in detail mode.</i>
crc4-threshold-from-iwf	Parameter type: <Alarm::DSX1CRC4THIWF> (yes no) Possible values: - yes : e1t1 sfp Cyclic Redundancy Check 4 threshold alarm from IWF - no : No e1t1 sfp Cyclic Redundancy Check 4 threshold alarm from IWF	cyclic redundancy check 4 threshold alarm from IWF <i>This element is only shown in detail mode.</i>
ais-from-iwf	Parameter type: <Alarm::DSX1AISIWF> (yes no) Possible values: - yes : e1t1 sfp Alarm Indication Signal alarm from IWF - no : No e1t1 sfp Alarm Indication Signal alarm from IWF	alarm indication signal alarm from IWF <i>This element is only shown in detail mode.</i>
los-from-iwf	Parameter type: <Alarm::DSX1LOSIWF> (yes no) Possible values: - yes : e1t1 sfp Loss of signal alarm from IWF - no : No e1t1 sfp Loss of signal alarm from IWF	loss of signal alarm from IWF <i>This element is only shown in detail mode.</i>
lof-from-iwf	Parameter type: <Alarm::DSX1LOFIWF> (yes no) Possible values: - yes : e1t1 sfp Loss of frame alarm from IWF - no : No e1t1 sfp Loss of frame alarm from IWF	loss of frame alarm from IWF <i>This element is only shown in detail mode.</i>
lomf-from-iwf	Parameter type: <Alarm::DSX1LOMFIWF> (yes no) Possible values: - yes : e1t1 sfp Loss of multi frame alarm from IWF - no : No e1t1 sfp Loss of multi frame alarm from IWF	loss of multi frame alarm from LIU <i>This element is only shown in detail mode.</i>

102.31 Plug In Unit Extended Alarm Log Status Command

Command Description

This command displays the plug-in unit extended alarm log status.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

> show alarm log plug-in-unit-ext [(index)]

Command Parameters

Table 102.31-1 "Plug In Unit Extended Alarm Log Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm log table index

Command Output

Table 102.31-2 "Plug In Unit Extended Alarm Log Status Command" Display parameters

Specific Information		
name	Type	Description
last-updated-on	Parameter type: <Sys::timeInSecs> - the time (yyyy-mm-dd:hour:minutes:secs) - unit: UTC	network time in seconds when the alarm was logged. <i>This element is only shown in detail mode.</i>
board-position	Parameter type: <Equipm::SlotIndex> (lt : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> nt-a nt-b nt acu : <Eqpt::RackId> / <Eqpt::ShelfId> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::EqSlotId> ext-a : <Eqpt::RackId> / <Eqpt::ShelfId> ext-b : <Eqpt::RackId> / <Eqpt::ShelfId> ctrl : <Eqpt::RackId> / <Eqpt::ShelfId> vlt : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::VirtualSlotId>)	identify where the alarm has occurred. <i>This element is only shown in detail mode.</i>

name	Type	Description
	Possible values: - lt : lt-slot - vlt : virtual LT slot (VVPS board can only be planned at NANT-E / FANT-F) - nt-a : nt-a slot - nt-b : nt-b slot - nt : nt slot - ext-a : nt-a slot in an extension shelf - ext-b : nt-b slot in an extension shelf - acu : acu slot - ctrl : ctrl-slot Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::VirtualSlotId> - the virtual LT slot number Field type <Eqpt::EqSlotId> - the equipment slot number	
fan-alarm	Parameter type: <Alarm::pluginFan> (yes no) Possible values: - yes : fan alarm - no : no fan alarm	current status specifying fan alarm is present or not <i>This element is only shown in detail mode.</i>
dc-a-alarm	Parameter type: <Alarm::plugin-dc-a> (yes no) Possible values: - yes : dc a failure alarm - no : no dc a failure alarm	current status specifying dc-a failure alarm is present or not <i>This element is only shown in detail mode.</i>
dc-b-alarm	Parameter type: <Alarm::plugin-dc-b> (yes no) Possible values: - yes : dc b failure alarm - no : no dc b failure alarm	current status specifying dc-b failure alarm is present or not <i>This element is only shown in detail mode.</i>
dg-alarm	Parameter type: <Alarm::plugin-dg> (yes no) Possible values: - yes : dying gasp alarm - no : no dying gasp alarm	current status specifying dying gasp alarm is present or not <i>This element is only shown in detail mode.</i>
apsf-alarm	Parameter type: <Alarm::pluginApsf> (yes no) Possible values: - yes : apsf failure alarm - no : no apsf failure alarm	applique power supply failure yes or no <i>This element is only shown in detail mode.</i>
ntr-a-loss	Parameter type: <Alarm::NTRALoss> (yes no) Possible values: - yes : ntr-a signal unavailable - no : ntr-a signal available	log status specifying NTR-A loss alarm is present or not <i>This element is only shown in detail mode.</i>

102 Alarm Log Status Commands

name	Type	Description
ntr-b-loss	Parameter type: <Alarm::NTRBLoss> (yes no) Possible values: - yes : ntr-b signal unavailable - no : ntr-b signal available	log status specifying NTR-B loss alarm is present or not <i>This element is only shown in detail mode.</i>
xvps-conf-loss	Parameter type: <Alarm::XvpsConfLoss> (yes no) Possible values: - yes : implicit xvps configuration loss. - no : no implicit xvps configuration loss.	implicit xvps configuration loss or not. <i>This element is only shown in detail mode.</i>
mac-entry-nofree	Parameter type: <Alarm::MacNofree> (nofree free) Possible values: - nofree : no free mac entry in the mac table on the lt board. - free : file transfer server available.	current status specifying no free mac entry in the mac table on the lt board. <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::MacNofree> (nofree free) Possible values: - nofree : no free mac entry in the mac table on the lt board. - free : file transfer server available.	current status specifying no free mac entry in the mac table on the lt board. <i>This element is only shown in detail mode.</i>
fibre-conn-mismatch	Parameter type: <Alarm::FibreConnMismatch> (yes no) Possible values: - yes : REM fibre connection mismatch alarm - no : no REM fibre connection mismatch alarm	current status specifying fibre connection mismatch on detected control card. <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::FibreConnMismatch> (yes no) Possible values: - yes : REM fibre connection mismatch alarm - no : no REM fibre connection mismatch alarm	status of fibre connection mismatch alarm with its previous logged value. <i>This element is only shown in detail mode.</i>
link-cap-mismatch	Parameter type: <Alarm::LinkCapMismatch> (yes no) Possible values: - yes : actual link speed is not inline with the end-to-end link capability between NT and LT - no : actual link speed is inline with the end-to-end link capability between NT and LT	log-status specifies that the actual link speed is not in line with the end-to-end link capability between NT and LT. <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::LinkCapMismatch> (yes no) Possible values: - yes : actual link speed is not inline with the end-to-end link capability between NT and LT - no : actual link speed is inline with the end-to-end link capability between NT and LT	status of link-cap-mismatch with its previous logged value. <i>This element is only shown in detail mode.</i>
eqpt-cap-mismatch	Parameter type: <Alarm::EqptCapMismatch> (yes no) Possible values: - yes : not all equipment between NT and LT can support the	log-status specifies that not all equipment between NT and LT can support the speed that NT and LT can support within the configured MaxLinkSpeed.

name	Type	Description
	speed that NT and LT can support within the configured MaxLinkSpeed. - no : all equipment between NT and LT can support the speed that NT and LT can support within the configured MaxLinkSpeed.	<i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::EqptCapMismatch> (yes no) Possible values: - yes : not all equipment between NT and LT can support the speed that NT and LT can support within the configured MaxLinkSpeed. - no : all equipment between NT and LT can support the speed that NT and LT can support within the configured MaxLinkSpeed.	status of eqpt-cap-mismatch with its previous logged value. <i>This element is only shown in detail mode.</i>
ctrl-dnld-failure	Parameter type: <Alarm::CtrlDownloadFailure> (yes no) Possible values: - yes : The downloading of the Software image to the controller card failed.. - no : The downloading of the Software image to the controller card passed.	log-status specifies that the downloading of the Software image to the controller card failed. <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::CtrlDownloadFailure> (yes no) Possible values: - yes : The downloading of the Software image to the controller card failed.. - no : The downloading of the Software image to the controller card passed.	status of ctrl-dnld-failure with its previous logged value. <i>This element is only shown in detail mode.</i>
melt-hw-issue	Parameter type: <Alarm::BoardHWIssue> (yes no) Possible values: - yes : Board hardware issue - no : No Board hardware issue.	log-status specifies that MELT hardware issue. <i>This element is only shown in detail mode.</i>
melt-board-reset	Parameter type: <Alarm::BoardHWIssue> (yes no) Possible values: - yes : Board hardware issue - no : No Board hardware issue.	log-status specifies that MELT board got reset. <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::BoardHWIssue> (yes no) Possible values: - yes : Board hardware issue - no : No Board hardware issue.	status of board hardware issue with its previous logged value. <i>This element is only shown in detail mode.</i>
board-shelf-mismatch	Parameter type: <Alarm::boardShelfMismatch> (yes no) Possible values: - yes : plugged-in board and shelf type are mismatch - no : plugged-in board and shelf type are match	alarm specifying the shelf type and plugged-in board types are mismatch. <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::boardShelfMismatch> (yes	status of shelf-board-mismatch with its previous logged value.

102 Alarm Log Status Commands

name	Type	Description
	no) Possible values: - yes : plugged-in board and shelf type are mismatch - no : plugged-in board and shelf type are match	<i>This element is only shown in detail mode.</i>
single-fan-fail	Parameter type: <Alarm::SINGLEFANFAILURE> (yes no) Possible values: - yes : single fan failure` - no : no single fan failure	log-status of single fan failure, indicating single fan failed. <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::SINGLEFANFAILURE> (yes no) Possible values: - yes : single fan failure` - no : no single fan failure	status of FAN failure with its previous logged value. <i>This element is only shown in detail mode.</i>
multi-fan-fail	Parameter type: <Alarm::MULTIFANFAILURE> (yes no) Possible values: - yes : more than one fan failed - no : NO MULTIPLE fans are failed	log-status of multi fan failure, indicating multiple fan failed. <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::MULTIFANFAILURE> (yes no) Possible values: - yes : more than one fan failed - no : NO MULTIPLE fans are failed	status of FAN failure with its previous logged value. <i>This element is only shown in detail mode.</i>
fan-tray-missing	Parameter type: <Alarm::FANTRAYMISSING> (yes no) Possible values: - yes : fan tray missing - no : fans tray is present	log-status of fan-tray-missing, indicating fan tray is missing. <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::FANTRAYMISSING> (yes no) Possible values: - yes : fan tray missing - no : fans tray is present	status of FAN failure with its previous logged value. <i>This element is only shown in detail mode.</i>

102.32 SIP Server Alarm Log Status Commands

Command Description

This command displays the SIP server alarm log status.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

> show alarm log sip-server [(index)]

Command Parameters

Table 102.32-1 "SIP Server Alarm Log Status Commands" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm log table index

Command Output

Table 102.32-2 "SIP Server Alarm Log Status Commands" Display parameters

Only Show Details: current and previous alarm log status		
name	Type	Description
transport-mismatch	Parameter type: <Alarm::transportMismatch> (yes no) Possible values: - yes : mismatch - no : not mismatch	specifies isamv and server transport mismatch or not. <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::transportMismatch> (yes no) Possible values: - yes : mismatch - no : not mismatch	status of specifies transport mismatch with its previous logged value <i>This element is only shown in detail mode.</i>
dns-lookup-failure	Parameter type: <Alarm::dnsLookUpFailure> (yes no) Possible values: - yes : fail - no : not fail	specifies dns look up fail or not. <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::dnsLookUpFailure>	status of specifies dns look up fail

102 Alarm Log Status Commands

name	Type	Description
	(yes no) Possible values: - yes : fail - no : not fail	with its previous logged value <i>This element is only shown in detail mode.</i>

102.33 SIP VSP Alarm Log Status Commands

Command Description

This command displays the SIP vsp alarm log status.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm log sip-vsp [ (index) ]
```

Command Parameters

Table 102.33-1 "SIP VSP Alarm Log Status Commands" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm log table index

Command Output

Table 102.33-2 "SIP VSP Alarm Log Status Commands" Display parameters

Only Show Details: current and previous alarm log status		
name	Type	Description
none-dns-srv	Parameter type: <Alarm::noneDNSSRV> (yes no) Possible values: - yes : none of dns server give reply to to DNS look up - no : dns server give reply to to DNS look up	specifies none of dns server give reply to to DNS look up or not. <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::noneDNSSRV> (yes no) Possible values: - yes : none of dns server give reply to to DNS look up - no : dns server give reply to to DNS look up	status of specifies none of dns server give reply to DNS look up with its previous logged value <i>This element is only shown in detail mode.</i>
no-dns-srv	Parameter type: <Alarm::noDNSSRV> (yes no) Possible values: - yes : no dns server configured when sip request - no : dns server configured when sip request	specifies no dns server configured when sip request or not. <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::noDNSSRV>	status of specifies no dns server

102 Alarm Log Status Commands

name	Type	Description
	(yes no) Possible values: - yes : no dns server configured when sip request - no : dns server configured when sip request	configured when sip request with its previous logged value <i>This element is only shown in detail mode.</i>
none-srv	Parameter type: <Alarm::noneSRV> (yes no) Possible values: - yes : none sip server give reply when send sip request - no : sip server give reply when send sip request	specifies none sip server give reply when send sip request or not. <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::noneSRV> (yes no) Possible values: - yes : none sip server give reply when send sip request - no : sip server give reply when send sip request	status of specifies none sip server give reply when send sip request with its previous logged value <i>This element is only shown in detail mode.</i>
no-srv	Parameter type: <Alarm::noSRV> (yes no) Possible values: - yes : no sip proxy server configured when send sip request - no : sip proxy server configured when send sip request	specifies no sip proxy server configured when send sip request or not. <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::noSRV> (yes no) Possible values: - yes : no sip proxy server configured when send sip request - no : sip proxy server configured when send sip request	status of specifies no sip proxy server configured when send sip request with its previous logged value <i>This element is only shown in detail mode.</i>
reg-srv-unreach	Parameter type: <Alarm::noRegSRV> (yes no) Possible values: - yes : no sip register server give reply when send sip register - no : sip register server give reply when send sip register	specifies no sip register servers give reply when send sip register or not. <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::noRegSRV> (yes no) Possible values: - yes : no sip register server give reply when send sip register - no : sip register server give reply when send sip register	status of specifies no sip register servers give reply when send sip register with its previous logged value <i>This element is only shown in detail mode.</i>
prxy-srv-unreach	Parameter type: <Alarm::noPrxySRV> (yes no) Possible values: - yes : no sip proxy server give reply when send sip request - no : sip proxy server give reply when send sip request	specifies no sip proxy servers give reply when send sip request or not. <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::noPrxySRV> (yes no) Possible values: - yes : no sip proxy server give reply when send sip request - no : sip proxy server give reply when send sip request	status of specifies no sip proxy servers give reply when send sip request with its previous logged value <i>This element is only shown in detail mode.</i>
fo-trigger	Parameter type: <Alarm::foTrigger> (yes	specifies fail-over is triggered or not.

name	Type	Description
	no) Possible values: - yes : fail over triggered - no : fail over is not triggered	<i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::foTrigger> (yes no) Possible values: - yes : fail over triggered - no : fail over is not triggered	status of specifies fail-over is triggered with its previous logged value <i>This element is only shown in detail mode.</i>
fb-trigger	Parameter type: <Alarm::fbTrigger> (yes no) Possible values: - yes : fail back triggered - no : fail back is not triggered	specifies fail-back is triggered or not. <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::fbTrigger> (yes no) Possible values: - yes : fail back triggered - no : fail back is not triggered	status of specifies fail-back is triggered with its previous logged value <i>This element is only shown in detail mode.</i>
du-trigger	Parameter type: <Alarm::duTrigger> (yes no) Possible values: - yes : deliberate update triggered - no : deliberate update is not triggered	specifies deliberate-update is triggered or not. <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::duTrigger> (yes no) Possible values: - yes : deliberate update triggered - no : deliberate update is not triggered	status of specifies deliberate-update is triggered with its previous logged value <i>This element is only shown in detail mode.</i>
ssp-missing	Parameter type: <Alarm::sspMissing> (yes no) Possible values: - yes : SSP missing in CDE - no : SSP exist in CDE	specifies ssp missing in cde or not. <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::sspMissing> (yes no) Possible values: - yes : SSP missing in CDE - no : SSP exist in CDE	status of specifies ssp missing in cde with its previous logged value <i>This element is only shown in detail mode.</i>
dns-pool-exceed	Parameter type: <Alarm::dnsPoolExceed> (yes no) Possible values: - yes : Number of different SG associated DNS pools exceed - no : Number of different SG associated DNS pools exceed	specifies Number of different SG associated DNS pools exceed or not. <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::dnsPoolExceed> (yes no) Possible values: - yes : Number of different SG associated DNS pools exceed	status of specifies Number of different SG associated DNS pools exceed with its previous logged value <i>This element is only shown in</i>

102 Alarm Log Status Commands

name	Type	Description
	- no : Number of different SG associated DNS pools exceed	<i>detail mode.</i>
lsa-fo-trigger	Parameter type: <Alarm::lsaFoTrigger> (yes no) Possible values: - yes : SIP voice service degraded - fail-over to LSA server - no : fail-over to LSA server is not triggered	specifies lsa-fail-over is triggered or not. <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::lsaFoTrigger> (yes no) Possible values: - yes : SIP voice service degraded - fail-over to LSA server - no : fail-over to LSA server is not triggered	status of specifies lsa-fail-over is triggered with its previous logged value <i>This element is only shown in detail mode.</i>

102.34 SIP Dial Plan Alarm Log Status Commands

Command Description

This command displays the SIP dial plan alarm log status.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

> show alarm log sip-dial-plan [(index)]

Command Parameters

Table 102.34-1 "SIP Dial Plan Alarm Log Status Commands" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm log table index

Command Output

Table 102.34-2 "SIP Dial Plan Alarm Log Status Commands" Display parameters

Only Show Details: current and previous alarm log status		
name	Type	Description
bad-digitmap	Parameter type: <Alarm::badDigitMap> (yes no) Possible values: - yes : digit map unusable - no : digit map usable	specifies sip digitmap usable or not. <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::badDigitMap> (yes no) Possible values: - yes : digit map unusable - no : digit map usable	status of specifies sip digitmap with its previous logged value <i>This element is only shown in detail mode.</i>

102.35 SIP User Agent Alarm Log Status Commands

Command Description

This command displays the SIP user agent alarm log status.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

> show alarm log sip-user-agent [(index)]

Command Parameters

Table 102.35-1 "SIP User Agent Alarm Log Status Commands" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm log table index

Command Output

Table 102.35-2 "SIP User Agent Alarm Log Status Commands" Display parameters

Only Show Details: current and previous alarm log status		
name	Type	Description
bad-digitmap	Parameter type: <Alarm::badDigitMap> (yes no) Possible values: - yes : digit map unusable - no : digit map usable	specifies sip digitmap usable or not. <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::badDigitMap> (yes no) Possible values: - yes : digit map unusable - no : digit map usable	status of specifies sip digitmap with its previous logged value <i>This element is only shown in detail mode.</i>
dhcp-unreach	Parameter type: <Alarm::dhcpUnreach> (yes no) Possible values:	specifies the DHCP server is unreachable or not <i>This element is only shown in detail mode.</i>

name	Type	Description
	- yes : The DHCP server is unreachable - no : The DHCP server is reachable	
prev-status	Parameter type: <Alarm::dhcpUnreach> (yes no) Possible values: - yes : The DHCP server is unreachable - no : The DHCP server is reachable	status of specifies the DHCP server is unreachable with its previous logged value <i>This element is only shown in detail mode.</i>
dhcp-no-srv	Parameter type: <Alarm::dhcpNoSrv> (yes no) Possible values: - yes : The address in DHCP reply is NULL - no : The address in DHCP reply is not NULL	specifies the address in DHCP reply is NULL or not <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::dhcpNoSrv> (yes no) Possible values: - yes : The address in DHCP reply is NULL - no : The address in DHCP reply is not NULL	status of specifies the address in DHCP reply is NULL with its previous logged value <i>This element is only shown in detail mode.</i>
dhcp-inv-srv	Parameter type: <Alarm::dhcpInvSrv> (yes no) Possible values: - yes : The address in DHCP reply is invalid - no : The address in DHCP reply is OK	specifies the address in DHCP reply is invalid or not <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::dhcpInvSrv> (yes no) Possible values: - yes : The address in DHCP reply is invalid - no : The address in DHCP reply is OK	status of specifies the address in DHCP reply is invalid with its previous logged value <i>This element is only shown in detail mode.</i>

102.36 SIP Slot Alarm Log Status Commands

Command Description

This command displays the SIP slot alarm log status.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm log sip-plugin-unit [ (index) ]
```

Command Parameters

Table 102.36-1 "SIP Slot Alarm Log Status Commands" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm log table index

Command Output

Table 102.36-2 "SIP Slot Alarm Log Status Commands" Display parameters

Only Show Details: current and previous alarm log status		
name	Type	Description
short-res	Parameter type: <Alarm::shortResource> (yes no) Possible values: - yes : short call resource - no : have call resource	sepcifies the call resource short or not. <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::shortResource> (yes no) Possible values: - yes : short call resource - no : have call resource	status of specifies call resources with its previous logged value <i>This element is only shown in detail mode.</i>
norpniewwithsoftdsp	Parameter type: <Alarm::noRpniEWithSoftDsp> (yes no) Possible values: - yes : plan / plug-in RPNI-E board with SoftDsp SW image - no : no plan / plug-in RPNI-E board with SoftDsp SW image	sepcifies if plan / plug-in RPNI-E board with SoftDsp SW image or not. <i>This element is only shown in detail mode.</i>

name	Type	Description
prev-status	Parameter type: <Alarm::noRpniEWithSoftDsp> (yes no) Possible values: - yes : plan / plug-in RPNI-E board with SoftDsp SW image - no : no plan / plug-in RPNI-E board with SoftDsp SW image	status of specifies plan / plug-in RPNI-E board with SoftDsp SW image with its previous logged value <i>This element is only shown in detail mode.</i>

102.37 SIP Termination Alarm Log Status Commands

Command Description

This command displays the SIP termination alarm log status.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

> show alarm log sip-termination [(index)]

Command Parameters

Table 102.37-1 "SIP Termination Alarm Log Status Commands" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm log table index

Command Output

Table 102.37-2 "SIP Termination Alarm Log Status Commands" Display parameters

Only Show Details: current and previous alarm log status		
name	Type	Description
unknown-sub	Parameter type: <Alarm::unknownSubscriber> (yes no) Possible values: - yes : wrong subscriber - no : right subscriber	specifies the sip subscriber unknow or not. <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::unknownSubscriber> (yes no) Possible values: - yes : wrong subscriber - no : right subscriber	status of specifies subscribers with its previous logged value <i>This element is only shown in detail mode.</i>
ground-key	Parameter type: <Alarm::groundKey> (yes no) Possible values:	status of the ground key. <i>This element is only shown in detail mode.</i>

name	Type	Description
	- yes : current to ground - no : current not to ground	
prev-status	Parameter type: <Alarm::groundKey> (yes no) Possible values: - yes : current to ground - no : current not to ground	status of specifies ground key with its previous logged value <i>This element is only shown in detail mode.</i>
port-hightemp	Parameter type: <Alarm::highTemperature> (yes no) Possible values: - yes : high temperature - no : not high temperature	status of the port temperature. <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::highTemperature> (yes no) Possible values: - yes : high temperature - no : not high temperature	status of specifies temperature with its previous logged value <i>This element is only shown in detail mode.</i>
l1-act-failure	Parameter type: <Alarm::l1ActFailure> (yes no) Possible values: - yes : high temperature - no : not high temperature	status of the layer 1 activation. <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::l1ActFailure> (yes no) Possible values: - yes : high temperature - no : not high temperature	status of specifies layer 1 activation with its previous logged value <i>This element is only shown in detail mode.</i>
port-overcurrent	Parameter type: <Alarm::overCurrent> (yes no) Possible values: - yes : over current - no : not over current	status of the port current <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::overCurrent> (yes no) Possible values: - yes : over current - no : not over current	status of specifies current with its previous logged value <i>This element is only shown in detail mode.</i>
port-jbfltca	Parameter type: <Alarm::jbflTca> (yes no) Possible values: - yes : high jb fill level - no : not high jb fill level	status of the port jitter buffer fill level tca. <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::jbflTca> (yes no) Possible values: - yes : high jb fill level - no : not high jb fill level	status of specifies jbfl tca with its previous logged value <i>This element is only shown in detail mode.</i>
reg-domainname	Parameter type: <Alarm::regdomainname>	status of resolving domain name

102 Alarm Log Status Commands

name	Type	Description
	(yes no) Possible values: - yes : register - resolving domain name failed - no : register - resolving domain name successful	(register). <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::regdomainname> (yes no) Possible values: - yes : register - resolving domain name failed - no : register - resolving domain name successful	status of resolving domain name (register) with its previous logged value <i>This element is only shown in detail mode.</i>
reg-auth	Parameter type: <Alarm::regauth> (yes no) Possible values: - yes : register - authentication failed - no : register - authentication successful	status of authentication (register). <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::regauth> (yes no) Possible values: - yes : register - authentication failed - no : register - authentication successful	status of authentication (register) with its previous logged value <i>This element is only shown in detail mode.</i>
reg-timeout	Parameter type: <Alarm::regtimeout> (yes no) Possible values: - yes : register - message timeout - no : register - message not timeout	status of message timeout (register). <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::regtimeout> (yes no) Possible values: - yes : register - message timeout - no : register - message not timeout	status of message timeout (register) with its previous logged value <i>This element is only shown in detail mode.</i>
reg-srvfailresp	Parameter type: <Alarm::regsrvfailresp> (yes no) Possible values: - yes : register - failure response from server - no : register - successful response from server	status of failure response from server (register). <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::regsrvfailresp> (yes no) Possible values: - yes : register - failure response from server - no : register - successful response from server	status of failure response from server (register) with its previous logged value <i>This element is only shown in detail mode.</i>
inv-domainname	Parameter type: <Alarm::invdomainname> (yes no) Possible values: - yes : invite - resolving domain name failed - no : invite - resolving domain name successful	status of resolving domain name (invite). <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::invdomainname> (yes no) Possible values:	status of resolving domain name (invite) with its previous logged value <i>This element is only shown in</i>

name	Type	Description
	- yes : invite - resolving domain name failed - no : invite - resolving domain name successful	<i>detail mode.</i>
inv-auth	Parameter type: <Alarm::invauth> (yes no) Possible values: - yes : invite - authentication failed - no : invite - authentication successful	status of authentication (invite). <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::invauth> (yes no) Possible values: - yes : invite - authentication failed - no : invite - authentication successful	status of authentication (invite) with its previous logged value <i>This element is only shown in detail mode.</i>
inv-timeout	Parameter type: <Alarm::invtimeout> (yes no) Possible values: - yes : invite - message timeout - no : invite - message not timeout	status of message timeout (invite). <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::invtimeout> (yes no) Possible values: - yes : invite - message timeout - no : invite - message not timeout	status of message timeout (invite) with its previous logged value <i>This element is only shown in detail mode.</i>
inv-srvfailresp	Parameter type: <Alarm::invsrvfailresp> (yes no) Possible values: - yes : invite - failure response from server - no : invite - successful response from server	status of failure response from server (invite). <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::invsrvfailresp> (yes no) Possible values: - yes : invite - failure response from server - no : invite - successful response from server	status of failure response from server (invite) with its previous logged value <i>This element is only shown in detail mode.</i>
subs-srvfailresp	Parameter type: <Alarm::subssrvfailresp> (yes no) Possible values: - yes : subscribe - failure response from server - no : subscribe - successful response from server	status of failure response from server (subscribe). <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::subssrvfailresp> (yes no) Possible values: - yes : subscribe - failure response from server - no : subscribe - successful response from server	status of failure response from server (subscribe) with its previous logged value <i>This element is only shown in detail mode.</i>
subs-domainname	Parameter type: <Alarm::subsdomainname> (yes no) Possible values: - yes : Subscribe - resolving domain name failed - no : Subscribe - resolving domain name successful	status of resolving domain name (subscribe). <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::subsdomainname>	status of resolving domain name

102 Alarm Log Status Commands

name	Type	Description
	(yes no) Possible values: - yes : Subscribe - resolving domain name failed - no : Subscribe - resolving domain name successful	(subscribe) with its previous logged value <i>This element is only shown in detail mode.</i>
subs-auth	Parameter type: <Alarm::subsauth> (yes no) Possible values: - yes : Subscribe - authentication failed - no : Subscribe - authentication successful	status of authentication (subscribe). <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::subsauth> (yes no) Possible values: - yes : Subscribe - authentication failed - no : Subscribe - authentication successful	status of authentication (subscribe) with its previous logged value <i>This element is only shown in detail mode.</i>
subs-refreshfail	Parameter type: <Alarm::subsrefreshfail> (yes no) Possible values: - yes : Subscribe - refresh failure - no : Subscribe - refresh failure	status of message timeout or 481 received (refresher subscribe). <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::subsrefreshfail> (yes no) Possible values: - yes : Subscribe - refresh failure - no : Subscribe - refresh failure	status of message timeout or 481 received (refresher subscribe) with its previous logged value <i>This element is only shown in detail mode.</i>
subs-inittimeout	Parameter type: <Alarm::subsintimeout> (yes no) Possible values: - yes : Subscribe - initial REQ timeout - no : Subscribe - initial REQ timeout	status of message timeout (initial subscribe). <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::subsintimeout> (yes no) Possible values: - yes : Subscribe - initial REQ timeout - no : Subscribe - initial REQ timeout	status of message timeout (initial subscribe) with its previous logged value <i>This element is only shown in detail mode.</i>
emergency-call	Parameter type: <Alarm::emergencycall> (yes no) Possible values: - yes : emergency call is ongoing - no : emergency call is not ongoing	status of emergency call. <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::emergencycall> (yes no) Possible values: - yes : emergency call is ongoing - no : emergency call is not ongoing	status of emergency call with its previous logged value <i>This element is only shown in detail mode.</i>

102.38 Secondary SIP Termination Alarm Log Status Command

Command Description

This command displays the secondary SIP termination alarm log status.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

> show alarm log secondary-sip-term [(index)]

Command Parameters

Table 102.38-1 "Secondary SIP Termination Alarm Log Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm log table index

Command Output

Table 102.38-2 "Secondary SIP Termination Alarm Log Status Command" Display parameters

Only Show Details: current and previous alarm log status		
name	Type	Description
reg-domainname-sec	Parameter type: <Alarm::regdomainname> (yes no) Possible values: - yes : register - resolving domain name failed - no : register - resolving domain name successful	status of resolving domain name (register). <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::regdomainname> (yes no) Possible values: - yes : register - resolving domain name failed - no : register - resolving domain name successful	status of resolving domain name (register) with its previous logged value <i>This element is only shown in detail mode.</i>
reg-auth-sec	Parameter type: <Alarm::regauth> (yes no) Possible values:	status of authentication (register). <i>This element is only shown in detail mode.</i>

102 Alarm Log Status Commands

name	Type	Description
	- yes : register - authentication failed - no : register - authentication successful	
prev-status	Parameter type: <Alarm::regauth> (yes no) Possible values: - yes : register - authentication failed - no : register - authentication successful	status of authentication (register) with its previous logged value <i>This element is only shown in detail mode.</i>
reg-timeout-sec	Parameter type: <Alarm::regtimeout> (yes no) Possible values: - yes : register - message timeout - no : register - message not timeout	status of message timeout (register). <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::regtimeout> (yes no) Possible values: - yes : register - message timeout - no : register - message not timeout	status of message timeout (register) with its previous logged value <i>This element is only shown in detail mode.</i>
reg-srvfailresp-sec	Parameter type: <Alarm::regsrvfailresp> (yes no) Possible values: - yes : register - failure response from server - no : register - successful response from server	status of failure response from server (register). <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::regsrvfailresp> (yes no) Possible values: - yes : register - failure response from server - no : register - successful response from server	status of failure response from server (register) with its previous logged value <i>This element is only shown in detail mode.</i>
inv-domainname-sec	Parameter type: <Alarm::invdomainname> (yes no) Possible values: - yes : invite - resolving domain name failed - no : invite - resolving domain name successful	status of resolving domain name (invite). <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::invdomainname> (yes no) Possible values: - yes : invite - resolving domain name failed - no : invite - resolving domain name successful	status of resolving domain name (invite) with its previous logged value <i>This element is only shown in detail mode.</i>
inv-auth-sec	Parameter type: <Alarm::invauth> (yes no) Possible values: - yes : invite - authentication failed - no : invite - authentication successful	status of authentication (invite). <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::invauth> (yes no) Possible values: - yes : invite - authentication failed - no : invite - authentication successful	status of authentication (invite) with its previous logged value <i>This element is only shown in detail mode.</i>
inv-timeout-sec	Parameter type: <Alarm::invtimeout>	status of message timeout

name	Type	Description
	(yes no) Possible values: - yes : invite - message timeout - no : invite - message not timeout	(invite). <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::invtimeout> (yes no) Possible values: - yes : invite - message timeout - no : invite - message not timeout	status of message timeout (invite) with its previous logged value <i>This element is only shown in detail mode.</i>
inv-srvfailresp-sec	Parameter type: <Alarm::invsrvfailresp> (yes no) Possible values: - yes : invite - failure response from server - no : invite - successful response from server	status of failure response from server (invite). <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::invsrvfailresp> (yes no) Possible values: - yes : invite - failure response from server - no : invite - successful response from server	status of failure response from server (invite) with its previous logged value <i>This element is only shown in detail mode.</i>
subs-srvfailresp-sec	Parameter type: <Alarm::subsrvfailresp> (yes no) Possible values: - yes : subscribe - failure response from server - no : subscribe - successful response from server	status of failure response from server (subscribe). <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::subsrvfailresp> (yes no) Possible values: - yes : subscribe - failure response from server - no : subscribe - successful response from server	status of failure response from server (subscribe) with its previous logged value <i>This element is only shown in detail mode.</i>
subs-domainname-sec	Parameter type: <Alarm::subdomainname> (yes no) Possible values: - yes : Subscribe - resolving domain name failed - no : Subscribe - resolving domain name successful	status of resolving domain name (subscribe). <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::subdomainname> (yes no) Possible values: - yes : Subscribe - resolving domain name failed - no : Subscribe - resolving domain name successful	status of resolving domain name (subscribe) with its previous logged value <i>This element is only shown in detail mode.</i>
subs-auth-sec	Parameter type: <Alarm::subsauth> (yes no) Possible values: - yes : Subscribe - authentication failed - no : Subscribe - authentication successful	status of authentication (subscribe). <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::subsauth> (yes no) Possible values:	status of authentication (subscribe) with its previous logged value <i>This element is only shown in detail mode.</i>

102 Alarm Log Status Commands

name	Type	Description
	- yes : Subscribe - authentication failed - no : Subscribe - authentication successful	<i>detail mode.</i>
subs-refreshfail-sec	Parameter type: <Alarm::subsrefreshfail> (yes no) Possible values: - yes : Subscribe - refresh failure - no : Subscribe - refresh failure	status of message timeout or 481 received (refresher subscribe). <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::subsrefreshfail> (yes no) Possible values: - yes : Subscribe - refresh failure - no : Subscribe - refresh failure	status of message timeout or 481 received (refresher subscribe) with its previous logged value <i>This element is only shown in detail mode.</i>
subs-inittimeout-sec	Parameter type: <Alarm::subsinittimeout> (yes no) Possible values: - yes : Subscribe - initial REQ timeout - no : Subscribe - initial REQ timeout	status of message timeout (initial subscribe). <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::subsinittimeout> (yes no) Possible values: - yes : Subscribe - initial REQ timeout - no : Subscribe - initial REQ timeout	status of message timeout (initial subscribe) with its previous logged value <i>This element is only shown in detail mode.</i>
emergency-call-sec	Parameter type: <Alarm::emergencycall> (yes no) Possible values: - yes : emergency call is ongoing - no : emergency call is not ongoing	status of emergency call. <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::emergencycall> (yes no) Possible values: - yes : emergency call is ongoing - no : emergency call is not ongoing	status of emergency call with its previous logged value <i>This element is only shown in detail mode.</i>

102.39 SIP Termination Alarm Log Status Commands

Command Description

This command displays the SIP termination alarm log status.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

> show alarm log e1-sip-termination [(index)]

Command Parameters

Table 102.39-1 "SIP Termination Alarm Log Status Commands" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm log table index

Command Output

Table 102.39-2 "SIP Termination Alarm Log Status Commands" Display parameters

Only Show Details: current and previous alarm log status		
name	Type	Description
reg-domainname	Parameter type: <Alarm::isdnregdomainname> (yes no) Possible values: - yes : register - resolving domain name failed - no : register - resolving domain name successful	status of resolving domain name (register). <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::isdnregdomainname> (yes no) Possible values: - yes : register - resolving domain name failed - no : register - resolving domain name successful	status of resolving domain name (register) with its previous logged value <i>This element is only shown in detail mode.</i>
reg-auth	Parameter type: <Alarm::isdnregauth> (yes no) Possible values:	status of authentication (register). <i>This element is only shown in detail mode.</i>

102 Alarm Log Status Commands

name	Type	Description
	- yes : register - authentication failed - no : register - authentication successful	
prev-status	Parameter type: <Alarm::isdnregauth> (yes no) Possible values: - yes : register - authentication failed - no : register - authentication successful	status of authentication (register) with its previous logged value <i>This element is only shown in detail mode.</i>
reg-timeout	Parameter type: <Alarm::isdnregtimeout> (yes no) Possible values: - yes : register - message timeout - no : register - message not timeout	status of message timeout (register). <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::isdnregtimeout> (yes no) Possible values: - yes : register - message timeout - no : register - message not timeout	status of message timeout (register) with its previous logged value <i>This element is only shown in detail mode.</i>
reg-srvfailresp	Parameter type: <Alarm::isdnregsrvfailresp> (yes no) Possible values: - yes : register - failure response from server - no : register - successful response from server	status of failure response from server (register). <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::isdnregsrvfailresp> (yes no) Possible values: - yes : register - failure response from server - no : register - successful response from server	status of failure response from server (register) with its previous logged value <i>This element is only shown in detail mode.</i>
inv-domainname	Parameter type: <Alarm::isdninvdomainname> (yes no) Possible values: - yes : invite - resolving domain name failed - no : invite - resolving domain name successful	status of resolving domain name (invite). <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::isdninvdomainname> (yes no) Possible values: - yes : invite - resolving domain name failed - no : invite - resolving domain name successful	status of resolving domain name (invite) with its previous logged value <i>This element is only shown in detail mode.</i>
inv-auth	Parameter type: <Alarm::isdninvauth> (yes no) Possible values: - yes : invite - authentication failed - no : invite - authentication successful	status of authentication (invite). <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::isdninvauth> (yes no) Possible values: - yes : invite - authentication failed - no : invite - authentication successful	status of authentication (invite) with its previous logged value <i>This element is only shown in detail mode.</i>
inv-timeout	Parameter type: <Alarm::isdninvtimeout>	status of message timeout

name	Type	Description
	(yes no) Possible values: - yes : invite - message timeout - no : invite - message not timeout	(invite). <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::isdninvttimeout> (yes no) Possible values: - yes : invite - message timeout - no : invite - message not timeout	status of message timeout (invite) with its previous logged value <i>This element is only shown in detail mode.</i>
inv-srvfailresp	Parameter type: <Alarm::isdninvsrvfailresp> (yes no) Possible values: - yes : invite - failure response from server - no : invite - successful response from server	status of failure response from server (invite). <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::isdninvsrvfailresp> (yes no) Possible values: - yes : invite - failure response from server - no : invite - successful response from server	status of failure response from server (invite) with its previous logged value <i>This element is only shown in detail mode.</i>
emergency-call	Parameter type: <Alarm::isdnemercencycall> (yes no) Possible values: - yes : emergency call is ongoing - no : emergency call is not ongoing	status of emergency call. <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::isdnemercencycall> (yes no) Possible values: - yes : emergency call is ongoing - no : emergency call is not ongoing	status of emergency call with its previous logged value <i>This element is only shown in detail mode.</i>
ais-signal	Parameter type: <Alarm::isdnaissignal> (yes no) Possible values: - yes : Alarm Indication Signal detected at E1 interface - no : no Alarm Indication Signal detected at E1 interface	status of Alarm Indication Signal. <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::isdnaissignal> (yes no) Possible values: - yes : Alarm Indication Signal detected at E1 interface - no : no Alarm Indication Signal detected at E1 interface	status of Alarm Indication Signal with its previous logged value <i>This element is only shown in detail mode.</i>
los-signal	Parameter type: <Alarm::isdnlossignal> (yes no) Possible values: - yes : Loss Of Signal detected at E1 interface - no : no Loss Of Signal detected at E1 interface	status of Loss Of Signal Alarm. <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::isdnlossignal> (yes no) Possible values:	status of Loss Of Signal Alarm with its previous logged value <i>This element is only shown in detail mode.</i>

102 Alarm Log Status Commands

name	Type	Description
	- yes : Loss Of Signal detected at E1 interface - no : no Loss Of Signal detected at E1 interface	
rai-signal	Parameter type: <Alarm::isdnraisignal> (yes no) Possible values: - yes : Remote Alarm Indication detected at E1 interface - no : no Remote Alarm Indication detected at E1 interface	status of Remote Alarm Indication. <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::isdnraisignal> (yes no) Possible values: - yes : Remote Alarm Indication detected at E1 interface - no : no Remote Alarm Indication detected at E1 interface	status of Remote Alarm Indication with its previous logged value <i>This element is only shown in detail mode.</i>
e1sip-misconfig-mgc10	Parameter type: <Alarm::sipmiscfgmgc10> (yes no) Possible values: - yes : Configuration not conform with the core network entity - no : no Configuration not conform with the core network entity	status of config error when connect to mgc10. <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::sipmiscfgmgc10> (yes no) Possible values: - yes : Configuration not conform with the core network entity - no : no Configuration not conform with the core network entity	status of config error when connect to mgc10 with its previous logged value <i>This element is only shown in detail mode.</i>
e1sip-nsmprf-missed	Parameter type: <Alarm::sipnsmprofmis> (yes no) Possible values: - yes : The SIP termination requires a NSM profile - no : no The SIP termination requires a NSM profile	status of requires a NSM profile. <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::sipnsmprofmis> (yes no) Possible values: - yes : The SIP termination requires a NSM profile - no : no The SIP termination requires a NSM profile	status of requires a NSM profile with its previous logged value <i>This element is only shown in detail mode.</i>

102.40 E1/T1 Interface Alarm Log Status Commands

Command Description

This command shows the E1/T1 interface alarm log status

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm log e1t1-interface [ (index) ]
```

Command Parameters

Table 102.40-1 "E1/T1 Interface Alarm Log Status Commands" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm type

Command Output

Table 102.40-2 "E1/T1 Interface Alarm Log Status Commands" Display parameters

Only Show Details: current and previous alarm log status		
name	Type	Description
e1t1itf-recv-ais	Parameter type: <Alarm::itfaissignal> (yes no) Possible values: - yes : Alarm Indication Signal received at interface - no : no Alarm Indication Signal received at interface	status of Alarm Indication Signal received at interface <i>This element is only shown in detail mode.</i>
e1t1itf-recv-los	Parameter type: <Alarm::itflossignal> (yes no) Possible values: - yes : Loss Of Signal received at interface - no : no Loss Of Signal received at interface	status of Loss Of Signal Alarm received at interface <i>This element is only shown in detail mode.</i>
e1t1itf-recv-rai	Parameter type: <Alarm::itfraissignal> (yes no) Possible values:	status of Remote Alarm Indication received at interface <i>This element is only shown in detail mode.</i>

102 Alarm Log Status Commands

name	Type	Description
	- yes : Remote Alarm Indication received at interface - no : no Remote Alarm Indication received at interface	

102.41 SIP Termination Alarm Log Status Commands

Command Description

This command displays the SIP termination alarm log status.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm log cas-r2-channel [ (index) ]
```

Command Parameters

Table 102.41-1 "SIP Termination Alarm Log Status Commands" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm log table index

Command Output

Table 102.41-2 "SIP Termination Alarm Log Status Commands" Display parameters

Only Show Details: current and previous alarm log status		
name	Type	Description
exp-seizureack	Parameter type: <Alarm::ExpSeizureAck> (yes no) Possible values: - yes : Channel was blocked due to failure in the reception of the SEIZURE ACK signal - no : Channel was not blocked due to failure in the reception of the SEIZURE ACK signal	status of seizure ack signal <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::ExpSeizureAck> (yes no) Possible values: - yes : Channel was blocked due to failure in the reception of the SEIZURE ACK signal - no : Channel was not blocked due to failure in the reception of the SEIZURE ACK signal	status of seizure ack signal with its previous logged value <i>This element is only shown in detail mode.</i>

102 Alarm Log Status Commands

name	Type	Description
exp-disconack	Parameter type: <Alarm::ExpDisconnectAck> (yes no) Possible values: - yes : Channel was blocked due to failure in the reception of the DISCONNECTION ACK signal - no : Channel was not blocked due to failure in the reception of the DISCONNECTION ACK signal	status of disconnect ack signal <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::ExpDisconnectAck> (yes no) Possible values: - yes : Channel was blocked due to failure in the reception of the DISCONNECTION ACK signal - no : Channel was not blocked due to failure in the reception of the DISCONNECTION ACK signal	status of disconnect ack signal with its previous logged value <i>This element is only shown in detail mode.</i>
exp-forcerelack	Parameter type: <Alarm::ExpForceRelAck> (yes no) Possible values: - yes : Channel was blocked due to failure in the reception of the BACKWARD DISCONNECTION ACK signal - no : No Channel was blocked due to failure in the reception of the BACKWARD DISCONNECTION ACK signal	status of forced release ack signal <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::ExpForceRelAck> (yes no) Possible values: - yes : Channel was blocked due to failure in the reception of the BACKWARD DISCONNECTION ACK signal - no : No Channel was blocked due to failure in the reception of the BACKWARD DISCONNECTION ACK signal	status of forced release ack signal with its previous logged value <i>This element is only shown in detail mode.</i>

102.42 Pseudo Wire Alarm Log Status Command

Command Description

This command displays alarm log status of the Pseudo Wire.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

> show alarm log pseudo-wire [(index)]

Command Parameters

Table 102.42-1 "Pseudo Wire Alarm Log Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm log table index

Command Output

Table 102.42-2 "Pseudo Wire Alarm Log Status Command" Display parameters

Only Show Details: current and previous alarm log status		
name	Type	Description
packet-loss	Parameter type: <Alarm::PacketLoss> (yes no) Possible values: - yes : Pseudo Wire entered the Packet loss state - no : Pseudo Wire not entered the Packet loss state	specifies the packet loss status <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::PacketLoss> (yes no) Possible values: - yes : Pseudo Wire entered the Packet loss state - no : Pseudo Wire not entered the Packet loss state	status of the packet loss with its previous logged value <i>This element is only shown in detail mode.</i>
remote-packet-loss	Parameter type: <Alarm::RemotePacketLoss> (yes no) Possible values: - yes : Remote Packet loss detected - no : Remote Packet loss not detected	specifies the remote packet loss status <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::RemotePacketLoss>	status of the remote packet loss

102 Alarm Log Status Commands

name	Type	Description
	(yes no) Possible values: - yes : Remote Packet loss detected - no : Remote Packet loss not detected	with its previous logged value <i>This element is only shown in detail mode.</i>
no-dsp-resource	Parameter type: <Alarm::NoDspResource> (yes no) Possible values: - yes : DSP resource allocation failed - no : DSP resource allocation failed	specifies the no DSP resource status <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::NoDspResource> (yes no) Possible values: - yes : DSP resource allocation failed - no : DSP resource allocation failed	status of no DSP resource with its previous logged value <i>This element is only shown in detail mode.</i>

102.43 E1 Alarm Log Status Command

Command Description

This command displays the E1 alarm log status.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm log e1 [ (index) ]
```

Command Parameters

Table 102.43-1 "E1 Alarm Log Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm log table index

Command Output

Table 102.43-2 "E1 Alarm Log Status Command" Display parameters

Specific Information		
name	Type	Description
last-updated-on	Parameter type: <Sys::timeInSecs> - the time (yyyy-mm-dd:hour:minutes:secs) - unit: UTC	network time in seconds when the alarm was logged. <i>This element is only shown in detail mode.</i>
port	Parameter type: <Itf::E1Line> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number	identifies the physical position of the port <i>This element is only shown in detail mode.</i>

Only Show Details: current and previous alarm log status		
name	Type	Description
rx-rai	Parameter type: <Alarm::E1RxRai> (yes	recieving RAI <i>This element is only shown in</i>

102 Alarm Log Status Commands

name	Type	Description
	no) Possible values: - yes : recieving RAI - no : no recieving RAI	detail mode.
prev-status	Parameter type: <Alarm::E1RxRai> (yes no) Possible values: - yes : recieving RAI - no : no recieving RAI	status of rx-rai with its previous logged value <i>This element is only shown in detail mode.</i>
tx-rai	Parameter type: <Alarm::E1TxRai> (yes no) Possible values: - yes : transmitting RAI - no : no transmitting RAI	transmitting RAI <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::E1TxRai> (yes no) Possible values: - yes : transmitting RAI - no : no transmitting RAI	status of tx-rai with its previous logged value <i>This element is only shown in detail mode.</i>
rx-ais	Parameter type: <Alarm::E1RxAis> (yes no) Possible values: - yes : recieving AIS - no : no recieving AIS	recieving AIS <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::E1RxAis> (yes no) Possible values: - yes : recieving AIS - no : no recieving AIS	status of rx-ais with its previous logged value <i>This element is only shown in detail mode.</i>
tx-ais	Parameter type: <Alarm::E1TxAis> (yes no) Possible values: - yes : transmitting AIS - no : no transmitting AIS	transmitting AIS <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::E1TxAis> (yes no) Possible values: - yes : transmitting AIS - no : no transmitting AIS	status of tx-ais with its previous logged value <i>This element is only shown in detail mode.</i>
lof	Parameter type: <Alarm::E1LOF> (yes no) Possible values: - yes : loss of frame - no : no loss of frame	loss of frame <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::E1LOF> (yes no) Possible values: - yes : loss of frame	status of lof with its previous logged value <i>This element is only shown in detail mode.</i>

name	Type	Description
	- no : no loss of frame	
los	Parameter type: <Alarm::E1LOS> (yes no) Possible values: - yes : loss of signal - no : no loss of signal	loss of signal <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::E1LOS> (yes no) Possible values: - yes : loss of signal - no : no loss of signal	status of los with its previous logged value <i>This element is only shown in detail mode.</i>
loopback	Parameter type: <Alarm::E1Loopback> (yes no) Possible values: - yes : facility in loopback - no : facility not in loopback	facility in E1 loopback <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::E1Loopback> (yes no) Possible values: - yes : facility in loopback - no : facility not in loopback	status of loopback with its previous logged value <i>This element is only shown in detail mode.</i>

102.44 Shdsl Alarm Log Status Command

Command Description

This command displays the Shdsl alarm log status.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm log shdsl [ (index) ]
```

Command Parameters

Table 102.44-1 "Shdsl Alarm Log Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm log table index

Command Output

Table 102.44-2 "Shdsl Alarm Log Status Command" Display parameters

Specific Information		
name	Type	Description
last-updated-on	Parameter type: <Sys::timeInSecs> - the time (yyyy-mm-dd:hour:minutes:secs) - unit: UTC	network time in seconds when the alarm was logged. <i>This element is only shown in detail mode.</i>
port	Parameter type: <Itf::ShdslLine> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number	identifies the physical position of the port <i>This element is only shown in detail mode.</i>
wire-pair	Parameter type: <Alarm::LinkDeviceValuesHigh> - identify where the alarm occurred	identify where the alarm has occurred <i>This element is only shown in detail mode.</i>

name	Type	Description
unit	Parameter type: <Alarm::LinkDeviceValuesLow> - identify where the alarm occurred	identify where the alarm has occurred <i>This element is only shown in detail mode.</i>

Only Show Details: current and previous alarm log status

name	Type	Description
loop-act-net	Parameter type: <Alarm::LoopbackActiveNetwork> (yes no) Possible values: - yes : loopback active - no : no loopback active	loopback active at the network side <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::LoopbackActiveNetwork> (yes no) Possible values: - yes : loopback active - no : no loopback active	status of loop-act-net with its previous logged value <i>This element is only shown in detail mode.</i>
loop-act-cus	Parameter type: <Alarm::LoopbackActiveCustom> (yes no) Possible values: - yes : loopback active - no : no loopback active	loopback active at the custom side <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::LoopbackActiveCustom> (yes no) Possible values: - yes : loopback active - no : no loopback active	status of loop-act-cus with its previous logged value <i>This element is only shown in detail mode.</i>
config-error	Parameter type: <Alarm::ConfigError> (yes no) Possible values: - yes : config error - no : no config error	configuration error <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::ConfigError> (yes no) Possible values: - yes : config error - no : no config error	status of config-error with its previous logged value <i>This element is only shown in detail mode.</i>
loss-atm	Parameter type: <Alarm::LossATMCellDel> (yes no) Possible values: - yes : loss atm cell delineation - no : no loss atm cell delineation	loss of atm cell delineation <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::LossATMCellDel> (yes no) Possible values: - yes : loss atm cell delineation - no : no loss atm cell delineation	status of loss-atm with its previous logged value <i>This element is only shown in detail mode.</i>
loss-pr	Parameter type: <Alarm::LossPowerSTUR> (yes no)	loss of power at stu-r <i>This element is only shown in detail mode.</i>

102 Alarm Log Status Commands

name	Type	Description
	Possible values: - yes : loss power at stu-r - no : no loss power at stu-r	
prev-status	Parameter type: <Alarm::LossPowerSTUR> (yes no) Possible values: - yes : loss power at stu-r - no : no loss power at stu-r	status of loss-pr with its previous logged value <i>This element is only shown in detail mode.</i>
secu-error	Parameter type: <Alarm::UnableDisableSTUR> (yes no) Possible values: - yes : loss ability at stu-r - no : no loss ability at stu-r	loss of ability to disable stu-r access <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::UnableDisableSTUR> (yes no) Possible values: - yes : loss ability at stu-r - no : no loss ability at stu-r	status of secu-error with its previous logged value <i>This element is only shown in detail mode.</i>
dev-fault	Parameter type: <Alarm::DeviceFault> (yes no) Possible values: - yes : device fault - no : no device fault	fault of device <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::DeviceFault> (yes no) Possible values: - yes : device fault - no : no device fault	status of dev-fault with its previous logged value <i>This element is only shown in detail mode.</i>
atm-ncd	Parameter type: <Alarm::ATMCellDel> (yes no) Possible values: - yes : no atm cell delineation - no : atm cell delineation	none of atm cell delineation <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::ATMCellDel> (yes no) Possible values: - yes : no atm cell delineation - no : atm cell delineation	status of atm-ncd with its previous logged value <i>This element is only shown in detail mode.</i>

102.45 Shdsl Alarm Log Status Command

Command Description

This command displays the Shdsl alarm log status.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm log shdsl-isam [ (index) ]
```

Command Parameters

Table 102.45-1 "Shdsl Alarm Log Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm log table index

Command Output

Table 102.45-2 "Shdsl Alarm Log Status Command" Display parameters

Specific Information		
name	Type	Description
last-updated-on	Parameter type: <Sys::timeInSecs> - the time (yyyy-mm-dd:hour:minutes:secs) - unit: UTC	network time in seconds when the alarm was logged. <i>This element is only shown in detail mode.</i>
port	Parameter type: <Itf::ShdslLine> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number	identifies the physical position of the port <i>This element is only shown in detail mode.</i>
unit	Parameter type: <Alarm::LinkDeviceValues> - a signed integer	identify where the alarm has occurred <i>This element is only shown in detail mode.</i>

102 Alarm Log Status Commands

Only Show Details: current and previous alarm log status		
name	Type	Description
loss-syn-net	Parameter type: <Alarm::LossSyncWordNetwork> (yes no) Possible values: - yes : loss sync word - no : no loss sync word	loss of sync word at the network side on each pair <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::LossSyncWordNetwork> (yes no) Possible values: - yes : loss sync word - no : no loss sync word	status of loss-syn-net with its previous logged value <i>This element is only shown in detail mode.</i>
loss-syn-cus	Parameter type: <Alarm::LossSyncWordCustom> (yes no) Possible values: - yes : loss sync word - no : no loss sync word	loss of sync word at the custom side on each pair <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::LossSyncWordCustom> (yes no) Possible values: - yes : loss sync word - no : no loss sync word	status of loss-syn-cus with its previous logged value <i>This element is only shown in detail mode.</i>
loop-att-net	Parameter type: <Alarm::LoopAttenuationNetwork> (yes no) Possible values: - yes : loop attenuation - no : no loop attenuation	loop attenuation alarm at the network side on each pair <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::LoopAttenuationNetwork> (yes no) Possible values: - yes : loop attenuation - no : no loop attenuation	status of loop-att-net with its previous logged value <i>This element is only shown in detail mode.</i>
loop-att-cus	Parameter type: <Alarm::LoopAttenuationCustom> (yes no) Possible values: - yes : loop attenuation - no : no loop attenuation	loop attenuation alarm at the custom side on each pair <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::LoopAttenuationCustom> (yes no) Possible values: - yes : loop attenuation - no : no loop attenuation	status of loop-att-cus with its previous logged value <i>This element is only shown in detail mode.</i>
snr-net	Parameter type: <Alarm::SNRNetwork> (yes no) Possible values: - yes : snr margin - no : no snr margin	snr margin alarm at the network side each pair <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::SNRNetwork> (yes	status of snr-net with its previous logged value

name	Type	Description
	no) Possible values: - yes : snr margin - no : no snr margin	<i>This element is only shown in detail mode.</i>
snr-cus	Parameter type: <Alarm::SNRCustom> (yes no) Possible values: - yes : snr margin - no : no snr margin	snr margin alarm at the custom side each pair <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::SNRCustom> (yes no) Possible values: - yes : snr margin - no : no snr margin	status of snr-cus with its previous logged value <i>This element is only shown in detail mode.</i>
dc-net	Parameter type: <Alarm::DCContinuityFaultNetwork> (yes no) Possible values: - yes : dc fault - no : no dc fault	dc continuity fault at the network side on each pair <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::DCContinuityFaultNetwork> (yes no) Possible values: - yes : dc fault - no : no dc fault	status of dc-net with its previous logged value <i>This element is only shown in detail mode.</i>
dc-cus	Parameter type: <Alarm::DCContinuityFaultCustom> (yes no) Possible values: - yes : dc fault - no : no dc fault	dc continuity fault at the custom side on each pair <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::DCContinuityFaultCustom> (yes no) Possible values: - yes : dc fault - no : no dc fault	status of dc-cus with its previous logged value <i>This element is only shown in detail mode.</i>

102.46 Megaco Media Gateway Alarm Log Status Command

Command Description

This command displays the Megaco media gateway alarm log status.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm log megaco-media-gw [ (index) ]
```

Command Parameters

Table 102.46-1 "Megaco Media Gateway Alarm Log Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm log table index

Command Output

Table 102.46-2 "Megaco Media Gateway Alarm Log Status Command" Display parameters

Only Show Details: current and previous alarm log status		
name	Type	Description
mgc-unreachable	Parameter type: <Alarm::mgcUnreachable> (yes no) Possible values: - yes : media gateway controller is unreachable - no : media gateway controller is reachable	specifies the media gateway controller status <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::mgcUnreachable> (yes no) Possible values: - yes : media gateway controller is unreachable - no : media gateway controller is reachable	status of specifies media gateway with its previous logged value <i>This element is only shown in detail mode.</i>
failover-to-esamgc	Parameter type: <Alarm::failovertoESAMGC> (yes no) Possible values:	specifies the esa mgc service status <i>This element is only shown in detail mode.</i>

name	Type	Description
	- yes : failover to esa mgc - no : normal mgc is in service	
prev-status	Parameter type: <Alarm::failoverttoESAMGC> (yes no) Possible values: - yes : failover to esa mgc - no : normal mgc is in service	status of esa mgc service <i>This element is only shown in detail mode.</i>

102.47 Megaco Signaling Gateway Alarm Log Status Command

Command Description

This command displays the Megaco signaling gateway alarm log status.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm log megaco-sig-gw [ (index) ]
```

Command Parameters

Table 102.47-1 "Megaco Signaling Gateway Alarm Log Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm log table index

Command Output

Table 102.47-2 "Megaco Signaling Gateway Alarm Log Status Command" Display parameters

Only Show Details: current and previous alarm log status		
name	Type	Description
sgc-unreachable	Parameter type: <Alarm::sgcUnreachable> (yes no) Possible values: - yes : signalling gateway controller is unreachable - no : signalling gateway controller is reachable	specifies the signaling gateway controller status <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::sgcUnreachable> (yes no) Possible values: - yes : signalling gateway controller is unreachable - no : signalling gateway controller is reachable	status of specifies signaling gateway with its previous logged value <i>This element is only shown in detail mode.</i>

102.48 Megaco Plug Unit Alarm Log Status Command

Command Description

This command displays the Megaco plug unit alarm log status.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm log megaco-plug-unit [ (index) ]
```

Command Parameters

Table 102.48-1 "Megaco Plug Unit Alarm Log Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm log table index

Command Output

Table 102.48-2 "Megaco Plug Unit Alarm Log Status Command" Display parameters

Only Show Details: current and previous alarm log status		
name	Type	Description
lcard-unreach-srvcard	Parameter type: <Alarm::lineCardUnreachSrvCard> (yes no) Possible values: - yes : line card is unreachable with server card - no : line card is reachable with server card	specifies the line card with server card status <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::lineCardUnreachSrvCard> (yes no) Possible values: - yes : line card is unreachable with server card - no : line card is reachable with server card	status of line card and server card with its previous logged value <i>This element is only shown in detail mode.</i>
lcard-type-mismatch	Parameter type: <Alarm::lineCardTypeMismatchch> (yes no) Possible values:	specifies the line card type status <i>This element is only shown in detail mode.</i>

102 Alarm Log Status Commands

name	Type	Description
	- yes : line card type is mismatch - no : line card type is match	
prev-status	Parameter type: <Alarm::lineCardTypeMismatchch> (yes no) Possible values: - yes : line card type is mismatch - no : line card type is match	status of line card type with its previous logged value <i>This element is only shown in detail mode.</i>

102.49 Megaco Termination Alarm Log Status Command

Command Description

This command displays the Megaco termination alarm log status.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

> show alarm log megaco-term [(index)]

Command Parameters

Table 102.49-1 "Megaco Termination Alarm Log Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm log table index

Command Output

Table 102.49-2 "Megaco Termination Alarm Log Status Command" Display parameters

Only Show Details: current and previous alarm log status		
name	Type	Description
meg-unknown-sub	Parameter type: <Alarm::megacoUnknownSubscriber> (yes no) Possible values: - yes : unknown wrong megaco subscriber - no : no wrong megaco subscriber	specifies the megaco subscriber status <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::megacoUnknownSubscriber> (yes no) Possible values: - yes : unknown wrong megaco subscriber - no : no wrong megaco subscriber	status of the megaco subscriber with its previous logged value <i>This element is only shown in detail mode.</i>
meg-ground-key	Parameter type: <Alarm::voicePortGroundKey> (yes no) Possible values:	specifies the voice port ground key status <i>This element is only shown in detail mode.</i>

102 Alarm Log Status Commands

name	Type	Description
	- yes : voice port ground key - no : voice port not ground key	
prev-status	Parameter type: <Alarm::voicePortGroundKey> (yes no) Possible values: - yes : voice port ground key - no : voice port not ground key	status of the voice port ground key with its previous logged value <i>This element is only shown in detail mode.</i>
meg-high-temp	Parameter type: <Alarm::voicePortHighTemp> (yes no) Possible values: - yes : voice port high temperature - no : voice port not high temperature	specifies the voice port temperature status <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::voicePortHighTemp> (yes no) Possible values: - yes : voice port high temperature - no : voice port not high temperature	status of the voice port temperature with its previous logged value <i>This element is only shown in detail mode.</i>
l1-act-fail	Parameter type: <Alarm::voicePortL1ActFail> (yes no) Possible values: - yes : voice port l1 act failure - no : voice port l1 act not failure	specifies the voice port l1 act status <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::voicePortL1ActFail> (yes no) Possible values: - yes : voice port l1 act failure - no : voice port l1 act not failure	status of the voice port l1 act with its previous logged value <i>This element is only shown in detail mode.</i>
over-current	Parameter type: <Alarm::voicePortOverCurrent> (yes no) Possible values: - yes : voice port over current - no : voice port not over current	specifies the voice port over current status <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::voicePortOverCurrent> (yes no) Possible values: - yes : voice port over current - no : voice port not over current	status of the voice port over current with its previous logged value <i>This element is only shown in detail mode.</i>
line-showering	Parameter type: <Alarm::lineshowering> (yes no) Possible values: - yes : line showering - no : no line showering	specifies the line showering status <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::lineshowering> (yes no) Possible values: - yes : line showering - no : no line showering	status of the line showering with its previous logged value <i>This element is only shown in detail mode.</i>
low-qos-packetloss	Parameter type: <Alarm::lowQosPacketLoss>	specifies the megaco total packet

name	Type	Description
	(yes no) Possible values: - yes : the total packet loss has exceeded the configured threshold - no : the total packet loss has not exceeded the configured threshold	loss status <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::lowQosPacketLoss> (yes no) Possible values: - yes : the total packet loss has exceeded the configured threshold - no : the total packet loss has not exceeded the configured threshold	status of the megaco total packet loss value <i>This element is only shown in detail mode.</i>
low-qos-jitter	Parameter type: <Alarm::lowQosJitter> (yes no) Possible values: - yes : the rtp jitter has exceeded the configured threshold - no : the rtp jitter has not exceeded the configured threshold	specifies the megaco rtp jitter status <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::lowQosJitter> (yes no) Possible values: - yes : the rtp jitter has exceeded the configured threshold - no : the rtp jitter has not exceeded the configured threshold	status of the megaco rtp jitter value <i>This element is only shown in detail mode.</i>
low-qos-delay	Parameter type: <Alarm::lowQosDelay> (yes no) Possible values: - yes : the rtp delay has exceeded the configured threshold - no : the rtp delay has not exceeded the configured threshold	specifies the megaco rtp delay status <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::lowQosDelay> (yes no) Possible values: - yes : the rtp delay has exceeded the configured threshold - no : the rtp delay has not exceeded the configured threshold	status of the megaco rtp delay value <i>This element is only shown in detail mode.</i>

102.50 Secondary Megaco Termination Alarm Log Status Command

Command Description

This command displays alarm log status of the secondary Megaco termination.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

> show alarm log secondary-megaco-term [(index)]

Command Parameters

Table 102.50-1 "Secondary Megaco Termination Alarm Log Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm log table index

Command Output

Table 102.50-2 "Secondary Megaco Termination Alarm Log Status Command" Display parameters

Only Show Details: current and previous alarm log status		
name	Type	Description
meg-unknown-sub-sec	Parameter type: <Alarm::megacoUnknownSubscriber> (yes no) Possible values: - yes : unknown wrong megaco subscriber - no : no wrong megaco subscriber	specifies the megaco subscriber status <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::megacoUnknownSubscriber> (yes no) Possible values: - yes : unknown wrong megaco subscriber - no : no wrong megaco subscriber	status of the megaco subscriber with its previous logged value <i>This element is only shown in detail mode.</i>
line-showering-sec	Parameter type: <Alarm::lineshowering> (yes no)	specifies the line showering status <i>This element is only shown in</i>

name	Type	Description
	Possible values: - yes : line showering - no : no line showering	<i>detail mode.</i>
prev-status	Parameter type: <Alarm::lineshowering> (yes no) Possible values: - yes : line showering - no : no line showering	status of the line showering with its previous logged value <i>This element is only shown in detail mode.</i>

102.51 Megaco Signaling Lt Alarm Log Status Command

Command Description

This command displays the Megaco signaling Lt alarm log status.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm log megaco-sig-lt [ (index) ]
```

Command Parameters

Table 102.51-1 "Megaco Signaling Lt Alarm Log Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm log table index

Command Output

Table 102.51-2 "Megaco Signaling Lt Alarm Log Status Command" Display parameters

Only Show Details: current and previous alarm log status		
name	Type	Description
sig-brd-persist-loss	Parameter type: <Alarm::megacoSigBoardPersDataLoss> (yes no) Possible values: - yes : the voice signaling board persistenet data loss - no : the voice signaling board persistenet data not loss	specifies the voice signaling board persistenet data status <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::megacoSigBoardPersDataLoss> (yes no) Possible values: - yes : the voice signaling board persistenet data loss - no : the voice signaling board persistenet data not loss	status of voice signaling board persistenet data with its previous logged value <i>This element is only shown in detail mode.</i>
sig-brd-disk-full	Parameter type: <Alarm::voiceSigBoard90PercentFull> (yes no) Possible values:	specifies the voice signaling board disk status <i>This element is only shown in detail mode.</i>

name	Type	Description
	- yes : specifies the voice signaling board disk 90% full - no : specifies the voice signaling board disk no 90% full	
prev-status	Parameter type: <Alarm::voiceSigBoard90PercentFull> (yes no) Possible values: - yes : specifies the voice signaling board disk 90% full - no : specifies the voice signaling board disk no 90% full	status of voice signaling board disk with its previous logged value <i>This element is only shown in detail mode.</i>
sig-brd-db-roolback	Parameter type: <Alarm::sigBoardDBRollback> (yes no) Possible values: - yes : specifies the voice signaling board implicit db rollback - no : specifies the voice signaling board implicit db no rollback	specifies the voice signaling board implicit db status <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::sigBoardDBRollback> (yes no) Possible values: - yes : specifies the voice signaling board implicit db rollback - no : specifies the voice signaling board implicit db no rollback	status of voice signaling board implicit db with its previous logged value <i>This element is only shown in detail mode.</i>
mg-overload	Parameter type: <Alarm::megMGOverLoad> (yes no) Possible values: - yes : specifies the mg overload - no : specifies the mg no overload	specifies the mg overload status <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::megMGOverLoad> (yes no) Possible values: - yes : specifies the mg overload - no : specifies the mg no overload	status of the mg overload with its previous logged value <i>This element is only shown in detail mode.</i>

102.52 Ima-Group Alarm Log Status Command

Command Description

This command displays the Ima-Group alarm log status.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm log ima-group [ (index) ]
```

Command Parameters

Table 102.52-1 "Ima-Group Alarm Log Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm log table index

Command Output

Table 102.52-2 "Ima-Group Alarm Log Status Command" Display parameters

Specific Information		
name	Type	Description
last-updated-on	Parameter type: <Sys::timeInSecs> - the time (yyyy-mm-dd:hour:minutes:secs) - unit: UTC	network time in seconds when the alarm was logged. <i>This element is only shown in detail mode.</i>
port	Parameter type: <Equipm::AtmImaIndex> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number	identifies the physical position of the port <i>This element is only shown in detail mode.</i>

Only Show Details: current and previous alarm log status		
name	Type	Description
far-end-start	Parameter type: <Alarm::FarEndStartup> (yes	far-end starting up <i>This element is only shown in</i>

name	Type	Description
	no) Possible values: - yes : far-end startup - no : no far-end startup	<i>detail mode.</i>
prev-status	Parameter type: <Alarm::FarEndStartup> (yes no) Possible values: - yes : far-end startup - no : no far-end startup	status of far-end-start with its previous logged value <i>This element is only shown in detail mode.</i>
far-end-fconf	Parameter type: <Alarm::FarEndFailedConfig> (yes no) Possible values: - yes : far-end failed config - no : no far-end failed config	failed configuration of far-end <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::FarEndFailedConfig> (yes no) Possible values: - yes : far-end failed config - no : no far-end failed config	status of far-end-fconf with its previous logged value <i>This element is only shown in detail mode.</i>
near-end-fconf	Parameter type: <Alarm::NearEndFailedConfig> (yes no) Possible values: - yes : near-end failed config - no : no near-end failed config	failed configuration of near-end <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::NearEndFailedConfig> (yes no) Possible values: - yes : near-end failed config - no : no near-end failed config	status of near-end-fconf with its previous logged value <i>This element is only shown in detail mode.</i>
far-end-ins-lnk	Parameter type: <Alarm::FarEndInsuffLinkNum> (yes no) Possible values: - yes : insufficient number of links at far-end - no : no insufficient number of links at far-end	insufficient number of links at far-end <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::FarEndInsuffLinkNum> (yes no) Possible values: - yes : insufficient number of links at far-end - no : no insufficient number of links at far-end	status of far-end-ins-lnk with its previous logged value <i>This element is only shown in detail mode.</i>
near-end-ins-lnk	Parameter type: <Alarm::NearEndInsuffLinkNum> (yes no) Possible values: - yes : insufficient number of links at near-end - no : no insufficient number of links at near-end	insufficient number of links at near-end <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::NearEndInsuffLinkNum> (yes no) Possible values: - yes : insufficient number of links at near-end	status of near-end-ins-lnk with its previous logged value <i>This element is only shown in detail mode.</i>

102 Alarm Log Status Commands

name	Type	Description
	- no : no insufficient number of links at near-end	
far-end-blk	Parameter type: <Alarm::FarEndBlocked> (yes no) Possible values: - yes : far-end blocked - no : no far-end blocked	status that far-end is blocked <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::FarEndBlocked> (yes no) Possible values: - yes : far-end blocked - no : no far-end blocked	status of far-end-blk with its previous logged value <i>This element is only shown in detail mode.</i>

102.53 Ima-Link Alarm Log Status Command

Command Description

This command displays the Ima-Link alarm log status.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm log ima-link [ (index) ]
```

Command Parameters

Table 102.53-1 "Ima-Link Alarm Log Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm log table index

Command Output

Table 102.53-2 "Ima-Link Alarm Log Status Command" Display parameters

Specific Information		
name	Type	Description
last-updated-on	Parameter type: <Sys::timeInSecs> - the time (yyyy-mm-dd:hour:minutes:secs) - unit: UTC	network time in seconds when the alarm was logged. <i>This element is only shown in detail mode.</i>
port	Parameter type: <Itf::ShdslLine> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number	identifies the physical position of the port <i>This element is only shown in detail mode.</i>

Only Show Details: current and previous alarm log status		
name	Type	Description
loss-ima-frm	Parameter type: <Alarm::LossImaFrame> (yes	loss of ima frame <i>This element is only shown in</i>

102 Alarm Log Status Commands

name	Type	Description
	no) Possible values: - yes : loss ima frame - no : no loss ima frame	detail mode.
prev-status	Parameter type: <Alarm::LossImaFrame> (yes no) Possible values: - yes : loss ima frame - no : no loss ima frame	status of loss-ima-frm with its previous logged value <i>This element is only shown in detail mode.</i>
lods	Parameter type: <Alarm::LinkOutofDelaySynch> (yes no) Possible values: - yes : link out of delay - no : no link out of delay	link out of delay synchronization <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::LinkOutofDelaySynch> (yes no) Possible values: - yes : link out of delay - no : no link out of delay	status of lods with its previous logged value <i>This element is only shown in detail mode.</i>
link-misc	Parameter type: <Alarm::LinkMisconnect> (yes no) Possible values: - yes : link misconnect - no : no link misconnect	link of misconnecting <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::LinkMisconnect> (yes no) Possible values: - yes : link misconnect - no : no link misconnect	status of link-misc with its previous logged value <i>This element is only shown in detail mode.</i>
link-rfi	Parameter type: <Alarm::LinkRemoteFailureIndication> (yes no) Possible values: - yes : link remote failure indication - no : no link remote failure indication	link of remote failure indication <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::LinkRemoteFailureIndication> (yes no) Possible values: - yes : link remote failure indication - no : no link remote failure indication	status of link-rfi with its previous logged value <i>This element is only shown in detail mode.</i>
link-fault	Parameter type: <Alarm::LinkFault> (yes no) Possible values: - yes : fault in link facility - no : no fault in link facility	fault of link <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::LinkFault> (yes no) Possible values: - yes : fault in link facility	status of link-fault with its previous logged value <i>This element is only shown in detail mode.</i>

name	Type	Description
	- no : no fault in link facility	
fe-tx-blk	Parameter type: <Alarm::FarEndTXBlocked> (yes no) Possible values: - yes : transmit blocked due to far-end - no : no transmit blocked due to far-end	transmit blocked due to far-end <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::FarEndTXBlocked> (yes no) Possible values: - yes : transmit blocked due to far-end - no : no transmit blocked due to far-end	status of fe-tx-blk with its previous logged value <i>This element is only shown in detail mode.</i>
fe-rec-blk	Parameter type: <Alarm::FarEndRXBlocked> (yes no) Possible values: - yes : receive blocked due to far-end - no : no receive blocked due to far-end	receive blocked due to far-end <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::FarEndRXBlocked> (yes no) Possible values: - yes : receive blocked due to far-end - no : no receive blocked due to far-end	status of fe-rec-blk with its previous logged value <i>This element is only shown in detail mode.</i>

102.54 Ether-Tca Alarm Log Status Command

Command Description

This command displays the Ether-Tca alarm log status.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm log ether-tca [ (index) ]
```

Command Parameters

Table 102.54-1 "Ether-Tca Alarm Log Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm log table index

Command Output

Table 102.54-2 "Ether-Tca Alarm Log Status Command" Display parameters

Specific Information		
name	Type	Description
last-updated-on	Parameter type: <Sys::timeInSecs> - the time (yyyy-mm-dd:hour:minutes:secs) - unit: UTC	network time in seconds when the alarm was logged. <i>This element is only shown in detail mode.</i>
port	Parameter type: <Itf::EthernetPortIndex> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number	identifies the physical position of the port <i>This element is only shown in detail mode.</i>

Only Show Details: current and previous alarm log status		
name	Type	Description
etca-los	Parameter type: <Alarm::EthTcaLos> (yes	ethernet loss of signal <i>This element is only shown in</i>

name	Type	Description
	no) Possible values: - yes : ethernet loss of signal errors exceeds - no : ethernet loss of signal errors normal	<i>detail mode.</i>
prev-status	Parameter type: <Alarm::EthTcaLos> (yes no) Possible values: - yes : ethernet loss of signal errors exceeds - no : ethernet loss of signal errors normal	status of etca-los with its previous logged value <i>This element is only shown in detail mode.</i>
etca-fcs	Parameter type: <Alarm::EthTcaFcs> (yes no) Possible values: - yes : ethernet frame check sequence errors exceeds - no : ethernet frame check sequence errors normal	ethernet frame check sequence <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::EthTcaFcs> (yes no) Possible values: - yes : ethernet frame check sequence errors exceeds - no : ethernet frame check sequence errors normal	status of etca-fcs with its previous logged value <i>This element is only shown in detail mode.</i>
etca-rx-octets	Parameter type: <Alarm::EthTcaRxb> (yes no) Possible values: - yes : received octets exceeds - no : received octets normal	received octets <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::EthTcaRxb> (yes no) Possible values: - yes : received octets exceeds - no : received octets normal	status of etca-rx-octets with its previous logged value <i>This element is only shown in detail mode.</i>
etca-tx-octets	Parameter type: <Alarm::EthTcaTxb> (yes no) Possible values: - yes : transmitted octets exceeds - no : transmitted octets normal	transmitted octets <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::EthTcaTxb> (yes no) Possible values: - yes : transmitted octets exceeds - no : transmitted octets normal	status of etca-tx-octets with its previous logged value <i>This element is only shown in detail mode.</i>
etca-day-los	Parameter type: <Alarm::EthDayLos> (yes no) Possible values: - yes : ethernet day los errors exceeds - no : ethernet day los errors normal	ethernet day los <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::EthDayLos> (yes no) Possible values: - yes : ethernet day los errors exceeds	status of etca-day-los with its previous logged value <i>This element is only shown in detail mode.</i>

102 Alarm Log Status Commands

name	Type	Description
	- no : ethernet day los errors normal	
etca-day-fcs	Parameter type: <Alarm::EthDayFcs> (yes no) Possible values: - yes : ethernet day fcs errors exceeds - no : ethernet day fcs errors normal	ethernet day fcs <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::EthDayFcs> (yes no) Possible values: - yes : ethernet day fcs errors exceeds - no : ethernet day fcs errors normal	status of etca-day-fcs with its previous logged value <i>This element is only shown in detail mode.</i>
etca-day-rx-octets	Parameter type: <Alarm::EthDayRxb> (yes no) Possible values: - yes : received octets day exceeds - no : received octets day normal	received octets <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::EthDayRxb> (yes no) Possible values: - yes : received octets day exceeds - no : received octets day normal	status of etca-day-rx-octets with its previous logged value <i>This element is only shown in detail mode.</i>
etca-day-tx-octets	Parameter type: <Alarm::EthDayTxb> (yes no) Possible values: - yes : transmitted octets day exceeds - no : transmitted octets day normal	transmitted octets <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::EthDayTxb> (yes no) Possible values: - yes : transmitted octets day exceeds - no : transmitted octets day normal	status of etca-day-tx-octets with its previous logged value <i>This element is only shown in detail mode.</i>

102.55 Ether-Sfp Alarm Log Status Command

Command Description

This command displays the Ether-Sfp alarm log status.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

> show alarm log ether-sfp [(index)]

Command Parameters

Table 102.55-1 "Ether-Sfp Alarm Log Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm log table index

Command Output

Table 102.55-2 "Ether-Sfp Alarm Log Status Command" Display parameters

Specific Information		
name	Type	Description
last-updated-on	Parameter type: <Sys::timeInSecs> - the time (yyyy-mm-dd:hour:minutes:secs) - unit: UTC	network time in seconds when the alarm was logged. <i>This element is only shown in detail mode.</i>
port	Parameter type: <Itf::EthernetPortIndex> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number	identifies the physical position of the port <i>This element is only shown in detail mode.</i>

Only Show Details: current and previous alarm log status		
name	Type	Description
user-sfp-los	Parameter type: <Alarm::EthSfpLos> (yes	ethernet sfp loss of signal <i>This element is only shown in</i>

102 Alarm Log Status Commands

name	Type	Description
	no) Possible values: - yes : ethernet sfp los error - no : ethernet sfp los normal	<i>detail mode.</i>
prev-status	Parameter type: <Alarm::EthSfpLos> (yes no) Possible values: - yes : ethernet sfp los error - no : ethernet sfp los normal	status of user-sfp-los with its previous logged value <i>This element is only shown in detail mode.</i>
user-sfp-tx-fail	Parameter type: <Alarm::EthSfpTxFail> (yes no) Possible values: - yes : ethernet sfp Tx Failure - no : ethernet sfp Tx normal	ethernet sfp tx <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::EthSfpTxFail> (yes no) Possible values: - yes : ethernet sfp Tx Failure - no : ethernet sfp Tx normal	status of user-sfp-tx-fail with its previous logged value <i>This element is only shown in detail mode.</i>
user-sfp-not-prst	Parameter type: <Alarm::EthSfpNotPrst> (yes no) Possible values: - yes : ethernet sfp not detected - no : ethernet sfp detected	ethernet sfp presence <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::EthSfpNotPrst> (yes no) Possible values: - yes : ethernet sfp not detected - no : ethernet sfp detected	status of user-sfp-not-prst with its previous logged value <i>This element is only shown in detail mode.</i>
user-sfp-inv-id	Parameter type: <Alarm::EthSfpInvalid> (yes no) Possible values: - yes : ethernet sfp id invalid - no : ethernet sfp id normal	ethernet sfp id validity <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::EthSfpInvalid> (yes no) Possible values: - yes : ethernet sfp id invalid - no : ethernet sfp id normal	status of user-sfp-inv-id with its previous logged value <i>This element is only shown in detail mode.</i>
user-sfp-t-exceed	Parameter type: <Alarm::EthSfpTempExceed> (yes no) Possible values: - yes : ethernet sfp temperature exceed - no : ethernet sfp temperature normal	ethernet sfp temperature <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::EthSfpTempExceed> (yes no) Possible values: - yes : ethernet sfp temperature exceed	status of user-sfp-t-exceed with its previous logged value <i>This element is only shown in detail mode.</i>

name	Type	Description
	- no : ethernet sfp temperature normal	
user-sfp-mismatch	Parameter type: <Alarm::EthSfpMismatch> (yes no) Possible values: - yes : ethernet sfp mismatch the configured type - no : ethernet sfp match the configured type	ethernet sfp type <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::EthSfpMismatch> (yes no) Possible values: - yes : ethernet sfp mismatch the configured type - no : ethernet sfp match the configured type	status of user-sfp-mismatch with its previous logged value <i>This element is only shown in detail mode.</i>

102.56 Ether-Sfp Alarm Log Status Command

Command Description

This command displays the Ether-Sfp alarm log status.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm log uplink-ether-sfp [ (index) ]
```

Command Parameters

Table 102.56-1 "Ether-Sfp Alarm Log Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm log table index

Command Output

Table 102.56-2 "Ether-Sfp Alarm Log Status Command" Display parameters

Specific Information		
name	Type	Description
last-updated-on	Parameter type: <Sys::timeInSecs> - the time (yyyy-mm-dd:hour:minutes:secs) - unit: UTC	network time in seconds when the alarm was logged. <i>This element is only shown in detail mode.</i>
port	Parameter type: <Itf::EthernetPortIndex> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number	identifies the physical position of the port <i>This element is only shown in detail mode.</i>

Only Show Details: current and previous alarm log status		
name	Type	Description
uplink-sfp-los	Parameter type: <Alarm::EthSfpLos> (yes	ethernet uplink sfp loss of signal <i>This element is only shown in</i>

name	Type	Description
	no) Possible values: - yes : ethernet sfp los error - no : ethernet sfp los normal	<i>detail mode.</i>
prev-status	Parameter type: <Alarm::EthSfpLos> (yes no) Possible values: - yes : ethernet sfp los error - no : ethernet sfp los normal	status of uplink sfp-los with its previous logged value <i>This element is only shown in detail mode.</i>
uplink-sfp-tx-fail	Parameter type: <Alarm::EthSfpTxFail> (yes no) Possible values: - yes : ethernet sfp Tx Failure - no : ethernet sfp Tx normal	uplink ethernet sfp tx <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::EthSfpTxFail> (yes no) Possible values: - yes : ethernet sfp Tx Failure - no : ethernet sfp Tx normal	status of uplink sfp-tx-fail with its previous logged value <i>This element is only shown in detail mode.</i>
uplink-sfp-not-prst	Parameter type: <Alarm::EthSfpNotPrst> (yes no) Possible values: - yes : ethernet sfp not detected - no : ethernet sfp detected	ethernet uplink sfp presence <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::EthSfpNotPrst> (yes no) Possible values: - yes : ethernet sfp not detected - no : ethernet sfp detected	status of uplink sfp-not-prst with its previous logged value <i>This element is only shown in detail mode.</i>
uplink-sfp-inv-id	Parameter type: <Alarm::EthSfpInvalid> (yes no) Possible values: - yes : ethernet sfp id invalid - no : ethernet sfp id normal	ethernet uplink sfp id validity <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::EthSfpInvalid> (yes no) Possible values: - yes : ethernet sfp id invalid - no : ethernet sfp id normal	status of sfp-inv-id with its previous logged value <i>This element is only shown in detail mode.</i>
uplink-sfp-t-exceed	Parameter type: <Alarm::EthSfpTempExceed> (yes no) Possible values: - yes : ethernet sfp temperature exceed - no : ethernet sfp temperature normal	ethernet uplink sfp temperature <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::EthSfpTempExceed> (yes no) Possible values: - yes : ethernet sfp temperature exceed	status of uplink-sfp-t-exceed with its previous logged value <i>This element is only shown in detail mode.</i>

102 Alarm Log Status Commands

name	Type	Description
	- no : ethernet sfp temperature normal	
uplink-sfp-mismatch	Parameter type: <Alarm::EthSfpMismatch> (yes no) Possible values: - yes : ethernet sfp mismatch the configured type - no : ethernet sfp match the configured type	uplink ethernet sfp type <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::EthSfpMismatch> (yes no) Possible values: - yes : ethernet sfp mismatch the configured type - no : ethernet sfp match the configured type	status of uplink-sfp-mismatch with its previous logged value <i>This element is only shown in detail mode.</i>

102.57 Alarm Qos Slot Log Status Commands

Command Description

This command displays the Qos Slot alarm log status.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm log qos-slot [ (index) ]
```

Command Parameters

Table 102.57-1 "Alarm Qos Slot Log Status Commands" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm log table index

Command Output

Table 102.57-2 "Alarm Qos Slot Log Status Commands" Display parameters

Specific Information		
name	Type	Description
last-updated-on	Parameter type: <Sys::timeInSecs> - the time (yyyy-mm-dd:hour:minutes:secs) - unit: UTC	network time in seconds when the alarm was logged. <i>This element is always shown.</i>
board-position	Parameter type: <Equipm::SlotIndex> (lt : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> nt-a nt-b nt acu : <Eqpt::RackId> / <Eqpt::ShelfId> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::EqSlotId> ext-a : <Eqpt::RackId> / <Eqpt::ShelfId> ext-b : <Eqpt::RackId> / <Eqpt::ShelfId> ctrl : <Eqpt::RackId> / <Eqpt::ShelfId> vlt : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::VirtualSlotId>) Possible values: - lt : lt-slot - vlt : virtual LT slot (VVPS board can only be planned at NANT-E / FANT-F)	identify where the alarm has occurred. <i>This element is always shown.</i>

102 Alarm Log Status Commands

name	Type	Description
	- nt-a : nt-a slot - nt-b : nt-b slot - nt : nt slot - ext-a : nt-a slot in an extension shelf - ext-b : nt-b slot in an extension shelf - acu : acu slot - ctrl : ctrl-slot Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::VirtualSlotId> - the virtual LT slot number Field type <Eqpt::EqSlotId> - the equipment slot number	

Only Show Details: current and previous alarm log status		
name	Type	Description
up-overflow	Parameter type: <Alarm::up-overflow> (yes no) Possible values: - yes : up overflow alarm - no : no up overflow alarm	check LT load in upstream. <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::up-overflow> (yes no) Possible values: - yes : up overflow alarm - no : no up overflow alarm	status of specifies up overflow with its previous logged value <i>This element is only shown in detail mode.</i>
dw-overflow	Parameter type: <Alarm::dw-overflow> (yes no) Possible values: - yes : down overflow alarm - no : no down overflow alarm	check LT load in downstream. <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::dw-overflow> (yes no) Possible values: - yes : down overflow alarm - no : no down overflow alarm	status of specifies down overflow with its previous logged value <i>This element is only shown in detail mode.</i>
upobc-overflow	Parameter type: <Alarm::upobc-overflow> (yes no) Possible values: - yes : up to obc overflow alarm - no : no up to obc overflow alarm	check LT load to OBC in upstream. <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::upobc-overflow> (yes no) Possible values: - yes : up to obc overflow alarm - no : no up to obc overflow alarm	status of specifies up to obc overflow with its previous logged value <i>This element is only shown in detail mode.</i>
dwobc-overflow	Parameter type: <Alarm::dwobc-overflow> (yes	check LT load to OBC in downstream.

name	Type	Description
	no) Possible values: - yes : down to obc overflow alarm - no : no down to obc overflow alarm	<i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::dwobc-overflow> (yes no) Possible values: - yes : down to obc overflow alarm - no : no down to obc overflow alarm	status of specifies down to obc overflow with its previous logged value <i>This element is only shown in detail mode.</i>
lwpriority-overflow	Parameter type: <Alarm::lwpriority-overflow> (yes no) Possible values: - yes : alarm - no : no dying gasp alarm	check Voice and Video load. <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::lwpriority-overflow> (yes no) Possible values: - yes : alarm - no : no dying gasp alarm	status of specifies voice and video load with its previous logged value <i>This element is only shown in detail mode.</i>
fanout	Parameter type: <Alarm::fanout> (yes no) Possible values: - yes : fan out alarm - no : no fan out alarm	check LT Load. <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::fanout> (yes no) Possible values: - yes : fan out alarm - no : no fan out alarm	status of fan out with its previous logged value <i>This element is only shown in detail mode.</i>

102.58 Ellid Alarm Status Command

Command Description

This command displays the ellid current alarm status.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm log ellid [ (alarm-index) ]
```

Command Parameters

Table 102.58-1 "Ellid Alarm Status Command" Resource Parameters

Resource Identifier	Type	Description
(alarm-index)	Format: - index of a current alarm entry	alarm log table index

Command Output

Table 102.58-2 "Ellid Alarm Status Command" Display parameters

Specific Information		
name	Type	Description
last-updated-on	Parameter type: <Sys::timeInSecs> - the time (yyyy-mm-dd:hour:minutes:secs) - unit: UTC	network time in seconds when the alarm was logged. <i>This element is only shown in detail mode.</i>
ellid-index	Parameter type: <Itf::ComplexPortType> (xdsl-line : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> voicefxs : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> xdsl-channel : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> atm-if : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> atm-pvc : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::VpiId> : <Eqpt::VciId> bridge-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::VpiId> : <Eqpt::VciId>	this is the epon id for Snapshot alarms. <i>This element is only shown in detail mode.</i>

name	Type	Description
	vlan-port:ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / <Eqpt::Ng2OntSlotId> / <Eqpt::Ng2OntPortId> : <Eqpt::UnstackedVlan> l2-vlan : <Eqpt::VlanId> ip : <Eqpt::LogicalId> sw-loopback slip uni:ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / <Eqpt::Ng2OntSlotId> / <Eqpt::Ng2OntPortId> vlan-port:ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / <Eqpt::Ng2OntSlotId> / <Eqpt::Ng2OntPortId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> atm-bonding : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> bonding : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> ip-gateway : <Eqpt::VrfId> ip-line : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::VpiId> : <Eqpt::VciId> ip-line : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> shdsl-line : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> e1-line : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> atm-ima : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> ethernet-line : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> bridge-port:ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / vuni vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::VpiId> : <Eqpt::VciId> : <Eqpt::UnstackedVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::UnstackedVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::VpiId> : <Eqpt::VciId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> voip:ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> ip-line : vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::VpiId> : <Eqpt::VciId> : <Eqpt::UnstackedVlan> ip-line : vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::UnstackedVlan> ip-line : vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::VpiId> : <Eqpt::VciId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> ip-line : vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : stacked : <Eqpt::SVlan> :	

name	Type	Description
	<pre> <Eqpt::CVlan> vlan-port:ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / vuni : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan-port:ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / vuni : <Eqpt::UnstackedVlan> chgroup : <Eqpt::ChannelGroupId> subchgroup : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> bridge-port:ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / <Eqpt::Ng2OntSlotId> / <Eqpt::Ng2OntPortId> atm-pvc : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> bridge-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> bridge-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> / <Eqpt::OntPortId> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> / <Eqpt::OntPortId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> / <Eqpt::OntPortId> : <Eqpt::UnstackedVlan> pon : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> ont : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> uni : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> / <Eqpt::OntPortId> bridge-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / voip bridge-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / vuni vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / voip : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / vuni : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / voip : <Eqpt::UnstackedVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / vuni : <Eqpt::UnstackedVlan> voip : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> la-group : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / </pre>	

name	Type	Description
	<pre> <Eqpt::LLId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> bridge-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::LLId> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::LLId> : <Eqpt::UnstackedVlan> mpm : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::ComboPonId> x-pon : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::XPonId> 25g-pon : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::M25GPonId> dist-router-interface : slot-stacked : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::SVlan> : <Eqpt::CVlan> dist-router-interface : slot-vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::UnstackedVlan> bundle : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::BundleId> chpair : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::ChannelPairId> ont.ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId>) Possible values: - xdsl-line : a static xdsl line interface - xdsl-channel : a static xdsl channel interface - atm-if : a static atm interface - atm-pvc : an atm pvc interface - bridge-port : a vlan bridge-port - bridge-port.ng2 : a ngpon2 vlan bridge-port - l2-vlan : a l2-vlan interface - ip : an ip interface - sw-loopback : a software loopback interface - slip : a slip interface - atm-bonding : atm bonding obsolete alternative replaced by bonding - bonding : bonding - ip-gateway : ip user gateway interface - ip-line : ip line interface - shdsl-line : a static shdsl line interface - e1-line : a e1 line interface - atm-ima : atm ima - ethernet-line : an ethernet line interface - vlan-port : vlan port - vlan-port.ng2 : a ngpon2 vlan port - pon : pon - x-pon : xgs pon - 25g-pon : 25g pon - chpair : channelpair - chgroup : channelgroup - subchgroup : subchannelgroup - bundle : bundle - ont : ont - ont.ng2 : ngpon2 ONT style identification - uni : uni - uni.ng2 : ngpon2 UNI style identification </pre>	

102 Alarm Log Status Commands

name	Type	Description
	- voip : voip - voip:ng2 : voip - la-group : link aggregation group - dist-router-interface : dist router interface - voicefxs : voicefxs - mpm : multi-pon module Possible values: - vlan : vlan port Possible values: - slot-vlan : slot unstacked - slot-stacked : slot vlan port Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number Field type <Eqpt::VpiId> - atm VPI Field type <Eqpt::VciId> - atm VCI Field type <Eqpt::PonId> - the PON identifier Field type <Eqpt::XPonId> - the XGS PON identifier Field type <Eqpt::M25GPonId> - the 25G PON identifier Field type <Eqpt::ComboPonId> - the comboPON identifier Field type <Eqpt::ChannelPairId> - the channel pair identifier Field type <Eqpt::ChannelGroupId> - the channel group identifier Field type <Eqpt::SubChannelGroupId> - the subchannel group identifier Field type <Eqpt::BundleId> - the BUNDLE identifier Field type <Eqpt::OntId> - the ONT identifier Field type <Eqpt::Ng2OntId> - the NG2 ONT identifier Possible values: - voip : virtual uni identifier obsolete alternative replaced by vuni - vuni : virtual uni identifier Possible values: - vuni : virtual NGPON2 uni identifier Field type <Eqpt::OntSlotId> - the ONT SLOT identifier Field type <Eqpt::OntPortId> - the ONT PORT identifier Field type <Eqpt::Ng2OntSlotId> - the NGPON2 ONT SLOT identifier Field type <Eqpt::Ng2OntPortId> - the NGPON2 ONT PORT identifier	

name	Type	Description
	Field type <Eqpt::LLId> - the LLID identifier, range 1 for EPON, range 1-8 for DPOE Possible values: - stacked : stacked vlan identity Field type <Eqpt::UnstackedVlan> - unstacked vlan id Field type <Eqpt::SVlan> - service vlan id Field type <Eqpt::CVlan> - customer vlan id Field type <Eqpt::VlanId> - VLAN id Field type <Eqpt::LogicalId> - logical id Field type <Eqpt::VrflId> - VRF id	

Only Show Details: current and previous alarm log status		
name	Type	Description
key-fail-one-churn	Parameter type: <alarm::keyfailone> (yes no) Possible values: - yes : key exchange failure during one churning time - no : key exchange failure during one churning time is ok	key exchange failure during one churning time <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <alarm::keyfailone> (yes no) Possible values: - yes : key exchange failure during one churning time - no : key exchange failure during one churning time is ok	status of key fail one churn with its previous logged value <i>This element is only shown in detail mode.</i>
key-fail-three-churn	Parameter type: <alarm::keyfailthree> (yes no) Possible values: - yes : key exchange failure during three churning time - no : key exchange failure during three churning time is ok	key exchange failure during three churning time <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <alarm::keyfailthree> (yes no) Possible values: - yes : key exchange failure during three churning time - no : key exchange failure during three churning time is ok	status of key fail three churn with its previous logged value <i>This element is only shown in detail mode.</i>
oam-discov-fail	Parameter type: <alarm::oamext> (yes no) Possible values: - yes : extend oam discovery failure - no : extend oam discovery failure is ok	extend oam discovery failure <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <alarm::oamext> (yes no) Possible values: - yes : extend oam discovery failure - no : extend oam discovery failure is ok	status of extend oam fail with its previous logged value <i>This element is only shown in detail mode.</i>
report-timeout	Parameter type: <alarm::timeout> (yes no)	report timeout detecting <i>This element is only shown in detail mode.</i>

102 Alarm Log Status Commands

name	Type	Description
	Possible values: - yes : report timeout detecting - no : report timeout detecting is ok	
prev-status	Parameter type: <alarm::timeout> (yes no) Possible values: - yes : report timeout detecting - no : report timeout detecting is ok	status of report timeout with its previous logged value <i>This element is only shown in detail mode.</i>
total-packets-exceed	Parameter type: <alarm::totalexceed> (yes no) Possible values: - yes : total amount of protocol packets exceed threshold - no : total amount of protocol packets is ok	total amount of protocol packets exceed threshold <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <alarm::totalexceed> (yes no) Possible values: - yes : total amount of protocol packets exceed threshold - no : total amount of protocol packets is ok	status of total packets exceed with its previous logged value <i>This element is only shown in detail mode.</i>
arp-packets-exceed	Parameter type: <alarm::arpexceed> (yes no) Possible values: - yes : protocol arp packets exceed threshold - no : protocol arp packets is ok	protocol arp packets exceed threshold <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <alarm::arpexceed> (yes no) Possible values: - yes : protocol arp packets exceed threshold - no : protocol arp packets is ok	status of arp packets exceed with its previous logged value <i>This element is only shown in detail mode.</i>
dhcp-packets-exceed	Parameter type: <alarm::dhcpxceed> (yes no) Possible values: - yes : protocol dhcp packets exceed threshold - no : protocol dhcp packets is ok	protocol dhcp packets exceed threshold <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <alarm::dhcpxceed> (yes no) Possible values: - yes : protocol dhcp packets exceed threshold - no : protocol dhcp packets is ok	status of dhcp packets exceed with its previous logged value <i>This element is only shown in detail mode.</i>
igmp-packets-exceed	Parameter type: <alarm::igmpexceed> (yes no) Possible values: - yes : protocol igmp packets exceed threshold - no : protocol igmp packets is ok	protocol igmp packets exceed threshold <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <alarm::igmpexceed> (yes no) Possible values: - yes : protocol igmp packets exceed threshold - no : protocol igmp packets is ok	status of igmp packets exceed with its previous logged value <i>This element is only shown in detail mode.</i>

name	Type	Description
pppoe-packets-exceed	Parameter type: <alarm::pppoeexceed> (yes no) Possible values: - yes : protocol pppoe packets exceed threshold - no : protocol pppoe packets is ok	protocol pppoe packets exceed threshold <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <alarm::pppoeexceed> (yes no) Possible values: - yes : protocol pppoe packets exceed threshold - no : protocol pppoe packets is ok	status of pppoe packets exceed with its previous logged value <i>This element is only shown in detail mode.</i>
nd-packets-exceed	Parameter type: <alarm::ndexceed> (yes no) Possible values: - yes : protocol nd packets exceed threshold - no : protocol nd packets is ok	protocol nd packets exceed threshold <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <alarm::ndexceed> (yes no) Possible values: - yes : protocol nd packets exceed threshold - no : protocol nd packets is ok	status of nd packets exceed with its previous logged value <i>This element is only shown in detail mode.</i>
icmpv6-packets-exceed	Parameter type: <alarm::icmpexceed> (yes no) Possible values: - yes : protocol icmp packets exceed threshold - no : protocol icmp packets is ok	protocol icmpv6 packets exceed threshold <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <alarm::icmpexceed> (yes no) Possible values: - yes : protocol icmp packets exceed threshold - no : protocol icmp packets is ok	status of icmp packets exceed with its previous logged value <i>This element is only shown in detail mode.</i>
mld-packets-exceed	Parameter type: <alarm::mldexceed> (yes no) Possible values: - yes : protocol igmp packets exceed threshold - no : protocol igmp packets is ok	protocol mld packets exceed threshold <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <alarm::mldexceed> (yes no) Possible values: - yes : protocol igmp packets exceed threshold - no : protocol igmp packets is ok	status of mld packets exceed with its previous logged value <i>This element is only shown in detail mode.</i>
dhcpv6-packets-exceed	Parameter type: <alarm::dhcpv6exceed> (yes no) Possible values: - yes : protocol dhcpv6 packets exceed threshold - no : protocol dhcpv6 packets is ok	protocol dhcpv6 packets exceed threshold <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <alarm::dhcpv6exceed> (yes no)	status of dhcpv6 packets exceed with its previous logged value <i>This element is only shown in detail mode.</i>

102 Alarm Log Status Commands

name	Type	Description
	Possible values: - yes : protocol dhcpv6 packets exceed threshold - no : protocol dhcpv6 packets is ok	<i>detail mode.</i>
cfm-packets-exceed	Parameter type: <alarm::cfmexceed> (yes no) Possible values: - yes : protocol cfm packets exceed threshold - no : protocol cfm packets is ok	protocol cfm packets exceed threshold <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <alarm::cfmexceed> (yes no) Possible values: - yes : protocol cfm packets exceed threshold - no : protocol cfm packets is ok	status of cfm packets exceed with its previous logged value <i>This element is only shown in detail mode.</i>

102.59 Alarm Qos Queue Log Status Commands

Command Description

This command displays the Qos Queue alarm log status.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm log qos-queue [ (index) ]
```

Command Parameters

Table 102.59-1 "Alarm Qos Queue Log Status Commands" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm log table index

Command Output

Table 102.59-2 "Alarm Qos Queue Log Status Commands" Display parameters

Specific Information		
name	Type	Description
last-updated-on	Parameter type: <Sys::timeInSecs> - the time (yyyy-mm-dd:hour:minutes:secs) - unit: UTC	network time in seconds when the alarm was logged. <i>This element is always shown.</i>
port	Parameter type: <Itf::PhyLine> (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> / <Eqpt::OntPortId> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / voip <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / vuni ont : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> ont.ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> uni.ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId>	identifies the physical position of the port <i>This element is always shown.</i>

102 Alarm Log Status Commands

name	Type	Description
	<code><Eqpt::Ng2OntSlotId> / <Eqpt::Ng2OntPortId></code> <code> uni.ng2 : <Eqpt::ChannelGroupId> /</code> <code><Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / vuni)</code> Possible values: - ont : ont - ont.ng2 : ngpon2 ONT style identification - uni.ng2 : ngpon2 UNI style identification Field type <code><Eqpt::RackId></code> - the rack number Field type <code><Eqpt::ShelfId></code> - the shelf number Field type <code><Eqpt::SlotId></code> - the LT slot number Field type <code><Eqpt::PortId></code> - the port number Field type <code><Eqpt::PonId></code> - the PON identifier Field type <code><Eqpt::OntId></code> - the ONT identifier Field type <code><Eqpt::ChannelGroupId></code> - the channel group identifier Field type <code><Eqpt::SubChannelGroupId></code> - the subchannel group identifier Field type <code><Eqpt::Ng2OntId></code> - the NG2 ONT identifier Possible values: - voip : virtual uni identifier obsolete alternative replaced by vuni - vuni : virtual uni identifier Possible values: - vuni : virtual NGPON2 uni identifier Field type <code><Eqpt::OntSlotId></code> - the ONT SLOT identifier Field type <code><Eqpt::OntPortId></code> - the ONT PORT identifier Field type <code><Eqpt::Ng2OntSlotId></code> - the NGPON2 ONT SLOT identifier Field type <code><Eqpt::Ng2OntPortId></code> - the NGPON2 ONT PORT identifier	
queue	Parameter type: <code><Qos::AlarmQueues></code> - identify where the alarm has occurred - range: [0...7]	identify where the alarm has occurred. <i>This element is always shown.</i>

Only Show Details: current and previous alarm log status		
name	Type	Description
queue-discard-overflow	Parameter type: <code><Alarm::queue-discard-overflow></code> (yes no) Possible values: - yes : queue discard alarm - no : no queue discard alarm	check the corresponding queue discard overflow. <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <code><Alarm::queue-discard-overflow></code> (yes no) Possible values: - yes : queue discard alarm - no : no queue discard alarm	status of specifies queue discard overflow with its previous logged value <i>This element is only shown in detail mode.</i>
queue-load	Parameter type: <code><Alarm::queue-load></code>	check the corresponding queue

name	Type	Description
	(yes no) Possible values: - yes : queue load alarm - no : no queue load alarm	Load. <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::queue-load> (yes no) Possible values: - yes : queue load alarm - no : no queue load alarm	status of queue load with its previous logged value <i>This element is only shown in detail mode.</i>
queue-peak-usage	Parameter type: <Alarm::queue-peak-usage> (yes no) Possible values: - yes : queue peak usage alarm - no : no queue peak usage alarm	check the corresponding queue peak usage. <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::queue-peak-usage> (yes no) Possible values: - yes : queue peak usage alarm - no : no queue peak usage alarm	status of queue peak usage with its previous logged value <i>This element is only shown in detail mode.</i>

102.60 Log File Transfer Server Alarm Log Status Command

Command Description

This command displays the log status of the file transfer server alarm.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

> show alarm log filetransfer [(index)]

Command Parameters

Table 102.60-1 "Log File Transfer Server Alarm Log Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm log table index

Command Output

Table 102.60-2 "Log File Transfer Server Alarm Log Status Command" Display parameters

Specific Information		
name	Type	Description
last-updated-on	Parameter type: <Sys::timeInSecs> - the time (yyyy-mm-dd:hour:minutes:secs) - unit: UTC	network time in seconds when the alarm was logged. <i>This element is only shown in detail mode.</i>
server-id	Parameter type: <Alarm::FileTransfer> - next hop IP address	this is the server id for file server alarms <i>This element is only shown in detail mode.</i>
fileserv-unavail	Parameter type: <Alarm::FileTransferUnavail> (unavailable available) Possible values: - unavailable : file transfer Server unavailable or file transfer failed - available : file transfer server available	current status specifying that whether file transfer server available <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::relayNotSet>	status of relay with its previous

name	Type	Description
	(yes no) Possible values: - yes : wrong appliq - no : right appliq	logged value <i>This element is only shown in detail mode.</i>

102.61 Log Lsm Redundancy Alarm Log Status Command

Command Description

This command displays the log status of the Lsm Redundancy alarm.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

> show alarm log lsmredundancy [(index)]

Command Parameters

Table 102.61-1 "Log Lsm Redundancy Alarm Log Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm log table index

Command Output

Table 102.61-2 "Log Lsm Redundancy Alarm Log Status Command" Display parameters

Specific Information		
name	Type	Description
last-updated-on	Parameter type: <Sys::timeInSecs> - the time (yyyy-mm-dd:hour:minutes:secs) - unit: UTC	network time in seconds when the alarm was logged. <i>This element is only shown in detail mode.</i>
board-station	Parameter type: <Equipm::LtSlotIndex> (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId>) Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number	this is the physical number of the slot for lsm redundancy alarms <i>This element is only shown in detail mode.</i>
loss-lsmswp-cap	Parameter type: <Alarm::SwoCap> (loss not-loss)	current status specifying the switchover capability in a redundant system

name	Type	Description
	Possible values: - loss : system loss of the swichover capability - not-loss : system not loss of the swichover capability	<i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::SwoCap> (loss not-loss) Possible values: - loss : system loss of the swichover capability - not-loss : system not loss of the swichover capability	prev status specifying the swichover capability in a redundant system <i>This element is only shown in detail mode.</i>
data-xvps-diff	Parameter type: <Alarm::DataXvps> (invalid valid) Possible values: - invalid : data of xvps pair is not the same - valid : data of xvps pair is same	log status of the data of xvps pair <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::DataXvps> (invalid valid) Possible values: - invalid : data of xvps pair is not the same - valid : data of xvps pair is same	prev status of the data of xvps pair <i>This element is only shown in detail mode.</i>

102.62 Log L2 Forward Alarm Log Status Command

Command Description

This command displays the log status of the l2 forward alarm.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm log l2forward [ (index) ]
```

Command Parameters

Table 102.62-1 "Log L2 Forward Alarm Log Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm log table index

Command Output

Table 102.62-2 "Log L2 Forward Alarm Log Status Command" Display parameters

Specific Information		
name	Type	Description
last-updated-on	Parameter type: <Sys::timeInSecs> - the time (yyyy-mm-dd:hour:minutes:secs) - unit: UTC	network time in seconds when the alarm was logged. <i>This element is only shown in detail mode.</i>
bridgeport	Parameter type: <Vlan::BridgePort> (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::VpiId> : <Eqpt::VciId> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> / <Eqpt::OntPortId> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / voip <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / vuni	identify the bridge port where the alarm has occurred. <i>This element is only shown in detail mode.</i>

name	Type	Description
	<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::LLId> ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Ng2::OntId> / <Eqpt::Ng2OntSlotId> / <Eqpt::Ng2OntPortId> ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Ng2::OntId> / vuni) Possible values: - ng2 : ngpon2 vlan bridge port Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number Field type <Eqpt::VpiId> - atm VPI Field type <Eqpt::VciId> - atm VCI Field type <Eqpt::PonId> - the PON identifier Field type <Eqpt::ChannelGroupId> - the channel group identifier Field type <Eqpt::SubChannelGroupId> - the subchannel group identifier Field type <Eqpt::OntId> - the ONT identifier Field type <Ng2::OntId> - the ONT identifier Possible values: - voip : virtual uni identifier obsolete alternative replaced by vuni - vuni : virtual uni identifier Possible values: - vuni : virtual NGPON2 uni identifier Field type <Eqpt::OntSlotId> - the ONT SLOT identifier Field type <Eqpt::OntPortId> - the ONT PORT identifier Field type <Eqpt::Ng2OntSlotId> - the NGPON2 ONT SLOT identifier Field type <Eqpt::Ng2OntPortId> - the NGPON2 ONT PORT identifier Field type <Eqpt::LLId> - the LLID identifier, range 1 for EPON, range 1-8 for DPOE	
vlan-id	Parameter type: <Vlan::StackedVlanSigned> (<Vlan::UVlanIndex> stacked : <Vlan::SVlanIndex> : <Vlan::CVlanIndex>) Possible values: - stacked : stacked vlan identity Field type <Vlan::UVlanIndex> - unstacked vlan identity - range: [1...4093,4096] Field type <Vlan::SVlanIndex> - service vlan identity	identify the vlan id where the alarm has occurred. <i>This element is only shown in detail mode.</i>

102 Alarm Log Status Commands

name	Type	Description
	- range: [2...4093,4094] Field type <Vlan::CVlanIndex> - customer vlan identity - range: [0...4093,4094,4095,4096]	
mac-conflict	Parameter type: <Alarm::MACconflict> (yes no) Possible values: - yes : duplicate mac address from this bridge port - no : no duplicate mac address from this bridge port	specifies whether duplicate mac address from the Bridge port. <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::MACconflict> (yes no) Possible values: - yes : duplicate mac address from this bridge port - no : no duplicate mac address from this bridge port	status of mac-conflict with its previous logged value. <i>This element is only shown in detail mode.</i>
vmac-full	Parameter type: <Alarm::VMACFull> (yes no) Possible values: - yes : virtual mac entry full on this bridge port - no : no virtual mac entry full on this bridge port	specifies whether virtual mac is full on the bridge port. <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::VMACFull> (yes no) Possible values: - yes : virtual mac entry full on this bridge port - no : no virtual mac entry full on this bridge port	status of vmac-full with its previous logged value. <i>This element is only shown in detail mode.</i>

102.63 External Device Alarm Log Status Command

Command Description

This command displays the external-device alarm log status.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

> show alarm log external-device [(index)]

Command Parameters

Table 102.63-1 "External Device Alarm Log Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm log table index

Command Output

Table 102.63-2 "External Device Alarm Log Status Command" Display parameters

Specific Information		
name	Type	Description
last-updated-on	Parameter type: <Sys::timeInSecs> - the time (yyyy-mm-dd:hour:minutes:secs) - unit: UTC	network time in seconds when the alarm was logged. <i>This element is only shown in detail mode.</i>
loss-env-mon	Parameter type: <Alarm::LossEnvMon> (lost not-lost) Possible values: - lost : env-mon box lost or not alive - not-lost : env-mon box exists	status of env-monitor box <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::LossEnvMon> (lost not-lost) Possible values: - lost : env-mon box lost or not alive - not-lost : env-mon box exists	status of loss-env-mon with its previous logged value <i>This element is only shown in detail mode.</i>

102.64 Multicast Source Alarm Log Status Command

Command Description

This command displays the multicast source alarm log status.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm log msrc [ (index) ]
```

Command Parameters

Table 102.64-1 "Multicast Source Alarm Log Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm log table index

Command Output

Table 102.64-2 "Multicast Source Alarm Log Status Command" Display parameters

Specific Information		
name	Type	Description
last-updated-on	Parameter type: <Sys::timeInSecs> - the time (yyyy-mm-dd:hour:minutes:secs) - unit: UTC	network time in seconds when the alarm was logged. <i>This element is only shown in detail mode.</i>
grp-ip-addr	Parameter type: <Alarm::IpAddress> - IPv4-address	identify the mcast address where the alarm has occurred. <i>This element is only shown in detail mode.</i>
slot-id	Parameter type: <Equipm::FullLtSlotIndex> lt : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> Possible values: - lt : lt-slot Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number	identify where the alarm has occurred. <i>This element is only shown in detail mode.</i>

102 Alarm Log Status Commands

name	Type	Description
	Field type <Eqpt::SlotId> - the LT slot number	

Only Show Details: current and previous alarm log status		
name	Type	Description
stream-lost	Parameter type: <Alarm::McastLoss> (yes no) Possible values: - yes : pon mcast video stream lost - no : pon mcast video stream not lost	current status of the alarm specifying if the pon mcast video stream is lost or not <i>This element is only shown in detail mode.</i>
prev-stream-lost	Parameter type: <Alarm::McastLoss> (yes no) Possible values: - yes : pon mcast video stream lost - no : pon mcast video stream not lost	status of stream-lost alarm with its previous logged value. <i>This element is only shown in detail mode.</i>

102.65 Vlanport Alarm Log Status Command

Command Description

This command displays the vlanport alarm log status.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm log vlanport [ (index) ]
```

Command Parameters

Table 102.65-1 "Vlanport Alarm Log Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm log table index

Command Output

Table 102.65-2 "Vlanport Alarm Log Status Command" Display parameters

Specific Information		
name	Type	Description
last-updated-on	Parameter type: <Sys::timeInSecs> - the time (yyyy-mm-dd:hour:minutes:secs) - unit: UTC	network time in seconds when the alarm was logged. <i>This element is only shown in detail mode.</i>
vlanport	Parameter type: <Itf::VlanPortInterface> (vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::VpiId> : <Eqpt::VciId> : <Eqpt::UnstackedVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::UnstackedVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::VpiId> : <Eqpt::VciId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> / <Eqpt::OntPortId> : stacked :	identify the provisioned vlanport where the alarm has occurred. <i>This element is only shown in detail mode.</i>

name	Type	Description
	<pre> <Eqpt::SVlan> : <Eqpt::CVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> / <Eqpt::OntPortId> : <Eqpt::UnstackedVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / voip : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / vuni : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / voip : <Eqpt::UnstackedVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / vuni : <Eqpt::UnstackedVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::LLId> : <Eqpt::UnstackedVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::LLId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan-port:ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Ng2::OntId> / <Eqpt::Ng2OntSlotId> / <Eqpt::Ng2OntPortId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan-port:ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Ng2::OntId> / <Eqpt::Ng2OntSlotId> / <Eqpt::Ng2OntPortId> : <Eqpt::UnstackedVlan> vlan-port:ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Ng2::OntId> / vuni : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan-port:ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Ng2::OntId> / vuni : <Eqpt::UnstackedVlan>) Possible values: - vlan-port : vlan port - vlan-port:ng2 : ngpon2 vlan port Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number Field type <Eqpt::Vpild> - atm VPI Field type <Eqpt::VciId> - atm VCI Field type <Eqpt::PonId> - the PON identifier Field type <Eqpt::OntId> - the ONT identifier Field type <Eqpt::ChannelGroupId> </pre>	

name	Type	Description
	- the channel group identifier Field type <Eqpt::SubChannelGroupId> - the subchannel group identifier Field type <Ng2::OntId> - the ONT identifier Possible values: - voip : virtual uni identifier obsolete alternative replaced by vuni - vuni : virtual uni identifier - Possible values: - vuni : virtual NGPON2 uni identifier - Field type <Eqpt::OntSlotId> - the ONT SLOT identifier Field type <Eqpt::OntPortId> - the ONT PORT identifier Field type <Eqpt::Ng2OntSlotId> - the NGPON2 ONT SLOT identifier Field type <Eqpt::Ng2OntPortId> - the NGPON2 ONT PORT identifier Field type <Eqpt::LLId> - the LLID identifier,range 1 for EPON,range 1-8 for DPOE - Possible values: - stacked : stacked vlan identity - Field type <Eqpt::UnstackedVlan> - unstacked vlan id Field type <Eqpt::SVlan> - service vlan id Field type <Eqpt::CVlan> - customer vlan id	
svc-mismatch	Parameter type: <Alarm::SVCMismatch> (yes no) Possible values: - yes : configuration request not accepted - no : configuration accepted	current status of the alarm specifying if the configuration for a provisioned vlanport is accepted or not. <i>This element is only shown in detail mode.</i>
prev-svc-mismatch	Parameter type: <Alarm::SVCMismatch> (yes no) Possible values: - yes : configuration request not accepted - no : configuration accepted	status of svc-mismatch alarm with its previous logged value. <i>This element is only shown in detail mode.</i>

102.66 BGP Alarm Log Status Command

Command Description

This command displays the bgp alarm log status.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm log bgp [ (index) ]
```

Command Parameters

Table 102.66-1 "BGP Alarm Log Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm log table index

Command Output

Table 102.66-2 "BGP Alarm Log Status Command" Display parameters

Specific Information		
name	Type	Description
last-updated-on	Parameter type: <Sys::timeInSecs> - the time (yyyy-mm-dd:hour:minutes:secs) - unit: UTC	network time in seconds when the alarm was logged <i>This element is only shown in detail mode.</i>
router-id	Parameter type: <Ihub::Router> (base <Ihub::Router>) Possible values: - base : base router Field type <Ihub::Router> - vprn service-id - range: [1...2147483647]	identifies the vprn service-id or the base router where the alarm has occurred. <i>This element is only shown in detail mode.</i>
neighbor-idx	Parameter type: <Alarm::AlarmIdentifIdxOrZero> - an unsigned integer	unique reference for the neighbor where the alarm occurred or zero when not applicable, neighbor is further specified in additional-info <i>This element is only shown in detail mode.</i>

name	Type	Description
additional-info	Parameter type: <Alarm::AddInfoString> - additional alarm information	identifies the neighbor where the alarm occurred or empty string if not applicable. <i>This element is only shown in detail mode.</i>

Only Show Details: current and previous alarm log status		
name	Type	Description
peer-down	Parameter type: <Alarm::PeerDown> (yes no) Possible values: - yes : operational state down - no : operational state up	specifies whether the BGP peer operational state is up or down <i>This element is only shown in detail mode.</i>
prev-peer-down	Parameter type: <Alarm::PeerDown> (yes no) Possible values: - yes : operational state down - no : operational state up	status of peer-down with its previous logged value <i>This element is only shown in detail mode.</i>
routes-mid-limit	Parameter type: <Alarm::RoutesMidLimit> (reached not-reached) Possible values: - reached : reached: 90% of max allowed routes learned - not-reached : less than 90% of max allowed routes learned	specifies whether 90% of the max nbr of routes BGP can learn from a peer is reached or not <i>This element is only shown in detail mode.</i>
prev-routes-mid-limit	Parameter type: <Alarm::RoutesMidLimit> (reached not-reached) Possible values: - reached : reached: 90% of max allowed routes learned - not-reached : less than 90% of max allowed routes learned	status of routes-mid-limit with its previous logged value <i>This element is only shown in detail mode.</i>

102.67 RIP Alarm Log Status Command

Command Description

This command displays the rip alarm log status.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm log rip [ (index) ]
```

Command Parameters

Table 102.67-1 "RIP Alarm Log Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm log table index

Command Output

Table 102.67-2 "RIP Alarm Log Status Command" Display parameters

Specific Information		
name	Type	Description
last-updated-on	Parameter type: <Sys::timeInSecs> - the time (yyyy-mm-dd:hour:minutes:secs) - unit: UTC	network time in seconds when the alarm was logged <i>This element is only shown in detail mode.</i>
router-id	Parameter type: <Ihub::Router> (base <Ihub::Router>) Possible values: - base : base router Field type <Ihub::Router> - vprn service-id - range: [1...2147483647]	identifies the vprn service-id or the base router where the alarm has occurred <i>This element is only shown in detail mode.</i>
Only Show Details: current and previous alarm log status		
name	Type	Description
instance-down	Parameter type: <Alarm::InstanceDown> (yes no) Possible values: - yes : RIP instance down	specifies whether RIP instance is down or not <i>This element is only shown in detail mode.</i>

name	Type	Description
	- no : RIP instance up	
prev-instance-down	Parameter type: <Alarm::InstanceDown> (yes no) Possible values: - yes : RIP instance down - no : RIP instance up	status of instance-down with its previous logged value <i>This element is only shown in detail mode.</i>

102.68 LAG Alarm Log Status Command

Command Description

This command displays the lag alarm log status.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm log lag [ (index) ]
```

Command Parameters

Table 102.68-1 "LAG Alarm Log Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm log table index

Command Output

Table 102.68-2 "LAG Alarm Log Status Command" Display parameters

Specific Information		
name	Type	Description
last-updated-on	Parameter type: <Sys::timeInSecs> - the time (yyyy-mm-dd:hour:minutes:secs) - unit: UTC	network time in seconds when the alarm was logged <i>This element is only shown in detail mode.</i>
lag-id	Parameter type: <Alarm::LagId> - link aggregation group id - range: [1...64]	Identifies the lag where the alarm has occurred <i>This element is only shown in detail mode.</i>
sub-group	Parameter type: <Alarm::AlarmIdentifIdxOrZero> - an unsigned integer	Identifies the subgroup for which the alarm has occurred or zero when not applicable. <i>This element is only shown in detail mode.</i>

Only Show Details: current and previous alarm log status		
name	Type	Description
lag-down	Parameter type: <Alarm::EthLagDown> (yes no) Possible values:	specifies whether the link aggregation group is down or not <i>This element is only shown in detail mode.</i>

name	Type	Description
	- yes : lag down - no : lag not down	
prev-lag-down	Parameter type: <Alarm::EthLagDown> (yes no) Possible values: - yes : lag down - no : lag not down	status of lag-down with its previous logged value <i>This element is only shown in detail mode.</i>
subgrp-thres-reach	Parameter type: <Alarm::LagSubgrpThresReach> (reached not-reached) Possible values: - reached : sub-group threshold reached - not-reached : sub-group threshold not reached	specifies whether the lag subgroup threshold is reached or not <i>This element is only shown in detail mode.</i>
prev-subgrp-thres-rch	Parameter type: <Alarm::LagSubgrpThresReach> (reached not-reached) Possible values: - reached : sub-group threshold reached - not-reached : sub-group threshold not reached	status of subgrp-thres-reach with its previous logged value <i>This element is only shown in detail mode.</i>
subgrp-switch-fail	Parameter type: <Alarm::LagSubgrpSwitchFail> (yes no) Possible values: - yes : lag subgroup switchover failed - no : lag subgroup switchover did not fail	specifies whether the lag subgroup switchover failed or not <i>This element is only shown in detail mode.</i>
prev-subgrp-swth-fail	Parameter type: <Alarm::LagSubgrpSwitchFail> (yes no) Possible values: - yes : lag subgroup switchover failed - no : lag subgroup switchover did not fail	status of subgrp-switch-fail with its previous logged value <i>This element is only shown in detail mode.</i>
nofree-port-inbase	Parameter type: <Alarm::LagNoUnpinFreePorts> (yes no) Possible values: - yes : No free ports available for un pinned traffic - no : free ports available for un pinned traffic	specifies whether the free ports available for unpinned traffic or not <i>This element is only shown in detail mode.</i>
prev-nofree-port-inbse	Parameter type: <Alarm::LagNoUnpinFreePorts> (yes no) Possible values: - yes : No free ports available for un pinned traffic - no : free ports available for un pinned traffic	status of LagNoUnpinFreePorts with its previous logged value <i>This element is only shown in detail mode.</i>

102.69 ihub-general Alarm Log Status Command

Command Description

This command displays the ihub-general alarm log status.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

> show alarm log ihub-general [(index)]

Command Parameters

Table 102.69-1 "ihub-general Alarm Log Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm log table index

Command Output

Table 102.69-2 "ihub-general Alarm Log Status Command" Display parameters

Specific Information		
name	Type	Description
last-updated-on	Parameter type: <Sys::timeInSecs> - the time (yyyy-mm-dd:hour:minutes:secs) - unit: UTC	network time in seconds when the alarm was logged <i>This element is only shown in detail mode.</i>
Only Show Details: current and previous alarm log status		
name	Type	Description
arp-limit	Parameter type: <Alarm::ArpLimit> (reached not-reached) Possible values: - reached : ARP tbl threshold reached or exceeded - not-reached : ARP tbl entries below threshold	specifies whether the nbr of ARP entries has reached the max threshold or not <i>This element is only shown in detail mode.</i>
prev-arp-limit	Parameter type: <Alarm::ArpLimit> (reached not-reached) Possible values: - reached : ARP tbl threshold reached or exceeded - not-reached : ARP tbl entries below threshold	status of arp-limit with its previous logged value <i>This element is only shown in detail mode.</i>
switch-out-of-res	Parameter type: <Alarm::IhubSwitchOutOfResource>	specifies whether e.g. storing a

name	Type	Description
	(yes no) Possible values: - yes : lack of resources in switch - no : no resource issues detected	configuration in the hardware has failed or not, due to a lack of resources in the switch. <i>This element is only shown in detail mode.</i>
prev-switch-out-of-res	Parameter type: <Alarm::IhubSwitchOutOfResource> (yes no) Possible values: - yes : lack of resources in switch - no : no resource issues detected	status of switch-out-of-res with its previous logged value <i>This element is only shown in detail mode.</i>
ipv6-nc-limit	Parameter type: <Alarm::IPv6NeighborCacheLimit> (reached not-reached) Possible values: - reached : neighbor cache up threshold reached - not-reached : neighbor cache entries within limit	specifies whether the number of ipv6 neighbor cache entries reached maximum threshold or not. <i>This element is only shown in detail mode.</i>
prev-ipv6-nc-limit	Parameter type: <Alarm::IPv6NeighborCacheLimit> (reached not-reached) Possible values: - reached : neighbor cache up threshold reached - not-reached : neighbor cache entries within limit	status of ipv6-nc-limit with its previous logged value <i>This element is only shown in detail mode.</i>
dhcp-session-oor	Parameter type: <Alarm::DhcpSessionOutOfResource> (yes no) Possible values: - yes : lack of resources for dhcp - no : no resource issues detected for dhcp	specifies whether dhcp session is out of resources or not. <i>This element is only shown in detail mode.</i>
prev-dhcp-session-oor	Parameter type: <Alarm::DhcpSessionOutOfResource> (yes no) Possible values: - yes : lack of resources for dhcp - no : no resource issues detected for dhcp	status of dhcp-session-oor with its previous logged value <i>This element is only shown in detail mode.</i>
fdb-limit	Parameter type: <Alarm::IhubL2FdbFull> (reached not-reached) Possible values: - reached : layer 2 fdb table entries reached upper threshold for the node - not-reached : layer 2 fdb table entries within limit for the node	specifies whether the number of layer 2 fdb table entries reached maximum threshold or not. <i>This element is only shown in detail mode.</i>
prev-fdb-limit	Parameter type: <Alarm::IhubL2FdbFull> (reached not-reached) Possible values: - reached : layer 2 fdb table entries reached upper threshold for the node - not-reached : layer 2 fdb table entries within limit for the node	status of fdb-limit with its previous logged value <i>This element is only shown in detail mode.</i>
mac-limit	Parameter type: <Alarm::IhubL2MacFull> (reached not-reached) Possible values: - reached : Internal Mac entries reached upper - not-reached : Internal Mac entries within limit	specifies whether the number of internal Mac entries reached maximum threshold or not. <i>This element is only shown in detail mode.</i>

102 Alarm Log Status Commands

name	Type	Description
prev-mac-limit	Parameter type: <Alarm::IhubL2MacFull> (reached not-reached) Possible values: - reached : Internal Mac entries reached upper - not-reached : Internal Mac entries within limit	status of mac-limit with its previous logged value <i>This element is only shown in detail mode.</i>

102.70 VPRN Alarm Log Status Command

Command Description

This command displays the vprn alarm log status.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm log vprn [ (index) ]
```

Command Parameters

Table 102.70-1 "VPRN Alarm Log Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm log table index

Command Output

Table 102.70-2 "VPRN Alarm Log Status Command" Display parameters

Specific Information		
name	Type	Description
last-updated-on	Parameter type: <Sys::timeInSecs> - the time (yyyy-mm-dd:hour:minutes:secs) - unit: UTC	network time in seconds when the alarm was logged <i>This element is only shown in detail mode.</i>
router-id	Parameter type: <Ihub::Router> (base <Ihub::Router>) Possible values: - base : base router Field type <Ihub::Router> - vprn service-id - range: [1...2147483647]	identifies the vprn service-id or the base router where the alarm has occurred. <i>This element is only shown in detail mode.</i>
if-index	Parameter type: <Alarm::IdentificationIdxOrZero> - a signed integer	unique reference for the interface for which the alarm occurred or zero when not applicable. <i>This element is only shown in detail mode.</i>
interface	Parameter type: <Alarm::AddInfoString> - additional alarm information	identifies the interface for which the alarm occurred or empty

102 Alarm Log Status Commands

name	Type	Description
		string if not applicable. <i>This element is only shown in detail mode.</i>

Only Show Details: current and previous alarm log status		
name	Type	Description
routes-limit	Parameter type: <Alarm::RoutesLimit> (reached not-reached) Possible values: - reached : ip routes limit reached or exceeded - not-reached : ip routes within limit	specifies whether the limit of dynamic routes is reached/exceeded or not <i>This element is only shown in detail mode.</i>
prev-routes-limit	Parameter type: <Alarm::RoutesLimit> (reached not-reached) Possible values: - reached : ip routes limit reached or exceeded - not-reached : ip routes within limit	status of routes-limit with its previous logged value <i>This element is only shown in detail mode.</i>
ipv6-routes-limit	Parameter type: <Alarm::IPv6RoutesLimit> (reached not-reached) Possible values: - reached : ipv6 routes limit reached or exceeded - not-reached : ipv6 routes within limit	specifies whether the number of dynamic ipv6 routes is approaching or has reached its limit <i>This element is only shown in detail mode.</i>
prev-ipv6-routes-limit	Parameter type: <Alarm::IPv6RoutesLimit> (reached not-reached) Possible values: - reached : ipv6 routes limit reached or exceeded - not-reached : ipv6 routes within limit	status of ipv6-routes-limit with its previous logged value <i>This element is only shown in detail mode.</i>
dhcpv6-lease-limit	Parameter type: <Alarm::DHCPV6LeaseLimit> (reached not-reached) Possible values: - reached : dhcpv6 relay leases limit reached or exceeded - not-reached : dhcpv6 relay leases within limit	specifies whether the limit of dhcpv6 relay leases is reached or not <i>This element is only shown in detail mode.</i>
prev-dhcpv6-lease-limit	Parameter type: <Alarm::DHCPV6LeaseLimit> (reached not-reached) Possible values: - reached : dhcpv6 relay leases limit reached or exceeded - not-reached : dhcpv6 relay leases within limit	status of dhcpv6-lease-limit with its previous logged value <i>This element is only shown in detail mode.</i>
dhcpv4-lease-limit	Parameter type: <Alarm::DHCPV4LeaseLimit> (reached not-reached) Possible values: - reached : dhcpv4 relay leases limit reached or exceeded - not-reached : dhcpv4 relay leases within limit	specifies whether the limit of dhcpv4 relay leases is reached or not <i>This element is only shown in detail mode.</i>
prev-dhcpv4-lease-limit	Parameter type: <Alarm::DHCPV4LeaseLimit> (reached not-reached) Possible values: - reached : dhcpv4 relay leases limit reached or exceeded - not-reached : dhcpv4 relay leases within limit	status of dhcpv4-lease-limit with its previous logged value <i>This element is only shown in detail mode.</i>

102.71 ISIS Alarm Log Status Command

Command Description

This command displays the isis alarm log status.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm log isis [ (index) ]
```

Command Parameters

Table 102.71-1 "ISIS Alarm Log Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm log table index

Command Output

Table 102.71-2 "ISIS Alarm Log Status Command" Display parameters

Specific Information		
name	Type	Description
last-updated-on	Parameter type: <Sys::timeInSecs> - the time (yyyy-mm-dd:hour:minutes:secs) - unit: UTC	network time in seconds when the alarm was logged <i>This element is only shown in detail mode.</i>
router-id	Parameter type: <Ihub::Router> (base <Ihub::Router>) Possible values: - base : base router Field type <Ihub::Router> - vprn service-id - range: [1...2147483647]	identifies the vprn service-id or the base router where the alarm has occurred <i>This element is only shown in detail mode.</i>
adjacency-index	Parameter type: <Alarm::IdentificationIdxOrZero> - a signed integer	unique reference for the adjacency where the alarm occurred or zero when not applicable, adjacency is further specified in additional-info <i>This element is only shown in detail mode.</i>

102 Alarm Log Status Commands

name	Type	Description
additional-info	Parameter type: <Alarm::AddInfoString> - additional alarm information	identifies the adjacency:instance/interface where the alarm occurred or empty string if not applicable. <i>This element is only shown in detail mode.</i>

Only Show Details: current and previous alarm log status		
name	Type	Description
adjacency-down	Parameter type: <Alarm::AdjacencyDown> (yes no) Possible values: - yes : interface down - no : interface up	specifies whether isis adjacency is down or not <i>This element is only shown in detail mode.</i>
prev-adjacency-down	Parameter type: <Alarm::AdjacencyDown> (yes no) Possible values: - yes : interface down - no : interface up	status of adjacency-down with its previous logged value <i>This element is only shown in detail mode.</i>
adjacency-reject	Parameter type: <Alarm::AdjacencyReject> (yes no) Possible values: - yes : interface mismatch - no : no interface mismatch	specifies whether isis adjacency is rejected or not <i>This element is only shown in detail mode.</i>
prev-adjacency-reject	Parameter type: <Alarm::AdjacencyReject> (yes no) Possible values: - yes : interface mismatch - no : no interface mismatch	status of adjacency-reject with its previous logged value <i>This element is only shown in detail mode.</i>
instance-down	Parameter type: <Alarm::IsisDown> (yes no) Possible values: - yes : ISIS instance down - no : ISIS instance up	specifies whether ISIS instance is down or not <i>This element is only shown in detail mode.</i>
prev-instance-down	Parameter type: <Alarm::IsisDown> (yes no) Possible values: - yes : ISIS instance down - no : ISIS instance up	status of instance-down with its previous logged value <i>This element is only shown in detail mode.</i>

102.72 Ospf Alarm Log Status Command

Command Description

This command displays the ospf alarm log status.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm log ospf [ (index) ]
```

Command Parameters

Table 102.72-1 "Ospf Alarm Log Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm log table index

Command Output

Table 102.72-2 "Ospf Alarm Log Status Command" Display parameters

Specific Information		
name	Type	Description
last-updated-on	Parameter type: <Sys::timeInSecs> - the time (yyyy-mm-dd:hour:minutes:secs) - unit: UTC	network time in seconds when the alarm was logged <i>This element is only shown in detail mode.</i>
router-id	Parameter type: <Ihub::Router> (base <Ihub::Router>) Possible values: - base : base router Field type <Ihub::Router> - vprn service-id - range: [1...2147483647]	identifies the vprn service-id or the base router where the alarm has occurred. <i>This element is only shown in detail mode.</i>
neighbor-idx	Parameter type: <Alarm::IdentificationIdxOrZero> - a signed integer	unique reference for the neighbor where the alarm occurred or zero when not applicable, neighbor is further specified in additional-info <i>This element is only shown in detail mode.</i>

102 Alarm Log Status Commands

name	Type	Description
additional-info	Parameter type: <Alarm::AddInfoString> - additional alarm information	identifies the neighbor/instance where the alarm occurred or empty string if not applicable <i>This element is only shown in detail mode.</i>

Only Show Details: current and previous alarm log status		
name	Type	Description
lsa-limit	Parameter type: <Alarm::LsaLimit> (reached not-reached) Possible values: - reached : external LSA limit reached - not-reached : external LSAs within limitation	specifies whether the limit of received external LSAs is reached or not <i>This element is only shown in detail mode.</i>
prev-lsa-limit	Parameter type: <Alarm::LsaLimit> (reached not-reached) Possible values: - reached : external LSA limit reached - not-reached : external LSAs within limitation	status of lsa-limit with its previous logged value <i>This element is only shown in detail mode.</i>
lsa-mid-limit	Parameter type: <Alarm::LsaMidLimit> (reached not-reached) Possible values: - reached : 90% of LSA limit reached - not-reached : less than 90% of LSA limit	specifies whether 90% of the limit of received external LSAs is reached or not <i>This element is only shown in detail mode.</i>
prev-lsa-mid-limit	Parameter type: <Alarm::LsaMidLimit> (reached not-reached) Possible values: - reached : 90% of LSA limit reached - not-reached : less than 90% of LSA limit	status of lsa-mid-limit with its previous logged value <i>This element is only shown in detail mode.</i>
neighbor-down	Parameter type: <Alarm::NeighborDown> (yes no) Possible values: - yes : OSPF neighbor down - no : OSPF neighbor up	specifies whether ospf neighbour is down or not <i>This element is only shown in detail mode.</i>
prev-neighbor-down	Parameter type: <Alarm::NeighborDown> (yes no) Possible values: - yes : OSPF neighbor down - no : OSPF neighbor up	status of neighbor-down with its previous logged value <i>This element is only shown in detail mode.</i>
instance-down	Parameter type: <Alarm::OspfDown> (yes no) Possible values: - yes : OSPF instance down - no : OSPF instance up	specifies whether OSPF instance is down or not <i>This element is only shown in detail mode.</i>
prev-instance-down	Parameter type: <Alarm::OspfDown> (yes no) Possible values: - yes : OSPF instance down - no : OSPF instance up	status of instance-down with its previous logged value <i>This element is only shown in detail mode.</i>
v3-lsa-limit	Parameter type: <Alarm::V3LsaLimit> (reached	specifies whether the limit of received external OSPFv3 LSAs

name	Type	Description
	not-reached) Possible values: - reached : external OSPFv3 LSA limit reached - not-reached : external OSPFv3 LSAs within limitation	is reached or not <i>This element is only shown in detail mode.</i>
prev-v3-lsa-limit	Parameter type: <Alarm::V3LsaLimit> (reached not-reached) Possible values: - reached : external OSPFv3 LSA limit reached - not-reached : external OSPFv3 LSAs within limitation	status of v3-lsa-limit with its previous logged value <i>This element is only shown in detail mode.</i>
v3-lsa-mid-limit	Parameter type: <Alarm::V3LsaMidLimit> (reached not-reached) Possible values: - reached : 90% of OSPFv3 LSA limit reached - not-reached : less than 90% of OSPFv3 LSA limit	specifies whether 90% of the limit of received external OSPFv3 LSAs is reached or not <i>This element is only shown in detail mode.</i>
prev-v3-lsa-mid-limit	Parameter type: <Alarm::V3LsaMidLimit> (reached not-reached) Possible values: - reached : 90% of OSPFv3 LSA limit reached - not-reached : less than 90% of OSPFv3 LSA limit	status of v3-lsa-mid-limit with its previous logged value <i>This element is only shown in detail mode.</i>
v3-neighbor-down	Parameter type: <Alarm::V3NeighborDown> (yes no) Possible values: - yes : OSPFv3 neighbor down - no : OSPFv3 neighbor up	specifies whether OSPFv3 neighbor is down or not <i>This element is only shown in detail mode.</i>
prev-v3-neighbor-down	Parameter type: <Alarm::V3NeighborDown> (yes no) Possible values: - yes : OSPFv3 neighbor down - no : OSPFv3 neighbor up	status of v3-neighbor-down with its previous logged value <i>This element is only shown in detail mode.</i>
v3-instance-down	Parameter type: <Alarm::V3OspfDown> (yes no) Possible values: - yes : OSPFv3 instance down - no : OSPFv3 instance up	specifies whether OSPFv3 instance is down or not <i>This element is only shown in detail mode.</i>
prev-v3-instance-down	Parameter type: <Alarm::V3OspfDown> (yes no) Possible values: - yes : OSPFv3 instance down - no : OSPFv3 instance up	status of v3-instance-down with its previous logged value <i>This element is only shown in detail mode.</i>

102.73 ihub-l2forward Alarm Log Status Command

Command Description

This command displays the ihub-l2forward alarm log status.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm log ihub-l2forward [ (index) ]
```

Command Parameters

Table 102.73-1 "ihub-l2forward Alarm Log Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm log table index

Command Output

Table 102.73-2 "ihub-l2forward Alarm Log Status Command" Display parameters

Specific Information		
name	Type	Description
last-updated-on	Parameter type: <Sys::timeInSecs> - the time (yyyy-mm-dd:hour:minutes:secs) - unit: UTC	network time in seconds when the alarm was logged <i>This element is only shown in detail mode.</i>
port	Parameter type: <Ihub::EtherPortAndLag> (nt-a : sfp : <Alarm::FacePlatePortIndex> nt-a : xfp : <Alarm::FacePlatePortIndex> nt-a : qsfp : <Alarm::FacePlatePortIndex> nt-a : eth : <Alarm::FacePlatePortIndex> nt-b : sfp : <Alarm::FacePlatePortIndex> nt-b : xfp : <Alarm::FacePlatePortIndex> nt-b : qsfp : <Alarm::FacePlatePortIndex> nt-b : eth : <Alarm::FacePlatePortIndex> ntio-1 : sfp : <Alarm::FacePlatePortIndex> ntio-1 : xfp : <Alarm::FacePlatePortIndex> ntio-1 : qsfp : <Alarm::FacePlatePortIndex> ntio-2 : sfp : <Alarm::FacePlatePortIndex> ntio-2 : xfp : <Alarm::FacePlatePortIndex> ntio-2 : qsfp : <Alarm::FacePlatePortIndex>	identifies the physical position of the port <i>This element is only shown in detail mode.</i>

name	Type	Description
	lt : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> lag : <Alarm::IhubLagId> nt-a : qsfp : <Alarm::QsfpPortIndex> - <Alarm::LaneIndex> nt-b : qsfp : <Alarm::QsfpPortIndex> - <Alarm::LaneIndex>) Possible values: - nt-a : the nt-a slot - nt-b : the nt-b slot - ntio-1 : an nt applique slot in a single or multiple-ntio-shelf - ntio-2 : an nt applique slot in a multiple-ntio-shelf - lt : the lt slot - lag : key word to specify link aggregation group - nt-a : the nt-a slot - nt-b : the nt-b slot Possible values: - sfp : SFP port - xfp : XFP port - qsfp : QSFP port - eth : RJ45 or lemi port Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Alarm::IhubLagId> - link aggregation group id Field type <Alarm::FacePlatePortIndex> - the faceplate port number Field type <Alarm::QsfpPortIndex> - the qsfp port number Field type <Alarm::LaneIndex> - the lane number of qsfp port	
service-id	Parameter type: <Alarm::ServiceId> - a profile index value - range: [1...2147483647]	identifies the vpls service-id where the alarm has occurred. <i>This element is only shown in detail mode.</i>

Only Show Details: current and previous alarm log status

name	Type	Description
stp-exception	Parameter type: <Alarm::StpException> (yes no) Possible values: - yes : stp exception condition detected on the port - no : no stp exception condition detected	specifies whether an STP exception condition is present on the port or not <i>This element is only shown in detail mode.</i>
prev-stp-exception	Parameter type: <Alarm::StpException> (yes no) Possible values: - yes : stp exception condition detected on the port - no : no stp exception condition detected	status of stp-exception with its previous logged value <i>This element is only shown in detail mode.</i>
stp-root-guard	Parameter type: <Alarm::StpRootGuard> (violation no violation) Possible values: - violation : stp root guard violation detected on the port	specifies whether an STP root-guard violation present or not <i>This element is only shown in detail mode.</i>

102 Alarm Log Status Commands

name	Type	Description
	- no violation : no stp root guard violation detected	
prev-stp-root-guard	Parameter type: <Alarm::StpRootGuard> (violation no violation) Possible values: - violation : stp root guard violation detected on the port - no violation : no stp root guard violation detected	status of stp-root-guard with its previous logged value <i>This element is only shown in detail mode.</i>

102.74 Vpls Alarm Log Status Command

Command Description

This command displays the vpls alarm log status.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm log vpls [ (index) ]
```

Command Parameters

Table 102.74-1 "Vpls Alarm Log Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm log table index

Command Output

Table 102.74-2 "Vpls Alarm Log Status Command" Display parameters

Specific Information		
name	Type	Description
last-updated-on	Parameter type: <Sys::timeInSecs> - the time (yyyy-mm-dd:hour:minutes:secs) - unit: UTC	network time in seconds when the alarm was logged <i>This element is only shown in detail mode.</i>
service-id	Parameter type: <Alarm::ServiceId> - a profile index value - range: [1...2147483647]	identifies the vpls service-id where the alarm has occurred. <i>This element is only shown in detail mode.</i>
mac-idx	Parameter type: <Alarm::IdentificationIdxOrZero> - a signed integer	unique reference for the duplicate mac alarm and zero for all other alarms; duplicate mac is further specified in additional-info <i>This element is only shown in detail mode.</i>
additional-info	Parameter type: <Alarm::AddInfoStringVpls> - additional alarm information	Additional information regarding duplicate MAC alarm <i>This element is only shown in detail mode.</i>

Only Show Details: current and previous alarm log status

102 Alarm Log Status Commands

name	Type	Description
mfib-limit	Parameter type: <Alarm::MfibLimit> (reached not-reached) Possible values: - reached : mfib table size limit reached - not-reached : mfib table size below limit.	specifies whether the number of entries in the multicast FIB table reached its limit or not <i>This element is only shown in detail mode.</i>
prev-mfib-limit	Parameter type: <Alarm::MfibLimit> (reached not-reached) Possible values: - reached : mfib table size limit reached - not-reached : mfib table size below limit.	status of mfib-limit with its previous logged value <i>This element is only shown in detail mode.</i>
duplicate-mac	Parameter type: <Alarm::DuplicateMac> (yes no) Possible values: - yes : duplicate mac detected on vpls - no : no duplicate mac on the vpls	specifies whether a duplicate MAC address is detected or not <i>This element is only shown in detail mode.</i>
prev-duplicate-mac	Parameter type: <Alarm::DuplicateMac> (yes no) Possible values: - yes : duplicate mac detected on vpls - no : no duplicate mac on the vpls	status of duplicate-mac with its previous logged value <i>This element is only shown in detail mode.</i>
fdb-limit	Parameter type: <Alarm::FdbLimit> (reached not-reached) Possible values: - reached : fdb table size limit reached - not-reached : fdb table size below low limit	specifies whether the number of entries in the fdb table reached the upper limit or dropped below the lower limit. <i>This element is only shown in detail mode.</i>
prev-fdb-limit	Parameter type: <Alarm::FdbLimit> (reached not-reached) Possible values: - reached : fdb table size limit reached - not-reached : fdb table size below low limit	status of fdb-limit with its previous logged value <i>This element is only shown in detail mode.</i>
self-duplic-mac	Parameter type: <Alarm::Selfduplic> (yes no) Possible values: - yes : self duplicate mac detected on a sap of the vpls - no : no self duplicate mac on a sap of the vpls	specifies whether a duplicate of a system owned mac address is detected on a sap of the vpls service or not <i>This element is only shown in detail mode.</i>
prev-self-duplic-mac	Parameter type: <Alarm::Selfduplic> (yes no) Possible values: - yes : self duplicate mac detected on a sap of the vpls - no : no self duplicate mac on a sap of the vpls	status of self-duplic-mac with its previous logged value <i>This element is only shown in detail mode.</i>
sdp-self-dup-mac	Parameter type: <Alarm::SdpSelfdupMac> (yes no) Possible values: - yes : self duplicate mac detected on sdp binding of the vpls - no : no self duplicate mac on a sdp binding of the vpls	specifies whether a duplicate of a system owned mac address is detected on a sdp binding of the vpls service or not <i>This element is only shown in detail mode.</i>
prev-sdp-self-dup-mac	Parameter type: <Alarm::SdpSelfdupMac> (yes no)	status of sdp-self-dup-mac with its previous logged value <i>This element is only shown in detail mode.</i>

name	Type	Description
	Possible values: - yes : self duplicate mac detected on sdp binding of the vpls - no : no self duplicate mac on a sdp binding of the vpls	<i>detail mode.</i>

102.75 IHUB-Eqip Alarm Log Status Command

Command Description

This command displays the ihub-equip alarm log status.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm log ihub-equip [ (index) ]
```

Command Parameters

Table 102.75-1 "IHUB-Eqip Alarm Log Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm log table index

Command Output

Table 102.75-2 "IHUB-Eqip Alarm Log Status Command" Display parameters

Specific Information		
name	Type	Description
last-updated-on	Parameter type: <Sys::timeInSecs> - the time (yyyy-mm-dd:hour:minutes:secs) - unit: UTC	network time in seconds when the alarm was logged <i>This element is only shown in detail mode.</i>
slot	Parameter type: <Alarm::NtSlotId> (nt-a nt-b) Possible values: - nt-a : nt-a slot - nt-b : nt-b slot	identifies the slot where the alarm has been detected. <i>This element is only shown in detail mode.</i>
additional-info	Parameter type: <Alarm::AddInfoString> - additional alarm information	additional information regarding the out-of-mem alarm, containing the name of the Software Module triggering this alarm <i>This element is only shown in detail mode.</i>

Only Show Details: current and previous alarm log status		
name	Type	Description
peer-comm	Parameter type: <Alarm::PeerComm>	specifies whether peer-to-peer

name	Type	Description
	(fail no fail) Possible values: - fail : peer-to-peer communication failure - no fail : no peer-to-peer communication failure	communication has failed or not <i>This element is only shown in detail mode.</i>
prev-peer-comm	Parameter type: <Alarm::PeerComm> (fail no fail) Possible values: - fail : peer-to-peer communication failure - no fail : no peer-to-peer communication failure	status of peer-comm with its previous logged value <i>This element is only shown in detail mode.</i>
sw-fail	Parameter type: <Alarm::SwFail> (yes no) Possible values: - yes : software failure detected - no : no software failure	specifies whether a software failure has occurred or not <i>This element is only shown in detail mode.</i>
prev-sw-fail	Parameter type: <Alarm::SwFail> (yes no) Possible values: - yes : software failure detected - no : no software failure	status of sw-fail with its previous logged value <i>This element is only shown in detail mode.</i>
hw-fail	Parameter type: <Alarm::HwFail> (yes no) Possible values: - yes : hardware failure detected - no : no hardware failure	specifies whether a hardware failure has occurred or not <i>This element is only shown in detail mode.</i>
prev-hw-fail	Parameter type: <Alarm::HwFail> (yes no) Possible values: - yes : hardware failure detected - no : no hardware failure	status of hw-fail with its previous logged value <i>This element is only shown in detail mode.</i>
link-fail	Parameter type: <Alarm::LinkFail> (yes no) Possible values: - yes : link failure detected - no : no link failiure	specifies whether a link failure has occurred or not <i>This element is only shown in detail mode.</i>
prev-link-fail	Parameter type: <Alarm::LinkFail> (yes no) Possible values: - yes : link failure detected - no : no link failiure	status of link-fail with its previous logged value <i>This element is only shown in detail mode.</i>
proc-overload	Parameter type: <Alarm::ProcOverload> (yes no) Possible values: - yes : processor overload detected - no : no processor overload	specifies whether an overload condition exists for the processor at ihub side <i>This element is only shown in detail mode.</i>
prev-proc-overload	Parameter type: <Alarm::ProcOverload> (yes no) Possible values:	status of proc-overload with its previous logged value <i>This element is only shown in detail mode.</i>

102 Alarm Log Status Commands

name	Type	Description
	- yes : processor overload detected - no : no processor overload	
out-of-mem	Parameter type: <Alarm::OutOfMem> (yes no) Possible values: - yes : memory allocation failure - no : memory allocation successful	specifies whether memory allocation in ihub failed or not <i>This element is only shown in detail mode.</i>
prev-out-of-mem	Parameter type: <Alarm::OutOfMem> (yes no) Possible values: - yes : memory allocation failure - no : memory allocation successful	status of out-of-mem with its previous logged value <i>This element is only shown in detail mode.</i>
ntp-comm	Parameter type: <Alarm::ntpCommLoss> (lost not-lost) Possible values: - lost : NTP communication lost - not-lost : NTP communication is not lost	specifies whether ntp communication is lost or not <i>This element is only shown in detail mode.</i>
prev-ntp-comm	Parameter type: <Alarm::ntpCommLoss> (lost not-lost) Possible values: - lost : NTP communication lost - not-lost : NTP communication is not lost	status of ntp communication with its previous logged value. <i>This element is only shown in detail mode.</i>

102.76 IHUB-Link Alarm Log Status Command

Command Description

This command displays the ihub-link alarm log status.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm log ihub-link [ (index) ]
```

Command Parameters

Table 102.76-1 "IHUB-Link Alarm Log Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm log table index

Command Output

Table 102.76-2 "IHUB-Link Alarm Log Status Command" Display parameters

Specific Information		
name	Type	Description
last-updated-on	Parameter type: <Sys::timeInSecs> - the time (yyyy-mm-dd:hour:minutes:secs) - unit: UTC	network time in seconds when the alarm was logged <i>This element is only shown in detail mode.</i>
port	Parameter type: <Ihub::EtherPort> (nt-a : sfp : <Alarm::FacePlatePortIndex> nt-a : xfp : <Alarm::FacePlatePortIndex> nt-a : qsfp : <Alarm::FacePlatePortIndex> nt-a : cfp : <Alarm::FacePlatePortIndex> nt-a : eth : <Alarm::FacePlatePortIndex> nt-a : ieee1588 : <Alarm::FacePlatePortIndex> nt-a : ai : <Alarm::FacePlatePortIndex> nt-b : sfp : <Alarm::FacePlatePortIndex> nt-b : xfp : <Alarm::FacePlatePortIndex> nt-b : qsfp : <Alarm::FacePlatePortIndex> nt-b : cfp : <Alarm::FacePlatePortIndex> nt-b : eth : <Alarm::FacePlatePortIndex> nt-b : ieee1588 : <Alarm::FacePlatePortIndex> nt-b : ai : <Alarm::FacePlatePortIndex>	identifies the ihub port where the alarm has occurred. <i>This element is only shown in detail mode.</i>

102 Alarm Log Status Commands

name	Type	Description
	ntio-1 : sfp : <Alarm::FacePlatePortIndex> ntio-1 : xfp : <Alarm::FacePlatePortIndex> ntio-1 : qsfp : <Alarm::FacePlatePortIndex> ntio-1 : cfp : <Alarm::FacePlatePortIndex> ntio-2 : sfp : <Alarm::FacePlatePortIndex> ntio-2 : xfp : <Alarm::FacePlatePortIndex> ntio-2 : qsfp : <Alarm::FacePlatePortIndex> ntio-2 : cfp : <Alarm::FacePlatePortIndex> lt : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> nt-a : qsfp : <Alarm::QsfpPortIndex> - <Alarm::LaneIndex> nt-b : qsfp : <Alarm::QsfpPortIndex> - <Alarm::LaneIndex> ntio-1 : qsfp : <Alarm::QsfpPortIndex> - <Alarm::LaneIndex>) Possible values: - nt-a : the nt-a slot - nt-b : the nt-b slot - ntio-1 : an nt applique slot in a single or multiple-ntio-shelf - ntio-2 : an nt applique slot in a multiple-ntio-shelf - lt : the lt slot - nt-a : the nt-a slot - nt-b : the nt-b slot - ntio-1 : the nt-b slot Possible values: - sfp : SFP port - xfp : XFP port - qsfp : QSFP port - cfp : CFP port - eth : RJ45 or lemi port - ieee1588 : IEEE1588 port - ai : AI port Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Alarm::FacePlatePortIndex> - the faceplate port number Field type <Alarm::QsfpPortIndex> - the qsfp port number Field type <Alarm::LaneIndex> - the lane number of qsfp port	
additional-info	Parameter type: <Alarm::AddInfoString> - additional alarm information	additional information regarding the lagport-add-fail alarm, containing the failure reason: Either of these will apply: - unknown - adminkey-mismatch - - sysid-mismatch - - lacp-passive-both-ends - - link-down <i>This element is only shown in detail mode.</i>

Only Show Details: current and previous alarm log status		
name	Type	Description
link-down	Parameter type: <Alarm::lhubLink>	specifies whether the link is

name	Type	Description
	(yes no) Possible values: - yes : link down - no : link up	down or not <i>This element is only shown in detail mode.</i>
prev-link-down	Parameter type: <Alarm::IhubLink> (yes no) Possible values: - yes : link down - no : link up	status of link-down with its previous logged value <i>This element is only shown in detail mode.</i>
lagport-add-fail	Parameter type: <Alarm::LagportAddFail> (yes no) Possible values: - yes : lag-port not added - no : lag-port successfully added	specifies whether a port was successfully added to a link aggregation group or not <i>This element is only shown in detail mode.</i>
prev-lagport-add-fail	Parameter type: <Alarm::LagportAddFail> (yes no) Possible values: - yes : lag-port not added - no : lag-port successfully added	status of lagport-add-fail with its previous logged value <i>This element is only shown in detail mode.</i>
conf-mismatch	Parameter type: <Alarm::SpeedMismatch> (yes no) Possible values: - yes : port configuration mismatch - no : no port configuration mismatch	specifies whether the inserted SFP or SFP+ type matches the planned speed and/or auto-negotiation for the port or not <i>This element is only shown in detail mode.</i>
prev-conf-mismatch	Parameter type: <Alarm::SpeedMismatch> (yes no) Possible values: - yes : port configuration mismatch - no : no port configuration mismatch	status of conf-mismatch with its previous logged value <i>This element is only shown in detail mode.</i>

102.77 IHUB-Tca Alarm Log Status Command

Command Description

This command displays the ihub-tca alarm log status.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm log ihub-tca [ (index) ]
```

Command Parameters

Table 102.77-1 "IHUB-Tca Alarm Log Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm log table index

Command Output

Table 102.77-2 "IHUB-Tca Alarm Log Status Command" Display parameters

Specific Information		
name	Type	Description
last-updated-on	Parameter type: <Sys::timeInSecs> - the time (yyyy-mm-dd:hour:minutes:secs) - unit: UTC	network time in seconds when the alarm was logged <i>This element is only shown in detail mode.</i>
port	Parameter type: <Ihub::EtherPort> (nt-a : sfp : <Alarm::FacePlatePortIndex> nt-a : xfp : <Alarm::FacePlatePortIndex> nt-a : qsfp : <Alarm::FacePlatePortIndex> nt-a : cfp : <Alarm::FacePlatePortIndex> nt-a : eth : <Alarm::FacePlatePortIndex> nt-a : ieee1588 : <Alarm::FacePlatePortIndex> nt-a : ai : <Alarm::FacePlatePortIndex> nt-b : sfp : <Alarm::FacePlatePortIndex> nt-b : xfp : <Alarm::FacePlatePortIndex> nt-b : qsfp : <Alarm::FacePlatePortIndex> nt-b : cfp : <Alarm::FacePlatePortIndex> nt-b : eth : <Alarm::FacePlatePortIndex> nt-b : ieee1588 : <Alarm::FacePlatePortIndex> nt-b : ai : <Alarm::FacePlatePortIndex>	identifies the ihub port where the alarm has occurred. <i>This element is only shown in detail mode.</i>

name	Type	Description
	ntio-1 : sfp : <Alarm::FacePlatePortIndex> ntio-1 : xfp : <Alarm::FacePlatePortIndex> ntio-1 : qsfp : <Alarm::FacePlatePortIndex> ntio-1 : cfp : <Alarm::FacePlatePortIndex> ntio-2 : sfp : <Alarm::FacePlatePortIndex> ntio-2 : xfp : <Alarm::FacePlatePortIndex> ntio-2 : qsfp : <Alarm::FacePlatePortIndex> ntio-2 : cfp : <Alarm::FacePlatePortIndex> lt : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> nt-a : qsfp : <Alarm::QsfpPortIndex> - <Alarm::LaneIndex> nt-b : qsfp : <Alarm::QsfpPortIndex> - <Alarm::LaneIndex> ntio-1 : qsfp : <Alarm::QsfpPortIndex> - <Alarm::LaneIndex>) Possible values: - nt-a : the nt-a slot - nt-b : the nt-b slot - ntio-1 : an nt applique slot in a single or multiple-ntio-shelf - ntio-2 : an nt applique slot in a multiple-ntio-shelf - lt : the lt slot - nt-a : the nt-a slot - nt-b : the nt-b slot - ntio-1 : the nt-b slot Possible values: - sfp : SFP port - xfp : XFP port - qsfp : QSFP port - cfp : CFP port - eth : RJ45 or lemi port - ieee1588 : IEEE1588 port - ai : AI port Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Alarm::FacePlatePortIndex> - the faceplate port number Field type <Alarm::QsfpPortIndex> - the qsfp port number Field type <Alarm::LaneIndex> - the lane number of qsfp port	

Only Show Details: current and previous alarm log status		
name	Type	Description
tca-outputbw	Parameter type: <Alarm::TcaOutputBw> (yes no) Possible values: - yes : tca output bandwidth crossed threshold - no : tca output bandwidth did not crossed threshold	specifies whether the output bw has crossed threshold or not <i>This element is only shown in detail mode.</i>
prev-tca-outputbw	Parameter type: <Alarm::TcaOutputBw> (yes no) Possible values: - yes : tca output bandwidth crossed threshold	status of tca output bw with its previous logged value <i>This element is only shown in detail mode.</i>

102 Alarm Log Status Commands

name	Type	Description
	- no : tca output bandwidth did not crossed threshold	
tca-inputbw	Parameter type: <Alarm::TcaInputBw> (yes no) Possible values: - yes : tca input bandwidth crossed threshold - no : tca input bandwidth did not crossed threshold	specifies whether the tca input bw has crossed threshold or not <i>This element is only shown in detail mode.</i>
prev-tca-inputbw	Parameter type: <Alarm::TcaInputBw> (yes no) Possible values: - yes : tca input bandwidth crossed threshold - no : tca input bandwidth did not crossed threshold	status of tca input bw with its previous logged value <i>This element is only shown in detail mode.</i>
tca-rxcrcalign	Parameter type: <Alarm::TcaRxCrcAlign> (yes no) Possible values: - yes : tca rxrc align errors crossed threshold - no : tca rxrc align errors did not crossed threshold	specifies whether the tca rxrc align errors has crossed threshold or not <i>This element is only shown in detail mode.</i>
prev-tca-rxcrcalign	Parameter type: <Alarm::TcaRxCrcAlign> (yes no) Possible values: - yes : tca rxrc align errors crossed threshold - no : tca rxrc align errors did not crossed threshold	status of tca rxrc align errors with its previous logged value <i>This element is only shown in detail mode.</i>
tca-txcrcalign	Parameter type: <Alarm::TcaTx_crcAlign> (yes no) Possible values: - yes : tca txrc align errors crossed threshold - no : tca txrc align errors did not crossed threshold	specifies whether the tca txrc align errors has crossed threshold or not <i>This element is only shown in detail mode.</i>
prev-tca-txcrcalign	Parameter type: <Alarm::TcaTx_crcAlign> (yes no) Possible values: - yes : tca txrc align errors crossed threshold - no : tca txrc align errors did not crossed threshold	status of tca txrc align errors with its previous logged value <i>This element is only shown in detail mode.</i>
tca-txcollisions	Parameter type: <Alarm::TcaTxCollisions> (yes no) Possible values: - yes : tca txcollisions errors crossed threshold - no : tca txcollisions errors did not crossed threshold	specifies whether the tca tx collisions errors has crossed threshold or not <i>This element is only shown in detail mode.</i>
prev-tca-txcollisions	Parameter type: <Alarm::TcaTxCollisions> (yes no) Possible values: - yes : tca txcollisions errors crossed threshold - no : tca txcollisions errors did not crossed threshold	status of tca tx collisions errors with its previous logged value <i>This element is only shown in detail mode.</i>
tca-outputhighbw	Parameter type: <Alarm::TcaOutputHighBw> (yes no) Possible values: - yes : tca output high bandwidth crossed threshold - no : tca output high bandwidth did not crossed threshold	specifies whether the continous output high bw has crossed threshold or not <i>This element is only shown in detail mode.</i>
prev-tca-outputhighbw	Parameter type: <Alarm::TcaOutputHighBw> (yes	status of tca output high bw with its previous logged value

name	Type	Description
	no) Possible values: - yes : tca output high bandwidth crossed threshold - no : tca output high bandwidth did not crossed threshold	<i>This element is only shown in detail mode.</i>
tca-outputmedbw	Parameter type: <Alarm::TcaOutputMediumBw> (yes no) Possible values: - yes : tca output medium bandwidth crossed threshold - no : tca output medium bandwidth did not crossed threshold	specifies whether the continous output medium bw has crossed threshold or not <i>This element is only shown in detail mode.</i>
prev-tca-outputmedbw	Parameter type: <Alarm::TcaOutputMediumBw> (yes no) Possible values: - yes : tca output medium bandwidth crossed threshold - no : tca output medium bandwidth did not crossed threshold	status of tca output medium bw with its previous logged value <i>This element is only shown in detail mode.</i>
tca-outputlowbw	Parameter type: <Alarm::TcaOutputLowBw> (yes no) Possible values: - yes : tca output low bandwidth crossed threshold - no : tca output low bandwidth did not crossed threshold	specifies whether the continous output low bw has crossed threshold or not <i>This element is only shown in detail mode.</i>
prev-tca-outputlowbw	Parameter type: <Alarm::TcaOutputLowBw> (yes no) Possible values: - yes : tca output low bandwidth crossed threshold - no : tca output low bandwidth did not crossed threshold	status of tca output low bw with its previous logged value <i>This element is only shown in detail mode.</i>
tca-inputhighbw	Parameter type: <Alarm::TcaInputHighBw> (yes no) Possible values: - yes : tca input high bandwidth crossed threshold - no : tca input high bandwidth did not crossed threshold	specifies whether the continous input high bw has crossed threshold or not <i>This element is only shown in detail mode.</i>
prev-tca-inputhighbw	Parameter type: <Alarm::TcaInputHighBw> (yes no) Possible values: - yes : tca input high bandwidth crossed threshold - no : tca input high bandwidth did not crossed threshold	status of tca input high bw with its previous logged value <i>This element is only shown in detail mode.</i>
tca-inputmediumbw	Parameter type: <Alarm::TcaInputMediumBw> (yes no) Possible values: - yes : tca input medium bandwidth crossed threshold - no : tca input medium bandwidth did not crossed threshold	specifies whether the continous input medium bw has crossed threshold or not <i>This element is only shown in detail mode.</i>
prev-tca-inputmediumbw	Parameter type: <Alarm::TcaInputMediumBw> (yes no) Possible values: - yes : tca input medium bandwidth crossed threshold - no : tca input medium bandwidth did not crossed threshold	status of tca input medium bw with its previous logged value <i>This element is only shown in detail mode.</i>
tca-inputlowbw	Parameter type: <Alarm::TcaInputLowBw> (yes no)	specifies whether the continous input low bw has crossed threshold or not

102 Alarm Log Status Commands

name	Type	Description
	Possible values: - yes : tca input low bandwidth crossed threshold - no : tca input low bandwidth did not crossed threshold	<i>This element is only shown in detail mode.</i>
prev-tca-inputlowbw	Parameter type: <Alarm::TcaInputLowBw> (yes no) Possible values: - yes : tca input low bandwidth crossed threshold - no : tca input low bandwidth did not crossed threshold	status of tca input low bw with its previous logged value <i>This element is only shown in detail mode.</i>

102.78 LDP Alarm Log Status Command

Command Description

This command displays the Label Distribution Protocol alarm log status.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm log ldp [ (index) ]
```

Command Parameters

Table 102.78-1 "LDP Alarm Log Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm log table index

Command Output

Table 102.78-2 "LDP Alarm Log Status Command" Display parameters

Specific Information		
name	Type	Description
last-updated-on	Parameter type: <Sys::timeInSecs> - the time (yyyy-mm-dd:hour:minutes:secs) - unit: UTC	network time in seconds when the alarm was logged <i>This element is only shown in detail mode.</i>
router-id	Parameter type: <Ihub::baseRouter> base Possible values: - base : base router	identifies the base router <i>This element is only shown in detail mode.</i>
ip-address	Parameter type: <Alarm::IPAddressOrZero> (not-applicable <IPv4::address>) Possible values: - not-applicable : not applicable Field type <IPv4::address> - IPv4-address	identifies the ip-address of the LDP targeted Peer <i>This element is only shown in detail mode.</i>

Only Show Details: current and previous alarm log status		
name	Type	Description
instance-down	Parameter type: <Alarm::LdpInstanceDown> (yes	specifies whether the LDP instance is down or not

102 Alarm Log Status Commands

name	Type	Description
	no) Possible values: - yes : ldp is down - no : ldp is up or not configured	<i>This element is only shown in detail mode.</i>
prev-instance-down	Parameter type: <Alarm::LdpInstanceDown> (yes no) Possible values: - yes : ldp is down - no : ldp is up or not configured	status of instance-down with its previous logged value <i>This element is only shown in detail mode.</i>
session-down	Parameter type: <Alarm::SessionDown> (yes no) Possible values: - yes : TCP session down - no : Connection re-established or ldp not configured or explicit configured peer is removed	specifies whether the LDP session is down or not <i>This element is only shown in detail mode.</i>
prev-session-down	Parameter type: <Alarm::SessionDown> (yes no) Possible values: - yes : TCP session down - no : Connection re-established or ldp not configured or explicit configured peer is removed	status of session-down with its previous logged value <i>This element is only shown in detail mode.</i>

102.79 MPLS Alarm Log Status Command

Command Description

This command displays the mpls alarm log status.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm log mpls [ (index) ]
```

Command Parameters

Table 102.79-1 "MPLS Alarm Log Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm log table index

Command Output

Table 102.79-2 "MPLS Alarm Log Status Command" Display parameters

Specific Information		
name	Type	Description
last-updated-on	Parameter type: <Sys::timeInSecs> - the time (yyyy-mm-dd:hour:minutes:secs) - unit: UTC	network time in seconds when the alarm was logged <i>This element is only shown in detail mode.</i>
router-id	Parameter type: <Ihub::baseRouter> base Possible values: - base : base router	identifies the base router <i>This element is only shown in detail mode.</i>
lsp-id-or-lsp-path-idx	Parameter type: <Alarm::LspIdOrLspPathIndexOrZero> - a signed integer	Lsp id or Lsp path index (unique identifier) where the alarm occurred or zero when not applicable, alarm entry is further specified in additional-info <i>This element is only shown in detail mode.</i>
additional-info	Parameter type: <Alarm::AddInfoString> - additional alarm information	identifies the alarm additional info specific to an mpls alarm. Empty string if not applicable. <i>This element is only shown in</i>

102 Alarm Log Status Commands

name	Type	Description
		<i>detail mode.</i>
Only Show Details: current and previous alarm log status		
name	Type	Description
instance-down	Parameter type: <Alarm::MplsInstanceDown> (yes no) Possible values: - yes : mpls is down - no : mpls is up or not configured	specifies whether the MPLS instance is down or not <i>This element is only shown in detail mode.</i>
prev-instance-down	Parameter type: <Alarm::MplsInstanceDown> (yes no) Possible values: - yes : mpls is down - no : mpls is up or not configured	status of instance-down with its previous logged value <i>This element is only shown in detail mode.</i>
lsp-down	Parameter type: <Alarm::LspDown> (yes no) Possible values: - yes : lsp is down - no : lsp is up or shutdown, or mpls instance is stopped or not configured	specifies whether the LSP is down or not <i>This element is only shown in detail mode.</i>
prev-lsp-down	Parameter type: <Alarm::LspDown> (yes no) Possible values: - yes : lsp is down - no : lsp is up or shutdown, or mpls instance is stopped or not configured	status of session-down with its previous logged value <i>This element is only shown in detail mode.</i>
lsp-path-down	Parameter type: <Alarm::LspPathDown> (yes no) Possible values: - yes : lsp path is down - no : lsp path is up or shutdown, or lsp is shutdown, or mpls instance is stopped or not configured	specifies whether the LSP path is down or not <i>This element is only shown in detail mode.</i>
prev-lsp-path-down	Parameter type: <Alarm::LspPathDown> (yes no) Possible values: - yes : lsp path is down - no : lsp path is up or shutdown, or lsp is shutdown, or mpls instance is stopped or not configured	status of lsp path down with its previous logged value <i>This element is only shown in detail mode.</i>

102.80 SDP Alarm Log Status Command

Command Description

This command displays the Service Delivery Point alarm log status

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm log sdp [ (index) ]
```

Command Parameters

Table 102.80-1 "SDP Alarm Log Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm log table index

Command Output

Table 102.80-2 "SDP Alarm Log Status Command" Display parameters

Specific Information		
name	Type	Description
last-updated-on	Parameter type: <Sys::timeInSecs> - the time (yyyy-mm-dd:hour:minutes:secs) - unit: UTC	network time in seconds when the alarm was logged <i>This element is only shown in detail mode.</i>
sdp-id	Parameter type: <Alarm::SdpId> - sdp-id value - range: [1...17407]	identifies the sdp-id of the sdp binding where the alarm has occurred <i>This element is only shown in detail mode.</i>
vc-id	Parameter type: <Alarm::SvcIdOrZero> - vc-id value or zero - range: [0,1...4294967295]	identifies the vc-id of the sdp binding where the alarm occurred or zero when not applicable, the sdp binding is further specified in additional-info <i>This element is only shown in detail mode.</i>

Only Show Details: current and previous alarm log status		
name	Type	Description
instance-down	Parameter type: <Alarm::SdpInstanceDown>	specifies whether the SDP

102 Alarm Log Status Commands

name	Type	Description
	(yes no) Possible values: - yes : sdp is operationl down - no : sdp is operational up or shutdown	instance is down or not <i>This element is only shown in detail mode.</i>
prev-instance-down	Parameter type: <Alarm::SdpInstanceDown> (yes no) Possible values: - yes : sdp is operationl down - no : sdp is operational up or shutdown	status of instance-down with its previous logged value <i>This element is only shown in detail mode.</i>
binding-down	Parameter type: <Alarm::BindlingDown> (yes no) Possible values: - yes : sdp binding is operational down - no : sdp binding is operational up or shutdown, or the sdp or service is shutdown	specifies whether the SDP binding is down or not <i>This element is only shown in detail mode.</i>
prev-binding-down	Parameter type: <Alarm::BindlingDown> (yes no) Possible values: - yes : sdp binding is operational down - no : sdp binding is operational up or shutdown, or the sdp or service is shutdown	status of binding down with its previous logged value <i>This element is only shown in detail mode.</i>

102.81 IHUB IPV6 Alarm Log Status Command

Command Description

This command displays the ihub-ipv6 alarm log status.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

> show alarm log ihub-ipv6 [(index)]

Command Parameters

Table 102.81-1 "IHUB IPV6 Alarm Log Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm log table index

Command Output

Table 102.81-2 "IHUB IPV6 Alarm Log Status Command" Display parameters

Specific Information		
name	Type	Description
last-updated-on	Parameter type: <Sys::timeInSecs> - the time (yyyy-mm-dd:hour:minutes:secs) - unit: UTC	network time in seconds when the alarm was logged <i>This element is only shown in detail mode.</i>
router-id	Parameter type: <Ihub::Router> (base <Ihub::Router>) Possible values: - base : base router Field type <Ihub::Router> - vprn service-id - range: [1...2147483647]	identifies the vprn service-id or the base router where the alarm has occurred. <i>This element is only shown in detail mode.</i>
duplicate-index	Parameter type: <Alarm::IdentificationIdxOrZero> - a signed integer	unique reference for the duplicate address for which the alarm occurred or zero when not applicable, duplicate address is further specified in additional-info. <i>This element is only shown in</i>

102 Alarm Log Status Commands

name	Type	Description
		<i>detail mode.</i>
additional-info	Parameter type: <Alarm::AddInfoStringVprn> - additional alarm information	identifies the ipv6 alarm additional info or empty string if not applicable. <i>This element is only shown in detail mode.</i>

Only Show Details: current and previous alarm log status		
name	Type	Description
duplicate-address-own	Parameter type: <Alarm::SelfDuplicateIPv6Addr> (yes no) Possible values: - yes : duplicate address detected for own ipv6 address - no : no duplicate address detected for own ipv6 address	specifies whether a duplicate address is detected for own IPV6 address or not <i>This element is only shown in detail mode.</i>
prev-duplic-addr-own	Parameter type: <Alarm::SelfDuplicateIPv6Addr> (yes no) Possible values: - yes : duplicate address detected for own ipv6 address - no : no duplicate address detected for own ipv6 address	status of duplicate-address-own with its previous logged value <i>This element is only shown in detail mode.</i>
duplicate-address	Parameter type: <Alarm::DuplicateIPv6Addr> (yes no) Possible values: - yes : duplicate address detected for user's ipv6 address - no : no duplicate address detected for user's ipv6 address	specifies whether a duplicate address is detected for a user's IPV6 address or not <i>This element is only shown in detail mode.</i>
prev-duplicate-address	Parameter type: <Alarm::DuplicateIPv6Addr> (yes no) Possible values: - yes : duplicate address detected for user's ipv6 address - no : no duplicate address detected for user's ipv6 address	status of duplicate-address with its previous logged value <i>This element is only shown in detail mode.</i>
ipv6-dup-pd-route	Parameter type: <Alarm::Ipv6DupPdRoute> (yes no) Possible values: - yes : duplicate address detected for user's ipv6 PD route - no : no duplicate address detected for user's ipv6 PD route	status of ipv6-dup-pd-route <i>This element is only shown in detail mode.</i>
prev-ipv6-dup-pd-route	Parameter type: <Alarm::Ipv6DupPdRoute> (yes no) Possible values: - yes : duplicate address detected for user's ipv6 PD route - no : no duplicate address detected for user's ipv6 PD route	status of ipv6-dup-pd-route with its previous logged value <i>This element is only shown in detail mode.</i>

102.82 EPIPE Alarm Log Status Command

Command Description

This command displays the Ethernet Pipe alarm log status.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

> show alarm log epipe [(index)]

Command Parameters

Table 102.82-1 "EPIPE Alarm Log Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm log table index

Command Output

Table 102.82-2 "EPIPE Alarm Log Status Command" Display parameters

Specific Information		
name	Type	Description
last-updated-on	Parameter type: <Sys::timeInSecs> - the time (yyyy-mm-dd:hour:minutes:secs) - unit: UTC	network time in seconds when the alarm was logged <i>This element is only shown in detail mode.</i>
service-id	Parameter type: <Alarm::ServiceId> - a profile index value - range: [1...2147483647]	identifies the epipe service-id where the alarm has occurred <i>This element is only shown in detail mode.</i>

Only Show Details: current and previous alarm log status		
name	Type	Description
instance-down	Parameter type: <Alarm::EpipeInstanceDown> (yes no) Possible values: - yes : epipe service is operational down - no : epipe service is operational up or shutdown	specifies whether the epipe instance is down or not <i>This element is only shown in detail mode.</i>
prev-instance-down	Parameter type: <Alarm::EpipeInstanceDown> (yes no)	status of instance-down with its previous logged value <i>This element is only shown in</i>

102 Alarm Log Status Commands

name	Type	Description
	Possible values: - yes : epipe service is operationl down - no : epipe service is operational up or shutdown	<i>detail mode.</i>

102.83 PIM Alarm Log Status Command

Command Description

This command displays the PIM alarm log status.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm log pim [ (index) ]
```

Command Parameters

Table 102.83-1 "PIM Alarm Log Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm log table index

Command Output

Table 102.83-2 "PIM Alarm Log Status Command" Display parameters

Specific Information		
name	Type	Description
last-updated-on	Parameter type: <Sys::timeInSecs> - the time (yyyy-mm-dd:hour:minutes:secs) - unit: UTC	network time in seconds when the alarm was logged <i>This element is only shown in detail mode.</i>
router-id	Parameter type: <Ihub::Router> (base <Ihub::Router>) Possible values: - base : base router Field type <Ihub::Router> - vprn service-id - range: [1...2147483647]	identifies the base router id where the alarm has occurred. <i>This element is only shown in detail mode.</i>
neighbor-idx	Parameter type: <Alarm::IdentificationIdxOrZero> - a signed integer	unique reference for the neighbor where the alarm occurred <i>This element is only shown in detail mode.</i>
additional-info	Parameter type: <Alarm::AddInfoStringPim> - additional alarm information	identifies the neighbor/instance where the alarm occurred or empty string if not applicable

102 Alarm Log Status Commands

name	Type	Description
		<i>This element is only shown in detail mode.</i>

Only Show Details: current and previous alarm log status		
name	Type	Description
pim-neighbor-down	Parameter type: <Alarm::IhubPimDown> (yes no) Possible values: - yes : pim neighbor down - no : pim neighbor up	specifies whether the neighbor instance is down or not <i>This element is only shown in detail mode.</i>
prev-pim-neighbor-down	Parameter type: <Alarm::IhubPimDown> (yes no) Possible values: - yes : pim neighbor down - no : pim neighbor up	status of instance-down with its previous logged value <i>This element is only shown in detail mode.</i>
mc-maximum-routes	Parameter type: <Alarm::IhubMaxRoutes> (yes no) Possible values: - yes : maximum routes reached - no : maximum routes not reached	specifies whether the max mc routes is reached <i>This element is only shown in detail mode.</i>
prev-mc-maximum-routes	Parameter type: <Alarm::IhubMaxRoutes> (yes no) Possible values: - yes : maximum routes reached - no : maximum routes not reached	status of max mc route with its previous logged value <i>This element is only shown in detail mode.</i>

102.84 IHUB Lawful Intercept Alarm Log Status Command

Command Description

This command displays the lawful intercept alarm log status.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm log li [ (index) ]
```

Command Parameters

Table 102.84-1 "IHUB Lawful Intercept Alarm Log Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm log table index

Command Output

Table 102.84-2 "IHUB Lawful Intercept Alarm Log Status Command" Display parameters

Specific Information		
name	Type	Description
last-updated-on	Parameter type: <Sys::timeInSecs> - the time (yyyy-mm-dd:hour:minutes:secs) - unit: UTC	network time in seconds when the alarm was logged <i>This element is only shown in detail mode.</i>
Only Show Details: current and previous alarm log status		
name	Type	Description
li-traf-disabled	Parameter type: <Alarm::LiTrafficDisabled> (yes no) Possible values: - yes : lawful interception of traffic disabled - no : lawful interception of traffic enabled	specifies whether a lawful intercept traffic is disabled or not <i>This element is only shown in detail mode.</i>
prev-li-traf-disabled	Parameter type: <Alarm::LiTrafficDisabled> (yes no) Possible values:	status of li-traf-disabled with its previous logged value <i>This element is only shown in detail mode.</i>

102 Alarm Log Status Commands

name	Type	Description
	- yes : lawful interception of traffic disabled - no : lawful interception of traffic enabled	
li-bandwidth	Parameter type: <Alarm::LiBandwidthLimit> (reached not-reached) Possible values: - reached : lawful intercept reached bandwidth limit - not-reached : lawful intercept within bandwidth limit	specifies whether lawful intercept reached bandwidth limit or not <i>This element is only shown in detail mode.</i>
prev-li-bandwidth	Parameter type: <Alarm::LiBandwidthLimit> (reached not-reached) Possible values: - reached : lawful intercept reached bandwidth limit - not-reached : lawful intercept within bandwidth limit	status of li-bandwidth with its previous logged value <i>This element is only shown in detail mode.</i>
li-out-of-res	Parameter type: <Alarm::LiOutOfRes> (yes no) Possible values: - yes : lack of resources for lawful intercept - no : no resource issues for lawful intercept	specifies whether lawful intercept is out of resources or not <i>This element is only shown in detail mode.</i>
prev-li-out-of-res	Parameter type: <Alarm::LiOutOfRes> (yes no) Possible values: - yes : lack of resources for lawful intercept - no : no resource issues for lawful intercept	status of li-out-of-res with its previous logged value <i>This element is only shown in detail mode.</i>

102.85 Sync Clock Alarm Log Status Command

Command Description

This command displays the synce and bits alarm log status.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm log sync [ (index) ]
```

Command Parameters

Table 102.85-1 "Sync Clock Alarm Log Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm log table index

Command Output

Table 102.85-2 "Sync Clock Alarm Log Status Command" Display parameters

Specific Information		
name	Type	Description
last-updated-on	Parameter type: <Sys::timeInSecs> - the time (yyyy-mm-dd:hour:minutes:secs) - unit: UTC	network time in seconds when the alarm was logged <i>This element is only shown in detail mode.</i>

Only Show Details: slot information		
name	Type	Description
slot	Parameter type: <Alarm::SynceSlot> (ntio-1 ntio-2 nt-a nt-b lt : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> not-used nt) Possible values: - ntio-1 : an nt applique slot in a single or multiple-ntio-shelf - ntio-2 : an nt applique slot in a multiple-ntio-shelf - nt-a : nt-a slot - nt-b : nt-b slot	identifies the synce port where the alarm has occurred. <i>This element is only shown in detail mode.</i>

102 Alarm Log Status Commands

name	Type	Description
	- nt : active nt slot - lt : lt slot - not-used : no interface Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number	
port	Parameter type: <Alarm::SyncePort> (sfp : <Alarm::SynceClk> xfp : <Alarm::SynceClk> bits-a bits-b ieee1588-a not-used ieee1588-b gnssrj45-a gnssrj45-b ieee1588-hybrid-a ieee1588-hybrid-b cfp : <Alarm::SynceClk> <Alarm::SynceClk> qsfp : <Alarm::SynceClk> ieee1588 internal-clk-a internal-clk-b) Possible values: - sfp : synce reference on sfp port - xfp : synce reference on xfp port - bits-a : bits clock source on nt-a - bits-b : bits clock source on nt-b - ieee1588-a : ieee1588 clock source on nt-a - ieee1588-b : ieee1588 clock source on nt-b - gnssrj45-a : gnss tod source on nt-a - gnssrj45-b : gnss tod source on nt-b - ieee1588-hybrid-a : 1588 hybrid tod source on nt-a - ieee1588-hybrid-b : 1588 hybrid tod source on nt-b - cfp : synce reference on cfp port - qsfp : synce reference on qsfp port - ieee1588 : ieee1588 clock source on nt - internal-clk-a : internal clock on nt-a - internal-clk-b : internal clock on nt-b - not-used : not-used Field type <Alarm::SynceClk> - value - range: [0...36]	identifies the synce port where the alarm has occurred. <i>This element is only shown in detail mode.</i>

Only Show Details: current and previous alarm log status		
name	Type	Description
bits-fail	Parameter type: <Alarm::BitsFail> (yes no) Possible values: - yes : bits source failed - no : no bits source failed	specifies whether bits clock source has failed or not <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::BitsFail> (yes	status of bits failure alarm with its previous logged value.

name	Type	Description
	no) Possible values: - yes : bits source failed - no : no bits source failed	<i>This element is only shown in detail mode.</i>
sync-fail	Parameter type: <Alarm::SyncFail> (yes no) Possible values: - yes : sync source failed - no : no sync source failed	specifies whether sync clock source has failed or not <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::SyncFail> (yes no) Possible values: - yes : sync source failed - no : no sync source failed	status of sync failure with its previous logged value. <i>This element is only shown in detail mode.</i>
bits-output-shutoff	Parameter type: <Alarm::BitsOutputShutoffFail> (yes no) Possible values: - yes : bits output shutoff - no : no bits output shutoff	specifies whether bits output failed or not <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::BitsOutputShutoffFail> (yes no) Possible values: - yes : bits output shutoff - no : no bits output shutoff	status of bits output shutoff alarm with its previous logged value. <i>This element is only shown in detail mode.</i>
ieee1588-fail	Parameter type: <Alarm::ieee1588Fail> (yes no) Possible values: - yes : bits output shutoff - no : no bits output shutoff	ieee1588 clock source failure <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::ieee1588Fail> (yes no) Possible values: - yes : bits output shutoff - no : no bits output shutoff	status of 1588 fail alarm with its previous logged value. <i>This element is only shown in detail mode.</i>
gnss-fail	Parameter type: <Alarm::gnssFail> (yes no) Possible values: - yes : gnss tod fail - no : no gnss tod fail	gnss time source failure <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::gnssFail> (yes no) Possible values: - yes : gnss tod fail - no : no gnss tod fail	status of gnss fail alarm with its previous logged value. <i>This element is only shown in detail mode.</i>
ieee1588hybrid-fail	Parameter type: <Alarm::ieee1588hybridFail> (yes no) Possible values: - yes : 1588 hybrid tod fail	1588 ToD source failure <i>This element is only shown in detail mode.</i>

102 Alarm Log Status Commands

name	Type	Description
	- no : no 1588 hybrid tod fail	
prev-status	Parameter type: <Alarm::ieee1588hybridFail> (yes no) Possible values: - yes : 1588 hybrid tod fail - no : no 1588 hybrid tod fail	status of 1588 hybrid ToD fail alarm with its previous logged value. <i>This element is only shown in detail mode.</i>
signal-loss	Parameter type: <Alarm::ClockLoss> (yes no) Possible values: - yes : synce or bits clock signal loss - no : no synce or bits clock signal loss	specifies whether synce or bits clock signal loss or not <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::ClockLoss> (yes no) Possible values: - yes : synce or bits clock signal loss - no : no synce or bits clock signal loss	status of synce or bits clock signal loss alarm with its previous logged value. <i>This element is only shown in detail mode.</i>
signal-efd	Parameter type: <Alarm::ClockEfd> (yes no) Possible values: - yes : synce or bits clock signal exceed frequency deviation - no : no synce or bits clock signal exceed frequency deviation	synce or bits clock signal exceed frequency deviation or not <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::ClockEfd> (yes no) Possible values: - yes : synce or bits clock signal exceed frequency deviation - no : no synce or bits clock signal exceed frequency deviation	status of synce or bits clock signal exceed frequency deviation alarm with its previous logged value. <i>This element is only shown in detail mode.</i>
esmc-loss	Parameter type: <Alarm::ClockEsmcLoss> (yes no) Possible values: - yes : clock source SSM infomation loss - no : no clock source SSM infomation loss	specifies whether clock source loss SSM infomation or not <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::ClockEsmcLoss> (yes no) Possible values: - yes : clock source SSM infomation loss - no : no clock source SSM infomation loss	status of bclock source loss SSM information alarm with its previous logged value. <i>This element is only shown in detail mode.</i>
bits-output-exceed	Parameter type: <Alarm::BitsOutputQlThreshExceed> (yes no) Possible values: - yes : bitout ql threshold exceed - no : no bitout ql threshold exceed	specifies whether bits output ql threshold exceeded or not <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::BitsOutputQlThreshExceed> (yes no) Possible values: - yes : bitout ql threshold exceed - no : no bitout ql threshold exceed	status of bits output ql threshold exceed alarm with its previous logged value. <i>This element is only shown in detail mode.</i>

name	Type	Description
ql-input-exceed	Parameter type: <Alarm::ClockExceed> (yes no) Possible values: - yes : input clock source threshold exceed - no : no input clock source threshold exceed	specifies whether exceed input clock source threshold or not <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::ClockExceed> (yes no) Possible values: - yes : input clock source threshold exceed - no : no input clock source threshold exceed	status of exceed input clock source threshold alarm with its previous logged value. <i>This element is only shown in detail mode.</i>
holdover	Parameter type: <Alarm::ClockHoldover> (yes no) Possible values: - yes : Clock system is in the holdover - no : Clock system is not in the holdover	specifies whether clock system is in the holdover or not <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::ClockHoldover> (yes no) Possible values: - yes : Clock system is in the holdover - no : Clock system is not in the holdover	status of clock system holdover alarm with its previous logged value. <i>This element is only shown in detail mode.</i>
lti	Parameter type: <Alarm::ClockLTI> (yes no) Possible values: - yes : all clock source failed - no : no all clock source failed	specifies whether all clock source failed or not <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::ClockLTI> (yes no) Possible values: - yes : all clock source failed - no : no all clock source failed	status of all clock source failed alarm with its previous logged value. <i>This element is only shown in detail mode.</i>
tod-reference-fail	Parameter type: <Alarm::ToDHoldover> (yes no) Possible values: - yes : Clock system ToD reference is failed - no : Clock system ToD reference is OK	specifies whether clock system tod reference is failed or not <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::ToDHoldover> (yes no) Possible values: - yes : Clock system ToD reference is failed - no : Clock system ToD reference is OK	status of clock system tod reference fail alarm with its previous logged value. <i>This element is only shown in detail mode.</i>
internal-clk-fail	Parameter type: <Alarm::ClockOCXOFail> (yes no) Possible values: - yes : Internal CLK is failed - no : Internal CLK is OK	specifies whether internal clock is failed or not <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::ClockOCXOFail> (yes no)	status of internal clock fail alarm with its previous logged value. <i>This element is only shown in detail mode.</i>

102 Alarm Log Status Commands

name	Type	Description
	Possible values: - yes : Internal CLK is failed - no : Internal CLK is OK	<i>detail mode.</i>

102.86 Equipment Supplemental Alarm Log Status Command

Command Description

This command displays the equipment supplemental alarm log status.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm log eqpt-supplemental [ (index) ]
```

Command Parameters

Table 102.86-1 "Equipment Supplemental Alarm Log Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm log table index

Command Output

Table 102.86-2 "Equipment Supplemental Alarm Log Status Command" Display parameters

Specific Information		
name	Type	Description
last-updated-on	Parameter type: <Sys::timeInSecs> - the time (yyyy-mm-dd:hour:minutes:secs) - unit: UTC	network time in seconds when the alarm was logged. <i>This element is only shown in detail mode.</i>
shelf	Parameter type: <Equipm::Shelf> <Eqpt::RackId> / <Eqpt::ShelfId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number	specify which shelf the alarm occurred on. <i>This element is only shown in detail mode.</i>
Only Show Details: current and previous alarm log status		
name	Type	Description
syslog-upload	Parameter type: <Alarm::uploadFailed> (failed ok) Possible values:	current status of the alarm specifying whether a failure occurred during upload of the NE's system log file to the syslog

102 Alarm Log Status Commands

name	Type	Description
	- failed : upload of syslog file to remote server failed - ok : no syslog file upload failure detected	server or not <i>This element is only shown in detail mode.</i>
prev-syslog-upload	Parameter type: <Alarm::uploadFailed> (failed ok) Possible values: - failed : upload of syslog file to remote server failed - ok : no syslog file upload failure detected	status of syslog-upload alarm with its previous logged value. <i>This element is only shown in detail mode.</i>
ont-sw-dnload	Parameter type: <Alarm::ontSoftwareDownload> (in-progress ok) Possible values: - in-progress : ont software download in progress - ok : no ont software download detected	current status of the alarm specifying whether downloading of ont sw from version control to ont is in progress or not <i>This element is only shown in detail mode.</i>
prev-ont-sw-dnload	Parameter type: <Alarm::ontSoftwareDownload> (in-progress ok) Possible values: - in-progress : ont software download in progress - ok : no ont software download detected	status of ont-sw-dnload alarm with its previous logged value . <i>This element is only shown in detail mode.</i>
cf-75%-used	Parameter type: <Alarm::cf75Percent> (above below) Possible values: - above : Compact flash exceeds 75% of life expectancy - below : Compact flash is below 75% of life expectancy	current status of CF utilization which could be more than 75% or less than that <i>This element is only shown in detail mode.</i>
prev-cf-75%-used	Parameter type: <Alarm::cf75Percent> (above below) Possible values: - above : Compact flash exceeds 75% of life expectancy - below : Compact flash is below 75% of life expectancy	status of CF utilization with its previous logged value. <i>This element is only shown in detail mode.</i>
cf-90%-used	Parameter type: <Alarm::cf90Percent> (above below) Possible values: - above : Compact flash exceeds 90% of life expectancy - below : Compact flash is below 90% of life expectancy	current status of CF utilization which could be more than 90% or less than that <i>This element is only shown in detail mode.</i>
prev-cf-90%-used	Parameter type: <Alarm::cf90Percent> (above below) Possible values: - above : Compact flash exceeds 90% of life expectancy - below : Compact flash is below 90% of life expectancy	status of CF utilization with its previous logged value. <i>This element is only shown in detail mode.</i>

102.87 Otdr Alarm Log Status Command

Command Description

This command displays the otdr alarm log status.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm log otdr [ (index) ]
```

Command Parameters

Table 102.87-1 "Otdr Alarm Log Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm log table index

Command Output

Table 102.87-2 "Otdr Alarm Log Status Command" Display parameters

Specific Information		
name	Type	Description
last-updated-on	Parameter type: <Sys::timeInSecs> - the time (yyyy-mm-dd:hour:minutes:secs) - unit: UTC	network time in seconds when the alarm was logged <i>This element is only shown in detail mode.</i>

Only Show Details: sfp information		
name	Type	Description
ponindex	Parameter type: <Itf::ComplexPortType> (xdsl-line : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> voicefxs : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> xdsl-channel : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> atm-if : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> atm-pvc : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::VpiId> : <Eqpt::VciId> bridge-port : <Eqpt::RackId> / <Eqpt::ShelfId> /	identifies the sf where the alarm has occurred. <i>This element is only shown in detail mode.</i>

name	Type	Description
	<pre> <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::VpiId> : <Eqpt::VciId> vlan-port:ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / <Eqpt::Ng2OntSlotId> / <Eqpt::Ng2OntPortId> : <Eqpt::UnstackedVlan> l2-vlan : <Eqpt::VlanId> ip : <Eqpt::LogicalId> sw-loopback slip uni:ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / <Eqpt::Ng2OntSlotId> / <Eqpt::Ng2OntPortId> vlan-port:ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / <Eqpt::Ng2OntSlotId> / <Eqpt::Ng2OntPortId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> atm-bonding : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> bonding : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> ip-gateway : <Eqpt::VrfId> ip-line : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::VpiId> : <Eqpt::VciId> ip-line : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> shdsl-line : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> e1-line : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> atm-ima : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> ethernet-line : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> bridge-port:ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / vuni vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::VpiId> : <Eqpt::VciId> : <Eqpt::UnstackedVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::UnstackedVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::VpiId> : <Eqpt::VciId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> voip:ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> ip-line : vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::VpiId> : <Eqpt::VciId> : <Eqpt::UnstackedVlan> ip-line : vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::UnstackedVlan> ip-line : vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::VpiId> : <Eqpt::VciId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> </pre>	

name	Type	Description
	ip-line : vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan-port:ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / vuni : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan-port:ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / vuni : <Eqpt::UnstackedVlan> chgroup : <Eqpt::ChannelGroupId> subchgroup : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> bridge-port:ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / <Eqpt::Ng2OntSlotId> / <Eqpt::Ng2OntPortId> atm-pvc : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> bridge-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> bridge-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> / <Eqpt::OntPortId> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> / <Eqpt::OntPortId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> / <Eqpt::OntPortId> : <Eqpt::UnstackedVlan> pon : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> ont : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> uni : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> / <Eqpt::OntPortId> bridge-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / voip bridge-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / vuni vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / voip : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / vuni : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / voip : <Eqpt::UnstackedVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / vuni : <Eqpt::UnstackedVlan> voip : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> la-group : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId>	

name	Type	Description
	vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::LLId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> bridge-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::LLId> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::LLId> : <Eqpt::UnstackedVlan> mpm : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::ComboPonId> x-pon : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::XPonId> 25g-pon : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::M25GPonId> dist-router-interface : slot-stacked : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::SVlan> : <Eqpt::CVlan> dist-router-interface : slot-vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::UnstackedVlan> bundle : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::BundleId> chpair : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::ChannelPairId> ont-ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId>) Possible values: - xdsl-line : a static xdsl line interface - xdsl-channel : a static xdsl channel interface - atm-if : a static atm interface - atm-pvc : an atm pvc interface - bridge-port : a vlan bridge-port - bridge-port:ng2 : a ngpon2 vlan bridge-port - l2-vlan : a l2-vlan interface - ip : an ip interface - sw-loopback : a software loopback interface - slip : a slip interface - atm-bonding : atm bonding obsolete alternative replaced by bonding - bonding : bonding - ip-gateway : ip user gateway interface - ip-line : ip line interface - shdsl-line : a static shdsl line interface - e1-line : a e1 line interface - atm-ima : atm ima - ethernet-line : an ethernet line interface - vlan-port : vlan port - vlan-port:ng2 : a ngpon2 vlan port - pon : pon - x-pon : xgs pon - 25g-pon : 25g pon - chpair : channelpair - chgroup : channelgroup - subchgroup : subchannelgroup - bundle : bundle - ont : ont - ont:ng2 : ngpon2 ONT style identification	

name	Type	Description
	- uni : uni - uni:ng2 : ngpon2 UNI style identification - voip : voip - voip:ng2 : voip - la-group : link aggregation group - dist-router-interface : dist router interface - voicefxs : voicefxs - mpm : multi-pon module Possible values: - vlan : vlan port Possible values: - slot-vlan : slot unstacked - slot-stacked : slot vlan port Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number Field type <Eqpt::VpiId> - atm VPI Field type <Eqpt::VciId> - atm VCI Field type <Eqpt::PonId> - the PON identifier Field type <Eqpt::XPonId> - the XGS PON identifier Field type <Eqpt::M25GPonId> - the 25G PON identifier Field type <Eqpt::ComboPonId> - the comboPON identifier Field type <Eqpt::ChannelPairId> - the channel pair identifier Field type <Eqpt::ChannelGroupId> - the channel group identifier Field type <Eqpt::SubChannelGroupId> - the subchannel group identifier Field type <Eqpt::BundleId> - the BUNDLE identifier Field type <Eqpt::OntId> - the ONT identifier Field type <Eqpt::Ng2OntId> - the NG2 ONT identifier Possible values: - voip : virtual uni identifier obsolete alternative replaced by vuni - vuni : virtual uni identifier Possible values: - vuni : virtual NGPON2 uni identifier Field type <Eqpt::OntSlotId> - the ONT SLOT identifier Field type <Eqpt::OntPortId> - the ONT PORT identifier Field type <Eqpt::Ng2OntSlotId> - the NGPON2 ONT SLOT identifier	

102 Alarm Log Status Commands

name	Type	Description
	Field type <Eqpt::Ng2OntPortId> - the NGPON2 ONT PORT identifier Field type <Eqpt::LLId> - the LLID identifier, range 1 for EPON, range 1-8 for DPOE Possible values: - stacked : stacked vlan identity Field type <Eqpt::UnstackedVlan> - unstacked vlan id Field type <Eqpt::SVlan> - service vlan id Field type <Eqpt::CVlan> - customer vlan id Field type <Eqpt::VlanId> - VLAN id Field type <Eqpt::LogicalId> - logical id Field type <Eqpt::VrfId> - VRF id	

Only Show Details: current and previous alarm log status		
name	Type	Description
capability-mismatch	Parameter type: <Alarm::OTDRmismatch> (yes no) Possible values: - yes : otdr capability mismatch - no : no otdr capability mismatch	specifies whether otdr capability mismatch has occurred. <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::OTDRmismatch> (yes no) Possible values: - yes : otdr capability mismatch - no : no otdr capability mismatch	status of capability mismatch with its previous logged value. <i>This element is only shown in detail mode.</i>

102.88 Management Security Access Alarm Log Status Command

Command Description

This command displays the management security access alarm log status.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm log mgmt-sec-access [ (index) ]
```

Command Parameters

Table 102.88-1 "Management Security Access Alarm Log Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm log table index

Command Output

Table 102.88-2 "Management Security Access Alarm Log Status Command" Display parameters

Specific Information		
name	Type	Description
last-updated-on	Parameter type: <Sys::timeInSecs> - the time (yyyy-mm-dd:hour:minutes:secs) - unit: UTC	network time in seconds when the alarm was logged. <i>This element is only shown in detail mode.</i>
ip-address	Parameter type: <Alarm::IpAddress> - IPv4-address	address of the operator <i>This element is only shown in detail mode.</i>

Only Show Details: current and previous alarm log status		
name	Type	Description
login-successful	Parameter type: <Alarm::MgmtAccess> (yes no) Possible values: - yes : successfully logged in via management access - no : successfully logged out via management access	current status specifying whether successfully logged in or logged out via Management access <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::MgmtAccess>	status of mgmt-access with its

102 Alarm Log Status Commands

name	Type	Description
	(yes no) Possible values: - yes : successfully logged in via management access - no : successfully logged out via management access	previous logged value. <i>This element is only shown in detail mode.</i>
login-failure	Parameter type: <Alarm::InvalidAccess> (yes no) Possible values: - yes : invalid login via management access crossed the threshold - no : invalid login via management access within the threshold	current status specifying invalid attempts to login via management access crossed the threshold or not <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::InvalidAccess> (yes no) Possible values: - yes : invalid login via management access crossed the threshold - no : invalid login via management access within the threshold	status of invalid-access with its previous logged value. <i>This element is only shown in detail mode.</i>

102.89 IHUB BFD Alarm Log Status Command

Command Description

This command displays the bfd alarm log status.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm log bfd [ (index) ]
```

Command Parameters

Table 102.89-1 "IHUB BFD Alarm Log Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm log table index

Command Output

Table 102.89-2 "IHUB BFD Alarm Log Status Command" Display parameters

Specific Information		
name	Type	Description
last-updated-on	Parameter type: <Sys::timeInSecs> - the time (yyyy-mm-dd:hour:minutes:secs) - unit: UTC	network time in seconds when the alarm was logged <i>This element is only shown in detail mode.</i>
vpnrn-id	Parameter type: <Ihub::Router> (base <Ihub::Router>) Possible values: - base : base router Field type <Ihub::Router> - vprn service-id - range: [1...2147483647]	identifies the vprn service-id or the base router where the alarm has occurred. <i>This element is only shown in detail mode.</i>
bfd-unique-id	Parameter type: <Alarm::IdentificationIdxOrZero> - a signed integer	unique identification for the alarm or zero when not applicable, alarm entry is further specified in additional-info <i>This element is only shown in detail mode.</i>
additional-info	Parameter type: <Alarm::AddInfoStringBfd>	Additional information regarding

102 Alarm Log Status Commands

name	Type	Description
	- additional alarm information	the bfd alarm <i>This element is only shown in detail mode.</i>

Only Show Details: current and previous alarm log status		
name	Type	Description
bfd-session-down	Parameter type: <Alarm::BfdSessionDown> (yes no) Possible values: - yes : bfd session down - no : bfd session not down	specifies whether a bfd session went down or not <i>This element is only shown in detail mode.</i>
prev-bfd-session-down	Parameter type: <Alarm::BfdSessionDown> (yes no) Possible values: - yes : bfd session down - no : bfd session not down	status of bfd-session-down with its previous logged value <i>This element is only shown in detail mode.</i>
bfd-max-resource	Parameter type: <Alarm::BfdMaxResource> (yes no) Possible values: - yes : bfd maximum resources reached - no : no resource issues for bfd	specifies whether bfd has reached maximum resources or not <i>This element is only shown in detail mode.</i>
prev-bfd-max-resource	Parameter type: <Alarm::BfdMaxResource> (yes no) Possible values: - yes : bfd maximum resources reached - no : no resource issues for bfd	status of bfd-max-resource with its previous logged value <i>This element is only shown in detail mode.</i>
bfd-stale-entry	Parameter type: <Alarm::BfdStaleEntry> (yes no) Possible values: - yes : bfd stale entry present - no : bfd stale entry not present	specifies whether a bfd entry has become stale or not <i>This element is only shown in detail mode.</i>
prev-bfd-stale-entry	Parameter type: <Alarm::BfdStaleEntry> (yes no) Possible values: - yes : bfd stale entry present - no : bfd stale entry not present	status of bfd-stale-entry with its previous logged value <i>This element is only shown in detail mode.</i>

102.90 Application Intelligence Alarm Log Status Command

Command Description

This command displays the log for the Application Intelligence alarm status.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm log ai [ (index) ]
```

Command Parameters

Table 102.90-1 "Application Intelligence Alarm Log Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm log table index

Command Output

Table 102.90-2 "Application Intelligence Alarm Log Status Command" Display parameters

Specific Information		
name	Type	Description
last-updated-on	Parameter type: <Sys::timeInSecs> - the time (yyyy-mm-dd:hour:minutes:secs) - unit: UTC	network time in seconds when the alarm was logged <i>This element is only shown in detail mode.</i>
slot-id	Parameter type: <Equipm::NtSlotIndex> (nt-a nt-b) Possible values: - nt-a : nt-a slot - nt-b : nt-b slot	identifies the board hosting the AI Platform for which the alarm has occurred. <i>This element is only shown in detail mode.</i>
application-virtplatf	Parameter type: <SignedInteger> - a signed integer	identifies the Application and/or the virtualplatform for which the alarm occurred <i>This element is only shown in detail mode.</i>
additional-info	Parameter type: <Alarm::AddInfoStringAI>	Additional information regarding

102 Alarm Log Status Commands

name	Type	Description
	- Additional info: Application Name - length: x<=32	the AI alarm (Application name or none) <i>This element is only shown in detail mode.</i>

Only Show Details: current and previous alarm log status		
name	Type	Description
ai-platform-down	Parameter type: <Alarm::AIPlatformDown> (yes no) Possible values: - yes : AI Platform down - no : AI Platform not down	specifies whether an AI Platform went down or not <i>This element is only shown in detail mode.</i>
prev-ai-platform-down	Parameter type: <Alarm::AIPlatformDown> (yes no) Possible values: - yes : AI Platform down - no : AI Platform not down	previously logged status of the ai-platform-down alarm <i>This element is only shown in detail mode.</i>
ai-appl-inst-fail	Parameter type: <Alarm::AIApplInstallFail> (yes no) Possible values: - yes : Application installation failed - no : Application installation successful	specifies whether an Application 'download and installation' failed or was successful <i>This element is only shown in detail mode.</i>
prev-ai-appl-inst-fail	Parameter type: <Alarm::AIApplInstallFail> (yes no) Possible values: - yes : Application installation failed - no : Application installation successful	previously logged status of the ai-appl-install-fail alarm <i>This element is only shown in detail mode.</i>
ip-assign-fail	Parameter type: <Alarm::IpAddrAssignFail> (yes no) Possible values: - yes : Dhcp assigned address failure - no : Dhcp assigned address successful	specifies whether dhcp client 'assigned ip address' failed or was successful <i>This element is only shown in detail mode.</i>
prev-ip-assign-fail	Parameter type: <Alarm::IpAddrAssignFail> (yes no) Possible values: - yes : Dhcp assigned address failure - no : Dhcp assigned address successful	previously logged status of the ip-addr-assign-fail alarm <i>This element is only shown in detail mode.</i>

102.91 ONT SNMP Alarm Log Status Command

Command Description

This command displays the ont snmp alarm log status.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm log ontsnmp [ (index) ]
```

Command Parameters

Table 102.91-1 "ONT SNMP Alarm Log Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm log table index

Command Output

Table 102.91-2 "ONT SNMP Alarm Log Status Command" Display parameters

Specific Information		
name	Type	Description
last-updated-on	Parameter type: <Sys::timeInSecs> - the time (yyyy-mm-dd:hour:minutes:secs) - unit: UTC	network time in seconds when the alarm was logged. <i>This element is only shown in detail mode.</i>
uni-index	Parameter type: <Ces::InterfaceIndex> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> / <Eqpt::OntPortId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Eqpt::OntId> - the ONT identifier Field type <Eqpt::OntSlotId>	identification of the uni interface index <i>This element is only shown in detail mode.</i>

102 Alarm Log Status Commands

name	Type	Description
	- the ONT SLOT identifier Field type <Eqpt::OntPortId> - the ONT PORT identifier	

Only Show Details: current and previous alarm log status		
name	Type	Description
snmp-mismatch	Parameter type: <Alarm::OntSnmpMismatch> (mismatch not-mismatch) Possible values: - mismatch : ont snmp agent configuration data is mismatch - not-mismatch : ont snmp agent configuration data is not mismatch	current status specifying ont snmp data is mismatch or not <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::OntSnmpMismatch> (mismatch not-mismatch) Possible values: - mismatch : ont snmp agent configuration data is mismatch - not-mismatch : ont snmp agent configuration data is not mismatch	status of snmp mismatch with its previous logged value. <i>This element is only shown in detail mode.</i>

102.92 Tr069 Alarm Status Command

Command Description

This command displays the tr069 current alarm status.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm log tr069serv [ (index) ]
```

Command Parameters

Table 102.92-1 "Tr069 Alarm Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm type

Command Output

Table 102.92-2 "Tr069 Alarm Status Command" Display parameters

Specific Information		
name	Type	Description
last-updated-on	Parameter type: <Sys::timeInSecs> - the time (yyyy-mm-dd:hour:minutes:secs) - unit: UTC	network time in seconds when the alarm was logged <i>This element is only shown in detail mode.</i>
tr069serv	Parameter type: <Ces::InterfaceIndex> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> / <Eqpt::OntPortId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Eqpt::OntId> - the ONT identifier Field type <Eqpt::OntSlotId>	identifies the tr069 serv entry <i>This element is only shown in detail mode.</i>

102 Alarm Log Status Commands

name	Type	Description
	- the ONT SLOT identifier Field type <Eqpt::OntPortId> - the ONT PORT identifier	

Only Show Details: current and previous alarm log status		
name	Type	Description
ont-tr069-serv-mis	Parameter type: <Alarm::Tr069ServMis> (yes no) Possible values: - yes : ont tr069 server mismatch occurred - no : no ont tr069 server mismatch	specifies ont tr069 server mismatch occurred or not. <i>This element is only shown in detail mode.</i>
prev-tr069-serv-mis	Parameter type: <Alarm::Tr069ServMis> (yes no) Possible values: - yes : ont tr069 server mismatch occurred - no : no ont tr069 server mismatch	status of ont-tr069-serv-mis with its previous logged value <i>This element is only shown in detail mode.</i>

102.93 Bulk Sync Alarm Log Status Command

Command Description

This command displays the bulk sync alarm log status.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm log bulk-sync [ (index) ]
```

Command Parameters

Table 102.93-1 "Bulk Sync Alarm Log Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm log table index

Command Output

Table 102.93-2 "Bulk Sync Alarm Log Status Command" Display parameters

Specific Information		
name	Type	Description
last-updated-on	Parameter type: <Sys::timeInSecs> - the time (yyyy-mm-dd:hour:minutes:secs) - unit: UTC	network time in seconds when the alarm was logged. <i>This element is only shown in detail mode.</i>
port	Parameter type: <RedPort::PortIndex> (pon : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> chpair : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::ChannelPairId>) Possible values: - pon : pon-aid - chpair : chpair-aid Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId>	specify which port the alarm occurred on. <i>This element is only shown in detail mode.</i>

102 Alarm Log Status Commands

name	Type	Description
	- the PON identifier Field type <Eqpt::ChannelPairId> - the channel pair identifier	
Only Show Details: current and previous alarm log status		
name	Type	Description
bsf-dhcpv4-fail	Parameter type: <Alarm::BsfDHCPv4> ((failing fail) ok) Possible values: - failing : dhcpv4 bulk-sync is failing - fail : dhcpv4 bulk-sync is failing - ok : dhcpv4 bulk-sync is ok	current status of dhcpv4 bulk-sync failure. <i>This element is only shown in detail mode.</i>
bsf-dhcpv6-fail	Parameter type: <Alarm::BsfDHCPv6> ((failing fail) ok) Possible values: - failing : dhcpv6 bulk-sync is failing - fail : dhcpv6 bulk-sync is failing - ok : dhcpv6 bulk-sync is ok	current status of dhcpv6 bulk-sync failure. <i>This element is only shown in detail mode.</i>
bsf-pon-fail	Parameter type: <Alarm::BsfPON> ((failing fail) ok) Possible values: - failing : pon bulk-sync is failing - fail : pon bulk-sync is failing - ok : pon bulk-sync is ok	current status of pon bulk-sync failure. <i>This element is only shown in detail mode.</i>
bsf-vlan-bridge-fail	Parameter type: <Alarm::BsfVBridge> ((failing fail) ok) Possible values: - failing : vlan-bridge bulk-sync is failing - fail : vlan-bridge bulk-sync is failing - ok : vlan-bridge bulk-sync is ok	current status of vlan-bridge bulk-sync failure. <i>This element is only shown in detail mode.</i>
bsf-qos-fail	Parameter type: <Alarm::BsfQoS> ((failing fail) ok) Possible values: - failing : qos bulk-sync is failing - fail : qos bulk-sync is failing - ok : qos bulk-sync is ok	current status of qos bulk-sync failure. <i>This element is only shown in detail mode.</i>
bsf-igmp-fail	Parameter type: <Alarm::BsfIGMP> ((failing fail) ok) Possible values: - failing : igmp bulk-sync is failing - fail : igmp bulk-sync is failing - ok : igmp bulk-sync is ok	current status of igmp bulk-sync failure. <i>This element is only shown in detail mode.</i>
bsf-lxfwd-fail	Parameter type: <Alarm::BsfLxFwd> ((failing fail) ok) Possible values: - failing : LxFwd bulk-sync is failing - fail : LxFwd bulk-sync is failing - ok : LxFwd bulk-sync is ok	current status of lxfwd bulk-sync failure. <i>This element is only shown in detail mode.</i>

102.94 Protection Group Alarm Log Status Command

Command Description

This command displays the protection group alarm log status.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

> show alarm log protection-group [(index)]

Command Parameters

Table 102.94-1 "Protection Group Alarm Log Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm log table index

Command Output

Table 102.94-2 "Protection Group Alarm Log Status Command" Display parameters

Specific Information		
name	Type	Description
last-updated-on	Parameter type: <Sys::timeInSecs> - the time (yyyy-mm-dd:hour:minutes:secs) - unit: UTC	network time in seconds when the alarm was logged. <i>This element is only shown in detail mode.</i>
port	Parameter type: <RedPort::PortIndex> (pon : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> chpair : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::ChannelPairId>) Possible values: - pon : pon-aid - chpair : chpair-aid Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number	specify which port the alarm occurred on. <i>This element is only shown in detail mode.</i>

102 Alarm Log Status Commands

name	Type	Description
	Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Eqpt::ChannelPairId> - the channel pair identifier	
Only Show Details: current and previous alarm log status		
name	Type	Description
port-protection-fail	Parameter type: <Alarm::ProtNotAvail> ((failing fail) ok) Possible values: - failing : port protection is failing - fail : port protection is failing - ok : port protection is ok	current status of port protection failure. <i>This element is only shown in detail mode.</i>
port-switchover-fail	Parameter type: <Alarm::ProtSwFail> ((failing fail) ok) Possible values: - failing : port protection switchover failing - fail : port protection switchover failing - ok : port protection switchover is ok	current status of port switchover failure. <i>This element is only shown in detail mode.</i>

102.95 Ont protection Alarm Log Status Command

Command Description

This command displays the ont protection alarm log status.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

> show alarm log ont-protection [(index)]

Command Parameters

Table 102.95-1 "Ont protection Alarm Log Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm log table index

Command Output

Table 102.95-2 "Ont protection Alarm Log Status Command" Display parameters

Specific Information		
name	Type	Description
last-updated-on	Parameter type: <Sys::timeInSecs> - the time (yyyy-mm-dd:hour:minutes:secs) - unit: UTC	network time in seconds when the alarm was logged. <i>This element is only shown in detail mode.</i>
ont	Parameter type: <Gpon::OntIndex> (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> ng2 : <Ng2::ChannelGroup> / <Ng2::SubchannelGroup> / <Ng2::OntId>) Possible values: - ng2 : ngpon2 style identification Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier	identifies the ont entry <i>This element is only shown in detail mode.</i>

102 Alarm Log Status Commands

name	Type	Description
	Field type <Ng2::ChannelGroup> - channel group number Field type <Ng2::SubchannelGroup> - subchannel group number Field type <Eqpt::OntId> - the ONT identifier Field type <Ng2::OntId> - the ONT identifier	

Only Show Details: current and previous alarm log status		
name	Type	Description
ont-prot-fail	Parameter type: <Alarm::OntProtNotAvail> ((failing fail) ok) Possible values: - failing : ont protection is failing - fail : ont protection is failing - ok : ont protection is ok	current status of ont protection failure. <i>This element is only shown in detail mode.</i>

102.96 ONT General Supplemental Alarm Log Status Command

Command Description

This command displays the ONT general supplemental alarm log status.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm log ont [ (index) ]
```

Command Parameters

Table 102.96-1 "ONT General Supplemental Alarm Log Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm type

Command Output

Table 102.96-2 "ONT General Supplemental Alarm Log Status Command" Display parameters

Specific Information		
name	Type	Description
last-updated-on	Parameter type: <Sys::timeInSecs> - the time (yyyy-mm-dd:hour:minutes:secs) - unit: UTC	network time in seconds when the alarm was logged <i>This element is only shown in detail mode.</i>
ont	Parameter type: <Gpon::OntIndex> (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> ng2 : <Ng2::ChannelGroup> / <Ng2::SubchannelGroup> / <Ng2::OntId>) Possible values: - ng2 : ngpon2 style identification Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId>	identifies the ont entry <i>This element is only shown in detail mode.</i>

102 Alarm Log Status Commands

name	Type	Description
	- the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Ng2::ChannelGroup> - channel group number Field type <Ng2::SubchannelGroup> - subchannel group number Field type <Eqpt::OntId> - the ONT identifier Field type <Ng2::OntId> - the ONT identifier	

Only Show Details: current and previous alarm log status		
name	Type	Description
ont-gen-sw-dnload-file	Parameter type: <Alarm::ONTGENERALSUPPLEMENTALSWDLFILE> (yes no) Possible values: - yes : ont sw download file missing - no : ont works properly	ont sw download file missing <i>This element is only shown in detail mode.</i>
ont-gen-fan-fail	Parameter type: <Alarm::ONTGENERALSUPPLEMENTALFANALM> (yes no) Possible values: - yes : ont fan failure - no : ont works properly	ont fan failure <i>This element is only shown in detail mode.</i>
ont-gen-high-temp	Parameter type: <Alarm::ONTGENERALSUPPLEMENTALHITEMPWARN> (yes no) Possible values: - yes : high temperature warning - no : ont works properly	ont high temperature <i>This element is only shown in detail mode.</i>
ont-gen-high-temp-ex	Parameter type: <Alarm::ONTGENERALSUPPLEMENTALHITEMPSHUTOFF> (yes no) Possible values: - yes : high temperature shutoff - no : ont works properly	ont excessive high temperature <i>This element is only shown in detail mode.</i>
ont-gen-emergency-call	Parameter type: <Alarm::ONTGENERALSUPPLEMENTALECALLACT> (yes no) Possible values: - yes : ont emergency call - no : ont works properly	ont emergency call <i>This element is only shown in detail mode.</i>
ont-gen-sw-version	Parameter type: <Alarm::ONTGENERALSUPPLEMENTALSWVERCTLERP> (yes no) Possible values: - yes : ont sw version control error - no : ont works properly	ont sw version control error <i>This element is only shown in detail mode.</i>
ont-poe-exceed-max	Parameter type: <Alarm::OntPoE> (yes	ont poe exceed max <i>This element is only shown in</i>

name	Type	Description
	no) Possible values: - yes : ont poe exceed max occurred - no : no ont poe exceed max	<i>detail mode.</i>
ont-poe-over-yell	Parameter type: <Alarm::OntPoEY> (yes no) Possible values: - yes : ont poe is nearing its maximum ability to supply the power - no : ont poe is not nearing its maximum ability to supply the power	specifies ont poe is nearing its maximum ability to supply power <i>This element is only shown in detail mode.</i>
ont-opti-malfunc	Parameter type: <Alarm::OntTransMal> (yes no) Possible values: - yes : ONT detects the malfunction of its optical transceiver - no : ONT not detects the malfunction of its optical transceiver	ONT detects the malfunction of its optical transceiver <i>This element is only shown in detail mode.</i>
ont-gen-cfgdld-fail	Parameter type: <Alarm::OntCfgDld> (yes no) Possible values: - yes : ont poe exceed max occurred - no : no ont poe exceed max	specifies download of voice xml file to ont failed or not. <i>This element is only shown in detail mode.</i>
ont-loopdetect-mis	Parameter type: <Alarm::OntLoopDetectMis> (yes no) Possible values: - yes : ont loop detect mismatch occurred - no : no ont loop detect mismatch	ONT loop detection configuration mismatch <i>This element is only shown in detail mode.</i>
rssi-mismatch	Parameter type: <Alarm::OntRssiMismatch> (yes no) Possible values: - yes : ont dose not support rssi feature - no : ont supports rssi feature	rssi mismatch status <i>This element is only shown in detail mode.</i>
tx-pwr-alm-low	Parameter type: <Alarm::OntTxPwrAlrmLow> (yes no) Possible values: - yes : tx pwr at ont side is too low - no : tx pwr at ont side is normal	tx pwr low alarm status <i>This element is only shown in detail mode.</i>
temp-alm-high	Parameter type: <Alarm::OntTempAlrmHigh> (yes no) Possible values: - yes : temperature at ont side is too high - no : temperature at ont side is normal	temp alarm high status <i>This element is only shown in detail mode.</i>
volt-alm-high	Parameter type: <Alarm::OntVoltAlrmHigh> (yes no) Possible values: - yes : voltage at ont side is too high - no : voltage at ont side is normal	voltage alarm high status <i>This element is only shown in detail mode.</i>
bias-alm-high	Parameter type: <Alarm::OntBiasAlrmHigh> (yes	bias alarm high status <i>This element is only shown in</i>

102 Alarm Log Status Commands

name	Type	Description
	no) Possible values: - yes : bias at ont side is too high - no : bias at ont side is normal	<i>detail mode.</i>
ont-olt-rx-pw-hig	Parameter type: <Alarm::OltRxPwrAlrmH> (yes no) Possible values: - yes : rx power at olt side is too high - no : rx power at olt side is normal	olt side receive power from ont high <i>This element is only shown in detail mode.</i>
ont-olt-rx-pw-warnhig	Parameter type: <Alarm::OltRxPwrWarnH> (yes no) Possible values: - yes : rx power at olt side is warn high - no : rx power at olt side is normal	olt side receive power from ont high warning <i>This element is only shown in detail mode.</i>
ont-olt-rx-pw-warnlo	Parameter type: <Alarm::OltRxPwrWarnL> (yes no) Possible values: - yes : rx power at olt side is warn low - no : rx power at olt side is normal	olt side receive power from ont low warning <i>This element is only shown in detail mode.</i>
ont-olt-rx-pw-lo	Parameter type: <Alarm::OltRxPwrAlrmL> (yes no) Possible values: - yes : rx power at olt side is too low - no : rx power at olt side is normal	olt side receive power from ont low <i>This element is only shown in detail mode.</i>
ont-gen-tod-out-sync	Parameter type: <Alarm::TODOUTSYNC> (yes no) Possible values: - yes : tod is out-sync with olt - no : tod is sync with olt	tod is out-sync with olt <i>This element is only shown in detail mode.</i>
ont-gen-tune-fail	Parameter type: <Alarm::TUNEFAIL> (yes no) Possible values: - yes : Ont has failed to tune to Target-ChnlPair - no : Ont is to tune to Target-ChnlPair	ONU has failed to tune to Pref-ChnlPair <i>This element is only shown in detail mode.</i>
hgu-tr069-parm-fail	Parameter type: <Alarm::HGUTR69FAIL> (yes no) Possible values: - yes : hgu tr069 parameters mismatch - no : hgu tr069 parameters not mismatch	hgu tr069 parameters mismatch <i>This element is only shown in detail mode.</i>
ont-gen-tod-mismatch	Parameter type: <Alarm::TODMISMATCH> (yes no) Possible values: - yes : tod is mismatch - no : tod is ok	tod is mismatch <i>This element is only shown in detail mode.</i>

102.97 SFU ONT General Supplemental Alarm Log Status Command

Command Description

This command displays the SFU ONT general supplemental alarm log status.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm log sfu-sup [ (index) ]
```

Command Parameters

Table 102.97-1 "SFU ONT General Supplemental Alarm Log Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm type

Command Output

Table 102.97-2 "SFU ONT General Supplemental Alarm Log Status Command" Display parameters

Specific Information		
name	Type	Description
last-updated-on	Parameter type: <Sys::timeInSecs> - the time (yyyy-mm-dd:hour:minutes:secs) - unit: UTC	network time in seconds when the alarm was logged <i>This element is only shown in detail mode.</i>
ont	Parameter type: <Gpon::OntIndex> (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> ng2 : <Ng2::ChannelGroup> / <Ng2::SubchannelGroup> / <Ng2::OntId>) Possible values: - ng2 : ngpon2 style identification Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId>	identifies the ont entry <i>This element is only shown in detail mode.</i>

102 Alarm Log Status Commands

name	Type	Description
	- the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Ng2::ChannelGroup> - channel group number Field type <Ng2::SubchannelGroup> - subchannel group number Field type <Eqpt::OntId> - the ONT identifier Field type <Ng2::OntId> - the ONT identifier	

Only Show Details: current and previous alarm log status		
name	Type	Description
sfu-sup-sw-file-error	Parameter type: <Alarm::ONTGENERALSUPPLEMENTALSWDLFILE> (yes no) Possible values: - yes : ont sw download file missing - no : ont works properly	SFU ONT - Software file has error or is missing <i>This element is only shown in detail mode.</i>
sfu-sup-fan-failure	Parameter type: <Alarm::ONTGENERALSUPPLEMENTALFANALM> (yes no) Possible values: - yes : ont fan failure - no : ont works properly	SFU ONT - Fan failure <i>This element is only shown in detail mode.</i>
sfu-sup-temp-high-warn	Parameter type: <Alarm::ONTGENERALSUPPLEMENTALHITEMPWARN> (yes no) Possible values: - yes : high temperature warning - no : ont works properly	SFU ONT - High temperature warning <i>This element is only shown in detail mode.</i>
sfu-sup-temp-shutoff	Parameter type: <Alarm::ONTGENERALSUPPLEMENTALHITEMPSHUTOFF> (yes no) Possible values: - yes : high temperature shutoff - no : ont works properly	SFU ONT - Service disabled due to excessive temperature <i>This element is only shown in detail mode.</i>
sfu-sup-emergency-call	Parameter type: <Alarm::ONTGENERALSUPPLEMENTALECALLACT> (yes no) Possible values: - yes : ont emergency call - no : ont works properly	SFU ONT - Emergency call active <i>This element is only shown in detail mode.</i>
sfu-sup-swverctrl-err	Parameter type: <Alarm::ONTGENERALSUPPLEMENTALSWVERCTLERR> (yes no) Possible values: - yes : ont sw version control error - no : ont works properly	SFU ONT - Software version control error <i>This element is only shown in detail mode.</i>

name	Type	Description
sfu-sup-poe-exceed-max	Parameter type: <Alarm::OntPoE> (yes no) Possible values: - yes : ont poe exceed max occurred - no : no ont poe exceed max	SFU ONT - Configured PoE feeding exceeds ONT maximum <i>This element is only shown in detail mode.</i>
sfu-sup-poe-over-yell	Parameter type: <Alarm::OntPoEY> (yes no) Possible values: - yes : ont poe is nearing its maximum ability to supply the power - no : ont poe is not nearing its maximum ability to supply the power	SFU ONT - specifies ont poe is nearing its maximum ability to supply power <i>This element is only shown in detail mode.</i>
sfu-ont-opti-malfunc	Parameter type: <Alarm::OntTransMal> (yes no) Possible values: - yes : ONT detects the malfunction of its optical transceiver - no : ONT not detects the malfunction of its optical transceiver	ONT detects the malfunction of its optical transceiver <i>This element is only shown in detail mode.</i>
sfu-sup-cfg-dnld-fail	Parameter type: <Alarm::OntCfgDld> (yes no) Possible values: - yes : ont poe exceed max occurred - no : no ont poe exceed max	SFU ONT - Download of voice xml file to ONT failed <i>This element is only shown in detail mode.</i>
sfu-sup-ld-cfg-mism	Parameter type: <Alarm::OntLoopDetectMis> (yes no) Possible values: - yes : ont loop detect mismatch occurred - no : no ont loop detect mismatch	SFU ONT - Loop detection configuration mismatch <i>This element is only shown in detail mode.</i>
sfu-sup-rssi-cfg-mism	Parameter type: <Alarm::OntRssiMismatch> (yes no) Possible values: - yes : ont dose not support rssi feature - no : ont supports rssi feature	SFU ONT - RSSI configuration mismatch <i>This element is only shown in detail mode.</i>
sfu-sup-sfp-tx-low	Parameter type: <Alarm::OntTxPwrAlrmLow> (yes no) Possible values: - yes : tx pwr at ont side is too low - no : tx pwr at ont side is normal	SFU ONT - SFP Tx Power below configured low-level alarm threshold <i>This element is only shown in detail mode.</i>
sfu-sup-sfp-temp-high	Parameter type: <Alarm::OntTempAlrmHigh> (yes no) Possible values: - yes : temperature at ont side is too high - no : temperature at ont side is normal	SFU ONT - SFP Temperature above configured high-level alarm threshold <i>This element is only shown in detail mode.</i>
sfu-sup-sfp-volt-high	Parameter type: <Alarm::OntVoltAlrmHigh> (yes no) Possible values: - yes : voltage at ont side is too high - no : voltage at ont side is normal	SFU ONT - SFP Voltage above configured high-level alarm threshold <i>This element is only shown in detail mode.</i>

102 Alarm Log Status Commands

name	Type	Description
sfu-sup-sfp-bias-high	Parameter type: <Alarm::OntBiasAlrmHigh> (yes no) Possible values: - yes : bias at ont side is too high - no : bias at ont side is normal	SFU ONT - SFP Bias above configured high-level alarm threshold <i>This element is only shown in detail mode.</i>
sfu-sup-olt-rx-high	Parameter type: <Alarm::OltRxPwrAlrmH> (yes no) Possible values: - yes : rx power at olt side is too high - no : rx power at olt side is normal	SFU ONT - OLT Rx power above receiver operating range <i>This element is only shown in detail mode.</i>
sfu-sup-olt-rx-hi-warn	Parameter type: <Alarm::OltRxPwrWarnH> (yes no) Possible values: - yes : rx power at olt side is warn high - no : rx power at olt side is normal	SFU ONT - OLT Rx power above high-level warning threshold <i>This element is only shown in detail mode.</i>
sfu-sup-olt-rx-lo-warn	Parameter type: <Alarm::OltRxPwrWarnL> (yes no) Possible values: - yes : rx power at olt side is warn low - no : rx power at olt side is normal	SFU ONT - OLT Rx power below low-level warning threshold <i>This element is only shown in detail mode.</i>
sfu-sup-olt-rx-low	Parameter type: <Alarm::OltRxPwrAlrmL> (yes no) Possible values: - yes : rx power at olt side is too low - no : rx power at olt side is normal	SFU ONT - OLT Rx power below receiver operating range <i>This element is only shown in detail mode.</i>
sfu-sup-tod-out-sync	Parameter type: <Alarm::TODOUTSYNC> (yes no) Possible values: - yes : tod is out-sync with olt - no : tod is sync with olt	SFU ONT - ONU TOD is out-sync with OLT <i>This element is only shown in detail mode.</i>
sfu-sup-ont-tune-fail	Parameter type: <Alarm::TUNEFAIL> (yes no) Possible values: - yes : Ont has failed to tune to Target-ChnlPair - no : Ont is to tune to Target-ChnlPair	SFU ONT - ONU has failed to tune to Target-ChnlPair <i>This element is only shown in detail mode.</i>
sfu-tr069-parm-fail	Parameter type: <Alarm::HGUTR69FAIL> (yes no) Possible values: - yes : hgu tr069 parameters mismatch - no : hgu tr069 parameters not mismatch	SFU ONT - hgu tr069 parameters mismatch <i>This element is only shown in detail mode.</i>
sfu-sup-tod-mismatch	Parameter type: <Alarm::TODMISMATCH> (yes no) Possible values: - yes : tod is mismatch - no : tod is ok	SFU ONT - ONU TOD MISMATCH <i>This element is only shown in detail mode.</i>

102.98 SOHO ONT General Supplemental Alarm Log Status Command

Command Description

This command displays the SOHO ONT general supplemental alarm log status.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

> show alarm log soho-sup [(index)]

Command Parameters

Table 102.98-1 "SOHO ONT General Supplemental Alarm Log Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm type

Command Output

Table 102.98-2 "SOHO ONT General Supplemental Alarm Log Status Command" Display parameters

Specific Information		
name	Type	Description
last-updated-on	Parameter type: <Sys::timeInSecs> - the time (yyyy-mm-dd:hour:minutes:secs) - unit: UTC	network time in seconds when the alarm was logged <i>This element is only shown in detail mode.</i>
ont	Parameter type: <Gpon::OntIndex> (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> ng2 : <Ng2::ChannelGroup> / <Ng2::SubchannelGroup> / <Ng2::OntId>) Possible values: - ng2 : ngpon2 style identification Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId>	identifies the ont entry <i>This element is only shown in detail mode.</i>

102 Alarm Log Status Commands

name	Type	Description
	- the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Ng2::ChannelGroup> - channel group number Field type <Ng2::SubchannelGroup> - subchannel group number Field type <Eqpt::OntId> - the ONT identifier Field type <Ng2::OntId> - the ONT identifier	

Only Show Details: current and previous alarm log status		
name	Type	Description
soho-sup-sw-file-error	Parameter type: <Alarm::ONTGENERALSUPPLEMENTALSWDLFILE> (yes no) Possible values: - yes : ont sw download file missing - no : ont works properly	SOHO ONT - Software file has error or is missing <i>This element is only shown in detail mode.</i>
soho-sup-fan-failure	Parameter type: <Alarm::ONTGENERALSUPPLEMENTALFANALM> (yes no) Possible values: - yes : ont fan failure - no : ont works properly	SOHO ONT - Fan failure <i>This element is only shown in detail mode.</i>
soho-sup-temp-high-war	Parameter type: <Alarm::ONTGENERALSUPPLEMENTALHITEMPWARN> (yes no) Possible values: - yes : high temperature warning - no : ont works properly	SOHO ONT - High temperature warning <i>This element is only shown in detail mode.</i>
soho-sup-temp-shutoff	Parameter type: <Alarm::ONTGENERALSUPPLEMENTALHITEMPSHUTOFF> (yes no) Possible values: - yes : high temperature shutoff - no : ont works properly	SOHO ONT - Service disabled due to excessive temperature <i>This element is only shown in detail mode.</i>
soho-sup-emergency-cal	Parameter type: <Alarm::ONTGENERALSUPPLEMENTALECALLACT> (yes no) Possible values: - yes : ont emergency call - no : ont works properly	SOHO ONT - Emergency call active <i>This element is only shown in detail mode.</i>
soho-sup-swverctrl-err	Parameter type: <Alarm::ONTGENERALSUPPLEMENTALSWVERCTLERR> (yes no) Possible values: - yes : ont sw version control error - no : ont works properly	SOHO ONT - Software version control error <i>This element is only shown in detail mode.</i>

name	Type	Description
soho-sup-poe-exceed-ma	Parameter type: <Alarm::OntPoE> (yes no) Possible values: - yes : ont poe exceed max occurred - no : no ont poe exceed max	SOHO ONT - Configured PoE feeding exceeds ONT maximum <i>This element is only shown in detail mode.</i>
soho-sup-poe-over-yell	Parameter type: <Alarm::OntPoEY> (yes no) Possible values: - yes : ont poe is nearing its maximum ability to supply the power - no : ont poe is not nearing its maximum ability to supply the power	SOHO ONT - specifies ont poe is nearing its maximum ability to supply power <i>This element is only shown in detail mode.</i>
soho-ont-opti-malfunc	Parameter type: <Alarm::OntTransMal> (yes no) Possible values: - yes : ONT detects the malfunction of its optical transceiver - no : ONT not detects the malfunction of its optical transceiver	ONT detects the malfunction of its optical transceiver <i>This element is only shown in detail mode.</i>
soho-sup-cfg-dnld-fail	Parameter type: <Alarm::OntCfgDld> (yes no) Possible values: - yes : ont poe exceed max occurred - no : no ont poe exceed max	SOHO ONT - Download of voice xml file to ONT failed <i>This element is only shown in detail mode.</i>
soho-sup-ld-cfg-mism	Parameter type: <Alarm::OntLoopDetectMis> (yes no) Possible values: - yes : ont loop detect mismatch occurred - no : no ont loop detect mismatch	SOHO ONT - Loop detection configuration mismatch <i>This element is only shown in detail mode.</i>
soho-sup-rssi-cfg-mism	Parameter type: <Alarm::OntRssiMismatch> (yes no) Possible values: - yes : ont dose not support rssi feature - no : ont supports rssi feature	SOHO ONT - RSSI configuration mismatch <i>This element is only shown in detail mode.</i>
soho-sup-sfp-tx-low	Parameter type: <Alarm::OntTxPwrAlrmLow> (yes no) Possible values: - yes : tx pwr at ont side is too low - no : tx pwr at ont side is normal	SOHO ONT - SFP Tx Power below configured low-level alarm threshold <i>This element is only shown in detail mode.</i>
soho-sup-sfp-temp-high	Parameter type: <Alarm::OntTempAlrmHigh> (yes no) Possible values: - yes : temperature at ont side is too high - no : temperature at ont side is normal	SOHO ONT - SFP Temperature above configured high-level alarm threshold <i>This element is only shown in detail mode.</i>
soho-sup-sfp-volt-high	Parameter type: <Alarm::OntVoltAlrmHigh> (yes no) Possible values: - yes : voltage at ont side is too high - no : voltage at ont side is normal	SOHO ONT - SFP Voltage above configured high-level alarm threshold <i>This element is only shown in detail mode.</i>

102 Alarm Log Status Commands

name	Type	Description
soho-sup-sfp-bias-high	Parameter type: <Alarm::OntBiasAlrmHigh> (yes no) Possible values: - yes : bias at ont side is too high - no : bias at ont side is normal	SOHO ONT - SFP Bias above configured high-level alarm threshold <i>This element is only shown in detail mode.</i>
soho-sup-olt-rx-high	Parameter type: <Alarm::OltRxPwrAlrmH> (yes no) Possible values: - yes : rx power at olt side is too high - no : rx power at olt side is normal	SOHO ONT - OLT Rx power above receiver operating range <i>This element is only shown in detail mode.</i>
soho-sup-olt-rx-hi-war	Parameter type: <Alarm::OltRxPwrWarnH> (yes no) Possible values: - yes : rx power at olt side is warn high - no : rx power at olt side is normal	SOHO ONT - OLT Rx power above high-level warning threshold <i>This element is only shown in detail mode.</i>
soho-sup-olt-rx-lo-war	Parameter type: <Alarm::OltRxPwrWarnL> (yes no) Possible values: - yes : rx power at olt side is warn low - no : rx power at olt side is normal	SOHO ONT - OLT Rx power below low-level warning threshold <i>This element is only shown in detail mode.</i>
soho-sup-olt-rx-low	Parameter type: <Alarm::OltRxPwrAlrmL> (yes no) Possible values: - yes : rx power at olt side is too low - no : rx power at olt side is normal	SOHO ONT - OLT Rx power below receiver operating range <i>This element is only shown in detail mode.</i>
soho-sup-tod-out-sync	Parameter type: <Alarm::TODOUTSYNC> (yes no) Possible values: - yes : tod is out-sync with olt - no : tod is sync with olt	SOHO ONT - ONU TOD is out-sync with OLT <i>This element is only shown in detail mode.</i>
soho-sup-ont-tune-fail	Parameter type: <Alarm::TUNEFAIL> (yes no) Possible values: - yes : Ont has failed to tune to Target-ChnlPair - no : Ont is to tune to Target-ChnlPair	SOHO ONT - ONU has failed to tune to Target-ChnlPair <i>This element is only shown in detail mode.</i>
soho-tr069-parm-fail	Parameter type: <Alarm::HGUTR69FAIL> (yes no) Possible values: - yes : hgu tr069 parameters mismatch - no : hgu tr069 parameters not mismatch	SOHO ONT - hgu tr069 parameters mismatch <i>This element is only shown in detail mode.</i>
soho-sup-tod-mismatch	Parameter type: <Alarm::TODMISMATCH> (yes no) Possible values: - yes : tod is mismatch - no : tod is ok	SOHO ONT - ONU TOD MISMATCH <i>This element is only shown in detail mode.</i>

102.99 MDU ONT General Supplemental Alarm Log Status Command

Command Description

This command displays the MDU ONT general supplemental alarm log status.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm log mdu-sup [ (index) ]
```

Command Parameters

Table 102.99-1 "MDU ONT General Supplemental Alarm Log Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm type

Command Output

Table 102.99-2 "MDU ONT General Supplemental Alarm Log Status Command" Display parameters

Specific Information		
name	Type	Description
last-updated-on	Parameter type: <Sys::timeInSecs> - the time (yyyy-mm-dd:hour:minutes:secs) - unit: UTC	network time in seconds when the alarm was logged <i>This element is only shown in detail mode.</i>
ont	Parameter type: <Gpon::OntIndex> (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> ng2 : <Ng2::ChannelGroup> / <Ng2::SubchannelGroup> / <Ng2::OntId>) Possible values: - ng2 : ngpon2 style identification Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId>	identifies the ont entry <i>This element is only shown in detail mode.</i>

102 Alarm Log Status Commands

name	Type	Description
	- the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Ng2::ChannelGroup> - channel group number Field type <Ng2::SubchannelGroup> - subchannel group number Field type <Eqpt::OntId> - the ONT identifier Field type <Ng2::OntId> - the ONT identifier	

Only Show Details: current and previous alarm log status		
name	Type	Description
mdu-sup-sw-file-error	Parameter type: <Alarm::ONTGENERALSUPPLEMENTALSWDLFILE> (yes no) Possible values: - yes : ont sw download file missing - no : ont works properly	MDU ONT - Software file has error or is missing <i>This element is only shown in detail mode.</i>
mdu-sup-fan-failure	Parameter type: <Alarm::ONTGENERALSUPPLEMENTALFANALM> (yes no) Possible values: - yes : ont fan failure - no : ont works properly	MDU ONT - Fan failure <i>This element is only shown in detail mode.</i>
mdu-sup-temp-high-warn	Parameter type: <Alarm::ONTGENERALSUPPLEMENTALHITEMPWARN> (yes no) Possible values: - yes : high temperature warning - no : ont works properly	MDU ONT - High temperature warning <i>This element is only shown in detail mode.</i>
mdu-sup-temp-shutoff	Parameter type: <Alarm::ONTGENERALSUPPLEMENTALHITEMPSHUTOFF> (yes no) Possible values: - yes : high temperature shutoff - no : ont works properly	MDU ONT - Service disabled due to excessive temperature <i>This element is only shown in detail mode.</i>
mdu-sup-emergency-call	Parameter type: <Alarm::ONTGENERALSUPPLEMENTALECALLACT> (yes no) Possible values: - yes : ont emergency call - no : ont works properly	MDU ONT - Emergency call active <i>This element is only shown in detail mode.</i>
mdu-sup-swverctrl-err	Parameter type: <Alarm::ONTGENERALSUPPLEMENTALSWVERCTLERR> (yes no) Possible values: - yes : ont sw version control error - no : ont works properly	MDU ONT - Software version control error <i>This element is only shown in detail mode.</i>

name	Type	Description
mdu-sup-poe-exceed-max	Parameter type: <Alarm::OntPoE> (yes no) Possible values: - yes : ont poe exceed max occurred - no : no ont poe exceed max	MDU ONT - Configured PoE feeding exceeds ONT maximum <i>This element is only shown in detail mode.</i>
mdu-sup-poe-over-yell	Parameter type: <Alarm::OntPoEY> (yes no) Possible values: - yes : ont poe is nearing its maximum ability to supply the power - no : ont poe is not nearing its maximum ability to supply the power	MDU ONT - specifies ont poe is nearing its maximum ability to supply power <i>This element is only shown in detail mode.</i>
mdu-ont-opti-malfunc	Parameter type: <Alarm::OntTransMal> (yes no) Possible values: - yes : ONT detects the malfunction of its optical transceiver - no : ONT not detects the malfunction of its optical transceiver	ONT detects the malfunction of its optical transceiver <i>This element is only shown in detail mode.</i>
mdu-sup-cfg-dnld-fail	Parameter type: <Alarm::OntCfgDld> (yes no) Possible values: - yes : ont poe exceed max occurred - no : no ont poe exceed max	MDU ONT - Download of voice xml file to ONT failed <i>This element is only shown in detail mode.</i>
mdu-sup-ld-cfg-mism	Parameter type: <Alarm::OntLoopDetectMis> (yes no) Possible values: - yes : ont loop detect mismatch occurred - no : no ont loop detect mismatch	MDU ONT - Loop detection configuration mismatch <i>This element is only shown in detail mode.</i>
mdu-sup-rssi-cfg-mism	Parameter type: <Alarm::OntRssiMismatch> (yes no) Possible values: - yes : ont dose not support rssi feature - no : ont supports rssi feature	MDU ONT - RSSI configuration mismatch <i>This element is only shown in detail mode.</i>
mdu-sup-sfp-tx-low	Parameter type: <Alarm::OntTxPwrAlrmLow> (yes no) Possible values: - yes : tx pwr at ont side is too low - no : tx pwr at ont side is normal	MDU ONT - SFP Tx Power below configured low-level alarm threshold <i>This element is only shown in detail mode.</i>
mdu-sup-sfp-temp-high	Parameter type: <Alarm::OntTempAlrmHigh> (yes no) Possible values: - yes : temperature at ont side is too high - no : temperature at ont side is normal	MDU ONT - SFP Temperature above configured high-level alarm threshold <i>This element is only shown in detail mode.</i>
mdu-sup-sfp-volt-high	Parameter type: <Alarm::OntVoltAlrmHigh> (yes no) Possible values: - yes : voltage at ont side is too high - no : voltage at ont side is normal	MDU ONT - SFP Voltage above configured high-level alarm threshold <i>This element is only shown in detail mode.</i>

102 Alarm Log Status Commands

name	Type	Description
mdu-sup-sfp-bias-high	Parameter type: <Alarm::OntBiasAlrmHigh> (yes no) Possible values: - yes : bias at ont side is too high - no : bias at ont side is normal	MDU ONT - SFP Bias above configured high-level alarm threshold <i>This element is only shown in detail mode.</i>
mdu-sup-olt-rx-high	Parameter type: <Alarm::OltRxPwrAlrmH> (yes no) Possible values: - yes : rx power at olt side is too high - no : rx power at olt side is normal	MDU ONT - OLT Rx power above receiver operating range <i>This element is only shown in detail mode.</i>
mdu-sup-olt-rx-hi-warn	Parameter type: <Alarm::OltRxPwrWarnH> (yes no) Possible values: - yes : rx power at olt side is warn high - no : rx power at olt side is normal	MDU ONT - OLT Rx power above high-level warning threshold <i>This element is only shown in detail mode.</i>
mdu-sup-olt-rx-lo-warn	Parameter type: <Alarm::OltRxPwrWarnL> (yes no) Possible values: - yes : rx power at olt side is warn low - no : rx power at olt side is normal	MDU ONT - OLT Rx power below low-level warning threshold <i>This element is only shown in detail mode.</i>
mdu-sup-olt-rx-low	Parameter type: <Alarm::OltRxPwrAlrmL> (yes no) Possible values: - yes : rx power at olt side is too low - no : rx power at olt side is normal	MDU ONT - OLT Rx power below receiver operating range <i>This element is only shown in detail mode.</i>
mdu-sup-tod-out-sync	Parameter type: <Alarm::TODOUTSYNC> (yes no) Possible values: - yes : tod is out-sync with olt - no : tod is sync with olt	MDU ONT - ONU TOD is out-sync with OLT <i>This element is only shown in detail mode.</i>
mdu-sup-ont-tune-fail	Parameter type: <Alarm::TUNEFAIL> (yes no) Possible values: - yes : Ont has failed to tune to Target-ChnlPair - no : Ont is to tune to Target-ChnlPair	MDU ONT - ONU has failed to tune to Target-ChnlPair <i>This element is only shown in detail mode.</i>
mdu-tr069-parm-fail	Parameter type: <Alarm::HGUTR69FAIL> (yes no) Possible values: - yes : hgu tr069 parameters mismatch - no : hgu tr069 parameters not mismatch	MDU ONT - hgu tr069 parameters mismatch <i>This element is only shown in detail mode.</i>
mdu-sup-tod-mismatch	Parameter type: <Alarm::TODMISMATCH> (yes no) Possible values: - yes : tod is mismatch - no : tod is ok	MDU ONT - ONU TOD MISMATCH <i>This element is only shown in detail mode.</i>

102.100 ONT General Supplemental 2 Alarm Log Status Command

Command Description

This command displays the ONT general supplemental 2 alarm log status.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

> show alarm log ont-ani [(index)]

Command Parameters

Table 102.100-1 "ONT General Supplemental 2 Alarm Log Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm type

Command Output

Table 102.100-2 "ONT General Supplemental 2 Alarm Log Status Command" Display parameters

Specific Information		
name	Type	Description
last-updated-on	Parameter type: <Sys::timeInSecs> - the time (yyyy-mm-dd:hour:minutes:secs) - unit: UTC	network time in seconds when the alarm was logged <i>This element is only shown in detail mode.</i>
ont	Parameter type: <Gpon::OntIndex> (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> ng2 : <Ng2::ChannelGroup> / <Ng2::SubchannelGroup> / <Ng2::OntId>) Possible values: - ng2 : ngpon2 style identification Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number	identifies the ont entry <i>This element is only shown in detail mode.</i>

102 Alarm Log Status Commands

name	Type	Description
	Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Ng2::ChannelGroup> - channel group number Field type <Ng2::SubchannelGroup> - subchannel group number Field type <Eqpt::OntId> - the ONT identifier Field type <Ng2::OntId> - the ONT identifier	

Only Show Details: current and previous alarm log status		
name	Type	Description
temp-alm-low	Parameter type: <Alarm::OntTempAlrmLow> (yes no) Possible values: - yes : temp at ont side is too low - no : temp at ont side is normal	temp alarm low status <i>This element is only shown in detail mode.</i>
volt-alm-low	Parameter type: <Alarm::OntVoltAlrmLow> (yes no) Possible values: - yes : voltage at ont side is too low - no : voltage at ont side is normal	voltage alarm low status <i>This element is only shown in detail mode.</i>
bias-alm-low	Parameter type: <Alarm::OntBiasAlrmLow> (yes no) Possible values: - yes : bias at ont side is too low - no : bias at ont side is normal	bias alarm low status <i>This element is only shown in detail mode.</i>
tx-pwr-alm-high	Parameter type: <Alarm::OntTxPwrAlrmHigh> (yes no) Possible values: - yes : tx power at ont side is too high - no : tx power at ont side is normal	tx pwr high alarm status <i>This element is only shown in detail mode.</i>
rx-pwr-warn-high	Parameter type: <Alarm::OntRxPwrWarnHigh> (yes no) Possible values: - yes : rx power at ont side is too high - no : rx power at ont side is normal	rx pwr warning high status <i>This element is only shown in detail mode.</i>
rx-pwr-warn-low	Parameter type: <Alarm::OntRxPwrWarnLow> (yes no) Possible values: - yes : rx power at ont side is too low - no : rx power at ont side is normal	rx pwr warning high status <i>This element is only shown in detail mode.</i>
tx-pwr-warn-high	Parameter type: <Alarm::OntTxPwrWarnHigh> (yes no) Possible values: - yes : tx power at ont side is too high - no : tx power at ont side is normal	tx pwr warning high status <i>This element is only shown in detail mode.</i>
tx-pwr-warn-low	Parameter type: <Alarm::OntTxPwrWarnLow>	tx pwr warning low status

name	Type	Description
	(yes no) Possible values: - yes : tx power at ont side is too low - no : tx power at ont side is normal	<i>This element is only shown in detail mode.</i>
temp-warn-high	Parameter type: <Alarm::OntTempWarnHigh> (yes no) Possible values: - yes : temp at ont side is too high - no : temp at ont side is normal	temp warning high status <i>This element is only shown in detail mode.</i>
temp-warn-low	Parameter type: <Alarm::OntTempWarnLow> (yes no) Possible values: - yes : temp at ont side is too low - no : temp at ont side is normal	temp warning low status <i>This element is only shown in detail mode.</i>
volt-warn-high	Parameter type: <Alarm::OntVoltWarnHigh> (yes no) Possible values: - yes : voltage at ont side is too high - no : voltage at ont side is normal	voltage warning high status <i>This element is only shown in detail mode.</i>
volt-warn-low	Parameter type: <Alarm::OntVoltWarnLow> (yes no) Possible values: - yes : voltage at ont side is too low - no : voltage at ont side is normal	voltage warning low status <i>This element is only shown in detail mode.</i>
bias-warn-high	Parameter type: <Alarm::OntBiasWarnHigh> (yes no) Possible values: - yes : bias at ont side is too high - no : bias at ont side is normal	bias warning high status <i>This element is only shown in detail mode.</i>
bias-warn-low	Parameter type: <Alarm::OntBiasWarnLow> (yes no) Possible values: - yes : bias at ont side is too low - no : bias at ont side is normal	bias warning low status <i>This element is only shown in detail mode.</i>

102.101 SFU ONT General Supplemental 2 Alarm Log Status Command

Command Description

This command displays the SFU ONT general supplemental 2 alarm log status.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm log sfu-sup2 [ (index) ]
```

Command Parameters

Table 102.101-1 "SFU ONT General Supplemental 2 Alarm Log Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm type

Command Output

Table 102.101-2 "SFU ONT General Supplemental 2 Alarm Log Status Command" Display parameters

Specific Information		
name	Type	Description
last-updated-on	Parameter type: <Sys::timeInSecs> - the time (yyyy-mm-dd:hour:minutes:secs) - unit: UTC	network time in seconds when the alarm was logged <i>This element is only shown in detail mode.</i>
ont	Parameter type: <Gpon::OntIndex> (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> ng2 : <Ng2::ChannelGroup> / <Ng2::SubchannelGroup> / <Ng2::OntId>) Possible values: - ng2 : ngpon2 style identification Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId>	identifies the ont entry <i>This element is only shown in detail mode.</i>

name	Type	Description
	- the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Ng2::ChannelGroup> - channel group number Field type <Ng2::SubchannelGroup> - subchannel group number Field type <Eqpt::OntId> - the ONT identifier Field type <Ng2::OntId> - the ONT identifier	

Only Show Details: current and previous alarm log status		
name	Type	Description
sfu-sup2-temp-low	Parameter type: <Alarm::OntTempAlrmLow> (yes no) Possible values: - yes : temp at ont side is too low - no : temp at ont side is normal	SFU ONT - SFP Temperature is higher than configured alarm high threshold <i>This element is only shown in detail mode.</i>
sfu-sup2-volt-low	Parameter type: <Alarm::OntVoltAlrmLow> (yes no) Possible values: - yes : voltage at ont side is too low - no : voltage at ont side is normal	SFU ONT - SFP Voltage is higher than configured alarm high threshold <i>This element is only shown in detail mode.</i>
sfu-sup2-tx-high	Parameter type: <Alarm::OntTxPwrAlrmHigh> (yes no) Possible values: - yes : tx power at ont side is too high - no : tx power at ont side is normal	SFU ONT - SFP tx power is higher than configured alarm high threshold <i>This element is only shown in detail mode.</i>
sfu-sup2-bias-low	Parameter type: <Alarm::OntBiasAlrmLow> (yes no) Possible values: - yes : bias at ont side is too low - no : bias at ont side is normal	SFU ONT - SFP Bias is lower than configured alarm low threshold <i>This element is only shown in detail mode.</i>
sfu-sup2-rx-hwarn	Parameter type: <Alarm::OntRxPwrWarnHigh> (yes no) Possible values: - yes : rx power at ont side is too high - no : rx power at ont side is normal	SFU ONT - SFP Rx power is higher than configured warn threshold <i>This element is only shown in detail mode.</i>
sfu-sup2-rx-lwarn	Parameter type: <Alarm::OntRxPwrWarnLow> (yes no) Possible values: - yes : rx power at ont side is too low - no : rx power at ont side is normal	SFU ONT - SFP Rx power is lower than configured warn threshold <i>This element is only shown in detail mode.</i>
sfu-sup2-tx-hwarn	Parameter type: <Alarm::OntTxPwrWarnHigh> (yes no) Possible values: - yes : tx power at ont side is too high - no : tx power at ont side is normal	SFU ONT - SFP Tx power is higher than configured warn threshold <i>This element is only shown in detail mode.</i>

102 Alarm Log Status Commands

name	Type	Description
sfu-sup2-tx-lwarn	Parameter type: <Alarm::OntTxPwrWarnLow> (yes no) Possible values: - yes : tx power at ont side is too low - no : tx power at ont side is normal	SFU ONT - SFP Tx power is lower than configured warn threshold <i>This element is only shown in detail mode.</i>
sfu-sup2-temp-hwarn	Parameter type: <Alarm::OntTempWarnHigh> (yes no) Possible values: - yes : temp at ont side is too high - no : temp at ont side is normal	SFU ONT - SFP temperature is higher than configured warn threshold <i>This element is only shown in detail mode.</i>
sfu-sup2-temp-lwarn	Parameter type: <Alarm::OntTempWarnLow> (yes no) Possible values: - yes : temp at ont side is too low - no : temp at ont side is normal	SFU ONT - SFP temperature is lower than configured warn threshold <i>This element is only shown in detail mode.</i>
sfu-sup2-volt-hwarn	Parameter type: <Alarm::OntVoltWarnHigh> (yes no) Possible values: - yes : voltage at ont side is too high - no : voltage at ont side is normal	SFU ONT - SFP voltage is higher than configured warn threshold <i>This element is only shown in detail mode.</i>
sfu-sup2-volt-lwarn	Parameter type: <Alarm::OntVoltWarnLow> (yes no) Possible values: - yes : voltage at ont side is too low - no : voltage at ont side is normal	SFU ONT - SFP voltage is lower than configured warn threshold <i>This element is only shown in detail mode.</i>
sfu-sup2-bias-hwarn	Parameter type: <Alarm::OntBiasWarnHigh> (yes no) Possible values: - yes : bias at ont side is too high - no : bias at ont side is normal	SFU ONT - SFP bias is higher than configured warn threshold <i>This element is only shown in detail mode.</i>
sfu-sup2-bias-lwarn	Parameter type: <Alarm::OntBiasWarnLow> (yes no) Possible values: - yes : bias at ont side is too low - no : bias at ont side is normal	SFU ONT - SFP bias is lower than configured warn threshold <i>This element is only shown in detail mode.</i>

102.102 SOHO ONT General Supplemental 2 Alarm Log Status Command

Command Description

This command displays the SOHO ONT general supplemental 2 alarm log status.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm log soho-sup2 [ (index) ]
```

Command Parameters

Table 102.102-1 "SOHO ONT General Supplemental 2 Alarm Log Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm type

Command Output

Table 102.102-2 "SOHO ONT General Supplemental 2 Alarm Log Status Command" Display parameters

Specific Information		
name	Type	Description
last-updated-on	Parameter type: <Sys::timeInSecs> - the time (yyyy-mm-dd:hour:minutes:secs) - unit: UTC	network time in seconds when the alarm was logged <i>This element is only shown in detail mode.</i>
ont	Parameter type: <Gpon::OntIndex> (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> ng2 : <Ng2::ChannelGroup> / <Ng2::SubchannelGroup> / <Ng2::OntId>) Possible values: - ng2 : ngpon2 style identification Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId>	identifies the ont entry <i>This element is only shown in detail mode.</i>

102 Alarm Log Status Commands

name	Type	Description
	- the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Ng2::ChannelGroup> - channel group number Field type <Ng2::SubchannelGroup> - subchannel group number Field type <Eqpt::OntId> - the ONT identifier Field type <Ng2::OntId> - the ONT identifier	

Only Show Details: current and previous alarm log status		
name	Type	Description
soho-sup2-temp-low	Parameter type: <Alarm::OntTempAlrmLow> (yes no) Possible values: - yes : temp at ont side is too low - no : temp at ont side is normal	SOHO ONT - SFP Temperature is higher than configured alarm high threshold <i>This element is only shown in detail mode.</i>
soho-sup2-volt-low	Parameter type: <Alarm::OntVoltAlrmLow> (yes no) Possible values: - yes : voltage at ont side is too low - no : voltage at ont side is normal	SOHO ONT - SFP Voltage is higher than configured alarm high threshold <i>This element is only shown in detail mode.</i>
soho-sup2-tx-high	Parameter type: <Alarm::OntTxPwrAlrmHigh> (yes no) Possible values: - yes : tx power at ont side is too high - no : tx power at ont side is normal	SOHO ONT - SFP tx power is higher than configured alarm high threshold <i>This element is only shown in detail mode.</i>
soho-sup2-bias-low	Parameter type: <Alarm::OntBiasAlrmLow> (yes no) Possible values: - yes : bias at ont side is too low - no : bias at ont side is normal	SOHO ONT - SFP Bias is lower than configured alarm low threshold <i>This element is only shown in detail mode.</i>
soho-sup2-rx-hwarn	Parameter type: <Alarm::OntRxPwrWarnHigh> (yes no) Possible values: - yes : rx power at ont side is too high - no : rx power at ont side is normal	SOHO ONT - SFP Rx power is higher than configured warn threshold <i>This element is only shown in detail mode.</i>
soho-sup2-rx-lwarn	Parameter type: <Alarm::OntRxPwrWarnLow> (yes no) Possible values: - yes : rx power at ont side is too low - no : rx power at ont side is normal	SOHO ONT - SFP Rx power is lower than configured warn threshold <i>This element is only shown in detail mode.</i>
soho-sup2-tx-hwarn	Parameter type: <Alarm::OntTxPwrWarnHigh> (yes no) Possible values: - yes : tx power at ont side is too high - no : tx power at ont side is normal	SOHO ONT - SFP Tx power is higher than configured warn threshold <i>This element is only shown in detail mode.</i>

name	Type	Description
soho-sup2-tx-lwarn	Parameter type: <Alarm::OntTxPwrWarnLow> (yes no) Possible values: - yes : tx power at ont side is too low - no : tx power at ont side is normal	SOHO ONT - SFP Tx power is lower than configured warn threshold <i>This element is only shown in detail mode.</i>
soho-sup2-temp-hwarn	Parameter type: <Alarm::OntTempWarnHigh> (yes no) Possible values: - yes : temp at ont side is too high - no : temp at ont side is normal	SOHO ONT - SFP temperature is higher than configured warn threshold <i>This element is only shown in detail mode.</i>
soho-sup2-temp-lwarn	Parameter type: <Alarm::OntTempWarnLow> (yes no) Possible values: - yes : temp at ont side is too low - no : temp at ont side is normal	SOHO ONT - SFP temperature is lower than configured warn threshold <i>This element is only shown in detail mode.</i>
soho-sup2-volt-hwarn	Parameter type: <Alarm::OntVoltWarnHigh> (yes no) Possible values: - yes : voltage at ont side is too high - no : voltage at ont side is normal	SOHO ONT - SFP voltage is higher than configured warn threshold <i>This element is only shown in detail mode.</i>
soho-sup2-volt-lwarn	Parameter type: <Alarm::OntVoltWarnLow> (yes no) Possible values: - yes : voltage at ont side is too low - no : voltage at ont side is normal	SOHO ONT - SFP voltage is lower than configured warn threshold <i>This element is only shown in detail mode.</i>
soho-sup2-bias-hwarn	Parameter type: <Alarm::OntBiasWarnHigh> (yes no) Possible values: - yes : bias at ont side is too high - no : bias at ont side is normal	SOHO ONT - SFP bias is higher than configured warn threshold <i>This element is only shown in detail mode.</i>
soho-sup2-bias-lwarn	Parameter type: <Alarm::OntBiasWarnLow> (yes no) Possible values: - yes : bias at ont side is too low - no : bias at ont side is normal	SOHO ONT - SFP bias is lower than configured warn threshold <i>This element is only shown in detail mode.</i>

102.103 MDU ONT General Supplemental 2 Alarm Log Status Command

Command Description

This command displays the MDU ONT general supplemental 2 alarm log status.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm log mdu-sup2 [ (index) ]
```

Command Parameters

Table 102.103-1 "MDU ONT General Supplemental 2 Alarm Log Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm type

Command Output

Table 102.103-2 "MDU ONT General Supplemental 2 Alarm Log Status Command" Display parameters

Specific Information		
name	Type	Description
last-updated-on	Parameter type: <Sys::timeInSecs> - the time (yyyy-mm-dd:hour:minutes:secs) - unit: UTC	network time in seconds when the alarm was logged <i>This element is only shown in detail mode.</i>
ont	Parameter type: <Gpon::OntIndex> (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> ng2 : <Ng2::ChannelGroup> / <Ng2::SubchannelGroup> / <Ng2::OntId>) Possible values: - ng2 : ngpon2 style identification Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId>	identifies the ont entry <i>This element is only shown in detail mode.</i>

name	Type	Description
	- the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Ng2::ChannelGroup> - channel group number Field type <Ng2::SubchannelGroup> - subchannel group number Field type <Eqpt::OntId> - the ONT identifier Field type <Ng2::OntId> - the ONT identifier	

Only Show Details: current and previous alarm log status		
name	Type	Description
mdu-sup2-temp-low	Parameter type: <Alarm::OntTempAlrmLow> (yes no) Possible values: - yes : temp at ont side is too low - no : temp at ont side is normal	MDU ONT - SFP Temperature is higher than configured alarm high threshold <i>This element is only shown in detail mode.</i>
mdu-sup2-volt-low	Parameter type: <Alarm::OntVoltAlrmLow> (yes no) Possible values: - yes : voltage at ont side is too low - no : voltage at ont side is normal	MDU ONT - SFP Voltage is higher than configured alarm high threshold <i>This element is only shown in detail mode.</i>
mdu-sup2-tx-high	Parameter type: <Alarm::OntTxPwrAlrmHigh> (yes no) Possible values: - yes : tx power at ont side is too high - no : tx power at ont side is normal	MDU ONT - SFP tx power is higher than configured alarm high threshold <i>This element is only shown in detail mode.</i>
mdu-sup2-bias-low	Parameter type: <Alarm::OntBiasAlrmLow> (yes no) Possible values: - yes : bias at ont side is too low - no : bias at ont side is normal	MDU ONT - SFP Bias is lower than configured alarm low threshold <i>This element is only shown in detail mode.</i>
mdu-sup2-rx-hwarn	Parameter type: <Alarm::OntRxPwrWarnHigh> (yes no) Possible values: - yes : rx power at ont side is too high - no : rx power at ont side is normal	MDU ONT - SFP Rx power is higher than configured warn threshold <i>This element is only shown in detail mode.</i>
mdu-sup2-rx-lwarn	Parameter type: <Alarm::OntRxPwrWarnLow> (yes no) Possible values: - yes : rx power at ont side is too low - no : rx power at ont side is normal	MDU ONT - SFP Rx power is lower than configured warn threshold <i>This element is only shown in detail mode.</i>
mdu-sup2-tx-hwarn	Parameter type: <Alarm::OntTxPwrWarnHigh> (yes no) Possible values: - yes : tx power at ont side is too high - no : tx power at ont side is normal	MDU ONT - SFP Tx power is higher than configured warn threshold <i>This element is only shown in detail mode.</i>

102 Alarm Log Status Commands

name	Type	Description
mdu-sup2-tx-lwarn	Parameter type: <Alarm::OntTxPwrWarnLow> (yes no) Possible values: - yes : tx power at ont side is too low - no : tx power at ont side is normal	MDU ONT - SFP Tx power is lower than configured warn threshold <i>This element is only shown in detail mode.</i>
mdu-sup2-temp-hwarn	Parameter type: <Alarm::OntTempWarnHigh> (yes no) Possible values: - yes : temp at ont side is too high - no : temp at ont side is normal	MDU ONT - SFP temperature is higher than configured warn threshold <i>This element is only shown in detail mode.</i>
mdu-sup2-temp-lwarn	Parameter type: <Alarm::OntTempWarnLow> (yes no) Possible values: - yes : temp at ont side is too low - no : temp at ont side is normal	MDU ONT - SFP temperature is lower than configured warn threshold <i>This element is only shown in detail mode.</i>
mdu-sup2-volt-hwarn	Parameter type: <Alarm::OntVoltWarnHigh> (yes no) Possible values: - yes : voltage at ont side is too high - no : voltage at ont side is normal	MDU ONT - SFP voltage is higher than configured warn threshold <i>This element is only shown in detail mode.</i>
mdu-sup2-volt-lwarn	Parameter type: <Alarm::OntVoltWarnLow> (yes no) Possible values: - yes : voltage at ont side is too low - no : voltage at ont side is normal	MDU ONT - SFP voltage is lower than configured warn threshold <i>This element is only shown in detail mode.</i>
mdu-sup2-bias-hwarn	Parameter type: <Alarm::OntBiasWarnHigh> (yes no) Possible values: - yes : bias at ont side is too high - no : bias at ont side is normal	MDU ONT - SFP bias is higher than configured warn threshold <i>This element is only shown in detail mode.</i>
mdu-sup2-bias-lwarn	Parameter type: <Alarm::OntBiasWarnLow> (yes no) Possible values: - yes : bias at ont side is too low - no : bias at ont side is normal	MDU ONT - SFP bias is lower than configured warn threshold <i>This element is only shown in detail mode.</i>

102.104 Ima-Group Alarm Log Status Command

Command Description

This command displays the Ima-Group alarm log status.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

> show alarm log epon [(alarm-index)]

Command Parameters

Table 102.104-1 "Ima-Group Alarm Log Status Command" Resource Parameters

Resource Identifier	Type	Description
(alarm-index)	Format: - index of a current alarm entry	alarm log table index

Command Output

Table 102.104-2 "Ima-Group Alarm Log Status Command" Display parameters

Specific Information		
name	Type	Description
last-updated-on	Parameter type: <Sys::timeInSecs> - the time (yyyy-mm-dd:hour:minutes:secs) - unit: UTC	network time in seconds when the alarm was logged. <i>This element is only shown in detail mode.</i>
pon-index	Parameter type: <Itf::ComplexPortType> (xdsl-line : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> voicefxs : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> xdsl-channel : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> atm-if : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> atm-pvc : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::VpiId> : <Eqpt::VciId> bridge-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::VpiId> : <Eqpt::VciId>	identifies the epon where the alarm has occurred. <i>This element is only shown in detail mode.</i>

name	Type	Description
	<pre> vlan-port:ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / <Eqpt::Ng2OntSlotId> / <Eqpt::Ng2OntPortId> : <Eqpt::UnstackedVlan> l2-vlan : <Eqpt::VlanId> ip : <Eqpt::LogicalId> sw-loopback slip uni:ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / <Eqpt::Ng2OntSlotId> / <Eqpt::Ng2OntPortId> vlan-port:ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / <Eqpt::Ng2OntSlotId> / <Eqpt::Ng2OntPortId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> atm-bonding : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> bonding : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> ip-gateway : <Eqpt::VrfId> ip-line : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::VpiId> : <Eqpt::VciId> ip-line : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> shdsl-line : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> e1-line : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> atm-ima : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> ethernet-line : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> bridge-port:ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / vuni vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::VpiId> : <Eqpt::VciId> : <Eqpt::UnstackedVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::UnstackedVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::VpiId> : <Eqpt::VciId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> voip:ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> ip-line : vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::VpiId> : <Eqpt::VciId> : <Eqpt::UnstackedVlan> ip-line : vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::UnstackedVlan> ip-line : vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::VpiId> : <Eqpt::VciId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> ip-line : vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : stacked : <Eqpt::SVlan> : </pre>	

name	Type	Description
	<pre> <Eqpt::CVlan> vlan-port:ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / vuni : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan-port:ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / vuni : <Eqpt::UnstackedVlan> chgroup : <Eqpt::ChannelGroupId> subchgroup : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> bridge-port:ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / <Eqpt::Ng2OntSlotId> / <Eqpt::Ng2OntPortId> atm-pvc : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> bridge-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> bridge-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> / <Eqpt::OntPortId> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> / <Eqpt::OntPortId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> / <Eqpt::OntPortId> : <Eqpt::UnstackedVlan> pon : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> ont : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> uni : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> / <Eqpt::OntPortId> bridge-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / voip bridge-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / vuni vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / voip : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / vuni : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / voip : <Eqpt::UnstackedVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / vuni : <Eqpt::UnstackedVlan> voip : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> la-group : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / </pre>	

name	Type	Description
	<pre> <Eqpt::LLId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> bridge-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::LLId> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::LLId> : <Eqpt::UnstackedVlan> mpm : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::ComboPonId> x-pon : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::XPonId> 25g-pon : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::M25GPonId> dist-router-interface : slot-stacked : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::SVlan> : <Eqpt::CVlan> dist-router-interface : slot-vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::UnstackedVlan> bundle : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::BundleId> chpair : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::ChannelPairId> ont.ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId>) Possible values: - xdsl-line : a static xdsl line interface - xdsl-channel : a static xdsl channel interface - atm-if : a static atm interface - atm-pvc : an atm pvc interface - bridge-port : a vlan bridge-port - bridge-port.ng2 : a ngpon2 vlan bridge-port - l2-vlan : a l2-vlan interface - ip : an ip interface - sw-loopback : a software loopback interface - slip : a slip interface - atm-bonding : atm bonding obsolete alternative replaced by bonding - bonding : bonding - ip-gateway : ip user gateway interface - ip-line : ip line interface - shdsl-line : a static shdsl line interface - e1-line : a e1 line interface - atm-ima : atm ima - ethernet-line : an ethernet line interface - vlan-port : vlan port - vlan-port.ng2 : a ngpon2 vlan port - pon : pon - x-pon : xgs pon - 25g-pon : 25g pon - chpair : channelpair - chgroup : channelgroup - subchgroup : subchannelgroup - bundle : bundle - ont : ont - ont.ng2 : ngpon2 ONT style identification - uni : uni - uni.ng2 : ngpon2 UNI style identification </pre>	

name	Type	Description
	- voip : voip - voip:ng2 : voip - la-group : link aggregation group - dist-router-interface : dist router interface - voicefxs : voicefxs - mpm : multi-pon module Possible values: - vlan : vlan port Possible values: - slot-vlan : slot unstacked - slot-stacked : slot vlan port Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number Field type <Eqpt::VpiId> - atm VPI Field type <Eqpt::VciId> - atm VCI Field type <Eqpt::PonId> - the PON identifier Field type <Eqpt::XPonId> - the XGS PON identifier Field type <Eqpt::M25GPonId> - the 25G PON identifier Field type <Eqpt::ComboPonId> - the comboPON identifier Field type <Eqpt::ChannelPairId> - the channel pair identifier Field type <Eqpt::ChannelGroupId> - the channel group identifier Field type <Eqpt::SubChannelGroupId> - the subchannel group identifier Field type <Eqpt::BundleId> - the BUNDLE identifier Field type <Eqpt::OntId> - the ONT identifier Field type <Eqpt::Ng2OntId> - the NG2 ONT identifier Possible values: - voip : virtual uni identifier obsolete alternative replaced by vuni - vuni : virtual uni identifier Possible values: - vuni : virtual NGPON2 uni identifier Field type <Eqpt::OntSlotId> - the ONT SLOT identifier Field type <Eqpt::OntPortId> - the ONT PORT identifier Field type <Eqpt::Ng2OntSlotId> - the NGPON2 ONT SLOT identifier Field type <Eqpt::Ng2OntPortId> - the NGPON2 ONT PORT identifier	

102 Alarm Log Status Commands

name	Type	Description
	Field type <Eqpt::LLId> - the LLID identifier, range 1 for EPON, range 1-8 for DPOE Possible values: - stacked : stacked vlan identity Field type <Eqpt::UnstackedVlan> - unstacked vlan id Field type <Eqpt::SVlan> - service vlan id Field type <Eqpt::CVlan> - customer vlan id Field type <Eqpt::VlanId> - VLAN id Field type <Eqpt::LogicalId> - logical id Field type <Eqpt::VrflId> - VRF id	
newonu-index	Parameter type: <SignedInteger> - a signed integer	the newonu index for the pon alarm <i>This element is only shown in detail mode.</i>
log-info	Parameter type: <Alarm::AdditionalInfo> - string to identify the owner (example: Tom) - length: x<=512	some additional information about the table entry. <i>This element is only shown in detail mode.</i>
newont-mac	Parameter type: <Alarm::MacAddr> - mac-address (example : 01:02:03:04:05:06) - length: 6	new ONT Mac address <i>This element is only shown in detail mode.</i>

Only Show Details: current and previous alarm log status		
name	Type	Description
onu-unprovisioned	Parameter type: <Alarm::checkNewOnu> (newonu not-newonu) Possible values: - newonu : new onu is exist - not-newonu : new onu is not exist	new onu is exist or not. <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::checkNewOnu> (newonu not-newonu) Possible values: - newonu : new onu is exist - not-newonu : new onu is not exist	new onu is exist or not with its previous logged value <i>This element is only shown in detail mode.</i>
signal-loss	Parameter type: <Alarm::NearEndLOF> (yes no) Possible values: - yes : near end loss of frame occurred - no : no near end loss of frame	pon loss of signal.olt is not receiving any upstream transmissions. <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::NearEndLOF> (yes no) Possible values: - yes : near end loss of frame occurred - no : no near end loss of frame	status of pon loss of signal with its previous logged value <i>This element is only shown in detail mode.</i>
bitrate-high	Parameter type: <Alarm::errorRateHigh> (yes no) Possible values:	the error bit rate high at pon interface is reached or not <i>This element is only shown in detail mode.</i>

name	Type	Description
	- yes : the error bit rate is too high than configured alarm high threshold - no : the error bit rate is ok	
prev-status	Parameter type: <Alarm::errorRateHigh> (yes no) Possible values: - yes : the error bit rate is too high than configured alarm high threshold - no : the error bit rate is ok	status of the error bit rate high with its previous logged value <i>This element is only shown in detail mode.</i>
opmodule-mismatch	Parameter type: <Alarm::opmoduleTypeMismatch> (mismatch no-mismatch) Possible values: - mismatch : installed and planned shelf types are different - no-mismatch : installed and planned shelf types are the same	the optical module mismatched at pon interface failed or not. <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::opmoduleTypeMismatch> (mismatch no-mismatch) Possible values: - mismatch : installed and planned shelf types are different - no-mismatch : installed and planned shelf types are the same	status of the optical module mismatched at pon interface with its previous logged value <i>This element is only shown in detail mode.</i>

102.105 LT CFM Alarm Log Status Command

Command Description

This command displays icam cfm alarm log status.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm log cfm [ (index) ]
```

Command Parameters

Table 102.105-1 "LT CFM Alarm Log Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm log table index

Command Output

Table 102.105-2 "LT CFM Alarm Log Status Command" Display parameters

Specific Information		
name	Type	Description
last-updated-on	Parameter type: <Sys::timeInSecs> - the time (yyyy-mm-dd:hour:minutes:secs) - unit: UTC	network time in seconds when the alarm was logged <i>This element is only shown in detail mode.</i>
cfm-mep-id	Parameter type: <UnsignedSignedInteger> - an unsigned integer	dot1agCfmMepIdentifier index where the alarm has occurred. <i>This element is only shown in detail mode.</i>
cfm-unique-id	Parameter type: <Alarm::IdentificationIdxOrZero> - a signed integer	unique identification for the alarm or zero when not applicable, alarm entry is further specified in additional-info <i>This element is only shown in detail mode.</i>
additional-info	Parameter type: <Alarm::AddInfoStringCcm> - additional alarm information	Additional information regarding the cfm alarm <i>This element is only shown in detail mode.</i>

Only Show Details: current and previous alarm log status

name	Type	Description
cfm-defrdiccm	Parameter type: <Alarm::IacmCfmRdiCcm> (yes no) Possible values: - yes : rdi bit in ccm received - no : no rdi bit in ccm received	specifies rdi bit in ccm received <i>This element is only shown in detail mode.</i>
cfm-defmacstatus	Parameter type: <Alarm::IacmCfmMacError> (yes no) Possible values: - yes : mac error status - no : no mac error status	ccm mac error status <i>This element is only shown in detail mode.</i>
cfm-defremoteccm	Parameter type: <Alarm::IacmCfmMepCcm> (yes no) Possible values: - yes : missing ccm from mep - no : no missing ccm from mep	specifies missing ccm from mep <i>This element is only shown in detail mode.</i>
cfm-deferrorccm	Parameter type: <Alarm::IacmCfmInvalidCcm> (yes no) Possible values: - yes : invalid ccm received - no : no invalid ccm received	specifies invalid ccm received <i>This element is only shown in detail mode.</i>
cfm-defxconccm	Parameter type: <Alarm::IacmCfmUnexpectedCcm> (yes no) Possible values: - yes : unexpected ccm received - no : no unexpected ccm received	specifies unexpected ccm received <i>This element is only shown in detail mode.</i>
cfm-defais	Parameter type: <Alarm::IacmCfmAis> (yes no) Possible values: - yes : ethernet ais received - no : no ethernet ais received	specifies ethernet ais received <i>This element is only shown in detail mode.</i>

102.106 IHUB CFM Alarm Log Status Command

Command Description

This command displays ihub cfm alarm log status.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm log eth-cfm [ (index) ]
```

Command Parameters

Table 102.106-1 "IHUB CFM Alarm Log Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm log table index

Command Output

Table 102.106-2 "IHUB CFM Alarm Log Status Command" Display parameters

Specific Information		
name	Type	Description
last-updated-on	Parameter type: <Sys::timeInSecs> - the time (yyyy-mm-dd:hour:minutes:secs) - unit: UTC	network time in seconds when the alarm was logged <i>This element is only shown in detail mode.</i>
cfm-mep-id	Parameter type: <UnsignedSignedInteger> - an unsigned integer	dot1agCfmMepIdentifier index where the alarm has occurred. <i>This element is only shown in detail mode.</i>
cfm-unique-id	Parameter type: <Alarm::IdentificationIdxOrZero> - a signed integer	unique identification for the alarm or zero when not applicable, alarm entry is further specified in additional-info <i>This element is only shown in detail mode.</i>
additional-info	Parameter type: <Alarm::AddInfoStringIhubCfm> - additional alarm information	Additional information regarding the eth cfm alarm <i>This element is only shown in detail mode.</i>

Only Show Details: current and previous alarm log status

name	Type	Description
defrdiccm	Parameter type: <Alarm::IhubCfmRdiCcm> (yes no) Possible values: - yes : rdi bit in ccm received - no : no rdi bit in ccm received	specifies rdi bit in ccm received <i>This element is only shown in detail mode.</i>
defmacstatus	Parameter type: <Alarm::IhubCfmMacError> (yes no) Possible values: - yes : mac error status - no : no mac error status	ccm mac error status <i>This element is only shown in detail mode.</i>
defremoteccm	Parameter type: <Alarm::IhubCfmMepCcm> (yes no) Possible values: - yes : missing ccm from mep - no : no missing ccm from mep	specifies missing ccm from mep <i>This element is only shown in detail mode.</i>
deferrorccm	Parameter type: <Alarm::IhubCfmInvalidCcm> (yes no) Possible values: - yes : invalid ccm received - no : no invalid ccm received	specifies invalid ccm received <i>This element is only shown in detail mode.</i>
defxconccm	Parameter type: <Alarm::IhubCfmUnexpectedCcm> (yes no) Possible values: - yes : unexpected ccm received - no : no unexpected ccm received	specifies unexpected ccm received <i>This element is only shown in detail mode.</i>

102.107 RSVP Alarm Log Status Command

Command Description

This command displays the rsvp alarm log status.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm log rsvp [ (index) ]
```

Command Parameters

Table 102.107-1 "RSVP Alarm Log Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm log table index

Command Output

Table 102.107-2 "RSVP Alarm Log Status Command" Display parameters

Specific Information		
name	Type	Description
last-updated-on	Parameter type: <Sys::timeInSecs> - the time (yyyy-mm-dd:hour:minutes:secs) - unit: UTC	network time in seconds when the alarm was logged <i>This element is only shown in detail mode.</i>
router-id	Parameter type: <Ihub::baseRouter> base Possible values: - base : base router	identifies the base router <i>This element is only shown in detail mode.</i>
neighbor-index	Parameter type: <Alarm::IdentificationIdxOrZero> - a signed integer	An unique number to identify the alarm or zero when not applicable, Neighbor is further specified in additional-info <i>This element is only shown in detail mode.</i>
additional-info	Parameter type: <Alarm::AddInfoString> - additional alarm information	identifies the Neighbor using the Nbr address and ifIndex or empty string if not applicable <i>This element is only shown in detail mode.</i>

Only Show Details: current and previous alarm log status		
name	Type	Description
neighbor-down	Parameter type: <Alarm::RsvpNeighborDown> (yes no) Possible values: - yes : rsvp neighbor is down - no : rsvp neighbor is up or rsvp interface is shutdown or ip interface is shutdown or rsvp instance is shutdown	specifies whether the Rsvp neighbor is down or not <i>This element is only shown in detail mode.</i>
prev-neighbor-down	Parameter type: <Alarm::RsvpNeighborDown> (yes no) Possible values: - yes : rsvp neighbor is down - no : rsvp neighbor is up or rsvp interface is shutdown or ip interface is shutdown or rsvp instance is shutdown	status of neighbor-down with its previous logged value <i>This element is only shown in detail mode.</i>
instance-down	Parameter type: <Alarm::RsvpInstanceDown> (yes no) Possible values: - yes : rsvp instance is down - no : rsvp instance is up or not configured	specifies whether the RSVP instance is down or not <i>This element is only shown in detail mode.</i>
prev-instance-down	Parameter type: <Alarm::RsvpInstanceDown> (yes no) Possible values: - yes : rsvp instance is down - no : rsvp instance is up or not configured	status of instance-down with its previous logged value <i>This element is only shown in detail mode.</i>

102.108 IPD eth-ring Alarm Log Status Command

Command Description

This command displays the ipd eth-ring alarm log status.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

> show alarm log eth-ring [(index)]

Command Parameters

Table 102.108-1 "IPD eth-ring Alarm Log Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm log table index

Command Output

Table 102.108-2 "IPD eth-ring Alarm Log Status Command" Display parameters

Specific Information		
name	Type	Description
last-updated-on	Parameter type: <Sys::timeInSecs> - the time (yyyy-mm-dd:hour:minutes:secs) - unit: UTC	network time in seconds when the alarm was logged <i>This element is only shown in detail mode.</i>
ring-id	Parameter type: <Alarm::genAlarmIndex> - index of a current alarm entry	identifies the eth-ring-instance <i>This element is only shown in detail mode.</i>
ring path-index	Parameter type: <Alarm::genAlarmIndex> - index of a current alarm entry	identifies the ring-path within a eth-ring <i>This element is only shown in detail mode.</i>

Only Show Details: current and previous alarm log status		
name	Type	Description
ering-path-blocked	Parameter type: <Alarm::EthRingPathBlocked> (yes no) Possible values: - yes : ethernet ring path is blocked - no : ethernet ring path is unblocked	specifies whether a eth-ring path is blocked or not <i>This element is only shown in detail mode.</i>

name	Type	Description
prev-ering-path-block	Parameter type: <Alarm::EthRingPathBlocked> (yes no) Possible values: - yes : ethernet ring path is blocked - no : ethernet ring path is unblocked	status of eth-ring path blocked state with its previous logged value <i>This element is only shown in detail mode.</i>

102.109 EFM-OAM Alarm Log Status Command

Command Description

This command displays the EFM-OAM alarm log status.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm log efm-oam [ (index) ]
```

Command Parameters

Table 102.109-1 "EFM-OAM Alarm Log Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm log table index

Command Output

Table 102.109-2 "EFM-OAM Alarm Log Status Command" Display parameters

Specific Information		
name	Type	Description
last-updated-on	Parameter type: <Sys::timeInSecs> - the time (yyyy-mm-dd:hour:minutes:secs) - unit: UTC	network time in seconds when the alarm was logged. <i>This element is only shown in detail mode.</i>
line	Parameter type: <Itf::EfmEthernetIndex> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number	identifies the physical xdsl line <i>This element is only shown in detail mode.</i>

Only Show Details: current and previous alarm log status		
name	Type	Description
link-fault	Parameter type: <Alarm::linkFaultType> (yes	specifies whether link fault is present or not.

name	Type	Description
	no) Possible values: - yes : link fault at cpe/onu - no : link fault is not exist	<i>This element is only shown in detail mode.</i>
prev-link-fault	Parameter type: <Alarm::linkFaultType> (yes no) Possible values: - yes : link fault at cpe/onu - no : link fault is not exist	status of link-fault with its previous logged value. <i>This element is only shown in detail mode.</i>
dying-gasp	Parameter type: <Alarm::dyingGaspType> (yes no) Possible values: - yes : dying gasp is exist - no : dying gasp is not exist	specifies whether dying gasp indication is received from cpe or not. <i>This element is only shown in detail mode.</i>
prev-dying-gasp	Parameter type: <Alarm::dyingGaspType> (yes no) Possible values: - yes : dying gasp is exist - no : dying gasp is not exist	status of dying-gasp with its previous logged value. <i>This element is only shown in detail mode.</i>
critical-event	Parameter type: <Alarm::criticalEventType> (yes no) Possible values: - yes : critical event is exist - no : critical event is not exist	specifies whether critical event is received from cpe or not. <i>This element is only shown in detail mode.</i>
prev-critical-event	Parameter type: <Alarm::criticalEventType> (yes no) Possible values: - yes : critical event is exist - no : critical event is not exist	status of critical-event with its previous logged value. <i>This element is only shown in detail mode.</i>

102.110 ont loop detect Alarm Log Status Command

Command Description

This command displays the ont loop detect alarm log status.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm log ont-loopdetect [ (index) ]
```

Command Parameters

Table 102.110-1 "ont loop detect Alarm Log Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm type

Command Output

Table 102.110-2 "ont loop detect Alarm Log Status Command" Display parameters

Specific Information		
name	Type	Description
last-updated-on	Parameter type: <Sys::timeInSecs> - the time (yyyy-mm-dd:hour:minutes:secs) - unit: UTC	network time in seconds when the alarm was logged <i>This element is only shown in detail mode.</i>
ont	Parameter type: <Gpon::OntIndex> (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> ng2 : <Ng2::ChannelGroup> / <Ng2::SubchannelGroup> / <Ng2::OntId>) Possible values: - ng2 : ngpon2 style identification Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId>	identifies the ont entry <i>This element is only shown in detail mode.</i>

name	Type	Description
	- the LT slot number - Field type <Eqpt::PonId> - the PON identifier - Field type <Ng2::ChannelGroup> - channel group number - Field type <Ng2::SubchannelGroup> - subchannel group number - Field type <Eqpt::OntId> - the ONT identifier - Field type <Ng2::OntId> - the ONT identifier	
ont-loopdetect	Parameter type: <Alarm::OntLoopDetectPortNumber> (port 1 looped port 2 looped port 3 looped port 4 looped port 5 looped port 6 looped port 7 looped port 8 looped port 9 looped port 10 looped port 11 looped port 12 looped port 13 looped port 14 looped port 15 looped port 16 looped port 17 looped port 18 looped port 19 looped port 20 looped port 21 looped port 22 looped port 23 looped port 24 looped) Possible values: - port 1 looped : ont port loop occurred - port 2 looped : ont port loop occurred - port 3 looped : ont port loop occurred - port 4 looped : ont port loop occurred - port 5 looped : ont port loop occurred - port 6 looped : ont port loop occurred - port 7 looped : ont port loop occurred - port 8 looped : ont port loop occurred - port 9 looped : ont port loop occurred - port 10 looped : ont port loop occurred - port 11 looped : ont port loop occurred - port 12 looped : ont port loop occurred - port 13 looped : ont port loop occurred - port 14 looped : ont port loop occurred - port 15 looped : ont port loop occurred - port 16 looped : ont port loop occurred - port 17 looped : ont port loop occurred - port 18 looped : ont port loop occurred - port 19 looped : ont port loop occurred - port 20 looped : ont port loop occurred	identifies the ont entry <i>This element is only shown in detail mode.</i>

102 Alarm Log Status Commands

name	Type	Description
	- port 21 looped : ont port loop occurred - port 22 looped : ont port loop occurred - port 23 looped : ont port loop occurred - port 24 looped : ont port loop occurred	

102.111 ONT PLOAM Alarm Log Status Command

Command Description

This command displays the ONT PLOAM alarm log status.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

> show alarm log ont-ploam [(index)]

Command Parameters

Table 102.111-1 "ONT PLOAM Alarm Log Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm log table index

Command Output

Table 102.111-2 "ONT PLOAM Alarm Log Status Command" Display parameters

Specific Information		
name	Type	Description
last-updated-on	Parameter type: <Sys::timeInSecs> - the time (yyyy-mm-dd:hour:minutes:secs) - unit: UTC	network time in seconds when the alarm was logged <i>This element is only shown in detail mode.</i>
ont	Parameter type: <Gpon::OntIndex> (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> ng2 : <Ng2::ChannelGroup> / <Ng2::SubchannelGroup> / <Ng2::OntId>) Possible values: - ng2 : ngpon2 style identification Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier	gpon ont equipment ifindex of ont <i>This element is only shown in detail mode.</i>

102 Alarm Log Status Commands

name	Type	Description
	Field type <Ng2::ChannelGroup> - channel group number Field type <Ng2::SubchannelGroup> - subchannel group number Field type <Eqpt::OntId> - the ONT identifier Field type <Ng2::OntId> - the ONT identifier	

Only Show Details: current alarm status		
name	Type	Description
ont-ploam-loss-sig	Parameter type: <Alarm::ONTPLOAMLOSO> (yes no) Possible values: - yes : loss of signal at ont - no : no loss of signal at ont	loss of signal at ont <i>This element is only shown in detail mode.</i>
ont-ploam-loss-ack	Parameter type: <Alarm::ONTPLOAMLOA> (yes no) Possible values: - yes : loss of acknowledge from ont - no : no loss of acknowledge from ont	loss of acknowledge from ont <i>This element is only shown in detail mode.</i>
ont-ploam-loss-cd	Parameter type: <Alarm::ONTPLOAMLCD> (yes no) Possible values: - yes : loss of gem/atm channel delineation of ont - no : gem/atm channel delineation of ont is normal	loss of gem/atm channel delineation of ont <i>This element is only shown in detail mode.</i>
ont-ploam-phy-eqpt-err	Parameter type: <Alarm::ONTPLOAMPEE> (yes no) Possible values: - yes : physical equipment error of ont - no : no physical equipment error of ont	physical equipment error of ont <i>This element is only shown in detail mode.</i>
ont-ploam-startup-fail	Parameter type: <Alarm::ONTPLOAMSUF> (yes no) Possible values: - yes : startup failure in ranging of ont - no : no startup failure in ranging of ont	startup failure in ranging of ont <i>This element is only shown in detail mode.</i>
ont-ploam-sig-degrade	Parameter type: <Alarm::ONTPLOAMSD> (yes no) Possible values: - yes : signal degrade ber threshold exceeded from ont - no : signal degrade ber threshold is normal	signal degrade ber threshold exceeded from ont <i>This element is only shown in detail mode.</i>
ont-ploam-disabled	Parameter type: <Alarm::ONTPLOAMONTDisabled> (yes no) Possible values: - yes : ont has been autonomously disabled - no : ont is enabled	ont has been autonomously disabled because of misbehaving transmissions <i>This element is only shown in detail mode.</i>
ont-ploam-err-msg	Parameter type: <Alarm::ONTPLOAMMEM> (yes no) Possible values: - yes : message error message from ont	message error message from ont <i>This element is only shown in detail mode.</i>

name	Type	Description
	- no : no message error message from ont	
ont-ploam-inactive	Parameter type: <Alarm::ONTPLOAMInact> (yes no) Possible values: - yes : ont is inactive - no : ont is active	ont is inactive <i>This element is only shown in detail mode.</i>
ont-ploam-sig-fail	Parameter type: <Alarm::ONTPLOAMSF> (yes no) Possible values: - yes : signal fail ber threshold exceeded from ont - no : no signal fail ber threshold exceeded from ont	signal fail ber threshold exceeded from ont <i>This element is only shown in detail mode.</i>
ont-ploam-dying-gasp	Parameter type: <Alarm::ONTPLOAMDG> (yes no) Possible values: - yes : received dying gasp indication from ont - no : no received dying gasp indication from ont	received dying gasp indication from ont <i>This element is only shown in detail mode.</i>
ont-ploam-deact-fail	Parameter type: <Alarm::ONTPLOAMDF> (yes no) Possible values: - yes : deactivate failure of ont - no : no deactivate failure of ont	deactivate failure of ont <i>This element is only shown in detail mode.</i>
ont-ploam-oam	Parameter type: <Alarm::ONTPLOAMLOAM> (yes no) Possible values: - yes : loss of ploam for ont - no : no Loss of ploam for ont	loss of ploam for ont <i>This element is only shown in detail mode.</i>
ont-ploam-win-drift	Parameter type: <Alarm::ONTPLOAMDOW> (yes no) Possible values: - yes : drift of window - no : no drift of window	drift of window. <i>This element is only shown in detail mode.</i>
ont-ploam-rdi	Parameter type: <Alarm::ONTPLOAMRDI> (yes no) Possible values: - yes : remote defect indication from ont - no : no remote defect indication from ont	remote defect indication from ont. <i>This element is only shown in detail mode.</i>
ont-ploam-loss-ks	Parameter type: <Alarm::ONTPLOAMLOKS> (yes no) Possible values: - yes : loss of key synchronization between olt and ont - no : key synchronization between olt and ont is ok	loss of key synchronization between olt and ont <i>This element is only shown in detail mode.</i>
ont-ploam-pwr-burst	Parameter type: <Alarm::ONTPLOAMONTPWREERR> (yes no) Possible values: - yes : ont power up error - no : ont power up ok	ont power up error. <i>This element is only shown in detail mode.</i>
ont-ploam-rog-disa	Parameter type: <Alarm::ONTPLOAMROGUEONTDIS> (yes	ont has been autonomously disabled because of misbehaving

102 Alarm Log Status Commands

name	Type	Description
	no) Possible values: - yes : ont has been autonomously disabled to be a rogue ont - no : ont is normal	transmissions and is thought to be a rogue ont. <i>This element is only shown in detail mode.</i>
ont-ploam-diff-reach	Parameter type: <Alarm::ONTPLOAMDIFREACH> (yes no) Possible values: - yes : ont has been deactivated because its location on the pon has exceeded its differential reach capability - no : ont is normal	ont has been deactivated because its location on the pon has exceeded its differential reach capability. <i>This element is only shown in detail mode.</i>
ont-ploam-looc	Parameter type: <Alarm::ONTPLOAMLOOC> (yes no) Possible values: - yes : ont has been deactivated due to persistent OMCI MIC failure - no : ont is normal	ont has been deactivated due to persistent OMCI MIC failure. <i>This element is only shown in detail mode.</i>

102.112 SFU ONT PLOAM Alarm Log Status Command

Command Description

This command displays the SFU ONT PLOAM alarm log status.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm log sfu-ploam [ (index) ]
```

Command Parameters

Table 102.112-1 "SFU ONT PLOAM Alarm Log Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm log table index

Command Output

Table 102.112-2 "SFU ONT PLOAM Alarm Log Status Command" Display parameters

Specific Information		
name	Type	Description
last-updated-on	Parameter type: <Sys::timeInSecs> - the time (yyyy-mm-dd:hour:minutes:secs) - unit: UTC	network time in seconds when the alarm was logged <i>This element is only shown in detail mode.</i>
ont	Parameter type: <Gpon::OntIndex> (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> ng2 : <Ng2::ChannelGroup> / <Ng2::SubchannelGroup> / <Ng2::OntId>) Possible values: - ng2 : ngpon2 style identification Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId>	gpon ont equipment ifindex of ont <i>This element is only shown in detail mode.</i>

102 Alarm Log Status Commands

name	Type	Description
	- the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Ng2::ChannelGroup> - channel group number Field type <Ng2::SubchannelGroup> - subchannel group number Field type <Eqpt::OntId> - the ONT identifier Field type <Ng2::OntId> - the ONT identifier	

Only Show Details: current alarm status		
name	Type	Description
sfu-ploam-loss-sig	Parameter type: <Alarm::ONTPLOAMLOSO> (yes no) Possible values: - yes : loss of signal at ont - no : no loss of signal at ont	loss of signal at ont <i>This element is only shown in detail mode.</i>
sfu-ploam-loss-ack	Parameter type: <Alarm::ONTPLOAMLOA> (yes no) Possible values: - yes : loss of acknowledge from ont - no : no loss of acknowledge from ont	loss of acknowledge from ont <i>This element is only shown in detail mode.</i>
sfu-ploam-loss-cd	Parameter type: <Alarm::ONTPLOAMLCD> (yes no) Possible values: - yes : loss of gem/atm channel delineation of ont - no : gem/atm channel delineation of ont is normal	loss of gem/atm channel delineation of ont <i>This element is only shown in detail mode.</i>
sfu-ploam-phy-eqpt-err	Parameter type: <Alarm::ONTPLOAMPEE> (yes no) Possible values: - yes : physical equipment error of ont - no : no physical equipment error of ont	physical equipment error of ont <i>This element is only shown in detail mode.</i>
sfu-ploam-startup-fail	Parameter type: <Alarm::ONTPLOAMSUF> (yes no) Possible values: - yes : startup failure in ranging of ont - no : no startup failure in ranging of ont	startup failure in ranging of ont <i>This element is only shown in detail mode.</i>
sfu-ploam-sig-degrade	Parameter type: <Alarm::ONTPLOAMSD> (yes no) Possible values: - yes : signal degrade ber threshold exceeded from ont - no : signal degrade ber threshold is normal	signal degrade ber threshold exceeded from ont <i>This element is only shown in detail mode.</i>
sfu-ploam-disabled	Parameter type: <Alarm::ONTPLOAMONTDisabled> (yes no) Possible values: - yes : ont has been autonomously disabled - no : ont is enabled	ont has been autonomously disabled because of misbehaving transmissions <i>This element is only shown in detail mode.</i>
sfu-ploam-err-msg	Parameter type: <Alarm::ONTPLOAMMEM> (yes	message error message from ont <i>This element is only shown in</i>

name	Type	Description
	no) Possible values: - yes : message error message from ont - no : no message error message from ont	detail mode.
sfu-ploam-inactive	Parameter type: <Alarm::ONTPLOAMInact> (yes no) Possible values: - yes : ont is inactive - no : ont is active	ont is inactive <i>This element is only shown in detail mode.</i>
sfu-ploam-sig-fail	Parameter type: <Alarm::ONTPLOAMSF> (yes no) Possible values: - yes : signal fail ber threshold exceeded from ont - no : no signal fail ber threshold exceeded from ont	signal fail ber threshold exceeded from ont <i>This element is only shown in detail mode.</i>
sfu-ploam-dying-gasp	Parameter type: <Alarm::ONTPLOAMDG> (yes no) Possible values: - yes : received dying gasp indication from ont - no : no received dying gasp indication from ont	received dying gasp indication from ont <i>This element is only shown in detail mode.</i>
sfu-ploam-deact-fail	Parameter type: <Alarm::ONTPLOAMDF> (yes no) Possible values: - yes : deactivate failure of ont - no : no deactivate failure of ont	deactivate failure of ont <i>This element is only shown in detail mode.</i>
sfu-ploam-oam	Parameter type: <Alarm::ONTPLOAMLOAM> (yes no) Possible values: - yes : loss of ploam for ont - no : no Loss of ploam for ont	loss of ploam for ont <i>This element is only shown in detail mode.</i>
sfu-ploam-win-drift	Parameter type: <Alarm::ONTPLOAMDOW> (yes no) Possible values: - yes : drift of window - no : no drift of window	drift of window. <i>This element is only shown in detail mode.</i>
sfu-ploam-rdi	Parameter type: <Alarm::ONTPLOAMRDI> (yes no) Possible values: - yes : remote defect indication from ont - no : no remote defect indication from ont	remote defect indication from ont. <i>This element is only shown in detail mode.</i>
sfu-ploam-loss-ks	Parameter type: <Alarm::ONTPLOAMLOKS> (yes no) Possible values: - yes : loss of key synchronization between olt and ont - no : key synchronization between olt and ont is ok	loss of key synchronization between olt and ont <i>This element is only shown in detail mode.</i>
sfu-ploam-pwr-burst	Parameter type: <Alarm::ONTPLOAMONTPWRERR> (yes no) Possible values: - yes : ont power up error	ont power up error. <i>This element is only shown in detail mode.</i>

102 Alarm Log Status Commands

name	Type	Description
	- no : ont power up ok	
sfu-ploam-rog-disa	Parameter type: <Alarm::ONTPLOAMROGUEONTDIS> (yes no) Possible values: - yes : ont has been autonomously disabled to be a rogue ont - no : ont is normal	ont has been autonomously disabled because of misbehaving transmissions and is thought to be a rogue ont. <i>This element is only shown in detail mode.</i>
sfu-ploam-diff-reach	Parameter type: <Alarm::ONTPLOAMDIFREACH> (yes no) Possible values: - yes : ont has been deactivated because its location on the pon has exceeded its differential reach capability - no : ont is normal	ont has been deactivated because its location on the pon has exceeded its differential reach capability. <i>This element is only shown in detail mode.</i>
sfu-ploam-looc	Parameter type: <Alarm::ONTPLOAMLOOC> (yes no) Possible values: - yes : ont has been deactivated due to persistent OMCI MIC failure - no : ont is normal	ont has been deactivated due to persistent OMCI MIC failure. <i>This element is only shown in detail mode.</i>

102.113 SOHO ONT PLOAM Alarm Log Status Command

Command Description

This command displays the SOHO ONT PLOAM alarm log status.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm log soho-ploam [ (index) ]
```

Command Parameters

Table 102.113-1 "SOHO ONT PLOAM Alarm Log Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm log table index

Command Output

Table 102.113-2 "SOHO ONT PLOAM Alarm Log Status Command" Display parameters

Specific Information		
name	Type	Description
last-updated-on	Parameter type: <Sys::timeInSecs> - the time (yyyy-mm-dd:hour:minutes:secs) - unit: UTC	network time in seconds when the alarm was logged <i>This element is only shown in detail mode.</i>
ont	Parameter type: <Gpon::OntIndex> (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> ng2 : <Ng2::ChannelGroup> / <Ng2::SubchannelGroup> / <Ng2::OntId>) Possible values: - ng2 : ngpon2 style identification Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId>	gpon ont equipment ifindex of ont <i>This element is only shown in detail mode.</i>

102 Alarm Log Status Commands

name	Type	Description
	- the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Ng2::ChannelGroup> - channel group number Field type <Ng2::SubchannelGroup> - subchannel group number Field type <Eqpt::OntId> - the ONT identifier Field type <Ng2::OntId> - the ONT identifier	

Only Show Details: current alarm status		
name	Type	Description
soho-ploam-loss-sig	Parameter type: <Alarm::ONTPLOAMLOSO> (yes no) Possible values: - yes : loss of signal at ont - no : no loss of signal at ont	loss of signal at ont <i>This element is only shown in detail mode.</i>
soho-ploam-loss-ack	Parameter type: <Alarm::ONTPLOAMLOA> (yes no) Possible values: - yes : loss of acknowledge from ont - no : no loss of acknowledge from ont	loss of acknowledge from ont <i>This element is only shown in detail mode.</i>
soho-ploam-loss-cd	Parameter type: <Alarm::ONTPLOAMLCD> (yes no) Possible values: - yes : loss of gem/atm channel delineation of ont - no : gem/atm channel delineation of ont is normal	loss of gem/atm channel delineation of ont <i>This element is only shown in detail mode.</i>
soho-ploam-phy-eqpt-er	Parameter type: <Alarm::ONTPLOAMPEE> (yes no) Possible values: - yes : physical equipment error of ont - no : no physical equipment error of ont	physical equipment error of ont <i>This element is only shown in detail mode.</i>
soho-ploam-startup-fai	Parameter type: <Alarm::ONTPLOAMSUF> (yes no) Possible values: - yes : startup failure in ranging of ont - no : no startup failure in ranging of ont	startup failure in ranging of ont <i>This element is only shown in detail mode.</i>
soho-ploam-sig-degrade	Parameter type: <Alarm::ONTPLOAMSD> (yes no) Possible values: - yes : signal degrade ber threshold exceeded from ont - no : signal degrade ber threshold is normal	signal degrade ber threshold exceeded from ont <i>This element is only shown in detail mode.</i>
soho-ploam-disabled	Parameter type: <Alarm::ONTPLOAMONTDisabled> (yes no) Possible values: - yes : ont has been autonomously disabled - no : ont is enabled	ont has been autonomously disabled because of misbehaving transmissions <i>This element is only shown in detail mode.</i>
soho-ploam-err-msg	Parameter type: <Alarm::ONTPLOAMMEM> (yes	message error message from ont <i>This element is only shown in</i>

name	Type	Description
	no) Possible values: - yes : message error message from ont - no : no message error message from ont	detail mode.
soho-ploam-inactive	Parameter type: <Alarm::ONTPLOAMInact> (yes no) Possible values: - yes : ont is inactive - no : ont is active	ont is inactive <i>This element is only shown in detail mode.</i>
soho-ploam-sig-fail	Parameter type: <Alarm::ONTPLOAMSF> (yes no) Possible values: - yes : signal fail ber threshold exceeded from ont - no : no signal fail ber threshold exceeded from ont	signal fail ber threshold exceeded from ont <i>This element is only shown in detail mode.</i>
soho-ploam-dying-gasp	Parameter type: <Alarm::ONTPLOAMDG> (yes no) Possible values: - yes : received dying gasp indication from ont - no : no received dying gasp indication from ont	received dying gasp indication from ont <i>This element is only shown in detail mode.</i>
soho-ploam-deact-fail	Parameter type: <Alarm::ONTPLOAMDF> (yes no) Possible values: - yes : deactivate failure of ont - no : no deactivate failure of ont	deactivate failure of ont <i>This element is only shown in detail mode.</i>
soho-ploam-oam	Parameter type: <Alarm::ONTPLOAMLOAM> (yes no) Possible values: - yes : loss of ploam for ont - no : no Loss of ploam for ont	loss of ploam for ont <i>This element is only shown in detail mode.</i>
soho-ploam-win-drift	Parameter type: <Alarm::ONTPLOAMDOW> (yes no) Possible values: - yes : drift of window - no : no drift of window	drift of window. <i>This element is only shown in detail mode.</i>
soho-ploam-rdi	Parameter type: <Alarm::ONTPLOAMRDI> (yes no) Possible values: - yes : remote defect indication from ont - no : no remote defect indication from ont	remote defect indication from ont. <i>This element is only shown in detail mode.</i>
soho-ploam-loss-ks	Parameter type: <Alarm::ONTPLOAMLOKS> (yes no) Possible values: - yes : loss of key synchronization between olt and ont - no : key synchronization between olt and ont is ok	loss of key synchronization between olt and ont <i>This element is only shown in detail mode.</i>
soho-ploam-pwr-burst	Parameter type: <Alarm::ONTPLOAMONTPWRERR> (yes no) Possible values: - yes : ont power up error	ont power up error. <i>This element is only shown in detail mode.</i>

102 Alarm Log Status Commands

name	Type	Description
	- no : ont power up ok	
soho-ploam-rog-disa	Parameter type: <Alarm::ONTPLOAMROGUEONTDIS> (yes no) Possible values: - yes : ont has been autonomously disabled to be a rogue ont - no : ont is normal	ont has been autonomously disabled because of misbehaving transmissions and is thought to be a rogue ont. <i>This element is only shown in detail mode.</i>
soho-ploam-diff-reach	Parameter type: <Alarm::ONTPLOAMDIFREACH> (yes no) Possible values: - yes : ont has been deactivated because its location on the pon has exceeded its differential reach capability - no : ont is normal	ont has been deactivated because its location on the pon has exceeded its differential reach capability. <i>This element is only shown in detail mode.</i>
soho-ploam-looc	Parameter type: <Alarm::ONTPLOAMLOOC> (yes no) Possible values: - yes : ont has been deactivated due to persistent OMCI MIC failure - no : ont is normal	ont has been deactivated due to persistent OMCI MIC failure. <i>This element is only shown in detail mode.</i>

102.114 MDU ONT PLOAM Alarm Log Status Command

Command Description

This command displays the MDU ONT PLOAM alarm log status.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm log mdu-ploam [ (index) ]
```

Command Parameters

Table 102.114-1 "MDU ONT PLOAM Alarm Log Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm log table index

Command Output

Table 102.114-2 "MDU ONT PLOAM Alarm Log Status Command" Display parameters

Specific Information		
name	Type	Description
last-updated-on	Parameter type: <Sys::timeInSecs> - the time (yyyy-mm-dd:hour:minutes:secs) - unit: UTC	network time in seconds when the alarm was logged <i>This element is only shown in detail mode.</i>
ont	Parameter type: <Gpon::OntIndex> (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> ng2 : <Ng2::ChannelGroup> / <Ng2::SubchannelGroup> / <Ng2::OntId>) Possible values: - ng2 : ngpon2 style identification Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId>	gpon ont equipment ifindex of ont <i>This element is only shown in detail mode.</i>

102 Alarm Log Status Commands

name	Type	Description
	- the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Ng2::ChannelGroup> - channel group number Field type <Ng2::SubchannelGroup> - subchannel group number Field type <Eqpt::OntId> - the ONT identifier Field type <Ng2::OntId> - the ONT identifier	

Only Show Details: current alarm status		
name	Type	Description
mdu-ploam-loss-sig	Parameter type: <Alarm::ONTPLOAMLOSO> (yes no) Possible values: - yes : loss of signal at ont - no : no loss of signal at ont	loss of signal at ont <i>This element is only shown in detail mode.</i>
mdu-ploam-loss-ack	Parameter type: <Alarm::ONTPLOAMLOA> (yes no) Possible values: - yes : loss of acknowledge from ont - no : no loss of acknowledge from ont	loss of acknowledge from ont <i>This element is only shown in detail mode.</i>
mdu-ploam-loss-cd	Parameter type: <Alarm::ONTPLOAMLCD> (yes no) Possible values: - yes : loss of gem/atm channel delineation of ont - no : gem/atm channel delineation of ont is normal	loss of gem/atm channel delineation of ont <i>This element is only shown in detail mode.</i>
mdu-ploam-phy-eqpt-err	Parameter type: <Alarm::ONTPLOAMPEE> (yes no) Possible values: - yes : physical equipment error of ont - no : no physical equipment error of ont	physical equipment error of ont <i>This element is only shown in detail mode.</i>
mdu-ploam-startup-fail	Parameter type: <Alarm::ONTPLOAMSUF> (yes no) Possible values: - yes : startup failure in ranging of ont - no : no startup failure in ranging of ont	startup failure in ranging of ont <i>This element is only shown in detail mode.</i>
mdu-ploam-sig-degrade	Parameter type: <Alarm::ONTPLOAMSD> (yes no) Possible values: - yes : signal degrade ber threshold exceeded from ont - no : signal degrade ber threshold is normal	signal degrade ber threshold exceeded from ont <i>This element is only shown in detail mode.</i>
mdu-ploam-disabled	Parameter type: <Alarm::ONTPLOAMONTDisabled> (yes no) Possible values: - yes : ont has been autonomously disabled - no : ont is enabled	ont has been autonomously disabled because of misbehaving transmissions <i>This element is only shown in detail mode.</i>
mdu-ploam-err-msg	Parameter type: <Alarm::ONTPLOAMMEM> (yes	message error message from ont <i>This element is only shown in</i>

name	Type	Description
	no) Possible values: - yes : message error message from ont - no : no message error message from ont	detail mode.
mdu-ploam-inactive	Parameter type: <Alarm::ONTPLOAMInact> (yes no) Possible values: - yes : ont is inactive - no : ont is active	ont is inactive <i>This element is only shown in detail mode.</i>
mdu-ploam-sig-fail	Parameter type: <Alarm::ONTPLOAMSF> (yes no) Possible values: - yes : signal fail ber threshold exceeded from ont - no : no signal fail ber threshold exceeded from ont	signal fail ber threshold exceeded from ont <i>This element is only shown in detail mode.</i>
mdu-ploam-dying-gasp	Parameter type: <Alarm::ONTPLOAMDG> (yes no) Possible values: - yes : received dying gasp indication from ont - no : no received dying gasp indication from ont	received dying gasp indication from ont <i>This element is only shown in detail mode.</i>
mdu-ploam-deact-fail	Parameter type: <Alarm::ONTPLOAMDF> (yes no) Possible values: - yes : deactivate failure of ont - no : no deactivate failure of ont	deactivate failure of ont <i>This element is only shown in detail mode.</i>
mdu-ploam-oam	Parameter type: <Alarm::ONTPLOAMLOAM> (yes no) Possible values: - yes : loss of ploam for ont - no : no Loss of ploam for ont	loss of ploam for ont <i>This element is only shown in detail mode.</i>
mdu-ploam-win-drift	Parameter type: <Alarm::ONTPLOAMDOW> (yes no) Possible values: - yes : drift of window - no : no drift of window	drift of window. <i>This element is only shown in detail mode.</i>
mdu-ploam-rdi	Parameter type: <Alarm::ONTPLOAMRDI> (yes no) Possible values: - yes : remote defect indication from ont - no : no remote defect indication from ont	remote defect indication from ont. <i>This element is only shown in detail mode.</i>
mdu-ploam-loss-ks	Parameter type: <Alarm::ONTPLOAMLOKS> (yes no) Possible values: - yes : loss of key synchronization between olt and ont - no : key synchronization between olt and ont is ok	loss of key synchronization between olt and ont <i>This element is only shown in detail mode.</i>
mdu-ploam-pwr-burst	Parameter type: <Alarm::ONTPLOAMONTPWRERR> (yes no) Possible values: - yes : ont power up error	ont power up error. <i>This element is only shown in detail mode.</i>

102 Alarm Log Status Commands

name	Type	Description
	- no : ont power up ok	
mdu-ploam-rog-disa	Parameter type: <Alarm::ONTPLOAMROGUEONTDIS> (yes no) Possible values: - yes : ont has been autonomously disabled to be a rogue ont - no : ont is normal	ont has been autonomously disabled because of misbehaving transmissions and is thought to be a rogue ont. <i>This element is only shown in detail mode.</i>
mdu-ploam-diff-reach	Parameter type: <Alarm::ONTPLOAMDIFREACH> (yes no) Possible values: - yes : ont has been deactivated because its location on the pon has exceeded its differential reach capability - no : ont is normal	ont has been deactivated because its location on the pon has exceeded its differential reach capability. <i>This element is only shown in detail mode.</i>
mdu-ploam-looc	Parameter type: <Alarm::ONTPLOAMLOOC> (yes no) Possible values: - yes : ont has been deactivated due to persistent OMCI MIC failure - no : ont is normal	ont has been deactivated due to persistent OMCI MIC failure. <i>This element is only shown in detail mode.</i>

102.115 ONT General Alarm Log Status Command

Command Description

This command displays the ONT general alarm log status.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm log ont-gen [ (index) ]
```

Command Parameters

Table 102.115-1 "ONT General Alarm Log Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm type

Command Output

Table 102.115-2 "ONT General Alarm Log Status Command" Display parameters

Specific Information		
name	Type	Description
last-updated-on	Parameter type: <Sys::timeInSecs> - the time (yyyy-mm-dd:hour:minutes:secs) - unit: UTC	network time in seconds when the alarm was logged <i>This element is only shown in detail mode.</i>
ont	Parameter type: <Gpon::OntIndex> (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> ng2 : <Ng2::ChannelGroup> / <Ng2::SubchannelGroup> / <Ng2::OntId>) Possible values: - ng2 : ngpon2 style identification Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier	identifies the ont entry <i>This element is only shown in detail mode.</i>

102 Alarm Log Status Commands

name	Type	Description
	Field type <Ng2::ChannelGroup> - channel group number Field type <Ng2::SubchannelGroup> - subchannel group number Field type <Eqpt::OntId> - the ONT identifier Field type <Ng2::OntId> - the ONT identifier	

Only Show Details: current and previous alarm log status		
name	Type	Description
ont-gen-omci-fail	Parameter type: <Alarm::ONTGENERALOMCICOMM> (yes no) Possible values: - yes : ont fails to respond to omci message requests - no : ont responds to omci message requests works properly	ont fails to respond to omci message requests <i>This element is only shown in detail mode.</i>
ont-gen-eqpt-selftest	Parameter type: <Alarm::ONTGENERALEQPT> (yes no) Possible values: - yes : ont has failed a self test - no : ont self test works properly	ont has failed a self-test <i>This element is only shown in detail mode.</i>
ont-gen-ac-pwr-fail	Parameter type: <Alarm::ONTGENERALACFAIL> (yes no) Possible values: - yes : loss of external ac power to the ont - no : external ac power to the ont is ok	loss of external ac power to the ont" <i>This element is only shown in detail mode.</i>
ont-gen-bat-missing	Parameter type: <Alarm::ONTGENERALBATTMIS> (yes no) Possible values: - yes : battery is provisioned for ont but is missing - no : battery is provisioned and present for ont	battery is provisioned for ont but is missing <i>This element is only shown in detail mode.</i>
ont-gen-bat-low	Parameter type: <Alarm::ONTGENERALBATTLLOW> (yes no) Possible values: - yes : battery charge is low - no : battery charge is ok	battery charge is low <i>This element is only shown in detail mode.</i>
ont-gen-bat-fail	Parameter type: <Alarm::ONTGENERALBATTFAIL> (yes no) Possible values: - yes : battery is provisioned and present but cannot recharge - no : battery is provisioned and present and can recharge	battery is provisioned and present but cannot recharge <i>This element is only shown in detail mode.</i>
ont-gen-phys-intrusion	Parameter type: <Alarm::ONTGENERALINTRUDER> (yes no) Possible values: - yes : unauthorized access to ont and door or box is open - no : authorized access to ont	unauthorized access to ont <i>This element is only shown in detail mode.</i>
ont-gen-sw-dnload-f	Parameter type: <Alarm::ONTGENERALSWDLFAIL> (yes no) Possible values: - yes : download of software to ont has failed	download of software to ont has failed <i>This element is only shown in detail mode.</i>

name	Type	Description
	- no : download of software to ont works properly	
ont-gen-sw-act-fail	Parameter type: <Alarm::ONTGENERALSWACTFAIL> (yes no) Possible values: - yes : ont failed to activate the passive image designated by the olt - no : ont works properly to activate the passive image designated by the olt	ont failed to activate the passive image designated by the olt <i>This element is only shown in detail mode.</i>
ont-gen-sw-dnload-p	Parameter type: <Alarm::ONTGENERALSWDLIP> (yes no) Possible values: - yes : a condition meaning that a transfer of ont software from the olt to the ont is pending or is actually being transmitted - no : a condition meaning that a transfer of ont software from the olt to the ont is not ready	a condition meaning that a transfer of ont software from the olt to the ont is pending or is actually being transmitted <i>This element is only shown in detail mode.</i>
ont-gen-eqpt-vers-mis	Parameter type: <Alarm::ONTGENERALEQVERMIS> (yes no) Possible values: - yes : a condition meaning the provisioned ont equipment part number does not match the version reported by the ont - no : a condition meaning that provisioned ont equipment part number matches the version reported by the ont	a condition meaning the provisioned ont equipment part number does not match the version reported by the ont <i>This element is only shown in detail mode.</i>
ont-gen-sw-vers-mis	Parameter type: <Alarm::ONTGENERALSWVER> (yes no) Possible values: - yes : a condition meaning that the planned software version does not equal the active software version - no : a condition meaning that the planned software version equals the active software version	a condition meaning that the planned software version does not equal the active software version <i>This element is only shown in detail mode.</i>
ont-gen-us-rate-mis	Parameter type: <Alarm::ONTGENERALUSRATE> (yes no) Possible values: - yes : a condition meaning that the planned upstream rate and the actual upstream rate do not match - no : a condition meaning that the planned upstream rate and the actual upstream rate match	a condition meaning that the planned upstream rate and the actual upstream rate do not match <i>This element is only shown in detail mode.</i>
ont-gen-eqpt-prov-sa	Parameter type: <Alarm::ONTGENERALONTMEA> (yes no) Possible values: - yes : mismatch between ont equipment and ont provisioning attributes - no : match between ont equipment and ont provisioning attributes	mismatch between ont equipment and ont provisioning attributes <i>This element is only shown in detail mode.</i>
ont-gen-mdu-env1	Parameter type: <Alarm::ONTGENERALENV1> (yes no) Possible values: - yes : mdu environmental alarm1 - no : do not detect the mdu environmental alarm1	mdu environmental alarm1 <i>This element is only shown in detail mode.</i>
ont-gen-mdu-env2	Parameter type: <Alarm::ONTGENERALENV2>	mdu environmental alarm2

102 Alarm Log Status Commands

name	Type	Description
	(yes no) Possible values: - yes : mdu environmental alarm2 - no : do not detect the mdu environmental alarm2	<i>This element is only shown in detail mode.</i>
ont-gen-mdv-env3	Parameter type: <Alarm::ONTGENERALENV3> (yes no) Possible values: - yes : mdu environmental alarm3 - no : do not detect the mdu environmental alarm3	mdv environmental alarm3 <i>This element is only shown in detail mode.</i>
ont-gen-nw-time-err	Parameter type: <Alarm::ONTGENERALNTPERR> (yes no) Possible values: - yes : a condition meaning the ont is unable to establish timing from the ntp server(s) - no : a condition meaning the ont is able to establish timing from the ntp server(s)	a condition meaning the ont is unable to establish timing from the ntp server(s) <i>This element is only shown in detail mode.</i>
ont-gen-opt-sig-high	Parameter type: <Alarm::ONTGENERALLEVELHI> (yes no) Possible values: - yes : optical signal level is too high - no : optical signal level is normal	optical signal level is too high <i>This element is only shown in detail mode.</i>
ont-gen-opt-sig-low	Parameter type: <Alarm::ONTGENERALLEVELLO> (yes no) Possible values: - yes : optical signal level is too low - no : optical signal level is normal	Optical signal level is too low <i>This element is only shown in detail mode.</i>
ont-gen-eqpt-prov-nsa	Parameter type: <Alarm::ONTGENERALONTNSAMEA> (yes no) Possible values: - yes : non service affects mismatch between ont equipment and ont provisioning attributes - no : ont is provisioned properly	non service affects mismatch between ont equipment and ont provisioning attributes <i>This element is only shown in detail mode.</i>

102.116 SFU ONT General Alarm Log Status Command

Command Description

This command displays the SFU ONT general alarm log status.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

> show alarm log sfu-gen [(index)]

Command Parameters

Table 102.116-1 "SFU ONT General Alarm Log Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm type

Command Output

Table 102.116-2 "SFU ONT General Alarm Log Status Command" Display parameters

Specific Information		
name	Type	Description
last-updated-on	Parameter type: <Sys::timeInSecs> - the time (yyyy-mm-dd:hour:minutes:secs) - unit: UTC	network time in seconds when the alarm was logged <i>This element is only shown in detail mode.</i>
ont	Parameter type: <Gpon::OntIndex> (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> ng2 : <Ng2::ChannelGroup> / <Ng2::SubchannelGroup> / <Ng2::OntId>) Possible values: - ng2 : ngpon2 style identification Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId>	identifies the ont entry <i>This element is only shown in detail mode.</i>

102 Alarm Log Status Commands

name	Type	Description
	- the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Ng2::ChannelGroup> - channel group number Field type <Ng2::SubchannelGroup> - subchannel group number Field type <Eqpt::OntId> - the ONT identifier Field type <Ng2::OntId> - the ONT identifier	

Only Show Details: current and previous alarm log status		
name	Type	Description
sfu-gen-omci-fail	Parameter type: <Alarm::ONTGENERALOMCICOMM> (yes no) Possible values: - yes : ont fails to respond to omci message requests - no : ont responds to omci message requests works properly	ont fails to respond to omci message requests <i>This element is only shown in detail mode.</i>
sfu-gen-eqpt-selftest	Parameter type: <Alarm::ONTGENERALEQPT> (yes no) Possible values: - yes : ont has failed a self test - no : ont self test works properly	ont has failed a self-test <i>This element is only shown in detail mode.</i>
sfu-gen-ac-pwr-fail	Parameter type: <Alarm::ONTGENERALACFAIL> (yes no) Possible values: - yes : loss of external ac power to the ont - no : external ac power to the ont is ok	loss of external ac power to the ont" <i>This element is only shown in detail mode.</i>
sfu-gen-bat-missing	Parameter type: <Alarm::ONTGENERALBATTMIS> (yes no) Possible values: - yes : battery is provisioned for ont but is missing - no : battery is provisioned and present for ont	battery is provisioned for ont but is missing <i>This element is only shown in detail mode.</i>
sfu-gen-bat-low	Parameter type: <Alarm::ONTGENERALBATTLOW> (yes no) Possible values: - yes : battery charge is low - no : battery charge is ok	battery charge is low <i>This element is only shown in detail mode.</i>
sfu-gen-bat-fail	Parameter type: <Alarm::ONTGENERALBATTFAIL> (yes no) Possible values: - yes : battery is provisioned and present but cannot recharge - no : battery is provisioned and present and can recharge	battery is provisioned and present but cannot recharge <i>This element is only shown in detail mode.</i>
sfu-gen-sw-dnload-f	Parameter type: <Alarm::ONTGENERALSWDLFAIL> (yes no) Possible values: - yes : download of software to ont has failed - no : download of software to ont works properly	download of software to ont has failed <i>This element is only shown in detail mode.</i>
sfu-gen-sw-act-fail	Parameter type: <Alarm::ONTGENERALSWACTFAIL> (yes	ont failed to activate the passive image designated by the olt

name	Type	Description
	no) Possible values: - yes : ont failed to activate the passive image designated by the olt - no : ont works properly to activate the passive image designated by the olt	<i>This element is only shown in detail mode.</i>
sfu-gen-sw-dnload-p	Parameter type: <Alarm::ONTGENERALSWDLIP> (yes no) Possible values: - yes : a condition meaning that a transfer of ont software from the olt to the ont is pending or is actually being transmitted - no : a condition meaning that a transfer of ont software from the olt to the ont is not ready	a condition meaning that a transfer of ont software from the olt to the ont is pending or is actually being transmitted <i>This element is only shown in detail mode.</i>
sfu-gen-eqpt-vers-mis	Parameter type: <Alarm::ONTGENERALEQVERMIS> (yes no) Possible values: - yes : a condition meaning the provisioned ont equipment part number does not match the version reported by the ont - no : a condition meaning that provisioned ont equipment part number matches the version reported by the ont	a condition meaning the provisioned ont equipment part number does not match the version reported by the ont <i>This element is only shown in detail mode.</i>
sfu-gen-sw-vers-mis	Parameter type: <Alarm::ONTGENERALSWVER> (yes no) Possible values: - yes : a condition meaning that the planned software version does not equal the active software version - no : a condition meaning that the planned software version equals the active software version	a condition meaning that the planned software version does not equal the active software version <i>This element is only shown in detail mode.</i>
sfu-gen-us-rate-mis	Parameter type: <Alarm::ONTGENERALUSRATE> (yes no) Possible values: - yes : a condition meaning that the planned upstream rate and the actual upstream rate do not match - no : a condition meaning that the planned upstream rate and the actual upstream rate match	a condition meaning that the planned upstream rate and the actual upstream rate do not match <i>This element is only shown in detail mode.</i>
sfu-gen-eqpt-prov-sa	Parameter type: <Alarm::ONTGENERALONTMEA> (yes no) Possible values: - yes : mismatch between ont equipment and ont provisioning attributes - no : match between ont equipment and ont provisioning attributes	mismatch between ont equipment and ont provisioning attributes <i>This element is only shown in detail mode.</i>
sfu-gen-nw-time-err	Parameter type: <Alarm::ONTGENERALNTPERR> (yes no) Possible values: - yes : a condition meaning the ont is unable to establish timing from the ntp server(s) - no : a condition meaning the ont is able to establish timing from the ntp server(s)	a condition meaning the ont is unable to establish timing from the ntp server(s) <i>This element is only shown in detail mode.</i>
sfu-gen-opt-sig-high	Parameter type: <Alarm::ONTGENERALLEVELHI> (yes	optical signal level is too high <i>This element is only shown in</i>

102 Alarm Log Status Commands

name	Type	Description
	no) Possible values: - yes : optical signal level is too high - no : optical signal level is normal	<i>detail mode.</i>
sfu-gen-opt-sig-low	Parameter type: <Alarm::ONTGENERALLEVELLO> (yes no) Possible values: - yes : optical signal level is too low - no : optical signal level is normal	Optical signal level is too low <i>This element is only shown in detail mode.</i>
sfu-gen-eqpt-prov-nsa	Parameter type: <Alarm::ONTGENERALONTNSAMEA> (yes no) Possible values: - yes : non service affects mismatch between ont equipment and ont provisioning attributes - no : ont is provisioned properly	non service affects mismatch between ont equipment and ont provisioning attributes <i>This element is only shown in detail mode.</i>

102.117 SOHO ONT General Alarm Log Status Command

Command Description

This command displays the SOHO ONT general alarm log status.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

> show alarm log soho-gen [(index)]

Command Parameters

Table 102.117-1 "SOHO ONT General Alarm Log Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm type

Command Output

Table 102.117-2 "SOHO ONT General Alarm Log Status Command" Display parameters

Specific Information		
name	Type	Description
last-updated-on	Parameter type: <Sys::timeInSecs> - the time (yyyy-mm-dd:hour:minutes:secs) - unit: UTC	network time in seconds when the alarm was logged <i>This element is only shown in detail mode.</i>
ont	Parameter type: <Gpon::OntIndex> (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> ng2 : <Ng2::ChannelGroup> / <Ng2::SubchannelGroup> / <Ng2::OntId>) Possible values: - ng2 : ngpon2 style identification Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId>	identifies the ont entry <i>This element is only shown in detail mode.</i>

102 Alarm Log Status Commands

name	Type	Description
	- the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Ng2::ChannelGroup> - channel group number Field type <Ng2::SubchannelGroup> - subchannel group number Field type <Eqpt::OntId> - the ONT identifier Field type <Ng2::OntId> - the ONT identifier	

Only Show Details: current and previous alarm log status		
name	Type	Description
soho-gen-omci-fail	Parameter type: <Alarm::ONTGENERALOMCICOMM> (yes no) Possible values: - yes : ont fails to respond to omci message requests - no : ont responds to omci message requests works properly	ont fails to respond to omci message requests <i>This element is only shown in detail mode.</i>
soho-gen-eqpt-selftest	Parameter type: <Alarm::ONTGENERALEQPT> (yes no) Possible values: - yes : ont has failed a self test - no : ont self test works properly	ont has failed a self-test <i>This element is only shown in detail mode.</i>
soho-gen-ac-pwr-fail	Parameter type: <Alarm::ONTGENERALACFAIL> (yes no) Possible values: - yes : loss of external ac power to the ont - no : external ac power to the ont is ok	loss of external ac power to the ont" <i>This element is only shown in detail mode.</i>
soho-gen-bat-missing	Parameter type: <Alarm::ONTGENERALBATTMIS> (yes no) Possible values: - yes : battery is provisioned for ont but is missing - no : battery is provisioned and present for ont	battery is provisioned for ont but is missing <i>This element is only shown in detail mode.</i>
soho-gen-bat-low	Parameter type: <Alarm::ONTGENERALBATTLOW> (yes no) Possible values: - yes : battery charge is low - no : battery charge is ok	battery charge is low <i>This element is only shown in detail mode.</i>
soho-gen-bat-fail	Parameter type: <Alarm::ONTGENERALBATTFAIL> (yes no) Possible values: - yes : battery is provisioned and present but cannot recharge - no : battery is provisioned and present and can recharge	battery is provisioned and present but cannot recharge <i>This element is only shown in detail mode.</i>
soho-gen-sw-dnload-f	Parameter type: <Alarm::ONTGENERALSWDLFAIL> (yes no) Possible values: - yes : download of software to ont has failed - no : download of software to ont works properly	download of software to ont has failed <i>This element is only shown in detail mode.</i>
soho-gen-sw-act-fail	Parameter type: <Alarm::ONTGENERALSWACTFAIL> (yes	ont failed to activate the passive image designated by the olt

name	Type	Description
	no) Possible values: - yes : ont failed to activate the passive image designated by the olt - no : ont works properly to activate the passive image designated by the olt	<i>This element is only shown in detail mode.</i>
soho-gen-sw-dnload-p	Parameter type: <Alarm::ONTGENERALSWDLIP> (yes no) Possible values: - yes : a condition meaning that a transfer of ont software from the olt to the ont is pending or is actually being transmitted - no : a condition meaning that a transfer of ont software from the olt to the ont is not ready	a condition meaning that a transfer of ont software from the olt to the ont is pending or is actually being transmitted <i>This element is only shown in detail mode.</i>
soho-gen-eqpt-vers-mis	Parameter type: <Alarm::ONTGENERALEQVERMIS> (yes no) Possible values: - yes : a condition meaning the provisioned ont equipment part number does not match the version reported by the ont - no : a condition meaning that provisioned ont equipment part number matches the version reported by the ont	a condition meaning the provisioned ont equipment part number does not match the version reported by the ont <i>This element is only shown in detail mode.</i>
soho-gen-sw-vers-mis	Parameter type: <Alarm::ONTGENERALSWVER> (yes no) Possible values: - yes : a condition meaning that the planned software version does not equal the active software version - no : a condition meaning that the planned software version equals the active software version	a condition meaning that the planned software version does not equal the active software version <i>This element is only shown in detail mode.</i>
soho-gen-us-rate-mis	Parameter type: <Alarm::ONTGENERALUSRATE> (yes no) Possible values: - yes : a condition meaning that the planned upstream rate and the actual upstream rate do not match - no : a condition meaning that the planned upstream rate and the actual upstream rate match	a condition meaning that the planned upstream rate and the actual upstream rate do not match <i>This element is only shown in detail mode.</i>
soho-gen-eqpt-prov-sa	Parameter type: <Alarm::ONTGENERALONTMEA> (yes no) Possible values: - yes : mismatch between ont equipment and ont provisioning attributes - no : match between ont equipment and ont provisioning attributes	mismatch between ont equipment and ont provisioning attributes <i>This element is only shown in detail mode.</i>
soho-gen-nw-time-err	Parameter type: <Alarm::ONTGENERALNTPERR> (yes no) Possible values: - yes : a condition meaning the ont is unable to establish timing from the ntp server(s) - no : a condition meaning the ont is able to establish timing from the ntp server(s)	a condition meaning the ont is unable to establish timing from the ntp server(s) <i>This element is only shown in detail mode.</i>
soho-gen-opt-sig-high	Parameter type: <Alarm::ONTGENERALLEVELHI> (yes	optical signal level is too high <i>This element is only shown in</i>

102 Alarm Log Status Commands

name	Type	Description
	no) Possible values: - yes : optical signal level is too high - no : optical signal level is normal	<i>detail mode.</i>
soho-gen-opt-sig-low	Parameter type: <Alarm::ONTGENERALLEVELLO> (yes no) Possible values: - yes : optical signal level is too low - no : optical signal level is normal	Optical signal level is too low <i>This element is only shown in detail mode.</i>
soho-gen-eqpt-prov-nsa	Parameter type: <Alarm::ONTGENERALONTNSAMEA> (yes no) Possible values: - yes : non service affects mismatch between ont equipment and ont provisioning attributes - no : ont is provisioned properly	non service affects mismatch between ont equipment and ont provisioning attributes <i>This element is only shown in detail mode.</i>

102.118 MDU ONT General Alarm Log Status Command

Command Description

This command displays the MDU ONT general alarm log status.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm log mdu-gen [ (index) ]
```

Command Parameters

Table 102.118-1 "MDU ONT General Alarm Log Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm type

Command Output

Table 102.118-2 "MDU ONT General Alarm Log Status Command" Display parameters

Specific Information		
name	Type	Description
last-updated-on	Parameter type: <Sys::timeInSecs> - the time (yyyy-mm-dd:hour:minutes:secs) - unit: UTC	network time in seconds when the alarm was logged <i>This element is only shown in detail mode.</i>
ont	Parameter type: <Gpon::OntIndex> (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> ng2 : <Ng2::ChannelGroup> / <Ng2::SubchannelGroup> / <Ng2::OntId>) Possible values: - ng2 : ngpon2 style identification Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId>	identifies the ont entry <i>This element is only shown in detail mode.</i>

102 Alarm Log Status Commands

name	Type	Description
	- the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Ng2::ChannelGroup> - channel group number Field type <Ng2::SubchannelGroup> - subchannel group number Field type <Eqpt::OntId> - the ONT identifier Field type <Ng2::OntId> - the ONT identifier	

Only Show Details: current and previous alarm log status		
name	Type	Description
mdu-gen-omci-fail	Parameter type: <Alarm::ONTGENERALOMCICOMM> (yes no) Possible values: - yes : ont fails to respond to omci message requests - no : ont responds to omci message requests works properly	ont fails to respond to omci message requests <i>This element is only shown in detail mode.</i>
mdu-gen-eqpt-selftest	Parameter type: <Alarm::ONTGENERALEQPT> (yes no) Possible values: - yes : ont has failed a self test - no : ont self test works properly	ont has failed a self-test <i>This element is only shown in detail mode.</i>
mdu-gen-ac-pwr-fail	Parameter type: <Alarm::ONTGENERALACFAIL> (yes no) Possible values: - yes : loss of external ac power to the ont - no : external ac power to the ont is ok	loss of external ac power to the ont" <i>This element is only shown in detail mode.</i>
mdu-gen-bat-missing	Parameter type: <Alarm::ONTGENERALBATMISSE> (yes no) Possible values: - yes : battery is provisioned for ont but is missing - no : battery is provisioned and present for ont	battery is provisioned for ont but is missing <i>This element is only shown in detail mode.</i>
mdu-gen-bat-low	Parameter type: <Alarm::ONTGENERALBATLOW> (yes no) Possible values: - yes : battery charge is low - no : battery charge is ok	battery charge is low <i>This element is only shown in detail mode.</i>
mdu-gen-bat-fail	Parameter type: <Alarm::ONTGENERALBATTFAIL> (yes no) Possible values: - yes : battery is provisioned and present but cannot recharge - no : battery is provisioned and present and can recharge	battery is provisioned and present but cannot recharge <i>This element is only shown in detail mode.</i>
mdu-gen-phys-intrusion	Parameter type: <Alarm::ONTGENERALINTRUDER> (yes no) Possible values: - yes : unauthorized access to ont and door or box is open - no : authorized access to ont	unauthorized access to ont <i>This element is only shown in detail mode.</i>
mdu-gen-sw-dnload-f	Parameter type: <Alarm::ONTGENERALSWDLFAIL> (yes	download of software to ont has failed

name	Type	Description
	no) Possible values: - yes : download of software to ont has failed - no : download of software to ont works properly	<i>This element is only shown in detail mode.</i>
mdu-gen-sw-act-fail	Parameter type: <Alarm::ONTGENERALSWACTFAIL> (yes no) Possible values: - yes : ont failed to activate the passive image designated by the olt - no : ont works properly to activate the passive image designated by the olt	ont failed to activate the passive image designated by the olt <i>This element is only shown in detail mode.</i>
mdu-gen-sw-dnload-p	Parameter type: <Alarm::ONTGENERALSWDLIP> (yes no) Possible values: - yes : a condition meaning that a transfer of ont software from the olt to the ont is pending or is actually being transmitted - no : a condition meaning that a transfer of ont software from the olt to the ont is not ready	a condition meaning that a transfer of ont software from the olt to the ont is pending or is actually being transmitted <i>This element is only shown in detail mode.</i>
mdu-gen-eqpt-vers-mis	Parameter type: <Alarm::ONTGENERALEQVERMIS> (yes no) Possible values: - yes : a condition meaning the provisioned ont equipment part number does not match the version reported by the ont - no : a condition meaning that provisioned ont equipment part number matches the version reported by the ont	a condition meaning the provisioned ont equipment part number does not match the version reported by the ont <i>This element is only shown in detail mode.</i>
mdu-gen-sw-vers-mis	Parameter type: <Alarm::ONTGENERALSWVER> (yes no) Possible values: - yes : a condition meaning that the planned software version does not equal the active software version - no : a condition meaning that the planned software version equals the active software version	a condition meaning that the planned software version does not equal the active software version <i>This element is only shown in detail mode.</i>
mdu-gen-us-rate-mis	Parameter type: <Alarm::ONTGENERALUSRATE> (yes no) Possible values: - yes : a condition meaning that the planned upstream rate and the actual upstream rate do not match - no : a condition meaning that the planned upstream rate and the actual upstream rate match	a condition meaning that the planned upstream rate and the actual upstream rate do not match <i>This element is only shown in detail mode.</i>
mdu-gen-eqpt-prov-sa	Parameter type: <Alarm::ONTGENERALONTMEA> (yes no) Possible values: - yes : mismatch between ont equipment and ont provisioning attributes - no : match between ont equipment and ont provisioning attributes	mismatch between ont equipment and ont provisioning attributes <i>This element is only shown in detail mode.</i>
mdu-gen-mdu-env1	Parameter type: <Alarm::ONTGENERALENV1> (yes no) Possible values:	mdu environmental alarm1 <i>This element is only shown in detail mode.</i>

102 Alarm Log Status Commands

name	Type	Description
	- yes : mdu environmental alarm1 - no : do not detect the mdu environmental alarm1	
mdu-gen-mdv-env2	Parameter type: <Alarm::ONTGENERALENV2> (yes no) Possible values: - yes : mdu environmental alarm2 - no : do not detect the mdu environmental alarm2	mdv environmental alarm2 <i>This element is only shown in detail mode.</i>
mdv-gen-mdv-env3	Parameter type: <Alarm::ONTGENERALENV3> (yes no) Possible values: - yes : mdu environmental alarm3 - no : do not detect the mdu environmental alarm3	mdv environmental alarm3 <i>This element is only shown in detail mode.</i>
mdv-gen-nw-time-err	Parameter type: <Alarm::ONTGENERALNTPERR> (yes no) Possible values: - yes : a condition meaning the ont is unable to establish timing from the ntp server(s) - no : a condition meaning the ont is able to establish timing from the ntp server(s)	a condition meaning the ont is unable to establish timing from the ntp server(s) <i>This element is only shown in detail mode.</i>
mdv-gen-opt-sig-high	Parameter type: <Alarm::ONTGENERALLEVELHI> (yes no) Possible values: - yes : optical signal level is too high - no : optical signal level is normal	optical signal level is too high <i>This element is only shown in detail mode.</i>
mdv-gen-opt-sig-low	Parameter type: <Alarm::ONTGENERALLEVELLO> (yes no) Possible values: - yes : optical signal level is too low - no : optical signal level is normal	Optical signal level is too low <i>This element is only shown in detail mode.</i>
mdv-gen-eqpt-prov-nsa	Parameter type: <Alarm::ONTGENERALONTNSAMEA> (yes no) Possible values: - yes : non service affects mismatch between ont equipment and ont provisioning attributes - no : ont is provisioned properly	non service affects mismatch between ont equipment and ont provisioning attributes <i>This element is only shown in detail mode.</i>

102.119 ONT SUBSCRIBER CARD Alarm Log

Status Command

Command Description

This command displays the ONT SUBSCRIBER CARD alarm log status.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm log ont-card [ (index) ]
```

Command Parameters

Table 102.119-1 "ONT SUBSCRIBER CARD Alarm Log Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm type

Command Output

Table 102.119-2 "ONT SUBSCRIBER CARD Alarm Log Status Command" Display parameters

Specific Information		
name	Type	Description
last-updated-on	Parameter type: <Sys::timeInSecs> - the time (yyyy-mm-dd:hour:minutes:secs) - unit: UTC	network time in seconds when the alarm was logged <i>This element is only shown in detail mode.</i>
ont-card	Parameter type: <Gpon::OntSlotAlarmIndex2> (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Gpon::OntSlotId> ng2 : <Ng2::ChannelGroup> / <Ng2::SubchannelGroup> / <Ng2::OntId> / <Gpon::OntSlotId>) Possible values: - ng2 : ngpon2 style identification Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId>	identifies the ont entry <i>This element is only shown in detail mode.</i>

102 Alarm Log Status Commands

name	Type	Description
	- the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Ng2::ChannelGroup> - channel group number Field type <Ng2::SubchannelGroup> - subchannel group number Field type <Eqpt::OntId> - the ONT identifier Field type <Ng2::OntId> - the ONT identifier Field type <Gpon::OntSlotId> - Gpon Ont Slot - range: [1...14]	
Only Show Details: current and previous alarm log status		
name	Type	Description
ont-sbscr-lim-missing	Parameter type: <Alarm::ONTCARDLIMMISSING> (yes no) Possible values: - yes : provisioned ont card missing - no : provisioned ont card works properly	provisioned ont card missing <i>This element is only shown in detail mode.</i>
ont-sbscr-lim-type-mis	Parameter type: <Alarm::ONTCARDLIMMEA> (yes no) Possible values: - yes : plug-in ont card is wrong type - no : ont card works properly	plug-in ont card is wrong type <i>This element is only shown in detail mode.</i>
ont-sbscr-lim-removal	Parameter type: <Alarm::ONTCARDLIMIMPROPRMVL> (yes no) Possible values: - yes : ont card removed without being deprovisioned - no : ont card removed correctly	ont card removed without being deprovisioned <i>This element is only shown in detail mode.</i>
ont-sbscr-lim-fail	Parameter type: <Alarm::ONTCARDLIMFAIL> (yes no) Possible values: - yes : ont card failed detected or failed self test - no : ont card works properly	ont card failed detected or failed self test <i>This element is only shown in detail mode.</i>
ont-sbscr-lim-svc-mis	Parameter type: <Alarm::ONTCARDLIMSVCMIS> (yes no) Possible values: - yes : ont did not accept the omci configuration requests for the provisioned onu card - no : ont card works properly	ont did not accept the omci configuration requests for the provisioned onu card <i>This element is only shown in detail mode.</i>
ont-sbscr-lim-port-mis	Parameter type: <Alarm::ONTCARDLIMNUMPORTSMIS> (yes no) Possible values: - yes : the actual number of ports of a plug-in ont card is different from the planned number of ports - no : the actual number of ports of a plug-in ont card is the same to the planned number of ports	the actual number of ports of a plug-in ont card is different from the planned number of ports <i>This element is only shown in detail mode.</i>

102.120 ONT SERVICES POTS Alarm Log Status Command

Command Description

This command displays the ONT SERVICES POTS alarm log status.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm log ont-pots [ (index) ]
```

Command Parameters

Table 102.120-1 "ONT SERVICES POTS Alarm Log Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm type

Command Output

Table 102.120-2 "ONT SERVICES POTS Alarm Log Status Command" Display parameters

Specific Information		
name	Type	Description
last-updated-on	Parameter type: <Sys::timeInSecs> - the time (yyyy-mm-dd:hour:minutes:secs) - unit: UTC	network time in seconds when the alarm was logged <i>This element is only shown in detail mode.</i>
ont-pots	Parameter type: <Gpon::OntPotsAlarmIndex2> (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Gpon::OntSlotId> / <Gpon::OntPotsPortId> ng2 : <Ng2::ChannelGroup> / <Ng2::SubchannelGroup> / <Ng2::OntId> / <Gpon::OntSlotId> / <Gpon::OntPotsPortId>) Possible values: - ng2 : ngpon2 style identification Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId>	gpon ont pots port index <i>This element is only shown in detail mode.</i>

name	Type	Description
	- the shelf number - Field type <Eqpt::SlotId> - the LT slot number - Field type <Eqpt::PonId> - the PON identifier - Field type <Ng2::ChannelGroup> - channel group number - Field type <Ng2::SubchannelGroup> - subchannel group number - Field type <Eqpt::OntId> - the ONT identifier - Field type <Ng2::OntId> - the ONT identifier - Field type <Gpon::OntSlotId> - Gpon Ont Slot - range: [1...14] - Field type <Gpon::OntPotsPortId> - Gpon Ont Pots Port - range: [1...24]	

Only Show Details: current and previous alarm log status

name	Type	Description
ont-svc-pots-svc-mis	Parameter type: <Alarm::ONTPOTSSVCMIS> (yes no) Possible values: - yes : ont service mismatch for provisioned pots - no : ont service pots works properly	ont service mismatch for provisioned pots <i>This element is only shown in detail mode.</i>
ont-svc-pots-rtcp-lost	Parameter type: <Alarm::ONTPOTSRTCPSTREAMLOSS> (yes no) Possible values: - yes : pots realtime transport control protocol stream lost - no : ont service pots works properly	pots realtime transport control protocol stream lost <i>This element is only shown in detail mode.</i>
ont-svc-pots-icnf-sub	Parameter type: <Alarm::ONTPOTSICONFIGSUBFAIL> (yes no) Possible values: - yes : iconfig subscription of the pots line failed - no : ont service pots works properly	pots line iconfig subscription failure <i>This element is only shown in detail mode.</i>
ont-svc-pots-icnf-ntfy	Parameter type: <Alarm::ONTPOTSICONFIGNOTIFYFAIL> (yes no) Possible values: - yes : iconfig notify failed for a pots line - no : ont service pots works properly	pots line iconfig notify failure <i>This element is only shown in detail mode.</i>
ont-svc-pots-icnf-http	Parameter type: <Alarm::ONTPOTSICONFIGHTTPFAIL> (yes no) Possible values: - yes : iconfig http redirect failed for a pots line - no : ont service pots works properly	pots line iconfig http failure <i>This element is only shown in detail mode.</i>
ont-svc-pots-sip-reg	Parameter type: <Alarm::ONTPOTSSIPREGFAIL> (yes no) Possible values: - yes : sip registration failed for the pots line	pots line sip registration failure <i>This element is only shown in detail mode.</i>

102 Alarm Log Status Commands

name	Type	Description
	- no : ont service pots works properly	
ont-svc-pots-sip-inv	Parameter type: <Alarm::ONTPOTSSIPINVITEFAIL> (yes no) Possible values: - yes : sip invite request for the pots line failed - no : ont service pots works properly	pots line sip invite request failure <i>This element is only shown in detail mode.</i>
ont-svc-pots-sip-subsc	Parameter type: <Alarm::ONTPOTSSIPSUBFAIL> (yes no) Possible values: - yes : sip subscribe failed for the pots line - no : ont service pots works properly	pots line sip subscribe failure <i>This element is only shown in detail mode.</i>
ont-svc-pots-sip-mt-tc	Parameter type: <Alarm::ONTPOTSSIPMSGTMOUTTCA> (yes no) Possible values: - yes : number of sip message timeouts threshold has crossed for the pots line - no : ont service pots works properly	pots line sip message timeout threshold crossed <i>This element is only shown in detail mode.</i>
ont-svc-pots-pk-los-tc	Parameter type: <Alarm::ONTPOTSRTPPKTLOSSTCA> (yes no) Possible values: - yes : number of rtp bearer packets loss on a pots line has been crossed - no : ont service pots works properly	pots line rtp bearer packets loss threshold crossed <i>This element is only shown in detail mode.</i>
ont-svc-pots-jitter-tc	Parameter type: <Alarm::ONTPOTSJITTERTCA> (yes no) Possible values: - yes : rtp jitter threshold has been crossed on a pots line - no : ont service pots works properly	pots line rtp jitter threshold crossed <i>This element is only shown in detail mode.</i>
ont-svc-pots-subs-dns	Parameter type: <Alarm::ONTPOTSICNFSUBSDNS> (yes no) Possible values: - yes : iconfig subscription failed because domain name could not be resolved - no : ont service pots works properly	iconfig subscription failed <i>This element is only shown in detail mode.</i>
ont-svc-pots-subs-tcp	Parameter type: <Alarm::ONTPOTSICNFSUBSTCP> (yes no) Possible values: - yes : iconfig subscription failed because of TCP socket - no : ont service pots works properly	iconfig subscription failed <i>This element is only shown in detail mode.</i>
ont-svc-pots-subs-tls	Parameter type: <Alarm::ONTPOTSICNFSUBSTLS> (yes no) Possible values: - yes : iconfig subscription failed because of TLS session - no : ont service pots works properly	iconfig subscription failed <i>This element is only shown in detail mode.</i>
ont-svc-pots-subs-auth	Parameter type: <Alarm::ONTPOTSICNFSUBSAUTH> (yes no) Possible values:	iconfig subscription failed <i>This element is only shown in detail mode.</i>

name	Type	Description
	- yes : iconfig subscription failed because authentication failed - no : ont service pots works properly	
ont-svc-pots-subs-to	Parameter type: <Alarm::ONTPOTSICNFSUBSTO> (yes no) Possible values: - yes : iconfig subscription failed because of retransmission timeout - no : ont service pots works properly	iconfig subscription failed <i>This element is only shown in detail mode.</i>
ont-svc-pots-subs-err	Parameter type: <Alarm::ONTPOTSICNFSUBSERR> (yes no) Possible values: - yes : iconfig subscription failed because of response error - no : ont service pots works properly	iconfig subscription failed <i>This element is only shown in detail mode.</i>
ont-svc-pots-not-to	Parameter type: <Alarm::ONTPOTSICNFNOTTO> (yes no) Possible values: - yes : iconfig notification failed because of retransmission timeout - no : ont service pots works properly	iconfig notification failed <i>This element is only shown in detail mode.</i>
ont-svc-pots-notref-to	Parameter type: <Alarm::ONTPOTSICNFNOTREFTO> (yes no) Possible values: - yes : iconfig notification refresh failed because of timeout - no : ont service pots works properly	iconfig notification failed <i>This element is only shown in detail mode.</i>
ont-svc-pots-not-mal	Parameter type: <Alarm::ONTPOTSICNFNOTMAL> (yes no) Possible values: - yes : iconfig notification refresh failed because of a malformed message - no : ont service pots works properly	iconfig notification failed <i>This element is only shown in detail mode.</i>
ont-svc-pots-not-rej	Parameter type: <Alarm::ONTPOTSICNFNOTREJ> (yes no) Possible values: - yes : iconfig notification refresh failed because it was rejected by the server - no : ont service pots works properly	iconfig notification failed <i>This element is only shown in detail mode.</i>
ont-svc-pots-http-dns	Parameter type: <Alarm::ONTPOTSICNFHTTPDNS> (yes no) Possible values: - yes : iconfig doc retrieval failed because domain name could not be resolved - no : ont service pots works properly	iconfig doc retrieval failed <i>This element is only shown in detail mode.</i>
ont-svc-pots-http-tcp	Parameter type: <Alarm::ONTPOTSICNFHTTPTCP> (yes no) Possible values: - yes : iconfig doc retrieval failed because of TCP socket - no : ont service pots works properly	iconfig doc retrieval failed <i>This element is only shown in detail mode.</i>
ont-svc-pots-http-tls	Parameter type: <Alarm::ONTPOTSICNFHTTPTLS>	iconfig doc retrieval failed

102 Alarm Log Status Commands

name	Type	Description
	(yes no) Possible values: - yes : iconfig doc retrieval failed because of TLS session - no : ont service pots works properly	<i>This element is only shown in detail mode.</i>
ont-svc-pots-http-auth	Parameter type: <Alarm::ONTPOTSICNFHTTPAUTH> (yes no) Possible values: - yes : iconfig doc retrieval failed because authentication failed - no : ont service pots works properly	iconfig doc retrieval failed <i>This element is only shown in detail mode.</i>
ont-svc-pots-http-to	Parameter type: <Alarm::ONTPOTSICNFHTTPTO> (yes no) Possible values: - yes : iconfig doc retrieval failed because of retransmission timeout - no : ont service pots works properly	iconfig doc retrieval failed <i>This element is only shown in detail mode.</i>
ont-svc-pots-http-err	Parameter type: <Alarm::ONTPOTSICNFHTTPERR> (yes no) Possible values: - yes : iconfig doc retrieval failed because of response error - no : ont service pots works properly	iconfig doc retrieval failed <i>This element is only shown in detail mode.</i>
ont-svc-pots-http-mal	Parameter type: <Alarm::ONTPOTSICNFHTTPMAL> (yes no) Possible values: - yes : iconfig doc retrieval failed because of a malformed message - no : ont service pots works properly	iconfig doc retrieval failed <i>This element is only shown in detail mode.</i>
ont-svc-pots-insuff	Parameter type: <Alarm::ONTPOTSINSUFF> (yes no) Possible values: - yes : iconfig service failed because of insufficient data - no : ont VOIP service pots works properly	iconfig VOIP service failed <i>This element is only shown in detail mode.</i>
ont-svc-pots-poos	Parameter type: <Alarm::ONTPOTSPOOS> (yes no) Possible values: - yes : pots ports out of service - no : pots ports work properly	pots ports out of service <i>This element is only shown in detail mode.</i>

102.121 ONT SERVICES LAN Alarm Log Status Command

Command Description

This command displays the ONT SERVICES LAN alarm log status.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm log ont-lan [ (index) ]
```

Command Parameters

Table 102.121-1 "ONT SERVICES LAN Alarm Log Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm type

Command Output

Table 102.121-2 "ONT SERVICES LAN Alarm Log Status Command" Display parameters

Specific Information		
name	Type	Description
last-updated-on	Parameter type: <Sys::timeInSecs> - the time (yyyy-mm-dd:hour:minutes:secs) - unit: UTC	network time in seconds when the alarm was logged <i>This element is only shown in detail mode.</i>
ont-port	Parameter type: <Gpon::IfIndexAlarmIndex2> (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Gpon::OntSlotId> / <Gpon::OntPortId> ng2 : <Ng2::ChannelGroup> / <Ng2::SubchannelGroup> / <Ng2::OntId> / <Gpon::OntSlotId> / <Gpon::OntPortId>) Possible values: - ng2 : ngpon2 style identification Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number	gpon ont port <i>This element is only shown in detail mode.</i>

102 Alarm Log Status Commands

name	Type	Description
	Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Ng2::ChannelGroup> - channel group number Field type <Ng2::SubchannelGroup> - subchannel group number Field type <Eqpt::OntId> - the ONT identifier Field type <Ng2::OntId> - the ONT identifier Field type <Gpon::OntSlotId> - Gpon Ont Slot - range: [1...14] Field type <Gpon::OntPortId> - Gpon Ont Port - range: [1...16]	

Only Show Details: current and previous alarm log status		
name	Type	Description
ont-svc-lan-mismatch	Parameter type: <Alarm::ONTLANSVCMIS> (yes no) Possible values: - yes : the ont did not accept the omci configuration requests for the lan service - no : ont service lan works properly	ont service mismatch for lan <i>This element is only shown in detail mode.</i>
ont-svc-lan-loss-sig	Parameter type: <Alarm::ONTLANLOS> (yes no) Possible values: - yes : loss of signal on an ethernet port interface - no : ont service lan works properly	loss of signal on an ethernet port interface <i>This element is only shown in detail mode.</i>
ont-svc-enet-poos	Parameter type: <Alarm::ONTENETPOOS> (yes no) Possible values: - yes : ethernet ports out of service - no : ethernet ports work properly	ethernet ports out of service <i>This element is only shown in detail mode.</i>

102.122 ONT TC TCA Alarm Log Status Command

Command Description

This command displays the ONT TC TCA alarm log status.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

> show alarm log ont-tc-tca [(index)]

Command Parameters

Table 102.122-1 "ONT TC TCA Alarm Log Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm type

Command Output

Table 102.122-2 "ONT TC TCA Alarm Log Status Command" Display parameters

Specific Information		
name	Type	Description
last-updated-on	Parameter type: <Sys::timeInSecs> - the time (yyyy-mm-dd:hour:minutes:secs) - unit: UTC	network time in seconds when the alarm was logged <i>This element is only shown in detail mode.</i>
ont	Parameter type: <Gpon::OntIndex> (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> ng2 : <Ng2::ChannelGroup> / <Ng2::SubchannelGroup> / <Ng2::OntId>) Possible values: - ng2 : ngpon2 style identification Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier	identifies the ont entry <i>This element is only shown in detail mode.</i>

102 Alarm Log Status Commands

name	Type	Description
	Field type <Ng2::ChannelGroup> - channel group number Field type <Ng2::SubchannelGroup> - subchannel group number Field type <Eqpt::OntId> - the ONT identifier Field type <Ng2::OntId> - the ONT identifier	

Only Show Details: current and previous alarm log status		
name	Type	Description
ont-tc-rx-los-frag-tc	Parameter type: <Alarm::ONTTCTCARLOSTFRAGS> (yes no) Possible values: - yes : rx loss of gem fragments threshold crossed - no : ont works properly	rx loss of gem fragments threshold crossed <i>This element is only shown in detail mode.</i>
ont-tc-tx-los-frag-tc	Parameter type: <Alarm::ONTTCTCATLOSTFRAGS> (yes no) Possible values: - yes : tx loss of gem fragments threshold crossed - no : ont works properly	tx loss of gem fragments threshold crossed <i>This element is only shown in detail mode.</i>
ont-tc-bad-gem-hd-tc	Parameter type: <Alarm::ONTTCTCABADGEMHDS> (yes no) Possible values: - yes : bad gem header threshold crossed - no : ont works properly	bad gem header threshold crossed <i>This element is only shown in detail mode.</i>

102.123 ONT TCA Alarm Log Status Command

Command Description

This command displays the ONT TCA alarm log status.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm log ont-tca [ (index) ]
```

Command Parameters

Table 102.123-1 "ONT TCA Alarm Log Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm type

Command Output

Table 102.123-2 "ONT TCA Alarm Log Status Command" Display parameters

Specific Information		
name	Type	Description
last-updated-on	Parameter type: <Sys::timeInSecs> - the time (yyyy-mm-dd:hour:minutes:secs) - unit: UTC	network time in seconds when the alarm was logged <i>This element is only shown in detail mode.</i>
ont	Parameter type: <Gpon::OntIndex> (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> ng2 : <Ng2::ChannelGroup> / <Ng2::SubchannelGroup> / <Ng2::OntId>) Possible values: - ng2 : ngpon2 style identification Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier	identifies the ont entry <i>This element is only shown in detail mode.</i>

102 Alarm Log Status Commands

name	Type	Description
	Field type <Ng2::ChannelGroup> - channel group number Field type <Ng2::SubchannelGroup> - subchannel group number Field type <Eqpt::OntId> - the ONT identifier Field type <Ng2::OntId> - the ONT identifier	

Only Show Details: current and previous alarm log status		
name	Type	Description
ont-cpu-util-tca	Parameter type: <Alarm::ONTTCACPUUTIL> (yes no) Possible values: - yes : ONT CPU utilization threshold crossed - no : ont works properly	ONT CPU utilization threshold crossed <i>This element is only shown in detail mode.</i>
ont-mem-util-tca	Parameter type: <Alarm::ONTTCAMEMUTIL> (yes no) Possible values: - yes : ONT memory utilization threshold crossed - no : ont works properly	ONT memory utilization threshold crossed <i>This element is only shown in detail mode.</i>

102.124 ONT L2 UNI Ethernet TCA Alarm Log Status Command

Command Description

This command displays the ONT L2 UNI Ethernet TCA alarm log status.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm log ont-l2uni-eth-tca [ (index) ]
```

Command Parameters

Table 102.124-1 " ONT L2 UNI Ethernet TCA Alarm Log Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm type

Command Output

Table 102.124-2 " ONT L2 UNI Ethernet TCA Alarm Log Status Command" Display parameters

Specific Information		
name	Type	Description
last-updated-on	Parameter type: <Sys::timeInSecs> - the time (yyyy-mm-dd:hour:minutes:secs) - unit: UTC	network time in seconds when the alarm was logged <i>This element is only shown in detail mode.</i>
ont-port	Parameter type: <Gpon::IfIndexAlarmIndex2> (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Gpon::OntSlotId> / <Gpon::OntPortId> ng2 : <Ng2::ChannelGroup> / <Ng2::SubchannelGroup> / <Ng2::OntId> / <Gpon::OntSlotId> / <Gpon::OntPortId>) Possible values: - ng2 : ngpon2 style identification Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number	gpon ont port spindex <i>This element is only shown in detail mode.</i>

102 Alarm Log Status Commands

name	Type	Description
	Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Ng2::ChannelGroup> - channel group number Field type <Ng2::SubchannelGroup> - subchannel group number Field type <Eqpt::OntId> - the ONT identifier Field type <Ng2::OntId> - the ONT identifier Field type <Gpon::OntSlotId> - Gpon Ont Slot - range: [1...14] Field type <Gpon::OntPortId> - Gpon Ont Port - range: [1...16]	

Only Show Details: current and previous alarm log status		
name	Type	Description
ont-uni-ds-drpdp-fr-tc	Parameter type: <Alarm::ONTL2UNIETHTCADSDRPFDRMS> (yes no) Possible values: - yes : downstream l2 dropped frames threshold crossed - no : ont works properly	downstream l2 dropped frames threshold crossed <i>This element is only shown in detail mode.</i>
ont-uni-up-drpdp-fr-tc	Parameter type: <Alarm::ONTL2UNIETHTCAUSDRPFDRMS> (yes no) Possible values: - yes : upstream l2 dropped frames threshold crossed - no : ont works properly	upstream l2 dropped frames threshold crossed <i>This element is only shown in detail mode.</i>
ont-uni-ds-crc-fr-tc	Parameter type: <Alarm::ONTL2UNIDSCRCRPFDRMS> (yes no) Possible values: - yes : downstream l2 rx crc error frames threshold crossed - no : ont works properly	downstream l2 rx crc error frames threshold crossed <i>This element is only shown in detail mode.</i>
ont-uni-up-crc-fr-tc	Parameter type: <Alarm::ONTL2UNIUPCRCRPFDRMS> (yes no) Possible values: - yes : upstream l2 rx crc error frames threshold crossed - no : ont works properly	upstream l2 rx crc error frames threshold crossed <i>This element is only shown in detail mode.</i>

102.125 OLT PON TC TCA Alarm Log Status Command

Command Description

This command displays the OLT PON TC TCA alarm log status.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm log olt-pon-tc-tca [ (index) ]
```

Command Parameters

Table 102.125-1 " OLT PON TC TCA Alarm Log Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm type

Command Output

Table 102.125-2 " OLT PON TC TCA Alarm Log Status Command" Display parameters

Specific Information		
name	Type	Description
last-updated-on	Parameter type: <Sys::timeInSecs> - the time (yyyy-mm-dd:hour:minutes:secs) - unit: UTC	network time in seconds when the alarm was logged <i>This element is only shown in detail mode.</i>
pon	Parameter type: <Gpon::PonId> (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> x-pon : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::XPonId> 25g-pon : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::M25GPonId>) Possible values: - 25g-pon : 25g pon - x-pon : Xgs pon Field type <Eqpt::RackId> - the rack number	pon ifindex <i>This element is only shown in detail mode.</i>

102 Alarm Log Status Commands

name	Type	Description
	Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Eqpt::XPonId> - the XGS PON identifier Field type <Eqpt::M25GPonId> - the 25G PON identifier	

Only Show Details: current and previous alarm log status		
name	Type	Description
olt-pon-tc-err-frag-tc	Parameter type: <Alarm::OLTPONTCTCAERRFRAGSPON> (yes no) Possible values: - yes : pon errored fragments threshold crossed - no : olt works properly	pon errored fragments threshold crossed <i>This element is only shown in detail mode.</i>
olt-pon-up-bw-tca	Parameter type: <Alarm::OLTPONTCTCAUPBWTCa> (yes no) Possible values: - yes : olt pon upstream bandwidth tca - no : olt works properly	OLT PON upstream bandwidth TCA <i>This element is only shown in detail mode.</i>
olt-pon-down-bw-tca	Parameter type: <Alarm::OLTPONTCTCADWBWTCA> (yes no) Possible values: - yes : olt pon downstream bandwidth tca - no : olt works properly	OLT PON downstream bandwidth TCA <i>This element is only shown in detail mode.</i>

102.126 OLT PON Utilization TCA Alarm Log Status Command

Command Description

This command displays the OLT PON utilization TCA alarm log status.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm log olt-pon-util-tca [ (index) ]
```

Command Parameters

Table 102.126-1 " OLT PON Utilization TCA Alarm Log Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm type

Command Output

Table 102.126-2 " OLT PON Utilization TCA Alarm Log Status Command" Display parameters

Specific Information		
name	Type	Description
last-updated-on	Parameter type: <Sys::timeInSecs> - the time (yyyy-mm-dd:hour:minutes:secs) - unit: UTC	network time in seconds when the alarm was logged <i>This element is only shown in detail mode.</i>
pon	Parameter type: <Gpon::PonId> (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> x-pon : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::XPonId> 25g-pon : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::M25GPonId>) Possible values: - 25g-pon : 25g pon - x-pon : Xgs pon Field type <Eqpt::RackId> - the rack number	pon ifindex <i>This element is only shown in detail mode.</i>

102 Alarm Log Status Commands

name	Type	Description
	Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Eqpt::XPonId> - the XGS PON identifier Field type <Eqpt::M25GPonId> - the 25G PON identifier	

Only Show Details: current and previous alarm log status		
name	Type	Description
pon-t-txmcutilhi	Parameter type: <Alarm::TXMCUTILHI> (yes no) Possible values: - yes : tx mcast utilization high tca - no : olt works properly	pon utilization tx (downstream) multicast high threshold crossed <i>This element is only shown in detail mode.</i>
pon-t-txmcutilmd	Parameter type: <Alarm::TXMCUTILMD> (yes no) Possible values: - yes : tx mcast utilization medium tca - no : olt works properly	pon utilization tx (downstream) multicast medium threshold crossed <i>This element is only shown in detail mode.</i>
pon-t-txmcutillo	Parameter type: <Alarm::TXMCUTILLO> (yes no) Possible values: - yes : tx mcast utilization low tca - no : olt works properly	pon utilization tx (downstream) multicast low threshold crossed <i>This element is only shown in detail mode.</i>
pon-t-txtotutilhi	Parameter type: <Alarm::TXTOTUTILHI> (yes no) Possible values: - yes : tx total utilization high tca - no : olt works properly	pon utilization tx (downstream) total high threshold crossed <i>This element is only shown in detail mode.</i>
pon-t-txtotutilmd	Parameter type: <Alarm::TXTOTUTILMD> (yes no) Possible values: - yes : tx total utilization medium tca - no : olt works properly	pon utilization tx (downstream) total medium threshold crossed <i>This element is only shown in detail mode.</i>
pon-t-txtotutillo	Parameter type: <Alarm::TXTOTUTILLO> (yes no) Possible values: - yes : tx total utilization low tca - no : olt works properly	pon utilization tx (downstream) total low threshold crossed <i>This element is only shown in detail mode.</i>
pon-t-rxtotutilhi	Parameter type: <Alarm::RXTOTUTILHI> (yes no) Possible values: - yes : rx total utilization high tca - no : olt works properly	pon utilization rx (upstream) total high threshold crossed <i>This element is only shown in detail mode.</i>
pon-t-rxtotutilmd	Parameter type: <Alarm::RXTOTUTILMD> (yes no)	pon utilization rx (upstream) total medium threshold crossed <i>This element is only shown in detail mode.</i>

name	Type	Description
	Possible values: - yes : rx total utilization medium tca - no : olt works properly	<i>detail mode.</i>
pon-t-rxtotutillo	Parameter type: <Alarm::RXTOTUTILLO> (yes no) Possible values: - yes : rx total utilization low tca - no : olt works properly	pon utilization rx (upstream) total low threshold crossed <i>This element is only shown in detail mode.</i>
pon-t-dbacongperiodhi	Parameter type: <Alarm::DBACONGPERIODHI> (yes no) Possible values: - yes : rx dba congestion period high tca - no : olt works properly	pon utilization rx (upstream) dbacongperiod high threshold crossed <i>This element is only shown in detail mode.</i>
pon-t-dbacongperiodmd	Parameter type: <Alarm::DBACONGPERIODMD> (yes no) Possible values: - yes : rx dba congestion period medium tca - no : olt works properly	pon utilization rx (upstream) dbacongperiod medium threshold crossed <i>This element is only shown in detail mode.</i>
pon-t-dbacongperiodlo	Parameter type: <Alarm::DBACONGPERIODLO> (yes no) Possible values: - yes : rx dba congestion period low tca - no : olt works properly	pon utilization rx (upstream) dbacongperiod low threshold crossed <i>This element is only shown in detail mode.</i>
pon-t-txucdropfrmhi	Parameter type: <Alarm::TXUCDROPFRMHI> (yes no) Possible values: - yes : tx unicast dropped packet high tca - no : olt works properly	pon utilization tx (downstream) unicast drop frame high threshold crossed <i>This element is only shown in detail mode.</i>
pon-t-txucdropfrmmd	Parameter type: <Alarm::TXUCDROPFRMMD> (yes no) Possible values: - yes : tx unicast dropped packet medium tca - no : olt works properly	pon utilization tx (downstream) unicast drop frame medium threshold crossed <i>This element is only shown in detail mode.</i>
pon-t-txucdropfrmlo	Parameter type: <Alarm::TXUCDROPFRMLO> (yes no) Possible values: - yes : tx unicast dropped packet low tca - no : olt works properly	pon utilization tx (downstream) unicast drop frame low threshold crossed <i>This element is only shown in detail mode.</i>
pon-t-txmcdropfrmhi	Parameter type: <Alarm::TXMCDROPFRMHI> (yes no) Possible values: - yes : tx multicast dropped packet high tca - no : olt works properly	pon utilization tx (downstream) multicast drop frame high threshold crossed <i>This element is only shown in detail mode.</i>
pon-t-txmcdropfrmmd	Parameter type: <Alarm::TXMCDROPFRMMD> (yes no) Possible values: - yes : tx multicast dropped packet medium tca - no : olt works properly	pon utilization tx (downstream) multicast drop frame medium threshold crossed <i>This element is only shown in detail mode.</i>

102 Alarm Log Status Commands

name	Type	Description
pon-t-txmcdropfrmlo	Parameter type: <Alarm::TXMCDROPFRMLO> (yes no) Possible values: - yes : tx multicast dropped packet low tca - no : olt works properly	pon utilization tx (downstream) multicast drop frame low threshold crossed <i>This element is only shown in detail mode.</i>
pon-t-txbcdropfrmhi	Parameter type: <Alarm::TXBCDROPFRMHI> (yes no) Possible values: - yes : tx broadcast dropped packet high tca - no : olt works properly	pon utilization tx (downstream) broadcast drop frame high threshold crossed <i>This element is only shown in detail mode.</i>
pon-t-txbcdropfrmmd	Parameter type: <Alarm::TXBCDROPFRMMD> (yes no) Possible values: - yes : tx broadcast dropped packet medium tca - no : olt works properly	pon utilization tx (downstream) broadcast drop frame medium threshold crossed <i>This element is only shown in detail mode.</i>
pon-t-txbcdropfrmlo	Parameter type: <Alarm::TXBCDROPFRMLO> (yes no) Possible values: - yes : tx broadcast dropped packet low tca - no : olt works properly	pon utilization tx (downstream) broadcast drop frame low threshold crossed <i>This element is only shown in detail mode.</i>
pon-t-rxtotdropfrmhi	Parameter type: <Alarm::RXTOTDROPFRMHI> (yes no) Possible values: - yes : rx total dropped packet high tca - no : olt works properly	pon utilization rx (upstream) total drop frame high threshold crossed <i>This element is only shown in detail mode.</i>
pon-t-rxtotdropfrmmd	Parameter type: <Alarm::RXTOTDROPFRMMD> (yes no) Possible values: - yes : rx total dropped packet medium tca - no : olt works properly	pon utilization rx (upstream) total drop frame medium threshold crossed <i>This element is only shown in detail mode.</i>
pon-t-rxtotdropfrmlo	Parameter type: <Alarm::RXTOTDROPFRMLO> (yes no) Possible values: - yes : rx total dropped packet low tca - no : olt works properly	pon utilization rx (upstream) total drop frame low threshold crossed <i>This element is only shown in detail mode.</i>

102.127 OLT Channel Pair Utilization TCA Alarm Log Status Command

Command Description

This command displays the channel-pair utilization TCA alarm log status.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

> show alarm log olt-chpr-util-tca [(index)]

Command Parameters

Table 102.127-1 "OLT Channel Pair Utilization TCA Alarm Log Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm type

Command Output

Table 102.127-2 "OLT Channel Pair Utilization TCA Alarm Log Status Command" Display parameters

Specific Information		
name	Type	Description
last-updated-on	Parameter type: <Sys::timeInSecs> - the time (yyyy-mm-dd:hour:minutes:secs) - unit: UTC	network time in seconds when the alarm was logged <i>This element is only shown in detail mode.</i>
channel-pair	Parameter type: <Gpon::ChannelPairId> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::ChannelPairId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::ChannelPairId>	channel-pair ifindex <i>This element is only shown in detail mode.</i>

102 Alarm Log Status Commands

name	Type	Description
	- the channel pair identifier	

Only Show Details: current and previous alarm log status		
name	Type	Description
chpr-t-txmcutilhi	Parameter type: <Alarm::TXMCUTILHI> (yes no) Possible values: - yes : tx mcast utilization high tca - no : olt works properly	channel-pair utilization tx (downstream) multicast high threshold crossed <i>This element is only shown in detail mode.</i>
chpr-t-txmcutilmd	Parameter type: <Alarm::TXMCUTILMD> (yes no) Possible values: - yes : tx mcast utilization medium tca - no : olt works properly	channel-pair utilization tx (downstream) multicast medium threshold crossed <i>This element is only shown in detail mode.</i>
chpr-t-txmcutillo	Parameter type: <Alarm::TXMCUTILLO> (yes no) Possible values: - yes : tx mcast utilization low tca - no : olt works properly	channel-pair utilization tx (downstream) multicast low threshold crossed <i>This element is only shown in detail mode.</i>
chpr-t-txtotutilhi	Parameter type: <Alarm::TXTOTUTILHI> (yes no) Possible values: - yes : tx total utilization high tca - no : olt works properly	channel-pair utilization tx (downstream) total high threshold crossed <i>This element is only shown in detail mode.</i>
chpr-t-txtotutilmd	Parameter type: <Alarm::TXTOTUTILMD> (yes no) Possible values: - yes : tx total utilization medium tca - no : olt works properly	#hannel-pair utilization tx (downstream) total medium threshold crossed <i>This element is only shown in detail mode.</i>
chpr-t-txtotutillo	Parameter type: <Alarm::TXTOTUTILLO> (yes no) Possible values: - yes : tx total utilization low tca - no : olt works properly	channel-pair utilization util tx (downstream) total low threshold crossed <i>This element is only shown in detail mode.</i>
chpr-t-rxtotutilhi	Parameter type: <Alarm::RXTOTUTILHI> (yes no) Possible values: - yes : rx total utilization high tca - no : olt works properly	channel-pair utilization rx (upstream) total high threshold crossed <i>This element is only shown in detail mode.</i>
chpr-t-rxtotutilmd	Parameter type: <Alarm::RXTOTUTILMD> (yes no) Possible values: - yes : rx total utilization medium tca - no : olt works properly	channel-pair utilization rx (upstream) total medium threshold crossed <i>This element is only shown in detail mode.</i>
chpr-t-rxtotutillo	Parameter type: <Alarm::RXTOTUTILLO> (yes no) Possible values: - yes : rx total utilization low tca - no : olt works properly	channel-pair utilization rx (upstream) total low threshold crossed <i>This element is only shown in detail mode.</i>

name	Type	Description
chpr-t-dbacongperiodhi	Parameter type: <Alarm::DBACONGPERIODHI> (yes no) Possible values: - yes : rx dba congestion period high tca - no : olt works properly	channel-pair utilization rx (upstream) dba congestion period high threshold crossed <i>This element is only shown in detail mode.</i>
chpr-t-dbacongperiodmd	Parameter type: <Alarm::DBACONGPERIODMD> (yes no) Possible values: - yes : rx dba congestion period medium tca - no : olt works properly	channel-pair utilization rx (upstream) dba congestion period medium threshold crossed <i>This element is only shown in detail mode.</i>
chpr-t-dbacongperiodlo	Parameter type: <Alarm::DBACONGPERIODLO> (yes no) Possible values: - yes : rx dba congestion period low tca - no : olt works properly	channel-pair utilization rx (upstream) dba congestion period low threshold crossed <i>This element is only shown in detail mode.</i>
chpr-t-txucdropfrmhi	Parameter type: <Alarm::TXUCDROPFRMHI> (yes no) Possible values: - yes : tx unicast dropped packet high tca - no : olt works properly	channel-pair utilization tx (downstream) unicast drop frame high threshold crossed <i>This element is only shown in detail mode.</i>
chpr-t-txucdropfrmmd	Parameter type: <Alarm::TXUCDROPFRMMD> (yes no) Possible values: - yes : tx unicast dropped packet medium tca - no : olt works properly	channel-pair utilization tx (downstream) unicast drop frame medium threshold crossed <i>This element is only shown in detail mode.</i>
chpr-t-txucdropfrmlo	Parameter type: <Alarm::TXUCDROPFRMLO> (yes no) Possible values: - yes : tx unicast dropped packet low tca - no : olt works properly	channel-pair utilization tx (downstream) unicast drop frame low threshold crossed <i>This element is only shown in detail mode.</i>
chpr-t-txmcdropfrmhi	Parameter type: <Alarm::TXMCDROPFRMHI> (yes no) Possible values: - yes : tx multicast dropped packet high tca - no : olt works properly	channel-pair utilization tx (downstream) multicast drop frame high threshold crossed <i>This element is only shown in detail mode.</i>
chpr-t-txmcdropfrmmd	Parameter type: <Alarm::TXMCDROPFRMMD> (yes no) Possible values: - yes : tx multicast dropped packet medium tca - no : olt works properly	channel-pair utilization tx (downstream) multicast drop frame medium threshold crossed <i>This element is only shown in detail mode.</i>
chpr-t-txmcdropfrmlo	Parameter type: <Alarm::TXMCDROPFRMLO> (yes no) Possible values: - yes : tx multicast dropped packet low tca - no : olt works properly	channel-pair utilization tx (downstream) multicast drop frame low threshold crossed <i>This element is only shown in detail mode.</i>
chpr-t-txbcdropfrmhi	Parameter type: <Alarm::TXBCDROPFRMHI> (yes no)	channel-pair utilization tx (downstream) broadcast drop frame high threshold crossed

102 Alarm Log Status Commands

name	Type	Description
	Possible values: - yes : tx broadcast dropped packet high tca - no : olt works properly	<i>This element is only shown in detail mode.</i>
chpr-t-txbcdropfrmmd	Parameter type: <Alarm::TXBCDROPPFRMMD> (yes no) Possible values: - yes : tx broadcast dropped packet medium tca - no : olt works properly	channel-pair utilization tx (downstream) broadcast drop frame medium threshold crossed <i>This element is only shown in detail mode.</i>
chpr-t-txbcdropfrmlo	Parameter type: <Alarm::TXBCDROPPFRMLO> (yes no) Possible values: - yes : tx broadcast dropped packet low tca - no : olt works properly	channel-pair utilization tx (downstream) broadcast drop frame low threshold crossed <i>This element is only shown in detail mode.</i>
chpr-t-rxtotdropfrmhi	Parameter type: <Alarm::RXTOTDROPPFRMHI> (yes no) Possible values: - yes : rx total dropped packet high tca - no : olt works properly	channel-pair utilization rx (upstream) total drop frame high threshold crossed <i>This element is only shown in detail mode.</i>
chpr-t-rxtotdropfrmmd	Parameter type: <Alarm::RXTOTDROPPFRMMD> (yes no) Possible values: - yes : rx total dropped packet medium tca - no : olt works properly	channel-pair utilization rx (upstream) total drop frame medium threshold crossed <i>This element is only shown in detail mode.</i>
chpr-t-rxtotdropfrmlo	Parameter type: <Alarm::RXTOTDROPPFRMLO> (yes no) Possible values: - yes : rx total dropped packet low tca - no : olt works properly	channel-pair utilization rx (upstream) total drop frame low threshold crossed <i>This element is only shown in detail mode.</i>

102.128 OLT ONT TC TCA Alarm Log Status Command

Command Description

This command displays the OLT ONT TC TCA alarm log status.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm log olt-ont-tc-tca [ (index) ]
```

Command Parameters

Table 102.128-1 " OLT ONT TC TCA Alarm Log Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm type

Command Output

Table 102.128-2 " OLT ONT TC TCA Alarm Log Status Command" Display parameters

Specific Information		
name	Type	Description
last-updated-on	Parameter type: <Sys::timeInSecs> - the time (yyyy-mm-dd:hour:minutes:secs) - unit: UTC	network time in seconds when the alarm was logged <i>This element is only shown in detail mode.</i>
ont	Parameter type: <Gpon::OntIndex> (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> ng2 : <Ng2::ChannelGroup> / <Ng2::SubchannelGroup> / <Ng2::OntId>) Possible values: - ng2 : ngpon2 style identification Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId>	identifies the ont entry <i>This element is only shown in detail mode.</i>

102 Alarm Log Status Commands

name	Type	Description
	- the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Ng2::ChannelGroup> - channel group number Field type <Ng2::SubchannelGroup> - subchannel group number Field type <Eqpt::OntId> - the ONT identifier Field type <Ng2::OntId> - the ONT identifier	

Only Show Details: current and previous alarm log status		
name	Type	Description
olt-ont-tc-err-frag-tc	Parameter type: <Alarm::OLTONTTCTCAERRFRAGSONT> (yes no) Possible values: - yes : ont errored fragments threshold crossed - no : olt works properly	ont errored fragments threshold crossed <i>This element is only shown in detail mode.</i>

102.129 ONT POTS SUPPLEMENTAL Alarm Log Status Command

Command Description

This command displays the ONT POTS SUPPLEMENTAL alarm log status.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm log ont-pots-supplemental [ (index) ]
```

Command Parameters

Table 102.129-1 " ONT POTS SUPPLEMENTAL Alarm Log Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm type

Command Output

Table 102.129-2 " ONT POTS SUPPLEMENTAL Alarm Log Status Command" Display parameters

Specific Information		
name	Type	Description
last-updated-on	Parameter type: <Sys::timeInSecs> - the time (yyyy-mm-dd:hour:minutes:secs) - unit: UTC	network time in seconds when the alarm was logged <i>This element is only shown in detail mode.</i>
ont-port	Parameter type: <Gpon::IfIndexAlarmIndex2> (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Gpon::OntSlotId> / <Gpon::OntPortId> ng2 : <Ng2::ChannelGroup> / <Ng2::SubchannelGroup> / <Ng2::OntId> / <Gpon::OntSlotId> / <Gpon::OntPortId>) Possible values: - ng2 : ngpon2 style identification Field type <Eqpt::RackId> - the rack number	gpon ont port <i>This element is only shown in detail mode.</i>

102 Alarm Log Status Commands

name	Type	Description
	Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Ng2::ChannelGroup> - channel group number Field type <Ng2::SubchannelGroup> - subchannel group number Field type <Eqpt::OntId> - the ONT identifier Field type <Ng2::OntId> - the ONT identifier Field type <Gpon::OntSlotId> - Gpon Ont Slot - range: [1...14] Field type <Gpon::OntPortId> - Gpon Ont Port - range: [1...16]	

Only Show Details: current and previous alarm log status		
name	Type	Description
ont-sip-reg-dns	Parameter type: <Alarm::ONTSERVICESPOTSSIPREGDNS> (yes no) Possible values: - yes : sip registration failed because the domain name could not be resolved - no : sip registration succeeds	ont services pots sip registration failed (resolving domain name) <i>This element is only shown in detail mode.</i>
ont-sip-reg-fail	Parameter type: <Alarm::ONTSERVICESPOTSSIPREGAUTH> (yes no) Possible values: - yes : sip registration failed because authentication failed - no : sip registration succeeds	ont services pots sip registration authentication failed <i>This element is only shown in detail mode.</i>
ont-sip-reg-timeout	Parameter type: <Alarm::ONTSERVICESPOTSSIPREGTO> (yes no) Possible values: - yes : sip registration failed because all attempted retransmissions timed out - no : sip registration succeeds	ont services pots sip registration timeout <i>This element is only shown in detail mode.</i>
ont-sip-reg-err-resps	Parameter type: <Alarm::ONTSERVICESPOTSSIPREGERR> (yes no) Possible values: - yes : sip registration failed because error response from the registration server - no : sip registration succeeds	ont services pots sip registration response error <i>This element is only shown in detail mode.</i>
ont-sip-inv-dns	Parameter type: <Alarm::ONTSERVICESPOTSSIPINVDNS> (yes no)	ont services pots sip invite failed (resolving domain name) <i>This element is only shown in detail mode.</i>

name	Type	Description
	Possible values: - yes : sip invite failed because the domain name could not be resolved - no : sip invite succeeds	
ont-sip-inv-auth	Parameter type: <Alarm::ONTSERVICESPOTSSIPINVAUTH> (yes no) Possible values: - yes : sip invite failed because authentication failed - no : sip invite succeeds	ont services pots sip invite authentication failed <i>This element is only shown in detail mode.</i>
ont-sip-inv-timeout	Parameter type: <Alarm::ONTSERVICESPOTSSIPINVTO> (yes no) Possible values: - yes : sip invite failed because all attempted retransmissions timed out - no : sip invite succeeds	ont services pots sip invite timeout <i>This element is only shown in detail mode.</i>
ont-sip-inv-err	Parameter type: <Alarm::ONTSERVICESPOTSSIPINVERR> (yes no) Possible values: - yes : sip invite failed because error response from the registration server - no : sip invite succeeds	ont services pots sip invite response error <i>This element is only shown in detail mode.</i>
ont-svc-pots-subs-refr	Parameter type: <Alarm::ONTSERVICESPOTSSUBSREFR> (yes no) Possible values: - yes : pots iconfig subscription could not be refreshed - no : pots iconfig subscription refreshed	ont services pots iconfig subscription could not be refreshed <i>This element is only shown in detail mode.</i>
ont-svc-pots-not-refr	Parameter type: <Alarm::ONTSERVICESPOTSNOTREFR> (yes no) Possible values: - yes : pots iconfig notify response for refresh subscribe failed - no : pots iconfig notify response for refresh subscribe succeeds	ont services pots iconfig notification could not be refreshed <i>This element is only shown in detail mode.</i>
ont-svc-pots-icfg-err	Parameter type: <Alarm::ONTSERVICESPOTSICFGERR> (yes no) Possible values: - yes : pots service failed due to an unmapped iconfig error - no : pots service works properly	ont services pots service failed due to an unmapped iconfig error <i>This element is only shown in detail mode.</i>

102.130 ONT VEIP Alarm Log Status Command

Command Description

This command displays the ONT VEIP alarm log status.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm log ont-veip [ (index) ]
```

Command Parameters

Table 102.130-1 " ONT VEIP Alarm Log Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm type

Command Output

Table 102.130-2 " ONT VEIP Alarm Log Status Command" Display parameters

Specific Information		
name	Type	Description
last-updated-on	Parameter type: <Sys::timeInSecs> - the time (yyyy-mm-dd:hour:minutes:secs) - unit: UTC	network time in seconds when the alarm was logged <i>This element is only shown in detail mode.</i>
ont-port	Parameter type: <Gpon::IfIndexAlarmIndex2> (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Gpon::OntSlotId> / <Gpon::OntPortId> ng2 : <Ng2::ChannelGroup> / <Ng2::SubchannelGroup> / <Ng2::OntId> / <Gpon::OntSlotId> / <Gpon::OntPortId>) Possible values: - ng2 : ngpon2 style identification Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId>	gpon ont port <i>This element is only shown in detail mode.</i>

name	Type	Description
	- the PON identifier - Field type <Ng2::ChannelGroup> - channel group number - Field type <Ng2::SubchannelGroup> - subchannel group number - Field type <Eqpt::OntId> - the ONT identifier - Field type <Ng2::OntId> - the ONT identifier - Field type <Gpon::OntSlotId> - Gpon Ont Slot - range: [1...14] - Field type <Gpon::OntPortId> - Gpon Ont Port - range: [1...16]	

Only Show Details: current and previous alarm log status		
name	Type	Description
ont-veip-mismatch	Parameter type: <Alarm::ONTVEIPMISMATCH> (yes no) Possible values: - yes : ont veip mismatch - no : ont veip match	ont veip mismatch <i>This element is only shown in detail mode.</i>

102.131 ONT IP HOST Alarm Log Status Command

Command Description

This command displays the ONT IP HOST alarm log status.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm log ont-iphost [ (index) ]
```

Command Parameters

Table 102.131-1 " ONT IP HOST Alarm Log Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm type

Command Output

Table 102.131-2 " ONT IP HOST Alarm Log Status Command" Display parameters

Specific Information		
name	Type	Description
last-updated-on	Parameter type: <Sys::timeInSecs> - the time (yyyy-mm-dd:hour:minutes:secs) - unit: UTC	network time in seconds when the alarm was logged <i>This element is only shown in detail mode.</i>
port	Parameter type: <Gpon::IpHostCommonIndex> (ont : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Gpon::IpHostId> vlanport : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / vuni : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlanport : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / vuni : <Eqpt::UnstackedVlan> ont:ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / <Ng2::IpHostId> vlanport:ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / vuni : stacked : <Eqpt::SVlan> : <Eqpt::CVlan>	gpon iphost port <i>This element is only shown in detail mode.</i>

name	Type	Description
	vlanport:ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / vuni : <Eqpt::UnstackedVlan>) Possible values: - ont:ng2 : ngpon2 ont - vlanport:ng2 : ngpon2 vlanport - ont : ont - vlanport : vlanport Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Eqpt::OntId> - the ONT identifier Field type <Eqpt::ChannelGroupId> - the channel group identifier Field type <Eqpt::SubChannelGroupId> - the subchannel group identifier Field type <Eqpt::Ng2OntId> - the NG2 ONT identifier Possible values: - vuni : virtual uni identifier Possible values: - vuni : virtual NGPON2 uni identifier Field type <Gpon::IpHostID> - iphost id Field type <Ng2::IpHostID> - iphost id (ngpon2) Possible values: - stacked : stacked vlan identity Field type <Eqpt::UnstackedVlan> - unstacked vlan id Field type <Eqpt::SVlan> - service vlan id Field type <Eqpt::CVlan> - customer vlan id	

Only Show Details: current and previous alarm log status		
name	Type	Description
ont-ip-host-mismatch	Parameter type: <Alarm::ONTIPHOS TMIS> (yes no) Possible values: - yes : ont ip host mismatch - no : ont ip host match	ont ip host mismatch <i>This element is only shown in detail mode.</i>
ont-ip-host-ip-alloc	Parameter type: <Alarm::ONTIPHOS TFAIL> (yes no) Possible values: - yes : ont ip host IP allocation failure - no : ont ip host IP allocation works properly	ont ip host IP allocation failure <i>This element is only shown in detail mode.</i>

102.132 Alarm Table Alarm Log Status Command

Command Description

This command displays the alarm-table alarm log status.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

> show alarm log alarm-table [(index)]

Command Parameters

Table 102.132-1 "Alarm Table Alarm Log Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm log table index

Command Output

Table 102.132-2 "Alarm Table Alarm Log Status Command" Display parameters

Specific Information		
name	Type	Description
last-updated-on	Parameter type: <Sys::timeInSecs> - the time (yyyy-mm-dd:hour:minutes:secs) - unit: UTC	network time in seconds when the alarm was logged. <i>This element is only shown in detail mode.</i>
Only Show Details: current and previous alarm log status		
name	Type	Description
alarm-tbl-overflow	Parameter type: <Alarm::AlrmTblOflow> (overflow no-overflow) Possible values: - overflow : alarm table overflow - no-overflow : no alarm table overflow	identify if the alarm table has overflowed <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::AlrmTblOflow> (overflow no-overflow) Possible values: - overflow : alarm table overflow - no-overflow : no alarm table overflow	previously logged value of the alarm table overflow alarm <i>This element is only shown in detail mode.</i>

102.133 ONT VIDEO Alarm Log Status Command

Command Description

This command displays the ONT VIDEO alarm log status.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

> show alarm log ont-video [(index)]

Command Parameters

Table 102.133-1 " ONT VIDEO Alarm Log Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm type

Command Output

Table 102.133-2 " ONT VIDEO Alarm Log Status Command" Display parameters

Specific Information		
name	Type	Description
last-updated-on	Parameter type: <Sys::timeInSecs> - the time (yyyy-mm-dd:hour:minutes:secs) - unit: UTC	network time in seconds when the alarm was logged <i>This element is only shown in detail mode.</i>
video-port	Parameter type: <Gpon::IfIndexAlarmIndex2> (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Gpon::OntSlotId> / <Gpon::OntPortId> ng2 : <Ng2::ChannelGroup> / <Ng2::SubchannelGroup> / <Ng2::OntId> / <Gpon::OntSlotId> / <Gpon::OntPortId>) Possible values: - ng2 : ngpon2 style identification Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId>	video port <i>This element is only shown in detail mode.</i>

name	Type	Description
	- the PON identifier - Field type <Ng2::ChannelGroup> - channel group number - Field type <Ng2::SubchannelGroup> - subchannel group number - Field type <Eqpt::OntId> - the ONT identifier - Field type <Ng2::OntId> - the ONT identifier - Field type <Gpon::OntSlotId> - Gpon Ont Slot - range: [1...14] - Field type <Gpon::OntPortId> - Gpon Ont Port - range: [1...16]	

Only Show Details: current and previous alarm log status		
name	Type	Description
ont-svc-video-conf-mis	Parameter type: <Alarm::ONTVIDEOUNISVCMIS> (yes no) Possible values: - yes : config request failure for video service - no : ont service is ok	config request failure for video service <i>This element is only shown in detail mode.</i>
ont-svc-video-pw-high	Parameter type: <Alarm::ONTRFOUTHIGH> (yes no) Possible values: - yes : high power level for rf video signal - no : ont service is ok	high power level for rf video signal <i>This element is only shown in detail mode.</i>
ont-svc-video-pw-low	Parameter type: <Alarm::ONTRFOUTLOW> (yes no) Possible values: - yes : low power level for rf video signal - no : ont service is ok	low power level for rf video signal <i>This element is only shown in detail mode.</i>

102.134 ONT CES Alarm Log Status Command

Command Description

This command displays the ONT CES alarm log status.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm log ont-ces [ (index) ]
```

Command Parameters

Table 102.134-1 " ONT CES Alarm Log Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm type

Command Output

Table 102.134-2 " ONT CES Alarm Log Status Command" Display parameters

Specific Information		
name	Type	Description
last-updated-on	Parameter type: <Sys::timeInSecs> - the time (yyyy-mm-dd:hour:minutes:secs) - unit: UTC	network time in seconds when the alarm was logged <i>This element is only shown in detail mode.</i>
cesds1-port	Parameter type: <Gpon::IfIndexAlarmIndex2> (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Gpon::OntSlotId> / <Gpon::OntPortId> ng2 : <Ng2::ChannelGroup> / <Ng2::SubchannelGroup> / <Ng2::OntId> / <Gpon::OntSlotId> / <Gpon::OntPortId>) Possible values: - ng2 : ngpon2 style identification Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId>	ces port <i>This element is only shown in detail mode.</i>

name	Type	Description
	- the PON identifier - Field type <Ng2::ChannelGroup> - channel group number - Field type <Ng2::SubchannelGroup> - subchannel group number - Field type <Eqpt::OntId> - the ONT identifier - Field type <Ng2::OntId> - the ONT identifier - Field type <Gpon::OntSlotId> - Gpon Ont Slot - range: [1...14] - Field type <Gpon::OntPortId> - Gpon Ont Port - range: [1...16]	

Only Show Details: current and previous alarm log status		
name	Type	Description
ont-svc-ces-ds1-mis	Parameter type: <Alarm::ONTCESDS1SVCNIS> (yes no) Possible values: - yes : ont service mismatch for provisioned ces ds1 - no : ont service is ok	ont service mismatch for provisioned ces ds1 <i>This element is only shown in detail mode.</i>
ont-svc-ces-ds1-los	Parameter type: <Alarm::ONTCESDS1LOS> (yes no) Possible values: - yes : loss of signal at ds1 interface - no : ont service is ok	loss of signal at ds1 interface <i>This element is only shown in detail mode.</i>
ont-svc-ces-ds1-lof	Parameter type: <Alarm::ONTCESDS1LOF> (yes no) Possible values: - yes : loss of frame at ds1 interface - no : ont service is ok	loss of frame at ds1 interface <i>This element is only shown in detail mode.</i>
ont-svc-ces-ds1-rair	Parameter type: <Alarm::ONTCESDS1RAIR> (yes no) Possible values: - yes : receiving rai at ds1 interface - no : ont service is ok	receiving rai at ds1 interface <i>This element is only shown in detail mode.</i>
ont-svc-ces-ds1-ais	Parameter type: <Alarm::ONTCESDS1AISR> (yes no) Possible values: - yes : receiving ais at ds1 interface - no : ont service is ok	receiving ais at ds1 interface <i>This element is only shown in detail mode.</i>
ont-svc-ces-ds1-lnlpbk	Parameter type: <Alarm::ONTCESDS1LNLBPBK> (yes no) Possible values: - yes : receiving line loopback at ds1 interface - no : ont service is ok	receiving line loopback at ds1 interface <i>This element is only shown in detail mode.</i>
ont-svc-ces-ds1-tmlpbk	Parameter type: <Alarm::ONTCESDS1TMLPBK> (yes no) Possible values:	receiving terminal loopback at ds1 interface <i>This element is only shown in detail mode.</i>

102 Alarm Log Status Commands

name	Type	Description
	- yes : receiving terminal loopback at ds1 interface - no : ont service is ok	

102.135 ONT VOIP Alarm Log Status Command

Command Description

This command displays the ONT VOIP alarm log status.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm log ont-voip [ (index) ]
```

Command Parameters

Table 102.135-1 " ONT VOIP Alarm Log Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm type

Command Output

Table 102.135-2 " ONT VOIP Alarm Log Status Command" Display parameters

Specific Information		
name	Type	Description
last-updated-on	Parameter type: <Sys::timeInSecs> - the time (yyyy-mm-dd:hour:minutes:secs) - unit: UTC	network time in seconds when the alarm was logged <i>This element is only shown in detail mode.</i>
voip-uni	Parameter type: <Gpon::VoipOntIndex> (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / 1 ng2 : <Ng2::ChannelGroup> / <Ng2::SubchannelGroup> / <Ng2::OntId> / 1) Possible values: - ng2 : ngpon2 style identification Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier	voip uni ifindex <i>This element is only shown in detail mode.</i>

102 Alarm Log Status Commands

name	Type	Description
	Field type <Eqpt::OntId> - the ONT identifier Possible values: - 1 : Gpon voip Port Field type <Ng2::ChannelGroup> - channel group number Field type <Ng2::SubchannelGroup> - subchannel group number Field type <Ng2::OntId> - the ONT identifier Possible values: - 1 : Gpon voip Port	
client-number	Parameter type: <Gpon::AlarmIndex2Integer> - a signed integer	service client number <i>This element is only shown in detail mode.</i>

Only Show Details: current and previous alarm log status		
name	Type	Description
ont-svc-voip-cnf-file	Parameter type: <Alarm::ONTVOICONFIGFLERR> (yes no) Possible values: - yes : voice configuration file error - no : ont service is ok	voice configuration file error <i>This element is only shown in detail mode.</i>
ont-svc-voip-svc-mis	Parameter type: <Alarm::ONTVOICLISERMIS> (yes no) Possible values: - yes : service mismatch for provisioned client service - no : ont service is ok	service mismatch for provisioned client service <i>This element is only shown in detail mode.</i>
ont-svc-voip-gw-comm	Parameter type: <Alarm::ONTVOIGATWCOMFAIL> (yes no) Possible values: - yes : voice gateway communication failure - no : ont service is ok	voice gateway communication failure <i>This element is only shown in detail mode.</i>
ont-svc-voip-dhcp-fail	Parameter type: <Alarm::ONTVOIDHCPSEFAIL> (yes no) Possible values: - yes : voice gateway communication failure - no : ont service is ok	voice dhcp server failure <i>This element is only shown in detail mode.</i>
ont-svc-voip-icnf-sub	Parameter type: <Alarm::ONTVOIICONSUBFAIL> (yes no) Possible values: - yes : voice iconfig subscription failure - no : ont service is ok	voice iconfig subscription failure <i>This element is only shown in detail mode.</i>
ont-svc-voip-icnf-ntfy	Parameter type: <Alarm::ONTVOIICONNOTFAIL> (yes no) Possible values: - yes : voice iconfig notify failure - no : ont service is ok	voice iconfig notify failure <i>This element is only shown in detail mode.</i>
ont-svc-voip-icnf-http	Parameter type: <Alarm::ONTVOIICONHTTPFAIL> (yes no) Possible values:	voice iconfig http failure <i>This element is only shown in detail mode.</i>

name	Type	Description
	- yes : voice iconfig http failure - no : ont service is ok	
ont-svc-voip-dhcp-to	Parameter type: <Alarm::ONTVOIDHCPTO> (yes no) Possible values: - yes : DHCP server retransmissions timed out - no : ont service is ok	DHCP server retransmissions timed out <i>This element is only shown in detail mode.</i>
ont-svc-voip-dhcp-mal	Parameter type: <Alarm::ONTVOIDHCPMAL> (yes no) Possible values: - yes : DHCP response was malformed - no : ont service is ok	DHCP response was malformed <i>This element is only shown in detail mode.</i>
ont-svc-voip-dhcp-noad	Parameter type: <Alarm::ONTVOIDHCPNOAD> (yes no) Possible values: - yes : DHCP server failed to issue the required parameters - no : ont service is ok	DHCP server failed to issue the required parameters <i>This element is only shown in detail mode.</i>
ont-svc-voip-dhcp-leas	Parameter type: <Alarm::ONTVOIDHCPLEAS> (yes no) Possible values: - yes : DHCP Server failure due to problem in lease renewal - no : ont service is ok	DHCP Server failure due to problem in lease renewal <i>This element is only shown in detail mode.</i>
ont-svc-voip-subscription-dns	Parameter type: <Alarm::ONTVOIICONDNS> (yes no) Possible values: - yes : iConfig Subscription failure due to DNS problem - no : ont service is ok	iConfig Subscription failure due to DNS problem <i>This element is only shown in detail mode.</i>
ont-svc-voip-subscription-tcp	Parameter type: <Alarm::ONTVOIICONTCP> (yes no) Possible values: - yes : iConfig Subscription failure due to TCP socket problem - no : ont service is ok	iConfig Subscription failure due to TCP socket problem <i>This element is only shown in detail mode.</i>
ont-svc-voip-subscription-tls	Parameter type: <Alarm::ONTVOIICONTLS> (yes no) Possible values: - yes : iConfig Subscription failure due to TLS session problem - no : ont service is ok	iConfig Subscription failure due to TLS session problem <i>This element is only shown in detail mode.</i>
ont-svc-voip-subscription-auth	Parameter type: <Alarm::ONTVOIICONAUTH> (yes no) Possible values: - yes : iConfig Subscription failure due to authentication error - no : ont service is ok	iConfig Subscription failure due to authentication error <i>This element is only shown in detail mode.</i>
ont-svc-voip-subscription-timeout	Parameter type: <Alarm::ONTVOIICONSUBSTO> (yes no) Possible values:	iConfig Subscription failure due to retransmission timeout <i>This element is only shown in detail mode.</i>

102 Alarm Log Status Commands

name	Type	Description
	- yes : iConfig Subscription failure due to retransmission timeout - no : ont service is ok	
ont-svc-voip-sub-err	Parameter type: <Alarm::ONTVOIICONSUBSERR> (yes no) Possible values: - yes : iConfig Subscription failure due to response error - no : ont service is ok	iConfig Subscription failure due to response error <i>This element is only shown in detail mode.</i>
ont-svc-voip-not-to	Parameter type: <Alarm::ONTVOIICONNOTTO> (yes no) Possible values: - yes : iConfig Notify response timeout for new subscription - no : ont service is ok	iConfig Notify response is malformed <i>This element is only shown in detail mode.</i>
ont-svc-voip-notref-to	Parameter type: <Alarm::ONTVOIICONNOTREFTO> (yes no) Possible values: - yes : iConfig Notify response timeout for subscription refresh - no : ont service is ok	iConfig Notify response timeout for subscription refresh <i>This element is only shown in detail mode.</i>
ont-svc-voip-not-mal	Parameter type: <Alarm::ONTVOIICONNOTMAL> (yes no) Possible values: - yes : iConfig Notify response is malformed - no : ont service is ok	iConfig Notify response is malformed <i>This element is only shown in detail mode.</i>
ont-svc-voip-not-rej	Parameter type: <Alarm::ONTVOIICONNOTREJ> (yes no) Possible values: - yes : iConfig subscription request rejected by configuration server - no : ont service is ok	iConfig subscription request rejected by configuration server <i>This element is only shown in detail mode.</i>
ont-svc-voip-http-dns	Parameter type: <Alarm::ONTVOIHTTPDNS> (yes no) Possible values: - yes : VOIP client can't retrieve config doc due to DNS problem - no : ont service is ok	VOIP client can't retrieve config doc due to DNS problem <i>This element is only shown in detail mode.</i>
ont-svc-voip-http-tcp	Parameter type: <Alarm::ONTVOIHTTPTCP> (yes no) Possible values: - yes : VOIP client can't retrieve config doc due to TCP socket problem - no : ont service is ok	VOIP client can't retrieve config doc due to TCP socket problem <i>This element is only shown in detail mode.</i>
ont-svc-voip-http-tls	Parameter type: <Alarm::ONTVOIHTTPTLS> (yes no) Possible values: - yes : VOIP client can't retrieve config doc due to TLS session problem - no : ont service is ok	VOIP client can't retrieve config doc due to TLS session problem <i>This element is only shown in detail mode.</i>
ont-svc-voip-http-auth	Parameter type: <Alarm::ONTVOIHTTPAUTH>	VOIP client can't retrieve config

name	Type	Description
	(yes no) Possible values: - yes : VOIP client can't retrieve config doc due to auth error - no : ont service is ok	doc due to auth error <i>This element is only shown in detail mode.</i>
ont-svc-voip-http-to	Parameter type: <Alarm::ONTVOIHTTPTO> (yes no) Possible values: - yes : VOIP client can't retrieve config doc due to re-tx timeout - no : ont service is ok	VOIP client can't retrieve config doc due to re-tx timeout <i>This element is only shown in detail mode.</i>
ont-svc-voip-http-err	Parameter type: <Alarm::ONTVOIHTTPErr> (yes no) Possible values: - yes : VOIP client can't retrieve config doc due to response error - no : ont service is ok	VOIP client can't retrieve config doc due to response error <i>This element is only shown in detail mode.</i>
ont-svc-voip-http-mal	Parameter type: <Alarm::ONTVOIICONHTTPMAL> (yes no) Possible values: - yes : iConfig configuration document is malformed - no : ont service is ok	iConfig configuration document is malformed <i>This element is only shown in detail mode.</i>
ont-svc-voip-subscr-refr	Parameter type: <Alarm::ONTVOIICONSUBSREFR> (yes no) Possible values: - yes : iConfig Subscription refresh error - no : ont service is ok	iConfig Subscription refresh error <i>This element is only shown in detail mode.</i>
ont-svc-voip-not-refr	Parameter type: <Alarm::ONTVOIICONNOTREFR> (yes no) Possible values: - yes : iConfig Notify response for refresh subscribe failed - no : ont service is ok	iConfig Notify response for refresh subscribe failed <i>This element is only shown in detail mode.</i>
ont-svc-voip-icfg-err	Parameter type: <Alarm::ONTVOIICONERR> (yes no) Possible values: - yes : iConfig Configuration Error - no : ont service is ok	iConfig Configuration Error <i>This element is only shown in detail mode.</i>

102.136 ONT VIDEO ANI Alarm Log Status Command

Command Description

This command displays the ONT VIDEO ANI alarm log status.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm log ont-video-ani [ (index) ]
```

Command Parameters

Table 102.136-1 " ONT VIDEO ANI Alarm Log Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm type

Command Output

Table 102.136-2 " ONT VIDEO ANI Alarm Log Status Command" Display parameters

Specific Information		
name	Type	Description
last-updated-on	Parameter type: <Sys::timeInSecs> - the time (yyyy-mm-dd:hour:minutes:secs) - unit: UTC	network time in seconds when the alarm was logged <i>This element is only shown in detail mode.</i>
ont	Parameter type: <Gpon::OntIndex> (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> ng2 : <Ng2::ChannelGroup> / <Ng2::SubchannelGroup> / <Ng2::OntId>) Possible values: - ng2 : ngpon2 style identification Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId>	identifies the ont entry <i>This element is only shown in detail mode.</i>

name	Type	Description
	- the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Ng2::ChannelGroup> - channel group number Field type <Ng2::SubchannelGroup> - subchannel group number Field type <Eqpt::OntId> - the ONT identifier Field type <Ng2::OntId> - the ONT identifier	
vedio-ani-index	Parameter type: <Gpon::AlarmIndex2Integer> - a signed integer	vedio ani index <i>This element is only shown in detail mode.</i>

Only Show Details: current and previous alarm log status		
name	Type	Description
ont-svc-v-ani-conf-mis	Parameter type: <Alarm::ONTVIDEOANISVCMIS> (yes no) Possible values: - yes : config request failure for video ani service - no : ont service is ok	config request failure for video ani service <i>This element is only shown in detail mode.</i>
ont-svc-v-ani-loss-sig	Parameter type: <Alarm::ONTVIDEOLOS> (yes no) Possible values: - yes : video loss of signal on ani - no : ont service is ok	video loss of signal on ani <i>This element is only shown in detail mode.</i>
ont-svc-v-ani-lv-high	Parameter <Alarm::ONTVIDEOOPTSIGLEVELHIGH> (yes no) Possible values: - yes : high video optical signal level - no : ont service is ok	type: high video optical signal level <i>This element is only shown in detail mode.</i>
ont-svc-v-ani-lv-low	Parameter <Alarm::ONTVIDEOOPTSIGLEVELLOW> (yes no) Possible values: - yes : low video optical signal level - no : ont service is ok	type: low video optical signal level <i>This element is only shown in detail mode.</i>

102.137 ONT PWE Alarm Log Status Command

Command Description

This command displays the ONT PWE alarm log status.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm log ont-pwe [ (index) ]
```

Command Parameters

Table 102.137-1 " ONT PWE Alarm Log Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm type

Command Output

Table 102.137-2 " ONT PWE Alarm Log Status Command" Display parameters

Specific Information		
name	Type	Description
last-updated-on	Parameter type: <Sys::timeInSecs> - the time (yyyy-mm-dd:hour:minutes:secs) - unit: UTC	network time in seconds when the alarm was logged <i>This element is only shown in detail mode.</i>
ont-ces-uni	Parameter type: <Ces::InterfaceIndex> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> / <Eqpt::OntPortId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Eqpt::OntId> - the ONT identifier Field type <Eqpt::OntSlotId>	ont ces uni <i>This element is only shown in detail mode.</i>

name	Type	Description
	- the ONT SLOT identifier Field type <Eqpt::OntPortId> - the ONT PORT identifier	
service-id	Parameter type: <Gpon::AlarmIndex2Integer> - a signed integer	service id <i>This element is only shown in detail mode.</i>

Only Show Details: current and previous alarm log status		
name	Type	Description
ont-svc-pwe-mismatch	Parameter type: <Alarm::ONTPWESVCMIS> (yes no) Possible values: - yes : service mismatch for provisioned pseudowire - no : ont service is ok	service mismatch for provisioned pseudowire <i>This element is only shown in detail mode.</i>
ont-svc-pwe-reordr-lof	Parameter type: <Alarm::ONTPWELOSSREORDER> (yes no) Possible values: - yes : pseudowire reordering and loss of frame - no : ont service is ok	pseudowire reordering and loss of frame <i>This element is only shown in detail mode.</i>
ont-svc-pwe-jitt-buf-o	Parameter type: <Alarm::ONTPWEJBOVRRUN> (yes no) Possible values: - yes : pseudowire jitter buffer overrun - no : ont service is ok	pseudowire jitter buffer overrun <i>This element is only shown in detail mode.</i>
ont-svc-pwe-jitt-buf-u	Parameter type: <Alarm::ONTPWEJBUNDRUN> (yes no) Possible values: - yes : pseudowire jitter buffer underrun - no : ont service is ok	pseudowire jitter buffer underrun <i>This element is only shown in detail mode.</i>
ont-svc-pwe-malf-frms	Parameter type: <Alarm::ONTPWEMALFORM> (yes no) Possible values: - yes : pseudowire malformed frames - no : ont service is ok	pseudowire malformed frames <i>This element is only shown in detail mode.</i>
ont-svc-pwe-late-frms	Parameter type: <Alarm::ONTPWELATEFRMS> (yes no) Possible values: - yes : pseudowire late frames - no : ont service is ok	pseudowire late frames <i>This element is only shown in detail mode.</i>
ont-svc-pwe-link-loss	Parameter type: <Alarm::ONTPWELINKLOSS> (yes no) Possible values: - yes : pseudowire link loss - no : ont service is ok	pseudowire link loss <i>This element is only shown in detail mode.</i>
ont-svc-pwe-arp-fail	Parameter type: <Alarm::ONTPWEARPFAIL> (yes no) Possible values: - yes : pseudowire arp failure - no : ont service is ok	pseudowire arp failure <i>This element is only shown in detail mode.</i>

102.138 ONT CESE1 Alarm Log Status Command

Command Description

This command displays the ONT CESE1 alarm log status.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm log ont-cese1 [ (index) ]
```

Command Parameters

Table 102.138-1 " ONT CESE1 Alarm Log Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm type

Command Output

Table 102.138-2 " ONT CESE1 Alarm Log Status Command" Display parameters

Specific Information		
name	Type	Description
last-updated-on	Parameter type: <Sys::timeInSecs> - the time (yyyy-mm-dd:hour:minutes:secs) - unit: UTC	network time in seconds when the alarm was logged <i>This element is only shown in detail mode.</i>
ces-port	Parameter type: <Gpon::IfIndexAlarmIndex2> (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Gpon::OntSlotId> / <Gpon::OntPortId> ng2 : <Ng2::ChannelGroup> / <Ng2::SubchannelGroup> / <Ng2::OntId> / <Gpon::OntSlotId> / <Gpon::OntPortId>) Possible values: - ng2 : ngpon2 style identification Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId>	ces port <i>This element is only shown in detail mode.</i>

102 Alarm Log Status Commands

name	Type	Description
	- the PON identifier - Field type <Ng2::ChannelGroup> - channel group number - Field type <Ng2::SubchannelGroup> - subchannel group number - Field type <Eqpt::OntId> - the ONT identifier - Field type <Ng2::OntId> - the ONT identifier - Field type <Gpon::OntSlotId> - Gpon Ont Slot - range: [1...14] - Field type <Gpon::OntPortId> - Gpon Ont Port - range: [1...16]	

Only Show Details: current and previous alarm log status		
name	Type	Description
ont-svc-ces-e1-mis	Parameter type: <Alarm::ONTCESE1SVCNIS> (yes no) Possible values: - yes : ont service mismatch for provisioned ces e1 - no : ont service is ok	ont service mismatch for provisioned ces e1 <i>This element is only shown in detail mode.</i>
ont-svc-ces-e1-los	Parameter type: <Alarm::ONTCESE1LOS> (yes no) Possible values: - yes : loss of signal at e1 interface - no : ont service is ok	loss of signal at e1 interface <i>This element is only shown in detail mode.</i>
ont-svc-ces-e1-lof	Parameter type: <Alarm::ONTCESE1LOF> (yes no) Possible values: - yes : loss of frame at e1 interface - no : ont service is ok	loss of frame at e1 interface <i>This element is only shown in detail mode.</i>
ont-svc-ces-e1-rair	Parameter type: <Alarm::ONTCESE1RAIR> (yes no) Possible values: - yes : receiving rai at e1 interface - no : ont service is ok	receiving rai at e1 interface <i>This element is only shown in detail mode.</i>
ont-svc-ces-e1-ais	Parameter type: <Alarm::ONTCESE1AISR> (yes no) Possible values: - yes : receiving ais at e1 interface - no : ont service is ok	receiving ais at e1 interface <i>This element is only shown in detail mode.</i>

102.139 ONT XDSL Alarm Log Status Command

Command Description

This command displays the ONT XDSL alarm log status.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm log ont-xdsl [ (index) ]
```

Command Parameters

Table 102.139-1 " ONT XDSL Alarm Log Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm type

Command Output

Table 102.139-2 " ONT XDSL Alarm Log Status Command" Display parameters

Specific Information		
name	Type	Description
last-updated-on	Parameter type: <Sys::timeInSecs> - the time (yyyy-mm-dd:hour:minutes:secs) - unit: UTC	network time in seconds when the alarm was logged <i>This element is only shown in detail mode.</i>
dsl-line-port	Parameter type: <Gpon::IfIndexAlarmIndex2> (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Gpon::OntSlotId> / <Gpon::OntPortId> ng2 : <Ng2::ChannelGroup> / <Ng2::SubchannelGroup> / <Ng2::OntId> / <Gpon::OntSlotId> / <Gpon::OntPortId>) Possible values: - ng2 : ngpon2 style identification Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId>	dsl line port <i>This element is only shown in detail mode.</i>

102 Alarm Log Status Commands

name	Type	Description
	- the PON identifier - Field type <Ng2::ChannelGroup> - channel group number - Field type <Ng2::SubchannelGroup> - subchannel group number - Field type <Eqpt::OntId> - the ONT identifier - Field type <Ng2::OntId> - the ONT identifier - Field type <Gpon::OntSlotId> - Gpon Ont Slot - range: [1...14] - Field type <Gpon::OntPortId> - Gpon Ont Port - range: [1...16]	

Only Show Details: current and previous alarm log status		
name	Type	Description
ont-svc-xdsl-mismatch	Parameter type: <Alarm::ONTXDSLVCNIS> (yes no) Possible values: - yes : receiving ais at e1 interface - no : ont service is ok	service mismatch for provisioned xdsl <i>This element is only shown in detail mode.</i>
ont-svc-xdsl-ne-lof	Parameter type: <Alarm::ONTXLOF> (yes no) Possible values: - yes : near end loss of frame - no : ont service is ok	near end loss of frame <i>This element is only shown in detail mode.</i>
ont-svc-xdsl-ne-los	Parameter type: <Alarm::ONTXLOS> (yes no) Possible values: - yes : near end loss of signal - no : ont service is ok	near end loss of signal <i>This element is only shown in detail mode.</i>
ont-svc-xdsl-ne-line	Parameter type: <Alarm::ONTLINEINIT> (yes no) Possible values: - yes : near end line init - no : ont service is ok	near end line init <i>This element is only shown in detail mode.</i>
ont-svc-xdsl-ne-lol	Parameter type: <Alarm::ONTXLOL> (yes no) Possible values: - yes : near end loss of link - no : ont service is ok	near end loss of link <i>This element is only shown in detail mode.</i>
ont-svc-xdsl-fe-lof	Parameter type: <Alarm::ONTXLOFFE> (yes no) Possible values: - yes : far end loss of frame - no : ont service is ok	far end loss of frame <i>This element is only shown in detail mode.</i>
ont-svc-xdsl-fe-los	Parameter type: <Alarm::ONTXLOSFE> (yes no) Possible values:	far end loss of signal <i>This element is only shown in detail mode.</i>

name	Type	Description
	- yes : far end loss of signal - no : ont service is ok	
ont-svc-xdsl-fe-lop	Parameter type: <Alarm::ONTXLOPFE> (yes no) Possible values: - yes : far end loss of power - no : ont service is ok	far end loss of power <i>This element is only shown in detail mode.</i>
ont-svc-xdsl-cnfg-err	Parameter type: <Alarm::ONTXDLCNFG> (yes no) Possible values: - yes : xdsl provisioning error - no : ont service is ok	xdsl provisioning error <i>This element is only shown in detail mode.</i>

102.140 ONT XDSL TCA Alarm Log Status Command

Command Description

This command displays the ONT XDSL TCA alarm log status.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm log ont-xdsl-tca [ (index) ]
```

Command Parameters

Table 102.140-1 " ONT XDSL TCA Alarm Log Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm type

Command Output

Table 102.140-2 " ONT XDSL TCA Alarm Log Status Command" Display parameters

Specific Information		
name	Type	Description
last-updated-on	Parameter type: <Sys::timeInSecs> - the time (yyyy-mm-dd:hour:minutes:secs) - unit: UTC	network time in seconds when the alarm was logged <i>This element is only shown in detail mode.</i>
dsl-line-port	Parameter type: <Gpon::IfIndexAlarmIndex2> (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Gpon::OntSlotId> / <Gpon::OntPortId> ng2 : <Ng2::ChannelGroup> / <Ng2::SubchannelGroup> / <Ng2::OntId> / <Gpon::OntSlotId> / <Gpon::OntPortId>) Possible values: - ng2 : ngpon2 style identification Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number	dsl line port <i>This element is only shown in detail mode.</i>

name	Type	Description
	Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Ng2::ChannelGroup> - channel group number Field type <Ng2::SubchannelGroup> - subchannel group number Field type <Eqpt::OntId> - the ONT identifier Field type <Ng2::OntId> - the ONT identifier Field type <Gpon::OntSlotId> - Gpon Ont Slot - range: [1...14] Field type <Gpon::OntPortId> - Gpon Ont Port - range: [1...16]	

Only Show Details: current and previous alarm log status

name	Type	Description
ont-svc-xdsl-ne-es-tc	Parameter type: <Alarm::ONTXDSLES> (yes no) Possible values: - yes : near end errored seconds threshold crossed - no : ont service is ok	near end errored seconds threshold crossed <i>This element is only shown in detail mode.</i>
ont-svc-xdsl-ne-ses-tc	Parameter type: <Alarm::ONTXDSESES> (yes no) Possible values: - yes : near end severe errored seconds threshold crossed - no : ont service is ok	near end severe errored seconds threshold crossed <i>This element is only shown in detail mode.</i>
ont-svc-xdsl-ne-uas-tc	Parameter type: <Alarm::ONTXDSELUAS> (yes no) Possible values: - yes : ear end unavailable seconds threshold crossed - no : ont service is ok	ear end unavailable seconds threshold crossed <i>This element is only shown in detail mode.</i>
ont-svc-xdsl-fe-es-tc	Parameter type: <Alarm::ONTXDSLESFAREND> (yes no) Possible values: - yes : far end errored seconds threshold crossed - no : ont service is ok	far end errored seconds threshold crossed <i>This element is only shown in detail mode.</i>
ont-svc-xdsl-fe-ses-tc	Parameter type: <Alarm::ONTXDSESESFAREND> (yes no) Possible values: - yes : far end severe errored seconds threshold crossed - no : ont service is ok	far end severe errored seconds threshold crossed <i>This element is only shown in detail mode.</i>
ont-svc-xdsl-fe-uas-tc	Parameter type: <Alarm::ONTXDSELUASFAREND> (yes no) Possible values: - yes : far end unavailable seconds threshold crossed - no : ont service is ok	far end unavailable seconds threshold crossed <i>This element is only shown in detail mode.</i>

102.141 ONT HPNA Alarm Log Status Command

Command Description

This command displays the ONT HPNA alarm log status.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm log ont-hpna [ (index) ]
```

Command Parameters

Table 102.141-1 " ONT HPNA Alarm Log Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm type

Command Output

Table 102.141-2 " ONT HPNA Alarm Log Status Command" Display parameters

Specific Information		
name	Type	Description
last-updated-on	Parameter type: <Sys::timeInSecs> - the time (yyyy-mm-dd:hour:minutes:secs) - unit: UTC	network time in seconds when the alarm was logged <i>This element is only shown in detail mode.</i>
ont-port	Parameter type: <Gpon::IfIndexAlarmIndex2> (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Gpon::OntSlotId> / <Gpon::OntPortId> ng2 : <Ng2::ChannelGroup> / <Ng2::SubchannelGroup> / <Ng2::OntId> / <Gpon::OntSlotId> / <Gpon::OntPortId>) Possible values: - ng2 : ngpon2 style identification Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId>	ont port <i>This element is only shown in detail mode.</i>

102 Alarm Log Status Commands

name	Type	Description
	- the PON identifier - Field type <Ng2::ChannelGroup> - channel group number - Field type <Ng2::SubchannelGroup> - subchannel group number - Field type <Eqpt::OntId> - the ONT identifier - Field type <Ng2::OntId> - the ONT identifier - Field type <Gpon::OntSlotId> - Gpon Ont Slot - range: [1...14] - Field type <Gpon::OntPortId> - Gpon Ont Port - range: [1...16]	

Only Show Details: current and previous alarm log status		
name	Type	Description
ont-hpna-ser-mis	Parameter type: <Alarm::ONTHPNASVCMIS> (yes no) Possible values: - yes : hpna ont service mismatch - no : ont service is ok	hpna ont service mismatch <i>This element is only shown in detail mode.</i>
ont-hpna-los-sig	Parameter type: <Alarm::ONTHPNALOS> (yes no) Possible values: - yes : hpna loss of link - no : ont service is ok	hpna loss of link <i>This element is only shown in detail mode.</i>

102.142 ONT SIP AGENT CFG Alarm Log Status Command

Command Description

This command displays the ONT SIP AGENT CFG alarm log status.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm log ont-sip-agent-cfg [ (index) ]
```

Command Parameters

Table 102.142-1 " ONT SIP AGENT CFG Alarm Log Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm type

Command Output

Table 102.142-2 " ONT SIP AGENT CFG Alarm Log Status Command" Display parameters

Specific Information		
name	Type	Description
last-updated-on	Parameter type: <Sys::timeInSecs> - the time (yyyy-mm-dd:hour:minutes:secs) - unit: UTC	network time in seconds when the alarm was logged <i>This element is only shown in detail mode.</i>
port	Parameter type: <Gpon::IpHostCommonIndex> (ont : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Gpon::IpHostId> vlanport : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / vuni : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlanport : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / vuni : <Eqpt::UnstackedVlan> ont:ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / <Ng2::IpHostId>	gpon iphost port <i>This element is only shown in detail mode.</i>

102 Alarm Log Status Commands

name	Type	Description
	vlanport:ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / vuni : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlanport:ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / vuni : <Eqpt::UnstackedVlan>) Possible values: - ont:ng2 : ngpon2 ont - vlanport:ng2 : ngpon2 vlanport - ont : ont - vlanport : vlanport Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Eqpt::OntId> - the ONT identifier Field type <Eqpt::ChannelGroupId> - the channel group identifier Field type <Eqpt::SubChannelGroupId> - the subchannel group identifier Field type <Eqpt::Ng2OntId> - the NG2 ONT identifier Possible values: - vuni : virtual uni identifier Possible values: - vuni : virtual NGPON2 uni identifier Field type <Gpon::IpHostID> - iphost id Field type <Ng2::IpHostID> - iphost id (ngpon2) Possible values: - stacked : stacked vlan identity Field type <Eqpt::UnstackedVlan> - unstacked vlan id Field type <Eqpt::SVlan> - service vlan id Field type <Eqpt::CVlan> - customer vlan id	

Only Show Details: current and previous alarm log status		
name	Type	Description
ont-sipa-reg-nm-fail	Parameter type: <Alarm::ONTSIPAREGFAILNAME> (yes no) Possible values: - yes : sipua registration name failed - no : ont service is ok	sipua registration name failed <i>This element is only shown in detail mode.</i>
ont-sipa-reg-rec-fail	Parameter type: <Alarm::ONTSIPAREGREACH> (yes no) Possible values: - yes : sipua register reach failed - no : ont service is ok	sipua register reach failed <i>This element is only shown in detail mode.</i>

name	Type	Description
ont-sipa-reg-con-fail	Parameter type: <Alarm::ONTSIPAREGCONNECT> (yes no) Possible values: - yes : sipua register connect failed - no : ont service is ok	sipua register connect failed <i>This element is only shown in detail mode.</i>
ont-sipa-reg-val-fail	Parameter type: <Alarm::ONTSIPAREGVALIDATE> (yes no) Possible values: - yes : sipua register validation failed - no : ont service is ok	sipua register validation failed <i>This element is only shown in detail mode.</i>
ont-sipa-reg-mis	Parameter type: <Alarm::ONTSIPAREGMIS> (yes no) Possible values: - yes : sipua register mismatch - no : ont service is ok	sipua register mismatch <i>This element is only shown in detail mode.</i>

102.143 ONT VOIP CFG Alarm Log Status Command

Command Description

This command displays the ONT VOIP CFG alarm log status.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm log ont-voip-cfg [ (index) ]
```

Command Parameters

Table 102.143-1 " ONT VOIP CFG Alarm Log Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm type

Command Output

Table 102.143-2 " ONT VOIP CFG Alarm Log Status Command" Display parameters

Specific Information		
name	Type	Description
last-updated-on	Parameter type: <Sys::timeInSecs> - the time (yyyy-mm-dd:hour:minutes:secs) - unit: UTC	network time in seconds when the alarm was logged <i>This element is only shown in detail mode.</i>
port	Parameter type: <Gpon::IpHostCommonIndex> (ont : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Gpon::IpHostId> vlanport : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / vuni : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlanport : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / vuni : <Eqpt::UnstackedVlan> ont:ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / <Ng2::IpHostId>	gpon iphost port <i>This element is only shown in detail mode.</i>

name	Type	Description
	vlanport:ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / vuni : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlanport:ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / vuni : <Eqpt::UnstackedVlan>) Possible values: - ont:ng2 : ngpon2 ont - vlanport:ng2 : ngpon2 vlanport - ont : ont - vlanport : vlanport Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Eqpt::OntId> - the ONT identifier Field type <Eqpt::ChannelGroupId> - the channel group identifier Field type <Eqpt::SubChannelGroupId> - the subchannel group identifier Field type <Eqpt::Ng2OntId> - the NG2 ONT identifier Possible values: - vuni : virtual uni identifier Possible values: - vuni : virtual NGPON2 uni identifier Field type <Gpon::IpHostID> - iphost id Field type <Ng2::IpHostID> - iphost id (ngpon2) Possible values: - stacked : stacked vlan identity Field type <Eqpt::UnstackedVlan> - unstacked vlan id Field type <Eqpt::SVlan> - service vlan id Field type <Eqpt::CVlan> - customer vlan id	

Only Show Details: current and previous alarm log status		
name	Type	Description
ont-vcd-cfg-nm-fail	Parameter type: <Alarm::ONTVCDCFGFAILNAME> (yes no) Possible values: - yes : vcd config name failed - no : ont service is ok	vcd config name failed <i>This element is only shown in detail mode.</i>
ont-vcd-cfg-rech-fail	Parameter type: <Alarm::ONTVCDCFGREACH> (yes no) Possible values: - yes : vcd config reach failed - no : ont service is ok	vcd config reach failed <i>This element is only shown in detail mode.</i>

102 Alarm Log Status Commands

name	Type	Description
ont-vcd-cfg-conn-fail	Parameter type: <Alarm::ONTVCDCFGCONNECT> (yes no) Possible values: - yes : vcd config connect failed - no : ont service is ok	vcd config connect failed <i>This element is only shown in detail mode.</i>
ont-vcd-cfg-vali-fail	Parameter type: <Alarm::ONTVCDCFGVALIDATE> (yes no) Possible values: - yes : vcd config validation failed - no : ont service is ok	vcd config validation failed <i>This element is only shown in detail mode.</i>
ont-vcd-cfg-auth-fail	Parameter type: <Alarm::ONTVCDCFGAUTH> (yes no) Possible values: - yes : vcd config authentication failed - no : ont service is ok	vcd config authentication failed <i>This element is only shown in detail mode.</i>
ont-vcd-cfg-resp-tmout	Parameter type: <Alarm::ONTVCDCFGTMOUT> (yes no) Possible values: - yes : vcd config response timeout - no : ont service is ok	vcd config response timeout <i>This element is only shown in detail mode.</i>
ont-vcd-cfg-resp-err	Parameter type: <Alarm::ONTVCDCFGRESPERR> (yes no) Possible values: - yes : vcd config response error - no : ont service is ok	vcd config response error <i>This element is only shown in detail mode.</i>
ont-vcd-cfg-file-err	Parameter type: <Alarm::ONTVCDCFGFILEERR> (yes no) Possible values: - yes : vcd config file error - no : ont service is ok	vcd config file error <i>This element is only shown in detail mode.</i>
ont-vcd-sub-nm-fail	Parameter type: <Alarm::ONTVCDSUBSFILNAME> (yes no) Possible values: - yes : vcd subscription name failed - no : ont service is ok	vcd subscription name failed <i>This element is only shown in detail mode.</i>
ont-vcd-sub-rech-fail	Parameter type: <Alarm::ONTVCDSUBSREACH> (yes no) Possible values: - yes : vcd subscription reach failed - no : ont service is ok	vcd subscription reach failed <i>This element is only shown in detail mode.</i>
ont-vcd-sub-conn-fail	Parameter type: <Alarm::ONTVCDSUBSCONNECT> (yes no) Possible values: - yes : vcd subscription connect failed - no : ont service is ok	vcd subscription connect failed <i>This element is only shown in detail mode.</i>
ont-vcd-sub-vali-fail	Parameter type: <Alarm::ONTVCDSUBSVALIDATE> (yes no)	vcd subscription validation failed <i>This element is only shown in detail mode.</i>

name	Type	Description
	Possible values: - yes : vcd subscription validation failed - no : ont service is ok	
ont-vcd-sub-auth-fail	Parameter type: <Alarm::ONTVCDSUBSAUTH> (yes no) Possible values: - yes : vcd subscription authentication failed - no : ont service is ok	vcd subscription authentication failed <i>This element is only shown in detail mode.</i>
ont-vcd-sub-resp-tmout	Parameter type: <Alarm::ONTVCDSUBSTMOUT> (yes no) Possible values: - yes : vcd subscription response timeout - no : ont service is ok	vcd subscription response timeout <i>This element is only shown in detail mode.</i>
ont-vcd-sub-resp-err	Parameter type: <Alarm::ONTVCDSUBSRESPERR> (yes no) Possible values: - yes : vcd subscription response error - no : ont service is ok	vcd subscription response error <i>This element is only shown in detail mode.</i>
ont-vcd-reb-requ	Parameter type: <Alarm::ONTVCDREBOOTREQ> (yes no) Possible values: - yes : vcd reboot request - no : ont service is ok	vcd reboot request <i>This element is only shown in detail mode.</i>
ont-vcd-mis	Parameter type: <Alarm::ONTVCDMIS> (yes no) Possible values: - yes : vcd mismatch - no : ont service is ok	vcd mismatch <i>This element is only shown in detail mode.</i>

102.144 ONT MGC Alarm Log Status Command

Command Description

This command displays the ONT MGC alarm log status.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm log ont-mgc [ (index) ]
```

Command Parameters

Table 102.144-1 " ONT MGC Alarm Log Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm type

Command Output

Table 102.144-2 " ONT MGC Alarm Log Status Command" Display parameters

Specific Information		
name	Type	Description
last-updated-on	Parameter type: <Sys::timeInSecs> - the time (yyyy-mm-dd:hour:minutes:secs) - unit: UTC	network time in seconds when the alarm was logged <i>This element is only shown in detail mode.</i>
port	Parameter type: <Gpon::IpHostCommonIndex> (ont : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Gpon::IpHostId> vlanport : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / vuni : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlanport : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / vuni : <Eqpt::UnstackedVlan> ont:ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / <Ng2::IpHostId> vlanport:ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / vuni : stacked : <Eqpt::SVlan> : <Eqpt::CVlan>	gpon iphost port <i>This element is only shown in detail mode.</i>

name	Type	Description
	vlanport:ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / vuni : <Eqpt::UnstackedVlan>) Possible values: - ont:ng2 : ngpon2 ont - vlanport:ng2 : ngpon2 vlanport - ont : ont - vlanport : vlanport Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Eqpt::OntId> - the ONT identifier Field type <Eqpt::ChannelGroupId> - the channel group identifier Field type <Eqpt::SubChannelGroupId> - the subchannel group identifier Field type <Eqpt::Ng2OntId> - the NG2 ONT identifier Possible values: - vuni : virtual uni identifier Possible values: - vuni : virtual NGPON2 uni identifier Field type <Gpon::IpHostID> - iphost id Field type <Ng2::IpHostID> - iphost id (ngpon2) Possible values: - stacked : stacked vlan identity Field type <Eqpt::UnstackedVlan> - unstacked vlan id Field type <Eqpt::SVlan> - service vlan id Field type <Eqpt::CVlan> - customer vlan id	

Only Show Details: current and previous alarm log status		
name	Type	Description
ont-mgc-mis	Parameter type: <Alarm::ONTMGCMIS> (yes no) Possible values: - yes : ont mgc mismatch - no : ont service is ok	ont mgc mismatch <i>This element is only shown in detail mode.</i>
ont-mgc-timeout	Parameter type: <Alarm::ONTMGCTMOUT> (yes no) Possible values: - yes : ont mgc timeout - no : ont service is ok	ont mgc timeout <i>This element is only shown in detail mode.</i>

102.145 ONT MoCA Alarm Log Status Command

Command Description

This command displays the ONT MoCA alarm log status.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

> show alarm log ont-moca [(index)]

Command Parameters

Table 102.145-1 " ONT MoCA Alarm Log Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm log table index

Command Output

Table 102.145-2 " ONT MoCA Alarm Log Status Command" Display parameters

Specific Information		
name	Type	Description
last-updated-on	Parameter type: <Sys::timeInSecs> - the time (yyyy-mm-dd:hour:minutes:secs) - unit: UTC	network time in seconds when the alarm was logged <i>This element is only shown in detail mode.</i>
uni-index	Parameter type: <Gpon::IfIndexAlarmIndex2> (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Gpon::OntSlotId> / <Gpon::OntPortId> ng2 : <Ng2::ChannelGroup> / <Ng2::SubchannelGroup> / <Ng2::OntId> / <Gpon::OntSlotId> / <Gpon::OntPortId>) Possible values: - ng2 : ngpon2 style identification Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId>	ont port <i>This element is only shown in detail mode.</i>

name	Type	Description
	- the PON identifier - Field type <Ng2::ChannelGroup> - channel group number - Field type <Ng2::SubchannelGroup> - subchannel group number - Field type <Eqpt::OntId> - the ONT identifier - Field type <Ng2::OntId> - the ONT identifier - Field type <Gpon::OntSlotId> - Gpon Ont Slot - range: [1...14] - Field type <Gpon::OntPortId> - Gpon Ont Port - range: [1...16]	

Only Show Details: current and previous alarm log status		
name	Type	Description
ont-moca-svc-mis	Parameter type: <Alarm::ONTMOCASVCMIS> (yes no) Possible values: - yes : moca ont service mismatch - no : moca ont service is ok	ont moca service mismatch <i>This element is only shown in detail mode.</i>
ont-moca-link-los	Parameter type: <Alarm::ONTMOCALOL> (yes no) Possible values: - yes : moca loss of link - no : moca ont service is ok	ont moca loss of link <i>This element is only shown in detail mode.</i>
ont-moca-min-bw	Parameter type: <Alarm::ONTMOCALIMLINK> (yes no) Possible values: - yes : moca limited link - no : moca ont service is ok	ont moca bw between nodes less than minimum bw <i>This element is only shown in detail mode.</i>

102.146 ONT MoCA Threshold Crossing Alert (TCA) Alarm Log Command

Command Description

This command displays the ONT MoCA Threshold Crossing Alert (TCA) alarm log.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm log ont-moca-tca [ (index) ]
```

Command Parameters

Table 102.146-1 " ONT MoCA Threshold Crossing Alert (TCA) Alarm Log Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm type

Command Output

Table 102.146-2 " ONT MoCA Threshold Crossing Alert (TCA) Alarm Log Command" Display parameters

Specific Information		
name	Type	Description
last-updated-on	Parameter type: <Sys::timeInSecs> - the time (yyyy-mm-dd:hour:minutes:secs) - unit: UTC	network time in seconds when the alarm was logged <i>This element is only shown in detail mode.</i>
uni-index	Parameter type: <Gpon::IfIndexAlarmIndex2> (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Gpon::OntSlotId> / <Gpon::OntPortId> ng2 : <Ng2::ChannelGroup> / <Ng2::SubchannelGroup> / <Ng2::OntId> / <Gpon::OntSlotId> / <Gpon::OntPortId>) Possible values: - ng2 : ngpon2 style identification Field type <Eqpt::RackId> - the rack number	ont port <i>This element is only shown in detail mode.</i>

name	Type	Description
	Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Ng2::ChannelGroup> - channel group number Field type <Ng2::SubchannelGroup> - subchannel group number Field type <Eqpt::OntId> - the ONT identifier Field type <Ng2::OntId> - the ONT identifier Field type <Gpon::OntSlotId> - Gpon Ont Slot - range: [1...14] Field type <Gpon::OntPortId> - Gpon Ont Port - range: [1...16]	

Only Show Details: current and previous alarm log status		
name	Type	Description
ont-moca-rx-err-fr	Parameter type: <Alarm::ONTMOCATCARXERRFRMS> (yes no) Possible values: - yes : ont moca rx errored frames threshold alert - no : no ont moca threshold alerts	ont moca rx errored frames threshold alert <i>This element is only shown in detail mode.</i>

102.147 Auto-Switch Alarm Log Status command

Command Description

This command displays log table of autoswitch alarm.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

> show alarm log auto-switch [(index)]

Command Parameters

Table 102.147-1 "Auto-Switch Alarm Log Status command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm log table index

Command Output

Table 102.147-2 "Auto-Switch Alarm Log Status command" Display parameters

Specific Information		
name	Type	Description
last-updated-on	Parameter type: <Sys::timeInSecs> - the time (yyyy-mm-dd:hour:minutes:secs) - unit: UTC	network time in seconds when the alarm was logged. <i>This element is only shown in detail mode.</i>
port	Parameter type: <Itf::XdslLine> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number	identifies the physical position of the port <i>This element is only shown in detail mode.</i>

Only Show Details: current and previous alarm log status		
name	Type	Description
auto-switch-status	Parameter type: <Alarm::autoSwitchStatus> (yes	show auto-switch alarm status. <i>This element is only shown in</i>

name	Type	Description
	no) Possible values: - yes : auto-switch alarm status - no : auto-switch alarm status clear	<i>detail mode.</i>
prev-status	Parameter type: <Alarm::autoSwitchStatus> (yes no) Possible values: - yes : auto-switch alarm status - no : auto-switch alarm status clear	status of auto-switch with its previous logged value. <i>This element is only shown in detail mode.</i>
queue-full-atm	Parameter type: <Alarm::auswqueuefullatm> (yes no) Possible values: - yes : auto-switch queue full for ATM - no : auto-switch queue full for ATM clear	show auto-switch alarm status. <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::auswqueuefullatm> (yes no) Possible values: - yes : auto-switch queue full for ATM - no : auto-switch queue full for ATM clear	status of auto-switch with its previous logged value. <i>This element is only shown in detail mode.</i>
cfg-data-bkup-fail-atm	Parameter type: <Alarm::auswbkpfailatm> (yes no) Possible values: - yes : auto-switch data backup failed for ATM - no : auto-switch data backup failed for ATM clear	show auto-switch alarm status. <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::auswbkpfailatm> (yes no) Possible values: - yes : auto-switch data backup failed for ATM - no : auto-switch data backup failed for ATM clear	status of auto-switch with its previous logged value. <i>This element is only shown in detail mode.</i>
recfg-fail-atm	Parameter type: <Alarm::auswrecfgfailatm> (yes no) Possible values: - yes : auto-switch reconfig failed for ATM - no : auto-switch reconfig failed for ATM clear	show auto-switch alarm status. <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::auswrecfgfailatm> (yes no) Possible values: - yes : auto-switch reconfig failed for ATM - no : auto-switch reconfig failed for ATM clear	status of auto-switch with its previous logged value. <i>This element is only shown in detail mode.</i>
data-unavail-atm	Parameter type: <Alarm::auswdataunatm> (yes no) Possible values: - yes : auto-switch data unavailable for ATM - no : auto-switch data unavailable for ATM clear	show auto-switch alarm status. <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::auswdataunatm> (yes no) Possible values: - yes : auto-switch data unavailable for ATM	status of auto-switch with its previous logged value. <i>This element is only shown in detail mode.</i>

102 Alarm Log Status Commands

name	Type	Description
	- no : auto-switch data unavailable for ATM clear	
queue-full-ptm	Parameter type: <Alarm::auswqueuefulptm> (yes no) Possible values: - yes : auto-switch queue full for PTM - no : auto-switch queue full for PTM clear	show auto-switch alarm status. <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::auswqueuefulptm> (yes no) Possible values: - yes : auto-switch queue full for PTM - no : auto-switch queue full for PTM clear	status of auto-switch with its previous logged value. <i>This element is only shown in detail mode.</i>
backup-fail-ptm	Parameter type: <Alarm::auswbkpfailptm> (yes no) Possible values: - yes : auto-switch data backup failed for PTM - no : auto-switch data backup failed for PTM clear	show auto-switch alarm status. <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::auswbkpfailptm> (yes no) Possible values: - yes : auto-switch data backup failed for PTM - no : auto-switch data backup failed for PTM clear	status of auto-switch with its previous logged value. <i>This element is only shown in detail mode.</i>
recfg-fail-ptm	Parameter type: <Alarm::auswrecfgfailptm> (yes no) Possible values: - yes : auto-switch reconfig failed for PTM - no : auto-switch reconfig failed for PTM clear	show auto-switch alarm status. <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::auswrecfgfailptm> (yes no) Possible values: - yes : auto-switch reconfig failed for PTM - no : auto-switch reconfig failed for PTM clear	status of auto-switch with its previous logged value. <i>This element is only shown in detail mode.</i>
data-unavail-ptm	Parameter type: <Alarm::auswdataunptm> (yes no) Possible values: - yes : auto-switch data unavailable for PTM - no : auto-switch data unavailable for PTM clear	show auto-switch alarm status. <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::auswdataunptm> (yes no) Possible values: - yes : auto-switch data unavailable for PTM - no : auto-switch data unavailable for PTM clear	status of auto-switch with its previous logged value. <i>This element is only shown in detail mode.</i>
bakp-fail-atm	Parameter type: <Alarm::auswbakpfailatm> (yes no) Possible values: - yes : auto-switch backup fail for ATM - no : auto-switch backup fail for ATM clear	show auto-switch alarm status. <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::auswbakpfailatm> (yes	status of auto-switch with its previous logged value.

102 Alarm Log Status Commands

name	Type	Description
	no) Possible values: - yes : auto-switch backup fail for ATM - no : auto-switch bakcup fail for ATM clear	<i>This element is only shown in detail mode.</i>

102.148 Channel Pair Alarm Log Status Command

Command Description

This command displays the Channel Pair alarm log status.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

> show alarm log channel-pair [(index)]

Command Parameters

Table 102.148-1 " Channel Pair Alarm Log Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm log table index

Command Output

Table 102.148-2 " Channel Pair Alarm Log Status Command" Display parameters

Specific Information		
name	Type	Description
last-updated-on	Parameter type: <Sys::timeInSecs> - the time (yyyy-mm-dd:hour:minutes:secs) - unit: UTC	network time in seconds when the alarm was logged. <i>This element is only shown in detail mode.</i>
channel-pair	Parameter type: <Gpon::ChannelPairId> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::ChannelPairId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::ChannelPairId> - the channel pair identifier	specify which channel pair the alarm occurred on. <i>This element is only shown in detail mode.</i>

Only Show Details: current alarm log status		
name	Type	Description
comm-fail	Parameter type: <Alarm::ChnPairComm> ((failing fail))	current status of Channel pair Communication failure on OLT

name	Type	Description
	ok) Possible values: - failing : Channel pair Communication is failing - fail : Channel pair Communication is failing - ok : Channel pair Communication is ok	Port <i>This element is only shown in detail mode.</i>
tx-fail	Parameter type: <Alarm::ChnPairTf> ((failing fail) ok) Possible values: - failing : Transmitt is failing - fail : Transmitt is failing - ok : Transmitt is ok	current status of transmit failure on OLT port <i>This element is only shown in detail mode.</i>
new-ont	Parameter type: <Alarm::ChnPairNewOnt> ((failing fail) ok) Possible values: - failing : NEW ONT is failing - fail : NEW ONT is failing - ok : NEW ONT is ok	current status of unprovisioned ont appearance <i>This element is only shown in detail mode.</i>
prov-mismatch	Parameter type: <Alarm::ChnPairMea> ((failing fail) ok) Possible values: - failing : Channel Pair Mismatch Provisioning is failing - fail : Channel Pair Mismatch Provisioning is failing - ok : Channel Pair Mismatch Provisioning is ok	current status of pon provision failure. <i>This element is only shown in detail mode.</i>
loss-sig	Parameter type: <Alarm::ChnPairLoss> ((failing fail) ok) Possible values: - failing : Channel Pair Loss of Signal is failing - fail : Channel Pair Loss of Signal is failing - ok : Channel Pair Loss of Signal is ok	current status of channel pair loss. <i>This element is only shown in detail mode.</i>
diagnostic	Parameter type: <Alarm::ChnPairRogueTest> ((failing fail) ok) Possible values: - failing : Rogue ONT detection mechanism effective is failing - fail : Rogue ONT detection mechanism effective is failing - ok : Rogue ONT detection mechanism effective is ok	current status of diagnostic tests <i>This element is only shown in detail mode.</i>
loid-conflict	Parameter type: <Alarm::ChnPairLoidConflict> ((failing fail) ok) Possible values: - failing : ONT LOID Conflict is failing - fail : ONT LOID Conflict is failing - ok : LOID Conflict is ok	current status of loid conflict ont. <i>This element is only shown in detail mode.</i>
loid-pwd-err	Parameter type: <Alarm::ChnPairLoidPwdErr> ((failing fail) ok) Possible values: - failing : ONT LOID PWD ERR is failing - fail : ONT LOID PWD ERR is failing - ok : ONT LOID PWD ERR is ok	current status of loid password error. <i>This element is only shown in detail mode.</i>
stk-laser-dis	Parameter type: <Alarm::ChnPairStkLaserDis> ((failing fail)	current status of stuck laser disabled.

102 Alarm Log Status Commands

name	Type	Description
	ok) Possible values: - failing : Unranged ONT with stuck laser disabled is failing - fail : Unranged ONT with stuck laser disabled is failing - ok : Unranged ONT with stuck laser disabled is ok	<i>This element is only shown in detail mode.</i>
sfp-mismatch	Parameter type: <Alarm::ChnPairSfpMismatch> ((failing fail) ok) Possible values: - failing : sfp mismatch is failing - fail : sfp mismatch is failing - ok : sfp mismatch is ok	current status of sfp mismatch. <i>This element is only shown in detail mode.</i>
rng-mismatch	Parameter type: <Alarm::ChnPairRngMismatch> ((failing fail) ok) Possible values: - failing : ranging mismatch is failing - fail : ranging mismatch is failing - ok : ranging mismatch is ok	current status of ranging mismatch. <i>This element is only shown in detail mode.</i>
alien-test	Parameter type: <Alarm::ChnPairAlienTest> ((failing fail) ok) Possible values: - failing : Alien ONT detection mechanism is active - fail : Alien ONT detection mechanism is active - ok : Alien ONT detection mechanism is not active	current status of alien diagnostic tests <i>This element is only shown in detail mode.</i>
alien-detect	Parameter type: <Alarm::ChnPairAlienDetected> ((failing fail) ok) Possible values: - failing : Alien ONT detected - fail : Alien ONT detected - ok : No alien ONT detected	current status of alien detect <i>This element is only shown in detail mode.</i>
deactont-high-tca	Parameter type: <Alarm::ChnPairDeactOntHighTca> (failing ok) Possible values: - failing : deactivated ont amount exceed high threshold occurred - ok : deactivated ont amount is less than high threshold occurred	current status of deactont high tca <i>This element is only shown in detail mode.</i>
deactont-low-tca	Parameter type: <Alarm::ChnPairDeactOntLowTca> (failing ok) Possible values: - failing : deactivated ont amount exceed low threshold occurred - ok : deactivated ont amount is less than low threshold occurred	current status of deactont low tca <i>This element is only shown in detail mode.</i>
datapath-integ	Parameter type: <Alarm::ChnPairDataPathInteg> (failing ok) Possible values: - failing : number of ONTs with SIPREGTO alarm exceeds threshold - ok : number of ONTs with SIPREGTO alarm does not exceed the threshold	current status of Channel-Pair Data Path Integrity <i>This element is only shown in detail mode.</i>

102.149 Channel Pair OLT TC TCA Alarm Log Status Command

Command Description

This command displays the Channel Pair OLT TC TCA alarm log status.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm log olt-chpair-tc-tca [ (index) ]
```

Command Parameters

Table 102.149-1 " Channel Pair OLT TC TCA Alarm Log Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm type

Command Output

Table 102.149-2 " Channel Pair OLT TC TCA Alarm Log Status Command" Display parameters

Specific Information		
name	Type	Description
last-updated-on	Parameter type: <Sys::timeInSecs> - the time (yyyy-mm-dd:hour:minutes:secs) - unit: UTC	network time in seconds when the alarm was logged <i>This element is only shown in detail mode.</i>
channel-pair	Parameter type: <Gpon::ChannelPairId> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::ChannelPairId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::ChannelPairId> - the channel pair identifier	channelpair ifindex <i>This element is only shown in detail mode.</i>

Only Show Details: current and previous alarm log status

name	Type	Description
olt-chpr-tc-err-frag	Parameter type: <Alarm::OLTCHPRTCTCAERRFRAGSPON> (yes no) Possible values: - yes : channelpair errored fragments threshold crossed - no : olt works properly	channelpair errored fragments threshold crossed <i>This element is only shown in detail mode.</i>
olt-chpr-up-bw-tca	Parameter type: <Alarm::OLTCHPRTCTCAUPBWTCa> (yes no) Possible values: - yes : olt channelpair upstream bandwidth tca - no : olt works properly	OLT CHANNELPAIR upstream bandwidth TCA <i>This element is only shown in detail mode.</i>
olt-chpr-down-bw-tca	Parameter type: <Alarm::OLTCHPRTCTCADWBWTCA> (yes no) Possible values: - yes : olt channelpair downstream bandwidth tca - no : olt works properly	OLT PON downstream bandwidth TCA <i>This element is only shown in detail mode.</i>

102.150 Ont Configuration Download Alarm Log Status Command

Command Description

This command displays the ont configuration download alarm log status.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm log ont-cfg-dld [ (index) ]
```

Command Parameters

Table 102.150-1 "Ont Configuration Download Alarm Log Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm log table index

Command Output

Table 102.150-2 "Ont Configuration Download Alarm Log Status Command" Display parameters

Specific Information		
name	Type	Description
last-updated-on	Parameter type: <Sys::timeInSecs> - the time (yyyy-mm-dd:hour:minutes:secs) - unit: UTC	network time in seconds when the alarm was logged. <i>This element is only shown in detail mode.</i>
ont	Parameter type: <Gpon::OntIndex> (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> ng2 : <Ng2::ChannelGroup> / <Ng2::SubchannelGroup> / <Ng2::OntId>) Possible values: - ng2 : ngpon2 style identification Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId>	identifies the ont entry <i>This element is only shown in detail mode.</i>

name	Type	Description
	- the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Ng2::ChannelGroup> - channel group number Field type <Ng2::SubchannelGroup> - subchannel group number Field type <Eqpt::OntId> - the ONT identifier Field type <Ng2::OntId> - the ONT identifier	
cfgfile-idx	Parameter type: <Alarm::OntCfgFileIndex> (configure file 1 configure file 2) Possible values: - configure file 1 : configure file 1 generate the alarm - configure file 2 : configure file 2 generate the alarm	identifies the configure file which generate the alarm <i>This element is only shown in detail mode.</i>

Only Show Details: current and previous alarm log status

name	Type	Description
cfg-dld-fail	Parameter type: <Alarm::OntCfgDldFail> (yes no) Possible values: - yes : download of configure file to ont is failed - no : download of configure file to ont is ok	current status of the alarm specifying download of configure file to ont is failed or not <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::OntCfgDldFail> (yes no) Possible values: - yes : download of configure file to ont is failed - no : download of configure file to ont is ok	status of cfg-dld-fail with its previous logged value. <i>This element is only shown in detail mode.</i>
cfg-act-fail	Parameter type: <Alarm::OntCfgActFail> (yes no) Possible values: - yes : activate the passive config file failed - no : activate the passive config file ok	current status of the alarm specifying activate of configure file to ont is failed or not <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::OntCfgActFail> (yes no) Possible values: - yes : activate the passive config file failed - no : activate the passive config file ok	status of cfg-act-fail with its previous logged value. <i>This element is only shown in detail mode.</i>
cfg-dld-ip	Parameter type: <Alarm::OntCfgDldIp> (yes no) Possible values: - yes : ont configure file download in progress - no : no ont configure file download detected	current status of the alarm specifying whether downloading <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::OntCfgDldIp> (yes no) Possible values: - yes : ont configure file download in progress - no : no ont configure file download detected	status of cfg-dld-ip with its previous logged value. <i>This element is only shown in detail mode.</i>
cfg-ver-mismatch	Parameter type: <Alarm::OntCfgVerMismatch> (yes	current status of the alarm specifying whether planned

102 Alarm Log Status Commands

name	Type	Description
	no) Possible values: - yes : the planned configure file does not match the active configure file - no : the planned configure file match the active configure file	configure file match the active configure file or not <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::OntCfgVerMismatch> (yes no) Possible values: - yes : the planned configure file does not match the active configure file - no : the planned configure file match the active configure file	status of cfg-ver-mismatch with its previous logged value. <i>This element is only shown in detail mode.</i>
cfg-file-missing	Parameter type: <Alarm::OntCfgFileMissing> (yes no) Possible values: - yes : ont configure file missing or has an error - no : ont configure file ok	ont configure file missing <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::OntCfgFileMissing> (yes no) Possible values: - yes : ont configure file missing or has an error - no : ont configure file ok	status of cfg-file-missing with its previous logged value. <i>This element is only shown in detail mode.</i>
cfg-verctrl-err	Parameter type: <Alarm::OntCfgVerCtrlErr> (yes no) Possible values: - yes : ont configure file version control error - no : ont configure file version control ok	ont configure file version control error <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::OntCfgVerCtrlErr> (yes no) Possible values: - yes : ont configure file version control error - no : ont configure file version control ok	status of cfg-verctrl-err with its previous logged value. <i>This element is only shown in detail mode.</i>
cfg-not-supported	Parameter type: <Alarm::OntCfgNotSupported> (yes no) Possible values: - yes : ont not support the configure file download function - no : ont support the configure file download function	ont not support configure file download function <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::OntCfgNotSupported> (yes no) Possible values: - yes : ont not support the configure file download function - no : ont support the configure file download function	status of cfg-not-supported with its previous logged value. <i>This element is only shown in detail mode.</i>

102.151 HGU TR069 Alarm Log Status Command

Command Description

This command displays the hgu tr069 alarm log status.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm log hgu-tr069 [ (index) ]
```

Command Parameters

Table 102.151-1 "HGU TR069 Alarm Log Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm log table index

Command Output

Table 102.151-2 "HGU TR069 Alarm Log Status Command" Display parameters

Specific Information		
name	Type	Description
last-updated-on	Parameter type: <Sys::timeInSecs> - the time (yyyy-mm-dd:hour:minutes:secs) - unit: UTC	network time in seconds when the alarm was logged. <i>This element is only shown in detail mode.</i>
ont	Parameter type: <Gpon::OntIndex> (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> ng2 : <Ng2::ChannelGroup> / <Ng2::SubchannelGroup> / <Ng2::OntId>) Possible values: - ng2 : ngpon2 style identification Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier	identifies the ont entry <i>This element is only shown in detail mode.</i>

102 Alarm Log Status Commands

name	Type	Description
	Field type <Ng2::ChannelGroup> - channel group number Field type <Ng2::SubchannelGroup> - subchannel group number Field type <Eqpt::OntId> - the ONT identifier Field type <Ng2::OntId> - the ONT identifier	

Only Show Details: current and previous alarm log status		
name	Type	Description
cust-alm1	Parameter type: <Alarm::HguCustAlm1> (yes no) Possible values: - yes : customized alarm 1 exist - no : customized alarm 1 not exist	current status of customized alarm 1 <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::HguCustAlm1> (yes no) Possible values: - yes : customized alarm 1 exist - no : customized alarm 1 not exist	status of cust-alm1 with its previous logged value. <i>This element is only shown in detail mode.</i>
cust-alm2	Parameter type: <Alarm::HguCustAlm2> (yes no) Possible values: - yes : customized alarm 2 exist - no : customized alarm 2 not exist	current status of customized alarm 2 <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::HguCustAlm2> (yes no) Possible values: - yes : customized alarm 2 exist - no : customized alarm 2 not exist	status of cust-alm2 with its previous logged value. <i>This element is only shown in detail mode.</i>
cust-alm3	Parameter type: <Alarm::HguCustAlm3> (yes no) Possible values: - yes : customized alarm 3 exist - no : customized alarm 3 not exist	current status of customized alarm 3 <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::HguCustAlm3> (yes no) Possible values: - yes : customized alarm 3 exist - no : customized alarm 3 not exist	status of cust-alm3 with its previous logged value. <i>This element is only shown in detail mode.</i>
cust-alm4	Parameter type: <Alarm::HguCustAlm4> (yes no) Possible values: - yes : customized alarm 4 exist - no : customized alarm 4 not exist	current status of customized alarm 4 <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::HguCustAlm4> (yes no) Possible values: - yes : customized alarm 4 exist	status of cust-alm4 with its previous logged value. <i>This element is only shown in detail mode.</i>

name	Type	Description
	- no : customized alarm 4 not exist	
cust-alm5	Parameter type: <Alarm::HguCustAlm5> (yes no) Possible values: - yes : customized alarm 5 exist - no : customized alarm 5 not exist	current status of customized alarm 5 <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::HguCustAlm5> (yes no) Possible values: - yes : customized alarm 5 exist - no : customized alarm 5 not exist	status of cust-alm5 with its previous logged value. <i>This element is only shown in detail mode.</i>
cust-alm6	Parameter type: <Alarm::HguCustAlm6> (yes no) Possible values: - yes : customized alarm 6 exist - no : customized alarm 6 not exist	current status of customized alarm 6 <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::HguCustAlm6> (yes no) Possible values: - yes : customized alarm 6 exist - no : customized alarm 6 not exist	status of cust-alm6 with its previous logged value. <i>This element is only shown in detail mode.</i>
cust-alm7	Parameter type: <Alarm::HguCustAlm7> (yes no) Possible values: - yes : customized alarm 7 exist - no : customized alarm 7 not exist	current status of customized alarm 7 <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::HguCustAlm7> (yes no) Possible values: - yes : customized alarm 7 exist - no : customized alarm 7 not exist	status of cust-alm7 with its previous logged value. <i>This element is only shown in detail mode.</i>
cust-alm8	Parameter type: <Alarm::HguCustAlm8> (yes no) Possible values: - yes : customized alarm 8 exist - no : customized alarm 8 not exist	current status of customized alarm 8 <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::HguCustAlm8> (yes no) Possible values: - yes : customized alarm 8 exist - no : customized alarm 8 not exist	status of cust-alm8 with its previous logged value. <i>This element is only shown in detail mode.</i>
cust-alm9	Parameter type: <Alarm::HguCustAlm9> (yes no) Possible values: - yes : customized alarm 9 exist - no : customized alarm 9 not exist	current status of customized alarm 9 <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::HguCustAlm9> (yes	status of cust-alm9 with its previous logged value.

102 Alarm Log Status Commands

name	Type	Description
	no) Possible values: - yes : customized alarm 9 exist - no : customized alarm 9 not exist	<i>This element is only shown in detail mode.</i>
cust-alm10	Parameter type: <Alarm::HguCustAlm10> (yes no) Possible values: - yes : customized alarm 10 exist - no : customized alarm 10 not exist	current status of customized alarm 10 <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::HguCustAlm10> (yes no) Possible values: - yes : customized alarm 10 exist - no : customized alarm 10 not exist	status of cust-alm10 with its previous logged value. <i>This element is only shown in detail mode.</i>
cust-alm11	Parameter type: <Alarm::HguCustAlm11> (yes no) Possible values: - yes : customized alarm 11 exist - no : customized alarm 11 not exist	current status of customized alarm 11 <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::HguCustAlm11> (yes no) Possible values: - yes : customized alarm 11 exist - no : customized alarm 11 not exist	status of cust-alm11 with its previous logged value. <i>This element is only shown in detail mode.</i>
cust-alm12	Parameter type: <Alarm::HguCustAlm12> (yes no) Possible values: - yes : customized alarm 12 exist - no : customized alarm 12 not exist	current status of customized alarm 12 <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::HguCustAlm12> (yes no) Possible values: - yes : customized alarm 12 exist - no : customized alarm 12 not exist	status of cust-alm12 with its previous logged value. <i>This element is only shown in detail mode.</i>
cust-alm13	Parameter type: <Alarm::HguCustAlm13> (yes no) Possible values: - yes : customized alarm 13 exist - no : customized alarm 13 not exist	current status of customized alarm 13 <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::HguCustAlm13> (yes no) Possible values: - yes : customized alarm 13 exist - no : customized alarm 13 not exist	status of cust-alm13 with its previous logged value. <i>This element is only shown in detail mode.</i>
cust-alm14	Parameter type: <Alarm::HguCustAlm14> (yes no) Possible values: - yes : customized alarm 14 exist	current status of customized alarm 14 <i>This element is only shown in detail mode.</i>

name	Type	Description
	- no : customized alarm 14 not exist	
prev-status	Parameter type: <Alarm::HguCustAlm14> (yes no) Possible values: - yes : customized alarm 14 exist - no : customized alarm 14 not exist	status of cust-alm14 with its previous logged value. <i>This element is only shown in detail mode.</i>
cust-alm15	Parameter type: <Alarm::HguCustAlm15> (yes no) Possible values: - yes : customized alarm 15 exist - no : customized alarm 15 not exist	current status of customized alarm 15 <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::HguCustAlm15> (yes no) Possible values: - yes : customized alarm 15 exist - no : customized alarm 15 not exist	status of cust-alm15 with its previous logged value. <i>This element is only shown in detail mode.</i>
cust-alm16	Parameter type: <Alarm::HguCustAlm16> (yes no) Possible values: - yes : customized alarm 16 exist - no : customized alarm 16 not exist	current status of customized alarm 16 <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::HguCustAlm16> (yes no) Possible values: - yes : customized alarm 16 exist - no : customized alarm 16 not exist	status of cust-alm16 with its previous logged value. <i>This element is only shown in detail mode.</i>
cust-alm17	Parameter type: <Alarm::HguCustAlm17> (yes no) Possible values: - yes : customized alarm 17 exist - no : customized alarm 17 not exist	current status of customized alarm 17 <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::HguCustAlm17> (yes no) Possible values: - yes : customized alarm 17 exist - no : customized alarm 17 not exist	status of cust-alm17 with its previous logged value. <i>This element is only shown in detail mode.</i>
cust-alm18	Parameter type: <Alarm::HguCustAlm18> (yes no) Possible values: - yes : customized alarm 18 exist - no : customized alarm 18 not exist	current status of customized alarm 18 <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::HguCustAlm18> (yes no) Possible values: - yes : customized alarm 18 exist - no : customized alarm 18 not exist	status of cust-alm18 with its previous logged value. <i>This element is only shown in detail mode.</i>
cust-alm19	Parameter type: <Alarm::HguCustAlm19> (yes	current status of customized alarm 19

102 Alarm Log Status Commands

name	Type	Description
	no) Possible values: - yes : customized alarm 19 exist - no : customized alarm 19 not exist	<i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::HguCustAlm19> (yes no) Possible values: - yes : customized alarm 19 exist - no : customized alarm 19 not exist	status of cust-alm19 with its previous logged value. <i>This element is only shown in detail mode.</i>
cust-alm20	Parameter type: <Alarm::HguCustAlm20> (yes no) Possible values: - yes : customized alarm 20 exist - no : customized alarm 20 not exist	current status of customized alarm 20 <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::HguCustAlm20> (yes no) Possible values: - yes : customized alarm 20 exist - no : customized alarm 20 not exist	status of cust-alm20 with its previous logged value. <i>This element is only shown in detail mode.</i>
cust-alm21	Parameter type: <Alarm::HguCustAlm21> (yes no) Possible values: - yes : customized alarm 21 exist - no : customized alarm 21 not exist	current status of customized alarm 21 <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::HguCustAlm21> (yes no) Possible values: - yes : customized alarm 21 exist - no : customized alarm 21 not exist	status of cust-alm21 with its previous logged value. <i>This element is only shown in detail mode.</i>
cust-alm22	Parameter type: <Alarm::HguCustAlm22> (yes no) Possible values: - yes : customized alarm 22 exist - no : customized alarm 22 not exist	current status of customized alarm 22 <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::HguCustAlm22> (yes no) Possible values: - yes : customized alarm 22 exist - no : customized alarm 22 not exist	status of cust-alm22 with its previous logged value. <i>This element is only shown in detail mode.</i>
cust-alm23	Parameter type: <Alarm::HguCustAlm23> (yes no) Possible values: - yes : customized alarm 23 exist - no : customized alarm 23 not exist	current status of customized alarm 23 <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::HguCustAlm23> (yes no) Possible values: - yes : customized alarm 23 exist	status of cust-alm23 with its previous logged value. <i>This element is only shown in detail mode.</i>

name	Type	Description
	- no : customized alarm 23 not exist	
cust-alm24	Parameter type: <Alarm::HguCustAlm24> (yes no) Possible values: - yes : customized alarm 24 exist - no : customized alarm 24 not exist	current status of customized alarm 24 <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::HguCustAlm24> (yes no) Possible values: - yes : customized alarm 24 exist - no : customized alarm 24 not exist	status of cust-alm24 with its previous logged value. <i>This element is only shown in detail mode.</i>
cust-alm25	Parameter type: <Alarm::HguCustAlm25> (yes no) Possible values: - yes : customized alarm 25 exist - no : customized alarm 25 not exist	current status of customized alarm 25 <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::HguCustAlm25> (yes no) Possible values: - yes : customized alarm 25 exist - no : customized alarm 25 not exist	status of cust-alm25 with its previous logged value. <i>This element is only shown in detail mode.</i>
cust-alm26	Parameter type: <Alarm::HguCustAlm26> (yes no) Possible values: - yes : customized alarm 26 exist - no : customized alarm 26 not exist	current status of customized alarm 26 <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::HguCustAlm26> (yes no) Possible values: - yes : customized alarm 26 exist - no : customized alarm 26 not exist	status of cust-alm26 with its previous logged value. <i>This element is only shown in detail mode.</i>
cust-alm27	Parameter type: <Alarm::HguCustAlm27> (yes no) Possible values: - yes : customized alarm 27 exist - no : customized alarm 27 not exist	current status of customized alarm 27 <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::HguCustAlm27> (yes no) Possible values: - yes : customized alarm 27 exist - no : customized alarm 27 not exist	status of cust-alm27 with its previous logged value. <i>This element is only shown in detail mode.</i>
cust-alm28	Parameter type: <Alarm::HguCustAlm28> (yes no) Possible values: - yes : customized alarm 28 exist - no : customized alarm 28 not exist	current status of customized alarm 28 <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::HguCustAlm28> (yes	status of cust-alm28 with its previous logged value.

102 Alarm Log Status Commands

name	Type	Description
	no) Possible values: - yes : customized alarm 28 exist - no : customized alarm 28 not exist	<i>This element is only shown in detail mode.</i>
cust-alm29	Parameter type: <Alarm::HguCustAlm29> (yes no) Possible values: - yes : customized alarm 29 exist - no : customized alarm 29 not exist	current status of customized alarm 29 <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::HguCustAlm29> (yes no) Possible values: - yes : customized alarm 29 exist - no : customized alarm 29 not exist	status of cust-alm29 with its previous logged value. <i>This element is only shown in detail mode.</i>
cust-alm30	Parameter type: <Alarm::HguCustAlm30> (yes no) Possible values: - yes : customized alarm 30 exist - no : customized alarm 30 not exist	current status of customized alarm 30 <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::HguCustAlm30> (yes no) Possible values: - yes : customized alarm 30 exist - no : customized alarm 30 not exist	status of cust-alm30 with its previous logged value. <i>This element is only shown in detail mode.</i>
cust-alm31	Parameter type: <Alarm::HguCustAlm31> (yes no) Possible values: - yes : customized alarm 31 exist - no : customized alarm 31 not exist	current status of customized alarm 31 <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::HguCustAlm31> (yes no) Possible values: - yes : customized alarm 31 exist - no : customized alarm 31 not exist	status of cust-alm31 with its previous logged value. <i>This element is only shown in detail mode.</i>

102.152 Equipment Holder Extended Alarm Log Status Command

Command Description

This command displays the equipment holder extended alarm log status.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm log eqpt-psu [ (index) ]
```

Command Parameters

Table 102.152-1 "Equipment Holder Extended Alarm Log Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm log table index

Command Output

Table 102.152-2 "Equipment Holder Extended Alarm Log Status Command" Display parameters

Specific Information		
name	Type	Description
last-updated-on	Parameter type: <Sys::timeInSecs> - the time (yyyy-mm-dd:hour:minutes:secs) - unit: UTC	network time in seconds when the alarm was logged. <i>This element is only shown in detail mode.</i>
shelf	Parameter type: <Equipm::Shelf> <Eqpt::RackId> / <Eqpt::ShelfId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number	specify which shelf the alarm occurred on. <i>This element is only shown in detail mode.</i>
Only Show Details: current and previous alarm log status		
name	Type	Description
psu-a-fail-presence	Parameter type: <Alarm::psuAPresence> (yes no) Possible values:	current status of PSU A presence <i>This element is only shown in detail mode.</i>

102 Alarm Log Status Commands

name	Type	Description
	- yes : PSU A presence failure - no : PSU A presence state OK	
prev-status	Parameter type: <Alarm::psuAPresence> (yes no) Possible values: - yes : PSU A presence failure - no : PSU A presence state OK	status of PSU A presence alarm <i>This element is only shown in detail mode.</i>
psu-a-fail-overtemp	Parameter type: <Alarm::psuAFailOverTemp> (yes no) Possible values: - yes : PSU A failure over temperature - no : PSU A temperature OK	current status of PSU A temperature alarm <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::psuAFailOverTemp> (yes no) Possible values: - yes : PSU A failure over temperature - no : PSU A temperature OK	status of PSU A output over temperature alarm <i>This element is only shown in detail mode.</i>
psu-a-fail-vin-ac-nok	Parameter type: <Alarm::psuAFailVinACNOK> (yes no) Possible values: - yes : PSU A failure input AC voltage - no : PSU A input AC voltage OK	current status of PSU A input AC voltage alarm <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::psuAFailVinACNOK> (yes no) Possible values: - yes : PSU A failure input AC voltage - no : PSU A input AC voltage OK	status of PSU A input AC voltage alarm <i>This element is only shown in detail mode.</i>
psu-b-fail-presence	Parameter type: <Alarm::psuBPresence> (yes no) Possible values: - yes : PSU B presence failure - no : PSU B presence state OK	current status of PSU B presence <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::psuBPresence> (yes no) Possible values: - yes : PSU B presence failure - no : PSU B presence state OK	status of PSU B presence alarm <i>This element is only shown in detail mode.</i>
psu-b-fail-overtemp	Parameter type: <Alarm::psuBFailOverTemp> (yes no) Possible values: - yes : PSU B failure over temperature - no : PSU B temperature OK	current status of PSU B temperature alarm <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::psuBFailOverTemp> (yes no) Possible values: - yes : PSU B failure over temperature - no : PSU B temperature OK	status of PSU B output over temperature alarm <i>This element is only shown in detail mode.</i>
psu-b-fail-vin-ac-nok	Parameter type: <Alarm::psuBFailVinACNOK>	current status of PSU B input AC

name	Type	Description
	(yes no) Possible values: - yes : PSU B failure input AC voltage - no : PSU B input AC voltage OK	voltage alarm <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::psuBFailVinACNOK> (yes no) Possible values: - yes : PSU B failure input AC voltage - no : PSU B input AC voltage OK	status of PSU B input AC voltage alarm <i>This element is only shown in detail mode.</i>

102.153 Ethernet Ring Alarm Log Status Command

Command Description

This command displays ethernet ring alarm Log status.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

> show alarm log ethernet-ring [(index)]

Command Parameters

Table 102.153-1 "Ethernet Ring Alarm Log Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm log table index

Command Output

Table 102.153-2 "Ethernet Ring Alarm Log Status Command" Display parameters

Specific Information		
name	Type	Description
last-updated-on	Parameter type: <Sys::timeInSecs> - the time (yyyy-mm-dd:hour:minutes:secs) - unit: UTC	network time in seconds when the alarm was logged <i>This element is only shown in detail mode.</i>
eth-ring-instance-id	Parameter type: <UnsignedSignedInteger> - an unsigned integer	ethernet ring instance id where the alarm has occurred <i>This element is only shown in detail mode.</i>
eth-ring-path	Parameter type: <Alarm::EthernetRingPath> (path-a path-b n/a) Possible values: - path-a : path-a of the ethernet ring instance - path-b : path-b of the ethernet ring instance - n/a : not applicable for the alarm, fop-pm	unique identification for the alarm, which identifies the path of the ethernet ring instance <i>This element is only shown in detail mode.</i>

Only Show Details: current and previous alarm log status		
name	Type	Description
eth-ring-fwd-st	Parameter type: <Alarm::EthernetRingPathFwdState>	current status of the forward state

name	Type	Description
	(blocked unblocked) Possible values: - blocked : ethernet ring path fwd state blocked - unblocked : ethernet ring path fwd state unblocked	of the ethernet ring path <i>This element is only shown in detail mode.</i>
prev-eth-ring-fwd-st	Parameter type: <Alarm::EthernetRingPathFwdState> (blocked unblocked) Possible values: - blocked : ethernet ring path fwd state blocked - unblocked : ethernet ring path fwd state unblocked	previous status of the forward state of the ethernet ring path <i>This element is only shown in detail mode.</i>
eth-ring-fop-to	Parameter type: <Alarm::EthernetRingFOPTIMEOUT> (yes no) Possible values: - yes : fop-to occurred - no : fop-to not occurred	current status of ethernet ring fop-to failure of protocol timeout <i>This element is only shown in detail mode.</i>
prev-eth-ring-fop-to	Parameter type: <Alarm::EthernetRingFOPTIMEOUT> (yes no) Possible values: - yes : fop-to occurred - no : fop-to not occurred	previous status of the ethernet ring fop-to failure of protocol timeout <i>This element is only shown in detail mode.</i>
eth-ring-fop-pm	Parameter type: <Alarm::EthernetRingFOPPM> (yes no) Possible values: - yes : fop-pm occurred - no : fop-pm not occurred	current status of ethernet ring failure of protocol provision mismatch alarm (fop-pm) <i>This element is only shown in detail mode.</i>
prev-eth-ring-fop-pm	Parameter type: <Alarm::EthernetRingFOPPM> (yes no) Possible values: - yes : fop-pm occurred - no : fop-pm not occurred	previous status of the ethernet ring failure of protocol provision mismatch alarm (fop-pm) <i>This element is only shown in detail mode.</i>

102.154 Lldpmed Alarm Log Status Command

Command Description

This command displays the LLDP-MED alarm log status.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm log lldpmed [ (index) ]
```

Command Parameters

Table 102.154-1 "Lldpmed Alarm Log Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm log table index

Command Output

Table 102.154-2 "Lldpmed Alarm Log Status Command" Display parameters

Specific Information		
name	Type	Description
last-updated-on	Parameter type: <Sys::timeInSecs> - the time (yyyy-mm-dd:hour:minutes:secs) - unit: UTC	network time in seconds when the alarm was logged. <i>This element is always shown.</i>
port	Parameter type: <LLDPMed::LLDPMedPort> (uni : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> / <Eqpt::OntPortId> uni:ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / <Eqpt::Ng2OntSlotId> / <Eqpt::Ng2OntPortId> uni:ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / vuni) Possible values: - uni : uni - uni:ng2 : ngpon2 UNI style identification Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number	identify the provisioned lldpmed port where the alarm has occurred. <i>This element is always shown.</i>

name	Type	Description
	Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Eqpt::OntId> - the ONT identifier Field type <Eqpt::ChannelGroupId> - the channel group identifier Field type <Eqpt::SubChannelGroupId> - the subchannel group identifier Field type <Eqpt::Ng2OntId> - the NG2 ONT identifier Possible values: - vuni : virtual NGPON2 uni identifier Field type <Eqpt::OntSlotId> - the ONT SLOT identifier Field type <Eqpt::OntPortId> - the ONT PORT identifier Field type <Eqpt::Ng2OntSlotId> - the NGPON2 ONT SLOT identifier Field type <Eqpt::Ng2OntPortId> - the NGPON2 ONT PORT identifier	

Only Show Details: current and previous alarm log status		
name	Type	Description
lldpmed-portcfg-mis	Parameter type: <Alarm::LLDPMED-portcfg-mismatch> (yes no) Possible values: - yes : configuration request not accepted - no : configuration accepted	current status of the alarm specifying if the configuration for a provisioned lldpmed port is accepted or not. <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::LLDPMED-portcfg-mismatch> (yes no) Possible values: - yes : configuration request not accepted - no : configuration accepted	status of lldpmed portconfig mismatch alarm with its previous logged value. <i>This element is only shown in detail mode.</i>
lldpmed-mediapl-mis	Parameter type: <Alarm::LLDPMED-mediapl-mismatch> (yes no) Possible values: - yes : configuration request not accepted - no : configuration accepted	current status of the alarm specifying if the configuration for a provisioned lldpmed mediapolicy is accepted or not. <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::LLDPMED-mediapl-mismatch> (yes no) Possible values: - yes : configuration request not accepted - no : configuration accepted	status of lldpmed mediapolicy mismatch alarm with its previous logged value. <i>This element is only shown in detail mode.</i>

102.155 Lag group Alarm Log Status Command

Command Description

This command displays lag group alarm Log status.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm log link-aggr [ (index) ]
```

Command Parameters

Table 102.155-1 "Lag group Alarm Log Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm log table index

Command Output

Table 102.155-2 "Lag group Alarm Log Status Command" Display parameters

Specific Information		
name	Type	Description
last-updated-on	Parameter type: <Sys::timeInSecs> - the time (yyyy-mm-dd:hour:minutes:secs) - unit: UTC	network time in seconds when the alarm was logged. <i>This element is only shown in detail mode.</i>
group	Parameter type: <Itf::LaGroupIndex> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number	identifies lag group index <i>This element is only shown in detail mode.</i>

Only Show Details: current and previous alarm log status		
name	Type	Description
la-oper-down	Parameter type: <Alarm::LaGroupDown> (yes	specifies whether an lag is down or not

name	Type	Description
	no) Possible values: - yes : link group operation down - no : link group operation up	<i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::LaGroupDown> (yes no) Possible values: - yes : link group operation down - no : link group operation up	previously oper-status of the lag alarm. <i>This element is only shown in detail mode.</i>
standby-not-available	Parameter type: <Alarm::StandbyUnavailable> (yes no) Possible values: - yes : lack of link-up ports on standby slot - no : link-up ports enough on standby slot	specifies whether standby slot is available <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::StandbyUnavailable> (yes no) Possible values: - yes : lack of link-up ports on standby slot - no : link-up ports enough on standby slot	status of available of standby slot. <i>This element is only shown in detail mode.</i>
switch-fail	Parameter type: <Alarm::LaSwitchFail> (yes no) Possible values: - yes : switchover failed for cross-lt la group - no : switchover is successful for cross-lt la group	specifies whether switchover is failed <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::LaSwitchFail> (yes no) Possible values: - yes : switchover failed for cross-lt la group - no : switchover is successful for cross-lt la group	status of switchover of cross-lag. <i>This element is only shown in detail mode.</i>
la-degrade	Parameter type: <Alarm::LaDegrade> (yes no) Possible values: - yes : lack of link-up ports on active slot - no : link-up ports enough on active slot	specifies whether lag degrades <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::LaDegrade> (yes no) Possible values: - yes : lack of link-up ports on active slot - no : link-up ports enough on active slot	status of degradation of lag. <i>This element is only shown in detail mode.</i>

102.156 40GBase-KR4 fcs exceed Alarm Log Status Command

Command Description

This command displays 40GBase-KR4 fcs exceed alarm Log status.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

> show alarm log fcs-exceed [(index)]

Command Parameters

Table 102.156-1 "40GBase-KR4 fcs exceed Alarm Log Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm log table index

Command Output

Table 102.156-2 "40GBase-KR4 fcs exceed Alarm Log Status Command" Display parameters

Specific Information		
name	Type	Description
last-updated-on	Parameter type: <Sys::timeInSecs> - the time (yyyy-mm-dd:hour:minutes:secs) - unit: UTC	network time in seconds when the alarm was logged. <i>This element is only shown in detail mode.</i>
slot	Parameter type: <Equipm::EqptSlotIndex> (lt : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> nt-a nt-b nt acu : <Eqpt::RackId> / <Eqpt::ShelfId> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::EqSlotId> ext-a : <Eqpt::RackId> / <Eqpt::ShelfId> ext-b : <Eqpt::RackId> / <Eqpt::ShelfId> ctrl : <Eqpt::RackId> / <Eqpt::ShelfId> vlt : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::VirtualSlotId>)	identifies index <i>This element is only shown in detail mode.</i>

name	Type	Description
	Possible values: - lt : lt-slot - vlt : virtual LT slot (VVPS board can only be planned at NANT-E / FANT-F) - nt-a : nt-a slot - nt-b : nt-b slot - nt : nt slot - ext-a : nt-a slot in an extension shelf - ext-b : nt-b slot in an extension shelf - acu : acu slot - ctrl : ctrl-slot Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::VirtualSlotId> - the virtual LT slot number Field type <Eqpt::EqSlotId> - the equipment slot number	
nta/b	Parameter type: <UnsignedSignedInteger> - an unsigned integer	identifies index2 <i>This element is only shown in detail mode.</i>

Only Show Details: current and previous alarm log status

name	Type	Description
fcs-is-exceed	Parameter type: <Alarm::almltypeFCSthreshexceed> (yes no) Possible values: - yes : FCS auto-recovery counter exceeded threshold - no : FCS auto-recovery counter not exceeded threshold	specifies whether fcs auto-recovery counter is exceed or not <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::almltypeFCSthreshexceed> (yes no) Possible values: - yes : FCS auto-recovery counter exceeded threshold - no : FCS auto-recovery counter not exceeded threshold	previously oper-status of the 40GBase-KR4 fcs exceed alarm. <i>This element is only shown in detail mode.</i>

103- Alarm Snap-shot Status Commands

103.1 Alarm Snap-shot Status Command Tree	103-4390
103.2 Alarm Snapshot Status Command	103-4396
103.3 Alarm Snapshot Equipment Status Command	103-4404
103.4 Equipment Holder Alarm Log Status Command	103-4407
103.5 Equipment Holder Alarm Extended Log Status Command	103-4409
103.6 Plug-in Unit Alarm Log Status Command	103-4411
103.7 ATM Alarm Log Status Command	103-4414
103.8 Alarm Snapshot Ethernet Interface Status Command	103-4416
103.9 Alarm Snapshot Software Management Status Command	103-4417
103.10 Alarm Snapshot Temporal Filter Status Command	103-4419
103.11 Alarm Snapshot Spatial Filter Status Command	103-4423
103.12 Alarm xDSL Snapshot Status Command	103-4427
103.13 TCA xDSL Alarm Log Status Command	103-4431
103.14 OLT General Alarm Snapshot Status Command	103-4435
103.15 Alarm Vectoring Line Snapshot Status Command	103-4439
103.16 Alarm Vectoring Board Snapshot Status Command	103-4441
103.17 Alarm Electrical-to-Optical Conversion for Snapshot Status Command	103-4443
103.18 Authentication Alarms for Snapshot Status Command	103-4444
103.19 Alarm xDSL Bonding Snap Shot Status Command	103-4447
103.20 Alarm Redundancy Snapshot Status Command	103-4450
103.21 Alarm Custom Snapshot Status Command	103-4451
103.22 Alarm SFP Snapshot Status Command	103-4455
103.23 Alarm Custom External Snap Shot Status Command	103-4459
103.24 Alarm RSSI SFP Snapshot Status Command	103-4461
103.25 Alarm PPP Cross-Connect Engine TCA Snapshot Status Command	103-4466
103.26 Ellid Alarm Status Command	103-4468
103.27 2xE1/DS1 SFP Clock Snapshot Status Command	103-4475
103.28 2xE1/DS1 SFP Framer Snapshot Status Command	103-4478
103.29 Epon Olt Sfp RSSI Snapshot Alarm Status Command	103-4482
103.30 Alarm Plug In Unit Extended Snap Shot Status Command	103-4486
103.31 Alarm Snap-shot SIP Server Status Command	103-4490
103.32 Alarm Snap-shot SIP VSP Status Command	103-4491
103.33 Alarm Snap-shot SIP Dial Plan Status Command	103-4493
103.34 Alarm Snap-shot SIP User Agent Status Command	103-4494
103.35 Alarm Snap-shot SIP Slot Status Command	103-4496
103.36 Alarm Snap-shot SIP Termination Status Command	103-4497
103.37 Alarm Snap-shot Secondary SIP Termination Status Command	103-4500
103.38 Alarm Snap-shot SIP Termination Status Command	103-4503
103.39 Alarm Snap-shot E1/T1 interface Status Command	103-4506
103.40 Alarm Snap-shot SIP Termination Status Command	103-4508
103.41 Alarm Snap-shot Pseudo Wire Status Command	103-4510

103.42 Alarm Snap-shot Megaco Media Gateway Status Command	103-4512
103.43 Alarm Snap-shot Megaco Signaling Gateway Status Command	103-4513
103.44 Alarm Snap-shot Megaco Plug Unit Status Command	103-4514
103.45 Alarm Snap-shot Megaco Termination Status Command	103-4515
103.46 Alarm Snap-shot Secondary Megaco Termination Status Command	103-4517
103.47 Alarm Snap-shot Megaco Signaling Lt Status Command	103-4518
103.48 Alarm Snap-shot E1 Status Command	103-4520
103.49 Alarm Snap-shot Shdsl Status Command	103-4522
103.50 Alarm Snap-shot Shdsl Status Command	103-4524
103.51 Alarm Snap-shot Ima-Group Status Command	103-4526
103.52 Alarm Snap-shot Ima-Link Status Command	103-4528
103.53 Alarm Snap-shot Ether-Tca Status Command	103-4530
103.54 Alarm Snap-shot Ether-Sfp Status Command	103-4532
103.55 Alarm Snap-shot Ether-Sfp Status Command	103-4534
103.56 Alarm Snap-shot SIP Termination Status Command	103-4536
103.57 Alarm Snap-shot SIP Termination Status Command	103-4538
103.58 Alarm File Transfer Server Status Command	103-4541
103.59 Alarm Lsm Redundancy Status Command	103-4542
103.60 Alarm L2 Forward Status Command	103-4544
103.61 Alarm Snap-shot External Device Status Command	103-4547
103.62 Alarm Snap-shot Multicast Source Status Command	103-4548
103.63 Vlanport Alarm Snapshot Status Command	103-4550
103.64 BGP Alarm SnapShot Status Command	103-4553
103.65 RIP Alarm SnapShot Status Command	103-4555
103.66 LAG Alarm SnapShot Status Command	103-4556
103.67 ihub-general Alarm SnapShot Status Command	103-4558
103.68 VPRN Alarm SnapShot Status Command	103-4560
103.69 ISIS Alarm SnapShot Status Command	103-4562
103.70 OSPF Alarm SnapShot Status Command	103-4564
103.71 ihub-l2forward Alarm SnapShot Status Command	103-4566
103.72 VPLS Alarm SnapShot Status Command	103-4568
103.73 IHUB-Equip Alarm SnapShot Status Command	103-4570
103.74 IHUB-link Alarm SnapShot Status Command	103-4572
103.75 IHUB-tca Alarm SnapShot Status Command	103-4575
103.76 LDP Alarm SnapShot Status Command	103-4578
103.77 Alarm SnapShot MPLS Status Command	103-4580
103.78 Alarm SnapShot SDP Status Command	103-4582
103.79 IHUB IPV6 Alarm SnapShot Status Command	103-4584
103.80 Alarm SnapShot EPIPE Status Command	103-4586
103.81 Alarm SnapShot PIM Status Command	103-4587
103.82 IHUB Lawful Intercept Alarm SnapShot Status Command	103-4589
103.83 Sync Clock Alarm SnapShot Status Command	103-4591
103.84 Alarm Snapshot Equipment Supplemental Status Command	103-4595
103.85 Otdr Alarm SnapShot Status Command	103-4597
103.86 Management Security Access Alarm SnapShot Status Command	103-4603
103.87 IHUB BFD Alarm SnapShot Status Command	103-4605
103.88 Application Intelligence Alarm Snap-shot Status Command	103-4607
103.89 Alarm ONT SNMP Snapshot Status Command	103-4609
103.90 Tr069 Alarm Status Command	103-4611
103.91 Bulk Sync Alarm Log Status Command	103-4613
103.92 Protection Group Alarm Log Status Command	103-4615

103.93 Ont protection Alarm Snapshot Status Command	103-4617
103.94 ONT General Supplemental Alarm Snapshot Status Command	103-4619
103.95 SFU ONT General Supplemental Alarm Snapshot Status Command	103-4623
103.96 SOHO ONT General Supplemental Alarm Snapshot Status Command	103-4627
103.97 MDU ONT General Supplemental Alarm Snapshot Status Command	103-4631
103.98 ONT General Supplemental 2 Alarm Snapshot Status Command	103-4635
103.99 SFU ONT General Supplemental 2 Alarm Snapshot Status Command	103-4638
103.100 SOHO ONT General Supplemental 2 Alarm Snapshot Status Command	103-4641
103.101 MDU ONT General Supplemental 2 Alarm Snapshot Status Command	103-4644
103.102 LT CFM Alarm SnapShot Status Command	103-4647
103.103 IHUB CFM Alarm SnapShot Status Command	103-4649
103.104 Alarm SnapShot RSVP Status Command	103-4651
103.105 IPD eth-ring Alarm SnapShot Status Command	103-4653
103.106 EFM-OAM alarm Snap-shot Status Command	103-4655
103.107 ONT loop detect alarm Snap-shot Status Command	103-4657
103.108 ONT PLOAM Alarm Snapshot Status Command	103-4660
103.109 SFU ONT PLOAM Alarm Snapshot Status Command	103-4664
103.110 SOHO ONT PLOAM Alarm Snapshot Status Command	103-4668
103.111 MDU ONT PLOAM Alarm Snapshot Status Command	103-4672
103.112 ONT General Alarm Snapshot Status Command	103-4676
103.113 SFU ONT General Alarm Snapshot Status Command	103-4680
103.114 SOHO ONT General Alarm Snapshot Status Command	103-4684
103.115 MDU ONT General Alarm Snapshot Status Command	103-4688
103.116 Alarm SnapShot ONT SUBSCRIBER CARD Status Command	103-4692
103.117 Alarm SnapShot ONT SERVICES POTS Status Command	103-4694
103.118 Alarm SnapShot ONT SERVICES LAN Status Command	103-4699
103.119 ONT TCA Alarm Log Status Command	103-4701
103.120 Alarm SnapShot ONT TC TCA Status Command	103-4703
103.121 Alarm SnapShot ONT L2 UNI Ethernet TCA Status Command	103-4705
103.122 Alarm SnapShot OLT PON TC TCA Status Command	103-4707
103.123 Alarm SnapShot OLT PON Utilization TCA Status Command	103-4709
103.124 Alarm SnapShot OLT Channel Pair Utilization TCA Status Command	103-4713
103.125 Alarm SnapShot OLT ONT TC TCA Status Command	103-4717
103.126 Alarm SnapShot ONT POTS SUPPLEMENTAL Status Command	103-4719
103.127 Alarm SnapShot ONT VEIP Status Command	103-4722
103.128 Alarm SnapShot ONT IP HOST Status Command	103-4724
103.129 Alarm Table Snapshot Status Command	103-4726
103.130 Alarm SnapShot ONT VIDEO Status Command	103-4727

103.131 Alarm SnapShot ONT CES Status Command	103-4729
103.132 Alarm SnapShot ONT VOIP Status Command	103-4732
103.133 Alarm SnapShot ONT VIDEO ANI Status Command	103-4737
103.134 Alarm SnapShot ONT PWE Status Command	103-4739
103.135 Alarm SnapShot ONT CESE1 Status Command	103-4741
103.136 Alarm SnapShot ONT XDSL Status Command	103-4743
103.137 Alarm SnapShot ONT XDSL TCA Status Command	103-4746
103.138 Alarm SnapShot ONT HPNA Status Command	103-4748
103.139 Alarm SnapShot ONT SIP AGENT CFG Status Command	103-4750
103.140 Alarm SnapShot ONT VOIP CFG Status Command	103-4753
103.141 Alarm SnapShot ONT MGC Status Command	103-4757
103.142 Alarm Snapshot ONT MoCA Status Command	103-4759
103.143 ONT MoCA Threshold Crossing Alert (TCA) Alarm Snapshot Status Command	103-4761
103.144 Auto-Switch Alarm Snapshot Status Command	103-4763
103.145 Ont Configuration Download Snapshot Status Command	103-4765
103.146 Alarm Snapshot Channel Pair OLT TC TCA Status Command	103-4768
103.147 Alarm Snapshot Channel Pair Status Command	103-4770
103.148 HGU TR069 Snapshot Status Command	103-4773
103.149 Equipment Holder Alarm Extended Log Status Command	103-4778
103.150 Ethernet Ring Alarm SnapShot Status Command	103-4781
103.151 Lldpmed Alarm Snapshot Status Command	103-4783
103.152 Alarm Snap-shot Lag-group Status Command	103-4785
103.153 Alarm Snap-shot 40GBase-KR4 fcs exceed Status Command	103-4787

103.1 Alarm Snap-shot Status Command Tree

Description

This chapter gives an overview of nodes that are handled by "Alarm Snap-shot Status Commands".

Command Tree

```
----show
  ----alarm
    ----snap-shot
      ----table
        - (index)
      ----equipment
        - (index)
      ----eqpt-holder
        - (index)
      ----eqpt-holder-ext
        - (index)
      ----plug-in-unit
        - (index)
      ----atm
        - (index)
      ----ether-itf
        - (index)
      ----sw-mgmt
        - (index)
      ----temporal
        - (index)
      ----spatial
        - (index)
      ----xdsl
        - (index)
      ----xdsl-tca
        - (index)
      ----olt-gen
        - (index)
      ----vect-line
        - (index)
      ----vect-board
        - (index)
      ----eo-conversion
        - (index)
      ----authentication
        - (index)
      ----bonding-group
        - (index)
      ----redundancy
        - (index)
      ----custom
        - (index)
      ----sfp
        - (index)
      ----custom-ext-alarm
```


- (index)
- sfprssi
 - (index)
- pppcc-engine-tca
 - (index)
- ellid
 - (alarm-index)
- sfpe1t1-clock
 - (index)
- sfpe1t1-framer
 - (index)
- eoltrssi
 - (index)
- plug-in-unit-ext
 - (index)
- sip-server
 - (index)
- sip-vsp
 - (index)
- sip-dial-plan
 - (index)
- sip-user-agent
 - (index)
- sip-plugin-unit
 - (index)
- sip-termination
 - (index)
- secondary-sip-term
 - (index)
- e1-sip-termination
 - (index)
- e1t1-interface
 - (index)
- cas-r2-channel
 - (index)
- pseudo-wire
 - (index)
- megaco-media-gw
 - (index)
- megaco-sig-gw
 - (index)
- megaco-plug-unit
 - (index)
- megaco-term
 - (index)
- secondary-megaco-term
 - (index)
- megaco-sig-lt
 - (index)
- e1
 - (index)
- shdsl
 - (index)
- shdsl-isam
 - (index)
- ima-group
 - (index)
- ima-link
 - (index)

- ether-tca
 - (index)
- ether-sfp
 - (index)
- uplink-ether-sfp
 - (index)
- qos-slot
 - (index)
- qos-queue
 - (index)
- filetransfer
 - (index)
- lsmredundancy
 - (index)
- l2forward
 - (index)
- external-device
 - (index)
- mcsrc
 - (index)
- vlanport
 - (index)
- bgp
 - (index)
- rip
 - (index)
- lag
 - (index)
- ihub-general
 - (index)
- vprn
 - (index)
- isis
 - (index)
- ospf
 - (index)
- ihub-l2forward
 - (index)
- vpls
 - (index)
- ihub-equip
 - (index)
- ihub-link
 - (index)
- ihub-tca
 - (index)
- ldp
 - (index)
- mpls
 - (index)
- sdp
 - (index)
- ihub-ipv6
 - (index)
- epipe
 - (index)
- pim
 - (index)
- li

- (index)
- sync
 - (index)
- eqpt-supplemental
 - (index)
- otdr
 - (index)
- mgmt-sec-access
 - (index)
- bfd
 - (index)
- ai
 - (index)
- ontsnmp
 - (index)
- tr069serv
 - (index)
- bulk-sync
 - (index)
- protection-group
 - (index)
- ont-protection
 - (index)
- ont
 - (index)
- sfu-sup
 - (index)
- soho-sup
 - (index)
- mdu-sup
 - (index)
- ont-ani
 - (index)
- sfu-sup2
 - (index)
- soho-sup2
 - (index)
- mdu-sup2
 - (index)
- cfm
 - (index)
- eth-cfm
 - (index)
- rsvp
 - (index)
- eth-ring
 - (index)
- efm-oam
 - (index)
- ont-loopdetect
 - (index)
- ont-ploam
 - (index)
- sfu-ploam
 - (index)
- soho-ploam
 - (index)
- mdu-ploam
 - (index)

- ont-gen**
 - (index)
- sfu-gen**
 - (index)
- soho-gen**
 - (index)
- mdu-gen**
 - (index)
- ont-card**
 - (index)
- ont-pots**
 - (index)
- ont-lan**
 - (index)
- ont-tca**
 - (index)
- ont-tc-tca**
 - (index)
- ont-l2uni-eth-tca**
 - (index)
- olt-pon-tc-tca**
 - (index)
- olt-pon-util-tca**
 - (index)
- olt-chpr-util-tca**
 - (index)
- olt-ont-tc-tca**
 - (index)
- ont-pots-supplemental**
 - (index)
- ont-veip**
 - (index)
- ont-iphost**
 - (index)
- alarm-table**
 - (index)
- ont-video**
 - (index)
- ont-ces**
 - (index)
- ont-voip**
 - (index)
- ont-video-ani**
 - (index)
- ont-pwe**
 - (index)
- ont-cese1**
 - (index)
- ont-xdsl**
 - (index)
- ont-xdsl-tca**
 - (index)
- ont-hpna**
 - (index)
- ont-sip-agent-cfg**
 - (index)
- ont-voip-cfg**
 - (index)
- ont-mgc**

- (index)
- ont-moca**
 - (index)
- ont-moca-tca**
 - (index)
- auto-switch**
 - (index)
- ont-cfg-dld**
 - (index)
- olt-chpair-tc-tca**
 - (index)
- channel-pair**
 - (index)
- hgu-tr069**
 - (index)
- eqpt-psu**
 - (index)
- ethernet-ring**
 - (index)
- lldpmed**
 - (index)
- link-agg**
 - (index)
- fcs-exceed**
 - (index)

103.2 Alarm Snapshot Status Command

Command Description

This command displays the snapshot alarm entries.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

> show alarm snap-shot table [(index)]

Command Parameters

Table 103.2-1 "Alarm Snapshot Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm snap shot table index

Command Output

Table 103.2-2 "Alarm Snapshot Status Command" Display parameters

Common Information:general information		
name	Type	Description
timeout-period	Parameter type: <IgnoredTimeTicks> - a timeout value - unit: msec	specifies the time out of the snapshot table <i>This element is always shown.</i>
entries	Parameter type: <IgnoredGauge> - gauge	specifies nbr of entries in the snapshot table. <i>This element is always shown.</i>
indeterminate	Parameter type: <Alarm::IndetSevState> (active not-active) Possible values: - active : at least one entry of this severity is present - not-active : no entries of this severity	active indeterminate severity levels of the alarms in the snapshot table. <i>This element is always shown.</i>
warning	Parameter type: <Alarm::WarnSevState> (active not-active) Possible values: - active : at least one entry of this severity is present - not-active : no entries of this severity	active warning severity levels of the alarms in the snapshot table. <i>This element is always shown.</i>
minor	Parameter type: <Alarm::MinorSevState>	active minor severity levels of the

name	Type	Description
	(active not-active) Possible values: - active : at least one entry of this severity is present - not-active : no entries of this severity	alarms in the snapshot table. <i>This element is always shown.</i>
major	Parameter type: <Alarm::MajorSevState> (active not-active) Possible values: - active : at least one entry of this severity is present - not-active : no entries of this severity	active major severity levels of the alarms in the snapshot table. <i>This element is always shown.</i>
critical	Parameter type: <Alarm::CriticalSevState> (active not-active) Possible values: - active : at least one entry of this severity is present - not-active : no entries of this severity	active critical severity levels of the alarms in the snapshot table. <i>This element is always shown.</i>
owner-id	Parameter type: <Alarm::alarmSnapShotOwner> - string to identify the owner (example: Tom),the string should has less than or equal to 128 characters - length: 1<=x<=128	the actual owner of the snap-shot <i>This element is always shown.</i>

Specific Information		
name	Type	Description
type	Parameter type: <Alarm::alarmIHUBType> (equipment eqpt-holder plug-in-unit atm custom e1 ima-group ima-link redundancy shdsl ether-itf traffic-overflow qos-queue temporal spatial (software-mngt sw-mgmt) xdsl xdsl-ext xdsl-tca olt-gen eo-conv authentication bonding sfp shdsl-isam custom-ext-alarm plug-in-unit-ext sip-user-agent sip-plugin-unit sip-termination e1-sip-termination filetransfer external-device	unique id for an alarm. <i>This element is always shown.</i>

103 Alarm Snap-shot Status Commands

name	Type	Description
	l2forward	
	ether-tca	
	ether-sfp	
	megaco-media-gw	
	megaco-sig-gw	
	megaco-plug-unit	
	megaco-term	
	megaco-sig-lt	
	eqpt-supplemental	
	eqpt-holder-ext	
	lsmredundancy	
	sync	
	mcsrc	
	vlanport	
	vect-line	
	vect-board	
	otdr	
	sip-dial-plan	
	sip-vsp	
	sip-server	
	bgp	
	rip	
	lag	
	ihub-general	
	vprn	
	isis	
	ospf	
	ihub-l2forward	
	vpls	
	ihub-equip	
	ihub-link	
	eont-phyoam	
	ellid	
	epon	
	eont-services-lan	
	eolt-ont-tca	
	eont-sw-dl	
	ldp	
	mpls	
	sdp	
	epipe	
	ihub-ipv6	
	pim	
	li	
	mgmt-sec-access	
	bfd	
	ai	
	tr069serv	
	ontsnmp	
	bulk-sync	
	protection-group	
	ont	
	sfu-sup	
	soho-sup	
	mdu-sup	
	ont-ani	
	sfu-sup2	

name	Type	Description
	soho-sup2	
	mdu-sup2	
	sfprssi	
	eoltrssi	
	cfm	
	sfpe1t1-framer	
	sfpe1t1-clock	
	pppcc-engine-tca	
	eth-cfm	
	rsvp	
	ihub-tca	
	eth-ring	
	efm-oam	
	ont-loopdetect	
	ont-video	
	ont-ces	
	ont-voip	
	ont-video-ani	
	ont-pwe	
	ont-cese1	
	ont-xdsl	
	ont-xdsl-tca	
	ont-hpna	
	ont-sip-agent-cfg	
	ont-voip-cfg	
	ont-mgc	
	ont-ploam	
	ont-gen	
	ont-card	
	ont-pots	
	ont-lan	
	ont-moca	
	ont-tc-tca	
	ont-moca-tca	
	ont-l2uni-eth-tca	
	olt-pon-tc-tca	
	olt-pon-util-tca	
	olt-chpr-util-tca	
	olt-ont-tc-tca	
	ont-tca	
	ont-pots-supplemental	
	sfu-ploam	
	sfu-gen	
	soho-ploam	
	soho-gen	
	mdu-ploam	
	mdu-gen	
	ont-veip	
	ont-iphost	
	alarm-table	
	auto-switch	
	channel-pair	
	ont-cfg-dld	
	olt-chpair-tc-tca	
	hgu-tr069	
	eqpt-psu	
	ont-protection	

103 Alarm Snap-shot Status Commands

name	Type	Description
	secondary-megaco-term secondary-sip-term cas-r2-channel lldpmed pseudo-wire link-agg fcs-exceed e1t1-interface) Possible values: - equipment : equipment alarms - eqpt-holder : equipment holder alarms - plug-in-unit : plugin unit alarms - atm : ATM alarms - custom : customizable alarms - e1 : e1 alarms - ima-group : ima-group alarms - ima-link : ima-link alarms - redundancy : redundancy alarms - shdsl : shdsl alarms - ether-itf : ethernet interface alarms - traffic-overflow : Traffic overflow alarms - qos-queue : qos queue alarms - temporal : temporal alarms - spatial : spatial alarms - software-mngt : software management alarms - sw-mgmt : software management alarms - xdsl : xDSL alarms - xdsl-ext : other xDSL alarms - xdsl-tca : xDSL threshold cross alarms - olt-gen : OLT general alarms - eo-conv : E/O conversion related alarms - authentication : authentication related alarms - bonding : bonding-group related alarms - sfp : SFP related alarms - shdsl-isam : shdsl isam alarms - custom-ext-alarm : customizable external alarms - plug-in-unit-ext : other plugin unit alarms - sip-user-agent : sip user agent related alarms - sip-plugin-unit : sip plug in unit related alarms - sip-termination : sip termination related alarms - e1-sip-termination : E1 sip termination related alarms - filetransfer : file transfer server alarms - external-device : external device related alarms - l2forward : l2forward related alarms - ether-tca : ethernet threshold cross alarms - ether-sfp : ethernet SFP related alarms - megaco-media-gw : megaco media gateway related alarms - megaco-sig-gw : megaco signaling gateway related alarms - megaco-plug-unit : megaco plug unit related alarms - megaco-term : megaco termination related alarms - megaco-sig-lt : megaco signaling lt related alarms - eqpt-supplemental : equipment supplemental alarms - eqpt-holder-ext : other equipment holder alarms - lsmredundancy : lsm redundancy alarms - sync : synce and bits alarms - mcsrc : multicast source alarms - vlanport : vlanport alarms	

name	Type	Description
	- vect-line : xDSL vectoring line alarms - vect-board : xDSL vectoring board alarms - otdr : otdr alarms - sip-dial-plan : sip dial plan related alarms - sip-vsp : sip vsp related alarms - sip-server : sip server related alarms - bgp : bgp related alarms - rip : rip related alarms - lag : LAG related alarms - ihub-general : IHUB general related alarms - vprn : vprn related alarms - isis : isis related alarms - ospf : ospf related alarms - ihub-l2forward : ihub-l2forward alarms - vpls : vpls related alarms - ihub-equip : ihub-equip related alarms - ihub-link : ihub-link related alarms - eont-phyoam : eont phyoam related alarms - ellid : ellid related alarms - epon : epon related alarms - eont-services-lan : eon phyoam related alarms - eolt-ont-tca : eon phyoam related alarms - eont-sw-dl : eon phyoam related alarms - ldp : ldp related alarms - mpls : mpls related alarms - sdp : sdp related alarms - epipe : epipe related alarms - ihub-ipv6 : ihub-ipv6 related alarms - pim : pim related alarms - li : lawful intercept related alarms - mgmt-sec-access : management security related alarms - bfd : bfd related alarms - ai : Application Intelligence related alarms - tr069serv : tr069 server related alarms - ontsnmp : ont snmp related alarms - bulk-sync : bulk-sync related alarms - protection-group : port protection group related alarms - ont : ONT general supplemental related alarms - sfu-sup : SFU ONT general supplemental related alarms - soho-sup : SOHO ONT general supplemental related alarms - mdu-sup : MDU ONT general supplemental related alarms - ont-ani : ONT general supplemental 2 related alarms - sfu-sup2 : SFU ONT general supplemental 2 related alarms - soho-sup2 : SOHO ONT general supplemental 2 related alarms - mdu-sup2 : MDU ONT general supplemental 2 related alarms - sfprssi : SFP RSSI related alarms - eoltrssi : epon olt Sfp RSSI related alarms - cfm : Cfm related alarms - sfpe1t1-framer : SFP 2e1t1 framer alarms - sfpe1t1-clock : SFP 2e1t1 clock alarms - pppcc-engine-tca : PPPOE Cross Connect Engine TCA related alarm - eth-cfm : eth-cfm related alarms - rsvp : rsvp related alarms	

103 Alarm Snap-shot Status Commands

name	Type	Description
	- ihub-tca : IHUB TCA related alarms - eth-ring : eth-ring related alarms - efm-oam : EFM-OAM related alarms - ont-loopdetect : ont loop detect related alarms - ont-video : ont services video related alarms - ont-ces : ont services ces related alarms - ont-voip : ont services voip related alarms - ont-video-ani : ont services video ani related alarms - ont-pwe : ont services pwe related alarms - ont-cese1 : ont services cese1 related alarms - ont-xdsl : ont services xdsl related alarms - ont-xdsl-tca : ont services xdsl tca related alarms - ont-hpna : ont hpna related alarms - ont-sip-agent-cfg : ont services voip sip agent config related alarms - ont-voip-cfg : ont services voip config related alarms - ont-mgc : ont mgc related alarms - ont-ploam : ONT PLOAM related alarms - ont-gen : ONT GENERAL related alarms - ont-card : ONT Subscriber Card related alarms - ont-pots : ONT Services POTS related alarms - ont-lan : ONT Services LAN related alarms - ont-moca : ONT MoCA related alarms - ont-tc-tca : ONT TC TCA related alarms - ont-moca-tca : ONT MoCA TCA related alarms - ont-l2uni-eth-tca : ONT L2 UNI Ethernet TCA related alarms - olt-pon-tc-tca : OLT PON TC TCA related alarms - olt-pon-util-tca : OLT PON utilization TCA related alarms - olt-chpr-util-tca : OLT channel-pair utilization TCA related alarms - olt-ont-tc-tca : OLT ONT TC TCA related alarms - ont-tca : ONT TCA related alarms - ont-pots-supplemental : ONT POTS Supplemental related alarms - sfu-ploam : SFU ONT PLOAM related alarms - sfu-gen : SFU ONT general related alarms - soho-ploam : SOHO ONT PLOAM related alarms - soho-gen : SOHO ONT general related alarms - mdu-ploam : MDU ONT PLOAM related alarms - mdu-gen : MDU ONT general related alarms - ont-veip : ONT VEIP related alarms - ont-iphost : ONT IP HOST related alarms - alarm-table : alarm table related alarms - auto-switch : auto-switch related alarms - channel-pair : channel pair related alarms - ont-cfg-dld : ont configure file download related alarms - olt-chpair-tc-tca : OLT CHANNELPAIR TC TCA related alarms - hgu-tr069 : hgu tr069 related alarms - eqpt-psu : equipment psu alarms - ont-protection : ONT protection related alarms - secondary-megaco-term : secondary megaco termination related alarms - secondary-sip-term : secondary sip termination related alarms - cas-r2-channel : CAS R2 channel related alarms	

name	Type	Description
	- lldpmed : lldpmed alarms - pseudo-wire : pseudo Wire related alarms - link-agg : Link aggregation related alarms - fcs-exceed : FCS auto-recovery related alarms - e1t1-interface : E1/T1 physical interfaces related alarms	
last-updated-on	Parameter type: <Sys::timeInSecs> - the time (yyyy-mm-dd:hour:minutes:secs) - unit: UTC	network time in seconds when the alarm was logged. <i>This element is always shown.</i>

103.3 Alarm Snapshot Equipment Status Command

Command Description

This command displays the equipment snapshot.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

> show alarm snap-shot equipment [(index)]

Command Parameters

Table 103.3-1 "Alarm Snapshot Equipment Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm snap shot table index

Command Output

Table 103.3-2 "Alarm Snapshot Equipment Status Command" Display parameters

Specific Information		
name	Type	Description
persist-data	Parameter type: <Alarm::persistDataLoss> (lost not-lost) Possible values: - lost : persistant data is lost - not-lost : persistant data is not lost	current status specifying persistant data is lost or not <i>This element is only shown in detail mode.</i>
sntp-comm	Parameter type: <Alarm::sntpCommLoss> (lost not-lost) Possible values: - lost : SNTP communication lost - not-lost : SNTP communication is not lost	current status of sntp communication is lost or not <i>This element is only shown in detail mode.</i>
cf-error	Parameter type: <Alarm::cfError> ((error cfError) (no-error cfNoError)) Possible values: - error : CF access error - cfError : CF access error - no-error : CF no access error	Compact flash read or write error occurred <i>This element is only shown in detail mode.</i>

name	Type	Description
	- cfNoError : CF no access error	
board-with-cf-error	Parameter type: <Eqptm::EqptNtSlotIndexOrNone> (nt-a nt-b nt <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::EqSlotId> none none) Possible values: - nt-a : nt-a slot - nt-b : nt-b slot - nt : nt slot - none : board not specified - none : board not specified Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::EqSlotId> - the equipment slot number	Board identification with cf-error <i>This element is only shown in detail mode.</i>
nt-disk	Parameter type: <Alarm::ntDiskSpace> ((nintyfive-perc 95%-full) (less-nintyfive-perc less-than-95%)) Possible values: - nintyfive-perc : NT disk space is 95% full - 95%-full : NT disk space is 95% full - less-nintyfive-perc : NT disk space usage less that 95% - less-than-95% : NT disk space usage less that 95%	current status of nt disk space is 95% full or less than that <i>This element is only shown in detail mode.</i>
preferred-mode	Parameter type: <Alarm::clkPrefMode> (not-available available) Possible values: - not-available : Preferred timing mode is not available - available : Preferred Timing mode available	current status of preferred timing mode <i>This element is only shown in detail mode.</i>
timing-reference	Parameter type: <Alarm::clkFreeMode> (failed available) Possible values: - failed : System is in holdover or free-run mode - available : System is not in holdover or free-run mode	shows the availability or failure of timing reference <i>This element is only shown in detail mode.</i>
connection-lost	Parameter type: <Alarm::ShubLoc> (lost not-lost) Possible values: - lost : NT shub communication lost - not-lost : NT shub communication intact	current status of nt shub communication is lost or intact <i>This element is only shown in detail mode.</i>
back-pnl-inv short name: bpnl-inv	Parameter type: <Alarm::BackPnlInv> (invalid valid) Possible values: - invalid : BackPanel-type Invalid - valid : BackPanel-type Valid	current status of BackPanel-type Invalid alarm. <i>This element is only shown in detail mode.</i>
shub-conf-lost	Parameter type: <Alarm::SHubCfgLost> (lost not-lost) Possible values: - lost : SHub configuration loss - recent changes lost	actual shub configuration may differ from lanx database on nt <i>This element is only shown in detail mode.</i>

103 Alarm Snap-shot Status Commands

name	Type	Description
	- not-lost : SHub configuration up to date	

103.4 Equipment Holder Alarm Log Status Command

Command Description

This command displays the snapshot equipment holder alarm log status.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm snap-shot eqpt-holder [ (index) ]
```

Command Parameters

Table 103.4-1 "Equipment Holder Alarm Log Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm snap shot table index

Command Output

Table 103.4-2 "Equipment Holder Alarm Log Status Command" Display parameters

Specific Information		
name	Type	Description
shelf	Parameter type: <Equipm::Shelf> <Eqpt::RackId> / <Eqpt::ShelfId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number	specify which shelf the alarm occurred on. <i>This element is only shown in detail mode.</i>
rack-power	Parameter type: <Alarm::rackPower> (failing ok) Possible values: - failing : the fuse is broken - ok : the fuse is intact	current status of rack power alarm, indicating fuse is broken or intact <i>This element is only shown in detail mode.</i>
fan-unit1	Parameter type: <Alarm::fanUnit1> ((failing fail) ok) Possible values:	current status of fan-unit1 <i>This element is only shown in detail mode.</i>

103 Alarm Snap-shot Status Commands

name	Type	Description
	- failing : fan unit 1 is failing - fail : fan unit 1 is failing - ok : fan unit 1 is ok	
fan-unit2	Parameter type: <Alarm::fanUnit2> ((failing fail) ok) Possible values: - failing : fan unit 2 is failing - fail : fan unit 2 is failing - ok : fan unit 2 is ok	current status of fan-unit2 <i>This element is only shown in detail mode.</i>
shelf-type-mismatch	Parameter type: <Alarm::shelfTypeMismatch> (mismatch no-mismatch) Possible values: - mismatch : installed and planned shelf types are different - no-mismatch : installed and planned shelf types are the same	current status specifies installed and planned shelf types are different <i>This element is only shown in detail mode.</i>
ext-chain-instl	Parameter type: <Alarm::extChainInstl> ((consistency-problem inconsistent) (no-consistency-problem ok)) Possible values: - consistency-problem : consistency problem detected for installation of extension chain - inconsistent : consistency problem detected for installation of extension chain - no-consistency-problem: no consistency problem - ok : no consistency problem	current alarm status of consistency problem detected for installation of extension chain <i>This element is only shown in detail mode.</i>
shelf-missing	Parameter type: <Alarm::shelfMissing> (missing not-missing) Possible values: - missing : detected shelf now missing - not-missing : detected shelf was missing, now reinserted	current status specifies once inserted shelf has gone missing <i>This element is only shown in detail mode.</i>
shelf-install-missing	Parameter type: <Alarm::shelfInstall> (yes no) Possible values: - yes : shelf now installed - no : shelf now not installed	current status specifies shelf is planned but not installed <i>This element is only shown in detail mode.</i>
door	Parameter type: <Alarm::door> ((failing fail) ok) Possible values: - failing : the cabinet door is opened - fail : the cabinet door is opened - ok : the cabinet door is closed	current status of door alarm, indicating the cabinet door is opened <i>This element is only shown in detail mode.</i>
ac-power-fail	Parameter type: <Alarm::acPowerFail> ((failing fail) ok) Possible values: - failing : system AC power fails - fail : system AC power fails - ok : the system AC power works properly	current status of AC power failure alarm, indicating the AC Power is broken <i>This element is only shown in detail mode.</i>

103.5 Equipment Holder Alarm Extended Log Status Command

Command Description

This command displays the snapshot equipment holder extended alarm log status.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

> show alarm snap-shot eqpt-holder-ext [(index)]

Command Parameters

Table 103.5-1 "Equipment Holder Alarm Extended Log Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm snap shot table index

Command Output

Table 103.5-2 "Equipment Holder Alarm Extended Log Status Command" Display parameters

Specific Information		
name	Type	Description
shelf	Parameter type: <Equipm::Shelf> <Eqpt::RackId> / <Eqpt::ShelfId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number	specify which shelf the alarm occurred on. <i>This element is only shown in detail mode.</i>
ctl-com-fail	Parameter type: <Alarm::ctlComFail> ((failing fail) ok) Possible values: - failing : shelf controller communication is failing - fail : shelf controller communication is failing - ok : shelf controller communication is ok	status of shelf controller communication failure. <i>This element is only shown in detail mode.</i>
bat-a-fail	Parameter type: <Alarm::batAFail> (yes no)	status of shelf power source A failure. <i>This element is only shown in</i>

103 Alarm Snap-shot Status Commands

name	Type	Description
	Possible values: - yes : Power Source Battery A Failure - no : Power Source Battery A is OK	<i>detail mode.</i>
bat-b-fail	Parameter type: <Alarm::batBFail> (yes no) Possible values: - yes : Power Source Battery B Failure - no : bfd stale entry not present	status of shelf power source B failure. <i>This element is only shown in detail mode.</i>
water-seepage-in-box	Parameter type: <Alarm::waterSeepageInBox> (detected not-detected) Possible values: - detected : detected water seepage in the enclosure - not-detected : no water seepage detected in the enclosure	status of detected water seepage in the enclosure <i>This element is only shown in detail mode.</i>
sealed-box-open	Parameter type: <Alarm::sealedBoxOpen> (detected not-detected) Possible values: - detected : detected open sealed box - not-detected : closed sealed box	status of detected open sealed box <i>This element is only shown in detail mode.</i>

103.6 Plug-in Unit Alarm Log Status Command

Command Description

This command displays the snapshot plug-in unit alarm log status.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

> show alarm snap-shot plug-in-unit [(index)]

Command Parameters

Table 103.6-1 "Plug-in Unit Alarm Log Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm snap shot table index

Command Output

Table 103.6-2 "Plug-in Unit Alarm Log Status Command" Display parameters

Specific Information		
name	Type	Description
board-position	Parameter type: <Equipm::SlotIndex> (lt : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> nt-a nt-b nt acu : <Eqpt::RackId> / <Eqpt::ShelfId> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::EqSlotId> ext-a : <Eqpt::RackId> / <Eqpt::ShelfId> ext-b : <Eqpt::RackId> / <Eqpt::ShelfId> ctrl : <Eqpt::RackId> / <Eqpt::ShelfId> vlt : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::VirtualSlotId>) Possible values: - lt : lt-slot - vlt : virtual LT slot (VVPS board can only be planned at NANT-E / FANT-F) - nt-a : nt-a slot - nt-b : nt-b slot - nt : nt slot - ext-a : nt-a slot in an extension shelf	identify where the alarm has occurred. <i>This element is only shown in detail mode.</i>

103 Alarm Snap-shot Status Commands

name	Type	Description
	- ext-b : nt-b slot in an extension shelf - acu : acu slot - ctrl : ctrl-slot Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::VirtualSlotId> - the virtual LT slot number Field type <Eqpt::EqSlotId> - the equipment slot number	
board-mismatch	Parameter type: <Alarm::boardMismatch> (yes no) Possible values: - yes : planned and plugged-in types are different - no : planned and plugged-in types are same	alarm specifying the planned and plugged-in types are different <i>This element is only shown in detail mode.</i>
sw-download	Parameter type: <Alarm::swStatus> (waiting completed) Possible values: - waiting : not able to download all the applicable SW files - completed : download completed	alarm specifying download of the software is completed or not. <i>This element is only shown in detail mode.</i>
temperature	Parameter type: <Alarm::tempStatus> (above-thres below-thres) Possible values: - above-thres : temperature threshold on board exceeded - below-thres : board temperature within threshold	alarm specifying board temperature is crossed the threshold or not. <i>This element is only shown in detail mode.</i>
temp-shutoff	Parameter type: <Alarm::tempShutoffStatus> (board-switched-off board-switched-on) Possible values: - board-switched-off : board switched off - excess temperature - board-switched-on : board switched on	alarm specifying board is switched off because of excess temperature. <i>This element is only shown in detail mode.</i>
sem-power-fail	Parameter type: <Alarm::extPowerStatus> (sem-power-fail sem-power-ok) Possible values: - sem-power-fail : SEM external power failure - sem-power-ok : SEM external power ok	alarm specifying SEM external power failure. <i>This element is only shown in detail mode.</i>
sem-ups-fail	Parameter type: <Alarm::powerSupplyStatus> (sem-ups-fail sem-ups-ok) Possible values: - sem-ups-fail : SEM external power supply failure - sem-ups-ok : SEM external power supply ok	alarm specifying SEM external power supply failure. <i>This element is only shown in detail mode.</i>
board-present	Parameter type: <Alarm::boardPresence> (missing yes) Possible values: - missing : board was present, but now missing - yes : board present	indicates the presence of the board. <i>This element is only shown in detail mode.</i>
board-inserted	Parameter type: <Alarm::boardInsertion>	indicates the status of board was

name	Type	Description
	(never-inserted inserted) Possible values: - never-inserted : board was never inserted - inserted : board was inserted	inserted or not. <i>This element is only shown in detail mode.</i>
board-init	Parameter type: <Alarm::boardInit> (failed completed) Possible values: - failed : board initialization failed - completed : board initialization completed	specifies board initializaion is sucessful or failed. <i>This element is only shown in detail mode.</i>
board-reset-cf	Parameter type: <Alarm::boardResetCommFail> (yes ok) Possible values: - yes : board reset/communication failure occurred - ok : no board reset/communication failure	indicates there has been a reset and/or communication failure of the board. <i>This element is only shown in detail mode.</i>
shub-uplink	Parameter type: <Alarm::lanxuplinkbrkdwn> (failure ok) Possible values: - failure : lanx uplink breakdown or removal - ok : no breakdown or removal of lanx uplink	indicates that lanx uplink breakdown or removal. <i>This element is only shown in detail mode.</i>
backplane-data-failure	Parameter type: <Alarm::BackplaneMismatch> (yes no) Possible values: - yes : LT backplane ports data failure - no : LT backplane ports data normal	indicates the lt backplane data status <i>This element is only shown in detail mode.</i>

103.7 ATM Alarm Log Status Command

Command Description

This command displays the ATM alarm log status.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm snap-shot atm [ (index) ]
```

Command Parameters

Table 103.7-1 "ATM Alarm Log Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm snap shot table index

Command Output

Table 103.7-2 "ATM Alarm Log Status Command" Display parameters

Specific Information		
name	Type	Description
port	Parameter type: <Equipm::AtmIndex> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number	identify where the alarm has occurred. <i>This element is only shown in detail mode.</i>
vpi-vci	Parameter type: <Alarm::VpiVciValues> - the vpi and vci value (vpi/vci)	identify where the alarm has occurred. <i>This element is only shown in detail mode.</i>
cell-discard-up	Parameter type: <Alarm::CellDiscardUpstream> (discarded no-discard) Possible values:	specifies ATM cell is discarded or not in upstream direction. <i>This element is only shown in detail mode.</i>

name	Type	Description
	- discarded : ATM cell discarded in upstream direction - no-discard : no ATM cell discarded in upstream direction	
cell-discard-down	Parameter type: <Alarm::CellDiscardDownstream> (discarded no-discard) Possible values: - discarded : ATM cell discarded in downstream direction - no-discard : no ATM cell discarded in downstream direction	specifies ATM cell is discarded or not in downstream direction. <i>This element is only shown in detail mode.</i>

103.8 Alarm Snapshot Ethernet Interface Status Command

Command Description

This command displays the current Ethernet interface alarm status.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

> show alarm snap-shot ether-itf [(index)]

Command Parameters

Table 103.8-1 "Alarm Snapshot Ethernet Interface Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm snap shot table index

Command Output

Table 103.8-2 "Alarm Snapshot Ethernet Interface Status Command" Display parameters

Specific Information		
name	Type	Description
ether-ifindex	Parameter type: <Ether::InterfaceIndex> - index of the collision interface - range: [0...2147483647]	identify where the alarm has occurred. <i>This element is only shown in detail mode.</i>

103.9 Alarm Snapshot Software Management Status Command

Command Description

This command displays the snapshot software management status.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm snap-shot sw-mgmt [ (index) ]
```

Command Parameters

Table 103.9-1 "Alarm Snapshot Software Management Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm snap shot table index

Command Output

Table 103.9-2 "Alarm Snapshot Software Management Status Command" Display parameters

Specific Information		
name	Type	Description
board-position	Parameter type: <Equipm::SlotIndex> (lt : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> nt-a nt-b nt acu : <Eqpt::RackId> / <Eqpt::ShelfId> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::EqSlotId> ext-a : <Eqpt::RackId> / <Eqpt::ShelfId> ext-b : <Eqpt::RackId> / <Eqpt::ShelfId> ctrl : <Eqpt::RackId> / <Eqpt::ShelfId> vlt : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::VirtualSlotId>) Possible values: - lt : lt-slot - vlt : virtual LT slot (VVPS board can only be planned at NANT-E / FANT-F)	identifies the physical position of the slot <i>This element is only shown in detail mode.</i>

103 Alarm Snap-shot Status Commands

name	Type	Description
	- nt-a : nt-a slot - nt-b : nt-b slot - nt : nt slot - ext-a : nt-a slot in an extension shelf - ext-b : nt-b slot in an extension shelf - acu : acu slot - ctrl : ctrl-slot Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::VirtualSlotId> - the virtual LT slot number Field type <Eqpt::EqSlotId> - the equipment slot number	
sw-rollback	Parameter type: <Alarm::SwRollback> (yes no) Possible values: - yes : implicit software rollback performed - no : no implicit software rollback	specifies implicit software rollback is performed or not. <i>This element is only shown in detail mode.</i>
db-rollback	Parameter type: <Alarm::DbRollback> (yes no) Possible values: - yes : implicit database rollback performed - no : no implicit database rollback	specifies implicit database rollback is performed or not. <i>This element is only shown in detail mode.</i>
xvps-inv-dbase	Parameter type: <Alarm::XvpsInvalidDataBase> (invalid valid) Possible values: - invalid : invalid xvps dbbase is detected - valid : xvps dbase is valid	specifies implicit xvps dbase is valid or not. <i>This element is only shown in detail mode.</i>
inv-cde-file	Parameter type: <Alarm::XvpsInvalidCDEFile> (invalid valid) Possible values: - invalid : invalid xvps cde file is detected - valid : xvps cde file is valid	specifies implicit xvps dbase is valid or not. <i>This element is only shown in detail mode.</i>
miss-cde-file	Parameter type: <Alarm::MissingCDEProfile> (yes no) Possible values: - yes : cde profile is missed - no : cde profile is exist	specifies cde profile is missed or not. <i>This element is only shown in detail mode.</i>

103.10 Alarm Snapshot Temporal Filter Status Command

Command Description

This command displays the temporal filter snapshot.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

> show alarm snap-shot temporal [(index)]

Command Parameters

Table 103.10-1 "Alarm Snapshot Temporal Filter Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm snap shot table index

Command Output

Table 103.10-2 "Alarm Snapshot Temporal Filter Status Command" Display parameters

Specific Information		
name	Type	Description
tmp-filter1	Parameter type: <Alarm::almFilter1> (yes no) Possible values: - yes : derived filter1 alarm - no : not derived filter1 alarm	current status of temporal filter1 is derived or not <i>This element is only shown in detail mode.</i>
tmp-filter2	Parameter type: <Alarm::almFilter2> (yes no) Possible values: - yes : derived filter2 alarm - no : not derived filter2 alarm	current status of temporal filter2 is derived or not <i>This element is only shown in detail mode.</i>
tmp-filter3	Parameter type: <Alarm::almFilter3> (yes no) Possible values:	current status of temporal filter3 is derived or not <i>This element is only shown in detail mode.</i>

103 Alarm Snap-shot Status Commands

name	Type	Description
	- yes : derived filter3 alarm - no : not derived filter3 alarm	
tmp-filter4	Parameter type: <Alarm::alrmFilter4> (yes no) Possible values: - yes : derived filter4 alarm - no : not derived filter4 alarm	current status of temporal filter4 is derived or not <i>This element is only shown in detail mode.</i>
tmp-filter5	Parameter type: <Alarm::alrmFilter5> (yes no) Possible values: - yes : derived filter5 alarm - no : not derived filter5 alarm	current status of temporal filter5 is derived or not <i>This element is only shown in detail mode.</i>
tmp-filter6	Parameter type: <Alarm::alrmFilter6> (yes no) Possible values: - yes : derived filter6 alarm - no : not derived filter6 alarm	current status of temporal filter6 is derived or not <i>This element is only shown in detail mode.</i>
tmp-filter7	Parameter type: <Alarm::alrmFilter7> (yes no) Possible values: - yes : derived filter7 alarm - no : not derived filter7 alarm	current status of temporal filter7 is derived or not <i>This element is only shown in detail mode.</i>
tmp-filter8	Parameter type: <Alarm::alrmFilter8> (yes no) Possible values: - yes : derived filter alarm - no : not derived filter alarm	current status of temporal filter8 is derived or not <i>This element is only shown in detail mode.</i>
tmp-filter9	Parameter type: <Alarm::alrmFilter9> (yes no) Possible values: - yes : derived filter9 alarm - no : not derived filter9 alarm	current status of temporal filter9 is derived or not <i>This element is only shown in detail mode.</i>
tmp-filter10	Parameter type: <Alarm::alrmFilter10> (yes no) Possible values: - yes : derived filter10 alarm - no : not derived filter alarm	current status of temporal filter10 is derived or not <i>This element is only shown in detail mode.</i>
tmp-filter11	Parameter type: <Alarm::alrmFilter11> (yes no) Possible values: - yes : derived filter11 alarm - no : not derived filter11 alarm	current status of temporal filter11 is derived or not <i>This element is only shown in detail mode.</i>
tmp-filter12	Parameter type: <Alarm::alrmFilter12> (yes no) Possible values: - yes : derived filter12 alarm - no : not derived filter12 alarm	current status of temporal filter12 is derived or not <i>This element is only shown in detail mode.</i>
tmp-filter13	Parameter type: <Alarm::alrmFilter13>	current status of temporal filter13

name	Type	Description
	(yes no) Possible values: - yes : derived filter13 alarm - no : not derived filter13 alarm	is derived or not <i>This element is only shown in detail mode.</i>
tmp-filter14	Parameter type: <Alarm::almFilter14> (yes no) Possible values: - yes : derived filter14 alarm - no : not derived filter14 alarm	current status of temporal filter14 is derived or not <i>This element is only shown in detail mode.</i>
tmp-filter15	Parameter type: <Alarm::almFilter15> (yes no) Possible values: - yes : derived filter15 alarm - no : not derived filter15 alarm	current status of temporal filter15 is derived or not <i>This element is only shown in detail mode.</i>
tmp-filter16	Parameter type: <Alarm::almFilter16> (yes no) Possible values: - yes : derived filter16 alarm - no : not derived filter16 alarm	current status of temporal filter16 is derived or not <i>This element is only shown in detail mode.</i>
tmp-filter17	Parameter type: <Alarm::almFilter17> (yes no) Possible values: - yes : derived filter17 alarm - no : not derived filter17 alarm	current status of temporal filter17 is derived or not <i>This element is only shown in detail mode.</i>
tmp-filter18	Parameter type: <Alarm::almFilter18> (yes no) Possible values: - yes : derived filter18 alarm - no : not derived filter18 alarm	current status of temporal filter18 is derived or not <i>This element is only shown in detail mode.</i>
tmp-filter19	Parameter type: <Alarm::almFilter19> (yes no) Possible values: - yes : derived filter19 alarm - no : not derived filter19 alarm	current status of temporal filter19 is derived or not <i>This element is only shown in detail mode.</i>
tmp-filter20	Parameter type: <Alarm::almFilter20> (yes no) Possible values: - yes : derived filter20 alarm - no : not derived filter20 alarm	current status of temporal filter20 is derived or not <i>This element is only shown in detail mode.</i>
tmp-filter21	Parameter type: <Alarm::almFilter21> (yes no) Possible values: - yes : derived filter21 alarm - no : not derived filter21 alarm	current status of temporal filter21 is derived or not <i>This element is only shown in detail mode.</i>
tmp-filter22	Parameter type: <Alarm::almFilter22> (yes no) Possible values:	current status of temporal filter22 is derived or not <i>This element is only shown in detail mode.</i>

103 Alarm Snap-shot Status Commands

name	Type	Description
	- yes : derived filter22 alarm - no : not derived filter22 alarm	
tmp-filter23	Parameter type: <Alarm::alrmFilter23> (yes no) Possible values: - yes : derived filter23 alarm - no : not derived filter23 alarm	current status of temporal filter23 is derived or not <i>This element is only shown in detail mode.</i>
tmp-filter24	Parameter type: <Alarm::alrmFilter24> (yes no) Possible values: - yes : derived filter24 alarm - no : not derived filter24 alarm	current status of temporal filter24 is derived or not <i>This element is only shown in detail mode.</i>
tmp-filter25	Parameter type: <Alarm::alrmFilter25> (yes no) Possible values: - yes : derived filter25 alarm - no : not derived filter25 alarm	current status of temporal filter25 is derived or not <i>This element is only shown in detail mode.</i>
tmp-filter26	Parameter type: <Alarm::alrmFilter26> (yes no) Possible values: - yes : derived filter26 alarm - no : not derived filter26 alarm	current status of temporal filter26 is derived or not <i>This element is only shown in detail mode.</i>
tmp-filter27	Parameter type: <Alarm::alrmFilter27> (yes no) Possible values: - yes : derived filter27 alarm - no : not derived filter27 alarm	current status of temporal filter27 is derived or not <i>This element is only shown in detail mode.</i>
tmp-filter28	Parameter type: <Alarm::alrmFilter28> (yes no) Possible values: - yes : derived filter28 alarm - no : not derived filter28 alarm	current status of temporal filter28 is derived or not <i>This element is only shown in detail mode.</i>
tmp-filter29	Parameter type: <Alarm::alrmFilter29> (yes no) Possible values: - yes : derived filter29 alarm - no : not derived filter29 alarm	current status of temporal filter29 is derived or not <i>This element is only shown in detail mode.</i>
tmp-filter30	Parameter type: <Alarm::alrmFilter30> (yes no) Possible values: - yes : derived filter30 alarm - no : not derived filter30 alarm	current status of temporal filter30 is derived or not <i>This element is only shown in detail mode.</i>
tmp-filter31	Parameter type: <Alarm::alrmFilter31> (yes no) Possible values: - yes : derived filter31 alarm - no : not derived filter31 alarm	current status of temporal filter31 is derived or not <i>This element is only shown in detail mode.</i>

103.11 Alarm Snapshot Spatial Filter Status Command

Command Description

This command displays the spatial filter snapshot.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

> show alarm snap-shot spatial [(index)]

Command Parameters

Table 103.11-1 "Alarm Snapshot Spatial Filter Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm snap shot table index

Command Output

Table 103.11-2 "Alarm Snapshot Spatial Filter Status Command" Display parameters

Specific Information		
name	Type	Description
spa-filter1	Parameter type: <Alarm::almFilter1> (yes no) Possible values: - yes : derived filter1 alarm - no : not derived filter1 alarm	current status of spatial filter1 is derived or not <i>This element is only shown in detail mode.</i>
spa-filter2	Parameter type: <Alarm::almFilter2> (yes no) Possible values: - yes : derived filter2 alarm - no : not derived filter2 alarm	current status of spatial filter2 is derived or not <i>This element is only shown in detail mode.</i>
spa-filter3	Parameter type: <Alarm::almFilter3> (yes no) Possible values:	current status of spatial filter3 is derived or not <i>This element is only shown in detail mode.</i>

103 Alarm Snap-shot Status Commands

name	Type	Description
	- yes : derived filter3 alarm - no : not derived filter3 alarm	
spa-filter4	Parameter type: <Alarm::alrmFilter4> (yes no) Possible values: - yes : derived filter4 alarm - no : not derived filter4 alarm	current status of spatial filter4 is derived or not <i>This element is only shown in detail mode.</i>
spa-filter5	Parameter type: <Alarm::alrmFilter5> (yes no) Possible values: - yes : derived filter5 alarm - no : not derived filter5 alarm	current status of spatial filter5 is derived or not <i>This element is only shown in detail mode.</i>
spa-filter6	Parameter type: <Alarm::alrmFilter6> (yes no) Possible values: - yes : derived filter6 alarm - no : not derived filter6 alarm	current status of spatial filter6 is derived or not <i>This element is only shown in detail mode.</i>
spa-filter7	Parameter type: <Alarm::alrmFilter7> (yes no) Possible values: - yes : derived filter7 alarm - no : not derived filter7 alarm	current status of spatial filter7 is derived or not <i>This element is only shown in detail mode.</i>
spa-filter8	Parameter type: <Alarm::alrmFilter8> (yes no) Possible values: - yes : derived filter alarm - no : not derived filter alarm	current status of spatial filter8 is derived or not <i>This element is only shown in detail mode.</i>
spa-filter9	Parameter type: <Alarm::alrmFilter9> (yes no) Possible values: - yes : derived filter9 alarm - no : not derived filter9 alarm	current status of spatial filter9 is derived or not <i>This element is only shown in detail mode.</i>
spa-filter10	Parameter type: <Alarm::alrmFilter10> (yes no) Possible values: - yes : derived filter10 alarm - no : not derived filter alarm	current status of spatial filter10 is derived or not <i>This element is only shown in detail mode.</i>
spa-filter11	Parameter type: <Alarm::alrmFilter11> (yes no) Possible values: - yes : derived filter11 alarm - no : not derived filter11 alarm	current status of spatial filter11 is derived or not <i>This element is only shown in detail mode.</i>
spa-filter12	Parameter type: <Alarm::alrmFilter12> (yes no) Possible values: - yes : derived filter12 alarm - no : not derived filter12 alarm	current status of spatial filter12 is derived or not <i>This element is only shown in detail mode.</i>
spa-filter13	Parameter type: <Alarm::alrmFilter13>	current status of spatial filter13 is

name	Type	Description
	(yes no) Possible values: - yes : derived filter13 alarm - no : not derived filter13 alarm	derived or not <i>This element is only shown in detail mode.</i>
spa-filter14	Parameter type: <Alarm::almFilter14> (yes no) Possible values: - yes : derived filter14 alarm - no : not derived filter14 alarm	current status of spatial filter14 is derived or not <i>This element is only shown in detail mode.</i>
spa-filter15	Parameter type: <Alarm::almFilter15> (yes no) Possible values: - yes : derived filter15 alarm - no : not derived filter15 alarm	current status of spatial filter15 is derived or not <i>This element is only shown in detail mode.</i>
spa-filter16	Parameter type: <Alarm::almFilter16> (yes no) Possible values: - yes : derived filter16 alarm - no : not derived filter16 alarm	current status of spatial filter16 is derived or not <i>This element is only shown in detail mode.</i>
spa-filter17	Parameter type: <Alarm::almFilter17> (yes no) Possible values: - yes : derived filter17 alarm - no : not derived filter17 alarm	current status of spatial filter17 is derived or not <i>This element is only shown in detail mode.</i>
spa-filter18	Parameter type: <Alarm::almFilter18> (yes no) Possible values: - yes : derived filter18 alarm - no : not derived filter18 alarm	current status of spatial filter18 is derived or not <i>This element is only shown in detail mode.</i>
spa-filter19	Parameter type: <Alarm::almFilter19> (yes no) Possible values: - yes : derived filter19 alarm - no : not derived filter19 alarm	current status of spatial filter19 is derived or not <i>This element is only shown in detail mode.</i>
spa-filter20	Parameter type: <Alarm::almFilter20> (yes no) Possible values: - yes : derived filter20 alarm - no : not derived filter20 alarm	current status of spatial filter20 is derived or not <i>This element is only shown in detail mode.</i>
spa-filter21	Parameter type: <Alarm::almFilter21> (yes no) Possible values: - yes : derived filter21 alarm - no : not derived filter21 alarm	current status of spatial filter21 is derived or not <i>This element is only shown in detail mode.</i>
spa-filter22	Parameter type: <Alarm::almFilter22> (yes no) Possible values:	current status of spatial filter22 is derived or not <i>This element is only shown in detail mode.</i>

103 Alarm Snap-shot Status Commands

name	Type	Description
	- yes : derived filter22 alarm - no : not derived filter22 alarm	
spa-filter23	Parameter type: <Alarm::alrmFilter23> (yes no) Possible values: - yes : derived filter23 alarm - no : not derived filter23 alarm	current status of spatial filter23 is derived or not <i>This element is only shown in detail mode.</i>
spa-filter24	Parameter type: <Alarm::alrmFilter24> (yes no) Possible values: - yes : derived filter24 alarm - no : not derived filter24 alarm	current status of spatial filter24 is derived or not <i>This element is only shown in detail mode.</i>
spa-filter25	Parameter type: <Alarm::alrmFilter25> (yes no) Possible values: - yes : derived filter25 alarm - no : not derived filter25 alarm	current status of spatial filter25 is derived or not <i>This element is only shown in detail mode.</i>
spa-filter26	Parameter type: <Alarm::alrmFilter26> (yes no) Possible values: - yes : derived filter26 alarm - no : not derived filter26 alarm	current status of spatial filter26 is derived or not <i>This element is only shown in detail mode.</i>
spa-filter27	Parameter type: <Alarm::alrmFilter27> (yes no) Possible values: - yes : derived filter27 alarm - no : not derived filter27 alarm	current status of spatial filter27 is derived or not <i>This element is only shown in detail mode.</i>
spa-filter28	Parameter type: <Alarm::alrmFilter28> (yes no) Possible values: - yes : derived filter28 alarm - no : not derived filter28 alarm	current status of spatial filter28 is derived or not <i>This element is only shown in detail mode.</i>
spa-filter29	Parameter type: <Alarm::alrmFilter29> (yes no) Possible values: - yes : derived filter29 alarm - no : not derived filter29 alarm	current status of spatial filter29 is derived or not <i>This element is only shown in detail mode.</i>
spa-filter30	Parameter type: <Alarm::alrmFilter30> (yes no) Possible values: - yes : derived filter30 alarm - no : not derived filter30 alarm	current status of spatial filter30 is derived or not <i>This element is only shown in detail mode.</i>
spa-filter31	Parameter type: <Alarm::alrmFilter31> (yes no) Possible values: - yes : derived filter31 alarm - no : not derived filter31 alarm	current status of spatial filter31 is derived or not <i>This element is only shown in detail mode.</i>

103.12 Alarm xDSL Snapshot Status Command

Command Description

This command displays the status of the snapshot xDSL alarm.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

> show alarm snap-shot xdsl [(index)]

Command Parameters

Table 103.12-1 "Alarm xDSL Snapshot Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm snap shot table index

Command Output

Table 103.12-2 "Alarm xDSL Snapshot Status Command" Display parameters

Specific Information		
name	Type	Description
port	Parameter type: <Itf::XdslLine> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number	identifies the physical position of the port <i>This element is only shown in detail mode.</i>
near-end-los	Parameter type: <Alarm::NearEndLOS> (yes no) Possible values: - yes : near end loss of signal occurred - no : no near end loss of signal	specifies near end loss of signal occurred or not. <i>This element is only shown in detail mode.</i>
near-end-lof	Parameter type: <Alarm::NearEndLOF> (yes	specifies near end loss of frame occurred or not.

103 Alarm Snap-shot Status Commands

name	Type	Description
	no) Possible values: - yes : near end loss of frame occurred - no : no near end loss of frame	<i>This element is only shown in detail mode.</i>
near-end-lom	Parameter type: <Alarm::NearEndLOM> (yes no) Possible values: - yes : near end loss of margin occurred - no : no near end loss of margin	specifies near end loss of margin occurred or not. <i>This element is only shown in detail mode.</i>
near-end-ese	Parameter type: <Alarm::NearEndESE> (yes no) Possible values: - yes : near end excessive severe errors occurred - no : no near end excessive severe errors occurred	specifies near end excessive severe errors occurred or not. <i>This element is only shown in detail mode.</i>
line-config	Parameter type: <Alarm::LineConfig> (config-error config-ok) Possible values: - config-error : line configuration data cannot be used - config-ok : Line configuration data OK	specifies whether line configuration data is used or not. <i>This element is only shown in detail mode.</i>
line-capacity	Parameter type: <Alarm::LineCapacity> (below-requirement meets-requirement) Possible values: - below-requirement : line capacity not enough to set up requested profile - meets-requirement : line capacity enough to set up requested profile	specifies whether line capacity is set up or not. <i>This element is only shown in detail mode.</i>
near-end-bitrate	Parameter type: <Alarm::NearEndBRthres> (below-plan meets-plan) Possible values: - below-plan : upstream planned bitrate not reached after initialization - meets-plan : upstream planned bitrate reached	specifies whether upstream planned bitrate reached or not after initialization. <i>This element is only shown in detail mode.</i>
near-end-ncd	Parameter type: <Alarm::NearEndNCD> (no-cell-deline cell-deline-occurred) Possible values: - no-cell-deline : no near end cell delineation - cell-deline-occurred : near end cell delineation occurred	specifies whether near end cell delineation is occurred or not. <i>This element is only shown in detail mode.</i>
near-end-lcd	Parameter type: <Alarm::NearEndLCD> (yes no) Possible values: - yes : loss of near end cell deliniation - no : no loss of near end cell deliniation	specifies whether loss of near end cell deliniation is occurred or not. <i>This element is only shown in detail mode.</i>
far-end-los	Parameter type: <Alarm::FarEndLOS> (yes no) Possible values: - yes : far end loss of signal occurred - no : no far end loss of signal	specifies whether far end loss of signal occurred or not. <i>This element is only shown in detail mode.</i>
far-end-lof	Parameter type: <Alarm::FarEndLOF> (yes	specifies whether far end loss of frame occurred or not.

name	Type	Description
	no) Possible values: - yes : far end loss of frame occurred - no : no far end loss of frame	<i>This element is only shown in detail mode.</i>
far-end-lpr	Parameter type: <Alarm::FarEndLPR> (yes no) Possible values: - yes : far end loss of power detected - no : no far end loss of power	specifies whether far end loss of power detected or not. <i>This element is only shown in detail mode.</i>
far-end-lol	Parameter type: <Alarm::FarEndLOL> (yes no) Possible values: - yes : far end loss of link detected - no : no far end loss of link	specifies whether far end loss of link detected or not. <i>This element is only shown in detail mode.</i>
far-end-lom	Parameter type: <Alarm::FarEndLOM> (yes no) Possible values: - yes : far end loss of margin occurred - no : no far end loss of margin	specifies whether far end loss of margin occurred or not. <i>This element is only shown in detail mode.</i>
far-end-ese	Parameter type: <Alarm::FarEndESE> (yes no) Possible values: - yes : far end excessive severe errors occurred - no : no far end excessive severe errors occurred	specifies whether far end excessive severe errors occurred or not. <i>This element is only shown in detail mode.</i>
xdsl-init	Parameter type: <Alarm::Initialization> (failed successful) Possible values: - failed : initialization unsuccessful due to communication problem - successful : initialization successful	specifies xdsl line initialization is successful or not. <i>This element is only shown in detail mode.</i>
peer-modem	Parameter type: <Alarm::PeerModem> (no yes) Possible values: - no : no peer modem detected - yes : peer modem detected	specifies whether peer modem detected or not. <i>This element is only shown in detail mode.</i>
far-end-bitrate	Parameter type: <Alarm::FarEndBRthres> (below-plan meets-plan) Possible values: - below-plan : downstream planned bitrate not reached after initialization - meets-plan : downstream planned bitrate reached	specifies whether downstream planned bitrate reached or not. <i>This element is only shown in detail mode.</i>
far-end-ncd	Parameter type: <Alarm::FarEndNCD> (no-cell-deline cell-deline-occurred) Possible values: - no-cell-deline : no far end cell delineation - cell-deline-occurred : far end cell delineation occurred	specifies whether far end cell delineation occurred or not. <i>This element is only shown in detail mode.</i>
far-end-lcd	Parameter type: <Alarm::FarEndLCD> (yes no)	specifies there is loss of far end cell deliniation or not. <i>This element is only shown in</i>

103 Alarm Snap-shot Status Commands

name	Type	Description
	Possible values: - yes : loss of far end cell deliniation - no : no loss of far end cell deliniation	<i>detail mode.</i>
far-end-upbo-vio	Parameter type: <Alarm::FarEndUPBO> (yes no) Possible values: - yes : UPBO violation - no : no UPBO violation	UPBO violation <i>This element is only shown in detail mode.</i>
far-end-cpe-pol	Parameter type: <Alarm::FarEndActFail> (yes no) Possible values: - yes : activation failure due to CPE policing - no : no activation failure due to CPE policing	activation failure due to CPE policing <i>This element is only shown in detail mode.</i>
far-end-mis-peer-35b	Parameter type: <Alarm::FarEndMismatchPeer35B> (yes no) Possible values: - yes : VDSL2 35b opmode mismatch between XTU-C and XTU-R - no : No VDSL2 35b opmode mismatch between XTU-C and XTU-R	VDSL2 35b opmode mismatch between XTU-C and XTU-R. <i>This element is only shown in detail mode.</i>
forced-rtx-init	Parameter type: <Alarm::ForcedRtxInit> (failed successful) Possible values: - failed : initialization unsuccessful due to forced retransmission - successful : initialization successful	specifies forced rtx initialization is successful or not <i>This element is only shown in detail mode.</i>
tpstc-mis	Parameter type: <Alarm::TpstcMis> (yes no) Possible values: - yes : mismatch between the configured tps-tc mode and the mode supported by the connected cpe - no : no mismatch between the configured and the tpstc mode supported by connected cpe	mismatch between the configured tps-tc mode and the mode supported by the connected cpe <i>This element is only shown in detail mode.</i>
vect-dle	Parameter type: <Alarm::NearEndVectDle> (yes no) Possible values: - yes : loss of us signal due to disorderly leaving event - no : no disorderly leaving detected	specifies whether a disorderly leaving event occurred or not. <i>This element is only shown in detail mode.</i>

103.13 TCA xDSL Alarm Log Status Command

Command Description

This command displays the xDSL threshold cross alarm log status.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm snap-shot xdsl-tca [ (index) ]
```

Command Parameters

Table 103.13-1 "TCA xDSL Alarm Log Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm snap shot table index

Command Output

Table 103.13-2 "TCA xDSL Alarm Log Status Command" Display parameters

Specific Information		
name	Type	Description
port	Parameter type: <Itf::XdslLine> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number	identifies where the alarm occurred <i>This element is only shown in detail mode.</i>
errored-secs	Parameter type: <Alarm::ErroredSeconds> (above-thres below-thres) Possible values: - above-thres : number of errored seconds exceeded threshold - below-thres : number of errored seconds below threshold	number of errored seconds exceeded or below threshold <i>This element is only shown in detail mode.</i>
es-in-a-day	Parameter type: <Alarm::ErroredSecondsInAday>	errored seconds in a day

103 Alarm Snap-shot Status Commands

name	Type	Description
	(above-thres below-thres) Possible values: - above-thres : number of errored seconds in a day, exceeded threshold - below-thres : number of errored seconds in a day, below threshold	exceeded or below threshold <i>This element is only shown in detail mode.</i>
severely-es	Parameter type: <Alarm::SeverelyErroredSeconds> (above-thres below-thres) Possible values: - above-thres : number of severely errored seconds exceeded threshold - below-thres : number of severely errored seconds below threshold	number of severely errored seconds exceeded or below threshold <i>This element is only shown in detail mode.</i>
severely-es-in-a-day	Parameter type: <Alarm::SevErroredSecsInAday> (above-thres below-thres) Possible values: - above-thres : number of severely errored seconds in a day, exceeded threshold - below-thres : number of severely errored seconds in a day, below threshold	number of severely errored seconds in a day, exceeded or below threshold <i>This element is only shown in detail mode.</i>
unavailable-secs	Parameter type: <Alarm::UnavailableSeconds> (above-thres below-thres) Possible values: - above-thres : number of unavailable seconds exceeded threshold - below-thres : number of unavailable seconds below threshold	number of unavailable seconds exceeded or below threshold <i>This element is only shown in detail mode.</i>
unavail-secs-in-a-day	Parameter type: <Alarm::UnavailSecsInAday> (above-thres below-thres) Possible values: - above-thres : number of unavailable seconds in a day, exceeded threshold - below-thres : number of unavailable seconds in a day, below threshold	number of far end unavailable seconds in a day, exceeded or below threshold <i>This element is only shown in detail mode.</i>
far-end-es	Parameter type: <Alarm::FarEndErroredSeconds> (above-thres below-thres) Possible values: - above-thres : number of far end errored seconds exceeded threshold - below-thres : number of far end errored seconds below threshold	number of far end errored seconds exceeded or below threshold <i>This element is only shown in detail mode.</i>
fe-severely-es	Parameter type: <Alarm::FarEndSevErroredSecs> (above-thres below-thres) Possible values: - above-thres : number of far end severely errored seconds exceeded threshold - below-thres : number of far end severely errored seconds below threshold	number of far end severely errored seconds exceeded or below threshold <i>This element is only shown in detail mode.</i>
fe-severely-es/day	Parameter type: <Alarm::FarEndSevErroredSecsInAday> (above-thres	number of severely errored seconds in a day, exceeded or

name	Type	Description
	below-thres) Possible values: - above-thres : number of far end severely errored seconds in a day, exceeded threshold - below-thres : number of far end severely errored seconds in a day, below threshold	below threshold <i>This element is only shown in detail mode.</i>
fe-unavail-secs	Parameter type: <Alarm::FarEndUnavailSecs> (above-thres below-thres) Possible values: - above-thres : number of far end unavailable seconds exceeded threshold - below-thres : number of far end unavailable seconds below threshold	number of far end unavailable seconds in a day, exceeded or below threshold <i>This element is only shown in detail mode.</i>
fe-unavail-sec/day	Parameter type: <Alarm::FarEndUnavailSecsInAday> (above-thres below-thres) Possible values: - above-thres : number of far end unavailable seconds in a day, exceeded threshold - below-thres : number of far end unavailable seconds in a day, below threshold	number of far end unavailable seconds in a day, exceeded or below threshold <i>This element is only shown in detail mode.</i>
fe-es-in-a-day	Parameter type: <Alarm::FarEndErroredSecsInAday> (above-thres below-thres) Possible values: - above-thres : number of far end errored seconds in a day, exceeded threshold - below-thres : number of far end errored seconds in a day, below threshold	number of far end errored seconds in a day, exceeded or below threshold <i>This element is only shown in detail mode.</i>
leftrs	Parameter type: <Alarm::LeftrSeconds> (above-thres below-thres) Possible values: - above-thres : number of low error free throughput seconds exceeded threshold - below-thres : number of low error free throughput seconds below threshold	number of low error free throughput seconds exceeded or below threshold <i>This element is only shown in detail mode.</i>
leftrs-in-a-day	Parameter type: <Alarm::LeftrSecondsInAday> (above-thres below-thres) Possible values: - above-thres : number of low error free throughput seconds in a day, exceeded threshold - below-thres : number of low error free throughput seconds in a day, below threshold	number of low error free throughput seconds in a day, exceeded or below threshold <i>This element is only shown in detail mode.</i>
fe-leftrs	Parameter type: <Alarm::FarEndLeftrSeconds> (above-thres below-thres) Possible values: - above-thres : number of far end low error free throughput seconds exceeded threshold - below-thres : number of far end low error free throughput seconds below threshold	number of far end low error free throughput seconds exceeded or below threshold <i>This element is only shown in detail mode.</i>
fe-leftrs-in-a-day	Parameter type: <Alarm::FarEndLeftrSecondsInAday> (above-thres below-thres)	number of far end low error free throughput seconds in a day, exceeded or below threshold

103 Alarm Snap-shot Status Commands

name	Type	Description
	Possible values: - above-thres : number of far end low error free throughput seconds in a day, exceeded threshold - below-thres : number of far end low error free throughput seconds in a day, below threshold	<i>This element is only shown in detail mode.</i>
xtca-auto-port-reset	Parameter type: <Alarm::AutoPortResetInAweek> (above-thres below-thres) Possible values: - above-thres : number of auto-port-resets reached threshold with in a week - below-thres : number of auto-port-resets below threshold	number of auto-port-resets in a week reached threshold <i>This element is only shown in detail mode.</i>
reinit	Parameter type: <Alarm::Reinit> (above-thres below-thres) Possible values: - above-thres : number of reinit counter exceeded threshold - below-thres : number of reinit counter below threshold	number of Reinitialization count in 15min, exceeded or below threshold <i>This element is only shown in detail mode.</i>
reinit-in-a-day	Parameter type: <Alarm::ReinitInAday> (above-thres below-thres) Possible values: - above-thres : number of reinit counter exceeded threshold - below-thres : number of reinit counter below threshold	number of Reinitialization count in a day, exceeded or below threshold <i>This element is only shown in detail mode.</i>

103.14 OLT General Alarm Snapshot Status Command

Command Description

This command displays the OLT general alarm snapshot status.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm snap-shot olt-gen [ (index) ]
```

Command Parameters

Table 103.14-1 "OLT General Alarm Snapshot Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm type

Command Output

Table 103.14-2 "OLT General Alarm Snapshot Status Command" Display parameters

Specific Information		
name	Type	Description
port	Parameter type: <Gpon::PonId> (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> x-pon : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::XPonId> 25g-pon : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::M25GPonId>) Possible values: - 25g-pon : 25g pon - x-pon : Xgs pon Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number	specify which port the alarm occurred on. <i>This element is only shown in detail mode.</i>

103 Alarm Snap-shot Status Commands

name	Type	Description
	Field type <Eqpt::PonId> - the PON identifier Field type <Eqpt::XPonId> - the XGS PON identifier Field type <Eqpt::M25GPonId> - the 25G PON identifier	
Only Show Details: alarm snap-shot log status		
name	Type	Description
olt-pon-comm	Parameter type: <Alarm::OltPonComm> ((failing fail) ok) Possible values: - failing : OLT port communication is failing - fail : OLT port communication is failing - ok : port protection is ok	snap-shot status of PON Communication failure on OLT Port <i>This element is only shown in detail mode.</i>
olt-gen-tf	Parameter type: <Alarm::OltGenTf> ((failing fail) ok) Possible values: - failing : port protection is failing - fail : port protection is failing - ok : port protection is ok	snap-shot status of transmit failure on OLT port <i>This element is only shown in detail mode.</i>
olt-new-ont	Parameter type: <Alarm::OltNewOnt> ((failing fail) ok) Possible values: - failing : port protection is failing - fail : port protection is failing - ok : port protection is ok	snap-shot status of unprovisioned ont appearance <i>This element is only shown in detail mode.</i>
olt-pon-mea	Parameter type: <Alarm::OltPonMea> ((failing fail) ok) Possible values: - failing : port protection is failing - fail : port protection is failing - ok : port protection is ok	snap-shot status of pon provision failure. <i>This element is only shown in detail mode.</i>
olt-pon-loss	Parameter type: <Alarm::OltPonLoss> ((failing fail) ok) Possible values: - failing : port protection is failing - fail : port protection is failing - ok : port protection is ok	snap-shot status of pon loss. <i>This element is only shown in detail mode.</i>
pon-rogue-test	Parameter type: <Alarm::PonRogueTest> ((failing fail) ok) Possible values: - failing : Rogue ONT detection mechanism effective is failing - fail : Rogue ONT detection mechanism effective is failing - ok : Rogue ONT detection mechanism effective is ok	snap-shot status of diagnostic tests <i>This element is only shown in detail mode.</i>
onu-loid-conflict	Parameter type: <Alarm::OnuLoidConflict> ((failing fail) ok) Possible values: - failing : port protection is failing - fail : port protection is failing	snap-shot status of loid conflict ont. <i>This element is only shown in detail mode.</i>

name	Type	Description
	- ok : port protection is ok	
onu-loid-pwd-err	Parameter type: <Alarm::OnuLoidPwdErr> ((failing fail) ok) Possible values: - failing : port protection is failing - fail : port protection is failing - ok : port protection is ok	snap-shot status of loid password error. <i>This element is only shown in detail mode.</i>
stk-laser-dis	Parameter type: <Alarm::StkLaserDis> ((failing fail) ok) Possible values: - failing : port protection is failing - fail : port protection is failing - ok : port protection is ok	snap-shot status of stuck laser disabled. <i>This element is only shown in detail mode.</i>
pon-alien-test	Parameter type: <Alarm::PonAlienTest> ((failing fail) ok) Possible values: - failing : Alien ONT detection mechanism is active - fail : Alien ONT detection mechanism is active - ok : Alien ONT detection mechanism is not active	snap-shot status of alien diagnostic tests <i>This element is only shown in detail mode.</i>
pon-alien-detect	Parameter type: <Alarm::AlienDetected> ((failing fail) ok) Possible values: - failing : Alien ONT detected - fail : Alien ONT detected - ok : No alien ONT detected	snap-shot status of alien detect <i>This element is only shown in detail mode.</i>
pon-rng-mismatch	Parameter type: <Alarm::PonRngMismatch> ((failing fail) ok) Possible values: - failing : ranging mismatch detection mechanism effective is failing - fail : ranging mismatch detection mechanism effective is failing - ok : ranging mismatch detection mechanism effective is ok	snap-shot status of ranging mismatch <i>This element is only shown in detail mode.</i>
pon-sfp-mismatch	Parameter type: <Alarm::PonSfpMismatch> ((failing fail) ok) Possible values: - failing : pon sfp mismatch is failing - fail : pon sfp mismatch is failing - ok : pon sfp mismatch is ok	snap-shot status of sfp mismatch <i>This element is only shown in detail mode.</i>
deactont-high-tca	Parameter type: <Alarm::DeactOntHighTca> (failing ok) Possible values: - failing : pon deactivated ont amount exceed high threshold occurred - ok : pon deactivated ont amount is less than high threshold occurred	snap-shot status of deactont high tca <i>This element is only shown in detail mode.</i>
deactont-low-tca	Parameter type: <Alarm::DeactOntLowTca> (failing ok) Possible values:	snap-shot status of deactont low tca <i>This element is only shown in detail mode.</i>

103 Alarm Snap-shot Status Commands

name	Type	Description
	- failing : pon deactivated ont amount exceed low threshhold occurred - ok : pon deactivated ont amount is less than low threshhold occurred	
datapath-integ	Parameter type: <Alarm::DataPathInteg> (failing ok) Possible values: - failing : number of ONTs with SIPREGTO alarm exceeds threshold - ok : number of ONTs with SIPREGTO alarm does not exceed the threshold	snap-shot status of PON Data Path Integrity <i>This element is only shown in detail mode.</i>

103.15 Alarm Vectoring Line Snapshot Status Command

Command Description

This command displays the status of the snapshot vectoring line alarm.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

> show alarm snap-shot vect-line [(index)]

Command Parameters

Table 103.15-1 "Alarm Vectoring Line Snapshot Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	index of the alarm snap shot table

Command Output

Table 103.15-2 "Alarm Vectoring Line Snapshot Status Command" Display parameters

Specific Information		
name	Type	Description
port	Parameter type: <Itf::XdslLine> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number	identifies the physical position of the port where the alarm has occurred. <i>This element is only shown in detail mode.</i>
xtc-variation-vict	Parameter type: <Alarm::VectXtcVariation> (excessive normal) Possible values: - excessive : abnormal amplitude variation in xtc	excessive : abnormal amplitude variation in xtc coefficients <i>This element is only shown in detail mode.</i>

103 Alarm Snap-shot Status Commands

name	Type	Description
	coefficients - normal : no excessive xtc coefficients variation	
xtc-variation-dist	Parameter type: <Alarm::VectXtcVariationDist> (excessive normal) Possible values: - excessive : abnormal amplitude variation in xtc coefficients - normal : no excessive xtc coefficients variation	specifies if excessive outgoing crosstalk coefficient variation occurred or not <i>This element is only shown in detail mode.</i>
corrupted-errf	Parameter type: <Alarm::VectCorptErrf> (yes no) Possible values: - yes : at least 10% corrupted or missing errorf samples received - no : received errorf samples ok	specifies if corrupted or at least 10% missing errorf samples received occurred or not <i>This element is only shown in detail mode.</i>
vect-cpe-cap-mismatch	Parameter type: <Alarm::VectCpeCapMism> (yes no) Possible values: - yes : not allowed Vectoring CPE connected - no : allowed Vectoring CPE connected	specifies if an allowed Vectoring CPE is connected or not <i>This element is only shown in detail mode.</i>
vect-conf-not-feas	Parameter type: <Alarm::VectConfNotFeas> (yes no) Possible values: - yes : vectoring configuration not feasible - no : vectoring configuration feasible	specifies if the vectoring configuration is feasible <i>This element is only shown in detail mode.</i>
prev-status	Parameter type: <Alarm::VectConfNotFeas> (yes no) Possible values: - yes : vectoring configuration not feasible - no : vectoring configuration feasible	status of vect-conf-not-feas with its previous logged value <i>This element is only shown in detail mode.</i>

103.16 Alarm Vectoring Board Snapshot Status Command

Command Description

This command displays the status of the snapshot vectoring board alarm.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

> show alarm snap-shot vect-board [(index)]

Command Parameters

Table 103.16-1 "Alarm Vectoring Board Snapshot Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	index of the alarm snap shot table

Command Output

Table 103.16-2 "Alarm Vectoring Board Snapshot Status Command" Display parameters

Specific Information		
name	Type	Description
board-index	Parameter type: <Equipm::EqptVpSlotIndex> (ctrl : <Eqpt::RackId> / <Eqpt::ShelfId> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId>) Possible values: - ctrl : ctrl-slot Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number	specifies where the alarm has occurred. <i>This element is only shown in detail mode.</i>
vp-link-index	Parameter type: <Alarm::VectVpLinkId2> - specifies the soft-link or the vp-link on the vp-board, or zero - range: [0,1...16]	this is the vplink id. This index has value zero when it is not used <i>This element is only shown in detail mode.</i>
vp-lt-mismatch	Parameter type: <Alarm::VectVpLtMism>	specifies if a mismatch between

103 Alarm Snap-shot Status Commands

name	Type	Description
	(yes no) Possible values: - yes : mismatch between expected and actual vp-lt mapping or incompatible sw version on vp and lt - no : expected and actual vp-lt in line or vp and lt have compatible sw versions, OR autodiscovery enabled on vp, autodiscovery disabled on lt	expected and actual vp-lt mapping OR incompatible sw version on vp and lt is detected or not. In case vplt-autodiscovery disabled on vp, failure reported on vp-board. In case vplt-autodiscovery enabled on lt, failure reported on lt-board. <i>This element is only shown in detail mode.</i>
qsfp-id	Parameter type: <Alarm::VectQsfpInvalidNokiaID> (invalid valid) Possible values: - invalid : QSFP does not have valid Nokia ID - valid : QSFP has valid Nokia ID OR no QSFP detected.	specifies if detected QSFP of the frontcable has a valid Nokia ID or not <i>This element is only shown in detail mode.</i>
vp-lt-link	Parameter type: <Alarm::VPLTLINKFAIL> (linkdown linkup) Possible values: - linkdown : vp-lt link problem - linkup : vp-lt link ok or no lt-expected OR autodiscovery enabled on vp, autodiscovery disabled on lt	specifies if a VP-LT link failure is detected or not. In case vplt-autodiscovery disabled on vp, failure reported on vp-board when an lt was expected but no valid connection between vp-lt. In case vplt-autodiscovery enabled on lt, failure reported on lt-board when no valid connection between vp-lt. <i>This element is only shown in detail mode.</i>
vect-no-gain-at-init	Parameter type: <Alarm::VECTNOGAINATINIT> (yes no) Possible values: - yes : Lines cannot train in gain-at-init mode - no : Lines can train in gain-at-init mode	vectoring gain-at-init mode is not feasible due to excessive number of non-FDPS capable CPEs <i>This element is only shown in detail mode.</i>

103.17 Alarm Electrical-to-Optical Conversion for Snapshot Status Command

Command Description

This command displays the electrical-to-optical conversion alarm log status.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm snap-shot eo-conversion [ (index) ]
```

Command Parameters

Table 103.17-1 "Alarm Electrical-to-Optical Conversion for Snapshot Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm snap shot table index

Command Output

Table 103.17-2 "Alarm Electrical-to-Optical Conversion for Snapshot Status Command" Display parameters

Specific Information		
name	Type	Description
loss-of-signal	Parameter type: <Alarm::EoConvLOS> (yes no) Possible values: - yes : loss of signal detected in the EO conversion module - no : no loss of signal detected in the EO conversion module	specifies whether loss of signal detected or not in the EO conversion module <i>This element is only shown in detail mode.</i>
transmission	Parameter type: <Alarm::EoConvTx> (faulty ok) Possible values: - faulty : transmission fault in the EO module - ok : transmission OK	specifies whether transmission fault is occurred or not in the EO module <i>This element is only shown in detail mode.</i>

103.18 Authentication Alarms for Snapshot Status Command

Command Description

This command displays the status of authentication-related alarms.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

> show alarm snap-shot authentication [(index)]

Command Parameters

Table 103.18-1 " Authentication Alarms for Snapshot Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm snap shot table index

Command Output

Table 103.18-2 " Authentication Alarms for Snapshot Status Command" Display parameters

Specific Information		
name	Type	Description
uni	Parameter type: <Itf::BridgePortItf> (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::VpiId> : <Eqpt::VciId> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> / <Eqpt::OntPortId> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / voip <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / vuni <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::LLId> ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> /	specify which uni the alarm occurred on. <i>This element is only shown in detail mode.</i>

name	Type	Description
	<Eqpt::Ng2OntSlotId> / <Eqpt::Ng2OntPortId> ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / vuni) Possible values: - ng2 : ngpon2 style identification Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number Field type <Eqpt::VpiId> - atm VPI Field type <Eqpt::VciId> - atm VCI Field type <Eqpt::ChannelGroupId> - the channel group identifier Field type <Eqpt::SubChannelGroupId> - the subchannel group identifier Field type <Eqpt::PonId> - the PON identifier Field type <Eqpt::OntId> - the ONT identifier Field type <Eqpt::Ng2OntId> - the NG2 ONT identifier Possible values: - voip : virtual uni identifier obsolete alternative replaced by vuni - vuni : virtual uni identifier Possible values: - vuni : virtual NGPON2 uni identifier Field type <Eqpt::OntSlotId> - the ONT SLOT identifier Field type <Eqpt::OntPortId> - the ONT PORT identifier Field type <Eqpt::Ng2OntSlotId> - the NGPON2 ONT SLOT identifier Field type <Eqpt::Ng2OntPortId> - the NGPON2 ONT PORT identifier Field type <Eqpt::LLId> - the LLID identifier, range 1 for EPON, range 1-8 for DPOE	
vlan-assignment	Parameter type: <Alarm::VLANAssignment> (failed successful) Possible values: - failed : failure to assign a VLAN for a user session - successful : assigned a VLAN for a user session	specifies whether a VLAN for a user session is assigned or failed <i>This element is only shown in detail mode.</i>
vsa-info-invalid	Parameter type: <Alarm::VSAValid> (yes no) Possible values: - yes : invalid VSA info alarm from RADIUS - no : valid VSA info from RADIUS and no alarm	specifies whether vsa information valid or not from RADIUS server. <i>This element is only shown in detail mode.</i>
mac-conflict	Parameter type: <Alarm::MACConflict> (yes	specifies whether mac conflict occurred or not in mac based

103 Alarm Snap-shot Status Commands

name	Type	Description
	no) Possible values: - yes : status of auth-mac-conflict alarm occurred - no : no status of auth-mac-conflict alarm occurred	authentication. <i>This element is only shown in detail mode.</i>
user-pwd-fault	Parameter type: <Alarm::USRPWDFault> (yes no) Possible values: - yes : invalid user or password alarm occurred - no : valid user and password and no alarm	specifies whether user or password valid or not in mac based authenticaiton. <i>This element is only shown in detail mode.</i>

103.19 Alarm xDSL Bonding Snap Shot Status Command

Command Description

This command displays the alarms of the xDSL bonding snap shot.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

> show alarm snap-shot bonding-group [(index)]

Command Parameters

Table 103.19-1 "Alarm xDSL Bonding Snap Shot Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm snap shot table index

Command Output

Table 103.19-2 "Alarm xDSL Bonding Snap Shot Status Command" Display parameters

Specific Information		
name	Type	Description
group	Parameter type: <Xdsl::BondingInterfaceIndex> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number	identifies the bonding group interface index <i>This element is only shown in detail mode.</i>
up-plan-bitrate	Parameter type: <Alarm::UpPlannedBitrate> (failure ok) Possible values: - failure : actual group bitrate is above the minimum	specifies whether the actual group upstream bit rate is above the group upstream planned bit rate or not <i>This element is only shown in</i>

103 Alarm Snap-shot Status Commands

name	Type	Description
	upstream bitrate but below the group upstream planned bitrate - ok : actual group bitrate is above the group upstream planned bitrate	<i>detail mode.</i>
down-plan-bitrate	Parameter type: <Alarm::DownPlanBitrate> (failure ok) Possible values: - failure : actual group bitrate is above the minimum downstream bitrate but below the group downstream planned bitrate - ok : actual group bitrate is above the group downstream planned bitrate	specifies whether the actual group downstream bit rate is above the group downstream planned bit rate or not <i>This element is only shown in detail mode.</i>
up-min-bitrate	Parameter type: <Alarm::UpMinBitrate> (failure ok) Possible values: - failure : actual group bitrate is below the group upstream minimum bitrate - ok : actual group bitrate is above the group upstream minimum bitrate	specifies whether the actual group upstream bit rate is above the group upstream minimum bit rate or not <i>This element is only shown in detail mode.</i>
down-min-bitrate	Parameter type: <Alarm::DownMinBitrate> (failure ok) Possible values: - failure : actual group bitrate is below the group downstream minimum bitrate - ok : actual group bitrate is above the group downstream minimum bitrate	specifies whether the actual group downstream bit rate is above the group downstream minimum bit rate or not <i>This element is only shown in detail mode.</i>
up-config	Parameter type: <Alarm::UpConfig> (not-feasible feasible) Possible values: - not-feasible : upstream configuration not feasible - feasible : upstream configuration feasible	specifies whether the upstream configuration is feasible or not <i>This element is only shown in detail mode.</i>
down-config	Parameter type: <Alarm::DownConfig> (not-feasible feasible) Possible values: - not-feasible : downstream configuration not feasible - feasible : downstream configuration feasible	specifies whether the downstream configuration is feasible or not <i>This element is only shown in detail mode.</i>
bond-cpe-conn	Parameter type: <Alarm::BondCPE> (not-connected connected) Possible values: - not-connected : bonding cpe modem not connected - connected : bonding cpe modem connected	specifies whether a bonding CPE modem is connected or not <i>This element is only shown in detail mode.</i>
multiple-cpes	Parameter type: <Alarm::BgConnCPE> (true false) Possible values: - true : bonding group has multiple cpe modems connected - false : bonding group has one cpe modem connected	specifies whether the lines of a bonding group are connected to multiple CPEs or only one <i>This element is only shown in detail mode.</i>
register	Parameter type: <Alarm::BgRegFail> (failure ok) Possible values:	specifies whether a discovery or aggregation failure is encountered or not <i>This element is only shown in</i>

name	Type	Description
	- failure : bonding group discovery or aggregation register failure detected - ok : bonding group discovery or aggregation register failure not detected	<i>detail mode.</i>
group-incomplete	Parameter type: <Alarm::BgNotCompl> (true false) Possible values: - true : bonding group is incomplete - false : bonding group is complete	specifies whether all configured lines of the bonding group are part of the bonding group <i>This element is only shown in detail mode.</i>

103.20 Alarm Redundancy Snapshot Status Command

Command Description

This command displays the redundancy snapshot-related alarms.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

> show alarm snap-shot redundancy [(index)]

Command Parameters

Table 103.20-1 "Alarm Redundancy Snapshot Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm snap shot table index

Command Output

Table 103.20-2 "Alarm Redundancy Snapshot Status Command" Display parameters

Specific Information		
name	Type	Description
loss-swo-cap	Parameter type: <Alarm::SwoCap> (loss not-loss) Possible values: - loss : system loss of the swichover capability - not-loss : system not loss of the swichover capability	identify the swichover capability in a redundant system. <i>This element is only shown in detail mode.</i>
ping-check	Parameter type: <Alarm::PingCheck> (failure successful) Possible values: - failure : system failure of ping check - successful : system successful of ping check	identify the ping check in a redundant system. <i>This element is only shown in detail mode.</i>

103.21 Alarm Custom Snapshot Status Command

Command Description

This command displays custom snapshot-related alarms.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

> show alarm snap-shot custom [(index)]

Command Parameters

Table 103.21-1 "Alarm Custom Snapshot Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm snap shot table index

Command Output

Table 103.21-2 "Alarm Custom Snapshot Status Command" Display parameters

Specific Information		
name	Type	Description
custom-alarm1	Parameter type: <Alarm::custom1> (yes no) Possible values: - yes : Miscellaneous environment alarm - no : no Miscellaneous environment alarm	identify the customizableAlarm1 . <i>This element is only shown in detail mode.</i>
custom-alarm2	Parameter type: <Alarm::custom2> (yes no) Possible values: - yes : Miscellaneous environment alarm - no : no Miscellaneous environment alarm	identify the customizableAlarm2 . <i>This element is only shown in detail mode.</i>
custom-alarm3	Parameter type: <Alarm::custom3> (yes no) Possible values: - yes : Miscellaneous environment alarm - no : no Miscellaneous environment alarm	identify the customizableAlarm3 . <i>This element is only shown in detail mode.</i>
custom-alarm4	Parameter type: <Alarm::custom4>	identify the customizableAlarm4

103 Alarm Snap-shot Status Commands

name	Type	Description
	(yes no) Possible values: - yes : Miscellaneous environment alarm - no : no Miscellaneous environment alarm	. <i>This element is only shown in detail mode.</i>
custom-alarm5	Parameter type: <Alarm::custom5> (yes no) Possible values: - yes : Miscellaneous environment alarm - no : no Miscellaneous environment alarm	identify the customizableAlarm5 . <i>This element is only shown in detail mode.</i>
custom-alarm6	Parameter type: <Alarm::custom6> (yes no) Possible values: - yes : Miscellaneous environment alarm - no : no Miscellaneous environment alarm	identify the customizableAlarm6 . <i>This element is only shown in detail mode.</i>
custom-alarm7	Parameter type: <Alarm::custom7> (yes no) Possible values: - yes : Miscellaneous environment alarm - no : no Miscellaneous environment alarm	identify the customizableAlarm7 . <i>This element is only shown in detail mode.</i>
custom-alarm8	Parameter type: <Alarm::custom8> (yes no) Possible values: - yes : Miscellaneous environment alarm - no : no Miscellaneous environment alarm	identify the customizableAlarm8 . <i>This element is only shown in detail mode.</i>
custom-alarm9	Parameter type: <Alarm::custom9> (yes no) Possible values: - yes : Miscellaneous environment alarm - no : no Miscellaneous environment alarm	identify the customizableAlarm9 . <i>This element is only shown in detail mode.</i>
custom-alarm10	Parameter type: <Alarm::custom10> (yes no) Possible values: - yes : Miscellaneous environment alarm - no : no Miscellaneous environment alarm	identify the customizableAlarm10 . <i>This element is only shown in detail mode.</i>
custom-alarm11	Parameter type: <Alarm::custom11> (yes no) Possible values: - yes : Miscellaneous environment alarm - no : no Miscellaneous environment alarm	identify the customizableAlarm11 . <i>This element is only shown in detail mode.</i>
custom-alarm12	Parameter type: <Alarm::custom12> (yes no) Possible values: - yes : Miscellaneous environment alarm - no : no Miscellaneous environment alarm	identify the customizableAlarm12 . <i>This element is only shown in detail mode.</i>
custom-alarm13	Parameter type: <Alarm::custom13> (yes no) Possible values:	identify the customizableAlarm13 . <i>This element is only shown in detail mode.</i>

name	Type	Description
	- yes : Miscellaneous environment alarm - no : no Miscellaneous environment alarm	
custom-alarm14	Parameter type: <Alarm::custom14> (yes no) Possible values: - yes : Miscellaneous environment alarm - no : no Miscellaneous environment alarm	identify the customizableAlarm14 . <i>This element is only shown in detail mode.</i>
custom-alarm15	Parameter type: <Alarm::custom15> (yes no) Possible values: - yes : Miscellaneous environment alarm - no : no Miscellaneous environment alarm	identify the customizableAlarm15 . <i>This element is only shown in detail mode.</i>
custom-alarm16	Parameter type: <Alarm::custom16> (yes no) Possible values: - yes : Miscellaneous environment alarm - no : no Miscellaneous environment alarm	identify the customizableAlarm16 . <i>This element is only shown in detail mode.</i>
custom-alarm17	Parameter type: <Alarm::custom17> (yes no) Possible values: - yes : Miscellaneous environment alarm - no : no Miscellaneous environment alarm	identify the customizableAlarm17 . <i>This element is only shown in detail mode.</i>

Only Show Details: host expansion shelves customizable alarms

name	Type	Description
shelf	Parameter type: <Equipm::HolderId> (<Eqpt::RackId> / <Eqpt::ShelfId> not-applicable) Possible values: - not-applicable : not applicable Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number	this is the shelf id (equipment hoder id) for host expansion alarms, otherwise it is the rack ID <i>This element is only shown in detail mode.</i>
he-custom-alarm1	Parameter type: <Alarm::he-custom1> (yes no) Possible values: - yes : Miscellaneous environment alarm - no : no Miscellaneous environment alarm	identify the host expansion's customizableAlarm1 . <i>This element is only shown in detail mode.</i>
he-custom-alarm2	Parameter type: <Alarm::he-custom2> (yes no) Possible values: - yes : Miscellaneous environment alarm - no : no Miscellaneous environment alarm	identify the host expansion's customizableAlarm2 . <i>This element is only shown in detail mode.</i>
he-custom-alarm3	Parameter type: <Alarm::he-custom3> (yes no) Possible values: - yes : Miscellaneous environment alarm - no : no Miscellaneous environment alarm	identify the host expansion's customizableAlarm3 . <i>This element is only shown in detail mode.</i>
he-custom-alarm4	Parameter type: <Alarm::he-custom4> (yes	identify the host expansion's customizableAlarm4 .

103 Alarm Snap-shot Status Commands

name	Type	Description
	no) Possible values: - yes : Miscellaneous environment alarm - no : no Miscellaneous environment alarm	<i>This element is only shown in detail mode.</i>
he-custom-alarm5	Parameter type: <Alarm::he-custom5> (yes no) Possible values: - yes : Miscellaneous environment alarm - no : no Miscellaneous environment alarm	identify the host expansion's customizableAlarm5 . <i>This element is only shown in detail mode.</i>
he-custom-alarm6	Parameter type: <Alarm::he-custom6> (yes no) Possible values: - yes : Miscellaneous environment alarm - no : no Miscellaneous environment alarm	identify the host expansion's customizableAlarm6 . <i>This element is only shown in detail mode.</i>

103.22 Alarm SFP Snapshot Status Command

This command displays the SFP snapshot-related alarms.

Command Description

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm snap-shot sfp [ (index) ]
```

Command Parameters

Table 103.22-1 "Alarm SFP Snapshot Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm snap shot table index

Command Output

Table 103.22-2 "Alarm SFP Snapshot Status Command" Display parameters

Specific Information		
name	Type	Description
alarm index 1	Parameter type: <Alarm::SfpAlarmIdx1Type> (<Alarm::SfpAlarmIdx1> lt : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId>) Possible values: - lt : the lt-slot Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Alarm::SfpAlarmIdx1> - the host port faceplate number or the equipment slot-id for expansion shelf alarm	this is the host sfp faceplate number for host alarms or it is the equipment slot id for expansion shelf alarms <i>This element is only shown in detail mode.</i>
alarm index 2	Parameter type: <Ihub::EthernetPort> (nt-a : sfp : <Alarm::FacePlatePortIndex> nt-a : xfp : <Alarm::FacePlatePortIndex> nt-a : eth : <Alarm::FacePlatePortIndex> nt-b : sfp : <Alarm::FacePlatePortIndex>	this is the ethernet port id or LT slot for host alarms. this index is not used for expansion shelf alarms <i>This element is only shown in</i>

103 Alarm Snap-shot Status Commands

name	Type	Description
	nt-b : xfp : <Alarm::FacePlatePortIndex> nt-b : eth : <Alarm::FacePlatePortIndex> ntio-1 : sfp : <Alarm::FacePlatePortIndex> ntio-1 : xfp : <Alarm::FacePlatePortIndex> ntio-2 : sfp : <Alarm::FacePlatePortIndex> ntio-2 : xfp : <Alarm::FacePlatePortIndex> lt : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> not-applicable lt-slot : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId>) Possible values: - nt-a : the nt-a slot - nt-b : the nt-b slot - ntio-1 : an nt applique slot in a single or multiple-ntio-shelf - ntio-2 : an nt applique slot in a multiple-ntio-shelf - lt : the lt slot - lt-slot : the port in lt slot - not-applicable : no port Possible values: - sfp : SFP port - xfp : XFP port - eth : RJ45 or lemi port Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Alarm::FacePlatePortIndex> - the faceplate port number	detail mode.

Only Show Details: host shelf alarms		
name	Type	Description
host-sfp-los	Parameter type: <Alarm::hostSFPLOS> (failing ok) Possible values: - failing : host downlink SFP loss of signal - ok : host downlink SFP signal ok	current status host downlink SFP loss of signal <i>This element is only shown in detail mode.</i>
host-sfp-tx	Parameter type: <Alarm::hostSFPTxFail> (failing ok) Possible values: - failing : host downlink SFP tx failure - ok : host downlink SFP tx ok	current status host downlink SFP tx failure <i>This element is only shown in detail mode.</i>
host-sfp-pres	Parameter type: <Alarm::hostSFPMissing> (not-present present) Possible values: - not-present : host downlink SFP not present - present : host downlink SFP present	current status host downlink SFP not present <i>This element is only shown in detail mode.</i>
host-sfp-id	Parameter type: <Alarm::hostSFPInvalidNokiaID> (invalid valid) Possible values: - invalid : host downlink SFP does not have valid Nokia ID - valid : host downlink SFP has valid Nokia ID	current status host downlink SFP does not have valid Nokia ID <i>This element is only shown in detail mode.</i>
host-sfp-ctrl	Parameter type: <Alarm::hostSFPControlFail>	current status host downlink SFP

name	Type	Description
	(failing ok) Possible values: - failing : host downlink SFP control failure - ok : host downlink SFP control ok	control failure <i>This element is only shown in detail mode.</i>
host-sfp-rmtlt	Parameter type: <Alarm::hostSFPUnexpectedRemoteLT> (yes no) Possible values: - yes : host shelf SFP unexpected remote LT plug-in - no : host shelf SFP expected remote LT plug-in	current status of SFP alarm, host downlink SFP detected unexpected remote plug-in <i>This element is only shown in detail mode.</i>
host-sfp-mismatch	Parameter type: <Alarm::hostSFPAssignmentMismatch> (yes no) Possible values: - yes : host shelf SFP assignment does not match reported rack/shelf/slot - no : host shelf SFP assignment matches reported rack/shelf/slot	current status of SFP alarm, host downlink SFP assignment does not match reported rack/shelf/slot <i>This element is only shown in detail mode.</i>
host-sfp-incompt	Parameter type: <Alarm::hostSFPIncompatibleShelf> (yes no) Possible values: - yes : host shelf SFP incompatible shelf type detected - no : host shelf SFP compatible shelf type detected	current status of SFP alarm, host downlink SFP detected incompatible shelf type <i>This element is only shown in detail mode.</i>

Only Show Details: expansion shelf alarms

name	Type	Description
exp-sfp-los	Parameter type: <Alarm::expansionShelfSFPLos> (failing ok) Possible values: - failing : expansion shelf downlink SFP loss of signal - ok : expansion shelf downlink SFP signal ok	current status expansion side SFP loss of signal <i>This element is only shown in detail mode.</i>
exp-sfp-tx	Parameter type: <Alarm::expansionShelfSFPTxFail> (failing ok) Possible values: - failing : expansion shelf host downlink SFP tx failure - ok : expansion shelf downlink SFP tx ok	current status expansion shelf downlink SFP tx failure <i>This element is only shown in detail mode.</i>
exp-sfp-pres	Parameter type: <Alarm::expansionShelfSFPMissing> (not-present present) Possible values: - not-present : expansion shelf downlink SFP not present - present : expansion shelf downlink SFP present	current status expansion shelf downlink SFP not detected <i>This element is only shown in detail mode.</i>
exp-sfp-id	Parameter type: <Alarm::expShelfSFPInvalidNokiaID> (invalid valid) Possible values: - invalid : expansion shelf downlink SFP does not have valid Nokia ID - valid : expansion shelf downlink SFP has valid Nokia ID	current status expansion shelf downlink SFP does not have valid Nokia ID <i>This element is only shown in detail mode.</i>
exp-sfp-ctrl	Parameter type: <Alarm::expansionShelfSFPCtrlFail> (failing ok) Possible values: - failing : expansion shelf downlink SFP control failure	current status expansion shelf downlink SFP control failure <i>This element is only shown in detail mode.</i>

103 Alarm Snap-shot Status Commands

name	Type	Description
	- ok : expansion shelf downlink SFP control ok	
exp-sfp-1-los	Parameter type: <Alarm::expansionShelfSFP1Los> (failing ok) Possible values: - failing : expansion shelf downlink SFP1 loss of signal - ok : expansion shelf downlink SFP1 signal ok	current status expansion side SFP1 loss of signal <i>This element is only shown in detail mode.</i>
exp-sfp-2-los	Parameter type: <Alarm::expansionShelfSFP2Los> (failing ok) Possible values: - failing : expansion shelf downlink SFP2 loss of signal - ok : expansion shelf downlink SFP2 signal ok	current status expansion side SFP2 loss of signal <i>This element is only shown in detail mode.</i>

103.23 Alarm Custom External Snap Shot Status Command

Command Description

This command shows the customizable external alarm snap shot status.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

> show alarm snap-shot custom-ext-alarm [(index)]

Command Parameters

Table 103.23-1 "Alarm Custom External Snap Shot Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm snap shot table index

Command Output

Table 103.23-2 "Alarm Custom External Snap Shot Status Command" Display parameters

Specific Information		
name	Type	Description
ext-alarm1	Parameter type: <Alarm::custExtAlarm1> (yes no) Possible values: - yes : customizable external alarm 1 - no : no customizable external alarm 1	current status specifying external alarm 1 is present or not <i>This element is always shown.</i>
ext-alarm2	Parameter type: <Alarm::custExtAlarm2> (yes no) Possible values: - yes : customizable external alarm 2 - no : no customizable external alarm 2	current status specifying external alarm 2 is present or not <i>This element is always shown.</i>
ext-alarm3	Parameter type: <Alarm::custExtAlarm3> (yes no) Possible values:	current status specifying external alarm 3 is present or not <i>This element is always shown.</i>

103 Alarm Snap-shot Status Commands

name	Type	Description
	- yes : customizable external alarm 3 - no : no customizable external alarm 3	
ext-alarm4	Parameter type: <Alarm::custExtAlarm4> (yes no) Possible values: - yes : customizable external alarm 4 - no : no customizable external alarm 4	current status specifying external alarm 4 is present or not <i>This element is always shown.</i>
ext-alarm5	Parameter type: <Alarm::custExtAlarm5> (yes no) Possible values: - yes : customizable external alarm 5 - no : no customizable external alarm 5	current status specifying external alarm 5 is present or not <i>This element is always shown.</i>

103.24 Alarm RSSI SFP Snapshot Status Command

Command Description

This command displays the SFP RSSI snapshot-related alarms.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm snap-shot sfrssi [ (index) ]
```

Command Parameters

Table 103.24-1 "Alarm RSSI SFP Snapshot Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm snapshot table index

Command Output

Table 103.24-2 "Alarm RSSI SFP Snapshot Status Command" Display parameters

Specific Information		
name	Type	Description
alarm index 1	Parameter type: <Alarm::SlotIndex> (lt : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> nt-a nt-b nt acu : <Eqpt::RackId> / <Eqpt::ShelfId> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::EqSlotId> ext-a : <Eqpt::RackId> / <Eqpt::ShelfId> ext-b : <Eqpt::RackId> / <Eqpt::ShelfId> ctrl : <Eqpt::RackId> / <Eqpt::ShelfId> iont : <Eqpt::RackId> / <Eqpt::ShelfId> lp : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::LtAppliqueSlotId> ntio-1 ntio-2 vlt : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::VirtualSlotId>) Possible values: - lt : lt-slot - vlt : virtual LT slot (VVPS board can only be planned at	this is the nt/ntio slot id for Snapshot alarms. <i>This element is only shown in detail mode.</i>

103 Alarm Snap-shot Status Commands

name	Type	Description
	NANT-E/FANT-F) - nt-a : nt-a slot - nt-b : nt-b slot - nt : nt slot - ext-a : nt-a slot in an extension shelf - ext-b : nt-b slot in an extension shelf - acu : acu slot - ctrl : ctrl-slot - iont : an nt applique slot - lp : an lt applique slot - ntio-1 : an nt applique slot in a single or multiple-ntio-shelf - ntio-2 : an nt applique slot in a multiple-ntio-shelf Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::LtAppliqueSlotId> - the LT Applique slot number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::VirtualSlotId> - the virtual LT slot number Field type <Eqpt::EqSlotId> - the equipment slot number	
alarm index 2	Parameter type: <Alarm::RssiPort> (sfp : <Alarm::RssiPort> xfp : <Alarm::RssiPort> cfp : <Alarm::RssiPort> qsf : <Alarm::RssiPort> sfp1 : <Alarm::RssiPort> sfp2 : <Alarm::RssiPort> xfp1 : <Alarm::RssiPort> xfp2 : <Alarm::RssiPort>) Possible values: - sfp : rssi sfp port - xfp : rssi xfp port - cfp : rssi cfp port - qsf : rssi qsf port - sfp1 : rssi sfp port 1 - sfp2 : rssi sfp port 2 - xfp1 : rssi xfp port 1 - xfp2 : rssi xfp port 2 Field type <Alarm::RssiPort> - value - range: [0...36]	this is the nt/ntio sfp faceplate number <i>This element is only shown in detail mode.</i>

Only Show Details: sfp rssi diagnostic threshold control alarms		
name	Type	Description
tx-power-high-alarm	Parameter type: <Alarm::NTNTIOTXPWHI> (yes no) Possible values: - yes : TX optical power is too high than configured alarm high threshold - no : The TX optical power is ok	current status optical power is too high than the configured alarm high threshold <i>This element is only shown in detail mode.</i>
tx-power-low-alarm	Parameter type: <Alarm::NTNTIOTXPWLO> (yes no)	current status Tx optical power is too low than the configured alarm low threshold

name	Type	Description
	Possible values: - yes : TX optical power is too low than the configured alarm low threshold - no : TX optical power is ok	<i>This element is only shown in detail mode.</i>
rx-power-high-alarm	Parameter type: <Alarm::NTNTIORXPWHI> (yes no) Possible values: - yes : RX optical power is too high than the configured alarm high threshold - no : RX optical power is ok	current status Rx optical power is too high than the configured alarm high threshold <i>This element is only shown in detail mode.</i>
rx-power-low-alarm	Parameter type: <Alarm::NTNTIORXPWLO> (yes no) Possible values: - yes : RX optical power is too low than the configured alarm low threshold - no : RX optical power is ok	current status Rx optical power is too low than the configured alarm low threshold <i>This element is only shown in detail mode.</i>
tx-biascur-high-alarm	Parameter type: <Alarm::NTNTIOTXBIASHI> (yes no) Possible values: - yes : TX bias is too high than the configured alarm low threshold - no : TX bias current is ok	current status Tx bias is too high than the configured alarm low threshold <i>This element is only shown in detail mode.</i>
tx-biascur-low-alarm	Parameter type: <Alarm::NTNTIOTXBIASLO> (yes no) Possible values: - yes : TX bias is too low than the configured alarm low threshold - no : TX bias current is ok	current status Tx bias is too low than the configured alarm low threshold <i>This element is only shown in detail mode.</i>
volt-high-alarm	Parameter type: <Alarm::NTNTIOVOLHI> (yes no) Possible values: - yes : voltage is too high than the configured alarm high threshold - no : voltage is ok	current status voltage is too high than the configured alarm high threshold <i>This element is only shown in detail mode.</i>
volt-low-alarm	Parameter type: <Alarm::NTNTIOVOLLO> (yes no) Possible values: - yes : voltage is too low than the configured alarm low threshold - no : voltage is ok	current status voltage is too low than the configured alarm low threshold <i>This element is only shown in detail mode.</i>
temp-high-alarm	Parameter type: <Alarm::NTNTIOTEMPHI> (yes no) Possible values: - yes : temperature is too high than the configured alarm high threshold - no : temperature is ok	current status temperature is too high than the configured alarm high threshold <i>This element is only shown in detail mode.</i>
temp-low-alarm	Parameter type: <Alarm::NTNTIOTEMPLO> (yes no) Possible values:	current status temperature is too low than the configured alarm low threshold <i>This element is only shown in detail mode.</i>

103 Alarm Snap-shot Status Commands

name	Type	Description
	- yes : temperature is too low than the configured alarm low threshold - no : temperature is ok	<i>detail mode.</i>
tx-power-high-warn	Parameter type: <Alarm::NTNTIOTXPWHIWARN> (yes no) Possible values: - yes : TX optical power is too high than the configured warning high threshold - no : TX optical power is ok	current status Tx optical power is too high than the configured warning high threshold <i>This element is only shown in detail mode.</i>
tx-power-low-warn	Parameter type: <Alarm::NTNTIOTXPWLOWARN> (yes no) Possible values: - yes : TX optical power is too low than the configured warning low threshold - no : TX optical power is ok	current status Tx optical power is too low than the configured warning low threshold <i>This element is only shown in detail mode.</i>
rx-power-high-warn	Parameter type: <Alarm::NTNTIORXPWHIWARN> (yes no) Possible values: - yes : RX optical power is too low than the configured warning high threshold - no : RX optical power is ok	current status Rx optical power is too low than the configured warning high threshold <i>This element is only shown in detail mode.</i>
rx-power-low-warn	Parameter type: <Alarm::NTNTIORXPWLOWARN> (yes no) Possible values: - yes : RX optical power is too low than the configured warning low threshold - no : RX optical power is ok	current status Rx optical power is too low than the configured warning low threshold <i>This element is only shown in detail mode.</i>
tx-biascur-high-warn	Parameter type: <Alarm::NTNTIOTXBIASHIWARN> (yes no) Possible values: - yes : TX bias is too high than the configured warning high threshold - no : TX bias current is ok	current status Tx bias is too high than the configured warning high threshold <i>This element is only shown in detail mode.</i>
tx-biascur-low-warn	Parameter type: <Alarm::NTNTIOTXBIASLOWARN> (yes no) Possible values: - yes : TX bias is too low than the configured warning low threshold - no : TX bias current is ok	current status Tx bias is too low than the configured warning low threshold <i>This element is only shown in detail mode.</i>
volt-high-warn	Parameter type: <Alarm::NTNTIOVOLHIWARN> (yes no) Possible values: - yes : voltage is too high than the configured warning high threshold - no : no Miscellaneous environment alarm	current status voltage is too high than the configured warning high threshold <i>This element is only shown in detail mode.</i>
volt-low-warn	Parameter type: <Alarm::NTNTIOVOLLOWARN> (yes no) Possible values: - yes : voltage is too low than the configured warning low threshold	current status voltage is too low than the configured warning low threshold <i>This element is only shown in detail mode.</i>

name	Type	Description
	threshold - no : voltage is ok	
temp-high-warn	Parameter type: <Alarm::NTNTIOTEMPEHIWARN> (yes no) Possible values: - yes : temperature is too high than the configured warning high threshold - no : temperature is ok	current status temperature is too high than the configured warning high threshold <i>This element is only shown in detail mode.</i>
temp-low-warn	Parameter type: <Alarm::NTNTIOTEMPELOWARN> (yes no) Possible values: - yes : temperature is too high than the configured warning low threshold - no : temperature is ok	current status temperature is too low than the configured warning low threshold <i>This element is only shown in detail mode.</i>

103.25 Alarm PPP Cross-Connect Engine TCA Snapshot Status Command

Command Description

This command displays the ppp cross-connect engine TCA snapshot-related alarms.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm snap-shot pppcc-engine-tca [ (index) ]
```

Command Parameters

Table 103.25-1 "Alarm PPP Cross-Connect Engine TCA Snapshot Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm snapshot table index

Command Output

Table 103.25-2 "Alarm PPP Cross-Connect Engine TCA Snapshot Status Command" Display parameters

Specific Information		
name	Type	Description
engine	Parameter type: <Vlan::StackedVlanSigned> (<Vlan::UVlanIndex> stacked : <Vlan::SVlanIndex> : <Vlan::CVlanIndex>) Possible values: - stacked : stacked vlan identity Field type <Vlan::UVlanIndex> - unstacked vlan identity - range: [1...4093,4096] Field type <Vlan::SVlanIndex> - service vlan identity - range: [2...4093,4094] Field type <Vlan::CVlanIndex> - customer vlan identity - range: [0...4093,4094,4095,4096]	this is the ppp-cc engine number <i>This element is only shown in detail mode.</i>

Only Show Details: pppoe cross-connect engine tca alarms		
name	Type	Description
pppcce-trans-15min-tca	Parameter type: <Alarm::PPPCCETRANS15MIN> (yes no) Possible values: - yes : 15 minutes transaction timeout count exceeds configured TCA - no : 15 minutes transaction timeout count is OK	current 15 minutes transaction timeout count exceeds configured tca <i>This element is only shown in detail mode.</i>
pppcce-sess-15min-tca	Parameter type: <Alarm::PPPCCESESS15MIN> (yes no) Possible values: - yes : 15 minutes session timeout count exceeds configured TCA - no : 15 minutes session timeout count is OK	15 minutes session timeout count exceeds configured TCA <i>This element is only shown in detail mode.</i>
pppcce-trans-1day-tca	Parameter type: <Alarm::PPPCCETRANS1DAY> (yes no) Possible values: - yes : 1day transaction timeout count exceeds configured TCA - no : 1day transaction timeout count is OK	1day transaction timeout count exceeds configured TCA <i>This element is only shown in detail mode.</i>
pppcce-sess-1day-tca	Parameter type: <Alarm::PPPCCESESS1DAY> (yes no) Possible values: - yes : 1day session timeout count exceeds configured TCA - no : 1day session timeout count is OK	1day session timeout count exceeds configured TCA <i>This element is only shown in detail mode.</i>

103.26 Ellid Alarm Status Command

Command Description

This command displays the ellid current alarm status.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

> show alarm snap-shot ellid [(alarm-index)]

Command Parameters

Table 103.26-1 "Ellid Alarm Status Command" Resource Parameters

Resource Identifier	Type	Description
(alarm-index)	Format: - index of a current alarm entry	alarm snapshot table index

Command Output

Table 103.26-2 "Ellid Alarm Status Command" Display parameters

Specific Information		
name	Type	Description
last-updated-on	Parameter type: <Sys::timeInSecs> - the time (yyyy-mm-dd:hour:minutes:secs) - unit: UTC	network time in seconds when the alarm was logged. <i>This element is only shown in detail mode.</i>
ellid-index	Parameter type: <Itf::ComplexPortType> (xdsl-line : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> voicefxs : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> xdsl-channel : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> atm-if : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> atm-pvc : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::VpiId> : <Eqpt::VciId> bridge-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::VpiId> : <Eqpt::VciId>	this is the epon id for Snapshot alarms. <i>This element is only shown in detail mode.</i>

name	Type	Description
	<pre> vlan-port:ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / <Eqpt::Ng2OntSlotId> / <Eqpt::Ng2OntPortId> : <Eqpt::UnstackedVlan> l2-vlan : <Eqpt::VlanId> ip : <Eqpt::LogicalId> sw-loopback slip uni:ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / <Eqpt::Ng2OntSlotId> / <Eqpt::Ng2OntPortId> vlan-port:ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / <Eqpt::Ng2OntSlotId> / <Eqpt::Ng2OntPortId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> atm-bonding : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> bonding : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> ip-gateway : <Eqpt::VrId> ip-line : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::VpiId> : <Eqpt::VciId> ip-line : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> shdsl-line : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> e1-line : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> atm-ima : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> ethernet-line : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> bridge-port:ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / vuni vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::VpiId> : <Eqpt::VciId> : <Eqpt::UnstackedVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::UnstackedVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::VpiId> : <Eqpt::VciId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> voip:ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> ip-line : vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::VpiId> : <Eqpt::VciId> : <Eqpt::UnstackedVlan> ip-line : vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::UnstackedVlan> ip-line : vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::VpiId> : <Eqpt::VciId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> ip-line : vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : stacked : <Eqpt::SVlan> : </pre>	

name	Type	Description
	<pre> <Eqpt::CVlan> vlan-port:ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / vuni : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan-port:ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / vuni : <Eqpt::UnstackedVlan> chgroup : <Eqpt::ChannelGroupId> subchgroup : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> bridge-port:ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / <Eqpt::Ng2OntSlotId> / <Eqpt::Ng2OntPortId> atm-pvc : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> bridge-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> bridge-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> / <Eqpt::OntPortId> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> / <Eqpt::OntPortId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> / <Eqpt::OntPortId> : <Eqpt::UnstackedVlan> pon : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> ont : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> uni : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> / <Eqpt::OntPortId> bridge-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / voip bridge-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / vuni vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / voip : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / vuni : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / voip : <Eqpt::UnstackedVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / vuni : <Eqpt::UnstackedVlan> voip : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> la-group : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / </pre>	

name	Type	Description
	<pre> <Eqpt::LLId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> bridge-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::LLId> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::LLId> : <Eqpt::UnstackedVlan> mpm : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::ComboPonId> x-pon : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::XPonId> 25g-pon : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::M25GPonId> dist-router-interface : slot-stacked : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::SVlan> : <Eqpt::CVlan> dist-router-interface : slot-vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::UnstackedVlan> bundle : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::BundleId> chpair : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::ChannelPairId> ont.ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId>) Possible values: - xdsl-line : a static xdsl line interface - xdsl-channel : a static xdsl channel interface - atm-if : a static atm interface - atm-pvc : an atm pvc interface - bridge-port : a vlan bridge-port - bridge-port.ng2 : a ngpon2 vlan bridge-port - l2-vlan : a l2-vlan interface - ip : an ip interface - sw-loopback : a software loopback interface - slip : a slip interface - atm-bonding : atm bonding obsolete alternative replaced by bonding - bonding : bonding - ip-gateway : ip user gateway interface - ip-line : ip line interface - shdsl-line : a static shdsl line interface - e1-line : a e1 line interface - atm-ima : atm ima - ethernet-line : an ethernet line interface - vlan-port : vlan port - vlan-port.ng2 : a ngpon2 vlan port - pon : pon - x-pon : xgs pon - 25g-pon : 25g pon - chpair : channelpair - chgroup : channelgroup - subchgroup : subchannelgroup - bundle : bundle - ont : ont - ont.ng2 : ngpon2 ONT style identification - uni : uni - uni.ng2 : ngpon2 UNI style identification </pre>	

103 Alarm Snap-shot Status Commands

name	Type	Description
	- voip : voip - voip:ng2 : voip - la-group : link aggregation group - dist-router-interface : dist router interface - voicefxs : voicefxs - mpm : multi-pon module Possible values: - vlan : vlan port Possible values: - slot-vlan : slot unstacked - slot-stacked : slot vlan port Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number Field type <Eqpt::VpiId> - atm VPI Field type <Eqpt::VciId> - atm VCI Field type <Eqpt::PonId> - the PON identifier Field type <Eqpt::XPonId> - the XGS PON identifier Field type <Eqpt::M25GPonId> - the 25G PON identifier Field type <Eqpt::ComboPonId> - the comboPON identifier Field type <Eqpt::ChannelPairId> - the channel pair identifier Field type <Eqpt::ChannelGroupId> - the channel group identifier Field type <Eqpt::SubChannelGroupId> - the subchannel group identifier Field type <Eqpt::BundleId> - the BUNDLE identifier Field type <Eqpt::OntId> - the ONT identifier Field type <Eqpt::Ng2OntId> - the NG2 ONT identifier Possible values: - voip : virtual uni identifier obsolete alternative replaced by vuni - vuni : virtual uni identifier Possible values: - vuni : virtual NGPON2 uni identifier Field type <Eqpt::OntSlotId> - the ONT SLOT identifier Field type <Eqpt::OntPortId> - the ONT PORT identifier Field type <Eqpt::Ng2OntSlotId> - the NGPON2 ONT SLOT identifier Field type <Eqpt::Ng2OntPortId> - the NGPON2 ONT PORT identifier	

name	Type	Description
	Field type <Eqpt::LLId> - the LLID identifier, range 1 for EPON, range 1-8 for DPOE Possible values: - stacked : stacked vlan identity Field type <Eqpt::UnstackedVlan> - unstacked vlan id Field type <Eqpt::SVlan> - service vlan id Field type <Eqpt::CVlan> - customer vlan id Field type <Eqpt::VlanId> - VLAN id Field type <Eqpt::LogicalId> - logical id Field type <Eqpt::VrflId> - VRF id	

Only Show Details: ellid alarms		
name	Type	Description
key-fail-one-churn	Parameter type: <alarm::keyfailone> (yes no) Possible values: - yes : key exchange failure during one churning time - no : key exchange failure during one churning time is ok	key exchange failure during one churning time <i>This element is only shown in detail mode.</i>
key-fail-three-churn	Parameter type: <alarm::keyfailthree> (yes no) Possible values: - yes : key exchange failure during three churning time - no : key exchange failure during three churning time is ok	key exchange failure during three churning time <i>This element is only shown in detail mode.</i>
oam-discov-fail	Parameter type: <alarm::oamext> (yes no) Possible values: - yes : extend oam discovery failure - no : extend oam discovery failure is ok	extend oam discovery failure <i>This element is only shown in detail mode.</i>
report-timeout	Parameter type: <alarm::timeout> (yes no) Possible values: - yes : report timeout detecting - no : report timeout detecting is ok	report timeout detecting <i>This element is only shown in detail mode.</i>
total-packets-exceed	Parameter type: <alarm::totalexceed> (yes no) Possible values: - yes : total amount of protocol packets exceed threshold - no : total amount of protocol packets is ok	total amount of protocol packets exceed threshold <i>This element is only shown in detail mode.</i>
arp-packets-exceed	Parameter type: <alarm::arpexceed> (yes no) Possible values: - yes : protocol arp packets exceed threshold - no : protocol arp packets is ok	protocol arp packets exceed threshold <i>This element is only shown in detail mode.</i>
dhcp-packets-exceed	Parameter type: <alarm::dhcpxceed> (yes no)	protocol dhcp packets exceed threshold <i>This element is only shown in</i>

103 Alarm Snap-shot Status Commands

name	Type	Description
	Possible values: - yes : protocol dhcp packets exceed threshold - no : protocol dhcp packets is ok	<i>detail mode.</i>
igmp-packets-exceed	Parameter type: <alarm::igmpexceed> (yes no) Possible values: - yes : protocol igmp packets exceed threshold - no : protocol igmp packets is ok	protocol igmp packets exceed threshold <i>This element is only shown in detail mode.</i>
pppoe-packets-exceed	Parameter type: <alarm::pppoeexceed> (yes no) Possible values: - yes : protocol pppoe packets exceed threshold - no : protocol pppoe packets is ok	protocol pppoe packets exceed threshold <i>This element is only shown in detail mode.</i>
nd-packets-exceed	Parameter type: <alarm::ndexceed> (yes no) Possible values: - yes : protocol nd packets exceed threshold - no : protocol nd packets is ok	protocol nd packets exceed threshold <i>This element is only shown in detail mode.</i>
icmpv6-packets-exceed	Parameter type: <alarm::icmpexceed> (yes no) Possible values: - yes : protocol icmp packets exceed threshold - no : protocol icmp packets is ok	protocol icmpv6 packets exceed threshold <i>This element is only shown in detail mode.</i>
mld-packets-exceed	Parameter type: <alarm::mldexceed> (yes no) Possible values: - yes : protocol igmp packets exceed threshold - no : protocol igmp packets is ok	protocol mld packets exceed threshold <i>This element is only shown in detail mode.</i>
dhcpv6-packets-exceed	Parameter type: <alarm::dhcpv6exceed> (yes no) Possible values: - yes : protocol dhcpv6 packets exceed threshold - no : protocol dhcpv6 packets is ok	protocol dhcpv6 packets exceed threshold <i>This element is only shown in detail mode.</i>
cfm-packets-exceed	Parameter type: <alarm::cfmexceed> (yes no) Possible values: - yes : protocol cfm packets exceed threshold - no : protocol cfm packets is ok	protocol cfm packets exceed threshold <i>This element is only shown in detail mode.</i>

103.27 2xE1/DS1 SFP Clock Snapshot Status Command

Command Description

This command displays the 2xE1/DS1 SFP Clock Snapshot-related alarms.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm snap-shot sfpe1t1-clock [ (index) ]
```

Command Parameters

Table 103.27-1 "2xE1/DS1 SFP Clock Snapshot Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm type

Command Output

Table 103.27-2 "2xE1/DS1 SFP Clock Snapshot Status Command" Display parameters

Specific Information		
name	Type	Description
alarm index 1	Parameter type: <Alarm::SlotIndex> (lt : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> nt-a nt-b nt acu : <Eqpt::RackId> / <Eqpt::ShelfId> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::EqSlotId> ext-a : <Eqpt::RackId> / <Eqpt::ShelfId> ext-b : <Eqpt::RackId> / <Eqpt::ShelfId> ctrl : <Eqpt::RackId> / <Eqpt::ShelfId> iont : <Eqpt::RackId> / <Eqpt::ShelfId> lp : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::LtAppliqueSlotId> ntio-1 ntio-2 vlt : <Eqpt::RackId> / <Eqpt::ShelfId> /	this is the nt/ntio slot id for host alarms. <i>This element is only shown in detail mode.</i>

103 Alarm Snap-shot Status Commands

name	Type	Description
	<Eqpt::VirtualSlotId>) Possible values: - lt : lt-slot - vlt : virtual LT slot (VVPS board can only be planned at NANT-E/FANT-F) - nt-a : nt-a slot - nt-b : nt-b slot - nt : nt slot - ext-a : nt-a slot in an extension shelf - ext-b : nt-b slot in an extension shelf - acu : acu slot - ctrl : ctrl-slot - iont : an nt applique slot - lp : an lt applique slot - ntio-1 : an nt applique slot in a single or multiple-ntio-shelf - ntio-2 : an nt applique slot in a multiple-ntio-shelf Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::LtAppliqueSlotId> - the LT Applique slot number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::VirtualSlotId> - the virtual LT slot number Field type <Eqpt::EqSlotId> - the equipment slot number	
alarm index 2	Parameter type: <Alarm::e1t1Port> (sfp : <Alarm::E1t1FramerPort> xfp : <Alarm::E1t1FramerPort>) Possible values: - sfp : e1t1 sfp port - xfp : e1t1 xfp port Field type <Alarm::E1t1FramerPort> - value - range: [0...35]	this is the host sfp faceplate number <i>This element is only shown in detail mode.</i>

Only Show Details: e1t1 sfp clock alarms		
name	Type	Description
dsx1-serdes-fail	Parameter type: <Alarm::DSX1SERDESFAIL> (yes no) Possible values: - yes : SERDES clock failure alarm - no : SERDES Clock no failure	SERDES clock alarm failure <i>This element is only shown in detail mode.</i>
dsx1-tributary1-fail	Parameter type: <Alarm::DSX1TRIB1FAIL> (yes no) Possible values: - yes : Tributary 1 clock failure alarm - no : Tributary 1 clock no failure	tributary 1 clock failure alarm <i>This element is only shown in detail mode.</i>
dsx1-tributary2-fail	Parameter type: <Alarm::DSX1TRIB2FAIL> (yes no) Possible values: - yes : Tributary 2 clock failure alarm - no : Tributary 2 clock no failure	tributary 2 clock failure alarm <i>This element is only shown in detail mode.</i>

name	Type	Description
dsx1-los-fail	Parameter type: <Alarm::DSX1LOSFAIL> (yes no) Possible values: - yes : All selected tributaries in Loss Of Signal - no : No All selected tributaries in Loss Of Signal	all selected tributaries in loss of signal <i>This element is only shown in detail mode.</i>
dsx1-ais-sync	Parameter type: <Alarm::DSX1AISFAIL> (yes no) Possible values: - yes : Alarm Indication Signal on the tributary selected sync source - no : No Alarm Indication Signal on the tributary selected sync source	alarm indication signal on the tributary selected as sync source <i>This element is only shown in detail mode.</i>
dsx1-lof-sync	Parameter type: <Alarm::DSX1LOFSYNCFAIL> (yes no) Possible values: - yes : Loss of Frame on the tributary selected sync source - no : No Loss of Frame on the tributary selected sync source	loss of frame on the tributary selected as sync source <i>This element is only shown in detail mode.</i>
dsx1-los-sync	Parameter type: <Alarm::DSX1LOSSYNCFAIL> (yes no) Possible values: - yes : Loss of Signal on the tributary selected sync source - no : No Loss of Signal on the tributary selected sync source	loss of signal on the tributary selected as sync source <i>This element is only shown in detail mode.</i>
dsx1-deg-fail	Parameter type: <Alarm::DSX1DEGFAIL> (yes no) Possible values: - yes : Signal degrade alarm - no : Signal degrade alarm	signal degrade alarm <i>This element is only shown in detail mode.</i>

103.28 2xE1/DS1 SFP Framer Snapshot Status Command

Command Description

This command displays the 2xE1/DS1 SFP Framer snapshot-related alarms.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm snap-shot sfpe1t1-framer [ (index) ]
```

Command Parameters

Table 103.28-1 "2xE1/DS1 SFP Framer Snapshot Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm type

Command Output

Table 103.28-2 "2xE1/DS1 SFP Framer Snapshot Status Command" Display parameters

Specific Information		
name	Type	Description
alarm index 1	Parameter type: <Alarm::SlotIndex> (lt : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> nt-a nt-b nt acu : <Eqpt::RackId> / <Eqpt::ShelfId> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::EqSlotId> ext-a : <Eqpt::RackId> / <Eqpt::ShelfId> ext-b : <Eqpt::RackId> / <Eqpt::ShelfId> ctrl : <Eqpt::RackId> / <Eqpt::ShelfId> iont : <Eqpt::RackId> / <Eqpt::ShelfId> lp : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::LtAppliqueSlotId> ntio-1 ntio-2 vlt : <Eqpt::RackId> / <Eqpt::ShelfId> /	this is the nt/ntio slot id for host alarms. <i>This element is only shown in detail mode.</i>

name	Type	Description
	<Eqpt::VirtualSlotId>) Possible values: - lt : lt-slot - vlt : virtual LT slot (VVPS board can only be planned at NANT-E/FANT-F) - nt-a : nt-a slot - nt-b : nt-b slot - nt : nt slot - ext-a : nt-a slot in an extension shelf - ext-b : nt-b slot in an extension shelf - acu : acu slot - ctrl : ctrl-slot - iont : an nt applique slot - lp : an lt applique slot - ntio-1 : an nt applique slot in a single or multiple-ntio-shelf - ntio-2 : an nt applique slot in a multiple-ntio-shelf Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::LtAppliqueSlotId> - the LT Applique slot number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::VirtualSlotId> - the virtual LT slot number Field type <Eqpt::EqSlotId> - the equipment slot number	
alarm index 2	Parameter type: <Alarm::e1t1framerPort> (sfp : <Alarm::E1t1FramerPort> : <Alarm::tributary> xfp : <Alarm::E1t1FramerPort> : <Alarm::tributary>) Possible values: - sfp : e1t1 sfp port - xfp : e1t1 xfp port Field type <Alarm::E1t1FramerPort> - value - range: [0...35] Field type <Alarm::tributary> - value - range: [1...2]	this is the host sfp faceplate number <i>This element is only shown in detail mode.</i>

Only Show Details: e1t1 framer alarms		
name	Type	Description
rei-from-liu	Parameter type: <Alarm::DSX1REILIU> (yes no) Possible values: - yes : e1t1 sfp Remote Error Indication Alarm from LIU - no : No e1t1 sfp Remote Error Indication Alarm from LIU	remote error indication alarm from LIU <i>This element is only shown in detail mode.</i>
rdi-from-liu	Parameter type: <Alarm::DSX1RDILIU> (yes no) Possible values: - yes : e1t1 sfp Remote Defect Alarmn from LIU - no : No e1t1 sfp Remote Defect Alarmn from LIU	remote defect indication alarm from LIU <i>This element is only shown in detail mode.</i>
crc6-from-liu	Parameter type: <Alarm::DSX1CRC6LIU> (yes no)	cyclic redundancy check 6 from LIU <i>This element is only shown in</i>

103 Alarm Snap-shot Status Commands

name	Type	Description
	Possible values: - yes : e1t1 sfp Cyclic Redundancy Check 6 from LIU - no : No e1t1 sfp Cyclic Redundancy Check 6 from LIU	<i>detail mode.</i>
crc4-from-liu	Parameter type: <Alarm::DSX1CRC4LIU> (yes no) Possible values: - yes : e1t1 sfp Cyclic Redundancy Check 4 from LIU - no : No e1t1 sfp Cyclic Redundancy Check 4 from LIU	cyclic redundancy check 4 from LIU <i>This element is only shown in detail mode.</i>
crc4-threshold-from-liu	Parameter type: <Alarm::DSX1CRC4THLIU> (yes no) Possible values: - yes : e1t1 sfp Cyclic Redundancy Check 4 threshold alarm from LIU - no : No e1t1 sfp Cyclic Redundancy Check 4 threshold alarm from LIU	cyclic redundancy check 4 threshold alarm from LIU <i>This element is only shown in detail mode.</i>
ais-from-liu	Parameter type: <Alarm::DSX1AISLIU> (yes no) Possible values: - yes : e1t1 sfp Alarm Indication Signal alarm from LIU - no : No e1t1 sfp Alarm Indication Signal alarm from LIU	alarm indication signal alarm from LIU <i>This element is only shown in detail mode.</i>
los-from-liu	Parameter type: <Alarm::DSX1LOSLIU> (yes no) Possible values: - yes : e1t1 sfp Loss of signal alarm from LIU - no : No e1t1 sfp Loss of signal alarm from LIU	loss of signal alarm from LIU <i>This element is only shown in detail mode.</i>
lof-from-liu	Parameter type: <Alarm::DSX1LOFLIU> (yes no) Possible values: - yes : e1t1 sfp Loss of frame alarm from LIU - no : No e1t1 sfp Loss of frame alarm from LIU	loss of frame alarm from LIU <i>This element is only shown in detail mode.</i>
lomf-from-liu	Parameter type: <Alarm::DSX1LOMFLIU> (yes no) Possible values: - yes : e1t1 sfp Loss of multi frame alarm from LIU - no : No e1t1 sfp Loss of multi frame alarm from LIU	loss of multi frame alarm from LIU <i>This element is only shown in detail mode.</i>
rei-from-iwf	Parameter type: <Alarm::DSX1REIIWF> (yes no) Possible values: - yes : e1t1 sfp Remote Error Indication Alarm from IWF - no : No e1t1 sfp Remote Error Indication Alarm from IWF	remote error indication alarm from IWF <i>This element is only shown in detail mode.</i>
rdi-from-iwf	Parameter type: <Alarm::DSX1RDIIWF> (yes no) Possible values: - yes : e1t1 sfp Remote Defect Alarm from IWF - no : No e1t1 sfp Remote Defect Alarm from IWF	remote defect indication alarm from IWF <i>This element is only shown in detail mode.</i>
crc6-from-iwf	Parameter type: <Alarm::DSX1CRC6IWF> (yes no) Possible values:	cyclic redundancy check 6 from IWF <i>This element is only shown in detail mode.</i>

name	Type	Description
	- yes : e1t1 sfp Cyclic Redundancy Check 6 from IWF - no : No e1t1 sfp Cyclic Redundancy Check 6 from IWF	
crc4-from-iwf	Parameter type: <Alarm::DSX1CRC4IWF> (yes no) Possible values: - yes : e1t1 sfp Cyclic Redundancy Check 4 from IWF - no : No e1t1 sfp Cyclic Redundancy Check 4 from IWF	cyclic redundancy check 4 from IWF <i>This element is only shown in detail mode.</i>
crc4-threshold-from-iwf	Parameter type: <Alarm::DSX1CRC4THIWF> (yes no) Possible values: - yes : e1t1 sfp Cyclic Redundancy Check 4 threshold alarm from IWF - no : No e1t1 sfp Cyclic Redundancy Check 4 threshold alarm from IWF	cyclic redundancy check 4 threshold alarm from IWF <i>This element is only shown in detail mode.</i>
ais-from-iwf	Parameter type: <Alarm::DSX1AISIWF> (yes no) Possible values: - yes : e1t1 sfp Alarm Indication Signal alarm from IWF - no : No e1t1 sfp Alarm Indication Signal alarm from IWF	alarm indication signal alarm from IWF <i>This element is only shown in detail mode.</i>
los-from-iwf	Parameter type: <Alarm::DSX1LOSIWF> (yes no) Possible values: - yes : e1t1 sfp Loss of signal alarm from IWF - no : No e1t1 sfp Loss of signal alarm from IWF	loss of signal alarm from IWF <i>This element is only shown in detail mode.</i>
lof-from-iwf	Parameter type: <Alarm::DSX1LOFIWF> (yes no) Possible values: - yes : e1t1 sfp Loss of frame alarm from IWF - no : No e1t1 sfp Loss of frame alarm from IWF	loss of frame alarm from IWF <i>This element is only shown in detail mode.</i>
lomf-from-iwf	Parameter type: <Alarm::DSX1LOMFIWF> (yes no) Possible values: - yes : e1t1 sfp Loss of multi frame alarm from IWF - no : No e1t1 sfp Loss of multi frame alarm from IWF	loss of multi frame alarm from LIU <i>This element is only shown in detail mode.</i>

103.29 Epon Olt Sfp RSSI Snapshot Alarm Status Command

Command Description

This command displays the Epon Olt Sfp RSSI Snapshot alarm.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm snap-shot eoltrssi [ (index) ]
```

Command Parameters

Table 103.29-1 "Epon Olt Sfp RSSI Snapshot Alarm Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm snapshot table index

Command Output

Table 103.29-2 "Epon Olt Sfp RSSI Snapshot Alarm Status Command" Display parameters

Specific Information		
name	Type	Description
epon id	Parameter type: <Epon::PonId> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier	this is the epon id for Snapshot alarms. <i>This element is only shown in detail mode.</i>
Only Show Details: epon olt sfp rssi diagnostic threshold control alarms		
name	Type	Description
eolt-tpwr-hi-alm	Parameter type: <Alarm::OLTTXPWHI> (yes no)	Snapshot status Tx optical power is too high than the configured alarm high threshold

name	Type	Description
	Possible values: - yes : Olt sfp Tx power is higher than the configured alarm high threshold - no : Olt sfp Tx power current is ok	<i>This element is only shown in detail mode.</i>
eolt-txpwr-lw-alm	Parameter type: <Alarm::OLTTPWLO> (yes no) Possible values: - yes : Olt sfp Tx power is lower than the configured alarm low threshold - no : Olt sfp Tx power current is ok	Snapshot status Tx optical power is too low than the configured alarm low threshold <i>This element is only shown in detail mode.</i>
eolt-txbias-hi-alm	Parameter type: <Alarm::OLTTXBIASHI> (yes no) Possible values: - yes : Olt sfp Bias is higher than the configured alarm high threshold - no : Olt sfp Bias current is ok	Snapshot status Bias is too high than the configured alarm high threshold <i>This element is only shown in detail mode.</i>
eolt-txbias-lw-alm	Parameter type: <Alarm::OLTTXBIASLO> (yes no) Possible values: - yes : Olt sfp Bias is lower than the configured alarm low threshold - no : Olt sfp Bias current is ok	Snapshot status Bias is too low than the configured alarm low threshold <i>This element is only shown in detail mode.</i>
eolt-volt-hi-alm	Parameter type: <Alarm::OLTVOLHI> (yes no) Possible values: - yes : Olt sfp voltage is higher than the configured alarm high threshold - no : Olt sfp voltage current is ok	Snapshot status voltage is too high than the configured alarm high threshold <i>This element is only shown in detail mode.</i>
eolt-volt-lw-alm	Parameter type: <Alarm::OLTVOLLO> (yes no) Possible values: - yes : Olt sfp voltage is lower than the configured alarm low threshold - no : Olt sfp voltage current is ok	Snapshot status voltage is too low than the configured alarm low threshold <i>This element is only shown in detail mode.</i>
eolt-temp-hi-alm	Parameter type: <Alarm::OLTTEMPEHI> (yes no) Possible values: - yes : Olt sfp temperature is higher than the configured alarm high threshold - no : Olt sfp temperature current is ok	Snapshot status temperature is too high than the configured alarm high threshold <i>This element is only shown in detail mode.</i>
eolt-temp-lw-alm	Parameter type: <Alarm::OLTTEMPELO> (yes no) Possible values: - yes : Olt sfp temperature is lower than the configured alarm low threshold - no : Olt sfp temperature current is ok	Snapshot status temperature is too low than the configured alarm low threshold <i>This element is only shown in detail mode.</i>
eolt-txpwr-hi-warn	Parameter type: <Alarm::OLTTPWHIWARN> (yes no) Possible values:	Snapshot status Tx optical power is too high than the configured warning high threshold <i>This element is only shown in</i>

103 Alarm Snap-shot Status Commands

name	Type	Description
	- yes : Olt sfp Tx power is higher than the configured warning high threshold - no : Olt sfp Tx power current is ok	<i>detail mode.</i>
eolt-txpwr-lw-warn	Parameter type: <Alarm::OLTTPWLOWARN> (yes no) Possible values: - yes : Olt sfp Tx power is lower than the configured warning low threshold - no : Olt sfp Tx power current is ok	Snapshot status Tx optical power is too low than the configured warning low threshold <i>This element is only shown in detail mode.</i>
eolt-txbias-hi-warn	Parameter type: <Alarm::OLTTXBIASHIWARN> (yes no) Possible values: - yes : Olt sfp Bias is higher than the configured warning high threshold - no : Olt sfp Bias current is ok	Snapshot status bias is too high than the configured warning high threshold <i>This element is only shown in detail mode.</i>
eolt-txbias-lw-warn	Parameter type: <Alarm::OLTTXBIASLOWARN> (yes no) Possible values: - yes : Olt sfp Bias is lower than the configured warning low threshold - no : Olt sfp Bias current is ok	Snapshot status bias is too low than the configured warning low threshold <i>This element is only shown in detail mode.</i>
eolt-volt-hi-warn	Parameter type: <Alarm::OLTVOLHIWARN> (yes no) Possible values: - yes : Olt sfp voltage is higher than the configured warning high threshold - no : Olt sfp voltage current is ok	Snapshot status voltage is too low than the configured warning high threshold <i>This element is only shown in detail mode.</i>
eolt-volt-lw-warn	Parameter type: <Alarm::OLTVOLLOWARN> (yes no) Possible values: - yes : Olt sfp voltage is lower than the configured warning low threshold - no : Olt sfp voltage current is ok	Snapshot status voltage is too low than the configured warning low threshold <i>This element is only shown in detail mode.</i>
eolt-temp-hi-warn	Parameter type: <Alarm::OLTTEMPEHIWARN> (yes no) Possible values: - yes : Olt sfp temperature is higher than the configured warning high threshold - no : Olt sfp temperature current is ok	Snapshot status temperature is too high than the configured warning high threshold <i>This element is only shown in detail mode.</i>
eolt-temp-lw-warn	Parameter type: <Alarm::OLTTEMPELOWARN> (yes no) Possible values: - yes : Olt sfp temperature is lower than the configured warning low threshold - no : Olt sfp temperature current is ok	Snapshot status temperature is too low than the configured warning low threshold <i>This element is only shown in detail mode.</i>
eolt-xfp-txpwr-hi-alm	Parameter type: <Alarm::OLTEXTTPWHI> (yes no) Possible values: - yes : Olt xfp Tx power is higher than the configured alarm	Snapshot status Xfp Tx optical power is too high than the configured alarm high threshold <i>This element is only shown in detail mode.</i>

name	Type	Description
	high threshold - no : Olt xfp Tx power current is ok	
eolt-xfp-txpwr-lw-alm	Parameter type: <Alarm::OLTEXTTXPWLO> (yes no) Possible values: - yes : Olt xfp Tx power is lower than the configured alarm low threshold - no : Olt xfp Tx power current is ok	Snapshot status Xfp Tx optical power is too low than the configured alarm low threshold <i>This element is only shown in detail mode.</i>
eolt-xfp-bias-hi-alm	Parameter type: <Alarm::OLTEXTTXBIASHI> (yes no) Possible values: - yes : Olt xfp Bias is higher than the configured alarm high threshold - no : Olt xfp Bias current is ok	Snapshot status Xfp bias is too high than the configured alarm high threshold <i>This element is only shown in detail mode.</i>
eolt-xfp-bias-lw-alm	Parameter type: <Alarm::OLTEXTTXBIASLO> (yes no) Possible values: - yes : Olt xfp Bias is lower than the configured alarm low threshold - no : Olt xfp Bias current is ok	Snapshot status Xfp bias is too low than the configured alarm low threshold <i>This element is only shown in detail mode.</i>
eolt-xfp-txpwr-hi-warn	Parameter type: <Alarm::OLTEXTTXPWHIWARN> (yes no) Possible values: - yes : Olt xfp Tx power is higher than the configured warning high threshold - no : Olt xfp Tx power current is ok	Snapshot status Xfp Tx optical power is too high than the configured warning high threshold <i>This element is only shown in detail mode.</i>
eolt-xfp-txpwr-lw-warn	Parameter type: <Alarm::OLTEXTTXPWLOWARN> (yes no) Possible values: - yes : Olt xfp Tx power is lower than the configured warning low threshold - no : Olt xfp Tx power current is ok	Snapshot status Xfp Tx optical power is too low than the configured warning low threshold <i>This element is only shown in detail mode.</i>
eolt-xfp-bias-hi-warn	Parameter type: <Alarm::OLTEXTTXBIASHIWARN> (yes no) Possible values: - yes : Olt xfp Bias is higher than the configured warning high threshold - no : Olt xfp Bias current is ok	Snapshot status Xfp bias is too high than the configured warning high threshold <i>This element is only shown in detail mode.</i>
eolt-xfp-bias-lw-warn	Parameter type: <Alarm::OLTEXTTXBIASLOWARN> (yes no) Possible values: - yes : Olt xfp Bias is lower than the configured warning low threshold - no : Olt xfp Bias current is ok	Snapshot status Xfp bias is too low than the configured warning low threshold <i>This element is only shown in detail mode.</i>

103.30 Alarm Plug In Unit Extended Snap Shot Status Command

Command Description

This command shows the alarm snap shot status for the extended plug in unit.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm snap-shot plug-in-unit-ext [ (index) ]
```

Command Parameters

Table 103.30-1 "Alarm Plug In Unit Extended Snap Shot Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm snapshot table index

Command Output

Table 103.30-2 "Alarm Plug In Unit Extended Snap Shot Status Command" Display parameters

Specific Information		
name	Type	Description
board-position	Parameter type: <Equipm::SlotIndex> (lt : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> nt-a nt-b nt acu : <Eqpt::RackId> / <Eqpt::ShelfId> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::EqSlotId> ext-a : <Eqpt::RackId> / <Eqpt::ShelfId> ext-b : <Eqpt::RackId> / <Eqpt::ShelfId> ctrl : <Eqpt::RackId> / <Eqpt::ShelfId> vlt : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::VirtualSlotId>) Possible values: - lt : lt-slot - vlt : virtual LT slot (VVPS board can only be planned at NANT-E / FANT-F)	identify where the alarm has occurred. <i>This element is only shown in detail mode.</i>

name	Type	Description
	- nt-a : nt-a slot - nt-b : nt-b slot - nt : nt slot - ext-a : nt-a slot in an extension shelf - ext-b : nt-b slot in an extension shelf - acu : acu slot - ctrl : ctrl-slot Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::VirtualSlotId> - the virtual LT slot number Field type <Eqpt::EqSlotId> - the equipment slot number	
fan-alarm	Parameter type: <Alarm::pluginFan> (yes no) Possible values: - yes : fan alarm - no : no fan alarm	current status specifying fan alarm is present or not <i>This element is only shown in detail mode.</i>
dc-a-alarm	Parameter type: <Alarm::plugin-dc-a> (yes no) Possible values: - yes : dc a failure alarm - no : no dc a failure alarm	current status specifying dc-a failure alarm is present or not <i>This element is only shown in detail mode.</i>
dc-b-alarm	Parameter type: <Alarm::plugin-dc-b> (yes no) Possible values: - yes : dc b failure alarm - no : no dc b failure alarm	current status specifying dc-b failure alarm is present or not <i>This element is only shown in detail mode.</i>
dg-alarm	Parameter type: <Alarm::plugin-dg> (yes no) Possible values: - yes : dying gasp alarm - no : no dying gasp alarm	current status specifying dying gasp alarm is present or not <i>This element is only shown in detail mode.</i>
apsf-alarm	Parameter type: <Alarm::pluginApsf> (yes no) Possible values: - yes : apsf failure alarm - no : no apsf failure alarm	power for the applique is available or not <i>This element is only shown in detail mode.</i>
ntr-a-loss	Parameter type: <Alarm::NTRALoss> (yes no) Possible values: - yes : ntr-a signal unavailable - no : ntr-a signal available	current status specifying NTR-A loss alarm is present or not <i>This element is only shown in detail mode.</i>
ntr-b-loss	Parameter type: <Alarm::NTRBLoss> (yes no) Possible values:	current status specifying NTR-B loss alarm is present or not <i>This element is only shown in detail mode.</i>

103 Alarm Snap-shot Status Commands

name	Type	Description
	- yes : ntr-b signal unavailable - no : ntr-b signal available	
xvps-conf-loss	Parameter type: <Alarm::XvpsConfLoss> (yes no) Possible values: - yes : implicit xvps configuration loss. - no : no implicit xvps configuration loss.	implicit xvps configuration loss or not. <i>This element is only shown in detail mode.</i>
mac-entry-nofree	Parameter type: <Alarm::MacNofree> (nofree free) Possible values: - nofree : no free mac entry in the mac table on the lt board. - free : file transfer server available.	current status specifying no free mac entry in the mac table on the lt board. <i>This element is only shown in detail mode.</i>
fibre-conn-mismatch	Parameter type: <Alarm::FibreConnMismatch> (yes no) Possible values: - yes : REM fibre connection mismatch alarm - no : no REM fibre connection mismatch alarm	current status specifying fibre connection mismatch on detected control card. <i>This element is only shown in detail mode.</i>
link-cap-mismatch	Parameter type: <Alarm::LinkCapMismatch> (yes no) Possible values: - yes : actual link speed is not inline with the end-to-end link capability between NT and LT - no : actual link speed is inline with the end-to-end link capability between NT and LT	log-status specifies that the actual link speed is not in line with the end-to-end link capability between NT and LT. <i>This element is only shown in detail mode.</i>
eqpt-cap-mismatch	Parameter type: <Alarm::EqptCapMismatch> (yes no) Possible values: - yes : not all equipment between NT and LT can support the speed that NT and LT can support within the configured MaxLinkSpeed. - no : all equipment between NT and LT can support the speed that NT and LT can support within the configured MaxLinkSpeed.	log-status specifies that not all equipment between NT and LT can support the speed that NT and LT can support within the configured MaxLinkSpeed. <i>This element is only shown in detail mode.</i>
ctrl-dnld-failure	Parameter type: <Alarm::CtrlDownloadFailure> (yes no) Possible values: - yes : The downloading of the Software image to the controller card failed.. - no : The downloading of the Software image to the controller card passed.	log-status specifies that the downloading of the Software image to the controller card failed. <i>This element is only shown in detail mode.</i>
melt-hw-issue	Parameter type: <Alarm::BoardHWIssue> (yes no) Possible values: - yes : Board hardware issue - no : No Board hardware issue.	log-status specifies that MELT hardware issue. <i>This element is only shown in detail mode.</i>
melt-board-reset	Parameter type: <Alarm::BoardHWIssue> (yes no) Possible values: - yes : Board hardware issue	log-status specifies that MELT board got reset. <i>This element is only shown in detail mode.</i>

name	Type	Description
	- no : No Board hardware issue.	
board-shelf-mismatch	Parameter type: <Alarm::boardShelfMismatch> (yes no) Possible values: - yes : plugged-in board and shelf type are mismatch - no : plugged-in board and shelf type are match	alarm specifying the shelf type and plugged-in board types are mismatch. <i>This element is only shown in detail mode.</i>
single-fan-fail	Parameter type: <Alarm::SINGLEFANFAILURE> (yes no) Possible values: - yes : single fan failure` - no : no single fan failure	log-status specifies that SINGLE FAN IS FAIL. <i>This element is only shown in detail mode.</i>
multi-fan-fail	Parameter type: <Alarm::MULTIFANFAILURE> (yes no) Possible values: - yes : more than one fan failed - no : NO MULTIPLE fans are failed	log-status specifies that MULTIPLE FAN IS FAIL. <i>This element is only shown in detail mode.</i>
fan-tray-missing	Parameter type: <Alarm::FANTRAYMISSING> (yes no) Possible values: - yes : fan tray missing - no : fans tray is present	log-status specifies that FAN TRAY IS MISSING. <i>This element is only shown in detail mode.</i>

103.31 Alarm Snap-shot SIP Server Status Command

Command Description

This command show the alarm snap-shot of SIP Server

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

> show alarm snap-shot sip-server [(index)]

Command Parameters

Table 103.31-1 "Alarm Snap-shot SIP Server Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm type

Command Output

Table 103.31-2 "Alarm Snap-shot SIP Server Status Command" Display parameters

Specific Information		
name	Type	Description
transport-mismatch	Parameter type: <Alarm::transportMismatch> (yes no) Possible values: - yes : mismatch - no : not mismatch	specifies isamv and server transport mismatch or not. <i>This element is only shown in detail mode.</i>
dns-lookup-failure	Parameter type: <Alarm::dnsLookUpFailure> (yes no) Possible values: - yes : fail - no : not fail	specifies dns look up fail or not. <i>This element is only shown in detail mode.</i>

103.32 Alarm Snap-shot SIP VSP Status Command

Command Description

This command show the alarm snap-shot of SIP VSP

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

> show alarm snap-shot sip-vsp [(index)]

Command Parameters

Table 103.32-1 "Alarm Snap-shot SIP VSP Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm type

Command Output

Table 103.32-2 "Alarm Snap-shot SIP VSP Status Command" Display parameters

Specific Information		
name	Type	Description
none-dns-srv	Parameter type: <Alarm::noneDNSSRV> (yes no) Possible values: - yes : none of dns server give reply to to DNS look up - no : dns server give reply to to DNS look up	specifies none of dns server give reply to to DNS look up or not. <i>This element is only shown in detail mode.</i>
no-dns-srv	Parameter type: <Alarm::noDNSSRV> (yes no) Possible values: - yes : no dns server configured when sip request - no : dns server configured when sip request	specifies no dns server configured when sip request or not. <i>This element is only shown in detail mode.</i>
none-srv	Parameter type: <Alarm::noneSRV> (yes no) Possible values: - yes : none sip server give reply when send sip request - no : sip server give reply when send sip request	specifies none sip server give reply when send sip request or not. <i>This element is only shown in detail mode.</i>
no-srv	Parameter type: <Alarm::noSRV>	specifies no sip proxy server

103 Alarm Snap-shot Status Commands

name	Type	Description
	(yes no) Possible values: - yes : no sip proxy server configured when send sip request - no : sip proxy server configured when send sip request	configured when send sip request or not. <i>This element is only shown in detail mode.</i>
reg-srv-unreach	Parameter type: <Alarm::noRegSRV> (yes no) Possible values: - yes : no sip register server give reply when send sip register - no : sip register server give reply when send sip register	specifies no sip register servers give reply when send sip register or not. <i>This element is only shown in detail mode.</i>
prxy-srv-unreach	Parameter type: <Alarm::noPrxySRV> (yes no) Possible values: - yes : no sip proxy server give reply when send sip request - no : sip proxy server give reply when send sip request	specifies no sip proxy servers give reply when send sip request or not. <i>This element is only shown in detail mode.</i>
fo-trigger	Parameter type: <Alarm::foTrigger> (yes no) Possible values: - yes : fail over triggered - no : fail over is not triggered	specifies fail-over is triggered or not. <i>This element is only shown in detail mode.</i>
fb-trigger	Parameter type: <Alarm::fbTrigger> (yes no) Possible values: - yes : fail back triggered - no : fail back is not triggered	specifies fail-back is triggered or not. <i>This element is only shown in detail mode.</i>
du-trigger	Parameter type: <Alarm::duTrigger> (yes no) Possible values: - yes : deliberate update triggered - no : deliberate update is not triggered	specifies deliberate-update is triggered or not. <i>This element is only shown in detail mode.</i>
ssp-missing	Parameter type: <Alarm::sspMissing> (yes no) Possible values: - yes : SSP missing in CDE - no : SSP exist in CDE	specifies ssp missing in cde or not. <i>This element is only shown in detail mode.</i>
dns-pool-exceed	Parameter type: <Alarm::dnsPoolExceed> (yes no) Possible values: - yes : Number of different SG associated DNS pools exceed - no : Number of different SG associated DNS pools exceed	specifies Number of different SG associated DNS pools exceed or not. <i>This element is only shown in detail mode.</i>
lsa-fo-trigger	Parameter type: <Alarm::lsaFoTrigger> (yes no) Possible values: - yes : SIP voice service degraded - fail-over to LSA server - no : fail-over to LSA server is not triggered	specifies lsa-fail-over is triggered or not. <i>This element is only shown in detail mode.</i>

103.33 Alarm Snap-shot SIP Dial Plan Status Command

Command Description

This command show the alarm snap-shot of SIP Dial Plan

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

> show alarm snap-shot sip-dial-plan [(index)]

Command Parameters

Table 103.33-1 "Alarm Snap-shot SIP Dial Plan Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm type

Command Output

Table 103.33-2 "Alarm Snap-shot SIP Dial Plan Status Command" Display parameters

Specific Information		
name	Type	Description
bad-digitmap	Parameter type: <Alarm::badDigitMap> (yes no) Possible values: - yes : digit map unusable - no : digit map usable	sepcifies the sip digitmap usable or not. <i>This element is only shown in detail mode.</i>

103.34 Alarm Snap-shot SIP User Agent Status Command

Command Description

This command show the alarm snap-shot of SIP User Agent

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

> show alarm snap-shot sip-user-agent [(index)]

Command Parameters

Table 103.34-1 "Alarm Snap-shot SIP User Agent Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm type

Command Output

Table 103.34-2 "Alarm Snap-shot SIP User Agent Status Command" Display parameters

Specific Information		
name	Type	Description
bad-digitmap	Parameter type: <Alarm::badDigitMap> (yes no) Possible values: - yes : digit map unusable - no : digit map usable	sepcifies the sip digitmap usable or not. <i>This element is only shown in detail mode.</i>
dhcp-unreach	Parameter type: <Alarm::dhcpUnreach> (yes no) Possible values: - yes : The DHCP server is unreachable - no : The DHCP server is reachable	specifies the DHCP server is unreachable or not <i>This element is only shown in detail mode.</i>
dhcp-no-srv	Parameter type: <Alarm::dhcpNoSrv> (yes no) Possible values:	specifies the address in DHCP reply is NULL or not <i>This element is only shown in detail mode.</i>

name	Type	Description
	- yes : The address in DHCP reply is NULL - no : The address in DHCP reply is not NULL	
dhcp-inv-srv	Parameter type: <Alarm::dhcpInvSrv> (yes no) Possible values: - yes : The address in DHCP reply is invalid - no : The address in DHCP reply is OK	specifies the address in DHCP reply is invalid or not <i>This element is only shown in detail mode.</i>

103.35 Alarm Snap-shot SIP Slot Status Command

Command Description

This command show the alarm snap-shot of SIP Slot

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

> show alarm snap-shot sip-plugin-unit [(index)]

Command Parameters

Table 103.35-1 "Alarm Snap-shot SIP Slot Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm type

Command Output

Table 103.35-2 "Alarm Snap-shot SIP Slot Status Command" Display parameters

Specific Information		
name	Type	Description
short-res	Parameter type: <Alarm::shortResource> (yes no) Possible values: - yes : short call resource - no : have call resource	sepcifies the call resource short or not. <i>This element is only shown in detail mode.</i>
norpniewithsoftdsp	Parameter type: <Alarm::noRpniEWithSoftDsp> (yes no) Possible values: - yes : plan / plug-in RPNI-E board with SoftDsp SW image - no : no plan / plug-in RPNI-E board with SoftDsp SW image	sepcifies if plan / plug-in RPNI-E board with SoftDsp SW image or not. <i>This element is only shown in detail mode.</i>

103.36 Alarm Snap-shot SIP Termination Status Command

Command Description

This command show the alarm snap-shot of SIP termination

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

> show alarm snap-shot sip-termination [(index)]

Command Parameters

Table 103.36-1 "Alarm Snap-shot SIP Termination Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm type

Command Output

Table 103.36-2 "Alarm Snap-shot SIP Termination Status Command" Display parameters

Specific Information		
name	Type	Description
unknown-sub	Parameter type: <Alarm::unknownSubscriber> (yes no) Possible values: - yes : wrong subscriber - no : right subscriber	specifies the sip subscriber unknown or not. <i>This element is only shown in detail mode.</i>
ground-key	Parameter type: <Alarm::groundKey> (yes no) Possible values: - yes : current to ground - no : current not to ground	status of the ground key. <i>This element is only shown in detail mode.</i>
port-hightemp	Parameter type: <Alarm::highTemperature> (yes no) Possible values:	status of the port temperature. <i>This element is only shown in detail mode.</i>

103 Alarm Snap-shot Status Commands

name	Type	Description
	- yes : high temperature - no : not high temperature	
l1-act-failure	Parameter type: <Alarm::l1ActFailure> (yes no) Possible values: - yes : high temperature - no : not high temperature	status of the layer 1 activation. <i>This element is only shown in detail mode.</i>
port-overcurrent	Parameter type: <Alarm::overCurrent> (yes no) Possible values: - yes : over current - no : not over current	status of the port current. <i>This element is only shown in detail mode.</i>
port-jbfltca	Parameter type: <Alarm::jbflTca> (yes no) Possible values: - yes : high jb fill level - no : not high jb fill level	status of the port jitter buffer fill level tca. <i>This element is only shown in detail mode.</i>
reg-domainname	Parameter type: <Alarm::regdomainname> (yes no) Possible values: - yes : register - resolving domain name failed - no : register - resolving domain name successful	status of resolving domain name (register). <i>This element is only shown in detail mode.</i>
reg-auth	Parameter type: <Alarm::regauth> (yes no) Possible values: - yes : register - authentication failed - no : register - authentication successful	status of authentication (register). <i>This element is only shown in detail mode.</i>
reg-timeout	Parameter type: <Alarm::regtimeout> (yes no) Possible values: - yes : register - message timeout - no : register - message not timeout	status of message timeout (register). <i>This element is only shown in detail mode.</i>
reg-srvfailresp	Parameter type: <Alarm::regsrvfailresp> (yes no) Possible values: - yes : register - failure response from server - no : register - successful response from server	status of failure response from server (register). <i>This element is only shown in detail mode.</i>
inv-domainname	Parameter type: <Alarm::invdomainname> (yes no) Possible values: - yes : invite - resolving domain name failed - no : invite - resolving domain name successful	status of resolving domain name (invite). <i>This element is only shown in detail mode.</i>
inv-auth	Parameter type: <Alarm::invauth> (yes no) Possible values: - yes : invite - authentication failed - no : invite - authentication successful	status of authentication (invite). <i>This element is only shown in detail mode.</i>
inv-timeout	Parameter type: <Alarm::invtimeout>	status of message timeout

name	Type	Description
	(yes no) Possible values: - yes : invite - message timeout - no : invite - message not timeout	(invite). <i>This element is only shown in detail mode.</i>
inv-srvfailresp	Parameter type: <Alarm::invsrvfailresp> (yes no) Possible values: - yes : invite - failure response from server - no : invite - successful response from server	status of failure response from server (invite). <i>This element is only shown in detail mode.</i>
subs-srvfailresp	Parameter type: <Alarm::subsrvfailresp> (yes no) Possible values: - yes : subscribe - failure response from server - no : subscribe - successful response from server	status of failure response from server (subscribe). <i>This element is only shown in detail mode.</i>
subs-domainname	Parameter type: <Alarm::subsdomainname> (yes no) Possible values: - yes : Subscribe - resolving domain name failed - no : Subscribe - resolving domain name successful	status of resolving domain name (subscribe). <i>This element is only shown in detail mode.</i>
subs-auth	Parameter type: <Alarm::subsauth> (yes no) Possible values: - yes : Subscribe - authentication failed - no : Subscribe - authentication successful	status of authentication(subscribe). <i>This element is only shown in detail mode.</i>
subs-refreshfail	Parameter type: <Alarm::subsrefreshfail> (yes no) Possible values: - yes : Subscribe - refresh failure - no : Subscribe - refresh failure	status of message timeout or 481 received(refresher subscribe). <i>This element is only shown in detail mode.</i>
subs-inittimeout	Parameter type: <Alarm::subsintimeout> (yes no) Possible values: - yes : Subscribe - initial REQ timeout - no : Subscribe - initial REQ timeout	status of message timeout(initial subscribe). <i>This element is only shown in detail mode.</i>
emergency-call	Parameter type: <Alarm::emergencycall> (yes no) Possible values: - yes : emergency call is ongoing - no : emergency call is not ongoing	status of emergency call. <i>This element is only shown in detail mode.</i>

103.37 Alarm Snap-shot Secondary SIP Termination Status Command

Command Description

This command show the alarm snap-shot of secondary SIP termination.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

> show alarm snap-shot secondary-sip-term [(index)]

Command Parameters

Table 103.37-1 "Alarm Snap-shot Secondary SIP Termination Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm type

Command Output

Table 103.37-2 "Alarm Snap-shot Secondary SIP Termination Status Command" Display parameters

Specific Information		
name	Type	Description
reg-domainname-sec	Parameter type: <Alarm::regdomainname> (yes no) Possible values: - yes : register - resolving domain name failed - no : register - resolving domain name successful	status of resolving domain name (register). <i>This element is only shown in detail mode.</i>
reg-auth-sec	Parameter type: <Alarm::regauth> (yes no) Possible values: - yes : register - authentication failed - no : register - authentication successful	status of authentication (register). <i>This element is only shown in detail mode.</i>
reg-timeout-sec	Parameter type: <Alarm::regtimeout> (yes	status of message timeout (register).

name	Type	Description
	no) Possible values: - yes : register - message timeout - no : register - message not timeout	<i>This element is only shown in detail mode.</i>
reg-srvfailresp-sec	Parameter type: <Alarm::regsrvfailresp> (yes no) Possible values: - yes : register - failure response from server - no : register - successful response from server	status of failure response from server (register). <i>This element is only shown in detail mode.</i>
inv-domainname-sec	Parameter type: <Alarm::invdomainname> (yes no) Possible values: - yes : invite - resolving domain name failed - no : invite - resolving domain name successful	status of resolving domain name (invite). <i>This element is only shown in detail mode.</i>
inv-auth-sec	Parameter type: <Alarm::invauth> (yes no) Possible values: - yes : invite - authentication failed - no : invite - authentication successful	status of authentication (invite). <i>This element is only shown in detail mode.</i>
inv-timeout-sec	Parameter type: <Alarm::invtimeout> (yes no) Possible values: - yes : invite - message timeout - no : invite - message not timeout	status of message timeout (invite). <i>This element is only shown in detail mode.</i>
inv-srvfailresp-sec	Parameter type: <Alarm::invsrvfailresp> (yes no) Possible values: - yes : invite - failure response from server - no : invite - successful response from server	status of failure response from server (invite). <i>This element is only shown in detail mode.</i>
subs-srvfailresp-sec	Parameter type: <Alarm::subsrvfailresp> (yes no) Possible values: - yes : subscribe - failure response from server - no : subscribe - successful response from server	status of failure response from server (subscribe). <i>This element is only shown in detail mode.</i>
subs-domainname-sec	Parameter type: <Alarm::subsdomainname> (yes no) Possible values: - yes : Subscribe - resolving domain name failed - no : Subscribe - resolving domain name successful	status of resolving domain name (subscribe). <i>This element is only shown in detail mode.</i>
subs-auth-sec	Parameter type: <Alarm::subsauth> (yes no) Possible values: - yes : Subscribe - authentication failed - no : Subscribe - authentication successful	status of authentication(subscribe). <i>This element is only shown in detail mode.</i>
subs-refreshfail-sec	Parameter type: <Alarm::subsrefreshfail> (yes no) Possible values: - yes : Subscribe - refresh failure	status of message timeout or 481 received(refresher subscribe). <i>This element is only shown in detail mode.</i>

103 Alarm Snap-shot Status Commands

name	Type	Description
	- no : Subscribe - refresh failure	
subs-inittimeout-sec	Parameter type: <Alarm::subsinittimeout> (yes no) Possible values: - yes : Subscribe - initial REQ timeout - no : Subscribe - initial REQ timeout	status of message timeout(initial subscribe). <i>This element is only shown in detail mode.</i>
emergency-call-sec	Parameter type: <Alarm::emergencycall> (yes no) Possible values: - yes : emergency call is ongoing - no : emergency call is not ongoing	status of emergency call. <i>This element is only shown in detail mode.</i>

103.38 Alarm Snap-shot SIP Termination Status Command

Command Description

This command show the alarm snap-shot of SIP termination

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

> show alarm snap-shot e1-sip-termination [(index)]

Command Parameters

Table 103.38-1 "Alarm Snap-shot SIP Termination Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm type

Command Output

Table 103.38-2 "Alarm Snap-shot SIP Termination Status Command" Display parameters

Specific Information		
name	Type	Description
reg-domainname	Parameter type: <Alarm::isdnregdomainname> (yes no) Possible values: - yes : register - resolving domain name failed - no : register - resolving domain name successful	status of resolving domain name (register). <i>This element is only shown in detail mode.</i>
reg-auth	Parameter type: <Alarm::isdnregauth> (yes no) Possible values: - yes : register - authentication failed - no : register - authentication successful	status of authentication (register). <i>This element is only shown in detail mode.</i>
reg-timeout	Parameter type: <Alarm::isdnregtimeout> (yes no) Possible values:	status of message timeout (register). <i>This element is only shown in detail mode.</i>

103 Alarm Snap-shot Status Commands

name	Type	Description
	- yes : register - message timeout - no : register - message not timeout	
reg-srvfailresp	Parameter type: <Alarm::isdnregsrvfailresp> (yes no) Possible values: - yes : register - failure response from server - no : register - successful response from server	status of failure response from server (register). <i>This element is only shown in detail mode.</i>
inv-domainname	Parameter type: <Alarm::isdninvdomainname> (yes no) Possible values: - yes : invite - resolving domain name failed - no : invite - resolving domain name successful	status of resolving domain name (invite). <i>This element is only shown in detail mode.</i>
inv-auth	Parameter type: <Alarm::isdninvauth> (yes no) Possible values: - yes : invite - authentication failed - no : invite - authentication successful	status of authentication (invite). <i>This element is only shown in detail mode.</i>
inv-timeout	Parameter type: <Alarm::isdninvtimeout> (yes no) Possible values: - yes : invite - message timeout - no : invite - message not timeout	status of message timeout (invite). <i>This element is only shown in detail mode.</i>
inv-srvfailresp	Parameter type: <Alarm::isdninvsrvfailresp> (yes no) Possible values: - yes : invite - failure response from server - no : invite - successful response from server	status of failure response from server (invite). <i>This element is only shown in detail mode.</i>
emergency-call	Parameter type: <Alarm::isdnemergencycall> (yes no) Possible values: - yes : emergency call is ongoing - no : emergency call is not ongoing	status of emergency call. <i>This element is only shown in detail mode.</i>
ais-signal	Parameter type: <Alarm::isdnaissignal> (yes no) Possible values: - yes : Alarm Indication Signal detected at E1 interface - no : no Alarm Indication Signal detected at E1 interface	status of Alarm Indication Signal. <i>This element is only shown in detail mode.</i>
los-signal	Parameter type: <Alarm::isdnlossignal> (yes no) Possible values: - yes : Loss Of Signal detected at E1 interface - no : no Loss Of Signal detected at E1 interface	status of Loss Of Signal Alarm. <i>This element is only shown in detail mode.</i>
rai-signal	Parameter type: <Alarm::isdnraisignal> (yes no) Possible values: - yes : Remote Alarm Indication detected at E1 interface - no : no Remote Alarm Indication detected at E1 interface	status of Remote Alarm Indication. <i>This element is only shown in detail mode.</i>
e1sip-misconfig-mgc10	Parameter type: <Alarm::sipmiscfgmgc10>	status of config error when

name	Type	Description
	(yes no) Possible values: - yes : Configuration not conform with the core network entity - no : no Configuration not conform with the core network entity	connect to mgc10. <i>This element is only shown in detail mode.</i>
e1sip-nsmprf-missed	Parameter type: <Alarm::sipnsmprofmis> (yes no) Possible values: - yes : The SIP termination requires a NSM profile - no : no The SIP termination requires a NSM profile	status of config error when connect to mgc10. <i>This element is only shown in detail mode.</i>

103.39 Alarm Snap-shot E1/T1 interface Status Command

Command Description

This command shows the snap shot status of E1T1 interface alarm

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm snap-shot e1t1-interface [ (index) ]
```

Command Parameters

Table 103.39-1 "Alarm Snap-shot E1/T1 interface Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm type

Command Output

Table 103.39-2 "Alarm Snap-shot E1/T1 interface Status Command" Display parameters

Specific Information		
name	Type	Description
e1t1itf-recv-ais	Parameter type: <Alarm::itfaissignal> (yes no) Possible values: - yes : Alarm Indication Signal received at interface - no : no Alarm Indication Signal received at interface	status of Alarm Indication Signal received at interface <i>This element is only shown in detail mode.</i>
e1t1itf-recv-los	Parameter type: <Alarm::itflossignal> (yes no) Possible values: - yes : Loss Of Signal received at interface - no : no Loss Of Signal received at interface	status of Loss Of Signal Alarm received at interface <i>This element is only shown in detail mode.</i>
e1t1itf-recv-rai	Parameter type: <Alarm::itfraissignal> (yes no) Possible values:	status of Remote Alarm Indication received at interface <i>This element is only shown in detail mode.</i>

name	Type	Description
	- yes : Remote Alarm Indication received at interface - no : no Remote Alarm Indication received at interface	

103.40 Alarm Snap-shot SIP Termination Status Command

Command Description

This command show the alarm snap-shot of SIP termination

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm snap-shot cas-r2-channel [ (index) ]
```

Command Parameters

Table 103.40-1 "Alarm Snap-shot SIP Termination Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm type

Command Output

Table 103.40-2 "Alarm Snap-shot SIP Termination Status Command" Display parameters

Specific Information		
name	Type	Description
exp-seizureack	Parameter type: <Alarm::ExpSeizureAck> (yes no) Possible values: - yes : Channel was blocked due to failure in the reception of the SEIZURE ACK signal - no : Channel was not blocked due to failure in the reception of the SEIZURE ACK signal	status of seizure ack signal <i>This element is only shown in detail mode.</i>
exp-disconack	Parameter type: <Alarm::ExpDisconnectAck> (yes no) Possible values: - yes : Channel was blocked due to failure in the reception of the DISCONNECTION ACK signal - no : Channel was not blocked due to failure in the reception of the DISCONNECTION ACK signal	status of disconnect ack signal <i>This element is only shown in detail mode.</i>

name	Type	Description
exp-forcerelack	Parameter type: <Alarm::ExpForceRelAck> (yes no) Possible values: - yes : Channel was blocked due to failure in the reception of the BACKWARD DISCONNECTION ACK signal - no : No Channel was blocked due to failure in the reception of the BACKWARD DISCONNECTION ACK signal	status of foreced release ack signal <i>This element is only shown in detail mode.</i>

103.41 Alarm Snap-shot Pseudo Wire Status Command

Command Description

This command show the alarm snap-shot of the Pseudo Wire.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

> show alarm snap-shot pseudo-wire [(index)]

Command Parameters

Table 103.41-1 "Alarm Snap-shot Pseudo Wire Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm type

Command Output

Table 103.41-2 "Alarm Snap-shot Pseudo Wire Status Command" Display parameters

Specific Information		
name	Type	Description
packet-loss	Parameter type: <Alarm::PacketLoss> (yes no) Possible values: - yes : Pseudo Wire entered the Packet loss state - no : Pseudo Wire not entered the Packet loss state	specifies the packet loss is unknown or not. <i>This element is only shown in detail mode.</i>
remote-packet-loss	Parameter type: <Alarm::RemotePacketLoss> (yes no) Possible values: - yes : Remote Packet loss detected - no : Remote Packet loss not detected	specifies the remote packet loss or not. <i>This element is only shown in detail mode.</i>
no-dsp-resource	Parameter type: <Alarm::NoDspResource> (yes no) Possible values:	specifies no DSP resource or not. <i>This element is only shown in detail mode.</i>

name	Type	Description
	- yes : DSP resource allocation failed - no : DSP resource allocation failed	

103.42 Alarm Snap-shot Megaco Media Gateway Status Command

Command Description

This command show the alarm snap-shot of Megaco media gateway.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

> show alarm snap-shot megaco-media-gw [(index)]

Command Parameters

Table 103.42-1 "Alarm Snap-shot Megaco Media Gateway Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm type

Command Output

Table 103.42-2 "Alarm Snap-shot Megaco Media Gateway Status Command" Display parameters

Specific Information		
name	Type	Description
mgc-unreachable	Parameter type: <Alarm::mgcUnreachable> (yes no) Possible values: - yes : media gateway controller is unreachable - no : media gateway controller is reachable	specifies the media gateway controller is unreachable or not. <i>This element is only shown in detail mode.</i>
failover-to-esamgc	Parameter type: <Alarm::failovertoESAMGC> (yes no) Possible values: - yes : failover to esa mgc - no : normal mgc is in service	specifies the media gateway failover to esa mgc or not. <i>This element is only shown in detail mode.</i>

103.43 Alarm Snap-shot Megaco Signaling Gateway Status Command

Command Description

This command show the alarm snap-shot of Megaco signaling gateway.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

> show alarm snap-shot megaco-sig-gw [(index)]

Command Parameters

Table 103.43-1 "Alarm Snap-shot Megaco Signaling Gateway Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm type

Command Output

Table 103.43-2 "Alarm Snap-shot Megaco Signaling Gateway Status Command" Display parameters

Specific Information		
name	Type	Description
sig-unreachable	Parameter type: <Alarm::sgcUnreachable> (yes no) Possible values: - yes : signalling gateway controller is unreachable - no : signalling gateway controller is reachable	specifies the signaling gateway controller is unreachable or not. <i>This element is only shown in detail mode.</i>

103.44 Alarm Snap-shot Megaco Plug Unit Status Command

Command Description

This command show the alarm snap-shot of Megaco plug unit.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

> show alarm snap-shot megaco-plug-unit [(index)]

Command Parameters

Table 103.44-1 "Alarm Snap-shot Megaco Plug Unit Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm type

Command Output

Table 103.44-2 "Alarm Snap-shot Megaco Plug Unit Status Command" Display parameters

Specific Information		
name	Type	Description
lcard-unreach-srvcard	Parameter type: <Alarm::lineCardUnreachSrvCard> (yes no) Possible values: - yes : line card is unreachable with server card - no : line card is reachable with server card	specifies the line card is unreachable with server card or not. <i>This element is only shown in detail mode.</i>
lcard-type-mismatch	Parameter type: <Alarm::lineCardTypeMismatchch> (yes no) Possible values: - yes : line card type is mismatch - no : line card type is match	specifies the line card type is mismatch or not. <i>This element is only shown in detail mode.</i>

103.45 Alarm Snap-shot Megaco Termination Status Command

Command Description

This command show the alarm snap-shot of Megaco termination.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

> show alarm snap-shot megaco-term [(index)]

Command Parameters

Table 103.45-1 "Alarm Snap-shot Megaco Termination Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm type

Command Output

Table 103.45-2 "Alarm Snap-shot Megaco Termination Status Command" Display parameters

Specific Information		
name	Type	Description
meg-unknown-sub	Parameter type: <Alarm::megacoUnknownSubscriber> (yes no) Possible values: - yes : unknown wrong megaco subscriber - no : no wrong megaco subscriber	specifies the megaco subscriber is unknown or not. <i>This element is only shown in detail mode.</i>
meg-ground-key	Parameter type: <Alarm::voicePortGroundKey> (yes no) Possible values: - yes : voice port ground key - no : voice port not ground key	specifies the voice port ground key or not. <i>This element is only shown in detail mode.</i>
meg-high-temp	Parameter type: <Alarm::voicePortHighTemp> (yes no) Possible values:	specifies the voice port high temperature or not. <i>This element is only shown in detail mode.</i>

103 Alarm Snap-shot Status Commands

name	Type	Description
	- yes : voice port high temperature - no : voice port not high temperature	
l1-act-fail	Parameter type: <Alarm::voicePortL1ActFail> (yes no) Possible values: - yes : voice port l1 act failure - no : voice port l1 act not failure	specifies the voice port l1 act failure or not. <i>This element is only shown in detail mode.</i>
over-current	Parameter type: <Alarm::voicePortOverCurrent> (yes no) Possible values: - yes : voice port over current - no : voice port not over current	specifies the voice port over current or not. <i>This element is only shown in detail mode.</i>
line-showering	Parameter type: <Alarm::lineshowering> (yes no) Possible values: - yes : line showering - no : no line showering	specifies the line showering or not. <i>This element is only shown in detail mode.</i>
low-qos-packetloss	Parameter type: <Alarm::lowQosPacketLoss> (yes no) Possible values: - yes : the total packet loss has exceeded the configured threshold - no : the total packet loss has not exceeded the configured threshold	specifies the megaco total packet loss has exceeded the configured threshold or not. <i>This element is only shown in detail mode.</i>
low-qos-jitter	Parameter type: <Alarm::lowQosJitter> (yes no) Possible values: - yes : the rtp jitter has exceeded the configured threshold - no : the rtp jitter has not exceeded the configured threshold	specifies the megaco rtp jitter has exceeded the configured threshold or not. <i>This element is only shown in detail mode.</i>
low-qos-delay	Parameter type: <Alarm::lowQosDelay> (yes no) Possible values: - yes : the rtp delay has exceeded the configured threshold - no : the rtp delay has not exceeded the configured threshold	specifies the megaco rtp delay has exceeded the configured threshold or not. <i>This element is only shown in detail mode.</i>

103.46 Alarm Snap-shot Secondary Megaco Termination Status Command

Command Description

This command show the alarm snap-shot of the secondary Megaco termination.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

> show alarm snap-shot secondary-megaco-term [(index)]

Command Parameters

Table 103.46-1 "Alarm Snap-shot Secondary Megaco Termination Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm type

Command Output

Table 103.46-2 "Alarm Snap-shot Secondary Megaco Termination Status Command" Display parameters

Specific Information		
name	Type	Description
meg-unknown-sub-sec	Parameter type: <Alarm::megacoUnknownSubscriber> (yes no) Possible values: - yes : unknown wrong megaco subscriber - no : no wrong megaco subscriber	specifies the megaco subscriber is unknown or not. <i>This element is only shown in detail mode.</i>
line-showering-sec	Parameter type: <Alarm::lineshowering> (yes no) Possible values: - yes : line showering - no : no line showering	specifies the line showering or not. <i>This element is only shown in detail mode.</i>

103.47 Alarm Snap-shot Megaco Signaling Lt Status Command

Command Description

This command show the alarm snap-shot of Megaco signaling Lt.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

> show alarm snap-shot megaco-sig-lt [(index)]

Command Parameters

Table 103.47-1 "Alarm Snap-shot Megaco Signaling Lt Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm type

Command Output

Table 103.47-2 "Alarm Snap-shot Megaco Signaling Lt Status Command" Display parameters

Specific Information		
name	Type	Description
sig-brd-persist-loss	Parameter type: <Alarm::megacoSigBoardPersDataLoss> (yes no) Possible values: - yes : the voice signaling board persistenet data loss - no : the voice signaling board persistenet data not loss	specifies the voice signaling board persistenet data loss or not. <i>This element is only shown in detail mode.</i>
sig-brd-disk-full	Parameter type: <Alarm::voiceSigBoard90PercentFull> (yes no) Possible values: - yes : specifies the voice signaling board disk 90% full - no : specifies the voice signaling board disk no 90% full	specifies the voice signaling board disk 90% full or not. <i>This element is only shown in detail mode.</i>
sig-brd-db-rollback	Parameter type: <Alarm::sigBoardDBRollback> (yes no) Possible values:	specifies he voice signaling board implicit db rollback or not. <i>This element is only shown in detail mode.</i>

name	Type	Description
	- yes : specifies the voice signaling board implicit db rollback - no : specifies the voice signaling board implicit db no rollback	
mg-overload	Parameter type: <Alarm::megMGOverLoad> (yes no) Possible values: - yes : specifies the mg overload - no : specifies the mg no overload	specifies the mg overload or not. <i>This element is only shown in detail mode.</i>

103.48 Alarm Snap-shot E1 Status Command

Command Description

This command show the alarm snap-shot of E1

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm snap-shot e1 [ (index) ]
```

Command Parameters

Table 103.48-1 "Alarm Snap-shot E1 Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm snap shot table index

Command Output

Table 103.48-2 "Alarm Snap-shot E1 Status Command" Display parameters

Specific Information		
name	Type	Description
port	Parameter type: <Itf::E1Line> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number	identifies the physical position of the port <i>This element is only shown in detail mode.</i>
rx-rai	Parameter type: <Alarm::E1RxRai> (yes no) Possible values: - yes : recieving RAI - no : no recieving RAI	snap shot of E1 receiving RAI <i>This element is only shown in detail mode.</i>
tx-rai	Parameter type: <Alarm::E1TxRai> (yes	snap shot of E1 transmitting RAI <i>This element is only shown in</i>

name	Type	Description
	no) Possible values: - yes : transmitting RAI - no : no transmitting RAI	<i>detail mode.</i>
rx-ais	Parameter type: <Alarm::E1RxAis> (yes no) Possible values: - yes : recieving AIS - no : no recieving AIS	snap shot of E1 receiving AIS <i>This element is only shown in detail mode.</i>
tx-ais	Parameter type: <Alarm::E1TxAis> (yes no) Possible values: - yes : transmitting AIS - no : no transmitting AIS	snap shot of E1 transmitting AIS <i>This element is only shown in detail mode.</i>
lof	Parameter type: <Alarm::E1LOF> (yes no) Possible values: - yes : loss of frame - no : no loss of frame	snap shot of E1 loss of frame <i>This element is only shown in detail mode.</i>
los	Parameter type: <Alarm::E1LOS> (yes no) Possible values: - yes : loss of signal - no : no loss of signal	snap shot of E1 loss of signal <i>This element is only shown in detail mode.</i>
loopback	Parameter type: <Alarm::E1Loopback> (yes no) Possible values: - yes : facility in loopback - no : facility not in loopback	snap shot of E1 loopback <i>This element is only shown in detail mode.</i>

103.49 Alarm Snap-shot Shdsl Status Command

Command Description

This command show the alarm snap-shot of Shdsl

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

> show alarm snap-shot shdsl [(index)]

Command Parameters

Table 103.49-1 "Alarm Snap-shot Shdsl Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm snap shot table index

Command Output

Table 103.49-2 "Alarm Snap-shot Shdsl Status Command" Display parameters

Specific Information		
name	Type	Description
port	Parameter type: <Itf::ShdslLine> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number	identifies the physical position of the port <i>This element is only shown in detail mode.</i>
unit	Parameter type: <Alarm::LinkDeviceValues> - a signed integer	identify where the alarm has occurred <i>This element is only shown in detail mode.</i>
loop-act-net	Parameter type: <Alarm::LoopbackActiveNetwork> (yes no) Possible values:	snap shot of loopback active at the network side <i>This element is only shown in detail mode.</i>

name	Type	Description
	- yes : loopback active - no : no loopback active	
loop-act-cus	Parameter type: <Alarm::LoopbackActiveCustom> (yes no) Possible values: - yes : loopback active - no : no loopback active	snap shot of loopback active at the custom side <i>This element is only shown in detail mode.</i>
config-error	Parameter type: <Alarm::ConfigError> (yes no) Possible values: - yes : config error - no : no config error	snap shot of configuration error <i>This element is only shown in detail mode.</i>
loss-atm	Parameter type: <Alarm::LossATMCellDel> (yes no) Possible values: - yes : loss atm cell delineation - no : no loss atm cell delineation	snap shot of loss of atm cell delineation <i>This element is only shown in detail mode.</i>
loss-pr	Parameter type: <Alarm::LossPowerSTUR> (yes no) Possible values: - yes : loss power at stu-r - no : no loss power at stu-r	snap shot of loss of power at stu-r <i>This element is only shown in detail mode.</i>
secu-error	Parameter type: <Alarm::UnableDisableSTUR> (yes no) Possible values: - yes : loss ability at stu-r - no : no loss ability at stu-r	snap shot of loss of ability to disable stu-r access <i>This element is only shown in detail mode.</i>
dev-fault	Parameter type: <Alarm::DeviceFault> (yes no) Possible values: - yes : device fault - no : no device fault	snap shot of fault of device <i>This element is only shown in detail mode.</i>
atm-ncd	Parameter type: <Alarm::ATMCellDel> (yes no) Possible values: - yes : no atm cell delineation - no : atm cell delineation	snap shot of none of atm cell delineation <i>This element is only shown in detail mode.</i>

103.50 Alarm Snap-shot Shdsl Status Command

Command Description

This command show the alarm snap-shot of Shdsl

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

> show alarm snap-shot shdsl-isam [(index)]

Command Parameters

Table 103.50-1 "Alarm Snap-shot Shdsl Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm snap shot table index

Command Output

Table 103.50-2 "Alarm Snap-shot Shdsl Status Command" Display parameters

Specific Information		
name	Type	Description
port	Parameter type: <Itf::ShdslLine> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number	identifies the physical position of the port <i>This element is only shown in detail mode.</i>
wire-pair	Parameter type: <Alarm::LinkDeviceValuesHigh> - identify where the alarm occurred	identify where the alarm has occurred <i>This element is only shown in detail mode.</i>
unit	Parameter type: <Alarm::LinkDeviceValuesLow> - identify where the alarm occurred	identify where the alarm has occurred <i>This element is only shown in detail mode.</i>

name	Type	Description
loss-syn-net	Parameter type: <Alarm::LossSyncWordNetwork> (yes no) Possible values: - yes : loss sync word - no : no loss sync word	snap shot of loss of sync word at the network side on each pair <i>This element is only shown in detail mode.</i>
loss-syn-cus	Parameter type: <Alarm::LossSyncWordCustom> (yes no) Possible values: - yes : loss sync word - no : no loss sync word	snap shot of loss of sync word at the custom side on each pair <i>This element is only shown in detail mode.</i>
loop-att-net	Parameter type: <Alarm::LoopAttenuationNetwork> (yes no) Possible values: - yes : loop attenuation - no : no loop attenuation	snap shot of loop attenuation alarm at the network side on each pair <i>This element is only shown in detail mode.</i>
loop-att-cus	Parameter type: <Alarm::LoopAttenuationCustom> (yes no) Possible values: - yes : loop attenuation - no : no loop attenuation	snap shot of loop attenuation alarm at the custom side on each pair <i>This element is only shown in detail mode.</i>
snr-net	Parameter type: <Alarm::SNRNetwork> (yes no) Possible values: - yes : snr margin - no : no snr margin	snap shot of snr margin alarm at the network side each pair <i>This element is only shown in detail mode.</i>
snr-cus	Parameter type: <Alarm::SNRCustom> (yes no) Possible values: - yes : snr margin - no : no snr margin	snap shot of snr margin alarm at the custom side each pair <i>This element is only shown in detail mode.</i>
dc-net	Parameter type: <Alarm::DCContinuityFaultNetwork> (yes no) Possible values: - yes : dc fault - no : no dc fault	snap shot of dc continuity fault at the network side on each pair <i>This element is only shown in detail mode.</i>
dc-cus	Parameter type: <Alarm::DCContinuityFaultCustom> (yes no) Possible values: - yes : dc fault - no : no dc fault	snap shot of dc continuity fault at the custom side on each pair <i>This element is only shown in detail mode.</i>

103.51 Alarm Snap-shot Ima-Group Status Command

Command Description

This command show the alarm snap-shot of Ima-Group

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

> show alarm snap-shot ima-group [(index)]

Command Parameters

Table 103.51-1 "Alarm Snap-shot Ima-Group Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm snap shot table index

Command Output

Table 103.51-2 "Alarm Snap-shot Ima-Group Status Command" Display parameters

Specific Information		
name	Type	Description
port	Parameter type: <Equipm::AtmImaIndex> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number	identifies the physical position of the port <i>This element is only shown in detail mode.</i>
far-end-start	Parameter type: <Alarm::FarEndStartup> (yes no) Possible values: - yes : far-end startup	snap shot of far-end starting up <i>This element is only shown in detail mode.</i>

name	Type	Description
	- no : no far-end startup	
far-end-fconf	Parameter type: <Alarm::FarEndFailedConfig> (yes no) Possible values: - yes : far-end failed config - no : no far-end failed config	snap shot of failed configuration of far-end <i>This element is only shown in detail mode.</i>
near-end-fconf	Parameter type: <Alarm::NearEndFailedConfig> (yes no) Possible values: - yes : near-end failed config - no : no near-end failed config	snap shot of failed configuration of near-end <i>This element is only shown in detail mode.</i>
far-end-ins-lnk	Parameter type: <Alarm::FarEndInsuffLinkNum> (yes no) Possible values: - yes : insufficient number of links at far-end - no : no insufficient number of links at far-end	snap shot of insufficient number of links at far-end <i>This element is only shown in detail mode.</i>
near-end-ins-lnk	Parameter type: <Alarm::NearEndInsuffLinkNum> (yes no) Possible values: - yes : insufficient number of links at near-end - no : no insufficient number of links at near-end	snap shot of insufficient number of links at near-end <i>This element is only shown in detail mode.</i>
far-end-blk	Parameter type: <Alarm::FarEndBlocked> (yes no) Possible values: - yes : far-end blocked - no : no far-end blocked	snap shot of status that far-end is blocked <i>This element is only shown in detail mode.</i>

103.52 Alarm Snap-shot Ima-Link Status Command

Command Description

This command show the alarm snap-shot of Ima-Link

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

> show alarm snap-shot ima-link [(index)]

Command Parameters

Table 103.52-1 "Alarm Snap-shot Ima-Link Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm snap shot table index

Command Output

Table 103.52-2 "Alarm Snap-shot Ima-Link Status Command" Display parameters

Specific Information		
name	Type	Description
port	Parameter type: <Itf::ShdslLine> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number	identifies the physical position of the port <i>This element is only shown in detail mode.</i>
loss-ima-frm	Parameter type: <Alarm::LossImaFrame> (yes no) Possible values: - yes : loss ima frame - no : no loss ima frame	snap shot of loss of ima frame <i>This element is only shown in detail mode.</i>
lods	Parameter type: <Alarm::LinkOutofDelaySynch> (yes	snap shot of link out of delay synchronization

name	Type	Description
	no) Possible values: - yes : link out of delay - no : no link out of delay	<i>This element is only shown in detail mode.</i>
link-misc	Parameter type: <Alarm::LinkMisconnect> (yes no) Possible values: - yes : link misconnect - no : no link misconnect	snap shot of link of misconnecting <i>This element is only shown in detail mode.</i>
link-rfi	Parameter type: <Alarm::LinkRemoteFailureIndication> (yes no) Possible values: - yes : link remote failure indication - no : no link remote failure indication	snap shot of link of remote failure indication <i>This element is only shown in detail mode.</i>
link-fault	Parameter type: <Alarm::LinkFault> (yes no) Possible values: - yes : fault in link facility - no : no fault in link facility	snap shot of fault of link <i>This element is only shown in detail mode.</i>
fe-tx-blk	Parameter type: <Alarm::FarEndTXBlocked> (yes no) Possible values: - yes : transmit blocked due to far-end - no : no transmit blocked due to far-end	snap shot of transmit blocked due to far-end <i>This element is only shown in detail mode.</i>
fe-rec-blk	Parameter type: <Alarm::FarEndRXBlocked> (yes no) Possible values: - yes : receive blocked due to far-end - no : no receive blocked due to far-end	snap shot of receive blocked due to far-end <i>This element is only shown in detail mode.</i>

103.53 Alarm Snap-shot Ether-Tca Status Command

Command Description

This command show the alarm snap-shot of Ether-Tca

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

> show alarm snap-shot ether-tca [(index)]

Command Parameters

Table 103.53-1 "Alarm Snap-shot Ether-Tca Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm snap shot table index

Command Output

Table 103.53-2 "Alarm Snap-shot Ether-Tca Status Command" Display parameters

Specific Information		
name	Type	Description
port	Parameter type: <Itf::EthernetPortIndex> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number	identifies the physical position of the port <i>This element is only shown in detail mode.</i>
etca-los	Parameter type: <Alarm::EthTcaLos> (yes no) Possible values: - yes : ethernet loss of signal errors exceeds	snap shot of ethernet los in 15 min <i>This element is only shown in detail mode.</i>

name	Type	Description
	- no : ethernet loss of signal errors normal	
etca-fcs	Parameter type: <Alarm::EthTcaFcs> (yes no) Possible values: - yes : ethernet frame check sequence errors exceeds - no : ethernet frame check sequence errors normal	snap shot of ethernet fcs in 15 min <i>This element is only shown in detail mode.</i>
etca-rx-octets	Parameter type: <Alarm::EthTcaRxb> (yes no) Possible values: - yes : received octets exceeds - no : received octets normal	snap shot of received octets in 15 min <i>This element is only shown in detail mode.</i>
etca-tx-octets	Parameter type: <Alarm::EthTcaTxb> (yes no) Possible values: - yes : transmitted octets exceeds - no : transmitted octets normal	snap shot of transmitted octets in 15 min <i>This element is only shown in detail mode.</i>
etca-day-los	Parameter type: <Alarm::EthDayLos> (yes no) Possible values: - yes : ethernet day los errors exceeds - no : ethernet day los errors normal	snap shot of ethernet day los <i>This element is only shown in detail mode.</i>
etca-day-fcs	Parameter type: <Alarm::EthDayFcs> (yes no) Possible values: - yes : ethernet day fcs errors exceeds - no : ethernet day fcs errors normal	snap shot of ethernet day fcs <i>This element is only shown in detail mode.</i>
etca-day-rx-octets	Parameter type: <Alarm::EthDayRxb> (yes no) Possible values: - yes : received octets day exceeds - no : received octets day normal	snap shot of received octets in 1 day <i>This element is only shown in detail mode.</i>
etca-day-tx-octets	Parameter type: <Alarm::EthDayTxb> (yes no) Possible values: - yes : transmitted octets day exceeds - no : transmitted octets day normal	snap shot of transmitted octets in 1 day <i>This element is only shown in detail mode.</i>

103.54 Alarm Snap-shot Ether-Sfp Status Command

Command Description

This command show the alarm snap-shot of Ether-Sfp

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

> show alarm snap-shot ether-sfp [(index)]

Command Parameters

Table 103.54-1 "Alarm Snap-shot Ether-Sfp Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm snap shot table index

Command Output

Table 103.54-2 "Alarm Snap-shot Ether-Sfp Status Command" Display parameters

Specific Information		
name	Type	Description
port	Parameter type: <Itf::EthernetPortIndex> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number	identifies the physical position of the port <i>This element is only shown in detail mode.</i>
user-sfp-los	Parameter type: <Alarm::EthSfpLos> (yes no) Possible values: - yes : ethernet sfp los error	snap shot of ethernet sfp los <i>This element is only shown in detail mode.</i>

name	Type	Description
	- no : ethernet sfp los normal	
user-sfp-tx-fail	Parameter type: <Alarm::EthSfpTxFail> (yes no) Possible values: - yes : ethernet sfp Tx Failure - no : ethernet sfp Tx normal	snap shot of ethernet sfp tx <i>This element is only shown in detail mode.</i>
user-sfp-not-prst	Parameter type: <Alarm::EthSfpNotPrst> (yes no) Possible values: - yes : ethernet sfp not detected - no : ethernet sfp detected	snap shot of ethernet sfp presence <i>This element is only shown in detail mode.</i>
user-sfp-inv-id	Parameter type: <Alarm::EthSfpInvalid> (yes no) Possible values: - yes : ethernet sfp id invalid - no : ethernet sfp id normal	snap shot of ethernet sfp id <i>This element is only shown in detail mode.</i>
user-sfp-t-exceed	Parameter type: <Alarm::EthSfpTempExceed> (yes no) Possible values: - yes : ethernet sfp temperature exceed - no : ethernet sfp temperature normal	snap shot of ethernet sfp temperature <i>This element is only shown in detail mode.</i>
user-sfp-mismatch	Parameter type: <Alarm::EthSfpMismatch> (yes no) Possible values: - yes : ethernet sfp mismatch the configured type - no : ethernet sfp match the configured type	snap shot of ethernet sfp type <i>This element is only shown in detail mode.</i>

103.55 Alarm Snap-shot Ether-Sfp Status Command

Command Description

This command show the alarm snap-shot of Ether-Sfp

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

> show alarm snap-shot uplink-ether-sfp [(index)]

Command Parameters

Table 103.55-1 "Alarm Snap-shot Ether-Sfp Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm snap shot table index

Command Output

Table 103.55-2 "Alarm Snap-shot Ether-Sfp Status Command" Display parameters

Specific Information		
name	Type	Description
port	Parameter type: <Itf::EthernetPortIndex> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number	identifies the physical position of the port <i>This element is only shown in detail mode.</i>
uplink-sfp-los	Parameter type: <Alarm::EthSfpLos> (yes no) Possible values: - yes : ethernet sfp los error	snap shot of uplink ethernet sfp los <i>This element is only shown in detail mode.</i>

name	Type	Description
	- no : ethernet sfp los normal	
uplink-sfp-tx-fail	Parameter type: <Alarm::EthSfpTxFail> (yes no) Possible values: - yes : ethernet sfp Tx Failure - no : ethernet sfp Tx normal	snap shot of uplink ethernet sfp tx <i>This element is only shown in detail mode.</i>
uplink-sfp-not-prst	Parameter type: <Alarm::EthSfpNotPrst> (yes no) Possible values: - yes : ethernet sfp not detected - no : ethernet sfp detected	snap shot of uplink ethernet sfp presence <i>This element is only shown in detail mode.</i>
uplink-sfp-inv-id	Parameter type: <Alarm::EthSfpInvalid> (yes no) Possible values: - yes : ethernet sfp id invalid - no : ethernet sfp id normal	snap shot of uplink ethernet sfp invalid id <i>This element is only shown in detail mode.</i>
uplink-sfp-t-exceed	Parameter type: <Alarm::EthSfpTempExceed> (yes no) Possible values: - yes : ethernet sfp temperature exceed - no : ethernet sfp temperature normal	snap shot of uplink ethernet sfp temperature <i>This element is only shown in detail mode.</i>
uplink-sfp-mismatch	Parameter type: <Alarm::EthSfpMismatch> (yes no) Possible values: - yes : ethernet sfp mismatch the configured type - no : ethernet sfp match the configured type	snap shot of uplink ethernet sfp type mismatch <i>This element is only shown in detail mode.</i>

103.56 Alarm Snap-shot SIP Termination Status Command

Command Description

This command show the alarm snap-shot of Qos Slot

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

> show alarm snap-shot qos-slot [(index)]

Command Parameters

Table 103.56-1 "Alarm Snap-shot SIP Termination Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm snapshot table index

Command Output

Table 103.56-2 "Alarm Snap-shot SIP Termination Status Command" Display parameters

Specific Information		
name	Type	Description
board-position	Parameter type: <Equiptm::SlotIndex> (lt : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> nt-a nt-b nt acu : <Eqpt::RackId> / <Eqpt::ShelfId> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::EqSlotId> ext-a : <Eqpt::RackId> / <Eqpt::ShelfId> ext-b : <Eqpt::RackId> / <Eqpt::ShelfId> ctrl : <Eqpt::RackId> / <Eqpt::ShelfId> vlt : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::VirtualSlotId>) Possible values: - lt : lt-slot - vlt : virtual LT slot (VVPS board can only be planned at NANT-E / FANT-F)	identify where the alarm has occurred. <i>This element is always shown.</i>

name	Type	Description
	- nt-a : nt-a slot - nt-b : nt-b slot - nt : nt slot - ext-a : nt-a slot in an extension shelf - ext-b : nt-b slot in an extension shelf - acu : acu slot - ctrl : ctrl-slot Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::VirtualSlotId> - the virtual LT slot number Field type <Eqpt::EqSlotId> - the equipment slot number	
up-overflow	Parameter type: <Alarm::up-overflow> (yes no) Possible values: - yes : up overflow alarm - no : no up overflow alarm	Check LT load in upstream. <i>This element is always shown.</i>
dw-overflow	Parameter type: <Alarm::dw-overflow> (yes no) Possible values: - yes : down overflow alarm - no : no down overflow alarm	Check LT load in downstream. <i>This element is always shown.</i>
upobc-overflow	Parameter type: <Alarm::upobc-overflow> (yes no) Possible values: - yes : up to obc overflow alarm - no : no up to obc overflow alarm	Check LT load to OBC in upstream. <i>This element is always shown.</i>
dwobc-overflow	Parameter type: <Alarm::dwobc-overflow> (yes no) Possible values: - yes : down to obc overflow alarm - no : no down to obc overflow alarm	Check LT load to OBC in downstream. <i>This element is always shown.</i>
lwpriority-overflow	Parameter type: <Alarm::lwpriority-overflow> (yes no) Possible values: - yes : alarm - no : no dying gasp alarm	Check Voice and Video load. <i>This element is always shown.</i>
fanout	Parameter type: <Alarm::fanout> (yes no) Possible values: - yes : fan out alarm - no : no fan out alarm	Check LT Load. <i>This element is always shown.</i>

103.57 Alarm Snap-shot SIP Termination Status Command

Command Description

This command show the alarm snap-shot of Qos Queue

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm snap-shot qos-queue [ (index) ]
```

Command Parameters

Table 103.57-1 "Alarm Snap-shot SIP Termination Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm snapshot table index

Command Output

Table 103.57-2 "Alarm Snap-shot SIP Termination Status Command" Display parameters

Specific Information		
name	Type	Description
port	Parameter type: <Itf::PhyLine> (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> / <Eqpt::OntPortId> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / voip <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / vuni ont : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> ont.ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> uni.ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> /	identifies the physical position of the port <i>This element is always shown.</i>

name	Type	Description
	<Eqpt::Ng2OntSlotId> / <Eqpt::Ng2OntPortId> uni.ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / vuni) Possible values: - ont : ont - ont.ng2 : ngpon2 ONT style identification - uni.ng2 : ngpon2 UNI style identification Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number Field type <Eqpt::PonId> - the PON identifier Field type <Eqpt::OntId> - the ONT identifier Field type <Eqpt::ChannelGroupId> - the channel group identifier Field type <Eqpt::SubChannelGroupId> - the subchannel group identifier Field type <Eqpt::Ng2OntId> - the NG2 ONT identifier Possible values: - voip : virtual uni identifier obsolete alternative replaced by vuni - vuni : virtual uni identifier Possible values: - vuni : virtual NGPON2 uni identifier Field type <Eqpt::OntSlotId> - the ONT SLOT identifier Field type <Eqpt::OntPortId> - the ONT PORT identifier Field type <Eqpt::Ng2OntSlotId> - the NGPON2 ONT SLOT identifier Field type <Eqpt::Ng2OntPortId> - the NGPON2 ONT PORT identifier	
queue	Parameter type: <Qos::AlarmQueues> - identify where the alarm has occurred - range: [0...7]	identify where the alarm has occurred. <i>This element is always shown.</i>
queue-discard-overflow	Parameter type: <Alarm::queue-discard-overflow> (yes no) Possible values: - yes : queue discard alarm - no : no queue discard alarm	Check the corresponding queue Load. <i>This element is always shown.</i>
queue-load	Parameter type: <Alarm::queue-load> (yes no) Possible values: - yes : queue load alarm - no : no queue load alarm	Check the corresponding queue Load. <i>This element is always shown.</i>
queue-peak-usage	Parameter type: <Alarm::queue-peak-usage> (yes no)	Check the corresponding queue peak usage. <i>This element is always shown.</i>

103 Alarm Snap-shot Status Commands

name	Type	Description
	Possible values: - yes : queue peak usage alarm - no : no queue peak usage alarm	

103.58 Alarm File Transfer Server Status Command

Command Description

This command displays the snap-shot of file transfer server alarm

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

> show alarm snap-shot filetransfer [(index)]

Command Parameters

Table 103.58-1 "Alarm File Transfer Server Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm snap shot table index

Command Output

Table 103.58-2 "Alarm File Transfer Server Status Command" Display parameters

Specific Information		
name	Type	Description
server-id	Parameter type: <Alarm::FileTransfer> - next hop IP address	identify where the alarm has occurred. <i>This element is only shown in detail mode.</i>
fileserv-unavail	Parameter type: <Alarm::FileTransferUnavail> (unavailable available) Possible values: - unavailable : file transfer Server unavailable or file transfer failed - available : file transfer server available	current status specifying that whether file transfer server available <i>This element is only shown in detail mode.</i>

103.59 Alarm Lsm Redundancy Status Command

Command Description

This command displays the snap-shot of Lsm Redundancy alarm

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

> show alarm snap-shot lsmredundancy [(index)]

Command Parameters

Table 103.59-1 "Alarm Lsm Redundancy Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm snap shot table index

Command Output

Table 103.59-2 "Alarm Lsm Redundancy Status Command" Display parameters

Specific Information		
name	Type	Description
board-station	Parameter type: <Equipm::LtSlotIndex> (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId>) Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number	physical number of the slot for lsm redundancy alarms <i>This element is only shown in detail mode.</i>
loss-lsmswp-cap	Parameter type: <Alarm::SwoCap> (loss not-loss) Possible values: - loss : system loss of the swichover capability - not-loss : system not loss of the swichover capability	snapshot of the swichover capability in a redundant system <i>This element is only shown in detail mode.</i>
data-xvps-diff	Parameter type: <Alarm::DataXvps> (invalid valid) Possible values:	log status of the data of xvps pair <i>This element is only shown in detail mode.</i>

name	Type	Description
	- invalid : data of xvps pair is not the same - valid : data of xvps pair is same	

103.60 Alarm L2 Forward Status Command

Command Description

This command displays the snap-shot of l2 forward alarm

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm snap-shot l2forward [ (index) ]
```

Command Parameters

Table 103.60-1 "Alarm L2 Forward Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm snap shot table index

Command Output

Table 103.60-2 "Alarm L2 Forward Status Command" Display parameters

Specific Information		
name	Type	Description
bridgeport	Parameter type: <Vlan::BridgePort> (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::VpId> : <Eqpt::VcId> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> / <Eqpt::OntPortId> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / voip <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / vuni <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::LLId> ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Ng2::OntId> / <Eqpt::Ng2OntSlotId> / <Eqpt::Ng2OntPortId> ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Ng2::OntId> / vuni) Possible values:	identify the bridge port where the alarm has occurred. <i>This element is only shown in detail mode.</i>

name	Type	Description
	- ng2 : ngpon2 vlan bridge port - Field type <Eqpt::RackId> - the rack number - Field type <Eqpt::ShelfId> - the shelf number - Field type <Eqpt::SlotId> - the LT slot number - Field type <Eqpt::PortId> - the port number - Field type <Eqpt::VpiId> - atm VPI - Field type <Eqpt::VciId> - atm VCI - Field type <Eqpt::PonId> - the PON identifier - Field type <Eqpt::ChannelGroupId> - the channel group identifier - Field type <Eqpt::SubChannelGroupId> - the subchannel group identifier - Field type <Eqpt::OntId> - the ONT identifier - Field type <Ng2::OntId> - the ONT identifier - Possible values: - voip : virtual uni identifier - obsolete alternative replaced by vuni - vuni : virtual uni identifier - Possible values: - vuni : virtual NGPON2 uni identifier - Field type <Eqpt::OntSlotId> - the ONT SLOT identifier - Field type <Eqpt::OntPortId> - the ONT PORT identifier - Field type <Eqpt::Ng2OntSlotId> - the NGPON2 ONT SLOT identifier - Field type <Eqpt::Ng2OntPortId> - the NGPON2 ONT PORT identifier - Field type <Eqpt::LLId> - the LLID identifier,range 1 for EPON,range 1-8 for DPOE	
vlan-id	Parameter type: <Vlan::StackedVlanSigned> (<Vlan::UVlanIndex> stacked : <Vlan::SVlanIndex> : <Vlan::CVlanIndex>) Possible values: - stacked : stacked vlan identity - Field type <Vlan::UVlanIndex> - unstacked vlan identity - range: [1...4093,4096] - Field type <Vlan::SVlanIndex> - service vlan identity - range: [2...4093,4094] - Field type <Vlan::CVlanIndex> - customer vlan identity - range: [0...4093,4094,4095,4096]	identify the vlan id where the alarm has occurred. <i>This element is only shown in detail mode.</i>
mac-conflict	Parameter type: <Alarm::MACconflict> (yes no) Possible values:	specifies whether duplicate mac address from the bridge port. <i>This element is only shown in detail mode.</i>

103 Alarm Snap-shot Status Commands

name	Type	Description
	- yes : duplicate mac address from this bridge port - no : no duplicate mac address from this bridge port	
vmac-full	Parameter type: <Alarm::VMACFull> (yes no) Possible values: - yes : virtual mac entry full on this bridge port - no : no virtual mac entry full on this bridge port	specifies whether virtual mac is full on the bridge port. <i>This element is only shown in detail mode.</i>

103.61 Alarm Snap-shot External Device Status Command

Command Description

This command show the alarm snap-shot of external-device

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

> show alarm snap-shot external-device [(index)]

Command Parameters

Table 103.61-1 "Alarm Snap-shot External Device Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm snap shot table index

Command Output

Table 103.61-2 "Alarm Snap-shot External Device Status Command" Display parameters

Specific Information		
name	Type	Description
loss-env-mon	Parameter type: <Alarm::LossEnvMon> (lost not-lost) Possible values: - lost : env-mon box lost or not alive - not-lost : env-mon box exists	snap shot status of env-monitor box <i>This element is only shown in detail mode.</i>

103.62 Alarm Snap-shot Multicast Source Status Command

Command Description

This command displays the multicast source alarm snap-shot status.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm snap-shot mcsrc [ (index) ]
```

Command Parameters

Table 103.62-1 "Alarm Snap-shot Multicast Source Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm snap shot table index

Command Output

Table 103.62-2 "Alarm Snap-shot Multicast Source Status Command" Display parameters

Specific Information		
name	Type	Description
grp-ip-addr	Parameter type: <Alarm::IpAddress> - IPv4-address	identify the mcast addr where the alarm has occurred. <i>This element is only shown in detail mode.</i>
slot-id	Parameter type: <Equipm::FullLtSlotIndex> lt : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> Possible values: - lt : lt-slot Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number	identify where the alarm has occurred. <i>This element is only shown in detail mode.</i>
stream-lost	Parameter type: <Alarm::McastLoss> (yes	current status of the alarm specifying if the pon mcast video

name	Type	Description
	no) Possible values: - yes : pon mcast video stream lost - no : pon mcast video stream not lost	stream is lost or not <i>This element is only shown in detail mode.</i>

103.63 Vlanport Alarm Snapshot Status Command

Command Description

This command displays the vlanport alarm snap-shot status.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm snap-shot vlanport [ (index) ]
```

Command Parameters

Table 103.63-1 "Vlanport Alarm Snapshot Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm snap shot table index

Command Output

Table 103.63-2 "Vlanport Alarm Snapshot Status Command" Display parameters

Specific Information		
name	Type	Description
vlanport	Parameter type: <Itf::VlanPortInterface> (vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::VpiId> : <Eqpt::VciId> : <Eqpt::UnstackedVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::UnstackedVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::VpiId> : <Eqpt::VciId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> / <Eqpt::OntPortId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> / <Eqpt::OntPortId> : <Eqpt::UnstackedVlan>	identify the provisioned vlanport where the alarm has occurred. <i>This element is only shown in detail mode.</i>

name	Type	Description
	<pre> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / voip : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / vuni : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / voip : <Eqpt::UnstackedVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / vuni : <Eqpt::UnstackedVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::LLId> : <Eqpt::UnstackedVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::LLId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan-port:ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Ng2::OntId> / <Eqpt::Ng2OntSlotId> / <Eqpt::Ng2OntPortId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan-port:ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Ng2::OntId> / <Eqpt::Ng2OntSlotId> / <Eqpt::Ng2OntPortId> : <Eqpt::UnstackedVlan> vlan-port:ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Ng2::OntId> / vuni : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan-port:ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Ng2::OntId> / vuni : <Eqpt::UnstackedVlan>) Possible values: - vlan-port : vlan port - vlan-port:ng2 : ngpon2 vlan port Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number Field type <Eqpt::VpiId> - atm VPI Field type <Eqpt::VciId> - atm VCI Field type <Eqpt::PonId> - the PON identifier Field type <Eqpt::OntId> - the ONT identifier Field type <Eqpt::ChannelGroupId> - the channel group identifier Field type <Eqpt::SubChannelGroupId> - the subchannel group identifier Field type <Ng2::OntId> - the ONT identifier </pre>	

103 Alarm Snap-shot Status Commands

name	Type	Description
	Possible values: - voip : virtual uni identifier obsolete alternative replaced by vuni - vuni : virtual uni identifier Possible values: - vuni : virtual NGPON2 uni identifier Field type <Eqpt::OntSlotId> - the ONT SLOT identifier Field type <Eqpt::OntPortId> - the ONT PORT identifier Field type <Eqpt::Ng2OntSlotId> - the NGPON2 ONT SLOT identifier Field type <Eqpt::Ng2OntPortId> - the NGPON2 ONT PORT identifier Field type <Eqpt::LLId> - the LLID identifier, range 1 for EPON, range 1-8 for DPOE Possible values: - stacked : stacked vlan identity Field type <Eqpt::UnstackedVlan> - unstacked vlan id Field type <Eqpt::SVlan> - service vlan id Field type <Eqpt::CVlan> - customer vlan id	
svc-mismatch	Parameter type: <Alarm::SVCMismatch> (yes no) Possible values: - yes : configuration request not accepted - no : configuration accepted	current status of the alarm specifying if the configuration for a provisioned vlanport is accepted or not. <i>This element is only shown in detail mode.</i>

103.64 BGP Alarm SnapShot Status Command

Command Description

This command displays the SnapShot bgp alarm log status.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm snap-shot bgp [ (index) ]
```

Command Parameters

Table 103.64-1 "BGP Alarm SnapShot Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm log table index

Command Output

Table 103.64-2 "BGP Alarm SnapShot Status Command" Display parameters

Specific Information		
name	Type	Description
router-id	Parameter type: <Ihub::Router> (base <Ihub::Router>) Possible values: - base : base router Field type <Ihub::Router> - vprn service-id - range: [1...2147483647]	identifies the vprn service-id or the base router where the alarm has occurred <i>This element is only shown in detail mode.</i>
neighbor-idx	Parameter type: <Alarm::AlarmIdentifIdxOrZero> - an unsigned integer	unique reference for the neighbor where the alarm occurred or zero when not applicable, neighbor is further specified in additional-info <i>This element is only shown in detail mode.</i>
additional-info	Parameter type: <Alarm::AddInfoString> - additional alarm information	identifies the neighbor where the alarm occurred or empty string if not applicable. <i>This element is only shown in</i>

103 Alarm Snap-shot Status Commands

name	Type	Description
		<i>detail mode.</i>
Only Show Details: current alarm status		
name	Type	Description
peer-down	Parameter type: <Alarm::PeerDown> (yes no) Possible values: - yes : operational state down - no : operational state up	specifies whether the BGP peer operational state is up or down <i>This element is only shown in detail mode.</i>
routes-mid-limit	Parameter type: <Alarm::RoutesMidLimit> (reached not-reached) Possible values: - reached : reached: 90% of max allowed routes learned - not-reached : less than 90% of max allowed routes learned	specifies whether 90% of the max nbr of routes BGP can learn from a peer is reached or not <i>This element is only shown in detail mode.</i>

103.65 RIP Alarm SnapShot Status Command

Command Description

This command displays the SnapShot rip alarm log status.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

> show alarm snap-shot rip [(index)]

Command Parameters

Table 103.65-1 "RIP Alarm SnapShot Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm log table index

Command Output

Table 103.65-2 "RIP Alarm SnapShot Status Command" Display parameters

Specific Information		
name	Type	Description
router-id	Parameter type: <Ihub::Router> (base <Ihub::Router>) Possible values: - base : base router Field type <Ihub::Router> - vprn service-id - range: [1...2147483647]	identifies the vprn service-id or the base router where the alarm has occurred <i>This element is only shown in detail mode.</i>

Only Show Details: current and previous alarm log status		
name	Type	Description
instance-down	Parameter type: <Alarm::InstanceDown> (yes no) Possible values: - yes : RIP instance down - no : RIP instance up	specifies whether RIP instance is down or not <i>This element is only shown in detail mode.</i>

103.66 LAG Alarm SnapShot Status Command

Command Description

This command displays the SnapShot lag alarm log status.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

> show alarm snap-shot lag [(index)]

Command Parameters

Table 103.66-1 "LAG Alarm SnapShot Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm log table index

Command Output

Table 103.66-2 "LAG Alarm SnapShot Status Command" Display parameters

Specific Information		
name	Type	Description
lag-id	Parameter type: <Alarm::LagId> - link aggregation group id - range: [1...64]	Identifies the lag where the alarm has occurred <i>This element is only shown in detail mode.</i>
sub-group	Parameter type: <Alarm::AlarmIdentifIdxOrZero> - an unsigned integer	Identifies the lag subgroup for which the alarm has occurred or zero when not applicable. <i>This element is only shown in detail mode.</i>

Only Show Details: current alarm snap-shot status		
name	Type	Description
lag-down	Parameter type: <Alarm::EthLagDown> (yes no) Possible values: - yes : lag down - no : lag not down	specifies whether the link aggregation group is down or not <i>This element is only shown in detail mode.</i>
subgrp-thres-reach	Parameter type: <Alarm::LagSubgrpThresReach> (reached	specifies whether the lag subgroup threshold is reached or

name	Type	Description
	not-reached) Possible values: - reached : sub-group threshold reached - not-reached : sub-group threshold not reached	not <i>This element is only shown in detail mode.</i>
subgrp-switch-fail	Parameter type: <Alarm::LagSubgrpSwitchFail> (yes no) Possible values: - yes : lag subgroup switchover failed - no : lag subgroup switchover did not fail	specifies whether the lag subgroup switchover failed or not <i>This element is only shown in detail mode.</i>
no-free-port-inbase	Parameter type: <Alarm::LagNoUnpinFreePorts> (yes no) Possible values: - yes : No free ports available for un pinned traffic - no : free ports available for un pinned traffic	specifies whether the free ports available for unpinned traffic or not <i>This element is only shown in detail mode.</i>

103.67 ihub-general Alarm SnapShot Status Command

Command Description

This command displays the SnapShot ihub-general alarm log status.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm snap-shot ihub-general [ (index) ]
```

Command Parameters

Table 103.67-1 "ihub-general Alarm SnapShot Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm log table index

Command Output

Table 103.67-2 "ihub-general Alarm SnapShot Status Command" Display parameters

Only Show Details: current alarm snap-shot status		
name	Type	Description
arp-limit	Parameter type: <Alarm::ArpLimit> (reached not-reached) Possible values: - reached : ARP tbl threshold reached or exceeded - not-reached : ARP tbl entries below threshold	specifies whether the nbr of ARP entries has reached the max threshold or not <i>This element is only shown in detail mode.</i>
switch-out-of-res	Parameter type: <Alarm::IhubSwitchOutOfResource> (yes no) Possible values: - yes : lack of resources in switch - no : no resource issues detected	specifies whether e.g. storing a configuration in the hardware has failed or not, due to a lack of resources in the switch. <i>This element is only shown in detail mode.</i>
ipv6-nc-limit	Parameter type: <Alarm::IPv6NeighborCacheLimit> (reached not-reached) Possible values:	specifies whether the number of ipv6 neighbor cache entries reached maximum threshold or not.

name	Type	Description
	- reached : neighbor cache up threshold reached - not-reached : neighbor cache entries within limit	<i>This element is only shown in detail mode.</i>
dhcp-session-oor	Parameter type: <Alarm::DhcpSessionOutOfResource> (yes no) Possible values: - yes : lack of resources for dhcp - no : no resource issues detected for dhcp	specifies whether dhcp session is out of resources or not. <i>This element is only shown in detail mode.</i>
fdb-limit	Parameter type: <Alarm::IhubL2FdbFull> (reached not-reached) Possible values: - reached : layer 2 fdb table entries reached upper threshold for the node - not-reached : layer 2 fdb table entries within limit for the node	specifies whether the number of layer 2 fdb table entries reached maximum threshold or not. <i>This element is only shown in detail mode.</i>
mac-limit	Parameter type: <Alarm::IhubL2MacFull> (reached not-reached) Possible values: - reached : Internal Mac entries reached upper - not-reached : Internal Mac entries within limit	specifies whether the number of internal Mac entries reached maximum threshold or not. <i>This element is only shown in detail mode.</i>

103.68 VPRN Alarm SnapShot Status Command

Command Description

This command displays the SnapShot vprn alarm log status.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm snap-shot vprn [ (index) ]
```

Command Parameters

Table 103.68-1 "VPRN Alarm SnapShot Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm log table index

Command Output

Table 103.68-2 "VPRN Alarm SnapShot Status Command" Display parameters

Specific Information		
name	Type	Description
router-id	Parameter type: <Ihub::Router> (base <Ihub::Router>) Possible values: - base : base router Field type <Ihub::Router> - vprn service-id - range: [1...2147483647]	identifies the vprn service-id or the base router where the alarm has occurred. <i>This element is only shown in detail mode.</i>
if-index	Parameter type: <Alarm::IdentificationIdxOrZero> - a signed integer	unique reference for the interface for which the alarm occurred or zero when not applicable. <i>This element is only shown in detail mode.</i>
interface	Parameter type: <Alarm::AddInfoString> - additional alarm information	identifies the interface for which the alarm occurred or empty string if not applicable. <i>This element is only shown in detail mode.</i>

Only Show Details: current alarm snap-shot status

name	Type	Description
routes-limit	Parameter type: <Alarm::RoutesLimit> (reached not-reached) Possible values: - reached : ip routes limit reached or exceeded - not-reached : ip routes within limit	specifies whether the limit of dynamic routes is reached/exceeded or not <i>This element is only shown in detail mode.</i>
ipv6-routes-limit	Parameter type: <Alarm::IPv6RoutesLimit> (reached not-reached) Possible values: - reached : ipv6 routes limit reached or exceeded - not-reached : ipv6 routes within limit	specifies whether the number of dynamic ipv6 routes is approaching or has reached its limit <i>This element is only shown in detail mode.</i>
dhcpv6-lease-limit	Parameter type: <Alarm::DHCPV6LeaseLimit> (reached not-reached) Possible values: - reached : dhcpv6 relay leases limit reached or exceeded - not-reached : dhcpv6 relay leases within limit	specifies whether the limit of dhcpv6 relay leases is reached or not <i>This element is only shown in detail mode.</i>
dhcpv4-lease-limit	Parameter type: <Alarm::DHCPV4LeaseLimit> (reached not-reached) Possible values: - reached : dhcpv4 relay leases limit reached or exceeded - not-reached : dhcpv4 relay leases within limit	specifies whether the limit of dhcpv4 relay leases is reached or not <i>This element is only shown in detail mode.</i>

103.69 ISIS Alarm SnapShot Status Command

Command Description

This command displays the SnapShot isis alarm log status.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

> show alarm snap-shot isis [(index)]

Command Parameters

Table 103.69-1 "ISIS Alarm SnapShot Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm log table index

Command Output

Table 103.69-2 "ISIS Alarm SnapShot Status Command" Display parameters

Specific Information		
name	Type	Description
router-id	Parameter type: <Ihub::Router> (base <Ihub::Router>) Possible values: - base : base router Field type <Ihub::Router> - vprn service-id - range: [1...2147483647]	identifies the vprn service-id or the base router where the alarm has occurred <i>This element is only shown in detail mode.</i>
adjacency-index	Parameter type: <Alarm::IdentificationIdxOrZero> - a signed integer	unique reference for the adjacency where the alarm occurred or zero when not applicable, adjacency is further specified in additional-info <i>This element is only shown in detail mode.</i>
additional-info	Parameter type: <Alarm::AddInfoString> - additional alarm information	identifies the adjacency:instance/interface where the alarm occurred or empty string if not applicable.

name	Type	Description
		<i>This element is only shown in detail mode.</i>

Only Show Details: current alarm snap-shot status		
name	Type	Description
adjacency-down	Parameter type: <Alarm::AdjacencyDown> (yes no) Possible values: - yes : interface down - no : interface up	specifies whether isis adjacency is down or not <i>This element is only shown in detail mode.</i>
adjacency-reject	Parameter type: <Alarm::AdjacencyReject> (yes no) Possible values: - yes : interface mismatch - no : no interface mismatch	specifies whether isis adjacency is rejected or not <i>This element is only shown in detail mode.</i>
instance-down	Parameter type: <Alarm::IsisDown> (yes no) Possible values: - yes : ISIS instance down - no : ISIS instance up	specifies whether ISIS instance is down or not <i>This element is only shown in detail mode.</i>

103.70 OSPF Alarm SnapShot Status Command

Command Description

This command displays the SnapShot ospf alarm log status.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

> show alarm snap-shot ospf [(index)]

Command Parameters

Table 103.70-1 "OSPF Alarm SnapShot Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm log table index

Command Output

Table 103.70-2 "OSPF Alarm SnapShot Status Command" Display parameters

Specific Information		
name	Type	Description
router-id	Parameter type: <Ihub::Router> (base <Ihub::Router>) Possible values: - base : base router Field type <Ihub::Router> - vprn service-id - range: [1...2147483647]	identifies the vprn service-id or the base router where the alarm has occurred <i>This element is only shown in detail mode.</i>
neighbor-idx	Parameter type: <Alarm::IdentificationIdxOrZero> - a signed integer	unique reference for the neighbor where the alarm occurred or zero when not applicable, neighbor is further specified in additional-info <i>This element is only shown in detail mode.</i>
additional-info	Parameter type: <Alarm::AddInfoString> - additional alarm information	identifies the neighbor/instance where the alarm occurred or empty string if not applicable <i>This element is only shown in</i>

name	Type	Description
		<i>detail mode.</i>

Only Show Details: snap-shot alarm status		
name	Type	Description
lsa-limit	Parameter type: <Alarm::LsaLimit> (reached not-reached) Possible values: - reached : external LSA limit reached - not-reached : external LSAs within limitation	specifies whether the limit of received external LSAs is reached or not <i>This element is only shown in detail mode.</i>
lsa-mid-limit	Parameter type: <Alarm::LsaMidLimit> (reached not-reached) Possible values: - reached : 90% of LSA limit reached - not-reached : less than 90% of LSA limit	specifies whether 90% of the limit of received external LSAs is reached or not <i>This element is only shown in detail mode.</i>
neighbor-down	Parameter type: <Alarm::NeighborDown> (yes no) Possible values: - yes : OSPF neighbor down - no : OSPF neighbor up	specifies whether ospf neighbour is down or not <i>This element is only shown in detail mode.</i>
instance-down	Parameter type: <Alarm::OspfDown> (yes no) Possible values: - yes : OSPF instance down - no : OSPF instance up	specifies whether OSPF instance is down or not <i>This element is only shown in detail mode.</i>
v3-lsa-limit	Parameter type: <Alarm::V3LsaLimit> (reached not-reached) Possible values: - reached : external OSPFv3 LSA limit reached - not-reached : external OSPFv3 LSAs within limitation	specifies whether the limit of received external OSPFv3 LSAs is reached or not <i>This element is only shown in detail mode.</i>
v3-lsa-mid-limit	Parameter type: <Alarm::V3LsaMidLimit> (reached not-reached) Possible values: - reached : 90% of OSPFv3 LSA limit reached - not-reached : less than 90% of OSPFv3 LSA limit	specifies whether 90% of the limit of received external OSPFv3 LSAs is reached or not <i>This element is only shown in detail mode.</i>
v3-neighbor-down	Parameter type: <Alarm::V3NeighborDown> (yes no) Possible values: - yes : OSPFv3 neighbor down - no : OSPFv3 neighbor up	specifies whether OSPFv3 neighbor is down or not <i>This element is only shown in detail mode.</i>
v3-instance-down	Parameter type: <Alarm::V3OspfDown> (yes no) Possible values: - yes : OSPFv3 instance down - no : OSPFv3 instance up	specifies whether OSPFv3 instance is down or not <i>This element is only shown in detail mode.</i>

103.71 ihub-l2forward Alarm SnapShot Status Command

Command Description

This command displays the ihub-l2forward SnapShot alarm log status.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm snap-shot ihub-l2forward [ (index) ]
```

Command Parameters

Table 103.71-1 "ihub-l2forward Alarm SnapShot Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm log table index

Command Output

Table 103.71-2 "ihub-l2forward Alarm SnapShot Status Command" Display parameters

Specific Information		
name	Type	Description
port	Parameter type: <Ihub::EtherPortAndLag> (nt-a : sfp : <Alarm::FacePlatePortIndex> nt-a : xfp : <Alarm::FacePlatePortIndex> nt-a : qsfp : <Alarm::FacePlatePortIndex> nt-a : eth : <Alarm::FacePlatePortIndex> nt-b : sfp : <Alarm::FacePlatePortIndex> nt-b : xfp : <Alarm::FacePlatePortIndex> nt-b : qsfp : <Alarm::FacePlatePortIndex> nt-b : eth : <Alarm::FacePlatePortIndex> ntio-1 : sfp : <Alarm::FacePlatePortIndex> ntio-1 : xfp : <Alarm::FacePlatePortIndex> ntio-1 : qsfp : <Alarm::FacePlatePortIndex> ntio-2 : sfp : <Alarm::FacePlatePortIndex> ntio-2 : xfp : <Alarm::FacePlatePortIndex> ntio-2 : qsfp : <Alarm::FacePlatePortIndex> lt : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId>	identifies the physical position of the port <i>This element is only shown in detail mode.</i>

name	Type	Description
	lag : <Alarm::IhubLagId> nt-a : qsfp : <Alarm::QsfpPortIndex> - <Alarm::LaneIndex> nt-b : qsfp : <Alarm::QsfpPortIndex> - <Alarm::LaneIndex>) Possible values: - nt-a : the nt-a slot - nt-b : the nt-b slot - ntio-1 : an nt applique slot in a single or multiple-ntio-shelf - ntio-2 : an nt applique slot in a multiple-ntio-shelf - lt : the lt slot - lag : key word to specify link aggregation group - nt-a : the nt-a slot - nt-b : the nt-b slot Possible values: - sfp : SFP port - xfp : XFP port - qsfp : QSFP port - eth : RJ45 or lemi port Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Alarm::IhubLagId> - link aggregation group id Field type <Alarm::FacePlatePortIndex> - the faceplate port number Field type <Alarm::QsfpPortIndex> - the qsfp port number Field type <Alarm::LaneIndex> - the lane number of qsfp port	
service-id	Parameter type: <Alarm::ServiceId> - a profile index value - range: [1...2147483647]	identifies the vpls service-id where the alarm has occurred. <i>This element is only shown in detail mode.</i>

Only Show Details: snap-shot alarm status		
name	Type	Description
stp-exception	Parameter type: <Alarm::StpException> (yes no) Possible values: - yes : stp exception condition detected on the port - no : no stp exception condition detected	specifies whether an STP exception condition is present on the port or not <i>This element is only shown in detail mode.</i>
stp-root-guard	Parameter type: <Alarm::StpRootGuard> (violation no violation) Possible values: - violation : stp root guard violation detected on the port - no violation : no stp root guard violation detected	specifies whether an STP root-guard violation present or not <i>This element is only shown in detail mode.</i>

103.72 VPLS Alarm SnapShot Status Command

Command Description

This command displays the SnapShot VPLS alarm log status.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm snap-shot vpls [ (index) ]
```

Command Parameters

Table 103.72-1 "VPLS Alarm SnapShot Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm log table index

Command Output

Table 103.72-2 "VPLS Alarm SnapShot Status Command" Display parameters

Specific Information		
name	Type	Description
service-id	Parameter type: <Alarm::ServiceId> - a profile index value - range: [1...2147483647]	identifies the vpls service-id where the alarm has occurred. <i>This element is only shown in detail mode.</i>
mac-idx	Parameter type: <Alarm::IdentificationIdxOrZero> - a signed integer	unique reference for the duplicate mac alarm and zero for all other alarms; duplicate mac is further specified in additional-info <i>This element is only shown in detail mode.</i>
additional-info	Parameter type: <Alarm::AddInfoStringVpls> - additional alarm information	Additional information regarding duplicate MAC alarm <i>This element is only shown in detail mode.</i>

Only Show Details: snap-shot alarm status		
name	Type	Description
mfib-limit	Parameter type: <Alarm::MfibLimit> (reached not-reached)	specifies whether the number of entries in the multicast FIB table reached its limit or not

name	Type	Description
	Possible values: - reached : mfib table size limit reached - not-reached : mfib table size below limit.	<i>This element is only shown in detail mode.</i>
duplicate-mac	Parameter type: <Alarm::DuplicateMac> (yes no) Possible values: - yes : duplicate mac detected on vpls - no : no duplicate mac on the vpls	specifies whether a duplicate MAC address is detected or not <i>This element is only shown in detail mode.</i>
fdb-limit	Parameter type: <Alarm::FdbLimit> (reached not-reached) Possible values: - reached : fdb table size limit reached - not-reached : fdb table size below low limit	specifies whether the number of entries in the fdb table reached the upper limit or dropped below the lower limit. <i>This element is only shown in detail mode.</i>
self-duplic-mac	Parameter type: <Alarm::Selfduplic> (yes no) Possible values: - yes : self duplicate mac detected on a sap of the vpls - no : no self duplicate mac on a sap of the vpls	specifies whether a duplicate of a system owned mac address is detected on a sap of the vpls service or not <i>This element is only shown in detail mode.</i>
sdp-self-dup-mac	Parameter type: <Alarm::SdpSelfdupMac> (yes no) Possible values: - yes : self duplicate mac detected on sdp binding of the vpls - no : no self duplicate mac on a sdp binding of the vpls	specifies whether a duplicate of a system owned mac address is detected on a sdp binding of the vpls service or not <i>This element is only shown in detail mode.</i>

103.73 IHUB-Equip Alarm SnapShot Status Command

Command Description

This command displays the SnapShot Ihub-equip alarm log status.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

> show alarm snap-shot ihub-equip [(index)]

Command Parameters

Table 103.73-1 "IHUB-Equip Alarm SnapShot Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm log table index

Command Output

Table 103.73-2 "IHUB-Equip Alarm SnapShot Status Command" Display parameters

Specific Information		
name	Type	Description
slot	Parameter type: <Alarm::NtSlotId> (nt-a nt-b) Possible values: - nt-a : nt-a slot - nt-b : nt-b slot	identifies the slot where the alarm has been detected. <i>This element is only shown in detail mode.</i>
additional-info	Parameter type: <Alarm::AddInfoString> - additional alarm information	additional information regarding the out-of-mem alarm, containing the name of the Software Module triggering this alarm <i>This element is only shown in detail mode.</i>

Only Show Details: snap-shot alarm status		
name	Type	Description
peer-comm	Parameter type: <Alarm::PeerComm> (fail	specifies whether peer-to-peer communication has failed or not

name	Type	Description
	no fail) Possible values: - fail : peer-to-peer communication failure - no fail : no peer-to-peer communication failure	<i>This element is only shown in detail mode.</i>
sw-fail	Parameter type: <Alarm::SwFail> (yes no) Possible values: - yes : software failure detected - no : no software failure	specifies whether a software failure has occurred or not <i>This element is only shown in detail mode.</i>
hw-fail	Parameter type: <Alarm::HwFail> (yes no) Possible values: - yes : hardware failure detected - no : no hardware failure	specifies whether a hardware failure has occurred or not <i>This element is only shown in detail mode.</i>
link-fail	Parameter type: <Alarm::LinkFail> (yes no) Possible values: - yes : link failure detected - no : no link failiure	specifies whether a link failure has occurred or not <i>This element is only shown in detail mode.</i>
proc-overload	Parameter type: <Alarm::ProcOverload> (yes no) Possible values: - yes : processor overload detected - no : no processor overload	specifies whether an overload condition exists for the processor at ihub side <i>This element is only shown in detail mode.</i>
out-of-mem	Parameter type: <Alarm::OutOfMem> (yes no) Possible values: - yes : memory allocation failure - no : memory allocation successful	specifies whether memory allocation in ihub failed or not <i>This element is only shown in detail mode.</i>
ntp-comm	Parameter type: <Alarm::ntpCommLoss> (lost not-lost) Possible values: - lost : NTP communication lost - not-lost : NTP communication is not lost	specifies whether ntp communication is lost or not <i>This element is only shown in detail mode.</i>

103.74 IHUB-link Alarm SnapShot Status Command

Command Description

This command displays the SnapShot ihub-link alarm log status.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm snap-shot ihub-link [ (index) ]
```

Command Parameters

Table 103.74-1 "IHUB-link Alarm SnapShot Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm log table index

Command Output

Table 103.74-2 "IHUB-link Alarm SnapShot Status Command" Display parameters

Specific Information		
name	Type	Description
port	Parameter type: <Ihub::EtherPort> (nt-a : sfp : <Alarm::FacePlatePortIndex> nt-a : xfp : <Alarm::FacePlatePortIndex> nt-a : qsfp : <Alarm::FacePlatePortIndex> nt-a : cfp : <Alarm::FacePlatePortIndex> nt-a : eth : <Alarm::FacePlatePortIndex> nt-a : ieee1588 : <Alarm::FacePlatePortIndex> nt-a : ai : <Alarm::FacePlatePortIndex> nt-b : sfp : <Alarm::FacePlatePortIndex> nt-b : xfp : <Alarm::FacePlatePortIndex> nt-b : qsfp : <Alarm::FacePlatePortIndex> nt-b : cfp : <Alarm::FacePlatePortIndex> nt-b : eth : <Alarm::FacePlatePortIndex> nt-b : ieee1588 : <Alarm::FacePlatePortIndex> nt-b : ai : <Alarm::FacePlatePortIndex> ntio-1 : sfp : <Alarm::FacePlatePortIndex> ntio-1 : xfp : <Alarm::FacePlatePortIndex> ntio-1 : qsfp : <Alarm::FacePlatePortIndex> ntio-1 : cfp : <Alarm::FacePlatePortIndex> ntio-2 : sfp : <Alarm::FacePlatePortIndex>	identifies the ihub port where the alarm has occurred. <i>This element is only shown in detail mode.</i>

name	Type	Description
	ntio-2 : xfp : <Alarm::FacePlatePortIndex> ntio-2 : qsfp : <Alarm::FacePlatePortIndex> ntio-2 : cfp : <Alarm::FacePlatePortIndex> lt : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> nt-a : qsfp : <Alarm::QsfpPortIndex> - <Alarm::LaneIndex> nt-b : qsfp : <Alarm::QsfpPortIndex> - <Alarm::LaneIndex> ntio-1 : qsfp : <Alarm::QsfpPortIndex> - <Alarm::LaneIndex>) Possible values: - nt-a : the nt-a slot - nt-b : the nt-b slot - ntio-1 : an nt applique slot in a single or multiple-ntio-shelf - ntio-2 : an nt applique slot in a multiple-ntio-shelf - lt : the lt slot - nt-a : the nt-a slot - nt-b : the nt-b slot - ntio-1 : the nt-b slot Possible values: - sfp : SFP port - xfp : XFP port - qsfp : QSFP port - cfp : CFP port - eth : RJ45 or lemi port - ieee1588 : IEEE1588 port - ai : AI port Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Alarm::FacePlatePortIndex> - the faceplate port number Field type <Alarm::QsfpPortIndex> - the qsfp port number Field type <Alarm::LaneIndex> - the lane number of qsfp port	
additional-info	Parameter type: <Alarm::AddInfoString> - additional alarm information	additional information regarding the lagport-add-fail alarm, containing the failure reason: Either of these will apply: - unknown - adminkey-mismatch - sysid-mismatch - lacp-passive-both-ends - link-down <i>This element is only shown in detail mode.</i>

Only Show Details: alarm snap-shot status

name	Type	Description
link-down	Parameter type: <Alarm::IhubLink> (yes no) Possible values: - yes : link down - no : link up	specifies whether the link is down or not <i>This element is only shown in detail mode.</i>

103 Alarm Snap-shot Status Commands

name	Type	Description
lagport-add-fail	Parameter type: <Alarm::LagportAddFail> (yes no) Possible values: - yes : lag-port not added - no : lag-port successfully added	specifies whether a port was successfully added to a link aggregation group or not <i>This element is only shown in detail mode.</i>
conf-mismatch	Parameter type: <Alarm::SpeedMismatch> (yes no) Possible values: - yes : port configuration mismatch - no : no port configuration mismatch	specifies whether the inserted SFP or SFP+ type matches the planned speed and/or auto-negotiation for the port or not <i>This element is only shown in detail mode.</i>

103.75 IHUB-tca Alarm SnapShot Status Command

Command Description

This command displays the SnapShot ihub-tca alarm log status.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm snap-shot ihub-tca [ (index) ]
```

Command Parameters

Table 103.75-1 "IHUB-tca Alarm SnapShot Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm log table index

Command Output

Table 103.75-2 "IHUB-tca Alarm SnapShot Status Command" Display parameters

Specific Information		
name	Type	Description
port	Parameter type: <Ihub::EtherPort> (nt-a : sfp : <Alarm::FacePlatePortIndex> nt-a : xfp : <Alarm::FacePlatePortIndex> nt-a : qsfp : <Alarm::FacePlatePortIndex> nt-a : cfp : <Alarm::FacePlatePortIndex> nt-a : eth : <Alarm::FacePlatePortIndex> nt-a : ieee1588 : <Alarm::FacePlatePortIndex> nt-a : ai : <Alarm::FacePlatePortIndex> nt-b : sfp : <Alarm::FacePlatePortIndex> nt-b : xfp : <Alarm::FacePlatePortIndex> nt-b : qsfp : <Alarm::FacePlatePortIndex> nt-b : cfp : <Alarm::FacePlatePortIndex> nt-b : eth : <Alarm::FacePlatePortIndex> nt-b : ieee1588 : <Alarm::FacePlatePortIndex> nt-b : ai : <Alarm::FacePlatePortIndex> ntio-1 : sfp : <Alarm::FacePlatePortIndex> ntio-1 : xfp : <Alarm::FacePlatePortIndex> ntio-1 : qsfp : <Alarm::FacePlatePortIndex> ntio-1 : cfp : <Alarm::FacePlatePortIndex> ntio-2 : sfp : <Alarm::FacePlatePortIndex>	identifies the ihub port where the alarm has occurred. <i>This element is only shown in detail mode.</i>

103 Alarm Snap-shot Status Commands

name	Type	Description
	ntio-2 : xfp : <Alarm::FacePlatePortIndex> ntio-2 : qsfp : <Alarm::FacePlatePortIndex> ntio-2 : cfp : <Alarm::FacePlatePortIndex> lt : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> nt-a : qsfp : <Alarm::QsfpPortIndex> - <Alarm::LaneIndex> nt-b : qsfp : <Alarm::QsfpPortIndex> - <Alarm::LaneIndex> ntio-1 : qsfp : <Alarm::QsfpPortIndex> - <Alarm::LaneIndex>) Possible values: - nt-a : the nt-a slot - nt-b : the nt-b slot - ntio-1 : an nt applique slot in a single or multiple-ntio-shelf - ntio-2 : an nt applique slot in a multiple-ntio-shelf - lt : the lt slot - nt-a : the nt-a slot - nt-b : the nt-b slot - ntio-1 : the nt-b slot Possible values: - sfp : SFP port - xfp : XFP port - qsfp : QSFP port - cfp : CFP port - eth : RJ45 or lemi port - ieee1588 : IEEE1588 port - ai : AI port Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Alarm::FacePlatePortIndex> - the faceplate port number Field type <Alarm::QsfpPortIndex> - the qsfp port number Field type <Alarm::LaneIndex> - the lane number of qsfp port	

Only Show Details: alarm snap-shot status		
name	Type	Description
tca-outputbw	Parameter type: <Alarm::TcaOutputBw> (yes no) Possible values: - yes : tca output bandwidth crossed threshold - no : tca output bandwidth did not crossed threshold	specifies whether the output bw has crossed threshold or not <i>This element is only shown in detail mode.</i>
tca-inputbw	Parameter type: <Alarm::TcaInputBw> (yes no) Possible values: - yes : tca input bandwidth crossed threshold - no : tca input bandwidth did not crossed threshold	specifies whether the tca input bw has crossed threshold or not <i>This element is only shown in detail mode.</i>
tca-rxcrcalign	Parameter type: <Alarm::TcaRxCrcAlign> (yes no) Possible values:	specifies whether the tca rxrcrc align errors has crossed threshold or not <i>This element is only shown in</i>

name	Type	Description
	- yes : tca rxcrc align errors crossed threshold - no : tca rxcrc align errors did not crossed threshold	<i>detail mode.</i>
tca-txcrcalign	Parameter type: <Alarm::TcaTxCrcAlign> (yes no) Possible values: - yes : tca txcrc align errors crossed threshold - no : tca txcrc align errors did not crossed threshold	specifies whether the tca txcrc align errors has crossed threshold or not <i>This element is only shown in detail mode.</i>
tca-txcollisions	Parameter type: <Alarm::TcaTxCollisions> (yes no) Possible values: - yes : tca txcollisions errors crossed threshold - no : tca txcollisions errors did not crossed threshold	specifies whether the tca tx collisions errors has crossed threshold or not <i>This element is only shown in detail mode.</i>
tca-outputhighbw	Parameter type: <Alarm::TcaOutputHighBw> (yes no) Possible values: - yes : tca output high bandwidth crossed threshold - no : tca output high bandwidth did not crossed threshold	specifies whether the continous output high bw has crossed threshold or not <i>This element is only shown in detail mode.</i>
tca-outputmedbw	Parameter type: <Alarm::TcaOutputMediumBw> (yes no) Possible values: - yes : tca output medium bandwidth crossed threshold - no : tca output medium bandwidth did not crossed threshold	specifies whether the continous output medium bw has crossed threshold or not <i>This element is only shown in detail mode.</i>
tca-outputlowbw	Parameter type: <Alarm::TcaOutputLowBw> (yes no) Possible values: - yes : tca output low bandwidth crossed threshold - no : tca output low bandwidth did not crossed threshold	specifies whether the continous output low bw has crossed threshold or not <i>This element is only shown in detail mode.</i>
tca-inputhighbw	Parameter type: <Alarm::TcaInputHighBw> (yes no) Possible values: - yes : tca input high bandwidth crossed threshold - no : tca input high bandwidth did not crossed threshold	specifies whether the continous input high bw has crossed threshold or not <i>This element is only shown in detail mode.</i>
tca-inputmediumbw	Parameter type: <Alarm::TcaInputMediumBw> (yes no) Possible values: - yes : tca input medium bandwidth crossed threshold - no : tca input medium bandwidth did not crossed threshold	specifies whether the continous input medium bw has crossed threshold or not <i>This element is only shown in detail mode.</i>
tca-inputlowbw	Parameter type: <Alarm::TcaInputLowBw> (yes no) Possible values: - yes : tca input low bandwidth crossed threshold - no : tca input low bandwidth did not crossed threshold	specifies whether the continous input low bw has crossed threshold or not <i>This element is only shown in detail mode.</i>

103.76 LDP Alarm SnapShot Status Command

Command Description

This command displays the snapshot Label Distribution Protocol alarm status.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm snap-shot ldp [ (index) ]
```

Command Parameters

Table 103.76-1 "LDP Alarm SnapShot Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm log table index

Command Output

Table 103.76-2 "LDP Alarm SnapShot Status Command" Display parameters

Specific Information		
name	Type	Description
router-id	Parameter type: <Ihub::baseRouter> base Possible values: - base : base router	identifies the base router <i>This element is only shown in detail mode.</i>
ip-address	Parameter type: <Alarm::IPAddressOrZero> (not-applicable <IPv4::address>) Possible values: - not-applicable : not applicable Field type <IPv4::address> - IPv4-address	identifies the ip-address of the LDP targeted Peer <i>This element is only shown in detail mode.</i>

Only Show Details: alarm snap-shot status		
name	Type	Description
instance-down	Parameter type: <Alarm::LdpInstanceDown> (yes no) Possible values: - yes : ldp is down - no : ldp is up or not configured	specifies whether the LDP instance is down or not <i>This element is only shown in detail mode.</i>

name	Type	Description
session-down	Parameter type: <Alarm::SessionDown> (yes no) Possible values: - yes : TCP session down - no : Connection re-established or ldp not configured or explicit configured peer is removed	specifies whether the LDP session is down or not <i>This element is only shown in detail mode.</i>

103.77 Alarm SnapShot MPLS Status Command

Command Description

This command displays the snap-shot MPLS alarm status.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm snap-shot mpls [ (index) ]
```

Command Parameters

Table 103.77-1 "Alarm SnapShot MPLS Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm log table index

Command Output

Table 103.77-2 "Alarm SnapShot MPLS Status Command" Display parameters

Specific Information		
name	Type	Description
router-id	Parameter type: <Ihub::baseRouter> base Possible values: - base : base router	identifies the base router <i>This element is only shown in detail mode.</i>
lsp-id-or-lsp-path-idx	Parameter type: <Alarm::LspIdOrLspPathIndexOrZero> - a signed integer	Lsp id or Lsp path index (unique identifier) where the alarm occurred or zero when not applicable, alarm entry is further specified in additional-info <i>This element is only shown in detail mode.</i>
additional-info	Parameter type: <Alarm::AddInfoString> - additional alarm information	identifies the alarm additional info specific to an mpls alarm. Empty string if not applicable. <i>This element is only shown in detail mode.</i>

Only Show Details: alarm snap-shot status		
name	Type	Description
instance-down	Parameter type: <Alarm::MplsInstanceDown>	specifies whether the MPLS

name	Type	Description
	(yes no) Possible values: - yes : mpls is down - no : mpls is up or not configured	instance is down or not <i>This element is only shown in detail mode.</i>
lsp-down	Parameter type: <Alarm::LspDown> (yes no) Possible values: - yes : lsp is down - no : lsp is up or shutdown, or mpls instance is stopped or not configured	specifies whether the LSP is down or not <i>This element is only shown in detail mode.</i>
lsp-path-down	Parameter type: <Alarm::LspPathDown> (yes no) Possible values: - yes : lsp path is down - no : lsp path is up or shutdown, or lsp is shutdown, or mpls instance is stopped or not configured	specifies whether the LSP Path is down or not <i>This element is only shown in detail mode.</i>

103.78 Alarm SnapShot SDP Status Command

Command Description

This command displays the snapshot Service Delivery Point alarm status

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

> show alarm snap-shot sdp [(index)]

Command Parameters

Table 103.78-1 "Alarm SnapShot SDP Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm log table index

Command Output

Table 103.78-2 "Alarm SnapShot SDP Status Command" Display parameters

Specific Information		
name	Type	Description
sdp-id	Parameter type: <Alarm::SdpId> - sdp-id value - range: [1...17407]	identifies the sdp-id of the sdp binding where the alarm has occurred <i>This element is only shown in detail mode.</i>
vc-id	Parameter type: <Alarm::SvcIdOrZero> - vc-id value or zero - range: [0,1...4294967295]	identifies the vc-id of the sdp binding where the alarm occurred or zero when not applicable, the sdp binding is further specified in additional-info <i>This element is only shown in detail mode.</i>
Only Show Details: alarm snap-shot status		
name	Type	Description
instance-down	Parameter type: <Alarm::SdpInstanceDown> (yes no) Possible values: - yes : sdp is operationl down	specifies whether the SDP instance is down or not <i>This element is only shown in detail mode.</i>

name	Type	Description
	- no : sdp is operational up or shutdown	
binding-down	Parameter type: <Alarm::BindlingDown> (yes no) Possible values: - yes : sdp binding is operational down - no : sdp binding is operational up or shutdown, or the sdp or service is shutdown	specifies whether the SDP binding is down or not <i>This element is only shown in detail mode.</i>

103.79 IHUB IPV6 Alarm SnapShot Status Command

Command Description

This command displays the SnapShot ihub-ipv6 alarm status.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm snap-shot ihub-ipv6 [ (index) ]
```

Command Parameters

Table 103.79-1 "IHUB IPV6 Alarm SnapShot Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm log table index

Command Output

Table 103.79-2 "IHUB IPV6 Alarm SnapShot Status Command" Display parameters

Specific Information		
name	Type	Description
router-id	Parameter type: <Ihub::Router> (base <Ihub::Router>) Possible values: - base : base router Field type <Ihub::Router> - vprn service-id - range: [1...2147483647]	identifies the vprn service-id or the base router where the alarm has occurred <i>This element is only shown in detail mode.</i>
duplicate-index	Parameter type: <Alarm::IdentificationIdxOrZero> - a signed integer	unique reference for the duplicate address for which alarm has occurred or zero when not applicable, duplicate address is further specified in additional-info. <i>This element is only shown in detail mode.</i>

name	Type	Description
additional-info	Parameter type: <Alarm::AddInfoStringVprn> - additional alarm information	identifies the ipv6 alarm additional info. empty string if not applicable. <i>This element is only shown in detail mode.</i>

Only Show Details: current alarm snap-shot status		
name	Type	Description
duplicate-address-own	Parameter type: <Alarm::SelfDuplicateIPv6Addr> (yes no) Possible values: - yes : duplicate address detected for own ipv6 address - no : no duplicate address detected for own ipv6 address	specifies whether a duplicate address is detected for own IPV6 address or not <i>This element is only shown in detail mode.</i>
duplicate-address	Parameter type: <Alarm::DuplicateIPv6Addr> (yes no) Possible values: - yes : duplicate address detected for user's ipv6 address - no : no duplicate address detected for user's ipv6 address	specifies whether a duplicate address is detected for a user's IPV6 address or not <i>This element is only shown in detail mode.</i>
ipv6-dup-pd-route	Parameter type: <Alarm::Ipv6DupPdRoute> (yes no) Possible values: - yes : duplicate address detected for user's ipv6 PD route - no : no duplicate address detected for user's ipv6 PD route	status of ipv6-dup-pd-route <i>This element is only shown in detail mode.</i>

103.80 Alarm SnapShot EPIPE Status Command

Command Description

This command displays the snapshot Ethernet Pipe alarm status.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

> show alarm snap-shot epipe [(index)]

Command Parameters

Table 103.80-1 "Alarm SnapShot EPIPE Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm log table index

Command Output

Table 103.80-2 "Alarm SnapShot EPIPE Status Command" Display parameters

Specific Information		
name	Type	Description
service-id	Parameter type: <Alarm::ServiceId> - a profile index value - range: [1...2147483647]	identifies the base router <i>This element is only shown in detail mode.</i>

Only Show Details: alarm snap-shot status		
name	Type	Description
instance-down	Parameter type: <Alarm::EpipeInstanceDown> (yes no) Possible values: - yes : epipe service is operational down - no : epipe service is operational up or shutdown	specifies whether the epipe instance is down or not <i>This element is only shown in detail mode.</i>

103.81 Alarm SnapShot PIM Status Command

Command Description

This command displays the snapshot PIM alarm status.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

> show alarm snap-shot pim [(index)]

Command Parameters

Table 103.81-1 "Alarm SnapShot PIM Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm log table index

Command Output

Table 103.81-2 "Alarm SnapShot PIM Status Command" Display parameters

Specific Information		
name	Type	Description
router-id	Parameter type: <Ihub::Router> (base <Ihub::Router>) Possible values: - base : base router Field type <Ihub::Router> - vprn service-id - range: [1...2147483647]	identifies the base router id where the alarm has occurred <i>This element is only shown in detail mode.</i>
neighbor-idx	Parameter type: <Alarm::IdentificationIdxOrZero> - a signed integer	unique reference for the neighbor where the alarm occurred <i>This element is only shown in detail mode.</i>
additional-info	Parameter type: <Alarm::AddInfoStringPim> - additional alarm information	identifies the neighbor/instance where the alarm occurred or empty string if not applicable <i>This element is only shown in detail mode.</i>

Only Show Details: alarm snap-shot status

103 Alarm Snap-shot Status Commands

name	Type	Description
pim-neighbor-down	Parameter type: <Alarm::IhubPimDown> (yes no) Possible values: - yes : pim neighbor down - no : pim neighbor up	specifies whether the neighbor instance is down or not <i>This element is only shown in detail mode.</i>
mc-maximum-routes	Parameter type: <Alarm::IhubMaxRoutes> (yes no) Possible values: - yes : maximum routes reached - no : maximum routes not reached	specifies whether the max mc routes is reached <i>This element is only shown in detail mode.</i>

103.82 IHUB Lawful Intercept Alarm SnapShot Status Command

Command Description

This command displays the SnapShot lawful intercept alarm status.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm snap-shot li [ (index) ]
```

Command Parameters

Table 103.82-1 "IHUB Lawful Intercept Alarm SnapShot Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm log table index

Command Output

Table 103.82-2 "IHUB Lawful Intercept Alarm SnapShot Status Command" Display parameters

Only Show Details: current alarm snap-shot status		
name	Type	Description
li-traf-disabled	Parameter type: <Alarm::LiTrafficDisabled> (yes no) Possible values: - yes : lawful interception of traffic disabled - no : lawful interception of traffic enabled	specifies whether a lawful intercept traffic is disabled or not <i>This element is only shown in detail mode.</i>
li-bandwidth	Parameter type: <Alarm::LiBandwidthLimit> (reached not-reached) Possible values: - reached : lawful intercept reached bandwidth limit - not-reached : lawful intercept within bandwidth limit	specifies whether lawful intercept reached bandwidth limit or not <i>This element is only shown in detail mode.</i>
li-out-of-res	Parameter type: <Alarm::LiOutOfRes> (yes no) Possible values:	specifies whether lawful intercept is out of resources or not <i>This element is only shown in detail mode.</i>

103 Alarm Snap-shot Status Commands

name	Type	Description
	- yes : lack of resources for lawful intercept - no : no resource issues for lawful intercept	

103.83 Sync Clock Alarm SnapShot Status Command

Command Description

This command displays the synce and bits snapShot alarm log status.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm snap-shot sync [ (index) ]
```

Command Parameters

Table 103.83-1 "Sync Clock Alarm SnapShot Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm log table index

Command Output

Table 103.83-2 "Sync Clock Alarm SnapShot Status Command" Display parameters

Only Show Details: slot information		
name	Type	Description
slot	Parameter type: <Alarm::SynceSlot> (ntio-1 ntio-2 nt-a nt-b lt : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> not-used nt) Possible values: - ntio-1 : an nt applique slot in a single or multiple-ntio-shelf - ntio-2 : an nt applique slot in a multiple-ntio-shelf - nt-a : nt-a slot - nt-b : nt-b slot - nt : active nt slot - lt : lt slot - not-used : no interface	identifies the synce port where the alarm has occurred. <i>This element is only shown in detail mode.</i>

103 Alarm Snap-shot Status Commands

name	Type	Description
	Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number	
port	Parameter type: <Alarm::SyncePort> (sfp : <Alarm::SynceClk> xfp : <Alarm::SynceClk> bits-a bits-b ieee1588-a not-used ieee1588-b gnssrj45-a gnssrj45-b ieee1588-hybrid-a ieee1588-hybrid-b cfp : <Alarm::SynceClk> <Alarm::SynceClk> qsfp : <Alarm::SynceClk> ieee1588 internal-clk-a internal-clk-b) Possible values: - sfp : synce reference on sfp port - xfp : synce reference on xfp port - bits-a : bits clock source on nt-a - bits-b : bits clock source on nt-b - ieee1588-a : ieee1588 clock source on nt-a - ieee1588-b : ieee1588 clock source on nt-b - gnssrj45-a : gnss tod source on nt-a - gnssrj45-b : gnss tod source on nt-b - ieee1588-hybrid-a : 1588 hybrid tod source on nt-a - ieee1588-hybrid-b : 1588 hybrid tod source on nt-b - cfp : synce reference on cfp port - qsfp : synce reference on qsfp port - ieee1588 : ieee1588 clock source on nt - internal-clk-a : internal clock on nt-a - internal-clk-b : internal clock on nt-b - not-used : not-used Field type <Alarm::SynceClk> - value - range: [0...36]	identifies the synce port where the alarm has occurred. <i>This element is only shown in detail mode.</i>

Only Show Details: snap-shot alarm status		
name	Type	Description
bits-fail	Parameter type: <Alarm::BitsFail> (yes no) Possible values: - yes : bits source failed - no : no bits source failed	specifies whether bits clock source has failed or not <i>This element is only shown in detail mode.</i>
synce-fail	Parameter type: <Alarm::SynceFail> (yes no) Possible values: - yes : synce source failed	specifies whether synce clock source has failed or not <i>This element is only shown in detail mode.</i>

name	Type	Description
	- no : no synce source failed	
bits-output-shutoff	Parameter type: <Alarm::BitsOutputShutoffFail> (yes no) Possible values: - yes : bits output shutoff - no : no bits output shutoff	specifies whether bits output failed or not <i>This element is only shown in detail mode.</i>
ieee1588-fail	Parameter type: <Alarm::ieee1588Fail> (yes no) Possible values: - yes : bits output shutoff - no : no bits output shutoff	ieee1588 clock source failure <i>This element is only shown in detail mode.</i>
gnss-fail	Parameter type: <Alarm::gnssFail> (yes no) Possible values: - yes : gnss tod fail - no : no gnss tod fail	gnss time source failure <i>This element is only shown in detail mode.</i>
signal-loss	Parameter type: <Alarm::ClockLoss> (yes no) Possible values: - yes : synce or bits clock signal loss - no : no synce or bits clock signal loss	specifies whether synce or bits clock signal loss or not <i>This element is only shown in detail mode.</i>
signal-efd	Parameter type: <Alarm::ClockEfd> (yes no) Possible values: - yes : synce or bits clock signal exceed frequency deviation - no : no synce or bits clock signal exceed frequency deviation	specifies whether bsynce or bits clock signal exceed frequency deviation or not <i>This element is only shown in detail mode.</i>
esmc-loss	Parameter type: <Alarm::ClockEsmcLoss> (yes no) Possible values: - yes : clock source SSM infomation loss - no : no clock source SSM infomation loss	specifies whether clock source loss SSM infomation or not <i>This element is only shown in detail mode.</i>
bits-output-exceed	Parameter type: <Alarm::BitsOutputQlThreshExceed> (yes no) Possible values: - yes : bitout ql threshold exceed - no : no bitout ql threshold exceed	specifies whether bits output ql threshold exceeded or not <i>This element is only shown in detail mode.</i>
ql-input-exceed	Parameter type: <Alarm::ClockExceed> (yes no) Possible values: - yes : input clock source threshold exceed - no : no input clock source threshold exceed	specifies whether exceed input clock source threshold or not <i>This element is only shown in detail mode.</i>
holdover	Parameter type: <Alarm::ClockHoldover> (yes no) Possible values: - yes : Clock system is in the holdover - no : Clock system is not in the holdover	specifies whether clock system is in the holdover or not <i>This element is only shown in detail mode.</i>
lti	Parameter type: <Alarm::ClockLTI>	specifies whether all clock source

103 Alarm Snap-shot Status Commands

name	Type	Description
	(yes no) Possible values: - yes : all clock source failed - no : no all clock source failed	failed or not <i>This element is only shown in detail mode.</i>
tod-reference-fail	Parameter type: <Alarm::ToDHoldover> (yes no) Possible values: - yes : Clock system ToD reference is failed - no : Clock system ToD reference is OK	specifies whether clock system tod reference is failed or not <i>This element is only shown in detail mode.</i>
internal-clk-fail	Parameter type: <Alarm::ClockOCXOFail> (yes no) Possible values: - yes : Internal CLK is failed - no : Internal CLK is OK	specifies whether internal clock is failed or not <i>This element is only shown in detail mode.</i>

103.84 Alarm Snapshot Equipment Supplemental Status Command

Command Description

This command displays the equipment supplemental snapshot.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

> show alarm snap-shot eqpt-supplemental [(index)]

Command Parameters

Table 103.84-1 "Alarm Snapshot Equipment Supplemental Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm snap shot table index

Command Output

Table 103.84-2 "Alarm Snapshot Equipment Supplemental Status Command" Display parameters

Specific Information		
name	Type	Description
shelf	Parameter type: <Equipm::Shelf> <Eqpt::RackId> / <Eqpt::ShelfId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number	specify which shelf the alarm occurred on. <i>This element is only shown in detail mode.</i>
syslog-upload	Parameter type: <Alarm::uploadFailed> (failed ok) Possible values: - failed : upload of syslog file to remote server failed - ok : no syslog file upload failure detected	current status of the alarm specifying whether a failure occurred during upload of the NE's system log file to the syslog server or not <i>This element is only shown in detail mode.</i>
ont-sw-dnload	Parameter type: <Alarm::ontSoftwareDownload> (in-progress ok)	current status of the alarm specifying whether downloading of ont sw from version control to

103 Alarm Snap-shot Status Commands

name	Type	Description
	Possible values: - in-progress : ont software download in progress - ok : no ont software download detected	ont is in progress or not <i>This element is only shown in detail mode.</i>
cf-75%-used	Parameter type: <Alarm::cf75Percent> (above below) Possible values: - above : Compact flash exceeds 75% of life expectancy - below : Compact flash is below 75% of life expectancy	current status of CF utilization which could be more than 75% or less than that <i>This element is only shown in detail mode.</i>
cf-90%-used	Parameter type: <Alarm::cf90Percent> (above below) Possible values: - above : Compact flash exceeds 90% of life expectancy - below : Compact flash is below 90% of life expectancy	current status of CF utilization which could be more than 90% or less than that <i>This element is only shown in detail mode.</i>

103.85 Otdr Alarm SnapShot Status Command

Command Description

This command displays the otdr snapShot alarm log status.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

> show alarm snap-shot otdr [(index)]

Command Parameters

Table 103.85-1 "Otdr Alarm SnapShot Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm log table index

Command Output

Table 103.85-2 "Otdr Alarm SnapShot Status Command" Display parameters

Only Show Details: sfp information		
name	Type	Description
ponindex	Parameter type: <Itf::ComplexPortType> (xdsl-line : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> voicefxs : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> xdsl-channel : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> atm-if : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> atm-pvc : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::VpiId> : <Eqpt::VciId> bridge-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::VpiId> : <Eqpt::VciId> vlan-port:ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / <Eqpt::Ng2OntSlotId> / <Eqpt::Ng2OntPortId> : <Eqpt::UnstackedVlan> l2-vlan : <Eqpt::VlanId>	identifies the spf where the alarm has occurred. <i>This element is only shown in detail mode.</i>

name	Type	Description
	<pre> ip : <Eqpt::LogicalId> sw-loopback slip uni:ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / <Eqpt::Ng2OntSlotId> / <Eqpt::Ng2OntPortId> vlan-port:ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / <Eqpt::Ng2OntSlotId> / <Eqpt::Ng2OntPortId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> atm-bonding : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> bonding : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> ip-gateway : <Eqpt::VrfId> ip-line : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::VpiId> : <Eqpt::VciId> ip-line : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> shdsl-line : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> e1-line : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> atm-ima : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> ethernet-line : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> bridge-port:ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / vuni vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::VpiId> : <Eqpt::VciId> : <Eqpt::UnstackedVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::UnstackedVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::VpiId> : <Eqpt::VciId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> voip:ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> ip-line : vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::VpiId> : <Eqpt::VciId> : <Eqpt::UnstackedVlan> ip-line : vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::UnstackedVlan> ip-line : vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::VpiId> : <Eqpt::VciId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> ip-line : vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan-port:ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / vuni : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan-port:ng2 : <Eqpt::ChannelGroupId> / </pre>	

name	Type	Description
	<pre> <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / vuni : <Eqpt::UnstackedVlan> chgroup : <Eqpt::ChannelGroupId> subchgroup : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> bridge-port:ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / <Eqpt::Ng2OntSlotId> / <Eqpt::Ng2OntPortId> atm-pvc : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> bridge-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> bridge-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> / <Eqpt::OntPortId> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> / <Eqpt::OntPortId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> / <Eqpt::OntPortId> : <Eqpt::UnstackedVlan> pon : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> ont : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> uni : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> / <Eqpt::OntPortId> bridge-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / voip bridge-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / vuni vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / voip : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / vuni : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / voip : <Eqpt::UnstackedVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / vuni : <Eqpt::UnstackedVlan> voip : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> la-group : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::LLId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> bridge-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::LLId> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / </pre>	

103 Alarm Snap-shot Status Commands

name	Type	Description
	<Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::LLId> : <Eqpt::UnstackedVlan> mpm : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::ComboPonId> x-pon : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::XPonId> 25g-pon : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::M25GPonId> dist-router-interface : slot-stacked : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::SVlan> : <Eqpt::CVlan> dist-router-interface : slot-vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::UnstackedVlan> bundle : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::BundleId> chpair : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::ChannelPairId> ont.ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId>) Possible values: - xdsl-line : a static xdsl line interface - xdsl-channel : a static xdsl channel interface - atm-if : a static atm interface - atm-pvc : an atm pvc interface - bridge-port : a vlan bridge-port - bridge-port.ng2 : a ngpon2 vlan bridge-port - l2-vlan : a l2-vlan interface - ip : an ip interface - sw-loopback : a software loopback interface - slip : a slip interface - atm-bonding : atm bonding obsolete alternative replaced by bonding - bonding : bonding - ip-gateway : ip user gateway interface - ip-line : ip line interface - shdsl-line : a static shdsl line interface - e1-line : a e1 line interface - atm-ima : atm ima - ethernet-line : an ethernet line interface - vlan-port : vlan port - vlan-port.ng2 : a ngpon2 vlan port - pon : pon - x-pon : xgs pon - 25g-pon : 25g pon - chpair : channelpair - chgroup : channelgroup - subchgroup : subchannelgroup - bundle : bundle - ont : ont - ont.ng2 : ngpon2 ONT style identification - uni : uni - uni.ng2 : ngpon2 UNI style identification - voip : voip - voip.ng2 : voip - la-group : link aggregation group - dist-router-interface : dist router interface - voicefxs : voicefxs	

name	Type	Description
	- mpm : multi-pon module - Possible values: - vlan : vlan port - Possible values: - slot-vlan : slot unstacked - slot-stacked : slot vlan port - Field type <Eqpt::RackId> - the rack number - Field type <Eqpt::ShelfId> - the shelf number - Field type <Eqpt::SlotId> - the LT slot number - Field type <Eqpt::PortId> - the port number - Field type <Eqpt::VpiId> - atm VPI - Field type <Eqpt::VciId> - atm VCI - Field type <Eqpt::PonId> - the PON identifier - Field type <Eqpt::XPonId> - the XGS PON identifier - Field type <Eqpt::M25GPonId> - the 25G PON identifier - Field type <Eqpt::ComboPonId> - the comboPON identifier - Field type <Eqpt::ChannelPairId> - the channel pair identifier - Field type <Eqpt::ChannelGroupId> - the channel group identifier - Field type <Eqpt::SubChannelGroupId> - the subchannel group identifier - Field type <Eqpt::BundleId> - the BUNDLE identifier - Field type <Eqpt::OntId> - the ONT identifier - Field type <Eqpt::Ng2OntId> - the NG2 ONT identifier - Possible values: - voip : virtual uni identifier - obsolete alternative replaced by vuni - vuni : virtual uni identifier - Possible values: - vuni : virtual NGPON2 uni identifier - Field type <Eqpt::OntSlotId> - the ONT SLOT identifier - Field type <Eqpt::OntPortId> - the ONT PORT identifier - Field type <Eqpt::Ng2OntSlotId> - the NGPON2 ONT SLOT identifier - Field type <Eqpt::Ng2OntPortId> - the NGPON2 ONT PORT identifier - Field type <Eqpt::LLId> - the LLID identifier,range 1 for EPON,range 1-8 for DPOE - Possible values: - stacked : stacked vlan identity - Field type <Eqpt::UnstackedVlan>	

103 Alarm Snap-shot Status Commands

name	Type	Description
	- unstacked vlan id Field type <Eqpt::SVlan> - service vlan id Field type <Eqpt::CVlan> - customer vlan id Field type <Eqpt::VlanId> - VLAN id Field type <Eqpt::LogicalId> - logical id Field type <Eqpt::VrflId> - VRF id	

Only Show Details: snap-shot alarm status		
name	Type	Description
capability-mismatch	Parameter type: <Alarm::OTDRmismatch> (yes no) Possible values: - yes : otdr capability mismatch - no : no otdr capability mismatch	specifies whether otdr capability mismatch has occurred. <i>This element is only shown in detail mode.</i>

103.86 Management Security Access Alarm SnapShot Status Command

Command Description

This command displays the management security access alarm snapshot status.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

> show alarm snap-shot mgmt-sec-access [(index)]

Command Parameters

Table 103.86-1 "Management Security Access Alarm SnapShot Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm log table index

Command Output

Table 103.86-2 "Management Security Access Alarm SnapShot Status Command" Display parameters

Specific Information		
name	Type	Description
last-updated-on	Parameter type: <Sys::timeInSecs> - the time (yyyy-mm-dd:hour:minutes:secs) - unit: UTC	network time in seconds when the alarm was logged. <i>This element is only shown in detail mode.</i>
ip-address	Parameter type: <Alarm::IpAddress> - IPv4-address	address of the operator <i>This element is only shown in detail mode.</i>
additional-info	Parameter type: <PrintableString> - printable string	displays the timestamp and operator name separated by semicolon. <i>This element is only shown in detail mode.</i>

Only Show Details: snap-shot alarm status

103 Alarm Snap-shot Status Commands

name	Type	Description
login-successful	Parameter type: <Alarm::MgmtAccess> (yes no) Possible values: - yes : successfully logged in via management access - no : successfully logged out via management access	current status specifying whether successfully logged in or logged out via Management access <i>This element is only shown in detail mode.</i>
login-failure	Parameter type: <Alarm::InvalidAccess> (yes no) Possible values: - yes : invalid login via management access crossed the threshold - no : invalid login via management access within the threshold	current status specifying invalid attempts to login via management access crossed the threshold or not <i>This element is only shown in detail mode.</i>

103.87 IHUB BFD Alarm SnapShot Status Command

Command Description

This command displays the SnapShot bfd alarm status.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

> show alarm snap-shot bfd [(index)]

Command Parameters

Table 103.87-1 "IHUB BFD Alarm SnapShot Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm log table index

Command Output

Table 103.87-2 "IHUB BFD Alarm SnapShot Status Command" Display parameters

Specific Information		
name	Type	Description
vprn-id	Parameter type: <Ihub::Router> (base <Ihub::Router>) Possible values: - base : base router Field type <Ihub::Router> - vprn service-id - range: [1...2147483647]	identifies the vprn service-id or the base router where the alarm has occurred. <i>This element is only shown in detail mode.</i>
bfd-unique-id	Parameter type: <Alarm::IdentificationIdxOrZero> - a signed integer	unique identification for the alarm or zero when not applicable, alarm entry is further specified in additional-info <i>This element is only shown in detail mode.</i>
additional-info	Parameter type: <Alarm::AddInfoStringBfd> - additional alarm information	Additional information regarding the bfd alarm

103 Alarm Snap-shot Status Commands

name	Type	Description
		<i>This element is only shown in detail mode.</i>

Only Show Details: alarm snap-shot status		
name	Type	Description
bfd-session-down	Parameter type: <Alarm::BfdSessionDown> (yes no) Possible values: - yes : bfd session down - no : bfd session not down	specifies whether a bfd session went down or not <i>This element is only shown in detail mode.</i>
bfd-max-resource	Parameter type: <Alarm::BfdMaxResource> (yes no) Possible values: - yes : bfd maximum resources reached - no : no resource issues for bfd	specifies whether bfd has reached maximum resources or not <i>This element is only shown in detail mode.</i>
bfd-stale-entry	Parameter type: <Alarm::BfdStaleEntry> (yes no) Possible values: - yes : bfd stale entry present - no : bfd stale entry not present	specifies whether a bfd entry has become stale or not <i>This element is only shown in detail mode.</i>

103.88 Application Intelligence Alarm Snap-shot Status Command

Command Description

This command displays the snap-shot for the Application Intelligence alarm status.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm snap-shot ai [ (index) ]
```

Command Parameters

Table 103.88-1 "Application Intelligence Alarm Snap-shot Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm snap-shot table index

Command Output

Table 103.88-2 "Application Intelligence Alarm Snap-shot Status Command" Display parameters

Specific Information		
name	Type	Description
slot-id	Parameter type: <Equipm::NtSlotIndex> (nt-a nt-b) Possible values: - nt-a : nt-a slot - nt-b : nt-b slot	identifies the board hosting the AI Platform for which the alarm has occurred. <i>This element is only shown in detail mode.</i>
application-virtplatf	Parameter type: <SignedInteger> - a signed integer	identifies the Application and/or the virtualplatform for which the alarm occurred <i>This element is only shown in detail mode.</i>
additional-info	Parameter type: <Alarm::AddInfoStringAI> - Additional info: Application Name - length: x<=32	identifies the Application and/or the virtualplatform for which the alarm occurred <i>This element is only shown in detail mode.</i>

103 Alarm Snap-shot Status Commands

Only Show Details: alarm snap-shot status		
name	Type	Description
ai-platform-down	Parameter type: <Alarm::AIPlatformDown> (yes no) Possible values: - yes : AI Platform down - no : AI Platform not down	specifies whether an AI Platform went down or not <i>This element is only shown in detail mode.</i>
ai-appl-install-fail	Parameter type: <Alarm::AIApplInstallFail> (yes no) Possible values: - yes : Application installation failed - no : Application installation successful	specifies whether an Application 'download and installation' failed or was successful <i>This element is only shown in detail mode.</i>
ip-assign-fail	Parameter type: <Alarm::IpAddrAssignFail> (yes no) Possible values: - yes : Dhcp assigned address failure - no : Dhcp assigned address successful	specifies whether dhcp client 'assigned ip address' failed or was successful <i>This element is only shown in detail mode.</i>

103.89 Alarm ONT SNMP Snapshot Status Command

This command displays the ont snmp snapshot-related alarms.

Command Description

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm snap-shot ontsnmp [ (index) ]
```

Command Parameters

Table 103.89-1 "Alarm ONT SNMP Snapshot Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm snap shot table index

Command Output

Table 103.89-2 "Alarm ONT SNMP Snapshot Status Command" Display parameters

Specific Information		
name	Type	Description
uni-index	Parameter type: <Ces::InterfaceIndex> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> / <Eqpt::OntPortId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Eqpt::OntId> - the ONT identifier Field type <Eqpt::OntSlotId> - the ONT SLOT identifier	identification of the uni interface index <i>This element is only shown in detail mode.</i>

103 Alarm Snap-shot Status Commands

name	Type	Description
	Field type <Eqpt::OntPortId> - the ONT PORT identifier	
snmp-mismatch	Parameter type: <Alarm::OntSnmpMismatch> (mismatch not-mismatch) Possible values: - mismatch : ont snmp agent configuration data is mismatch - not-mismatch : ont snmp agent configuration data is not mismatch	current status specifying ont snmp is mismatch or not <i>This element is only shown in detail mode.</i>

103.90 Tr069 Alarm Status Command

Command Description

This command displays the tr069 current alarm status.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm snap-shot tr069serv [ (index) ]
```

Command Parameters

Table 103.90-1 "Tr069 Alarm Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm snapshot table index

Command Output

Table 103.90-2 "Tr069 Alarm Status Command" Display parameters

Specific Information		
name	Type	Description
tr069serv	Parameter type: <Gpon::UniInterfaceIndexSnmpAgent> (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> / <Eqpt::OntPortId> ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / <Eqpt::Ng2OntSlotId> / <Eqpt::Ng2OntPortId> ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / vuni) Possible values: - ng2 : ngpon2 style identification Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Eqpt::ChannelGroupId>	identifies the tr069 serv entry <i>This element is only shown in detail mode.</i>

103 Alarm Snap-shot Status Commands

name	Type	Description
	- the channel group identifier Field type <Eqpt::SubChannelGroupId> - the subchannel group identifier Field type <Eqpt::OntId> - the ONT identifier Field type <Eqpt::Ng2OntId> - the NG2 ONT identifier Possible values: - vuni : virtual NGPON2 uni identifier Field type <Eqpt::OntSlotId> - the ONT SLOT identifier Field type <Eqpt::OntPortId> - the ONT PORT identifier Field type <Eqpt::Ng2OntSlotId> - the NGPON2 ONT SLOT identifier Field type <Eqpt::Ng2OntPortId> - the NGPON2 ONT PORT identifier	

Only Show Details: alarm snap-shot status		
name	Type	Description
ont-tr069-serv-mis	Parameter type: <Alarm::Tr069ServMis> (yes no) Possible values: - yes : ont tr069 server mismatch occurred - no : no ont tr069 server mismatch	specifies ont tr069 server mismatch occurred or not. <i>This element is only shown in detail mode.</i>

103.91 Bulk Sync Alarm Log Status Command

Command Description

This command displays the bulk sync alarm log status.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

> show alarm snap-shot bulk-sync [(index)]

Command Parameters

Table 103.91-1 "Bulk Sync Alarm Log Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm snapshot table index

Command Output

Table 103.91-2 "Bulk Sync Alarm Log Status Command" Display parameters

Specific Information		
name	Type	Description
last-updated-on	Parameter type: <Sys::timeInSecs> - the time (yyyy-mm-dd:hour:minutes:secs) - unit: UTC	network time in seconds when the alarm was logged. <i>This element is only shown in detail mode.</i>
port	Parameter type: <RedPort::PortIndex> (pon : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> chpair : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::ChannelPairId>) Possible values: - pon : pon-aid - chpair : chpair-aid Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId>	specify which port the alarm occurred on. <i>This element is only shown in detail mode.</i>

103 Alarm Snap-shot Status Commands

name	Type	Description
	- the PON identifier Field type <Eqpt::ChannelPairId> - the channel pair identifier	

Only Show Details: alarm snap-shot status		
name	Type	Description
bsf-dhcpv4-fail	Parameter type: <Alarm::BsfDHCPv4> ((failing fail) ok) Possible values: - failing : dhcpv4 bulk-sync is failing - fail : dhcpv4 bulk-sync is failing - ok : dhcpv4 bulk-sync is ok	current status of dhcpv4 bulk-sync failure. <i>This element is only shown in detail mode.</i>
bsf-dhcpv6-fail	Parameter type: <Alarm::BsfDHCPv6> ((failing fail) ok) Possible values: - failing : dhcpv6 bulk-sync is failing - fail : dhcpv6 bulk-sync is failing - ok : dhcpv6 bulk-sync is ok	current status of dhcpv6 bulk-sync failure. <i>This element is only shown in detail mode.</i>
bsf-pon-fail	Parameter type: <Alarm::BsfPON> ((failing fail) ok) Possible values: - failing : pon bulk-sync is failing - fail : pon bulk-sync is failing - ok : pon bulk-sync is ok	current status of pon bulk-sync failure. <i>This element is only shown in detail mode.</i>
bsf-vbridge-fail	Parameter type: <Alarm::BsfVBridge> ((failing fail) ok) Possible values: - failing : vlan-bridge bulk-sync is failing - fail : vlan-bridge bulk-sync is failing - ok : vlan-bridge bulk-sync is ok	current status of vlan-bridge bulk-sync failure. <i>This element is only shown in detail mode.</i>
bsf-qos-fail	Parameter type: <Alarm::BsfQoS> ((failing fail) ok) Possible values: - failing : qos bulk-sync is failing - fail : qos bulk-sync is failing - ok : qos bulk-sync is ok	current status of qos bulk-sync failure. <i>This element is only shown in detail mode.</i>
bsf-igmp-fail	Parameter type: <Alarm::BsfIGMP> ((failing fail) ok) Possible values: - failing : igmp bulk-sync is failing - fail : igmp bulk-sync is failing - ok : igmp bulk-sync is ok	current status of igmp bulk-sync failure. <i>This element is only shown in detail mode.</i>
bsf-lxfwd-fail	Parameter type: <Alarm::BsfLxFwd> ((failing fail) ok) Possible values: - failing : LxFwd bulk-sync is failing - fail : LxFwd bulk-sync is failing - ok : LxFwd bulk-sync is ok	current status of lxfwd bulk-sync failure. <i>This element is only shown in detail mode.</i>

103.92 Protection Group Alarm Log Status Command

Command Description

This command displays the protection group alarm log status.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

> show alarm snap-shot protection-group [(index)]

Command Parameters

Table 103.92-1 "Protection Group Alarm Log Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm snapshot table index

Command Output

Table 103.92-2 "Protection Group Alarm Log Status Command" Display parameters

Specific Information		
name	Type	Description
last-updated-on	Parameter type: <Sys::timeInSecs> - the time (yyyy-mm-dd:hour:minutes:secs) - unit: UTC	network time in seconds when the alarm was logged. <i>This element is only shown in detail mode.</i>
port	Parameter type: <RedPort::PortIndex> (pon : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> chpair : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::ChannelPairId>) Possible values: - pon : pon-aid - chpair : chpair-aid Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number	specify which port the alarm occurred on. <i>This element is only shown in detail mode.</i>

103 Alarm Snap-shot Status Commands

name	Type	Description
	Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Eqpt::ChannelPairId> - the channel pair identifier	

Only Show Details: alarm snap-shot status		
name	Type	Description
port-protection-fail	Parameter type: <Alarm::ProtNotAvail> ((failing fail) ok) Possible values: - failing : port protection is failing - fail : port protection is failing - ok : port protection is ok	status of port protection failure. <i>This element is only shown in detail mode.</i>
port-switchover-fail	Parameter type: <Alarm::ProtSwFail> ((failing fail) ok) Possible values: - failing : port protection switchover failing - fail : port protection switchover failing - ok : port protection switchover is ok	status of port switchover failure. <i>This element is only shown in detail mode.</i>

103.93 Ont protection Alarm Snapshot Status Command

Command Description

This command displays the ont protection alarm snapshot status.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

> show alarm snap-shot ont-protection [(index)]

Command Parameters

Table 103.93-1 "Ont protection Alarm Snapshot Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm snapshot table index

Command Output

Table 103.93-2 "Ont protection Alarm Snapshot Status Command" Display parameters

Specific Information		
name	Type	Description
last-updated-on	Parameter type: <Sys::timeInSecs> - the time (yyyy-mm-dd:hour:minutes:secs) - unit: UTC	network time in seconds when the alarm was logged. <i>This element is only shown in detail mode.</i>
ont	Parameter type: <Gpon::OntIndex> (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> ng2 : <Ng2::ChannelGroup> / <Ng2::SubchannelGroup> / <Ng2::OntId>) Possible values: - ng2 : ngpon2 style identification Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId>	identifies the ont entry <i>This element is only shown in detail mode.</i>

103 Alarm Snap-shot Status Commands

name	Type	Description
	- the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Ng2::ChannelGroup> - channel group number Field type <Ng2::SubchannelGroup> - subchannel group number Field type <Eqpt::OntId> - the ONT identifier Field type <Ng2::OntId> - the ONT identifier	

Only Show Details: alarm snap-shot status		
name	Type	Description
ont-prot-fail	Parameter type: <Alarm::OntProtNotAvail> ((failing fail) ok) Possible values: - failing : ont protection is failing - fail : ont protection is failing - ok : ont protection is ok	status of ont protection failure. <i>This element is only shown in detail mode.</i>

103.94 ONT General Supplemental Alarm Snapshot Status Command

Command Description

This command displays the ONT general supplemental alarm snapshot status.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

> show alarm snap-shot ont [(index)]

Command Parameters

Table 103.94-1 "ONT General Supplemental Alarm Snapshot Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm snapshot table index

Command Output

Table 103.94-2 "ONT General Supplemental Alarm Snapshot Status Command" Display parameters

Specific Information		
name	Type	Description
ont	Parameter type: <Gpon::OntIndex> (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> ng2 : <Ng2::ChannelGroup> / <Ng2::SubchannelGroup> / <Ng2::OntId>) Possible values: - ng2 : ngpon2 style identification Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId>	identifies the ont entry <i>This element is only shown in detail mode.</i>

103 Alarm Snap-shot Status Commands

name	Type	Description
	- the PON identifier Field type <Ng2::ChannelGroup> - channel group number Field type <Ng2::SubchannelGroup> - subchannel group number Field type <Eqpt::OntId> - the ONT identifier Field type <Ng2::OntId> - the ONT identifier	

Only Show Details: alarm snap-shot status		
name	Type	Description
ont-gen-sw-dnload-file	Parameter type: <Alarm::ONTGENERALSUPPLEMENTALSWDLFILE> (yes no) Possible values: - yes : ont sw download file missing - no : ont works properly	ont sw download file missing <i>This element is only shown in detail mode.</i>
ont-gen-fan-fail	Parameter type: <Alarm::ONTGENERALSUPPLEMENTALFANALM> (yes no) Possible values: - yes : ont fan failure - no : ont works properly	ont fan failure <i>This element is only shown in detail mode.</i>
ont-gen-high-temp	Parameter type: <Alarm::ONTGENERALSUPPLEMENTALHITEMPWARN> (yes no) Possible values: - yes : high temperature warning - no : ont works properly	ont high temperature <i>This element is only shown in detail mode.</i>
ont-gen-high-temp-ex	Parameter type: <Alarm::ONTGENERALSUPPLEMENTALHITEMPSHUTOFF> (yes no) Possible values: - yes : high temperature shutoff - no : ont works properly	ont excessive high temperature <i>This element is only shown in detail mode.</i>
ont-gen-emergency-call	Parameter type: <Alarm::ONTGENERALSUPPLEMENTALECALLACT> (yes no) Possible values: - yes : ont emergency call - no : ont works properly	ont emergency call <i>This element is only shown in detail mode.</i>
ont-gen-sw-version	Parameter type: <Alarm::ONTGENERALSUPPLEMENTALSWVERCTLERR> (yes no) Possible values: - yes : ont sw version control error - no : ont works properly	ont sw version control error <i>This element is only shown in detail mode.</i>
ont-poe-exceed-max	Parameter type: <Alarm::OntPoE> (yes no) Possible values:	ont poe exceed max <i>This element is only shown in detail mode.</i>

name	Type	Description
	- yes : ont poe exceed max occurred - no : no ont poe exceed max	
ont-poe-over-yell	Parameter type: <Alarm::OntPoEY> (yes no) Possible values: - yes : ont poe is nearing its maximum ability to supply the power - no : ont poe is not nearing its maximum ability to supply the power	Specifies ont poe is nearing its maximum ability to supply power <i>This element is only shown in detail mode.</i>
ont-opti-malfunc	Parameter type: <Alarm::OntTransMal> (yes no) Possible values: - yes : ONT detects the malfunction of its optical transceiver - no : ONT not detects the malfunction of its optical transceiver	ONT detects the malfunction of its optical transceiver <i>This element is only shown in detail mode.</i>
ont-gen-cfgdld-fail	Parameter type: <Alarm::OntCfgDld> (yes no) Possible values: - yes : ont poe exceed max occurred - no : no ont poe exceed max	specifies download of voice xml file to ont failed or not. <i>This element is only shown in detail mode.</i>
ont-loopdetect-mis	Parameter type: <Alarm::OntLoopDetectMis> (yes no) Possible values: - yes : ont loop detect mismatch occurred - no : no ont loop detect mismatch	ONT loop detection configuration mismatch <i>This element is only shown in detail mode.</i>
rsi-mismatch	Parameter type: <Alarm::OntRssiMismatch> (yes no) Possible values: - yes : ont dose not support rssi feature - no : ont supports rssi feature	rsi mismatch status <i>This element is only shown in detail mode.</i>
tx-pwr-alm-low	Parameter type: <Alarm::OntTxPwrAlrmLow> (yes no) Possible values: - yes : tx pwr at ont side is too low - no : tx pwr at ont side is normal	tx pwr low alarm status <i>This element is only shown in detail mode.</i>
temp-alm-high	Parameter type: <Alarm::OntTempAlrmHigh> (yes no) Possible values: - yes : temperature at ont side is too high - no : temperature at ont side is normal	temp alarm high status <i>This element is only shown in detail mode.</i>
volt-alm-high	Parameter type: <Alarm::OntVoltAlrmHigh> (yes no) Possible values: - yes : voltage at ont side is too high - no : voltage at ont side is normal	voltage alarm high status <i>This element is only shown in detail mode.</i>
bias-alm-high	Parameter type: <Alarm::OntBiasAlrmHigh> (yes no) Possible values:	bias alarm high status <i>This element is only shown in detail mode.</i>

103 Alarm Snap-shot Status Commands

name	Type	Description
	- yes : bias at ont side is too high - no : bias at ont side is normal	
ont-olt-rx-pw-hig	Parameter type: <Alarm::OltRxPwrAlrmH> (yes no) Possible values: - yes : rx power at olt side is too high - no : rx power at olt side is normal	olt side receive power from ont high <i>This element is only shown in detail mode.</i>
ont-olt-rx-pw-warnhig	Parameter type: <Alarm::OltRxPwrWarnH> (yes no) Possible values: - yes : rx power at olt side is warn high - no : rx power at olt side is normal	olt side receive power from ont high warning <i>This element is only shown in detail mode.</i>
ont-olt-rx-pw-warnlo	Parameter type: <Alarm::OltRxPwrWarnL> (yes no) Possible values: - yes : rx power at olt side is warn low - no : rx power at olt side is normal	olt side receive power from ont low warning <i>This element is only shown in detail mode.</i>
ont-olt-rx-pw-lo	Parameter type: <Alarm::OltRxPwrAlrmL> (yes no) Possible values: - yes : rx power at olt side is too low - no : rx power at olt side is normal	olt side receive power from ont low <i>This element is only shown in detail mode.</i>
ont-gen-tod-out-sync	Parameter type: <Alarm::TODOUTSYNC> (yes no) Possible values: - yes : tod is out-sync with olt - no : tod is sync with olt	tod is out-sync with olt <i>This element is only shown in detail mode.</i>
ont-gen-tune-fail	Parameter type: <Alarm::TUNEFAIL> (yes no) Possible values: - yes : Ont has failed to tune to Target-ChnlPair - no : Ont is to tune to Target-ChnlPair	ONU has failed to tune to Pref-ChnlPair <i>This element is only shown in detail mode.</i>
hgu-tr069-param-fail	Parameter type: <Alarm::HGUTR69FAIL> (yes no) Possible values: - yes : hgu tr069 parameters mismatch - no : hgu tr069 parameters not mismatch	hgu tr069 parameters mismatch <i>This element is only shown in detail mode.</i>
ont-gen-tod-mismatch	Parameter type: <Alarm::TODMISMATCH> (yes no) Possible values: - yes : tod is mismatch - no : tod is ok	tod is mismatch <i>This element is only shown in detail mode.</i>

103.95 SFU ONT General Supplemental Alarm Snapshot Status Command

Command Description

This command displays the SFU ONT general supplemental alarm snapshot status.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm snap-shot sfu-sup [ (index) ]
```

Command Parameters

Table 103.95-1 "SFU ONT General Supplemental Alarm Snapshot Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm snapshot table index

Command Output

Table 103.95-2 "SFU ONT General Supplemental Alarm Snapshot Status Command" Display parameters

Specific Information		
name	Type	Description
ont	Parameter type: <Gpon::OntIndex> (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> ng2 : <Ng2::ChannelGroup> / <Ng2::SubchannelGroup> / <Ng2::OntId>) Possible values: - ng2 : ngpon2 style identification Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId>	identifies the ont entry <i>This element is only shown in detail mode.</i>

103 Alarm Snap-shot Status Commands

name	Type	Description
	- the PON identifier Field type <Ng2::ChannelGroup> - channel group number Field type <Ng2::SubchannelGroup> - subchannel group number Field type <Eqpt::OntId> - the ONT identifier Field type <Ng2::OntId> - the ONT identifier	

Only Show Details: alarm snap-shot status		
name	Type	Description
sfu-sup-sw-file-error	Parameter type: <Alarm::ONTGENERALSUPPLEMENTALSWDLFILE> (yes no) Possible values: - yes : ont sw download file missing - no : ont works properly	SFU ONT - Software file has error or is missing <i>This element is only shown in detail mode.</i>
sfu-sup-fan-failure	Parameter type: <Alarm::ONTGENERALSUPPLEMENTALFANALM> (yes no) Possible values: - yes : ont fan failure - no : ont works properly	SFU ONT - Fan failure <i>This element is only shown in detail mode.</i>
sfu-sup-temp-high-warn	Parameter type: <Alarm::ONTGENERALSUPPLEMENTALHITEMPWARN> (yes no) Possible values: - yes : high temperature warning - no : ont works properly	SFU ONT - High temperature warning <i>This element is only shown in detail mode.</i>
sfu-sup-temp-shutoff	Parameter type: <Alarm::ONTGENERALSUPPLEMENTALHITEMPSHUTOFF> (yes no) Possible values: - yes : high temperature shutoff - no : ont works properly	SFU ONT - Service disabled due to excessive temperature <i>This element is only shown in detail mode.</i>
sfu-sup-emergency-call	Parameter type: <Alarm::ONTGENERALSUPPLEMENTALECALLACT> (yes no) Possible values: - yes : ont emergency call - no : ont works properly	SFU ONT - Emergency call active <i>This element is only shown in detail mode.</i>
sfu-sup-swverctrl-err	Parameter type: <Alarm::ONTGENERALSUPPLEMENTALSWVERCTRLERR> (yes no) Possible values: - yes : ont sw version control error - no : ont works properly	SFU ONT - Software version control error <i>This element is only shown in detail mode.</i>
sfu-sup-poe-exceed-max	Parameter type: <Alarm::OntPoE> (yes no) Possible values:	SFU ONT - Configured PoE feeding exceeds ONT maximum <i>This element is only shown in detail mode.</i>

name	Type	Description
	- yes : ont poe exceed max occurred - no : no ont poe exceed max	
sfu-sup-poe-over-yell	Parameter type: <Alarm::OntPoEY> (yes no) Possible values: - yes : ont poe is nearing its maximum ability to supply the power - no : ont poe is not nearing its maximum ability to supply the power	SFU ONT - specifies ont poe is nearing its maximum ability to supply power <i>This element is only shown in detail mode.</i>
sfu-ont-opti-malfunc	Parameter type: <Alarm::OntTransMal> (yes no) Possible values: - yes : ONT detects the malfunction of its optical transceiver - no : ONT not detects the malfunction of its optical transceiver	ONT detects the malfunction of its optical transceiver <i>This element is only shown in detail mode.</i>
sfu-sup-cfg-dnld-fail	Parameter type: <Alarm::OntCfgDld> (yes no) Possible values: - yes : ont poe exceed max occurred - no : no ont poe exceed max	SFU ONT - Download of voice xml file to ONT failed <i>This element is only shown in detail mode.</i>
sfu-sup-ld-cfg-mism	Parameter type: <Alarm::OntLoopDetectMis> (yes no) Possible values: - yes : ont loop detect mismatch occurred - no : no ont loop detect mismatch	SFU ONT - Loop detection configuration mismatch <i>This element is only shown in detail mode.</i>
sfu-sup-rssi-cfg-mism	Parameter type: <Alarm::OntRssiMismatch> (yes no) Possible values: - yes : ont dose not support rssi feature - no : ont supports rssi feature	SFU ONT - RSSI configuration mismatch <i>This element is only shown in detail mode.</i>
sfu-sup-sfp-tx-low	Parameter type: <Alarm::OntTxPwrAlrmLow> (yes no) Possible values: - yes : tx pwr at ont side is too low - no : tx pwr at ont side is normal	SFU ONT - SFP Tx Power below configured low-level alarm threshold <i>This element is only shown in detail mode.</i>
sfu-sup-sfp-temp-high	Parameter type: <Alarm::OntTempAlrmHigh> (yes no) Possible values: - yes : temperature at ont side is too high - no : temperature at ont side is normal	SFU ONT - SFP Temperature above configured high-level alarm threshold <i>This element is only shown in detail mode.</i>
sfu-sup-sfp-volt-high	Parameter type: <Alarm::OntVoltAlrmHigh> (yes no) Possible values: - yes : voltage at ont side is too high - no : voltage at ont side is normal	SFU ONT - SFP Voltage above configured high-level alarm threshold <i>This element is only shown in detail mode.</i>
sfu-sup-sfp-bias-high	Parameter type: <Alarm::OntBiasAlrmHigh> (yes no) Possible values:	SFU ONT - SFP Bias above configured high-level alarm threshold <i>This element is only shown in</i>

103 Alarm Snap-shot Status Commands

name	Type	Description
	- yes : bias at ont side is too high - no : bias at ont side is normal	<i>detail mode.</i>
sfu-sup-olt-rx-high	Parameter type: <Alarm::OltRxPwrAlrmH> (yes no) Possible values: - yes : rx power at olt side is too high - no : rx power at olt side is normal	SFU ONT - OLT Rx power above receiver operating range <i>This element is only shown in detail mode.</i>
sfu-sup-olt-rx-hi-warn	Parameter type: <Alarm::OltRxPwrWarnH> (yes no) Possible values: - yes : rx power at olt side is warn high - no : rx power at olt side is normal	SFU ONT - OLT Rx power above high-level warning threshold <i>This element is only shown in detail mode.</i>
sfu-sup-olt-rx-lo-warn	Parameter type: <Alarm::OltRxPwrWarnL> (yes no) Possible values: - yes : rx power at olt side is warn low - no : rx power at olt side is normal	SFU ONT - OLT Rx power below low-level warning threshold <i>This element is only shown in detail mode.</i>
sfu-sup-olt-rx-low	Parameter type: <Alarm::OltRxPwrAlrmL> (yes no) Possible values: - yes : rx power at olt side is too low - no : rx power at olt side is normal	SFU ONT - OLT Rx power below receiver operating range <i>This element is only shown in detail mode.</i>
sfu-sup-tod-out-sync	Parameter type: <Alarm::TODOUTSYNC> (yes no) Possible values: - yes : tod is out-sync with olt - no : tod is sync with olt	SFU ONT - ONU TOD is out-sync with OLT <i>This element is only shown in detail mode.</i>
sfu-sup-ont-tune-fail	Parameter type: <Alarm::TUNEFAIL> (yes no) Possible values: - yes : Ont has failed to tune to Target-ChnlPair - no : Ont is to tune to Target-ChnlPair	SFU ONT - ONU has failed to tune to Target-ChnlPair <i>This element is only shown in detail mode.</i>
sfu-tr069-parm-fail	Parameter type: <Alarm::HGUTR69FAIL> (yes no) Possible values: - yes : hgu tr069 parameters mismatch - no : hgu tr069 parameters not mismatch	SFU ONT - hgu tr069 parameters mismatch <i>This element is only shown in detail mode.</i>
sfu-sup-tod-mismatch	Parameter type: <Alarm::TODMISMATCH> (yes no) Possible values: - yes : tod is mismatch - no : tod is ok	SFU ONT - ONU TOD MISMATCH <i>This element is only shown in detail mode.</i>

103.96 SOHO ONT General Supplemental Alarm Snapshot Status Command

Command Description

This command displays the SOHO ONT general supplemental alarm snapshot status.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

> show alarm snap-shot soho-sup [(index)]

Command Parameters

Table 103.96-1 "SOHO ONT General Supplemental Alarm Snapshot Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm snapshot table index

Command Output

Table 103.96-2 "SOHO ONT General Supplemental Alarm Snapshot Status Command" Display parameters

Specific Information		
name	Type	Description
ont	Parameter type: <Gpon::OntIndex> (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> ng2 : <Ng2::ChannelGroup> / <Ng2::SubchannelGroup> / <Ng2::OntId>) Possible values: - ng2 : ngpon2 style identification Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId>	identifies the ont entry <i>This element is only shown in detail mode.</i>

103 Alarm Snap-shot Status Commands

name	Type	Description
	- the PON identifier Field type <Ng2::ChannelGroup> - channel group number Field type <Ng2::SubchannelGroup> - subchannel group number Field type <Eqpt::OntId> - the ONT identifier Field type <Ng2::OntId> - the ONT identifier	

Only Show Details: alarm snap-shot status		
name	Type	Description
soho-sup-sw-file-error	Parameter type: <Alarm::ONTGENERALSUPPLEMENTALSWDLFILE> (yes no) Possible values: - yes : ont sw download file missing - no : ont works properly	SOHO ONT - Software file has error or is missing <i>This element is only shown in detail mode.</i>
soho-sup-fan-failure	Parameter type: <Alarm::ONTGENERALSUPPLEMENTALFANALM> (yes no) Possible values: - yes : ont fan failure - no : ont works properly	SOHO ONT - Fan failure <i>This element is only shown in detail mode.</i>
soho-sup-temp-high-war	Parameter type: <Alarm::ONTGENERALSUPPLEMENTALHITEMPWARN> (yes no) Possible values: - yes : high temperature warning - no : ont works properly	SOHO ONT - High temperature warning <i>This element is only shown in detail mode.</i>
soho-sup-temp-shutoff	Parameter type: <Alarm::ONTGENERALSUPPLEMENTALHITEMPSHUTOFF> (yes no) Possible values: - yes : high temperature shutoff - no : ont works properly	SOHO ONT - Service disabled due to excessive temperature <i>This element is only shown in detail mode.</i>
soho-sup-emergency-cal	Parameter type: <Alarm::ONTGENERALSUPPLEMENTALECALLACT> (yes no) Possible values: - yes : ont emergency call - no : ont works properly	SOHO ONT - Emergency call active <i>This element is only shown in detail mode.</i>
soho-sup-swverctrl-err	Parameter type: <Alarm::ONTGENERALSUPPLEMENTALSWVERCTRLERR> (yes no) Possible values: - yes : ont sw version control error - no : ont works properly	SOHO ONT - Software version control error <i>This element is only shown in detail mode.</i>
soho-sup-poe-exceed-ma	Parameter type: <Alarm::OntPoE> (yes no) Possible values:	SOHO ONT - Configured PoE feeding exceeds ONT maximum <i>This element is only shown in detail mode.</i>

name	Type	Description
	- yes : ont poe exceed max occurred - no : no ont poe exceed max	
soho-sup-poe-over-yell	Parameter type: <Alarm::OntPoEY> (yes no) Possible values: - yes : ont poe is nearing its maximum ability to supply the power - no : ont poe is not nearing its maximum ability to supply the power	SOHO ONT - specifies ont poe is nearing its maximum ability to supply power <i>This element is only shown in detail mode.</i>
soho-ont-opti-malfunc	Parameter type: <Alarm::OntTransMal> (yes no) Possible values: - yes : ONT detects the malfunction of its optical transceiver - no : ONT not detects the malfunction of its optical transceiver	ONT detects the malfunction of its optical transceiver <i>This element is only shown in detail mode.</i>
soho-sup-cfg-dnld-fail	Parameter type: <Alarm::OntCfgDld> (yes no) Possible values: - yes : ont poe exceed max occurred - no : no ont poe exceed max	SOHO ONT - Download of voice xml file to ONT failed <i>This element is only shown in detail mode.</i>
soho-sup-ld-cfg-mism	Parameter type: <Alarm::OntLoopDetectMis> (yes no) Possible values: - yes : ont loop detect mismatch occurred - no : no ont loop detect mismatch	SOHO ONT - Loop detection configuration mismatch <i>This element is only shown in detail mode.</i>
soho-sup-rssi-cfg-mism	Parameter type: <Alarm::OntRssiMismatch> (yes no) Possible values: - yes : ont dose not support rssi feature - no : ont supports rssi feature	SOHO ONT - RSSI configuration mismatch <i>This element is only shown in detail mode.</i>
soho-sup-sfp-tx-low	Parameter type: <Alarm::OntTxPwrAlrmLow> (yes no) Possible values: - yes : tx pwr at ont side is too low - no : tx pwr at ont side is normal	SOHO ONT - SFP Tx Power below configured low-level alarm threshold <i>This element is only shown in detail mode.</i>
soho-sup-sfp-temp-high	Parameter type: <Alarm::OntTempAlrmHigh> (yes no) Possible values: - yes : temperature at ont side is too high - no : temperature at ont side is normal	SOHO ONT - SFP Temperature above configured high-level alarm threshold <i>This element is only shown in detail mode.</i>
soho-sup-sfp-volt-high	Parameter type: <Alarm::OntVoltAlrmHigh> (yes no) Possible values: - yes : voltage at ont side is too high - no : voltage at ont side is normal	SOHO ONT - SFP Voltage above configured high-level alarm threshold <i>This element is only shown in detail mode.</i>
soho-sup-sfp-bias-high	Parameter type: <Alarm::OntBiasAlrmHigh> (yes no) Possible values:	SOHO ONT - SFP Bias above configured high-level alarm threshold <i>This element is only shown in</i>

103 Alarm Snap-shot Status Commands

name	Type	Description
	- yes : bias at ont side is too high - no : bias at ont side is normal	<i>detail mode.</i>
soho-sup-olt-rx-high	Parameter type: <Alarm::OltRxPwrAlrmH> (yes no) Possible values: - yes : rx power at olt side is too high - no : rx power at olt side is normal	SOHO ONT - OLT Rx power above receiver operating range <i>This element is only shown in detail mode.</i>
soho-sup-olt-rx-hi-war	Parameter type: <Alarm::OltRxPwrWarnH> (yes no) Possible values: - yes : rx power at olt side is warn high - no : rx power at olt side is normal	SOHO ONT - OLT Rx power above high-level warning threshold <i>This element is only shown in detail mode.</i>
soho-sup-olt-rx-lo-war	Parameter type: <Alarm::OltRxPwrWarnL> (yes no) Possible values: - yes : rx power at olt side is warn low - no : rx power at olt side is normal	SOHO ONT - OLT Rx power below low-level warning threshold <i>This element is only shown in detail mode.</i>
soho-sup-olt-rx-low	Parameter type: <Alarm::OltRxPwrAlrmL> (yes no) Possible values: - yes : rx power at olt side is too low - no : rx power at olt side is normal	SOHO ONT - OLT Rx power below receiver operating range <i>This element is only shown in detail mode.</i>
soho-sup-tod-out-sync	Parameter type: <Alarm::TODOUTSYNC> (yes no) Possible values: - yes : tod is out-sync with olt - no : tod is sync with olt	SOHO ONT - ONU TOD is out-sync with OLT <i>This element is only shown in detail mode.</i>
soho-sup-ont-tune-fail	Parameter type: <Alarm::TUNEFAIL> (yes no) Possible values: - yes : Ont has failed to tune to Target-ChnlPair - no : Ont is to tune to Target-ChnlPair	SOHO ONT - ONU has failed to tune to Target-ChnlPair <i>This element is only shown in detail mode.</i>
soho-tr069-param-fail	Parameter type: <Alarm::HGUTR69FAIL> (yes no) Possible values: - yes : hgu tr069 parameters mismatch - no : hgu tr069 parameters not mismatch	SOHO ONT - hgu tr069 parameters mismatch <i>This element is only shown in detail mode.</i>
soho-sup-tod-mismatch	Parameter type: <Alarm::TODMISMATCH> (yes no) Possible values: - yes : tod is mismatch - no : tod is ok	SOHO ONT - ONU TOD MISMATCH <i>This element is only shown in detail mode.</i>

103.97 MDU ONT General Supplemental Alarm Snapshot Status Command

Command Description

This command displays the MDU ONT general supplemental alarm snapshot status.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

> show alarm snap-shot mdu-sup [(index)]

Command Parameters

Table 103.97-1 "MDU ONT General Supplemental Alarm Snapshot Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm snapshot table index

Command Output

Table 103.97-2 "MDU ONT General Supplemental Alarm Snapshot Status Command" Display parameters

Specific Information		
name	Type	Description
ont	Parameter type: <Gpon::OntIndex> (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> ng2 : <Ng2::ChannelGroup> / <Ng2::SubchannelGroup> / <Ng2::OntId>) Possible values: - ng2 : ngpon2 style identification Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId>	identifies the ont entry <i>This element is only shown in detail mode.</i>

103 Alarm Snap-shot Status Commands

name	Type	Description
	- the PON identifier Field type <Ng2::ChannelGroup> - channel group number Field type <Ng2::SubchannelGroup> - subchannel group number Field type <Eqpt::OntId> - the ONT identifier Field type <Ng2::OntId> - the ONT identifier	

Only Show Details: alarm snap-shot status		
name	Type	Description
mdu-sup-sw-file-error	Parameter type: <Alarm::ONTGENERALSUPPLEMENTALSWDLFILE> (yes no) Possible values: - yes : ont sw download file missing - no : ont works properly	MDU ONT - Software file has error or is missing <i>This element is only shown in detail mode.</i>
mdu-sup-fan-failure	Parameter type: <Alarm::ONTGENERALSUPPLEMENTALFANALM> (yes no) Possible values: - yes : ont fan failure - no : ont works properly	MDU ONT - Fan failure <i>This element is only shown in detail mode.</i>
mdu-sup-temp-high-warn	Parameter type: <Alarm::ONTGENERALSUPPLEMENTALHITEMPWARN> (yes no) Possible values: - yes : high temperature warning - no : ont works properly	MDU ONT - High temperature warning <i>This element is only shown in detail mode.</i>
mdu-sup-temp-shutoff	Parameter type: <Alarm::ONTGENERALSUPPLEMENTALHITEMPSHUTOFF> (yes no) Possible values: - yes : high temperature shutoff - no : ont works properly	MDU ONT - Service disabled due to excessive temperature <i>This element is only shown in detail mode.</i>
mdu-sup-emergency-call	Parameter type: <Alarm::ONTGENERALSUPPLEMENTALECALLACT> (yes no) Possible values: - yes : ont emergency call - no : ont works properly	MDU ONT - Emergency call active <i>This element is only shown in detail mode.</i>
mdu-sup-swverctrl-err	Parameter type: <Alarm::ONTGENERALSUPPLEMENTALSWVERCTRLERR> (yes no) Possible values: - yes : ont sw version control error - no : ont works properly	MDU ONT - Software version control error <i>This element is only shown in detail mode.</i>
mdu-sup-poe-exceed-max	Parameter type: <Alarm::OntPoE> (yes no) Possible values:	MDU ONT - Configured PoE feeding exceeds ONT maximum <i>This element is only shown in detail mode.</i>

name	Type	Description
	- yes : ont poe exceed max occurred - no : no ont poe exceed max	
mdu-sup-poe-over-yell	Parameter type: <Alarm::OntPoEY> (yes no) Possible values: - yes : ont poe is nearing its maximum ability to supply the power - no : ont poe is not nearing its maximum ability to supply the power	MDU ONT - specifies ont poe is nearing its maximum ability to supply power <i>This element is only shown in detail mode.</i>
mdu-opti-malfunc	Parameter type: <Alarm::OntTransMal> (yes no) Possible values: - yes : ONT detects the malfunction of its optical transceiver - no : ONT not detects the malfunction of its optical transceiver	ONT detects the malfunction of its optical transceiver <i>This element is only shown in detail mode.</i>
mdu-sup-cfg-dnld-fail	Parameter type: <Alarm::OntCfgDld> (yes no) Possible values: - yes : ont poe exceed max occurred - no : no ont poe exceed max	MDU ONT - Download of voice xml file to ONT failed <i>This element is only shown in detail mode.</i>
mdu-sup-ld-cfg-mism	Parameter type: <Alarm::OntLoopDetectMis> (yes no) Possible values: - yes : ont loop detect mismatch occurred - no : no ont loop detect mismatch	MDU ONT - Loop detection configuration mismatch <i>This element is only shown in detail mode.</i>
mdu-sup-rssi-cfg-mism	Parameter type: <Alarm::OntRssiMismatch> (yes no) Possible values: - yes : ont dose not support rssi feature - no : ont supports rssi feature	MDU ONT - RSSI configuration mismatch <i>This element is only shown in detail mode.</i>
mdu-sup-sfp-tx-low	Parameter type: <Alarm::OntTxPwrAlrmLow> (yes no) Possible values: - yes : tx pwr at ont side is too low - no : tx pwr at ont side is normal	MDU ONT - SFP Tx Power below configured low-level alarm threshold <i>This element is only shown in detail mode.</i>
mdu-sup-sfp-temp-high	Parameter type: <Alarm::OntTempAlrmHigh> (yes no) Possible values: - yes : temperature at ont side is too high - no : temperature at ont side is normal	MDU ONT - SFP Temperature above configured high-level alarm threshold <i>This element is only shown in detail mode.</i>
mdu-sup-sfp-volt-high	Parameter type: <Alarm::OntVoltAlrmHigh> (yes no) Possible values: - yes : voltage at ont side is too high - no : voltage at ont side is normal	MDU ONT - SFP Voltage above configured high-level alarm threshold <i>This element is only shown in detail mode.</i>
mdu-sup-sfp-bias-high	Parameter type: <Alarm::OntBiasAlrmHigh> (yes no) Possible values:	MDU ONT - SFP Bias above configured high-level alarm threshold <i>This element is only shown in</i>

103 Alarm Snap-shot Status Commands

name	Type	Description
	- yes : bias at ont side is too high - no : bias at ont side is normal	<i>detail mode.</i>
mdu-sup-olt-rx-high	Parameter type: <Alarm::OltRxPwrAlrmH> (yes no) Possible values: - yes : rx power at olt side is too high - no : rx power at olt side is normal	MDU ONT - OLT Rx power above receiver operating range <i>This element is only shown in detail mode.</i>
mdu-sup-olt-rx-hi-warn	Parameter type: <Alarm::OltRxPwrWarnH> (yes no) Possible values: - yes : rx power at olt side is warn high - no : rx power at olt side is normal	MDU ONT - OLT Rx power above high-level warning threshold <i>This element is only shown in detail mode.</i>
mdu-sup-olt-rx-lo-warn	Parameter type: <Alarm::OltRxPwrWarnL> (yes no) Possible values: - yes : rx power at olt side is warn low - no : rx power at olt side is normal	MDU ONT - OLT Rx power below low-level warning threshold <i>This element is only shown in detail mode.</i>
mdu-sup-olt-rx-low	Parameter type: <Alarm::OltRxPwrAlrmL> (yes no) Possible values: - yes : rx power at olt side is too low - no : rx power at olt side is normal	MDU ONT - OLT Rx power below receiver operating range <i>This element is only shown in detail mode.</i>
mdu-sup-tod-out-sync	Parameter type: <Alarm::TODOUTSYNC> (yes no) Possible values: - yes : tod is out-sync with olt - no : tod is sync with olt	MDU ONT - ONU TOD is out-sync with OLT <i>This element is only shown in detail mode.</i>
mdu-sup-ont-tune-fail	Parameter type: <Alarm::TUNEFAIL> (yes no) Possible values: - yes : Ont has failed to tune to Target-ChnlPair - no : Ont is to tune to Target-ChnlPair	MDU ONT - ONU has failed to tune to Target-ChnlPair <i>This element is only shown in detail mode.</i>
mdu-tr069-param-fail	Parameter type: <Alarm::HGUTR69FAIL> (yes no) Possible values: - yes : hgu tr069 parameters mismatch - no : hgu tr069 parameters not mismatch	MDU ONT - hgu tr069 parameters mismatch <i>This element is only shown in detail mode.</i>
mdu-sup-tod-mismatch	Parameter type: <Alarm::TODMISMATCH> (yes no) Possible values: - yes : tod is mismatch - no : tod is ok	MDU ONT - ONU TOD MISMATCH <i>This element is only shown in detail mode.</i>

103.98 ONT General Supplemental 2 Alarm Snapshot Status Command

Command Description

This command displays the ONT general supplemental2 alarm snapshot status.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

> show alarm snap-shot ont-ani [(index)]

Command Parameters

Table 103.98-1 "ONT General Supplemental 2 Alarm Snapshot Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm snapshot table index

Command Output

Table 103.98-2 "ONT General Supplemental 2 Alarm Snapshot Status Command" Display parameters

Specific Information		
name	Type	Description
ont	Parameter type: <Gpon::OntIndex> (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> ng2 : <Ng2::ChannelGroup> / <Ng2::SubchannelGroup> / <Ng2::OntId>) Possible values: - ng2 : ngpon2 style identification Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId>	identifies the ont entry <i>This element is only shown in detail mode.</i>

103 Alarm Snap-shot Status Commands

name	Type	Description
	- the PON identifier Field type <Ng2::ChannelGroup> - channel group number Field type <Ng2::SubchannelGroup> - subchannel group number Field type <Eqpt::OntId> - the ONT identifier Field type <Ng2::OntId> - the ONT identifier	

Only Show Details: alarm snap-shot status		
name	Type	Description
temp-alm-low	Parameter type: <Alarm::OntTempAlrmLow> (yes no) Possible values: - yes : temp at ont side is too low - no : temp at ont side is normal	temp alarm low status <i>This element is only shown in detail mode.</i>
volt-alm-low	Parameter type: <Alarm::OntVoltAlrmLow> (yes no) Possible values: - yes : voltage at ont side is too low - no : voltage at ont side is normal	voltage alarm low status <i>This element is only shown in detail mode.</i>
bias-alm-low	Parameter type: <Alarm::OntBiasAlrmLow> (yes no) Possible values: - yes : bias at ont side is too low - no : bias at ont side is normal	bias alarm low status <i>This element is only shown in detail mode.</i>
tx-pwr-alm-high	Parameter type: <Alarm::OntTxPwrAlrmHigh> (yes no) Possible values: - yes : tx power at ont side is too high - no : tx power at ont side is normal	tx pwr high alarm status <i>This element is only shown in detail mode.</i>
rx-pwr-warn-high	Parameter type: <Alarm::OntRxPwrWarnHigh> (yes no) Possible values: - yes : rx power at ont side is too high - no : rx power at ont side is normal	rx pwr warning high status <i>This element is only shown in detail mode.</i>
rx-pwr-warn-low	Parameter type: <Alarm::OntRxPwrWarnLow> (yes no) Possible values: - yes : rx power at ont side is too low - no : rx power at ont side is normal	rx pwr warning high status <i>This element is only shown in detail mode.</i>
tx-pwr-warn-high	Parameter type: <Alarm::OntTxPwrWarnHigh> (yes no) Possible values: - yes : tx power at ont side is too high - no : tx power at ont side is normal	tx pwr warning high status <i>This element is only shown in detail mode.</i>
tx-pwr-warn-low	Parameter type: <Alarm::OntTxPwrWarnLow> (yes no) Possible values:	tx pwr warning low status <i>This element is only shown in detail mode.</i>

name	Type	Description
	- yes : tx power at ont side is too low - no : tx power at ont side is normal	
temp-warn-high	Parameter type: <Alarm::OntTempWarnHigh> (yes no) Possible values: - yes : temp at ont side is too high - no : temp at ont side is normal	temp warning high status <i>This element is only shown in detail mode.</i>
temp-warn-low	Parameter type: <Alarm::OntTempWarnLow> (yes no) Possible values: - yes : temp at ont side is too low - no : temp at ont side is normal	temp warning low status <i>This element is only shown in detail mode.</i>
volt-warn-high	Parameter type: <Alarm::OntVoltWarnHigh> (yes no) Possible values: - yes : voltage at ont side is too high - no : voltage at ont side is normal	voltage warning high status <i>This element is only shown in detail mode.</i>
volt-warn-low	Parameter type: <Alarm::OntVoltWarnLow> (yes no) Possible values: - yes : voltage at ont side is too low - no : voltage at ont side is normal	voltage warning low status <i>This element is only shown in detail mode.</i>
bias-warn-high	Parameter type: <Alarm::OntBiasWarnHigh> (yes no) Possible values: - yes : bias at ont side is too high - no : bias at ont side is normal	bias warning high status <i>This element is only shown in detail mode.</i>
bias-warn-low	Parameter type: <Alarm::OntBiasWarnLow> (yes no) Possible values: - yes : bias at ont side is too low - no : bias at ont side is normal	bias warning low status <i>This element is only shown in detail mode.</i>

103.99 SFU ONT General Supplemental 2 Alarm Snapshot Status Command

Command Description

This command displays the SFU ONT general supplemental 2 alarm snapshot status.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm snap-shot sfu-sup2 [ (index) ]
```

Command Parameters

Table 103.99-1 "SFU ONT General Supplemental 2 Alarm Snapshot Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm snapshot table index

Command Output

Table 103.99-2 "SFU ONT General Supplemental 2 Alarm Snapshot Status Command" Display parameters

Specific Information		
name	Type	Description
ont	Parameter type: <Gpon::OntIndex> (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> ng2 : <Ng2::ChannelGroup> / <Ng2::SubchannelGroup> / <Ng2::OntId>) Possible values: - ng2 : ngpon2 style identification Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId>	identifies the ont entry <i>This element is only shown in detail mode.</i>

name	Type	Description
	- the PON identifier Field type <Ng2::ChannelGroup> - channel group number Field type <Ng2::SubchannelGroup> - subchannel group number Field type <Eqpt::OntId> - the ONT identifier Field type <Ng2::OntId> - the ONT identifier	

Only Show Details: alarm snap-shot status		
name	Type	Description
sfu-sup2-temp-low	Parameter type: <Alarm::OntTempAlrmLow> (yes no) Possible values: - yes : temp at ont side is too low - no : temp at ont side is normal	SFU ONT - SFP Temperature is higher than configured alarm high threshold <i>This element is only shown in detail mode.</i>
sfu-sup2-volt-low	Parameter type: <Alarm::OntVoltAlrmLow> (yes no) Possible values: - yes : voltage at ont side is too low - no : voltage at ont side is normal	SFU ONT - SFP Voltage is higher than configured alarm high threshold <i>This element is only shown in detail mode.</i>
sfu-sup2-bias-low	Parameter type: <Alarm::OntBiasAlrmLow> (yes no) Possible values: - yes : bias at ont side is too low - no : bias at ont side is normal	SFU ONT - SFP Bias is lower than configured alarm low threshold <i>This element is only shown in detail mode.</i>
sfu-sup2-tx-high	Parameter type: <Alarm::OntTxPwrAlrmHigh> (yes no) Possible values: - yes : tx power at ont side is too high - no : tx power at ont side is normal	SFU ONT - SFP tx power is higher than configured alarm high threshold <i>This element is only shown in detail mode.</i>
sfu-sup2-rx-hwarn	Parameter type: <Alarm::OntRxPwrWarnHigh> (yes no) Possible values: - yes : rx power at ont side is too high - no : rx power at ont side is normal	SFU ONT - SFP Rx power is higher than configured warn threshold <i>This element is only shown in detail mode.</i>
sfu-sup2-rx-lwarn	Parameter type: <Alarm::OntRxPwrWarnLow> (yes no) Possible values: - yes : rx power at ont side is too low - no : rx power at ont side is normal	SFU ONT - SFP Rx power is lower than configured warn threshold <i>This element is only shown in detail mode.</i>
sfu-sup2-tx-hwarn	Parameter type: <Alarm::OntTxPwrWarnHigh> (yes no) Possible values: - yes : tx power at ont side is too high - no : tx power at ont side is normal	SFU ONT - SFP Tx power is higher than configured warn threshold <i>This element is only shown in detail mode.</i>
sfu-sup2-tx-lwarn	Parameter type: <Alarm::OntTxPwrWarnLow> (yes no) Possible values:	SFU ONT - SFP Tx power is lower than configured warn threshold <i>This element is only shown in</i>

103 Alarm Snap-shot Status Commands

name	Type	Description
	- yes : tx power at ont side is too low - no : tx power at ont side is normal	<i>detail mode.</i>
sfu-sup2-temp-hwarn	Parameter type: <Alarm::OntTempWarnHigh> (yes no) Possible values: - yes : temp at ont side is too high - no : temp at ont side is normal	SFU ONT - SFP temperature is higher than configured warn threshold <i>This element is only shown in detail mode.</i>
sfu-sup2-temp-lwarn	Parameter type: <Alarm::OntTempWarnLow> (yes no) Possible values: - yes : temp at ont side is too low - no : temp at ont side is normal	SFU ONT - SFP temperature is lower than configured warn threshold <i>This element is only shown in detail mode.</i>
sfu-sup2-volt-hwarn	Parameter type: <Alarm::OntVoltWarnHigh> (yes no) Possible values: - yes : voltage at ont side is too high - no : voltage at ont side is normal	SFU ONT - SFP voltage is higher than configured warn threshold <i>This element is only shown in detail mode.</i>
sfu-sup2-volt-lwarn	Parameter type: <Alarm::OntVoltWarnLow> (yes no) Possible values: - yes : voltage at ont side is too low - no : voltage at ont side is normal	SFU ONT - SFP voltage is lower than configured warn threshold <i>This element is only shown in detail mode.</i>
sfu-sup2-bias-hwarn	Parameter type: <Alarm::OntBiasWarnHigh> (yes no) Possible values: - yes : bias at ont side is too high - no : bias at ont side is normal	SFU ONT - SFP bias is higher than configured warn threshold <i>This element is only shown in detail mode.</i>
sfu-sup2-bias-lwarn	Parameter type: <Alarm::OntBiasWarnLow> (yes no) Possible values: - yes : bias at ont side is too low - no : bias at ont side is normal	SFU ONT - SFP bias is lower than configured warn threshold <i>This element is only shown in detail mode.</i>

103.100 SOHO ONT General Supplemental 2 Alarm Snapshot Status Command

Command Description

This command displays the SOHO ONT general supplemental 2 alarm snapshot status.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm snap-shot soho-sup2 [ (index) ]
```

Command Parameters

Table 103.100-1 "SOHO ONT General Supplemental 2 Alarm Snapshot Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm snapshot table index

Command Output

Table 103.100-2 "SOHO ONT General Supplemental 2 Alarm Snapshot Status Command" Display parameters

Specific Information		
name	Type	Description
ont	Parameter type: <Gpon::OntIndex> (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> ng2 : <Ng2::ChannelGroup> / <Ng2::SubchannelGroup> / <Ng2::OntId>) Possible values: - ng2 : ngpon2 style identification Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId>	identifies the ont entry <i>This element is only shown in detail mode.</i>

103 Alarm Snap-shot Status Commands

name	Type	Description
	- the PON identifier Field type <Ng2::ChannelGroup> - channel group number Field type <Ng2::SubchannelGroup> - subchannel group number Field type <Eqpt::OntId> - the ONT identifier Field type <Ng2::OntId> - the ONT identifier	

Only Show Details: alarm snap-shot status		
name	Type	Description
soho-sup2-temp-low	Parameter type: <Alarm::OntTempAlrmLow> (yes no) Possible values: - yes : temp at ont side is too low - no : temp at ont side is normal	SOHO ONT - SFP Temperature is higher than configured alarm high threshold <i>This element is only shown in detail mode.</i>
soho-sup2-volt-low	Parameter type: <Alarm::OntVoltAlrmLow> (yes no) Possible values: - yes : voltage at ont side is too low - no : voltage at ont side is normal	SOHO ONT - SFP Voltage is higher than configured alarm high threshold <i>This element is only shown in detail mode.</i>
soho-sup2-bias-low	Parameter type: <Alarm::OntBiasAlrmLow> (yes no) Possible values: - yes : bias at ont side is too low - no : bias at ont side is normal	SOHO ONT - SFP Bias is lower than configured alarm low threshold <i>This element is only shown in detail mode.</i>
soho-sup2-tx-high	Parameter type: <Alarm::OntTxPwrAlrmHigh> (yes no) Possible values: - yes : tx power at ont side is too high - no : tx power at ont side is normal	SOHO ONT - SFP tx power is higher than configured alarm high threshold <i>This element is only shown in detail mode.</i>
soho-sup2-rx-hwarn	Parameter type: <Alarm::OntRxPwrWarnHigh> (yes no) Possible values: - yes : rx power at ont side is too high - no : rx power at ont side is normal	SOHO ONT - SFP Rx power is higher than configured warn threshold <i>This element is only shown in detail mode.</i>
soho-sup2-rx-lwarn	Parameter type: <Alarm::OntRxPwrWarnLow> (yes no) Possible values: - yes : rx power at ont side is too low - no : rx power at ont side is normal	SOHO ONT - SFP Rx power is lower than configured warn threshold <i>This element is only shown in detail mode.</i>
soho-sup2-tx-hwarn	Parameter type: <Alarm::OntTxPwrWarnHigh> (yes no) Possible values: - yes : tx power at ont side is too high - no : tx power at ont side is normal	SOHO ONT - SFP Tx power is higher than configured warn threshold <i>This element is only shown in detail mode.</i>
soho-sup2-tx-lwarn	Parameter type: <Alarm::OntTxPwrWarnLow> (yes no) Possible values:	SOHO ONT - SFP Tx power is lower than configured warn threshold <i>This element is only shown in detail mode.</i>

name	Type	Description
	- yes : tx power at ont side is too low - no : tx power at ont side is normal	<i>detail mode.</i>
soho-sup2-temp-hwarn	Parameter type: <Alarm::OntTempWarnHigh> (yes no) Possible values: - yes : temp at ont side is too high - no : temp at ont side is normal	SOHO ONT - SFP temperature is higher than configured warn threshold <i>This element is only shown in detail mode.</i>
soho-sup2-temp-lwarn	Parameter type: <Alarm::OntTempWarnLow> (yes no) Possible values: - yes : temp at ont side is too low - no : temp at ont side is normal	SOHO ONT - SFP temperature is lower than configured warn threshold <i>This element is only shown in detail mode.</i>
soho-sup2-volt-hwarn	Parameter type: <Alarm::OntVoltWarnHigh> (yes no) Possible values: - yes : voltage at ont side is too high - no : voltage at ont side is normal	SOHO ONT - SFP voltage is higher than configured warn threshold <i>This element is only shown in detail mode.</i>
soho-sup2-volt-lwarn	Parameter type: <Alarm::OntVoltWarnLow> (yes no) Possible values: - yes : voltage at ont side is too low - no : voltage at ont side is normal	SOHO ONT - SFP voltage is lower than configured warn threshold <i>This element is only shown in detail mode.</i>
soho-sup2-bias-hwarn	Parameter type: <Alarm::OntBiasWarnHigh> (yes no) Possible values: - yes : bias at ont side is too high - no : bias at ont side is normal	SOHO ONT - SFP bias is higher than configured warn threshold <i>This element is only shown in detail mode.</i>
soho-sup2-bias-lwarn	Parameter type: <Alarm::OntBiasWarnLow> (yes no) Possible values: - yes : bias at ont side is too low - no : bias at ont side is normal	SOHO ONT - SFP bias is lower than configured warn threshold <i>This element is only shown in detail mode.</i>

103.101 MDU ONT General Supplemental 2 Alarm Snapshot Status Command

Command Description

This command displays the MDU ONT general supplemental 2 alarm snapshot status.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm snap-shot mdu-sup2 [ (index) ]
```

Command Parameters

Table 103.101-1 "MDU ONT General Supplemental 2 Alarm Snapshot Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm snapshot table index

Command Output

Table 103.101-2 "MDU ONT General Supplemental 2 Alarm Snapshot Status Command" Display parameters

Specific Information		
name	Type	Description
ont	Parameter type: <Gpon::OntIndex> (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> ng2 : <Ng2::ChannelGroup> / <Ng2::SubchannelGroup> / <Ng2::OntId>) Possible values: - ng2 : ngpon2 style identification Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId>	identifies the ont entry <i>This element is only shown in detail mode.</i>

name	Type	Description
	- the PON identifier Field type <Ng2::ChannelGroup> - channel group number Field type <Ng2::SubchannelGroup> - subchannel group number Field type <Eqpt::OntId> - the ONT identifier Field type <Ng2::OntId> - the ONT identifier	

Only Show Details: alarm snap-shot status		
name	Type	Description
mdu-sup2-temp-low	Parameter type: <Alarm::OntTempAlrmLow> (yes no) Possible values: - yes : temp at ont side is too low - no : temp at ont side is normal	MDU ONT - SFP Temperature is higher than configured alarm high threshold <i>This element is only shown in detail mode.</i>
mdu-sup2-volt-low	Parameter type: <Alarm::OntVoltAlrmLow> (yes no) Possible values: - yes : voltage at ont side is too low - no : voltage at ont side is normal	MDU ONT - SFP Voltage is higher than configured alarm high threshold <i>This element is only shown in detail mode.</i>
mdu-sup2-bias-low	Parameter type: <Alarm::OntBiasAlrmLow> (yes no) Possible values: - yes : bias at ont side is too low - no : bias at ont side is normal	MDU ONT - SFP Bias is lower than configured alarm low threshold <i>This element is only shown in detail mode.</i>
mdu-sup2-tx-high	Parameter type: <Alarm::OntTxPwrAlrmHigh> (yes no) Possible values: - yes : tx power at ont side is too high - no : tx power at ont side is normal	MDU ONT - SFP tx power is higher than configured alarm high threshold <i>This element is only shown in detail mode.</i>
mdu-sup2-rx-hwarn	Parameter type: <Alarm::OntRxPwrWarnHigh> (yes no) Possible values: - yes : rx power at ont side is too high - no : rx power at ont side is normal	MDU ONT - SFP Rx power is higher than configured warn threshold <i>This element is only shown in detail mode.</i>
mdu-sup2-rx-lwarn	Parameter type: <Alarm::OntRxPwrWarnLow> (yes no) Possible values: - yes : rx power at ont side is too low - no : rx power at ont side is normal	MDU ONT - SFP Rx power is lower than configured warn threshold <i>This element is only shown in detail mode.</i>
mdu-sup2-tx-hwarn	Parameter type: <Alarm::OntTxPwrWarnHigh> (yes no) Possible values: - yes : tx power at ont side is too high - no : tx power at ont side is normal	MDU ONT - SFP Tx power is higher than configured warn threshold <i>This element is only shown in detail mode.</i>
mdu-sup2-tx-lwarn	Parameter type: <Alarm::OntTxPwrWarnLow> (yes no) Possible values:	MDU ONT - SFP Tx power is lower than configured warn threshold <i>This element is only shown in detail mode.</i>

103 Alarm Snap-shot Status Commands

name	Type	Description
	- yes : tx power at ont side is too low - no : tx power at ont side is normal	<i>detail mode.</i>
mdu-sup2-temp-hwarn	Parameter type: <Alarm::OntTempWarnHigh> (yes no) Possible values: - yes : temp at ont side is too high - no : temp at ont side is normal	MDU ONT - SFP temperature is higher than configured warn threshold <i>This element is only shown in detail mode.</i>
mdu-sup2-temp-lwarn	Parameter type: <Alarm::OntTempWarnLow> (yes no) Possible values: - yes : temp at ont side is too low - no : temp at ont side is normal	MDU ONT - SFP temperature is lower than configured warn threshold <i>This element is only shown in detail mode.</i>
mdu-sup2-volt-hwarn	Parameter type: <Alarm::OntVoltWarnHigh> (yes no) Possible values: - yes : voltage at ont side is too high - no : voltage at ont side is normal	MDU ONT - SFP voltage is higher than configured warn threshold <i>This element is only shown in detail mode.</i>
mdu-sup2-volt-lwarn	Parameter type: <Alarm::OntVoltWarnLow> (yes no) Possible values: - yes : voltage at ont side is too low - no : voltage at ont side is normal	MDU ONT - SFP voltage is lower than configured warn threshold <i>This element is only shown in detail mode.</i>
mdu-sup2-bias-hwarn	Parameter type: <Alarm::OntBiasWarnHigh> (yes no) Possible values: - yes : bias at ont side is too high - no : bias at ont side is normal	MDU ONT - SFP bias is higher than configured warn threshold <i>This element is only shown in detail mode.</i>
mdu-sup2-bias-lwarn	Parameter type: <Alarm::OntBiasWarnLow> (yes no) Possible values: - yes : bias at ont side is too low - no : bias at ont side is normal	MDU ONT - SFP bias is lower than configured warn threshold <i>This element is only shown in detail mode.</i>

103.102 LT CFM Alarm SnapShot Status Command

Command Description

This command displays the SnapShot iacm cfm alarm status.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

> show alarm snap-shot cfm [(index)]

Command Parameters

Table 103.102-1 "LT CFM Alarm SnapShot Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	cfm log table index

Command Output

Table 103.102-2 "LT CFM Alarm SnapShot Status Command" Display parameters

Specific Information		
name	Type	Description
cfm-mep-id	Parameter type: <UnsignedSignedInteger> - an unsigned integer	dot1agCfmMepIdentifier index where the alarm has occurred. <i>This element is only shown in detail mode.</i>
cfm-unique-id	Parameter type: <Alarm::IdentificationIdxOrZero> - a signed integer	unique identification for the alarm or zero when not applicable, alarm entry is further specified in additional-info <i>This element is only shown in detail mode.</i>
additional-info	Parameter type: <Alarm::AddInfoStringCcm> - additional alarm information	Additional information regarding the cfm alarm <i>This element is only shown in detail mode.</i>

Only Show Details: alarm snap-shot status		
name	Type	Description
cfm-defrdiccm	Parameter type: <Alarm::IacmCfmRdiCcm> (yes no)	specifies rdi bit in ccm received <i>This element is only shown in detail mode.</i>

103 Alarm Snap-shot Status Commands

name	Type	Description
	Possible values: - yes : rdi bit in ccm received - no : no rdi bit in ccm received	
cfm-defmacstatus	Parameter type: <Alarm::IacmCfmMacError> (yes no) Possible values: - yes : mac error status - no : no mac error status	ccm mac error status <i>This element is only shown in detail mode.</i>
cfm-defremoteccm	Parameter type: <Alarm::IacmCfmMepCcm> (yes no) Possible values: - yes : missing ccm from mep - no : no missing ccm from mep	specifies missing ccm from mep <i>This element is only shown in detail mode.</i>
cfm-deferrorccm	Parameter type: <Alarm::IacmCfmInvalidCcm> (yes no) Possible values: - yes : invalid ccm received - no : no invalid ccm received	specifies invalid ccm received <i>This element is only shown in detail mode.</i>
cfm-defxconccm	Parameter type: <Alarm::IacmCfmUnexpectedCcm> (yes no) Possible values: - yes : unexpected ccm received - no : no unexpected ccm received	specifies unexpected ccm received <i>This element is only shown in detail mode.</i>
cfm-defais	Parameter type: <Alarm::IacmCfmAis> (yes no) Possible values: - yes : ethernet ais received - no : no ethernet ais received	specifies ethernet ais received <i>This element is only shown in detail mode.</i>

103.103 IHUB CFM Alarm SnapShot Status Command

Command Description

This command displays the SnapShot ihub cfm alarm status.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm snap-shot eth-cfm [ (index) ]
```

Command Parameters

Table 103.103-1 "IHUB CFM Alarm SnapShot Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	eth cfm log table index

Command Output

Table 103.103-2 "IHUB CFM Alarm SnapShot Status Command" Display parameters

Specific Information		
name	Type	Description
cfm-mep-id	Parameter type: <UnsignedSignedInteger> - an unsigned integer	dot1agCfmMepIdentifier index where the alarm has occurred. <i>This element is only shown in detail mode.</i>
cfm-unique-id	Parameter type: <Alarm::IdentificationIdxOrZero> - a signed integer	unique identification for the alarm or zero when not applicable, alarm entry is further specified in additional-info <i>This element is only shown in detail mode.</i>
additional-info	Parameter type: <Alarm::AddInfoStringIhubCfm> - additional alarm information	Additional information regarding the eth cfm alarm <i>This element is only shown in detail mode.</i>

Only Show Details: alarm snap-shot status

103 Alarm Snap-shot Status Commands

name	Type	Description
defrdiccm	Parameter type: <Alarm::IhubCfmRdiCcm> (yes no) Possible values: - yes : rdi bit in ccm received - no : no rdi bit in ccm received	specifies rdi bit in ccm received <i>This element is only shown in detail mode.</i>
defmacstatus	Parameter type: <Alarm::IhubCfmMacError> (yes no) Possible values: - yes : mac error status - no : no mac error status	ccm mac error status <i>This element is only shown in detail mode.</i>
defremoteccm	Parameter type: <Alarm::IhubCfmMepCcm> (yes no) Possible values: - yes : missing ccm from mep - no : no missing ccm from mep	specifies missing ccm from mep <i>This element is only shown in detail mode.</i>
deferrorccm	Parameter type: <Alarm::IhubCfmInvalidCcm> (yes no) Possible values: - yes : invalid ccm received - no : no invalid ccm received	specifies invalid ccm received <i>This element is only shown in detail mode.</i>
defxconccm	Parameter type: <Alarm::IhubCfmUnexpectedCcm> (yes no) Possible values: - yes : unexpected ccm received - no : no unexpected ccm received	specifies unexpected ccm received <i>This element is only shown in detail mode.</i>

103.104 Alarm SnapShot RSVP Status Command

Command Description

This command displays the snap-shot RSVP alarm status.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm snap-shot rsvp [ (index) ]
```

Command Parameters

Table 103.104-1 "Alarm SnapShot RSVP Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm log table index

Command Output

Table 103.104-2 "Alarm SnapShot RSVP Status Command" Display parameters

Specific Information		
name	Type	Description
router-id	Parameter type: <Ihub::baseRouter> base Possible values: - base : base router	identifies the base router <i>This element is only shown in detail mode.</i>
neighbor-index	Parameter type: <Alarm::IdentificationIdxOrZero> - a signed integer	An unique number to identify the alarm or zero when not applicable, Neighbor is further specified in additional <i>This element is only shown in detail mode.</i>
additional-info	Parameter type: <Alarm::AddInfoString> - additional alarm information	identifies the Neighbor using the Nbr address and ifIndex or empty string if not applicable <i>This element is only shown in detail mode.</i>

Only Show Details: alarm snap-shot status		
name	Type	Description
neighbor-down	Parameter type: <Alarm::RsvpNeighborDown> (yes	specifies whether the RSVP neighbor is down or not

103 Alarm Snap-shot Status Commands

name	Type	Description
	no) Possible values: - yes : rsvp neighbor is down - no : rsvp neighbor is up or rsvp interface is shutdown or ip interface is shutdown or rsvp instance is shutdown	<i>This element is only shown in detail mode.</i>
rsvp-instance-down	Parameter type: <Alarm::RsvpInstanceDown> (yes no) Possible values: - yes : rsvp instance is down - no : rsvp instance is up or not configured	specifies whether the RSVP instance is down or not <i>This element is only shown in detail mode.</i>

103.105 IPD eth-ring Alarm SnapShot Status Command

Command Description

This command displays the SnapShot ipd eth-ring alarm log status.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

> show alarm snap-shot eth-ring [(index)]

Command Parameters

Table 103.105-1 "IPD eth-ring Alarm SnapShot Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm log table index

Command Output

Table 103.105-2 "IPD eth-ring Alarm SnapShot Status Command" Display parameters

Specific Information		
name	Type	Description
ring-id	Parameter type: <Alarm::genAlarmIndex> - index of a current alarm entry	identifies the eth-ring-instance <i>This element is only shown in detail mode.</i>
ring path-index	Parameter type: <Alarm::genAlarmIndex> - index of a current alarm entry	identifies the ring-path within a eth-ring <i>This element is only shown in detail mode.</i>

Only Show Details: alarm snap-shot status		
name	Type	Description
ering-path-blocked	Parameter type: <Alarm::EthRingPathBlocked> (yes no) Possible values: - yes : ethernet ring path is blocked - no : ethernet ring path is unblocked	specifies whether a eth-ring path is blocked or not <i>This element is only shown in detail mode.</i>

103.106 EFM-OAM alarm Snap-shot Status Command

Command Description

This command shows the snap-shot of EFM-OAM alarms.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

> show alarm snap-shot efm-oam [(index)]

Command Parameters

Table 103.106-1 "EFM-OAM alarm Snap-shot Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	current alarm index

Command Output

Table 103.106-2 "EFM-OAM alarm Snap-shot Status Command" Display parameters

Specific Information		
name	Type	Description
line	Parameter type: <Itf::EfmEthernetIndex> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number	identifies the line where the alarm has occurred. <i>This element is only shown in detail mode.</i>
Only Show Details: snap-shot alarm status		
name	Type	Description
link-fault	Parameter type: <Alarm::linkFaultType> (yes no)	Link fault at cpe <i>This element is only shown in detail mode.</i>

103 Alarm Snap-shot Status Commands

name	Type	Description
	Possible values: - yes : link fault at cpe/onu - no : link fault is not exist	
dying-gasp	Parameter type: <Alarm::dyingGaspType> (yes no) Possible values: - yes : dying gasp is exist - no : dying gasp is not exist	received dying gasp indication from cpe <i>This element is only shown in detail mode.</i>
critical-event	Parameter type: <Alarm::criticalEventType> (yes no) Possible values: - yes : critical event is exist - no : critical event is not exist	receive critical event indication from cpe <i>This element is only shown in detail mode.</i>

103.107 ONT loop detect alarm Snap-shot Status Command

Command Description

This command shows the snap-shot of ont loop detect alarms.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm snap-shot ont-loopdetect [ (index) ]
```

Command Parameters

Table 103.107-1 "ONT loop detect alarm Snap-shot Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm snapshot table index

Command Output

Table 103.107-2 "ONT loop detect alarm Snap-shot Status Command" Display parameters

Specific Information		
name	Type	Description
ont	Parameter type: <Gpon::OntIndex> (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> ng2 : <Ng2::ChannelGroup> / <Ng2::SubchannelGroup> / <Ng2::OntId>) Possible values: - ng2 : ngpon2 style identification Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Ng2::ChannelGroup>	identifies the ont entry <i>This element is only shown in detail mode.</i>

103 Alarm Snap-shot Status Commands

name	Type	Description
	- channel group number Field type <Ng2::SubchannelGroup> - subchannel group number Field type <Eqpt::OntId> - the ONT identifier Field type <Ng2::OntId> - the ONT identifier	
ont-loopdetect	Parameter type: <Alarm::OntLoopDetectPortNumber> (port 1 looped port 2 looped port 3 looped port 4 looped port 5 looped port 6 looped port 7 looped port 8 looped port 9 looped port 10 looped port 11 looped port 12 looped port 13 looped port 14 looped port 15 looped port 16 looped port 17 looped port 18 looped port 19 looped port 20 looped port 21 looped port 22 looped port 23 looped port 24 looped) Possible values: - port 1 looped : ont port loop occurred - port 2 looped : ont port loop occurred - port 3 looped : ont port loop occurred - port 4 looped : ont port loop occurred - port 5 looped : ont port loop occurred - port 6 looped : ont port loop occurred - port 7 looped : ont port loop occurred - port 8 looped : ont port loop occurred - port 9 looped : ont port loop occurred - port 10 looped : ont port loop occurred - port 11 looped : ont port loop occurred - port 12 looped : ont port loop occurred - port 13 looped : ont port loop occurred - port 14 looped : ont port loop occurred - port 15 looped : ont port loop occurred - port 16 looped : ont port loop occurred - port 17 looped : ont port loop occurred - port 18 looped : ont port loop occurred - port 19 looped : ont port loop occurred - port 20 looped : ont port loop occurred - port 21 looped : ont port loop occurred - port 22 looped : ont port loop occurred - port 23 looped : ont port loop occurred - port 24 looped : ont port loop occurred	identifies the ont entry <i>This element is only shown in detail mode.</i>

103.108 ONT PLOAM Alarm Snapshot Status Command

Command Description

This command displays the ONT PLOAM alarm snapshot status.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm snap-shot ont-ploam [ (index) ]
```

Command Parameters

Table 103.108-1 "ONT PLOAM Alarm Snapshot Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm log table index

Command Output

Table 103.108-2 "ONT PLOAM Alarm Snapshot Status Command" Display parameters

Specific Information		
name	Type	Description
ont	Parameter type: <Gpon::OntIndex> (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> ng2 : <Ng2::ChannelGroup> / <Ng2::SubchannelGroup> / <Ng2::OntId>) Possible values: - ng2 : ngpon2 style identification Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Ng2::ChannelGroup>	gpon ont equipment ifindex of ont <i>This element is only shown in detail mode.</i>

name	Type	Description
	- channel group number Field type <Ng2::SubchannelGroup> - subchannel group number Field type <Eqpt::OntId> - the ONT identifier Field type <Ng2::OntId> - the ONT identifier	

Only Show Details: current alarm status

name	Type	Description
ont-ploam-loss-sig	Parameter type: <Alarm::ONTPLOAMLOSO> (yes no) Possible values: - yes : loss of signal at ont - no : no loss of signal at ont	loss of signal at ont <i>This element is only shown in detail mode.</i>
ont-ploam-loss-ack	Parameter type: <Alarm::ONTPLOAMLOA> (yes no) Possible values: - yes : loss of acknowledge from ont - no : no loss of acknowledge from ont	loss of acknowledge from ont <i>This element is only shown in detail mode.</i>
ont-ploam-loss-cd	Parameter type: <Alarm::ONTPLOAMLCD> (yes no) Possible values: - yes : loss of gem/atm channel delineation of ont - no : gem/atm channel delineation of ont is normal	loss of gem/atm channel delineation of ont <i>This element is only shown in detail mode.</i>
ont-ploam-phy-eqpt-err	Parameter type: <Alarm::ONTPLOAMPEE> (yes no) Possible values: - yes : physical equipment error of ont - no : no physical equipment error of ont	physical equipment error of ont <i>This element is only shown in detail mode.</i>
ont-ploam-startup-fail	Parameter type: <Alarm::ONTPLOAMSUF> (yes no) Possible values: - yes : startup failure in ranging of ont - no : no startup failure in ranging of ont	startup failure in ranging of ont <i>This element is only shown in detail mode.</i>
ont-ploam-sig-degrade	Parameter type: <Alarm::ONTPLOAMSD> (yes no) Possible values: - yes : signal degrade ber threshold exceeded from ont - no : signal degrade ber threshold is normal	signal degrade ber threshold exceeded from ont <i>This element is only shown in detail mode.</i>
ont-ploam-disabled	Parameter type: <Alarm::ONTPLOAMONTDisabled> (yes no) Possible values: - yes : ont has been autonomously disabled - no : ont is enabled	ont has been autonomously disabled because of misbehaving transmissions <i>This element is only shown in detail mode.</i>
ont-ploam-err-msg	Parameter type: <Alarm::ONTPLOAMMEM> (yes no) Possible values: - yes : message error message from ont - no : no message error message from ont	message error message from ont <i>This element is only shown in detail mode.</i>

103 Alarm Snap-shot Status Commands

name	Type	Description
ont-ploam-inactive	Parameter type: <Alarm::ONTPLOAMInact> (yes no) Possible values: - yes : ont is inactive - no : ont is active	ont is inactive <i>This element is only shown in detail mode.</i>
ont-ploam-sig-fail	Parameter type: <Alarm::ONTPLOAMSF> (yes no) Possible values: - yes : signal fail ber threshold exceeded from ont - no : no signal fail ber threshold exceeded from ont	signal fail ber threshold exceeded from ont <i>This element is only shown in detail mode.</i>
ont-ploam-dying-gasp	Parameter type: <Alarm::ONTPLOAMDG> (yes no) Possible values: - yes : received dying gasp indication from ont - no : no received dying gasp indication from ont	received dying gasp indication from ont <i>This element is only shown in detail mode.</i>
ont-ploam-deact-fail	Parameter type: <Alarm::ONTPLOAMDF> (yes no) Possible values: - yes : deactivate failure of ont - no : no deactivate failure of ont	deactivate failure of ont <i>This element is only shown in detail mode.</i>
ont-ploam-oam	Parameter type: <Alarm::ONTPLOAMLOAM> (yes no) Possible values: - yes : loss of ploam for ont - no : no Loss of ploam for ont	loss of ploam for ont <i>This element is only shown in detail mode.</i>
ont-ploam-win-drift	Parameter type: <Alarm::ONTPLOAMDOW> (yes no) Possible values: - yes : drift of window - no : no drift of window	drift of window. <i>This element is only shown in detail mode.</i>
ont-ploam-rdi	Parameter type: <Alarm::ONTPLOAMRDI> (yes no) Possible values: - yes : remote defect indication from ont - no : no remote defect indication from ont	remote defect indication from ont. <i>This element is only shown in detail mode.</i>
ont-ploam-loss-ks	Parameter type: <Alarm::ONTPLOAMLOKS> (yes no) Possible values: - yes : loss of key synchronization between olt and ont - no : key synchronization between olt and ont is ok	loss of key synchronization between olt and ont <i>This element is only shown in detail mode.</i>
ont-ploam-pwr-burst	Parameter type: <Alarm::ONTPLOAMONTPWRERR> (yes no) Possible values: - yes : ont power up error - no : ont power up ok	ont power up error. <i>This element is only shown in detail mode.</i>
ont-ploam-rog-disa	Parameter type: <Alarm::ONTPLOAMROGUEONTDIS> (yes no)	ont has been autonomously disabled because of misbehaving transmissions and is thought to be

name	Type	Description
	Possible values: - yes : ont has been autonomously disabled to be a rogue ont - no : ont is normal	a rogue ont. <i>This element is only shown in detail mode.</i>
ont-ploam-diff-reach	Parameter type: <Alarm::ONTPLOAMDIFREACH> (yes no) Possible values: - yes : ont has been deactivated because its location on the pon has exceeded its differential reach capability - no : ont is normal	ont has been deactivated because its location on the pon has exceeded its differential reach capability. <i>This element is only shown in detail mode.</i>
ont-ploam-looc	Parameter type: <Alarm::ONTPLOAMLOOC> (yes no) Possible values: - yes : ont has been deactivated due to persistent OMCI MIC failure - no : ont is normal	ont has been deactivated due to persistent OMCI MIC failure. <i>This element is only shown in detail mode.</i>

103.109 SFU ONT PLOAM Alarm Snapshot Status Command

Command Description

This command displays the SFU ONT PLOAM alarm snapshot status.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm snap-shot sfu-ploam [ (index) ]
```

Command Parameters

Table 103.109-1 "SFU ONT PLOAM Alarm Snapshot Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm log table index

Command Output

Table 103.109-2 "SFU ONT PLOAM Alarm Snapshot Status Command" Display parameters

Specific Information		
name	Type	Description
ont	Parameter type: <Gpon::OntIndex> (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> ng2 : <Ng2::ChannelGroup> / <Ng2::SubchannelGroup> / <Ng2::OntId>) Possible values: - ng2 : ngpon2 style identification Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Ng2::ChannelGroup>	gpon ont equipment ifindex of ont <i>This element is only shown in detail mode.</i>

name	Type	Description
	- channel group number Field type <Ng2::SubchannelGroup> - subchannel group number Field type <Eqpt::OntId> - the ONT identifier Field type <Ng2::OntId> - the ONT identifier	

Only Show Details: current alarm status		
name	Type	Description
sfu-ploam-loss-sig	Parameter type: <Alarm::ONTPLOAMLOSO> (yes no) Possible values: - yes : loss of signal at ont - no : no loss of signal at ont	loss of signal at ont <i>This element is only shown in detail mode.</i>
sfu-ploam-loss-ack	Parameter type: <Alarm::ONTPLOAMLOA> (yes no) Possible values: - yes : loss of acknowledge from ont - no : no loss of acknowledge from ont	loss of acknowledge from ont <i>This element is only shown in detail mode.</i>
sfu-ploam-loss-cd	Parameter type: <Alarm::ONTPLOAMLCD> (yes no) Possible values: - yes : loss of gem/atm channel delineation of ont - no : gem/atm channel delineation of ont is normal	loss of gem/atm channel delineation of ont <i>This element is only shown in detail mode.</i>
sfu-ploam-phy-eqpt-err	Parameter type: <Alarm::ONTPLOAMPEE> (yes no) Possible values: - yes : physical equipment error of ont - no : no physical equipment error of ont	physical equipment error of ont <i>This element is only shown in detail mode.</i>
sfu-ploam-startup-fail	Parameter type: <Alarm::ONTPLOAMSUF> (yes no) Possible values: - yes : startup failure in ranging of ont - no : no startup failure in ranging of ont	startup failure in ranging of ont <i>This element is only shown in detail mode.</i>
sfu-ploam-sig-degrade	Parameter type: <Alarm::ONTPLOAMSD> (yes no) Possible values: - yes : signal degrade ber threshold exceeded from ont - no : signal degrade ber threshold is normal	signal degrade ber threshold exceeded from ont <i>This element is only shown in detail mode.</i>
sfu-ploam-disabled	Parameter type: <Alarm::ONTPLOAMONTDisabled> (yes no) Possible values: - yes : ont has been autonomously disabled - no : ont is enabled	ont has been autonomously disabled because of misbehaving transmissions <i>This element is only shown in detail mode.</i>
sfu-ploam-err-msg	Parameter type: <Alarm::ONTPLOAMMEM> (yes no) Possible values: - yes : message error message from ont - no : no message error message from ont	message error message from ont <i>This element is only shown in detail mode.</i>

103 Alarm Snap-shot Status Commands

name	Type	Description
sfu-ploam-inactive	Parameter type: <Alarm::ONTPLOAMInact> (yes no) Possible values: - yes : ont is inactive - no : ont is active	ont is inactive <i>This element is only shown in detail mode.</i>
sfu-ploam-sig-fail	Parameter type: <Alarm::ONTPLOAMSF> (yes no) Possible values: - yes : signal fail ber threshold exceeded from ont - no : no signal fail ber threshold exceeded from ont	signal fail ber threshold exceeded from ont <i>This element is only shown in detail mode.</i>
sfu-ploam-dying-gasp	Parameter type: <Alarm::ONTPLOAMDG> (yes no) Possible values: - yes : received dying gasp indication from ont - no : no received dying gasp indication from ont	received dying gasp indication from ont <i>This element is only shown in detail mode.</i>
sfu-ploam-deact-fail	Parameter type: <Alarm::ONTPLOAMDF> (yes no) Possible values: - yes : deactivate failure of ont - no : no deactivate failure of ont	deactivate failure of ont <i>This element is only shown in detail mode.</i>
sfu-ploam-oam	Parameter type: <Alarm::ONTPLOAMLOAM> (yes no) Possible values: - yes : loss of ploam for ont - no : no Loss of ploam for ont	loss of ploam for ont <i>This element is only shown in detail mode.</i>
sfu-ploam-win-drift	Parameter type: <Alarm::ONTPLOAMDOW> (yes no) Possible values: - yes : drift of window - no : no drift of window	drift of window. <i>This element is only shown in detail mode.</i>
sfu-ploam-rdi	Parameter type: <Alarm::ONTPLOAMRDI> (yes no) Possible values: - yes : remote defect indication from ont - no : no remote defect indication from ont	remote defect indication from ont. <i>This element is only shown in detail mode.</i>
sfu-ploam-loss-ks	Parameter type: <Alarm::ONTPLOAMLOKS> (yes no) Possible values: - yes : loss of key synchronization between olt and ont - no : key synchronization between olt and ont is ok	loss of key synchronization between olt and ont <i>This element is only shown in detail mode.</i>
sfu-ploam-pwr-burst	Parameter type: <Alarm::ONTPLOAMONTPWRERR> (yes no) Possible values: - yes : ont power up error - no : ont power up ok	ont power up error. <i>This element is only shown in detail mode.</i>
sfu-ploam-rog-disa	Parameter type: <Alarm::ONTPLOAMROGUEONTDIS> (yes no)	ont has been autonomously disabled because of misbehaving transmissions and is thought to be

name	Type	Description
	Possible values: - yes : ont has been autonomously disabled to be a rogue ont - no : ont is normal	a rogue ont. <i>This element is only shown in detail mode.</i>
sfu-ploam-diff-reach	Parameter type: <Alarm::ONTPLOAMDIFREACH> (yes no) Possible values: - yes : ont has been deactivated because its location on the pon has exceeded its differential reach capability - no : ont is normal	ont has been deactivated because its location on the pon has exceeded its differential reach capability. <i>This element is only shown in detail mode.</i>
sfu-ploam-looc	Parameter type: <Alarm::ONTPLOAMLOOC> (yes no) Possible values: - yes : ont has been deactivated due to persistent OMCI MIC failure - no : ont is normal	ont has been deactivated due to persistent OMCI MIC failure. <i>This element is only shown in detail mode.</i>

103.110 SOHO ONT PLOAM Alarm Snapshot Status Command

Command Description

This command displays the SOHO ONT PLOAM alarm snapshot status.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm snap-shot soho-ploam [ (index) ]
```

Command Parameters

Table 103.110-1 "SOHO ONT PLOAM Alarm Snapshot Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm log table index

Command Output

Table 103.110-2 "SOHO ONT PLOAM Alarm Snapshot Status Command" Display parameters

Specific Information		
name	Type	Description
ont	Parameter type: <Gpon::OntIndex> (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> ng2 : <Ng2::ChannelGroup> / <Ng2::SubchannelGroup> / <Ng2::OntId>) Possible values: - ng2 : ngpon2 style identification Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Ng2::ChannelGroup>	gpon ont equipment ifindex of ont <i>This element is only shown in detail mode.</i>

name	Type	Description
	- channel group number Field type <Ng2::SubchannelGroup> - subchannel group number Field type <Eqpt::OntId> - the ONT identifier Field type <Ng2::OntId> - the ONT identifier	

Only Show Details: current alarm status

name	Type	Description
soho-ploam-loss-sig	Parameter type: <Alarm::ONTPLOAMLOSO> (yes no) Possible values: - yes : loss of signal at ont - no : no loss of signal at ont	loss of signal at ont <i>This element is only shown in detail mode.</i>
soho-ploam-loss-ack	Parameter type: <Alarm::ONTPLOAMLOA> (yes no) Possible values: - yes : loss of acknowledge from ont - no : no loss of acknowledge from ont	loss of acknowledge from ont <i>This element is only shown in detail mode.</i>
soho-ploam-loss-cd	Parameter type: <Alarm::ONTPLOAMLCD> (yes no) Possible values: - yes : loss of gem/atm channel delineation of ont - no : gem/atm channel delineation of ont is normal	loss of gem/atm channel delineation of ont <i>This element is only shown in detail mode.</i>
soho-ploam-phy-eqpt-er	Parameter type: <Alarm::ONTPLOAMPEE> (yes no) Possible values: - yes : physical equipment error of ont - no : no physical equipment error of ont	physical equipment error of ont <i>This element is only shown in detail mode.</i>
soho-ploam-startup-fai	Parameter type: <Alarm::ONTPLOAMSUF> (yes no) Possible values: - yes : startup failure in ranging of ont - no : no startup failure in ranging of ont	startup failure in ranging of ont <i>This element is only shown in detail mode.</i>
soho-ploam-sig-degrade	Parameter type: <Alarm::ONTPLOAMSD> (yes no) Possible values: - yes : signal degrade ber threshold exceeded from ont - no : signal degrade ber threshold is normal	signal degrade ber threshold exceeded from ont <i>This element is only shown in detail mode.</i>
soho-ploam-disabled	Parameter type: <Alarm::ONTPLOAMONTDisabled> (yes no) Possible values: - yes : ont has been autonomously disabled - no : ont is enabled	ont has been autonomously disabled because of misbehaving transmissions <i>This element is only shown in detail mode.</i>
soho-ploam-err-msg	Parameter type: <Alarm::ONTPLOAMMEM> (yes no) Possible values: - yes : message error message from ont - no : no message error message from ont	message error message from ont <i>This element is only shown in detail mode.</i>

103 Alarm Snap-shot Status Commands

name	Type	Description
soho-ploam-inactive	Parameter type: <Alarm::ONTPLOAMInact> (yes no) Possible values: - yes : ont is inactive - no : ont is active	ont is inactive <i>This element is only shown in detail mode.</i>
soho-ploam-sig-fail	Parameter type: <Alarm::ONTPLOAMSF> (yes no) Possible values: - yes : signal fail ber threshold exceeded from ont - no : no signal fail ber threshold exceeded from ont	signal fail ber threshold exceeded from ont <i>This element is only shown in detail mode.</i>
soho-ploam-dying-gasp	Parameter type: <Alarm::ONTPLOAMDG> (yes no) Possible values: - yes : received dying gasp indication from ont - no : no received dying gasp indication from ont	received dying gasp indication from ont <i>This element is only shown in detail mode.</i>
soho-ploam-deact-fail	Parameter type: <Alarm::ONTPLOAMDF> (yes no) Possible values: - yes : deactivate failure of ont - no : no deactivate failure of ont	deactivate failure of ont <i>This element is only shown in detail mode.</i>
soho-ploam-oam	Parameter type: <Alarm::ONTPLOAMLOAM> (yes no) Possible values: - yes : loss of ploam for ont - no : no Loss of ploam for ont	loss of ploam for ont <i>This element is only shown in detail mode.</i>
soho-ploam-win-drift	Parameter type: <Alarm::ONTPLOAMDOW> (yes no) Possible values: - yes : drift of window - no : no drift of window	drift of window. <i>This element is only shown in detail mode.</i>
soho-ploam-rdi	Parameter type: <Alarm::ONTPLOAMRDI> (yes no) Possible values: - yes : remote defect indication from ont - no : no remote defect indication from ont	remote defect indication from ont. <i>This element is only shown in detail mode.</i>
soho-ploam-loss-ks	Parameter type: <Alarm::ONTPLOAMLOKS> (yes no) Possible values: - yes : loss of key synchronization between olt and ont - no : key synchronization between olt and ont is ok	loss of key synchronization between olt and ont <i>This element is only shown in detail mode.</i>
soho-ploam-pwr-burst	Parameter type: <Alarm::ONTPLOAMONTPWRERR> (yes no) Possible values: - yes : ont power up error - no : ont power up ok	ont power up error. <i>This element is only shown in detail mode.</i>
soho-ploam-rog-disa	Parameter type: <Alarm::ONTPLOAMROGUEONTDIS> (yes no)	ont has been autonomously disabled because of misbehaving transmissions and is thought to be

name	Type	Description
	Possible values: - yes : ont has been autonomously disabled to be a rogue ont - no : ont is normal	a rogue ont. <i>This element is only shown in detail mode.</i>
soho-ploam-diff-reach	Parameter type: <Alarm::ONTPLOAMDIFREACH> (yes no) Possible values: - yes : ont has been deactivated because its location on the pon has exceeded its differential reach capability - no : ont is normal	ont has been deactivated because its location on the pon has exceeded its differential reach capability. <i>This element is only shown in detail mode.</i>
soho-ploam-looc	Parameter type: <Alarm::ONTPLOAMLOOC> (yes no) Possible values: - yes : ont has been deactivated due to persistent OMCI MIC failure - no : ont is normal	ont has been deactivated due to persistent OMCI MIC failure. <i>This element is only shown in detail mode.</i>

103.111 MDU ONT PLOAM Alarm Snapshot Status Command

Command Description

This command displays the MDU ONT PLOAM alarm snapshot status.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm snap-shot mdu-ploam [ (index) ]
```

Command Parameters

Table 103.111-1 "MDU ONT PLOAM Alarm Snapshot Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm log table index

Command Output

Table 103.111-2 "MDU ONT PLOAM Alarm Snapshot Status Command" Display parameters

Specific Information		
name	Type	Description
ont	Parameter type: <Gpon::OntIndex> (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> ng2 : <Ng2::ChannelGroup> / <Ng2::SubchannelGroup> / <Ng2::OntId>) Possible values: - ng2 : ngpon2 style identification Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Ng2::ChannelGroup>	gpon ont equipment ifindex of ont <i>This element is only shown in detail mode.</i>

name	Type	Description
	- channel group number Field type <Ng2::SubchannelGroup> - subchannel group number Field type <Eqpt::OntId> - the ONT identifier Field type <Ng2::OntId> - the ONT identifier	

Only Show Details: current alarm status		
name	Type	Description
mdu-ploam-loss-sig	Parameter type: <Alarm::ONTPLOAMLOSO> (yes no) Possible values: - yes : loss of signal at ont - no : no loss of signal at ont	loss of signal at ont <i>This element is only shown in detail mode.</i>
mdu-ploam-loss-ack	Parameter type: <Alarm::ONTPLOAMLOA> (yes no) Possible values: - yes : loss of acknowledge from ont - no : no loss of acknowledge from ont	loss of acknowledge from ont <i>This element is only shown in detail mode.</i>
mdu-ploam-loss-cd	Parameter type: <Alarm::ONTPLOAMLCD> (yes no) Possible values: - yes : loss of gem/atm channel delineation of ont - no : gem/atm channel delineation of ont is normal	loss of gem/atm channel delineation of ont <i>This element is only shown in detail mode.</i>
mdu-ploam-phy-eqpt-err	Parameter type: <Alarm::ONTPLOAMPEE> (yes no) Possible values: - yes : physical equipment error of ont - no : no physical equipment error of ont	physical equipment error of ont <i>This element is only shown in detail mode.</i>
mdu-ploam-startup-fail	Parameter type: <Alarm::ONTPLOAMSUF> (yes no) Possible values: - yes : startup failure in ranging of ont - no : no startup failure in ranging of ont	startup failure in ranging of ont <i>This element is only shown in detail mode.</i>
mdu-ploam-sig-degrade	Parameter type: <Alarm::ONTPLOAMSD> (yes no) Possible values: - yes : signal degrade ber threshold exceeded from ont - no : signal degrade ber threshold is normal	signal degrade ber threshold exceeded from ont <i>This element is only shown in detail mode.</i>
mdu-ploam-disabled	Parameter type: <Alarm::ONTPLOAMONTDisabled> (yes no) Possible values: - yes : ont has been autonomously disabled - no : ont is enabled	ont has been autonomously disabled because of misbehaving transmissions <i>This element is only shown in detail mode.</i>
mdu-ploam-err-msg	Parameter type: <Alarm::ONTPLOAMMEM> (yes no) Possible values: - yes : message error message from ont - no : no message error message from ont	message error message from ont <i>This element is only shown in detail mode.</i>

103 Alarm Snap-shot Status Commands

name	Type	Description
mdu-ploam-inactive	Parameter type: <Alarm::ONTPLOAMInact> (yes no) Possible values: - yes : ont is inactive - no : ont is active	ont is inactive <i>This element is only shown in detail mode.</i>
mdu-ploam-sig-fail	Parameter type: <Alarm::ONTPLOAMSF> (yes no) Possible values: - yes : signal fail ber threshold exceeded from ont - no : no signal fail ber threshold exceeded from ont	signal fail ber threshold exceeded from ont <i>This element is only shown in detail mode.</i>
mdu-ploam-dying-gasp	Parameter type: <Alarm::ONTPLOAMDG> (yes no) Possible values: - yes : received dying gasp indication from ont - no : no received dying gasp indication from ont	received dying gasp indication from ont <i>This element is only shown in detail mode.</i>
mdu-ploam-deact-fail	Parameter type: <Alarm::ONTPLOAMDF> (yes no) Possible values: - yes : deactivate failure of ont - no : no deactivate failure of ont	deactivate failure of ont <i>This element is only shown in detail mode.</i>
mdu-ploam-oam	Parameter type: <Alarm::ONTPLOAMLOAM> (yes no) Possible values: - yes : loss of ploam for ont - no : no Loss of ploam for ont	loss of ploam for ont <i>This element is only shown in detail mode.</i>
mdu-ploam-win-drift	Parameter type: <Alarm::ONTPLOAMDOW> (yes no) Possible values: - yes : drift of window - no : no drift of window	drift of window. <i>This element is only shown in detail mode.</i>
mdu-ploam-rdi	Parameter type: <Alarm::ONTPLOAMRDI> (yes no) Possible values: - yes : remote defect indication from ont - no : no remote defect indication from ont	remote defect indication from ont. <i>This element is only shown in detail mode.</i>
mdu-ploam-loss-ks	Parameter type: <Alarm::ONTPLOAMLOKS> (yes no) Possible values: - yes : loss of key synchronization between olt and ont - no : key synchronization between olt and ont is ok	loss of key synchronization between olt and ont <i>This element is only shown in detail mode.</i>
mdu-ploam-pwr-burst	Parameter type: <Alarm::ONTPLOAMONTPWRERR> (yes no) Possible values: - yes : ont power up error - no : ont power up ok	ont power up error. <i>This element is only shown in detail mode.</i>
mdu-ploam-rog-disa	Parameter type: <Alarm::ONTPLOAMROGUEONTDIS> (yes no)	ont has been autonomously disabled because of misbehaving transmissions and is thought to be

name	Type	Description
	Possible values: - yes : ont has been autonomously disabled to be a rogue ont - no : ont is normal	a rogue ont. <i>This element is only shown in detail mode.</i>
mdu-ploam-diff-reach	Parameter type: <Alarm::ONTPLOAMDIFREACH> (yes no) Possible values: - yes : ont has been deactivated because its location on the pon has exceeded its differential reach capability - no : ont is normal	ont has been deactivated because its location on the pon has exceeded its differential reach capability. <i>This element is only shown in detail mode.</i>
mdu-ploam-looc	Parameter type: <Alarm::ONTPLOAMLOOC> (yes no) Possible values: - yes : ont has been deactivated due to persistent OMCI MIC failure - no : ont is normal	ont has been deactivated due to persistent OMCI MIC failure. <i>This element is only shown in detail mode.</i>

103.112 ONT General Alarm Snapshot Status Command

Command Description

This command displays the ONT general alarm snapshot status.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm snap-shot ont-gen [ (index) ]
```

Command Parameters

Table 103.112-1 "ONT General Alarm Snapshot Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm snapshot table index

Command Output

Table 103.112-2 "ONT General Alarm Snapshot Status Command" Display parameters

Specific Information		
name	Type	Description
ont	Parameter type: <Gpon::OntIndex> (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> ng2 : <Ng2::ChannelGroup> / <Ng2::SubchannelGroup> / <Ng2::OntId>) Possible values: - ng2 : ngpon2 style identification Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Ng2::ChannelGroup>	identifies the ont entry <i>This element is only shown in detail mode.</i>

name	Type	Description
	- channel group number Field type <Ng2::SubchannelGroup> - subchannel group number Field type <Eqpt::OntId> - the ONT identifier Field type <Ng2::OntId> - the ONT identifier	

Only Show Details: alarm snap-shot status

name	Type	Description
ont-gen-omci-fail	Parameter type: <Alarm::ONTGENERALOMCICOMM> (yes no) Possible values: - yes : ont fails to respond to omci message requests - no : ont responds to omci message requests works properly	ont fails to respond to omci message requests <i>This element is only shown in detail mode.</i>
ont-gen-eqpt-selftest	Parameter type: <Alarm::ONTGENERALEQPT> (yes no) Possible values: - yes : ont has failed a self test - no : ont self test works properly	ont has failed a self-test <i>This element is only shown in detail mode.</i>
ont-gen-ac-pwr-fail	Parameter type: <Alarm::ONTGENERALACFAIL> (yes no) Possible values: - yes : loss of external ac power to the ont - no : external ac power to the ont is ok	loss of external ac power to the ont <i>This element is only shown in detail mode.</i>
ont-gen-bat-missing	Parameter type: <Alarm::ONTGENERALBATTMIS> (yes no) Possible values: - yes : battery is provisioned for ont but is missing - no : battery is provisioned and present for ont	battery is provisioned for ont but is missing <i>This element is only shown in detail mode.</i>
ont-gen-bat-low	Parameter type: <Alarm::ONTGENERALBATTLOW> (yes no) Possible values: - yes : battery charge is low - no : battery charge is ok	battery charge is low <i>This element is only shown in detail mode.</i>
ont-gen-bat-fail	Parameter type: <Alarm::ONTGENERALBATTFAIL> (yes no) Possible values: - yes : battery is provisioned and present but cannot recharge - no : battery is provisioned and present and can recharge	battery is provisioned and present but cannot recharge <i>This element is only shown in detail mode.</i>
ont-gen-phys-intrusion	Parameter type: <Alarm::ONTGENERALINTRUDER> (yes no) Possible values: - yes : unauthorized access to ont and door or box is open - no : authorized access to ont	unauthorized access to ont <i>This element is only shown in detail mode.</i>
ont-gen-sw-dnload-f	Parameter type: <Alarm::ONTGENERALSWDLFAIL> (yes no) Possible values: - yes : download of software to ont has failed - no : download of software to ont works properly	download of software to ont has failed <i>This element is only shown in detail mode.</i>

103 Alarm Snap-shot Status Commands

name	Type	Description
ont-gen-sw-act-fail	Parameter type: <Alarm::ONTGENERALSWACTFAIL> (yes no) Possible values: - yes : ont failed to activate the passive image designated by the olt - no : ont works properly to activate the passive image designated by the olt	ont failed to activate the passive image designated by the olt <i>This element is only shown in detail mode.</i>
ont-gen-sw-dnload-p	Parameter type: <Alarm::ONTGENERALSWDLIP> (yes no) Possible values: - yes : a condition meaning that a transfer of ont software from the olt to the ont is pending or is actually being transmitted - no : a condition meaning that a transfer of ont software from the olt to the ont is not ready	a condition meaning that a transfer of ont software from the olt to the ont is pending or is actually being transmitted <i>This element is only shown in detail mode.</i>
ont-gen-eqpt-vers-mis	Parameter type: <Alarm::ONTGENERALEQVERMIS> (yes no) Possible values: - yes : a condition meaning the provisioned ont equipment part number does not match the version reported by the ont - no : a condition meaning that provisioned ont equipment part number matches the version reported by the ont	a condition meaning the provisioned ont equipment part number does not match the version reported by the ont <i>This element is only shown in detail mode.</i>
ont-gen-sw-vers-mis	Parameter type: <Alarm::ONTGENERALSWVER> (yes no) Possible values: - yes : a condition meaning that the planned software version does not equal the active software version - no : a condition meaning that the planned software version equals the active software version	a condition meaning that the planned software version does not equal the active software version <i>This element is only shown in detail mode.</i>
ont-gen-us-rate-mis	Parameter type: <Alarm::ONTGENERALUSRATE> (yes no) Possible values: - yes : a condition meaning that the planned upstream rate and the actual upstream rate do not match - no : a condition meaning that the planned upstream rate and the actual upstream rate match	a condition meaning that the planned upstream rate and the actual upstream rate do not match <i>This element is only shown in detail mode.</i>
ont-gen-eqpt-prov-sa	Parameter type: <Alarm::ONTGENERALONTMEA> (yes no) Possible values: - yes : mismatch between ont equipment and ont provisioning attributes - no : match between ont equipment and ont provisioning attributes	mismatch between ont equipment and ont provisioning attributes <i>This element is only shown in detail mode.</i>
ont-gen-mdv-env1	Parameter type: <Alarm::ONTGENERALENV1> (yes no) Possible values: - yes : mdv environmental alarm1 - no : do not detect the mdv environmental alarm1	mdv environmental alarm1 <i>This element is only shown in detail mode.</i>
ont-gen-mdv-env2	Parameter type: <Alarm::ONTGENERALENV2> (yes	mdv environmental alarm2 <i>This element is only shown in</i>

name	Type	Description
	no) Possible values: - yes : mdu environmental alarm2 - no : do not detect the mdu environmental alarm2	<i>detail mode.</i>
ont-gen-mdv-env3	Parameter type: <Alarm::ONTGENERALENV3> (yes no) Possible values: - yes : mdu environmental alarm3 - no : do not detect the mdu environmental alarm3	mdv environmental alarm3 <i>This element is only shown in detail mode.</i>
ont-gen-nw-time-err	Parameter type: <Alarm::ONTGENERALNTPERR> (yes no) Possible values: - yes : a condition meaning the ont is unable to establish timing from the ntp server(s) - no : a condition meaning the ont is able to establish timing from the ntp server(s)	a condition meaning the ont is unable to establish timing from the ntp server(s) <i>This element is only shown in detail mode.</i>
ont-gen-opt-sig-high	Parameter type: <Alarm::ONTGENERALLEVELHI> (yes no) Possible values: - yes : optical signal level is too high - no : optical signal level is normal	optical signal level is too high <i>This element is only shown in detail mode.</i>
ont-gen-opt-sig-low	Parameter type: <Alarm::ONTGENERALLEVELLO> (yes no) Possible values: - yes : optical signal level is too low - no : optical signal level is normal	Optical signal level is too low <i>This element is only shown in detail mode.</i>
ont-gen-eqpt-prov-nsa	Parameter type: <Alarm::ONTGENERALONTNSAMEA> (yes no) Possible values: - yes : non service affects mismatch between ont equipment and ont provisioning attributes - no : ont is provisioned properly	non service affects mismatch between ont equipment and ont provisioning attributes <i>This element is only shown in detail mode.</i>

103.113 SFU ONT General Alarm Snapshot Status Command

Command Description

This command displays the SFU ONT general alarm snapshot status.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm snap-shot sfu-gen [ (index) ]
```

Command Parameters

Table 103.113-1 "SFU ONT General Alarm Snapshot Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm snapshot table index

Command Output

Table 103.113-2 "SFU ONT General Alarm Snapshot Status Command" Display parameters

Specific Information		
name	Type	Description
ont	Parameter type: <Gpon::OntIndex> (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> ng2 : <Ng2::ChannelGroup> / <Ng2::SubchannelGroup> / <Ng2::OntId>) Possible values: - ng2 : ngpon2 style identification Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Ng2::ChannelGroup>	identifies the ont entry <i>This element is only shown in detail mode.</i>

name	Type	Description
	- channel group number Field type <Ng2::SubchannelGroup> - subchannel group number Field type <Eqpt::OntId> - the ONT identifier Field type <Ng2::OntId> - the ONT identifier	

Only Show Details: alarm snap-shot status		
name	Type	Description
sfu-gen-omci-fail	Parameter type: <Alarm::ONTGENERALOMCICOMM> (yes no) Possible values: - yes : ont fails to respond to omci message requests - no : ont responds to omci message requests works properly	ont fails to respond to omci message requests <i>This element is only shown in detail mode.</i>
sfu-gen-eqpt-selftest	Parameter type: <Alarm::ONTGENERALEQPT> (yes no) Possible values: - yes : ont has failed a self test - no : ont self test works properly	ont has failed a self-test <i>This element is only shown in detail mode.</i>
sfu-gen-ac-pwr-fail	Parameter type: <Alarm::ONTGENERALACFAIL> (yes no) Possible values: - yes : loss of external ac power to the ont - no : external ac power to the ont is ok	loss of external ac power to the ont" <i>This element is only shown in detail mode.</i>
sfu-gen-bat-missing	Parameter type: <Alarm::ONTGENERALBATTMIS> (yes no) Possible values: - yes : battery is provisioned for ont but is missing - no : battery is provisioned and present for ont	battery is provisioned for ont but is missing <i>This element is only shown in detail mode.</i>
sfu-gen-bat-low	Parameter type: <Alarm::ONTGENERALBATTLLOW> (yes no) Possible values: - yes : battery charge is low - no : battery charge is ok	battery charge is low <i>This element is only shown in detail mode.</i>
sfu-gen-bat-fail	Parameter type: <Alarm::ONTGENERALBATTFAIL> (yes no) Possible values: - yes : battery is provisioned and present but cannot recharge - no : battery is provisioned and present and can recharge	battery is provisioned and present but cannot recharge <i>This element is only shown in detail mode.</i>
sfu-gen-sw-dnload-f	Parameter type: <Alarm::ONTGENERALSWDLFAIL> (yes no) Possible values: - yes : download of software to ont has failed - no : download of software to ont works properly	download of software to ont has failed <i>This element is only shown in detail mode.</i>
sfu-gen-sw-act-fail	Parameter type: <Alarm::ONTGENERALSWACTFAIL> (yes no) Possible values: - yes : ont failed to activate the passive image designated by the olt	ont failed to activate the passive image designated by the olt <i>This element is only shown in detail mode.</i>

103 Alarm Snap-shot Status Commands

name	Type	Description
	- no : ont works properly to activate the passive image designated by the olt	
sfu-gen-sw-dnload-p	Parameter type: <Alarm::ONTGENERALSWDLIP> (yes no) Possible values: - yes : a condition meaning that a transfer of ont software from the olt to the ont is pending or is actually being transmitted - no : a condition meaning that a transfer of ont software from the olt to the ont is not ready	a condition meaning that a transfer of ont software from the olt to the ont is pending or is actually being transmitted <i>This element is only shown in detail mode.</i>
sfu-gen-eqpt-vers-mis	Parameter type: <Alarm::ONTGENERALEQVERMIS> (yes no) Possible values: - yes : a condition meaning the provisioned ont equipment part number does not match the version reported by the ont - no : a condition meaning that provisioned ont equipment part number matches the version reported by the ont	a condition meaning the provisioned ont equipment part number does not match the version reported by the ont <i>This element is only shown in detail mode.</i>
sfu-gen-sw-vers-mis	Parameter type: <Alarm::ONTGENERALSWVER> (yes no) Possible values: - yes : a condition meaning that the planned software version does not equal the active software version - no : a condition meaning that the planned software version equals the active software version	a condition meaning that the planned software version does not equal the active software version <i>This element is only shown in detail mode.</i>
sfu-gen-us-rate-mis	Parameter type: <Alarm::ONTGENERALUSRATE> (yes no) Possible values: - yes : a condition meaning that the planned upstream rate and the actual upstream rate do not match - no : a condition meaning that the planned upstream rate and the actual upstream rate match	a condition meaning that the planned upstream rate and the actual upstream rate do not match <i>This element is only shown in detail mode.</i>
sfu-gen-eqpt-prov-sa	Parameter type: <Alarm::ONTGENERALONTMEA> (yes no) Possible values: - yes : mismatch between ont equipment and ont provisioning attributes - no : match between ont equipment and ont provisioning attributes	mismatch between ont equipment and ont provisioning attributes <i>This element is only shown in detail mode.</i>
sfu-gen-nw-time-err	Parameter type: <Alarm::ONTGENERALNTPERR> (yes no) Possible values: - yes : a condition meaning the ont is unable to establish timing from the ntp server(s) - no : a condition meaning the ont is able to establish timing from the ntp server(s)	a condition meaning the ont is unable to establish timing from the ntp server(s) <i>This element is only shown in detail mode.</i>
sfu-gen-opt-sig-high	Parameter type: <Alarm::ONTGENERALLEVELHI> (yes no) Possible values: - yes : optical signal level is too high - no : optical signal level is normal	optical signal level is too high <i>This element is only shown in detail mode.</i>

name	Type	Description
sfu-gen-opt-sig-low	Parameter type: <Alarm::ONTGENERALLEVELLO> (yes no) Possible values: - yes : optical signal level is too low - no : optical signal level is normal	Optical signal level is too low <i>This element is only shown in detail mode.</i>
sfu-gen-eqpt-prov-nsa	Parameter type: <Alarm::ONTGENERALONTNSAMEA> (yes no) Possible values: - yes : non service affects mismatch between ont equipment and ont provisioning attributes - no : ont is provisioned properly	non service affects mismatch between ont equipment and ont provisioning attributes <i>This element is only shown in detail mode.</i>

103.114 SOHO ONT General Alarm Snapshot Status Command

Command Description

This command displays the SOHO ONT general alarm snapshot status.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

> show alarm snap-shot soho-gen [(index)]

Command Parameters

Table 103.114-1 "SOHO ONT General Alarm Snapshot Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm snapshot table index

Command Output

Table 103.114-2 "SOHO ONT General Alarm Snapshot Status Command" Display parameters

Specific Information		
name	Type	Description
ont	Parameter type: <Gpon::OntIndex> (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> ng2 : <Ng2::ChannelGroup> / <Ng2::SubchannelGroup> / <Ng2::OntId>) Possible values: - ng2 : ngpon2 style identification Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Ng2::ChannelGroup>	identifies the ont entry <i>This element is only shown in detail mode.</i>

name	Type	Description
	- channel group number Field type <Ng2::SubchannelGroup> - subchannel group number Field type <Eqpt::OntId> - the ONT identifier Field type <Ng2::OntId> - the ONT identifier	

Only Show Details: alarm snap-shot status		
name	Type	Description
soho-gen-omci-fail	Parameter type: <Alarm::ONTGENERALOMCICOMM> (yes no) Possible values: - yes : ont fails to respond to omci message requests - no : ont responds to omci message requests works properly	ont fails to respond to omci message requests <i>This element is only shown in detail mode.</i>
soho-gen-eqpt-selftest	Parameter type: <Alarm::ONTGENERALEQPT> (yes no) Possible values: - yes : ont has failed a self test - no : ont self test works properly	ont has failed a self-test <i>This element is only shown in detail mode.</i>
soho-gen-ac-pwr-fail	Parameter type: <Alarm::ONTGENERALACFAIL> (yes no) Possible values: - yes : loss of external ac power to the ont - no : external ac power to the ont is ok	loss of external ac power to the ont" <i>This element is only shown in detail mode.</i>
soho-gen-bat-missing	Parameter type: <Alarm::ONTGENERALBATTMIS> (yes no) Possible values: - yes : battery is provisioned for ont but is missing - no : battery is provisioned and present for ont	battery is provisioned for ont but is missing <i>This element is only shown in detail mode.</i>
soho-gen-bat-low	Parameter type: <Alarm::ONTGENERALBATTLLOW> (yes no) Possible values: - yes : battery charge is low - no : battery charge is ok	battery charge is low <i>This element is only shown in detail mode.</i>
soho-gen-bat-fail	Parameter type: <Alarm::ONTGENERALBATTFAIL> (yes no) Possible values: - yes : battery is provisioned and present but cannot recharge - no : battery is provisioned and present and can recharge	battery is provisioned and present but cannot recharge <i>This element is only shown in detail mode.</i>
soho-gen-sw-dnload-f	Parameter type: <Alarm::ONTGENERALSWDLFAIL> (yes no) Possible values: - yes : download of software to ont has failed - no : download of software to ont works properly	download of software to ont has failed <i>This element is only shown in detail mode.</i>
soho-gen-sw-act-fail	Parameter type: <Alarm::ONTGENERALSWACTFAIL> (yes no) Possible values: - yes : ont failed to activate the passive image designated by the olt	ont failed to activate the passive image designated by the olt <i>This element is only shown in detail mode.</i>

103 Alarm Snap-shot Status Commands

name	Type	Description
	- no : ont works properly to activate the passive image designated by the olt	
soho-gen-sw-dnload-p	Parameter type: <Alarm::ONTGENERALSWDLIP> (yes no) Possible values: - yes : a condition meaning that a transfer of ont software from the olt to the ont is pending or is actually being transmitted - no : a condition meaning that a transfer of ont software from the olt to the ont is not ready	a condition meaning that a transfer of ont software from the olt to the ont is pending or is actually being transmitted <i>This element is only shown in detail mode.</i>
soho-gen-eqpt-vers-mis	Parameter type: <Alarm::ONTGENERALEQVERMIS> (yes no) Possible values: - yes : a condition meaning the provisioned ont equipment part number does not match the version reported by the ont - no : a condition meaning that provisioned ont equipment part number matches the version reported by the ont	a condition meaning the provisioned ont equipment part number does not match the version reported by the ont <i>This element is only shown in detail mode.</i>
soho-gen-sw-vers-mis	Parameter type: <Alarm::ONTGENERALSWVER> (yes no) Possible values: - yes : a condition meaning that the planned software version does not equal the active software version - no : a condition meaning that the planned software version equals the active software version	a condition meaning that the planned software version does not equal the active software version <i>This element is only shown in detail mode.</i>
soho-gen-us-rate-mis	Parameter type: <Alarm::ONTGENERALUSRATE> (yes no) Possible values: - yes : a condition meaning that the planned upstream rate and the actual upstream rate do not match - no : a condition meaning that the planned upstream rate and the actual upstream rate match	a condition meaning that the planned upstream rate and the actual upstream rate do not match <i>This element is only shown in detail mode.</i>
soho-gen-eqpt-prov-sa	Parameter type: <Alarm::ONTGENERALONTMEA> (yes no) Possible values: - yes : mismatch between ont equipment and ont provisioning attributes - no : match between ont equipment and ont provisioning attributes	mismatch between ont equipment and ont provisioning attributes <i>This element is only shown in detail mode.</i>
soho-gen-nw-time-err	Parameter type: <Alarm::ONTGENERALNTPERR> (yes no) Possible values: - yes : a condition meaning the ont is unable to establish timing from the ntp server(s) - no : a condition meaning the ont is able to establish timing from the ntp server(s)	a condition meaning the ont is unable to establish timing from the ntp server(s) <i>This element is only shown in detail mode.</i>
soho-gen-opt-sig-high	Parameter type: <Alarm::ONTGENERALLEVELHI> (yes no) Possible values: - yes : optical signal level is too high - no : optical signal level is normal	optical signal level is too high <i>This element is only shown in detail mode.</i>

name	Type	Description
soho-gen-opt-sig-low	Parameter type: <Alarm::ONTGENERALLEVELLO> (yes no) Possible values: - yes : optical signal level is too low - no : optical signal level is normal	Optical signal level is too low <i>This element is only shown in detail mode.</i>
soho-gen-eqpt-prov-nsa	Parameter type: <Alarm::ONTGENERALONTNSAMEA> (yes no) Possible values: - yes : non service affects mismatch between ont equipment and ont provisioning attributes - no : ont is provisioned properly	non service affects mismatch between ont equipment and ont provisioning attributes <i>This element is only shown in detail mode.</i>

103.115 MDU ONT General Alarm Snapshot Status Command

Command Description

This command displays the MDU ONT general alarm snapshot status.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

> show alarm snap-shot mdu-gen [(index)]

Command Parameters

Table 103.115-1 "MDU ONT General Alarm Snapshot Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm snapshot table index

Command Output

Table 103.115-2 "MDU ONT General Alarm Snapshot Status Command" Display parameters

Specific Information		
name	Type	Description
ont	Parameter type: <Gpon::OntIndex> (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> ng2 : <Ng2::ChannelGroup> / <Ng2::SubchannelGroup> / <Ng2::OntId>) Possible values: - ng2 : ngpon2 style identification Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Ng2::ChannelGroup>	identifies the ont entry <i>This element is only shown in detail mode.</i>

name	Type	Description
	- channel group number Field type <Ng2::SubchannelGroup> - subchannel group number Field type <Eqpt::OntId> - the ONT identifier Field type <Ng2::OntId> - the ONT identifier	

Only Show Details: alarm snap-shot status		
name	Type	Description
mdu-gen-omci-fail	Parameter type: <Alarm::ONTGENERALOMCICOMM> (yes no) Possible values: - yes : ont fails to respond to omci message requests - no : ont responds to omci message requests works properly	ont fails to respond to omci message requests <i>This element is only shown in detail mode.</i>
mdu-gen-eqpt-selftest	Parameter type: <Alarm::ONTGENERALEQPT> (yes no) Possible values: - yes : ont has failed a self test - no : ont self test works properly	ont has failed a self-test <i>This element is only shown in detail mode.</i>
mdu-gen-ac-pwr-fail	Parameter type: <Alarm::ONTGENERALACFAIL> (yes no) Possible values: - yes : loss of external ac power to the ont - no : external ac power to the ont is ok	loss of external ac power to the ont" <i>This element is only shown in detail mode.</i>
mdu-gen-bat-missing	Parameter type: <Alarm::ONTGENERALBATTMIS> (yes no) Possible values: - yes : battery is provisioned for ont but is missing - no : battery is provisioned and present for ont	battery is provisioned for ont but is missing <i>This element is only shown in detail mode.</i>
mdu-gen-bat-low	Parameter type: <Alarm::ONTGENERALBATTLLOW> (yes no) Possible values: - yes : battery charge is low - no : battery charge is ok	battery charge is low <i>This element is only shown in detail mode.</i>
mdu-gen-bat-fail	Parameter type: <Alarm::ONTGENERALBATTFAIL> (yes no) Possible values: - yes : battery is provisioned and present but cannot recharge - no : battery is provisioned and present and can recharge	battery is provisioned and present but cannot recharge <i>This element is only shown in detail mode.</i>
mdu-gen-phys-intrusion	Parameter type: <Alarm::ONTGENERALINTRUDER> (yes no) Possible values: - yes : unauthorized access to ont and door or box is open - no : authorized access to ont	unauthorized access to ont <i>This element is only shown in detail mode.</i>
mdu-gen-sw-dnload-f	Parameter type: <Alarm::ONTGENERALSWDLFAIL> (yes no) Possible values: - yes : download of software to ont has failed - no : download of software to ont works properly	download of software to ont has failed <i>This element is only shown in detail mode.</i>

103 Alarm Snap-shot Status Commands

name	Type	Description
mdu-gen-sw-act-fail	Parameter type: <Alarm::ONTGENERALSWACTFAIL> (yes no) Possible values: - yes : ont failed to activate the passive image designated by the olt - no : ont works properly to activate the passive image designated by the olt	ont failed to activate the passive image designated by the olt <i>This element is only shown in detail mode.</i>
mdu-gen-sw-dnload-p	Parameter type: <Alarm::ONTGENERALSWDLIP> (yes no) Possible values: - yes : a condition meaning that a transfer of ont software from the olt to the ont is pending or is actually being transmitted - no : a condition meaning that a transfer of ont software from the olt to the ont is not ready	a condition meaning that a transfer of ont software from the olt to the ont is pending or is actually being transmitted <i>This element is only shown in detail mode.</i>
mdu-gen-eqpt-vers-mis	Parameter type: <Alarm::ONTGENERALEQVERMIS> (yes no) Possible values: - yes : a condition meaning the provisioned ont equipment part number does not match the version reported by the ont - no : a condition meaning that provisioned ont equipment part number matches the version reported by the ont	a condition meaning the provisioned ont equipment part number does not match the version reported by the ont <i>This element is only shown in detail mode.</i>
mdu-gen-sw-vers-mis	Parameter type: <Alarm::ONTGENERALSWVER> (yes no) Possible values: - yes : a condition meaning that the planned software version does not equal the active software version - no : a condition meaning that the planned software version equals the active software version	a condition meaning that the planned software version does not equal the active software version <i>This element is only shown in detail mode.</i>
mdu-gen-us-rate-mis	Parameter type: <Alarm::ONTGENERALUSRATE> (yes no) Possible values: - yes : a condition meaning that the planned upstream rate and the actual upstream rate do not match - no : a condition meaning that the planned upstream rate and the actual upstream rate match	a condition meaning that the planned upstream rate and the actual upstream rate do not match <i>This element is only shown in detail mode.</i>
mdu-gen-eqpt-prov-sa	Parameter type: <Alarm::ONTGENERALONTMEA> (yes no) Possible values: - yes : mismatch between ont equipment and ont provisioning attributes - no : match between ont equipment and ont provisioning attributes	mismatch between ont equipment and ont provisioning attributes <i>This element is only shown in detail mode.</i>
mdu-gen-mdu-env1	Parameter type: <Alarm::ONTGENERALENV1> (yes no) Possible values: - yes : mdu environmental alarm1 - no : do not detect the mdu environmental alarm1	mdu environmental alarm1 <i>This element is only shown in detail mode.</i>
mdu-gen-mdu-env2	Parameter type: <Alarm::ONTGENERALENV2> (yes	mdu environmental alarm2 <i>This element is only shown in</i>

name	Type	Description
	no) Possible values: - yes : mdu environmental alarm2 - no : do not detect the mdu environmental alarm2	<i>detail mode.</i>
mdu-gen-mdv-env3	Parameter type: <Alarm::ONTGENERALENV3> (yes no) Possible values: - yes : mdu environmental alarm3 - no : do not detect the mdu environmental alarm3	mdv environmental alarm3 <i>This element is only shown in detail mode.</i>
mdv-gen-nw-time-err	Parameter type: <Alarm::ONTGENERALNTPERR> (yes no) Possible values: - yes : a condition meaning the ont is unable to establish timing from the ntp server(s) - no : a condition meaning the ont is able to establish timing from the ntp server(s)	a condition meaning the ont is unable to establish timing from the ntp server(s) <i>This element is only shown in detail mode.</i>
mdv-gen-opt-sig-high	Parameter type: <Alarm::ONTGENERALLEVELHI> (yes no) Possible values: - yes : optical signal level is too high - no : optical signal level is normal	optical signal level is too high <i>This element is only shown in detail mode.</i>
mdv-gen-opt-sig-low	Parameter type: <Alarm::ONTGENERALLEVELLO> (yes no) Possible values: - yes : optical signal level is too low - no : optical signal level is normal	Optical signal level is too low <i>This element is only shown in detail mode.</i>
mdv-gen-eqpt-prov-nsa	Parameter type: <Alarm::ONTGENERALONTNSAMEA> (yes no) Possible values: - yes : non service affects mismatch between ont equipment and ont provisioning attributes - no : ont is provisioned properly	non service affects mismatch between ont equipment and ont provisioning attributes <i>This element is only shown in detail mode.</i>

103.116 Alarm SnapShot ONT SUBSCRIBER CARD Status Command

Command Description

This command displays the snapshot ONT SUBSCRIBER CARD alarm status.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

> show alarm snap-shot ont-card [(index)]

Command Parameters

Table 103.116-1 " Alarm SnapShot ONT SUBSCRIBER CARD Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm snapshot table index

Command Output

Table 103.116-2 " Alarm SnapShot ONT SUBSCRIBER CARD Status Command" Display parameters

Specific Information		
name	Type	Description
ont-card	Parameter type: <Gpon::OntSlotAlarmIndex2> (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Gpon::OntSlotId> ng2 : <Ng2::ChannelGroup> / <Ng2::SubchannelGroup> / <Ng2::OntId> / <Gpon::OntSlotId>) Possible values: - ng2 : ngpon2 style identification Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId>	identifies the ont entry <i>This element is only shown in detail mode.</i>

name	Type	Description
	- the PON identifier Field type <Ng2::ChannelGroup> - channel group number Field type <Ng2::SubchannelGroup> - subchannel group number Field type <Eqpt::OntId> - the ONT identifier Field type <Ng2::OntId> - the ONT identifier Field type <Gpon::OntSlotId> - Gpon Ont Slot - range: [1...14]	

Only Show Details: alarm snap-shot status		
name	Type	Description
ont-sbscr-lim-missing	Parameter type: <Alarm::ONTCARDLIMMISSING> (yes no) Possible values: - yes : provisioned ont card missing - no : provisioned ont card works properly	provisioned ont card missing <i>This element is only shown in detail mode.</i>
ont-sbscr-lim-type-mis	Parameter type: <Alarm::ONTCARDLIMMEA> (yes no) Possible values: - yes : plug-in ont card is wrong type - no : ont card works properly	plug-in ont card is wrong type <i>This element is only shown in detail mode.</i>
ont-sbscr-lim-removal	Parameter type: <Alarm::ONTCARDLIMIMPROPRMVL> (yes no) Possible values: - yes : ont card removed without being deprovisioned - no : ont card removed correctly	ont card removed without being deprovisioned <i>This element is only shown in detail mode.</i>
ont-sbscr-lim-fail	Parameter type: <Alarm::ONTCARDLIMFAIL> (yes no) Possible values: - yes : ont card failed detected or failed self test - no : ont card works properly	ont card failed detected or failed self test <i>This element is only shown in detail mode.</i>
ont-sbscr-lim-svc-mis	Parameter type: <Alarm::ONTCARDLIMSVCNIS> (yes no) Possible values: - yes : ont did not accept the omci configuration requests for the provisioned onu card - no : ont card works properly	ont did not accept the omci configuration requests for the provisioned onu card <i>This element is only shown in detail mode.</i>
ont-sbscr-lim-port-mis	Parameter type: <Alarm::ONTCARDLIMNUMPORTSMIS> (yes no) Possible values: - yes : the actual number of ports of a plug-in ont card is different from the planned number of ports - no : the actual number of ports of a plug-in ont card is the same to the planned number of ports	the actual number of ports of a plug-in ont card is different from the planned number of ports <i>This element is only shown in detail mode.</i>

103.117 Alarm SnapShot ONT SERVICES POTS Status Command

Command Description

This command displays the snapshot ONT SERVICES POTS alarm status.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

> show alarm snap-shot ont-pots [(index)]

Command Parameters

Table 103.117-1 " Alarm SnapShot ONT SERVICES POTS Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm snapshot table index

Command Output

Table 103.117-2 " Alarm SnapShot ONT SERVICES POTS Status Command" Display parameters

Specific Information		
name	Type	Description
ont-pots	Parameter type: <Gpon::OntPotsAlarmIndex2> (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Gpon::OntSlotId> / <Gpon::OntPotsPortId> ng2 : <Ng2::ChannelGroup> / <Ng2::SubchannelGroup> / <Ng2::OntId> / <Gpon::OntSlotId> / <Gpon::OntPotsPortId>) Possible values: - ng2 : ngpon2 style identification Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number	gpon ont pots port index <i>This element is only shown in detail mode.</i>

name	Type	Description
	Field type <Eqpt::PonId> - the PON identifier Field type <Ng2::ChannelGroup> - channel group number Field type <Ng2::SubchannelGroup> - subchannel group number Field type <Eqpt::OntId> - the ONT identifier Field type <Ng2::OntId> - the ONT identifier Field type <Gpon::OntSlotId> - Gpon Ont Slot - range: [1...14] Field type <Gpon::OntPotsPortId> - Gpon Ont Pots Port - range: [1...24]	

Only Show Details: alarm snap-shot status		
name	Type	Description
ont-svc-pots-svc-mis	Parameter type: <Alarm::ONTPOTSSVCMIS> (yes no) Possible values: - yes : ont service mismatch for provisioned pots - no : ont service pots works properly	ont service mismatch for provisioned pots <i>This element is only shown in detail mode.</i>
ont-svc-pots-rtcp-lost	Parameter type: <Alarm::ONTPOTSRTCPSTREAMLOSS> (yes no) Possible values: - yes : pots realtime transport control protocol stream lost - no : ont service pots works properly	pots realtime transport control protocol stream lost <i>This element is only shown in detail mode.</i>
ont-svc-pots-icnf-sub	Parameter type: <Alarm::ONTPOTSICONFIGSUBFAIL> (yes no) Possible values: - yes : iconfig subscription of the pots line failed - no : ont service pots works properly	pots line iconfig subscription failure <i>This element is only shown in detail mode.</i>
ont-svc-pots-icnf-ntfy	Parameter type: <Alarm::ONTPOTSICONFIGNOTIFYFAIL> (yes no) Possible values: - yes : iconfig notify failed for a pots line - no : ont service pots works properly	pots line iconfig notify failure <i>This element is only shown in detail mode.</i>
ont-svc-pots-icnf-http	Parameter type: <Alarm::ONTPOTSICONFIGHTTPFAIL> (yes no) Possible values: - yes : iconfig http redirect failed for a pots line - no : ont service pots works properly	pots line iconfig http failure <i>This element is only shown in detail mode.</i>
ont-svc-pots-sip-reg	Parameter type: <Alarm::ONTPOTSSIPREGFAIL> (yes no) Possible values: - yes : sip registration failed for the pots line - no : ont service pots works properly	pots line sip registration failure <i>This element is only shown in detail mode.</i>
ont-svc-pots-sip-inv	Parameter type: <Alarm::ONTPOTSSIPINVITEFAIL> (yes	pots line sip invite request failure <i>This element is only shown in</i>

103 Alarm Snap-shot Status Commands

name	Type	Description
	no) Possible values: - yes : sip invite request for the pots line failed - no : ont service pots works properly	<i>detail mode.</i>
ont-svc-pots-sip-subsc	Parameter type: <Alarm::ONTPOTSSIPSUBFAIL> (yes no) Possible values: - yes : sip subscribe failed for the pots line - no : ont service pots works properly	pots line sip subscribe failure <i>This element is only shown in detail mode.</i>
ont-svc-pots-sip-mt-tc	Parameter type: <Alarm::ONTPOTSSIPMSGTMOUTTCA> (yes no) Possible values: - yes : number of sip message timeouts threshold has crossed for the pots line - no : ont service pots works properly	pots line sip message timeout threshold crossed <i>This element is only shown in detail mode.</i>
ont-svc-pots-pk-los-tc	Parameter type: <Alarm::ONTPOTSRTTPKTLOSSTCA> (yes no) Possible values: - yes : number of rtp bearer packets loss on a pots line has been crossed - no : ont service pots works properly	pots line rtp bearer packets loss threshold crossed <i>This element is only shown in detail mode.</i>
ont-svc-pots-jitter-tc	Parameter type: <Alarm::ONTPOTSJITTERTCA> (yes no) Possible values: - yes : rtp jitter threshold has been crossed on a pots line - no : ont service pots works properly	pots line rtp jitter threshold crossed <i>This element is only shown in detail mode.</i>
ont-svc-pots-subsc-dns	Parameter type: <Alarm::ONTPOTSICNFSUBSDNS> (yes no) Possible values: - yes : iconfig subscription failed because domain name could not be resolved - no : ont service pots works properly	iconfig subscription failed <i>This element is only shown in detail mode.</i>
ont-svc-pots-subsc-tcp	Parameter type: <Alarm::ONTPOTSICNFSUBSTCP> (yes no) Possible values: - yes : iconfig subscription failed because of TCP socket - no : ont service pots works properly	iconfig subscription failed <i>This element is only shown in detail mode.</i>
ont-svc-pots-subsc-tls	Parameter type: <Alarm::ONTPOTSICNFSUBSTLS> (yes no) Possible values: - yes : iconfig subscription failed because of TLS session - no : ont service pots works properly	iconfig subscription failed <i>This element is only shown in detail mode.</i>
ont-svc-pots-subsc-auth	Parameter type: <Alarm::ONTPOTSICNFSUBSAUTH> (yes no) Possible values: - yes : iconfig subscription failed because authentication failed - no : ont service pots works properly	iconfig subscription failed <i>This element is only shown in detail mode.</i>

name	Type	Description
ont-svc-pots-subst-to	Parameter type: <Alarm::ONTPOTSICNFSUBSTO> (yes no) Possible values: - yes : iconfig subscription failed because of retransmission timeout - no : ont service pots works properly	iconfig subscription failed <i>This element is only shown in detail mode.</i>
ont-svc-pots-subst-err	Parameter type: <Alarm::ONTPOTSICNFSUBSERR> (yes no) Possible values: - yes : iconfig subscription failed because of response error - no : ont service pots works properly	iconfig subscription failed <i>This element is only shown in detail mode.</i>
ont-svc-pots-not-to	Parameter type: <Alarm::ONTPOTSICNFNOTTO> (yes no) Possible values: - yes : iconfig notification failed because of retransmission timeout - no : ont service pots works properly	iconfig notification failed <i>This element is only shown in detail mode.</i>
ont-svc-pots-notref-to	Parameter type: <Alarm::ONTPOTSICNFNOTREFTO> (yes no) Possible values: - yes : iconfig notification refresh failed because of timeout - no : ont service pots works properly	iconfig notification failed <i>This element is only shown in detail mode.</i>
ont-svc-pots-not-mal	Parameter type: <Alarm::ONTPOTSICNFNOTMAL> (yes no) Possible values: - yes : iconfig notification refresh failed because of a malformed message - no : ont service pots works properly	iconfig notification failed <i>This element is only shown in detail mode.</i>
ont-svc-pots-not-rej	Parameter type: <Alarm::ONTPOTSICNFNOTREJ> (yes no) Possible values: - yes : iconfig notification refresh failed because it was rejected by the server - no : ont service pots works properly	iconfig notification failed <i>This element is only shown in detail mode.</i>
ont-svc-pots-http-dns	Parameter type: <Alarm::ONTPOTSICNFHTTTPDNS> (yes no) Possible values: - yes : iconfig doc retrieval failed because domain name could not be resolved - no : ont service pots works properly	iconfig doc retrieval failed <i>This element is only shown in detail mode.</i>
ont-svc-pots-http-tcp	Parameter type: <Alarm::ONTPOTSICNFHTTPTCP> (yes no) Possible values: - yes : iconfig doc retrieval failed because of TCP socket - no : ont service pots works properly	iconfig doc retrieval failed <i>This element is only shown in detail mode.</i>
ont-svc-pots-http-tls	Parameter type: <Alarm::ONTPOTSICNFHTTPTLS> (yes no) Possible values:	iconfig doc retrieval failed <i>This element is only shown in detail mode.</i>

103 Alarm Snap-shot Status Commands

name	Type	Description
	- yes : iconfig doc retrieval failed because of TLS session - no : ont service pots works properly	
ont-svc-pots-http-auth	Parameter type: <Alarm::ONTPOTSICNFHTTPAUTH> (yes no) Possible values: - yes : iconfig doc retrieval failed because authentication failed - no : ont service pots works properly	iconfig doc retrieval failed <i>This element is only shown in detail mode.</i>
ont-svc-pots-http-to	Parameter type: <Alarm::ONTPOTSICNFHTTPTO> (yes no) Possible values: - yes : iconfig doc retrieval failed because of retransmission timeout - no : ont service pots works properly	iconfig doc retrieval failed <i>This element is only shown in detail mode.</i>
ont-svc-pots-http-err	Parameter type: <Alarm::ONTPOTSICNFHTTPERR> (yes no) Possible values: - yes : iconfig doc retrieval failed because of response error - no : ont service pots works properly	iconfig doc retrieval failed <i>This element is only shown in detail mode.</i>
ont-svc-pots-http-mal	Parameter type: <Alarm::ONTPOTSICNFHTTPMAL> (yes no) Possible values: - yes : iconfig doc retrieval failed because of a malformed message - no : ont service pots works properly	iconfig doc retrieval failed <i>This element is only shown in detail mode.</i>
ont-svc-pots-insuff	Parameter type: <Alarm::ONTPOTSINSUFF> (yes no) Possible values: - yes : iconfig service failed because of insufficient data - no : ont VOIP service pots works properly	iconfig VOIP service failed <i>This element is only shown in detail mode.</i>
ont-svc-pots-poos	Parameter type: <Alarm::ONTPOTSPOOS> (yes no) Possible values: - yes : pots ports out of service - no : pots ports work properly	pots ports out of service <i>This element is only shown in detail mode.</i>

103.118 Alarm SnapShot ONT SERVICES LAN

Status Command

Command Description

This command displays the snapshot ONT SERVICES LAN alarm status.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm snap-shot ont-lan [ (index) ]
```

Command Parameters

Table 103.118-1 " Alarm SnapShot ONT SERVICES LAN Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm snapshot table index

Command Output

Table 103.118-2 " Alarm SnapShot ONT SERVICES LAN Status Command" Display parameters

Specific Information		
name	Type	Description
ont-port	Parameter type: <Gpon::IfIndexAlarmIndex2> (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Gpon::OntSlotId> / <Gpon::OntPortId> ng2 : <Ng2::ChannelGroup> / <Ng2::SubchannelGroup> / <Ng2::OntId> / <Gpon::OntSlotId> / <Gpon::OntPortId>) Possible values: - ng2 : ngpon2 style identification Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier	gpon ont port <i>This element is only shown in detail mode.</i>

103 Alarm Snap-shot Status Commands

name	Type	Description
	Field type <Ng2::ChannelGroup> - channel group number Field type <Ng2::SubchannelGroup> - subchannel group number Field type <Eqpt::OntId> - the ONT identifier Field type <Ng2::OntId> - the ONT identifier Field type <Gpon::OntSlotId> - Gpon Ont Slot - range: [1...14] Field type <Gpon::OntPortId> - Gpon Ont Port - range: [1...16]	

Only Show Details: alarm snap-shot status		
name	Type	Description
ont-svc-lan-mismatch	Parameter type: <Alarm::ONTLANSVCMIS> (yes no) Possible values: - yes : the ont did not accept the omci configuration requests for the lan service - no : ont service lan works properly	ont service mismatch for lan <i>This element is only shown in detail mode.</i>
ont-svc-lan-loss-sig	Parameter type: <Alarm::ONTLANLOS> (yes no) Possible values: - yes : loss of signal on an ethernet port interface - no : ont service lan works properly	loss of signal on an ethernet port interface <i>This element is only shown in detail mode.</i>
ont-svc-enet-poos	Parameter type: <Alarm::ONTENETPOOS> (yes no) Possible values: - yes : ethernet ports out of service - no : ethernet ports work properly	ethernet ports out of service <i>This element is only shown in detail mode.</i>

103.119 ONT TCA Alarm Log Status Command

Command Description

This command displays the ONT TCA alarm log status.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

> show alarm snap-shot ont-tca [(index)]

Command Parameters

Table 103.119-1 "ONT TCA Alarm Log Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm type

Command Output

Table 103.119-2 "ONT TCA Alarm Log Status Command" Display parameters

Specific Information		
name	Type	Description
ont	Parameter type: <Gpon::OntIndex> (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> ng2 : <Ng2::ChannelGroup> / <Ng2::SubchannelGroup> / <Ng2::OntId>) Possible values: - ng2 : ngpon2 style identification Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Ng2::ChannelGroup> - channel group number Field type <Ng2::SubchannelGroup> - subchannel group number Field type <Eqpt::OntId>	identifies the ont entry <i>This element is only shown in detail mode.</i>

103 Alarm Snap-shot Status Commands

name	Type	Description
	- the ONT identifier Field type <Ng2::OntId> - the ONT identifier	

Only Show Details: alarm snap-shot status		
name	Type	Description
ont-cpu-util-tca	Parameter type: <Alarm::ONTTCACPUUTIL> (yes no) Possible values: - yes : ONT CPU utilization threshold crossed - no : ont works properly	ONT CPU utilization threshold crossed <i>This element is only shown in detail mode.</i>
ont-mem-util-tca	Parameter type: <Alarm::ONTTCAMEMUTIL> (yes no) Possible values: - yes : ONT memory utilization threshold crossed - no : ont works properly	ONT memory utilization threshold crossed <i>This element is only shown in detail mode.</i>

103.120 Alarm SnapShot ONT TC TCA Status Command

Command Description

This command displays the snapshot ONT TC TCA alarm status.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm snap-shot ont-tc-tca [ (index) ]
```

Command Parameters

Table 103.120-1 " Alarm SnapShot ONT TC TCA Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm snapshot table index

Command Output

Table 103.120-2 " Alarm SnapShot ONT TC TCA Status Command" Display parameters

Specific Information		
name	Type	Description
ont	Parameter type: <Gpon::OntIndex> (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> ng2 : <Ng2::ChannelGroup> / <Ng2::SubchannelGroup> / <Ng2::OntId>) Possible values: - ng2 : ngpon2 style identification Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Ng2::ChannelGroup>	identifies the ont entry <i>This element is only shown in detail mode.</i>

103 Alarm Snap-shot Status Commands

name	Type	Description
	- channel group number Field type <Ng2::SubchannelGroup> - subchannel group number Field type <Eqpt::OntId> - the ONT identifier Field type <Ng2::OntId> - the ONT identifier	

Only Show Details: alarm snap-shot status		
name	Type	Description
ont-tc-rx-los-frag-tc	Parameter type: <Alarm::ONTTCTCARLOSTFRAGS> (yes no) Possible values: - yes : rx loss of gem fragments threshold crossed - no : ont works properly	rx loss of gem fragments threshold crossed <i>This element is only shown in detail mode.</i>
ont-tc-tx-los-frag-tc	Parameter type: <Alarm::ONTTCTCATLOSTFRAGS> (yes no) Possible values: - yes : tx loss of gem fragments threshold crossed - no : ont works properly	tx loss of gem fragments threshold crossed <i>This element is only shown in detail mode.</i>
ont-tc-bad-gem-hd-tc	Parameter type: <Alarm::ONTTCTCABADGEMHDRS> (yes no) Possible values: - yes : bad gem header threshold crossed - no : ont works properly	bad gem header threshold crossed <i>This element is only shown in detail mode.</i>

103.121 Alarm SnapShot ONT L2 UNI Ethernet TCA Status Command

Command Description

This command displays the snapshot ONT L2 UNI Ethernet TCA alarm status.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm snap-shot ont-l2uni-eth-tca [ (index) ]
```

Command Parameters

Table 103.121-1 " Alarm SnapShot ONT L2 UNI Ethernet TCA Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm snapshot table index

Command Output

Table 103.121-2 " Alarm SnapShot ONT L2 UNI Ethernet TCA Status Command" Display parameters

Specific Information		
name	Type	Description
ont-port	Parameter type: <Gpon::IfIndexAlarmIndex2> (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Gpon::OntSlotId> / <Gpon::OntPortId> ng2 : <Ng2::ChannelGroup> / <Ng2::SubchannelGroup> / <Ng2::OntId> / <Gpon::OntSlotId> / <Gpon::OntPortId>) Possible values: - ng2 : ngpon2 style identification Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number	gpon ont port <i>This element is only shown in detail mode.</i>

103 Alarm Snap-shot Status Commands

name	Type	Description
	Field type <Eqpt::PonId> - the PON identifier Field type <Ng2::ChannelGroup> - channel group number Field type <Ng2::SubchannelGroup> - subchannel group number Field type <Eqpt::OntId> - the ONT identifier Field type <Ng2::OntId> - the ONT identifier Field type <Gpon::OntSlotId> - Gpon Ont Slot - range: [1...14] Field type <Gpon::OntPortId> - Gpon Ont Port - range: [1...16]	

Only Show Details: alarm snap-shot status		
name	Type	Description
ont-uni-ds-drpdr-fr-tc	Parameter type: <Alarm::ONTL2UNIETHTCADSDRPDFRMS> (yes no) Possible values: - yes : downstream l2 dropped frames threshold crossed - no : ont works properly	downstream l2 dropped frames threshold crossed <i>This element is only shown in detail mode.</i>
ont-uni-up-drpdr-fr-tc	Parameter type: <Alarm::ONTL2UNIETHTCASDRPDFRMS> (yes no) Possible values: - yes : upstream l2 dropped frames threshold crossed - no : ont works properly	upstream l2 dropped frames threshold crossed <i>This element is only shown in detail mode.</i>
ont-uni-ds-crc-fr-tc	Parameter type: <Alarm::ONTL2UNIDSCRCRPDFRMS> (yes no) Possible values: - yes : downstream l2 rx crc error frames threshold crossed - no : ont works properly	downstream l2 rx crc error frames threshold crossed <i>This element is only shown in detail mode.</i>
ont-uni-up-crc-fr-tc	Parameter type: <Alarm::ONTL2UNIUPCRCRPDFRMS> (yes no) Possible values: - yes : upstream l2 rx crc error frames threshold crossed - no : ont works properly	upstream l2 rx crc error frames threshold crossed <i>This element is only shown in detail mode.</i>

103.122 Alarm SnapShot OLT PON TC TCA Status Command

Command Description

This command displays the snapshot OLT PON TC TCA alarm status.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm snap-shot olt-pon-tc-tca [ (index) ]
```

Command Parameters

Table 103.122-1 " Alarm SnapShot OLT PON TC TCA Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm snapshot table index

Command Output

Table 103.122-2 " Alarm SnapShot OLT PON TC TCA Status Command" Display parameters

Specific Information		
name	Type	Description
pon	Parameter type: <Gpon::PonId> (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> x-pon : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::XPonId> 25g-pon : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::M25GPonId>) Possible values: - 25g-pon : 25g pon - x-pon : Xgs pon Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number	pon ifindex <i>This element is only shown in detail mode.</i>

103 Alarm Snap-shot Status Commands

name	Type	Description
	Field type <Eqpt::PonId> - the PON identifier Field type <Eqpt::XPonId> - the XGS PON identifier Field type <Eqpt::M25GPonId> - the 25G PON identifier	

Only Show Details: alarm snap-shot status		
name	Type	Description
olt-pon-tc-err-frag-tc	Parameter type: <Alarm::OLTPONTCTCAERRFRAGSPON> (yes no) Possible values: - yes : pon errored fragments threshold crossed - no : olt works properly	pon errored fragments threshold crossed <i>This element is only shown in detail mode.</i>
olt-pon-up-bw-tca	Parameter type: <Alarm::OLTPONTCTCAUPBWTCA> (yes no) Possible values: - yes : olt pon upstream bandwidth tca - no : olt works properly	OLT PON upstream bandwidth TCA <i>This element is only shown in detail mode.</i>
olt-pon-down-bw-tca	Parameter type: <Alarm::OLTPONTCTCADWBWTCA> (yes no) Possible values: - yes : olt pon downstream bandwidth tca - no : olt works properly	OLT PON downstream bandwidth TCA <i>This element is only shown in detail mode.</i>

103.123 Alarm SnapShot OLT PON Utilization TCA Status Command

Command Description

This command displays the snapshot OLT PON utilization TCA alarm status.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

> show alarm snap-shot olt-pon-util-tca [(index)]

Command Parameters

Table 103.123-1 "Alarm SnapShot OLT PON Utilization TCA Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm snapshot table index

Command Output

Table 103.123-2 "Alarm SnapShot OLT PON Utilization TCA Status Command" Display parameters

Specific Information		
name	Type	Description
pon	Parameter type: <Gpon::PonId> (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> x-pon : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::XPonId> 25g-pon : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::M25GPonId>) Possible values: - 25g-pon : 25g pon - x-pon : Xgs pon Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number	pon ifindex <i>This element is only shown in detail mode.</i>

103 Alarm Snap-shot Status Commands

name	Type	Description
	Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Eqpt::XPonId> - the XGS PON identifier Field type <Eqpt::M25GPonId> - the 25G PON identifier	

Only Show Details: alarm snap-shot status		
name	Type	Description
pon-t-txmcutilhi	Parameter type: <Alarm::TXMCUTILHI> (yes no) Possible values: - yes : tx mcast utilization high tca - no : olt works properly	pon utilization tx (downstream) multicast high threshold crossed <i>This element is only shown in detail mode.</i>
pon-t-txmcutilmd	Parameter type: <Alarm::TXMCUTILMD> (yes no) Possible values: - yes : tx mcast utilization medium tca - no : olt works properly	pon utilization tx (downstream) multicast medium threshold crossed <i>This element is only shown in detail mode.</i>
pon-t-txmcutillo	Parameter type: <Alarm::TXMCUTILLO> (yes no) Possible values: - yes : tx mcast utilization low tca - no : olt works properly	pon utilization tx (downstream) multicast low threshold crossed <i>This element is only shown in detail mode.</i>
pon-t-txtotutilhi	Parameter type: <Alarm::TXTOTUTILHI> (yes no) Possible values: - yes : tx total utilization high tca - no : olt works properly	pon utilization tx (downstream) total high threshold crossed <i>This element is only shown in detail mode.</i>
pon-t-txtotutilmd	Parameter type: <Alarm::TXTOTUTILMD> (yes no) Possible values: - yes : tx total utilization medium tca - no : olt works properly	pon utilization tx (downstream) total medium threshold crossed <i>This element is only shown in detail mode.</i>
pon-t-txtotutillo	Parameter type: <Alarm::TXTOTUTILLO> (yes no) Possible values: - yes : tx total utilization low tca - no : olt works properly	pon utilization tx (downstream) total low threshold crossed <i>This element is only shown in detail mode.</i>
pon-t-rxtotutilhi	Parameter type: <Alarm::RXTOTUTILHI> (yes no) Possible values: - yes : rx total utilization high tca - no : olt works properly	pon utilization rx (upstream) total high threshold crossed <i>This element is only shown in detail mode.</i>
pon-t-rxtotutilmd	Parameter type: <Alarm::RXTOTUTILMD> (yes no) Possible values: - yes : rx total utilization medium tca	pon utilization rx (upstream) total medium threshold crossed <i>This element is only shown in detail mode.</i>

name	Type	Description
	- no : olt works properly	
pon-t-rxtotutillo	Parameter type: <Alarm::RXTOTUTILLO> (yes no) Possible values: - yes : rx total utilization low tca - no : olt works properly	pon utilization rx (upstream) total low threshold crossed <i>This element is only shown in detail mode.</i>
pon-t-dbacongperiodhi	Parameter type: <Alarm::DBACONGPERIODHI> (yes no) Possible values: - yes : rx dba congestion period high tca - no : olt works properly	pon utilization rx (upstream) dbacongperiod high threshold crossed <i>This element is only shown in detail mode.</i>
pon-t-dbacongperiodmd	Parameter type: <Alarm::DBACONGPERIODMD> (yes no) Possible values: - yes : rx dba congestion period medium tca - no : olt works properly	pon utilization rx (upstream) dbacongperiod medium threshold crossed <i>This element is only shown in detail mode.</i>
pon-t-dbacongperiodlo	Parameter type: <Alarm::DBACONGPERIODLO> (yes no) Possible values: - yes : rx dba congestion period low tca - no : olt works properly	pon utilization rx (upstream) dbacongperiod low threshold crossed <i>This element is only shown in detail mode.</i>
pon-t-txucdropfrmhi	Parameter type: <Alarm::TXUCDROPFRMHI> (yes no) Possible values: - yes : tx unicast dropped packet high tca - no : olt works properly	pon utilization tx (downstream) unicast drop frame high threshold crossed <i>This element is only shown in detail mode.</i>
pon-t-txucdropfrmmd	Parameter type: <Alarm::TXUCDROPFRMMD> (yes no) Possible values: - yes : tx unicast dropped packet medium tca - no : olt works properly	pon utilization tx (downstream) unicast drop frame medium threshold crossed <i>This element is only shown in detail mode.</i>
pon-t-txucdropfrmlo	Parameter type: <Alarm::TXUCDROPFRMLO> (yes no) Possible values: - yes : tx unicast dropped packet low tca - no : olt works properly	pon utilization tx (downstream) unicast drop frame low threshold crossed <i>This element is only shown in detail mode.</i>
pon-t-txmcdropfrmhi	Parameter type: <Alarm::TXMCDROPFRMHI> (yes no) Possible values: - yes : tx multicast dropped packet high tca - no : olt works properly	pon utilization tx (downstream) multicast drop frame high threshold crossed <i>This element is only shown in detail mode.</i>
pon-t-txmcdropfrmmd	Parameter type: <Alarm::TXMCDROPFRMMD> (yes no) Possible values: - yes : tx multicast dropped packet medium tca - no : olt works properly	pon utilization tx (downstream) multicast drop frame medium threshold crossed <i>This element is only shown in detail mode.</i>
pon-t-txmcdropfrmlo	Parameter type: <Alarm::TXMCDROPFRMLO> (yes	pon utilization tx (downstream) multicast drop frame low

103 Alarm Snap-shot Status Commands

name	Type	Description
	no) Possible values: - yes : tx multicast dropped packet low tca - no : olt works properly	threshold crossed <i>This element is only shown in detail mode.</i>
pon-t-txbcdropfrmhi	Parameter type: <Alarm::TXBCDROPPFRMHI> (yes no) Possible values: - yes : tx broadcast dropped packet high tca - no : olt works properly	pon utilization tx (downstream) broadcast drop frame high threshold crossed <i>This element is only shown in detail mode.</i>
pon-t-txbcdropfrmmd	Parameter type: <Alarm::TXBCDROPPFRMMD> (yes no) Possible values: - yes : tx broadcast dropped packet medium tca - no : olt works properly	pon utilization tx (downstream) broadcast drop frame medium threshold crossed <i>This element is only shown in detail mode.</i>
pon-t-txbcdropfrmlo	Parameter type: <Alarm::TXBCDROPPFRMLO> (yes no) Possible values: - yes : tx broadcast dropped packet low tca - no : olt works properly	pon utilization tx (downstream) broadcast drop frame low threshold crossed <i>This element is only shown in detail mode.</i>
pon-t-rxtotdropfrmhi	Parameter type: <Alarm::RXTOTDROPPFRMHI> (yes no) Possible values: - yes : rx total dropped packet high tca - no : olt works properly	pon utilization rx (upstream) total drop frame high threshold crossed <i>This element is only shown in detail mode.</i>
pon-t-rxtotdropfrmmd	Parameter type: <Alarm::RXTOTDROPPFRMMD> (yes no) Possible values: - yes : rx total dropped packet medium tca - no : olt works properly	pon utilization rx (upstream) total drop frame medium threshold crossed <i>This element is only shown in detail mode.</i>
pon-t-rxtotdropfrmlo	Parameter type: <Alarm::RXTOTDROPPFRMLO> (yes no) Possible values: - yes : rx total dropped packet low tca - no : olt works properly	pon utilization rx (upstream) total drop frame low threshold crossed <i>This element is only shown in detail mode.</i>

103.124 Alarm SnapShot OLT Channel Pair Utilization TCA Status Command

Command Description

This command displays the snapshot channel-pair utilization TCA alarm status.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm snap-shot olt-chpr-util-tca [ (index) ]
```

Command Parameters

Table 103.124-1 "Alarm SnapShot OLT Channel Pair Utilization TCA Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm snapshot table index

Command Output

Table 103.124-2 "Alarm SnapShot OLT Channel Pair Utilization TCA Status Command" Display parameters

Specific Information		
name	Type	Description
channel-pair	Parameter type: <Gpon::ChannelPairId> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::ChannelPairId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::ChannelPairId> - the channel pair identifier	channel-pair ifindex <i>This element is only shown in detail mode.</i>
Only Show Details: alarm snap-shot status		
name	Type	Description
chpr-t-txmcutilhi	Parameter type: <Alarm::TXMCUTILHI>	channel-pair utilization tx

103 Alarm Snap-shot Status Commands

name	Type	Description
	(yes no) Possible values: - yes : tx mcast utilization high tca - no : olt works properly	(downstream) multicast high threshold crossed <i>This element is only shown in detail mode.</i>
chpr-t-txmcutilmd	Parameter type: <Alarm::TXMCUTILMD> (yes no) Possible values: - yes : tx mcast utilization medium tca - no : olt works properly	channel-pair utilization tx (downstream) multicast medium threshold crossed <i>This element is only shown in detail mode.</i>
chpr-t-txmcutillo	Parameter type: <Alarm::TXMCUTILLO> (yes no) Possible values: - yes : tx mcast utilization low tca - no : olt works properly	channel-pair utilization tx (downstream) multicast low threshold crossed <i>This element is only shown in detail mode.</i>
chpr-t-txtotutilhi	Parameter type: <Alarm::TXTOTUTILHI> (yes no) Possible values: - yes : tx total utilization high tca - no : olt works properly	channel-pair utilization tx (downstream) total high threshold crossed <i>This element is only shown in detail mode.</i>
otutilmd	Parameter type: <Alarm::TXTOTUTILMD> (yes no) Possible values: - yes : tx total utilization medium tca - no : olt works properly	channel-pair utilization tx (downstream) total medium threshold crossed <i>This element is only shown in detail mode.</i>
chpr-t-txtotutillo	Parameter type: <Alarm::TXTOTUTILLO> (yes no) Possible values: - yes : tx total utilization low tca - no : olt works properly	channel-pair utilization tx (downstream) total low threshold crossed <i>This element is only shown in detail mode.</i>
chpr-t-rxtotutilhi	Parameter type: <Alarm::RXTOTUTILHI> (yes no) Possible values: - yes : rx total utilization high tca - no : olt works properly	channel-pair utilization rx (upstream) total high threshold crossed <i>This element is only shown in detail mode.</i>
chpr-t-rxtotutilmd	Parameter type: <Alarm::RXTOTUTILMD> (yes no) Possible values: - yes : rx total utilization medium tca - no : olt works properly	channel-pair utilization rx (upstream) total medium threshold crossed <i>This element is only shown in detail mode.</i>
chpr-t-rxtotutillo	Parameter type: <Alarm::RXTOTUTILLO> (yes no) Possible values: - yes : rx total utilization low tca - no : olt works properly	channel-pair utilization rx (upstream) total low threshold crossed <i>This element is only shown in detail mode.</i>
chpr-t-dbacongperiodhi	Parameter type: <Alarm::DBACONGPERIODHI> (yes no) Possible values:	channel-pair utilization rx (upstream) dbacongperiod high threshold crossed <i>This element is only shown in</i>

name	Type	Description
	- yes : rx dba congestion period high tca - no : olt works properly	<i>detail mode.</i>
chpr-t-dbacongperiodmd	Parameter type: <Alarm::DBACONGPERIODMD> (yes no) Possible values: - yes : rx dba congestion period medium tca - no : olt works properly	channel-pair utilization rx (upstream) dbacongperiod medium threshold crossed <i>This element is only shown in detail mode.</i>
chpr-t-dbacongperiodlo	Parameter type: <Alarm::DBACONGPERIODLO> (yes no) Possible values: - yes : rx dba congestion period low tca - no : olt works properly	channel-pair utilization rx (upstream) dbacongperiod low threshold crossed <i>This element is only shown in detail mode.</i>
chpr-t-txucdropfrmhi	Parameter type: <Alarm::TXUCDROPFRMHI> (yes no) Possible values: - yes : tx unicast dropped packet high tca - no : olt works properly	channel-pair utilization tx (downstream) unicast drop frame high threshold crossed <i>This element is only shown in detail mode.</i>
chpr-t-txucdropfrmmd	Parameter type: <Alarm::TXUCDROPFRMMD> (yes no) Possible values: - yes : tx unicast dropped packet medium tca - no : olt works properly	channel-pair utilization tx (downstream) unicast drop frame medium threshold crossed <i>This element is only shown in detail mode.</i>
chpr-t-txucdropfrmlo	Parameter type: <Alarm::TXUCDROPFRMLO> (yes no) Possible values: - yes : tx unicast dropped packet low tca - no : olt works properly	channel-pair utilization tx (downstream) unicast drop frame low threshold crossed <i>This element is only shown in detail mode.</i>
chpr-t-txmcdropfrmhi	Parameter type: <Alarm::TXMCDROPFRMHI> (yes no) Possible values: - yes : tx multicast dropped packet high tca - no : olt works properly	channel-pair utilization tx (downstream) multicast drop frame high threshold crossed <i>This element is only shown in detail mode.</i>
chpr-t-txmcdropfrmmd	Parameter type: <Alarm::TXMCDROPFRMMD> (yes no) Possible values: - yes : tx multicast dropped packet medium tca - no : olt works properly	channel-pair utilization tx (downstream) multicast drop frame medium threshold crossed <i>This element is only shown in detail mode.</i>
chpr-t-txmcdropfrmlo	Parameter type: <Alarm::TXMCDROPFRMLO> (yes no) Possible values: - yes : tx multicast dropped packet low tca - no : olt works properly	channel-pair utilization tx (downstream) multicast drop frame low threshold crossed <i>This element is only shown in detail mode.</i>
chpr-t-txbcdropfrmhi	Parameter type: <Alarm::TXBCDROPFRMHI> (yes no) Possible values: - yes : tx broadcast dropped packet high tca - no : olt works properly	channel-pair utilization tx (downstream) broadcast drop frame high threshold crossed <i>This element is only shown in detail mode.</i>
chprt-txbcdropfrmmd	Parameter type: <Alarm::TXBCDROPFRMMD>	channel-pair utilization tx

103 Alarm Snap-shot Status Commands

name	Type	Description
	(yes no) Possible values: - yes : tx broadcast dropped packet medium tca - no : olt works properly	(downstream) broadcast drop frame medium threshold crossed <i>This element is only shown in detail mode.</i>
chpr-t-txbcdropfrmlo	Parameter type: <Alarm::TXBCDROPPFRMLO> (yes no) Possible values: - yes : tx broadcast dropped packet low tca - no : olt works properly	channel-pair utilization tx (downstream) broadcast drop frame low threshold crossed <i>This element is only shown in detail mode.</i>
chpr-t-rxtotdropfrmhi	Parameter type: <Alarm::RXTOTDROPPFRMHI> (yes no) Possible values: - yes : rx total dropped packet high tca - no : olt works properly	channel-pair utilization rx (upstream) total drop frame high threshold crossed <i>This element is only shown in detail mode.</i>
chpr-t-rxtotdropfrmmd	Parameter type: <Alarm::RXTOTDROPPFRMMD> (yes no) Possible values: - yes : rx total dropped packet medium tca - no : olt works properly	channel-pair utilization rx (upstream) total drop frame medium threshold crossed <i>This element is only shown in detail mode.</i>
chpr-t-rxtotdropfrmlo	Parameter type: <Alarm::RXTOTDROPPFRMLO> (yes no) Possible values: - yes : rx total dropped packet low tca - no : olt works properly	channel-pair utilization rx (upstream) total drop frame low threshold crossed <i>This element is only shown in detail mode.</i>

103.125 Alarm SnapShot OLT ONT TC TCA Status Command

Command Description

This command displays the snapshot OLT ONT TC TCA alarm status.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

> show alarm snap-shot olt-ont-tc-tca [(index)]

Command Parameters

Table 103.125-1 " Alarm SnapShot OLT ONT TC TCA Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm snapshot table index

Command Output

Table 103.125-2 " Alarm SnapShot OLT ONT TC TCA Status Command" Display parameters

Specific Information		
name	Type	Description
ont	Parameter type: <Gpon::OntIndex> (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> ng2 : <Ng2::ChannelGroup> / <Ng2::SubchannelGroup> / <Ng2::OntId>) Possible values: - ng2 : ngpon2 style identification Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Ng2::ChannelGroup>	identifies the ont entry <i>This element is only shown in detail mode.</i>

103 Alarm Snap-shot Status Commands

name	Type	Description
	- channel group number Field type <Ng2::SubchannelGroup> - subchannel group number Field type <Eqpt::OntId> - the ONT identifier Field type <Ng2::OntId> - the ONT identifier	

Only Show Details: alarm snap-shot status		
name	Type	Description
olt-ont-tc-err-frag-tc	Parameter <Alarm::OLTONTTCTCAERRFRAGSONT> (yes no) Possible values: - yes : ont errored fragments threshold crossed - no : olt works properly	type: ont errored fragments threshold crossed <i>This element is only shown in detail mode.</i>

103.126 Alarm SnapShot ONT POTS SUPPLEMENTAL Status Command

Command Description

This command displays the snapshot ONT POTS SUPPLEMENTAL alarm status.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm snap-shot ont-pots-supplemental [ (index) ]
```

Command Parameters

Table 103.126-1 " Alarm SnapShot ONT POTS SUPPLEMENTAL Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm snapshot table index

Command Output

Table 103.126-2 " Alarm SnapShot ONT POTS SUPPLEMENTAL Status Command" Display parameters

Specific Information		
name	Type	Description
ont-port	Parameter type: <Gpon::IfIndexAlarmIndex2> (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Gpon::OntSlotId> / <Gpon::OntPortId> ng2 : <Ng2::ChannelGroup> / <Ng2::SubchannelGroup> / <Ng2::OntId> / <Gpon::OntSlotId> / <Gpon::OntPortId>) Possible values: - ng2 : ngpon2 style identification Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number	gpon ont port <i>This element is only shown in detail mode.</i>

103 Alarm Snap-shot Status Commands

name	Type	Description
	Field type <Eqpt::PonId> - the PON identifier Field type <Ng2::ChannelGroup> - channel group number Field type <Ng2::SubchannelGroup> - subchannel group number Field type <Eqpt::OntId> - the ONT identifier Field type <Ng2::OntId> - the ONT identifier Field type <Gpon::OntSlotId> - Gpon Ont Slot - range: [1...14] Field type <Gpon::OntPortId> - Gpon Ont Port - range: [1...16]	

Only Show Details: alarm snap-shot status		
name	Type	Description
ont-sip-reg-dns	Parameter type: <Alarm::ONTSERVICESPOTSSIPREGDNS> (yes no) Possible values: - yes : sip registration failed because the domain name could not be resolved - no : sip registration succeeds	ont services pots sip registration failed (resolving domain name) <i>This element is only shown in detail mode.</i>
ont-sip-reg-fail	Parameter type: <Alarm::ONTSERVICESPOTSSIPREGAUTH> (yes no) Possible values: - yes : sip registration failed because authentication failed - no : sip registration succeeds	ont services pots sip registration authentication failed <i>This element is only shown in detail mode.</i>
ont-sip-reg-timeout	Parameter type: <Alarm::ONTSERVICESPOTSSIPREGTO> (yes no) Possible values: - yes : sip registration failed because all attempted retransmissions timed out - no : sip registration succeeds	ont services pots sip registration timeout <i>This element is only shown in detail mode.</i>
ont-sip-reg-err-resps	Parameter type: <Alarm::ONTSERVICESPOTSSIPREGERR> (yes no) Possible values: - yes : sip registration failed because error response from the registration server - no : sip registration succeeds	ont services pots sip registration response error <i>This element is only shown in detail mode.</i>
ont-sip-inv-dns	Parameter type: <Alarm::ONTSERVICESPOTSSIPINVDNS> (yes no) Possible values: - yes : sip invite failed because the domain name could not be resolved - no : sip invite succeeds	ont services pots sip invite failed (resolving domain name) <i>This element is only shown in detail mode.</i>

name	Type	Description
ont-sip-inv-auth	Parameter type: <Alarm::ONTSERVICESPOTSSIPINVAUTH> (yes no) Possible values: - yes : sip invite failed because authentication failed - no : sip invite succeeds	ont services pots sip invite authentication failed <i>This element is only shown in detail mode.</i>
ont-sip-inv-timeout	Parameter type: <Alarm::ONTSERVICESPOTSSIPINVTO> (yes no) Possible values: - yes : sip invite failed because all attempted retransmissions timed out - no : sip invite succeeds	ont services pots sip invite timeout <i>This element is only shown in detail mode.</i>
ont-sip-inv-err	Parameter type: <Alarm::ONTSERVICESPOTSSIPINVERR> (yes no) Possible values: - yes : sip invite failed because error response from the registration server - no : sip invite succeeds	ont services pots sip invite response error <i>This element is only shown in detail mode.</i>
ont-svc-pots-subs-refr	Parameter type: <Alarm::ONTSERVICESPOTSSUBSREFR> (yes no) Possible values: - yes : pots iconfig subscription could not be refreshed - no : pots iconfig subscription refreshed	ont services pots iconfig subscription could not be refreshed <i>This element is only shown in detail mode.</i>
ont-svc-pots-not-refr	Parameter type: <Alarm::ONTSERVICESPOTSNOTREFR> (yes no) Possible values: - yes : pots iconfig notify response for refresh subscribe failed - no : pots iconfig notify response for refresh subscribe succeeds	ont services pots iconfig notification could not be refreshed <i>This element is only shown in detail mode.</i>
ont-svc-pots-icfg-err	Parameter type: <Alarm::ONTSERVICESPOTSICFGERR> (yes no) Possible values: - yes : pots service failed due to an unmapped iconfig error - no : pots service works properly	ont services pots service failed due to an unmapped iconfig error <i>This element is only shown in detail mode.</i>

103.127 Alarm SnapShot ONT VEIP Status Command

Command Description

This command displays the snapshot ONT VEIP alarm status.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

> show alarm snap-shot ont-veip [(index)]

Command Parameters

Table 103.127-1 " Alarm SnapShot ONT VEIP Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm snapshot table index

Command Output

Table 103.127-2 " Alarm SnapShot ONT VEIP Status Command" Display parameters

Specific Information		
name	Type	Description
ont-port	Parameter type: <Gpon::IfIndexAlarmIndex2> (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Gpon::OntSlotId> / <Gpon::OntPortId> ng2 : <Ng2::ChannelGroup> / <Ng2::SubchannelGroup> / <Ng2::OntId> / <Gpon::OntSlotId> / <Gpon::OntPortId>) Possible values: - ng2 : ngpon2 style identification Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier	gpon ont port <i>This element is only shown in detail mode.</i>

name	Type	Description
	Field type <Ng2::ChannelGroup> - channel group number Field type <Ng2::SubchannelGroup> - subchannel group number Field type <Eqpt::OntId> - the ONT identifier Field type <Ng2::OntId> - the ONT identifier Field type <Gpon::OntSlotId> - Gpon Ont Slot - range: [1...14] Field type <Gpon::OntPortId> - Gpon Ont Port - range: [1...16]	

Only Show Details: alarm snap-shot status		
name	Type	Description
ont-veip-mismatch	Parameter type: <Alarm::ONTVEIPMISMATCH> (yes no) Possible values: - yes : ont veip mismatch - no : ont veip match	ont veip mismatch <i>This element is only shown in detail mode.</i>

103.128 Alarm SnapShot ONT IP HOST Status Command

Command Description

This command displays the snapshot ONT IP HOST alarm status.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm snap-shot ont-iphost [ (index) ]
```

Command Parameters

Table 103.128-1 " Alarm SnapShot ONT IP HOST Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm snapshot table index

Command Output

Table 103.128-2 " Alarm SnapShot ONT IP HOST Status Command" Display parameters

Specific Information		
name	Type	Description
port	Parameter type: <Gpon::IpHostCommonIndex> (ont : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Gpon::IpHostId> vlanport : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / vuni : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlanport : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / vuni : <Eqpt::UnstackedVlan> ont.ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / <Ng2::IpHostId> vlanport.ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / vuni : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlanport.ng2 : <Eqpt::ChannelGroupId> /	gpon iphost port <i>This element is only shown in detail mode.</i>

name	Type	Description
	<Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / vuni : <Eqpt::UnstackedVlan>) Possible values: - ont:ng2 : ngpon2 ont - vlanport:ng2 : ngpon2 vlanport - ont : ont - vlanport : vlanport Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Eqpt::OntId> - the ONT identifier Field type <Eqpt::ChannelGroupId> - the channel group identifier Field type <Eqpt::SubChannelGroupId> - the subchannel group identifier Field type <Eqpt::Ng2OntId> - the NG2 ONT identifier Possible values: - vuni : virtual uni identifier Possible values: - vuni : virtual NGPON2 uni identifier Field type <Gpon::IpHostID> - iphost id Field type <Ng2::IpHostID> - iphost id (ngpon2) Possible values: - stacked : stacked vlan identity Field type <Eqpt::UnstackedVlan> - unstacked vlan id Field type <Eqpt::SVlan> - service vlan id Field type <Eqpt::CVlan> - customer vlan id	

Only Show Details: alarm snap-shot status		
name	Type	Description
ont-ip-host-mismatch	Parameter type: <Alarm::ONTIPHOS TMIS> (yes no) Possible values: - yes : ont ip host mismatch - no : ont ip host match	ont ip host mismatch <i>This element is only shown in detail mode.</i>
ont-ip-host-ip-alloc	Parameter type: <Alarm::ONTIPHOS TFAIL> (yes no) Possible values: - yes : ont ip host IP allocation failure - no : ont ip host IP allocation works properly	ont ip host IP allocation failure <i>This element is only shown in detail mode.</i>

103.129 Alarm Table Snapshot Status Command

Command Description

This command displays the alarm-table snapshot-related alarms.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

> show alarm snap-shot alarm-table [(index)]

Command Parameters

Table 103.129-1 "Alarm Table Snapshot Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm snap shot table index

Command Output

Table 103.129-2 "Alarm Table Snapshot Status Command" Display parameters

Specific Information		
name	Type	Description
last-updated-on	Parameter type: <Sys::timeInSecs> - the time (yyyy-mm-dd:hour:minutes:secs) - unit: UTC	network time in seconds when the alarm was logged. <i>This element is only shown in detail mode.</i>
alarm-tbl-overflow	Parameter type: <Alarm::AlrmTblOflow> (overflow no-overflow) Possible values: - overflow : alarm table overflow - no-overflow : no alarm table overflow	identify if the alarm table has overflowed <i>This element is only shown in detail mode.</i>

103.130 Alarm SnapShot ONT VIDEO Status Command

Command Description

This command displays the snapshot ONT VIDEO alarm status.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

> show alarm snap-shot ont-video [(index)]

Command Parameters

Table 103.130-1 " Alarm SnapShot ONT VIDEO Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm snapshot table index

Command Output

Table 103.130-2 " Alarm SnapShot ONT VIDEO Status Command" Display parameters

Specific Information		
name	Type	Description
video-port	Parameter type: <Gpon::IfIndexAlarmIndex2> (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Gpon::OntSlotId> / <Gpon::OntPortId> ng2 : <Ng2::ChannelGroup> / <Ng2::SubchannelGroup> / <Ng2::OntId> / <Gpon::OntSlotId> / <Gpon::OntPortId>) Possible values: - ng2 : ngpon2 style identification Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier	video port <i>This element is only shown in detail mode.</i>

103 Alarm Snap-shot Status Commands

name	Type	Description
	Field type <Ng2::ChannelGroup> - channel group number Field type <Ng2::SubchannelGroup> - subchannel group number Field type <Eqpt::OntId> - the ONT identifier Field type <Ng2::OntId> - the ONT identifier Field type <Gpon::OntSlotId> - Gpon Ont Slot - range: [1...14] Field type <Gpon::OntPortId> - Gpon Ont Port - range: [1...16]	
Only Show Details: alarm snap-shot status		
name	Type	Description
ont-svc-video-conf-mis	Parameter type: <Alarm::ONTVIDEOUNISVCMIS> (yes no) Possible values: - yes : config request failure for video service - no : ont service is ok	config request failure for video service <i>This element is only shown in detail mode.</i>
ont-svc-video-pw-high	Parameter type: <Alarm::ONTRFOUTHIGH> (yes no) Possible values: - yes : high power level for rf video signal - no : ont service is ok	high power level for rf video signal <i>This element is only shown in detail mode.</i>
ont-svc-video-pw-low	Parameter type: <Alarm::ONTRFOUTLOW> (yes no) Possible values: - yes : low power level for rf video signal - no : ont service is ok	low power level for rf video signal <i>This element is only shown in detail mode.</i>

103.131 Alarm SnapShot ONT CES Status Command

Command Description

This command displays the snapshot ONT CES alarm status.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm snap-shot ont-ces [ (index) ]
```

Command Parameters

Table 103.131-1 " Alarm SnapShot ONT CES Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm snapshot table index

Command Output

Table 103.131-2 " Alarm SnapShot ONT CES Status Command" Display parameters

Specific Information		
name	Type	Description
cesds1-port	Parameter type: <Gpon::IfIndexAlarmIndex2> (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Gpon::OntSlotId> / <Gpon::OntPortId> ng2 : <Ng2::ChannelGroup> / <Ng2::SubchannelGroup> / <Ng2::OntId> / <Gpon::OntSlotId> / <Gpon::OntPortId>) Possible values: - ng2 : ngpon2 style identification Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier	ces port <i>This element is only shown in detail mode.</i>

103 Alarm Snap-shot Status Commands

name	Type	Description
	Field type <Ng2::ChannelGroup> - channel group number Field type <Ng2::SubchannelGroup> - subchannel group number Field type <Eqpt::OntId> - the ONT identifier Field type <Ng2::OntId> - the ONT identifier Field type <Gpon::OntSlotId> - Gpon Ont Slot - range: [1...14] Field type <Gpon::OntPortId> - Gpon Ont Port - range: [1...16]	

Only Show Details: alarm snap-shot status		
name	Type	Description
ont-svc-ces-ds1-mis	Parameter type: <Alarm::ONTCESDS1SVCNIS> (yes no) Possible values: - yes : ont service mismatch for provisioned ces ds1 - no : ont service is ok	ont service mismatch for provisioned ces ds1 <i>This element is only shown in detail mode.</i>
ont-svc-ces-ds1-los	Parameter type: <Alarm::ONTCESDS1LOS> (yes no) Possible values: - yes : loss of signal at ds1 interface - no : ont service is ok	loss of signal at ds1 interface <i>This element is only shown in detail mode.</i>
ont-svc-ces-ds1-lof	Parameter type: <Alarm::ONTCESDS1LOF> (yes no) Possible values: - yes : loss of frame at ds1 interface - no : ont service is ok	loss of frame at ds1 interface <i>This element is only shown in detail mode.</i>
ont-svc-ces-ds1-rair	Parameter type: <Alarm::ONTCESDS1RAIR> (yes no) Possible values: - yes : receiving rai at ds1 interface - no : ont service is ok	receiving rai at ds1 interface <i>This element is only shown in detail mode.</i>
ont-svc-ces-ds1-ais	Parameter type: <Alarm::ONTCESDS1AISR> (yes no) Possible values: - yes : receiving ais at ds1 interface - no : ont service is ok	receiving ais at ds1 interface <i>This element is only shown in detail mode.</i>
ont-svc-ces-ds1-lnlpbk	Parameter type: <Alarm::ONTCESDS1LNLBPBK> (yes no) Possible values: - yes : receiving line loopback at ds1 interface - no : ont service is ok	receiving line loopback at ds1 interface <i>This element is only shown in detail mode.</i>
ont-svc-ces-ds1-tmlpbk	Parameter type: <Alarm::ONTCESDS1TMLPBK> (yes no) Possible values: - yes : receiving terminal loopback at ds1 interface	receiving terminal loopback at ds1 interface <i>This element is only shown in detail mode.</i>

103 Alarm Snap-shot Status Commands

name	Type	Description
	- no : ont service is ok	

103.132 Alarm SnapShot ONT VOIP Status Command

Command Description

This command displays the snapshot ONT VOIP alarm status.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

> show alarm snap-shot ont-voip [(index)]

Command Parameters

Table 103.132-1 " Alarm SnapShot ONT VOIP Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm snapshot table index

Command Output

Table 103.132-2 " Alarm SnapShot ONT VOIP Status Command" Display parameters

Specific Information		
name	Type	Description
voip-uni	Parameter type: <Gpon::VoipOntIndex> (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / 1 ng2 : <Ng2::ChannelGroup> / <Ng2::SubchannelGroup> / <Ng2::OntId> / 1) Possible values: - ng2 : ngpon2 style identification Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Eqpt::OntId>	voip uni ifindex <i>This element is only shown in detail mode.</i>

name	Type	Description
	- the ONT identifier Possible values: - 1 : Gpon voip Port Field type <Ng2::ChannelGroup> - channel group number Field type <Ng2::SubchannelGroup> - subchannel group number Field type <Ng2::OntId> - the ONT identifier Possible values: - 1 : Gpon voip Port	
client-number	Parameter type: <Gpon::AlarmIndex2Integer> - a signed integer	service client number <i>This element is only shown in detail mode.</i>

Only Show Details: alarm snap-shot status		
name	Type	Description
ont-svc-voip-cnf-file	Parameter type: <Alarm::ONTVOICONFIGFLERR> (yes no) Possible values: - yes : voice configuration file error - no : ont service is ok	voice configuration file error <i>This element is only shown in detail mode.</i>
ont-svc-voip-svc-mis	Parameter type: <Alarm::ONTVOICLISERMIS> (yes no) Possible values: - yes : service mismatch for provisioned client service - no : ont service is ok	service mismatch for provisioned client service <i>This element is only shown in detail mode.</i>
ont-svc-voip-gw-comm	Parameter type: <Alarm::ONTVOIGATWCOMFAIL> (yes no) Possible values: - yes : voice gateway communication failure - no : ont service is ok	voice gateway communication failure <i>This element is only shown in detail mode.</i>
ont-svc-voip-dhcp-fail	Parameter type: <Alarm::ONTVOIDHCPSEFAIL> (yes no) Possible values: - yes : voice gateway communication failure - no : ont service is ok	voice dhcp server failure <i>This element is only shown in detail mode.</i>
ont-svc-voip-icnf-sub	Parameter type: <Alarm::ONTVOIICONSUBFAIL> (yes no) Possible values: - yes : voice iconfig subscription failure - no : ont service is ok	voice iconfig subscription failure <i>This element is only shown in detail mode.</i>
ont-svc-voip-icnf-ntfy	Parameter type: <Alarm::ONTVOIICONNOTFAIL> (yes no) Possible values: - yes : voice iconfig notify failure - no : ont service is ok	voice iconfig notify failure <i>This element is only shown in detail mode.</i>
ont-svc-voip-icnf-http	Parameter type: <Alarm::ONTVOIICONHTTPFAIL> (yes no) Possible values: - yes : voice iconfig http failure	voice iconfig http failure <i>This element is only shown in detail mode.</i>

103 Alarm Snap-shot Status Commands

name	Type	Description
	- no : ont service is ok	
ont-svc-voip-dhcp-to	Parameter type: <Alarm::ONTVOIDHCPTO> (yes no) Possible values: - yes : DHCP server retransmissions timed out - no : ont service is ok	DHCP server retransmissions timed out <i>This element is only shown in detail mode.</i>
ont-svc-voip-dhcp-mal	Parameter type: <Alarm::ONTVOIDHCPMAL> (yes no) Possible values: - yes : DHCP response was malformed - no : ont service is ok	DHCP response was malformed <i>This element is only shown in detail mode.</i>
ont-svc-voip-dhcp-noad	Parameter type: <Alarm::ONTVOIDHCPNOAD> (yes no) Possible values: - yes : DHCP server failed to issue the required parameters - no : ont service is ok	DHCP server failed to issue the required parameters <i>This element is only shown in detail mode.</i>
ont-svc-voip-dhcp-leas	Parameter type: <Alarm::ONTVOIDHCPLEAS> (yes no) Possible values: - yes : DHCP Server failure due to problem in lease renewal - no : ont service is ok	DHCP Server failure due to problem in lease renewal <i>This element is only shown in detail mode.</i>
ont-svc-voip-subscription-dns	Parameter type: <Alarm::ONTVOIICONDNS> (yes no) Possible values: - yes : iConfig Subscription failure due to DNS problem - no : ont service is ok	iConfig Subscription failure due to DNS problem <i>This element is only shown in detail mode.</i>
ont-svc-voip-subscription-tcp	Parameter type: <Alarm::ONTVOIICONTCP> (yes no) Possible values: - yes : iConfig Subscription failure due to TCP socket problem - no : ont service is ok	iConfig Subscription failure due to TCP socket problem <i>This element is only shown in detail mode.</i>
ont-svc-voip-subscription-tls	Parameter type: <Alarm::ONTVOIICONTLS> (yes no) Possible values: - yes : iConfig Subscription failure due to TLS session problem - no : ont service is ok	iConfig Subscription failure due to TLS session problem <i>This element is only shown in detail mode.</i>
ont-svc-voip-subscription-auth	Parameter type: <Alarm::ONTVOIICONAUTH> (yes no) Possible values: - yes : iConfig Subscription failure due to authentication error - no : ont service is ok	iConfig Subscription failure due to authentication error <i>This element is only shown in detail mode.</i>
ont-svc-voip-subscription-to	Parameter type: <Alarm::ONTVOIICONSUBSTO> (yes no) Possible values: - yes : iConfig Subscription failure due to retransmission timeout - no : ont service is ok	iConfig Subscription failure due to retransmission timeout <i>This element is only shown in detail mode.</i>

name	Type	Description
	timeout - no : ont service is ok	
ont-svc-voip-sub-err	Parameter type: <Alarm::ONTVOIICONSUBERR> (yes no) Possible values: - yes : iConfig Subscription failure due to response error - no : ont service is ok	iConfig Subscription failure due to response error <i>This element is only shown in detail mode.</i>
ont-svc-voip-not-to	Parameter type: <Alarm::ONTVOIICONNOTTO> (yes no) Possible values: - yes : iConfig Notify response timeout for new subscription - no : ont service is ok	iConfig Notify response is malformed <i>This element is only shown in detail mode.</i>
ont-svc-voip-notref-to	Parameter type: <Alarm::ONTVOIICONNOTREFTO> (yes no) Possible values: - yes : iConfig Notify response timeout for subscription refresh - no : ont service is ok	iConfig Notify response timeout for subscription refresh <i>This element is only shown in detail mode.</i>
ont-svc-voip-not-mal	Parameter type: <Alarm::ONTVOIICONNOTMAL> (yes no) Possible values: - yes : iConfig Notify response is malformed - no : ont service is ok	iConfig Notify response is malformed <i>This element is only shown in detail mode.</i>
ont-svc-voip-not-rej	Parameter type: <Alarm::ONTVOIICONNOTREJ> (yes no) Possible values: - yes : iConfig subscription request rejected by configuration server - no : ont service is ok	iConfig subscription request rejected by configuration server <i>This element is only shown in detail mode.</i>
ont-svc-voip-http-dns	Parameter type: <Alarm::ONTVOIHTTPDNS> (yes no) Possible values: - yes : VOIP client can't retrieve config doc due to DNS problem - no : ont service is ok	VOIP client can't retrieve config doc due to DNS problem <i>This element is only shown in detail mode.</i>
ont-svc-voip-http-tcp	Parameter type: <Alarm::ONTVOIHTTPTCP> (yes no) Possible values: - yes : VOIP client can't retrieve config doc due to TCP socket problem - no : ont service is ok	VOIP client can't retrieve config doc due to TCP socket problem <i>This element is only shown in detail mode.</i>
ont-svc-voip-http-tls	Parameter type: <Alarm::ONTVOIHTTPTLS> (yes no) Possible values: - yes : VOIP client can't retrieve config doc due to TLS session problem - no : ont service is ok	VOIP client can't retrieve config doc due to TLS session problem <i>This element is only shown in detail mode.</i>
ont-svc-voip-http-auth	Parameter type: <Alarm::ONTVOIHTTPAUTH> (yes	VOIP client can't retrieve config doc due to auth error

103 Alarm Snap-shot Status Commands

name	Type	Description
	no) Possible values: - yes : VOIP client can't retrieve config doc due to auth error - no : ont service is ok	<i>This element is only shown in detail mode.</i>
ont-svc-voip-http-to	Parameter type: <Alarm::ONTVOIHTTPTO> (yes no) Possible values: - yes : VOIP client can't retrieve config doc due to re-tx timeout - no : ont service is ok	VOIP client can't retrieve config doc due to re-tx timeout <i>This element is only shown in detail mode.</i>
ont-svc-voip-http-err	Parameter type: <Alarm::ONTVOIHTTPErr> (yes no) Possible values: - yes : VOIP client can't retrieve config doc due to response error - no : ont service is ok	VOIP client can't retrieve config doc due to response error <i>This element is only shown in detail mode.</i>
ont-svc-voip-http-mal	Parameter type: <Alarm::ONTVOIICONHTTPMAL> (yes no) Possible values: - yes : iConfig configuration document is malformed - no : ont service is ok	iConfig configuration document is malformed <i>This element is only shown in detail mode.</i>
ont-svc-voip-subscr-refer	Parameter type: <Alarm::ONTVOIICONSUBSREFER> (yes no) Possible values: - yes : iConfig Subscription refresh error - no : ont service is ok	iConfig Subscription refresh error <i>This element is only shown in detail mode.</i>
ont-svc-voip-not-refer	Parameter type: <Alarm::ONTVOIICONNOTREFER> (yes no) Possible values: - yes : iConfig Notify response for refresh subscribe failed - no : ont service is ok	iConfig Notify response for refresh subscribe failed <i>This element is only shown in detail mode.</i>
ont-svc-voip-icfg-err	Parameter type: <Alarm::ONTVOIICONERR> (yes no) Possible values: - yes : iConfig Configuration Error - no : ont service is ok	iConfig Configuration Error <i>This element is only shown in detail mode.</i>

103.133 Alarm SnapShot ONT VIDEO ANI Status Command

Command Description

This command displays the snapshot ONT VIDEO ANI alarm status.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

> show alarm snap-shot ont-video-ani [(index)]

Command Parameters

Table 103.133-1 " Alarm SnapShot ONT VIDEO ANI Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm snapshot table index

Command Output

Table 103.133-2 " Alarm SnapShot ONT VIDEO ANI Status Command" Display parameters

Specific Information		
name	Type	Description
ont	Parameter type: <Gpon::OntIndex> (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> ng2 : <Ng2::ChannelGroup> / <Ng2::SubchannelGroup> / <Ng2::OntId>) Possible values: - ng2 : ngpon2 style identification Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Ng2::ChannelGroup>	identifies the ont entry <i>This element is only shown in detail mode.</i>

103 Alarm Snap-shot Status Commands

name	Type	Description
	- channel group number Field type <Ng2::SubchannelGroup> - subchannel group number Field type <Eqpt::OntId> - the ONT identifier Field type <Ng2::OntId> - the ONT identifier	
vedio-ani-index	Parameter type: <Gpon::AlarmIndex2Integer> - a signed integer	vedio ani index <i>This element is only shown in detail mode.</i>

Only Show Details: alarm snap-shot status		
name	Type	Description
ont-svc-v-ani-conf-mis	Parameter type: <Alarm::ONTVIDEOANISVCMIS> (yes no) Possible values: - yes : config request failure for video ani service - no : ont service is ok	config request failure for video ani service <i>This element is only shown in detail mode.</i>
ont-svc-v-ani-loss-sig	Parameter type: <Alarm::ONTVIDEOLOS> (yes no) Possible values: - yes : video loss of signal on ani - no : ont service is ok	video loss of signal on ani <i>This element is only shown in detail mode.</i>
ont-svc-v-ani-lv-high	Parameter <Alarm::ONTVIDEOOPTSIGLEVELHIGH> (yes no) Possible values: - yes : high video optical signal level - no : ont service is ok	type: high video optical signal level <i>This element is only shown in detail mode.</i>
ont-svc-v-ani-lv-low	Parameter <Alarm::ONTVIDEOOPTSIGLEVELLOW> (yes no) Possible values: - yes : low video optical signal level - no : ont service is ok	type: low video optical signal level <i>This element is only shown in detail mode.</i>

103.134 Alarm SnapShot ONT PWE Status Command

Command Description

This command displays the snapshot ONT PWE alarm status.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm snap-shot ont-pwe [ (index) ]
```

Command Parameters

Table 103.134-1 " Alarm SnapShot ONT PWE Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm snapshot table index

Command Output

Table 103.134-2 " Alarm SnapShot ONT PWE Status Command" Display parameters

Specific Information		
name	Type	Description
ont-ces-uni	Parameter type: <Ces::InterfaceIndex> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> / <Eqpt::OntPortId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Eqpt::OntId> - the ONT identifier Field type <Eqpt::OntSlotId> - the ONT SLOT identifier	ont ces uni <i>This element is only shown in detail mode.</i>

103 Alarm Snap-shot Status Commands

name	Type	Description
	Field type <Eqpt::OntPortId> - the ONT PORT identifier	
service-id	Parameter type: <Gpon::AlarmIndex2Integer> - a signed integer	service id <i>This element is only shown in detail mode.</i>

Only Show Details: alarm snap-shot status		
name	Type	Description
ont-svc-pwe-mismatch	Parameter type: <Alarm::ONTPWESVCMIS> (yes no) Possible values: - yes : service mismatch for provisioned pseudowire - no : ont service is ok	service mismatch for provisioned pseudowire <i>This element is only shown in detail mode.</i>
ont-svc-pwe-reordr-lof	Parameter type: <Alarm::ONTPWELOSSREORDER> (yes no) Possible values: - yes : pseudowire reordering and loss of frame - no : ont service is ok	pseudowire reordering and loss of frame <i>This element is only shown in detail mode.</i>
ont-svc-pwe-jitt-buf-o	Parameter type: <Alarm::ONTPWEJBOVRRUN> (yes no) Possible values: - yes : pseudowire jitter buffer overrun - no : ont service is ok	pseudowire jitter buffer overrun <i>This element is only shown in detail mode.</i>
ont-svc-pwe-jitt-buf-u	Parameter type: <Alarm::ONTPWEJBUNDRUN> (yes no) Possible values: - yes : pseudowire jitter buffer underrun - no : ont service is ok	pseudowire jitter buffer underrun <i>This element is only shown in detail mode.</i>
ont-svc-pwe-malf-frms	Parameter type: <Alarm::ONTPWEMALFORM> (yes no) Possible values: - yes : pseudowire malformed frames - no : ont service is ok	pseudowire malformed frames <i>This element is only shown in detail mode.</i>
ont-svc-pwe-late-frms	Parameter type: <Alarm::ONTPWELATEFRMS> (yes no) Possible values: - yes : pseudowire late frames - no : ont service is ok	pseudowire late frames <i>This element is only shown in detail mode.</i>
ont-svc-pwe-link-loss	Parameter type: <Alarm::ONTPWELINKLOSS> (yes no) Possible values: - yes : pseudowire link loss - no : ont service is ok	pseudowire link loss <i>This element is only shown in detail mode.</i>
ont-svc-pwe-arp-fail	Parameter type: <Alarm::ONTPWEARPFAIL> (yes no) Possible values: - yes : pseudowire arp failure - no : ont service is ok	pseudowire arp failure <i>This element is only shown in detail mode.</i>

103.135 Alarm SnapShot ONT CESE1 Status Command

Command Description

This command displays the snapshot ONT CESE1 alarm status.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

> show alarm snap-shot ont-cese1 [(index)]

Command Parameters

Table 103.135-1 " Alarm SnapShot ONT CESE1 Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm snapshot table index

Command Output

Table 103.135-2 " Alarm SnapShot ONT CESE1 Status Command" Display parameters

Specific Information		
name	Type	Description
ces-port	Parameter type: <Gpon::IfIndexAlarmIndex2> (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Gpon::OntSlotId> / <Gpon::OntPortId> ng2 : <Ng2::ChannelGroup> / <Ng2::SubchannelGroup> / <Ng2::OntId> / <Gpon::OntSlotId> / <Gpon::OntPortId>) Possible values: - ng2 : ngpon2 style identification Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier	ces port <i>This element is only shown in detail mode.</i>

103 Alarm Snap-shot Status Commands

name	Type	Description
	Field type <Ng2::ChannelGroup> - channel group number Field type <Ng2::SubchannelGroup> - subchannel group number Field type <Eqpt::OntId> - the ONT identifier Field type <Ng2::OntId> - the ONT identifier Field type <Gpon::OntSlotId> - Gpon Ont Slot - range: [1...14] Field type <Gpon::OntPortId> - Gpon Ont Port - range: [1...16]	

Only Show Details: alarm snap-shot status		
name	Type	Description
ont-svc-ces-e1-mis	Parameter type: <Alarm::ONTCESE1SVCNIS> (yes no) Possible values: - yes : ont service mismatch for provisioned ces e1 - no : ont service is ok	ont service mismatch for provisioned ces e1 <i>This element is only shown in detail mode.</i>
ont-svc-ces-e1-los	Parameter type: <Alarm::ONTCESE1LOS> (yes no) Possible values: - yes : loss of signal at e1 interface - no : ont service is ok	loss of signal at e1 interface <i>This element is only shown in detail mode.</i>
ont-svc-ces-e1-lof	Parameter type: <Alarm::ONTCESE1LOF> (yes no) Possible values: - yes : loss of frame at e1 interface - no : ont service is ok	loss of frame at e1 interface <i>This element is only shown in detail mode.</i>
ont-svc-ces-e1-rair	Parameter type: <Alarm::ONTCESE1RAIR> (yes no) Possible values: - yes : receiving rai at e1 interface - no : ont service is ok	receiving rai at e1 interface <i>This element is only shown in detail mode.</i>
ont-svc-ces-e1-ais	Parameter type: <Alarm::ONTCESE1AISR> (yes no) Possible values: - yes : receiving ais at e1 interface - no : ont service is ok	receiving ais at e1 interface <i>This element is only shown in detail mode.</i>

103.136 Alarm SnapShot ONT XDSL Status Command

Command Description

This command displays the snapshot ONT XDSL alarm status.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm snap-shot ont-xdsl [ (index) ]
```

Command Parameters

Table 103.136-1 " Alarm SnapShot ONT XDSL Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm snapshot table index

Command Output

Table 103.136-2 " Alarm SnapShot ONT XDSL Status Command" Display parameters

Specific Information		
name	Type	Description
dsl-line-port	Parameter type: <Gpon::IfIndexAlarmIndex2> (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Gpon::OntSlotId> / <Gpon::OntPortId> ng2 : <Ng2::ChannelGroup> / <Ng2::SubchannelGroup> / <Ng2::OntId> / <Gpon::OntSlotId> / <Gpon::OntPortId>) Possible values: - ng2 : ngpon2 style identification Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier	dsl line port <i>This element is only shown in detail mode.</i>

103 Alarm Snap-shot Status Commands

name	Type	Description
	Field type <Ng2::ChannelGroup> - channel group number Field type <Ng2::SubchannelGroup> - subchannel group number Field type <Eqpt::OntId> - the ONT identifier Field type <Ng2::OntId> - the ONT identifier Field type <Gpon::OntSlotId> - Gpon Ont Slot - range: [1...14] Field type <Gpon::OntPortId> - Gpon Ont Port - range: [1...16]	

Only Show Details: alarm snap-shot status		
name	Type	Description
ont-svc-xdsl-mismatch	Parameter type: <Alarm::ONTXDSLVCNIS> (yes no) Possible values: - yes : receiving ais at e1 interface - no : ont service is ok	service mismatch for provisioned xdsl <i>This element is only shown in detail mode.</i>
ont-svc-xdsl-ne-lof	Parameter type: <Alarm::ONTXLOF> (yes no) Possible values: - yes : near end loss of frame - no : ont service is ok	near end loss of frame <i>This element is only shown in detail mode.</i>
ont-svc-xdsl-ne-los	Parameter type: <Alarm::ONTXLOS> (yes no) Possible values: - yes : near end loss of signal - no : ont service is ok	near end loss of signal <i>This element is only shown in detail mode.</i>
ont-svc-xdsl-ne-line	Parameter type: <Alarm::ONTLINEINIT> (yes no) Possible values: - yes : near end line init - no : ont service is ok	near end line init <i>This element is only shown in detail mode.</i>
ont-svc-xdsl-ne-lol	Parameter type: <Alarm::ONTXLLOL> (yes no) Possible values: - yes : near end loss of link - no : ont service is ok	near end loss of link <i>This element is only shown in detail mode.</i>
ont-svc-xdsl-fe-lof	Parameter type: <Alarm::ONTXLOFFE> (yes no) Possible values: - yes : far end loss of frame - no : ont service is ok	far end loss of frame <i>This element is only shown in detail mode.</i>
ont-svc-xdsl-fe-los	Parameter type: <Alarm::ONTXLOSFE> (yes no) Possible values: - yes : far end loss of signal	far end loss of signal <i>This element is only shown in detail mode.</i>

name	Type	Description
	- no : ont service is ok	
ont-svc-xdsl-fe-lop	Parameter type: <Alarm::ONTXLOPFE> (yes no) Possible values: - yes : far end loss of power - no : ont service is ok	far end loss of power <i>This element is only shown in detail mode.</i>
ont-svc-xdsl-cnfg-err	Parameter type: <Alarm::ONTXDSLCONF> (yes no) Possible values: - yes : xdsl provisioning error - no : ont service is ok	xdsl provisioning error <i>This element is only shown in detail mode.</i>

103.137 Alarm SnapShot ONT XDSL TCA Status Command

Command Description

This command displays the snapshot ONT XDSL TCA alarm status.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm snap-shot ont-xdsl-tca [ (index) ]
```

Command Parameters

Table 103.137-1 " Alarm SnapShot ONT XDSL TCA Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm snapshot table index

Command Output

Table 103.137-2 " Alarm SnapShot ONT XDSL TCA Status Command" Display parameters

Specific Information		
name	Type	Description
dsl-line-port	Parameter type: <Gpon::IfIndexAlarmIndex2> (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Gpon::OntSlotId> / <Gpon::OntPortId> ng2 : <Ng2::ChannelGroup> / <Ng2::SubchannelGroup> / <Ng2::OntId> / <Gpon::OntSlotId> / <Gpon::OntPortId>) Possible values: - ng2 : ngpon2 style identification Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier	dsl line port <i>This element is only shown in detail mode.</i>

name	Type	Description
	Field type <Ng2::ChannelGroup> - channel group number Field type <Ng2::SubchannelGroup> - subchannel group number Field type <Eqpt::OntId> - the ONT identifier Field type <Ng2::OntId> - the ONT identifier Field type <Gpon::OntSlotId> - Gpon Ont Slot - range: [1...14] Field type <Gpon::OntPortId> - Gpon Ont Port - range: [1...16]	

Only Show Details: alarm snap-shot status		
name	Type	Description
ont-svc-xdsl-ne-es-tc	Parameter type: <Alarm::ONTXDSLES> (yes no) Possible values: - yes : near end errored seconds threshold crossed - no : ont service is ok	near end errored seconds threshold crossed <i>This element is only shown in detail mode.</i>
ont-svc-xdsl-ne-ses-tc	Parameter type: <Alarm::ONTXDSESES> (yes no) Possible values: - yes : near end severe errored seconds threshold crossed - no : ont service is ok	near end severe errored seconds threshold crossed <i>This element is only shown in detail mode.</i>
ont-svc-xdsl-ne-uas-tc	Parameter type: <Alarm::ONTXDSELUAS> (yes no) Possible values: - yes : ear end unavailable seconds threshold crossed - no : ont service is ok	ear end unavailable seconds threshold crossed <i>This element is only shown in detail mode.</i>
ont-svc-xdsl-fe-es-tc	Parameter type: <Alarm::ONTXDSLESFAREND> (yes no) Possible values: - yes : far end errored seconds threshold crossed - no : ont service is ok	far end errored seconds threshold crossed <i>This element is only shown in detail mode.</i>
ont-svc-xdsl-fe-ses-tc	Parameter type: <Alarm::ONTXDSESESFAREND> (yes no) Possible values: - yes : far end severe errored seconds threshold crossed - no : ont service is ok	far end severe errored seconds threshold crossed <i>This element is only shown in detail mode.</i>
ont-svc-xdsl-fe-uas-tc	Parameter type: <Alarm::ONTXDSELUASFAREND> (yes no) Possible values: - yes : far end unavailable seconds threshold crossed - no : ont service is ok	far end unavailable seconds threshold crossed <i>This element is only shown in detail mode.</i>

103.138 Alarm SnapShot ONT HPNA Status Command

Command Description

This command displays the snapshot ONT HPNA alarm status.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm snap-shot ont-hpna [ (index) ]
```

Command Parameters

Table 103.138-1 " Alarm SnapShot ONT HPNA Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm snapshot table index

Command Output

Table 103.138-2 " Alarm SnapShot ONT HPNA Status Command" Display parameters

Specific Information		
name	Type	Description
ont-port	Parameter type: <Gpon::IfIndexAlarmIndex2> (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Gpon::OntSlotId> / <Gpon::OntPortId> ng2 : <Ng2::ChannelGroup> / <Ng2::SubchannelGroup> / <Ng2::OntId> / <Gpon::OntSlotId> / <Gpon::OntPortId>) Possible values: - ng2 : ngpon2 style identification Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier	ont port <i>This element is only shown in detail mode.</i>

name	Type	Description
	Field type <Ng2::ChannelGroup> - channel group number Field type <Ng2::SubchannelGroup> - subchannel group number Field type <Eqpt::OntId> - the ONT identifier Field type <Ng2::OntId> - the ONT identifier Field type <Gpon::OntSlotId> - Gpon Ont Slot - range: [1...14] Field type <Gpon::OntPortId> - Gpon Ont Port - range: [1...16]	
Only Show Details: alarm snap-shot status		
name	Type	Description
ont-hpna-ser-mis	Parameter type: <Alarm::ONTHPNASVCMIS> (yes no) Possible values: - yes : hpna ont service mismatch - no : ont service is ok	hpna ont service mismatch <i>This element is only shown in detail mode.</i>
ont-hpna-los-sig	Parameter type: <Alarm::ONTHPNALOS> (yes no) Possible values: - yes : hpna loss of link - no : ont service is ok	hpna loss of link <i>This element is only shown in detail mode.</i>

103.139 Alarm SnapShot ONT SIP AGENT CFG Status Command

Command Description

This command displays the snapshot ONT SIP AGENT CFG alarm status.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

> show alarm snap-shot ont-sip-agent-cfg [(index)]

Command Parameters

Table 103.139-1 " Alarm SnapShot ONT SIP AGENT CFG Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm snapshot table index

Command Output

Table 103.139-2 " Alarm SnapShot ONT SIP AGENT CFG Status Command" Display parameters

Specific Information		
name	Type	Description
port	Parameter type: <Gpon::IpHostCommonIndex> (ont : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Gpon::IpHostId> vlanport : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / vuni : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlanport : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / vuni : <Eqpt::UnstackedVlan> ont:ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / <Ng2::IpHostId> vlanport:ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / vuni : stacked : <Eqpt::SVlan> : <Eqpt::CVlan>	gpon iphost port <i>This element is only shown in detail mode.</i>

name	Type	Description
	vlanport:ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / vuni : <Eqpt::UnstackedVlan>) Possible values: - ont:ng2 : ngpon2 ont - vlanport:ng2 : ngpon2 vlanport - ont : ont - vlanport : vlanport Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Eqpt::OntId> - the ONT identifier Field type <Eqpt::ChannelGroupId> - the channel group identifier Field type <Eqpt::SubChannelGroupId> - the subchannel group identifier Field type <Eqpt::Ng2OntId> - the NG2 ONT identifier Possible values: - vuni : virtual uni identifier Possible values: - vuni : virtual NGPON2 uni identifier Field type <Gpon::IpHostID> - iphost id Field type <Ng2::IpHostID> - iphost id (ngpon2) Possible values: - stacked : stacked vlan identity Field type <Eqpt::UnstackedVlan> - unstacked vlan id Field type <Eqpt::SVlan> - service vlan id Field type <Eqpt::CVlan> - customer vlan id	

Only Show Details: alarm snap-shot status		
name	Type	Description
ont-sipa-reg-nm-fail	Parameter type: <Alarm::ONTSIPAREGFAILNAME> (yes no) Possible values: - yes : sipua registration name failed - no : ont service is ok	sipua registration name failed <i>This element is only shown in detail mode.</i>
ont-sipa-reg-rec-fail	Parameter type: <Alarm::ONTSIPAREGREACH> (yes no) Possible values: - yes : sipua register reach failed - no : ont service is ok	sipua register reach failed <i>This element is only shown in detail mode.</i>
ont-sipa-reg-con-fail	Parameter type: <Alarm::ONTSIPAREGCONNECT> (yes no)	sipua register connect failed <i>This element is only shown in detail mode.</i>

103 Alarm Snap-shot Status Commands

name	Type	Description
	Possible values: - yes : sipua register connect failed - no : ont service is ok	
ont-sipa-reg-val-fail	Parameter type: <Alarm::ONTSIPAREGVALIDATE> (yes no) Possible values: - yes : sipua register validation failed - no : ont service is ok	sipua register validation failed <i>This element is only shown in detail mode.</i>
ont-sipa-reg-mis	Parameter type: <Alarm::ONTSIPAREGMIS> (yes no) Possible values: - yes : sipua register mismatch - no : ont service is ok	sipua register mismatch <i>This element is only shown in detail mode.</i>

103.140 Alarm SnapShot ONT VOIP CFG Status Command

Command Description

This command displays the snapshot ONT VOIP CFG alarm status.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm snap-shot ont-voip-cfg [ (index) ]
```

Command Parameters

Table 103.140-1 " Alarm SnapShot ONT VOIP CFG Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm snapshot table index

Command Output

Table 103.140-2 " Alarm SnapShot ONT VOIP CFG Status Command" Display parameters

Specific Information		
name	Type	Description
port	Parameter type: <Gpon::IpHostCommonIndex> (ont : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Gpon::IpHostId> vlanport : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / vuni : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlanport : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / vuni : <Eqpt::UnstackedVlan> ont.ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / <Ng2::IpHostId> vlanport.ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / vuni : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlanport.ng2 : <Eqpt::ChannelGroupId> /	gpon iphost port <i>This element is only shown in detail mode.</i>

103 Alarm Snap-shot Status Commands

name	Type	Description
	<Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / vuni : <Eqpt::UnstackedVlan>) Possible values: - ont:ng2 : ngpon2 ont - vlanport:ng2 : ngpon2 vlanport - ont : ont - vlanport : vlanport Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Eqpt::OntId> - the ONT identifier Field type <Eqpt::ChannelGroupId> - the channel group identifier Field type <Eqpt::SubChannelGroupId> - the subchannel group identifier Field type <Eqpt::Ng2OntId> - the NG2 ONT identifier Possible values: - vuni : virtual uni identifier Possible values: - vuni : virtual NGPON2 uni identifier Field type <Gpon::IpHostID> - iphost id Field type <Ng2::IpHostID> - iphost id (ngpon2) Possible values: - stacked : stacked vlan identity Field type <Eqpt::UnstackedVlan> - unstacked vlan id Field type <Eqpt::SVlan> - service vlan id Field type <Eqpt::CVlan> - customer vlan id	

Only Show Details: alarm snap-shot status		
name	Type	Description
ont-vcd-cfg-nm-fail	Parameter type: <Alarm::ONTVCDCFGFAILNAME> (yes no) Possible values: - yes : vcd config name failed - no : ont service is ok	vcd config name failed <i>This element is only shown in detail mode.</i>
ont-vcd-cfg-rech-fail	Parameter type: <Alarm::ONTVCDCFGREACH> (yes no) Possible values: - yes : vcd config reach failed - no : ont service is ok	vcd config reach failed <i>This element is only shown in detail mode.</i>
ont-vcd-cfg-conn-fail	Parameter type: <Alarm::ONTVCDCFGCONNECT> (yes no) Possible values:	vcd config connect failed <i>This element is only shown in detail mode.</i>

name	Type	Description
	- yes : vcd config connect failed - no : ont service is ok	
ont-vcd-cfg-vali-fail	Parameter type: <Alarm::ONTVCDCFGVALIDATE> (yes no) Possible values: - yes : vcd config validation failed - no : ont service is ok	vcd config validation failed <i>This element is only shown in detail mode.</i>
ont-vcd-cfg-auth-fail	Parameter type: <Alarm::ONTVCDCFGAUTH> (yes no) Possible values: - yes : vcd config authentication failed - no : ont service is ok	vcd config authentication failed <i>This element is only shown in detail mode.</i>
ont-vcd-cfg-resp-tmout	Parameter type: <Alarm::ONTVCDCFGTMOUT> (yes no) Possible values: - yes : vcd config response timeout - no : ont service is ok	vcd config response timeout <i>This element is only shown in detail mode.</i>
ont-vcd-cfg-resp-err	Parameter type: <Alarm::ONTVCDCFGRESPERR> (yes no) Possible values: - yes : vcd config response error - no : ont service is ok	vcd config response error <i>This element is only shown in detail mode.</i>
ont-vcd-cfg-file-err	Parameter type: <Alarm::ONTVCDCFGFILEERR> (yes no) Possible values: - yes : vcd config file error - no : ont service is ok	vcd config file error <i>This element is only shown in detail mode.</i>
ont-vcd-sub-nm-fail	Parameter type: <Alarm::ONTVCDSUBSFILNAME> (yes no) Possible values: - yes : vcd subscription name failed - no : ont service is ok	vcd subscription name failed <i>This element is only shown in detail mode.</i>
ont-vcd-sub-rech-fail	Parameter type: <Alarm::ONTVCDSUBSREACH> (yes no) Possible values: - yes : vcd subscription reach failed - no : ont service is ok	vcd subscription reach failed <i>This element is only shown in detail mode.</i>
ont-vcd-sub-conn-fail	Parameter type: <Alarm::ONTVCDSUBSCONNECT> (yes no) Possible values: - yes : vcd subscription connect failed - no : ont service is ok	vcd subscription connect failed <i>This element is only shown in detail mode.</i>
ont-vcd-sub-vali-fail	Parameter type: <Alarm::ONTVCDSUBSVALIDATE> (yes no) Possible values: - yes : vcd subscription validation failed - no : ont service is ok	vcd subscription validation failed <i>This element is only shown in detail mode.</i>
ont-vcd-sub-auth-fail	Parameter type: <Alarm::ONTVCDSUBSAUTH>	vcd subscription authentication

103 Alarm Snap-shot Status Commands

name	Type	Description
	(yes no) Possible values: - yes : vcd subscription authentication failed - no : ont service is ok	failed <i>This element is only shown in detail mode.</i>
ont-vcd-sub-resp-tmout	Parameter type: <Alarm::ONTVCDSUBSTMOUT> (yes no) Possible values: - yes : vcd subscription response timeout - no : ont service is ok	vcd subscription response timeout <i>This element is only shown in detail mode.</i>
ont-vcd-sub-resp-err	Parameter type: <Alarm::ONTVCDSUBSRESPERR> (yes no) Possible values: - yes : vcd subscription response error - no : ont service is ok	vcd subscription response error <i>This element is only shown in detail mode.</i>
ont-vcd-reb-requ	Parameter type: <Alarm::ONTVCDREBOOTREQ> (yes no) Possible values: - yes : vcd reboot request - no : ont service is ok	vcd reboot request <i>This element is only shown in detail mode.</i>
ont-vcd-mis	Parameter type: <Alarm::ONTVCDMIS> (yes no) Possible values: - yes : vcd mismatch - no : ont service is ok	vcd mismatch <i>This element is only shown in detail mode.</i>

103.141 Alarm SnapShot ONT MGC Status Command

Command Description

This command displays the snapshot ONT MGC alarm status.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm snap-shot ont-mgc [ (index) ]
```

Command Parameters

Table 103.141-1 " Alarm SnapShot ONT MGC Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm snapshot table index

Command Output

Table 103.141-2 " Alarm SnapShot ONT MGC Status Command" Display parameters

Specific Information		
name	Type	Description
port	Parameter type: <Gpon::IpHostCommonIndex> (ont : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Gpon::IpHostId> vlanport : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / vuni : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlanport : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / vuni : <Eqpt::UnstackedVlan> ont.ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / <Ng2::IpHostId> vlanport.ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / vuni : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlanport.ng2 : <Eqpt::ChannelGroupId> /	gpon iphost port <i>This element is only shown in detail mode.</i>

103 Alarm Snap-shot Status Commands

name	Type	Description
	<Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / vuni : <Eqpt::UnstackedVlan>) Possible values: - ont:ng2 : ngpon2 ont - vlanport:ng2 : ngpon2 vlanport - ont : ont - vlanport : vlanport Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Eqpt::OntId> - the ONT identifier Field type <Eqpt::ChannelGroupId> - the channel group identifier Field type <Eqpt::SubChannelGroupId> - the subchannel group identifier Field type <Eqpt::Ng2OntId> - the NG2 ONT identifier Possible values: - vuni : virtual uni identifier Possible values: - vuni : virtual NGPON2 uni identifier Field type <Gpon::IpHostID> - iphost id Field type <Ng2::IpHostID> - iphost id (ngpon2) Possible values: - stacked : stacked vlan identity Field type <Eqpt::UnstackedVlan> - unstacked vlan id Field type <Eqpt::SVlan> - service vlan id Field type <Eqpt::CVlan> - customer vlan id	

Only Show Details: alarm snap-shot status		
name	Type	Description
ont-mgc-mis	Parameter type: <Alarm::ONTMGCMIS> (yes no) Possible values: - yes : ont mgc mismatch - no : ont service is ok	ont mgc mismatch <i>This element is only shown in detail mode.</i>
ont-mgc-timeout	Parameter type: <Alarm::ONTMGCTMOUT> (yes no) Possible values: - yes : ont mgc timeout - no : ont service is ok	ont mgc timeout <i>This element is only shown in detail mode.</i>

103.142 Alarm Snapshot ONT MoCA Status Command

Command Description

This command displays the snapshot ONT MoCA alarm status.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm snap-shot ont-moca [ (index) ]
```

Command Parameters

Table 103.142-1 " Alarm Snapshot ONT MoCA Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm snapshot table index

Command Output

Table 103.142-2 " Alarm Snapshot ONT MoCA Status Command" Display parameters

Specific Information		
name	Type	Description
uni-index	Parameter type: <Gpon::IfIndexAlarmIndex2> (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Gpon::OntSlotId> / <Gpon::OntPortId> ng2 : <Ng2::ChannelGroup> / <Ng2::SubchannelGroup> / <Ng2::OntId> / <Gpon::OntSlotId> / <Gpon::OntPortId>) Possible values: - ng2 : ngpon2 style identification Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier	ont port <i>This element is only shown in detail mode.</i>

103 Alarm Snap-shot Status Commands

name	Type	Description
	Field type <Ng2::ChannelGroup> - channel group number Field type <Ng2::SubchannelGroup> - subchannel group number Field type <Eqpt::OntId> - the ONT identifier Field type <Ng2::OntId> - the ONT identifier Field type <Gpon::OntSlotId> - Gpon Ont Slot - range: [1...14] Field type <Gpon::OntPortId> - Gpon Ont Port - range: [1...16]	
Only Show Details: alarm snap-shot status		
name	Type	Description
ont-moca-svc-mis	Parameter type: <Alarm::ONTMOCASVCMIS> (yes no) Possible values: - yes : moca ont service mismatch - no : moca ont service is ok	ont moca service mismatch <i>This element is only shown in detail mode.</i>
ont-moca-link-los	Parameter type: <Alarm::ONTMOCALOL> (yes no) Possible values: - yes : moca loss of link - no : moca ont service is ok	ont moca loss of link <i>This element is only shown in detail mode.</i>
ont-moca-min-bw	Parameter type: <Alarm::ONTMOCALIMLINK> (yes no) Possible values: - yes : moca limited link - no : moca ont service is ok	ont moca bw between nodes less than minimum bw <i>This element is only shown in detail mode.</i>

103.143 ONT MoCA Threshold Crossing Alert (TCA) Alarm Snapshot Status Command

Command Description

This command displays the ONT MoCA Threshold Crossing Alert (TCA) snapshot alarm status.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm snap-shot ont-moca-tca [ (index) ]
```

Command Parameters

Table 103.143-1 " ONT MoCA Threshold Crossing Alert (TCA) Alarm Snapshot Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm type

Command Output

Table 103.143-2 " ONT MoCA Threshold Crossing Alert (TCA) Alarm Snapshot Status Command" Display parameters

Specific Information		
name	Type	Description
uni-index	Parameter type: <Gpon::IfIndexAlarmIndex2> (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Gpon::OntSlotId> / <Gpon::OntPortId> ng2 : <Ng2::ChannelGroup> / <Ng2::SubchannelGroup> / <Ng2::OntId> / <Gpon::OntSlotId> / <Gpon::OntPortId>) Possible values: - ng2 : ngpon2 style identification Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number	ont port <i>This element is only shown in detail mode.</i>

103 Alarm Snap-shot Status Commands

name	Type	Description
	Field type <Eqpt::PonId> - the PON identifier Field type <Ng2::ChannelGroup> - channel group number Field type <Ng2::SubchannelGroup> - subchannel group number Field type <Eqpt::OntId> - the ONT identifier Field type <Ng2::OntId> - the ONT identifier Field type <Gpon::OntSlotId> - Gpon Ont Slot - range: [1...14] Field type <Gpon::OntPortId> - Gpon Ont Port - range: [1...16]	

Only Show Details: alarm snap-shot status		
name	Type	Description
ont-moca-rx-err-fr	Parameter type: <Alarm::ONTMOCATCARXERRFRMS> (yes no) Possible values: - yes : ont moca rx errored frames threshold alert - no : no ont moca threshold alerts	ont moca rx errored frames threshold alert <i>This element is only shown in detail mode.</i>

103.144 Auto-Switch Alarm Snapshot Status Command

Command Description

This command displays the status of the snapshot of auto-switch alarm.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

> show alarm snap-shot auto-switch [(index)]

Command Parameters

Table 103.144-1 "Auto-Switch Alarm Snapshot Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm snap shot table index

Command Output

Table 103.144-2 "Auto-Switch Alarm Snapshot Status Command" Display parameters

Specific Information		
name	Type	Description
port	Parameter type: <Itf::XdslLine> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number	identifies the physical position of the port <i>This element is only shown in detail mode.</i>
auto-switch-status	Parameter type: <Alarm::autoSwitchStatus> (yes no) Possible values: - yes : auto-switch alarm status	show auto-switch alarm status. <i>This element is only shown in detail mode.</i>

103 Alarm Snap-shot Status Commands

name	Type	Description
	- no : auto-switch alarm status clear	
queue-full-atm	Parameter type: <Alarm::auswqueuefullatm> (yes no) Possible values: - yes : auto-switch queue full for ATM - no : auto-switch queue full for ATM clear	show auto-switch alarm status. <i>This element is only shown in detail mode.</i>
cfg-data-bkup-fail-atm	Parameter type: <Alarm::auswbkpfailatm> (yes no) Possible values: - yes : auto-switch data backup failed for ATM - no : auto-switch data backup failed for ATM clear	show auto-switch alarm status. <i>This element is only shown in detail mode.</i>
recfg-fail-atm	Parameter type: <Alarm::auswrecfgfailatm> (yes no) Possible values: - yes : auto-switch reconfig failed for ATM - no : auto-switch reconfig failed for ATM clear	show auto-switch alarm status. <i>This element is only shown in detail mode.</i>
data-unavail-atm	Parameter type: <Alarm::auswdataunatm> (yes no) Possible values: - yes : auto-switch data unavailable for ATM - no : auto-switch data unavailable for ATM clear	show auto-switch alarm status. <i>This element is only shown in detail mode.</i>
queue-full-ptm	Parameter type: <Alarm::auswqueuefulptm> (yes no) Possible values: - yes : auto-switch queue full for PTM - no : auto-switch queue full for PTM clear	show auto-switch alarm status. <i>This element is only shown in detail mode.</i>
backup-fail-ptm	Parameter type: <Alarm::auswbkpfailptm> (yes no) Possible values: - yes : auto-switch data backup failed for PTM - no : auto-switch data backup failed for PTM clear	show auto-switch alarm status. <i>This element is only shown in detail mode.</i>
recfg-fail-ptm	Parameter type: <Alarm::auswrecfgfailptm> (yes no) Possible values: - yes : auto-switch reconfig failed for PTM - no : auto-switch reconfig failed for PTM clear	show auto-switch alarm status. <i>This element is only shown in detail mode.</i>
data-unavail-ptm	Parameter type: <Alarm::auswdataunptm> (yes no) Possible values: - yes : auto-switch data unavailable for PTM - no : auto-switch data unavailable for PTM clear	show auto-switch alarm status. <i>This element is only shown in detail mode.</i>
bakp-fail-atm	Parameter type: <Alarm::auswbakpfailatm> (yes no) Possible values: - yes : auto-switch backup fail for ATM - no : auto-switch bakcup fail for ATM clear	show auto-switch alarm status. <i>This element is only shown in detail mode.</i>

103.145 Ont Configuration Download Snapshot Status Command

Command Description

This command displays the ont configuration download snapshot-related alarms.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm snap-shot ont-cfg-dld [ (index) ]
```

Command Parameters

Table 103.145-1 "Ont Configuration Download Snapshot Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm snap shot table index

Command Output

Table 103.145-2 "Ont Configuration Download Snapshot Status Command" Display parameters

Specific Information		
name	Type	Description
ont	Parameter type: <Gpon::OntIndex> (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> ng2 : <Ng2::ChannelGroup> / <Ng2::SubchannelGroup> / <Ng2::OntId>) Possible values: - ng2 : ngpon2 style identification Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Ng2::ChannelGroup>	identifies the ont entry <i>This element is only shown in detail mode.</i>

103 Alarm Snap-shot Status Commands

name	Type	Description
	- channel group number Field type <Ng2::SubchannelGroup> - subchannel group number Field type <Eqpt::OntId> - the ONT identifier Field type <Ng2::OntId> - the ONT identifier	
cfgfile-idx	Parameter type: <Alarm::OntCfgFileIndex> (configure file 1 configure file 2) Possible values: - configure file 1 : configure file 1 generate the alarm - configure file 2 : configure file 2 generate the alarm	identifies the configure file which generate the alarm <i>This element is only shown in detail mode.</i>
cfg-dld-fail	Parameter type: <Alarm::OntCfgDldFail> (yes no) Possible values: - yes : download of configure file to ont is failed - no : download of configure file to ont is ok	specifies download of configure file to ont is failed or not <i>This element is only shown in detail mode.</i>
cfg-act-fail	Parameter type: <Alarm::OntCfgActFail> (yes no) Possible values: - yes : activate the passive config file failed - no : activate the passive config file ok	specifies activate of configure file to ont is failed or not <i>This element is only shown in detail mode.</i>
cfg-dld-ip	Parameter type: <Alarm::OntCfgDldIp> (yes no) Possible values: - yes : ont configure file download in progress - no : no ont configure file download detected	specifies whether downloading <i>This element is only shown in detail mode.</i>
cfg-ver-mismatch	Parameter type: <Alarm::OntCfgVerMismatch> (yes no) Possible values: - yes : the planned configure file does not match the active configure file - no : the planned configure file match the active configure file	specifies whether planned configure file match the active configure file or not <i>This element is only shown in detail mode.</i>
cfg-file-missing	Parameter type: <Alarm::OntCfgFileMissing> (yes no) Possible values: - yes : ont configure file missing or has an error - no : ont configure file ok	specifies whether ont configure file missing <i>This element is only shown in detail mode.</i>
cfg-verctrl-err	Parameter type: <Alarm::OntCfgVerCtrlErr> (yes no) Possible values: - yes : ont configure file version control error - no : ont configure file version control ok	specifies ont configure file version control error <i>This element is only shown in detail mode.</i>
cfg-not-supported	Parameter type: <Alarm::OntCfgNotSupported> (yes no) Possible values: - yes : ont not support the configure file download function - no : ont support the configure file download function	specifies ont not support configure file download function <i>This element is only shown in detail mode.</i>

103.146 Alarm Snapshot Channel Pair OLT TC TCA Status Command

Command Description

This command displays the snapshot Channel Pair OLT TC TCA alarm status.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm snap-shot olt-chpair-tc-tca [ (index) ]
```

Command Parameters

Table 103.146-1 " Alarm Snapshot Channel Pair OLT TC TCA Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm snapshot table index

Command Output

Table 103.146-2 " Alarm Snapshot Channel Pair OLT TC TCA Status Command" Display parameters

Specific Information		
name	Type	Description
channel-pair	Parameter type: <Gpon::ChannelPairId> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::ChannelPairId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::ChannelPairId> - the channel pair identifier	pon ifindex <i>This element is only shown in detail mode.</i>

Only Show Details: alarm snap-shot status		
name	Type	Description
olt-chpr-tc-err-frag	Parameter	type: channelpair errored fragments

name	Type	Description
	<Alarm::OLTCHPRTCTCAERRFRAGSPON> (yes no) Possible values: - yes : channelpair errored fragments threshold crossed - no : olt works properly	threshold crossed <i>This element is only shown in detail mode.</i>
olt-chpr-up-bw-tca	Parameter type: <Alarm::OLTCHPRTCTCAUPBWTCa> (yes no) Possible values: - yes : olt channelpair upstream bandwidth tca - no : olt works properly	OLT CHANNELPAIR upstream bandwidth TCA <i>This element is only shown in detail mode.</i>
olt-chpr-down-bw-tca	Parameter type: <Alarm::OLTCHPRTCTCADWBWTCA> (yes no) Possible values: - yes : olt channelpair downstream bandwidth tca - no : olt works properly	OLT CHANNELPAIR downstream bandwidth TCA <i>This element is only shown in detail mode.</i>

103.147 Alarm Snapshot Channel Pair Status Command

Command Description

This command displays the snapshot Channel Pair alarm status.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

> show alarm snap-shot channel-pair [(index)]

Command Parameters

Table 103.147-1 " Alarm Snapshot Channel Pair Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm type

Command Output

Table 103.147-2 " Alarm Snapshot Channel Pair Status Command" Display parameters

Specific Information		
name	Type	Description
channel-pair	Parameter type: <Gpon::ChannelPairId> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::ChannelPairId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::ChannelPairId> - the channel pair identifier	channel-pair ifindex <i>This element is only shown in detail mode.</i>
Only Show Details: alarm snap-shot status		
name	Type	Description
comm-fail	Parameter type: <Alarm::ChnPairComm> ((failing fail) ok)	Channel pair Communication failure on channel Pair Port <i>This element is only shown in</i>

name	Type	Description
	Possible values: - failing : Channel pair Communication is failing - fail : Channel pair Communication is failing - ok : Channel pair Communication is ok	<i>detail mode.</i>
tx-fail	Parameter type: <Alarm::ChnPairTf> ((failing fail) ok) Possible values: - failing : Transmitte is failing - fail : Transmitte is failing - ok : Transmitte is ok	transmit failure on OLT port <i>This element is only shown in detail mode.</i>
new-ont	Parameter type: <Alarm::ChnPairNewOnt> ((failing fail) ok) Possible values: - failing : NEW ONT is failing - fail : NEW ONT is failing - ok : NEW ONT is ok	unprovisioned ont appearance <i>This element is only shown in detail mode.</i>
prov-mismatch	Parameter type: <Alarm::ChnPairMea> ((failing fail) ok) Possible values: - failing : Channel Pair Mismatch Provisioning is failing - fail : Channel Pair Mismatch Provisioning is failing - ok : Channel Pair Mismatch Provisioning is ok	channel Pair provision failure. <i>This element is only shown in detail mode.</i>
loss-sig	Parameter type: <Alarm::ChnPairLoss> ((failing fail) ok) Possible values: - failing : Channel Pair Loss of Signal is failing - fail : Channel Pair Loss of Signal is failing - ok : Channel Pair Loss of Signal is ok	channel Pair loss. <i>This element is only shown in detail mode.</i>
diagnostic	Parameter type: <Alarm::ChnPairRogueTest> ((failing fail) ok) Possible values: - failing : Rogue ONT detection mechanism effective is failing - fail : Rogue ONT detection mechanism effective is failing - ok : Rogue ONT detection mechanism effective is ok	diagnostic tests <i>This element is only shown in detail mode.</i>
loid-conflict	Parameter type: <Alarm::ChnPairLoidConflict> ((failing fail) ok) Possible values: - failing : ONT LOID Conflict is failing - fail : ONT LOID Conflict is failing - ok : LOID Conflict is ok	loid conflict ont. <i>This element is only shown in detail mode.</i>
loid-pwd-err	Parameter type: <Alarm::ChnPairLoidPwdErr> ((failing fail) ok) Possible values: - failing : ONT LOID PWD ERR is failing - fail : ONT LOID PWD ERR is failing - ok : ONT LOID PWD ERR is ok	loid password error. <i>This element is only shown in detail mode.</i>
stk-laser-dis	Parameter type: <Alarm::ChnPairStkLaserDis> ((failing fail) ok)	stuck laser disabled. <i>This element is only shown in detail mode.</i>

103 Alarm Snap-shot Status Commands

name	Type	Description
	Possible values: - failing : Unranged ONT with stuck laser disabled is failing - fail : Unranged ONT with stuck laser disabled is failing - ok : Unranged ONT with stuck laser disabled is ok	
sfp-mismatch	Parameter type: <Alarm::ChnPairSfpMismatch> ((failing fail) ok) Possible values: - failing : sfp mismatch is failing - fail : sfp mismatch is failing - ok : sfp mismatch is ok	sfp mismatch. <i>This element is only shown in detail mode.</i>
rng-mismatch	Parameter type: <Alarm::ChnPairRngMismatch> ((failing fail) ok) Possible values: - failing : ranging mismatch is failing - fail : ranging mismatch is failing - ok : ranging mismatch is ok	current status of ranging mismatch. <i>This element is only shown in detail mode.</i>
alien-test	Parameter type: <Alarm::ChnPairAlienTest> ((failing fail) ok) Possible values: - failing : Alien ONT detection mechanism is active - fail : Alien ONT detection mechanism is active - ok : Alien ONT detection mechanism is not active	current status of alien diagnostic tests <i>This element is only shown in detail mode.</i>
alien-detect	Parameter type: <Alarm::ChnPairAlienDetected> ((failing fail) ok) Possible values: - failing : Alien ONT detected - fail : Alien ONT detected - ok : No alien ONT detected	current status of alien detect <i>This element is only shown in detail mode.</i>

103.148 HGU TR069 Snapshot Status Command

Command Description

This command displays the hgu tr069 snapshot-related alarms.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

> show alarm snap-shot hgu-tr069 [(index)]

Command Parameters

Table 103.148-1 "HGU TR069 Snapshot Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm snap shot table index

Command Output

Table 103.148-2 "HGU TR069 Snapshot Status Command" Display parameters

Specific Information		
name	Type	Description
ont	Parameter type: <Gpon::OntIndex> (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> ng2 : <Ng2::ChannelGroup> / <Ng2::SubchannelGroup> / <Ng2::OntId>) Possible values: - ng2 : ngpon2 style identification Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Ng2::ChannelGroup> - channel group number Field type <Ng2::SubchannelGroup> - subchannel group number Field type <Eqpt::OntId>	identifies the ont entry <i>This element is only shown in detail mode.</i>

103 Alarm Snap-shot Status Commands

name	Type	Description
	- the ONT identifier Field type <Ng2::OntId> - the ONT identifier	
cust-alm1	Parameter type: <Alarm::HguCustAlm1> (yes no) Possible values: - yes : customized alarm 1 exist - no : customized alarm 1 not exist	current status of customized alarm 1 <i>This element is only shown in detail mode.</i>
cust-alm2	Parameter type: <Alarm::HguCustAlm2> (yes no) Possible values: - yes : customized alarm 2 exist - no : customized alarm 2 not exist	current status of customized alarm 2 <i>This element is only shown in detail mode.</i>
cust-alm3	Parameter type: <Alarm::HguCustAlm3> (yes no) Possible values: - yes : customized alarm 3 exist - no : customized alarm 3 not exist	current status of customized alarm 3 <i>This element is only shown in detail mode.</i>
cust-alm4	Parameter type: <Alarm::HguCustAlm4> (yes no) Possible values: - yes : customized alarm 4 exist - no : customized alarm 4 not exist	current status of customized alarm 4 <i>This element is only shown in detail mode.</i>
cust-alm5	Parameter type: <Alarm::HguCustAlm5> (yes no) Possible values: - yes : customized alarm 5 exist - no : customized alarm 5 not exist	current status of customized alarm 5 <i>This element is only shown in detail mode.</i>
cust-alm6	Parameter type: <Alarm::HguCustAlm6> (yes no) Possible values: - yes : customized alarm 6 exist - no : customized alarm 6 not exist	current status of customized alarm 6 <i>This element is only shown in detail mode.</i>
cust-alm7	Parameter type: <Alarm::HguCustAlm7> (yes no) Possible values: - yes : customized alarm 7 exist - no : customized alarm 7 not exist	current status of customized alarm 7 <i>This element is only shown in detail mode.</i>
cust-alm8	Parameter type: <Alarm::HguCustAlm8> (yes no) Possible values: - yes : customized alarm 8 exist - no : customized alarm 8 not exist	current status of customized alarm 8 <i>This element is only shown in detail mode.</i>
cust-alm9	Parameter type: <Alarm::HguCustAlm9> (yes no) Possible values: - yes : customized alarm 9 exist - no : customized alarm 9 not exist	current status of customized alarm 9 <i>This element is only shown in detail mode.</i>

name	Type	Description
cust-alm10	Parameter type: <Alarm::HguCustAlm10> (yes no) Possible values: - yes : customized alarm 10 exist - no : customized alarm 10 not exist	current status of customized alarm 10 <i>This element is only shown in detail mode.</i>
cust-alm11	Parameter type: <Alarm::HguCustAlm11> (yes no) Possible values: - yes : customized alarm 11 exist - no : customized alarm 11 not exist	current status of customized alarm 11 <i>This element is only shown in detail mode.</i>
cust-alm12	Parameter type: <Alarm::HguCustAlm12> (yes no) Possible values: - yes : customized alarm 12 exist - no : customized alarm 12 not exist	current status of customized alarm 12 <i>This element is only shown in detail mode.</i>
cust-alm13	Parameter type: <Alarm::HguCustAlm13> (yes no) Possible values: - yes : customized alarm 13 exist - no : customized alarm 13 not exist	current status of customized alarm 13 <i>This element is only shown in detail mode.</i>
cust-alm14	Parameter type: <Alarm::HguCustAlm14> (yes no) Possible values: - yes : customized alarm 14 exist - no : customized alarm 14 not exist	current status of customized alarm 14 <i>This element is only shown in detail mode.</i>
cust-alm15	Parameter type: <Alarm::HguCustAlm15> (yes no) Possible values: - yes : customized alarm 15 exist - no : customized alarm 15 not exist	current status of customized alarm 15 <i>This element is only shown in detail mode.</i>
cust-alm16	Parameter type: <Alarm::HguCustAlm16> (yes no) Possible values: - yes : customized alarm 16 exist - no : customized alarm 16 not exist	current status of customized alarm 16 <i>This element is only shown in detail mode.</i>
cust-alm17	Parameter type: <Alarm::HguCustAlm17> (yes no) Possible values: - yes : customized alarm 17 exist - no : customized alarm 17 not exist	current status of customized alarm 17 <i>This element is only shown in detail mode.</i>
cust-alm18	Parameter type: <Alarm::HguCustAlm18> (yes no) Possible values: - yes : customized alarm 18 exist - no : customized alarm 18 not exist	current status of customized alarm 18 <i>This element is only shown in detail mode.</i>
cust-alm19	Parameter type: <Alarm::HguCustAlm19> (yes no)	current status of customized alarm 19 <i>This element is only shown in</i>

103 Alarm Snap-shot Status Commands

name	Type	Description
	Possible values: - yes : customized alarm 19 exist - no : customized alarm 19 not exist	<i>detail mode.</i>
cust-alm20	Parameter type: <Alarm::HguCustAlm20> (yes no) Possible values: - yes : customized alarm 20 exist - no : customized alarm 20 not exist	current status of customized alarm 20 <i>This element is only shown in detail mode.</i>
cust-alm21	Parameter type: <Alarm::HguCustAlm21> (yes no) Possible values: - yes : customized alarm 21 exist - no : customized alarm 21 not exist	current status of customized alarm 21 <i>This element is only shown in detail mode.</i>
cust-alm22	Parameter type: <Alarm::HguCustAlm22> (yes no) Possible values: - yes : customized alarm 22 exist - no : customized alarm 22 not exist	current status of customized alarm 22 <i>This element is only shown in detail mode.</i>
cust-alm23	Parameter type: <Alarm::HguCustAlm23> (yes no) Possible values: - yes : customized alarm 23 exist - no : customized alarm 23 not exist	current status of customized alarm 23 <i>This element is only shown in detail mode.</i>
cust-alm24	Parameter type: <Alarm::HguCustAlm24> (yes no) Possible values: - yes : customized alarm 24 exist - no : customized alarm 24 not exist	current status of customized alarm 24 <i>This element is only shown in detail mode.</i>
cust-alm25	Parameter type: <Alarm::HguCustAlm25> (yes no) Possible values: - yes : customized alarm 25 exist - no : customized alarm 25 not exist	current status of customized alarm 25 <i>This element is only shown in detail mode.</i>
cust-alm26	Parameter type: <Alarm::HguCustAlm26> (yes no) Possible values: - yes : customized alarm 26 exist - no : customized alarm 26 not exist	current status of customized alarm 26 <i>This element is only shown in detail mode.</i>
cust-alm27	Parameter type: <Alarm::HguCustAlm27> (yes no) Possible values: - yes : customized alarm 27 exist - no : customized alarm 27 not exist	current status of customized alarm 27 <i>This element is only shown in detail mode.</i>
cust-alm28	Parameter type: <Alarm::HguCustAlm28> (yes no) Possible values: - yes : customized alarm 28 exist - no : customized alarm 28 not exist	current status of customized alarm 28 <i>This element is only shown in detail mode.</i>

103 Alarm Snap-shot Status Commands

name	Type	Description
cust-alm29	Parameter type: <Alarm::HguCustAlm29> (yes no) Possible values: - yes : customized alarm 29 exist - no : customized alarm 29 not exist	current status of customized alarm 29 <i>This element is only shown in detail mode.</i>
cust-alm30	Parameter type: <Alarm::HguCustAlm30> (yes no) Possible values: - yes : customized alarm 30 exist - no : customized alarm 30 not exist	current status of customized alarm 30 <i>This element is only shown in detail mode.</i>
cust-alm31	Parameter type: <Alarm::HguCustAlm31> (yes no) Possible values: - yes : customized alarm 31 exist - no : customized alarm 31 not exist	current status of customized alarm 31 <i>This element is only shown in detail mode.</i>

103.149 Equipment Holder Alarm Extended Log Status Command

Command Description

This command displays the snapshot equipment holder extended alarm log status.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

> show alarm snap-shot eqpt-psu [(index)]

Command Parameters

Table 103.149-1 "Equipment Holder Alarm Extended Log Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm snap shot table index

Command Output

Table 103.149-2 "Equipment Holder Alarm Extended Log Status Command" Display parameters

Specific Information		
name	Type	Description
shelf	Parameter type: <Equipm::Shelf> <Eqpt::RackId> / <Eqpt::ShelfId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number	specify which shelf the alarm occurred on. <i>This element is only shown in detail mode.</i>
psu-fail-crit	Parameter type: <Alarm::psuFailCrit> (yes no) Possible values: - yes : General critical PSU alarm raised - no : General PSU state OK	current status of PSU general status <i>This element is only shown in detail mode.</i>
psu-a-fail-presence	Parameter type: <Alarm::psuAPresence> (yes no) Possible values:	current status of PSU A presence <i>This element is only shown in detail mode.</i>

name	Type	Description
	- yes : PSU A presence failure - no : PSU A presence state OK	
psu-a-fail-vin-ac-nok	Parameter type: <Alarm::psuAFailVinACNOK> (yes no) Possible values: - yes : PSU A failure input AC voltage - no : PSU A input AC voltage OK	current status of PSU A input AC voltage alarm <i>This element is only shown in detail mode.</i>
psu-a-fail-vin-uv	Parameter type: <Alarm::psuAFailVinUV> (yes no) Possible values: - yes : PSU A failure input under voltage - no : PSU A input voltage OK	current status of PSU A input under voltage alarm <i>This element is only shown in detail mode.</i>
psu-a-fail-vin-ov	Parameter type: <Alarm::psuAFailVinOV> (yes no) Possible values: - yes : PSU A failure input over voltage - no : PSU A input voltage OK	current status of PSU A input over voltage alarm <i>This element is only shown in detail mode.</i>
psu-a-fail-vout-uv	Parameter type: <Alarm::psuAFailVoutUV> (yes no) Possible values: - yes : PSU A failure output under voltage - no : PSU A output voltage OK	current status of PSU A output under voltage alarm <i>This element is only shown in detail mode.</i>
psu-a-fail-vout-ov	Parameter type: <Alarm::psuAFailVoutOV> (yes no) Possible values: - yes : PSU A failure output over voltage - no : PSU A output voltage OK	current status of PSU A output over voltage alarm <i>This element is only shown in detail mode.</i>
psu-a-fail-iout-oc	Parameter type: <Alarm::psuAFailIoutOC> (yes no) Possible values: - yes : PSU A failure output over current - no : PSU A output current OK	current status of PSU A output over current alarm <i>This element is only shown in detail mode.</i>
psu-a-fail-overtemp	Parameter type: <Alarm::psuAFailOverTemp> (yes no) Possible values: - yes : PSU A failure over temperature - no : PSU A temperature OK	current status of PSU A temperature alarm <i>This element is only shown in detail mode.</i>
psu-b-fail-presence	Parameter type: <Alarm::psuBPresence> (yes no) Possible values: - yes : PSU B presence failure - no : PSU B presence state OK	current status of PSU B presence <i>This element is only shown in detail mode.</i>
psu-b-fail-vin-ac-nok	Parameter type: <Alarm::psuBFailVinACNOK> (yes no) Possible values: - yes : PSU B failure input AC voltage - no : PSU B input AC voltage OK	current status of PSU B input AC voltage alarm <i>This element is only shown in detail mode.</i>
psu-b-fail-vin-uv	Parameter type: <Alarm::psuBFailVinUV>	current status of PSU B input

103 Alarm Snap-shot Status Commands

name	Type	Description
	(yes no) Possible values: - yes : PSU B failure input under voltage - no : PSU B input voltage OK	under voltage alarm <i>This element is only shown in detail mode.</i>
psu-b-fail-vin-ov	Parameter type: <Alarm::psuBFailVinOV> (yes no) Possible values: - yes : PSU B failure input over voltage - no : PSU B input voltage OK	current status of PSU B input over voltage alarm <i>This element is only shown in detail mode.</i>
psu-b-fail-vout-uv	Parameter type: <Alarm::psuBFailVoutUV> (yes no) Possible values: - yes : PSU B failure output under voltage - no : PSU B output voltage OK	current status of PSU B output under voltage alarm <i>This element is only shown in detail mode.</i>
psu-b-fail-vout-ov	Parameter type: <Alarm::psuBFailVoutOV> (yes no) Possible values: - yes : PSU B failure output over voltage - no : PSU B output voltage OK	current status of PSU B output over voltage alarm <i>This element is only shown in detail mode.</i>
psu-b-fail-iout-oc	Parameter type: <Alarm::psuBFailIoutOC> (yes no) Possible values: - yes : PSU B failure output over current - no : PSU B output current OK	current status of PSU B output over current alarm <i>This element is only shown in detail mode.</i>
psu-b-fail-overtemp	Parameter type: <Alarm::psuBFailOverTemp> (yes no) Possible values: - yes : PSU B failure over temperature - no : PSU B temperature OK	current status of PSU B temperature alarm <i>This element is only shown in detail mode.</i>

103.150 Ethernet Ring Alarm SnapShot Status Command

Command Description

This command displays ethernet ring Snapshot alarm status

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

> show alarm snap-shot ethernet-ring [(index)]

Command Parameters

Table 103.150-1 "Ethernet Ring Alarm SnapShot Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	ethernet ring log table index

Command Output

Table 103.150-2 "Ethernet Ring Alarm SnapShot Status Command" Display parameters

Specific Information		
name	Type	Description
eth-ring-instance-id	Parameter type: <UnsignedSignedInteger> - an unsigned integer	ethernet ring instance id where the alarm has occurred <i>This element is only shown in detail mode.</i>
eth-ring-path	Parameter type: <Alarm::EthernetRingPath> (path-a path-b n/a) Possible values: - path-a : path-a of the ethernet ring instance - path-b : path-b of the ethernet ring instance - n/a : not applicable for the alarm, fop-pm	unique identification for the alarm, which identifies the path of the ethernet ring instance <i>This element is only shown in detail mode.</i>
Only Show Details: alarm snap-shot status		
name	Type	Description
eth-ring-fwd-st	Parameter type: <Alarm::EthernetRingPathFwdState> (blocked	specifies the forward state of the ethernet ring path

103 Alarm Snap-shot Status Commands

name	Type	Description
	unblocked) Possible values: - blocked : ethernet ring path fwd state blocked - unblocked : ethernet ring path fwd state unblocked	<i>This element is only shown in detail mode.</i>
eth-ring-fop-to	Parameter type: <Alarm::EthernetRingFOPTIMEOUT> (yes no) Possible values: - yes : fop-to occurred - no : fop-to not occurred	specifies ethernet ring fop-to failure of protocol timeout <i>This element is only shown in detail mode.</i>
eth-ring-fop-pm	Parameter type: <Alarm::EthernetRingFOPPM> (yes no) Possible values: - yes : fop-pm occurred - no : fop-pm not occurred	specifies ethernet ring failure of protocol provision mismatch alarm (fop-pm) <i>This element is only shown in detail mode.</i>

103.151 Lldpmed Alarm Snapshot Status Command

Command Description

This command displays the LLDP-MED alarm snap-shot status.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm snap-shot lldpmed [ (index) ]
```

Command Parameters

Table 103.151-1 "Lldpmed Alarm Snapshot Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm snap shot table index

Command Output

Table 103.151-2 "Lldpmed Alarm Snapshot Status Command" Display parameters

Specific Information		
name	Type	Description
lldpmed	Parameter type: <LLDPMed::LLDPMedPort> (uni : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> / <Eqpt::OntPortId> uni:ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / <Eqpt::Ng2OntSlotId> / <Eqpt::Ng2OntPortId> uni:ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / vuni) Possible values: - uni : uni - uni:ng2 : ngpon2 UNI style identification Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number	identify the provisioned lldpmed port where the alarm has occurred. <i>This element is always shown.</i>

103 Alarm Snap-shot Status Commands

name	Type	Description
	Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Eqpt::OntId> - the ONT identifier Field type <Eqpt::ChannelGroupId> - the channel group identifier Field type <Eqpt::SubChannelGroupId> - the subchannel group identifier Field type <Eqpt::Ng2OntId> - the NG2 ONT identifier Possible values: - vuni : virtual NGPON2 uni identifier Field type <Eqpt::OntSlotId> - the ONT SLOT identifier Field type <Eqpt::OntPortId> - the ONT PORT identifier Field type <Eqpt::Ng2OntSlotId> - the NGPON2 ONT SLOT identifier Field type <Eqpt::Ng2OntPortId> - the NGPON2 ONT PORT identifier	
lldpmed-portcfg-mis	Parameter type: <Alarm::LLDPMED-portcfg-mismatch> (yes no) Possible values: - yes : configuration request not accepted - no : configuration accepted	current status of the alarm specifying if the configuration for a provisioned lldpmed port is accepted or not. <i>This element is always shown.</i>
lldpmed-mediapl-mis	Parameter type: <Alarm::LLDPMED-mediapl-mismatch> (yes no) Possible values: - yes : configuration request not accepted - no : configuration accepted	current status of the alarm specifying if the configuration for a provisioned lldpmed port is accepted or not. <i>This element is always shown.</i>

103.152 Alarm Snap-shot Lag-group Status Command

Command Description

This command show the alarm snap-shot of lag group

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

> show alarm snap-shot link-aggr [(index)]

Command Parameters

Table 103.152-1 "Alarm Snap-shot Lag-group Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm snap shot table index

Command Output

Table 103.152-2 "Alarm Snap-shot Lag-group Status Command" Display parameters

Specific Information		
name	Type	Description
group	Parameter type: <Itf::LaGroupIndex> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number	identifies lag group index <i>This element is only shown in detail mode.</i>
la-oper-down	Parameter type: <Alarm::LaGroupDown> (yes no) Possible values: - yes : link group operation down	snap shot of link group operation down <i>This element is only shown in detail mode.</i>

103 Alarm Snap-shot Status Commands

name	Type	Description
	- no : link group operation up	
standby-not-available	Parameter type: <Alarm::StandbyUnavailable> (yes no) Possible values: - yes : lack of link-up ports on standby slot - no : link-up ports enough on standby slot	snap shot of unavailable standby slot <i>This element is only shown in detail mode.</i>
switch-fail	Parameter type: <Alarm::LaSwitchFail> (yes no) Possible values: - yes : switchover failed for cross-lt la group - no : switchover is successful for cross-lt la group	snap shot of switchover failure <i>This element is only shown in detail mode.</i>
la-degrade	Parameter type: <Alarm::LaDegrade> (yes no) Possible values: - yes : lack of link-up ports on active slot - no : link-up ports enough on active slot	snap shot of lag degradation <i>This element is only shown in detail mode.</i>

103.153 Alarm Snap-shot 40GBase-KR4 fcs exceed Status Command

Command Description

This command show the alarm snap-shot of 40GBase-KR4 fcs exceed

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

> show alarm snap-shot fcs-exceed [(index)]

Command Parameters

Table 103.153-1 "Alarm Snap-shot 40GBase-KR4 fcs exceed Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm snap shot table index

Command Output

Table 103.153-2 "Alarm Snap-shot 40GBase-KR4 fcs exceed Status Command" Display parameters

Specific Information		
name	Type	Description
slot	Parameter type: <Equipm::EqptSlotIndex> (lt : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> nt-a nt-b nt acu : <Eqpt::RackId> / <Eqpt::ShelfId> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::EqSlotId> ext-a : <Eqpt::RackId> / <Eqpt::ShelfId> ext-b : <Eqpt::RackId> / <Eqpt::ShelfId> ctrl : <Eqpt::RackId> / <Eqpt::ShelfId> vlt : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::VirtualSlotId>) Possible values: - lt : lt-slot - vlt : virtual LT slot (VVPS board can only be planned at	identifies index <i>This element is only shown in detail mode.</i>

103 Alarm Snap-shot Status Commands

name	Type	Description
	NANT-E / FANT-F) - nt-a : nt-a slot - nt-b : nt-b slot - nt : nt slot - ext-a : nt-a slot in an extension shelf - ext-b : nt-b slot in an extension shelf - acu : acu slot - ctrl : ctrl-slot Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::VirtualSlotId> - the virtual LT slot number Field type <Eqpt::EqSlotId> - the equipment slot number	
nta/b	Parameter type: <UnsignedSignedInteger> - an unsigned integer	identifies index2 <i>This element is only shown in detail mode.</i>
fcs-is-exceed	Parameter type: <Alarm::almtypeFCSthreshexceed> (yes no) Possible values: - yes : FCS auto-recovery counter exceeded threshold - no : FCS auto-recovery counter not exceeded threshold	snap shot of whether fcs auto-recovery counter is exceed or not <i>This element is only shown in detail mode.</i>

104- Current Alarm Status Commands

104.1 Current Alarm Status Command Tree	104-4793
104.2 Alarm Current Status Command	104-4799
104.3 Equipment Current Alarm Status Command	104-4807
104.4 Equipment Holder Current Alarm Status Command	104-4810
104.5 Equipment Holder Extended Current Alarm Status Command	104-4812
104.6 Plug-in Unit Current Alarm Status Command	104-4814
104.7 ATM Current Alarm Status Command	104-4817
104.8 Ethernet Interface Current Alarm Status Command	104-4819
104.9 Software Management Current Alarm Status Command	104-4820
104.10 Temporal Filter Current Alarm Status Command	104-4822
104.11 Spatial Filter Current Alarm Status Command	104-4826
104.12 xDSL Current Alarm Status Command	104-4830
104.13 TCA xDSL Current Alarm Status Command	104-4834
104.14 OLT General Current Alarm Status Command	104-4838
104.15 Vectoring Line Current Alarm Status Command	104-4842
104.16 Vectoring Board Current Alarm Status Command	104-4844
104.17 Electrical-to-Optical Conversion Current Alarm Status Command	104-4846
104.18 Authentication Current Alarm Status Command	104-4848
104.19 xDSL Bonding Current Alarm Status Command	104-4851
104.20 Redundancy Current Alarm Status Command	104-4854
104.21 Custom Current Alarm Status Command	104-4855
104.22 SFP Current Alarm Status Command	104-4859
104.23 Custom External Current Alarm Status Command	104-4863
104.24 SFP RSSI Current Alarm Status Command	104-4865
104.25 PPP Cross-Connect Engine TCA Current Alarm Status Command	104-4870
104.26 Epon Olt Sfp RSSI Current Alarm Status Command	104-4872
104.27 2xE1/DS1 SFP Clock Current Alarm Status Command	104-4876
104.28 2xE1/DS1 SFP Framer Alarm Status Command	104-4879
104.29 Plug In Unit Extended Current Alarm Status Command	104-4883
104.30 SIP Server Current Alarm Status Command	104-4887
104.31 SIP VSP Current Alarm Status Command	104-4888
104.32 SIP Dial Plan Current Alarm Status Command	104-4891
104.33 SIP User Agent Current Alarm Status Command	104-4892
104.34 SIP Slot Current Alarm Status Command	104-4894
104.35 SIP Termination Current Alarm Status Command	104-4896
104.36 Secondary SIP Termination Current Alarm Status Command	104-4900
104.37 SIP Termination Current Alarm Status Command	104-4903
104.38 E1T1 Interface Current Alarm Status Command	104-4906
104.39 SIP Termination Current Alarm Status Command	104-4908
104.40 Pseudo Wire Current Alarm Status Command	104-4910
104.41 Megaco Media Gateway Current Alarm Status Command	104-4912
104.42 Megaco Signaling Gateway Current Alarm Status	104-4914

Command	
104.43 Megaco Plugin Unit Current Alarm Status	104-4916
Command	
104.44 Megaco Termination Current Alarm Status	104-4918
Command	
104.45 Secondary Megaco Termination Current Alarm Status Command	104-4920
104.46 Megaco Signaling Lt Current Alarm Status	104-4922
Command	
104.47 E1Current Alarm Status Command	104-4924
104.48 Shdsl Current Alarm Status Command	104-4926
104.49 Shdsl Current Alarm Status Command	104-4928
104.50 Ima-Group Current Alarm Status Command	104-4930
104.51 Ima-Link Current Alarm Status Command	104-4932
104.52 Alarm Current Ether-Tca Status Command	104-4934
104.53 Alarm Current Ether-Sfp Status Command	104-4936
104.54 Alarm Current Ether-Sfp Status Command	104-4938
104.55 Alarm Current Qos Slot Status Command	104-4940
104.56 Alarm Current Qos Queue Status Command	104-4942
104.57 Alarm File Transfer Server Status Command	104-4945
104.58 Alarm LSM Redundancy Status Command	104-4946
104.59 Alarm L2 Forward Status Command	104-4948
104.60 Alarm Current External Device Status Command	104-4951
104.61 Multicast Source Current Alarm Status Command	104-4952
104.62 Vlanport Current Alarm Status Command	104-4954
104.63 BGP Current Alarm Status Command	104-4957
104.64 RIP Current Alarm Status Command	104-4959
104.65 LAG Current Alarm Status Command	104-4960
104.66 ihub-general Current Alarm Status Command	104-4962
104.67 VPRN Current Alarm Status Command	104-4964
104.68 ISIS Current Alarm Status Command	104-4966
104.69 Ospf Current Alarm Status Command	104-4968
104.70 ihub-l2forward Current Alarm Status Command	104-4970
104.71 VPLS Current Alarm Status Command	104-4972
104.72 IHUB-Equip Current Alarm Status Command	104-4974
104.73 ihub-link Current Alarm Status Command	104-4976
104.74 ihub-tca Current Alarm Status Command	104-4979
104.75 LDP Current Alarm Status Command	104-4982
104.76 MPLS Current Alarm Status Command	104-4984
104.77 SDP Current Alarm Status Command	104-4986
104.78 IHUB IPV6 Current Alarm Status Command	104-4988
104.79 EPIPE Current Alarm Status Command	104-4990
104.80 PIM Current Alarm Status Command	104-4991
104.81 IHUB Lawful Intercept Current Alarm Status	104-4993
Command	
104.82 Sync Clock Current Alarm Status Command	104-4995
104.83 Equipment Supplemental Current Alarm Status	104-4999
Command	
104.84 Otdr Current Alarm Status Command	104-5001
104.85 Management Security Access Current Alarm Status	104-5007
Command	
104.86 IHUB BFD Current Alarm Status Command	104-5009
104.87 Application Intelligence Current Alarm Status	104-5011
Command	
104.88 Tr069 Alarm Status Command	104-5013
104.89 ONT SNMP Current Alarm Status Command	104-5015
104.90 Bulk Sync Alarm Log Status Command	104-5017
104.91 Protection Group Alarm Log Status Command	104-5019
104.92 Ont protection Alarm Log Status Command	104-5021
104.93 ONT General Supplemental Current Alarm Status	104-5023
Command	
104.94 SFU ONT General Supplemental Current Alarm	104-5027

Status Command	
104.95 SOHO ONT General Supplemental Current Alarm	104-5031
Status Command	
104.96 MDU ONT General Supplemental Current Alarm	104-5035
Status Command	
104.97 ONT General Supplemental 2 Current Alarm Status	104-5039
Command	
104.98 SFU ONT General Supplemental 2 Current Alarm	104-5042
Status Command	
104.99 SOHO ONT General Supplemental 2 Current Alarm	104-5045
Status Command	
104.100 MDU ONT General Supplemental 2 Current Alarm	104-5048
Status Command	
104.101 Ellid Alarm Status Command	104-5051
104.102 Ima-Group Alarm Log Status Command	104-5058
104.103 Ima-Group Alarm Log Status Command	104-5064
104.104 Ima-Group Alarm Log Status Command	104-5070
104.105 Ima-Group Alarm Log Status Command	104-5076
104.106 Ima-Group Alarm Log Status Command	104-5082
104.107 LT CFM Current Alarm Status Command	104-5084
104.108 IHUB Eth Cfm Current Alarm Status Command	104-5086
104.109 RSVP Current Alarm Status Command	104-5088
104.110 IPD eth-ring Current Alarm Status Command	104-5090
104.111 EFM-OAM Current Alarm Status Command	104-5092
104.112 Ont loop detect Current Alarm Status Command	104-5094
104.113 ONT PLOAM Current Alarm Status Command	104-5097
104.114 SFU ONT PLOAM Current Alarm Status Command	104-5101
104.115 SOHO ONT PLOAM Current Alarm Status	104-5105
Command	
104.116 MDU ONT PLOAM Current Alarm Status Command	104-5109
104.117 ONT General Current Alarm Status Command	104-5113
104.118 SFU ONT General Current Alarm Status Command	104-5117
104.119 SOHO ONT General Current Alarm Status	104-5121
Command	
104.120 MDU ONT General Current Alarm Status	104-5125
Command	
104.121 ONT SUBSCRIBER CARD Current Alarm Status	104-5129
Command	
104.122 ONT SERVICES POTS Current Alarm Status	104-5131
Command	
104.123 ONT SERVICES LAN Current Alarm Status	104-5136
Command	
104.124 ONT TCA Current Alarm Status Command	104-5138
104.125 ONT TC TCA Current Alarm Status Command	104-5140
104.126 ONT L2 UNI Ethernet TCA Current Alarm Status	104-5142
Command	
104.127 OLT PON TC TCA Current Alarm Status Command	104-5144
104.128 OLT PON Utilization TCA Current Alarm Status	104-5146
Command	
104.129 OLT Channel Pair Utilization TCA Current Alarm	104-5150
Status Command	
104.130 OLT ONT TC TCA Current Alarm Status Command	104-5154
104.131 ONT POTS SUPPLEMENTAL Current Alarm Status	104-5156
Command	
104.132 ONT VEIP Current Alarm Status Command	104-5159
104.133 ONT IP HOST Current Alarm Status Command	104-5161
104.134 Alarm Table Current Alarm Status Command	104-5163
104.135 ONT VIDEO Current Alarm Status Command	104-5164
104.136 ONT CES Current Alarm Status Command	104-5166
104.137 ONT VOIP Current Alarm Status Command	104-5168
104.138 ONT VIDEO ANI Current Alarm Status Command	104-5173
104.139 ONT PWE Current Alarm Status Command	104-5175

104.140 ONT CESE1 Current Alarm Status Command	104-5177
104.141 ONT XDSL Current Alarm Status Command	104-5179
104.142 ONT XDSL TCA Current Alarm Status Command	104-5182
104.143 ONT HPNA Current Alarm Status Command	104-5184
104.144 ONT SIP AGENT CFG Current Alarm Status Command	104-5186
104.145 ONT VOIP CFG Current Alarm Status Command	104-5189
104.146 ONT MGC Current Alarm Status Command	104-5193
104.147 ONT MoCA Current Alarm Status Command	104-5195
104.148 ONT MoCA Threshold Crossing Alert (TCA) Current Alarm Status Command	104-5197
104.149 Auto-Switch Current Alarm Status Command	104-5199
104.150 Channel Pair Current Alarm Status Command	104-5201
104.151 Channel Pair OLT TC TCA Current Alarm Status Command	104-5204
104.152 Ont Configuration Download Current Alarm Status Command	104-5206
104.153 HGU TR069 Current Alarm Status Command	104-5209
104.154 Equipment Holder Extended Current Alarm Status Command	104-5214
104.155 Ethernet Ring Current Alarm Status Command	104-5215
104.156 LldpMed Current Alarm Status Command	104-5217
104.157 Lag group Current Alarm Status Command	104-5219
104.158 40GBase-KR4 fcs exceed Current Alarm Status Command	104-5221

104.1 Current Alarm Status Command Tree

Description

This chapter gives an overview of nodes that are handled by "Current Alarm Status Commands".

Command Tree

```

----show
  ----alarm
    ----current
      ----table
        - (index)
      ----equipment
        - (index)
      ----eqpt-holder
        - (index)
      ----eqpt-holder-ext
        - (index)
      ----plug-in-unit
        - (index)
      ----atm
        - (index)
      ----ether-itf
        - (index)
      ----sw-mgmt
        - (index)
      ----temporal
        - (index)
      ----spatial
        - (index)
      ----xdsl
        - (index)
      ----xdsl-tca
        - (index)
      ----olt-gen
        - (index)
      ----vect-line
        - (index)
      ----vect-board
        - (index)
      ----eo-conversion
        - (index)
      ----authentication
        - (index)
      ----bonding-group
        - (index)
      ----redundancy
        - (index)
      ----custom
        - (index)
      ----sfp
        - (index)
      ----custom-ext-alarm

```

- (index)
- sfprssi
 - (index)
- pppcc-engine-tca
 - (index)
- eoltrssi
 - (index)
- sfpe1t1-clock
 - (index)
- sfpe1t1-framer
 - (index)
- plug-in-unit-ext
 - (index)
- sip-server
 - (index)
- sip-vsp
 - (index)
- sip-dial-plan
 - (index)
- sip-user-agent
 - (index)
- sip-plugin-unit
 - (index)
- sip-termination
 - (index)
- secondary-sip-term
 - (index)
- e1-sip-termination
 - (index)
- e1t1-interface
 - (index)
- cas-r2-channel
 - (index)
- pseudo-wire
 - (index)
- megaco-media-gw
 - (index)
- megaco-sig-gw
 - (index)
- megaco-plugin-unit
 - (index)
- megaco-term
 - (index)
- secondary-megaco-term
 - (index)
- megaco-sig-lt
 - (index)
- e1
 - (index)
- shdsl
 - (index)
- shdsl-isam
 - (index)
- ima-group
 - (index)
- ima-link
 - (index)
- ether-tca
 - (index)

- ether-sfp
 - (index)
- uplink-ether-sfp
 - (index)
- qos-slot
 - (index)
- qos-queue
 - (index)
- filetransfer
 - (index)
- lsmredundancy
 - (index)
- l2forward
 - (index)
- external-device
 - (index)
- mcsrc
 - (index)
- vlanport
 - (index)
- bgp
 - (index)
- rip
 - (index)
- lag
 - (index)
- ihub-general
 - (index)
- vprn
 - (index)
- isis
 - (index)
- ospf
 - (index)
- ihub-l2forward
 - (index)
- vpls
 - (index)
- ihub-equip
 - (index)
- ihub-link
 - (index)
- ihub-tca
 - (index)
- ldp
 - (index)
- mpls
 - (index)
- sdp
 - (index)
- ihub-ipv6
 - (index)
- epipe
 - (index)
- pim
 - (index)
- li
 - (index)
- sync

- (index)
- eqpt-supplemental
 - (index)
- otdr
 - (index)
- mgmt-sec-access
 - (index)
- bfd
 - (index)
- ai
 - (index)
- tr069serv
 - (index)
- ontsnmp
 - (index)
- bulk-sync
 - (index)
- protection-group
 - (index)
- ont-protection
 - (index)
- ont
 - (index)
- sfu-sup
 - (index)
- soho-sup
 - (index)
- mdu-sup
 - (index)
- ont-ani
 - (index)
- sfu-sup2
 - (index)
- soho-sup2
 - (index)
- mdu-sup2
 - (index)
- ellid
 - (alarm-index)
- epon
 - (alarm-index)
- eont-phyoam
 - (index)
- eont-services-lan
 - (alarm-index)
- eolt-ont-tca
 - (alarm-index)
- eont-sw-dl
 - (alarm-index)
- cfm
 - (index)
- eth-cfm
 - (index)
- rsvp
 - (index)
- eth-ring
 - (index)
- efm-oam
 - (index)

----ont-loopdetect
- (index)
----ont-ploam
- (index)
----sfu-ploam
- (index)
----soho-ploam
- (index)
----mdu-ploam
- (index)
----ont-gen
- (index)
----sfu-gen
- (index)
----soho-gen
- (index)
----mdu-gen
- (index)
----ont-card
- (index)
----ont-pots
- (index)
----ont-lan
- (index)
----ont-tca
- (index)
----ont-tc-tca
- (index)
----ont-l2uni-eth-tca
- (index)
----olt-pon-tc-tca
- (index)
----olt-pon-util-tca
- (index)
----olt-chpr-util-tca
- (index)
----olt-ont-tc-tca
- (index)
----ont-pots-supplemental
- (index)
----ont-veip
- (index)
----ont-iphost
- (index)
----alarm-table
- (index)
----ont-video
- (index)
----ont-ces
- (index)
----ont-voip
- (index)
----ont-video-ani
- (index)
----ont-pwe
- (index)
----ont-cese1
- (index)
----ont-xdsl

- (index)
- ont-xdsl-tca
 - (index)
- ont-hpna
 - (index)
- ont-sip-agent-cfg
 - (index)
- ont-voip-cfg
 - (index)
- ont-mgc
 - (index)
- ont-moca
 - (index)
- ont-moca-tca
 - (index)
- auto-switch
 - (index)
- channel-pair
 - (index)
- olt-chpair-tc-tca
 - (index)
- ont-cfg-dld
 - (index)
- hgu-tr069
 - (index)
- eqpt-psu
 - (index)
- ethernet-ring
 - (index)
- lldpmed
 - (index)
- link-agg
 - (index)
- fcs-exceed
 - (index)

104.2 Alarm Current Status Command

Command Description

This command displays all current alarms.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

> show alarm current table [(index)]

Command Parameters

Table 104.2-1 "Alarm Current Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm type

Command Output

Table 104.2-2 "Alarm Current Status Command" Display parameters

Specific Information		
name	Type	Description
type	Parameter type: <Alarm::alarmIHUBType> (equipment eqpt-holder plug-in-unit atm custom e1 ima-group ima-link redundancy shdsl ether-itf traffic-overflow qos-queue temporal spatial (software-mngt sw-mgmt) xdsl xdsl-ext xdsl-tca	type of the alarms that are active. <i>This element is always shown.</i>

104 Current Alarm Status Commands

name	Type	Description
	olt-gen	
	eo-conv	
	authentication	
	bonding	
	sfp	
	shdsl-isam	
	custom-ext-alarm	
	plug-in-unit-ext	
	sip-user-agent	
	sip-plugin-unit	
	sip-termination	
	e1-sip-termination	
	filetransfer	
	external-device	
	l2forward	
	ether-tca	
	ether-sfp	
	megaco-media-gw	
	megaco-sig-gw	
	megaco-plug-unit	
	megaco-term	
	megaco-sig-lt	
	eqpt-supplemental	
	eqpt-holder-ext	
	lsmredundancy	
	sync	
	mcsrc	
	vlanport	
	vect-line	
	vect-board	
	otdr	
	sip-dial-plan	
	sip-vsp	
	sip-server	
	bgp	
	rip	
	lag	
	ihub-general	
	vprn	
	isis	
	ospf	
	ihub-l2forward	
	vpls	
	ihub-equip	
	ihub-link	
	eont-phyoam	
	ellid	
	epon	
	eont-services-lan	
	eolt-ont-tca	
	eont-sw-dl	
	ldp	
	mpls	
	sdp	
	epipe	
	ihub-ipv6	
	pim	

name	Type	Description
	li	
	mgmt-sec-access	
	bfd	
	ai	
	tr069serv	
	ontsnmp	
	bulk-sync	
	protection-group	
	ont	
	sfu-sup	
	soho-sup	
	mdu-sup	
	ont-ani	
	sfu-sup2	
	soho-sup2	
	mdu-sup2	
	sfprssi	
	eoltrssi	
	cfm	
	sfpe1t1-framer	
	sfpe1t1-clock	
	pppcc-engine-tca	
	eth-cfm	
	rsvp	
	ihub-tca	
	eth-ring	
	efm-oam	
	ont-loopdetect	
	ont-video	
	ont-ces	
	ont-voip	
	ont-video-ani	
	ont-pwe	
	ont-cese1	
	ont-xdsl	
	ont-xdsl-tca	
	ont-hpna	
	ont-sip-agent-cfg	
	ont-voip-cfg	
	ont-mgc	
	ont-ploam	
	ont-gen	
	ont-card	
	ont-pots	
	ont-lan	
	ont-moca	
	ont-tc-tca	
	ont-moca-tca	
	ont-l2uni-eth-tca	
	olt-pon-tc-tca	
	olt-pon-util-tca	
	olt-chpr-util-tca	
	olt-ont-tc-tca	
	ont-tca	
	ont-pots-supplemental	
	sfu-ploam	
	sfu-gen	

104 Current Alarm Status Commands

name	Type	Description
	soho-ploam soho-gen mdu-ploam mdu-gen ont-veip ont-iphost alarm-table auto-switch channel-pair ont-cfg-dld olt-chpair-tc-tca hgu-tr069 eqpt-psu ont-protection secondary-megaco-term secondary-sip-term cas-r2-channel lldpmed pseudo-wire link-agg fcs-exceed e1t1-interface) Possible values: - equipment : equipment alarms - eqpt-holder : equipment holder alarms - plug-in-unit : plugin unit alarms - atm : ATM alarms - custom : customizable alarms - e1 : e1 alarms - ima-group : ima-group alarms - ima-link : ima-link alarms - redundancy : redundancy alarms - shdsl : shdsl alarms - ether-itf : ethernet interface alarms - traffic-overflow : Traffic overflow alarms - qos-queue : qos queue alarms - temporal : temporal alarms - spatial : spatial alarms - software-mngt : software management alarms - sw-mgmt : software management alarms - xdsl : xDSL alarms - xdsl-ext : other xDSL alarms - xdsl-tca : xDSL threshold cross alarms - olt-gen : OLT general alarms - eo-conv : E/O conversion related alarms - authentication : authentication related alarms - bonding : bonding-group related alarms - sfp : SFP related alarms - shdsl-isam : shdsl isam alarms - custom-ext-alarm : customizable external alarms - plug-in-unit-ext : other plugin unit alarms - sip-user-agent : sip user agent related alarms - sip-plugin-unit : sip plug in unit related alarms - sip-termination : sip termination related alarms - e1-sip-termination : E1 sip termination related alarms - filetransfer : file transfer server alarms - external-device : external device related alarms	

name	Type	Description
	- l2forward : l2forward related alarms - ether-tca : ethernet threshold cross alarms - ether-sfp : ethernet SFP related alarms - megaco-media-gw : megaco media gateway related alarms - megaco-sig-gw : megaco signaling gateway related alarms - megaco-plug-unit : megaco plug unit related alarms - megaco-term : megaco termination related alarms - megaco-sig-lt : megaco signaling lt related alarms - eqpt-supplemental : equipment supplemental alarms - eqpt-holder-ext : other equipment holder alarms - lsmredundancy : lsm redundancy alarms - sync : synce and bits alarms - mcsrc : multicast source alarms - vlanport : vlanport alarms - vect-line : xDSL vectoring line alarms - vect-board : xDSL vectoring board alarms - otdr : otdr alarms - sip-dial-plan : sip dial plan related alarms - sip-vsp : sip vsp related alarms - sip-server : sip server related alarms - bgp : bgp related alarms - rip : rip related alarms - lag : LAG related alarms - ihub-general : IHUB general related alarms - vprn : vprn related alarms - isis : isis related alarms - ospf : ospf related alarms - ihub-l2forward : ihub-l2forward alarms - vpls : vpls related alarms - ihub-equip : ihub-equip related alarms - ihub-link : ihub-link related alarms - eont-phyoam : eont phyoam related alarms - ellid : ellid related alarms - epon : epon related alarms - eont-services-lan : eon phyoam related alarms - eolt-ont-tca : eon phyoam related alarms - eont-sw-dl : eon phyoam related alarms - ldp : ldp related alarms - mpls : mpls related alarms - sdp : sdp related alarms - epipe : epipe related alarms - ihub-ipv6 : ihub-ipv6 related alarms - pim : pim related alarms - li : lawful intercept related alarms - mgmt-sec-access : management security related alarms - bfd : bfd related alarms - ai : Application Intelligence related alarms - tr069serv : tr069 server related alarms - ontsnmp : ont snmp related alarms - bulk-sync : bulk-sync related alarms - protection-group : port protection group related alarms - ont : ONT general supplemental related alarms - sfu-sup : SFU ONT general supplemental related alarms - soho-sup : SOHO ONT general supplemental related alarms - mdu-sup : MDU ONT general supplemental related alarms - ont-ani : ONT general supplemental 2 related alarms	

104 Current Alarm Status Commands

name	Type	Description
	- sfu-sup2 : SFU ONT general supplemental 2 related alarms - soho-sup2 : SOHO ONT general supplemental 2 related alarms - mdu-sup2 : MDU ONT general supplemental 2 related alarms - sfprssi : SFP RSSI related alarms - eoltrssi : epon olt Sfp RSSI related alarms - cfm : Cfm related alarms - sfpe1t1-framer : SFP 2e1t1 framer alarms - sfpe1t1-clock : SFP 2e1t1 clock alarms - pppcc-engine-tca : PPPOE Cross Connect Engine TCA related alarm - eth-cfm : eth-cfm related alarms - rsvp : rsvp related alarms - ihub-tca : IHUB TCA related alarms - eth-ring : eth-ring related alarms - efm-oam : EFM-OAM related alarms - ont-loopdetect : ont loop detect related alarms - ont-video : ont services video related alarms - ont-ces : ont services ces related alarms - ont-voip : ont services voip related alarms - ont-video-ani : ont services video ani related alarms - ont-pwe : ont services pwe related alarms - ont-cese1 : ont services cese1 related alarms - ont-xdsl : ont services xdsl related alarms - ont-xdsl-tca : ont services xdsl tca related alarms - ont-hpna : ont hpna related alarms - ont-sip-agent-cfg : ont services voip sip agent config related alarms - ont-voip-cfg : ont services voip config related alarms - ont-mgc : ont mgc related alarms - ont-ploam : ONT PLOAM related alarms - ont-gen : ONT GENERAL related alarms - ont-card : ONT Subscriber Card related alarms - ont-pots : ONT Services POTS related alarms - ont-lan : ONT Services LAN related alarms - ont-moca : ONT MoCA related alarms - ont-tc-tca : ONT TC TCA related alarms - ont-moca-tca : ONT MoCA TCA related alarms - ont-l2uni-eth-tca : ONT L2 UNI Ethernet TCA related alarms - olt-pon-tc-tca : OLT PON TC TCA related alarms - olt-pon-util-tca : OLT PON utilization TCA related alarms - olt-chpr-util-tca : OLT channel-pair utilization TCA related alarms - olt-ont-tc-tca : OLT ONT TC TCA related alarms - ont-tca : ONT TCA related alarms - ont-pots-supplemental : ONT POTS Supplemental related alarms - sfu-ploam : SFU ONT PLOAM related alarms - sfu-gen : SFU ONT general related alarms - soho-ploam : SOHO ONT PLOAM related alarms - soho-gen : SOHO ONT general related alarms - mdu-ploam : MDU ONT PLOAM related alarms - mdu-gen : MDU ONT general related alarms - ont-veip : ONT VEIP related alarms - ont-iphost : ONT IP HOST related alarms	

name	Type	Description
	- alarm-table : alarm table related alarms - auto-switch : auto-switch related alarms - channel-pair : channel pair related alarms - ont-cfg-dld : ont configure file download related alarms - olt-chpair-tc-tca : OLT CHANNELPAIR TC TCA related alarms - hgu-tr069 : hgu tr069 related alarms - eqpt-psu : equipment psu alarms - ont-protection : ONT protection related alarms - secondary-megaco-term : secondary megaco termination related alarms - secondary-sip-term : secondary sip termination related alarms - cas-r2-channel : CAS R2 channel related alarms - lldpmed : lldpmed alarms - pseudo-wire : pseudo Wire related alarms - link-agg : Link aggregation related alarms - fcs-exceed : FCS auto-recovery related alarms - e1t1-interface : E1/T1 physical interfaces related alarms	
last-updated-on	Parameter type: <Sys::timeInSecs> - the time (yyyy-mm-dd:hour:minutes:secs) - unit: UTC	time in seconds when the entry was updated. <i>This element is always shown.</i>

Only Show Details: number of changes since start up and number of entries in the table

name	Type	Description
changes	Parameter type: <Counter> - 32 bit counter	number of changes that have occurred since startup. <i>This element is only shown in detail mode.</i>
entries	Parameter type: <Gauge> - gauge	number of entries <i>This element is only shown in detail mode.</i>
tot-delta-log	Parameter type: <UnsignedSignedInteger> - an unsigned integer	total number of delta log entries <i>This element is only shown in detail mode.</i>

Only Show Details: active severities in the table

name	Type	Description
indeterminate	Parameter type: <Alarm::IndetSevState> (active not-active) Possible values: - active : at least one entry of this severity is present - not-active : no entries of this severity	status of the severity type indeterminate <i>This element is only shown in detail mode.</i>
warning	Parameter type: <Alarm::WarnSevState> (active not-active) Possible values: - active : at least one entry of this severity is present - not-active : no entries of this severity	status of the severity type warning <i>This element is only shown in detail mode.</i>
minor	Parameter type: <Alarm::MinorSevState> (active not-active) Possible values: - active : at least one entry of this severity is present - not-active : no entries of this severity	status of the severity type minor <i>This element is only shown in detail mode.</i>
major	Parameter type: <Alarm::MajorSevState> (active	status of the severity type major <i>This element is only shown in</i>

104 Current Alarm Status Commands

name	Type	Description
	not-active) Possible values: - active : at least one entry of this severity is present - not-active : no entries of this severity	<i>detail mode.</i>
critical	Parameter type: <Alarm::CriticalSevState> (active not-active) Possible values: - active : at least one entry of this severity is present - not-active : no entries of this severity	status of the severity type critical <i>This element is only shown in detail mode.</i>

104.3 Equipment Current Alarm Status Command

Command Description

This command displays the equipment current alarm status.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

> show alarm current equipment [(index)]

Command Parameters

Table 104.3-1 "Equipment Current Alarm Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm type

Command Output

Table 104.3-2 "Equipment Current Alarm Status Command" Display parameters

Specific Information		
name	Type	Description
persist-data	Parameter type: <Alarm::persistDataLoss> (lost not-lost) Possible values: - lost : persistant data is lost - not-lost : persistant data is not lost	current status specifying persistant data is lost or not <i>This element is only shown in detail mode.</i>
sntp-comm	Parameter type: <Alarm::sntpCommLoss> (lost not-lost) Possible values: - lost : SNTP communication lost - not-lost : SNTP communication is not lost	current status of sntp communication is lost or not <i>This element is only shown in detail mode.</i>
cf-error	Parameter type: <Alarm::cfError> ((error cfError) (no-error cfNoError)) Possible values: - error : CF access error - cfError : CF access error - no-error : CF no access error	Compact flash read or write error occurred <i>This element is only shown in detail mode.</i>

104 Current Alarm Status Commands

name	Type	Description
	- cfNoError : CF no access error	
board-with-cf-error	Parameter type: <Equipm::EqptNtSlotIndexOrNone> (nt-a nt-b nt <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::EqSlotId> none none) Possible values: - nt-a : nt-a slot - nt-b : nt-b slot - nt : nt slot - none : board not specified - none : board not specified Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::EqSlotId> - the equipment slot number	Board identification with cf-error <i>This element is only shown in detail mode.</i>
nt-disk	Parameter type: <Alarm::ntDiskSpace> ((nintyfive-perc 95%-full) (less-nintyfive-perc less-than-95%)) Possible values: - nintyfive-perc : NT disk space is 95% full - 95%-full : NT disk space is 95% full - less-nintyfive-perc : NT disk space usage less that 95% - less-than-95% : NT disk space usage less that 95%	current status of nt disk space is 95% full or less than that <i>This element is only shown in detail mode.</i>
preferred-mode short name: pref-mode	Parameter type: <Alarm::clkPrefMode> (not-available available) Possible values: - not-available : Preferred timing mode is not available - available : Preferred Timing mode available	current status of preferred timing mode <i>This element is only shown in detail mode.</i>
timing-reference short name: time-ref	Parameter type: <Alarm::clkFreeMode> (failed available) Possible values: - failed : System is in holdover or free-run mode - available : System is not in holdover or free-run mode	current status of timing reference <i>This element is only shown in detail mode.</i>
connection-lost short name: conn-lost	Parameter type: <Alarm::ShubLoc> (lost not-lost) Possible values: - lost : NT shub communication lost - not-lost : NT shub communication intact	current status of nt shub communication is lost or intact <i>This element is only shown in detail mode.</i>
back-pnl-inv short name: bpnl-inv	Parameter type: <Alarm::BackPnlInv> (invalid valid) Possible values: - invalid : BackPanel-type Invalid - valid : BackPanel-type Valid	current status of BackPanel-type Invalid alarm. <i>This element is only shown in detail mode.</i>
shub-conf-lost short name: conf-lost	Parameter type: <Alarm::SHubCfgLost> (lost not-lost) Possible values: - lost : SHub configuration loss - recent changes lost	actual shub configuration may differ from lanx database on nt <i>This element is only shown in detail mode.</i>

name	Type	Description
	- not-lost : SHub configuration up to date	

104.4 Equipment Holder Current Alarm Status Command

Command Description

This command displays the equipment holder current alarm status.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm current eqpt-holder [ (index) ]
```

Command Parameters

Table 104.4-1 "Equipment Holder Current Alarm Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm type

Command Output

Table 104.4-2 "Equipment Holder Current Alarm Status Command" Display parameters

Specific Information		
name	Type	Description
shelf	Parameter type: <Equipm::Shelf> <Eqpt::RackId> / <Eqpt::ShelfId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number	specify which shelf the alarm occurred on. <i>This element is only shown in detail mode.</i>
rack-power	Parameter type: <Alarm::rackPower> (failing ok) Possible values: - failing : the fuse is broken - ok : the fuse is intact	current status of rack power alarm, indicating fuse is broken or intact <i>This element is only shown in detail mode.</i>
fan-unit1 short name: fan1	Parameter type: <Alarm::fanUnit1> ((failing fail) ok) Possible values:	current status of fan-unit1 <i>This element is only shown in detail mode.</i>

name	Type	Description
	- failing : fan unit 1 is failing - fail : fan unit 1 is failing - ok : fan unit 1 is ok	
fan-unit2 short name: fan2	Parameter type: <Alarm::fanUnit2> ((failing fail) ok) Possible values: - failing : fan unit 2 is failing - fail : fan unit 2 is failing - ok : fan unit 2 is ok	current status of fan-unit2 <i>This element is only shown in detail mode.</i>
shelf-type-mismatch short name: shelf-type	Parameter type: <Alarm::shelfTypeMismatch> (mismatch no-mismatch) Possible values: - mismatch : installed and planned shelf types are different - no-mismatch : installed and planned shelf types are the same	current status specifies installed and planned shelf types are different <i>This element is only shown in detail mode.</i>
ext-chain-instl	Parameter type: <Alarm::extChainInstl> ((consistency-problem inconsistent) (no-consistency-problem ok)) Possible values: - consistency-problem : consistency problem detected for installation of extension chain - inconsistent : consistency problem detected for installation of extension chain - no-consistency-problem: no consistency problem - ok : no consistency problem	current alarm status of consistency problem detected for installation of extension chain <i>This element is only shown in detail mode.</i>
shelf-missing	Parameter type: <Alarm::shelfMissing> (missing not-missing) Possible values: - missing : detected shelf now missing - not-missing : detected shelf was missing, now reinserted	current status specifies once inserted shelf has gone missing <i>This element is only shown in detail mode.</i>
shelf-install-missing	Parameter type: <Alarm::shelfInstall> (yes no) Possible values: - yes : shelf now installed - no : shelf now not installed	current status specifies shelf is planned but not installed <i>This element is only shown in detail mode.</i>
door	Parameter type: <Alarm::door> ((failing fail) ok) Possible values: - failing : the cabinet door is opened - fail : the cabinet door is opened - ok : the cabinet door is closed	current status of door alarm, indicating the cabinet door is opened <i>This element is only shown in detail mode.</i>
ac-power-fail short name: ac-pwr	Parameter type: <Alarm::acPowerFail> ((failing fail) ok) Possible values: - failing : system AC power fails - fail : system AC power fails - ok : the system AC power works properly	current status of AC power failure alarm, indicating the AC Power is broken <i>This element is only shown in detail mode.</i>

104.5 Equipment Holder Extended Current Alarm Status Command

Command Description

This command displays the equipment holder extended current alarm status.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

> show alarm current eqpt-holder-ext [(index)]

Command Parameters

Table 104.5-1 "Equipment Holder Extended Current Alarm Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm type

Command Output

Table 104.5-2 "Equipment Holder Extended Current Alarm Status Command" Display parameters

Specific Information		
name	Type	Description
shelf	Parameter type: <Equipm::Shelf> <Eqpt::RackId> / <Eqpt::ShelfId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number	specify which shelf the alarm occurred on. <i>This element is only shown in detail mode.</i>
ctl-com-fail	Parameter type: <Alarm::ctlComFail> ((failing fail) ok) Possible values: - failing : shelf controller communication is failing - fail : shelf controller communication is failing - ok : shelf controller communication is ok	current status of shelf controller communication failure. <i>This element is only shown in detail mode.</i>
bat-a-fail	Parameter type: <Alarm::batAFail> (yes	current status of shelf power source A failure.

name	Type	Description
	no) Possible values: - yes : Power Source Battery A Failure - no : Power Source Battery A is OK	<i>This element is only shown in detail mode.</i>
bat-b-fail	Parameter type: <Alarm::batBFail> (yes no) Possible values: - yes : Power Source Battery B Failure - no : bfd stale entry not present	current status of shelf power source B failure. <i>This element is only shown in detail mode.</i>
water-seepage-in-box	Parameter type: <Alarm::waterSeepageInBox> (detected not-detected) Possible values: - detected : detected water seepage in the enclosure - not-detected : no water seepage detected in the enclosure	current status of detected water seepage in the enclosure <i>This element is only shown in detail mode.</i>
sealed-box-open	Parameter type: <Alarm::sealedBoxOpen> (detected not-detected) Possible values: - detected : detected open sealed box - not-detected : closed sealed box	current status of detected open sealed box <i>This element is only shown in detail mode.</i>

104.6 Plug-in Unit Current Alarm Status Command

Command Description

This command displays the plug-in unit current alarm status.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

> show alarm current plug-in-unit [(index)]

Command Parameters

Table 104.6-1 "Plug-in Unit Current Alarm Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm type

Command Output

Table 104.6-2 "Plug-in Unit Current Alarm Status Command" Display parameters

Specific Information		
name	Type	Description
board-position	Parameter type: <Alarm::SlotIndex> (lt : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> nt-a nt-b nt acu : <Eqpt::RackId> / <Eqpt::ShelfId> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::EqSlotId> ext-a : <Eqpt::RackId> / <Eqpt::ShelfId> ext-b : <Eqpt::RackId> / <Eqpt::ShelfId> ctrl : <Eqpt::RackId> / <Eqpt::ShelfId> iont : <Eqpt::RackId> / <Eqpt::ShelfId> lp : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::LtAppliqueSlotId> ntio-1 ntio-2 vlt : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::VirtualSlotId>) Possible values: - lt : lt-slot - vlt : virtual LT slot (VVPS board can only be planned at	identify where the alarm has occurred. <i>This element is only shown in detail mode.</i>

name	Type	Description
	NANT-E/FANT-F) - nt-a : nt-a slot - nt-b : nt-b slot - nt : nt slot - ext-a : nt-a slot in an extension shelf - ext-b : nt-b slot in an extension shelf - acu : acu slot - ctrl : ctrl-slot - iont : an nt applique slot - lp : an lt applique slot - ntio-1 : an nt applique slot in a single or multiple-ntio-shelf - ntio-2 : an nt applique slot in a multiple-ntio-shelf Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::LtAppliqueSlotId> - the LT Applique slot number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::VirtualSlotId> - the virtual LT slot number Field type <Eqpt::EqSlotId> - the equipment slot number	
board-mismatch	Parameter type: <Alarm::boardMismatch> (yes no) Possible values: - yes : planned and plugged-in types are different - no : planned and plugged-in types are same	alarm specifying the planned and plugged-in types are different <i>This element is only shown in detail mode.</i>
sw-download	Parameter type: <Alarm::swStatus> (waiting completed) Possible values: - waiting : not able to download all the applicable SW files - completed : download completed	alarm specifying download of the software is completed or not. <i>This element is only shown in detail mode.</i>
temperature	Parameter type: <Alarm::tempStatus> (above-thres below-thres) Possible values: - above-thres : temperature threshold on board exceeded - below-thres : board temperature within threshold	alarm specifying board temperature is crossed the threshold or not. <i>This element is only shown in detail mode.</i>
sem-power-fail	Parameter type: <Alarm::extPowerStatus> (sem-power-fail sem-power-ok) Possible values: - sem-power-fail : SEM external power failure - sem-power-ok : SEM external power ok	alarm specifying SEM external power failure. <i>This element is only shown in detail mode.</i>
sem-ups-fail	Parameter type: <Alarm::powerSupplyStatus> (sem-ups-fail sem-ups-ok) Possible values: - sem-ups-fail : SEM external power supply failure - sem-ups-ok : SEM external power supply ok	alarm specifying SEM external power supply failure. <i>This element is only shown in detail mode.</i>
temp-shutoff	Parameter type: <Alarm::tempShutoffStatus> (board-switched-off board-switched-on)	alarm specifying board is switched off because of excess temperature.

104 Current Alarm Status Commands

name	Type	Description
	Possible values: - board-switched-off : board switched off - excess temperature - board-switched-on : board switched on	<i>This element is only shown in detail mode.</i>
board-present	Parameter type: <Alarm::boardPresence> (missing yes) Possible values: - missing : board was present, but now missing - yes : board present	indicates the presence of the board. <i>This element is only shown in detail mode.</i>
board-inserted	Parameter type: <Alarm::boardInsertion> (never-inserted inserted) Possible values: - never-inserted : board was never inserted - inserted : board was inserted	indicates the status of board was inserted or not. <i>This element is only shown in detail mode.</i>
board-init	Parameter type: <Alarm::boardInit> (failed completed) Possible values: - failed : board initialization failed - completed : board initialization completed	specifies board initializaion is sucessful or failed. <i>This element is only shown in detail mode.</i>
board-reset-cf	Parameter type: <Alarm::boardResetCommFail> (yes ok) Possible values: - yes : board reset/communication failure occurred - ok : no board reset/communication failure	indicates there has been a reset and/or communication failure of the board. <i>This element is only shown in detail mode.</i>
shub-uplink	Parameter type: <Alarm::lanxuplinkbrkdown> (failure ok) Possible values: - failure : lanx uplink breakdown or removal - ok : no breakdown or removal of lanx uplink	indicates that lanx uplink breakdown or removal <i>This element is only shown in detail mode.</i>
backplane-data-failure	Parameter type: <Alarm::BackplaneMismatch> (yes no) Possible values: - yes : LT backplane ports data failure - no : LT backplane ports data normal	indicates the lt backplane data status <i>This element is only shown in detail mode.</i>

104.7 ATM Current Alarm Status Command

Command Description

This command displays the ATM current alarm status.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm current atm [ (index) ]
```

Command Parameters

Table 104.7-1 "ATM Current Alarm Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm type

Command Output

Table 104.7-2 "ATM Current Alarm Status Command" Display parameters

Specific Information		
name	Type	Description
port	Parameter type: <Equipm::AtmIndex> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number	identify where the alarm has occurred. <i>This element is only shown in detail mode.</i>
vpi-vci	Parameter type: <Alarm::VpiVciValues> - the vpi and vci value (vpi/vci)	identify where the alarm has occurred. <i>This element is only shown in detail mode.</i>
cell-discard-up	Parameter type: <Alarm::CellDiscardUpstream> (discarded no-discard) Possible values:	specifies ATM cell is discarded or not in upstream direction. <i>This element is only shown in detail mode.</i>

104 Current Alarm Status Commands

name	Type	Description
	- discarded : ATM cell discarded in upstream direction - no-discard : no ATM cell discarded in upstream direction	
cell-discard-down	Parameter type: <Alarm::CellDiscardDownstream> (discarded no-discard) Possible values: - discarded : ATM cell discarded in downstream direction - no-discard : no ATM cell discarded in downstream direction	specifies ATM cell is discarded or not in downstream direction. <i>This element is only shown in detail mode.</i>

104.8 Ethernet Interface Current Alarm Status Command

Command Description

This command displays the Ethernet Interface current alarm status.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

> show alarm current ether-itf [(index)]

Command Parameters

Table 104.8-1 "Ethernet Interface Current Alarm Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm type

Command Output

Table 104.8-2 "Ethernet Interface Current Alarm Status Command" Display parameters

Specific Information		
name	Type	Description
ether-ifindex	Parameter type: <Ether::InterfaceIndex> - index of the collision interface - range: [0...2147483647]	identify where the alarm has occurred. <i>This element is only shown in detail mode.</i>

104.9 Software Management Current Alarm Status Command

Command Description

This command displays the software management current alarm status.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm current sw-mgmt [ (index) ]
```

Command Parameters

Table 104.9-1 "Software Management Current Alarm Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm type

Command Output

Table 104.9-2 "Software Management Current Alarm Status Command" Display parameters

Specific Information		
name	Type	Description
board-position	Parameter type: <Equipm::SlotIndex> (lt : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> nt-a nt-b nt acu : <Eqpt::RackId> / <Eqpt::ShelfId> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::EqSlotId> ext-a : <Eqpt::RackId> / <Eqpt::ShelfId> ext-b : <Eqpt::RackId> / <Eqpt::ShelfId> ctrl : <Eqpt::RackId> / <Eqpt::ShelfId> vlt : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::VirtualSlotId>) Possible values: - lt : lt-slot - vlt : virtual LT slot (VVPS board can only be planned at NANT-E / FANT-F)	identifies the physical position of the slot <i>This element is only shown in detail mode.</i>

name	Type	Description
	- nt-a : nt-a slot - nt-b : nt-b slot - nt : nt slot - ext-a : nt-a slot in an extension shelf - ext-b : nt-b slot in an extension shelf - acu : acu slot - ctrl : ctrl-slot Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::VirtualSlotId> - the virtual LT slot number Field type <Eqpt::EqSlotId> - the equipment slot number	
sw-rollback	Parameter type: <Alarm::SwRollback> (yes no) Possible values: - yes : implicit software rollback performed - no : no implicit software rollback	specifies implicit software rollback is performed or not. <i>This element is only shown in detail mode.</i>
db-rollback	Parameter type: <Alarm::DbRollback> (yes no) Possible values: - yes : implicit database rollback performed - no : no implicit database rollback	specifies implicit database rollback is performed or not. <i>This element is only shown in detail mode.</i>
xvps-inv-dbase	Parameter type: <Alarm::XvpsInvalidDataBase> (invalid valid) Possible values: - invalid : invalid xvps dbbase is detected - valid : xvps dbase is valid	specifies implicit xvps dbase is valid or not. <i>This element is only shown in detail mode.</i>
inv-cde-file	Parameter type: <Alarm::XvpsInvalidCDEFile> (invalid valid) Possible values: - invalid : invalid xvps cde file is detected - valid : xvps cde file is valid	specifies implicit xvps cde file is valid or not. <i>This element is only shown in detail mode.</i>
miss-cde-file	Parameter type: <Alarm::MissingCDEProfile> (yes no) Possible values: - yes : cde profile is missed - no : cde profile is exist	specifies cde profile is missed or not. <i>This element is only shown in detail mode.</i>

104.10 Temporal Filter Current Alarm Status Command

Command Description

This command displays temporal filter current alarm status.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

> show alarm current temporal [(index)]

Command Parameters

Table 104.10-1 "Temporal Filter Current Alarm Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm type

Command Output

Table 104.10-2 "Temporal Filter Current Alarm Status Command" Display parameters

Specific Information		
name	Type	Description
tmp-filter1	Parameter type: <Alarm::almFilter1> (yes no) Possible values: - yes : derived filter1 alarm - no : not derived filter1 alarm	current status for temporal filter1 <i>This element is only shown in detail mode.</i>
tmp-filter2	Parameter type: <Alarm::almFilter2> (yes no) Possible values: - yes : derived filter2 alarm - no : not derived filter2 alarm	current status for temporal filter2 <i>This element is only shown in detail mode.</i>
tmp-filter3	Parameter type: <Alarm::almFilter3> (yes no) Possible values:	current status for temporal filter3 <i>This element is only shown in detail mode.</i>

name	Type	Description
	- yes : derived filter3 alarm - no : not derived filter3 alarm	
tmp-filter4	Parameter type: <Alarm::almFilter4> (yes no) Possible values: - yes : derived filter4 alarm - no : not derived filter4 alarm	current status for temporal filter4 <i>This element is only shown in detail mode.</i>
tmp-filter5	Parameter type: <Alarm::almFilter5> (yes no) Possible values: - yes : derived filter5 alarm - no : not derived filter5 alarm	current status for temporal filter5 <i>This element is only shown in detail mode.</i>
tmp-filter6	Parameter type: <Alarm::almFilter6> (yes no) Possible values: - yes : derived filter6 alarm - no : not derived filter6 alarm	current status for temporal filter6 <i>This element is only shown in detail mode.</i>
tmp-filter7	Parameter type: <Alarm::almFilter7> (yes no) Possible values: - yes : derived filter7 alarm - no : not derived filter7 alarm	current status for temporal filter7 <i>This element is only shown in detail mode.</i>
tmp-filter8	Parameter type: <Alarm::almFilter8> (yes no) Possible values: - yes : derived filter alarm - no : not derived filter alarm	current status for temporal filter8 <i>This element is only shown in detail mode.</i>
tmp-filter9	Parameter type: <Alarm::almFilter9> (yes no) Possible values: - yes : derived filter9 alarm - no : not derived filter9 alarm	current status for temporal filter9 <i>This element is only shown in detail mode.</i>
tmp-filter10	Parameter type: <Alarm::almFilter10> (yes no) Possible values: - yes : derived filter10 alarm - no : not derived filter alarm	current status for temporal filter10 <i>This element is only shown in detail mode.</i>
tmp-filter11	Parameter type: <Alarm::almFilter11> (yes no) Possible values: - yes : derived filter11 alarm - no : not derived filter11 alarm	current status for temporal filter11 <i>This element is only shown in detail mode.</i>
tmp-filter12	Parameter type: <Alarm::almFilter12> (yes no) Possible values: - yes : derived filter12 alarm - no : not derived filter12 alarm	current status for temporal filter12 <i>This element is only shown in detail mode.</i>
tmp-filter13	Parameter type: <Alarm::almFilter13>	current status for temporal

104 Current Alarm Status Commands

name	Type	Description
	(yes no) Possible values: - yes : derived filter13 alarm - no : not derived filter13 alarm	filter13 <i>This element is only shown in detail mode.</i>
tmp-filter14	Parameter type: <Alarm::almFilter14> (yes no) Possible values: - yes : derived filter14 alarm - no : not derived filter14 alarm	current status for temporal filter14 <i>This element is only shown in detail mode.</i>
tmp-filter15	Parameter type: <Alarm::almFilter15> (yes no) Possible values: - yes : derived filter15 alarm - no : not derived filter15 alarm	current status for temporal filter15 <i>This element is only shown in detail mode.</i>
tmp-filter16	Parameter type: <Alarm::almFilter16> (yes no) Possible values: - yes : derived filter16 alarm - no : not derived filter16 alarm	current status for temporal filter16 <i>This element is only shown in detail mode.</i>
tmp-filter17	Parameter type: <Alarm::almFilter17> (yes no) Possible values: - yes : derived filter17 alarm - no : not derived filter17 alarm	current status for temporal filter17 <i>This element is only shown in detail mode.</i>
tmp-filter18	Parameter type: <Alarm::almFilter18> (yes no) Possible values: - yes : derived filter18 alarm - no : not derived filter18 alarm	current status for temporal filter18 <i>This element is only shown in detail mode.</i>
tmp-filter19	Parameter type: <Alarm::almFilter19> (yes no) Possible values: - yes : derived filter19 alarm - no : not derived filter19 alarm	current status for temporal filter19 <i>This element is only shown in detail mode.</i>
tmp-filter20	Parameter type: <Alarm::almFilter20> (yes no) Possible values: - yes : derived filter20 alarm - no : not derived filter20 alarm	current status for temporal filter20 <i>This element is only shown in detail mode.</i>
tmp-filter21	Parameter type: <Alarm::almFilter21> (yes no) Possible values: - yes : derived filter21 alarm - no : not derived filter21 alarm	current status for temporal filter21 <i>This element is only shown in detail mode.</i>
tmp-filter22	Parameter type: <Alarm::almFilter22> (yes no) Possible values:	current status for temporal filter22 <i>This element is only shown in detail mode.</i>

name	Type	Description
	- yes : derived filter22 alarm - no : not derived filter22 alarm	
tmp-filter23	Parameter type: <Alarm::almFilter23> (yes no) Possible values: - yes : derived filter23 alarm - no : not derived filter23 alarm	current status for temporal filter23 <i>This element is only shown in detail mode.</i>
tmp-filter24	Parameter type: <Alarm::almFilter24> (yes no) Possible values: - yes : derived filter24 alarm - no : not derived filter24 alarm	current status for temporal filter24 <i>This element is only shown in detail mode.</i>
tmp-filter25	Parameter type: <Alarm::almFilter25> (yes no) Possible values: - yes : derived filter25 alarm - no : not derived filter25 alarm	current status for temporal filter25 <i>This element is only shown in detail mode.</i>
tmp-filter26	Parameter type: <Alarm::almFilter26> (yes no) Possible values: - yes : derived filter26 alarm - no : not derived filter26 alarm	current status for temporal filter26 <i>This element is only shown in detail mode.</i>
tmp-filter27	Parameter type: <Alarm::almFilter27> (yes no) Possible values: - yes : derived filter27 alarm - no : not derived filter27 alarm	current status for temporal filter27 <i>This element is only shown in detail mode.</i>
tmp-filter28	Parameter type: <Alarm::almFilter28> (yes no) Possible values: - yes : derived filter28 alarm - no : not derived filter28 alarm	current status for temporal filter28 <i>This element is only shown in detail mode.</i>
tmp-filter29	Parameter type: <Alarm::almFilter29> (yes no) Possible values: - yes : derived filter29 alarm - no : not derived filter29 alarm	current status for temporal filter29 <i>This element is only shown in detail mode.</i>
tmp-filter30	Parameter type: <Alarm::almFilter30> (yes no) Possible values: - yes : derived filter30 alarm - no : not derived filter30 alarm	current status for temporal filter30 <i>This element is only shown in detail mode.</i>
tmp-filter31	Parameter type: <Alarm::almFilter31> (yes no) Possible values: - yes : derived filter31 alarm - no : not derived filter31 alarm	current status for temporal filter31 <i>This element is only shown in detail mode.</i>

104.11 Spatial Filter Current Alarm Status Command

Command Description

This command displays spatial filter current alarm status.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

> show alarm current spatial [(index)]

Command Parameters

Table 104.11-1 "Spatial Filter Current Alarm Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm type

Command Output

Table 104.11-2 "Spatial Filter Current Alarm Status Command" Display parameters

Specific Information		
name	Type	Description
spa-filter1	Parameter type: <Alarm::almFilter1> (yes no) Possible values: - yes : derived filter1 alarm - no : not derived filter1 alarm	current status for spatial filter1 <i>This element is only shown in detail mode.</i>
spa-filter2	Parameter type: <Alarm::almFilter2> (yes no) Possible values: - yes : derived filter2 alarm - no : not derived filter2 alarm	current status for spatial filter2 <i>This element is only shown in detail mode.</i>
spa-filter3	Parameter type: <Alarm::almFilter3> (yes no) Possible values:	current status for spatial filter3 <i>This element is only shown in detail mode.</i>

name	Type	Description
	- yes : derived filter3 alarm - no : not derived filter3 alarm	
spa-filter4	Parameter type: <Alarm::almFilter4> (yes no) Possible values: - yes : derived filter4 alarm - no : not derived filter4 alarm	current status for spatial filter4 <i>This element is only shown in detail mode.</i>
spa-filter5	Parameter type: <Alarm::almFilter5> (yes no) Possible values: - yes : derived filter5 alarm - no : not derived filter5 alarm	current status for spatial filter5 <i>This element is only shown in detail mode.</i>
spa-filter6	Parameter type: <Alarm::almFilter6> (yes no) Possible values: - yes : derived filter6 alarm - no : not derived filter6 alarm	current status for spatial filter6 <i>This element is only shown in detail mode.</i>
spa-filter7	Parameter type: <Alarm::almFilter7> (yes no) Possible values: - yes : derived filter7 alarm - no : not derived filter7 alarm	current status for spatial filter7 <i>This element is only shown in detail mode.</i>
spa-filter8	Parameter type: <Alarm::almFilter8> (yes no) Possible values: - yes : derived filter alarm - no : not derived filter alarm	current status for spatial filter8 <i>This element is only shown in detail mode.</i>
spa-filter9	Parameter type: <Alarm::almFilter9> (yes no) Possible values: - yes : derived filter9 alarm - no : not derived filter9 alarm	current status for spatial filter9 <i>This element is only shown in detail mode.</i>
spa-filter10	Parameter type: <Alarm::almFilter10> (yes no) Possible values: - yes : derived filter10 alarm - no : not derived filter alarm	current status for spatial filter10 <i>This element is only shown in detail mode.</i>
spa-filter11	Parameter type: <Alarm::almFilter11> (yes no) Possible values: - yes : derived filter11 alarm - no : not derived filter11 alarm	current status for spatial filter11 <i>This element is only shown in detail mode.</i>
spa-filter12	Parameter type: <Alarm::almFilter12> (yes no) Possible values: - yes : derived filter12 alarm - no : not derived filter12 alarm	current status for spatial filter12 <i>This element is only shown in detail mode.</i>
spa-filter13	Parameter type: <Alarm::almFilter13>	current status for spatial filter13

104 Current Alarm Status Commands

name	Type	Description
	(yes no) Possible values: - yes : derived filter13 alarm - no : not derived filter13 alarm	<i>This element is only shown in detail mode.</i>
spa-filter14	Parameter type: <Alarm::almFilter14> (yes no) Possible values: - yes : derived filter14 alarm - no : not derived filter14 alarm	current status for spatial filter14 <i>This element is only shown in detail mode.</i>
spa-filter15	Parameter type: <Alarm::almFilter15> (yes no) Possible values: - yes : derived filter15 alarm - no : not derived filter15 alarm	current status for spatial filter15 <i>This element is only shown in detail mode.</i>
spa-filter16	Parameter type: <Alarm::almFilter16> (yes no) Possible values: - yes : derived filter16 alarm - no : not derived filter16 alarm	current status for spatial filter16 <i>This element is only shown in detail mode.</i>
spa-filter17	Parameter type: <Alarm::almFilter17> (yes no) Possible values: - yes : derived filter17 alarm - no : not derived filter17 alarm	current status for spatial filter17 <i>This element is only shown in detail mode.</i>
spa-filter18	Parameter type: <Alarm::almFilter18> (yes no) Possible values: - yes : derived filter18 alarm - no : not derived filter18 alarm	current status for spatial filter18 <i>This element is only shown in detail mode.</i>
spa-filter19	Parameter type: <Alarm::almFilter19> (yes no) Possible values: - yes : derived filter19 alarm - no : not derived filter19 alarm	current status for spatial filter19 <i>This element is only shown in detail mode.</i>
spa-filter20	Parameter type: <Alarm::almFilter20> (yes no) Possible values: - yes : derived filter20 alarm - no : not derived filter20 alarm	current status for spatial filter20 <i>This element is only shown in detail mode.</i>
spa-filter21	Parameter type: <Alarm::almFilter21> (yes no) Possible values: - yes : derived filter21 alarm - no : not derived filter21 alarm	current status for spatial filter21 <i>This element is only shown in detail mode.</i>
spa-filter22	Parameter type: <Alarm::almFilter22> (yes no) Possible values:	current status for spatial filter22 <i>This element is only shown in detail mode.</i>

name	Type	Description
	- yes : derived filter22 alarm - no : not derived filter22 alarm	
spa-filter23	Parameter type: <Alarm::almFilter23> (yes no) Possible values: - yes : derived filter23 alarm - no : not derived filter23 alarm	current status for spatial filter23 <i>This element is only shown in detail mode.</i>
spa-filter24	Parameter type: <Alarm::almFilter24> (yes no) Possible values: - yes : derived filter24 alarm - no : not derived filter24 alarm	current status for spatial filter24 <i>This element is only shown in detail mode.</i>
spa-filter25	Parameter type: <Alarm::almFilter25> (yes no) Possible values: - yes : derived filter25 alarm - no : not derived filter25 alarm	current status for spatial filter25 <i>This element is only shown in detail mode.</i>
spa-filter26	Parameter type: <Alarm::almFilter26> (yes no) Possible values: - yes : derived filter26 alarm - no : not derived filter26 alarm	current status for spatial filter26 <i>This element is only shown in detail mode.</i>
spa-filter27	Parameter type: <Alarm::almFilter27> (yes no) Possible values: - yes : derived filter27 alarm - no : not derived filter27 alarm	current status for spatial filter27 <i>This element is only shown in detail mode.</i>
spa-filter28	Parameter type: <Alarm::almFilter28> (yes no) Possible values: - yes : derived filter28 alarm - no : not derived filter28 alarm	current status for spatial filter28 <i>This element is only shown in detail mode.</i>
spa-filter29	Parameter type: <Alarm::almFilter29> (yes no) Possible values: - yes : derived filter29 alarm - no : not derived filter29 alarm	current status for spatial filter29 <i>This element is only shown in detail mode.</i>
spa-filter30	Parameter type: <Alarm::almFilter30> (yes no) Possible values: - yes : derived filter30 alarm - no : not derived filter30 alarm	current status for spatial filter30 <i>This element is only shown in detail mode.</i>
spa-filter31	Parameter type: <Alarm::almFilter31> (yes no) Possible values: - yes : derived filter31 alarm - no : not derived filter31 alarm	current status for spatial filter31 <i>This element is only shown in detail mode.</i>

104.12 xDSL Current Alarm Status Command

Command Description

This command displays the xDSL current alarm status.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm current xdsl [ (index) ]
```

Command Parameters

Table 104.12-1 "xDSL Current Alarm Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm type

Command Output

Table 104.12-2 "xDSL Current Alarm Status Command" Display parameters

Specific Information		
name	Type	Description
port	Parameter type: <Itf::XdslLine> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number	identifies the physical position of the port <i>This element is only shown in detail mode.</i>
near-end-los	Parameter type: <Alarm::NearEndLOS> (yes no) Possible values: - yes : near end loss of signal occurred - no : no near end loss of signal	specifies near end loss of signal occurred or not. <i>This element is only shown in detail mode.</i>
near-end-lof	Parameter type: <Alarm::NearEndLOF> (yes	specifies near end loss of frame occurred or not.

name	Type	Description
	no) Possible values: - yes : near end loss of frame occurred - no : no near end loss of frame	<i>This element is only shown in detail mode.</i>
near-end-lom	Parameter type: <Alarm::NearEndLOM> (yes no) Possible values: - yes : near end loss of margin occurred - no : no near end loss of margin	specifies near end loss of margin occurred or not. <i>This element is only shown in detail mode.</i>
near-end-ese	Parameter type: <Alarm::NearEndESE> (yes no) Possible values: - yes : near end excessive severe errors occurred - no : no near end excessive severe errors occurred	specifies near end excessive severe errors occurred or not. <i>This element is only shown in detail mode.</i>
line-config	Parameter type: <Alarm::LineConfig> (config-error config-ok) Possible values: - config-error : line configuration data cannot be used - config-ok : Line configuration data OK	specifies whether line configuration data is used or not. <i>This element is only shown in detail mode.</i>
line-capacity	Parameter type: <Alarm::LineCapacity> (below-requirement meets-requirement) Possible values: - below-requirement : line capacity not enough to set up requested profile - meets-requirement : line capacity enough to set up requested profile	specifies whether line capacity is set up or not. <i>This element is only shown in detail mode.</i>
near-end-bitrate	Parameter type: <Alarm::NearEndBRthres> (below-plan meets-plan) Possible values: - below-plan : upstream planned bitrate not reached after initialization - meets-plan : upstream planned bitrate reached	specifies whether upstream planned bitrate reached or not after initialization. <i>This element is only shown in detail mode.</i>
near-end-ncd	Parameter type: <Alarm::NearEndNCD> (no-cell-deline cell-deline-occurred) Possible values: - no-cell-deline : no near end cell delineation - cell-deline-occurred : near end cell delineation occurred	specifies whether near end cell delineation is occurred or not. <i>This element is only shown in detail mode.</i>
near-end-lcd	Parameter type: <Alarm::NearEndLCD> (yes no) Possible values: - yes : loss of near end cell deliniation - no : no loss of near end cell deliniation	specifies whether loss of near end cell deliniation is occurred or not. <i>This element is only shown in detail mode.</i>
far-end-los	Parameter type: <Alarm::FarEndLOS> (yes no) Possible values: - yes : far end loss of signal occurred - no : no far end loss of signal	specifies whether far end loss of signal occurred or not. <i>This element is only shown in detail mode.</i>
far-end-lof	Parameter type: <Alarm::FarEndLOF> (yes	specifies whether far end loss of frame occurred or not.

104 Current Alarm Status Commands

name	Type	Description
	no) Possible values: - yes : far end loss of frame occurred - no : no far end loss of frame	<i>This element is only shown in detail mode.</i>
far-end-lpr	Parameter type: <Alarm::FarEndLPR> (yes no) Possible values: - yes : far end loss of power detected - no : no far end loss of power	specifies whether far end loss of power detected or not. <i>This element is only shown in detail mode.</i>
far-end-lol	Parameter type: <Alarm::FarEndLOL> (yes no) Possible values: - yes : far end loss of link detected - no : no far end loss of link	specifies whether far end loss of link detected or not. <i>This element is only shown in detail mode.</i>
far-end-lom	Parameter type: <Alarm::FarEndLOM> (yes no) Possible values: - yes : far end loss of margin occurred - no : no far end loss of margin	specifies whether far end loss of margin occurred or not. <i>This element is only shown in detail mode.</i>
far-end-ese	Parameter type: <Alarm::FarEndESE> (yes no) Possible values: - yes : far end excessive severe errors occurred - no : no far end excessive severe errors occurred	specifies whether far end excessive severe errors occurred or not. <i>This element is only shown in detail mode.</i>
xdsl-init	Parameter type: <Alarm::Initialization> (failed successful) Possible values: - failed : initialization unsuccessful due to communication problem - successful : initialization successful	specifies xdsl line initialization is successful or not. <i>This element is only shown in detail mode.</i>
peer-modem	Parameter type: <Alarm::PeerModem> (no yes) Possible values: - no : no peer modem detected - yes : peer modem detected	specifies whether peer modem detected or not. <i>This element is only shown in detail mode.</i>
far-end-bitrate	Parameter type: <Alarm::FarEndBRthres> (below-plan meets-plan) Possible values: - below-plan : downstream planned bitrate not reached after initialization - meets-plan : downstream planned bitrate reached	specifies whether downstream planned bitrate reached or not. <i>This element is only shown in detail mode.</i>
far-end-ncd	Parameter type: <Alarm::FarEndNCD> (no-cell-deline cell-deline-occurred) Possible values: - no-cell-deline : no far end cell delineation - cell-deline-occurred : far end cell delineation occurred	specifies whether far end cell delineation occurred or not. <i>This element is only shown in detail mode.</i>
far-end-lcd	Parameter type: <Alarm::FarEndLCD> (yes no)	specifies there is loss of far end cell delineation or not. <i>This element is only shown in</i>

name	Type	Description
	Possible values: - yes : loss of far end cell deliniation - no : no loss of far end cell deliniation	<i>detail mode.</i>
far-end-upbo-vio	Parameter type: <Alarm::FarEndUPBO> (yes no) Possible values: - yes : UPBO violation - no : no UPBO violation	UPBO violation <i>This element is only shown in detail mode.</i>
far-end-mis-peer-35b	Parameter type: <Alarm::FarEndMismatchPeer35B> (yes no) Possible values: - yes : VDSL2 35b opmode mismatch between XTU-C and XTU-R - no : No VDSL2 35b opmode mismatch between XTU-C and XTU-R	VDSL2 35b opmode mismatch between XTU-C and XTU-R <i>This element is only shown in detail mode.</i>
far-end-cpe-pol	Parameter type: <Alarm::FarEndActFail> (yes no) Possible values: - yes : activation failure due to CPE policing - no : no activation failure due to CPE policing	activation failure due to CPE policing <i>This element is only shown in detail mode.</i>
tpstc-mis	Parameter type: <Alarm::TpstcMis> (yes no) Possible values: - yes : mismatch between the configured tps-tc mode and the mode supported by the connected cpe - no : no mismatch between the configured and the tpstc mode supported by connected cpe	mismatch between the configured tps-tc mode and the mode supported by the connected cpe <i>This element is only shown in detail mode.</i>
forced-rtx-init	Parameter type: <Alarm::ForcedRtxInit> (failed successful) Possible values: - failed : initialization unsuccessful due to forced retransmission - successful : initialization successful	specifies forced rtx initialization is successful or not <i>This element is only shown in detail mode.</i>
vect-dle	Parameter type: <Alarm::NearEndVectDle> (yes no) Possible values: - yes : loss of us signal due to disorderly leaving event - no : no disorderly leaving detected	specifies whether a disorderly leaving event occurred or not <i>This element is only shown in detail mode.</i>

104.13 TCA xDSL Current Alarm Status Command

Command Description

This command displays the xDSL threshold cross current alarm status.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm current xdsl-tca [ (index) ]
```

Command Parameters

Table 104.13-1 "TCA xDSL Current Alarm Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm type

Command Output

Table 104.13-2 "TCA xDSL Current Alarm Status Command" Display parameters

Specific Information		
name	Type	Description
port	Parameter type: <Itf::XdslLine> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number	identifies where the alarm occurred <i>This element is only shown in detail mode.</i>
errored-secs	Parameter type: <Alarm::ErroredSeconds> (above-thres below-thres) Possible values: - above-thres : number of errored seconds exceeded threshold - below-thres : number of errored seconds below threshold	number of errored seconds exceeded or below threshold <i>This element is only shown in detail mode.</i>
es-in-a-day	Parameter type: <Alarm::ErroredSecondsInAday>	errored seconds in a day

name	Type	Description
	(above-thres below-thres) Possible values: - above-thres : number of errored seconds in a day, exceeded threshold - below-thres : number of errored seconds in a day, below threshold	exceeded or below threshold <i>This element is only shown in detail mode.</i>
severely-es	Parameter type: <Alarm::SeverelyErroredSeconds> (above-thres below-thres) Possible values: - above-thres : number of severely errored seconds exceeded threshold - below-thres : number of severely errored seconds below threshold	number of severely errored seconds exceeded or below threshold <i>This element is only shown in detail mode.</i>
severely-es-in-a-day	Parameter type: <Alarm::SevErroredSecsInAday> (above-thres below-thres) Possible values: - above-thres : number of severely errored seconds in a day, exceeded threshold - below-thres : number of severely errored seconds in a day, below threshold	number of severely errored seconds in a day, exceeded or below threshold <i>This element is only shown in detail mode.</i>
unavailable-secs	Parameter type: <Alarm::UnavailableSeconds> (above-thres below-thres) Possible values: - above-thres : number of unavailable seconds exceeded threshold - below-thres : number of unavailable seconds below threshold	number of unavailable seconds exceeded or below threshold <i>This element is only shown in detail mode.</i>
unavail-secs-in-a-day	Parameter type: <Alarm::UnavailSecsInAday> (above-thres below-thres) Possible values: - above-thres : number of unavailable seconds in a day, exceeded threshold - below-thres : number of unavailable seconds in a day, below threshold	number of far end unavailable seconds in a day, exceeded or below threshold <i>This element is only shown in detail mode.</i>
far-end-es	Parameter type: <Alarm::FarEndErroredSeconds> (above-thres below-thres) Possible values: - above-thres : number of far end errored seconds exceeded threshold - below-thres : number of far end errored seconds below threshold	number of far end errored seconds exceeded or below threshold <i>This element is only shown in detail mode.</i>
fe-severely-es	Parameter type: <Alarm::FarEndSevErroredSecs> (above-thres below-thres) Possible values: - above-thres : number of far end severely errored seconds exceeded threshold - below-thres : number of far end severely errored seconds below threshold	number of far end severely errored seconds exceeded or below threshold <i>This element is only shown in detail mode.</i>
fe-severely-es/day	Parameter type: <Alarm::FarEndSevErroredSecsInAday> (above-thres	number of severely errored seconds in a day, exceeded or

104 Current Alarm Status Commands

name	Type	Description
	below-thres) Possible values: - above-thres : number of far end severely errored seconds in a day, exceeded threshold - below-thres : number of far end severely errored seconds in a day, below threshold	below threshold <i>This element is only shown in detail mode.</i>
fe-unavail-secs	Parameter type: <Alarm::FarEndUnavailSecs> (above-thres below-thres) Possible values: - above-thres : number of far end unavailable seconds exceeded threshold - below-thres : number of far end unavailable seconds below threshold	number of far end unavailable seconds in a day, exceeded or below threshold <i>This element is only shown in detail mode.</i>
fe-unavail-sec/day	Parameter type: <Alarm::FarEndUnavailSecsInAday> (above-thres below-thres) Possible values: - above-thres : number of far end unavailable seconds in a day, exceeded threshold - below-thres : number of far end unavailable seconds in a day, below threshold	number of far end unavailable seconds in a day, exceeded or below threshold <i>This element is only shown in detail mode.</i>
fe-es-in-a-day	Parameter type: <Alarm::FarEndErroredSecsInAday> (above-thres below-thres) Possible values: - above-thres : number of far end errored seconds in a day, exceeded threshold - below-thres : number of far end errored seconds in a day, below threshold	number of far end errored seconds in a day, exceeded or below threshold <i>This element is only shown in detail mode.</i>
leftrs	Parameter type: <Alarm::LeftrSeconds> (above-thres below-thres) Possible values: - above-thres : number of low error free throughput seconds exceeded threshold - below-thres : number of low error free throughput seconds below threshold	number of low error free throughput seconds exceeded or below threshold <i>This element is only shown in detail mode.</i>
leftrs-in-a-day	Parameter type: <Alarm::LeftrSecondsInAday> (above-thres below-thres) Possible values: - above-thres : number of low error free throughput seconds in a day, exceeded threshold - below-thres : number of low error free throughput seconds in a day, below threshold	number of low error free throughput seconds in a day, exceeded or below threshold <i>This element is only shown in detail mode.</i>
fe-leftrs	Parameter type: <Alarm::FarEndLeftrSeconds> (above-thres below-thres) Possible values: - above-thres : number of far end low error free throughput seconds exceeded threshold - below-thres : number of far end low error free throughput seconds below threshold	number of far end low error free throughput seconds exceeded or below threshold <i>This element is only shown in detail mode.</i>
fe-leftrs-in-a-day	Parameter type: <Alarm::FarEndLeftrSecondsInAday> (above-thres below-thres)	number of far end low error free throughput seconds in a day, exceeded or below threshold

name	Type	Description
	Possible values: - above-thres : number of far end low error free throughput seconds in a day, exceeded threshold - below-thres : number of far end low error free throughput seconds in a day, below threshold	<i>This element is only shown in detail mode.</i>
xtca-auto-port-reset	Parameter type: <Alarm::AutoPortResetInAweek> (above-thres below-thres) Possible values: - above-thres : number of auto-port-resets reached threshold with in a week - below-thres : number of auto-port-resets below threshold	number of auto-port-resets in a week reached threshold <i>This element is only shown in detail mode.</i>
reinit	Parameter type: <Alarm::Reinit> (above-thres below-thres) Possible values: - above-thres : number of reinit counter exceeded threshold - below-thres : number of reinit counter below threshold	number of Reinitialization count in 15min, exceeded or below threshold <i>This element is only shown in detail mode.</i>
reinit-in-a-day	Parameter type: <Alarm::ReinitInAday> (above-thres below-thres) Possible values: - above-thres : number of reinit counter exceeded threshold - below-thres : number of reinit counter below threshold	number of Reinitialization count in a day, exceeded or below threshold <i>This element is only shown in detail mode.</i>

104.14 OLT General Current Alarm Status Command

Command Description

This command displays the OLT general current alarm status.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm current olt-gen [ (index) ]
```

Command Parameters

Table 104.14-1 "OLT General Current Alarm Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm type

Command Output

Table 104.14-2 "OLT General Current Alarm Status Command" Display parameters

Specific Information		
name	Type	Description
port	Parameter type: <Gpon::PonId> (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> x-pon : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::XPonId> 25g-pon : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::M25GPonId>) Possible values: - 25g-pon : 25g pon - x-pon : Xgs pon Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number	specify which port the alarm occurred on. <i>This element is only shown in detail mode.</i>

name	Type	Description
	Field type <Eqpt::PonId> - the PON identifier Field type <Eqpt::XPonId> - the XGS PON identifier Field type <Eqpt::M25GPonId> - the 25G PON identifier	
Only Show Details: current alarm log status		
name	Type	Description
olt-pon-comm	Parameter type: <Alarm::OltPonComm> ((failing fail) ok) Possible values: - failing : OLT port communication is failing - fail : OLT port communication is failing - ok : port protection is ok	current status of PON Communication failure on OLT Port <i>This element is only shown in detail mode.</i>
olt-gen-tf	Parameter type: <Alarm::OltGenTf> ((failing fail) ok) Possible values: - failing : port protection is failing - fail : port protection is failing - ok : port protection is ok	current status of transmit failure on OLT port <i>This element is only shown in detail mode.</i>
olt-new-ont	Parameter type: <Alarm::OltNewOnt> ((failing fail) ok) Possible values: - failing : port protection is failing - fail : port protection is failing - ok : port protection is ok	current status of unprovisioned ont appearance <i>This element is only shown in detail mode.</i>
olt-pon-mea	Parameter type: <Alarm::OltPonMea> ((failing fail) ok) Possible values: - failing : port protection is failing - fail : port protection is failing - ok : port protection is ok	current status of pon provision failure. <i>This element is only shown in detail mode.</i>
olt-pon-loss	Parameter type: <Alarm::OltPonLoss> ((failing fail) ok) Possible values: - failing : port protection is failing - fail : port protection is failing - ok : port protection is ok	current status of pon loss. <i>This element is only shown in detail mode.</i>
pon-rogue-test	Parameter type: <Alarm::PonRogueTest> ((failing fail) ok) Possible values: - failing : Rogue ONT detection mechanism effective is failing - fail : Rogue ONT detection mechanism effective is failing - ok : Rogue ONT detection mechanism effective is ok	current status of diagnostic tests <i>This element is only shown in detail mode.</i>
onu-loid-conflict	Parameter type: <Alarm::OnuLoidConflict> ((failing fail) ok) Possible values: - failing : port protection is failing - fail : port protection is failing	current status of loid conflict ont. <i>This element is only shown in detail mode.</i>

104 Current Alarm Status Commands

name	Type	Description
	- ok : port protection is ok	
onu-loid-pwd-err	Parameter type: <Alarm::OnuLoidPwdErr> ((failing fail) ok) Possible values: - failing : port protection is failing - fail : port protection is failing - ok : port protection is ok	current status of loid password error. <i>This element is only shown in detail mode.</i>
stk-laser-dis	Parameter type: <Alarm::StkLaserDis> ((failing fail) ok) Possible values: - failing : port protection is failing - fail : port protection is failing - ok : port protection is ok	current status of stuck laser disabled. <i>This element is only shown in detail mode.</i>
pon-alien-test	Parameter type: <Alarm::PonAlienTest> ((failing fail) ok) Possible values: - failing : Alien ONT detection mechanism is active - fail : Alien ONT detection mechanism is active - ok : Alien ONT detection mechanism is not active	current status of alien diagnostic tests <i>This element is only shown in detail mode.</i>
pon-alien-detect	Parameter type: <Alarm::AlienDetected> ((failing fail) ok) Possible values: - failing : Alien ONT detected - fail : Alien ONT detected - ok : No alien ONT detected	current status of alien detect <i>This element is only shown in detail mode.</i>
pon-rng-mismatch	Parameter type: <Alarm::PonRngMismatch> ((failing fail) ok) Possible values: - failing : ranging mismatch detection mechanism effective is failing - fail : ranging mismatch detection mechanism effective is failing - ok : ranging mismatch detection mechanism effective is ok	current status of ranging mismatch <i>This element is only shown in detail mode.</i>
pon-sfp-mismatch	Parameter type: <Alarm::PonSfpMismatch> ((failing fail) ok) Possible values: - failing : pon sfp mismatch is failing - fail : pon sfp mismatch is failing - ok : pon sfp mismatch is ok	current status of sfp mismatch <i>This element is only shown in detail mode.</i>
deactont-high-tca	Parameter type: <Alarm::DeactOntHighTca> (failing ok) Possible values: - failing : pon deactivated ont amount exceed high threshold occurred - ok : pon deactivated ont amount is less than high threshold occurred	current status of deactont high tca <i>This element is only shown in detail mode.</i>
deactont-low-tca	Parameter type: <Alarm::DeactOntLowTca> (failing ok) Possible values:	current status of deactont low tca <i>This element is only shown in detail mode.</i>

name	Type	Description
	- failing : pon deactivated ont amount exceed low threshold occurred - ok : pon deactivated ont amount is less than low threshold occurred	
datapath-integ	Parameter type: <Alarm::DataPathInteg> (failing ok) Possible values: - failing : number of ONTs with SIPREGTO alarm exceeds threshold - ok : number of ONTs with SIPREGTO alarm does not exceed the threshold	current status of PON Data Path Integrity <i>This element is only shown in detail mode.</i>
ddr-fault	Parameter type: <Alarm::DdrFault> (failing ok) Possible values: - failing : pon failure due to ddr fault - ok : ddr ok	pon failure due to ddr fault <i>This element is only shown in detail mode.</i>

104.15 Vectoring Line Current Alarm Status Command

Command Description

This command displays the vectoring line current alarm status.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

> show alarm current vect-line [(index)]

Command Parameters

Table 104.15-1 "Vectoring Line Current Alarm Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm type

Command Output

Table 104.15-2 "Vectoring Line Current Alarm Status Command" Display parameters

Specific Information		
name	Type	Description
port	Parameter type: <Itf::XdslLine> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number	identifies the physical position of the port where the alarm has occurred. <i>This element is only shown in detail mode.</i>
xtc-variation-vict	Parameter type: <Alarm::VectXtcVariation> (excessive normal) Possible values: - excessive : abnormal amplitude variation in xtc	excessive : abnormal amplitude variation in xtc coefficients <i>This element is only shown in detail mode.</i>

name	Type	Description
	coefficients - normal : no excessive xtc coefficients variation	
xtc-variation-dist	Parameter type: <Alarm::VectXtcVariationDist> (excessive normal) Possible values: - excessive : abnormal amplitude variation in xtc coefficients - normal : no excessive xtc coefficients variation	specifies if excessive outgoing crosstalk coefficient variation occurred or not <i>This element is only shown in detail mode.</i>
corrupted-errf	Parameter type: <Alarm::VectCorptErrf> (yes no) Possible values: - yes : at least 10% corrupted or missing errorf samples received - no : received errorf samples ok	specifies if corrupted or at least 10% missing errorf samples received occurred or not <i>This element is only shown in detail mode.</i>
vect-cpe-cap-mismatch	Parameter type: <Alarm::VectCpeCapMism> (yes no) Possible values: - yes : not allowed Vectoring CPE connected - no : allowed Vectoring CPE connected	specifies if an allowed Vectoring CPE is connected or not <i>This element is only shown in detail mode.</i>
vect-conf-not-feas	Parameter type: <Alarm::VectConfNotFeas> (yes no) Possible values: - yes : vectoring configuration not feasible - no : vectoring configuration feasible	specifies if the vectoring configuration is feasible <i>This element is only shown in detail mode.</i>

104.16 Vectoring Board Current Alarm Status Command

Command Description

This command displays the vectoring board current alarm status.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

> show alarm current vect-board [(index)]

Command Parameters

Table 104.16-1 "Vectoring Board Current Alarm Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm type

Command Output

Table 104.16-2 "Vectoring Board Current Alarm Status Command" Display parameters

Specific Information		
name	Type	Description
board-index	Parameter type: <Equipm::EqptVpSlotIndex> (ctrl : <Eqpt::RackId> / <Eqpt::ShelfId> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId>) Possible values: - ctrl : ctrl-slot Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number	specifies where the alarm has occurred. <i>This element is only shown in detail mode.</i>
vp-link-index	Parameter type: <Alarm::VectVpLinkId2> - specifies the soft-link or the vp-link on the vp-board, or zero - range: [0,1...16]	this is the vplink id. This index has value zero when it is not used <i>This element is only shown in detail mode.</i>
vp-lt-mismatch	Parameter type: <Alarm::VectVpLtMism>	specifies if a mismatch between

name	Type	Description
	(yes no) Possible values: - yes : mismatch between expected and actual vp-lt mapping or incompatible sw version on vp and lt - no : expected and actual vp-lt in line or vp and lt have compatible sw versions, OR autodiscovery enabled on vp, autodiscovery disabled on lt	expected and actual vp-lt mapping OR incompatible sw version on vp and lt is detected or not. In case vplt-autodiscovery disabled on vp, failure reported on vp-board. In case vplt-autodiscovery enabled on lt, failure reported on lt-board. <i>This element is only shown in detail mode.</i>
qsfp-id	Parameter type: <Alarm::VectQsfpInvalidNokiaID> (invalid valid) Possible values: - invalid : QSFP does not have valid Nokia ID - valid : QSFP has valid Nokia ID OR no QSFP detected.	specifies if detected QSFP of the frontcable has a valid Nokia ID or not <i>This element is only shown in detail mode.</i>
vp-lt-link	Parameter type: <Alarm::VPLTLINKFAIL> (linkdown linkup) Possible values: - linkdown : vp-lt link problem - linkup : vp-lt link ok or no lt-expected OR autodiscovery enabled on vp, autodiscovery disabled on lt	specifies if a VP-LT link failure is detected or not. In case vplt-autodiscovery disabled on vp, failure reported on vp-board when an lt was expected but no valid connection between vp-lt. In case vplt-autodiscovery enabled on lt, failure reported on lt-board when no valid connection between vp-lt. <i>This element is only shown in detail mode.</i>
vect-no-gain-at-init	Parameter type: <Alarm::VECTNOGAINATINIT> (yes no) Possible values: - yes : Lines cannot train in gain-at-init mode - no : Lines can train in gain-at-init mode	vectoring gain-at-init mode is not feasible due to excessive number of non-FDPS capable CPEs <i>This element is only shown in detail mode.</i>
additional-info	Parameter type: <Alarm::VpLtLinkFailAdditionalInfo> - string contains slot identifier (type-based slot-numbering), isam ipaddress, isam-id , qsfp-state of the peer slv-vp board - length: x<=512	AdditionalInfo in case a vp-lt link failure is reported, or empty string <i>This element is only shown in detail mode.</i>

104.17 Electrical-to-Optical Conversion Current Alarm Status Command

Command Description

This command displays the Electrical-to-Optical conversion current alarm status.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

> show alarm current eo-conversion [(index)]

Command Parameters

Table 104.17-1 "Electrical-to-Optical Conversion Current Alarm Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm type

Command Output

Table 104.17-2 "Electrical-to-Optical Conversion Current Alarm Status Command" Display parameters

Specific Information		
name	Type	Description
port	Parameter type: <SignedInteger> - a signed integer	identifies where the alarm occurred. <i>This element is only shown in detail mode.</i>
loss-of-signal	Parameter type: <Alarm::EoConvLOS> (yes no) Possible values: - yes : loss of signal detected in the EO conversion module - no : no loss of signal detected in the EO conversion module	specifies whether loss of signal detected or not in the EO conversion module <i>This element is only shown in detail mode.</i>
transmission	Parameter type: <Alarm::EoConvTx> (faulty ok)	specifies whether transmission fault is occurred or not in the EO module

name	Type	Description
	Possible values: - faulty : transmission fault in the EO module - ok : transmission OK	<i>This element is only shown in detail mode.</i>

104.18 Authentication Current Alarm Status Command

Command Description

This command displays the authentication current alarm status.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

> show alarm current authentication [(index)]

Command Parameters

Table 104.18-1 "Authentication Current Alarm Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm type

Command Output

Table 104.18-2 "Authentication Current Alarm Status Command" Display parameters

Specific Information		
name	Type	Description
uni	Parameter type: <Itf::BridgePortItf> (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::VpiId> : <Eqpt::VciId> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> / <Eqpt::OntPortId> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / voip <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / vuni <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::LLId> ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> /	specify which uni the alarm occurred on. <i>This element is only shown in detail mode.</i>

name	Type	Description
	<Eqpt::Ng2OntSlotId> / <Eqpt::Ng2OntPortId> ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / vuni) Possible values: - ng2 : ngpon2 style identification Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number Field type <Eqpt::VpiId> - atm VPI Field type <Eqpt::VciId> - atm VCI Field type <Eqpt::ChannelGroupId> - the channel group identifier Field type <Eqpt::SubChannelGroupId> - the subchannel group identifier Field type <Eqpt::PonId> - the PON identifier Field type <Eqpt::OntId> - the ONT identifier Field type <Eqpt::Ng2OntId> - the NG2 ONT identifier Possible values: - voip : virtual uni identifier obsolete alternative replaced by vuni - vuni : virtual uni identifier Possible values: - vuni : virtual NGPON2 uni identifier Field type <Eqpt::OntSlotId> - the ONT SLOT identifier Field type <Eqpt::OntPortId> - the ONT PORT identifier Field type <Eqpt::Ng2OntSlotId> - the NGPON2 ONT SLOT identifier Field type <Eqpt::Ng2OntPortId> - the NGPON2 ONT PORT identifier Field type <Eqpt::LLId> - the LLID identifier, range 1 for EPON, range 1-8 for DPOE	
vlan-assign	Parameter type: <Alarm::VLANAssignment> (failed successful) Possible values: - failed : failure to assign a VLAN for a user session - successful : assigned a VLAN for a user session	specifies whether a VLAN for a user session is assigned or failed <i>This element is only shown in detail mode.</i>
vsa-info-invalid	Parameter type: <Alarm::VSAValid> (yes no) Possible values: - yes : invalid VSA info alarm from RADIUS - no : valid VSA info from RADIUS and no alarm	specifies whether vsa information valid or not from RADIUS server. <i>This element is only shown in detail mode.</i>
mac-conflict	Parameter type: <Alarm::MACConflict> (yes	specifies whether mac conflict occurred or not in mac based

104 Current Alarm Status Commands

name	Type	Description
	no) Possible values: - yes : status of auth-mac-conflict alarm occurred - no : no status of auth-mac-conflict alarm occurred	authentication. <i>This element is only shown in detail mode.</i>
user-pwd-fault	Parameter type: <Alarm::USRPWDFault> (yes no) Possible values: - yes : invalid user or password alarm occurred - no : valid user and password and no alarm	specifies whether user or password valid or not in mac based authenticaiton. <i>This element is only shown in detail mode.</i>

104.19 xDSL Bonding Current Alarm Status Command

Command Description

This command displays the xDSL Bonding current alarm status.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

> show alarm current bonding-group [(index)]

Command Parameters

Table 104.19-1 "xDSL Bonding Current Alarm Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm type

Command Output

Table 104.19-2 "xDSL Bonding Current Alarm Status Command" Display parameters

Specific Information		
name	Type	Description
group	Parameter type: <Xdsl::BondingInterfaceIndex> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number	identifies the bonding group interface index <i>This element is only shown in detail mode.</i>
up-plan-bitrate	Parameter type: <Alarm::UpPlannedBitrate> (failure ok) Possible values: - failure : actual group bitrate is above the minimum	specifies whether the actual group upstream bit rate is above the group upstream planned bit rate or not <i>This element is only shown in</i>

104 Current Alarm Status Commands

name	Type	Description
	upstream bitrate but below the group upstream planned bitrate - ok : actual group bitrate is above the group upstream planned bitrate	<i>detail mode.</i>
down-plan-bitrate	Parameter type: <Alarm::DownPlanBitrate> (failure ok) Possible values: - failure : actual group bitrate is above the minimum downstream bitrate but below the group downstream planned bitrate - ok : actual group bitrate is above the group downstream planned bitrate	specifies whether the actual group downstream bit rate is above the group downstream planned bit rate or not <i>This element is only shown in detail mode.</i>
up-min-bitrate	Parameter type: <Alarm::UpMinBitrate> (failure ok) Possible values: - failure : actual group bitrate is below the group upstream minimum bitrate - ok : actual group bitrate is above the group upstream minimum bitrate	specifies whether the actual group upstream bit rate is above the group upstream minimum bit rate or not <i>This element is only shown in detail mode.</i>
down-min-bitrate	Parameter type: <Alarm::DownMinBitrate> (failure ok) Possible values: - failure : actual group bitrate is below the group downstream minimum bitrate - ok : actual group bitrate is above the group downstream minimum bitrate	specifies whether the actual group downstream bit rate is above the group downstream minimum bit rate or not <i>This element is only shown in detail mode.</i>
up-config	Parameter type: <Alarm::UpConfig> (not-feasible feasible) Possible values: - not-feasible : upstream configuration not feasible - feasible : upstream configuration feasible	specifies whether the upstream configuration is feasible or not <i>This element is only shown in detail mode.</i>
down-config	Parameter type: <Alarm::DownConfig> (not-feasible feasible) Possible values: - not-feasible : downstream configuration not feasible - feasible : downstream configuration feasible	specifies whether the downstream configuration is feasible or not <i>This element is only shown in detail mode.</i>
bond-cpe-conn	Parameter type: <Alarm::BondCPE> (not-connected connected) Possible values: - not-connected : bonding cpe modem not connected - connected : bonding cpe modem connected	specifies whether a bonding CPE modem is connected or not <i>This element is only shown in detail mode.</i>
multiple-cpes	Parameter type: <Alarm::BgConnCPE> (true false) Possible values: - true : bonding group has multiple cpe modems connected - false : bonding group has one cpe modem connected	specifies whether the lines of a bonding group are connected to multiple CPEs or only one <i>This element is only shown in detail mode.</i>
register	Parameter type: <Alarm::BgRegFail> (failure ok) Possible values:	specifies whether a discovery or aggregation failure is encountered or not <i>This element is only shown in</i>

name	Type	Description
	- failure : bonding group discovery or aggregation register failure detected - ok : bonding group discovery or aggregation register failure not detected	<i>detail mode.</i>
group-incomplete	Parameter type: <Alarm::BgNotCompl> (true false) Possible values: - true : bonding group is incomplete - false : bonding group is complete	specifies whether all configured lines of the bonding group are part of the bonding group <i>This element is only shown in detail mode.</i>

104.20 Redundancy Current Alarm Status Command

Command Description

This command displays the redundancy current alarm status.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

> show alarm current redundancy [(index)]

Command Parameters

Table 104.20-1 "Redundancy Current Alarm Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm type

Command Output

Table 104.20-2 "Redundancy Current Alarm Status Command" Display parameters

Specific Information		
name	Type	Description
loss-swo-cap	Parameter type: <Alarm::SwoCap> (loss not-loss) Possible values: - loss : system loss of the swichover capability - not-loss : system not loss of the swichover capability	identify the swichover capability in a redundant system. <i>This element is only shown in detail mode.</i>
ping-check-fail	Parameter type: <Alarm::PingCheck> (failure successful) Possible values: - failure : system failure of ping check - successful : system successful of ping check	identify the ping check in a redundant system. <i>This element is only shown in detail mode.</i>

104.21 Custom Current Alarm Status Command

Command Description

This command displays the custom current alarm status.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

> show alarm current custom [(index)]

Command Parameters

Table 104.21-1 "Custom Current Alarm Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm type

Command Output

Table 104.21-2 "Custom Current Alarm Status Command" Display parameters

Specific Information		
name	Type	Description
custom-alarm1	Parameter type: <Alarm::custom1> (yes no) Possible values: - yes : Miscellaneous environment alarm - no : no Miscellaneous environment alarm	identify the customizableAlarm1 . <i>This element is only shown in detail mode.</i>
custom-alarm2	Parameter type: <Alarm::custom2> (yes no) Possible values: - yes : Miscellaneous environment alarm - no : no Miscellaneous environment alarm	identify the customizableAlarm2 . <i>This element is only shown in detail mode.</i>
custom-alarm3	Parameter type: <Alarm::custom3> (yes no) Possible values: - yes : Miscellaneous environment alarm - no : no Miscellaneous environment alarm	identify the customizableAlarm3 . <i>This element is only shown in detail mode.</i>
custom-alarm4	Parameter type: <Alarm::custom4>	identify the customizableAlarm4

104 Current Alarm Status Commands

name	Type	Description
	(yes no) Possible values: - yes : Miscellaneous environment alarm - no : no Miscellaneous environment alarm	. <i>This element is only shown in detail mode.</i>
custom-alarm5	Parameter type: <Alarm::custom5> (yes no) Possible values: - yes : Miscellaneous environment alarm - no : no Miscellaneous environment alarm	identify the customizableAlarm5 . <i>This element is only shown in detail mode.</i>
custom-alarm6	Parameter type: <Alarm::custom6> (yes no) Possible values: - yes : Miscellaneous environment alarm - no : no Miscellaneous environment alarm	identify the customizableAlarm6 . <i>This element is only shown in detail mode.</i>
custom-alarm7	Parameter type: <Alarm::custom7> (yes no) Possible values: - yes : Miscellaneous environment alarm - no : no Miscellaneous environment alarm	identify the customizableAlarm7 . <i>This element is only shown in detail mode.</i>
custom-alarm8	Parameter type: <Alarm::custom8> (yes no) Possible values: - yes : Miscellaneous environment alarm - no : no Miscellaneous environment alarm	identify the customizableAlarm8 . <i>This element is only shown in detail mode.</i>
custom-alarm9	Parameter type: <Alarm::custom9> (yes no) Possible values: - yes : Miscellaneous environment alarm - no : no Miscellaneous environment alarm	identify the customizableAlarm9 . <i>This element is only shown in detail mode.</i>
custom-alarm10	Parameter type: <Alarm::custom10> (yes no) Possible values: - yes : Miscellaneous environment alarm - no : no Miscellaneous environment alarm	identify the customizableAlarm10 . <i>This element is only shown in detail mode.</i>
custom-alarm11	Parameter type: <Alarm::custom11> (yes no) Possible values: - yes : Miscellaneous environment alarm - no : no Miscellaneous environment alarm	identify the customizableAlarm11 . <i>This element is only shown in detail mode.</i>
custom-alarm12	Parameter type: <Alarm::custom12> (yes no) Possible values: - yes : Miscellaneous environment alarm - no : no Miscellaneous environment alarm	identify the customizableAlarm12 . <i>This element is only shown in detail mode.</i>
custom-alarm13	Parameter type: <Alarm::custom13> (yes no) Possible values:	identify the customizableAlarm13 . <i>This element is only shown in detail mode.</i>

name	Type	Description
	- yes : Miscellaneous environment alarm - no : no Miscellaneous environment alarm	
custom-alarm14	Parameter type: <Alarm::custom14> (yes no) Possible values: - yes : Miscellaneous environment alarm - no : no Miscellaneous environment alarm	identify the customizableAlarm14 . <i>This element is only shown in detail mode.</i>
custom-alarm15	Parameter type: <Alarm::custom15> (yes no) Possible values: - yes : Miscellaneous environment alarm - no : no Miscellaneous environment alarm	identify the customizableAlarm15 . <i>This element is only shown in detail mode.</i>
custom-alarm16	Parameter type: <Alarm::custom16> (yes no) Possible values: - yes : Miscellaneous environment alarm - no : no Miscellaneous environment alarm	identify the customizableAlarm16 . <i>This element is only shown in detail mode.</i>
custom-alarm17	Parameter type: <Alarm::custom17> (yes no) Possible values: - yes : Miscellaneous environment alarm - no : no Miscellaneous environment alarm	identify the customizableAlarm17 . <i>This element is only shown in detail mode.</i>

Only Show Details: host expansion shelves customizable alarms

name	Type	Description
shelf	Parameter type: <Equipm::HolderId> (<Eqpt::RackId> / <Eqpt::ShelfId> not-applicable) Possible values: - not-applicable : not applicable Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number	this is the shelf id (equipment holder id) for host expansion alarms, otherwise it is the rack ID <i>This element is only shown in detail mode.</i>
he-custom-alarm1	Parameter type: <Alarm::he-custom1> (yes no) Possible values: - yes : Miscellaneous environment alarm - no : no Miscellaneous environment alarm	identify the host expansion shelf's customizableAlarm1 . <i>This element is only shown in detail mode.</i>
he-custom-alarm2	Parameter type: <Alarm::he-custom2> (yes no) Possible values: - yes : Miscellaneous environment alarm - no : no Miscellaneous environment alarm	identify the host expansion shelf's customizableAlarm2 . <i>This element is only shown in detail mode.</i>
he-custom-alarm3	Parameter type: <Alarm::he-custom3> (yes no) Possible values: - yes : Miscellaneous environment alarm - no : no Miscellaneous environment alarm	identify the host expansion shelf's customizableAlarm3 . <i>This element is only shown in detail mode.</i>
he-custom-alarm4	Parameter type: <Alarm::he-custom4> (yes	identify the host expansion shelf's customizableAlarm4 .

104 Current Alarm Status Commands

name	Type	Description
	no) Possible values: - yes : Miscellaneous environment alarm - no : no Miscellaneous environment alarm	<i>This element is only shown in detail mode.</i>
he-custom-alarm5	Parameter type: <Alarm::he-custom5> (yes no) Possible values: - yes : Miscellaneous environment alarm - no : no Miscellaneous environment alarm	identify the host expansion shelf's customizableAlarm5 . <i>This element is only shown in detail mode.</i>
he-custom-alarm6	Parameter type: <Alarm::he-custom6> (yes no) Possible values: - yes : Miscellaneous environment alarm - no : no Miscellaneous environment alarm	identify the host expansion shelf's customizableAlarm6 . <i>This element is only shown in detail mode.</i>

104.22 SFP Current Alarm Status Command

Command Description

This command displays the SFP current alarm status.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm current sfp [ (index) ]
```

Command Parameters

Table 104.22-1 "SFP Current Alarm Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm type

Command Output

Table 104.22-2 "SFP Current Alarm Status Command" Display parameters

Specific Information		
name	Type	Description
alarm index 1	Parameter type: <Alarm::SfpAlarmIdx1Type> (<Alarm::SfpAlarmIdx1> lt : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId>) Possible values: - lt : the lt-slot Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Alarm::SfpAlarmIdx1> - the host port faceplate number or the equipment slot-id for expansion shelf alarm	this is the host sfp faceplate number for host alarms or it is the equipment slot id for expansion shelf alarms <i>This element is only shown in detail mode.</i>
alarm index 2	Parameter type: <Ihub::EthernetPort> (nt-a : sfp : <Alarm::FacePlatePortIndex> nt-a : xfp : <Alarm::FacePlatePortIndex> nt-a : eth : <Alarm::FacePlatePortIndex> nt-b : sfp : <Alarm::FacePlatePortIndex>	this is the ethernet port id or LT slot for host alarms, this index is not used for expansion shelf alarms <i>This element is only shown in</i>

104 Current Alarm Status Commands

name	Type	Description
	nt-b : xfp : <Alarm::FacePlatePortIndex> nt-b : eth : <Alarm::FacePlatePortIndex> ntio-1 : sfp : <Alarm::FacePlatePortIndex> ntio-1 : xfp : <Alarm::FacePlatePortIndex> ntio-2 : sfp : <Alarm::FacePlatePortIndex> ntio-2 : xfp : <Alarm::FacePlatePortIndex> lt : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> not-applicable lt-slot : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId>) Possible values: - nt-a : the nt-a slot - nt-b : the nt-b slot - ntio-1 : an nt applique slot in a single or multiple-ntio-shelf - ntio-2 : an nt applique slot in a multiple-ntio-shelf - lt : the lt slot - lt-slot : the port in lt slot - not-applicable : no port Possible values: - sfp : SFP port - xfp : XFP port - eth : RJ45 or lemi port Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Alarm::FacePlatePortIndex> - the faceplate port number	detail mode.

Only Show Details: host shelf alarms		
name	Type	Description
host-sfp-los	Parameter type: <Alarm::hostSFPLOS> (failing ok) Possible values: - failing : host downlink SFP loss of signal - ok : host downlink SFP signal ok	current status of SFP alarm, Host downlink SFP loss of signal <i>This element is only shown in detail mode.</i>
host-sfp-tx	Parameter type: <Alarm::hostSFPTxFail> (failing ok) Possible values: - failing : host downlink SFP tx failure - ok : host downlink SFP tx ok	current status of SFP alarm, host downlink SFP Tx failure <i>This element is only shown in detail mode.</i>
host-sfp-pres	Parameter type: <Alarm::hostSFPMissing> (not-present present) Possible values: - not-present : host downlink SFP not present - present : host downlink SFP present	current status of SFP alarm, Host downlink SFP not present <i>This element is only shown in detail mode.</i>
host-sfp-id	Parameter type: <Alarm::hostSFPInvalidNokiaID> (invalid valid) Possible values: - invalid : host downlink SFP does not have valid Nokia ID - valid : host downlink SFP has valid Nokia ID	current status of SFP alarm, host downlink SFP does not have valid Nokia ID <i>This element is only shown in detail mode.</i>
host-sfp-ctrl	Parameter type: <Alarm::hostSFPControlFail>	current status of SFP alarm, host

name	Type	Description
	(failing ok) Possible values: - failing : host downlink SFP control failure - ok : host downlink SFP control ok	downlink SFP control failure <i>This element is only shown in detail mode.</i>
host-sfp-rmtlt	Parameter type: <Alarm::hostSFPUnexpectedRemoteLT> (yes no) Possible values: - yes : host shelf SFP unexpected remote LT plug-in - no : host shelf SFP expected remote LT plug-in	current status of SFP alarm, host downlink SFP unexpected remote plug-in <i>This element is only shown in detail mode.</i>
host-sfp-mismatch	Parameter type: <Alarm::hostSFPAssignmentMismatch> (yes no) Possible values: - yes : host shelf SFP assignment does not match reported rack/shelf/slot - no : host shelf SFP assignment matches reported rack/shelf/slot	current status of SFP alarm, host downlink SFP assignment does not match reported rack/shelf/slot <i>This element is only shown in detail mode.</i>
host-sfp-incompt	Parameter type: <Alarm::hostSFPIncompatibleShelf> (yes no) Possible values: - yes : host shelf SFP incompatible shelf type detected - no : host shelf SFP compatible shelf type detected	current status of SFP alarm, host downlink SFP detected incompatible shelf type <i>This element is only shown in detail mode.</i>

Only Show Details: expansion shelf alarms

name	Type	Description
exp-sfp-los	Parameter type: <Alarm::expansionShelfSFPLos> (failing ok) Possible values: - failing : expansion shelf downlink SFP loss of signal - ok : expansion shelf downlink SFP signal ok	current status of SFP alarm, Expansion side SFP loss of signal <i>This element is only shown in detail mode.</i>
exp-sfp-tx	Parameter type: <Alarm::expansionShelfSFPTxFail> (failing ok) Possible values: - failing : expansion shelf host downlink SFP tx failure - ok : expansion shelf downlink SFP tx ok	current status of SFP alarm, Expansion shelf SFP Tx failure <i>This element is only shown in detail mode.</i>
exp-sfp-pres	Parameter type: <Alarm::expansionShelfSFPMissing> (not-present present) Possible values: - not-present : expansion shelf downlink SFP not present - present : expansion shelf downlink SFP present	current status of SFP alarm, expansion shelf SFP not present <i>This element is only shown in detail mode.</i>
exp-sfp-id	Parameter type: <Alarm::expShelfSFPInvalidNokiaID> (invalid valid) Possible values: - invalid : expansion shelf downlink SFP does not have valid Nokia ID - valid : expansion shelf downlink SFP has valid Nokia ID	current status of SFP alarm, expansion shelf SFP does not have valid Nokia ID <i>This element is only shown in detail mode.</i>
exp-sfp-ctrl	Parameter type: <Alarm::expansionShelfSFPCtrlFail> (failing ok) Possible values: - failing : expansion shelf downlink SFP control failure	current status of SFP alarm, expansion shelf downlink SFP control failure <i>This element is only shown in detail mode.</i>

104 Current Alarm Status Commands

name	Type	Description
	- ok : expansion shelf downlink SFP control ok	
exp-sfp-1-los	Parameter type: <Alarm::expansionShelfSFP1Los> (failing ok) Possible values: - failing : expansion shelf downlink SFP1 loss of signal - ok : expansion shelf downlink SFP1 signal ok	current status of SFP1 alarm, Expansion side SFP1 loss of signal <i>This element is only shown in detail mode.</i>
exp-sfp-2-los	Parameter type: <Alarm::expansionShelfSFP2Los> (failing ok) Possible values: - failing : expansion shelf downlink SFP2 loss of signal - ok : expansion shelf downlink SFP2 signal ok	current status of SFP2 alarm, Expansion side SFP2 loss of signal <i>This element is only shown in detail mode.</i>

104.23 Custom External Current Alarm Status Command

Command Description

This command displays the custom external current alarm status.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

> show alarm current custom-ext-alarm [(index)]

Command Parameters

Table 104.23-1 "Custom External Current Alarm Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm type

Command Output

Table 104.23-2 "Custom External Current Alarm Status Command" Display parameters

Specific Information		
name	Type	Description
board-position	Parameter type: <Equipm::SlotIndex> (lt : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> nt-a nt-b nt acu : <Eqpt::RackId> / <Eqpt::ShelfId> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::EqSlotId> ext-a : <Eqpt::RackId> / <Eqpt::ShelfId> ext-b : <Eqpt::RackId> / <Eqpt::ShelfId> ctrl : <Eqpt::RackId> / <Eqpt::ShelfId> vlt : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::VirtualSlotId>) Possible values: - lt : lt-slot - vlt : virtual LT slot (VVPS board can only be planned at NANT-E / FANT-F)	identify where the alarm has occurred. <i>This element is always shown.</i>

104 Current Alarm Status Commands

name	Type	Description
	- nt-a : nt-a slot - nt-b : nt-b slot - nt : nt slot - ext-a : nt-a slot in an extension shelf - ext-b : nt-b slot in an extension shelf - acu : acu slot - ctrl : ctrl-slot Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::VirtualSlotId> - the virtual LT slot number Field type <Eqpt::EqSlotId> - the equipment slot number	
ext-alarm1	Parameter type: <Alarm::custExtAlarm1> (yes no) Possible values: - yes : customizable external alarm 1 - no : no customizable external alarm 1	current status specifying external alarm 1 is present or not <i>This element is always shown.</i>
ext-alarm2	Parameter type: <Alarm::custExtAlarm2> (yes no) Possible values: - yes : customizable external alarm 2 - no : no customizable external alarm 2	current status specifying external alarm 2 is present or not <i>This element is always shown.</i>
ext-alarm3	Parameter type: <Alarm::custExtAlarm3> (yes no) Possible values: - yes : customizable external alarm 3 - no : no customizable external alarm 3	current status specifying external alarm 3 is present or not <i>This element is always shown.</i>
ext-alarm4	Parameter type: <Alarm::custExtAlarm4> (yes no) Possible values: - yes : customizable external alarm 4 - no : no customizable external alarm 4	current status specifying external alarm 4 is present or not <i>This element is always shown.</i>
ext-alarm5	Parameter type: <Alarm::custExtAlarm5> (yes no) Possible values: - yes : customizable external alarm 5 - no : no customizable external alarm 5	current status specifying external alarm 5 is present or not <i>This element is always shown.</i>

104.24 SFP RSSI Current Alarm Status Command

Command Description

This command displays the SFP RSSI current alarm status.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

> show alarm current sfrssi [(index)]

Command Parameters

Table 104.24-1 "SFP RSSI Current Alarm Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm type

Command Output

Table 104.24-2 "SFP RSSI Current Alarm Status Command" Display parameters

Specific Information		
name	Type	Description
alarm index 1	Parameter type: <Alarm::SlotIndex> (lt : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> nt-a nt-b nt acu : <Eqpt::RackId> / <Eqpt::ShelfId> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::EqSlotId> ext-a : <Eqpt::RackId> / <Eqpt::ShelfId> ext-b : <Eqpt::RackId> / <Eqpt::ShelfId> ctrl : <Eqpt::RackId> / <Eqpt::ShelfId> iont : <Eqpt::RackId> / <Eqpt::ShelfId> lp : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::LtAppliqueSlotId> ntio-1 ntio-2 vlt : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::VirtualSlotId>) Possible values: - lt : lt-slot - vlt : virtual LT slot (VVPS board can only be planned at	this is the nt/ntio slot id for Current alarms. <i>This element is only shown in detail mode.</i>

104 Current Alarm Status Commands

name	Type	Description
	NANT-E/FANT-F) - nt-a : nt-a slot - nt-b : nt-b slot - nt : nt slot - ext-a : nt-a slot in an extension shelf - ext-b : nt-b slot in an extension shelf - acu : acu slot - ctrl : ctrl-slot - iont : an nt applique slot - lp : an lt applique slot - ntio-1 : an nt applique slot in a single or multiple-ntio-shelf - ntio-2 : an nt applique slot in a multiple-ntio-shelf Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::LtAppliqueSlotId> - the LT Applique slot number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::VirtualSlotId> - the virtual LT slot number Field type <Eqpt::EqSlotId> - the equipment slot number	
alarm index 2	Parameter type: <Alarm::RssiPort> (sfp : <Alarm::RssiPort> xfp : <Alarm::RssiPort> cfp : <Alarm::RssiPort> qsf : <Alarm::RssiPort> sfp1 : <Alarm::RssiPort> sfp2 : <Alarm::RssiPort> xfp1 : <Alarm::RssiPort> xfp2 : <Alarm::RssiPort>) Possible values: - sfp : rssi sfp port - xfp : rssi xfp port - cfp : rssi cfp port - qsf : rssi qsf port - sfp1 : rssi sfp port 1 - sfp2 : rssi sfp port 2 - xfp1 : rssi xfp port 1 - xfp2 : rssi xfp port 2 Field type <Alarm::RssiPort> - value - range: [0...36]	this is the host sfp faceplate number <i>This element is only shown in detail mode.</i>

Only Show Details: sfp rssi diagnostic threshold control alarms		
name	Type	Description
tx-power-high-alarm	Parameter type: <Alarm::NTNTIOTXPWHI> (yes no) Possible values: - yes : TX optical power is too high than configured alarm high threshold - no : The TX optical power is ok	current status optical power is too high than the configured alarm high threshold <i>This element is only shown in detail mode.</i>
tx-power-low-alarm	Parameter type: <Alarm::NTNTIOTXPWLO> (yes no)	current status Tx optical power is too low than the configured alarm low threshold

name	Type	Description
	Possible values: - yes : TX optical power is too low than the configured alarm low threshold - no : TX optical power is ok	<i>This element is only shown in detail mode.</i>
rx-power-high-alarm	Parameter type: <Alarm::NTNTIORXPWHI> (yes no) Possible values: - yes : RX optical power is too high than the configured alarm high threshold - no : RX optical power is ok	current status Rx optical power is too high than the configured alarm high threshold <i>This element is only shown in detail mode.</i>
rx-power-low-alarm	Parameter type: <Alarm::NTNTIORXPWLO> (yes no) Possible values: - yes : RX optical power is too low than the configured alarm low threshold - no : RX optical power is ok	current status Rx optical power is too low than the configured alarm low threshold <i>This element is only shown in detail mode.</i>
tx-biascur-high-alarm	Parameter type: <Alarm::NTNTIOTXBIASHI> (yes no) Possible values: - yes : TX bias is too high than the configured alarm low threshold - no : TX bias current is ok	current status Tx bias is too high than the configured alarm low threshold <i>This element is only shown in detail mode.</i>
tx-biascur-low-alarm	Parameter type: <Alarm::NTNTIOTXBIASLO> (yes no) Possible values: - yes : TX bias is too low than the configured alarm low threshold - no : TX bias current is ok	current status Tx bias is too low than the configured alarm low threshold <i>This element is only shown in detail mode.</i>
volt-high-alarm	Parameter type: <Alarm::NTNTIOVOLHI> (yes no) Possible values: - yes : voltage is too high than the configured alarm high threshold - no : voltage is ok	current status voltage is too high than the configured alarm high threshold <i>This element is only shown in detail mode.</i>
volt-low-alarm	Parameter type: <Alarm::NTNTIOVOLLO> (yes no) Possible values: - yes : voltage is too low than the configured alarm low threshold - no : voltage is ok	current status voltage is too low than the configured alarm low threshold <i>This element is only shown in detail mode.</i>
temp-high-alarm	Parameter type: <Alarm::NTNTIOTEMPHI> (yes no) Possible values: - yes : temperature is too high than the configured alarm high threshold - no : temperature is ok	current status temperature is too high than the configured alarm high threshold <i>This element is only shown in detail mode.</i>
temp-low-alarm	Parameter type: <Alarm::NTNTIOTEMPLO> (yes no) Possible values:	current status temperature is too low than the configured alarm low threshold <i>This element is only shown in detail mode.</i>

104 Current Alarm Status Commands

name	Type	Description
	- yes : temperature is too low than the configured alarm low threshold - no : temperature is ok	<i>detail mode.</i>
tx-power-high-warn	Parameter type: <Alarm::NTNTIOTXPWHIWARN> (yes no) Possible values: - yes : TX optical power is too high than the configured warning high threshold - no : TX optical power is ok	current status Tx optical power is too high than the configured warning high threshold <i>This element is only shown in detail mode.</i>
tx-power-low-warn	Parameter type: <Alarm::NTNTIOTXPWLOWARN> (yes no) Possible values: - yes : TX optical power is too low than the configured warning low threshold - no : TX optical power is ok	current status Tx optical power is too low than the configured warning low threshold <i>This element is only shown in detail mode.</i>
rx-power-high-warn	Parameter type: <Alarm::NTNTIORXPWHIWARN> (yes no) Possible values: - yes : RX optical power is too low than the configured warning high threshold - no : RX optical power is ok	current status Rx optical power is too low than the configured warning high threshold <i>This element is only shown in detail mode.</i>
rx-power-low-warn	Parameter type: <Alarm::NTNTIORXPWLOWARN> (yes no) Possible values: - yes : RX optical power is too low than the configured warning low threshold - no : RX optical power is ok	current status Rx optical power is too low than the configured warning low threshold <i>This element is only shown in detail mode.</i>
tx-biascur-high-warn	Parameter type: <Alarm::NTNTIOTXBIASHIWARN> (yes no) Possible values: - yes : TX bias is too high than the configured warning high threshold - no : TX bias current is ok	current status Tx bias is too high than the configured warning high threshold <i>This element is only shown in detail mode.</i>
tx-biascur-low-warn	Parameter type: <Alarm::NTNTIOTXBIASLOWARN> (yes no) Possible values: - yes : TX bias is too low than the configured warning low threshold - no : TX bias current is ok	current status Tx bias is too low than the configured warning low threshold <i>This element is only shown in detail mode.</i>
volt-high-warn	Parameter type: <Alarm::NTNTIOVOLHIWARN> (yes no) Possible values: - yes : voltage is too high than the configured warning high threshold - no : no Miscellaneous environment alarm	current status voltage is too high than the configured warning high threshold <i>This element is only shown in detail mode.</i>
volt-low-warn	Parameter type: <Alarm::NTNTIOVOLLOWARN> (yes no) Possible values: - yes : voltage is too low than the configured warning low threshold	current status voltage is too low than the configured warning low threshold <i>This element is only shown in detail mode.</i>

name	Type	Description
	threshold - no : voltage is ok	
temp-high-warn	Parameter type: <Alarm::NTNTIOTEMPEHIWARN> (yes no) Possible values: - yes : temperature is too high than the configured warning high threshold - no : temperature is ok	current status temperature is too high than the configured warning high threshold <i>This element is only shown in detail mode.</i>
temp-low-warn	Parameter type: <Alarm::NTNTIOTEMPELOWARN> (yes no) Possible values: - yes : temperature is too high than the configured warning low threshold - no : temperature is ok	current status temperature is too low than the configured warning low threshold <i>This element is only shown in detail mode.</i>

104.25 PPP Cross-Connect Engine TCA Current Alarm Status Command

Command Description

This command displays the pppcc engine tca current alarm status.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

> show alarm current pppcc-engine-tca [(index)]

Command Parameters

Table 104.25-1 "PPP Cross-Connect Engine TCA Current Alarm Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm type

Command Output

Table 104.25-2 "PPP Cross-Connect Engine TCA Current Alarm Status Command" Display parameters

Specific Information		
name	Type	Description
engine	Parameter type: <Vlan::StackedVlanSigned> (<Vlan::UVlanIndex> stacked : <Vlan::SVlanIndex> : <Vlan::CVlanIndex>) Possible values: - stacked : stacked vlan identity Field type <Vlan::UVlanIndex> - unstacked vlan identity - range: [1...4093,4096] Field type <Vlan::SVlanIndex> - service vlan identity - range: [2...4093,4094] Field type <Vlan::CVlanIndex> - customer vlan identity - range: [0...4093,4094,4095,4096]	this is the ppp-cc engine number <i>This element is only shown in detail mode.</i>

Only Show Details: pppoe cross-connect engine tca alarms		
name	Type	Description
pppcce-trans-15min-tca	Parameter type: <Alarm::PPPCCETRANS15MIN> (yes no) Possible values: - yes : 15 minutes transaction timeout count exceeds configured TCA - no : 15 minutes transaction timeout count is OK	current 15 minutes transaction timeout count exceeds configured tca <i>This element is only shown in detail mode.</i>
pppcce-sess-15min-tca	Parameter type: <Alarm::PPPCCESESS15MIN> (yes no) Possible values: - yes : 15 minutes session timeout count exceeds configured TCA - no : 15 minutes session timeout count is OK	15 minutes session timeout count exceeds configured TCA <i>This element is only shown in detail mode.</i>
pppcce-trans-1day-tca	Parameter type: <Alarm::PPPCCETRANS1DAY> (yes no) Possible values: - yes : 1day transaction timeout count exceeds configured TCA - no : 1day transaction timeout count is OK	1day transaction timeout count exceeds configured TCA <i>This element is only shown in detail mode.</i>
pppcce-sess-1day-tca	Parameter type: <Alarm::PPPCCESESS1DAY> (yes no) Possible values: - yes : 1day session timeout count exceeds configured TCA - no : 1day session timeout count is OK	1day session timeout count exceeds configured TCA <i>This element is only shown in detail mode.</i>

104.26 Epon Olt Sfp RSSI Current Alarm Status Command

Command Description

This command displays the Epon Olt Sfp RSSI Current alarm.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm current eoltrssi [ (index) ]
```

Command Parameters

Table 104.26-1 "Epon Olt Sfp RSSI Current Alarm Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm type

Command Output

Table 104.26-2 "Epon Olt Sfp RSSI Current Alarm Status Command" Display parameters

Specific Information		
name	Type	Description
epon id	Parameter type: <Epon::PonId> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier	this is the epon id for Current alarms. <i>This element is only shown in detail mode.</i>
Only Show Details: epon olt sfp rssi diagnostic threshold control alarms		
name	Type	Description
eolt-txpwr-hi-alm	Parameter type: <Alarm::OLTTXPWHI> (yes no)	current status Tx optical power is too high than the configured alarm high threshold

name	Type	Description
	Possible values: - yes : Olt sfp Tx power is higher than the configured alarm high threshold - no : Olt sfp Tx power current is ok	<i>This element is only shown in detail mode.</i>
eolt-txpwr-lw-alm	Parameter type: <Alarm::OLTTPWLO> (yes no) Possible values: - yes : Olt sfp Tx power is lower than the configured alarm low threshold - no : Olt sfp Tx power current is ok	current status Tx optical power is too low than the configured alarm low threshold <i>This element is only shown in detail mode.</i>
eolt-txbias-hi-alm	Parameter type: <Alarm::OLTTXBIASHI> (yes no) Possible values: - yes : Olt sfp Bias is higher than the configured alarm high threshold - no : Olt sfp Bias current is ok	current status Bias is too high than the configured alarm high threshold <i>This element is only shown in detail mode.</i>
eolt-txbias-lw-alm	Parameter type: <Alarm::OLTTXBIASLO> (yes no) Possible values: - yes : Olt sfp Bias is lower than the configured alarm low threshold - no : Olt sfp Bias current is ok	current status Bias is too low than the configured alarm low threshold <i>This element is only shown in detail mode.</i>
eolt-volt-hi-alm	Parameter type: <Alarm::OLTVOLHI> (yes no) Possible values: - yes : Olt sfp voltage is higher than the configured alarm high threshold - no : Olt sfp voltage current is ok	current status voltage is too high than the configured alarm high threshold <i>This element is only shown in detail mode.</i>
eolt-volt-lw-alm	Parameter type: <Alarm::OLTVOLLO> (yes no) Possible values: - yes : Olt sfp voltage is lower than the configured alarm low threshold - no : Olt sfp voltage current is ok	current status voltage is too low than the configured alarm low threshold <i>This element is only shown in detail mode.</i>
eolt-temp-hi-alm	Parameter type: <Alarm::OLTTEMPEHI> (yes no) Possible values: - yes : Olt sfp temperature is higher than the configured alarm high threshold - no : Olt sfp temperature current is ok	current status temperature is too high than the configured alarm high threshold <i>This element is only shown in detail mode.</i>
eolt-temp-lw-alm	Parameter type: <Alarm::OLTTEMPELO> (yes no) Possible values: - yes : Olt sfp temperature is lower than the configured alarm low threshold - no : Olt sfp temperature current is ok	current status temperature is too low than the configured alarm low threshold <i>This element is only shown in detail mode.</i>
eolt-txpwr-hi-warn	Parameter type: <Alarm::OLTTPWHIWARN> (yes no) Possible values:	current status Tx optical power is too high than the configured warning high threshold <i>This element is only shown in</i>

104 Current Alarm Status Commands

name	Type	Description
	- yes : Olt sfp Tx power is higher than the configured warning high threshold - no : Olt sfp Tx power current is ok	<i>detail mode.</i>
eolt-txpwr-lw-warn	Parameter type: <Alarm::OLTTPWLOWARN> (yes no) Possible values: - yes : Olt sfp Tx power is lower than the configured warning low threshold - no : Olt sfp Tx power current is ok	current status Tx optical power is too low than the configured warning low threshold <i>This element is only shown in detail mode.</i>
eolt-txbias-hi-warn	Parameter type: <Alarm::OLTTXBIASHIWARN> (yes no) Possible values: - yes : Olt sfp Bias is higher than the configured warning high threshold - no : Olt sfp Bias current is ok	current status bias is too high than the configured warning high threshold <i>This element is only shown in detail mode.</i>
eolt-txbias-lw-warn	Parameter type: <Alarm::OLTTXBIASLOWARN> (yes no) Possible values: - yes : Olt sfp Bias is lower than the configured warning low threshold - no : Olt sfp Bias current is ok	current status bias is too low than the configured warning low threshold <i>This element is only shown in detail mode.</i>
eolt-volt-hi-warn	Parameter type: <Alarm::OLTVOLHIWARN> (yes no) Possible values: - yes : Olt sfp voltage is higher than the configured warning high threshold - no : Olt sfp voltage current is ok	current status voltage is too low than the configured warning high threshold <i>This element is only shown in detail mode.</i>
eolt-volt-lw-warn	Parameter type: <Alarm::OLTVOLLOWARN> (yes no) Possible values: - yes : Olt sfp voltage is lower than the configured warning low threshold - no : Olt sfp voltage current is ok	current status voltage is too low than the configured warning low threshold <i>This element is only shown in detail mode.</i>
eolt-temp-hi-warn	Parameter type: <Alarm::OLTTEMPEHIWARN> (yes no) Possible values: - yes : Olt sfp temperature is higher than the configured warning high threshold - no : Olt sfp temperature current is ok	current status temperature is too high than the configured warning high threshold <i>This element is only shown in detail mode.</i>
eolt-temp-lw-warn	Parameter type: <Alarm::OLTTEMPELOWARN> (yes no) Possible values: - yes : Olt sfp temperature is lower than the configured warning low threshold - no : Olt sfp temperature current is ok	current status temperature is too low than the configured warning low threshold <i>This element is only shown in detail mode.</i>
eolt-xfp-txpwr-hi-alm	Parameter type: <Alarm::OLTEXTTPWHI> (yes no) Possible values: - yes : Olt xfp Tx power is higher than the configured alarm	current status Xfp Tx optical power is too high than the configured alarm high threshold <i>This element is only shown in detail mode.</i>

name	Type	Description
	high threshold - no : Olt xfp Tx power current is ok	
eolt-xfp-txpwr-lw-alm	Parameter type: <Alarm::OLTEXTTXPWLO> (yes no) Possible values: - yes : Olt xfp Tx power is lower than the configured alarm low threshold - no : Olt xfp Tx power current is ok	current status Xfp Tx optical power is too low than the configured alarm low threshold <i>This element is only shown in detail mode.</i>
eolt-xfp-bias-hi-alm	Parameter type: <Alarm::OLTEXTTXBIASHI> (yes no) Possible values: - yes : Olt xfp Bias is higher than the configured alarm high threshold - no : Olt xfp Bias current is ok	current status Xfp bias is too high than the configured alarm high threshold <i>This element is only shown in detail mode.</i>
eolt-xfp-bias-lw-alm	Parameter type: <Alarm::OLTEXTTXBIASLO> (yes no) Possible values: - yes : Olt xfp Bias is lower than the configured alarm low threshold - no : Olt xfp Bias current is ok	current status Xfp bias is too low than the configured alarm low threshold <i>This element is only shown in detail mode.</i>
eolt-xfp-txpwr-hi-warn	Parameter type: <Alarm::OLTEXTTXPWHIWARN> (yes no) Possible values: - yes : Olt xfp Tx power is higher than the configured warning high threshold - no : Olt xfp Tx power current is ok	current status Xfp Tx optical power is too high than the configured warning high threshold <i>This element is only shown in detail mode.</i>
eolt-xfp-txpwr-lw-warn	Parameter type: <Alarm::OLTEXTTXPWLOWARN> (yes no) Possible values: - yes : Olt xfp Tx power is lower than the configured warning low threshold - no : Olt xfp Tx power current is ok	current status Xfp Tx optical power is too low than the configured warning low threshold <i>This element is only shown in detail mode.</i>
eolt-xfp-bias-hi-warn	Parameter type: <Alarm::OLTEXTTXBIASHIWARN> (yes no) Possible values: - yes : Olt xfp Bias is higher than the configured warning high threshold - no : Olt xfp Bias current is ok	current status Xfp bias is too high than the configured warning high threshold <i>This element is only shown in detail mode.</i>
eolt-xfp-bias-lw-warn	Parameter type: <Alarm::OLTEXTTXBIASLOWARN> (yes no) Possible values: - yes : Olt xfp Bias is lower than the configured warning low threshold - no : Olt xfp Bias current is ok	current status Xfp bias is too low than the configured warning low threshold <i>This element is only shown in detail mode.</i>

104.27 2xE1/DS1 SFP Clock Current Alarm Status Command

Command Description

This command displays the 2xE1/DS1 SFP Clock current alarm status.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm current sfpe1t1-clock [ (index) ]
```

Command Parameters

Table 104.27-1 "2xE1/DS1 SFP Clock Current Alarm Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm type

Command Output

Table 104.27-2 "2xE1/DS1 SFP Clock Current Alarm Status Command" Display parameters

Specific Information		
name	Type	Description
alarm index 1	Parameter type: <Alarm::SlotIndex> (lt : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> nt-a nt-b nt acu : <Eqpt::RackId> / <Eqpt::ShelfId> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::EqSlotId> ext-a : <Eqpt::RackId> / <Eqpt::ShelfId> ext-b : <Eqpt::RackId> / <Eqpt::ShelfId> ctrl : <Eqpt::RackId> / <Eqpt::ShelfId> iont : <Eqpt::RackId> / <Eqpt::ShelfId> lp : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::LtAppliqueSlotId> ntio-1 ntio-2 vlt : <Eqpt::RackId> / <Eqpt::ShelfId> /	this is the nt/ntio slot id for host alarms. <i>This element is only shown in detail mode.</i>

name	Type	Description
	<Eqpt::VirtualSlotId>) Possible values: - lt : lt-slot - vlt : virtual LT slot (VVPS board can only be planned at NANT-E/FANT-F) - nt-a : nt-a slot - nt-b : nt-b slot - nt : nt slot - ext-a : nt-a slot in an extension shelf - ext-b : nt-b slot in an extension shelf - acu : acu slot - ctrl : ctrl-slot - iont : an nt applique slot - lp : an lt applique slot - ntio-1 : an nt applique slot in a single or multiple-ntio-shelf - ntio-2 : an nt applique slot in a multiple-ntio-shelf Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::LtAppliqueSlotId> - the LT Applique slot number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::VirtualSlotId> - the virtual LT slot number Field type <Eqpt::EqSlotId> - the equipment slot number	
alarm index 2	Parameter type: <Alarm::e1t1Port> (sfp : <Alarm::E1t1FramerPort> xfp : <Alarm::E1t1FramerPort>) Possible values: - sfp : e1t1 sfp port - xfp : e1t1 xfp port Field type <Alarm::E1t1FramerPort> - value - range: [0...35]	this is the host sfp faceplate number <i>This element is only shown in detail mode.</i>

Only Show Details: e1t1 sfp clock alarms

name	Type	Description
dsx1-serdes-fail	Parameter type: <Alarm::DSX1SERDESFAIL> (yes no) Possible values: - yes : SERDES clock failure alarm - no : SERDES Clock no failure	SERDES clock failure alarm <i>This element is only shown in detail mode.</i>
dsx1-tributary1-fail	Parameter type: <Alarm::DSX1TRIB1FAIL> (yes no) Possible values: - yes : Tributary 1 clock failure alarm - no : Tributary 1 clock no failure	tributary 1 clock failure alarm <i>This element is only shown in detail mode.</i>
dsx1-tributary2-fail	Parameter type: <Alarm::DSX1TRIB2FAIL> (yes no) Possible values: - yes : Tributary 2 clock failure alarm - no : Tributary 2 clock no failure	tributary 2 clock failure alarm <i>This element is only shown in detail mode.</i>

104 Current Alarm Status Commands

name	Type	Description
dsx1-los-fail	Parameter type: <Alarm::DSX1LOSFAIL> (yes no) Possible values: - yes : All selected tributaries in Loss Of Signal - no : No All selected tributaries in Loss Of Signal	all selected tributaries in loss of signal <i>This element is only shown in detail mode.</i>
dsx1-ais-sync	Parameter type: <Alarm::DSX1AISFAIL> (yes no) Possible values: - yes : Alarm Indication Signal on the tributary selected sync source - no : No Alarm Indication Signal on the tributary selected sync source	alarm indication signal on the tributary selected as sync source <i>This element is only shown in detail mode.</i>
dsx1-lof-sync	Parameter type: <Alarm::DSX1LOFSYNCFAIL> (yes no) Possible values: - yes : Loss of Frame on the tributary selected sync source - no : No Loss of Frame on the tributary selected sync source	loss of frame on the tributary selected as sync source <i>This element is only shown in detail mode.</i>
dsx1-los-sync	Parameter type: <Alarm::DSX1LOSSYNCFAIL> (yes no) Possible values: - yes : Loss of Signal on the tributary selected sync source - no : No Loss of Signal on the tributary selected sync source	loss of signal on the tributary selected as sync source <i>This element is only shown in detail mode.</i>
dsx1-deg-fail	Parameter type: <Alarm::DSX1DEGFAIL> (yes no) Possible values: - yes : Signal degrade alarm - no : Signal degrade alarm	signal degrade alarm <i>This element is only shown in detail mode.</i>

104.28 2xE1/DS1 SFP Framer Alarm Status Command

Command Description

This command displays the 2xE1/DS1 SFP Framer current alarm status.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm current sfpe1t1-framer [ (index) ]
```

Command Parameters

Table 104.28-1 "2xE1/DS1 SFP Framer Alarm Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm type

Command Output

Table 104.28-2 "2xE1/DS1 SFP Framer Alarm Status Command" Display parameters

Specific Information		
name	Type	Description
alarm index 1	Parameter type: <Alarm::SlotIndex> (lt : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> nt-a nt-b nt acu : <Eqpt::RackId> / <Eqpt::ShelfId> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::EqSlotId> ext-a : <Eqpt::RackId> / <Eqpt::ShelfId> ext-b : <Eqpt::RackId> / <Eqpt::ShelfId> ctrl : <Eqpt::RackId> / <Eqpt::ShelfId> iont : <Eqpt::RackId> / <Eqpt::ShelfId> lp : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::LtAppliqueSlotId> ntio-1 ntio-2 vlt : <Eqpt::RackId> / <Eqpt::ShelfId> /	this is the nt/ntio slot id for host alarms. <i>This element is only shown in detail mode.</i>

104 Current Alarm Status Commands

name	Type	Description
	<Eqpt::VirtualSlotId>) Possible values: - lt : lt-slot - vlt : virtual LT slot (VVPS board can only be planned at NANT-E/FANT-F) - nt-a : nt-a slot - nt-b : nt-b slot - nt : nt slot - ext-a : nt-a slot in an extension shelf - ext-b : nt-b slot in an extension shelf - acu : acu slot - ctrl : ctrl-slot - iont : an nt applique slot - lp : an lt applique slot - ntio-1 : an nt applique slot in a single or multiple-ntio-shelf - ntio-2 : an nt applique slot in a multiple-ntio-shelf Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::LtAppliqueSlotId> - the LT Applique slot number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::VirtualSlotId> - the virtual LT slot number Field type <Eqpt::EqSlotId> - the equipment slot number	
alarm index 2	Parameter type: <Alarm::e1t1framerPort> (sfp : <Alarm::E1t1FramerPort> : <Alarm::tributary> xfp : <Alarm::E1t1FramerPort> : <Alarm::tributary>) Possible values: - sfp : e1t1 sfp port - xfp : e1t1 xfp port Field type <Alarm::E1t1FramerPort> - value - range: [0...35] Field type <Alarm::tributary> - value - range: [1...2]	this is the host sfp faceplate number <i>This element is only shown in detail mode.</i>

Only Show Details: e1t1 framer alarms		
name	Type	Description
rei-from-liu	Parameter type: <Alarm::DSX1REILIU> (yes no) Possible values: - yes : e1t1 sfp Remote Error Indication Alarm from LIU - no : No e1t1 sfp Remote Error Indication Alarm from LIU	remote error indication alarm from LIU <i>This element is only shown in detail mode.</i>
rdi-from-liu	Parameter type: <Alarm::DSX1RDILIU> (yes no) Possible values: - yes : e1t1 sfp Remote Defect Alarmn from LIU - no : No e1t1 sfp Remote Defect Alarmn from LIU	remote defect indication alarm from LIU <i>This element is only shown in detail mode.</i>
crc6-from-liu	Parameter type: <Alarm::DSX1CRC6LIU> (yes no)	cyclic redundancy check 6 from LIU <i>This element is only shown in</i>

name	Type	Description
	Possible values: - yes : e1t1 sfp Cyclic Redundancy Check 6 from LIU - no : No e1t1 sfp Cyclic Redundancy Check 6 from LIU	<i>detail mode.</i>
crc4-from-liu	Parameter type: <Alarm::DSX1CRC4LIU> (yes no) Possible values: - yes : e1t1 sfp Cyclic Redundancy Check 4 from LIU - no : No e1t1 sfp Cyclic Redundancy Check 4 from LIU	cyclic redundancy check 4 from LIU <i>This element is only shown in detail mode.</i>
crc4-threshold-from-liu	Parameter type: <Alarm::DSX1CRC4THLIU> (yes no) Possible values: - yes : e1t1 sfp Cyclic Redundancy Check 4 threshold alarm from LIU - no : No e1t1 sfp Cyclic Redundancy Check 4 threshold alarm from LIU	cyclic redundancy check 4 threshold alarm from LIU <i>This element is only shown in detail mode.</i>
ais-from-liu	Parameter type: <Alarm::DSX1AISLIU> (yes no) Possible values: - yes : e1t1 sfp Alarm Indication Signal alarm from LIU - no : No e1t1 sfp Alarm Indication Signal alarm from LIU	alarm indication signal alarm from LIU <i>This element is only shown in detail mode.</i>
los-from-liu	Parameter type: <Alarm::DSX1LOSLIU> (yes no) Possible values: - yes : e1t1 sfp Loss of signal alarm from LIU - no : No e1t1 sfp Loss of signal alarm from LIU	loss of signal alarm from LIU <i>This element is only shown in detail mode.</i>
lof-from-liu	Parameter type: <Alarm::DSX1LOFLIU> (yes no) Possible values: - yes : e1t1 sfp Loss of frame alarm from LIU - no : No e1t1 sfp Loss of frame alarm from LIU	loss of frame alarm from LIU <i>This element is only shown in detail mode.</i>
lomf-from-liu	Parameter type: <Alarm::DSX1LOMFLIU> (yes no) Possible values: - yes : e1t1 sfp Loss of multi frame alarm from LIU - no : No e1t1 sfp Loss of multi frame alarm from LIU	loss of multi frame alarm from LIU <i>This element is only shown in detail mode.</i>
rei-from-iwf	Parameter type: <Alarm::DSX1REIIWF> (yes no) Possible values: - yes : e1t1 sfp Remote Error Indication Alarm from IWF - no : No e1t1 sfp Remote Error Indication Alarm from IWF	remote error indication alarm from IWF <i>This element is only shown in detail mode.</i>
rdi-from-iwf	Parameter type: <Alarm::DSX1RDIIWF> (yes no) Possible values: - yes : e1t1 sfp Remote Defect Alarm from IWF - no : No e1t1 sfp Remote Defect Alarm from IWF	remote defect indication alarm from IWF <i>This element is only shown in detail mode.</i>
crc6-from-iwf	Parameter type: <Alarm::DSX1CRC6IWF> (yes no) Possible values:	cyclic redundancy check 6 from IWF <i>This element is only shown in detail mode.</i>

104 Current Alarm Status Commands

name	Type	Description
	- yes : e1t1 sfp Cyclic Redundancy Check 6 from IWF - no : No e1t1 sfp Cyclic Redundancy Check 6 from IWF	
crc4-from-iwf	Parameter type: <Alarm::DSX1CRC4IWF> (yes no) Possible values: - yes : e1t1 sfp Cyclic Redundancy Check 4 from IWF - no : No e1t1 sfp Cyclic Redundancy Check 4 from IWF	cyclic redundancy check 4 from IWF <i>This element is only shown in detail mode.</i>
crc4-threshold-from-iwf	Parameter type: <Alarm::DSX1CRC4THIWF> (yes no) Possible values: - yes : e1t1 sfp Cyclic Redundancy Check 4 threshold alarm from IWF - no : No e1t1 sfp Cyclic Redundancy Check 4 threshold alarm from IWF	cyclic redundancy check 4 threshold alarm from IWF <i>This element is only shown in detail mode.</i>
ais-from-iwf	Parameter type: <Alarm::DSX1AISIWF> (yes no) Possible values: - yes : e1t1 sfp Alarm Indication Signal alarm from IWF - no : No e1t1 sfp Alarm Indication Signal alarm from IWF	alarm indication signal alarm from IWF <i>This element is only shown in detail mode.</i>
los-from-iwf	Parameter type: <Alarm::DSX1LOSIWF> (yes no) Possible values: - yes : e1t1 sfp Loss of signal alarm from IWF - no : No e1t1 sfp Loss of signal alarm from IWF	loss of signal alarm from IWF <i>This element is only shown in detail mode.</i>
lof-from-iwf	Parameter type: <Alarm::DSX1LOFIWF> (yes no) Possible values: - yes : e1t1 sfp Loss of frame alarm from IWF - no : No e1t1 sfp Loss of frame alarm from IWF	loss of frame alarm from IWF <i>This element is only shown in detail mode.</i>
lomf-from-iwf	Parameter type: <Alarm::DSX1LOMFIWF> (yes no) Possible values: - yes : e1t1 sfp Loss of multi frame alarm from IWF - no : No e1t1 sfp Loss of multi frame alarm from IWF	loss of multi frame alarm from LIU <i>This element is only shown in detail mode.</i>

104.29 Plug In Unit Extended Current Alarm Status Command

Command Description

This command shows the plug-in unit extended current alarm status.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

> show alarm current plug-in-unit-ext [(index)]

Command Parameters

Table 104.29-1 "Plug In Unit Extended Current Alarm Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm type

Command Output

Table 104.29-2 "Plug In Unit Extended Current Alarm Status Command" Display parameters

Specific Information		
name	Type	Description
board-position	Parameter type: <Equipm::SlotIndex> (lt : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> nt-a nt-b nt acu : <Eqpt::RackId> / <Eqpt::ShelfId> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::EqSlotId> ext-a : <Eqpt::RackId> / <Eqpt::ShelfId> ext-b : <Eqpt::RackId> / <Eqpt::ShelfId> ctrl : <Eqpt::RackId> / <Eqpt::ShelfId> vlt : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::VirtualSlotId>) Possible values: - lt : lt-slot - vlt : virtual LT slot (VVPS board can only be planned at NANT-E / FANT-F)	identify where the alarm has occurred. <i>This element is only shown in detail mode.</i>

104 Current Alarm Status Commands

name	Type	Description
	- nt-a : nt-a slot - nt-b : nt-b slot - nt : nt slot - ext-a : nt-a slot in an extension shelf - ext-b : nt-b slot in an extension shelf - acu : acu slot - ctrl : ctrl-slot Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::VirtualSlotId> - the virtual LT slot number Field type <Eqpt::EqSlotId> - the equipment slot number	
ctrl-dnld-addinfo	Parameter type: <PrintableString> - printable string	displays the current version of controller card. <i>This element is only shown in detail mode.</i>

Only Show Details: current alarm status		
name	Type	Description
fan-alarm	Parameter type: <Alarm::pluginFan> (yes no) Possible values: - yes : fan alarm - no : no fan alarm	current status specifying fan alarm is present or not <i>This element is only shown in detail mode.</i>
dc-a-alarm	Parameter type: <Alarm::plugin-dc-a> (yes no) Possible values: - yes : dc a failure alarm - no : no dc a failure alarm	current status specifying dc-a failure alarm is present or not <i>This element is only shown in detail mode.</i>
dc-b-alarm	Parameter type: <Alarm::plugin-dc-b> (yes no) Possible values: - yes : dc b failure alarm - no : no dc b failure alarm	current status specifying dc-b failure alarm is present or not <i>This element is only shown in detail mode.</i>
dg-alarm	Parameter type: <Alarm::plugin-dg> (yes no) Possible values: - yes : dying gasp alarm - no : no dying gasp alarm	current status specifying dying gasp alarm is present or not <i>This element is only shown in detail mode.</i>
apsf-alarm	Parameter type: <Alarm::pluginApsf> (yes no) Possible values: - yes : apsf failure alarm - no : no apsf failure alarm	power for the applique is available or not <i>This element is only shown in detail mode.</i>
ntr-a-loss	Parameter type: <Alarm::NTRALoss> (yes no) Possible values:	current status specifying NTR-A loss alarm is present or not <i>This element is only shown in detail mode.</i>

name	Type	Description
	- yes : ntr-a signal unavailable - no : ntr-a signal available	
ntr-b-loss	Parameter type: <Alarm::NTRBLoss> (yes no) Possible values: - yes : ntr-b signal unavailable - no : ntr-b signal available	current status specifying NTR-B loss alarm is present or not <i>This element is only shown in detail mode.</i>
xvps-conf-loss	Parameter type: <Alarm::XvpsConfLoss> (yes no) Possible values: - yes : implicit xvps configuration loss. - no : no implicit xvps configuration loss.	implicit xvps configuration loss or not. <i>This element is only shown in detail mode.</i>
mac-entry-nofree	Parameter type: <Alarm::MacNofree> (nofree free) Possible values: - nofree : no free mac entry in the mac table on the lt board. - free : file transfer server available.	current status specifying no free mac entry in the mac table on the lt board <i>This element is only shown in detail mode.</i>
fibre-conn-mismatch	Parameter type: <Alarm::FibreConnMismatch> (yes no) Possible values: - yes : REM fibre connection mismatch alarm - no : no REM fibre connection mismatch alarm	current status specifying fibre connection mismatch on detected control card. <i>This element is only shown in detail mode.</i>
link-cap-mismatch	Parameter type: <Alarm::LinkCapMismatch> (yes no) Possible values: - yes : actual link speed is not inline with the end-to-end link capability between NT and LT - no : actual link speed is inline with the end-to-end link capability between NT and LT	current status actual link speed is not in line with the end-to-end link capability between NT and LT. <i>This element is only shown in detail mode.</i>
eqpt-cap-mismatch	Parameter type: <Alarm::EqptCapMismatch> (yes no) Possible values: - yes : not all equipment between NT and LT can support the speed that NT and LT can support within the configured MaxLinkSpeed. - no : all equipment between NT and LT can support the speed that NT and LT can support within the configured MaxLinkSpeed.	current status not all equipment between NT and LT can support the speed that NT and LT can support within the configured MaxLinkSpeed. <i>This element is only shown in detail mode.</i>
ctrl-dnld-failed	Parameter type: <Alarm::CtrlDownloadFailure> (yes no) Possible values: - yes : The downloading of the Software image to the controller card failed.. - no : The downloading of the Software image to the controller card passed.	current status The downloading of the Software image to the controller card failed. <i>This element is only shown in detail mode.</i>
melt-hw-issue	Parameter type: <Alarm::BoardHWIssue> (yes no) Possible values: - yes : Board hardware issue	current status MELT hardware issue. <i>This element is only shown in detail mode.</i>

104 Current Alarm Status Commands

name	Type	Description
	- no : No Board hardware issue.	
melt-board-reset	Parameter type: <Alarm::BoardHWIssue> (yes no) Possible values: - yes : Board hardware issue - no : No Board hardware issue.	current status MELT Board reset. <i>This element is only shown in detail mode.</i>
board-shelf-mismatch	Parameter type: <Alarm::boardShelfMismatch> (yes no) Possible values: - yes : plugged-in board and shelf type are mismatch - no : plugged-in board and shelf type are match	alarm specifying the shelf type and plugged-in board types are mismatch. <i>This element is only shown in detail mode.</i>
single-fan-fail	Parameter type: <Alarm::SINGLEFANFAILURE> (yes no) Possible values: - yes : single fan failure` - no : no single fan failure	current status of single fan failure <i>This element is only shown in detail mode.</i>
multi-fan-fail	Parameter type: <Alarm::MULTIFANFAILURE> (yes no) Possible values: - yes : more than one fan failed - no : NO MULTIPLE fans are failed	current status of MULTIPLE fan failure <i>This element is only shown in detail mode.</i>
fan-tray-missing	Parameter type: <Alarm::FANTRAYMISSING> (yes no) Possible values: - yes : fan tray missing - no : fans tray is present	current status of fan tray <i>This element is only shown in detail mode.</i>

104.30 SIP Server Current Alarm Status Command

Command Description

This command displays the SIP Server current alarm status.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

> show alarm current sip-server [(index)]

Command Parameters

Table 104.30-1 "SIP Server Current Alarm Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm type

Command Output

Table 104.30-2 "SIP Server Current Alarm Status Command" Display parameters

Specific Information		
name	Type	Description
server-index	Parameter type: <Sip::ServerId> - the SIP server table index - range: [1...128]	identifies sip server <i>This element is only shown in detail mode.</i>
transport-mismatch	Parameter type: <Alarm::transportMismatch> (yes no) Possible values: - yes : mismatch - no : not mismatch	specifies isamv and server transport mismatch or not. <i>This element is only shown in detail mode.</i>
dns-lookup-failure	Parameter type: <Alarm::dnsLookUpFailure> (yes no) Possible values: - yes : fail - no : not fail	specifies dns look up fail or not. <i>This element is only shown in detail mode.</i>

104.31 SIP VSP Current Alarm Status Command

Command Description

This command displays the SIP VSP current alarm status.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

> show alarm current sip-vsp [(index)]

Command Parameters

Table 104.31-1 "SIP VSP Current Alarm Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm type

Command Output

Table 104.31-2 "SIP VSP Current Alarm Status Command" Display parameters

Specific Information		
name	Type	Description
vsp-index	Parameter type: <Sip::DialPlanId> - the dial plan table index - range: [1...255]	identifies sip vsp <i>This element is only shown in detail mode.</i>
none-dns-srv	Parameter type: <Alarm::noneDNSSRV> (yes no) Possible values: - yes : none of dns server give reply to to DNS look up - no : dns server give reply to to DNS look up	specifies none of dns server give reply to to DNS look up or not. <i>This element is only shown in detail mode.</i>
no-dns-srv	Parameter type: <Alarm::noDNSSRV> (yes no) Possible values: - yes : no dns server configured when sip request - no : dns server configured when sip request	specifies no dns server configured when sip request or not. <i>This element is only shown in detail mode.</i>
none-srv	Parameter type: <Alarm::noneSRV> (yes no) Possible values:	specifies none sip server give reply when send sip request or not. <i>This element is only shown in</i>

name	Type	Description
	- yes : none sip server give reply when send sip request - no : sip server give reply when send sip request	<i>detail mode.</i>
no-srv	Parameter type: <Alarm::noSRV> (yes no) Possible values: - yes : no sip proxy server configured when send sip request - no : sip proxy server configured when send sip request	specifies no sip proxy server configured when send sip request or not. <i>This element is only shown in detail mode.</i>
reg-srv-unreach	Parameter type: <Alarm::noRegSRV> (yes no) Possible values: - yes : no sip register server give reply when send sip register - no : sip register server give reply when send sip register	specifies no sip register servers give reply when send sip register or not. <i>This element is only shown in detail mode.</i>
prxy-srv-unreach	Parameter type: <Alarm::noPrxySRV> (yes no) Possible values: - yes : no sip proxy server give reply when send sip request - no : sip proxy server give reply when send sip request	specifies no sip proxy servers give reply when send sip request or not. <i>This element is only shown in detail mode.</i>
fo-trigger	Parameter type: <Alarm::foTrigger> (yes no) Possible values: - yes : fail over triggered - no : fail over is not triggered	specifies fail-over is triggered or not. <i>This element is only shown in detail mode.</i>
fb-trigger	Parameter type: <Alarm::fbTrigger> (yes no) Possible values: - yes : fail back triggered - no : fail back is not triggered	specifies fail-back is triggered or not. <i>This element is only shown in detail mode.</i>
du-trigger	Parameter type: <Alarm::duTrigger> (yes no) Possible values: - yes : deliberate update triggered - no : deliberate update is not triggered	specifies deliberate-update is triggered or not. <i>This element is only shown in detail mode.</i>
ssp-missing	Parameter type: <Alarm::sspMissing> (yes no) Possible values: - yes : SSP missing in CDE - no : SSP exist in CDE	specifies ssp missing in cde or not. <i>This element is only shown in detail mode.</i>
dns-pool-exceed	Parameter type: <Alarm::dnsPoolExceed> (yes no) Possible values: - yes : Number of different SG associated DNS pools exceed - no : Number of different SG associated DNS pools exceed	specifies Number of different SG associated DNS pools exceed or not. <i>This element is only shown in detail mode.</i>
lsa-fo-trigger	Parameter type: <Alarm::lsaFoTrigger> (yes no) Possible values: - yes : SIP voice service degraded - fail-over to LSA server - no : fail-over to LSA server is not triggered	specifies lsa-fail-over is triggered or not. <i>This element is only shown in detail mode.</i>

104.32 SIP Dial Plan Current Alarm Status Command

Command Description

This command displays the SIP dial plan current alarm status.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

> show alarm current sip-dial-plan [(index)]

Command Parameters

Table 104.32-1 "SIP Dial Plan Current Alarm Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm type

Command Output

Table 104.32-2 "SIP Dial Plan Current Alarm Status Command" Display parameters

Specific Information		
name	Type	Description
dialplan-index	Parameter type: <Sip::DialPlanId> - the dial plan table index - range: [1...255]	identifies the dial plan <i>This element is only shown in detail mode.</i>
bad-digitmap	Parameter type: <Alarm::badDigitMap> (yes no) Possible values: - yes : digit map unusable - no : digit map usable	specifies sip digitmap status. <i>This element is only shown in detail mode.</i>

104.33 SIP User Agent Current Alarm Status Command

Command Description

This command displays the SIP user agent current alarm status.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

> show alarm current sip-user-agent [(index)]

Command Parameters

Table 104.33-1 "SIP User Agent Current Alarm Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm type

Command Output

Table 104.33-2 "SIP User Agent Current Alarm Status Command" Display parameters

Specific Information		
name	Type	Description
ua-index	Parameter type: <Sip::UserAgentId> - SIP user agent table index - range: [1...255]	identifies the user agent <i>This element is only shown in detail mode.</i>
slot-index	Parameter type: <Equipm::EqptSlotIndex> (lt : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> nt-a nt-b nt acu : <Eqpt::RackId> / <Eqpt::ShelfId> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::EqSlotId> ext-a : <Eqpt::RackId> / <Eqpt::ShelfId> ext-b : <Eqpt::RackId> / <Eqpt::ShelfId> ctrl : <Eqpt::RackId> / <Eqpt::ShelfId> vlt : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::VirtualSlotId>) Possible values:	identifies the board <i>This element is only shown in detail mode.</i>

name	Type	Description
	- lt : lt-slot - vlt : virtual LT slot (VVPS board can only be planned at NANT-E / FANT-F) - nt-a : nt-a slot - nt-b : nt-b slot - nt : nt slot - ext-a : nt-a slot in an extension shelf - ext-b : nt-b slot in an extension shelf - acu : acu slot - ctrl : ctrl-slot Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::VirtualSlotId> - the virtual LT slot number Field type <Eqpt::EqSlotId> - the equipment slot number	
bad-digitmap	Parameter type: <Alarm::badDigitMap> (yes no) Possible values: - yes : digit map unusable - no : digit map usable	specifies sip digitmap status. <i>This element is only shown in detail mode.</i>
dhcp-unreach	Parameter type: <Alarm::dhcpUnreach> (yes no) Possible values: - yes : The DHCP server is unreachable - no : The DHCP server is reachable	specifies the DHCP server is unreachable or not <i>This element is only shown in detail mode.</i>
dhcp-no-srv	Parameter type: <Alarm::dhcpNoSrv> (yes no) Possible values: - yes : The address in DHCP reply is NULL - no : The address in DHCP reply is not NULL	specifies the address in DHCP reply is NULL or not <i>This element is only shown in detail mode.</i>
dhcp-inv-srv	Parameter type: <Alarm::dhcpInvSrv> (yes no) Possible values: - yes : The address in DHCP reply is invalid - no : The address in DHCP reply is OK	specifies the address in DHCP reply is invalid or not <i>This element is only shown in detail mode.</i>

104.34 SIP Slot Current Alarm Status Command

Command Description

This command displays the SIP slot current alarm status.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

> show alarm current sip-plugin-unit [(index)]

Command Parameters

Table 104.34-1 "SIP Slot Current Alarm Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm type

Command Output

Table 104.34-2 "SIP Slot Current Alarm Status Command" Display parameters

Specific Information		
name	Type	Description
slot-index	Parameter type: <Equipm::LtSlotIndex> (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId>) Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number	identifies the board <i>This element is only shown in detail mode.</i>
short-res	Parameter type: <Alarm::shortResource> (yes no) Possible values: - yes : short call resource - no : have call resource	sepcifies the call resource short or not. <i>This element is only shown in detail mode.</i>
norpniewithsoftdsp	Parameter type: <Alarm::noRpniEWithSoftDsp> (yes no) Possible values:	sepcifies if plan / plug-in RPNI-E board with SoftDsp SW image or not. <i>This element is only shown in</i>

name	Type	Description
	- yes : plan / plug-in RPNI-E board with SoftDsp SW image - no : no plan / plug-in RPNI-E board with SoftDsp SW image	<i>detail mode.</i>

104.35 SIP Termination Current Alarm Status Command

Command Description

This command displays the SIP termination current alarm status.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

> show alarm current sip-termination [(index)]

Command Parameters

Table 104.35-1 "SIP Termination Current Alarm Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm type

Command Output

Table 104.35-2 "SIP Termination Current Alarm Status Command" Display parameters

Specific Information		
name	Type	Description
term-index	Parameter type: <Itf::PotsLine> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number	identifies the termination <i>This element is only shown in detail mode.</i>
unknown-sub	Parameter type: <Alarm::unknownSubscriber> (yes no) Possible values: - yes : wrong subscriber	specifies the sip subscriber unknown or not. <i>This element is only shown in detail mode.</i>

name	Type	Description
	- no : right subscriber	
ground-key	Parameter type: <Alarm::groundKey> (yes no) Possible values: - yes : current to ground - no : current not to ground	status of the ground key. <i>This element is only shown in detail mode.</i>
port-hightemp	Parameter type: <Alarm::highTemperature> (yes no) Possible values: - yes : high temperature - no : not high temperature	status of the port temperature. <i>This element is only shown in detail mode.</i>
l1-act-failure	Parameter type: <Alarm::l1ActFailure> (yes no) Possible values: - yes : high temperature - no : not high temperature	status of the layer 1 activation. <i>This element is only shown in detail mode.</i>
port-overcurrent	Parameter type: <Alarm::overCurrent> (yes no) Possible values: - yes : over current - no : not over current	status of the port current. <i>This element is only shown in detail mode.</i>
port-jbfltca	Parameter type: <Alarm::jbflTca> (yes no) Possible values: - yes : high jb fill level - no : not high jb fill level	status of the port jitter buffer fill level tca. <i>This element is only shown in detail mode.</i>
reg-domainname	Parameter type: <Alarm::regdomainname> (yes no) Possible values: - yes : register - resolving domain name failed - no : register - resolving domain name successful	status of resolving domain name (register). <i>This element is only shown in detail mode.</i>
reg-auth	Parameter type: <Alarm::regauth> (yes no) Possible values: - yes : register - authentication failed - no : register - authentication successful	status of authentication (register). <i>This element is only shown in detail mode.</i>
reg-timeout	Parameter type: <Alarm::regtimeout> (yes no) Possible values: - yes : register - message timeout - no : register - message not timeout	status of message timeout (register). <i>This element is only shown in detail mode.</i>
reg-srvfailresp	Parameter type: <Alarm::regsrvfailresp> (yes no) Possible values: - yes : register - failure response from server - no : register - successful response from server	status of failure response from server (register). <i>This element is only shown in detail mode.</i>
inv-domainname	Parameter type: <Alarm::invdomainname> (yes	status of resolving domain name (invite).

104 Current Alarm Status Commands

name	Type	Description
	no) Possible values: - yes : invite - resolving domain name failed - no : invite - resolving domain name successful	<i>This element is only shown in detail mode.</i>
inv-auth	Parameter type: <Alarm::invauth> (yes no) Possible values: - yes : invite - authentication failed - no : invite - authentication successful	status of authentication (invite). <i>This element is only shown in detail mode.</i>
inv-timeout	Parameter type: <Alarm::invtimeout> (yes no) Possible values: - yes : invite - message timeout - no : invite - message not timeout	status of message timeout (invite). <i>This element is only shown in detail mode.</i>
inv-srvfailresp	Parameter type: <Alarm::invsrvfailresp> (yes no) Possible values: - yes : invite - failure response from server - no : invite - successful response from server	status of failure response from server (invite). <i>This element is only shown in detail mode.</i>
subs-srvfailresp	Parameter type: <Alarm::subsrvfailresp> (yes no) Possible values: - yes : subscribe - failure response from server - no : subscribe - successful response from server	status of failure response from server (subscribe). <i>This element is only shown in detail mode.</i>
subs-domainname	Parameter type: <Alarm::subsdomainname> (yes no) Possible values: - yes : Subscribe - resolving domain name failed - no : Subscribe - resolving domain name successful	status of resolving domain name (subscribe). <i>This element is only shown in detail mode.</i>
subs-auth	Parameter type: <Alarm::subsauth> (yes no) Possible values: - yes : Subscribe - authentication failed - no : Subscribe - authentication successful	status of authentication(subscribe). <i>This element is only shown in detail mode.</i>
subs-refreshfail	Parameter type: <Alarm::subsrefreshfail> (yes no) Possible values: - yes : Subscribe - refresh failure - no : Subscribe - refresh failure	status of message timeout or 481 received (refresh subscribe). <i>This element is only shown in detail mode.</i>
subs-inittimeout	Parameter type: <Alarm::subsintimeout> (yes no) Possible values: - yes : Subscribe - initial REQ timeout - no : Subscribe - initial REQ timeout	status of message timeout (initial subscribe). <i>This element is only shown in detail mode.</i>
emergency-call	Parameter type: <Alarm::emergencycall> (yes no) Possible values: - yes : emergency call is ongoing	status of emergency call. <i>This element is only shown in detail mode.</i>

name	Type	Description
	- no : emergency call is not ongoing	
additional-info	Parameter type: <Alarm::AddInfoString> - additional alarm information	Additional information regarding the reg-srvfailresp alarm. <i>This element is only shown in detail mode.</i>

104.36 Secondary SIP Termination Current Alarm Status Command

Command Description

This command displays the secondary SIP termination current alarm status.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

> show alarm current secondary-sip-term [(index)]

Command Parameters

Table 104.36-1 "Secondary SIP Termination Current Alarm Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm type

Command Output

Table 104.36-2 "Secondary SIP Termination Current Alarm Status Command" Display parameters

Specific Information		
name	Type	Description
term-index	Parameter type: <Itf::PotsLine> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number	identifies the secondary term <i>This element is only shown in detail mode.</i>
reg-domainname-sec	Parameter type: <Alarm::regdomainname> (yes no) Possible values:	status of resolving domain name (register). <i>This element is only shown in detail mode.</i>

name	Type	Description
	- yes : register - resolving domain name failed - no : register - resolving domain name successful	
reg-auth-sec	Parameter type: <Alarm::regauth> (yes no) Possible values: - yes : register - authentication failed - no : register - authentication successful	status of authentication (register). <i>This element is only shown in detail mode.</i>
reg-timeout-sec	Parameter type: <Alarm::regtimeout> (yes no) Possible values: - yes : register - message timeout - no : register - message not timeout	status of message timeout (register). <i>This element is only shown in detail mode.</i>
reg-srvfailresp-sec	Parameter type: <Alarm::regsrvfailresp> (yes no) Possible values: - yes : register - failure response from server - no : register - successful response from server	status of failure response from server (register). <i>This element is only shown in detail mode.</i>
inv-domainname-sec	Parameter type: <Alarm::invdomainname> (yes no) Possible values: - yes : invite - resolving domain name failed - no : invite - resolving domain name successful	status of resolving domain name (invite). <i>This element is only shown in detail mode.</i>
inv-auth-sec	Parameter type: <Alarm::invauth> (yes no) Possible values: - yes : invite - authentication failed - no : invite - authentication successful	status of authentication (invite). <i>This element is only shown in detail mode.</i>
inv-timeout-sec	Parameter type: <Alarm::invtimeout> (yes no) Possible values: - yes : invite - message timeout - no : invite - message not timeout	status of message timeout (invite). <i>This element is only shown in detail mode.</i>
inv-srvfailresp-sec	Parameter type: <Alarm::invsrvfailresp> (yes no) Possible values: - yes : invite - failure response from server - no : invite - successful response from server	status of failure response from server (invite). <i>This element is only shown in detail mode.</i>
subs-srvfailresp-sec	Parameter type: <Alarm::subssrvfailresp> (yes no) Possible values: - yes : subscribe - failure response from server - no : subscribe - successful response from server	status of failure response from server (subscribe). <i>This element is only shown in detail mode.</i>
subs-domainname-sec	Parameter type: <Alarm::subsdomainname> (yes no) Possible values: - yes : Subscribe - resolving domain name failed - no : Subscribe - resolving domain name successful	status of resolving domain name (subscribe). <i>This element is only shown in detail mode.</i>
subs-auth-sec	Parameter type: <Alarm::subsauth>	status of

104 Current Alarm Status Commands

name	Type	Description
	(yes no) Possible values: - yes : Subscribe - authentication failed - no : Subscribe - authentication successful	authentication(subscribe). <i>This element is only shown in detail mode.</i>
subs-refreshfail-sec	Parameter type: <Alarm::subsrefreshfail> (yes no) Possible values: - yes : Subscribe - refresh failure - no : Subscribe - refresh failure	status of message timeout or 481 received (refresh subscribe). <i>This element is only shown in detail mode.</i>
subs-inittimeout-sec	Parameter type: <Alarm::subsinittimeout> (yes no) Possible values: - yes : Subscribe - initial REQ timeout - no : Subscribe - initial REQ timeout	status of message timeout (initial subscribe). <i>This element is only shown in detail mode.</i>
emergency-call-sec	Parameter type: <Alarm::emergencycall> (yes no) Possible values: - yes : emergency call is ongoing - no : emergency call is not ongoing	status of emergency call. <i>This element is only shown in detail mode.</i>
additional-info	Parameter type: <Alarm::AddInfoString> - additional alarm information	Additional information regarding the reg-srvfailresp alarm. <i>This element is only shown in detail mode.</i>

104.37 SIP Termination Current Alarm Status Command

Command Description

This command displays the SIP termination current alarm status.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

> show alarm current e1-sip-termination [(index)]

Command Parameters

Table 104.37-1 "SIP Termination Current Alarm Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm type

Command Output

Table 104.37-2 "SIP Termination Current Alarm Status Command" Display parameters

Specific Information		
name	Type	Description
term-index	Parameter type: <Itf::IsdnLine> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number	identifies the termination <i>This element is only shown in detail mode.</i>
reg-domainname	Parameter type: <Alarm::isdnregdomainname> (yes no) Possible values: - yes : register - resolving domain name failed	status of resolving domain name (register). <i>This element is only shown in detail mode.</i>

104 Current Alarm Status Commands

name	Type	Description
	- no : register - resolving domain name successful	
reg-auth	Parameter type: <Alarm::isdnregauth> (yes no) Possible values: - yes : register - authentication failed - no : register - authentication successful	status of authentication (register). <i>This element is only shown in detail mode.</i>
reg-timeout	Parameter type: <Alarm::isdnregtimeout> (yes no) Possible values: - yes : register - message timeout - no : register - message not timeout	status of message timeout (register). <i>This element is only shown in detail mode.</i>
reg-srvfailresp	Parameter type: <Alarm::isdnregsrvfailresp> (yes no) Possible values: - yes : register - failure response from server - no : register - successful response from server	status of failure response from server (register). <i>This element is only shown in detail mode.</i>
inv-domainname	Parameter type: <Alarm::isdninvdomainname> (yes no) Possible values: - yes : invite - resolving domain name failed - no : invite - resolving domain name successful	status of resolving domain name (invite). <i>This element is only shown in detail mode.</i>
inv-auth	Parameter type: <Alarm::isdninvauth> (yes no) Possible values: - yes : invite - authentication failed - no : invite - authentication successful	status of authentication (invite). <i>This element is only shown in detail mode.</i>
inv-timeout	Parameter type: <Alarm::isdninvtimeout> (yes no) Possible values: - yes : invite - message timeout - no : invite - message not timeout	status of message timeout (invite). <i>This element is only shown in detail mode.</i>
inv-srvfailresp	Parameter type: <Alarm::isdninvsrvfailresp> (yes no) Possible values: - yes : invite - failure response from server - no : invite - successful response from server	status of failure response from server (invite). <i>This element is only shown in detail mode.</i>
emergency-call	Parameter type: <Alarm::isdnemergencycall> (yes no) Possible values: - yes : emergency call is ongoing - no : emergency call is not ongoing	status of emergency call. <i>This element is only shown in detail mode.</i>
ais-signal	Parameter type: <Alarm::isdnaissignal> (yes no) Possible values: - yes : Alarm Indication Signal detected at E1 interface - no : no Alarm Indication Signal detected at E1 interface	status of Alarm Indication Signal. <i>This element is only shown in detail mode.</i>
los-signal	Parameter type: <Alarm::isdnlossignal> (yes	status of Loss Of Signal Alarm. <i>This element is only shown in</i>

name	Type	Description
	no) Possible values: - yes : Loss Of Signal detected at E1 interface - no : no Loss Of Signal detected at E1 interface	<i>detail mode.</i>
rai-signal	Parameter type: <Alarm::isdnraisignal> (yes no) Possible values: - yes : Remote Alarm Indication detected at E1 interface - no : no Remote Alarm Indication detected at E1 interface	status of Remote Alarm Indication. <i>This element is only shown in detail mode.</i>
e1sip-misconfig-mgc10	Parameter type: <Alarm::sipmiscfgmgc10> (yes no) Possible values: - yes : Configuration not conform with the core network entity - no : no Configuration not conform with the core network entity	status of config error when connect to mgc10. <i>This element is only shown in detail mode.</i>
e1sip-nsmprf-missed	Parameter type: <Alarm::sipnsmprofmis> (yes no) Possible values: - yes : The SIP termination requires a NSM profile - no : no The SIP termination requires a NSM profile	status of requires a NSM profile. <i>This element is only shown in detail mode.</i>
additional-info	Parameter type: <Alarm::AddInfoString> - additional alarm information	Additional information regarding the reg-srvfailresp alarm. <i>This element is only shown in detail mode.</i>

104.38 E1T1 Interface Current Alarm Status Command

Command Description

This command shows the status of E1T1 interface alarm

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

> show alarm current e1t1-interface [(index)]

Command Parameters

Table 104.38-1 "E1T1 Interface Current Alarm Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm type

Command Output

Table 104.38-2 "E1T1 Interface Current Alarm Status Command" Display parameters

Specific Information		
name	Type	Description
ifindex	Parameter type: <Itf::IsdnLine> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number	value of the Ifindex of the SIP termination <i>This element is only shown in detail mode.</i>
e1t1itf-recv-ais	Parameter type: <Alarm::itfaissignal> (yes no) Possible values: - yes : Alarm Indication Signal received at interface	status of Alarm Indication Signal detected at interface. <i>This element is only shown in detail mode.</i>

name	Type	Description
	- no : no Alarm Indication Signal received at interface	
e1t1itf-recv-los	Parameter type: <Alarm::itflossignal> (yes no) Possible values: - yes : Loss Of Signal received at interface - no : no Loss Of Signal received at interface	status of Loss Of Signal Alarm detected at interface. <i>This element is only shown in detail mode.</i>
e1t1itf-recv-rai	Parameter type: <Alarm::itfraissignal> (yes no) Possible values: - yes : Remote Alarm Indication received at interface - no : no Remote Alarm Indication received at interface	status of Remote Alarm Indication detected at interface. <i>This element is only shown in detail mode.</i>
additional-info	Parameter type: <Alarm::AddInfoString> - additional alarm information	Additional information regarding the E1/T1 interface alarm. <i>This element is only shown in detail mode.</i>

104.39 SIP Termination Current Alarm Status Command

Command Description

This command displays the SIP termination current alarm status.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm current cas-r2-channel [ (index) ]
```

Command Parameters

Table 104.39-1 "SIP Termination Current Alarm Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm type

Command Output

Table 104.39-2 "SIP Termination Current Alarm Status Command" Display parameters

Specific Information		
name	Type	Description
term-index	Parameter type: <Itf::IsdnLine> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number	identifies the termination <i>This element is only shown in detail mode.</i>
channel-id	Parameter type: <Alarm::E1ChannelId> - The E1 channel Id - range: [0...31]	identifies the E1 channel <i>This element is only shown in detail mode.</i>
exp-seizureack	Parameter type: <Alarm::ExpSeizureAck> (yes	status of seizure ack signal <i>This element is only shown in</i>

name	Type	Description
	no) Possible values: - yes : Channel was blocked due to failure in the reception of the SEIZURE ACK signal - no : Channel was not blocked due to failure in the reception of the SEIZURE ACK signal	<i>detail mode.</i>
exp-disconack	Parameter type: <Alarm::ExpDisconnectAck> (yes no) Possible values: - yes : Channel was blocked due to failure in the reception of the DISCONNECTION ACK signal - no : Channel was not blocked due to failure in the reception of the DISCONNECTION ACK signal	status of disconnect ack signal <i>This element is only shown in detail mode.</i>
exp-forcerelack	Parameter type: <Alarm::ExpForceRelAck> (yes no) Possible values: - yes : Channel was blocked due to failure in the reception of the BACKWARD DISCONNECTION ACK signal - no : No Channel was blocked due to failure in the reception of the BACKWARD DISCONNECTION ACK signal	status of forced release ack signal <i>This element is only shown in detail mode.</i>

104.40 Pseudo Wire Current Alarm Status Command

Command Description

This command displays current alarm status of the Pseudo Wire.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

> show alarm current pseudo-wire [(index)]

Command Parameters

Table 104.40-1 "Pseudo Wire Current Alarm Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm type

Command Output

Table 104.40-2 "Pseudo Wire Current Alarm Status Command" Display parameters

Specific Information		
name	Type	Description
term-index	Parameter type: <Itf::IsdnLine> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number	identify the pseudo wire. <i>This element is only shown in detail mode.</i>
packet-loss	Parameter type: <Alarm::PacketLoss> (yes no) Possible values: - yes : Pseudo Wire entered the Packet loss state	specifies the packet loss is unknown or not. <i>This element is only shown in detail mode.</i>

name	Type	Description
	- no : Pseudo Wire not entered the Packet loss state	
remote-packet-loss	Parameter type: <Alarm::RemotePacketLoss> (yes no) Possible values: - yes : Remote Packet loss detected - no : Remote Packet loss not detected	specifies the remote packet loss or not. <i>This element is only shown in detail mode.</i>
no-dsp-resource	Parameter type: <Alarm::NoDspResource> (yes no) Possible values: - yes : DSP resource allocation failed - no : DSP resource allocation failed	specifies no DSP resource or not. <i>This element is only shown in detail mode.</i>

104.41 Megaco Media Gateway Current Alarm Status Command

Command Description

This command displays the Megaco media gateway current alarm status.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm current megaco-media-gw [ (index) ]
```

Command Parameters

Table 104.41-1 "Megaco Media Gateway Current Alarm Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm type

Command Output

Table 104.41-2 "Megaco Media Gateway Current Alarm Status Command" Display parameters

Specific Information		
name	Type	Description
board-position	Parameter type: <Equipm::EqptSlotIndex> (lt : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> nt-a nt-b nt acu : <Eqpt::RackId> / <Eqpt::ShelfId> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::EqSlotId> ext-a : <Eqpt::RackId> / <Eqpt::ShelfId> ext-b : <Eqpt::RackId> / <Eqpt::ShelfId> ctrl : <Eqpt::RackId> / <Eqpt::ShelfId> vlt : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::VirtualSlotId>) Possible values: - lt : lt-slot - vlt : virtual LT slot (VVPS board can only be planned at NANT-E / FANT-F)	identify the board where the alarm has occurred. <i>This element is only shown in detail mode.</i>

name	Type	Description
	- nt-a : nt-a slot - nt-b : nt-b slot - nt : nt slot - ext-a : nt-a slot in an extension shelf - ext-b : nt-b slot in an extension shelf - acu : acu slot - ctrl : ctrl-slot Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::VirtualSlotId> - the virtual LT slot number Field type <Eqpt::EqSlotId> - the equipment slot number	
mgc-unreachable	Parameter type: <Alarm::mgcUnreachable> (yes no) Possible values: - yes : media gateway controller is unreachable - no : media gateway controller is reachable	specifies the media gateway controller is unreachable or not. <i>This element is only shown in detail mode.</i>
failover-to-esamgc	Parameter type: <Alarm::failoverttoESAMGC> (yes no) Possible values: - yes : failover to esa mgc - no : normal mgc is in service	specifies the media gateway failover to esa mgc or not. <i>This element is only shown in detail mode.</i>

104.42 Megaco Signaling Gateway Current Alarm Status Command

Command Description

This command displays the Megaco signaling gateway current alarm status.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm current megaco-sig-gw [ (index) ]
```

Command Parameters

Table 104.42-1 "Megaco Signaling Gateway Current Alarm Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm type

Command Output

Table 104.42-2 "Megaco Signaling Gateway Current Alarm Status Command" Display parameters

Specific Information		
name	Type	Description
board-position	Parameter type: <Equipm::LtSlotIndex> (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId>) Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number	identify the board where the alarm has occurred. <i>This element is only shown in detail mode.</i>
sgc-unreachable	Parameter type: <Alarm::sgcUnreachable> (yes no) Possible values: - yes : signalling gateway controller is unreachable - no : signalling gateway controller is reachable	specifies the signaling gateway controller is unreachable or not. <i>This element is only shown in detail mode.</i>

104.43 Megaco Plugin Unit Current Alarm Status Command

Command Description

This command displays the Megaco plugin unit current alarm status.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

> show alarm current megaco-plug-unit [(index)]

Command Parameters

Table 104.43-1 "Megaco Plugin Unit Current Alarm Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm type

Command Output

Table 104.43-2 "Megaco Plugin Unit Current Alarm Status Command" Display parameters

Specific Information		
name	Type	Description
board-position	Parameter type: <Equipm::PortSlotIndex> (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::NewSlotId> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::NewSlotId>) Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::NewSlotId> - the LT slot number	identify the board where the alarm has occurred. <i>This element is only shown in detail mode.</i>
lcard-unreach-srvcard	Parameter type: <Alarm::lineCardUnreachSrvCard> (yes no) Possible values: - yes : line card is unreachable with server card - no : line card is reachable with server card	specifies the line card is unreachable with server card or not. <i>This element is only shown in detail mode.</i>
lcard-type-mismatch	Parameter type: <Alarm::lineCardTypeMismatchch>	specifies the line card type is

name	Type	Description
	(yes no) Possible values: - yes : line card type is mismatch - no : line card type is match	mismatch or not. <i>This element is only shown in detail mode.</i>

104.44 Megaco Termination Current Alarm Status Command

Command Description

This command displays the Megaco termination current alarm status.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

> show alarm current megaco-term [(index)]

Command Parameters

Table 104.44-1 "Megaco Termination Current Alarm Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm type

Command Output

Table 104.44-2 "Megaco Termination Current Alarm Status Command" Display parameters

Specific Information		
name	Type	Description
port	Parameter type: <Itf::MegacoPotsLine> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::NewSlotId> / <Eqpt::MegacoPortId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::NewSlotId> - the LT slot number Field type <Eqpt::MegacoPortId> - the port number of Megaco	identify the physical position of the port. <i>This element is only shown in detail mode.</i>
meg-unknown-sub	Parameter type: <Alarm::megacoUnknownSubscriber> (yes no) Possible values: - yes : unknown wrong megaco subscriber	specifies the megaco subscriber is unknown or not. <i>This element is only shown in detail mode.</i>

name	Type	Description
	- no : no wrong megaco subscriber	
meg-ground-key	Parameter type: <Alarm::voicePortGroundKey> (yes no) Possible values: - yes : voice port ground key - no : voice port not ground key	specifies the voice port ground key or not. <i>This element is only shown in detail mode.</i>
meg-high-temp	Parameter type: <Alarm::voicePortHighTemp> (yes no) Possible values: - yes : voice port high temperature - no : voice port not high temperature	specifies the voice port high temperature or not. <i>This element is only shown in detail mode.</i>
l1-act-fail	Parameter type: <Alarm::voicePortL1ActFail> (yes no) Possible values: - yes : voice port l1 act failure - no : voice port l1 act not failure	specifies the voice port l1 act failure or not. <i>This element is only shown in detail mode.</i>
over-current	Parameter type: <Alarm::voicePortOverCurrent> (yes no) Possible values: - yes : voice port over current - no : voice port not over current	specifies the voice port over current or not. <i>This element is only shown in detail mode.</i>
line-showering	Parameter type: <Alarm::lineshowering> (yes no) Possible values: - yes : line showering - no : no line showering	specifies the line showering or not. <i>This element is only shown in detail mode.</i>
low-qos-packetloss	Parameter type: <Alarm::lowQosPacketLoss> (yes no) Possible values: - yes : the total packet loss has exceeded the configured threshold - no : the total packet loss has not exceeded the configured threshold	specifies the megaco total packet loss has exceeded the configured threshold or not. <i>This element is only shown in detail mode.</i>
low-qos-jitter	Parameter type: <Alarm::lowQosJitter> (yes no) Possible values: - yes : the rtp jitter has exceeded the configured threshold - no : the rtp jitter has not exceeded the configured threshold	specifies the megaco rtp jitter has exceeded the configured threshold or not. <i>This element is only shown in detail mode.</i>
low-qos-delay	Parameter type: <Alarm::lowQosDelay> (yes no) Possible values: - yes : the rtp delay has exceeded the configured threshold - no : the rtp delay has not exceeded the configured threshold	specifies the megaco rtp delay has exceeded the configured threshold or not. <i>This element is only shown in detail mode.</i>

104.45 Secondary Megaco Termination Current Alarm Status Command

Command Description

This command displays current alarm status of the secondary Megaco termination.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

> show alarm current secondary-megaco-term [(index)]

Command Parameters

Table 104.45-1 "Secondary Megaco Termination Current Alarm Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm type

Command Output

Table 104.45-2 "Secondary Megaco Termination Current Alarm Status Command" Display parameters

Specific Information		
name	Type	Description
port	Parameter type: <Itf::MegacoPotsLine> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::NewSlotId> / <Eqpt::MegacoPortId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::NewSlotId> - the LT slot number Field type <Eqpt::MegacoPortId> - the port number of Megaco	identify the physical position of the port. <i>This element is only shown in detail mode.</i>
meg-unknown-sub-sec	Parameter type: <Alarm::megacoUnknownSubscriber> (yes no)	specifies the megaco subscriber is unknown or not. <i>This element is only shown in</i>

name	Type	Description
	Possible values: - yes : unknown wrong megaco subscriber - no : no wrong megaco subscriber	<i>detail mode.</i>
line-showering-sec	Parameter type: <Alarm::lineshowering> (yes no) Possible values: - yes : line showering - no : no line showering	specifies the line showering or not. <i>This element is only shown in detail mode.</i>

104.46 Megaco Signaling Lt Current Alarm Status Command

Command Description

This command displays the Megaco signaling Lt current alarm status.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm current megaco-sig-lt [ (index) ]
```

Command Parameters

Table 104.46-1 "Megaco Signaling Lt Current Alarm Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm type

Command Output

Table 104.46-2 "Megaco Signaling Lt Current Alarm Status Command" Display parameters

Specific Information		
name	Type	Description
board-position	Parameter type: <Equipm::LtSlotIndex> (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId>) Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number	identify the board where the alarm has occurred. <i>This element is only shown in detail mode.</i>
sig-brd-persist-loss	Parameter type: <Alarm::megacoSigBoardPersDataLoss> (yes no) Possible values: - yes : the voice signaling board persistenet data loss - no : the voice signaling board persistenet data not loss	specifies the voice signaling board persistenet data loss or not. <i>This element is only shown in detail mode.</i>
sig-brd-disk-full	Parameter type: <Alarm::voiceSigBoard90PercentFull>	specifies the voice signaling

name	Type	Description
	(yes no) Possible values: - yes : specifies the voice signaling board disk 90% full - no : specifies the voice signaling board disk no 90% full	board disk 90% full or not. <i>This element is only shown in detail mode.</i>
sig-brd-db-rollback	Parameter type: <Alarm::sigBoardDBRollback> (yes no) Possible values: - yes : specifies the voice signaling board implicit db rollback - no : specifies the voice signaling board implicit db no rollback	specifies the voice signaling board implicit db rollback or not. <i>This element is only shown in detail mode.</i>
mg-overload	Parameter type: <Alarm::megMGOverLoad> (yes no) Possible values: - yes : specifies the mg overload - no : specifies the mg no overload	specifies the mg overload or not. <i>This element is only shown in detail mode.</i>

104.47 E1Current Alarm Status Command

Command Description

This command displays the E1 current alarm status.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm current e1 [ (index) ]
```

Command Parameters

Table 104.47-1 "E1Current Alarm Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm type

Command Output

Table 104.47-2 "E1Current Alarm Status Command" Display parameters

Specific Information		
name	Type	Description
port	Parameter type: <Itf::E1Line> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number	identifies the physical position of the port <i>This element is only shown in detail mode.</i>
rx-rai	Parameter type: <Alarm::E1RxRai> (yes no) Possible values: - yes : recieving RAI - no : no recieving RAI	current status of e1 recieving RAI <i>This element is only shown in detail mode.</i>
tx-rai	Parameter type: <Alarm::E1TxRai> (yes	current status of e1 transmitting RAI

name	Type	Description
	no) Possible values: - yes : transmitting RAI - no : no transmitting RAI	<i>This element is only shown in detail mode.</i>
rx-ais	Parameter type: <Alarm::E1RxAis> (yes no) Possible values: - yes : recieving AIS - no : no recieving AIS	current status of e1 recieving AIS <i>This element is only shown in detail mode.</i>
tx-ais	Parameter type: <Alarm::E1TxAis> (yes no) Possible values: - yes : transmitting AIS - no : no transmitting AIS	current status of e1 transmitting AIS <i>This element is only shown in detail mode.</i>
lof	Parameter type: <Alarm::E1LOF> (yes no) Possible values: - yes : loss of frame - no : no loss of frame	current status of e1 loss of frame <i>This element is only shown in detail mode.</i>
los	Parameter type: <Alarm::E1LOS> (yes no) Possible values: - yes : loss of signal - no : no loss of signal	current status of e1 loss of signal <i>This element is only shown in detail mode.</i>
loopback	Parameter type: <Alarm::E1Loopback> (yes no) Possible values: - yes : facility in loopback - no : facility not in loopback	current status of e1 loopback <i>This element is only shown in detail mode.</i>

104.48 Shdsl Current Alarm Status Command

Command Description

This command displays the Shdsl current alarm status.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm current shdsl [ (index) ]
```

Command Parameters

Table 104.48-1 "Shdsl Current Alarm Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm type

Command Output

Table 104.48-2 "Shdsl Current Alarm Status Command" Display parameters

Specific Information		
name	Type	Description
port	Parameter type: <Itf::ShdslLine> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number	identifies the physical position of the port <i>This element is only shown in detail mode.</i>
unit	Parameter type: <Alarm::LinkDeviceValues> - a signed integer	identify where the alarm has occurred <i>This element is only shown in detail mode.</i>
loop-act-net	Parameter type: <Alarm::LoopbackActiveNetwork> (yes no) Possible values:	current status of loopback active at the network side <i>This element is only shown in detail mode.</i>

name	Type	Description
	- yes : loopback active - no : no loopback active	
loop-act-cus	Parameter type: <Alarm::LoopbackActiveCustom> (yes no) Possible values: - yes : loopback active - no : no loopback active	current status of loopback active at the custom side <i>This element is only shown in detail mode.</i>
config-error	Parameter type: <Alarm::ConfigError> (yes no) Possible values: - yes : config error - no : no config error	current status of configuration error <i>This element is only shown in detail mode.</i>
loss-atm	Parameter type: <Alarm::LossATMCellDel> (yes no) Possible values: - yes : loss atm cell delineation - no : no loss atm cell delineation	current status of loss of atm cell delineation <i>This element is only shown in detail mode.</i>
loss-pr	Parameter type: <Alarm::LossPowerSTUR> (yes no) Possible values: - yes : loss power at stu-r - no : no loss power at stu-r	current status of loss of power at stu-r <i>This element is only shown in detail mode.</i>
secu-error	Parameter type: <Alarm::UnableDisableSTUR> (yes no) Possible values: - yes : loss ability at stu-r - no : no loss ability at stu-r	current status of loss of ability to disable stu-r access <i>This element is only shown in detail mode.</i>
dev-fault	Parameter type: <Alarm::DeviceFault> (yes no) Possible values: - yes : device fault - no : no device fault	current status of fault of device <i>This element is only shown in detail mode.</i>
atm-ncd	Parameter type: <Alarm::ATMCellDel> (yes no) Possible values: - yes : no atm cell delineation - no : atm cell delineation	current status of none of atm cell delineation <i>This element is only shown in detail mode.</i>

104.49 Shdsl Current Alarm Status Command

Command Description

This command displays the Shdsl current alarm status.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

> show alarm current shdsl-isam [(index)]

Command Parameters

Table 104.49-1 "Shdsl Current Alarm Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm type

Command Output

Table 104.49-2 "Shdsl Current Alarm Status Command" Display parameters

Specific Information		
name	Type	Description
port	Parameter type: <Itf::ShdslLine> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number	identifies the physical position of the port <i>This element is only shown in detail mode.</i>
wire-pair	Parameter type: <Alarm::LinkDeviceValuesHigh> - identify where the alarm occurred	identify where the alarm has occurred <i>This element is only shown in detail mode.</i>
unit	Parameter type: <Alarm::LinkDeviceValuesLow> - identify where the alarm occurred	identify where the alarm has occurred <i>This element is only shown in detail mode.</i>

name	Type	Description
loss-syn-net	Parameter type: <Alarm::LossSyncWordNetwork> (yes no) Possible values: - yes : loss sync word - no : no loss sync word	current status of loss of sync word at the network side on each pair <i>This element is only shown in detail mode.</i>
loss-syn-cus	Parameter type: <Alarm::LossSyncWordCustom> (yes no) Possible values: - yes : loss sync word - no : no loss sync word	current status of loss of sync word at the custom side on each pair <i>This element is only shown in detail mode.</i>
loop-att-net	Parameter type: <Alarm::LoopAttenuationNetwork> (yes no) Possible values: - yes : loop attenuation - no : no loop attenuation	current status of loop attenuation alarm at the network side on each pair <i>This element is only shown in detail mode.</i>
loop-att-cus	Parameter type: <Alarm::LoopAttenuationCustom> (yes no) Possible values: - yes : loop attenuation - no : no loop attenuation	current status of loop attenuation alarm at the custom side on each pair <i>This element is only shown in detail mode.</i>
snr-net	Parameter type: <Alarm::SNRNetwork> (yes no) Possible values: - yes : snr margin - no : no snr margin	current status of snr margin alarm at the network side each pair <i>This element is only shown in detail mode.</i>
snr-cus	Parameter type: <Alarm::SNRCustom> (yes no) Possible values: - yes : snr margin - no : no snr margin	current status of snr margin alarm at the custom side each pair <i>This element is only shown in detail mode.</i>
dc-net	Parameter type: <Alarm::DCContinuityFaultNetwork> (yes no) Possible values: - yes : dc fault - no : no dc fault	current status of dc continuity fault at the network side on each pair <i>This element is only shown in detail mode.</i>
dc-cus	Parameter type: <Alarm::DCContinuityFaultCustom> (yes no) Possible values: - yes : dc fault - no : no dc fault	current status of dc continuity fault at the custom side on each pair <i>This element is only shown in detail mode.</i>

104.50 Ima-Group Current Alarm Status Command

Command Description

This command displays the Ima-Group current alarm status.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

> show alarm current ima-group [(index)]

Command Parameters

Table 104.50-1 "Ima-Group Current Alarm Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm type

Command Output

Table 104.50-2 "Ima-Group Current Alarm Status Command" Display parameters

Specific Information		
name	Type	Description
port	Parameter type: <Equipm::AtmImaIndex> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number	identifies the physical position of the port <i>This element is only shown in detail mode.</i>
far-end-start	Parameter type: <Alarm::FarEndStartup> (yes no) Possible values: - yes : far-end startup - no : no far-end startup	current status of far-end starting up <i>This element is only shown in detail mode.</i>
far-end-fconf	Parameter type: <Alarm::FarEndFailedConfig> (yes	current status of failed configuration of far-end

name	Type	Description
	no) Possible values: - yes : far-end failed config - no : no far-end failed config	<i>This element is only shown in detail mode.</i>
near-end-fconf	Parameter type: <Alarm::NearEndFailedConfig> (yes no) Possible values: - yes : near-end failed config - no : no near-end failed config	current status of failed configuration of near-end <i>This element is only shown in detail mode.</i>
far-end-ins-lnk	Parameter type: <Alarm::FarEndInsuffLinkNum> (yes no) Possible values: - yes : insufficient number of links at far-end - no : no insufficient number of links at far-end	current status of insufficient number of links at far-end <i>This element is only shown in detail mode.</i>
near-end-ins-lnk	Parameter type: <Alarm::NearEndInsuffLinkNum> (yes no) Possible values: - yes : insufficient number of links at near-end - no : no insufficient number of links at near-end	current status of insufficient number of links at near-end <i>This element is only shown in detail mode.</i>
far-end-blk	Parameter type: <Alarm::FarEndBlocked> (yes no) Possible values: - yes : far-end blocked - no : no far-end blocked	current status of status that far-end is blocked <i>This element is only shown in detail mode.</i>

104.51 Ima-Link Current Alarm Status Command

Command Description

This command displays the Ima-Link current alarm status.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

> show alarm current ima-link [(index)]

Command Parameters

Table 104.51-1 "Ima-Link Current Alarm Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm type

Command Output

Table 104.51-2 "Ima-Link Current Alarm Status Command" Display parameters

Specific Information		
name	Type	Description
port	Parameter type: <Itf::ShdslLine> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number	identifies the physical position of the port <i>This element is only shown in detail mode.</i>
loss-ima-frm	Parameter type: <Alarm::LossImaFrame> (yes no) Possible values: - yes : loss ima frame - no : no loss ima frame	current status of loss of ima frame <i>This element is only shown in detail mode.</i>
lods	Parameter type: <Alarm::LinkOutOfDelaySynch> (yes	current status of link out of delay synchronization

name	Type	Description
	no) Possible values: - yes : link out of delay - no : no link out of delay	<i>This element is only shown in detail mode.</i>
link-misc	Parameter type: <Alarm::LinkMisconnect> (yes no) Possible values: - yes : link misconnect - no : no link misconnect	current status of link of misconnecting <i>This element is only shown in detail mode.</i>
link-rfi	Parameter type: <Alarm::LinkRemoteFailureIndication> (yes no) Possible values: - yes : link remote failure indication - no : no link remote failure indication	current status of link of remote failure indication <i>This element is only shown in detail mode.</i>
link-fault	Parameter type: <Alarm::LinkFault> (yes no) Possible values: - yes : fault in link facility - no : no fault in link facility	current status of fault of link <i>This element is only shown in detail mode.</i>
fe-tx-blk	Parameter type: <Alarm::FarEndTXBlocked> (yes no) Possible values: - yes : transmit blocked due to far-end - no : no transmit blocked due to far-end	current status of transmit blocked due to far-end <i>This element is only shown in detail mode.</i>
fe-rec-blk	Parameter type: <Alarm::FarEndRXBlocked> (yes no) Possible values: - yes : receive blocked due to far-end - no : no receive blocked due to far-end	current status of receive blocked due to far-end <i>This element is only shown in detail mode.</i>

104.52 Alarm Current Ether-Tca Status Command

Command Description

This command displays the Ether-Tca related alarms.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

> show alarm current ether-tca [(index)]

Command Parameters

Table 104.52-1 "Alarm Current Ether-Tca Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm type

Command Output

Table 104.52-2 "Alarm Current Ether-Tca Status Command" Display parameters

Specific Information		
name	Type	Description
port	Parameter type: <Itf::EthernetPortIndex> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number	identify where the alarm has occurred <i>This element is only shown in detail mode.</i>
etca-los	Parameter type: <Alarm::EthTcaLos> (yes no) Possible values: - yes : ethernet loss of signal errors exceeds - no : ethernet loss of signal errors normal	current status of ethernet los in 15 min <i>This element is only shown in detail mode.</i>
etca-fcs	Parameter type: <Alarm::EthTcaFcs> (yes	current status of ethernet fcs in 15 min

name	Type	Description
	no) Possible values: - yes : ethernet frame check sequence errors exceeds - no : ethernet frame check sequence errors normal	<i>This element is only shown in detail mode.</i>
etca-rx-octets	Parameter type: <Alarm::EthTcaRxb> (yes no) Possible values: - yes : received octets exceeds - no : received octets normal	current status of received octets in 15 min <i>This element is only shown in detail mode.</i>
etca-tx-octets	Parameter type: <Alarm::EthTcaTxb> (yes no) Possible values: - yes : transmitted octets exceeds - no : transmitted octets normal	current status of transmitted octets in 15 min <i>This element is only shown in detail mode.</i>
etca-day-los	Parameter type: <Alarm::EthDayLos> (yes no) Possible values: - yes : ethernet day los errors exceeds - no : ethernet day los errors normal	current status of ethernet day los <i>This element is only shown in detail mode.</i>
etca-day-fcs	Parameter type: <Alarm::EthDayFcs> (yes no) Possible values: - yes : ethernet day fcs errors exceeds - no : ethernet day fcs errors normal	current status of ethernet day fcs <i>This element is only shown in detail mode.</i>
etca-day-rx-octets	Parameter type: <Alarm::EthDayRxb> (yes no) Possible values: - yes : received octets day exceeds - no : received octets day normal	current status of received octets in 1 day <i>This element is only shown in detail mode.</i>
etca-day-tx-octets	Parameter type: <Alarm::EthDayTxb> (yes no) Possible values: - yes : transmitted octets day exceeds - no : transmitted octets day normal	current status of transmitted octets in 1 day <i>This element is only shown in detail mode.</i>

104.53 Alarm Current Ether-Sfp Status Command

Command Description

This command displays the Ether-Sfp related alarms.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

> show alarm current ether-sfp [(index)]

Command Parameters

Table 104.53-1 "Alarm Current Ether-Sfp Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm type

Command Output

Table 104.53-2 "Alarm Current Ether-Sfp Status Command" Display parameters

Specific Information		
name	Type	Description
port	Parameter type: <If::EthernetPortIndex> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number	identify where the alarm has occurred <i>This element is only shown in detail mode.</i>
user-sfp-los	Parameter type: <Alarm::EthSfpLos> (yes no) Possible values: - yes : ethernet sfp los error - no : ethernet sfp los normal	current status of ethernet sfp los <i>This element is only shown in detail mode.</i>
user-sfp-tx-fail	Parameter type: <Alarm::EthSfpTxFail> (yes	current status of ethernet sfp tx <i>This element is only shown in</i>

name	Type	Description
	no) Possible values: - yes : ethernet sfp Tx Failure - no : ethernet sfp Tx normal	<i>detail mode.</i>
user-sfp-not-prst	Parameter type: <Alarm::EthSfpNotPrst> (yes no) Possible values: - yes : ethernet sfp not detected - no : ethernet sfp detected	current status of ethernet sfp presence <i>This element is only shown in detail mode.</i>
user-sfp-inv-id	Parameter type: <Alarm::EthSfpInvalid> (yes no) Possible values: - yes : ethernet sfp id invalid - no : ethernet sfp id normal	current status of ethernet sfp id <i>This element is only shown in detail mode.</i>
user-sfp-t-exceed	Parameter type: <Alarm::EthSfpTempExceed> (yes no) Possible values: - yes : ethernet sfp temperature exceed - no : ethernet sfp temperature normal	current status of ethernet sfp temperature <i>This element is only shown in detail mode.</i>
user-sfp-mismatch	Parameter type: <Alarm::EthSfpMismatch> (yes no) Possible values: - yes : ethernet sfp mismatch the configured type - no : ethernet sfp match the configured type	current status of ethernet sfp type <i>This element is only shown in detail mode.</i>

104.54 Alarm Current Ether-Sfp Status Command

Command Description

This command displays the Ether-Sfp related alarms.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

> show alarm current uplink-ether-sfp [(index)]

Command Parameters

Table 104.54-1 "Alarm Current Ether-Sfp Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm type

Command Output

Table 104.54-2 "Alarm Current Ether-Sfp Status Command" Display parameters

Specific Information		
name	Type	Description
port	Parameter type: <Itf::EthernetPortIndex> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number	identify where the alarm has occurred <i>This element is only shown in detail mode.</i>
uplink-sfp-los	Parameter type: <Alarm::EthSfpLos> (yes no) Possible values: - yes : ethernet sfp los error - no : ethernet sfp los normal	current status of uplink ethernet sfp los <i>This element is only shown in detail mode.</i>
uplink-sfp-tx-fail	Parameter type: <Alarm::EthSfpTxFail> (yes	current status of uplink ethernet sfp tx

name	Type	Description
	no) Possible values: - yes : ethernet sfp Tx Failure - no : ethernet sfp Tx normal	<i>This element is only shown in detail mode.</i>
uplink-sfp-not-prst	Parameter type: <Alarm::EthSfpNotPrst> (yes no) Possible values: - yes : ethernet sfp not detected - no : ethernet sfp detected	current status of uplink ethernet sfp presence <i>This element is only shown in detail mode.</i>
uplink-sfp-inv-id	Parameter type: <Alarm::EthSfpInvalid> (yes no) Possible values: - yes : ethernet sfp id invalid - no : ethernet sfp id normal	current status of uplink ethernet sfp id <i>This element is only shown in detail mode.</i>
uplink-sfp-t-exceed	Parameter type: <Alarm::EthSfpTempExceed> (yes no) Possible values: - yes : ethernet sfp temperature exceed - no : ethernet sfp temperature normal	current status of uplink ethernet sfp temperature <i>This element is only shown in detail mode.</i>
uplink-sfp-mismatch	Parameter type: <Alarm::EthSfpMismatch> (yes no) Possible values: - yes : ethernet sfp mismatch the configured type - no : ethernet sfp match the configured type	current status of uplink ethernet sfp type <i>This element is only shown in detail mode.</i>

104.55 Alarm Current Qos Slot Status Command

Command Description

This command displays the Qos Slot related alarms.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

> show alarm current qos-slot [(index)]

Command Parameters

Table 104.55-1 "Alarm Current Qos Slot Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm type

Command Output

Table 104.55-2 "Alarm Current Qos Slot Status Command" Display parameters

Specific Information		
name	Type	Description
board-position	Parameter type: <Equipm::SlotIndex> (lt : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> nt-a nt-b nt acu : <Eqpt::RackId> / <Eqpt::ShelfId> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::EqSlotId> ext-a : <Eqpt::RackId> / <Eqpt::ShelfId> ext-b : <Eqpt::RackId> / <Eqpt::ShelfId> ctrl : <Eqpt::RackId> / <Eqpt::ShelfId> vlt : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::VirtualSlotId>) Possible values: - lt : lt-slot - vlt : virtual LT slot (VVPS board can only be planned at NANT-E / FANT-F) - nt-a : nt-a slot - nt-b : nt-b slot - nt : nt slot - ext-a : nt-a slot in an extension shelf	identify where the alarm has occurred. <i>This element is only shown in detail mode.</i>

name	Type	Description
	- ext-b : nt-b slot in an extension shelf - acu : acu slot - ctrl : ctrl-slot Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::VirtualSlotId> - the virtual LT slot number Field type <Eqpt::EqSlotId> - the equipment slot number	
up-overflow	Parameter type: <Alarm::up-overflow> (yes no) Possible values: - yes : up overflow alarm - no : no up overflow alarm	check LT load in upstream. <i>This element is only shown in detail mode.</i>
dw-overflow	Parameter type: <Alarm::dw-overflow> (yes no) Possible values: - yes : down overflow alarm - no : no down overflow alarm	check LT load in downstream. <i>This element is only shown in detail mode.</i>
upobc-overflow	Parameter type: <Alarm::upobc-overflow> (yes no) Possible values: - yes : up to obc overflow alarm - no : no up to obc overflow alarm	check LT load to OBC in upstream. <i>This element is only shown in detail mode.</i>
dwobc-overflow	Parameter type: <Alarm::dwobc-overflow> (yes no) Possible values: - yes : down to obc overflow alarm - no : no down to obc overflow alarm	check LT load to OBC in downstream. <i>This element is only shown in detail mode.</i>
lwpriority-overflow	Parameter type: <Alarm::lwpriority-overflow> (yes no) Possible values: - yes : alarm - no : no dying gasp alarm	check Voice and Video load. <i>This element is only shown in detail mode.</i>
fanout	Parameter type: <Alarm::fanout> (yes no) Possible values: - yes : fan out alarm - no : no fan out alarm	check LT Load. <i>This element is only shown in detail mode.</i>

104.56 Alarm Current Qos Queue Status Command

Command Description

This command displays the Qos Queue related alarms.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

> show alarm current qos-queue [(index)]

Command Parameters

Table 104.56-1 "Alarm Current Qos Queue Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm type

Command Output

Table 104.56-2 "Alarm Current Qos Queue Status Command" Display parameters

Specific Information		
name	Type	Description
port	Parameter type: <Itf::PhyLine> (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> / <Eqpt::OntPortId> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / voip <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / vuni ont : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> ont.ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> uni.ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / <Eqpt::Ng2OntSlotId> / <Eqpt::Ng2OntPortId> uni.ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / vuni) Possible values:	identifies the physical position of the port <i>This element is only shown in detail mode.</i>

name	Type	Description
	- ont : ont - ont:ng2 : ngpon2 ONT style identification - uni:ng2 : ngpon2 UNI style identification - Field type <Eqpt::RackId> - the rack number - Field type <Eqpt::ShelfId> - the shelf number - Field type <Eqpt::SlotId> - the LT slot number - Field type <Eqpt::PortId> - the port number - Field type <Eqpt::PonId> - the PON identifier - Field type <Eqpt::OntId> - the ONT identifier - Field type <Eqpt::ChannelGroupId> - the channel group identifier - Field type <Eqpt::SubChannelGroupId> - the subchannel group identifier - Field type <Eqpt::Ng2OntId> - the NG2 ONT identifier - Possible values: - voip : virtual uni identifier - obsolete alternative replaced by vuni - vuni : virtual uni identifier - Possible values: - vuni : virtual NGPON2 uni identifier - Field type <Eqpt::OntSlotId> - the ONT SLOT identifier - Field type <Eqpt::OntPortId> - the ONT PORT identifier - Field type <Eqpt::Ng2OntSlotId> - the NGPON2 ONT SLOT identifier - Field type <Eqpt::Ng2OntPortId> - the NGPON2 ONT PORT identifier	
queue	Parameter type: <Qos::AlarmQueues> - identify where the alarm has occurred - range: [0...7]	identify where the alarm has occurred. <i>This element is only shown in detail mode.</i>
queue-discard-overflow	Parameter type: <Alarm::queue-discard-overflow> (yes no) Possible values: - yes : queue discard alarm - no : no queue discard alarm	check the corresponding queue discard overflow. <i>This element is only shown in detail mode.</i>
queue-load	Parameter type: <Alarm::queue-load> (yes no) Possible values: - yes : queue load alarm - no : no queue load alarm	check the corresponding queue Load. <i>This element is only shown in detail mode.</i>
queue-peak-usage	Parameter type: <Alarm::queue-peak-usage> (yes no) Possible values: - yes : queue peak usage alarm - no : no queue peak usage alarm	check the corresponding queue peak usage. <i>This element is only shown in detail mode.</i>

104.57 Alarm File Transfer Server Status Command

Command Description

This command displays the file transfer server related current alarms.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

> show alarm current filetransfer [(index)]

Command Parameters

Table 104.57-1 "Alarm File Transfer Server Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm type

Command Output

Table 104.57-2 "Alarm File Transfer Server Status Command" Display parameters

Specific Information		
name	Type	Description
server-id	Parameter type: <Alarm::FileTransfer> - next hop IP address	identify where the alarm has occurred. <i>This element is only shown in detail mode.</i>
fileserv-unavail	Parameter type: <Alarm::FileTransferUnavail> (unavailable available) Possible values: - unavailable : file transfer Server unavailable or file transfer failed - available : file transfer server available	current status specifying that whether file transfer server available <i>This element is only shown in detail mode.</i>

104.58 Alarm LSM Redundancy Status Command

Command Description

This command displays the LSM Redundancy related current alarms.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

> show alarm current lsmredundancy [(index)]

Command Parameters

Table 104.58-1 "Alarm LSM Redundancy Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm type

Command Output

Table 104.58-2 "Alarm LSM Redundancy Status Command" Display parameters

Specific Information		
name	Type	Description
board-station	Parameter type: <Equipm::LtSlotIndex> (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId>) Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number	physical number of the slot for lsm redundancy alarms <i>This element is only shown in detail mode.</i>
loss-lsmswp-cap	Parameter type: <Alarm::SwoCap> (loss not-loss) Possible values: - loss : system loss of the swichover capability - not-loss : system not loss of the swichover capability	current status specifying the swichover capability <i>This element is only shown in detail mode.</i>
data-xvps-diff	Parameter type: <Alarm::DataXvps> (invalid valid) Possible values:	log status of the data of xvps pair <i>This element is only shown in detail mode.</i>

name	Type	Description
	- invalid : data of xvps pair is not the same - valid : data of xvps pair is same	

104.59 Alarm L2 Forward Status Command

Command Description

This command displays the l2 forward related current alarms.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm current l2forward [ (index) ]
```

Command Parameters

Table 104.59-1 "Alarm L2 Forward Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm type

Command Output

Table 104.59-2 "Alarm L2 Forward Status Command" Display parameters

Specific Information		
name	Type	Description
bridgeport	Parameter type: <Vlan::BridgePort> (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::VpId> : <Eqpt::VcId> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> / <Eqpt::OntPortId> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / voip <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / vuni <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::LLId> ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Ng2::OntId> / <Eqpt::Ng2OntSlotId> / <Eqpt::Ng2OntPortId> ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Ng2::OntId> / vuni) Possible values:	identify the bridge port where the alarm has occurred. <i>This element is only shown in detail mode.</i>

name	Type	Description
	- ng2 : ngpon2 vlan bridge port - Field type <Eqpt::RackId> - the rack number - Field type <Eqpt::ShelfId> - the shelf number - Field type <Eqpt::SlotId> - the LT slot number - Field type <Eqpt::PortId> - the port number - Field type <Eqpt::VpiId> - atm VPI - Field type <Eqpt::VciId> - atm VCI - Field type <Eqpt::PonId> - the PON identifier - Field type <Eqpt::ChannelGroupId> - the channel group identifier - Field type <Eqpt::SubChannelGroupId> - the subchannel group identifier - Field type <Eqpt::OntId> - the ONT identifier - Field type <Ng2::OntId> - the ONT identifier - Possible values: - voip : virtual uni identifier - obsolete alternative replaced by vuni - vuni : virtual uni identifier - Possible values: - vuni : virtual NGPON2 uni identifier - Field type <Eqpt::OntSlotId> - the ONT SLOT identifier - Field type <Eqpt::OntPortId> - the ONT PORT identifier - Field type <Eqpt::Ng2OntSlotId> - the NGPON2 ONT SLOT identifier - Field type <Eqpt::Ng2OntPortId> - the NGPON2 ONT PORT identifier - Field type <Eqpt::LLId> - the LLID identifier,range 1 for EPON,range 1-8 for DPOE	
vlan-id	Parameter type: <Vlan::StackedVlanSigned> (<Vlan::UVlanIndex> stacked : <Vlan::SVlanIndex> : <Vlan::CVlanIndex>) Possible values: - stacked : stacked vlan identity - Field type <Vlan::UVlanIndex> - unstacked vlan identity - range: [1...4093,4096] - Field type <Vlan::SVlanIndex> - service vlan identity - range: [2...4093,4094] - Field type <Vlan::CVlanIndex> - customer vlan identity - range: [0...4093,4094,4095,4096]	identify the vlan id where the alarm has occurred. <i>This element is only shown in detail mode.</i>
mac-conflict	Parameter type: <Alarm::MACconflict> (yes no) Possible values:	specifies whether duplicate mac address from the bridge port. <i>This element is only shown in detail mode.</i>

104 Current Alarm Status Commands

name	Type	Description
	- yes : duplicate mac address from this bridge port - no : no duplicate mac address from this bridge port	
vmac-full	Parameter type: <Alarm::VMACFull> (yes no) Possible values: - yes : virtual mac entry full on this bridge port - no : no virtual mac entry full on this bridge port	specifies whether virtual mac is full on the bridge port. <i>This element is only shown in detail mode.</i>

104.60 Alarm Current External Device Status Command

Command Description

This command displays the external-device related alarms.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

> show alarm current external-device [(index)]

Command Parameters

Table 104.60-1 "Alarm Current External Device Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm type

Command Output

Table 104.60-2 "Alarm Current External Device Status Command" Display parameters

Specific Information		
name	Type	Description
loss-env-mon	Parameter type: <Alarm::LossEnvMon> (lost not-lost) Possible values: - lost : env-mon box lost or not alive - not-lost : env-mon box exists	current status of env-monitor box <i>This element is only shown in detail mode.</i>

104.61 Multicast Source Current Alarm Status Command

Command Description

This command displays the multicast source current alarm status.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm current mcsrc [ (index) ]
```

Command Parameters

Table 104.61-1 "Multicast Source Current Alarm Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm type

Command Output

Table 104.61-2 "Multicast Source Current Alarm Status Command" Display parameters

Specific Information		
name	Type	Description
grp-ip-addr	Parameter type: <Alarm::IpAddress> - IPv4-address	identify the mcast address where the alarm has occurred. <i>This element is only shown in detail mode.</i>
slot-id	Parameter type: <Equipm::FullLtSlotIndex> lt : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> Possible values: - lt : lt-slot Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number	identify where the alarm has occurred. <i>This element is only shown in detail mode.</i>
stream-lost	Parameter type: <Alarm::McastLoss> (yes	current status of the alarm specifying if the pon mcast video

name	Type	Description
	no) Possible values: - yes : pon mcast video stream lost - no : pon mcast video stream not lost	stream is lost or not <i>This element is only shown in detail mode.</i>

104.62 Vlanport Current Alarm Status Command

Command Description

This command displays the vlanport current alarm status.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

> show alarm current vlanport [(index)]

Command Parameters

Table 104.62-1 "Vlanport Current Alarm Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm type

Command Output

Table 104.62-2 "Vlanport Current Alarm Status Command" Display parameters

Specific Information		
name	Type	Description
vlanport	Parameter type: <Itf::VlanPortInterface> (vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::VpiId> : <Eqpt::VciId> : <Eqpt::UnstackedVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::UnstackedVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::VpiId> : <Eqpt::VciId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> / <Eqpt::OntPortId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> / <Eqpt::OntPortId> : <Eqpt::UnstackedVlan>	identify the vlan port where the alarm has occurred. <i>This element is only shown in detail mode.</i>

name	Type	Description
	<pre> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / voip : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / vuni : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / voip : <Eqpt::UnstackedVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / vuni : <Eqpt::UnstackedVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::LLId> : <Eqpt::UnstackedVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::LLId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan-port:ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Ng2::OntId> / <Eqpt::Ng2OntSlotId> / <Eqpt::Ng2OntPortId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan-port:ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Ng2::OntId> / <Eqpt::Ng2OntSlotId> / <Eqpt::Ng2OntPortId> : <Eqpt::UnstackedVlan> vlan-port:ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Ng2::OntId> / vuni : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan-port:ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Ng2::OntId> / vuni : <Eqpt::UnstackedVlan>) Possible values: - vlan-port : vlan port - vlan-port:ng2 : ngpon2 vlan port Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number Field type <Eqpt::VpiId> - atm VPI Field type <Eqpt::VciId> - atm VCI Field type <Eqpt::PonId> - the PON identifier Field type <Eqpt::OntId> - the ONT identifier Field type <Eqpt::ChannelGroupId> - the channel group identifier Field type <Eqpt::SubChannelGroupId> - the subchannel group identifier Field type <Ng2::OntId> - the ONT identifier </pre>	

104 Current Alarm Status Commands

name	Type	Description
	Possible values: - voip : virtual uni identifier obsolete alternative replaced by vuni - vuni : virtual uni identifier Possible values: - vuni : virtual NGPON2 uni identifier Field type <Eqpt::OntSlotId> - the ONT SLOT identifier Field type <Eqpt::OntPortId> - the ONT PORT identifier Field type <Eqpt::Ng2OntSlotId> - the NGPON2 ONT SLOT identifier Field type <Eqpt::Ng2OntPortId> - the NGPON2 ONT PORT identifier Field type <Eqpt::LLId> - the LLID identifier, range 1 for EPON, range 1-8 for DPOE Possible values: - stacked : stacked vlan identity Field type <Eqpt::UnstackedVlan> - unstacked vlan id Field type <Eqpt::SVlan> - service vlan id Field type <Eqpt::CVlan> - customer vlan id	
svc-mismatch	Parameter type: <Alarm::SVCMismatch> (yes no) Possible values: - yes : configuration request not accepted - no : configuration accepted	current status of the alarm specifying if the configuration for a provisioned vlanport is accepted or not. <i>This element is only shown in detail mode.</i>

104.63 BGP Current Alarm Status Command

Command Description

This command displays the bgp current alarm status.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

> show alarm current bgp [(index)]

Command Parameters

Table 104.63-1 "BGP Current Alarm Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm type

Command Output

Table 104.63-2 "BGP Current Alarm Status Command" Display parameters

Specific Information		
name	Type	Description
router-id	Parameter type: <Ihub::Router> (base <Ihub::Router>) Possible values: - base : base router Field type <Ihub::Router> - vprn service-id - range: [1...2147483647]	identifies the vprn service-id or the base router where the alarm has occurred <i>This element is only shown in detail mode.</i>
neighbor-idx	Parameter type: <Alarm::AlarmIdentifIdxOrZero> - an unsigned integer	unique reference for the neighbor where the alarm occurred or zero when not applicable, neighbor is further specified in additional-info <i>This element is only shown in detail mode.</i>
additional-info	Parameter type: <Alarm::AddInfoString> - additional alarm information	identifies the neighbor where the alarm occurred or empty string if not applicable. <i>This element is only shown in</i>

104 Current Alarm Status Commands

name	Type	Description
		<i>detail mode.</i>
Only Show Details: current alarm status		
name	Type	Description
peer-down	Parameter type: <Alarm::PeerDown> (yes no) Possible values: - yes : operational state down - no : operational state up	specifies whether the BGP peer operational state is up or down <i>This element is only shown in detail mode.</i>
routes-mid-limit	Parameter type: <Alarm::RoutesMidLimit> (reached not-reached) Possible values: - reached : reached: 90% of max allowed routes learned - not-reached : less than 90% of max allowed routes learned	specifies whether 90% of the max nbr of routes BGP can learn from a peer is reached or not <i>This element is only shown in detail mode.</i>

104.64 RIP Current Alarm Status Command

Command Description

This command displays the rip current alarm status.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

> show alarm current rip [(index)]

Command Parameters

Table 104.64-1 "RIP Current Alarm Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm type

Command Output

Table 104.64-2 "RIP Current Alarm Status Command" Display parameters

Specific Information		
name	Type	Description
router-id	Parameter type: <Ihub::Router> (base <Ihub::Router>) Possible values: - base : base router Field type <Ihub::Router> - vprn service-id - range: [1...2147483647]	identifies the vprn service-id or the base router where the alarm has occurred <i>This element is only shown in detail mode.</i>

Only Show Details: current alarm status		
name	Type	Description
instance-down	Parameter type: <Alarm::InstanceDown> (yes no) Possible values: - yes : RIP instance down - no : RIP instance up	specifies whether RIP instance is down or not <i>This element is only shown in detail mode.</i>

104.65 LAG Current Alarm Status Command

Command Description

This command displays the lag current alarm status.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm current lag [ (index) ]
```

Command Parameters

Table 104.65-1 "LAG Current Alarm Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm type

Command Output

Table 104.65-2 "LAG Current Alarm Status Command" Display parameters

Specific Information		
name	Type	Description
lag-id	Parameter type: <Alarm::LagId> - link aggregation group id - range: [1...64]	Identifies the lag where the alarm has occurred <i>This element is only shown in detail mode.</i>
sub-group	Parameter type: <Alarm::AlarmIdentifIdxOrZero> - an unsigned integer	Identifies the lag subgroup for which the alarm has occurred or zero when not applicable <i>This element is only shown in detail mode.</i>

Only Show Details: current alarm status		
name	Type	Description
lag-down	Parameter type: <Alarm::EthLagDown> (yes no) Possible values: - yes : lag down - no : lag not down	specifies whether the link aggregation group is down or not <i>This element is only shown in detail mode.</i>
subgrp-thres-reach	Parameter type: <Alarm::LagSubgrpThresReach> (reached	specifies whether the lag sub-group threshold is reached or

name	Type	Description
	not-reached) Possible values: - reached : sub-group threshold reached - not-reached : sub-group threshold not reached	not <i>This element is only shown in detail mode.</i>
subgrp-switch-fail	Parameter type: <Alarm::LagSubgrpSwitchFail> (yes no) Possible values: - yes : lag subgroup switchover failed - no : lag subgroup switchover did not fail	specifies whether the lag sub-group switchover failed or not <i>This element is only shown in detail mode.</i>
no-free-port-inbase	Parameter type: <Alarm::LagNoUnpinFreePorts> (yes no) Possible values: - yes : No free ports available for un pinned traffic - no : free ports available for un pinned traffic	specifies whether the free ports available for unpinned traffic or not <i>This element is only shown in detail mode.</i>

104.66 ihub-general Current Alarm Status Command

Command Description

This command displays the ihub-general current alarm status.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

> show alarm current ihub-general [(index)]

Command Parameters

Table 104.66-1 "ihub-general Current Alarm Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm type

Command Output

Table 104.66-2 "ihub-general Current Alarm Status Command" Display parameters

Only Show Details: current alarm status		
name	Type	Description
arp-limit	Parameter type: <Alarm::ArpLimit> (reached not-reached) Possible values: - reached : ARP tbl threshold reached or exceeded - not-reached : ARP tbl entries below threshold	specifies whether the nbr of ARP entries has reached the max threshold or not <i>This element is only shown in detail mode.</i>
switch-out-of-res	Parameter type: <Alarm::IhubSwitchOutOfResource> (yes no) Possible values: - yes : lack of resources in switch - no : no resource issues detected	specifies whether e.g. storing a configuration in the hardware has failed or not, due to a lack of resources in the switch. <i>This element is only shown in detail mode.</i>
ipv6-nc-limit	Parameter type: <Alarm::IPv6NeighborCacheLimit> (reached not-reached) Possible values:	specifies whether the number of ipv6 neighbor cache entries reached maximum threshold or not.

name	Type	Description
	- reached : neighbor cache up threshold reached - not-reached : neighbor cache entries within limit	<i>This element is only shown in detail mode.</i>
dhcp-session-oor	Parameter type: <Alarm::DhcpSessionOutOfResource> (yes no) Possible values: - yes : lack of resources for dhcp - no : no resource issues detected for dhcp	specifies whether dhcp session is out of resources or not. <i>This element is only shown in detail mode.</i>
fdb-limit	Parameter type: <Alarm::IhubL2FdbFull> (reached not-reached) Possible values: - reached : layer 2 fdb table entries reached upper threshold for the node - not-reached : layer 2 fdb table entries within limit for the node	specifies whether the number of layer 2 fdb table entries reached maximum threshold or not. <i>This element is only shown in detail mode.</i>
mac-limit	Parameter type: <Alarm::IhubL2MacFull> (reached not-reached) Possible values: - reached : Internal Mac entries reached upper - not-reached : Internal Mac entries within limit	specifies whether the number of internal Mac entries reached maximum threshold or not. <i>This element is only shown in detail mode.</i>

104.67 VPRN Current Alarm Status Command

Command Description

This command displays the vprn current alarm status.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm current vprn [ (index) ]
```

Command Parameters

Table 104.67-1 "VPRN Current Alarm Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm type

Command Output

Table 104.67-2 "VPRN Current Alarm Status Command" Display parameters

Specific Information		
name	Type	Description
router-id	Parameter type: <Ihub::Router> (base <Ihub::Router>) Possible values: - base : base router Field type <Ihub::Router> - vprn service-id - range: [1...2147483647]	identifies the vprn service-id or the base router where the alarm has occurred. <i>This element is only shown in detail mode.</i>
if-index	Parameter type: <Alarm::IdentificationIdxOrZero> - a signed integer	unique reference for the interface for which the alarm occurred or zero when not applicable. <i>This element is only shown in detail mode.</i>
interface	Parameter type: <Alarm::AddInfoString> - additional alarm information	identifies the interface for which the alarm occurred or empty string if not applicable. <i>This element is only shown in detail mode.</i>

Only Show Details: current alarm status

name	Type	Description
routes-limit	Parameter type: <Alarm::RoutesLimit> (reached not-reached) Possible values: - reached : ip routes limit reached or exceeded - not-reached : ip routes within limit	specifies whether the limit of dynamic routes is reached/exceeded or not <i>This element is only shown in detail mode.</i>
ipv6-routes-limit	Parameter type: <Alarm::IPv6RoutesLimit> (reached not-reached) Possible values: - reached : ipv6 routes limit reached or exceeded - not-reached : ipv6 routes within limit	specifies whether the number of dynamic ipv6 routes is approaching or has reached its limit <i>This element is only shown in detail mode.</i>
dhcpv6-lease-limit	Parameter type: <Alarm::DHCPV6LeaseLimit> (reached not-reached) Possible values: - reached : dhcpv6 relay leases limit reached or exceeded - not-reached : dhcpv6 relay leases within limit	specifies whether the limit of dhcpv6 relay leases is reached or not <i>This element is only shown in detail mode.</i>
dhcpv4-lease-limit	Parameter type: <Alarm::DHCPV4LeaseLimit> (reached not-reached) Possible values: - reached : dhcpv4 relay leases limit reached or exceeded - not-reached : dhcpv4 relay leases within limit	specifies whether the limit of dhcpv4 relay leases is reached or not <i>This element is only shown in detail mode.</i>

104.68 ISIS Current Alarm Status Command

Command Description

This command displays the isis current alarm status.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

> show alarm current isis [(index)]

Command Parameters

Table 104.68-1 "ISIS Current Alarm Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm type

Command Output

Table 104.68-2 "ISIS Current Alarm Status Command" Display parameters

Specific Information		
name	Type	Description
router-id	Parameter type: <Ihub::Router> (base <Ihub::Router>) Possible values: - base : base router Field type <Ihub::Router> - vprn service-id - range: [1...2147483647]	identifies the vprn service-id or the base router where the alarm has occurred <i>This element is only shown in detail mode.</i>
adjacency-index	Parameter type: <Alarm::IdentificationIdxOrZero> - a signed integer	unique reference for the adjacency where the alarm occurred or zero when not applicable, adjacency is further specified in additional-info <i>This element is only shown in detail mode.</i>
additional-info	Parameter type: <Alarm::AddInfoString> - additional alarm information	identifies the adjacency:instance/interface where the alarm occurred or empty string if not applicable.

name	Type	Description
		<i>This element is only shown in detail mode.</i>

Only Show Details: current alarm status		
name	Type	Description
adjacency-down	Parameter type: <Alarm::AdjacencyDown> (yes no) Possible values: - yes : interface down - no : interface up	specifies whether isis adjacency is down or not <i>This element is only shown in detail mode.</i>
adjacency-reject	Parameter type: <Alarm::AdjacencyReject> (yes no) Possible values: - yes : interface mismatch - no : no interface mismatch	specifies whether isis adjacency is rejected or not <i>This element is only shown in detail mode.</i>
instance-down	Parameter type: <Alarm::IsisDown> (yes no) Possible values: - yes : ISIS instance down - no : ISIS instance up	specifies whether ISIS instance is down or not <i>This element is only shown in detail mode.</i>

104.69 Ospf Current Alarm Status Command

Command Description

This command displays the ospf current alarm status.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

> show alarm current ospf [(index)]

Command Parameters

Table 104.69-1 "Ospf Current Alarm Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm type

Command Output

Table 104.69-2 "Ospf Current Alarm Status Command" Display parameters

Specific Information		
name	Type	Description
router-id	Parameter type: <Ihub::Router> (base <Ihub::Router>) Possible values: - base : base router Field type <Ihub::Router> - vprn service-id - range: [1...2147483647]	identifies the vprn service-id or the base router where the alarm has occurred <i>This element is only shown in detail mode.</i>
neighbor-idx	Parameter type: <Alarm::IdentificationIdxOrZero> - a signed integer	unique reference for the neighbor where the alarm occurred or zero when not applicable, neighbor is further specified in additional-info <i>This element is only shown in detail mode.</i>
additional-info	Parameter type: <Alarm::AddInfoString> - additional alarm information	identifies the neighbor/instance where the alarm occurred or empty string if not applicable <i>This element is only shown in</i>

name	Type	Description
		<i>detail mode.</i>

Only Show Details: current alarm status

name	Type	Description
lsa-limit	Parameter type: <Alarm::LsaLimit> (reached not-reached) Possible values: - reached : external LSA limit reached - not-reached : external LSAs within limitation	specifies whether the limit of received external LSAs is reached or not <i>This element is only shown in detail mode.</i>
lsa-mid-limit	Parameter type: <Alarm::LsaMidLimit> (reached not-reached) Possible values: - reached : 90% of LSA limit reached - not-reached : less than 90% of LSA limit	specifies whether 90% of the limit of received external LSAs is reached or not <i>This element is only shown in detail mode.</i>
neighbor-down	Parameter type: <Alarm::NeighborDown> (yes no) Possible values: - yes : OSPF neighbor down - no : OSPF neighbor up	specifies whether ospf neighbour is down or not <i>This element is only shown in detail mode.</i>
instance-down	Parameter type: <Alarm::OspfDown> (yes no) Possible values: - yes : OSPF instance down - no : OSPF instance up	specifies whether OSPF instance is down or not <i>This element is only shown in detail mode.</i>
v3-lsa-limit	Parameter type: <Alarm::V3LsaLimit> (reached not-reached) Possible values: - reached : external OSPFv3 LSA limit reached - not-reached : external OSPFv3 LSAs within limitation	specifies whether the limit of received external OSPFv3 LSAs is reached or not <i>This element is only shown in detail mode.</i>
v3-lsa-mid-limit	Parameter type: <Alarm::V3LsaMidLimit> (reached not-reached) Possible values: - reached : 90% of OSPFv3 LSA limit reached - not-reached : less than 90% of OSPFv3 LSA limit	specifies whether 90% of the limit of received external OSPFv3 LSAs is reached or not <i>This element is only shown in detail mode.</i>
v3-neighbor-down	Parameter type: <Alarm::V3NeighborDown> (yes no) Possible values: - yes : OSPFv3 neighbor down - no : OSPFv3 neighbor up	specifies whether OSPFv3 neighbour is down or not <i>This element is only shown in detail mode.</i>
v3-instance-down	Parameter type: <Alarm::V3OspfDown> (yes no) Possible values: - yes : OSPFv3 instance down - no : OSPFv3 instance up	specifies whether OSPFv3 instance is down or not <i>This element is only shown in detail mode.</i>

104.70 ihub-l2forward Current Alarm Status Command

Command Description

This command displays the ihub-l2forward current alarm status.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm current ihub-l2forward [ (index) ]
```

Command Parameters

Table 104.70-1 "ihub-l2forward Current Alarm Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm type

Command Output

Table 104.70-2 "ihub-l2forward Current Alarm Status Command" Display parameters

Specific Information		
name	Type	Description
port	Parameter type: <Ihub::EtherPortAndLag> (nt-a : sfp : <Alarm::FacePlatePortIndex> nt-a : xfp : <Alarm::FacePlatePortIndex> nt-a : qsfp : <Alarm::FacePlatePortIndex> nt-a : eth : <Alarm::FacePlatePortIndex> nt-b : sfp : <Alarm::FacePlatePortIndex> nt-b : xfp : <Alarm::FacePlatePortIndex> nt-b : qsfp : <Alarm::FacePlatePortIndex> nt-b : eth : <Alarm::FacePlatePortIndex> ntio-1 : sfp : <Alarm::FacePlatePortIndex> ntio-1 : xfp : <Alarm::FacePlatePortIndex> ntio-1 : qsfp : <Alarm::FacePlatePortIndex> ntio-2 : sfp : <Alarm::FacePlatePortIndex> ntio-2 : xfp : <Alarm::FacePlatePortIndex> ntio-2 : qsfp : <Alarm::FacePlatePortIndex> lt : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId>	identifies the physical position of the port <i>This element is only shown in detail mode.</i>

name	Type	Description
	<pre>lag : <Alarm::IhubLagId> nt-a : qsfp : <Alarm::QsfpPortIndex> - <Alarm::LaneIndex> nt-b : qsfp : <Alarm::QsfpPortIndex> - <Alarm::LaneIndex>)</pre> Possible values: - nt-a : the nt-a slot - nt-b : the nt-b slot - ntio-1 : an nt applique slot in a single or multiple-ntio-shelf - ntio-2 : an nt applique slot in a multiple-ntio-shelf - lt : the lt slot - lag : key word to specify link aggregation group - nt-a : the nt-a slot - nt-b : the nt-b slot Possible values: - sfp : SFP port - xfp : XFP port - qsfp : QSFP port - eth : RJ45 or lemi port Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Alarm::IhubLagId> - link aggregation group id Field type <Alarm::FacePlatePortIndex> - the faceplate port number Field type <Alarm::QsfpPortIndex> - the qsfp port number Field type <Alarm::LaneIndex> - the lane number of qsfp port	
service-id	Parameter type: <Alarm::ServiceId> - a profile index value - range: [1...2147483647]	identifies the vpls service-id where the alarm has occurred. <i>This element is only shown in detail mode.</i>

Only Show Details: current alarm status

name	Type	Description
stp-exception	Parameter type: <Alarm::StpException> (yes no) Possible values: - yes : stp exception condition detected on the port - no : no stp exception condition detected	specifies whether an STP exception condition is present on the port or not <i>This element is only shown in detail mode.</i>
stp-root-guard	Parameter type: <Alarm::StpRootGuard> (violation no violation) Possible values: - violation : stp root guard violation detected on the port - no violation : no stp root guard violation detected	specifies whether an STP root-guard violation present or not <i>This element is only shown in detail mode.</i>

104.71 VPLS Current Alarm Status Command

Command Description

This command displays the vpls current alarm status.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm current vpls [ (index) ]
```

Command Parameters

Table 104.71-1 "VPLS Current Alarm Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm type

Command Output

Table 104.71-2 "VPLS Current Alarm Status Command" Display parameters

Specific Information		
name	Type	Description
service-id	Parameter type: <Alarm::ServiceId> - a profile index value - range: [1...2147483647]	identifies the vpls service-id where the alarm has occurred. <i>This element is only shown in detail mode.</i>
mac-idx	Parameter type: <Alarm::IdentificationIdxOrZero> - a signed integer	unique reference for the duplicate mac alarm and zero for all other alarms; duplicate mac is further specified in additional-info <i>This element is only shown in detail mode.</i>
additional-info	Parameter type: <Alarm::AddInfoStringVpls> - additional alarm information	Additional information regarding duplicate MAC alarm <i>This element is only shown in detail mode.</i>

Only Show Details: current alarm status		
name	Type	Description
mfib-limit	Parameter type: <Alarm::MfibLimit> (reached not-reached)	specifies whether the number of entries in the multicast FIB table reached its limit or not

name	Type	Description
	Possible values: - reached : mfib table size limit reached - not-reached : mfib table size below limit.	<i>This element is only shown in detail mode.</i>
duplicate-mac	Parameter type: <Alarm::DuplicateMac> (yes no) Possible values: - yes : duplicate mac detected on vpls - no : no duplicate mac on the vpls	specifies whether a duplicate MAC address is detected or not <i>This element is only shown in detail mode.</i>
fdb-limit	Parameter type: <Alarm::FdbLimit> (reached not-reached) Possible values: - reached : fdb table size limit reached - not-reached : fdb table size below low limit	specifies whether the number of entries in the fdb table reached the upper limit or dropped below the lower limit. <i>This element is only shown in detail mode.</i>
self-duplic-mac	Parameter type: <Alarm::Selfduplic> (yes no) Possible values: - yes : self duplicate mac detected on a sap of the vpls - no : no self duplicate mac on a sap of the vpls	specifies whether a duplicate of a system owned mac address is detected on a sap of the vpls service or not <i>This element is only shown in detail mode.</i>
sdp-self-dup-mac	Parameter type: <Alarm::SdpSelfdupMac> (yes no) Possible values: - yes : self duplicate mac detected on sdp binding of the vpls - no : no self duplicate mac on a sdp binding of the vpls	specifies whether a duplicate of a system owned mac address is detected on a sdp binding of the vpls service or not <i>This element is only shown in detail mode.</i>

104.72 IHUB-Equip Current Alarm Status Command

Command Description

This command displays the ihub-equip current alarm status.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm current ihub-equip [ (index) ]
```

Command Parameters

Table 104.72-1 "IHUB-Equip Current Alarm Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm type

Command Output

Table 104.72-2 "IHUB-Equip Current Alarm Status Command" Display parameters

Specific Information		
name	Type	Description
slot	Parameter type: <Alarm::NtSlotId> (nt-a nt-b) Possible values: - nt-a : nt-a slot - nt-b : nt-b slot	identifies the slot where the alarm has been detected. <i>This element is only shown in detail mode.</i>
additional-info	Parameter type: <Alarm::AddInfoString> - additional alarm information	additional information regarding the out-of-mem alarm, containing the name of the Software Module triggering this alarm <i>This element is only shown in detail mode.</i>

Only Show Details: current alarm status		
name	Type	Description
peer-comm	Parameter type: <Alarm::PeerComm> (fail no fail) Possible values: - fail : peer-to-peer communication failure	specifies whether peer-to-peer communication has failed or not <i>This element is only shown in detail mode.</i>

name	Type	Description
	- no fail : no peer-to-peer communication failure	
sw-fail	Parameter type: <Alarm::SwFail> (yes no) Possible values: - yes : software failure detected - no : no software failure	specifies whether a software failure has occurred or not <i>This element is only shown in detail mode.</i>
hw-fail	Parameter type: <Alarm::HwFail> (yes no) Possible values: - yes : hardware failure detected - no : no hardware failure	specifies whether a hardware failure has occurred or not <i>This element is only shown in detail mode.</i>
link-fail	Parameter type: <Alarm::LinkFail> (yes no) Possible values: - yes : link failure detected - no : no link failure	specifies whether a link failure has occurred or not <i>This element is only shown in detail mode.</i>
proc-overload	Parameter type: <Alarm::ProcOverload> (yes no) Possible values: - yes : processor overload detected - no : no processor overload	specifies whether an overload condition exists for the processor at ihub side <i>This element is only shown in detail mode.</i>
out-of-mem	Parameter type: <Alarm::OutOfMem> (yes no) Possible values: - yes : memory allocation failure - no : memory allocation successful	specifies whether memory allocation in ihub failed or not <i>This element is only shown in detail mode.</i>
ntp-comm	Parameter type: <Alarm::ntpCommLoss> (lost not-lost) Possible values: - lost : NTP communication lost - not-lost : NTP communication is not lost	specifies whether ntp communication is lost or not <i>This element is only shown in detail mode.</i>

104.73 ihub-link Current Alarm Status Command

Command Description

This command displays the ihub-link current alarm status.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm current ihub-link [ (index) ]
```

Command Parameters

Table 104.73-1 "ihub-link Current Alarm Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm type

Command Output

Table 104.73-2 "ihub-link Current Alarm Status Command" Display parameters

Specific Information		
name	Type	Description
port	Parameter type: <Ihub::EtherPort> (nt-a : sfp : <Alarm::FacePlatePortIndex> nt-a : xfp : <Alarm::FacePlatePortIndex> nt-a : qsfp : <Alarm::FacePlatePortIndex> nt-a : cfp : <Alarm::FacePlatePortIndex> nt-a : eth : <Alarm::FacePlatePortIndex> nt-a : ieee1588 : <Alarm::FacePlatePortIndex> nt-a : ai : <Alarm::FacePlatePortIndex> nt-b : sfp : <Alarm::FacePlatePortIndex> nt-b : xfp : <Alarm::FacePlatePortIndex> nt-b : qsfp : <Alarm::FacePlatePortIndex> nt-b : cfp : <Alarm::FacePlatePortIndex> nt-b : eth : <Alarm::FacePlatePortIndex> nt-b : ieee1588 : <Alarm::FacePlatePortIndex> nt-b : ai : <Alarm::FacePlatePortIndex> ntio-1 : sfp : <Alarm::FacePlatePortIndex> ntio-1 : xfp : <Alarm::FacePlatePortIndex> ntio-1 : qsfp : <Alarm::FacePlatePortIndex> ntio-1 : cfp : <Alarm::FacePlatePortIndex> ntio-2 : sfp : <Alarm::FacePlatePortIndex>	identifies the ihub port where the alarm has occurred. <i>This element is only shown in detail mode.</i>

name	Type	Description
	ntio-2 : xfp : <Alarm::FacePlatePortIndex> ntio-2 : qsfp : <Alarm::FacePlatePortIndex> ntio-2 : cfp : <Alarm::FacePlatePortIndex> lt : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> nt-a : qsfp : <Alarm::QsfpPortIndex> - <Alarm::LaneIndex> nt-b : qsfp : <Alarm::QsfpPortIndex> - <Alarm::LaneIndex> ntio-1 : qsfp : <Alarm::QsfpPortIndex> - <Alarm::LaneIndex>) Possible values: - nt-a : the nt-a slot - nt-b : the nt-b slot - ntio-1 : an nt applique slot in a single or multiple-ntio-shelf - ntio-2 : an nt applique slot in a multiple-ntio-shelf - lt : the lt slot - nt-a : the nt-a slot - nt-b : the nt-b slot - ntio-1 : the nt-b slot Possible values: - sfp : SFP port - xfp : XFP port - qsfp : QSFP port - cfp : CFP port - eth : RJ45 or lemi port - ieee1588 : IEEE1588 port - ai : AI port Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Alarm::FacePlatePortIndex> - the faceplate port number Field type <Alarm::QsfpPortIndex> - the qsfp port number Field type <Alarm::LaneIndex> - the lane number of qsfp port	
additional-info	Parameter type: <Alarm::AddInfoString> - additional alarm information	additional information regarding the lagport-add-fail alarm, containing the failure reason: Either of these will apply: - unknown - adminkey-mismatch - - sysid-mismatch - - lacp-passive-both-ends - - link-down <i>This element is only shown in detail mode.</i>

Only Show Details: current and previous alarm log status

name	Type	Description
link-down	Parameter type: <Alarm::IhubLink> (yes no) Possible values: - yes : link down - no : link up	specifies whether the link is down or not <i>This element is only shown in detail mode.</i>

104 Current Alarm Status Commands

name	Type	Description
lagport-add-fail	Parameter type: <Alarm::LagportAddFail> (yes no) Possible values: - yes : lag-port not added - no : lag-port successfully added	specifies whether a port was successfully added to a link aggregation group or not <i>This element is only shown in detail mode.</i>
conf-mismatch	Parameter type: <Alarm::SpeedMismatch> (yes no) Possible values: - yes : port configuration mismatch - no : no port configuration mismatch	specifies whether the inserted SFP or SFP+ type matches the planned speed and/or auto-negotiation for the port or not <i>This element is only shown in detail mode.</i>

104.74 ihub-tca Current Alarm Status Command

Command Description

This command displays the ihub-tca current alarm status.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

> show alarm current ihub-tca [(index)]

Command Parameters

Table 104.74-1 "ihub-tca Current Alarm Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm type

Command Output

Table 104.74-2 "ihub-tca Current Alarm Status Command" Display parameters

Specific Information		
name	Type	Description
port	Parameter type: <Ihub::EtherPort> (nt-a : sfp : <Alarm::FacePlatePortIndex> nt-a : xfp : <Alarm::FacePlatePortIndex> nt-a : qsfp : <Alarm::FacePlatePortIndex> nt-a : cfp : <Alarm::FacePlatePortIndex> nt-a : eth : <Alarm::FacePlatePortIndex> nt-a : ieee1588 : <Alarm::FacePlatePortIndex> nt-a : ai : <Alarm::FacePlatePortIndex> nt-b : sfp : <Alarm::FacePlatePortIndex> nt-b : xfp : <Alarm::FacePlatePortIndex> nt-b : qsfp : <Alarm::FacePlatePortIndex> nt-b : cfp : <Alarm::FacePlatePortIndex> nt-b : eth : <Alarm::FacePlatePortIndex> nt-b : ieee1588 : <Alarm::FacePlatePortIndex> nt-b : ai : <Alarm::FacePlatePortIndex> ntio-1 : sfp : <Alarm::FacePlatePortIndex> ntio-1 : xfp : <Alarm::FacePlatePortIndex> ntio-1 : qsfp : <Alarm::FacePlatePortIndex> ntio-1 : cfp : <Alarm::FacePlatePortIndex> ntio-2 : sfp : <Alarm::FacePlatePortIndex>	identifies the ihub port where the alarm has occurred. <i>This element is only shown in detail mode.</i>

104 Current Alarm Status Commands

name	Type	Description
	ntio-2 : xfp : <Alarm::FacePlatePortIndex> ntio-2 : qsfp : <Alarm::FacePlatePortIndex> ntio-2 : cfp : <Alarm::FacePlatePortIndex> lt : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> nt-a : qsfp : <Alarm::QsfpPortIndex> - <Alarm::LaneIndex> nt-b : qsfp : <Alarm::QsfpPortIndex> - <Alarm::LaneIndex> ntio-1 : qsfp : <Alarm::QsfpPortIndex> - <Alarm::LaneIndex>) Possible values: - nt-a : the nt-a slot - nt-b : the nt-b slot - ntio-1 : an nt applique slot in a single or multiple-ntio-shelf - ntio-2 : an nt applique slot in a multiple-ntio-shelf - lt : the lt slot - nt-a : the nt-a slot - nt-b : the nt-b slot - ntio-1 : the nt-b slot Possible values: - sfp : SFP port - xfp : XFP port - qsfp : QSFP port - cfp : CFP port - eth : RJ45 or lemi port - ieee1588 : IEEE1588 port - ai : AI port Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Alarm::FacePlatePortIndex> - the faceplate port number Field type <Alarm::QsfpPortIndex> - the qsfp port number Field type <Alarm::LaneIndex> - the lane number of qsfp port	

Only Show Details: current and previous alarm log status		
name	Type	Description
tca-outputbw	Parameter type: <Alarm::TcaOutputBw> (yes no) Possible values: - yes : tca output bandwidth crossed threshold - no : tca output bandwidth did not crossed threshold	specifies whether the tca output bw has crossed threshold or not <i>This element is only shown in detail mode.</i>
tca-inputbw	Parameter type: <Alarm::TcaInputBw> (yes no) Possible values: - yes : tca input bandwidth crossed threshold - no : tca input bandwidth did not crossed threshold	specifies whether the tca input bw has crossed threshold or not <i>This element is only shown in detail mode.</i>
tca-rxcrcalign	Parameter type: <Alarm::TcaRxCrcAlign> (yes no) Possible values:	specifies whether the tca rxrcr align errors has crossed threshold or not <i>This element is only shown in</i>

name	Type	Description
	- yes : tca rxcrc align errors crossed threshold - no : tca rxcrc align errors did not crossed threshold	<i>detail mode.</i>
tca-txcrcalign	Parameter type: <Alarm::TcaTxCrcAlign> (yes no) Possible values: - yes : tca txcrc align errors crossed threshold - no : tca txcrc align errors did not crossed threshold	specifies whether the tca txcrc align errors has crossed threshold or not <i>This element is only shown in detail mode.</i>
tca-txcollisions	Parameter type: <Alarm::TcaTxCollisions> (yes no) Possible values: - yes : tca txcollisions errors crossed threshold - no : tca txcollisions errors did not crossed threshold	specifies whether the tca tx collisions errors has crossed threshold or not <i>This element is only shown in detail mode.</i>
tca-outputhighbw	Parameter type: <Alarm::TcaOutputHighBw> (yes no) Possible values: - yes : tca output high bandwidth crossed threshold - no : tca output high bandwidth did not crossed threshold	specifies whether the continous output high bw has crossed threshold or not <i>This element is only shown in detail mode.</i>
tca-outputmedbw	Parameter type: <Alarm::TcaOutputMediumBw> (yes no) Possible values: - yes : tca output medium bandwidth crossed threshold - no : tca output medium bandwidth did not crossed threshold	specifies whether the continous output medium bw has crossed threshold or not <i>This element is only shown in detail mode.</i>
tca-outputlowbw	Parameter type: <Alarm::TcaOutputLowBw> (yes no) Possible values: - yes : tca output low bandwidth crossed threshold - no : tca output low bandwidth did not crossed threshold	specifies whether the continous output low bw has crossed threshold or not <i>This element is only shown in detail mode.</i>
tca-inputhighbw	Parameter type: <Alarm::TcaInputHighBw> (yes no) Possible values: - yes : tca input high bandwidth crossed threshold - no : tca input high bandwidth did not crossed threshold	specifies whether the continous input high bw has crossed threshold or not <i>This element is only shown in detail mode.</i>
tca-inputmediumbw	Parameter type: <Alarm::TcaInputMediumBw> (yes no) Possible values: - yes : tca input medium bandwidth crossed threshold - no : tca input medium bandwidth did not crossed threshold	specifies whether the continous input medium bw has crossed threshold or not <i>This element is only shown in detail mode.</i>
tca-inputlowbw	Parameter type: <Alarm::TcaInputLowBw> (yes no) Possible values: - yes : tca input low bandwidth crossed threshold - no : tca input low bandwidth did not crossed threshold	specifies whether the continous input low bw has crossed threshold or not <i>This element is only shown in detail mode.</i>

104.75 LDP Current Alarm Status Command

Command Description

This command displays the current Label Distribution Protocol alarm status.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm current ldp [ (index) ]
```

Command Parameters

Table 104.75-1 "LDP Current Alarm Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm type

Command Output

Table 104.75-2 "LDP Current Alarm Status Command" Display parameters

Specific Information		
name	Type	Description
router-id	Parameter type: <Ihub::baseRouter> base Possible values: - base : base router	identifies the base router <i>This element is only shown in detail mode.</i>
ip-address	Parameter type: <Alarm::IPAddressOrZero> (not-applicable <IPv4::address>) Possible values: - not-applicable : not applicable Field type <IPv4::address> - IPv4-address	identifies the ip-address of the LDP targeted Peer <i>This element is only shown in detail mode.</i>

Only Show Details: current alarm status		
name	Type	Description
instance-down	Parameter type: <Alarm::LdpInstanceDown> (yes no) Possible values: - yes : ldp is down - no : ldp is up or not configured	specifies whether the LDP instance is down or not <i>This element is only shown in detail mode.</i>

name	Type	Description
session-down	Parameter type: <Alarm::SessionDown> (yes no) Possible values: - yes : TCP session down - no : Connection re-established or ldp not configured or explicit configured peer is removed	specifies whether the LDP session is down or not <i>This element is only shown in detail mode.</i>

104.76 MPLS Current Alarm Status Command

Command Description

This command displays the current MPLS alarm status.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm current mpls [ (index) ]
```

Command Parameters

Table 104.76-1 "MPLS Current Alarm Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm type

Command Output

Table 104.76-2 "MPLS Current Alarm Status Command" Display parameters

Specific Information		
name	Type	Description
router-id	Parameter type: <Ihub::baseRouter> base Possible values: - base : base router	identifies the base router <i>This element is only shown in detail mode.</i>
lsp-id-or-lsp-path-idx	Parameter type: <Alarm::LspIdOrLspPathIndexOrZero> - a signed integer	Lsp id or Lsp path index (unique identifier) where the alarm occurred or zero when not applicable, alarm entry is further specified in additional-info <i>This element is only shown in detail mode.</i>
additional-info	Parameter type: <Alarm::AddInfoString> - additional alarm information	identifies the alarm additional info specific to an mpls alarm. Empty string if not applicable. <i>This element is only shown in detail mode.</i>

Only Show Details: current alarm status		
name	Type	Description
instance-down	Parameter type: <Alarm::MplsInstanceDown>	specifies whether the MPLS

name	Type	Description
	(yes no) Possible values: - yes : mpls is down - no : mpls is up or not configured	instance is down or not <i>This element is only shown in detail mode.</i>
lsp-down	Parameter type: <Alarm::LspDown> (yes no) Possible values: - yes : lsp is down - no : lsp is up or shutdown, or mpls instance is stopped or not configured	specifies whether the LSP is down or not <i>This element is only shown in detail mode.</i>
lsp-path-down	Parameter type: <Alarm::LspPathDown> (yes no) Possible values: - yes : lsp path is down - no : lsp path is up or shutdown, or lsp is shutdown, or mpls instance is stopped or not configured	specifies whether the Lsp Path is down or not <i>This element is only shown in detail mode.</i>

104.77 SDP Current Alarm Status Command

Command Description

This command displays the current Service Delivery Point alarm status

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

> show alarm current sdp [(index)]

Command Parameters

Table 104.77-1 "SDP Current Alarm Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm type

Command Output

Table 104.77-2 "SDP Current Alarm Status Command" Display parameters

Specific Information		
name	Type	Description
sdp-id	Parameter type: <Alarm::SdpId> - sdp-id value - range: [1...17407]	identifies the sdp-id of the sdp binding where the alarm has occurred <i>This element is only shown in detail mode.</i>
vc-id	Parameter type: <Alarm::SvcIdOrZero> - vc-id value or zero - range: [0,1...4294967295]	identifies the vc-id of the sdp binding where the alarm occurred or zero when not applicable, the sdp binding is further specified in additional-info <i>This element is only shown in detail mode.</i>
Only Show Details: current alarm status		
name	Type	Description
instance-down	Parameter type: <Alarm::SdpInstanceDown> (yes no) Possible values: - yes : sdp is operationl down	specifies whether the SDP instance is down or not <i>This element is only shown in detail mode.</i>

name	Type	Description
	- no : sdp is operational up or shutdown	
binding-down	Parameter type: <Alarm::BindlingDown> (yes no) Possible values: - yes : sdp binding is operational down - no : sdp binding is operational up or shutdown, or the sdp or service is shutdown	specifies whether the SDP binding is down or not <i>This element is only shown in detail mode.</i>

104.78 IHUB IPV6 Current Alarm Status Command

Command Description

This command displays the ihub-ipv6 current alarm status.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm current ihub-ipv6 [ (index) ]
```

Command Parameters

Table 104.78-1 "IHUB IPV6 Current Alarm Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm type

Command Output

Table 104.78-2 "IHUB IPV6 Current Alarm Status Command" Display parameters

Specific Information		
name	Type	Description
router-id	Parameter type: <Ihub::Router> (base <Ihub::Router>) Possible values: - base : base router Field type <Ihub::Router> - vprn service-id - range: [1...2147483647]	identifies the vprn service-id or the base router where the alarm has occurred <i>This element is only shown in detail mode.</i>
duplicate-index	Parameter type: <Alarm::IdentificationIdxOrZero> - a signed integer	unique reference for the duplicate address for which the alarm has occurred or zero when not applicable, duplicate address is further specified in additional-info. <i>This element is only shown in detail mode.</i>
additional-info	Parameter type: <Alarm::AddInfoStringVprn> - additional alarm information	identifies the ipv6 alarm additional info or empty string if not applicable.

name	Type	Description
		<i>This element is only shown in detail mode.</i>

Only Show Details: current alarm status		
name	Type	Description
duplicate-address-own	Parameter type: <Alarm::SelfDuplicateIPv6Addr> (yes no) Possible values: - yes : duplicate address detected for own ipv6 address - no : no duplicate address detected for own ipv6 address	specifies whether a duplicate address is detected for own IPV6 address or not <i>This element is only shown in detail mode.</i>
duplicate-address	Parameter type: <Alarm::DuplicateIPv6Addr> (yes no) Possible values: - yes : duplicate address detected for user's ipv6 address - no : no duplicate address detected for user's ipv6 address	specifies whether a duplicate address is detected for a user's IPV6 address or not <i>This element is only shown in detail mode.</i>
ipv6-dup-pd-route	Parameter type: <Alarm::Ipv6DupPdRoute> (yes no) Possible values: - yes : duplicate address detected for user's ipv6 PD route - no : no duplicate address detected for user's ipv6 PD route	status of ipv6-dup-pd-route <i>This element is only shown in detail mode.</i>

104.79 EPIPE Current Alarm Status Command

Command Description

This command displays the current Ethernet Pipe alarm status.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

> show alarm current epipe [(index)]

Command Parameters

Table 104.79-1 "EPIPE Current Alarm Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm type

Command Output

Table 104.79-2 "EPIPE Current Alarm Status Command" Display parameters

Specific Information		
name	Type	Description
service-id	Parameter type: <Alarm::ServiceId> - a profile index value - range: [1...2147483647]	identifies the epipe service-id where the alarm has occurred <i>This element is only shown in detail mode.</i>

Only Show Details: current alarm status		
name	Type	Description
instance-down	Parameter type: <Alarm::EpipeInstanceDown> (yes no) Possible values: - yes : epipe service is operationl down - no : epipe service is operational up or shutdown	specifies whether the epipe instance is down or not <i>This element is only shown in detail mode.</i>

104.80 PIM Current Alarm Status Command

Command Description

This command displays the current PIM alarm status.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

> show alarm current pim [(index)]

Command Parameters

Table 104.80-1 "PIM Current Alarm Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm type

Command Output

Table 104.80-2 "PIM Current Alarm Status Command" Display parameters

Specific Information		
name	Type	Description
router-id	Parameter type: <Ihub::Router> (base <Ihub::Router>) Possible values: - base : base router Field type <Ihub::Router> - vprn service-id - range: [1...2147483647]	identifies the base router where the alarm has occurred <i>This element is only shown in detail mode.</i>
neighbor-idx	Parameter type: <Alarm::IdentificationIdxOrZero> - a signed integer	unique reference for the neighbor where the alarm occurred <i>This element is only shown in detail mode.</i>
additional-info	Parameter type: <Alarm::AddInfoStringPim> - additional alarm information	identifies the neighbor/instance where the alarm occurred or empty string if not applicable <i>This element is only shown in detail mode.</i>

Only Show Details: current alarm status

104 Current Alarm Status Commands

name	Type	Description
pim-neighbor-down	Parameter type: <Alarm::IhubPimDown> (yes no) Possible values: - yes : pim neighbor down - no : pim neighbor up	specifies whether the neighbor instance is down or not <i>This element is only shown in detail mode.</i>
mc-maximum-routes	Parameter type: <Alarm::IhubMaxRoutes> (yes no) Possible values: - yes : maximum routes reached - no : maximum routes not reached	specifies whether the max mc routes is reached <i>This element is only shown in detail mode.</i>

104.81 IHUB Lawful Intercept Current Alarm Status Command

Command Description

This command displays the lawful intercept current alarm status.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm current li [ (index) ]
```

Command Parameters

Table 104.81-1 "IHUB Lawful Intercept Current Alarm Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm type

Command Output

Table 104.81-2 "IHUB Lawful Intercept Current Alarm Status Command" Display parameters

Only Show Details: current alarm status		
name	Type	Description
li-traf-disabled	Parameter type: <Alarm::LiTrafficDisabled> (yes no) Possible values: - yes : lawful interception of traffic disabled - no : lawful interception of traffic enabled	specifies whether a lawful intercept traffic is disabled or not <i>This element is only shown in detail mode.</i>
li-bandwidth	Parameter type: <Alarm::LiBandwidthLimit> (reached not-reached) Possible values: - reached : lawful intercept reached bandwidth limit - not-reached : lawful intercept within bandwidth limit	specifies whether lawful intercept reached bandwidth limit or not <i>This element is only shown in detail mode.</i>
li-out-of-res	Parameter type: <Alarm::LiOutOfRes> (yes no) Possible values:	specifies whether lawful intercept is out of resources or not <i>This element is only shown in detail mode.</i>

104 Current Alarm Status Commands

name	Type	Description
	- yes : lack of resources for lawful intercept - no : no resource issues for lawful intercept	

104.82 Sync Clock Current Alarm Status Command

Command Description

This command displays the synce and bits current alarm status.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm current sync [ (index) ]
```

Command Parameters

Table 104.82-1 "Sync Clock Current Alarm Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm type

Command Output

Table 104.82-2 "Sync Clock Current Alarm Status Command" Display parameters

Only Show Details: slot information		
name	Type	Description
slot	Parameter type: <Alarm::SynceSlot> (ntio-1 ntio-2 nt-a nt-b lt : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> not-used nt) Possible values: - ntio-1 : an nt applique slot in a single or multiple-ntio-shelf - ntio-2 : an nt applique slot in a multiple-ntio-shelf - nt-a : nt-a slot - nt-b : nt-b slot - nt : active nt slot - lt : lt slot - not-used : no interface Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number	identifies the synce port where the alarm has occurred. <i>This element is only shown in detail mode.</i>

104 Current Alarm Status Commands

name	Type	Description
	Field type <Eqpt::SlotId> - the LT slot number	
port	Parameter type: <Alarm::SyncePort> (sfp : <Alarm::SynceClk> xfp : <Alarm::SynceClk> bits-a bits-b ieee1588-a not-used ieee1588-b gnssrj45-a gnssrj45-b ieee1588-hybrid-a ieee1588-hybrid-b cfp : <Alarm::SynceClk> <Alarm::SynceClk> qsfps : <Alarm::SynceClk> ieee1588 internal-clk-a internal-clk-b) Possible values: - sfp : synce reference on sfp port - xfp : synce reference on xfp port - bits-a : bits clock source on nt-a - bits-b : bits clock source on nt-b - ieee1588-a : ieee1588 clock source on nt-a - ieee1588-b : ieee1588 clock source on nt-b - gnssrj45-a : gnss tod source on nt-a - gnssrj45-b : gnss tod source on nt-b - ieee1588-hybrid-a : 1588 hybrid tod source on nt-a - ieee1588-hybrid-b : 1588 hybrid tod source on nt-b - cfp : synce reference on cfp port - qsfps : synce reference on qsfps port - ieee1588 : ieee1588 clock source on nt - internal-clk-a : internal clock on nt-a - internal-clk-b : internal clock on nt-b - not-used : not-used Field type <Alarm::SynceClk> - value - range: [0...36]	identifies the synce port where the alarm has occurred. <i>This element is only shown in detail mode.</i>

Only Show Details: current and previous alarm log status		
name	Type	Description
bits-fail	Parameter type: <Alarm::BitsFail> (yes no) Possible values: - yes : bits source failed - no : no bits source failed	specifies whether bits clock source has failed or not <i>This element is only shown in detail mode.</i>
synce-fail	Parameter type: <Alarm::SynceFail> (yes no) Possible values: - yes : synce source failed - no : no synce source failed	specifies whether synce clock source has failed or not <i>This element is only shown in detail mode.</i>
bits-output-shutoff	Parameter type: <Alarm::BitsOutputShutoffFail> (yes no)	specifies whether bits output failed or not <i>This element is only shown in</i>

name	Type	Description
	Possible values: - yes : bits output shutoff - no : no bits output shutoff	<i>detail mode.</i>
ieee1588-fail	Parameter type: <Alarm::ieee1588Fail> (yes no) Possible values: - yes : bits output shutoff - no : no bits output shutoff	ieee1588 clock source failure <i>This element is only shown in detail mode.</i>
gnss-fail	Parameter type: <Alarm::gnssFail> (yes no) Possible values: - yes : gnss tod fail - no : no gnss tod fail	gnss time source failure <i>This element is only shown in detail mode.</i>
ieee1588hybrid-fail	Parameter type: <Alarm::ieee1588hybridFail> (yes no) Possible values: - yes : 1588 hybrid tod fail - no : no 1588 hybrid tod fail	ieee1588 hybrid tod source failure <i>This element is only shown in detail mode.</i>
signal-loss	Parameter type: <Alarm::ClockLoss> (yes no) Possible values: - yes : synce or bits clock signal loss - no : no synce or bits clock signal loss	specifies whether synce or bits clock signal loss or not <i>This element is only shown in detail mode.</i>
signal-efd	Parameter type: <Alarm::ClockEfd> (yes no) Possible values: - yes : synce or bits clock signal exceed frequency deviation - no : no synce or bits clock signal exceed frequency deviation	specifies whether synce or bits clock signal exceed frequency deviation or not <i>This element is only shown in detail mode.</i>
esmc-loss	Parameter type: <Alarm::ClockEsmcLoss> (yes no) Possible values: - yes : clock source SSM infomation loss - no : no clock source SSM infomation loss	specifies whether clock source loss SSM infomation or not <i>This element is only shown in detail mode.</i>
bits-output-exceed	Parameter type: <Alarm::BitsOutputQlThreshExceed> (yes no) Possible values: - yes : bitout ql threshold exceed - no : no bitout ql threshold exceed	specifies whether bits output ql threshold exceeded or not <i>This element is only shown in detail mode.</i>
ql-input-exceed	Parameter type: <Alarm::ClockExceed> (yes no) Possible values: - yes : input clock source threshold exceed - no : no input clock source threshold exceed	specifies whether exceed input clock source threshold or not <i>This element is only shown in detail mode.</i>
holdover	Parameter type: <Alarm::ClockHoldover> (yes no) Possible values: - yes : Clock system is in the holdover	specifies whether clock system is in the holdover or not <i>This element is only shown in detail mode.</i>

104 Current Alarm Status Commands

name	Type	Description
	- no : Clock system is not in the holdover	
lti	Parameter type: <Alarm::ClockLTI> (yes no) Possible values: - yes : all clock source failed - no : no all clock source failed	specifies whether all clock source failed or not <i>This element is only shown in detail mode.</i>
tod-reference-fail	Parameter type: <Alarm::ToDHoldover> (yes no) Possible values: - yes : Clock system ToD reference is failed - no : Clock system ToD reference is OK	specifies whether clock system tod reference is failed or not <i>This element is only shown in detail mode.</i>
internal-clk-fail	Parameter type: <Alarm::ClockOCXOFail> (yes no) Possible values: - yes : Internal CLK is failed - no : Internal CLK is OK	specifies whether internal clock is failed or not <i>This element is only shown in detail mode.</i>

104.83 Equipment Supplemental Current Alarm Status Command

Command Description

This command displays the equipment supplemental current alarm status.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

> show alarm current eqpt-supplemental [(index)]

Command Parameters

Table 104.83-1 "Equipment Supplemental Current Alarm Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm type

Command Output

Table 104.83-2 "Equipment Supplemental Current Alarm Status Command" Display parameters

Specific Information		
name	Type	Description
shelf	Parameter type: <Equipm::Shelf> <Eqpt::RackId> / <Eqpt::ShelfId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number	specify which shelf the alarm occurred on. <i>This element is only shown in detail mode.</i>
syslog-upload	Parameter type: <Alarm::uploadFailed> (failed ok) Possible values: - failed : upload of syslog file to remote server failed - ok : no syslog file upload failure detected	current status of the alarm specifying whether a failure occurred during upload of the NE's system log file to the syslog server or not <i>This element is only shown in detail mode.</i>
ont-sw-dnload	Parameter type: <Alarm::ontSoftwareDownload> (in-progress ok)	current status of the alarm specifying whether downloading of ont sw from version control to

104 Current Alarm Status Commands

name	Type	Description
	Possible values: - in-progress : ont software download in progress - ok : no ont software download detected	ont is in progress or not <i>This element is only shown in detail mode.</i>
cf-75%-used	Parameter type: <Alarm::cf75Percent> (above below) Possible values: - above : Compact flash exceeds 75% of life expectancy - below : Compact flash is below 75% of life expectancy	current status of CF utilization which could be more than 75% or less than that <i>This element is only shown in detail mode.</i>
cf-90%-used	Parameter type: <Alarm::cf90Percent> (above below) Possible values: - above : Compact flash exceeds 90% of life expectancy - below : Compact flash is below 90% of life expectancy	current status of CF utilization which could be more than 90% or less than that <i>This element is only shown in detail mode.</i>

104.84 Otdr Current Alarm Status Command

Command Description

This command displays the otdr current alarm status.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm current otdr [ (index) ]
```

Command Parameters

Table 104.84-1 "Otdr Current Alarm Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm type

Command Output

Table 104.84-2 "Otdr Current Alarm Status Command" Display parameters

Only Show Details: sfp information		
name	Type	Description
ponindex	Parameter type: <Itf::ComplexPortType> (xdsl-line : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> voicefxs : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> xdsl-channel : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> atm-if : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> atm-pvc : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::VpiId> : <Eqpt::VciId> bridge-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::VpiId> : <Eqpt::VciId> vlan-port:ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / <Eqpt::Ng2OntSlotId> / <Eqpt::Ng2OntPortId> : <Eqpt::UnstackedVlan> l2-vlan : <Eqpt::VlanId>	identifies the spf where the alarm has occurred. <i>This element is only shown in detail mode.</i>

name	Type	Description
	ip : <Eqpt::LogicalId> sw-loopback slip uni:ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / <Eqpt::Ng2OntSlotId> / <Eqpt::Ng2OntPortId> vlan-port:ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / <Eqpt::Ng2OntSlotId> / <Eqpt::Ng2OntPortId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> atm-bonding : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> bonding : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> ip-gateway : <Eqpt::VrfId> ip-line : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::VpiId> : <Eqpt::VciId> ip-line : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> shdsl-line : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> e1-line : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> atm-ima : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> ethernet-line : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> bridge-port:ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / vuni vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::VpiId> : <Eqpt::VciId> : <Eqpt::UnstackedVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::UnstackedVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::VpiId> : <Eqpt::VciId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> voip:ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> ip-line : vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::VpiId> : <Eqpt::VciId> : <Eqpt::UnstackedVlan> ip-line : vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::UnstackedVlan> ip-line : vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::VpiId> : <Eqpt::VciId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> ip-line : vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan-port:ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / vuni : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan-port:ng2 : <Eqpt::ChannelGroupId> /	

name	Type	Description
	<pre> <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / vuni : <Eqpt::UnstackedVlan> chgroup : <Eqpt::ChannelGroupId> subchgroup : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> bridge-port:ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / <Eqpt::Ng2OntSlotId> / <Eqpt::Ng2OntPortId> atm-pvc : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> bridge-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> bridge-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> / <Eqpt::OntPortId> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> / <Eqpt::OntPortId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> / <Eqpt::OntPortId> : <Eqpt::UnstackedVlan> pon : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> ont : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> uni : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> / <Eqpt::OntPortId> bridge-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / voip bridge-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / vuni vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / voip : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / vuni : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / voip : <Eqpt::UnstackedVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / vuni : <Eqpt::UnstackedVlan> voip : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> la-group : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::LLId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> bridge-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::LLId> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / </pre>	

104 Current Alarm Status Commands

name	Type	Description
	<Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::LLId> : <Eqpt::UnstackedVlan> mpm : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::ComboPonId> x-pon : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::XPonId> 25g-pon : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::M25GPonId> dist-router-interface : slot-stacked : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::SVlan> : <Eqpt::CVlan> dist-router-interface : slot-vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::UnstackedVlan> bundle : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::BundleId> chpair : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::ChannelPairId> ont.ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId>) Possible values: - xdsl-line : a static xdsl line interface - xdsl-channel : a static xdsl channel interface - atm-if : a static atm interface - atm-pvc : an atm pvc interface - bridge-port : a vlan bridge-port - bridge-port.ng2 : a ngpon2 vlan bridge-port - l2-vlan : a l2-vlan interface - ip : an ip interface - sw-loopback : a software loopback interface - slip : a slip interface - atm-bonding : atm bonding obsolete alternative replaced by bonding - bonding : bonding - ip-gateway : ip user gateway interface - ip-line : ip line interface - shdsl-line : a static shdsl line interface - e1-line : a e1 line interface - atm-ima : atm ima - ethernet-line : an ethernet line interface - vlan-port : vlan port - vlan-port.ng2 : a ngpon2 vlan port - pon : pon - x-pon : xgs pon - 25g-pon : 25g pon - chpair : channelpair - chgroup : channelgroup - subchgroup : subchannelgroup - bundle : bundle - ont : ont - ont.ng2 : ngpon2 ONT style identification - uni : uni - uni.ng2 : ngpon2 UNI style identification - voip : voip - voip.ng2 : voip - la-group : link aggregation group - dist-router-interface : dist router interface - voicefxs : voicefxs	

name	Type	Description
	- mpm : multi-pon module - Possible values: - vlan : vlan port - Possible values: - slot-vlan : slot unstacked - slot-stacked : slot vlan port - Field type <Eqpt::RackId> - the rack number - Field type <Eqpt::ShelfId> - the shelf number - Field type <Eqpt::SlotId> - the LT slot number - Field type <Eqpt::PortId> - the port number - Field type <Eqpt::VpiId> - atm VPI - Field type <Eqpt::VciId> - atm VCI - Field type <Eqpt::PonId> - the PON identifier - Field type <Eqpt::XPonId> - the XGS PON identifier - Field type <Eqpt::M25GPonId> - the 25G PON identifier - Field type <Eqpt::ComboPonId> - the comboPON identifier - Field type <Eqpt::ChannelPairId> - the channel pair identifier - Field type <Eqpt::ChannelGroupId> - the channel group identifier - Field type <Eqpt::SubChannelGroupId> - the subchannel group identifier - Field type <Eqpt::BundleId> - the BUNDLE identifier - Field type <Eqpt::OntId> - the ONT identifier - Field type <Eqpt::Ng2OntId> - the NG2 ONT identifier - Possible values: - voip : virtual uni identifier - obsolete alternative replaced by vuni - vuni : virtual uni identifier - Possible values: - vuni : virtual NGPON2 uni identifier - Field type <Eqpt::OntSlotId> - the ONT SLOT identifier - Field type <Eqpt::OntPortId> - the ONT PORT identifier - Field type <Eqpt::Ng2OntSlotId> - the NGPON2 ONT SLOT identifier - Field type <Eqpt::Ng2OntPortId> - the NGPON2 ONT PORT identifier - Field type <Eqpt::LLId> - the LLID identifier,range 1 for EPON,range 1-8 for DPOE - Possible values: - stacked : stacked vlan identity - Field type <Eqpt::UnstackedVlan>	

104 Current Alarm Status Commands

name	Type	Description
	- unstacked vlan id Field type <Eqpt::SVlan> - service vlan id Field type <Eqpt::CVlan> - customer vlan id Field type <Eqpt::VlanId> - VLAN id Field type <Eqpt::LogicalId> - logical id Field type <Eqpt::VrflId> - VRF id	

Only Show Details: current and previous alarm log status		
name	Type	Description
capability-mismatch	Parameter type: <Alarm::OTDRmismatch> (yes no) Possible values: - yes : otdr capability mismatch - no : no otdr capability mismatch	specifies whether otdr capability mismatch has occurred. <i>This element is only shown in detail mode.</i>

104.85 Management Security Access Current Alarm Status Command

Command Description

This command displays the management security access current alarm status.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

> show alarm current mgmt-sec-access [(index)]

Command Parameters

Table 104.85-1 "Management Security Access Current Alarm Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm type

Command Output

Table 104.85-2 "Management Security Access Current Alarm Status Command" Display parameters

Specific Information		
name	Type	Description
last-updated-on	Parameter type: <Sys::timeInSecs> - the time (yyyy-mm-dd:hour:minutes:secs) - unit: UTC	network time in seconds when the alarm was logged. <i>This element is only shown in detail mode.</i>
ip-address	Parameter type: <Alarm::IpAddress> - IPv4-address	address of the operator <i>This element is only shown in detail mode.</i>
additional-info	Parameter type: <PrintableString> - printable string	displays the timestamp and operator name separated by semicolon. <i>This element is only shown in detail mode.</i>

Only Show Details: current alarm status

104 Current Alarm Status Commands

name	Type	Description
login-successful	Parameter type: <Alarm::MgmtAccess> (yes no) Possible values: - yes : successfully logged in via management access - no : successfully logged out via management access	current status specifying whether successfully logged in or logged out via Management access <i>This element is only shown in detail mode.</i>
login-failure	Parameter type: <Alarm::InvalidAccess> (yes no) Possible values: - yes : invalid login via management access crossed the threshold - no : invalid login via management access within the threshold	current status specifying invalid attempts to login via management access crossed the threshold or not <i>This element is only shown in detail mode.</i>

104.86 IHUB BFD Current Alarm Status Command

Command Description

This command displays the bfd current alarm status.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm current bfd [ (index) ]
```

Command Parameters

Table 104.86-1 "IHUB BFD Current Alarm Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm type

Command Output

Table 104.86-2 "IHUB BFD Current Alarm Status Command" Display parameters

Specific Information		
name	Type	Description
vpn-id	Parameter type: <Ihub::Router> (base <Ihub::Router>) Possible values: - base : base router Field type <Ihub::Router> - vpn service-id - range: [1...2147483647]	identifies the vpn service-id or the base router where the alarm has occurred. <i>This element is only shown in detail mode.</i>
bfd-unique-id	Parameter type: <Alarm::IdentificationIdxOrZero> - a signed integer	unique identification for the alarm or zero when not applicable, alarm entry is further specified in additional-info <i>This element is only shown in detail mode.</i>
additional-info	Parameter type: <Alarm::AddInfoStringBfd> - additional alarm information	Additional information regarding the bfd alarm <i>This element is only shown in detail mode.</i>

Only Show Details: current alarm status

104 Current Alarm Status Commands

name	Type	Description
bfd-session-down	Parameter type: <Alarm::BfdSessionDown> (yes no) Possible values: - yes : bfd session down - no : bfd session not down	specifies whether a bfd session went down or not <i>This element is only shown in detail mode.</i>
bfd-max-resource	Parameter type: <Alarm::BfdMaxResource> (yes no) Possible values: - yes : bfd maximum resources reached - no : no resource issues for bfd	specifies whether bfd has reached maximum resources or not <i>This element is only shown in detail mode.</i>
bfd-stale-entry	Parameter type: <Alarm::BfdStaleEntry> (yes no) Possible values: - yes : bfd stale entry present - no : bfd stale entry not present	specifies whether a bfd entry has become stale or not <i>This element is only shown in detail mode.</i>

104.87 Application Intelligence Current Alarm Status Command

Command Description

This command displays the current Application Intelligence alarm status.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm current ai [ (index) ]
```

Command Parameters

Table 104.87-1 "Application Intelligence Current Alarm Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm type

Command Output

Table 104.87-2 "Application Intelligence Current Alarm Status Command" Display parameters

Specific Information		
name	Type	Description
slot-id	Parameter type: <Equipm::NtSlotIndex> (nt-a nt-b) Possible values: - nt-a : nt-a slot - nt-b : nt-b slot	identifies the board hosting the AI Platform for which the alarm has occurred. <i>This element is only shown in detail mode.</i>
application-virtplatf	Parameter type: <SignedInteger> - a signed integer	identifies the Application and/or the virtualplatform for which the alarm occurred <i>This element is only shown in detail mode.</i>
additional-info	Parameter type: <Alarm::AddInfoStringAI> - Additional info: Application Name - length: x<=32	Additional information regarding the AI alarm (Application name or none) <i>This element is only shown in detail mode.</i>

104 Current Alarm Status Commands

Only Show Details: current alarm status		
name	Type	Description
ai-platform-down	Parameter type: <Alarm::AIPlatformDown> (yes no) Possible values: - yes : AI Platform down - no : AI Platform not down	specifies whether an AI Platform went down or not <i>This element is only shown in detail mode.</i>
ai-appl-install-fail	Parameter type: <Alarm::AIApplInstallFail> (yes no) Possible values: - yes : Application installation failed - no : Application installation successful	specifies whether an Application 'download and installation' failed or was successful <i>This element is only shown in detail mode.</i>
ip-assign-fail	Parameter type: <Alarm::IpAddrAssignFail> (yes no) Possible values: - yes : Dhcp assigned address failure - no : Dhcp assigned address successful	specifies whether dhcp client 'assigned ip address' failed or was successful <i>This element is only shown in detail mode.</i>

104.88 Tr069 Alarm Status Command

Command Description

This command displays the tr069 current alarm status.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm current tr069serv [ (index) ]
```

Command Parameters

Table 104.88-1 "Tr069 Alarm Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm type

Command Output

Table 104.88-2 "Tr069 Alarm Status Command" Display parameters

Specific Information		
name	Type	Description
tr069serv	Parameter type: <Gpon::UniInterfaceIndexSnpAgent> (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> / <Eqpt::OntPortId> ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / <Eqpt::Ng2OntSlotId> / <Eqpt::Ng2OntPortId> ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / vuni) Possible values: - ng2 : ngpon2 style identification Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Eqpt::ChannelGroupId>	identifies the tr069 serv entry <i>This element is only shown in detail mode.</i>

104 Current Alarm Status Commands

name	Type	Description
	- the channel group identifier Field type <Eqpt::SubChannelGroupId> - the subchannel group identifier Field type <Eqpt::OntId> - the ONT identifier Field type <Eqpt::Ng2OntId> - the NG2 ONT identifier Possible values: - vuni : virtual NGPON2 uni identifier - the ONT SLOT identifier Field type <Eqpt::OntSlotId> - the ONT PORT identifier Field type <Eqpt::Ng2OntSlotId> - the NGPON2 ONT SLOT identifier Field type <Eqpt::Ng2OntPortId> - the NGPON2 ONT PORT identifier	

Only Show Details: current alarm status		
name	Type	Description
ont-tr069-serv-mis	Parameter type: <Alarm::Tr069ServMis> (yes no) Possible values: - yes : ont tr069 server mismatch occurred - no : no ont tr069 server mismatch	specifies ont tr069 server mismatch occurred or not. <i>This element is only shown in detail mode.</i>

104.89 ONT SNMP Current Alarm Status Command

Command Description

This command displays the ont snmp current alarm status.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

> show alarm current ontsnmp [(index)]

Command Parameters

Table 104.89-1 "ONT SNMP Current Alarm Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm type

Command Output

Table 104.89-2 "ONT SNMP Current Alarm Status Command" Display parameters

Specific Information		
name	Type	Description
uni-index	Parameter type: <Ces::InterfaceIndex> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> / <Eqpt::OntPortId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Eqpt::OntId> - the ONT identifier Field type <Eqpt::OntSlotId> - the ONT SLOT identifier Field type <Eqpt::OntPortId> - the ONT PORT identifier	identification of the uni interface index <i>This element is only shown in detail mode.</i>
snmp-mismatch	Parameter type: <Alarm::OntSnmpMismatch>	current status specifying ont snmp

104 Current Alarm Status Commands

name	Type	Description
	(mismatch not-mismatch) Possible values: - mismatch : ont snmp agent configuration data is mismatch - not-mismatch : ont snmp agent configuration data is not mismatch	is mismatch or not <i>This element is only shown in detail mode.</i>

104.90 Bulk Sync Alarm Log Status Command

Command Description

This command displays the bulk sync alarm log status.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

> show alarm current bulk-sync [(index)]

Command Parameters

Table 104.90-1 "Bulk Sync Alarm Log Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm type

Command Output

Table 104.90-2 "Bulk Sync Alarm Log Status Command" Display parameters

Specific Information		
name	Type	Description
port	Parameter type: <RedPort::PortIndex> (pon : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> chpair : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::ChannelPairId>) Possible values: - pon : pon-aid - chpair : chpair-aid Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Eqpt::ChannelPairId> - the channel pair identifier	specify which port the alarm occurred on. <i>This element is only shown in detail mode.</i>

Only Show Details: current alarm log status

104 Current Alarm Status Commands

name	Type	Description
bsf-dhcpv4-fail	Parameter type: <Alarm::BsfDHCPv4> ((failing fail) ok) Possible values: - failing : dhcpv4 bulk-sync is failing - fail : dhcpv4 bulk-sync is failing - ok : dhcpv4 bulk-sync is ok	current status of dhcpv4 bulk-sync failure. <i>This element is only shown in detail mode.</i>
bsf-dhcpv6-fail	Parameter type: <Alarm::BsfDHCPv6> ((failing fail) ok) Possible values: - failing : dhcpv6 bulk-sync is failing - fail : dhcpv6 bulk-sync is failing - ok : dhcpv6 bulk-sync is ok	current status of dhcpv6 bulk-sync failure. <i>This element is only shown in detail mode.</i>
bsf-pon-fail	Parameter type: <Alarm::BsfPON> ((failing fail) ok) Possible values: - failing : pon bulk-sync is failing - fail : pon bulk-sync is failing - ok : pon bulk-sync is ok	current status of pon bulk-sync failure. <i>This element is only shown in detail mode.</i>
bsf-vlan-bridge-fail	Parameter type: <Alarm::BsfVBridge> ((failing fail) ok) Possible values: - failing : vlan-bridge bulk-sync is failing - fail : vlan-bridge bulk-sync is failing - ok : vlan-bridge bulk-sync is ok	current status of vlan-bridge bulk-sync failure. <i>This element is only shown in detail mode.</i>
bsf-qos-fail	Parameter type: <Alarm::BsfQoS> ((failing fail) ok) Possible values: - failing : qos bulk-sync is failing - fail : qos bulk-sync is failing - ok : qos bulk-sync is ok	current status of qos bulk-sync failure. <i>This element is only shown in detail mode.</i>
bsf-igmp-fail	Parameter type: <Alarm::BsfIGMP> ((failing fail) ok) Possible values: - failing : igmp bulk-sync is failing - fail : igmp bulk-sync is failing - ok : igmp bulk-sync is ok	current status of igmp bulk-sync failure. <i>This element is only shown in detail mode.</i>
bsf-lxfwd-fail	Parameter type: <Alarm::BsfLxFwd> ((failing fail) ok) Possible values: - failing : LxFwd bulk-sync is failing - fail : LxFwd bulk-sync is failing - ok : LxFwd bulk-sync is ok	current status of lxfwd bulk-sync failure. <i>This element is only shown in detail mode.</i>

104.91 Protection Group Alarm Log Status Command

Command Description

This command displays the protection group alarm log status.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

> show alarm current protection-group [(index)]

Command Parameters

Table 104.91-1 "Protection Group Alarm Log Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm type

Command Output

Table 104.91-2 "Protection Group Alarm Log Status Command" Display parameters

Specific Information		
name	Type	Description
port	Parameter type: <RedPort::PortIndex> (pon : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> chpair : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::ChannelPairId>) Possible values: - pon : pon-aid - chpair : chpair-aid Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier	specify which port the alarm occurred on. <i>This element is only shown in detail mode.</i>

104 Current Alarm Status Commands

name	Type	Description
	Field type <Eqpt::ChannelPairId> - the channel pair identifier	

Only Show Details: current alarm log status		
name	Type	Description
port-protection-fail	Parameter type: <Alarm::ProtNotAvail> ((failing fail) ok) Possible values: - failing : port protection is failing - fail : port protection is failing - ok : port protection is ok	current status of port protection failure. <i>This element is only shown in detail mode.</i>
port-switchover-fail	Parameter type: <Alarm::ProtSwFail> ((failing fail) ok) Possible values: - failing : port protection switchover failing - fail : port protection switchover failing - ok : port protection switchover is ok	current status of port switchover failure. <i>This element is only shown in detail mode.</i>

104.92 Ont protection Alarm Log Status Command

Command Description

This command displays the ont protection alarm log status.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

> show alarm current ont-protection [(index)]

Command Parameters

Table 104.92-1 "Ont protection Alarm Log Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm type

Command Output

Table 104.92-2 "Ont protection Alarm Log Status Command" Display parameters

Specific Information		
name	Type	Description
ont	Parameter type: <Gpon::OntIndex> (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> ng2 : <Ng2::ChannelGroup> / <Ng2::SubchannelGroup> / <Ng2::OntId>) Possible values: - ng2 : ngpon2 style identification Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Ng2::ChannelGroup> - channel group number Field type <Ng2::SubchannelGroup> - subchannel group number Field type <Eqpt::OntId>	identifies the ont entry <i>This element is only shown in detail mode.</i>

104 Current Alarm Status Commands

name	Type	Description
	- the ONT identifier Field type <Ng2::OntId> - the ONT identifier	

Only Show Details: current alarm log status		
name	Type	Description
ont-prot-fail	Parameter type: <Alarm::OntProtNotAvail> ((failing fail) ok) Possible values: - failing : ont protection is failing - fail : ont protection is failing - ok : ont protection is ok	current status of ont protection failure. <i>This element is only shown in detail mode.</i>

104.93 ONT General Supplemental Current Alarm Status Command

Command Description

This command displays the ONT general supplemental current alarm status.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

> show alarm current ont [(index)]

Command Parameters

Table 104.93-1 "ONT General Supplemental Current Alarm Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm type

Command Output

Table 104.93-2 "ONT General Supplemental Current Alarm Status Command" Display parameters

Specific Information		
name	Type	Description
ont	Parameter type: <Gpon::OntIndex> (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> ng2 : <Ng2::ChannelGroup> / <Ng2::SubchannelGroup> / <Ng2::OntId>) Possible values: - ng2 : ngpon2 style identification Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier	identifies the ont entry <i>This element is only shown in detail mode.</i>

104 Current Alarm Status Commands

name	Type	Description
	Field type <Ng2::ChannelGroup> - channel group number Field type <Ng2::SubchannelGroup> - subchannel group number Field type <Eqpt::OntId> - the ONT identifier Field type <Ng2::OntId> - the ONT identifier	

Only Show Details: current alarm status		
name	Type	Description
ont-gen-sw-dnload-file	Parameter type: <Alarm::ONTGENERALSUPPLEMENTALSWDLFILE> (yes no) Possible values: - yes : ont sw download file missing - no : ont works properly	ont sw download file missing <i>This element is only shown in detail mode.</i>
ont-gen-fan-fail	Parameter type: <Alarm::ONTGENERALSUPPLEMENTALFANALM> (yes no) Possible values: - yes : ont fan failure - no : ont works properly	ont fan failure <i>This element is only shown in detail mode.</i>
ont-gen-high-temp	Parameter type: <Alarm::ONTGENERALSUPPLEMENTALHITEMPWARN> (yes no) Possible values: - yes : high temperature warning - no : ont works properly	ont high temperature <i>This element is only shown in detail mode.</i>
ont-gen-high-temp-ex	Parameter type: <Alarm::ONTGENERALSUPPLEMENTALHITEMPSHUTOFF> (yes no) Possible values: - yes : high temperature shutoff - no : ont works properly	ont excessive high temperature <i>This element is only shown in detail mode.</i>
ont-gen-emergency-call	Parameter type: <Alarm::ONTGENERALSUPPLEMENTALECALLACT> (yes no) Possible values: - yes : ont emergency call - no : ont works properly	ont emergency call <i>This element is only shown in detail mode.</i>
ont-gen-sw-version	Parameter type: <Alarm::ONTGENERALSUPPLEMENTALSWVERCTLERR> (yes no) Possible values: - yes : ont sw version control error - no : ont works properly	ont sw version control error <i>This element is only shown in detail mode.</i>
ont-poe-exceed-max	Parameter type: <Alarm::OntPoE> (yes no) Possible values: - yes : ont poe exceed max occurred	specifies ont poe exceed max occurred or not. <i>This element is only shown in detail mode.</i>

name	Type	Description
	- no : no ont poe exceed max	
ont-poe-over-yell	Parameter type: <Alarm::OntPoEY> (yes no) Possible values: - yes : ont poe is nearing its maximum ability to supply the power - no : ont poe is not nearing its maximum ability to supply the power	specifies ont poe is nearing its maximum ability to supply power. <i>This element is only shown in detail mode.</i>
ont-opti-malfunc	Parameter type: <Alarm::OntTransMal> (yes no) Possible values: - yes : ONT detects the malfunction of its optical transceiver - no : ONT not detects the malfunction of its optical transceiver	ONT detects the malfunction of its optical transceiver <i>This element is only shown in detail mode.</i>
ont-gen-cfgdld-fail	Parameter type: <Alarm::OntCfgDld> (yes no) Possible values: - yes : ont poe exceed max occurred - no : no ont poe exceed max	specifies download of voice xml file to ont failed or not. <i>This element is only shown in detail mode.</i>
ont-loopdetect-mis	Parameter type: <Alarm::OntLoopDetectMis> (yes no) Possible values: - yes : ont loop detect mismatch occurred - no : no ont loop detect mismatch	ONT loop detection configuration mismatch <i>This element is only shown in detail mode.</i>
ont-gen-rssi-mis	Parameter type: <Alarm::OntRssiMismatch> (yes no) Possible values: - yes : ont dose not support rssi feature - no : ont supports rssi feature	rssi mismatch status <i>This element is only shown in detail mode.</i>
ont-gen-tx-pwr-low	Parameter type: <Alarm::OntTxPwrAlrmLow> (yes no) Possible values: - yes : tx pwr at ont side is too low - no : tx pwr at ont side is normal	tx pwr low alarm status <i>This element is only shown in detail mode.</i>
ont-gen-temp-high	Parameter type: <Alarm::OntTempAlrmHigh> (yes no) Possible values: - yes : temperature at ont side is too high - no : temperature at ont side is normal	temp alarm high status <i>This element is only shown in detail mode.</i>
ont-gen-volt-high	Parameter type: <Alarm::OntVoltAlrmHigh> (yes no) Possible values: - yes : voltage at ont side is too high - no : voltage at ont side is normal	voltage alarm high status <i>This element is only shown in detail mode.</i>
ont-gen-bias-high	Parameter type: <Alarm::OntBiasAlrmHigh> (yes no) Possible values: - yes : bias at ont side is too high	bias alarm high status <i>This element is only shown in detail mode.</i>

104 Current Alarm Status Commands

name	Type	Description
	- no : bias at ont side is normal	
ont-olt-rx-pw-hig	Parameter type: <Alarm::OltRxPwrAlrmH> (yes no) Possible values: - yes : rx power at olt side is too high - no : rx power at olt side is normal	bias alarm high status <i>This element is only shown in detail mode.</i>
ont-olt-rx-pw-warnhig	Parameter type: <Alarm::OltRxPwrWarnH> (yes no) Possible values: - yes : rx power at olt side is warn high - no : rx power at olt side is normal	bias alarm high status <i>This element is only shown in detail mode.</i>
ont-olt-rx-pw-warnlo	Parameter type: <Alarm::OltRxPwrWarnL> (yes no) Possible values: - yes : rx power at olt side is warn low - no : rx power at olt side is normal	bias alarm high status <i>This element is only shown in detail mode.</i>
ont-olt-rx-pw-lo	Parameter type: <Alarm::OltRxPwrAlrmL> (yes no) Possible values: - yes : rx power at olt side is too low - no : rx power at olt side is normal	bias alarm high status <i>This element is only shown in detail mode.</i>
ont-gen-tod-out-sync	Parameter type: <Alarm::TODOUTSYNC> (yes no) Possible values: - yes : tod is out-sync with olt - no : tod is sync with olt	tod is out-sync with olt <i>This element is only shown in detail mode.</i>
ont-gen-tune-fail	Parameter type: <Alarm::TUNEFAIL> (yes no) Possible values: - yes : Ont has failed to tune to Target-ChnlPair - no : Ont is to tune to Target-ChnlPair	ONU has failed to tune to Pref-ChnlPair <i>This element is only shown in detail mode.</i>
hgu-tr069-parm-fail	Parameter type: <Alarm::HGUTR69FAIL> (yes no) Possible values: - yes : hgu tr069 parameters mismatch - no : hgu tr069 parameters not mismatch	hgu tr069 parameters mismatch <i>This element is only shown in detail mode.</i>
ont-gen-tod-mismatch	Parameter type: <Alarm::TODMISMATCH> (yes no) Possible values: - yes : tod is mismatch - no : tod is ok	tod is mismatch <i>This element is only shown in detail mode.</i>

104.94 SFU ONT General Supplemental Current Alarm Status Command

Command Description

This command displays the SFU ONT general supplemental current alarm status.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm current sfu-sup [ (index) ]
```

Command Parameters

Table 104.94-1 "SFU ONT General Supplemental Current Alarm Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm type

Command Output

Table 104.94-2 "SFU ONT General Supplemental Current Alarm Status Command" Display parameters

Specific Information		
name	Type	Description
ont	Parameter type: <Gpon::OntIndex> (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> ng2 : <Ng2::ChannelGroup> / <Ng2::SubchannelGroup> / <Ng2::OntId>) Possible values: - ng2 : ngpon2 style identification Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId>	identifies the ont entry <i>This element is only shown in detail mode.</i>

104 Current Alarm Status Commands

name	Type	Description
	- the PON identifier - Field type <Ng2::ChannelGroup> - channel group number - Field type <Ng2::SubchannelGroup> - subchannel group number - Field type <Eqpt::OntId> - the ONT identifier - Field type <Ng2::OntId> - the ONT identifier	

Only Show Details: current alarm status		
name	Type	Description
sfu-sup-sw-file-error	Parameter type: <Alarm::ONTGENERALSUPPLEMENTALSWDLFILE> (yes no) Possible values: - yes : ont sw download file missing - no : ont works properly	SFU ONT - Software file has error or is missing <i>This element is only shown in detail mode.</i>
sfu-sup-fan-failure	Parameter type: <Alarm::ONTGENERALSUPPLEMENTALFANALM> (yes no) Possible values: - yes : ont fan failure - no : ont works properly	SFU ONT - Fan failure <i>This element is only shown in detail mode.</i>
sfu-sup-temp-high-warn	Parameter type: <Alarm::ONTGENERALSUPPLEMENTALHITEMPWARN> (yes no) Possible values: - yes : high temperature warning - no : ont works properly	SFU ONT - High temperature warning <i>This element is only shown in detail mode.</i>
sfu-sup-temp-shutoff	Parameter type: <Alarm::ONTGENERALSUPPLEMENTALHITEMPSHUTOFF> (yes no) Possible values: - yes : high temperature shutoff - no : ont works properly	SFU ONT - Service disabled due to excessive temperature <i>This element is only shown in detail mode.</i>
sfu-sup-emergency-call	Parameter type: <Alarm::ONTGENERALSUPPLEMENTALECALLACT> (yes no) Possible values: - yes : ont emergency call - no : ont works properly	SFU ONT - Emergency call active <i>This element is only shown in detail mode.</i>
sfu-sup-swverctrl-err	Parameter type: <Alarm::ONTGENERALSUPPLEMENTALSWVERCTRLERR> (yes no) Possible values: - yes : ont sw version control error - no : ont works properly	SFU ONT - Software version control error <i>This element is only shown in detail mode.</i>
sfu-sup-poe-exceed-max	Parameter type: <Alarm::OntPoE> (yes no) Possible values:	SFU ONT - Configured PoE feeding exceeds ONT maximum <i>This element is only shown in detail mode.</i>

name	Type	Description
	- yes : ont poe exceed max occurred - no : no ont poe exceed max	
sfu-sup-poe-over-yell	Parameter type: <Alarm::OntPoEY> (yes no) Possible values: - yes : ont poe is nearing its maximum ability to supply the power - no : ont poe is not nearing its maximum ability to supply the power	SFU ONT - specifies ont poe is nearing its maximum ability to supply power <i>This element is only shown in detail mode.</i>
sfu-opti-malfunc	Parameter type: <Alarm::OntTransMal> (yes no) Possible values: - yes : ONT detects the malfunction of its optical transceiver - no : ONT not detects the malfunction of its optical transceiver	ONT detects the malfunction of its optical transceiver <i>This element is only shown in detail mode.</i>
sfu-sup-cfg-dnld-fail	Parameter type: <Alarm::OntCfgDld> (yes no) Possible values: - yes : ont poe exceed max occurred - no : no ont poe exceed max	SFU ONT - Download of voice xml file to ONT failed <i>This element is only shown in detail mode.</i>
sfu-sup-ld-cfg-mism	Parameter type: <Alarm::OntLoopDetectMis> (yes no) Possible values: - yes : ont loop detect mismatch occurred - no : no ont loop detect mismatch	SFU ONT - Loop detection configuration mismatch <i>This element is only shown in detail mode.</i>
sfu-sup-rssi-cfg-mism	Parameter type: <Alarm::OntRssiMismatch> (yes no) Possible values: - yes : ont dose not support rssi feature - no : ont supports rssi feature	SFU ONT - RSSI configuration mismatch <i>This element is only shown in detail mode.</i>
sfu-sup-sfp-tx-low	Parameter type: <Alarm::OntTxPwrAlrmLow> (yes no) Possible values: - yes : tx pwr at ont side is too low - no : tx pwr at ont side is normal	SFU ONT - SFP Tx Power below configured low-level alarm threshold <i>This element is only shown in detail mode.</i>
sfu-sup-sfp-temp-high	Parameter type: <Alarm::OntTempAlrmHigh> (yes no) Possible values: - yes : temperature at ont side is too high - no : temperature at ont side is normal	SFU ONT - SFP Temperature above configured high-level alarm threshold <i>This element is only shown in detail mode.</i>
sfu-sup-sfp-volt-high	Parameter type: <Alarm::OntVoltAlrmHigh> (yes no) Possible values: - yes : voltage at ont side is too high - no : voltage at ont side is normal	SFU ONT - SFP Voltage above configured high-level alarm threshold <i>This element is only shown in detail mode.</i>
sfu-sup-sfp-bias-high	Parameter type: <Alarm::OntBiasAlrmHigh> (yes no) Possible values:	SFU ONT - SFP Bias above configured high-level alarm threshold <i>This element is only shown in</i>

104 Current Alarm Status Commands

name	Type	Description
	- yes : bias at ont side is too high - no : bias at ont side is normal	<i>detail mode.</i>
sfu-sup-olt-rx-high	Parameter type: <Alarm::OltRxPwrAlrmH> (yes no) Possible values: - yes : rx power at olt side is too high - no : rx power at olt side is normal	SFU ONT - OLT Rx power above receiver operating range <i>This element is only shown in detail mode.</i>
sfu-sup-olt-rx-hi-warn	Parameter type: <Alarm::OltRxPwrWarnH> (yes no) Possible values: - yes : rx power at olt side is warn high - no : rx power at olt side is normal	SFU ONT - OLT Rx power above high-level warning threshold <i>This element is only shown in detail mode.</i>
sfu-sup-olt-rx-lo-warn	Parameter type: <Alarm::OltRxPwrWarnL> (yes no) Possible values: - yes : rx power at olt side is warn low - no : rx power at olt side is normal	SFU ONT - OLT Rx power below low-level warning threshold <i>This element is only shown in detail mode.</i>
sfu-sup-olt-rx-low	Parameter type: <Alarm::OltRxPwrAlrmL> (yes no) Possible values: - yes : rx power at olt side is too low - no : rx power at olt side is normal	SFU ONT - OLT Rx power below receiver operating range <i>This element is only shown in detail mode.</i>
sfu-sup-tod-out-sync	Parameter type: <Alarm::TODOUTSYNC> (yes no) Possible values: - yes : tod is out-sync with olt - no : tod is sync with olt	SFU ONT - ONU TOD is out-sync with OLT <i>This element is only shown in detail mode.</i>
sfu-sup-ont-tune-fail	Parameter type: <Alarm::TUNEFAIL> (yes no) Possible values: - yes : Ont has failed to tune to Target-ChnlPair - no : Ont is to tune to Target-ChnlPair	SFU ONT - ONU has failed to tune to Target-ChnlPair <i>This element is only shown in detail mode.</i>
sfu-tr069-parm-fail	Parameter type: <Alarm::HGUTR69FAIL> (yes no) Possible values: - yes : hgu tr069 parameters mismatch - no : hgu tr069 parameters not mismatch	SFU ONT - hgu tr069 parameters mismatch <i>This element is only shown in detail mode.</i>
sfu-sup-tod-mismatch	Parameter type: <Alarm::TODMISMATCH> (yes no) Possible values: - yes : tod is mismatch - no : tod is ok	SFU ONT - ONU TOD MISMATCH <i>This element is only shown in detail mode.</i>

104.95 SOHO ONT General Supplemental Current Alarm Status Command

Command Description

This command displays the SOHO ONT general supplemental current alarm status.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

> show alarm current soho-sup [(index)]

Command Parameters

Table 104.95-1 "SOHO ONT General Supplemental Current Alarm Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm type

Command Output

Table 104.95-2 "SOHO ONT General Supplemental Current Alarm Status Command" Display parameters

Specific Information		
name	Type	Description
ont	Parameter type: <Gpon::OntIndex> (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> ng2 : <Ng2::ChannelGroup> / <Ng2::SubchannelGroup> / <Ng2::OntId>) Possible values: - ng2 : ngpon2 style identification Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId>	identifies the ont entry <i>This element is only shown in detail mode.</i>

104 Current Alarm Status Commands

name	Type	Description
	- the PON identifier - Field type <Ng2::ChannelGroup> - channel group number - Field type <Ng2::SubchannelGroup> - subchannel group number - Field type <Eqpt::OntId> - the ONT identifier - Field type <Ng2::OntId> - the ONT identifier	

Only Show Details: current alarm status		
name	Type	Description
soho-sup-sw-file-error	Parameter type: <Alarm::ONTGENERALSUPPLEMENTALSWDLFILE> (yes no) Possible values: - yes : ont sw download file missing - no : ont works properly	SOHO ONT - Software file has error or is missing <i>This element is only shown in detail mode.</i>
soho-sup-fan-failure	Parameter type: <Alarm::ONTGENERALSUPPLEMENTALFANALM> (yes no) Possible values: - yes : ont fan failure - no : ont works properly	SOHO ONT - Fan failure <i>This element is only shown in detail mode.</i>
soho-sup-temp-high-war	Parameter type: <Alarm::ONTGENERALSUPPLEMENTALHITEMPWARN> (yes no) Possible values: - yes : high temperature warning - no : ont works properly	SOHO ONT - High temperature warning <i>This element is only shown in detail mode.</i>
soho-sup-temp-shutoff	Parameter type: <Alarm::ONTGENERALSUPPLEMENTALHITEMPSHUTOFF> (yes no) Possible values: - yes : high temperature shutoff - no : ont works properly	SOHO ONT - Service disabled due to excessive temperature <i>This element is only shown in detail mode.</i>
soho-sup-emergency-cal	Parameter type: <Alarm::ONTGENERALSUPPLEMENTALECALLACT> (yes no) Possible values: - yes : ont emergency call - no : ont works properly	SOHO ONT - Emergency call active <i>This element is only shown in detail mode.</i>
soho-sup-swverctrl-err	Parameter type: <Alarm::ONTGENERALSUPPLEMENTALSWVERCTRLERR> (yes no) Possible values: - yes : ont sw version control error - no : ont works properly	SOHO ONT - Software version control error <i>This element is only shown in detail mode.</i>
soho-sup-poe-exceed-ma	Parameter type: <Alarm::OntPoE> (yes no) Possible values:	SOHO ONT - Configured PoE feeding exceeds ONT maximum <i>This element is only shown in detail mode.</i>

name	Type	Description
	- yes : ont poe exceed max occurred - no : no ont poe exceed max	
soho-sup-poe-over-yell	Parameter type: <Alarm::OntPoEY> (yes no) Possible values: - yes : ont poe is nearing its maximum ability to supply the power - no : ont poe is not nearing its maximum ability to supply the power	SOHO ONT - specifies ont poe is nearing its maximum ability to supply power <i>This element is only shown in detail mode.</i>
soho-opti-malfunc	Parameter type: <Alarm::OntTransMal> (yes no) Possible values: - yes : ONT detects the malfunction of its optical transceiver - no : ONT not detects the malfunction of its optical transceiver	ONT detects the malfunction of its optical transceiver <i>This element is only shown in detail mode.</i>
soho-sup-cfg-dnld-fail	Parameter type: <Alarm::OntCfgDld> (yes no) Possible values: - yes : ont poe exceed max occurred - no : no ont poe exceed max	SOHO ONT - Download of voice xml file to ONT failed <i>This element is only shown in detail mode.</i>
soho-sup-ld-cfg-mism	Parameter type: <Alarm::OntLoopDetectMis> (yes no) Possible values: - yes : ont loop detect mismatch occurred - no : no ont loop detect mismatch	SOHO ONT - Loop detection configuration mismatch <i>This element is only shown in detail mode.</i>
soho-sup-rssi-cfg-mism	Parameter type: <Alarm::OntRssiMismatch> (yes no) Possible values: - yes : ont dose not support rssi feature - no : ont supports rssi feature	SOHO ONT - RSSI configuration mismatch <i>This element is only shown in detail mode.</i>
soho-sup-sfp-tx-low	Parameter type: <Alarm::OntTxPwrAlrmLow> (yes no) Possible values: - yes : tx pwr at ont side is too low - no : tx pwr at ont side is normal	SOHO ONT - SFP Tx Power below configured low-level alarm threshold <i>This element is only shown in detail mode.</i>
soho-sup-sfp-temp-high	Parameter type: <Alarm::OntTempAlrmHigh> (yes no) Possible values: - yes : temperature at ont side is too high - no : temperature at ont side is normal	SOHO ONT - SFP Temperature above configured high-level alarm threshold <i>This element is only shown in detail mode.</i>
soho-sup-sfp-volt-high	Parameter type: <Alarm::OntVoltAlrmHigh> (yes no) Possible values: - yes : voltage at ont side is too high - no : voltage at ont side is normal	SOHO ONT - SFP Voltage above configured high-level alarm threshold <i>This element is only shown in detail mode.</i>
soho-sup-sfp-bias-high	Parameter type: <Alarm::OntBiasAlrmHigh> (yes no) Possible values:	SOHO ONT - SFP Bias above configured high-level alarm threshold <i>This element is only shown in</i>

104 Current Alarm Status Commands

name	Type	Description
	- yes : bias at ont side is too high - no : bias at ont side is normal	<i>detail mode.</i>
soho-sup-olt-rx-high	Parameter type: <Alarm::OltRxPwrAlrmH> (yes no) Possible values: - yes : rx power at olt side is too high - no : rx power at olt side is normal	SOHO ONT - OLT Rx power above receiver operating range <i>This element is only shown in detail mode.</i>
soho-sup-olt-rx-hi-war	Parameter type: <Alarm::OltRxPwrWarnH> (yes no) Possible values: - yes : rx power at olt side is warn high - no : rx power at olt side is normal	SOHO ONT - OLT Rx power above high-level warning threshold <i>This element is only shown in detail mode.</i>
soho-sup-olt-rx-lo-war	Parameter type: <Alarm::OltRxPwrWarnL> (yes no) Possible values: - yes : rx power at olt side is warn low - no : rx power at olt side is normal	SOHO ONT - OLT Rx power below low-level warning threshold <i>This element is only shown in detail mode.</i>
soho-sup-olt-rx-low	Parameter type: <Alarm::OltRxPwrAlrmL> (yes no) Possible values: - yes : rx power at olt side is too low - no : rx power at olt side is normal	SOHO ONT - OLT Rx power below receiver operating range <i>This element is only shown in detail mode.</i>
soho-sup-tod-out-sync	Parameter type: <Alarm::TODOUTSYNC> (yes no) Possible values: - yes : tod is out-sync with olt - no : tod is sync with olt	SOHO ONT - ONU TOD is out-sync with OLT <i>This element is only shown in detail mode.</i>
soho-sup-ont-tune-fail	Parameter type: <Alarm::TUNEFAIL> (yes no) Possible values: - yes : Ont has failed to tune to Target-ChnlPair - no : Ont is to tune to Target-ChnlPair	SOHO ONT - ONU has failed to tune to Target-ChnlPair <i>This element is only shown in detail mode.</i>
soho-tr069-param-fail	Parameter type: <Alarm::HGUTR69FAIL> (yes no) Possible values: - yes : hgu tr069 parameters mismatch - no : hgu tr069 parameters not mismatch	SOHO ONT - hgu tr069 parameters mismatch <i>This element is only shown in detail mode.</i>
soho-sup-tod-mismatch	Parameter type: <Alarm::TODMISMATCH> (yes no) Possible values: - yes : tod is mismatch - no : tod is ok	SOHO ONT - ONU TOD MISMATCH <i>This element is only shown in detail mode.</i>

104.96 MDU ONT General Supplemental Current Alarm Status Command

Command Description

This command displays the MDU ONT general supplemental current alarm status.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

> show alarm current mdu-sup [(index)]

Command Parameters

Table 104.96-1 "MDU ONT General Supplemental Current Alarm Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm type

Command Output

Table 104.96-2 "MDU ONT General Supplemental Current Alarm Status Command" Display parameters

Specific Information		
name	Type	Description
ont	Parameter type: <Gpon::OntIndex> (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> ng2 : <Ng2::ChannelGroup> / <Ng2::SubchannelGroup> / <Ng2::OntId>) Possible values: - ng2 : ngpon2 style identification Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId>	identifies the ont entry <i>This element is only shown in detail mode.</i>

104 Current Alarm Status Commands

name	Type	Description
	- the PON identifier - Field type <Ng2::ChannelGroup> - channel group number - Field type <Ng2::SubchannelGroup> - subchannel group number - Field type <Eqpt::OntId> - the ONT identifier - Field type <Ng2::OntId> - the ONT identifier	

Only Show Details: current alarm status		
name	Type	Description
mdu-sup-sw-file-error	Parameter type: <Alarm::ONTGENERALSUPPLEMENTALSWDLFILE> (yes no) Possible values: - yes : ont sw download file missing - no : ont works properly	MDU ONT - Software file has error or is missing <i>This element is only shown in detail mode.</i>
mdu-sup-fan-failure	Parameter type: <Alarm::ONTGENERALSUPPLEMENTALFANALM> (yes no) Possible values: - yes : ont fan failure - no : ont works properly	MDU ONT - Fan failure <i>This element is only shown in detail mode.</i>
mdu-sup-temp-high-warn	Parameter type: <Alarm::ONTGENERALSUPPLEMENTALHITEMPWARN> (yes no) Possible values: - yes : high temperature warning - no : ont works properly	MDU ONT - High temperature warning <i>This element is only shown in detail mode.</i>
mdu-sup-temp-shutoff	Parameter type: <Alarm::ONTGENERALSUPPLEMENTALHITEMPSHUTOFF> (yes no) Possible values: - yes : high temperature shutoff - no : ont works properly	MDU ONT - Service disabled due to excessive temperature <i>This element is only shown in detail mode.</i>
mdu-sup-emergency-call	Parameter type: <Alarm::ONTGENERALSUPPLEMENTALECALLACT> (yes no) Possible values: - yes : ont emergency call - no : ont works properly	MDU ONT - Emergency call active <i>This element is only shown in detail mode.</i>
mdu-sup-swverctrl-err	Parameter type: <Alarm::ONTGENERALSUPPLEMENTALSWVERCTRLERR> (yes no) Possible values: - yes : ont sw version control error - no : ont works properly	MDU ONT - Software version control error <i>This element is only shown in detail mode.</i>
mdu-sup-poe-exceed-max	Parameter type: <Alarm::OntPoE> (yes no) Possible values:	MDU ONT - Configured PoE feeding exceeds ONT maximum <i>This element is only shown in detail mode.</i>

name	Type	Description
	- yes : ont poe exceed max occurred - no : no ont poe exceed max	
mdu-sup-poe-over-yell	Parameter type: <Alarm::OntPoEY> (yes no) Possible values: - yes : ont poe is nearing its maximum ability to supply the power - no : ont poe is not nearing its maximum ability to supply the power	MDU ONT - specifies ont poe is nearing its maximum ability to supply power <i>This element is only shown in detail mode.</i>
mdu-opti-malfunc	Parameter type: <Alarm::OntTransMal> (yes no) Possible values: - yes : ONT detects the malfunction of its optical transceiver - no : ONT not detects the malfunction of its optical transceiver	ONT detects the malfunction of its optical transceiver <i>This element is only shown in detail mode.</i>
mdu-sup-cfg-dnld-fail	Parameter type: <Alarm::OntCfgDld> (yes no) Possible values: - yes : ont poe exceed max occurred - no : no ont poe exceed max	MDU ONT - Download of voice xml file to ONT failed <i>This element is only shown in detail mode.</i>
mdu-sup-ld-cfg-mism	Parameter type: <Alarm::OntLoopDetectMis> (yes no) Possible values: - yes : ont loop detect mismatch occurred - no : no ont loop detect mismatch	MDU ONT - Loop detection configuration mismatch <i>This element is only shown in detail mode.</i>
mdu-sup-rssi-cfg-mism	Parameter type: <Alarm::OntRssiMismatch> (yes no) Possible values: - yes : ont dose not support rssi feature - no : ont supports rssi feature	MDU ONT - RSSI configuration mismatch <i>This element is only shown in detail mode.</i>
mdu-sup-sfp-tx-low	Parameter type: <Alarm::OntTxPwrAlrmLow> (yes no) Possible values: - yes : tx pwr at ont side is too low - no : tx pwr at ont side is normal	MDU ONT - SFP Tx Power below configured low-level alarm threshold <i>This element is only shown in detail mode.</i>
mdu-sup-sfp-temp-high	Parameter type: <Alarm::OntTempAlrmHigh> (yes no) Possible values: - yes : temperature at ont side is too high - no : temperature at ont side is normal	MDU ONT - SFP Temperature above configured high-level alarm threshold <i>This element is only shown in detail mode.</i>
mdu-sup-sfp-volt-high	Parameter type: <Alarm::OntVoltAlrmHigh> (yes no) Possible values: - yes : voltage at ont side is too high - no : voltage at ont side is normal	MDU ONT - SFP Voltage above configured high-level alarm threshold <i>This element is only shown in detail mode.</i>
mdu-sup-sfp-bias-high	Parameter type: <Alarm::OntBiasAlrmHigh> (yes no) Possible values:	MDU ONT - SFP Bias above configured high-level alarm threshold <i>This element is only shown in</i>

104 Current Alarm Status Commands

name	Type	Description
	- yes : bias at ont side is too high - no : bias at ont side is normal	<i>detail mode.</i>
mdu-sup-olt-rx-high	Parameter type: <Alarm::OltRxPwrAlrmH> (yes no) Possible values: - yes : rx power at olt side is too high - no : rx power at olt side is normal	MDU ONT - OLT Rx power above receiver operating range <i>This element is only shown in detail mode.</i>
mdu-sup-olt-rx-hi-warn	Parameter type: <Alarm::OltRxPwrWarnH> (yes no) Possible values: - yes : rx power at olt side is warn high - no : rx power at olt side is normal	MDU ONT - OLT Rx power above high-level warning threshold <i>This element is only shown in detail mode.</i>
mdu-sup-olt-rx-lo-warn	Parameter type: <Alarm::OltRxPwrWarnL> (yes no) Possible values: - yes : rx power at olt side is warn low - no : rx power at olt side is normal	MDU ONT - OLT Rx power below low-level warning threshold <i>This element is only shown in detail mode.</i>
mdu-sup-olt-rx-low	Parameter type: <Alarm::OltRxPwrAlrmL> (yes no) Possible values: - yes : rx power at olt side is too low - no : rx power at olt side is normal	MDU ONT - OLT Rx power below receiver operating range <i>This element is only shown in detail mode.</i>
mdu-sup-tod-out-sync	Parameter type: <Alarm::TODOUTSYNC> (yes no) Possible values: - yes : tod is out-sync with olt - no : tod is sync with olt	MDU ONT - ONU TOD is out-sync with OLT <i>This element is only shown in detail mode.</i>
mdu-sup-ont-tune-fail	Parameter type: <Alarm::TUNEFAIL> (yes no) Possible values: - yes : Ont has failed to tune to Target-ChnlPair - no : Ont is to tune to Target-ChnlPair	MDU ONT - ONU has failed to tune to Target-ChnlPair <i>This element is only shown in detail mode.</i>
mdu-tr069-param-fail	Parameter type: <Alarm::HGUTR69FAIL> (yes no) Possible values: - yes : hgu tr069 parameters mismatch - no : hgu tr069 parameters not mismatch	MDU ONT - hgu tr069 parameters mismatch <i>This element is only shown in detail mode.</i>
mdu-sup-tod-mismatch	Parameter type: <Alarm::TODMISMATCH> (yes no) Possible values: - yes : tod is mismatch - no : tod is ok	MDU ONT - ONU TOD MISMATCH <i>This element is only shown in detail mode.</i>

104.97 ONT General Supplemental 2 Current Alarm Status Command

Command Description

This command displays the ONT general supplemental 2 current alarm status.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm current ont-ani [ (index) ]
```

Command Parameters

Table 104.97-1 "ONT General Supplemental 2 Current Alarm Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm type

Command Output

Table 104.97-2 "ONT General Supplemental 2 Current Alarm Status Command" Display parameters

Specific Information		
name	Type	Description
ont	Parameter type: <Gpon::OntIndex> (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> ng2 : <Ng2::ChannelGroup> / <Ng2::SubchannelGroup> / <Ng2::OntId>) Possible values: - ng2 : ngpon2 style identification Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId>	identifies the ont entry <i>This element is only shown in detail mode.</i>

104 Current Alarm Status Commands

name	Type	Description
	- the PON identifier Field type <Ng2::ChannelGroup> - channel group number Field type <Ng2::SubchannelGroup> - subchannel group number Field type <Eqpt::OntId> - the ONT identifier Field type <Ng2::OntId> - the ONT identifier	

Only Show Details: current alarm status		
name	Type	Description
temp-alm-low	Parameter type: <Alarm::OntTempAlrmLow> (yes no) Possible values: - yes : temp at ont side is too low - no : temp at ont side is normal	temp alarm low status <i>This element is only shown in detail mode.</i>
volt-alm-low	Parameter type: <Alarm::OntVoltAlrmLow> (yes no) Possible values: - yes : voltage at ont side is too low - no : voltage at ont side is normal	voltage alarm low status <i>This element is only shown in detail mode.</i>
bias-alm-low	Parameter type: <Alarm::OntBiasAlrmLow> (yes no) Possible values: - yes : bias at ont side is too low - no : bias at ont side is normal	bias alarm low status <i>This element is only shown in detail mode.</i>
tx-pwr-alm-high	Parameter type: <Alarm::OntTxPwrAlrmHigh> (yes no) Possible values: - yes : tx power at ont side is too high - no : tx power at ont side is normal	tx pwr high alarm status <i>This element is only shown in detail mode.</i>
rx-pwr-warn-high	Parameter type: <Alarm::OntRxPwrWarnHigh> (yes no) Possible values: - yes : rx power at ont side is too high - no : rx power at ont side is normal	rx pwr warning high status <i>This element is only shown in detail mode.</i>
rx-pwr-warn-low	Parameter type: <Alarm::OntRxPwrWarnLow> (yes no) Possible values: - yes : rx power at ont side is too low - no : rx power at ont side is normal	rx pwr warning high status <i>This element is only shown in detail mode.</i>
tx-pwr-warn-high	Parameter type: <Alarm::OntTxPwrWarnHigh> (yes no) Possible values: - yes : tx power at ont side is too high - no : tx power at ont side is normal	tx pwr warning high status <i>This element is only shown in detail mode.</i>
tx-pwr-warn-low	Parameter type: <Alarm::OntTxPwrWarnLow> (yes no) Possible values:	tx pwr warning low status <i>This element is only shown in detail mode.</i>

name	Type	Description
	- yes : tx power at ont side is too low - no : tx power at ont side is normal	
temp-warn-high	Parameter type: <Alarm::OntTempWarnHigh> (yes no) Possible values: - yes : temp at ont side is too high - no : temp at ont side is normal	temp warning high status <i>This element is only shown in detail mode.</i>
temp-warn-low	Parameter type: <Alarm::OntTempWarnLow> (yes no) Possible values: - yes : temp at ont side is too low - no : temp at ont side is normal	temp warning low status <i>This element is only shown in detail mode.</i>
volt-warn-high	Parameter type: <Alarm::OntVoltWarnHigh> (yes no) Possible values: - yes : voltage at ont side is too high - no : voltage at ont side is normal	voltage warning high status <i>This element is only shown in detail mode.</i>
volt-warn-low	Parameter type: <Alarm::OntVoltWarnLow> (yes no) Possible values: - yes : voltage at ont side is too low - no : voltage at ont side is normal	voltage warning low status <i>This element is only shown in detail mode.</i>
bias-warn-high	Parameter type: <Alarm::OntBiasWarnHigh> (yes no) Possible values: - yes : bias at ont side is too high - no : bias at ont side is normal	bias warning high status <i>This element is only shown in detail mode.</i>
bias-warn-low	Parameter type: <Alarm::OntBiasWarnLow> (yes no) Possible values: - yes : bias at ont side is too low - no : bias at ont side is normal	bias warning low status <i>This element is only shown in detail mode.</i>

104.98 SFU ONT General Supplemental 2 Current Alarm Status Command

Command Description

This command displays the SFU ONT general supplemental 2 current alarm status.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm current sfu-sup2 [ (index) ]
```

Command Parameters

Table 104.98-1 "SFU ONT General Supplemental 2 Current Alarm Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm type

Command Output

Table 104.98-2 "SFU ONT General Supplemental 2 Current Alarm Status Command" Display parameters

Specific Information		
name	Type	Description
ont	Parameter type: <Gpon::OntIndex> (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> ng2 : <Ng2::ChannelGroup> / <Ng2::SubchannelGroup> / <Ng2::OntId>) Possible values: - ng2 : ngpon2 style identification Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId>	identifies the ont entry <i>This element is only shown in detail mode.</i>

name	Type	Description
	- the PON identifier Field type <Ng2::ChannelGroup> - channel group number Field type <Ng2::SubchannelGroup> - subchannel group number Field type <Eqpt::OntId> - the ONT identifier Field type <Ng2::OntId> - the ONT identifier	

Only Show Details: current alarm status		
name	Type	Description
sfu-sup2-temp-low	Parameter type: <Alarm::OntTempAlrmLow> (yes no) Possible values: - yes : temp at ont side is too low - no : temp at ont side is normal	SFU ONT - SFP Temperature is higher than configured alarm high threshold <i>This element is only shown in detail mode.</i>
sfu-sup2-volt-low	Parameter type: <Alarm::OntVoltAlrmLow> (yes no) Possible values: - yes : voltage at ont side is too low - no : voltage at ont side is normal	SFU ONT - SFP Voltage is higher than configured alarm high threshold <i>This element is only shown in detail mode.</i>
sfu-sup2-bias-low	Parameter type: <Alarm::OntBiasAlrmLow> (yes no) Possible values: - yes : bias at ont side is too low - no : bias at ont side is normal	SFU ONT - SFP Bias is lower than configured alarm low threshold <i>This element is only shown in detail mode.</i>
sfu-sup2-tx-high	Parameter type: <Alarm::OntTxPwrAlrmHigh> (yes no) Possible values: - yes : tx power at ont side is too high - no : tx power at ont side is normal	SFU ONT - SFP tx power is higher than configured alarm high threshold <i>This element is only shown in detail mode.</i>
sfu-sup2-rx-hwarn	Parameter type: <Alarm::OntRxPwrWarnHigh> (yes no) Possible values: - yes : rx power at ont side is too high - no : rx power at ont side is normal	SFU ONT - SFP Rx power is higher than configured warn threshold <i>This element is only shown in detail mode.</i>
sfu-sup2-rx-lwarn	Parameter type: <Alarm::OntRxPwrWarnLow> (yes no) Possible values: - yes : rx power at ont side is too low - no : rx power at ont side is normal	SFU ONT - SFP Rx power is lower than configured warn threshold <i>This element is only shown in detail mode.</i>
sfu-sup2-tx-hwarn	Parameter type: <Alarm::OntTxPwrWarnHigh> (yes no) Possible values: - yes : tx power at ont side is too high - no : tx power at ont side is normal	SFU ONT - SFP Tx power is higher than configured warn threshold <i>This element is only shown in detail mode.</i>
sfu-sup2-tx-lwarn	Parameter type: <Alarm::OntTxPwrWarnLow> (yes no) Possible values:	SFU ONT - SFP Tx power is lower than configured warn threshold <i>This element is only shown in</i>

104 Current Alarm Status Commands

name	Type	Description
	- yes : tx power at ont side is too low - no : tx power at ont side is normal	<i>detail mode.</i>
sfu-sup2-temp-hwarn	Parameter type: <Alarm::OntTempWarnHigh> (yes no) Possible values: - yes : temp at ont side is too high - no : temp at ont side is normal	SFU ONT - SFP temperature is higher than configured warn threshold <i>This element is only shown in detail mode.</i>
sfu-sup2-temp-lwarn	Parameter type: <Alarm::OntTempWarnLow> (yes no) Possible values: - yes : temp at ont side is too low - no : temp at ont side is normal	SFU ONT - SFP temperature is lower than configured warn threshold <i>This element is only shown in detail mode.</i>
sfu-sup2-volt-hwarn	Parameter type: <Alarm::OntVoltWarnHigh> (yes no) Possible values: - yes : voltage at ont side is too high - no : voltage at ont side is normal	SFU ONT - SFP voltage is higher than configured warn threshold <i>This element is only shown in detail mode.</i>
sfu-sup2-volt-lwarn	Parameter type: <Alarm::OntVoltWarnLow> (yes no) Possible values: - yes : voltage at ont side is too low - no : voltage at ont side is normal	SFU ONT - SFP voltage is lower than configured warn threshold <i>This element is only shown in detail mode.</i>
sfu-sup2-bias-hwarn	Parameter type: <Alarm::OntBiasWarnHigh> (yes no) Possible values: - yes : bias at ont side is too high - no : bias at ont side is normal	SFU ONT - SFP bias is higher than configured warn threshold <i>This element is only shown in detail mode.</i>
sfu-sup2-bias-lwarn	Parameter type: <Alarm::OntBiasWarnLow> (yes no) Possible values: - yes : bias at ont side is too low - no : bias at ont side is normal	SFU ONT - SFP bias is lower than configured warn threshold <i>This element is only shown in detail mode.</i>

104.99 SOHO ONT General Supplemental 2 Current Alarm Status Command

Command Description

This command displays the SOHO ONT general supplemental 2 current alarm status.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm current soho-sup2 [ (index) ]
```

Command Parameters

Table 104.99-1 "SOHO ONT General Supplemental 2 Current Alarm Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm type

Command Output

Table 104.99-2 "SOHO ONT General Supplemental 2 Current Alarm Status Command" Display parameters

Specific Information		
name	Type	Description
ont	Parameter type: <Gpon::OntIndex> (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> ng2 : <Ng2::ChannelGroup> / <Ng2::SubchannelGroup> / <Ng2::OntId>) Possible values: - ng2 : ngpon2 style identification Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId>	identifies the ont entry <i>This element is only shown in detail mode.</i>

104 Current Alarm Status Commands

name	Type	Description
	- the PON identifier Field type <Ng2::ChannelGroup> - channel group number Field type <Ng2::SubchannelGroup> - subchannel group number Field type <Eqpt::OntId> - the ONT identifier Field type <Ng2::OntId> - the ONT identifier	

Only Show Details: current alarm status		
name	Type	Description
soho-sup2-temp-low	Parameter type: <Alarm::OntTempAlrmLow> (yes no) Possible values: - yes : temp at ont side is too low - no : temp at ont side is normal	SOHO ONT - SFP Temperature is higher than configured alarm high threshold <i>This element is only shown in detail mode.</i>
soho-sup2-volt-low	Parameter type: <Alarm::OntVoltAlrmLow> (yes no) Possible values: - yes : voltage at ont side is too low - no : voltage at ont side is normal	SOHO ONT - SFP Voltage is higher than configured alarm high threshold <i>This element is only shown in detail mode.</i>
soho-sup2-bias-low	Parameter type: <Alarm::OntBiasAlrmLow> (yes no) Possible values: - yes : bias at ont side is too low - no : bias at ont side is normal	SOHO ONT - SFP Bias is lower than configured alarm low threshold <i>This element is only shown in detail mode.</i>
soho-sup2-tx-high	Parameter type: <Alarm::OntTxPwrAlrmHigh> (yes no) Possible values: - yes : tx power at ont side is too high - no : tx power at ont side is normal	SOHO ONT - SFP tx power is higher than configured alarm high threshold <i>This element is only shown in detail mode.</i>
soho-sup2-rx-hwarn	Parameter type: <Alarm::OntRxPwrWarnHigh> (yes no) Possible values: - yes : rx power at ont side is too high - no : rx power at ont side is normal	SOHO ONT - SFP Rx power is higher than configured warn threshold <i>This element is only shown in detail mode.</i>
soho-sup2-rx-lwarn	Parameter type: <Alarm::OntRxPwrWarnLow> (yes no) Possible values: - yes : rx power at ont side is too low - no : rx power at ont side is normal	SOHO ONT - SFP Rx power is lower than configured warn threshold <i>This element is only shown in detail mode.</i>
soho-sup2-tx-hwarn	Parameter type: <Alarm::OntTxPwrWarnHigh> (yes no) Possible values: - yes : tx power at ont side is too high - no : tx power at ont side is normal	SOHO ONT - SFP Tx power is higher than configured warn threshold <i>This element is only shown in detail mode.</i>
soho-sup2-tx-lwarn	Parameter type: <Alarm::OntTxPwrWarnLow> (yes no) Possible values:	SOHO ONT - SFP Tx power is lower than configured warn threshold <i>This element is only shown in detail mode.</i>

name	Type	Description
	- yes : tx power at ont side is too low - no : tx power at ont side is normal	<i>detail mode.</i>
soho-sup2-temp-hwarn	Parameter type: <Alarm::OntTempWarnHigh> (yes no) Possible values: - yes : temp at ont side is too high - no : temp at ont side is normal	SOHO ONT - SFP temperature is higher than configured warn threshold <i>This element is only shown in detail mode.</i>
soho-sup2-temp-lwarn	Parameter type: <Alarm::OntTempWarnLow> (yes no) Possible values: - yes : temp at ont side is too low - no : temp at ont side is normal	SOHO ONT - SFP temperature is lower than configured warn threshold <i>This element is only shown in detail mode.</i>
soho-sup2-volt-hwarn	Parameter type: <Alarm::OntVoltWarnHigh> (yes no) Possible values: - yes : voltage at ont side is too high - no : voltage at ont side is normal	SOHO ONT - SFP voltage is higher than configured warn threshold <i>This element is only shown in detail mode.</i>
soho-sup2-volt-lwarn	Parameter type: <Alarm::OntVoltWarnLow> (yes no) Possible values: - yes : voltage at ont side is too low - no : voltage at ont side is normal	SOHO ONT - SFP voltage is lower than configured warn threshold <i>This element is only shown in detail mode.</i>
soho-sup2-bias-hwarn	Parameter type: <Alarm::OntBiasWarnHigh> (yes no) Possible values: - yes : bias at ont side is too high - no : bias at ont side is normal	SOHO ONT - SFP bias is higher than configured warn threshold <i>This element is only shown in detail mode.</i>
soho-sup2-bias-lwarn	Parameter type: <Alarm::OntBiasWarnLow> (yes no) Possible values: - yes : bias at ont side is too low - no : bias at ont side is normal	SOHO ONT - SFP bias is lower than configured warn threshold <i>This element is only shown in detail mode.</i>

104.100 MDU ONT General Supplemental 2 Current Alarm Status Command

Command Description

This command displays the MDU ONT general supplemental 2 current alarm status.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm current mdu-sup2 [ (index) ]
```

Command Parameters

Table 104.100-1 "MDU ONT General Supplemental 2 Current Alarm Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm type

Command Output

Table 104.100-2 "MDU ONT General Supplemental 2 Current Alarm Status Command" Display parameters

Specific Information		
name	Type	Description
ont	Parameter type: <Gpon::OntIndex> (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> ng2 : <Ng2::ChannelGroup> / <Ng2::SubchannelGroup> / <Ng2::OntId>) Possible values: - ng2 : ngpon2 style identification Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId>	identifies the ont entry <i>This element is only shown in detail mode.</i>

name	Type	Description
	- the PON identifier Field type <Ng2::ChannelGroup> - channel group number Field type <Ng2::SubchannelGroup> - subchannel group number Field type <Eqpt::OntId> - the ONT identifier Field type <Ng2::OntId> - the ONT identifier	

Only Show Details: current alarm status		
name	Type	Description
mdu-sup2-temp-low	Parameter type: <Alarm::OntTempAlrmLow> (yes no) Possible values: - yes : temp at ont side is too low - no : temp at ont side is normal	MDU ONT - SFP Temperature is higher than configured alarm high threshold <i>This element is only shown in detail mode.</i>
mdu-sup2-volt-low	Parameter type: <Alarm::OntVoltAlrmLow> (yes no) Possible values: - yes : voltage at ont side is too low - no : voltage at ont side is normal	MDU ONT - SFP Voltage is higher than configured alarm high threshold <i>This element is only shown in detail mode.</i>
mdu-sup2-bias-low	Parameter type: <Alarm::OntBiasAlrmLow> (yes no) Possible values: - yes : bias at ont side is too low - no : bias at ont side is normal	MDU ONT - SFP Bias is lower than configured alarm low threshold <i>This element is only shown in detail mode.</i>
mdu-sup2-tx-high	Parameter type: <Alarm::OntTxPwrAlrmHigh> (yes no) Possible values: - yes : tx power at ont side is too high - no : tx power at ont side is normal	MDU ONT - SFP tx power is higher than configured alarm high threshold <i>This element is only shown in detail mode.</i>
mdu-sup2-rx-hwarn	Parameter type: <Alarm::OntRxPwrWarnHigh> (yes no) Possible values: - yes : rx power at ont side is too high - no : rx power at ont side is normal	MDU ONT - SFP Rx power is higher than configured warn threshold <i>This element is only shown in detail mode.</i>
mdu-sup2-rx-lwarn	Parameter type: <Alarm::OntRxPwrWarnLow> (yes no) Possible values: - yes : rx power at ont side is too low - no : rx power at ont side is normal	MDU ONT - SFP Rx power is lower than configured warn threshold <i>This element is only shown in detail mode.</i>
mdu-sup2-tx-hwarn	Parameter type: <Alarm::OntTxPwrWarnHigh> (yes no) Possible values: - yes : tx power at ont side is too high - no : tx power at ont side is normal	MDU ONT - SFP Tx power is higher than configured warn threshold <i>This element is only shown in detail mode.</i>
mdu-sup2-tx-lwarn	Parameter type: <Alarm::OntTxPwrWarnLow> (yes no) Possible values:	MDU ONT - SFP Tx power is lower than configured warn threshold <i>This element is only shown in</i>

104 Current Alarm Status Commands

name	Type	Description
	- yes : tx power at ont side is too low - no : tx power at ont side is normal	<i>detail mode.</i>
mdu-sup2-temp-hwarn	Parameter type: <Alarm::OntTempWarnHigh> (yes no) Possible values: - yes : temp at ont side is too high - no : temp at ont side is normal	MDU ONT - SFP temperature is higher than configured warn threshold <i>This element is only shown in detail mode.</i>
mdu-sup2-temp-lwarn	Parameter type: <Alarm::OntTempWarnLow> (yes no) Possible values: - yes : temp at ont side is too low - no : temp at ont side is normal	MDU ONT - SFP temperature is lower than configured warn threshold <i>This element is only shown in detail mode.</i>
mdu-sup2-volt-hwarn	Parameter type: <Alarm::OntVoltWarnHigh> (yes no) Possible values: - yes : voltage at ont side is too high - no : voltage at ont side is normal	MDU ONT - SFP voltage is higher than configured warn threshold <i>This element is only shown in detail mode.</i>
mdu-sup2-volt-lwarn	Parameter type: <Alarm::OntVoltWarnLow> (yes no) Possible values: - yes : voltage at ont side is too low - no : voltage at ont side is normal	MDU ONT - SFP voltage is lower than configured warn threshold <i>This element is only shown in detail mode.</i>
mdu-sup2-bias-hwarn	Parameter type: <Alarm::OntBiasWarnHigh> (yes no) Possible values: - yes : bias at ont side is too high - no : bias at ont side is normal	MDU ONT - SFP bias is higher than configured warn threshold <i>This element is only shown in detail mode.</i>
mdu-sup2-bias-lwarn	Parameter type: <Alarm::OntBiasWarnLow> (yes no) Possible values: - yes : bias at ont side is too low - no : bias at ont side is normal	MDU ONT - SFP bias is lower than configured warn threshold <i>This element is only shown in detail mode.</i>

104.101 Ellid Alarm Status Command

Command Description

This command displays the ellid current alarm status.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

> show alarm current ellid [(alarm-index)]

Command Parameters

Table 104.101-1 "Ellid Alarm Status Command" Resource Parameters

Resource Identifier	Type	Description
(alarm-index)	Format: - index of a current alarm entry	alarm type

Command Output

Table 104.101-2 "Ellid Alarm Status Command" Display parameters

Specific Information		
name	Type	Description
last-updated-on	Parameter type: <Sys::timeInSecs> - the time (yyyy-mm-dd:hour:minutes:secs) - unit: UTC	network time in seconds when the alarm was logged. <i>This element is only shown in detail mode.</i>
ellid-index	Parameter type: <Itf::ComplexPortType> (xdsl-line : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> voicefxs : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> xdsl-channel : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> atm-if : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> atm-pvc : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::VpiId> : <Eqpt::VciId> bridge-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::VpiId> : <Eqpt::VciId>	identifies the ellid where the alarm has occurred. <i>This element is only shown in detail mode.</i>

name	Type	Description
	<pre> vlan-port:ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / <Eqpt::Ng2OntSlotId> / <Eqpt::Ng2OntPortId> : <Eqpt::UnstackedVlan> l2-vlan : <Eqpt::VlanId> ip : <Eqpt::LogicalId> sw-loopback slip uni:ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / <Eqpt::Ng2OntSlotId> / <Eqpt::Ng2OntPortId> vlan-port:ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / <Eqpt::Ng2OntSlotId> / <Eqpt::Ng2OntPortId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> atm-bonding : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> bonding : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> ip-gateway : <Eqpt::VrfId> ip-line : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::VpiId> : <Eqpt::VciId> ip-line : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> shdsl-line : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> e1-line : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> atm-ima : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> ethernet-line : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> bridge-port:ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / vuni vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::VpiId> : <Eqpt::VciId> : <Eqpt::UnstackedVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::UnstackedVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::VpiId> : <Eqpt::VciId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> voip:ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> ip-line : vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::VpiId> : <Eqpt::VciId> : <Eqpt::UnstackedVlan> ip-line : vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::UnstackedVlan> ip-line : vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::VpiId> : <Eqpt::VciId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> ip-line : vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : stacked : <Eqpt::SVlan> : </pre>	

name	Type	Description
	<pre> <Eqpt::CVlan> vlan-port:ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / vuni : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan-port:ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / vuni : <Eqpt::UnstackedVlan> chgroup : <Eqpt::ChannelGroupId> subchgroup : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> bridge-port:ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / <Eqpt::Ng2OntSlotId> / <Eqpt::Ng2OntPortId> atm-pvc : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> bridge-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> bridge-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> / <Eqpt::OntPortId> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> / <Eqpt::OntPortId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> / <Eqpt::OntPortId> : <Eqpt::UnstackedVlan> pon : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> ont : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> uni : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> / <Eqpt::OntPortId> bridge-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / voip bridge-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / vuni vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / voip : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / vuni : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / voip : <Eqpt::UnstackedVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / vuni : <Eqpt::UnstackedVlan> voip : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> la-group : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / </pre>	

name	Type	Description
	<pre> <Eqpt::LLId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> bridge-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::LLId> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::LLId> : <Eqpt::UnstackedVlan> mpm : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::ComboPonId> x-pon : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::XPonId> 25g-pon : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::M25GPonId> dist-router-interface : slot-stacked : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::SVlan> : <Eqpt::CVlan> dist-router-interface : slot-vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::UnstackedVlan> bundle : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::BundleId> chpair : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::ChannelPairId> ont.ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId>) Possible values: - xdsl-line : a static xdsl line interface - xdsl-channel : a static xdsl channel interface - atm-if : a static atm interface - atm-pvc : an atm pvc interface - bridge-port : a vlan bridge-port - bridge-port.ng2 : a ngpon2 vlan bridge-port - l2-vlan : a l2-vlan interface - ip : an ip interface - sw-loopback : a software loopback interface - slip : a slip interface - atm-bonding : atm bonding obsolete alternative replaced by bonding - bonding : bonding - ip-gateway : ip user gateway interface - ip-line : ip line interface - shdsl-line : a static shdsl line interface - e1-line : a e1 line interface - atm-ima : atm ima - ethernet-line : an ethernet line interface - vlan-port : vlan port - vlan-port.ng2 : a ngpon2 vlan port - pon : pon - x-pon : xgs pon - 25g-pon : 25g pon - chpair : channelpair - chgroup : channelgroup - subchgroup : subchannelgroup - bundle : bundle - ont : ont - ont.ng2 : ngpon2 ONT style identification - uni : uni - uni.ng2 : ngpon2 UNI style identification </pre>	

name	Type	Description
	- voip : voip - voip:ng2 : voip - la-group : link aggregation group - dist-router-interface : dist router interface - voicefxs : voicefxs - mpm : multi-pon module Possible values: - vlan : vlan port Possible values: - slot-vlan : slot unstacked - slot-stacked : slot vlan port Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number Field type <Eqpt::VpiId> - atm VPI Field type <Eqpt::VciId> - atm VCI Field type <Eqpt::PonId> - the PON identifier Field type <Eqpt::XPonId> - the XGS PON identifier Field type <Eqpt::M25GPonId> - the 25G PON identifier Field type <Eqpt::ComboPonId> - the comboPON identifier Field type <Eqpt::ChannelPairId> - the channel pair identifier Field type <Eqpt::ChannelGroupId> - the channel group identifier Field type <Eqpt::SubChannelGroupId> - the subchannel group identifier Field type <Eqpt::BundleId> - the BUNDLE identifier Field type <Eqpt::OntId> - the ONT identifier Field type <Eqpt::Ng2OntId> - the NG2 ONT identifier Possible values: - voip : virtual uni identifier obsolete alternative replaced by vuni - vuni : virtual uni identifier Possible values: - vuni : virtual NGPON2 uni identifier Field type <Eqpt::OntSlotId> - the ONT SLOT identifier Field type <Eqpt::OntPortId> - the ONT PORT identifier Field type <Eqpt::Ng2OntSlotId> - the NGPON2 ONT SLOT identifier Field type <Eqpt::Ng2OntPortId> - the NGPON2 ONT PORT identifier	

104 Current Alarm Status Commands

name	Type	Description
	Field type <Eqpt::LLId> - the LLID identifier, range 1 for EPON, range 1-8 for DPOE Possible values: - stacked : stacked vlan identity Field type <Eqpt::UnstackedVlan> - unstacked vlan id Field type <Eqpt::SVlan> - service vlan id Field type <Eqpt::CVlan> - customer vlan id Field type <Eqpt::VlanId> - VLAN id Field type <Eqpt::LogicalId> - logical id Field type <Eqpt::VrflId> - VRF id	

Only Show Details: ellid alarms		
name	Type	Description
key-fail-one-churn	Parameter type: <alarm::keyfailone> (yes no) Possible values: - yes : key exchange failure during one churning time - no : key exchange failure during one churning time is ok	key exchange failure during one churning time <i>This element is only shown in detail mode.</i>
key-fail-three-churn	Parameter type: <alarm::keyfailthree> (yes no) Possible values: - yes : key exchange failure during three churning time - no : key exchange failure during three churning time is ok	key exchange failure during three churning time <i>This element is only shown in detail mode.</i>
oam-discov-fail	Parameter type: <alarm::oamext> (yes no) Possible values: - yes : extend oam discovery failure - no : extend oam discovery failure is ok	extend oam discovery failure <i>This element is only shown in detail mode.</i>
report-timeout	Parameter type: <alarm::timeout> (yes no) Possible values: - yes : report timeout detecting - no : report timeout detecting is ok	report timeout detecting <i>This element is only shown in detail mode.</i>
total-packets-exceed	Parameter type: <alarm::totalexceed> (yes no) Possible values: - yes : total amount of protocol packets exceed threshold - no : total amount of protocol packets is ok	total amount of protocol packets exceed threshold <i>This element is only shown in detail mode.</i>
arp-packets-exceed	Parameter type: <alarm::arpexceed> (yes no) Possible values: - yes : protocol arp packets exceed threshold - no : protocol arp packets is ok	protocol arp packets exceed threshold <i>This element is only shown in detail mode.</i>
dhcp-packets-exceed	Parameter type: <alarm::dhcpxceed> (yes no)	protocol dhcp packets exceed threshold <i>This element is only shown in</i>

name	Type	Description
	Possible values: - yes : protocol dhcp packets exceed threshold - no : protocol dhcp packets is ok	<i>detail mode.</i>
igmp-packets-exceed	Parameter type: <alarm::igmpexceed> (yes no) Possible values: - yes : protocol igmp packets exceed threshold - no : protocol igmp packets is ok	protocol igmp packets exceed threshold <i>This element is only shown in detail mode.</i>
pppoe-packets-exceed	Parameter type: <alarm::pppoeexceed> (yes no) Possible values: - yes : protocol pppoe packets exceed threshold - no : protocol pppoe packets is ok	protocol pppoe packets exceed threshold <i>This element is only shown in detail mode.</i>
nd-packets-exceed	Parameter type: <alarm::ndexceed> (yes no) Possible values: - yes : protocol nd packets exceed threshold - no : protocol nd packets is ok	protocol nd packets exceed threshold <i>This element is only shown in detail mode.</i>
icmpv6-packets-exceed	Parameter type: <alarm::icmpexceed> (yes no) Possible values: - yes : protocol icmp packets exceed threshold - no : protocol icmp packets is ok	protocol icmpv6 packets exceed threshold <i>This element is only shown in detail mode.</i>
mld-packets-exceed	Parameter type: <alarm::mldexceed> (yes no) Possible values: - yes : protocol igmp packets exceed threshold - no : protocol igmp packets is ok	protocol mld packets exceed threshold <i>This element is only shown in detail mode.</i>
dhcpv6-packets-exceed	Parameter type: <alarm::dhcpv6exceed> (yes no) Possible values: - yes : protocol dhcpv6 packets exceed threshold - no : protocol dhcpv6 packets is ok	protocol dhcpv6 packets exceed threshold <i>This element is only shown in detail mode.</i>
cfm-packets-exceed	Parameter type: <alarm::cfmexceed> (yes no) Possible values: - yes : protocol cfm packets exceed threshold - no : protocol cfm packets is ok	protocol cfm packets exceed threshold <i>This element is only shown in detail mode.</i>

104.102 Ima-Group Alarm Log Status Command

Command Description

This command displays the Ima-Group alarm log status.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

> show alarm current epon [(alarm-index)]

Command Parameters

Table 104.102-1 "Ima-Group Alarm Log Status Command" Resource Parameters

Resource Identifier	Type	Description
(alarm-index)	Format: - index of a current alarm entry	alarm type

Command Output

Table 104.102-2 "Ima-Group Alarm Log Status Command" Display parameters

Specific Information		
name	Type	Description
last-updated-on	Parameter type: <Sys::timeInSecs> - the time (yyyy-mm-dd:hour:minutes:secs) - unit: UTC	network time in seconds when the alarm was logged. <i>This element is only shown in detail mode.</i>
pon-index	Parameter type: <Itf::ComplexPortType> (xdsl-line : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> voicefxs : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> xdsl-channel : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> atm-if : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> atm-pvc : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::VpiId> : <Eqpt::VciId> bridge-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::VpiId> : <Eqpt::VciId>	identifies the epon where the alarm has occurred. <i>This element is only shown in detail mode.</i>

name	Type	Description
	vlan-port:ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / <Eqpt::Ng2OntSlotId> / <Eqpt::Ng2OntPortId> : <Eqpt::UnstackedVlan> l2-vlan : <Eqpt::VlanId> ip : <Eqpt::LogicalId> sw-loopback slip uni:ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / <Eqpt::Ng2OntSlotId> / <Eqpt::Ng2OntPortId> vlan-port:ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / <Eqpt::Ng2OntSlotId> / <Eqpt::Ng2OntPortId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> atm-bonding : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> bonding : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> ip-gateway : <Eqpt::VrfId> ip-line : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::VpiId> : <Eqpt::VciId> ip-line : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> shdsl-line : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> e1-line : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> atm-ima : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> ethernet-line : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> bridge-port:ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / vuni vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::VpiId> : <Eqpt::VciId> : <Eqpt::UnstackedVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::UnstackedVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::VpiId> : <Eqpt::VciId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> voip:ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> ip-line : vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::VpiId> : <Eqpt::VciId> : <Eqpt::UnstackedVlan> ip-line : vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::UnstackedVlan> ip-line : vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::VpiId> : <Eqpt::VciId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> ip-line : vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : stacked : <Eqpt::SVlan> :	

name	Type	Description
	<pre> <Eqpt::CVlan> vlan-port:ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / vuni : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan-port:ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / vuni : <Eqpt::UnstackedVlan> chgroup : <Eqpt::ChannelGroupId> subchgroup : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> bridge-port:ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / <Eqpt::Ng2OntSlotId> / <Eqpt::Ng2OntPortId> atm-pvc : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> bridge-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> bridge-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> / <Eqpt::OntPortId> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> / <Eqpt::OntPortId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> / <Eqpt::OntPortId> : <Eqpt::UnstackedVlan> pon : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> ont : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> uni : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> / <Eqpt::OntPortId> bridge-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / voip bridge-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / vuni vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / voip : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / vuni : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / voip : <Eqpt::UnstackedVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / vuni : <Eqpt::UnstackedVlan> voip : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> la-group : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / </pre>	

name	Type	Description
	<pre> <Eqpt::LLId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> bridge-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::LLId> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::LLId> : <Eqpt::UnstackedVlan> mpm : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::ComboPonId> x-pon : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::XPonId> 25g-pon : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::M25GPonId> dist-router-interface : slot-stacked : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::SVlan> : <Eqpt::CVlan> dist-router-interface : slot-vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::UnstackedVlan> bundle : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::BundleId> chpair : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::ChannelPairId> ont.ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId>) Possible values: - xdsl-line : a static xdsl line interface - xdsl-channel : a static xdsl channel interface - atm-if : a static atm interface - atm-pvc : an atm pvc interface - bridge-port : a vlan bridge-port - bridge-port.ng2 : a ngpon2 vlan bridge-port - l2-vlan : a l2-vlan interface - ip : an ip interface - sw-loopback : a software loopback interface - slip : a slip interface - atm-bonding : atm bonding obsolete alternative replaced by bonding - bonding : bonding - ip-gateway : ip user gateway interface - ip-line : ip line interface - shdsl-line : a static shdsl line interface - e1-line : a e1 line interface - atm-ima : atm ima - ethernet-line : an ethernet line interface - vlan-port : vlan port - vlan-port.ng2 : a ngpon2 vlan port - pon : pon - x-pon : xgs pon - 25g-pon : 25g pon - chpair : channelpair - chgroup : channelgroup - subchgroup : subchannelgroup - bundle : bundle - ont : ont - ont.ng2 : ngpon2 ONT style identification - uni : uni - uni.ng2 : ngpon2 UNI style identification </pre>	

104 Current Alarm Status Commands

name	Type	Description
	- voip : voip - voip:ng2 : voip - la-group : link aggregation group - dist-router-interface : dist router interface - voicefxs : voicefxs - mpm : multi-pon module Possible values: - vlan : vlan port Possible values: - slot-vlan : slot unstacked - slot-stacked : slot vlan port Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number Field type <Eqpt::VpiId> - atm VPI Field type <Eqpt::VciId> - atm VCI Field type <Eqpt::PonId> - the PON identifier Field type <Eqpt::XPonId> - the XGS PON identifier Field type <Eqpt::M25GPonId> - the 25G PON identifier Field type <Eqpt::ComboPonId> - the comboPON identifier Field type <Eqpt::ChannelPairId> - the channel pair identifier Field type <Eqpt::ChannelGroupId> - the channel group identifier Field type <Eqpt::SubChannelGroupId> - the subchannel group identifier Field type <Eqpt::BundleId> - the BUNDLE identifier Field type <Eqpt::OntId> - the ONT identifier Field type <Eqpt::Ng2OntId> - the NG2 ONT identifier Possible values: - voip : virtual uni identifier obsolete alternative replaced by vuni - vuni : virtual uni identifier Possible values: - vuni : virtual NGPON2 uni identifier Field type <Eqpt::OntSlotId> - the ONT SLOT identifier Field type <Eqpt::OntPortId> - the ONT PORT identifier Field type <Eqpt::Ng2OntSlotId> - the NGPON2 ONT SLOT identifier Field type <Eqpt::Ng2OntPortId> - the NGPON2 ONT PORT identifier	

name	Type	Description
	Field type <Eqpt::LLId> - the LLID identifier, range 1 for EPON, range 1-8 for DPOE Possible values: - stacked : stacked vlan identity Field type <Eqpt::UnstackedVlan> - unstacked vlan id Field type <Eqpt::SVlan> - service vlan id Field type <Eqpt::CVlan> - customer vlan id Field type <Eqpt::VlanId> - VLAN id Field type <Eqpt::LogicalId> - logical id Field type <Eqpt::VrflId> - VRF id	
newonu-index	Parameter type: <SignedInteger> - a signed integer	the newonu index for the pon alarm <i>This element is only shown in detail mode.</i>
log-info	Parameter type: <Alarm::AdditionalInfo> - string to identify the owner (example: Tom) - length: x<=512	some additional information about the table entry. <i>This element is only shown in detail mode.</i>

Only Show Details: current alarm status

name	Type	Description
onu-unprovisioned	Parameter type: <Alarm::checkNewOnu> (newonu not-newonu) Possible values: - newonu : new onu is exist - not-newonu : new onu is not exist	new onu is exist or not. <i>This element is only shown in detail mode.</i>
signal-loss	Parameter type: <Alarm::signalLoss> (loss not-loss) Possible values: - loss : new onu is exist - not-loss : new onu is not exist	pon loss of signal <i>This element is only shown in detail mode.</i>
bitrate-high	Parameter type: <Alarm::bitRate> (yes no) Possible values: - yes : new onu is exist - no : new onu is not exist	the error bit rate high at pon interface is reached or not <i>This element is only shown in detail mode.</i>
opmodule-mismatch	Parameter type: <Alarm::opmoudleMatch> (yes no) Possible values: - yes : new onu is exist - no : new onu is not exist	the optical module mismatched at pon interface failed or not. <i>This element is only shown in detail mode.</i>

104.103 Ima-Group Alarm Log Status Command

Command Description

This command displays the Ima-Group alarm log status.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm current eont-phyoam [ (index) ]
```

Command Parameters

Table 104.103-1 "Ima-Group Alarm Log Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm type

Command Output

Table 104.103-2 "Ima-Group Alarm Log Status Command" Display parameters

Specific Information		
name	Type	Description
last-updated-on	Parameter type: <Sys::timeInSecs> - the time (yyyy-mm-dd:hour:minutes:secs) - unit: UTC	network time in seconds when the alarm was logged. <i>This element is only shown in detail mode.</i>
onu-index	Parameter type: <Itf::ComplexPortType> (xdsl-line : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> voicefxs : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> xdsl-channel : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> atm-if : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> atm-pvc : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::VpiId> : <Eqpt::VciId> bridge-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::VpiId> : <Eqpt::VciId>	identifies the epon where the alarm has occurred. <i>This element is only shown in detail mode.</i>

name	Type	Description
	<pre> vlan-port:ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / <Eqpt::Ng2OntSlotId> / <Eqpt::Ng2OntPortId> : <Eqpt::UnstackedVlan> l2-vlan : <Eqpt::VlanId> ip : <Eqpt::LogicalId> sw-loopback slip uni:ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / <Eqpt::Ng2OntSlotId> / <Eqpt::Ng2OntPortId> vlan-port:ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / <Eqpt::Ng2OntSlotId> / <Eqpt::Ng2OntPortId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> atm-bonding : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> bonding : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> ip-gateway : <Eqpt::VrId> ip-line : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::VpiId> : <Eqpt::VciId> ip-line : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> shdsl-line : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> e1-line : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> atm-ima : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> ethernet-line : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> bridge-port:ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / vuni vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::VpiId> : <Eqpt::VciId> : <Eqpt::UnstackedVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::UnstackedVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::VpiId> : <Eqpt::VciId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> voip:ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> ip-line : vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::VpiId> : <Eqpt::VciId> : <Eqpt::UnstackedVlan> ip-line : vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::UnstackedVlan> ip-line : vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::VpiId> : <Eqpt::VciId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> ip-line : vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : stacked : <Eqpt::SVlan> : </pre>	

name	Type	Description
	<pre> <Eqpt::CVlan> vlan-port:ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / vuni : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan-port:ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / vuni : <Eqpt::UnstackedVlan> chgroup : <Eqpt::ChannelGroupId> subchgroup : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> bridge-port:ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / <Eqpt::Ng2OntSlotId> / <Eqpt::Ng2OntPortId> atm-pvc : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> bridge-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> bridge-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> / <Eqpt::OntPortId> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> / <Eqpt::OntPortId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> / <Eqpt::OntPortId> : <Eqpt::UnstackedVlan> pon : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> ont : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> uni : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> / <Eqpt::OntPortId> bridge-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / voip bridge-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / vuni vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / voip : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / vuni : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / voip : <Eqpt::UnstackedVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / vuni : <Eqpt::UnstackedVlan> voip : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> la-group : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / </pre>	

name	Type	Description
	<pre> <Eqpt::LLId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> bridge-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::LLId> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::LLId> : <Eqpt::UnstackedVlan> mpm : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::ComboPonId> x-pon : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::XPonId> 25g-pon : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::M25GPonId> dist-router-interface : slot-stacked : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::SVlan> : <Eqpt::CVlan> dist-router-interface : slot-vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::UnstackedVlan> bundle : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::BundleId> chpair : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::ChannelPairId> ont.ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId>) Possible values: - xdsl-line : a static xdsl line interface - xdsl-channel : a static xdsl channel interface - atm-if : a static atm interface - atm-pvc : an atm pvc interface - bridge-port : a vlan bridge-port - bridge-port.ng2 : a ngpon2 vlan bridge-port - l2-vlan : a l2-vlan interface - ip : an ip interface - sw-loopback : a software loopback interface - slip : a slip interface - atm-bonding : atm bonding obsolete alternative replaced by bonding - bonding : bonding - ip-gateway : ip user gateway interface - ip-line : ip line interface - shdsl-line : a static shdsl line interface - e1-line : a e1 line interface - atm-ima : atm ima - ethernet-line : an ethernet line interface - vlan-port : vlan port - vlan-port.ng2 : a ngpon2 vlan port - pon : pon - x-pon : xgs pon - 25g-pon : 25g pon - chpair : channelpair - chgroup : channelgroup - subchgroup : subchannelgroup - bundle : bundle - ont : ont - ont.ng2 : ngpon2 ONT style identification - uni : uni - uni.ng2 : ngpon2 UNI style identification </pre>	

104 Current Alarm Status Commands

name	Type	Description
	- voip : voip - voip:ng2 : voip - la-group : link aggregation group - dist-router-interface : dist router interface - voicefxs : voicefxs - mpm : multi-pon module Possible values: - vlan : vlan port Possible values: - slot-vlan : slot unstacked - slot-stacked : slot vlan port Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number Field type <Eqpt::VpiId> - atm VPI Field type <Eqpt::VciId> - atm VCI Field type <Eqpt::PonId> - the PON identifier Field type <Eqpt::XPonId> - the XGS PON identifier Field type <Eqpt::M25GPonId> - the 25G PON identifier Field type <Eqpt::ComboPonId> - the comboPON identifier Field type <Eqpt::ChannelPairId> - the channel pair identifier Field type <Eqpt::ChannelGroupId> - the channel group identifier Field type <Eqpt::SubChannelGroupId> - the subchannel group identifier Field type <Eqpt::BundleId> - the BUNDLE identifier Field type <Eqpt::OntId> - the ONT identifier Field type <Eqpt::Ng2OntId> - the NG2 ONT identifier Possible values: - voip : virtual uni identifier obsolete alternative replaced by vuni - vuni : virtual uni identifier Possible values: - vuni : virtual NGPON2 uni identifier Field type <Eqpt::OntSlotId> - the ONT SLOT identifier Field type <Eqpt::OntPortId> - the ONT PORT identifier Field type <Eqpt::Ng2OntSlotId> - the NGPON2 ONT SLOT identifier Field type <Eqpt::Ng2OntPortId> - the NGPON2 ONT PORT identifier	

name	Type	Description
	Field type <Eqpt::LLId> - the LLID identifier, range 1 for EPON, range 1-8 for DPOE Possible values: - stacked : stacked vlan identity Field type <Eqpt::UnstackedVlan> - unstacked vlan id Field type <Eqpt::SVlan> - service vlan id Field type <Eqpt::CVlan> - customer vlan id Field type <Eqpt::VlanId> - VLAN id Field type <Eqpt::LogicalId> - logical id Field type <Eqpt::VrflId> - VRF id	
additional-info	Parameter type: <Alarm::AdditionalInfo> - string to identify the owner (example: Tom) - length: x<=512	some additional information about the table entry. <i>This element is only shown in detail mode.</i>

Only Show Details: current alarm status

name	Type	Description
link-fault	Parameter type: <Alarm::linkFaultType> (yes no) Possible values: - yes : link fault at cpe/onu - no : link fault is not exist	Link fault at ont. <i>This element is only shown in detail mode.</i>
dying-gasp	Parameter type: <Alarm::dyingGaspType> (yes no) Possible values: - yes : dying gasp is exist - no : dying gasp is not exist	received dying gasp indication from ont. <i>This element is only shown in detail mode.</i>
critical-event	Parameter type: <Alarm::criticalEventType> (yes no) Possible values: - yes : critical event is exist - no : critical event is not exist	receive critical event indication from ont is ok or not <i>This element is only shown in detail mode.</i>
oam-fail	Parameter type: <Alarm::oamFailType> (yes no) Possible values: - yes : oam failing is yes - no : oam failing is not exist	ont fails to respond to oam message requests. <i>This element is only shown in detail mode.</i>

104.104 Ima-Group Alarm Log Status Command

Command Description

This command displays the Ima-Group alarm log status.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm current eont-services-lan [ (alarm-index) ]
```

Command Parameters

Table 104.104-1 "Ima-Group Alarm Log Status Command" Resource Parameters

Resource Identifier	Type	Description
(alarm-index)	Format: - index of a current alarm entry	alarm type

Command Output

Table 104.104-2 "Ima-Group Alarm Log Status Command" Display parameters

Specific Information		
name	Type	Description
last-updated-on	Parameter type: <Sys::timeInSecs> - the time (yyyy-mm-dd:hour:minutes:secs) - unit: UTC	network time in seconds when the alarm was logged. <i>This element is only shown in detail mode.</i>
uni-index	Parameter type: <Itf::ComplexPortType> (xdsl-line : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> voicefxs : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> xdsl-channel : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> atm-if : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> atm-pvc : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::VpiId> : <Eqpt::VciId> bridge-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::VpiId> : <Eqpt::VciId>	identifies the epon where the alarm has occurred. <i>This element is only shown in detail mode.</i>

name	Type	Description
	vlan-port:ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / <Eqpt::Ng2OntSlotId> / <Eqpt::Ng2OntPortId> : <Eqpt::UnstackedVlan> l2-vlan : <Eqpt::VlanId> ip : <Eqpt::LogicalId> sw-loopback slip uni:ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / <Eqpt::Ng2OntSlotId> / <Eqpt::Ng2OntPortId> vlan-port:ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / <Eqpt::Ng2OntSlotId> / <Eqpt::Ng2OntPortId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> atm-bonding : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> bonding : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> ip-gateway : <Eqpt::VrfId> ip-line : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::VpiId> : <Eqpt::VciId> ip-line : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> shdsl-line : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> e1-line : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> atm-ima : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> ethernet-line : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> bridge-port:ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / vuni vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::VpiId> : <Eqpt::VciId> : <Eqpt::UnstackedVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::UnstackedVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::VpiId> : <Eqpt::VciId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> voip:ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> ip-line : vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::VpiId> : <Eqpt::VciId> : <Eqpt::UnstackedVlan> ip-line : vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::UnstackedVlan> ip-line : vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::VpiId> : <Eqpt::VciId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> ip-line : vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : stacked : <Eqpt::SVlan> :	

name	Type	Description
	<pre> <Eqpt::CVlan> vlan-port:ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / vuni : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan-port:ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / vuni : <Eqpt::UnstackedVlan> chgroup : <Eqpt::ChannelGroupId> subchgroup : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> bridge-port:ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / <Eqpt::Ng2OntSlotId> / <Eqpt::Ng2OntPortId> atm-pvc : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> bridge-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> bridge-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> / <Eqpt::OntPortId> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> / <Eqpt::OntPortId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> / <Eqpt::OntPortId> : <Eqpt::UnstackedVlan> pon : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> ont : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> uni : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> / <Eqpt::OntPortId> bridge-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / voip bridge-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / vuni vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / voip : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / vuni : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / voip : <Eqpt::UnstackedVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / vuni : <Eqpt::UnstackedVlan> voip : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> la-group : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / </pre>	

name	Type	Description
	<pre> <Eqpt::LLId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> bridge-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::LLId> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::LLId> : <Eqpt::UnstackedVlan> mpm : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::ComboPonId> x-pon : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::XPonId> 25g-pon : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::M25GPonId> dist-router-interface : slot-stacked : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::SVlan> : <Eqpt::CVlan> dist-router-interface : slot-vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::UnstackedVlan> bundle : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::BundleId> chpair : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::ChannelPairId> ont.ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId>) Possible values: - xdsl-line : a static xdsl line interface - xdsl-channel : a static xdsl channel interface - atm-if : a static atm interface - atm-pvc : an atm pvc interface - bridge-port : a vlan bridge-port - bridge-port.ng2 : a ngpon2 vlan bridge-port - l2-vlan : a l2-vlan interface - ip : an ip interface - sw-loopback : a software loopback interface - slip : a slip interface - atm-bonding : atm bonding obsolete alternative replaced by bonding - bonding : bonding - ip-gateway : ip user gateway interface - ip-line : ip line interface - shdsl-line : a static shdsl line interface - e1-line : a e1 line interface - atm-ima : atm ima - ethernet-line : an ethernet line interface - vlan-port : vlan port - vlan-port.ng2 : a ngpon2 vlan port - pon : pon - x-pon : xgs pon - 25g-pon : 25g pon - chpair : channelpair - chgroup : channelgroup - subchgroup : subchannelgroup - bundle : bundle - ont : ont - ont.ng2 : ngpon2 ONT style identification - uni : uni - uni.ng2 : ngpon2 UNI style identification </pre>	

104 Current Alarm Status Commands

name	Type	Description
	- voip : voip - voip:ng2 : voip - la-group : link aggregation group - dist-router-interface : dist router interface - voicefxs : voicefxs - mpm : multi-pon module Possible values: - vlan : vlan port Possible values: - slot-vlan : slot unstacked - slot-stacked : slot vlan port Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number Field type <Eqpt::VpiId> - atm VPI Field type <Eqpt::VciId> - atm VCI Field type <Eqpt::PonId> - the PON identifier Field type <Eqpt::XPonId> - the XGS PON identifier Field type <Eqpt::M25GPonId> - the 25G PON identifier Field type <Eqpt::ComboPonId> - the comboPON identifier Field type <Eqpt::ChannelPairId> - the channel pair identifier Field type <Eqpt::ChannelGroupId> - the channel group identifier Field type <Eqpt::SubChannelGroupId> - the subchannel group identifier Field type <Eqpt::BundleId> - the BUNDLE identifier Field type <Eqpt::OntId> - the ONT identifier Field type <Eqpt::Ng2OntId> - the NG2 ONT identifier Possible values: - voip : virtual uni identifier obsolete alternative replaced by vuni - vuni : virtual uni identifier Possible values: - vuni : virtual NGPON2 uni identifier Field type <Eqpt::OntSlotId> - the ONT SLOT identifier Field type <Eqpt::OntPortId> - the ONT PORT identifier Field type <Eqpt::Ng2OntSlotId> - the NGPON2 ONT SLOT identifier Field type <Eqpt::Ng2OntPortId> - the NGPON2 ONT PORT identifier	

name	Type	Description
	Field type <Eqpt::LLId> - the LLID identifier, range 1 for EPON, range 1-8 for DPOE Possible values: - stacked : stacked vlan identity Field type <Eqpt::UnstackedVlan> - unstacked vlan id Field type <Eqpt::SVlan> - service vlan id Field type <Eqpt::CVlan> - customer vlan id Field type <Eqpt::VlanId> - VLAN id Field type <Eqpt::LogicalId> - logical id Field type <Eqpt::VrflId> - VRF id	
additional-info	Parameter type: <Alarm::AdditionalInfo> - string to identify the owner (example: Tom) - length: x<=512	some additional information about the table entry. <i>This element is only shown in detail mode.</i>

Only Show Details: current alarm status

name	Type	Description
port-loop	Parameter type: <Alarm::portLoopType> (yes no) Possible values: - yes : port loop happen is yes - no : port loop happen is not exist	port loop happen at ont uniport. <i>This element is only shown in detail mode.</i>
port-neg-fail	Parameter type: <Alarm::portNegFailType> (yes no) Possible values: - yes : failure of auto negotiation is yes - no : failure of auto negotiation is not exist	failure of auto negotiation for specific ethernet port. <i>This element is only shown in detail mode.</i>
port-loss	Parameter type: <Alarm::portLossType> (yes no) Possible values: - yes : loss of signal is yes - no : loss of signal is not exist	loss of signal for specific ethernet port is ok or not <i>This element is only shown in detail mode.</i>
port-fail	Parameter type: <Alarm::portFailType> (yes no) Possible values: - yes : failure of specific ethernet port is yes - no : failure of specific ethernet port is not exist	failure of specific ethernet port. <i>This element is only shown in detail mode.</i>
port-cong	Parameter type: <Alarm::portCongType> (yes no) Possible values: - yes : congestion of ethernet port is detected - no : congestion of ethernet port is not exist	congestion of ethernet port is detected. <i>This element is only shown in detail mode.</i>

104.105 Ima-Group Alarm Log Status Command

Command Description

This command displays the Ima-Group alarm log status.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm current eolt-ont-tca [ (alarm-index) ]
```

Command Parameters

Table 104.105-1 "Ima-Group Alarm Log Status Command" Resource Parameters

Resource Identifier	Type	Description
(alarm-index)	Format: - index of a current alarm entry	alarm type

Command Output

Table 104.105-2 "Ima-Group Alarm Log Status Command" Display parameters

Specific Information		
name	Type	Description
last-updated-on	Parameter type: <Sys::timeInSecs> - the time (yyyy-mm-dd:hour:minutes:secs) - unit: UTC	network time in seconds when the alarm was logged. <i>This element is only shown in detail mode.</i>
onu-index	Parameter type: <Itf::ComplexPortType> (xdsl-line : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> voicefxs : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> xdsl-channel : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> atm-if : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> atm-pvc : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::VpiId> : <Eqpt::VciId> bridge-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::VpiId> : <Eqpt::VciId>	identifies the epon where the alarm has occurred. <i>This element is only shown in detail mode.</i>

name	Type	Description
	<pre> vlan-port:ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / <Eqpt::Ng2OntSlotId> / <Eqpt::Ng2OntPortId> : <Eqpt::UnstackedVlan> l2-vlan : <Eqpt::VlanId> ip : <Eqpt::LogicalId> sw-loopback slip uni:ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / <Eqpt::Ng2OntSlotId> / <Eqpt::Ng2OntPortId> vlan-port:ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / <Eqpt::Ng2OntSlotId> / <Eqpt::Ng2OntPortId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> atm-bonding : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> bonding : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> ip-gateway : <Eqpt::VrId> ip-line : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::VpiId> : <Eqpt::VciId> ip-line : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> shdsl-line : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> e1-line : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> atm-ima : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> ethernet-line : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> bridge-port:ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / vuni vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::VpiId> : <Eqpt::VciId> : <Eqpt::UnstackedVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::UnstackedVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::VpiId> : <Eqpt::VciId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> voip:ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> ip-line : vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::VpiId> : <Eqpt::VciId> : <Eqpt::UnstackedVlan> ip-line : vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::UnstackedVlan> ip-line : vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::VpiId> : <Eqpt::VciId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> ip-line : vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : stacked : <Eqpt::SVlan> : </pre>	

name	Type	Description
	<pre> <Eqpt::CVlan> vlan-port:ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / vuni : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan-port:ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / vuni : <Eqpt::UnstackedVlan> chgroup : <Eqpt::ChannelGroupId> subchgroup : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> bridge-port:ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / <Eqpt::Ng2OntSlotId> / <Eqpt::Ng2OntPortId> atm-pvc : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> bridge-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> bridge-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> / <Eqpt::OntPortId> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> / <Eqpt::OntPortId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> / <Eqpt::OntPortId> : <Eqpt::UnstackedVlan> pon : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> ont : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> uni : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> / <Eqpt::OntPortId> bridge-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / voip bridge-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / vuni vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / voip : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / vuni : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / voip : <Eqpt::UnstackedVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / vuni : <Eqpt::UnstackedVlan> voip : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> la-group : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / </pre>	

name	Type	Description
	<pre> <Eqpt::LLId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> bridge-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::LLId> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::LLId> : <Eqpt::UnstackedVlan> mpm : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::ComboPonId> x-pon : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::XPonId> 25g-pon : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::M25GPonId> dist-router-interface : slot-stacked : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::SVlan> : <Eqpt::CVlan> dist-router-interface : slot-vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::UnstackedVlan> bundle : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::BundleId> chpair : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::ChannelPairId> ont.ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId>) Possible values: - xdsl-line : a static xdsl line interface - xdsl-channel : a static xdsl channel interface - atm-if : a static atm interface - atm-pvc : an atm pvc interface - bridge-port : a vlan bridge-port - bridge-port.ng2 : a ngpon2 vlan bridge-port - l2-vlan : a l2-vlan interface - ip : an ip interface - sw-loopback : a software loopback interface - slip : a slip interface - atm-bonding : atm bonding obsolete alternative replaced by bonding - bonding : bonding - ip-gateway : ip user gateway interface - ip-line : ip line interface - shdsl-line : a static shdsl line interface - e1-line : a e1 line interface - atm-ima : atm ima - ethernet-line : an ethernet line interface - vlan-port : vlan port - vlan-port.ng2 : a ngpon2 vlan port - pon : pon - x-pon : xgs pon - 25g-pon : 25g pon - chpair : channelpair - chgroup : channelgroup - subchgroup : subchannelgroup - bundle : bundle - ont : ont - ont.ng2 : ngpon2 ONT style identification - uni : uni - uni.ng2 : ngpon2 UNI style identification </pre>	

104 Current Alarm Status Commands

name	Type	Description
	- voip : voip - voip:ng2 : voip - la-group : link aggregation group - dist-router-interface : dist router interface - voicefxs : voicefxs - mpm : multi-pon module Possible values: - vlan : vlan port Possible values: - slot-vlan : slot unstacked - slot-stacked : slot vlan port Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number Field type <Eqpt::VpiId> - atm VPI Field type <Eqpt::VciId> - atm VCI Field type <Eqpt::PonId> - the PON identifier Field type <Eqpt::XPonId> - the XGS PON identifier Field type <Eqpt::M25GPonId> - the 25G PON identifier Field type <Eqpt::ComboPonId> - the comboPON identifier Field type <Eqpt::ChannelPairId> - the channel pair identifier Field type <Eqpt::ChannelGroupId> - the channel group identifier Field type <Eqpt::SubChannelGroupId> - the subchannel group identifier Field type <Eqpt::BundleId> - the BUNDLE identifier Field type <Eqpt::OntId> - the ONT identifier Field type <Eqpt::Ng2OntId> - the NG2 ONT identifier Possible values: - voip : virtual uni identifier obsolete alternative replaced by vuni - vuni : virtual uni identifier Possible values: - vuni : virtual NGPON2 uni identifier Field type <Eqpt::OntSlotId> - the ONT SLOT identifier Field type <Eqpt::OntPortId> - the ONT PORT identifier Field type <Eqpt::Ng2OntSlotId> - the NGPON2 ONT SLOT identifier Field type <Eqpt::Ng2OntPortId> - the NGPON2 ONT PORT identifier	

name	Type	Description
	Field type <Eqpt::LLId> - the LLID identifier, range 1 for EPON, range 1-8 for DPOE Possible values: - stacked : stacked vlan identity Field type <Eqpt::UnstackedVlan> - unstacked vlan id Field type <Eqpt::SVlan> - service vlan id Field type <Eqpt::CVlan> - customer vlan id Field type <Eqpt::VlanId> - VLAN id Field type <Eqpt::LogicalId> - logical id Field type <Eqpt::VrflId> - VRF id	
additional-info	Parameter type: <Alarm::AdditionalInfo> - string to identify the owner (example: Tom) - length: x<=512	some additional information about the table entry. <i>This element is only shown in detail mode.</i>

Only Show Details: current alarm status		
name	Type	Description
ont-olt-rx-pw-lo	Parameter type: <Alarm::pwLoType> (yes no) Possible values: - yes : congestion of ethernet port is detected - no : congestion of ethernet port is not exist	receive power from ont at olt side is lower. <i>This element is only shown in detail mode.</i>
ont-olt-rx-pw-hig	Parameter type: <Alarm::pwHigType> (yes no) Possible values: - yes : congestion of ethernet port is detected - no : congestion of ethernet port is not exist	receive power from ont at olt side is high. <i>This element is only shown in detail mode.</i>
ont-olt-rx-pw-warnlo	Parameter type: <Alarm::pwWarnLoType> (yes no) Possible values: - yes : congestion of ethernet port is detected - no : congestion of ethernet port is not exist	receive power from ont at olt side is warn lower. <i>This element is only shown in detail mode.</i>
ont-olt-rx-pw-warnhig	Parameter type: <Alarm::pwWarnHigType> (yes no) Possible values: - yes : congestion of ethernet port is detected - no : congestion of ethernet port is not exist	receive power from ont at olt side is warn high. <i>This element is only shown in detail mode.</i>

104.106 Ima-Group Alarm Log Status Command

Command Description

This command displays the Ima-Group alarm log status.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm current eont-sw-dl [ (alarm-index) ]
```

Command Parameters

Table 104.106-1 "Ima-Group Alarm Log Status Command" Resource Parameters

Resource Identifier	Type	Description
(alarm-index)	Format: - index of a current alarm entry	alarm type

Command Output

Table 104.106-2 "Ima-Group Alarm Log Status Command" Display parameters

Specific Information		
name	Type	Description
last-updated-on	Parameter type: <Sys::timeInSecs> - the time (yyyy-mm-dd:hour:minutes:secs) - unit: UTC	network time in seconds when the alarm was logged. <i>This element is only shown in detail mode.</i>
additional-info	Parameter type: <Alarm::AdditionalInfo> - string to identify the owner (example: Tom) - length: x<=512	some additional information about the table entry. <i>This element is only shown in detail mode.</i>

Only Show Details: current alarm status		
name	Type	Description
version-mismatch	Parameter type: <Alarm::versionMismatchType> (yes no) Possible values: - yes : software version mismatch is yes - no : software version mismatch is no	software version is mismatch. <i>This element is only shown in detail mode.</i>
dl-mode-mismatch	Parameter type: <Alarm::downloadModelType> (yes no)	software download mode mismatch. <i>This element is only shown in</i>

name	Type	Description
	Possible values: - yes : software download mode mismatch is yes - no : software download mode mismatch is no	<i>detail mode.</i>
version-not-found	Parameter type: <Alarm::versionFoundType> (yes no) Possible values: - yes : software version not found is yes - no : software version not found is no	software version not found. <i>This element is only shown in detail mode.</i>
dl-file-missing	Parameter type: <Alarm::downloadFileType> (yes no) Possible values: - yes : software download file missing is yes - no : software download file missing is no	software download file missing . <i>This element is only shown in detail mode.</i>
dl-in-progress	Parameter type: <Alarm::downloadProgressType> (yes no) Possible values: - yes : software download in progress is yes - no : software download in progress is no	software download in progress . <i>This element is only shown in detail mode.</i>
st-dl-failing	Parameter type: <Alarm::downloadFailType> (yes no) Possible values: - yes : software download failure is yes - no : software download failure is no	software download failure . <i>This element is only shown in detail mode.</i>
dl-active-failing	Parameter type: <Alarm::downloadActFailType> (yes no) Possible values: - yes : software download active failure is yes - no : software download active failure is no	software download active failure. <i>This element is only shown in detail mode.</i>
dl--commit-failing	Parameter type: <Alarm::downloadComFailType> (yes no) Possible values: - yes : software download commit failure is yes - no : software download commit failure is no	software download commit failure. <i>This element is only shown in detail mode.</i>

104.107 LT CFM Current Alarm Status Command

Command Description

This command displays iacm cfm current alarm status.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm current cfm [ (index) ]
```

Command Parameters

Table 104.107-1 "LT CFM Current Alarm Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm type

Command Output

Table 104.107-2 "LT CFM Current Alarm Status Command" Display parameters

Specific Information		
name	Type	Description
cfm-mep-id	Parameter type: <UnsignedSignedInteger> - an unsigned integer	dot1agCfmMepIdentifier index where the alarm has occurred. <i>This element is only shown in detail mode.</i>
cfm-unique-id	Parameter type: <Alarm::IdentificationIdxOrZero> - a signed integer	unique identification for the alarm or zero when not applicable, alarm entry is further specified in additional-info <i>This element is only shown in detail mode.</i>
additional-info	Parameter type: <Alarm::AddInfoStringCcm> - additional alarm information	Additional information regarding the cfm alarm <i>This element is only shown in detail mode.</i>

Only Show Details: current alarm status		
name	Type	Description
cfm-defrdiccm	Parameter type: <Alarm::IacmCfmRdiCcm> (yes no)	specifies rdi bit in ccm received <i>This element is only shown in detail mode.</i>

name	Type	Description
	Possible values: - yes : rdi bit in ccm received - no : no rdi bit in ccm received	
cfm-defmacstatus	Parameter type: <Alarm::IacmCfmMacError> (yes no) Possible values: - yes : mac error status - no : no mac error status	ccm mac error status <i>This element is only shown in detail mode.</i>
cfm-defremoteccm	Parameter type: <Alarm::IacmCfmMepCcm> (yes no) Possible values: - yes : missing ccm from mep - no : no missing ccm from mep	specifies missing ccm from mep <i>This element is only shown in detail mode.</i>
cfm-deferrorccm	Parameter type: <Alarm::IacmCfmInvalidCcm> (yes no) Possible values: - yes : invalid ccm received - no : no invalid ccm received	specifies invalid ccm received <i>This element is only shown in detail mode.</i>
cfm-defxconccm	Parameter type: <Alarm::IacmCfmUnexpectedCcm> (yes no) Possible values: - yes : unexpected ccm received - no : no unexpected ccm received	specifies unexpected ccm received <i>This element is only shown in detail mode.</i>
cfm-defais	Parameter type: <Alarm::IacmCfmAis> (yes no) Possible values: - yes : ethernet ais received - no : no ethernet ais received	specifies ethernet ais received <i>This element is only shown in detail mode.</i>

104.108 IHUB Eth Cfm Current Alarm Status Command

Command Description

This command displays ihub cfm current alarm status.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm current eth-cfm [ (index) ]
```

Command Parameters

Table 104.108-1 "IHUB Eth Cfm Current Alarm Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm type

Command Output

Table 104.108-2 "IHUB Eth Cfm Current Alarm Status Command" Display parameters

Specific Information		
name	Type	Description
cfm-mep-id	Parameter type: <UnsignedSignedInteger> - an unsigned integer	dot1agCfmMepIdentifier index where the alarm has occurred. <i>This element is only shown in detail mode.</i>
cfm-unique-id	Parameter type: <Alarm::IdentificationIdxOrZero> - a signed integer	unique identification for the alarm or zero when not applicable, alarm entry is further specified in additional-info <i>This element is only shown in detail mode.</i>
additional-info	Parameter type: <Alarm::AddInfoStringIhubCfm> - additional alarm information	Additional information regarding the cfm alarm <i>This element is only shown in detail mode.</i>

Only Show Details: current alarm status

name	Type	Description
defrdiccm	Parameter type: <Alarm::IhubCfmRdiCcm> (yes no) Possible values: - yes : rdi bit in ccm received - no : no rdi bit in ccm received	specifies rdi bit in ccm received <i>This element is only shown in detail mode.</i>
defmacstatus	Parameter type: <Alarm::IhubCfmMacError> (yes no) Possible values: - yes : mac error status - no : no mac error status	ccm mac error status <i>This element is only shown in detail mode.</i>
defremoteccm	Parameter type: <Alarm::IhubCfmMepCcm> (yes no) Possible values: - yes : missing ccm from mep - no : no missing ccm from mep	specifies missing ccm from mep <i>This element is only shown in detail mode.</i>
deferrorccm	Parameter type: <Alarm::IhubCfmInvalidCcm> (yes no) Possible values: - yes : invalid ccm received - no : no invalid ccm received	specifies invalid ccm received <i>This element is only shown in detail mode.</i>
defxconccm	Parameter type: <Alarm::IhubCfmUnexpectedCcm> (yes no) Possible values: - yes : unexpected ccm received - no : no unexpected ccm received	specifies unexpected ccm received <i>This element is only shown in detail mode.</i>

104.109 RSVP Current Alarm Status Command

Command Description

This command displays the current RSVP alarm status.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm current rsvp [ (index) ]
```

Command Parameters

Table 104.109-1 "RSVP Current Alarm Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm type

Command Output

Table 104.109-2 "RSVP Current Alarm Status Command" Display parameters

Specific Information		
name	Type	Description
router-id	Parameter type: <Ihub::baseRouter> base Possible values: - base : base router	identifies the base router <i>This element is only shown in detail mode.</i>
neighbor-index	Parameter type: <Alarm::IdentificationIdxOrZero> - a signed integer	An unique number to identify the alarm or zero when not applicable, Neighbor is further specified in additional-info <i>This element is only shown in detail mode.</i>
additional-info	Parameter type: <Alarm::AddInfoString> - additional alarm information	identifies the Neighbor using the Nbr address and ifIndex or empty string if not applicable <i>This element is only shown in detail mode.</i>

Only Show Details: current alarm status		
name	Type	Description
neighbor-down	Parameter type: <Alarm::RsvpNeighborDown> (yes	specifies whether the RSVP Neighbor is down or not

name	Type	Description
	no) Possible values: - yes : rsvp neighbor is down - no : rsvp neighbor is up or rsvp interface is shutdown or ip interface is shutdown or rsvp instance is shutdown	<i>This element is only shown in detail mode.</i>
instance-down	Parameter type: <Alarm::RsvpInstanceDown> (yes no) Possible values: - yes : rsvp instance is down - no : rsvp instance is up or not configured	specifies whether the Rsvp instance is down or not <i>This element is only shown in detail mode.</i>

104.110 IPD eth-ring Current Alarm Status Command

Command Description

This command displays the ipd eth-ring current alarm status.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

> show alarm current eth-ring [(index)]

Command Parameters

Table 104.110-1 "IPD eth-ring Current Alarm Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm log table index

Command Output

Table 104.110-2 "IPD eth-ring Current Alarm Status Command" Display parameters

Specific Information		
name	Type	Description
ring-id	Parameter type: <Alarm::genAlarmIndex> - index of a current alarm entry	identifies the eth-ring-instance <i>This element is only shown in detail mode.</i>
ring path-index	Parameter type: <Alarm::genAlarmIndex> - index of a current alarm entry	identifies the ring-path within a eth-ring <i>This element is only shown in detail mode.</i>

Only Show Details: current alarm status		
name	Type	Description
ering-path-blocked	Parameter type: <Alarm::EthRingPathBlocked> (yes no) Possible values: - yes : ethernet ring path is blocked - no : ethernet ring path is unblocked	specifies whether a eth-ring path is blocked or not <i>This element is only shown in detail mode.</i>

104.111 EFM-OAM Current Alarm Status Command

Command Description

This command displays the EFM-OAM current alarm status.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm current efm-oam [ (index) ]
```

Command Parameters

Table 104.111-1 "EFM-OAM Current Alarm Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm type

Command Output

Table 104.111-2 "EFM-OAM Current Alarm Status Command" Display parameters

Specific Information		
name	Type	Description
last-updated-on	Parameter type: <Sys::timeInSecs> - the time (yyyy-mm-dd:hour:minutes:secs) - unit: UTC	network time in seconds when the alarm was logged. <i>This element is only shown in detail mode.</i>
line	Parameter type: <Itf::EfmEthernetIndex> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number	identifies the line where the alarm has occurred. <i>This element is only shown in detail mode.</i>

Only Show Details: current alarm status		
name	Type	Description
link-fault	Parameter type: <Alarm::linkFaultType> (yes	Link fault at cpe <i>This element is only shown in</i>

name	Type	Description
	no) Possible values: - yes : link fault at cpe/onu - no : link fault is not exist	<i>detail mode.</i>
dying-gasp	Parameter type: <Alarm::dyingGaspType> (yes no) Possible values: - yes : dying gasp is exist - no : dying gasp is not exist	received dying gasp indication from cpe <i>This element is only shown in detail mode.</i>
critical-event	Parameter type: <Alarm::criticalEventType> (yes no) Possible values: - yes : critical event is exist - no : critical event is not exist	receive critical event indication from cpe <i>This element is only shown in detail mode.</i>

104.112 Ont loop detect Current Alarm Status Command

Command Description

This command displays the ont loop detect current alarm status.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

> show alarm current ont-loopdetect [(index)]

Command Parameters

Table 104.112-1 "Ont loop detect Current Alarm Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm type

Command Output

Table 104.112-2 "Ont loop detect Current Alarm Status Command" Display parameters

Specific Information		
name	Type	Description
ont	Parameter type: <Gpon::OntIndex> (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> ng2 : <Ng2::ChannelGroup> / <Ng2::SubchannelGroup> / <Ng2::OntId>) Possible values: - ng2 : ngpon2 style identification Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Ng2::ChannelGroup>	identifies the ont entry <i>This element is only shown in detail mode.</i>

name	Type	Description
	- channel group number Field type <Ng2::SubchannelGroup> - subchannel group number Field type <Eqpt::OntId> - the ONT identifier Field type <Ng2::OntId> - the ONT identifier	
ont-loopdetect	Parameter type: <Alarm::OntLoopDetectPortNumber> (port 1 looped port 2 looped port 3 looped port 4 looped port 5 looped port 6 looped port 7 looped port 8 looped port 9 looped port 10 looped port 11 looped port 12 looped port 13 looped port 14 looped port 15 looped port 16 looped port 17 looped port 18 looped port 19 looped port 20 looped port 21 looped port 22 looped port 23 looped port 24 looped) Possible values: - port 1 looped : ont port loop occurred - port 2 looped : ont port loop occurred - port 3 looped : ont port loop occurred - port 4 looped : ont port loop occurred - port 5 looped : ont port loop occurred - port 6 looped : ont port loop occurred - port 7 looped : ont port loop occurred - port 8 looped : ont port loop occurred - port 9 looped : ont port loop occurred - port 10 looped : ont port loop occurred - port 11 looped : ont port loop occurred - port 12 looped : ont port loop occurred - port 13 looped : ont port loop occurred - port 14 looped : ont port loop occurred - port 15 looped : ont port loop occurred - port 16 looped : ont port loop occurred - port 17 looped : ont port loop occurred - port 18 looped : ont port loop occurred - port 19 looped : ont port loop occurred - port 20 looped : ont port loop occurred - port 21 looped : ont port loop occurred - port 22 looped : ont port loop occurred - port 23 looped : ont port loop occurred - port 24 looped : ont port loop occurred	identifies the ont entry <i>This element is only shown in detail mode.</i>

104.113 ONT PLOAM Current Alarm Status Command

Command Description

This command displays the ONT PLOAM current alarm status.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

> show alarm current ont-ploam [(index)]

Command Parameters

Table 104.113-1 "ONT PLOAM Current Alarm Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm type

Command Output

Table 104.113-2 "ONT PLOAM Current Alarm Status Command" Display parameters

Specific Information		
name	Type	Description
ont	Parameter type: <Gpon::OntIndex> (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> ng2 : <Ng2::ChannelGroup> / <Ng2::SubchannelGroup> / <Ng2::OntId>) Possible values: - ng2 : ngpon2 style identification Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Ng2::ChannelGroup>	gpon ont equipment ifindex of ont <i>This element is only shown in detail mode.</i>

104 Current Alarm Status Commands

name	Type	Description
	- channel group number Field type <Ng2::SubchannelGroup> - subchannel group number Field type <Eqpt::OntId> - the ONT identifier Field type <Ng2::OntId> - the ONT identifier	

Only Show Details: current alarm status		
name	Type	Description
ont-ploam-loss-sig	Parameter type: <Alarm::ONTPLOAMLOSO> (yes no) Possible values: - yes : loss of signal at ont - no : no loss of signal at ont	loss of signal at ont <i>This element is only shown in detail mode.</i>
ont-ploam-loss-ack	Parameter type: <Alarm::ONTPLOAMLOA> (yes no) Possible values: - yes : loss of acknowledge from ont - no : no loss of acknowledge from ont	loss of acknowledge from ont <i>This element is only shown in detail mode.</i>
ont-ploam-loss-cd	Parameter type: <Alarm::ONTPLOAMLCD> (yes no) Possible values: - yes : loss of gem/atm channel delineation of ont - no : gem/atm channel delineation of ont is normal	loss of gem/atm channel delineation of ont <i>This element is only shown in detail mode.</i>
ont-ploam-phy-eqpt-err	Parameter type: <Alarm::ONTPLOAMPEE> (yes no) Possible values: - yes : physical equipment error of ont - no : no physical equipment error of ont	physical equipment error of ont <i>This element is only shown in detail mode.</i>
ont-ploam-startup-fail	Parameter type: <Alarm::ONTPLOAMSUF> (yes no) Possible values: - yes : startup failure in ranging of ont - no : no startup failure in ranging of ont	startup failure in ranging of ont <i>This element is only shown in detail mode.</i>
ont-ploam-sig-degrade	Parameter type: <Alarm::ONTPLOAMSD> (yes no) Possible values: - yes : signal degrade ber threshold exceeded from ont - no : signal degrade ber threshold is normal	signal degrade ber threshold exceeded from ont <i>This element is only shown in detail mode.</i>
ont-ploam-disabled	Parameter type: <Alarm::ONTPLOAMONTDisabled> (yes no) Possible values: - yes : ont has been autonomously disabled - no : ont is enabled	ont has been autonomously disabled because of misbehaving transmissions <i>This element is only shown in detail mode.</i>
ont-ploam-err-msg	Parameter type: <Alarm::ONTPLOAMMEM> (yes no) Possible values: - yes : message error message from ont - no : no message error message from ont	message error message from ont <i>This element is only shown in detail mode.</i>

name	Type	Description
ont-ploam-inactive	Parameter type: <Alarm::ONTPLOAMInact> (yes no) Possible values: - yes : ont is inactive - no : ont is active	ont is inactive <i>This element is only shown in detail mode.</i>
ont-ploam-sig-fail	Parameter type: <Alarm::ONTPLOAMSF> (yes no) Possible values: - yes : signal fail ber threshold exceeded from ont - no : no signal fail ber threshold exceeded from ont	signal fail ber threshold exceeded from ont <i>This element is only shown in detail mode.</i>
ont-ploam-dying-gasp	Parameter type: <Alarm::ONTPLOAMDG> (yes no) Possible values: - yes : received dying gasp indication from ont - no : no received dying gasp indication from ont	received dying gasp indication from ont <i>This element is only shown in detail mode.</i>
ont-ploam-deact-fail	Parameter type: <Alarm::ONTPLOAMDF> (yes no) Possible values: - yes : deactivate failure of ont - no : no deactivate failure of ont	deactivate failure of ont <i>This element is only shown in detail mode.</i>
ont-ploam-oam	Parameter type: <Alarm::ONTPLOAMLOAM> (yes no) Possible values: - yes : loss of ploam for ont - no : no Loss of ploam for ont	loss of ploam for ont <i>This element is only shown in detail mode.</i>
ont-ploam-win-drift	Parameter type: <Alarm::ONTPLOAMDOW> (yes no) Possible values: - yes : drift of window - no : no drift of window	drift of window. <i>This element is only shown in detail mode.</i>
ont-ploam-rdi	Parameter type: <Alarm::ONTPLOAMRDI> (yes no) Possible values: - yes : remote defect indication from ont - no : no remote defect indication from ont	remote defect indication from ont. <i>This element is only shown in detail mode.</i>
ont-ploam-loss-ks	Parameter type: <Alarm::ONTPLOAMLOKS> (yes no) Possible values: - yes : loss of key synchronization between olt and ont - no : key synchronization between olt and ont is ok	loss of key synchronization between olt and ont <i>This element is only shown in detail mode.</i>
ont-ploam-pwr-burst	Parameter type: <Alarm::ONTPLOAMONTPWREERR> (yes no) Possible values: - yes : ont power up error - no : ont power up ok	ont power up error. <i>This element is only shown in detail mode.</i>
ont-ploam-rog-disa	Parameter type: <Alarm::ONTPLOAMROGUEONTDIS> (yes no)	ont has been autonomously disabled because of misbehaving transmissions and is thought to be

104 Current Alarm Status Commands

name	Type	Description
	Possible values: - yes : ont has been autonomously disabled to be a rogue ont - no : ont is normal	a rogue ont. <i>This element is only shown in detail mode.</i>
ont-ploam-diff-reach	Parameter type: <Alarm::ONTPLOAMDIFREACH> (yes no) Possible values: - yes : ont has been deactivated because its location on the pon has exceeded its differential reach capability - no : ont is normal	ont has been deactivated because its location on the pon has exceeded its differential reach capability. <i>This element is only shown in detail mode.</i>
ont-ploam-looc	Parameter type: <Alarm::ONTPLOAMLOOC> (yes no) Possible values: - yes : ont has been deactivated due to persistent OMCI MIC failure - no : ont is normal	ont has been deactivated due to persistent OMCI MIC failure. <i>This element is only shown in detail mode.</i>

104.114 SFU ONT PLOAM Current Alarm Status Command

Command Description

This command displays the SFU ONT PLOAM current alarm status.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm current sfu-ploam [ (index) ]
```

Command Parameters

Table 104.114-1 "SFU ONT PLOAM Current Alarm Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm type

Command Output

Table 104.114-2 "SFU ONT PLOAM Current Alarm Status Command" Display parameters

Specific Information		
name	Type	Description
ont	Parameter type: <Gpon::OntIndex> (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> ng2 : <Ng2::ChannelGroup> / <Ng2::SubchannelGroup> / <Ng2::OntId>) Possible values: - ng2 : ngpon2 style identification Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Ng2::ChannelGroup>	gpon ont equipment ifindex of ont <i>This element is only shown in detail mode.</i>

104 Current Alarm Status Commands

name	Type	Description
	- channel group number Field type <Ng2::SubchannelGroup> - subchannel group number Field type <Eqpt::OntId> - the ONT identifier Field type <Ng2::OntId> - the ONT identifier	

Only Show Details: current alarm status		
name	Type	Description
sfu-ploam-loss-sig	Parameter type: <Alarm::ONTPLOAMLOSO> (yes no) Possible values: - yes : loss of signal at ont - no : no loss of signal at ont	loss of signal at ont <i>This element is only shown in detail mode.</i>
sfu-ploam-loss-ack	Parameter type: <Alarm::ONTPLOAMLOA> (yes no) Possible values: - yes : loss of acknowledge from ont - no : no loss of acknowledge from ont	loss of acknowledge from ont <i>This element is only shown in detail mode.</i>
sfu-ploam-loss-cd	Parameter type: <Alarm::ONTPLOAMLCD> (yes no) Possible values: - yes : loss of gem/atm channel delineation of ont - no : gem/atm channel delineation of ont is normal	loss of gem/atm channel delineation of ont <i>This element is only shown in detail mode.</i>
sfu-ploam-phy-eqpt-err	Parameter type: <Alarm::ONTPLOAMPEE> (yes no) Possible values: - yes : physical equipment error of ont - no : no physical equipment error of ont	physical equipment error of ont <i>This element is only shown in detail mode.</i>
sfu-ploam-startup-fail	Parameter type: <Alarm::ONTPLOAMSUF> (yes no) Possible values: - yes : startup failure in ranging of ont - no : no startup failure in ranging of ont	startup failure in ranging of ont <i>This element is only shown in detail mode.</i>
sfu-ploam-sig-degrade	Parameter type: <Alarm::ONTPLOAMSD> (yes no) Possible values: - yes : signal degrade ber threshold exceeded from ont - no : signal degrade ber threshold is normal	signal degrade ber threshold exceeded from ont <i>This element is only shown in detail mode.</i>
sfu-ploam-disabled	Parameter type: <Alarm::ONTPLOAMONTDisabled> (yes no) Possible values: - yes : ont has been autonomously disabled - no : ont is enabled	ont has been autonomously disabled because of misbehaving transmissions <i>This element is only shown in detail mode.</i>
sfu-ploam-err-msg	Parameter type: <Alarm::ONTPLOAMMEM> (yes no) Possible values: - yes : message error message from ont - no : no message error message from ont	message error message from ont <i>This element is only shown in detail mode.</i>

name	Type	Description
sfu-ploam-inactive	Parameter type: <Alarm::ONTPLOAMInact> (yes no) Possible values: - yes : ont is inactive - no : ont is active	ont is inactive <i>This element is only shown in detail mode.</i>
sfu-ploam-sig-fail	Parameter type: <Alarm::ONTPLOAMSF> (yes no) Possible values: - yes : signal fail ber threshold exceeded from ont - no : no signal fail ber threshold exceeded from ont	signal fail ber threshold exceeded from ont <i>This element is only shown in detail mode.</i>
sfu-ploam-dying-gasp	Parameter type: <Alarm::ONTPLOAMDG> (yes no) Possible values: - yes : received dying gasp indication from ont - no : no received dying gasp indication from ont	received dying gasp indication from ont <i>This element is only shown in detail mode.</i>
sfu-ploam-deact-fail	Parameter type: <Alarm::ONTPLOAMDF> (yes no) Possible values: - yes : deactivate failure of ont - no : no deactivate failure of ont	deactivate failure of ont <i>This element is only shown in detail mode.</i>
sfu-ploam-oam	Parameter type: <Alarm::ONTPLOAMLOAM> (yes no) Possible values: - yes : loss of ploam for ont - no : no Loss of ploam for ont	loss of ploam for ont <i>This element is only shown in detail mode.</i>
sfu-ploam-win-drift	Parameter type: <Alarm::ONTPLOAMDOW> (yes no) Possible values: - yes : drift of window - no : no drift of window	drift of window. <i>This element is only shown in detail mode.</i>
sfu-ploam-rdi	Parameter type: <Alarm::ONTPLOAMRDI> (yes no) Possible values: - yes : remote defect indication from ont - no : no remote defect indication from ont	remote defect indication from ont. <i>This element is only shown in detail mode.</i>
sfu-ploam-loss-ks	Parameter type: <Alarm::ONTPLOAMLOKS> (yes no) Possible values: - yes : loss of key synchronization between olt and ont - no : key synchronization between olt and ont is ok	loss of key synchronization between olt and ont <i>This element is only shown in detail mode.</i>
sfu-ploam-pwr-burst	Parameter type: <Alarm::ONTPLOAMONTPWREERR> (yes no) Possible values: - yes : ont power up error - no : ont power up ok	ont power up error. <i>This element is only shown in detail mode.</i>
sfu-ploam-rog-disa	Parameter type: <Alarm::ONTPLOAMROGUEONTDIS> (yes no)	ont has been autonomously disabled because of misbehaving transmissions and is thought to be

104 Current Alarm Status Commands

name	Type	Description
	Possible values: - yes : ont has been autonomously disabled to be a rogue ont - no : ont is normal	a rogue ont. <i>This element is only shown in detail mode.</i>
sfu-ploam-diff-reach	Parameter type: <Alarm::ONTPLOAMDIFREACH> (yes no) Possible values: - yes : ont has been deactivated because its location on the pon has exceeded its differential reach capability - no : ont is normal	ont has been deactivated because its location on the pon has exceeded its differential reach capability. <i>This element is only shown in detail mode.</i>
sfu-ploam-looc	Parameter type: <Alarm::ONTPLOAMLOOC> (yes no) Possible values: - yes : ont has been deactivated due to persistent OMCI MIC failure - no : ont is normal	ont has been deactivated due to persistent OMCI MIC failure. <i>This element is only shown in detail mode.</i>

104.115 SOHO ONT PLOAM Current Alarm Status Command

Command Description

This command displays the SOHO ONT PLOAM current alarm status.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

> show alarm current soho-ploam [(index)]

Command Parameters

Table 104.115-1 "SOHO ONT PLOAM Current Alarm Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm type

Command Output

Table 104.115-2 "SOHO ONT PLOAM Current Alarm Status Command" Display parameters

Specific Information		
name	Type	Description
ont	Parameter type: <Gpon::OntIndex> (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> ng2 : <Ng2::ChannelGroup> / <Ng2::SubchannelGroup> / <Ng2::OntId>) Possible values: - ng2 : ngpon2 style identification Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Ng2::ChannelGroup>	gpon ont equipment ifindex of ont <i>This element is only shown in detail mode.</i>

104 Current Alarm Status Commands

name	Type	Description
	- channel group number Field type <Ng2::SubchannelGroup> - subchannel group number Field type <Eqpt::OntId> - the ONT identifier Field type <Ng2::OntId> - the ONT identifier	

Only Show Details: current alarm status		
name	Type	Description
soho-ploam-loss-sig	Parameter type: <Alarm::ONTPLOAMLOSO> (yes no) Possible values: - yes : loss of signal at ont - no : no loss of signal at ont	loss of signal at ont <i>This element is only shown in detail mode.</i>
soho-ploam-loss-ack	Parameter type: <Alarm::ONTPLOAMLOA> (yes no) Possible values: - yes : loss of acknowledge from ont - no : no loss of acknowledge from ont	loss of acknowledge from ont <i>This element is only shown in detail mode.</i>
soho-ploam-loss-cd	Parameter type: <Alarm::ONTPLOAMLCD> (yes no) Possible values: - yes : loss of gem/atm channel delineation of ont - no : gem/atm channel delineation of ont is normal	loss of gem/atm channel delineation of ont <i>This element is only shown in detail mode.</i>
soho-ploam-phy-eqpt-er	Parameter type: <Alarm::ONTPLOAMPEE> (yes no) Possible values: - yes : physical equipment error of ont - no : no physical equipment error of ont	physical equipment error of ont <i>This element is only shown in detail mode.</i>
soho-ploam-startup-fai	Parameter type: <Alarm::ONTPLOAMSUF> (yes no) Possible values: - yes : startup failure in ranging of ont - no : no startup failure in ranging of ont	startup failure in ranging of ont <i>This element is only shown in detail mode.</i>
soho-ploam-sig-degrade	Parameter type: <Alarm::ONTPLOAMSD> (yes no) Possible values: - yes : signal degrade ber threshold exceeded from ont - no : signal degrade ber threshold is normal	signal degrade ber threshold exceeded from ont <i>This element is only shown in detail mode.</i>
soho-ploam-disabled	Parameter type: <Alarm::ONTPLOAMONTDisabled> (yes no) Possible values: - yes : ont has been autonomously disabled - no : ont is enabled	ont has been autonomously disabled because of misbehaving transmissions <i>This element is only shown in detail mode.</i>
soho-ploam-err-msg	Parameter type: <Alarm::ONTPLOAMMEM> (yes no) Possible values: - yes : message error message from ont - no : no message error message from ont	message error message from ont <i>This element is only shown in detail mode.</i>

name	Type	Description
soho-ploam-inactive	Parameter type: <Alarm::ONTPLOAMInact> (yes no) Possible values: - yes : ont is inactive - no : ont is active	ont is inactive <i>This element is only shown in detail mode.</i>
soho-ploam-sig-fail	Parameter type: <Alarm::ONTPLOAMSF> (yes no) Possible values: - yes : signal fail ber threshold exceeded from ont - no : no signal fail ber threshold exceeded from ont	signal fail ber threshold exceeded from ont <i>This element is only shown in detail mode.</i>
soho-ploam-dying-gasp	Parameter type: <Alarm::ONTPLOAMDG> (yes no) Possible values: - yes : received dying gasp indication from ont - no : no received dying gasp indication from ont	received dying gasp indication from ont <i>This element is only shown in detail mode.</i>
soho-ploam-deact-fail	Parameter type: <Alarm::ONTPLOAMDF> (yes no) Possible values: - yes : deactivate failure of ont - no : no deactivate failure of ont	deactivate failure of ont <i>This element is only shown in detail mode.</i>
soho-ploam-oam	Parameter type: <Alarm::ONTPLOAMLOAM> (yes no) Possible values: - yes : loss of ploam for ont - no : no Loss of ploam for ont	loss of ploam for ont <i>This element is only shown in detail mode.</i>
soho-ploam-win-drift	Parameter type: <Alarm::ONTPLOAMDOW> (yes no) Possible values: - yes : drift of window - no : no drift of window	drift of window. <i>This element is only shown in detail mode.</i>
soho-ploam-rdi	Parameter type: <Alarm::ONTPLOAMRDI> (yes no) Possible values: - yes : remote defect indication from ont - no : no remote defect indication from ont	remote defect indication from ont. <i>This element is only shown in detail mode.</i>
soho-ploam-loss-ks	Parameter type: <Alarm::ONTPLOAMLOKS> (yes no) Possible values: - yes : loss of key synchronization between olt and ont - no : key synchronization between olt and ont is ok	loss of key synchronization between olt and ont <i>This element is only shown in detail mode.</i>
soho-ploam-pwr-burst	Parameter type: <Alarm::ONTPLOAMONTPWRERR> (yes no) Possible values: - yes : ont power up error - no : ont power up ok	ont power up error. <i>This element is only shown in detail mode.</i>
soho-ploam-roq-disa	Parameter type: <Alarm::ONTPLOAMROGUEONTDIS> (yes no)	ont has been autonomously disabled because of misbehaving transmissions and is thought to be

104 Current Alarm Status Commands

name	Type	Description
	Possible values: - yes : ont has been autonomously disabled to be a rogue ont - no : ont is normal	a rogue ont. <i>This element is only shown in detail mode.</i>
soho-ploam-diff-reach	Parameter type: <Alarm::ONTPLOAMDIFREACH> (yes no) Possible values: - yes : ont has been deactivated because its location on the pon has exceeded its differential reach capability - no : ont is normal	ont has been deactivated because its location on the pon has exceeded its differential reach capability. <i>This element is only shown in detail mode.</i>
soho-ploam-looc	Parameter type: <Alarm::ONTPLOAMLOOC> (yes no) Possible values: - yes : ont has been deactivated due to persistent OMCI MIC failure - no : ont is normal	ont has been deactivated due to persistent OMCI MIC failure. <i>This element is only shown in detail mode.</i>

104.116 MDU ONT PLOAM Current Alarm Status Command

Command Description

This command displays the MDU ONT PLOAM current alarm status.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

> show alarm current mdu-ploam [(index)]

Command Parameters

Table 104.116-1 "MDU ONT PLOAM Current Alarm Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm type

Command Output

Table 104.116-2 "MDU ONT PLOAM Current Alarm Status Command" Display parameters

Specific Information		
name	Type	Description
ont	Parameter type: <Gpon::OntIndex> (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> ng2 : <Ng2::ChannelGroup> / <Ng2::SubchannelGroup> / <Ng2::OntId>) Possible values: - ng2 : ngpon2 style identification Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Ng2::ChannelGroup>	gpon ont equipment ifindex of ont <i>This element is only shown in detail mode.</i>

104 Current Alarm Status Commands

name	Type	Description
	- channel group number Field type <Ng2::SubchannelGroup> - subchannel group number Field type <Eqpt::OntId> - the ONT identifier Field type <Ng2::OntId> - the ONT identifier	

Only Show Details: current alarm status		
name	Type	Description
mdu-ploam-loss-sig	Parameter type: <Alarm::ONTPLOAMLOSO> (yes no) Possible values: - yes : loss of signal at ont - no : no loss of signal at ont	loss of signal at ont <i>This element is only shown in detail mode.</i>
mdu-ploam-loss-ack	Parameter type: <Alarm::ONTPLOAMLOA> (yes no) Possible values: - yes : loss of acknowledge from ont - no : no loss of acknowledge from ont	loss of acknowledge from ont <i>This element is only shown in detail mode.</i>
mdu-ploam-loss-cd	Parameter type: <Alarm::ONTPLOAMLCD> (yes no) Possible values: - yes : loss of gem/atm channel delineation of ont - no : gem/atm channel delineation of ont is normal	loss of gem/atm channel delineation of ont <i>This element is only shown in detail mode.</i>
mdu-ploam-phy-eqpt-err	Parameter type: <Alarm::ONTPLOAMPEE> (yes no) Possible values: - yes : physical equipment error of ont - no : no physical equipment error of ont	physical equipment error of ont <i>This element is only shown in detail mode.</i>
mdu-ploam-startup-fail	Parameter type: <Alarm::ONTPLOAMSUF> (yes no) Possible values: - yes : startup failure in ranging of ont - no : no startup failure in ranging of ont	startup failure in ranging of ont <i>This element is only shown in detail mode.</i>
mdu-ploam-sig-degrade	Parameter type: <Alarm::ONTPLOAMSD> (yes no) Possible values: - yes : signal degrade ber threshold exceeded from ont - no : signal degrade ber threshold is normal	signal degrade ber threshold exceeded from ont <i>This element is only shown in detail mode.</i>
mdu-ploam-disabled	Parameter type: <Alarm::ONTPLOAMONTDisabled> (yes no) Possible values: - yes : ont has been autonomously disabled - no : ont is enabled	ont has been autonomously disabled because of misbehaving transmissions <i>This element is only shown in detail mode.</i>
mdu-ploam-err-msg	Parameter type: <Alarm::ONTPLOAMMEM> (yes no) Possible values: - yes : message error message from ont - no : no message error message from ont	message error message from ont <i>This element is only shown in detail mode.</i>

name	Type	Description
mdu-ploam-inactive	Parameter type: <Alarm::ONTPLOAMInact> (yes no) Possible values: - yes : ont is inactive - no : ont is active	ont is inactive <i>This element is only shown in detail mode.</i>
mdu-ploam-sig-fail	Parameter type: <Alarm::ONTPLOAMSF> (yes no) Possible values: - yes : signal fail ber threshold exceeded from ont - no : no signal fail ber threshold exceeded from ont	signal fail ber threshold exceeded from ont <i>This element is only shown in detail mode.</i>
mdu-ploam-dying-gasp	Parameter type: <Alarm::ONTPLOAMDG> (yes no) Possible values: - yes : received dying gasp indication from ont - no : no received dying gasp indication from ont	received dying gasp indication from ont <i>This element is only shown in detail mode.</i>
mdu-ploam-deact-fail	Parameter type: <Alarm::ONTPLOAMDF> (yes no) Possible values: - yes : deactivate failure of ont - no : no deactivate failure of ont	deactivate failure of ont <i>This element is only shown in detail mode.</i>
mdu-ploam-oam	Parameter type: <Alarm::ONTPLOAMLOAM> (yes no) Possible values: - yes : loss of ploam for ont - no : no Loss of ploam for ont	loss of ploam for ont <i>This element is only shown in detail mode.</i>
mdu-ploam-win-drift	Parameter type: <Alarm::ONTPLOAMDOW> (yes no) Possible values: - yes : drift of window - no : no drift of window	drift of window. <i>This element is only shown in detail mode.</i>
mdu-ploam-rdi	Parameter type: <Alarm::ONTPLOAMRDI> (yes no) Possible values: - yes : remote defect indication from ont - no : no remote defect indication from ont	remote defect indication from ont. <i>This element is only shown in detail mode.</i>
mdu-ploam-loss-ks	Parameter type: <Alarm::ONTPLOAMLOKS> (yes no) Possible values: - yes : loss of key synchronization between olt and ont - no : key synchronization between olt and ont is ok	loss of key synchronization between olt and ont <i>This element is only shown in detail mode.</i>
mdu-ploam-pwr-burst	Parameter type: <Alarm::ONTPLOAMONTPWREERR> (yes no) Possible values: - yes : ont power up error - no : ont power up ok	ont power up error. <i>This element is only shown in detail mode.</i>
mdu-ploam-rog-disa	Parameter type: <Alarm::ONTPLOAMROGUEONTDIS> (yes no)	ont has been autonomously disabled because of misbehaving transmissions and is thought to be

104 Current Alarm Status Commands

name	Type	Description
	Possible values: - yes : ont has been autonomously disabled to be a rogue ont - no : ont is normal	a rogue ont. <i>This element is only shown in detail mode.</i>
mdu-ploam-diff-reach	Parameter type: <Alarm::ONTPLOAMDIFREACH> (yes no) Possible values: - yes : ont has been deactivated because its location on the pon has exceeded its differential reach capability - no : ont is normal	ont has been deactivated because its location on the pon has exceeded its differential reach capability. <i>This element is only shown in detail mode.</i>
mdu-ploam-looc	Parameter type: <Alarm::ONTPLOAMLOOC> (yes no) Possible values: - yes : ont has been deactivated due to persistent OMCI MIC failure - no : ont is normal	ont has been deactivated due to persistent OMCI MIC failure. <i>This element is only shown in detail mode.</i>

104.117 ONT General Current Alarm Status Command

Command Description

This command displays the ONT general current alarm status.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

> show alarm current ont-gen [(index)]

Command Parameters

Table 104.117-1 "ONT General Current Alarm Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm type

Command Output

Table 104.117-2 "ONT General Current Alarm Status Command" Display parameters

Specific Information		
name	Type	Description
ont	Parameter type: <Gpon::OntIndex> (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> ng2 : <Ng2::ChannelGroup> / <Ng2::SubchannelGroup> / <Ng2::OntId>) Possible values: - ng2 : ngpon2 style identification Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Ng2::ChannelGroup>	gpon ont equipment ifindex of ont <i>This element is only shown in detail mode.</i>

104 Current Alarm Status Commands

name	Type	Description
	- channel group number Field type <Ng2::SubchannelGroup> - subchannel group number Field type <Eqpt::OntId> - the ONT identifier Field type <Ng2::OntId> - the ONT identifier	

Only Show Details: current alarm status		
name	Type	Description
ont-gen-omci-fail	Parameter type: <Alarm::ONTGENERALOMCICOMM> (yes no) Possible values: - yes : ont fails to respond to omci message requests - no : ont responds to omci message requests works properly	ont fails to respond to omci message requests <i>This element is only shown in detail mode.</i>
ont-gen-eqpt-selftest	Parameter type: <Alarm::ONTGENERALEQPT> (yes no) Possible values: - yes : ont has failed a self test - no : ont self test works properly	ont has failed a self-test <i>This element is only shown in detail mode.</i>
ont-gen-ac-pwr-fail	Parameter type: <Alarm::ONTGENERALACFAIL> (yes no) Possible values: - yes : loss of external ac power to the ont - no : external ac power to the ont is ok	loss of external ac power to the ont" <i>This element is only shown in detail mode.</i>
ont-gen-bat-missing	Parameter type: <Alarm::ONTGENERALBATTMIS> (yes no) Possible values: - yes : battery is provisioned for ont but is missing - no : battery is provisioned and present for ont	battery is provisioned for ont but is missing <i>This element is only shown in detail mode.</i>
ont-gen-bat-low	Parameter type: <Alarm::ONTGENERALBATTLLOW> (yes no) Possible values: - yes : battery charge is low - no : battery charge is ok	battery charge is low <i>This element is only shown in detail mode.</i>
ont-gen-bat-fail	Parameter type: <Alarm::ONTGENERALBATTFAIL> (yes no) Possible values: - yes : battery is provisioned and present but cannot recharge - no : battery is provisioned and present and can recharge	battery is provisioned and present but cannot recharge <i>This element is only shown in detail mode.</i>
ont-gen-phys-intrusion	Parameter type: <Alarm::ONTGENERALINTRUDER> (yes no) Possible values: - yes : unauthorized access to ont and door or box is open - no : authorized access to ont	unauthorized access to ont <i>This element is only shown in detail mode.</i>
ont-gen-sw-dnload-f	Parameter type: <Alarm::ONTGENERALSWDLFAIL> (yes no) Possible values: - yes : download of software to ont has failed - no : download of software to ont works properly	download of software to ont has failed <i>This element is only shown in detail mode.</i>

name	Type	Description
ont-gen-sw-act-fail	Parameter type: <Alarm::ONTGENERALSWACTFAIL> (yes no) Possible values: - yes : ont failed to activate the passive image designated by the olt - no : ont works properly to activate the passive image designated by the olt	ont failed to activate the passive image designated by the olt <i>This element is only shown in detail mode.</i>
ont-gen-sw-dnload-p	Parameter type: <Alarm::ONTGENERALSWDLIP> (yes no) Possible values: - yes : a condition meaning that a transfer of ont software from the olt to the ont is pending or is actually being transmitted - no : a condition meaning that a transfer of ont software from the olt to the ont is not ready	a condition meaning that a transfer of ont software from the olt to the ont is pending or is actually being transmitted <i>This element is only shown in detail mode.</i>
ont-gen-eqpt-vers-mis	Parameter type: <Alarm::ONTGENERALEQVERMIS> (yes no) Possible values: - yes : a condition meaning the provisioned ont equipment part number does not match the version reported by the ont - no : a condition meaning that provisioned ont equipment part number matches the version reported by the ont	a condition meaning the provisioned ont equipment part number does not match the version reported by the ont <i>This element is only shown in detail mode.</i>
ont-gen-sw-vers-mis	Parameter type: <Alarm::ONTGENERALSWVER> (yes no) Possible values: - yes : a condition meaning that the planned software version does not equal the active software version - no : a condition meaning that the planned software version equals the active software version	a condition meaning that the planned software version does not equal the active software version <i>This element is only shown in detail mode.</i>
ont-gen-us-rate-mis	Parameter type: <Alarm::ONTGENERALUSRATE> (yes no) Possible values: - yes : a condition meaning that the planned upstream rate and the actual upstream rate do not match - no : a condition meaning that the planned upstream rate and the actual upstream rate match	a condition meaning that the planned upstream rate and the actual upstream rate do not match <i>This element is only shown in detail mode.</i>
ont-gen-eqpt-prov-sa	Parameter type: <Alarm::ONTGENERALONTMEA> (yes no) Possible values: - yes : mismatch between ont equipment and ont provisioning attributes - no : match between ont equipment and ont provisioning attributes	mismatch between ont equipment and ont provisioning attributes <i>This element is only shown in detail mode.</i>
ont-gen-mdv-env1	Parameter type: <Alarm::ONTGENERALENV1> (yes no) Possible values: - yes : mdv environmental alarm1 - no : do not detect the mdv environmental alarm1	mdv environmental alarm1 <i>This element is only shown in detail mode.</i>
ont-gen-mdv-env2	Parameter type: <Alarm::ONTGENERALENV2> (yes	mdv environmental alarm2 <i>This element is only shown in</i>

104 Current Alarm Status Commands

name	Type	Description
	no) Possible values: - yes : mdu environmental alarm2 - no : do not detect the mdu environmental alarm2	<i>detail mode.</i>
ont-gen-mdv-env3	Parameter type: <Alarm::ONTGENERALENV3> (yes no) Possible values: - yes : mdu environmental alarm3 - no : do not detect the mdu environmental alarm3	mdv environmental alarm3 <i>This element is only shown in detail mode.</i>
ont-gen-nw-time-err	Parameter type: <Alarm::ONTGENERALNTPERR> (yes no) Possible values: - yes : a condition meaning the ont is unable to establish timing from the ntp server(s) - no : a condition meaning the ont is able to establish timing from the ntp server(s)	a condition meaning the ont is unable to establish timing from the ntp server(s) <i>This element is only shown in detail mode.</i>
ont-gen-opt-sig-high	Parameter type: <Alarm::ONTGENERALLEVELHI> (yes no) Possible values: - yes : optical signal level is too high - no : optical signal level is normal	optical signal level is too high <i>This element is only shown in detail mode.</i>
ont-gen-opt-sig-low	Parameter type: <Alarm::ONTGENERALLEVELLO> (yes no) Possible values: - yes : optical signal level is too low - no : optical signal level is normal	Optical signal level is too low <i>This element is only shown in detail mode.</i>
ont-gen-eqpt-prov-nsa	Parameter type: <Alarm::ONTGENERALONTNSAMEA> (yes no) Possible values: - yes : non service affects mismatch between ont equipment and ont provisioning attributes - no : ont is provisioned properly	non service affects mismatch between ont equipment and ont provisioning attributes <i>This element is only shown in detail mode.</i>

104.118 SFU ONT General Current Alarm Status Command

Command Description

This command displays the SFU ONT general current alarm status.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm current sfu-gen [ (index) ]
```

Command Parameters

Table 104.118-1 "SFU ONT General Current Alarm Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm type

Command Output

Table 104.118-2 "SFU ONT General Current Alarm Status Command" Display parameters

Specific Information		
name	Type	Description
ont	Parameter type: <Gpon::OntIndex> (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> ng2 : <Ng2::ChannelGroup> / <Ng2::SubchannelGroup> / <Ng2::OntId>) Possible values: - ng2 : ngpon2 style identification Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Ng2::ChannelGroup>	gpon ont equipment ifindex of ont <i>This element is only shown in detail mode.</i>

104 Current Alarm Status Commands

name	Type	Description
	- channel group number Field type <Ng2::SubchannelGroup> - subchannel group number Field type <Eqpt::OntId> - the ONT identifier Field type <Ng2::OntId> - the ONT identifier	
Only Show Details: current alarm status		
name	Type	Description
sfu-gen-omci-fail	Parameter type: <Alarm::ONTGENERALOMCICOMM> (yes no) Possible values: - yes : ont fails to respond to omci message requests - no : ont responds to omci message requests works properly	ont fails to respond to omci message requests <i>This element is only shown in detail mode.</i>
sfu-gen-eqpt-selftest	Parameter type: <Alarm::ONTGENERALEQPT> (yes no) Possible values: - yes : ont has failed a self test - no : ont self test works properly	ont has failed a self-test <i>This element is only shown in detail mode.</i>
sfu-gen-ac-pwr-fail	Parameter type: <Alarm::ONTGENERALACFAIL> (yes no) Possible values: - yes : loss of external ac power to the ont - no : external ac power to the ont is ok	loss of external ac power to the ont" <i>This element is only shown in detail mode.</i>
sfu-gen-bat-missing	Parameter type: <Alarm::ONTGENERALBATTMIS> (yes no) Possible values: - yes : battery is provisioned for ont but is missing - no : battery is provisioned and present for ont	battery is provisioned for ont but is missing <i>This element is only shown in detail mode.</i>
sfu-gen-bat-low	Parameter type: <Alarm::ONTGENERALBATTLLOW> (yes no) Possible values: - yes : battery charge is low - no : battery charge is ok	battery charge is low <i>This element is only shown in detail mode.</i>
sfu-gen-bat-fail	Parameter type: <Alarm::ONTGENERALBATTFAIL> (yes no) Possible values: - yes : battery is provisioned and present but cannot recharge - no : battery is provisioned and present and can recharge	battery is provisioned and present but cannot recharge <i>This element is only shown in detail mode.</i>
sfu-gen-sw-dnload-f	Parameter type: <Alarm::ONTGENERALSWDLFAIL> (yes no) Possible values: - yes : download of software to ont has failed - no : download of software to ont works properly	download of software to ont has failed <i>This element is only shown in detail mode.</i>
sfu-gen-sw-act-fail	Parameter type: <Alarm::ONTGENERALSWACTFAIL> (yes no) Possible values: - yes : ont failed to activate the passive image designated by the olt	ont failed to activate the passive image designated by the olt <i>This element is only shown in detail mode.</i>

name	Type	Description
	- no : ont works properly to activate the passive image designated by the olt	
sfu-gen-sw-dnload-p	Parameter type: <Alarm::ONTGENERALSWDLIP> (yes no) Possible values: - yes : a condition meaning that a transfer of ont software from the olt to the ont is pending or is actually being transmitted - no : a condition meaning that a transfer of ont software from the olt to the ont is not ready	a condition meaning that a transfer of ont software from the olt to the ont is pending or is actually being transmitted <i>This element is only shown in detail mode.</i>
sfu-gen-eqpt-vers-mis	Parameter type: <Alarm::ONTGENERALEQVERMIS> (yes no) Possible values: - yes : a condition meaning the provisioned ont equipment part number does not match the version reported by the ont - no : a condition meaning that provisioned ont equipment part number matches the version reported by the ont	a condition meaning the provisioned ont equipment part number does not match the version reported by the ont <i>This element is only shown in detail mode.</i>
sfu-gen-sw-vers-mis	Parameter type: <Alarm::ONTGENERALSWVER> (yes no) Possible values: - yes : a condition meaning that the planned software version does not equal the active software version - no : a condition meaning that the planned software version equals the active software version	a condition meaning that the planned software version does not equal the active software version <i>This element is only shown in detail mode.</i>
sfu-gen-us-rate-mis	Parameter type: <Alarm::ONTGENERALUSRATE> (yes no) Possible values: - yes : a condition meaning that the planned upstream rate and the actual upstream rate do not match - no : a condition meaning that the planned upstream rate and the actual upstream rate match	a condition meaning that the planned upstream rate and the actual upstream rate do not match <i>This element is only shown in detail mode.</i>
sfu-gen-eqpt-prov-sa	Parameter type: <Alarm::ONTGENERALONTMEA> (yes no) Possible values: - yes : mismatch between ont equipment and ont provisioning attributes - no : match between ont equipment and ont provisioning attributes	mismatch between ont equipment and ont provisioning attributes <i>This element is only shown in detail mode.</i>
sfu-gen-nw-time-err	Parameter type: <Alarm::ONTGENERALNTPERR> (yes no) Possible values: - yes : a condition meaning the ont is unable to establish timing from the ntp server(s) - no : a condition meaning the ont is able to establish timing from the ntp server(s)	a condition meaning the ont is unable to establish timing from the ntp server(s) <i>This element is only shown in detail mode.</i>
sfu-gen-opt-sig-high	Parameter type: <Alarm::ONTGENERALLEVELHI> (yes no) Possible values: - yes : optical signal level is too high - no : optical signal level is normal	optical signal level is too high <i>This element is only shown in detail mode.</i>

104 Current Alarm Status Commands

name	Type	Description
sfu-gen-opt-sig-low	Parameter type: <Alarm::ONTGENERALLEVELLO> (yes no) Possible values: - yes : optical signal level is too low - no : optical signal level is normal	Optical signal level is too low <i>This element is only shown in detail mode.</i>
sfu-gen-eqpt-prov-nsa	Parameter type: <Alarm::ONTGENERALONTNSAMEA> (yes no) Possible values: - yes : non service affects mismatch between ont equipment and ont provisioning attributes - no : ont is provisioned properly	non service affects mismatch between ont equipment and ont provisioning attributes <i>This element is only shown in detail mode.</i>

104.119 SOHO ONT General Current Alarm Status Command

Command Description

This command displays the SOHO ONT general current alarm status.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

> show alarm current soho-gen [(index)]

Command Parameters

Table 104.119-1 "SOHO ONT General Current Alarm Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm type

Command Output

Table 104.119-2 "SOHO ONT General Current Alarm Status Command" Display parameters

Specific Information		
name	Type	Description
ont	Parameter type: <Gpon::OntIndex> (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> ng2 : <Ng2::ChannelGroup> / <Ng2::SubchannelGroup> / <Ng2::OntId>) Possible values: - ng2 : ngpon2 style identification Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Ng2::ChannelGroup>	gpon ont equipment ifindex of ont <i>This element is only shown in detail mode.</i>

104 Current Alarm Status Commands

name	Type	Description
	- channel group number Field type <Ng2::SubchannelGroup> - subchannel group number Field type <Eqpt::OntId> - the ONT identifier Field type <Ng2::OntId> - the ONT identifier	
Only Show Details: current alarm status		
name	Type	Description
soho-gen-omci-fail	Parameter type: <Alarm::ONTGENERALOMCICOMM> (yes no) Possible values: - yes : ont fails to respond to omci message requests - no : ont responds to omci message requests works properly	ont fails to respond to omci message requests <i>This element is only shown in detail mode.</i>
soho-gen-eqpt-selftest	Parameter type: <Alarm::ONTGENERALEQPT> (yes no) Possible values: - yes : ont has failed a self test - no : ont self test works properly	ont has failed a self-test <i>This element is only shown in detail mode.</i>
soho-gen-ac-pwr-fail	Parameter type: <Alarm::ONTGENERALACFAIL> (yes no) Possible values: - yes : loss of external ac power to the ont - no : external ac power to the ont is ok	loss of external ac power to the ont" <i>This element is only shown in detail mode.</i>
soho-gen-bat-missing	Parameter type: <Alarm::ONTGENERALBATTMIS> (yes no) Possible values: - yes : battery is provisioned for ont but is missing - no : battery is provisioned and present for ont	battery is provisioned for ont but is missing <i>This element is only shown in detail mode.</i>
soho-gen-bat-low	Parameter type: <Alarm::ONTGENERALBATTLLOW> (yes no) Possible values: - yes : battery charge is low - no : battery charge is ok	battery charge is low <i>This element is only shown in detail mode.</i>
soho-gen-bat-fail	Parameter type: <Alarm::ONTGENERALBATTFAIL> (yes no) Possible values: - yes : battery is provisioned and present but cannot recharge - no : battery is provisioned and present and can recharge	battery is provisioned and present but cannot recharge <i>This element is only shown in detail mode.</i>
soho-gen-sw-dnload-f	Parameter type: <Alarm::ONTGENERALSWDLFAIL> (yes no) Possible values: - yes : download of software to ont has failed - no : download of software to ont works properly	download of software to ont has failed <i>This element is only shown in detail mode.</i>
soho-gen-sw-act-fail	Parameter type: <Alarm::ONTGENERALSWACTFAIL> (yes no) Possible values: - yes : ont failed to activate the passive image designated by the olt	ont failed to activate the passive image designated by the olt <i>This element is only shown in detail mode.</i>

name	Type	Description
	- no : ont works properly to activate the passive image designated by the olt	
soho-gen-sw-dnload-p	Parameter type: <Alarm::ONTGENERALSWDLIP> (yes no) Possible values: - yes : a condition meaning that a transfer of ont software from the olt to the ont is pending or is actually being transmitted - no : a condition meaning that a transfer of ont software from the olt to the ont is not ready	a condition meaning that a transfer of ont software from the olt to the ont is pending or is actually being transmitted <i>This element is only shown in detail mode.</i>
soho-gen-eqpt-vers-mis	Parameter type: <Alarm::ONTGENERALEQVERMIS> (yes no) Possible values: - yes : a condition meaning the provisioned ont equipment part number does not match the version reported by the ont - no : a condition meaning that provisioned ont equipment part number matches the version reported by the ont	a condition meaning the provisioned ont equipment part number does not match the version reported by the ont <i>This element is only shown in detail mode.</i>
soho-gen-sw-vers-mis	Parameter type: <Alarm::ONTGENERALSWVER> (yes no) Possible values: - yes : a condition meaning that the planned software version does not equal the active software version - no : a condition meaning that the planned software version equals the active software version	a condition meaning that the planned software version does not equal the active software version <i>This element is only shown in detail mode.</i>
soho-gen-us-rate-mis	Parameter type: <Alarm::ONTGENERALUSRATE> (yes no) Possible values: - yes : a condition meaning that the planned upstream rate and the actual upstream rate do not match - no : a condition meaning that the planned upstream rate and the actual upstream rate match	a condition meaning that the planned upstream rate and the actual upstream rate do not match <i>This element is only shown in detail mode.</i>
soho-gen-eqpt-prov-sa	Parameter type: <Alarm::ONTGENERALONTMEA> (yes no) Possible values: - yes : mismatch between ont equipment and ont provisioning attributes - no : match between ont equipment and ont provisioning attributes	mismatch between ont equipment and ont provisioning attributes <i>This element is only shown in detail mode.</i>
soho-gen-nw-time-err	Parameter type: <Alarm::ONTGENERALNTPERR> (yes no) Possible values: - yes : a condition meaning the ont is unable to establish timing from the ntp server(s) - no : a condition meaning the ont is able to establish timing from the ntp server(s)	a condition meaning the ont is unable to establish timing from the ntp server(s) <i>This element is only shown in detail mode.</i>
soho-gen-opt-sig-high	Parameter type: <Alarm::ONTGENERALLEVELHI> (yes no) Possible values: - yes : optical signal level is too high - no : optical signal level is normal	optical signal level is too high <i>This element is only shown in detail mode.</i>

104 Current Alarm Status Commands

name	Type	Description
soho-gen-opt-sig-low	Parameter type: <Alarm::ONTGENERALLEVELLO> (yes no) Possible values: - yes : optical signal level is too low - no : optical signal level is normal	Optical signal level is too low <i>This element is only shown in detail mode.</i>
soho-gen-eqpt-prov-nsa	Parameter type: <Alarm::ONTGENERALONTNSAMEA> (yes no) Possible values: - yes : non service affects mismatch between ont equipment and ont provisioning attributes - no : ont is provisioned properly	non service affects mismatch between ont equipment and ont provisioning attributes <i>This element is only shown in detail mode.</i>

104.120 MDU ONT General Current Alarm Status Command

Command Description

This command displays the MDU ONT general current alarm status.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

> show alarm current mdu-gen [(index)]

Command Parameters

Table 104.120-1 "MDU ONT General Current Alarm Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm type

Command Output

Table 104.120-2 "MDU ONT General Current Alarm Status Command" Display parameters

Specific Information		
name	Type	Description
ont	Parameter type: <Gpon::OntIndex> (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> ng2 : <Ng2::ChannelGroup> / <Ng2::SubchannelGroup> / <Ng2::OntId>) Possible values: - ng2 : ngpon2 style identification Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Ng2::ChannelGroup>	gpon ont equipment ifindex of ont <i>This element is only shown in detail mode.</i>

104 Current Alarm Status Commands

name	Type	Description
	- channel group number Field type <Ng2::SubchannelGroup> - subchannel group number Field type <Eqpt::OntId> - the ONT identifier Field type <Ng2::OntId> - the ONT identifier	

Only Show Details: current alarm status		
name	Type	Description
mdu-gen-omci-fail	Parameter type: <Alarm::ONTGENERALOMCICOMM> (yes no) Possible values: - yes : ont fails to respond to omci message requests - no : ont responds to omci message requests works properly	ont fails to respond to omci message requests <i>This element is only shown in detail mode.</i>
mdu-gen-eqpt-selftest	Parameter type: <Alarm::ONTGENERALEQPT> (yes no) Possible values: - yes : ont has failed a self test - no : ont self test works properly	ont has failed a self-test <i>This element is only shown in detail mode.</i>
mdu-gen-ac-pwr-fail	Parameter type: <Alarm::ONTGENERALACFAIL> (yes no) Possible values: - yes : loss of external ac power to the ont - no : external ac power to the ont is ok	loss of external ac power to the ont" <i>This element is only shown in detail mode.</i>
mdu-gen-bat-missing	Parameter type: <Alarm::ONTGENERALBATTMIS> (yes no) Possible values: - yes : battery is provisioned for ont but is missing - no : battery is provisioned and present for ont	battery is provisioned for ont but is missing <i>This element is only shown in detail mode.</i>
mdu-gen-bat-low	Parameter type: <Alarm::ONTGENERALBATTLLOW> (yes no) Possible values: - yes : battery charge is low - no : battery charge is ok	battery charge is low <i>This element is only shown in detail mode.</i>
mdu-gen-bat-fail	Parameter type: <Alarm::ONTGENERALBATTFAIL> (yes no) Possible values: - yes : battery is provisioned and present but cannot recharge - no : battery is provisioned and present and can recharge	battery is provisioned and present but cannot recharge <i>This element is only shown in detail mode.</i>
mdu-gen-phys-intrusion	Parameter type: <Alarm::ONTGENERALINTRUDER> (yes no) Possible values: - yes : unauthorized access to ont and door or box is open - no : authorized access to ont	unauthorized access to ont <i>This element is only shown in detail mode.</i>
mdu-gen-sw-dnload-f	Parameter type: <Alarm::ONTGENERALSWDLFAIL> (yes no) Possible values: - yes : download of software to ont has failed - no : download of software to ont works properly	download of software to ont has failed <i>This element is only shown in detail mode.</i>

name	Type	Description
mdu-gen-sw-act-fail	Parameter type: <Alarm::ONTGENERALSWACTFAIL> (yes no) Possible values: - yes : ont failed to activate the passive image designated by the olt - no : ont works properly to activate the passive image designated by the olt	ont failed to activate the passive image designated by the olt <i>This element is only shown in detail mode.</i>
mdu-gen-sw-dnload-p	Parameter type: <Alarm::ONTGENERALSWDLIP> (yes no) Possible values: - yes : a condition meaning that a transfer of ont software from the olt to the ont is pending or is actually being transmitted - no : a condition meaning that a transfer of ont software from the olt to the ont is not ready	a condition meaning that a transfer of ont software from the olt to the ont is pending or is actually being transmitted <i>This element is only shown in detail mode.</i>
mdu-gen-eqpt-vers-mis	Parameter type: <Alarm::ONTGENERALEQVERMIS> (yes no) Possible values: - yes : a condition meaning the provisioned ont equipment part number does not match the version reported by the ont - no : a condition meaning that provisioned ont equipment part number matches the version reported by the ont	a condition meaning the provisioned ont equipment part number does not match the version reported by the ont <i>This element is only shown in detail mode.</i>
mdu-gen-sw-vers-mis	Parameter type: <Alarm::ONTGENERALSWVER> (yes no) Possible values: - yes : a condition meaning that the planned software version does not equal the active software version - no : a condition meaning that the planned software version equals the active software version	a condition meaning that the planned software version does not equal the active software version <i>This element is only shown in detail mode.</i>
mdu-gen-us-rate-mis	Parameter type: <Alarm::ONTGENERALUSRATE> (yes no) Possible values: - yes : a condition meaning that the planned upstream rate and the actual upstream rate do not match - no : a condition meaning that the planned upstream rate and the actual upstream rate match	a condition meaning that the planned upstream rate and the actual upstream rate do not match <i>This element is only shown in detail mode.</i>
mdu-gen-eqpt-prov-sa	Parameter type: <Alarm::ONTGENERALONTMEA> (yes no) Possible values: - yes : mismatch between ont equipment and ont provisioning attributes - no : match between ont equipment and ont provisioning attributes	mismatch between ont equipment and ont provisioning attributes <i>This element is only shown in detail mode.</i>
mdu-gen-mdu-env1	Parameter type: <Alarm::ONTGENERALENV1> (yes no) Possible values: - yes : mdu environmental alarm1 - no : do not detect the mdu environmental alarm1	mdu environmental alarm1 <i>This element is only shown in detail mode.</i>
mdu-gen-mdu-env2	Parameter type: <Alarm::ONTGENERALENV2> (yes	mdu environmental alarm2 <i>This element is only shown in</i>

104 Current Alarm Status Commands

name	Type	Description
	no) Possible values: - yes : mdu environmental alarm2 - no : do not detect the mdu environmental alarm2	<i>detail mode.</i>
mdu-gen-mdv-env3	Parameter type: <Alarm::ONTGENERALENV3> (yes no) Possible values: - yes : mdu environmental alarm3 - no : do not detect the mdu environmental alarm3	mdv environmental alarm3 <i>This element is only shown in detail mode.</i>
mdv-gen-nw-time-err	Parameter type: <Alarm::ONTGENERALNTPERR> (yes no) Possible values: - yes : a condition meaning the ont is unable to establish timing from the ntp server(s) - no : a condition meaning the ont is able to establish timing from the ntp server(s)	a condition meaning the ont is unable to establish timing from the ntp server(s) <i>This element is only shown in detail mode.</i>
mdv-gen-opt-sig-high	Parameter type: <Alarm::ONTGENERALLEVELHI> (yes no) Possible values: - yes : optical signal level is too high - no : optical signal level is normal	optical signal level is too high <i>This element is only shown in detail mode.</i>
mdv-gen-opt-sig-low	Parameter type: <Alarm::ONTGENERALLEVELLO> (yes no) Possible values: - yes : optical signal level is too low - no : optical signal level is normal	Optical signal level is too low <i>This element is only shown in detail mode.</i>
mdv-gen-eqpt-prov-nsa	Parameter type: <Alarm::ONTGENERALONTNSAMEA> (yes no) Possible values: - yes : non service affects mismatch between ont equipment and ont provisioning attributes - no : ont is provisioned properly	non service affects mismatch between ont equipment and ont provisioning attributes <i>This element is only shown in detail mode.</i>

104.121 ONT SUBSCRIBER CARD Current Alarm Status Command

Command Description

This command displays the ONT SUBSCRIBER CARD current alarm status.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

> show alarm current ont-card [(index)]

Command Parameters

Table 104.121-1 "ONT SUBSCRIBER CARD Current Alarm Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm type

Command Output

Table 104.121-2 "ONT SUBSCRIBER CARD Current Alarm Status Command" Display parameters

Specific Information		
name	Type	Description
ont-card	Parameter type: <Gpon::OntSlotAlarmIndex2> (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Gpon::OntSlotId> ng2 : <Ng2::ChannelGroup> / <Ng2::SubchannelGroup> / <Ng2::OntId> / <Gpon::OntSlotId>) Possible values: - ng2 : ngpon2 style identification Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId>	gpon ont plan card <i>This element is only shown in detail mode.</i>

104 Current Alarm Status Commands

name	Type	Description
	- the PON identifier - Field type <Ng2::ChannelGroup> - channel group number - Field type <Ng2::SubchannelGroup> - subchannel group number - Field type <Eqpt::OntId> - the ONT identifier - Field type <Ng2::OntId> - the ONT identifier - Field type <Gpon::OntSlotId> - Gpon Ont Slot - range: [1...14]	

Only Show Details: current alarm status		
name	Type	Description
ont-sbscr-lim-missing	Parameter type: <Alarm::ONTCARDLIMMISSING> (yes no) Possible values: - yes : provisioned ont card missing - no : provisioned ont card works properly	provisioned ont card missing <i>This element is only shown in detail mode.</i>
ont-sbscr-lim-type-mis	Parameter type: <Alarm::ONTCARDLIMMEA> (yes no) Possible values: - yes : plug-in ont card is wrong type - no : ont card works properly	plug-in ont card is wrong type <i>This element is only shown in detail mode.</i>
ont-sbscr-lim-removal	Parameter type: <Alarm::ONTCARDLIMIMPROPRMVL> (yes no) Possible values: - yes : ont card removed without being deprovisioned - no : ont card removed correctly	ont card removed without being deprovisioned <i>This element is only shown in detail mode.</i>
ont-sbscr-lim-fail	Parameter type: <Alarm::ONTCARDLIMFAIL> (yes no) Possible values: - yes : ont card failed detected or failed self test - no : ont card works properly	ont card failed detected or failed self test <i>This element is only shown in detail mode.</i>
ont-sbscr-lim-svc-mis	Parameter type: <Alarm::ONTCARDLIMSVCNIS> (yes no) Possible values: - yes : ont did not accept the omci configuration requests for the provisioned onu card - no : ont card works properly	ont did not accept the omci configuration requests for the provisioned onu card <i>This element is only shown in detail mode.</i>
ont-sbscr-lim-port-mis	Parameter type: <Alarm::ONTCARDLIMNUMPORTSMIS> (yes no) Possible values: - yes : the actual number of ports of a plug-in ont card is different from the planned number of ports - no : the actual number of ports of a plug-in ont card is the same to the planned number of ports	the actual number of ports of a plug-in ont card is different from the planned number of ports <i>This element is only shown in detail mode.</i>

104.122 ONT SERVICES POTS Current Alarm Status Command

Command Description

This command displays the ONT SERVICES POTS current alarm status.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

> show alarm current ont-pots [(index)]

Command Parameters

Table 104.122-1 "ONT SERVICES POTS Current Alarm Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm type

Command Output

Table 104.122-2 "ONT SERVICES POTS Current Alarm Status Command" Display parameters

Specific Information		
name	Type	Description
ont-pots	Parameter type: <Gpon::OntPotsAlarmIndex2> (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Gpon::OntSlotId> / <Gpon::OntPotsPortId> ng2 : <Ng2::ChannelGroup> / <Ng2::SubchannelGroup> / <Ng2::OntId> / <Gpon::OntSlotId> / <Gpon::OntPotsPortId>) Possible values: - ng2 : ngpon2 style identification Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId>	gpon ont pots port index <i>This element is only shown in detail mode.</i>

104 Current Alarm Status Commands

name	Type	Description
	- the PON identifier Field type <Ng2::ChannelGroup> - channel group number Field type <Ng2::SubchannelGroup> - subchannel group number Field type <Eqpt::OntId> - the ONT identifier Field type <Ng2::OntId> - the ONT identifier Field type <Gpon::OntSlotId> - Gpon Ont Slot - range: [1...14] Field type <Gpon::OntPotsPortId> - Gpon Ont Pots Port - range: [1...24]	

Only Show Details: current alarm status		
name	Type	Description
ont-svc-pots-svc-mis	Parameter type: <Alarm::ONTPOTSSVCMIS> (yes no) Possible values: - yes : ont service mismatch for provisioned pots - no : ont service pots works properly	ont service mismatch for provisioned pots <i>This element is only shown in detail mode.</i>
ont-svc-pots-rtcp-lost	Parameter type: <Alarm::ONTPOTSRTCPSTREAMLOSS> (yes no) Possible values: - yes : pots realtime transport control protocol stream lost - no : ont service pots works properly	pots realtime transport control protocol stream lost <i>This element is only shown in detail mode.</i>
ont-svc-pots-icnf-subs	Parameter type: <Alarm::ONTPOTSICONFIGSUBFAIL> (yes no) Possible values: - yes : iconfig subscription of the pots line failed - no : ont service pots works properly	pots line iconfig subscription failure <i>This element is only shown in detail mode.</i>
ont-svc-pots-icnf-ntfy	Parameter type: <Alarm::ONTPOTSICONFIGNOTIFYFAIL> (yes no) Possible values: - yes : iconfig notify failed for a pots line - no : ont service pots works properly	pots line iconfig notify failure <i>This element is only shown in detail mode.</i>
ont-svc-pots-icnf-http	Parameter type: <Alarm::ONTPOTSICONFIGHTTPFAIL> (yes no) Possible values: - yes : iconfig http redirect failed for a pots line - no : ont service pots works properly	pots line iconfig http failure <i>This element is only shown in detail mode.</i>
ont-svc-pots-sip-reg	Parameter type: <Alarm::ONTPOTSSIPREGFAIL> (yes no) Possible values: - yes : sip registration failed for the pots line - no : ont service pots works properly	pots line sip registration failure <i>This element is only shown in detail mode.</i>
ont-svc-pots-sip-inv	Parameter type: <Alarm::ONTPOTSSIPINVITEFAIL> (yes no)	pots line sip invite request failure <i>This element is only shown in detail mode.</i>

name	Type	Description
	Possible values: - yes : sip invite request for the pots line failed - no : ont service pots works properly	
ont-svc-pots-sip-subsc	Parameter type: <Alarm::ONTPOTSSIPSUBFAIL> (yes no) Possible values: - yes : sip subscribe failed for the pots line - no : ont service pots works properly	pots line sip subscribe failure <i>This element is only shown in detail mode.</i>
ont-svc-pots-sip-mt-tc	Parameter type: <Alarm::ONTPOTSSIPMSGTMOUTTCA> (yes no) Possible values: - yes : number of sip message timeouts threshold has crossed for the pots line - no : ont service pots works properly	pots line sip message timeout threshold crossed <i>This element is only shown in detail mode.</i>
ont-svc-pots-pk-loss-tc	Parameter type: <Alarm::ONTPOTSRTTPKTLOSSTCA> (yes no) Possible values: - yes : number of rtp bearer packets loss on a pots line has been crossed - no : ont service pots works properly	pots line rtp bearer packets loss threshold crossed <i>This element is only shown in detail mode.</i>
ont-svc-pots-jitter-tc	Parameter type: <Alarm::ONTPOTSJITTERTCA> (yes no) Possible values: - yes : rtp jitter threshold has been crossed on a pots line - no : ont service pots works properly	pots line rtp jitter threshold crossed <i>This element is only shown in detail mode.</i>
ont-svc-pots-subs-dns	Parameter type: <Alarm::ONTPOTSICNFSUBSDNS> (yes no) Possible values: - yes : iconfig subscription failed because domain name could not be resolved - no : ont service pots works properly	iconfig subscription failed <i>This element is only shown in detail mode.</i>
ont-svc-pots-subs-tcp	Parameter type: <Alarm::ONTPOTSICNFSUBSTCP> (yes no) Possible values: - yes : iconfig subscription failed because of TCP socket - no : ont service pots works properly	iconfig subscription failed <i>This element is only shown in detail mode.</i>
ont-svc-pots-subs-tls	Parameter type: <Alarm::ONTPOTSICNFSUBSTLS> (yes no) Possible values: - yes : iconfig subscription failed because of TLS session - no : ont service pots works properly	iconfig subscription failed <i>This element is only shown in detail mode.</i>
ont-svc-pots-subs-auth	Parameter type: <Alarm::ONTPOTSICNFSUBSAUTH> (yes no) Possible values: - yes : iconfig subscription failed because authentication failed - no : ont service pots works properly	iconfig subscription failed <i>This element is only shown in detail mode.</i>
ont-svc-pots-subs-to	Parameter type: <Alarm::ONTPOTSICNFSUBSTO>	iconfig subscription failed

104 Current Alarm Status Commands

name	Type	Description
	(yes no) Possible values: - yes : iconfig subscription failed because of retransmission timeout - no : ont service pots works properly	<i>This element is only shown in detail mode.</i>
ont-svc-pots-sub-err	Parameter type: <Alarm::ONTPOTSICNFSUBSERR> (yes no) Possible values: - yes : iconfig subscription failed because of response error - no : ont service pots works properly	iconfig subscription failed <i>This element is only shown in detail mode.</i>
ont-svc-pots-not-to	Parameter type: <Alarm::ONTPOTSICNFNOTTO> (yes no) Possible values: - yes : iconfig notification failed because of retransmission timeout - no : ont service pots works properly	iconfig notification failed <i>This element is only shown in detail mode.</i>
ont-svc-pots-notref-to	Parameter type: <Alarm::ONTPOTSICNFNOTREFTO> (yes no) Possible values: - yes : iconfig notification refresh failed because of timeout - no : ont service pots works properly	iconfig notification failed <i>This element is only shown in detail mode.</i>
ont-svc-pots-not-mal	Parameter type: <Alarm::ONTPOTSICNFNOTMAL> (yes no) Possible values: - yes : iconfig notification refresh failed because of a malformed message - no : ont service pots works properly	iconfig notification failed <i>This element is only shown in detail mode.</i>
ont-svc-pots-not-rej	Parameter type: <Alarm::ONTPOTSICNFNOTREJ> (yes no) Possible values: - yes : iconfig notification refresh failed because it was rejected by the server - no : ont service pots works properly	iconfig notification failed <i>This element is only shown in detail mode.</i>
ont-svc-pots-http-dns	Parameter type: <Alarm::ONTPOTSICNFHTTPTDNS> (yes no) Possible values: - yes : iconfig doc retrieval failed because domain name could not be resolved - no : ont service pots works properly	iconfig doc retrieval failed <i>This element is only shown in detail mode.</i>
ont-svc-pots-http-tcp	Parameter type: <Alarm::ONTPOTSICNFHTTPTCP> (yes no) Possible values: - yes : iconfig doc retrieval failed because of TCP socket - no : ont service pots works properly	iconfig doc retrieval failed <i>This element is only shown in detail mode.</i>
ont-svc-pots-http-tls	Parameter type: <Alarm::ONTPOTSICNFHTTPTLS> (yes no) Possible values: - yes : iconfig doc retrieval failed because of TLS session	iconfig doc retrieval failed <i>This element is only shown in detail mode.</i>

name	Type	Description
	- no : ont service pots works properly	
ont-svc-pots-http-auth	Parameter type: <Alarm::ONTPOTSICNFHTTPAUTH> (yes no) Possible values: - yes : iconfig doc retrieval failed because authentication failed - no : ont service pots works properly	iconfig doc retrieval failed <i>This element is only shown in detail mode.</i>
ont-svc-pots-http-to	Parameter type: <Alarm::ONTPOTSICNFHTTPTO> (yes no) Possible values: - yes : iconfig doc retrieval failed because of retransmission timeout - no : ont service pots works properly	iconfig doc retrieval failed <i>This element is only shown in detail mode.</i>
ont-svc-pots-http-err	Parameter type: <Alarm::ONTPOTSICNFHTTTPERR> (yes no) Possible values: - yes : iconfig doc retrieval failed because of response error - no : ont service pots works properly	iconfig doc retrieval failed <i>This element is only shown in detail mode.</i>
ont-svc-pots-http-mal	Parameter type: <Alarm::ONTPOTSICNFHTTPMAL> (yes no) Possible values: - yes : iconfig doc retrieval failed because of a malformed message - no : ont service pots works properly	iconfig doc retrieval failed <i>This element is only shown in detail mode.</i>
ont-svc-pots-insuff	Parameter type: <Alarm::ONTPOTSINSUFF> (yes no) Possible values: - yes : iconfig service failed because of insufficient data - no : ont VOIP service pots works properly	iconfig VOIP service failed <i>This element is only shown in detail mode.</i>
ont-svc-pots-poos	Parameter type: <Alarm::ONTPOTSPOOS> (yes no) Possible values: - yes : pots ports out of service - no : pots ports work properly	pots ports out of service <i>This element is only shown in detail mode.</i>

104.123 ONT SERVICES LAN Current Alarm Status Command

Command Description

This command displays the ONT SERVICES LAN current alarm status.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm current ont-lan [ (index) ]
```

Command Parameters

Table 104.123-1 "ONT SERVICES LAN Current Alarm Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm type

Command Output

Table 104.123-2 "ONT SERVICES LAN Current Alarm Status Command" Display parameters

Specific Information		
name	Type	Description
ont-port	Parameter type: <Gpon::IfIndexAlarmIndex2> (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Gpon::OntSlotId> / <Gpon::OntPortId> ng2 : <Ng2::ChannelGroup> / <Ng2::SubchannelGroup> / <Ng2::OntId> / <Gpon::OntSlotId> / <Gpon::OntPortId>) Possible values: - ng2 : ngpon2 style identification Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier	gpon ont port <i>This element is only shown in detail mode.</i>

name	Type	Description
	Field type <Ng2::ChannelGroup> - channel group number Field type <Ng2::SubchannelGroup> - subchannel group number Field type <Eqpt::OntId> - the ONT identifier Field type <Ng2::OntId> - the ONT identifier Field type <Gpon::OntSlotId> - Gpon Ont Slot - range: [1...14] Field type <Gpon::OntPortId> - Gpon Ont Port - range: [1...16]	

Only Show Details: current alarm status		
name	Type	Description
ont-svc-lan-mismatch	Parameter type: <Alarm::ONTLANSVCMIS> (yes no) Possible values: - yes : the ont did not accept the omci configuration requests for the lan service - no : ont service lan works properly	ont service mismatch for lan <i>This element is only shown in detail mode.</i>
ont-svc-lan-loss-sig	Parameter type: <Alarm::ONTLANLOS> (yes no) Possible values: - yes : loss of signal on an ethernet port interface - no : ont service lan works properly	loss of signal on an ethernet port interface <i>This element is only shown in detail mode.</i>
ont-svc-enet-poos	Parameter type: <Alarm::ONTENETPOOS> (yes no) Possible values: - yes : ethernet ports out of service - no : ethernet ports work properly	ethernet ports out of service <i>This element is only shown in detail mode.</i>

104.124 ONT TCA Current Alarm Status Command

Command Description

This command displays the ONT TCA current alarm status.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

> show alarm current ont-tca [(index)]

Command Parameters

Table 104.124-1 "ONT TCA Current Alarm Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm type

Command Output

Table 104.124-2 "ONT TCA Current Alarm Status Command" Display parameters

Specific Information		
name	Type	Description
ont	Parameter type: <Gpon::OntIndex> (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> ng2 : <Ng2::ChannelGroup> / <Ng2::SubchannelGroup> / <Ng2::OntId>) Possible values: - ng2 : ngpon2 style identification Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Ng2::ChannelGroup> - channel group number Field type <Ng2::SubchannelGroup> - subchannel group number Field type <Eqpt::OntId>	gpon ont equipment ifindex of ont <i>This element is only shown in detail mode.</i>

name	Type	Description
	- the ONT identifier Field type <Ng2::OntId> - the ONT identifier	

Only Show Details: current alarm status		
name	Type	Description
ont-cpu-util-tca	Parameter type: <Alarm::ONTTCACPUUTIL> (yes no) Possible values: - yes : ONT CPU utilization threshold crossed - no : ont works properly	ONT CPU utilization threshold crossed <i>This element is only shown in detail mode.</i>
ont-mem-util-tca	Parameter type: <Alarm::ONTTCAMEMUTIL> (yes no) Possible values: - yes : ONT memory utilization threshold crossed - no : ont works properly	ONT memory utilization threshold crossed <i>This element is only shown in detail mode.</i>

104.125 ONT TC TCA Current Alarm Status Command

Command Description

This command displays the ONT TC TCA current alarm status.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm current ont-tc-tca [ (index) ]
```

Command Parameters

Table 104.125-1 "ONT TC TCA Current Alarm Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm type

Command Output

Table 104.125-2 "ONT TC TCA Current Alarm Status Command" Display parameters

Specific Information		
name	Type	Description
ont	Parameter type: <Gpon::OntIndex> (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> ng2 : <Ng2::ChannelGroup> / <Ng2::SubchannelGroup> / <Ng2::OntId>) Possible values: - ng2 : ngpon2 style identification Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Ng2::ChannelGroup>	gpon ont equipment ifindex of ont <i>This element is only shown in detail mode.</i>

name	Type	Description
	- channel group number Field type <Ng2::SubchannelGroup> - subchannel group number Field type <Eqpt::OntId> - the ONT identifier Field type <Ng2::OntId> - the ONT identifier	

Only Show Details: current alarm status		
name	Type	Description
ont-tc-rx-los-frag-tc	Parameter type: <Alarm::ONTTCTCARLOSTFRAGS> (yes no) Possible values: - yes : rx loss of gem fragments threshold crossed - no : ont works properly	rx loss of gem fragments threshold crossed <i>This element is only shown in detail mode.</i>
ont-tc-tx-los-frag-tc	Parameter type: <Alarm::ONTTCTCATLOSTFRAGS> (yes no) Possible values: - yes : tx loss of gem fragments threshold crossed - no : ont works properly	tx loss of gem fragments threshold crossed <i>This element is only shown in detail mode.</i>
ont-tc-bad-gem-hd-tc	Parameter type: <Alarm::ONTTCTCABADGEMHDRS> (yes no) Possible values: - yes : bad gem header threshold crossed - no : ont works properly	bad gem header threshold crossed <i>This element is only shown in detail mode.</i>

104.126 ONT L2 UNI Ethernet TCA Current Alarm Status Command

Command Description

This command displays the ONT L2 UNI Ethernet TCA current alarm status.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm current ont-l2uni-eth-tca [ (index) ]
```

Command Parameters

Table 104.126-1 " ONT L2 UNI Ethernet TCA Current Alarm Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm type

Command Output

Table 104.126-2 " ONT L2 UNI Ethernet TCA Current Alarm Status Command" Display parameters

Specific Information		
name	Type	Description
ont-port	Parameter type: <Gpon::IfIndexAlarmIndex2> (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Gpon::OntSlotId> / <Gpon::OntPortId> ng2 : <Ng2::ChannelGroup> / <Ng2::SubchannelGroup> / <Ng2::OntId> / <Gpon::OntSlotId> / <Gpon::OntPortId>) Possible values: - ng2 : ngpon2 style identification Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number	gpon ont port spindex <i>This element is only shown in detail mode.</i>

name	Type	Description
	Field type <Eqpt::PonId> - the PON identifier Field type <Ng2::ChannelGroup> - channel group number Field type <Ng2::SubchannelGroup> - subchannel group number Field type <Eqpt::OntId> - the ONT identifier Field type <Ng2::OntId> - the ONT identifier Field type <Gpon::OntSlotId> - Gpon Ont Slot - range: [1...14] Field type <Gpon::OntPortId> - Gpon Ont Port - range: [1...16]	

Only Show Details: current alarm status		
name	Type	Description
ont-uni-ds-drpdr-fr-tc	Parameter type: <Alarm::ONTL2UNIETHTCADSDRPDFRMS> (yes no) Possible values: - yes : downstream l2 dropped frames threshold crossed - no : ont works properly	downstream l2 dropped frames threshold crossed <i>This element is only shown in detail mode.</i>
ont-uni-up-drpdr-fr-tc	Parameter type: <Alarm::ONTL2UNIETHTCASDRPDFRMS> (yes no) Possible values: - yes : upstream l2 dropped frames threshold crossed - no : ont works properly	upstream l2 dropped frames threshold crossed <i>This element is only shown in detail mode.</i>
ont-uni-ds-crc-fr-tc	Parameter type: <Alarm::ONTL2UNIDSCRCRDPDFRMS> (yes no) Possible values: - yes : downstream l2 rx crc error frames threshold crossed - no : ont works properly	downstream l2 rx crc error frames threshold crossed <i>This element is only shown in detail mode.</i>
ont-uni-up-crc-fr-tc	Parameter type: <Alarm::ONTL2UNIUPCRCRDPDFRMS> (yes no) Possible values: - yes : upstream l2 rx crc error frames threshold crossed - no : ont works properly	upstream l2 rx crc error frames threshold crossed <i>This element is only shown in detail mode.</i>

104.127 OLT PON TC TCA Current Alarm Status Command

Command Description

This command displays the OLT PON TC TCA current alarm status.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm current olt-pon-tc-tca [ (index) ]
```

Command Parameters

Table 104.127-1 " OLT PON TC TCA Current Alarm Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm type

Command Output

Table 104.127-2 " OLT PON TC TCA Current Alarm Status Command" Display parameters

Specific Information		
name	Type	Description
pon	Parameter type: <Gpon::PonId> (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> x-pon : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::XPonId> 25g-pon : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::M25GPonId>) Possible values: - 25g-pon : 25g pon - x-pon : Xgs pon Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number	gpon pon ifindex <i>This element is only shown in detail mode.</i>

name	Type	Description
	Field type <Eqpt::PonId> - the PON identifier Field type <Eqpt::XPonId> - the XGS PON identifier Field type <Eqpt::M25GPonId> - the 25G PON identifier	

Only Show Details: current alarm status		
name	Type	Description
olt-pon-tc-err-frag-tc	Parameter type: <Alarm::OLTPONTCTCAERRFRAGSPON> (yes no) Possible values: - yes : pon errored fragments threshold crossed - no : olt works properly	pon errored fragments threshold crossed <i>This element is only shown in detail mode.</i>
olt-pon-up-bw-tca	Parameter type: <Alarm::OLTPONTCTCAUPBWTCA> (yes no) Possible values: - yes : olt pon upstream bandwidth tca - no : olt works properly	OLT PON upstream bandwidth TCA <i>This element is only shown in detail mode.</i>
olt-pon-down-bw-tca	Parameter type: <Alarm::OLTPONTCTCADWBWTCA> (yes no) Possible values: - yes : olt pon downstream bandwidth tca - no : olt works properly	OLT PON downstream bandwidth TCA <i>This element is only shown in detail mode.</i>

104.128 OLT PON Utilization TCA Current Alarm Status Command

Command Description

This command displays the OLT PON utilization TCA current alarm status.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm current olt-pon-util-tca [ (index) ]
```

Command Parameters

Table 104.128-1 " OLT PON Utilization TCA Current Alarm Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm type

Command Output

Table 104.128-2 " OLT PON Utilization TCA Current Alarm Status Command" Display parameters

Specific Information		
name	Type	Description
pon	Parameter type: <Gpon::PonId> (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> x-pon : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::XPonId> 25g-pon : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::M25GPonId>) Possible values: - 25g-pon : 25g pon - x-pon : Xgs pon Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number	gpon pon ifindex <i>This element is only shown in detail mode.</i>

name	Type	Description
	Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Eqpt::XPonId> - the XGS PON identifier Field type <Eqpt::M25GPonId> - the 25G PON identifier	

Only Show Details: current alarm status		
name	Type	Description
pon-t-txmcutilhi	Parameter type: <Alarm::TXMCUTILHI> (yes no) Possible values: - yes : tx mcast utilization high tca - no : olt works properly	pon utilization tx (downstream) multicast high threshold crossed <i>This element is only shown in detail mode.</i>
pon-t-txmcutilmd	Parameter type: <Alarm::TXMCUTILMD> (yes no) Possible values: - yes : tx mcast utilization medium tca - no : olt works properly	pon utilization tx (downstream) multicast medium threshold crossed <i>This element is only shown in detail mode.</i>
pon-t-txmcutillo	Parameter type: <Alarm::TXMCUTILLO> (yes no) Possible values: - yes : tx mcast utilization low tca - no : olt works properly	pon utilization tx (downstream) multicast low threshold crossed <i>This element is only shown in detail mode.</i>
pon-t-txtotutilhi	Parameter type: <Alarm::TXTOTUTILHI> (yes no) Possible values: - yes : tx total utilization high tca - no : olt works properly	pon utilization tx (downstream) total high threshold crossed <i>This element is only shown in detail mode.</i>
pon-t-txtotutilmd	Parameter type: <Alarm::TXTOTUTILMD> (yes no) Possible values: - yes : tx total utilization medium tca - no : olt works properly	pon utilization tx (downstream) total medium threshold crossed <i>This element is only shown in detail mode.</i>
pon-t-txtotutillo	Parameter type: <Alarm::TXTOTUTILLO> (yes no) Possible values: - yes : tx total utilization low tca - no : olt works properly	pon utilization tx (downstream) total low threshold crossed <i>This element is only shown in detail mode.</i>
pon-t-rxtotutilhi	Parameter type: <Alarm::RXTOTUTILHI> (yes no) Possible values: - yes : rx total utilization high tca - no : olt works properly	pon utilization rx (upstream) total high threshold crossed <i>This element is only shown in detail mode.</i>
pon-t-rxtotutilmd	Parameter type: <Alarm::RXTOTUTILMD> (yes no) Possible values: - yes : rx total utilization medium tca	pon utilization rx (upstream) total medium threshold crossed <i>This element is only shown in detail mode.</i>

104 Current Alarm Status Commands

name	Type	Description
	- no : olt works properly	
pon-t-rxtotutillo	Parameter type: <Alarm::RXTOTUTILLO> (yes no) Possible values: - yes : rx total utilization low tca - no : olt works properly	pon utilization rx (upstream) total low threshold crossed <i>This element is only shown in detail mode.</i>
pon-t-dbacongperiodhi	Parameter type: <Alarm::DBACONGPERIODHI> (yes no) Possible values: - yes : rx dba congestion period high tca - no : olt works properly	pon utilization rx (upstream) dbacongperiod high threshold crossed <i>This element is only shown in detail mode.</i>
pon-t-dbacongperiodmd	Parameter type: <Alarm::DBACONGPERIODMD> (yes no) Possible values: - yes : rx dba congestion period medium tca - no : olt works properly	pon utilization rx (upstream) dbacongperiod medium threshold crossed <i>This element is only shown in detail mode.</i>
pon-t-dbacongperiodlo	Parameter type: <Alarm::DBACONGPERIODLO> (yes no) Possible values: - yes : rx dba congestion period low tca - no : olt works properly	pon utilization rx (upstream) dbacongperiod low threshold crossed <i>This element is only shown in detail mode.</i>
pon-t-txucdropfrmhi	Parameter type: <Alarm::TXUCDROPFRMHI> (yes no) Possible values: - yes : tx unicast dropped packet high tca - no : olt works properly	pon utilization tx (downstream) unicast drop frame high threshold crossed <i>This element is only shown in detail mode.</i>
pon-t-txucdropfrmmd	Parameter type: <Alarm::TXUCDROPFRMMD> (yes no) Possible values: - yes : tx unicast dropped packet medium tca - no : olt works properly	pon utilization tx (downstream) unicast drop frame medium threshold crossed <i>This element is only shown in detail mode.</i>
pon-t-txucdropfrmlo	Parameter type: <Alarm::TXUCDROPFRMLO> (yes no) Possible values: - yes : tx unicast dropped packet low tca - no : olt works properly	pon utilization tx (downstream) unicast drop frame low threshold crossed <i>This element is only shown in detail mode.</i>
pon-t-txmcdropfrmhi	Parameter type: <Alarm::TXMCDROPFRMHI> (yes no) Possible values: - yes : tx multicast dropped packet high tca - no : olt works properly	pon utilization tx (downstream) multicast drop frame high threshold crossed <i>This element is only shown in detail mode.</i>
pon-t-txmcdropfrmmd	Parameter type: <Alarm::TXMCDROPFRMMD> (yes no) Possible values: - yes : tx multicast dropped packet medium tca - no : olt works properly	pon utilization tx (downstream) multicast drop frame medium threshold crossed <i>This element is only shown in detail mode.</i>
pon-t-txmcdropfrmlo	Parameter type: <Alarm::TXMCDROPFRMLO> (yes	pon utilization tx (downstream) multicast drop frame low

name	Type	Description
	no) Possible values: - yes : tx multicast dropped packet low tca - no : olt works properly	threshold crossed <i>This element is only shown in detail mode.</i>
pon-t-txbcdropfrmhi	Parameter type: <Alarm::TXBCDROPPFRMHI> (yes no) Possible values: - yes : tx broadcast dropped packet high tca - no : olt works properly	pon utilization tx (downstream) broadcast drop frame high threshold crossed <i>This element is only shown in detail mode.</i>
pon-t-txbcdropfrmmd	Parameter type: <Alarm::TXBCDROPPFRMMD> (yes no) Possible values: - yes : tx broadcast dropped packet medium tca - no : olt works properly	pon utilization tx (downstream) broadcast drop frame medium threshold crossed <i>This element is only shown in detail mode.</i>
pon-t-txbcdropfrmlo	Parameter type: <Alarm::TXBCDROPPFRMLO> (yes no) Possible values: - yes : tx broadcast dropped packet low tca - no : olt works properly	pon utilization tx (downstream) broadcast drop frame low threshold crossed <i>This element is only shown in detail mode.</i>
pon-t-rxtotdropfrmhi	Parameter type: <Alarm::RXTOTDROPPFRMHI> (yes no) Possible values: - yes : rx total dropped packet high tca - no : olt works properly	pon utilization rx (upstream) total drop frame high threshold crossed <i>This element is only shown in detail mode.</i>
pon-t-rxtotdropfrmmd	Parameter type: <Alarm::RXTOTDROPPFRMMD> (yes no) Possible values: - yes : rx total dropped packet medium tca - no : olt works properly	pon utilization rx (upstream) total drop frame medium threshold crossed <i>This element is only shown in detail mode.</i>
pon-t-rxtotdropfrmlo	Parameter type: <Alarm::RXTOTDROPPFRMLO> (yes no) Possible values: - yes : rx total dropped packet low tca - no : olt works properly	pon utilization rx (upstream) total drop frame low threshold crossed <i>This element is only shown in detail mode.</i>

104.129 OLT Channel Pair Utilization TCA Current Alarm Status Command

Command Description

This command displays the channel-pair utilization TCA current alarm status.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm current olt-chpr-util-tca [ (index) ]
```

Command Parameters

Table 104.129-1 "OLT Channel Pair Utilization TCA Current Alarm Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm type

Command Output

Table 104.129-2 "OLT Channel Pair Utilization TCA Current Alarm Status Command" Display parameters

Specific Information		
name	Type	Description
channel-pair	Parameter type: <Gpon::ChannelPairId> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::ChannelPairId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::ChannelPairId> - the channel pair identifier	channel-pair ifindex <i>This element is only shown in detail mode.</i>

Only Show Details: current alarm status		
name	Type	Description
chpr-t-txmcutilhi	Parameter type: <Alarm::TXMCUTILHI>	channel-pair utilization tx

name	Type	Description
	(yes no) Possible values: - yes : tx mcast utilization high tca - no : olt works properly	(downstream) multicast high threshold crossed <i>This element is only shown in detail mode.</i>
chpr-t-txmcutilmd	Parameter type: <Alarm::TXMCUTILMD> (yes no) Possible values: - yes : tx mcast utilization medium tca - no : olt works properly	channel-pair utilization tx (downstream) multicast medium threshold crossed <i>This element is only shown in detail mode.</i>
chpr-t-txmcutillo	Parameter type: <Alarm::TXMCUTILLO> (yes no) Possible values: - yes : tx mcast utilization low tca - no : olt works properly	channel-pair utilization tx (downstream) multicast low threshold crossed <i>This element is only shown in detail mode.</i>
chpr-t-txtotutilhi	Parameter type: <Alarm::TXTOTUTILHI> (yes no) Possible values: - yes : tx total utilization high tca - no : olt works properly	channel-pair utilization tx (downstream) total high threshold crossed <i>This element is only shown in detail mode.</i>
chpr-t-txtotutilmd	Parameter type: <Alarm::TXTOTUTILMD> (yes no) Possible values: - yes : tx total utilization medium tca - no : olt works properly	channel-pair utilization tx (downstream) total medium threshold crossed <i>This element is only shown in detail mode.</i>
chpr-t-txtotutillo	Parameter type: <Alarm::TXTOTUTILLO> (yes no) Possible values: - yes : tx total utilization low tca - no : olt works properly	channel-pair utilization tx (downstream) total low threshold crossed <i>This element is only shown in detail mode.</i>
chpr-t-rxtotutilhi	Parameter type: <Alarm::RXTOTUTILHI> (yes no) Possible values: - yes : rx total utilization high tca - no : olt works properly	channel-pair utilization rx (upstream) total high threshold crossed <i>This element is only shown in detail mode.</i>
chpr-t-rxtotutilmd	Parameter type: <Alarm::RXTOTUTILMD> (yes no) Possible values: - yes : rx total utilization medium tca - no : olt works properly	channel-pair utilization rx (upstream) total medium threshold crossed <i>This element is only shown in detail mode.</i>
chpr-t-rxtotutillo	Parameter type: <Alarm::RXTOTUTILLO> (yes no) Possible values: - yes : rx total utilization low tca - no : olt works properly	channel-pair utilization rx (upstream) total low threshold crossed <i>This element is only shown in detail mode.</i>
chpr-t-dbacongperiodhi	Parameter type: <Alarm::DBACONGPERIODHI> (yes no) Possible values:	channel-pair utilization rx (upstream) dbacongperiod high threshold crossed <i>This element is only shown in</i>

104 Current Alarm Status Commands

name	Type	Description
	- yes : rx dba congestion period high tca - no : olt works properly	<i>detail mode.</i>
chpr-t-dbacongperiodmd	Parameter type: <Alarm::DBACONGPERIODMD> (yes no) Possible values: - yes : rx dba congestion period medium tca - no : olt works properly	channel-pair utilization rx (upstream) dbacongperiod medium threshold crossed <i>This element is only shown in detail mode.</i>
chpr-t-dbacongperiodlo	Parameter type: <Alarm::DBACONGPERIODLO> (yes no) Possible values: - yes : rx dba congestion period low tca - no : olt works properly	channel-pair utilization rx (upstream) dbacongperiod low threshold crossed <i>This element is only shown in detail mode.</i>
chpr-t-txucdropfrmhi	Parameter type: <Alarm::TXUCDROPFRMHI> (yes no) Possible values: - yes : tx unicast dropped packet high tca - no : olt works properly	channel-pair utilization tx (downstream) unicast drop frame high threshold crossed <i>This element is only shown in detail mode.</i>
chpr-t-txucdropfrmmd	Parameter type: <Alarm::TXUCDROPFRMMD> (yes no) Possible values: - yes : tx unicast dropped packet medium tca - no : olt works properly	channel-pair utilization tx (downstream) unicast drop frame medium threshold crossed <i>This element is only shown in detail mode.</i>
chpr-t-txucdropfrmlo	Parameter type: <Alarm::TXUCDROPFRMLO> (yes no) Possible values: - yes : tx unicast dropped packet low tca - no : olt works properly	channel-pair utilization tx (downstream) unicast drop frame low threshold crossed <i>This element is only shown in detail mode.</i>
chpr-t-txmcdropfrmhi	Parameter type: <Alarm::TXMCDROPFRMHI> (yes no) Possible values: - yes : tx multicast dropped packet high tca - no : olt works properly	channel-pair utilization tx (downstream) multicast drop frame high threshold crossed <i>This element is only shown in detail mode.</i>
chpr-t-txmcdropfrmmd	Parameter type: <Alarm::TXMCDROPFRMMD> (yes no) Possible values: - yes : tx multicast dropped packet medium tca - no : olt works properly	channel-pair utilization tx (downstream) multicast drop frame medium threshold crossed <i>This element is only shown in detail mode.</i>
chpr-t-txmcdropfrmlo	Parameter type: <Alarm::TXMCDROPFRMLO> (yes no) Possible values: - yes : tx multicast dropped packet low tca - no : olt works properly	channel-pair utilization tx (downstream) multicast drop frame low threshold crossed <i>This element is only shown in detail mode.</i>
chpr-t-txbcdropfrmhi	Parameter type: <Alarm::TXBCDROPFRMHI> (yes no) Possible values: - yes : tx broadcast dropped packet high tca - no : olt works properly	channel-pair utilization tx (downstream) broadcast drop frame high threshold crossed <i>This element is only shown in detail mode.</i>
chpr-t-txbcdropfrmmd	Parameter type: <Alarm::TXBCDROPFRMMD>	channel-pair utilization tx

name	Type	Description
	(yes no) Possible values: - yes : tx broadcast dropped packet medium tca - no : olt works properly	(downstream) broadcast drop frame medium threshold crossed <i>This element is only shown in detail mode.</i>
chpr-t-txbcdropfrmlo	Parameter type: <Alarm::TXBCDROPPFRMLO> (yes no) Possible values: - yes : tx broadcast dropped packet low tca - no : olt works properly	channel-pair utilization tx (downstream) broadcast drop frame low threshold crossed <i>This element is only shown in detail mode.</i>
chpr-t-rxtotdropfrmhi	Parameter type: <Alarm::RXTOTDROPPFRMHI> (yes no) Possible values: - yes : rx total dropped packet high tca - no : olt works properly	channel-pair utilization rx (upstream) total drop frame high threshold crossed <i>This element is only shown in detail mode.</i>
chpr-t-rxtotdropfrmmd	Parameter type: <Alarm::RXTOTDROPPFRMMD> (yes no) Possible values: - yes : rx total dropped packet medium tca - no : olt works properly	channel-pair utilization rx (upstream) total drop frame medium threshold crossed <i>This element is only shown in detail mode.</i>
chpr-t-rxtotdropfrmlo	Parameter type: <Alarm::RXTOTDROPPFRMLO> (yes no) Possible values: - yes : rx total dropped packet low tca - no : olt works properly	channel-pair utilization rx (upstream) total drop frame low threshold crossed <i>This element is only shown in detail mode.</i>

104.130 OLT ONT TC TCA Current Alarm Status Command

Command Description

This command displays the OLT ONT TC TCA current alarm status.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

> show alarm current olt-ont-tc-tca [(index)]

Command Parameters

Table 104.130-1 " OLT ONT TC TCA Current Alarm Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm type

Command Output

Table 104.130-2 " OLT ONT TC TCA Current Alarm Status Command" Display parameters

Specific Information		
name	Type	Description
ont	Parameter type: <Gpon::OntIndex> (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> ng2 : <Ng2::ChannelGroup> / <Ng2::SubchannelGroup> / <Ng2::OntId>) Possible values: - ng2 : ngpon2 style identification Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Ng2::ChannelGroup>	gpon ont equipment ifindex of ont <i>This element is only shown in detail mode.</i>

name	Type	Description
	- channel group number Field type <Ng2::SubchannelGroup> - subchannel group number Field type <Eqpt::OntId> - the ONT identifier Field type <Ng2::OntId> - the ONT identifier	

Only Show Details: current alarm status		
name	Type	Description
olt-ont-tc-err-frag-tc	Parameter type: <Alarm::OLTONTTCTCAERRFRAGSONT> (yes no) Possible values: - yes : ont errored fragments threshold crossed - no : olt works properly	ont errored fragments threshold crossed <i>This element is only shown in detail mode.</i>

104.131 ONT POTS SUPPLEMENTAL Current Alarm Status Command

Command Description

This command displays the ONT POTS SUPPLEMENTAL current alarm status.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

> show alarm current ont-pots-supplemental [(index)]

Command Parameters

Table 104.131-1 " ONT POTS SUPPLEMENTAL Current Alarm Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm type

Command Output

Table 104.131-2 " ONT POTS SUPPLEMENTAL Current Alarm Status Command" Display parameters

Specific Information		
name	Type	Description
ont-port	Parameter type: <Gpon::IfIndexAlarmIndex2> (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Gpon::OntSlotId> / <Gpon::OntPortId> ng2 : <Ng2::ChannelGroup> / <Ng2::SubchannelGroup> / <Ng2::OntId> / <Gpon::OntSlotId> / <Gpon::OntPortId>) Possible values: - ng2 : ngpon2 style identification Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number	gpon ont port <i>This element is only shown in detail mode.</i>

name	Type	Description
	Field type <Eqpt::PonId> - the PON identifier Field type <Ng2::ChannelGroup> - channel group number Field type <Ng2::SubchannelGroup> - subchannel group number Field type <Eqpt::OntId> - the ONT identifier Field type <Ng2::OntId> - the ONT identifier Field type <Gpon::OntSlotId> - Gpon Ont Slot - range: [1...14] Field type <Gpon::OntPortId> - Gpon Ont Port - range: [1...16]	

Only Show Details: current alarm status		
name	Type	Description
ont-sip-reg-dns	Parameter type: <Alarm::ONTSERVICESPOTSSIPREGDNS> (yes no) Possible values: - yes : sip registration failed because the domain name could not be resolved - no : sip registration succeeds	ont services pots sip registration failed (resolving domain name) <i>This element is only shown in detail mode.</i>
ont-sip-reg-fail	Parameter type: <Alarm::ONTSERVICESPOTSSIPREGAUTH> (yes no) Possible values: - yes : sip registration failed because authentication failed - no : sip registration succeeds	ont services pots sip registration authentication failed <i>This element is only shown in detail mode.</i>
ont-sip-reg-timeout	Parameter type: <Alarm::ONTSERVICESPOTSSIPREGTO> (yes no) Possible values: - yes : sip registration failed because all attempted retransmissions timed out - no : sip registration succeeds	ont services pots sip registration timeout <i>This element is only shown in detail mode.</i>
ont-sip-reg-err-resps	Parameter type: <Alarm::ONTSERVICESPOTSSIPREGERR> (yes no) Possible values: - yes : sip registration failed because error response from the registration server - no : sip registration succeeds	ont services pots sip registration response error <i>This element is only shown in detail mode.</i>
ont-sip-inv-dns	Parameter type: <Alarm::ONTSERVICESPOTSSIPINVDNS> (yes no) Possible values: - yes : sip invite failed because the domain name could not be resolved - no : sip invite succeeds	ont services pots sip invite failed (resolving domain name) <i>This element is only shown in detail mode.</i>

104 Current Alarm Status Commands

name	Type	Description
ont-sip-inv-auth	Parameter type: <Alarm::ONTSERVICESPOTSSIPINVAUTH> (yes no) Possible values: - yes : sip invite failed because authentication failed - no : sip invite succeeds	ont services pots sip invite authentication failed <i>This element is only shown in detail mode.</i>
ont-sip-inv-timeout	Parameter type: <Alarm::ONTSERVICESPOTSSIPINVTO> (yes no) Possible values: - yes : sip invite failed because all attempted retransmissions timed out - no : sip invite succeeds	ont services pots sip invite timeout <i>This element is only shown in detail mode.</i>
ont-sip-inv-err	Parameter type: <Alarm::ONTSERVICESPOTSSIPINVERR> (yes no) Possible values: - yes : sip invite failed because error response from the registration server - no : sip invite succeeds	ont services pots sip invite response error <i>This element is only shown in detail mode.</i>
ont-svc-pots-subs-refr	Parameter type: <Alarm::ONTSERVICESPOTSSUBSREFR> (yes no) Possible values: - yes : pots iconfig subscription could not be refreshed - no : pots iconfig subscription refreshed	ont services pots iconfig subscription could not be refreshed <i>This element is only shown in detail mode.</i>
ont-svc-pots-not-refr	Parameter type: <Alarm::ONTSERVICESPOTSNOTREFR> (yes no) Possible values: - yes : pots iconfig notify response for refresh subscribe failed - no : pots iconfig notify response for refresh subscribe succeeds	ont services pots iconfig notification could not be refreshed <i>This element is only shown in detail mode.</i>
ont-svc-pots-icfg-err	Parameter type: <Alarm::ONTSERVICESPOTSICFGERR> (yes no) Possible values: - yes : pots service failed due to an unmapped iconfig error - no : pots service works properly	ont services pots service failed due to an unmapped iconfig error <i>This element is only shown in detail mode.</i>

104.132 ONT VEIP Current Alarm Status Command

Command Description

This command displays the ONT VEIP current alarm status.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

> show alarm current ont-veip [(index)]

Command Parameters

Table 104.132-1 " ONT VEIP Current Alarm Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm type

Command Output

Table 104.132-2 " ONT VEIP Current Alarm Status Command" Display parameters

Specific Information		
name	Type	Description
ont-port	Parameter type: <Gpon::IfIndexAlarmIndex2> (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Gpon::OntSlotId> / <Gpon::OntPortId> ng2 : <Ng2::ChannelGroup> / <Ng2::SubchannelGroup> / <Ng2::OntId> / <Gpon::OntSlotId> / <Gpon::OntPortId>) Possible values: - ng2 : ngpon2 style identification Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Ng2::ChannelGroup> - channel group number Field type <Ng2::SubchannelGroup> - subchannel group number	gpon ont port <i>This element is only shown in detail mode.</i>

104 Current Alarm Status Commands

name	Type	Description
	Field type <Eqpt::OntId> - the ONT identifier Field type <Ng2::OntId> - the ONT identifier Field type <Gpon::OntSlotId> - Gpon Ont Slot - range: [1...14] Field type <Gpon::OntPortId> - Gpon Ont Port - range: [1...16]	

Only Show Details: current alarm status		
name	Type	Description
ont-veip-mismatch	Parameter type: <Alarm::ONTVEIPMISMATCH> (yes no) Possible values: - yes : ont veip mismatch - no : ont veip match	ont veip mismatch <i>This element is only shown in detail mode.</i>

104.133 ONT IP HOST Current Alarm Status Command

Command Description

This command displays the ONT IP HOST current alarm status.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm current ont-iphost [ (index) ]
```

Command Parameters

Table 104.133-1 " ONT IP HOST Current Alarm Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm type

Command Output

Table 104.133-2 " ONT IP HOST Current Alarm Status Command" Display parameters

Specific Information		
name	Type	Description
port	Parameter type: <Gpon::IpHostCommonIndex> (ont : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Gpon::IpHostId> vlanport : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / vuni : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlanport : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / vuni : <Eqpt::UnstackedVlan> ont.ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / <Ng2::IpHostId> vlanport.ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / vuni : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlanport.ng2 : <Eqpt::ChannelGroupId> /	gpon iphost port <i>This element is only shown in detail mode.</i>

104 Current Alarm Status Commands

name	Type	Description
	<Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / vuni : <Eqpt::UnstackedVlan>) Possible values: - ont:ng2 : ngpon2 ont - vlanport:ng2 : ngpon2 vlanport - ont : ont - vlanport : vlanport Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Eqpt::OntId> - the ONT identifier Field type <Eqpt::ChannelGroupId> - the channel group identifier Field type <Eqpt::SubChannelGroupId> - the subchannel group identifier Field type <Eqpt::Ng2OntId> - the NG2 ONT identifier Possible values: - vuni : virtual uni identifier Possible values: - vuni : virtual NGPON2 uni identifier Field type <Gpon::IpHostID> - iphost id Field type <Ng2::IpHostID> - iphost id (ngpon2) Possible values: - stacked : stacked vlan identity Field type <Eqpt::UnstackedVlan> - unstacked vlan id Field type <Eqpt::SVlan> - service vlan id Field type <Eqpt::CVlan> - customer vlan id	

Only Show Details: current alarm status		
name	Type	Description
ont-ip-host-mismatch	Parameter type: <Alarm::ONTIPHOS TMIS> (yes no) Possible values: - yes : ont ip host mismatch - no : ont ip host match	ont ip host mismatch <i>This element is only shown in detail mode.</i>
ont-ip-host-ip-alloc	Parameter type: <Alarm::ONTIPHOS TFAIL> (yes no) Possible values: - yes : ont ip host IP allocation failure - no : ont ip host IP allocation works properly	ont ip host IP allocation failure <i>This element is only shown in detail mode.</i>

104.134 Alarm Table Current Alarm Status Command

Command Description

This command displays the alarm-table current alarm status.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

> show alarm current alarm-table [(index)]

Command Parameters

Table 104.134-1 "Alarm Table Current Alarm Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm type

Command Output

Table 104.134-2 "Alarm Table Current Alarm Status Command" Display parameters

Specific Information		
name	Type	Description
last-updated-on	Parameter type: <Sys::timeInSecs> - the time (yyyy-mm-dd:hour:minutes:secs) - unit: UTC	network time in seconds when the alarm was logged. <i>This element is only shown in detail mode.</i>

Only Show Details: current alarm status		
name	Type	Description
alarm-tbl-overflow	Parameter type: <Alarm::AlrmTblOflow> (overflow no-overflow) Possible values: - overflow : alarm table overflow - no-overflow : no alarm table overflow	identify if the alarm table has overflowed <i>This element is only shown in detail mode.</i>

104.135 ONT VIDEO Current Alarm Status Command

Command Description

This command displays the ONT VIDEO current alarm status.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm current ont-video [ (index) ]
```

Command Parameters

Table 104.135-1 " ONT VIDEO Current Alarm Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm type

Command Output

Table 104.135-2 " ONT VIDEO Current Alarm Status Command" Display parameters

Specific Information		
name	Type	Description
video-port	Parameter type: <Gpon::IfIndexAlarmIndex2> (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Gpon::OntSlotId> / <Gpon::OntPortId> ng2 : <Ng2::ChannelGroup> / <Ng2::SubchannelGroup> / <Ng2::OntId> / <Gpon::OntSlotId> / <Gpon::OntPortId>) Possible values: - ng2 : ngpon2 style identification Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier	video port <i>This element is only shown in detail mode.</i>

name	Type	Description
	Field type <Ng2::ChannelGroup> - channel group number Field type <Ng2::SubchannelGroup> - subchannel group number Field type <Eqpt::OntId> - the ONT identifier Field type <Ng2::OntId> - the ONT identifier Field type <Gpon::OntSlotId> - Gpon Ont Slot - range: [1...14] Field type <Gpon::OntPortId> - Gpon Ont Port - range: [1...16]	

Only Show Details: current alarm status

name	Type	Description
ont-svc-video-conf-mis	Parameter type: <Alarm::ONTVIDEOUNISVCMIS> (yes no) Possible values: - yes : config request failure for video service - no : ont service is ok	config request failure for video service <i>This element is only shown in detail mode.</i>
ont-svc-video-pw-high	Parameter type: <Alarm::ONTRFOUTHIGH> (yes no) Possible values: - yes : high power level for rf video signal - no : ont service is ok	high power level for rf video signal <i>This element is only shown in detail mode.</i>
ont-svc-video-pw-low	Parameter type: <Alarm::ONTRFOUTLOW> (yes no) Possible values: - yes : low power level for rf video signal - no : ont service is ok	low power level for rf video signal <i>This element is only shown in detail mode.</i>

104.136 ONT CES Current Alarm Status Command

Command Description

This command displays the ONT CES current alarm status.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm current ont-ces [ (index) ]
```

Command Parameters

Table 104.136-1 " ONT CES Current Alarm Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm type

Command Output

Table 104.136-2 " ONT CES Current Alarm Status Command" Display parameters

Specific Information		
name	Type	Description
cesds1-port	Parameter type: <Gpon::IfIndexAlarmIndex2> (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Gpon::OntSlotId> / <Gpon::OntPortId> ng2 : <Ng2::ChannelGroup> / <Ng2::SubchannelGroup> / <Ng2::OntId> / <Gpon::OntSlotId> / <Gpon::OntPortId>) Possible values: - ng2 : ngpon2 style identification Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Ng2::ChannelGroup> - channel group number Field type <Ng2::SubchannelGroup> - subchannel group number	ces port <i>This element is only shown in detail mode.</i>

name	Type	Description
	Field type <Eqpt::OntId> - the ONT identifier Field type <Ng2::OntId> - the ONT identifier Field type <Gpon::OntSlotId> - Gpon Ont Slot - range: [1...14] Field type <Gpon::OntPortId> - Gpon Ont Port - range: [1...16]	

Only Show Details: current alarm status		
name	Type	Description
ont-svc-ces-ds1-mis	Parameter type: <Alarm::ONTCESDS1SVCNIS> (yes no) Possible values: - yes : ont service mismatch for provisioned ces ds1 - no : ont service is ok	ont service mismatch for provisioned ces ds1 <i>This element is only shown in detail mode.</i>
ont-svc-ces-ds1-los	Parameter type: <Alarm::ONTCESDS1LOS> (yes no) Possible values: - yes : loss of signal at ds1 interface - no : ont service is ok	loss of signal at ds1 interface <i>This element is only shown in detail mode.</i>
ont-svc-ces-ds1-lof	Parameter type: <Alarm::ONTCESDS1LOF> (yes no) Possible values: - yes : loss of frame at ds1 interface - no : ont service is ok	loss of frame at ds1 interface <i>This element is only shown in detail mode.</i>
ont-svc-ces-ds1-rair	Parameter type: <Alarm::ONTCESDS1RAIR> (yes no) Possible values: - yes : receiving rai at ds1 interface - no : ont service is ok	receiving rai at ds1 interface <i>This element is only shown in detail mode.</i>
ont-svc-ces-ds1-ais	Parameter type: <Alarm::ONTCESDS1AISR> (yes no) Possible values: - yes : receiving ais at ds1 interface - no : ont service is ok	receiving ais at ds1 interface <i>This element is only shown in detail mode.</i>
ont-svc-ces-ds1-lnlpbk	Parameter type: <Alarm::ONTCESDS1LNLBPBK> (yes no) Possible values: - yes : receiving line loopback at ds1 interface - no : ont service is ok	receiving line loopback at ds1 interface <i>This element is only shown in detail mode.</i>
ont-svc-ces-ds1-tmlpbk	Parameter type: <Alarm::ONTCESDS1TMLPBK> (yes no) Possible values: - yes : receiving terminal loopback at ds1 interface - no : ont service is ok	receiving terminal loopback at ds1 interface <i>This element is only shown in detail mode.</i>

104.137 ONT VOIP Current Alarm Status Command

Command Description

This command displays the ONT VOIP current alarm status.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

> show alarm current ont-voip [(index)]

Command Parameters

Table 104.137-1 " ONT VOIP Current Alarm Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm type

Command Output

Table 104.137-2 " ONT VOIP Current Alarm Status Command" Display parameters

Specific Information		
name	Type	Description
voip-uni	Parameter type: <Gpon::VoipOntIndex> (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / 1 ng2 : <Ng2::ChannelGroup> / <Ng2::SubchannelGroup> / <Ng2::OntId> / 1) Possible values: - ng2 : ngpon2 style identification Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Eqpt::OntId> - the ONT identifier Possible values: - 1 : Gpon voip Port Field type <Ng2::ChannelGroup>	uni ifindex <i>This element is only shown in detail mode.</i>

name	Type	Description
	- channel group number Field type <Ng2::SubchannelGroup> - subchannel group number Field type <Ng2::OntId> - the ONT identifier Possible values: - 1 : Gpon voip Port	
client-number	Parameter type: <Gpon::AlarmIndex2Integer> - a signed integer	service client number <i>This element is only shown in detail mode.</i>

Only Show Details: current alarm status

name	Type	Description
ont-svc-voip-cnf-file	Parameter type: <Alarm::ONTVOICONFIGFLERR> (yes no) Possible values: - yes : voice configuration file error - no : ont service is ok	voice configuration file error <i>This element is only shown in detail mode.</i>
ont-svc-voip-svc-mis	Parameter type: <Alarm::ONTVOICLISERMIS> (yes no) Possible values: - yes : service mismatch for provisioned client service - no : ont service is ok	service mismatch for provisioned client service <i>This element is only shown in detail mode.</i>
ont-svc-voip-gw-comm	Parameter type: <Alarm::ONTVOIGATWCOMFAIL> (yes no) Possible values: - yes : voice gateway communication failure - no : ont service is ok	voice gateway communication failure <i>This element is only shown in detail mode.</i>
ont-svc-voip-dhcp-fail	Parameter type: <Alarm::ONTVOIDHCPSEFAIL> (yes no) Possible values: - yes : voice gateway communication failure - no : ont service is ok	voice dhcp server failure <i>This element is only shown in detail mode.</i>
ont-svc-voip-icnf-sub	Parameter type: <Alarm::ONTVOIICONSUBFAIL> (yes no) Possible values: - yes : voice iconfig subscription failure - no : ont service is ok	voice iconfig subscription failure <i>This element is only shown in detail mode.</i>
ont-svc-voip-icnf-ntfy	Parameter type: <Alarm::ONTVOIICONNOTFAIL> (yes no) Possible values: - yes : voice iconfig notify failure - no : ont service is ok	voice iconfig notify failure <i>This element is only shown in detail mode.</i>
ont-svc-voip-icnf-http	Parameter type: <Alarm::ONTVOIICONHTTPFAIL> (yes no) Possible values: - yes : voice iconfig http failure - no : ont service is ok	voice iconfig http failure <i>This element is only shown in detail mode.</i>
ont-svc-voip-dhcp-to	Parameter type: <Alarm::ONTVOIDHCPTO> (yes no)	DHCP server retransmissions timed out <i>This element is only shown in</i>

104 Current Alarm Status Commands

name	Type	Description
	Possible values: - yes : DHCP server retransmissions timed out - no : ont service is ok	<i>detail mode.</i>
ont-svc-voip-dhcp-mal	Parameter type: <Alarm::ONTVOIDHCPMAL> (yes no) Possible values: - yes : DHCP response was malformed - no : ont service is ok	DHCP response was malformed <i>This element is only shown in detail mode.</i>
ont-svc-voip-dhcp-noad	Parameter type: <Alarm::ONTVOIDHCPNOAD> (yes no) Possible values: - yes : DHCP server failed to issue the required parameters - no : ont service is ok	DHCP server failed to issue the required parameters <i>This element is only shown in detail mode.</i>
ont-svc-voip-dhcp-leas	Parameter type: <Alarm::ONTVOIDHCPLEAS> (yes no) Possible values: - yes : DHCP Server failure due to problem in lease renewal - no : ont service is ok	DHCP Server failure due to problem in lease renewal <i>This element is only shown in detail mode.</i>
ont-svc-voip-subscription-dns	Parameter type: <Alarm::ONTVOIICONDNS> (yes no) Possible values: - yes : iConfig Subscription failure due to DNS problem - no : ont service is ok	iConfig Subscription failure due to DNS problem <i>This element is only shown in detail mode.</i>
ont-svc-voip-subscription-tcp	Parameter type: <Alarm::ONTVOIICONTCP> (yes no) Possible values: - yes : iConfig Subscription failure due to TCP socket problem - no : ont service is ok	iConfig Subscription failure due to TCP socket problem <i>This element is only shown in detail mode.</i>
ont-svc-voip-subscription-tls	Parameter type: <Alarm::ONTVOIICONTLS> (yes no) Possible values: - yes : iConfig Subscription failure due to TLS session problem - no : ont service is ok	iConfig Subscription failure due to TLS session problem <i>This element is only shown in detail mode.</i>
ont-svc-voip-subscription-auth	Parameter type: <Alarm::ONTVOIICONAUTH> (yes no) Possible values: - yes : iConfig Subscription failure due to authentication error - no : ont service is ok	iConfig Subscription failure due to authentication error <i>This element is only shown in detail mode.</i>
ont-svc-voip-subscription-timeout	Parameter type: <Alarm::ONTVOIICONSUBSTO> (yes no) Possible values: - yes : iConfig Subscription failure due to retransmission timeout - no : ont service is ok	iConfig Subscription failure due to retransmission timeout <i>This element is only shown in detail mode.</i>
ont-svc-voip-subscription-error	Parameter type: <Alarm::ONTVOIICONSUBSERR> (yes	iConfig Subscription failure due to response error

name	Type	Description
	no) Possible values: - yes : iConfig Subscription failure due to response error - no : ont service is ok	<i>This element is only shown in detail mode.</i>
ont-svc-voip-not-to	Parameter type: <Alarm::ONTVOIICONNOTTO> (yes no) Possible values: - yes : iConfig Notify response timeout for new subscription - no : ont service is ok	iConfig Notify response is malformed <i>This element is only shown in detail mode.</i>
ont-svc-voip-notref-to	Parameter type: <Alarm::ONTVOIICONNOTREFTO> (yes no) Possible values: - yes : iConfig Notify response timeout for subscription refresh - no : ont service is ok	iConfig Notify response timeout for subscription refresh <i>This element is only shown in detail mode.</i>
ont-svc-voip-not-mal	Parameter type: <Alarm::ONTVOIICONNOTMAL> (yes no) Possible values: - yes : iConfig Notify response is malformed - no : ont service is ok	iConfig Notify response is malformed <i>This element is only shown in detail mode.</i>
ont-svc-voip-not-rej	Parameter type: <Alarm::ONTVOIICONNOTREJ> (yes no) Possible values: - yes : iConfig subscription request rejected by configuration server - no : ont service is ok	iConfig subscription request rejected by configuration server <i>This element is only shown in detail mode.</i>
ont-svc-voip-http-dns	Parameter type: <Alarm::ONTVOIHTTPDNS> (yes no) Possible values: - yes : VOIP client can't retrieve config doc due to DNS problem - no : ont service is ok	VOIP client can't retrieve config doc due to DNS problem <i>This element is only shown in detail mode.</i>
ont-svc-voip-http-tcp	Parameter type: <Alarm::ONTVOIHTTPTCP> (yes no) Possible values: - yes : VOIP client can't retrieve config doc due to TCP socket problem - no : ont service is ok	VOIP client can't retrieve config doc due to TCP socket problem <i>This element is only shown in detail mode.</i>
ont-svc-voip-http-tls	Parameter type: <Alarm::ONTVOIHTTPTLS> (yes no) Possible values: - yes : VOIP client can't retrieve config doc due to TLS session problem - no : ont service is ok	VOIP client can't retrieve config doc due to TLS session problem <i>This element is only shown in detail mode.</i>
ont-svc-voip-http-auth	Parameter type: <Alarm::ONTVOIHTTPAUTH> (yes no) Possible values: - yes : VOIP client can't retrieve config doc due to auth error - no : ont service is ok	VOIP client can't retrieve config doc due to auth error <i>This element is only shown in detail mode.</i>

104 Current Alarm Status Commands

name	Type	Description
ont-svc-voip-http-to	Parameter type: <Alarm::ONTVOIHTTPTO> (yes no) Possible values: - yes : VOIP client can't retrieve config doc due to re-tx timeout - no : ont service is ok	VOIP client can't retrieve config doc due to re-tx timeout <i>This element is only shown in detail mode.</i>
ont-svc-voip-http-err	Parameter type: <Alarm::ONTVOIHTTPERR> (yes no) Possible values: - yes : VOIP client can't retrieve config doc due to response error - no : ont service is ok	VOIP client can't retrieve config doc due to response error <i>This element is only shown in detail mode.</i>
ont-svc-voip-http-mal	Parameter type: <Alarm::ONTVOIICONHTTPMAL> (yes no) Possible values: - yes : iConfig configuration document is malformed - no : ont service is ok	iConfig configuration document is malformed <i>This element is only shown in detail mode.</i>
ont-svc-voip-sub-s-refr	Parameter type: <Alarm::ONTVOIICONSUBSREFR> (yes no) Possible values: - yes : iConfig Subscription refresh error - no : ont service is ok	iConfig Subscription refresh error <i>This element is only shown in detail mode.</i>
ont-svc-voip-not-refr	Parameter type: <Alarm::ONTVOIICONNOTREFR> (yes no) Possible values: - yes : iConfig Notify response for refresh subscribe failed - no : ont service is ok	iConfig Notify response for refresh subscribe failed <i>This element is only shown in detail mode.</i>
ont-svc-voip-icfg-err	Parameter type: <Alarm::ONTVOIICONERR> (yes no) Possible values: - yes : iConfig Configuration Error - no : ont service is ok	iConfig Configuration Error <i>This element is only shown in detail mode.</i>

104.138 ONT VIDEO ANI Current Alarm Status Command

Command Description

This command displays the ONT VIDEO ANI current alarm status.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

> show alarm current ont-video-ani [(index)]

Command Parameters

Table 104.138-1 " ONT VIDEO ANI Current Alarm Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm type

Command Output

Table 104.138-2 " ONT VIDEO ANI Current Alarm Status Command" Display parameters

Specific Information		
name	Type	Description
ont	Parameter type: <Gpon::OntIndex> (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> ng2 : <Ng2::ChannelGroup> / <Ng2::SubchannelGroup> / <Ng2::OntId>) Possible values: - ng2 : ngpon2 style identification Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Ng2::ChannelGroup>	gpon ont equipment ifindex of ont <i>This element is only shown in detail mode.</i>

104 Current Alarm Status Commands

name	Type	Description
	- channel group number Field type <Ng2::SubchannelGroup> - subchannel group number Field type <Eqpt::OntId> - the ONT identifier Field type <Ng2::OntId> - the ONT identifier	
vedio-ani-index	Parameter type: <Gpon::AlarmIndex2Integer> - a signed integer	vedio ani index <i>This element is only shown in detail mode.</i>

Only Show Details: current alarm status		
name	Type	Description
ont-svc-v-ani-conf-mis	Parameter type: <Alarm::ONTVIDEOANISVCMIS> (yes no) Possible values: - yes : config request failure for video ani service - no : ont service is ok	config request failure for video ani service <i>This element is only shown in detail mode.</i>
ont-svc-v-ani-loss-sig	Parameter type: <Alarm::ONTVIDEOLOS> (yes no) Possible values: - yes : video loss of signal on ani - no : ont service is ok	video loss of signal on ani <i>This element is only shown in detail mode.</i>
ont-svc-v-ani-lv-high	Parameter <Alarm::ONTVIDEOOPTSIGLEVELHIGH> (yes no) Possible values: - yes : high video optical signal level - no : ont service is ok	type: high video optical signal level <i>This element is only shown in detail mode.</i>
ont-svc-v-ani-lv-low	Parameter <Alarm::ONTVIDEOOPTSIGLEVELLOW> (yes no) Possible values: - yes : low video optical signal level - no : ont service is ok	type: low video optical signal level <i>This element is only shown in detail mode.</i>

104.139 ONT PWE Current Alarm Status Command

Command Description

This command displays the ONT PWE current alarm status.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

> show alarm current ont-pwe [(index)]

Command Parameters

Table 104.139-1 " ONT PWE Current Alarm Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm type

Command Output

Table 104.139-2 " ONT PWE Current Alarm Status Command" Display parameters

Specific Information		
name	Type	Description
ont-ces-uni	Parameter type: <Ces::InterfaceIndex> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> / <Eqpt::OntPortId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Eqpt::OntId> - the ONT identifier Field type <Eqpt::OntSlotId> - the ONT SLOT identifier Field type <Eqpt::OntPortId> - the ONT PORT identifier	ont ces uni <i>This element is only shown in detail mode.</i>
service-id	Parameter type: <Gpon::AlarmIndex2Integer>	service id

104 Current Alarm Status Commands

name	Type	Description
	- a signed integer	<i>This element is only shown in detail mode.</i>

Only Show Details: current alarm status		
name	Type	Description
ont-svc-pwe-mismatch	Parameter type: <Alarm::ONTPWESVCMIS> (yes no) Possible values: - yes : service mismatch for provisioned pseudowire - no : ont service is ok	service mismatch for provisioned pseudowire <i>This element is only shown in detail mode.</i>
ont-svc-pwe-reordr-lof	Parameter type: <Alarm::ONTPWELOSSREORDER> (yes no) Possible values: - yes : pseudowire reordering and loss of frame - no : ont service is ok	pseudowire reordering and loss of frame <i>This element is only shown in detail mode.</i>
ont-svc-pwe-jitt-buf-o	Parameter type: <Alarm::ONTPWEJBOVRRUN> (yes no) Possible values: - yes : pseudowire jitter buffer overrun - no : ont service is ok	pseudowire jitter buffer overrun <i>This element is only shown in detail mode.</i>
ont-svc-pwe-jitt-buf-u	Parameter type: <Alarm::ONTPWEJBUNDRUN> (yes no) Possible values: - yes : pseudowire jitter buffer underrun - no : ont service is ok	pseudowire jitter buffer underrun <i>This element is only shown in detail mode.</i>
ont-svc-pwe-malf-frms	Parameter type: <Alarm::ONTPWEMALFORM> (yes no) Possible values: - yes : pseudowire malformed frames - no : ont service is ok	pseudowire malformed frames <i>This element is only shown in detail mode.</i>
ont-svc-pwe-late-frms	Parameter type: <Alarm::ONTPWELATEFRMS> (yes no) Possible values: - yes : pseudowire late frames - no : ont service is ok	pseudowire late frames <i>This element is only shown in detail mode.</i>
ont-svc-pwe-link-loss	Parameter type: <Alarm::ONTPWELINKLOSS> (yes no) Possible values: - yes : pseudowire link loss - no : ont service is ok	pseudowire link loss <i>This element is only shown in detail mode.</i>
ont-svc-pwe-arp-fail	Parameter type: <Alarm::ONTPWEARPFail> (yes no) Possible values: - yes : pseudowire arp failure - no : ont service is ok	pseudowire arp failure <i>This element is only shown in detail mode.</i>

104.140 ONT CESE1 Current Alarm Status Command

Command Description

This command displays the ONT CESE1 current alarm status.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm current ont-cese1 [ (index) ]
```

Command Parameters

Table 104.140-1 " ONT CESE1 Current Alarm Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm type

Command Output

Table 104.140-2 " ONT CESE1 Current Alarm Status Command" Display parameters

Specific Information		
name	Type	Description
ces-port	Parameter type: <Gpon::IfIndexAlarmIndex2> (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Gpon::OntSlotId> / <Gpon::OntPortId> ng2 : <Ng2::ChannelGroup> / <Ng2::SubchannelGroup> / <Ng2::OntId> / <Gpon::OntSlotId> / <Gpon::OntPortId>) Possible values: - ng2 : ngpon2 style identification Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier	ces port <i>This element is only shown in detail mode.</i>

104 Current Alarm Status Commands

name	Type	Description
	Field type <Ng2::ChannelGroup> - channel group number Field type <Ng2::SubchannelGroup> - subchannel group number Field type <Eqpt::OntId> - the ONT identifier Field type <Ng2::OntId> - the ONT identifier Field type <Gpon::OntSlotId> - Gpon Ont Slot - range: [1...14] Field type <Gpon::OntPortId> - Gpon Ont Port - range: [1...16]	

Only Show Details: current alarm status		
name	Type	Description
ont-svc-ces-e1-mis	Parameter type: <Alarm::ONTCESE1SVCNIS> (yes no) Possible values: - yes : ont service mismatch for provisioned ces e1 - no : ont service is ok	ont service mismatch for provisioned ces e1 <i>This element is only shown in detail mode.</i>
ont-svc-ces-e1-los	Parameter type: <Alarm::ONTCESE1LOS> (yes no) Possible values: - yes : loss of signal at e1 interface - no : ont service is ok	loss of signal at e1 interface <i>This element is only shown in detail mode.</i>
ont-svc-ces-e1-lof	Parameter type: <Alarm::ONTCESE1LOF> (yes no) Possible values: - yes : loss of frame at e1 interface - no : ont service is ok	loss of frame at e1 interface <i>This element is only shown in detail mode.</i>
ont-svc-ces-e1-rair	Parameter type: <Alarm::ONTCESE1RAIR> (yes no) Possible values: - yes : receiving rai at e1 interface - no : ont service is ok	receiving rai at e1 interface <i>This element is only shown in detail mode.</i>
ont-svc-ces-e1-ais	Parameter type: <Alarm::ONTCESE1AISR> (yes no) Possible values: - yes : receiving ais at e1 interface - no : ont service is ok	receiving ais at e1 interface <i>This element is only shown in detail mode.</i>

104.141 ONT XDSL Current Alarm Status Command

Command Description

This command displays the ONT XDSL current alarm status.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

> show alarm current ont-xdsl [(index)]

Command Parameters

Table 104.141-1 " ONT XDSL Current Alarm Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm type

Command Output

Table 104.141-2 " ONT XDSL Current Alarm Status Command" Display parameters

Specific Information		
name	Type	Description
dsl-line-port	Parameter type: <Gpon::IfIndexAlarmIndex2> (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Gpon::OntSlotId> / <Gpon::OntPortId> ng2 : <Ng2::ChannelGroup> / <Ng2::SubchannelGroup> / <Ng2::OntId> / <Gpon::OntSlotId> / <Gpon::OntPortId>) Possible values: - ng2 : ngpon2 style identification Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Ng2::ChannelGroup> - channel group number Field type <Ng2::SubchannelGroup> - subchannel group number	dsl line port <i>This element is only shown in detail mode.</i>

104 Current Alarm Status Commands

name	Type	Description
	Field type <Eqpt::OntId> - the ONT identifier Field type <Ng2::OntId> - the ONT identifier Field type <Gpon::OntSlotId> - Gpon Ont Slot - range: [1...14] Field type <Gpon::OntPortId> - Gpon Ont Port - range: [1...16]	

Only Show Details: current alarm status		
name	Type	Description
ont-svc-xdsl-mismatch	Parameter type: <Alarm::ONTXDSLVCNIS> (yes no) Possible values: - yes : receiving ais at e1 interface - no : ont service is ok	service mismatch for provisioned xdsl <i>This element is only shown in detail mode.</i>
ont-svc-xdsl-ne-lof	Parameter type: <Alarm::ONTXLOF> (yes no) Possible values: - yes : near end loss of frame - no : ont service is ok	near end loss of frame <i>This element is only shown in detail mode.</i>
ont-svc-xdsl-ne-los	Parameter type: <Alarm::ONTXLOS> (yes no) Possible values: - yes : near end loss of signal - no : ont service is ok	near end loss of signal <i>This element is only shown in detail mode.</i>
ont-svc-xdsl-ne-line	Parameter type: <Alarm::ONTLINEINIT> (yes no) Possible values: - yes : near end line init - no : ont service is ok	near end line init <i>This element is only shown in detail mode.</i>
ont-svc-xdsl-ne-lol	Parameter type: <Alarm::ONTXLOL> (yes no) Possible values: - yes : near end loss of link - no : ont service is ok	near end loss of link <i>This element is only shown in detail mode.</i>
ont-svc-xdsl-fe-lof	Parameter type: <Alarm::ONTXLOFFE> (yes no) Possible values: - yes : far end loss of frame - no : ont service is ok	far end loss of frame <i>This element is only shown in detail mode.</i>
ont-svc-xdsl-fe-los	Parameter type: <Alarm::ONTXLOSFE> (yes no) Possible values: - yes : far end loss of signal - no : ont service is ok	far end loss of signal <i>This element is only shown in detail mode.</i>
ont-svc-xdsl-fe-lop	Parameter type: <Alarm::ONTXLOPFE> (yes no)	far end loss of power <i>This element is only shown in detail mode.</i>

name	Type	Description
	Possible values: - yes : far end loss of power - no : ont service is ok	
ont-svc-xdsl-cnf-err	Parameter type: <Alarm::ONTXDSL CNFG> (yes no) Possible values: - yes : xdsl provisioning error - no : ont service is ok	xdsl provisioning error <i>This element is only shown in detail mode.</i>

104.142 ONT XDSL TCA Current Alarm Status Command

Command Description

This command displays the ONT XDSL TCA current alarm status.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm current ont-xdsl-tca [ (index) ]
```

Command Parameters

Table 104.142-1 " ONT XDSL TCA Current Alarm Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm type

Command Output

Table 104.142-2 " ONT XDSL TCA Current Alarm Status Command" Display parameters

Specific Information		
name	Type	Description
dsl-line-port	Parameter type: <Gpon::IfIndexAlarmIndex2> (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Gpon::OntSlotId> / <Gpon::OntPortId> ng2 : <Ng2::ChannelGroup> / <Ng2::SubchannelGroup> / <Ng2::OntId> / <Gpon::OntSlotId> / <Gpon::OntPortId>) Possible values: - ng2 : ngpon2 style identification Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier	dsl line port <i>This element is only shown in detail mode.</i>

name	Type	Description
	Field type <Ng2::ChannelGroup> - channel group number Field type <Ng2::SubchannelGroup> - subchannel group number Field type <Eqpt::OntId> - the ONT identifier Field type <Ng2::OntId> - the ONT identifier Field type <Gpon::OntSlotId> - Gpon Ont Slot - range: [1...14] Field type <Gpon::OntPortId> - Gpon Ont Port - range: [1...16]	

Only Show Details: current alarm status		
name	Type	Description
ont-svc-xdsl-ne-es-tc	Parameter type: <Alarm::ONTXDSLES> (yes no) Possible values: - yes : near end errored seconds threshold crossed - no : ont service is ok	near end errored seconds threshold crossed <i>This element is only shown in detail mode.</i>
ont-svc-xdsl-ne-ses-tc	Parameter type: <Alarm::ONTXDSLSES> (yes no) Possible values: - yes : near end severe errored seconds threshold crossed - no : ont service is ok	near end severe errored seconds threshold crossed <i>This element is only shown in detail mode.</i>
ont-svc-xdsl-ne-uas-tc	Parameter type: <Alarm::ONTXDSLUS> (yes no) Possible values: - yes : ear end unavailable seconds threshold crossed - no : ont service is ok	ear end unavailable seconds threshold crossed <i>This element is only shown in detail mode.</i>
ont-svc-xdsl-fe-es-tc	Parameter type: <Alarm::ONTXDSLESFAREND> (yes no) Possible values: - yes : far end errored seconds threshold crossed - no : ont service is ok	far end errored seconds threshold crossed <i>This element is only shown in detail mode.</i>
ont-svc-xdsl-fe-ses-tc	Parameter type: <Alarm::ONTXDSLSESFAREND> (yes no) Possible values: - yes : far end severe errored seconds threshold crossed - no : ont service is ok	far end severe errored seconds threshold crossed <i>This element is only shown in detail mode.</i>
ont-svc-xdsl-fe-uas-tc	Parameter type: <Alarm::ONTXDSLUSFAREND> (yes no) Possible values: - yes : far end unavailable seconds threshold crossed - no : ont service is ok	far end unavailable seconds threshold crossed <i>This element is only shown in detail mode.</i>

104.143 ONT HPNA Current Alarm Status Command

Command Description

This command displays the ONT HPNA current alarm status.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm current ont-hpna [ (index) ]
```

Command Parameters

Table 104.143-1 " ONT HPNA Current Alarm Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm type

Command Output

Table 104.143-2 " ONT HPNA Current Alarm Status Command" Display parameters

Specific Information		
name	Type	Description
ont-port	Parameter type: <Gpon::IfIndexAlarmIndex2> (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Gpon::OntSlotId> / <Gpon::OntPortId> ng2 : <Ng2::ChannelGroup> / <Ng2::SubchannelGroup> / <Ng2::OntId> / <Gpon::OntSlotId> / <Gpon::OntPortId>) Possible values: - ng2 : ngpon2 style identification Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier	ont port <i>This element is only shown in detail mode.</i>

name	Type	Description
	Field type <Ng2::ChannelGroup> - channel group number Field type <Ng2::SubchannelGroup> - subchannel group number Field type <Eqpt::OntId> - the ONT identifier Field type <Ng2::OntId> - the ONT identifier Field type <Gpon::OntSlotId> - Gpon Ont Slot - range: [1...14] Field type <Gpon::OntPortId> - Gpon Ont Port - range: [1...16]	

Only Show Details: current alarm status		
name	Type	Description
ont-hpna-ser-mis	Parameter type: <Alarm::ONTHPNASVCMIS> (yes no) Possible values: - yes : hpna ont service mismatch - no : ont service is ok	hpna ont service mismatch <i>This element is only shown in detail mode.</i>
ont-hpna-los-sig	Parameter type: <Alarm::ONTHPNALOS> (yes no) Possible values: - yes : hpna loss of link - no : ont service is ok	hpna loss of link <i>This element is only shown in detail mode.</i>

104.144 ONT SIP AGENT CFG Current Alarm Status Command

Command Description

This command displays the ONT SIP AGENT CFG current alarm status.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm current ont-sip-agent-cfg [ (index) ]
```

Command Parameters

Table 104.144-1 " ONT SIP AGENT CFG Current Alarm Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm type

Command Output

Table 104.144-2 " ONT SIP AGENT CFG Current Alarm Status Command" Display parameters

Specific Information		
name	Type	Description
port	Parameter type: <Gpon::IpHostCommonIndex> (ont : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Gpon::IpHostId> vlanport : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / vuni : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlanport : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / vuni : <Eqpt::UnstackedVlan> ont:ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / <Ng2::IpHostId> vlanport:ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / vuni : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlanport:ng2 : <Eqpt::ChannelGroupId> /	gpon iphost port <i>This element is only shown in detail mode.</i>

name	Type	Description
	<Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / vuni : <Eqpt::UnstackedVlan>) Possible values: - ont:ng2 : ngpon2 ont - vlanport:ng2 : ngpon2 vlanport - ont : ont - vlanport : vlanport Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Eqpt::OntId> - the ONT identifier Field type <Eqpt::ChannelGroupId> - the channel group identifier Field type <Eqpt::SubChannelGroupId> - the subchannel group identifier Field type <Eqpt::Ng2OntId> - the NG2 ONT identifier Possible values: - vuni : virtual uni identifier Possible values: - vuni : virtual NGPON2 uni identifier Field type <Gpon::IpHostID> - iphost id Field type <Ng2::IpHostID> - iphost id (ngpon2) Possible values: - stacked : stacked vlan identity Field type <Eqpt::UnstackedVlan> - unstacked vlan id Field type <Eqpt::SVlan> - service vlan id Field type <Eqpt::CVlan> - customer vlan id	

Only Show Details: current alarm status

name	Type	Description
ont-sipa-reg-nm-fail	Parameter type: <Alarm::ONTSIPAREGFAILNAME> (yes no) Possible values: - yes : sipua registration name failed - no : ont service is ok	sipua registration name failed <i>This element is only shown in detail mode.</i>
ont-sipa-reg-rec-fail	Parameter type: <Alarm::ONTSIPAREGREACH> (yes no) Possible values: - yes : sipua register reach failed - no : ont service is ok	sipua register reach failed <i>This element is only shown in detail mode.</i>
ont-sipa-reg-con-fail	Parameter type: <Alarm::ONTSIPAREGCONNECT> (yes no) Possible values:	sipua register connect failed <i>This element is only shown in detail mode.</i>

104 Current Alarm Status Commands

name	Type	Description
	- yes : sipua register connect failed - no : ont service is ok	
ont-sipa-reg-val-fail	Parameter type: <Alarm::ONTSIPAREGVALIDATE> (yes no) Possible values: - yes : sipua register validation failed - no : ont service is ok	sipua register validation failed <i>This element is only shown in detail mode.</i>
ont-sipa-reg-mis	Parameter type: <Alarm::ONTSIPAREGMIS> (yes no) Possible values: - yes : sipua register mismatch - no : ont service is ok	sipua register mismatch <i>This element is only shown in detail mode.</i>

104.145 ONT VOIP CFG Current Alarm Status Command

Command Description

This command displays the ONT VOIP CFG current alarm status.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm current ont-voip-cfg [ (index) ]
```

Command Parameters

Table 104.145-1 " ONT VOIP CFG Current Alarm Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm type

Command Output

Table 104.145-2 " ONT VOIP CFG Current Alarm Status Command" Display parameters

Specific Information		
name	Type	Description
port	Parameter type: <Gpon::IpHostCommonIndex> (ont : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Gpon::IpHostId> vlanport : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / vuni : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlanport : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / vuni : <Eqpt::UnstackedVlan> ont.ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / <Ng2::IpHostId> vlanport.ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / vuni : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlanport.ng2 : <Eqpt::ChannelGroupId> /	gpon iphost port <i>This element is only shown in detail mode.</i>

104 Current Alarm Status Commands

name	Type	Description
	<Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / vuni : <Eqpt::UnstackedVlan>) Possible values: - ont:ng2 : ngpon2 ont - vlanport:ng2 : ngpon2 vlanport - ont : ont - vlanport : vlanport Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Eqpt::OntId> - the ONT identifier Field type <Eqpt::ChannelGroupId> - the channel group identifier Field type <Eqpt::SubChannelGroupId> - the subchannel group identifier Field type <Eqpt::Ng2OntId> - the NG2 ONT identifier Possible values: - vuni : virtual uni identifier Possible values: - vuni : virtual NGPON2 uni identifier Field type <Gpon::IpHostID> - iphost id Field type <Ng2::IpHostID> - iphost id (ngpon2) Possible values: - stacked : stacked vlan identity Field type <Eqpt::UnstackedVlan> - unstacked vlan id Field type <Eqpt::SVlan> - service vlan id Field type <Eqpt::CVlan> - customer vlan id	

Only Show Details: current alarm status		
name	Type	Description
ont-vcd-cfg-nm-fail	Parameter type: <Alarm::ONTVCDCFGFAILNAME> (yes no) Possible values: - yes : vcd config name failed - no : ont service is ok	vcd config name failed <i>This element is only shown in detail mode.</i>
ont-vcd-cfg-rech-fail	Parameter type: <Alarm::ONTVCDCFGREACH> (yes no) Possible values: - yes : vcd config reach failed - no : ont service is ok	vcd config reach failed <i>This element is only shown in detail mode.</i>
ont-vcd-cfg-conn-fail	Parameter type: <Alarm::ONTVCDCFGCONNECT> (yes no) Possible values:	vcd config connect failed <i>This element is only shown in detail mode.</i>

name	Type	Description
	- yes : vcd config connect failed - no : ont service is ok	
ont-vcd-cfg-vali-fail	Parameter type: <Alarm::ONTVCDCFGVALIDATE> (yes no) Possible values: - yes : vcd config validation failed - no : ont service is ok	vcd config validation failed <i>This element is only shown in detail mode.</i>
ont-vcd-cfg-auth-fail	Parameter type: <Alarm::ONTVCDCFGAUTH> (yes no) Possible values: - yes : vcd config authentication failed - no : ont service is ok	vcd config authentication failed <i>This element is only shown in detail mode.</i>
ont-vcd-cfg-resp-tmout	Parameter type: <Alarm::ONTVCDCFGTMOUT> (yes no) Possible values: - yes : vcd config response timeout - no : ont service is ok	vcd config response timeout <i>This element is only shown in detail mode.</i>
ont-vcd-cfg-resp-err	Parameter type: <Alarm::ONTVCDCFGRESPERR> (yes no) Possible values: - yes : vcd config response error - no : ont service is ok	vcd config response error <i>This element is only shown in detail mode.</i>
ont-vcd-cfg-file-err	Parameter type: <Alarm::ONTVCDCFGFILEERR> (yes no) Possible values: - yes : vcd config file error - no : ont service is ok	vcd config file error <i>This element is only shown in detail mode.</i>
ont-vcd-sub-nm-fail	Parameter type: <Alarm::ONTVCDSUBSFILNAME> (yes no) Possible values: - yes : vcd subscription name failed - no : ont service is ok	vcd subscription name failed <i>This element is only shown in detail mode.</i>
ont-vcd-sub-rech-fail	Parameter type: <Alarm::ONTVCDSUBSREACH> (yes no) Possible values: - yes : vcd subscription reach failed - no : ont service is ok	vcd subscription reach failed <i>This element is only shown in detail mode.</i>
ont-vcd-sub-conn-fail	Parameter type: <Alarm::ONTVCDSUBSCONNECT> (yes no) Possible values: - yes : vcd subscription connect failed - no : ont service is ok	vcd subscription connect failed <i>This element is only shown in detail mode.</i>
ont-vcd-sub-vali-fail	Parameter type: <Alarm::ONTVCDSUBSVALIDATE> (yes no) Possible values: - yes : vcd subscription validation failed - no : ont service is ok	vcd subscription validation failed <i>This element is only shown in detail mode.</i>
ont-vcd-sub-auth-fail	Parameter type: <Alarm::ONTVCDSUBSAUTH>	vcd subscription authentication

104 Current Alarm Status Commands

name	Type	Description
	(yes no) Possible values: - yes : vcd subscription authentication failed - no : ont service is ok	failed <i>This element is only shown in detail mode.</i>
ont-vcd-sub-resp-tmout	Parameter type: <Alarm::ONTVCDSUBSTMOUT> (yes no) Possible values: - yes : vcd subscription response timeout - no : ont service is ok	vcd subscription response timeout <i>This element is only shown in detail mode.</i>
ont-vcd-sub-resp-err	Parameter type: <Alarm::ONTVCDSUBSRESPERR> (yes no) Possible values: - yes : vcd subscription response error - no : ont service is ok	vcd subscription response error <i>This element is only shown in detail mode.</i>
ont-vcd-reb-requ	Parameter type: <Alarm::ONTVCDREBOOTREQ> (yes no) Possible values: - yes : vcd reboot request - no : ont service is ok	vcd reboot request <i>This element is only shown in detail mode.</i>
ont-vcd-mis	Parameter type: <Alarm::ONTVCDMIS> (yes no) Possible values: - yes : vcd mismatch - no : ont service is ok	vcd mismatch <i>This element is only shown in detail mode.</i>

104.146 ONT MGC Current Alarm Status Command

Command Description

This command displays the ONT MGC current alarm status.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

> show alarm current ont-mgc [(index)]

Command Parameters

Table 104.146-1 " ONT MGC Current Alarm Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm type

Command Output

Table 104.146-2 " ONT MGC Current Alarm Status Command" Display parameters

Specific Information		
name	Type	Description
port	Parameter type: <Gpon::IpHostCommonIndex> (ont : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Gpon::IpHostID> vlanport : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / vuni : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlanport : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / vuni : <Eqpt::UnstackedVlan> ont.ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / <Ng2::IpHostID> vlanport.ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / vuni : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlanport.ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / vuni : <Eqpt::UnstackedVlan>) Possible values: - ont.ng2 : ngpon2 ont	gpon iphost port <i>This element is only shown in detail mode.</i>

104 Current Alarm Status Commands

name	Type	Description
	- vlanport:ng2 : ngpon2 vlanport - ont : ont - vlanport : vlanport - Field type <Eqpt::RackId> - the rack number - Field type <Eqpt::ShelfId> - the shelf number - Field type <Eqpt::SlotId> - the LT slot number - Field type <Eqpt::PonId> - the PON identifier - Field type <Eqpt::OntId> - the ONT identifier - Field type <Eqpt::ChannelGroupId> - the channel group identifier - Field type <Eqpt::SubChannelGroupId> - the subchannel group identifier - Field type <Eqpt::Ng2OntId> - the NG2 ONT identifier - Possible values: - vuni : virtual uni identifier - Possible values: - vuni : virtual NGPON2 uni identifier - Field type <Gpon::IpHostID> - iphost id - Field type <Ng2::IpHostID> - iphost id (ngpon2) - Possible values: - stacked : stacked vlan identity - Field type <Eqpt::UnstackedVlan> - unstacked vlan id - Field type <Eqpt::SVlan> - service vlan id - Field type <Eqpt::CVlan> - customer vlan id	

Only Show Details: current alarm status		
name	Type	Description
ont-mgc-mis	Parameter type: <Alarm::ONTMGCMIS> (yes no) Possible values: - yes : ont mgc mismatch - no : ont service is ok	ont mgc mismatch <i>This element is only shown in detail mode.</i>
ont-mgc-timeout	Parameter type: <Alarm::ONTMGCTMOUT> (yes no) Possible values: - yes : ont mgc timeout - no : ont service is ok	ont mgc timeout <i>This element is only shown in detail mode.</i>

104.147 ONT MoCA Current Alarm Status Command

Command Description

This command displays the ONT MoCA current alarm status.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm current ont-moca [ (index) ]
```

Command Parameters

Table 104.147-1 " ONT MoCA Current Alarm Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm type

Command Output

Table 104.147-2 " ONT MoCA Current Alarm Status Command" Display parameters

Specific Information		
name	Type	Description
uni-index	Parameter type: <Gpon::IfIndexAlarmIndex2> (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Gpon::OntSlotId> / <Gpon::OntPortId> ng2 : <Ng2::ChannelGroup> / <Ng2::SubchannelGroup> / <Ng2::OntId> / <Gpon::OntSlotId> / <Gpon::OntPortId>) Possible values: - ng2 : ngpon2 style identification Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier	ont port <i>This element is only shown in detail mode.</i>

104 Current Alarm Status Commands

name	Type	Description
	Field type <Ng2::ChannelGroup> - channel group number Field type <Ng2::SubchannelGroup> - subchannel group number Field type <Eqpt::OntId> - the ONT identifier Field type <Ng2::OntId> - the ONT identifier Field type <Gpon::OntSlotId> - Gpon Ont Slot - range: [1...14] Field type <Gpon::OntPortId> - Gpon Ont Port - range: [1...16]	
Only Show Details: current alarm status		
name	Type	Description
ont-moca-svc-mis	Parameter type: <Alarm::ONTMOCASVCMIS> (yes no) Possible values: - yes : moca ont service mismatch - no : moca ont service is ok	ont moca service mismatch <i>This element is only shown in detail mode.</i>
ont-moca-link-los	Parameter type: <Alarm::ONTMOCALOL> (yes no) Possible values: - yes : moca loss of link - no : moca ont service is ok	ont moca loss of link <i>This element is only shown in detail mode.</i>
ont-moca-min-bw	Parameter type: <Alarm::ONTMOCALIMLINK> (yes no) Possible values: - yes : moca limited link - no : moca ont service is ok	ont moca bw between nodes less than minimum bw <i>This element is only shown in detail mode.</i>

104.148 ONT MoCA Threshold Crossing Alert (TCA) Current Alarm Status Command

Command Description

This command displays the ONT MoCA Threshold Crossing Alert (TCA) current alarm status.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm current ont-moca-tca [ (index) ]
```

Command Parameters

Table 104.148-1 " ONT MoCA Threshold Crossing Alert (TCA) Current Alarm Status Command"
Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm type

Command Output

Table 104.148-2 " ONT MoCA Threshold Crossing Alert (TCA) Current Alarm Status Command"
Display parameters

Specific Information		
name	Type	Description
uni-index	Parameter type: <Gpon::IfIndexAlarmIndex2> (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Gpon::OntSlotId> / <Gpon::OntPortId> ng2 : <Ng2::ChannelGroup> / <Ng2::SubchannelGroup> / <Ng2::OntId> / <Gpon::OntSlotId> / <Gpon::OntPortId>) Possible values: - ng2 : ngpon2 style identification Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number	ont port <i>This element is only shown in detail mode.</i>

104 Current Alarm Status Commands

name	Type	Description
	Field type <Eqpt::PonId> - the PON identifier Field type <Ng2::ChannelGroup> - channel group number Field type <Ng2::SubchannelGroup> - subchannel group number Field type <Eqpt::OntId> - the ONT identifier Field type <Ng2::OntId> - the ONT identifier Field type <Gpon::OntSlotId> - Gpon Ont Slot - range: [1...14] Field type <Gpon::OntPortId> - Gpon Ont Port - range: [1...16]	

Only Show Details: current alarm status		
name	Type	Description
ont-moca-rx-err-fr	Parameter type: <Alarm::ONTMOCATCARXERRFRMS> (yes no) Possible values: - yes : ont moca rx errored frames threshold alert - no : no ont moca threshold alerts	ont moca rx errored frames threshold alert <i>This element is only shown in detail mode.</i>

104.149 Auto-Switch Current Alarm Status Command

Command Description

This command displays the auto-switch current alarm status.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

> show alarm current auto-switch [(index)]

Command Parameters

Table 104.149-1 "Auto-Switch Current Alarm Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm type

Command Output

Table 104.149-2 "Auto-Switch Current Alarm Status Command" Display parameters

Specific Information		
name	Type	Description
port	Parameter type: <Itf::XdslLine> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number	identifies the physical position of the port <i>This element is only shown in detail mode.</i>
auto-switch-status	Parameter type: <Alarm::autoSwitchStatus> (yes no) Possible values: - yes : auto-switch alarm status	show auto-switch alarm status. <i>This element is only shown in detail mode.</i>

104 Current Alarm Status Commands

name	Type	Description
	- no : auto-switch alarm status clear	
queue-full-atm	Parameter type: <Alarm::auswqueuefullatm> (yes no) Possible values: - yes : auto-switch queue full for ATM - no : auto-switch queue full for ATM clear	Auto switch queue full status for ATM <i>This element is only shown in detail mode.</i>
cfg-data-bkup-fail-atm	Parameter type: <Alarm::auswbkpfailatm> (yes no) Possible values: - yes : auto-switch data backup failed for ATM - no : auto-switch data backup failed for ATM clear	Auto switch data backup status for ATM <i>This element is only shown in detail mode.</i>
recfg-fail-atm	Parameter type: <Alarm::auswrecfgfailatm> (yes no) Possible values: - yes : auto-switch reconfig failed for ATM - no : auto-switch reconfig failed for ATM clear	Auto switch reconfig status for ATM <i>This element is only shown in detail mode.</i>
data-unavail-atm	Parameter type: <Alarm::auswdataunatm> (yes no) Possible values: - yes : auto-switch data unavailable for ATM - no : auto-switch data unavailable for ATM clear	Auto switch data unavail status for ATM <i>This element is only shown in detail mode.</i>
queue-full-ptm	Parameter type: <Alarm::auswqueuefulptm> (yes no) Possible values: - yes : auto-switch queue full for PTM - no : auto-switch queue full for PTM clear	Auto switch queue full status for PTM <i>This element is only shown in detail mode.</i>
backup-fail-ptm	Parameter type: <Alarm::auswbkpfailptm> (yes no) Possible values: - yes : auto-switch data backup failed for PTM - no : auto-switch data backup failed for PTM clear	Auto switch data backup status for PTM <i>This element is only shown in detail mode.</i>
recfg-fail-ptm	Parameter type: <Alarm::auswrecfgfailptm> (yes no) Possible values: - yes : auto-switch reconfig failed for PTM - no : auto-switch reconfig failed for PTM clear	Auto switch reconfig status for PTM <i>This element is only shown in detail mode.</i>
data-unavail-ptm	Parameter type: <Alarm::auswdataunptm> (yes no) Possible values: - yes : auto-switch data unavailable for PTM - no : auto-switch data unavailable for PTM clear	Auto switch data unavail status for PTM <i>This element is only shown in detail mode.</i>
bakp-fail-atm	Parameter type: <Alarm::auswbakpfailatm> (yes no) Possible values: - yes : auto-switch backup fail for ATM - no : auto-switch bakcup fail for ATM clear	Auto switch backup status for ATM <i>This element is only shown in detail mode.</i>

104.150 Channel Pair Current Alarm Status Command

Command Description

This command displays the Channel Pair current alarm status.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

> show alarm current channel-pair [(index)]

Command Parameters

Table 104.150-1 " Channel Pair Current Alarm Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm type

Command Output

Table 104.150-2 " Channel Pair Current Alarm Status Command" Display parameters

Specific Information		
name	Type	Description
channel-pair	Parameter type: <Gpon::ChannelPairId> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::ChannelPairId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::ChannelPairId> - the channel pair identifier	specify which port the alarm occurred on. <i>This element is only shown in detail mode.</i>
Only Show Details: current alarm log status		
name	Type	Description
comm-fail	Parameter type: <Alarm::ChnPairComm> ((failing fail) ok)	current status of Channel pair Communication failure on channel Pair Port

104 Current Alarm Status Commands

name	Type	Description
	Possible values: - failing : Channel pair Communication is failing - fail : Channel pair Communication is failing - ok : Channel pair Communication is ok	<i>This element is only shown in detail mode.</i>
tx-fail	Parameter type: <Alarm::ChnPairTf> ((failing fail) ok) Possible values: - failing : Transmitte is failing - fail : Transmitte is failing - ok : Transmitte is ok	current status of transmit failure on OLT port <i>This element is only shown in detail mode.</i>
new-ont	Parameter type: <Alarm::ChnPairNewOnt> ((failing fail) ok) Possible values: - failing : NEW ONT is failing - fail : NEW ONT is failing - ok : NEW ONT is ok	current status of unprovisioned ont appearance <i>This element is only shown in detail mode.</i>
prov-mismatch	Parameter type: <Alarm::ChnPairMea> ((failing fail) ok) Possible values: - failing : Channel Pair Mismatch Provisioning is failing - fail : Channel Pair Mismatch Provisioning is failing - ok : Channel Pair Mismatch Provisioning is ok	current status of channel Pair provision failure. <i>This element is only shown in detail mode.</i>
loss-sig	Parameter type: <Alarm::ChnPairLoss> ((failing fail) ok) Possible values: - failing : Channel Pair Loss of Signal is failing - fail : Channel Pair Loss of Signal is failing - ok : Channel Pair Loss of Signal is ok	current status of channel Pair loss. <i>This element is only shown in detail mode.</i>
diagnostic	Parameter type: <Alarm::ChnPairRogueTest> ((failing fail) ok) Possible values: - failing : Rogue ONT detection mechanism effective is failing - fail : Rogue ONT detection mechanism effective is failing - ok : Rogue ONT detection mechanism effective is ok	current status of diagnostic tests <i>This element is only shown in detail mode.</i>
loid-conflict	Parameter type: <Alarm::ChnPairLoidConflict> ((failing fail) ok) Possible values: - failing : ONT LOID Conflict is failing - fail : ONT LOID Conflict is failing - ok : LOID Conflict is ok	current status of loid conflict ont. <i>This element is only shown in detail mode.</i>
loid-pwd-err	Parameter type: <Alarm::ChnPairLoidPwdErr> ((failing fail) ok) Possible values: - failing : ONT LOID PWD ERR is failing - fail : ONT LOID PWD ERR is failing - ok : ONT LOID PWD ERR is ok	current status of loid password error. <i>This element is only shown in detail mode.</i>
stk-laser-dis	Parameter type: <Alarm::ChnPairStkLaserDis> ((failing fail) ok)	current status of stuck laser disabled. <i>This element is only shown in</i>

name	Type	Description
	Possible values: - failing : Unranged ONT with stuck laser disabled is failing - fail : Unranged ONT with stuck laser disabled is failing - ok : Unranged ONT with stuck laser disabled is ok	<i>detail mode.</i>
sfp-mismatch	Parameter type: <Alarm::ChnPairSfpMismatch> ((failing fail) ok) Possible values: - failing : sfp mismatch is failing - fail : sfp mismatch is failing - ok : sfp mismatch is ok	current status of sfp mismatch. <i>This element is only shown in detail mode.</i>
rng-mismatch	Parameter type: <Alarm::ChnPairRngMismatch> ((failing fail) ok) Possible values: - failing : ranging mismatch is failing - fail : ranging mismatch is failing - ok : ranging mismatch is ok	current status of ranging mismatch. <i>This element is only shown in detail mode.</i>
alien-test	Parameter type: <Alarm::ChnPairAlienTest> ((failing fail) ok) Possible values: - failing : Alien ONT detection mechanism is active - fail : Alien ONT detection mechanism is active - ok : Alien ONT detection mechanism is not active	current status of alien diagnostic tests <i>This element is only shown in detail mode.</i>
alien-detect	Parameter type: <Alarm::ChnPairAlienDetected> ((failing fail) ok) Possible values: - failing : Alien ONT detected - fail : Alien ONT detected - ok : No alien ONT detected	current status of alien detect <i>This element is only shown in detail mode.</i>
deactont-high-tca	Parameter type: <Alarm::ChnPairDeactOntHighTca> (failing ok) Possible values: - failing : deactivated ont amount exceed high threshold occurred - ok : deactivated ont amount is less than high threshold occurred	current status of deactont high tca <i>This element is only shown in detail mode.</i>
deactont-low-tca	Parameter type: <Alarm::ChnPairDeactOntLowTca> (failing ok) Possible values: - failing : deactivated ont amount exceed low threshold occurred - ok : deactivated ont amount is less than low threshold occurred	current status of deactont low tca <i>This element is only shown in detail mode.</i>
datapath-integ	Parameter type: <Alarm::ChnPairDataPathInteg> (failing ok) Possible values: - failing : number of ONTs with SIPREGTO alarm exceeds threshold - ok : number of ONTs with SIPREGTO alarm does not exceed the threshold	current status of Channel-Pair Data Path Integrity <i>This element is only shown in detail mode.</i>

104.151 Channel Pair OLT TC TCA Current Alarm Status Command

Command Description

This command displays the Channel Pair OLT TC TCA current alarm status.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm current olt-chpair-tc-tca [ (index) ]
```

Command Parameters

Table 104.151-1 " Channel Pair OLT TC TCA Current Alarm Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm type

Command Output

Table 104.151-2 " Channel Pair OLT TC TCA Current Alarm Status Command" Display parameters

Specific Information		
name	Type	Description
channel-pair	Parameter type: <Gpon::ChannelPairId> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::ChannelPairId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::ChannelPairId> - the channel pair identifier	gpon channelpair ifindex <i>This element is only shown in detail mode.</i>

Only Show Details: current alarm status		
name	Type	Description
olt-chpr-tc-err-frag	Parameter	type: channelpair errored fragments

name	Type	Description
	<Alarm::OLTCHPRTCTCAERRFRAGSPON> (yes no) Possible values: - yes : channelpair errored fragments threshold crossed - no : olt works properly	threshold crossed <i>This element is only shown in detail mode.</i>
olt-chpr-up-bw-tca	Parameter type: <Alarm::OLTCHPRTCTCAUPBWTCa> (yes no) Possible values: - yes : olt channelpair upstream bandwidth tca - no : olt works properly	OLT CHANNELPAIR upstream bandwidth TCA <i>This element is only shown in detail mode.</i>
olt-chpr-down-bw-tca	Parameter type: <Alarm::OLTCHPRTCTCADWBWTCA> (yes no) Possible values: - yes : olt channelpair downstream bandwidth tca - no : olt works properly	OLT CHANNELPAIR downstream bandwidth TCA <i>This element is only shown in detail mode.</i>

104.152 Ont Configuration Download Current Alarm Status Command

Command Description

This command displays the ont configuration download current alarm status.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm current ont-cfg-dld [ (index) ]
```

Command Parameters

Table 104.152-1 "Ont Configuration Download Current Alarm Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm type

Command Output

Table 104.152-2 "Ont Configuration Download Current Alarm Status Command" Display parameters

Specific Information		
name	Type	Description
ont	Parameter type: <Gpon::OntIndex> (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> ng2 : <Ng2::ChannelGroup> / <Ng2::SubchannelGroup> / <Ng2::OntId>) Possible values: - ng2 : ngpon2 style identification Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId>	identifies the ont entry <i>This element is only shown in detail mode.</i>

name	Type	Description
	- the PON identifier Field type <Ng2::ChannelGroup> - channel group number Field type <Ng2::SubchannelGroup> - subchannel group number Field type <Eqpt::OntId> - the ONT identifier Field type <Ng2::OntId> - the ONT identifier	
cfgfile-idx	Parameter type: <Alarm::OntCfgFileIndex> (configure file 1 configure file 2) Possible values: - configure file 1 : configure file 1 generate the alarm - configure file 2 : configure file 2 generate the alarm	identifies the configure file which generate the alarm <i>This element is only shown in detail mode.</i>

Only Show Details: current alarm status

name	Type	Description
cfg-dld-fail	Parameter type: <Alarm::OntCfgDldFail> (yes no) Possible values: - yes : download of configure file to ont is failed - no : download of configure file to ont is ok	current status of the alarm specifying download of configure file to ont is failed or not <i>This element is only shown in detail mode.</i>
cfg-act-fail	Parameter type: <Alarm::OntCfgActFail> (yes no) Possible values: - yes : activate the passive config file failed - no : activate the passive config file ok	current status of the alarm specifying activate of configure file to ont is failed or not <i>This element is only shown in detail mode.</i>
cfg-dld-ip	Parameter type: <Alarm::OntCfgDldIp> (yes no) Possible values: - yes : ont configure file download in progress - no : no ont configure file download detected	current status of the alarm specifying whether downloading <i>This element is only shown in detail mode.</i>
cfg-ver-mismatch	Parameter type: <Alarm::OntCfgVerMismatch> (yes no) Possible values: - yes : the planned configure file does not match the active configure file - no : the planned configure file match the active configure file	current status of the alarm specifying whether planned configure file match the active configure file or not <i>This element is only shown in detail mode.</i>
cfg-file-missing	Parameter type: <Alarm::OntCfgFileMissing> (yes no) Possible values: - yes : ont configure file missing or has an error - no : ont configure file ok	ont configure file missing <i>This element is only shown in detail mode.</i>
cfg-verctrl-err	Parameter type: <Alarm::OntCfgVerCtrlErr> (yes no) Possible values: - yes : ont configure file version control error - no : ont configure file version control ok	ont configure file version control error <i>This element is only shown in detail mode.</i>
cfg-not-supported	Parameter type: <Alarm::OntCfgNotSupported> (yes	ont not support configure file download function

104 Current Alarm Status Commands

name	Type	Description
	no) Possible values: - yes : ont not support the configure file download function - no : ont support the configure file download function	<i>This element is only shown in detail mode.</i>

104.153 HGU TR069 Current Alarm Status Command

Command Description

This command displays the hgu tr069 current alarm status.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm current hgu-tr069 [ (index) ]
```

Command Parameters

Table 104.153-1 "HGU TR069 Current Alarm Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm type

Command Output

Table 104.153-2 "HGU TR069 Current Alarm Status Command" Display parameters

Specific Information		
name	Type	Description
ont	Parameter type: <Gpon::OntIndex> (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> ng2 : <Ng2::ChannelGroup> / <Ng2::SubchannelGroup> / <Ng2::OntId>) Possible values: - ng2 : ngpon2 style identification Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Ng2::ChannelGroup>	identifies the ont entry <i>This element is only shown in detail mode.</i>

104 Current Alarm Status Commands

name	Type	Description
	- channel group number Field type <Ng2::SubchannelGroup> - subchannel group number Field type <Eqpt::OntId> - the ONT identifier Field type <Ng2::OntId> - the ONT identifier	

Only Show Details: current alarm status		
name	Type	Description
cust-alm1	Parameter type: <Alarm::HguCustAlm1> (yes no) Possible values: - yes : customized alarm 1 exist - no : customized alarm 1 not exist	current status of customized alarm 1 <i>This element is only shown in detail mode.</i>
cust-alm2	Parameter type: <Alarm::HguCustAlm2> (yes no) Possible values: - yes : customized alarm 2 exist - no : customized alarm 2 not exist	current status of customized alarm 2 <i>This element is only shown in detail mode.</i>
cust-alm3	Parameter type: <Alarm::HguCustAlm3> (yes no) Possible values: - yes : customized alarm 3 exist - no : customized alarm 3 not exist	current status of customized alarm 3 <i>This element is only shown in detail mode.</i>
cust-alm4	Parameter type: <Alarm::HguCustAlm4> (yes no) Possible values: - yes : customized alarm 4 exist - no : customized alarm 4 not exist	current status of customized alarm 4 <i>This element is only shown in detail mode.</i>
cust-alm5	Parameter type: <Alarm::HguCustAlm5> (yes no) Possible values: - yes : customized alarm 5 exist - no : customized alarm 5 not exist	current status of customized alarm 5 <i>This element is only shown in detail mode.</i>
cust-alm6	Parameter type: <Alarm::HguCustAlm6> (yes no) Possible values: - yes : customized alarm 6 exist - no : customized alarm 6 not exist	current status of customized alarm 6 <i>This element is only shown in detail mode.</i>
cust-alm7	Parameter type: <Alarm::HguCustAlm7> (yes no) Possible values: - yes : customized alarm 7 exist - no : customized alarm 7 not exist	current status of customized alarm 7 <i>This element is only shown in detail mode.</i>
cust-alm8	Parameter type: <Alarm::HguCustAlm8> (yes no) Possible values: - yes : customized alarm 8 exist - no : customized alarm 8 not exist	current status of customized alarm 8 <i>This element is only shown in detail mode.</i>

name	Type	Description
cust-alm9	Parameter type: <Alarm::HguCustAlm9> (yes no) Possible values: - yes : customized alarm 9 exist - no : customized alarm 9 not exist	current status of customized alarm 9 <i>This element is only shown in detail mode.</i>
cust-alm10	Parameter type: <Alarm::HguCustAlm10> (yes no) Possible values: - yes : customized alarm 10 exist - no : customized alarm 10 not exist	current status of customized alarm 10 <i>This element is only shown in detail mode.</i>
cust-alm11	Parameter type: <Alarm::HguCustAlm11> (yes no) Possible values: - yes : customized alarm 11 exist - no : customized alarm 11 not exist	current status of customized alarm 11 <i>This element is only shown in detail mode.</i>
cust-alm12	Parameter type: <Alarm::HguCustAlm12> (yes no) Possible values: - yes : customized alarm 12 exist - no : customized alarm 12 not exist	current status of customized alarm 12 <i>This element is only shown in detail mode.</i>
cust-alm13	Parameter type: <Alarm::HguCustAlm13> (yes no) Possible values: - yes : customized alarm 13 exist - no : customized alarm 13 not exist	current status of customized alarm 13 <i>This element is only shown in detail mode.</i>
cust-alm14	Parameter type: <Alarm::HguCustAlm14> (yes no) Possible values: - yes : customized alarm 14 exist - no : customized alarm 14 not exist	current status of customized alarm 14 <i>This element is only shown in detail mode.</i>
cust-alm15	Parameter type: <Alarm::HguCustAlm15> (yes no) Possible values: - yes : customized alarm 15 exist - no : customized alarm 15 not exist	current status of customized alarm 15 <i>This element is only shown in detail mode.</i>
cust-alm16	Parameter type: <Alarm::HguCustAlm16> (yes no) Possible values: - yes : customized alarm 16 exist - no : customized alarm 16 not exist	current status of customized alarm 16 <i>This element is only shown in detail mode.</i>
cust-alm17	Parameter type: <Alarm::HguCustAlm17> (yes no) Possible values: - yes : customized alarm 17 exist - no : customized alarm 17 not exist	current status of customized alarm 17 <i>This element is only shown in detail mode.</i>
cust-alm18	Parameter type: <Alarm::HguCustAlm18> (yes no)	current status of customized alarm 18 <i>This element is only shown in</i>

104 Current Alarm Status Commands

name	Type	Description
	Possible values: - yes : customized alarm 18 exist - no : customized alarm 18 not exist	<i>detail mode.</i>
cust-alm19	Parameter type: <Alarm::HguCustAlm19> (yes no) Possible values: - yes : customized alarm 19 exist - no : customized alarm 19 not exist	current status of customized alarm 19 <i>This element is only shown in detail mode.</i>
cust-alm20	Parameter type: <Alarm::HguCustAlm20> (yes no) Possible values: - yes : customized alarm 20 exist - no : customized alarm 20 not exist	current status of customized alarm 20 <i>This element is only shown in detail mode.</i>
cust-alm21	Parameter type: <Alarm::HguCustAlm21> (yes no) Possible values: - yes : customized alarm 21 exist - no : customized alarm 21 not exist	current status of customized alarm 21 <i>This element is only shown in detail mode.</i>
cust-alm22	Parameter type: <Alarm::HguCustAlm22> (yes no) Possible values: - yes : customized alarm 22 exist - no : customized alarm 22 not exist	current status of customized alarm 22 <i>This element is only shown in detail mode.</i>
cust-alm23	Parameter type: <Alarm::HguCustAlm23> (yes no) Possible values: - yes : customized alarm 23 exist - no : customized alarm 23 not exist	current status of customized alarm 23 <i>This element is only shown in detail mode.</i>
cust-alm24	Parameter type: <Alarm::HguCustAlm24> (yes no) Possible values: - yes : customized alarm 24 exist - no : customized alarm 24 not exist	current status of customized alarm 24 <i>This element is only shown in detail mode.</i>
cust-alm25	Parameter type: <Alarm::HguCustAlm25> (yes no) Possible values: - yes : customized alarm 25 exist - no : customized alarm 25 not exist	current status of customized alarm 25 <i>This element is only shown in detail mode.</i>
cust-alm26	Parameter type: <Alarm::HguCustAlm26> (yes no) Possible values: - yes : customized alarm 26 exist - no : customized alarm 26 not exist	current status of customized alarm 26 <i>This element is only shown in detail mode.</i>
cust-alm27	Parameter type: <Alarm::HguCustAlm27> (yes no) Possible values: - yes : customized alarm 27 exist - no : customized alarm 27 not exist	current status of customized alarm 27 <i>This element is only shown in detail mode.</i>

name	Type	Description
cust-alm28	Parameter type: <Alarm::HguCustAlm28> (yes no) Possible values: - yes : customized alarm 28 exist - no : customized alarm 28 not exist	current status of customized alarm 28 <i>This element is only shown in detail mode.</i>
cust-alm29	Parameter type: <Alarm::HguCustAlm29> (yes no) Possible values: - yes : customized alarm 29 exist - no : customized alarm 29 not exist	current status of customized alarm 29 <i>This element is only shown in detail mode.</i>
cust-alm30	Parameter type: <Alarm::HguCustAlm30> (yes no) Possible values: - yes : customized alarm 30 exist - no : customized alarm 30 not exist	current status of customized alarm 30 <i>This element is only shown in detail mode.</i>
cust-alm31	Parameter type: <Alarm::HguCustAlm31> (yes no) Possible values: - yes : customized alarm 31 exist - no : customized alarm 31 not exist	current status of customized alarm 31 <i>This element is only shown in detail mode.</i>

104.154 Equipment Holder Extended Current Alarm Status Command

Command Description

This command displays the equipment holder extended current alarm status.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm current eqpt-psu [ (index) ]
```

Command Parameters

Table 104.154-1 "Equipment Holder Extended Current Alarm Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm type

Command Output

Table 104.154-2 "Equipment Holder Extended Current Alarm Status Command" Display parameters

Specific Information		
name	Type	Description
shelf	Parameter type: <Equipm::Shelf> <Eqpt::RackId> / <Eqpt::ShelfId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number	specify which shelf the alarm occurred on. <i>This element is only shown in detail mode.</i>

104.155 Ethernet Ring Current Alarm Status Command

Command Description

This command displays ethernet ring Current alarm status.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

> show alarm current ethernet-ring [(index)]

Command Parameters

Table 104.155-1 "Ethernet Ring Current Alarm Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm log table index

Command Output

Table 104.155-2 "Ethernet Ring Current Alarm Status Command" Display parameters

Specific Information		
name	Type	Description
eth-ring-instance-id	Parameter type: <UnsignedSignedInteger> - an unsigned integer	ethernet ring instance id where the alarm has occurred <i>This element is only shown in detail mode.</i>
eth-ring-path	Parameter type: <Alarm::EthernetRingPath> (path-a path-b n/a) Possible values: - path-a : path-a of the ethernet ring instance - path-b : path-b of the ethernet ring instance - n/a : not applicable for the alarm, fop-pm	unique identification for the alarm, Which identifies the path of the ethernet ring instance <i>This element is only shown in detail mode.</i>
Only Show Details: current alarm status		
name	Type	Description
eth-ring-fwd-st	Parameter type: <Alarm::EthernetRingPathFwdState> (blocked	specifies the forward state of the ethernet ring path

104 Current Alarm Status Commands

name	Type	Description
	unblocked) Possible values: - blocked : ethernet ring path fwd state blocked - unblocked : ethernet ring path fwd state unblocked	<i>This element is only shown in detail mode.</i>
eth-ring-fop-to	Parameter type: <Alarm::EthernetRingFOPTIMEOUT> (yes no) Possible values: - yes : fop-to occurred - no : fop-to not occurred	specifies ethernet ring fop-to failure of protocol timeout <i>This element is only shown in detail mode.</i>
eth-ring-fop-pm	Parameter type: <Alarm::EthernetRingFOPPM> (yes no) Possible values: - yes : fop-pm occurred - no : fop-pm not occurred	specifies ethernet ring failure of protocol provision mismatch alarm(fop-pm) <i>This element is only shown in detail mode.</i>

104.156 LldpMed Current Alarm Status Command

Command Description

This command displays the LLDP-MED current alarm status.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

> show alarm current lldpmed [(index)]

Command Parameters

Table 104.156-1 "LldpMed Current Alarm Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm type

Command Output

Table 104.156-2 "LldpMed Current Alarm Status Command" Display parameters

Specific Information		
name	Type	Description
lldpmed	Parameter type: <LLDPMed::LLDPMedPort> (uni : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> / <Eqpt::OntPortId> uni:ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / <Eqpt::Ng2OntSlotId> / <Eqpt::Ng2OntPortId> uni:ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / vuni) Possible values: - uni : uni - uni:ng2 : ngpon2 UNI style identification Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier	identify the lldpmed port where the alarm has occurred. <i>This element is always shown.</i>

104 Current Alarm Status Commands

name	Type	Description
	Field type <Eqpt::OntId> - the ONT identifier Field type <Eqpt::ChannelGroupId> - the channel group identifier Field type <Eqpt::SubChannelGroupId> - the subchannel group identifier Field type <Eqpt::Ng2OntId> - the NG2 ONT identifier Possible values: - vuni : virtual NGPON2 uni identifier Field type <Eqpt::OntSlotId> - the ONT SLOT identifier Field type <Eqpt::OntPortId> - the ONT PORT identifier Field type <Eqpt::Ng2OntSlotId> - the NGPON2 ONT SLOT identifier Field type <Eqpt::Ng2OntPortId> - the NGPON2 ONT PORT identifier	
lldpmed-portcfg-mis	Parameter type: <Alarm::LLDPMED-portcfg-mismatch> (yes no) Possible values: - yes : configuration request not accepted - no : configuration accepted	current status of the alarm specifying if the configuration for a provisioned lldpmed port is accepted or not. <i>This element is always shown.</i>
lldpmed-mediapl-mis	Parameter type: <Alarm::LLDPMED-mediapl-mismatch> (yes no) Possible values: - yes : configuration request not accepted - no : configuration accepted	current status of the alarm specifying if the configuration for a provisioned lldpmed port is accepted or not. <i>This element is always shown.</i>

104.157 Lag group Current Alarm Status Command

Command Description

This command displays the lag group current alarm status.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

> show alarm current link-agg [(index)]

Command Parameters

Table 104.157-1 "Lag group Current Alarm Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm type

Command Output

Table 104.157-2 "Lag group Current Alarm Status Command" Display parameters

Specific Information		
name	Type	Description
group	Parameter type: <Itf::LaGroupIndex> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number	identifies lag group index <i>This element is only shown in detail mode.</i>
la-oper-down	Parameter type: <Alarm::LaGroupDown> (yes no) Possible values: - yes : link group operation down - no : link group operation up	current status of la group operation <i>This element is only shown in detail mode.</i>
standby-not-available	Parameter type: <Alarm::StandbyUnavailable> (yes	current status of available of standby slot

104 Current Alarm Status Commands

name	Type	Description
	no) Possible values: - yes : lack of link-up ports on standby slot - no : link-up ports enough on standby slot	<i>This element is only shown in detail mode.</i>
switch-fail	Parameter type: <Alarm::LaSwitchFail> (yes no) Possible values: - yes : switchover failed for cross-lt la group - no : switchover is successful for cross-lt la group	current status of lag switchover <i>This element is only shown in detail mode.</i>
la-degrade	Parameter type: <Alarm::LaDegrade> (yes no) Possible values: - yes : lack of link-up ports on active slot - no : link-up ports enough on active slot	current status of lag degradation <i>This element is only shown in detail mode.</i>

104.158 40GBase-KR4 fcs exceed Current Alarm Status Command

Command Description

This command displays the 40GBase-KR4 fcs exceed current alarm status.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show alarm current fcs-exceed [ (index) ]
```

Command Parameters

Table 104.158-1 "40GBase-KR4 fcs exceed Current Alarm Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - index of a current alarm entry	alarm type

Command Output

Table 104.158-2 "40GBase-KR4 fcs exceed Current Alarm Status Command" Display parameters

Specific Information		
name	Type	Description
slot	Parameter type: <Equipm::EqptSlotIndex> (lt : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> nt-a nt-b nt acu : <Eqpt::RackId> / <Eqpt::ShelfId> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::EqSlotId> ext-a : <Eqpt::RackId> / <Eqpt::ShelfId> ext-b : <Eqpt::RackId> / <Eqpt::ShelfId> ctrl : <Eqpt::RackId> / <Eqpt::ShelfId> vlt : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::VirtualSlotId>) Possible values: - lt : lt-slot - vlt : virtual LT slot (VVPS board can only be planned at NANT-E / FANT-F)	identifies index <i>This element is only shown in detail mode.</i>

104 Current Alarm Status Commands

name	Type	Description
	- nt-a : nt-a slot - nt-b : nt-b slot - nt : nt slot - ext-a : nt-a slot in an extension shelf - ext-b : nt-b slot in an extension shelf - acu : acu slot - ctrl : ctrl-slot Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::VirtualSlotId> - the virtual LT slot number Field type <Eqpt::EqSlotId> - the equipment slot number	
nta/b	Parameter type: <UnsignedSignedInteger> - an unsigned integer	identifies index2 <i>This element is only shown in detail mode.</i>
fcs-is-exceed	Parameter type: <Alarm::almtypeFCSthreshexceed> (yes no) Possible values: - yes : FCS auto-recovery counter exceeded threshold - no : FCS auto-recovery counter not exceeded threshold	current status of whether fcs auto-recovery counter is exceed or not <i>This element is only shown in detail mode.</i>

105- ATM Status Commands

105.1 ATM Status Command Tree	105-5224
105.2 ATM Interface Status Command	105-5225
105.3 PVC Status Command	105-5227
105.4 TC Adapter Protocol Interval Status Command	105-5229
105.5 TC Adapter Protocol Current Quarter Performance Data Command	105-5231
105.6 TC Adapter Protocol Current Day Performance Data Command	105-5233
105.7 TC Adapter Protocol Performance Data for Previous Quarter Intervals Command	105-5235
105.8 TC Adapter Protocol Performance Data for Previous Day Intervals Command	105-5237

105.1 ATM Status Command Tree

Description

This chapter gives an overview of nodes that are handled by "ATM Status Commands".

Command Tree

```
----show
  ----atm
    ----interface
      - (port)
    ----pvc
      - (port-index)
    ----tc-int
      - (port)
    ----tc-current-int
      ----fifteen-min
        - (port)
      ----one-day
        - (port)
    ----tc-15min-int
      - (port)
      - intvl-number
    ----tc-1day-int
      - (port)
      - intvl-number
```

105.2 ATM Interface Status Command

Command Description

This command displays the ATM interface configuration table.

User Level

The command can be accessed by operators with atm privileges.

Command Syntax

The command has the following syntax:

```
> show atm interface [ (port) ]
```

Command Parameters

Table 105.2-1 "ATM Interface Status Command" Resource Parameters

Resource Identifier	Type	Description
(port)	Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number	ATM interface

Command Output

Table 105.2-2 "ATM Interface Status Command" Display parameters

Specific Information		
name	Type	Description
type	Parameter type: <Atm::asamAtmIrfType> (not-specified network-termination access-to-access user-to-access internal-server external-server) Possible values: - not-specified : not specified - network-termination : network termination - access-to-access : access to access interface	type of ATM interface. <i>This element is always shown.</i>

105 ATM Status Commands

name	Type	Description
	- user-to-access : user to access interface - internal-server : internal server interface - external-server : external server interface	
number-of-pvcs	Parameter type: <Atm::CrossConnectedPVccs> - the number of Vcttp connections - range: [0...65535]	specifies the number of vcttp connections on this ATM interface (only PVC). <i>This element is always shown.</i>

105.3 PVC Status Command

Command Description

This command displays the status of the PVC.

User Level

The command can be accessed by operators with atm privileges.

Command Syntax

The command has the following syntax:

```
> show atm pvc [ (port-index) ]
```

Command Parameters

Table 105.3-1 "PVC Status Command" Resource Parameters

Resource Identifier	Type	Description
(port-index)	Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::VpiMandatoryId> : <Eqpt::VciMandatoryId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number Field type <Eqpt::VpiMandatoryId> - atm VPI Field type <Eqpt::VciMandatoryId> - atm VCI	the ATM PVC

Command Output

Table 105.3-2 "PVC Status Command" Display parameters

Specific Information		
name	Type	Description
admin-status	Parameter type: <Atm::adminStatus> (admin-up admin-down) Possible values: - admin-up : enable traffic flow - admin-down : disable traffic flow	specifies the desired administrative state of the VCL. <i>This element is always shown.</i>

105 ATM Status Commands

name	Type	Description
operational-status	Parameter type: <Atm::atmVclOperStatus> (up down unknown) Possible values: - up : traffic flow is enabled in the virtual link - down : traffic flow is disabled in the virtual link - unknown : state is unknown	indicates the current operational status of the VCL. <i>This element is always shown.</i>
last-change	Parameter type: <Atm::ExtLastChangeTime> - the time elapsed since a certain event - 64-bit	time the VCL entered its current operational state. <i>This element is always shown.</i>
curr-encap-type	Parameter type: <Atm::CurVccEncapType> (llc-snap llc-snap-routed llc-nlpid vc-mux-bridged-8023 vc-mux-routed vc-mux-pppoa other unknown none) Possible values: - llc-snap : logical link control encapsulation bridged protocol - llc-snap-routed : logical link control encapsulation routed protocol - llc-nlpid : logical link control encapsulation pppoa protocol - vc-mux-bridged-8023 : virtual channel multiplex bridged protocol - vc-mux-routed : virtual channel multiplex routed protocol - vc-mux-pppoa : virtual channel multiplex pppoa protocol - other : other encapsulation type - unknown : unknown encapsulation type - none : no encapsulation type	the current established encapsulation type. <i>This element is always shown.</i>

105.4 TC Adapter Protocol Interval Status Command

Command Description

This command displays the TC adapter protocol interval status.

User Level

The command can be accessed by operators with atm privileges.

Command Syntax

The command has the following syntax:

```
> show atm tc-int [ (port) ]
```

Command Parameters

Table 105.4-1 "TC Adapter Protocol Interval Status Command" Resource Parameters

Resource Identifier	Type	Description
(port)	Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number	ATM interface index (rack/shelf/slot/port)

Command Output

Table 105.4-2 "TC Adapter Protocol Interval Status Command" Display parameters

Specific Information		
name	Type	Description
valid-15-min-intervals	Parameter type: <SignedInteger> - a signed integer	the number of previous intervals (maximum 192) for which valid data has been stored. The value of this object will be 192 unless the device was brought online within the last nx15 minutes, in which case the value will be the

105 ATM Status Commands

name	Type	Description
		number of complete 15 minute intervals the device has been online <i>This element is always shown.</i>
valid-1-day-intervals	Parameter type: <SignedInteger> - a signed integer	The number of previous intervals (maximum 2) for which valid data has been stored. The value of this object will be 2 unless the device was brought online within the last nx24 hours, in which case the value will be the number of complete 24 hours intervals the device has been online <i>This element is always shown.</i>

105.5 TC Adapter Protocol Current Quarter Performance Data Command

Command Description

This command displays the TC adapter protocol current quarter performance data.

User Level

The command can be accessed by operators with atm privileges.

Command Syntax

The command has the following syntax:

```
> show atm tc-current-int fifteen-min [ (port) ]
```

Command Parameters

Table 105.5-1 "TC Adapter Protocol Current Quarter Performance Data Command" Resource Parameters

Resource Identifier	Type	Description
(port)	Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number	ATM interface

Command Output

Table 105.5-2 "TC Adapter Protocol Current Quarter Performance Data Command" Display parameters

Specific Information		
name	Type	Description
ocd-far-end	Parameter type: <Counter> - 32 bit counter	the number of out of cell delineations anomalies for incoming cells on a far end ATM interface connected to this ATM interface

105 ATM Status Commands

name	Type	Description
		<i>This element is always shown.</i>
hec-far-end	Parameter type: <Counter> - 32 bit counter	the number of ATM cells discarded on the far end ATM interface connected to this ATM interface due to HEC errors <i>This element is always shown.</i>
ocd-near-end	Parameter type: <Counter> - 32 bit counter	the number of out of cell delineations anomalies for incoming cells on an ATM interface. An out of cell delineation anomaly occurs when there are 7 consecutive ATM cells received which contain HEC errors. <i>This element is always shown.</i>
hec-near-end	Parameter type: <Counter> - 32 bit counter	number of ATM cells discarded on the ATM interface due to HEC errors <i>This element is always shown.</i>

105.6 TC Adapter Protocol Current Day Performance Data Command

Command Description

This command displays the TC adapter protocol current day performance data.

User Level

The command can be accessed by operators with atm privileges.

Command Syntax

The command has the following syntax:

```
> show atm tc-current-int one-day [ (port) ]
```

Command Parameters

Table 105.6-1 "TC Adapter Protocol Current Day Performance Data Command" Resource Parameters

Resource Identifier	Type	Description
(port)	Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number	ATM interface

Command Output

Table 105.6-2 "TC Adapter Protocol Current Day Performance Data Command" Display parameters

Specific Information		
name	Type	Description
ocd-far-end	Parameter type: <Counter> - 32 bit counter	the number of out of cell delineations anomalies for incoming cells on a far end ATM interface connected to this ATM interface

105 ATM Status Commands

name	Type	Description
		<i>This element is always shown.</i>
hec-far-end	Parameter type: <Counter> - 32 bit counter	the number of ATM cells discarded on the far end ATM interface connected to this ATM interface due to HEC errors <i>This element is always shown.</i>
ocd-near-end	Parameter type: <Counter> - 32 bit counter	the number of out of cell delineations anomalies for incoming cells on an ATM interface. An out of cell delineation anomaly occurs when there are 7 consecutive ATM cells received which contain HEC errors. <i>This element is always shown.</i>
hec-near-end	Parameter type: <Counter> - 32 bit counter	number of ATM cells discarded on the ATM interface due to HEC errors <i>This element is always shown.</i>

105.7 TC Adapter Protocol Performance Data for Previous Quarter Intervals Command

Command Description

This command displays the TC adapter protocol-monitoring 15-min interval data parameters.

User Level

The command can be accessed by operators with atm privileges.

Command Syntax

The command has the following syntax:

```
> show atm tc-15min-int [ (port) [ intvl-number <Atm::AtmItvlNumber> ] ]
```

Command Parameters

Table 105.7-1 "TC Adapter Protocol Performance Data for Previous Quarter Intervals Command" Resource Parameters

Resource Identifier	Type	Description
(port)	Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number	ATM interface
intvl-number	Parameter type: <Atm::AtmItvlNumber> Format: - interval for which statistics is available - range: [1...192]	interval for which statistics are available

Command Output

Table 105.7-2 "TC Adapter Protocol Performance Data for Previous Quarter Intervals Command" Display parameters

Specific Information		
name	Type	Description
ocd-near-end	Parameter type: <Counter>	the number of out of cell

105 ATM Status Commands

name	Type	Description
	- 32 bit counter	delineations anomalies for incoming cells on an ATM interface. An out of cell delineation anomaly occurs when there are 7 consecutive ATM cells received which contain HEC errors <i>This element is always shown.</i>
hec-near-end	Parameter type: <Counter> - 32 bit counter	number of ATM cells discarded on the ATM interface due to HEC errors <i>This element is always shown.</i>
ocd-far-end	Parameter type: <Counter> - 32 bit counter	the number of out of cell delineations anomalies for incoming cells on a far end ATM interface connected to this ATM interface <i>This element is always shown.</i>
hec-far-end	Parameter type: <Counter> - 32 bit counter	the number of ATM cells discarded on the far end ATM interface connected to this ATM interface due to HEC errors <i>This element is always shown.</i>

105.8 TC Adapter Protocol Performance Data for Previous Day Intervals Command

Command Description

This command displays the TC adapter protocol-monitoring 1-day interval data parameters.

User Level

The command can be accessed by operators with atm privileges.

Command Syntax

The command has the following syntax:

```
> show atm tc-1day-int [ (port) [ intvl-number <Atm::AtmItvlNo1day> ] ]
```

Command Parameters

Table 105.8-1 "TC Adapter Protocol Performance Data for Previous Day Intervals Command" Resource Parameters

Resource Identifier	Type	Description
(port)	Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number	ATM interface
intvl-number	Parameter type: <Atm::AtmItvlNo1day> Format: - itvl for which statistics is available - range: [1...2]	interval for which statistics are available

Command Output

Table 105.8-2 "TC Adapter Protocol Performance Data for Previous Day Intervals Command" Display parameters

Specific Information		
name	Type	Description
ocd-near-end	Parameter type: <Counter>	the number of out of cell

105 ATM Status Commands

name	Type	Description
	- 32 bit counter	delineations anomalies for incoming cells on an ATM interface. An out of cell delineation anomaly occurs when there are 7 consecutive ATM cells received which contain HEC errors. <i>This element is always shown.</i>
hec-near-end	Parameter type: <Counter> - 32 bit counter	number of ATM cells discarded on the ATM interface due to HEC errors <i>This element is always shown.</i>
ocd-far-end	Parameter type: <Counter> - 32 bit counter	the number of out of cell delineations anomalies for incoming cells on a far end ATM interface connected to this ATM interface <i>This element is always shown.</i>
hec-far-end	Parameter type: <Counter> - 32 bit counter	the number of ATM cells discarded on the far end ATM interface connected to this ATM interface due to HEC errors <i>This element is always shown.</i>

106- VLAN Status Commands

106.1 VLAN Status Command Tree	106-5240
106.2 Global VLAN Status Command	106-5242
106.3 Residential Bridge VLAN Summary Status Command	106-5243
106.4 Residential Bridge VLAN Extensive Status Command	106-5246
106.5 Cross-connect VLAN Status Command	106-5251
106.6 Stacked VLAN Status Command	106-5256
106.7 Stacked QoS VLAN Status Command	106-5258
106.8 QoS C-VLAN Status Command	106-5260
106.9 Layer-2 Terminated VLAN Status Command	106-5261
106.10 VLAN Name Mapping Status Command	106-5263
106.11 VLAN Filtering Database Per LIM Status Command	106-5264
106.12 Bridge Port Filtering Database Status Command	106-5268
106.13 VLAN Priority Regeneration Profile Status Command	106-5271
106.14 VLAN Priority Regeneration Profile Name Status Command	106-5274
106.15 Show Next Free ID of VLAN Priority Regeneration Profile	106-5277
106.16 Duplicate MAC Alarm Status Command	106-5278
106.17 Port Event Status Command	106-5282
106.18 Port Statistics for Current Quarter Status Command	106-5285
106.19 Port Statistics for Current Day Status Command	106-5288
106.20 Port Statistics for Previous Quarter Intervals Status Command	106-5291
106.21 Port Statistics for Previous Day Intervals Status Command	106-5294
106.22 VLAN Port Statistics for Current Quarter Status Command	106-5297
106.23 VLAN Port Statistics for Current Day Status Command	106-5301
106.24 VLAN Port Statistics for Previous Quarter Intervals Status Command	106-5305
106.25 VLAN Port Statistics for Previous Day Intervals Status Command	106-5309
106.26 VLAN Filtering Database Status Command	106-5313
106.27 P-bit Traffic Counters Status Command	106-5316
106.28 Current VLAN Filtering Database Status Command	106-5319
106.29 Accumulated Port Statistics	106-5321

106.1 VLAN Status Command Tree

Description

This chapter gives an overview of nodes that are handled by "VLAN Status Commands".

Command Tree

```
----show
  ----vlan
    ----global
    ----residential-bridge
      ----summary
        - (vlan-id)
        - vlan-port
      ----extensive
        - (vlan-id)
        - vlan-port
    ----cross-connect
      - (vlan-id)
      - vlan-port
    ----stacked-vlan
      - (s-vlanid)
      - vlan-id
    ----stacked-qos-vlan
      - (s-vlanid)
      - vlan-id
    ----qos-cvlan-list
      - (vlan-id)
    ----layer2-terminated
      - (vlanid)
    ----name
      - (name)
    ----fdb-board
      - (slot)
      - fdb-id
      - mac
    ----bridge-port-fdb
      - (port)
      - vlan-id
      - mac
    ----priority-regen
      - (profile-id)
    ----prio-regen-name
      - (name)
    ----prio-regen-next
    ----dup-mac-alarm
      - (dup-port)
      - dup-fdb-id
      - dup-mac
    ----port-event
      - (port)
    ----port-curr-15min-stats
      - (port)
```

- port-curr-day-stats
 - (port)
- port-15min-stats
 - (port)
 - interval-number
- port-prev-day-stats
 - (port)
 - interval-number
- current-15min-stats
 - (vlanid)
 - port
- current-day-stats
 - (vlanid)
 - port
- previous-15min-stats
 - (vlanid)
 - port
 - interval-number
- vlan-day-stats
 - (vlanid)
 - port
 - interval-number
- X vmac-bridge-port-fdb
 - (port)
 - vlan-id
 - mac
- pbit-statistics
 - port
 - (vlan-port)
 - min-dot1p
 - max-dot1p
- fdbid
 - (vlan-id)
- port-accumu-stats
 - (port)

106.2 Global VLAN Status Command

Command Description

This command displays information common to all VLANs.

User Level

The command can be accessed by operators with vlan privileges.

Command Syntax

The command has the following syntax:

```
> show vlan global
```

Command Output

Table 106.2-2 "Global VLAN Status Command" Display parameters

Common Information:vlan parameters		
name	Type	Description
configured-vlans	Parameter type: <Vlan::Gauge> - an unsigned integer	current number of configured and auto configured vlans <i>This element is always shown.</i>
management	Parameter type: <Vlan::MgmtVlanMode> (inband outband inband-outband) Possible values: - inband : inband - outband : outband - inband-outband : inband and outband	specifies how the node is managed <i>This element is always shown.</i>
max-rb-vlan	Parameter type: <Vlan::Gauge> - an unsigned integer	maximum number of residential bridge vlans that are supported <i>This element is always shown.</i>
max-layer2-term-vlan	Parameter type: <Vlan::Gauge> - an unsigned integer	maximum number of layer2 terminated vlans that are supported <i>This element is always shown.</i>

106.3 Residential Bridge VLAN Summary Status Command

Command Description

This command displays a list of ports attached to a particular VLAN of the type residential bridge VLAN.

User Level

The command can be accessed by operators with vlan privileges.

Command Syntax

The command has the following syntax:

```
> show vlan residential-bridge summary [ (vlan-id) [ vlan-port <Itf::VlanPortInterface> ] ]
```

Command Parameters

Table 106.3-1 "Residential Bridge VLAN Summary Status Command" Resource Parameters

Resource Identifier	Type	Description
(vlan-id)	Format: (<Vlan::UVlanIndex> stacked : <Vlan::SVlanIndex> : <Vlan::CVlanIndex>) Possible values: - stacked : stacked vlan identity Field type <Vlan::UVlanIndex> - unstacked vlan identity - range: [1...4093,4096] Field type <Vlan::SVlanIndex> - service vlan identity - range: [2...4093] Field type <Vlan::CVlanIndex> - customer vlan identity - range: [0...4093]	network vlan id
vlan-port	Parameter type: <Itf::VlanPortInterface> Format: (vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::VpiId> : <Eqpt::VciId> : <Eqpt::UnstackedVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::UnstackedVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::VpiId> : <Eqpt::VciId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : stacked : <Eqpt::SVlan> :	vlan port

Resource Identifier	Type	Description
	<pre> <Eqpt::CVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> / <Eqpt::OntPortId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> / <Eqpt::OntPortId> : <Eqpt::UnstackedVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / voip : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / vuni : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / voip : <Eqpt::UnstackedVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / vuni : <Eqpt::UnstackedVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::LLId> : <Eqpt::UnstackedVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::LLId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan-port:ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Ng2::OntId> / <Eqpt::Ng2OntSlotId> / <Eqpt::Ng2OntPortId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan-port:ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Ng2::OntId> / <Eqpt::Ng2OntSlotId> / <Eqpt::Ng2OntPortId> : <Eqpt::UnstackedVlan> vlan-port:ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Ng2::OntId> / vuni : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan-port:ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Ng2::OntId> / vuni : <Eqpt::UnstackedVlan>) Possible values: - vlan-port : vlan port - vlan-port:ng2 : ngpon2 vlan port Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number Field type <Eqpt::VpiId> - atm VPI Field type <Eqpt::VcId> - atm VCI Field type <Eqpt::PonId> </pre>	

Resource Identifier	Type	Description
	- the PON identifier - Field type <Eqpt::OntId> - the ONT identifier - Field type <Eqpt::ChannelGroupId> - the channel group identifier - Field type <Eqpt::SubChannelGroupId> - the subchannel group identifier - Field type <Ng2::OntId> - the ONT identifier - Possible values: - voip : virtual uni identifier - obsolete alternative replaced by vuni - vuni : virtual uni identifier - Possible values: - vuni : virtual NGPON2 uni identifier - Field type <Eqpt::OntSlotId> - the ONT SLOT identifier - Field type <Eqpt::OntPortId> - the ONT PORT identifier - Field type <Eqpt::Ng2OntSlotId> - the NGPON2 ONT SLOT identifier - Field type <Eqpt::Ng2OntPortId> - the NGPON2 ONT PORT identifier - Field type <Eqpt::LLId> - the LLID identifier,range 1 for EPON,range 1-8 for DPOE - Possible values: - stacked : stacked vlan identity - Field type <Eqpt::UnstackedVlan> - unstacked vlan id - Field type <Eqpt::SVlan> - service vlan id - Field type <Eqpt::CVlan> - customer vlan id	

Command Output

Table 106.3-2 "Residential Bridge VLAN Summary Status Command" Display parameters

Specific Information		
name	Type	Description
association type	Parameter type: <Vlan::AssociationType> (static dynamic) Possible values: - static : association type is dynamic - dynamic : association type is static	The type of association is static or dynamic <i>This element is always shown.</i>

106.4 Residential Bridge VLAN Extensive Status Command

Command Description

This command displays a list of ports, each with an extensive set of parameters, for a particular VLAN of the type residential bridge VLAN in detail mode. Execution of this command may take a long time.

User Level

The command can be accessed by operators with vlan privileges.

Command Syntax

The command has the following syntax:

```
> show vlan residential-bridge extensive [ (vlan-id) [ vlan-port <Itf::VlanPortInterface> ] ]
```

Command Parameters

Table 106.4-1 "Residential Bridge VLAN Extensive Status Command" Resource Parameters

Resource Identifier	Type	Description
(vlan-id)	Format: (<Vlan::UVlanIndex> stacked : <Vlan::SVlanIndex> : <Vlan::CVlanIndex>) Possible values: - stacked : stacked vlan identity Field type <Vlan::UVlanIndex> - unstacked vlan identity - range: [1...4093,4096] Field type <Vlan::SVlanIndex> - service vlan identity - range: [2...4093] Field type <Vlan::CVlanIndex> - customer vlan identity - range: [0...4093]	network vlan id
vlan-port	Parameter type: <Itf::VlanPortInterface> Format: (vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::VpiId> : <Eqpt::VciId> : <Eqpt::UnstackedVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::UnstackedVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::VpiId> : <Eqpt::VciId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> /	vlan port

Resource Identifier	Type	Description
	<Eqpt::SlotId> / <Eqpt::PortId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> / <Eqpt::OntPortId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> / <Eqpt::OntPortId> : <Eqpt::UnstackedVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / voip : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / vuni : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / voip : <Eqpt::UnstackedVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / vuni : <Eqpt::UnstackedVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::LLId> : <Eqpt::UnstackedVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::LLId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan-port:ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Ng2::OntId> / <Eqpt::Ng2OntSlotId> / <Eqpt::Ng2OntPortId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan-port:ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Ng2::OntId> / <Eqpt::Ng2OntSlotId> / <Eqpt::Ng2OntPortId> : <Eqpt::UnstackedVlan> vlan-port:ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Ng2::OntId> / vuni : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan-port:ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Ng2::OntId> / vuni : <Eqpt::UnstackedVlan>) Possible values: - vlan-port : vlan port - vlan-port:ng2 : ngpon2 vlan port Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number Field type <Eqpt::VpiId> - atm VPI Field type <Eqpt::VciId> - atm VCI	

Resource Identifier	Type	Description
	Field type <Eqpt::PonId> - the PON identifier Field type <Eqpt::OntId> - the ONT identifier Field type <Eqpt::ChannelGroupId> - the channel group identifier Field type <Eqpt::SubChannelGroupId> - the subchannel group identifier Field type <Ng2::OntId> - the ONT identifier Possible values: - voip : virtual uni identifier obsolete alternative replaced by vuni - vuni : virtual uni identifier Possible values: - vuni : virtual NGPON2 uni identifier Field type <Eqpt::OntSlotId> - the ONT SLOT identifier Field type <Eqpt::OntPortId> - the ONT PORT identifier Field type <Eqpt::Ng2OntSlotId> - the NGPON2 ONT SLOT identifier Field type <Eqpt::Ng2OntPortId> - the NGPON2 ONT PORT identifier Field type <Eqpt::LLId> - the LLID identifier, range 1 for EPON, range 1-8 for DPOE Possible values: - stacked : stacked vlan identity Field type <Eqpt::UnstackedVlan> - unstacked vlan id Field type <Eqpt::SVlan> - service vlan id Field type <Eqpt::CVlan> - customer vlan id	

Command Output

Table 106.4-2 "Residential Bridge VLAN Extensive Status Command" Display parameters

Specific Information		
name	Type	Description
association type	Parameter type: <Vlan::AssociationType> (static dynamic) Possible values: - static : association type is dynamic - dynamic : association type is static	The type of association is static or dynamic <i>This element is always shown.</i>
qos-profile	Parameter type: <Vlan::QosProfileName> (none name : <Vlan::IgnoredQosProfileName>) Possible values: - none : no profile name to associate - name : enter profile name to be associated Field type <Vlan::IgnoredQosProfileName> - name of the QoS profile - length: 1<=x<=64	QOS profile, dynamically or statically (if no dynamic) assigned to a port <i>This element is always shown.</i>
qos	Parameter type: <Vlan::QosPolicy>	the qos policy

name	Type	Description
	(priority : <Vlan::Priority> profile : none profile : trusted-port profile : best-effort profile : cl-all-prio-3 profile : cl-all-prio-4 profile : background profile : be-cl-voice profile : be-cl-1d-voice profile : be-voice profile : l2-vpn-3 profile : l2-vpn-4 profile : 11 profile : 12 profile : 13 profile : 14 profile : 15 profile : 16 profile : 17 profile : 18 profile : 19 profile : 20 profile : 21 profile : 22 profile : 23 profile : 24 profile : 25 profile : 26 profile : 27 profile : 28 profile : 29 profile : 30 profile : 31 profile : 32 prio-regen-name : none prio-regen-name : name : <Vlan::IgnoredVlanProfileName>) Possible values: - priority : fixed priority identify - profile : regeneration profile identify - prio-regen-name : priority regeneration profile name Field type <Vlan::Priority> - priority of ethernet frames - range: [0...7] Possible values: - none : default value - trusted-port : trusted port - best-effort : best effort - cl-all-prio-3 : controlled load, all priority 3 traffic - cl-all-prio-4 : controlled load, all priority 4 traffic - background : background - be-cl-voice : best effort, controlled load, voice - be-cl-1d-voice : best effort, controlled load, 802.Id Annex G voice - be-voice : best effort voice - l2-vpn-3 : L2 VPN with 3 traffic classes - l2-vpn-4 : L2 VPN with 4 traffic classes	<i>This element is always shown.</i>

106 VLAN Status Commands

name	Type	Description
	- 11 : operator-defined profile - 12 : operator-defined profile - 13 : operator-defined profile - 14 : operator-defined profile - 15 : operator-defined profile - 16 : operator-defined profile - 17 : operator-defined profile - 18 : operator-defined profile - 19 : operator-defined profile - 20 : operator-defined profile - 21 : operator-defined profile - 22 : operator-defined profile - 23 : operator-defined profile - 24 : operator-defined profile - 25 : operator-defined profile - 26 : operator-defined profile - 27 : operator-defined profile - 28 : operator-defined profile - 29 : operator-defined profile - 30 : operator-defined profile - 31 : operator-defined profile - 32 : operator-defined profile Possible values: - none : no profile name to associate - name : enter profile name to be associated Data driven field type Possible values are depending on the actual configuration and software. The currently allowed values can be shown with online-help.	
prio-regen-name	Parameter type: <Vlan::PrioRegenProfileName> (none name : <Vlan::IgnoredVlanProfileName>) Possible values: - none : no profile name to associate - name : enter profile name to be associated Data driven field type Possible values are depending on the actual configuration and software. The currently allowed values can be shown with online-help.	priority regeneration profile name <i>This element is always shown.</i>
transmit-mode	Parameter type: <Vlan::PortUntagStatus> (untagged single-tagged priority-tagged) Possible values: - untagged : untagged outgoing frames - single-tagged : singletagged outgoing frames - priority-tagged : prioritytagged outgoing frames	transmit mode on egress forwarding interface as tagged, untagged or priority tagged <i>This element is always shown.</i>

106.5 Cross-connect VLAN Status Command

Command Description

This command displays all parameters for the ports attached to a particular VLAN of the type cross-connect VLAN.

User Level

The command can be accessed by operators with vlan privileges.

Command Syntax

The command has the following syntax:

```
> show vlan cross-connect [ (vlan-id) [ vlan-port <Itf::VlanPortInterface> ] ]
```

Command Parameters

Table 106.5-1 "Cross-connect VLAN Status Command" Resource Parameters

Resource Identifier	Type	Description
(vlan-id)	Format: (<Vlan::UVlanIndex> stacked : <Vlan::SVlanIndex> : <Vlan::CVlanIndex>) Possible values: - stacked : stacked vlan identity Field type <Vlan::UVlanIndex> - unstacked vlan identity - range: [1...4093,4096] Field type <Vlan::SVlanIndex> - service vlan identity - range: [2...4093] Field type <Vlan::CVlanIndex> - customer vlan identity - range: [0...4093]	network vlan id
vlan-port	Parameter type: <Itf::VlanPortInterface> Format: (vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::VpId> : <Eqpt::VcId> : <Eqpt::UnstackedVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::UnstackedVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::VpId> : <Eqpt::VcId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> /	vlan port

Resource Identifier	Type	Description
	<Eqpt::OntSlotId> / <Eqpt::OntPortId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> / <Eqpt::OntPortId> : <Eqpt::UnstackedVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / voip : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / vuni : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / voip : <Eqpt::UnstackedVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / vuni : <Eqpt::UnstackedVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::LLId> : <Eqpt::UnstackedVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::LLId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan-port:ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Ng2::OntId> / <Eqpt::Ng2OntSlotId> / <Eqpt::Ng2OntPortId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan-port:ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Ng2::OntId> / <Eqpt::Ng2OntSlotId> / <Eqpt::Ng2OntPortId> : <Eqpt::UnstackedVlan> vlan-port:ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Ng2::OntId> / vuni : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan-port:ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Ng2::OntId> / vuni : <Eqpt::UnstackedVlan>) Possible values: - vlan-port : vlan port - vlan-port:ng2 : ngpon2 vlan port Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number Field type <Eqpt::VpiId> - atm VPI Field type <Eqpt::VciId> - atm VCI Field type <Eqpt::PonId> - the PON identifier Field type <Eqpt::OntId> - the ONT identifier	

Resource Identifier	Type	Description
	Field type <Eqpt::ChannelGroupId> - the channel group identifier Field type <Eqpt::SubChannelGroupId> - the subchannel group identifier Field type <Ng2::OntId> - the ONT identifier Possible values: - voip : virtual uni identifier obsolete alternative replaced by vuni - vuni : virtual uni identifier Possible values: - vuni : virtual NGPON2 uni identifier Field type <Eqpt::OntSlotId> - the ONT SLOT identifier Field type <Eqpt::OntPortId> - the ONT PORT identifier Field type <Eqpt::Ng2OntSlotId> - the NGPON2 ONT SLOT identifier Field type <Eqpt::Ng2OntPortId> - the NGPON2 ONT PORT identifier Field type <Eqpt::LLId> - the LLID identifier,range 1 for EPON,range 1-8 for DPOE Possible values: - stacked : stacked vlan identity Field type <Eqpt::UnstackedVlan> - unstacked vlan id Field type <Eqpt::SVlan> - service vlan id Field type <Eqpt::CVlan> - customer vlan id	

Command Output

Table 106.5-2 "Cross-connect VLAN Status Command" Display parameters

Specific Information		
name	Type	Description
association type	Parameter type: <Vlan::AssociationType> (static dynamic) Possible values: - static : association type is dynamic - dynamic : association type is static	The type of association is static or dynamic <i>This element is always shown.</i>
qos-profile	Parameter type: <Vlan::QosProfileName> (none name : <Vlan::IgnoredQosProfileName>) Possible values: - none : no profile name to associate - name : enter profile name to be associated Field type <Vlan::IgnoredQosProfileName> - name of the QoS profile - length: 1<=x<=64	QOS profile, dynamically or statically (if no dynamic) assigned to a port <i>This element is always shown.</i>
qos	Parameter type: <Vlan::QosPolicy> (priority : <Vlan::Priority> profile : none profile : trusted-port profile : best-effort	the qos policy <i>This element is always shown.</i>

106 VLAN Status Commands

name	Type	Description
	profile : cl-all-prio-3 profile : cl-all-prio-4 profile : background profile : be-cl-voice profile : be-cl-1d-voice profile : be-voice profile : l2-vpn-3 profile : l2-vpn-4 profile : 11 profile : 12 profile : 13 profile : 14 profile : 15 profile : 16 profile : 17 profile : 18 profile : 19 profile : 20 profile : 21 profile : 22 profile : 23 profile : 24 profile : 25 profile : 26 profile : 27 profile : 28 profile : 29 profile : 30 profile : 31 profile : 32 prio-regen-name : none prio-regen-name : name : <Vlan::IgnoredVlanProfileName>) Possible values: - priority : fixed priority identify - profile : regeneration profile identify - prio-regen-name : priority regeneration profile name Field type <Vlan::Priority> - priority of ethernet frames - range: [0...7] Possible values: - none : default value - trusted-port : trusted port - best-effort : best effort - cl-all-prio-3 : controlled load, all priority 3 traffic - cl-all-prio-4 : controlled load, all priority 4 traffic - background : background - be-cl-voice : best effort, controlled load, voice - be-cl-1d-voice : best effort, controlled load, 802.1d Annex G voice - be-voice : best effort voice - l2-vpn-3 : L2 VPN with 3 traffic classes - l2-vpn-4 : L2 VPN with 4 traffic classes - 11 : operator-defined profile - 12 : operator-defined profile - 13 : operator-defined profile - 14 : operator-defined profile	

name	Type	Description
	- 15 : operator-defined profile - 16 : operator-defined profile - 17 : operator-defined profile - 18 : operator-defined profile - 19 : operator-defined profile - 20 : operator-defined profile - 21 : operator-defined profile - 22 : operator-defined profile - 23 : operator-defined profile - 24 : operator-defined profile - 25 : operator-defined profile - 26 : operator-defined profile - 27 : operator-defined profile - 28 : operator-defined profile - 29 : operator-defined profile - 30 : operator-defined profile - 31 : operator-defined profile - 32 : operator-defined profile Possible values: - none : no profile name to associate - name : enter profile name to be associated Data driven field type Possible values are depending on the actual configuration and software. The currently allowed values can be shown with online-help.	
prio-regen-name	Parameter type: <Vlan::PrioRegenProfileName> (none name : <Vlan::IgnoredVlanProfileName>) Possible values: - none : no profile name to associate - name : enter profile name to be associated Data driven field type Possible values are depending on the actual configuration and software. The currently allowed values can be shown with online-help.	priority regeneration profile name <i>This element is always shown.</i>
transmit-mode	Parameter type: <Vlan::PortUntagStatus> (untagged single-tagged priority-tagged) Possible values: - untagged : untagged outgoing frames - single-tagged : singletagged outgoing frames - priority-tagged : prioritytagged outgoing frames	transmit mode on egress forwarding interface as tagged, untagged or priority tagged <i>This element is always shown.</i>

106.6 Stacked VLAN Status Command

Command Description

This command displays the stacked VLANs configured in the system.

User Level

The command can be accessed by operators with vlan privileges.

Command Syntax

The command has the following syntax:

```
> show vlan stacked-vlan [ (s-vlanid) [ vlan-id <Vlan::StackedVlan> ] ]
```

Command Parameters

Table 106.6-1 "Stacked VLAN Status Command" Resource Parameters

Resource Identifier	Type	Description
(s-vlanid)	Format: (<Vlan::UVlanIndex> stacked : <Vlan::SVlanIndex> : <Vlan::CVlanIndex>) Possible values: - stacked : stacked vlan identity Field type <Vlan::UVlanIndex> - unstacked vlan identity - range: [1...4093,4096] Field type <Vlan::SVlanIndex> - service vlan identity - range: [2...4093] Field type <Vlan::CVlanIndex> - customer vlan identity - range: [0...4093]	vlan id
vlan-id	Parameter type: <Vlan::StackedVlan> Format: (<Vlan::UVlanIndex> stacked : <Vlan::SVlanIndex> : <Vlan::CVlanIndex>) Possible values: - stacked : stacked vlan identity Field type <Vlan::UVlanIndex> - unstacked vlan identity - range: [1...4093,4096] Field type <Vlan::SVlanIndex> - service vlan identity - range: [2...4093] Field type <Vlan::CVlanIndex> - customer vlan identity - range: [0...4093]	customer vlan

106.7 Stacked QoS VLAN Status Command

Command Description

This command displays the stacked VLANs configured in the system.

User Level

The command can be accessed by operators with vlan privileges.

Command Syntax

The command has the following syntax:

```
> show vlan stacked-qos-vlan [ (s-vlanid) [ vlan-id <Vlan::StackedVlan> ] ]
```

Command Parameters

Table 106.7-1 "Stacked QoS VLAN Status Command" Resource Parameters

Resource Identifier	Type	Description
(s-vlanid)	Format: (<Vlan::UVlanIndex> stacked : <Vlan::SVlanIndex> : <Vlan::CVlanIndex>) Possible values: - stacked : stacked vlan identity Field type <Vlan::UVlanIndex> - unstacked vlan identity - range: [1...4093,4096] Field type <Vlan::SVlanIndex> - service vlan identity - range: [2...4093] Field type <Vlan::CVlanIndex> - customer vlan identity - range: [0...4093]	vlan id
vlan-id	Parameter type: <Vlan::StackedVlan> Format: (<Vlan::UVlanIndex> stacked : <Vlan::SVlanIndex> : <Vlan::CVlanIndex>) Possible values: - stacked : stacked vlan identity Field type <Vlan::UVlanIndex> - unstacked vlan identity - range: [1...4093,4096] Field type <Vlan::SVlanIndex> - service vlan identity - range: [2...4093] Field type <Vlan::CVlanIndex> - customer vlan identity - range: [0...4093]	customer vlan

106.8 QoS C-VLAN Status Command

Command Description

This command shows the QoS CVlans configured in the system.

User Level

The command can be accessed by operators with vlan privileges.

Command Syntax

The command has the following syntax:

> show vlan qos-cvlan-list [(vlan-id)]

Command Parameters

Table 106.8-1 "QoS C-VLAN Status Command" Resource Parameters

Resource Identifier	Type	Description
(vlan-id)	Format: - vlan id - range: [1...4093]	customer vlan

106.9 Layer-2 Terminated VLAN Status Command

Command Description

This command displays all parameters for a particular VLAN of the type Layer 2 terminated VLAN.

User Level

The command can be accessed by operators with vlan privileges.

Command Syntax

The command has the following syntax:

```
> show vlan layer2-terminated [ (vlanid) ]
```

Command Parameters

Table 106.9-1 "Layer-2 Terminated VLAN Status Command" Resource Parameters

Resource Identifier	Type	Description
(vlanid)	Format: (<Vlan::UVlanIndex> stacked : <Vlan::SVlanIndex> : <Vlan::CVlanIndex>) Possible values: - stacked : stacked vlan identity Field type <Vlan::UVlanIndex> - unstacked vlan identity - range: [1...4093,4096] Field type <Vlan::SVlanIndex> - service vlan identity - range: [2...4093] Field type <Vlan::CVlanIndex> - customer vlan identity - range: [0...4093]	vlan id

Command Output

Table 106.9-2 "Layer-2 Terminated VLAN Status Command" Display parameters

Specific Information		
name	Type	Description
fdb-id	Parameter type: <Vlan::StackedVlan> (<Vlan::UVlanIndex> stacked : <Vlan::SVlanIndex> : <Vlan::CVlanIndex>) Possible values: - stacked : stacked vlan identity Field type <Vlan::UVlanIndex> - unstacked vlan identity - range: [1...4093,4096]	identity of the filtering database <i>This element is always shown.</i>

106 VLAN Status Commands

name	Type	Description
	Field type <Vlan::SVlanIndex> - service vlan identity - range: [2...4093,4094] Field type <Vlan::CVlanIndex> - customer vlan identity - range: [0...4093,4094,4095,4096]	
filter-entries	Parameter type: <Vlan::Counter> - an unsigned integer	number of entries in the filtering database <i>This element is always shown.</i>
network-ifindex	Parameter type: <Vlan::Integer> - a signed integer	interface index of the IpoE interface related to this VLAN, at the network side <i>This element is always shown.</i>

106.10 VLAN Name Mapping Status Command

Command Description

This command displays the VLAN identity that corresponds to a given VLAN name.

User Level

The command can be accessed by operators with vlan privileges.

Command Syntax

The command has the following syntax:

```
> show vlan name [ (name) ]
```

Command Parameters

Table 106.10-1 "VLAN Name Mapping Status Command" Resource Parameters

Resource Identifier	Type	Description
(name)	Format: - char string - length: x<=80	name used to identify the vlan

Command Output

Table 106.10-2 "VLAN Name Mapping Status Command" Display parameters

Specific Information		
name	Type	Description
id	Parameter type: <Vlan::StackedVlan> (<Vlan::UVlanIndex> stacked : <Vlan::SVlanIndex> : <Vlan::CVlanIndex>) Possible values: - stacked : stacked vlan identity Field type <Vlan::UVlanIndex> - unstacked vlan identity - range: [1...4093,4096] Field type <Vlan::SVlanIndex> - service vlan identity - range: [2...4093,4094] Field type <Vlan::CVlanIndex> - customer vlan identity - range: [0...4093,4094,4095,4096]	the vlan identity <i>This element is always shown.</i>

106.11 VLAN Filtering Database Per LIM Status

Command

Command Description

This command displays, given a particular VLAN, a unicast MAC address and a vlan port, an entry of the filtering database, if any. The filtering database is used by the bridging function in determining how to propagate a received frame. This command displays information about an entry of the filtering database associated to a network VLAN. It can also be used to display all fdb entries associated to a network VLAN.

The status parameter indicates what the trigger was for creation of the filtering database entry, that is, a filtering entry can be configured or dynamically learned.

User Level

The command can be accessed by operators with vlan privileges.

Command Syntax

The command has the following syntax:

```
> show vlan fdb-board [ (slot) [ fdb-id <Network::StackedVlan> ] [ mac <Vlan::MacAddr> ] ]
```

Command Parameters

Table 106.11-1 "VLAN Filtering Database Per LIM Status Command" Resource Parameters

Resource Identifier	Type	Description
(slot)	Format: lt : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> Possible values: - lt : lt-slot Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number	the physical slot position
fdb-id	Parameter type: <Network::StackedVlan> Format: (<Network::UVlanIndex> stacked : <Network::SVlanIndex> : <Network::CVlanIndex>) Possible values: - stacked : stacked vlan identity Field type <Network::UVlanIndex> - unstacked vlan identity - range: [1...4093]	fdb id

Resource Identifier	Type	Description
	Field type <Network::SVlanIndex> - service vlan identity - range: [2...4093] Field type <Network::CVlanIndex> - customer vlan identity - range: [0...4093]	
mac	Parameter type: <Vlan::MacAddr> Format: - mac address (aa:bb:cc:a1:02:03) - unit: Byte - length: 6	the network mac address

Command Output

Table 106.11-2 "VLAN Filtering Database Per LIM Status Command" Display parameters

Specific Information		
name	Type	Description
vlan-port	Parameter type: <Itf::VlanPortInterface> (vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::VpiId> : <Eqpt::VciId> : <Eqpt::UnstackedVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::UnstackedVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::VpiId> : <Eqpt::VciId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> / <Eqpt::OntPortId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> / <Eqpt::OntPortId> : <Eqpt::UnstackedVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / voip : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / vuni : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / voip : <Eqpt::UnstackedVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / vuni : <Eqpt::UnstackedVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::LLId> : <Eqpt::UnstackedVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::LLId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan-port.ng2 : <Eqpt::ChannelGroupId> /	vlan port <i>This element is only shown in detail mode.</i>

name	Type	Description
	<code><Eqpt::SubChannelGroupId> / <Ng2::OntId> / <Eqpt::Ng2OntSlotId> / <Eqpt::Ng2OntPortId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan></code> <code> vlan-port:ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Ng2::OntId> / <Eqpt::Ng2OntSlotId> / <Eqpt::Ng2OntPortId> : <Eqpt::UnstackedVlan></code> <code> vlan-port:ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Ng2::OntId> / vuni : stacked : <Eqpt::SVlan> : <Eqpt::CVlan></code> <code> vlan-port:ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Ng2::OntId> / vuni : <Eqpt::UnstackedVlan>)</code> Possible values: - vlan-port : vlan port - vlan-port:ng2 : ngpon2 vlan port Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number Field type <Eqpt::VpId> - atm VPI Field type <Eqpt::VciId> - atm VCI Field type <Eqpt::PonId> - the PON identifier Field type <Eqpt::OntId> - the ONT identifier Field type <Eqpt::ChannelGroupId> - the channel group identifier Field type <Eqpt::SubChannelGroupId> - the subchannel group identifier Field type <Ng2::OntId> - the ONT identifier Possible values: - voip : virtual uni identifier obsolete alternative replaced by vuni - vuni : virtual uni identifier Possible values: - vuni : virtual NGPON2 uni identifier Field type <Eqpt::OntSlotId> - the ONT SLOT identifier Field type <Eqpt::OntPortId> - the ONT PORT identifier Field type <Eqpt::Ng2OntSlotId> - the NGPON2 ONT SLOT identifier Field type <Eqpt::Ng2OntPortId> - the NGPON2 ONT PORT identifier Field type <Eqpt::LLId> - the LLID identifier,range 1 for EPON,range 1-8 for DPOE Possible values: - stacked : stacked vlan identity Field type <Eqpt::UnstackedVlan>	

name	Type	Description
	- unstacked vlan id Field type <Eqpt::SVlan> - service vlan id Field type <Eqpt::CVlan> - customer vlan id	
status	Parameter type: <Vlan::FdbEntryStatus> (other invalid learned self static) Possible values: - other : entry does not determine the forwarding of frames - invalid : entry is being removed - learned : entry has been learned dynamically - self : entry represents one of the device's addresses - static : entry has been configured by a manager	the origin of the entry, unless invalid. Invalid indicates the entry is in progress of being deleted. <i>This element is always shown.</i>
sub-mac	Parameter type: <Vlan::MacAddr> - mac address (aa:bb:cc:a1:02:03) - unit: Byte - length: 6	the user mac address ,when vmac is enabled, it identifies a vmac <i>This element is always shown.</i>

106.12 Bridge Port Filtering Database Status Command

Command Description

This command displays information about an entry of the filtering database on a particular vlan port. The filtering database is used by the bridging function in determining how to propagate a received frame. It can also be used to display all fdb entries on a vlan port or all fdb entries on a bridge port.

The status parameter indicates what the trigger was for creation of the filtering database entry, that is, a filtering entry can be configured or dynamically learned.

The command should be executed with atleast the bridgeport as mandatory input otherwise it will take longer execution time to retrieve the information in larger systems where large number of bridgeports / vlan ports are configured while limited fdb entries on part of the vlan ports.

For 7362 uplink LTs and FELT-B, a vlanport together with the bridgeport are mandatory inputs of the command. Assigning a bridgeport is not enough, because for these LT, there could be thousands of vlan ports attached to one bridgeport, it will take a long time to retrieve them all, which is different from user side.

User Level

The command can be accessed by operators with vlan privileges.

Command Syntax

The command has the following syntax:

```
> show vlan bridge-port-fdb [ (port) [ vlan-id <Vlan::StackedVlan> ] [ mac <Vlan::MacAddr> ] ]
```

Command Parameters

Table 106.12-1 "Bridge Port Filtering Database Status Command" Resource Parameters

Resource Identifier	Type	Description
(port)	Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::VpiId> : <Eqpt::VciId> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> / <Eqpt::OntPortId> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / voip <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / vuni <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::LLId>	identity of a port(e.g. atm PVC, EFM port, ...)

Resource Identifier	Type	Description
	ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Ng2::OntId> / <Eqpt::Ng2OntSlotId> / <Eqpt::Ng2OntPortId> ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Ng2::OntId> / vuni) Possible values: - ng2 : ngpon2 style identification Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number Field type <Eqpt::VpiId> - atm VPI Field type <Eqpt::VciId> - atm VCI Field type <Eqpt::PonId> - the PON identifier Field type <Eqpt::ChannelGroupId> - the channel group identifier Field type <Eqpt::SubChannelGroupId> - the subchannel group identifier Field type <Eqpt::OntId> - the ONT identifier Field type <Ng2::OntId> - the ONT identifier Possible values: - voip : virtual uni identifier obsolete alternative replaced by vuni - vuni : virtual uni identifier Possible values: - vuni : virtual NGPON2 uni identifier Field type <Eqpt::OntSlotId> - the ONT SLOT identifier Field type <Eqpt::OntPortId> - the ONT PORT identifier Field type <Eqpt::Ng2OntSlotId> - the NGPON2 ONT SLOT identifier Field type <Eqpt::Ng2OntPortId> - the NGPON2 ONT PORT identifier Field type <Eqpt::LLId> - the LLID identifier, range 1 for EPON, range 1-8 for DPOE	
vlan-id	Parameter type: <Vlan::StackedVlan> Format: (<Vlan::UVlanIndex> stacked : <Vlan::SVlanIndex> : <Vlan::CVlanIndex>) Possible values: - stacked : stacked vlan identity Field type <Vlan::UVlanIndex> - unstacked vlan identity range: [1...4093,4096] Field type <Vlan::SVlanIndex> - service vlan identity range: [2...4093]	the subscriber vlan id

Resource Identifier	Type	Description
	Field type <Vlan::CVlanIndex> - customer vlan identity - range: [0...4093]	
mac	Parameter type: <Vlan::MacAddr> Format: - mac address (aa:bb:cc:a1:02:03) - unit: Byte - length: 6	mac address

Command Output

Table 106.12-2 "Bridge Port Filtering Database Status Command" Display parameters

Specific Information		
name	Type	Description
fdb-id	Parameter type: <Vlan::StackedVlan> (<Vlan::UVlanIndex> stacked : <Vlan::SVlanIndex> : <Vlan::CVlanIndex>) Possible values: - stacked : stacked vlan identity Field type <Vlan::UVlanIndex> - unstacked vlan identity - range: [1...4093,4096] Field type <Vlan::SVlanIndex> - service vlan identity - range: [2...4093,4094] Field type <Vlan::CVlanIndex> - customer vlan identity - range: [0...4093,4094,4095,4096]	the identity of this filtering database <i>This element is always shown.</i>
status	Parameter type: <Vlan::FdbEntryStatus> (other invalid learned self static) Possible values: - other : entry does not determine the forwarding of frames - invalid : entry is being removed - learned : entry has been learned dynamically - self : entry represents one of the device's addresses - static : entry has been configured by a manager	the origin of the entry, unless invalid <i>This element is always shown.</i>
vmac	Parameter type: <Vlan::MacAddr> - mac address (aa:bb:cc:a1:02:03) - unit: Byte - length: 6	unicast virtual mac address <i>This element is always shown.</i>

106.13 VLAN Priority Regeneration Profile Status Command

Command Description

This command displays, for a given priority regeneration profile, the mapping of the external p-bit codepoints versus the internal priority. Such a profile provides a mapping for both the upstream and the downstream direction.

These priority regeneration profiles and their contents are predetermined and cannot be changed by the operator.

A priority regeneration profile is assigned to a bridge port when configuring the bridge port.

User Level

The command can be accessed by operators with vlan privileges.

Command Syntax

The command has the following syntax:

```
> show vlan priority-regen [ (profile-id) ]
```

Command Parameters

Table 106.13-1 "VLAN Priority Regeneration Profile Status Command" Resource Parameters

Resource Identifier	Type	Description
(profile-id)	Format: (trusted-port best-effort cl-all-prio-3 cl-all-prio-4 background be-cl-voice be-cl-1d-voice be-voice l2-vpn-3 l2-vpn-4 11 12 13 14 15 16 17 18 19 20 21	profile id

Resource Identifier	Type	Description
	22 23 24 25 26 27 28 29 30 31 32) Possible values: - trusted-port : trusted port - best-effort : best effort - cl-all-prio-3 : controlled load, all priority 3 traffic - cl-all-prio-4 : controlled load, all priority 4 traffic - background : background - be-cl-voice : best effort, controlled load, voice - be-cl-1d-voice : best effort, controlled load, 802.1d Annex G voice - be-voice : best effort voice - l2-vpn-3 : L2 VPN with 3 traffic classes - l2-vpn-4 : L2 VPN with 4 traffic classes - 11 : operator-defined profile - 12 : operator-defined profile - 13 : operator-defined profile - 14 : operator-defined profile - 15 : operator-defined profile - 16 : operator-defined profile - 17 : operator-defined profile - 18 : operator-defined profile - 19 : operator-defined profile - 20 : operator-defined profile - 21 : operator-defined profile - 22 : operator-defined profile - 23 : operator-defined profile - 24 : operator-defined profile - 25 : operator-defined profile - 26 : operator-defined profile - 27 : operator-defined profile - 28 : operator-defined profile - 29 : operator-defined profile - 30 : operator-defined profile - 31 : operator-defined profile - 32 : operator-defined profile	

Command Output

Table 106.13-2 "VLAN Priority Regeneration Profile Status Command" Display parameters

Specific Information		
name	Type	Description
name	Parameter type: <Vlan::AdminString> - char string - length: x<=80	name of the profile <i>This element is always shown.</i>
reference-count	Parameter type: <Vlan::Integer> - a signed integer	the reference count for the profile <i>This element is always shown.</i>

Only Show Details: priority regeneration profile		
name	Type	Description
priority-0	Parameter type: <Vlan::NibbleMask_0> - nibble mask	the regenerated priority for .1p priority codepoint 0 <i>This element is only shown in detail mode.</i>
priority-1	Parameter type: <Vlan::NibbleMask_1> - nibble mask	the regenerated priority for .1p priority codepoint 1 <i>This element is only shown in detail mode.</i>
priority-2	Parameter type: <Vlan::NibbleMask_2> - nibble mask	the regenerated priority for .1p priority codepoint 2 <i>This element is only shown in detail mode.</i>
priority-3	Parameter type: <Vlan::NibbleMask_3> - nibble mask	the regenerated priority for .1p priority codepoint 3 <i>This element is only shown in detail mode.</i>
priority-4	Parameter type: <Vlan::NibbleMask_4> - nibble mask	the regenerated priority for .1p priority codepoint 4 <i>This element is only shown in detail mode.</i>
priority-5	Parameter type: <Vlan::NibbleMask_5> - nibble mask	the regenerated priority for .1p priority codepoint 5 <i>This element is only shown in detail mode.</i>
priority-6	Parameter type: <Vlan::NibbleMask_6> - nibble mask	the regenerated priority for .1p priority codepoint 6 <i>This element is only shown in detail mode.</i>
priority-7	Parameter type: <Vlan::NibbleMask_7> - nibble mask	the regenerated priority for .1p priority codepoint 7 <i>This element is only shown in detail mode.</i>

106.14 VLAN Priority Regeneration Profile Name Status Command

Command Description

This command displays, for a given priority regeneration profile Name, the mapping of the external p-bit codepoints versus the internal priority. Such a profile provides a mapping for both the upstream and the downstream direction.

These priority regeneration profiles and their contents are predetermined and cannot be changed by the operator.

User Level

The command can be accessed by operators with vlan privileges.

Command Syntax

The command has the following syntax:

```
> show vlan prio-regen-name [ (name) ]
```

Command Parameters

Table 106.14-1 "VLAN Priority Regeneration Profile Name Status Command" Resource Parameters

Resource Identifier	Type	Description
(name)	Format: Data driven field type Possible values are depending on the actual configuration and software. The currently allowed values can be shown with online-help.	A unique profile name

Command Output

Table 106.14-2 "VLAN Priority Regeneration Profile Name Status Command" Display parameters

Specific Information		
name	Type	Description
profile-id	Parameter type: <Vlan::ShowPrioRegenProfile> (trusted-port best-effort cl-all-prio-3 cl-all-prio-4 background be-cl-voice be-cl-1d-voice be-voice	name of the profile <i>This element is always shown.</i>

name	Type	Description
	l2-vpn-3 l2-vpn-4 11 12 13 14 15 16 17 18 19 20 21 22 23 24 25 26 27 28 29 30 31 32) Possible values: - trusted-port : trusted port - best-effort : best effort - cl-all-prio-3 : controlled load, all priority 3 traffic - cl-all-prio-4 : controlled load, all priority 4 traffic - background : background - be-cl-voice : best effort, controlled load, voice - be-cl-1d-voice : best effort, controlled load, 802.1d Annex G voice - be-voice : best effort voice - l2-vpn-3 : L2 VPN with 3 traffic classes - l2-vpn-4 : L2 VPN with 4 traffic classes - 11 : operator-defined profile - 12 : operator-defined profile - 13 : operator-defined profile - 14 : operator-defined profile - 15 : operator-defined profile - 16 : operator-defined profile - 17 : operator-defined profile - 18 : operator-defined profile - 19 : operator-defined profile - 20 : operator-defined profile - 21 : operator-defined profile - 22 : operator-defined profile - 23 : operator-defined profile - 24 : operator-defined profile - 25 : operator-defined profile - 26 : operator-defined profile - 27 : operator-defined profile - 28 : operator-defined profile - 29 : operator-defined profile - 30 : operator-defined profile - 31 : operator-defined profile	

106 VLAN Status Commands

name	Type	Description
	- 32 : operator-defined profile	
reference-count	Parameter type: <Vlan::Integer> - a signed integer	the reference count for the profile <i>This element is always shown.</i>

Only Show Details: priority regeneration profile		
name	Type	Description
priority-0	Parameter type: <Vlan::NibbleMask_0> - nibble mask	the regenerated priority for .1p priority codepoint 0 <i>This element is only shown in detail mode.</i>
priority-1	Parameter type: <Vlan::NibbleMask_1> - nibble mask	the regenerated priority for .1p priority codepoint 1 <i>This element is only shown in detail mode.</i>
priority-2	Parameter type: <Vlan::NibbleMask_2> - nibble mask	the regenerated priority for .1p priority codepoint 2 <i>This element is only shown in detail mode.</i>
priority-3	Parameter type: <Vlan::NibbleMask_3> - nibble mask	the regenerated priority for .1p priority codepoint 3 <i>This element is only shown in detail mode.</i>
priority-4	Parameter type: <Vlan::NibbleMask_4> - nibble mask	the regenerated priority for .1p priority codepoint 4 <i>This element is only shown in detail mode.</i>
priority-5	Parameter type: <Vlan::NibbleMask_5> - nibble mask	the regenerated priority for .1p priority codepoint 5 <i>This element is only shown in detail mode.</i>
priority-6	Parameter type: <Vlan::NibbleMask_6> - nibble mask	the regenerated priority for .1p priority codepoint 6 <i>This element is only shown in detail mode.</i>
priority-7	Parameter type: <Vlan::NibbleMask_7> - nibble mask	the regenerated priority for .1p priority codepoint 7 <i>This element is only shown in detail mode.</i>

106.15 Show Next Free ID of VLAN Priority Regeneration Profile

Command Description

This command displays next free id of VLAN Priority Regeneration Profile.

User Level

The command can be accessed by operators with vlan privileges.

Command Syntax

The command has the following syntax:

```
> show vlan prio-regen-next
```

Command Output

Table 106.15-2 "Show Next Free ID of VLAN Priority Regeneration Profile " Display parameters

Specific Information		
name	Type	Description
next-free-index	Parameter type: <AsamNextProfileIndex> - a profile index - range: [0...65535]	next free profile index <i>This element is always shown.</i>

106.16 Duplicate MAC Alarm Status Command

Command Description

This command is useful when a duplicate MAC alarm has occurred. A duplicate MAC alarm is raised when a new MAC address could not be learned on a port because this MAC address already exists on another port for the same VLAN, that is, within the same filtering database. The information displayed indicates the port where the MAC address is assigned, that is, the original port.

The duplicate MAC alarm information is available as long as the alarm is on.

User Level

The command can be accessed by operators with vlan privileges.

Command Syntax

The command has the following syntax:

```
> show vlan dup-mac-alarm [ (dup-port) [ dup-fdb-id <Network::StackedVlan> ] [ dup-mac <Vlan::MacAddr> ] ]
```

Command Parameters

Table 106.16-1 "Duplicate MAC Alarm Status Command" Resource Parameters

Resource Identifier	Type	Description
(dup-port)	Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::VpiId> : <Eqpt::VciId> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> / <Eqpt::OntPortId> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / voip <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / vuni <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::LLId> ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Ng2::OntId> / <Eqpt::Ng2OntSlotId> / <Eqpt::Ng2OntPortId> ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Ng2::OntId> / vuni) Possible values: - ng2 : ngpon2 style identification Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number	identity of a port(e.g. atm PVC, EFM port, ...)

Resource Identifier	Type	Description
	Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number Field type <Eqpt::VpiId> - atm VPI Field type <Eqpt::Vcild> - atm VCI Field type <Eqpt::PonId> - the PON identifier Field type <Eqpt::ChannelGroupId> - the channel group identifier Field type <Eqpt::SubChannelGroupId> - the subchannel group identifier Field type <Eqpt::OntId> - the ONT identifier Field type <Ng2::OntId> - the ONT identifier Possible values: - voip : virtual uni identifier obsolete alternative replaced by vuni - vuni : virtual uni identifier Possible values: - vuni : virtual NGPON2 uni identifier Field type <Eqpt::OntSlotId> - the ONT SLOT identifier Field type <Eqpt::OntPortId> - the ONT PORT identifier Field type <Eqpt::Ng2OntSlotId> - the NGPON2 ONT SLOT identifier Field type <Eqpt::Ng2OntPortId> - the NGPON2 ONT PORT identifier Field type <Eqpt::LLId> - the LLID identifier, range 1 for EPON, range 1-8 for DPOE	
dup-fdb-id	Parameter type: <Network::StackedVlan> Format: (<Network::UVlanIndex> stacked : <Network::SVlanIndex> : <Network::CVlanIndex>) Possible values: - stacked : stacked vlan identity Field type <Network::UVlanIndex> - unstacked vlan identity - range: [1...4093] Field type <Network::SVlanIndex> - service vlan identity - range: [2...4093] Field type <Network::CVlanIndex> - customer vlan identity - range: [0...4093]	duplicate fdb id
dup-mac	Parameter type: <Vlan::MacAddr> Format: - mac address (aa:bb:cc:a1:02:03) - unit: Byte - length: 6	duplicate mac address

Command Output

Table 106.16-2 "Duplicate MAC Alarm Status Command" Display parameters

Specific Information		
name	Type	Description
port	Parameter type: <Vlan::BridgePort> (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::VpiId> : <Eqpt::VciId> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> / <Eqpt::OntPortId> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / voip <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / vuni <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::LLId> ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Ng2::OntId> / <Eqpt::Ng2OntSlotId> / <Eqpt::Ng2OntPortId> ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Ng2::OntId> / vuni) Possible values: - ng2 : ngpon2 vlan bridge port Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number Field type <Eqpt::VpiId> - atm VPI Field type <Eqpt::VciId> - atm VCI Field type <Eqpt::PonId> - the PON identifier Field type <Eqpt::ChannelGroupId> - the channel group identifier Field type <Eqpt::SubChannelGroupId> - the subchannel group identifier Field type <Eqpt::OntId> - the ONT identifier Field type <Ng2::OntId> - the ONT identifier Possible values: - voip : virtual uni identifier obsolete alternative replaced by vuni - vuni : virtual uni identifier Possible values: - vuni : virtual NGPON2 uni identifier Field type <Eqpt::OntSlotId> - the ONT SLOT identifier Field type <Eqpt::OntPortId> - the ONT PORT identifier Field type <Eqpt::Ng2OntSlotId>	identity of a port(e.g. atm PVC, EFM port, ...) <i>This element is always shown.</i>

name	Type	Description
	- the NGPON2 ONT SLOT identifier Field type <Eqpt::Ng2OntPortId> - the NGPON2 ONT PORT identifier Field type <Eqpt::LLId> - the LLID identifier,range 1 for EPON,range 1-8 for DPOE	
sub-vlan	Parameter type: <Vlan::StackedVlan> (<Vlan::UVlanIndex> stacked : <Vlan::SVlanIndex> : <Vlan::CVlanIndex>) Possible values: - stacked : stacked vlan identity Field type <Vlan::UVlanIndex> - unstacked vlan identity - range: [1...4093,4096] Field type <Vlan::SVlanIndex> - service vlan identity - range: [2...4093,4094] Field type <Vlan::CVlanIndex> - customer vlan identity - range: [0...4093,4094,4095,4096]	the subscriber vlan associated to bridge port <i>This element is always shown.</i>
dup-sub-vlan	Parameter type: <Vlan::StackedVlan> (<Vlan::UVlanIndex> stacked : <Vlan::SVlanIndex> : <Vlan::CVlanIndex>) Possible values: - stacked : stacked vlan identity Field type <Vlan::UVlanIndex> - unstacked vlan identity - range: [1...4093,4096] Field type <Vlan::SVlanIndex> - service vlan identity - range: [2...4093,4094] Field type <Vlan::CVlanIndex> - customer vlan identity - range: [0...4093,4094,4095,4096]	the subscriber vlan associated to duplicate bridge port <i>This element is always shown.</i>

106.17 Port Event Status Command

Command Description

This command displays all the kinds of events that occurred on a given port. These events relate to error cases.

*The display element **no-mac-learn** that indicates that not all mac addresses are learned, is not applicable for intel/CATE boards.*

User Level

The command can be accessed by operators with vlan privileges.

Command Syntax

The command has the following syntax:

```
> show vlan port-event [ (port) ]
```

Command Parameters

Table 106.17-1 "Port Event Status Command" Resource Parameters

Resource Identifier	Type	Description
(port)	Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::VpiId> : <Eqpt::VciId> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> / <Eqpt::OntPortId> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / voip <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / vuni <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::LLId> ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / <Eqpt::Ng2OntSlotId> / <Eqpt::Ng2OntPortId> ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / vuni) Possible values: - ng2 : ngpon2 style identification Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number	identity of a port(e.g. atm PVC, EFM port, ...)

Resource Identifier	Type	Description
	Field type <Eqpt::PortId> - the port number Field type <Eqpt::VpiId> - atm VPI Field type <Eqpt::VciId> - atm VCI Field type <Eqpt::ChannelGroupId> - the channel group identifier Field type <Eqpt::SubChannelGroupId> - the subchannel group identifier Field type <Eqpt::PonId> - the PON identifier Field type <Eqpt::OntId> - the ONT identifier Field type <Eqpt::Ng2OntId> - the NG2 ONT identifier Possible values: - voip : virtual uni identifier obsolete alternative replaced by vuni - vuni : virtual uni identifier Possible values: - vuni : virtual NGPON2 uni identifier Field type <Eqpt::OntSlotId> - the ONT SLOT identifier Field type <Eqpt::OntPortId> - the ONT PORT identifier Field type <Eqpt::Ng2OntSlotId> - the NGPON2 ONT SLOT identifier Field type <Eqpt::Ng2OntPortId> - the NGPON2 ONT PORT identifier Field type <Eqpt::LLId> - the LLID identifier, range 1 for EPON, range 1-8 for DPOE	

Command Output

Table 106.17-2 "Port Event Status Command" Display parameters

Specific Information		
name	Type	Description
event-time	Parameter type: <Equipm::restartTime> - the time (yyyy-mm-dd:hour:minutes:secs) - unit: UTC	the time in seconds when the event occurred <i>This element is always shown.</i>
aal5-fcs-error short name: aal5-fcs	Parameter type: <Vlan::Aal5FcsError> ((aal5-fcs yes) (no-aal5-fcs no)) Possible values: - aal5-fcs : aal5 or fcs error - yes : aal5 or fcs error - no-aal5-fcs : no aal5 or fcs error - no : no aal5 or fcs error	error of the aal5 frame or fcs error <i>This element is always shown.</i>
llc-error short name: llc	Parameter type: <Vlan::LlcError> ((llc yes) (no-llc no)) Possible values: - llc : incorrect llc - yes : incorrect llc - no-llc : correct llc	incorrect llc format <i>This element is always shown.</i>

106 VLAN Status Commands

name	Type	Description
	- no : correct llc	
no-mac-learn short name: no-mac	Parameter type: <Vlan::MacNoLearnError> ((mac-learn-error yes) (no-mac-learn-error no)) Possible values: - mac-learn-error : mac learn error - yes : mac learn error - no-mac-learn-error : no mac learn error - no : no mac learn error	new MAC address could not be learned, upstream pkt is discarded <i>This element is always shown.</i>
dup-mac	Parameter type: <Vlan::MacDuplicateError> ((mac-dup-error yes) (no-mac-dup-error no)) Possible values: - mac-dup-error : mac duplicate error - yes : mac duplicate error - no-mac-dup-error : no mac duplicate error - no : no mac duplicate error	failure of MAC address learning while MAC address already exists on another port within the same VLAN <i>This element is always shown.</i>

106.18 Port Statistics for Current Quarter Status Command

Command Description

This command displays performance statistics for the current quarter for a particular port. Counters for upstream and downstream traffic are displayed. These counters include all traffic on the port, including PPPoE relayed and PPPoE terminated traffic.

Counters for discarded frames are displayed. Frames are discarded as a result of buffer acceptance control or policing.

User Level

The command can be accessed by operators with vlan privileges.

Command Syntax

The command has the following syntax:

```
> show vlan port-curr-15min-stats [ (port) ]
```

Command Parameters

Table 106.18-1 "Port Statistics for Current Quarter Status Command" Resource Parameters

Resource Identifier	Type	Description
(port)	Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::VpiId> : <Eqpt::VciId> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> / <Eqpt::OntPortId> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / voip <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / vuni <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::LLId> ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Ng2::OntId> / <Eqpt::Ng2OntSlotId> / <Eqpt::Ng2OntPortId> ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Ng2::OntId> / vuni) Possible values: - ng2 : ngpon2 vlan bridge port	identity of a port(e.g. atm PVC, EFM port, ...)

Resource Identifier	Type	Description
	Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number Field type <Eqpt::VpiId> - atm VPI Field type <Eqpt::VciId> - atm VCI Field type <Eqpt::PonId> - the PON identifier Field type <Eqpt::ChannelGroupId> - the channel group identifier Field type <Eqpt::SubChannelGroupId> - the subchannel group identifier Field type <Eqpt::OntId> - the ONT identifier Field type <Ng2::OntId> - the ONT identifier Possible values: - voip : virtual uni identifier obsolete alternative replaced by vuni - vuni : virtual uni identifier Possible values: - vuni : virtual NGPON2 uni identifier Field type <Eqpt::OntSlotId> - the ONT SLOT identifier Field type <Eqpt::OntPortId> - the ONT PORT identifier Field type <Eqpt::Ng2OntSlotId> - the NGPON2 ONT SLOT identifier Field type <Eqpt::Ng2OntPortId> - the NGPON2 ONT PORT identifier Field type <Eqpt::LLId> - the LLID identifier, range 1 for EPON, range 1-8 for DPOE	

Command Output

Table 106.18-2 "Port Statistics for Current Quarter Status Command" Display parameters

Specific Information		
name	Type	Description
elapsed-time	Parameter type: <Vlan::StatsTime> - time - unit: sec	elapsed time in this interval, i.e. for the current 15 minutes interval; expressed in seconds <i>This element is always shown.</i>
measure-time	Parameter type: <Vlan::StatsTime> - time - unit: sec	actually measured time in this interval; expressed in seconds <i>This element is always shown.</i>
Only Show Details: up stream counters		
name	Type	Description
forward-frame	Parameter type: <Vlan::OctetCounter> - vlan counter	number of frames forwarded in upstream direction on a bridge

name	Type	Description
		port, for the specified interval <i>This element is only shown in detail mode.</i>
forward-byte	Parameter type: <Vlan::OctetCounter> - vlan counter	number of bytes forwarded in upstream direction on a bridge port, for the specified interval <i>This element is only shown in detail mode.</i>
discard-frame	Parameter type: <Vlan::OctetCounter> - vlan counter	number of discarded frames in upstream direction on a bridge port, for the specified interval <i>This element is only shown in detail mode.</i>
discard-byte	Parameter type: <Vlan::OctetCounter> - vlan counter	number of discarded bytes in upstream direction on a bridge port, for the specified interval <i>This element is only shown in detail mode.</i>

Only Show Details: down stream counters		
name	Type	Description
forward-frame	Parameter type: <Vlan::OctetCounter> - vlan counter	number of frames forwarded in downstream direction on a bridge port, for the specified interval <i>This element is only shown in detail mode.</i>
forward-byte	Parameter type: <Vlan::OctetCounter> - vlan counter	number of bytes forwarded in downstream direction on a bridge port, for the specified interval <i>This element is only shown in detail mode.</i>
discard-frame	Parameter type: <Vlan::OctetCounter> - vlan counter	number of discarded frames in downstream direction on a bridge port, for the specified interval <i>This element is only shown in detail mode.</i>
discard-byte	Parameter type: <Vlan::OctetCounter> - vlan counter	number of discarded bytes in downstream direction on a bridge port, for the specified interval <i>This element is only shown in detail mode.</i>

106.19 Port Statistics for Current Day Status Command

Command Description

This command shows Performance Statistics for the current day for a particular port. Counters for upstream and downstream traffic are displayed. These counters include all traffic on the port, including PPPoE Relayed and PPPoE terminated traffic.

Counters for discarded frames are displayed. Frames are discarded as a result of buffer acceptance control or policing.

User Level

The command can be accessed by operators with vlan privileges.

Command Syntax

The command has the following syntax:

```
> show vlan port-curr-day-stats [ (port) ]
```

Command Parameters

Table 106.19-1 "Port Statistics for Current Day Status Command" Resource Parameters

Resource Identifier	Type	Description
(port)	Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::VpiId> : <Eqpt::VciId> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> / <Eqpt::OntPortId> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / voip <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / vuni <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::LLId> ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Ng2::OntId> / <Eqpt::Ng2OntSlotId> / <Eqpt::Ng2OntPortId> ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Ng2::OntId> / vuni) Possible values: - ng2 : ngpon2 vlan bridge port	identity of a port(e.g. atm PVC, EFM port, ...)

Resource Identifier	Type	Description
	Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number Field type <Eqpt::VpiId> - atm VPI Field type <Eqpt::VciId> - atm VCI Field type <Eqpt::PonId> - the PON identifier Field type <Eqpt::ChannelGroupId> - the channel group identifier Field type <Eqpt::SubChannelGroupId> - the subchannel group identifier Field type <Eqpt::OntId> - the ONT identifier Field type <Ng2::OntId> - the ONT identifier Possible values: - voip : virtual uni identifier obsolete alternative replaced by vuni - vuni : virtual uni identifier Possible values: - vuni : virtual NGPON2 uni identifier Field type <Eqpt::OntSlotId> - the ONT SLOT identifier Field type <Eqpt::OntPortId> - the ONT PORT identifier Field type <Eqpt::Ng2OntSlotId> - the NGPON2 ONT SLOT identifier Field type <Eqpt::Ng2OntPortId> - the NGPON2 ONT PORT identifier Field type <Eqpt::LLId> - the LLID identifier, range 1 for EPON, range 1-8 for DPOE	

Command Output

Table 106.19-2 "Port Statistics for Current Day Status Command" Display parameters

Specific Information		
name	Type	Description
elapsed-time	Parameter type: <Vlan::StatsTime> - time - unit: sec	elapsed time in this interval, i.e. for the current day interval; expressed in seconds <i>This element is always shown.</i>
measure-time	Parameter type: <Vlan::StatsTime> - time - unit: sec	actually measured time in this interval; expressed in seconds <i>This element is always shown.</i>
Only Show Details: up stream counters		
name	Type	Description
forward-frame	Parameter type: <Vlan::OctetCounter> - vlan counter	number of frames forwarded in upstream direction on a bridge

106 VLAN Status Commands

name	Type	Description
		port, for the specified interval <i>This element is only shown in detail mode.</i>
forward-byte	Parameter type: <Vlan::OctetCounter> - vlan counter	number of bytes forwarded in upstream direction on a bridge port, for the specified interval <i>This element is only shown in detail mode.</i>
discard-frame	Parameter type: <Vlan::OctetCounter> - vlan counter	number of discarded frames in upstream direction on a bridge port, for the specified interval <i>This element is only shown in detail mode.</i>
discard-byte	Parameter type: <Vlan::OctetCounter> - vlan counter	number of discarded bytes in upstream direction on a bridge port, for the specified interval <i>This element is only shown in detail mode.</i>

Only Show Details: down stream counters		
name	Type	Description
forward-frame	Parameter type: <Vlan::OctetCounter> - vlan counter	number of frames forwarded in downstream direction on a bridge port, for the specified interval <i>This element is only shown in detail mode.</i>
forward-byte	Parameter type: <Vlan::OctetCounter> - vlan counter	number of bytes forwarded in downstream direction on a bridge port, for the specified interval <i>This element is only shown in detail mode.</i>
discard-frame	Parameter type: <Vlan::OctetCounter> - vlan counter	number of discarded frames in downstream direction on a bridge port, for the specified interval <i>This element is only shown in detail mode.</i>
discard-byte	Parameter type: <Vlan::OctetCounter> - vlan counter	number of discarded bytes in downstream direction on a bridge port, for the specified interval <i>This element is only shown in detail mode.</i>

106.20 Port Statistics for Previous Quarter Intervals

Status Command

Command Description

This command displays performance statistics for the previous quarter intervals, for a particular port. Counters for upstream and downstream traffic are displayed. These counters include all traffic on the port, including PPPoE relayed and PPPoE terminated traffic.

Counters for discarded frames are displayed. Frames are discarded as a result of buffer acceptance control or policing.

The interval is specified. Interval number 1 identifies the most recent completed quarter interval. From there onward, interval numbers are incremented by 1. Higher interval numbers relate to less recent intervals.

User Level

The command can be accessed by operators with vlan privileges.

Command Syntax

The command has the following syntax:

```
> show vlan port-15min-stats [ (port) [ interval-number <Vlan::IntervalNumber> ] ]
```

Command Parameters

Table 106.20-1 "Port Statistics for Previous Quarter Intervals Status Command" Resource Parameters

Resource Identifier	Type	Description
(port)	Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::Vpild> : <Eqpt::Vcild> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> / <Eqpt::OntPortId> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / voip <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / vuni <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::LLId> ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Ng2::OntId> / <Eqpt::Ng2OntSlotId> / <Eqpt::Ng2OntPortId> ng2 : <Eqpt::ChannelGroupId> /	identity of a port(e.g. atm PVC, EFM port, ...)

Resource Identifier	Type	Description
	<Eqpt::SubChannelGroupId> / <Ng2::OntId> / vuni) Possible values: - ng2 : ngpon2 vlan bridge port Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number Field type <Eqpt::VpiId> - atm VPI Field type <Eqpt::VciId> - atm VCI Field type <Eqpt::PonId> - the PON identifier Field type <Eqpt::ChannelGroupId> - the channel group identifier Field type <Eqpt::SubChannelGroupId> - the subchannel group identifier Field type <Eqpt::OntId> - the ONT identifier Field type <Ng2::OntId> - the ONT identifier Possible values: - voip : virtual uni identifier obsolete alternative replaced by vuni - vuni : virtual uni identifier Possible values: - vuni : virtual NGPON2 uni identifier Field type <Eqpt::OntSlotId> - the ONT SLOT identifier Field type <Eqpt::OntPortId> - the ONT PORT identifier Field type <Eqpt::Ng2OntSlotId> - the NGPON2 ONT SLOT identifier Field type <Eqpt::Ng2OntPortId> - the NGPON2 ONT PORT identifier Field type <Eqpt::LLId> - the LLID identifier, range 1 for EPON, range 1-8 for DPOE	
interval-number	Parameter type: <Vlan::IntervalNumber> Format: - [1...32] for gpon, [1...96] for others - range: [1...96]	interval number, where 1 is the most recent completed interval

Command Output

Table 106.20-2 "Port Statistics for Previous Quarter Intervals Status Command" Display parameters

Specific Information		
name	Type	Description
measure-time	Parameter type: <Vlan::StatsTime> - time - unit: sec	actually measured time in this interval; expressed in seconds <i>This element is always shown.</i>

Only Show Details: up stream counters		
name	Type	Description
forward-frame	Parameter type: <Vlan::OctetCounter> - vlan counter	number of frames forwarded in upstream direction on a bridge port, for the specified interval <i>This element is only shown in detail mode.</i>
forward-byte	Parameter type: <Vlan::OctetCounter> - vlan counter	number of bytes forwarded in upstream direction on a bridge port, for the specified interval <i>This element is only shown in detail mode.</i>
discard-frame	Parameter type: <Vlan::OctetCounter> - vlan counter	number of discarded frames in upstream direction on a bridge port, for the specified interval. Frames are discarded as a result of buffer acceptance or policing <i>This element is only shown in detail mode.</i>
discard-byte	Parameter type: <Vlan::OctetCounter> - vlan counter	number of discarded bytes in upstream direction on a bridge port, for the specified interval. Discarding is a result of buffer acceptance or policing <i>This element is only shown in detail mode.</i>

Only Show Details: down stream counters		
name	Type	Description
forward-frame	Parameter type: <Vlan::OctetCounter> - vlan counter	number of frames forwarded in downstream direction on a bridge port, for the specified interval <i>This element is only shown in detail mode.</i>
forward-byte	Parameter type: <Vlan::OctetCounter> - vlan counter	number of bytes forwarded in downstream direction on a bridge port, for the specified interval <i>This element is only shown in detail mode.</i>
discard-frame	Parameter type: <Vlan::OctetCounter> - vlan counter	number of discarded frames in downstream direction on a bridge port, for the specified interval <i>This element is only shown in detail mode.</i>
discard-byte	Parameter type: <Vlan::OctetCounter> - vlan counter	number of discarded bytes in downstream direction on a bridge port, for the specified interval <i>This element is only shown in detail mode.</i>

106.21 Port Statistics for Previous Day Intervals

Status Command

Command Description

This command displays performance statistics for the previous day intervals for a particular port. Counters for upstream and downstream traffic are displayed. These counters include all traffic on the port, including PPPoE relayed and PPPoE terminated traffic.

Counters for discarded frames are displayed. Frames are discarded as a result of buffer acceptance control or policing.

The interval is specified. Interval number 1 identifies the most recent completed day interval. From there onward, interval numbers are incremented by 1. Higher interval numbers relate to less recent intervals.

User Level

The command can be accessed by operators with vlan privileges.

Command Syntax

The command has the following syntax:

```
> show vlan port-prev-day-stats [ (port) [ interval-number <Vlan::DayIntervalNumber> ] ]
```

Command Parameters

Table 106.21-1 "Port Statistics for Previous Day Intervals Status Command" Resource Parameters

Resource Identifier	Type	Description
(port)	Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::VpiId> : <Eqpt::VciId> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> / <Eqpt::OntPortId> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / voip <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / vuni <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::LLId> ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Ng2::OntId> / <Eqpt::Ng2OntSlotId> / <Eqpt::Ng2OntPortId> ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Ng2::OntId> / vuni)	identity of a port(e.g. atm PVC, EFM port, ...)

Resource Identifier	Type	Description
	Possible values: - ng2 : ngpon2 vlan bridge port Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number Field type <Eqpt::VpiId> - atm VPI Field type <Eqpt::Vcild> - atm VCI Field type <Eqpt::PonId> - the PON identifier Field type <Eqpt::ChannelGroupId> - the channel group identifier Field type <Eqpt::SubChannelGroupId> - the subchannel group identifier Field type <Eqpt::OntId> - the ONT identifier Field type <Ng2::OntId> - the ONT identifier Possible values: - voip : virtual uni identifier obsolete alternative replaced by vuni - vuni : virtual uni identifier Possible values: - vuni : virtual NGPON2 uni identifier Field type <Eqpt::OntSlotId> - the ONT SLOT identifier Field type <Eqpt::OntPortId> - the ONT PORT identifier Field type <Eqpt::Ng2OntSlotId> - the NGPON2 ONT SLOT identifier Field type <Eqpt::Ng2OntPortId> - the NGPON2 ONT PORT identifier Field type <Eqpt::LLId> - the LLID identifier, range 1 for EPON, range 1-8 for DPOE	
interval-number	Parameter type: <Vlan::DayIntervalNumber> Format: - IntervalNumber for one day pm - range: [1]	interval number

Command Output

Table 106.21-2 "Port Statistics for Previous Day Intervals Status Command" Display parameters

Specific Information		
name	Type	Description
measure-time	Parameter type: <Vlan::StatsTime> - time - unit: sec	actually measured time in this interval; expressed in seconds <i>This element is always shown.</i>

Only Show Details: up stream counters

106 VLAN Status Commands

name	Type	Description
forward-frame	Parameter type: <Vlan::OctetCounter> - vlan counter	number of frames forwarded in upstream direction on a bridge port, for the specified interval <i>This element is only shown in detail mode.</i>
forward-byte	Parameter type: <Vlan::OctetCounter> - vlan counter	number of bytes forwarded in upstream direction on a bridge port, for the specified interval <i>This element is only shown in detail mode.</i>
discard-frame	Parameter type: <Vlan::OctetCounter> - vlan counter	number of discarded frames in upstream direction on a bridge port, for the specified interval <i>This element is only shown in detail mode.</i>
discard-byte	Parameter type: <Vlan::OctetCounter> - vlan counter	number of discarded bytes in upstream direction on a bridge port, for the specified interval <i>This element is only shown in detail mode.</i>

Only Show Details: down stream counters		
name	Type	Description
forward-frame	Parameter type: <Vlan::OctetCounter> - vlan counter	number of frames forwarded in downstream direction on a bridge port, for the specified interval <i>This element is only shown in detail mode.</i>
forward-byte	Parameter type: <Vlan::OctetCounter> - vlan counter	number of bytes forwarded in downstream direction on a bridge port, for the specified interval <i>This element is only shown in detail mode.</i>
discard-frame	Parameter type: <Vlan::OctetCounter> - vlan counter	number of discarded frames in downstream direction on a bridge port, for the specified interval <i>This element is only shown in detail mode.</i>
discard-byte	Parameter type: <Vlan::OctetCounter> - vlan counter	number of discarded bytes in downstream direction on a bridge port, for the specified interval <i>This element is only shown in detail mode.</i>

106.22 VLAN Port Statistics for Current Quarter

Status Command

Command Description

This command displays performance statistics for the current quarter for a particular VLAN and port. Counters for upstream and downstream traffic are displayed. These counters include all traffic on the port, including PPPoE relayed and PPPoE terminated traffic.

User Level

The command can be accessed by operators with vlan privileges.

Command Syntax

The command has the following syntax:

```
> show vlan current-15min-stats [ (vlanid) [ port <Vlan::BridgePort> ] ]
```

Command Parameters

Table 106.22-1 "VLAN Port Statistics for Current Quarter Status Command" Resource Parameters

Resource Identifier	Type	Description
(vlanid)	Format: (<Vlan::UVlanIndex> stacked : <Vlan::SVlanIndex> : <Vlan::CVlanIndex>) Possible values: - stacked : stacked vlan identity Field type <Vlan::UVlanIndex> - unstacked vlan identity - range: [1...4093,4096] Field type <Vlan::SVlanIndex> - service vlan identity - range: [2...4093] Field type <Vlan::CVlanIndex> - customer vlan identity - range: [0...4093]	vlan id
port	Parameter type: <Vlan::BridgePort> Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::VpiId> : <Eqpt::VciId> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> / <Eqpt::OntPortId> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> /	identity of a port(e.g. atm PVC, EFM port, ...)

Resource Identifier	Type	Description
	<code><Eqpt::PonId> / <Eqpt::OntId> / voip</code> <code> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> /</code> <code><Eqpt::PonId> / <Eqpt::OntId> / vuni</code> <code> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> /</code> <code><Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::LLId></code> <code> ng2 : <Eqpt::ChannelGroupId> /</code> <code><Eqpt::SubChannelGroupId> / <Ng2::OntId> /</code> <code><Eqpt::Ng2OntSlotId> / <Eqpt::Ng2OntPortId></code> <code> ng2 : <Eqpt::ChannelGroupId> /</code> <code><Eqpt::SubChannelGroupId> / <Ng2::OntId> / vuni)</code> Possible values: - ng2 : ngpon2 vlan bridge port Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number Field type <Eqpt::VpiId> - atm VPI Field type <Eqpt::VciId> - atm VCI Field type <Eqpt::PonId> - the PON identifier Field type <Eqpt::ChannelGroupId> - the channel group identifier Field type <Eqpt::SubChannelGroupId> - the subchannel group identifier Field type <Eqpt::OntId> - the ONT identifier Field type <Ng2::OntId> - the ONT identifier Possible values: - voip : virtual uni identifier obsolete alternative replaced by vuni - vuni : virtual uni identifier Possible values: - vuni : virtual NGPON2 uni identifier Field type <Eqpt::OntSlotId> - the ONT SLOT identifier Field type <Eqpt::OntPortId> - the ONT PORT identifier Field type <Eqpt::Ng2OntSlotId> - the NGPON2 ONT SLOT identifier Field type <Eqpt::Ng2OntPortId> - the NGPON2 ONT PORT identifier Field type <Eqpt::LLId> - the LLID identifier, range 1 for EPON, range 1-8 for DPOE	

Command Output

Table 106.22-2 "VLAN Port Statistics for Current Quarter Status Command" Display parameters

Specific Information

name	Type	Description
elapsed-time	Parameter type: <Vlan::StatsTime> - time - unit: sec	elapsed time in this interval, i.e. for the current 15 minutes interval; expressed in seconds <i>This element is always shown.</i>
measure-time	Parameter type: <Vlan::StatsTime> - time - unit: sec	actually measured time in this interval; expressed in seconds <i>This element is always shown.</i>

Only Show Details: up stream counters		
name	Type	Description
forward-frame	Parameter type: <Vlan::OctetCounter> - vlan counter	number of frames forwarded in upstream direction per VLAN on a bridge port, for the specified interval <i>This element is only shown in detail mode.</i>
forward-byte	Parameter type: <Vlan::OctetCounter> - vlan counter	number of frames forwarded in upstream direction per VLAN on a bridge port, for the specified interval <i>This element is only shown in detail mode.</i>
discard-frame	Parameter type: <Vlan::OctetCounter> - vlan counter	number of discarded frames in upstream direction per VLAN on a bridge port, for the specified interval <i>This element is only shown in detail mode.</i>
discard-byte	Parameter type: <Vlan::OctetCounter> - vlan counter	number of discarded bytes in upstream direction per VLAN on a bridge port, for the specified interval <i>This element is only shown in detail mode.</i>

Only Show Details: down stream counters		
name	Type	Description
forward-frame	Parameter type: <Vlan::OctetCounter> - vlan counter	number of frames forwarded in downstream direction per VLAN on a bridge port, for the specified interval <i>This element is only shown in detail mode.</i>
forward-byte	Parameter type: <Vlan::OctetCounter> - vlan counter	number of bytes forwarded in downstream direction per VLAN on a bridge port, for the specified interval <i>This element is only shown in detail mode.</i>
discard-frame	Parameter type: <Vlan::OctetCounter> - vlan counter	number of discarded frames in downstream direction per VLAN on a bridge port, for the specified interval <i>This element is only shown in detail mode.</i>
discard-byte	Parameter type: <Vlan::OctetCounter> - vlan counter	number of discarded bytes in downstream direction per VLAN on a bridge port, for the specified interval

106 VLAN Status Commands

name	Type	Description
		interval <i>This element is only shown in detail mode.</i>

106.23 VLAN Port Statistics for Current Day Status Command

Command Description

This command displays performance statistics for the current day for a particular VLAN and port. Counters for upstream and downstream traffic are displayed. These counters include all traffic on the port, including PPPoE relayed and PPPoE terminated traffic.

Counters for discarded frames are displayed. Frames are discarded as a result of buffer acceptance control or policing.

User Level

The command can be accessed by operators with vlan privileges.

Command Syntax

The command has the following syntax:

```
> show vlan current-day-stats [ (vlanid) [ port <Vlan::BridgePort> ] ]
```

Command Parameters

Table 106.23-1 "VLAN Port Statistics for Current Day Status Command" Resource Parameters

Resource Identifier	Type	Description
(vlanid)	Format: (<Vlan::UVlanIndex> stacked : <Vlan::SVlanIndex> : <Vlan::CVlanIndex>) Possible values: - stacked : stacked vlan identity Field type <Vlan::UVlanIndex> - unstacked vlan identity - range: [1...4093,4096] Field type <Vlan::SVlanIndex> - service vlan identity - range: [2...4093] Field type <Vlan::CVlanIndex> - customer vlan identity - range: [0...4093]	vlan id
port	Parameter type: <Vlan::BridgePort> Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::VpId> : <Eqpt::VcId> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> /	identity of a port(e.g. atm PVC, EFM port, ...)

Resource Identifier	Type	Description
	<code><Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> / <Eqpt::OntPortId></code> <code> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / voip</code> <code> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / vuni</code> <code> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::LLId></code> <code> ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Ng2::OntId> / <Eqpt::Ng2OntSlotId> / <Eqpt::Ng2OntPortId></code> <code> ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Ng2::OntId> / vuni)</code> Possible values: - ng2 : ngpon2 vlan bridge port Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number Field type <Eqpt::VpiId> - atm VPI Field type <Eqpt::VciId> - atm VCI Field type <Eqpt::PonId> - the PON identifier Field type <Eqpt::ChannelGroupId> - the channel group identifier Field type <Eqpt::SubChannelGroupId> - the subchannel group identifier Field type <Eqpt::OntId> - the ONT identifier Field type <Ng2::OntId> - the ONT identifier Possible values: - voip : virtual uni identifier obsolete alternative replaced by vuni - vuni : virtual uni identifier Possible values: - vuni : virtual NGPON2 uni identifier Field type <Eqpt::OntSlotId> - the ONT SLOT identifier Field type <Eqpt::OntPortId> - the ONT PORT identifier Field type <Eqpt::Ng2OntSlotId> - the NGPON2 ONT SLOT identifier Field type <Eqpt::Ng2OntPortId> - the NGPON2 ONT PORT identifier Field type <Eqpt::LLId> - the LLID identifier, range 1 for EPON, range 1-8 for DPOE	

Command Output

Table 106.23-2 "VLAN Port Statistics for Current Day Status Command" Display parameters

Specific Information		
name	Type	Description
elapsed-time	Parameter type: <Vlan::StatsTime> - time - unit: sec	elapsed time in this interval, i.e. for the current 15 minutes interval; expressed in seconds <i>This element is always shown.</i>
measure-time	Parameter type: <Vlan::StatsTime> - time - unit: sec	actually measured time in this interval; expressed in seconds <i>This element is always shown.</i>

Only Show Details: up stream counters		
name	Type	Description
forward-frame	Parameter type: <Vlan::OctetCounter> - vlan counter	number of frames forwarded in upstream direction per VLAN on a bridge port, for the specified interval <i>This element is only shown in detail mode.</i>
forward-byte	Parameter type: <Vlan::OctetCounter> - vlan counter	number of bytes forwarded in upstream direction per VLAN on a bridge port, for the specified interval <i>This element is only shown in detail mode.</i>
discard-frame	Parameter type: <Vlan::OctetCounter> - vlan counter	number of discarded frames in upstream direction per VLAN on a bridge port, for the specified interval <i>This element is only shown in detail mode.</i>
discard-byte	Parameter type: <Vlan::OctetCounter> - vlan counter	number of discarded bytes in upstream direction per VLAN on a bridge port, for the specified interval <i>This element is only shown in detail mode.</i>

Only Show Details: down stream counters		
name	Type	Description
forward-frame	Parameter type: <Vlan::OctetCounter> - vlan counter	number of frames forwarded in downstream direction per VLAN on a bridge port, for the specified interval <i>This element is only shown in detail mode.</i>
forward-byte	Parameter type: <Vlan::OctetCounter> - vlan counter	number of bytes forwarded in downstream direction per VLAN on a bridge port, for the specified interval <i>This element is only shown in detail mode.</i>
discard-frame	Parameter type: <Vlan::OctetCounter> - vlan counter	number of discarded frames in downstream direction per VLAN on a bridge port, for the specified interval <i>This element is only shown in detail mode.</i>

106 VLAN Status Commands

name	Type	Description
discard-byte	Parameter type: <Vlan::OctetCounter> - vlan counter	number of discarded bytes in downstream direction per VLAN on a bridge port, for the specified interval <i>This element is only shown in detail mode.</i>

106.24 VLAN Port Statistics for Previous Quarter Intervals Status Command

Command Description

This command displays performance statistics for the previous quarter intervals for a particular VLAN and port. Counters for upstream and downstream traffic are displayed. These counters include all traffic on the port, including PPPoE relayed and PPPoE terminated traffic.

The interval is specified. Interval number 1 identifies the most recent completed quarter interval. From there onward, interval numbers are incremented by 1. Higher interval numbers relate to less recent intervals.

Counters for discarded frames are displayed. Frames are discarded as a result of buffer acceptance control or policing.

User Level

The command can be accessed by operators with vlan privileges.

Command Syntax

The command has the following syntax:

```
> show vlan previous-15min-stats [ (vlanid) [ port <Vlan::BridgePort> ] [ interval-number <Vlan::IntervalNumber> ] ]
```

Command Parameters

Table 106.24-1 "VLAN Port Statistics for Previous Quarter Intervals Status Command" Resource Parameters

Resource Identifier	Type	Description
(vlanid)	Format: (<Vlan::UVlanIndex> stacked : <Vlan::SVlanIndex> : <Vlan::CVlanIndex>) Possible values: - stacked : stacked vlan identity Field type <Vlan::UVlanIndex> - unstacked vlan identity - range: [1...4093,4096] Field type <Vlan::SVlanIndex> - service vlan identity - range: [2...4093] Field type <Vlan::CVlanIndex> - customer vlan identity - range: [0...4093]	vlan id
port	Parameter type: <Vlan::BridgePort> Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> /	identity of a port(e.g. atm PVC, EFM port, ...)

Resource Identifier	Type	Description
	<code><Eqpt::PortId> : <Eqpt::VpId> : <Eqpt::VcId></code> <code> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> /</code> <code><Eqpt::PortId></code> <code> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> /</code> <code><Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> /</code> <code><Eqpt::OntPortId></code> <code> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> /</code> <code><Eqpt::PonId> / <Eqpt::OntId> / voip</code> <code> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> /</code> <code><Eqpt::PonId> / <Eqpt::OntId> / vuni</code> <code> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> /</code> <code><Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::LLId></code> <code> ng2 : <Eqpt::ChannelGroupId> /</code> <code><Eqpt::SubChannelGroupId> / <Ng2::OntId> /</code> <code><Eqpt::Ng2OntSlotId> / <Eqpt::Ng2OntPortId></code> <code> ng2 : <Eqpt::ChannelGroupId> /</code> <code><Eqpt::SubChannelGroupId> / <Ng2::OntId> / vuni)</code> Possible values: - ng2 : ngpon2 vlan bridge port Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number Field type <Eqpt::VpId> - atm VPI Field type <Eqpt::VcId> - atm VCI Field type <Eqpt::PonId> - the PON identifier Field type <Eqpt::ChannelGroupId> - the channel group identifier Field type <Eqpt::SubChannelGroupId> - the subchannel group identifier Field type <Eqpt::OntId> - the ONT identifier Field type <Ng2::OntId> - the ONT identifier Possible values: - voip : virtual uni identifier obsolete alternative replaced by vuni - vuni : virtual uni identifier Possible values: - vuni : virtual NGPON2 uni identifier Field type <Eqpt::OntSlotId> - the ONT SLOT identifier Field type <Eqpt::OntPortId> - the ONT PORT identifier Field type <Eqpt::Ng2OntSlotId> - the NGPON2 ONT SLOT identifier Field type <Eqpt::Ng2OntPortId> - the NGPON2 ONT PORT identifier Field type <Eqpt::LLId> - the LLID identifier, range 1 for EPON, range 1-8 for DPOE	

Resource Identifier	Type	Description
interval-number	Parameter type: <Vlan::IntervalNumber> Format: - [1...32] for gpon,[1...96] for others - range: [1...96]	interval number

Command Output

Table 106.24-2 "VLAN Port Statistics for Previous Quarter Intervals Status Command" Display parameters

Specific Information		
name	Type	Description
measure-time	Parameter type: <Vlan::StatsTime> - time - unit: sec	actually measured time in this interval; expressed in seconds <i>This element is always shown.</i>

Only Show Details: up stream counters		
name	Type	Description
forward-frame	Parameter type: <Vlan::OctetCounter> - vlan counter	number of frames forwarded in upstream direction per VLAN on a bridge port, for the specified interval <i>This element is only shown in detail mode.</i>
forward-byte	Parameter type: <Vlan::OctetCounter> - vlan counter	number of bytes forwarded in upstream direction per VLAN on a bridge port, for the specified interval <i>This element is only shown in detail mode.</i>
discard-frame	Parameter type: <Vlan::OctetCounter> - vlan counter	number of discarded frames in upstream direction per VLAN on a bridge port, for the specified interval <i>This element is only shown in detail mode.</i>
discard-byte	Parameter type: <Vlan::OctetCounter> - vlan counter	number of discarded bytes in upstream direction per VLAN on a bridge port, for the specified interval <i>This element is only shown in detail mode.</i>

Only Show Details: down stream counters		
name	Type	Description
forward-frame	Parameter type: <Vlan::OctetCounter> - vlan counter	number of frames forwarded in downstream direction per VLAN on a bridge port, for the specified interval <i>This element is only shown in detail mode.</i>
forward-byte	Parameter type: <Vlan::OctetCounter> - vlan counter	number of bytes forwarded in downstream direction per VLAN on a bridge port, for the specified interval <i>This element is only shown in detail mode.</i>

106 VLAN Status Commands

name	Type	Description
discard-frame	Parameter type: <Vlan::OctetCounter> - vlan counter	number of discarded frames in downstream direction per VLAN on a bridge port, for the specified interval <i>This element is only shown in detail mode.</i>
discard-byte	Parameter type: <Vlan::OctetCounter> - vlan counter	number of discarded bytes in downstream direction per VLAN on a bridge port, for the specified interval <i>This element is only shown in detail mode.</i>

106.25 VLAN Port Statistics for Previous Day Intervals Status Command

Command Description

This command displays performance statistics for the previous day intervals for a particular VLAN and port. Counters for upstream and downstream traffic are displayed. These counters include all traffic on the port, including PPPoE relayed and PPPoE terminated traffic.

The interval is specified. Interval number 1 identifies the most recent completed day interval. From there onward, interval numbers are incremented by 1. Higher interval numbers relate to less recent intervals.

Counters for discarded frames are displayed. Frames are discarded as a result of buffer acceptance control or policing.

User Level

The command can be accessed by operators with vlan privileges.

Command Syntax

The command has the following syntax:

```
> show vlan vlan-day-stats [ (vlanid) [ port <Vlan::BridgePort> ] [ interval-number <Vlan::DayIntervalNumber> ] ]
```

Command Parameters

Table 106.25-1 "VLAN Port Statistics for Previous Day Intervals Status Command" Resource Parameters

Resource Identifier	Type	Description
(vlanid)	Format: (<Vlan::UVlanIndex> stacked : <Vlan::SVlanIndex> : <Vlan::CVlanIndex>) Possible values: - stacked : stacked vlan identity Field type <Vlan::UVlanIndex> - unstacked vlan identity - range: [1...4093,4096] Field type <Vlan::SVlanIndex> - service vlan identity - range: [2...4093] Field type <Vlan::CVlanIndex> - customer vlan identity - range: [0...4093]	vlan id
port	Parameter type: <Vlan::BridgePort> Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::VpiId> : <Eqpt::VciId>	identity of a port(e.g. atm PVC, EFM port, ...)

Resource Identifier	Type	Description
	<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> / <Eqpt::OntPortId> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / voip <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / vuni <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::LLId> ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Ng2::OntId> / <Eqpt::Ng2OntSlotId> / <Eqpt::Ng2OntPortId> ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Ng2::OntId> / vuni) Possible values: - ng2 : ngpon2 vlan bridge port Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number Field type <Eqpt::VpiId> - atm VPI Field type <Eqpt::VciId> - atm VCI Field type <Eqpt::PonId> - the PON identifier Field type <Eqpt::ChannelGroupId> - the channel group identifier Field type <Eqpt::SubChannelGroupId> - the subchannel group identifier Field type <Eqpt::OntId> - the ONT identifier Field type <Ng2::OntId> - the ONT identifier Possible values: - voip : virtual uni identifier obsolete alternative replaced by vuni - vuni : virtual uni identifier Possible values: - vuni : virtual NGPON2 uni identifier Field type <Eqpt::OntSlotId> - the ONT SLOT identifier Field type <Eqpt::OntPortId> - the ONT PORT identifier Field type <Eqpt::Ng2OntSlotId> - the NGPON2 ONT SLOT identifier Field type <Eqpt::Ng2OntPortId> - the NGPON2 ONT PORT identifier Field type <Eqpt::LLId> - the LLID identifier, range 1 for EPON, range 1-8 for DPOE	
interval-number	Parameter type: <Vlan::DayIntervalNumber>	interval number

Resource Identifier	Type	Description
	Format: - IntervalNumber for one day pm - range: [1]	

Command Output

Table 106.25-2 "VLAN Port Statistics for Previous Day Intervals Status Command" Display parameters

Specific Information		
name	Type	Description
measure-time	Parameter type: <Vlan::StatsTime> - time - unit: sec	actually measured time in this interval; expressed in seconds <i>This element is always shown.</i>

Only Show Details: up stream counters		
name	Type	Description
forward-frame	Parameter type: <Vlan::OctetCounter> - vlan counter	number of frames forwarded in upstream direction per VLAN on a bridge port, for the specified interval <i>This element is only shown in detail mode.</i>
forward-byte	Parameter type: <Vlan::OctetCounter> - vlan counter	number of bytes forwarded in upstream direction per VLAN on a bridge port, for the specified interval <i>This element is only shown in detail mode.</i>
discard-frame	Parameter type: <Vlan::OctetCounter> - vlan counter	number of discarded frames in upstream direction per VLAN on a bridge port, for the specified interval <i>This element is only shown in detail mode.</i>
discard-byte	Parameter type: <Vlan::OctetCounter> - vlan counter	number of discarded bytes in upstream direction per VLAN on a bridge port, for the specified interval <i>This element is only shown in detail mode.</i>

Only Show Details: down stream counters		
name	Type	Description
forward-frame	Parameter type: <Vlan::OctetCounter> - vlan counter	number of frames forwarded in downstream direction per VLAN on a bridge port, for the specified interval <i>This element is only shown in detail mode.</i>
forward-byte	Parameter type: <Vlan::OctetCounter> - vlan counter	number of bytes forwarded in downstream direction per VLAN on a bridge port, for the specified interval <i>This element is only shown in detail mode.</i>
discard-frame	Parameter type: <Vlan::OctetCounter>	number of discarded frames in

106 VLAN Status Commands

name	Type	Description
	- vlan counter	downstream direction per VLAN on a bridge port, for the specified interval <i>This element is only shown in detail mode.</i>
discard-byte	Parameter type: <Vlan::OctetCounter> - vlan counter	number of discarded bytes in downstream direction per VLAN on a bridge port, for the specified interval <i>This element is only shown in detail mode.</i>

106.26 VLAN Filtering Database Status Command

Command Description

Obsolete command, replaced by `show vlan bridge-port-fdb`.

This command displays the contents of the virtual MAC table. The display can be filtered by Vlan, bridge port, and/or subscriber MAC address.

User Level

The command can be accessed by operators with vlan privileges.

Command Syntax

The command has the following syntax:

```
> show vlan vmac-bridge-port-fdb [ (port) [ vlan-id <Vlan::StackedVlan> ] [ mac <Vlan::MacAddr> ] ]
```

Obsolete command, replaced by `show vlan bridge-port-fdb`.

Command Parameters

Table 106.26-1 "VLAN Filtering Database Status Command" Resource Parameters

Resource Identifier	Type	Description
(port)	Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::VpId> : <Eqpt::VcId> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> / <Eqpt::OntPortId> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / voip <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / vuni <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::LLId> ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / <Eqpt::Ng2OntSlotId> / <Eqpt::Ng2OntPortId> ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / vuni) Possible values: - ng2 : ngpon2 style identification Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number	identity of the PVC

Resource Identifier	Type	Description
	Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number Field type <Eqpt::VpiId> - atm VPI Field type <Eqpt::VciId> - atm VCI Field type <Eqpt::ChannelGroupId> - the channel group identifier Field type <Eqpt::SubChannelGroupId> - the subchannel group identifier Field type <Eqpt::PonId> - the PON identifier Field type <Eqpt::OntId> - the ONT identifier Field type <Eqpt::Ng2OntId> - the NG2 ONT identifier Possible values: - voip : virtual uni identifier obsolete alternative replaced by vuni - vuni : virtual uni identifier Possible values: - vuni : virtual NGPON2 uni identifier Field type <Eqpt::OntSlotId> - the ONT SLOT identifier Field type <Eqpt::OntPortId> - the ONT PORT identifier Field type <Eqpt::Ng2OntSlotId> - the NGPON2 ONT SLOT identifier Field type <Eqpt::Ng2OntPortId> - the NGPON2 ONT PORT identifier Field type <Eqpt::LLId> - the LLID identifier, range 1 for EPON, range 1-8 for DPOE	
vlan-id	Parameter type: <Vlan::StackedVlan> Format: (<Vlan::UVlanIndex> stacked : <Vlan::SVlanIndex> : <Vlan::CVlanIndex>) Possible values: - stacked : stacked vlan identity Field type <Vlan::UVlanIndex> - unstacked vlan identity - range: [1...4093,4096] Field type <Vlan::SVlanIndex> - service vlan identity - range: [2...4093] Field type <Vlan::CVlanIndex> - customer vlan identity - range: [0...4093]	subscriber vlan id
mac	Parameter type: <Vlan::MacAddr> Format: - mac address (aa:bb:cc:a1:02:03) - unit: Byte - length: 6	mac address

Command Output

Table 106.26-2 "VLAN Filtering Database Status Command" Display parameters

Specific Information		
name	Type	Description
fdb-id	Parameter type: <Vlan::StackedVlan> (<Vlan::UVlanIndex> stacked : <Vlan::SVlanIndex> : <Vlan::CVlanIndex>) Possible values: - stacked : stacked vlan identity Field type <Vlan::UVlanIndex> - unstacked vlan identity - range: [1...4093,4096] Field type <Vlan::SVlanIndex> - service vlan identity - range: [2...4093,4094] Field type <Vlan::CVlanIndex> - customer vlan identity - range: [0...4093,4094,4095,4096]	the identity of this filtering database <i>This element is always shown.</i>
status	Parameter type: <Vlan::FdbEntryStatus> (other invalid learned self static) Possible values: - other : entry does not determine the forwarding of frames - invalid : entry is being removed - learned : entry has been learned dynamically - self : entry represents one of the device's addresses - static : entry has been configured by a manager	the origin of the entry, unless invalid <i>This element is always shown.</i>
vmac	Parameter type: <Vlan::FilterVMacAddr> - mac address (aa:bb:cc:a1:02:03) - length: 6	unicast virtual mac address <i>This element is always shown.</i>

106.27 P-bit Traffic Counters Status Command

Command Description

This command allows the operator to show the p-bit traffic counters.

User Level

The command can be accessed by operators with vlan privileges.

Command Syntax

The command has the following syntax:

```
> show vlan pbit-statistics port [ (vlan-port) [ min-dot1p <Vlan::Dot1pMin> ] [ max-dot1p <Vlan::Dot1pMax> ] ]
```

Command Parameters

Table 106.27-1 "P-bit Traffic Counters Status Command" Resource Parameters

Resource Identifier	Type	Description
(vlan-port)	Format: (vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::VpiId> : <Eqpt::VciId> : <Eqpt::UnstackedVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::UnstackedVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::VpiId> : <Eqpt::VciId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> / <Eqpt::OntPortId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> / <Eqpt::OntPortId> : <Eqpt::UnstackedVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / voip : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / vuni : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / voip : <Eqpt::UnstackedVlan>	vlan port

Resource Identifier	Type	Description
	vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / vuni : <Eqpt::UnstackedVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::LLId> : <Eqpt::UnstackedVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::LLId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan-port:ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Ng2::OntId> / <Eqpt::Ng2OntSlotId> / <Eqpt::Ng2OntPortId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan-port:ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Ng2::OntId> / <Eqpt::Ng2OntSlotId> / <Eqpt::Ng2OntPortId> : <Eqpt::UnstackedVlan> vlan-port:ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Ng2::OntId> / vuni : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan-port:ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Ng2::OntId> / vuni : <Eqpt::UnstackedVlan>) Possible values: - vlan-port : vlan port - vlan-port:ng2 : ngpon2 vlan port Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number Field type <Eqpt::VpiId> - atm VPI Field type <Eqpt::VcId> - atm VCI Field type <Eqpt::PonId> - the PON identifier Field type <Eqpt::OntId> - the ONT identifier Field type <Eqpt::ChannelGroupId> - the channel group identifier Field type <Eqpt::SubChannelGroupId> - the subchannel group identifier Field type <Ng2::OntId> - the ONT identifier Possible values: - voip : virtual uni identifier obsolete alternative replaced by vuni - vuni : virtual uni identifier Possible values: - vuni : virtual NGPON2 uni identifier Field type <Eqpt::OntSlotId> - the ONT SLOT identifier Field type <Eqpt::OntPortId>	

Resource Identifier	Type	Description
	- the ONT PORT identifier Field type <Eqpt::Ng2OntSlotId> - the NGPON2 ONT SLOT identifier Field type <Eqpt::Ng2OntPortId> - the NGPON2 ONT PORT identifier Field type <Eqpt::LLId> - the LLID identifier,range 1 for EPON,range 1-8 for DPOE Possible values: - stacked : stacked vlan identity Field type <Eqpt::UnstackedVlan> - unstacked vlan id Field type <Eqpt::SVlan> - service vlan id Field type <Eqpt::CVlan> - customer vlan id	
min-dot1p	Parameter type: <Vlan::Dot1pMin> Format: - dot1p value range - range: [0...7]	the min pbit value
max-dot1p	Parameter type: <Vlan::Dot1pMax> Format: - dot1p value range - range: [0...7]	the max pbit value

Command Output

Table 106.27-2 "P-bit Traffic Counters Status Command" Display parameters

Specific Information		
name	Type	Description
up-forward-byte	Parameter type: <Vlan::Dot1pTraffCounter> - 64 bit counter,range:[0-9223372036854775808]	all forwarded bytes in upstream directions on a vlan port for the given P-bit range. <i>This element is always shown.</i>
dn-forward-byte	Parameter type: <Vlan::Dot1pTraffCounter> - 64 bit counter,range:[0-9223372036854775808]	all forwarded bytes in downstream directions on a vlan port for the given P-bit range. <i>This element is always shown.</i>

106.28 Current VLAN Filtering Database Status Command

Command Description

This command displays filtering database used by this VLAN.

User Level

The command can be accessed by operators with vlan privileges.

Command Syntax

The command has the following syntax:

```
> show vlan fdbid [ (vlan-id) ]
```

Command Parameters

Table 106.28-1 "Current VLAN Filtering Database Status Command" Resource Parameters

Resource Identifier	Type	Description
(vlan-id)	Format: (<Vlan::UVlanIndex> stacked : <Vlan::SVlanIndex> : <Vlan::CVlanIndex>) Possible values: - stacked : stacked vlan identity Field type <Vlan::UVlanIndex> - unstacked vlan identity - range: [1...4093,4096] Field type <Vlan::SVlanIndex> - service vlan identity - range: [2...4093] Field type <Vlan::CVlanIndex> - customer vlan identity - range: [0...4093]	network vlan id

Command Output

Table 106.28-2 "Current VLAN Filtering Database Status Command" Display parameters

Specific Information		
name	Type	Description
fdb-id	Parameter type: <Vlan::StackedVlan> (<Vlan::UVlanIndex> stacked : <Vlan::SVlanIndex> : <Vlan::CVlanIndex>) Possible values:	identity of the filtering database <i>This element is always shown.</i>

106 VLAN Status Commands

name	Type	Description
	- stacked : stacked vlan identity Field type <Vlan::UVlanIndex> - unstacked vlan identity - range: [1...4093,4096] Field type <Vlan::SVlanIndex> - service vlan identity - range: [2...4093,4094] Field type <Vlan::CVlanIndex> - customer vlan identity - range: [0...4093,4094,4095,4096]	

106.29 Accumulated Port Statistics

Command Description

This command displays performance statistics for a particular port. Counters for upstream and downstream traffic are displayed. These counters do not include broadcast/multicast frames per bridge port in downstream direction.

User Level

The command can be accessed by operators with vlan privileges.

Command Syntax

The command has the following syntax:

```
> show vlan port-accumu-stats [ (port) ]
```

Command Parameters

Table 106.29-1 "Accumulated Port Statistics" Resource Parameters

Resource Identifier	Type	Description
(port)	Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::VpiId> : <Eqpt::VciId> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> / <Eqpt::OntPortId> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / voip <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / vuni <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::LLId> ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Ng2::OntId> / <Eqpt::Ng2OntSlotId> / <Eqpt::Ng2OntPortId> ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Ng2::OntId> / vuni) Possible values: - ng2 : ngpon2 vlan bridge port Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId>	identity of a port(e.g. atm PVC, EFM port, ...)

Resource Identifier	Type	Description
	- the port number - Field type <Eqpt::VpiId> - atm VPI - Field type <Eqpt::VciId> - atm VCI - Field type <Eqpt::PonId> - the PON identifier - Field type <Eqpt::ChannelGroupId> - the channel group identifier - Field type <Eqpt::SubChannelGroupId> - the subchannel group identifier - Field type <Eqpt::OntId> - the ONT identifier - Field type <Ng2::OntId> - the ONT identifier - Possible values: - voip : virtual uni identifier - obsolete alternative replaced by vuni - vuni : virtual uni identifier - Possible values: - vuni : virtual NGPON2 uni identifier - Field type <Eqpt::OntSlotId> - the ONT SLOT identifier - Field type <Eqpt::OntPortId> - the ONT PORT identifier - Field type <Eqpt::Ng2OntSlotId> - the NGPON2 ONT SLOT identifier - Field type <Eqpt::Ng2OntPortId> - the NGPON2 ONT PORT identifier - Field type <Eqpt::LLId> - the LLID identifier, range 1 for EPON, range 1-8 for DPOE	

Command Output

Table 106.29-2 "Accumulated Port Statistics" Display parameters

Specific Information		
name	Type	Description
up-fwd-frame	Parameter type: <Vlan::OctetCounter> - vlan counter	number of frames forwarded in upstream direction on a bridge port, for the specified interval <i>This element is always shown.</i>
up-fwd-byte	Parameter type: <Vlan::OctetCounter> - vlan counter	number of bytes forwarded in upstream direction on a bridge port, for the specified interval <i>This element is always shown.</i>
up-dis-frame	Parameter type: <Vlan::OctetCounter> - vlan counter	number of discarded frames in upstream direction on a bridge port, for the specified interval <i>This element is always shown.</i>
up-dis-byte	Parameter type: <Vlan::OctetCounter> - vlan counter	number of discarded bytes in upstream direction on a bridge port, for the specified interval <i>This element is always shown.</i>
dn-fwd-frame	Parameter type: <Vlan::OctetCounter> - vlan counter	number of frames forwarded in downstream direction on a bridge port, for the specified interval

name	Type	Description
		<i>This element is always shown.</i>
dn-fwd-byte	Parameter type: <Vlan::OctetCounter> - vlan counter	number of bytes forwarded in downstream direction on a bridge port, for the specified interval <i>This element is always shown.</i>
dn-dis-frame	Parameter type: <Vlan::OctetCounter> - vlan counter	number of discarded frames in downstream direction on a bridge port, for the specified interval <i>This element is always shown.</i>
dn-dis-byte	Parameter type: <Vlan::OctetCounter> - vlan counter	number of discarded bytes in downstream direction on a bridge port, for the specified interval <i>This element is always shown.</i>

107- QOS Status Commands

107.1 QOS Status Command Tree	107-5326
107.2 QoS Session Profile Status Command	107-5328
107.3 QoS Marker Profile Status Command	107-5329
107.4 QoS Policer Profile Status Command	107-5330
107.5 QoS Queue Profile Status Command	107-5331
107.6 QoS Scheduler Node Profile Status Command	107-5332
107.7 QoS CAC Profile Status Command	107-5333
107.8 QoS Policy Profile Status Command	107-5334
107.9 QoS L2 Filter Profile Status Command	107-5335
107.10 QoS L3 Filter Profile Status Command	107-5336
107.11 QoS Policy Action Profile Status Command	107-5337
107.12 QoS IngressQoS Profile Status Command	107-5338
107.13 QoS Shaper Profile Status Command	107-5339
107.14 QoS Bandwidth Profile Status Command	107-5340
107.15 QoS Rate Limit Profile Status Command	107-5341
107.16 QoS DSCP to PBIT Profile Status Command	107-5342
107.17 QoS Policer Per Tc Profile Status Command	107-5343
107.18 QoS Policer Threshold Profile Status Command	107-5344
107.19 QoS aggrQueuesConfig Profile Status Command	107-5345
107.20 QoS Ingress filter Resource Usage Status Command	107-5346
107.21 QoS DSL Bandwidth Status Command	107-5348
107.22 QoS Shdsl Bandwidth Status Command	107-5350
107.23 QoS Ethernet Bandwidth Status Command	107-5352
107.24 QoS Interface Bandwidth Status Command	107-5354
107.25 QoS Total Buffer Overflow Statistics for Previous Quarter	107-5359
107.26 QoS Total Buffer Overflow Statistics for Current Quarter	107-5362
107.27 QoS Total Buffer Overflow Statistics for Previous Day Command	107-5365
107.28 QoS Total Buffer Overflow Statistics for Current Day	107-5368
107.29 QoS Total Buffer Overflow Statistics Total Status Command	107-5371
107.30 QoS Interface Buffer Overflow Statistics for Previous Quarter	107-5375
107.31 QoS Interface Buffer Overflow Statistics for Current Quarter	107-5379
107.32 QoS Fan Out Statistics for Previous Quarter	107-5383
107.33 QoS Fan Out Statistics for Current 15 minutes	107-5385
107.34 QoS Fan Out Statistics for Previous Day	107-5387
107.35 QoS Fan Out Statistics for Current Day	107-5389
107.36 QoS LT Queue Overflow Statistics for Previous Quarter	107-5391
107.37 QoS LT Queue Overflow Statistics for current Quarter	107-5393
107.38 QoS Interface Color Queue Statistics for Previous 15 minutes Quarter	107-5395
107.39 QoS Interface Color Queue Statistics for Current 15	107-5400

minutes Quarter

107.40 QoS TC2QMapping Status Command

107-5404

107.41 QoS Bandwidth Profile Actuals Command

107-5406

107.1 QOS Status Command Tree

Description

This chapter gives an overview of nodes that are handled by "QOS Status Commands".

Command Tree

```
----show
  ----qos
    ----profile-usage
      ----session
        - (name)
      ----marker
        - (name)
      ----policer
        - (name)
      ----queue
        - (name)
      ----scheduler-node
        - (name)
      ----cac
        - (name)
      ----policy
        - (name)
      ----l2-filter
        - (name)
      ----l3-filter
        - (name)
      ----policy-action
        - (name)
      ----ingress-qos
        - (name)
      ----shaper
        - (name)
      ----bandwidth
        - (name)
      ----rate-limit
        - (name)
      ----dscp-pbit
        - (name)
      ----policer-per-tc
        - (name)
      ----cos-threshold
        - (name)
      ----aggrqueuesconfig
        - (name)
    ----resource-usage
      ----ingress-hw-filter
        - (equip-slot)
  ----X dsl-bandwidth
    - (index)
  ----X shdsl-bandwidth
    - (index)
```



```

----X ethernet-bandwidth
  - (index)
----interface-bandwidth
  - (index)
----statistics
  ----buffer-overflow
    ----prev-15min
      - (equip-slot)
      - interval-num
    ----current-15min
      - (equip-slot)
    ----prev-1day
      - (equip-slot)
    ----current-1day
      - (equip-slot)
    ----total
      - (equip-slot)
  ----queue
    ----prev-15min
      - (index)
      - queue
      - interval-num
    ----current-15min
      - (index)
      - queue
  ----lt-cos
    ----prev-15min
      - (equip-slot)
      - traffic-class
      - interval-num
    ----current-15min
      - (equip-slot)
      - traffic-class
    ----prev-1day
      - (equip-slot)
      - interval-num
    ----current-1day
      - (equip-slot)
  ----lt-queue
    ----prev-15min
      - (index)
    ----current-15min
      - (index)
  ----color-queue
    ----prev-15min
      - (index)
      - queue
      - interval-num
    ----current-15min
      - (index)
      - queue
  ----tc-to-qmap
    - (name)
  ----bandwidth-profile
    - (name)
    - pon-type

```

107.2 QoS Session Profile Status Command

Command Description

This command displays the QoS session profile status. A QoS profile that is in use cannot be deleted, so the operator can use this command to display the usage of QoS session profiles. The QoS session profile usage represents the total user sessions (both for statically configured and dynamic sessions).

User Level

The command can be accessed by operators with qos privileges.

Command Syntax

The command has the following syntax:

```
> show qos profile-usage session [ (name) ]
```

Command Parameters

Table 107.2-1 "QoS Session Profile Status Command" Resource Parameters

Resource Identifier	Type	Description
(name)	Format: Data driven field type Possible values are depending on the actual configuration and software. The currently allowed values can be shown with online-help.	A session profile name

Command Output

Table 107.2-2 "QoS Session Profile Status Command" Display parameters

Specific Information		
name	Type	Description
ref-count	Parameter type: <AsamProfileRefCount32> - number of entities using this particular profile - range: [0...4294967295]	Indicates the number of entities using this profile. If the reference count is greater than 0, then this profile is 'in use', and may NOT be deleted. If the value is 0, then this profile is 'not in use', and can be deleted. <i>This element is always shown.</i>

107.3 QoS Marker Profile Status Command

Command Description

This command displays the QoS marker profile status. A QoS profile that is in use cannot be deleted, so the operator can use this command to display the usage of QoS marker profiles. The QoS marker profile usage shows the references from existing QoS session profiles because these profiles are not applied on their own.

User Level

The command can be accessed by operators with qos privileges.

Command Syntax

The command has the following syntax:

```
> show qos profile-usage marker [ (name) ]
```

Command Parameters

Table 107.3-1 "QoS Marker Profile Status Command" Resource Parameters

Resource Identifier	Type	Description
(name)	Format: Data driven field type Possible values are depending on the actual configuration and software. The currently allowed values can be shown with online-help.	A marker profile name

Command Output

Table 107.3-2 "QoS Marker Profile Status Command" Display parameters

Specific Information		
name	Type	Description
ref-count	Parameter type: <AsamProfileRefCount32> - number of entities using this particular profile - range: [0...4294967295]	Indicates the number of entities using this profile. If the reference count is greater than 0, then this profile 'is in use', and may NOT be deleted. If the value is 0, then this profile is 'not in use', and can be deleted. <i>This element is always shown.</i>

107.4 QoS Policer Profile Status Command

Command Description

This command displays the QoS policer profile status. A QoS profile that is in use cannot be deleted, so the operator can use this command to display the usage of QoS policer profiles. The QoS policer profile usage shows the references from existing QoS session profiles because these profiles are not applied on their own.

User Level

The command can be accessed by operators with qos privileges.

Command Syntax

The command has the following syntax:

```
> show qos profile-usage policer [ (name) ]
```

Command Parameters

Table 107.4-1 "QoS Policer Profile Status Command" Resource Parameters

Resource Identifier	Type	Description
(name)	Format: Data driven field type Possible values are depending on the actual configuration and software. The currently allowed values can be shown with online-help.	A policer profile name

Command Output

Table 107.4-2 "QoS Policer Profile Status Command" Display parameters

Specific Information		
name	Type	Description
ref-count	Parameter type: <AsamProfileRefCount32> - number of entities using this particular profile - range: [0...4294967295]	Indicates the number of entities using this profile. If the reference count is greater than 0, then this profile is 'in use', and may NOT be deleted. If the value is 0, then this profile is 'not in use', and can be deleted. <i>This element is always shown.</i>

107.5 QoS Queue Profile Status Command

Command Description

This command displays the QoS queue profile status. A QoS profile that is in use cannot be deleted, so the operator can use this command to display the usage of QoS queue profiles. The QoS queue profile usage shows the references from existing QoS session profiles because these profiles are not applied on their own.

User Level

The command can be accessed by operators with qos privileges.

Command Syntax

The command has the following syntax:

```
> show qos profile-usage queue [ (name) ]
```

Command Parameters

Table 107.5-1 "QoS Queue Profile Status Command" Resource Parameters

Resource Identifier	Type	Description
(name)	Format: Data driven field type Possible values are depending on the actual configuration and software. The currently allowed values can be shown with online-help.	A queue profile name

Command Output

Table 107.5-2 "QoS Queue Profile Status Command" Display parameters

Specific Information		
name	Type	Description
ref-count	Parameter type: <AsamProfileRefCount32> - number of entities using this particular profile - range: [0...4294967295]	indicates the number of entities using this profile. If the reference count is not 0, then this profile is 'in use', and can not be deleted. If the value is 0, then this profile is 'not in use', and can be deleted. <i>This element is always shown.</i>

107.6 QoS Scheduler Node Profile Status Command

Command Description

This command displays the QoS scheduler-node profile status. A QoS profile that is in use cannot be deleted, so the operator can use this command to display the usage of QoS scheduler-node profiles. The QoS scheduler-node profile usage shows the references from existing QoS session profiles because these profiles are not applied on their own.

User Level

The command can be accessed by operators with qos privileges.

Command Syntax

The command has the following syntax:

```
> show qos profile-usage scheduler-node [ (name) ]
```

Command Parameters

Table 107.6-1 "QoS Scheduler Node Profile Status Command" Resource Parameters

Resource Identifier	Type	Description
(name)	Format: Data driven field type Possible values are depending on the actual configuration and software. The currently allowed values can be shown with online-help.	A scheduler-node profile name

Command Output

Table 107.6-2 "QoS Scheduler Node Profile Status Command" Display parameters

Specific Information		
name	Type	Description
ref-count	Parameter type: <AsamProfileRefCount32> - number of entities using this particular profile - range: [0...4294967295]	Indicates the number of entities using this profile. If the reference count is greater than 0, then this profile is 'in use', and may NOT be deleted. If the value is 0, then this profile is 'not in use', and can be deleted. <i>This element is always shown.</i>

107.7 QoS CAC Profile Status Command

Command Description

This command displays the QoS CAC profile status. A QoS profile that is in use cannot be deleted, so the operator can use this command to display the usage of QoS CAC profiles. The QoS CAC profile usage displays the references from existing QoS session profiles because these profiles are not applied on their own.

User Level

The command can be accessed by operators with qos privileges.

Command Syntax

The command has the following syntax:

```
> show qos profile-usage cac [ (name) ]
```

Command Parameters

Table 107.7-1 "QoS CAC Profile Status Command" Resource Parameters

Resource Identifier	Type	Description
(name)	Format: Data driven field type Possible values are depending on the actual configuration and software. The currently allowed values can be shown with online-help.	A unique profile name

Command Output

Table 107.7-2 "QoS CAC Profile Status Command" Display parameters

Specific Information		
name	Type	Description
ref-count	Parameter type: <AsamProfileRefCount> - number of entities using this particular profile - range: [0...65535]	indicates the number of entities using this profile. If the reference count is greater than 0, then this profile is 'in use', and may NOT be deleted. If the value is 0, then this profile is 'not in use', and can be deleted. <i>This element is always shown.</i>

107.8 QoS Policy Profile Status Command

Command Description

This command displays the QoS policy profile status. A QoS profile in use cannot be deleted. Use this command to display the usage of QoS policy profiles. The QoS policy profile usage shows the references from existing QoS session profiles because these profiles are not applied on their own.

User Level

The command can be accessed by operators with qos privileges.

Command Syntax

The command has the following syntax:

```
> show qos profile-usage policy [ (name) ]
```

Command Parameters

Table 107.8-1 "QoS Policy Profile Status Command" Resource Parameters

Resource Identifier	Type	Description
(name)	Format: Data driven field type Possible values are depending on the actual configuration and software. The currently allowed values can be shown with online-help.	A unique policy profile name

Command Output

Table 107.8-2 "QoS Policy Profile Status Command" Display parameters

Specific Information		
name	Type	Description
ref-count	Parameter type: <AsamProfileRefCount32> - number of entities using this particular profile - range: [0...4294967295]	indicates the number of entities using this profile. If the reference count is greater than 0, then this profile is 'in use', and may NOT be deleted. If the value is 0, then this profile is 'not in use', and can be deleted. <i>This element is always shown.</i>

107.9 QoS L2 Filter Profile Status Command

Command Description

This command displays the QoS L2 filter profile status. A QoS profile in use cannot be deleted. Use this command to display the usage of QoS L2 filter profiles. The QoS L2 filter profile usage shows the references from existing QoS session profiles because these profiles are not applied on their own.

User Level

The command can be accessed by operators with qos privileges.

Command Syntax

The command has the following syntax:

```
> show qos profile-usage l2-filter [ (name) ]
```

Command Parameters

Table 107.9-1 "QoS L2 Filter Profile Status Command" Resource Parameters

Resource Identifier	Type	Description
(name)	Format: Data driven field type Possible values are depending on the actual configuration and software. The currently allowed values can be shown with online-help.	A l2 filter name

Command Output

Table 107.9-2 "QoS L2 Filter Profile Status Command" Display parameters

Specific Information		
name	Type	Description
ref-count	Parameter type: <AsamProfileRefCount32> - number of entities using this particular profile - range: [0...4294967295]	indicates the number of entities using this profile. If the reference count is greater than 0, then this profile is 'in use', and may NOT be deleted. If the value is 0, then this profile is 'not in use', and can be deleted. <i>This element is always shown.</i>

107.10 QoS L3 Filter Profile Status Command

Command Description

This command displays the QoS L3 filter profile status. A QoS profile in use cannot be deleted. Use this command to display the usage of QoS L3 Filter profiles. The QoS L3 filter profile usage shows the references from existing QoS session profiles because these profiles are not applied on their own.

User Level

The command can be accessed by operators with qos privileges.

Command Syntax

The command has the following syntax:

```
> show qos profile-usage l3-filter [ (name) ]
```

Command Parameters

Table 107.10-1 "QoS L3 Filter Profile Status Command" Resource Parameters

Resource Identifier	Type	Description
(name)	Format: Data driven field type Possible values are depending on the actual configuration and software. The currently allowed values can be shown with online-help.	A l3 filter name

Command Output

Table 107.10-2 "QoS L3 Filter Profile Status Command" Display parameters

Specific Information		
name	Type	Description
ref-count	Parameter type: <AsamProfileRefCount32> - number of entities using this particular profile - range: [0...4294967295]	indicates the number of entities using this profile. If the reference count is greater than 0, then this profile is 'in use', and may NOT be deleted. If the value is 0, then this profile is 'not in use', and can be deleted. <i>This element is always shown.</i>

107.11 QoS Policy Action Profile Status Command

Command Description

This command displays the QoS policy action profile status. A QoS profile in use cannot be deleted. Use this command to display the usage of policy action profiles. The QoS policy action profile usage shows the references from existing QoS session profiles because these profiles are not applied on their own.

User Level

The command can be accessed by operators with qos privileges.

Command Syntax

The command has the following syntax:

```
> show qos profile-usage policy-action [ (name) ]
```

Command Parameters

Table 107.11-1 "QoS Policy Action Profile Status Command" Resource Parameters

Resource Identifier	Type	Description
(name)	Format: Data driven field type Possible values are depending on the actual configuration and software. The currently allowed values can be shown with online-help.	A policy action profile name

Command Output

Table 107.11-2 "QoS Policy Action Profile Status Command" Display parameters

Specific Information		
name	Type	Description
ref-count	Parameter type: <AsamProfileRefCount32> - number of entities using this particular profile - range: [0...4294967295]	indicates the number of entities using this profile. If the reference count is greater than 0, then this profile is 'in use', and may NOT be deleted. If the value is 0, then this profile is 'not in use', and can be deleted. <i>This element is always shown.</i>

107.12 QoS IngressQoS Profile Status Command

Command Description

This command displays the QoS Ingress profile status. A QoS profile that is in use cannot be deleted, so the operator can use this command to display the usage of QoS Ingress profiles. The QoS Ingress profile usage shows the references from existing QoS session profiles because these profiles are not applied on their own.

User Level

The command can be accessed by operators with qos privileges.

Command Syntax

The command has the following syntax:

```
> show qos profile-usage ingress-qos [ (name) ]
```

Command Parameters

Table 107.12-1 "QoS IngressQoS Profile Status Command" Resource Parameters

Resource Identifier	Type	Description
(name)	Format: Data driven field type Possible values are depending on the actual configuration and software. The currently allowed values can be shown with online-help.	An ingress profile name

Command Output

Table 107.12-2 "QoS IngressQoS Profile Status Command" Display parameters

Specific Information		
name	Type	Description
ref-count	Parameter type: <AsamProfileRefCount32> - number of entities using this particular profile - range: [0...4294967295]	Indicates the number of entities using this profile. If the reference count is greater than 0, then this profile is 'in use', and may NOT be deleted. If the value is 0, then this profile is 'not in use', and can be deleted. <i>This element is always shown.</i>

107.13 QoS Shaper Profile Status Command

Command Description

This command displays the QoS shaper profile status. A QoS profile that is in use cannot be deleted, so the operator can use this command to display the usage of QoS shaper profiles. The QoS shaper profile usage shows the reference from existing QoS shaper profiles because these profiles are not applied on their own.

User Level

The command can be accessed by operators with qos privileges.

Command Syntax

The command has the following syntax:

```
> show qos profile-usage shaper [ (name) ]
```

Command Parameters

Table 107.13-1 "QoS Shaper Profile Status Command" Resource Parameters

Resource Identifier	Type	Description
(name)	Format: Data driven field type Possible values are depending on the actual configuration and software. The currently allowed values can be shown with online-help.	A shaper profile name

Command Output

Table 107.13-2 "QoS Shaper Profile Status Command" Display parameters

Specific Information		
name	Type	Description
ref-count	Parameter type: <AsamProfileRefCount32> - number of entities using this particular profile - range: [0...4294967295]	Indicates the number of entities using this profile. If the reference count is greater than 0, then this profile is 'in use', and may NOT be deleted. If the value is 0, then this profile is 'not in use', and can be deleted. <i>This element is always shown.</i>

107.14 QoS Bandwidth Profile Status Command

Command Description

This command displays the QoS Bandwidth profile status. A QoS profile that is in use cannot be deleted, so the operator can use this command to display the usage of QoS scheduler-node profiles. The QoS Bandwidth profile usage shows the references from existing QoS session profiles because these profiles are not applied on their own.

User Level

The command can be accessed by operators with qos privileges.

Command Syntax

The command has the following syntax:

```
> show qos profile-usage bandwidth [ (name) ]
```

Command Parameters

Table 107.14-1 "QoS Bandwidth Profile Status Command" Resource Parameters

Resource Identifier	Type	Description
(name)	Format: Data driven field type Possible values are depending on the actual configuration and software. The currently allowed values can be shown with online-help.	A scheduler profile name

Command Output

Table 107.14-2 "QoS Bandwidth Profile Status Command" Display parameters

Specific Information		
name	Type	Description
ref-count	Parameter type: <AsamProfileRefCount32> - number of entities using this particular profile - range: [0...4294967295]	Indicates the number of entities using this profile. If the reference count is greater than 0, then this profile is 'in use', and may NOT be deleted. If the value is 0, then this profile is 'not in use', and can be deleted. <i>This element is always shown.</i>

107.15 QoS Rate Limit Profile Status Command

Command Description

This command displays the QoS Rate Limit profile status. A QoS profile that is in use cannot be deleted, so the operator can use this command to display the usage of QoS rate limit profiles. The QoS rate limit profile usage shows the reference from existing QoS rate limit profiles because these profiles are not applied on their own.

User Level

The command can be accessed by operators with qos privileges.

Command Syntax

The command has the following syntax:

```
> show qos profile-usage rate-limit [ (name) ]
```

Command Parameters

Table 107.15-1 "QoS Rate Limit Profile Status Command" Resource Parameters

Resource Identifier	Type	Description
(name)	Format: Data driven field type Possible values are depending on the actual configuration and software. The currently allowed values can be shown with online-help.	Protocol Rate Limit profile name

Command Output

Table 107.15-2 "QoS Rate Limit Profile Status Command" Display parameters

Specific Information		
name	Type	Description
ref-count	Parameter type: <AsamProfileRefCount32> - number of entities using this particular profile - range: [0...4294967295]	Indicates the number of entities using this profile. If the reference count is greater than 0, then this profile is 'in use', and may NOT be deleted. If the value is 0, then this profile is 'not in use', and can be deleted. <i>This element is always shown.</i>

107.16 QoS DSCP to PBIT Profile Status Command

Command Description

This command displays the QoS DSCP to PBIT profile status. A QoS profile that is in use cannot be deleted, so the operator can use this command to display the usage of QoS DSCP to PBIT profiles. The QoS DSCP to PBIT profile usage shows the references from existing QoS Marker profiles because these profiles are not applied on their own.

User Level

The command can be accessed by operators with qos privileges.

Command Syntax

The command has the following syntax:

```
> show qos profile-usage dscp-pbit [ (name) ]
```

Command Parameters

Table 107.16-1 "QoS DSCP to PBIT Profile Status Command" Resource Parameters

Resource Identifier	Type	Description
(name)	Format: Data driven field type Possible values are depending on the actual configuration and software. The currently allowed values can be shown with online-help.	A DSCP to PBIT profile name

Command Output

Table 107.16-2 "QoS DSCP to PBIT Profile Status Command" Display parameters

Specific Information		
name	Type	Description
ref-count	Parameter type: <AsamProfileRefCount32> - number of entities using this particular profile - range: [0...4294967295]	Indicates the number of entities using this profile. If the reference count is greater than 0, then this profile 'is in use', and may NOT be deleted. If the value is 0, then this profile is 'not in use', and can be deleted. <i>This element is always shown.</i>

107.17 QoS Policer Per Tc Profile Status Command

Command Description

This command displays the QoS Policer Per Tc profile status. A QoS profile that is in use cannot be deleted, so the operator can use this command to display the usage of QoS Policer Per Tc profiles. The QoS Policer Per Tc profile usage shows the references from existing QoS session profiles because these profiles are not applied on their own.

User Level

The command can be accessed by operators with qos privileges.

Command Syntax

The command has the following syntax:

```
> show qos profile-usage policer-per-tc [ (name) ]
```

Command Parameters

Table 107.17-1 "QoS Policer Per Tc Profile Status Command" Resource Parameters

Resource Identifier	Type	Description
(name)	Format: Data driven field type Possible values are depending on the actual configuration and software. The currently allowed values can be shown with online-help.	A policer per tc profile name

Command Output

Table 107.17-2 "QoS Policer Per Tc Profile Status Command" Display parameters

Specific Information		
name	Type	Description
ref-count	Parameter type: <AsamProfileRefCount32> - number of entities using this particular profile - range: [0...4294967295]	Indicates the number of entities using this profile. If the reference count is greater than 0, then this profile 'is in use', and may NOT be deleted. If the value is 0, then this profile is 'not in use', and can be deleted. <i>This element is always shown.</i>

107.18 QoS Policer Threshold Profile Status

Command

Command Description

This command displays the QoS policer threshold profile status. A QoS profile that is in use cannot be deleted, so the operator can use this command to display the usage of QoS policer threshold profiles. The QoS policer threshold profile usage shows the references from existing QoS policer profiles because these profiles are not applied on their own.

User Level

The command can be accessed by operators with qos privileges.

Command Syntax

The command has the following syntax:

```
> show qos profile-usage cos-threshold [ (name) ]
```

Command Parameters

Table 107.18-1 "QoS Policer Threshold Profile Status Command" Resource Parameters

Resource Identifier	Type	Description
(name)	Format: Data driven field type Possible values are depending on the actual configuration and software. The currently allowed values can be shown with online-help.	A cos threshold profile name

Command Output

Table 107.18-2 "QoS Policer Threshold Profile Status Command" Display parameters

Specific Information		
name	Type	Description
ref-count	Parameter type: <AsamProfileRefCount32> - number of entities using this particular profile - range: [0...4294967295]	Indicates the number of entities using this profile. If the reference count is greater than 0, then this profile is 'in use', and may NOT be deleted. If the value is 0, then this profile is 'not in use', and can be deleted. <i>This element is always shown.</i>

107.19 QoS aggrQueuesConfig Profile Status Command

Command Description

This command displays the QoS aggrQueuesConfig profile status. A QoS profile that is in use cannot be deleted, so the operator can use this command to display the usage of QoS aggrQueuesConfig profiles. The QoS aggrQueuesConfig profile usage shows the references of the profile.

User Level

The command can be accessed by operators with qos privileges.

Command Syntax

The command has the following syntax:

```
> show qos profile-usage aggrqueuesconfig [ (name) ]
```

Command Parameters

Table 107.19-1 "QoS aggrQueuesConfig Profile Status Command" Resource Parameters

Resource Identifier	Type	Description
(name)	Format: Data driven field type Possible values are depending on the actual configuration and software. The currently allowed values can be shown with online-help.	A aggrQueuesConfig profile name

Command Output

Table 107.19-2 "QoS aggrQueuesConfig Profile Status Command" Display parameters

Specific Information		
name	Type	Description
ref-count	Parameter type: <AsamProfileRefCount32> - number of entities using this particular profile - range: [0...4294967295]	indicates the number of entities using this profile. If the reference count is not 0, then this profile is 'in use', and can not be deleted. If the value is 0, then this profile is 'not in use', and can be deleted. <i>This element is always shown.</i>

107.20 QoS Ingress filter Resource Usage Status Command

Command Description

This command displays QoS resource usage information for line cards of type NELT-B: -the available and used ingress hardware filters. Qos ingress hardware filters are used for next QoS items: 1. The supported QoS Policies of a sessionprofile attached to a bridge/vlan port. 2. The supported Policers (SAP level) of a sessionprofile attached to a bridge/vlan port. 3. DSCP enforcement (SAP level) of a sessionprofile attached to a bridge/vlan port. - the number of ingress hardware filters which must be released, via adapting QoS configuration, to be able to apply ip antispoofing on ports of type HC-UNI. These values are only applicable for NELT_B boards. In particular, the command is to be used in case secure forwarding enablement or static ip address configuration fails on a NELT-B HC-UNI interface, due to insufficient resources.

User Level

The command can be accessed by operators with qos privileges.

Command Syntax

The command has the following syntax:

```
> show qos resource-usage ingress-hw-filter [ (equip-slot) ]
```

Command Parameters

Table 107.20-1 "QoS Ingress filter Resource Usage Status Command" Resource Parameters

Resource Identifier	Type	Description
(equip-slot)	Format: (lt : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::EqSlotId>) Possible values: - lt : lt-slot Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::EqSlotId> - the equipment slot number	physical position of the board

Command Output

Table 107.20-2 "QoS Ingress filter Resource Usage Status Command" Display parameters

Specific Information		
name	Type	Description
max-val	Parameter type: <UnsignedInteger> - an unsigned integer	The actual available Qos Ingress hardware filters. The displayed maximum value applies on each of the two port-groups of the NELT-B. <i>This element is always shown.</i>
cur-val-portgrp1	Parameter type: <UnsignedInteger> - an unsigned integer	The number of used Qos Ingress hardware filters on the first port-group of the concerned NELT-B. The first port-group consists out of lines 1-18. <i>This element is always shown.</i>
cur-val-portgrp2	Parameter type: <UnsignedInteger> - an unsigned integer	The number of used Qos Ingress hardware filters on the second port-group of the concerned NELT-B. The second port-group consists out of lines 19-36. <i>This element is always shown.</i>
excess-ipantispoof-pg1	Parameter type: <UnsignedInteger> - an unsigned integer	The number of Qos ingress hardware filters which must be released for interfaces 1 until 18, to be able to apply IpAntispoofing on ports of type Hicap-UNI. <i>This element is always shown.</i>
excess-ipantispoof-pg2	Parameter type: <UnsignedInteger> - an unsigned integer	The number of Qos ingress hardware filters which must be released for interfaces 19 until 36, to be able to apply IpAntispoofing on ports of type Hicap-UNI. <i>This element is always shown.</i>

107.21 QoS DSL Bandwidth Status Command

Command Description

Obsolete command, replaced by `show qos interface-bandwidth`.

This command displays the bandwidth allocation and usage for each DSL link.

User Level

The command can be accessed by operators with qos privileges.

Command Syntax

The command has the following syntax:

```
> show qos dsl-bandwidth [ (index) ]
```

Obsolete command, replaced by `show qos interface-bandwidth`.

Command Parameters

Table 107.21-1 "QoS DSL Bandwidth Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number	physical port of a dsl link

Command Output

Table 107.21-2 "QoS DSL Bandwidth Status Command" Display parameters

Specific Information		
name	Type	Description
frame-net-bw	Parameter type: <SignedInteger> - a signed integer	Represents an approximation of the bandwidth available for Ethernet frames. This approximation is made by using an appropriate overhead factor (ATM, EFM, ..). The basis for the calculus can be minimum

name	Type	Description
		sync rate or actual sync rate, or the native bandwidth for non-xDSL interfaces. <i>This element is always shown.</i>
res-data-bw	Parameter type: <SignedInteger> - a signed integer	The portion the frame-net-bw that is reserved for all data services (typically HSI user traffic). This is a reserved value per DSL interface (and not per user session) and applicable in the downstream direction only. <i>This element is only shown in detail mode.</i>
res-voice-bw	Parameter type: <SignedInteger> - a signed integer	The portion of the frame-net-bw that is reserved for all voice services (typically HSI user traffic). This is a reserved value per DSL interface (and not per voice call) and applicable in the downstream direction only. The usage of this value is to set apart a minimum rate such that video and voice services can never impact each other. <i>This element is only shown in detail mode.</i>
m-cast-max-bw	Parameter type: <SignedInteger> - a signed integer	Represents the rate limitation imposed by the operator upon the maximum bandwidth to be consumed by user multicast video sessions. This limit can enforce a smaller value than actually available on the DSL link. <i>This element is only shown in detail mode.</i>
m-cast-avail-bw	Parameter type: <SignedInteger> - a signed integer	Represents the bandwidth available for multicast services, calculated by the ISAM. This value is what is left from frame-net-bw after deducting from it res-data-bw and res-voice-bw. The minimum of m-cast-avail-bw and m-cast-max-bw will be the actual limitation for user multicast bandwidth usage per DSL link. <i>This element is always shown.</i>
m-cast-used-bw	Parameter type: <SignedInteger> - a signed integer	Shows the bandwidth currently in use by pre-configured multicast streams. <i>This element is always shown.</i>

107.22 QoS Shdsl Bandwidth Status Command

Command Description

Obsolete command, replaced by **show qos interface-bandwidth**.

This command displays the bandwidth allocation and usage for each Shdsl link.

User Level

The command can be accessed by operators with qos privileges.

Command Syntax

The command has the following syntax:

```
> show qos shdsl-bandwidth [ (index) ]
```

Obsolete command, replaced by **show qos interface-bandwidth**.

Command Parameters

Table 107.22-1 "QoS Shdsl Bandwidth Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number	physical port of a shdsl link

Command Output

Table 107.22-2 "QoS Shdsl Bandwidth Status Command" Display parameters

Specific Information		
name	Type	Description
frame-net-bw	Parameter type: <SignedInteger> - a signed integer	Represents the approximate bandwidth available for Ethernet frames, which is guaranteed to be available by the physical layer. This approximation is made by the configurable ATM overhead factor.

name	Type	Description
		<i>This element is always shown.</i>
res-data-bw	Parameter type: <SignedInteger> - a signed integer	The portion the frame-net-bw that is reserved for all data services (typically HSI user traffic). This is a reserved value per DSL interface (and not per user session) and applicable in the downstream direction only. <i>This element is only shown in detail mode.</i>
res-voice-bw	Parameter type: <SignedInteger> - a signed integer	The portion of the frame-net-bw that is reserved for all voice services (typically HSI user traffic). This is a reserved value per DSL interface (and not per voice call) and applicable in the downstream direction only. The usage of this value is to set apart a minimum rate such that video and voice services can never impact each other. <i>This element is only shown in detail mode.</i>
m-cast-max-bw	Parameter type: <SignedInteger> - a signed integer	Represents the rate limitation imposed by the operator upon the maximum bandwidth to be consumed by user multicast video sessions. This limit can enforce a smaller value than actually available on the DSL link. <i>This element is only shown in detail mode.</i>
m-cast-avail-bw	Parameter type: <SignedInteger> - a signed integer	Represents the bandwidth available for multicast services, calculated by the ISAM. This value is what is left from frame-net-bw after deducting from it res-data-bw and res-voice-bw. The minimum of m-cast-avail-bw and m-cast-max-bw will be the actual limitation for user multicast bandwidth usage per DSL link. <i>This element is always shown.</i>
m-cast-used-bw	Parameter type: <SignedInteger> - a signed integer	Shows the bandwidth currently in use by pre-configured multicast streams. <i>This element is always shown.</i>

107.23 QoS Ethernet Bandwidth Status Command

Command Description

Obsolete command, replaced by **show qos interface-bandwidth**.

This command displays the bandwidth allocation and usage for each Ethernet link.

User Level

The command can be accessed by operators with qos privileges.

Command Syntax

The command has the following syntax:

> show qos ethernet-bandwidth [(index)]

Obsolete command, replaced by **show qos interface-bandwidth**.

Command Parameters

Table 107.23-1 "QoS Ethernet Bandwidth Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number	physical port of a ethernet link

Command Output

Table 107.23-2 "QoS Ethernet Bandwidth Status Command" Display parameters

Specific Information		
name	Type	Description
frame-net-bw	Parameter type: <SignedInteger> - a signed integer	Represents the approximate bandwidth available for Ethernet frames, which is guaranteed to be available by the physical layer. This approximation is made by the configurable ATM overhead factor.

name	Type	Description
		<i>This element is always shown.</i>
res-data-bw	Parameter type: <SignedInteger> - a signed integer	The portion the frame-net-bw that is reserved for all data services (typically HSI user traffic). This is a reserved value per DSL interface (and not per user session) and applicable in the downstream direction only. <i>This element is only shown in detail mode.</i>
res-voice-bw	Parameter type: <SignedInteger> - a signed integer	The portion of the frame-net-bw that is reserved for all voice services (typically HSI user traffic). This is a reserved value per DSL interface (and not per voice call) and applicable in the downstream direction only. The usage of this value is to set apart a minimum rate such that video and voice services can never impact each other. <i>This element is only shown in detail mode.</i>
m-cast-max-bw	Parameter type: <SignedInteger> - a signed integer	Represents the rate limitation imposed by the operator upon the maximum bandwidth to be consumed by user multicast video sessions. This limit can enforce a smaller value than actually available on the DSL link. <i>This element is only shown in detail mode.</i>
m-cast-avail-bw	Parameter type: <SignedInteger> - a signed integer	Represents the bandwidth available for multicast services, calculated by the ISAM. This value is what is left from frame-net-bw after deducting from it res-data-bw and res-voice-bw. The minimum of m-cast-avail-bw and m-cast-max-bw will be the actual limitation for user multicast bandwidth usage per DSL link. <i>This element is always shown.</i>
m-cast-used-bw	Parameter type: <SignedInteger> - a signed integer	Shows the bandwidth currently in use by pre-configured multicast streams. <i>This element is always shown.</i>

107.24 QoS Interface Bandwidth Status Command

Command Description

This command displays the bandwidth allocation and usage for each interface.

User Level

The command can be accessed by operators with qos privileges.

Command Syntax

The command has the following syntax:

```
> show qos interface-bandwidth [ (index) ]
```

Command Parameters

Table 107.24-1 "QoS Interface Bandwidth Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> / <Eqpt::OntPortId> pon : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> ont : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / voip <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / vuni ellid : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::LLId> epon : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> eont : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> / <Eqpt::OntPortId> : <Eqpt::UnstackedVlan> vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> / <Eqpt::OntPortId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / voip :	port

Resource Identifier	Type	Description
	<pre> <Eqpt::UnstackedVlan> vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / vuni : <Eqpt::UnstackedVlan> vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / voip : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / vuni : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::UnstackedVlan> vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> chpair : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::ChannelPairId> ont.ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> uni.ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / <Eqpt::Ng2OntSlotId> / <Eqpt::Ng2OntPortId> vlan.ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / <Eqpt::Ng2OntSlotId> / <Eqpt::Ng2OntPortId> : <Eqpt::UnstackedVlan> vlan.ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / <Eqpt::Ng2OntSlotId> / <Eqpt::Ng2OntPortId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> ltbackpl : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> uni.ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / vuni vlan.ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / vuni : <Eqpt::UnstackedVlan> vlan.ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / vuni : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> x-pon : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::XPonId> 25g-pon : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::M25GPonId>) Possible values: - pon : pon - x-pon : xgs pon - 25g-pon : 25g pon - chpair : channel pair - ont : ont - epon : epon - eont : eont - ellid : ellid - vlan : vlan - ont.ng2 : ngpon2 ONT style identification - uni.ng2 : ngpon2 UNI style identification - vlan.ng2 : ngpon2 vlan - ltbackpl : Backplane Port on LT </pre>	

Resource Identifier	Type	Description
	Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number Field type <Eqpt::PonId> - the PON identifier Field type <Eqpt::XPonId> - the XGS PON identifier Field type <Eqpt::M25GPonId> - the 25G PON identifier Field type <Eqpt::ChannelPairId> - the channel pair identifier Field type <Eqpt::ChannelGroupId> - the channel group identifier Field type <Eqpt::SubChannelGroupId> - the subchannel group identifier Field type <Eqpt::OntId> - the ONT identifier Field type <Eqpt::Ng2OntId> - the NG2 ONT identifier Field type <Eqpt::LLId> - the LLID identifier, range 1 for EPON, range 1-8 for DPOE Possible values: - voip : virtual uni identifier obsolete alternative replaced by vuni - vuni : virtual uni identifier Possible values: - vuni : virtual NGPON2 uni identifier Field type <Eqpt::OntSlotId> - the ONT SLOT identifier Field type <Eqpt::OntPortId> - the ONT PORT identifier Field type <Eqpt::Ng2OntSlotId> - the NGPON2 ONT SLOT identifier Field type <Eqpt::Ng2OntPortId> - the NGPON2 ONT PORT identifier Possible values: - stacked : stacked vlan identity Field type <Eqpt::UnstackedVlan> - unstacked vlan id Field type <Eqpt::SVlan> - service vlan id Field type <Eqpt::CVlan> - customer vlan id	

Command Output

Table 107.24-2 "QoS Interface Bandwidth Status Command" Display parameters

Specific Information		
name	Type	Description
frame-net-bw	Parameter type: <SignedInteger> - a signed integer	Represents the approximate bandwidth available for Ethernet

name	Type	Description
		frames, which is guaranteed to be available by the physical layer. This approximation is made by the configurable ATM overhead factor. <i>This element is always shown.</i>
res-data-bw	Parameter type: <Qos::IgnoredSignedInteger> - a signed integer	The portion the frame-net-bw that is reserved for all data services (typically HSI user traffic). This is a reserved value per DSL interface (and not per user session) and applicable in the downstream direction only. <i>This element is only shown in detail mode.</i>
res-voice-bw	Parameter type: <Qos::IgnoredSignedInteger> - a signed integer	The portion of the frame-net-bw that is reserved for all voice services (typically HSI user traffic). This is a reserved value per DSL interface (and not per voice call) and applicable in the downstream direction only. The usage of this value is to set apart a minimum rate such that video and voice services can never impact each other. <i>This element is only shown in detail mode.</i>
m-cast-max-bw	Parameter type: <Qos::IgnoredSignedInteger> - a signed integer	Represents the rate limitation imposed by the operator upon the maximum bandwidth to be consumed by user multicast video sessions. This limit can enforce a smaller value than actually available on the DSL link. <i>This element is only shown in detail mode.</i>
m-cast-avail-bw	Parameter type: <SignedInteger> - a signed integer	Represents the bandwidth available for multicast services, calculated by the ISAM. This value is what is left from frame-net-bw after deducting from it res-data-bw and res-voice-bw. The minimum of m-cast-avail-bw and m-cast-max-bw will be the actual limitation for user multicast bandwidth usage per DSL link. <i>This element is always shown.</i>
m-cast-used-bw	Parameter type: <SignedInteger> - a signed integer	Shows the bandwidth currently in use by pre-configured multicast streams. <i>This element is always shown.</i>
u-cast-avail-us-bw	Parameter type: <SignedInteger> - a signed integer	Shows the up stream bandwidth currently available. <i>This element is always shown.</i>
u-cast-avail-ds-bw	Parameter type: <SignedInteger>	Shows the down stream

107 QOS Status Commands

name	Type	Description
	- a signed integer	bandwidth currently available. <i>This element is always shown.</i>
cur-tcont-per-frame	Parameter type: <SignedInteger> - a signed integer	Shows the current tconts number per frame. <i>This element is always shown.</i>
free-tcont-per-frame	Parameter type: <SignedInteger> - a signed integer	Shows the free tconts number per frame. <i>This element is always shown.</i>

107.25 QoS Total Buffer Overflow Statistics for Previous Quarter

Command Description

This command displays the buffer overflow for each unit applicable on dedicated buffer pools and not on individual queues. These counters are supported on L3 units. Under normal working conditions, all these counters should read zero.

User Level

The command can be accessed by operators with qos privileges.

Command Syntax

The command has the following syntax:

```
> show qos statistics buffer-overflow prev-15min [ (equip-slot) [ interval-num <Qos::CounterInterval> ] ]
```

Command Parameters

Table 107.25-1 "QoS Total Buffer Overflow Statistics for Previous Quarter" Resource Parameters

Resource Identifier	Type	Description
(equip-slot)	Format: (lt : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::EqSlotId>) Possible values: - lt : lt-slot Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::EqSlotId> - the equipment slot number	physical position of the board
interval-num	Parameter type: <Qos::CounterInterval> Format: - time interval interms of 15 mins - range: [1...32]	time interval interms of 15 min

Command Output

Table 107.25-2 "QoS Total Buffer Overflow Statistics for Previous Quarter" Display parameters

Specific Information

107 QOS Status Commands

name	Type	Description
upstream	Parameter type: <Counter> - 32 bit counter	the number of buffer overflows on an LIM module in the upstream direction on a 15 minute interval basis. The upstream direction on the LIM is non-blocking, hence this value should always read zero under normal working conditions. <i>This element is always shown.</i>
upstream-obc	Parameter type: <Counter> - 32 bit counter	the number of buffer overflows on an LIM module for the OBC-directed traffic upstream on a 15 minute interval basis. In some special conditions such as system startup or re-start packet loss may occur here but under normal circumstances this counter should read zero. <i>This element is always shown.</i>
downstream-obc	Parameter type: <Counter> - 32 bit counter	the number of buffer overflows on an LIM module for the OBC-directed traffic downstream on a 15 minute interval basis. Under normal circumstances this counter should always read zero. <i>This element is always shown.</i>
downstream-unicast	Parameter type: <Counter> - 32 bit counter	a counter for the event of total buffer overflow of the downstream unicast pool. This even should not occur. Queue fill-up and tail drop is a normal condition for data traffic (individual queues) but not for voice and video on demand services (individual queues). If the total downstream pool is filled, that means that non-QoS aware packet loss will occur. <i>This element is always shown.</i>
downstream-multicast	Parameter type: <Counter> - 32 bit counter	a counter for the event of total buffer overflow of the downstream multicast pool. This even should be a rather rare event. On the long term, buffer overflow in the multicast pool may occur a few times a day (less than a few tens under heavy multicast usage). <i>This element is always shown.</i>
obc-injected	Parameter type: <Counter> - 32 bit counter	Previous 15 minute for OBC-injected buffer overflow event on LIM, This event happens if the processor cannot cope with the extensive load of the system and cannot reassemble a frame in due time. This event should not occur under normal

name	Type	Description
		working conditions. This counter is used for both upstream and downstream OBC-injected frames on an LIM. <i>This element is always shown.</i>
measured-time	Parameter type: <Qos::TimeTicks> - timer value for parameters - unit: sec	the amount of time, that statistics for this entry have been counted. <i>This element is always shown.</i>
partial-aggr-buf-ovflw	Parameter type: <Vlan::OctetCounter> - vlan counter	the number of lower traffic class packets discarded due to global buffer occupancy threshold overflow <i>This element is always shown.</i>
inv-data-flag	Parameter type: <Qos::DataFlag> (yes no) Possible values: - yes : data is not valid - no : data is valid	Indicates the validity of the corresponding PM data. <i>This element is always shown.</i>

107.26 QoS Total Buffer Overflow Statistics for Current Quarter

Command Description

This command displays the buffer overflow for each unit applicable on dedicated buffer pools and not on individual queues. These counters are supported on L3 units. Under normal working conditions, all these counters should read zero.

User Level

The command can be accessed by operators with qos privileges.

Command Syntax

The command has the following syntax:

```
> show qos statistics buffer-overflow current-15min [ (equip-slot) ]
```

Command Parameters

Table 107.26-1 "QoS Total Buffer Overflow Statistics for Current Quarter" Resource Parameters

Resource Identifier	Type	Description
(equip-slot)	Format: (lt : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::EqSlotId>) Possible values: - lt : lt-slot Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::EqSlotId> - the equipment slot number	physical position of the board

Command Output

Table 107.26-2 "QoS Total Buffer Overflow Statistics for Current Quarter" Display parameters

Specific Information		
name	Type	Description
upstream	Parameter type: <Counter> - 32 bit counter	number of buffer overflows on an EBLT LIM module in the upstream direction on a 15

name	Type	Description
		minute interval basis in the current measurement epoch. The upstream direction on the LIM is non-blocking, hence this value should read always zero under normal working conditions. <i>This element is always shown.</i>
upstream-obc	Parameter type: <Counter> - 32 bit counter	number of buffer overflows on an EBLT LIM module for the OBC-directed traffic upstream on a 15 minute interval basis in the current measurement. In some special conditions such as system startup or re-start packet loss may occur here but under normal circumstances this counter should read zero. <i>This element is always shown.</i>
downstream-obc	Parameter type: <Counter> - 32 bit counter	number of buffer overflows on an EBLT LIM module for the OBC-directed traffic downstream on a 15 minute interval basis in the current measurement. <i>This element is always shown.</i>
downstream-unicast	Parameter type: <Counter> - 32 bit counter	a counter for the event of total buffer overflow of the downstream unicast pool. This even should not occur. Queue fill-up and tail drop is a normal condition for data traffic (individual queues) but not for voice and video on demand services (individual queues). If the total downstream pool is filled, that means that QoS un-aware packet loss will occur. <i>This element is always shown.</i>
downstream-multicast	Parameter type: <Counter> - 32 bit counter	a counter for the event of total buffer overflow of the downstream multicast pool. This even should be a rather rare event. On the long term, buffer overflow in the multicast pool may occur a few times a day (less than a few tens under heavy multicast usage). <i>This element is always shown.</i>
obc-injected	Parameter type: <Counter> - 32 bit counter	Current 15 minute for OBC-injected buffer overflow event on LIM, there is a reserved buffer pool for OBC-injected traffic which under very heavy load conditions may eventually get full, and the LIM OBC will be unable to communicate with the external world for a very short time interval.

107 QOS Status Commands

name	Type	Description
		<i>This element is always shown.</i>
elapsed-time	Parameter type: <Qos::TimeTicks> - timer value for parameters - unit: sec	elapsed time interval since the last measurement epoch started. <i>This element is always shown.</i>
measured-time	Parameter type: <Qos::TimeTicks> - timer value for parameters - unit: sec	the amount of time, that statistics for this entry have been counted. <i>This element is always shown.</i>
partial-aggr-buf-ovflw	Parameter type: <Vlan::OctetCounter> - vlan counter	the number of lower traffic class packets discarded due to global buffer occupancy threshold overflow <i>This element is always shown.</i>
inv-data-flag	Parameter type: <Qos::DataFlag> (yes no) Possible values: - yes : data is not valid - no : data is valid	Indicates the validity of the corresponding PM data <i>This element is always shown.</i>

107.27 QoS Total Buffer Overflow Statistics for Previous Day Command

Command Description

This command displays the buffer overflow for each unit applicable on dedicated buffer pools and not on individual queues. These counters are supported on L3 units. Under normal working conditions, all these counters should read zero.

User Level

The command can be accessed by operators with qos privileges.

Command Syntax

The command has the following syntax:

```
> show qos statistics buffer-overflow prev-1day [ (equip-slot) ]
```

Command Parameters

Table 107.27-1 "QoS Total Buffer Overflow Statistics for Previous Day Command" Resource Parameters

Resource Identifier	Type	Description
(equip-slot)	Format: (lt : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::EqSlotId>) Possible values: - lt : lt-slot Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::EqSlotId> - the equipment slot number	physical position of the board

Command Output

Table 107.27-2 "QoS Total Buffer Overflow Statistics for Previous Day Command" Display parameters

Specific Information		
name	Type	Description
upstream	Parameter type: <Counter>	the number of buffer overflows

107 QOS Status Commands

name	Type	Description
	- 32 bit counter	on an EBLT LIM module in the upstream direction on a one day interval basis. The upstream direction on the LIM is non-blocking, hence this value should read always zero under normal working conditions. <i>This element is always shown.</i>
upstream-obc	Parameter type: <Counter> - 32 bit counter	the number of buffer overflows on an EBLT LIM module for the OBC-directed traffic upstream on a one day interval basis. In some special conditions such as system startup or re-start packet loss may occur here but under normal circumstances this counter should read zero. <i>This element is always shown.</i>
downstream-obc	Parameter type: <Counter> - 32 bit counter	the number of buffer overflows on a EBLT LIM module for the OBC-directed traffic downstream on a one day interval basis. Under normal circumstances this counter should always read zero. <i>This element is always shown.</i>
downstream-unicast	Parameter type: <Counter> - 32 bit counter	a counter for the event of total buffer overflow of the downstream unicast pool. This even should not occur. Queue fill-up and tail drop is a normal condition for data traffic (individual queues) but not for voice and video on demand services (individual queues). If the total downstream pool is filled, that means that non-QoS aware packet loss will occur. <i>This element is always shown.</i>
downstream-multicast	Parameter type: <Counter> - 32 bit counter	a counter for the event of total buffer overflow of the downstream multicast pool. On the long term, buffer overflow in the multicast pool may occur a few times a day (less than a few tens under heavy multicast usage). <i>This element is always shown.</i>
obc-injected	Parameter type: <Counter> - 32 bit counter	previous one day OBC-injected buffer-pool overflow. In some heavy load conditions this event may occur as the OBC-injected frames fill up completely the buffer space reserved for this purpose. <i>This element is always shown.</i>
measured-time	Parameter type: <Qos::TimeTicks> - timer value for parameters	actual time elapsed during which the measurement was made

name	Type	Description
	- unit: sec	<i>This element is always shown.</i>
partial-aggr-buf-ovflw	Parameter type: <Vlan::OctetCounter> - vlan counter	the number of lower traffic class packets discarded due to global buffer occupancy threshold overflow. <i>This element is always shown.</i>
inv-data-flag	Parameter type: <Qos::DataFlag> (yes no) Possible values: - yes : data is not valid - no : data is valid	Indicates the validity of the corresponding PM data. <i>This element is always shown.</i>

107.28 QoS Total Buffer Overflow Statistics for Current Day

Command Description

This command displays the buffer overflow for each unit applicable on dedicated buffer pools and not on individual queues. These counters are supported on L3 units. Under normal working conditions, all these counters should read zero.

User Level

The command can be accessed by operators with qos privileges.

Command Syntax

The command has the following syntax:

```
> show qos statistics buffer-overflow current-1day [ (equip-slot) ]
```

Command Parameters

Table 107.28-1 "QoS Total Buffer Overflow Statistics for Current Day" Resource Parameters

Resource Identifier	Type	Description
(equip-slot)	Format: (lt : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::EqSlotId>) Possible values: - lt : lt-slot Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::EqSlotId> - the equipment slot number	physical position of the board

Command Output

Table 107.28-2 "QoS Total Buffer Overflow Statistics for Current Day" Display parameters

Specific Information		
name	Type	Description
upstream	Parameter type: <Counter> - 32 bit counter	the number of buffer overflows on EBLT LIM modules in the upstream direction on a one day

name	Type	Description
		interval basis in the current measurement period. The upstream direction on the LIM is non-blocking, hence this value should read always zero under normal working conditions. <i>This element is always shown.</i>
upstream-obc	Parameter type: <Counter> - 32 bit counter	the number of buffer overflows on EBLT LIM modules for the OBC-directed traffic upstream on a one day interval basis in the current measurement period. In some special conditions such as system startup or re-start packet loss may occur here but under normal circumstances this counter should read zero. <i>This element is always shown.</i>
downstream-obc	Parameter type: <Counter> - 32 bit counter	the number of buffer overflows on an EBLT LIM module for the OBC-directed traffic downstream on a one day interval basis in the current measurement epoch. under normal circumstances this counter should always read zero. <i>This element is always shown.</i>
downstream-unicast	Parameter type: <Counter> - 32 bit counter	a counter for the event of total buffer overflow of the downstream unicast pool. Queue fill-up and tail drop is a normal condition for data traffic (individual queues) but not for voice and video on demand services (individual queues). If the total downstream pool is filled, that means that QoS un-aware packet loss will occur. <i>This element is always shown.</i>
downstream-multicast	Parameter type: <Counter> - 32 bit counter	specifies number of times, current one day downstream multicast total buffer pool overflow - total buffer overflow of the downstream multicast pool. This even should be a rather rare event. On the long term, buffer overflow in the multicast pool may occur a few times a day (less than a few tens under heavy multicast usage). <i>This element is always shown.</i>
obc-injected	Parameter type: <Counter> - 32 bit counter	specifies number of times, current one day obc-injected buffer overflow occurred. There is a reserved buffer pool for obc-injected traffic which under very heavy load conditions may eventually get full, and the LIM

107 QOS Status Commands

name	Type	Description
		OBC will be unable to communicate with the external world for a very short time interval. <i>This element is always shown.</i>
elapsed-time	Parameter type: <Qos::TimeTicks> - timer value for parameters - unit: sec	elapsed time interval since the last measurement period started. <i>This element is always shown.</i>
measured-time	Parameter type: <Qos::TimeTicks> - timer value for parameters - unit: sec	the measured time interval since the last measurement period started. <i>This element is always shown.</i>
partial-aggr-buf-ovflw	Parameter type: <Vlan::OctetCounter> - vlan counter	the number of lower traffic class packets discarded due to global buffer occupancy threshold overflow. <i>This element is always shown.</i>
inv-data-flag	Parameter type: <Qos::DataFlag> (yes no) Possible values: - yes : data is not valid - no : data is valid	Indicates the validity of the corresponding PM data. <i>This element is always shown.</i>

107.29 QoS Total Buffer Overflow Statistics Total Status Command

Command Description

This command displays the buffer overflow for each unit applicable on dedicated buffer pools and not on individual queues. The L3 units have four isolated buffer pools for upstream, downstream, multicast, and OBC-injected traffic. Under normal working conditions, all these counters should read zero. Check these counters for QoS problems, which can occur under heavy load conditions.

User Level

The command can be accessed by operators with qos privileges.

Command Syntax

The command has the following syntax:

```
> show qos statistics buffer-overflow total [ (equip-slot) ]
```

Command Parameters

Table 107.29-1 "QoS Total Buffer Overflow Statistics Total Status Command" Resource Parameters

Resource Identifier	Type	Description
(equip-slot)	Format: (lt : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::EqSlotId>) Possible values: - lt : lt-slot Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::EqSlotId> - the equipment slot number	physical position of the board

Command Output

Table 107.29-2 "QoS Total Buffer Overflow Statistics Total Status Command" Display parameters

Specific Information		
name	Type	Description
upstream	Parameter type: <Counter>	the number of buffer overflows

107 QOS Status Commands

name	Type	Description
	- 32 bit counter	per EBLT LIM module in the upstream direction since the statistics were last reset. The upstream direction on the LIM is non-blocking, hence this value should read always zero under normal working conditions. <i>This element is always shown.</i>
upstream-obc	Parameter type: <Counter> - 32 bit counter	the number of buffer overflows on a LIM module for the OBC-directed traffic upstream since the statistic was last reset. In some special conditions such as system startup or re-start packet loss may occur here but under normal circumstances this counter should read zero. <i>This element is only shown in detail mode.</i>
downstream-obc	Parameter type: <Counter> - 32 bit counter	the number of buffer overflows on a LIM module for the OBC-directed traffic downstream since the statistic was last reset. Under normal circumstances this counter should always read zero. <i>This element is only shown in detail mode.</i>
downstream-unicast	Parameter type: <Counter> - 32 bit counter	a counter for the event of total buffer overflow of the downstream unicast pool. This even should not occur. Queue fill-up and tail drop is a normal condition for data traffic (individual queues) but not for voice and video on demand services (individual queues). If the total downstream pool is filled, that means that QoS un-aware packet loss will occur. <i>This element is always shown.</i>
downstream-multicast	Parameter type: <Counter> - 32 bit counter	a counter for the event of total buffer overflow of the downstream multicast pool. This even should be a rather rare event. On the long term, buffer overflow in the multicast pool may occur a few times a day (less than a few tens under heavy multicast usage). <i>This element is always shown.</i>
obc-injected	Parameter type: <Counter> - 32 bit counter	the total OBC-injected buffer overflow event on EBLT LIMs. There is a reserved buffer pool for OBC-injected traffic which under very heavy load conditions may eventually get full, and the LIM OBC will be unable to

name	Type	Description
		communicate with the external world for a very short time interval. <i>This element is only shown in detail mode.</i>
elapsed-time	Parameter type: <Qos::TimeTicks> - timer value for parameters - unit: sec	the elapsed time interval since the last measurement period started. <i>This element is only shown in detail mode.</i>
measured-time	Parameter type: <Qos::TimeTicks> - timer value for parameters - unit: sec	the measured time interval since the last measurement period started. <i>This element is only shown in detail mode.</i>
valid-15min-intervals	Parameter type: <Qos::Valid15mInterval> - number of valid 15m intervals - range: [0...96]	the number of statistics of 15 minutes collected so far. At most 96 such entries are stored. <i>This element is always shown.</i>
valid-1day-intervals	Parameter type: <Qos::Valid1dInterval> - number of valid 1 day intervals - range: [0...1]	the number of statistics of one day collected so far. At most one entry is stored from the past. <i>This element is always shown.</i>
total-policer-inuse	Parameter type: <SignedInteger> - a signed integer	the total number of policers in use per EBLT LIM. The policers are managed in hardware in pairs, so even if a Session is using both up and downstream policers, it is counted as one policer. <i>This element is always shown.</i>
policers-in-vlan	Parameter type: <SignedInteger> - a signed integer	this counter is no longer applicable. <i>This element is only shown in detail mode.</i>
policers-in-dot1x	Parameter type: <SignedInteger> - a signed integer	this counter is no longer applicable. <i>This element is only shown in detail mode.</i>
policers-in-ppp	Parameter type: <SignedInteger> - a signed integer	this counter is no longer applicable. <i>This element is only shown in detail mode.</i>
policers-in-ip	Parameter type: <SignedInteger> - a signed integer	this counter is no longer applicable. <i>This element is only shown in detail mode.</i>
policers-in-subflow	Parameter type: <SignedInteger> - a signed integer	this counter is no longer applicable. <i>This element is only shown in detail mode.</i>
total-downstr-bytes	Parameter type: <Vlan::OctetCounter> - vlan counter	the number of LIM physical bus total-downstream passed bytes per LIM module at subscriber side since the statistics were last reset. <i>This element is always shown.</i>
total-downstr-frames	Parameter type: <Vlan::OctetCounter> - vlan counter	the number of LIM physical bus total-downstream passed frames

107 QOS Status Commands

name	Type	Description
		per LIM module at subscriber side since the statistics were last reset. <i>This element is always shown.</i>
partial-aggr-buf-ovflw	Parameter type: <Vlan::OctetCounter> - vlan counter	the number of buffer overflows on a LIM module for the discarded lower traffic class packets due to global buffer occupancy threshold overflow since the statistic was last reset. <i>This element is always shown.</i>

107.30 QoS Interface Buffer Overflow Statistics for Previous Quarter

Command Description

This command displays the interface-level QoS buffer overflow statistics of the previous 15 minute interval.

User Level

The command can be accessed by operators with qos privileges.

Command Syntax

The command has the following syntax:

```
> show qos statistics queue prev-15min [ (index) [ queue <Qos::ExpandQueues> ] [ interval-num
<Qos::NumInterval> ] ]
```

Command Parameters

Table 107.30-1 "QoS Interface Buffer Overflow Statistics for Previous Quarter" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> / <Eqpt::OntPortId> pon : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> ont : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / voip <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / vuni ellid : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::LLId> epon : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> eont : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> / <Eqpt::OntPortId> : <Eqpt::UnstackedVlan> vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> /	physical port or lag port of a dsl link

Resource Identifier	Type	Description
	<code><Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> /</code> <code><Eqpt::OntPortId> : stacked : <Eqpt::SVlan> :</code> <code><Eqpt::CVlan></code> <code> vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> /</code> <code><Eqpt::PonId> / <Eqpt::OntId> / voip :</code> <code><Eqpt::UnstackedVlan></code> <code> vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> /</code> <code><Eqpt::PonId> / <Eqpt::OntId> / vuni :</code> <code><Eqpt::UnstackedVlan></code> <code> vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> /</code> <code><Eqpt::PonId> / <Eqpt::OntId> / voip : stacked :</code> <code><Eqpt::SVlan> : <Eqpt::CVlan></code> <code> vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> /</code> <code><Eqpt::PonId> / <Eqpt::OntId> / vuni : stacked :</code> <code><Eqpt::SVlan> : <Eqpt::CVlan></code> <code> vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> /</code> <code><Eqpt::PortId> : <Eqpt::UnstackedVlan></code> <code> vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> /</code> <code><Eqpt::PortId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan></code> <code> chpair : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId></code> <code>/ <Eqpt::ChannelPairId></code> <code> ont:ng2 : <Eqpt::ChannelGroupId> /</code> <code><Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId></code> <code> uni:ng2 : <Eqpt::ChannelGroupId> /</code> <code><Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> /</code> <code><Eqpt::Ng2OntSlotId> / <Eqpt::Ng2OntPortId></code> <code> vlan:ng2 : <Eqpt::ChannelGroupId> /</code> <code><Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> /</code> <code><Eqpt::Ng2OntSlotId> / <Eqpt::Ng2OntPortId> :</code> <code><Eqpt::UnstackedVlan></code> <code> vlan:ng2 : <Eqpt::ChannelGroupId> /</code> <code><Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> /</code> <code><Eqpt::Ng2OntSlotId> / <Eqpt::Ng2OntPortId> : stacked :</code> <code><Eqpt::SVlan> : <Eqpt::CVlan></code> <code> lbackpl : <Eqpt::RackId> / <Eqpt::ShelfId> /</code> <code><Eqpt::SlotId></code> <code> uni:ng2 : <Eqpt::ChannelGroupId> /</code> <code><Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / vuni</code> <code> vlan:ng2 : <Eqpt::ChannelGroupId> /</code> <code><Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / vuni :</code> <code><Eqpt::UnstackedVlan></code> <code> vlan:ng2 : <Eqpt::ChannelGroupId> /</code> <code><Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / vuni :</code> <code>stacked : <Eqpt::SVlan> : <Eqpt::CVlan></code> <code> x-pon : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId></code> <code>/ <Eqpt::XPonId></code> <code> 25g-pon : <Eqpt::RackId> / <Eqpt::ShelfId> /</code> <code><Eqpt::SlotId> / <Eqpt::M25GPonId>)</code> Possible values: - pon : pon - x-pon : xgs pon - 25g-pon : 25g pon - chpair : channel pair - ont : ont - epon : epon - eont : eont - ellid : ellid	

Resource Identifier	Type	Description
	- vlan : vlan - ont:ng2 : ngpon2 ONT style identification - uni:ng2 : ngpon2 UNI style identification - vlan:ng2 : ngpon2 vlan - ltbackpl : Backplane Port on LT - Field type <Eqpt::RackId> - the rack number - Field type <Eqpt::ShelfId> - the shelf number - Field type <Eqpt::SlotId> - the LT slot number - Field type <Eqpt::PortId> - the port number - Field type <Eqpt::PonId> - the PON identifier - Field type <Eqpt::XPonId> - the XGS PON identifier - Field type <Eqpt::M25GPonId> - the 25G PON identifier - Field type <Eqpt::ChannelPairId> - the channel pair identifier - Field type <Eqpt::ChannelGroupId> - the channel group identifier - Field type <Eqpt::SubChannelGroupId> - the subchannel group identifier - Field type <Eqpt::OntId> - the ONT identifier - Field type <Eqpt::Ng2OntId> - the NG2 ONT identifier - Field type <Eqpt::LLId> - the LLID identifier, range 1 for EPON, range 1-8 for DPOE - Possible values: - voip : virtual uni identifier - obsolete alternative replaced by vuni - vuni : virtual uni identifier - Possible values: - vuni : virtual NGPON2 uni identifier - Field type <Eqpt::OntSlotId> - the ONT SLOT identifier - Field type <Eqpt::OntPortId> - the ONT PORT identifier - Field type <Eqpt::Ng2OntSlotId> - the NGPON2 ONT SLOT identifier - Field type <Eqpt::Ng2OntPortId> - the NGPON2 ONT PORT identifier - Possible values: - stacked : stacked vlan identity - Field type <Eqpt::UnstackedVlan> - unstacked vlan id - Field type <Eqpt::SVlan> - service vlan id - Field type <Eqpt::CVlan> - customer vlan id	
queue	Parameter type: <Qos::ExpandQueues> Format: (all <Qos::ExpandQueues>)	This object is used to index the queue within the scope of one physical link on the LIM

Resource Identifier	Type	Description
	Possible values: - all : total physical line on the LIM Field type <Qos::ExpandQueues> - output dsl port expand queue number - range: [0...7]	
interval-num	Parameter type: <Qos::NumInterval> Format: - time interval in terms of 15 mins - range: [1]	time interval in terms of 15 min

Command Output

Table 107.30-2 "QoS Interface Buffer Overflow Statistics for Previous Quarter" Display parameters

Specific Information		
name	Type	Description
queue-load	Parameter type: <Qos::Load> - load percentage - range: [0...100]	Average queue load percentage <i>This element is always shown.</i>
forward-byte	Parameter type: <Qos::OctetCounter> - qos counter	number of bytes forwarded in this queue. <i>This element is always shown.</i>
forward-frame	Parameter type: <Qos::OctetCounter> - qos counter	number of frames forwarded in this queue. <i>This element is always shown.</i>
discard-byte	Parameter type: <Qos::OctetCounter> - qos counter	number of bytes discarded in this queue. <i>This element is always shown.</i>
discard-frame	Parameter type: <Qos::OctetCounter> - qos counter	number of frames discarded in this queue. <i>This element is always shown.</i>
queue-peak-usage	Parameter type: <Qos::PeakUsage> - peak usage percentage - range: [0...100]	queue peak usage for this interval in percentage. <i>This element is always shown.</i>
measured-time	Parameter type: <Qos::TimeTicks> - timer value for parameters - unit: sec	The measured time interval since the last measurement period started. <i>This element is always shown.</i>
inv-data-flag	Parameter type: <Qos::DataFlag> (yes no) Possible values: - yes : data is not valid - no : data is valid	Indicates the validity of the corresponding PM data. <i>This element is always shown.</i>

107.31 QoS Interface Buffer Overflow Statistics for Current Quarter

Command Description

This command displays the interface-level QoS buffer overflow statistics of the current 15 minute interval.

User Level

The command can be accessed by operators with qos privileges.

Command Syntax

The command has the following syntax:

```
> show qos statistics queue current-15min [ (index) [ queue <Qos::ExpandQueues> ] ]
```

Command Parameters

Table 107.31-1 "QoS Interface Buffer Overflow Statistics for Current Quarter" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> / <Eqpt::OntPortId> pon : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> ont : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / voip <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / vuni ellid : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::LLId> epon : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> eont : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> / <Eqpt::OntPortId> : <Eqpt::UnstackedVlan> vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> /	physical port or lag port of a dsl link

Resource Identifier	Type	Description
	<pre> <Eqpt::OntPortId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / voip : <Eqpt::UnstackedVlan> vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / vuni : <Eqpt::UnstackedVlan> vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / voip : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / vuni : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::UnstackedVlan> vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> chpair : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::ChannelPairId> ont.ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> uni.ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / <Eqpt::Ng2OntSlotId> / <Eqpt::Ng2OntPortId> vlan.ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / <Eqpt::Ng2OntSlotId> / <Eqpt::Ng2OntPortId> : <Eqpt::UnstackedVlan> vlan.ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / <Eqpt::Ng2OntSlotId> / <Eqpt::Ng2OntPortId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> lbackpl : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> uni.ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / vuni vlan.ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / vuni : <Eqpt::UnstackedVlan> vlan.ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / vuni : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> x-pon : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::XPonId> 25g-pon : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::M25GPonId>) Possible values: - pon : pon - x-pon : xgs pon - 25g-pon : 25g pon - chpair : channel pair - ont : ont - epon : epon - eont : eont - ellid : ellid - vlan : vlan </pre>	

Resource Identifier	Type	Description
	- ont:ng2 : ngpon2 ONT style identification - uni:ng2 : ngpon2 UNI style identification - vlan:ng2 : ngpon2 vlan - ltbackpl : Backplane Port on LT - Field type <Eqpt::RackId> - the rack number - Field type <Eqpt::ShelfId> - the shelf number - Field type <Eqpt::SlotId> - the LT slot number - Field type <Eqpt::PortId> - the port number - Field type <Eqpt::PonId> - the PON identifier - Field type <Eqpt::XPonId> - the XGS PON identifier - Field type <Eqpt::M25GPonId> - the 25G PON identifier - Field type <Eqpt::ChannelPairId> - the channel pair identifier - Field type <Eqpt::ChannelGroupId> - the channel group identifier - Field type <Eqpt::SubChannelGroupId> - the subchannel group identifier - Field type <Eqpt::OntId> - the ONT identifier - Field type <Eqpt::Ng2OntId> - the NG2 ONT identifier - Field type <Eqpt::LLId> - the LLID identifier, range 1 for EPON, range 1-8 for DPOE - Possible values: - voip : virtual uni identifier - obsolete alternative replaced by vuni - vuni : virtual uni identifier - Possible values: - vuni : virtual NGPON2 uni identifier - Field type <Eqpt::OntSlotId> - the ONT SLOT identifier - Field type <Eqpt::OntPortId> - the ONT PORT identifier - Field type <Eqpt::Ng2OntSlotId> - the NGPON2 ONT SLOT identifier - Field type <Eqpt::Ng2OntPortId> - the NGPON2 ONT PORT identifier - Possible values: - stacked : stacked vlan identity - Field type <Eqpt::UnstackedVlan> - unstacked vlan id - Field type <Eqpt::SVlan> - service vlan id - Field type <Eqpt::CVlan> - customer vlan id	
queue	Parameter type: <Qos::ExpandQueues> Format: (all <Qos::ExpandQueues>) Possible values:	This object is used to index the queue within the scope of one physical link on the LIM

Resource Identifier	Type	Description
	- all : total physical line on the LIM Field type <Qos::ExpandQueues> - output dsl port expand queue number - range: [0...7]	

Command Output

Table 107.31-2 "QoS Interface Buffer Overflow Statistics for Current Quarter" Display parameters

Specific Information		
name	Type	Description
queue-load	Parameter type: <Qos::Load> - load percentage - range: [0...100]	Average queue load percentage <i>This element is always shown.</i>
forward-byte	Parameter type: <Qos::OctetCounter> - qos counter	number of bytes forwarded in this queue. <i>This element is always shown.</i>
forward-frame	Parameter type: <Qos::OctetCounter> - qos counter	number of frames forwarded in this queue. <i>This element is always shown.</i>
discard-byte	Parameter type: <Qos::OctetCounter> - qos counter	number of bytes discarded in this queue. <i>This element is always shown.</i>
discard-frame	Parameter type: <Qos::OctetCounter> - qos counter	number of frames discarded in this queue. <i>This element is always shown.</i>
queue-peak-usage	Parameter type: <Qos::PeakUsage> - peak usage percentage - range: [0...100]	queue peak usage for this interval in percentage. <i>This element is always shown.</i>
measured-time	Parameter type: <Qos::TimeTicks> - timer value for parameters - unit: sec	The measured time interval since the last measurement period started. <i>This element is always shown.</i>
elapsed-time	Parameter type: <Qos::TimeTicks> - timer value for parameters - unit: sec	The elapsed time interval since the last measurement period started. <i>This element is always shown.</i>
inv-data-flag	Parameter type: <Qos::DataFlag> (yes no) Possible values: - yes : data is not valid - no : data is valid	Indicates the validity of the corresponding PM data <i>This element is always shown.</i>

107.32 QoS Fan Out Statistics for Previous Quarter

Command Description

This command shows the QoS Fan Out statistics of the previous 15 minute interval.

Currently, only traffic classes [0...3] are supported for traffic class voice, resp. video, CL, BE and traffic class 8 for the aggregate of the previous mentioned traffic classes

User Level

The command can be accessed by operators with qos privileges.

Command Syntax

The command has the following syntax:

```
> show qos statistics lt-cos prev-15min [ (equip-slot) [ traffic-class <Qos::TrafficClass> ] [ interval-num
<Qos::NumIntervalExpand> ] ]
```

Command Parameters

Table 107.32-1 "QoS Fan Out Statistics for Previous Quarter" Resource Parameters

Resource Identifier	Type	Description
(equip-slot)	Format: (lt : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::EqSlotId>) Possible values: - lt : lt-slot Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::EqSlotId> - the equipment slot number	physical position of the board
traffic-class	Parameter type: <Qos::TrafficClass> Format: - value of traffic class, the received frame is mapped to - range: [0...8]	This object is used to index the traffic class on the LIM
interval-num	Parameter type: <Qos::NumIntervalExpand> Format: - time interval in terms of 15 mins - range: [1...96]	time interval in terms of 15 min

Command Output

Table 107.32-2 "QoS Fan Out Statistics for Previous Quarter" Display parameters

Specific Information		
name	Type	Description
load	Parameter type: <Qos::Load> - load percentage - range: [0...100]	traffic class load percentage <i>This element is always shown.</i>
forward-byte	Parameter type: <Qos::OctetCounter> - qos counter	number of bytes forwarded in this traffic class. <i>This element is always shown.</i>
forward-frame	Parameter type: <Qos::OctetCounter> - qos counter	number of frames forwarded in this traffic class. <i>This element is always shown.</i>
measured-time	Parameter type: <Qos::TimeTicks> - timer value for parameters - unit: sec	The measured time interval since the last measurement period started. <i>This element is always shown.</i>
inv-data-flag	Parameter type: <Qos::DataFlag> (yes no) Possible values: - yes : data is not valid - no : data is valid	Indicates the validity of the corresponding PM data. <i>This element is always shown.</i>

107.33 QoS Fan Out Statistics for Current 15 minutes

Command Description

This command shows the QoS Fan Out statistics of the current 15 minutes interval.

Currently, only traffic classes [0...3] are supported for traffic class voice, resp. video, CL, BE and traffic class 8 for the aggregate of the previous mentioned traffic classes

User Level

The command can be accessed by operators with qos privileges.

Command Syntax

The command has the following syntax:

```
> show qos statistics lt-cos current-15min [ (equip-slot) [ traffic-class <Qos::TrafficClass> ] ]
```

Command Parameters

Table 107.33-1 "QoS Fan Out Statistics for Current 15 minutes" Resource Parameters

Resource Identifier	Type	Description
(equip-slot)	Format: (lt : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::EqSlotId>) Possible values: - lt : lt-slot Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::EqSlotId> - the equipment slot number	physical position of the board
traffic-class	Parameter type: <Qos::TrafficClass> Format: - value of traffic class, the received frame is mapped to - range: [0...8]	This object is used to index the traffic class on the LIM

Command Output

Table 107.33-2 "QoS Fan Out Statistics for Current 15 minutes" Display parameters

Specific Information

107 QOS Status Commands

name	Type	Description
load	Parameter type: <Qos::Load> - load percentage - range: [0...100]	traffic class load percentage <i>This element is always shown.</i>
forward-byte	Parameter type: <Qos::OctetCounter> - qos counter	number of bytes forwarded in this traffic class. <i>This element is always shown.</i>
forward-frame	Parameter type: <Qos::OctetCounter> - qos counter	number of frames forwarded in this traffic class. <i>This element is always shown.</i>
elapsed-time	Parameter type: <Qos::TimeTicks> - timer value for parameters - unit: sec	The elapsed time interval since the last measurement epoch started. <i>This element is always shown.</i>
measured-time	Parameter type: <Qos::TimeTicks> - timer value for parameters - unit: sec	The measured time interval since the last measurement period started. <i>This element is always shown.</i>
inv-data-flag	Parameter type: <Qos::DataFlag> (yes no) Possible values: - yes : data is not valid - no : data is valid	Indicates the validity of the corresponding PM data. <i>This element is always shown.</i>

107.34 QoS Fan Out Statistics for Previous Day

Command Description

This command shows the QoS Fan Out statistics of the previous 1 day interval.

User Level

The command can be accessed by operators with qos privileges.

Command Syntax

The command has the following syntax:

```
> show qos statistics lt-cos prev-1day [ (equip-slot) [ interval-num <Qos::NumInterval> ] ]
```

Command Parameters

Table 107.34-1 "QoS Fan Out Statistics for Previous Day " Resource Parameters

Resource Identifier	Type	Description
(equip-slot)	Format: (lt : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::EqSlotId>) Possible values: - lt : lt-slot Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::EqSlotId> - the equipment slot number	physical position of the board
interval-num	Parameter type: <Qos::NumInterval> Format: - time interval interms of 15 mins - range: [1]	time interval interms of one day

Command Output

Table 107.34-2 "QoS Fan Out Statistics for Previous Day " Display parameters

Specific Information		
name	Type	Description
forward-byte	Parameter type: <Qos::OctetCounter> - qos counter	number of bytes forwarded in this LIM. <i>This element is always shown.</i>
forward-frame	Parameter type: <Qos::OctetCounter>	number of frames forwarded in

107 QOS Status Commands

name	Type	Description
	- qos counter	this LIM. <i>This element is always shown.</i>
measured-time	Parameter type: <Qos::TimeTicks> - timer value for parameters - unit: sec	The measured time interval since the last measurement period started. <i>This element is always shown.</i>
inv-data-flag	Parameter type: <Qos::DataFlag> (yes no) Possible values: - yes : data is not valid - no : data is valid	Indicates the validity of the corresponding PM data. <i>This element is always shown.</i>

107.35 QoS Fan Out Statistics for Current Day

Command Description

This command shows the QoS fan out statistics of the current 1 day interval.

User Level

The command can be accessed by operators with qos privileges.

Command Syntax

The command has the following syntax:

```
> show qos statistics lt-cos current-1day [ (equip-slot) ]
```

Command Parameters

Table 107.35-1 "QoS Fan Out Statistics for Current Day" Resource Parameters

Resource Identifier	Type	Description
(equip-slot)	Format: (lt : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::EqSlotId>) Possible values: - lt : lt-slot Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::EqSlotId> - the equipment slot number	physical position of the board

Command Output

Table 107.35-2 "QoS Fan Out Statistics for Current Day" Display parameters

Specific Information		
name	Type	Description
forward-byte	Parameter type: <Qos::OctetCounter> - qos counter	number of bytes forwarded in this LIM. <i>This element is always shown.</i>
forward-frame	Parameter type: <Qos::OctetCounter> - qos counter	number of frames forwarded in this LIM. <i>This element is always shown.</i>
elapsed-time	Parameter type: <Qos::TimeTicks> - timer value for parameters	The elapsed time interval since the last measurement epoch

107 QOS Status Commands

name	Type	Description
	- unit: sec	started. <i>This element is always shown.</i>
measured-time	Parameter type: <Qos::TimeTicks> - timer value for parameters - unit: sec	The measured time interval since the last measurement period started. <i>This element is always shown.</i>
inv-data-flag	Parameter type: <Qos::DataFlag> (yes no) Possible values: - yes : data is not valid - no : data is valid	Indicates the validity of the corresponding PM data. <i>This element is always shown.</i>

107.36 QoS LT Queue Overflow Statistics for Previous Quarter

Command Description

This command displays the previous 15 min QoS statistics on a per GLT LIM basis of packets discarded towards OBC and backplane.

User Level

The command can be accessed by operators with qos privileges.

Command Syntax

The command has the following syntax:

```
> show qos statistics lt-queue prev-15min [ (index) ]
```

Command Parameters

Table 107.36-1 "QoS LT Queue Overflow Statistics for Previous Quarter" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId>) Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number	physical position of the board

Command Output

Table 107.36-2 "QoS LT Queue Overflow Statistics for Previous Quarter" Display parameters

Specific Information		
name	Type	Description
bckpln-low-dis-frame	Parameter type: <Counter> - 32 bit counter	Current discarded packet count towards backplane due to low water mark crossing. <i>This element is always shown.</i>
bckpln-low-dis-bytes	Parameter type: <Counter> - 32 bit counter	Current discarded bytes count towards backplane due to low water mark crossing. <i>This element is always shown.</i>

107 QOS Status Commands

name	Type	Description
bckpln-high-dis-frame	Parameter type: <Counter> - 32 bit counter	Current discarded packet count towards backplane due to high water mark crossing. <i>This element is always shown.</i>
bckpln-high-dis-bytes	Parameter type: <Counter> - 32 bit counter	Current discarded bytes count towards backplane due to high water mark crossing. <i>This element is always shown.</i>
obc-low-discard-frame	Parameter type: <Counter> - 32 bit counter	Current discarded packet count towards OBC due to low water mark crossing. <i>This element is always shown.</i>
obc-low-discard-bytes	Parameter type: <Counter> - 32 bit counter	Current discarded bytes count towards OBC due to low water mark crossing. <i>This element is always shown.</i>
obc-high-discard-frame	Parameter type: <Counter> - 32 bit counter	Current discarded packet count towards OBC due to high water mark crossing. <i>This element is always shown.</i>
obc-high-discard-bytes	Parameter type: <Counter> - 32 bit counter	Current discarded byte count towards OBC due to high water mark crossing. <i>This element is always shown.</i>
bckpln_down_dis_frame	Parameter type: <Counter> - 32 bit counter	Current discarded downstream packets due to congestion or oversized. <i>This element is always shown.</i>

107.37 QoS LT Queue Overflow Statistics for current Quarter

Command Description

This command displays the current 15 min QoS statistics on a per GLT LIM basis of packets discarded towards OBC and backplane.

User Level

The command can be accessed by operators with qos privileges.

Command Syntax

The command has the following syntax:

```
> show qos statistics lt-queue current-15min [ (index) ]
```

Command Parameters

Table 107.37-1 "QoS LT Queue Overflow Statistics for current Quarter" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId>) Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number	physical position of the board

Command Output

Table 107.37-2 "QoS LT Queue Overflow Statistics for current Quarter" Display parameters

Specific Information		
name	Type	Description
bckpln-low-dis-frame	Parameter type: <Counter> - 32 bit counter	Current discarded packet count towards backplane due to low water mark crossing. <i>This element is always shown.</i>
bckpln-low-dis-bytes	Parameter type: <Counter> - 32 bit counter	Current discarded bytes count towards backplane due to low water mark crossing. <i>This element is always shown.</i>

107 QOS Status Commands

name	Type	Description
bckpln-high-dis-frame	Parameter type: <Counter> - 32 bit counter	Current discarded packet count towards backplane due to high water mark crossing. <i>This element is always shown.</i>
bckpln-high-dis-bytes	Parameter type: <Counter> - 32 bit counter	Current discarded bytes count towards backplane due to high water mark crossing. <i>This element is always shown.</i>
obc-low-discard-frame	Parameter type: <Counter> - 32 bit counter	Current discarded packet count towards OBC due to low water mark crossing. <i>This element is always shown.</i>
obc-low-discard-bytes	Parameter type: <Counter> - 32 bit counter	Current discarded byte count towards OBC due to low water mark crossing. <i>This element is always shown.</i>
obc-high-discard-frame	Parameter type: <Counter> - 32 bit counter	Current discarded packet count towards OBC due to high water mark crossing. <i>This element is always shown.</i>
obc-high-discard-bytes	Parameter type: <Counter> - 32 bit counter	Current discarded byte count towards OBC due to high water mark crossing. <i>This element is always shown.</i>
bckpln_down_dis_frame	Parameter type: <Counter> - 32 bit counter	Current discarded downstream packets due to congestion or oversized. <i>This element is always shown.</i>

107.38 QoS Interface Color Queue Statistics for Previous 15 minutes Quarter

Command Description

This command displays the interface-level QoS color queue statistics of the previous 15 minute interval.

User Level

The command can be accessed by operators with qos privileges.

Command Syntax

The command has the following syntax:

```
> show qos statistics color-queue prev-15min [ (index) [ queue <Qos::ExpandQueues> ] [ interval-num
<Qos::NumInterval> ] ]
```

Command Parameters

Table 107.38-1 "QoS Interface Color Queue Statistics for Previous 15 minutes Quarter" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> / <Eqpt::OntPortId> pon : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> ont : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / voip <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / vuni ellid : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::LLId> epon : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> eont : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> / <Eqpt::OntPortId> : <Eqpt::UnstackedVlan> vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> /	physical port or lag port of a dsl link

Resource Identifier	Type	Description
	<code><Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> /</code> <code><Eqpt::OntPortId> : stacked : <Eqpt::SVlan> :</code> <code><Eqpt::CVlan></code> <code> vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> /</code> <code><Eqpt::PonId> / <Eqpt::OntId> / voip :</code> <code><Eqpt::UnstackedVlan></code> <code> vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> /</code> <code><Eqpt::PonId> / <Eqpt::OntId> / vuni :</code> <code><Eqpt::UnstackedVlan></code> <code> vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> /</code> <code><Eqpt::PonId> / <Eqpt::OntId> / voip : stacked :</code> <code><Eqpt::SVlan> : <Eqpt::CVlan></code> <code> vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> /</code> <code><Eqpt::PonId> / <Eqpt::OntId> / vuni : stacked :</code> <code><Eqpt::SVlan> : <Eqpt::CVlan></code> <code> vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> /</code> <code><Eqpt::PortId> : <Eqpt::UnstackedVlan></code> <code> vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> /</code> <code><Eqpt::PortId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan></code> <code> chpair : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId></code> <code>/ <Eqpt::ChannelPairId></code> <code> ont:ng2 : <Eqpt::ChannelGroupId> /</code> <code><Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId></code> <code> uni:ng2 : <Eqpt::ChannelGroupId> /</code> <code><Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> /</code> <code><Eqpt::Ng2OntSlotId> / <Eqpt::Ng2OntPortId></code> <code> vlan:ng2 : <Eqpt::ChannelGroupId> /</code> <code><Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> /</code> <code><Eqpt::Ng2OntSlotId> / <Eqpt::Ng2OntPortId> :</code> <code><Eqpt::UnstackedVlan></code> <code> vlan:ng2 : <Eqpt::ChannelGroupId> /</code> <code><Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> /</code> <code><Eqpt::Ng2OntSlotId> / <Eqpt::Ng2OntPortId> : stacked :</code> <code><Eqpt::SVlan> : <Eqpt::CVlan></code> <code> lbackpl : <Eqpt::RackId> / <Eqpt::ShelfId> /</code> <code><Eqpt::SlotId></code> <code> uni:ng2 : <Eqpt::ChannelGroupId> /</code> <code><Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / vuni</code> <code> vlan:ng2 : <Eqpt::ChannelGroupId> /</code> <code><Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / vuni :</code> <code><Eqpt::UnstackedVlan></code> <code> vlan:ng2 : <Eqpt::ChannelGroupId> /</code> <code><Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / vuni :</code> <code>stacked : <Eqpt::SVlan> : <Eqpt::CVlan></code> <code> x-pon : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId></code> <code>/ <Eqpt::XPonId></code> <code> 25g-pon : <Eqpt::RackId> / <Eqpt::ShelfId> /</code> <code><Eqpt::SlotId> / <Eqpt::M25GPonId>)</code> Possible values: - pon : pon - x-pon : xgs pon - 25g-pon : 25g pon - chpair : channel pair - ont : ont - epon : epon - eont : eont - ellid : ellid	

Resource Identifier	Type	Description
	- vlan : vlan - ont:ng2 : ngpon2 ONT style identification - uni:ng2 : ngpon2 UNI style identification - vlan:ng2 : ngpon2 vlan - ltbackpl : Backplane Port on LT - Field type <Eqpt::RackId> - the rack number - Field type <Eqpt::ShelfId> - the shelf number - Field type <Eqpt::SlotId> - the LT slot number - Field type <Eqpt::PortId> - the port number - Field type <Eqpt::PonId> - the PON identifier - Field type <Eqpt::XPonId> - the XGS PON identifier - Field type <Eqpt::M25GPonId> - the 25G PON identifier - Field type <Eqpt::ChannelPairId> - the channel pair identifier - Field type <Eqpt::ChannelGroupId> - the channel group identifier - Field type <Eqpt::SubChannelGroupId> - the subchannel group identifier - Field type <Eqpt::OntId> - the ONT identifier - Field type <Eqpt::Ng2OntId> - the NG2 ONT identifier - Field type <Eqpt::LLId> - the LLID identifier, range 1 for EPON, range 1-8 for DPOE - Possible values: - voip : virtual uni identifier - obsolete alternative replaced by vuni - vuni : virtual uni identifier - Possible values: - vuni : virtual NGPON2 uni identifier - Field type <Eqpt::OntSlotId> - the ONT SLOT identifier - Field type <Eqpt::OntPortId> - the ONT PORT identifier - Field type <Eqpt::Ng2OntSlotId> - the NGPON2 ONT SLOT identifier - Field type <Eqpt::Ng2OntPortId> - the NGPON2 ONT PORT identifier - Possible values: - stacked : stacked vlan identity - Field type <Eqpt::UnstackedVlan> - unstacked vlan id - Field type <Eqpt::SVlan> - service vlan id - Field type <Eqpt::CVlan> - customer vlan id	
queue	Parameter type: <Qos::ExpandQueues> Format: (all <Qos::ExpandQueues>)	This object is used to index the queue within the scope of one physical link on the LIM

Resource Identifier	Type	Description
	Possible values: - all : total physical line on the LIM Field type <Qos::ExpandQueues> - output dsl port expand queue number - range: [0...7]	
interval-num	Parameter type: <Qos::NumInterval> Format: - time interval in terms of 15 mins - range: [1]	time interval in terms of 15 min

Command Output

Table 107.38-2 "QoS Interface Color Queue Statistics for Previous 15 minutes Quarter" Display parameters

Specific Information		
name	Type	Description
red-forward-byte	Parameter type: <Qos::OctetCounter> - qos counter	number of bytes forwarded red in this queue. <i>This element is always shown.</i>
red-forward-frame	Parameter type: <Qos::OctetCounter> - qos counter	number of frames forwarded red in this queue. <i>This element is always shown.</i>
red-discard-byte	Parameter type: <Qos::OctetCounter> - qos counter	number of bytes discarded red in this queue. <i>This element is always shown.</i>
red-discard-frame	Parameter type: <Qos::OctetCounter> - qos counter	number of frames discarded red in this queue. <i>This element is always shown.</i>
yellow-forward-byte	Parameter type: <Qos::OctetCounter> - qos counter	number of bytes forwarded yellow in this queue. <i>This element is always shown.</i>
yellow-forward-frame	Parameter type: <Qos::OctetCounter> - qos counter	number of frames forwarded yellow in this queue. <i>This element is always shown.</i>
yellow-discard-byte	Parameter type: <Qos::OctetCounter> - qos counter	number of bytes discarded yellow in this queue. <i>This element is always shown.</i>
yellow-discard-frame	Parameter type: <Qos::OctetCounter> - qos counter	number of frames discarded yellow in this queue. <i>This element is always shown.</i>
green-forward-byte	Parameter type: <Qos::OctetCounter> - qos counter	number of bytes forwarded green in this queue. <i>This element is always shown.</i>
green-forward-frame	Parameter type: <Qos::OctetCounter> - qos counter	number of frames forwarded green in this queue. <i>This element is always shown.</i>
green-discard-byte	Parameter type: <Qos::OctetCounter> - qos counter	number of bytes discarded green in this queue. <i>This element is always shown.</i>
green-discard-frame	Parameter type: <Qos::OctetCounter> - qos counter	number of frames discarded green in this queue. <i>This element is always shown.</i>
measured-time	Parameter type: <Qos::TimeTicks> - timer value for parameters - unit: sec	The measured time interval since the last measurement period started. <i>This element is always shown.</i>

107.39 QoS Interface Color Queue Statistics for Current 15 minutes Quarter

Command Description

This command displays the interface-level QoS color queue statistics of the current 15 minute interval.

User Level

The command can be accessed by operators with qos privileges.

Command Syntax

The command has the following syntax:

```
> show qos statistics color-queue current-15min [ (index) [ queue <Qos::ExpandQueues> ] ]
```

Command Parameters

Table 107.39-1 "QoS Interface Color Queue Statistics for Current 15 minutes Quarter" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> / <Eqpt::OntPortId> pon : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> ont : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / voip <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / vuni ellid : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::LLId> epon : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> eont : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> / <Eqpt::OntPortId> : <Eqpt::UnstackedVlan> vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> /	physical port or lag port of a dsl link

Resource Identifier	Type	Description
	<pre> <Eqpt::OntPortId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / voip : <Eqpt::UnstackedVlan> vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / vuni : <Eqpt::UnstackedVlan> vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / voip : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / vuni : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::UnstackedVlan> vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> chpair : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::ChannelPairId> ont:ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> uni:ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / <Eqpt::Ng2OntSlotId> / <Eqpt::Ng2OntPortId> vlan:ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / <Eqpt::Ng2OntSlotId> / <Eqpt::Ng2OntPortId> : <Eqpt::UnstackedVlan> vlan:ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / <Eqpt::Ng2OntSlotId> / <Eqpt::Ng2OntPortId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> lbackpl : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> uni:ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / vuni vlan:ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / vuni : <Eqpt::UnstackedVlan> vlan:ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / vuni : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> x-pon : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::XPonId> 25g-pon : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::M25GPonId>) Possible values: - pon : pon - x-pon : xgs pon - 25g-pon : 25g pon - chpair : channel pair - ont : ont - epon : epon - eont : eont - ellid : ellid - vlan : vlan </pre>	

Resource Identifier	Type	Description
	- ont:ng2 : ngpon2 ONT style identification - uni:ng2 : ngpon2 UNI style identification - vlan:ng2 : ngpon2 vlan - ltbackpl : Backplane Port on LT - Field type <Eqpt::RackId> - the rack number - Field type <Eqpt::ShelfId> - the shelf number - Field type <Eqpt::SlotId> - the LT slot number - Field type <Eqpt::PortId> - the port number - Field type <Eqpt::PonId> - the PON identifier - Field type <Eqpt::XPonId> - the XGS PON identifier - Field type <Eqpt::M25GPonId> - the 25G PON identifier - Field type <Eqpt::ChannelPairId> - the channel pair identifier - Field type <Eqpt::ChannelGroupId> - the channel group identifier - Field type <Eqpt::SubChannelGroupId> - the subchannel group identifier - Field type <Eqpt::OntId> - the ONT identifier - Field type <Eqpt::Ng2OntId> - the NG2 ONT identifier - Field type <Eqpt::LLId> - the LLID identifier, range 1 for EPON, range 1-8 for DPOE - Possible values: - voip : virtual uni identifier - obsolete alternative replaced by vuni - vuni : virtual uni identifier - Possible values: - vuni : virtual NGPON2 uni identifier - Field type <Eqpt::OntSlotId> - the ONT SLOT identifier - Field type <Eqpt::OntPortId> - the ONT PORT identifier - Field type <Eqpt::Ng2OntSlotId> - the NGPON2 ONT SLOT identifier - Field type <Eqpt::Ng2OntPortId> - the NGPON2 ONT PORT identifier - Possible values: - stacked : stacked vlan identity - Field type <Eqpt::UnstackedVlan> - unstacked vlan id - Field type <Eqpt::SVlan> - service vlan id - Field type <Eqpt::CVlan> - customer vlan id	
queue	Parameter type: <Qos::ExpandQueues> Format: (all <Qos::ExpandQueues>) Possible values:	This object is used to index the queue within the scope of one physical link on the LIM

Resource Identifier	Type	Description
	- all : total physical line on the LIM - Field type <Qos::ExpandQueues> - output dsl port expand queue number - range: [0...7]	

Command Output

Table 107.39-2 "QoS Interface Color Queue Statistics for Current 15 minutes Quarter" Display parameters

Specific Information		
name	Type	Description
red-forward-byte	Parameter type: <Qos::OctetCounter> - qos counter	number of bytes forwarded red in this queue. <i>This element is always shown.</i>
red-forward-frame	Parameter type: <Qos::OctetCounter> - qos counter	number of frames forwarded red in this queue. <i>This element is always shown.</i>
red-discard-byte	Parameter type: <Qos::OctetCounter> - qos counter	number of bytes discarded red in this queue. <i>This element is always shown.</i>
red-discard-frame	Parameter type: <Qos::OctetCounter> - qos counter	number of frames discarded red in this queue. <i>This element is always shown.</i>
yellow-forward-byte	Parameter type: <Qos::OctetCounter> - qos counter	number of bytes forwarded yellow in this queue. <i>This element is always shown.</i>
yellow-forward-frame	Parameter type: <Qos::OctetCounter> - qos counter	number of frames forwarded yellow in this queue. <i>This element is always shown.</i>
yellow-discard-byte	Parameter type: <Qos::OctetCounter> - qos counter	number of bytes discarded yellow in this queue. <i>This element is always shown.</i>
yellow-discard-frame	Parameter type: <Qos::OctetCounter> - qos counter	number of frames discarded yellow in this queue. <i>This element is always shown.</i>
green-forward-byte	Parameter type: <Qos::OctetCounter> - qos counter	number of bytes forwarded green in this queue. <i>This element is always shown.</i>
green-forward-frame	Parameter type: <Qos::OctetCounter> - qos counter	number of frames forwarded green in this queue. <i>This element is always shown.</i>
green-discard-byte	Parameter type: <Qos::OctetCounter> - qos counter	number of bytes discarded green in this queue. <i>This element is always shown.</i>
green-discard-frame	Parameter type: <Qos::OctetCounter> - qos counter	number of frames discarded green in this queue. <i>This element is always shown.</i>
measured-time	Parameter type: <Qos::TimeTicks> - timer value for parameters - unit: sec	The measured time interval since the last measurement period started. <i>This element is always shown.</i>

107.40 QoS TC2QMapping Status Command

Command Description

This command shows the mapping between the traffic class and the queue of a UNI. Three rows in the table will be automatically created with default values and can only be edited but the operator. Row 1 is used for the case when the LIM has 4 queues per UNI and 4 TCs, Row 2 is used for the case when the LIM has 4 queues per UNI but 8 TCs, Row 3 is used for the case when the LIM has 8 queues per UNI but 8 TCs.

User Level

The command can be accessed by operators with qos privileges.

Command Syntax

The command has the following syntax:

```
> show qos tc-to-qmap [ (name) ]
```

Command Parameters

Table 107.40-1 "QoS TC2QMapping Status Command" Resource Parameters

Resource Identifier	Type	Description
(name)	Format: (legacy4queue 4queuemapping 8queuemapping) Possible values: - legacy4queue : LIM has 4 queues per UNI and 4 TCs - 4queuemapping : LIM has 4 queues per UNI but 8 TCs - 8queuemapping : LIM has 8 queues per UNI but 8 TCs	name of the mapping

Command Output

Table 107.40-2 "QoS TC2QMapping Status Command" Display parameters

Specific Information		
name	Type	Description
traffic-class0	Parameter type: <Vlan::NibbleMask_0> - nibble mask	the queue corresponding to Traffic Class 0. <i>This element is always shown.</i>
traffic-class1	Parameter type: <Vlan::NibbleMask_1> - nibble mask	the queue corresponding to Traffic Class 1. <i>This element is always shown.</i>
traffic-class2	Parameter type: <Vlan::NibbleMask_2> - nibble mask	the queue corresponding to Traffic Class 2. <i>This element is always shown.</i>
traffic-class3	Parameter type: <Vlan::NibbleMask_3>	the queue corresponding to

name	Type	Description
	- nibble mask	Traffic Class 3. <i>This element is always shown.</i>
traffic-class4	Parameter type: <Vlan::NibbleMask_4> - nibble mask	the queue corresponding to Traffic Class 4. <i>This element is always shown.</i>
traffic-class5	Parameter type: <Vlan::NibbleMask_5> - nibble mask	the queue corresponding to Traffic Class 5. <i>This element is always shown.</i>
traffic-class6	Parameter type: <Vlan::NibbleMask_6> - nibble mask	the queue corresponding to Traffic Class 6. <i>This element is always shown.</i>
traffic-class7	Parameter type: <Vlan::NibbleMask_7> - nibble mask	the queue corresponding to Traffic Class 7. <i>This element is always shown.</i>

107.41 QoS Bandwidth Profile Actuals Command

Command Description

This command displays the QoS Bandwidth profile actual values. The values like eir, cir, air and dt configured by operator are adjusted based on the pon-type to which the profile is attached to.

User Level

The command can be accessed by operators with qos privileges.

Command Syntax

The command has the following syntax:

```
> show qos bandwidth-profile [ (name) [ pon-type <Qos::PonType> ] ]
```

Command Parameters

Table 107.41-1 "QoS Bandwidth Profile Actuals Command" Resource Parameters

Resource Identifier	Type	Description
(name)	Format: Data driven field type Possible values are depending on the actual configuration and software. The currently allowed values can be shown with online-help.	A bandwidth profile name
pon-type	Parameter type: <Qos::PonType> Format: (gpon xgpon ngpon2 25gpon) Possible values: - gpon : gpon type - xgpon : xgpon type - ngpon2 : ngpon2 type - 25gpon : 25gpon type	pon technology

Command Output

Table 107.41-2 "QoS Bandwidth Profile Actuals Command" Display parameters

Specific Information		
name	Type	Description
cfg-excess-info-rate short name: config-eir	Parameter type: <Qos::BwExcessiveInfoRate> - excessive information rate - unit: kbps - range: [0...25000000]	operator configured excessive information rate <i>This element is only shown in detail mode.</i>

name	Type	Description
actl-excess-info-rate short name: actual-eir	Parameter type: <Qos::BwExcessiveInfoRate> - excessive information rate - unit: kbps - range: [0...25000000]	actual excessive information rate <i>This element is always shown.</i>
cfg-commitd-info-rate short name: config-cir	Parameter type: <Qos::CommittedInfoRate> - information rate - unit: kbps - range: [0...2147483647]	operator configured committed information rate <i>This element is only shown in detail mode.</i>
actl-commitd-info-rate short name: actual-cir	Parameter type: <Qos::CommittedInfoRate> - information rate - unit: kbps - range: [0...2147483647]	actual committed information rate <i>This element is always shown.</i>
cfg-assurd-info-rate short name: config-air	Parameter type: <Qos::BwAssuredInfoRate> - assured information rate - unit: kbps - range: [0...25000000]	operator configured assured information rate <i>This element is only shown in detail mode.</i>
actl-assurd-info-rate short name: actual-air	Parameter type: <Qos::BwAssuredInfoRate> - assured information rate - unit: kbps - range: [0...25000000]	actual assured information rate <i>This element is always shown.</i>
cfg-delay-tolerance short name: config-dt	Parameter type: <Qos::DelayTolerance> - delay tolerance - range: [1...240]	operator configured delay tolerance <i>This element is only shown in detail mode.</i>
actl-delay-tolerance short name: actual-dt	Parameter type: <Qos::DelayTolerance> - delay tolerance - range: [1...240]	actual delay tolerance <i>This element is always shown.</i>

108- ARP-RELAY Status Commands

108.1 ARP-RELAY Status Command Tree	108-5409
108.2 ARP-RELAY statistics Status Command	108-5410
108.3 ARP-RELAY summary statistics Status Command	108-5412
108.4 ARP-RELAY detailed statistics Status Command	108-5415

108.1 ARP-RELAY Status Command Tree

Description

This chapter gives an overview of nodes that are handled by "ARP-RELAY Status Commands".

Command Tree

```
----show
  ----arp-relay-stats
    - (user-port)
      ----vlan
        - (subscr-vlan)
          ----summary
          ----extensive
```

108.2 ARP-RELAY statistics Status Command

Command Description

This command displays the detailed and summary ARP-RELAY statistics for static/dynamic VLAN-ports associated to a user interface.

User Level

The command can be accessed by operators with ip privileges.

Command Syntax

The command has the following syntax:

```
> show arp-relay-stats (user-port) vlan [ (subscr-vlan) ]
```

Command Parameters

Table 108.2-1 "ARP-RELAY statistics Status Command" Resource Parameters

Resource Identifier	Type	Description
(user-port)	Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::VpiId> : <Eqpt::VciId> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> / <Eqpt::OntPortId> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / voip <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / vuni <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::LLId> ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / <Eqpt::Ng2OntSlotId> / <Eqpt::Ng2OntPortId> ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / vuni) Possible values: - ng2 : ngpon2 style identification Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId>	identification of the port or virtual channel

Resource Identifier	Type	Description
	- the port number - Field type <Eqpt::VpiId> - atm VPI - Field type <Eqpt::VciId> - atm VCI - Field type <Eqpt::ChannelGroupId> - the channel group identifier - Field type <Eqpt::SubChannelGroupId> - the subchannel group identifier - Field type <Eqpt::PonId> - the PON identifier - Field type <Eqpt::OntId> - the ONT identifier - Field type <Eqpt::Ng2OntId> - the NG2 ONT identifier - Possible values: - voip : virtual uni identifier - obsolete alternative replaced by vuni - vuni : virtual uni identifier - Possible values: - vuni : virtual NGPON2 uni identifier - Field type <Eqpt::OntSlotId> - the ONT SLOT identifier - Field type <Eqpt::OntPortId> - the ONT PORT identifier - Field type <Eqpt::Ng2OntSlotId> - the NGPON2 ONT SLOT identifier - Field type <Eqpt::Ng2OntPortId> - the NGPON2 ONT PORT identifier - Field type <Eqpt::LLId> - the LLID identifier, range 1 for EPON, range 1-8 for DPOE	
(subscr-vlan)	Format: (<Vlan::UVlanIndex> stacked : <Vlan::SVlanIndex> : <Vlan::CVlanIndex>) Possible values: - stacked : stacked vlan identity - Field type <Vlan::UVlanIndex> - unstacked vlan identity - range: [1...4093,4096] - Field type <Vlan::SVlanIndex> - service vlan identity - range: [2...4093] - Field type <Vlan::CVlanIndex> - customer vlan identity - range: [0...4093]	the subscriber vlan id

108.3 ARP-RELAY summary statistics Status Command

Command Description

This command displays the summary ARP-RELAY statistics for static/dynamic VLAN-ports associated to a user interface.

User Level

The command can be accessed by operators with ip privileges.

Command Syntax

The command has the following syntax:

```
> show arp-relay-stats (user-port) vlan (subscr-vlan) summary
```

Command Parameters

Table 108.3-1 "ARP-RELAY summary statistics Status Command" Resource Parameters

Resource Identifier	Type	Description
(user-port)	Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::VpiId> : <Eqpt::VciId> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> / <Eqpt::OntPortId> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / voip <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / vuni <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::LLId> ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / <Eqpt::Ng2OntSlotId> / <Eqpt::Ng2OntPortId> ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / vuni) Possible values: - ng2 : ngpon2 style identification Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number	identification of the port or virtual channel

Resource Identifier	Type	Description
	Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number Field type <Eqpt::VpiId> - atm VPI Field type <Eqpt::Vcild> - atm VCI Field type <Eqpt::ChannelGroupId> - the channel group identifier Field type <Eqpt::SubChannelGroupId> - the subchannel group identifier Field type <Eqpt::PonId> - the PON identifier Field type <Eqpt::OntId> - the ONT identifier Field type <Eqpt::Ng2OntId> - the NG2 ONT identifier Possible values: - voip : virtual uni identifier obsolete alternative replaced by vuni - vuni : virtual uni identifier Possible values: - vuni : virtual NGPON2 uni identifier Field type <Eqpt::OntSlotId> - the ONT SLOT identifier Field type <Eqpt::OntPortId> - the ONT PORT identifier Field type <Eqpt::Ng2OntSlotId> - the NGPON2 ONT SLOT identifier Field type <Eqpt::Ng2OntPortId> - the NGPON2 ONT PORT identifier Field type <Eqpt::LLId> - the LLID identifier, range 1 for EPON, range 1-8 for DPOE	
(subscr-vlan)	Format: (<Vlan::UVlanIndex> stacked : <Vlan::SVlanIndex> : <Vlan::CVlanIndex>) Possible values: - stacked : stacked vlan identity Field type <Vlan::UVlanIndex> - unstacked vlan identity - range: [1...4093,4096] Field type <Vlan::SVlanIndex> - service vlan identity - range: [2...4093] Field type <Vlan::CVlanIndex> - customer vlan identity - range: [0...4093]	the subscriber vlan id

Command Output

Table 108.3-2 "ARP-RELAY summary statistics Status Command" Display parameters

Specific Information		
name	Type	Description
error-summary-ctr	Parameter type: <ArpRelay::Counter> - an unsigned integer	all ARP pkts dropped because of errors

108 ARP-RELAY Status Commands

name	Type	Description
		<i>This element is always shown.</i>
antispoof-disc-ctr	Parameter type: <ArpRelay::Counter> - an unsigned integer	all ARP pkts dropped because of anti-spoofing check failed <i>This element is always shown.</i>

108.4 ARP-RELAY detailed statistics Status

Command

Command Description

This command displays the detailed ARP-RELAY statistics for static/dynamic VLAN-ports associated to a user interface.

User Level

The command can be accessed by operators with ip privileges.

Command Syntax

The command has the following syntax:

> show arp-relay-stats (user-port) vlan (subscr-vlan) extensive

Command Parameters

Table 108.4-1 "ARP-RELAY detailed statistics Status Command" Resource Parameters

Resource Identifier	Type	Description
(user-port)	Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::VpId> : <Eqpt::VcId> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> / <Eqpt::OntPortId> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / voip <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / vuni <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::LLId> ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / <Eqpt::Ng2OntSlotId> / <Eqpt::Ng2OntPortId> ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / vuni) Possible values: - ng2 : ngpon2 style identification Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number	identification of the port or virtual channel

Resource Identifier	Type	Description
	Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number Field type <Eqpt::VpiId> - atm VPI Field type <Eqpt::Vcild> - atm VCI Field type <Eqpt::ChannelGroupId> - the channel group identifier Field type <Eqpt::SubChannelGroupId> - the subchannel group identifier Field type <Eqpt::PonId> - the PON identifier Field type <Eqpt::OntId> - the ONT identifier Field type <Eqpt::Ng2OntId> - the NG2 ONT identifier Possible values: - voip : virtual uni identifier obsolete alternative replaced by vuni - vuni : virtual uni identifier Possible values: - vuni : virtual NGPON2 uni identifier Field type <Eqpt::OntSlotId> - the ONT SLOT identifier Field type <Eqpt::OntPortId> - the ONT PORT identifier Field type <Eqpt::Ng2OntSlotId> - the NGPON2 ONT SLOT identifier Field type <Eqpt::Ng2OntPortId> - the NGPON2 ONT PORT identifier Field type <Eqpt::LLId> - the LLID identifier, range 1 for EPON, range 1-8 for DPOE	
(subscr-vlan)	Format: (<Vlan::UVlanIndex> stacked : <Vlan::SVlanIndex> : <Vlan::CVlanIndex>) Possible values: - stacked : stacked vlan identity Field type <Vlan::UVlanIndex> - unstacked vlan identity - range: [1...4093,4096] Field type <Vlan::SVlanIndex> - service vlan identity - range: [2...4093] Field type <Vlan::CVlanIndex> - customer vlan identity - range: [0...4093]	the subscriber vlan id

Command Output

Table 108.4-2 "ARP-RELAY detailed statistics Status Command" Display parameters

Specific Information		
name	Type	Description
unsupported-hwtype	Parameter type: <ArpRelay::Counter> - an unsigned integer	wrong hardware type in ARP pkt header

name	Type	Description
		<i>This element is always shown.</i>
unsupported-l3proto	Parameter type: <ArpRelay::Counter> - an unsigned integer	wrong protocol type in ARP pkt header <i>This element is always shown.</i>
unsupported-addrlen	Parameter type: <ArpRelay::Counter> - an unsigned integer	wrong adress length in ARP pkt header <i>This element is always shown.</i>
unsupported-probepkt	Parameter type: <ArpRelay::Counter> - an unsigned integer	nbr ARP probe pkts(i.e source ip address all zero's) <i>This element is always shown.</i>
inv-pktlen	Parameter type: <ArpRelay::Counter> - an unsigned integer	invalid ARP pkt length <i>This element is always shown.</i>
inv-opcode	Parameter type: <ArpRelay::Counter> - an unsigned integer	invalid /not supported opcode in ARP pkt <i>This element is always shown.</i>
inv-arpreq-srcmac	Parameter type: <ArpRelay::Counter> - an unsigned integer	invalid source mac addr in ARP request <i>This element is always shown.</i>
inv-arpreq-dstip	Parameter type: <ArpRelay::Counter> - an unsigned integer	invalid target IP addr in ARP request <i>This element is always shown.</i>
inv-arpreq-srcip	Parameter type: <ArpRelay::Counter> - an unsigned integer	invalid source IP addr in ARP request <i>This element is always shown.</i>
inv-arpreply-srcmac	Parameter type: <ArpRelay::Counter> - an unsigned integer	invalid source mac addr in ARP reply <i>This element is always shown.</i>
inv-arpreply-dstip	Parameter type: <ArpRelay::Counter> - an unsigned integer	invalid target IP addr in ARP reply <i>This element is always shown.</i>
inv-arpreply-srcip	Parameter type: <ArpRelay::Counter> - an unsigned integer	invalid target IP addr in ARP request <i>This element is always shown.</i>
arpreq-same-itf	Parameter type: <ArpRelay::Counter> - an unsigned integer	arp-req pkts dropped because sender and target IP addr learnt on same user interface <i>This element is always shown.</i>
arpreq-antispoof	Parameter type: <ArpRelay::Counter> - an unsigned integer	arp-req IP antispoofing check failure <i>This element is always shown.</i>
arpreq-up	Parameter type: <ArpRelay::Counter> - an unsigned integer	nbr upstream arp-request pkts relayed <i>This element is always shown.</i>
arpreq-dn	Parameter type: <ArpRelay::Counter> - an unsigned integer	nbr downstream arp-request pkts relayed <i>This element is always shown.</i>
arpreply-same-itf	Parameter type: <ArpRelay::Counter> - an unsigned integer	arp-req pkts dropped because sender and target IP addr learnt on same user interface <i>This element is always shown.</i>
arpreply-antispoof	Parameter type: <ArpRelay::Counter> - an unsigned integer	arp-reply IP antispoofing check failure <i>This element is always shown.</i>
arpreply-up	Parameter type: <ArpRelay::Counter> - an unsigned integer	nbr upstream arp-reply pkts relayed <i>This element is always shown.</i>

109- xDSL Status Commands

109.1 xDSL Status Command Tree	109-5421
109.2 xDSL Profiles Status Command	109-5425
109.3 xDSL PM Interval Per Interface Status Command	109-5427
109.4 xDSL Operational Data Near End Line Status Command	109-5429
109.5 xDSL Operational Data Near End Channel Status Command	109-5439
109.6 xDSL Operational Data Far End Line Status Command	109-5441
109.7 xDSL Operational Data Far End Channel Status Command	109-5450
109.8 xDSL Operational Data Statistics	109-5452
109.9 xDSL Carrier Data Near End Status Command	109-5458
109.10 xDSL Carrier Data Far End Status Command	109-5464
109.11 xDSL Failure Status Near End Status Command	109-5467
109.12 xDSL Failure Status Far End Status Command	109-5470
109.13 xDSL Vectored Line Failure Status Command	109-5473
109.14 xDSL Vectoring Board Failure Status Command	109-5475
109.15 xDSL Counters Near End Line Current 15 Min	109-5477
109.16 xDSL Counters Near End Line Current Day	109-5480
109.17 xDSL Counters Near End Line Previous 15 Min	109-5483
109.18 xDSL Counters Near End Of Line Previous Day	109-5486
109.19 xDSL Counters Near End Channel Current 15 Min	109-5489
109.20 xDSL Counters Near End Channel Current Day	109-5491
109.21 xDSL Counters Near End Channel Previous 15 Min	109-5493
109.22 xDSL Counters Near End Channel Previous Day	109-5495
109.23 xDSL Counters Far End Line Current 15 Min	109-5497
109.24 xDSL Counters Far End Line Current Day	109-5499
109.25 xDSL Counters Far End Line Previous 15 Min	109-5501
109.26 xDSL Counters Far End Line Previous Day	109-5504
109.27 xDSL Counters Far End Channel Current 15 Min	109-5507
109.28 xDSL Counters Far End Channel Current Day	109-5509
109.29 xDSL Counters Far End Channel Previous 15 Min	109-5511
109.30 xDSL Counters Far End Channel Previous Day	109-5513
109.31 xDSL XTU-R Inventory Status Command	109-5515
109.32 xDSL XTU-C Inventory Status Command	109-5517
109.33 xDSL Board Capability Status Command	109-5519
109.34 xDSL Low Rate Alarm Timestamp Command	109-5525
109.35 xDSL Low Rate Alarm Line Bitmap Status Command	109-5526
109.36 xDSL Low Rate Alarm Linkup Record Data Command	109-5527
109.37 xDSL INS Near End Operational Data Status Command	109-5530
109.38 xDSL INS Near End Current 15Min Data Status Command	109-5532
109.39 xDSL INS Near End Current 15Min IAT Histogram	109-5533
109.40 xDSL INS Near End Current 15Min EINP Histogram	109-5534
109.41 xDSL INS Near End Current Day Data Status Command	109-5535

109.42 xDSL INS Near End Current Day IAT Histogram	109-5536
109.43 xDSL INS Near End Current Day EINP Histogram	109-5537
109.44 xDSL INS Near End Previous 15Min Data Status Command	109-5538
109.45 xDSL INS Near End Previous 15Min IAT Histogram	109-5539
109.46 xDSL INS Near End Previous 15Min EINP Histogram	109-5540
109.47 xDSL INS Near End Previous Day Data Status Command	109-5541
109.48 xDSL INS Near End Previous Day IAT Histogram	109-5542
109.49 xDSL INS Near End Previous Day EINP Histogram	109-5543
109.50 xDSL INS Far End Operational Data Status Command	109-5544
109.51 xDSL INS Far End Current 15Min Data Status Command	109-5546
109.52 xDSL INS Far End Current 15Min IAT Histogram	109-5547
109.53 xDSL INS Far End Current 15Min EINP Histogram	109-5548
109.54 xDSL INS Far End Current Day Data Status Command	109-5549
109.55 xDSL INS Far End Current Day IAT Histogram	109-5550
109.56 xDSL INS Far End Current Day EINP Histogram	109-5551
109.57 xDSL INS Far End Previous 15Min Data Status Command	109-5552
109.58 xDSL INS Far End Previous 15Min IAT Histogram	109-5553
109.59 xDSL INS Far End Previous 15Min EINP Histogram	109-5554
109.60 xDSL INS Far End Previous Day Status Command	109-5555
109.61 xDSL INS Far End Previous Day IAT Histogram	109-5556
109.62 xDSL INS Far End Previous Day EINP Histogram	109-5557
109.63 xDSL Downstream Vectoring Disturberlist Status Command	109-5558
109.64 xDSL Upstream Vectoring Disturberlist Status Command	109-5560
109.65 xDSL Downstream Vectoring Disturberlist Status Command	109-5562
109.66 xDSL Vectoring Carrier Data Near End Status Command	109-5564
109.67 xDSL Vectoring Carrier Data Far End Status Command	109-5567
109.68 xDSL Vectoring Processing Board Status Command	109-5570
109.69 xDSL Vectoring Processing Group Status Command	109-5573

109.1 xDSL Status Command Tree

Description

This chapter gives an overview of nodes that are handled by "xDSL Status Commands".

Command Tree

```

----show
  ----xdsl
    ----profiles
    ----xdsl-int
      - (if-index)
    ----operational-data
      ----near-end
        ----line
          - (if-index)
        ----channel
          - (if-index)
      ----far-end
        ----line
          - (if-index)
        ----channel
          - (if-index)
      ----line
        - (if-index)
    ----carrier-data
      ----near-end
        - (if-index)
      ----far-end
        - (if-index)
    ----failure-status
      ----near-end
        - (if-index)
      ----far-end
        - (if-index)
      ----vect-line-near-end
        - (if-index)
      ----vect-board
        - (board-index)
    ----counters
      ----near-end
        ----line
          ----current-interval
            - (if-index)
          ----current-1day
            - (if-index)
          ----previous-interval
            - (if-index)
            - interval-no
          ----previous-1day
            - (if-index)
            - interval-no
        ----channel

```

- current-interval
 - (if-index)
- current-1day
 - (if-index)
- previous-interval
 - (if-index)
 - interval-no
- previous-1day
 - (if-index)
 - interval-no
- far-end
- line
 - current-interval
 - (if-index)
 - current-1day
 - (if-index)
 - previous-interval
 - (if-index)
 - interval-no
 - previous-1day
 - (if-index)
 - interval-no
- channel
 - current-interval
 - (if-index)
 - current-1day
 - (if-index)
 - previous-interval
 - (if-index)
 - interval-no
 - previous-1day
 - (if-index)
 - interval-no
- cpe-inventory
 - (if-index)
- co-inventory
 - (if-index)
- board
 - (if-index)
- link-up-changes
 - (linkup-timestamp)
- slot
 - (slot)
- linkup-record
 - (line)
- imp-noise-sensor
 - near-end
 - oper-data
 - (if-index)
 - current-interval
 - (if-index)
 - inm-iat-histo
 - (class-interval)
 - inm-equiv-inp-histo
 - (class-interval)
 - current-1day
 - (if-index)
 - inm-iat-histo
 - (class-interval)


```

        ----inm-equiv-inp-histo
            - (class-interval)
    ----previous-interval
        - (if-index)
        ----inm-iat-histo
            - (class-interval)
        ----inm-equiv-inp-histo
            - (class-interval)
    ----previous-1day
        - (if-index)
        ----inm-iat-histo
            - (class-interval)
        ----inm-equiv-inp-histo
            - (class-interval)
    ----far-end
        ----oper-data
            - (if-index)
        ----current-interval
            - (if-index)
            ----inm-iat-histo
                - (class-interval)
            ----inm-equiv-inp-histo
                - (class-interval)
        ----current-1day
            - (if-index)
            ----inm-iat-histo
                - (class-interval)
            ----inm-equiv-inp-histo
                - (class-interval)
        ----previous-interval
            - (if-index)
            ----inm-iat-histo
                - (class-interval)
            ----inm-equiv-inp-histo
                - (class-interval)
        ----previous-1day
            - (if-index)
            ----inm-iat-histo
                - (class-interval)
            ----inm-equiv-inp-histo
                - (class-interval)
    ----X vect-disturbers
        - (victim-line)
        - [no] max-reported-dist
    ----vect-disturber-list
        ----upstream
            - (victim-line)
            - [no] max-reported-dist
        ----downstream
            - (victim-line)
            - [no] max-reported-dist
            - [no] calc-mode
    ----vect-carrier-data
        ----near-end
            - (line)
            - disturber-line
            - [no] vgr-link
            - [no] group-sampling
        ----far-end

```

- **(line)**
- disturber-line
- [no] vgr-link
- [no] group-sampling
- vp-board**
- **(board-index)**
- vp-link
- vect-group**
- **(board-index)**
- vgr-link

109.2 xDSL Profiles Status Command

Command Description

This command displays xDSL profiles.

User Level

The command can be accessed by operators with xdsl privileges.

Command Syntax

The command has the following syntax:

> show xdsl profiles

Command Output

Table 109.2-2 "xDSL Profiles Status Command" Display parameters

Specific Information		
name	Type	Description
next-av-serv-pr	Parameter type: <AsamNextProfileIndex> - a profile index - range: [0...65535]	next available service profile index <i>This element is always shown.</i>
max-serv-pr	Parameter type: <AsamMaxProfileIndex> - a maximum value of a profile index - range: [0...65535]	max number of service profiles that can be created <i>This element is always shown.</i>
next-av-spec-pr	Parameter type: <AsamNextProfileIndex> - a profile index - range: [0...65535]	next available spectrum profile index <i>This element is always shown.</i>
max-spec-pr	Parameter type: <AsamMaxProfileIndex> - a maximum value of a profile index - range: [0...65535]	max number of spectrum profiles that can be created <i>This element is always shown.</i>
next-av-dpbo-pr	Parameter type: <AsamNextProfileIndex> - a profile index - range: [0...65535]	next available dpbo profile index <i>This element is always shown.</i>
max-dpbo-pr	Parameter type: <AsamMaxProfileIndex> - a maximum value of a profile index - range: [0...65535]	max number of dpbo profiles that can be created <i>This element is always shown.</i>
next-av-rtx-pr	Parameter type: <AsamNextProfileIndex> - a profile index - range: [0...65535]	next available rtx profile index <i>This element is always shown.</i>
max-rtx-pr	Parameter type: <AsamMaxProfileIndex> - a maximum value of a profile index - range: [0...65535]	max number of rtx profiles that can be created <i>This element is always shown.</i>
next-av-vect-pr	Parameter type: <AsamNextProfileIndex> - a profile index - range: [0...65535]	next available vectoring profile index <i>This element is always shown.</i>
max-vect-pr	Parameter type: <AsamMaxProfileIndex>	max number of vectoring profiles

109 xDSL Status Commands

name	Type	Description
	- a maximum value of a profile index - range: [0...65535]	that can be created <i>This element is always shown.</i>
next-av-vce-pr	Parameter type: <AsamNextProfileIndex> - a profile index - range: [0...65535]	next available vectoring control entity profile index <i>This element is always shown.</i>
max-vce-pr	Parameter type: <AsamMaxProfileIndex> - a maximum value of a profile index - range: [0...65535]	max number of vectoring control entity profiles that can be created <i>This element is always shown.</i>
next-av-sos-pr	Parameter type: <AsamNextProfileIndex> - a profile index - range: [0...65535]	next available sos profile index <i>This element is always shown.</i>
max-sos-pr	Parameter type: <AsamMaxProfileIndex> - a maximum value of a profile index - range: [0...65535]	max number of sos profiles that can be created <i>This element is always shown.</i>
max-leg-upbo-pr	Parameter type: <AsamMaxProfileIndex> - a maximum value of a profile index - range: [0...65535]	max number of xdsl legacy upbo profiles that can be created <i>This element is always shown.</i>
next-av-leg-upbo-pr	Parameter type: <AsamNextProfileIndex> - a profile index - range: [0...65535]	next available legacy upbo profile index <i>This element is always shown.</i>

109.3 xDSL PM Interval Per Interface Status Command

Command Description

This command displays the number of available pm intervals per xdsl interface.

User Level

The command can be accessed by operators with xdsl privileges.

Command Syntax

The command has the following syntax:

```
> show xdsl xdsl-int [ (if-index) ]
```

Command Parameters

Table 109.3-1 "xDSL PM Interval Per Interface Status Command" Resource Parameters

Resource Identifier	Type	Description
(if-index)	Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number	interface index of the port

Command Output

Table 109.3-2 "xDSL PM Interval Per Interface Status Command" Display parameters

Specific Information		
name	Type	Description
cur-int-elapsetime	Parameter type: <SignedInteger> - a signed integer	nbr of sec elapsed in cur intvl err-measurement <i>This element is always shown.</i>
cur-1day-elapsetime	Parameter type: <SignedInteger> - a signed integer	nbr of sec elapsed in cur one day err-measurement <i>This element is always shown.</i>
valid-intervals	Parameter type: <SignedInteger>	nbr of prev intvl for which valid

109 xDSL Status Commands

name	Type	Description
	- a signed integer	data has been stored <i>This element is always shown.</i>
valid-1days	Parameter type: <SignedInteger> - a signed integer	nbr of prev 1Days for which valid data has been stored <i>This element is always shown.</i>

Only Show Details: global settings		
name	Type	Description
xdsl-coding-type	Parameter type: <Xdsl::Coding> (other dmt cap) Possible values: - other : other type - dmt : DMT type - cap : CAP type	type of modulation technique <i>This element is only shown in detail mode.</i>

109.4 xDSL Operational Data Near End Line Status Command

Command Description

This command displays the xDSL operational data for the near end of line. It displays the XTU-O controlled parameters that can be receiver related or transmitted related.

Note: the applicability of parameters displayed in the command output, depends on the operational mode of the line ADSLx/VDSLx, VDSL2, G.Fast

User Level

The command can be accessed by operators with xdsl privileges.

Command Syntax

The command has the following syntax:

```
> show xdsl operational-data near-end line [ (if-index) ]
```

Command Parameters

Table 109.4-1 "xDSL Operational Data Near End Line Status Command" Resource Parameters

Resource Identifier	Type	Description
(if-index)	Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number	interface index of the port

Command Output

Table 109.4-2 "xDSL Operational Data Near End Line Status Command" Display parameters

Specific Information		
name	Type	Description
rel-cap-occ-up	Parameter type: <Xdsl::CapacityUtil> - utilization of the capacity available - unit: % - range: [0...100]	ratio of actual bitrate over the max attainable bitrate. Only applicable for ADSLx/VDSLx. <i>This element is always shown.</i>

109 xDSL Status Commands

name	Type	Description
noise-margin-up	Parameter type: <Xdsl::NoiseValue> - a noise value - unit: 1/10 dB	current noise margin for the upstream direction. Applicable for all operational modes. For GFast a special value -512 is reported when no data is available. <i>This element is always shown.</i>
output-power-down short name: output-pwr-dn	Parameter type: <Xdsl::OutputPwr> - a power value - unit: 1/10 dBm	actual aggregate output power for the downstream carriers <i>This element is always shown.</i>
sig-attenuation-up short name: sig-attn-up	Parameter type: <Xdsl::SigAttenuation> - an attenuation value - unit: 1/10 dB	diff btw pwr at near-end rx-ver and that tx-ed from far-end. Only applicable for ADSLx/VDSLx. <i>This element is only shown in detail mode.</i>
loop-attenuation-up short name: loop-attn-up	Parameter type: <Xdsl::SigAttenuation> - an attenuation value - unit: 1/10 dB	diff btw pwr at near-end rx-ver and tx-ed from far-end over all sub-carriers. Only applicable for ADSLx/VDSLx. <i>This element is only shown in detail mode.</i>
actual-opmode	Parameter type: <Xdsl::OneOpModeTypeLinePreDef> (ansi-t1413 etsi-dts g992-1-a g992-1-b g992-2-a g992-3-a g992-3-b g992-3-aj g992-3-l1 g992-3-l2 g992-3-am g992-5-a g992-5-b ansi-t1.424 etsi-ts itu-g993-1 ieee-802.3ah g992-5-aj g992-5-am g993-2-8a g993-2-8b g993-2-8c g993-2-8d g993-2-12a g993-2-12b g993-2-17a g993-2-30a g993-2-35b gfast default) Possible values: - ansi-t1413 : ANSI T1.413-1998 - etsi-dts : ETSI DTS/TM06006 - g992-1-a : G.992.1 POTS non-overlapped spectrum - g992-1-b : G.992.1 ISDN non-overlapped spectrum	actual value of the operational mode <i>This element is only shown in detail mode.</i>

name	Type	Description
	- g992-2-a : G.992.2 POTS non-overlapped spectrum - g992-3-a : G.992.2 POTS non-overlapped spectrum - g992-3-b : G.992.3 ISDN non-overlapped spectrum - g992-3-aj : G.992.3 All Digital Mode with non-overlapped spectrum - g992-3-l1 : G.992.3 POTS non-overlapped spectrum US mask 1 - g992-3-l2 : G.992.3 POTS non-overlapped spectrum US mask 2 - g992-3-am : G.992.3 extended POTS with non-overlapped spectrum - g992-5-a : G.992.5 POTS non-overlapped spectrum - g992-5-b : G.992.5 POTS non-overlapped spectrum - ansi-t1.424 : ANSI T1.424 - etsi-ts : ETSI TS - itu-g993-1 : ITU G993-1 - ieee-802.3ah : IEEE 802.3ah - g992-5-aj : G.992.5 All Digital Mode with non-overlapped spectrum - g992-5-am : G.992.5 extended POTS non-overlapped spectrum - g993-2-8a : VDSL-2 with profile 8A - g993-2-8b : VDSL-2 with profile 8B - g993-2-8c : VDSL-2 with profile 8C - g993-2-8d : VDSL-2 with profile 8D - g993-2-12a : VDSL-2 with profile 12A - g993-2-12b : VDSL-2 with profile 12B - g993-2-17a : VDSL-2 with profile 17A - g993-2-30a : VDSL-2 with profile 30A - g993-2-35b : VDSL-2 with profile 35B - gfast : gfast profile - default : default value	
xtu-c-opmode	Parameter type: <Xdsl::OpModeTypeLinePreDef> (ansi-t1413 etsi-dts g992-1-a g992-1-b g992-2-a g992-3-a g992-3-b g992-3-aj g992-3-l1 g992-3-l2 g992-3-am g992-5-a g992-5-b ansi-t1.424 etsi-ts itu-g993-1 ieee-802.3ah g992-5-aj g992-5-am g993-2-8a g993-2-8b g993-2-8c g993-2-8d g993-2-12a	bitmap which represents the operational modes <i>This element is only shown in detail mode.</i>

name	Type	Description
	g993-2-12b g993-2-17a g993-2-30a g993-2-35b gfast default <Xdsl::OpModeType>) Possible values: - ansi-t1413 : ANSI T1.413-1998 - etsi-dts : ETSI DTS/TM06006 - g992-1-a : G.992.1 POTS non-overlapped spectrum - g992-1-b : G.992.1 ISDN non-overlapped spectrum - g992-2-a : G.992.2 POTS non-overlapped spectrum - g992-3-a : G.992.2 POTS non-overlapped spectrum - g992-3-b : G.992.3 ISDN non-overlapped spectrum - g992-3-aj : G.992.3 All Digital Mode with non-overlapped spectrum - g992-3-l1 : G.992.3 POTS non-overlapped spectrum US mask 1 - g992-3-l2 : G.992.3 POTS non-overlapped spectrum US mask 2 - g992-3-am : G.992.3 extended POTS with non-overlapped spectrum - g992-5-a : G.992.5 POTS non-overlapped spectrum - g992-5-b : G.992.5 POTS non-overlapped spectrum - ansi-t1.424 : ANSI T1.424 - etsi-ts : ETSI TS - itu-g993-1 : ITU G993-1 - ieee-802.3ah : IEEE 802.3ah - g992-5-aj : G.992.5 All Digital Mode with non-overlapped spectrum - g992-5-am : G.992.5 extended POTS non-overlapped spectrum - g993-2-8a : VDSL-2 with profile 8A - g993-2-8b : VDSL-2 with profile 8B - g993-2-8c : VDSL-2 with profile 8C - g993-2-8d : VDSL-2 with profile 8D - g993-2-12a : VDSL-2 with profile 12A - g993-2-12b : VDSL-2 with profile 12B - g993-2-17a : VDSL-2 with profile 17A - g993-2-30a : VDSL-2 with profile 30A - g993-2-35b : VDSL-2 with profile 35B - gfast : gfast profile - default : default value Field type <Xdsl::OpModeType> - octet string bitmask defining operational mode - length: 16	
ansi-t1413	Parameter type: <Xdsl::T1413> (dis-ansi-t1413 ansi-t1413) Possible values: - dis-ansi-t1413 : disable ANSI T1.413-1998 - ansi-t1413 : ANSI T1.413-1998	ANSI T1.413-1998 <i>This element is only shown in detail mode.</i>
etsi-dts	Parameter type: <Xdsl::Etsidts> (dis-etsi-dts etsi-dts) Possible values:	ETSI DTS/TM06006 <i>This element is only shown in detail mode.</i>

name	Type	Description
	- dis-etsi-dts : disable ETSI DTS/TM06006 - etsi-dts : ETSI DTS/TM06006	
g992-1-a	Parameter type: <Xdsl::G21potsnos> (dis-g992-1-a g992-1-a) Possible values: - dis-g992-1-a : disable G.992.1 POTS non-overlapped spectrum - g992-1-a : G.992.1 POTS non-overlapped spectrum	G.992.1 POTS non-overlapped spectrum <i>This element is only shown in detail mode.</i>
g992-1-b	Parameter type: <Xdsl::G21isdnnos> (dis-g992-1-b g992-1-b) Possible values: - dis-g992-1-b : disable G.992.1 ISDN non-overlapped spectrum - g992-1-b : G.992.1 ISDN non-overlapped spectrum	G.992.1 ISDN non-overlapped spectrum <i>This element is only shown in detail mode.</i>
g992-2-a	Parameter type: <Xdsl::G22potsnos> (dis-g992-2-a g992-2-a) Possible values: - dis-g992-2-a : disable G.992.2 POTS non-overlapped spectrum - g992-2-a : G.992.2 POTS non-overlapped spectrum	G.992.2 POTS non-overlapped spectrum <i>This element is only shown in detail mode.</i>
g992-3-a	Parameter type: <Xdsl::G23potsnos> (dis-g992-3-a g992-3-a) Possible values: - dis-g992-3-a : disable G.992.3 POTS non-overlapped spectrum - g992-3-a : G.992.3 POTS non-overlapped spectrum	G.992.3 POTS non-overlapped spectrum <i>This element is only shown in detail mode.</i>
g992-3-b	Parameter type: <Xdsl::G23isdnnos> (dis-g992-3-b g992-3-b) Possible values: - dis-g992-3-b : disable G.992.3 ISDN non-overlapped spectrum - g992-3-b : G.992.3 ISDN non-overlapped spectrum	G.992.3 ISDN non-overlapped spectrum <i>This element is only shown in detail mode.</i>
g992-3-aj	Parameter type: <Xdsl::G23AllDigNos> (dis-g992-3-aj g992-3-aj) Possible values: - dis-g992-3-aj : disable G.992.3 all digital mode non-overlapped spectrum - g992-3-aj : G.992.3 all digital mode non-overlapped spectrum	G.992.3 all digital mode non-overlapped spectrum <i>This element is only shown in detail mode.</i>
g992-3-l1	Parameter type: <Xdsl::G23PotsnosUs1> (dis-g992-3-l1 g992-3-l1) Possible values: - dis-g992-3-l1 : disable G.992.3 POTS non-overlapped spectrum US mask 1 - g992-3-l1 : G.992.3 POTS non-overlapped spectrum US mask 1	G.992.3 POTS non-overlapped spectrum US mask 1 <i>This element is only shown in detail mode.</i>
g992-3-l2	Parameter type: <Xdsl::G23PotsNosUs2> (dis-g992-3-l2 g992-3-l2) Possible values:	G.992.3 POTS non-overlapped spectrum US mask 2 <i>This element is only shown in detail mode.</i>

name	Type	Description
	- dis-g992-3-l2 : disable G.992.3 POTS non-overlapped spectrum US mask 2 - g992-3-l2 : G.992.3 POTS non-overlapped spectrum US mask 2	
g992-3-am	Parameter type: <Xdsl::G23ExtPotsNos> (dis-g992-3-am g992-3-am) Possible values: - dis-g992-3-am : disable G.992.3 extended POTS with non-overlapped spectrum - g992-3-am : G.992.3 extended POTS with non-overlapped spectrum	G.992.3 extended POTS with non-overlapped spectrum <i>This element is only shown in detail mode.</i>
g992-5-a	Parameter type: <Xdsl::G25PotsNos> (dis-g992-5-a g992-5-a) Possible values: - dis-g992-5-a : disable G.992.5 POTS non-overlapped spectrum - g992-5-a : G.992.5 POTS non-overlapped spectrum	G.992.5 POTS non-overlapped spectrum <i>This element is only shown in detail mode.</i>
g992-5-b	Parameter type: <Xdsl::G25IsdnNos> (dis-g992-5-b g992-5-b) Possible values: - dis-g992-5-b : disable G.992.5 ISDN non-overlapped spectrum - g992-5-b : G.992.5 ISDN non-overlapped spectrum	G.992.5 ISDN non-overlapped spectrum <i>This element is only shown in detail mode.</i>
ansi-t1.424	Parameter type: <Xdsl::AnsiT1424> (dis-ansi-t1.424 ansi-t1.424) Possible values: - dis-ansi-t1.424 : disable ANSI T1.424 - ansi-t1.424 : ANSI T1.424	ansi T1.424 <i>This element is only shown in detail mode.</i>
etsi-ts	Parameter type: <Xdsl::EtsiTs> (dis-etsi-ts etsi-ts) Possible values: - dis-etsi-ts : disable ETSI TS - etsi-ts : ETSI TS	ETSI TS 101 270 <i>This element is only shown in detail mode.</i>
itu-g993-1	Parameter type: <Xdsl::ItuG9931> (dis-itu-g993-1 itu-g993-1) Possible values: - dis-itu-g993-1 : disable ITU G993-1 - itu-g993-1 : ITU G993-1	ITU G993-1 <i>This element is only shown in detail mode.</i>
ieee-802.3ah	Parameter type: <Xdsl::Ieee802.3Ah> (dis-ieee-802.3ah ieee-802.3ah) Possible values: - dis-ieee-802.3ah : disable IEEE 802.3ah - ieee-802.3ah : IEEE 802.3ah	IEEE 802.3ah <i>This element is only shown in detail mode.</i>
g992-5-aj	Parameter type: <Xdsl::G25AllDigNos> (dis-g992-5-aj g992-5-aj) Possible values: - dis-g992-5-aj : disable G.992.5 all digital mode non-overlapped spectrum - g992-5-aj : G.992.5 all digital mode non-overlapped	G.992.5 all digital mode non-overlapped spectrum <i>This element is only shown in detail mode.</i>

name	Type	Description
	spectrum	
g992-5-am	Parameter type: <Xdsl::G25ExtPotsNos> (dis-g992-5-am g992-5-am) Possible values: - dis-g992-5-am : disable G.992.5 extended POTS non-overlapped spectrum - g992-5-am : G.992.5 extended POTS non-overlapped spectrum	G.992.5 extended POTS non-overlapped spectrum <i>This element is only shown in detail mode.</i>
g993-2-8a	Parameter type: <Xdsl::GProfile8A> (dis-g993-2-8a g993-2-8a) Possible values: - dis-g993-2-8a : disable G.993.2_8A VDSL-2 with profile 8A - g993-2-8a : G.993.2_8A VDSL-2 with profile 8A	VDSL-2 with profile 8A <i>This element is only shown in detail mode.</i>
g993-2-8b	Parameter type: <Xdsl::GProfile8B> (dis-g993-2-8b g993-2-8b) Possible values: - dis-g993-2-8b : disable G.993.2_8B VDSL-2 with profile 8B - g993-2-8b : G.993.2_8B VDSL-2 with profile 8B	VDSL-2 with profile 8B <i>This element is only shown in detail mode.</i>
g993-2-8c	Parameter type: <Xdsl::GProfile8C> (dis-g993-2-8c g993-2-8c) Possible values: - dis-g993-2-8c : disable G.993.2_8C VDSL-2 with profile 8C - g993-2-8c : G.993.2_8C VDSL-2 with profile 8C	VDSL-2 with profile 8C <i>This element is only shown in detail mode.</i>
g993-2-8d	Parameter type: <Xdsl::GProfile8D> (dis-g993-2-8d g993-2-8d) Possible values: - dis-g993-2-8d : disable G.993.2_8D VDSL-2 with profile 8D - g993-2-8d : G.993.2_8D VDSL-2 with profile 8D	VDSL-2 with profile 8D <i>This element is only shown in detail mode.</i>
g993-2-12a	Parameter type: <Xdsl::GProfile12A> (dis-g993-2-12a g993-2-12a) Possible values: - dis-g993-2-12a : disable G.993.2_12A VDSL-2 with profile 12A - g993-2-12a : G.993.2_12A VDSL-2 with profile 12A	VDSL-2 with profile 12A <i>This element is only shown in detail mode.</i>
g993-2-12b	Parameter type: <Xdsl::GProfile12B> (dis-g993-2-12b g993-2-12b) Possible values: - dis-g993-2-12b : disable G.993.2_12B VDSL-2 with profile 12B - g993-2-12b : G.993.2_12B VDSL-2 with profile 12B	VDSL-2 with profile 12B <i>This element is only shown in detail mode.</i>
g993-2-17a	Parameter type: <Xdsl::GProfile17A> (dis-g993-2-17a g993-2-17a) Possible values: - dis-g993-2-17a : disable G.993.2_17A VDSL-2 with profile 17A	VDSL-2 with profile 17A <i>This element is only shown in detail mode.</i>

name	Type	Description
	- g993-2-17a : G.993.2_17A VDSL-2 with profile 17A	
g993-2-30a	Parameter type: <Xdsl::GProfile30A> (dis-g993-2-30a g993-2-30a) Possible values: - dis-g993-2-30a : disable G.993.2_30A VDSL-2 with profile 30A - g993-2-30a : G.993.2_30A VDSL-2 with profile 30A	VDSL-2 with profile 30A <i>This element is only shown in detail mode.</i>
g993-2-35b	Parameter type: <Xdsl::GProfile35B> (dis-g993-2-35b g993-2-35b) Possible values: - dis-g993-2-35b : disable G.993.2_35B VDSL-2 with profile 35B - g993-2-35b : G.993.2_35B VDSL-2 with profile 35B	VDSL-2 with profile 35B <i>This element is only shown in detail mode.</i>
actual-psd-down short name: act-psd-dn	Parameter type: <Xdsl::SignedIntegerDBHZ> - a power spectral density value - unit: 1/10 dBm/Hz	avg transmit power spectrum density over used carriers. Only applicable for ADSLx/VDSLx. <i>This element is always shown.</i>
power-mgnt-state short name: pwr-mgnt	Parameter type: <Xdsl::PowerMgtState> (10 12 13) Possible values: - 10 : full transmission - 12 : downstream net data rate is reduced - 13 : no transmission	actual power management state of the line <i>This element is always shown.</i>
per-bnd-lp-att-up	Parameter type: <Xdsl::PerBandOperDataType> - printable string - length: 10	loop attenuation for each upstream band in case of VDSL2 <i>This element is only shown in detail mode.</i>
pr-bnd-sgn-att-up	Parameter type: <Xdsl::PerBandOperDataType> - printable string - length: 10	signal attenuation for each upstream band in case of VDSL2 <i>This element is only shown in detail mode.</i>
pr-bnd-nois-mg-up	Parameter type: <Xdsl::PerBandOperDataType> - printable string - length: 10	noise margin for each upstream band in case of VDSL2 <i>This element is only shown in detail mode.</i>
high-freq-up	Parameter type: <Xdsl::HighFreqType> - a frequency - unit: kHz	highest carrier frequency used in the upstream direction in case of VDSL2 and G.Fast <i>This element is only shown in detail mode.</i>
elect-length	Parameter type: <Xdsl::ElectrLengthType> - Electrical length. When ELE-M1 is used, value 255 specifies that this parameter is not supported. - unit: 1/2 * dB @ 1MHz - range: [0...255]	Line Electrical Length actually used by XTU-C when mode is VDSL2. <i>This element is only shown in detail mode.</i>
time-adv-corr	Parameter type: <Xdsl::TimingAdvanceType> - a time value - unit: ns * 10 - range: [-25000...25000]	the timing advance of transmitted symbol with respect to the received symbol when mode is VDSL2 <i>This element is only shown in detail mode.</i>
actual-tps-tc-mode	Parameter type: <Xdsl::ActualTpsTcMode> (no-value	actual transfer mode <i>This element is only shown in</i>

name	Type	Description
	atm ptm system-default) Possible values: - no-value : no value - atm : atm mode - ptm : ptm mode - system-default : determined by the system, based on board type	detail mode.
actual-ra-mode-up	Parameter type: <Xdsl::ActualRaMode> (no-value operator-ctrlld automatic dynamic sos-dynamic) Possible values: - no-value : not supported - operator-ctrlld : operatorControlledRateAdaptive - automatic : automaticRateAdaptiveAtStartup - dynamic : dynamicRateAdaptive - sos-dynamic : dynamic rate adaptive mode with SOS	actual ra mode for upstream. Only applicable for ADSLx/VDSLx <i>This element is only shown in detail mode.</i>
vect-cpe-type	Parameter type: <Xdsl::ActualVectCpeType> (gvector gvect-friendly gvect-friendly-dn legacy unknown) Possible values: - gvector : g.vector capable cpe type - gvect-friendly : full vector friendly cpe type (downstream/upstream) - gvect-friendly-dn : vector friendly cpe type downstream - legacy : legacy cpe type - unknown : unknown,not supported cpe type	actual operating mode of the cpe connected to the line in case of VDSL2. <i>This element is only shown in detail mode.</i>
vect-fallback	Parameter type: <Xdsl::ActualVectFallbackState> ((normal-mode normal) (fallback-mode fallback)) Possible values: - normal-mode : line is operating using normal profiles - normal : line is operating using normal profiles - fallback-mode : line is operating using vectoring fallback configured profiles - fallback : line is operating using vectoring fallback configured profiles	actual vectoring fallback state of the line in case of VDSL2. <i>This element is only shown in detail mode.</i>
vect-legacy-cancel	Parameter type: <Xdsl::ActualVectLegacyFextCancelMethodDownstream> (no-legacy-fext-cancel method-1 method-2) Possible values: - no-legacy-fext-cancel : crosstalk cancellation of legacy line is disabled - method-1 : method 1 is used to cancel crosstalk of legacy lines into g.vect lines - method-2 : method 2 is used to cancel crosstalk of legacy lines into g.vect lines	method used to cancel crosstalk from legacy VDSL2 lines into g.vect lines. <i>This element is only shown in detail mode.</i>
upbo-aele-mode	Parameter type: <Xdsl::UpboAeleModeUsed>	the actual AELE mode of a line

name	Type	Description
	- the actual electrical length estimation mode used in AeLe Method - range: [0...3]	in case of VDSL2. <i>This element is only shown in detail mode.</i>
upbo-aele-pb-up	Parameter type: <Xdsl::ElectricalLengthTypeUp> - First two octets represent value for band 0 and specifies supported range 0..1280 and 2047. Similarly next two octets represent value for band 1 and so on. Default value 0xFFFF per band specifies that no data is available. - unit: 1/10dB - length: 10	the Line Electrical Length Estimation per band calculated by the XTU-C when mode is VDSL2 <i>This element is only shown in detail mode.</i>
upbo-aele-rx-thrs-up	Parameter type: <Xdsl::UpboAEleRxThrsUp> - the upstream received signal level threshold value used in AELE. This parameter represents an offset from -100 dBm/Hz - unit: dB - range: [-64...0,255]	the upstream received signal level threshold value when mode is VDSL2. Special value 255 is reported when not applicable. <i>This element is only shown in detail mode.</i>
roc-bitrate-impact-up	Parameter type: <Xdsl::RocBitRateKbps> (roc-disabled <Xdsl::BitRateKbps>) Possible values: - roc-disabled : ROC channel for SOS is disabled Field type <Xdsl::BitRateKbps> - Bitrate in kbps - unit: kbps	actual loss of bitrate or ETR due to ROC is active in upstream when mode is VDSL2. Special value -1 is reported when no data available or ROC not active. <i>This element is only shown in detail mode.</i>
actual-inp-roc-up	Parameter type: <Xdsl::ActInpRoc> - actual impulse noise protection for ROC - unit: 1/10 DMT symbols - range: [0...255]	actual impulse noise protection of the ROC in upstream when mode is VDSL2. Special value 255 is reported when no data available or data out-of-range. <i>This element is only shown in detail mode.</i>
actual-snr-m-roc-up	Parameter type: <Xdsl::ActSnrMROC> - actual SNR Margin for ROC - unit: 1/10 dB - range: [-5120,-640...630]	actual SNR Margin of the ROC in upstream when mode is VDSL2. Special value -5120 is reported when no data available or data out-of-range. <i>This element is only shown in detail mode.</i>
vdsl2-lr-support	Parameter type: <Xdsl::LongReachSupportNE> (not-supported supported) Possible values: - not-supported : xtuc does not support vdsl2 lr - supported : xtuc supports vdsl2 lr	Status of long reach support by XTU-C <i>This element is only shown in detail mode.</i>

109.5 xDSL Operational Data Near End Channel Status Command

Command Description

This command displays the xDSL operational data for the near and of line. It displays the XTU-O controlled parameters that can be receiver related or transmitted related.

Note: the applicability of parameters displayed in the command output, depends on the operational mode of the line ADSLx/VDSLx, VDSL2, G.Fast. For G.Fast, RTX is always in use.

User Level

The command can be accessed by operators with xdsl privileges.

Command Syntax

The command has the following syntax:

```
> show xdsl operational-data near-end channel [ (if-index) ]
```

Command Parameters

Table 109.5-1 "xDSL Operational Data Near End Channel Status Command" Resource Parameters

Resource Identifier	Type	Description
(if-index)	Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number	interface index of the port

Command Output

Table 109.5-2 "xDSL Operational Data Near End Channel Status Command" Display parameters

Specific Information		
name	Type	Description
actual-bitrate-up	Parameter type: <Xdsl::SignedIntegerKBPS> - bitrate - unit: kbits/sec	bitrate or expected throughput for upstream fast or interleaved data flow <i>This element is always shown.</i>

name	Type	Description
attain-bitrate-up	Parameter type: <Xdsl::SignedIntegerKBPS> - bitrate - unit: kbits/sec	maximum attainable bit rate or expected throughput the modem can support <i>This element is always shown.</i>
interleave-delay-down	Parameter type: <Xdsl::SignedIntegerMSEC> - milli-second - unit: msec	delay caused by the interleaving and deinterleaving functionality or delay caused by rtx functionality. Only applicable for ADSLx/VDSLx <i>This element is always shown.</i>
imp-noise-prot-down	Parameter type: <Xdsl::SignedIntegerSYMBOL> - impulse noise protection - unit: 1/10 symbols	actual impulse noise protection or actual impulse noise protection against shine when the rtx functionality is in use. Value 2047 for ADSLx/VDSLx and 20470 for G.Fast indicates a reported value equal to or higher than the value. <i>This element is always shown.</i>
net-data-rate-rtx-up	Parameter type: <Xdsl::SignedIntegerKBPS> - bitrate - unit: kbits/sec	actual net data rate in upstream direction <i>This element is only shown in detail mode.</i>
inp-rein-dn	Parameter type: <Xdsl::SignedIntegerSYMBOL> - impulse noise protection - unit: 1/10 symbols	actual impulse noise protection or actual impulse noise protection against rein when the rtx functionality is in use. Special value 255 for ADSLx/VDSLx and 630 for G.Fast indicates a reported value equal to or higher than the special value. <i>This element is only shown in detail mode.</i>
attain-netrate-rtx-up	Parameter type: <Xdsl::SignedIntegerKBPS> - bitrate - unit: kbits/sec	maximum attainable net data rate in upstream direction <i>This element is only shown in detail mode.</i>
prev-bitrate-up	Parameter type: <Xdsl::SignedIntegerKBPS> - bitrate - unit: kbits/sec	previous bit rate in upstream direction. Only applicable for ADSLx/VDSLx <i>This element is only shown in detail mode.</i>
actual-dtusize-up	Parameter type: <Xdsl::DtuSizeUS> - dtu size in units of 1/10000 symbols - range: [0,2500...40000]	actual dtu size in upstream direction <i>This element is only shown in detail mode.</i>

109.6 xDSL Operational Data Far End Line Status Command

Command Description

This command displays the xDSL operational data for the line far end. It displays the XTU-R controlled parameters that can be receiver related or transmitted related.

Note: the applicability of parameters displayed in the command output, depends on the operational mode of the line ADSLx/VDSLx, VDSL2, G.Fast

User Level

The command can be accessed by operators with xdsl privileges.

Command Syntax

The command has the following syntax:

```
> show xdsl operational-data far-end line [ (if-index) ]
```

Command Parameters

Table 109.6-1 "xDSL Operational Data Far End Line Status Command" Resource Parameters

Resource Identifier	Type	Description
(if-index)	Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number	interface index of the port

Command Output

Table 109.6-2 "xDSL Operational Data Far End Line Status Command" Display parameters

Specific Information		
name	Type	Description
rel-cap-occ-down	Parameter type: <Xdsl::CapacityUtil> - utilization of the capacity available - unit: % - range: [0...100]	ratio of actual bitrate over the max attainable bitrate. Only applicable for ADSLx/VDSLx. <i>This element is always shown.</i>

109 xDSL Status Commands

name	Type	Description
noise-margin-down	Parameter type: <Xdsl::NoiseValue> - a noise value - unit: 1/10 dB	current noise margin for the downstream direction. Applicable for all operational modes. For G.Fast, -512 is reported when no data is available. <i>This element is always shown.</i>
output-power-up	Parameter type: <Xdsl::OutputPwr> - a power value - unit: 1/10 dBm	actual aggregate output power for the upstream carriers <i>This element is always shown.</i>
sig-attenuation-down short name: sig-attn-dn	Parameter type: <Xdsl::SigAttenuation> - an attenuation value - unit: 1/10 dB	diff btw pwr at far-end rx-ver and tx-ed from near-end. Only applicable for ADSLx/VDSLx. <i>This element is only shown in detail mode.</i>
loop-attenuation-down short name: loop-attn-dn	Parameter type: <Xdsl::SigAttenuation> - an attenuation value - unit: 1/10 dB	diff btw pwr at far-end rx-ver and tx-ed from near-end over all sub-carriers. Only applicable for ADSLx/VDSLx. <i>This element is only shown in detail mode.</i>
xtu-r-opmode	Parameter type: <Xdsl::OpModeTypeLinePreDef> (ansi-t1413 etsi-dts g992-1-a g992-1-b g992-2-a g992-3-a g992-3-b g992-3-aj g992-3-l1 g992-3-l2 g992-3-am g992-5-a g992-5-b ansi-t1.424 etsi-ts itu-g993-1 ieee-802.3ah g992-5-aj g992-5-am g993-2-8a g993-2-8b g993-2-8c g993-2-8d g993-2-12a g993-2-12b g993-2-17a g993-2-30a g993-2-35b gfast default <Xdsl::OpModeType>) Possible values: - ansi-t1413 : ANSI T1.413-1998 - etsi-dts : ETSI DTS/TM06006 - g992-1-a : G.992.1 POTS non-overlapped spectrum - g992-1-b : G.992.1 ISDN non-overlapped spectrum	bitmap which represents the operational modes <i>This element is only shown in detail mode.</i>

name	Type	Description
	- g992-2-a : G.992.2 POTS non-overlapped spectrum - g992-3-a : G.992.2 POTS non-overlapped spectrum - g992-3-b : G.992.3 ISDN non-overlapped spectrum - g992-3-aj : G.992.3 All Digital Mode with non-overlapped spectrum - g992-3-l1 : G.992.3 POTS non-overlapped spectrum US mask 1 - g992-3-l2 : G.992.3 POTS non-overlapped spectrum US mask 2 - g992-3-am : G.992.3 extended POTS with non-overlapped spectrum - g992-5-a : G.992.5 POTS non-overlapped spectrum - g992-5-b : G.992.5 POTS non-overlapped spectrum - ansi-t1.424 : ANSI T1.424 - etsi-ts : ETSI TS - itu-g993-1 : ITU G993-1 - ieee-802.3ah : IEEE 802.3ah - g992-5-aj : G.992.5 All Digital Mode with non-overlapped spectrum - g992-5-am : G.992.5 extended POTS non-overlapped spectrum - g993-2-8a : VDSL-2 with profile 8A - g993-2-8b : VDSL-2 with profile 8B - g993-2-8c : VDSL-2 with profile 8C - g993-2-8d : VDSL-2 with profile 8D - g993-2-12a : VDSL-2 with profile 12A - g993-2-12b : VDSL-2 with profile 12B - g993-2-17a : VDSL-2 with profile 17A - g993-2-30a : VDSL-2 with profile 30A - g993-2-35b : VDSL-2 with profile 35B - gfast : gfast profile - default : default value Field type <Xdsl::OpModeType> - octet string bitmask defining operational mode - length: 16	
ansi-t1413	Parameter type: <Xdsl::T1413> (dis-ansi-t1413 ansi-t1413) Possible values: - dis-ansi-t1413 : disable ANSI T1.413-1998 - ansi-t1413 : ANSI T1.413-1998	ANSI T1.413-1998 <i>This element is only shown in detail mode.</i>
etsi-dts	Parameter type: <Xdsl::Etsids> (dis-etsi-dts etsi-dts) Possible values: - dis-etsi-dts : disable ETSI DTS/TM06006 - etsi-dts : ETSI DTS/TM06006	ETSI DTS/TM06006 <i>This element is only shown in detail mode.</i>
g992-1-a	Parameter type: <Xdsl::G21potsnos> (dis-g992-1-a g992-1-a) Possible values: - dis-g992-1-a : disable G.992.1 POTS non-overlapped spectrum - g992-1-a : G.992.1 POTS non-overlapped spectrum	G.992.1 POTS non-overlapped spectrum <i>This element is only shown in detail mode.</i>
g992-1-b	Parameter type: <Xdsl::G21isdnnos> (dis-g992-1-b g992-1-b)	G.992.1 ISDN non-overlapped spectrum <i>This element is only shown in</i>

name	Type	Description
	Possible values: - dis-g992-1-b : disable G.992.1 ISDN non-overlapped spectrum - g992-1-b : G.992.1 ISDN non-overlapped spectrum	<i>detail mode.</i>
g992-2-a	Parameter type: <Xdsl::G22potsnos> (dis-g992-2-a g992-2-a) Possible values: - dis-g992-2-a : disable G.992.2 POTS non-overlapped spectrum - g992-2-a : G.992.2 POTS non-overlapped spectrum	G.992.2 POTS non-overlapped spectrum <i>This element is only shown in detail mode.</i>
g992-3-a	Parameter type: <Xdsl::G23potsnos> (dis-g992-3-a g992-3-a) Possible values: - dis-g992-3-a : disable G.992.3 POTS non-overlapped spectrum - g992-3-a : G.992.3 POTS non-overlapped spectrum	G.992.3 POTS non-overlapped spectrum <i>This element is only shown in detail mode.</i>
g992-3-b	Parameter type: <Xdsl::G23isdnnos> (dis-g992-3-b g992-3-b) Possible values: - dis-g992-3-b : disable G.992.3 ISDN non-overlapped spectrum - g992-3-b : G.992.3 ISDN non-overlapped spectrum	G.992.3 ISDN non-overlapped spectrum <i>This element is only shown in detail mode.</i>
g992-3-aj	Parameter type: <Xdsl::G23AllDigNos> (dis-g992-3-aj g992-3-aj) Possible values: - dis-g992-3-aj : disable G.992.3 all digital mode non-overlapped spectrum - g992-3-aj : G.992.3 all digital mode non-overlapped spectrum	G.992.3 all digital mode non-overlapped spectrum <i>This element is only shown in detail mode.</i>
g992-3-l1	Parameter type: <Xdsl::G23PotsnosUs1> (dis-g992-3-l1 g992-3-l1) Possible values: - dis-g992-3-l1 : disable G.992.3 POTS non-overlapped spectrum US mask 1 - g992-3-l1 : G.992.3 POTS non-overlapped spectrum US mask 1	G.992.3 POTS non-overlapped spectrum US mask 1 <i>This element is only shown in detail mode.</i>
g992-3-l2	Parameter type: <Xdsl::G23PotsNosUs2> (dis-g992-3-l2 g992-3-l2) Possible values: - dis-g992-3-l2 : disable G.992.3 POTS non-overlapped spectrum US mask 2 - g992-3-l2 : G.992.3 POTS non-overlapped spectrum US mask 2	G.992.3 POTS non-overlapped spectrum US mask 2 <i>This element is only shown in detail mode.</i>
g992-3-am	Parameter type: <Xdsl::G23ExtPotsNos> (dis-g992-3-am g992-3-am) Possible values: - dis-g992-3-am : disable G.992.3 extended POTS with non-overlapped spectrum - g992-3-am : G.992.3 extended POTS with non-overlapped spectrum	G.992.3 extended POTS with non-overlapped spectrum <i>This element is only shown in detail mode.</i>

name	Type	Description
g992-5-a	Parameter type: <Xdsl::G25PotsNos> (dis-g992-5-a g992-5-a) Possible values: - dis-g992-5-a : disable G.992.5 POTS non-overlapped spectrum - g992-5-a : G.992.5 POTS non-overlapped spectrum	G.992.5 POTS non-overlapped spectrum <i>This element is only shown in detail mode.</i>
g992-5-b	Parameter type: <Xdsl::G25IsdnNos> (dis-g992-5-b g992-5-b) Possible values: - dis-g992-5-b : disable G.992.5 ISDN non-overlapped spectrum - g992-5-b : G.992.5 ISDN non-overlapped spectrum	G.992.5 ISDN non-overlapped spectrum <i>This element is only shown in detail mode.</i>
ansi-t1.424	Parameter type: <Xdsl::AnsiT1424> (dis-ansi-t1.424 ansi-t1.424) Possible values: - dis-ansi-t1.424 : disable ANSI T1.424 - ansi-t1.424 : ANSI T1.424	ansi T1.424 <i>This element is only shown in detail mode.</i>
etsi-ts	Parameter type: <Xdsl::EtsiTs> (dis-etsi-ts etsi-ts) Possible values: - dis-etsi-ts : disable ETSI TS - etsi-ts : ETSI TS	ETSI TS 101 270 <i>This element is only shown in detail mode.</i>
itu-g993-1	Parameter type: <Xdsl::ItuG9931> (dis-itu-g993-1 itu-g993-1) Possible values: - dis-itu-g993-1 : disable ITU G993-1 - itu-g993-1 : ITU G993-1	ITU G993-1 <i>This element is only shown in detail mode.</i>
ieee-802.3ah	Parameter type: <Xdsl::Ieee802.3Ah> (dis-ieee-802.3ah ieee-802.3ah) Possible values: - dis-ieee-802.3ah : disable IEEE 802.3ah - ieee-802.3ah : IEEE 802.3ah	IEEE 802.3ah <i>This element is only shown in detail mode.</i>
g992-5-aj	Parameter type: <Xdsl::G25AllDigNos> (dis-g992-5-aj g992-5-aj) Possible values: - dis-g992-5-aj : disable G.992.5 all digital mode non-overlapped spectrum - g992-5-aj : G.992.5 all digital mode non-overlapped spectrum	G.992.5 all digital mode non-overlapped spectrum <i>This element is only shown in detail mode.</i>
g992-5-am	Parameter type: <Xdsl::G25ExtPotsNos> (dis-g992-5-am g992-5-am) Possible values: - dis-g992-5-am : disable G.992.5 extended POTS non-overlapped spectrum - g992-5-am : G.992.5 extended POTS non-overlapped spectrum	G.992.5 extended POTS non-overlapped spectrum <i>This element is only shown in detail mode.</i>
g993-2-8a	Parameter type: <Xdsl::GProfile8A> (dis-g993-2-8a g993-2-8a)	VDSL-2 with profile 8A <i>This element is only shown in detail mode.</i>

109 xDSL Status Commands

name	Type	Description
	Possible values: - dis-g993-2-8a : disable G.993.2_8A VDSL-2 with profile 8A - g993-2-8a : G.993.2_8A VDSL-2 with profile 8A	
g993-2-8b	Parameter type: <Xdsl::GProfile8B> (dis-g993-2-8b g993-2-8b) Possible values: - dis-g993-2-8b : disable G.993.2_8B VDSL-2 with profile 8B - g993-2-8b : G.993.2_8B VDSL-2 with profile 8B	VDSL-2 with profile 8B <i>This element is only shown in detail mode.</i>
g993-2-8c	Parameter type: <Xdsl::GProfile8C> (dis-g993-2-8c g993-2-8c) Possible values: - dis-g993-2-8c : disable G.993.2_8C VDSL-2 with profile 8C - g993-2-8c : G.993.2_8C VDSL-2 with profile 8C	VDSL-2 with profile 8C <i>This element is only shown in detail mode.</i>
g993-2-8d	Parameter type: <Xdsl::GProfile8D> (dis-g993-2-8d g993-2-8d) Possible values: - dis-g993-2-8d : disable G.993.2_8D VDSL-2 with profile 8D - g993-2-8d : G.993.2_8D VDSL-2 with profile 8D	VDSL-2 with profile 8D <i>This element is only shown in detail mode.</i>
g993-2-12a	Parameter type: <Xdsl::GProfile12A> (dis-g993-2-12a g993-2-12a) Possible values: - dis-g993-2-12a : disable G.993.2_12A VDSL-2 with profile 12A - g993-2-12a : G.993.2_12A VDSL-2 with profile 12A	VDSL-2 with profile 12A <i>This element is only shown in detail mode.</i>
g993-2-12b	Parameter type: <Xdsl::GProfile12B> (dis-g993-2-12b g993-2-12b) Possible values: - dis-g993-2-12b : disable G.993.2_12B VDSL-2 with profile 12B - g993-2-12b : G.993.2_12B VDSL-2 with profile 12B	VDSL-2 with profile 12B <i>This element is only shown in detail mode.</i>
g993-2-17a	Parameter type: <Xdsl::GProfile17A> (dis-g993-2-17a g993-2-17a) Possible values: - dis-g993-2-17a : disable G.993.2_17A VDSL-2 with profile 17A - g993-2-17a : G.993.2_17A VDSL-2 with profile 17A	VDSL-2 with profile 17A <i>This element is only shown in detail mode.</i>
g993-2-30a	Parameter type: <Xdsl::GProfile30A> (dis-g993-2-30a g993-2-30a) Possible values: - dis-g993-2-30a : disable G.993.2_30A VDSL-2 with profile 30A - g993-2-30a : G.993.2_30A VDSL-2 with profile 30A	VDSL-2 with profile 30A <i>This element is only shown in detail mode.</i>
g993-2-35b	Parameter type: <Xdsl::GProfile35B> (dis-g993-2-35b g993-2-35b) Possible values:	VDSL-2 with profile 35B <i>This element is only shown in detail mode.</i>

name	Type	Description
	- dis-g993-2-35b : disable G.993.2_35B VDSL-2 with profile 35B - g993-2-35b : G.993.2_35B VDSL-2 with profile 35B	
actual-psd-up	Parameter type: <Xdsl::SignedIntegerDBHZ> - a power spectral density value - unit: 1/10 dBm/Hz	avg transmit power spectrum density over used carriers. Only applicable for ADSLx/VDSLx. <i>This element is always shown.</i>
pr-bnd-lp-att-dn	Parameter type: <Xdsl::PerBandOperDataType> - printable string - length: 10	loop attenuation for each downstream band in case of VDSL2 <i>This element is only shown in detail mode.</i>
pr-bnd-sig-att-dn	Parameter type: <Xdsl::PerBandOperDataType> - printable string - length: 10	loop attenuation for each downstream band in case of VDSL2 <i>This element is only shown in detail mode.</i>
pr-bnd-nmgn-dn	Parameter type: <Xdsl::PerBandOperDataType> - printable string - length: 10	loop attenuation for each downstream band in case of VDSL2 <i>This element is only shown in detail mode.</i>
elect-length-est	Parameter type: <Xdsl::ElectrLengthType> - Electrical length. When ELE-M1 is used, value 255 specifies that this parameter is not supported. - unit: 1/2 * dB @ 1MHz - range: [0...255]	Line Electrical Length actually estimated by XTU-R when mode is VDSL2 <i>This element is only shown in detail mode.</i>
time-adv-prp	Parameter type: <Xdsl::TimingAdvanceType> - a time value - unit: ns * 10 - range: [-25000...25000]	the timing advance of transmitted symbol with respect to the received symbol when mode is VDSL2 <i>This element is only shown in detail mode.</i>
high-freq-dn	Parameter type: <Xdsl::HighFreqType> - a frequency - unit: kHz	highest carrier frequency used in the downstream direction in case of VDSL2 and G.Fast <i>This element is only shown in detail mode.</i>
actual-ra-mode-dn	Parameter type: <Xdsl::ActualRaMode> (no-value operator-ctrlld automatic dynamic sos-dynamic) Possible values: - no-value : not supported - operator-ctrlld : operatorControlledRateAdaptive - automatic : automaticRateAdaptiveAtStartup - dynamic : dynamicRateAdaptive - sos-dynamic : dynamic rate adaptive mode with SOS	actual ra mode for downstream. Only applicable for ADSLx/VDSLx <i>This element is only shown in detail mode.</i>
cpecap-recvd	Parameter type: <Xdsl::VectCpeReceived> (no yes yes yes yes yes	vectoring CPE capabilities are received from the CPE. "no" is reported in case of G.Fast. <i>This element is only shown in detail mode.</i>

name	Type	Description
	yes yes yes yes yes yes yes yes yes yes) Possible values: - no : Vectoring Cpe Capabilities are not reported - yes : Vectoring Cpe Capabilities are reported - yes : Vectoring Cpe Capabilities are reported - yes : Vectoring Cpe Capabilities are reported - yes : Vectoring Cpe Capabilities are reported - yes : Vectoring Cpe Capabilities are reported - yes : Vectoring Cpe Capabilities are reported - yes : Vectoring Cpe Capabilities are reported - yes : Vectoring Cpe Capabilities are reported - yes : Vectoring Cpe Capabilities are reported - yes : Vectoring Cpe Capabilities are reported - yes : Vectoring Cpe Capabilities are reported - yes : Vectoring Cpe Capabilities are reported - yes : Vectoring Cpe Capabilities are reported - yes : Vectoring Cpe Capabilities are reported - yes : Vectoring Cpe Capabilities are reported - yes : Vectoring Cpe Capabilities are reported	
cpecap-gvector	Parameter type: <Xdsl::GvectorCpeShow> (no yes) Possible values: - no : not g.vector capable cpe - yes : g.vector capable cpe	g.vector capable cpe <i>This element is only shown in detail mode.</i>
cpecap-gvect-friendly	Parameter type: <Xdsl::FullVectFriendlyCpeShow> (no yes) Possible values: - no : no full vector friendly (dn/up) cpe - yes : full vector friendly (dn/up) cpe	full g.vector friendly cpe <i>This element is only shown in detail mode.</i>
cpecap-gvect-friend-dn	Parameter type: <Xdsl::VectFriendlyCpeShow> (no yes) Possible values: - no : not vector friendly downstream cpe - yes : vector friendly downstream cpe	g.vector friendly downstream cpe <i>This element is only shown in detail mode.</i>
cpecap-legacy	Parameter type: <Xdsl::LegacyCpeShow> (no yes) Possible values: - no : no legacy cpe - yes : legacy cpe	legacy cpe <i>This element is only shown in detail mode.</i>
upbo-aele-pb-dn	Parameter type: <Xdsl::ElectricalLengthTypeDn> - First two octets represent value for band 0 and specifies supported range 0..1280 and 2047. Similarly next two octets represent value for band 1 and so on. Default value 0xFFFF per band specifies that no data is available. - unit: 1/10dB	the Line Electrical Length Estimation per band calculated by the XTU-R when mode is VDSL2 <i>This element is only shown in detail mode.</i>

name	Type	Description
	- length: 10	
upbo-aele-rx-thrs-dn	Parameter type: <Xdsl::UpboAEleRxThrsDn> - the downstream received signal level threshold value used in AELE. This parameter represents an offset from -100 dBm/Hz - unit: dB - range: [-64...0,255]	the downstream received signal level threshold value when mode is VDSL2. Special value 255 is reported when not applicable. <i>This element is only shown in detail mode.</i>
roc-bitrate-impact-dn	Parameter type: <Xdsl::RocBitRateKbps> (roc-disabled <Xdsl::BitRateKbps>) Possible values: - roc-disabled : ROC channel for SOS is disabled Field type <Xdsl::BitRateKbps> - Bitrate in kbps - unit: kbps	actual loss of bitrate or ETR due to ROC is active in downstream when mode is VDSL2. Special value -1 is reported when no data available or ROC not active. <i>This element is only shown in detail mode.</i>
actual-inp-roc-dn	Parameter type: <Xdsl::ActInpRoc> - actual impulse noise protection for ROC - unit: 1/10 DMT symbols - range: [0...255]	actual impulse noise protection of the ROC in downstream when mode is VDSL2. Special value 255 is reported when no data available or data out-of-range. <i>This element is only shown in detail mode.</i>
actual-snr-m-roc-dn	Parameter type: <Xdsl::ActSnrMroc> - actual SNR Margin for ROC - unit: 1/10 dB - range: [-5120,-640...630]	actual SNR Margin of the ROC in downstream when mode is VDSL2. Special value -5120 is reported when no data available or data out-of-range. <i>This element is only shown in detail mode.</i>
vdsl2-lr-support	Parameter type: <Xdsl::LongReachSupportFE> (not-supported supported) Possible values: - not-supported : xtur does not support vdsl2 lr - supported : xtur supports vdsl2 lr	Status of long reach support by XTU-R <i>This element is only shown in detail mode.</i>
vdsl2-cpecap-fdps	Parameter type: <Xdsl::Vdsl2FdpsSupportFE> (not-supported supported) Possible values: - not-supported : xtur does not support fdps - supported : xtur supports fdps	Status of vdsl2 fdps support by XTU-R <i>This element is only shown in detail mode.</i>

109.7 xDSL Operational Data Far End Channel Status Command

Command Description

This command displays the xDSL operational data for the far end of the channel. It displays the XTU-R controlled parameters that can be receiver related or transmitted related.

Note: the applicability of parameters displayed in the command output, depends on the operational mode of the line ADSLx/VDSLx, VDSL2, G.Fast. For G.Fast, RTX is always in use.

User Level

The command can be accessed by operators with xdsl privileges.

Command Syntax

The command has the following syntax:

```
> show xdsl operational-data far-end channel [ (if-index) ]
```

Command Parameters

Table 109.7-1 "xDSL Operational Data Far End Channel Status Command" Resource Parameters

Resource Identifier	Type	Description
(if-index)	Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number	interface index of the port

Command Output

Table 109.7-2 "xDSL Operational Data Far End Channel Status Command" Display parameters

Specific Information		
name	Type	Description
actual-bitrate-down short name: act-br-down	Parameter type: <Xdsl::SignedIntegerKBPS> - bitrate - unit: kbits/sec	bitrate or expected throughput for downstream fast or interleaved data flow <i>This element is always shown.</i>

name	Type	Description
attain-bitrate-down short name: att-br-down	Parameter type: <Xdsl::SignedIntegerKBPS> - bitrate - unit: kbits/sec	maximum attainable bit rate or expected throughput the modem can support <i>This element is always shown.</i>
interleave-delay-up	Parameter type: <Xdsl::SignedIntegerMSEC> - milli-second - unit: msec	delay caused by the interleaving and deinterleaving functionality or delay caused by rtx functionality. Only applicable for ADSLx/VDSLx <i>This element is always shown.</i>
imp-noise-prot-up	Parameter type: <Xdsl::SignedIntegerSYMBOL> - impulse noise protection - unit: 1/10 symbols	actual impulse noise protection or actual impulse noise protection against shine when the rtx functionality is in use. Value 2047 for ADSLx/VDSLx and 20470 for G.Fast indicates a reported value equal to or higher than the value. <i>This element is always shown.</i>
act-l2-bitrt-down short name: act-l2-br-dn	Parameter type: <Xdsl::SignedIntegerKBPS> - bitrate - unit: kbits/sec	actual L2 bitrate when in L2 state. Only applicable for ADSLx/VDSLx <i>This element is always shown.</i>
net-data-rate-rtx-dn	Parameter type: <Xdsl::SignedIntegerKBPS> - bitrate - unit: kbits/sec	actual net data rate in downstream direction <i>This element is only shown in detail mode.</i>
inp-rein-up	Parameter type: <Xdsl::SignedIntegerSYMBOL> - impulse noise protection - unit: 1/10 symbols	actual impulse noise protection or actual impulse noise protection against rein when the rtx functionality is in use. Special value 255 for ADSLx/VDSLx and 630 for G.Fast indicates a reported value equal to or higher than the special value. <i>This element is only shown in detail mode.</i>
attain-netrate-rtx-dn	Parameter type: <Xdsl::SignedIntegerKBPS> - bitrate - unit: kbits/sec	maximum attainable net data rate in downstream direction <i>This element is only shown in detail mode.</i>
prev-bitrate-dw	Parameter type: <Xdsl::SignedIntegerKBPS> - bitrate - unit: kbits/sec	previous bit rate in downstream direction. Only applicable for ADSLx/VDSLx <i>This element is only shown in detail mode.</i>
actual-dtusize-down	Parameter type: <Xdsl::DtuSizeDS> - dtu size in units of 1/10000 symbols - range: [0,2500...40000]	actual dtu size in downstream direction <i>This element is only shown in detail mode.</i>

109.8 xDSL Operational Data Statistics

Command Description

This command displays the xDSL operational data statistics.

User Level

The command can be accessed by operators with xdsl privileges.

Command Syntax

The command has the following syntax:

```
> show xdsl operational-data line [ (if-index) ]
```

Command Parameters

Table 109.8-1 "xDSL Operational Data Statistics" Resource Parameters

Resource Identifier	Type	Description
(if-index)	Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number	interface index of the port

Command Output

Table 109.8-2 "xDSL Operational Data Statistics" Display parameters

Specific Information		
name	Type	Description
adm-state	Parameter type: <Itf::ifAdminStatus> (not-appl up down testing) Possible values: - not-appl : not-applicable - up : admin status is up - down : admin status is down - testing : no operational packets can be passed	specifies state of the interface <i>This element is always shown.</i>

name	Type	Description
opr-state/tx-rate-ds	Parameter type: <Xdsl::combinedCol> (down testing unknown dormant up : <Xdsl::bitrate>) Possible values: - up : up,traffic can pass - down : down,no traffic is passing - testing : testing,no traffic is passing - unknown : unknown - dormant : dormant,no traffic is passing Field type <Xdsl::bitrate> - bitrate - unit: kbits/sec	current operational state of the interface. <i>This element is always shown.</i>
tx-rate/us	Parameter type: <Xdsl::SignedIntegerKBPS> - bitrate - unit: kbits/sec	bitrate or expected throughput for upstream fast or interleaved data flow <i>This element is always shown.</i>
tx-rate/ds	Parameter type: <Xdsl::SignedIntegerKBPS> - bitrate - unit: kbits/sec	bitrate or expected throughput for downstream fast or interleaved data flow <i>This element is always shown.</i>
max-tx-rate-us	Parameter type: <Xdsl::SignedIntegerKBPS> - bitrate - unit: kbits/sec	maximum attainable bit rate or expected throughput the modem can support <i>This element is only shown in detail mode.</i>
max-tx-rate-ds	Parameter type: <Xdsl::SignedIntegerKBPS> - bitrate - unit: kbits/sec	maximum attainable bit rate or expected throughput the modem can support <i>This element is only shown in detail mode.</i>
inp-up	Parameter type: <Xdsl::SignedIntegerSYMBOL> - impulse noise protection - unit: 1/10 symbols	actual impulse noise protection or actual impulse noise protection against shine when the rtx functionality is in use. Value 2047 for ADSLx/VDSLx and 20470 for G.Fast indicates a reported value equal to or higher than the value. <i>This element is only shown in detail mode.</i>
inp-dn	Parameter type: <Xdsl::SignedIntegerSYMBOL> - impulse noise protection - unit: 1/10 symbols	actual impulse noise protection or actual impulse noise protection against shine when the rtx functionality is in use. Value 2047 for ADSLx/VDSLx and 20470 for G.Fast indicates a reported value equal to or higher than the value. <i>This element is only shown in detail mode.</i>
interl-us	Parameter type: <Xdsl::SignedIntegerMSEC> - milli-second - unit: msec	delay caused by the interleaving and deinterleaving functionality or delay caused by the rtx functionality. Only applicable for

109 xDSL Status Commands

name	Type	Description
		ADSLx/VDSLx <i>This element is only shown in detail mode.</i>
interl-ds	Parameter type: <Xdsl::SignedIntegerMSEC> - milli-second - unit: msec	delay caused by the interleaving and deinterleaving functionality or delay caused by the rtx functionality. Only applicable for ADSLx/VDSLx <i>This element is only shown in detail mode.</i>
cur-op-mode	Parameter type: <Xdsl::OneOpModeTypeLinePreDef> (ansi-t1413 etsi-dts g992-1-a g992-1-b g992-2-a g992-3-a g992-3-b g992-3-aj g992-3-l1 g992-3-l2 g992-3-am g992-5-a g992-5-b ansi-t1.424 etsi-ts itu-g993-1 ieee-802.3ah g992-5-aj g992-5-am g993-2-8a g993-2-8b g993-2-8c g993-2-8d g993-2-12a g993-2-12b g993-2-17a g993-2-30a g993-2-35b gfast default) Possible values: - ansi-t1413 : ANSI T1.413-1998 - etsi-dts : ETSI DTS/TM06006 - g992-1-a : G.992.1 POTS non-overlapped spectrum - g992-1-b : G.992.1 ISDN non-overlapped spectrum - g992-2-a : G.992.2 POTS non-overlapped spectrum - g992-3-a : G.992.2 POTS non-overlapped spectrum - g992-3-b : G.992.3 ISDN non-overlapped spectrum - g992-3-aj : G.992.3 All Digital Mode with non-overlapped spectrum - g992-3-l1 : G.992.3 POTS non-overlapped spectrum US mask 1 - g992-3-l2 : G.992.3 POTS non-overlapped spectrum US mask 2 - g992-3-am : G.992.3 extended POTS with non-overlapped spectrum	actual operational mode <i>This element is always shown.</i>

name	Type	Description
	- g992-5-a : G.992.5 POTS non-overlapped spectrum - g992-5-b : G.992.5 POTS non-overlapped spectrum - ansi-t1.424 : ANSI T1.424 - etsi-ts : ETSI TS - itu-g993-1 : ITU G993-1 - ieee-802.3ah : IEEE 802.3ah - g992-5-aj : G.992.5 All Digital Mode with non-overlapped spectrum - g992-5-am : G.992.5 extended POTS non-overlapped spectrum - g993-2-8a : VDSL-2 with profile 8A - g993-2-8b : VDSL-2 with profile 8B - g993-2-8c : VDSL-2 with profile 8C - g993-2-8d : VDSL-2 with profile 8D - g993-2-12a : VDSL-2 with profile 12A - g993-2-12b : VDSL-2 with profile 12B - g993-2-17a : VDSL-2 with profile 17A - g993-2-30a : VDSL-2 with profile 30A - g993-2-35b : VDSL-2 with profile 35B - gfast : gfast profile - default : default value	
rinit-1d	Parameter type: <Counter> - 32 bit counter	number of times the modem re-initialize the line in a day. Only applicable for ADSLx/VDSLx <i>This element is only shown in detail mode.</i>
actual-tps-tc-mode	Parameter type: <Xdsl::ActualTpsTcMode> (no-value atm ptm system-default) Possible values: - no-value : no value - atm : atm mode - ptm : ptm mode - system-default : determined by the system, based on board type	actual transfer mode <i>This element is only shown in detail mode.</i>
rtx-mode-up	Parameter type: <Xdsl::ActualRtxModeType> (in-use forbidden no-xtuc no-xtur no-xtuc-xtur supported unknown) Possible values: - in-use : retransmission in use - forbidden : retransmission not_in_use forbidden - no-xtuc : retransmission not_in_use and not_supported for xtuc - no-xtur : retransmission not_in_use and not_supported for xtur - no-xtuc-xtur : retransmission not_in_use and not_supported for xtuc and xtur - supported : retransmission not selected but supported - unknown : retransmission not supported	actual retransmission mode in upstream direction. "in-use" is reported in case of G.Fast. <i>This element is only shown in detail mode.</i>

109 xDSL Status Commands

name	Type	Description
rtx-mode-dn	Parameter type: <Xdsl::ActualRtxModeType> (in-use forbidden no-xtuc no-xtur no-xtuc-xtur supported unknown) Possible values: - in-use : retransmission in use - forbidden : retransmission not_in_use forbidden - no-xtuc : retransmission not_in_use and not_supported for xtuc - no-xtur : retransmission not_in_use and not_supported for xtur - no-xtuc-xtur : retransmission not_in_use and not_supported for xtuc and xtur - supported : retransmission not selected but supported - unknown : retransmission not supported	actual retransmission mode in downstream direction. "in-use" is reported in case of G.Fast. <i>This element is only shown in detail mode.</i>
total-reset-attempt	Parameter type: <Counter> - 32 bit counter	total number of auto-port-reset attempts for line <i>This element is only shown in detail mode.</i>
success-reset-attempt	Parameter type: <Counter> - 32 bit counter	number of successful auto-port-reset attempts for line <i>This element is only shown in detail mode.</i>
cur-init-state	Parameter type: <Xdsl::CurrentInitStateType> (idle handshake wait-for-start channel-discovery training channel-analysis showtime loop-diagnostics selt shutdown not-available) Possible values: - idle : No activity on the line - handshake : Handshake started - wait-for-start : Handshake on hold for vectoring - channel-discovery : Channel discovery phase started - training : Training phase started - channel-analysis : Channel analysis and exchange phase started - showtime : Showtime achieved - loop-diagnostics : Loop Diagnostics test mode active - selt : SELT test mode active - shutdown : Line not allowed to start-up - not-available : Line state not available	xdsl line actual interim initialization state <i>This element is only shown in detail mode.</i>
actual-vdsl2-lr-mode	Parameter type: <Xdsl::LongReachMode> (not-operational short-loop-lr medium-loop-lr long-loop-lr)	actual vdsl2-lr mode in which the line operates <i>This element is only shown in detail mode.</i>

name	Type	Description
	Possible values: - not-operational : vdsl2 lr is not operational - short-loop-lr : vdsl2 lr short loop operation mode - medium-loop-lr : vdsl2 lr medium loop operation mode - long-loop-lr : vdsl2 lr long loop operation mode	

109.9 xDSL Carrier Data Near End Status Command

Command Description

This command displays xDSL carrier data near end.

Carrier data is displayed in raw format so the actual data interpretation is described in this section.

The XDSL passband (downstream or upstream) is composed of one or more bands (max 5, including VDSL optional band). Each carrier is coded as a bitmap. When the data are not available because the measurement is not completed, not enabled or not supported, an empty string will be returned. Below is the definition of the carrier specific bitmap.

Carrier load (Load-distribution-down) : When the modem is not in showtime this object will have the previously measured value. Each carrier can carry up to 15 bits. The carrier load is coded as a bitmap defined as follows:

- OCTETS 0,1: INTEGER (0..8191), index of the start carrier group of the first downstream band. The value is defined as MSB-LSB (big-endian).
- OCTETS 2,3: INTEGER (0..8191), index of the stop carrier group of the first downstream band. The value is defined as MSB-LSB (big-endian).
- OCTET 4: contains the bit load of the first two carrier groups of the band. The load of the first carrier group uses the most significant 4 bits nibble. Range is 0-15 bits per carrier group, with a granularity of 1 bit/carrier group.
- OCTETS 5..L: and so on, up to the last carrier group of the first downstream band. The last nibble of OCTET L is set to 0x0 if not used.
- OCTETS L+1..M: contain the start/stop carrier groups and the carrier load of the second downstream band when available.
- OCTETS M+1..N: contain the start/stop carrier groups and the carrier load of the third downstream band when available.
- OCTETS N+1..P: contain the start/stop carrier groups and the carrier load of the fourth downstream band when available.
- OCTETS P+1..Q: contain the start/stop carrier groups and the carrier load of the fifth downstream band when available.

Carrier gain (gain-allocation-down) : When the modem is not in showtime this object will have the previously measured value. The gain has a range of approximately 0 - 8, in steps of 1/512. The gain value is represented as $gi/512$ on a linear scale with gi a 12 bits unsigned integer in the 0 to 4095 range given by the 12 LSB bits of a 2 bytes integer. The carrier gain allocation is coded as a bitmap defined as follows:

- OCTETS 0,1: INTEGER (0..8191), index of the start carrier group of the first downstream band. The value is defined as MSB-LSB (big-endian).
- OCTETS 2,3: INTEGER (0..8191), index of the stop carrier group of the first downstream band. The value is defined as MSB-LSB (big-endian).
- OCTETS 4,5: INTEGER, contains the gain of the first carrier group of the band (start carrier group).
- OCTETS 6..L: and so on until the last carrier group of the first downstream band (stop carrier group).
- OCTETS L+1..M: contain the start/stop carrier groups and the carrier gain of the second downstream band when available.
- OCTETS M+1..N: contain the start/stop carrier groups and the carrier gain of the third downstream band when available.
- OCTETS N+1..P: contain the start/stop carrier groups and the carrier gain of the fourth downstream band when available.
- OCTETS P+1..Q: contain the start/stop carrier groups and the carrier gain of the fifth downstream band when available.

Carrier snr (snr-up): When the modem is not in showtime this object will have the previously measured value. The SNR has a range from -32 to 95 dB in steps of 0.5 dB. It is represented as $SNR_i = -32 + snr_i/2$, with snr_i an 8 bit unsigned integer in the range 0 to 254. The special value 255 indicates that no measurement is available for the carrier or that the measurement is out of range. The carrier snrs are coded as a bitmap defined as follows:

- OCTETS 0,1: INTEGER, contains the number of symbols used to measure the data. The value is defined as MSB-LSB (big-endian).
- OCTETS 2,3: INTEGER (0..8191), index of the start carrier group of the first upstream band. The value is defined as MSB-LSB (big-endian).
- OCTETS 4,5: INTEGER (0..8191), index of the stop carrier group of the first upstream band. The value is defined as MSB-LSB (big-endian).
- OCTETS 6: INTEGER, contains the snr of the first carrier group of the band (start carrier group).
- OCTETS 7..L: and so on until the last carrier group of the first upstream band (stop carrier group).
- OCTETS L+1..M: contain the start/stop carrier groups and the carrier snr of the second upstream band when available.
- OCTETS M+1..N: contain the start/stop carrier groups and the carrier snr of the third upstream band when available.
- OCTETS N+1..P: contain the start/stop carrier groups and the carrier snr of the fourth upstream band when available.
- OCTETS P+1..Q: contain the start/stop carrier groups and the carrier snr of the fifth upstream band when available.

Carrier qln (qln-up): The QLN has a range from -150 dBm/Hz to -23 dBm/Hz in steps of 0.5 dB. It is represented as $QLN_i = -23 - qln_i/2$, with qln_i an 8 bit unsigned integer in the range 0 to 254. The special value 255 indicates that no measurement is available for the carrier or that the measurement is out of range. The carrier qlns are coded as a bitmap defined as follows:

- OCTETS 0,1: INTEGER, contains the number of symbols used to measure the data. The value is defined as MSB-LSB (big-endian).
- OCTETS 2,3: INTEGER (0..8191), index of the start carrier group of the first upstream band. The value is defined as MSB-LSB (big-endian).
- OCTETS 4,5: INTEGER (0..8191), index of the stop carrier group of the first upstream band. The value is defined as MSB-LSB (big-endian).
- OCTETS 6: INTEGER, contains the qln of the first carrier group of the band (start carrier group).
- OCTETS 7..L: and so on until the last carrier group of the first upstream band (stop carrier group).
- OCTETS L+1..M: contain the start/stop carrier groups and the carrier qln of the second downstream band when available.
- OCTETS M+1..N: contain the start/stop carrier groups and the carrier qln of the third upstream band when available.
- OCTETS N+1..P: contain the start/stop carrier groups and the carrier qln of the fourth upstream band when available.
- OCTETS P+1..Q: contain the start/stop carrier groups and the carrier qln of the fifth upstream band when available.

Carrier HLIN (char-func-complex): HLIN has a range of approximately +6 dB to -90 dB, with a granularity of 2^{-15} . The Hlin is represented as $HLIN_i = (scale/2^{15}) * ((ai + j*bi)/2^{15})$, with ai and bi 2 bytes signed integers in the range -32767 to 32767. The special value -32768 indicates that no measurement is available for the carrier or that the measurement is out of range. The scale factor is a 2 bytes unsigned integer. The scale factor must be chosen such that: $\max(|Ai|, |Bi|)$ over all i is equal to $2^{15}-1$, i.e. over all carriers of the XDSL band(s) of the corresponding direction. The carrier HLINs are coded as a bitmap defined as follows:

- OCTETS 0,1: INTEGER, contains the number of symbols used to measure the data. The value is defined as MSB-LSB (big-endian).
- OCTETS 2,3: INTEGER(0..65535), contains the scale factor to apply to the hlin values, over the upstream band(s). The value is defined as MSB-LSB (big-endian).
- OCTETS 4,5: INTEGER (0..8191), index of the start carrier group of the first upstream band. The value is defined as MSB-LSB (big-endian).
- OCTETS 6,7: INTEGER (0..8191), index of the stop carrier group of the first upstream band. The value is defined as MSB-LSB (big-endian).
- OCTETS 8,9: SIGNED INTEGER, contains the ai for the first carrier group of the band (start carrier group). The value is defined as MSB-LSB (big-endian).
- OCTETS 10,11: SIGNED INTEGER, contains the bi for the first carrier group of the band (start carrier

- group). The value is defined as MSB-LSB (big-endian).
- OCTETS 12..L: ai and bi for the next carrier group and so on until the last carrier group of the first upstream band (stop carrier group).
 - OCTETS L+1..M: contain the start/stop carrier groups and the HLIN ai and bi of the second upstream band when available.
 - OCTETS M+1..N: contain the start/stop carrier groups and the HLIN ai and bi of the third upstream band when available.
 - OCTETS N+1..P: contain the start/stop carrier groups and the HLIN ai and bi of the fourth upstream band when available.
 - OCTETS P+1..Q: contain the start/stop carrier groups and the HLIN ai and bi of the fifth upstream band when available.

Carrier HLOG (char-func-real): Hlog has a range of approximately +6 dB to -96 dB in steps of 0.1 dB. The Hlog is represented as $HLOG_i = 6 - mi/10$, with mi a 10 bits unsigned integer in the range 0 to 1022. The special value 1023 indicates that no measurement is available for the carrier or that the measurement is out of range. The carrier HLOGs are coded as a bitmap defined as follows:

- OCTETS 0,1: INTEGER, contains the number of symbols used to measure the data. The value is defined as MSB-LSB (big-endian).
- OCTETS 2,3: INTEGER (0..8191), index of the start carrier group of the first upstream band. The value is defined as MSB-LSB (big-endian).
- OCTETS 4,5: INTEGER (0..8191), index of the stop carrier group of the first upstream band. The value is defined as MSB-LSB (big-endian).
- OCTETS 6,7: INTEGER (0..1023), contains the HLOG mi of the first carrier group of the band (start carrier group). The value is defined as MSB-LSB (big-endian).
- OCTETS 8..L: mi for the next carrier group and so on until the last carrier group of the first upstream band (stop carrier group).
- OCTETS L+1..M: contain the start/stop carrier groups and the HLOG mi of the second upstream band when available.
- OCTETS M+1..N: contain the start/stop carrier groups and the HLOG mi of the third upstream band when available.
- OCTETS N+1..P: contain the start/stop carrier groups and the HLOG mi of the fourth upstream band when available.
- OCTETS P+1..Q: contain the start/stop carrier groups and the HLOG mi of the fifth upstream band when available.

Carrier Tx PSD (tx-psd-dn): When the modem is not in showtime this object will have the previously measured value. The PSD has a range from -127 dBm/Hz to 0 dBm/Hz in steps of 0.5 dB. It is represented as $PSD_i = -psdi/2$, with psdi an 8 bit unsigned integer in the range 0 to 254. The special value 255 indicates that no measurement is available for the carrier, the carrier is not loaded, or that the measurement is out of range. The carrier Tx PSD is coded as a bitmap defined as follows:

- OCTETS 0,1: INTEGER (0..8191), index of the start carrier group of the downstream band. The value is defined as MSB-LSB (big-endian).
- OCTETS 2,3: INTEGER (0..8191), index of the stop carrier group of the downstream band. The value is defined as MSB-LSB (big-endian).
- OCTETS 4: INTEGER(0..255), PSD of the first carrier group of the band (start carrier group).
- OCTETS 5..L: and so on until the last carrier group of the first downstream band (stop carrier group).
- OCTETS L+1..M: contain the start/stop carrier groups and the carrier PSD of the second downstream band when available.
- OCTETS M+1..N: contain the start/stop carrier groups and the carrier PSD of the third downstream band when available.
- OCTETS N+1..P: contain the start/stop carrier groups and the carrier PSD of the fourth downstream band when available.
- OCTETS P+1..Q: contain the start/stop carrier groups and the carrier PSD of the fifth downstream band when available.

For G.Fast, the configured carrier-data-mode is ignored and the system behaves as if the carrier data collection is enabled. Each carrier is coded as a bitmap. When the data are not available because the measurement is not completed, or not supported, an empty string will be returned. The carrier group parameters hlog-carr-grp and qln-carr-grp are supported for both G.Fast and ADSLx/VDSLx. All other carrier group related parameters are not

applicable for G.Fast, value 1 will be returned. Below is the definition of the carrier specific bitmap for the G.Fast related parameters.

The bit allocation values on RMC sub-carriers in RMC symbols in the downstream direction (rmc-carr-load-dn): The bit loading allocation for RMC sub-carriers is defined as follows:

- OCTETS 0,1: INTEGER (0..4095), index of the first RMC sub-carrier.
- OCTETS 2: INTEGER (0,2..6), bit allocation value for the first RMC sub-carrier.
- OCTETS 3*N-2..3*N: reports the sub-carrier index and the bit allocation value of the successive RMC sub-carrier #N (N is less or equals 512).

GFast Quiet Line Noise in the upstream direction (gf-qln-up) : When the modem is not in showtime this object will have the previously measured value. The quiet Line Noise has a range from -160 dBm/Hz to -35.5 dBm/Hz in steps of 0.5 dB. It is represented as $QLNi = -35 - qlni/2$, with qlni an 8-bit unsigned integer in the range 1 to 250. Special value 0 indicates that the measurement for the sub-carrier group is greater than or equal to -35dBm/Hz. Special value 251 indicates that the measurement for the sub-carrier group is less than or equal to -160.5 dBm/Hz. Special value 254 indicates that no measurement could be done for the sub-carrier group because it is out of the upstream MEDLEY set. Special value 255 indicates that no measurement is available for the sub-carrier group. The carrier measurements are coded as a bitmap defined as follows:

- OCTETS 0,1: INTEGER, contains the number of symbols used to measure the data. The value is defined as MSB-LSB (big-endian).
- OCTETS 2,3: INTEGER (0.2047), index of the start carrier group of the reported data. The value is defined as MSB-LSB (big-endian).
- OCTETS 4,5: INTEGER (0.2047), index of the stop carrier group of the reported data. The value is defined as MSB-LSB (big-endian).
- OCTET 6: INTEGER, contains the qln of the first sub-carrier group.
- OCTET 7...N: and so on until the last sub-carrier group.

User Level

The command can be accessed by operators with xdsl privileges.

Command Syntax

The command has the following syntax:

```
> show xdsl carrier-data near-end [ (if-index) ]
```

Command Parameters

Table 109.9-1 "xDSL Carrier Data Near End Status Command" Resource Parameters

Resource Identifier	Type	Description
(if-index)	Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number	interface index of the port

Command Output

Table 109.9-2 "xDSL Carrier Data Near End Status Command" Display parameters

Specific Information		
name	Type	Description
spacing	Parameter type: <Xdsl::CarrierSpacingType> (single double half quarter gfast) Possible values: - single : single - double : double - half : half - quarter : quarter - gfast : gfast	the actual carrier spacing used on the XDSL line in the downstream direction <i>This element is always shown.</i>
load-distribution-down	Parameter type: <Xdsl::OctetStingType> - a binary string	nbr of bits per carrier group over the downstream passband <i>This element is always shown.</i>
gain-allocation-down	Parameter type: <Xdsl::OctetStingType> - a binary string	gain allocation (i.e. gi) per carrier group over the downstream passband. Only applicable for ADSLx/VDSLx <i>This element is always shown.</i>
snr-up	Parameter type: <Xdsl::OctetStingType> - a binary string	signal to noise ratio per carrier group over the upstream passband <i>This element is always shown.</i>
qln-up	Parameter type: <Xdsl::OctetStingType> - a binary string	quiet line noise per carrier group over the upstream passband. Only applicable for ADSLx/VDSLx <i>This element is always shown.</i>
char-func-complex	Parameter type: <Xdsl::OctetStingType> - a binary string	provides the channel characteristics function complex values in linear scale for each carrier group over upstream passband (hlin). Only applicable for ADSLx/VDSLx <i>This element is always shown.</i>
char-func-real	Parameter type: <Xdsl::OctetStingType> - a binary string	char func real values in dB over upstream passband (hlog) <i>This element is always shown.</i>
tx-psd-dn	Parameter type: <Xdsl::OctetStingType> - a binary string	the actual transmit PSD per carrier group over the downstream passband <i>This element is always shown.</i>
tx-psd-carr-grop	Parameter type: <Xdsl::SubCarrierGroupSizeType> - grouping factor per carrier data octet-string - range: [1,2,4,8,16]	the grouping factor for Actual Tx Power Spectrum Density carrier data octet-string. Only applicable for ADSLx/VDSLx <i>This element is always shown.</i>
load-carr-grp	Parameter type: <Xdsl::SubCarrierGroupSizeType> - grouping factor per carrier data octet-string - range: [1,2,4,8,16]	Provides the grouping factor for carrier load data octet-string. Only applicable for ADSLx/VDSLx

name	Type	Description
		<i>This element is always shown.</i>
gain-carr-grp	Parameter type: <Xdsl::SubCarrierGroupSizeType> - grouping factor per carrier data octet-string - range: [1,2,4,8,16]	Provides the grouping factor for carrier gain allocation data octet-string. Only applicable for ADSLx/VDSLx <i>This element is always shown.</i>
snr-carr-grp	Parameter type: <Xdsl::SubCarrierGroupSizeType> - grouping factor per carrier data octet-string - range: [1,2,4,8,16]	Provides the grouping factor for Signal to Noise Ratio per carrier data octet-string. Only applicable for ADSLx/VDSLx <i>This element is always shown.</i>
qln-carr-grp	Parameter type: <Xdsl::SubCarrierGroupSizeType> - grouping factor per carrier data octet-string - range: [1,2,4,8,16]	Provides the grouping factor for Quiet Line Noise data octet-string <i>This element is always shown.</i>
hlin-carr-grp	Parameter type: <Xdsl::SubCarrierGroupSizeType> - grouping factor per carrier data octet-string - range: [1,2,4,8,16]	Provides the grouping factor for Complex Channel Characteristics data in linear scale. Only applicable for ADSLx/VDSLx <i>This element is always shown.</i>
hlog-carr-grp	Parameter type: <Xdsl::SubCarrierGroupSizeType> - grouping factor per carrier data octet-string - range: [1,2,4,8,16]	Provides the grouping factor for Channel Characteristics data in dB <i>This element is always shown.</i>
vect-qln-mode-up	Parameter type: <Xdsl::ActualQlnMode> (with-cancel without-cancel unknown) Possible values: - with-cancel : with xtalk cancellation - without-cancel : without xtalk cancellation - unknown : qln reporting mode not known	actual reported line carrier data quiet line noise. Only applicable for ADSLx/VDSLx <i>This element is only shown in detail mode.</i>

109.10 xDSL Carrier Data Far End Status Command

Command Description

This command displays xDSL carrier data far end.

Carrier data is displayed in raw format so the actual data interpretation is described in this section.

Several parameters have similar definitions for far end and near end. Hence, for more details related to the bitmap definition and the description of ranges, specific values,... of the carriers, we refer to the command description section of the "xDSL Carrier Data Near End Status Command" section. When reading this in scope of "Far End", "downstream" becomes "upstream" and vice versa. Parameters which are only reported for far end are explained below.

GFast Active Line Noise in the Downstream direction (gf-aln-down) : When the modem is not in showtime this object will have the previously measured value. The Active Line Noise has a range from -160 dBm/Hz to -35.5 dBm/Hz in steps of 0.5 dB. It is represented as $ALNi = -35 - alni/2$, with alni an 8-bit unsigned integer in the range 1 to 250. Special value 0 indicates that the measurement for the sub-carrier group is greater than or equal to -35dBm/Hz. Special value 251 indicates that the measurement for the sub-carrier group is less than or equal to -160.5 dBm/Hz. Special value 254 indicates that no measurement could be done for the sub-carrier group because it is out of the downstream MEDLEY set. Special value 255 indicates that no measurement is available for the sub-carrier group. The carrier measurements are coded as a bitmap defined as follows:

- OCTETS 0,1: INTEGER, contains the number of symbols used to measure the data. The value is defined as MSB-LSB (big-endian).
- OCTETS 2,3: INTEGER (0.2047), index of the start carrier group of the reported data. The value is defined as MSB-LSB (big-endian).
- OCTETS 4,5: INTEGER (0.2047), index of the stop carrier group of the reported data. The value is defined as MSB-LSB (big-endian).
- OCTET 6: INTEGER, contains the aln of the first sub-carrier group.
- OCTET 7...N: and so on until the last sub-carrier group.

The Far End Carrier Data also reports the carrier group parameter gf-aln-carr-grp, which is only applicable for G.Fast. Default value 1 is returned for ADSLx/VDSLx.

User Level

The command can be accessed by operators with xdsl privileges.

Command Syntax

The command has the following syntax:

```
> show xdsl carrier-data far-end [ (if-index) ]
```

Command Parameters

Table 109.10-1 "xDSL Carrier Data Far End Status Command" Resource Parameters

Resource Identifier	Type	Description
(if-index)	Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId>	interface index of the port

Resource Identifier	Type	Description
	Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number	

Command Output

Table 109.10-2 "xDSL Carrier Data Far End Status Command" Display parameters

Specific Information		
name	Type	Description
spacing	Parameter type: <Xdsl::CarrierSpacingType> (single double half quarter gfast) Possible values: - single : single - double : double - half : half - quarter : quarter - gfast : gfast	the actual carrier spacing used on the XDSL line in the upstream direction <i>This element is always shown.</i>
load-distribution-up	Parameter type: <Xdsl::OctetStingType> - a binary string	nbr of bits per carrier group over the upstream passband <i>This element is always shown.</i>
gain-allocation-up	Parameter type: <Xdsl::OctetStingType> - a binary string	gain allocation (i.e.gi) per carrier group over the upstream passband. Only applicable for ADSLx/VDSLx <i>This element is always shown.</i>
snr-down	Parameter type: <Xdsl::OctetStingType> - a binary string	signal to noise ratio per carrier group over the downstream passband <i>This element is always shown.</i>
qln-down	Parameter type: <Xdsl::OctetStingType> - a binary string	quiet line noise per carrier group over the downstream passband. Only applicable for ADSLx/VDSLx <i>This element is always shown.</i>
char-func-complex	Parameter type: <Xdsl::OctetStingType> - a binary string	provides the channel characteristics function complex values in linear scale per carrier group over downstream passband (hlin). Only applicable for ADSLx/VDSLx <i>This element is always shown.</i>
char-func-real	Parameter type: <Xdsl::OctetStingType> - a binary string	char func real values in dB over downstream passband (hlog) <i>This element is always shown.</i>
tx-psd-up	Parameter type: <Xdsl::OctetStingType> - a binary string	the actual transmit PSD per carrier group over the upstream passband

109 xDSL Status Commands

name	Type	Description
		<i>This element is always shown.</i>
tx-psd-carr-grop	Parameter type: <Xdsl::SubCarrierGroupSizeType> - grouping factor per carrier data octet-string - range: [1,2,4,8,16]	the grouping factor for Actual Tx Power Spectrum Density carrier data octet-string. Only applicable for ADSLx/VDSLx <i>This element is always shown.</i>
load-carr-grp	Parameter type: <Xdsl::SubCarrierGroupSizeType> - grouping factor per carrier data octet-string - range: [1,2,4,8,16]	Provides the grouping factor for carrier load data octet-string. Only applicable for ADSLx/VDSLx <i>This element is always shown.</i>
gain-carr-grp	Parameter type: <Xdsl::SubCarrierGroupSizeType> - grouping factor per carrier data octet-string - range: [1,2,4,8,16]	Provides the grouping factor for carrier gain allocation data octet-string. Only applicable for ADSLx/VDSLx <i>This element is always shown.</i>
snr-carr-grp	Parameter type: <Xdsl::SubCarrierGroupSizeType> - grouping factor per carrier data octet-string - range: [1,2,4,8,16]	Provides the grouping factor for Signal to Noise Ratio per carrier data octet-string. Only applicable for ADSLx/VDSLx <i>This element is always shown.</i>
qln-carr-grp	Parameter type: <Xdsl::SubCarrierGroupSizeType> - grouping factor per carrier data octet-string - range: [1,2,4,8,16]	Provides the grouping factor for Quiet Line Noise data octet-string <i>This element is always shown.</i>
hlin-carr-grp	Parameter type: <Xdsl::SubCarrierGroupSizeType> - grouping factor per carrier data octet-string - range: [1,2,4,8,16]	Provides the grouping factor for Complex Channel Characteristics data in linear scale. Only applicable for ADSLx/VDSLx <i>This element is always shown.</i>
hlog-carr-grp	Parameter type: <Xdsl::SubCarrierGroupSizeType> - grouping factor per carrier data octet-string - range: [1,2,4,8,16]	Provides the grouping factor for Channel Characteristics data in dB <i>This element is always shown.</i>
vect-qln-mode-down	Parameter type: <Xdsl::ActualQlnMode> (with-cancel without-cancel unknown) Possible values: - with-cancel : with xtalk cancellation - without-cancel : without xtalk cancellation - unknown : qln reporting mode not known	actual reported line carrier data quiet line noise. Only applicable for ADSLx/VDSLx <i>This element is only shown in detail mode.</i>

109.11 xDSL Failure Status Near End Status Command

Command Description

This command displays the xDSL failure status near end.

User Level

The command can be accessed by operators with xdsl privileges.

Command Syntax

The command has the following syntax:

```
> show xdsl failure-status near-end [ (if-index) ]
```

Command Parameters

Table 109.11-1 "xDSL Failure Status Near End Status Command" Resource Parameters

Resource Identifier	Type	Description
(if-index)	Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number	interface index of the port

Command Output

Table 109.11-2 "xDSL Failure Status Near End Status Command" Display parameters

Specific Information		
name	Type	Description
line-defect	Parameter type: <Xdsl::FailureStatusNearEnd> (yes no) Possible values: - yes : defect in the near-end failure status - no : no defect in the near-end failure status	specifies the defect status in the near-end <i>This element is always shown.</i>
los	Parameter type: <Xdsl::FailureStatusNELOS>	specifies status of the Loss of

109 xDSL Status Commands

name	Type	Description
	(no yes) Possible values: - no : no LOS in upstream direction - yes : LOS in the upstream direction	Signal in upstream direction <i>This element is always shown.</i>
lof	Parameter type: <Xdsl::FailureStatusNELOF> (no yes) Possible values: - no : no LOF in upstream direction - yes : LOF in the upstream direction	specifies status of the Loss of Frame in upstream direction <i>This element is always shown.</i>
lom	Parameter type: <Xdsl::FailureStatusNELOM> (no yes) Possible values: - no : no LOM in upstream direction - yes : LOM in the upstream direction	specifies status of the Loss of Margin in upstream direction <i>This element is always shown.</i>
lpr	Parameter type: <Xdsl::FailureStatusNELPR> (no yes) Possible values: - no : no LPR of the ATU-C - yes : LPR of the ATU-C	specifies status of the Loss of Power of the ATU-C <i>This element is always shown.</i>
ese	Parameter type: <Xdsl::FailureStatusNEESE> (no yes) Possible values: - no : no ESE in upstream direction - yes : ESE in the upstream direction	specifies status of the Excessive Severe Errors in upstream direction <i>This element is always shown.</i>
act-fail-conf-err	Parameter type: <Xdsl::NEActFailConfErr> (no yes) Possible values: - no : no Activation Failure due to configuration error - yes : Line Activation Fail due to configuration error	specifies status of line Activation <i>This element is always shown.</i>
act-fail-conf-not-feas	Parameter type: <Xdsl::NEActFailConfNotFeasible> (no yes) Possible values: - no : Line Activation Fail due to configuration not feasible - yes : no Activation Failure due to configuration not feasible	specifies status of line Activation <i>This element is always shown.</i>
bitrate-threshold	Parameter type: <Xdsl::FailureStatusNEBitRateThrs> (no-low-rate low-rate) Possible values: - no-low-rate : no Bit rate threshold for the upstream direction - low-rate : Bit rate threshold for upstream direction	specifies status of Bit Rate Threshold <i>This element is always shown.</i>
tpstc-mismatch	Parameter type: <Xdsl::FailureStatusNETpstcMism> (no yes) Possible values: - no : no TpsTc mismatch is detected - yes : a TpsTc mismatch is detected	indicates a Tpstc mismatch <i>This element is always shown.</i>
forced-rtx-init-fail	Parameter type: <Xdsl::FailureStatusNERTxInitFail> (no	specifies status of line initialisation when forced RTX

name	Type	Description
	yes) Possible values: - no : No line initialisation failure due to forced Rtx request - yes : Line Initialisation failure due to forced Rtx request	<i>This element is always shown.</i>
vect-dle	Parameter type: <Xdsl::FailureStatusNEDLE> (yes no) Possible values: - yes : loss of us signal due to disorderly leaving event - no : no disorderly leaving detected	counter for disorderly leaving failure events <i>This element is always shown.</i>
act-fail-err-code	Parameter type: <SignedInteger> - a signed integer	activation failure error code <i>This element is always shown.</i>
act-fail-err-descr	Parameter type: <Xdsl::IgnoredPrintableString> - ignored printable string	activation failure error description <i>This element is only shown in detail mode.</i>

109.12 xDSL Failure Status Far End Status Command

Command Description

This command displays the xDSL failure of the far end.

User Level

The command can be accessed by operators with xdsl privileges.

Command Syntax

The command has the following syntax:

```
> show xdsl failure-status far-end [ (if-index) ]
```

Command Parameters

Table 109.12-1 "xDSL Failure Status Far End Status Command" Resource Parameters

Resource Identifier	Type	Description
(if-index)	Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number	interface index of the port

Command Output

Table 109.12-2 "xDSL Failure Status Far End Status Command" Display parameters

Specific Information		
name	Type	Description
line-defect	Parameter type: <Xdsl::FailureStatusNoDefect> (yes no) Possible values: - yes : defect in the far-end failure status - no : no defect in the far-end failure status	specifies the defect status in the far-end <i>This element is always shown.</i>
los	Parameter type: <Xdsl::FailureStatusFELOS>	specifies status of the Loss of

name	Type	Description
	(no yes) Possible values: - no : no LOS in downstream direction - yes : LOS in the downstream direction	Signal in downstream direction <i>This element is always shown.</i>
lof	Parameter type: <Xdsl::FailureStatusFELOF> (no yes) Possible values: - no : no LOF in downstream direction - yes : LOF in the downstream direction	specifies status of the Loss of Frame in downstream direction <i>This element is always shown.</i>
lom	Parameter type: <Xdsl::FailureStatusFELOM> (no yes) Possible values: - no : no LOM in downstream direction - yes : LOM in the downstream direction	specifies status of the Loss of Margin in downstream direction <i>This element is always shown.</i>
lpr	Parameter type: <Xdsl::FailureStatusFELPR> (no yes) Possible values: - no : no LPR of the XTU-R - yes : LPR of the XTU-R	specifies status of the Loss of Power of the XTU-C <i>This element is always shown.</i>
lol	Parameter type: <Xdsl::FailureStatusFELOL> (no yes) Possible values: - no : no LOL in line - yes : LOL in line	specifies status of the Loss of Link <i>This element is always shown.</i>
ese	Parameter type: <Xdsl::FailureStatusFEESE> (no yes) Possible values: - no : no ESE in downstream direction - yes : ESE in the downstream direction	specifies status of the Excessive Severe Errors <i>This element is always shown.</i>
act-fail-comm-prob	Parameter type: <Xdsl::FEActFailCommProb> (no yes) Possible values: - no : no Activation Failure due to communication problems - yes : Line Activation Fail due to communication problems	specifies status of line Activation <i>This element is always shown.</i>
act-fail-no-xtu-r	Parameter type: <Xdsl::FEActFailNoXTUR> (no yes) Possible values: - no : Line Activation Fail due to no XTU-R detected - yes : no Activation Failure due to no XTU-R detected	specifies status of line Activation <i>This element is always shown.</i>
bitrate-threshold	Parameter type: <Xdsl::FailureStatusFEBitRateThrs> (no-low-rate low-rate) Possible values: - no-low-rate : no Bit rate threshold for the downstream direction - low-rate : Bit rate threshold for downstream direction	specifies status of Bit Rate Threshold <i>This element is always shown.</i>
upbo-vio	Parameter type: <Xdsl::FailureStatusFEUPBOViolate> (no yes)	specifies far end UPBO violation status <i>This element is always shown.</i>

109 xDSL Status Commands

name	Type	Description
	Possible values: - no : no far end UPBO violation - yes : far end UPBO violation	
cpe-pol	Parameter type: <Xdsl::FailureStatusFECPEPolicing> (no yes) Possible values: - no : no activation failure due to CPE policing - yes : activation failure due to CPE policing	specifies Activation Failure status due to CPE policing <i>This element is always shown.</i>
mis-peer-35b	Parameter type: <Xdsl::FailureStatusMismatchPeer35B> (no yes) Possible values: - no : no VDSL2 35b opmode mismatch between XTU-C and XTU-R - yes : VDSL2 35b opmode mismatch between XTU-C and XTU-R	VDSL2 35b opmode mismatch between XTU-C and XTU-R <i>This element is always shown.</i>
act-fail-err-code	Parameter type: <SignedInteger> - a signed integer	activation failure error code <i>This element is always shown.</i>
act-fail-err-descr	Parameter type: <Xdsl::IgnoredPrintableString> - ignored printable string	activation failure error description <i>This element is only shown in detail mode.</i>

109.13 xDSL Vectored Line Failure Status Command

Command Description

This command displays the xDSL vectored line failure status.

User Level

The command can be accessed by operators with xdsl privileges.

Command Syntax

The command has the following syntax:

```
> show xdsl failure-status vect-line-near-end [ (if-index) ]
```

Command Parameters

Table 109.13-1 "xDSL Vectored Line Failure Status Command" Resource Parameters

Resource Identifier	Type	Description
(if-index)	Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number	interface index of the port

Command Output

Table 109.13-2 "xDSL Vectored Line Failure Status Command" Display parameters

Specific Information		
name	Type	Description
xtc-variation-vict	Parameter type: <Xdsl::FailureStatusXTCVARVICT> (excessive normal) Possible values: - excessive : abnormal amplitude variation in xtc coefficients - normal : no excessive xtc coefficients variation	specifies status of excessive victim crosstalk coefficient variation <i>This element is always shown.</i>

109 xDSL Status Commands

name	Type	Description
xtc-variation-dist	Parameter type: <Xdsl::FailureStatusXTCVARDIST> (excessive normal) Possible values: - excessive : abnormal amplitude variation in xtc coefficients - normal : no excessive xtc coefficients variation	specifies status of excessive disturber crosstalk coefficient variation <i>This element is always shown.</i>
corrupted-errf	Parameter type: <Xdsl::FailureStatusCorpERRF> (yes no) Possible values: - yes : at least 10% corrupted or missing errorf samples received - no : received errorf samples ok	specifies status of received corrupted errorf samples <i>This element is always shown.</i>
vect-cpe-cap-mismatch	Parameter type: <Xdsl::FailureStatusVectCpeCapMism> (yes no) Possible values: - yes : not allowed Vectoring CPE connected - no : allowed Vectoring CPE connected	specifies if an allowed Vectoring CPE is connected or not <i>This element is always shown.</i>
vect-conf-not-feas	Parameter type: <Xdsl::FailureStatusVectConfigNotFeas> (yes no) Possible values: - yes : Vectoring Configuration Not Feasible - no : Vectoring Configuration Feasible	specifies if the vectoring configuration is feasible <i>This element is always shown.</i>

109.14 xDSL Vectoring Board Failure Status Command

Command Description

This command displays the xDSL vectoring board failure status.

User Level

The command can be accessed by operators with xdsl privileges.

Command Syntax

The command has the following syntax:

```
> show xdsl failure-status vect-board [ (board-index) ]
```

Command Parameters

Table 109.14-1 "xDSL Vectoring Board Failure Status Command" Resource Parameters

Resource Identifier	Type	Description
(board-index)	Format: (ctrl : <Eqpt::RackId> / <Eqpt::ShelfId> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId>) Possible values: - ctrl : ctrl-slot Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number	interface index of the board

Command Output

Table 109.14-2 "xDSL Vectoring Board Failure Status Command" Display parameters

Specific Information		
name	Type	Description
vp-lt-mismatch	Parameter type: <Xdsl::FailureStatusVPLTMISM> (yes no) Possible values: - yes : mismatch between expected and actual vp-lt mapping or incompatible sw version on vp and lt. - no : expected and actual vp-lt in line or vp and lt have	specifies failure status of vp and its expected connected lt's OR incompatible sw versions. In case vplt-autodiscovery disabled on vp, failure reported on vp-board. In case vplt-autodiscovery enabled on lt, failure reported on

109 xDSL Status Commands

name	Type	Description
	compatible sw versions OR autodiscovery enabled on vp, autodiscovery disabled on lt	lt-board. <i>This element is always shown.</i>
qsfp-id	Parameter type: <Xdsl::FailureStatusINVQSFP> (invalid valid) Possible values: - invalid : QSFP does not have a valid Nokia ID - valid : QSFP has a valid Nokia ID or no QSFP detected or not applicable.	specifies the failure status of the detected qsfp-id of the frontcable <i>This element is always shown.</i>
vp-lt-link short name: vp-lt-link-fail	Parameter type: <Xdsl::FailureStatusVPLTLINKFAIL> ((linkdown yes) (linkup no/not-app)) Possible values: - linkdown : vp-lt link problem - yes : vp-lt link problem - linkup : vp-lt link ok or no lt-expected OR autodiscovery enabled on vp, autodiscovery disabled on lt - no/not-app : vp-lt link ok or no lt-expected OR autodiscovery enabled on vp, autodiscovery disabled on lt	specifies the failure status of the VP-LT Link. In case vplt-autodiscovery disabled on vp, failure reported on vp-board when an lt was expected but no valid connection between vp-lt. In case vplt-autodiscovery enabled on lt, failure reported on lt-board when no valid connection between vp-lt. <i>This element is always shown.</i>

109.15 xDSL Counters Near End Line Current 15 Min

Command Description

This command displays xDSL counters near end line current 15 min.

User Level

The command can be accessed by operators with xdsl privileges.

Command Syntax

The command has the following syntax:

```
> show xdsl counters near-end line current-interval [ (if-index) ]
```

Command Parameters

Table 109.15-1 "xDSL Counters Near End Line Current 15 Min" Resource Parameters

Resource Identifier	Type	Description
(if-index)	Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number	interface index of the port

Command Output

Table 109.15-2 "xDSL Counters Near End Line Current 15 Min" Display parameters

Specific Information		
name	Type	Description
los	Parameter type: <Counter> - 32 bit counter	number of occurrences of an LOS failure event <i>This element is always shown.</i>
loss	Parameter type: <Counter> - 32 bit counter	number of occurrences of an LOSS failure event <i>This element is always shown.</i>
lof	Parameter type: <Counter>	number of occurrences of an LOF

name	Type	Description
	- 32 bit counter	failure event <i>This element is always shown.</i>
lom	Parameter type: <Counter> - 32 bit counter	number of occurrences of a LOM failure event <i>This element is always shown.</i>
ese	Parameter type: <Counter> - 32 bit counter	number of occurrences of an ESE failure event <i>This element is always shown.</i>
es	Parameter type: <Counter> - 32 bit counter	number of errored seconds encountered by the line <i>This element is always shown.</i>
ses	Parameter type: <Counter> - 32 bit counter	number of severely errored seconds encountered by the line <i>This element is always shown.</i>
uas	Parameter type: <Counter> - 32 bit counter	number of unavailable seconds encountered by the line <i>This element is always shown.</i>
re-init	Parameter type: <Counter> - 32 bit counter	number of times the modem re-initialize the line. Only applicable for ADSLx/VDSLx. <i>This element is always shown.</i>
failed-init	Parameter type: <Counter> - 32 bit counter	number of times the modem failed to initialize the line <i>This element is always shown.</i>
measured-time	Parameter type: <Xdsl::PrevCurIntervalMeasureTime> - the measured time interval - unit: sec - range: [0...900]	amount of time in sec that statistics have been counted <i>This element is only shown in detail mode.</i>
in-valid-flag	Parameter type: <Xdsl::IntervalValidityFlag> (true false) Possible values: - true : data is not valid - false : data is valid	validity of the corresponding PM data <i>This element is only shown in detail mode.</i>
ra-upshift short name: rau	Parameter type: <Counter> - 32 bit counter	number of occurrences of a Upshift Rate Adaptation <i>This element is always shown.</i>
ra-downshift short name: rad	Parameter type: <Counter> - 32 bit counter	number of occurrences of a Downshift Rate Adaptation <i>This element is always shown.</i>
leftrs	Parameter type: <Counter> - 32 bit counter	number of leftr seconds encountered by the line <i>This element is always shown.</i>
err-free-bits	Parameter type: <Counter> - 32 bit counter	count of the number of error freebits divided by 2 ¹⁶ <i>This element is always shown.</i>
min-eftr	Parameter type: <Xdsl::SignedIntegerKbps> - 1000 bits per second - unit: kbits/sec	minimum error free throughput observed <i>This element is always shown.</i>
dle	Parameter type: <Counter> - 32 bit counter	counter for disorderly leaving failure events, not applicable for GFAST a zero value will be returned <i>This element is always shown.</i>
fecs	Parameter type: <Counter> - 32 bit counter	forward error correction second <i>This element is always shown.</i>
init-count	Parameter type: <Counter>	full init counter

name	Type	Description
	- 32 bit counter	<i>This element is always shown.</i>
sos-success-count	Parameter type: <Counter> - 32 bit counter	counts number of sos are successful. Only applicable for VDSL2. <i>This element is always shown.</i>

109.16 xDSL Counters Near End Line Current Day

Command Description

This command displays the xDSL counters near end line current day.

User Level

The command can be accessed by operators with xdsl privileges.

Command Syntax

The command has the following syntax:

```
> show xdsl counters near-end line current-1day [ (if-index) ]
```

Command Parameters

Table 109.16-1 "xDSL Counters Near End Line Current Day" Resource Parameters

Resource Identifier	Type	Description
(if-index)	Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number	interface index of the port

Command Output

Table 109.16-2 "xDSL Counters Near End Line Current Day" Display parameters

Specific Information		
name	Type	Description
los	Parameter type: <Counter> - 32 bit counter	number of occurrences of an LOS failure event <i>This element is always shown.</i>
loss	Parameter type: <Counter> - 32 bit counter	number of occurrences of an LOSS failure event <i>This element is always shown.</i>
lof	Parameter type: <Counter> - 32 bit counter	number of occurrences of an LOF failure event <i>This element is always shown.</i>
lom	Parameter type: <Counter>	number of occurrences of a LOM

name	Type	Description
	- 32 bit counter	failure event <i>This element is always shown.</i>
ese	Parameter type: <Counter> - 32 bit counter	number of occurrences of an ESE failure event <i>This element is always shown.</i>
es	Parameter type: <Counter> - 32 bit counter	number of errored seconds encountered by the line <i>This element is always shown.</i>
ses	Parameter type: <Counter> - 32 bit counter	number of severely errored seconds encountered by the line <i>This element is always shown.</i>
uas	Parameter type: <Counter> - 32 bit counter	number of unavailable seconds encountered by the line <i>This element is always shown.</i>
re-init	Parameter type: <Counter> - 32 bit counter	number of times the modem re-initialize the line. Only applicable for ADSLx/VDSLx. <i>This element is always shown.</i>
failed-init	Parameter type: <Counter> - 32 bit counter	number of times the modem failed to initialize the line <i>This element is always shown.</i>
measured-time	Parameter type: <Xdsl::IntervalMeasureTime> - the measured time interval - unit: sec - range: [0...86400]	amount of time in sec that statistics have been counted <i>This element is only shown in detail mode.</i>
in-valid-flag	Parameter type: <Xdsl::IntervalValidityFlag> (true false) Possible values: - true : data is not valid - false : data is valid	validity of the corresponding PM data <i>This element is only shown in detail mode.</i>
ra-upshift short name: rau	Parameter type: <Counter> - 32 bit counter	number of occurrences of a Upshift Rate Adaptation <i>This element is always shown.</i>
ra-downshift short name: rad	Parameter type: <Counter> - 32 bit counter	number of occurrences of a Downshift Rate Adaptation <i>This element is always shown.</i>
leftrs	Parameter type: <Counter> - 32 bit counter	number of leftr seconds encountered by the line <i>This element is always shown.</i>
err-free-bits	Parameter type: <Counter> - 32 bit counter	count of the number of error freebits divided by 2^{16} <i>This element is always shown.</i>
min-eftr	Parameter type: <Xdsl::SignedIntegerKbps> - 1000 bits per second - unit: kbits/sec	minimum error free throughput observed <i>This element is always shown.</i>
dle	Parameter type: <Counter> - 32 bit counter	counter for disorderly leaving failure events <i>This element is always shown.</i>
fecs	Parameter type: <Counter> - 32 bit counter	forward error correction second <i>This element is always shown.</i>
init-count	Parameter type: <Counter> - 32 bit counter	full init counter <i>This element is always shown.</i>
sos-success-count	Parameter type: <Counter> - 32 bit counter	counts number of sos are successful. Only applicable for VDSL2. <i>This element is always shown.</i>

109.17 xDSL Counters Near End Line Previous 15 Min

Command Description

This command displays the xDSL counters near end line previous 15 min.

User Level

The command can be accessed by operators with xdsl privileges.

Command Syntax

The command has the following syntax:

```
> show xdsl counters near-end line previous-interval [ (if-index) [ interval-no <Xdsl::IntervalNumber15min> ] ]
```

Command Parameters

Table 109.17-1 "xDSL Counters Near End Line Previous 15 Min" Resource Parameters

Resource Identifier	Type	Description
(if-index)	Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number	interface index of the port
interval-no	Parameter type: <Xdsl::IntervalNumber15min> Format: - a number identifying 15 minutes interval time - range: [1...192]	identifies prev 15min intvls, val 1 as the latest intvl

Command Output

Table 109.17-2 "xDSL Counters Near End Line Previous 15 Min" Display parameters

Specific Information		
name	Type	Description
los	Parameter type: <Counter> - 32 bit counter	number of occurrences of an LOS failure event <i>This element is always shown.</i>

109 xDSL Status Commands

name	Type	Description
loss	Parameter type: <Counter> - 32 bit counter	number of occurrences of an LOSS failure event <i>This element is always shown.</i>
lof	Parameter type: <Counter> - 32 bit counter	number of occurrences of an LOF failure event <i>This element is always shown.</i>
lom	Parameter type: <Counter> - 32 bit counter	number of occurrences of a LOM failure event <i>This element is always shown.</i>
ese	Parameter type: <Counter> - 32 bit counter	number of occurrences of an ESE failure event <i>This element is always shown.</i>
es	Parameter type: <Counter> - 32 bit counter	number of errored seconds encountered by the line <i>This element is always shown.</i>
ses	Parameter type: <Counter> - 32 bit counter	number of severely errored seconds encountered by the line <i>This element is always shown.</i>
uas	Parameter type: <Counter> - 32 bit counter	number of unavailable seconds encountered by the line <i>This element is always shown.</i>
re-init	Parameter type: <Counter> - 32 bit counter	number of times the modem re-initialize the line. Only applicable for ADSLx/VDSLx. <i>This element is always shown.</i>
fail-init	Parameter type: <Counter> - 32 bit counter	number of times the modem failed to initialize the line <i>This element is always shown.</i>
measured-time	Parameter type: <Xdsl::PrevCurIntervalMeasureTime> - the measured time interval - unit: sec - range: [0...900]	amount of time in sec that statistics have been counted <i>This element is always shown.</i>
invalid-flag	Parameter type: <Xdsl::IntervalValidityFlag> (true false) Possible values: - true : data is not valid - false : data is valid	validity of the corresponding PM data <i>This element is always shown.</i>
ra-upshift short name: rau	Parameter type: <Counter> - 32 bit counter	number of occurrences of a Upshift Rate Adaptation <i>This element is always shown.</i>
ra-downshift short name: rad	Parameter type: <Counter> - 32 bit counter	number of occurrences of a Downshift Rate Adaptation <i>This element is always shown.</i>
leftrs	Parameter type: <Counter> - 32 bit counter	number of leftr seconds encountered by the line <i>This element is always shown.</i>
err-free-bits	Parameter type: <Counter> - 32 bit counter	count of the number of error freebits divided by 2 ¹⁶ <i>This element is always shown.</i>
min-eftr	Parameter type: <Xdsl::SignedIntegerKbps> - 1000 bits per second - unit: kbits/sec	count of the minimum of the error free throughput observed <i>This element is always shown.</i>
dle	Parameter type: <Counter> - 32 bit counter	counter for disorderly leaving failure events <i>This element is always shown.</i>
fecs	Parameter type: <Counter>	forward error correction second

name	Type	Description
	- 32 bit counter	<i>This element is always shown.</i>
init-count	Parameter type: <Counter> - 32 bit counter	full init counter <i>This element is always shown.</i>
interval-time	Parameter type: <Xdsl::PmTimeStamp> - Timestamp for Pm interval(yyyymmdd:hour:minutes)	specifies the start time of interval <i>This element is always shown.</i>
sos-success-count	Parameter type: <Counter> - 32 bit counter	counts number of sos are successful. Only applicable for VDSL2. <i>This element is always shown.</i>

109.18 xDSL Counters Near End Of Line Previous Day

Command Description

This command displays the xDSL counters near end of the previous day.

User Level

The command can be accessed by operators with xdsl privileges.

Command Syntax

The command has the following syntax:

```
> show xdsl counters near-end line previous-1day [ (if-index) [ interval-no <Xdsl::IntervalNumber1day> ] ]
```

Command Parameters

Table 109.18-1 "xDSL Counters Near End Of Line Previous Day" Resource Parameters

Resource Identifier	Type	Description
(if-index)	Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number	interface index of the port
interval-no	Parameter type: <Xdsl::IntervalNumber1day> Format: - a number identifying 1 day interval time - range: [1...7]	nbr identifying previous 1 day intvl time, value 1 is the most recently completed 1 day intvl

Command Output

Table 109.18-2 "xDSL Counters Near End Of Line Previous Day" Display parameters

Specific Information		
name	Type	Description
los	Parameter type: <Counter> - 32 bit counter	number of occurrences of an LOS failure event <i>This element is always shown.</i>

name	Type	Description
loss	Parameter type: <Counter> - 32 bit counter	number of occurrences of an LOSS failure event <i>This element is always shown.</i>
lof	Parameter type: <Counter> - 32 bit counter	number of occurrences of an LOF failure event <i>This element is always shown.</i>
lom	Parameter type: <Counter> - 32 bit counter	number of occurrences of a LOM failure event <i>This element is always shown.</i>
ese	Parameter type: <Counter> - 32 bit counter	number of occurrences of an ESE failure event <i>This element is always shown.</i>
es	Parameter type: <Counter> - 32 bit counter	number of errored seconds encountered by the line <i>This element is always shown.</i>
ses	Parameter type: <Counter> - 32 bit counter	number of severely errored seconds encountered by the line <i>This element is always shown.</i>
uas	Parameter type: <Counter> - 32 bit counter	number of unavailable seconds encountered by the line <i>This element is always shown.</i>
re-init	Parameter type: <Counter> - 32 bit counter	number of times the modem re-initialize the line. Only applicable for ADSLx/VDSLx. <i>This element is always shown.</i>
failed-init	Parameter type: <Counter> - 32 bit counter	number of times the modem failed to initialize the line <i>This element is always shown.</i>
measured-time	Parameter type: <Xdsl::IntervalMeasureTime> - the measured time interval - unit: sec - range: [0...86400]	amount of time in sec that statistics have been counted <i>This element is only shown in detail mode.</i>
in-valid-flag	Parameter type: <Xdsl::IntervalValidityFlag> (true false) Possible values: - true : data is not valid - false : data is valid	validity of the corresponding PM data <i>This element is only shown in detail mode.</i>
ra-upshift short name: rau	Parameter type: <Counter> - 32 bit counter	number of occurrences of a Upshift Rate Adaptation <i>This element is always shown.</i>
ra-downshift short name: rad	Parameter type: <Counter> - 32 bit counter	number of occurrences of a Downshift Rate Adaptation <i>This element is always shown.</i>
leftrs	Parameter type: <Counter> - 32 bit counter	number of leftr seconds encountered by the line <i>This element is always shown.</i>
err-free-bits	Parameter type: <Counter> - 32 bit counter	count of the number of error freebits divided by 2^{16} <i>This element is always shown.</i>
min-eftr	Parameter type: <Xdsl::SignedIntegerKbps> - 1000 bits per second - unit: kbits/sec	count of the minimum of the error free throughput observed <i>This element is always shown.</i>
dle	Parameter type: <Counter> - 32 bit counter	counter for disorderly leaving failure events <i>This element is always shown.</i>
fecs	Parameter type: <Counter>	forward error correction second

109 xDSL Status Commands

name	Type	Description
	- 32 bit counter	<i>This element is always shown.</i>
init-count	Parameter type: <Counter> - 32 bit counter	full init counter <i>This element is always shown.</i>
sos-success-count	Parameter type: <Counter> - 32 bit counter	counts number of sos are successful. Only applicable for VDSL2. <i>This element is always shown.</i>
interval-time	Parameter type: <Xdsl::PmTimeStamp> - Timestamp for Pm interval(yyyymmdd:hour:minutes)	specifies the start time of interval <i>This element is always shown.</i>

109.19 xDSL Counters Near End Channel Current 15 Min

Command Description

CEC parameter only applies to VDSL2.

CEC: Number of uncorrected codewords encountered by near-end (or far-end) channel in VDSL2 mode.

User Level

The command can be accessed by operators with xdsl privileges.

Command Syntax

The command has the following syntax:

> show xdsl counters near-end channel current-interval [(if-index)]

Command Parameters

Table 109.19-1 "xDSL Counters Near End Channel Current 15 Min" Resource Parameters

Resource Identifier	Type	Description
(if-index)	Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number	interface index of the port

Command Output

Table 109.19-2 "xDSL Counters Near End Channel Current 15 Min" Display parameters

Specific Information		
name	Type	Description
cv	Parameter type: <Counter> - 32 bit counter	number of coding violations encountered by the channel <i>This element is always shown.</i>
fecc	Parameter type: <Counter> - 32 bit counter	number of corrected codewords encountered by the channel, respectively corrected octets in

109 xDSL Status Commands

name	Type	Description
		case of vdsl1 G.993.1 <i>This element is always shown.</i>
cec	Parameter type: <Counter> - 32 bit counter	the number of non-corrected erroneous codewords encountered by the near end channel <i>This element is always shown.</i>
measured-time	Parameter type: <Xdsl::PrevCurIntervalMeasureTime> - the measured time interval - unit: sec - range: [0...900]	amt of time in sec that statistics have been counted <i>This element is always shown.</i>
in-valid-flag	Parameter type: <Xdsl::IntervalValidityFlag> (true false) Possible values: - true : data is not valid - false : data is valid	validity of the corresponding PM data <i>This element is always shown.</i>
rtx-c-up	Parameter type: <Counter> - 32 bit counter	the total number of detected errored DTUs which have been successfully corrected by a retransmission as seen by the near-end receiver. Only applicable for VDSL2. <i>This element is always shown.</i>
rtx-uc-up	Parameter type: <Counter> - 32 bit counter	the total number of detected errored DTUs which have not been corrected by one or more retransmissions <i>This element is always shown.</i>
rtx-tx-down	Parameter type: <Counter> - 32 bit counter	the total number of retransmitted DTUs by the transmitter <i>This element is always shown.</i>

109.20 xDSL Counters Near End Channel Current Day

Command Description

CEC parameter only applies to VDSL2.

CEC: Number of uncorrected codewords encountered by near-end (or far-end) channel in VDSL2 mode.

User Level

The command can be accessed by operators with xdsl privileges.

Command Syntax

The command has the following syntax:

```
> show xdsl counters near-end channel current-1day [ (if-index) ]
```

Command Parameters

Table 109.20-1 "xDSL Counters Near End Channel Current Day" Resource Parameters

Resource Identifier	Type	Description
(if-index)	Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number	interface index of the port

Command Output

Table 109.20-2 "xDSL Counters Near End Channel Current Day" Display parameters

Specific Information		
name	Type	Description
cv	Parameter type: <Counter> - 32 bit counter	number of coding violations encountered by the channel <i>This element is always shown.</i>
fecc	Parameter type: <Counter> - 32 bit counter	number of corrected codewords encountered by the channel, respectively corrected octets in

109 xDSL Status Commands

name	Type	Description
		case of vdsl1 G.993.1 <i>This element is always shown.</i>
cec	Parameter type: <Counter> - 32 bit counter	the number of non-corrected erroneous codewords encountered by the near end channel <i>This element is always shown.</i>
measured-time	Parameter type: <Xdsl::IntervalMeasureTime> - the measured time interval - unit: sec - range: [0...86400]	amt of time in sec that statistics have been counted <i>This element is always shown.</i>
in-valid-flag	Parameter type: <Xdsl::IntervalValidityFlag> (true false) Possible values: - true : data is not valid - false : data is valid	validity of the corresponding PM data <i>This element is always shown.</i>
rtx-c-up	Parameter type: <Counter> - 32 bit counter	the total number of detected errored DTUs which have been successfully corrected by a retransmission as seen by the near-end receiver. Only applicable for VDSL2. <i>This element is always shown.</i>
rtx-uc-up	Parameter type: <Counter> - 32 bit counter	the total number of detected errored DTUs which have not been corrected by one or more retransmissions <i>This element is always shown.</i>
rtx-tx-down	Parameter type: <Counter> - 32 bit counter	the total number of retransmitted DTUs by the transmitter <i>This element is always shown.</i>

109.21 xDSL Counters Near End Channel Previous 15 Min

Command Description

CEC parameter only applies to VDSL2.

CEC: Number of uncorrected codewords encountered by near-end (or far-end) channel in VDSL2 mode.

User Level

The command can be accessed by operators with xdsl privileges.

Command Syntax

The command has the following syntax:

```
> show xdsl counters near-end channel previous-interval [ (if-index) [ interval-no <Xdsl::IntervalNumber15min> ] ]
```

Command Parameters

Table 109.21-1 "xDSL Counters Near End Channel Previous 15 Min" Resource Parameters

Resource Identifier	Type	Description
(if-index)	Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number	interface index of the port
interval-no	Parameter type: <Xdsl::IntervalNumber15min> Format: - a number identifying 15 minutes interval time - range: [1...192]	nbr identifying previous 15 min intvl time, value 1 is the most recently completed 15 min intvl

Command Output

Table 109.21-2 "xDSL Counters Near End Channel Previous 15 Min" Display parameters

Specific Information		
name	Type	Description
cv	Parameter type: <Counter>	number of coding violations

109 xDSL Status Commands

name	Type	Description
	- 32 bit counter	encountered by the channel <i>This element is always shown.</i>
fecc	Parameter type: <Counter> - 32 bit counter	number of corrected codewords encountered by the channel, respectively corrected octets in case of vdsl1 G.993.1 <i>This element is always shown.</i>
cec	Parameter type: <Counter> - 32 bit counter	the number of non-corrected erroneous codewords encountered by the near end channel <i>This element is always shown.</i>
measured-time	Parameter type: <Xdsl::PrevCurIntervalMeasureTime> - the measured time interval - unit: sec - range: [0...900]	amt of time in sec that statistics have been counted <i>This element is always shown.</i>
in-valid-flag	Parameter type: <Xdsl::IntervalValidityFlag> (true false) Possible values: - true : data is not valid - false : data is valid	validity of the corresponding PM data <i>This element is always shown.</i>
rtx-c-up	Parameter type: <Counter> - 32 bit counter	the total number of detected errored DTUs which have been successfully corrected by a retransmission as seen by the near-end receiver. Only applicable for VDSL2. <i>This element is always shown.</i>
rtx-uc-up	Parameter type: <Counter> - 32 bit counter	the total number of detected errored DTUs which have not been corrected by one or more retransmissions <i>This element is always shown.</i>
rtx-tx-down	Parameter type: <Counter> - 32 bit counter	the total number of retransmitted DTUs by the transmitter <i>This element is always shown.</i>
interval-time	Parameter type: <Xdsl::PmTimeStamp> - Timestamp for Pm interval(yyyymmdd:hour:minutes)	specifies the start time of interval <i>This element is always shown.</i>

109.22 xDSL Counters Near End Channel Previous Day

Command Description

CEC parameter only applies to VDSL2.

CEC: Number of uncorrected codewords encountered by near-end (or far-end) channel in VDSL2 mode.

User Level

The command can be accessed by operators with xdsl privileges.

Command Syntax

The command has the following syntax:

```
> show xdsl counters near-end channel previous-1day [ (if-index) [ interval-no <Xdsl::IntervalNumber1day> ] ]
```

Command Parameters

Table 109.22-1 "xDSL Counters Near End Channel Previous Day" Resource Parameters

Resource Identifier	Type	Description
(if-index)	Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number	interface index of the port
interval-no	Parameter type: <Xdsl::IntervalNumber1day> Format: - a number identifying 1 day interval time - range: [1...7]	nbr identifying previous 1 day intvl time, value 1 is the most recently completed 1 day intvl

Command Output

Table 109.22-2 "xDSL Counters Near End Channel Previous Day" Display parameters

Specific Information		
name	Type	Description
cv	Parameter type: <Counter> - 32 bit counter	number of coding violations encountered by the channel

name	Type	Description
		<i>This element is always shown.</i>
fecc	Parameter type: <Counter> - 32 bit counter	number of corrected codewords encountered by the channel, respectively corrected octets in case of vdsl1 G.993.1 <i>This element is always shown.</i>
cec	Parameter type: <Counter> - 32 bit counter	the number of non-corrected erroneous codewords encountered by the near end channel <i>This element is always shown.</i>
measured-time	Parameter type: <Xdsl::IntervalMeasureTime> - the measured time interval - unit: sec - range: [0...86400]	amount of time in sec that statistics have been counted <i>This element is always shown.</i>
in-valid-flag	Parameter type: <Xdsl::IntervalValidityFlag> (true false) Possible values: - true : data is not valid - false : data is valid	validity of the corresponding PM data <i>This element is always shown.</i>
rtx-c-up	Parameter type: <Counter> - 32 bit counter	the total number of detected errored DTUs which have been successfully corrected by a retransmission as seen by the near-end receiver. Only applicable for VDSL2. <i>This element is always shown.</i>
rtx-uc-up	Parameter type: <Counter> - 32 bit counter	the total number of detected errored DTUs which have not been corrected by one or more retransmissions <i>This element is always shown.</i>
rtx-tx-down	Parameter type: <Counter> - 32 bit counter	the total number of retransmitted DTUs by the transmitter <i>This element is always shown.</i>
interval-time	Parameter type: <Xdsl::PmTimeStamp> - Timestamp for Pm interval(yyyymmdd:hour:minutes)	specifies the start time of interval <i>This element is always shown.</i>

109.23 xDSL Counters Far End Line Current 15 Min

Command Description

This command displays xDSL counters far end line current 15 min.

User Level

The command can be accessed by operators with xdsl privileges.

Command Syntax

The command has the following syntax:

> show xdsl counters far-end line current-interval [(if-index)]

Command Parameters

Table 109.23-1 "xDSL Counters Far End Line Current 15 Min" Resource Parameters

Resource Identifier	Type	Description
(if-index)	Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number	interface index of the xdsl port

Command Output

Table 109.23-2 "xDSL Counters Far End Line Current 15 Min" Display parameters

Specific Information		
name	Type	Description
los	Parameter type: <Counter> - 32 bit counter	number of occurrences of an los failure event <i>This element is always shown.</i>
loss	Parameter type: <Counter> - 32 bit counter	number of occurrences of an loss failure event <i>This element is always shown.</i>
lof	Parameter type: <Counter> - 32 bit counter	number of occurrences of an lof failure event <i>This element is always shown.</i>
lom	Parameter type: <Counter>	number of occurrences of an lom

109 xDSL Status Commands

name	Type	Description
	- 32 bit counter	failure event <i>This element is always shown.</i>
lpr	Parameter type: <Counter> - 32 bit counter	number of occurrences of an lpr failure event <i>This element is always shown.</i>
lol	Parameter type: <Counter> - 32 bit counter	number of occurrences of an lol failure event <i>This element is always shown.</i>
ese	Parameter type: <Counter> - 32 bit counter	number of occurrences of an ese failure event <i>This element is always shown.</i>
es	Parameter type: <Counter> - 32 bit counter	number of errored seconds encountered by the line <i>This element is always shown.</i>
ses	Parameter type: <Counter> - 32 bit counter	number of severely errored seconds encountered by the line <i>This element is always shown.</i>
uas	Parameter type: <Counter> - 32 bit counter	number of unavailable seconds encountered by the line <i>This element is always shown.</i>
measured-time	Parameter type: <Xdsl::PrevCurIntervalMeasureTime> - the measured time interval - unit: sec - range: [0...900]	amount of time in sec that statistics have been counted <i>This element is always shown.</i>
in-valid-flag	Parameter type: <Xdsl::IntervalValidityFlag> (true false) Possible values: - true : data is not valid - false : data is valid	validity of the corresponding PM data <i>This element is always shown.</i>
ra-upshift short name: rau	Parameter type: <Counter> - 32 bit counter	number of occurrences of a Upshift Rate Adaptation <i>This element is always shown.</i>
ra-downshift short name: rad	Parameter type: <Counter> - 32 bit counter	number of occurrences of a Downshift Rate Adaptation <i>This element is always shown.</i>
leftrs	Parameter type: <Counter> - 32 bit counter	number of leftrs seconds encountered by the line <i>This element is always shown.</i>
err-free-bits	Parameter type: <Counter> - 32 bit counter	count of the number of error freebits divided by 2 ¹⁶ <i>This element is always shown.</i>
min-eftr	Parameter type: <Xdsl::SignedIntegerKbps> - 1000 bits per second - unit: kbits/sec	count of the minimum of the error free throughput observed <i>This element is always shown.</i>
fecs	Parameter type: <Counter> - 32 bit counter	forward error correction second <i>This element is always shown.</i>
sos-success-count	Parameter type: <Counter> - 32 bit counter	counts number of sos are successful. Only applicable for VDSL2. <i>This element is always shown.</i>

109.24 xDSL Counters Far End Line Current Day

Command Description

This command displays xDSL counters far end line current day.

User Level

The command can be accessed by operators with xdsl privileges.

Command Syntax

The command has the following syntax:

```
> show xdsl counters far-end line current-1day [ (if-index) ]
```

Command Parameters

Table 109.24-1 "xDSL Counters Far End Line Current Day" Resource Parameters

Resource Identifier	Type	Description
(if-index)	Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number	interface index of the port

Command Output

Table 109.24-2 "xDSL Counters Far End Line Current Day" Display parameters

Specific Information		
name	Type	Description
los	Parameter type: <Counter> - 32 bit counter	number of occurrences of an los failure event <i>This element is always shown.</i>
loss	Parameter type: <Counter> - 32 bit counter	number of occurrences of an loss failure event <i>This element is always shown.</i>
lof	Parameter type: <Counter> - 32 bit counter	number of occurrences of an lof failure event <i>This element is always shown.</i>
lom	Parameter type: <Counter>	number of occurrences of an lom

109 xDSL Status Commands

name	Type	Description
	- 32 bit counter	failure event <i>This element is always shown.</i>
lpr	Parameter type: <Counter> - 32 bit counter	number of occurrences of an lpr failure event <i>This element is always shown.</i>
lol	Parameter type: <Counter> - 32 bit counter	number of occurrences of an lol failure event <i>This element is always shown.</i>
ese	Parameter type: <Counter> - 32 bit counter	number of occurrences of an ese failure event <i>This element is always shown.</i>
es	Parameter type: <Counter> - 32 bit counter	number of errored seconds encountered by the line <i>This element is always shown.</i>
ses	Parameter type: <Counter> - 32 bit counter	number of severely errored seconds encountered by the line <i>This element is always shown.</i>
uas	Parameter type: <Counter> - 32 bit counter	number of unavailable seconds encountered by the line <i>This element is always shown.</i>
measured-time	Parameter type: <Xdsl::IntervalMeasureTime> - the measured time interval - unit: sec - range: [0...86400]	amount of time in sec that statistics have been counted <i>This element is only shown in detail mode.</i>
in-valid-flag	Parameter type: <Xdsl::IntervalValidityFlag> (true false) Possible values: - true : data is not valid - false : data is valid	validity of the corresponding PM data <i>This element is only shown in detail mode.</i>
ra-upshift short name: rau	Parameter type: <Counter> - 32 bit counter	number of occurrences of a Upshift Rate Adaptation <i>This element is always shown.</i>
ra-downshift short name: rad	Parameter type: <Counter> - 32 bit counter	number of occurrences of a Downshift Rate Adaptation <i>This element is always shown.</i>
leftrs	Parameter type: <Counter> - 32 bit counter	number of leftrs seconds encountered by the line <i>This element is always shown.</i>
err-free-bits	Parameter type: <Counter> - 32 bit counter	count of the number of error freebits divided by 2 ¹⁶ <i>This element is always shown.</i>
min-eftr	Parameter type: <Xdsl::SignedIntegerKbps> - 1000 bits per second - unit: kbits/sec	count of the minimum of the error free throughput observed <i>This element is always shown.</i>
fecs	Parameter type: <Counter> - 32 bit counter	forward error correction second <i>This element is always shown.</i>
sos-success-count	Parameter type: <Counter> - 32 bit counter	counts number of sos are successful. Only applicable for VDSL2. <i>This element is always shown.</i>

109.25 xDSL Counters Far End Line Previous 15 Min

Command Description

This command displays xDSL counters far end line previous 15 min.

User Level

The command can be accessed by operators with xdsl privileges.

Command Syntax

The command has the following syntax:

```
> show xdsl counters far-end line previous-interval [ (if-index) [ interval-no <Xdsl::IntervalNumber15min> ] ]
```

Command Parameters

Table 109.25-1 "xDSL Counters Far End Line Previous 15 Min" Resource Parameters

Resource Identifier	Type	Description
(if-index)	Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number	interface index of the port
interval-no	Parameter type: <Xdsl::IntervalNumber15min> Format: - a number identifying 15 minutes interval time - range: [1...192]	nbr identifying previous 15 min intvl time, value 1 is the most recently completed 15 min intvl

Command Output

Table 109.25-2 "xDSL Counters Far End Line Previous 15 Min" Display parameters

Specific Information		
name	Type	Description
los	Parameter type: <Counter> - 32 bit counter	number of occurrences of an los failure event <i>This element is always shown.</i>

name	Type	Description
loss	Parameter type: <Counter> - 32 bit counter	number of occurrences of an loss failure event <i>This element is always shown.</i>
lof	Parameter type: <Counter> - 32 bit counter	number of occurrences of an lof failure event <i>This element is always shown.</i>
lom	Parameter type: <Counter> - 32 bit counter	number of occurrences of an lom failure event <i>This element is always shown.</i>
lpr	Parameter type: <Counter> - 32 bit counter	number of occurrences of an lpr failure event <i>This element is always shown.</i>
lol	Parameter type: <Counter> - 32 bit counter	number of occurrences of an lol failure event <i>This element is always shown.</i>
ese	Parameter type: <Counter> - 32 bit counter	number of occurrences of an ese failure event <i>This element is always shown.</i>
es	Parameter type: <Counter> - 32 bit counter	number of errored seconds encountered by the line <i>This element is always shown.</i>
ses	Parameter type: <Counter> - 32 bit counter	number of severely errored seconds encountered by the line <i>This element is always shown.</i>
uas	Parameter type: <Counter> - 32 bit counter	number of unavailable seconds encountered by the line <i>This element is always shown.</i>
measured-time	Parameter type: <Xdsl::PrevCurIntervalMeasureTime> - the measured time interval - unit: sec - range: [0...900]	amount of time in sec that statistics have been counted <i>This element is only shown in detail mode.</i>
in-valid-flag	Parameter type: <Xdsl::IntervalValidityFlag> (true false) Possible values: - true : data is not valid - false : data is valid	validity of the corresponding PM data <i>This element is only shown in detail mode.</i>
ra-upshift short name: rau	Parameter type: <Counter> - 32 bit counter	number of occurrences of a Upshift Rate Adaptation <i>This element is always shown.</i>
ra-downshift short name: rad	Parameter type: <Counter> - 32 bit counter	number of occurrences of a Downshift Rate Adaptation <i>This element is always shown.</i>
leftrs	Parameter type: <Counter> - 32 bit counter	number of leftrs seconds encountered by the line <i>This element is always shown.</i>
err-free-bits	Parameter type: <Counter> - 32 bit counter	count of the number of error freebits divided by 2^{16} <i>This element is always shown.</i>
min-eftr	Parameter type: <Xdsl::SignedIntegerKbps> - 1000 bits per second - unit: kbits/sec	count of the minimum of the error free throughput observed <i>This element is always shown.</i>
fecs	Parameter type: <Counter> - 32 bit counter	forward error correction second <i>This element is always shown.</i>
sos-success-count	Parameter type: <Counter> - 32 bit counter	counts number of sos are successful. Only applicable for VDSL2.

name	Type	Description
		<i>This element is always shown.</i>
interval-time	Parameter type: <Xdsl::PmTimeStamp> - Timestamp for Pm interval(yyyymmdd:hour:minutes)	specifies the start time of interval <i>This element is always shown.</i>

109.26 xDSL Counters Far End Line Previous Day

Command Description

This command displays xDSL counters far end line previous day.

User Level

The command can be accessed by operators with xdsl privileges.

Command Syntax

The command has the following syntax:

```
> show xdsl counters far-end line previous-1day [ (if-index) [ interval-no <Xdsl::IntervalNumber1day> ] ]
```

Command Parameters

Table 109.26-1 "xDSL Counters Far End Line Previous Day" Resource Parameters

Resource Identifier	Type	Description
(if-index)	Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number	interface index of the port
interval-no	Parameter type: <Xdsl::IntervalNumber1day> Format: - a number identifying 1 day interval time - range: [1...7]	nbr identifying previous 1 day intvl time, value 1 is the most recently completed 1 day intvl

Command Output

Table 109.26-2 "xDSL Counters Far End Line Previous Day" Display parameters

Specific Information		
name	Type	Description
los	Parameter type: <Counter> - 32 bit counter	number of occurrences of an los failure event <i>This element is always shown.</i>
loss	Parameter type: <Counter> - 32 bit counter	number of occurrences of an loss failure event <i>This element is always shown.</i>

name	Type	Description
lof	Parameter type: <Counter> - 32 bit counter	number of occurrences of an lof failure event <i>This element is always shown.</i>
lom	Parameter type: <Counter> - 32 bit counter	number of occurrences of an lom failure event <i>This element is always shown.</i>
lpr	Parameter type: <Counter> - 32 bit counter	number of occurrences of an lpr failure event <i>This element is always shown.</i>
lol	Parameter type: <Counter> - 32 bit counter	number of occurrences of an lol failure event <i>This element is always shown.</i>
ese	Parameter type: <Counter> - 32 bit counter	number of occurrences of an ese failure event <i>This element is always shown.</i>
es	Parameter type: <Counter> - 32 bit counter	number of errored seconds encountered by the line <i>This element is always shown.</i>
ses	Parameter type: <Counter> - 32 bit counter	number of severely errored seconds encountered by the line <i>This element is always shown.</i>
uas	Parameter type: <Counter> - 32 bit counter	number of unavailable seconds encountered by the line <i>This element is always shown.</i>
measured-time	Parameter type: <Xdsl::IntervalMeasureTime> - the measured time interval - unit: sec - range: [0...86400]	amount of time in sec that statistics have been counted <i>This element is only shown in detail mode.</i>
in-valid-flag	Parameter type: <Xdsl::IntervalValidityFlag> (true false) Possible values: - true : data is not valid - false : data is valid	validity of the corresponding PM data <i>This element is only shown in detail mode.</i>
ra-upshift short name: rau	Parameter type: <Counter> - 32 bit counter	number of occurrences of a Upshift Rate Adaptation <i>This element is always shown.</i>
ra-downshift short name: rad	Parameter type: <Counter> - 32 bit counter	number of occurrences of a Downshift Rate Adaptation <i>This element is always shown.</i>
leftrs	Parameter type: <Counter> - 32 bit counter	number of leftrs seconds encountered by the line <i>This element is always shown.</i>
err-free-bits	Parameter type: <Counter> - 32 bit counter	count of the number of error freebits divided by 2 ¹⁶ <i>This element is always shown.</i>
min-eftr	Parameter type: <Xdsl::SignedIntegerKbps> - 1000 bits per second - unit: kbits/sec	count of the minimum of the error free throughput observed <i>This element is always shown.</i>
fecs	Parameter type: <Counter> - 32 bit counter	forward error correction second <i>This element is always shown.</i>
sos-success-count	Parameter type: <Counter> - 32 bit counter	counts number of sos are successful. Only applicable for VDSL2. <i>This element is always shown.</i>
interval-time	Parameter type: <Xdsl::PmTimeStamp> - Timestamp for Pm interval(yyyymmdd:hour:minutes)	specifies the start time of interval <i>This element is always shown.</i>

109.27 xDSL Counters Far End Channel Current 15 Min

Command Description

CEC parameter only applies to VDSL2.

CEC: Number of uncorrected codewords encountered by near-end (or far-end) channel in VDSL2 mode.

User Level

The command can be accessed by operators with xdsl privileges.

Command Syntax

The command has the following syntax:

```
> show xdsl counters far-end channel current-interval [ (if-index) ]
```

Command Parameters

Table 109.27-1 "xDSL Counters Far End Channel Current 15 Min" Resource Parameters

Resource Identifier	Type	Description
(if-index)	Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number	interface index of the port

Command Output

Table 109.27-2 "xDSL Counters Far End Channel Current 15 Min" Display parameters

Specific Information		
name	Type	Description
cv	Parameter type: <Counter> - 32 bit counter	nbr of coding violations encountered by far end channel <i>This element is always shown.</i>
fecc	Parameter type: <Counter> - 32 bit counter	number of corrected codewords encountered by the channel, respectively corrected octets in

109 xDSL Status Commands

name	Type	Description
		case of vdsl1 G.993.1 <i>This element is always shown.</i>
cec	Parameter type: <Counter> - 32 bit counter	the number of non-corrected erroneous codewords encountered by the far end channel <i>This element is always shown.</i>
measured-time	Parameter type: <Xdsl::PrevCurIntervalMeasureTime> - the measured time interval - unit: sec - range: [0...900]	amt of time in sec that statistics have been counted <i>This element is always shown.</i>
in-valid-flag	Parameter type: <Xdsl::IntervalValidityFlag> (true false) Possible values: - true : data is not valid - false : data is valid	validity of the corresponding PM data <i>This element is always shown.</i>
rtx-c-down	Parameter type: <Counter> - 32 bit counter	the total number of detected errored DTUs which have been successfully corrected by a retransmission as seen by the far-end receiver. Only applicable for VDSL2. <i>This element is always shown.</i>
rtx-uc-down	Parameter type: <Counter> - 32 bit counter	the total number of detected errored DTUs which have not been corrected by one or more retransmissions <i>This element is always shown.</i>
rtx-tx-up	Parameter type: <Counter> - 32 bit counter	the total number of retransmitted DTUs by the transmitter <i>This element is always shown.</i>

109.28 xDSL Counters Far End Channel Current Day

Command Description

CEC parameter only applies to VDSL2.

CEC: Number of uncorrected codewords encountered by near-end (or far-end) channel in VDSL2 mode.

User Level

The command can be accessed by operators with xdsl privileges.

Command Syntax

The command has the following syntax:

```
> show xdsl counters far-end channel current-1day [ (if-index) ]
```

Command Parameters

Table 109.28-1 "xDSL Counters Far End Channel Current Day" Resource Parameters

Resource Identifier	Type	Description
(if-index)	Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number	interface index of the port

Command Output

Table 109.28-2 "xDSL Counters Far End Channel Current Day" Display parameters

Specific Information		
name	Type	Description
cv	Parameter type: <Counter> - 32 bit counter	nbr of coding violations encountered by far end channel <i>This element is always shown.</i>
fecc	Parameter type: <Counter> - 32 bit counter	number of corrected codewords encountered by the channel, respectively corrected octets in

109 xDSL Status Commands

name	Type	Description
		case of vdsl1 G.993.1 <i>This element is always shown.</i>
cec	Parameter type: <Counter> - 32 bit counter	the number of non-corrected erroneous codewords encountered by the far end channel <i>This element is always shown.</i>
measured-time	Parameter type: <Xdsl::IntervalMeasureTime> - the measured time interval - unit: sec - range: [0...86400]	amt of time in sec that statistics have been counted <i>This element is always shown.</i>
in-valid-flag	Parameter type: <Xdsl::IntervalValidityFlag> (true false) Possible values: - true : data is not valid - false : data is valid	validity of the corresponding PM data <i>This element is always shown.</i>
rtx-c-down	Parameter type: <Counter> - 32 bit counter	the total number of detected errored DTUs which have been successfully corrected by a retransmission as seen by the far-end receiver. Only applicable for VDSL2. <i>This element is always shown.</i>
rtx-uc-down	Parameter type: <Counter> - 32 bit counter	the total number of detected errored DTUs which have not been corrected by one or more retransmissions <i>This element is always shown.</i>
rtx-tx-up	Parameter type: <Counter> - 32 bit counter	the total number of retransmitted DTUs by the transmitter <i>This element is always shown.</i>

109.29 xDSL Counters Far End Channel Previous 15 Min

Command Description

CEC parameter only applies to VDSL2.

CEC: Number of uncorrected codewords encountered by near-end (or far-end) channel in VDSL2 mode.

User Level

The command can be accessed by operators with xdsl privileges.

Command Syntax

The command has the following syntax:

```
> show xdsl counters far-end channel previous-interval [ (if-index) [ interval-no <Xdsl::IntervalNumber15min> ] ]
```

Command Parameters

Table 109.29-1 "xDSL Counters Far End Channel Previous 15 Min" Resource Parameters

Resource Identifier	Type	Description
(if-index)	Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number	interface index of the port
interval-no	Parameter type: <Xdsl::IntervalNumber15min> Format: - a number identifying 15 minutes interval time - range: [1...192]	nbr identifying previous 15 min intvl time, value 1 is the most recently completed 15 min intvl

Command Output

Table 109.29-2 "xDSL Counters Far End Channel Previous 15 Min" Display parameters

Specific Information		
name	Type	Description
cv	Parameter type: <Counter> - 32 bit counter	number of coding violations in the previous 15 min

109 xDSL Status Commands

name	Type	Description
		<i>This element is always shown.</i>
fecc	Parameter type: <Counter> - 32 bit counter	number of corrected codewords encountered by the channel, respectively corrected octets in case of vdsl1 G.993.1 <i>This element is always shown.</i>
cec	Parameter type: <Counter> - 32 bit counter	the number of non-corrected erroneous codewords encountered by the far end channel <i>This element is always shown.</i>
measured-time	Parameter type: <Xdsl::PrevCurIntervalMeasureTime> - the measured time interval - unit: sec - range: [0...900]	amt of time in sec that statistics have been counted <i>This element is always shown.</i>
in-valid-flag	Parameter type: <Xdsl::IntervalValidityFlag> (true false) Possible values: - true : data is not valid - false : data is valid	validity of the corresponding PM data <i>This element is always shown.</i>
rtx-c-down	Parameter type: <Counter> - 32 bit counter	the total number of detected errored DTUs which have been successfully corrected by a retransmission as seen by the far-end receiver. Only applicable for VDSL2. <i>This element is always shown.</i>
rtx-uc-down	Parameter type: <Counter> - 32 bit counter	the total number of detected errored DTUs which have not been corrected by one or more retransmissions <i>This element is always shown.</i>
rtx-tx-up	Parameter type: <Counter> - 32 bit counter	the total number of retransmitted DTUs by the transmitter <i>This element is always shown.</i>
interval-time	Parameter type: <Xdsl::PmTimeStamp> - Timestamp for Pm interval(yyyymmdd:hour:minutes)	specifies the start time of interval <i>This element is always shown.</i>

109.30 xDSL Counters Far End Channel Previous Day

Command Description

CEC parameter only applies to VDSL2.

CEC: Number of uncorrected codewords encountered by near-end (or far-end) channel in VDSL2 mode.

User Level

The command can be accessed by operators with xdsl privileges.

Command Syntax

The command has the following syntax:

```
> show xdsl counters far-end channel previous-1day [ (if-index) [ interval-no <Xdsl::IntervalNumber1day> ] ]
```

Command Parameters

Table 109.30-1 "xDSL Counters Far End Channel Previous Day" Resource Parameters

Resource Identifier	Type	Description
(if-index)	Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number	interface index of the port
interval-no	Parameter type: <Xdsl::IntervalNumber1day> Format: - a number identifying 1 day interval time - range: [1...7]	nbr identifying previous 1 day intvl time, value 1 is the most recently completed 1 day intvl

Command Output

Table 109.30-2 "xDSL Counters Far End Channel Previous Day" Display parameters

Specific Information		
name	Type	Description
cv	Parameter type: <Counter> - 32 bit counter	number of coding violations in the previous one day

109 xDSL Status Commands

name	Type	Description
		<i>This element is always shown.</i>
fecc	Parameter type: <Counter> - 32 bit counter	number of corrected codewords encountered by the channel, respectively corrected octets in case of vdsl1 G.993.1 <i>This element is always shown.</i>
cec	Parameter type: <Counter> - 32 bit counter	the number of non-corrected erroneous codewords encountered by the far end channel <i>This element is always shown.</i>
measured-time	Parameter type: <Xdsl::IntervalMeasureTime> - the measured time interval - unit: sec - range: [0...86400]	amt of time in sec that statistics have been counted <i>This element is always shown.</i>
in-valid-flag	Parameter type: <Xdsl::IntervalValidityFlag> (true false) Possible values: - true : data is not valid - false : data is valid	validity of the corresponding PM data <i>This element is always shown.</i>
rtx-c-down	Parameter type: <Counter> - 32 bit counter	the total number of detected errored DTUs which have been successfully corrected by a retransmission as seen by the far-end receiver. Only applicable for VDSL2. <i>This element is always shown.</i>
rtx-uc-down	Parameter type: <Counter> - 32 bit counter	the total number of detected errored DTUs which have not been corrected by one or more retransmissions <i>This element is always shown.</i>
rtx-tx-up	Parameter type: <Counter> - 32 bit counter	the total number of retransmitted DTUs by the transmitter <i>This element is always shown.</i>
interval-time	Parameter type: <Xdsl::PmTimeStamp> - Timestamp for Pm interval(yyyymmdd:hour:minutes)	specifies the start time of interval <i>This element is always shown.</i>

109.31 xDSL XTU-R Inventory Status Command

Command Description

This command displays the xDSL XTU-R inventory data.

User Level

The command can be accessed by operators with xdsl privileges.

Command Syntax

The command has the following syntax:

```
> show xdsl cpe-inventory [ (if-index) ]
```

Command Parameters

Table 109.31-1 "xDSL XTU-R Inventory Status Command" Resource Parameters

Resource Identifier	Type	Description
(if-index)	Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number	interface index of the port

Command Output

Table 109.31-2 "xDSL XTU-R Inventory Status Command" Display parameters

Specific Information		
name	Type	Description
modem-vendor-id	Parameter type: <Xdsl::VendorID> - an octet string defining vendor identification - length: x<=16	vendor ID retrieved during handshaking <i>This element is always shown.</i>
sys-serial-no	Parameter type: <Xdsl::SystemSerialNumber> - an octet string defining system serial number - length: x<=32	serial number that identifies the vendor equipment <i>This element is only shown in detail mode.</i>
sys-vendor-id	Parameter type: <Xdsl::VendorID> - an octet string defining vendor identification - length: x<=16	vendor ID retrieved via the xdsl EOC <i>This element is always shown.</i>

109 xDSL Status Commands

name	Type	Description
sys-version-no	Parameter type: <Xdsl::XturSystemVersionNo> - an octet string defining xtur system version number - length: x<=34	version number retrieved via the the xdsl EOC <i>This element is only shown in detail mode.</i>
self-test-result	Parameter type: <Xdsl::SelfTestResult> - an octet string defining self test result - length: x<=8	self test results value retrieved via the the xdsl EOC <i>This element is always shown.</i>

109.32 xDSL XTU-C Inventory Status Command

Command Description

This command displays the xDSL XTU-C inventory data.

User Level

The command can be accessed by operators with xdsl privileges.

Command Syntax

The command has the following syntax:

```
> show xdsl co-inventory [ (if-index) ]
```

Command Parameters

Table 109.32-1 "xDSL XTU-C Inventory Status Command" Resource Parameters

Resource Identifier	Type	Description
(if-index)	Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number	interface index of the port

Command Output

Table 109.32-2 "xDSL XTU-C Inventory Status Command" Display parameters

Specific Information		
name	Type	Description
modem-vendor-id	Parameter type: <Xdsl::VendorID> - an octet string defining vendor identification - length: x<=16	vendor ID retrieved during handshaking <i>This element is always shown.</i>
sys-serial-no	Parameter type: <Xdsl::SystemSerialNumber> - an octet string defining system serial number - length: x<=32	serial number that identifies the vendor equipment <i>This element is only shown in detail mode.</i>
sys-vendor-id	Parameter type: <Xdsl::VendorID> - an octet string defining vendor identification - length: x<=16	vendor ID <i>This element is always shown.</i>

109 xDSL Status Commands

name	Type	Description
sys-version-no	Parameter type: <Xdsl::SystemVersionNo> - an octet string defining system version number - length: x<=32	version number <i>This element is only shown in detail mode.</i>
modem-sw-ver-no	Parameter type: <Xdsl::ModemSwVersionNo> - display string of modem software version - length: x<=32	modem sw version number <i>This element is only shown in detail mode.</i>
self-test-result	Parameter type: <Xdsl::SelfTestResult> - an octet string defining self test result - length: x<=8	self test results value <i>This element is always shown.</i>

109.33 xDSL Board Capability Status Command

Command Description

This command displays xDSL board capability.

User Level

The command can be accessed by operators with xdsl privileges.

Command Syntax

The command has the following syntax:

```
> show xdsl board [ (if-index) ]
```

Command Parameters

Table 109.33-1 "xDSL Board Capability Status Command" Resource Parameters

Resource Identifier	Type	Description
(if-index)	Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number	interface index of the port

Command Output

Table 109.33-2 "xDSL Board Capability Status Command" Display parameters

Specific Information		
name	Type	Description
capability	Parameter type: <Xdsl::OpModeTypeLinePreDef> (ansi-t1413 etsi-dts g992-1-a g992-1-b g992-2-a g992-3-a g992-3-b g992-3-aj g992-3-l1 g992-3-l2	operational mode supported by the board <i>This element is always shown.</i>

name	Type	Description
	<pre> g992-3-am g992-5-a g992-5-b ansi-t1.424 etsi-ts itu-g993-1 ieee-802.3ah g992-5-aj g992-5-am g993-2-8a g993-2-8b g993-2-8c g993-2-8d g993-2-12a g993-2-12b g993-2-17a g993-2-30a g993-2-35b gfast default <Xdsl::OpModeType>) Possible values: - ansi-t1413 : ANSI T1.413-1998 - etsi-dts : ETSI DTS/TM06006 - g992-1-a : G.992.1 POTS non-overlapped spectrum - g992-1-b : G.992.1 ISDN non-overlapped spectrum - g992-2-a : G.992.2 POTS non-overlapped spectrum - g992-3-a : G.992.2 POTS non-overlapped spectrum - g992-3-b : G.992.3 ISDN non-overlapped spectrum - g992-3-aj : G.992.3 All Digital Mode with non-overlapped spectrum - g992-3-l1 : G.992.3 POTS non-overlapped spectrum US mask 1 - g992-3-l2 : G.992.3 POTS non-overlapped spectrum US mask 2 - g992-3-am : G.992.3 extended POTS with non-overlapped spectrum - g992-5-a : G.992.5 POTS non-overlapped spectrum - g992-5-b : G.992.5 POTS non-overlapped spectrum - ansi-t1.424 : ANSI T1.424 - etsi-ts : ETSI TS - itu-g993-1 : ITU G993-1 - ieee-802.3ah : IEEE 802.3ah - g992-5-aj : G.992.5 All Digital Mode with non-overlapped spectrum - g992-5-am : G.992.5 extended POTS non-overlapped spectrum - g993-2-8a : VDSL-2 with profile 8A - g993-2-8b : VDSL-2 with profile 8B - g993-2-8c : VDSL-2 with profile 8C - g993-2-8d : VDSL-2 with profile 8D - g993-2-12a : VDSL-2 with profile 12A - g993-2-12b : VDSL-2 with profile 12B - g993-2-17a : VDSL-2 with profile 17A - g993-2-30a : VDSL-2 with profile 30A - g993-2-35b : VDSL-2 with profile 35B - gfast : gfast profile </pre>	

name	Type	Description
	- default : default value Field type <Xdsl::OpModeType> - octet string bitmask defining operational mode - length: 16	
ansi-t1413	Parameter type: <Xdsl::T1413> (dis-ansi-t1413 ansi-t1413) Possible values: - dis-ansi-t1413 : disable ANSI T1.413-1998 - ansi-t1413 : ANSI T1.413-1998	ANSI T1.413-1998 <i>This element is only shown in detail mode.</i>
etsi-dts	Parameter type: <Xdsl::Etsidts> (dis-etsi-dts etsi-dts) Possible values: - dis-etsi-dts : disable ETSI DTS/TM06006 - etsi-dts : ETSI DTS/TM06006	ETSI DTS/TM06006 <i>This element is only shown in detail mode.</i>
g992-1-a	Parameter type: <Xdsl::G21potsnos> (dis-g992-1-a g992-1-a) Possible values: - dis-g992-1-a : disable G.992.1 POTS non-overlapped spectrum - g992-1-a : G.992.1 POTS non-overlapped spectrum	G.992.1 POTS non-overlapped spectrum <i>This element is only shown in detail mode.</i>
g992-1-b	Parameter type: <Xdsl::G21isdnnos> (dis-g992-1-b g992-1-b) Possible values: - dis-g992-1-b : disable G.992.1 ISDN non-overlapped spectrum - g992-1-b : G.992.1 ISDN non-overlapped spectrum	G.992.1 ISDN non-overlapped spectrum <i>This element is only shown in detail mode.</i>
g992-2-a	Parameter type: <Xdsl::G22potsnos> (dis-g992-2-a g992-2-a) Possible values: - dis-g992-2-a : disable G.992.2 POTS non-overlapped spectrum - g992-2-a : G.992.2 POTS non-overlapped spectrum	G.992.2 POTS non-overlapped spectrum <i>This element is only shown in detail mode.</i>
g992-3-a	Parameter type: <Xdsl::G23potsnos> (dis-g992-3-a g992-3-a) Possible values: - dis-g992-3-a : disable G.992.3 POTS non-overlapped spectrum - g992-3-a : G.992.3 POTS non-overlapped spectrum	G.992.3 POTS non-overlapped spectrum <i>This element is only shown in detail mode.</i>
g992-3-b	Parameter type: <Xdsl::G23isdnnos> (dis-g992-3-b g992-3-b) Possible values: - dis-g992-3-b : disable G.992.3 ISDN non-overlapped spectrum - g992-3-b : G.992.3 ISDN non-overlapped spectrum	G.992.3 ISDN non-overlapped spectrum <i>This element is only shown in detail mode.</i>
g992-3-aj	Parameter type: <Xdsl::G23AllDigNos> (dis-g992-3-aj g992-3-aj) Possible values: - dis-g992-3-aj : disable G.992.3 all digital mode non-overlapped spectrum	G.992.3 all digital mode non-overlapped spectrum <i>This element is only shown in detail mode.</i>

name	Type	Description
	- g992-3-aj : G.992.3 all digital mode non-overlapped spectrum	
g992-3-l1	Parameter type: <Xdsl::G23PotsnosUs1> (dis-g992-3-l1 g992-3-l1) Possible values: - dis-g992-3-l1 : disable G.992.3 POTS non-overlapped spectrum US mask 1 - g992-3-l1 : G.992.3 POTS non-overlapped spectrum US mask 1	G.992.3 POTS non-overlapped spectrum US mask 1 <i>This element is only shown in detail mode.</i>
g992-3-l2	Parameter type: <Xdsl::G23PotsNosUs2> (dis-g992-3-l2 g992-3-l2) Possible values: - dis-g992-3-l2 : disable G.992.3 POTS non-overlapped spectrum US mask 2 - g992-3-l2 : G.992.3 POTS non-overlapped spectrum US mask 2	G.992.3 POTS non-overlapped spectrum US mask 2 <i>This element is only shown in detail mode.</i>
g992-3-am	Parameter type: <Xdsl::G23ExtPotsNos> (dis-g992-3-am g992-3-am) Possible values: - dis-g992-3-am : disable G.992.3 extended POTS with non-overlapped spectrum - g992-3-am : G.992.3 extended POTS with non-overlapped spectrum	G.992.3 extended POTS with non-overlapped spectrum <i>This element is only shown in detail mode.</i>
g992-5-a	Parameter type: <Xdsl::G25PotsNos> (dis-g992-5-a g992-5-a) Possible values: - dis-g992-5-a : disable G.992.5 POTS non-overlapped spectrum - g992-5-a : G.992.5 POTS non-overlapped spectrum	G.992.5 POTS non-overlapped spectrum <i>This element is only shown in detail mode.</i>
g992-5-b	Parameter type: <Xdsl::G25IsdnNos> (dis-g992-5-b g992-5-b) Possible values: - dis-g992-5-b : disable G.992.5 ISDN non-overlapped spectrum - g992-5-b : G.992.5 ISDN non-overlapped spectrum	G.992.5 ISDN non-overlapped spectrum <i>This element is only shown in detail mode.</i>
ansi-t1.424	Parameter type: <Xdsl::AnsiT1424> (dis-ansi-t1.424 ansi-t1.424) Possible values: - dis-ansi-t1.424 : disable ANSI T1.424 - ansi-t1.424 : ANSI T1.424	ansi T1.424 <i>This element is only shown in detail mode.</i>
etsi-ts	Parameter type: <Xdsl::EtsiTs> (dis-etsi-ts etsi-ts) Possible values: - dis-etsi-ts : disable ETSI TS - etsi-ts : ETSI TS	ETSI TS 101 270 <i>This element is only shown in detail mode.</i>
itu-g993-1	Parameter type: <Xdsl::ItuG9931> (dis-itu-g993-1 itu-g993-1) Possible values: - dis-itu-g993-1 : disable ITU G993-1	ITU G993-1 <i>This element is only shown in detail mode.</i>

name	Type	Description
	- itu-g993-1 : ITU G993-1	
ieee-802.3ah	Parameter type: <Xdsl::Ieee802.3Ah> (dis-ieee-802.3ah ieee-802.3ah) Possible values: - dis-ieee-802.3ah : disable IEEE 802.3ah - ieee-802.3ah : IEEE 802.3ah	IEEE 802.3ah <i>This element is only shown in detail mode.</i>
g992-5-aj	Parameter type: <Xdsl::G25AllDigNos> (dis-g992-5-aj g992-5-aj) Possible values: - dis-g992-5-aj : disable G.992.5 all digital mode non-overlapped spectrum - g992-5-aj : G.992.5 all digital mode non-overlapped spectrum	G.992.5 all digital mode non-overlapped spectrum <i>This element is only shown in detail mode.</i>
g992-5-am	Parameter type: <Xdsl::G25ExtPotsNos> (dis-g992-5-am g992-5-am) Possible values: - dis-g992-5-am : disable G.992.5 extended POTS non-overlapped spectrum - g992-5-am : G.992.5 extended POTS non-overlapped spectrum	G.992.5 extended POTS non-overlapped spectrum <i>This element is only shown in detail mode.</i>
g993-2-8a	Parameter type: <Xdsl::GProfile8A> (dis-g993-2-8a g993-2-8a) Possible values: - dis-g993-2-8a : disable G.993.2_8A VDSL-2 with profile 8A - g993-2-8a : G.993.2_8A VDSL-2 with profile 8A	VDSL-2 with profile 8A <i>This element is only shown in detail mode.</i>
g993-2-8b	Parameter type: <Xdsl::GProfile8B> (dis-g993-2-8b g993-2-8b) Possible values: - dis-g993-2-8b : disable G.993.2_8B VDSL-2 with profile 8B - g993-2-8b : G.993.2_8B VDSL-2 with profile 8B	VDSL-2 with profile 8B <i>This element is only shown in detail mode.</i>
g993-2-8c	Parameter type: <Xdsl::GProfile8C> (dis-g993-2-8c g993-2-8c) Possible values: - dis-g993-2-8c : disable G.993.2_8C VDSL-2 with profile 8C - g993-2-8c : G.993.2_8C VDSL-2 with profile 8C	VDSL-2 with profile 8C <i>This element is only shown in detail mode.</i>
g993-2-8d	Parameter type: <Xdsl::GProfile8D> (dis-g993-2-8d g993-2-8d) Possible values: - dis-g993-2-8d : disable G.993.2_8D VDSL-2 with profile 8D - g993-2-8d : G.993.2_8D VDSL-2 with profile 8D	VDSL-2 with profile 8D <i>This element is only shown in detail mode.</i>
g993-2-12a	Parameter type: <Xdsl::GProfile12A> (dis-g993-2-12a g993-2-12a) Possible values: - dis-g993-2-12a : disable G.993.2_12A VDSL-2 with profile 12A	VDSL-2 with profile 12A <i>This element is only shown in detail mode.</i>

109 xDSL Status Commands

name	Type	Description
	- g993-2-12a : G.993.2_12A VDSL-2 with profile 12A	
g993-2-12b	Parameter type: <Xdsl::GProfile12B> (dis-g993-2-12b g993-2-12b) Possible values: - dis-g993-2-12b : disable G.993.2_12B VDSL-2 with profile 12B - g993-2-12b : G.993.2_12B VDSL-2 with profile 12B	VDSL-2 with profile 12B <i>This element is only shown in detail mode.</i>
g993-2-17a	Parameter type: <Xdsl::GProfile17A> (dis-g993-2-17a g993-2-17a) Possible values: - dis-g993-2-17a : disable G.993.2_17A VDSL-2 with profile 17A - g993-2-17a : G.993.2_17A VDSL-2 with profile 17A	VDSL-2 with profile 17A <i>This element is only shown in detail mode.</i>
g993-2-30a	Parameter type: <Xdsl::GProfile30A> (dis-g993-2-30a g993-2-30a) Possible values: - dis-g993-2-30a : disable G.993.2_30A VDSL-2 with profile 30A - g993-2-30a : G.993.2_30A VDSL-2 with profile 30A	VDSL-2 with profile 30A <i>This element is only shown in detail mode.</i>
g993-2-35b	Parameter type: <Xdsl::GProfile35B> (dis-g993-2-35b g993-2-35b) Possible values: - dis-g993-2-35b : disable G.993.2_35B VDSL-2 with profile 35B - g993-2-35b : G.993.2_35B VDSL-2 with profile 35B	VDSL-2 with profile 35B <i>This element is only shown in detail mode.</i>

109.34 xDSL Low Rate Alarm Timestamp Command

Command Description

This command displays the latest configured timestamp. This timestamp value will be used to build-up the line-bitmap table.

User Level

The command can be accessed by operators with xdsl privileges.

Command Syntax

The command has the following syntax:

```
> show xdsl link-up-changes [ (linkup-timestamp) ]
```

Command Parameters

Table 109.34-1 "xDSL Low Rate Alarm Timestamp Command" Resource Parameters

Resource Identifier	Type	Description
(linkup-timestamp)	Format: - Printable string	the latest link up timestamp

109.35 xDSL Low Rate Alarm Line Bitmap Status Command

Command Description

This command displays in a bitmap all the lines (of the specified slot) which have changed state after the specified timestamp. - to the Up-state and current bitrate is less than planned-bit-rate - to the Down-state.

User Level

The command can be accessed by operators with xdsl privileges.

Command Syntax

The command has the following syntax:

```
> show xdsl link-up-changes (linkup-timestamp) slot [ (slot) ]
```

Command Parameters

Table 109.35-1 "xDSL Low Rate Alarm Line Bitmap Status Command" Resource Parameters

Resource Identifier	Type	Description
(linkup-timestamp)	Format: - Printable string	the latest link up timestamp
(slot)	Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId>) Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number	the physical slot position

Command Output

Table 109.35-2 "xDSL Low Rate Alarm Line Bitmap Status Command" Display parameters

Specific Information		
name	Type	Description
port	Parameter type: <Xdsl::PortList> - Printable string	displays all the lines with state change after specified time <i>This element is always shown.</i>

109.36 xDSL Low Rate Alarm Linkup Record Data Command

Command Description

This command displays the linkup record for the line. This command is only applicable for ADSLx/VDSLx.

User Level

The command can be accessed by operators with xdsl privileges.

Command Syntax

The command has the following syntax:

```
> show xdsl linkup-record [ (line) ]
```

Command Parameters

Table 109.36-1 "xDSL Low Rate Alarm Linkup Record Data Command" Resource Parameters

Resource Identifier	Type	Description
(line)	Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number	the physical slot position

Command Output

Table 109.36-2 "xDSL Low Rate Alarm Linkup Record Data Command" Display parameters

Specific Information		
name	Type	Description
link-timestamp-down	Parameter type: <Xdsl::timeInSecs> - Printable string	Displays the latest link down timestamp <i>This element is always shown.</i>
link-timestamp-up	Parameter type: <Xdsl::timeInSecs> - Printable string	Displays the latest link up timestamp <i>This element is always shown.</i>
act-bitrate-up	Parameter type: <Xdsl::BitRateKbps>	Displays the actual net data or

name	Type	Description
	- Bitrate in kbps - unit: kbps	expected throughput for the upstream fast or interleaved channel <i>This element is always shown.</i>
act-bitrate-down	Parameter type: <Xdsl::BitRateKbps> - Bitrate in kbps - unit: kbps	Displays the actual net data or expected throughput for the downstream fast or interleaved channel <i>This element is always shown.</i>
act-noise-margin-up	Parameter type: <Xdsl::NoiseMargindB> - Noise Margin in dB - unit: 1/10 dB	Displays the realised noise margin for the upstream direction <i>This element is always shown.</i>
act-noise-margin-down	Parameter type: <Xdsl::NoiseMargindB> - Noise Margin in dB - unit: 1/10 dB	Displays the realised noise margin for the downstream direction <i>This element is always shown.</i>
attenuation-up	Parameter type: <Xdsl::AttenuationdB> - an attenuation value - unit: 1/10 dB	Displays the link up attenuation on upstream <i>This element is always shown.</i>
attenuation-down	Parameter type: <Xdsl::AttenuationdB> - an attenuation value - unit: 1/10 dB	Displays the link up attenuation on downstream <i>This element is always shown.</i>
attained-bitrate-up	Parameter type: <Xdsl::BitRateKbps> - Bitrate in kbps - unit: kbps	Displays maximum attainable net data rate or expected throughput the modem can support in upstream <i>This element is always shown.</i>
attained-bitrate-down	Parameter type: <Xdsl::BitRateKbps> - Bitrate in kbps - unit: kbps	Displays maximum attainable net data rate or expected throughput the modem can support in downstream <i>This element is always shown.</i>
max-bitrate-up	Parameter type: <Xdsl::SignedIntegerKbps> - 1000 bits per second - unit: kbits/sec	Displays the configured maximum bitrate for the upstream <i>This element is always shown.</i>
max-bitrate-down	Parameter type: <Xdsl::SignedIntegerKbps> - 1000 bits per second - unit: kbits/sec	Displays the configured maximum bitrate for the downstream <i>This element is always shown.</i>
threshold-bitrate-up	Parameter type: <Xdsl::BitRateKbps> - Bitrate in kbps - unit: kbps	Displays the configured threshold bitrate for upstream <i>This element is always shown.</i>
threshold-bitrate-down	Parameter type: <Xdsl::BitRateKbps> - Bitrate in kbps - unit: kbps	Displays the configured threshold bitrate for downstream <i>This element is always shown.</i>
max-delay-up	Parameter type: <Xdsl::Delay> - Delay in kbps - unit: msec	Displays the configured maximum interleaving delay for upstream <i>This element is always shown.</i>
max-delay-down	Parameter type: <Xdsl::Delay> - Delay in kbps - unit: msec	Displays the configured maximum interleaving delay for downstream <i>This element is always shown.</i>
tgt-noise-margin-up	Parameter type: <Xdsl::NoiseMargindB> - Noise Margin in dB - unit: 1/10 dB	Displays the configured target noise margin for upstream <i>This element is always shown.</i>

name	Type	Description
tgt-noise-margin-down	Parameter type: <Xdsl::NoiseMargindB> - Noise Margin in dB - unit: 1/10 dB	Displays the configured target noise margin for downstream <i>This element is always shown.</i>

109.37 xDSL INS Near End Operational Data Status Command

Command Description

This command displays the xDSL Impulse-Noise-Sensor near-end operational data.

User Level

The command can be accessed by operators with xdsl privileges.

Command Syntax

The command has the following syntax:

```
> show xdsl imp-noise-sensor near-end oper-data [ (if-index) ]
```

Command Parameters

Table 109.37-1 "xDSL INS Near End Operational Data Status Command" Resource Parameters

Resource Identifier	Type	Description
(if-index)	Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number	interface index of the port

Command Output

Table 109.37-2 "xDSL INS Near End Operational Data Status Command" Display parameters

Specific Information		
name	Type	Description
sensitivity	Parameter type: <Xdsl::InsSensitivity> - impulse noise sensitivity - unit: dB / 10 - range: [-128...127]	impulse noise sensitivity <i>This element is always shown.</i>
equiv-inp-mode	Parameter type: <Xdsl::InmEquivInpMode> (mode-0 mode-1	equivalent INP mode actually used to construct the INM equivalent INP histograms.

name	Type	Description
	mode-2 mode-3 not-supported) Possible values: - mode-0 : impulse length - mode-1 : cluster length - mode-2 : sum of impulse length in cluster - mode-3 : gap compensated impulse length in cluster - not-supported : INM not supported by modem	<i>This element is always shown.</i>

109.38 xDSL INS Near End Current 15Min Data Status Command

Command Description

This command displays the xDSL Impulse-Noise-Sensor near-end current 15Min data.

User Level

The command can be accessed by operators with xdsl privileges.

Command Syntax

The command has the following syntax:

```
> show xdsl imp-noise-sensor near-end current-interval [ (if-index) ]
```

Command Parameters

Table 109.38-1 "xDSL INS Near End Current 15Min Data Status Command" Resource Parameters

Resource Identifier	Type	Description
(if-index)	Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number	interface index of the port

Command Output

Table 109.38-2 "xDSL INS Near End Current 15Min Data Status Command" Display parameters

Specific Information		
name	Type	Description
inm-data-symb-cnt	Parameter type: <Xdsl::DataSymbolCounter> - an unsigned integer	number of monitored data symbols <i>This element is always shown.</i>

109.39 xDSL INS Near End Current 15Min IAT Histogram

Command Description

This command displays the xDSL Impulse-Noise-Sensor near-end current 15Min Inter-Arrival-Time histogram.

User Level

The command can be accessed by operators with xdsl privileges.

Command Syntax

The command has the following syntax:

```
> show xdsl imp-noise-sensor near-end current-interval (if-index) inm-iat-histo [ (class-interval) ]
```

Command Parameters

Table 109.39-1 "xDSL INS Near End Current 15Min IAT Histogram" Resource Parameters

Resource Identifier	Type	Description
(if-index)	Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number	interface index of the port
(class-interval)	Format: - impulse noise monitoring inter arrival time histogram - range: [1...8]	class interval

Command Output

Table 109.39-2 "xDSL INS Near End Current 15Min IAT Histogram" Display parameters

Specific Information		
name	Type	Description
counter	Parameter type: <SignedInteger> - a signed integer	counter <i>This element is always shown.</i>

109.40 xDSL INS Near End Current 15Min EINP Histogram

Command Description

This command displays the xDSL Impulse-Noise-Sensor near-end current 15Min Equivalent-Impulse-Noise-Protection histogram.

User Level

The command can be accessed by operators with xdsl privileges.

Command Syntax

The command has the following syntax:

```
> show xdsl imp-noise-sensor near-end current-interval (if-index) inm-equiv-inp-histo [ (class-interval) ]
```

Command Parameters

Table 109.40-1 "xDSL INS Near End Current 15Min EINP Histogram" Resource Parameters

Resource Identifier	Type	Description
(if-index)	Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number	interface index of the port
(class-interval)	Format: - impulse noise monitoring equivalent INP histogram - range: [1...17]	class interval

Command Output

Table 109.40-2 "xDSL INS Near End Current 15Min EINP Histogram" Display parameters

Specific Information		
name	Type	Description
counter	Parameter type: <SignedInteger> - a signed integer	counter <i>This element is always shown.</i>

109.41 xDSL INS Near End Current Day Data Status Command

Command Description

This command displays the xDSL Impulse-Noise-Sensor near-end current day data.

User Level

The command can be accessed by operators with xdsl privileges.

Command Syntax

The command has the following syntax:

```
> show xdsl imp-noise-sensor near-end current-1day [ (if-index) ]
```

Command Parameters

Table 109.41-1 "xDSL INS Near End Current Day Data Status Command" Resource Parameters

Resource Identifier	Type	Description
(if-index)	Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number	interface index of the port

Command Output

Table 109.41-2 "xDSL INS Near End Current Day Data Status Command" Display parameters

Specific Information		
name	Type	Description
inm-data-symb-cnt	Parameter type: <Xdsl::DataSymbolCounter> - an unsigned integer	number of monitored data symbols <i>This element is always shown.</i>

109.42 xDSL INS Near End Current Day IAT Histogram

Command Description

This command displays the xDSL impulse-Noise-Sensor near-end current day Inter-Arrival-Time histogram.

User Level

The command can be accessed by operators with xdsl privileges.

Command Syntax

The command has the following syntax:

```
> show xdsl imp-noise-sensor near-end current-1day (if-index) inm-iat-histo [ (class-interval) ]
```

Command Parameters

Table 109.42-1 "xDSL INS Near End Current Day IAT Histogram" Resource Parameters

Resource Identifier	Type	Description
(if-index)	Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number	interface index of the port
(class-interval)	Format: - impulse noise monitoring inter arrival time histogram - range: [1...8]	class interval

Command Output

Table 109.42-2 "xDSL INS Near End Current Day IAT Histogram" Display parameters

Specific Information		
name	Type	Description
counter	Parameter type: <SignedInteger> - a signed integer	counter <i>This element is always shown.</i>

109.43 xDSL INS Near End Current Day EINP Histogram

Command Description

This command displays the xDSL Impulse-Noise-Sensor near-end current day Equivalent-Impulse-Noise-Protection histogram.

User Level

The command can be accessed by operators with xdsl privileges.

Command Syntax

The command has the following syntax:

```
> show xdsl imp-noise-sensor near-end current-1day (if-index) inm-equiv-inp-histo [ (class-interval) ]
```

Command Parameters

Table 109.43-1 "xDSL INS Near End Current Day EINP Histogram" Resource Parameters

Resource Identifier	Type	Description
(if-index)	Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number	interface index of the port
(class-interval)	Format: - impulse noise monitoring equivalent INP histogram - range: [1...17]	class interval

Command Output

Table 109.43-2 "xDSL INS Near End Current Day EINP Histogram" Display parameters

Specific Information		
name	Type	Description
counter	Parameter type: <SignedInteger> - a signed integer	counter <i>This element is always shown.</i>

109.44 xDSL INS Near End Previous 15Min Data Status Command

Command Description

This command displays the xDSL Impulse-Noise-Sensor near-end previous 15Min data.

User Level

The command can be accessed by operators with xdsl privileges.

Command Syntax

The command has the following syntax:

```
> show xdsl imp-noise-sensor near-end previous-interval [ (if-index) ]
```

Command Parameters

Table 109.44-1 "xDSL INS Near End Previous 15Min Data Status Command" Resource Parameters

Resource Identifier	Type	Description
(if-index)	Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number	interface index of the port

Command Output

Table 109.44-2 "xDSL INS Near End Previous 15Min Data Status Command" Display parameters

Specific Information		
name	Type	Description
inm-data-symb-cnt	Parameter type: <Xdsl::DataSymbolCounter> - an unsigned integer	number of monitored data symbols <i>This element is always shown.</i>
interval-time	Parameter type: <Xdsl::PmTimeStamp> - Timestamp for Pm interval(yyyymmdd:hour:minutes)	specifies the start time of interval <i>This element is always shown.</i>

109.45 xDSL INS Near End Previous 15Min IAT Histogram

Command Description

This command displays the xDSL Impulse-Noise-Sensor near-end previous 15Min Inter-Arrival-Time histogram.

User Level

The command can be accessed by operators with xdsl privileges.

Command Syntax

The command has the following syntax:

```
> show xdsl imp-noise-sensor near-end previous-interval (if-index) inm-iat-histo [ (class-interval) ]
```

Command Parameters

Table 109.45-1 "xDSL INS Near End Previous 15Min IAT Histogram" Resource Parameters

Resource Identifier	Type	Description
(if-index)	Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number	interface index of the port
(class-interval)	Format: - impulse noise monitoring inter arrival time histogram - range: [1...8]	class interval

Command Output

Table 109.45-2 "xDSL INS Near End Previous 15Min IAT Histogram" Display parameters

Specific Information		
name	Type	Description
counter	Parameter type: <SignedInteger> - a signed integer	counter <i>This element is always shown.</i>

109.46 xDSL INS Near End Previous 15Min EINP Histogram

Command Description

This command displays the xDSL impulse-Noise-Sensor near-end previous 15Min Equivalent-Impulse-Noise-Protection histogram.

User Level

The command can be accessed by operators with xdsl privileges.

Command Syntax

The command has the following syntax:

```
> show xdsl imp-noise-sensor near-end previous-interval (if-index) inm-equiv-inp-histo [ (class-interval) ]
```

Command Parameters

Table 109.46-1 "xDSL INS Near End Previous 15Min EINP Histogram" Resource Parameters

Resource Identifier	Type	Description
(if-index)	Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number	interface index of the port
(class-interval)	Format: - impulse noise monitoring equivalent INP histogram - range: [1...17]	class interval

Command Output

Table 109.46-2 "xDSL INS Near End Previous 15Min EINP Histogram" Display parameters

Specific Information		
name	Type	Description
counter	Parameter type: <SignedInteger> - a signed integer	counter <i>This element is always shown.</i>

109.47 xDSL INS Near End Previous Day Data Status Command

Command Description

This command displays the xDSL Impulse-Noise-Sensor near-end previous day data.

User Level

The command can be accessed by operators with xdsl privileges.

Command Syntax

The command has the following syntax:

```
> show xdsl imp-noise-sensor near-end previous-1day [ (if-index) ]
```

Command Parameters

Table 109.47-1 "xDSL INS Near End Previous Day Data Status Command" Resource Parameters

Resource Identifier	Type	Description
(if-index)	Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number	interface index of the port

Command Output

Table 109.47-2 "xDSL INS Near End Previous Day Data Status Command" Display parameters

Specific Information		
name	Type	Description
inm-data-symb-cnt	Parameter type: <Xdsl::DataSymbolCounter> - an unsigned integer	number of monitored data symbols <i>This element is always shown.</i>
interval-time	Parameter type: <Xdsl::PmTimeStamp> - Timestamp for Pm interval(yyyymmdd:hour:minutes)	specifies the start time of interval <i>This element is always shown.</i>

109.48 xDSL INS Near End Previous Day IAT Histogram

Command Description

This command displays the xDSL Impulse-Noise-Sensor near-end previous day Inter-Arrival-Time histogram.

User Level

The command can be accessed by operators with xdsl privileges.

Command Syntax

The command has the following syntax:

```
> show xdsl imp-noise-sensor near-end previous-1day (if-index) inm-iat-histo [ (class-interval) ]
```

Command Parameters

Table 109.48-1 "xDSL INS Near End Previous Day IAT Histogram" Resource Parameters

Resource Identifier	Type	Description
(if-index)	Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number	interface index of the port
(class-interval)	Format: - impulse noise monitoring inter arrival time histogram - range: [1...8]	class interval

Command Output

Table 109.48-2 "xDSL INS Near End Previous Day IAT Histogram" Display parameters

Specific Information		
name	Type	Description
counter	Parameter type: <SignedInteger> - a signed integer	counter <i>This element is always shown.</i>

109.49 xDSL INS Near End Previous Day EINP Histogram

Command Description

This command displays the xDSL Impulse-Noise-Sensor near-end previous day Equivalent-Impulse-Noise-Protection histogram.

User Level

The command can be accessed by operators with xdsl privileges.

Command Syntax

The command has the following syntax:

```
> show xdsl imp-noise-sensor near-end previous-1day (if-index) inm-equiv-inp-histo [ (class-interval) ]
```

Command Parameters

Table 109.49-1 "xDSL INS Near End Previous Day EINP Histogram" Resource Parameters

Resource Identifier	Type	Description
(if-index)	Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number	interface index of the port
(class-interval)	Format: - impulse noise monitoring equivalent INP histogram - range: [1...17]	class interval

Command Output

Table 109.49-2 "xDSL INS Near End Previous Day EINP Histogram" Display parameters

Specific Information		
name	Type	Description
counter	Parameter type: <SignedInteger> - a signed integer	counter <i>This element is always shown.</i>

109.50 xDSL INS Far End Operational Data Status Command

Command Description

This command displays the xDSL Impulse-Noise-Sensor far-end operational data.

User Level

The command can be accessed by operators with xdsl privileges.

Command Syntax

The command has the following syntax:

```
> show xdsl imp-noise-sensor far-end oper-data [ (if-index) ]
```

Command Parameters

Table 109.50-1 "xDSL INS Far End Operational Data Status Command" Resource Parameters

Resource Identifier	Type	Description
(if-index)	Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number	interface index of the port

Command Output

Table 109.50-2 "xDSL INS Far End Operational Data Status Command" Display parameters

Specific Information		
name	Type	Description
ins-sensitivity	Parameter type: <Xdsl::InsSensitivity> - impulse noise sensitivity - unit: dB / 10 - range: [-128...127]	impulse noise sensitivity <i>This element is always shown.</i>
equiv-inp-mode	Parameter type: <Xdsl::InmEquivInpMode> (mode-0 mode-1	equivalent INP mode actually used to construct the INM equivalent INP histograms.

name	Type	Description
	mode-2 mode-3 not-supported) Possible values: - mode-0 : impulse length - mode-1 : cluster length - mode-2 : sum of impulse length in cluster - mode-3 : gap compensated impulse length in cluster - not-supported : INM not supported by modem	<i>This element is always shown.</i>

109.51 xDSL INS Far End Current 15Min Data Status Command

Command Description

This command displays the xDSL Impulse-Noise-Sensor far-end current 15Min data.

User Level

The command can be accessed by operators with xdsl privileges.

Command Syntax

The command has the following syntax:

```
> show xdsl imp-noise-sensor far-end current-interval [ (if-index) ]
```

Command Parameters

Table 109.51-1 "xDSL INS Far End Current 15Min Data Status Command" Resource Parameters

Resource Identifier	Type	Description
(if-index)	Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number	interface index of the port

Command Output

Table 109.51-2 "xDSL INS Far End Current 15Min Data Status Command" Display parameters

Specific Information		
name	Type	Description
inm-data-symb-cnt	Parameter type: <Xdsl::DataSymbolCounter> - an unsigned integer	number of monitored data symbols <i>This element is always shown.</i>

109.52 xDSL INS Far End Current 15Min IAT Histogram

Command Description

This command displays the xDSL Impulse-Noise-Sensor far-end current 15Min Inter-Arrival-Time histogram.

User Level

The command can be accessed by operators with xdsl privileges.

Command Syntax

The command has the following syntax:

```
> show xdsl imp-noise-sensor far-end current-interval (if-index) inm-iat-histo [ (class-interval) ]
```

Command Parameters

Table 109.52-1 "xDSL INS Far End Current 15Min IAT Histogram" Resource Parameters

Resource Identifier	Type	Description
(if-index)	Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number	interface index of the port
(class-interval)	Format: - impulse noise monitoring inter arrival time histogram - range: [1...8]	class interval

Command Output

Table 109.52-2 "xDSL INS Far End Current 15Min IAT Histogram" Display parameters

Specific Information		
name	Type	Description
counter	Parameter type: <SignedInteger> - a signed integer	counter <i>This element is always shown.</i>

109.53 xDSL INS Far End Current 15Min EINP Histogram

Command Description

This command displays the xDSL Impulse-Noise-Sensor far-end current 15Min Equivalent-Impulse-Noise-Protection histogram.

User Level

The command can be accessed by operators with xdsl privileges.

Command Syntax

The command has the following syntax:

> show xdsl imp-noise-sensor far-end current-interval (if-index) inm-equiv-inp-histo [(class-interval)]

Command Parameters

Table 109.53-1 "xDSL INS Far End Current 15Min EINP Histogram" Resource Parameters

Resource Identifier	Type	Description
(if-index)	Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number	interface index of the port
(class-interval)	Format: - impulse noise monitoring equivalent INP histogram - range: [1...17]	class interval

Command Output

Table 109.53-2 "xDSL INS Far End Current 15Min EINP Histogram" Display parameters

Specific Information		
name	Type	Description
counter	Parameter type: <SignedInteger> - a signed integer	counter <i>This element is always shown.</i>

109.54 xDSL INS Far End Current Day Data Status Command

Command Description

This command displays the xDSL Impulse-Noise-Sensor far-end current day data.

User Level

The command can be accessed by operators with xdsl privileges.

Command Syntax

The command has the following syntax:

```
> show xdsl imp-noise-sensor far-end current-1day [ (if-index) ]
```

Command Parameters

Table 109.54-1 "xDSL INS Far End Current Day Data Status Command" Resource Parameters

Resource Identifier	Type	Description
(if-index)	Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number	interface index of the port

Command Output

Table 109.54-2 "xDSL INS Far End Current Day Data Status Command" Display parameters

Specific Information		
name	Type	Description
inm-data-symb-cnt	Parameter type: <Xdsl::DataSymbolCounter> - an unsigned integer	number of monitored data symbols <i>This element is always shown.</i>

109.55 xDSL INS Far End Current Day IAT Histogram

Command Description

This command displays the xDSL Impulse-Noise-Sensor far-end current day Inter-Arrival-Time histogram.

User Level

The command can be accessed by operators with xdsl privileges.

Command Syntax

The command has the following syntax:

```
> show xdsl imp-noise-sensor far-end current-1day (if-index) inm-iat-histo [ (class-interval) ]
```

Command Parameters

Table 109.55-1 "xDSL INS Far End Current Day IAT Histogram" Resource Parameters

Resource Identifier	Type	Description
(if-index)	Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number	interface index of the port
(class-interval)	Format: - impulse noise monitoring inter arrival time histogram - range: [1...8]	class interval

Command Output

Table 109.55-2 "xDSL INS Far End Current Day IAT Histogram" Display parameters

Specific Information		
name	Type	Description
counter	Parameter type: <SignedInteger> - a signed integer	counter <i>This element is always shown.</i>

109.56 xDSL INS Far End Current Day EINP Histogram

Command Description

This command displays the xDSL Impulse-Noise-Sensor far-end current day Equivalent-Impulse-Noise-Protection histogram.

User Level

The command can be accessed by operators with xdsl privileges.

Command Syntax

The command has the following syntax:

```
> show xdsl imp-noise-sensor far-end current-1day (if-index) inm-equiv-inp-histo [ (class-interval) ]
```

Command Parameters

Table 109.56-1 "xDSL INS Far End Current Day EINP Histogram" Resource Parameters

Resource Identifier	Type	Description
(if-index)	Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number	interface index of the port
(class-interval)	Format: - impulse noise monitoring equivalent INP histogram - range: [1...17]	class interval

Command Output

Table 109.56-2 "xDSL INS Far End Current Day EINP Histogram" Display parameters

Specific Information		
name	Type	Description
counter	Parameter type: <SignedInteger> - a signed integer	counter <i>This element is always shown.</i>

109.57 xDSL INS Far End Previous 15Min Data Status Command

Command Description

This command displays the xDSL Impulse-Noise-Sensor far-end previous 15Min data. Note: Timestamp value will be displayed only when actual Impulse-Noise counter values are retrieved.

User Level

The command can be accessed by operators with xdsl privileges.

Command Syntax

The command has the following syntax:

```
> show xdsl imp-noise-sensor far-end previous-interval [ (if-index) ]
```

Command Parameters

Table 109.57-1 "xDSL INS Far End Previous 15Min Data Status Command" Resource Parameters

Resource Identifier	Type	Description
(if-index)	Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number	interface index of the port

Command Output

Table 109.57-2 "xDSL INS Far End Previous 15Min Data Status Command" Display parameters

Specific Information		
name	Type	Description
inm-data-symb-cnt	Parameter type: <Xdsl::DataSymbolCounter> - an unsigned integer	number of monitored data symbols <i>This element is always shown.</i>
interval-time	Parameter type: <Xdsl::PmTimeStamp> - Timestamp for Pm interval(yyyymmdd:hour:minutes)	specifies the start time of interval <i>This element is always shown.</i>

109.58 xDSL INS Far End Previous 15Min IAT Histogram

Command Description

This command displays the xDSL Impulse-Noise-Sensor far-end previous 15Min Inter-Arrival-Time histogram.

User Level

The command can be accessed by operators with xdsl privileges.

Command Syntax

The command has the following syntax:

```
> show xdsl imp-noise-sensor far-end previous-interval (if-index) inm-iat-histo [ (class-interval) ]
```

Command Parameters

Table 109.58-1 "xDSL INS Far End Previous 15Min IAT Histogram" Resource Parameters

Resource Identifier	Type	Description
(if-index)	Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number	interface index of the port
(class-interval)	Format: - impulse noise monitoring inter arrival time histogram - range: [1...8]	class interval

Command Output

Table 109.58-2 "xDSL INS Far End Previous 15Min IAT Histogram" Display parameters

Specific Information		
name	Type	Description
counter	Parameter type: <SignedInteger> - a signed integer	counter <i>This element is always shown.</i>

109.59 xDSL INS Far End Previous 15Min EINP Histogram

Command Description

This command displays the xDSL Impulse-Noise-Sensor far-end previous 15Min Equivalent-Impulse-Noise-Protection histogram.

User Level

The command can be accessed by operators with xdsl privileges.

Command Syntax

The command has the following syntax:

```
> show xdsl imp-noise-sensor far-end previous-interval (if-index) inm-equiv-inp-histo [ (class-interval) ]
```

Command Parameters

Table 109.59-1 "xDSL INS Far End Previous 15Min EINP Histogram" Resource Parameters

Resource Identifier	Type	Description
(if-index)	Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number	interface index of the port
(class-interval)	Format: - impulse noise monitoring equivalent INP histogram - range: [1...17]	class interval

Command Output

Table 109.59-2 "xDSL INS Far End Previous 15Min EINP Histogram" Display parameters

Specific Information		
name	Type	Description
counter	Parameter type: <SignedInteger> - a signed integer	counter <i>This element is always shown.</i>

109.60 xDSL INS Far End Previous Day Status Command

Command Description

This command displays the xDSL Impulse-Noise-Sensor far-end previous day data. Note: Timestamp value will be displayed only when actual Impulse-Noise counter values are retrieved.

User Level

The command can be accessed by operators with xdsl privileges.

Command Syntax

The command has the following syntax:

```
> show xdsl imp-noise-sensor far-end previous-1day [ (if-index) ]
```

Command Parameters

Table 109.60-1 "xDSL INS Far End Previous Day Status Command" Resource Parameters

Resource Identifier	Type	Description
(if-index)	Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number	interface index of the port

Command Output

Table 109.60-2 "xDSL INS Far End Previous Day Status Command" Display parameters

Specific Information		
name	Type	Description
inm-data-symb-cnt	Parameter type: <Xdsl::DataSymbolCounter> - an unsigned integer	number of monitored data symbols <i>This element is always shown.</i>
interval-time	Parameter type: <Xdsl::PmTimeStamp> - Timestamp for Pm interval(yyyymmdd:hour:minutes)	specifies the start time of interval <i>This element is always shown.</i>

109.61 xDSL INS Far End Previous Day IAT Histogram

Command Description

This command displays the xDSL Impulse-Noise-Sensor far-end previous day Inter-Arrival-Time histogram.

User Level

The command can be accessed by operators with xdsl privileges.

Command Syntax

The command has the following syntax:

```
> show xdsl imp-noise-sensor far-end previous-1day (if-index) inm-iat-histo [ (class-interval) ]
```

Command Parameters

Table 109.61-1 "xDSL INS Far End Previous Day IAT Histogram" Resource Parameters

Resource Identifier	Type	Description
(if-index)	Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number	interface index of the port
(class-interval)	Format: - impulse noise monitoring inter arrival time histogram - range: [1...8]	class interval

Command Output

Table 109.61-2 "xDSL INS Far End Previous Day IAT Histogram" Display parameters

Specific Information		
name	Type	Description
counter	Parameter type: <SignedInteger> - a signed integer	counter <i>This element is always shown.</i>

109.62 xDSL INS Far End Previous Day EINP Histogram

Command Description

This command displays the xDSL Impulse-Noise-Sensor far-end previous day Equivalent-Impulse-Noise-Protection histogram.

User Level

The command can be accessed by operators with xdsl privileges.

Command Syntax

The command has the following syntax:

```
> show xdsl imp-noise-sensor far-end previous-1day (if-index) inm-equiv-inp-histo [ (class-interval) ]
```

Command Parameters

Table 109.62-1 "xDSL INS Far End Previous Day EINP Histogram" Resource Parameters

Resource Identifier	Type	Description
(if-index)	Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number	interface index of the port
(class-interval)	Format: - impulse noise monitoring equivalent INP histogram - range: [1...17]	class interval

Command Output

Table 109.62-2 "xDSL INS Far End Previous Day EINP Histogram" Display parameters

Specific Information		
name	Type	Description
counter	Parameter type: <SignedInteger> - a signed integer	counter <i>This element is always shown.</i>

109.63 xDSL Downstream Vectoring Disturberlist Status Command

Command Description

Obsolete command, replaced by `show xdsl vect-disturber-list downstream r/s/p`.

This command displays the downstream disturber list for a specified victim line. The operator can also specify the maximum number of disturbers to be reported through the `max-reported-dist` parameter.

The disturber list will contain the following information per reported disturber:

- disturber line identifier
- Average Magnitude (available for both G.Fast and G.Vect lines), range [-32768,-1400 -400], unit 0.1dBm/Hz or Equal level FEXT (available for G.Vect lines), range [-32768,-1000,200], unit 0.1dB.
- Special value -32768 indicates that the averaged xtalk magnitude or elfext magnitude could not be estimated.
- cancelled line indicator [false,true,low,high]

User Level

The command can be accessed by operators with `xdsl` privileges.

Command Syntax

The command has the following syntax:

```
> show xdsl vect-disturbers [ (victim-line) ] [ no max-reported-dist | max-reported-dist <Xdsl::VectMaxNbrDist> ]
```

Obsolete command, replaced by `show xdsl vect-disturber-list downstream r/s/p`.

Command Parameters

Table 109.63-1 "xDSL Downstream Vectoring Disturberlist Status Command" Resource Parameters

Resource Identifier	Type	Description
(victim-line)	Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number	interface index of the port

Table 109.63-2 "xDSL Downstream Vectoring Disturberlist Status Command" Command Parameters

Parameter	Type	Description
[no] max-reported-dist	Parameter type: <Xdsl::VectMaxNbrDist> Format: - max number of vector disturbers to be reported - range: [1...767]	<i>optional parameter with default value: 10</i> defines the maximum number of disturbers to be reported

Command Output

Table 109.63-3 "xDSL Downstream Vectoring Disturberlist Status Command" Display parameters

Specific Information		
name	Type	Description
max-reported-dist	Parameter type: <Xdsl::VectMaxNbrDist> - max number of vector disturbers to be reported - range: [1...767]	defines the maximum number of disturbers to be reported <i>This element is only shown in detail mode.</i>
disturber-list	Parameter type: <Xdsl::VectDistPrintableString> - the vector disturber list	sorted list of disturber lines. The strongest disturbers are listed first. Data per reported disturber in the list : disturber identifier, average magnitude 0.1dBm/Hz, cancelled line indicator. <i>This element is only shown in detail mode.</i>

109.64 xDSL Upstream Vectoring Disturberlist Status Command

Command Description

This command displays the upstream disturber list for a specified victim line. The operator can also specify the maximum number of disturbers to be reported through the max-reported-dist parameter.

The disturber list will contain the following information per reported disturber:

- disturber line identifier
- Average Magnitude, range [-32768,-1400 -400], unit 0.1dBm/Hz
- Special value -32768 indicates that the averaged xtalk magnitude could not be estimated.
- cancelled line indicator [false,true,low,high]

User Level

The command can be accessed by operators with xdsl privileges.

Command Syntax

The command has the following syntax:

```
> show xdsl vect-disturber-list upstream [ (victim-line) ] [ no max-reported-dist | max-reported-dist
<Xdsl::VectMaxNbrDist> ]
```

Command Parameters

Table 109.64-1 "xDSL Upstream Vectoring Disturberlist Status Command" Resource Parameters

Resource Identifier	Type	Description
(victim-line)	Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number	interface index of the port

Table 109.64-2 "xDSL Upstream Vectoring Disturberlist Status Command" Command Parameters

Parameter	Type	Description
[no] max-reported-dist	Parameter type: <Xdsl::VectMaxNbrDist> Format: - max number of vector disturbers to be reported - range: [1...767]	optional parameter with default value: 10 defines the maximum number of disturbers to be reported

Command Output

Table 109.64-3 "xDSL Upstream Vectoring Disturberlist Status Command" Display parameters

Specific Information		
name	Type	Description
max-reported-dist	Parameter type: <Xdsl::VectMaxNbrDist> - max number of vector disturbers to be reported - range: [1...767]	defines the maximum number of disturbers to be reported <i>This element is only shown in detail mode.</i>
disturber-list	Parameter type: <Xdsl::MultiVectDistPrintableString> - the vector disturber list	sorted list of disturber lines. The strongest disturbers are listed first. Data per reported disturber in the list : disturber identifier, average magnitude 0.1dBm/Hz, cancelled line indicator. <i>This element is only shown in detail mode.</i>

109.65 xDSL Downstream Vectoring Disturberlist Status Command

Command Description

This command displays the downstream disturber list for a specified victim line. The operator can also specify the maximum number of disturbers to be reported through the max-reported-dist parameter.

The disturber list will contain the following information per reported disturber:

- disturber line identifier
- Average Magnitude (available for both G.Fast and G.Vect lines), range [-32768,-1400 -400], unit 0.1dBm/Hz or Equal level FEXT (available for G.Vect lines), range [-32768,-1000,200], unit 0.1dB.
- Special value -32768 indicates that the averaged xtalk magnitude or elfext magnitude could not be estimated.
- cancelled line indicator [false,true,low,high]

User Level

The command can be accessed by operators with xdsl privileges.

Command Syntax

The command has the following syntax:

```
> show xdsl vect-disturber-list downstream [ (victim-line) ] [ no max-reported-dist | max-reported-dist
<Xdsl::VectMaxNbrDist> ] [ no calc-mode | calc-mode <Xdsl::VectCalcMode> ]
```

Command Parameters

Table 109.65-1 "xDSL Downstream Vectoring Disturberlist Status Command" Resource Parameters

Resource Identifier	Type	Description
(victim-line)	Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number	interface index of the port

Table 109.65-2 "xDSL Downstream Vectoring Disturberlist Status Command" Command Parameters

Parameter	Type	Description
[no] max-reported-dist	Parameter type: <Xdsl::VectMaxNbrDist>	optional parameter with default

Parameter	Type	Description
	Format: - max number of vector disturbers to be reported - range: [1...767]	<i>value: 10</i> defines the maximum number of disturbers to be reported
[no] calc-mode	Parameter type: <Xdsl::VectCalcMode> Format: (avmag elfext) Possible values: - avmag : calculates avg magnitude of disturber - elfext : calculates elfext magnitude of disturber	<i>optional parameter with default value: "avmag"</i> defines the calculation mode for disturbers to be reported

Command Output

Table 109.65-3 "xDSL Downstream Vectoring Disturberlist Status Command" Display parameters

Specific Information		
name	Type	Description
max-reported-dist	Parameter type: <Xdsl::VectMaxNbrDist> - max number of vector disturbers to be reported - range: [1...767]	defines the maximum number of disturbers to be reported <i>This element is only shown in detail mode.</i>
disturber-list	Parameter type: <Xdsl::MultiVectDistPrintableString> - the vector disturber list	sorted list of disturber lines. The strongest disturbers are listed first. Data per reported disturber in the list : disturber identifier, average magnitude 0.1dBm/Hz or ELFEXT 0.1dB, cancelled line indicator. <i>This element is only shown in detail mode.</i>

109.66 xDSL Vectoring Carrier Data Near End

Status Command

Command Description

This command displays xDSL vectoring carrier data near end.

Carrier data is displayed in raw format so the actual data interpretation is described in this section.

The XDSL passband (downstream or upstream) is composed of one or more bands (max 5, including VDSL optional band). Each carrier is coded as a bitmap. When the data are not available because the measurement is not completed, not enabled or not supported, an empty string will be returned. Below is the definition of the carrier specific bitmap.

Crosstalk Matrix : *The carrier XLINs is coded as a bitmap defined as follows:*

- OCTETS 0,1: INTEGER, (1..512) contains the carrier group size. The value is defined as MSB-LSB (big-endian)
- OCTETS 2,3: INTEGER(0..65535), contains the scale factor to apply to the xlin values, over the upstream band(s). The value is defined as MSB-LSB (big-endian).
- OCTETS 4,5 : INTEGER (0..8191), index of the start carrier index of the first upstream band. The value is defined as MSB-LSB (big-endian).
- OCTETS 6,7 : INTEGER (0..8191), index of the stop carrier index of the first upstream band. The value is defined as MSB-LSB (big-endian).
- OCTETS 8,9 : SIGNED INTEGER , contains the ai for the first carrier index of the band (start carrier index). The value is defined as MSB-LSB (big-endian).
- OCTETS 10,11: SIGNED INTEGER , contains the bi for the first carrier index of the band (start carrier index). The value is defined as MSB-LSB (big-endian).
- OCTETS 12..L: ai and bi for the next carrier index and so on until the last carrier index of the first upstream band (stop carrier index).
- OCTETS L+1..M: contain the start/stop carrier groups and the XLIN ai and bi of the second upstream band when available.
- OCTETS M+1..N: contain the start/stop carrier index and the XLIN ai and bi of the third upstream band when available.
- OCTETS N+1..P: contain the start/stop carrier index and the XLIN ai and bi of the fourth upstream band when available.
- OCTETS P+1..Q: contain the start/stop carrier index and the XLIN ai and bi of the fifth upstream band when available.

User Level

The command can be accessed by operators with xdsl privileges.

Command Syntax

The command has the following syntax:

```
> show xdsl vect-carrier-data near-end [ (line) ] disturber-line <Xdsl::MultiXdslLine> [ no vgr-link | vgr-link <Xdsl::VectGrpLink> ] [ no group-sampling | group-sampling <Xdsl::ReqSamplingRate> ]
```

Command Parameters

Table 109.66-1 "xDSL Vectoring Carrier Data Near End Status Command" Resource Parameters

Resource Identifier	Type	Description
(line)	Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number	interface index of the port

Table 109.66-2 "xDSL Vectoring Carrier Data Near End Status Command" Command Parameters

Parameter	Type	Description
disturber-line	Parameter type: <Xdsl::MultiXdslLine> Format: <Eqpt::MultiRackId> / <Eqpt::MultiShelfId> / <Eqpt::MultiLtSlotId> / <Eqpt::MultiPortId> Field type <Eqpt::MultiRackId> - the rack number Field type <Eqpt::MultiShelfId> - the shelf number Field type <Eqpt::MultiLtSlotId> - the LT board slot number Field type <Eqpt::MultiPortId> - the port number	<i>optional parameter</i> the interface identifier of the disturber
[no] vgr-link	Parameter type: <Xdsl::VectGrpLink> Format: (local <Xdsl::VectGrpLink>) Possible values: - local : vp-slv and disturber-line are managed by the local isam Field type <Xdsl::VectGrpLink> - specifies the vectgroup link - range: [1...16]	<i>optional parameter with default value: "local"</i> the vector grouplink is mandatory when the vp-slv and/or the disturber-line are managed by a remote isam
[no] group-sampling	Parameter type: <Xdsl::ReqSamplingRate> Format: - the requested group sampling rate. Note that while values less than 4 are accepted, the min actual group sampling rate will be 4 if the crosstalk matrix is available. - range: [1...50]	<i>optional parameter with default value: 1</i> the requested group sampling rate of the reported xlin.

Command Output

Table 109.66-3 "xDSL Vectoring Carrier Data Near End Status Command" Display parameters

Specific Information		
name	Type	Description
disturber	Parameter type: <Xdsl::MultiXdslLine> <Eqpt::MultiRackId> / <Eqpt::MultiShelfId> /	the interface identifier of the disturber

109 xDSL Status Commands

name	Type	Description
	<Eqpt::MultiLtSlotId> / <Eqpt::MultiPortId> Field type <Eqpt::MultiRackId> - the rack number Field type <Eqpt::MultiShelfId> - the shelf number Field type <Eqpt::MultiLtSlotId> - the LT board slot number Field type <Eqpt::MultiPortId> - the port number	<i>This element is always shown.</i>
vgr-link	Parameter type: <Xdsl::VectGrpLink> (local <Xdsl::VectGrpLink>) Possible values: - local : vp-slv and disturber-line are managed by the local isam Field type <Xdsl::VectGrpLink> - specifies the vectgroup link - range: [1...16]	the vectorgroup link identifier or local <i>This element is always shown.</i>
group-sampling	Parameter type: <Xdsl::SamplingRate> - the group sampling rate of reported xlin - range: [1...50]	the actual selected group sampling rate of the reported xlin <i>This element is always shown.</i>
xtalk-mat-complex	Parameter type: <Xdsl::OctetStingType> - a binary string	provides the crosstalk matrix values in linear scale for each carrier group over the upstream passband(xlin) <i>This element is always shown.</i>

109.67 xDSL Vectoring Carrier Data Far End Status Command

Command Description

This command displays xDSL vectoring carrier data far end.

Carrier data is displayed in raw format so the actual data interpretation is described in this section.

The XDSL passband (downstream or upstream) is composed of one or more bands (max 5, including VDSL optional band). Each carrier is coded as a bitmap. When the data are not available because the measurement is not completed, not enabled or not supported, an empty string will be returned. Below is the definition of the carrier specific bitmap.

Crosstalk Matrix : *The carrier XLINs is coded as a bitmap defined as follows:*

- OCTETS 0,1: INTEGER, (1..512) contains the carrier group size. The value is defined as MSB-LSB (big-endian)
- OCTETS 2,3: INTEGER(0..65535), contains the scale factor to apply to the xlin values, over the downstream band(s). The value is defined as MSB-LSB (big-endian).
- OCTETS 4,5 : INTEGER (0..8191), index of the start carrier index of the first downstream band. The value is defined as MSB-LSB (big-endian).
- OCTETS 6,7 : INTEGER (0..8191), index of the stop carrier index of the first downstream band. The value is defined as MSB-LSB (big-endian).
- OCTETS 8,9 : SIGNED INTEGER , contains the ai for the first carrier index of the band (start carrier index). The value is defined as MSB-LSB (big-endian).
- OCTETS 10,11: SIGNED INTEGER , contains the bi for the first carrier index of the band (start carrier index). The value is defined as MSB-LSB (big-endian).
- OCTETS 12..L: ai and bi for the next carrier index and so on until the last carrier index of the first downstream band (stop carrier index).
- OCTETS L+1..M: contain the start/stop carrier groups and the XLIN ai and bi of the second downstream band when available.
- OCTETS M+1..N: contain the start/stop carrier index and the XLIN ai and bi of the third downstream band when available.
- OCTETS N+1..P: contain the start/stop carrier index and the XLIN ai and bi of the fourth downstream band when available.
- OCTETS P+1..Q: contain the start/stop carrier index and the XLIN ai and bi of the fifth downstream band when available.

User Level

The command can be accessed by operators with xdsl privileges.

Command Syntax

The command has the following syntax:

```
> show xdsl vect-carrier-data far-end [ (line) ] disturber-line <Xdsl::MultiXdslLine> [ no vgr-link | vgr-link <Xdsl::VectGrpLink> ] [ no group-sampling | group-sampling <Xdsl::ReqSamplingRate> ]
```

Command Parameters

Table 109.67-1 "xDSL Vectoring Carrier Data Far End Status Command" Resource Parameters

Resource Identifier	Type	Description
(line)	Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number	interface index of the port

Table 109.67-2 "xDSL Vectoring Carrier Data Far End Status Command" Command Parameters

Parameter	Type	Description
disturber-line	Parameter type: <Xdsl::MultiXdslLine> Format: <Eqpt::MultiRackId> / <Eqpt::MultiShelfId> / <Eqpt::MultiLtSlotId> / <Eqpt::MultiPortId> Field type <Eqpt::MultiRackId> - the rack number Field type <Eqpt::MultiShelfId> - the shelf number Field type <Eqpt::MultiLtSlotId> - the LT board slot number Field type <Eqpt::MultiPortId> - the port number	<i>optional parameter</i> the interface identifier of the disturber
[no] vgr-link	Parameter type: <Xdsl::VectGrpLink> Format: (local <Xdsl::VectGrpLink>) Possible values: - local : vp-slv and disturber-line are managed by the local isam Field type <Xdsl::VectGrpLink> - specifies the vectgroup link - range: [1...16]	<i>optional parameter with default value: "local"</i> the vector grouplink is mandatory when the vp-slv and/or the disturber-line are managed by a remote isam
[no] group-sampling	Parameter type: <Xdsl::ReqSamplingRate> Format: - the requested group sampling rate. Note that while values less than 4 are accepted, the min actual group sampling rate will be 4 if the crosstalk matrix is available. - range: [1...50]	<i>optional parameter with default value: 1</i> the requested group sampling rate of the reported xlin.

Command Output

Table 109.67-3 "xDSL Vectoring Carrier Data Far End Status Command" Display parameters

Specific Information		
name	Type	Description
disturber	Parameter type: <Xdsl::MultiXdslLine> <Eqpt::MultiRackId> / <Eqpt::MultiShelfId> /	the interface identifier of the disturber

name	Type	Description
	<Eqpt::MultiLtSlotId> / <Eqpt::MultiPortId> Field type <Eqpt::MultiRackId> - the rack number Field type <Eqpt::MultiShelfId> - the shelf number Field type <Eqpt::MultiLtSlotId> - the LT board slot number Field type <Eqpt::MultiPortId> - the port number	<i>This element is always shown.</i>
vgr-link	Parameter type: <Xdsl::VectGrpLink> (local <Xdsl::VectGrpLink>) Possible values: - local : vp-slv and disturber-line are managed by the local isam Field type <Xdsl::VectGrpLink> - specifies the vectgroup link - range: [1...16]	the vectorgroup link identifier or local <i>This element is always shown.</i>
group-sampling	Parameter type: <Xdsl::SamplingRate> - the group sampling rate of reported xlin - range: [1...50]	the actual selected group sampling rate of the reported xlin <i>This element is always shown.</i>
xtalk-mat-complex	Parameter type: <Xdsl::OctetStingType> - a binary string	provides the crosstalk matrix values in linear scale for each carrier group over the upstream passband(xlin) <i>This element is always shown.</i>

109.68 xDSL Vectoring Processing Board Status Command

Command Description

This command allows the operator to show which LTs are actual connected to the vp-board. It also gives status information on the cable connection and the related vectoring control entity.

User Level

The command can be accessed by operators with xdsl privileges.

Command Syntax

The command has the following syntax:

```
> show xdsl vp-board [ (board-index) [ vp-link <Xdsl::VectVpLink> ] ]
```

Command Parameters

Table 109.68-1 "xDSL Vectoring Processing Board Status Command" Resource Parameters

Resource Identifier	Type	Description
(board-index)	Format: (ctrl : <Eqpt::RackId> / <Eqpt::ShelfId> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId>) Possible values: - ctrl : ctrl-slot Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number	vp board index
vp-link	Parameter type: <Xdsl::VectVpLink> Format: - specifies the vp-link or the soft-link on the vp-board - range: [1...16]	the (soft) link on the vp board

Command Output

Table 109.68-2 "xDSL Vectoring Processing Board Status Command" Display parameters

Specific Information		
name	Type	Description
lt-detect	Parameter type: <Xdsl::ActLsmBoardOrZero> (<Eqpt::MultiRackId> / <Eqpt::MultiShelfId> /	actual detected lt board slot index or value "none"

name	Type	Description
	<Eqpt::MultiSlotId> none) Possible values: - none : lt board not specified Field type <Eqpt::MultiRackId> - the rack number Field type <Eqpt::MultiShelfId> - the shelf number Field type <Eqpt::MultiSlotId> - the LT slot number	<i>This element is always shown.</i>
lt-link-nr short name: lt-lnk	Parameter type: <Xdsl::VectLtLink> - specifies the lt-link on the lt-board - range: [0...2]	link id of the slv lt <i>This element is always shown.</i>
link-status	Parameter type: <Xdsl::VpLinkStatus> ((not-connected not-connect) (connected connect) (operational oper) not-appl) Possible values: - not-connected : missing cable, invalid qsfp or connected lt not active OR in case of a soft-link: no SLV-LT plugged in - not-connect : missing cable, invalid qsfp or connected lt not active OR in case of a soft-link: no SLV-LT plugged in - connected : vp-lt communication possible - connect : vp-lt communication possible - operational : vp-lt communication operational - oper : vp-lt communication operational - not-appl : the link status is not applicable	the status of the cable connected to the vp-link OR the soft-link status <i>This element is always shown.</i>
vce-status	Parameter type: <Xdsl::VceStatus> ((not-operational not-oper) (operational oper) not-appl) Possible values: - not-operational : link-status not operational or lt not synchronized with vp-board - not-oper : link-status not operational or lt not synchronized with vp-board - operational : link-status operational and lt synchronized with vp-board - oper : link-status operational and lt synchronized with vp-board - not-appl : not applicable	the status of the vectoring control entity <i>This element is always shown.</i>
qsfp-status	Parameter type: <Xdsl::QsfpStatus> (not-present invalid valid not-appl) Possible values: - not-present : the hw does not detect a qsfp connector - invalid : the detected qsfp does not contain a valid qsfp string - valid : the detected qsfp connector is valid and operational - not-appl : the qsfp status is not applicable	the vp-qsfp connector status OR not applicable in case of soft-links <i>This element is always shown.</i>
isam-ip	Parameter type: <Xdsl::IpAddress> - IPv4-address	the ip address of the isam which holds the detected lt board <i>This element is always shown.</i>
system-id	Parameter type: <Sys::systemId>	a unique system identification

109 xDSL Status Commands

name	Type	Description
	- system ID - range: printable string (no white-spaces) - length: x<=64	<i>This element is only shown in detail mode.</i>

109.69 xDSL Vectoring Processing Group Status Command

Command Description

This command allows the operator to retrieve, for a specified lt board (optional parameter), the vectoring group information and its own info.

A vectoring group exists of a vp board and, per vgr-link, the detected lt's which passed their identification over the vp-lt-link to the vp board.

Every update in the vectoring group e.g. new detected lt or vp has lost connectivity with an lt, is broadcasted by the vp to all lt's within the group.

Therefore:

- vectoring group info: contains the **last retrieved data from the vp board when the vp-lt-link was operational!**
 - vp info: id of the vp board , the IP@ and system-id of the system which holds the vp board, vce status
 - info per vgr-link:
 - the qsf status of the connector on the vp board
 - id of the detected lt, the IP@ and system-id of the system which holds the detected lt, the link status and vce status
- own info: contains the actual status of its vp-lt-link, the qsf status of the connector on the lt, the IP@ and system-id of the system which holds the lt
- own2 info: contains the actual status of its second vp-lt-link, the qsf status of the connector on the lt, the IP@ and system-id of the system which holds the lt

User Level

The command can be accessed by operators with xdsl privileges.

Command Syntax

The command has the following syntax:

```
> show xdsl vect-group [ (board-index) [ vgr-link <Xdsl::VectGroupLink> ] ]
```

Command Parameters

Table 109.69-1 "xDSL Vectoring Processing Group Status Command" Resource Parameters

Resource Identifier	Type	Description
(board-index)	Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId>) Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number	vp board index

Resource Identifier	Type	Description
	Field type <Eqpt::SlotId> - the LT slot number	
vgr-link	Parameter type: <Xdsl::VectGroupLink> Format: (vp own own2 <Xdsl::VectGroupLink>) Possible values: - vp : vp-board entry in the vectgroup table - own : own lt entry in the vectgroup table - own2 : second own lt entry in the vectgroup table Field type <Xdsl::VectGroupLink> - specifies the vp-link or the soft-link on the vp-board - range: [1...16]	the vector group link

Command Output

Table 109.69-2 "xDSL Vectoring Processing Group Status Command" Display parameters

Specific Information		
name	Type	Description
board-detect	Parameter type: <Xdsl::VectGroupActLsmBoardOrZero> (lt : <Eqpt::MultiRackId> / <Eqpt::MultiShelfId> / <Eqpt::MultiLtSlotId> ctrl : <Eqpt::MultiRackId> / <Eqpt::MultiShelfId> acu : <Eqpt::MultiRackId> / <Eqpt::MultiShelfId> <Eqpt::MultiRackId> / <Eqpt::MultiShelfId> / <Eqpt::MultiLtSlotId> none) Possible values: - none : lt board not specified - lt : lt-slot - ctrl : ctrl-slot - acu : acu-slot Field type <Eqpt::MultiRackId> - the rack number Field type <Eqpt::MultiShelfId> - the shelf number Field type <Eqpt::MultiLtSlotId> - the LT board slot number	a board slot index or value "none" <i>This element is always shown.</i>
lt-link-nr short name: lt-lnk	Parameter type: <Xdsl::VectLtLink> - specifies the lt-link on the lt-board - range: [0...2]	link id of the slv lt <i>This element is always shown.</i>
link-status	Parameter type: <Xdsl::VpLinkStatus> ((not-connected not-connect) (connected connect) (operational oper) not-appl) Possible values: - not-connected : missing cable, invalid qsfp or connected lt not active OR in case of a soft-link: no SLV-LT plugged in - not-connect : missing cable, invalid qsfp or connected lt not active OR in case of a soft-link: no SLV-LT plugged in - connected : vp-lt communication possible - connect : vp-lt communication possible - operational : vp-lt communication operational	the status of the cable connected to the vp-link of the vp-board OR the soft-link status. The vp-link value is equal to the vgr-link. <i>This element is always shown.</i>

name	Type	Description
	- oper : vp-lt communication operational - not-appl : the link status is not applicable	
vce-status	Parameter type: <Xdsl::VceStatus> ((not-operational not-oper) (operational oper) not-appl) Possible values: - not-operational : link-status not operational or lt not synchronized with vp-board - not-oper : link-status not operational or lt not synchronized with vp-board - operational : link-status operational and lt synchronized with vp-board - oper : link-status operational and lt synchronized with vp-board - not-appl : not applicable	the status of the vectoring control entity <i>This element is always shown.</i>
qsfp-status	Parameter type: <Xdsl::QsfpStatus> (not-present invalid valid not-appl) Possible values: - not-present : the hw does not detect a qsfp connector - invalid : the detected qsfp does not contain a valid qsfp string - valid : the detected qsfp connector is valid and operational - not-appl : the qsfp status is not applicable	the qsfp connector status OR not applicable in case of soft-links <i>This element is always shown.</i>
isam-ip	Parameter type: <Xdsl::IpAddress> - IPv4-address	the ip address of the isam which holds the detected board <i>This element is always shown.</i>
system-id	Parameter type: <Sys::systemId> - system ID - range: printable string (no white-spaces) - length: x<=64	a unique system identification <i>This element is only shown in detail mode.</i>

110- Configuration Data Status Commands

110.1 Configuration Data Status Command Tree	110-5577
110.2 xDSL Port Configuration Status Command	110-5578
110.3 xDSL Port ATM Configuration Status Command	110-5584
110.4 xDSL Port ATM Interface Configuration Status Command	110-5586
110.5 xDSL Port Interface Configuration Status Command	110-5588
110.6 xDSL IGMP Configuration Status Command	110-5590
110.7 xDSL Security PAE Configuration Status Command	110-5592
110.8 xDSL BridgePort Configuration Status Command	110-5595
110.9 xDSL QoS Configuration Status Command	110-5599
110.10 xDSL PPPoX Relay Configuration Status Command	110-5601
110.11 xDSL Bonding Group Configuration Status Command	110-5603

110.1 Configuration Data Status Command Tree

Description

This chapter gives an overview of nodes that are handled by "Configuration Data Status Commands".

Command Tree

```
----show
  ----xdsl
    ----config-data-port
      - (if-index)
        ----xdsl
          ----atm-pvc
            - (port-index)
          ----interface-atm-pvc
            - (pvc-index)
          ----interface-port
          ----igmp
            - (port)
          ----security-pae
            - (port)
          ----bridge-port
            - (port)
          ----qos
          ----pppox-relay
            - (port)
          ----bonding-group
```

110.2 xDSL Port Configuration Status Command

Command Description

This command displays the xDSL Port Configuration data.

User Level

The command can be accessed by operators with xdsl privileges.

Command Syntax

The command has the following syntax:

```
> show xdsl config-data-port (if-index) xdsl
```

Command Parameters

Table 110.2-1 "xDSL Port Configuration Status Command" Resource Parameters

Resource Identifier	Type	Description
(if-index)	Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number	interface index of the port

Command Output

Table 110.2-2 "xDSL Port Configuration Status Command" Display parameters

Specific Information		
name	Type	Description
service-profile	Parameter type: <AsamProfilePointer> - a pointer to a profile or profile index - range: [0...65535]	ADSLx/VDSLx service profile configured on this port <i>This element is always shown.</i>
spectrum-profile	Parameter type: <AsamProfilePointer> - a pointer to a profile or profile index - range: [0...65535]	ADSLx/VDSLx spectrum profile configured on this port <i>This element is always shown.</i>
dpbo-profile	Parameter type: <Xdsl::DpboProfilePointer> - profile index - range: [0...50]	ADSLx/VDSLx dpbo profile configured on this port <i>This element is always shown.</i>
rtx-profile	Parameter type: <AsamProfilePointer>	ADSLx/VDSLx rtx profile

name	Type	Description
	- a pointer to a profile or profile index - range: [0...65535]	configured on this port <i>This element is always shown.</i>
vect-profile	Parameter type: <AsamProfilePointer> - a pointer to a profile or profile index - range: [0...65535]	VDLS2 vectoring profile configured on this port <i>This element is always shown.</i>
ansi-t1413	Parameter type: <Xdsl::T1413> (dis-ansi-t1413 ansi-t1413) Possible values: - dis-ansi-t1413 : disable ANSI T1.413-1998 - ansi-t1413 : ANSI T1.413-1998	ANSI T1.413-1998 <i>This element is always shown.</i>
etsi-dts	Parameter type: <Xdsl::Etsidts> (dis-etsi-dts etsi-dts) Possible values: - dis-etsi-dts : disable ETSI DTS/TM06006 - etsi-dts : ETSI DTS/TM06006	ETSI DTS/TM06006 <i>This element is always shown.</i>
g992-1-a	Parameter type: <Xdsl::G21potsnos> (dis-g992-1-a g992-1-a) Possible values: - dis-g992-1-a : disable G.992.1 POTS non-overlapped spectrum - g992-1-a : G.992.1 POTS non-overlapped spectrum	G.992.1 POTS non-overlapped spectrum <i>This element is always shown.</i>
g992-1-b	Parameter type: <Xdsl::G21isdnnos> (dis-g992-1-b g992-1-b) Possible values: - dis-g992-1-b : disable G.992.1 ISDN non-overlapped spectrum - g992-1-b : G.992.1 ISDN non-overlapped spectrum	G.992.1 ISDN non-overlapped spectrum <i>This element is always shown.</i>
g992-2-a	Parameter type: <Xdsl::G22potsnos> (dis-g992-2-a g992-2-a) Possible values: - dis-g992-2-a : disable G.992.2 POTS non-overlapped spectrum - g992-2-a : G.992.2 POTS non-overlapped spectrum	G.992.2 POTS non-overlapped spectrum <i>This element is always shown.</i>
g992-3-a	Parameter type: <Xdsl::G23potsnos> (dis-g992-3-a g992-3-a) Possible values: - dis-g992-3-a : disable G.992.3 POTS non-overlapped spectrum - g992-3-a : G.992.3 POTS non-overlapped spectrum	G.992.3 POTS non-overlapped spectrum <i>This element is always shown.</i>
g992-3-b	Parameter type: <Xdsl::G23isdnnos> (dis-g992-3-b g992-3-b) Possible values: - dis-g992-3-b : disable G.992.3 ISDN non-overlapped spectrum - g992-3-b : G.992.3 ISDN non-overlapped spectrum	G.992.3 ISDN non-overlapped spectrum <i>This element is always shown.</i>
g992-3-aj	Parameter type: <Xdsl::G23AllDigNos> (dis-g992-3-aj g992-3-aj) Possible values: - dis-g992-3-aj : disable G.992.3 all digital mode	G.992.3 all digital mode non-overlapped spectrum <i>This element is always shown.</i>

110 Configuration Data Status Commands

name	Type	Description
	non-overlapped spectrum - g992-3-aj : G.992.3 all digital mode non-overlapped spectrum	
g992-3-l1	Parameter type: <Xdsl::G23PotsnosUs1> (dis-g992-3-l1 g992-3-l1) Possible values: - dis-g992-3-l1 : disable G.992.3 POTS non-overlapped spectrum US mask 1 - g992-3-l1 : G.992.3 POTS non-overlapped spectrum US mask 1	G.992.3 POTS non-overlapped spectrum US mask 1 <i>This element is always shown.</i>
g992-3-l2	Parameter type: <Xdsl::G23PotsNosUs2> (dis-g992-3-l2 g992-3-l2) Possible values: - dis-g992-3-l2 : disable G.992.3 POTS non-overlapped spectrum US mask 2 - g992-3-l2 : G.992.3 POTS non-overlapped spectrum US mask 2	G.992.3 POTS non-overlapped spectrum US mask 2 <i>This element is always shown.</i>
g992-3-am	Parameter type: <Xdsl::G23ExtPotsNos> (dis-g992-3-am g992-3-am) Possible values: - dis-g992-3-am : disable G.992.3 extended POTS with non-overlapped spectrum - g992-3-am : G.992.3 extended POTS with non-overlapped spectrum	G.992.3 extended POTS with non-overlapped spectrum <i>This element is always shown.</i>
g992-5-a	Parameter type: <Xdsl::G25PotsNos> (dis-g992-5-a g992-5-a) Possible values: - dis-g992-5-a : disable G.992.5 POTS non-overlapped spectrum - g992-5-a : G.992.5 POTS non-overlapped spectrum	G.992.5 POTS non-overlapped spectrum <i>This element is always shown.</i>
g992-5-b	Parameter type: <Xdsl::G25IsdnNos> (dis-g992-5-b g992-5-b) Possible values: - dis-g992-5-b : disable G.992.5 ISDN non-overlapped spectrum - g992-5-b : G.992.5 ISDN non-overlapped spectrum	G.992.5 ISDN non-overlapped spectrum <i>This element is always shown.</i>
ansi-t1.424	Parameter type: <Xdsl::AnsiT1424> (dis-ansi-t1.424 ansi-t1.424) Possible values: - dis-ansi-t1.424 : disable ANSI T1.424 - ansi-t1.424 : ANSI T1.424	ansi T1.424 <i>This element is always shown.</i>
etsi-ts	Parameter type: <Xdsl::EtsiTs> (dis-etsi-ts etsi-ts) Possible values: - dis-etsi-ts : disable ETSI TS - etsi-ts : ETSI TS	ETSI TS 101 270 <i>This element is always shown.</i>
itu-g993-1	Parameter type: <Xdsl::ItuG9931> (dis-itu-g993-1 itu-g993-1) Possible values:	ITU G993-1 <i>This element is always shown.</i>

name	Type	Description
	- dis-itu-g993-1 : disable ITU G993-1 - itu-g993-1 : ITU G993-1	
ieee-802.3ah	Parameter type: <Xdsl::Ieee802.3Ah> (dis-ieee-802.3ah ieee-802.3ah) Possible values: - dis-ieee-802.3ah : disable IEEE 802.3ah - ieee-802.3ah : IEEE 802.3ah	IEEE 802.3ah <i>This element is always shown.</i>
g992-5-aj	Parameter type: <Xdsl::G25AllDigNos> (dis-g992-5-aj g992-5-aj) Possible values: - dis-g992-5-aj : disable G.992.5 all digital mode non-overlapped spectrum - g992-5-aj : G.992.5 all digital mode non-overlapped spectrum	G.992.5 all digital mode non-overlapped spectrum <i>This element is always shown.</i>
g992-5-am	Parameter type: <Xdsl::G25ExtPotsNos> (dis-g992-5-am g992-5-am) Possible values: - dis-g992-5-am : disable G.992.5 extended POTS non-overlapped spectrum - g992-5-am : G.992.5 extended POTS non-overlapped spectrum	G.992.5 extended POTS non-overlapped spectrum <i>This element is always shown.</i>
g993-2-8a	Parameter type: <Xdsl::GProfile8A> (dis-g993-2-8a g993-2-8a) Possible values: - dis-g993-2-8a : disable G.993.2_8A VDSL-2 with profile 8A - g993-2-8a : G.993.2_8A VDSL-2 with profile 8A	VDSL-2 with profile 8A <i>This element is always shown.</i>
g993-2-8b	Parameter type: <Xdsl::GProfile8B> (dis-g993-2-8b g993-2-8b) Possible values: - dis-g993-2-8b : disable G.993.2_8B VDSL-2 with profile 8B - g993-2-8b : G.993.2_8B VDSL-2 with profile 8B	VDSL-2 with profile 8B <i>This element is always shown.</i>
g993-2-8c	Parameter type: <Xdsl::GProfile8C> (dis-g993-2-8c g993-2-8c) Possible values: - dis-g993-2-8c : disable G.993.2_8C VDSL-2 with profile 8C - g993-2-8c : G.993.2_8C VDSL-2 with profile 8C	VDSL-2 with profile 8C <i>This element is always shown.</i>
g993-2-8d	Parameter type: <Xdsl::GProfile8D> (dis-g993-2-8d g993-2-8d) Possible values: - dis-g993-2-8d : disable G.993.2_8D VDSL-2 with profile 8D - g993-2-8d : G.993.2_8D VDSL-2 with profile 8D	VDSL-2 with profile 8D <i>This element is always shown.</i>
g993-2-12a	Parameter type: <Xdsl::GProfile12A> (dis-g993-2-12a g993-2-12a) Possible values: - dis-g993-2-12a : disable G.993.2_12A VDSL-2 with	VDSL-2 with profile 12A <i>This element is always shown.</i>

110 Configuration Data Status Commands

name	Type	Description
	profile 12A - g993-2-12a : G.993.2_12A VDSL-2 with profile 12A	
g993-2-12b	Parameter type: <Xdsl::GProfile12B> (dis-g993-2-12b g993-2-12b) Possible values: - dis-g993-2-12b : disable G.993.2_12B VDSL-2 with profile 12B - g993-2-12b : G.993.2_12B VDSL-2 with profile 12B	VDSL-2 with profile 12b <i>This element is always shown.</i>
g993-2-17a	Parameter type: <Xdsl::GProfile17A> (dis-g993-2-17a g993-2-17a) Possible values: - dis-g993-2-17a : disable G.993.2_17A VDSL-2 with profile 17A - g993-2-17a : G.993.2_17A VDSL-2 with profile 17A	VDSL-2 with profile 17A <i>This element is always shown.</i>
g993-2-30a	Parameter type: <Xdsl::GProfile30A> (dis-g993-2-30a g993-2-30a) Possible values: - dis-g993-2-30a : disable G.993.2_30A VDSL-2 with profile 30A - g993-2-30a : G.993.2_30A VDSL-2 with profile 30A	VDSL-2 with profile 30A <i>This element is always shown.</i>
g993-2-35b	Parameter type: <Xdsl::GProfile35B> (dis-g993-2-35b g993-2-35b) Possible values: - dis-g993-2-35b : disable G.993.2_35B VDSL-2 with profile 35B - g993-2-35b : G.993.2_35B VDSL-2 with profile 35B	VDSL-2 with profile 35B <i>This element is always shown.</i>
carrier-data-mode	Parameter type: <Xdsl::CarrierDataMode> (off on on-init) Possible values: - off : disable the collection - on : enable the collection - on-init : enable and re-initialize the line	carrier data measurement collection <i>This element is always shown.</i>
admin-state	Parameter type: <Xdsl::XdslAdminStatus> (not-applicable up down testing) Possible values: - not-applicable : not-applicable - up : admin status is up - down : admin status is down - testing : no operational packets can be passed	specifies state of the interface <i>This element is only shown in detail mode.</i>
bonding-mode	Parameter type: <Xdsl::BondingMode> (native atm-bonding bonding) Possible values: - native : (deprecated)native mode for channel-1 - atm-bonding : (deprecated)atm bonding mode for channel-1 obsolete alternative replaced by bonding	channel-1 bonding mode <i>This element is always shown.</i>

name	Type	Description
	- bonding : (deprecated)bonding mode for channel-1	
transfer-mode	Parameter type: <Xdsl::ActualTpsTcMode> (no-value atm ptm system-default) Possible values: - no-value : no value - atm : atm mode - ptm : ptm mode - system-default : determined by the system, based on board type	transfer mode which the node will apply to the line <i>This element is only shown in detail mode.</i>
override-state	Parameter type: <Xdsl::OverrideState> (not-created created-no-overrules created-overrules) Possible values: - not-created : not created - created-no-overrules : created no overrides - created-overrules : created overrides	indicates whether an override record is configured and not all 'no-overrules' <i>This element is only shown in detail mode.</i>

110.3 xDSL Port ATM Configuration Status Command

Command Description

This command displays the xDSL port atm configuration data.

User Level

The command can be accessed by operators with atm privileges.

Command Syntax

The command has the following syntax:

```
> show xdsl config-data-port (if-index) atm-pvc [ (port-index) ]
```

Command Parameters

Table 110.3-1 "xDSL Port ATM Configuration Status Command" Resource Parameters

Resource Identifier	Type	Description
(if-index)	Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number	interface index of the port
(port-index)	Format: (dsl : <Eqpt::VpiMandatoryId> : <Eqpt::VciMandatoryId> dsl) Possible values: - dsl : ADSL/SHDSL board Field type <Eqpt::VpiMandatoryId> - atm VPI Field type <Eqpt::VciMandatoryId> - atm VCI	the ATM PVC

Command Output

Table 110.3-2 "xDSL Port ATM Configuration Status Command" Display parameters

Specific Information		
name	Type	Description
admin-state	Parameter type: <Xdsl::XdslAdminStatusAtm> (up down) Possible values: - up : enable traffic flow - down : disable traffic flow	specifies the administrative state of the VCL. <i>This element is only shown in detail mode.</i>
aal5-encap-type	Parameter type: <Atm::VccEncapType> (llc-snap llc-snap-routed llc-nlpid vc-mux-bridged-8023 vc-mux-routed vc-mux-pppoa none automatic : ip automatic : ppp automatic : pppoa automatic : ipoe-ppp) Possible values: - llc-snap : logical link control encapsulation bridged protocol - llc-snap-routed : logical link control encapsulation routed protocol - llc-nlpid : logical link control encapsulation pppoa protocol - vc-mux-bridged-8023 : virtual channel multiplex bridged protocol - vc-mux-routed : virtual channel multiplex routed protocol - vc-mux-pppoa : virtual channel multiplex pppoa protocol - automatic : automatic detection of encapsulation type - none : no encapsulation type Possible values: - ip : autodetection of the used ip encapsulation - ppp : autodetection of the used ppp encapsulation - pppoa : autodetection of the used pppoa encapsulation - ipoe-ppp : autodetection of the used ip or ppp encapsulation	displays the encapsulations method for carrying network interconnect traffic over AAL type 5 over ATM <i>This element is always shown.</i>

110.4 xDSL Port ATM Interface Configuration Status Command

Command Description

This command displays the xDSL port atm-interface configuration data.

User Level

The command can be accessed by operators with atm privileges.

Command Syntax

The command has the following syntax:

```
> show xdsl config-data-port (if-index) interface-atm-pvc [ (pvc-index) ]
```

Command Parameters

Table 110.4-1 "xDSL Port ATM Interface Configuration Status Command" Resource Parameters

Resource Identifier	Type	Description
(if-index)	Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number	interface index of the port
(pvc-index)	Format: (dsl : <Eqpt::VpiId> : <Eqpt::VciId> dsl) Possible values: - dsl : vdsl board Field type <Eqpt::VpiId> - atm VPI Field type <Eqpt::VciId> - atm VCI	the ATM PVC

Command Output

Table 110.4-2 "xDSL Port ATM Interface Configuration Status Command" Display parameters

Specific Information		
name	Type	Description
customer-id	Parameter type: <ltf::asamIfExtCustomerId> - a string identifying the customer or user - length: x<=64	the customerId per PVC <i>This element is always shown.</i>

110.5 xDSL Port Interface Configuration Status Command

Command Description

This command displays the xDSL port interface configuration data.

User Level

The command can be accessed by operators with xdsl privileges.

Command Syntax

The command has the following syntax:

```
> show xdsl config-data-port (if-index) interface-port
```

Command Parameters

Table 110.5-1 "xDSL Port Interface Configuration Status Command" Resource Parameters

Resource Identifier	Type	Description
(if-index)	Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number	interface index of the port

Command Output

Table 110.5-2 "xDSL Port Interface Configuration Status Command" Display parameters

Specific Information		
name	Type	Description
admin-state	Parameter type: <Xdsl::XdslAdminStatus> (not-applicable up down testing) Possible values: - not-applicable : not-applicable	the state of the interface <i>This element is always shown.</i>

name	Type	Description
	- up : admin status is up - down : admin status is down - testing : no operational packets can be passed	
link-updown-trap	Parameter type: <Itf::ifLinkUpDownTrapEnable> ((link-updown-trap enabled) (no-link-updown-trap disabled)) Possible values: - link-updown-trap : enable link-up/link-down traps - enabled : enable link-up/link-down traps - no-link-updown-trap : disable link-up/link-down traps - disabled : disable link-up/link-down traps	indicates whether link-up/link-down traps are generated <i>This element is always shown.</i>
user	Parameter type: <Itf::asamIfExtCustomerId> - a string identifying the customer or user - length: x<=64	description of the user connected to this interface <i>This element is always shown.</i>
severity	Parameter type: <Itf::asamIfExtAlmReportingSeverity> (indeterminate warning minor major critical no-alarms default no-value) Possible values: - indeterminate : not a definite known severity - warning : just to inform as a warning - minor : not service affecting - major : service affecting - critical : service breaking - no-alarms : do not report alarm - default : take default as specified via Interface Alarm Configuration command - no-value : no entry in the table	severity for alarm to be reported <i>This element is always shown.</i>

110.6 xDSL IGMP Configuration Status Command

Command Description

This command displays the xDSL IGMP configuration data.

User Level

The command can be accessed by operators with igmp privileges.

Command Syntax

The command has the following syntax:

```
> show xdsl config-data-port (if-index) igmp [ (port) ]
```

Command Parameters

Table 110.6-1 "xDSL IGMP Configuration Status Command" Resource Parameters

Resource Identifier	Type	Description
(if-index)	Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number	interface index of the port
(port)	Format: (dsl : <Eqpt::VpiId> : <Eqpt::VciId> dsl vlan : dsl : <Eqpt::VpiId> : <Eqpt::VciId> : <Eqpt::UnstackedVlan> vlan : dsl : <Eqpt::UnstackedVlan> vlan : dsl : <Eqpt::VpiId> : <Eqpt::VciId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan : dsl : stacked : <Eqpt::SVlan> : <Eqpt::CVlan>) Possible values: - vlan : vlan port Possible values: - dsl : vdsl board Field type <Eqpt::VpiId> - atm VPI Field type <Eqpt::VciId> - atm VCI Possible values:	identification of the port or virtual channel

Resource Identifier	Type	Description
	- stacked : stacked vlan identity Field type <Eqpt::UnstackedVlan> - unstacked vlan id Field type <Eqpt::SVlan> - service vlan id Field type <Eqpt::CVlan> - customer vlan id	

Command Output

Table 110.6-2 "xDSL IGMP Configuration Status Command" Display parameters

Specific Information		
name	Type	Description
perm-pkg-bitmap	Parameter type: <Igmp::PermPkgBitMap> - a binary string - length: 128	packages, the user is allowed to join <i>This element is only shown in detail mode.</i>
max-num-group	Parameter type: <Igmp::ChannelMaxNumGroup> - Max group number this port can support.The value depends on the board type and port type,please refer to the product information document for detail. - range: [0...2048]	max group number this port (ADSL, PVC) can support <i>This element is only shown in detail mode.</i>

110.7 xDSL Security PAE Configuration Status Command

Command Description

This command displays the xDSL security PAE configuration data.

User Level

The command can be accessed by operators with aaa privileges.

Command Syntax

The command has the following syntax:

```
> show xdsl config-data-port (if-index) security-pae [ (port) ]
```

Command Parameters

Table 110.7-1 "xDSL Security PAE Configuration Status Command" Resource Parameters

Resource Identifier	Type	Description
(if-index)	Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number	interface index of the port
(port)	Format: (dsl : <Eqpt::VpiId> : <Eqpt::VciId> dsl) Possible values: - dsl : vdsl board Field type <Eqpt::VpiId> - atm VPI Field type <Eqpt::VciId> - atm VCI	identification of the port or virtual channel

Command Output

Table 110.7-2 "xDSL Security PAE Configuration Status Command" Display parameters

Specific Information		
name	Type	Description
controlled-port	Parameter type: <Aaa::PaeControlledPortControl> (force-unauthorized auto force-authorized) Possible values: - force-unauthorized : force unauthorized control - auto : automatic control - force-authorized : force authorized control	current value of the controlled Port <i>This element is always shown.</i>
quiet-period	Parameter type: <Aaa::paeQuitTime> - quietPeriod - unit: sec - range: [0...65535]	quietPeriod constant currently used, value in seconds <i>This element is always shown.</i>
tx-period	Parameter type: <Aaa::paeTime> - authentication time - unit: sec - range: [1...65535]	txPeriod constant currently used, value in seconds <i>This element is always shown.</i>
supp-timeout	Parameter type: <Aaa::paeTime> - authentication time - unit: sec - range: [1...65535]	suppTimeout constant currently used, value in seconds <i>This element is always shown.</i>
server-timeout	Parameter type: <Aaa::paeTime> - authentication time - unit: sec - range: [1...65535]	serverTimeout constant currently used, value in seconds <i>This element is always shown.</i>
max-req	Parameter type: <Aaa::paeMaxReq> - max number of requests - range: [1...10]	maxReq constant currently used <i>This element is always shown.</i>
authentication	Parameter type: <Aaa::PortAuthState> (authentication no-authen) Possible values: - authentication : enable 802.1x authentication - no-authen : disable 802.1x authentication	enable 802.1x authentication <i>This element is always shown.</i>
init-authreq-off	Parameter type: <Aaa::PortAuthReq> (initiate-authreq init-authreq-off) Possible values: - initiate-authreq : enable initiate authentication request to supplicant - init-authreq-off : disable initiate authentication request to supplicant	specify initiate authentication request to supplicant <i>This element is always shown.</i>
handshake	Parameter type: <Aaa::PortHandShakeMode> (handshake no-handshake) Possible values: - handshake : enable handshake for this port - no-handshake : disable handshake for this port	enable handshake for this port <i>This element is always shown.</i>
handshake-period	Parameter type: <Aaa::PortHandShakePeriod> - handshake time interval - unit: sec - range: [5...90]	specify the handshake time interval <i>This element is always shown.</i>
initialize	Parameter type: <Aaa::InitCont> (initialize no-initialize) Possible values: - initialize : initialize this port	initialization control for this port <i>This element is always shown.</i>

110 Configuration Data Status Commands

name	Type	Description
	- no-initialize : don't initialize this port	

110.8 xDSL BridgePort Configuration Status Command

Command Description

This command displays the Bridge Port configured data.

User Level

The command can be accessed by operators with vlan privileges.

Command Syntax

The command has the following syntax:

```
> show xdsl config-data-port (if-index) bridge-port [ (port) ]
```

Command Parameters

Table 110.8-1 "xDSL BridgePort Configuration Status Command" Resource Parameters

Resource Identifier	Type	Description
(if-index)	Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number	interface index of the port
(port)	Format: (dsl : <Eqpt::VpiId> : <Eqpt::VciId> dsl) Possible values: - dsl : vdsl board Field type <Eqpt::VpiId> - atm VPI Field type <Eqpt::VciId> - atm VCI	identification of the port or virtual channel

Command Output

Table 110.8-2 "xDSL BridgePort Configuration Status Command" Display parameters

Specific Information		
name	Type	Description
pvid	Parameter type: <Vlan::StackedVlan> (<Vlan::UVlanIndex> stacked : <Vlan::SVlanIndex> : <Vlan::CVlanIndex>) Possible values: - stacked : stacked vlan identity Field type <Vlan::UVlanIndex> - unstacked vlan identity - range: [1...4093,4096] Field type <Vlan::SVlanIndex> - service vlan identity - range: [2...4093,4094] Field type <Vlan::CVlanIndex> - customer vlan identity - range: [0...4093,4094,4095,4096]	default vlan id for untagged frames <i>This element is only shown in detail mode.</i>
default-priority	Parameter type: <Vlan::Priority> - priority of ethernet frames - range: [0...7]	priority to be set in upstream frames <i>This element is only shown in detail mode.</i>
mac-learn-off	Parameter type: <Vlan::learnStatus> (mac-learning mac-learn-off) Possible values: - mac-learning : enable self learning of mac address - mac-learn-off : disable self learning of mac address	self learning of mac address <i>This element is only shown in detail mode.</i>
max-unicast-mac	Parameter type: <Vlan::MaxMac> - number of unicast mac addresses - range: [1...65535]	max unicast mac addresses <i>This element is only shown in detail mode.</i>
accept-frame-type	Parameter type: <Vlan::VlanFrameTypes> (single-tagged untagged mixed-tagged) Possible values: - single-tagged : admit only vlan tagged - untagged : admit only vlan untagged - mixed-tagged : admit vlan tagged and vlan untagged	accept frame types <i>This element is only shown in detail mode.</i>
prio-regen-prof	Parameter type: <Vlan::PrioRegenProfile> (none trusted-port best-effort cl-all-prio-3 cl-all-prio-4 background be-cl-voice be-cl-1d-voice be-voice l2-vpn-3 l2-vpn-4 11 12 13 14 15 16 17 18 19	priority regeneration profile <i>This element is only shown in detail mode.</i>

name	Type	Description
	20 21 22 23 24 25 26 27 28 29 30 31 32) Possible values: - none : default value - trusted-port : trusted port - best-effort : best effort - cl-all-prio-3 : controlled load, all priority 3 traffic - cl-all-prio-4 : controlled load, all priority 4 traffic - background : background - be-cl-voice : best effort, controlled load, voice - be-cl-1d-voice : best effort, controlled load, 802.Id Annex G voice - be-voice : best effort voice - l2-vpn-3 : L2 VPN with 3 traffic classes - l2-vpn-4 : L2 VPN with 4 traffic classes - 11 : operator-defined profile - 12 : operator-defined profile - 13 : operator-defined profile - 14 : operator-defined profile - 15 : operator-defined profile - 16 : operator-defined profile - 17 : operator-defined profile - 18 : operator-defined profile - 19 : operator-defined profile - 20 : operator-defined profile - 21 : operator-defined profile - 22 : operator-defined profile - 23 : operator-defined profile - 24 : operator-defined profile - 25 : operator-defined profile - 26 : operator-defined profile - 27 : operator-defined profile - 28 : operator-defined profile - 29 : operator-defined profile - 30 : operator-defined profile - 31 : operator-defined profile - 32 : operator-defined profile	
prio-regen-name	Parameter type: <Vlan::PrioRegenProfileName> (none name : <Vlan::IgnoredVlanProfileName>) Possible values: - none : no profile name to associate - name : enter profile name to be associated Data driven field type Possible values are depending on the actual configuration and software.	priority regeneration profile name <i>This element is only shown in detail mode.</i>

110 Configuration Data Status Commands

name	Type	Description
	The currently allowed values can be shown with online-help.	
qos-profile	Parameter type: <Vlan::QosProfileName> (none name : <Vlan::IgnoredQosProfileName>) Possible values: - none : no profile name to associate - name : enter profile name to be associated Field type <Vlan::IgnoredQosProfileName> - name of the QoS profile - length: 1<=x<=64	qos profile name <i>This element is always shown.</i>

110.9 xDSL QoS Configuration Status Command

Command Description

This command displays the xDSL QoS configuration data.

User Level

The command can be accessed by operators with qos privileges.

Command Syntax

The command has the following syntax:

```
> show xdsl config-data-port (if-index) qos
```

Command Parameters

Table 110.9-1 "xDSL QoS Configuration Status Command" Resource Parameters

Resource Identifier	Type	Description
(if-index)	Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number	interface index of the port

Command Output

Table 110.9-2 "xDSL QoS Configuration Status Command" Display parameters

Specific Information		
name	Type	Description
scheduler-profile	Parameter type: <Qos::QoS Scheduler Profile Name> (none name : <Qos::IgnoredQoS Profile Name>) Possible values: - none : no profile name to associate - name : enter profile name to be associated Data driven field type Possible values are depending on the actual configuration and software. The currently allowed values can be shown with online-help.	the name of the scheduler profile to be mapped on this dsl link <i>This element is only shown in detail mode.</i>

110 Configuration Data Status Commands

name	Type	Description
cac-profile	Parameter type: <Qos::QosCacProfileName> (name : <Qos::IgnoredQosProfileName> none) Possible values: - none : no profile name to associated - name : enter profile name to be associated Data driven field type Possible values are depending on the actual configuration and software. The currently allowed values can be shown with online-help.	the name of the cac profile to be mapped on this dsl link2 <i>This element is only shown in detail mode.</i>

110.10 xDSL PPPoX Relay Configuration Status Command

Command Description

This command displays the xDSL PPPoX relay client port configuration data.

User Level

The command can be accessed by operators with pppoe privileges.

Command Syntax

The command has the following syntax:

```
> show xdsl config-data-port (if-index) pppox-relay [ (port) ]
```

Command Parameters

Table 110.10-1 "xDSL PPPoX Relay Configuration Status Command" Resource Parameters

Resource Identifier	Type	Description
(if-index)	Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number	interface index of the port
(port)	Format: (dsl : <Eqpt::VpiId> : <Eqpt::VciId> dsl vlan : dsl : <Eqpt::VpiId> : <Eqpt::VciId> : <Eqpt::UnstackedVlan> vlan : dsl : <Eqpt::UnstackedVlan> vlan : dsl : <Eqpt::VpiId> : <Eqpt::VciId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan : dsl : stacked : <Eqpt::SVlan> : <Eqpt::CVlan>) Possible values: - vlan : vlan port Possible values: - dsl : vdsl board Field type <Eqpt::VpiId> - atm VPI	client port identification

Resource Identifier	Type	Description
	Field type <Eqpt::Vcild> - atm VCI Possible values: - stacked : stacked vlan identity Field type <Eqpt::UnstackedVlan> - unstacked vlan id Field type <Eqpt::SVlan> - service vlan id Field type <Eqpt::CVlan> - customer vlan id	

Command Output

Table 110.10-2 "xDSL PPPoX Relay Configuration Status Command" Display parameters

Specific Information		
name	Type	Description
vlan-id	Parameter type: <Vlan::StackedVlanSigned> (<Vlan::UVlanIndex> stacked : <Vlan::SVlanIndex> : <Vlan::CVlanIndex>) Possible values: - stacked : stacked vlan identity Field type <Vlan::UVlanIndex> - unstacked vlan identity - range: [1...4093,4096] Field type <Vlan::SVlanIndex> - service vlan identity - range: [2...4093,4094] Field type <Vlan::CVlanIndex> - customer vlan identity - range: [0...4093,4094,4095,4096]	client port associated to cc-engine <i>This element is only shown in detail mode.</i>
default-priority	Parameter type: <PPPoX::DefaultPriority> - indicates the p-bit for the client port - range: [0...7]	indicates the p-bit for the client port <i>This element is only shown in detail mode.</i>
max-cc	Parameter type: <PPPoX::MaxNumPppCc> - max no. of PPP cross connection on a port - range: [1...64], [9...64] = 8 with MAC concentration.	max no. of PPP cross connection on a port <i>This element is only shown in detail mode.</i>
qos-profile	Parameter type: <PPPoX::QosProfileName> (none name : <PPPoX::IgnoredQosProfileName>) Possible values: - none : no profile name to associate - name : enter profile name to be associated Field type <PPPoX::IgnoredQosProfileName> - name of the QoS profile - length: 1<=x<=32	qos profile name associated with client port <i>This element is only shown in detail mode.</i>

110.11 xDSL Bonding Group Configuration Status Command

Command Description

This command displays the xDSL bonding group configuration data.

User Level

The command can be accessed by operators with xdsl privileges.

Command Syntax

The command has the following syntax:

```
> show xdsl config-data-port (if-index) bonding-group
```

Command Parameters

Table 110.11-1 "xDSL Bonding Group Configuration Status Command" Resource Parameters

Resource Identifier	Type	Description
(if-index)	Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number	interface index of the port

Command Output

Table 110.11-2 "xDSL Bonding Group Configuration Status Command" Display parameters

Specific Information		
name	Type	Description
group-profile	Parameter type: <Xdsl::IgnoredPrintableString> - ignored printable string	name of the bonding group profile <i>This element is always shown.</i>
group-rtx-profile	Parameter type: <Xdsl::IgnoredPrintableString> - ignored printable string	name of the bonding group rtx profile <i>This element is always shown.</i>
admin-state	Parameter type: <Xdsl::XdslAdminStatusGroup>	the admin-state of the primary

110 Configuration Data Status Commands

name	Type	Description
	(up down) Possible values: - up : admin-state of the group to up - down : admin-state of the group to down	link of the bonding group <i>This element is always shown.</i>

111- Operational Data Status Commands

111.1 Operational Data Status Command Tree	111-5606
111.2 xDSL Port Operational Status Command	111-5607
111.3 xDSL BridgePort Operational Status Command	111-5611
111.4 xDSL Port ATM Operational Status Command	111-5613
111.5 xDSL Port Interface Configuration Status Command	111-5615
111.6 xDSL IGMP Operational Status Command	111-5617
111.7 xDSL Port Ip Bridge Operational Status Command	111-5620
111.8 xDSL QoS Opertaional Status Command	111-5622

111.1 Operational Data Status Command Tree

Description

This chapter gives an overview of nodes that are handled by "Operational Data Status Commands".

Command Tree

```
----show
  ----xdsl
    ----oper-data-port
      - (if-index)
        ----xdsl
          ----bridge-port
            - (port)
              ----atm-pvc
                - (port-index)
              ----interface-port
            ----igmp
              - (port)
            ----ip-bridge-port
              - (ip-bridge-port)
          ----qos
```


111.2 xDSL Port Operational Status Command

Command Description

This command displays the xDSL Port Operational data.

User Level

The command can be accessed by operators with xdsl privileges.

Command Syntax

The command has the following syntax:

```
> show xdsl oper-data-port (if-index) xdsl
```

Command Parameters

Table 111.2-1 "xDSL Port Operational Status Command" Resource Parameters

Resource Identifier	Type	Description
(if-index)	Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number	interface index of the port

Command Output

Table 111.2-2 "xDSL Port Operational Status Command" Display parameters

Specific Information		
name	Type	Description
admin-state	Parameter type: <If::ifAdminStatus> (not-appl up down testing) Possible values: - not-appl : not-applicable - up : admin status is up - down : admin status is down - testing : no operational packets can be passed	specifies state of the interface <i>This element is only shown in detail mode.</i>

111 Operational Data Status Commands

name	Type	Description
opr-state/tx-rate-ds	Parameter type: <Xdsl::combinedCol> (down testing unknown dormant up : <Xdsl::bitrate>) Possible values: - up : up,traffic can pass - down : down,no traffic is passing - testing : testing,no traffic is passing - unknown : unknown - dormant : dormant,no traffic is passing Field type <Xdsl::bitrate> - bitrate - unit: kbits/sec	current operational state of the interface. <i>This element is only shown in detail mode.</i>
cur-op-mode	Parameter type: <Xdsl::OneOpModeTypeLinePreDef> (ansi-t1413 etsi-dts g992-1-a g992-1-b g992-2-a g992-3-a g992-3-b g992-3-aj g992-3-l1 g992-3-l2 g992-3-am g992-5-a g992-5-b ansi-t1.424 etsi-ts itu-g993-1 ieee-802.3ah g992-5-aj g992-5-am g993-2-8a g993-2-8b g993-2-8c g993-2-8d g993-2-12a g993-2-12b g993-2-17a g993-2-30a g993-2-35b gfast default) Possible values: - ansi-t1413 : ANSI T1.413-1998 - etsi-dts : ETSI DTS/TM06006 - g992-1-a : G.992.1 POTS non-overlapped spectrum - g992-1-b : G.992.1 ISDN non-overlapped spectrum - g992-2-a : G.992.2 POTS non-overlapped spectrum - g992-3-a : G.992.2 POTS non-overlapped spectrum - g992-3-b : G.992.3 ISDN non-overlapped spectrum - g992-3-aj : G.992.3 All Digital Mode with non-overlapped spectrum - g992-3-l1 : G.992.3 POTS non-overlapped spectrum US	operational mode allowed by this profile <i>This element is only shown in detail mode.</i>

name	Type	Description
	mask 1 - g992-3-l2 : G.992.3 POTS non-overlapped spectrum US mask 2 - g992-3-am : G.992.3 extended POTS with non-overlapped spectrum - g992-5-a : G.992.5 POTS non-overlapped spectrum - g992-5-b : G.992.5 POTS non-overlapped spectrum - ansi-t1.424 : ANSI T1.424 - etsi-ts : ETSI TS - itu-g993-1 : ITU G993-1 - ieee-802.3ah : IEEE 802.3ah - g992-5-aj : G.992.5 All Digital Mode with non-overlapped spectrum - g992-5-am : G.992.5 extended POTS non-overlapped spectrum - g993-2-8a : VDSL-2 with profile 8A - g993-2-8b : VDSL-2 with profile 8B - g993-2-8c : VDSL-2 with profile 8C - g993-2-8d : VDSL-2 with profile 8D - g993-2-12a : VDSL-2 with profile 12A - g993-2-12b : VDSL-2 with profile 12B - g993-2-17a : VDSL-2 with profile 17A - g993-2-30a : VDSL-2 with profile 30A - g993-2-35b : VDSL-2 with profile 35B - gfast : gfast profile - default : default value	
tx-rate-us	Parameter type: <Xdsl::SignedIntegerKBPS> - bitrate - unit: kbits/sec	bitrate or expected throughput for upstream fast or interleaved data flow <i>This element is only shown in detail mode.</i>
tx-rate-ds	Parameter type: <Xdsl::SignedIntegerKBPS> - bitrate - unit: kbits/sec	bitrate or expected throughput for downstream fast or interleaved data flow <i>This element is only shown in detail mode.</i>
noise-margin-down	Parameter type: <Xdsl::NoiseValue> - a noise value - unit: 1/10 dB	current noise margin for the downstream direction. For G.Fast, value -512 is reported when no data is available. <i>This element is only shown in detail mode.</i>
noise-margin-up	Parameter type: <Xdsl::NoiseValue> - a noise value - unit: 1/10 dB	current noise margin for the upstream direction. For G.Fast, value -512 is reported when no data is available. <i>This element is only shown in detail mode.</i>
actual-tps-tc-mode	Parameter type: <Xdsl::ActualTpsTcMode> (no-value atm ptm system-default) Possible values: - no-value : no value - atm : atm mode - ptm : ptm mode	actual transfer mode <i>This element is only shown in detail mode.</i>

111 Operational Data Status Commands

name	Type	Description
	- system-default : determined by the system, based on board type	
override-state	Parameter type: <Xdsl::OverrideState> (not-created created-no-overrules created-overrules) Possible values: - not-created : not created - created-no-overrules : created no overrules - created-overrules : created overrules	indicates whether an override record is configured and not all 'no-overrules'. Only applicable for ADSLx/VDSLx <i>This element is only shown in detail mode.</i>
rtx-mode-up	Parameter type: <Xdsl::ActualRtxModeType> (in-use forbidden no-xtuc no-xtur no-xtuc-xtur supported unknown) Possible values: - in-use : retransmission in use - forbidden : retransmission not_in_use forbidden - no-xtuc : retransmission not_in_use and not_supported for xtuc - no-xtur : retransmission not_in_use and not_supported for xtur - no-xtuc-xtur : retransmission not_in_use and not_supported for xtuc and xtur - supported : retransmission not selected but supported - unknown : retransmission not supported	actual retransmission mode in upstream direction. "in-use" is reported in case of G.Fast. <i>This element is only shown in detail mode.</i>
rtx-mode-dn	Parameter type: <Xdsl::ActualRtxModeType> (in-use forbidden no-xtuc no-xtur no-xtuc-xtur supported unknown) Possible values: - in-use : retransmission in use - forbidden : retransmission not_in_use forbidden - no-xtuc : retransmission not_in_use and not_supported for xtuc - no-xtur : retransmission not_in_use and not_supported for xtur - no-xtuc-xtur : retransmission not_in_use and not_supported for xtuc and xtur - supported : retransmission not selected but supported - unknown : retransmission not supported	actual retransmission mode in downstream direction. "in-use" is reported in case of G.Fast. <i>This element is only shown in detail mode.</i>

111.3 xDSL BridgePort Operational Status Command

Command Description

This command displays the Bridge Port Operational data.

User Level

The command can be accessed by operators with atm privileges.

Command Syntax

The command has the following syntax:

```
> show xdsl oper-data-port (if-index) bridge-port [ (port) ]
```

Command Parameters

Table 111.3-1 "xDSL BridgePort Operational Status Command" Resource Parameters

Resource Identifier	Type	Description
(if-index)	Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number	interface index of the port
(port)	Format: (dsl : <Eqpt::VpiId> : <Eqpt::VciId> dsl) Possible values: - dsl : vdsl board Field type <Eqpt::VpiId> - atm VPI Field type <Eqpt::VciId> - atm VCI	identity of the PVC

Command Output

Table 111.3-2 "xDSL BridgePort Operational Status Command" Display parameters

111 Operational Data Status Commands

Specific Information		
name	Type	Description
pvid	Parameter type: <Vlan::StackedVlan> (<Vlan::UVlanIndex> stacked : <Vlan::SVlanIndex> : <Vlan::CVlanIndex>) Possible values: - stacked : stacked vlan identity Field type <Vlan::UVlanIndex> - unstacked vlan identity - range: [1...4093,4096] Field type <Vlan::SVlanIndex> - service vlan identity - range: [2...4093,4094] Field type <Vlan::CVlanIndex> - customer vlan identity - range: [0...4093,4094,4095,4096]	default vlan id for untagged frames <i>This element is only shown in detail mode.</i>
default-priority	Parameter type: <Vlan::Priority> - priority of ethernet frames - range: [0...7]	port dynamic or static (if no dynamic) default priority <i>This element is only shown in detail mode.</i>
qos-profile	Parameter type: <Vlan::QosProfileName> (none name : <Vlan::IgnoredQosProfileName>) Possible values: - none : no profile name to associate - name : enter profile name to be associated Field type <Vlan::IgnoredQosProfileName> - name of the QoS profile - length: 1<=x<=64	qos profile name <i>This element is always shown.</i>

111.4 xDSL Port ATM Operational Status Command

Command Description

This command displays the xDSL port atm operational data.

User Level

The command can be accessed by operators with atm privileges.

Command Syntax

The command has the following syntax:

```
> show xdsl oper-data-port (if-index) atm-pvc [ (port-index) ]
```

Command Parameters

Table 111.4-1 "xDSL Port ATM Operational Status Command" Resource Parameters

Resource Identifier	Type	Description
(if-index)	Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number	interface index of the port
(port-index)	Format: (dsl : <Eqpt::VpiMandatoryId> : <Eqpt::VciMandatoryId> dsl) Possible values: - dsl : ADSL/SHDSL board Field type <Eqpt::VpiMandatoryId> - atm VPI Field type <Eqpt::VciMandatoryId> - atm VCI	the ATM PVC

Command Output

Table 111.4-2 "xDSL Port ATM Operational Status Command" Display parameters

Specific Information		
name	Type	Description
admin-state	Parameter type: <Xdsl::XdslAdminStatusAtm>	specifies the desired

111 Operational Data Status Commands

name	Type	Description
	(up down) Possible values: - up : enable traffic flow - down : disable traffic flow	administrative state of the VCL. <i>This element is only shown in detail mode.</i>
oper-state	Parameter type: <Atm::atmVclOperStatus> (up down unknown) Possible values: - up : traffic flow is enabled in the virtual link - down : traffic flow is disabled in the virtual link - unknown : state is unknown	indicates the current operational status of the VCL. <i>This element is only shown in detail mode.</i>
curr-encap-type	Parameter type: <Atm::CurVccEncapType> (llc-snap llc-snap-routed llc-nlpid vc-mux-bridged-8023 vc-mux-routed vc-mux-pppoa other unknown none) Possible values: - llc-snap : logical link control encapsulation bridged protocol - llc-snap-routed : logical link control encapsulation routed protocol - llc-nlpid : logical link control encapsulation pppoa protocol - vc-mux-bridged-8023 : virtual channel multiplex bridged protocol - vc-mux-routed : virtual channel multiplex routed protocol - vc-mux-pppoa : virtual channel multiplex pppoa protocol - other : other encapsulation type - unknown : unknown encapsulation type - none : no encapsulation type	the current established encapsulation type. <i>This element is only shown in detail mode.</i>

111.5 xDSL Port Interface Configuration Status Command

Command Description

This command displays the xDSL port interface configuration data.

User Level

The command can be accessed by operators with xdsl privileges.

Command Syntax

The command has the following syntax:

```
> show xdsl oper-data-port (if-index) interface-port
```

Command Parameters

Table 111.5-1 "xDSL Port Interface Configuration Status Command" Resource Parameters

Resource Identifier	Type	Description
(if-index)	Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number	interface index of the port

Command Output

Table 111.5-2 "xDSL Port Interface Configuration Status Command" Display parameters

Specific Information		
name	Type	Description
admin-state	Parameter type: <Xdsl::XdslAdminStatus> (not-applicable up down testing) Possible values: - not-applicable : not-applicable	the desired state of the interface <i>This element is always shown.</i>

111 Operational Data Status Commands

name	Type	Description
	- up : admin status is up - down : admin status is down - testing : no operational packets can be passed	
oper-state	Parameter type: <If::ifOperStatus> (up down testing unknown dormant no-value) Possible values: - up : up,traffic can pass - down : down,no traffic is passing - testing : testing,no traffic is passing - unknown : unknown - dormant : dormant,no traffic is passing - no-value : no entry in the table	the operational state of the interface <i>This element is only shown in detail mode.</i>

111.6 xDSL IGMP Operational Status Command

Command Description

This command displays the xDSL IGMP operational data.

User Level

The command can be accessed by operators with igmp privileges.

Command Syntax

The command has the following syntax:

```
> show xdsl oper-data-port (if-index) igmp [ (port) ]
```

Command Parameters

Table 111.6-1 "xDSL IGMP Operational Status Command" Resource Parameters

Resource Identifier	Type	Description
(if-index)	Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number	interface index of the port
(port)	Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::VpiId> : <Eqpt::VciId> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::Vpild> : <Eqpt::VciId> : <Eqpt::UnstackedVlan> vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::UnstackedVlan> vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::Vpild> : <Eqpt::VciId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> / <Eqpt::OntPortId> : stacked : <Eqpt::SVlan> :	identification of the port or virtual channel

Resource Identifier	Type	Description
	<code><Eqpt::CVlan></code> <code> vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> /</code> <code><Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> /</code> <code><Eqpt::OntPortId> : <Eqpt::UnstackedVlan></code> <code> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> /</code> <code><Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> /</code> <code><Eqpt::OntPortId></code> <code> vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> /</code> <code><Eqpt::PonId> / <Eqpt::OntId> / voip : stacked :</code> <code><Eqpt::SVlan> : <Eqpt::CVlan></code> <code> vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> /</code> <code><Eqpt::PonId> / <Eqpt::OntId> / vuni : stacked :</code> <code><Eqpt::SVlan> : <Eqpt::CVlan></code> <code> vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> /</code> <code><Eqpt::PonId> / <Eqpt::OntId> / voip :</code> <code><Eqpt::UnstackedVlan></code> <code> vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> /</code> <code><Eqpt::PonId> / <Eqpt::OntId> / vuni :</code> <code><Eqpt::UnstackedVlan></code> <code> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> /</code> <code><Eqpt::PonId> / <Eqpt::OntId> / voip</code> <code> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> /</code> <code><Eqpt::PonId> / <Eqpt::OntId> / vuni</code> <code> vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> /</code> <code><Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::LLId> : stacked :</code> <code><Eqpt::SVlan> : <Eqpt::CVlan></code> <code> vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> /</code> <code><Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::LLId> :</code> <code><Eqpt::UnstackedVlan></code> <code> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> /</code> <code><Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::LLId></code> <code> vlan.ng2 : <Eqpt::ChannelGroupId> /</code> <code><Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> /</code> <code><Eqpt::Ng2OntSlotId> / <Eqpt::Ng2OntPortId> : stacked :</code> <code><Eqpt::SVlan> : <Eqpt::CVlan></code> <code> vlan.ng2 : <Eqpt::ChannelGroupId> /</code> <code><Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> /</code> <code><Eqpt::Ng2OntSlotId> / <Eqpt::Ng2OntPortId> :</code> <code><Eqpt::UnstackedVlan>)</code> Possible values: - vlan : vlan port - vlan.ng2 : ngpon2 vlan port Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number Field type <Eqpt::VpiId> - atm VPI Field type <Eqpt::VciId> - atm VCI Field type <Eqpt::PonId> - the PON identifier Field type <Eqpt::ChannelGroupId>	

Resource Identifier	Type	Description
	- the channel group identifier Field type <Eqpt::SubChannelGroupId> - the subchannel group identifier Field type <Eqpt::Ng2OntId> - the NG2 ONT identifier Field type <Eqpt::OntId> - the ONT identifier Possible values: - voip : virtual uni identifier obsolete alternative replaced by vuni - vuni : virtual uni identifier Possible values: - vuni : virtual NGPON2 uni identifier - the ONT SLOT identifier Field type <Eqpt::OntSlotId> - the ONT PORT identifier Field type <Eqpt::Ng2OntSlotId> - the NGPON2 ONT SLOT identifier Field type <Eqpt::Ng2OntPortId> - the NGPON2 ONT PORT identifier Field type <Eqpt::LLId> - the LLID identifier, range 1 for EPON, range 1-8 for DPOE Possible values: - stacked : stacked vlan identity Field type <Eqpt::UnstackedVlan> - unstacked vlan id Field type <Eqpt::SVlan> - service vlan id Field type <Eqpt::CVlan> - customer vlan id	

Command Output

Table 111.6-2 "xDSL IGMP Operational Status Command" Display parameters

Specific Information		
name	Type	Description
curr-num-group	Parameter type: <Gauge> - gauge	Indicates the current group number in this port <i>This element is only shown in detail mode.</i>
curr-preview-num	Parameter type: <Counter> - 32 bit counter	Indicates the number of preview multicast group that igmp channel joins currently <i>This element is only shown in detail mode.</i>
curr-uncfg-num	Parameter type: <Counter> - 32 bit counter	Indicates the current unconfig group number in this port <i>This element is only shown in detail mode.</i>

111.7 xDSL Port Ip Bridge Operational Status Command

Command Description

This command displays the xDSL Port Ip Bridge Operational data.

User Level

The command can be accessed by operators with ip privileges.

Command Syntax

The command has the following syntax:

```
> show xdsl oper-data-port (if-index) ip-bridge-port [ (ip-bridge-port) ]
```

Command Parameters

Table 111.7-1 "xDSL Port Ip Bridge Operational Status Command" Resource Parameters

Resource Identifier	Type	Description
(if-index)	Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number	interface index of the port
(ip-bridge-port)	Format: (dsl : <Eqpt::VpiId> : <Eqpt::VciId> dsl) Possible values: - dsl : vdsl board Field type <Eqpt::VpiId> - atm VPI Field type <Eqpt::VciId> - atm VCI	identification of the port or virtual channel

Command Output

Table 111.7-2 "xDSL Port Ip Bridge Operational Status Command" Display parameters

Specific Information		
name	Type	Description
rx-pkts	Parameter type: <Equipm::Octet-8> - a binary string - length: 8	show the number of received packets <i>This element is always shown.</i>
rx-drop-pkts	Parameter type: <Equipm::Octet-8> - a binary string - length: 8	show the number of received packets which are dropped <i>This element is always shown.</i>
tx-pkts	Parameter type: <Equipm::Octet-8> - a binary string - length: 8	show the number of transmitted packets <i>This element is always shown.</i>

111.8 xDSL QoS Operational Status Command

Command Description

This command displays the xDSL QoS operational data.

User Level

The command can be accessed by operators with qos privileges.

Command Syntax

The command has the following syntax:

```
> show xdsl oper-data-port (if-index) qos
```

Command Parameters

Table 111.8-1 "xDSL QoS Operational Status Command" Resource Parameters

Resource Identifier	Type	Description
(if-index)	Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number	interface index of the port

Command Output

Table 111.8-2 "xDSL QoS Operational Status Command" Display parameters

Specific Information		
name	Type	Description
frame-net-bw	Parameter type: <SignedInteger> - a signed integer	Represents the approximate bandwidth available for Ethernet frames, which is guaranteed to be available by the physical layer. This approximation is made by the configurable ATM overhead factor. <i>This element is only shown in detail mode.</i>
m-cast-avail-bw	Parameter type: <SignedInteger>	Represents the bandwidth

name	Type	Description
	- a signed integer	available for multicast services, calculated by the ISAM. This value is what is left from frame-net-bw after deducting from it res-data-bw and res-voice-bw. The minimum of m-cast-avail-bw and m-cast-max-bw will be the actual limitation for user multicast bandwidth usage per DSL link. <i>This element is only shown in detail mode.</i>
m-cast-used-bw	Parameter type: <SignedInteger> - a signed integer	Shows the bandwidth currently in use by pre-configured multicast streams. <i>This element is only shown in detail mode.</i>

112- Gpon xDSL Status Commands

112.1 Gpon xDSL Status Command Tree	112-5625
112.2 Gpon xDSL Profiles Status Command	112-5627
112.3 Gpon xDSL PM Interval Per Interface Status Command	112-5628
112.4 Gpon xDSL Operational Data Near End Line Status Command	112-5630
112.5 Gpon xDSL Operational Data Near End Channel Status Command	112-5635
112.6 Gpon xDSL Operational Data Far End Line Status Command	112-5637
112.7 Gpon xDSL Operational Data Far End Channel Status Command	112-5641
112.8 Gpon xDSL Carrier Data Near End Status Command	112-5643
112.9 Gpon xDSL Carrier Data Far End Status Command	112-5648
112.10 Gpon xDSL Failure Status Near End Status Command	112-5651
112.11 Gpon xDSL Failure Status Far End Status Command	112-5654
112.12 Gpon xDSL Counters Near End Line Current 15 Min	112-5657
112.13 Gpon xDSL Counters Near End Line Previous 15 Min	112-5659
112.14 Gpon xDSL Counters Near End Channel Current 15 Min	112-5661
112.15 Gpon xDSL Counters Near End Channel Previous 15 Min	112-5663
112.16 Gpon xDSL Counters Far End Line Current 15 Min	112-5665
112.17 Gpon xDSL Counters Far End Line Previous 15 Min	112-5667
112.18 Gpon xDSL Counters Far End Channel Current 15 Min	112-5669
112.19 Gpon xDSL Counters Far End Channel Previous 15 Min	112-5671
112.20 Gpon xDSL XTU-R Inventory Status Command	112-5673
112.21 Gpon xDSL XTU-C Inventory Status Command	112-5675

112.1 Gpon xDSL Status Command Tree

Description

This chapter gives an overview of nodes that are handled by "Gpon xDSL Status Commands".

Command Tree

```

----show
  ----xdsl
    ----ont
      ----profiles
      ----xdsl-int
        - (if-index)
      ----operational-data
        ----near-end
          ----line
            - (if-index)
          ----channel
            - (if-index)
        ----far-end
          ----line
            - (if-index)
          ----channel
            - (if-index)
      ----carrier-data
        ----near-end
          - (if-index)
        ----far-end
          - (if-index)
      ----failure-status
        ----near-end
          - (if-index)
        ----far-end
          - (if-index)
      ----counters
        ----near-end
          ----line
            ----current-interval
              - (if-index)
            ----previous-interval
              - (if-index)
              - interval-no
          ----channel
            ----current-interval
              - (if-index)
            ----previous-interval
              - (if-index)
              - interval-no
        ----far-end
          ----line
            ----current-interval
              - (if-index)
            ----previous-interval

```

- (if-index)
- interval-no
- channel
- current-interval
 - (if-index)
- previous-interval
 - (if-index)
 - interval-no
- cpe-tur-inventory
 - (if-index)
- cpe-tuc-inventory
 - (if-index)

112.2 Gpon xDSL Profiles Status Command

Command Description

This command displays Gpon xDSL profiles.

User Level

The command can be accessed by operators with xdsl privileges.

Command Syntax

The command has the following syntax:

```
> show xdsl ont profiles
```

Command Output

Table 112.2-2 "Gpon xDSL Profiles Status Command" Display parameters

Specific Information		
name	Type	Description
next-av-serv-pr	Parameter type: <AsamNextProfileIndex> - a profile index - range: [0...65535]	next available service profile index <i>This element is always shown.</i>
max-serv-pr	Parameter type: <AsamMaxProfileIndex> - a maximum value of a profile index - range: [0...65535]	max number of service profiles that can be created <i>This element is always shown.</i>
next-av-spec-pr	Parameter type: <AsamNextProfileIndex> - a profile index - range: [0...65535]	next available spectrum profile index <i>This element is always shown.</i>
max-spec-pr	Parameter type: <AsamMaxProfileIndex> - a maximum value of a profile index - range: [0...65535]	max number of spectrum profiles that can be created <i>This element is always shown.</i>
next-av-dpbo-pr	Parameter type: <AsamNextProfileIndex> - a profile index - range: [0...65535]	next available dpbo profile index <i>This element is always shown.</i>
max-dpbo-pr	Parameter type: <AsamMaxProfileIndex> - a maximum value of a profile index - range: [0...65535]	max number of dpbo profiles that can be created <i>This element is always shown.</i>
next-av-rtx-pr	Parameter type: <AsamNextProfileIndex> - a profile index - range: [0...65535]	next available Rtx profile index <i>This element is always shown.</i>
max-rtx-pr	Parameter type: <AsamMaxProfileIndex> - a maximum value of a profile index - range: [0...65535]	max number of rtx profiles that can be created <i>This element is always shown.</i>

112.3 Gpon xDSL PM Interval Per Interface Status Command

Command Description

This command displays the number of available pm intervals per xdsl interface.

User Level

The command can be accessed by operators with xdsl privileges.

Command Syntax

The command has the following syntax:

```
> show xdsl ont xdsl-int [ (if-index) ]
```

Command Parameters

Table 112.3-1 "Gpon xDSL PM Interval Per Interface Status Command" Resource Parameters

Resource Identifier	Type	Description
(if-index)	Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Gpon::OntSlotId> / <Gpon::OntPortId> ng2 : <Ng2::ChannelGroup> / <Ng2::SubchannelGroup> / <Ng2::OntId> / <Gpon::OntSlotId> / <Gpon::OntPortId>) Possible values: - ng2 : ngpon2 style identification Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Ng2::ChannelGroup> - channel group number Field type <Ng2::SubchannelGroup> - subchannel group number Field type <Eqpt::OntId> - the ONT identifier Field type <Ng2::OntId> - the ONT identifier Field type <Gpon::OntSlotId> - Gpon Ont Slot	interface index of the port

Resource Identifier	Type	Description
	- range: [1...14] Field type <Gpon::OntPortId> - Gpon Ont Port - range: [1...16]	

Command Output

Table 112.3-2 "Gpon xDSL PM Interval Per Interface Status Command" Display parameters

Specific Information		
name	Type	Description
valid-intervals	Parameter type: <SignedInteger> - a signed integer	nbr of prev intvl for which valid data has been stored <i>This element is always shown.</i>

112.4 Gpon xDSL Operational Data Near End Line Status Command

Command Description

This command displays the xDSL operational data for the near and of line.

User Level

The command can be accessed by operators with xdsl privileges.

Command Syntax

The command has the following syntax:

```
> show xdsl ont operational-data near-end line [ (if-index) ]
```

Command Parameters

Table 112.4-1 "Gpon xDSL Operational Data Near End Line Status Command" Resource Parameters

Resource Identifier	Type	Description
(if-index)	Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Gpon::OntSlotId> / <Gpon::OntPortId> ng2 : <Ng2::ChannelGroup> / <Ng2::SubchannelGroup> / <Ng2::OntId> / <Gpon::OntSlotId> / <Gpon::OntPortId>) Possible values: - ng2 : ngpon2 style identification Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Ng2::ChannelGroup> - channel group number Field type <Ng2::SubchannelGroup> - subchannel group number Field type <Eqpt::OntId> - the ONT identifier Field type <Ng2::OntId> - the ONT identifier Field type <Gpon::OntSlotId>	interface index of the port

Resource Identifier	Type	Description
	- Gpon Ont Slot - range: [1...14] Field type <Gpon::OntPortId> - Gpon Ont Port - range: [1...16]	

Command Output

Table 112.4-2 "Gpon xDSL Operational Data Near End Line Status Command" Display parameters

Specific Information		
name	Type	Description
rel-cap-occ-up	Parameter type: <Xdsl::CapacityUtil> - utilization of the capacity available - unit: % - range: [0...100]	ratio of actual bitrate over the max attainable bitrate <i>This element is always shown.</i>
noise-margin-up	Parameter type: <Xdsl::NoiseValue> - a noise value - unit: 1/10 dB	current noise margin for the upstream direction <i>This element is always shown.</i>
output-power-down short name: output-pwr-dn	Parameter type: <Xdsl::OutputPwr> - a power value - unit: 1/10 dBm	actual aggregate output power for the downstream carriers <i>This element is always shown.</i>
sig-attenuation-up short name: sig-attn-up	Parameter type: <Xdsl::SigAttenuation> - an attenuation value - unit: 1/10 dB	diff btw pwr at near-end rx-ver and that tx-ed from far-end <i>This element is only shown in detail mode.</i>
loop-attenuation-up short name: loop-attn-up	Parameter type: <Xdsl::SigAttenuation> - an attenuation value - unit: 1/10 dB	diff btw pwr at near-end rx-ver and tx-ed from far-end over all sub-carriers <i>This element is only shown in detail mode.</i>
actual-opmode	Parameter type: <Xdsl::OneOpModeTypeLinePreDef> (ansi-t1413 etsi-dts g992-1-a g992-1-b g992-2-a g992-3-a g992-3-b g992-3-aj g992-3-l1 g992-3-l2 g992-3-am g992-5-a g992-5-b ansi-t1.424 etsi-ts itu-g993-1 ieee-802.3ah g992-5-aj g992-5-am g993-2-8a g993-2-8b g993-2-8c g993-2-8d g993-2-12a g993-2-12b	actual value of the operational mode <i>This element is only shown in detail mode.</i>

112 Gpon xDSL Status Commands

name	Type	Description
	g993-2-17a g993-2-30a g993-2-35b gfast default) Possible values: - ansi-t1413 : ANSI T1.413-1998 - etsi-dts : ETSI DTS/TM06006 - g992-1-a : G.992.1 POTS non-overlapped spectrum - g992-1-b : G.992.1 ISDN non-overlapped spectrum - g992-2-a : G.992.2 POTS non-overlapped spectrum - g992-3-a : G.992.2 POTS non-overlapped spectrum - g992-3-b : G.992.3 ISDN non-overlapped spectrum - g992-3-aj : G.992.3 All Digital Mode with non-overlapped spectrum - g992-3-l1 : G.992.3 POTS non-overlapped spectrum US mask 1 - g992-3-l2 : G.992.3 POTS non-overlapped spectrum US mask 2 - g992-3-am : G.992.3 extended POTS with non-overlapped spectrum - g992-5-a : G.992.5 POTS non-overlapped spectrum - g992-5-b : G.992.5 POTS non-overlapped spectrum - ansi-t1.424 : ANSI T1.424 - etsi-ts : ETSI TS - itu-g993-1 : ITU G993-1 - ieee-802.3ah : IEEE 802.3ah - g992-5-aj : G.992.5 All Digital Mode with non-overlapped spectrum - g992-5-am : G.992.5 extended POTS non-overlapped spectrum - g993-2-8a : VDSL-2 with profile 8A - g993-2-8b : VDSL-2 with profile 8B - g993-2-8c : VDSL-2 with profile 8C - g993-2-8d : VDSL-2 with profile 8D - g993-2-12a : VDSL-2 with profile 12A - g993-2-12b : VDSL-2 with profile 12B - g993-2-17a : VDSL-2 with profile 17A - g993-2-30a : VDSL-2 with profile 30A - g993-2-35b : VDSL-2 with profile 35B - gfast : gfast profile - default : default value	
xtu-c-opmode	Parameter type: <Xdsl::GOpModeTypeLinePreDef> (ansi-t1413 etsi-dts g992-1-a g992-1-b g992-2-a g992-3-a g992-3-b g992-3-aj g992-3-l1 g992-3-l2 g992-3-am g992-5-a g992-5-b ansi-t1.424	a bitmap which represents the operational modes enabled at the XTU-C <i>This element is only shown in detail mode.</i>

name	Type	Description
	etsi-ts itu-g993-1 ieee-802.3ah g992-5-aj g992-5-am g993-2-8a g993-2-8b g993-2-8c g993-2-8d g993-2-12a g993-2-12b g993-2-17a g993-2-30a default <Xdsl::GOpModeType>) Possible values: - ansi-t1413 : ANSI T1.413-1998 - etsi-dts : ETSI DTS/TM06006 - g992-1-a : G.992.1 POTS non-overlapped spectrum - g992-1-b : G.992.1 ISDN non-overlapped spectrum - g992-2-a : G.992.2 POTS non-overlapped spectrum - g992-3-a : G.992.2 POTS non-overlapped spectrum - g992-3-b : G.992.3 ISDN non-overlapped spectrum - g992-3-aj : G.992.3 All Digital Mode with non-overlapped spectrum - g992-3-l1 : G.992.3 POTS non-overlapped spectrum US mask 1 - g992-3-l2 : G.992.3 POTS non-overlapped spectrum US mask 2 - g992-3-am : G.992.3 extended POTS with non-overlapped spectrum - g992-5-a : G.992.5 POTS non-overlapped spectrum - g992-5-b : G.992.5 POTS non-overlapped spectrum - ansi-t1.424 : ANSI T1.424 - etsi-ts : ETSI TS - itu-g993-1 : ITU G993-1 - ieee-802.3ah : IEEE 802.3ah - g992-5-aj : G.992.5 All Digital Mode with non-overlapped spectrum - g992-5-am : G.992.5 extended POTS non-overlapped spectrum - g993-2-8a : VDSL-2 with profile 8A - g993-2-8b : VDSL-2 with profile 8B - g993-2-8c : VDSL-2 with profile 8C - g993-2-8d : VDSL-2 with profile 8D - g993-2-12a : VDSL-2 with profile 12A - g993-2-12b : VDSL-2 with profile 12B - g993-2-17a : VDSL-2 with profile 17A - g993-2-30a : VDSL-2 with profile 30A - default : default value Field type <Xdsl::GOpModeType> - octet string bitmask defining operational mode - length: 16	
last-tx-state-down	Parameter type: <Xdsl::LastTxStateType> - a signed integer	last successful transmitted initialisation state downstream <i>This element is only shown in detail mode.</i>

112 Gpon xDSL Status Commands

name	Type	Description
actual-psd-down short name: act-psd-dn	Parameter type: <Xdsl::SignedIntegerDBHZ> - a power spectral density value - unit: 1/10 dBm/Hz	avg transmit power spectrum density over used carriers <i>This element is always shown.</i>
power-mgnt-state short name: pwr-mgnt	Parameter type: <Xdsl::PowerMgtState> (10 12 13) Possible values: - 10 : full transmission - 12 : downstream net data rate is reduced - 13 : no transmission	actual power management state of the line <i>This element is always shown.</i>
per-bnd-lp-att-up	Parameter type: <Xdsl::PerBandOperDataType> - printable string - length: 10	loop attenuation for each upstream band in case of VDSL2 <i>This element is only shown in detail mode.</i>
pr-bnd-sgn-att-up	Parameter type: <Xdsl::PerBandOperDataType> - printable string - length: 10	signal attenuation for each upstream band in case of VDSL2 <i>This element is only shown in detail mode.</i>
pr-bnd-nois-mg-up	Parameter type: <Xdsl::PerBandOperDataType> - printable string - length: 10	noise margin for each upstream band in case of VDSL2 <i>This element is only shown in detail mode.</i>
high-freq-up	Parameter type: <Xdsl::GHighFreqType> - a frequency - unit: kHz	highest carrier frequency used in the upstream direction in case of VDSL2 and G.Fast <i>This element is always shown.</i>
elect-length	Parameter type: <Xdsl::ElectrLengthType> - Electrical length. When ELE-M1 is used, value 255 specifies that this parameter is not supported. - unit: 1/2 * dB @ 1MHz - range: [0...255]	Line Electrical Length actually used by XTU-C when mode is VDSL2 <i>This element is only shown in detail mode.</i>
actual-tps-tc-mode	Parameter type: <Xdsl::ActualTpsTcMode> (no-value atm ptm system-default) Possible values: - no-value : no value - atm : atm mode - ptm : ptm mode - system-default : determined by the system, based on board type	actual transfer mode <i>This element is only shown in detail mode.</i>
actual-v-noise-snr-up	Parameter type: <Xdsl::SnrmModeUp> (mode-1 mode-2 mode-3) Possible values: - mode-1 : virtual noise disabled - mode-2 : Tx referred virtual noise enabled - mode-3 : Rx referred virtual noise enabled	upstream operational mode of virtual noise SNR margin <i>This element is only shown in detail mode.</i>

112.5 Gpon xDSL Operational Data Near End Channel Status Command

Command Description

This command displays the xDSL operational data for the near and of line.

User Level

The command can be accessed by operators with xdsl privileges.

Command Syntax

The command has the following syntax:

```
> show xdsl ont operational-data near-end channel [ (if-index) ]
```

Command Parameters

Table 112.5-1 "Gpon xDSL Operational Data Near End Channel Status Command" Resource Parameters

Resource Identifier	Type	Description
(if-index)	Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Gpon::OntSlotId> / <Gpon::OntPortId> ng2 : <Ng2::ChannelGroup> / <Ng2::SubchannelGroup> / <Ng2::OntId> / <Gpon::OntSlotId> / <Gpon::OntPortId>) Possible values: - ng2 : ngpon2 style identification Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Ng2::ChannelGroup> - channel group number Field type <Ng2::SubchannelGroup> - subchannel group number Field type <Eqpt::OntId> - the ONT identifier Field type <Ng2::OntId> - the ONT identifier Field type <Gpon::OntSlotId>	interface index of the port

Resource Identifier	Type	Description
	- Gpon Ont Slot - range: [1...14] - Field type <Gpon::OntPortId> - Gpon Ont Port - range: [1...16]	

Command Output

Table 112.5-2 "Gpon xDSL Operational Data Near End Channel Status Command" Display parameters

Specific Information		
name	Type	Description
actual-bitrate-up	Parameter type: <Xdsl::SignedIntegerKBPS> - bitrate - unit: kbits/sec	atm bitrate for upstream fast or interleaved data flow <i>This element is always shown.</i>
attain-bitrate-up	Parameter type: <Xdsl::SignedIntegerKBPS> - bitrate - unit: kbits/sec	maximum attainable atm rate the modem can support <i>This element is always shown.</i>
interleave-delay-down	Parameter type: <Xdsl::SignedIntegerMSEC> - milli-second - unit: msec	delay caused by the interleaving and deinterleaving functionality <i>This element is always shown.</i>
imp-noise-prot-down	Parameter type: <Xdsl::SignedIntegerSYMBOL> - impulse noise protection - unit: 1/10 symbols	actual impulse noise protection <i>This element is always shown.</i>

112.6 Gpon xDSL Operational Data Far End Line Status Command

Command Description

This command displays the xDSL operational data for the line far end.

User Level

The command can be accessed by operators with xdsl privileges.

Command Syntax

The command has the following syntax:

```
> show xdsl ont operational-data far-end line [ (if-index) ]
```

Command Parameters

Table 112.6-1 "Gpon xDSL Operational Data Far End Line Status Command" Resource Parameters

Resource Identifier	Type	Description
(if-index)	Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Gpon::OntSlotId> / <Gpon::OntPortId> ng2 : <Ng2::ChannelGroup> / <Ng2::SubchannelGroup> / <Ng2::OntId> / <Gpon::OntSlotId> / <Gpon::OntPortId>) Possible values: - ng2 : ngpon2 style identification Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Ng2::ChannelGroup> - channel group number Field type <Ng2::SubchannelGroup> - subchannel group number Field type <Eqpt::OntId> - the ONT identifier Field type <Ng2::OntId> - the ONT identifier Field type <Gpon::OntSlotId>	interface index of the port

Resource Identifier	Type	Description
	- Gpon Ont Slot - range: [1...14] Field type <Gpon::OntPortId> - Gpon Ont Port - range: [1...16]	

Command Output

Table 112.6-2 "Gpon xDSL Operational Data Far End Line Status Command" Display parameters

Specific Information		
name	Type	Description
rel-cap-occ-down	Parameter type: <Xdsl::CapacityUtil> - utilization of the capacity available - unit: % - range: [0...100]	ratio of actual bitrate over the max attainable bitrate <i>This element is always shown.</i>
noise-margin-down	Parameter type: <Xdsl::NoiseValue> - a noise value - unit: 1/10 dB	current noise margin for the downstream direction <i>This element is always shown.</i>
output-power-up	Parameter type: <Xdsl::OutputPwr> - a power value - unit: 1/10 dBm	actual aggregate output power for the upstream carriers <i>This element is always shown.</i>
sig-attenuation-down short name: sig-attn-dn	Parameter type: <Xdsl::SigAttenuation> - an attenuation value - unit: 1/10 dB	diff btw pwr at far-end rx-ver and tx-ed from near-end <i>This element is only shown in detail mode.</i>
loop-attenuation-down short name: loop-attn-dn	Parameter type: <Xdsl::SigAttenuation> - an attenuation value - unit: 1/10 dB	diff btw pwr at far-end rx-ver and tx-ed from near-end over all sub-carriers <i>This element is only shown in detail mode.</i>
xtu-r-opmode	Parameter type: <Xdsl::GOpModeTypeLinePreDef> (ansi-t1413 etsi-dts g992-1-a g992-1-b g992-2-a g992-3-a g992-3-b g992-3-aj g992-3-l1 g992-3-l2 g992-3-am g992-5-a g992-5-b ansi-t1.424 etsi-ts itu-g993-1 ieee-802.3ah g992-5-aj g992-5-am g993-2-8a g993-2-8b g993-2-8c g993-2-8d g993-2-12a g993-2-12b)	a bitmap which represents the operational modes supported at the XTU-R <i>This element is only shown in detail mode.</i>

name	Type	Description
	g993-2-17a g993-2-30a default <Xdsl::GOpModeType>) Possible values: - ansi-t1413 : ANSI T1.413-1998 - etsi-dts : ETSI DTS/TM06006 - g992-1-a : G.992.1 POTS non-overlapped spectrum - g992-1-b : G.992.1 ISDN non-overlapped spectrum - g992-2-a : G.992.2 POTS non-overlapped spectrum - g992-3-a : G.992.2 POTS non-overlapped spectrum - g992-3-b : G.992.3 ISDN non-overlapped spectrum - g992-3-aj : G.992.3 All Digital Mode with non-overlapped spectrum - g992-3-l1 : G.992.3 POTS non-overlapped spectrum US mask 1 - g992-3-l2 : G.992.3 POTS non-overlapped spectrum US mask 2 - g992-3-am : G.992.3 extended POTS with non-overlapped spectrum - g992-5-a : G.992.5 POTS non-overlapped spectrum - g992-5-b : G.992.5 POTS non-overlapped spectrum - ansi-t1.424 : ANSI T1.424 - etsi-ts : ETSI TS - itu-g993-1 : ITU G993-1 - ieee-802.3ah : IEEE 802.3ah - g992-5-aj : G.992.5 All Digital Mode with non-overlapped spectrum - g992-5-am : G.992.5 extended POTS non-overlapped spectrum - g993-2-8a : VDSL-2 with profile 8A - g993-2-8b : VDSL-2 with profile 8B - g993-2-8c : VDSL-2 with profile 8C - g993-2-8d : VDSL-2 with profile 8D - g993-2-12a : VDSL-2 with profile 12A - g993-2-12b : VDSL-2 with profile 12B - g993-2-17a : VDSL-2 with profile 17A - g993-2-30a : VDSL-2 with profile 30A - default : default value Field type <Xdsl::GOpModeType> - octet string bitmask defining operational mode - length: 16	
last-tx-state-up	Parameter type: <Xdsl::LastTxStateType> - a signed integer	last successful transmitted initialisation state upstream <i>This element is only shown in detail mode.</i>
actual-psd-up	Parameter type: <Xdsl::SignedIntegerDBHZ> - a power spectral density value - unit: 1/10 dBm/Hz	avg transmit power spectrum density over used carriers <i>This element is always shown.</i>
pr-bnd-lp-att-dn	Parameter type: <Xdsl::PerBandOperDataType> - printable string - length: 10	loop attenuation for each downstream band in case of VDSL2 <i>This element is only shown in detail mode.</i>
pr-bnd-sig-att-dn	Parameter type: <Xdsl::PerBandOperDataType> - printable string - length: 10	loop attenuation for each downstream band in case of VDSL2

112 Gpon xDSL Status Commands

name	Type	Description
		<i>This element is only shown in detail mode.</i>
pr-bnd-nmgn-dn	Parameter type: <Xdsl::PerBandOperDataType> - printable string - length: 10	loop attenuation for each downstream band in case of VDSL2 <i>This element is only shown in detail mode.</i>
high-freq-down	Parameter type: <Xdsl::GHighFreqType> - a frequency - unit: kHz	highest carrier frequency used in the downstream direction in case of VDSL2 and G.Fast <i>This element is always shown.</i>
elect-len-estimated	Parameter type: <Xdsl::ElectrLengthType> - Electrical length. When ELE-M1 is used, value 255 specifies that this parameter is not supported. - unit: 1/2 * dB @ 1MHz - range: [0...255]	the Line Electrical Length actually estimated by XTU-R when mode is VDSL2 <i>This element is only shown in detail mode.</i>
actual-v-noise-snr-dn	Parameter type: <Xdsl::SnrmMode> (mode-1 mode-2 mode-3) Possible values: - mode-1 : virtual noise disabled - mode-2 : Tx referred virtual noise enabled - mode-3 : Rx referred virtual noise enabled(not supported)	downstream operational mode of virtual noise SNR margin <i>This element is only shown in detail mode.</i>

112.7 Gpon xDSL Operational Data Far End Channel Status Command

Command Description

This command displays the xDSL operational data for the far end of the channel.

User Level

The command can be accessed by operators with xdsl privileges.

Command Syntax

The command has the following syntax:

```
> show xdsl ont operational-data far-end channel [ (if-index) ]
```

Command Parameters

Table 112.7-1 "Gpon xDSL Operational Data Far End Channel Status Command" Resource Parameters

Resource Identifier	Type	Description
(if-index)	Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Gpon::OntSlotId> / <Gpon::OntPortId> ng2 : <Ng2::ChannelGroup> / <Ng2::SubchannelGroup> / <Ng2::OntId> / <Gpon::OntSlotId> / <Gpon::OntPortId>) Possible values: - ng2 : ngpon2 style identification Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Ng2::ChannelGroup> - channel group number Field type <Ng2::SubchannelGroup> - subchannel group number Field type <Eqpt::OntId> - the ONT identifier Field type <Ng2::OntId> - the ONT identifier Field type <Gpon::OntSlotId>	interface index of the port

Resource Identifier	Type	Description
	- Gpon Ont Slot - range: [1...14] - Field type <Gpon::OntPortId> - Gpon Ont Port - range: [1...16]	

Command Output

Table 112.7-2 "Gpon xDSL Operational Data Far End Channel Status Command" Display parameters

Specific Information		
name	Type	Description
actual-bitrate-down short name: act-br-down	Parameter type: <Xdsl::SignedIntegerKBPS> - bitrate - unit: kbits/sec	atm bitrate for downstream fast or interleaved data flow <i>This element is always shown.</i>
attain-bitrate-down short name: att-br-down	Parameter type: <Xdsl::SignedIntegerKBPS> - bitrate - unit: kbits/sec	maximum attainable atm rate the modem can support <i>This element is always shown.</i>
interleave-delay-up	Parameter type: <Xdsl::SignedIntegerMSEC> - milli-second - unit: msec	delay caused by the interleaving and deinterleaving functionality <i>This element is always shown.</i>
imp-noise-prot-up	Parameter type: <Xdsl::SignedIntegerSYMBOL> - impulse noise protection - unit: 1/10 symbols	actual impulse noise protection <i>This element is always shown.</i>

112.8 Gpon xDSL Carrier Data Near End Status Command

Command Description

This command displays xDSL carrier data near end.

Carrier data is displayed in raw format so the actual data interpretation is described in this section.

The XDSL passband (downstream or upstream) is composed of one or more bands (max 5, including VDSL optional band). Each carrier is coded as a bitmap. When the data are not available because the measurement is not completed, not enabled or not supported, an empty string will be returned. Below is the definition of the carrier specific bitmap.

Carrier load (Load-distribution-down) : When the modem is not in showtime this object will have the previously measured value. Each carrier can carry up to 15 bits. The carrier load is coded as a bitmap defined as follows:

- OCTETS 0,1: INTEGER (0..4096), index of the start carrier group of the first downstream band. The value is defined as MSB-LSB (big-endian).
- OCTETS 2,3: INTEGER (0..4096), index of the stop carrier group of the first downstream band. The value is defined as MSB-LSB (big-endian).
- OCTET 4: contains the bit load of the first two carrier groups of the band. The load of the first carrier group uses the most significant 4 bits nibble. Range is 0-15 bits per carrier group, with a granularity of 1 bit/carrier group.
- OCTETS 5..L: and so on, up to the last carrier group of the first downstream band. The last nibble of OCTET L is set to 0x0 if not used.
- OCTETS L+1..M: contain the start/stop carrier groups and the carrier load of the second downstream band when available.
- OCTETS M+1..N: contain the start/stop carrier groups and the carrier load of the third downstream band when available.
- OCTETS N+1..P: contain the start/stop carrier groups and the carrier load of the fourth downstream band when available.
- OCTETS P+1..Q: contain the start/stop carrier groups and the carrier load of the fifth downstream band when available.

Carrier gain (gain-allocation-down) : When the modem is not in showtime this object will have the previously measured value. The gain has a range of approximately 0 - 8, in steps of 1/512. The gain value is represented as $gi/512$ on a linear scale with gi a 12 bits unsigned integer in the 0 to 4095 range given by the 12 LSB bits of a 2 bytes integer. The carrier gain allocation is coded as a bitmap defined as follows:

- OCTETS 0,1: INTEGER (0..4096), index of the start carrier group of the first downstream band. The value is defined as MSB-LSB (big-endian).
- OCTETS 2,3: INTEGER (0..4096), index of the stop carrier group of the first downstream band. The value is defined as MSB-LSB (big-endian).
- OCTETS 4,5: INTEGER, contains the gain of the first carrier group of the band (start carrier group).
- OCTETS 6..L: and so on until the last carrier group of the first downstream band (stop carrier group).
- OCTETS L+1..M: contain the start/stop carrier groups and the carrier gain of the second downstream band when available.
- OCTETS M+1..N: contain the start/stop carrier groups and the carrier gain of the third downstream band when available.
- OCTETS N+1..P: contain the start/stop carrier groups and the carrier gain of the fourth downstream band when available.
- OCTETS P+1..Q: contain the start/stop carrier groups and the carrier gain of the fifth downstream band when available.

Carrier snr (snr-up): When the modem is not in showtime this object will have the previously measured value. The SNR has a range from -32 to 95 dB in steps of 0.5 dB. It is represented as $SNR_i = -32 + snr_i/2$, with snr_i an 8 bit unsigned integer in the range 0 to 254. The special value 255 indicates that no measurement is available for the carrier or that the measurement is out of range. The carrier snrs are coded as a bitmap defined as follows:

- OCTETS 0,1: INTEGER, contains the number of symbols used to measure the data. The value is defined as MSB-LSB (big-endian).
- OCTETS 2,3: INTEGER (0..4096), index of the start carrier group of the first upstream band. The value is defined as MSB-LSB (big-endian).
- OCTETS 4,5: INTEGER (0..4096), index of the stop carrier group of the first upstream band. The value is defined as MSB-LSB (big-endian).
- OCTETS 6: INTEGER, contains the snr of the first carrier group of the band (start carrier group).
- OCTETS 7..L: and so on until the last carrier group of the first upstream band (stop carrier group).
- OCTETS L+1..M: contain the start/stop carrier groups and the carrier snr of the second upstream band when available.
- OCTETS M+1..N: contain the start/stop carrier groups and the carrier snr of the third upstream band when available.
- OCTETS N+1..P: contain the start/stop carrier groups and the carrier snr of the fourth upstream band when available.
- OCTETS P+1..Q: contain the start/stop carrier groups and the carrier snr of the fifth upstream band when available.

Carrier qln (qln-up): The QLN has a range from -150 dBm/Hz to -23 dBm/Hz in steps of 0.5 dB. It is represented as $QLN_i = -23 - qln_i/2$, with qln_i an 8 bit unsigned integer in the range 0 to 254. The special value 255 indicates that no measurement is available for the carrier or that the measurement is out of range. The carrier qlns are coded as a bitmap defined as follows:

- OCTETS 0,1: INTEGER, contains the number of symbols used to measure the data. The value is defined as MSB-LSB (big-endian).
- OCTETS 2,3: INTEGER (0..4096), index of the start carrier group of the first upstream band. The value is defined as MSB-LSB (big-endian).
- OCTETS 4,5: INTEGER (0..4096), index of the stop carrier group of the first upstream band. The value is defined as MSB-LSB (big-endian).
- OCTETS 6: INTEGER, contains the qln of the first carrier group of the band (start carrier group).
- OCTETS 7..L: and so on until the last carrier group of the first upstream band (stop carrier group).
- OCTETS L+1..M: contain the start/stop carrier groups and the carrier qln of the second downstream band when available.
- OCTETS M+1..N: contain the start/stop carrier groups and the carrier qln of the third upstream band when available.
- OCTETS N+1..P: contain the start/stop carrier groups and the carrier qln of the fourth upstream band when available.
- OCTETS P+1..Q: contain the start/stop carrier groups and the carrier qln of the fifth upstream band when available.

Carrier HLIN (char-func-complex): HLIN has a range of approximately +6 dB to -90 dB, with a granularity of 2^{-15} . The Hlin is represented as $HLIN_i = (scale/2^{15}) * ((ai + j*bi)/2^{15})$, with ai and bi 2 bytes signed integers in the range -32767 to 32767. The special value -32768 indicates that no measurement is available for the carrier or that the measurement is out of range. The scale factor is a 2 bytes unsigned integer. The scale factor must be chosen such that: $\max(|Ai|, |Bi|)$ over all i is equal to $2^{15}-1$, i.e. over all carriers of the XDSL band(s) of the corresponding direction. The carrier HLINs are coded as a bitmap defined as follows:

- OCTETS 0,1: INTEGER, contains the number of symbols used to measure the data. The value is defined as MSB-LSB (big-endian).
- OCTETS 2,3: INTEGER(0..65535), contains the scale factor to apply to the hlin values, over the upstream band(s). The value is defined as MSB-LSB (big-endian).
- OCTETS 4,5: INTEGER (0..4096), index of the start carrier group of the first upstream band. The value is defined as MSB-LSB (big-endian).
- OCTETS 6,7: INTEGER (0..4096), index of the stop carrier group of the first upstream band. The value is defined as MSB-LSB (big-endian).
- OCTETS 8,9: SIGNED INTEGER , contains the ai for the first carrier group of the band (start carrier group). The value is defined as MSB-LSB (big-endian).
- OCTETS 10,11: SIGNED INTEGER , contains the bi for the first carrier group of the band (start carrier

- group). The value is defined as MSB-LSB (big-endian).
- OCTETS 12..L: *ai* and *bi* for the next carrier group and so on until the last carrier group of the first upstream band (stop carrier group).
 - OCTETS L+1..M: contain the start/stop carrier groups and the HLIN *ai* and *bi* of the second upstream band when available.
 - OCTETS M+1..N: contain the start/stop carrier groups and the HLIN *ai* and *bi* of the third upstream band when available.
 - OCTETS N+1..P: contain the start/stop carrier groups and the HLIN *ai* and *bi* of the fourth upstream band when available.
 - OCTETS P+1..Q: contain the start/stop carrier groups and the HLIN *ai* and *bi* of the fifth upstream band when available.

Carrier HLOG (char-func-real): Hlog has a range of approximately +6 dB to -96 dB in steps of 0.1 dB. The Hlog is represented as $HLOG_i = 6 - mi/10$, with *mi* a 10 bits unsigned integer in the range 0 to 1022. The special value 1023 indicates that no measurement is available for the carrier or that the measurement is out of range. The carrier HLOGs are coded as a bitmap defined as follows:

- OCTETS 0,1: INTEGER, contains the number of symbols used to measure the data. The value is defined as MSB-LSB (big-endian).
- OCTETS 2,3: INTEGER (0..4096), index of the start carrier group of the first upstream band. The value is defined as MSB-LSB (big-endian).
- OCTETS 4,5: INTEGER (0..4096), index of the stop carrier group of the first upstream band. The value is defined as MSB-LSB (big-endian).
- OCTETS 6,7: INTEGER (0..1023), contains the HLOG *mi* of the first carrier group of the band (start carrier group). The value is defined as MSB-LSB (big-endian).
- OCTETS 8..L: *mi* for the next carrier group and so on until the last carrier group of the first upstream band (stop carrier group).
- OCTETS L+1..M: contain the start/stop carrier groups and the HLOG *mi* of the second upstream band when available.
- OCTETS M+1..N: contain the start/stop carrier groups and the HLOG *mi* of the third upstream band when available.
- OCTETS N+1..P: contain the start/stop carrier groups and the HLOG *mi* of the fourth upstream band when available.
- OCTETS P+1..Q: contain the start/stop carrier groups and the HLOG *mi* of the fifth upstream band when available.

Carrier Tx PSD (tx-psd-dn): When the modem is not in showtime this object will have the previously measured value. The PSD has a range from -127 dBm/Hz to 0 dBm/Hz in steps of 0.5 dB. It is represented as $PSD_i = -psdi/2$, with *psdi* an 8 bit unsigned integer in the range 0 to 254. The special value 255 indicates that no measurement is available for the carrier, the carrier is not loaded, or that the measurement is out of range. The carrier Tx PSD is coded as a bitmap defined as follows:

- OCTETS 0,1: INTEGER (0..4096), index of the start carrier group of the downstream band. The value is defined as MSB-LSB (big-endian).
- OCTETS 2,3: INTEGER (0..4096), index of the stop carrier group of the downstream band. The value is defined as MSB-LSB (big-endian).
- OCTET 4: INTEGER(0..255), PSD of the first carrier group of the band (start carrier group).
- OCTETS 5..L: and so on until the last carrier group of the first downstream band (stop carrier group).
- OCTETS L+1..M: contain the start/stop carrier groups and the carrier PSD of the second downstream band when available.
- OCTETS M+1..N: contain the start/stop carrier groups and the carrier PSD of the third downstream band when available.
- OCTETS N+1..P: contain the start/stop carrier groups and the carrier PSD of the fourth downstream band when available.
- OCTETS P+1..Q: contain the start/stop carrier groups and the carrier PSD of the fifth downstream band when available.

User Level

The command can be accessed by operators with xdsl privileges.

Command Syntax

The command has the following syntax:

```
> show xdsl ont carrier-data near-end [ (if-index) ]
```

Command Parameters

Table 112.8-1 "Gpon xDSL Carrier Data Near End Status Command" Resource Parameters

Resource Identifier	Type	Description
(if-index)	Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Gpon::OntSlotId> / <Gpon::OntPortId> ng2 : <Ng2::ChannelGroup> / <Ng2::SubchannelGroup> / <Ng2::OntId> / <Gpon::OntSlotId> / <Gpon::OntPortId>) Possible values: - ng2 : ngpon2 style identification Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Ng2::ChannelGroup> - channel group number Field type <Ng2::SubchannelGroup> - subchannel group number Field type <Eqpt::OntId> - the ONT identifier Field type <Ng2::OntId> - the ONT identifier Field type <Gpon::OntSlotId> - Gpon Ont Slot - range: [1...14] Field type <Gpon::OntPortId> - Gpon Ont Port - range: [1...16]	interface index of the port

Command Output

Table 112.8-2 "Gpon xDSL Carrier Data Near End Status Command" Display parameters

Specific Information		
name	Type	Description
spacing	Parameter type: <Xdsl::CarrierSpacingType> (single double half quarter	the actual carrier spacing used on the XDSL line in the downstream direction <i>This element is always shown.</i>

name	Type	Description
	gfast) Possible values: - single : single - double : double - half : half - quarter : quarter - gfast : gfast	
load-distribution-down	Parameter type: <Xdsl::OctetStingType> - a binary string	nbr of bits per carrier group over the downstream passband <i>This element is always shown.</i>
gain-allocation-down	Parameter type: <Xdsl::OctetStingType> - a binary string	gain allocation (i.e. gi) per carrier group over the downstream passband <i>This element is always shown.</i>
snr-up	Parameter type: <Xdsl::OctetStingType> - a binary string	signal to noise ratio per carrier group over the upstream passband <i>This element is always shown.</i>
qln-up	Parameter type: <Xdsl::OctetStingType> - a binary string	quiet line noise per carrier group over the upstream passband <i>This element is always shown.</i>
char-func-complex	Parameter type: <Xdsl::OctetStingType> - a binary string	provides the channel characteristics function complex values in linear scale for each carrier group over upstream passband (hlin) <i>This element is always shown.</i>
char-func-real	Parameter type: <Xdsl::OctetStingType> - a binary string	char func real values in dB over upstream passband (hlog) <i>This element is always shown.</i>
load-carr-grp	Parameter type: <Gpon::GSubCarrierGroupSizeType> - grouping factor per carrier data octet-string - range: [0...2,4,8,16]	Provides the grouping factor for carrier load data octet-string <i>This element is always shown.</i>
gain-carr-grp	Parameter type: <Gpon::GSubCarrierGroupSizeType> - grouping factor per carrier data octet-string - range: [0...2,4,8,16]	Provides the grouping factor for carrier gain allocation data octet-string <i>This element is always shown.</i>
snr-carr-grp	Parameter type: <Gpon::GSubCarrierGroupSizeType> - grouping factor per carrier data octet-string - range: [0...2,4,8,16]	Provides the grouping factor for Signal to Noise Ratio per carrier data octet-string <i>This element is always shown.</i>
qln-carr-grp	Parameter type: <Gpon::GSubCarrierGroupSizeType> - grouping factor per carrier data octet-string - range: [0...2,4,8,16]	Provides the grouping factor for Quiet Line Noise data octet-string <i>This element is always shown.</i>
hlin-carr-grp	Parameter type: <Gpon::GSubCarrierGroupSizeType> - grouping factor per carrier data octet-string - range: [0...2,4,8,16]	Provides the grouping factor for Complex Channel Characteristics data in linear scale <i>This element is always shown.</i>
hlog-carr-grp	Parameter type: <Gpon::GSubCarrierGroupSizeType> - grouping factor per carrier data octet-string - range: [0...2,4,8,16]	Provides the grouping factor for Channel Characteristics data in dB <i>This element is always shown.</i>

112.9 Gpon xDSL Carrier Data Far End Status Command

Command Description

This command displays xDSL carrier data far end.

Each carrier is coded as a bitmap. For more details related to : the bitmap definition and the description of ranges, specific values,.. of the carriers, we refer to the command description section of the "xDSL Carrier Data Near End Status Command" section. When reading this in scope of "Far End", "downstream" becomes "upstream" and vice versa.

User Level

The command can be accessed by operators with xdsl privileges.

Command Syntax

The command has the following syntax:

```
> show xdsl ont carrier-data far-end [ (if-index) ]
```

Command Parameters

Table 112.9-1 "Gpon xDSL Carrier Data Far End Status Command" Resource Parameters

Resource Identifier	Type	Description
(if-index)	Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Gpon::OntSlotId> / <Gpon::OntPortId> ng2 : <Ng2::ChannelGroup> / <Ng2::SubchannelGroup> / <Ng2::OntId> / <Gpon::OntSlotId> / <Gpon::OntPortId>) Possible values: - ng2 : ngpon2 style identification Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Ng2::ChannelGroup> - channel group number Field type <Ng2::SubchannelGroup> - subchannel group number Field type <Eqpt::OntId>	interface index of the port

Resource Identifier	Type	Description
	- the ONT identifier Field type <Ng2::OntId> - the ONT identifier Field type <Gpon::OntSlotId> - Gpon Ont Slot - range: [1...14] Field type <Gpon::OntPortId> - Gpon Ont Port - range: [1...16]	

Command Output

Table 112.9-2 "Gpon xDSL Carrier Data Far End Status Command" Display parameters

Specific Information		
name	Type	Description
spacing	Parameter type: <Xdsl::CarrierSpacingType> (single double half quarter gfast) Possible values: - single : single - double : double - half : half - quarter : quarter - gfast : gfast	the actual carrier spacing used on the XDSL line in the upstream direction <i>This element is always shown.</i>
load-distribution-up	Parameter type: <Xdsl::OctetStingType> - a binary string	nbr of bits per carrier group over the upstream passband <i>This element is always shown.</i>
gain-allocation-up	Parameter type: <Xdsl::OctetStingType> - a binary string	gain allocation (i.e.gi) per carrier group over the upstream passband <i>This element is always shown.</i>
snr-down	Parameter type: <Xdsl::OctetStingType> - a binary string	signal to noise ratio per carrier group over the downstream passband <i>This element is always shown.</i>
qln-down	Parameter type: <Xdsl::OctetStingType> - a binary string	quiet line noise per carrier group over the downstream passband <i>This element is always shown.</i>
char-func-complex	Parameter type: <Xdsl::OctetStingType> - a binary string	provides the channel characteristics function complex values in linear scale per carrier group over downstream passband (hlin) <i>This element is always shown.</i>
char-func-real	Parameter type: <Xdsl::OctetStingType> - a binary string	char func real values in dB over downstream passband (hlog) <i>This element is always shown.</i>
load-carr-grp	Parameter type: <Gpon::GSubCarrierGroupSizeType> - grouping factor per carrier data octet-string - range: [0...2,4,8,16]	Provides the grouping factor for carrier load data octet-string <i>This element is always shown.</i>
gain-carr-grp	Parameter type: <Gpon::GSubCarrierGroupSizeType> - grouping factor per carrier data octet-string - range: [0...2,4,8,16]	Provides the grouping factor for carrier gain allocation data octet-string

112 Gpon xDSL Status Commands

name	Type	Description
		<i>This element is always shown.</i>
snr-carr-grp	Parameter type: <Gpon::GSubCarrierGroupSizeType> - grouping factor per carrier data octet-string - range: [0...2,4,8,16]	Provides the grouping factor for Signal to Noise Ratio per carrier data octet-string <i>This element is always shown.</i>
qln-carr-grp	Parameter type: <Gpon::GSubCarrierGroupSizeType> - grouping factor per carrier data octet-string - range: [0...2,4,8,16]	Provides the grouping factor for Quiet Line Noise data octet-string <i>This element is always shown.</i>
hlin-carr-grp	Parameter type: <Gpon::GSubCarrierGroupSizeType> - grouping factor per carrier data octet-string - range: [0...2,4,8,16]	Provides the grouping factor for Complex Channel Characteristics data in linear scale <i>This element is always shown.</i>
hlog-carr-grp	Parameter type: <Gpon::GSubCarrierGroupSizeType> - grouping factor per carrier data octet-string - range: [0...2,4,8,16]	Provides the grouping factor for Channel Characteristics data in dB <i>This element is always shown.</i>

112.10 Gpon xDSL Failure Status Near End Status Command

Command Description

This command displays the Gpon xDSL failure status near end.

User Level

The command can be accessed by operators with xdsl privileges.

Command Syntax

The command has the following syntax:

```
> show xdsl ont failure-status near-end [ (if-index) ]
```

Command Parameters

Table 112.10-1 "Gpon xDSL Failure Status Near End Status Command" Resource Parameters

Resource Identifier	Type	Description
(if-index)	Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Gpon::OntSlotId> / <Gpon::OntPortId> ng2 : <Ng2::ChannelGroup> / <Ng2::SubchannelGroup> / <Ng2::OntId> / <Gpon::OntSlotId> / <Gpon::OntPortId>) Possible values: - ng2 : ngpon2 style identification Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Ng2::ChannelGroup> - channel group number Field type <Ng2::SubchannelGroup> - subchannel group number Field type <Eqpt::OntId> - the ONT identifier Field type <Ng2::OntId> - the ONT identifier Field type <Gpon::OntSlotId> - Gpon Ont Slot	interface index of the port

Resource Identifier	Type	Description
	- range: [1...14] Field type <Gpon::OntPortId> - Gpon Ont Port - range: [1...16]	

Command Output

Table 112.10-2 "Gpon xDSL Failure Status Near End Status Command" Display parameters

Specific Information		
name	Type	Description
line-defect	Parameter type: <Xdsl::FailureStatusNearEnd> (yes no) Possible values: - yes : defect in the near-end failure status - no : no defect in the near-end failure status	specifies the defect status in the near-end <i>This element is always shown.</i>
los	Parameter type: <Xdsl::FailureStatusNELOS> (no yes) Possible values: - no : no LOS in upstream direction - yes : LOS in the upstream direction	specifies status of the Loss of Signal in upstream direction <i>This element is always shown.</i>
lof	Parameter type: <Xdsl::FailureStatusNELOF> (no yes) Possible values: - no : no LOF in upstream direction - yes : LOF in the upstream direction	specifies status of the Loss of Frame in upstream direction <i>This element is always shown.</i>
lom	Parameter type: <Xdsl::FailureStatusNELOM> (no yes) Possible values: - no : no LOM in upstream direction - yes : LOM in the upstream direction	specifies status of the Loss of Margin in upstream direction <i>This element is always shown.</i>
lpr	Parameter type: <Xdsl::FailureStatusNELPR> (no yes) Possible values: - no : no LPR of the ATU-C - yes : LPR of the ATU-C	specifies status of the Loss of Power of the ATU-C <i>This element is always shown.</i>
lol	Parameter type: <Xdsl::FailureStatusNELOL> (no yes) Possible values: - no : no LOL in line - yes : LOL in line	specifies status of the Loss of Link <i>This element is always shown.</i>
ese	Parameter type: <Xdsl::FailureStatusNEESE> (no yes) Possible values: - no : no ESE in upstream direction - yes : ESE in the upstream direction	specifies status of the Excessive Severe Errors in upstream direction <i>This element is always shown.</i>
act-fail-conf-err	Parameter type: <Xdsl::NEActFailConfErr> (no yes) Possible values:	specifies status of line Activation <i>This element is always shown.</i>

name	Type	Description
	- no : no Activation Failure due to configuration error - yes : Line Activation Fail due to configuration error	
act-fail-conf-not-feas	Parameter type: <Xdsl::NEActFailConfNotFeasible> (no yes) Possible values: - no : Line Activation Fail due to configuration not feasible - yes : no Activation Failure due to configuration not feasible	specifies status of line Activation <i>This element is always shown.</i>
line-init-fail	Parameter type: <Xdsl::FailureStatusNELineInitFail> (no yes) Possible values: - no : no line initialization failure - yes : line initialization failure	specifies status of line initialization failure <i>This element is always shown.</i>
bitrate-threshold	Parameter type: <Xdsl::FailureStatusNEBitRateThrs> (no-low-rate low-rate) Possible values: - no-low-rate : no Bit rate threshold for the upstream direction - low-rate : Bit rate threshold for upstream direction	specifies status of Bit Rate Threshold <i>This element is always shown.</i>

112.11 Gpon xDSL Failure Status Far End Status Command

Command Description

This command displays the Gpon xDSL failure of the far end.

User Level

The command can be accessed by operators with xdsl privileges.

Command Syntax

The command has the following syntax:

```
> show xdsl ont failure-status far-end [ (if-index) ]
```

Command Parameters

Table 112.11-1 "Gpon xDSL Failure Status Far End Status Command" Resource Parameters

Resource Identifier	Type	Description
(if-index)	Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Gpon::OntSlotId> / <Gpon::OntPortId> ng2 : <Ng2::ChannelGroup> / <Ng2::SubchannelGroup> / <Ng2::OntId> / <Gpon::OntSlotId> / <Gpon::OntPortId>) Possible values: - ng2 : ngpon2 style identification Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Ng2::ChannelGroup> - channel group number Field type <Ng2::SubchannelGroup> - subchannel group number Field type <Eqpt::OntId> - the ONT identifier Field type <Ng2::OntId> - the ONT identifier Field type <Gpon::OntSlotId> - Gpon Ont Slot	interface index of the port

Resource Identifier	Type	Description
	- range: [1...14] Field type <Gpon::OntPortId> - Gpon Ont Port - range: [1...16]	

Command Output

Table 112.11-2 "Gpon xDSL Failure Status Far End Status Command" Display parameters

Specific Information		
name	Type	Description
line-defect	Parameter type: <Xdsl::FailureStatusNoDefect> (yes no) Possible values: - yes : defect in the far-end failure status - no : no defect in the far-end failure status	specifies the defect status in the far-end <i>This element is always shown.</i>
los	Parameter type: <Xdsl::FailureStatusFELOS> (no yes) Possible values: - no : no LOS in downstream direction - yes : LOS in the downstream direction	specifies status of the Loss of Signal in downstream direction <i>This element is always shown.</i>
lof	Parameter type: <Xdsl::FailureStatusFELOF> (no yes) Possible values: - no : no LOF in downstream direction - yes : LOF in the downstream direction	specifies status of the Loss of Frame in downstream direction <i>This element is always shown.</i>
lom	Parameter type: <Xdsl::FailureStatusFELOM> (no yes) Possible values: - no : no LOM in downstream direction - yes : LOM in the downstream direction	specifies status of the Loss of Margin in downstream direction <i>This element is always shown.</i>
lpr	Parameter type: <Xdsl::FailureStatusFELPR> (no yes) Possible values: - no : no LPR of the XTU-R - yes : LPR of the XTU-R	specifies status of the Loss of Power of the XTU-C <i>This element is always shown.</i>
lol	Parameter type: <Xdsl::FailureStatusFELOL> (no yes) Possible values: - no : no LOL in line - yes : LOL in line	specifies status of the Loss of Link <i>This element is always shown.</i>
ese	Parameter type: <Xdsl::FailureStatusFEESE> (no yes) Possible values: - no : no ESE in downstream direction - yes : ESE in the downstream direction	specifies status of the Excessive Severe Errors <i>This element is always shown.</i>
act-fail-comm-prob	Parameter type: <Xdsl::FEActFailCommProb> (no yes) Possible values:	specifies status of line Activation <i>This element is always shown.</i>

112 Gpon xDSL Status Commands

name	Type	Description
	- no : no Activation Failure due to communication problems - yes : Line Activation Fail due to communication problems	
act-fail-no-xtu-r	Parameter type: <Xdsl::FEActFailNoXTUR> (no yes) Possible values: - no : Line Activation Fail due to no XTU-R detected - yes : no Activation Failure due to no XTU-R detected	specifies status of line Activation <i>This element is always shown.</i>
bitrate-threshold	Parameter type: <Xdsl::FailureStatusFEBitRateThrs> (no-low-rate low-rate) Possible values: - no-low-rate : no Bit rate threshold for the downstream direction - low-rate : Bit rate threshold for downstream direction	specifies status of Bit Rate Threshold <i>This element is always shown.</i>

112.12 Gpon xDSL Counters Near End Line Current 15 Min

Command Description

This command displays xDSL counters near end line current 15 min.

User Level

The command can be accessed by operators with xdsl privileges.

Command Syntax

The command has the following syntax:

```
> show xdsl ont counters near-end line current-interval [ (if-index) ]
```

Command Parameters

Table 112.12-1 "Gpon xDSL Counters Near End Line Current 15 Min" Resource Parameters

Resource Identifier	Type	Description
(if-index)	Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Gpon::OntSlotId> / <Gpon::OntPortId> ng2 : <Ng2::ChannelGroup> / <Ng2::SubchannelGroup> / <Ng2::OntId> / <Gpon::OntSlotId> / <Gpon::OntPortId>) Possible values: - ng2 : ngpon2 style identification Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Ng2::ChannelGroup> - channel group number Field type <Ng2::SubchannelGroup> - subchannel group number Field type <Eqpt::OntId> - the ONT identifier Field type <Ng2::OntId> - the ONT identifier Field type <Gpon::OntSlotId> - Gpon Ont Slot	interface index of the port

Resource Identifier	Type	Description
	- range: [1...14] Field type <Gpon::OntPortId> - Gpon Ont Port - range: [1...16]	

Command Output

Table 112.12-2 "Gpon xDSL Counters Near End Line Current 15 Min" Display parameters

Specific Information		
name	Type	Description
los	Parameter type: <Counter> - 32 bit counter	number of occurrences of an LOS failure event <i>This element is always shown.</i>
lof	Parameter type: <Counter> - 32 bit counter	number of occurrences of an LOF failure event <i>This element is always shown.</i>
es	Parameter type: <Counter> - 32 bit counter	number of errored seconds encountered by the line <i>This element is always shown.</i>
ses	Parameter type: <Counter> - 32 bit counter	number of severely errored seconds encountered by the line <i>This element is always shown.</i>
uas	Parameter type: <Counter> - 32 bit counter	number of unavailable seconds encountered by the line <i>This element is always shown.</i>
re-init	Parameter type: <Counter> - 32 bit counter	number of times the modem re-initialize the line <i>This element is always shown.</i>
failed-init	Parameter type: <Counter> - 32 bit counter	number of times the modem failed to initialize the line <i>This element is always shown.</i>
init-timeout	Parameter type: <Counter> - 32 bit counter	number of initialization timeouts <i>This element is always shown.</i>

112.13 Gpon xDSL Counters Near End Line Previous 15 Min

Command Description

This command displays the xDSL counters near end line previous 15 min.

User Level

The command can be accessed by operators with xdsl privileges.

Command Syntax

The command has the following syntax:

```
> show xdsl ont counters near-end line previous-interval [ (if-index) [ interval-no <Xdsl::IntervalNumber15min> ] ]
```

Command Parameters

Table 112.13-1 "Gpon xDSL Counters Near End Line Previous 15 Min" Resource Parameters

Resource Identifier	Type	Description
(if-index)	Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Gpon::OntSlotId> / <Gpon::OntPortId> ng2 : <Ng2::ChannelGroup> / <Ng2::SubchannelGroup> / <Ng2::OntId> / <Gpon::OntSlotId> / <Gpon::OntPortId>) Possible values: - ng2 : ngpon2 style identification Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Ng2::ChannelGroup> - channel group number Field type <Ng2::SubchannelGroup> - subchannel group number Field type <Eqpt::OntId> - the ONT identifier Field type <Ng2::OntId> - the ONT identifier Field type <Gpon::OntSlotId> - Gpon Ont Slot	interface index of the port

Resource Identifier	Type	Description
	- range: [1...14] Field type <Gpon::OntPortId> - Gpon Ont Port - range: [1...16]	
interval-no	Parameter type: <Xdsl::IntervalNumber15min> Format: - a number identifying 15 minutes interval time - range: [1...192]	identifies prev 15min intvls, val 1 as the latest intvl

Command Output

Table 112.13-2 "Gpon xDSL Counters Near End Line Previous 15 Min" Display parameters

Specific Information		
name	Type	Description
los	Parameter type: <Counter> - 32 bit counter	number of occurrences of an LOS failure event <i>This element is always shown.</i>
lof	Parameter type: <Counter> - 32 bit counter	number of occurrences of an LOF failure event <i>This element is always shown.</i>
es	Parameter type: <Counter> - 32 bit counter	number of errored seconds encountered by the line <i>This element is always shown.</i>
ses	Parameter type: <Counter> - 32 bit counter	number of severely errored seconds encountered by the line <i>This element is always shown.</i>
uas	Parameter type: <Counter> - 32 bit counter	number of unavailable seconds encountered by the line <i>This element is always shown.</i>
re-init	Parameter type: <Counter> - 32 bit counter	number of times the modem re-initialize the line <i>This element is always shown.</i>
fail-init	Parameter type: <Counter> - 32 bit counter	number of times the modem failed to initialize the line <i>This element is always shown.</i>
init-timeout	Parameter type: <Counter> - 32 bit counter	number of initialization timeouts <i>This element is always shown.</i>

112.14 Gpon xDSL Counters Near End Channel Current 15 Min

Command Description

This command displays xDSL counters near end channel current 15 min.

User Level

The command can be accessed by operators with xdsl privileges.

Command Syntax

The command has the following syntax:

```
> show xdsl ont counters near-end channel current-interval [ (if-index) ]
```

Command Parameters

Table 112.14-1 "Gpon xDSL Counters Near End Channel Current 15 Min" Resource Parameters

Resource Identifier	Type	Description
(if-index)	Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Gpon::OntSlotId> / <Gpon::OntPortId> ng2 : <Ng2::ChannelGroup> / <Ng2::SubchannelGroup> / <Ng2::OntId> / <Gpon::OntSlotId> / <Gpon::OntPortId>) Possible values: - ng2 : ngpon2 style identification Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Ng2::ChannelGroup> - channel group number Field type <Ng2::SubchannelGroup> - subchannel group number Field type <Eqpt::OntId> - the ONT identifier Field type <Ng2::OntId> - the ONT identifier Field type <Gpon::OntSlotId> - Gpon Ont Slot	interface index of the port

Resource Identifier	Type	Description
	- range: [1...14] Field type <Gpon::OntPortId> - Gpon Ont Port - range: [1...16]	

Command Output

Table 112.14-2 "Gpon xDSL Counters Near End Channel Current 15 Min" Display parameters

Specific Information		
name	Type	Description
cv	Parameter type: <Counter> - 32 bit counter	number of coding violations encountered by the channel <i>This element is always shown.</i>
fecc	Parameter type: <Counter> - 32 bit counter	number of corrected codewords encountered by the channel, respectively corrected octets in case of vdsl1 G.993.1 <i>This element is always shown.</i>

112.15 Gpon xDSL Counters Near End Channel Previous 15 Min

Command Description

This command displays xDSL counters near end channel previous 15 min.

User Level

The command can be accessed by operators with xdsl privileges.

Command Syntax

The command has the following syntax:

```
> show xdsl ont counters near-end channel previous-interval [ (if-index) [ interval-no
<Xdsl::IntervalNumber15min> ] ]
```

Command Parameters

Table 112.15-1 "Gpon xDSL Counters Near End Channel Previous 15 Min" Resource Parameters

Resource Identifier	Type	Description
(if-index)	Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Gpon::OntSlotId> / <Gpon::OntPortId> ng2 : <Ng2::ChannelGroup> / <Ng2::SubchannelGroup> / <Ng2::OntId> / <Gpon::OntSlotId> / <Gpon::OntPortId>) Possible values: - ng2 : ngpon2 style identification Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Ng2::ChannelGroup> - channel group number Field type <Ng2::SubchannelGroup> - subchannel group number Field type <Eqpt::OntId> - the ONT identifier Field type <Ng2::OntId> - the ONT identifier Field type <Gpon::OntSlotId>	interface index of the port

Resource Identifier	Type	Description
	- Gpon Ont Slot - range: [1...14] - Field type <Gpon::OntPortId> - Gpon Ont Port - range: [1...16]	
interval-no	Parameter type: <Xdsl::IntervalNumber15min> Format: - a number identifying 15 minutes interval time - range: [1...192]	previous 15 minute interval number, value 1 is the most recently completed 15 minute interval

Command Output

Table 112.15-2 "Gpon xDSL Counters Near End Channel Previous 15 Min" Display parameters

Specific Information		
name	Type	Description
cv	Parameter type: <Counter> - 32 bit counter	number of coding violations encountered by the channel <i>This element is always shown.</i>
fecc	Parameter type: <Counter> - 32 bit counter	number of corrected codewords encountered by the channel, respectively corrected octets in case of vdsl1 G.993.1 <i>This element is always shown.</i>

112.16 Gpon xDSL Counters Far End Line Current 15 Min

Command Description

This command displays xDSL counters far end line current 15 min.

User Level

The command can be accessed by operators with xdsl privileges.

Command Syntax

The command has the following syntax:

```
> show xdsl ont counters far-end line current-interval [ (if-index) ]
```

Command Parameters

Table 112.16-1 "Gpon xDSL Counters Far End Line Current 15 Min" Resource Parameters

Resource Identifier	Type	Description
(if-index)	Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Gpon::OntSlotId> / <Gpon::OntPortId> ng2 : <Ng2::ChannelGroup> / <Ng2::SubchannelGroup> / <Ng2::OntId> / <Gpon::OntSlotId> / <Gpon::OntPortId>) Possible values: - ng2 : ngpon2 style identification Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Ng2::ChannelGroup> - channel group number Field type <Ng2::SubchannelGroup> - subchannel group number Field type <Eqpt::OntId> - the ONT identifier Field type <Ng2::OntId> - the ONT identifier Field type <Gpon::OntSlotId> - Gpon Ont Slot	interface index of the port

Resource Identifier	Type	Description
	- range: [1...14] Field type <Gpon::OntPortId> - Gpon Ont Port - range: [1...16]	

Command Output

Table 112.16-2 "Gpon xDSL Counters Far End Line Current 15 Min" Display parameters

Specific Information		
name	Type	Description
los	Parameter type: <Counter> - 32 bit counter	number of occurrences of an los failure event <i>This element is always shown.</i>
lof	Parameter type: <Counter> - 32 bit counter	number of occurrences of an lof failure event <i>This element is always shown.</i>
es	Parameter type: <Counter> - 32 bit counter	number of errored seconds encountered by the line <i>This element is always shown.</i>
ses	Parameter type: <Counter> - 32 bit counter	number of severely errored seconds encountered by the line <i>This element is always shown.</i>
uas	Parameter type: <Counter> - 32 bit counter	number of unavailable seconds encountered by the line <i>This element is always shown.</i>

112.17 Gpon xDSL Counters Far End Line Previous 15 Min

Command Description

This command displays xDSL counters far end line previous 15 min.

User Level

The command can be accessed by operators with xdsl privileges.

Command Syntax

The command has the following syntax:

```
> show xdsl ont counters far-end line previous-interval [ (if-index) [ interval-no <Xdsl::IntervalNumber15min> ] ]
```

Command Parameters

Table 112.17-1 "Gpon xDSL Counters Far End Line Previous 15 Min" Resource Parameters

Resource Identifier	Type	Description
(if-index)	Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Gpon::OntSlotId> / <Gpon::OntPortId> ng2 : <Ng2::ChannelGroup> / <Ng2::SubchannelGroup> / <Ng2::OntId> / <Gpon::OntSlotId> / <Gpon::OntPortId>) Possible values: - ng2 : ngpon2 style identification Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Ng2::ChannelGroup> - channel group number Field type <Ng2::SubchannelGroup> - subchannel group number Field type <Eqpt::OntId> - the ONT identifier Field type <Ng2::OntId> - the ONT identifier Field type <Gpon::OntSlotId> - Gpon Ont Slot	interface index of the port

Resource Identifier	Type	Description
	- range: [1...14] Field type <Gpon::OntPortId> - Gpon Ont Port - range: [1...16]	
interval-no	Parameter type: <Xdsl::IntervalNumber15min> Format: - a number identifying 15 minutes interval time - range: [1...192]	nbr identifying previous 15 min intvl time, value 1 is the most recently completed 15 min intvl

Command Output

Table 112.17-2 "Gpon xDSL Counters Far End Line Previous 15 Min" Display parameters

Specific Information		
name	Type	Description
los	Parameter type: <Counter> - 32 bit counter	number of occurrences of an los failure event <i>This element is always shown.</i>
lof	Parameter type: <Counter> - 32 bit counter	number of occurrences of an lof failure event <i>This element is always shown.</i>
es	Parameter type: <Counter> - 32 bit counter	number of errored seconds encountered by the line <i>This element is always shown.</i>
ses	Parameter type: <Counter> - 32 bit counter	number of severely errored seconds encountered by the line <i>This element is always shown.</i>
uas	Parameter type: <Counter> - 32 bit counter	number of unavailable seconds encountered by the line <i>This element is always shown.</i>

112.18 Gpon xDSL Counters Far End Channel Current 15 Min

Command Description

This command displays xDSL counters far end channel current 15 min.

User Level

The command can be accessed by operators with xdsl privileges.

Command Syntax

The command has the following syntax:

```
> show xdsl ont counters far-end channel current-interval [ (if-index) ]
```

Command Parameters

Table 112.18-1 "Gpon xDSL Counters Far End Channel Current 15 Min" Resource Parameters

Resource Identifier	Type	Description
(if-index)	Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Gpon::OntSlotId> / <Gpon::OntPortId> ng2 : <Ng2::ChannelGroup> / <Ng2::SubchannelGroup> / <Ng2::OntId> / <Gpon::OntSlotId> / <Gpon::OntPortId>) Possible values: - ng2 : ngpon2 style identification Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Ng2::ChannelGroup> - channel group number Field type <Ng2::SubchannelGroup> - subchannel group number Field type <Eqpt::OntId> - the ONT identifier Field type <Ng2::OntId> - the ONT identifier Field type <Gpon::OntSlotId> - Gpon Ont Slot	interface index of the port

Resource Identifier	Type	Description
	- range: [1...14] Field type <Gpon::OntPortId> - Gpon Ont Port - range: [1...16]	

Command Output

Table 112.18-2 "Gpon xDSL Counters Far End Channel Current 15 Min" Display parameters

Specific Information		
name	Type	Description
cv	Parameter type: <Counter> - 32 bit counter	nbr of coding violations encountered by far end channel <i>This element is always shown.</i>
fecc	Parameter type: <Counter> - 32 bit counter	number of corrected codewords encountered by the channel, respectively corrected octets in case of vdsl1 G.993.1 <i>This element is always shown.</i>

112.19 Gpon xDSL Counters Far End Channel Previous 15 Min

Command Description

This command displays xDSL counters far end channel current 15 min.

User Level

The command can be accessed by operators with xdsl privileges.

Command Syntax

The command has the following syntax:

```
> show xdsl ont counters far-end channel previous-interval [ (if-index) [ interval-no <Xdsl::IntervalNumber15min> ] ]
```

Command Parameters

Table 112.19-1 "Gpon xDSL Counters Far End Channel Previous 15 Min" Resource Parameters

Resource Identifier	Type	Description
(if-index)	Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Gpon::OntSlotId> / <Gpon::OntPortId> ng2 : <Ng2::ChannelGroup> / <Ng2::SubchannelGroup> / <Ng2::OntId> / <Gpon::OntSlotId> / <Gpon::OntPortId>) Possible values: - ng2 : ngpon2 style identification Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Ng2::ChannelGroup> - channel group number Field type <Ng2::SubchannelGroup> - subchannel group number Field type <Eqpt::OntId> - the ONT identifier Field type <Ng2::OntId> - the ONT identifier Field type <Gpon::OntSlotId>	interface index of the port

Resource Identifier	Type	Description
	- Gpon Ont Slot - range: [1...14] - Field type <Gpon::OntPortId> - Gpon Ont Port - range: [1...16]	
interval-no	Parameter type: <Xdsl::IntervalNumber15min> Format: - a number identifying 15 minutes interval time - range: [1...192]	previous 15 minute interval number, value 1 is the most recently completed 15 minute interval

Command Output

Table 112.19-2 "Gpon xDSL Counters Far End Channel Previous 15 Min" Display parameters

Specific Information		
name	Type	Description
cv	Parameter type: <Counter> - 32 bit counter	number of coding violations in the previous 15 min <i>This element is always shown.</i>
fecc	Parameter type: <Counter> - 32 bit counter	number of corrected codewords encountered by the channel, respectively corrected octets in case of vdsl1 G.993.1 <i>This element is always shown.</i>

112.20 Gpon xDSL XTU-R Inventory Status Command

Command Description

This command displays xDSL inventory XT/RT.

User Level

The command can be accessed by operators with xdsl privileges.

Command Syntax

The command has the following syntax:

```
> show xdsl ont cpe-tur-inventory [ (if-index) ]
```

Command Parameters

Table 112.20-1 "Gpon xDSL XTU-R Inventory Status Command" Resource Parameters

Resource Identifier	Type	Description
(if-index)	Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Gpon::OntSlotId> / <Gpon::OntPortId> ng2 : <Ng2::ChannelGroup> / <Ng2::SubchannelGroup> / <Ng2::OntId> / <Gpon::OntSlotId> / <Gpon::OntPortId>) Possible values: - ng2 : ngpon2 style identification Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Ng2::ChannelGroup> - channel group number Field type <Ng2::SubchannelGroup> - subchannel group number Field type <Eqpt::OntId> - the ONT identifier Field type <Ng2::OntId> - the ONT identifier Field type <Gpon::OntSlotId> - Gpon Ont Slot	interface index of the port

Resource Identifier	Type	Description
	- range: [1...14] Field type <Gpon::OntPortId> - Gpon Ont Port - range: [1...16]	

Command Output

Table 112.20-2 "Gpon xDSL XTU-R Inventory Status Command" Display parameters

Specific Information		
name	Type	Description
modem-vendor-id	Parameter type: <Xdsl::VendorID> - an octet string defining vendor identification - length: x<=16	vendor ID retrieved during handshaking <i>This element is always shown.</i>
sys-serial-no	Parameter type: <Xdsl::SystemSerialNumber> - an octet string defining system serial number - length: x<=32	serial number that identifies the vendor equipment <i>This element is only shown in detail mode.</i>
sys-vendor-id	Parameter type: <Xdsl::VendorID> - an octet string defining vendor identification - length: x<=16	vendor ID retrieved via the xdsl EOC <i>This element is always shown.</i>
sys-version-no	Parameter type: <Xdsl::SystemVersionNo> - an octet string defining system version number - length: x<=32	version number retrieved via the the xdsl EOC <i>This element is only shown in detail mode.</i>
self-test-result	Parameter type: <Xdsl::SelfTestResult> - an octet string defining self test result - length: x<=8	self test results value retrieved via the the xdsl EOC <i>This element is always shown.</i>

112.21 Gpon xDSL XTU-C Inventory Status Command

Command Description

This command displays xDSL inventory XT/RT.

User Level

The command can be accessed by operators with xdsl privileges.

Command Syntax

The command has the following syntax:

```
> show xdsl ont cpe-tuc-inventory [ (if-index) ]
```

Command Parameters

Table 112.21-1 "Gpon xDSL XTU-C Inventory Status Command" Resource Parameters

Resource Identifier	Type	Description
(if-index)	Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Gpon::OntSlotId> / <Gpon::OntPortId> ng2 : <Ng2::ChannelGroup> / <Ng2::SubchannelGroup> / <Ng2::OntId> / <Gpon::OntSlotId> / <Gpon::OntPortId>) Possible values: - ng2 : ngpon2 style identification Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Ng2::ChannelGroup> - channel group number Field type <Ng2::SubchannelGroup> - subchannel group number Field type <Eqpt::OntId> - the ONT identifier Field type <Ng2::OntId> - the ONT identifier Field type <Gpon::OntSlotId> - Gpon Ont Slot	interface index of the port

Resource Identifier	Type	Description
	- range: [1...14] - Field type <Gpon::OntPortId> - Gpon Ont Port - range: [1...16]	

Command Output

Table 112.21-2 "Gpon xDSL XTU-C Inventory Status Command" Display parameters

Specific Information		
name	Type	Description
modem-vendor-id	Parameter type: <Xdsl::VendorID> - an octet string defining vendor identification - length: x<=16	vendor ID retrieved during handshaking <i>This element is always shown.</i>
sys-serial-no	Parameter type: <Xdsl::SystemSerialNumber> - an octet string defining system serial number - length: x<=32	serial number that identifies the vendor equipment <i>This element is only shown in detail mode.</i>
sys-vendor-id	Parameter type: <Xdsl::VendorID> - an octet string defining vendor identification - length: x<=16	vendor ID retrieved via the xdsl EOC <i>This element is always shown.</i>
sys-version-no	Parameter type: <Xdsl::SystemVersionNo> - an octet string defining system version number - length: x<=32	version number retrieved via the xdsl EOC <i>This element is only shown in detail mode.</i>

113- xDSL Bonding Status Commands

113.1 xDSL Bonding Status Command Tree	113-5678
113.2 xDSL Bonding Group Profiles Status Command	113-5679
113.3 xDSL Bonding Group Rtx Profiles Status Command	113-5681
113.4 xDSL Bonding Near End Operational Data Status Command	113-5683
113.5 xDSL Bonding Far End Operational Data Status Command	113-5685
113.6 xDSL Bonding Group Operational Data Command	113-5687
113.7 xDSL Bonding Link Operational Data Command	113-5690
113.8 xDSL Bonding Near End Failure Status Command	113-5692
113.9 xDSL Bonding Far End Failure Status Command	113-5694
113.10 xDSL Bonding Group Failure Status Command	113-5696
113.11 xDSL Bonding Group Summary Info Command	113-5698
113.12 xDSL Bonding actual PTM Initialization Mode status command	113-5699

113.1 xDSL Bonding Status Command Tree

Description

This chapter gives an overview of nodes that are handled by "xDSL Bonding Status Commands".

Command Tree

```
----show
  ----xdsl-bonding
    ----profiles
      - (index)
    ----group-rtx-profiles
      - (index)
    ----operational-data
      ----X near-end
        - (if-index)
      ----X far-end
        - (if-index)
      ----group
        - (if-index)
      ----link
        - (bonding-link-id)
    ----failure-status
      ----near-end
        - (if-index)
      ----far-end
        - (if-index)
      ----group
        - (if-index)
    ----summary
      - (index)
  ----actual-ptm-init-mode
```


113.2 xDSL Bonding Group Profiles Status Command

Command Description

This command displays the usage of the xDSL bonding group profiles.

User Level

The command can be accessed by operators with xdsl privileges.

Command Syntax

The command has the following syntax:

```
> show xdsl-bonding profiles [ (index) ]
```

Command Parameters

Table 113.2-1 "xDSL Bonding Group Profiles Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - bonding group profile index - range: [1...100]	a unique interface index

Command Output

Table 113.2-2 "xDSL Bonding Group Profiles Status Command" Display parameters

Common Information:profile		
name	Type	Description
next-av-bond-pr	Parameter type: <AsamNextProfileIndex> - a profile index - range: [0...65535]	next available index for the bonding group profile <i>This element is always shown.</i>
max-bond-pr	Parameter type: <AsamMaxProfileIndex> - a maximum value of a profile index - range: [0...65535]	max number of bonding group profile indices that can be created <i>This element is always shown.</i>
Specific Information		
name	Type	Description
name	Parameter type: <AsamProfileName> - a profile name - range: [a-zA-Z0-9-_.] - length: 1<=x<=32	name of the bonding group profile <i>This element is always shown.</i>
used-status	Parameter type: <Xdsl::UsedStatus> - number of entities using this profile - range: [0...65535]	specifies the number of entities using this profile. <i>This element is always shown.</i>

113.3 xDSL Bonding Group Rtx Profiles Status Command

Command Description

This command displays the usage of the xDSL bonding group rtx profiles.

User Level

The command can be accessed by operators with xdsl privileges.

Command Syntax

The command has the following syntax:

```
> show xdsl-bonding group-rtx-profiles [ (index) ]
```

Command Parameters

Table 113.3-1 "xDSL Bonding Group Rtx Profiles Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - a profile index value - range: [1...1024]	a unique interface index

Command Output

Table 113.3-2 "xDSL Bonding Group Rtx Profiles Status Command" Display parameters

Common Information:profile		
name	Type	Description
next-av-bond-rtx-pr	Parameter type: <AsamNextProfileIndex> - a profile index - range: [0...65535]	next available index for the bonding group rtx profile <i>This element is always shown.</i>
max-bond-rtx-pr	Parameter type: <AsamMaxProfileIndex> - a maximum value of a profile index - range: [0...65535]	max number of bonding group rtx profile indices that can be created <i>This element is always shown.</i>
Specific Information		
name	Type	Description
name	Parameter type: <AsamProfileName> - a profile name - range: [a-zA-Z0-9-_.] - length: 1<=x<=32	name of the bonding group rtx profile <i>This element is always shown.</i>
used-status	Parameter type: <Xdsl::UsedStatus> - number of entities using this profile - range: [0...65535]	specifies the number of entities using this profile. <i>This element is always shown.</i>

113.4 xDSL Bonding Near End Operational Data Status Command

Command Description

Obsolete command, replaced by `show xdsl-bonding operational-data group`.

This command shows the operational data near end statistics.

User Level

The command can be accessed by operators with `xdsl` privileges.

Command Syntax

The command has the following syntax:

```
> show xdsl-bonding operational-data near-end [ (if-index) ]
```

Obsolete command, replaced by `show xdsl-bonding operational-data group`.

Command Parameters

Table 113.4-1 "xDSL Bonding Near End Operational Data Status Command" Resource Parameters

Resource Identifier	Type	Description
(if-index)	Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number	a unique interface index

Command Output

Table 113.4-2 "xDSL Bonding Near End Operational Data Status Command" Display parameters

Specific Information		
name	Type	Description
actual-bitrate-up	Parameter type: <Xdsl::maxBitRate> - a bit rate value - unit: kbps - range: [0...4294967295]	when the bonding group is in service, this will give the actual bitrate and 0 when not in service also in case no data is available.

113 xDSL Bonding Status Commands

name	Type	Description
		<i>This element is always shown.</i>
actaggr-ndr-up	Parameter type: <Xdsl::maxBitRate> - a bit rate value - unit: kbps - range: [0...4294967295]	when the bonding group is in service, this will give the actual net data rate in upstream direction. Value 0 means bonding group not in service or no data available. <i>This element is always shown.</i>

113.5 xDSL Bonding Far End Operational Data Status Command

Command Description

Obsolete command, replaced by `show xdsl-bonding operational-data group`.

This command shows the operational data far end statistics.

User Level

The command can be accessed by operators with `xdsl` privileges.

Command Syntax

The command has the following syntax:

```
> show xdsl-bonding operational-data far-end [ (if-index) ]
```

Obsolete command, replaced by `show xdsl-bonding operational-data group`.

Command Parameters

Table 113.5-1 "xDSL Bonding Far End Operational Data Status Command" Resource Parameters

Resource Identifier	Type	Description
(if-index)	Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number	a unique interface index

Command Output

Table 113.5-2 "xDSL Bonding Far End Operational Data Status Command" Display parameters

Specific Information		
name	Type	Description
actual-bitrate-down	Parameter type: <Xdsl::maxBitRate> - a bit rate value - unit: kbps - range: [0...4294967295]	when the bonding group is in service, this will give the actual bitrate and 0 when not in service also in case no data is available.

113 xDSL Bonding Status Commands

name	Type	Description
		<i>This element is always shown.</i>
actaggr-ndr-dn	Parameter type: <Xdsl::maxBitRate> - a bit rate value - unit: kbps - range: [0...4294967295]	when the bonding group is in service, this will give the actual net data rate in downstream direction. Value 0 means bonding group not in service or no data available. <i>This element is always shown.</i>

113.6 xDSL Bonding Group Operational Data Command

Command Description

This command displays the xDSL bonding oper-data group statistics.

User Level

The command can be accessed by operators with xdsl privileges.

Command Syntax

The command has the following syntax:

```
> show xdsl-bonding operational-data group [ (if-index) ]
```

Command Parameters

Table 113.6-1 "xDSL Bonding Group Operational Data Command" Resource Parameters

Resource Identifier	Type	Description
(if-index)	Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number	a unique interface index

Command Output

Table 113.6-2 "xDSL Bonding Group Operational Data Command" Display parameters

Specific Information		
name	Type	Description
running-time	Parameter type: <SignedInteger> - a signed integer	specifies accumulated time of bonding group normal operation <i>This element is always shown.</i>
actual-bitrate-up	Parameter type: <Xdsl::maxBitRate> - a bit rate value - unit: kbps - range: [0...4294967295]	when the bonding group is in service, this will give the actual net data rate in upstream direction or the expected

113 xDSL Bonding Status Commands

name	Type	Description
		throughput for the upstream retransmission bonded data flow. Value 0 means bonding group not in service or no data available. <i>This element is always shown.</i>
actual-bitrate-down	Parameter type: <Xdsl::maxBitRate> - a bit rate value - unit: kbps - range: [0...4294967295]	when the bonding group is in service, this will give the actual net data rate in downstream direction or the expected throughput for the downstream retransmission bonded data flow. Value 0 means bonding group not in service also or no data available. <i>This element is always shown.</i>
actaggr-ndr-up	Parameter type: <Xdsl::maxBitRate> - a bit rate value - unit: kbps - range: [0...4294967295]	when the bonding group is in service, this will give the actual net data rate in upstream direction. Value 0 means bonding group not in service or no data available. <i>This element is always shown.</i>
actaggr-ndr-dn	Parameter type: <Xdsl::maxBitRate> - a bit rate value - unit: kbps - range: [0...4294967295]	when the bonding group is in service, this will give the actual net data rate in downstream direction. Value 0 means bonding group not in service or no data available. <i>This element is always shown.</i>
nbr-contributing-links short name: contrib-lnks	Parameter type: <SignedInteger> - a signed integer	the number of operational links, selected by bandwidth split, contributing to the overall bonding group actual bitrate <i>This element is always shown.</i>
vect-fallback short name: vect-fb	Parameter type: <Xdsl::ActualVectFallbackState> ((normal-mode normal) (fallback-mode fallback)) Possible values: - normal-mode : line is operating using normal profiles - normal : line is operating using normal profiles - fallback-mode : line is operating using vectoring fallback configured profiles - fallback : line is operating using vectoring fallback configured profiles	actual vectoring fallback state of the group <i>This element is always shown.</i>
opr-status short name: oper/status	Parameter type: <If::ifOperStatus> (up down testing unknown dormant no-value) Possible values: - up : up, traffic can pass - down : down, no traffic is passing - testing : testing, no traffic is passing - unknown : unknown - dormant : dormant, no traffic is passing	The current operational state of the interface. <i>This element is always shown.</i>

name	Type	Description
	- no-value : no entry in the table	

113.7 xDSL Bonding Link Operational Data Command

Command Description

This command displays the xDSL bonding oper-data link statistics.

User Level

The command can be accessed by operators with xdsl privileges.

Command Syntax

The command has the following syntax:

```
> show xdsl-bonding operational-data link [ (bonding-link-id) ]
```

Command Parameters

Table 113.7-1 "xDSL Bonding Link Operational Data Command" Resource Parameters

Resource Identifier	Type	Description
(bonding-link-id)	Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number	a bonding link interface index

Command Output

Table 113.7-2 "xDSL Bonding Link Operational Data Command" Display parameters

Specific Information		
name	Type	Description
link-status	Parameter type: <Xdsl::BondingGroupLinkStatus> (not-training training not-selected up-no-traffic up-traffic) Possible values:	the operational and selection status of a bonding group link <i>This element is always shown.</i>

name	Type	Description
	- not-training : no training allowed - training : training triggered - not-selected : line not selected by BW-split algorithm. This value is not applicable for PTM bonding group initialization mode2. - up-no-traffic : selected by BW-split algorithm, not selected for traffic(only for ATM lines) - up-traffic : selected by BW-split algorithm, selected for traffic	
link-group-idx	Parameter type: <Xdsl::BondingInterfaceIndex> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number	the bonding group index of which the link is a member <i>This element is always shown.</i>

113.8 xDSL Bonding Near End Failure Status Command

Command Description

This command displays the xDSL bonding failure near end statistics.

User Level

The command can be accessed by operators with xdsl privileges.

Command Syntax

The command has the following syntax:

```
> show xdsl-bonding failure-status near-end [ (if-index) ]
```

Command Parameters

Table 113.8-1 "xDSL Bonding Near End Failure Status Command" Resource Parameters

Resource Identifier	Type	Description
(if-index)	Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number	a unique interface index

Command Output

Table 113.8-2 "xDSL Bonding Near End Failure Status Command" Display parameters

Specific Information		
name	Type	Description
defect	Parameter type: <Xdsl::FailureStatusNEDefect> (yes none) Possible values: - yes : defect in the near-end failure status - none : no defect in the near-end failure status	specifies the defect status in the near-end <i>This element is always shown.</i>
up-min-bitrate	Parameter type: <Xdsl::FailureStatusMinBitrate>	specifies the upstream minimum

name	Type	Description
	(ok failure) Possible values: - ok : actual group bitrate is above the group minimum bitrate - failure : actual group bitrate is below the group minimum bitrate	bitrate threshold alarm status <i>This element is always shown.</i>
up-config	Parameter type: <Xdsl::FailureStatusConfig> (feasible not-feasible) Possible values: - feasible : configuration feasible - not-feasible : configuration not feasible e.g. actual group bitrate is not high enough	specifies the upstream configured alarm status <i>This element is always shown.</i>
up-plan-bitrate	Parameter type: <Xdsl::FailureStatusPlanBitrate> (ok failure) Possible values: - ok : actual group bitrate is above the group planned bitrate - failure : actual group bitrate is above the minimum bitrate but below the group planned bitrate	specifies the upstream planned bitrate threshold alarm status <i>This element is always shown.</i>
defect-count	Parameter type: <Counter> - 32 bit counter	Indicates the number of failures during the accumulation period <i>This element is always shown.</i>
rxlos-count	Parameter type: <Counter> - 32 bit counter	Indicates the number of lost ATM cells or ETH fragments due to sequence ID errors. <i>This element is only shown in detail mode.</i>

113.9 xDSL Bonding Far End Failure Status Command

Command Description

This command displays the xDSL bonding failure far end statistics.

User Level

The command can be accessed by operators with xdsl privileges.

Command Syntax

The command has the following syntax:

```
> show xdsl-bonding failure-status far-end [ (if-index) ]
```

Command Parameters

Table 113.9-1 "xDSL Bonding Far End Failure Status Command" Resource Parameters

Resource Identifier	Type	Description
(if-index)	Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number	a unique interface index

Command Output

Table 113.9-2 "xDSL Bonding Far End Failure Status Command" Display parameters

Specific Information		
name	Type	Description
defect	Parameter type: <Xdsl::FailureStatusFEDefect> (yes none) Possible values: - yes : defect in the far-end failure status - none : no defect in the far-end failure status	specifies the defect status in the far-end <i>This element is always shown.</i>
down-min-bitrate	Parameter type: <Xdsl::FailureStatusMinBitrate>	specifies the downstream

name	Type	Description
	(ok failure) Possible values: - ok : actual group bitrate is above the group minimum bitrate - failure : actual group bitrate is below the group minimum bitrate	minimum bitrate threshold alarm status <i>This element is always shown.</i>
down-config	Parameter type: <Xdsl::FailureStatusConfig> (feasible not-feasible) Possible values: - feasible : configuration feasible - not-feasible : configuration not feasible e.g. actual group bitrate is not high enough	specifies the downstream configured alarm status <i>This element is always shown.</i>
down-plan-bitrate	Parameter type: <Xdsl::FailureStatusPlanBitrate> (ok failure) Possible values: - ok : actual group bitrate is above the group planned bitrate - failure : actual group bitrate is above the minimum bitrate but below the group planned bitrate	specifies the downstream planned bitrate threshold alarm status <i>This element is always shown.</i>
peer-cpe	Parameter type: <Xdsl::FailureStatusFEPeerCpeConn> (conn not-conn) Possible values: - conn : peer cpe is connected - not-conn : peer cpe is not connected	specifies the peer cpe connected alarm status <i>This element is only shown in detail mode.</i>
bond-cpe	Parameter type: <Xdsl::FailureStatusFEBondCpeConn> (conn not-conn) Possible values: - conn : bonding capable cpe is connected - not-conn : bonding capable cpe is not connected	specifies the bonding capable cpe connected alarm status <i>This element is only shown in detail mode.</i>
bg-conn-cpes	Parameter type: <Xdsl::FailureStatusFEBondGrpConnCpe> (one-cpe several-cpe) Possible values: - one-cpe : bonding group has one cpe connected - several-cpe : bonding group has multiple cpe connected	specifies the bonding group multiple cpe connected alarm status <i>This element is only shown in detail mode.</i>
bg-reg-fail	Parameter type: <Xdsl::FailureStatusFEBondGrpRegFail> (no yes) Possible values: - no : bonding group register failure not encountered - yes : bonding group register failure encountered	specifies the bonding group discovery or aggregation register failure alarm status <i>This element is only shown in detail mode.</i>
defect-count	Parameter type: <Counter> - 32 bit counter	Indicates the number of failures during the accumulation period <i>This element is always shown.</i>
rxlos-count	Parameter type: <Counter> - 32 bit counter	Indicates the number of lost ATM cells or ETH fragments due to sequence ID errors. <i>This element is only shown in detail mode.</i>

113.10 xDSL Bonding Group Failure Status

Command

Command Description

This command displays the xDSL bonding failure group statistics.

User Level

The command can be accessed by operators with xdsl privileges.

Command Syntax

The command has the following syntax:

```
> show xdsl-bonding failure-status group [ (if-index) ]
```

Command Parameters

Table 113.10-1 "xDSL Bonding Group Failure Status Command" Resource Parameters

Resource Identifier	Type	Description
(if-index)	Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number	a unique interface index

Command Output

Table 113.10-2 "xDSL Bonding Group Failure Status Command" Display parameters

Specific Information		
name	Type	Description
defect	Parameter type: <Xdsl::BondingGroupFailureStatusDefect> (none not-feasible min-bitrate no-host diff-delay incomplete)	specifies the current failure reason of a bonding group <i>This element is always shown.</i>

name	Type	Description
	Possible values: - none : no defect on the bonding group failure status - not-feasible : bonding group configuration not feasible - min-bitrate : bonding group minimum data rate not met - no-host : bonding group host not reachable - diff-delay : bonding group differential delay tolerance exceeded - incomplete : bonding group incomplete	
failure-count	Parameter type: <Counter> - 32 bit counter	specifies the number of times a bonding group is declared unavailable <i>This element is always shown.</i>
rx-error-count	Parameter type: <Counter> - 32 bit counter	specifies the number of errored cells received <i>This element is always shown.</i>
unavailable-time	Parameter type: <Xdsl::IntervalMeasureTime> - the measured time interval - unit: sec - range: [0...86400]	specifies accumulated time of bonding group unavailability <i>This element is always shown.</i>

113.11 xDSL Bonding Group Summary Info Command

Command Description

This command displays the xDSL bonding group summary information.

User Level

The command can be accessed by operators with xdsl privileges.

Command Syntax

The command has the following syntax:

```
> show xdsl-bonding summary [ (index) ]
```

Command Parameters

Table 113.11-1 "xDSL Bonding Group Summary Info Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId>) Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number	the physical number of the slot

Command Output

Table 113.11-2 "xDSL Bonding Group Summary Info Command" Display parameters

Specific Information		
name	Type	Description
occupancy	Parameter type: <SignedInteger> - a signed integer	indicates the occupancy per slot of the bonding host function <i>This element is always shown.</i>

113.12 xDSL Bonding actual PTM Initialization Mode status command

Command Description

This command displays the xDSL Bonding actual PTM Initialization Mode effective on the system.

User Level

The command can be accessed by operators with xdsl privileges.

Command Syntax

The command has the following syntax:

```
> show xdsl-bonding actual-ptm-init-mode
```

Command Output

Table 113.12-2 "xDSL Bonding actual PTM Initialization Mode status command" Display parameters

Specific Information		
name	Type	Description
actual-ptm-init-mode	Parameter type: <Xdsl::BondingInitMode> (mode1 mode2) Possible values: - mode1 : Double initialization with probe-training - mode2 : Single initialization without probe-training	Actual PTM bonding initialization mode effective in the system <i>This element is always shown.</i>

114- PPPoE Status Commands

114.1 PPPoE Status Command Tree	114-5701
114.2 PPPoE Client Emulation Status Command	114-5702
114.3 PPPoE Interface Status Command	114-5706

114.1 PPPoE Status Command Tree

Description

This chapter gives an overview of nodes that are handled by "PPPoE Status Commands".

Command Tree

```
----show
  ----pppoe-client
    ----emulation
      - (ifindex)
      - client-id
    ----session
      - (ifindex)
```

114.2 PPPoE Client Emulation Status Command

Command Description

This command displays the PPPoE client emulation parameters, such as emulation state, and error code for failed PPPoE emulation.

User Level

The command can be accessed by operators with pppoe privileges.

Command Syntax

The command has the following syntax:

```
> show pppoe-client emulation [ (ifindex) [ client-id <PPPoE::ClientId> ] ]
```

Command Parameters

Table 114.2-1 "PPPoE Client Emulation Status Command" Resource Parameters

Resource Identifier	Type	Description
(ifindex)	Format: (vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::VpiId> : <Eqpt::VciId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::VpiId> : <Eqpt::VciId> : <Eqpt::UnstackedVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::UnstackedVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> / <Eqpt::OntPortId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> / <Eqpt::OntPortId> : <Eqpt::UnstackedVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / voip : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / vuni : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / voip :	interface index of the PPPoE client port

Resource Identifier	Type	Description
	<pre> <Eqpt::UnstackedVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / vuni : <Eqpt::UnstackedVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::LLId> : <Eqpt::UnstackedVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::LLId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan-port:ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / <Eqpt::Ng2OntSlotId> / <Eqpt::Ng2OntPortId> : <Eqpt::UnstackedVlan> vlan-port:ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / <Eqpt::Ng2OntSlotId> / <Eqpt::Ng2OntPortId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan-port:ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / vuni) Possible values: - vlan-port : vlan port - vlan-port:ng2 : an NGPON2 vlan port Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number Field type <Eqpt::VpiId> - atm VPI Field type <Eqpt::VciId> - atm VCI Field type <Eqpt::ChannelGroupId> - the channel group identifier Field type <Eqpt::SubChannelGroupId> - the subchannel group identifier Field type <Eqpt::PonId> - the PON identifier Field type <Eqpt::OntId> - the ONT identifier Field type <Eqpt::Ng2OntId> - the NG2 ONT identifier Possible values: - voip : virtual uni identifier obsolete alternative replaced by vuni - vuni : virtual uni identifier Possible values: - vuni : virtual NGPON2 uni identifier Field type <Eqpt::OntSlotId> - the ONT SLOT identifier Field type <Eqpt::OntPortId> - the ONT PORT identifier Field type <Eqpt::Ng2OntSlotId> - the NGPON2 ONT SLOT identifier </pre>	

Resource Identifier	Type	Description
	Field type <Eqpt::Ng2OntPortId> - the NGPON2 ONT PORT identifier Field type <Eqpt::LLId> - the LLID identifier, range 1 for EPON, range 1-8 for DPOE Possible values: - stacked : stacked vlan identity Field type <Eqpt::UnstackedVlan> - unstacked vlan id Field type <Eqpt::SVlan> - service vlan id Field type <Eqpt::CVlan> - customer vlan id	
client-id	Parameter type: <PPPoE::ClientId> Format: - the PPPoE client id - range: [1]	the PPPoE client id

Command Output

Table 114.2-2 "PPPoE Client Emulation Status Command" Display parameters

Specific Information		
name	Type	Description
state	Parameter type: <PPPoE::pppoeClientEmulationState> (initied ongoing failed succeeded stopped) Possible values: - initied : PPPoE emulation has never been executed since initialization - ongoing : emulation is in progress - failed : emulation failed - succeeded : emulation succeeded and PPPoE session established - stopped : PPPoE session has been terminated	the state of the PPPoE client emulation. <i>This element is always shown.</i>
error-code	Parameter type: <PPPoE::pppoeClientEmulationErrorCode> (none port-failure padi-timeout padr-timeout lcp-timeout auth-timeout auth-failure ncp-failure internal other onu-timeout onu-omci-failure) Possible values: - none : no errcode - port-failure : port-failure - padi-timeout : padi-timeout - padr-timeout : padr-timeout - lcp-timeout : lcp-timeout - auth-timeout : auth-timeout	the failure reason for failed PPPoE emulation. <i>This element is always shown.</i>

name	Type	Description
	- auth-failure : auth-failure - ncp-failure : ncp-failure - internal : internal err - other : other err - onu-timeout : onu-timeout - onu-omci-failure : onu-omci-failure	

114.3 PPPoE Interface Status Command

This command displays the PPPoE interface parameters.

Command Description

User Level

The command can be accessed by operators with pppoe privileges.

Command Syntax

The command has the following syntax:

```
> show pppoe-client session [ (ifindex) ]
```

Command Parameters

Table 114.3-1 "PPPoE Interface Status Command" Resource Parameters

Resource Identifier	Type	Description
(ifindex)	Format: (vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::VpiId> : <Eqpt::VciId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::VpiId> : <Eqpt::VciId> : <Eqpt::UnstackedVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::UnstackedVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> / <Eqpt::OntPortId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> / <Eqpt::OntPortId> : <Eqpt::UnstackedVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / voip : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / vuni : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / voip : <Eqpt::UnstackedVlan>	interface index of the PPP session

Resource Identifier	Type	Description
	vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / vuni : <Eqpt::UnstackedVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::LLId> : <Eqpt::UnstackedVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::LLId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan-port:ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / <Eqpt::Ng2OntSlotId> / <Eqpt::Ng2OntPortId> : <Eqpt::UnstackedVlan> vlan-port:ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / <Eqpt::Ng2OntSlotId> / <Eqpt::Ng2OntPortId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan-port:ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / vuni) Possible values: - vlan-port : vlan port - vlan-port:ng2 : an NGPON2 vlan port Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number Field type <Eqpt::VpId> - atm VPI Field type <Eqpt::VciId> - atm VCI Field type <Eqpt::ChannelGroupId> - the channel group identifier Field type <Eqpt::SubChannelGroupId> - the subchannel group identifier Field type <Eqpt::PonId> - the PON identifier Field type <Eqpt::OntId> - the ONT identifier Field type <Eqpt::Ng2OntId> - the NG2 ONT identifier Possible values: - voip : virtual uni identifier obsolete alternative replaced by vuni - vuni : virtual uni identifier Possible values: - vuni : virtual NGPON2 uni identifier Field type <Eqpt::OntSlotId> - the ONT SLOT identifier Field type <Eqpt::OntPortId> - the ONT PORT identifier Field type <Eqpt::Ng2OntSlotId> - the NGPON2 ONT SLOT identifier Field type <Eqpt::Ng2OntPortId>	

Resource Identifier	Type	Description
	- the NGPON2 ONT PORT identifier Field type <Eqpt::LLId> - the LLID identifier, range 1 for EPON, range 1-8 for DPOE Possible values: - stacked : stacked vlan identity Field type <Eqpt::UnstackedVlan> - unstacked vlan id Field type <Eqpt::SVlan> - service vlan id Field type <Eqpt::CVlan> - customer vlan id	

Command Output

Table 114.3-2 "PPPoE Interface Status Command" Display parameters

Specific Information		
name	Type	Description
ipv4-addr	Parameter type: <Ip::V4Address> - IPv4-address	IPv4 address of the system on which PPP connection is established. <i>This element is always shown.</i>
ipv6-addr	Parameter type: <Ip::V6Prefix> - IPv6-address	IPv6 address of the system on which PPP connection is established. <i>This element is always shown.</i>
mru	Parameter type: <PPPoE::PppProfileMru> - the MRU of PPP - range: [0...65535]	The MRU of the system link, on which PPPoE session is established. <i>This element is always shown.</i>

115- PPPoEL2 Statistics Status Commands

115.1 PPPoEL2 Statistics Status Command Tree	115-5710
115.2 PPPoEL2 Statistics Status Command	115-5711
115.3 PPPoEL2 detailed Statistics Status Command	115-5713
115.4 PPPoEL2 On-demand Statistics Status Command	115-5716

115.1 PPPoEL2 Statistics Status Command Tree

Description

This chapter gives an overview of nodes that are handled by "PPPoEL2 Statistics Status Commands".

Command Tree

```
----show
  ----pppoel2-stats
    - (user-port)
      ----vlan
        - (subscr-vlan)
          ----summary
          ----extensive
```


115.2 PPPoEL2 Statistics Status Command

Command Description

This command displays the detailed and summary (on-demand) PPPoE L2 packet statistics that are counted on vlan-port associated to a user interface.

User Level

The command can be accessed by operators with pppoe privileges.

Command Syntax

The command has the following syntax:

```
> show pppoel2-stats (user-port) vlan [ (subscr-vlan) ]
```

Command Parameters

Table 115.2-1 "PPPoEL2 Statistics Status Command" Resource Parameters

Resource Identifier	Type	Description
(user-port)	Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::VpiId> : <Eqpt::VciId> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> / <Eqpt::OntPortId> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / voip <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / vuni <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::LLId> ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / <Eqpt::Ng2OntSlotId> / <Eqpt::Ng2OntPortId> ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / vuni) Possible values: - ng2 : ngpon2 style identification Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId>	identification of the port

Resource Identifier	Type	Description
	- the port number - Field type <Eqpt::VpiId> - atm VPI - Field type <Eqpt::VciId> - atm VCI - Field type <Eqpt::ChannelGroupId> - the channel group identifier - Field type <Eqpt::SubChannelGroupId> - the subchannel group identifier - Field type <Eqpt::PonId> - the PON identifier - Field type <Eqpt::OntId> - the ONT identifier - Field type <Eqpt::Ng2OntId> - the NG2 ONT identifier - Possible values: - voip : virtual uni identifier - obsolete alternative replaced by vuni - vuni : virtual uni identifier - Possible values: - vuni : virtual NGPON2 uni identifier - Field type <Eqpt::OntSlotId> - the ONT SLOT identifier - Field type <Eqpt::OntPortId> - the ONT PORT identifier - Field type <Eqpt::Ng2OntSlotId> - the NGPON2 ONT SLOT identifier - Field type <Eqpt::Ng2OntPortId> - the NGPON2 ONT PORT identifier - Field type <Eqpt::LLId> - the LLID identifier, range 1 for EPON, range 1-8 for DPOE	
(subscr-vlan)	Format: (<Vlan::UVlanIndex> stacked : <Vlan::SVlanIndex> : <Vlan::CVlanIndex>) Possible values: - stacked : stacked vlan identity - Field type <Vlan::UVlanIndex> - unstacked vlan identity - range: [1...4093,4096] - Field type <Vlan::SVlanIndex> - service vlan identity - range: [2...4093] - Field type <Vlan::CVlanIndex> - customer vlan identity - range: [0...4093]	the subscriber vlan id

115.3 PPPoEL2 detailed Statistics Status

Command

Command Description

This command displays the detailed PPPoE L2 packet statistics that are counted on vlan-port associated to a user interface.

User Level

The command can be accessed by operators with pppoe privileges.

Command Syntax

The command has the following syntax:

```
> show pppoel2-stats (user-port) vlan (subscr-vlan) summary
```

Command Parameters

Table 115.3-1 "PPPoEL2 detailed Statistics Status Command" Resource Parameters

Resource Identifier	Type	Description
(user-port)	Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::VpiId> : <Eqpt::VciId> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> / <Eqpt::OntPortId> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / voip <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / vuni <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::LLId> ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / <Eqpt::Ng2OntSlotId> / <Eqpt::Ng2OntPortId> ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / vuni) Possible values: - ng2 : ngpon2 style identification Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number	identification of the port

Resource Identifier	Type	Description
	Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number Field type <Eqpt::VpiId> - atm VPI Field type <Eqpt::VciId> - atm VCI Field type <Eqpt::ChannelGroupId> - the channel group identifier Field type <Eqpt::SubChannelGroupId> - the subchannel group identifier Field type <Eqpt::PonId> - the PON identifier Field type <Eqpt::OntId> - the ONT identifier Field type <Eqpt::Ng2OntId> - the NG2 ONT identifier Possible values: - voip : virtual uni identifier obsolete alternative replaced by vuni - vuni : virtual uni identifier Possible values: - vuni : virtual NGPON2 uni identifier Field type <Eqpt::OntSlotId> - the ONT SLOT identifier Field type <Eqpt::OntPortId> - the ONT PORT identifier Field type <Eqpt::Ng2OntSlotId> - the NGPON2 ONT SLOT identifier Field type <Eqpt::Ng2OntPortId> - the NGPON2 ONT PORT identifier Field type <Eqpt::LLId> - the LLID identifier, range 1 for EPON, range 1-8 for DPOE	
(subscr-vlan)	Format: (<Vlan::UVlanIndex> stacked : <Vlan::SVlanIndex> : <Vlan::CVlanIndex>) Possible values: - stacked : stacked vlan identity Field type <Vlan::UVlanIndex> - unstacked vlan identity - range: [1...4093,4096] Field type <Vlan::SVlanIndex> - service vlan identity - range: [2...4093] Field type <Vlan::CVlanIndex> - customer vlan identity - range: [0...4093]	the subscriber vlan id

Command Output

Table 115.3-2 "PPPoEL2 detailed Statistics Status Command" Display parameters

Specific Information		
name	Type	Description
rx-error-count	Parameter type: <PPPoE::Counter> - an unsigned integer	total number of pppoe packet errors after the pppoe relay

name	Type	Description
		module received for upstream direction <i>This element is always shown.</i>
up-discovery-count	Parameter type: <PPPoE::Counter> - an unsigned integer	total number of pppoe discovery packet received from upstream direction <i>This element is always shown.</i>

115.4 PPPoEL2 On-demand Statistics Status Command

Command Description

This command displays the on-demand PPPoE L2 packet statistics that are counted on vlan-port associated to a user interface.

User Level

The command can be accessed by operators with pppoe privileges.

Command Syntax

The command has the following syntax:

```
> show pppoel2-stats (user-port) vlan (subscr-vlan) extensive
```

Command Parameters

Table 115.4-1 "PPPoEL2 On-demand Statistics Status Command" Resource Parameters

Resource Identifier	Type	Description
(user-port)	Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::VpiId> : <Eqpt::VciId> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> / <Eqpt::OntPortId> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / voip <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / vuni <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::LLId> ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / <Eqpt::Ng2OntSlotId> / <Eqpt::Ng2OntPortId> ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / vuni) Possible values: - ng2 : ngpon2 style identification Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number	identification of the port

Resource Identifier	Type	Description
	Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number Field type <Eqpt::VpiId> - atm VPI Field type <Eqpt::VciId> - atm VCI Field type <Eqpt::ChannelGroupId> - the channel group identifier Field type <Eqpt::SubChannelGroupId> - the subchannel group identifier Field type <Eqpt::PonId> - the PON identifier Field type <Eqpt::OntId> - the ONT identifier Field type <Eqpt::Ng2OntId> - the NG2 ONT identifier Possible values: - voip : virtual uni identifier obsolete alternative replaced by vuni - vuni : virtual uni identifier Possible values: - vuni : virtual NGPON2 uni identifier Field type <Eqpt::OntSlotId> - the ONT SLOT identifier Field type <Eqpt::OntPortId> - the ONT PORT identifier Field type <Eqpt::Ng2OntSlotId> - the NGPON2 ONT SLOT identifier Field type <Eqpt::Ng2OntPortId> - the NGPON2 ONT PORT identifier Field type <Eqpt::LLId> - the LLID identifier, range 1 for EPON, range 1-8 for DPOE	
(subscr-vlan)	Format: (<Vlan::UVlanIndex> stacked : <Vlan::SVlanIndex> : <Vlan::CVlanIndex>) Possible values: - stacked : stacked vlan identity Field type <Vlan::UVlanIndex> - unstacked vlan identity - range: [1...4093,4096] Field type <Vlan::SVlanIndex> - service vlan identity - range: [2...4093] Field type <Vlan::CVlanIndex> - customer vlan identity - range: [0...4093]	the subscriber vlan id

Command Output

Table 115.4-2 "PPPoEL2 On-demand Statistics Status Command" Display parameters

Specific Information		
name	Type	Description
rx-inv-version	Parameter type: <PPPoE::Counter> - an unsigned integer	total number of pppoe invalid header packets received. The

115 PPPoEL2 Statistics Status Commands

name	Type	Description
		value is incremented when the version field in pppoe header is not 0x1 in the discovery stage <i>This element is always shown.</i>
rx-inv-type	Parameter type: <PPPoE::Counter> - an unsigned integer	total number of pppoe invalid type packets received. The value is incremented when the type field in pppoe header is not 0x1 in the discovery stage <i>This element is always shown.</i>
rx-inv-code	Parameter type: <PPPoE::Counter> - an unsigned integer	total number of pppoe invalid code packets received. The value is incremented when the field in pppoe header is not either padi, pado, padr, pads in the discovery stage <i>This element is always shown.</i>
rx-inv-pl-length	Parameter type: <PPPoE::Counter> - an unsigned integer	total number packets received with invalid pppoe payload length <i>This element is always shown.</i>
rx-inv-tag-type	Parameter type: <PPPoE::Counter> - an unsigned integer	total number packets received with invalid tag length <i>This element is always shown.</i>
rx-inv-length	Parameter type: <PPPoE::Counter> - an unsigned integer	total number of generated pppoe discovery message is too long after insertion of the vendor specific tag <i>This element is always shown.</i>
dn-discovery-count	Parameter type: <PPPoE::Counter> - an unsigned integer	total number of pppoe discovery packet received from downstream direction <i>This element is always shown.</i>

116- Pon Status Commands

116.1 Pon Status Command Tree	116-5720
116.2 PON Bit Error Status Command	116-5722
116.3 Aggregate Pon Gem Port Current Interval Status Command	116-5724
116.4 Aggregate Pon Gem Port Previous Interval Status Command	116-5726
116.5 Multicast TC-layer Current Interval Performance Data Status Command	116-5728
116.6 Multicast TC-layer Previous Interval Performance Data Status Command	116-5730
116.7 Pon FEC Current Interval Status Command	116-5732
116.8 Pon Physical LayerCurrent Interval Status Command	116-5734
116.9 PON XGPON tc-layer Current Interval Status Command	116-5736
116.10 PON XGPON TC-layer Previous Interval Performance Data Status Command	116-5738
116.11 PON Optics Operational Information Status Command	116-5740
116.12 PON Software Download Status Command	116-5742
116.13 PON Optics Status Command	116-5744
116.14 PON Diagnostic Status Command	116-5746
116.15 Show Pon Unprovisioned Onu Command	116-5748
116.16 PON Configure File Download Status Command	116-5750
116.17 PON Utilization Current Interval PM Command	116-5752
116.18 PON Utilization Current Interval Top Five ONT Downstream PM Command	116-5756
116.19 PON Utilization Current Interval Top Five ONT Upstream PM Command	116-5758
116.20 PON Utilization Previous Interval PM Command	116-5760
116.21 PON Utilization Previous Interval Top Five ONT Downstream PM Command	116-5764
116.22 PON Utilization Previous Interval Top Five ONT Upstream PM Command	116-5766
116.23 PON Peak Utilization Current Interval PM Command	116-5768
116.24 PON Peak Utilization Current Interval Top Five ONT Downstream PM Command	116-5770
116.25 PON Peak Utilization Current Interval Top Five ONT Upstream PM Command	116-5772
116.26 PON Peak Utilization Previous Interval PM Command	116-5774
116.27 PON Peak Utilization Previous Interval Top Five ONT Downstream PM Command	116-5776
116.28 PON Peak Utilization Previous Interval Top Five ONT Upstream PM Command	116-5778

116.1 Pon Status Command Tree

Description

This chapter gives an overview of nodes that are handled by "Pon Status Commands".

Command Tree

```
----show
  ----pon
    ----ber-stats
      - (pon-idx)
      - ont-num
    ----interface
      ----tc-layer
        ----current-interval
          - (pon-idx)
        ----previous-interval
          - (pon-idx)
          - interval-nbr
      ----mcast-tc-layer
        ----current-interval
          - (pon-idx)
        ----previous-interval
          - (pon-idx)
          - interval-no
      ----fec-tc-layer
        ----current-interval
          - (pon-idx)
      ----phy-layer
        ----current-interval
          - (pon-idx)
      ----xg-tc-layer
        ----current-interval
          - (pon-idx)
        ----previous-interval
          - (pon-idx)
          - interval-no
    ----sfp-inventory
      - (pon-idx)
    ----sw-download
      - (pon-idx)
    ----optics
      - (pon-idx)
    ----pon-diagnostics
      - (index)
    ----unprovision-onu
      - (alarm-idx)
    ----cfg-download
      - (pon-idx)
    ----utilization
      ----current-interval
        - (pon-idx)
      ----cur-intvl-top-ont-tx
```

- (pon-idx)
- rank
- cur-intvl-top-ont-rx**
 - (pon-idx)
 - rank
- previous-interval**
 - (pon-idx)
 - interval-num
- prv-intvl-top-ont-tx**
 - (pon-idx)
 - interval-num
 - rank
- prv-intvl-top-ont-rx**
 - (pon-idx)
 - interval-num
 - rank
- peak-utilization**
 - current-interval**
 - (pon-idx)
 - cur-intvl-top-ont-tx**
 - (pon-idx)
 - rank
 - cur-intvl-top-ont-rx**
 - (pon-idx)
 - rank
 - previous-interval**
 - (pon-idx)
 - interval-num
 - prv-intvl-top-ont-tx**
 - (pon-idx)
 - interval-num
 - rank
 - prv-intvl-top-ont-rx**
 - (pon-idx)
 - interval-num
 - rank

116.2 PON Bit Error Status Command

Command Description

This command reports a summary of current operational parameters for a specified PON.

For each PON matched and for each ONT on that PON, the following response is presented

Bit Error Count in Downstream Direction

Bit Error Count in Upstream Direction

Indication that the ONT is currently Ranged

User Level

The command can be accessed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

```
> show pon ber-stats [ (pon-idx) [ ont-num <Gpon::OntNum> ] ]
```

Command Parameters

Table 116.2-1 "PON Bit Error Status Command" Resource Parameters

Resource Identifier	Type	Description
(pon-idx)	Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> x-pon : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::XPonId> 25g-pon : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::M25GPonId>) Possible values: - 25g-pon : 25g pon - x-pon : Xgs pon Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Eqpt::XPonId> - the XGS PON identifier Field type <Eqpt::M25GPonId> - the 25G PON identifier	ifindex of pon
ont-num	Parameter type: <Gpon::OntNum>	number of the ont on the pon

Resource Identifier	Type	Description
	Format: - number of the ONT on the PON - range: [1...128]	

Command Output

Table 116.2-2 "PON Bit Error Status Command" Display parameters

Specific Information		
name	Type	Description
bit-err-down	Parameter type: <Gpon::Counter> (n/a <Counter>) Possible values: - n/a : olt has not yet support Field type <Counter> - 32 bit counter	number of downstream bit error counts for an ont. <i>This element is always shown.</i>
bit-err-up	Parameter type: <Gpon::Counter> (n/a <Counter>) Possible values: - n/a : olt has not yet support Field type <Counter> - 32 bit counter	number of upstream bit error counts for an ont <i>This element is always shown.</i>
ranged-ind	Parameter type: <Gpon::RangedInd> (not-ranged ranged manually-disabled auto-disabled) Possible values: - not-ranged : this ont is not ranged (and not disabled) - ranged : this ont is ranged - manually-disabled : this ont is manually-disabled (by the operator) - auto-disabled : enable port-to-port traffic exchange	indicates whether this ont is currently ranged or not <i>This element is always shown.</i>

116.3 Aggregate Pon Gem Port Current Interval Status Command

Command Description

Current interval table contains various statistics collected for aggregate PON GEM ports (from OLT side of the PON) in the current 15 minutes interval.

User Level

The command can be accessed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

```
> show pon interface tc-layer current-interval [ (pon-idx) ]
```

Command Parameters

Table 116.3-1 "Aggregate Pon Gem Port Current Interval Status Command" Resource Parameters

Resource Identifier	Type	Description
(pon-idx)	Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> x-pon : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::XPonId> 25g-pon : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::M25GPonId>) Possible values: - 25g-pon : 25g pon - x-pon : Xgs pon Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Eqpt::XPonId> - the XGS PON identifier Field type <Eqpt::M25GPonId> - the 25G PON identifier	ifindex of the pon

Command Output

Table 116.3-2 "Aggregate Pon Gem Port Current Interval Status Command" Display parameters

Specific Information		
name	Type	Description
err-frags-up	Parameter type: <Counter> - 32 bit counter	a count of errored gem fragments (upstream) <i>This element is always shown.</i>

116.4 Aggregate Pon Gem Port Previous Interval Status Command

Command Description

Previous interval table contains various statistics collected for aggregate PON GEM ports (from OLT side of the PON) over the previous 8 hours of operation.

The past 8 hours are broken into 32 completed 15 minute intervals. Each row in this table represents one such interval.

User Level

The command can be accessed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

```
> show pon interface tc-layer previous-interval [ (pon-idx) [ interval-nbr <Gpon::GemPortInterval> ] ]
```

Command Parameters

Table 116.4-1 "Aggregate Pon Gem Port Previous Interval Status Command" Resource Parameters

Resource Identifier	Type	Description
(pon-idx)	Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> x-pon : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::XPonId> 25g-pon : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::M25GPonId>) Possible values: - 25g-pon : 25g pon - x-pon : Xgs pon Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Eqpt::XPonId> - the XGS PON identifier Field type <Eqpt::M25GPonId> - the 25G PON identifier	ifindex of the pon

Resource Identifier	Type	Description
interval-nbr	Parameter type: <Gpon::GemPortInterval> Format: - time interval interms of 15 mins - range: [1...32]	aggregate gem port interval number

Command Output

Table 116.4-2 "Aggregate Pon Gem Port Previous Interval Status Command" Display parameters

Specific Information		
name	Type	Description
err-frags-up	Parameter type: <Counter> - 32 bit counter	a count of errored gem fragments (upstream) <i>This element is always shown.</i>

116.5 Multicast TC-layer Current Interval Performance Data Status Command

Command Description

This command displays various statistics collected for OLT-side Multicast TC-layer during the current 15 minute interval of operation.

User Level

The command can be accessed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

```
> show pon interface mcast-tc-layer current-interval [ (pon-idx) ]
```

Command Parameters

Table 116.5-1 "Multicast TC-layer Current Interval Performance Data Status Command" Resource Parameters

Resource Identifier	Type	Description
(pon-idx)	Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> x-pon : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::XPonId> 25g-pon : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::M25GPonId>) Possible values: - 25g-pon : 25g pon - x-pon : Xgs pon Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Eqpt::XPonId> - the XGS PON identifier Field type <Eqpt::M25GPonId> - the 25G PON identifier	pon index

Command Output

Table 116.5-2 "Multicast TC-layer Current Interval Performance Data Status Command" Display parameters

Specific Information		
name	Type	Description
transmit-blocks	Parameter type: <Counter> - 32 bit counter	count of transmitted gem blocks on gem 4095 <i>This element is always shown.</i>
transmit-frags	Parameter type: <Counter> - 32 bit counter	count of transmitted gem fragments on gem 4095 <i>This element is always shown.</i>

116.6 Multicast TC-layer Previous Interval Performance Data Status Command

Command Description

This command displays various statistics collected for OLT-side Multicast TC-layer over the previous 8 hours of operations which is broken in to 32 completed 15 minute intervals.

User Level

The command can be accessed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

```
> show pon interface mcast-tc-layer previous-interval [ (pon-idx) [ interval-no <Gpon::IntervalNo> ] ]
```

Command Parameters

Table 116.6-1 "Multicast TC-layer Previous Interval Performance Data Status Command" Resource Parameters

Resource Identifier	Type	Description
(pon-idx)	Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> x-pon : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::XPonId> 25g-pon : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::M25GPonId>) Possible values: - 25g-pon : 25g pon - x-pon : Xgs pon Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Eqpt::XPonId> - the XGS PON identifier Field type <Eqpt::M25GPonId> - the 25G PON identifier	pon index
interval-no	Parameter type: <Gpon::IntervalNo> Format:	identifies prev 15min intvls, val 1 as the latest intvl

Resource Identifier	Type	Description
	- a number of a previous interval number - range: [1...32]	

Command Output

Table 116.6-2 "Multicast TC-layer Previous Interval Performance Data Status Command" Display parameters

Specific Information		
name	Type	Description
transmit-blocks	Parameter type: <Counter> - 32 bit counter	count of transmitted gem blocks on gem 4095 <i>This element is always shown.</i>
transmit-frags	Parameter type: <Counter> - 32 bit counter	count of transmitted gem fragments on gem 4095 <i>This element is always shown.</i>

116.7 Pon FEC Current Interval Status Command

Command Description

Current interval table contains various FEC counters collected for XGPON ports (from OLT side of the PON) in the current 15 minutes interval.

User Level

The command can be accessed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

> show pon interface fec-tc-layer current-interval [(pon-idx)]

Command Parameters

Table 116.7-1 "Pon FEC Current Interval Status Command" Resource Parameters

Resource Identifier	Type	Description
(pon-idx)	Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> x-pon : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::XPonId> 25g-pon : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::M25GPonId>) Possible values: - 25g-pon : 25g pon - x-pon : Xgs pon Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Eqpt::XPonId> - the XGS PON identifier Field type <Eqpt::M25GPonId> - the 25G PON identifier	ont index

Command Output

Table 116.7-2 "Pon FEC Current Interval Status Command" Display parameters

Specific Information

name	Type	Description
corrected-bytes	Parameter type: <OctetCounter64> - 64 bit counter,range:[0-9223372036854775808]	A count of number of bytes that were corrected by the FEC function <i>This element is always shown.</i>
corrected-code-words	Parameter type: <Counter> - 32 bit counter	A count of number of code words that were corrected by the FEC function. <i>This element is always shown.</i>
uncorrected-words	Parameter type: <Counter> - 32 bit counter	A count of number of errored code words that could not be corrected by the FEC function. <i>This element is always shown.</i>
total-code-words	Parameter type: <Counter> - 32 bit counter	A count of total number of received code words. <i>This element is always shown.</i>

116.8 Pon Physical LayerCurrent Interval Status Command

Command Description

Current interval table contains various physical layer counters collected for XGPON ports (from OLT side of the PON) in the current 15 minutes interval.

User Level

The command can be accessed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

```
> show pon interface phy-layer current-interval [ (pon-idx) ]
```

Command Parameters

Table 116.8-1 "Pon Physical LayerCurrent Interval Status Command" Resource Parameters

Resource Identifier	Type	Description
(pon-idx)	Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> x-pon : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::XPonId> 25g-pon : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::M25GPonId>) Possible values: - 25g-pon : 25g pon - x-pon : Xgs pon Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Eqpt::XPonId> - the XGS PON identifier Field type <Eqpt::M25GPonId> - the 25G PON identifier	ont index

Command Output

Table 116.8-2 "Pon Physical LayerCurrent Interval Status Command" Display parameters

Specific Information		
name	Type	Description
bip32-prot-words	Parameter type: <OctetCounter64> - 64 bit counter,range:[0-9223372036854775808]	A count of total number of BIP32 words on physical PON <i>This element is always shown.</i>
bip32-bit-errors	Parameter type: <OctetCounter64> - 64 bit counter,range:[0-9223372036854775808]	A count of number of BIP32 errors on physical PON. <i>This element is always shown.</i>

116.9 PON XGPON tc-layer Current Interval Status Command

Command Description

Current interval table contains XGPON tc-layer counters collected for XGPON ports (from OLT side of the PON) in the current 15 minutes interval.

User Level

The command can be accessed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

```
> show pon interface xg-tc-layer current-interval [ (pon-idx) ]
```

Command Parameters

Table 116.9-1 "PON XGPON tc-layer Current Interval Status Command" Resource Parameters

Resource Identifier	Type	Description
(pon-idx)	Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> x-pon : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::XPonId> 25g-pon : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::M25GPonId>) Possible values: - 25g-pon : 25g pon - x-pon : Xgs pon Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Eqpt::XPonId> - the XGS PON identifier Field type <Eqpt::M25GPonId> - the 25G PON identifier	ont index

Command Output

Table 116.9-2 "PON XGPON tc-layer Current Interval Status Command" Display parameters

Specific Information		
name	Type	Description
rng-time-msgs	Parameter type: <Counter> - 32 bit counter	A count of number of ranging time messages that were sent on this PON. <i>This element is always shown.</i>

116.10 PON XGPON TC-layer Previous Interval Performance Data Status Command

Command Description

This command displays XGPON tc-layer counters collected for XGPON ports (from OLT side of the PON) over the previous 8 hours of operations which is broken in to 32 completed 15 minute intervals.

User Level

The command can be accessed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

```
> show pon interface xg-tc-layer previous-interval [ (pon-idx) [ interval-no <Gpon::IntervalNo> ] ]
```

Command Parameters

Table 116.10-1 "PON XGPON TC-layer Previous Interval Performance Data Status Command" Resource Parameters

Resource Identifier	Type	Description
(pon-idx)	Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> x-pon : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::XPonId> 25g-pon : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::M25GPonId>) Possible values: - 25g-pon : 25g pon - x-pon : Xgs pon Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Eqpt::XPonId> - the XGS PON identifier Field type <Eqpt::M25GPonId> - the 25G PON identifier	ont index
interval-no	Parameter type: <Gpon::IntervalNo> Format:	identifies prev 15min intvls, val 1 as the latest intvl

Resource Identifier	Type	Description
	- a number of a previous interval number - range: [1...32]	

Command Output

Table 116.10-2 "PON XGPON TC-layer Previous Interval Performance Data Status Command"
Display parameters

Specific Information		
name	Type	Description
rng-time-msgs	Parameter type: <Counter> - 32 bit counter	A count of number of ranging time messages that were sent on this PON. <i>This element is always shown.</i>

116.11 PON Optics Operational Information Status Command

Command Description

OLT-SIDE current operational information regarding a PON (primarily optical transmit levels and laser parameters).

The content of the special feature register is reflected in the display parameters with the specific information name "otdr". In case the spf is otdr capable, "yes" is reflected. All other special feature values are mapped to "no".

User Level

The command can be accessed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

```
> show pon sfp-inventory [ (pon-idx) ]
```

Command Parameters

Table 116.11-1 "PON Optics Operational Information Status Command" Resource Parameters

Resource Identifier	Type	Description
(pon-idx)	Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> x-pon : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::XPonId> 25g-pon : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::M25GPonId>) Possible values: - 25g-pon : 25g pon - x-pon : Xgs pon Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Eqpt::XPonId> - the XGS PON identifier Field type <Eqpt::M25GPonId> - the 25G PON identifier	ifindex of pon

Command Output

Table 116.11-2 "PON Optics Operational Information Status Command" Display parameters

Specific Information		
name	Type	Description
sfp-vendor	Parameter type: <Gpon::OpVendorName> - printable string	vendor name associated with the optics module for this pon <i>This element is always shown.</i>
part-num	Parameter type: <Gpon::OpPartNumber> - printable string	model part number associated with the optics module for this pon <i>This element is always shown.</i>
serial-num	Parameter type: <Gpon::OpSerialNumber> - printable string	serial number associated with the optics module for this pon <i>This element is always shown.</i>
mfg-date	Parameter type: <Gpon::OpMfgDateCode> - printable string	manufacturing date code associated with the optics module for this pon <i>This element is always shown.</i>
otdr	Parameter type: <Gpon::OpSpecFeat> (yes no) Possible values: - yes : sfp is otdr capable - no : sfp is not otdr capable	special features supported by the sfp <i>This element is always shown.</i>

116.12 PON Software Download Status Command

Command Description

Shows individual PON fine-grain status associated with any SW download activity.

User Level

The command can be accessed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

> show pon sw-download [(pon-idx)]

Command Parameters

Table 116.12-1 "PON Software Download Status Command" Resource Parameters

Resource Identifier	Type	Description
(pon-idx)	Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> x-pon : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::XPonId> 25g-pon : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::M25GPonId>) Possible values: - 25g-pon : 25g pon - x-pon : Xgs pon Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Eqpt::XPonId> - the XGS PON identifier Field type <Eqpt::M25GPonId> - the 25G PON identifier	ifindex of the pon

Command Output

Table 116.12-2 "PON Software Download Status Command" Display parameters

Specific Information

116 Pon Status Commands

name	Type	Description
status	Parameter type: <Gpon::SwDownloadStatus> - pon software download status	software download status <i>This element is always shown.</i>

116.13 PON Optics Status Command

Command Description

User Level

The command can be accessed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

```
> show pon optics [ (pon-idx) ]
```

Command Parameters

Table 116.13-1 "PON Optics Status Command" Resource Parameters

Resource Identifier	Type	Description
(pon-idx)	Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> x-pon : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::XPonId> 25g-pon : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::M25GPonId>) Possible values: - 25g-pon : 25g pon - x-pon : Xgs pon Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Eqpt::XPonId> - the XGS PON identifier Field type <Eqpt::M25GPonId> - the 25G PON identifier	access identifier for the pon

Command Output

Table 116.13-2 "PON Optics Status Command" Display parameters

Specific Information		
name	Type	Description
olt-tx-signal-lvl	Parameter type: <Gpon::OltOpticalSignalLevel>	this attribute indicates the current

name	Type	Description
	(invalid not-supported <Gpon::OltOpticalSignalLevel>) Possible values: - invalid : a valid measurement is currently unattainable for some reason - not-supported : the measurement functionality is not supported by this particular unit Field type <Gpon::OltOpticalSignalLevel> - olt optical signal level - unit: db - range: [-30.0...6553.5]	level of the olt's transmit optical signal. <i>This element is always shown.</i>
olt-temperature	Parameter type: <Gpon::OltTemperature> (invalid not-supported <Gpon::OltTemperature>) Possible values: - invalid : a valid measurement is currently unattainable for some reason - not-supported : the measurement functionality is not supported by this particular unit Field type <Gpon::OltTemperature> - temperature of olt optical module - unit: degree C - range: [-655.35...655.35]	this attribute indicates the current level of the olt's transmit optical signal <i>This element is always shown.</i>
olt-voltage	Parameter type: <Gpon::OltVoltage> (invalid not-supported <Gpon::OltVoltage>) Possible values: - invalid : a valid measurement is currently unattainable for some reason - not-supported : the measurement functionality is not supported by this particular unit Field type <Gpon::OltVoltage> - power feed voltage of olt optical module - unit: Volts - range: [0...655.35]	this attribute indicates the current voltage of the optics module associated with this pon. <i>This element is always shown.</i>
olt-laser-curr	Parameter type: <Gpon::OltLaserBias> (invalid not-supported <Gpon::OltLaserBias>) Possible values: - invalid : a valid measurement is currently unattainable for some reason - not-supported : the measurement functionality is not supported by this particular unit Field type <Gpon::OltLaserBias> - indicates the current bias current of the laser - unit: mA - range: [0...65535]	this attribute indicates the current bias current of the laser associated with this pon. <i>This element is always shown.</i>

116.14 PON Diagnostic Status Command

Command Description

This command reports a summary of current background Diagnostic Tests for specified PON.

For each PON matched , the following response is presented

Background Stuck Laser Rogue Test

Background Pattern Rogue Test

Background Rogue Test Interval

User Level

The command can be accessed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

```
> show pon pon-diagnostics [ (index) ]
```

Command Parameters

Table 116.14-1 "PON Diagnostic Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> x-pon : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::XPonId> 25g-pon : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::M25GPonId>) Possible values: - 25g-pon : 25g pon - x-pon : Xgs pon Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Eqpt::XPonId> - the XGS PON identifier Field type <Eqpt::M25GPonId> - the 25G PON identifier	ifindex of pon

Command Output

Table 116.14-2 "PON Diagnostic Status Command" Display parameters

Specific Information		
name	Type	Description
bkg-stucklaser-test	Parameter type: <Gpon::BkgdRogueDispEnableDisable> (stopped initiated) Possible values: - stopped : background test is stopped - initiated : background test is initiated	background stuck laser test. <i>This element is always shown.</i>
bkg-pattern-test	Parameter type: <Gpon::BkgdRogueDispEnableDisable> (stopped initiated) Possible values: - stopped : background test is stopped - initiated : background test is initiated	background pattern test. <i>This element is always shown.</i>
bkg-roguetest-interval	Parameter type: <SignedInteger> - a signed integer	Frequency of background rogue ont test execution in units of minutes <i>This element is always shown.</i>
bkg-alien-test	Parameter type: <Gpon::BkgdRogueDispEnableDisable> (stopped initiated) Possible values: - stopped : background test is stopped - initiated : background test is initiated	background alien test. <i>This element is always shown.</i>
bkg-alientest-interval	Parameter type: <Gpon::BkgdAlienTestInterval> - Numbers divisible by 30 are permitted. - unit: Minutes - range: [30...240]	Frequency of background alien ont test execution in units of minutes <i>This element is always shown.</i>

116.15 Show Pon Unprovisioned Onu Command

Command Description

This command displays the pon unprovisioned onu.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show pon unprovision-onu [ (alarm-idx) ]
```

Command Parameters

Table 116.15-1 " Show Pon Unprovisioned Onu Command" Resource Parameters

Resource Identifier	Type	Description
(alarm-idx)	Format: - index of a current alarm entry	current alarm index

Command Output

Table 116.15-2 " Show Pon Unprovisioned Onu Command" Display parameters

Specific Information		
name	Type	Description
gpon-index	Parameter type: <Gpon::PonId> (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> x-pon : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::XPonId> 25g-pon : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::M25GPonId>) Possible values: - 25g-pon : 25g pon - x-pon : Xgs pon Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Eqpt::XPonId> - the XGS PON identifier	identifies the epon where the alarm has occurred. <i>This element is always shown.</i>

name	Type	Description
	Field type <Eqpt::M25GPonId> - the 25G PON identifier	
newont-index	Parameter type: <SignedInteger> - a signed integer	the newonu index for the pon alarm <i>This element is only shown in detail mode.</i>
sernum	Parameter type: <Gpon::SerNum1> - serv num - length: 12	new ONT Serial Num <i>This element is always shown.</i>
subscriber-locid	Parameter type: <Gpon::SubsLocId> - subsloc id, 0 to 12 (36 for ngpon2/xgs/25g) ASCII character string or 0 to 24 (72 for ngpon2/xgs/25g) HEX string depending on slidmode - length: x<=72	new ONT Subscriber Location ID <i>This element is always shown.</i>
logical-authid	Parameter type: <Gpon::LogAuthId> - ont logical id - length: x<=24	new ONT logical AuthId <i>This element is always shown.</i>
actual-us-rate	Parameter type: <Gpon::ActualUsRate> (2.5g 10g 1.25g 25g) Possible values: - : unknown - 2.5g : 2.5 GBit/sec - 10g : 10 GBit/sec - 1.25g : 1.25 GBit/sec - 25g : 25 GBit/sec	new ONT actual upstream rate <i>This element is always shown.</i>
equip-id	Parameter type: <Gpon::EquipId> - ont equip Id - length: x<=20	new ONT Equipment Id <i>This element is only shown in detail mode.</i>

116.16 PON Configure File Download Status Command

Command Description

Show individual PON fine-grain status associated with any configure file download activity.

User Level

The command can be accessed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

```
> show pon cfg-download [ (pon-idx) ]
```

Command Parameters

Table 116.16-1 "PON Configure File Download Status Command" Resource Parameters

Resource Identifier	Type	Description
(pon-idx)	Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> x-pon : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::XPonId> 25g-pon : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::M25GPonId>) Possible values: - 25g-pon : 25g pon - x-pon : Xgs pon Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Eqpt::XPonId> - the XGS PON identifier Field type <Eqpt::M25GPonId> - the 25G PON identifier	ifindex of the pon

Command Output

Table 116.16-2 "PON Configure File Download Status Command" Display parameters

Specific Information		
name	Type	Description
cfgfile1-status	Parameter type: <Gpon::cfgDownloadStatus> - pon configure file download status	configure file 1 download status <i>This element is always shown.</i>
cfgfile2-status	Parameter type: <Gpon::cfgDownloadStatus> - pon configure file download status	configure file 2 download status <i>This element is always shown.</i>

116.17 PON Utilization Current Interval PM Command

Command Description

This command retrieves PON utilization current interval performance monitoring data.

User Level

The command can be accessed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

> show pon utilization current-interval [(pon-idx)]

Command Parameters

Table 116.17-1 "PON Utilization Current Interval PM Command" Resource Parameters

Resource Identifier	Type	Description
(pon-idx)	Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> x-pon : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::XPonId> 25g-pon : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::M25GPonId>) Possible values: - 25g-pon : 25g pon - x-pon : Xgs pon Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Eqpt::XPonId> - the XGS PON identifier Field type <Eqpt::M25GPonId> - the 25G PON identifier	ifindex of the pon

Command Output

Table 116.17-2 "PON Utilization Current Interval PM Command" Display parameters

Specific Information		
name	Type	Description
txtotutil	Parameter type: <Gpon::FloatPonUtilPercent> - utilization percentage - unit: percentage - range: [0.00...100.00]	transmit (downstream) total utilization (percentage) relative to the total bandwidth <i>This element is always shown.</i>
txbcutil	Parameter type: <Gpon::FloatPonUtilThousandPercent> - utilization percentage - unit: percentage - range: [0.00...1000.00]	transmit (downstream) broadcast utilization (percentage) relative to the non-multicast bandwidth [because the broadcast bandwidth can exceed the non-multicast bandwidth, this value can exceed 100%] <i>This element is always shown.</i>
txmcutil	Parameter type: <Gpon::FloatPonUtilPercent> - utilization percentage - unit: percentage - range: [0.00...100.00]	transmit (downstream) multicast utilization (percentage) relative to the configured multicast bandwidth <i>This element is always shown.</i>
txucutil	Parameter type: <Gpon::FloatPonUtilThousandPercent> - utilization percentage - unit: percentage - range: [0.00...1000.00]	transmit (downstream) unicast utilization (percentage) relative to the non-multicast bandwidth [because the unicast bandwidth can exceed the non-multicast bandwidth, this value can exceed 100%] <i>This element is always shown.</i>
dbacongperiod	Parameter type: <Gpon::FloatPonUtilDbapercent> - utilization percentage - unit: percentage - range: [0.00...100.00]	dba (upstream) congestion period (percentage) [the percentage of the dba granting windows in which the dba congestion threshold was exceeded] <i>This element is always shown.</i>
rxtotutil	Parameter type: <Gpon::FloatPonUtilPercent> - utilization percentage - unit: percentage - range: [0.00...100.00]	receive (upstream) total utilization (percentage) relative to the total bandwidth <i>This element is always shown.</i>

Only Show Details: transmitted/received counts		
name	Type	Description
txtotbyte	Parameter type: <OctetCounter64> - 64 bit counter,range:[0-9223372036854775808]	total number of bytes transmitted on the pon (downstream) <i>This element is only shown in detail mode.</i>
txbcbyte	Parameter type: <OctetCounter64> - 64 bit counter,range:[0-9223372036854775808]	number of broadcast bytes transmitted on the pon (downstream) <i>This element is only shown in detail mode.</i>
txmcbyte	Parameter type: <OctetCounter64> - 64 bit counter,range:[0-9223372036854775808]	total number of multicast bytes transmitted on the pon (downstream) <i>This element is only shown in detail mode.</i>
txucbyte	Parameter type: <OctetCounter64> - 64 bit counter,range:[0-9223372036854775808]	number of unicast bytes transmitted on the pon

116 Pon Status Commands

name	Type	Description
		(downstream) <i>This element is only shown in detail mode.</i>
rxatotbyte	Parameter type: <OctetCounter64> - 64 bit counter,range:[0-9223372036854775808]	total number of bytes transmitted on the pon (downstream) <i>This element is only shown in detail mode.</i>
txtotfrm	Parameter type: <OctetCounter64> - 64 bit counter,range:[0-9223372036854775808]	total number of packets transmitted on the pon (downstream) <i>This element is only shown in detail mode.</i>
txbcfrm	Parameter type: <OctetCounter64> - 64 bit counter,range:[0-9223372036854775808]	number of broadcast packets transmitted on the pon (downstream) <i>This element is only shown in detail mode.</i>
txmcfrm	Parameter type: <OctetCounter64> - 64 bit counter,range:[0-9223372036854775808]	number of multicast packets transmitted on the pon (downstream) <i>This element is only shown in detail mode.</i>
txucfrm	Parameter type: <OctetCounter64> - 64 bit counter,range:[0-9223372036854775808]	number of unicast packets transmitted on the pon (downstream) <i>This element is only shown in detail mode.</i>
rxtotfrm	Parameter type: <OctetCounter64> - 64 bit counter,range:[0-9223372036854775808]	total number of packets received on the pon (upstream) <i>This element is only shown in detail mode.</i>

Only Show Details: dropped counts		
name	Type	Description
txtotdropbyte	Parameter type: <OctetCounter64> - 64 bit counter,range:[0-9223372036854775808]	total number of bytes dropped destined for the pon (downstream) <i>This element is only shown in detail mode.</i>
txbcdropbyte	Parameter type: <OctetCounter64> - 64 bit counter,range:[0-9223372036854775808]	number of bytes dropped destined for the pon (downstream) <i>This element is only shown in detail mode.</i>
txmcdropbyte	Parameter type: <OctetCounter64> - 64 bit counter,range:[0-9223372036854775808]	number of broadcast bytes dropped destined for the pon (downstream) <i>This element is only shown in detail mode.</i>
txucdropbyte	Parameter type: <OctetCounter64> - 64 bit counter,range:[0-9223372036854775808]	number of unicast bytes dropped destined for the pon (downstream) <i>This element is only shown in detail mode.</i>
rxtotdropbyte	Parameter type: <OctetCounter64> - 64 bit counter,range:[0-9223372036854775808]	total number of bytes dropped received on the pon (downstream) <i>This element is only shown in detail mode.</i>

name	Type	Description
txtotdropfrm	Parameter type: <OctetCounter64> - 64 bit counter,range:[0-9223372036854775808]	total number of packets dropped destined for the pon (downstream) <i>This element is only shown in detail mode.</i>
txbcdropfrm	Parameter type: <OctetCounter64> - 64 bit counter,range:[0-9223372036854775808]	number of broadcast packets dropped destined for the pon (downstream) <i>This element is only shown in detail mode.</i>
txmcdropfrm	Parameter type: <OctetCounter64> - 64 bit counter,range:[0-9223372036854775808]	number of multicast packets dropped destined for the pon (downstream) <i>This element is only shown in detail mode.</i>
txucdropfrm	Parameter type: <OctetCounter64> - 64 bit counter,range:[0-9223372036854775808]	number of unicast packets dropped destined for the pon (downstream) <i>This element is only shown in detail mode.</i>
rxtotdropfrm	Parameter type: <OctetCounter64> - 64 bit counter,range:[0-9223372036854775808]	total number of packets dropped destined for the pon (downstream) <i>This element is only shown in detail mode.</i>

Only Show Details: number of active onts on pon

name	Type	Description
numactiveonts	Parameter type: <Gpon::NumActiveOnt> - number of active onts that carry atleast a minimum amount of traffic - range: [0...128]	number of active ONTs on the PON (carrying more than a minimum amount of traffic) <i>This element is only shown in detail mode.</i>

116.18 PON Utilization Current Interval Top Five ONT Downstream PM Command

Command Description

This command retrieves the top 5 ONTs on the PON ranked by downstream traffic for the current interval.

User Level

The command can be accessed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

```
> show pon utilization cur-intvl-top-ont-tx [ (pon-idx) [ rank <Gpon::PonUtilOntRank> ] ]
```

Command Parameters

Table 116.18-1 "PON Utilization Current Interval Top Five ONT Downstream PM Command" Resource Parameters

Resource Identifier	Type	Description
(pon-idx)	Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> x-pon : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::XPonId> 25g-pon : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::M25GPonId>) Possible values: - 25g-pon : 25g pon - x-pon : Xgs pon Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Eqpt::XPonId> - the XGS PON identifier Field type <Eqpt::M25GPonId> - the 25G PON identifier	ifindex of the pon
rank	Parameter type: <Gpon::PonUtilOntRank> Format: - rank of the ont	rank of the ont within the pon

Resource Identifier	Type	Description
	- range: [1...5]	

Command Output

Table 116.18-2 "PON Utilization Current Interval Top Five ONT Downstream PM Command"
Display parameters

Specific Information		
name	Type	Description
ont-idx	Parameter type: <Gpon::OntIndex> (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> ng2 : <Ng2::ChannelGroup> / <Ng2::SubchannelGroup> / <Ng2::OntId>) Possible values: - ng2 : ngpon2 style identification Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Ng2::ChannelGroup> - channel group number Field type <Ng2::SubchannelGroup> - subchannel group number Field type <Eqpt::OntId> - the ONT identifier Field type <Ng2::OntId> - the ONT identifier	ont-index of the particular ont <i>This element is always shown.</i>
txucutil	Parameter type: <Gpon::FloatPonUtilThousandPercent> - utilization percentage - unit: percentage - range: [0.00...1000.00]	transmit (downstream) unicast utilization (percentage) relative to the non-multicast pon bandwidth [because the unicast bandwidth can exceed the non-multicast bandwidth, this value can exceed 100%] <i>This element is always shown.</i>

116.19 PON Utilization Current Interval Top Five ONT Upstream PM Command

Command Description

This command retrieves the top 5 ONTs on the PON ranked by upstream traffic for the current interval.

User Level

The command can be accessed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

```
> show pon utilization cur-intvl-top-ont-rx [ (pon-idx) [ rank <Gpon::PonUtilOntRank> ] ]
```

Command Parameters

Table 116.19-1 "PON Utilization Current Interval Top Five ONT Upstream PM Command" Resource Parameters

Resource Identifier	Type	Description
(pon-idx)	Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> x-pon : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::XPonId> 25g-pon : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::M25GPonId>) Possible values: - 25g-pon : 25g pon - x-pon : Xgs pon Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Eqpt::XPonId> - the XGS PON identifier Field type <Eqpt::M25GPonId> - the 25G PON identifier	ifindex of the pon
rank	Parameter type: <Gpon::PonUtilOntRank> Format: - rank of the ont	rank of the ont within the pon

Resource Identifier	Type	Description
	- range: [1...5]	

Command Output

**Table 116.19-2 "PON Utilization Current Interval Top Five ONT Upstream PM Command"
Display parameters**

Specific Information		
name	Type	Description
ont-idx	Parameter type: <Gpon::OntIndex> (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> ng2 : <Ng2::ChannelGroup> / <Ng2::SubchannelGroup> / <Ng2::OntId>) Possible values: - ng2 : ngpon2 style identification Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Ng2::ChannelGroup> - channel group number Field type <Ng2::SubchannelGroup> - subchannel group number Field type <Eqpt::OntId> - the ONT identifier Field type <Ng2::OntId> - the ONT identifier	ont-index of the particular ont <i>This element is always shown.</i>
rxucutil	Parameter type: <Gpon::FloatPonUtilPercent> - utilization percentage - unit: percentage - range: [0.00...100.00]	receive (upstream) unicast utilization (percentage) relative to total pon bandwidth <i>This element is always shown.</i>

116.20 PON Utilization Previous Interval PM Command

Command Description

This command retrieves PON utilization previous interval performance monitoring data.

User Level

The command can be accessed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

```
> show pon utilization previous-interval [ (pon-idx) [ interval-num <Gpon::FiveMinIntvlNo> ] ]
```

Command Parameters

Table 116.20-1 "PON Utilization Previous Interval PM Command" Resource Parameters

Resource Identifier	Type	Description
(pon-idx)	Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> x-pon : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::XPonId> 25g-pon : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::M25GPonId>) Possible values: - 25g-pon : 25g pon - x-pon : Xgs pon Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Eqpt::XPonId> - the XGS PON identifier Field type <Eqpt::M25GPonId> - the 25G PON identifier	ifindex of the pon
interval-num	Parameter type: <Gpon::FiveMinIntvlNo> Format: - a number of a previous five minute interval number - range: [1...288]	identifies prev five-min interval (1 is the most recent)

Command Output

Table 116.20-2 "PON Utilization Previous Interval PM Command" Display parameters

Specific Information		
name	Type	Description
txtotutil	Parameter type: <Gpon::FloatPonUtilPercent> - utilization percentage - unit: percentage - range: [0.00...100.00]	transmit (downstream) total utilization (percentage) relative to the total bandwidth <i>This element is always shown.</i>
txbcutil	Parameter type: <Gpon::FloatPonUtilThousandPercent> - utilization percentage - unit: percentage - range: [0.00...1000.00]	transmit (downstream) broadcast utilization (percentage) relative to the non-multicast bandwidth [because the broadcast bandwidth can exceed the non-multicast bandwidth, this value can exceed 100%] <i>This element is always shown.</i>
txmcutil	Parameter type: <Gpon::FloatPonUtilPercent> - utilization percentage - unit: percentage - range: [0.00...100.00]	transmit (downstream) multicast utilization (percentage) relative to the configured multicast bandwidth <i>This element is always shown.</i>
txucutil	Parameter type: <Gpon::FloatPonUtilThousandPercent> - utilization percentage - unit: percentage - range: [0.00...1000.00]	transmit (downstream) unicast utilization (percentage) relative to the non-multicast bandwidth [because the unicast bandwidth can exceed the non-multicast bandwidth, this value can exceed 100%] <i>This element is always shown.</i>
dbacongperiod	Parameter type: <Gpon::FloatPonUtilDbapercent> - utilization percentage - unit: percentage - range: [0.00...100.00]	dba (upstream) congestion period (percentage) [the percentage of the dba granting windows in which the dba congestion threshold was exceeded] <i>This element is always shown.</i>
rxtotutil	Parameter type: <Gpon::FloatPonUtilPercent> - utilization percentage - unit: percentage - range: [0.00...100.00]	receive (upstream) total utilization (percentage) relative to the total bandwidth <i>This element is always shown.</i>

Only Show Details: transmitted/received counts		
name	Type	Description
txtotbyte	Parameter type: <OctetCounter64> - 64 bit counter,range:[0-9223372036854775808]	total number of bytes transmitted on the pon (downstream) <i>This element is only shown in detail mode.</i>
txbcbyte	Parameter type: <OctetCounter64> - 64 bit counter,range:[0-9223372036854775808]	number of broadcast bytes transmitted on the pon (downstream) <i>This element is only shown in detail mode.</i>
txmcbyte	Parameter type: <OctetCounter64> - 64 bit counter,range:[0-9223372036854775808]	total number of multicast bytes transmitted on the pon (downstream) <i>This element is only shown in detail mode.</i>

116 Pon Status Commands

name	Type	Description
		<i>detail mode.</i>
txucbyte	Parameter type: <OctetCounter64> - 64 bit counter,range:[0-9223372036854775808]	number of unicast bytes transmitted on the pon (downstream) <i>This element is only shown in detail mode.</i>
rxtothbyte	Parameter type: <OctetCounter64> - 64 bit counter,range:[0-9223372036854775808]	total number of bytes transmitted on the pon (downstream) <i>This element is only shown in detail mode.</i>
txtotfrm	Parameter type: <OctetCounter64> - 64 bit counter,range:[0-9223372036854775808]	total number of packets transmitted on the pon (downstream) <i>This element is only shown in detail mode.</i>
txbcfrm	Parameter type: <OctetCounter64> - 64 bit counter,range:[0-9223372036854775808]	number of broadcast packets transmitted on the pon (downstream) <i>This element is only shown in detail mode.</i>
txmcfrm	Parameter type: <OctetCounter64> - 64 bit counter,range:[0-9223372036854775808]	number of multicast packets transmitted on the pon (downstream) <i>This element is only shown in detail mode.</i>
txucfrm	Parameter type: <OctetCounter64> - 64 bit counter,range:[0-9223372036854775808]	number of unicast packets transmitted on the pon (downstream) <i>This element is only shown in detail mode.</i>
rxtotfrm	Parameter type: <OctetCounter64> - 64 bit counter,range:[0-9223372036854775808]	total number of packets received on the pon (upstream) <i>This element is only shown in detail mode.</i>

Only Show Details: dropped counts		
name	Type	Description
txtodtrobbyte	Parameter type: <OctetCounter64> - 64 bit counter,range:[0-9223372036854775808]	total number of bytes dropped destined for the pon (downstream) <i>This element is only shown in detail mode.</i>
txbcdrobbyte	Parameter type: <OctetCounter64> - 64 bit counter,range:[0-9223372036854775808]	number of bytes dropped destined for the pon (downstream) <i>This element is only shown in detail mode.</i>
txmcdrobbyte	Parameter type: <OctetCounter64> - 64 bit counter,range:[0-9223372036854775808]	number of broadcast bytes dropped destined for the pon (downstream) <i>This element is only shown in detail mode.</i>
txucdtrobbyte	Parameter type: <OctetCounter64> - 64 bit counter,range:[0-9223372036854775808]	number of unicast bytes dropped destined for the pon (downstream) <i>This element is only shown in detail mode.</i>
rxtodtrobbyte	Parameter type: <OctetCounter64> - 64 bit counter,range:[0-9223372036854775808]	total number of bytes dropped received on the pon

name	Type	Description
		(downstream) <i>This element is only shown in detail mode.</i>
txtotdropfrm	Parameter type: <OctetCounter64> - 64 bit counter,range:[0-9223372036854775808]	total number of packets dropped destined for the pon (downstream) <i>This element is only shown in detail mode.</i>
txbcdropfrm	Parameter type: <OctetCounter64> - 64 bit counter,range:[0-9223372036854775808]	number of broadcast packets dropped destined for the pon (downstream) <i>This element is only shown in detail mode.</i>
txmcdropfrm	Parameter type: <OctetCounter64> - 64 bit counter,range:[0-9223372036854775808]	number of multicast packets dropped destined for the pon (downstream) <i>This element is only shown in detail mode.</i>
txucdropfrm	Parameter type: <OctetCounter64> - 64 bit counter,range:[0-9223372036854775808]	number of unicast packets dropped destined for the pon (downstream) <i>This element is only shown in detail mode.</i>
rxtotdropfrm	Parameter type: <OctetCounter64> - 64 bit counter,range:[0-9223372036854775808]	total number of packets dropped destined for the pon (downstream) <i>This element is only shown in detail mode.</i>

Only Show Details: number of active onts on pon

name	Type	Description
numactiveonts	Parameter type: <Gpon::NumActiveOnt> - number of active onts that carry atleast a minimum amount of traffic - range: [0...128]	number of active ONTs on the pon (carrying more than a minimum amount of traffic) <i>This element is only shown in detail mode.</i>

116.21 PON Utilization Previous Interval Top Five ONT Downstream PM Command

Command Description

This command retrieves the top 5 ONTs on the PON ranked by downstream traffic for previous intervals.

User Level

The command can be accessed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

```
> show pon utilization prv-intvl-top-ont-tx [ (pon-idx) [ interval-num <Gpon::FiveMinIntvlNo> ] [ rank
<Gpon::PonUtilOntRank> ] ]
```

Command Parameters

Table 116.21-1 "PON Utilization Previous Interval Top Five ONT Downstream PM Command" Resource Parameters

Resource Identifier	Type	Description
(pon-idx)	Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> x-pon : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::XPonId> 25g-pon : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::M25GPonId>) Possible values: - 25g-pon : 25g pon - x-pon : Xgs pon Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Eqpt::XPonId> - the XGS PON identifier Field type <Eqpt::M25GPonId> - the 25G PON identifier	ifindex of the pon
interval-num	Parameter type: <Gpon::FiveMinIntvlNo> Format:	identifies prev five-min interval (1 is the most recent)

Resource Identifier	Type	Description
	- a number of a previous five minute interval number - range: [1...288]	
rank	Parameter type: <Gpon::PonUtilOntRank> Format: - rank of the ont - range: [1...5]	rank of the ont within the pon

Command Output

**Table 116.21-2 "PON Utilization Previous Interval Top Five ONT Downstream PM Command"
Display parameters**

Specific Information		
name	Type	Description
ont-idx	Parameter type: <Gpon::OntIndex> (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> ng2 : <Ng2::ChannelGroup> / <Ng2::SubchannelGroup> / <Ng2::OntId>) Possible values: - ng2 : ngpon2 style identification Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Ng2::ChannelGroup> - channel group number Field type <Ng2::SubchannelGroup> - subchannel group number Field type <Eqpt::OntId> - the ONT identifier Field type <Ng2::OntId> - the ONT identifier	ont-index of the particular ont <i>This element is always shown.</i>
txucutil	Parameter type: <Gpon::FloatPonUtilThousandPercent> - utilization percentage - unit: percentage - range: [0.00...1000.00]	transmit (downstream) unicast utilization (percentage) relative to the non-multicast pon bandwidth [because the unicast bandwidth can exceed the non-multicast bandwidth, this value can exceed 100%] <i>This element is always shown.</i>

116.22 PON Utilization Previous Interval Top Five ONT Upstream PM Command

Command Description

This command retrieves the top 5 ONTs on the PON ranked by upstream traffic for previous intervals.

User Level

The command can be accessed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

```
> show pon utilization prv-intvl-top-ont-rx [ (pon-idx) [ interval-num <Gpon::FiveMinIntvlNo> ] [ rank
<Gpon::PonUtilOntRank> ] ]
```

Command Parameters

Table 116.22-1 "PON Utilization Previous Interval Top Five ONT Upstream PM Command" Resource Parameters

Resource Identifier	Type	Description
(pon-idx)	Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> x-pon : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::XPonId> 25g-pon : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::M25GPonId>) Possible values: - 25g-pon : 25g pon - x-pon : Xgs pon Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Eqpt::XPonId> - the XGS PON identifier Field type <Eqpt::M25GPonId> - the 25G PON identifier	ifindex of the pon
interval-num	Parameter type: <Gpon::FiveMinIntvlNo> Format:	identifies prev five-min interval (1 is the most recent)

Resource Identifier	Type	Description
	- a number of a previous five minute interval number - range: [1...288]	
rank	Parameter type: <Gpon::PonUtilOntRank> Format: - rank of the ont - range: [1...5]	rank of the ont within the pon

Command Output

**Table 116.22-2 "PON Utilization Previous Interval Top Five ONT Upstream PM Command"
Display parameters**

Specific Information		
name	Type	Description
ont-idx	Parameter type: <Gpon::OntIndex> (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> ng2 : <Ng2::ChannelGroup> / <Ng2::SubchannelGroup> / <Ng2::OntId>) Possible values: - ng2 : ngpon2 style identification Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Ng2::ChannelGroup> - channel group number Field type <Ng2::SubchannelGroup> - subchannel group number Field type <Eqpt::OntId> - the ONT identifier Field type <Ng2::OntId> - the ONT identifier	ont-index of the particular ont <i>This element is always shown.</i>
rxucutil	Parameter type: <Gpon::FloatPonUtilPercent> - utilization percentage - unit: percentage - range: [0.00...100.00]	receive (upstream) unicast utilization (percentage) relative to total pon bandwidth <i>This element is always shown.</i>

116.23 PON Peak Utilization Current Interval PM Command

Command Description

This command retrieves PON peak utilization current interval performance monitoring data.

User Level

The command can be accessed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

```
> show pon peak-utilization current-interval [ (pon-idx) ]
```

Command Parameters

Table 116.23-1 "PON Peak Utilization Current Interval PM Command" Resource Parameters

Resource Identifier	Type	Description
(pon-idx)	Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> x-pon : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::XPonId> 25g-pon : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::M25GPonId>) Possible values: - 25g-pon : 25g pon - x-pon : Xgs pon Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Eqpt::XPonId> - the XGS PON identifier Field type <Eqpt::M25GPonId> - the 25G PON identifier	ifindex of the pon

Command Output

Table 116.23-2 "PON Peak Utilization Current Interval PM Command" Display parameters

Specific Information		
name	Type	Description
txpkucutil	Parameter type: <Gpon::FloatPonUtilThousandPercent> - utilization percentage - unit: percentage - range: [0.00...1000.00]	transmit (downstream) peak unicast utilization (percentage) relative to the non-multicast bandwidth [because the unicast bandwidth can exceed the non-multicast bandwidth, this value can exceed 100%] <i>This element is always shown.</i>
rxpktotutil	Parameter type: <Gpon::FloatPonUtilPercent> - utilization percentage - unit: percentage - range: [0.00...100.00]	receive (upstream) total peak utilization (percentage) relative to the total bandwidth <i>This element is always shown.</i>
Only Show Details: transmitted/received counts		
name	Type	Description
txpkucbyte	Parameter type: <OctetCounter64> - 64 bit counter,range:[0-9223372036854775808]	number of peak unicast bytes transmitted on the pon (downstream) <i>This element is only shown in detail mode.</i>
rxpktotbyte	Parameter type: <OctetCounter64> - 64 bit counter,range:[0-9223372036854775808]	total number of peak bytes transmitted on the pon (downstream) <i>This element is only shown in detail mode.</i>
txpkucfrm	Parameter type: <OctetCounter64> - 64 bit counter,range:[0-9223372036854775808]	number of peak unicast packets transmitted on the pon (downstream) <i>This element is only shown in detail mode.</i>
rxpktotfrm	Parameter type: <OctetCounter64> - 64 bit counter,range:[0-9223372036854775808]	total number of peak packets received on the pon (upstream) <i>This element is only shown in detail mode.</i>

116.24 PON Peak Utilization Current Interval Top Five ONT Downstream PM Command

Command Description

This command retrieves the top 5 ONTs on the PON ranked by peak downstream traffic for the current interval.

User Level

The command can be accessed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

```
> show pon peak-utilization cur-intvl-top-ont-tx [ (pon-idx) [ rank <Gpon::PonUtilOntRank> ] ]
```

Command Parameters

Table 116.24-1 "PON Peak Utilization Current Interval Top Five ONT Downstream PM Command" Resource Parameters

Resource Identifier	Type	Description
(pon-idx)	Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> x-pon : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::XPonId> 25g-pon : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::M25GPonId>) Possible values: - 25g-pon : 25g pon - x-pon : Xgs pon Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Eqpt::XPonId> - the XGS PON identifier Field type <Eqpt::M25GPonId> - the 25G PON identifier	ifindex of the pon
rank	Parameter type: <Gpon::PonUtilOntRank> Format: - rank of the ont	rank of the ont within the pon

Resource Identifier	Type	Description
	- range: [1...5]	

Command Output

Table 116.24-2 "PON Peak Utilization Current Interval Top Five ONT Downstream PM Command" Display parameters

Specific Information		
name	Type	Description
ont-idx	Parameter type: <Gpon::OntIndex> (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> ng2 : <Ng2::ChannelGroup> / <Ng2::SubchannelGroup> / <Ng2::OntId>) Possible values: - ng2 : ngpon2 style identification Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Ng2::ChannelGroup> - channel group number Field type <Ng2::SubchannelGroup> - subchannel group number Field type <Eqpt::OntId> - the ONT identifier Field type <Ng2::OntId> - the ONT identifier	ont-index of the particular ont <i>This element is always shown.</i>
txpkucutil	Parameter type: <Gpon::FloatPonUtilThousandPercent> - utilization percentage - unit: percentage - range: [0.00...1000.00]	transmit (downstream) peak unicast utilization (percentage) relative to the non-multicast pon bandwidth [because the unicast bandwidth can exceed the non-multicast bandwidth, this value can exceed 100%] <i>This element is always shown.</i>

116.25 PON Peak Utilization Current Interval Top Five ONT Upstream PM Command

Command Description

This command retrieves the top 5 ONTs on the PON ranked by peak upstream traffic for the current interval.

User Level

The command can be accessed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

```
> show pon peak-utilization cur-intvl-top-ont-rx [ (pon-idx) [ rank <Gpon::PonUtilOntRank> ] ]
```

Command Parameters

Table 116.25-1 "PON Peak Utilization Current Interval Top Five ONT Upstream PM Command" Resource Parameters

Resource Identifier	Type	Description
(pon-idx)	Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> x-pon : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::XPonId> 25g-pon : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::M25GPonId>) Possible values: - 25g-pon : 25g pon - x-pon : Xgs pon Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Eqpt::XPonId> - the XGS PON identifier Field type <Eqpt::M25GPonId> - the 25G PON identifier	ifindex of the pon
rank	Parameter type: <Gpon::PonUtilOntRank> Format: - rank of the ont	rank of the ont within the pon

Resource Identifier	Type	Description
	- range: [1...5]	

Command Output

**Table 116.25-2 "PON Peak Utilization Current Interval Top Five ONT Upstream PM Command"
Display parameters**

Specific Information		
name	Type	Description
ont-idx	Parameter type: <Gpon::OntIndex> (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> ng2 : <Ng2::ChannelGroup> / <Ng2::SubchannelGroup> / <Ng2::OntId>) Possible values: - ng2 : ngpon2 style identification Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Ng2::ChannelGroup> - channel group number Field type <Ng2::SubchannelGroup> - subchannel group number Field type <Eqpt::OntId> - the ONT identifier Field type <Ng2::OntId> - the ONT identifier	ont-index of the particular ont <i>This element is always shown.</i>
rxpktotutil	Parameter type: <Gpon::FloatPonUtilPercent> - utilization percentage - unit: percentage - range: [0.00...100.00]	receive (upstream) total peak utilization (percentage) relative to total pon bandwidth <i>This element is always shown.</i>

116.26 PON Peak Utilization Previous Interval PM Command

Command Description

This command retrieves PON peak utilization previous interval performance monitoring data.

User Level

The command can be accessed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

```
> show pon peak-utilization previous-interval [ (pon-idx) [ interval-num <Gpon::FiveMinIntvlNo> ] ]
```

Command Parameters

Table 116.26-1 "PON Peak Utilization Previous Interval PM Command" Resource Parameters

Resource Identifier	Type	Description
(pon-idx)	Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> x-pon : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::XPonId> 25g-pon : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::M25GPonId>) Possible values: - 25g-pon : 25g pon - x-pon : Xgs pon Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Eqpt::XPonId> - the XGS PON identifier Field type <Eqpt::M25GPonId> - the 25G PON identifier	ifindex of the pon
interval-num	Parameter type: <Gpon::FiveMinIntvlNo> Format: - a number of a previous five minute interval number - range: [1...288]	identifies prev five-min interval (1 is the most recent)

Command Output

Table 116.26-2 "PON Peak Utilization Previous Interval PM Command" Display parameters

Specific Information		
name	Type	Description
txpkucutil	Parameter type: <Gpon::FloatPonUtilThousandPercent> - utilization percentage - unit: percentage - range: [0.00...1000.00]	transmit (downstream) peak unicast utilization (percentage) relative to the non-multicast bandwidth [because the unicast bandwidth can exceed the non-multicast bandwidth, this value can exceed 100%] <i>This element is always shown.</i>
rxpktotutil	Parameter type: <Gpon::FloatPonUtilPercent> - utilization percentage - unit: percentage - range: [0.00...100.00]	receive (upstream) total peak utilization (percentage) relative to the total bandwidth <i>This element is always shown.</i>
Only Show Details: transmitted/received counts		
name	Type	Description
txpkucbyte	Parameter type: <OctetCounter64> - 64 bit counter,range:[0-9223372036854775808]	number of peak unicast bytes transmitted on the pon (downstream) <i>This element is only shown in detail mode.</i>
rxpktotbyte	Parameter type: <OctetCounter64> - 64 bit counter,range:[0-9223372036854775808]	total number of peak bytes received on the pon (upstream) <i>This element is only shown in detail mode.</i>
txpkucfrm	Parameter type: <OctetCounter64> - 64 bit counter,range:[0-9223372036854775808]	number of peak unicast packets transmitted on the pon (downstream) <i>This element is only shown in detail mode.</i>
rxpktotfrm	Parameter type: <OctetCounter64> - 64 bit counter,range:[0-9223372036854775808]	total number of peak packets received on the pon (upstream) <i>This element is only shown in detail mode.</i>

116.27 PON Peak Utilization Previous Interval Top Five ONT Downstream PM Command

Command Description

This command retrieves the top 5 ONTs on the PON ranked by peak downstream traffic for previous intervals.

User Level

The command can be accessed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

```
> show pon peak-utilization prv-intvl-top-ont-tx [ (pon-idx) [ interval-num <Gpon::FiveMinIntvlNo> ] [ rank
<Gpon::PonUtilOntRank> ] ]
```

Command Parameters

Table 116.27-1 "PON Peak Utilization Previous Interval Top Five ONT Downstream PM Command" Resource Parameters

Resource Identifier	Type	Description
(pon-idx)	Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> x-pon : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::XPonId> 25g-pon : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::M25GPonId>) Possible values: - 25g-pon : 25g pon - x-pon : Xgs pon Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Eqpt::XPonId> - the XGS PON identifier Field type <Eqpt::M25GPonId> - the 25G PON identifier	ifindex of the pon
interval-num	Parameter type: <Gpon::FiveMinIntvlNo> Format:	identifies prev five-min interval (1 is the most recent)

Resource Identifier	Type	Description
	- a number of a previous five minute interval number - range: [1...288]	
rank	Parameter type: <Gpon::PonUtilOntRank> Format: - rank of the ont - range: [1...5]	rank of the ont within the pon

Command Output

Table 116.27-2 "PON Peak Utilization Previous Interval Top Five ONT Downstream PM Command" Display parameters

Specific Information		
name	Type	Description
ont-idx	Parameter type: <Gpon::OntIndex> (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> ng2 : <Ng2::ChannelGroup> / <Ng2::SubchannelGroup> / <Ng2::OntId>) Possible values: - ng2 : ngpon2 style identification Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Ng2::ChannelGroup> - channel group number Field type <Ng2::SubchannelGroup> - subchannel group number Field type <Eqpt::OntId> - the ONT identifier Field type <Ng2::OntId> - the ONT identifier	ont-index of the particular ont <i>This element is always shown.</i>
txpkucutil	Parameter type: <Gpon::FloatPonUtilThousandPercent> - utilization percentage - unit: percentage - range: [0.00...1000.00]	transmit (downstream) peak unicast utilization (percentage) relative to the non-multicast pon bandwidth [because the unicast bandwidth can exceed the non-multicast bandwidth, this value can exceed 100%] <i>This element is always shown.</i>

116.28 PON Peak Utilization Previous Interval Top Five ONT Upstream PM Command

Command Description

This command retrieves the top 5 ONTs on the PON ranked by peak upstream traffic for previous intervals.

User Level

The command can be accessed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

```
> show pon peak-utilization prv-intvl-top-ont-rx [ (pon-idx) [ interval-num <Gpon::FiveMinIntvlNo> ] [ rank
<Gpon::PonUtilOntRank> ] ]
```

Command Parameters

Table 116.28-1 "PON Peak Utilization Previous Interval Top Five ONT Upstream PM Command" Resource Parameters

Resource Identifier	Type	Description
(pon-idx)	Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> x-pon : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::XPonId> 25g-pon : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::M25GPonId>) Possible values: - 25g-pon : 25g pon - x-pon : Xgs pon Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Eqpt::XPonId> - the XGS PON identifier Field type <Eqpt::M25GPonId> - the 25G PON identifier	ifindex of the pon
interval-num	Parameter type: <Gpon::FiveMinIntvlNo> Format:	identifies prev five-min interval (1 is the most recent)

Resource Identifier	Type	Description
	- a number of a previous five minute interval number - range: [1...288]	
rank	Parameter type: <Gpon::PonUtilOntRank> Format: - rank of the ont - range: [1...5]	rank of the ont within the pon

Command Output

**Table 116.28-2 "PON Peak Utilization Previous Interval Top Five ONT Upstream PM Command"
Display parameters**

Specific Information		
name	Type	Description
ont-idx	Parameter type: <Gpon::OntIndex> (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> ng2 : <Ng2::ChannelGroup> / <Ng2::SubchannelGroup> / <Ng2::OntId>) Possible values: - ng2 : ngpon2 style identification Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Ng2::ChannelGroup> - channel group number Field type <Ng2::SubchannelGroup> - subchannel group number Field type <Eqpt::OntId> - the ONT identifier Field type <Ng2::OntId> - the ONT identifier	ont-index of the particular ont <i>This element is always shown.</i>
rxpktotutil	Parameter type: <Gpon::FloatPonUtilPercent> - utilization percentage - unit: percentage - range: [0.00...100.00]	receive (upstream) total peak utilization (percentage) relative to total pon bandwidth <i>This element is always shown.</i>

117- Channel Pair Status Commands

117.1 Channel Pair Status Command Tree	117-5781
117.2 Aggregate Channel Pair XGEM Ports Current Interval Status Command	117-5783
117.3 Aggregate Channel Pair XGEM Ports Previous Interval Status Command	117-5784
117.4 Multicast TC-layer Current Interval Performance Data Status Command	117-5786
117.5 Multicast TC-layer Previous Interval Performance Data Status Command	117-5788
117.6 Pon FEC Current Interval Status Command	117-5790
117.7 Channel Pair Physical LayerCurrent Interval Status Command	117-5792
117.8 Channel pair NGPON2 tc-layer Current Interval Status Command	117-5794
117.9 Channel Pair NGPON2 TC-layer Previous Interval Performance Data Status Command	117-5796
117.10 PON Optics Operational Information Status Command	117-5798
117.11 Channel Pair Optics Status Command	117-5800
117.12 NGPON2 Diagnostic Status Command	117-5802
117.13 Show Channel Pair Unprovisioned Onu Command	117-5804
117.14 Channel Pair Utilization Current Interval PM Command	117-5806
117.15 Channel Pair Utilization Current Interval Top Five ONT Downstream PM Command	117-5810
117.16 Channel Pair Utilization Current Interval Top Five ONT Upstream PM Command	117-5812
117.17 Channel Pair Utilization Previous Interval PM Command	117-5814
117.18 Channel Pair Utilization Previous Interval Top Five ONT Downstream PM Command	117-5818
117.19 Channel Pair Utilization Previous Interval Top Five ONT Upstream PM Command	117-5820
117.20 Channel Pair Peak Utilization Current Interval PM Command	117-5822
117.21 Channel Pair Peak Utilization Current Interval Top Five ONT Downstream PM Command	117-5824
117.22 Channel Pair Peak Utilization Current Interval Top Five ONT Upstream PM Command	117-5826
117.23 Channel Pair Peak Utilization Previous Interval PM Command	117-5828
117.24 Channel Pair Peak Utilization Previous Interval Top Five ONT Downstream PM Command	117-5830
117.25 Channel Pair Peak Utilization Previous Interval Top Five ONT Upstream PM Command	117-5832

117.1 Channel Pair Status Command Tree

Description

This chapter gives an overview of nodes that are handled by "Channel Pair Status Commands".

Command Tree

```

----show
  ----channel-pair
    ----tc-layer
      ----current-interval
        - (chanpair-idx)
      ----previous-interval
        - (chanpair-idx)
        - interval-nbr
    ----mcast-tc-layer
      ----current-interval
        - (chanpair-idx)
      ----previous-interval
        - (chanpair-idx)
        - interval-no
    ----fec-tc-layer
      ----current-interval
        - (chanpair-idx)
    ----phy-layer
      ----current-interval
        - (chanpair-idx)
    ----xg-tc-layer
      ----current-interval
        - (chanpair-idx)
      ----previous-interval
        - (chanpair-idx)
        - interval-no
    ----sfp-inventory
      - (chanpair-idx)
    ----optics
      - (chanpair-idx)
    ----diagnostics
      - (chanpair-idx)
    ----unprovision-onu
      - (alarm-idx)
    ----utilization
      ----current-interval
        - (chanpair-idx)
      ----cur-intvl-top-ont-tx
        - (chanpair-idx)
        - rank
      ----cur-intvl-top-ont-rx
        - (chanpair-idx)
        - rank
      ----previous-interval
        - (chanpair-idx)
        - interval-num
  
```

- prv-intvl-top-ont-tx**
 - (chanpair-idx)
 - interval-num
 - rank
- prv-intvl-top-ont-rx**
 - (chanpair-idx)
 - interval-num
 - rank
- peak-utilization**
 - current-interval**
 - (chanpair-idx)
 - cur-intvl-top-ont-tx**
 - (chanpair-idx)
 - rank
 - cur-intvl-top-ont-rx**
 - (chanpair-idx)
 - rank
 - previous-interval**
 - (chanpair-idx)
 - interval-num
 - prv-intvl-top-ont-tx**
 - (chanpair-idx)
 - interval-num
 - rank
 - prv-intvl-top-ont-rx**
 - (chanpair-idx)
 - interval-num
 - rank

117.2 Aggregate Channel Pair XGEM Ports Current Interval Status Command

Command Description

Current interval table contains various statistics collected for aggregate channel pair XGEM ports (from OLT side of the channel pair) in the current 15 minutes interval.

User Level

The command can be accessed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

```
> show channel-pair tc-layer current-interval [ (chanpair-idx) ]
```

Command Parameters

Table 117.2-1 "Aggregate Channel Pair XGEM Ports Current Interval Status Command" Resource Parameters

Resource Identifier	Type	Description
(chanpair-idx)	Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::ChannelPairId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::ChannelPairId> - the channel pair identifier	ifindex of the channel pair

Command Output

Table 117.2-2 "Aggregate Channel Pair XGEM Ports Current Interval Status Command" Display parameters

Specific Information		
name	Type	Description
err-frags-up	Parameter type: <Counter> - 32 bit counter	a count of errored gem fragments (upstream) <i>This element is always shown.</i>

117.3 Aggregate Channel Pair XGEM Ports

Previous Interval Status Command

Command Description

Previous interval table contains various statistics collected for aggregate channel pair XGEM ports (from OLT side of the channel pair) over the previous 8 hours of operation.

The past 8 hours are broken into 32 completed 15 minute intervals. Each row in this table represents one such interval.

User Level

The command can be accessed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

```
> show channel-pair tc-layer previous-interval [ (chanpair-idx) [ interval-nbr <Gpon::GemPortInterval> ] ]
```

Command Parameters

Table 117.3-1 "Aggregate Channel Pair XGEM Ports Previous Interval Status Command" Resource Parameters

Resource Identifier	Type	Description
(chanpair-idx)	Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::ChannelPairId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::ChannelPairId> - the channel pair identifier	ifindex of the channel pair
interval-nbr	Parameter type: <Gpon::GemPortInterval> Format: - time interval in terms of 15 mins - range: [1...32]	aggregate gem port interval number

Command Output

Table 117.3-2 "Aggregate Channel Pair XGEM Ports Previous Interval Status Command" Display parameters

Specific Information		
name	Type	Description
err-frags-up	Parameter type: <Counter> - 32 bit counter	a count of errored gem fragments (upstream) <i>This element is always shown.</i>

117.4 Multicast TC-layer Current Interval Performance Data Status Command

Command Description

This command displays various statistics collected for OLT-side Multicast TC-layer during the current 15 minute interval of operation.

User Level

The command can be accessed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

```
> show channel-pair mcast-tc-layer current-interval [ (chanpair-idx) ]
```

Command Parameters

Table 117.4-1 "Multicast TC-layer Current Interval Performance Data Status Command" Resource Parameters

Resource Identifier	Type	Description
(chanpair-idx)	Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::ChannelPairId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::ChannelPairId> - the channel pair identifier	channel pair index

Command Output

Table 117.4-2 "Multicast TC-layer Current Interval Performance Data Status Command" Display parameters

Specific Information		
name	Type	Description
transmit-blocks	Parameter type: <Counter> - 32 bit counter	count of transmitted gem blocks on gem 4095 <i>This element is always shown.</i>
transmit-frags	Parameter type: <Counter>	count of transmitted gem

117 Channel Pair Status Commands

name	Type	Description
	- 32 bit counter	fragments on gem 4095 <i>This element is always shown.</i>

117.5 Multicast TC-layer Previous Interval Performance Data Status Command

Command Description

This command displays various statistics collected for OLT-side Multicast TC-layer over the previous 8 hours of operations which is broken in to 32 completed 15 minute intervals.

User Level

The command can be accessed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

```
> show channel-pair mcast-tc-layer previous-interval [ (chanpair-idx) [ interval-no <Gpon::IntervalNo> ] ]
```

Command Parameters

Table 117.5-1 "Multicast TC-layer Previous Interval Performance Data Status Command" Resource Parameters

Resource Identifier	Type	Description
(chanpair-idx)	Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::ChannelPairId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::ChannelPairId> - the channel pair identifier	channel-pair index
interval-no	Parameter type: <Gpon::IntervalNo> Format: - a number of a previous interval number - range: [1...32]	identifies prev 15min intvl, val 1 as the latest intvl

Command Output

Table 117.5-2 "Multicast TC-layer Previous Interval Performance Data Status Command" Display parameters

Specific Information

117 Channel Pair Status Commands

name	Type	Description
transmit-blocks	Parameter type: <Counter> - 32 bit counter	count of transmitted gem blocks on gem 4095 <i>This element is always shown.</i>
transmit-frags	Parameter type: <Counter> - 32 bit counter	count of transmitted gem fragments on gem 4095 <i>This element is always shown.</i>

117.6 Pon FEC Current Interval Status Command

Command Description

Current interval table contains various FEC counters collected for XGPON ports (from OLT side of the PON) in the current 15 minutes interval.

User Level

The command can be accessed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

```
> show channel-pair fec-tc-layer current-interval [ (chanpair-idx) ]
```

Command Parameters

Table 117.6-1 "Pon FEC Current Interval Status Command" Resource Parameters

Resource Identifier	Type	Description
(chanpair-idx)	Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::ChannelPairId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::ChannelPairId> - the channel pair identifier	channel pair index

Command Output

Table 117.6-2 "Pon FEC Current Interval Status Command" Display parameters

Specific Information		
name	Type	Description
corrected-bytes	Parameter type: <OctetCounter64> - 64 bit counter,range:[0-9223372036854775808]	A count of number of bytes that were corrected by the FEC function <i>This element is always shown.</i>
corrected-code-words	Parameter type: <Counter> - 32 bit counter	A count of number of code words that were corrected by the FEC function. <i>This element is always shown.</i>
uncorrected-words	Parameter type: <Counter>	A count of number of errored

117 Channel Pair Status Commands

name	Type	Description
	- 32 bit counter	code words that could not be corrected by the FEC function. <i>This element is always shown.</i>
total-code-words	Parameter type: <Counter> - 32 bit counter	A count of total number of received code words. <i>This element is always shown.</i>

117.7 Channel Pair Physical LayerCurrent Interval Status Command

Command Description

Current interval table contains various physical layer counters collected for NGPON2 ports (from OLT side of the channel pair) in the current 15 minutes interval.

User Level

The command can be accessed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

```
> show channel-pair phy-layer current-interval [ (chanpair-idx) ]
```

Command Parameters

Table 117.7-1 "Channel Pair Physical LayerCurrent Interval Status Command" Resource Parameters

Resource Identifier	Type	Description
(chanpair-idx)	Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::ChannelPairId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::ChannelPairId> - the channel pair identifier	ont index

Command Output

Table 117.7-2 "Channel Pair Physical LayerCurrent Interval Status Command" Display parameters

Specific Information		
name	Type	Description
bip32-prot-words	Parameter type: <OctetCounter64> - 64 bit counter,range:[0-9223372036854775808]	A count of total number of BIP32 words on physical channel pair. <i>This element is always shown.</i>
bip32-bit-errors	Parameter type: <OctetCounter64>	A count of number of BIP32

117 Channel Pair Status Commands

name	Type	Description
	- 64 bit counter,range:[0-9223372036854775808]	errors on physical channel pair. <i>This element is always shown.</i>

117.8 Channel pair NGPON2 tc-layer Current Interval Status Command

Command Description

Current interval table contains NGPON2 tc-layer counters collected for channel pair ports (from OLT side of the channel pair) in the current 15 minutes interval.

User Level

The command can be accessed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

```
> show channel-pair xg-tc-layer current-interval [ (chanpair-idx) ]
```

Command Parameters

Table 117.8-1 "Channel pair NGPON2 tc-layer Current Interval Status Command" Resource Parameters

Resource Identifier	Type	Description
(chanpair-idx)	Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::ChannelPairId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::ChannelPairId> - the channel pair identifier	channel pair index

Command Output

Table 117.8-2 "Channel pair NGPON2 tc-layer Current Interval Status Command" Display parameters

Specific Information		
name	Type	Description
rng-time-msgs	Parameter type: <Counter> - 32 bit counter	A count of number of ranging time messages that were sent on this channel pair. <i>This element is always shown.</i>

117.9 Channel Pair NGPON2 TC-layer Previous Interval Performance Data Status Command

Command Description

This command displays NGPON2 tc-layer counters collected for channel pair ports (from OLT side of the channel pair) over the previous 8 hours of operations which is broken in to 32 completed 15 minute intervals.

User Level

The command can be accessed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

> show channel-pair xg-tc-layer previous-interval [(chanpair-idx) [interval-no <Gpon::IntervalNo>]]

Command Parameters

Table 117.9-1 "Channel Pair NGPON2 TC-layer Previous Interval Performance Data Status Command" Resource Parameters

Resource Identifier	Type	Description
(chanpair-idx)	Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::ChannelPairId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::ChannelPairId> - the channel pair identifier	ont index
interval-no	Parameter type: <Gpon::IntervalNo> Format: - a number of a previous interval number - range: [1...32]	identifies prev 15min intvls, val 1 as the latest intvl

Command Output

Table 117.9-2 "Channel Pair NGPON2 TC-layer Previous Interval Performance Data Status Command" Display parameters

Specific Information

117 Channel Pair Status Commands

name	Type	Description
rng-time-msgs	Parameter type: <Counter> - 32 bit counter	A count of number of ranging time messages that were sent on this channel pair. <i>This element is always shown.</i>

117.10 PON Optics Operational Information Status Command

Command Description

OLT-SIDE current operational information regarding a PON (primarily optical transmit levels and laser parameters).

The content of the special feature register is reflected in the display parameters with the specific information name "otdr". In case the *spf* is *otdr* capable, "yes" is reflected. All other special feature values are mapped to "no".

User Level

The command can be accessed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

```
> show channel-pair sfp-inventory [ (chanpair-idx) ]
```

Command Parameters

Table 117.10-1 "PON Optics Operational Information Status Command" Resource Parameters

Resource Identifier	Type	Description
(chanpair-idx)	Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::ChannelPairId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::ChannelPairId> - the channel pair identifier	ifindex of channel pair

Command Output

Table 117.10-2 "PON Optics Operational Information Status Command" Display parameters

Specific Information		
name	Type	Description
sfp-vendor	Parameter type: <Gpon::OpVendorName> - printable string	vendor name associated with the optics module for this pon <i>This element is always shown.</i>
part-num	Parameter type: <Gpon::OpPartNumber>	model part number associated

117 Channel Pair Status Commands

name	Type	Description
	- printable string	with the optics module for this pon <i>This element is always shown.</i>
serial-num	Parameter type: <Gpon::OpSerialNumber> - printable string	serial number associated with the optics module for this pon <i>This element is always shown.</i>
mfg-date	Parameter type: <Gpon::OpMfgDateCode> - printable string	manufacturing date code associated with the optics module for this pon <i>This element is always shown.</i>
otdr	Parameter type: <Gpon::OpSpecFeat> (yes no) Possible values: - yes : sfp is otdr capable - no : sfp is not otdr capable	special features supported by the sfp <i>This element is always shown.</i>

117.11 Channel Pair Optics Status Command

Command Description

User Level

The command can be accessed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

> show channel-pair optics [(chanpair-idx)]

Command Parameters

Table 117.11-1 "Channel Pair Optics Status Command" Resource Parameters

Resource Identifier	Type	Description
(chanpair-idx)	Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::ChannelPairId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::ChannelPairId> - the channel pair identifier	access identifier for the channel pair

Command Output

Table 117.11-2 "Channel Pair Optics Status Command" Display parameters

Specific Information		
name	Type	Description
olt-tx-signal-lvl	Parameter type: <Gpon::OltOpticalSignalLevel> (invalid not-supported <Gpon::OltOpticalSignalLevel>) Possible values: - invalid : a valid measurement is currently unattainable for some reason - not-supported : the measurement functionality is not supported by this particular unit Field type <Gpon::OltOpticalSignalLevel> - olt optical signal level - unit: db	this attribute indicates the current level of the olt's transmit optical signal. <i>This element is always shown.</i>

name	Type	Description
olt-temperature	- range: [-30.0...6553.5] Parameter type: <Gpon::OltTemperature> (invalid not-supported <Gpon::OltTemperature>) Possible values: - invalid : a valid measurement is currently unattainable for some reason - not-supported : the measurement functionality is not supported by this particular unit Field type <Gpon::OltTemperature> - temperature of olt optical module - unit: degree C - range: [-655.35...655.35]	this attribute indicates the current level of the olt's transmit optical signal <i>This element is always shown.</i>
olt-voltage	Parameter type: <Gpon::OltVoltage> (invalid not-supported <Gpon::OltVoltage>) Possible values: - invalid : a valid measurement is currently unattainable for some reason - not-supported : the measurement functionality is not supported by this particular unit Field type <Gpon::OltVoltage> - power feed voltage of olt optical module - unit: Volts - range: [0...655.35]	this attribute indicates the current voltage of the optics module associated with this channel pair. <i>This element is always shown.</i>
olt-laser-curr	Parameter type: <Gpon::OltLaserBias> (invalid not-supported <Gpon::OltLaserBias>) Possible values: - invalid : a valid measurement is currently unattainable for some reason - not-supported : the measurement functionality is not supported by this particular unit Field type <Gpon::OltLaserBias> - indicates the current bias current of the laser - unit: mA - range: [0...65535]	this attribute indicates the current bias current of the laser associated with this channel pair. <i>This element is always shown.</i>

117.12 NGPON2 Diagnostic Status Command

Command Description

This command reports a summary of current background Diagnostic Tests for specified channel pair.

For each channel pair matched, the following response is presented

Background Stuck Laser Rogue Test

Background Pattern Rogue Test

Background Rogue Test Interval

User Level

The command can be accessed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

```
> show channel-pair diagnostics [ (chanpair-idx) ]
```

Command Parameters

Table 117.12-1 "NGPON2 Diagnostic Status Command" Resource Parameters

Resource Identifier	Type	Description
(chanpair-idx)	Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::ChannelPairId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::ChannelPairId> - the channel pair identifier	ifindex of channel pair

Command Output

Table 117.12-2 "NGPON2 Diagnostic Status Command" Display parameters

Specific Information		
name	Type	Description
bkg-stucklaser-test	Parameter type: <Gpon::BkgdRogueDispEnableDisable> (stopped initiated) Possible values:	background stuck laser test. <i>This element is always shown.</i>

name	Type	Description
	- stopped : background test is stopped - initiated : background test is initiated	
bkg-pattern-test	Parameter type: <Gpon::BkgdRogueDispEnableDisable> (stopped initiated) Possible values: - stopped : background test is stopped - initiated : background test is initiated	background pattern test. <i>This element is always shown.</i>
bkg-roguetest-interval	Parameter type: <SignedInteger> - a signed integer	Frequency of background pattern test execution in units of minutes <i>This element is always shown.</i>
bkg-alien-test	Parameter type: <Gpon::BkgdRogueDispEnableDisable> (stopped initiated) Possible values: - stopped : background test is stopped - initiated : background test is initiated	background alien test. <i>This element is always shown.</i>
bkg-alientest-interval	Parameter type: <Gpon::BkgdAlienTestInterval> - Numbers divisible by 30 are permitted. - unit: Minutes - range: [30...240]	Frequency of background alien ont test execution in units of minutes <i>This element is always shown.</i>

117.13 Show Channel Pair Unprovisioned Onu Command

Command Description

This command displays the channel pair unprovisioned onu.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show channel-pair unprovision-onu [ (alarm-idx) ]
```

Command Parameters

Table 117.13-1 " Show Channel Pair Unprovisioned Onu Command" Resource Parameters

Resource Identifier	Type	Description
(alarm-idx)	Format: - index of a current alarm entry	current alarm index

Command Output

Table 117.13-2 " Show Channel Pair Unprovisioned Onu Command" Display parameters

Specific Information		
name	Type	Description
chanpair-idx	Parameter type: <Ng2::ChannelPairIndexOrZero> (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::ChannelPairId> -) Possible values: - - : ont not ranged Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::ChannelPairId> - the channel pair identifier	identifies the channel pair where the alarm has occurred. <i>This element is always shown.</i>
newont-index	Parameter type: <SignedInteger> - a signed integer	the newonu index for the channel pair alarm

name	Type	Description
		<i>This element is only shown in detail mode.</i>
sernum	Parameter type: <Gpon::SerNum1> - serv num - length: 12	new ONT Serial Num <i>This element is always shown.</i>
subscriber-locid	Parameter type: <Gpon::SubsLocId> - subsloc id, 0 to 12 (36 for ngpon2/xgs/25g) ASCII character string or 0 to 24 (72 for ngpon2/xgs/25g) HEX string depending on slidmode - length: x<=72	new ONT Subscriber Location ID <i>This element is always shown.</i>
logical-authid	Parameter type: <Gpon::LogAuthId> - ont logical id - length: x<=24	new ONT logical AuthId <i>This element is always shown.</i>
actual-us-rate	Parameter type: <Gpon::ActualUsRate> (2.5g 10g 1.25g 25g) Possible values: - : unknown - 2.5g : 2.5 GBit/sec - 10g : 10 GBit/sec - 1.25g : 1.25 GBit/sec - 25g : 25 GBit/sec	new ONT actual upstream rate <i>This element is always shown.</i>

117.14 Channel Pair Utilization Current Interval PM Command

Command Description

This command retrieves channel-pair utilization current interval performance monitoring data.

User Level

The command can be accessed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

```
> show channel-pair utilization current-interval [ (chanpair-idx) ]
```

Command Parameters

Table 117.14-1 "Channel Pair Utilization Current Interval PM Command" Resource Parameters

Resource Identifier	Type	Description
(chanpair-idx)	Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::ChannelPairId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::ChannelPairId> - the channel pair identifier	channel pair ifindex

Command Output

Table 117.14-2 "Channel Pair Utilization Current Interval PM Command" Display parameters

Specific Information		
name	Type	Description
txtotutil	Parameter type: <Gpon::FloatPonUtilPercent> - utilization percentage - unit: percentage - range: [0.00...100.00]	transmit (downstream) total utilization (percentage) relative to the total bandwidth <i>This element is always shown.</i>
txbcutil	Parameter type: <Gpon::FloatPonUtilThousandPercent> - utilization percentage - unit: percentage	transmit (downstream) broadcast utilization (percentage) relative to the non-multicast bandwidth

name	Type	Description
	- range: [0.00...1000.00]	[because the broadcast bandwidth can exceed the non-multicast bandwidth, this value can exceed 100%] <i>This element is always shown.</i>
txmcutil	Parameter type: <Gpon::FloatPonUtilPercent> - utilization percentage - unit: percentage - range: [0.00...100.00]	transmit (downstream) multicast utilization (percentage) relative to the configured multicast bandwidth <i>This element is always shown.</i>
txucutil	Parameter type: <Gpon::FloatPonUtilThousandPercent> - utilization percentage - unit: percentage - range: [0.00...1000.00]	transmit (downstream) unicast utilization (percentage) relative to the non-multicast bandwidth [because the unicast bandwidth can exceed the non-multicast bandwidth, this value can exceed 100%] <i>This element is always shown.</i>
dbacongperiod	Parameter type: <Gpon::FloatPonUtilDbapercent> - utilization percentage - unit: percentage - range: [0.00...100.00]	dba (upstream) congestion period (percentage) [the percentage of the dba granting windows in which the dba congestion threshold was exceeded] <i>This element is always shown.</i>
rxtotutil	Parameter type: <Gpon::FloatPonUtilPercent> - utilization percentage - unit: percentage - range: [0.00...100.00]	receive (upstream) total utilization (percentage) relative to the total bandwidth <i>This element is always shown.</i>

Only Show Details: transmitted/received counts		
name	Type	Description
txtotbyte	Parameter type: <OctetCounter64> - 64 bit counter,range:[0-9223372036854775808]	total number of bytes transmitted on the channel pair (downstream) <i>This element is only shown in detail mode.</i>
txbcbyte	Parameter type: <OctetCounter64> - 64 bit counter,range:[0-9223372036854775808]	number of broadcast bytes transmitted on the channel pair (downstream) <i>This element is only shown in detail mode.</i>
txmcbyte	Parameter type: <OctetCounter64> - 64 bit counter,range:[0-9223372036854775808]	number of multicast bytes transmitted on the channel pair (downstream) <i>This element is only shown in detail mode.</i>
txucbyte	Parameter type: <OctetCounter64> - 64 bit counter,range:[0-9223372036854775808]	number of unicast bytes transmitted on the channel pair (downstream) <i>This element is only shown in detail mode.</i>
rxtotbyte	Parameter type: <OctetCounter64> - 64 bit counter,range:[0-9223372036854775808]	total number of bytes received on the channel pair (upstream) <i>This element is only shown in detail mode.</i>
txtotfrm	Parameter type: <OctetCounter64> - 64 bit counter,range:[0-9223372036854775808]	total number of packets transmitted on the channel pair (downstream) <i>This element is only shown in detail mode.</i>

117 Channel Pair Status Commands

name	Type	Description
		<i>detail mode.</i>
txbcfrm	Parameter type: <OctetCounter64> - 64 bit counter,range:[0-9223372036854775808]	number of broadcast packets transmitted on the channel pair (downstream) <i>This element is only shown in detail mode.</i>
txmcfrm	Parameter type: <OctetCounter64> - 64 bit counter,range:[0-9223372036854775808]	number of multicast packets transmitted on the channel pair (downstream) <i>This element is only shown in detail mode.</i>
txucfrm	Parameter type: <OctetCounter64> - 64 bit counter,range:[0-9223372036854775808]	number of unicast packets transmitted on the channel pair (downstream) <i>This element is only shown in detail mode.</i>
rxtotfrm	Parameter type: <OctetCounter64> - 64 bit counter,range:[0-9223372036854775808]	total number of packets received on the channel pair (upstream) <i>This element is only shown in detail mode.</i>

Only Show Details: dropped counts		
name	Type	Description
txtotdropbyte	Parameter type: <OctetCounter64> - 64 bit counter,range:[0-9223372036854775808]	total number of bytes dropped destined for the channel pair (downstream) <i>This element is only shown in detail mode.</i>
txbcdropbyte	Parameter type: <OctetCounter64> - 64 bit counter,range:[0-9223372036854775808]	number of broadcast bytes dropped destined for the channel pair (downstream) <i>This element is only shown in detail mode.</i>
txmcdropbyte	Parameter type: <OctetCounter64> - 64 bit counter,range:[0-9223372036854775808]	number of multicast bytes dropped destined for the channel pair (downstream) <i>This element is only shown in detail mode.</i>
txucdropbyte	Parameter type: <OctetCounter64> - 64 bit counter,range:[0-9223372036854775808]	number of unicast bytes dropped destined for the channel pair (downstream) <i>This element is only shown in detail mode.</i>
rxtotdropbyte	Parameter type: <OctetCounter64> - 64 bit counter,range:[0-9223372036854775808]	total number of bytes dropped received on the channel pair (upstream) <i>This element is only shown in detail mode.</i>
txtotdropfrm	Parameter type: <OctetCounter64> - 64 bit counter,range:[0-9223372036854775808]	total number of packets dropped destined for the channel pair (downstream) <i>This element is only shown in detail mode.</i>
txbcdropfrm	Parameter type: <OctetCounter64> - 64 bit counter,range:[0-9223372036854775808]	number of broadcast packets dropped destined for the channel pair (downstream) <i>This element is only shown in detail mode.</i>

117 Channel Pair Status Commands

name	Type	Description
txmcdropfrm	Parameter type: <OctetCounter64> - 64 bit counter,range:[0-9223372036854775808]	number of multicast packets dropped destined for the channel pair (downstream) <i>This element is only shown in detail mode.</i>
txucdropfrm	Parameter type: <OctetCounter64> - 64 bit counter,range:[0-9223372036854775808]	number of unicast packets dropped destined for the channel pair (downstream) <i>This element is only shown in detail mode.</i>
rxtotdropfrm	Parameter type: <OctetCounter64> - 64 bit counter,range:[0-9223372036854775808]	total number of packets dropped received on the channel pair (upstream) <i>This element is only shown in detail mode.</i>

Only Show Details: number of active onts on channel pair		
name	Type	Description
numactiveonts	Parameter type: <Gpon::NumActiveOnt> - number of active onts that carry atleast a minimum amount of traffic - range: [0...128]	number of active onts on the channel pair (carry more than a minimum amount of traffic) <i>This element is only shown in detail mode.</i>

117.15 Channel Pair Utilization Current Interval Top Five ONT Downstream PM Command

Command Description

This command retrieves the top 5 ONTs on the channel-pair ranked by downstream traffic for the current interval.

User Level

The command can be accessed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

```
> show channel-pair utilization cur-intvl-top-ont-tx [ (chanpair-idx) [ rank <Gpon::PonUtilOntRank> ] ]
```

Command Parameters

Table 117.15-1 "Channel Pair Utilization Current Interval Top Five ONT Downstream PM Command" Resource Parameters

Resource Identifier	Type	Description
(chanpair-idx)	Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::ChannelPairId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::ChannelPairId> - the channel pair identifier	channel pair ifindex
rank	Parameter type: <Gpon::PonUtilOntRank> Format: - rank of the ont - range: [1...5]	rank of the ont within the channel pair

Command Output

Table 117.15-2 "Channel Pair Utilization Current Interval Top Five ONT Downstream PM Command" Display parameters

Specific Information		
name	Type	Description
ont-idx	Parameter type: <Gpon::OntIndex>	ont ifindex

name	Type	Description
	(<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> ng2 : <Ng2::ChannelGroup> / <Ng2::SubchannelGroup> / <Ng2::OntId>) Possible values: - ng2 : ngpon2 style identification Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Ng2::ChannelGroup> - channel group number Field type <Ng2::SubchannelGroup> - subchannel group number Field type <Eqpt::OntId> - the ONT identifier Field type <Ng2::OntId> - the ONT identifier	<i>This element is always shown.</i>
txucutil	Parameter type: <Gpon::FloatPonUtilThousandPercent> - utilization percentage - unit: percentage - range: [0.00...1000.00]	transmit (downstream) unicast utilization (percentage) relative to the non-multicast channel-pair bandwidth [because the unicast bandwidth can exceed the non-multicast bandwidth, this value can exceed 100%] <i>This element is always shown.</i>

117.16 Channel Pair Utilization Current Interval Top Five ONT Upstream PM Command

Command Description

This command retrieves the top 5 ONTs on the channel-pair ranked by upstream traffic for the current interval.

User Level

The command can be accessed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

```
> show channel-pair utilization cur-intvl-top-ont-rx [ (chanpair-idx) [ rank <Gpon::PonUtilOntRank> ] ]
```

Command Parameters

Table 117.16-1 "Channel Pair Utilization Current Interval Top Five ONT Upstream PM Command" Resource Parameters

Resource Identifier	Type	Description
(chanpair-idx)	Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::ChannelPairId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::ChannelPairId> - the channel pair identifier	channel pair ifindex
rank	Parameter type: <Gpon::PonUtilOntRank> Format: - rank of the ont - range: [1...5]	rank of the ont within the channel pair

Command Output

Table 117.16-2 "Channel Pair Utilization Current Interval Top Five ONT Upstream PM Command" Display parameters

Specific Information		
name	Type	Description
ont-idx	Parameter type: <Gpon::OntIndex>	ont ifindex

name	Type	Description
	(<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> ng2 : <Ng2::ChannelGroup> / <Ng2::SubchannelGroup> / <Ng2::OntId>) Possible values: - ng2 : ngpon2 style identification Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Ng2::ChannelGroup> - channel group number Field type <Ng2::SubchannelGroup> - subchannel group number Field type <Eqpt::OntId> - the ONT identifier Field type <Ng2::OntId> - the ONT identifier	<i>This element is always shown.</i>
rxucutil	Parameter type: <Gpon::FloatPonUtilPercent> - utilization percentage - unit: percentage - range: [0.00...100.00]	receive (upstream) unicast utilization (percentage) relative to total channel-pair bandwidth <i>This element is always shown.</i>

117.17 Channel Pair Utilization Previous Interval PM Command

Command Description

This command retrieves channel-pair utilization previous interval performance monitoring data.

User Level

The command can be accessed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

```
> show channel-pair utilization previous-interval [ (chanpair-idx) [ interval-num <Gpon::FiveMinIntvlNo> ] ]
```

Command Parameters

Table 117.17-1 "Channel Pair Utilization Previous Interval PM Command" Resource Parameters

Resource Identifier	Type	Description
(chanpair-idx)	Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::ChannelPairId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::ChannelPairId> - the channel pair identifier	channel pair ifindex
interval-num	Parameter type: <Gpon::FiveMinIntvlNo> Format: - a number of a previous five minute interval number - range: [1...288]	previous five-min interval number (1 is the most recent)

Command Output

Table 117.17-2 "Channel Pair Utilization Previous Interval PM Command" Display parameters

Specific Information		
name	Type	Description
txtotutil	Parameter type: <Gpon::FloatPonUtilPercent> - utilization percentage - unit: percentage	transmit (downstream) total utilization (percentage) relative to the total bandwidth

name	Type	Description
	- range: [0.00...100.00]	<i>This element is always shown.</i>
txbcutil	Parameter type: <Gpon::FloatPonUtilThousandPercent> - utilization percentage - unit: percentage - range: [0.00...1000.00]	transmit (downstream) broadcast utilization (percentage) relative to the non-multicast bandwidth [because the broadcast bandwidth can exceed the non-multicast bandwidth, this value can exceed 100%] <i>This element is always shown.</i>
txmcutil	Parameter type: <Gpon::FloatPonUtilPercent> - utilization percentage - unit: percentage - range: [0.00...100.00]	transmit (downstream) multicast utilization (percentage) relative to the configured multicast bandwidth <i>This element is always shown.</i>
txucutil	Parameter type: <Gpon::FloatPonUtilThousandPercent> - utilization percentage - unit: percentage - range: [0.00...1000.00]	transmit (downstream) unicast utilization (percentage) relative to the non-multicast bandwidth [because the unicast bandwidth can exceed the non-multicast bandwidth, this value can exceed 100%] <i>This element is always shown.</i>
dbacongperiod	Parameter type: <Gpon::FloatPonUtilDbapercent> - utilization percentage - unit: percentage - range: [0.00...100.00]	dba (upstream) congestion period (percentage) [the percentage of the dba granting windows in which the dba congestion threshold was exceeded] <i>This element is always shown.</i>
rxtotutil	Parameter type: <Gpon::FloatPonUtilPercent> - utilization percentage - unit: percentage - range: [0.00...100.00]	receive (upstream) total utilization (percentage) relative to the total bandwidth <i>This element is always shown.</i>

Only Show Details: transmitted/received counts

name	Type	Description
txtotbyte	Parameter type: <OctetCounter64> - 64 bit counter,range:[0-9223372036854775808]	total number of bytes transmitted on the channel pair (downstream) <i>This element is only shown in detail mode.</i>
txbcbyte	Parameter type: <OctetCounter64> - 64 bit counter,range:[0-9223372036854775808]	number of broadcast bytes transmitted on the channel pair (downstream) <i>This element is only shown in detail mode.</i>
txmcbyte	Parameter type: <OctetCounter64> - 64 bit counter,range:[0-9223372036854775808]	number of multicast bytes transmitted on the channel pair (downstream) <i>This element is only shown in detail mode.</i>
txucbyte	Parameter type: <OctetCounter64> - 64 bit counter,range:[0-9223372036854775808]	number of unicast bytes transmitted on the channel pair (downstream) <i>This element is only shown in detail mode.</i>
rxtotbyte	Parameter type: <OctetCounter64> - 64 bit counter,range:[0-9223372036854775808]	total number of bytes received on the channel pair (upstream) <i>This element is only shown in detail mode.</i>

117 Channel Pair Status Commands

name	Type	Description
txtotfrm	Parameter type: <OctetCounter64> - 64 bit counter,range:[0-9223372036854775808]	total number of packets transmitted on the channel pair (downstream) <i>This element is only shown in detail mode.</i>
txbcfrm	Parameter type: <OctetCounter64> - 64 bit counter,range:[0-9223372036854775808]	number of broadcast packets transmitted on the channel pair (downstream) <i>This element is only shown in detail mode.</i>
txmcfrm	Parameter type: <OctetCounter64> - 64 bit counter,range:[0-9223372036854775808]	number of multicast packets transmitted on the channel pair (downstream) <i>This element is only shown in detail mode.</i>
txucfrm	Parameter type: <OctetCounter64> - 64 bit counter,range:[0-9223372036854775808]	number of unicast packets transmitted on the channel pair (downstream) <i>This element is only shown in detail mode.</i>
rxtotfrm	Parameter type: <OctetCounter64> - 64 bit counter,range:[0-9223372036854775808]	total number of packets received on the channel pair (upstream) <i>This element is only shown in detail mode.</i>

Only Show Details: dropped counts		
name	Type	Description
txtotdropbyte	Parameter type: <OctetCounter64> - 64 bit counter,range:[0-9223372036854775808]	total number of bytes dropped destined for the channel pair (downstream) <i>This element is only shown in detail mode.</i>
txbcdropbyte	Parameter type: <OctetCounter64> - 64 bit counter,range:[0-9223372036854775808]	number of broadcast bytes dropped destined for the channel pair (downstream) <i>This element is only shown in detail mode.</i>
txmcdropbyte	Parameter type: <OctetCounter64> - 64 bit counter,range:[0-9223372036854775808]	number of multicast bytes dropped destined for the channel pair (downstream) <i>This element is only shown in detail mode.</i>
txucdropbyte	Parameter type: <OctetCounter64> - 64 bit counter,range:[0-9223372036854775808]	number of unicast bytes dropped destined for the channel pair (downstream) <i>This element is only shown in detail mode.</i>
rxtotdropbyte	Parameter type: <OctetCounter64> - 64 bit counter,range:[0-9223372036854775808]	total number of bytes dropped received on the channel pair (upstream) <i>This element is only shown in detail mode.</i>
txtotdropfrm	Parameter type: <OctetCounter64> - 64 bit counter,range:[0-9223372036854775808]	total number of packets dropped destined for the channel pair (downstream) <i>This element is only shown in detail mode.</i>
txbcdropfrm	Parameter type: <OctetCounter64>	number of broadcast packets

117 Channel Pair Status Commands

name	Type	Description
	- 64 bit counter,range:[0-9223372036854775808]	dropped destined for the channel pair (downstream) <i>This element is only shown in detail mode.</i>
txmcdropfrm	Parameter type: <OctetCounter64> - 64 bit counter,range:[0-9223372036854775808]	number of multicast packets dropped destined for the channel pair (downstream) <i>This element is only shown in detail mode.</i>
txucdropfrm	Parameter type: <OctetCounter64> - 64 bit counter,range:[0-9223372036854775808]	number of unicast packets dropped destined for the channel pair (downstream) <i>This element is only shown in detail mode.</i>
rxtotdropfrm	Parameter type: <OctetCounter64> - 64 bit counter,range:[0-9223372036854775808]	total number of packets dropped received on the channel pair (upstream) <i>This element is only shown in detail mode.</i>

Only Show Details: number of active onts on channel pair		
name	Type	Description
numactiveonts	Parameter type: <Gpon::NumActiveOnt> - number of active onts that carry atleast a minimum amount of traffic - range: [0...128]	number of active Onts on the channel pair (carry more than a minimum amount of traffic) <i>This element is only shown in detail mode.</i>

117.18 Channel Pair Utilization Previous Interval Top Five ONT Downstream PM Command

Command Description

This command retrieves the top 5 ONTs on the channel-pair ranked by downstream traffic for previous intervals.

User Level

The command can be accessed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

```
> show channel-pair utilization prv-intvl-top-ont-tx [ (chanpair-idx) [ interval-num <Gpon::FiveMinIntvlNo> ] [ rank <Gpon::PonUtilOntRank> ] ]
```

Command Parameters

Table 117.18-1 "Channel Pair Utilization Previous Interval Top Five ONT Downstream PM Command" Resource Parameters

Resource Identifier	Type	Description
(chanpair-idx)	Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::ChannelPairId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::ChannelPairId> - the channel pair identifier	channel pair ifindex
interval-num	Parameter type: <Gpon::FiveMinIntvlNo> Format: - a number of a previous five minute interval number - range: [1...288]	previous five-min interval number (1 is the most recent)
rank	Parameter type: <Gpon::PonUtilOntRank> Format: - rank of the ont - range: [1...5]	rank of the ont within the channel pair

Command Output

Table 117.18-2 "Channel Pair Utilization Previous Interval Top Five ONT Downstream PM

Command" Display parameters

Specific Information		
name	Type	Description
ont-idx	Parameter type: <Gpon::OntIndex> (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> ng2 : <Ng2::ChannelGroup> / <Ng2::SubchannelGroup> / <Ng2::OntId>) Possible values: - ng2 : ngpon2 style identification Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Ng2::ChannelGroup> - channel group number Field type <Ng2::SubchannelGroup> - subchannel group number Field type <Eqpt::OntId> - the ONT identifier Field type <Ng2::OntId> - the ONT identifier	ont ifindex <i>This element is always shown.</i>
txucutil	Parameter type: <Gpon::FloatPonUtilThousandPercent> - utilization percentage - unit: percentage - range: [0.00...1000.00]	transmit (downstream) unicast utilization (percentage) relative to the non-multicast channel-pair bandwidth [because the unicast bandwidth can exceed the non-multicast bandwidth, this value can exceed 100%] <i>This element is always shown.</i>

117.19 Channel Pair Utilization Previous Interval Top Five ONT Upstream PM Command

Command Description

This command retrieves the top 5 ONTs on the channel-pair ranked by upstream traffic for previous intervals.

User Level

The command can be accessed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

```
> show channel-pair utilization prv-intvl-top-ont-rx [ (chanpair-idx) [ interval-num <Gpon::FiveMinIntvlNo> ] [ rank <Gpon::PonUtilOntRank> ] ]
```

Command Parameters

Table 117.19-1 "Channel Pair Utilization Previous Interval Top Five ONT Upstream PM Command" Resource Parameters

Resource Identifier	Type	Description
(chanpair-idx)	Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::ChannelPairId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::ChannelPairId> - the channel pair identifier	channel pair ifindex
interval-num	Parameter type: <Gpon::FiveMinIntvlNo> Format: - a number of a previous five minute interval number - range: [1...288]	previous five-min interval number (1 is the most recent)
rank	Parameter type: <Gpon::PonUtilOntRank> Format: - rank of the ont - range: [1...5]	rank of the ont within the channel pair

Command Output

Table 117.19-2 "Channel Pair Utilization Previous Interval Top Five ONT Upstream PM

Command" Display parameters

Specific Information		
name	Type	Description
ont-idx	Parameter type: <Gpon::OntIndex> (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> ng2 : <Ng2::ChannelGroup> / <Ng2::SubchannelGroup> / <Ng2::OntId>) Possible values: - ng2 : ngpon2 style identification Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Ng2::ChannelGroup> - channel group number Field type <Ng2::SubchannelGroup> - subchannel group number Field type <Eqpt::OntId> - the ONT identifier Field type <Ng2::OntId> - the ONT identifier	ont ifindex <i>This element is always shown.</i>
rxucutil	Parameter type: <Gpon::FloatPonUtilPercent> - utilization percentage - unit: percentage - range: [0.00...100.00]	receive (upstream) unicast utilization (percentage) relative to total channel-pair bandwidth <i>This element is always shown.</i>

117.20 Channel Pair Peak Utilization Current Interval PM Command

Command Description

This command retrieves channel-pair peak utilization current interval performance monitoring data.

User Level

The command can be accessed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

> show channel-pair peak-utilization current-interval [(chanpair-idx)]

Command Parameters

Table 117.20-1 "Channel Pair Peak Utilization Current Interval PM Command" Resource Parameters

Resource Identifier	Type	Description
(chanpair-idx)	Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::ChannelPairId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::ChannelPairId> - the channel pair identifier	channel pair ifindex

Command Output

Table 117.20-2 "Channel Pair Peak Utilization Current Interval PM Command" Display parameters

Specific Information		
name	Type	Description
txpkucutil	Parameter type: <Gpon::FloatPonUtilThousandPercent> - utilization percentage - unit: percentage - range: [0.00...1000.00]	transmit (downstream) peak unicast utilization (percentage) relative to the non-multicast bandwidth [because the unicast bandwidth can exceed the

name	Type	Description
		non-multicast bandwidth, this value can exceed 100%] <i>This element is always shown.</i>
rxpktotutil	Parameter type: <Gpon::FloatPonUtilPercent> - utilization percentage - unit: percentage - range: [0.00...100.00]	receive (upstream) total peak utilization (percentage) relative to the total bandwidth <i>This element is always shown.</i>

Only Show Details: transmitted/received counts

name	Type	Description
txpkucbyte	Parameter type: <OctetCounter64> - 64 bit counter,range:[0-9223372036854775808]	number of peak unicast bytes transmitted on the channel pair (downstream) <i>This element is only shown in detail mode.</i>
rxpktotbyte	Parameter type: <OctetCounter64> - 64 bit counter,range:[0-9223372036854775808]	total number of peak bytes received on the channel pair (upstream) <i>This element is only shown in detail mode.</i>
txpkucfrm	Parameter type: <OctetCounter64> - 64 bit counter,range:[0-9223372036854775808]	number of peak unicast packets transmitted on the channel pair (downstream) <i>This element is only shown in detail mode.</i>
rxpktotfrm	Parameter type: <OctetCounter64> - 64 bit counter,range:[0-9223372036854775808]	total number of peak packets received on the channel pair (upstream) <i>This element is only shown in detail mode.</i>

117.21 Channel Pair Peak Utilization Current Interval Top Five ONT Downstream PM Command

Command Description

This command retrieves the top 5 ONTs on the channel-pair ranked by peak downstream traffic for the current interval.

User Level

The command can be accessed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

```
> show channel-pair peak-utilization cur-intvl-top-ont-tx [ (chanpair-idx) [ rank <Gpon::PonUtilOntRank> ] ]
```

Command Parameters

Table 117.21-1 "Channel Pair Peak Utilization Current Interval Top Five ONT Downstream PM Command" Resource Parameters

Resource Identifier	Type	Description
(chanpair-idx)	Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::ChannelPairId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::ChannelPairId> - the channel pair identifier	channel pair ifindex
rank	Parameter type: <Gpon::PonUtilOntRank> Format: - rank of the ont - range: [1...5]	rank of the ont within the channel pair

Command Output

Table 117.21-2 "Channel Pair Peak Utilization Current Interval Top Five ONT Downstream PM Command" Display parameters

Specific Information

name	Type	Description
ont-idx	Parameter type: <Gpon::OntIndex> (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> ng2 : <Ng2::ChannelGroup> / <Ng2::SubchannelGroup> / <Ng2::OntId>) Possible values: - ng2 : ngpon2 style identification Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Ng2::ChannelGroup> - channel group number Field type <Ng2::SubchannelGroup> - subchannel group number Field type <Eqpt::OntId> - the ONT identifier Field type <Ng2::OntId> - the ONT identifier	ont ifindex <i>This element is always shown.</i>
txpkucutil	Parameter type: <Gpon::FloatPonUtilThousandPercent> - utilization percentage - unit: percentage - range: [0.00...1000.00]	transmit (downstream) peak unicast utilization (percentage) relative to the non-multicast channel-pair bandwidth [because the unicast bandwidth can exceed the non-multicast bandwidth, this value can exceed 100%] <i>This element is always shown.</i>

117.22 Channel Pair Peak Utilization Current Interval Top Five ONT Upstream PM Command

Command Description

This command retrieves the top 5 ONTs on the channel-pair ranked by peak upstream traffic for the current interval.

User Level

The command can be accessed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

```
> show channel-pair peak-utilization cur-intvl-top-ont-rx [ (chanpair-idx) [ rank <Gpon::PonUtilOntRank> ] ]
```

Command Parameters

Table 117.22-1 "Channel Pair Peak Utilization Current Interval Top Five ONT Upstream PM Command" Resource Parameters

Resource Identifier	Type	Description
(chanpair-idx)	Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::ChannelPairId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::ChannelPairId> - the channel pair identifier	channel pair ifindex
rank	Parameter type: <Gpon::PonUtilOntRank> Format: - rank of the ont - range: [1...5]	rank of the ont within the channel pair

Command Output

Table 117.22-2 "Channel Pair Peak Utilization Current Interval Top Five ONT Upstream PM Command" Display parameters

Specific Information

name	Type	Description
ont-idx	Parameter type: <Gpon::OntIndex> (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> ng2 : <Ng2::ChannelGroup> / <Ng2::SubchannelGroup> / <Ng2::OntId>) Possible values: - ng2 : ngpon2 style identification Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Ng2::ChannelGroup> - channel group number Field type <Ng2::SubchannelGroup> - subchannel group number Field type <Eqpt::OntId> - the ONT identifier Field type <Ng2::OntId> - the ONT identifier	ont ifindex <i>This element is always shown.</i>
rxpktotutil	Parameter type: <Gpon::FloatPonUtilPercent> - utilization percentage - unit: percentage - range: [0.00...100.00]	receive (upstream) total peak utilization (percentage) relative to total channel-pair bandwidth <i>This element is always shown.</i>

117.23 Channel Pair Peak Utilization Previous Interval PM Command

Command Description

This command retrieves channel-pair peak utilization previous interval performance monitoring data.

User Level

The command can be accessed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

```
> show channel-pair peak-utilization previous-interval [ (chanpair-idx) [ interval-num <Gpon::FiveMinIntvlNo> ] ]
```

Command Parameters

Table 117.23-1 "Channel Pair Peak Utilization Previous Interval PM Command" Resource Parameters

Resource Identifier	Type	Description
(chanpair-idx)	Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::ChannelPairId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::ChannelPairId> - the channel pair identifier	channel pair ifindex
interval-num	Parameter type: <Gpon::FiveMinIntvlNo> Format: - a number of a previous five minute interval number - range: [1...288]	previous five-min interval number (1 is the most recent)

Command Output

Table 117.23-2 "Channel Pair Peak Utilization Previous Interval PM Command" Display parameters

Specific Information		
name	Type	Description
txpkucutil	Parameter type: <Gpon::FloatPonUtilThousandPercent>	transmit (downstream) peak

name	Type	Description
	- utilization percentage - unit: percentage - range: [0.00...1000.00]	unicast utilization (percentage) relative to the non-multicast bandwidth [because the unicast bandwidth can exceed the non-multicast bandwidth, this value can exceed 100%] <i>This element is always shown.</i>
rxpktotutil	Parameter type: <Gpon::FloatPonUtilPercent> - utilization percentage - unit: percentage - range: [0.00...100.00]	receive (upstream) total peak utilization (percentage) relative to the total bandwidth <i>This element is always shown.</i>

Only Show Details: transmitted/received counts		
name	Type	Description
txpkucbyte	Parameter type: <OctetCounter64> - 64 bit counter,range:[0-9223372036854775808]	number of peak unicast bytes transmitted on the channel pair (downstream) <i>This element is only shown in detail mode.</i>
rxpktotbyte	Parameter type: <OctetCounter64> - 64 bit counter,range:[0-9223372036854775808]	total number of peak bytes received on the channel pair (upstream) <i>This element is only shown in detail mode.</i>
txpkucfrm	Parameter type: <OctetCounter64> - 64 bit counter,range:[0-9223372036854775808]	number of peak unicast packets transmitted on the channel pair (downstream) <i>This element is only shown in detail mode.</i>
rxpktotfrm	Parameter type: <OctetCounter64> - 64 bit counter,range:[0-9223372036854775808]	total number of peak packets received on the channel pair (upstream) <i>This element is only shown in detail mode.</i>

117.24 Channel Pair Peak Utilization Previous Interval Top Five ONT Downstream PM Command

Command Description

This command retrieves the top 5 ONTs on the channel-pair ranked by peak downstream traffic for previous intervals.

User Level

The command can be accessed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

```
> show channel-pair peak-utilization prv-intvl-top-ont-tx [ (chanpair-idx) [ interval-num <Gpon::FiveMinIntvlNo> ] [ rank <Gpon::PonUtilOntRank> ] ]
```

Command Parameters

Table 117.24-1 "Channel Pair Peak Utilization Previous Interval Top Five ONT Downstream PM Command" Resource Parameters

Resource Identifier	Type	Description
(chanpair-idx)	Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::ChannelPairId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::ChannelPairId> - the channel pair identifier	channel pair ifindex
interval-num	Parameter type: <Gpon::FiveMinIntvlNo> Format: - a number of a previous five minute interval number - range: [1...288]	previous five-min interval number (1 is the most recent)
rank	Parameter type: <Gpon::PonUtilOntRank> Format: - rank of the ont - range: [1...5]	rank of the ont within the channel pair

Command Output

Table 117.24-2 "Channel Pair Peak Utilization Previous Interval Top Five ONT Downstream PM Command" Display parameters

Specific Information		
name	Type	Description
ont-idx	Parameter type: <Gpon::OntIndex> (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> ng2 : <Ng2::ChannelGroup> / <Ng2::SubchannelGroup> / <Ng2::OntId>) Possible values: - ng2 : ngpon2 style identification Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Ng2::ChannelGroup> - channel group number Field type <Ng2::SubchannelGroup> - subchannel group number Field type <Eqpt::OntId> - the ONT identifier Field type <Ng2::OntId> - the ONT identifier	ont ifindex <i>This element is always shown.</i>
txpkucutil	Parameter type: <Gpon::FloatPonUtilThousandPercent> - utilization percentage - unit: percentage - range: [0.00...1000.00]	transmit (downstream) peak unicast utilization (percentage) relative to the non-multicast channel-pair bandwidth [because the unicast bandwidth can exceed the non-multicast bandwidth, this value can exceed 100%] <i>This element is always shown.</i>

117.25 Channel Pair Peak Utilization Previous Interval Top Five ONT Upstream PM Command

Command Description

This command retrieves the top 5 ONTs on the channel-pair ranked by peak upstream traffic for previous intervals.

User Level

The command can be accessed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

```
> show channel-pair peak-utilization prv-intvl-top-ont-rx [ (chanpair-idx) [ interval-num <Gpon::FiveMinIntvlNo> ] [ rank <Gpon::PonUtilOntRank> ] ]
```

Command Parameters

Table 117.25-1 "Channel Pair Peak Utilization Previous Interval Top Five ONT Upstream PM Command" Resource Parameters

Resource Identifier	Type	Description
(chanpair-idx)	Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::ChannelPairId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::ChannelPairId> - the channel pair identifier	channel pair ifindex
interval-num	Parameter type: <Gpon::FiveMinIntvlNo> Format: - a number of a previous five minute interval number - range: [1...288]	previous five-min interval number (1 is the most recent)
rank	Parameter type: <Gpon::PonUtilOntRank> Format: - rank of the ont - range: [1...5]	rank of the ont within the channel pair

Command Output

Table 117.25-2 "Channel Pair Peak Utilization Previous Interval Top Five ONT Upstream PM

Command" Display parameters

Specific Information		
name	Type	Description
ont-idx	Parameter type: <Gpon::OntIndex> (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> ng2 : <Ng2::ChannelGroup> / <Ng2::SubchannelGroup> / <Ng2::OntId>) Possible values: - ng2 : ngpon2 style identification Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Ng2::ChannelGroup> - channel group number Field type <Ng2::SubchannelGroup> - subchannel group number Field type <Eqpt::OntId> - the ONT identifier Field type <Ng2::OntId> - the ONT identifier	ont ifindex <i>This element is always shown.</i>
rxpktotutil	Parameter type: <Gpon::FloatPonUtilPercent> - utilization percentage - unit: percentage - range: [0.00...100.00]	receive (upstream) peak unicast utilization (percentage) relative to total channel-pair bandwidth <i>This element is always shown.</i>

118- Uni Ont Gem-port Status Commands

118.1 Uni Ont Gem-port Status Command Tree	118-5835
118.2 Uni Gem-port Olt-side Current Interval Status Command	118-5836
118.3 Uni Gem-port Olt-side Previous Interval Status Command	118-5838
118.4 Uni Gem-port Ont-side Current Interval Status Command	118-5840
118.5 Uni Gem-port Ont-side Previous Interval Status Command	118-5842

118.1 Uni Ont Gem-port Status Command Tree

Description

This chapter gives an overview of nodes that are handled by "Uni Ont Gem-port Status Commands".

Command Tree

```
----show
  ----uni
    ----ont
      ----tc-layer
        ----olt-side
          ----current-interval
            - (ont-index)
          ----previous-interval
            - (ont-index)
            - interval-nbr
        ----ont-side
          ----current-interval
            - (ont-index)
          ----previous-interval
            - (ont-index)
            - interval-nbr
```

118.2 Uni Gem-port Olt-side Current Interval Status Command

Command Description

This command displays the entries of the uni oltside gemport's current interval.

User Level

The command can be accessed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

```
> show uni ont tc-layer olt-side current-interval [ (ont-index) ]
```

Command Parameters

Table 118.2-1 "Uni Gem-port Olt-side Current Interval Status Command" Resource Parameters

Resource Identifier	Type	Description
(ont-index)	Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Gpon::OntSlotId> / <Gpon::OntPortId> ng2 : <Ng2::ChannelGroup> / <Ng2::SubchannelGroup> / <Ng2::OntId> / <Gpon::OntSlotId> / <Gpon::OntPortId>) Possible values: - ng2 : ngpon2 style identification Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Ng2::ChannelGroup> - channel group number Field type <Ng2::SubchannelGroup> - subchannel group number Field type <Eqpt::OntId> - the ONT identifier Field type <Ng2::OntId> - the ONT identifier Field type <Gpon::OntSlotId> - Gpon Ont Slot	gpon ont index

Resource Identifier	Type	Description
	- range: [1...14] - Field type <Gpon::OntPortId> - Gpon Ont Port - range: [1...16]	

Command Output

Table 118.2-2 "Uni Gem-port Olt-side Current Interval Status Command" Display parameters

Specific Information		
name	Type	Description
lost-frags-down	Parameter type: <Counter> - 32 bit counter	a count of lost gem fragments downstream <i>This element is always shown.</i>
lost-frags-up	Parameter type: <Counter> - 32 bit counter	a count of lost gem fragments upstream <i>This element is always shown.</i>
receive-frags	Parameter type: <Counter> - 32 bit counter	a count of received gem fragments <i>This element is always shown.</i>
transmit-frags	Parameter type: <Counter> - 32 bit counter	a count of transmitted gem fragments <i>This element is always shown.</i>
receive-blocks	Parameter type: <Counter> - 32 bit counter	a count of received gem blocks <i>This element is always shown.</i>
transmit-blocks	Parameter type: <Counter> - 32 bit counter	a count of transmitted gem blocks <i>This element is always shown.</i>

118.3 Uni Gem-port Olt-side Previous Interval Status Command

Command Description

This command displays the entries of the uni oltside gemport's previous interval.

User Level

The command can be accessed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

```
> show uni ont tc-layer olt-side previous-interval [ (ont-index) [ interval-nbr <Gpon::UniIntervalnbr> ] ]
```

Command Parameters

Table 118.3-1 "Uni Gem-port Olt-side Previous Interval Status Command" Resource Parameters

Resource Identifier	Type	Description
(ont-index)	Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Gpon::OntSlotId> / <Gpon::OntPortId> ng2 : <Ng2::ChannelGroup> / <Ng2::SubchannelGroup> / <Ng2::OntId> / <Gpon::OntSlotId> / <Gpon::OntPortId>) Possible values: - ng2 : ngpon2 style identification Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Ng2::ChannelGroup> - channel group number Field type <Ng2::SubchannelGroup> - subchannel group number Field type <Eqpt::OntId> - the ONT identifier Field type <Ng2::OntId> - the ONT identifier Field type <Gpon::OntSlotId> - Gpon Ont Slot	gpon ont index

Resource Identifier	Type	Description
	- range: [1...14] Field type <Gpon::OntPortId> - Gpon Ont Port - range: [1...16]	
interval-nbr	Parameter type: <Gpon::UniIntervalnbr> Format: - the interval number - range: [1...32]	the interval number

Command Output

Table 118.3-2 "Uni Gem-port Olt-side Previous Interval Status Command" Display parameters

Specific Information		
name	Type	Description
lost-frags-down	Parameter type: <Counter> - 32 bit counter	a count of lost gem fragments downstream <i>This element is always shown.</i>
lost-frags-up	Parameter type: <Counter> - 32 bit counter	a count of lost gem fragments upstream <i>This element is always shown.</i>
receive-frags	Parameter type: <Counter> - 32 bit counter	a count of received gem fragments <i>This element is always shown.</i>
transmit-frags	Parameter type: <Counter> - 32 bit counter	a count of transmitted gem fragments <i>This element is always shown.</i>
receive-blocks	Parameter type: <Counter> - 32 bit counter	a count of received gem blocks <i>This element is always shown.</i>
transmit-blocks	Parameter type: <Counter> - 32 bit counter	a count of transmitted gem blocks <i>This element is always shown.</i>

118.4 Uni Gem-port Ont-side Current Interval Status Command

Command Description

This command displays the entries of the uni onside gemport's current interval.

User Level

The command can be accessed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

```
> show uni ont tc-layer ont-side current-interval [ (ont-index) ]
```

Command Parameters

Table 118.4-1 "Uni Gem-port Ont-side Current Interval Status Command" Resource Parameters

Resource Identifier	Type	Description
(ont-index)	Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Gpon::OntSlotId> / <Gpon::OntPortId> ng2 : <Ng2::ChannelGroup> / <Ng2::SubchannelGroup> / <Ng2::OntId> / <Gpon::OntSlotId> / <Gpon::OntPortId>) Possible values: - ng2 : ngpon2 style identification Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Ng2::ChannelGroup> - channel group number Field type <Ng2::SubchannelGroup> - subchannel group number Field type <Eqpt::OntId> - the ONT identifier Field type <Ng2::OntId> - the ONT identifier Field type <Gpon::OntSlotId> - Gpon Ont Slot	gpon ont index

Resource Identifier	Type	Description
	- range: [1...14] - Field type <Gpon::OntPortId> - Gpon Ont Port - range: [1...16]	

Command Output

Table 118.4-2 "Uni Gem-port Ont-side Current Interval Status Command" Display parameters

Specific Information		
name	Type	Description
lost-frags-down	Parameter type: <Counter> - 32 bit counter	a count of lost gem fragments downstream <i>This element is always shown.</i>
lost-frags-up	Parameter type: <Counter> - 32 bit counter	a count of lost gem fragments upstream <i>This element is always shown.</i>
receive-frags	Parameter type: <Counter> - 32 bit counter	a count of received gem fragments <i>This element is always shown.</i>
transmit-frags	Parameter type: <Counter> - 32 bit counter	a count of transmitted gem fragments <i>This element is always shown.</i>
receive-blocks	Parameter type: <Counter> - 32 bit counter	a count of received gem blocks <i>This element is always shown.</i>
transmit-blocks	Parameter type: <Counter> - 32 bit counter	a count of transmitted gem blocks <i>This element is always shown.</i>

118.5 Uni Gem-port Ont-side Previous Interval Status Command

Command Description

This command displays the entries of the uni onside gemport's previous interval.

User Level

The command can be accessed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

```
> show uni ont tc-layer ont-side previous-interval [ (ont-index) [ interval-nbr <Gpon::UniIntervalnbr> ] ]
```

Command Parameters

Table 118.5-1 "Uni Gem-port Ont-side Previous Interval Status Command" Resource Parameters

Resource Identifier	Type	Description
(ont-index)	Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Gpon::OntSlotId> / <Gpon::OntPortId> ng2 : <Ng2::ChannelGroup> / <Ng2::SubchannelGroup> / <Ng2::OntId> / <Gpon::OntSlotId> / <Gpon::OntPortId>) Possible values: - ng2 : ngpon2 style identification Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Ng2::ChannelGroup> - channel group number Field type <Ng2::SubchannelGroup> - subchannel group number Field type <Eqpt::OntId> - the ONT identifier Field type <Ng2::OntId> - the ONT identifier Field type <Gpon::OntSlotId> - Gpon Ont Slot	gpon ont index

Resource Identifier	Type	Description
	- range: [1...14] Field type <Gpon::OntPortId> - Gpon Ont Port - range: [1...16]	
interval-nbr	Parameter type: <Gpon::UniIntervalnbr> Format: - the interval number - range: [1...32]	the interval number

Command Output

Table 118.5-2 "Uni Gem-port Ont-side Previous Interval Status Command" Display parameters

Specific Information		
name	Type	Description
lost-frags-down	Parameter type: <Counter> - 32 bit counter	a count of lost gem fragments downstream <i>This element is always shown.</i>
lost-frags-up	Parameter type: <Counter> - 32 bit counter	a count of lost gem fragments upstream <i>This element is always shown.</i>
receive-frags	Parameter type: <Counter> - 32 bit counter	a count of received gem fragments <i>This element is always shown.</i>
transmit-frags	Parameter type: <Counter> - 32 bit counter	a count of transmitted gem fragments <i>This element is always shown.</i>
receive-blocks	Parameter type: <Counter> - 32 bit counter	a count of received gem blocks <i>This element is always shown.</i>
transmit-blocks	Parameter type: <Counter> - 32 bit counter	a count of transmitted gem blocks <i>This element is always shown.</i>

119- CES Show Commands

119.1 CES Show Command Tree	119-5845
119.2 CES Service Operational Information	119-5846
119.3 CESPW Service Current Interval Statistics Command	119-5848
119.4 CESPW Service Previous Interval Statistics Command	119-5850
119.5 Current Interval OLT side PM status Command	119-5852
119.6 Previous Interval OLT side PM status Command	119-5854
119.7 Current Interval ONT side PM status Command	119-5856
119.8 Previous Interval ONT side PM status Command	119-5858
119.9 CESUNI Current Interval PM status Command	119-5860
119.10 CESUNI Previous Interval PM status Command	119-5862

119.1 CES Show Command Tree

Description

This chapter gives an overview of nodes that are handled by "CES Show Commands".

Command Tree

```

----show
  ----ces
    ----ont
      ----service
        ----operational-data
          - (uni-idx)
        ----pseudo-wire
          ----current-interval
            - (uni-idx)
          ----previous-interval
            - (uni-idx)
            - interval-nbr
        ----tc-layer
          ----olt-side
            ----current-interval
              - (uni-idx)
            ----previous-interval
              - (uni-idx)
              - interval-nbr
          ----ont-side
            ----current-interval
              - (uni-idx)
            ----previous-interval
              - (uni-idx)
              - interval-nbr
      ----line
        ----port
          ----current-interval
            - (ont-idx)
          ----previous-interval
            - (ont-idx)
            - interval-nbr

```

119.2 CES Service Operational Information

Command Description

This command displays operational information regarding a CES service.

User Level

The command can be accessed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

```
> show ces ont service operational-data [ (uni-idx) ]
```

Command Parameters

Table 119.2-1 "CES Service Operational Information" Resource Parameters

Resource Identifier	Type	Description
(uni-idx)	Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> / <Eqpt::OntPortId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Eqpt::OntId> - the ONT identifier Field type <Eqpt::OntSlotId> - the ONT SLOT identifier Field type <Eqpt::OntPortId> - the ONT PORT identifier	interface index of the ces ont uni

Command Output

Table 119.2-2 "CES Service Operational Information" Display parameters

Specific Information		
name	Type	Description
source-mac-address	Parameter type: <Ces::SourceMacAddress> - a mac-address (example : 01:02:03:04:05:06) (L2 only) - length: 6	source mac address <i>This element is always shown.</i>

119.3 CESPW Service Current Interval Statistics Command

Command Description

This command displays various statistics collected for a CES Service (pseudowire) during the current 15 minute interval of operation.

User Level

The command can be accessed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

```
> show ces ont service pseudo-wire current-interval [ (uni-idx) ]
```

Command Parameters

Table 119.3-1 "CESPW Service Current Interval Statistics Command" Resource Parameters

Resource Identifier	Type	Description
(uni-idx)	Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> / <Eqpt::OntPortId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Eqpt::OntId> - the ONT identifier Field type <Eqpt::OntSlotId> - the ONT SLOT identifier Field type <Eqpt::OntPortId> - the ONT PORT identifier	interface index of the ces ont uni

Command Output

Table 119.3-2 "CESPW Service Current Interval Statistics Command" Display parameters

Specific Information

name	Type	Description
rx-pkts	Parameter type: <Counter> - 32 bit counter	number of received packets <i>This element is always shown.</i>
tx-pkts	Parameter type: <Counter> - 32 bit counter	number of transmitted packets <i>This element is always shown.</i>
missing-pkts	Parameter type: <Counter> - 32 bit counter	number of lost packets <i>This element is always shown.</i>
misorder-pkts-usable	Parameter type: <Counter> - 32 bit counter	number of packets received out of order that can be successfully re-ordered <i>This element is always shown.</i>
misorder-pkts-dropped	Parameter type: <Counter> - 32 bit counter	number of packets received out of sequence that were discarded <i>This element is always shown.</i>
buff-over-under-runs	Parameter type: <Counter> - 32 bit counter	number of packets that were discarded as they arrived too late or too early <i>This element is always shown.</i>
malformed-pkts	Parameter type: <Counter> - 32 bit counter	number of malformed packets <i>This element is always shown.</i>
stray-pkts	Parameter type: <Counter> - 32 bit counter	number of packets whose ECID or RTP SSRC failed to match the expected value or were misdelivered <i>This element is always shown.</i>
lost-remote-pkts	Parameter type: <Counter> - 32 bit counter	number of received packets whose R bit is set indicating the loss of packets <i>This element is always shown.</i>
tx-tdm-lbit-pkts	Parameter type: <Counter> - 32 bit counter	number of packets transmitted with the L bit set indicating a near-end TDM fault <i>This element is always shown.</i>
es	Parameter type: <Counter> - 32 bit counter	count of errored seconds <i>This element is always shown.</i>
ses	Parameter type: <Counter> - 32 bit counter	count of severely errored seconds <i>This element is always shown.</i>
uas	Parameter type: <Counter> - 32 bit counter	count of unavailable seconds <i>This element is always shown.</i>

119.4 CESPW Service Previous Interval Statistics Command

Command Description

This command displays CES psuedowire service statistics collected at an ONT over the previous 8 hours of operation. The past 8 hours are broken into 32 completed 15 minute intervals.

User Level

The command can be accessed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

```
> show ces ont service pseudo-wire previous-interval [ (uni-idx) [ interval-nbr <Ces::IntervalNumber> ] ]
```

Command Parameters

Table 119.4-1 "CESPW Service Previous Interval Statistics Command" Resource Parameters

Resource Identifier	Type	Description
(uni-idx)	Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> / <Eqpt::OntPortId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Eqpt::OntId> - the ONT identifier Field type <Eqpt::OntSlotId> - the ONT SLOT identifier Field type <Eqpt::OntPortId> - the ONT PORT identifier	interface index of the ces ont uni
interval-nbr	Parameter type: <Ces::IntervalNumber> Format: - interval number - range: [1...32]	interval number

Command Output

Table 119.4-2 "CESPW Service Previous Interval Statistics Command" Display parameters

Specific Information		
name	Type	Description
rx-pkts	Parameter type: <Counter> - 32 bit counter	number of received packets <i>This element is always shown.</i>
tx-pkts	Parameter type: <Counter> - 32 bit counter	number of transmitted packets <i>This element is always shown.</i>
missing-pkts	Parameter type: <Counter> - 32 bit counter	number of lost packets <i>This element is always shown.</i>
misorder-pkts-usable	Parameter type: <Counter> - 32 bit counter	number of packets received out of order that can be successfully re-ordered <i>This element is always shown.</i>
misorder-pkts-dropped	Parameter type: <Counter> - 32 bit counter	number of packets received out of sequence that were discarded <i>This element is always shown.</i>
buff-over-under-runs	Parameter type: <Counter> - 32 bit counter	number of packets that were discarded as they arrived too late or too early <i>This element is always shown.</i>
malformed-pkts	Parameter type: <Counter> - 32 bit counter	number of malformed packets <i>This element is always shown.</i>
stray-pkts	Parameter type: <Counter> - 32 bit counter	number of packets whose ECID or RTP SSRC failed to match the expected value or were misdelivered <i>This element is always shown.</i>
lost-remote-pkts	Parameter type: <Counter> - 32 bit counter	number of received packets whose R bit is set indicating the loss of packets <i>This element is always shown.</i>
tx-tdm-lbit-pkts	Parameter type: <Counter> - 32 bit counter	number of packets transmitted with the L bit set indicating a near-end TDM fault <i>This element is always shown.</i>
es	Parameter type: <Counter> - 32 bit counter	count of errored seconds <i>This element is always shown.</i>
ses	Parameter type: <Counter> - 32 bit counter	count of severely errored seconds <i>This element is always shown.</i>
uas	Parameter type: <Counter> - 32 bit counter	count of unavailable seconds <i>This element is always shown.</i>

119.5 Current Interval OLT side PM status Command

Command Description

This command retrieves OLT-side TC layer performance monitoring data for current Interval

User Level

The command can be accessed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

> show ces ont service tc-layer olt-side current-interval [(uni-idx)]

Command Parameters

Table 119.5-1 "Current Interval OLT side PM status Command" Resource Parameters

Resource Identifier	Type	Description
(uni-idx)	Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> / <Eqpt::OntPortId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Eqpt::OntId> - the ONT identifier Field type <Eqpt::OntSlotId> - the ONT SLOT identifier Field type <Eqpt::OntPortId> - the ONT PORT identifier	This index is the ifIndex of the physical UNI

Command Output

Table 119.5-2 "Current Interval OLT side PM status Command" Display parameters

Specific Information

name	Type	Description
lost-frags-down	Parameter type: <Counter> - 32 bit counter	A count of Lost GEM Fragments (downstream) <i>This element is always shown.</i>
lost-frags-up	Parameter type: <Counter> - 32 bit counter	A count of Lost GEM Fragments (upstream) <i>This element is always shown.</i>
receive-frags	Parameter type: <Counter> - 32 bit counter	A count of Received GEM Fragments. <i>This element is always shown.</i>
transmit-frags	Parameter type: <Counter> - 32 bit counter	A count of Transmitted GEM Fragments. <i>This element is always shown.</i>
receive-blocks	Parameter type: <Counter> - 32 bit counter	A count of Received GEM Blocks. <i>This element is always shown.</i>
transmit-blocks	Parameter type: <Counter> - 32 bit counter	A count of Transmitted GEM Blocks. <i>This element is always shown.</i>

119.6 Previous Interval OLT side PM status

Command

Command Description

This command retrieves OLT-side TC layer performance monitoring data for previous Interval

User Level

The command can be accessed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

```
> show ces ont service tc-layer olt-side previous-interval [ (uni-idx) [ interval-nbr <Ces::IntervalNumber> ] ]
```

Command Parameters

Table 119.6-1 "Previous Interval OLT side PM status Command" Resource Parameters

Resource Identifier	Type	Description
(uni-idx)	Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> / <Eqpt::OntPortId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Eqpt::OntId> - the ONT identifier Field type <Eqpt::OntSlotId> - the ONT SLOT identifier Field type <Eqpt::OntPortId> - the ONT PORT identifier	This index is the ifIndex of the physical UNI
interval-nbr	Parameter type: <Ces::IntervalNumber> Format: - interval number - range: [1...32]	identifies prev 15min intvls, val 1 as the latest intvl

Command Output

Table 119.6-2 "Previous Interval OLT side PM status Command" Display parameters

Specific Information		
name	Type	Description
lost-frags-down	Parameter type: <Counter> - 32 bit counter	A count of Lost GEM Fragments (downstream) <i>This element is always shown.</i>
lost-frags-up	Parameter type: <Counter> - 32 bit counter	A count of Lost GEM Fragments (upstream) <i>This element is always shown.</i>
receive-frags	Parameter type: <Counter> - 32 bit counter	A count of Received GEM Fragments <i>This element is always shown.</i>
transmit-frags	Parameter type: <Counter> - 32 bit counter	A count of Transmitted GEM Fragments <i>This element is always shown.</i>
receive-blocks	Parameter type: <Counter> - 32 bit counter	A count of Received GEM Blocks. <i>This element is always shown.</i>
transmit-blocks	Parameter type: <Counter> - 32 bit counter	A count of Transmitted GEM Blocks <i>This element is always shown.</i>

119.7 Current Interval ONT side PM status Command

Command Description

This command retrieves ONT-side TC layer performance monitoring data for current Interval

User Level

The command can be accessed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

> show ces ont service tc-layer ont-side current-interval [(uni-idx)]

Command Parameters

Table 119.7-1 "Current Interval ONT side PM status Command" Resource Parameters

Resource Identifier	Type	Description
(uni-idx)	Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> / <Eqpt::OntPortId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Eqpt::OntId> - the ONT identifier Field type <Eqpt::OntSlotId> - the ONT SLOT identifier Field type <Eqpt::OntPortId> - the ONT PORT identifier	This index is the ifIndex of the physical UNI

Command Output

Table 119.7-2 "Current Interval ONT side PM status Command" Display parameters

Specific Information

name	Type	Description
lost-frags-down	Parameter type: <Counter> - 32 bit counter	A count of Lost GEM Fragments (downstream) <i>This element is always shown.</i>
lost-frags-up	Parameter type: <Counter> - 32 bit counter	A count of Lost GEM Fragments (upstream) <i>This element is always shown.</i>
receive-frags	Parameter type: <Counter> - 32 bit counter	A count of Received GEM Fragments. <i>This element is always shown.</i>
transmit-frags	Parameter type: <Counter> - 32 bit counter	A count of Transmitted GEM Fragments. <i>This element is always shown.</i>
receive-blocks	Parameter type: <Counter> - 32 bit counter	A count of Received GEM Blocks. <i>This element is always shown.</i>
transmit-blocks	Parameter type: <Counter> - 32 bit counter	A count of Transmitted GEM Blocks. <i>This element is always shown.</i>

119.8 Previous Interval ONT side PM status Command

Command Description

This command retrieves ONT-side TC layer performance monitoring data for previous Interval

User Level

The command can be accessed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

```
> show ces ont service tc-layer ont-side previous-interval [ (uni-idx) [ interval-nbr <Ces::IntervalNumber> ] ]
```

Command Parameters

Table 119.8-1 "Previous Interval ONT side PM status Command" Resource Parameters

Resource Identifier	Type	Description
(uni-idx)	Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> / <Eqpt::OntPortId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Eqpt::OntId> - the ONT identifier Field type <Eqpt::OntSlotId> - the ONT SLOT identifier Field type <Eqpt::OntPortId> - the ONT PORT identifier	This index is the ifIndex of the physical UNI
interval-nbr	Parameter type: <Ces::IntervalNumber> Format: - interval number - range: [1...32]	identifies prev 15min intvls, val 1 as the latest intvl

Command Output

Table 119.8-2 "Previous Interval ONT side PM status Command" Display parameters

Specific Information		
name	Type	Description
lost-frags-down	Parameter type: <Counter> - 32 bit counter	A count of Lost GEM Fragments (downstream) <i>This element is always shown.</i>
lost-frags-up	Parameter type: <Counter> - 32 bit counter	A count of Lost GEM Fragments (upstream) <i>This element is always shown.</i>
receive-frags	Parameter type: <Counter> - 32 bit counter	A count of Received GEM Fragments <i>This element is always shown.</i>
transmit-frags	Parameter type: <Counter> - 32 bit counter	A count of Transmitted GEM Fragments <i>This element is always shown.</i>
receive-blocks	Parameter type: <Counter> - 32 bit counter	A count of Received GEM Blocks. <i>This element is always shown.</i>
transmit-blocks	Parameter type: <Counter> - 32 bit counter	A count of Transmitted GEM Blocks <i>This element is always shown.</i>

119.9 CESUNI Current Interval PM status Command

Command Description

This command retrieves current Interval CESUNI performance monitoring data from the ONT(s)

User Level

The command can be accessed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

```
> show ces ont line port current-interval [ (ont-idx) ]
```

Command Parameters

Table 119.9-1 "CESUNI Current Interval PM status Command" Resource Parameters

Resource Identifier	Type	Description
(ont-idx)	Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Gpon::OntSlotId> / <Gpon::OntPortId> ng2 : <Ng2::ChannelGroup> / <Ng2::SubchannelGroup> / <Ng2::OntId> / <Gpon::OntSlotId> / <Gpon::OntPortId>) Possible values: - ng2 : ngpon2 style identification Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Ng2::ChannelGroup> - channel group number Field type <Ng2::SubchannelGroup> - subchannel group number Field type <Eqpt::OntId> - the ONT identifier Field type <Ng2::OntId> - the ONT identifier Field type <Gpon::OntSlotId> - Gpon Ont Slot - range: [1...14] Field type <Gpon::OntPortId> - Gpon Ont Port	interface index of the ces ont uni

Resource Identifier	Type	Description
	- range: [1...16]	

Command Output

Table 119.9-2 "CESUNI Current Interval PM status Command" Display parameters

Specific Information		
name	Type	Description
es	Parameter type: <Counter> - 32 bit counter	A count of Errored Seconds during this CurrentInterval <i>This element is always shown.</i>
ses	Parameter type: <Counter> - 32 bit counter	A count of Severely Errored Seconds during this CurrentInterval <i>This element is always shown.</i>
bes	Parameter type: <Counter> - 32 bit counter	A count of Bursty Errored Seconds during this CurrentInterval <i>This element is always shown.</i>
uas	Parameter type: <Counter> - 32 bit counter	A count of Unavailable Seconds during this CurrentInterval <i>This element is always shown.</i>
css	Parameter type: <Counter> - 32 bit counter	A count of Controlled Slip Seconds during this CurrentInterval <i>This element is always shown.</i>

119.10 CESUNI Previous Interval PM status

Command

Command Description

This command retrieves previous Interval CESUNI performance monitoring data from the ONT(s)

User Level

The command can be accessed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

```
> show ces ont line port previous-interval [ (ont-idx) [ interval-nbr <Ces::IntervalNumber> ] ]
```

Command Parameters

Table 119.10-1 "CESUNI Previous Interval PM status Command" Resource Parameters

Resource Identifier	Type	Description
(ont-idx)	Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Gpon::OntSlotId> / <Gpon::OntPortId> ng2 : <Ng2::ChannelGroup> / <Ng2::SubchannelGroup> / <Ng2::OntId> / <Gpon::OntSlotId> / <Gpon::OntPortId>) Possible values: - ng2 : ngpon2 style identification Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Ng2::ChannelGroup> - channel group number Field type <Ng2::SubchannelGroup> - subchannel group number Field type <Eqpt::OntId> - the ONT identifier Field type <Ng2::OntId> - the ONT identifier Field type <Gpon::OntSlotId> - Gpon Ont Slot	interface index of the ces ont uni

Resource Identifier	Type	Description
	- range: [1...14] Field type <Gpon::OntPortId> - Gpon Ont Port - range: [1...16]	
interval-nbr	Parameter type: <Ces::IntervalNumber> Format: - interval number - range: [1...32]	identifies prev 15min intvl, val 1 as the latest intvl

Command Output

Table 119.10-2 "CESUNI Previous Interval PM status Command" Display parameters

Specific Information		
name	Type	Description
es	Parameter type: <Counter> - 32 bit counter	A count of Errored Seconds during this interval <i>This element is always shown.</i>
ses	Parameter type: <Counter> - 32 bit counter	A count of Severely Errored Seconds during this interval <i>This element is always shown.</i>
bes	Parameter type: <Counter> - 32 bit counter	A count of Bursty Errored Seconds during this interval <i>This element is always shown.</i>
uas	Parameter type: <Counter> - 32 bit counter	A count of Unavailable Seconds during this interval <i>This element is always shown.</i>
css	Parameter type: <Counter> - 32 bit counter	A count of Controlled Slip Seconds during this interval <i>This element is always shown.</i>

120- ANI ONT Show Commands

120.1 ANI ONT Show Command Tree	120-5865
120.2 ANI ONT Operational-Data Status Command	120-5866
120.3 ANI ONT Video Status Command	120-5868
120.4 ANI ONT Video Stats Command	120-5871

120.1 ANI ONT Show Command Tree

Description

This chapter gives an overview of nodes that are handled by "ANI ONT Show Commands".

Command Tree

```
----show
  ----ani
    ----ont
      ----operational-data
        - (ont-index)
      ----video
        - (ont-index)
      ----video-stats
        - (ont-index)
```

120.2 ANI ONT Operational-Data Status Command

Command Description

This command reports a summary of current operational parameters for a specified ONT ANI.

User Level

The command can be accessed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

```
> show ani ont operational-data [ (ont-index) ]
```

Command Parameters

Table 120.2-1 "ANI ONT Operational-Data Status Command" Resource Parameters

Resource Identifier	Type	Description
(ont-index)	Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> ng2 : <Ng2::ChannelGroup> / <Ng2::SubchannelGroup> / <Ng2::OntId>) Possible values: - ng2 : ngpon2 style identification Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Ng2::ChannelGroup> - channel group number Field type <Ng2::SubchannelGroup> - subchannel group number Field type <Eqpt::OntId> - the ONT identifier Field type <Ng2::OntId> - the ONT identifier	a unique interface index

Command Output

Table 120.2-2 "ANI ONT Operational-Data Status Command" Display parameters

Specific Information

name	Type	Description
optical-signal-level1	Parameter type: <Gpon::OntOpticalSignalLevel> (unknown unsupported <Gpon::OpticalSignalLevel>) Possible values: - unknown : olt has not yet communicated with ont - unsupported : ont does not support the measurement of this attribute Field type <Gpon::OpticalSignalLevel> - ont receive / transmit optical signal level - unit: dbm - range: [-65.536...65.538]	indicates the current measurement of the total receive optical signal level. <i>This element is always shown.</i>

120.3 ANI ONT Video Status Command

Command Description

This command retrieves provisioned and discovered parameters for ONTVIDANIs.

User Level

The command can be accessed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

> show ani ont video [(ont-index)]

Command Parameters

Table 120.3-1 "ANI ONT Video Status Command" Resource Parameters

Resource Identifier	Type	Description
(ont-index)	Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> ng2 : <Ng2::ChannelGroup> / <Ng2::SubchannelGroup> / <Ng2::OntId>) Possible values: - ng2 : ngpon2 style identification Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Ng2::ChannelGroup> - channel group number Field type <Ng2::SubchannelGroup> - subchannel group number Field type <Eqpt::OntId> - the ONT identifier Field type <Ng2::OntId> - the ONT identifier	interface index of the port

Command Output

Table 120.3-2 "ANI ONT Video Status Command" Display parameters

Specific Information

name	Type	Description
freq-range-low	Parameter type: <Gpon::Freqlow> (no low band 50 - 550 mhz 50 - 750 mhz 50 - 870 mhz unknown) Possible values: - no low band : no low band is supported - 50 - 550 mhz : 50 - 550 mhz is supported - 50 - 750 mhz : 50 - 750 mhz is supported - 50 - 870 mhz : 50 - 870 mhz is supported - unknown : unknown	Indicates the lower of two frequency ranges supported. <i>This element is always shown.</i>
freq-range-high	Parameter type: <Gpon::Freqhigh> (no high band 550 - 750 mhz 550 - 870 mhz 950 - 2050 mhz 2150 - 3250 mhz 950 - 3250 mhz unknown) Possible values: - no high band : no high band is supported - 550 - 750 mhz : 550 - 750 mhz is supported - 550 - 870 mhz : 550 - 870 mhz is supported - 950 - 2050 mhz : 950 - 2050 mhz is supported - 2150 - 3250 mhz : 2150 - 3250 mhz is supported - 950 - 3250 mhz : 950 - 3250 mhz is supported - unknown : Unknown	Indicates the higher of two frequency ranges supported <i>This element is always shown.</i>
signal-capability	Parameter type: <Gpon::SignalCapability> (no-signal optical-power fixed-freq optical-fixed var-freq optical-var bb-rfpower optical-rfpower unknown) Possible values: - no-signal : no signal level capability is supported - optical-power : total optical power level is supported - fixed-freq : fixed freq pilot tone is supported - optical-fixed : total optical power level and fixed freq pilot tone is supported - var-freq : variable freq pilot tone is supported - optical-var : total optical power level and variable freq pilot tone is supported - bb-rfpower : broadband RF power level is supported - optical-rfpower : total optical power level and broadband RF power level is supported - unknown : unknown	Indicates the capability of the ONT to measure the video signal level. <i>This element is always shown.</i>
min-signal-level	Parameter type: <Gpon::SignalLevel> - Indicates the maximum/minimum optical RF power per channel - unit: dBuW - range: [0...256]	Indicates the minimum optical RF power per channel <i>This element is always shown.</i>
max-signal-level	Parameter type: <Gpon::SignalLevel>	Indicates the maximum optical

120 ANI ONT Show Commands

name	Type	Description
	- Indicates the maximum/minimum optical RF power per channel - unit: dBuW - range: [0...256]	RF power per channel <i>This element is always shown.</i>
planned-agc-mode	Parameter type: <Gpon::AgcMode> (no-agc broad-band-agc) Possible values: - no-agc : No AGC is used - broad-band-agc : Broadband RF AGC is used	Indicates the discovered value of ONT's AGC capabilities. <i>This element is always shown.</i>
actual-agc-mode	Parameter type: <Gpon::AgcMode> (no-agc broad-band-agc) Possible values: - no-agc : No AGC is used - broad-band-agc : Broadband RF AGC is used	Indicates the discovered value of ONT's AGC capabilities. <i>This element is always shown.</i>
state	Parameter type: <Gpon::OperState> (enabled disabled) Possible values: - enabled : enable the service - disabled : disable the service	Indicates operational state of the 1550 overlay reception capability <i>This element is always shown.</i>
min-signal-level-dbm	Parameter type: <Gpon::SignalLevelDbm> - Indicates the maximum/minimum optical RF power per channel in dBm - unit: dBm - range: [-30...226]	Indicates the minimum optical RF power per channel in dbm <i>This element is always shown.</i>
max-signal-level-dbm	Parameter type: <Gpon::SignalLevelDbm> - Indicates the maximum/minimum optical RF power per channel in dBm - unit: dBm - range: [-30...226]	Indicates the maximum optical RF power per channel in dbm <i>This element is always shown.</i>

120.4 ANI ONT Video Stats Command

Command Description

This command reports a summary of current operational parameters for a specified ONTVIDANI.

User Level

The command can be accessed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

```
> show ani ont video-stats [ (ont-index) ]
```

Command Parameters

Table 120.4-1 "ANI ONT Video Stats Command" Resource Parameters

Resource Identifier	Type	Description
(ont-index)	Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> ng2 : <Ng2::ChannelGroup> / <Ng2::SubchannelGroup> / <Ng2::OntId>) Possible values: - ng2 : ngpon2 style identification Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Ng2::ChannelGroup> - channel group number Field type <Ng2::SubchannelGroup> - subchannel group number Field type <Eqpt::OntId> - the ONT identifier Field type <Ng2::OntId> - the ONT identifier	interface index of the port

Command Output

Table 120.4-2 "ANI ONT Video Stats Command" Display parameters

Specific Information

120 ANI ONT Show Commands

name	Type	Description
opt-sig-level	Parameter type: <Gpon::SignalLevel> - Indicates the maximum/minimum optical RF power per channel - unit: dBuW - range: [0...256]	Total optical signal level in dBuW optical. <i>This element is always shown.</i>
pilot-level	Parameter type: <Gpon::SigPwrLevel> - Indicates the measurement of the pilot signal level or the broadband RF power level - unit: dBuV - range: [0...256]	Signal level of the Pilot frequency in dBuV optical <i>This element is always shown.</i>
opt-sig-level-dbm	Parameter type: <Gpon::SignalLevelDbm> - Indicates the maximum/minimum optical RF power per channel in dBm - unit: dBm - range: [-30...226]	Total optical signal level in dBm optical. <i>This element is always shown.</i>

121- L2UNI Show Commands

121.1 L2UNI Show Command Tree	121-5874
121.2 Current L2UNI ONT Status Command	121-5875
121.3 Previous L2UNI ONT Status Command	121-5879
121.4 Current L2UNI ONT Status Command	121-5883
121.5 Previous L2UNI ONT Status Command	121-5887
121.6 Current L2UNI ONT Status Command	121-5891
121.7 Previous L2UNI ONT Status Command	121-5895
121.8 Show muticast subscriber monitor Command	121-5899
121.9 Show active group list	121-5901

121.1 L2UNI Show Command Tree

Description

This chapter gives an overview of nodes that are handled by "L2UNI Show Commands".

Command Tree

```
----show
  ----l2uni
    ----ont
      ----performance-data
        ----current-interval
          - (if-index)
        ----previous-interval
          - (if-index)
          - interval-nbr
      ----performance-data-64bit
        ----current-interval
          - (if-index)
        ----previous-interval
          - (if-index)
          - interval-nbr
      ----performance-data-ext
        ----current-interval
          - (if-index)
        ----previous-interval
          - (if-index)
          - interval-nbr
      ----mcast-subscriber
        ----general
          - (if-index)
        ----active-groups
          - (if-index)
          - index
```

121.2 Current L2UNI ONT Status Command

Command Description

This retrieves Current Ethernet L2 performance monitoring data from the ONT UNI(s).

User Level

The command can be accessed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

```
> show l2uni ont performance-data current-interval [ (if-index) ]
```

Command Parameters

Table 121.2-1 "Current L2UNI ONT Status Command" Resource Parameters

Resource Identifier	Type	Description
(if-index)	Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Gpon::OntSlotId> / <Gpon::OntPortId> ng2 : <Ng2::ChannelGroup> / <Ng2::SubchannelGroup> / <Ng2::OntId> / <Gpon::OntSlotId> / <Gpon::OntPortId>) Possible values: - ng2 : ngpon2 style identification Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Ng2::ChannelGroup> - channel group number Field type <Ng2::SubchannelGroup> - subchannel group number Field type <Eqpt::OntId> - the ONT identifier Field type <Ng2::OntId> - the ONT identifier Field type <Gpon::OntSlotId> - Gpon Ont Slot - range: [1...14] Field type <Gpon::OntPortId> - Gpon Ont Port	interface index of the port

Resource Identifier	Type	Description
	- range: [1...16]	

Command Output

Table 121.2-2 "Current L2UNI ONT Status Command" Display parameters

Specific Information		
name	Type	Description
tx-frames	Parameter type: <Counter> - 32 bit counter	A count of Transmitted Ethernet Frames. <i>This element is always shown.</i>
rx-frames	Parameter type: <Counter> - 32 bit counter	A count of Received Ethernet Frames. <i>This element is always shown.</i>
tx-bytes	Parameter type: <OctetCounter64> - 64 bit counter,range:[0-9223372036854775808]	A count of Transmitted Ethernet Bytes. <i>This element is always shown.</i>
rx-bytes	Parameter type: <OctetCounter64> - 64 bit counter,range:[0-9223372036854775808]	A count of Received Ethernet Bytes. <i>This element is always shown.</i>
dropped-frames-up	Parameter type: <Counter> - 32 bit counter	A count of Dropped Frames Upstream. <i>This element is always shown.</i>
dropped-frames-dn	Parameter type: <Counter> - 32 bit counter	A count of Dropped Frames Downstream. <i>This element is always shown.</i>
tx-frames-multicast	Parameter type: <Counter> - 32 bit counter	A count of Transmitted Multicast Ethernet Frames. <i>This element is always shown.</i>
rx-frames-multicast	Parameter type: <Counter> - 32 bit counter	A count of Received Multicast Ethernet Frames. <i>This element is always shown.</i>
dropped-bytes-up	Parameter type: <Counter> - 32 bit counter	A count of Dropped Bytes Upstream <i>This element is only shown in detail mode.</i>
rx-dropped-evt	Parameter type: <Counter> - 32 bit counter	Number of events in which rx packets were dropped due to lack of resources <i>This element is only shown in detail mode.</i>
rx-frame-brdcast	Parameter type: <Counter> - 32 bit counter	The total number of received good packets directed to the broadcast address. <i>This element is only shown in detail mode.</i>
rx-crc-errframe	Parameter type: <Counter> - 32 bit counter	Number of rx packets that had crc error <i>This element is only shown in detail mode.</i>
rx-undersz-frame	Parameter type: <Counter> - 32 bit counter	Number of rx packets that were less than 64 octets long but were otherwise well formed <i>This element is only shown in detail mode.</i>
rx-oversz-frame	Parameter type: <Counter> - 32 bit counter	No of rx packets that were longer than 1518 octets and were

name	Type	Description
		otherwise well formed <i>This element is only shown in detail mode.</i>
rx-64-octet	Parameter type: <Counter> - 32 bit counter	No of rx packets that were 64 octets long <i>This element is only shown in detail mode.</i>
rx-65to127-octet	Parameter type: <Counter> - 32 bit counter	No of rx packets that were 65 to 127 octets long <i>This element is only shown in detail mode.</i>
rx-128to255-octet	Parameter type: <Counter> - 32 bit counter	No of rx packets that were 128 to 255 octets long <i>This element is only shown in detail mode.</i>
rx-256to511-octet	Parameter type: <Counter> - 32 bit counter	No of rx packets that were 256 to 511 octets long <i>This element is only shown in detail mode.</i>
rx-512to1023-oct	Parameter type: <Counter> - 32 bit counter	No of rx packets that were 512 to 1023 octets long <i>This element is only shown in detail mode.</i>
rx-1024to1518-oct	Parameter type: <Counter> - 32 bit counter	No of rx packets that were 1024 to 1518 octets long <i>This element is only shown in detail mode.</i>
tx-dropped-evt	Parameter type: <Counter> - 32 bit counter	Number of events in which tx packets were dropped due to lack of resources <i>This element is only shown in detail mode.</i>
tx-frame-brdcast	Parameter type: <Counter> - 32 bit counter	The total number of transmitted good packets directed to the broadcast address <i>This element is only shown in detail mode.</i>
tx-crc-errframe	Parameter type: <Counter> - 32 bit counter	Number of tx packets that had crc error <i>This element is only shown in detail mode.</i>
tx-undersz-frame	Parameter type: <Counter> - 32 bit counter	Number of tx packets that were less than 64 octets long but were otherwise well formed <i>This element is only shown in detail mode.</i>
tx-oversz-frame	Parameter type: <Counter> - 32 bit counter	No of tx packets that were longer than 1518 octets and were otherwise well formed <i>This element is only shown in detail mode.</i>
tx-64-octet	Parameter type: <Counter> - 32 bit counter	No of tx packets that were 64 octets long <i>This element is only shown in detail mode.</i>
tx-65to127-octet	Parameter type: <Counter> - 32 bit counter	No of tx packets that were 65 to 127 octets long

121 L2UNI Show Commands

name	Type	Description
		<i>This element is only shown in detail mode.</i>
tx-128to255-octet	Parameter type: <Counter> - 32 bit counter	No of tx packets that were 128 to 255 octets long <i>This element is only shown in detail mode.</i>
tx-256to511-octet	Parameter type: <Counter> - 32 bit counter	No of tx packets that were 256 to 511 octets long <i>This element is only shown in detail mode.</i>
tx-512to1023-oct	Parameter type: <Counter> - 32 bit counter	No of tx packets that were 512 to 1023 octets long <i>This element is only shown in detail mode.</i>
tx-1024to1518-oct	Parameter type: <Counter> - 32 bit counter	No of tx packets that were 1024 to 1518 octets long <i>This element is only shown in detail mode.</i>
rx-packets	Parameter type: <OctetCounter64> - 64 bit counter,range:[0-9223372036854775808]	The total number of upstream packets received <i>This element is only shown in detail mode.</i>
tx-packets	Parameter type: <OctetCounter64> - 64 bit counter,range:[0-9223372036854775808]	The total number of downstream packets transmitted <i>This element is only shown in detail mode.</i>

121.3 Previous L2UNI ONT Status Command

Command Description

This retrieves Previous Ethernet L2 performance monitoring data from the ONT UNI(s).

User Level

The command can be accessed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

```
> show l2uni ont performance-data previous-interval [ (if-index) [ interval-nbr <Gpon::IntervalNo> ] ]
```

Command Parameters

Table 121.3-1 "Previous L2UNI ONT Status Command" Resource Parameters

Resource Identifier	Type	Description
(if-index)	Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Gpon::OntSlotId> / <Gpon::OntPortId> ng2 : <Ng2::ChannelGroup> / <Ng2::SubchannelGroup> / <Ng2::OntId> / <Gpon::OntSlotId> / <Gpon::OntPortId>) Possible values: - ng2 : ngpon2 style identification Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Ng2::ChannelGroup> - channel group number Field type <Ng2::SubchannelGroup> - subchannel group number Field type <Eqpt::OntId> - the ONT identifier Field type <Ng2::OntId> - the ONT identifier Field type <Gpon::OntSlotId> - Gpon Ont Slot - range: [1...14] Field type <Gpon::OntPortId> - Gpon Ont Port	interface index of the port

Resource Identifier	Type	Description
	- range: [1...16]	
interval-nbr	Parameter type: <Gpon::IntervalNo> Format: - a number of a previous interval number - range: [1...32]	A number between 1 and 32

Command Output

Table 121.3-2 "Previous L2UNI ONT Status Command" Display parameters

Specific Information		
name	Type	Description
tx-frames	Parameter type: <Counter> - 32 bit counter	A count of Transmitted Ethernet Frames. <i>This element is always shown.</i>
rx-frames	Parameter type: <Counter> - 32 bit counter	A count of Received Ethernet Frames. <i>This element is always shown.</i>
tx-bytes	Parameter type: <OctetCounter64> - 64 bit counter,range:[0-9223372036854775808]	A count of Transmitted Ethernet Bytes. <i>This element is always shown.</i>
rx-bytes	Parameter type: <OctetCounter64> - 64 bit counter,range:[0-9223372036854775808]	A count of Received Ethernet Bytes. <i>This element is always shown.</i>
dropped-frames-up	Parameter type: <Counter> - 32 bit counter	A count of Dropped Frames Upstream. <i>This element is always shown.</i>
dropped-frames-dn	Parameter type: <Counter> - 32 bit counter	A count of Dropped Frames Downstream. <i>This element is always shown.</i>
tx-frames-multicast	Parameter type: <Counter> - 32 bit counter	A count of Transmitted Multicast Ethernet Frames. <i>This element is always shown.</i>
rx-frames-multicast	Parameter type: <Counter> - 32 bit counter	A count of Received Multicast Ethernet Frames. <i>This element is always shown.</i>
dropped-bytes-up	Parameter type: <Counter> - 32 bit counter	A count of Dropped Bytes Upstream <i>This element is only shown in detail mode.</i>
rx-dropped-evt	Parameter type: <Counter> - 32 bit counter	Number of events in which rx packets were dropped due to lack of resources <i>This element is only shown in detail mode.</i>
rx-frame-brdcast	Parameter type: <Counter> - 32 bit counter	The total number of received good packets directed to the broadcast address. <i>This element is only shown in detail mode.</i>
rx-crc-errframe	Parameter type: <Counter> - 32 bit counter	Number of rx packets that had crc error <i>This element is only shown in detail mode.</i>
rx-undersz-frame	Parameter type: <Counter> - 32 bit counter	Number of rx packets that were less than 64 octets long but were otherwise well formed

name	Type	Description
		<i>This element is only shown in detail mode.</i>
rx-oversz-frame	Parameter type: <Counter> - 32 bit counter	No of rx packets that were longer than 1518 octets and were otherwise well formed <i>This element is only shown in detail mode.</i>
rx-64-octet	Parameter type: <Counter> - 32 bit counter	No of rx packets that were 64 octets long <i>This element is only shown in detail mode.</i>
rx-65to127-octet	Parameter type: <Counter> - 32 bit counter	No of rx packets that were 65 to 127 octets long <i>This element is only shown in detail mode.</i>
rx-128to255-octet	Parameter type: <Counter> - 32 bit counter	No of rx packets that were 128 to 255 octets long <i>This element is only shown in detail mode.</i>
rx-256to511-octet	Parameter type: <Counter> - 32 bit counter	No of rx packets that were 256 to 511 octets long <i>This element is only shown in detail mode.</i>
rx-512to1023-oct	Parameter type: <Counter> - 32 bit counter	No of rx packets that were 512 to 1023 octets long <i>This element is only shown in detail mode.</i>
rx-1024to1518-oct	Parameter type: <Counter> - 32 bit counter	No of rx packets that were 1024 to 1518 octets long <i>This element is only shown in detail mode.</i>
tx-dropped-evt	Parameter type: <Counter> - 32 bit counter	Number of events in which tx packets were dropped due to lack of resources <i>This element is only shown in detail mode.</i>
tx-frame-brdcast	Parameter type: <Counter> - 32 bit counter	The total number of transmitted good packets directed to the broadcast address <i>This element is only shown in detail mode.</i>
tx-crc-errframe	Parameter type: <Counter> - 32 bit counter	Number of tx packets that had crc error <i>This element is only shown in detail mode.</i>
tx-undersz-frame	Parameter type: <Counter> - 32 bit counter	Number of tx packets that were less than 64 octets long but were otherwise well formed <i>This element is only shown in detail mode.</i>
tx-oversz-frame	Parameter type: <Counter> - 32 bit counter	No of tx packets that were longer than 1518 octets and were otherwise well formed <i>This element is only shown in detail mode.</i>
tx-64-octet	Parameter type: <Counter> - 32 bit counter	No of tx packets that were 64 octets long

121 L2UNI Show Commands

name	Type	Description
		<i>This element is only shown in detail mode.</i>
tx-65to127-octet	Parameter type: <Counter> - 32 bit counter	No of tx packets that were 65 to 127 octets long <i>This element is only shown in detail mode.</i>
tx-128to255-octet	Parameter type: <Counter> - 32 bit counter	No of tx packets that were 128 to 255 octets long <i>This element is only shown in detail mode.</i>
tx-256to511-octet	Parameter type: <Counter> - 32 bit counter	No of tx packets that were 256 to 511 octets long <i>This element is only shown in detail mode.</i>
tx-512to1023-oct	Parameter type: <Counter> - 32 bit counter	No of tx packets that were 512 to 1023 octets long <i>This element is only shown in detail mode.</i>
tx-1024to1518-oct	Parameter type: <Counter> - 32 bit counter	No of tx packets that were 1024 to 1518 octets long <i>This element is only shown in detail mode.</i>
rx-packets	Parameter type: <OctetCounter64> - 64 bit counter,range:[0-9223372036854775808]	The total number of upstream packets received <i>This element is only shown in detail mode.</i>
tx-packets	Parameter type: <OctetCounter64> - 64 bit counter,range:[0-9223372036854775808]	The total number of downstream packets transmitted <i>This element is only shown in detail mode.</i>

121.4 Current L2UNI ONT Status Command

Command Description

This retrieves Current Ethernet L2 performance monitoring data(64 bit) from the ONT UNI(s).

User Level

The command can be accessed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

```
> show l2uni ont performance-data-64bit current-interval [ (if-index) ]
```

Command Parameters

Table 121.4-1 "Current L2UNI ONT Status Command" Resource Parameters

Resource Identifier	Type	Description
(if-index)	Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Gpon::OntSlotId> / <Gpon::OntPortId> ng2 : <Ng2::ChannelGroup> / <Ng2::SubchannelGroup> / <Ng2::OntId> / <Gpon::OntSlotId> / <Gpon::OntPortId>) Possible values: - ng2 : ngpon2 style identification Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Ng2::ChannelGroup> - channel group number Field type <Ng2::SubchannelGroup> - subchannel group number Field type <Eqpt::OntId> - the ONT identifier Field type <Ng2::OntId> - the ONT identifier Field type <Gpon::OntSlotId> - Gpon Ont Slot - range: [1...14] Field type <Gpon::OntPortId> - Gpon Ont Port	interface index of the port

Resource Identifier	Type	Description
	- range: [1...16]	

Command Output

Table 121.4-2 "Current L2UNI ONT Status Command" Display parameters

Specific Information		
name	Type	Description
tx-frames	Parameter type: <OctetCounter64> - 64 bit counter,range:[0-9223372036854775808]	A count of Transmitted Ethernet Frames. <i>This element is always shown.</i>
rx-frames	Parameter type: <OctetCounter64> - 64 bit counter,range:[0-9223372036854775808]	A count of Received Ethernet Frames. <i>This element is always shown.</i>
tx-bytes	Parameter type: <OctetCounter64> - 64 bit counter,range:[0-9223372036854775808]	A count of Transmitted Ethernet Bytes. <i>This element is always shown.</i>
rx-bytes	Parameter type: <OctetCounter64> - 64 bit counter,range:[0-9223372036854775808]	A count of Received Ethernet Bytes. <i>This element is always shown.</i>
tx-frames-multicast	Parameter type: <OctetCounter64> - 64 bit counter,range:[0-9223372036854775808]	A count of Transmitted Multicast Ethernet Frames. <i>This element is always shown.</i>
rx-frames-multicast	Parameter type: <OctetCounter64> - 64 bit counter,range:[0-9223372036854775808]	A count of Received Multicast Ethernet Frames. <i>This element is always shown.</i>
rx-dropped-evt	Parameter type: <OctetCounter64> - 64 bit counter,range:[0-9223372036854775808]	Number of events in which rx packets were dropped due to lack of resources <i>This element is only shown in detail mode.</i>
rx-frame-brdcast	Parameter type: <OctetCounter64> - 64 bit counter,range:[0-9223372036854775808]	The total number of received good packets directed to the broadcast address. <i>This element is only shown in detail mode.</i>
rx-crc-errframe	Parameter type: <OctetCounter64> - 64 bit counter,range:[0-9223372036854775808]	Number of rx packets that had crc error <i>This element is only shown in detail mode.</i>
rx-undersz-frame	Parameter type: <OctetCounter64> - 64 bit counter,range:[0-9223372036854775808]	Number of rx packets that were less than 64 octets long but were otherwise well formed <i>This element is only shown in detail mode.</i>
rx-oversz-frame	Parameter type: <OctetCounter64> - 64 bit counter,range:[0-9223372036854775808]	No of rx packets that were longer than 1518 octets and were otherwise well formed <i>This element is only shown in detail mode.</i>
rx-64-octet	Parameter type: <OctetCounter64> - 64 bit counter,range:[0-9223372036854775808]	No of rx packets that were 64 octets long <i>This element is only shown in detail mode.</i>
rx-65to127-octet	Parameter type: <OctetCounter64> - 64 bit counter,range:[0-9223372036854775808]	No of rx packets that were 65 to 127 octets long <i>This element is only shown in</i>

name	Type	Description
		<i>detail mode.</i>
rx-128to255-octet	Parameter type: <OctetCounter64> - 64 bit counter,range:[0-9223372036854775808]	No of rx packets that were 128 to 255 octets long <i>This element is only shown in detail mode.</i>
rx-256to511-octet	Parameter type: <OctetCounter64> - 64 bit counter,range:[0-9223372036854775808]	No of rx packets that were 256 to 511 octets long <i>This element is only shown in detail mode.</i>
rx-512to1023-oct	Parameter type: <OctetCounter64> - 64 bit counter,range:[0-9223372036854775808]	No of rx packets that were 512 to 1023 octets long <i>This element is only shown in detail mode.</i>
rx-1024to1518-oct	Parameter type: <OctetCounter64> - 64 bit counter,range:[0-9223372036854775808]	No of rx packets that were 1024 to 1518 octets long <i>This element is only shown in detail mode.</i>
tx-dropped-evt	Parameter type: <OctetCounter64> - 64 bit counter,range:[0-9223372036854775808]	Number of events in which tx packets were dropped due to lack of resources <i>This element is only shown in detail mode.</i>
tx-frame-brdcast	Parameter type: <OctetCounter64> - 64 bit counter,range:[0-9223372036854775808]	The total number of transmitted good packets directed to the broadcast address <i>This element is only shown in detail mode.</i>
tx-crc-errframe	Parameter type: <OctetCounter64> - 64 bit counter,range:[0-9223372036854775808]	Number of tx packets that had crc error <i>This element is only shown in detail mode.</i>
tx-undersz-frame	Parameter type: <OctetCounter64> - 64 bit counter,range:[0-9223372036854775808]	Number of tx packets that were less than 64 octets long but were otherwise well formed <i>This element is only shown in detail mode.</i>
tx-oversz-frame	Parameter type: <OctetCounter64> - 64 bit counter,range:[0-9223372036854775808]	No of tx packets that were longer than 1518 octets and were otherwise well formed <i>This element is only shown in detail mode.</i>
tx-64-octet	Parameter type: <OctetCounter64> - 64 bit counter,range:[0-9223372036854775808]	No of tx packets that were 64 octets long <i>This element is only shown in detail mode.</i>
tx-65to127-octet	Parameter type: <OctetCounter64> - 64 bit counter,range:[0-9223372036854775808]	No of tx packets that were 65 to 127 octets long <i>This element is only shown in detail mode.</i>
tx-128to255-octet	Parameter type: <OctetCounter64> - 64 bit counter,range:[0-9223372036854775808]	No of tx packets that were 128 to 255 octets long <i>This element is only shown in detail mode.</i>
tx-256to511-octet	Parameter type: <OctetCounter64> - 64 bit counter,range:[0-9223372036854775808]	No of tx packets that were 256 to 511 octets long <i>This element is only shown in detail mode.</i>

121 L2UNI Show Commands

name	Type	Description
tx-512to1023-oct	Parameter type: <OctetCounter64> - 64 bit counter,range:[0-9223372036854775808]	No of tx packets that were 512 to 1023 octets long <i>This element is only shown in detail mode.</i>
tx-1024to1518-oct	Parameter type: <OctetCounter64> - 64 bit counter,range:[0-9223372036854775808]	No of tx packets that were 1024 to 1518 octets long <i>This element is only shown in detail mode.</i>

121.5 Previous L2UNI ONT Status Command

Command Description

This retrieves Previous Ethernet L2 performance monitoring data(64 bit) from the ONT UNI(s).

User Level

The command can be accessed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

```
> show l2uni ont performance-data-64bit previous-interval [ (if-index) [ interval-nbr <Gpon::IntervalNo> ] ]
```

Command Parameters

Table 121.5-1 "Previous L2UNI ONT Status Command" Resource Parameters

Resource Identifier	Type	Description
(if-index)	Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Gpon::OntSlotId> / <Gpon::OntPortId> ng2 : <Ng2::ChannelGroup> / <Ng2::SubchannelGroup> / <Ng2::OntId> / <Gpon::OntSlotId> / <Gpon::OntPortId>) Possible values: - ng2 : ngpon2 style identification Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Ng2::ChannelGroup> - channel group number Field type <Ng2::SubchannelGroup> - subchannel group number Field type <Eqpt::OntId> - the ONT identifier Field type <Ng2::OntId> - the ONT identifier Field type <Gpon::OntSlotId> - Gpon Ont Slot - range: [1...14] Field type <Gpon::OntPortId> - Gpon Ont Port	interface index of the port

Resource Identifier	Type	Description
	- range: [1...16]	
interval-nbr	Parameter type: <Gpon::IntervalNo> Format: - a number of a previous interval number - range: [1...32]	A number between 1 and 15

Command Output

Table 121.5-2 "Previous L2UNI ONT Status Command" Display parameters

Specific Information		
name	Type	Description
tx-frames	Parameter type: <OctetCounter64> - 64 bit counter,range:[0-9223372036854775808]	A count of Transmitted Ethernet Frames. <i>This element is always shown.</i>
rx-frames	Parameter type: <OctetCounter64> - 64 bit counter,range:[0-9223372036854775808]	A count of Received Ethernet Frames. <i>This element is always shown.</i>
tx-bytes	Parameter type: <OctetCounter64> - 64 bit counter,range:[0-9223372036854775808]	A count of Transmitted Ethernet Bytes. <i>This element is always shown.</i>
rx-bytes	Parameter type: <OctetCounter64> - 64 bit counter,range:[0-9223372036854775808]	A count of Received Ethernet Bytes. <i>This element is always shown.</i>
tx-frames-multicast	Parameter type: <OctetCounter64> - 64 bit counter,range:[0-9223372036854775808]	A count of Transmitted Multicast Ethernet Frames. <i>This element is always shown.</i>
rx-frames-multicast	Parameter type: <OctetCounter64> - 64 bit counter,range:[0-9223372036854775808]	A count of Received Multicast Ethernet Frames. <i>This element is always shown.</i>
rx-dropped-evt	Parameter type: <OctetCounter64> - 64 bit counter,range:[0-9223372036854775808]	Number of events in which rx packets were dropped due to lack of resources <i>This element is only shown in detail mode.</i>
rx-frame-brdcast	Parameter type: <OctetCounter64> - 64 bit counter,range:[0-9223372036854775808]	The total number of received good packets directed to the broadcast address. <i>This element is only shown in detail mode.</i>
rx-crc-errframe	Parameter type: <OctetCounter64> - 64 bit counter,range:[0-9223372036854775808]	Number of rx packets that had crc error <i>This element is only shown in detail mode.</i>
rx-undersz-frame	Parameter type: <OctetCounter64> - 64 bit counter,range:[0-9223372036854775808]	Number of rx packets that were less than 64 octets long but were otherwise well formed <i>This element is only shown in detail mode.</i>
rx-oversz-frame	Parameter type: <OctetCounter64> - 64 bit counter,range:[0-9223372036854775808]	No of rx packets that were longer than 1518 octets and were otherwise well formed <i>This element is only shown in detail mode.</i>
rx-64-octet	Parameter type: <OctetCounter64> - 64 bit counter,range:[0-9223372036854775808]	No of rx packets that were 64 octets long <i>This element is only shown in</i>

name	Type	Description
		<i>detail mode.</i>
rx-65to127-octet	Parameter type: <OctetCounter64> - 64 bit counter,range:[0-9223372036854775808]	No of rx packets that were 65 to 127 octets long <i>This element is only shown in detail mode.</i>
rx-128to255-octet	Parameter type: <OctetCounter64> - 64 bit counter,range:[0-9223372036854775808]	No of rx packets that were 128 to 255 octets long <i>This element is only shown in detail mode.</i>
rx-256to511-octet	Parameter type: <OctetCounter64> - 64 bit counter,range:[0-9223372036854775808]	No of rx packets that were 256 to 511 octets long <i>This element is only shown in detail mode.</i>
rx-512to1023-oct	Parameter type: <OctetCounter64> - 64 bit counter,range:[0-9223372036854775808]	No of rx packets that were 512 to 1023 octets long <i>This element is only shown in detail mode.</i>
rx-1024to1518-oct	Parameter type: <OctetCounter64> - 64 bit counter,range:[0-9223372036854775808]	No of rx packets that were 1024 to 1518 octets long <i>This element is only shown in detail mode.</i>
tx-dropped-evt	Parameter type: <OctetCounter64> - 64 bit counter,range:[0-9223372036854775808]	Number of events in which tx packets were dropped due to lack of resources <i>This element is only shown in detail mode.</i>
tx-frame-brdcast	Parameter type: <OctetCounter64> - 64 bit counter,range:[0-9223372036854775808]	The total number of transmitted good packets directed to the broadcast address <i>This element is only shown in detail mode.</i>
tx-crc-errframe	Parameter type: <OctetCounter64> - 64 bit counter,range:[0-9223372036854775808]	Number of tx packets that had crc error <i>This element is only shown in detail mode.</i>
tx-undersz-frame	Parameter type: <OctetCounter64> - 64 bit counter,range:[0-9223372036854775808]	Number of tx packets that were less than 64 octets long but were otherwise well formed <i>This element is only shown in detail mode.</i>
tx-oversz-frame	Parameter type: <OctetCounter64> - 64 bit counter,range:[0-9223372036854775808]	No of tx packets that were longer than 1518 octets and were otherwise well formed <i>This element is only shown in detail mode.</i>
tx-64-octet	Parameter type: <OctetCounter64> - 64 bit counter,range:[0-9223372036854775808]	No of tx packets that were 64 octets long <i>This element is only shown in detail mode.</i>
tx-65to127-octet	Parameter type: <OctetCounter64> - 64 bit counter,range:[0-9223372036854775808]	No of tx packets that were 65 to 127 octets long <i>This element is only shown in detail mode.</i>
tx-128to255-octet	Parameter type: <OctetCounter64> - 64 bit counter,range:[0-9223372036854775808]	No of tx packets that were 128 to 255 octets long <i>This element is only shown in detail mode.</i>

121 L2UNI Show Commands

name	Type	Description
tx-256to511-octet	Parameter type: <OctetCounter64> - 64 bit counter,range:[0-9223372036854775808]	No of tx packets that were 256 to 511 octets long <i>This element is only shown in detail mode.</i>
tx-512to1023-oct	Parameter type: <OctetCounter64> - 64 bit counter,range:[0-9223372036854775808]	No of tx packets that were 512 to 1023 octets long <i>This element is only shown in detail mode.</i>
tx-1024to1518-oct	Parameter type: <OctetCounter64> - 64 bit counter,range:[0-9223372036854775808]	No of tx packets that were 1024 to 1518 octets long <i>This element is only shown in detail mode.</i>

121.6 Current L2UNI ONT Status Command

Command Description

This retrieves Current Ethernet L2 performance monitoring extended data(32 bit) from the ONT UNI(s).

User Level

The command can be accessed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

```
> show l2uni ont performance-data-ext current-interval [ (if-index) ]
```

Command Parameters

Table 121.6-1 "Current L2UNI ONT Status Command" Resource Parameters

Resource Identifier	Type	Description
(if-index)	Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Gpon::OntSlotId> / <Gpon::OntPortId> ng2 : <Ng2::ChannelGroup> / <Ng2::SubchannelGroup> / <Ng2::OntId> / <Gpon::OntSlotId> / <Gpon::OntPortId>) Possible values: - ng2 : ngpon2 style identification Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Ng2::ChannelGroup> - channel group number Field type <Ng2::SubchannelGroup> - subchannel group number Field type <Eqpt::OntId> - the ONT identifier Field type <Ng2::OntId> - the ONT identifier Field type <Gpon::OntSlotId> - Gpon Ont Slot - range: [1...14] Field type <Gpon::OntPortId> - Gpon Ont Port	interface index of the port

Resource Identifier	Type	Description
	- range: [1...16]	

Command Output

Table 121.6-2 "Current L2UNI ONT Status Command" Display parameters

Specific Information		
name	Type	Description
tx-frames	Parameter type: <Counter> - 32 bit counter	A count of Transmitted Ethernet Frames. <i>This element is always shown.</i>
rx-frames	Parameter type: <Counter> - 32 bit counter	A count of Received Ethernet Frames. <i>This element is always shown.</i>
tx-bytes	Parameter type: <Counter> - 32 bit counter	A count of Transmitted Ethernet Bytes. <i>This element is always shown.</i>
rx-bytes	Parameter type: <Counter> - 32 bit counter	A count of Received Ethernet Bytes. <i>This element is always shown.</i>
tx-frames-multicast	Parameter type: <Counter> - 32 bit counter	A count of Transmitted Multicast Ethernet Frames. <i>This element is always shown.</i>
rx-frames-multicast	Parameter type: <Counter> - 32 bit counter	A count of Received Multicast Ethernet Frames. <i>This element is always shown.</i>
rx-dropped-evt	Parameter type: <Counter> - 32 bit counter	Number of events in which rx packets were dropped due to lack of resources <i>This element is only shown in detail mode.</i>
rx-frame-brdcast	Parameter type: <Counter> - 32 bit counter	The total number of received good packets directed to the broadcast address. <i>This element is only shown in detail mode.</i>
rx-crc-errframe	Parameter type: <Counter> - 32 bit counter	Number of rx packets that had crc error <i>This element is only shown in detail mode.</i>
rx-undersz-frame	Parameter type: <Counter> - 32 bit counter	Number of rx packets that were less than 64 octets long but were otherwise well formed <i>This element is only shown in detail mode.</i>
rx-oversz-frame	Parameter type: <Counter> - 32 bit counter	No of rx packets that were longer than 1518 octets and were otherwise well formed <i>This element is only shown in detail mode.</i>
rx-64-octet	Parameter type: <Counter> - 32 bit counter	No of rx packets that were 64 octets long <i>This element is only shown in detail mode.</i>
rx-65to127-octet	Parameter type: <Counter> - 32 bit counter	No of rx packets that were 65 to 127 octets long <i>This element is only shown in</i>

name	Type	Description
		<i>detail mode.</i>
rx-128to255-octet	Parameter type: <Counter> - 32 bit counter	No of rx packets that were 128 to 255 octets long <i>This element is only shown in detail mode.</i>
rx-256to511-octet	Parameter type: <Counter> - 32 bit counter	No of rx packets that were 256 to 511 octets long <i>This element is only shown in detail mode.</i>
rx-512to1023-oct	Parameter type: <Counter> - 32 bit counter	No of rx packets that were 512 to 1023 octets long <i>This element is only shown in detail mode.</i>
rx-1024to1518-oct	Parameter type: <Counter> - 32 bit counter	No of rx packets that were 1024 to 1518 octets long <i>This element is only shown in detail mode.</i>
tx-dropped-evt	Parameter type: <Counter> - 32 bit counter	Number of events in which tx packets were dropped due to lack of resources <i>This element is only shown in detail mode.</i>
tx-frame-brdcast	Parameter type: <Counter> - 32 bit counter	The total number of transmitted good packets directed to the broadcast address <i>This element is only shown in detail mode.</i>
tx-crc-errframe	Parameter type: <Counter> - 32 bit counter	Number of tx packets that had crc error <i>This element is only shown in detail mode.</i>
tx-undersz-frame	Parameter type: <Counter> - 32 bit counter	Number of tx packets that were less than 64 octets long but were otherwise well formed <i>This element is only shown in detail mode.</i>
tx-oversz-frame	Parameter type: <Counter> - 32 bit counter	No of tx packets that were longer than 1518 octets and were otherwise well formed <i>This element is only shown in detail mode.</i>
tx-64-octet	Parameter type: <Counter> - 32 bit counter	No of tx packets that were 64 octets long <i>This element is only shown in detail mode.</i>
tx-65to127-octet	Parameter type: <Counter> - 32 bit counter	No of tx packets that were 65 to 127 octets long <i>This element is only shown in detail mode.</i>
tx-128to255-octet	Parameter type: <Counter> - 32 bit counter	No of tx packets that were 128 to 255 octets long <i>This element is only shown in detail mode.</i>
tx-256to511-octet	Parameter type: <Counter> - 32 bit counter	No of tx packets that were 256 to 511 octets long <i>This element is only shown in detail mode.</i>

121 L2UNI Show Commands

name	Type	Description
tx-512to1023-oct	Parameter type: <Counter> - 32 bit counter	No of tx packets that were 512 to 1023 octets long <i>This element is only shown in detail mode.</i>
tx-1024to1518-oct	Parameter type: <Counter> - 32 bit counter	No of tx packets that were 1024 to 1518 octets long <i>This element is only shown in detail mode.</i>

121.7 Previous L2UNI ONT Status Command

Command Description

This retrieves Previous Ethernet L2 performance monitoring extended data(32 bit) from the ONT UNI(s).

User Level

The command can be accessed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

```
> show l2uni ont performance-data-ext previous-interval [ (if-index) [ interval-nbr <Gpon::IntervalNo> ] ]
```

Command Parameters

Table 121.7-1 "Previous L2UNI ONT Status Command" Resource Parameters

Resource Identifier	Type	Description
(if-index)	Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Gpon::OntSlotId> / <Gpon::OntPortId> ng2 : <Ng2::ChannelGroup> / <Ng2::SubchannelGroup> / <Ng2::OntId> / <Gpon::OntSlotId> / <Gpon::OntPortId>) Possible values: - ng2 : ngpon2 style identification Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Ng2::ChannelGroup> - channel group number Field type <Ng2::SubchannelGroup> - subchannel group number Field type <Eqpt::OntId> - the ONT identifier Field type <Ng2::OntId> - the ONT identifier Field type <Gpon::OntSlotId> - Gpon Ont Slot - range: [1...14] Field type <Gpon::OntPortId> - Gpon Ont Port	interface index of the port

Resource Identifier	Type	Description
	- range: [1...16]	
interval-nbr	Parameter type: <Gpon::IntervalNo> Format: - a number of a previous interval number - range: [1...32]	A number between 1 and 15

Command Output

Table 121.7-2 "Previous L2UNI ONT Status Command" Display parameters

Specific Information		
name	Type	Description
tx-frames	Parameter type: <Counter> - 32 bit counter	A count of Transmitted Ethernet Frames. <i>This element is always shown.</i>
rx-frames	Parameter type: <Counter> - 32 bit counter	A count of Received Ethernet Frames. <i>This element is always shown.</i>
tx-bytes	Parameter type: <Counter> - 32 bit counter	A count of Transmitted Ethernet Bytes. <i>This element is always shown.</i>
rx-bytes	Parameter type: <Counter> - 32 bit counter	A count of Received Ethernet Bytes. <i>This element is always shown.</i>
tx-frames-multicast	Parameter type: <Counter> - 32 bit counter	A count of Transmitted Multicast Ethernet Frames. <i>This element is always shown.</i>
rx-frames-multicast	Parameter type: <Counter> - 32 bit counter	A count of Received Multicast Ethernet Frames. <i>This element is always shown.</i>
rx-dropped-evt	Parameter type: <Counter> - 32 bit counter	Number of events in which rx packets were dropped due to lack of resources <i>This element is only shown in detail mode.</i>
rx-frame-brdcast	Parameter type: <Counter> - 32 bit counter	The total number of received good packets directed to the broadcast address. <i>This element is only shown in detail mode.</i>
rx-crc-errframe	Parameter type: <Counter> - 32 bit counter	Number of rx packets that had crc error <i>This element is only shown in detail mode.</i>
rx-undersz-frame	Parameter type: <Counter> - 32 bit counter	Number of rx packets that were less than 64 octets long but were otherwise well formed <i>This element is only shown in detail mode.</i>
rx-oversz-frame	Parameter type: <Counter> - 32 bit counter	No of rx packets that were longer than 1518 octets and were otherwise well formed <i>This element is only shown in detail mode.</i>
rx-64-octet	Parameter type: <Counter> - 32 bit counter	No of rx packets that were 64 octets long <i>This element is only shown in</i>

name	Type	Description
		<i>detail mode.</i>
rx-65to127-octet	Parameter type: <Counter> - 32 bit counter	No of rx packets that were 65 to 127 octets long <i>This element is only shown in detail mode.</i>
rx-128to255-octet	Parameter type: <Counter> - 32 bit counter	No of rx packets that were 128 to 255 octets long <i>This element is only shown in detail mode.</i>
rx-256to511-octet	Parameter type: <Counter> - 32 bit counter	No of rx packets that were 256 to 511 octets long <i>This element is only shown in detail mode.</i>
rx-512to1023-oct	Parameter type: <Counter> - 32 bit counter	No of rx packets that were 512 to 1023 octets long <i>This element is only shown in detail mode.</i>
rx-1024to1518-oct	Parameter type: <Counter> - 32 bit counter	No of rx packets that were 1024 to 1518 octets long <i>This element is only shown in detail mode.</i>
tx-dropped-evt	Parameter type: <Counter> - 32 bit counter	Number of events in which tx packets were dropped due to lack of resources <i>This element is only shown in detail mode.</i>
tx-frame-brdcast	Parameter type: <Counter> - 32 bit counter	The total number of transmitted good packets directed to the broadcast address <i>This element is only shown in detail mode.</i>
tx-crc-errframe	Parameter type: <Counter> - 32 bit counter	Number of tx packets that had crc error <i>This element is only shown in detail mode.</i>
tx-undersz-frame	Parameter type: <Counter> - 32 bit counter	Number of tx packets that were less than 64 octets long but were otherwise well formed <i>This element is only shown in detail mode.</i>
tx-oversz-frame	Parameter type: <Counter> - 32 bit counter	No of tx packets that were longer than 1518 octets and were otherwise well formed <i>This element is only shown in detail mode.</i>
tx-64-octet	Parameter type: <Counter> - 32 bit counter	No of tx packets that were 64 octets long <i>This element is only shown in detail mode.</i>
tx-65to127-octet	Parameter type: <Counter> - 32 bit counter	No of tx packets that were 65 to 127 octets long <i>This element is only shown in detail mode.</i>
tx-128to255-octet	Parameter type: <Counter> - 32 bit counter	No of tx packets that were 128 to 255 octets long <i>This element is only shown in detail mode.</i>

121 L2UNI Show Commands

name	Type	Description
tx-256to511-octet	Parameter type: <Counter> - 32 bit counter	No of tx packets that were 256 to 511 octets long <i>This element is only shown in detail mode.</i>
tx-512to1023-oct	Parameter type: <Counter> - 32 bit counter	No of tx packets that were 512 to 1023 octets long <i>This element is only shown in detail mode.</i>
tx-1024to1518-oct	Parameter type: <Counter> - 32 bit counter	No of tx packets that were 1024 to 1518 octets long <i>This element is only shown in detail mode.</i>

121.8 Show muticast subscriber monitor Command

Command Description

This retrieves muticast subscriber monitor general data except ipv4 active group list.

User Level

The command can be accessed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

```
> show l2uni ont mcast-subscriber general [ (if-index) ]
```

Command Parameters

Table 121.8-1 "Show muticast subscriber monitor Command" Resource Parameters

Resource Identifier	Type	Description
(if-index)	Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Gpon::OntSlotId> / <Gpon::OntPortId> ng2 : <Ng2::ChannelGroup> / <Ng2::SubchannelGroup> / <Ng2::OntId> / <Gpon::OntSlotId> / <Gpon::OntPortId>) Possible values: - ng2 : ngpon2 style identification Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Ng2::ChannelGroup> - channel group number Field type <Ng2::SubchannelGroup> - subchannel group number Field type <Eqpt::OntId> - the ONT identifier Field type <Ng2::OntId> - the ONT identifier Field type <Gpon::OntSlotId> - Gpon Ont Slot - range: [1...14] Field type <Gpon::OntPortId> - Gpon Ont Port	interface index of the port

Resource Identifier	Type	Description
	- range: [1...16]	

Command Output

Table 121.8-2 "Show muticast subscriber monitor Command" Display parameters

Specific Information		
name	Type	Description
cur-mcast-bw	Parameter type: <Counter> - 32 bit counter	ONU's best effort estimate of the actual bandwidth currently being delivered to this particular MAC bridge port. <i>This element is always shown.</i>
join-messages	Parameter type: <Counter> - 32 bit counter	The number of times the corresponding subscriber sent a join message that was accepted. <i>This element is always shown.</i>
bw-exceeded-num	Parameter type: <Counter> - 32 bit counter	A count of Transmitted Ethernet Bytes. <i>This element is always shown.</i>
act-grp-records	Parameter type: <Counter> - 32 bit counter	A count of Active group list record. <i>This element is always shown.</i>

121.9 Show active group list

Command Description

This retrieves ipv4 active group list detail data.

User Level

The command can be accessed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

```
> show l2uni ont mcast-subscriber active-groups [ (if-index) [ index <SignedInteger> ] ]
```

Command Parameters

Table 121.9-1 "Show active group list" Resource Parameters

Resource Identifier	Type	Description
(if-index)	Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Gpon::OntSlotId> / <Gpon::OntPortId> ng2 : <Ng2::ChannelGroup> / <Ng2::SubchannelGroup> / <Ng2::OntId> / <Gpon::OntSlotId> / <Gpon::OntPortId>) Possible values: - ng2 : ngpon2 style identification Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Ng2::ChannelGroup> - channel group number Field type <Ng2::SubchannelGroup> - subchannel group number Field type <Eqpt::OntId> - the ONT identifier Field type <Ng2::OntId> - the ONT identifier Field type <Gpon::OntSlotId> - Gpon Ont Slot - range: [1...14] Field type <Gpon::OntPortId> - Gpon Ont Port	interface index of the port

Resource Identifier	Type	Description
	- range: [1...16]	
index	Parameter type: <SignedInteger> Format: - a signed integer	ipv4 active group record index, between 0 and (Uni's active group records number -1)

Command Output

Table 121.9-2 "Show active group list" Display parameters

Specific Information		
name	Type	Description
vlan-id	Parameter type: <Vlan::VlanIndexOrZero> - vlan id - range: [0...4092]	vlan-id. <i>This element is always shown.</i>
src-ip-address	Parameter type: <Ip::V4Address> - IPv4-address	Source IP address. <i>This element is always shown.</i>
dest-ip-address	Parameter type: <Ip::V4Address> - IPv4-address	Multicast destination IP address. <i>This element is always shown.</i>
current-mcast-bw	Parameter type: <SignedInteger> - a signed integer	Best efforts actual bandwidth estimate. <i>This element is always shown.</i>
client-ip-addr	Parameter type: <Ip::V4Address> - IPv4-address	the IP address of the device currently joined. <i>This element is always shown.</i>
join-time	Parameter type: <SignedInteger> - a signed integer	Time passed in second(s) since the client joined the mcast group <i>This element is always shown.</i>

122- HPNA Show Commands

122.1 HPNA Show Command Tree	122-5904
122.2 Current HPNA ONT Status Command	122-5905
122.3 Previous L2UNI ONT Status Command	122-5909

122.1 HPNA Show Command Tree

Description

This chapter gives an overview of nodes that are handled by "HPNA Show Commands".

Command Tree

```
----show
  ----hpna
    ----ont
      ----performance-data
        ----current-interval
          - (if-index)
        ----previous-interval
          - (if-index)
          - interval-nbr
```

122.2 Current HPNA ONT Status Command

Command Description

This retrieves Current HPNA performance monitoring data from the ONT UNI(s).

User Level

The command can be accessed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

```
> show hpna ont performance-data current-interval [ (if-index) ]
```

Command Parameters

Table 122.2-1 "Current HPNA ONT Status Command" Resource Parameters

Resource Identifier	Type	Description
(if-index)	Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Gpon::OntSlotId> / <Gpon::OntPortId> ng2 : <Ng2::ChannelGroup> / <Ng2::SubchannelGroup> / <Ng2::OntId> / <Gpon::OntSlotId> / <Gpon::OntPortId>) Possible values: - ng2 : ngpon2 style identification Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Ng2::ChannelGroup> - channel group number Field type <Ng2::SubchannelGroup> - subchannel group number Field type <Eqpt::OntId> - the ONT identifier Field type <Ng2::OntId> - the ONT identifier Field type <Gpon::OntSlotId> - Gpon Ont Slot - range: [1...14] Field type <Gpon::OntPortId> - Gpon Ont Port	interface index of the port

Resource Identifier	Type	Description
	- range: [1...16]	

Command Output

Table 122.2-2 "Current HPNA ONT Status Command" Display parameters

Specific Information		
name	Type	Description
tx-frames	Parameter type: <Counter> - 32 bit counter	A count of Transmitted Ethernet Frames. <i>This element is always shown.</i>
rx-frames	Parameter type: <Counter> - 32 bit counter	A count of Received Ethernet Frames. <i>This element is always shown.</i>
tx-bytes	Parameter type: <OctetCounter64> - 64 bit counter,range:[0-9223372036854775808]	A count of Transmitted Ethernet Bytes. <i>This element is always shown.</i>
rx-bytes	Parameter type: <OctetCounter64> - 64 bit counter,range:[0-9223372036854775808]	A count of Received Ethernet Bytes. <i>This element is always shown.</i>
dropped-frames-up	Parameter type: <Counter> - 32 bit counter	A count of Dropped Frames Upstream. <i>This element is always shown.</i>
dropped-frames-dn	Parameter type: <Counter> - 32 bit counter	A count of Dropped Frames Downstream. <i>This element is always shown.</i>
tx-frames-multicast	Parameter type: <Counter> - 32 bit counter	A count of Transmitted Multicast Ethernet Frames. <i>This element is always shown.</i>
rx-frames-multicast	Parameter type: <Counter> - 32 bit counter	A count of Received Multicast Ethernet Frames. <i>This element is always shown.</i>
dropped-bytes-up	Parameter type: <Counter> - 32 bit counter	A count of Dropped Bytes Upstream <i>This element is only shown in detail mode.</i>
rx-dropped-evt	Parameter type: <Counter> - 32 bit counter	Number of events in which rx packets were dropped due to lack of resources <i>This element is only shown in detail mode.</i>
rx-frame-brdcast	Parameter type: <Counter> - 32 bit counter	The total number of received good packets directed to the broadcast address. <i>This element is only shown in detail mode.</i>
rx-crc-errframe	Parameter type: <Counter> - 32 bit counter	Number of rx packets that had crc error <i>This element is only shown in detail mode.</i>
rx-undersz-frame	Parameter type: <Counter> - 32 bit counter	Number of rx packets that were less than 64 octets long but were otherwise well formed <i>This element is only shown in detail mode.</i>
rx-oversz-frame	Parameter type: <Counter> - 32 bit counter	No of rx packets that were longer than 1518 octets and were

name	Type	Description
		otherwise well formed <i>This element is only shown in detail mode.</i>
rx-64-octet	Parameter type: <Counter> - 32 bit counter	No of rx packets that were 64 octets long <i>This element is only shown in detail mode.</i>
rx-65to127-octet	Parameter type: <Counter> - 32 bit counter	No of rx packets that were 65 to 127 octets long <i>This element is only shown in detail mode.</i>
rx-128to255-octet	Parameter type: <Counter> - 32 bit counter	No of rx packets that were 128 to 255 octets long <i>This element is only shown in detail mode.</i>
rx-256to511-octet	Parameter type: <Counter> - 32 bit counter	No of rx packets that were 256 to 511 octets long <i>This element is only shown in detail mode.</i>
rx-512to1023-oct	Parameter type: <Counter> - 32 bit counter	No of rx packets that were 512 to 1023 octets long <i>This element is only shown in detail mode.</i>
rx-1024to1518-oct	Parameter type: <Counter> - 32 bit counter	No of rx packets that were 1024 to 1518 octets long <i>This element is only shown in detail mode.</i>
tx-dropped-evt	Parameter type: <Counter> - 32 bit counter	Number of events in which tx packets were dropped due to lack of resources <i>This element is only shown in detail mode.</i>
tx-frame-brdcast	Parameter type: <Counter> - 32 bit counter	The total number of transmitted good packets directed to the broadcast address <i>This element is only shown in detail mode.</i>
tx-crc-errframe	Parameter type: <Counter> - 32 bit counter	Number of tx packets that had crc error <i>This element is only shown in detail mode.</i>
tx-undersz-frame	Parameter type: <Counter> - 32 bit counter	Number of tx packets that were less than 64 octets long but were otherwise well formed <i>This element is only shown in detail mode.</i>
tx-oversz-frame	Parameter type: <Counter> - 32 bit counter	No of tx packets that were longer than 1518 octets and were otherwise well formed <i>This element is only shown in detail mode.</i>
tx-64-octet	Parameter type: <Counter> - 32 bit counter	No of tx packets that were 64 octets long <i>This element is only shown in detail mode.</i>
tx-65to127-octet	Parameter type: <Counter> - 32 bit counter	No of tx packets that were 65 to 127 octets long

122 HPNA Show Commands

name	Type	Description
		<i>This element is only shown in detail mode.</i>
tx-128to255-octet	Parameter type: <Counter> - 32 bit counter	No of tx packets that were 128 to 255 octets long <i>This element is only shown in detail mode.</i>
tx-256to511-octet	Parameter type: <Counter> - 32 bit counter	No of tx packets that were 256 to 511 octets long <i>This element is only shown in detail mode.</i>
tx-512to1023-oct	Parameter type: <Counter> - 32 bit counter	No of tx packets that were 512 to 1023 octets long <i>This element is only shown in detail mode.</i>
tx-1024to1518-oct	Parameter type: <Counter> - 32 bit counter	No of tx packets that were 1024 to 1518 octets long <i>This element is only shown in detail mode.</i>
rx-packets	Parameter type: <OctetCounter64> - 64 bit counter,range:[0-9223372036854775808]	The total number of upstream packets received <i>This element is only shown in detail mode.</i>
tx-packets	Parameter type: <OctetCounter64> - 64 bit counter,range:[0-9223372036854775808]	The total number of downstream packets transmitted <i>This element is only shown in detail mode.</i>

122.3 Previous L2UNI ONT Status Command

Command Description

This retrieves Previous HPNA performance monitoring data from the ONT UNI(s).

User Level

The command can be accessed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

```
> show hpna ont performance-data previous-interval [ (if-index) [ interval-nbr <Gpon::IntervalNo> ] ]
```

Command Parameters

Table 122.3-1 "Previous L2UNI ONT Status Command" Resource Parameters

Resource Identifier	Type	Description
(if-index)	Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Gpon::OntSlotId> / <Gpon::OntPortId> ng2 : <Ng2::ChannelGroup> / <Ng2::SubchannelGroup> / <Ng2::OntId> / <Gpon::OntSlotId> / <Gpon::OntPortId>) Possible values: - ng2 : ngpon2 style identification Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Ng2::ChannelGroup> - channel group number Field type <Ng2::SubchannelGroup> - subchannel group number Field type <Eqpt::OntId> - the ONT identifier Field type <Ng2::OntId> - the ONT identifier Field type <Gpon::OntSlotId> - Gpon Ont Slot - range: [1...14] Field type <Gpon::OntPortId> - Gpon Ont Port	interface index of the port

Resource Identifier	Type	Description
	- range: [1...16]	
interval-nbr	Parameter type: <Gpon::IntervalNo> Format: - a number of a previous interval number - range: [1...32]	A number between 1 and 32

Command Output

Table 122.3-2 "Previous L2UNI ONT Status Command" Display parameters

Specific Information		
name	Type	Description
tx-frames	Parameter type: <Counter> - 32 bit counter	A count of Transmitted Ethernet Frames. <i>This element is always shown.</i>
rx-frames	Parameter type: <Counter> - 32 bit counter	A count of Received Ethernet Frames. <i>This element is always shown.</i>
tx-bytes	Parameter type: <OctetCounter64> - 64 bit counter,range:[0-9223372036854775808]	A count of Transmitted Ethernet Bytes. <i>This element is always shown.</i>
rx-bytes	Parameter type: <OctetCounter64> - 64 bit counter,range:[0-9223372036854775808]	A count of Received Ethernet Bytes. <i>This element is always shown.</i>
dropped-frames-up	Parameter type: <Counter> - 32 bit counter	A count of Dropped Frames Upstream. <i>This element is always shown.</i>
dropped-frames-dn	Parameter type: <Counter> - 32 bit counter	A count of Dropped Frames Downstream. <i>This element is always shown.</i>
tx-frames-multicast	Parameter type: <Counter> - 32 bit counter	A count of Transmitted Multicast Ethernet Frames. <i>This element is always shown.</i>
rx-frames-multicast	Parameter type: <Counter> - 32 bit counter	A count of Received Multicast Ethernet Frames. <i>This element is always shown.</i>
dropped-bytes-up	Parameter type: <Counter> - 32 bit counter	A count of Dropped Bytes Upstream <i>This element is only shown in detail mode.</i>
rx-dropped-evt	Parameter type: <Counter> - 32 bit counter	Number of events in which rx packets were dropped due to lack of resources <i>This element is only shown in detail mode.</i>
rx-frame-brdcast	Parameter type: <Counter> - 32 bit counter	The total number of received good packets directed to the broadcast address. <i>This element is only shown in detail mode.</i>
rx-crc-errframe	Parameter type: <Counter> - 32 bit counter	Number of rx packets that had crc error <i>This element is only shown in detail mode.</i>
rx-undersz-frame	Parameter type: <Counter> - 32 bit counter	Number of rx packets that were less than 64 octets long but were otherwise well formed

name	Type	Description
		<i>This element is only shown in detail mode.</i>
rx-oversz-frame	Parameter type: <Counter> - 32 bit counter	No of rx packets that were longer than 1518 octets and were otherwise well formed <i>This element is only shown in detail mode.</i>
rx-64-octet	Parameter type: <Counter> - 32 bit counter	No of rx packets that were 64 octets long <i>This element is only shown in detail mode.</i>
rx-65to127-octet	Parameter type: <Counter> - 32 bit counter	No of rx packets that were 65 to 127 octets long <i>This element is only shown in detail mode.</i>
rx-128to255-octet	Parameter type: <Counter> - 32 bit counter	No of rx packets that were 128 to 255 octets long <i>This element is only shown in detail mode.</i>
rx-256to511-octet	Parameter type: <Counter> - 32 bit counter	No of rx packets that were 256 to 511 octets long <i>This element is only shown in detail mode.</i>
rx-512to1023-oct	Parameter type: <Counter> - 32 bit counter	No of rx packets that were 512 to 1023 octets long <i>This element is only shown in detail mode.</i>
rx-1024to1518-oct	Parameter type: <Counter> - 32 bit counter	No of rx packets that were 1024 to 1518 octets long <i>This element is only shown in detail mode.</i>
tx-dropped-evt	Parameter type: <Counter> - 32 bit counter	Number of events in which tx packets were dropped due to lack of resources <i>This element is only shown in detail mode.</i>
tx-frame-brdcast	Parameter type: <Counter> - 32 bit counter	The total number of transmitted good packets directed to the broadcast address <i>This element is only shown in detail mode.</i>
tx-crc-errframe	Parameter type: <Counter> - 32 bit counter	Number of tx packets that had crc error <i>This element is only shown in detail mode.</i>
tx-undersz-frame	Parameter type: <Counter> - 32 bit counter	Number of tx packets that were less than 64 octets long but were otherwise well formed <i>This element is only shown in detail mode.</i>
tx-oversz-frame	Parameter type: <Counter> - 32 bit counter	No of tx packets that were longer than 1518 octets and were otherwise well formed <i>This element is only shown in detail mode.</i>
tx-64-octet	Parameter type: <Counter> - 32 bit counter	No of tx packets that were 64 octets long

122 HPNA Show Commands

name	Type	Description
		<i>This element is only shown in detail mode.</i>
tx-65to127-octet	Parameter type: <Counter> - 32 bit counter	No of tx packets that were 65 to 127 octets long <i>This element is only shown in detail mode.</i>
tx-128to255-octet	Parameter type: <Counter> - 32 bit counter	No of tx packets that were 128 to 255 octets long <i>This element is only shown in detail mode.</i>
tx-256to511-octet	Parameter type: <Counter> - 32 bit counter	No of tx packets that were 256 to 511 octets long <i>This element is only shown in detail mode.</i>
tx-512to1023-oct	Parameter type: <Counter> - 32 bit counter	No of tx packets that were 512 to 1023 octets long <i>This element is only shown in detail mode.</i>
tx-1024to1518-oct	Parameter type: <Counter> - 32 bit counter	No of tx packets that were 1024 to 1518 octets long <i>This element is only shown in detail mode.</i>
rx-packets	Parameter type: <OctetCounter64> - 64 bit counter,range:[0-9223372036854775808]	The total number of upstream packets received <i>This element is only shown in detail mode.</i>
tx-packets	Parameter type: <OctetCounter64> - 64 bit counter,range:[0-9223372036854775808]	The total number of downstream packets transmitted <i>This element is only shown in detail mode.</i>

123- Voice Ont IP Host Show Commands

123.1 Voice Ont IP Host Show Command Tree	123-5914
123.2 ONT IP Host Operational Data Status Command	123-5915
123.3 ONT IP Host Current 15min Statistics Status Command	123-5918

123.1 Voice Ont IP Host Show Command Tree

Description

This chapter gives an overview of nodes that are handled by "Voice Ont IP Host Show Commands".

Command Tree

```
----show
  ----iphost
    ----ont
      ----operational-data
        - (index)
      ----statistics
        ----current-15min
          - (index)
```

123.2 ONT IP Host Operational Data Status Command

Command Description

This command displays the latest operational information for an IP stack on the ONT

User Level

The command can be accessed by operators with sip,megaco,vlan privileges.

Command Syntax

The command has the following syntax:

```
> show iphost ont operational-data [ (index) ]
```

Command Parameters

Table 123.2-1 "ONT IP Host Operational Data Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: (ont : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Gpon::IpHostId> vlanport : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / vuni : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlanport : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / vuni : <Eqpt::UnstackedVlan> ont:ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / <Ng2::IpHostId> vlanport:ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / vuni : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlanport:ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / vuni : <Eqpt::UnstackedVlan>) Possible values: - ont:ng2 : ngpon2 ont - vlanport:ng2 : ngpon2 vlanport - ont : ont - vlanport : vlanport Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId>	a unique interface index

Resource Identifier	Type	Description
	- the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Eqpt::OntId> - the ONT identifier Field type <Eqpt::ChannelGroupId> - the channel group identifier Field type <Eqpt::SubChannelGroupId> - the subchannel group identifier Field type <Eqpt::Ng2OntId> - the NG2 ONT identifier Possible values: - vuni : virtual uni identifier Possible values: - vuni : virtual NGPON2 uni identifier Field type <Gpon::IpHostID> - iphost id Field type <Ng2::IpHostID> - iphost id (ngpon2) Possible values: - stacked : stacked vlan identity Field type <Eqpt::UnstackedVlan> - unstacked vlan id Field type <Eqpt::SVlan> - service vlan id Field type <Eqpt::CVlan> - customer vlan id	

Command Output

Table 123.2-2 "ONT IP Host Operational Data Status Command" Display parameters

Specific Information		
name	Type	Description
ip-address	Parameter type: <Gpon::ActualIpAddr> (undefined unknown not-supported <Ip::V4Address>) Possible values: - undefined : DHCP is unavailable - unknown : OLT could not communicate with ONT for discovery - not-supported : ONT doesnot support this activity Field type <Ip::V4Address> - IPv4-address	the current IP address for the IP host service <i>This element is always shown.</i>
net-mask	Parameter type: <Gpon::ActualIpAddr> (undefined unknown not-supported <Ip::V4Address>) Possible values: - undefined : DHCP is unavailable - unknown : OLT could not communicate with ONT for discovery	the current network mask for the IP host service <i>This element is always shown.</i>

name	Type	Description
	- not-supported : ONT doesnot support this activity Field type <Ip::V4Address> - IPv4-address	
default-router	Parameter type: <Gpon::ActualIpAddr> (undefined unknown not-supported <Ip::V4Address>) Possible values: - undefined : DHCP is unavailable - unknown : OLT could not communicate with ONT for discovery - not-supported : ONT doesnot support this activity Field type <Ip::V4Address> - IPv4-address	the current default router IP address for the IP host service <i>This element is always shown.</i>
dns-addr	Parameter type: <Gpon::ActualIpAddr> (undefined unknown not-supported <Ip::V4Address>) Possible values: - undefined : DHCP is unavailable - unknown : OLT could not communicate with ONT for discovery - not-supported : ONT doesnot support this activity Field type <Ip::V4Address> - IPv4-address	the current IP address of the primary DNS server for the IP host service <i>This element is always shown.</i>
sec-dns-addr	Parameter type: <Gpon::ActualIpAddr> (undefined unknown not-supported <Ip::V4Address>) Possible values: - undefined : DHCP is unavailable - unknown : OLT could not communicate with ONT for discovery - not-supported : ONT doesnot support this activity Field type <Ip::V4Address> - IPv4-address	the current IP address of the secondary DNS server for the IP host service <i>This element is always shown.</i>
host-name	Parameter type: <Gpon::HostName> (undefined unknown <Gpon::hostname>) Possible values: - undefined : DHCP is unavailable or ONT returns null string - unknown : OLT could not communicate with ONT for discovery Field type <Gpon::hostname> - host name address - length: x<=255	the hostname for the IP host service <i>This element is only shown in detail mode.</i>

123.3 ONT IP Host Current 15min Statistics Status Command

Command Description

This command displays the IP Host Performance statistics during the current 15 minute interval of operation

User Level

The command can be accessed by operators with sip,megaco privileges.

Command Syntax

The command has the following syntax:

```
> show iphost ont statistics current-15min [ (index) ]
```

Command Parameters

Table 123.3-1 "ONT IP Host Current 15min Statistics Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: (ont : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Gpon::IpHostId> vlanport : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / vuni : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlanport : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / vuni : <Eqpt::UnstackedVlan> ont:ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / <Ng2::IpHostId> vlanport:ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / vuni : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlanport:ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / vuni : <Eqpt::UnstackedVlan>) Possible values: - ont:ng2 : ngpon2 ont - vlanport:ng2 : ngpon2 vlanport - ont : ont - vlanport : vlanport Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId>	a unique interface index

Resource Identifier	Type	Description
	- the shelf number - Field type <Eqpt::SlotId> - the LT slot number - Field type <Eqpt::PonId> - the PON identifier - Field type <Eqpt::OntId> - the ONT identifier - Field type <Eqpt::ChannelGroupId> - the channel group identifier - Field type <Eqpt::SubChannelGroupId> - the subchannel group identifier - Field type <Eqpt::Ng2OntId> - the NG2 ONT identifier - Possible values: - vuni : virtual uni identifier - Possible values: - vuni : virtual NGPON2 uni identifier - Field type <Gpon::IpHostID> - iphost id - Field type <Ng2::IpHostID> - iphost id (ngpon2) - Possible values: - stacked : stacked vlan identity - Field type <Eqpt::UnstackedVlan> - unstacked vlan id - Field type <Eqpt::SVlan> - service vlan id - Field type <Eqpt::CVlan> - customer vlan id	

Command Output

Table 123.3-2 "ONT IP Host Current 15min Statistics Status Command" Display parameters

Specific Information		
name	Type	Description
icmp-err	Parameter type: <Counter> - 32 bit counter	a count of number of ICMP errors received <i>This element is always shown.</i>
dns-err	Parameter type: <Counter> - 32 bit counter	a count of number of DNS errors received <i>This element is always shown.</i>
dhcp-timeout	Parameter type: <Counter> - 32 bit counter	a count of number of DHCP timeouts <i>This element is always shown.</i>
addr-conflict	Parameter type: <Counter> - 32 bit counter	a count of conflicting IP address(one that has the same value as the one currently assigned to the ONT) <i>This element is always shown.</i>
out-of-mem	Parameter type: <Counter> - 32 bit counter	a count of out of memory condition in the IP stack <i>This element is always shown.</i>
internal-err	Parameter type: <Counter> - 32 bit counter	a count of internal error condition(such as a driver interface failure in the IP stack) <i>This element is always shown.</i>

124- MoCA Status Commands

124.1 MoCA Status Command Tree	124-5922
124.2 MoCA ONT Uni Operational Data Status Command	124-5923
124.3 MoCA ONT Current PM Data Status Command	124-5926
124.4 MoCA ONT Historical PM Data Status Command	124-5928

124.1 MoCA Status Command Tree

Description

This chapter gives an overview of nodes that are handled by "MoCA Status Commands".

Command Tree

```
----show
  ----moca
    ----ont
      ----operational-data
        - (uni-index)
      ----performance-data
        ----current-interval
          - (uni-index)
        ----previous-interval
          - (uni-index)
          - interval-nbr
```

124.2 MoCA ONT Uni Operational Data Status Command

Command Description

This retrieves MoCA operational data from the ONT UNI(s).

User Level

The command can be accessed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

```
> show moca ont operational-data [ (uni-index) ]
```

Command Parameters

Table 124.2-1 "MoCA ONT Uni Operational Data Status Command" Resource Parameters

Resource Identifier	Type	Description
(uni-index)	Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Gpon::OntSlotId> / <Gpon::OntPortId> ng2 : <Ng2::ChannelGroup> / <Ng2::SubchannelGroup> / <Ng2::OntId> / <Gpon::OntSlotId> / <Gpon::OntPortId>) Possible values: - ng2 : ngpon2 style identification Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Ng2::ChannelGroup> - channel group number Field type <Ng2::SubchannelGroup> - subchannel group number Field type <Eqpt::OntId> - the ONT identifier Field type <Ng2::OntId> - the ONT identifier Field type <Gpon::OntSlotId> - Gpon Ont Slot	interface index of the moca uni

Resource Identifier	Type	Description
	- range: [1...14] - Field type <Gpon::OntPortId> - Gpon Ont Port - range: [1...16]	

Command Output

Table 124.2-2 "MoCA ONT Uni Operational Data Status Command" Display parameters

Specific Information		
name	Type	Description
network-status	Parameter type: <Moca::NetworkStatus> (not-joined joined master) Possible values: - not-joined : has not joined a MoCA network - joined : has joined a MoCA network - master : network coordinator of a MoCA network	networking state <i>This element is only shown in detail mode.</i>
rf-channel short name: freq	Parameter type: <SignedInteger> - a signed integer	frequency to which the MoCA interface is tuned, in MHz <i>This element is always shown.</i>
last-op-freq	Parameter type: <SignedInteger> - a signed integer	frequency to which the MoCA interface was last tuned, in MHz <i>This element is only shown in detail mode.</i>
link-status short name: stat	Parameter type: <Moca::LinkStatus> ((no-carrier los) (carrier ok) low-bw) Possible values: - no-carrier : no carrier detected - los : no carrier detected - carrier : carrier detected - ok : carrier detected - low-bw : carrier detected, but low bandwidth	MoCA network link status <i>This element is always shown.</i>
tx-power	Parameter type: <SignedInteger> - a signed integer	transmitter power level, in dBm <i>This element is only shown in detail mode.</i>
ont-mac-address short name: ont-mac	Parameter type: <Gpon::MacAddress> - a mac-address (example : 01:02:03:04:05:06) - length: 6	mac address of the ont moca uni <i>This element is only shown in detail mode.</i>
bhr-mac-address short name: bhr-mac	Parameter type: <Gpon::MacAddress> - a mac-address (example : 01:02:03:04:05:06) - length: 6	mac address of the bhr/rgw moca device <i>This element is always shown.</i>
phy-tx-rate short name: tx-rate	Parameter type: <UnsignedInteger> - an unsigned integer	transmit rate from the ONT MoCA interface to the RGW/BHR <i>This element is always shown.</i>
phy-rx-rate short name: rx-rate	Parameter type: <UnsignedInteger> - an unsigned integer	receive rate to the ONT MoCA interface from the RGW/BHR <i>This element is always shown.</i>
version short name: ver	Parameter type: <Moca::Version> ((unknown ?) 1.0 1.1 2.0	MoCA version <i>This element is always shown.</i>

name	Type	Description
	2.5) Possible values: - unknown : MoCA version unknown - ? : MoCA version unknown - 1.0 : MoCA version 1.0 - 1.1 : MoCA version 1.1 - 2.0 : MoCA version 2.0 - 2.5 : MoCA version 2.5	
power-state	Parameter type: <Moca::PowerState> (unknown normal idle standby sleep) Possible values: - unknown : unknown power state - normal : normal power state - idle : idle low power state - standby : standby low power state - sleep : sleep low power state	MoCA version <i>This element is only shown in detail mode.</i>

124.3 MoCA ONT Current PM Data Status Command

Command Description

This retrieves Current MoCA physical layer performance monitoring data from the ONT UNI(s).

User Level

The command can be accessed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

```
> show moca ont performance-data current-interval [ (uni-index) ]
```

Command Parameters

Table 124.3-1 "MoCA ONT Current PM Data Status Command" Resource Parameters

Resource Identifier	Type	Description
(uni-index)	Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Gpon::OntSlotId> / <Gpon::OntPortId> ng2 : <Ng2::ChannelGroup> / <Ng2::SubchannelGroup> / <Ng2::OntId> / <Gpon::OntSlotId> / <Gpon::OntPortId>) Possible values: - ng2 : ngpon2 style identification Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Ng2::ChannelGroup> - channel group number Field type <Ng2::SubchannelGroup> - subchannel group number Field type <Eqpt::OntId> - the ONT identifier Field type <Ng2::OntId> - the ONT identifier Field type <Gpon::OntSlotId> - Gpon Ont Slot	interface index of the moca uni

Resource Identifier	Type	Description
	- range: [1...14] Field type <Gpon::OntPortId> - Gpon Ont Port - range: [1...16]	

Command Output

Table 124.3-2 "MoCA ONT Current PM Data Status Command" Display parameters

Specific Information		
name	Type	Description
rx-packets	Parameter type: <Counter> - 32 bit counter	received packets counter <i>This element is always shown.</i>
rx-err-packets	Parameter type: <Counter> - 32 bit counter	received errored packets counter <i>This element is always shown.</i>

124.4 MoCA ONT Historical PM Data Status Command

Command Description

This retrieves Previous MoCA physical layer performance monitoring data from the ONT UNI(s).

User Level

The command can be accessed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

```
> show moca ont performance-data previous-interval [ (uni-index) [ interval-nbr <Gpon::IntervalNo> ] ]
```

Command Parameters

Table 124.4-1 "MoCA ONT Historical PM Data Status Command" Resource Parameters

Resource Identifier	Type	Description
(uni-index)	Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Gpon::OntSlotId> / <Gpon::OntPortId> ng2 : <Ng2::ChannelGroup> / <Ng2::SubchannelGroup> / <Ng2::OntId> / <Gpon::OntSlotId> / <Gpon::OntPortId>) Possible values: - ng2 : ngpon2 style identification Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Ng2::ChannelGroup> - channel group number Field type <Ng2::SubchannelGroup> - subchannel group number Field type <Eqpt::OntId> - the ONT identifier Field type <Ng2::OntId> - the ONT identifier Field type <Gpon::OntSlotId> - Gpon Ont Slot	interface index of the moca uni

Resource Identifier	Type	Description
	- range: [1...14] - Field type <Gpon::OntPortId> - Gpon Ont Port - range: [1...16]	
interval-nbr	Parameter type: <Gpon::IntervalNo> Format: - a number of a previous interval number - range: [1...32]	15 minute interval identifier from 1(most recent) to 32(oldest)

Command Output

Table 124.4-2 "MoCA ONT Historical PM Data Status Command" Display parameters

Specific Information		
name	Type	Description
rx-packets	Parameter type: <Counter> - 32 bit counter	received packets counter <i>This element is always shown.</i>
rx-err-packets	Parameter type: <Counter> - 32 bit counter	received errored packets counter <i>This element is always shown.</i>

125- Epon Status Commands

125.1 Epon Status Command Tree	125-5931
125.2 EPON Optics Status Command	125-5932
125.3 Epon Profile Status Command	125-5936
125.4 Epon Queue Profile Status Command	125-5937
125.5 Epon Filter Profile Status Command	125-5938
125.6 Epon Digitmap Profile Status Command	125-5939
125.7 Epon Alarm Control Profile Status Command	125-5940
125.8 Epon Pon Interface Status Command	125-5941
125.9 Epon Pon Interface Current 15min Status Command	125-5942
125.10 Epon Pon Interface Current 1day Status Command	125-5946
125.11 Epon Pon Interface Previous 15min Status Command	125-5950
125.12 Epon Pon Interface Previous 15min Status Command	125-5951
125.13 Epon Pon Interface Previous 1Day Status Command	125-5955
125.14 Epon Pon Interface Previous 1Day Status Command	125-5956
125.15 Epon Pon Interface Information Command	125-5960
125.16 EPON Rogue Onu Test Result	125-5962
125.17 Ima-Group Alarm Log Status Command	125-5964

125.1 Epon Status Command Tree

Description

This chapter gives an overview of nodes that are handled by "Epon Status Commands".

Command Tree

```

----show
  ----epon
    ----optics
      - (pon-idx)
    ----profiles-usage
      ----queue
        - (profile-idx)
      ----filter
        - (profile-idx)
      ----digitmap
        - (profile-idx)
      ----ontalarm
        - (name)
    ----interface
      ----current-15min
        - (pon-idx)
      ----current-1day
        - (pon-idx)
      ----previous-15min
        - (pon-idx)
        ----interval-num
          - (interval-num)
      ----previous-1day
        - (pon-idx)
        ----interval-num
          - (interval-num)
      ----information
        - (pon-idx)
    ----rogue
      - (pon-idx)
      - onu-id
    ----unprovision-onu
      - (alarm-index)

```

125.2 EPON Optics Status Command

Command Description

User Level

The command can be accessed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

```
> show epon optics [ (pon-idx) ]
```

Command Parameters

Table 125.2-1 "EPON Optics Status Command" Resource Parameters

Resource Identifier	Type	Description
(pon-idx)	Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier	Pon interface

Command Output

Table 125.2-2 "EPON Optics Status Command" Display parameters

Specific Information		
name	Type	Description
olt-tx-sig-lvl 0.1uw	Parameter type: <Epon::OpticalSignalLevel> (unknown <Epon::OpticalSignalLevel>) Possible values: - unknown : a valid measurement is currently unattainable for some reason Field type <Epon::OpticalSignalLevel> - olt optical signal level - unit: 0.1 uW - range: [0...65535]	This attribute indicates the current measurement of the OLT transmit optical signal level in 0.1uw <i>This element is always shown.</i>
olt-tx-sig-lvl dbm	Parameter type: <Epon::OptPwrDbm> (nopower <Epon::floatoptpwr>	This attribute indicates the current measurement of the OLT

name	Type	Description
	<Epon::float> <Epon::floatoptpwr>) Possible values: - nopower : a valid measurement is currently unattainable for some reason Field type <Epon::float> - OLT side TCA threshold - unit: dbm - range: [-40...8.2] Field type <Epon::floatoptpwr> - Power of Optical Unit in Dbm - unit: dbm - range: [-99.0...8.164]	transmit optical signal level in dBm <i>This element is only shown in detail mode.</i>
olt-temperature 1/256c	Parameter type: <Epon::Temperature> (unknown <Epon::Temperature>) Possible values: - unknown : a valid measurement is currently unattainable for some reason Field type <Epon::Temperature> - temperature of olt optical module - unit: 1/256 Celsius - range: [-32768...32768]	This attribute indicates the current temperature of the optics module associated with this PON <i>This element is always shown.</i>
olt-temperature c	Parameter type: <Epon::OpticalTempC> - temperature of optical unit - unit: degree C - range: [-128...128]	This attribute indicates the current temperature of the optics module associated with this PON <i>This element is only shown in detail mode.</i>
olt-voltage 0.1mv	Parameter type: <Epon::Voltage> (unknown <Epon::Voltage>) Possible values: - unknown : a valid measurement is currently unattainable for some reason Field type <Epon::Voltage> - power feed voltage of olt optical module - unit: 100u Volts - range: [0...65500]	This attribute indicates the current voltage of the optics module associated with this PON <i>This element is always shown.</i>
olt-voltage v	Parameter type: <Epon::OpticalVoltageV> - voltage of optical unit - unit: volts - range: [0...6.55]	This attribute indicates the current voltage of the optics module associated with this PON <i>This element is only shown in detail mode.</i>
olt-bias 2ua	Parameter type: <Epon::LaserBias> (unknown <Epon::LaserBias>) Possible values: - unknown : a valid measurement is currently unattainable for some reason Field type <Epon::LaserBias> - indicates the current bias current of the laser - unit: 2uA - range: [0...131000]	This attribute indicates the current bias current of the laser associated with this PON <i>This element is always shown.</i>
olt-bias ma	Parameter type: <Epon::OpticalBiasMa> - bias of optical unit - unit: mA - range: [0...262]	This attribute indicates the current bias current of the laser associated with this PON <i>This element is only shown in detail mode.</i>

125 Epon Status Commands

name	Type	Description
olt-sig-lvl-10g 0.1uw	Parameter type: <Epon::OpticalSignalLevel> (unknown <Epon::OpticalSignalLevel>) Possible values: - unknown : a valid measurement is currently unattainable for some reason Field type <Epon::OpticalSignalLevel> - olt optical signal level - unit: 0.1 uW - range: [0...65535]	This attribute indicates the current measurement of the OLT 10G PON transmit optical signal level in 0.1uw <i>This element is always shown.</i>
olt-sig-lvl-10g dbm	Parameter type: <Epon::OptPwrDbm> (nopower <Epon::floatoptpwr> <Epon::float> <Epon::floatoptpwr>) Possible values: - nopower : a valid measurement is currently unattainable for some reason Field type <Epon::float> - OLT side TCA threshold - unit: dbm - range: [-40...8.2] Field type <Epon::floatoptpwr> - Power of Optical Unit in Dbm - unit: dbm - range: [-99.0...8.164]	This attribute indicates the current measurement of the OLT 10G PON transmit optical signal level in dBm <i>This element is only shown in detail mode.</i>
olt-bias-10g 2ua	Parameter type: <Epon::LaserBias> (unknown <Epon::LaserBias>) Possible values: - unknown : a valid measurement is currently unattainable for some reason Field type <Epon::LaserBias> - indicates the current bias current of the laser - unit: 2uA - range: [0...131000]	This attribute indicates the current bias current of the laser associated with 10G PON <i>This element is always shown.</i>
olt-bias-10g ma	Parameter type: <Epon::OpticalBiasMa> - bias of optical unit - unit: mA - range: [0...262]	This attribute indicates the current bias current of the laser associated with 10G PON <i>This element is only shown in detail mode.</i>
otdr	Parameter type: <Epon::OpSpecFeat> (yes no) Possible values: - yes : sfp is otdr capable - no : sfp is not otdr capable	special features supported by the sfp <i>This element is always shown.</i>
curidlepwr 0.1uw	Parameter type: <Epon::CurIdlePwr> (nopower <Epon::floatidlepwr> <Epon::float> <Epon::floatidlepwr>) Possible values: - nopower : a valid measurement is currently unattainable for some reason Field type <Epon::float> - OLT side TCA threshold - unit: dbm - range: [-40...8.2] Field type <Epon::floatidlepwr> - OLT side TCA threshold	current idle pwr of the pon <i>This element is always shown.</i>

name	Type	Description
	- unit: dbm - range: [-40...8.164]	

125.3 Epon Profile Status Command

Command Description

This command indicates the number of entities using this profile.

If the reference count is greater than 0, then this profile is 'in use', and may NOT be deleted.

If the value is 0, then this profile is 'not in use', and can be deleted.

User Level

The command can be accessed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

> show epon profiles-usage

125.4 Epon Queue Profile Status Command

Command Description

User Level

The command can be accessed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

```
> show epon profiles-usage queue [ (profile-idx) ]
```

Command Parameters

Table 125.4-1 "Epon Queue Profile Status Command" Resource Parameters

Resource Identifier	Type	Description
(profile-idx)	Format: - a profile index - range: [1...250]	index to the Profile

Command Output

Table 125.4-2 "Epon Queue Profile Status Command" Display parameters

Specific Information		
name	Type	Description
ref-count	Parameter type: <Epon::RefCnt> - number of entities using this particular profile - range: [0...4294967295]	indicates the number of entities using this profile <i>This element is always shown.</i>

125.5 Epon Filter Profile Status Command

Command Description

User Level

The command can be accessed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

> show epon profiles-usage filter [(profile-idx)]

Command Parameters

Table 125.5-1 "Epon Filter Profile Status Command" Resource Parameters

Resource Identifier	Type	Description
(profile-idx)	Format: - filter profile id - range: [1...8192]	index to the Profile

Command Output

Table 125.5-2 "Epon Filter Profile Status Command" Display parameters

Specific Information		
name	Type	Description
ref-count	Parameter type: <Epon::RefCnt> - number of entities using this particular profile - range: [0...4294967295]	indicates the number of entities using this profile <i>This element is always shown.</i>

125.6 Epon Digitmap Profile Status Command

Command Description

User Level

The command can be accessed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

```
> show epon profiles-usage digitmap [ (profile-idx) ]
```

Command Parameters

Table 125.6-1 "Epon Digitmap Profile Status Command" Resource Parameters

Resource Identifier	Type	Description
(profile-idx)	Format: - a profile index - range: [1...250]	index to the Profile

Command Output

Table 125.6-2 "Epon Digitmap Profile Status Command" Display parameters

Specific Information		
name	Type	Description
ref-count	Parameter type: <Epon::RefCnt> - number of entities using this particular profile - range: [0...4294967295]	indicates the number of entities using this profile <i>This element is always shown.</i>

125.7 Epon Alarm Control Profile Status Command

Command Description

User Level

The command can be accessed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

```
> show epon profiles-usage ontalarm [ (name) ]
```

Command Parameters

Table 125.7-1 "Epon Alarm Control Profile Status Command" Resource Parameters

Resource Identifier	Type	Description
(name)	Format: - name of the Alarm Control profile - length: 1<=x<=32	A queue profile name

Command Output

Table 125.7-2 "Epon Alarm Control Profile Status Command" Display parameters

Specific Information		
name	Type	Description
ref-count	Parameter type: <Epon::RefCnt> - number of entities using this particular profile - range: [0...4294967295]	indicates the number of entities using this profile <i>This element is always shown.</i>

125.8 Epon Pon Interface Status Command

Command Description

This command indicates the Epon performance counters specific to a PON port on OLT side.

User Level

The command can be accessed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

> show epon interface

125.9 Epon Pon Interface Current 15min Status Command

Command Description

User Level

The command can be accessed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

> show epon interface current-15min [(pon-idx)]

Command Parameters

Table 125.9-1 "Epon Pon Interface Current 15min Status Command" Resource Parameters

Resource Identifier	Type	Description
(pon-idx)	Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier	Pon interface

Command Output

Table 125.9-2 "Epon Pon Interface Current 15min Status Command" Display parameters

Specific Information		
name	Type	Description
elapsed-time	Parameter type: <SignedInteger> - a signed integer	Elapsed time in interval <i>This element is always shown.</i>
measure-time	Parameter type: <SignedInteger> - a signed integer	Measured time in interval <i>This element is always shown.</i>
octets-up	Parameter type: <Epon::OctetCounter> - Epon Frames counter	octets transferred in upstream direction <i>This element is always shown.</i>
frames-up	Parameter type: <Epon::OctetCounter> - Epon Frames counter	Total Frames transferred in upstream direction

name	Type	Description
		<i>This element is always shown.</i>
segment1octets-up	Parameter type: <Epon::OctetCounter> - Epon Frames counter	64 Octet Frames in upstream direction <i>This element is only shown in detail mode.</i>
segment2octets-up	Parameter type: <Epon::OctetCounter> - Epon Frames counter	65-127 Octet Frames in upstream direction <i>This element is only shown in detail mode.</i>
segment3octets-up	Parameter type: <Epon::OctetCounter> - Epon Frames counter	128-255 Octet Frames in upstream direction <i>This element is only shown in detail mode.</i>
segment4octets-up	Parameter type: <Epon::OctetCounter> - Epon Frames counter	256-511 Octet Frames in upstream direction <i>This element is only shown in detail mode.</i>
segment5octets-up	Parameter type: <Epon::OctetCounter> - Epon Frames counter	512-1023 Octet Frames in upstream direction <i>This element is only shown in detail mode.</i>
segment6octets-up	Parameter type: <Epon::OctetCounter> - Epon Frames counter	1024-1518 Octet Frames in upstream direction <i>This element is only shown in detail mode.</i>
segment7octets-up	Parameter type: <Epon::OctetCounter> - Epon Frames counter	1519+ Octet Frames in upstream direction <i>This element is only shown in detail mode.</i>
octets-down	Parameter type: <Epon::OctetCounter> - Epon Frames counter	octets transferred in downstream direction <i>This element is always shown.</i>
frames-down	Parameter type: <Epon::OctetCounter> - Epon Frames counter	Total Frames transferred in downstream direction <i>This element is always shown.</i>
segment1octets-down	Parameter type: <Epon::OctetCounter> - Epon Frames counter	64 Octet Frames in downstream direction <i>This element is only shown in detail mode.</i>
segment2octets-down	Parameter type: <Epon::OctetCounter> - Epon Frames counter	65-127 Octet Frames in downstream direction <i>This element is only shown in detail mode.</i>
segment3octets-down	Parameter type: <Epon::OctetCounter> - Epon Frames counter	128-255 Octet Frames in downstream direction <i>This element is only shown in detail mode.</i>
segment4octets-down	Parameter type: <Epon::OctetCounter> - Epon Frames counter	256-511 Octet Frames in downstream direction <i>This element is only shown in detail mode.</i>
segment5octets-down	Parameter type: <Epon::OctetCounter> - Epon Frames counter	512-1023 Octet Frames in downstream direction <i>This element is only shown in detail mode.</i>
segment6octets-down	Parameter type: <Epon::OctetCounter> - Epon Frames counter	1024-1518 Octet Frames in downstream direction

125 Epon Status Commands

name	Type	Description
		<i>This element is only shown in detail mode.</i>
segment7octets-down	Parameter type: <Epon::OctetCounter> - Epon Frames counter	1519+ Octet Frames in downstream direction <i>This element is only shown in detail mode.</i>
unicastframes-up	Parameter type: <Epon::OctetCounter> - Epon Frames counter	unicast Frames in upstream direction <i>This element is only shown in detail mode.</i>
unicastframes-down	Parameter type: <Epon::OctetCounter> - Epon Frames counter	unicast Frames in downstream direction <i>This element is only shown in detail mode.</i>
multicastframes-up	Parameter type: <Epon::OctetCounter> - Epon Frames counter	multicast Frames in upstream direction <i>This element is only shown in detail mode.</i>
multicastframes-down	Parameter type: <Epon::OctetCounter> - Epon Frames counter	multicast Frames in downstream direction <i>This element is only shown in detail mode.</i>
broadcastframes-up	Parameter type: <Epon::OctetCounter> - Epon Frames counter	boardcast Frames in upstream direction <i>This element is only shown in detail mode.</i>
broadcastframes-down	Parameter type: <Epon::OctetCounter> - Epon Frames counter	boardcast Frames in downstream direction <i>This element is only shown in detail mode.</i>
drpframes-up	Parameter type: <Epon::OctetCounter> - Epon Frames counter	discard Frames in upstream direction <i>This element is only shown in detail mode.</i>
drpframes-down	Parameter type: <Epon::OctetCounter> - Epon Frames counter	discard Frames in downstream direction <i>This element is only shown in detail mode.</i>
errframes-up	Parameter type: <Epon::OctetCounter> - Epon Frames counter	error Frames in upstream direction <i>This element is only shown in detail mode.</i>
errframes-down	Parameter type: <Epon::OctetCounter> - Epon Frames counter	error Frames in downstream direction <i>This element is only shown in detail mode.</i>
crcerrframes-up	Parameter type: <Epon::OctetCounter> - Epon Frames counter	CRC error Frames in upstream direction <i>This element is only shown in detail mode.</i>
undframes-up	Parameter type: <Epon::OctetCounter> - Epon Frames counter	less than 64 bytes bytes Frames in upstream direction <i>This element is only shown in detail mode.</i>
undframes-down	Parameter type: <Epon::OctetCounter> - Epon Frames counter	less than 64 bytes bytes Frames in downstream direction <i>This element is only shown in</i>

name	Type	Description
		<i>detail mode.</i>
ovrframes-up	Parameter type: <Epon::OctetCounter> - Epon Frames counter	1526+ Frames in upstream direction <i>This element is only shown in detail mode.</i>
ovrframes-down	Parameter type: <Epon::OctetCounter> - Epon Frames counter	1526+ Frames in downstream direction <i>This element is only shown in detail mode.</i>
dropevents-up	Parameter type: <Epon::OctetCounter> - Epon Frames counter	drop event in upstream direction on a PON port <i>This element is only shown in detail mode.</i>
dropevents-down	Parameter type: <Epon::OctetCounter> - Epon Frames counter	drop event in downstream direction on a PON port <i>This element is only shown in detail mode.</i>
fragments-up	Parameter type: <Epon::OctetCounter> - Epon Frames counter	fragment frames in upstream direction on a PON port <i>This element is only shown in detail mode.</i>
fragments-down	Parameter type: <Epon::OctetCounter> - Epon Frames counter	fragment frames in downstream direction on a PON port <i>This element is only shown in detail mode.</i>
jabberframes-up	Parameter type: <Epon::OctetCounter> - Epon Frames counter	jabber frames in upstream direction on a PON port <i>This element is only shown in detail mode.</i>
jabberframes-down	Parameter type: <Epon::OctetCounter> - Epon Frames counter	jabber frames in downstream direction on a PON port <i>This element is only shown in detail mode.</i>
statuschange	Parameter type: <Epon::OctetCounter> - Epon Frames counter	the number of status change on a PON port <i>This element is only shown in detail mode.</i>

125.10 Epon Pon Interface Current 1day Status Command

Command Description

User Level

The command can be accessed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

```
> show epon interface current-1day [ (pon-idx) ]
```

Command Parameters

Table 125.10-1 "Epon Pon Interface Current 1day Status Command" Resource Parameters

Resource Identifier	Type	Description
(pon-idx)	Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier	Pon interface

Command Output

Table 125.10-2 "Epon Pon Interface Current 1day Status Command" Display parameters

Specific Information		
name	Type	Description
elapsed-time	Parameter type: <SignedInteger> - a signed integer	Elapsed time in interval <i>This element is always shown.</i>
measure-time	Parameter type: <SignedInteger> - a signed integer	Measured time in interval <i>This element is always shown.</i>
octets-up	Parameter type: <Epon::OctetCounter> - Epon Frames counter	octets transferred in upstream direction <i>This element is always shown.</i>
frames-up	Parameter type: <Epon::OctetCounter> - Epon Frames counter	Total Frames transferred in upstream direction

name	Type	Description
		<i>This element is always shown.</i>
segment1octets-up	Parameter type: <Epon::OctetCounter> - Epon Frames counter	64 Octet Frames in upstream direction <i>This element is only shown in detail mode.</i>
segment2octets-up	Parameter type: <Epon::OctetCounter> - Epon Frames counter	65-127 Octet Frames in upstream direction <i>This element is only shown in detail mode.</i>
segment3octets-up	Parameter type: <Epon::OctetCounter> - Epon Frames counter	128-255 Octet Frames in upstream direction <i>This element is only shown in detail mode.</i>
segment4octets-up	Parameter type: <Epon::OctetCounter> - Epon Frames counter	256-511 Octet Frames in upstream direction <i>This element is only shown in detail mode.</i>
segment5octets-up	Parameter type: <Epon::OctetCounter> - Epon Frames counter	512-1023 Octet Frames in upstream direction <i>This element is only shown in detail mode.</i>
segment6octets-up	Parameter type: <Epon::OctetCounter> - Epon Frames counter	1024-1518 Octet Frames in upstream direction <i>This element is only shown in detail mode.</i>
segment7octets-up	Parameter type: <Epon::OctetCounter> - Epon Frames counter	1519+ Octet Frames in upstream direction <i>This element is only shown in detail mode.</i>
octets-down	Parameter type: <Epon::OctetCounter> - Epon Frames counter	octets transferred in downstream direction <i>This element is always shown.</i>
frames-down	Parameter type: <Epon::OctetCounter> - Epon Frames counter	Total Frames transferred in downstream direction <i>This element is always shown.</i>
segment1octets-down	Parameter type: <Epon::OctetCounter> - Epon Frames counter	64 Octet Frames in downstream direction <i>This element is only shown in detail mode.</i>
segment2octets-down	Parameter type: <Epon::OctetCounter> - Epon Frames counter	65-127 Octet Frames in downstream direction <i>This element is only shown in detail mode.</i>
segment3octets-down	Parameter type: <Epon::OctetCounter> - Epon Frames counter	128-255 Octet Frames in downstream direction <i>This element is only shown in detail mode.</i>
segment4octets-down	Parameter type: <Epon::OctetCounter> - Epon Frames counter	256-511 Octet Frames in downstream direction <i>This element is only shown in detail mode.</i>
segment5octets-down	Parameter type: <Epon::OctetCounter> - Epon Frames counter	512-1023 Octet Frames in downstream direction <i>This element is only shown in detail mode.</i>
segment6octets-down	Parameter type: <Epon::OctetCounter> - Epon Frames counter	1024-1518 Octet Frames in downstream direction

125 Epon Status Commands

name	Type	Description
		<i>This element is only shown in detail mode.</i>
segment7octets-down	Parameter type: <Epon::OctetCounter> - Epon Frames counter	1519+ Octet Frames in downstream direction <i>This element is only shown in detail mode.</i>
unicastframes-up	Parameter type: <Epon::OctetCounter> - Epon Frames counter	unicast Frames in upstream direction <i>This element is only shown in detail mode.</i>
unicastframes-down	Parameter type: <Epon::OctetCounter> - Epon Frames counter	unicast Frames in downstream direction <i>This element is only shown in detail mode.</i>
multicastframes-up	Parameter type: <Epon::OctetCounter> - Epon Frames counter	multicast Frames in upstream direction <i>This element is only shown in detail mode.</i>
multicastframes-down	Parameter type: <Epon::OctetCounter> - Epon Frames counter	multicast Frames in downstream direction <i>This element is only shown in detail mode.</i>
broadcastframes-up	Parameter type: <Epon::OctetCounter> - Epon Frames counter	boardcast Frames in upstream direction <i>This element is only shown in detail mode.</i>
broadcastframes-down	Parameter type: <Epon::OctetCounter> - Epon Frames counter	boardcast Frames in downstream direction <i>This element is only shown in detail mode.</i>
drpframes-up	Parameter type: <Epon::OctetCounter> - Epon Frames counter	discard Frames in upstream direction <i>This element is only shown in detail mode.</i>
drpframes-down	Parameter type: <Epon::OctetCounter> - Epon Frames counter	discard Frames in downstream direction <i>This element is only shown in detail mode.</i>
errframes-up	Parameter type: <Epon::OctetCounter> - Epon Frames counter	error Frames in upstream direction <i>This element is only shown in detail mode.</i>
errframes-down	Parameter type: <Epon::OctetCounter> - Epon Frames counter	error Frames in downstream direction <i>This element is only shown in detail mode.</i>
crcerrframes-up	Parameter type: <Epon::OctetCounter> - Epon Frames counter	CRC error Frames in upstream direction <i>This element is only shown in detail mode.</i>
undframes-up	Parameter type: <Epon::OctetCounter> - Epon Frames counter	less than 64 bytes bytes Frames in upstream direction <i>This element is only shown in detail mode.</i>
undframes-down	Parameter type: <Epon::OctetCounter> - Epon Frames counter	less than 64 bytes bytes Frames in downstream direction <i>This element is only shown in</i>

name	Type	Description
		<i>detail mode.</i>
ovrframes-up	Parameter type: <Epon::OctetCounter> - Epon Frames counter	1526+ Frames in upstream direction <i>This element is only shown in detail mode.</i>
ovrframes-down	Parameter type: <Epon::OctetCounter> - Epon Frames counter	1526+ Frames in downstream direction <i>This element is only shown in detail mode.</i>
dropevents-up	Parameter type: <Epon::OctetCounter> - Epon Frames counter	drop event in upstream direction on a PON port <i>This element is only shown in detail mode.</i>
dropevents-down	Parameter type: <Epon::OctetCounter> - Epon Frames counter	drop event in downstream direction on a PON port <i>This element is only shown in detail mode.</i>
fragments-up	Parameter type: <Epon::OctetCounter> - Epon Frames counter	fragment frames in upstream direction on a PON port <i>This element is only shown in detail mode.</i>
fragments-down	Parameter type: <Epon::OctetCounter> - Epon Frames counter	fragment frames in downstream direction on a PON port <i>This element is only shown in detail mode.</i>
jabberframes-up	Parameter type: <Epon::OctetCounter> - Epon Frames counter	jabber frames in upstream direction on a PON port <i>This element is only shown in detail mode.</i>
jabberframes-down	Parameter type: <Epon::OctetCounter> - Epon Frames counter	jabber frames in downstream direction on a PON port <i>This element is only shown in detail mode.</i>
statuschange	Parameter type: <Epon::OctetCounter> - Epon Frames counter	the number of status change on a PON port <i>This element is only shown in detail mode.</i>

125.11 Epon Pon Interface Previous 15min Status Command

Command Description

User Level

The command can be accessed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

> show epon interface previous-15min [(pon-idx)]

Command Parameters

Table 125.11-1 "Epon Pon Interface Previous 15min Status Command" Resource Parameters

Resource Identifier	Type	Description
(pon-idx)	Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier	Pon interface

125.12 Epon Pon Interface Previous 15min Status Command

Command Description

User Level

The command can be accessed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

> show epon interface previous-15min (pon-idx) interval-num [(interval-num)]

Command Parameters

Table 125.12-1 "Epon Pon Interface Previous 15min Status Command" Resource Parameters

Resource Identifier	Type	Description
(pon-idx)	Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier	Pon interface
(interval-num)	Format: - Previous interval reference - range: [1...192]	Previous interval reference

Command Output

Table 125.12-2 "Epon Pon Interface Previous 15min Status Command" Display parameters

Specific Information		
name	Type	Description
measure-time	Parameter type: <SignedInteger> - a signed integer	Measured time in interval <i>This element is always shown.</i>
octets-up	Parameter type: <Epon::OctetCounter> - Epon Frames counter	octets transferred in upstream direction <i>This element is always shown.</i>
frames-up	Parameter type: <Epon::OctetCounter>	Total Frames transferred in

125 Epon Status Commands

name	Type	Description
	- Epon Frames counter	upstream direction <i>This element is always shown.</i>
segment1octets-up	Parameter type: <Epon::OctetCounter> - Epon Frames counter	64 Octet Frames in upstream direction <i>This element is only shown in detail mode.</i>
segment2octets-up	Parameter type: <Epon::OctetCounter> - Epon Frames counter	65-127 Octet Frames in upstream direction <i>This element is only shown in detail mode.</i>
segment3octets-up	Parameter type: <Epon::OctetCounter> - Epon Frames counter	128-255 Octet Frames in upstream direction <i>This element is only shown in detail mode.</i>
segment4octets-up	Parameter type: <Epon::OctetCounter> - Epon Frames counter	256-511 Octet Frames in upstream direction <i>This element is only shown in detail mode.</i>
segment5octets-up	Parameter type: <Epon::OctetCounter> - Epon Frames counter	512-1023 Octet Frames in upstream direction <i>This element is only shown in detail mode.</i>
segment6octets-up	Parameter type: <Epon::OctetCounter> - Epon Frames counter	1024-1518 Octet Frames in upstream direction <i>This element is only shown in detail mode.</i>
segment7octets-up	Parameter type: <Epon::OctetCounter> - Epon Frames counter	1519+ Octet Frames in upstream direction <i>This element is only shown in detail mode.</i>
octets-down	Parameter type: <Epon::OctetCounter> - Epon Frames counter	octets transferred in downstream direction <i>This element is always shown.</i>
frames-down	Parameter type: <Epon::OctetCounter> - Epon Frames counter	Total Frames transferred in downstream direction <i>This element is always shown.</i>
segment1octets-down	Parameter type: <Epon::OctetCounter> - Epon Frames counter	64 Octet Frames in downstream direction <i>This element is only shown in detail mode.</i>
segment2octets-down	Parameter type: <Epon::OctetCounter> - Epon Frames counter	65-127 Octet Frames in downstream direction <i>This element is only shown in detail mode.</i>
segment3octets-down	Parameter type: <Epon::OctetCounter> - Epon Frames counter	128-255 Octet Frames in downstream direction <i>This element is only shown in detail mode.</i>
segment4octets-down	Parameter type: <Epon::OctetCounter> - Epon Frames counter	256-511 Octet Frames in downstream direction <i>This element is only shown in detail mode.</i>
segment5octets-down	Parameter type: <Epon::OctetCounter> - Epon Frames counter	512-1023 Octet Frames in downstream direction <i>This element is only shown in detail mode.</i>
segment6octets-down	Parameter type: <Epon::OctetCounter>	1024-1518 Octet Frames in

name	Type	Description
	- Epon Frames counter	downstream direction <i>This element is only shown in detail mode.</i>
segment7octets-down	Parameter type: <Epon::OctetCounter> - Epon Frames counter	1519+ Octet Frames in downstream direction <i>This element is only shown in detail mode.</i>
unicastframes-up	Parameter type: <Epon::OctetCounter> - Epon Frames counter	unicast Frames in upstream direction <i>This element is only shown in detail mode.</i>
unicastframes-down	Parameter type: <Epon::OctetCounter> - Epon Frames counter	unicast Frames in downstream direction <i>This element is only shown in detail mode.</i>
multicastframes-up	Parameter type: <Epon::OctetCounter> - Epon Frames counter	multicast Frames in upstream direction <i>This element is only shown in detail mode.</i>
multicastframes-down	Parameter type: <Epon::OctetCounter> - Epon Frames counter	multicast Frames in downstream direction <i>This element is only shown in detail mode.</i>
broadcastframes-up	Parameter type: <Epon::OctetCounter> - Epon Frames counter	boardcast Frames in upstream direction <i>This element is only shown in detail mode.</i>
broadcastframes-down	Parameter type: <Epon::OctetCounter> - Epon Frames counter	boardcast Frames in downstream direction <i>This element is only shown in detail mode.</i>
drpframes-up	Parameter type: <Epon::OctetCounter> - Epon Frames counter	discard Frames in upstream direction <i>This element is only shown in detail mode.</i>
drpframes-down	Parameter type: <Epon::OctetCounter> - Epon Frames counter	discard Frames in downstream direction <i>This element is only shown in detail mode.</i>
errframes-up	Parameter type: <Epon::OctetCounter> - Epon Frames counter	error Frames in upstream direction <i>This element is only shown in detail mode.</i>
errframes-down	Parameter type: <Epon::OctetCounter> - Epon Frames counter	error Frames in downstream direction <i>This element is only shown in detail mode.</i>
crcerrframes-up	Parameter type: <Epon::OctetCounter> - Epon Frames counter	CRC error Frames in upstream direction <i>This element is only shown in detail mode.</i>
undframes-up	Parameter type: <Epon::OctetCounter> - Epon Frames counter	less than 64 bytes bytes Frames in upstream direction <i>This element is only shown in detail mode.</i>
undframes-down	Parameter type: <Epon::OctetCounter> - Epon Frames counter	less than 64 bytes bytes Frames in downstream direction

125 Epon Status Commands

name	Type	Description
		<i>This element is only shown in detail mode.</i>
ovrframes-up	Parameter type: <Epon::OctetCounter> - Epon Frames counter	1526+ Frames in upstream direction <i>This element is only shown in detail mode.</i>
ovrframes-down	Parameter type: <Epon::OctetCounter> - Epon Frames counter	1526+ Frames in downstream direction <i>This element is only shown in detail mode.</i>
dropevents-up	Parameter type: <Epon::OctetCounter> - Epon Frames counter	drop event in upstream direction on a PON port <i>This element is only shown in detail mode.</i>
dropevents-down	Parameter type: <Epon::OctetCounter> - Epon Frames counter	drop event in downstream direction on a PON port <i>This element is only shown in detail mode.</i>
fragments-up	Parameter type: <Epon::OctetCounter> - Epon Frames counter	fragment frames in upstream direction on a PON port <i>This element is only shown in detail mode.</i>
fragments-down	Parameter type: <Epon::OctetCounter> - Epon Frames counter	fragment frames in downstream direction on a PON port <i>This element is only shown in detail mode.</i>
jabberframes-up	Parameter type: <Epon::OctetCounter> - Epon Frames counter	jabber frames in upstream direction on a PON port <i>This element is only shown in detail mode.</i>
jabberframes-down	Parameter type: <Epon::OctetCounter> - Epon Frames counter	jabber frames in downstream direction on a PON port <i>This element is only shown in detail mode.</i>
statuschange	Parameter type: <Epon::OctetCounter> - Epon Frames counter	the number of status change on a PON port <i>This element is only shown in detail mode.</i>

125.13 Epon Pon Interface Previous 1Day Status Command

Command Description

User Level

The command can be accessed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

> show epon interface previous-1day [(pon-idx)]

Command Parameters

Table 125.13-1 "Epon Pon Interface Previous 1Day Status Command" Resource Parameters

Resource Identifier	Type	Description
(pon-idx)	Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier	Pon interface

125.14 Epon Pon Interface Previous 1Day Status Command

Command Description

User Level

The command can be accessed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

> show epon interface previous-1day (pon-idx) interval-num [(interval-num)]

Command Parameters

Table 125.14-1 "Epon Pon Interface Previous 1Day Status Command" Resource Parameters

Resource Identifier	Type	Description
(pon-idx)	Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier	Pon interface
(interval-num)	Format: - Previous interval reference - range: [1...2]	Previous interval reference

Command Output

Table 125.14-2 "Epon Pon Interface Previous 1Day Status Command" Display parameters

Specific Information		
name	Type	Description
measure-time	Parameter type: <SignedInteger> - a signed integer	Measured time in interval <i>This element is always shown.</i>
octets-up	Parameter type: <Epon::OctetCounter> - Epon Frames counter	octets transferred in upstream direction <i>This element is always shown.</i>
frames-up	Parameter type: <Epon::OctetCounter>	Total Frames transferred in

name	Type	Description
	- Epon Frames counter	upstream direction <i>This element is always shown.</i>
segment1octets-up	Parameter type: <Epon::OctetCounter> - Epon Frames counter	64 Octet Frames in upstream direction <i>This element is only shown in detail mode.</i>
segment2octets-up	Parameter type: <Epon::OctetCounter> - Epon Frames counter	65-127 Octet Frames in upstream direction <i>This element is only shown in detail mode.</i>
segment3octets-up	Parameter type: <Epon::OctetCounter> - Epon Frames counter	128-255 Octet Frames in upstream direction <i>This element is only shown in detail mode.</i>
segment4octets-up	Parameter type: <Epon::OctetCounter> - Epon Frames counter	256-511 Octet Frames in upstream direction <i>This element is only shown in detail mode.</i>
segment5octets-up	Parameter type: <Epon::OctetCounter> - Epon Frames counter	512-1023 Octet Frames in upstream direction <i>This element is only shown in detail mode.</i>
segment6octets-up	Parameter type: <Epon::OctetCounter> - Epon Frames counter	1024-1518 Octet Frames in upstream direction <i>This element is only shown in detail mode.</i>
segment7octets-up	Parameter type: <Epon::OctetCounter> - Epon Frames counter	1519+ Octet Frames in upstream direction <i>This element is only shown in detail mode.</i>
octets-down	Parameter type: <Epon::OctetCounter> - Epon Frames counter	octets transferred in downstream direction <i>This element is always shown.</i>
frames-down	Parameter type: <Epon::OctetCounter> - Epon Frames counter	Total Frames transferred in downstream direction <i>This element is always shown.</i>
segment1octets-down	Parameter type: <Epon::OctetCounter> - Epon Frames counter	64 Octet Frames in downstream direction <i>This element is only shown in detail mode.</i>
segment2octets-down	Parameter type: <Epon::OctetCounter> - Epon Frames counter	65-127 Octet Frames in downstream direction <i>This element is only shown in detail mode.</i>
segment3octets-down	Parameter type: <Epon::OctetCounter> - Epon Frames counter	128-255 Octet Frames in downstream direction <i>This element is only shown in detail mode.</i>
segment4octets-down	Parameter type: <Epon::OctetCounter> - Epon Frames counter	256-511 Octet Frames in downstream direction <i>This element is only shown in detail mode.</i>
segment5octets-down	Parameter type: <Epon::OctetCounter> - Epon Frames counter	512-1023 Octet Frames in downstream direction <i>This element is only shown in detail mode.</i>
segment6octets-down	Parameter type: <Epon::OctetCounter>	1024-1518 Octet Frames in

125 Epon Status Commands

name	Type	Description
	- Epon Frames counter	downstream direction <i>This element is only shown in detail mode.</i>
segment7octets-down	Parameter type: <Epon::OctetCounter> - Epon Frames counter	1519+ Octet Frames in downstream direction <i>This element is only shown in detail mode.</i>
unicastframes-up	Parameter type: <Epon::OctetCounter> - Epon Frames counter	unicast Frames in upstream direction <i>This element is only shown in detail mode.</i>
unicastframes-down	Parameter type: <Epon::OctetCounter> - Epon Frames counter	unicast Frames in downstream direction <i>This element is only shown in detail mode.</i>
multicastframes-up	Parameter type: <Epon::OctetCounter> - Epon Frames counter	multicast Frames in upstream direction <i>This element is only shown in detail mode.</i>
multicastframes-down	Parameter type: <Epon::OctetCounter> - Epon Frames counter	multicast Frames in downstream direction <i>This element is only shown in detail mode.</i>
broadcastframes-up	Parameter type: <Epon::OctetCounter> - Epon Frames counter	boardcast Frames in upstream direction <i>This element is only shown in detail mode.</i>
broadcastframes-down	Parameter type: <Epon::OctetCounter> - Epon Frames counter	boardcast Frames in downstream direction <i>This element is only shown in detail mode.</i>
drpframes-up	Parameter type: <Epon::OctetCounter> - Epon Frames counter	discard Frames in upstream direction <i>This element is only shown in detail mode.</i>
drpframes-down	Parameter type: <Epon::OctetCounter> - Epon Frames counter	discard Frames in downstream direction <i>This element is only shown in detail mode.</i>
errframes-up	Parameter type: <Epon::OctetCounter> - Epon Frames counter	error Frames in upstream direction <i>This element is only shown in detail mode.</i>
errframes-down	Parameter type: <Epon::OctetCounter> - Epon Frames counter	error Frames in downstream direction <i>This element is only shown in detail mode.</i>
crcerrframes-up	Parameter type: <Epon::OctetCounter> - Epon Frames counter	CRC error Frames in upstream direction <i>This element is only shown in detail mode.</i>
undframes-up	Parameter type: <Epon::OctetCounter> - Epon Frames counter	less than 64 bytes bytes Frames in upstream direction <i>This element is only shown in detail mode.</i>
undframes-down	Parameter type: <Epon::OctetCounter> - Epon Frames counter	less than 64 bytes bytes Frames in downstream direction

name	Type	Description
		<i>This element is only shown in detail mode.</i>
ovrframes-up	Parameter type: <Epon::OctetCounter> - Epon Frames counter	1526+ Frames in upstream direction <i>This element is only shown in detail mode.</i>
ovrframes-down	Parameter type: <Epon::OctetCounter> - Epon Frames counter	1526+ Frames in downstream direction <i>This element is only shown in detail mode.</i>
dropevents-up	Parameter type: <Epon::OctetCounter> - Epon Frames counter	drop event in upstream direction on a PON port <i>This element is only shown in detail mode.</i>
dropevents-down	Parameter type: <Epon::OctetCounter> - Epon Frames counter	drop event in downstream direction on a PON port <i>This element is only shown in detail mode.</i>
fragments-up	Parameter type: <Epon::OctetCounter> - Epon Frames counter	fragment frames in upstream direction on a PON port <i>This element is only shown in detail mode.</i>
fragments-down	Parameter type: <Epon::OctetCounter> - Epon Frames counter	fragment frames in downstream direction on a PON port <i>This element is only shown in detail mode.</i>
jabberframes-up	Parameter type: <Epon::OctetCounter> - Epon Frames counter	jabber frames in upstream direction on a PON port <i>This element is only shown in detail mode.</i>
jabberframes-down	Parameter type: <Epon::OctetCounter> - Epon Frames counter	jabber frames in downstream direction on a PON port <i>This element is only shown in detail mode.</i>
statuschange	Parameter type: <Epon::OctetCounter> - Epon Frames counter	the number of status change on a PON port <i>This element is only shown in detail mode.</i>

125.15 Epon Pon Interface Information Command

Command Description

User Level

The command can be accessed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

> show epon interface information [(pon-idx)]

Command Parameters

Table 125.15-1 "Epon Pon Interface Information Command" Resource Parameters

Resource Identifier	Type	Description
(pon-idx)	Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier	Pon interface

Command Output

Table 125.15-2 "Epon Pon Interface Information Command" Display parameters

Specific Information		
name	Type	Description
ac-op-module-type	Parameter type: <epon::acopmoduletype> (1000base-px20h 1000base-px20 10/1gbase-prx 10gbase-pr-d3 10g1g/1gbase-prx 10g1g/10gbase-pr unknown) Possible values: - 1000base-px20h : 1000base-px20h - 1000base-px20 : 1000base-px20 - 10/1gbase-prx : 10/1gbase-prx	actual optical module type <i>This element is always shown.</i>

name	Type	Description
	- 10gbase-pr-d3 : 10gbase-pr-d3 - 10g1g/1gbase-prx : 10g1g/1gbase-prx - 10g1g/10gbase-pr : 10g1g/10gbase-pr - unknown : unknown	
next-free-ont	Parameter type: <epon::nextfreeont> (none <Epon::dbaInt>) Possible values: - none : none Field type <Epon::dbaInt> - DBA polling interval per pon interface - range: [0...65535]	next free ont <i>This element is always shown.</i>
max-ont-num	Parameter type: <epon::maxontnum> - Onu num of rogue onu test result - range: [0...128]	max ont number per pon <i>This element is always shown.</i>
free-ont-num	Parameter type: <epon::freeontnum> - Onu num of rogue onu test result - range: [0...128]	free ont number per pon <i>This element is always shown.</i>

125.16 EPON Rogue Onu Test Result

Command Description

User Level

The command can be accessed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

```
> show epon rogue [ (pon-idx) [ onu-id <Epon::onu-id> ] ]
```

Command Parameters

Table 125.16-1 "EPON Rogue Onu Test Result" Resource Parameters

Resource Identifier	Type	Description
(pon-idx)	Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier	Pon interface
onu-id	Parameter type: <Epon::onu-id> Format: - Onu num of rogue onu test result - range: [0...128]	onu num of rogue onu test result

Command Output

Table 125.16-2 "EPON Rogue Onu Test Result" Display parameters

Specific Information		
name	Type	Description
testresult	Parameter type: <Epon::rogueTestResult> (unknown unsupport rogueonu notest) Possible values: - unknown : - unsupport :	The test result of rogue onu diagnose <i>This element is always shown.</i>

name	Type	Description
	- rogueonu : - notest :	
mac	Parameter type: <Epon::MacAddr> - mac-address (example : 01:02:03:04:05:06) - length: 6	The Mac of onu of rogue test result <i>This element is always shown.</i>
eontindex	Parameter type: <Epon::rogueontIdx> (ont : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> no-interface) Possible values: - ont : ont - no-interface : no interface Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Eqpt::OntId> - the ONT identifier	The Ifindex of onu of rogue test result <i>This element is always shown.</i>
almstatus	Parameter type: <Epon::roguealmstatus> (noalarm active clear) Possible values: - noalarm : - active : - clear :	The alarm status of onu of rogue test result <i>This element is always shown.</i>

125.17 Ima-Group Alarm Log Status Command

Command Description

This command displays the Ima-Group alarm log status.

User Level

The command can be accessed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

```
> show epon unprovision-onu [ (alarm-index) ]
```

Command Parameters

Table 125.17-1 "Ima-Group Alarm Log Status Command" Resource Parameters

Resource Identifier	Type	Description
(alarm-index)	Format: - index of a current alarm entry	current alarm index

Command Output

Table 125.17-2 "Ima-Group Alarm Log Status Command" Display parameters

Specific Information		
name	Type	Description
last-updated-on	Parameter type: <Sys::timeInSecs> - the time (yyyy-mm-dd:hour:minutes:secs) - unit: UTC	network time in seconds when the alarm was logged. <i>This element is only shown in detail mode.</i>
pon-index	Parameter type: <Itf::ComplexPortType> (xdsl-line : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> voicefxs : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> xdsl-channel : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> atm-if : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> atm-pvc : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::VpiId> : <Eqpt::VciId> bridge-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::VpiId> : <Eqpt::VciId>	identifies the epon where the alarm has occurred. <i>This element is only shown in detail mode.</i>

name	Type	Description
	<pre> vlan-port:ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / <Eqpt::Ng2OntSlotId> / <Eqpt::Ng2OntPortId> : <Eqpt::UnstackedVlan> l2-vlan : <Eqpt::VlanId> ip : <Eqpt::LogicalId> sw-loopback slip uni:ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / <Eqpt::Ng2OntSlotId> / <Eqpt::Ng2OntPortId> vlan-port:ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / <Eqpt::Ng2OntSlotId> / <Eqpt::Ng2OntPortId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> atm-bonding : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> bonding : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> ip-gateway : <Eqpt::VrId> ip-line : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::VpiId> : <Eqpt::VciId> ip-line : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> shdsl-line : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> e1-line : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> atm-ima : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> ethernet-line : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> bridge-port:ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / vuni vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::VpiId> : <Eqpt::VciId> : <Eqpt::UnstackedVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::UnstackedVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::VpiId> : <Eqpt::VciId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> voip:ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> ip-line : vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::VpiId> : <Eqpt::VciId> : <Eqpt::UnstackedVlan> ip-line : vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::UnstackedVlan> ip-line : vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::VpiId> : <Eqpt::VciId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> ip-line : vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : stacked : <Eqpt::SVlan> : </pre>	

name	Type	Description
	<pre> <Eqpt::CVlan> vlan-port:ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / vuni : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan-port:ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / vuni : <Eqpt::UnstackedVlan> chgroup : <Eqpt::ChannelGroupId> subchgroup : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> bridge-port:ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / <Eqpt::Ng2OntSlotId> / <Eqpt::Ng2OntPortId> atm-pvc : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> bridge-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> bridge-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> / <Eqpt::OntPortId> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> / <Eqpt::OntPortId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> / <Eqpt::OntPortId> : <Eqpt::UnstackedVlan> pon : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> ont : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> uni : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> / <Eqpt::OntPortId> bridge-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / voip bridge-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / vuni vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / voip : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / vuni : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / voip : <Eqpt::UnstackedVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / vuni : <Eqpt::UnstackedVlan> voip : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> la-group : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / </pre>	

name	Type	Description
	<pre> <Eqpt::LLId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> bridge-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::LLId> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::LLId> : <Eqpt::UnstackedVlan> mpm : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::ComboPonId> x-pon : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::XPonId> 25g-pon : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::M25GPonId> dist-router-interface : slot-stacked : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::SVlan> : <Eqpt::CVlan> dist-router-interface : slot-vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::UnstackedVlan> bundle : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::BundleId> chpair : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::ChannelPairId> ont.ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId>) Possible values: - xdsl-line : a static xdsl line interface - xdsl-channel : a static xdsl channel interface - atm-if : a static atm interface - atm-pvc : an atm pvc interface - bridge-port : a vlan bridge-port - bridge-port.ng2 : a ngpon2 vlan bridge-port - l2-vlan : a l2-vlan interface - ip : an ip interface - sw-loopback : a software loopback interface - slip : a slip interface - atm-bonding : atm bonding obsolete alternative replaced by bonding - bonding : bonding - ip-gateway : ip user gateway interface - ip-line : ip line interface - shdsl-line : a static shdsl line interface - e1-line : a e1 line interface - atm-ima : atm ima - ethernet-line : an ethernet line interface - vlan-port : vlan port - vlan-port.ng2 : a ngpon2 vlan port - pon : pon - x-pon : xgs pon - 25g-pon : 25g pon - chpair : channelpair - chgroup : channelgroup - subchgroup : subchannelgroup - bundle : bundle - ont : ont - ont.ng2 : ngpon2 ONT style identification - uni : uni - uni.ng2 : ngpon2 UNI style identification </pre>	

name	Type	Description
	- voip : voip - voip:ng2 : voip - la-group : link aggregation group - dist-router-interface : dist router interface - voicefxs : voicefxs - mpm : multi-pon module Possible values: - vlan : vlan port Possible values: - slot-vlan : slot unstacked - slot-stacked : slot vlan port Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number Field type <Eqpt::VpiId> - atm VPI Field type <Eqpt::VciId> - atm VCI Field type <Eqpt::PonId> - the PON identifier Field type <Eqpt::XPonId> - the XGS PON identifier Field type <Eqpt::M25GPonId> - the 25G PON identifier Field type <Eqpt::ComboPonId> - the comboPON identifier Field type <Eqpt::ChannelPairId> - the channel pair identifier Field type <Eqpt::ChannelGroupId> - the channel group identifier Field type <Eqpt::SubChannelGroupId> - the subchannel group identifier Field type <Eqpt::BundleId> - the BUNDLE identifier Field type <Eqpt::OntId> - the ONT identifier Field type <Eqpt::Ng2OntId> - the NG2 ONT identifier Possible values: - voip : virtual uni identifier obsolete alternative replaced by vuni - vuni : virtual uni identifier Possible values: - vuni : virtual NGPON2 uni identifier Field type <Eqpt::OntSlotId> - the ONT SLOT identifier Field type <Eqpt::OntPortId> - the ONT PORT identifier Field type <Eqpt::Ng2OntSlotId> - the NGPON2 ONT SLOT identifier Field type <Eqpt::Ng2OntPortId> - the NGPON2 ONT PORT identifier	

name	Type	Description
	Field type <Eqpt::LLId> - the LLID identifier, range 1 for EPON, range 1-8 for DPOE Possible values: - stacked : stacked vlan identity Field type <Eqpt::UnstackedVlan> - unstacked vlan id Field type <Eqpt::SVlan> - service vlan id Field type <Eqpt::CVlan> - customer vlan id Field type <Eqpt::VlanId> - VLAN id Field type <Eqpt::LogicalId> - logical id Field type <Eqpt::VrflId> - VRF id	
newonu-index	Parameter type: <SignedInteger> - a signed integer	the newonu index for the pon alarm <i>This element is only shown in detail mode.</i>
add-info	Parameter type: <Alarm::AdditionalInfo> - string to identify the owner (example: Tom) - length: x<=512	some additional information about the table entry. <i>This element is only shown in detail mode.</i>
newont-mac	Parameter type: <Alarm::MacAddr> - mac-address (example : 01:02:03:04:05:06) - length: 6	new ONT Mac address <i>This element is only shown in detail mode.</i>
newont-loid	Parameter type: <Alarm::AuthId> - Authentication ID - length: 1<=x<=24	new ONT LOID <i>This element is only shown in detail mode.</i>

Only Show Details: current alarm status

name	Type	Description
onu-unprovisioned	Parameter type: <Alarm::checkNewOnu> (newonu not-newonu) Possible values: - newonu : new onu is exist - not-newonu : new onu is not exist	new onu is exist or not. <i>This element is only shown in detail mode.</i>

126- Interface Status Commands

126.1 Interface Status Command Tree	126-5971
126.2 Interface Alarm Status Command	126-5972
126.3 Physical Interface Status Command	126-5974
126.4 Interface Status Command	126-5975
126.5 Interface Test Status Command	126-5986
126.6 Interface Stack Status Command	126-5992
126.7 Interface Extensive Status Command	126-6002
126.8 Interface Troubleshooting Ethernet Statistics Commands	126-6004
126.9 Interface Sliding-Window Traffic Statistics Command	126-6007

126.1 Interface Status Command Tree

Description

This chapter gives an overview of nodes that are handled by "Interface Status Commands".

Command Tree

```
----show
  ----interface
    ----alarm
      - (interface-type)
    ----phy-itf-status
      - (shelf)
    ----port
      - (port)
    ----test
      - (port)
    ----stack
      - (higher)
      - lower
    ----availability
      - (port-type)
    ----trouble-shooting
      ----ethernet
        ----statistics
          - (slot-id)
    ----statistics
      - (port)
      - period
```

126.2 Interface Alarm Status Command

Command Description

This command shows the alarm configured for the interface and the default minimal severity with which the alarm is reported.

User Level

The command can be accessed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

```
> show interface alarm [ (interface-type) ]
```

Command Parameters

Table 126.2-1 "Interface Alarm Status Command" Resource Parameters

Resource Identifier	Type	Description
(interface-type)	Format: (xdsl-line ethernet-line shdsl-line voicefxs pon chpair chgroup subchgroup ont uni epon eont euni ellid lag ds1) Possible values: - xdsl-line : xdsl line - ethernet-line : ethernet line - shdsl-line : shdsl line - voicefxs : voicefxs - pon : pon interface - chpair : channelpair interface - chgroup : channelgroup interface - subchgroup : subchannelgroup interface - ont : ont interface - uni : uni interface	type of the interface

Resource Identifier	Type	Description
	- epon : epon interface - eont : epon ont interface - euni : epon uni interface - ellid : epon llid interface - lag : link aggregation group - ds1 : ds1 interface	

Command Output

Table 126.2-2 "Interface Alarm Status Command" Display parameters

Specific Information		
name	Type	Description
default-severity	Parameter <Itf::asamIfExtAlmReportingSeverityDefault> (indeterminate warning minor major critical) Possible values: - indeterminate : not a definite known severity - warning : just to inform as a warning - minor : not service affecting - major : service affecting - critical : service breaking	type: The default minimal severity for an alarm to be reported that will be used for interfaces. <i>This element is always shown.</i>

126.3 Physical Interface Status Command

Command Description

This command shows the summary of the physical interface, for example, the number of changes which occurred for the physical interface.

User Level

The command can be accessed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

```
> show interface phy-itf-status [ (shelf) ]
```

Command Parameters

Table 126.3-1 "Physical Interface Status Command" Resource Parameters

Resource Identifier	Type	Description
(shelf)	Format: <Eqpt::RackId> / <Eqpt::ShelfId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number	the physical position of the shelf

Command Output

Table 126.3-2 "Physical Interface Status Command" Display parameters

Specific Information		
name	Type	Description
no-of-change-occur	Parameter type: <Counter> - 32 bit counter	Number of state changes of physical lines, equipped on boards within this shelf. <i>This element is always shown.</i>

126.4 Interface Status Command

Command Description

This command shows all the parameters related to the interface such as the type of interface, current bandwidth of the interface, maximum size of the packet supported, and the connector present. All interfaces do not support each of these parameters.

Ethernet port interfaces supports 14 ethernet ports.

- Port 1 : **Internal** port used for management
- Port 2 : **External** port used for management
- Port 3 : **Used for L2CP OAM** traffic to BRAS
- Ports 4-14 : **Not used**

Ethernet, loop, slip supports largest-pkt-size, current-bandwidth, phy-addr, admin-status, opr-status, last-chg-opr-stat, in-octets, in-ucast-pkts, in-discard-pkts, in-err-pkts, out-err-pkts, pkts-unknown-proto, out-octets, high-speed, connector-present and media.

ATM supports phy-addr, opr-status, last-chg-opr-stat, in-octets, in-err-pkts, out-err-pkts, pkts-unknown-proto and out-octets.

Xdsl-Line and Bonding supports admin-status, opr-status and last-chg-opr-stat.

Bridge Port supports type and last-chg-opr-stat, the remaining interfaces supports opr-status and last-chg-opr-stat.

Shdsl-line supports info, name, admin-status, opr-status and last-chg-opr-stat.

voicefxs supports info, type, name, admin-status, opr-status, last-chg-opr-stat.

User Level

The command can be accessed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

```
> show interface port [ (port) ]
```

Command Parameters

Table 126.4-1 "Interface Status Command" Resource Parameters

Resource Identifier	Type	Description
(port)	Format: (xdsl-line : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> voicefxs : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> xdsl-channel : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> atm-if : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId>	the interface index

Resource Identifier	Type	Description
	atm-pvc : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::VpiId> : <Eqpt::VciId> bridge-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::VpiId> : <Eqpt::VciId> vlan-port:ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / <Eqpt::Ng2OntSlotId> / <Eqpt::Ng2OntPortId> : <Eqpt::UnstackedVlan> l2-vlan : <Eqpt::VlanId> ip : <Eqpt::LogicalId> sw-loopback slip uni:ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / <Eqpt::Ng2OntSlotId> / <Eqpt::Ng2OntPortId> vlan-port:ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / <Eqpt::Ng2OntSlotId> / <Eqpt::Ng2OntPortId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> atm-bonding : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> bonding : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> ip-gateway : <Eqpt::VrId> ip-line : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::VpiId> : <Eqpt::VciId> ip-line : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> shdsl-line : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> e1-line : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> atm-ima : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> ethernet-line : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> bridge-port:ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / vuni vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::VpiId> : <Eqpt::VciId> : <Eqpt::UnstackedVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::UnstackedVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::VpiId> : <Eqpt::VciId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> voip:ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> ip-line : vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::VpiId> : <Eqpt::VciId> : <Eqpt::UnstackedVlan> ip-line : vlan : <Eqpt::RackId> / <Eqpt::ShelfId> /	

Resource Identifier	Type	Description
	<code><Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::UnstackedVlan></code> <code> ip-line : vlan : <Eqpt::RackId> / <Eqpt::ShelfId> /</code> <code><Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::VpiId> :</code> <code><Eqpt::VciId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan></code> <code> ip-line : vlan : <Eqpt::RackId> / <Eqpt::ShelfId> /</code> <code><Eqpt::SlotId> / <Eqpt::PortId> : stacked : <Eqpt::SVlan> :</code> <code><Eqpt::CVlan></code> <code> vlan-port:ng2 : <Eqpt::ChannelGroupId> /</code> <code><Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / vuni :</code> <code>stacked : <Eqpt::SVlan> : <Eqpt::CVlan></code> <code> vlan-port:ng2 : <Eqpt::ChannelGroupId> /</code> <code><Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / vuni :</code> <code><Eqpt::UnstackedVlan></code> <code> chgroup : <Eqpt::ChannelGroupId></code> <code> subchgroup : <Eqpt::ChannelGroupId> /</code> <code><Eqpt::SubChannelGroupId></code> <code> bridge-port:ng2 : <Eqpt::ChannelGroupId> /</code> <code><Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> /</code> <code><Eqpt::Ng2OntSlotId> / <Eqpt::Ng2OntPortId></code> <code> atm-pvc : <Eqpt::RackId> / <Eqpt::ShelfId> /</code> <code><Eqpt::SlotId> / <Eqpt::PortId></code> <code> bridge-port : <Eqpt::RackId> / <Eqpt::ShelfId> /</code> <code><Eqpt::SlotId> / <Eqpt::PortId></code> <code> bridge-port : <Eqpt::RackId> / <Eqpt::ShelfId> /</code> <code><Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> /</code> <code><Eqpt::OntSlotId> / <Eqpt::OntPortId></code> <code> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> /</code> <code><Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> /</code> <code><Eqpt::OntSlotId> / <Eqpt::OntPortId> : stacked :</code> <code><Eqpt::SVlan> : <Eqpt::CVlan></code> <code> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> /</code> <code><Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> /</code> <code><Eqpt::OntSlotId> / <Eqpt::OntPortId> :</code> <code><Eqpt::UnstackedVlan></code> <code> pon : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> /</code> <code><Eqpt::PonId></code> <code> ont : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> /</code> <code><Eqpt::PonId> / <Eqpt::OntId></code> <code> uni : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> /</code> <code><Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> /</code> <code><Eqpt::OntPortId></code> <code> bridge-port : <Eqpt::RackId> / <Eqpt::ShelfId> /</code> <code><Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / voip</code> <code> bridge-port : <Eqpt::RackId> / <Eqpt::ShelfId> /</code> <code><Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / vuni</code> <code> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> /</code> <code><Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / voip :</code> <code>stacked : <Eqpt::SVlan> : <Eqpt::CVlan></code> <code> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> /</code> <code><Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / vuni :</code> <code>stacked : <Eqpt::SVlan> : <Eqpt::CVlan></code> <code> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> /</code> <code><Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / voip :</code> <code><Eqpt::UnstackedVlan></code> <code> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> /</code> <code><Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / vuni :</code> <code><Eqpt::UnstackedVlan></code>	

Resource Identifier	Type	Description
	voip : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> la-group : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::LLId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> bridge-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::LLId> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::LLId> : <Eqpt::UnstackedVlan> mpm : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::ComboPonId> x-pon : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::XPonId> 25g-pon : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::M25GPonId> dist-router-interface : slot-stacked : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::SVlan> : <Eqpt::CVlan> dist-router-interface : slot-vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::UnstackedVlan> bundle : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::BundleId> chpair : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::ChannelPairId> ont:ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId>) Possible values: - xdsl-line : a static xdsl line interface - xdsl-channel : a static xdsl channel interface - atm-if : a static atm interface - atm-pvc : an atm pvc interface - bridge-port : a vlan bridge-port - bridge-port:ng2 : a ngpon2 vlan bridge-port - l2-vlan : a l2-vlan interface - ip : an ip interface - sw-loopback : a software loopback interface - slip : a slip interface - atm-bonding : atm bonding obsolete alternative replaced by bonding - bonding : bonding - ip-gateway : ip user gateway interface - ip-line : ip line interface - shdsl-line : a static shdsl line interface - e1-line : a e1 line interface - atm-ima : atm ima - ethernet-line : an ethernet line interface - vlan-port : vlan port - vlan-port:ng2 : a ngpon2 vlan port - pon : pon - x-pon : xgs pon - 25g-pon : 25g pon - chpair : channelpair - chgroup : channelgroup	

Resource Identifier	Type	Description
	- subchgroup : subchannelgroup - bundle : bundle - ont : ont - ont:ng2 : ngpon2 ONT style identification - uni : uni - uni:ng2 : ngpon2 UNI style identification - voip : voip - voip:ng2 : voip - la-group : link aggregation group - dist-router-interface : dist router interface - voicefxs : voicefxs - mpm : multi-pon module Possible values: - vlan : vlan port Possible values: - slot-vlan : slot unstacked - slot-stacked : slot vlan port Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number Field type <Eqpt::VpiId> - atm VPI Field type <Eqpt::VciId> - atm VCI Field type <Eqpt::PonId> - the PON identifier Field type <Eqpt::XPonId> - the XGS PON identifier Field type <Eqpt::M25GPonId> - the 25G PON identifier Field type <Eqpt::ComboPonId> - the comboPON identifier Field type <Eqpt::ChannelPairId> - the channel pair identifier Field type <Eqpt::ChannelGroupId> - the channel group identifier Field type <Eqpt::SubChannelGroupId> - the subchannel group identifier Field type <Eqpt::BundleId> - the BUNDLE identifier Field type <Eqpt::OntId> - the ONT identifier Field type <Eqpt::Ng2OntId> - the NG2 ONT identifier Possible values: - voip : virtual uni identifier obsolete alternative replaced by vuni - vuni : virtual uni identifier Possible values: - vuni : virtual NGPON2 uni identifier Field type <Eqpt::OntSlotId> - the ONT SLOT identifier	

Resource Identifier	Type	Description
	Field type <Eqpt::OntPortId> - the ONT PORT identifier Field type <Eqpt::Ng2OntSlotId> - the NGPON2 ONT SLOT identifier Field type <Eqpt::Ng2OntPortId> - the NGPON2 ONT PORT identifier Field type <Eqpt::LLId> - the LLID identifier, range 1 for EPON, range 1-8 for DPOE Possible values: - stacked : stacked vlan identity Field type <Eqpt::UnstackedVlan> - unstacked vlan id Field type <Eqpt::SVlan> - service vlan id Field type <Eqpt::CVlan> - customer vlan id Field type <Eqpt::VlanId> - VLAN id Field type <Eqpt::LogicalId> - logical id Field type <Eqpt::VrflId> - VRF id	

Command Output

Table 126.4-2 "Interface Status Command" Display parameters

Specific Information		
name	Type	Description
if-index	Parameter type: <SignedInteger> - a signed integer	Specifies a unique value for each interface. <i>This element is only shown in detail mode.</i>
info	Parameter type: <PrintableString> - printable string	A textual string containing information about the interface. This string includes the name of the manufacturer, the product name and the version of the interface hardware/software. <i>This element is only shown in detail mode.</i>
type	Parameter type: <Itf::IANAifType> (ethernet sw-loopback slip atm atm-bonding bonding xdsl-line xdsl-channel atm-vci-ep bridge-port l2-vlan ip-fwd efm atm-ima e1	Specifies the type of interface. <i>This element is only shown in detail mode.</i>

name	Type	Description
	shdsl ip-gateway pon chpair chgroup subchgroup bundle ont uni epon eont euni ellid lag dist-router-interface voicefxs com) Possible values: - ethernet : ethernet CSMACD - sw-loopback : software loopback interface - slip : generic SLIP interface - atm : atm interface - atm-bonding : atm bonding obsolete alternative replaced by bonding - bonding : bonding - xdsl-line : xdsl line - xdsl-channel : xdsl channel - atm-vci-ep : ATM VCI end point - bridge-port : transparent bridge interface - l2-vlan : layer 3 VLAN using IPX - ip-fwd : IP forwarding interface - efm : EFM interface - atm-ima : atm-ima interface - e1 : e1 interface - shdsl : shdsl interface - ip-gateway : vrf interface - pon : pon interface - chpair : channelpair interface - chgroup : channelgroup interface - subchgroup : subchannelgroup interface - bundle : bundle interface - ont : ont interface - uni : uni interface - epon : epon interface - eont : epon ont interface - euni : epon uni interface - ellid : epon llid interface - lag : link aggregation group - dist-router-interface : dist router interface - voicefxs : voicefxs - com : comboPon	
name	Parameter type: <PrintableString> - printable string	Name of the interface. <i>This element is only shown in detail mode.</i>
high-speed	Parameter type: <If::ifHighSpeed> - interface bandwidth - unit: Mbit/sec	Specifies interface's current bandwidth. <i>This element is only shown in</i>

126 Interface Status Commands

name	Type	Description
		<i>detail mode.</i>
connector-present	Parameter type: <Ifc::ifConnectorPresent> (not-applicable has-connector no-connector) Possible values: - not-applicable : not-applicable - has-connector : interface sublayer has a physical connector - no-connector : interface sublayer doesn't have a physical connector	Specifies the interface sublayer has a physical connector or not. <i>This element is only shown in detail mode.</i>
media	Parameter type: <Object> - an object identifier	Specifies information about the particular media being used to realize the interface. <i>This element is only shown in detail mode.</i>
largest-pkt-size	Parameter type: <Ifc::MtuSize> - packet size - unit: octets	The size of the largest packet which can be sent/received on the interface, specified in octets. For interfaces that are used for transmitting network datagrams, this is the size of the largest network datagram that can be sent on the interface. <i>This element is only shown in detail mode.</i>
current-bandwidth	Parameter type: <Ifc::ifSpeed> - interface bandwidth - unit: bits/sec	Specifies the interface's current bandwidth. <i>This element is only shown in detail mode.</i>
phy-addr	Parameter type: <Ifc::PhyAddress> - mac address (aa:bb:cc:a1:02:03) - unit: Byte - length: 6	The interface's address at its protocol sub-layer. <i>This element is only shown in detail mode.</i>
admin-status	Parameter type: <Ifc::ifAdminStatus> (not-appl up down testing) Possible values: - not-appl : not-applicable - up : admin status is up - down : admin status is down - testing : no operational packets can be passed	Specifies state of the interface. <i>This element is always shown.</i>
opr-status	Parameter type: <Ifc::ifOperStatus> (up down testing unknown dormant no-value) Possible values: - up : up, traffic can pass - down : down, no traffic is passing - testing : testing, no traffic is passing - unknown : unknown - dormant : dormant, no traffic is passing - no-value : no entry in the table	The current operational state of the interface. <i>This element is always shown.</i>

name	Type	Description
last-chg-opr-stat	Parameter type: <Itf::ElapsedTime10Msec> - the time elapsed since a certain event	The value of elapsed time since the interface entered its current operational state. <i>This element is only shown in detail mode.</i>
pkts-unknown-proto	Parameter type: <Itf::Counter> - 32 bit counter	Number of packets(for packet-oriented interfaces) or transmission units(for character-oriented interfaces) received via the interface which were discarded because of an unknown or unsupported protocol. <i>This element is only shown in detail mode.</i>
in-octets	Parameter type: <Itf::Counter> - 32 bit counter	The total number of octets received on the interface, including framing characters. <i>This element is only shown in detail mode.</i>
out-octets	Parameter type: <Itf::Counter> - 32 bit counter	The total number of octets transmitted out of the interface, including framing characters. <i>This element is only shown in detail mode.</i>
in-ucast-pkts	Parameter type: <Itf::Counter> - 32 bit counter	The number of packets, delivered by this sub-layer to a higher (sub-)layer, which were not addressed to a multicast or broadcast address at this sub-layer. <i>This element is only shown in detail mode.</i>
out-ucast-pkts	Parameter type: <Itf::Counter> - 32 bit counter	The total number of packets that higher-level protocols requested be transmitted, and which were not addressed to a multicast or broadcast address at this sub-layer. <i>This element is only shown in detail mode.</i>
in-mcast-pkts	Parameter type: <Itf::Counter> - 32 bit counter	The number of packets, transmitted by this sub-layer, which were addressed to a multicast address at this sub-layer. <i>This element is only shown in detail mode.</i>
out-mcast-pkts	Parameter type: <Itf::Counter> - 32 bit counter	The total number of packets that higher-level protocols requested be transmitted, and which were addressed to a multicast address at this sub-layer. <i>This element is only shown in detail mode.</i>
in-broadcast-pkts	Parameter type: <Itf::Counter> - 32 bit counter	The number of packets, delivered by this sub-layer to a higher

126 Interface Status Commands

name	Type	Description
		(sub-)layer, which were addressed to a broadcast address at this sub-layer. <i>This element is only shown in detail mode.</i>
out-broadcast-pkts	Parameter type: <Itf::Counter> - 32 bit counter	The total number of packets that higher-level protocols requested be transmitted, and which were addressed to a broadcast address at this sub-layer. <i>This element is only shown in detail mode.</i>
in-discard-pkts	Parameter type: <Itf::Counter> - 32 bit counter	The number of inbound packets which were chosen to be discarded even though no errors had been detected to prevent their being deliverable to a higher-layer protocol. One possible reason for discarding such a packet could be to free up buffer space. <i>This element is only shown in detail mode.</i>
out-discard-pkts	Parameter type: <Itf::Counter> - 32 bit counter	The number of outbound packets which were chosen to be discarded even though no errors had been detected to prevent them being transmitted. One possible reason for discarding such a packet could be to free up buffer space. <i>This element is only shown in detail mode.</i>
in-err-pkts	Parameter type: <Itf::Counter> - 32 bit counter	Number of inbound packets(for packet-oriented interfaces) or transmission units(for character-oriented interfaces) that contained errors preventing them from being deliverable to a higher-layer protocol. <i>This element is only shown in detail mode.</i>
out-err-pkts	Parameter type: <Itf::Counter> - 32 bit counter	The number of outbound packets(for packet-oriented interfaces) or transmission units(for character-oriented interfaces) that could not be transmitted because of errors. <i>This element is only shown in detail mode.</i>
in-octets-hc	Parameter type: <Itf::Counter64> - 64 bit counter	The total number of octets received on the interface, including framing characters. <i>This element is only shown in detail mode.</i>
out-octets-hc	Parameter type: <Itf::Counter64> - 64 bit counter	The total number of octets transmitted out of the interface,

name	Type	Description
		including framing characters. <i>This element is only shown in detail mode.</i>
in-ucast-pkts-hc	Parameter type: <Itf::Counter64> - 64 bit counter	The number of packets, delivered by this sub-layer to a higher (sub-)layer, which were not addressed to a multicast or broadcast address at this sub-layer. <i>This element is only shown in detail mode.</i>
out-ucast-pkts-hc	Parameter type: <Itf::Counter64> - 64 bit counter	The number of packets, transmitted by this sub-layer, which were not addressed to a multicast or broadcast address at this sub-layer. <i>This element is only shown in detail mode.</i>
in-mcast-pkts-hc	Parameter type: <Itf::Counter64> - 64 bit counter	The number of packets, delivered by this sub-layer to a higher (sub-)layer, which were addressed to a multicast address at this sub-layer. <i>This element is only shown in detail mode.</i>
out-mcast-pkts-hc	Parameter type: <Itf::Counter64> - 64 bit counter	The number of packets, transmitted by this sub-layer, which were addressed to a multicast address at this sub-layer. <i>This element is only shown in detail mode.</i>
in-broadcast-pkts-hc	Parameter type: <Itf::Counter64> - 64 bit counter	The number of packets, delivered by this sub-layer to a higher (sub-)layer, which were addressed to a broadcast address at this sub-layer. <i>This element is only shown in detail mode.</i>
out-broadcast-pkts-hc	Parameter type: <Itf::Counter64> - 64 bit counter	The number of packets, transmitted by this sub-layer, which were addressed to a broadcast address at this sub-layer. <i>This element is only shown in detail mode.</i>

126.5 Interface Test Status Command

Command Description

This command shows the parameters related to the testing of an interface.

Metallic Test Access is an example of an interface test. The result of the Metallic Test Access interface test is shown with this command.

voicefxs interface is not supported yet but will be supported in future.

User Level

The command can be accessed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

```
> show interface test [ (port) ]
```

Command Parameters

Table 126.5-1 "Interface Test Status Command" Resource Parameters

Resource Identifier	Type	Description
(port)	Format: (xdsl-line : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> voicefxs : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> xdsl-channel : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> atm-if : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> atm-pvc : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::VpiId> : <Eqpt::VciId> bridge-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::VpiId> : <Eqpt::VciId> vlan-port:ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / <Eqpt::Ng2OntSlotId> / <Eqpt::Ng2OntPortId> : <Eqpt::UnstackedVlan> l2-vlan : <Eqpt::VlanId> ip : <Eqpt::LogicalId> sw-loopback slip uni:ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> /	index (1/1/3/0..) of rack/shelf/slot/port

Resource Identifier	Type	Description
	<code><Eqpt::Ng2OntSlotId> / <Eqpt::Ng2OntPortId></code> <code> vlan-port:ng2 : <Eqpt::ChannelGroupId> /</code> <code><Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> /</code> <code><Eqpt::Ng2OntSlotId> / <Eqpt::Ng2OntPortId> : stacked :</code> <code><Eqpt::SVlan> : <Eqpt::CVlan></code> <code> atm-bonding : <Eqpt::RackId> / <Eqpt::ShelfId> /</code> <code><Eqpt::SlotId> / <Eqpt::PortId></code> <code> bonding : <Eqpt::RackId> / <Eqpt::ShelfId> /</code> <code><Eqpt::SlotId> / <Eqpt::PortId></code> <code> ip-gateway : <Eqpt::VrfId></code> <code> ip-line : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId></code> <code>/ <Eqpt::PortId> : <Eqpt::VpId> : <Eqpt::VciId></code> <code> ip-line : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId></code> <code>/ <Eqpt::PortId></code> <code> shdsl-line : <Eqpt::RackId> / <Eqpt::ShelfId> /</code> <code><Eqpt::SlotId> / <Eqpt::PortId></code> <code> e1-line : <Eqpt::RackId> / <Eqpt::ShelfId> /</code> <code><Eqpt::SlotId> / <Eqpt::PortId></code> <code> atm-ima : <Eqpt::RackId> / <Eqpt::ShelfId> /</code> <code><Eqpt::SlotId> / <Eqpt::PortId></code> <code> ethernet-line : <Eqpt::RackId> / <Eqpt::ShelfId> /</code> <code><Eqpt::SlotId> / <Eqpt::PortId></code> <code> bridge-port:ng2 : <Eqpt::ChannelGroupId> /</code> <code><Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / vuni</code> <code> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> /</code> <code><Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::VpId> :</code> <code><Eqpt::VciId> : <Eqpt::UnstackedVlan></code> <code> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> /</code> <code><Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::UnstackedVlan></code> <code> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> /</code> <code><Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::VpId> :</code> <code><Eqpt::VciId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan></code> <code> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> /</code> <code><Eqpt::SlotId> / <Eqpt::PortId> : stacked : <Eqpt::SVlan> :</code> <code><Eqpt::CVlan></code> <code> voip:ng2 : <Eqpt::ChannelGroupId> /</code> <code><Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId></code> <code> ip-line : vlan : <Eqpt::RackId> / <Eqpt::ShelfId> /</code> <code><Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::VpId> :</code> <code><Eqpt::VciId> : <Eqpt::UnstackedVlan></code> <code> ip-line : vlan : <Eqpt::RackId> / <Eqpt::ShelfId> /</code> <code><Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::UnstackedVlan></code> <code> ip-line : vlan : <Eqpt::RackId> / <Eqpt::ShelfId> /</code> <code><Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::VpId> :</code> <code><Eqpt::VciId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan></code> <code> ip-line : vlan : <Eqpt::RackId> / <Eqpt::ShelfId> /</code> <code><Eqpt::SlotId> / <Eqpt::PortId> : stacked : <Eqpt::SVlan> :</code> <code><Eqpt::CVlan></code> <code> vlan-port:ng2 : <Eqpt::ChannelGroupId> /</code> <code><Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / vuni :</code> <code>stacked : <Eqpt::SVlan> : <Eqpt::CVlan></code> <code> vlan-port:ng2 : <Eqpt::ChannelGroupId> /</code> <code><Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / vuni :</code> <code><Eqpt::UnstackedVlan></code> <code> chgroup : <Eqpt::ChannelGroupId></code> <code> subchgroup : <Eqpt::ChannelGroupId> /</code> <code><Eqpt::SubChannelGroupId></code>	

Resource Identifier	Type	Description
	bridge-port:ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / <Eqpt::Ng2OntSlotId> / <Eqpt::Ng2OntPortId> atm-pvc : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> bridge-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> bridge-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> / <Eqpt::OntPortId> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> / <Eqpt::OntPortId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> / <Eqpt::OntPortId> : <Eqpt::UnstackedVlan> pon : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> ont : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> uni : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> / <Eqpt::OntPortId> bridge-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / voip bridge-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / vuni vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / voip : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / vuni : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / voip : <Eqpt::UnstackedVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / vuni : <Eqpt::UnstackedVlan> voip : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> la-group : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::LLId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> bridge-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::LLId> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::LLId> : <Eqpt::UnstackedVlan> mpm : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::ComboPonId> x-pon : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId>	

Resource Identifier	Type	Description
	<pre> / <Eqpt::XPonId> 25g-pon : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::M25GPonId> dist-router-interface : slot-stacked : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::SVlan> : <Eqpt::CVlan> dist-router-interface : slot-vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::UnstackedVlan> bundle : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::BundleId> chpair : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::ChannelPairId> ont:ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId>) Possible values: - xdsl-line : a static xdsl line interface - xdsl-channel : a static xdsl channel interface - atm-if : a static atm interface - atm-pvc : an atm pvc interface - bridge-port : a vlan bridge-port - bridge-port:ng2 : a ngpon2 vlan bridge-port - l2-vlan : a l2-vlan interface - ip : an ip interface - sw-loopback : a software loopback interface - slip : a slip interface - atm-bonding : atm bonding obsolete alternative replaced by bonding - bonding : bonding - ip-gateway : ip user gateway interface - ip-line : ip line interface - shdsl-line : a static shdsl line interface - e1-line : a e1 line interface - atm-ima : atm ima - ethernet-line : an ethernet line interface - vlan-port : vlan port - vlan-port:ng2 : a ngpon2 vlan port - pon : pon - x-pon : xgs pon - 25g-pon : 25g pon - chpair : channelpair - chgroup : channelgroup - subchgroup : subchannelgroup - bundle : bundle - ont : ont - ont:ng2 : ngpon2 ONT style identification - uni : uni - uni:ng2 : ngpon2 UNI style identification - voip : voip - voip:ng2 : voip - la-group : link aggregation group - dist-router-interface : dist router interface - voicefxs : voicefxs - mpm : multi-pon module Possible values: - vlan : vlan port Possible values: - slot-vlan : slot unstacked </pre>	

Resource Identifier	Type	Description
	- slot-stacked : slot vlan port - Field type <Eqpt::RackId> - the rack number - Field type <Eqpt::ShelfId> - the shelf number - Field type <Eqpt::SlotId> - the LT slot number - Field type <Eqpt::PortId> - the port number - Field type <Eqpt::VpiId> - atm VPI - Field type <Eqpt::VciId> - atm VCI - Field type <Eqpt::PonId> - the PON identifier - Field type <Eqpt::XPonId> - the XGS PON identifier - Field type <Eqpt::M25GPonId> - the 25G PON identifier - Field type <Eqpt::ComboPonId> - the comboPON identifier - Field type <Eqpt::ChannelPairId> - the channel pair identifier - Field type <Eqpt::ChannelGroupId> - the channel group identifier - Field type <Eqpt::SubChannelGroupId> - the subchannel group identifier - Field type <Eqpt::BundleId> - the BUNDLE identifier - Field type <Eqpt::OntId> - the ONT identifier - Field type <Eqpt::Ng2OntId> - the NG2 ONT identifier - Possible values: - voip : virtual uni identifier - obsolete alternative replaced by vuni - vuni : virtual uni identifier - Possible values: - vuni : virtual NGPON2 uni identifier - Field type <Eqpt::OntSlotId> - the ONT SLOT identifier - Field type <Eqpt::OntPortId> - the ONT PORT identifier - Field type <Eqpt::Ng2OntSlotId> - the NGPON2 ONT SLOT identifier - Field type <Eqpt::Ng2OntPortId> - the NGPON2 ONT PORT identifier - Field type <Eqpt::LLId> - the LLID identifier,range 1 for EPON,range 1-8 for DPOE - Possible values: - stacked : stacked vlan identity - Field type <Eqpt::UnstackedVlan> - unstacked vlan id - Field type <Eqpt::SVlan> - service vlan id - Field type <Eqpt::CVlan> - customer vlan id	

Resource Identifier	Type	Description
	Field type <Eqpt::VlanId> - VLAN id Field type <Eqpt::LogicalId> - logical id Field type <Eqpt::VrfId> - VRF id	

Command Output

Table 126.5-2 "Interface Test Status Command" Display parameters

Specific Information		
name	Type	Description
id	Parameter type: <TestAndIncr> - TestAndIncr - range: [0...2147483647]	Specifies the current invocation of the interface's test. <i>This element is always shown.</i>
result	Parameter type: <Itf::ifTestResult> (none success in-progress not-supported unable-to-run aborted failed) Possible values: - none : no tests have been requested since the last reset - success : test successfully completed - in-progress : test is still in progress - not-supported : test is not supported - unable-to-run : test is unable to run - aborted : test is aborted - failed : test is failed	Specifies the result of the most recently requested test <i>This element is always shown.</i>
code	Parameter type: <Object> - an object identifier	Specifies a code which contains more specific information on the test result <i>This element is always shown.</i>

126.6 Interface Stack Status Command

Command Description

This command shows the status of the stack.

User Level

The command can be accessed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

```
> show interface stack [ (higher) [ lower <Itf::InterfaceStack> ] ]
```

Command Parameters

Table 126.6-1 "Interface Stack Status Command" Resource Parameters

Resource Identifier	Type	Description
(higher)	Format: (xdsl-line : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> voicefxs : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> xdsl-channel : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> atm-if : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> atm-pvc : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::VpiId> : <Eqpt::VciId> bridge-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::VpiId> : <Eqpt::VciId> 25g-pon : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::M25GPonId> l2-vlan : <Eqpt::VlanId> ip : <Eqpt::LogicalId> sw-loopback slip vlan-port:ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / <Eqpt::Ng2OntSlotId> / <Eqpt::Ng2OntPortId> : <Eqpt::UnstackedVlan> vlan-port:ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / <Eqpt::Ng2OntSlotId> / <Eqpt::Ng2OntPortId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> atm-bonding : <Eqpt::RackId> / <Eqpt::ShelfId> /	a higher layer interface index

Resource Identifier	Type	Description
	<code><Eqpt::SlotId> / <Eqpt::PortId></code> <code> bonding : <Eqpt::RackId> / <Eqpt::ShelfId> /</code> <code><Eqpt::SlotId> / <Eqpt::PortId></code> <code> ip-gateway : <Eqpt::VrfId></code> <code> ip-line : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId></code> <code>/ <Eqpt::PortId> : <Eqpt::VpiId> : <Eqpt::VciId></code> <code> ip-line : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId></code> <code>/ <Eqpt::PortId></code> <code> shdsl-line : <Eqpt::RackId> / <Eqpt::ShelfId> /</code> <code><Eqpt::SlotId> / <Eqpt::PortId></code> <code> e1-line : <Eqpt::RackId> / <Eqpt::ShelfId> /</code> <code><Eqpt::SlotId> / <Eqpt::PortId></code> <code> atm-ima : <Eqpt::RackId> / <Eqpt::ShelfId> /</code> <code><Eqpt::SlotId> / <Eqpt::PortId></code> <code> ethernet-line : <Eqpt::RackId> / <Eqpt::ShelfId> /</code> <code><Eqpt::SlotId> / <Eqpt::PortId></code> <code> voip:ng2 : <Eqpt::ChannelGroupId> /</code> <code><Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId></code> <code> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> /</code> <code><Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::VpiId> :</code> <code><Eqpt::VciId> : <Eqpt::UnstackedVlan></code> <code> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> /</code> <code><Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::UnstackedVlan></code> <code> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> /</code> <code><Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::VpiId> :</code> <code><Eqpt::VciId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan></code> <code> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> /</code> <code><Eqpt::SlotId> / <Eqpt::PortId> : stacked : <Eqpt::SVlan> :</code> <code><Eqpt::CVlan></code> <code> bridge-port:ng2 : <Eqpt::ChannelGroupId> /</code> <code><Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / vuni</code> <code> ip-line : vlan : <Eqpt::RackId> / <Eqpt::ShelfId> /</code> <code><Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::VpiId> :</code> <code><Eqpt::VciId> : <Eqpt::UnstackedVlan></code> <code> ip-line : vlan : <Eqpt::RackId> / <Eqpt::ShelfId> /</code> <code><Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::UnstackedVlan></code> <code> ip-line : vlan : <Eqpt::RackId> / <Eqpt::ShelfId> /</code> <code><Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::VpiId> :</code> <code><Eqpt::VciId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan></code> <code> ip-line : vlan : <Eqpt::RackId> / <Eqpt::ShelfId> /</code> <code><Eqpt::SlotId> / <Eqpt::PortId> : stacked : <Eqpt::SVlan> :</code> <code><Eqpt::CVlan></code> <code> uni:ng2 : <Eqpt::ChannelGroupId> /</code> <code><Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / vuni</code> <code> uni:ng2 : <Eqpt::ChannelGroupId> /</code> <code><Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> /</code> <code><Eqpt::Ng2OntSlotId> / <Eqpt::Ng2OntPortId></code> <code> bridge-port:ng2 : <Eqpt::ChannelGroupId> /</code> <code><Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> /</code> <code><Eqpt::Ng2OntSlotId> / <Eqpt::Ng2OntPortId></code> <code> ont:ng2 : <Eqpt::ChannelGroupId> /</code> <code><Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId></code> <code> atm-pvc : <Eqpt::RackId> / <Eqpt::ShelfId> /</code> <code><Eqpt::SlotId> / <Eqpt::PortId></code> <code> bridge-port : <Eqpt::RackId> / <Eqpt::ShelfId> /</code> <code><Eqpt::SlotId> / <Eqpt::PortId></code> <code> no-interface</code>	

Resource Identifier	Type	Description
	bridge-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> / <Eqpt::OntPortId> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> / <Eqpt::OntPortId> : <Eqpt::UnstackedVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> / <Eqpt::OntPortId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> pon : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> ont : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> uni : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> / <Eqpt::OntPortId> bridge-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / voip bridge-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / vuni vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / voip : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / vuni : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / voip : <Eqpt::UnstackedVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / vuni : <Eqpt::UnstackedVlan> voip : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> la-group : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::LLId> : <Eqpt::UnstackedVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::LLId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> bridge-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::LLId> mpm : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::ComboPonId> x-pon : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::XPonId> bundle : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::BundleId> chpair : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::ChannelPairId> chgroup : <Eqpt::ChannelGroupId> subchgroup : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId>)	

Resource Identifier	Type	Description
	Possible values: - xdsl-line : a static xdsl line interface - xdsl-channel : a static xdsl channel interface - atm-if : a static atm interface - atm-pvc : an atm pvc interface - bridge-port : a vlan bridge-port - bridge-port:ng2 : a ngpon2 vlan bridge-port - l2-vlan : a l2-vlan interface - ip : an ip interface - sw-loopback : a software loopback interface - slip : a slip interface - atm-bonding : atm bonding obsolete alternative replaced by bonding - bonding : bonding - ip-gateway : ip user gateway interface - ip-line : ip line interface - shdsl-line : a static shdsl line interface - atm-ima : atm ima - e1-line : e1 Interface - ethernet-line : an ethernet line interface - vlan-port : vlan port - vlan-port:ng2 : NGPON2 vlan port - pon : pon - x-pon : xgs pon - 25g-pon : 25g pon - chpair : channelpair - chgroup : channelgroup - subchgroup : subchannelgroup - bundle : bundle - ont : ont - ont:ng2 : ngpon2 ONT style identification - uni : uni - uni:ng2 : ngpon2 UNI style identification - voip : voip - voip:ng2 : ngpon2 voip - mpm : multi-pon module - la-group : link aggregation group - no-interface : no interface - voicefxs : voicefxs Possible values: - vlan : vlan port Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number Field type <Eqpt::VpiId> - atm VPI Field type <Eqpt::VciId> - atm VCI Field type <Eqpt::PonId> - the PON identifier Field type <Eqpt::XPonId> - the XGS PON identifier	

Resource Identifier	Type	Description
	Field type <Eqpt::M25GPonId> - the 25G PON identifier Field type <Eqpt::ComboPonId> - the comboPON identifier Field type <Eqpt::ChannelPairId> - the channel pair identifier Field type <Eqpt::ChannelGroupId> - the channel group identifier Field type <Eqpt::SubChannelGroupId> - the subchannel group identifier Field type <Eqpt::BundleId> - the BUNDLE identifier Field type <Eqpt::OntId> - the ONT identifier Field type <Eqpt::Ng2OntId> - the NG2 ONT identifier Possible values: - voip : virtual uni identifier obsolete alternative replaced by vuni - vuni : virtual uni identifier Possible values: - vuni : virtual NGPON2 uni identifier Field type <Eqpt::OntSlotId> - the ONT SLOT identifier Field type <Eqpt::OntPortId> - the ONT PORT identifier Field type <Eqpt::LLId> - the LLID identifier, range 1 for EPON, range 1-8 for DPOE Field type <Eqpt::Ng2OntSlotId> - the NGPON2 ONT SLOT identifier Field type <Eqpt::Ng2OntPortId> - the NGPON2 ONT PORT identifier Possible values: - stacked : stacked vlan identity Field type <Eqpt::UnstackedVlan> - unstacked vlan id Field type <Eqpt::SVlan> - service vlan id Field type <Eqpt::CVlan> - customer vlan id Field type <Eqpt::VlanId> - VLAN id Field type <Eqpt::LogicalId> - logical id Field type <Eqpt::VrfId> - VRF id	
lower	Parameter type: <Itf::InterfaceStack> Format: (xdsl-line : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> voicefxs : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> xdsl-channel : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> atm-if : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> atm-pvc : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::VpiId> :	a lower layer interface index

Resource Identifier	Type	Description
	<pre> <Eqpt::VciId> bridge-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::VpiId> : <Eqpt::VciId> 25g-pon : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::M25GPonId> l2-vlan : <Eqpt::VlanId> ip : <Eqpt::LogicalId> sw-loopback slip vlan-port:ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / <Eqpt::Ng2OntSlotId> / <Eqpt::Ng2OntPortId> : <Eqpt::UnstackedVlan> vlan-port:ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / <Eqpt::Ng2OntSlotId> / <Eqpt::Ng2OntPortId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> atm-bonding : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> bonding : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> ip-gateway : <Eqpt::VrfId> ip-line : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::VpiId> : <Eqpt::VciId> ip-line : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> shdsl-line : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> e1-line : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> atm-ima : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> ethernet-line : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> voip:ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::VpiId> : <Eqpt::VciId> : <Eqpt::UnstackedVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::UnstackedVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::VpiId> : <Eqpt::VciId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> bridge-port:ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / vuni ip-line : vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::VpiId> : <Eqpt::VciId> : <Eqpt::UnstackedVlan> ip-line : vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::UnstackedVlan> ip-line : vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::VpiId> : </pre>	

Resource Identifier	Type	Description
	<pre> <Eqpt::VcId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> ip-line : vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> uni.ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / vuni uni.ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / <Eqpt::Ng2OntSlotId> / <Eqpt::Ng2OntPortId> bridge-port.ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / <Eqpt::Ng2OntSlotId> / <Eqpt::Ng2OntPortId> ont.ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> atm-pvc : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> bridge-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> no-interface bridge-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> / <Eqpt::OntPortId> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> / <Eqpt::OntPortId> : <Eqpt::UnstackedVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> / <Eqpt::OntPortId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> pon : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> ont : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> uni : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> / <Eqpt::OntPortId> bridge-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / voip bridge-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / vuni vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / voip : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / vuni : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / voip : <Eqpt::UnstackedVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / vuni : <Eqpt::UnstackedVlan> voip : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> la-group : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> </pre>	

Resource Identifier	Type	Description
	vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::LLId> : <Eqpt::UnstackedVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::LLId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> bridge-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::LLId> mpm : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::ComboPonId> x-pon : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::XPonId> bundle : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::BundleId> chpair : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::ChannelPairId> chgroup : <Eqpt::ChannelGroupId> subchgroup : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId>) Possible values: - xdsl-line : a static xdsl line interface - xdsl-channel : a static xdsl channel interface - atm-if : a static atm interface - atm-pvc : an atm pvc interface - bridge-port : a vlan bridge-port - bridge-port:ng2 : a ngpon2 vlan bridge-port - l2-vlan : a l2-vlan interface - ip : an ip interface - sw-loopback : a software loopback interface - slip : a slip interface - atm-bonding : atm bonding obsolete alternative replaced by bonding - bonding : bonding - ip-gateway : ip user gateway interface - ip-line : ip line interface - shdsl-line : a static shdsl line interface - atm-ima : atm ima - e1-line : e1 Interface - ethernet-line : an ethernet line interface - vlan-port : vlan port - vlan-port:ng2 : NGPON2 vlan port - pon : pon - x-pon : xgs pon - 25g-pon : 25g pon - chpair : channelpair - chgroup : channelgroup - subchgroup : subchannelgroup - bundle : bundle - ont : ont - ont:ng2 : ngpon2 ONT style identification - uni : uni - uni:ng2 : ngpon2 UNI style identification - voip : voip - voip:ng2 : ngpon2 voip - mpm : multi-pon module - la-group : link aggregation group - no-interface : no interface	

Resource Identifier	Type	Description
	- voicefxs : voicefxs - Possible values: - vlan : vlan port - Field type <Eqpt::RackId> - the rack number - Field type <Eqpt::ShelfId> - the shelf number - Field type <Eqpt::SlotId> - the LT slot number - Field type <Eqpt::PortId> - the port number - Field type <Eqpt::VpiId> - atm VPI - Field type <Eqpt::VciId> - atm VCI - Field type <Eqpt::PonId> - the PON identifier - Field type <Eqpt::XPonId> - the XGS PON identifier - Field type <Eqpt::M25GPonId> - the 25G PON identifier - Field type <Eqpt::ComboPonId> - the comboPON identifier - Field type <Eqpt::ChannelPairId> - the channel pair identifier - Field type <Eqpt::ChannelGroupId> - the channel group identifier - Field type <Eqpt::SubChannelGroupId> - the subchannel group identifier - Field type <Eqpt::BundleId> - the BUNDLE identifier - Field type <Eqpt::OntId> - the ONT identifier - Field type <Eqpt::Ng2OntId> - the NG2 ONT identifier - Possible values: - voip : virtual uni identifier - obsolete alternative replaced by vuni - vuni : virtual uni identifier - Possible values: - vuni : virtual NGPON2 uni identifier - Field type <Eqpt::OntSlotId> - the ONT SLOT identifier - Field type <Eqpt::OntPortId> - the ONT PORT identifier - Field type <Eqpt::LLId> - the LLID identifier, range 1 for EPON, range 1-8 for DPOE - Field type <Eqpt::Ng2OntSlotId> - the NGPON2 ONT SLOT identifier - Field type <Eqpt::Ng2OntPortId> - the NGPON2 ONT PORT identifier - Possible values: - stacked : stacked vlan identity - Field type <Eqpt::UnstackedVlan> - unstacked vlan id - Field type <Eqpt::SVlan> - service vlan id	

Resource Identifier	Type	Description
	Field type <Eqpt::CVlan> - customer vlan id Field type <Eqpt::VlanId> - VLAN id Field type <Eqpt::LogicalId> - logical id Field type <Eqpt::VrflId> - VRF id	

126.7 Interface Extensive Status Command

Command Description

This command shows the parameters related to an interface such as next available port type, counter indicating number of state changes, and number of network interfaces.

User Level

The command can be accessed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

> show interface availability [(port-type)]

Command Parameters

Table 126.7-1 "Interface Extensive Status Command" Resource Parameters

Resource Identifier	Type	Description
(port-type)	Format: (xdsl-line ethernet-line voicefxs) Possible values: - xdsl-line : xdsl line - ethernet-line : ethernet line - voicefxs : voicefxs	the port type

Command Output

Table 126.7-2 "Interface Extensive Status Command" Display parameters

Common Information:common		
name	Type	Description
change-count	Parameter type: <Counter> - 32 bit counter	Number of state changes of the physical line. <i>This element is always shown.</i>
interface-cnt	Parameter type: <SignedInteger> - a signed integer	The number of network interfaces (regardless of their current state) present on this system. <i>This element is always shown.</i>
Specific Information		
name	Type	Description
next-available	Parameter type: <Itf::NextAvailable> (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId>	Specifies the next available physical interface can be retrieved.

name	Type	Description
	<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> / <Eqpt::OntPortId> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / voip <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / vuni) Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number Field type <Eqpt::PonId> - the PON identifier Field type <Eqpt::OntId> - the ONT identifier Possible values: - voip : virtual uni identifier obsolete alternative replaced by vuni - vuni : virtual uni identifier Field type <Eqpt::OntSlotId> - the ONT SLOT identifier Field type <Eqpt::OntPortId> - the ONT PORT identifier	<i>This element is always shown.</i>

126.8 Interface Troubleshooting Ethernet Statistics Commands

Command Description

This command shows the interface statistics for trouble shooting counters on FD-REM at far-end side. Statistics regarding frames received and transmitted at the remote LT side are displayed. All these counters are supported only for NDLT-G and NELT-B LT card, "not-supported" will be displayed for other LT cards.

User Level

The command can be accessed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

```
> show interface trouble-shooting ethernet statistics [ (slot-id) ]
```

Command Parameters

Table 126.8-1 "Interface Troubleshooting Ethernet Statistics Commands" Resource Parameters

Resource Identifier	Type	Description
(slot-id)	Format: (lt : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> lt-link : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::LtBackPlPortId>) Possible values: - lt : lt-slot - lt-link : lt-slot-port Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::LtBackPlPortId> - the lt backplane port number	slot id

Command Output

Table 126.8-2 "Interface Troubleshooting Ethernet Statistics Commands" Display parameters

Specific Information		
name	Type	Description
entry-status	Parameter type: <ETHITF::CounterEntryStatus>	The status of the entry. Valid

name	Type	Description
	(valid invalid) Possible values: - valid : counters for this ifIndex are valid - invalid : entry represents one of the device's addresses	indicates the counters have actual values, invalid means the counters are unreliable. <i>This element is always shown.</i>
in-octets-hc	Parameter type: <If::IfXCounter64> - 64 bit counter	The total number of octets received on the LT interface. <i>This element is always shown.</i>
out-octets-hc	Parameter type: <If::IfXCounter64> - 64 bit counter	The total number of octets transmitted out of the interface, including framing characters. <i>This element is always shown.</i>
in-discard-pkts	Parameter type: <If::IfCounter32> - 32 bit counter	The number of inbound packets which were chosen to be discarded even though no errors had been detected to prevent their being deliverable to a higher-layer protocol. One possible reason for discarding such a packet could be to free up buffer space. <i>This element is only shown in detail mode.</i>
fcs-err	Parameter type: <If::IfCounter32> - 32 bit counter	A count of frames received on a particular interface that has frame check error status is returned by the MAC service to the LLC (or other MAC user). <i>This element is always shown.</i>
align-err	Parameter type: <If::IfCounter32> - 32 bit counter	A count of frames received on a particular interface that has alignment error status returned by MAC service to the LLC(or other MAC user). <i>This element is always shown.</i>
oversize-pkts	Parameter type: <If::IfCounter32> - 32 bit counter	The total number of packets received that were longer than 1518 octets (excluding framing bits, but including FCS octets). <i>This element is always shown.</i>
undersize-pkts	Parameter type: <If::IfCounter32> - 32 bit counter	The total number of packets received that were less than 64 octets long (excluding framing bits, but including FCS octets) <i>This element is always shown.</i>
in-ucast-pkts-hc	Parameter type: <If::IfXCounter64> - 64 bit counter	The number of packets, delivered by this sub-layer to a higher (sub-)layer, which were not addressed to a multicast or broadcast address at this sub-layer. <i>This element is only shown in detail mode.</i>
in-mcast-pkts-hc	Parameter type: <If::IfXCounter64> - 64 bit counter	The number of packets, delivered by this sub-layer to a higher (sub-)layer, which were addressed to a multicast address

126 Interface Status Commands

name	Type	Description
		at this sub-layer. <i>This element is only shown in detail mode.</i>
in-broadcast-pkts-hc	Parameter type: <Itf::IfXCounter64> - 64 bit counter	The number of packets, delivered by this sub-layer to a higher (sub-)layer, which were addressed to a broadcast address at this sub-layer. <i>This element is only shown in detail mode.</i>
in-frames-hc	Parameter type: <Counter64> - 64 bit counter	The total number of packets, delivered by this sub-layer to a higher (sub-)layer <i>This element is only shown in detail mode.</i>
out-broadcast-pkts-hc	Parameter type: <Itf::IfXCounter64> - 64 bit counter	The number of packets, transmitted by this sub-layer, which were addressed to a broadcast address at this sub-layer. <i>This element is only shown in detail mode.</i>
out-mcast-pkts-hc	Parameter type: <Itf::IfXCounter64> - 64 bit counter	The number of packets, transmitted by this sub-layer, which were addressed to a multicast address at this sub-layer. <i>This element is only shown in detail mode.</i>
out-ucast-pkts-hc	Parameter type: <Itf::IfXCounter64> - 64 bit counter	The number of packets, transmitted by this sub-layer, which were not addressed to a multicast or broadcast address at this sub-layer. <i>This element is only shown in detail mode.</i>
out-frames-hc	Parameter type: <Counter64> - 64 bit counter	The total number of packets, delivered by this sub-layer to a higher (sub-)layer <i>This element is only shown in detail mode.</i>

126.9 Interface Sliding-Window Traffic Statistics Command

Command Description

This command allows the operator to show sliding-window traffic statistics rate on related interface.

User Level

The command can be accessed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

```
> show interface statistics [ (port) [ period <Itf::ifStatsSlidWin> ] ]
```

Command Parameters

Table 126.9-1 "Interface Sliding-Window Traffic Statistics Command" Resource Parameters

Resource Identifier	Type	Description
(port)	Format: chpair : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::ChannelPairId> Possible values: - chpair : channelpair Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::ChannelPairId> - the channel pair identifier	The interface port
period	Parameter type: <Itf::ifStatsSlidWin> Format: (5sec 1min 10min) Possible values: - 5sec : five seconds sliding-window - 1min : one mintue sliding-window - 10min : ten mintues sliding-window	The Sliding window period

Command Output

Table 126.9-2 "Interface Sliding-Window Traffic Statistics Command" Display parameters

Specific Information		
name	Type	Description
tx-pps	Parameter type: <Itf::ifStatsRateBypps> - interface statistics rate by Pkts/s - unit: Pkts/s	An average traffic rate on the interface port in downstream direction in units of packets per second during last appointed period. <i>This element is always shown.</i>
tx-mbps	Parameter type: <Itf::ifStatsRateByMbps> - interface statistics rate by Mbps - unit: Mbps - range: [0.0...15000.0]	An average traffic rate on the interface port in downstream direction in units of megabits per second during last appointed period. <i>This element is always shown.</i>
tx-discard-pps	Parameter type: <Itf::ifStatsRateBypps> - interface statistics rate by Pkts/s - unit: Pkts/s	An average discard traffic rate on the interface port in downstream direction in units of packets per second during last appointed period. <i>This element is always shown.</i>
tx-discard-mbps	Parameter type: <Itf::ifStatsRateByMbps> - interface statistics rate by Mbps - unit: Mbps - range: [0.0...15000.0]	An average discard traffic rate on the interface port in downstream direction in units of megabits per second during last appointed period. <i>This element is always shown.</i>
rx-pps	Parameter type: <Itf::ifStatsRateBypps> - interface statistics rate by Pkts/s - unit: Pkts/s	An average traffic rate on the interface port in upstream direction in units of packets per second during last appointed period. <i>This element is always shown.</i>
rx-mbps	Parameter type: <Itf::ifStatsRateByMbps> - interface statistics rate by Mbps - unit: Mbps - range: [0.0...15000.0]	An average traffic rate on the interface port in upstream direction in units of megabits per second during last appointed period. <i>This element is always shown.</i>
rx-discard-pps	Parameter type: <Itf::ifStatsRateBypps> - interface statistics rate by Pkts/s - unit: Pkts/s	An average discard traffic rate on the interface port in upstream direction in units of packets per second during last appointed period. <i>This element is always shown.</i>
rx-discard-mbps	Parameter type: <Itf::ifStatsRateByMbps> - interface statistics rate by Mbps - unit: Mbps - range: [0.0...15000.0]	An average discard traffic rate on the interface port in upstream direction in units of megabits per second during last appointed period. <i>This element is always shown.</i>
Only Show Details: traffic statistics rate by pps		
name	Type	Description
tx-ucast-pps	Parameter type: <Itf::ifStatsRateBypps> - interface statistics rate by Pkts/s - unit: Pkts/s	An average unicast traffic rate on the interface port in downstream direction in units of packets per

name	Type	Description
		second during last appointed period. <i>This element is only shown in detail mode.</i>
tx-mcast-pps	Parameter type: <Itf::ifStatsRateBypps> - interface statistics rate by Pkts/s - unit: Pkts/s	An average multicast traffic rate on the interface port in downstream direction in units of packets per second during last appointed period. <i>This element is only shown in detail mode.</i>
tx-bcast-pps	Parameter type: <Itf::ifStatsRateBypps> - interface statistics rate by Pkts/s - unit: Pkts/s	An average broadcast traffic rate on the interface port in downstream direction in units of packets per second during last appointed period. <i>This element is only shown in detail mode.</i>
tx-pps	Parameter type: <Itf::ifStatsRateBypps> - interface statistics rate by Pkts/s - unit: Pkts/s	An average traffic rate on the interface port in downstream direction in units of packets per second during last appointed period. <i>This element is only shown in detail mode.</i>
tx-discard-pps	Parameter type: <Itf::ifStatsRateBypps> - interface statistics rate by Pkts/s - unit: Pkts/s	An average discard traffic rate on the interface port in downstream direction in units of packets per second during last appointed period. <i>This element is only shown in detail mode.</i>
rx-ucast-pps	Parameter type: <Itf::ifStatsRateBypps> - interface statistics rate by Pkts/s - unit: Pkts/s	An average unicast traffic rate on the interface port in upstream direction in units of packets per second during last appointed period. <i>This element is only shown in detail mode.</i>
rx-mcast-pps	Parameter type: <Itf::ifStatsRateBypps> - interface statistics rate by Pkts/s - unit: Pkts/s	An average multicast traffic rate on the interface port in upstream direction in units of packets per second during last appointed period. <i>This element is only shown in detail mode.</i>
rx-bcast-pps	Parameter type: <Itf::ifStatsRateBypps> - interface statistics rate by Pkts/s - unit: Pkts/s	An average broadcast traffic rate on the interface port in upstream direction in units of packets per second during last appointed period. <i>This element is only shown in detail mode.</i>
rx-pps	Parameter type: <Itf::ifStatsRateBypps> - interface statistics rate by Pkts/s - unit: Pkts/s	An average traffic rate on the interface port in upstream direction in units of packets per second during last appointed

126 Interface Status Commands

name	Type	Description
		period. <i>This element is only shown in detail mode.</i>
rx-discard-pps	Parameter type: <Itf::ifStatsRateBypps> - interface statistics rate by Pkts/s - unit: Pkts/s	An average discard traffic rate on the interface port in upstream direction in units of packets per second during last appointed period. <i>This element is only shown in detail mode.</i>

Only Show Details: traffic statistics rate by mbps		
name	Type	Description
tx-ucast-mbps	Parameter type: <Itf::ifStatsRateByMbps> - interface statistics rate by Mbps - unit: Mbps - range: [0.0...15000.0]	An average unicast traffic rate on the interface port in downstream direction in units of megabits per second during last appointed period. <i>This element is only shown in detail mode.</i>
tx-mcast-mbps	Parameter type: <Itf::ifStatsRateByMbps> - interface statistics rate by Mbps - unit: Mbps - range: [0.0...15000.0]	An average multicast traffic rate on the interface port in downstream direction in units of megabits per second during last appointed period. <i>This element is only shown in detail mode.</i>
tx-bcast-mbps	Parameter type: <Itf::ifStatsRateByMbps> - interface statistics rate by Mbps - unit: Mbps - range: [0.0...15000.0]	An average broadcast traffic rate on the interface port in downstream direction in units of megabits per second during last appointed period. <i>This element is only shown in detail mode.</i>
tx-mbps	Parameter type: <Itf::ifStatsRateByMbps> - interface statistics rate by Mbps - unit: Mbps - range: [0.0...15000.0]	An average traffic rate on the interface port in downstream direction in units of megabits per second during last appointed period. <i>This element is only shown in detail mode.</i>
tx-discard-mbps	Parameter type: <Itf::ifStatsRateByMbps> - interface statistics rate by Mbps - unit: Mbps - range: [0.0...15000.0]	An average discard traffic rate on the interface port in downstream direction in units of megabits per second during last appointed period. <i>This element is only shown in detail mode.</i>
rx-ucast-mbps	Parameter type: <Itf::ifStatsRateByMbps> - interface statistics rate by Mbps - unit: Mbps - range: [0.0...15000.0]	An average unicast traffic rate on the interface port in upstream direction in units of megabits per second during last appointed period. <i>This element is only shown in detail mode.</i>
rx-mcast-mbps	Parameter type: <Itf::ifStatsRateByMbps> - interface statistics rate by Mbps - unit: Mbps	An average multicast traffic rate on the interface port in upstream direction in units of megabits per

name	Type	Description
	- range: [0.0...15000.0]	second during last appointed period. <i>This element is only shown in detail mode.</i>
rx-bcast-mbps	Parameter type: <Itf::ifStatsRateByMbps> - interface statistics rate by Mbps - unit: Mbps - range: [0.0...15000.0]	An average broadcast traffic rate on the interface port in upstream direction in units of megabits per second during last appointed period. <i>This element is only shown in detail mode.</i>
rx-mbps	Parameter type: <Itf::ifStatsRateByMbps> - interface statistics rate by Mbps - unit: Mbps - range: [0.0...15000.0]	An average traffic rate on the interface port in upstream direction in units of megabits per second during last appointed period. <i>This element is only shown in detail mode.</i>
rx-discard-mbps	Parameter type: <Itf::ifStatsRateByMbps> - interface statistics rate by Mbps - unit: Mbps - range: [0.0...15000.0]	An average discard traffic rate on the interface port in upstream direction in units of megabits per second during last appointed period. <i>This element is only shown in detail mode.</i>

127- *SNTP Status Commands*

127.1 SNTP Status Command Tree
127.2 SNTP Status Command

127-6013
127-6014

127.1 SNTP Status Command Tree

Description

This chapter gives an overview of nodes that are handled by "SNTP Status Commands".

Command Tree

```
----show
  ----sntp
```

127.2 SNTP Status Command

Command Description

This command displays the information about the SNTP and its related parameters.

User Level

The command can be accessed by operators with all privileges.

Command Syntax

The command has the following syntax:

```
> show sntp
```

Command Output

Table 127.2-2 "SNTP Status Command" Display parameters

Specific Information		
name	Type	Description
operating-mode	Parameter type: <Sys::SNTPOperatingMode> (unicast anycast multicast) Possible values: - unicast : operating mode unicast value 1 - anycast : operating mode anycast value 2 - multicast : operating mode multicast value 3	specifies the operating mode for the SNTP application at the SNMP agent. <i>This element is always shown.</i>
system-time	Parameter type: <Sys::GaugeTimeInSecs> - the time (yyyy-mm-dd:hour:minutes:secs)	specifies the network time. <i>This element is always shown.</i>
system-boot-time	Parameter type: <Sys::GaugeTimeInSecs> - the time (yyyy-mm-dd:hour:minutes:secs)	specifies the system boot time in network time. Value is not valid until system-time is updated manually or SNTP packet response is received. <i>This element is always shown.</i>

128- *SNTP Server Commands*

128.1 SNTP Server Command Tree
128.2 SNTP Server Status Command

128-6016
128-6017

128.1 SNTP Server Command Tree

Description

This chapter gives an overview of nodes that are handled by "SNTP Server Commands".

Command Tree

```
----show
  ----sntp
    ----server-table
      - (server-ip-addr)
```

128.2 SNTP Server Status Command

Command Description

This command displays the information about the SNTP Servers and its related parameters.

User Level

The command can be accessed by operators with all privileges.

Command Syntax

The command has the following syntax:

```
> show sntp server-table [ (server-ip-addr) ]
```

Command Parameters

Table 128.2-1 "SNTP Server Status Command" Resource Parameters

Resource Identifier	Type	Description
(server-ip-addr)	Format: - IPv4-address	specifies the ip address of the sntp server

Command Output

Table 128.2-2 "SNTP Server Status Command" Display parameters

Specific Information		
name	Type	Description
port	Parameter type: <Sys::ServerPortNumber> - port number - range: [0...65535]	specifies the port number of the sntp server <i>This element is always shown.</i>
priority	Parameter type: <Sys::priority> - sntp server priority(1 - high) [1...6] for ipv6 management supported boards,[1...3] for others	specifies the priority number of the sntp server <i>This element is always shown.</i>
issyncsource	Parameter type: <Sys::issyncsrc> (yes no) Possible values: - yes : this server is the current source of time synchronization - no : this server is not the current source of time synchronization	display whether this sntp server is the current source of time synchronization <i>This element is always shown.</i>

129- *SNTP Server Commands*

129.1 SNTP Server Command Tree
129.2 SNTP Server Status Command

129-6019
129-6020

129.1 SNTP Server Command Tree

Description

This chapter gives an overview of nodes that are handled by "SNTP Server Commands".

Command Tree

```
----show
  ----sntp
    ----server-tablev6
      - (server-ip-addrv6)
```

129.2 SNTP Server Status Command

Command Description

This command displays the information about the SNTP Servers and its related parameters.

User Level

The command can be accessed by operators with all privileges.

Command Syntax

The command has the following syntax:

```
> show sntp server-tablev6 [ (server-ip-addrv6) ]
```

Command Parameters

Table 129.2-1 "SNTP Server Status Command" Resource Parameters

Resource Identifier	Type	Description
(server-ip-addrv6)	Format: - IPv6-address	specifies the ip address of the sntp server

Command Output

Table 129.2-2 "SNTP Server Status Command" Display parameters

Specific Information		
name	Type	Description
port	Parameter type: <Sys::ServerPortNumber> - port number - range: [0...65535]	specifies the port number of the sntp server <i>This element is always shown.</i>
priority	Parameter type: <Sys::priority> - sntp server priority(1 - high) [1...6] for ipv6 management supported boards,[1...3] for others	specifies the priority number of the sntp server <i>This element is always shown.</i>
issyncsource	Parameter type: <Sys::issyncsrc> (yes no) Possible values: - yes : this server is the current source of time synchronization - no : this server is not the current source of time synchronization	display whether this sntp server is the current source of time synchronization <i>This element is always shown.</i>

130- System Status Commands

130.1 System Status Command Tree	130-6022
130.2 System Statistics Command	130-6023
130.3 System Licenses Status Command	130-6024
130.4 System License Usage Command	130-6029
130.5 System Clock Status Command	130-6031
130.6 Show syslog parameters	130-6033
130.7 System Memory Usage Status Command	130-6034
130.8 System CPU Load Status Command	130-6036
130.9 System Compact Flash Usage Status Command	130-6038
130.10 System CDE Command	130-6040
130.11 System CDE Extended Command	130-6041
130.12 System Clock Management Status Command	130-6042
130.13 PTP master clock device detailed information Command	130-6045
130.14 PTP client detailed information Command	130-6049
130.15 System Clock Management ToD Status Command	130-6051
130.16 System T4 Clock Management Status Command	130-6053
130.17 System Clock IEEE1588 master profile detailed info command	130-6056
130.18 System Clock Management IEEE1588 Status Command	130-6057
130.19 System Clock IEEE1588 current master detailed info Command	130-6059
130.20 System Clock IEEE1588 visible master detailed info Command	130-6063
130.21 Scaling Mode Status Command	130-6067
130.22 System ipv6 prefix resource usage show Command	130-
130.23 System TechSupport Status Command	130-6068
130.24 show system fips	130-6071
130.25 System Autoboot file timestamps Command	130-6072

130.1 System Status Command Tree

Description

This chapter gives an overview of nodes that are handled by "System Status Commands".

Command Tree

```
----show
  ----system
    ----entry
    ----license
      - (feature)
    ----license-usage
      - (feature)
    ----clock-mgmt
    ----syslog
    ----memory-usage
      - (slot)
    ----cpu-load
      - (slot)
    ----cf-usage
      - (slot)
    ----cde-bitmap
    ----cde-bitmap-extended
    ----sync-if-timing
      - (priority)
    ----sync-ptp-mstrport
      - (ptpdev-index)
    ----sync-ptp-client
      - (ptpdev-index)
      - client-index
    ----sync-if-timing-tod
      - (priority)
    ----sync-if-timing-t4
      - (priority)
    ----sync-ptp-mstrprofile
      - (name)
    ----sync-ptp-slaveport
      - (ptp-port)
    ----sync-ptp-currmaster
      - (ptp-port)
    ----sync-ptp-inmasters
      - (vm-idx)
    ----scalingmode
    ----ipv6-prefix-mgmt
    ----techsupport
      - (session)
  ----X fips
  ----autoboot-config
```


130.2 System Statistics Command

Command Description

This command displays the status of the list commands.

User Level

The command can be accessed by operators with all privileges.

Command Syntax

The command has the following syntax:

> show system entry

Command Output

Table 130.2-2 "System Statistics Command" Display parameters

Specific Information		
name	Type	Description
status-bit-map	Parameter type: <Sys::AsamSysStatusBitMap> - status bitmap	Specifies the status bitmap. <i>This element is always shown.</i>
mib-version	Parameter type: <Sys::asamMibVersion> - a printable string - length: x<=21	Specifies the version of the management interface. <i>This element is always shown.</i>
init-progress	Parameter type: <Sys::AsamSystemInitProgress> - progress of system initialisation indicated as percent - unit: percent - range: [0...100]	Specifies the progress of the system initialization indicated as a percentage. <i>This element is always shown.</i>
act-nt-intercon-vlan	Parameter type: <Ihub::CurrentVlanId> - the vlan-id used for current communication between stacked Broadcom switching devices on the NT - range: [1...4093]	the value of the act-nt-intercon-vlan <i>This element is always shown.</i>
cfg-nt-intercon-vlan	Parameter type: <Ihub::StackingVlanId> - the vlan-id used for stacked Broadcom switching devices of NT - range: [1...4093]	the value of the cfg-nt-intercon-vlan <i>This element is always shown.</i>
act-internal-nw-vlan	Parameter type: <Ihub::InternalNwVlanId> - the vlan-id for internal handling of packets on network ports - range: [1...4093]	Specifies the currently used vlan-id for internal handling of packets on network ports <i>This element is always shown.</i>
cfg-internal-nw-vlan	Parameter type: <Ihub::InternalNwVlanId> - the vlan-id for internal handling of packets on network ports - range: [1...4093]	Specifies the configured vlan-id for internal handling of packets on network ports <i>This element is always shown.</i>

130.3 System Licenses Status Command

Command Description

This command displays the routing-license indicating the status of the L3 routing protocols and displays also the number of software licenses for the following features.

For ADSL2+, the counter indicates the number of XDSL lines for which an ADSL2+ operational mode (POTS and/or ISDN) is enabled in its configuration, and supported by the LT board, and for which the XDSL board is equipped.

For READSL2 operational mode (US mode 1 and/or US mode 2), the counter is enabled in its configuration, and supported by the LT board, and for which the XDSL board is equipped.

For IGMP, the counter indicates the number of DSL subscriber lines for which an IGMP control channel has been configured.

For xDSL Annex-M, the counter indicates the number of DSL subscriber line which is configured for Annex-M.

For IP-Forwarding, the counter indicates the number of DSL subscriber lines configured.

For PPPoX Relay, the counter indicates the number of DSL subscriber lines configured.

For 802.1x, the counter indicates the number of DSL subscriber lines for which 802.1x has been configured as 'enabled'.

For IPoA-CC/RB, the counter indicates the number of DSL subscriber lines which are configured for IPoA cross connect mode and enhanced i-bridge mode .In Release 3.6 IPOA-CC is replaced by IPOA-CC/RB

For UPBO Policing, the counter indicates the number of XDSL lines for which a VDSL2 opmode has been selected, for which UPBO Policing pbo mode has been enabled in its configuration and supported by the LT board and for which the XDSL board is equipped. The counter is decremented when one of these conditions is not met anymore.

For XDSL-Perline-Override, the counter indicates the number of XDSL lines for which the per-line override data has been used in its configuration and for which the XDSL board is equipped.

For Impulse Noise Sensor, the counter indicates the number of XDSL lines for which the Impulse Noise Sensor is enabled and for which the XDSL board is equipped.

For ADSL1/2 PSD Shaping, the counter indicates the number of XDSL line configured for which ADSL1 or ADSL2 opMode is enabled with DBPO shaping and supported by the LT board and for which the XDSL board is equipped. The counter is decremented if the DPBO profile is unassigned or if the XDSL line is unconfigured.

For xDSL Annex-J, the counter indicates the number of DSL subscriber line which is configured for Annex-J.

For syncE clock source, the counter indicates the number of Synchronous Ethernet ports are configured as a clock source.

For 2dot5gbps-lt, the counter indicates the number of LTs that operate at 2.5Gbps link speed.

For redcy, the counter indicates the number protection groups are enabled (unlocked).

Shdsl-ctc: this key isn't used, the counter remains zero.

For VDSL2, the counter indicates the number of xdsl lines for which Seamless Rate Adaptation and VDSL2 is enabled.

For ARQ, the counter indicates the number of XDSL lines for which ARQ is enabled in the configuration, supported by the LT board and for which the XDSL board is equipped.

For 10 Gbps enabled LT, the counter indicates the number of LTs that have an uplink that is running at 10 Gbps speed.

For 20 Gbps enabled LT, the counter indicates the number of LTs that have an uplink that is running at 20 Gbps

speed.

For ipv6 security, the counter indicates the number of access lines (DSL, Ethernet or ONT UNI) where one or more IPv6 security features are activated.

For Higig NT, the counter indicates whether lawful intercept is enabled (value 1) or Disabled (value 0).

For vectoring, the counter indicates the number of lines where a vectoring profile has been assigned to.

For Green DSL L2 mode, the counter indicates the number of xDSL lines which are equipped and configured with L2 mode enabled.

For Ethernet OAM Advanced Monitoring Functions, the counter indicates the number of MEPS which can send and/or receive CFM Continuity Check Messages.

For MPLS Advanced Resiliency, the counter indicates whether MPLS-FRR or MPLS LSR is being used (value 1) or not used (value 0).

For 40 Gbps enabled LT, the counter indicates the number of LTs that have an uplink that is running at 40 Gbps speed.

For Type-B protection, the counter indicates the number of protection groups in the system that are configured by the operator. The counter is only valid on NANT-E and FANT-F boards. For other NTs, the value should always be 0, as protection group creation is not allowed. The value is between 0 (no protection group) and 62 (maximum allowed by the system).

For vectoring legacy fext cancellation, the counter indicates the number of lines where a vectoring profile has been assigned to in which the legacy fext cancellation feature is enabled.

For Vlan Translation resources extended usage vxlt-ext-usage, the counter indicates the number of line cards making use of VLAN translation resources in an extended way.

For Ethernet OAM Y1731 Performance monitoring functions, the counter indicates the number of MEPS in the system in which Y1731 performance monitoring functions have been enabled.

For VDSL2-35b-mode, the counter indicates the number of xdsl lines for which VDSL2-35b-mode is enabled.

For G.Fast the counter indicates the number of xdsl lines for which G.fast operational mode is enabled by configuration. The value should always be zero for systems which do not support G.Fast.

For VULA, the counter indicates the number of FELT-B planned as uplink_mode.

For Multiple SG, the counter indicates the number of SIP terminations created in the local access node.

For ethernet-ring, the counter indicates whether Ethernet Ring Protection Switching is enabled or not. For non-supported platforms, the value will be 0 by default.

For LSA and Emergency call, the counter indicates the number of SIP terminations created in local access node

For VDSL2-LR, the counter indicates the number of xdsl lines for which VDSL2-LR is enabled.

For 10G-PON LT upgrade, the counter indicates the number of LTs that have been upgraded from GPON to 10G-PON technology.

User Level

The command can be accessed by operators with all privileges.

Command Syntax

The command has the following syntax:

```
> show system license [ (feature) ]
```

Command Parameters

Table 130.3-1 "System Licenses Status Command" Resource Parameters

Resource Identifier	Type	Description
(feature)	Format: (adsl2-plus readsl2 igmp annex-m ip-forward pppox-relay 802dot1x ipoa-cc ipoa-cc/rb upbo-policing xdsl-line-override xdsl-ins adsl-adsl2-dpbo annex-j synce-if-timing 2dot5gbps-lt redcy shdsl-ctc vdsl2 arq 10gbps-lt 20gbps-lt ipv6-security lawful-intercept vectoring green-dsl-l2-mode eth-oam-adv-mon eth-y1731-pm-mon mpls-adv-resilien 40gbps-lt port-protection vectoring-legacy vxlt-ext-usage vdsl2-35b-mode gfast vula multi-vsg ethernet-ring lsa vdsl2-lr 100gbps-lt 25gbps-lt 50gbps-lt 10g-pon-lt-upgrade) Possible values: - adsl2-plus : number of xdsl lines for which ADSL2 is enabled - readsl2 : number of xdsl lines for which READSL2 is enabled - igmp : number of DSL subscribers configured for IGMP - annex-m : number of DSL subscribers configured for	table index

Resource Identifier	Type	Description
	annex-m - ip-forward : number of DSL subscribers configured for Ip-forwarding - pppox-relay : number of DSL subscribers configured for PPPoX relay - 802dot1x : number of DSL subscribers configured for 802.1x - ipoa-cc : number of DSL subscribers configured for IPoA-CC obsolete alternative replaced by ipoa-cc/rb - ipoa-cc/rb : number of DSL subscribers configured for IPoA-CC/RB - upbo-policing : number of lines configured with UPBO policing - xdsl-line-override : number of xdsl lines for which override data is used - xdsl-ins : number of lines for which impulse noise sensor is enabled - adsl-adsl2-dpbo : number of ADSL/ADSL2 lines for which DPBO is enabled - annex-j : number of DSL subscribers configured for annex-j - synce-if-timing : number of Synchronous Ethernet ports are configured as a clock source - 2dot5gbps-lt : number of LTs that operate at 2.5Gbps link speed - redcy : number of protection groups enabled (unlocked) - shdsl-ctc : number of equipped SHDSL lines configured for which cross-talk cancellation (CTC) is enabled - vdsl2 : number of xdsl lines for which Seamless Rate Adaptation and VDSL2 is enabled - arq : number of xdsl lines for which ARQ is enabled - 10gbps-lt : number of LTs that operate at 10Gbps link - 20gbps-lt : number of LTs that operate at 20Gbps link - ipv6-security : the number of access lines (DSL, Ethernet or ONT UNI) where one or more IPv6 security features are activated - lawful-intercept : indicates whether lawful intercept is enabled or disabled - vectoring : number of xdsl lines where a vectoring profile has been associated to - green-dsl-l2-mode : number of xdsl lines where green-dsl-l2-mode is on - eth-oam-adv-mon : number of MEPS where Ethernet OAM Advanced Monitoring Functions are enabled - eth-y1731-pm-mon : number of MEPS where Ethernet y1731 performance monitoring functions are enabled - mpls-adv-resilien : indicates whether MPLS-FRR or MPLS LSR is being used (value 1) or not used (value 0) - 40gbps-lt : number of LTs that operate at 40Gbps link - port-protection : number of port-protection groups - vectoring-legacy : number of xdsl lines where vectoring legacy FEXT cancellation is enabled - vxlt-ext-usage : indicates the number of line cards that are extendedly using Vlan Translation Hardware Resources. - vdsl2-35b-mode : number of xdsl lines for which VDSL2-35b-mode is enabled	

Resource Identifier	Type	Description
	- gfast : number of xdsl lines for which G.fast operational mode is enabled by configuration. - vula : number of ethernet lines cards for which VULA mode is enabled by configuration. - multi-vsg : the number of SIP terminations created in the local access node - ethernet-ring : indicates whether ethernet ring is enabled or not - lsa : the number of SIP terminations created in the local access node which can register to the LSA server. - vdsl2-lr : number of xdsl lines for which VDSL2-lr is enabled - 100gbps-lt : number of LTs that operate at 100Gbps link - 25gbps-lt : number of LTs that operate at 25Gbps link - 50gbps-lt : number of LTs that operate at 50Gbps link - 10g-pon-lt-upgrade : number of LTs that have been upgraded from GPON to 10G-PON technology	

Command Output

Table 130.3-2 "System Licenses Status Command" Display parameters

Specific Information		
name	Type	Description
number-license	Parameter type: <SignedInteger> - a signed integer	Specifies number of license. <i>This element is always shown.</i>

130.4 System License Usage Command

Command Description

This command shows the authorized and utilized license count of restricted license feature, and the entities that are license enabled

User Level

The command can be accessed by operators with all privileges.

Command Syntax

The command has the following syntax:

> show system license-usage [(feature)]

Command Parameters

Table 130.4-1 "System License Usage Command" Resource Parameters

Resource Identifier	Type	Description
(feature)	Format: 10g-pon-lt-upgrade Possible values: - 10g-pon-lt-upgrade : number of LTs that have been upgraded from GPON to 10G-PON technology	Name of configurable license feature

Command Output

Table 130.4-2 "System License Usage Command" Display parameters

Common Information:license-config		
name	Type	Description
authorized	Parameter type: <Sys::licenseConfig> - license configuration data type	<i>This element is always shown.</i>
utilized	Parameter type: <Sys::licenseConfig> - license configuration data type	<i>This element is always shown.</i>
Specific Information		
name	Type	Description
entity	Parameter type: <Equipm::NtLtSlotIndex1> (lt : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> nt-a nt-b nt <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::EqSlotId>) Possible values: - lt : lt-slot - nt-a : nt-a slot	License enabled entity <i>This element is always shown.</i>

130 System Status Commands

name	Type	Description
	- nt-b : nt-b slot - nt : nt slot Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::EqSlotId> - the equipment slot number	

130.5 System Clock Status Command

Command Description

This command displays three display elements named actual-priority, clock-status, and clock-selection.

User Level

The command can be accessed by operators with all privileges.

Command Syntax

The command has the following syntax:

```
> show system clock-mgmt
```

Command Output

Table 130.5-2 "System Clock Status Command" Display parameters

Specific Information		
name	Type	Description
actual-priority	Parameter type: <Sys::SysClkSrcPriorityScheme> (autoselect local external-local) Possible values: - autoselect : select based on location - local : always select local clock - external-local : external clock > local clock	Shows the actual priority of clock sources. <i>This element is always shown.</i>
selection	Parameter type: <Sys::asamSysClkSrcSelection> (active-external active-local) Possible values: - active-external : external clock on active NT - active-local : local clock on active NT	Shows the clock source selected by system <i>This element is always shown.</i>
ext-source	Parameter type: <Sys::SysClkExtSource> (e1 ds1 khz2048 autoselect) Possible values: - e1 : select E1 Source - ds1 : select DS1 Source - khz2048 : select 2048KHz Source - autoselect : autoselect Source	Shows the clock source selected by system E1/DS1/2048KHz <i>This element is always shown.</i>
external-nt-a	Parameter type: <Sys::clkSrcExtAFailure> (failure available) Possible values:	Shows the status of the External clock on NT A <i>This element is always shown.</i>

130 System Status Commands

name	Type	Description
	- failure : failure of external clock on NT A - available : availability of external of clock on NT A	
external-nt-b	Parameter type: <Sys::clkSrcExtBFailure> (failure available) Possible values: - failure : failure of external clock on NT B - available : availability of external of clock on NT B	Shows the status of the External clock on NT B <i>This element is always shown.</i>
local-nt-a	Parameter type: <Sys::clkSrcLocAFailure> (failure available) Possible values: - failure : failure of local of clock on NT A - available : availability of local of clock on NT A	Shows the status of the Local clock on NT A <i>This element is always shown.</i>
local-nt-b	Parameter type: <Sys::clkSrcLocBFailure> (failure available) Possible values: - failure : faiulre of local of clock on NT B - available : availablity of local of clock on NT B	Shows the status of the Local clock on NT B <i>This element is always shown.</i>

130.6 Show syslog parameters

Command Description

This command displays the system related parameters for syslog.

User Level

The command can be accessed by operators with security privileges.

Command Syntax

The command has the following syntax:

```
> show system syslog
```

Command Output

Table 130.6-2 "Show syslog parameters" Display parameters

Specific Information		
name	Type	Description
max-msg-size	Parameter type: <Sys::MaxMsgSize> - the maximum size of the syslog message - unit: bytes - range: [0...1024]	maximum size of the syslog message <i>This element is always shown.</i>
available-on-disk	Parameter type: <Sys::MaxStorageSize> - total storage size available to store the messages - unit: bytes - range: [0...2147483647]	total storage size available to store the messages <i>This element is always shown.</i>
used-on-disk	Parameter type: <Sys::UsedSize> - indicates inuse storage size by the messages - unit: bytes - range: [0...2147483647]	indicates inuse storage size by the messages <i>This element is always shown.</i>
reserved-on-disk	Parameter type: <Sys::ReservedSize> - indicates inuse storage size by the messages - unit: bytes - range: [0...2147483647]	indicate the reserved storage size for the messages <i>This element is always shown.</i>
free-on-disk	Parameter type: <Sys::FreeSize> - free memory available for storing syslog messages from total allocated memory - unit: bytes - range: [0...2147483647]	total free memory available to store syslog messages <i>This element is always shown.</i>

130.7 System Memory Usage Status Command

Command Description

This command displays the various memory usage parameters.

User Level

The command can be accessed by operators with all privileges.

Command Syntax

The command has the following syntax:

```
> show system memory-usage [ (slot) ]
```

Command Parameters

Table 130.7-1 "System Memory Usage Status Command" Resource Parameters

Resource Identifier	Type	Description
(slot)	Format: (lt : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> nt-a nt-b nt <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::EqSlotId> ntio-1) Possible values: - lt : lt-slot - nt-a : nt-a slot - nt-b : nt-b slot - nt : nt slot - ntio-1 : an nt applique slot in a single or multiple-ntio-shelf Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::EqSlotId> - the equipment slot number	slot index

Command Output

Table 130.7-2 "System Memory Usage Status Command" Display parameters

Specific Information		
name	Type	Description
total(mb)	Parameter type: <Sys::totalMem>	the size of the total memory on

name	Type	Description
	- memory size - unit: Mbyte	this board <i>This element is always shown.</i>
used(mb)	Parameter type: <Sys::memusageAbsolute> - memory size - unit: Mbyte	the size of the memory actually in use <i>This element is always shown.</i>
used-portion(%)	Parameter type: <Sys::memusagePrecent> - the size of the memory actually in use, expressed as a portion of the total memory - unit: percentage - range: [0...100]	the size of the memory actually in use, expressed as a portion of the total memory <i>This element is always shown.</i>

130.8 System CPU Load Status Command

Command Description

This command shows the various CPU load parameters, including the start time of monitoring, the average load for the measurement period and the current condition of the CPU load monitoring activity. CPU Load monitoring can be started and stopped using the command "admin system cpu-load".

User Level

The command can be accessed by operators with all privileges.

Command Syntax

The command has the following syntax:

```
> show system cpu-load [ (slot) ]
```

Command Parameters

Table 130.8-1 "System CPU Load Status Command" Resource Parameters

Resource Identifier	Type	Description
(slot)	Format: (lt : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> nt-a nt-b nt <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::EqSlotId> ntio-1) Possible values: - lt : lt-slot - nt-a : nt-a slot - nt-b : nt-b slot - nt : nt slot - ntio-1 : an nt applique slot in a single or multiple-ntio-shelf Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::EqSlotId> - the equipment slot number	slot index

Command Output

Table 130.8-2 "System CPU Load Status Command" Display parameters

Specific Information

name	Type	Description
monitor-start-time	Parameter type: <Sys::startMonitorTime> - the time (yyyy-mm-dd:hour:minutes:secs) - unit: UTC	the start time of last 3 minutes or less monitoring <i>This element is always shown.</i>
average(%)	Parameter type: <Sys::cpuloadaverage> - average load for the measurement period , expressed in percentage - unit: percentage - range: [0...100]	average load for the measurement period , expressed in percentage <i>This element is always shown.</i>
oper-status	Parameter type: <Sys::operateStatus> (proceeding idle not-operational) Possible values: - proceeding : cpu load monitoring is ongoing - idle : monitoring is either not started or already completed - not-operational : monitoring cannot be performed as the board is not operational	current condition of the cpu load monitoring activity <i>This element is always shown.</i>

130.9 System Compact Flash Usage Status Command

Command Description

This command shows the compact flash life usage parameters, including smart interface supported, inconsistent behaviour on smart interface, current utilization in raw value and in percentage."

User Level

The command can be accessed by operators with all privileges.

Command Syntax

The command has the following syntax:

```
> show system cf-usage [ (slot) ]
```

Command Parameters

Table 130.9-1 "System Compact Flash Usage Status Command" Resource Parameters

Resource Identifier	Type	Description
(slot)	Format: (nt-a nt-b) Possible values: - nt-a : nt-a slot - nt-b : nt-b slot	slot index

Command Output

Table 130.9-2 "System Compact Flash Usage Status Command" Display parameters

Specific Information		
name	Type	Description
smart	Parameter type: <Sys::smartInterfaceSupported> (yes no) Possible values: - yes : The installed compact flash supports SMART interface - no : The installed compact flash doesn't support SMART interface	The parameter indicates if an installed compact flash supports SMART interface. <i>This element is always shown.</i>
inconsistency	Parameter type: <Sys::smartInterfaceInconsistent> (yes no)	The parameter indicates if an installed compact flash shows inconsistent behaviour on

name	Type	Description
	Possible values: - yes : The installed compact flash shows inconsistent behaviour on SMART interface - no : The installed compact flash doesn't show inconsistent behaviour on SMART interface.	SMART interface. <i>This element is always shown.</i>
erase-counts-raw-value	Parameter type: <Sys::eraseCount> - Current utilization in terms of life expectancy in raw value. - length: x<=21	Current utilization in terms of life expectancy in raw value <i>This element is always shown.</i>
life-used-percentage	Parameter type: <Sys::lifeUsedPercentage> - Current utilization in terms of life expectancy in percentage and the percentage is rounded to the nearest integer. - unit: percentage - range: [0...100]	Current utilization in terms of life expectancy in percentage <i>This element is always shown.</i>

130.10 System CDE Command

Command Description

This command displays the activated Customer Dependent Engineering feature bitmap.

User Level

The command can be accessed by operators with all privileges.

Command Syntax

The command has the following syntax:

```
> show system cde-bitmap
```

Command Output

Table 130.10-2 "System CDE Command" Display parameters

Specific Information		
name	Type	Description
cde-bitmap	Parameter type: <Sys::cdeBitMap> <Sys::printableCdeBitMap> Field type <Sys::printableCdeBitMap> - printable cde bitmap	show activated cde feature bitmap <i>This element is always shown.</i>

130.11 System CDE Extended Command

Command Description

This command displays the activated Customer Dependent Engineering feature extended bitmap.

User Level

The command can be accessed by operators with all privileges.

Command Syntax

The command has the following syntax:

> show system cde-bitmap-extended

Command Output

Table 130.11-2 "System CDE Extended Command" Display parameters

Specific Information		
name	Type	Description
cde-bitmap-extended	Parameter type: <Hex-32-32> - a binary string - length: 32	show activated cde feature bitmap (up to 256 bits, big endian) <i>This element is always shown.</i>

130.12 System Clock Management Status Command

Command Description

This command shows the status of the clock sources configured for selection.

User Level

The command can be accessed by operators with all privileges.

Command Syntax

The command has the following syntax:

> show system sync-if-timing [(priority)]

Command Parameters

Table 130.12-1 "System Clock Management Status Command" Resource Parameters

Resource Identifier	Type	Description
(priority)	Format: - priority index of the system clock source - range: [1...3]	priority configured for the clock source

Command Output

Table 130.12-2 "System Clock Management Status Command" Display parameters

Common Information:bits-mode		
name	Type	Description
bits-mode	Parameter type: <Sys::ActualSysClkExtSource> (e1 ds1 khz2048) Possible values: - e1 : select E1 Source - ds1 : select DS1 Source - khz2048 : select 2048KHz Source	external clock type E1 or DS1 or 2048Khz <i>This element is always shown.</i>

Specific Information		
name	Type	Description
clock-source	Parameter type: <Sys::SysClkSrc> (bits-a bits-b synce-1 synce-2	The clock source configured for selection <i>This element is always shown.</i>

name	Type	Description
	local ieee1588 ieee1588-a ieee1588-b none) Possible values: - bits-a : select BITS-A for this priority - bits-b : select BITS-B for this priority - synce-1 : select SyncE reference 1 for this priority - synce-2 : select SyncE reference 2 for this priority - local : holdover specified (always enable last priority) - ieee1588 : select IEEE 1588 clock for this priority - ieee1588-a : select IEEE 1588-A clock for this priority - ieee1588-b : select IEEE 1588-B clock for this priority - none : remove clock source for this priority	
ql	Parameter type: <Ntr::SysClkSrcQL> (clk-ql-stu clk-ql-prs clk-ql-prc clk-ql-inv3 clk-ql-ssu-a-tnc clk-ql-ssu-a clk-ql-tnc clk-ql-inv5 clk-ql-inv6 clk-ql-st2 clk-ql-ssu-b clk-ql-inv9 clk-ql-st3 clk-ql-sec clk-ql-smc clk-ql-st3e clk-ql-prov clk-ql-dnu-dus clk-ql-dnu clk-ql-dus) Possible values: - clk-ql-stu : Synchronized-Traceability Unknown - clk-ql-prs : Primary Reference Source - clk-ql-prc : Primary Reference Clock - clk-ql-inv3 : Quality Level unallocated - clk-ql-ssu-a-tnc : Traced to Sync Supply Unit-A/Transmit Node Clock - clk-ql-ssu-a : Traced to Sync Supply Unit-A(ETSI) - clk-ql-tnc : Traced to Transmit Node Clock(ANSI) - clk-ql-inv5 : Quality Level unallocated - clk-ql-inv6 : Quality Level unallocated - clk-ql-st2 : Traceable to Stratum 2 - clk-ql-ssu-b : Traced to Sync Supply Unit-B - clk-ql-inv9 : Quality Level unallocated - clk-ql-st3 : Traceable to Stratum 3 - clk-ql-sec : Traceable to SDH Equipment Clock - clk-ql-smc : Traceable to SONET Clock SelfTimed - clk-ql-st3e : Traceable to Stratum 3E - clk-ql-prov : Operator Provisioned - clk-ql-dnu-dus : Signal should not be used for sync - clk-ql-dnu : Signal should not be used for sync(ETSI)	Quality level of the clock <i>This element is always shown.</i>

130 System Status Commands

name	Type	Description
	- clk-ql-dus : Signal should not be used for sync(ANSI)	
status	Parameter type: <Sys::SysClkStatusActual> (reference valid fail donotuse unknown forced nosynceconfig nosyncesupport onnonreadypeernt syncenotavailable noieee1588config missing invalid) Possible values: - reference : clock is selected as the reference clock - valid : clock is available for selection - fail : clock is not available for selection - donotuse : clock must not be used as indicated by SSM - unknown : clock status unknown - forced : clock is manually selected - nosynceconfig : syncE clock (ref1/2) is not bound to a port - nosyncesupport : SyncE clock (ref1/2) is bound to a port that does not support syncE clock extraction - onnonreadypeernt : clock configured on the face plate of the peer NT is not eligible due to the state of the peer NT - syncenotavailable : SyncE clock not available - noieee1588config : ieee1588 is not configured - missing : no SSM-QL received - invalid : clock not available for selection	Operational status of the configured clock <i>This element is always shown.</i>

130.13 PTP master clock device detailed information Command

Command Description

This command shows the detailed information of PTP master clock device.

User Level

The command can be accessed by operators with all privileges.

Command Syntax

The command has the following syntax:

```
> show system sync-ptp-mstrport [ (ptpdev-index) ]
```

Command Parameters

Table 130.13-1 "PTP master clock device detailed information Command" Resource Parameters

Resource Identifier	Type	Description
(ptpdev-index)	Format: (lt : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> ont : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> ont:ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId>) Possible values: - lt : lt slot - ont : ont index - ont:ng2 : ngpon2 index Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Eqpt::OntId> - the ONT identifier Field type <Eqpt::ChannelGroupId> - the channel group identifier Field type <Eqpt::SubChannelGroupId> - the subchannel group identifier Field type <Eqpt::Ng2OntId> - the NG2 ONT identifier	ptp master port index

Command Output

Table 130.13-2 "PTP master clock device detailed information Command" Display parameters

Specific Information		
name	Type	Description
log-var	Parameter type: <Sys::portNumber> - index number - range: [0...65535]	OffsetScaledLogVariance <i>This element is always shown.</i>
clkid	Parameter type: <Sys::SysClkPtpDefaultDSIdentity> - Hexadecimal Clock Identity (example : 01:02:03:04:05:06:07:08) - length: 8	the clock identity of ptp master clock device <i>This element is always shown.</i>
prio1	Parameter type: <Ntr::Priority> - priority of the acceptable master - range: [0...255]	the priority1 of ptp master clock device <i>This element is always shown.</i>
prio2	Parameter type: <Ntr::Priority> - priority of the acceptable master - range: [0...255]	the priority2 of ptp master clock device <i>This element is always shown.</i>
clkclass	Parameter type: <Sys::SysClkPtpClockQuality> - clock quality of the PTP source - range: [0...255]	the clock class of ptp master clock device <i>This element is always shown.</i>
clkaccuracy	Parameter type: <Sys::SysClkPtpClockAccuracy> - ptp clock accuracy - range: [0...255]	the clock accuracy of current ptp master clock <i>This element is always shown.</i>
stepremoved	Parameter type: <Sys::stepRemoved> - index number - range: [0...65535]	the steps removed of ptp master clock device <i>This element is only shown in detail mode.</i>
grandmasterclkid	Parameter type: <Sys::SysClkPtpDefaultDSIdentity> - Hexadecimal Clock Identity (example : 01:02:03:04:05:06:07:08) - length: 8	the ptp grand master identity of ptp master clock device <i>This element is always shown.</i>
domain	Parameter type: <Ntr::PtpDomain> - ptp domain - range: [0...255]	the domain of ptp master clock device <i>This element is always shown.</i>
portnumber	Parameter type: <Sys::portNumber> - index number - range: [0...65535]	the port number of ptp master clock device <i>This element is always shown.</i>
time-source	Parameter type: <Sys::PtpTimeSource> (atomic gps radio ptp ntp handset other internal unknown) Possible values: - atomic : ATOMIC_CLOCK - gps : GPS - radio : TERRESTRIAL_RADIO - ptp : PTP - ntp : NTP - handset : HAND_SET - other : OTHER	ptp time source <i>This element is only shown in detail mode.</i>

name	Type	Description
	- internal : INTERNAL_OSCILLATOR - unknown : No information	
leap61	Parameter type: <Sys::FlagValue> (false true unknown) Possible values: - false : the flag is false - true : the flag is true - unknown : the flag is not available	leap61 <i>This element is only shown in detail mode.</i>
leap59	Parameter type: <Sys::FlagValue> (false true unknown) Possible values: - false : the flag is false - true : the flag is true - unknown : the flag is not available	leap59 <i>This element is only shown in detail mode.</i>
utc-offset-valid	Parameter type: <Sys::FlagValue> (false true unknown) Possible values: - false : the flag is false - true : the flag is true - unknown : the flag is not available	the current utc offset valid <i>This element is only shown in detail mode.</i>
ptp-timescale	Parameter type: <Sys::FlagValue> (false true unknown) Possible values: - false : the flag is false - true : the flag is true - unknown : the flag is not available	ptp time scale <i>This element is only shown in detail mode.</i>
time-traceable	Parameter type: <Sys::FlagValue> (false true unknown) Possible values: - false : the flag is false - true : the flag is true - unknown : the flag is not available	time traceable <i>This element is only shown in detail mode.</i>
frequency-traceable	Parameter type: <Sys::FlagValue> (false true unknown) Possible values: - false : the flag is false - true : the flag is true - unknown : the flag is not available	frequency traceable <i>This element is only shown in detail mode.</i>
announce-interval	Parameter type: <Sys::SysSignedCharInt> - signed char - range: [-128...127]	LogAnnounceInterval <i>This element is only shown in detail mode.</i>
sync-interval	Parameter type: <Sys::SysSignedCharInt> - signed char - range: [-128...127]	LogSyncInterval <i>This element is only shown in detail mode.</i>
delay-interval	Parameter type: <Sys::SysSignedCharInt>	LogMinDelayReqInterval

130 System Status Commands

name	Type	Description
	- signed char - range: [-128...127]	<i>This element is only shown in detail mode.</i>
mac-addr	Parameter type: <Sys::PTPMacAddr> (xx:xx:xx:xx:xx:xx xx:xx:xx:xx:xx:xx <Sys::MacAddr>) Possible values: - xx:xx:xx:xx:xx:xx : Invalid MAC address - xx:xx:xx:xx:xx:xx : Invalid MAC address Field type <Sys::MacAddr> - a mac-address (example : 01:02:03:04:05:06) - length: 6	mac address <i>This element is only shown in detail mode.</i>
announce-packets	Parameter type: <Sys::SysPacketCountInt> - Packets counter - range: [0...4294967295]	announce packets <i>This element is only shown in detail mode.</i>
sync-packets	Parameter type: <Sys::SysPacketCountInt> - Packets counter - range: [0...4294967295]	sync packets <i>This element is only shown in detail mode.</i>
delay-req-packets	Parameter type: <Sys::SysPacketCountInt> - Packets counter - range: [0...4294967295]	delay req packets <i>This element is only shown in detail mode.</i>
delay-resp-packets	Parameter type: <Sys::SysPacketCountInt> - Packets counter - range: [0...4294967295]	delay req packets <i>This element is only shown in detail mode.</i>
portstate	Parameter type: <Ntr::PtpMode> (port-fault port-disabled port-listen port-pre-master port-master port-passive port-uncalibrated port-slave) Possible values: - port-fault : unicast ptp packet processing mode - port-disabled : unicast multicast packet processing mode - port-listen : unicast multicast packet processing mode - port-pre-master : unicast multicast packet processing mode - port-master : unicast multicast packet processing mode - port-passive : unicast multicast packet processing mode - port-uncalibrated : unicast multicast packet processing mode - port-slave : unicast multicast packet processing mode	the ster port state of ptp master clock device <i>This element is only shown in detail mode.</i>
utc-offset	Parameter type: <Sys::SysSignedShortInt> - signed short - range: [-32768...32767]	CurrentUtcOffset <i>This element is only shown in detail mode.</i>
tai-time	Parameter type: <Sys::TAITime> - time-of-day in TAI format	tai second <i>This element is only shown in detail mode.</i>
utc-time	Parameter type: <Sys::UTCTime> - time-of-day in UTC format	tai nanosecond <i>This element is only shown in detail mode.</i>

130.14 PTP client detailed information Command

Command Description

This command shows the detailed information of PTP cliet.

User Level

The command can be accessed by operators with all privileges.

Command Syntax

The command has the following syntax:

```
> show system sync-ptp-client [ (ptpdev-index) [ client-index <Sys::PtpClientNo> ] ]
```

Command Parameters

Table 130.14-1 "PTP client detailed information Command" Resource Parameters

Resource Identifier	Type	Description
(ptpdev-index)	Format: (lt : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> uni : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> / <Eqpt::OntPortId> uni.ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / <Eqpt::Ng2OntSlotId> / <Eqpt::Ng2OntPortId> uni.ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / vuni) Possible values: - lt : lt slot - uni : uni - uni.ng2 : ngpon2 UNI style identification Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Eqpt::OntId> - the ONT identifier Field type <Eqpt::ChannelGroupId> - the channel group identifier Field type <Eqpt::SubChannelGroupId> - the subchannel group identifier Field type <Eqpt::Ng2OntId>	ptp master index

Resource Identifier	Type	Description
	- the NG2 ONT identifier Possible values: - vuni : virtual NGPON2 uni identifier Field type <Eqpt::OntSlotId> - the ONT SLOT identifier Field type <Eqpt::OntPortId> - the ONT PORT identifier Field type <Eqpt::Ng2OntSlotId> - the NGPON2 ONT SLOT identifier Field type <Eqpt::Ng2OntPortId> - the NGPON2 ONT PORT identifier	
client-index	Parameter type: <Sys::PtpClientNo> Format: - client number of ptp device - range: [0...1023]	ptp master index

Command Output

Table 130.14-2 "PTP client detailed information Command" Display parameters

Specific Information		
name	Type	Description
clkid	Parameter type: <Sys::SysClkPtpDefaultDSIdentity> - Hexadecimal Clock Identity (example : 01:02:03:04:05:06:07:08) - length: 8	the clock identity of ptp client <i>This element is always shown.</i>
portnumber	Parameter type: <Sys::portNumber> - index number - range: [0...65535]	the port number of ptp client <i>This element is always shown.</i>
domain	Parameter type: <Ntr::PtpDomain> - ptp domain - range: [0...255]	the domain of ptp client <i>This element is always shown.</i>
mac-addr	Parameter type: <Sys::PTPMacAddr> (xx:xx:xx:xx:xx:xx xx:xx:xx:xx:xx:xx <Sys::MacAddr>) Possible values: - xx:xx:xx:xx:xx:xx : Invalid MAC address - xx:xx:xx:xx:xx:xx : Invalid MAC address Field type <Sys::MacAddr> - a mac-address (example : 01:02:03:04:05:06) - length: 6	mac address <i>This element is always shown.</i>
announce-interval	Parameter type: <Sys::SysSignedCharInt> - signed char - range: [-128...127]	LogAnnounceInterval <i>This element is always shown.</i>
sync-interval	Parameter type: <Sys::SysSignedCharInt> - signed char - range: [-128...127]	LogSyncInterval <i>This element is always shown.</i>
delay-interval	Parameter type: <Sys::SysSignedCharInt> - signed char - range: [-128...127]	LogMinDelayReqInterval <i>This element is always shown.</i>

130.15 System Clock Management ToD Status Command

Command Description

This command shows the status of the ToD clock sources configured for selection.

User Level

The command can be accessed by operators with all privileges.

Command Syntax

The command has the following syntax:

> show system sync-if-timing-tod [(priority)]

Command Parameters

Table 130.15-1 "System Clock Management ToD Status Command" Resource Parameters

Resource Identifier	Type	Description
(priority)	Format: - priority index of the system clock source - range: [1...3]	priority configured for the ToD clock source

Command Output

Table 130.15-2 "System Clock Management ToD Status Command" Display parameters

Common Information:time		
name	Type	Description
tai-time	Parameter type: <Sys::TAITime> - time-of-day in TAI format	Specifies TAI time(International Atomic Time) <i>This element is always shown.</i>
utc-time	Parameter type: <Sys::UTCTime> - time-of-day in UTC format	Specifies UTC time(Coordinated Universal Time) <i>This element is always shown.</i>
Specific Information		
name	Type	Description
tod-source	Parameter type: <Sys::SysClkToDSrc> (ieee1588-a ieee1588 ieee1588-b gnss-a gnss-b none	The ToD clock source configured for selection <i>This element is always shown.</i>

130 System Status Commands

name	Type	Description
	- local) Possible values: - ieee1588-a : select IEEE 1588-A clock for this ToD priority - ieee1588 : select IEEE 1588 clock for this ToD priority - ieee1588-b : select IEEE 1588-B clock for this ToD priority - gnss-a : select GNSS-A clock for this ToD priority - gnss-b : select GNSS-B clock for this ToD priority - none : remove clock source for this ToD priority - local : holdover specified (always enable last priority)	
clockclass	Parameter type: <Sys::SysClkPtpClockQuality> - clock quality of the PTP source - range: [0...255]	the clock class of the ToD clock source <i>This element is always shown.</i>
tod-status	Parameter type: <Sys::SysClkToDStatusActual> (reference valid fail donotuse unknown) Possible values: - reference : tod clock is selected as the reference clock - valid : tod clock is available for selection - fail : tod clock is not available for selection - donotuse : tod clock must not be used as indicated by SSM - unknown : tod clock status unknown	Operational status of the ToD configured clock <i>This element is always shown.</i>

130.16 System T4 Clock Management Status Command

Command Description

This command shows the operational status of the configured clocks for the T4 PLL

User Level

The command can be accessed by operators with all privileges.

Command Syntax

The command has the following syntax:

```
> show system sync-if-timing-t4 [ (priority) ]
```

Command Parameters

Table 130.16-1 "System T4 Clock Management Status Command" Resource Parameters

Resource Identifier	Type	Description
(priority)	Format: - priority index of the system clock source - range: [1...3]	priority configured for the clock source

Command Output

Table 130.16-2 "System T4 Clock Management Status Command" Display parameters

Specific Information		
name	Type	Description
clock-source	Parameter type: <Ntr::T4PrioRef> (none local synce-1 synce-2 assysclk) Possible values: - none : no clock is specified for this priority - local : This option cannot be configured - synce-1 : 1st SyncE clock is specified for this priority - synce-2 : 2nd SyncE clock is specified for this priority - assysclk : This option cannot be configured	The clock source configured for selection <i>This element is always shown.</i>
ql	Parameter type: <Ntr::SysClkSrcQL> (clk-ql-stu clk-ql-prs	Quality level of the configured clock source <i>This element is always shown.</i>

name	Type	Description
	clk-ql-prc clk-ql-inv3 clk-ql-ssu-a-tnc clk-ql-ssu-a clk-ql-tnc clk-ql-inv5 clk-ql-inv6 clk-ql-st2 clk-ql-ssu-b clk-ql-inv9 clk-ql-st3 clk-ql-sec clk-ql-smc clk-ql-st3e clk-ql-prov clk-ql-dnu-dus clk-ql-dnu clk-ql-dus) Possible values: - clk-ql-stu : Synchronized-Traceability Unknown - clk-ql-prs : Primary Reference Source - clk-ql-prc : Primary Reference Clock - clk-ql-inv3 : Quality Level unallocated - clk-ql-ssu-a-tnc : Traced to Sync Supply Unit-A/Transmit Node Clock - clk-ql-ssu-a : Traced to Sync Supply Unit-A(ETSI) - clk-ql-tnc : Traced to Transmit Node Clock(ANSI) - clk-ql-inv5 : Quality Level unallocated - clk-ql-inv6 : Quality Level unallocated - clk-ql-st2 : Traceable to Stratum 2 - clk-ql-ssu-b : Traced to Sync Supply Unit-B - clk-ql-inv9 : Quality Level unallocated - clk-ql-st3 : Traceable to Stratum 3 - clk-ql-sec : Traceable to SDH Equipment Clock - clk-ql-smc : Traceable to SONET Clock SelfTimed - clk-ql-st3e : Traceable to Stratum 3E - clk-ql-prov : Operator Provisioned - clk-ql-dnu-dus : Signal should not be used for sync - clk-ql-dnu : Signal should not be used for sync(ETSI) - clk-ql-dus : Signal should not be used for sync(ANSI)	
status	Parameter type: <Ntr::SysClkStatusActual> (reference valid fail donotuse unknown forced nosynceconfig nosyncesupport onnonreadypeernt syncenotavailable noieee1588config missing invalid) Possible values: - reference : clock is selected as the reference clock - valid : clock is available for selection	Operational status of the t4 configured clock sources <i>This element is always shown.</i>

name	Type	Description
	- fail : clock is not available for selection - donotuse : clock must not be used as indicated by SSM - unknown : clock status unknown - forced : clock is manually selected - nosynceconfig : syncE clock (ref1/2) is not bound to a port - nosyncesupport : SyncE clock (ref1/2) is bound to a port that does not support syncE clock extraction - onnonreadypeernt : clock configured on the face plate of the peer NT is not eligible due to the state of the peer NT - syncenotavailable : SyncE clock not available - noieee1588config : ieee1588 is not configured - missing : no SSM-QL received - invalid : clock not available for selection	

130.17 System Clock IEEE1588 master profile detailed info command

Command Description

This command is used to configure the Packet Processing Mode for the PTP-communication between the slave clock device on the ISAM and the GrandMaster device.

User Level

The command can be accessed by operators with all privileges.

Command Syntax

The command has the following syntax:

```
> show system sync-ptp-mstrprofile [ (name) ]
```

Command Parameters

Table 130.17-1 "System Clock IEEE1588 master profile detailed info command" Resource Parameters

Resource Identifier	Type	Description
(name)	Format: - a profile name - range: [a-zA-Z0-9-_.] - length: 1<=x<=32	name for the profile of the PTP Master Port DataSet

Command Output

Table 130.17-2 "System Clock IEEE1588 master profile detailed info command" Display parameters

Specific Information		
name	Type	Description
ref-count	Parameter type: <AsamProfileRefCount> - number of entities using this particular profile - range: [0...65535]	Indicates the number of entities using this profile. If the reference count is greater than 0, then this profile is 'in use', and may NOT be deleted. If the value is 0, then this profile is 'not in use', and can be deleted. <i>This element is always shown.</i>

130.18 System Clock Management IEE1588 Status Command

Command Description

This command shows the status of the ieee1588 clock devices configured for selection.

User Level

The command can be accessed by operators with all privileges.

Command Syntax

The command has the following syntax:

```
> show system sync-ptp-slaveport [ (ptp-port) ]
```

Command Parameters

Table 130.18-1 "System Clock Management IEE1588 Status Command" Resource Parameters

Resource Identifier	Type	Description
(ptp-port)	Format: (ieee1588-a ieee1588-b ieee1588-a:1 ieee1588-b:1 ieee1588) Possible values: - ieee1588-a : ieee1588 port on nt-a excluding FANT-G NT type - ieee1588-b : ieee1588 port on nt-b excluding FANT-G NT type - ieee1588-a:1 : ieee1588 port 1 on nt-a of FANT-G - ieee1588-b:1 : ieee1588 port 1 on nt-b of FANT-G - ieee1588 : ieee1588 port on nt of FNAT-H	ieee1588 ptp port index

Command Output

Table 130.18-2 "System Clock Management IEE1588 Status Command" Display parameters

Specific Information		
name	Type	Description
ptp-mode	Parameter type: <Ntr::PtpMode> (port-fault port-disabled port-listen	operational mode of the ne for ptp functionality <i>This element is always shown.</i>

130 System Status Commands

name	Type	Description
	port-pre-master port-master port-passive port-uncalibrated port-slave) Possible values: - port-fault : unicast ptp packet processing mode - port-disabled : unicast multicast packet processing mode - port-listen : unicast multicast packet processing mode - port-pre-master : unicast multicast packet processing mode - port-master : unicast multicast packet processing mode - port-passive : unicast multicast packet processing mode - port-uncalibrated : unicast multicast packet processing mode - port-slave : unicast multicast packet processing mode	
clkid	Parameter type: <Sys::SysClkPtpDefaultDSIdentity> - Hexadecimal Clock Identity (example : 01:02:03:04:05:06:07:08) - length: 8	the clock identity of current ptp slave <i>This element is always shown.</i>
mac-addr	Parameter type: <Sys::PTPMacAddr> (xx:xx:xx:xx:xx:xx xx:xx:xx:xx:xx:xx <Sys::MacAddr>) Possible values: - xx:xx:xx:xx:xx:xx : Invalid MAC address - xx:xx:xx:xx:xx:xx : Invalid MAC address Field type <Sys::MacAddr> - a mac-address (example : 01:02:03:04:05:06) - length: 6	mac address <i>This element is always shown.</i>

130.19 System Clock IEEE1588 current master detailed info Command

Command Description

This command show the detailed information of IEEE1588 current master.

User Level

The command can be accessed by operators with all privileges.

Command Syntax

The command has the following syntax:

```
> show system sync-ptp-currmaster [ (ptp-port) ]
```

Command Parameters

Table 130.19-1 "System Clock IEEE1588 current master detailed info Command" Resource Parameters

Resource Identifier	Type	Description
(ptp-port)	Format: (ieee1588-a ieee1588-b ieee1588-a:1 ieee1588-b:1 ieee1588) Possible values: - ieee1588-a : ieee1588 port on nt-a excluding FANT-G NT type - ieee1588-b : ieee1588 port on nt-b excluding FANT-G NT type - ieee1588-a:1 : ieee1588 port 1 on nt-a of FANT-G - ieee1588-b:1 : ieee1588 port 1 on nt-b of FANT-G - ieee1588 : ieee1588 port on nt of FNAT-H	ieee1588 ptp port index

Command Output

Table 130.19-2 "System Clock IEEE1588 current master detailed info Command" Display parameters

Specific Information		
name	Type	Description
leap61	Parameter type: <Sys::FlagValue> (false	leap61 <i>This element is only shown in</i>

130 System Status Commands

name	Type	Description
	true unknown) Possible values: - false : the flag is false - true : the flag is true - unknown : the flag is not available	<i>detail mode.</i>
leap59	Parameter type: <Sys::FlagValue> (false true unknown) Possible values: - false : the flag is false - true : the flag is true - unknown : the flag is not available	leap59 <i>This element is only shown in detail mode.</i>
utc-offset-valid	Parameter type: <Sys::FlagValue> (false true unknown) Possible values: - false : the flag is false - true : the flag is true - unknown : the flag is not available	the current utc offset valid <i>This element is only shown in detail mode.</i>
ptp-timescale	Parameter type: <Sys::FlagValue> (false true unknown) Possible values: - false : the flag is false - true : the flag is true - unknown : the flag is not available	ptp time scale <i>This element is only shown in detail mode.</i>
time-traceable	Parameter type: <Sys::FlagValue> (false true unknown) Possible values: - false : the flag is false - true : the flag is true - unknown : the flag is not available	time traceable <i>This element is only shown in detail mode.</i>
frequency-traceable	Parameter type: <Sys::FlagValue> (false true unknown) Possible values: - false : the flag is false - true : the flag is true - unknown : the flag is not available	frequency traceable <i>This element is only shown in detail mode.</i>
announce-interval	Parameter type: <Sys::SysSignedCharInt> - signed char - range: [-128...127]	LogAnnounceInterval <i>This element is only shown in detail mode.</i>
sync-interval	Parameter type: <Sys::SysSignedCharInt> - signed char - range: [-128...127]	LogSyncInterval <i>This element is only shown in detail mode.</i>
delay-interval	Parameter type: <Sys::SysSignedCharInt> - signed char - range: [-128...127]	LogMinDelayReqInterval <i>This element is only shown in detail mode.</i>
ip-addr	Parameter type: <Ip::V4Address> - IPv4-address	ip address <i>This element is only shown in</i>

name	Type	Description
		<i>detail mode.</i>
mac-addr	Parameter type: <Sys::PTPMacAddr> (xx:xx:xx:xx:xx:xx xx:xx:xx:xx:xx:xx <Sys::MacAddr>) Possible values: - xx:xx:xx:xx:xx:xx : Invalid MAC address - xx:xx:xx:xx:xx:xx : Invalid MAC address Field type <Sys::MacAddr> - a mac-address (example : 01:02:03:04:05:06) - length: 6	mac address <i>This element is only shown in detail mode.</i>
announce-packets	Parameter type: <Sys::SysPacketCountInt> - Packets counter - range: [0...4294967295]	announce packets <i>This element is only shown in detail mode.</i>
sync-packets	Parameter type: <Sys::SysPacketCountInt> - Packets counter - range: [0...4294967295]	sync packets <i>This element is only shown in detail mode.</i>
delay-req-packets	Parameter type: <Sys::SysPacketCountInt> - Packets counter - range: [0...4294967295]	delay req packets <i>This element is only shown in detail mode.</i>
delay-resp-packets	Parameter type: <Sys::SysPacketCountInt> - Packets counter - range: [0...4294967295]	delay req packets <i>This element is only shown in detail mode.</i>
utc-offset	Parameter type: <Sys::SysSignedShortInt> - signed short - range: [-32768...32767]	CurrentUtcOffset <i>This element is only shown in detail mode.</i>
log-var	Parameter type: <Sys::portNumber> - index number - range: [0...65535]	OffsetScaledLogVariance <i>This element is always shown.</i>
time-source	Parameter type: <Sys::PtpTimeSource> (atomic gps radio ptp ntp handset other internal unknown) Possible values: - atomic : ATOMIC_CLOCK - gps : GPS - radio : TERRESTRIAL_RADIO - ptp : PTP - ntp : NTP - handset : HAND_SET - other : OTHER - internal : INTERNAL_OSCILLATOR - unknown : No information	ptp time source <i>This element is only shown in detail mode.</i>
lock-time	Parameter type: <Sys::PtpTime> - yyyy-mm-dd:hour:min:sec (example : 2017-11-11:01:02:03) - length: 19	lock time <i>This element is only shown in detail mode.</i>
fail-time	Parameter type: <Sys::PtpTime> - yyyy-mm-dd:hour:min:sec (example : 2017-11-11:01:02:03) - length: 19	fail time <i>This element is only shown in detail mode.</i>

130 System Status Commands

name	Type	Description
fail-reason	Parameter type: <Sys::PtpFailReason> - Ptp Fail Reason - range: [a-zA-Z0-9-_.] - length: 1<=x<=32	fail reason <i>This element is only shown in detail mode.</i>
clkid	Parameter type: <Sys::SysClkPtpDefaultDSIdentity> - Hexadecimal Clock Identity (example : 01:02:03:04:05:06:07:08) - length: 8	the clock identity of current ptp master clock <i>This element is always shown.</i>
prio1	Parameter type: <Ntr::Priority> - priority of the acceptable master - range: [0...255]	the priority1 of current ptp master clock <i>This element is always shown.</i>
prio2	Parameter type: <Ntr::Priority> - priority of the acceptable master - range: [0...255]	the priority2 of current ptp master clock <i>This element is always shown.</i>
clkclass	Parameter type: <Sys::SysClkPtpClockQuality> - clock quality of the PTP source - range: [0...255]	the clock class of current ptp master clock <i>This element is always shown.</i>
clkaccuracy	Parameter type: <Sys::SysClkPtpClockAccuracy> - ptp clock accuracy - range: [0...255]	the clock accuracy of current ptp master clock <i>This element is always shown.</i>
portnumber	Parameter type: <Sys::portNumber> - index number - range: [0...65535]	the port number of current ptp master clock <i>This element is always shown.</i>
stepremoved	Parameter type: <Sys::stepRemoved> - index number - range: [0...65535]	the steps removed of current ptp master clock <i>This element is only shown in detail mode.</i>
grandmasterclkid	Parameter type: <Sys::SysClkPtpDefaultDSIdentity> - Hexadecimal Clock Identity (example : 01:02:03:04:05:06:07:08) - length: 8	the current ptp grand master clock identity <i>This element is always shown.</i>
domain	Parameter type: <Ntr::PtpDomain> - ptp domain - range: [0...255]	the domain of current ptp master clock <i>This element is always shown.</i>
masterselected	Parameter type: <Ntr::MasterSelected> (no yes) Possible values: - no : the current ptp master clock is not selected as reference - yes : the current ptp master clock is selected as reference	current ptp master clock selected as reference <i>This element is only shown in detail mode.</i>

130.20 System Clock IEEE1588 visible master detailed info Command

Command Description

This command show the detailed information of IEEE1588 visible master.

User Level

The command can be accessed by operators with all privileges.

Command Syntax

The command has the following syntax:

```
> show system sync-ptp-inmasters [ (vm-idx) ]
```

Command Parameters

Table 130.20-1 "System Clock IEEE1588 visible master detailed info Command" Resource Parameters

Resource Identifier	Type	Description
(vm-idx)	Format: (ieee1588-vm-a:1 ieee1588-vm-a:2 ieee1588-vm-a:3 ieee1588-vm-b:1 ieee1588-vm-b:2 ieee1588-vm-b:3) Possible values: - ieee1588-vm-a:1 : ieee1588 visible master 1 on nt-a - ieee1588-vm-a:2 : ieee1588 visible master 2 on nt-a - ieee1588-vm-a:3 : ieee1588 visible master 3 on nt-a - ieee1588-vm-b:1 : ieee1588 visible master 1 on nt-b - ieee1588-vm-b:2 : ieee1588 visible master 2 on nt-b - ieee1588-vm-b:3 : ieee1588 visible master 3 on nt-b	ieee1588 visible master index

Command Output

Table 130.20-2 "System Clock IEEE1588 visible master detailed info Command" Display parameters

Specific Information		
name	Type	Description
clkid	Parameter type: <Sys::SysClkPtpDefaultDSIdentity> - Hexadecimal Clock Identity (example :	the clock identity of ptp master clock

130 System Status Commands

name	Type	Description
	01:02:03:04:05:06:07:08) - length: 8	<i>This element is always shown.</i>
prio1	Parameter type: <Ntr::Priority> - priority of the acceptable master - range: [0...255]	the priority1 of ptp master clock <i>This element is always shown.</i>
prio2	Parameter type: <Ntr::Priority> - priority of the acceptable master - range: [0...255]	the priority2 of ptp master clock <i>This element is always shown.</i>
clkclass	Parameter type: <Sys::SysClkPtpClockQuality> - clock quality of the PTP source - range: [0...255]	the clock class of ptp master clock <i>This element is always shown.</i>
clkaccuracy	Parameter type: <Sys::SysClkPtpClockAccuracy> - ptp clock accuracy - range: [0...255]	the clock accuracy of ptp master clock <i>This element is always shown.</i>
portnumber	Parameter type: <Sys::portNumber> - index number - range: [0...65535]	the port number of current ptp master clock <i>This element is always shown.</i>
stepremoved	Parameter type: <Sys::stepRemoved> - index number - range: [0...65535]	the steps removed of ptp master clock <i>This element is only shown in detail mode.</i>
grandmasterclkid	Parameter type: <Sys::SysClkPtpDefaultDSIdentity> - Hexadecimal Clock Identity (example : 01:02:03:04:05:06:07:08) - length: 8	the ptp grand master clock identity <i>This element is always shown.</i>
domain	Parameter type: <Ntr::PtpDomain> - ptp domain - range: [0...255]	the domain of ptp master clock <i>This element is always shown.</i>
utc-offset	Parameter type: <Sys::SysSignedShortInt> - signed short - range: [-32768...32767]	CurrentUtcOffset <i>This element is only shown in detail mode.</i>
log-var	Parameter type: <Sys::portNumber> - index number - range: [0...65535]	OffsetScaledLogVariance <i>This element is always shown.</i>
time-source	Parameter type: <Sys::PtpTimeSource> (atomic gps radio ptp ntp handset other internal unknown) Possible values: - atomic : ATOMIC_CLOCK - gps : GPS - radio : TERRESTRIAL_RADIO - ptp : PTP - ntp : NTP - handset : HAND_SET - other : OTHER - internal : INTERNAL_OSCILLATOR - unknown : No information	ptp time source <i>This element is only shown in detail mode.</i>
leap61	Parameter type: <Sys::FlagValue> (false true	leap61 <i>This element is only shown in detail mode.</i>

name	Type	Description
	unknown) Possible values: - false : the flag is false - true : the flag is true - unknown : the flag is not available	
leap59	Parameter type: <Sys::FlagValue> (false true unknown) Possible values: - false : the flag is false - true : the flag is true - unknown : the flag is not available	leap59 <i>This element is only shown in detail mode.</i>
utc-offset-valid	Parameter type: <Sys::FlagValue> (false true unknown) Possible values: - false : the flag is false - true : the flag is true - unknown : the flag is not available	the current utc offset valid <i>This element is only shown in detail mode.</i>
ptp-timescale	Parameter type: <Sys::FlagValue> (false true unknown) Possible values: - false : the flag is false - true : the flag is true - unknown : the flag is not available	ptp time scale <i>This element is only shown in detail mode.</i>
time-traceable	Parameter type: <Sys::FlagValue> (false true unknown) Possible values: - false : the flag is false - true : the flag is true - unknown : the flag is not available	time traceable <i>This element is only shown in detail mode.</i>
frequency-traceable	Parameter type: <Sys::FlagValue> (false true unknown) Possible values: - false : the flag is false - true : the flag is true - unknown : the flag is not available	frequency traceable <i>This element is only shown in detail mode.</i>
announce-interval	Parameter type: <Sys::SysSignedCharInt> - signed char - range: [-128...127]	LogAnnounceInterval <i>This element is only shown in detail mode.</i>
sync-interval	Parameter type: <Sys::SysSignedCharInt> - signed char - range: [-128...127]	LogSyncInterval <i>This element is only shown in detail mode.</i>
delay-interval	Parameter type: <Sys::SysSignedCharInt> - signed char - range: [-128...127]	LogMinDelayReqInterval <i>This element is only shown in detail mode.</i>
ip-addr	Parameter type: <Ip::V4Address> - IPv4-address	ip address <i>This element is only shown in detail mode.</i>

130 System Status Commands

name	Type	Description
mac-addr	Parameter type: <Sys::PTPMacAddr> (xx:xx:xx:xx:xx:xx xx:xx:xx:xx:xx:xx <Sys::MacAddr>) Possible values: - xx:xx:xx:xx:xx:xx : Invalid MAC address - xx:xx:xx:xx:xx:xx : Invalid MAC address Field type <Sys::MacAddr> - a mac-address (example : 01:02:03:04:05:06) - length: 6	mac address <i>This element is only shown in detail mode.</i>

130.21 Scaling Mode Status Command

Command Description

This command displays the scaling mode.

User Level

The command can be accessed by operators with all privileges.

Command Syntax

The command has the following syntax:

```
> show system scalingmode
```

Command Output

Table 130.21-2 "Scaling Mode Status Command" Display parameters

Specific Information		
name	Type	Description
scaling-mode	Parameter type: <Sys::sysScalingMode> (l2plus l3plus_host l3plus_lpm) Possible values: - l2plus : l2plus-Mode with L2 FDB table - l3plus_host : l3plus_host-Mode with L3 host/ARP table - l3plus_lpm : l3plus_lpm-Mode with L3 LPM/route table	configure scaling mode <i>This element is always shown.</i>
oper-scaling-mode	Parameter type: <Sys::sysScalingMode> (l2plus l3plus_host l3plus_lpm) Possible values: - l2plus : l2plus-Mode with L2 FDB table - l3plus_host : l3plus_host-Mode with L3 host/ARP table - l3plus_lpm : l3plus_lpm-Mode with L3 LPM/route table	operational scaling mode <i>This element is always shown.</i>

130.22 System TechSupport Status Command

Command Description

This command shows the state of the TechSupport functionality and the existing On Demand Sessions

User Level

The command can be accessed by operators with all privileges.

Command Syntax

The command has the following syntax:

```
> show system techsupport [ (session) ]
```

Command Parameters

Table 130.22-1 "System TechSupport Status Command" Resource Parameters

Resource Identifier	Type	Description
(session)	Format: - number identifying a Tech Support Session - range: [0...65535]	Id of the session to display

Command Output

Table 130.22-2 "System TechSupport Status Command" Display parameters

Common Information:status		
name	Type	Description
status	Parameter type: <Sys::TechSupportStatus> (disabled enabled) Possible values: - disabled : the techsupport functionality is disabled - enabled : the techsupport functionality is enabled	<i>This element is always shown.</i>

Specific Information		
name	Type	Description
type	Parameter type: <Sys::TechSupportSessionType> (crashlog board-on-demand ifindex-on-demand) Possible values: - crashlog : a Tech Support file corresponging to a board crash - board-on-demand : a Tech Support file corresponding to a board-on-demand request - ifindex-on-demand : a Tech Support file corresponding to	show's the type of the Tech Support Entry <i>This element is only shown in detail mode.</i>

name	Type	Description
	an on-demand request for a certain interface	
object	Parameter type: <Equipm::NtLtSlotIndex1> (lt : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> nt-a nt-b nt <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::EqSlotId>) Possible values: - lt : lt-slot - nt-a : nt-a slot - nt-b : nt-b slot - nt : nt slot Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::EqSlotId> - the equipment slot number	show's the object corresponding to the Tech Support Entry <i>This element is always shown.</i>
server-ip-addr	Parameter type: <Ip::V4Address> - IPv4-address	shows the ip address of the server to which the Tech Support File needs to be uploaded <i>This element is always shown.</i>
file	Parameter type: <PrintableString> - printable string	show's the file corresponding to the Tech Support Entry <i>This element is always shown.</i>
state	Parameter type: <Sys::TechSupportSessionStatus> (busy failed done) Possible values: - busy : the entry is in busy state - failed : the entry failed - done : the entry is completed	show's the state corresponding to the Tech Support Entry <i>This element is always shown.</i>
error	Parameter type: <Sys::TechSupportSessionError> (no-error conv-error send-ping ts-not-avail inv-ping-resp send-gen gen-timeout inv-gen-resp send-info info-timeout inv-info-resp request-data data-timeout inv-data-resp res-acquiring res-acq-timeout incomplete res-not-avail disk-file-error encrytion-error) Possible values:	show's the error corresponding to the Tech Support Entry <i>This element is always shown.</i>

130 System Status Commands

name	Type	Description
	- no-error : the entry is not in error - conv-error : internal error: conversion failure - send-ping : send ping failed - ts-not-avail : techsupport not available at LT - inv-ping-resp : invalid ping response - send-gen : send generation failed - gen-timeout : generation timeout error - inv-gen-resp : invalid generation response - send-info : send data info failed - info-timeout : data info timeout error - inv-info-resp : invalid data info response - request-data : request data failed - data-timeout : data timeout error - inv-data-resp : invalid data response - res-acquiring : resource acquiring failed - res-acq-timeout : resource acquiring timeout - incomplete : not completed request - res-not-avail : resource should be already reserved - disk-file-error : CF file handler error - encrytion-error : encrytion failed	
size	Parameter type: <SignedInteger> - a signed integer	show's the error corresponding to the Tech Support Entry <i>This element is only shown in detail mode.</i>
time	Parameter type: <Sys::timeInSecs> - the time (yyyy-mm-dd:hour:minutes:secs) - unit: UTC	show's the error corresponding to the Tech Support Entry <i>This element is only shown in detail mode.</i>

130.23 show system fips

Command Description

Obsolete command.

User Level

The command can be accessed by operators with all privileges.

Command Syntax

The command has the following syntax:

> show system fips

Obsolete command.

Command Output

Table 130.23-2 "show system fips" Display parameters

Specific Information		
name	Type	Description
enabled-state	Parameter type: <Sys::sysFipsEnable> (disable enable) Possible values: - disable : Disable FIPS - enable : Enable FIPS	FIPS Enabled Status <i>This element is only shown in detail mode.</i>
run-test-state	Parameter type: <Sys::sysFipsTestState> (idle test-start test-passed) Possible values: - idle : Initial State - test-start : Trigger the self test - test-passed : Test is completed	total storage size available to store the messages <i>This element is only shown in detail mode.</i>

130.24 System Autoboot file timestamps Command

Command Description

This command displays the timestamps of the autoboot files.

User Level

The command can be accessed by operators with all privileges.

Command Syntax

The command has the following syntax:

```
> show system autoboot-config
```

Command Output

Table 130.24-2 "System Autoboot file timestamps Command" Display parameters

Specific Information		
name	Type	Description
last-extern-access	Parameter type: <Sys::LastExtFSAccessAutoBootTime> - yyyy-mm-dd:hour:min:sec (example : 2017-11-11:01:02:03) - length: 19	This parameter holds the timestamp when the autoboot files were last updated.. <i>This element is always shown.</i>
last-autoboot-start	Parameter type: <Sys::LastAutoBootTimeStart> - yyyy-mm-dd:hour:min:sec (example : 2017-11-11:01:02:03) - length: 19	This parameter holds the last timestamp right before the autoboot file was executed. <i>This element is always shown.</i>
last-autoboot-end	Parameter type: <Sys::LastAutoBootTimeEnd> - yyyy-mm-dd:hour:min:sec (example : 2017-11-11:01:02:03) - length: 19	This parameter holds the last timestamp right after the autoboot file was executed. <i>This element is always shown.</i>

131- daylight saving time Status Commands

131.1 daylight saving time Status Command Tree	131-6074
131.2 daylight saving time Status Commands	131-6075

131.1 daylight saving time Status Command Tree

Description

This chapter gives an overview of nodes that are handled by "daylight saving time Status Commands".

Command Tree

```
----show
  ----system
    ----dst
```

131.2 daylight saving time Status Commands

Command Description

This command displays the information about the daylight saving time and its related parameters.

User Level

The command can be accessed by operators with all privileges.

Command Syntax

The command has the following syntax:

> show system dst

Command Output

Table 131.2-2 " daylight saving time Status Commands" Display parameters

Specific Information		
name	Type	Description
isaaffected	Parameter type: <Sys::DstAffected> (yes no) Possible values: - yes : Now daylight saving time is affected - no : Now daylight saving time is not affected	specifies whether daylight saving time is affected. <i>This element is always shown.</i>

132- DST Configuration Commands

132.1 DST Configuration Command Tree	132-6077
132.2 DST Recurring method Command	132-6078

132.1 DST Configuration Command Tree

Description

This chapter gives an overview of nodes that are handled by "DST Configuration Commands".

Command Tree

```
----show
  ----system
    ----dst
      ----recurring-table
        - (zone)
```

132.2 DST Recurring method Command

Command Description

This command displays the information about the daylight saving time related parameters with recurring method.

User Level

The command can be accessed by operators with all privileges.

Command Syntax

The command has the following syntax:

```
> show system dst recurring-table [ (zone) ]
```

Command Parameters

Table 132.2-1 "DST Recurring method Command" Resource Parameters

Resource Identifier	Type	Description
(zone)	Format: - specify the offset for timezone from GMT/UTC - range: [-780...840]	specifies the timezone

Command Output

Table 132.2-2 "DST Recurring method Command" Display parameters

Specific Information		
name	Type	Description
start-time	Parameter type: <Sys::DSTRecurring> (jan - first - sun : <Sys::DSThour> : <Sys::DSTmin> jan - first - mon : <Sys::DSThour> : <Sys::DSTmin> jan - first - tues : <Sys::DSThour> : <Sys::DSTmin> jan - first - wed : <Sys::DSThour> : <Sys::DSTmin> jan - first - thur : <Sys::DSThour> : <Sys::DSTmin> jan - first - fri : <Sys::DSThour> : <Sys::DSTmin> jan - first - sat : <Sys::DSThour> : <Sys::DSTmin> jan - second - sun : <Sys::DSThour> : <Sys::DSTmin> jan - second - mon : <Sys::DSThour> : <Sys::DSTmin> jan - second - tues : <Sys::DSThour> : <Sys::DSTmin> jan - second - wed : <Sys::DSThour> : <Sys::DSTmin> jan - second - thur : <Sys::DSThour> : <Sys::DSTmin> jan - second - fri : <Sys::DSThour> : <Sys::DSTmin> jan - second - sat : <Sys::DSThour> : <Sys::DSTmin> jan - third - sun : <Sys::DSThour> : <Sys::DSTmin> jan - third - mon : <Sys::DSThour> : <Sys::DSTmin> jan - third - tues : <Sys::DSThour> : <Sys::DSTmin> jan - third - wed : <Sys::DSThour> : <Sys::DSTmin>	specifies start time of daylight saving time <i>This element is always shown.</i>

name	Type	Description
	jan - third - thur : <Sys::DSThour> : <Sys::DSTmin> jan - third - fri : <Sys::DSThour> : <Sys::DSTmin> jan - third - sat : <Sys::DSThour> : <Sys::DSTmin> jan - fourth - sun : <Sys::DSThour> : <Sys::DSTmin> jan - fourth - mon : <Sys::DSThour> : <Sys::DSTmin> jan - fourth - tues : <Sys::DSThour> : <Sys::DSTmin> jan - fourth - wed : <Sys::DSThour> : <Sys::DSTmin> jan - fourth - thur : <Sys::DSThour> : <Sys::DSTmin> jan - fourth - fri : <Sys::DSThour> : <Sys::DSTmin> jan - fourth - sat : <Sys::DSThour> : <Sys::DSTmin> jan - last - sun : <Sys::DSThour> : <Sys::DSTmin> jan - last - mon : <Sys::DSThour> : <Sys::DSTmin> jan - last - tues : <Sys::DSThour> : <Sys::DSTmin> jan - last - wed : <Sys::DSThour> : <Sys::DSTmin> jan - last - thur : <Sys::DSThour> : <Sys::DSTmin> jan - last - fri : <Sys::DSThour> : <Sys::DSTmin> jan - last - sat : <Sys::DSThour> : <Sys::DSTmin> feb - first - sun : <Sys::DSThour> : <Sys::DSTmin> feb - first - mon : <Sys::DSThour> : <Sys::DSTmin> feb - first - tues : <Sys::DSThour> : <Sys::DSTmin> feb - first - wed : <Sys::DSThour> : <Sys::DSTmin> feb - first - thur : <Sys::DSThour> : <Sys::DSTmin> feb - first - fri : <Sys::DSThour> : <Sys::DSTmin> feb - first - sat : <Sys::DSThour> : <Sys::DSTmin> feb - second - sun : <Sys::DSThour> : <Sys::DSTmin> feb - second - mon : <Sys::DSThour> : <Sys::DSTmin> feb - second - tues : <Sys::DSThour> : <Sys::DSTmin> feb - second - wed : <Sys::DSThour> : <Sys::DSTmin> feb - second - thur : <Sys::DSThour> : <Sys::DSTmin> feb - second - fri : <Sys::DSThour> : <Sys::DSTmin> feb - second - sat : <Sys::DSThour> : <Sys::DSTmin> feb - third - sun : <Sys::DSThour> : <Sys::DSTmin> feb - third - mon : <Sys::DSThour> : <Sys::DSTmin> feb - third - tues : <Sys::DSThour> : <Sys::DSTmin> feb - third - wed : <Sys::DSThour> : <Sys::DSTmin> feb - third - thur : <Sys::DSThour> : <Sys::DSTmin> feb - third - fri : <Sys::DSThour> : <Sys::DSTmin> feb - third - sat : <Sys::DSThour> : <Sys::DSTmin> feb - fourth - sun : <Sys::DSThour> : <Sys::DSTmin> feb - fourth - mon : <Sys::DSThour> : <Sys::DSTmin> feb - fourth - tues : <Sys::DSThour> : <Sys::DSTmin> feb - fourth - wed : <Sys::DSThour> : <Sys::DSTmin> feb - fourth - thur : <Sys::DSThour> : <Sys::DSTmin> feb - fourth - fri : <Sys::DSThour> : <Sys::DSTmin> feb - fourth - sat : <Sys::DSThour> : <Sys::DSTmin> feb - last - sun : <Sys::DSThour> : <Sys::DSTmin> feb - last - mon : <Sys::DSThour> : <Sys::DSTmin> feb - last - tues : <Sys::DSThour> : <Sys::DSTmin> feb - last - wed : <Sys::DSThour> : <Sys::DSTmin> feb - last - thur : <Sys::DSThour> : <Sys::DSTmin> feb - last - fri : <Sys::DSThour> : <Sys::DSTmin> feb - last - sat : <Sys::DSThour> : <Sys::DSTmin> mar - first - sun : <Sys::DSThour> : <Sys::DSTmin> mar - first - mon : <Sys::DSThour> : <Sys::DSTmin> mar - first - tues : <Sys::DSThour> : <Sys::DSTmin> mar - first - wed : <Sys::DSThour> : <Sys::DSTmin> mar - first - thur : <Sys::DSThour> : <Sys::DSTmin>	

name	Type	Description
	mar - first - fri : <Sys::DSThour> : <Sys::DSTmin> mar - first - sat : <Sys::DSThour> : <Sys::DSTmin> mar - second - sun : <Sys::DSThour> : <Sys::DSTmin> mar - second - mon : <Sys::DSThour> : <Sys::DSTmin> mar - second - tues : <Sys::DSThour> : <Sys::DSTmin> mar - second - wed : <Sys::DSThour> : <Sys::DSTmin> mar - second - thur : <Sys::DSThour> : <Sys::DSTmin> mar - second - fri : <Sys::DSThour> : <Sys::DSTmin> mar - second - sat : <Sys::DSThour> : <Sys::DSTmin> mar - third - sun : <Sys::DSThour> : <Sys::DSTmin> mar - third - mon : <Sys::DSThour> : <Sys::DSTmin> mar - third - tues : <Sys::DSThour> : <Sys::DSTmin> mar - third - wed : <Sys::DSThour> : <Sys::DSTmin> mar - third - thur : <Sys::DSThour> : <Sys::DSTmin> mar - third - fri : <Sys::DSThour> : <Sys::DSTmin> mar - third - sat : <Sys::DSThour> : <Sys::DSTmin> mar - fourth - sun : <Sys::DSThour> : <Sys::DSTmin> mar - fourth - mon : <Sys::DSThour> : <Sys::DSTmin> mar - fourth - tues : <Sys::DSThour> : <Sys::DSTmin> mar - fourth - wed : <Sys::DSThour> : <Sys::DSTmin> mar - fourth - thur : <Sys::DSThour> : <Sys::DSTmin> mar - fourth - fri : <Sys::DSThour> : <Sys::DSTmin> mar - fourth - sat : <Sys::DSThour> : <Sys::DSTmin> mar - last - sun : <Sys::DSThour> : <Sys::DSTmin> mar - last - mon : <Sys::DSThour> : <Sys::DSTmin> mar - last - tues : <Sys::DSThour> : <Sys::DSTmin> mar - last - wed : <Sys::DSThour> : <Sys::DSTmin> mar - last - thur : <Sys::DSThour> : <Sys::DSTmin> mar - last - fri : <Sys::DSThour> : <Sys::DSTmin> mar - last - sat : <Sys::DSThour> : <Sys::DSTmin> apr - first - sun : <Sys::DSThour> : <Sys::DSTmin> apr - first - mon : <Sys::DSThour> : <Sys::DSTmin> apr - first - tues : <Sys::DSThour> : <Sys::DSTmin> apr - first - wed : <Sys::DSThour> : <Sys::DSTmin> apr - first - thur : <Sys::DSThour> : <Sys::DSTmin> apr - first - fri : <Sys::DSThour> : <Sys::DSTmin> apr - first - sat : <Sys::DSThour> : <Sys::DSTmin> apr - second - sun : <Sys::DSThour> : <Sys::DSTmin> apr - second - mon : <Sys::DSThour> : <Sys::DSTmin> apr - second - tues : <Sys::DSThour> : <Sys::DSTmin> apr - second - wed : <Sys::DSThour> : <Sys::DSTmin> apr - second - thur : <Sys::DSThour> : <Sys::DSTmin> apr - second - fri : <Sys::DSThour> : <Sys::DSTmin> apr - second - sat : <Sys::DSThour> : <Sys::DSTmin> apr - third - sun : <Sys::DSThour> : <Sys::DSTmin> apr - third - mon : <Sys::DSThour> : <Sys::DSTmin> apr - third - tues : <Sys::DSThour> : <Sys::DSTmin> apr - third - wed : <Sys::DSThour> : <Sys::DSTmin> apr - third - thur : <Sys::DSThour> : <Sys::DSTmin> apr - third - fri : <Sys::DSThour> : <Sys::DSTmin> apr - third - sat : <Sys::DSThour> : <Sys::DSTmin> apr - fourth - sun : <Sys::DSThour> : <Sys::DSTmin> apr - fourth - mon : <Sys::DSThour> : <Sys::DSTmin> apr - fourth - tues : <Sys::DSThour> : <Sys::DSTmin> apr - fourth - wed : <Sys::DSThour> : <Sys::DSTmin> apr - fourth - thur : <Sys::DSThour> : <Sys::DSTmin> apr - fourth - fri : <Sys::DSThour> : <Sys::DSTmin>	

name	Type	Description
	apr - fourth - sat : <Sys::DSThour> : <Sys::DSTmin> apr - last - sun : <Sys::DSThour> : <Sys::DSTmin> apr - last - mon : <Sys::DSThour> : <Sys::DSTmin> apr - last - tues : <Sys::DSThour> : <Sys::DSTmin> apr - last - wed : <Sys::DSThour> : <Sys::DSTmin> apr - last - thur : <Sys::DSThour> : <Sys::DSTmin> apr - last - fri : <Sys::DSThour> : <Sys::DSTmin> apr - last - sat : <Sys::DSThour> : <Sys::DSTmin> may - first - sun : <Sys::DSThour> : <Sys::DSTmin> may - first - mon : <Sys::DSThour> : <Sys::DSTmin> may - first - tues : <Sys::DSThour> : <Sys::DSTmin> may - first - wed : <Sys::DSThour> : <Sys::DSTmin> may - first - thur : <Sys::DSThour> : <Sys::DSTmin> may - first - fri : <Sys::DSThour> : <Sys::DSTmin> may - first - sat : <Sys::DSThour> : <Sys::DSTmin> may - second - sun : <Sys::DSThour> : <Sys::DSTmin> may - second - mon : <Sys::DSThour> : <Sys::DSTmin> may - second - tues : <Sys::DSThour> : <Sys::DSTmin> may - second - wed : <Sys::DSThour> : <Sys::DSTmin> may - second - thur : <Sys::DSThour> : <Sys::DSTmin> may - second - fri : <Sys::DSThour> : <Sys::DSTmin> may - second - sat : <Sys::DSThour> : <Sys::DSTmin> may - third - sun : <Sys::DSThour> : <Sys::DSTmin> may - third - mon : <Sys::DSThour> : <Sys::DSTmin> may - third - tues : <Sys::DSThour> : <Sys::DSTmin> may - third - wed : <Sys::DSThour> : <Sys::DSTmin> may - third - thur : <Sys::DSThour> : <Sys::DSTmin> may - third - fri : <Sys::DSThour> : <Sys::DSTmin> may - third - sat : <Sys::DSThour> : <Sys::DSTmin> may - fourth - sun : <Sys::DSThour> : <Sys::DSTmin> may - fourth - mon : <Sys::DSThour> : <Sys::DSTmin> may - fourth - tues : <Sys::DSThour> : <Sys::DSTmin> may - fourth - wed : <Sys::DSThour> : <Sys::DSTmin> may - fourth - thur : <Sys::DSThour> : <Sys::DSTmin> may - fourth - fri : <Sys::DSThour> : <Sys::DSTmin> may - fourth - sat : <Sys::DSThour> : <Sys::DSTmin> may - last - sun : <Sys::DSThour> : <Sys::DSTmin> may - last - mon : <Sys::DSThour> : <Sys::DSTmin> may - last - tues : <Sys::DSThour> : <Sys::DSTmin> may - last - wed : <Sys::DSThour> : <Sys::DSTmin> may - last - thur : <Sys::DSThour> : <Sys::DSTmin> may - last - fri : <Sys::DSThour> : <Sys::DSTmin> may - last - sat : <Sys::DSThour> : <Sys::DSTmin> jun - first - sun : <Sys::DSThour> : <Sys::DSTmin> jun - first - mon : <Sys::DSThour> : <Sys::DSTmin> jun - first - tues : <Sys::DSThour> : <Sys::DSTmin> jun - first - wed : <Sys::DSThour> : <Sys::DSTmin> jun - first - thur : <Sys::DSThour> : <Sys::DSTmin> jun - first - fri : <Sys::DSThour> : <Sys::DSTmin> jun - first - sat : <Sys::DSThour> : <Sys::DSTmin> jun - second - sun : <Sys::DSThour> : <Sys::DSTmin> jun - second - mon : <Sys::DSThour> : <Sys::DSTmin> jun - second - tues : <Sys::DSThour> : <Sys::DSTmin> jun - second - wed : <Sys::DSThour> : <Sys::DSTmin> jun - second - thur : <Sys::DSThour> : <Sys::DSTmin> jun - second - fri : <Sys::DSThour> : <Sys::DSTmin> jun - second - sat : <Sys::DSThour> : <Sys::DSTmin>	

name	Type	Description
	jun - third - sun : <Sys::DSThour> : <Sys::DSTmin> jun - third - mon : <Sys::DSThour> : <Sys::DSTmin> jun - third - tues : <Sys::DSThour> : <Sys::DSTmin> jun - third - wed : <Sys::DSThour> : <Sys::DSTmin> jun - third - thur : <Sys::DSThour> : <Sys::DSTmin> jun - third - fri : <Sys::DSThour> : <Sys::DSTmin> jun - third - sat : <Sys::DSThour> : <Sys::DSTmin> jun - fourth - sun : <Sys::DSThour> : <Sys::DSTmin> jun - fourth - mon : <Sys::DSThour> : <Sys::DSTmin> jun - fourth - tues : <Sys::DSThour> : <Sys::DSTmin> jun - fourth - wed : <Sys::DSThour> : <Sys::DSTmin> jun - fourth - thur : <Sys::DSThour> : <Sys::DSTmin> jun - fourth - fri : <Sys::DSThour> : <Sys::DSTmin> jun - fourth - sat : <Sys::DSThour> : <Sys::DSTmin> jun - last - sun : <Sys::DSThour> : <Sys::DSTmin> jun - last - mon : <Sys::DSThour> : <Sys::DSTmin> jun - last - tues : <Sys::DSThour> : <Sys::DSTmin> jun - last - wed : <Sys::DSThour> : <Sys::DSTmin> jun - last - thur : <Sys::DSThour> : <Sys::DSTmin> jun - last - fri : <Sys::DSThour> : <Sys::DSTmin> jun - last - sat : <Sys::DSThour> : <Sys::DSTmin> jul - first - sun : <Sys::DSThour> : <Sys::DSTmin> jul - first - mon : <Sys::DSThour> : <Sys::DSTmin> jul - first - tues : <Sys::DSThour> : <Sys::DSTmin> jul - first - wed : <Sys::DSThour> : <Sys::DSTmin> jul - first - thur : <Sys::DSThour> : <Sys::DSTmin> jul - first - fri : <Sys::DSThour> : <Sys::DSTmin> jul - first - sat : <Sys::DSThour> : <Sys::DSTmin> jul - second - sun : <Sys::DSThour> : <Sys::DSTmin> jul - second - mon : <Sys::DSThour> : <Sys::DSTmin> jul - second - tues : <Sys::DSThour> : <Sys::DSTmin> jul - second - wed : <Sys::DSThour> : <Sys::DSTmin> jul - second - thur : <Sys::DSThour> : <Sys::DSTmin> jul - second - fri : <Sys::DSThour> : <Sys::DSTmin> jul - second - sat : <Sys::DSThour> : <Sys::DSTmin> jul - third - sun : <Sys::DSThour> : <Sys::DSTmin> jul - third - mon : <Sys::DSThour> : <Sys::DSTmin> jul - third - tues : <Sys::DSThour> : <Sys::DSTmin> jul - third - wed : <Sys::DSThour> : <Sys::DSTmin> jul - third - thur : <Sys::DSThour> : <Sys::DSTmin> jul - third - fri : <Sys::DSThour> : <Sys::DSTmin> jul - third - sat : <Sys::DSThour> : <Sys::DSTmin> jul - fourth - sun : <Sys::DSThour> : <Sys::DSTmin> jul - fourth - mon : <Sys::DSThour> : <Sys::DSTmin> jul - fourth - tues : <Sys::DSThour> : <Sys::DSTmin> jul - fourth - wed : <Sys::DSThour> : <Sys::DSTmin> jul - fourth - thur : <Sys::DSThour> : <Sys::DSTmin> jul - fourth - fri : <Sys::DSThour> : <Sys::DSTmin> jul - fourth - sat : <Sys::DSThour> : <Sys::DSTmin> jul - last - sun : <Sys::DSThour> : <Sys::DSTmin> jul - last - mon : <Sys::DSThour> : <Sys::DSTmin> jul - last - tues : <Sys::DSThour> : <Sys::DSTmin> jul - last - wed : <Sys::DSThour> : <Sys::DSTmin> jul - last - thur : <Sys::DSThour> : <Sys::DSTmin> jul - last - fri : <Sys::DSThour> : <Sys::DSTmin> jul - last - sat : <Sys::DSThour> : <Sys::DSTmin> aug - first - sun : <Sys::DSThour> : <Sys::DSTmin>	

name	Type	Description
	aug - first - mon : <Sys::DSThour> : <Sys::DSTmin> aug - first - tues : <Sys::DSThour> : <Sys::DSTmin> aug - first - wed : <Sys::DSThour> : <Sys::DSTmin> aug - first - thur : <Sys::DSThour> : <Sys::DSTmin> aug - first - fri : <Sys::DSThour> : <Sys::DSTmin> aug - first - sat : <Sys::DSThour> : <Sys::DSTmin> aug - second - sun : <Sys::DSThour> : <Sys::DSTmin> aug - second - mon : <Sys::DSThour> : <Sys::DSTmin> aug - second - tues : <Sys::DSThour> : <Sys::DSTmin> aug - second - wed : <Sys::DSThour> : <Sys::DSTmin> aug - second - thur : <Sys::DSThour> : <Sys::DSTmin> aug - second - fri : <Sys::DSThour> : <Sys::DSTmin> aug - second - sat : <Sys::DSThour> : <Sys::DSTmin> aug - third - sun : <Sys::DSThour> : <Sys::DSTmin> aug - third - mon : <Sys::DSThour> : <Sys::DSTmin> aug - third - tues : <Sys::DSThour> : <Sys::DSTmin> aug - third - wed : <Sys::DSThour> : <Sys::DSTmin> aug - third - thur : <Sys::DSThour> : <Sys::DSTmin> aug - third - fri : <Sys::DSThour> : <Sys::DSTmin> aug - third - sat : <Sys::DSThour> : <Sys::DSTmin> aug - fourth - sun : <Sys::DSThour> : <Sys::DSTmin> aug - fourth - mon : <Sys::DSThour> : <Sys::DSTmin> aug - fourth - tues : <Sys::DSThour> : <Sys::DSTmin> aug - fourth - wed : <Sys::DSThour> : <Sys::DSTmin> aug - fourth - thur : <Sys::DSThour> : <Sys::DSTmin> aug - fourth - fri : <Sys::DSThour> : <Sys::DSTmin> aug - fourth - sat : <Sys::DSThour> : <Sys::DSTmin> aug - last - sun : <Sys::DSThour> : <Sys::DSTmin> aug - last - mon : <Sys::DSThour> : <Sys::DSTmin> aug - last - tues : <Sys::DSThour> : <Sys::DSTmin> aug - last - wed : <Sys::DSThour> : <Sys::DSTmin> aug - last - thur : <Sys::DSThour> : <Sys::DSTmin> aug - last - fri : <Sys::DSThour> : <Sys::DSTmin> aug - last - sat : <Sys::DSThour> : <Sys::DSTmin> sep - first - sun : <Sys::DSThour> : <Sys::DSTmin> sep - first - mon : <Sys::DSThour> : <Sys::DSTmin> sep - first - tues : <Sys::DSThour> : <Sys::DSTmin> sep - first - wed : <Sys::DSThour> : <Sys::DSTmin> sep - first - thur : <Sys::DSThour> : <Sys::DSTmin> sep - first - fri : <Sys::DSThour> : <Sys::DSTmin> sep - first - sat : <Sys::DSThour> : <Sys::DSTmin> sep - second - sun : <Sys::DSThour> : <Sys::DSTmin> sep - second - mon : <Sys::DSThour> : <Sys::DSTmin> sep - second - tues : <Sys::DSThour> : <Sys::DSTmin> sep - second - wed : <Sys::DSThour> : <Sys::DSTmin> sep - second - thur : <Sys::DSThour> : <Sys::DSTmin> sep - second - fri : <Sys::DSThour> : <Sys::DSTmin> sep - second - sat : <Sys::DSThour> : <Sys::DSTmin> sep - third - sun : <Sys::DSThour> : <Sys::DSTmin> sep - third - mon : <Sys::DSThour> : <Sys::DSTmin> sep - third - tues : <Sys::DSThour> : <Sys::DSTmin> sep - third - wed : <Sys::DSThour> : <Sys::DSTmin> sep - third - thur : <Sys::DSThour> : <Sys::DSTmin> sep - third - fri : <Sys::DSThour> : <Sys::DSTmin> sep - third - sat : <Sys::DSThour> : <Sys::DSTmin> sep - fourth - sun : <Sys::DSThour> : <Sys::DSTmin> sep - fourth - mon : <Sys::DSThour> : <Sys::DSTmin>	

name	Type	Description
	sep - fourth - tues : <Sys::DSThour> : <Sys::DSTmin> sep - fourth - wed : <Sys::DSThour> : <Sys::DSTmin> sep - fourth - thur : <Sys::DSThour> : <Sys::DSTmin> sep - fourth - fri : <Sys::DSThour> : <Sys::DSTmin> sep - fourth - sat : <Sys::DSThour> : <Sys::DSTmin> sep - last - sun : <Sys::DSThour> : <Sys::DSTmin> sep - last - mon : <Sys::DSThour> : <Sys::DSTmin> sep - last - tues : <Sys::DSThour> : <Sys::DSTmin> sep - last - wed : <Sys::DSThour> : <Sys::DSTmin> sep - last - thur : <Sys::DSThour> : <Sys::DSTmin> sep - last - fri : <Sys::DSThour> : <Sys::DSTmin> sep - last - sat : <Sys::DSThour> : <Sys::DSTmin> oct - first - sun : <Sys::DSThour> : <Sys::DSTmin> oct - first - mon : <Sys::DSThour> : <Sys::DSTmin> oct - first - tues : <Sys::DSThour> : <Sys::DSTmin> oct - first - wed : <Sys::DSThour> : <Sys::DSTmin> oct - first - thur : <Sys::DSThour> : <Sys::DSTmin> oct - first - fri : <Sys::DSThour> : <Sys::DSTmin> oct - first - sat : <Sys::DSThour> : <Sys::DSTmin> oct - second - sun : <Sys::DSThour> : <Sys::DSTmin> oct - second - mon : <Sys::DSThour> : <Sys::DSTmin> oct - second - tues : <Sys::DSThour> : <Sys::DSTmin> oct - second - wed : <Sys::DSThour> : <Sys::DSTmin> oct - second - thur : <Sys::DSThour> : <Sys::DSTmin> oct - second - fri : <Sys::DSThour> : <Sys::DSTmin> oct - second - sat : <Sys::DSThour> : <Sys::DSTmin> oct - third - sun : <Sys::DSThour> : <Sys::DSTmin> oct - third - mon : <Sys::DSThour> : <Sys::DSTmin> oct - third - tues : <Sys::DSThour> : <Sys::DSTmin> oct - third - wed : <Sys::DSThour> : <Sys::DSTmin> oct - third - thur : <Sys::DSThour> : <Sys::DSTmin> oct - third - fri : <Sys::DSThour> : <Sys::DSTmin> oct - third - sat : <Sys::DSThour> : <Sys::DSTmin> oct - fourth - sun : <Sys::DSThour> : <Sys::DSTmin> oct - fourth - mon : <Sys::DSThour> : <Sys::DSTmin> oct - fourth - tues : <Sys::DSThour> : <Sys::DSTmin> oct - fourth - wed : <Sys::DSThour> : <Sys::DSTmin> oct - fourth - thur : <Sys::DSThour> : <Sys::DSTmin> oct - fourth - fri : <Sys::DSThour> : <Sys::DSTmin> oct - fourth - sat : <Sys::DSThour> : <Sys::DSTmin> oct - last - sun : <Sys::DSThour> : <Sys::DSTmin> oct - last - mon : <Sys::DSThour> : <Sys::DSTmin> oct - last - tues : <Sys::DSThour> : <Sys::DSTmin> oct - last - wed : <Sys::DSThour> : <Sys::DSTmin> oct - last - thur : <Sys::DSThour> : <Sys::DSTmin> oct - last - fri : <Sys::DSThour> : <Sys::DSTmin> oct - last - sat : <Sys::DSThour> : <Sys::DSTmin> nov - first - sun : <Sys::DSThour> : <Sys::DSTmin> nov - first - mon : <Sys::DSThour> : <Sys::DSTmin> nov - first - tues : <Sys::DSThour> : <Sys::DSTmin> nov - first - wed : <Sys::DSThour> : <Sys::DSTmin> nov - first - thur : <Sys::DSThour> : <Sys::DSTmin> nov - first - fri : <Sys::DSThour> : <Sys::DSTmin> nov - first - sat : <Sys::DSThour> : <Sys::DSTmin> nov - second - sun : <Sys::DSThour> : <Sys::DSTmin> nov - second - mon : <Sys::DSThour> : <Sys::DSTmin> nov - second - tues : <Sys::DSThour> : <Sys::DSTmin>	

name	Type	Description
	nov - second - wed : <Sys::DSThour> : <Sys::DSTmin> nov - second - thur : <Sys::DSThour> : <Sys::DSTmin> nov - second - fri : <Sys::DSThour> : <Sys::DSTmin> nov - second - sat : <Sys::DSThour> : <Sys::DSTmin> nov - third - sun : <Sys::DSThour> : <Sys::DSTmin> nov - third - mon : <Sys::DSThour> : <Sys::DSTmin> nov - third - tues : <Sys::DSThour> : <Sys::DSTmin> nov - third - wed : <Sys::DSThour> : <Sys::DSTmin> nov - third - thur : <Sys::DSThour> : <Sys::DSTmin> nov - third - fri : <Sys::DSThour> : <Sys::DSTmin> nov - third - sat : <Sys::DSThour> : <Sys::DSTmin> nov - fourth - sun : <Sys::DSThour> : <Sys::DSTmin> nov - fourth - mon : <Sys::DSThour> : <Sys::DSTmin> nov - fourth - tues : <Sys::DSThour> : <Sys::DSTmin> nov - fourth - wed : <Sys::DSThour> : <Sys::DSTmin> nov - fourth - thur : <Sys::DSThour> : <Sys::DSTmin> nov - fourth - fri : <Sys::DSThour> : <Sys::DSTmin> nov - fourth - sat : <Sys::DSThour> : <Sys::DSTmin> nov - last - sun : <Sys::DSThour> : <Sys::DSTmin> nov - last - mon : <Sys::DSThour> : <Sys::DSTmin> nov - last - tues : <Sys::DSThour> : <Sys::DSTmin> nov - last - wed : <Sys::DSThour> : <Sys::DSTmin> nov - last - thur : <Sys::DSThour> : <Sys::DSTmin> nov - last - fri : <Sys::DSThour> : <Sys::DSTmin> nov - last - sat : <Sys::DSThour> : <Sys::DSTmin> dec - first - sun : <Sys::DSThour> : <Sys::DSTmin> dec - first - mon : <Sys::DSThour> : <Sys::DSTmin> dec - first - tues : <Sys::DSThour> : <Sys::DSTmin> dec - first - wed : <Sys::DSThour> : <Sys::DSTmin> dec - first - thur : <Sys::DSThour> : <Sys::DSTmin> dec - first - fri : <Sys::DSThour> : <Sys::DSTmin> dec - first - sat : <Sys::DSThour> : <Sys::DSTmin> dec - second - sun : <Sys::DSThour> : <Sys::DSTmin> dec - second - mon : <Sys::DSThour> : <Sys::DSTmin> dec - second - tues : <Sys::DSThour> : <Sys::DSTmin> dec - second - wed : <Sys::DSThour> : <Sys::DSTmin> dec - second - thur : <Sys::DSThour> : <Sys::DSTmin> dec - second - fri : <Sys::DSThour> : <Sys::DSTmin> dec - second - sat : <Sys::DSThour> : <Sys::DSTmin> dec - third - sun : <Sys::DSThour> : <Sys::DSTmin> dec - third - mon : <Sys::DSThour> : <Sys::DSTmin> dec - third - tues : <Sys::DSThour> : <Sys::DSTmin> dec - third - wed : <Sys::DSThour> : <Sys::DSTmin> dec - third - thur : <Sys::DSThour> : <Sys::DSTmin> dec - third - fri : <Sys::DSThour> : <Sys::DSTmin> dec - third - sat : <Sys::DSThour> : <Sys::DSTmin> dec - fourth - sun : <Sys::DSThour> : <Sys::DSTmin> dec - fourth - mon : <Sys::DSThour> : <Sys::DSTmin> dec - fourth - tues : <Sys::DSThour> : <Sys::DSTmin> dec - fourth - wed : <Sys::DSThour> : <Sys::DSTmin> dec - fourth - thur : <Sys::DSThour> : <Sys::DSTmin> dec - fourth - fri : <Sys::DSThour> : <Sys::DSTmin> dec - fourth - sat : <Sys::DSThour> : <Sys::DSTmin> dec - last - sun : <Sys::DSThour> : <Sys::DSTmin> dec - last - mon : <Sys::DSThour> : <Sys::DSTmin> dec - last - tues : <Sys::DSThour> : <Sys::DSTmin> dec - last - wed : <Sys::DSThour> : <Sys::DSTmin>	

132 DST Configuration Commands

name	Type	Description
	<pre> dec - last - thur : <Sys::DSThour> : <Sys::DSTmin> dec - last - fri : <Sys::DSThour> : <Sys::DSTmin> dec - last - sat : <Sys::DSThour> : <Sys::DSTmin>) Possible values: - jan : january - feb : february - mar : march - apr : april - may : may - jun : june - jul : july - aug : august - sep : september - oct : october - nov : november - dec : december Possible values: - first : first week of the month - second : second week of the month - third : third week of the month - fourth : fourth week of the month - last : last week of the month Possible values: - sun : sunday - mon : monday - tues : tuesday - wed : wednesday - thur : thursday - fri : friday - sat : saturday Field type <Sys::DSThour> - hour - range: [0...23] Field type <Sys::DSTmin> - minutes - unit: minutes - range: [0...59] </pre>	
end-time	<pre> Parameter type: <Sys::DSTRecurring> (jan - first - sun : <Sys::DSThour> : <Sys::DSTmin> jan - first - mon : <Sys::DSThour> : <Sys::DSTmin> jan - first - tues : <Sys::DSThour> : <Sys::DSTmin> jan - first - wed : <Sys::DSThour> : <Sys::DSTmin> jan - first - thur : <Sys::DSThour> : <Sys::DSTmin> jan - first - fri : <Sys::DSThour> : <Sys::DSTmin> jan - first - sat : <Sys::DSThour> : <Sys::DSTmin> jan - second - sun : <Sys::DSThour> : <Sys::DSTmin> jan - second - mon : <Sys::DSThour> : <Sys::DSTmin> jan - second - tues : <Sys::DSThour> : <Sys::DSTmin> jan - second - wed : <Sys::DSThour> : <Sys::DSTmin> jan - second - thur : <Sys::DSThour> : <Sys::DSTmin> jan - second - fri : <Sys::DSThour> : <Sys::DSTmin> jan - second - sat : <Sys::DSThour> : <Sys::DSTmin> jan - third - sun : <Sys::DSThour> : <Sys::DSTmin> jan - third - mon : <Sys::DSThour> : <Sys::DSTmin> jan - third - tues : <Sys::DSThour> : <Sys::DSTmin> jan - third - wed : <Sys::DSThour> : <Sys::DSTmin> jan - third - thur : <Sys::DSThour> : <Sys::DSTmin> </pre>	specifies end time of daylight saving time <i>This element is always shown.</i>

name	Type	Description
	jan - third - fri : <Sys::DSThour> : <Sys::DSTmin> jan - third - sat : <Sys::DSThour> : <Sys::DSTmin> jan - fourth - sun : <Sys::DSThour> : <Sys::DSTmin> jan - fourth - mon : <Sys::DSThour> : <Sys::DSTmin> jan - fourth - tues : <Sys::DSThour> : <Sys::DSTmin> jan - fourth - wed : <Sys::DSThour> : <Sys::DSTmin> jan - fourth - thur : <Sys::DSThour> : <Sys::DSTmin> jan - fourth - fri : <Sys::DSThour> : <Sys::DSTmin> jan - fourth - sat : <Sys::DSThour> : <Sys::DSTmin> jan - last - sun : <Sys::DSThour> : <Sys::DSTmin> jan - last - mon : <Sys::DSThour> : <Sys::DSTmin> jan - last - tues : <Sys::DSThour> : <Sys::DSTmin> jan - last - wed : <Sys::DSThour> : <Sys::DSTmin> jan - last - thur : <Sys::DSThour> : <Sys::DSTmin> jan - last - fri : <Sys::DSThour> : <Sys::DSTmin> jan - last - sat : <Sys::DSThour> : <Sys::DSTmin> feb - first - sun : <Sys::DSThour> : <Sys::DSTmin> feb - first - mon : <Sys::DSThour> : <Sys::DSTmin> feb - first - tues : <Sys::DSThour> : <Sys::DSTmin> feb - first - wed : <Sys::DSThour> : <Sys::DSTmin> feb - first - thur : <Sys::DSThour> : <Sys::DSTmin> feb - first - fri : <Sys::DSThour> : <Sys::DSTmin> feb - first - sat : <Sys::DSThour> : <Sys::DSTmin> feb - second - sun : <Sys::DSThour> : <Sys::DSTmin> feb - second - mon : <Sys::DSThour> : <Sys::DSTmin> feb - second - tues : <Sys::DSThour> : <Sys::DSTmin> feb - second - wed : <Sys::DSThour> : <Sys::DSTmin> feb - second - thur : <Sys::DSThour> : <Sys::DSTmin> feb - second - fri : <Sys::DSThour> : <Sys::DSTmin> feb - second - sat : <Sys::DSThour> : <Sys::DSTmin> feb - third - sun : <Sys::DSThour> : <Sys::DSTmin> feb - third - mon : <Sys::DSThour> : <Sys::DSTmin> feb - third - tues : <Sys::DSThour> : <Sys::DSTmin> feb - third - wed : <Sys::DSThour> : <Sys::DSTmin> feb - third - thur : <Sys::DSThour> : <Sys::DSTmin> feb - third - fri : <Sys::DSThour> : <Sys::DSTmin> feb - third - sat : <Sys::DSThour> : <Sys::DSTmin> feb - fourth - sun : <Sys::DSThour> : <Sys::DSTmin> feb - fourth - mon : <Sys::DSThour> : <Sys::DSTmin> feb - fourth - tues : <Sys::DSThour> : <Sys::DSTmin> feb - fourth - wed : <Sys::DSThour> : <Sys::DSTmin> feb - fourth - thur : <Sys::DSThour> : <Sys::DSTmin> feb - fourth - fri : <Sys::DSThour> : <Sys::DSTmin> feb - fourth - sat : <Sys::DSThour> : <Sys::DSTmin> feb - last - sun : <Sys::DSThour> : <Sys::DSTmin> feb - last - mon : <Sys::DSThour> : <Sys::DSTmin> feb - last - tues : <Sys::DSThour> : <Sys::DSTmin> feb - last - wed : <Sys::DSThour> : <Sys::DSTmin> feb - last - thur : <Sys::DSThour> : <Sys::DSTmin> feb - last - fri : <Sys::DSThour> : <Sys::DSTmin> feb - last - sat : <Sys::DSThour> : <Sys::DSTmin> mar - first - sun : <Sys::DSThour> : <Sys::DSTmin> mar - first - mon : <Sys::DSThour> : <Sys::DSTmin> mar - first - tues : <Sys::DSThour> : <Sys::DSTmin> mar - first - wed : <Sys::DSThour> : <Sys::DSTmin> mar - first - thur : <Sys::DSThour> : <Sys::DSTmin> mar - first - fri : <Sys::DSThour> : <Sys::DSTmin>	

name	Type	Description
	mar - first - sat : <Sys::DSThour> : <Sys::DSTmin> mar - second - sun : <Sys::DSThour> : <Sys::DSTmin> mar - second - mon : <Sys::DSThour> : <Sys::DSTmin> mar - second - tues : <Sys::DSThour> : <Sys::DSTmin> mar - second - wed : <Sys::DSThour> : <Sys::DSTmin> mar - second - thur : <Sys::DSThour> : <Sys::DSTmin> mar - second - fri : <Sys::DSThour> : <Sys::DSTmin> mar - second - sat : <Sys::DSThour> : <Sys::DSTmin> mar - third - sun : <Sys::DSThour> : <Sys::DSTmin> mar - third - mon : <Sys::DSThour> : <Sys::DSTmin> mar - third - tues : <Sys::DSThour> : <Sys::DSTmin> mar - third - wed : <Sys::DSThour> : <Sys::DSTmin> mar - third - thur : <Sys::DSThour> : <Sys::DSTmin> mar - third - fri : <Sys::DSThour> : <Sys::DSTmin> mar - third - sat : <Sys::DSThour> : <Sys::DSTmin> mar - fourth - sun : <Sys::DSThour> : <Sys::DSTmin> mar - fourth - mon : <Sys::DSThour> : <Sys::DSTmin> mar - fourth - tues : <Sys::DSThour> : <Sys::DSTmin> mar - fourth - wed : <Sys::DSThour> : <Sys::DSTmin> mar - fourth - thur : <Sys::DSThour> : <Sys::DSTmin> mar - fourth - fri : <Sys::DSThour> : <Sys::DSTmin> mar - fourth - sat : <Sys::DSThour> : <Sys::DSTmin> mar - last - sun : <Sys::DSThour> : <Sys::DSTmin> mar - last - mon : <Sys::DSThour> : <Sys::DSTmin> mar - last - tues : <Sys::DSThour> : <Sys::DSTmin> mar - last - wed : <Sys::DSThour> : <Sys::DSTmin> mar - last - thur : <Sys::DSThour> : <Sys::DSTmin> mar - last - fri : <Sys::DSThour> : <Sys::DSTmin> mar - last - sat : <Sys::DSThour> : <Sys::DSTmin> apr - first - sun : <Sys::DSThour> : <Sys::DSTmin> apr - first - mon : <Sys::DSThour> : <Sys::DSTmin> apr - first - tues : <Sys::DSThour> : <Sys::DSTmin> apr - first - wed : <Sys::DSThour> : <Sys::DSTmin> apr - first - thur : <Sys::DSThour> : <Sys::DSTmin> apr - first - fri : <Sys::DSThour> : <Sys::DSTmin> apr - first - sat : <Sys::DSThour> : <Sys::DSTmin> apr - second - sun : <Sys::DSThour> : <Sys::DSTmin> apr - second - mon : <Sys::DSThour> : <Sys::DSTmin> apr - second - tues : <Sys::DSThour> : <Sys::DSTmin> apr - second - wed : <Sys::DSThour> : <Sys::DSTmin> apr - second - thur : <Sys::DSThour> : <Sys::DSTmin> apr - second - fri : <Sys::DSThour> : <Sys::DSTmin> apr - second - sat : <Sys::DSThour> : <Sys::DSTmin> apr - third - sun : <Sys::DSThour> : <Sys::DSTmin> apr - third - mon : <Sys::DSThour> : <Sys::DSTmin> apr - third - tues : <Sys::DSThour> : <Sys::DSTmin> apr - third - wed : <Sys::DSThour> : <Sys::DSTmin> apr - third - thur : <Sys::DSThour> : <Sys::DSTmin> apr - third - fri : <Sys::DSThour> : <Sys::DSTmin> apr - third - sat : <Sys::DSThour> : <Sys::DSTmin> apr - fourth - sun : <Sys::DSThour> : <Sys::DSTmin> apr - fourth - mon : <Sys::DSThour> : <Sys::DSTmin> apr - fourth - tues : <Sys::DSThour> : <Sys::DSTmin> apr - fourth - wed : <Sys::DSThour> : <Sys::DSTmin> apr - fourth - thur : <Sys::DSThour> : <Sys::DSTmin> apr - fourth - fri : <Sys::DSThour> : <Sys::DSTmin> apr - fourth - sat : <Sys::DSThour> : <Sys::DSTmin>	

name	Type	Description
	apr - last - sun : <Sys::DSThour> : <Sys::DSTmin> apr - last - mon : <Sys::DSThour> : <Sys::DSTmin> apr - last - tues : <Sys::DSThour> : <Sys::DSTmin> apr - last - wed : <Sys::DSThour> : <Sys::DSTmin> apr - last - thur : <Sys::DSThour> : <Sys::DSTmin> apr - last - fri : <Sys::DSThour> : <Sys::DSTmin> apr - last - sat : <Sys::DSThour> : <Sys::DSTmin> may - first - sun : <Sys::DSThour> : <Sys::DSTmin> may - first - mon : <Sys::DSThour> : <Sys::DSTmin> may - first - tues : <Sys::DSThour> : <Sys::DSTmin> may - first - wed : <Sys::DSThour> : <Sys::DSTmin> may - first - thur : <Sys::DSThour> : <Sys::DSTmin> may - first - fri : <Sys::DSThour> : <Sys::DSTmin> may - first - sat : <Sys::DSThour> : <Sys::DSTmin> may - second - sun : <Sys::DSThour> : <Sys::DSTmin> may - second - mon : <Sys::DSThour> : <Sys::DSTmin> may - second - tues : <Sys::DSThour> : <Sys::DSTmin> may - second - wed : <Sys::DSThour> : <Sys::DSTmin> may - second - thur : <Sys::DSThour> : <Sys::DSTmin> may - second - fri : <Sys::DSThour> : <Sys::DSTmin> may - second - sat : <Sys::DSThour> : <Sys::DSTmin> may - third - sun : <Sys::DSThour> : <Sys::DSTmin> may - third - mon : <Sys::DSThour> : <Sys::DSTmin> may - third - tues : <Sys::DSThour> : <Sys::DSTmin> may - third - wed : <Sys::DSThour> : <Sys::DSTmin> may - third - thur : <Sys::DSThour> : <Sys::DSTmin> may - third - fri : <Sys::DSThour> : <Sys::DSTmin> may - third - sat : <Sys::DSThour> : <Sys::DSTmin> may - fourth - sun : <Sys::DSThour> : <Sys::DSTmin> may - fourth - mon : <Sys::DSThour> : <Sys::DSTmin> may - fourth - tues : <Sys::DSThour> : <Sys::DSTmin> may - fourth - wed : <Sys::DSThour> : <Sys::DSTmin> may - fourth - thur : <Sys::DSThour> : <Sys::DSTmin> may - fourth - fri : <Sys::DSThour> : <Sys::DSTmin> may - fourth - sat : <Sys::DSThour> : <Sys::DSTmin> may - last - sun : <Sys::DSThour> : <Sys::DSTmin> may - last - mon : <Sys::DSThour> : <Sys::DSTmin> may - last - tues : <Sys::DSThour> : <Sys::DSTmin> may - last - wed : <Sys::DSThour> : <Sys::DSTmin> may - last - thur : <Sys::DSThour> : <Sys::DSTmin> may - last - fri : <Sys::DSThour> : <Sys::DSTmin> may - last - sat : <Sys::DSThour> : <Sys::DSTmin> jun - first - sun : <Sys::DSThour> : <Sys::DSTmin> jun - first - mon : <Sys::DSThour> : <Sys::DSTmin> jun - first - tues : <Sys::DSThour> : <Sys::DSTmin> jun - first - wed : <Sys::DSThour> : <Sys::DSTmin> jun - first - thur : <Sys::DSThour> : <Sys::DSTmin> jun - first - fri : <Sys::DSThour> : <Sys::DSTmin> jun - first - sat : <Sys::DSThour> : <Sys::DSTmin> jun - second - sun : <Sys::DSThour> : <Sys::DSTmin> jun - second - mon : <Sys::DSThour> : <Sys::DSTmin> jun - second - tues : <Sys::DSThour> : <Sys::DSTmin> jun - second - wed : <Sys::DSThour> : <Sys::DSTmin> jun - second - thur : <Sys::DSThour> : <Sys::DSTmin> jun - second - fri : <Sys::DSThour> : <Sys::DSTmin> jun - second - sat : <Sys::DSThour> : <Sys::DSTmin> jun - third - sun : <Sys::DSThour> : <Sys::DSTmin>	

name	Type	Description
	jun - third - mon : <Sys::DSThour> : <Sys::DSTmin> jun - third - tues : <Sys::DSThour> : <Sys::DSTmin> jun - third - wed : <Sys::DSThour> : <Sys::DSTmin> jun - third - thur : <Sys::DSThour> : <Sys::DSTmin> jun - third - fri : <Sys::DSThour> : <Sys::DSTmin> jun - third - sat : <Sys::DSThour> : <Sys::DSTmin> jun - fourth - sun : <Sys::DSThour> : <Sys::DSTmin> jun - fourth - mon : <Sys::DSThour> : <Sys::DSTmin> jun - fourth - tues : <Sys::DSThour> : <Sys::DSTmin> jun - fourth - wed : <Sys::DSThour> : <Sys::DSTmin> jun - fourth - thur : <Sys::DSThour> : <Sys::DSTmin> jun - fourth - fri : <Sys::DSThour> : <Sys::DSTmin> jun - fourth - sat : <Sys::DSThour> : <Sys::DSTmin> jun - last - sun : <Sys::DSThour> : <Sys::DSTmin> jun - last - mon : <Sys::DSThour> : <Sys::DSTmin> jun - last - tues : <Sys::DSThour> : <Sys::DSTmin> jun - last - wed : <Sys::DSThour> : <Sys::DSTmin> jun - last - thur : <Sys::DSThour> : <Sys::DSTmin> jun - last - fri : <Sys::DSThour> : <Sys::DSTmin> jun - last - sat : <Sys::DSThour> : <Sys::DSTmin> jul - first - sun : <Sys::DSThour> : <Sys::DSTmin> jul - first - mon : <Sys::DSThour> : <Sys::DSTmin> jul - first - tues : <Sys::DSThour> : <Sys::DSTmin> jul - first - wed : <Sys::DSThour> : <Sys::DSTmin> jul - first - thur : <Sys::DSThour> : <Sys::DSTmin> jul - first - fri : <Sys::DSThour> : <Sys::DSTmin> jul - first - sat : <Sys::DSThour> : <Sys::DSTmin> jul - second - sun : <Sys::DSThour> : <Sys::DSTmin> jul - second - mon : <Sys::DSThour> : <Sys::DSTmin> jul - second - tues : <Sys::DSThour> : <Sys::DSTmin> jul - second - wed : <Sys::DSThour> : <Sys::DSTmin> jul - second - thur : <Sys::DSThour> : <Sys::DSTmin> jul - second - fri : <Sys::DSThour> : <Sys::DSTmin> jul - second - sat : <Sys::DSThour> : <Sys::DSTmin> jul - third - sun : <Sys::DSThour> : <Sys::DSTmin> jul - third - mon : <Sys::DSThour> : <Sys::DSTmin> jul - third - tues : <Sys::DSThour> : <Sys::DSTmin> jul - third - wed : <Sys::DSThour> : <Sys::DSTmin> jul - third - thur : <Sys::DSThour> : <Sys::DSTmin> jul - third - fri : <Sys::DSThour> : <Sys::DSTmin> jul - third - sat : <Sys::DSThour> : <Sys::DSTmin> jul - fourth - sun : <Sys::DSThour> : <Sys::DSTmin> jul - fourth - mon : <Sys::DSThour> : <Sys::DSTmin> jul - fourth - tues : <Sys::DSThour> : <Sys::DSTmin> jul - fourth - wed : <Sys::DSThour> : <Sys::DSTmin> jul - fourth - thur : <Sys::DSThour> : <Sys::DSTmin> jul - fourth - fri : <Sys::DSThour> : <Sys::DSTmin> jul - fourth - sat : <Sys::DSThour> : <Sys::DSTmin> jul - last - sun : <Sys::DSThour> : <Sys::DSTmin> jul - last - mon : <Sys::DSThour> : <Sys::DSTmin> jul - last - tues : <Sys::DSThour> : <Sys::DSTmin> jul - last - wed : <Sys::DSThour> : <Sys::DSTmin> jul - last - thur : <Sys::DSThour> : <Sys::DSTmin> jul - last - fri : <Sys::DSThour> : <Sys::DSTmin> jul - last - sat : <Sys::DSThour> : <Sys::DSTmin> aug - first - sun : <Sys::DSThour> : <Sys::DSTmin> aug - first - mon : <Sys::DSThour> : <Sys::DSTmin>	

name	Type	Description
	aug - first - tues : <Sys::DSThour> : <Sys::DSTmin> aug - first - wed : <Sys::DSThour> : <Sys::DSTmin> aug - first - thur : <Sys::DSThour> : <Sys::DSTmin> aug - first - fri : <Sys::DSThour> : <Sys::DSTmin> aug - first - sat : <Sys::DSThour> : <Sys::DSTmin> aug - second - sun : <Sys::DSThour> : <Sys::DSTmin> aug - second - mon : <Sys::DSThour> : <Sys::DSTmin> aug - second - tues : <Sys::DSThour> : <Sys::DSTmin> aug - second - wed : <Sys::DSThour> : <Sys::DSTmin> aug - second - thur : <Sys::DSThour> : <Sys::DSTmin> aug - second - fri : <Sys::DSThour> : <Sys::DSTmin> aug - second - sat : <Sys::DSThour> : <Sys::DSTmin> aug - third - sun : <Sys::DSThour> : <Sys::DSTmin> aug - third - mon : <Sys::DSThour> : <Sys::DSTmin> aug - third - tues : <Sys::DSThour> : <Sys::DSTmin> aug - third - wed : <Sys::DSThour> : <Sys::DSTmin> aug - third - thur : <Sys::DSThour> : <Sys::DSTmin> aug - third - fri : <Sys::DSThour> : <Sys::DSTmin> aug - third - sat : <Sys::DSThour> : <Sys::DSTmin> aug - fourth - sun : <Sys::DSThour> : <Sys::DSTmin> aug - fourth - mon : <Sys::DSThour> : <Sys::DSTmin> aug - fourth - tues : <Sys::DSThour> : <Sys::DSTmin> aug - fourth - wed : <Sys::DSThour> : <Sys::DSTmin> aug - fourth - thur : <Sys::DSThour> : <Sys::DSTmin> aug - fourth - fri : <Sys::DSThour> : <Sys::DSTmin> aug - fourth - sat : <Sys::DSThour> : <Sys::DSTmin> aug - last - sun : <Sys::DSThour> : <Sys::DSTmin> aug - last - mon : <Sys::DSThour> : <Sys::DSTmin> aug - last - tues : <Sys::DSThour> : <Sys::DSTmin> aug - last - wed : <Sys::DSThour> : <Sys::DSTmin> aug - last - thur : <Sys::DSThour> : <Sys::DSTmin> aug - last - fri : <Sys::DSThour> : <Sys::DSTmin> aug - last - sat : <Sys::DSThour> : <Sys::DSTmin> sep - first - sun : <Sys::DSThour> : <Sys::DSTmin> sep - first - mon : <Sys::DSThour> : <Sys::DSTmin> sep - first - tues : <Sys::DSThour> : <Sys::DSTmin> sep - first - wed : <Sys::DSThour> : <Sys::DSTmin> sep - first - thur : <Sys::DSThour> : <Sys::DSTmin> sep - first - fri : <Sys::DSThour> : <Sys::DSTmin> sep - first - sat : <Sys::DSThour> : <Sys::DSTmin> sep - second - sun : <Sys::DSThour> : <Sys::DSTmin> sep - second - mon : <Sys::DSThour> : <Sys::DSTmin> sep - second - tues : <Sys::DSThour> : <Sys::DSTmin> sep - second - wed : <Sys::DSThour> : <Sys::DSTmin> sep - second - thur : <Sys::DSThour> : <Sys::DSTmin> sep - second - fri : <Sys::DSThour> : <Sys::DSTmin> sep - second - sat : <Sys::DSThour> : <Sys::DSTmin> sep - third - sun : <Sys::DSThour> : <Sys::DSTmin> sep - third - mon : <Sys::DSThour> : <Sys::DSTmin> sep - third - tues : <Sys::DSThour> : <Sys::DSTmin> sep - third - wed : <Sys::DSThour> : <Sys::DSTmin> sep - third - thur : <Sys::DSThour> : <Sys::DSTmin> sep - third - fri : <Sys::DSThour> : <Sys::DSTmin> sep - third - sat : <Sys::DSThour> : <Sys::DSTmin> sep - fourth - sun : <Sys::DSThour> : <Sys::DSTmin> sep - fourth - mon : <Sys::DSThour> : <Sys::DSTmin> sep - fourth - tues : <Sys::DSThour> : <Sys::DSTmin>	

name	Type	Description
	sep - fourth - wed : <Sys::DSThour> : <Sys::DSTmin> sep - fourth - thur : <Sys::DSThour> : <Sys::DSTmin> sep - fourth - fri : <Sys::DSThour> : <Sys::DSTmin> sep - fourth - sat : <Sys::DSThour> : <Sys::DSTmin> sep - last - sun : <Sys::DSThour> : <Sys::DSTmin> sep - last - mon : <Sys::DSThour> : <Sys::DSTmin> sep - last - tues : <Sys::DSThour> : <Sys::DSTmin> sep - last - wed : <Sys::DSThour> : <Sys::DSTmin> sep - last - thur : <Sys::DSThour> : <Sys::DSTmin> sep - last - fri : <Sys::DSThour> : <Sys::DSTmin> sep - last - sat : <Sys::DSThour> : <Sys::DSTmin> oct - first - sun : <Sys::DSThour> : <Sys::DSTmin> oct - first - mon : <Sys::DSThour> : <Sys::DSTmin> oct - first - tues : <Sys::DSThour> : <Sys::DSTmin> oct - first - wed : <Sys::DSThour> : <Sys::DSTmin> oct - first - thur : <Sys::DSThour> : <Sys::DSTmin> oct - first - fri : <Sys::DSThour> : <Sys::DSTmin> oct - first - sat : <Sys::DSThour> : <Sys::DSTmin> oct - second - sun : <Sys::DSThour> : <Sys::DSTmin> oct - second - mon : <Sys::DSThour> : <Sys::DSTmin> oct - second - tues : <Sys::DSThour> : <Sys::DSTmin> oct - second - wed : <Sys::DSThour> : <Sys::DSTmin> oct - second - thur : <Sys::DSThour> : <Sys::DSTmin> oct - second - fri : <Sys::DSThour> : <Sys::DSTmin> oct - second - sat : <Sys::DSThour> : <Sys::DSTmin> oct - third - sun : <Sys::DSThour> : <Sys::DSTmin> oct - third - mon : <Sys::DSThour> : <Sys::DSTmin> oct - third - tues : <Sys::DSThour> : <Sys::DSTmin> oct - third - wed : <Sys::DSThour> : <Sys::DSTmin> oct - third - thur : <Sys::DSThour> : <Sys::DSTmin> oct - third - fri : <Sys::DSThour> : <Sys::DSTmin> oct - third - sat : <Sys::DSThour> : <Sys::DSTmin> oct - fourth - sun : <Sys::DSThour> : <Sys::DSTmin> oct - fourth - mon : <Sys::DSThour> : <Sys::DSTmin> oct - fourth - tues : <Sys::DSThour> : <Sys::DSTmin> oct - fourth - wed : <Sys::DSThour> : <Sys::DSTmin> oct - fourth - thur : <Sys::DSThour> : <Sys::DSTmin> oct - fourth - fri : <Sys::DSThour> : <Sys::DSTmin> oct - fourth - sat : <Sys::DSThour> : <Sys::DSTmin> oct - last - sun : <Sys::DSThour> : <Sys::DSTmin> oct - last - mon : <Sys::DSThour> : <Sys::DSTmin> oct - last - tues : <Sys::DSThour> : <Sys::DSTmin> oct - last - wed : <Sys::DSThour> : <Sys::DSTmin> oct - last - thur : <Sys::DSThour> : <Sys::DSTmin> oct - last - fri : <Sys::DSThour> : <Sys::DSTmin> oct - last - sat : <Sys::DSThour> : <Sys::DSTmin> nov - first - sun : <Sys::DSThour> : <Sys::DSTmin> nov - first - mon : <Sys::DSThour> : <Sys::DSTmin> nov - first - tues : <Sys::DSThour> : <Sys::DSTmin> nov - first - wed : <Sys::DSThour> : <Sys::DSTmin> nov - first - thur : <Sys::DSThour> : <Sys::DSTmin> nov - first - fri : <Sys::DSThour> : <Sys::DSTmin> nov - first - sat : <Sys::DSThour> : <Sys::DSTmin> nov - second - sun : <Sys::DSThour> : <Sys::DSTmin> nov - second - mon : <Sys::DSThour> : <Sys::DSTmin> nov - second - tues : <Sys::DSThour> : <Sys::DSTmin> nov - second - wed : <Sys::DSThour> : <Sys::DSTmin>	

name	Type	Description
	nov - second - thur : <Sys::DSThour> : <Sys::DSTmin> nov - second - fri : <Sys::DSThour> : <Sys::DSTmin> nov - second - sat : <Sys::DSThour> : <Sys::DSTmin> nov - third - sun : <Sys::DSThour> : <Sys::DSTmin> nov - third - mon : <Sys::DSThour> : <Sys::DSTmin> nov - third - tues : <Sys::DSThour> : <Sys::DSTmin> nov - third - wed : <Sys::DSThour> : <Sys::DSTmin> nov - third - thur : <Sys::DSThour> : <Sys::DSTmin> nov - third - fri : <Sys::DSThour> : <Sys::DSTmin> nov - third - sat : <Sys::DSThour> : <Sys::DSTmin> nov - fourth - sun : <Sys::DSThour> : <Sys::DSTmin> nov - fourth - mon : <Sys::DSThour> : <Sys::DSTmin> nov - fourth - tues : <Sys::DSThour> : <Sys::DSTmin> nov - fourth - wed : <Sys::DSThour> : <Sys::DSTmin> nov - fourth - thur : <Sys::DSThour> : <Sys::DSTmin> nov - fourth - fri : <Sys::DSThour> : <Sys::DSTmin> nov - fourth - sat : <Sys::DSThour> : <Sys::DSTmin> nov - last - sun : <Sys::DSThour> : <Sys::DSTmin> nov - last - mon : <Sys::DSThour> : <Sys::DSTmin> nov - last - tues : <Sys::DSThour> : <Sys::DSTmin> nov - last - wed : <Sys::DSThour> : <Sys::DSTmin> nov - last - thur : <Sys::DSThour> : <Sys::DSTmin> nov - last - fri : <Sys::DSThour> : <Sys::DSTmin> nov - last - sat : <Sys::DSThour> : <Sys::DSTmin> dec - first - sun : <Sys::DSThour> : <Sys::DSTmin> dec - first - mon : <Sys::DSThour> : <Sys::DSTmin> dec - first - tues : <Sys::DSThour> : <Sys::DSTmin> dec - first - wed : <Sys::DSThour> : <Sys::DSTmin> dec - first - thur : <Sys::DSThour> : <Sys::DSTmin> dec - first - fri : <Sys::DSThour> : <Sys::DSTmin> dec - first - sat : <Sys::DSThour> : <Sys::DSTmin> dec - second - sun : <Sys::DSThour> : <Sys::DSTmin> dec - second - mon : <Sys::DSThour> : <Sys::DSTmin> dec - second - tues : <Sys::DSThour> : <Sys::DSTmin> dec - second - wed : <Sys::DSThour> : <Sys::DSTmin> dec - second - thur : <Sys::DSThour> : <Sys::DSTmin> dec - second - fri : <Sys::DSThour> : <Sys::DSTmin> dec - second - sat : <Sys::DSThour> : <Sys::DSTmin> dec - third - sun : <Sys::DSThour> : <Sys::DSTmin> dec - third - mon : <Sys::DSThour> : <Sys::DSTmin> dec - third - tues : <Sys::DSThour> : <Sys::DSTmin> dec - third - wed : <Sys::DSThour> : <Sys::DSTmin> dec - third - thur : <Sys::DSThour> : <Sys::DSTmin> dec - third - fri : <Sys::DSThour> : <Sys::DSTmin> dec - third - sat : <Sys::DSThour> : <Sys::DSTmin> dec - fourth - sun : <Sys::DSThour> : <Sys::DSTmin> dec - fourth - mon : <Sys::DSThour> : <Sys::DSTmin> dec - fourth - tues : <Sys::DSThour> : <Sys::DSTmin> dec - fourth - wed : <Sys::DSThour> : <Sys::DSTmin> dec - fourth - thur : <Sys::DSThour> : <Sys::DSTmin> dec - fourth - fri : <Sys::DSThour> : <Sys::DSTmin> dec - fourth - sat : <Sys::DSThour> : <Sys::DSTmin> dec - last - sun : <Sys::DSThour> : <Sys::DSTmin> dec - last - mon : <Sys::DSThour> : <Sys::DSTmin> dec - last - tues : <Sys::DSThour> : <Sys::DSTmin> dec - last - wed : <Sys::DSThour> : <Sys::DSTmin> dec - last - thur : <Sys::DSThour> : <Sys::DSTmin>	

132 DST Configuration Commands

name	Type	Description
	dec - last - fri : <Sys::DSThour> : <Sys::DSTmin> dec - last - sat : <Sys::DSThour> : <Sys::DSTmin>) Possible values: - jan : january - feb : february - mar : march - apr : april - may : may - jun : june - jul : july - aug : august - sep : september - oct : october - nov : november - dec : december Possible values: - first : first week of the month - second : second week of the month - third : third week of the month - fourth : fourth week of the month - last : last week of the month Possible values: - sun : sunday - mon : monday - tues : tuesday - wed : wednesday - thur : thursday - fri : friday - sat : saturday Field type <Sys::DSThour> - hour - range: [0...23] Field type <Sys::DSTmin> - minutes - unit: minutes - range: [0...59]	
offset	Parameter type: <Sys::DstAdjustment> - The number of minutes that will be adjusted to the time - unit: minutes - range: [0...60]	display the adjustment of daylight saving time <i>This element is always shown.</i>
isaffectedsrc	Parameter type: <Sys::isaffectedsrc> (yes no) Possible values: - yes : this item's timezone matches current OLT timezone - no : this item's timezone doesn't match current OLT timezone	specifies whether this item matches the current OLT timezone <i>This element is always shown.</i>

133- DST Configuration Commands

133.1 DST Configuration Command Tree	133-6096
133.2 DST Date method Command	133-6097

133.1 DST Configuration Command Tree

Description

This chapter gives an overview of nodes that are handled by "DST Configuration Commands".

Command Tree

```
----show
  ----system
    ----dst
      ----date-table
        - (zone)
```

133.2 DST Date method Command

Command Description

This command displays the information about the daylight saving time related parameters with date method for some year.

User Level

The command can be accessed by operators with all privileges.

Command Syntax

The command has the following syntax:

```
> show system dst date-table [ (zone) ]
```

Command Parameters

Table 133.2-1 "DST Date method Command" Resource Parameters

Resource Identifier	Type	Description
(zone)	Format: - specify the offset for timezone from GMT/UTC - range: [-780...840]	specifies the timezone

Command Output

Table 133.2-2 "DST Date method Command" Display parameters

Specific Information		
name	Type	Description
start-time	Parameter type: <Sys::GaugeTimeInSecs> - the time (yyyy-mm-dd:hour:minutes:secs)	specifies start time of daylight saving time <i>This element is always shown.</i>
end-time	Parameter type: <Sys::GaugeTimeInSecs> - the time (yyyy-mm-dd:hour:minutes:secs)	specifies end time of daylight saving time <i>This element is always shown.</i>
offset	Parameter type: <Sys::DstAdjustment> - The number of minutes that will be adjusted to the time - unit: minutes - range: [0...60]	display the adjustment of daylight saving time <i>This element is always shown.</i>
isaffectedsrc	Parameter type: <Sys::isaffectedsrc> (yes no) Possible values: - yes : this item's timezone matches current OLT timezone - no : this item's timezone doesn't match current OLT timezone	specifies whether this item matches the current OLT timezone <i>This element is always shown.</i>

134- Transaction Status Commands

134.1 Transaction Status Command Tree	134-6100
134.2 Transaction Log Status Command	134-6101
134.3 Transaction Log Entry Status Command	134-6103

134.1 Transaction Status Command Tree

Description

This chapter gives an overview of nodes that are handled by "Transaction Status Commands".

Command Tree

```
----show
  ----transaction
    ----set-log-table
      - (log-table-index)
    ----log-entry
```

134.2 Transaction Log Status Command

Command Description

This command displays the transaction set log parameters.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show transaction set-log-table [ (log-table-index) ]
```

Command Parameters

Table 134.2-1 "Transaction Log Status Command" Resource Parameters

Resource Identifier	Type	Description
(log-table-index)	Format: - a signed integer	the key in the set Log table

Command Output

Table 134.2-2 "Transaction Log Status Command" Display parameters

Specific Information		
name	Type	Description
log-ipaddr	Parameter type: <Ip::IpXAddress> (<Ip::V4Address> ipv6 : <ipv6::Prefix>) Possible values: - ipv6 : ipv6-address Field type <Ip::V4Address> - IPv4-address Field type <ipv6::Prefix> - IPv6-address	IP address of the Manager who changed this object <i>This element is always shown.</i>
changed-object-id	Parameter type: <Object> - an object identifier	the Object Identifier of an object which has been changed. <i>This element is always shown.</i>
context	Parameter type: <Trans::context> (nt shub xvps1 xvps2 xvps3 xvps4	The context, which the object belongs to <i>This element is always shown.</i>

134 Transaction Status Commands

name	Type	Description
	xvps5 xvps6 xvps7 xvps8 ihub dynamic aint1 ainta1 aintb1 dpoe vvpsa) Possible values: - nt : nt: nt context - shub : shub: shub context - xvps1 : xvps1: xvps1 context - xvps2 : xvps2: xvps2 context - xvps3 : xvps3: xvps3 context - xvps4 : xvps4: xvps4 context - xvps5 : xvps5: xvps5 context - xvps6 : xvps6: xvps6 context - xvps7 : xvps7: xvps7 context - xvps8 : xvps8: xvps8 context - ihub : ihub: ihub context - dynamic : dynamic: dynamic context - aint1 : aint1: aint1 context - ainta1 : ainta1: ainta1 context - aintb1 : aintb1: aintb1 context - dpoe : dpoe: dpoe context - vvpsa : vvpsa: vvpsa context	

134.3 Transaction Log Entry Status Command

Command Description

This command displays the transaction log entry-related parameters.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> show transaction log-entry
```

Command Output

Table 134.3-2 "Transaction Log Entry Status Command" Display parameters

Specific Information		
name	Type	Description
set-log-lastentry	Parameter type: <SignedInteger> - a signed integer	index of the last entry that has been added to the set log table. <i>This element is always shown.</i>
set-log-resettime	Parameter type: <Sys::Time> - the time (yyyy-mm-dd:hour:minutes:secs) - unit: UTC	time when set log has been reset <i>This element is always shown.</i>
set-log-overflowed	Parameter type: <Trans::overflowed> (not-overflowed overflowed) Possible values: - not-overflowed : log buffer not overflowed is 1 - overflowed : log buffer overflowed is 2	specifies whether the set log buffer is overflowed or not. <i>This element is always shown.</i>
set-log-buffersize	Parameter type: <SignedInteger> - a signed integer	the size of the internal set log buffer. <i>This element is always shown.</i>
nbr-of-sets	Parameter type: <SignedInteger> - a signed integer	nbr of successful sets since system is up. <i>This element is always shown.</i>

135- Error Status Command

135.1 Error Status Command Tree
135.2 Error Log Status Command

135-6105
135-6106

135.1 Error Status Command Tree

Description

This chapter gives an overview of nodes that are handled by "Error Status Command".

Command Tree

```
----show
  ----error
    - (id)
```

135.2 Error Log Status Command

Command Description

This command displays the error log status.

User Level

The command can be accessed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

> show error (id)

Command Parameters

Table 135.2-1 "Error Log Status Command" Resource Parameters

Resource Identifier	Type	Description
(id)	Format: - a signed integer	error number

Command Output

Table 135.2-2 "Error Log Status Command" Display parameters

Common Information:error-log related information		
name	Type	Description
last-entry	Parameter type: <Error::ErrLogLastEntry> - index of the last entry of error log table	index of the last entry that is added to the error log table. <i>This element is always shown.</i>
reset-time	Parameter type: <Sys::Time> - the time (yyyy-mm-dd:hour:minutes:secs) - unit: UTC	time value when the error log is resetted <i>This element is always shown.</i>
buffer-size	Parameter type: <SignedInteger> - a signed integer	size of the internal log buffer. <i>This element is always shown.</i>
overflowed	Parameter type: <Error::LogOverFlow> (no yes) Possible values: - no : when log buffer is reset - yes : full action set to warp around	specifies whether log buffer is overflowed or not. <i>This element is always shown.</i>
Specific Information		
name	Type	Description
timestamp	Parameter type: <Sys::Time> - the time (yyyy-mm-dd:hour:minutes:secs) - unit: UTC	network time when the error is generated. <i>This element is always shown.</i>

name	Type	Description
originator	Parameter type: <Alarm::ReqIdAndIPAddress> (<SignedInteger> @ <Ip::V4Address> ipv6 : <SignedInteger> @ <Ip::V6Prefix>) Possible values: - ipv6 : ipv6-address Field type <SignedInteger> - a signed integer Field type <Ip::V4Address> - IPv4-address Field type <Ip::V6Prefix> - IPv6-address	request-id and IP address that generated the error <i>This element is only shown in detail mode.</i>
description	Parameter type: <Description-127> - description to help the operator to identify the object - length: x<=127	description of the error. <i>This element is always shown.</i>
info	Parameter type: <PrintableString> - printable string	additional information to guide to correct the error <i>This element is only shown in detail mode.</i>
obj-id	Parameter type: <Alarm::MibName> - representation of the mib name	object identifier in the request that caused the error. <i>This element is always shown.</i>
obj-value	Parameter type: <PrintableString> - printable string	value received from the manager for the object that generated the error. <i>This element is only shown in detail mode.</i>

136- Software Status Commands

136.1 Software Status Command Tree	136-6109
136.2 Database Status Command	136-6110
136.3 Disk Status Command	136-6112
136.4 Overall Software Package Status Command	136-6114
136.5 Software Management Upgrade Plan Command	136-6117
136.6 Software Management Upgrade Status Command	136-6119
136.7 Software Package Status Command	136-6121
136.8 File Status Command	136-6123
136.9 Upload/Download Status Command	136-6125
136.10 Upload/Download Sub-directory Status Command	136-6128
136.11 Software Version For ANSI Status Command	136-6129
136.12 Software Version For ETSI Status Command	136-6130
136.13 TLS CA file download Status Command	136-6131
136.14 Lightspan Migration Status Command	136-6133
136.15 lacm OAM DB save Status Command	136-6135
136.16 Upload/Download Sw ONTSw Status Command	136-6136

136.1 Software Status Command Tree

Description

This chapter gives an overview of nodes that are handled by "Software Status Commands".

Command Tree

```

----show
  ----software-mngt
    ----database
      - (db-container)
      - oswp-number
    ----descriptor-files
      - (index)
    ----oswp
      - (index)
    ----upgrade-plan
      - phase
      - slot
    ----upgrade-status
      - phase
      - slot
    ----swp
      - (name)
    ----swp-disk-file
      - (name)
      - file-name
      - file-board-type
    ----upload-download
    ----upload-download-dir
    ----version
      ----ansi
      ----etsi
    ----tls-cafile
      - (tls-cafile-name)
    ----ls-migration
    ----oam-save-protected
    ----upload-download-info

```

136.2 Database Status Command

Command Description

This command displays the various database parameters.

User Level

The command can be accessed by operators with software management privileges.

Command Syntax

The command has the following syntax:

```
> show software-mngt database [ (db-container) [ oswp-number <SwMngt::DbmOswpIndex> ] ]
```

Command Parameters

Table 136.2-1 "Database Status Command" Resource Parameters

Resource Identifier	Type	Description
(db-container)	Format: (first second third) Possible values: - first : first container - second : second container - third : third container	the database container ID
oswp-number	Parameter type: <SwMngt::DbmOswpIndex> Format: - index in the database table - range: [1...2]	index in the database table

Command Output

Table 136.2-2 "Database Status Command" Display parameters

Specific Information		
name	Type	Description
name	Parameter type: <SwMngt::dbmDatabaseName> - a printable string - length: x<=32	A string representing the database. The value 'NO-NAME' will be used by the system for the default databases. <i>This element is always shown.</i>
oper-status	Parameter type: <SwMngt::dBaseOperStatus> (actual preferable previous	The operational status of the database. <i>This element is always shown.</i>

name	Type	Description
	failed not-useful) Possible values: - actual : actual oper status - preferable : preferable oper status - previous : previous oper status - failed : failed oper status - not-useful : not useful oper status	
version	Parameter type: <SwMngt::dbmDatabaseVersion> - a printable string - length: x<=32	The version of the database. <i>This element is always shown.</i>

136.3 Disk Status Command

Command Description

This command displays the values of the various attributes of the SWM disk file.

User Level

The command can be accessed by operators with software management privileges.

Command Syntax

The command has the following syntax:

> show software-mngt descriptor-files [(index)]

Command Parameters

Table 136.3-1 "Disk Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - path and name of the oswp ,file name less than 160 char - range: [a-zA-Z0-9-_/.*] - length: 1<=x<=160	index to the swm disk file table

Command Output

Table 136.3-2 "Disk Status Command" Display parameters

Specific Information		
name	Type	Description
type	Parameter type: <SwMngt::diskFileType> (overall-descriptor descriptor file-type-a file-type-b not-specified file-type-c file-type-d file-type-e file-type-f file-type-g file-type-h file-type-i file-type-j file-type-k file-type-l file-type-m file-type-n	Specifies the type of the file. <i>This element is always shown.</i>

name	Type	Description
	file-type-o file-type-p file-type-s file-type-v) Possible values: - overall-descriptor : over all descriptor file - descriptor : descriptor file - file-type-a : file type a - file-type-b : file type b - not-specified : file type not specified - file-type-c : file type c - file-type-d : file type d - file-type-e : file type e - file-type-f : file type f - file-type-g : file type g - file-type-h : file type h - file-type-i : file type i - file-type-j : file type j - file-type-k : file type k - file-type-l : file type l - file-type-m : file type m - file-type-n : file type n - file-type-o : file type o - file-type-p : file type p - file-type-s : file type s - file-type-v : file type v	
file-size	Parameter type: <SwMngt::DiskFileSize> - specifies the size of the file - unit: bytes	Specifies the size of the file. <i>This element is always shown.</i>

136.4 Overall Software Package Status Command

Command Description

This command displays various OSWP states and attributes.

User Level

The command can be accessed by operators with software management privileges.

Command Syntax

The command has the following syntax:

```
> show software-mngt oswp [ (index) ]
```

Command Parameters

Table 136.4-1 "Overall Software Package Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - id of one of the two oswps - range: [1...2]	index to the swm oswp table

Command Output

Table 136.4-2 "Overall Software Package Status Command" Display parameters

Specific Information		
name	Type	Description
name	Parameter type: <SwMngt::swmOswpName> - The name of OSWP without path - range: [a-zA-Z0-9-_/:*] - length: 1<=x<=160	The name of OSWP without path <i>This element is always shown.</i>
availability	Parameter type: <SwMngt::operAvailStatus> (empty enabled disabled downloading aborting) Possible values: - empty : no OSWP is related to the index - enabled : related OSWP is valid - disabled : download of related OSWP failed - downloading : download of related OSWP is ongoing - aborting : files of the related OSWP are removed	Specifies the availability status of the OSWP. <i>This element is always shown.</i>
act-status	Parameter type: <SwMngt::operActStatus> (active	Specifies the related OSWP is currently active, not active or

name	Type	Description
	not-active act-act-nt act-stb-nt) Possible values: - active : related OSWP is active - not-active : related OSWP is not active - act-act-nt : related OSWP is being activated on the active NT - act-stb-nt : related OSWP is being activated on the standby NT	being activated on active or standby NT. <i>This element is always shown.</i>
commit-status	Parameter type: <SwMngt::operCommitStatus> (committed un-committed committing) Possible values: - committed : Committed - un-committed : Un committed - committing : OSWP is committing	Specifies the OSWP is committed or uncommitted or whether the commit-operation is still ongoing. <i>This element is always shown.</i>
download-error	Parameter type: <SwMngt::oswpDldErr> (invalidftpdaemon invalidftpdaemon invalidsftpdaemon not-defined file-not-found access-violation diskfull-alloc-exced illegal-tftp-operation unknown-transfer-id file-exists no-such-user syntax-error lack-of-storage system-restart no-error synchronization-failed tftp-busy swload-verify-fail crc-verify-fail) Possible values: - invalidftpdaemon : trying to download using ftp when sftp is enabled - invalidtftpdaemon : trying to download using tftp when sftp is enabled - invalidsftpdaemon : trying to download using sftp when tftp is enabled - not-defined : the error is not defined - file-not-found : file is not found - access-violation : access violation - diskfull-alloc-exced : disk is full - illegal-tftp-operation: illegal TFTP operation - unknown-transfer-id : transfer id is unknown - file-exists : file is already existing - no-such-user : no such user - syntax-error : Syntax error - lack-of-storage : Lack of storage resource - system-restart : system restart - no-error : no error in download	Specifies for what reason the download of the OSWP failed for the requested set of files. <i>This element is only shown in detail mode.</i>

name	Type	Description
	- synchronization-failed: synchronization failed - tftp-busy : tftp client is occupied by other task - swload-verify-fail : swload validation failed after successful download - crc-verify-fail : crc validation failed after successful download	
err-file-name	Parameter type: <SwMngt::oswpName> - path and name of the oswp ,file name less than 160 char - range: [a-zA-Z0-9-_/.*] - length: 1<=x<=160	The name of the file that caused the error. <i>This element is only shown in detail mode.</i>
err-file-server	Parameter type: <SwMngt::serverIdv6> (<Ip::V4Address> ipv6 : <Ip::InetAddressType>) Possible values: - ipv6 : Ipv6 address (only for management IPv6 supported boards) Field type <Ip::V4Address> - IPv4-address Field type <Ip::InetAddressType> - IPv6 address	Specifies the IP address of the file server where the file can be found. <i>This element is only shown in detail mode.</i>
auto-activate-error	Parameter type: <SwMngt::OswpAutoActErr> (not-defined no-error another-swdb-on no-compatible-db unknown-err) Possible values: - not-defined : the error is not defined - no-error : no error in download - another-swdb-on : another swdb process ongoing - no-compatible-db : no compatible database - unknown-err : unknown error during activation	the reason the automatic activation of the OSWP failed <i>This element is only shown in detail mode.</i>
on-schedule-act-time	Parameter type: <Sys::TimeIOInMinsRef1970> - the time (yyyy-mm-dd:hour:minutes)	the on-schedule activation time of OSWP, range:[1970-01-01:00:00:00,2035-12-31-12-31] <i>This element is only shown in detail mode.</i>
on-schedule-act-status	Parameter type: <SwMngt::OswpOnScheduleTreatedStatus> (unplanned planned activate-triggered activate-aborted) Possible values: - unplanned : on-schedule activation not planned - planned : on-schedule activation planned - activate-triggered : last on-schedule activation triggered - activate-aborted : last on-schedule activation aborted	the status of on-schedule activation of OSWP <i>This element is only shown in detail mode.</i>

136.5 Software Management Upgrade Plan

Command

Command Description

Views the upgrade plan with the list of planned boards to be upgraded chronologically, depending on the software replacement mode. The output won't change once an OSWP is activated.

User Level

The command can be accessed by operators with software management privileges.

Command Syntax

The command has the following syntax:

```
> show software-mngt upgrade-plan [ phase <SignedInteger> ] [ slot <Equipm::NtLtSlotIndex> ]
```

Command Parameters

Table 136.5-1 "Software Management Upgrade Plan Command" Resource Parameters

Resource Identifier	Type	Description
phase	Parameter type: <SignedInteger> Format: - a signed integer	The phase id
slot	Parameter type: <Equipm::NtLtSlotIndex> Format: (lt : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> nt-a nt-b nt <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::EqSlotId>) Possible values: - lt : lt-slot - nt-a : nt-a slot - nt-b : nt-b slot - nt : nt slot Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::EqSlotId> - the equipment slot number	The slot id within the phase

Command Output

Table 136.5-2 "Software Management Upgrade Plan Command" Display parameters

Specific Information		
name	Type	Description
planned-type	Parameter type: <Equipm::BrdType> Data driven field type Possible values are depending on the actual configuration and software. The currently allowed values can be shown with online-help.	The actual type of the board <i>This element is always shown.</i>
upgrade-action	Parameter type: <SwMgnt::UpgradePlanUpgradeAction> (preloading-lts via-standby-nt via-active-nt) Possible values: - preloading-lts : NT is preloading the LT board(s) - via-standby-nt : This board will be upgraded via the standby NT - via-active-nt : This board will be upgraded via the active NT	The action associated with this entry <i>This element is always shown.</i>
protected-ports	Parameter type: <SignedInteger> - a signed integer	The number of protected ports for the slot <i>This element is always shown.</i>

136.6 Software Management Upgrade Status Command

Command Description

Views the status table of the list of planned boards in chronological order with its upgrade status, during or after OSWP activation.

User Level

The command can be accessed by operators with software management privileges.

Command Syntax

The command has the following syntax:

```
> show software-mngt upgrade-status [ phase <SignedInteger> ] [ slot <Equipm::NtLtSlotIndex> ]
```

Command Parameters

Table 136.6-1 "Software Management Upgrade Status Command" Resource Parameters

Resource Identifier	Type	Description
phase	Parameter type: <SignedInteger> Format: - a signed integer	The phase id
slot	Parameter type: <Equipm::NtLtSlotIndex> Format: (lt : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> nt-a nt-b nt <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::EqSlotId>) Possible values: - lt : lt-slot - nt-a : nt-a slot - nt-b : nt-b slot - nt : nt slot Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::EqSlotId> - the equipment slot number	The slot id within the phase

Command Output

Table 136.6-2 "Software Management Upgrade Status Command" Display parameters

Specific Information		
name	Type	Description
planned-type	Parameter type: <Equipm::BrdType> Data driven field type Possible values are depending on the actual configuration and software. The currently allowed values can be shown with online-help.	The actual type of the board <i>This element is always shown.</i>
upgrade-action	Parameter type: <SwMgmt::UpgradeStatusUpgradeAction> (preloading-lts via-standby-nt via-active-nt) Possible values: - preloading-lts : NT is preloading the LT board(s) - via-standby-nt : This board will be upgraded via the standby NT - via-active-nt : This board will be upgraded via the active NT	The action associated with this entry <i>This element is always shown.</i>
protected-ports	Parameter type: <SignedInteger> - a signed integer	The number of protected ports for the slot <i>This element is always shown.</i>
upgrade-state	Parameter type: <SwMgmt::UpgradeStatusUpgradeState> (not-started ongoing failed completed) Possible values: - not-started : The upgrade actions still need to start - ongoing : The upgrade action for this board is ongoing - failed : The upgrade of this board has finished with error - completed : The upgrade of this board has finished	The current state of the board <i>This element is always shown.</i>

136.7 Software Package Status Command

Command Description

This command displays the parameters of the dynamic SWP table, which represent the SWPs that belong to at least one of the OSWPs available in the system.

User Level

The command can be accessed by operators with software management privileges.

Command Syntax

The command has the following syntax:

```
> show software-mngt swp [ (name) ]
```

Command Parameters

Table 136.7-1 "Software Package Status Command" Resource Parameters

Resource Identifier	Type	Description
(name)	Format: - a printable string - length: x<=32	index to the swm-swp table

Command Output

Table 136.7-2 "Software Package Status Command" Display parameters

Specific Information		
name	Type	Description
type	Parameter type: <SwMngt::swmSwpType> (asam-core voice-gateway ip-server) Possible values: - asam-core : asam core - voice-gateway : voice gateway - ip-server : ip server	Specifies the type of the software package. <i>This element is always shown.</i>
dbase-ver-no	Parameter type: <SwMngt::dBVersionNumber> - a printable string - length: x<=32	Specifies the version number of the database that is compatible with the software package. <i>This element is always shown.</i>
primary-file-id	Parameter type: <SwMngt::serverIdv6> (<Ip::V4Address> ipv6 : <Ip::InetAddressType>) Possible values: - ipv6 : Ipv6 address (only for management IPv6 supported	Specifies the IP address of the TFTP/SFTP server where the software package can be found. <i>This element is always shown.</i>

name	Type	Description
	boards) Field type <Ip::V4Address> - IPv4-address Field type <Ip::InetAddressType> - IPv6 address	
secondary-file-id	Parameter type: <SwMngt::serverIdv6> (<Ip::V4Address> ipv6 : <Ip::InetAddressType>) Possible values: - ipv6 : IPv6 address (only for management IPv6 supported boards) Field type <Ip::V4Address> - IPv4-address Field type <Ip::InetAddressType> - IPv6 address	Specifies the IP address of a possible second TFTP/SFTP server where the software package can be found. <i>This element is always shown.</i>

136.8 File Status Command

Command Description

This command displays information about the relationships between the files known by the system and the available OSWPs.

User Level

The command can be accessed by operators with software management privileges.

Command Syntax

The command has the following syntax:

```
> show software-mngt swp-disk-file [ (name) [ file-name <SwMngt::swpContainsFileName> ] [ file-board-type
<SwMngt::swpBoardType> ] ]
```

Command Parameters

Table 136.8-1 "File Status Command" Resource Parameters

Resource Identifier	Type	Description
(name)	Format: - a printable string - length: x<=32	index to the Swm_Contains_File table
file-name	Parameter type: <SwMngt::swpContainsFileName> Format: - a printable string - length: x<=32	index to the Swm_Contains_File table
file-board-type	Parameter type: <SwMngt::swpBoardType> Format: - a printable string - length: x<=21	index to the Swm_Contains_File table

Command Output

Table 136.8-2 "File Status Command" Display parameters

Specific Information		
name	Type	Description
file-format	Parameter type: <SwMngt::fileFormat> (tar lz77 ascii exe coff) Possible values: - tar : file format is tar	Specifies the format of the file. <i>This element is always shown.</i>

name	Type	Description
	- lz77 : file format is lz77 - ascii : file format is ascii - exe : file format is exe - coff : file format is coff	
available-status	Parameter type: <SwMngt::availableStatus> (available not-available) Possible values: - available : the file is available - not-available : the file is not available	Specifies whether the file is available on the file disk or not. <i>This element is always shown.</i>
file-priority	Parameter type: <SwMngt::filePriority> (part-min-set no-part-min-set) Possible values: - part-min-set : part min set - no-part-min-set : no part min set	Specifies whether the file belongs to the minimum set of the related OSWPs. <i>This element is only shown in detail mode.</i>
file-size	Parameter type: <SwMngt::SwmFileSize> - specifies the size of the file - unit: bytes	Specifies the size of the file. <i>This element is only shown in detail mode.</i>
file-type	Parameter type: <SwMngt::SwmFileType> (special-file file-type-a file-type-b) Possible values: - special-file : special file type - file-type-a : file type A - file-type-b : file type B	Specifies the type of the file. <i>This element is only shown in detail mode.</i>
file-decompression	Parameter type: <SwMngt::swmFileDecompression> (decompressed no-decompressed) Possible values: - decompressed : file is decompressed - no-decompressed : file is compressed	Specifies whether the file must be decompressed or not before being sent to the applicable boards. <i>This element is only shown in detail mode.</i>

136.9 Upload/Download Status Command

Command Description

This command displays the upload and download parameters.

User Level

The command can be accessed by operators with software management privileges.

Command Syntax

The command has the following syntax:

> show software-mngt upload-download

Command Output

Table 136.9-2 "Upload/Download Status Command" Display parameters

Specific Information		
name	Type	Description
disk-space	Parameter type: <SwMngt::TotalSpaceOnDisk> - total space on file disk that is reserved for storage - unit: bytes	The total space on the file disk that is reserved for the storage of files. <i>This element is always shown.</i>
free-space	Parameter type: <SwMngt::FreeSpaceOnDisk> - total space on the file disk that is still available - unit: bytes	Specifies the space on the file disk that is still available for the storage of files. <i>This element is always shown.</i>
download-progress	Parameter type: <SwMngt::downloadProgress> (download-ongoing download-success download-fail) Possible values: - download-ongoing : download ongoing - download-success : download finished and successfull - download-fail : download finished but failed	Specifies the current status of the database download process. <i>This element is always shown.</i>
download-error	Parameter type: <SwMngt::downloadError> (not-defined file-not-found access-violation diskfull-alloc-exced illegal-tftp-operation unknown-transfer-id file-exists no-such-user corrupted-database system-restart no-error	Specifies the reason in case of a database download failure. <i>This element is always shown.</i>

name	Type	Description
	iss-cksm-fail issprot-cksm-fail another-swdb-on tftp-busy) Possible values: - not-defined : the error is not defined - file-not-found : file is not found - access-violation : access violation - diskfull-alloc-exced : disk is full - illegal-tftp-operation: illegal TFTP operation - unknown-transfer-id : transfer id is unknown - file-exists : file is already existing - no-such-user : no such user - corrupted-database : corrupted/incompleted database - system-restart : system restart - no-error : no error in download - iss-cksm-fail : checksum-failed for iss.conf - issprot-cksm-fail : checksum-failed for issprot.conf - another-swdb-on : another swdb progress ongoing - tftp-busy : tftp client is occupied by other task	
upload-progress	Parameter type: <SwMngt::uploadProgress> (upload-ongoing upload-success upload-fail) Possible values: - upload-ongoing : upload ongoing - upload-success : upload finished and successfull - upload-fail : upload finished but failed	Specifies the current status of the database upload process. <i>This element is always shown.</i>
upload-error	Parameter type: <SwMngt::uploadError> (not-defined file-not-found access-violation diskfull-alloc-exced illegal-tftp-operation unknown-transfer-id file-exists no-such-user database-not-avail system-restart no-error another-swdb-on authentication-failed tftp-busy) Possible values: - not-defined : the error is not defined - file-not-found : file is not found - access-violation : access violation - diskfull-alloc-exced : disk is full - illegal-tftp-operation: illegal TFTP operation - unknown-transfer-id : transfer id is unknown - file-exists : file is already existing - no-such-user : no such user - database-not-avail : selected database not available - system-restart : system restart - no-error : no error in download - another-swdb-on : another swdb progress ongoing - authentication-failed : authentication failed	Specifies the reason in case of a database upload failure. <i>This element is always shown.</i>

name	Type	Description
	- tftp-busy : tftp client is occupied by other task	
auto-activate-error	Parameter type: <SwMngt::DbAutoActErr> (not-defined no-error another-swdb-on no-compat-oswp unknown-err) Possible values: - not-defined : the error is not defined - no-error : no error in download - another-swdb-on : another swdb process ongoing - no-compat-oswp : no compatible OSWP - unknown-err : unknown error during activation	the reason the automatic activation of the Database failed <i>This element is always shown.</i>

136.10 Upload/Download Sub-directory Status Command

Command Description

This command displays the upload and download parameters.

User Level

The command can be accessed by operators with software management privileges.

Command Syntax

The command has the following syntax:

```
> show software-mngt upload-download-dir
```

136.11 Software Version For ANSI Status Command

Command Description

This command shows the Software version for ANSI market.

User Level

The command can be accessed by operators with software management privileges.

Command Syntax

The command has the following syntax:

> show software-mngt version ansi

Command Output

Table 136.11-2 " Software Version For ANSI Status Command " Display parameters

Specific Information		
name	Type	Description
isam-feature-group	Parameter type: <SwMngt::swAnsiVersion> - the ANSI market version - length: x<=50	the ansi market version <i>This element is always shown.</i>

136.12 Software Version For ETSI Status Command

Command Description

This command shows the Software version for ETSI market.

User Level

The command can be accessed by operators with software management privileges.

Command Syntax

The command has the following syntax:

> show software-mngt version etsi

Command Output

Table 136.12-2 "Software Version For ETSI Status Command" Display parameters

Specific Information		
name	Type	Description
isam-release	Parameter type: <SwMngt::swEtsiVersion> - the ETSI market version - length: x<=50	the ETSI market version <i>This element is always shown.</i>

136.13 TLS CA file download Status Command

Command Description

This command displays the TLS CA file and download status.

User Level

The command can be accessed by operators with software management privileges.

Command Syntax

The command has the following syntax:

```
> show software-mngt tls-cafile [ (tls-cafile-name) ]
```

Command Parameters

Table 136.13-1 "TLS CA file download Status Command" Resource Parameters

Resource Identifier	Type	Description
(tls-cafile-name)	Format: - string representing the TLS CA file name - length: 1<=x<=13	name of TLS CA file

Command Output

Table 136.13-2 "TLS CA file download Status Command" Display parameters

Specific Information		
name	Type	Description
index	Parameter type: <SwMngt::CAFileIndex> - the TLS CA file table index - range: [1...16]	show index of TLS CA file <i>This element is always shown.</i>
download-progress	Parameter type: <SwMngt::downloadProgress> (download-ongoing download-success download-fail) Possible values: - download-ongoing : download ongoing - download-success : download finished and successfull - download-fail : download finished but failed	show progress of downloading TLS CA file <i>This element is always shown.</i>
download-error	Parameter type: <SwMngt::CAFileDldError> (not-defined file-not-found access-violation diskfull-alloc-exced illegal-tftp-operation unknown-transfer-id	specifies the reason in case of a tls ca file download failure <i>This element is always shown.</i>

name	Type	Description
	no-such-user cafile-error wrong-cafile-size connection-time-out no-error) Possible values: - not-defined : the error is not defined - file-not-found : file is not found - access-violation : access violation - diskfull-alloc-exced : disk is full - illegal-tftp-operation: illegal TFTP operation - unknown-transfer-id : transfer id is unknown - no-such-user : no such user - cafile-error : TLS CA file error - wrong-cafile-size : wrong CA file size - connection-time-out : connection time out - no-error : no error in download	
active-status	Parameter type: <SwMngt::CAFileStatus> (new activated) Possible values: - new : The active-status of TLS CA file is new - activated : The active-status of TLS CA file is activated	show active-status of TLS CA file activated <i>This element is always shown.</i>

136.14 Lightspan Migration Status Command

Command Description

This command shows the status of Lightspan Migration Status.

User Level

The command can be accessed by operators with software management privileges.

Command Syntax

The command has the following syntax:

```
> show software-mngt ls-migration
```

Command Output

Table 136.14-2 "Lightspan Migration Status Command" Display parameters

Specific Information		
name	Type	Description
package	Parameter type: <SwMngt::lsMigrPkgFile> - name - length: 1<=x<=256	the status of the migration package <i>This element is always shown.</i>
package-status	Parameter type: <SwMngt::lsMigrPkgStatus> (idle downloading invalid download-complete) Possible values: - idle : package file download idle - downloading : package file downloading - invalid : package file invalid - download-complete : package file download complete	the status of the migration package <i>This element is always shown.</i>
default-config	Parameter type: <SwMngt::lsMigrConfigFile> - name - length: 1<=x<=256	the status of default config file <i>This element is always shown.</i>
default-config-status	Parameter type: <SwMngt::lsMigrConfigFileStatus> (idle downloading invalid download-complete) Possible values: - idle : config file download idle - downloading : config file downloading - invalid : config file invalid - download-complete : config file downloadcomplete	the status of default config file <i>This element is always shown.</i>
migration-status	Parameter type: <SwMngt::lsMigrStatus> (not-ready	the status of migration status <i>This element is always shown.</i>

136 Software Status Commands

name	Type	Description
	ready activating activating-failed) Possible values: - not-ready : lightspan migration not ready - ready : lightspan migration ready - activating : lightspan migration activating - activating-failed : lightspan migration activating failed	

136.15 lacm OAM DB save Status Command

Command Description

This command displays the progress of lacm OAM DB save.

User Level

The command can be accessed by operators with software management privileges.

Command Syntax

The command has the following syntax:

```
> show software-mngt oam-save-protected
```

Command Output

Table 136.15-2 "Iacm OAM DB save Status Command" Display parameters

Specific Information		
name	Type	Description
oam-save-progress	Parameter type: <SwMngt::oamSaveProgress> (oam-save-ongoing oam-save-success oam-save-fail) Possible values: - oam-save-ongoing : oam save ongoing - oam-save-success : oam save finished and successfull - oam-save-fail : oam save finished but failed	Specifies the current status of oam db save process. <i>This element is always shown.</i>
oam-save-error	Parameter type: <SwMngt::oamSaveError> (no-error db-size-exceed dm-dir-null db-internal-err swm-busy sync-busy) Possible values: - no-error : no error - db-size-exceed : oam db size exceeds 10M bytes - dm-dir-null : dm directory is NULL - db-internal-err : dm internal error - swm-busy : swm busy - sync-busy : db sync busy	Specifies the error in case of oam db save failure. <i>This element is always shown.</i>

136.16 Upload/Download Sw ONTSw Status

Command

Command Description

This command displays the upload and download parameters.

User Level

The command can be accessed by operators with software management privileges.

Command Syntax

The command has the following syntax:

> show software-mngt upload-download-info

Command Output

Table 136.16-2 "Upload/Download Sw ONTSw Status Command" Display parameters

Specific Information		
name	Type	Description
free-sw-space	Parameter type: <SwMngt::FreeSpaceOnSwDisk> - total space on the file Sw disk that is still available - unit: bytes	Specifies the space on the file /Sw disk that is still available for the storage of files. <i>This element is always shown.</i>
free-ontsw-space	Parameter type: <SwMngt::FreeSpaceOnONTSwDisk> - total space on the file ONTSw disk that is still available - unit: bytes	Specifies the space on the file /ONT/SW disk that is still available for the storage of files. <i>This element is always shown.</i>

137- Software Load Validation Commands

137.1 Software Load Validation Command Tree	137-6138
137.2 Overall Software Load Validation Status Command	137-6139
137.3 Software Load Validation Root Certificate Display Command	137-6141
137.4 Software Load Validation Status of SWP files Command	137-6142

137.1 Software Load Validation Command Tree

Description

This chapter gives an overview of nodes that are handled by "Software Load Validation Commands".

Command Tree

```
----show
  ----software-mngt
    ----sw-load-valid
      ----oswp-status
        - (index)
      ----oswp-root-certificate
        - (index)
      ----file-status
        - (name)
        - file-name
        - file-board-type
```

137.2 Overall Software Load Validation Status Command

Command Description

This command displays various Sw Load Validation states and attributes of OSWP.

User Level

The command can be accessed by operators with software management privileges.

Command Syntax

The command has the following syntax:

```
> show software-mngt sw-load-valid oswp-status [ (index) ]
```

Command Parameters

Table 137.2-1 "Overall Software Load Validation Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - id of one of the two oswps - range: [1...2]	index to the swm oswp table

Command Output

Table 137.2-2 "Overall Software Load Validation Status Command" Display parameters

Specific Information		
name	Type	Description
name	Parameter type: <SwMngt::swmOswpName> - The name of OSWP without path - range: [a-zA-Z0-9-_/.*] - length: 1<=x<=160	The name of OSWP without path <i>This element is always shown.</i>
status	Parameter type: <SwMngt::SwLoadValidStatus> (not-executed success failure in-progress) Possible values: - not-executed : SW Load Validation is not executed - success : SW Load Validation success - failure : SW Load Validation failed - in-progress : SW Load Validation in-progress	OSWP Sw Load Validation Status <i>This element is always shown.</i>
error-info	Parameter type: <SwMngt::SwLoadErrInfo>	OSWP Sw Load Validation Error

137 Software Load Validation Commands

name	Type	Description
	- string representing sw load validation error information - length: $1 \leq x \leq 12$	Information <i>This element is always shown.</i>

137.3 Software Load Validation Root Certificate

Display Command

Command Description

This command displays root certificate used for Sw Load Validation of OSWP. An Copy of this certificate shall be obtained on request from Nokia for verification. Nokia shall share this through a digitally signed e-mail

User Level

The command can be accessed by operators with software management privileges.

Command Syntax

The command has the following syntax:

```
> show software-mngt sw-load-valid oswp-root-certificate [ (index) ]
```

Command Parameters

Table 137.3-1 "Software Load Validation Root Certificate Display Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - id of one of the two oswps - range: [1...2]	index to the swm oswp table

Command Output

Table 137.3-2 "Software Load Validation Root Certificate Display Command" Display parameters

Specific Information		
name	Type	Description
root-certificate	Parameter type: <PrintableString> - printable string	content of OSWP root certificate <i>This element is only shown in detail mode.</i>

137.4 Software Load Validation Status of SWP files Command

Command Description

This command displays Sw Load Validation status for individual files of SWP.

User Level

The command can be accessed by operators with software management privileges.

Command Syntax

The command has the following syntax:

```
> show software-mngt sw-load-valid file-status [ (name) [ file-name <SwMngt::swpContainsFileName> ] [
file-board-type <SwMngt::swpBoardType> ] ]
```

Command Parameters

Table 137.4-1 "Software Load Validation Status of SWP files Command" Resource Parameters

Resource Identifier	Type	Description
(name)	Format: - a printable string - length: x<=32	index to the Swm_Contains_File table
file-name	Parameter type: <SwMngt::swpContainsFileName> Format: - a printable string - length: x<=32	index to the Swm_Contains_File table
file-board-type	Parameter type: <SwMngt::swpBoardType> Format: - a printable string - length: x<=21	index to the Swm_Contains_File table

Command Output

Table 137.4-2 "Software Load Validation Status of SWP files Command" Display parameters

Specific Information		
name	Type	Description
verify-status	Parameter type: <SwMngt::verifyStatus> (success failure in-progress not-executed not-applicable)	Specifies whether the file is digitally verified. <i>This element is always shown.</i>

name	Type	Description
	Possible values: - success : the digital file verification succeeded - failure : the digital file verification failed - in-progress : the digital file verification is in-progress - not-executed : the digital file verification is not executed - not-applicable : the digital file verification is not applicable for type-s file or non own board NT files	
available-status	Parameter type: <SwMngt::availableStatus> (available not-available) Possible values: - available : the file is available - not-available : the file is not available	Specifies whether the file is available on the file disk or not. <i>This element is always shown.</i>

138- CDE Status Commands

138.1 CDE Status Command Tree	138-6145
138.2 CDE download Status Command	138-6146

138.1 CDE Status Command Tree

Description

This chapter gives an overview of nodes that are handled by "CDE Status Commands".

Command Tree

```
----show
  ----software-mngt
    ----cdeprof
      ----dldstatus
```

138.2 CDE download Status Command

Command Description

This command displays the CDE profile and download status.

User Level

The command can be accessed by operators with software management privileges.

Command Syntax

The command has the following syntax:

> show software-mngt cdeprof dldstatus

Command Output

Table 138.2-2 "CDE download Status Command" Display parameters

Specific Information		
name	Type	Description
server-ip	Parameter type: <SwMngt::serverId> - IPv4-address	show file server Ip address <i>This element is always shown.</i>
path	Parameter type: <SwMngt::cdePath> - path for the cde(example: /path_to_cde/file_name) - range: [a-zA-Z0-9-_/():] - length: 1<=x<=128	show the cde file downloading path <i>This element is always shown.</i>
download-progress	Parameter type: <SwMngt::CDETarDldProgress> (download-ongoing download-success download-fail) Possible values: - download-ongoing : download ongoing - download-success : download finished and successfull - download-fail : download finished but failed	show the cde file download progress <i>This element is always shown.</i>
download-error	Parameter type: <SwMngt::CDETarDldError> (not-defined file-not-found access-violation diskfull-alloc-exced illegal-tftp-operation no-such-user file-name-error corrupted-cde server-ip-error cde-file-error no-error) Possible values: - not-defined : the error is not defined	specifies the reason in case of a cde download failure <i>This element is always shown.</i>

name	Type	Description
	- file-not-found : file is not found - access-violation : access violation - diskfull-alloc-exced : disk is full - illegal-tftp-operation: illegal TFTP operation - no-such-user : no such user - file-name-error : the CDE profile name error - corrupted-cde : corrupted/incompleted CDE profile - server-ip-error : input the server ip address - cde-file-error : CDE file error - no-error : no error in download	

139- IGMP Status Commands

139.1 IGMP Status Command Tree	139-6149
139.2 IGMP System Status Command	139-6150
139.3 IGMP Channel Sources Status Command	139-6152
139.4 IGMP Channel Miscellaneous Status Command	139-6155
139.5 IGMP Channel Protocol Status Command	139-6158
139.6 IGMP package to multicast source Command	139-6162
139.7 IGMP Group to Package Status Command	139-6163
139.8 Show Multicast Source Statistics Command	139-6164
139.9 Show Multicast Channel Statistics Command	139-6166
139.10 IGMP Module Counter Status Command	139-6168
139.11 IGMP Module Time Status Command	139-6171
139.12 IGMP Module Miscellaneous Status Command	139-6173
139.13 IGMP System Status Command	139-6175

139.1 IGMP Status Command Tree

Description

This chapter gives an overview of nodes that are handled by "IGMP Status Commands".

Command Tree

```

----show
  ----igmp
    ----system
    ----channel
      ----counter
        - (port)
      ----miscellaneous
        - (port)
      ----protocol
        - (port)
    ----package-to-src
      - (package-id)
    ----grp-to-package
      - (grp-ip-addr)
      - src-ip-addr
      - vlan-id
    ----X module-mcast-src
      - (slot)
      - mcast-addr
    ----module-mcast-channel
      - (slot)
      - grp-ip-addr
      - src-ip-addr
      - vlan-id
    ----module
      ----counter
        - (slot-index)
      ----time
        - (slot-index)
      ----miscellaneous
        - (slot-index)
    ----mcast-svc-context

```

139.2 IGMP System Status Command

Command Description

This command displays the IGMP system-related parameters.

User Level

The command can be accessed by operators with igmp privileges.

Command Syntax

The command has the following syntax:

```
> show igmp system
```

Command Output

Table 139.2-2 "IGMP System Status Command" Display parameters

Specific Information		
name	Type	Description
startup-query-intvl	Parameter type: <Igmp::SysStartUpQueryInt> - interval at which general membership queries transmitted - unit: sec - range: [1...3175]	The interval between general membership queries sent on startup. <i>This element is always shown.</i>
startup-query-count	Parameter type: <Igmp::SystemStartupQueryCount> - queries sent out on startup separated by query interval - range: [1...10]	The number of queries sent out on startup separated by the query interval. <i>This element is always shown.</i>
stats-intvl	Parameter type: <Igmp::McastSrcPeakTime> - the time (yyyy-mm-dd:hour:minutes:secs) - unit: UTC	This statistics indicates the network time of when the system-wide statistics were last reset. <i>This element is always shown.</i>
src-ipaddr	Parameter type: <Ip::V4Address> - IPv4-address	This object specifies the source IP address which is contained in every multicast IP datagrams transmitted on all IGMP control channels. <i>This element is always shown.</i>
router-present-timeout	Parameter type: <SignedInteger> - a signed integer	When the system acts as host on the network side of the IGMP proxy, this value is the time how long the system shall wait after hearing a Version 1 Query before it shall send any IGMPv2 messages. <i>This element is always shown.</i>
grp-memb-intvl	Parameter type: <SignedInteger>	The interval that must pass before

name	Type	Description
	- a signed integer	the system decides there are no more members of a group on a network. <i>This element is always shown.</i>

139.3 IGMP Channel Sources Status Command

Command Description

This command displays the IGMP channel source.

User Level

The command can be accessed by operators with igmp privileges.

Command Syntax

The command has the following syntax:

```
> show igmp channel counter [ (port) ]
```

Command Parameters

Table 139.3-1 "IGMP Channel Sources Status Command" Resource Parameters

Resource Identifier	Type	Description
(port)	Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::VpiId> : <Eqpt::VciId> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::VpiId> : <Eqpt::VciId> : <Eqpt::UnstackedVlan> vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::UnstackedVlan> vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::VpiId> : <Eqpt::VciId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> / <Eqpt::OntPortId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> / <Eqpt::OntPortId> : <Eqpt::UnstackedVlan> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> / <Eqpt::OntPortId> vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / voip : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> /	identification of the port, vlanport or virtual channel

Resource Identifier	Type	Description
	<code><Eqpt::PonId> / <Eqpt::OntId> / vuni : stacked :</code> <code><Eqpt::SVlan> : <Eqpt::CVlan></code> <code> vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> /</code> <code><Eqpt::PonId> / <Eqpt::OntId> / voip :</code> <code><Eqpt::UnstackedVlan></code> <code> vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> /</code> <code><Eqpt::PonId> / <Eqpt::OntId> / vuni :</code> <code><Eqpt::UnstackedVlan></code> <code> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> /</code> <code><Eqpt::PonId> / <Eqpt::OntId> / voip</code> <code> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> /</code> <code><Eqpt::PonId> / <Eqpt::OntId> / vuni</code> <code> vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> /</code> <code><Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::LLId> : stacked :</code> <code><Eqpt::SVlan> : <Eqpt::CVlan></code> <code> vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> /</code> <code><Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::LLId> :</code> <code><Eqpt::UnstackedVlan></code> <code> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> /</code> <code><Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::LLId></code> <code> vlan:ng2 : <Eqpt::ChannelGroupId> /</code> <code><Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> /</code> <code><Eqpt::Ng2OntSlotId> / <Eqpt::Ng2OntPortId> : stacked :</code> <code><Eqpt::SVlan> : <Eqpt::CVlan></code> <code> vlan:ng2 : <Eqpt::ChannelGroupId> /</code> <code><Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> /</code> <code><Eqpt::Ng2OntSlotId> / <Eqpt::Ng2OntPortId> :</code> <code><Eqpt::UnstackedVlan>)</code> Possible values: - vlan : vlan port - vlan:ng2 : ngpon2 vlan port Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number Field type <Eqpt::VpiId> - atm VPI Field type <Eqpt::VciId> - atm VCI Field type <Eqpt::PonId> - the PON identifier Field type <Eqpt::ChannelGroupId> - the channel group identifier Field type <Eqpt::SubChannelGroupId> - the subchannel group identifier Field type <Eqpt::Ng2OntId> - the NG2 ONT identifier Field type <Eqpt::OntId> - the ONT identifier Possible values: - voip : virtual uni identifier obsolete alternative replaced by vuni - vuni : virtual uni identifier	

Resource Identifier	Type	Description
	Possible values: - vuni : virtual NGPON2 uni identifier Field type <Eqpt::OntSlotId> - the ONT SLOT identifier Field type <Eqpt::OntPortId> - the ONT PORT identifier Field type <Eqpt::Ng2OntSlotId> - the NGPON2 ONT SLOT identifier Field type <Eqpt::Ng2OntPortId> - the NGPON2 ONT PORT identifier Field type <Eqpt::LLId> - the LLID identifier, range 1 for EPON, range 1-8 for DPOE Possible values: - stacked : stacked vlan identity Field type <Eqpt::UnstackedVlan> - unstacked vlan id Field type <Eqpt::SVlan> - service vlan id Field type <Eqpt::CVlan> - customer vlan id	

Command Output

Table 139.3-2 "IGMP Channel Sources Status Command" Display parameters

Specific Information		
name	Type	Description
noperm-join	Parameter type: <Counter> - 32 bit counter	no of times perm bitmap failure has occurred. <i>This element is always shown.</i>
bitrate-fail	Parameter type: <Counter> - 32 bit counter	no of times IGMP join message failed <i>This element is always shown.</i>
inval-classd	Parameter type: <Counter> - 32 bit counter	indicates the count of IP address states <i>This element is always shown.</i>
numsec-ovld-protappl	Parameter type: <Counter> - 32 bit counter	no of 1sec int for overload protection has been applied <i>This element is always shown.</i>
num-fail	Parameter type: <Counter> - 32 bit counter	Indicates the count of failure join <i>This element is always shown.</i>
sysnum-fail	Parameter type: <Counter> - 32 bit counter	Indicates the count of failure IGMP join <i>This element is always shown.</i>
sysrate-fail	Parameter type: <Counter> - 32 bit counter	Indicates the count of failure IGMP join because of low Bandwidth <i>This element is always shown.</i>

139.4 IGMP Channel Miscellaneous Status Command

Command Description

This command displays the IGMP channel source.

User Level

The command can be accessed by operators with igmp privileges.

Command Syntax

The command has the following syntax:

```
> show igmp channel miscellaneous [ (port) ]
```

Command Parameters

Table 139.4-1 "IGMP Channel Miscellaneous Status Command" Resource Parameters

Resource Identifier	Type	Description
(port)	Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::VpiId> : <Eqpt::VciId> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::VpiId> : <Eqpt::VciId> : <Eqpt::UnstackedVlan> vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::UnstackedVlan> vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::VpiId> : <Eqpt::VciId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> / <Eqpt::OntPortId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> / <Eqpt::OntPortId> : <Eqpt::UnstackedVlan> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> / <Eqpt::OntPortId> vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> /	identification of the port, vlanport or virtual channel

Resource Identifier	Type	Description
	<Eqpt::PonId> / <Eqpt::OntId> / voip : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / vuni : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / voip : <Eqpt::UnstackedVlan> vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / vuni : <Eqpt::UnstackedVlan> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / voip <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / vuni vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::LLId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::LLId> : <Eqpt::UnstackedVlan> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::LLId> vlan:ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / <Eqpt::Ng2OntSlotId> / <Eqpt::Ng2OntPortId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan:ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / <Eqpt::Ng2OntSlotId> / <Eqpt::Ng2OntPortId> : <Eqpt::UnstackedVlan>) Possible values: - vlan : vlan port - vlan:ng2 : ngpon2 vlan port Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number Field type <Eqpt::VpId> - atm VPI Field type <Eqpt::VciId> - atm VCI Field type <Eqpt::PonId> - the PON identifier Field type <Eqpt::ChannelGroupId> - the channel group identifier Field type <Eqpt::SubChannelGroupId> - the subchannel group identifier Field type <Eqpt::Ng2OntId> - the NG2 ONT identifier Field type <Eqpt::OntId> - the ONT identifier Possible values:	

Resource Identifier	Type	Description
	- voip : virtual uni identifier obsolete alternative replaced by vuni - vuni : virtual uni identifier Possible values: - vuni : virtual NGPON2 uni identifier Field type <Eqpt::OntSlotId> - the ONT SLOT identifier Field type <Eqpt::OntPortId> - the ONT PORT identifier Field type <Eqpt::Ng2OntSlotId> - the NGPON2 ONT SLOT identifier Field type <Eqpt::Ng2OntPortId> - the NGPON2 ONT PORT identifier Field type <Eqpt::LLId> - the LLID identifier,range 1 for EPON,range 1-8 for DPOE Possible values: - stacked : stacked vlan identity Field type <Eqpt::UnstackedVlan> - unstacked vlan id Field type <Eqpt::SVlan> - service vlan id Field type <Eqpt::CVlan> - customer vlan id	

Command Output

Table 139.4-2 "IGMP Channel Miscellaneous Status Command" Display parameters

Specific Information		
name	Type	Description
curr-num-group	Parameter type: <Gauge> - gauge	current group number in this port(ADSL,PVC) <i>This element is always shown.</i>
curr-preview-num	Parameter type: <Counter> - 32 bit counter	count of prev mcast grp that igmp channel joins currently <i>This element is always shown.</i>
curr-uncfg-num	Parameter type: <Counter> - 32 bit counter	current unconfig group number in this port(ADSL,PVC) <i>This element is always shown.</i>

139.5 IGMP Channel Protocol Status Command

Command Description

This command shows the IGMP protocol statistics for an IGMP channel

User Level

The command can be accessed by operators with igmp privileges.

Command Syntax

The command has the following syntax:

```
> show igmp channel protocol [ (port) ]
```

Command Parameters

Table 139.5-1 "IGMP Channel Protocol Status Command" Resource Parameters

Resource Identifier	Type	Description
(port)	Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::VpiId> : <Eqpt::VciId> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::VpiId> : <Eqpt::VciId> : <Eqpt::UnstackedVlan> vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::UnstackedVlan> vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::VpiId> : <Eqpt::VciId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> / <Eqpt::OntPortId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> / <Eqpt::OntPortId> : <Eqpt::UnstackedVlan> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> / <Eqpt::OntPortId> vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / voip : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> /	identification of the port, vlanport or virtual channel

Resource Identifier	Type	Description
	<Eqpt::PonId> / <Eqpt::OntId> / vuni : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / voip : <Eqpt::UnstackedVlan> vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / vuni : <Eqpt::UnstackedVlan> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / voip <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / vuni vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::LLId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::LLId> : <Eqpt::UnstackedVlan> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::LLId> vlan:ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / <Eqpt::Ng2OntSlotId> / <Eqpt::Ng2OntPortId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan:ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / <Eqpt::Ng2OntSlotId> / <Eqpt::Ng2OntPortId> : <Eqpt::UnstackedVlan>) Possible values: - vlan : vlan port - vlan:ng2 : ngpon2 vlan port Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number Field type <Eqpt::VpiId> - atm VPI Field type <Eqpt::VciId> - atm VCI Field type <Eqpt::PonId> - the PON identifier Field type <Eqpt::ChannelGroupId> - the channel group identifier Field type <Eqpt::SubChannelGroupId> - the subchannel group identifier Field type <Eqpt::Ng2OntId> - the NG2 ONT identifier Field type <Eqpt::OntId> - the ONT identifier Possible values: - voip : virtual uni identifier obsolete alternative replaced by vuni - vuni : virtual uni identifier	

Resource Identifier	Type	Description
	Possible values: - vuni : virtual NGPON2 uni identifier Field type <Eqpt::OntSlotId> - the ONT SLOT identifier Field type <Eqpt::OntPortId> - the ONT PORT identifier Field type <Eqpt::Ng2OntSlotId> - the NGPON2 ONT SLOT identifier Field type <Eqpt::Ng2OntPortId> - the NGPON2 ONT PORT identifier Field type <Eqpt::LLId> - the LLID identifier, range 1 for EPON, range 1-8 for DPOE Possible values: - stacked : stacked vlan identity Field type <Eqpt::UnstackedVlan> - unstacked vlan id Field type <Eqpt::SVlan> - service vlan id Field type <Eqpt::CVlan> - customer vlan id	

Command Output

Table 139.5-2 "IGMP Channel Protocol Status Command" Display parameters

Specific Information		
name	Type	Description
tx-gmq short name: tx/gmq	Parameter type: <Counter> - 32 bit counter	number of general queries transmitted on user interface <i>This element is always shown.</i>
tx-gsq short name: tx/gsq	Parameter type: <Counter> - 32 bit counter	number of group specific queries transmitted <i>This element is always shown.</i>
tx-gssq short name: tx/gssq	Parameter type: <Counter> - 32 bit counter	number of group-source specific queries transmitted <i>This element is always shown.</i>
rx-v1-req short name: rx-req/v1	Parameter type: <Counter> - 32 bit counter	number of V1 membership report received <i>This element is always shown.</i>
rx-v2-req short name: rx-req/v2	Parameter type: <Counter> - 32 bit counter	number of V2 membership report received <i>This element is always shown.</i>
rx-v3-req short name: rx-req/v3	Parameter type: <Counter> - 32 bit counter	number of V3 membership report received <i>This element is always shown.</i>
rx-v2-leaves	Parameter type: <Counter> - 32 bit counter	number of leave messages report received <i>This element is only shown in detail mode.</i>
rx-valid-message short name: rx-msg/ok	Parameter type: <Counter> - 32 bit counter	number of valid IGMP packets received <i>This element is always shown.</i>
rx-invalid-message short name: rx-msg/nok	Parameter type: <Counter> - 32 bit counter	number of invalid IGMP packets received <i>This element is always shown.</i>
rx-unknown-message short name:	Parameter type: <Counter> - 32 bit counter	number of unknown IGMP packets received

name	Type	Description
rx-msg/unknown		<i>This element is always shown.</i>
rx-bad-length	Parameter type: <Counter> - 32 bit counter	number of bad length IGMP packet received/dropped <i>This element is only shown in detail mode.</i>
rx-bad-ip-checksum	Parameter type: <Counter> - 32 bit counter	number of wrong IP checksum IGMP packet received/dropped <i>This element is only shown in detail mode.</i>
rx-bad-igmp-checksum	Parameter type: <Counter> - 32 bit counter	number of wrong IGMP checksum IGMP packets received/dropped <i>This element is only shown in detail mode.</i>
rx-wrong-src-ip-addr	Parameter type: <Counter> - 32 bit counter	number of IGMP signals received where the src-ip-addr of the multicast channel violates the ASM/SSM rules <i>This element is only shown in detail mode.</i>

139.6 IGMP package to multicast source Command

Command Description

This command shows the IGMP package to multicast source parameters.

User Level

The command can be accessed by operators with igmp privileges.

Command Syntax

The command has the following syntax:

```
> show igmp package-to-src [ (package-id) ]
```

Command Parameters

Table 139.6-1 "IGMP package to multicast source Command" Resource Parameters

Resource Identifier	Type	Description
(package-id)	Format: - index of the package - range: [1...1024]	name used to identify the packages

Command Output

Table 139.6-2 "IGMP package to multicast source Command" Display parameters

Specific Information		
name	Type	Description
group-address	Parameter type: <Ip::V4Address> - IPv4-address	the multicast group address <i>This element is always shown.</i>
source-address	Parameter type: <Ip::V4Address> - IPv4-address	the multicast group source address <i>This element is always shown.</i>
vlan-id	Parameter type: <Igmp::SrcVlanId> - the multicast vlan id - range: [1...4094]	the multicast vlan id <i>This element is always shown.</i>

139.7 IGMP Group to Package Status Command

Command Description

This command shows the IGMP group to package parameters

User Level

The command can be accessed by operators with igmp privileges.

Command Syntax

The command has the following syntax:

```
> show igmp grp-to-package [ (grp-ip-addr) [ src-ip-addr <Ip::V4Address> ] [ vlan-id <Igmp::SrcVlanId> ] ]
```

Command Parameters

Table 139.7-1 "IGMP Group to Package Status Command" Resource Parameters

Resource Identifier	Type	Description
(grp-ip-addr)	Format: - multicast-address (range: 224.0.0.3....239.255.255.255)	ip address identifying the multicast group
src-ip-addr	Parameter type: <Ip::V4Address> Format: - IPv4-address	ip address of the multicast server originating the multicast channel,value 0.0.0.0 means ASM(any-src-ip-addr)
vlan-id	Parameter type: <Igmp::SrcVlanId> Format: - the multicast vlan id - range: [1...4094]	identifies a particular vlan id

Command Output

Table 139.7-2 "IGMP Group to Package Status Command" Display parameters

Specific Information		
name	Type	Description
index	Parameter type: <Igmp::PackageIndex> - index of the package - range: [1...1024]	index used to identify the packages <i>This element is always shown.</i>

139.8 Show Multicast Source Statistics Command

Command Description

Obsolete command.

User Level

The command can be accessed by operators with igmp privileges.

Command Syntax

The command has the following syntax:

```
> show igmp module-mcast-src [ (slot) [ mcast-addr <Igmp::MulticastAddress> ] ]
```

Obsolete command.

Command Parameters

Table 139.8-1 "Show Multicast Source Statistics Command" Resource Parameters

Resource Identifier	Type	Description
(slot)	Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId>) Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number	identifies an IGMP module by the logical SlotId
mcast-addr	Parameter type: <Igmp::MulticastAddress> Format: - multicast-address (range: 224.0.0.3....239.255.255.255, except for 224.0.0.22)	mcast src address in network-byte order(big-endian)

Command Output

Table 139.8-2 "Show Multicast Source Statistics Command" Display parameters

Specific Information		
name	Type	Description
peak-nbr-sub-channels short name: pk-nr-sub-chan	Parameter type: <Counter> - 32 bit counter	The peak number of subscribed IGMP channels which have members connected to the source since the last statistics reset. It is only for those groups configured in multicast source table. <i>This element is always shown.</i>

name	Type	Description
peak-time	Parameter type: <Igmp::McastSrcPeakTime> - the time (yyyy-mm-dd:hour:minutes:secs) - unit: UTC	The network time indicating when the peak number of subscribed IGMP channels for the source occurred. It is only for those groups configured in Multicast Source Table. <i>This element is always shown.</i>
curr-subs-channels	Parameter type: <Gauge> - gauge	Indicates the current number of subscribed IGMP channels for the source. <i>This element is only shown in detail mode.</i>
nbr-connect-fail short name: nr-con-fail	Parameter type: <Counter> - 32 bit counter	Indicates the number of times that an attempt to create a multicast connection fails. <i>This element is always shown.</i>
user-success-join	Parameter type: <Counter> - 32 bit counter	indicates the number of times that users successfully joined a group. <i>This element is always shown.</i>

139.9 Show Multicast Channel Statistics Command

Command Description

This command shows the distribution of statistics information maintained by IGMP channels. The operator should know the slot index (the range is 1/1/0 to 1/1/18), the class D address (the range is 224.0.0.3 to 239.255.255.255) and the source-ip-addr of the mcast server. The following statistics objects measure the popularity of a multicast channel (when and how much the multicast channel is being watched by end users). The term "subscribe" in this context means how many IGMP channels have a group member connected to this multicast source.

- **peak-nbr-subs-channels:** This statistic indicates the peak number of subscribed IGMP channels for which leaf multicast VCLs have connected to the source since the last statistics reset.
- **peak-time:** This statistic indicates the network time, in seconds, when the peak number of subscribed IGMP channels for the source occurred.
- **curr-subs-channels:** This statistic indicates the current number of subscribed IGMP channels for the source.
- **connect-fail-counter:** This statistic indicates the number of times that an attempt to create a multicast connection has failed and the number of times that a multicast connection failure has occurred. The reason for failure is likely because there is insufficient bandwidth in the internal backplane of the Nokia 7302 or 7330 ISAM FTTN to transport the data traffic from the root endpoint of the network interface to the leaf endpoint of the access interface.

User Level

The command can be accessed by operators with igmp privileges.

Command Syntax

The command has the following syntax:

```
> show igmp module-mcast-channel [ (slot) [ grp-ip-addr <Igmp::MulticastAddress> ] [ src-ip-addr <Ip::V4Address> ] [ vlan-id <Igmp::McastChannelVlan> ] ]
```

Command Parameters

Table 139.9-1 "Show Multicast Channel Statistics Command" Resource Parameters

Resource Identifier	Type	Description
(slot)	Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId>) Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number	identifies an IGMP module by the logical SlotId
grp-ip-addr	Parameter type: <Igmp::MulticastAddress> Format: - multicast-address (range: 224.0.0.3....239.255.255.255, except for 224.0.0.22)	ip address identifying the multicast group
src-ip-addr	Parameter type: <Ip::V4Address>	ip address of the multicast server

Resource Identifier	Type	Description
	Format: - IPv4-address	originating the multicast channel,value 0.0.0.0 means ASM(any-src-ip-addr)
vlan-id	Parameter type: <Igmp::McastChannelVlan> Format: - vlan id for multicast - range: [1...4093]	vlanid of the multicast channel which is configured in it

Command Output

Table 139.9-2 "Show Multicast Channel Statistics Command" Display parameters

Specific Information		
name	Type	Description
peak-nbr-sub-channels short name: pk-nr-sub-ch	Parameter type: <Counter> - 32 bit counter	The peak number of subscribed IGMP channels which have members connected to the source since the last statistics reset. It is only for those groups configured in Multicast Channel table. <i>This element is always shown.</i>
peak-time	Parameter type: <Igmp::McastSrcPeakTime> - the time (yyyy-mm-dd:hour:minutes:secs) - unit: UTC	The network time indicating when the peak number of subscribed IGMP channels for the source occurred. It is only for those groups configured in Multicast Channel Table. <i>This element is always shown.</i>
curr-sub-channels	Parameter type: <Gauge> - gauge	Indicates the current number of subscribed IGMP channels for the multicast stream/channel. <i>This element is only shown in detail mode.</i>
nbr-connect-fail short name: nr-con-nok	Parameter type: <Counter> - 32 bit counter	Indicates the number of times that an attempt to create a multicast connection fails. <i>This element is always shown.</i>
user-success-join	Parameter type: <Counter> - 32 bit counter	indicates the number of times that users successfully joined a group. <i>This element is only shown in detail mode.</i>

139.10 IGMP Module Counter Status Command

Command Description

This command displays the IGMP module counters.

User Level

The command can be accessed by operators with igmp privileges.

Command Syntax

The command has the following syntax:

```
> show igmp module counter [ (slot-index) ]
```

Command Parameters

Table 139.10-1 "IGMP Module Counter Status Command" Resource Parameters

Resource Identifier	Type	Description
(slot-index)	Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId>) Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number	identifies an IGMP module by the logical slot id

Command Output

Table 139.10-2 "IGMP Module Counter Status Command" Display parameters

Specific Information		
name	Type	Description
total-msg	Parameter type: <Counter> - 32 bit counter	The total number of messages received from users, including IGMP messages and invalid messages. <i>This element is always shown.</i>
total-igmp-msg	Parameter type: <Counter> - 32 bit counter	The total number of IGMP messages, which includes join and leave requests from users, (both successful and unsuccessful). <i>This element is always shown.</i>
total-req	Parameter type: <Counter>	The total number of join requests

name	Type	Description
	- 32 bit counter	from users, which includes successful and unsuccessful attempts. <i>This element is always shown.</i>
success-req	Parameter type: <Counter> - 32 bit counter	The total number of successful join requests from users which includes new joins (which make a new connection) and re-joins (which already have a connection). <i>This element is always shown.</i>
unsuccess-req	Parameter type: <Counter> - 32 bit counter	The total number of unsuccessful new join requests from users. The failures could be due to the following reasons: permission bitmap failure, bitrate failure, lack of resource or invalid group address. <i>This element is only shown in detail mode.</i>
total-leave-req	Parameter type: <Counter> - 32 bit counter	The total number of leave requests from users. <i>This element is only shown in detail mode.</i>
total-inval-msg	Parameter type: <Counter> - 32 bit counter	The total number of invalid messages from users. These messages could be invalid for the following reasons: invalid IGMP message type, invalid IGMP message CRC, invalid IGMP message size, non-IGMP frame received, unexpected IGMP Query (GSQ or GMQ) received, RFC 1483 errors, MAC layer errors, or IP layer errors. <i>This element is only shown in detail mode.</i>
num-connects	Parameter type: <Counter> - 32 bit counter	The total number of connects due to successful new IGMP join requests from users. <i>This element is always shown.</i>
num-disconnects	Parameter type: <Counter> - 32 bit counter	The total number of disconnects to users. They can be due to GSQ or GMQ timer expiry or the triggering of fast channel changes. <i>This element is only shown in detail mode.</i>
peak-connects-sec	Parameter type: <Counter> - 32 bit counter	The peak number of multicast branch connections performed per second since the statistics were last cleared. <i>This element is only shown in detail mode.</i>
peak-disconnects-sec	Parameter type: <Counter> - 32 bit counter	The peak number of disconnects to users performed per second. <i>This element is only shown in</i>

139 IGMP Status Commands

name	Type	Description
		<i>detail mode.</i>
peak-msg-sec	Parameter type: <Counter> - 32 bit counter	The peak number of messages received from users per second. <i>This element is only shown in detail mode.</i>
gmq	Parameter type: <Counter> - 32 bit counter	The total number of GMQ requests from network. <i>This element is only shown in detail mode.</i>
gsq	Parameter type: <Counter> - 32 bit counter	The total number of GSQ requests from network. <i>This element is only shown in detail mode.</i>
gssq	Parameter type: <Counter> - 32 bit counter	The total number of GSSQ requests from network. <i>This element is only shown in detail mode.</i>
ovrld-app	Parameter type: <Counter> - 32 bit counter	The number of seconds during which module overload protection has been applied affecting all IGMP channels which are terminated at the IGMP module. <i>This element is only shown in detail mode.</i>

139.11 IGMP Module Time Status Command

Command Description

This command displays the IGMP module time-related parameters.

User Level

The command can be accessed by operators with igmp privileges.

Command Syntax

The command has the following syntax:

```
> show igmp module time [ (slot-index) ]
```

Command Parameters

Table 139.11-1 "IGMP Module Time Status Command" Resource Parameters

Resource Identifier	Type	Description
(slot-index)	Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId>) Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number	identifies an IGMP module by the logical slot id

Command Output

Table 139.11-2 "IGMP Module Time Status Command" Display parameters

Specific Information		
name	Type	Description
peak-connects	Parameter type: <Igmp::McastSrcPeakTime> - the time (yyyy-mm-dd:hour:minutes:secs) - unit: UTC	This will show "1970-01-01:00:00:00" by default. In case the peak number of connect occurs , it displays the time at which the event occurred <i>This element is always shown.</i>
peak-disconnects	Parameter type: <Igmp::McastSrcPeakTime> - the time (yyyy-mm-dd:hour:minutes:secs) - unit: UTC	This will show "1970-01-01:00:00:00" by default. In case the peak number of disconnect occurs , it displays the time at which the event occurred

139 IGMP Status Commands

name	Type	Description
		<i>This element is always shown.</i>
peak-msg	Parameter type: <Igmp::McastSrcPeakTime> - the time (yyyy-mm-dd:hour:minutes:secs) - unit: UTC	This will show "1970-01-01:00:00:00" by default. In case the peak number of messages received occurs, it displays the time at which the event occurred <i>This element is always shown.</i>
stats-intval	Parameter type: <Igmp::McastSrcPeakTime> - the time (yyyy-mm-dd:hour:minutes:secs) - unit: UTC	The network time, when the module-wide statistics were last reset. <i>This element is only shown in detail mode.</i>

139.12 IGMP Module Miscellaneous Status Command

Command Description

This command displays the IGMP module parameters.

User Level

The command can be accessed by operators with igmp privileges.

Command Syntax

The command has the following syntax:

```
> show igmp module miscellaneous [ (slot-index) ]
```

Command Parameters

Table 139.12-1 "IGMP Module Miscellaneous Status Command" Resource Parameters

Resource Identifier	Type	Description
(slot-index)	Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId>) Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number	identifies an IGMP module by the logical slot id

Command Output

Table 139.12-2 "IGMP Module Miscellaneous Status Command" Display parameters

Specific Information		
name	Type	Description
curr-root-conn	Parameter type: <Gauge> - gauge	The number of the connected groups. <i>This element is always shown.</i>
con-cfgd	Parameter type: <Gauge> - gauge	The number of the connected groups who are configured in multicast source table. <i>This element is always shown.</i>
con-un-cfgd	Parameter type: <Gauge> - gauge	The number of the connected groups who aren't configured in

139 IGMP Status Commands

name	Type	Description
		multicast source table. <i>This element is always shown.</i>
con-no-memb	Parameter type: <Gauge> - gauge	The number of the connected groups who is in reserve state(no member). <i>This element is always shown.</i>

139.13 IGMP System Status Command

Command Description

This command displays the next Multicast Service Context Profile Index available.

User Level

The command can be accessed by operators with igmp privileges.

Command Syntax

The command has the following syntax:

```
> show igmp mcast-svc-context
```

Command Output

Table 139.13-2 "IGMP System Status Command" Display parameters

Specific Information		
name	Type	Description
next	Parameter type: <Igmp::McastSvcCtxtNextPointer> - mcast service context profile index - range: [0...64]	The next available id for multicast service context profile. <i>This element is always shown.</i>

140- Transport Status Commands

140.1 Transport Status Command Tree	140-6177
140.2 SNMP Protocol Statistics Command	140-6178
140.3 SNMP Engine Status Command	140-6181
140.4 System Status Command	140-6182
140.5 SFP status commands	140-6183
140.6 Interface MAU Status Command	140-6185
140.7 Ethernet Lt Dot3 Status Command	140-6190

140.1 Transport Status Command Tree

Description

This chapter gives an overview of nodes that are handled by "Transport Status Commands".

Command Tree

```
----show
  ----transport
    ----snmp
      ----protocol-stats
      ----engine
    ----system-parameters
  ----X ether-ifsfp1t
    - (if-index)
    - index
  ----X ether-ifmault
    - (if-index)
    - index
  ----X ether-dot3lt
    - (stats-index)
```

140.2 SNMP Protocol Statistics Command

Command Description

This command displays the statistics related to the SNMP protocol.

User Level

The command can be accessed by operators with transport privileges.

Command Syntax

The command has the following syntax:

```
> show transport snmp protocol-stats
```

Command Output

Table 140.2-2 "SNMP Protocol Statistics Command" Display parameters

Specific Information		
name	Type	Description
in-pkts	Parameter type: <Counter> - 32 bit counter	The total number of received SNMP packets. <i>This element is always shown.</i>
out-pkts	Parameter type: <Counter> - 32 bit counter	The total number of transmitted SNMP packets. <i>This element is always shown.</i>
in-get-requests	Parameter type: <Counter> - 32 bit counter	The total number of received SNMP get requests. <i>This element is always shown.</i>
out-get-requests	Parameter type: <Counter> - 32 bit counter	The total number of transmitted SNMP get requests. <i>This element is always shown.</i>
in-get-next-requests	Parameter type: <Counter> - 32 bit counter	The total number of received SNMP get-next requests. <i>This element is always shown.</i>
out-get-next-requests	Parameter type: <Counter> - 32 bit counter	The total number of transmitted get-next requests . <i>This element is always shown.</i>
in-set-requests	Parameter type: <Counter> - 32 bit counter	The total number of received SNMP set requests. <i>This element is always shown.</i>
out-set-requests	Parameter type: <Counter> - 32 bit counter	The total number of transmitted SNMP set requests. <i>This element is always shown.</i>
in-get-responses	Parameter type: <Counter> - 32 bit counter	The total number of received SNMP get responses. <i>This element is always shown.</i>
out-get-responses	Parameter type: <Counter>	The total number of transmitted

name	Type	Description
	- 32 bit counter	SNMP get responsesG. <i>This element is always shown.</i>
in-traps	Parameter type: <Counter> - 32 bit counter	The total number of received SNMP traps. <i>This element is always shown.</i>
out-traps	Parameter type: <Counter> - 32 bit counter	The total number of transmitted SNMP traps. <i>This element is always shown.</i>
success-get-objects	Parameter type: <Counter> - 32 bit counter	The total number of successfully read SNMP objects. <i>This element is always shown.</i>
success-set-objects	Parameter type: <Counter> - 32 bit counter	The total number of successfully altered objects. <i>This element is always shown.</i>
in-too-bigs	Parameter type: <Counter> - 32 bit counter	The total number of received SNMP packets with tooBig error-status. <i>This element is always shown.</i>
out-too-bigs	Parameter type: <Counter> - 32 bit counter	The total number of transmitted SNMP packets with tooBig error-status. <i>This element is always shown.</i>
in-no-such-names	Parameter type: <Counter> - 32 bit counter	The total number of received SNMP packets with noSuchName error-status. <i>This element is always shown.</i>
out-no-such-names	Parameter type: <Counter> - 32 bit counter	The total number of transmitted SNMP packets with noSuchName error-status. <i>This element is always shown.</i>
in-bad-values	Parameter type: <Counter> - 32 bit counter	The total number of received SNMP packets with badValue error-status. <i>This element is always shown.</i>
out-bad-values	Parameter type: <Counter> - 32 bit counter	The total number of transmitted SNMP packets with badValue error-status. <i>This element is always shown.</i>
in-gen-errors	Parameter type: <Counter> - 32 bit counter	The total number received SNMP packets with genErr error-status. <i>This element is always shown.</i>
out-gen-errors	Parameter type: <Counter> - 32 bit counter	The total number of transmitted SNMP packets with genErr error-status. <i>This element is always shown.</i>
in-read-only-s	Parameter type: <Counter> - 32 bit counter	The total number received SNMP packets with readOnly error-status. <i>This element is always shown.</i>
in-bad-versions	Parameter type: <Counter> - 32 bit counter	The total number of received SNMP packets with a bad SNMP version. <i>This element is always shown.</i>
in-unknown-communities	Parameter type: <Counter> - 32 bit counter	The total number of received SNMP packets with an unknown community name. <i>This element is always shown.</i>

140 Transport Status Commands

name	Type	Description
in-bad-communities	Parameter type: <Counter> - 32 bit counter	The total number of received SNMP packets with an operation not allowed for the specified community.. <i>This element is always shown.</i>
in-asn1-errors	Parameter type: <Counter> - 32 bit counter	The total number of received SNMP packets with ASN.1 coding errors. <i>This element is always shown.</i>
in-unknown-contexts	Parameter type: <Counter> - 32 bit counter	The total number of received SNMP packets targetted to a wrong context. <i>This element is always shown.</i>
in-bad-security-levels	Parameter type: <Counter> - 32 bit counter	The total number of received SNMP packets with an invalid security-level. <i>This element is always shown.</i>
in-not-in-time-windows	Parameter type: <Counter> - 32 bit counter	The total number of received SNMP packets outside the allowed time-window. <i>This element is always shown.</i>
in-unknown-users	Parameter type: <Counter> - 32 bit counter	The total number of received SNMP packets with an unknown user name. <i>This element is always shown.</i>
in-unknown-engines	Parameter type: <Counter> - 32 bit counter	The total number of received SNMP packets with an unknown engine-id. <i>This element is always shown.</i>
in-wrong-digests	Parameter type: <Counter> - 32 bit counter	The total number of received SNMP packets with a wrong authentication digest. <i>This element is always shown.</i>
in-decrypt-errors	Parameter type: <Counter> - 32 bit counter	The total number of received SNMP packets that could not be decrypted. <i>This element is always shown.</i>
in-unknown-models	Parameter type: <Counter> - 32 bit counter	nbr of pkts rx which referred an unknown model <i>This element is always shown.</i>
in-invalids	Parameter type: <Counter> - 32 bit counter	The number of received invalid SNMP messages. <i>This element is always shown.</i>
in-unknown-pdu-types	Parameter type: <Counter> - 32 bit counter	The number of received SNMP packets with an unknown PDU type. <i>This element is always shown.</i>

140.3 SNMP Engine Status Command

Command Description

This command displays the status of the SNMP engine.

User Level

The command can be accessed by operators with transport privileges.

Command Syntax

The command has the following syntax:

> show transport snmp engine

Command Output

Table 140.3-2 "SNMP Engine Status Command" Display parameters

Specific Information		
name	Type	Description
engine-id	Parameter type: <Snmp::EngineID> - SNMP Engine Identifier - length: 5<=x<=32	the unique identifier for the SNMP engine <i>This element is always shown.</i>
boot-cnt	Parameter type: <Snmp::EngineBoots> - SNMP Engine Boots - range: [1...2147483647]	the number of times the SNMP engine booted. <i>This element is always shown.</i>
up-time	Parameter type: <Snmp::EngineTime> - SNMP Engine Time - range: [1...2147483647]	the number of seconds since the last boot <i>This element is always shown.</i>
max-message-size	Parameter type: <Snmp::MessageSize> - SNMP Message Size - range: [484...2147483647]	the maximum length for an SNMP message for this engine <i>This element is always shown.</i>

140.4 System Status Command

Command Description

This command displays the system statistics.

User Level

The command can be accessed by operators with transport privileges.

Command Syntax

The command has the following syntax:

```
> show transport system-parameters
```

Command Output

Table 140.4-2 "System Status Command" Display parameters

Specific Information		
name	Type	Description
description	Parameter type: <Transport::sysDescr> - a printable string - length: x<=255	A textual description which include's the full name and version identification of the system's hardware type, software operating-system, and networking software. <i>This element is always shown.</i>
object-id	Parameter type: <Object> - an object identifier	The vendor's authoritative identification of the network management subsystem contained in the entity. This value is allocated within the SMI enterprises subtree (1.3.6.1.4.1) and provides an easy and unambiguous means for determining 'what kind of box' is being managed. <i>This element is always shown.</i>
up-time	Parameter type: <Transport::TimeTicks> - a timeout value - unit: hundredths of a second	The time since the network management portion of the system was last re-initialized. <i>This element is always shown.</i>
services	Parameter type: <Transport::SysServices> - set of services - unit: milisec - range: [0...127]	A value which indicates the set of services that this entity primarily offers. <i>This element is always shown.</i>

140.5 SFP status commands

Command Description

Obsolete command, replaced by `show ethernet sfp`.

This command displays the Ethernet SFP parameters

User Level

The command can be accessed by operators with transport privileges.

Command Syntax

The command has the following syntax:

```
> show transport ether-ifsplt [ (if-index) [ index <Transport::Index> ] ]
```

Obsolete command, replaced by `show ethernet sfp`.

Command Parameters

Table 140.5-1 "SFP status commands" Resource Parameters

Resource Identifier	Type	Description
(if-index)	Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number	interface index of the sfp
index	Parameter type: <Transport::Index> Format: - port to which the MAU is connected - range: [1...2147483647]	identify sfp, among others connected to same interface

Command Output

Table 140.5-2 "SFP status commands" Display parameters

Specific Information		
name	Type	Description
sfp-status	Parameter type: <Transport::SFPstatus> (operational-up interface-down	identifies the status of the sfp <i>This element is always shown.</i>

140 Transport Status Commands

name	Type	Description
	no-nokia-label los type-mismatch local-power-off brother-power-off active-power-off) Possible values: - operational-up : SFP is operational up - interface-down : SFP is not plugged in, interface is down - no-nokia-label : SFP is plugged in but in power down because no Nokia label - los : SFP is plugged in but detected LOS.Note:if ALS enabled,when RX is LOS,disable TX.when RX out of LOS,enable TX. if ALS disabled,always enable TX - type-mismatch : SFP real type mismatch with configured type - local-power-off : local SFP power off since temperature over - brother-power-off : brother SFP power off since temperature over - active-power-off : SFP power down actively by operator	
sfp-inventory	Parameter type: <Transport::SFPinventory> - specification of Sfp inventory. - length: 1<=x<=128	indicates the information of the sfp vendor <i>This element is only shown in detail mode.</i>

140.6 Interface MAU Status Command

Command Description

Obsolete command, replaced by `show ethernet mau`.

This command displays the Ethernet MAU parameters.

User Level

The command can be accessed by operators with transport privileges.

Command Syntax

The command has the following syntax:

```
> show transport ether-ifmault [ (if-index) [ index <Transport::Index> ] ]
```

Obsolete command, replaced by `show ethernet mau`.

Command Parameters

Table 140.6-1 "Interface MAU Status Command" Resource Parameters

Resource Identifier	Type	Description
(if-index)	Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number	interface index of the mau
index	Parameter type: <Transport::Index> Format: - port to which the MAU is connected - range: [1...2147483647]	identify MAU, among others connected to same interface

Command Output

Table 140.6-2 "Interface MAU Status Command" Display parameters

Specific Information		
name	Type	Description
type	Parameter type: <Ether::MAUType> (10baset 100basexhd	Specifies the MAU type. If the MAU type is unknown, then unknown MAU type will be

140 Transport Status Commands

name	Type	Description
	100basetxfd 100basexhd 100basexfd 1000basexhd 1000basexfd 1000baselxhd 1000baselxfd 1000basesxhd 1000basesxfd 1000basethd 1000basetfd 10gbasex 10gbaser 10gbaseer 10gbaselr 10gbasesr 100basebx10d 100basebx10u 100baselx10 1000basebx10d 1000basebx10u 1000baselx10 2500basex 10gbasetfd - unknown) Possible values: - 10baset : UTP 10M - 100basexhd : UTP 100M half duplex - 100basetxfd : UTP 100M full duplex - 100basexhd : X fiber over PMT half duplex - 100basexfd : X fiber over PMT full duplex - 1000basexhd : PCS/PMA,unknown PMD, half duplex - 1000basexfd : PCS/PMA,unknown PMD, full duplex - 1000baselxhd : fiber over long-wavelength laser half duplex - 1000baselxfd : fiber over long-wavelength laser full duplex - 1000basesxhd : fiber over short-wavelength laser half duplex - 1000basesxfd : fiber over short-wavelength laser full duplex - 1000basethd : UTP 1G half duplex - 1000basetfd : UTP 1G full duplex - 10gbasex : fiber 10G ethernet, PCS 8B/10B - 10gbaser : fiber 10G ethernet, PCS 64B/66B - 10gbaseer : fiber 10G ethernet extended reach, 30km - 10gbaselr : fiber 10G ethernet long reach, 10km - 10gbasesr : fiber 10G ethernet short reach, 300m - 100basebx10d : one single-mode fiber OLT long wavelength, 10km, 100 base - 100basebx10u : one single-mode fiber ONU, long wavelength, 10km, 100 base - 100baselx10 : two single-mode fibers over long wavelength, 10km, 100 base - 1000basebx10d : one single-mode fiber OLT over long wavelength, 10km, 1000 base - 1000basebx10u : one single-mode fiber ONU over long wavelength, 10km, 1000 base	returned. If the MAU is a link or fiber type then media-available is equivalent to the link test fail state/low light function. For an AUI or a coax (including broadband) MAU this indicates whether or not loopback is detected on the DI circuit. The value of this attribute persists between packets for MAU types AUI, 10BASE5, 10BASE2, 10BROAD36, and 10BASE-FP. <i>This element is always shown.</i>

name	Type	Description
	- 1000baselx10 : two single-mode fibers over long wavelength, 10km, 1000 base - 2500basex : single-mode fibers, 2.5G base - 10gbasetfd : UTP 10G full duplex - unknown : unknown type	
media-available	Parameter type: <Transport::MauAvailable> (other unknown available not-available remote-fault invalid-signal remote-jabber remote-link-loss remote-test off-line auto-neg-error) Possible values: - other : MAU in other state - unknown : MAU's true state is unknown - available : - not-available : MAU is fully functional - remote-fault : power down - invalid-signal : reset the MAU - remote-jabber : power down - remote-link-loss : power down - remote-test : power down - off-line : power down - auto-neg-error : power down	Specifies whether the media is available for the MAU or not. <i>This element is always shown.</i>
jabber-state	Parameter type: <Transport::MauJabber> (other unknown no-jabber jabbering) Possible values: - other : if not in any state - unknown : MAU's true state is unknown - no-jabber : MAU not jabbering - jabbering : MAU is jabbering	The jabber-state indicates whether this entity is jabbering, not jabbering, unknown or other state. <i>This element is always shown.</i>
b100basefxfd	Parameter type: <Ether::B100BaseFXFD> (yes no) Possible values: - yes : 100basefxfd supported - no : 100basefxfd not supported	X fiber over PMT full duplex <i>This element is only shown in detail mode.</i>
b100baselx10	Parameter type: <Ether::B100BaseLX10> (yes no) Possible values: - yes : 100baselx10 supported - no : 100baselx10 not supported	two single-mode fibers over long wavelength, 10km, 100 base <i>This element is only shown in detail mode.</i>
b100basebx10d	Parameter type: <Ether::B100BaseBX10D> (yes no) Possible values: - yes : 100basebx10d supported - no : 100basebx10d not supported	one single-mode fiber OLT long wavelength, 10km, 100 base <i>This element is only shown in detail mode.</i>

140 Transport Status Commands

name	Type	Description
b100basebx10u	Parameter type: <Ether::B100BaseBX10U> (yes no) Possible values: - yes : 100basebx10u supported - no : 100basebx10u not supported	one single-mode fiber ONU, long wavelength, 10km, 100 base <i>This element is only shown in detail mode.</i>
b100basetx10d	Parameter type: <Ether::B100BaseTXFD> (yes no) Possible values: - yes : 100basetx10d supported - no : 100basetx10d not supported	UTP 100M full duplex <i>This element is only shown in detail mode.</i>
b1000basetfd	Parameter type: <Ether::B1000BaseTFD> (yes no) Possible values: - yes : 1000basetfd supported - no : 1000basetfd not supported	UTP 1G full duplex <i>This element is only shown in detail mode.</i>
b1000basesx10d	Parameter type: <Ether::B1000BaseSXF10D> (yes no) Possible values: - yes : 1000basesx10d supported - no : 1000basesx10d not supported	fiber over short-wavelength laser full duplex <i>This element is only shown in detail mode.</i>
b1000baselx10	Parameter type: <Ether::B1000BaseLX10> (yes no) Possible values: - yes : 1000baselx10 supported - no : 1000baselx10 not supported	two single-mode fibers over long wavelength, 10km, 1000 base <i>This element is only shown in detail mode.</i>
b1000baselx10d	Parameter type: <Ether::B1000BaseLXFD> (yes no) Possible values: - yes : 1000baselx10d supported - no : 1000baselx10d not supported	fiber over long-wavelength laser full duplex <i>This element is only shown in detail mode.</i>
b1000basebx10u	Parameter type: <Ether::B1000BaseBX10U> (yes no) Possible values: - yes : 1000basebx10u supported - no : 1000basebx10u not supported	one single-mode fiber ONU over long wavelength, 10km, 1000 base <i>This element is only shown in detail mode.</i>
b1000basebx10d	Parameter type: <Ether::B1000BaseBX10D> (yes no) Possible values: - yes : 1000basebx10d supported - no : 1000basebx10d not supported	one single-mode fiber OLT over long wavelength, 10km, 1000 base <i>This element is only shown in detail mode.</i>
b10gbase10r	Parameter type: <Ether::B10GBaseLR> (yes no) Possible values: - yes : 10GbaseLR supported - no : 10GbaseLR not supported	10G optical ethernet long reach 10km <i>This element is only shown in detail mode.</i>
b10gbase30r	Parameter type: <Ether::B10GBaseER> (yes no)	10G optical ethernet extended reach 30km <i>This element is only shown in detail mode.</i>

name	Type	Description
	Possible values: - yes : 10GbaseER supported - no : 10GbaseER not supported	<i>detail mode.</i>
b10gbasesr	Parameter type: <Ether::B10GBaseSR> (yes no) Possible values: - yes : 10GbaseSR supported - no : 10GbaseSR not supported	10G optical ethernet short reach 300m <i>This element is only shown in detail mode.</i>
auto-neg-supported	Parameter type: <Ether::TruthValue> (true false) Possible values: - true : autonegotiation is supported - false : autonegotiation is not supported	Specifies whether or not auto-negotiation is supported on this MAU. <i>This element is always shown.</i>
auto-neg-status	Parameter type: <Ether::AutoNegStatus> (other configuring complete disabled paralleldetectfail) Possible values: - other : unknown auto-negotiation status - configuring : auto-negotiation still ongoing - complete : auto-negotiation completed - disabled : auto-negotiation disabled - paralleldetectfail : parallel detection failed	Displays the auto-negotiation status of this MAU. <i>This element is always shown.</i>
cap100base-tfd	Parameter type: <Ether::ACAP_100BaseTFD> (yes no) Possible values: - yes : 100BaseTFD supported - no : 100BaseTFD not supported	electrical 100M full duplex autonegotiation capable <i>This element is only shown in detail mode.</i>
cap1000base-xfd	Parameter type: <Ether::ACAP_1000BaseXFD> (yes no) Possible values: - yes : 1000BaseXFD supported - no : 1000BaseXFD not supported	optical 1G full duplex autonegotiation capable <i>This element is only shown in detail mode.</i>
cap1000base-tfd	Parameter type: <Ether::ACAP_1000BaseTFD> (yes no) Possible values: - yes : 1000BaseTFD supported - no : 1000BaseTFD not supported	electrical 1G full duplex autonegotiation capable <i>This element is only shown in detail mode.</i>
cap10gbase-tfd	Parameter type: <Ether::ACAP_10GBaseTFD> (yes no) Possible values: - yes : 10GBaseTFD supported - no : 10GBaseTFD not supported	electrical 10G full duplex autonegotiation capable <i>This element is only shown in detail mode.</i>

140.7 Ethernet Lt Dot3 Status Command

Command Description

Obsolete command, replaced by `show ethernet dot3stats`.

This command displays the statistics for a collection of Ethernet-like interfaces attached to a particular system. There will be one row in this table for each Ethernet-like interface in the system. The parameter stats-index gives an index value that uniquely identifies an interface to an Ethernet-like medium.

The alignment-error parameter gives a count of frames received on a particular interface that are not an integral number of octets in length and do not pass the FCS check. The count represented by an instance of this object is incremented when the alignmentError status is returned by the MAC service to the LLC. This counter does not increment for 8-bit wide group encoding schemes. Discontinuities in the value of this counter can occur at re-initialization of the management system.

The fcs-error parameter gives a count of frames received on a particular interface that are an integral number of octets in length, but do not pass the FCS check. This count does not include frames received with frame-too-long or frame-too-short error.

The internal-mac-tx-error parameter gives a count of frames for which transmission on a particular interface fails due to an internal MAC sublayer transmit error. A frame is only counted by an instance of this object if it is not counted by the corresponding instance of either the late collisions object, the excessive collisions object, or the carrier sense errors object. The precise meaning of the count represented by an instance of this object is implementation-specific. In particular, an instance of this object may represent a count of transmission errors on a particular interface that are not otherwise counted.

The internal-mac-rx-error parameter gives a count of frames for which reception on a particular interface fails due to an internal MAC sublayer receive error. A frame is only counted by an instance of this object if it is not counted by the corresponding instance of either the frame toolongs object, the alignment errors object, or the FCS errors object. The precise meaning of the count represented by an instance of this object is implementation-specific. In particular, an instance of this object may represent a count of receive errors on a particular interface that are not otherwise counted.

User Level

The command can be accessed by operators with transport privileges.

Command Syntax

The command has the following syntax:

```
> show transport ether-dot3lt [ (stats-index) ]
```

Obsolete command, replaced by `show ethernet dot3stats`.

Command Parameters

Table 140.7-1 "Ethernet Lt Dot3 Status Command" Resource Parameters

Resource Identifier	Type	Description
(stats-index)	Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> /	index of the interface to an ethernet-like medium

Resource Identifier	Type	Description
	<Eqpt::PortId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number	

Command Output

Table 140.7-2 "Ethernet Lt Dot3 Status Command" Display parameters

Specific Information		
name	Type	Description
align-err	Parameter type: <Counter> - 32 bit counter	A count of frames received on a particular interface that are not an integral number of octets in length and do not pass the FCS check. <i>This element is always shown.</i>
fcs-err	Parameter type: <Counter> - 32 bit counter	A count of frames received on a particular interface that are not an integral number of octets in length and do not pass the FCS check. <i>This element is always shown.</i>
internal-mac-tx-err	Parameter type: <Counter> - 32 bit counter	A count of frames for which transmission on a particular interface fails due to an internal MAC sublayer transmit error. <i>This element is only shown in detail mode.</i>
internal-mac-rx-err	Parameter type: <Counter> - 32 bit counter	A count of frames for which reception on a particular interface fails due to an internal MAC sublayer receive error. <i>This element is only shown in detail mode.</i>

141- Efm Oam Status Commands

141.1 Efm Oam Status Command Tree	141-6193
141.2 Efm Oam Mac Statistics Command	141-6194
141.3 Efm Oam Pme Statistics Command	141-6197
141.4 Efm Oam Local Information Status Command	141-6199
141.5 Efm Oam Peer Information Status Command	141-6201
141.6 Efm Oam statistics Status Command	141-6204
141.7 Efm Oam loopback Status Command	141-6206
141.8 Efm Oam Internal Traffic generator Status Command	141-6208

141.1 Efm Oam Status Command Tree

Description

This chapter gives an overview of nodes that are handled by "Efm Oam Status Commands".

Command Tree

```
----show
  ----efm-oam
    ----mac-stats
      - (interface)
    ----pme-stats
      - (group)
    ----local-oam-info
      - (interface)
    ----peer-oam-info
      - (interface)
    ----oam-stats
      - (interface)
    ----loopback-info
      - (interface)
    ----X int-traff-gen
      - (interface)
```

141.2 Efm Oam Mac Statistics Command

Command Description

This command triggers a request to retrieve MAC information from the CPE and displays the result if and when available.

The output of this command is always in detailed format.

User Level

The command can be accessed by operators with transport privileges.

Command Syntax

The command has the following syntax:

```
> show efm-oam mac-stats [ (interface) ]
```

Command Parameters

Table 141.2-1 "Efm Oam Mac Statistics Command" Resource Parameters

Resource Identifier	Type	Description
(interface)	Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number	identification of the EFM port / Ethernet port

Command Output

Table 141.2-2 "Efm Oam Mac Statistics Command" Display parameters

Specific Information		
name	Type	Description
frames-tx-ok	Parameter type: <Ether::FramesTxOkCounter> (not-available <Counter>) Possible values: - not-available : counter not available Field type <Counter> - 32 bit counter	the number of frames that are successfully transmitted (by CPE). <i>This element is only shown in detail mode.</i>
frames-rx-ok	Parameter type: <Ether::FramesRxOkCounter>	the number of frames that are

name	Type	Description
	(not-available <Counter>) Possible values: - not-available : counter not available Field type <Counter> - 32 bit counter	successfully received (by CPE). <i>This element is only shown in detail mode.</i>
fcs-errors	Parameter type: <Ether::FcsErrorsCounter> (not-available <Counter>) Possible values: - not-available : counter not available Field type <Counter> - 32 bit counter	the number of receive frames (in CPE) that are an integral number of octets in length and do not pass the FCS check. This does not include frames with frame fragment error. The ReceiveStatus is reported as frameCheckError <i>This element is only shown in detail mode.</i>
alignment-errors	Parameter type: <Ether::AlignmentErrorsCounter> (not-available <Counter>) Possible values: - not-available : counter not available Field type <Counter> - 32 bit counter	the number of frames (in CPE) that are not an integral number of octets in length and do not pass the FCS check. The ReceiveStatus is reported as alignmentError. <i>This element is only shown in detail mode.</i>
frames-lost-mac-tx	Parameter type: <Ether::FramesLostMacTxCounter> (not-available <Counter>) Possible values: - not-available : counter not available Field type <Counter> - 32 bit counter	the number of frames (in CPE) that would otherwise be transmitted by the station, but could not be sent due to an internal MAC sublayer transmit error. <i>This element is only shown in detail mode.</i>
frames-lost-mac-rx	Parameter type: <Ether::FramesLostMacRxCounter> (not-available <Counter>) Possible values: - not-available : counter not available Field type <Counter> - 32 bit counter	the number of frames (in CPE) that would otherwise be received by the station, but could not be accepted due to an internal MAC sublayer receive error. <i>This element is only shown in detail mode.</i>
mcast-frames-rx-ok	Parameter type: <Ether::McastFramesRxOkCounter> (not-available <Counter>) Possible values: - not-available : counter not available Field type <Counter> - 32 bit counter	the number of frames that are successfully received (by CPE) and are directed to an active nonbroadcast group address. <i>This element is only shown in detail mode.</i>
bcast-frames-rx-ok	Parameter type: <Ether::BcastFramesRxOkCounter> (not-available <Counter>) Possible values: - not-available : counter not available Field type <Counter> - 32 bit counter	the number of frames that are successfully received (by CPE) and are directed to the broadcast group address. <i>This element is only shown in detail mode.</i>
in-range-len-err	Parameter type: <Ether::InRangeLenErrCounter> (not-available <Counter>) Possible values:	the number of frames that are successfully received (by CPE) and are directed to the broadcast group address. This does not

141 Efm Oam Status Commands

name	Type	Description
	- not-available : counter not available Field type <Counter> - 32 bit counter	include frames received with frame-too-long, FCS, length or alignment errors, or frames lost due to internal MAC sublayer error. <i>This element is only shown in detail mode.</i>
len-out-of-range	Parameter type: <Ether::LenOutOfRangeCounter> (not-available <Counter>) Possible values: - not-available : counter not available Field type <Counter> - 32 bit counter	the number of frames (in CPE) with a length field value greater than the maximum allowed LLC data size. <i>This element is only shown in detail mode.</i>
frame-too-long-err	Parameter type: <Ether::FrameTooLongErrorsCounter> (not-available <Counter>) Possible values: - not-available : counter not available Field type <Counter> - 32 bit counter	the number of frames received (by CPE) that exceed the maximum permitted frame size. <i>This element is only shown in detail mode.</i>
octets-tx-ok	Parameter type: <Ether::OctetsTxOkCounter> (not-available <Counter>) Possible values: - not-available : counter not available Field type <Counter> - 32 bit counter	the number of data and padding octets transmitted (by cpe). <i>This element is only shown in detail mode.</i>
octets-rx-ok	Parameter type: <Ether::OctetsRxOkCounter> (not-available <Counter>) Possible values: - not-available : counter not available Field type <Counter> - 32 bit counter	the number of data and padding octets received (by cpe). <i>This element is only shown in detail mode.</i>
bcast-frames-tx-ok	Parameter type: <Ether::BroadcastFramesTxOkCounter> (not-available <Counter>) Possible values: - not-available : counter not available Field type <Counter> - 32 bit counter	the number of frames that are transmitted (by CPE) and are directed to the broadcast group address. <i>This element is only shown in detail mode.</i>
mcast-frames-tx-ok	Parameter type: <Ether::MulticastFramesTxOkCounter> (not-available <Counter>) Possible values: - not-available : counter not available Field type <Counter> - 32 bit counter	the number of frames that are transmitted (by CPE) and are directed to an active nonbroadcast group address. <i>This element is only shown in detail mode.</i>
runts-counter	Parameter type: <Ether::Runts> (not-available <Counter>) Possible values: - not-available : counter not available Field type <Counter> - 32 bit counter	the number of runts event detected (by cpe). <i>This element is only shown in detail mode.</i>

141.3 Efm Oam Pme Statistics Command

Command Description

This command triggers a request to retrieve PME information from the CPE and displays the result if and when available. This commands allows retrieval of PME information for an individual dsl link or for all links in an EFM bonding group.

The output of this command is always in detailed format.

User Level

The command can be accessed by operators with transport privileges.

Command Syntax

The command has the following syntax:

```
> show efm-oam pme-stats [ (group) ]
```

Command Parameters

Table 141.3-1 "Efm Oam Pme Statistics Command" Resource Parameters

Resource Identifier	Type	Description
(group)	Format: (link : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId>) Possible values: - link : xdsl-line Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number	identification of the EFM or XDSL port

Command Output

Table 141.3-2 "Efm Oam Pme Statistics Command" Display parameters

Specific Information		
name	Type	Description
link	Parameter type: <Itf::LinkPmeEthernetIndex> (xdsl : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId>	identification of the xdsl port <i>This element is only shown in detail mode.</i>

141 Efm Oam Status Commands

name	Type	Description
	eth : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId>) Possible values: - xdsl : xdsl-line - eth : eth-line Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number	
tc-cod-violations	Parameter type: <Ether::CodingViolationsCounter> (not-available <Counter>) Possible values: - not-available : counter not available Field type <Counter> - 32 bit counter	a number of 64/65-octet encapsulation error (in CPE). <i>This element is only shown in detail mode.</i>
fec-corrected-blk	Parameter type: <Ether::FecCorrectedBlkCounter> (not-available <Counter>) Possible values: - not-available : counter not available Field type <Counter> - 32 bit counter	For a 10PASS-TS PME, a number of corrected FEC blocks (in CPE). This counter will not increment for other PHY types. <i>This element is only shown in detail mode.</i>
fec-uncorrect-blk	Parameter type: <Ether::FecUncorrectBlkCounter> (not-available <Counter>) Possible values: - not-available : counter not available Field type <Counter> - 32 bit counter	For a 10PASS-TS PME, a number of uncorrectable FEC blocks (in CPE). This counter will not increment for other PME types. <i>This element is only shown in detail mode.</i>
tc-crc-errors	Parameter type: <Ether::CrcErrorsCounter> (not-available <Counter>) Possible values: - not-available : counter not available Field type <Counter> - 32 bit counter	number of TC-CRC errors recorded on the CPE. <i>This element is only shown in detail mode.</i>

141.4 Efm Oam Local Information Status Command

Command Description

This command displays the local EFM OAM data.

User Level

The command can be accessed by operators with transport privileges.

Command Syntax

The command has the following syntax:

```
> show efm-oam local-oam-info [ (interface) ]
```

Command Parameters

Table 141.4-1 "Efm Oam Local Information Status Command" Resource Parameters

Resource Identifier	Type	Description
(interface)	Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number	identification of the EFM port / Ethernet port

Command Output

Table 141.4-2 "Efm Oam Local Information Status Command" Display parameters

Specific Information		
name	Type	Description
oper-status	Parameter type: <Ether::OperStatus> (disabled link-fault passive-wait active-snd-local snd-local-rem snd-local-rem-ok peer-local-rej peer-remote-rej operational) Possible values:	operational status of the OAM entity <i>This element is always shown.</i>

141 Efm Oam Status Commands

name	Type	Description
	- disabled : efm oam not enabled - link-fault : interface operational down - passive-wait : passive mode - active-snd-local : send local config - snd-local-rem : send local remote tlv - snd-local-rem-ok : remote config ok - peer-local-rej : remote config locally rejected - peer-remote-rej : local config remotely rejected - operational : fully operational	
max-oam-pdu-size short name: max-pdu/size	Parameter type: <Ether::PduSize> - an integer value - unit: bytes - range: [0,64...1518]	the maximum size of the OAMPDU supported by the CPE. <i>This element is always shown.</i>
config-revision short name: cfg/rev	Parameter type: <Ether::ConfigRevision> - an unsigned short value - range: [0...65535]	the configuration revision of the OAM peer as reflected in the latest OAMPDU. <i>This element is always shown.</i>
version short name: vers	Parameter type: <Ether::Version> - the version of the local OAM entity	the version of the local OAM entity <i>This element is always shown.</i>
support-unidirect short name: support/uni	Parameter type: <Ether::unidirection> (yes no) Possible values: - yes : unidirection supported - no : unidirection not supported	unidirection support function <i>This element is always shown.</i>
support-loopback short name: support/lpbck	Parameter type: <Ether::loopback> (yes no) Possible values: - yes : loopback supported - no : loopback not supported	loopback support function <i>This element is always shown.</i>
support-event short name: support/evnt	Parameter type: <Ether::event> (yes no) Possible values: - yes : event supported - no : event not supported	event support function <i>This element is always shown.</i>
support-variable short name: support/var	Parameter type: <Ether::variable> (yes no) Possible values: - yes : variable functions supported - no : variable functions not supported	variable support function <i>This element is always shown.</i>

141.5 Efm Oam Peer Information Status Command

Command Description

This command displays the peer (CPE) EFM OAM configuration data.

User Level

The command can be accessed by operators with transport privileges.

Command Syntax

The command has the following syntax:

```
> show efm-oam peer-oam-info [ (interface) ]
```

Command Parameters

Table 141.5-1 "Efm Oam Peer Information Status Command" Resource Parameters

Resource Identifier	Type	Description
(interface)	Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number	identification of the EFM port / Ethernet port

Command Output

Table 141.5-2 "Efm Oam Peer Information Status Command" Display parameters

Specific Information		
name	Type	Description
mac-address	Parameter type: <Ether::MacAddr> - mac address (aa:bb:cc:a1:02:03) - length: 6	the mac address of the peer OAM entity. <i>This element is always shown.</i>
vendor-oui short name: vendor/oui	Parameter type: <Ether::VendorOui> - an octet string bitmask - length: 3	The oui of the CPE. <i>This element is always shown.</i>
vendor-info short name: vendor/info	Parameter type: <Ether::VendorInfo> <Ether::PrintableVendorInfo> Field type <Ether::PrintableVendorInfo> - description to help the operator to identify the object	the vendor info of the CPE. <i>This element is always shown.</i>

141 Efm Oam Status Commands

name	Type	Description
	- length: 4	
mode	Parameter type: <Ether::Mode> ((passive pas) (active act) (unknown unkn)) Possible values: - passive : passive mode - pas : passive mode - active : active mode - act : active mode - unknown : unknown mode - unkn : unknown mode	the mode of the OAM peer as reflected in the latest information OAMPDU received with a local information tlv. <i>This element is always shown.</i>
max-oam-pdu-size short name: max-pdu/size	Parameter type: <Ether::PduSize> - an integer value - unit: bytes - range: [0,64...1518]	the maximum size of the OAMPDU supported by the CPE. <i>This element is always shown.</i>
config-revision short name: cfg/rev	Parameter type: <Ether::ConfigRevision> - an unsigned short value - range: [0...65535]	the configuration revision of the OAM peer as reflected in the latest OAMPDU. <i>This element is always shown.</i>
support-unidirect short name: support/uni	Parameter type: <Ether::unidirection> (yes no) Possible values: - yes : unidirection supported - no : unidirection not supported	unidirection support function <i>This element is always shown.</i>
support-loopback short name: support/lpbck	Parameter type: <Ether::loopback> (yes no) Possible values: - yes : loopback supported - no : loopback not supported	loopback support function <i>This element is always shown.</i>
support-event short name: support/evnt	Parameter type: <Ether::event> (yes no) Possible values: - yes : event supported - no : event not supported	event support function <i>This element is always shown.</i>
support-variable short name: support/var	Parameter type: <Ether::variable> (yes no) Possible values: - yes : variable functions supported - no : variable functions not supported	variable support function <i>This element is always shown.</i>
flags-linkfault short name: flags/linkfault	Parameter type: <Ether::linkfault> (yes no) Possible values: - yes : peer device's receive path fault - no : peer device's receive path not fault	peer device's receive path states <i>This element is always shown.</i>
flags-dyinggasp short name: flags/dyinggasp	Parameter type: <Ether::dyinggasp> (yes no) Possible values: - yes : peer device unrecoverable failure condition - no : peer device not unrecoverable failure condition	peer device unrecoverable failure condition <i>This element is always shown.</i>
flags-criticalevent	Parameter type: <Ether::criticalevent>	peer device critical event

name	Type	Description
short name: flags/criticalevent	(yes no) Possible values: - yes : peer device critical event - no : peer device not critical event	<i>This element is always shown.</i>
flags-stable short name: flags/stable	Parameter type: <Ether::stable> (unstable evaluating stable) Possible values: - unstable : peer DTE unsatisfied, discovery can not complete - evaluating : peer DTE discovery process has not completed - stable : peer DTE discovery process has completed	peer device evaluating and stable <i>This element is always shown.</i>

141.6 Efm Oam statistics Status Command

Command Description

This command displays the EFM OAM statistics.

User Level

The command can be accessed by operators with transport privileges.

Command Syntax

The command has the following syntax:

```
> show efm-oam oam-stats [ (interface) ]
```

Command Parameters

Table 141.6-1 "Efm Oam statistics Status Command" Resource Parameters

Resource Identifier	Type	Description
(interface)	Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number	identification of the EFM port / Ethernet port

Command Output

Table 141.6-2 "Efm Oam statistics Status Command" Display parameters

Specific Information		
name	Type	Description
information-tx short name: information/tx	Parameter type: <Counter> - 32 bit counter	number of information OAMPDUs transmitted. <i>This element is always shown.</i>
information-rx short name: information/rx	Parameter type: <Counter> - 32 bit counter	number of information OAMPDUs received. <i>This element is always shown.</i>
variable-rqst-tx short name: variable/rqst-tx	Parameter type: <Counter> - 32 bit counter	number of variable request OAMPDUs transmitted. <i>This element is always shown.</i>
variable-rsp-rx	Parameter type: <Counter>	number of variable response

name	Type	Description
short name: variable/rsp-rx	- 32 bit counter	OAMPDUs received. <i>This element is always shown.</i>
loopback-control-tx short name: loopback-ctrl/tx	Parameter type: <Counter> - 32 bit counter	number of Loopback Control OAMPDUs transmitted on this interface. <i>This element is always shown.</i>
unsup-codes-rx short name: unsup-codes/rx	Parameter type: <Counter> - 32 bit counter	number of OAMPDUs received with an unsupported op-code. <i>This element is always shown.</i>
org-spec-pdu-tx short name: org-spec-pdu/tx	Parameter type: <Counter> - 32 bit counter	number of org spec OAMPDUs transmitted on this interface. <i>This element is only shown in detail mode.</i>
org-spec-pdu-rx short name: org-spec-pdu/rx	Parameter type: <Counter> - 32 bit counter	number of org spec OAMPDUs received on this interface. <i>This element is only shown in detail mode.</i>

141.7 Efm Oam loopback Status Command

Command Description

This command displays the EFM OAM loopback status.

User Level

The command can be accessed by operators with transport privileges.

Command Syntax

The command has the following syntax:

```
> show efm-oam loopback-info [ (interface) ]
```

Command Parameters

Table 141.7-1 "Efm Oam loopback Status Command" Resource Parameters

Resource Identifier	Type	Description
(interface)	Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number	identification of the EFM port / Ethernet port

Command Output

Table 141.7-2 "Efm Oam loopback Status Command" Display parameters

Specific Information		
name	Type	Description
loopback-status	Parameter type: <Ether::LoopbackStatus> (no-loopback initiating-loopback terminating-loopback remote-loopback unknown) Possible values: - no-loopback : no loopback - initiating-loopback : remote loopback is initiated - terminating-loopback : termination of remote loopback ongoing	loopback status of the OAM entity <i>This element is always shown.</i>

name	Type	Description
	- remote-loopback : peer device on this interface is in remote loopback. - unknown : unknown	
parser-action	Parameter type: <Ether::ParserAction> (discard forward) Possible values: - discard : discard looped back packets - forward : forward looped back packets	Loopback parser action <i>This element is always shown.</i>
loopback-timeout	Parameter type: <Ether::LoopbackTimeout> - A timeout value expressed in seconds - unit: seconds - range: [0...3600]	Timeout value for auto clearing remote Loopback configuration. <i>This element is always shown.</i>
loopbck-remaining-time	Parameter type: <Ether::LoopbackRemainingTimeout> - A timeout value expressed in seconds - unit: seconds - range: [0...3600]	Remaining remote loopback timeout time. <i>This element is always shown.</i>

141.8 Efm Oam Internal Traffic generator Status Command

Command Description

Obsolete command.

User Level

The command can be accessed by operators with transport privileges.

Command Syntax

The command has the following syntax:

```
> show efm-oam int-traff-gen [ (interface) ]
```

Obsolete command.

Command Parameters

Table 141.8-1 "Efm Oam Internal Traffic generator Status Command" Resource Parameters

Resource Identifier	Type	Description
(interface)	Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number	identification of the EFM port / Ethernet port

Command Output

Table 141.8-2 "Efm Oam Internal Traffic generator Status Command" Display parameters

Specific Information		
name	Type	Description
state	Parameter type: <Ether::TraffGenState> (active not-active) Possible values: - active : Internal traffic generator on specified itf is active - not-active : Internal traffic generator on specified itf is not	State of the internal traffic generator for the specified interface. <i>This element is always shown.</i>

name	Type	Description
	active	
data-length	Parameter type: <Ether::TraffGenDataLengthType> - A value of 1 up to 1500. Indicates length in bytes. - unit: byte - range: [1...1500]	Length of data field, in bytes, of the generated test traffic. <i>This element is always shown.</i>
bitrate	Parameter type: <Ether::TraffGenBitRateType> (100k 1m 10m 100m 1g) Possible values: - 100k : bitrate = 100K bit/sec - 1m : bitrate = 1M bit/sec - 10m : bitrate = 10M bit/sec - 100m : bitrate = 100M bit/sec - 1g : bitrate = 1G bit/sec	Requested bitrate for the generated test traffic. <i>This element is always shown.</i>
smac	Parameter type: <Ether::MacAddr> - mac address (aa:bb:cc:a1:02:03) - length: 6	Source MAC address of the generated test traffic. <i>This element is only shown in detail mode.</i>
dmac	Parameter type: <Ether::MacAddr> - mac address (aa:bb:cc:a1:02:03) - length: 6	Destination MAC address of the generated test traffic. <i>This element is only shown in detail mode.</i>

142- DHCP Relay Status Commands

142.1 DHCP Relay Status Command Tree	142-6211
142.2 DHCP Relay Port Statistics	142-6212
142.3 DHCP Relay Port Statistics Related To Vlan Ports	142-6214
142.4 DHCP Relay Port Summary Statistics Related To Vlan Ports	142-6216
142.5 DHCP Relay Port Detailed Statistics Related To Vlan Ports	142-6219
142.6 DHCP v6 Relay Port Statistics	142-6226
142.7 DHCP v6 Relay Port Statistics Related To Vlan Ports	142-6228
142.8 DHCP v6 Relay Port Summary Statistics Related To Vlan Ports	142-6230
142.9 DHCP v6 Relay Port Detailed Statistics Related To Vlan Ports	142-6233
142.10 DHCP Relay Session Status Command	142-6238

142.1 DHCP Relay Status Command Tree

Description

This chapter gives an overview of nodes that are handled by "DHCP Relay Status Commands".

Command Tree

```
----show
  ----dhcp-relay
    ----port-stats
      - (port-interface)
        ----vlan
          - (subscr-vlan)
            ----summary
            ----extensive
    ----v6-port-stats
      - (port-interface)
        ----vlan
          - (subscr-vlan)
            ----v6summary
            ----v6extensive
  ----session
    - (client)
    - ip-addr
```

142.2 DHCP Relay Port Statistics

Command Description

This command allows the operator to view the DHCP relay port counters. When this show command is invoked, all commands in underlying nodes are automatically executed.

User Level

The command can be accessed by operators with dhcp privileges.

Command Syntax

The command has the following syntax:

```
> show dhcp-relay port-stats [ (port-interface) ]
```

Command Parameters

Table 142.2-1 "DHCP Relay Port Statistics" Resource Parameters

Resource Identifier	Type	Description
(port-interface)	Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::VpiId> : <Eqpt::VciId> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> / <Eqpt::OntPortId> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / voip <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / vuni <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::LLId> ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / <Eqpt::Ng2OntSlotId> / <Eqpt::Ng2OntPortId> ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / vuni) Possible values: - ng2 : ngpon2 style identification Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId>	user port interface

Resource Identifier	Type	Description
	- the port number - Field type <Eqpt::VpiId> - atm VPI - Field type <Eqpt::VciId> - atm VCI - Field type <Eqpt::ChannelGroupId> - the channel group identifier - Field type <Eqpt::SubChannelGroupId> - the subchannel group identifier - Field type <Eqpt::PonId> - the PON identifier - Field type <Eqpt::OntId> - the ONT identifier - Field type <Eqpt::Ng2OntId> - the NG2 ONT identifier - Possible values: - voip : virtual uni identifier - obsolete alternative replaced by vuni - vuni : virtual uni identifier - Possible values: - vuni : virtual NGPON2 uni identifier - Field type <Eqpt::OntSlotId> - the ONT SLOT identifier - Field type <Eqpt::OntPortId> - the ONT PORT identifier - Field type <Eqpt::Ng2OntSlotId> - the NGPON2 ONT SLOT identifier - Field type <Eqpt::Ng2OntPortId> - the NGPON2 ONT PORT identifier - Field type <Eqpt::LLId> - the LLID identifier, range 1 for EPON, range 1-8 for DPOE	

142.3 DHCP Relay Port Statistics Related To Vlan Ports

Command Description

This command allows the operator to view the DHCP relay port counters. The command will show all counters related to the specified vlan tagged frames.

Both the summary and detailed counters are shown through the underlying nodes.

The detailed counters are only available when the counters are enabled via the related configuration command.

User Level

The command can be accessed by operators with dhcp privileges.

Command Syntax

The command has the following syntax:

```
> show dhcp-relay port-stats (port-interface) vlan [ (subscr-vlan) ]
```

Command Parameters

Table 142.3-1 "DHCP Relay Port Statistics Related To Vlan Ports" Resource Parameters

Resource Identifier	Type	Description
(port-interface)	Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::VpiId> : <Eqpt::VciId> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> / <Eqpt::OntPortId> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / voip <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / vuni <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::LLId> ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / <Eqpt::Ng2OntSlotId> / <Eqpt::Ng2OntPortId> ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / vuni) Possible values: - ng2 : ngpon2 style identification Field type <Eqpt::RackId>	user port interface

Resource Identifier	Type	Description
	- the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number Field type <Eqpt::VpiId> - atm VPI Field type <Eqpt::VciId> - atm VCI Field type <Eqpt::ChannelGroupId> - the channel group identifier Field type <Eqpt::SubChannelGroupId> - the subchannel group identifier Field type <Eqpt::PonId> - the PON identifier Field type <Eqpt::OntId> - the ONT identifier Field type <Eqpt::Ng2OntId> - the NG2 ONT identifier Possible values: - voip : virtual uni identifier obsolete alternative replaced by vuni - vuni : virtual uni identifier Possible values: - vuni : virtual NGPON2 uni identifier Field type <Eqpt::OntSlotId> - the ONT SLOT identifier Field type <Eqpt::OntPortId> - the ONT PORT identifier Field type <Eqpt::Ng2OntSlotId> - the NGPON2 ONT SLOT identifier Field type <Eqpt::Ng2OntPortId> - the NGPON2 ONT PORT identifier Field type <Eqpt::LLId> - the LLID identifier, range 1 for EPON, range 1-8 for DPOE	
(subscr-vlan)	Format: (<Vlan::UVlanIndex> stacked : <Vlan::SVlanIndex> : <Vlan::CVlanIndex>) Possible values: - stacked : stacked vlan identity Field type <Vlan::UVlanIndex> - unstacked vlan identity - range: [1...4093,4096] Field type <Vlan::SVlanIndex> - service vlan identity - range: [2...4093] Field type <Vlan::CVlanIndex> - customer vlan identity - range: [0...4093]	the subscriber vlan id

142.4 DHCP Relay Port Summary Statistics Related To Vlan Ports

Command Description

This command allows the operator to view the DHCP relay port counters. The command will show all counters related to the specified vlan tagged frames. These summary counters are always available.

User Level

The command can be accessed by operators with dhcp privileges.

Command Syntax

The command has the following syntax:

```
> show dhcp-relay port-stats (port-interface) vlan (subscr-vlan) summary
```

Command Parameters

Table 142.4-1 "DHCP Relay Port Summary Statistics Related To Vlan Ports" Resource Parameters

Resource Identifier	Type	Description
(port-interface)	Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::VpiId> : <Eqpt::VciId> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> / <Eqpt::OntPortId> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / voip <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / vuni <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::LLId> ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / <Eqpt::Ng2OntSlotId> / <Eqpt::Ng2OntPortId> ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / vuni) Possible values: - ng2 : ngpon2 style identification Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number	user port interface

Resource Identifier	Type	Description
	Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number Field type <Eqpt::VpiId> - atm VPI Field type <Eqpt::Vcild> - atm VCI Field type <Eqpt::ChannelGroupId> - the channel group identifier Field type <Eqpt::SubChannelGroupId> - the subchannel group identifier Field type <Eqpt::PonId> - the PON identifier Field type <Eqpt::OntId> - the ONT identifier Field type <Eqpt::Ng2OntId> - the NG2 ONT identifier Possible values: - voip : virtual uni identifier obsolete alternative replaced by vuni - vuni : virtual uni identifier Possible values: - vuni : virtual NGPON2 uni identifier Field type <Eqpt::OntSlotId> - the ONT SLOT identifier Field type <Eqpt::OntPortId> - the ONT PORT identifier Field type <Eqpt::Ng2OntSlotId> - the NGPON2 ONT SLOT identifier Field type <Eqpt::Ng2OntPortId> - the NGPON2 ONT PORT identifier Field type <Eqpt::LLId> - the LLID identifier, range 1 for EPON, range 1-8 for DPOE	
(subscr-vlan)	Format: (<Vlan::UVlanIndex> stacked : <Vlan::SVlanIndex> : <Vlan::CVlanIndex>) Possible values: - stacked : stacked vlan identity Field type <Vlan::UVlanIndex> - unstacked vlan identity - range: [1...4093,4096] Field type <Vlan::SVlanIndex> - service vlan identity - range: [2...4093] Field type <Vlan::CVlanIndex> - customer vlan identity - range: [0...4093]	the subscriber vlan id

Command Output

Table 142.4-2 "DHCP Relay Port Summary Statistics Related To Vlan Ports" Display parameters

Specific Information		
name	Type	Description
error-summary	Parameter type: <Counter> - 32 bit counter	show the total of DHCP packets that have been dropped because

142 DHCP Relay Status Commands

name	Type	Description
		of errors <i>This element is only shown in detail mode.</i>
total-in	Parameter type: <Counter> - 32 bit counter	show count of all DHCP packets that have been received <i>This element is only shown in detail mode.</i>
total-out	Parameter type: <Counter> - 32 bit counter	show count of all DHCP packets that have been sent <i>This element is only shown in detail mode.</i>

142.5 DHCP Relay Port Detailed Statistics Related To Vlan Ports

Command Description

This command allows the operator to view the DHCP relay port counters. The command will show all counters related to the specified vlan tagged frames.

The detailed counters are only given when the counters are enabled via the related configuration command.

User Level

The command can be accessed by operators with dhcp privileges.

Command Syntax

The command has the following syntax:

> show dhcp-relay port-stats (port-interface) vlan (subscr-vlan) extensive

Command Parameters

Table 142.5-1 "DHCP Relay Port Detailed Statistics Related To Vlan Ports" Resource Parameters

Resource Identifier	Type	Description
(port-interface)	Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::Vpild> : <Eqpt::VciId> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> / <Eqpt::OntPortId> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / voip <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / vuni <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::LLId> ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / <Eqpt::Ng2OntSlotId> / <Eqpt::Ng2OntPortId> ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / vuni) Possible values: - ng2 : ngpon2 style identification Field type <Eqpt::RackId> - the rack number	user port interface

Resource Identifier	Type	Description
	Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number Field type <Eqpt::VpId> - atm VPI Field type <Eqpt::VciId> - atm VCI Field type <Eqpt::ChannelGroupId> - the channel group identifier Field type <Eqpt::SubChannelGroupId> - the subchannel group identifier Field type <Eqpt::PonId> - the PON identifier Field type <Eqpt::OntId> - the ONT identifier Field type <Eqpt::Ng2OntId> - the NG2 ONT identifier Possible values: - voip : virtual uni identifier obsolete alternative replaced by vuni - vuni : virtual uni identifier Possible values: - vuni : virtual NGPON2 uni identifier Field type <Eqpt::OntSlotId> - the ONT SLOT identifier Field type <Eqpt::OntPortId> - the ONT PORT identifier Field type <Eqpt::Ng2OntSlotId> - the NGPON2 ONT SLOT identifier Field type <Eqpt::Ng2OntPortId> - the NGPON2 ONT PORT identifier Field type <Eqpt::LLId> - the LLID identifier, range 1 for EPON, range 1-8 for DPOE	
(subscr-vlan)	Format: (<Vlan::UVlanIndex> stacked : <Vlan::SVlanIndex> : <Vlan::CVlanIndex>) Possible values: - stacked : stacked vlan identity Field type <Vlan::UVlanIndex> - unstacked vlan identity - range: [1...4093,4096] Field type <Vlan::SVlanIndex> - service vlan identity - range: [2...4093] Field type <Vlan::CVlanIndex> - customer vlan identity - range: [0...4093]	the subscriber vlan id

Command Output

Table 142.5-2 "DHCP Relay Port Detailed Statistics Related To Vlan Ports" Display parameters

Specific Information

name	Type	Description
internal-ctxt-err	Parameter type: <CounterWithDefaultValue> ((not-available na) <CounterWithDefaultValue>) Possible values: - not-available : counter value is not applicable for this type of board - na : counter value is not applicable for this type of board Field type <CounterWithDefaultValue> - Number of times mac filter is matched - range: [0...4294967294]	show the number of ARP packets dropped due to internal context errors <i>This element is only shown in detail mode.</i>
up-corrupt-pkt	Parameter type: <CounterWithDefaultValue> ((not-available na) <CounterWithDefaultValue>) Possible values: - not-available : counter value is not applicable for this type of board - na : counter value is not applicable for this type of board Field type <CounterWithDefaultValue> - Number of times mac filter is matched - range: [0...4294967294]	show the number of upstream DHCP packets classified as corrupt and discarded <i>This element is only shown in detail mode.</i>
up-invalid-l2-PROTO	Parameter type: <CounterWithDefaultValue> ((not-available na) <CounterWithDefaultValue>) Possible values: - not-available : counter value is not applicable for this type of board - na : counter value is not applicable for this type of board Field type <CounterWithDefaultValue> - Number of times mac filter is matched - range: [0...4294967294]	show the number of upstream DHCP packets discarded due to invalid Layer 2 protocol configuration <i>This element is only shown in detail mode.</i>
up-unsupp-l3-PROTO	Parameter type: <CounterWithDefaultValue> ((not-available na) <CounterWithDefaultValue>) Possible values: - not-available : counter value is not applicable for this type of board - na : counter value is not applicable for this type of board Field type <CounterWithDefaultValue> - Number of times mac filter is matched - range: [0...4294967294]	show the number of upstream DHCP packets discarded due to unsupported protocol version <i>This element is only shown in detail mode.</i>
up-large-pkt-discard	Parameter type: <CounterWithDefaultValue> ((not-available na) <CounterWithDefaultValue>) Possible values: - not-available : counter value is not applicable for this type of board - na : counter value is not applicable for this type of board Field type <CounterWithDefaultValue> - Number of times mac filter is matched - range: [0...4294967294]	show the number of upstream DHCP packets discarded due to packet size exceeds the MTU <i>This element is only shown in detail mode.</i>
up-frag-pkt-discard	Parameter type: <CounterWithDefaultValue> ((not-available na) <CounterWithDefaultValue>) Possible values: - not-available : counter value is not applicable for this type of board - na : counter value is not applicable for this type of board	show the number of upstream DHCP packets discarded due to received fragmented packet <i>This element is only shown in detail mode.</i>

142 DHCP Relay Status Commands

name	Type	Description
	Field type <CounterWithDefaultValue> - Number of times mac filter is matched - range: [0...4294967294]	
up-malformed-option	Parameter type: <CounterWithDefaultValue> ((not-available na) <CounterWithDefaultValue>) Possible values: - not-available : counter value is not applicable for this type of board - na : counter value is not applicable for this type of board Field type <CounterWithDefaultValue> - Number of times mac filter is matched - range: [0...4294967294]	show the number of upstream DHCP packets discarded due to malformed 'options' field <i>This element is only shown in detail mode.</i>
up-invalid-hops	Parameter type: <CounterWithDefaultValue> ((not-available na) <CounterWithDefaultValue>) Possible values: - not-available : counter value is not applicable for this type of board - na : counter value is not applicable for this type of board Field type <CounterWithDefaultValue> - Number of times mac filter is matched - range: [0...4294967294]	show the number of upstream DHCP packets discarded due to inconsistency between 'giaddr' field and 'hops' field <i>This element is only shown in detail mode.</i>
up-invalid-op-code	Parameter type: <CounterWithDefaultValue> ((not-available na) <CounterWithDefaultValue>) Possible values: - not-available : counter value is not applicable for this type of board - na : counter value is not applicable for this type of board Field type <CounterWithDefaultValue> - Number of times mac filter is matched - range: [0...4294967294]	show the number of upstream DHCP packets discarded due to invalid opcode in packet header <i>This element is only shown in detail mode.</i>
up-not-allowed-pkt	Parameter type: <CounterWithDefaultValue> ((not-available na) <CounterWithDefaultValue>) Possible values: - not-available : counter value is not applicable for this type of board - na : counter value is not applicable for this type of board Field type <CounterWithDefaultValue> - Number of times mac filter is matched - range: [0...4294967294]	show the number of upstream DHCP packets discarded due to invalid packet type <i>This element is only shown in detail mode.</i>
up-opt82-too-long	Parameter type: <CounterWithDefaultValue> ((not-available na) <CounterWithDefaultValue>) Possible values: - not-available : counter value is not applicable for this type of board - na : counter value is not applicable for this type of board Field type <CounterWithDefaultValue> - Number of times mac filter is matched - range: [0...4294967294]	show the number of received packets that exceed the MTU after Option 82 insertion <i>This element is only shown in detail mode.</i>
up-not-trusted	Parameter type: <CounterWithDefaultValue> ((not-available na) <CounterWithDefaultValue>) Possible values:	show the number of upstream DHCP packets discarded due to unexpected presence of Option 82

name	Type	Description
	- not-available : counter value is not applicable for this type of board - na : counter value is not applicable for this type of board Field type <CounterWithDefaultValue> - Number of times mac filter is matched - range: [0...4294967294]	<i>This element is only shown in detail mode.</i>
up-invalid-chaddr	Parameter type: <CounterWithDefaultValue> ((not-available na) <CounterWithDefaultValue>) Possible values: - not-available : counter value is not applicable for this type of board - na : counter value is not applicable for this type of board Field type <CounterWithDefaultValue> - Number of times mac filter is matched - range: [0...4294967294]	show the number of upstream DHCP packets discarded due to client invalid hardware address <i>This element is only shown in detail mode.</i>
up-dup-chaddr	Parameter type: <CounterWithDefaultValue> ((not-available na) <CounterWithDefaultValue>) Possible values: - not-available : counter value is not applicable for this type of board - na : counter value is not applicable for this type of board Field type <CounterWithDefaultValue> - Number of times mac filter is matched - range: [0...4294967294]	show the number of upstream DHCP packets discarded due to duplicate client hardware address <i>This element is only shown in detail mode.</i>
up-invalid-giaddr	Parameter type: <CounterWithDefaultValue> ((not-available na) <CounterWithDefaultValue>) Possible values: - not-available : counter value is not applicable for this type of board - na : counter value is not applicable for this type of board Field type <CounterWithDefaultValue> - Number of times mac filter is matched - range: [0...4294967294]	show the number of upstream DHCP packets discarded due to IP anti-spoofing failure for 'giaddr' field <i>This element is only shown in detail mode.</i>
up-invalid-ciaddr	Parameter type: <CounterWithDefaultValue> ((not-available na) <CounterWithDefaultValue>) Possible values: - not-available : counter value is not applicable for this type of board - na : counter value is not applicable for this type of board Field type <CounterWithDefaultValue> - Number of times mac filter is matched - range: [0...4294967294]	show the number of upstream DHCP packets discarded due to IP anti-spoofing failure for 'ciaddr' field <i>This element is only shown in detail mode.</i>
up-no-free-context	Parameter type: <CounterWithDefaultValue> ((not-available na) <CounterWithDefaultValue>) Possible values: - not-available : counter value is not applicable for this type of board - na : counter value is not applicable for this type of board Field type <CounterWithDefaultValue> - Number of times mac filter is matched - range: [0...4294967294]	show number of upstream DHCP packets discarded due to free session context is unavailable <i>This element is only shown in detail mode.</i>
up-no-assoc-context	Parameter type: <CounterWithDefaultValue>	show the number of upstream

142 DHCP Relay Status Commands

name	Type	Description
	((not-available na) <CounterWithDefaultValue>) Possible values: - not-available : counter value is not applicable for this type of board - na : counter value is not applicable for this type of board Field type <CounterWithDefaultValue> - Number of times mac filter is matched - range: [0...4294967294]	DHCP packets discarded for which no session context could be associated <i>This element is only shown in detail mode.</i>
up-relay-agent-un supp	Parameter type: <CounterWithDefaultValue> ((not-available na) <CounterWithDefaultValue>) Possible values: - not-available : counter value is not applicable for this type of board - na : counter value is not applicable for this type of board Field type <CounterWithDefaultValue> - Number of times mac filter is matched - range: [0...4294967294]	show the number of upstream DHCP packets discarded due to already been relayed by another relay agent <i>This element is only shown in detail mode.</i>
up-no-broadcast-vlan	Parameter type: <CounterWithDefaultValue> ((not-available na) <CounterWithDefaultValue>) Possible values: - not-available : counter value is not applicable for this type of board - na : counter value is not applicable for this type of board Field type <CounterWithDefaultValue> - Number of times mac filter is matched - range: [0...4294967294]	show the number of upstream DHCP packets discarded due to no Upstream broadcast Vlan configured <i>This element is only shown in detail mode.</i>
dn-not-trusted	Parameter type: <CounterWithDefaultValue> ((not-available na) <CounterWithDefaultValue>) Possible values: - not-available : counter value is not applicable for this type of board - na : counter value is not applicable for this type of board Field type <CounterWithDefaultValue> - Number of times mac filter is matched - range: [0...4294967294]	show the number of downstream DHCP packets discarded due to unexpected presence of Option 82 <i>This element is only shown in detail mode.</i>
dn-invalid-yiaddr	Parameter type: <CounterWithDefaultValue> ((not-available na) <CounterWithDefaultValue>) Possible values: - not-available : counter value is not applicable for this type of board - na : counter value is not applicable for this type of board Field type <CounterWithDefaultValue> - Number of times mac filter is matched - range: [0...4294967294]	show the number of downstream DHCP packets discarded due to invalid client IP address <i>This element is only shown in detail mode.</i>
dn-invalid-server-resp	Parameter type: <CounterWithDefaultValue> ((not-available na) <CounterWithDefaultValue>) Possible values: - not-available : counter value is not applicable for this type of board - na : counter value is not applicable for this type of board Field type <CounterWithDefaultValue>	show the number of downstream DHCP packets discarded due to invalid DHCP Server response received <i>This element is only shown in detail mode.</i>

name	Type	Description
	- Number of times mac filter is matched - range: [0...4294967294]	
dn-no-free-context	Parameter type: <CounterWithDefaultValue> ((not-available na) <CounterWithDefaultValue>) Possible values: - not-available : counter value is not applicable for this type of board - na : counter value is not applicable for this type of board Field type <CounterWithDefaultValue> - Number of times mac filter is matched - range: [0...4294967294]	show number of downstream DHCP packets discarded due to free session context is unavailable <i>This element is only shown in detail mode.</i>
option82-inserted	Parameter type: <CounterWithDefaultValue> ((not-available na) <CounterWithDefaultValue>) Possible values: - not-available : counter value is not applicable for this type of board - na : counter value is not applicable for this type of board Field type <CounterWithDefaultValue> - Number of times mac filter is matched - range: [0...4294967294]	show the number of all DHCP packets received in the upstream and successfully inserted with option 82 <i>This element is only shown in detail mode.</i>
option82-removed	Parameter type: <CounterWithDefaultValue> ((not-available na) <CounterWithDefaultValue>) Possible values: - not-available : counter value is not applicable for this type of board - na : counter value is not applicable for this type of board Field type <CounterWithDefaultValue> - Number of times mac filter is matched - range: [0...4294967294]	show the number of all DHCP packets received in the downstream from which option 82 has been successfully removed <i>This element is only shown in detail mode.</i>
active-snooped-session	Parameter type: <CounterWithDefaultValue> ((not-available na) <CounterWithDefaultValue>) Possible values: - not-available : counter value is not applicable for this type of board - na : counter value is not applicable for this type of board Field type <CounterWithDefaultValue> - Number of times mac filter is matched - range: [0...4294967294]	show the number of all the DHCP sessions that have been established and are currently being snooped <i>This element is only shown in detail mode.</i>
total-snooped-session	Parameter type: <CounterWithDefaultValue> ((not-available na) <CounterWithDefaultValue>) Possible values: - not-available : counter value is not applicable for this type of board - na : counter value is not applicable for this type of board Field type <CounterWithDefaultValue> - Number of times mac filter is matched - range: [0...4294967294]	show the number of all the DHCP sessions that have been established and are being or have been snooped <i>This element is only shown in detail mode.</i>

142.6 DHCP v6 Relay Port Statistics

Command Description

This command allows the operator to view the DHCP v6 relay port counters. When this show command is invoked, all commands in underlying nodes are automatically executed.

User Level

The command can be accessed by operators with dhcp privileges.

Command Syntax

The command has the following syntax:

```
> show dhcp-relay v6-port-stats [ (port-interface) ]
```

Command Parameters

Table 142.6-1 "DHCP v6 Relay Port Statistics" Resource Parameters

Resource Identifier	Type	Description
(port-interface)	Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::VpiId> : <Eqpt::VciId> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> / <Eqpt::OntPortId> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / voip <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / vuni <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::LLId> ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / <Eqpt::Ng2OntSlotId> / <Eqpt::Ng2OntPortId> ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / vuni) Possible values: - ng2 : ngpon2 style identification Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId>	user port interface

Resource Identifier	Type	Description
	- the port number - Field type <Eqpt::VpiId> - atm VPI - Field type <Eqpt::VciId> - atm VCI - Field type <Eqpt::ChannelGroupId> - the channel group identifier - Field type <Eqpt::SubChannelGroupId> - the subchannel group identifier - Field type <Eqpt::PonId> - the PON identifier - Field type <Eqpt::OntId> - the ONT identifier - Field type <Eqpt::Ng2OntId> - the NG2 ONT identifier - Possible values: - voip : virtual uni identifier - obsolete alternative replaced by vuni - vuni : virtual uni identifier - Possible values: - vuni : virtual NGPON2 uni identifier - Field type <Eqpt::OntSlotId> - the ONT SLOT identifier - Field type <Eqpt::OntPortId> - the ONT PORT identifier - Field type <Eqpt::Ng2OntSlotId> - the NGPON2 ONT SLOT identifier - Field type <Eqpt::Ng2OntPortId> - the NGPON2 ONT PORT identifier - Field type <Eqpt::LLId> - the LLID identifier, range 1 for EPON, range 1-8 for DPOE	

142.7 DHCP v6 Relay Port Statistics Related To Vlan Ports

Command Description

This command allows the operator to view the DHCP v6 relay port counters. The command will show all counters related to the specified vlan tagged frames.

Both the summary and detailed counters are shown through the underlying nodes.

The detailed counters are only available when the counters are enabled via the related configuration command.

User Level

The command can be accessed by operators with dhcp privileges.

Command Syntax

The command has the following syntax:

```
> show dhcp-relay v6-port-stats (port-interface) vlan [ (subscr-vlan) ]
```

Command Parameters

Table 142.7-1 "DHCP v6 Relay Port Statistics Related To Vlan Ports" Resource Parameters

Resource Identifier	Type	Description
(port-interface)	Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::VpiId> : <Eqpt::VciId> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> / <Eqpt::OntPortId> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / voip <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / vuni <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::LLId> ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / <Eqpt::Ng2OntSlotId> / <Eqpt::Ng2OntPortId> ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / vuni) Possible values: - ng2 : ngpon2 style identification Field type <Eqpt::RackId>	user port interface

Resource Identifier	Type	Description
	- the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number Field type <Eqpt::VpiId> - atm VPI Field type <Eqpt::VciId> - atm VCI Field type <Eqpt::ChannelGroupId> - the channel group identifier Field type <Eqpt::SubChannelGroupId> - the subchannel group identifier Field type <Eqpt::PonId> - the PON identifier Field type <Eqpt::OntId> - the ONT identifier Field type <Eqpt::Ng2OntId> - the NG2 ONT identifier Possible values: - voip : virtual uni identifier obsolete alternative replaced by vuni - vuni : virtual uni identifier Possible values: - vuni : virtual NGPON2 uni identifier Field type <Eqpt::OntSlotId> - the ONT SLOT identifier Field type <Eqpt::OntPortId> - the ONT PORT identifier Field type <Eqpt::Ng2OntSlotId> - the NGPON2 ONT SLOT identifier Field type <Eqpt::Ng2OntPortId> - the NGPON2 ONT PORT identifier Field type <Eqpt::LLId> - the LLID identifier, range 1 for EPON, range 1-8 for DPOE	
(subscr-vlan)	Format: (<Vlan::UVlanIndex> stacked : <Vlan::SVlanIndex> : <Vlan::CVlanIndex>) Possible values: - stacked : stacked vlan identity Field type <Vlan::UVlanIndex> - unstacked vlan identity - range: [1...4093,4096] Field type <Vlan::SVlanIndex> - service vlan identity - range: [2...4093] Field type <Vlan::CVlanIndex> - customer vlan identity - range: [0...4093]	the subscriber vlan id

142.8 DHCP v6 Relay Port Summary Statistics Related To Vlan Ports

Command Description

This command allows the operator to view the DHCP v6 relay port counters. The command will show all counters related to the specified vlan tagged frames. These summary counters are always available.

User Level

The command can be accessed by operators with dhcp privileges.

Command Syntax

The command has the following syntax:

```
> show dhcp-relay v6-port-stats (port-interface) vlan (subscr-vlan) v6summary
```

Command Parameters

Table 142.8-1 "DHCP v6 Relay Port Summary Statistics Related To Vlan Ports" Resource Parameters

Resource Identifier	Type	Description
(port-interface)	Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::VpiId> : <Eqpt::VciId> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> / <Eqpt::OntPortId> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / voip <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / vuni <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::LLId> ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / <Eqpt::Ng2OntSlotId> / <Eqpt::Ng2OntPortId> ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / vuni) Possible values: - ng2 : ngpon2 style identification Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId>	user port interface

Resource Identifier	Type	Description
	- the shelf number - Field type <Eqpt::SlotId> - the LT slot number - Field type <Eqpt::PortId> - the port number - Field type <Eqpt::VpiId> - atm VPI - Field type <Eqpt::VciId> - atm VCI - Field type <Eqpt::ChannelGroupId> - the channel group identifier - Field type <Eqpt::SubChannelGroupId> - the subchannel group identifier - Field type <Eqpt::PonId> - the PON identifier - Field type <Eqpt::OntId> - the ONT identifier - Field type <Eqpt::Ng2OntId> - the NG2 ONT identifier - Possible values: - voip : virtual uni identifier - obsolete alternative replaced by vuni - vuni : virtual uni identifier - Possible values: - vuni : virtual NGPON2 uni identifier - Field type <Eqpt::OntSlotId> - the ONT SLOT identifier - Field type <Eqpt::OntPortId> - the ONT PORT identifier - Field type <Eqpt::Ng2OntSlotId> - the NGPON2 ONT SLOT identifier - Field type <Eqpt::Ng2OntPortId> - the NGPON2 ONT PORT identifier - Field type <Eqpt::LLId> - the LLID identifier, range 1 for EPON, range 1-8 for DPOE	
(subscr-vlan)	Format: (<Vlan::UVlanIndex> stacked : <Vlan::SVlanIndex> : <Vlan::CVlanIndex>) Possible values: - stacked : stacked vlan identity Field type <Vlan::UVlanIndex> - unstacked vlan identity - range: [1...4093,4096] Field type <Vlan::SVlanIndex> - service vlan identity - range: [2...4093] Field type <Vlan::CVlanIndex> - customer vlan identity - range: [0...4093]	the subscriber vlan id

Command Output

Table 142.8-2 "DHCP v6 Relay Port Summary Statistics Related To Vlan Ports" Display parameters

Specific Information

142 DHCP Relay Status Commands

name	Type	Description
dhcpv6-error-summary	Parameter type: <Counter> - 32 bit counter	show the total of DHCP v6 packets that have been dropped because of errors <i>This element is only shown in detail mode.</i>

142.9 DHCP v6 Relay Port Detailed Statistics Related To Vlan Ports

Command Description

This command allows the operator to view the DHCP v6 relay port counters. The command will show all counters related to the specified vlan tagged frames.

The detailed counters are only given when the counters are enabled via the related configuration command.

User Level

The command can be accessed by operators with dhcp privileges.

Command Syntax

The command has the following syntax:

```
> show dhcp-relay v6-port-stats (port-interface) vlan (subscr-vlan) v6extensive
```

Command Parameters

Table 142.9-1 "DHCP v6 Relay Port Detailed Statistics Related To Vlan Ports" Resource Parameters

Resource Identifier	Type	Description
(port-interface)	Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::VpiId> : <Eqpt::VciId> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> / <Eqpt::OntPortId> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / voip <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / vuni <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::LLId> ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / <Eqpt::Ng2OntSlotId> / <Eqpt::Ng2OntPortId> ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / vuni) Possible values: - ng2 : ngpon2 style identification Field type <Eqpt::RackId>	user port interface

Resource Identifier	Type	Description
	- the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number Field type <Eqpt::VpiId> - atm VPI Field type <Eqpt::VciId> - atm VCI Field type <Eqpt::ChannelGroupId> - the channel group identifier Field type <Eqpt::SubChannelGroupId> - the subchannel group identifier Field type <Eqpt::PonId> - the PON identifier Field type <Eqpt::OntId> - the ONT identifier Field type <Eqpt::Ng2OntId> - the NG2 ONT identifier Possible values: - voip : virtual uni identifier obsolete alternative replaced by vuni - vuni : virtual uni identifier Possible values: - vuni : virtual NGPON2 uni identifier Field type <Eqpt::OntSlotId> - the ONT SLOT identifier Field type <Eqpt::OntPortId> - the ONT PORT identifier Field type <Eqpt::Ng2OntSlotId> - the NGPON2 ONT SLOT identifier Field type <Eqpt::Ng2OntPortId> - the NGPON2 ONT PORT identifier Field type <Eqpt::LLId> - the LLID identifier, range 1 for EPON, range 1-8 for DPOE	
(subscr-vlan)	Format: (<Vlan::UVlanIndex> stacked : <Vlan::SVlanIndex> : <Vlan::CVlanIndex>) Possible values: - stacked : stacked vlan identity Field type <Vlan::UVlanIndex> - unstacked vlan identity - range: [1...4093,4096] Field type <Vlan::SVlanIndex> - service vlan identity - range: [2...4093] Field type <Vlan::CVlanIndex> - customer vlan identity - range: [0...4093]	the subscriber vlan id

Command Output

Table 142.9-2 "DHCP v6 Relay Port Detailed Statistics Related To Vlan Ports" Display parameters

Specific Information

name	Type	Description
dhcipv6-up-corrupt-pkt	Parameter type: <Counter> - 32 bit counter	show the number of upstream DHCP v6 packets classified as corrupt and discarded <i>This element is only shown in detail mode.</i>
dhcipv6-up-lg-pkt-discd	Parameter type: <Counter> - 32 bit counter	show the number of upstream DHCPv6 packets discarded due to packet size exceeds the MTU <i>This element is only shown in detail mode.</i>
dhcipv6-up-not-allowed	Parameter type: <Counter> - 32 bit counter	show the number of upstream DHCPv6 packets discarded due to invalid packet type <i>This element is only shown in detail mode.</i>
dhcipv6-up-untrusted	Parameter type: <Counter> - 32 bit counter	show the number of Relay-Forward messages received from the untrusted client port <i>This element is only shown in detail mode.</i>
dhcipv6-up-opt18-too-lg	Parameter type: <Counter> - 32 bit counter	show the number of received packets that exceed the MTU after option-18 insertion <i>This element is only shown in detail mode.</i>
dhcipv6-up-opt37-too-lg	Parameter type: <Counter> - 32 bit counter	show the number of received packets that exceed the MTU after option-37 insertion <i>This element is only shown in detail mode.</i>
dhcipv6-up-opt53-too-lg	Parameter type: <Counter> - 32 bit counter	show the number of received packets that exceed the MTU after option-53 insertion <i>This element is only shown in detail mode.</i>
dhcipv6-dn-not-allowed	Parameter type: <Counter> - 32 bit counter	show the number of downstream DHCPv6 packets discarded due to invalid packet type <i>This element is only shown in detail mode.</i>
dhcipv6-opt18-inserted	Parameter type: <Counter> - 32 bit counter	show the number of all DHCPv6 packets received in the upstream and successfully inserted with option-18 <i>This element is only shown in detail mode.</i>
dhcipv6-opt37-inserted	Parameter type: <Counter> - 32 bit counter	show the number of all DHCPv6 packets received in the upstream and successfully inserted with option-37 <i>This element is only shown in detail mode.</i>
dhcipv6-opt53-inserted	Parameter type: <Counter> - 32 bit counter	show the number of all DHCPv6 packets received in the upstream and successfully inserted with option-53

142 DHCP Relay Status Commands

name	Type	Description
		<i>This element is only shown in detail mode.</i>
dhcpv6-opt18-removed	Parameter type: <Counter> - 32 bit counter	show the number of all DHCPv6 packets received in the downstream from which option-18 has been successfully removed <i>This element is only shown in detail mode.</i>
dhcpv6-opt37-removed	Parameter type: <Counter> - 32 bit counter	show the number of all DHCPv6 packets received in the downstream from which option-37 has been successfully removed <i>This element is only shown in detail mode.</i>
dhcpv6-opt53-removed	Parameter type: <Counter> - 32 bit counter	show the number of all DHCPv6 packets received in the downstream from which option-53 has been successfully removed <i>This element is only shown in detail mode.</i>
dhcpv6-dn-corrupt-pkt	Parameter type: <Counter> - 32 bit counter	show the number of downstream DHCP v6 packets classified as corrupt and discarded <i>This element is only shown in detail mode.</i>
dhcpv6dn-no-free-ctxt	Parameter type: <Counter> - 32 bit counter	show the number of DHCPv6 packets which were discarded in the downstream due to exceed max dimension <i>This element is only shown in detail mode.</i>
dhcpv6-up-opt17-too-lg	Parameter type: <CounterWithDefaultValue> ((not-available na) <CounterWithDefaultValue>) Possible values: - not-available : counter value is not applicable for this type of board - na : counter value is not applicable for this type of board Field type <CounterWithDefaultValue> - Number of times mac filter is matched - range: [0...4294967294]	show the number of received packets that exceed the MTU after option-17 insertion <i>This element is only shown in detail mode.</i>
dhcpv6-opt17-inserted	Parameter type: <CounterWithDefaultValue> ((not-available na) <CounterWithDefaultValue>) Possible values: - not-available : counter value is not applicable for this type of board - na : counter value is not applicable for this type of board Field type <CounterWithDefaultValue> - Number of times mac filter is matched - range: [0...4294967294]	show the number of all DHCPv6 packets received in the upstream and successfully inserted with option-17 <i>This element is only shown in detail mode.</i>
dhcpv6-opt17-removed	Parameter type: <CounterWithDefaultValue> ((not-available na) <CounterWithDefaultValue>)	show the number of all DHCPv6 packets received in the downstream from which

name	Type	Description
	Possible values: - not-available : counter value is not applicable for this type of board - na : counter value is not applicable for this type of board Field type <CounterWithDefaultValue> - Number of times mac filter is matched - range: [0...4294967294]	option-17 has been successfully removed <i>This element is only shown in detail mode.</i>

142.10 DHCP Relay Session Status Command

Command Description

This command displays the dhcp-sessions information.

Note: Once the remaining-lease timer has expired, there will be a delay of 30 seconds for the removal of the session. Until then, the traffic will be forwarded to the corresponding user interface.

User Level

The command can be accessed by operators with dhcp privileges.

Command Syntax

The command has the following syntax:

```
> show dhcp-relay session [ (client) [ ip-addr <Ip::V4Address> ] ]
```

Command Parameters

Table 142.10-1 "DHCP Relay Session Status Command" Resource Parameters

Resource Identifier	Type	Description
(client)	Format: (ipox : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::VpiId> : <Eqpt::VciId> ipox : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> ipox : vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::VpiId> : <Eqpt::VciId> : <Eqpt::UnstackedVlan> ipox : vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::UnstackedVlan> ipox : vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::VpiId> : <Eqpt::VciId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> ipox : vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlanport : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::VpiId> : <Eqpt::VciId> : <Eqpt::UnstackedVlan> vlanport : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::UnstackedVlan> vlanport : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::VpiId> : <Eqpt::VciId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlanport : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan>	Specifies the if-index uniquely indentifying each interface

Resource Identifier	Type	Description
	ipox : vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> / <Eqpt::OntPortId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> ipox : vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> / <Eqpt::OntPortId> : <Eqpt::UnstackedVlan> ipox : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> / <Eqpt::OntPortId> vlanport : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> / <Eqpt::OntPortId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlanport : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> / <Eqpt::OntPortId> : <Eqpt::UnstackedVlan> vlanport : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / voip : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlanport : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / vuni : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlanport : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / voip : <Eqpt::UnstackedVlan> vlanport : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / vuni : <Eqpt::UnstackedVlan> vlanport : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::LLId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlanport : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::LLId> : <Eqpt::UnstackedVlan> vlanport:ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / <Eqpt::Ng2OntSlotId> / <Eqpt::Ng2OntPortId> : <Eqpt::UnstackedVlan> vlanport:ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / <Eqpt::Ng2OntSlotId> / <Eqpt::Ng2OntPortId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlanport:ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / vuni) Possible values: - ipox : ip line interface (supported vlan for Unstacked [1..4093] and stacked cvlan [0..4093]) - vlanport : vlan port(supported vlan for Unstacked [1..4093] and stacked cvlan [0..4093]) - vlanport:ng2 : an NGPON2 vlan port Possible values: - vlan : vlan port Field type <Eqpt::RackId> - the rack number	

Resource Identifier	Type	Description
	Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number Field type <Eqpt::VpId> - atm VPI Field type <Eqpt::VciId> - atm VCI Field type <Eqpt::PonId> - the PON identifier Field type <Eqpt::OntId> - the ONT identifier Field type <Eqpt::ChannelGroupId> - the channel group identifier Field type <Eqpt::SubChannelGroupId> - the subchannel group identifier Field type <Eqpt::Ng2OntId> - the NG2 ONT identifier Possible values: - voip : virtual uni identifier obsolete alternative replaced by vuni - vuni : virtual uni identifier Possible values: - vuni : virtual NGPON2 uni identifier Field type <Eqpt::OntSlotId> - the ONT SLOT identifier Field type <Eqpt::OntPortId> - the ONT PORT identifier Field type <Eqpt::Ng2OntSlotId> - the NGPON2 ONT SLOT identifier Field type <Eqpt::Ng2OntPortId> - the NGPON2 ONT PORT identifier Field type <Eqpt::LLId> - the LLID identifier, range 1 for EPON, range 1-8 for DPOE Possible values: - stacked : stacked vlan identity Field type <Eqpt::UnstackedVlan> - unstacked vlan id Field type <Eqpt::SVlan> - service vlan id Field type <Eqpt::CVlan> - customer vlan id	
ip-addr	Parameter type: <Ip::V4Address> Format: - IPv4-address	client ip address assigned by dhcp server

Command Output

Table 142.10-2 "DHCP Relay Session Status Command" Display parameters

Specific Information		
name	Type	Description
subnet	Parameter type: <Ip::PrefixLength> - IP address prefix length - range: [0...30]	the subnet mask of the client ip address <i>This element is always shown.</i>

name	Type	Description
lease-time	Parameter type: <Ip::LeaseTimeInSec> - the lease time	time period for which DHCP server leases ip address to a client <i>This element is always shown.</i>
gateway-ip-addr	Parameter type: <Ip::V4Address> - IPv4-address	the gateway ip address <i>This element is only shown in detail mode.</i>
dhcp-ip-addr	Parameter type: <Ip::V4Address> - IPv4-address	ip address of dhcp server <i>This element is only shown in detail mode.</i>
forwarder-type	Parameter type: <Dhcp::ForwarderType> (layer2 layer3) Possible values: - layer2 : the session belongs to l2forwarder - layer3 : the session belongs to l3forwarder	the forwarder type to which this session belongs <i>This element is always shown.</i>
forwarder-id	Parameter type: <Dhcp::ForwarderId> (<DHCP::Layer> stacked : <Vlan::SVlanIndex> : <Vlan::CVlanIndex> vrf : <Vrf::UnsignedVrfIndex>) Possible values: - vrf : vrf identity - stacked : stacked vlan identity Field type <DHCP::Layer> - unstacked vlan identity - range: [1...4093] Field type <Vrf::UnsignedVrfIndex> - the VRF ID which uniquely identify a VRF - range: [1...127] Field type <Vlan::SVlanIndex> - service vlan identity - range: [2...4093,4094] Field type <Vlan::CVlanIndex> - customer vlan identity - range: [0...4093,4094,4095,4096]	the id of the forwarder to which this session belongs <i>This element is always shown.</i>
remaining-lease	Parameter type: <Ip::RemainingLeaseTimeInSec> ((session-being-deleted ses-deleting) <Ip::LeaseTimeInSec>) Possible values: - session-being-deleted : session being deleted - ses-deleting : session being deleted Field type <Ip::LeaseTimeInSec> - the lease time	remaining time period for which DHCP server leases ip address to a client <i>This element is always shown.</i>

143- Multicast Status Commands

143.1 Multicast Status Command Tree	143-6243
143.2 Multicast Active Groups Status Command	143-6244
143.3 Multicast Ipv6 Active Groups Status Command	143-6248
143.4 Multicast PON Active Groups Status Command	143-6252
143.5 Multicast ONT Active Groups Status Command	143-6256
143.6 Multicast Channel Pair Active Groups Status Command	143-6260
143.7 Multicast Group Membership Status Command	143-6264

143.1 Multicast Status Command Tree

Description

This chapter gives an overview of nodes that are handled by "Multicast Status Commands".

Command Tree

```

----show
  ----mcast
    ----active-groups
      - (port)
      - vlan-id
      - mcast-grp-addr
      - mcast-src-addr
    ----ipv6-active-groups
      - (port)
      - vlan-id
      - mcast-grp-addr
      - mcast-src-addr
    ----pon-active-groups
      - (pon-idx)
      - port
      - vlan-id
      - mcast-grp-addr
      - mcast-src-addr
    ----ont-active-groups
      - (ont-idx)
      - port
      - vlan-id
      - mcast-grp-addr
      - mcast-src-addr
    ----chpair-active-groups
      - (chpair-idx)
      - port
      - vlan-id
      - mcast-grp-addr
      - mcast-src-addr
    ----grp-membership
      - (mcast-grp-addr)
      - vlan-id
      - mcast-src-addr
      - port
  
```

143.2 Multicast Active Groups Status Command

Command Description

This command shows per user interface the list of active multicast streams.

User Level

The command can be accessed by operators with igmp privileges.

Command Syntax

The command has the following syntax:

```
> show mcast active-groups [ (port) [ vlan-id <Vlan::VlanId> ] [ mcast-grp-addr <Igmp::MulticastAddress> ] [ mcast-src-addr <Ip::V4Address> ] ]
```

Command Parameters

Table 143.2-1 "Multicast Active Groups Status Command" Resource Parameters

Resource Identifier	Type	Description
(port)	Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::VpiId> : <Eqpt::VciId> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::VpiId> : <Eqpt::VciId> : <Eqpt::UnstackedVlan> vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::UnstackedVlan> vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::VpiId> : <Eqpt::VciId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> / <Eqpt::OntPortId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> / <Eqpt::OntPortId> : <Eqpt::UnstackedVlan> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> / <Eqpt::OntPortId> vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / voip : stacked : <Eqpt::SVlan> : <Eqpt::CVlan>	identification of the port, vlanport or virtual channel

Resource Identifier	Type	Description
	vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / vuni : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / voip : <Eqpt::UnstackedVlan> vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / vuni : <Eqpt::UnstackedVlan> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / voip <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / vuni vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::LLId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::LLId> : <Eqpt::UnstackedVlan> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::LLId> vlan:ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / <Eqpt::Ng2OntSlotId> / <Eqpt::Ng2OntPortId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan:ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / <Eqpt::Ng2OntSlotId> / <Eqpt::Ng2OntPortId> : <Eqpt::UnstackedVlan>) Possible values: - vlan : vlan port - vlan:ng2 : ngpon2 vlan port Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number Field type <Eqpt::VpiId> - atm VPI Field type <Eqpt::Vcild> - atm VCI Field type <Eqpt::PonId> - the PON identifier Field type <Eqpt::ChannelGroupId> - the channel group identifier Field type <Eqpt::SubChannelGroupId> - the subchannel group identifier Field type <Eqpt::Ng2OntId> - the NG2 ONT identifier Field type <Eqpt::OntId> - the ONT identifier Possible values: - voip : virtual uni identifier obsolete alternative replaced by vuni	

Resource Identifier	Type	Description
	- vuni : virtual uni identifier Possible values: - vuni : virtual NGPON2 uni identifier Field type <Eqpt::OntSlotId> - the ONT SLOT identifier Field type <Eqpt::OntPortId> - the ONT PORT identifier Field type <Eqpt::Ng2OntSlotId> - the NGPON2 ONT SLOT identifier Field type <Eqpt::Ng2OntPortId> - the NGPON2 ONT PORT identifier Field type <Eqpt::LLId> - the LLID identifier, range 1 for EPON, range 1-8 for DPOE Possible values: - stacked : stacked vlan identity Field type <Eqpt::UnstackedVlan> - unstacked vlan id Field type <Eqpt::SVlan> - service vlan id Field type <Eqpt::CVlan> - customer vlan id	
vlan-id	Parameter type: <Vlan::VlanId> Format: - vlan id - range: [1...4093]	vlan Id
mcast-grp-addr	Parameter type: <Igmp::MulticastAddress> Format: - multicast-address (range: 224.0.0.3....239.255.255.255, except for 224.0.0.22)	class D address of the multicast stream
mcast-src-addr	Parameter type: <Ip::V4Address> Format: - IPv4-address	the multicast group source address

Command Output

Table 143.2-2 "Multicast Active Groups Status Command" Display parameters

Specific Information		
name	Type	Description
state	Parameter type: <Igmp::ActualState> (full-view pre-view black-out) Possible values: - full-view : full view of the stream - pre-view : preview of the stream - black-out : no stream is viewed	The actual state of the multicast stream <i>This element is always shown.</i>
curr-previewed-nbr short name: prev-nbr	Parameter type: <Igmp::PreviewNumber> - number of pre-view sessions already been viewed - range: [0...1000]	number of pre-view sessions that have already been viewed <i>This element is only shown in detail mode.</i>
status	Parameter type: <Igmp::McastStatus> (static static-dynamic dynamic) Possible values: - static : static entry	the current type of multicast group <i>This element is always shown.</i>

name	Type	Description
	- static-dynamic : static dynamic entry - dynamic : dynamic entry	
last-host-ip	Parameter type: <Igmp::MulticastLastHostIp> - IPv4-address	currently joined last HostIP for IGMP control channel <i>This element is only shown in detail mode.</i>

143.3 Multicast Ipv6 Active Groups Status Command

Command Description

This command shows per user interface the list of ipv6 active multicast streams.

User Level

The command can be accessed by operators with igmp privileges.

Command Syntax

The command has the following syntax:

```
> show mcast ipv6-active-groups [ (port) [ vlan-id <Vlan::VlanId> ] [ mcast-grp-addr <Ip::V6Prefix> ] [ mcast-src-addr <Ip::V6Prefix> ] ]
```

Command Parameters

Table 143.3-1 "Multicast Ipv6 Active Groups Status Command" Resource Parameters

Resource Identifier	Type	Description
(port)	Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::VpiId> : <Eqpt::VciId> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::VpiId> : <Eqpt::VciId> : <Eqpt::UnstackedVlan> vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::UnstackedVlan> vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::VpiId> : <Eqpt::VciId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> / <Eqpt::OntPortId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> / <Eqpt::OntPortId> : <Eqpt::UnstackedVlan> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> / <Eqpt::OntPortId>	identification of the port, vlanport or virtual channel

Resource Identifier	Type	Description
	<pre> vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / voip : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / vuni : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / voip : <Eqpt::UnstackedVlan> vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / vuni : <Eqpt::UnstackedVlan> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / voip <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / vuni vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::LLId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::LLId> : <Eqpt::UnstackedVlan> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::LLId> vlan:ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / <Eqpt::Ng2OntSlotId> / <Eqpt::Ng2OntPortId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan:ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / <Eqpt::Ng2OntSlotId> / <Eqpt::Ng2OntPortId> : <Eqpt::UnstackedVlan>) Possible values: - vlan : vlan port - vlan:ng2 : ngpon2 vlan port Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number Field type <Eqpt::VpiId> - atm VPI Field type <Eqpt::VciId> - atm VCI Field type <Eqpt::PonId> - the PON identifier Field type <Eqpt::ChannelGroupId> - the channel group identifier Field type <Eqpt::SubChannelGroupId> - the subchannel group identifier Field type <Eqpt::Ng2OntId> - the NG2 ONT identifier Field type <Eqpt::OntId> - the ONT identifier </pre>	

Resource Identifier	Type	Description
	Possible values: - voip : virtual uni identifier obsolete alternative replaced by vuni - vuni : virtual uni identifier Possible values: - vuni : virtual NGPON2 uni identifier Field type <Eqpt::OntSlotId> - the ONT SLOT identifier Field type <Eqpt::OntPortId> - the ONT PORT identifier Field type <Eqpt::Ng2OntSlotId> - the NGPON2 ONT SLOT identifier Field type <Eqpt::Ng2OntPortId> - the NGPON2 ONT PORT identifier Field type <Eqpt::LLId> - the LLID identifier, range 1 for EPON, range 1-8 for DPOE Possible values: - stacked : stacked vlan identity Field type <Eqpt::UnstackedVlan> - unstacked vlan id Field type <Eqpt::SVlan> - service vlan id Field type <Eqpt::CVlan> - customer vlan id	
vlan-id	Parameter type: <Vlan::VlanId> Format: - vlan id - range: [1...4093]	vlan Id
mcast-grp-addr	Parameter type: <Ip::V6Prefix> Format: - IPv6-address	ipv6 address of the multicast stream
mcast-src-addr	Parameter type: <Ip::V6Prefix> Format: - IPv6-address	the multicast group source address

Command Output

Table 143.3-2 "Multicast Ipv6 Active Groups Status Command" Display parameters

Specific Information		
name	Type	Description
state	Parameter type: <Igmp::ActualState> (full-view pre-view black-out) Possible values: - full-view : full view of the stream - pre-view : preview of the stream - black-out : no stream is viewed	The actual state of the multicast stream <i>This element is only shown in detail mode.</i>
curr-previewed-nbr short name: prev-nbr	Parameter type: <Igmp::PreviewNumber> - number of pre-view sessions already been viewed - range: [0...1000]	number of pre-view sessions that have already been viewed <i>This element is only shown in detail mode.</i>
status	Parameter type: <Igmp::McastStatus> (static static-dynamic dynamic)	the current type of multicast group <i>This element is only shown in detail mode.</i>

name	Type	Description
	Possible values: - static : static entry - static-dynamic : static dynamic entry - dynamic : dynamic entry	

143.4 Multicast PON Active Groups Status Command

Command Description

This command shows per user interface on a particular PON the list of active multicast streams.

User Level

The command can be accessed by operators with igmp privileges.

Command Syntax

The command has the following syntax:

```
> show mcast pon-active-groups [ (pon-idx) [ port <Igmp::IgmpIfIndex> ] [ vlan-id <Vlan::VlanId> ] [ mcast-grp-addr <Igmp::MulticastAddress> ] [ mcast-src-addr <Ip::V4Address> ] ]
```

Command Parameters

Table 143.4-1 "Multicast PON Active Groups Status Command" Resource Parameters

Resource Identifier	Type	Description
(pon-idx)	Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> x-pon : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::XPonId> 25g-pon : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::M25GPonId>) Possible values: - 25g-pon : 25g pon - x-pon : Xgs pon Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Eqpt::XPonId> - the XGS PON identifier Field type <Eqpt::M25GPonId> - the 25G PON identifier	identification of the PON
port	Parameter type: <Igmp::IgmpIfIndex> Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> /	identification of the vlanport

Resource Identifier	Type	Description
	<pre> <Eqpt::PortId> : <Eqpt::VpId> : <Eqpt::VciId> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::VpId> : <Eqpt::VciId> : <Eqpt::UnstackedVlan> vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::UnstackedVlan> vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::VpId> : <Eqpt::VciId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> / <Eqpt::OntPortId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> / <Eqpt::OntPortId> : <Eqpt::UnstackedVlan> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> / <Eqpt::OntPortId> vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / voip : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / vuni : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / voip : <Eqpt::UnstackedVlan> vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / vuni : <Eqpt::UnstackedVlan> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / voip <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / vuni vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::LLId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::LLId> : <Eqpt::UnstackedVlan> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::LLId> vlan.ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / <Eqpt::Ng2OntSlotId> / <Eqpt::Ng2OntPortId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan.ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / <Eqpt::Ng2OntSlotId> / <Eqpt::Ng2OntPortId> : <Eqpt::UnstackedVlan>) Possible values: - vlan : vlan port </pre>	

143 Multicast Status Commands

Resource Identifier	Type	Description
	- vlan:ng2 : ngpon2 vlan port - Field type <Eqpt::RackId> - the rack number - Field type <Eqpt::ShelfId> - the shelf number - Field type <Eqpt::SlotId> - the LT slot number - Field type <Eqpt::PortId> - the port number - Field type <Eqpt::VpiId> - atm VPI - Field type <Eqpt::VciId> - atm VCI - Field type <Eqpt::PonId> - the PON identifier - Field type <Eqpt::ChannelGroupId> - the channel group identifier - Field type <Eqpt::SubChannelGroupId> - the subchannel group identifier - Field type <Eqpt::Ng2OntId> - the NG2 ONT identifier - Field type <Eqpt::OntId> - the ONT identifier - Possible values: - voip : virtual uni identifier - obsolete alternative replaced by vuni - vuni : virtual uni identifier - Possible values: - vuni : virtual NGPON2 uni identifier - Field type <Eqpt::OntSlotId> - the ONT SLOT identifier - Field type <Eqpt::OntPortId> - the ONT PORT identifier - Field type <Eqpt::Ng2OntSlotId> - the NGPON2 ONT SLOT identifier - Field type <Eqpt::Ng2OntPortId> - the NGPON2 ONT PORT identifier - Field type <Eqpt::LLId> - the LLID identifier,range 1 for EPON,range 1-8 for DPOE - Possible values: - stacked : stacked vlan identity - Field type <Eqpt::UnstackedVlan> - unstacked vlan id - Field type <Eqpt::SVlan> - service vlan id - Field type <Eqpt::CVlan> - customer vlan id	
vlan-id	Parameter type: <Vlan::VlanId> Format: - vlan id - range: [1...4093]	vlan id
mcast-grp-addr	Parameter type: <Igmp::MulticastAddress> Format: - multicast-address (range: 224.0.0.3....239.255.255.255, except for 224.0.0.22)	class D address of the multicast stream
mcast-src-addr	Parameter type: <Ip::V4Address> Format:	the multicast group source address

Resource Identifier	Type	Description
	- IPv4-address	

Command Output

Table 143.4-2 "Multicast PON Active Groups Status Command" Display parameters

Specific Information		
name	Type	Description
state	Parameter type: <Igmp::ActualState> (full-view pre-view black-out) Possible values: - full-view : full view of the stream - pre-view : preview of the stream - black-out : no stream is viewed	The actual state of the multicast stream <i>This element is always shown.</i>
curr-previewed-nbr short name: prev-nbr	Parameter type: <Igmp::PreviewNumber> - number of pre-view sessions already been viewed - range: [0...1000]	number of pre-view sessions that have already been viewed <i>This element is only shown in detail mode.</i>
status	Parameter type: <Igmp::McastStatus> (static static-dynamic dynamic) Possible values: - static : static entry - static-dynamic : static dynamic entry - dynamic : dynamic entry	the current type of multicast group <i>This element is always shown.</i>

143.5 Multicast ONT Active Groups Status Command

Command Description

This command shows per user interface on a particular ONT the list of active multicast streams.

User Level

The command can be accessed by operators with igmp privileges.

Command Syntax

The command has the following syntax:

```
> show mcast ont-active-groups [ (ont-idx) [ port <Igmp::IgmpIfIndex> ] [ vlan-id <Vlan::VlanId> ] [ mcast-grp-addr <Igmp::MulticastAddress> ] [ mcast-src-addr <Ip::V4Address> ] ]
```

Command Parameters

Table 143.5-1 "Multicast ONT Active Groups Status Command" Resource Parameters

Resource Identifier	Type	Description
(ont-idx)	Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> ng2 : <Ng2::ChannelGroup> / <Ng2::SubchannelGroup> / <Ng2::OntId>) Possible values: - ng2 : ngpon2 style identification Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Ng2::ChannelGroup> - channel group number Field type <Ng2::SubchannelGroup> - subchannel group number Field type <Eqpt::OntId> - the ONT identifier Field type <Ng2::OntId> - the ONT identifier	identification of the ONT
port	Parameter type: <Igmp::IgmpIfIndex> Format:	identification of the vlanport

Resource Identifier	Type	Description
	<pre> (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::VpId> : <Eqpt::VciId> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::VpId> : <Eqpt::VciId> : <Eqpt::UnstackedVlan> vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::UnstackedVlan> vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::VpId> : <Eqpt::VciId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> / <Eqpt::OntPortId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> / <Eqpt::OntPortId> : <Eqpt::UnstackedVlan> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> / <Eqpt::OntPortId> vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / voip : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / vuni : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / voip : <Eqpt::UnstackedVlan> vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / vuni : <Eqpt::UnstackedVlan> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / voip <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / vuni vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::LLId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::LLId> : <Eqpt::UnstackedVlan> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::LLId> vlan:ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / <Eqpt::Ng2OntSlotId> / <Eqpt::Ng2OntPortId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan:ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / <Eqpt::Ng2OntSlotId> / <Eqpt::Ng2OntPortId> : <Eqpt::UnstackedVlan>) Possible values: </pre>	

Resource Identifier	Type	Description
	- vlan : vlan port - vlan:ng2 : ngpon2 vlan port - Field type <Eqpt::RackId> - the rack number - Field type <Eqpt::ShelfId> - the shelf number - Field type <Eqpt::SlotId> - the LT slot number - Field type <Eqpt::PortId> - the port number - Field type <Eqpt::VpiId> - atm VPI - Field type <Eqpt::Vcild> - atm VCI - Field type <Eqpt::PonId> - the PON identifier - Field type <Eqpt::ChannelGroupId> - the channel group identifier - Field type <Eqpt::SubChannelGroupId> - the subchannel group identifier - Field type <Eqpt::Ng2OntId> - the NG2 ONT identifier - Field type <Eqpt::OntId> - the ONT identifier - Possible values: - voip : virtual uni identifier - obsolete alternative replaced by vuni - vuni : virtual uni identifier - Possible values: - vuni : virtual NGPON2 uni identifier - Field type <Eqpt::OntSlotId> - the ONT SLOT identifier - Field type <Eqpt::OntPortId> - the ONT PORT identifier - Field type <Eqpt::Ng2OntSlotId> - the NGPON2 ONT SLOT identifier - Field type <Eqpt::Ng2OntPortId> - the NGPON2 ONT PORT identifier - Field type <Eqpt::LLId> - the LLID identifier, range 1 for EPON, range 1-8 for DPOE - Possible values: - stacked : stacked vlan identity - Field type <Eqpt::UnstackedVlan> - unstacked vlan id - Field type <Eqpt::SVlan> - service vlan id - Field type <Eqpt::CVlan> - customer vlan id	
vlan-id	Parameter type: <Vlan::VlanId> Format: - vlan id - range: [1...4093]	vlan Id
mcast-grp-addr	Parameter type: <Igmp::MulticastAddress> Format: - multicast-address (range: 224.0.0.3....239.255.255.255, except for 224.0.0.22)	class D address of the multicast stream
mcast-src-addr	Parameter type: <Ip::V4Address>	the multicast group source

Resource Identifier	Type	Description
	Format: - IPv4-address	address

Command Output

Table 143.5-2 "Multicast ONT Active Groups Status Command" Display parameters

Specific Information		
name	Type	Description
state	Parameter type: <Igmp::ActualState> (full-view pre-view black-out) Possible values: - full-view : full view of the stream - pre-view : preview of the stream - black-out : no stream is viewed	The actual state of the multicast stream <i>This element is always shown.</i>
curr-previewed-nbr short name: prev-nbr	Parameter type: <Igmp::PreviewNumber> - number of pre-view sessions already been viewed - range: [0...1000]	number of pre-view sessions that have already been viewed <i>This element is only shown in detail mode.</i>
status	Parameter type: <Igmp::McastStatus> (static static-dynamic dynamic) Possible values: - static : static entry - static-dynamic : static dynamic entry - dynamic : dynamic entry	the current type of multicast group <i>This element is always shown.</i>

143.6 Multicast Channel Pair Active Groups Status Command

Command Description

This command shows per user interface on a particular Channel Pair the list of active multicast streams.

User Level

The command can be accessed by operators with igmp privileges.

Command Syntax

The command has the following syntax:

```
> show mcast chpair-active-groups [ (chpair-idx) [ port <Igmp::IgmpIfIndex> ] [ vlan-id <Vlan::VlanId> ] [ mcast-grp-addr <Igmp::MulticastAddress> ] [ mcast-src-addr <Ip::V4Address> ] ]
```

Command Parameters

Table 143.6-1 "Multicast Channel Pair Active Groups Status Command" Resource Parameters

Resource Identifier	Type	Description
(chpair-idx)	Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::ChannelPairId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::ChannelPairId> - the channel pair identifier	identification of the Channel-Pair
port	Parameter type: <Igmp::IgmpIfIndex> Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::VpiId> : <Eqpt::VciId> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::VpiId> : <Eqpt::VciId> : <Eqpt::UnstackedVlan> vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::UnstackedVlan> vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::VpiId> : <Eqpt::VciId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan>	identification of the vlanport

Resource Identifier	Type	Description
	vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> / <Eqpt::OntPortId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> / <Eqpt::OntPortId> : <Eqpt::UnstackedVlan> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> / <Eqpt::OntPortId> vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / voip : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / vuni : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / voip : <Eqpt::UnstackedVlan> vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / vuni : <Eqpt::UnstackedVlan> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / voip <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / vuni vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::LLId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::LLId> : <Eqpt::UnstackedVlan> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::LLId> vlan:ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / <Eqpt::Ng2OntSlotId> / <Eqpt::Ng2OntPortId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan:ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / <Eqpt::Ng2OntSlotId> / <Eqpt::Ng2OntPortId> : <Eqpt::UnstackedVlan>) Possible values: - vlan : vlan port - vlan:ng2 : ngpon2 vlan port Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number Field type <Eqpt::VpiId> - atm VPI	

Resource Identifier	Type	Description
	Field type <Eqpt::VcId> - atm VCI Field type <Eqpt::PonId> - the PON identifier Field type <Eqpt::ChannelGroupId> - the channel group identifier Field type <Eqpt::SubChannelGroupId> - the subchannel group identifier Field type <Eqpt::Ng2OntId> - the NG2 ONT identifier Field type <Eqpt::OntId> - the ONT identifier Possible values: - voip : virtual uni identifier obsolete alternative replaced by vuni - vuni : virtual uni identifier Possible values: - vuni : virtual NGPON2 uni identifier Field type <Eqpt::OntSlotId> - the ONT SLOT identifier Field type <Eqpt::OntPortId> - the ONT PORT identifier Field type <Eqpt::Ng2OntSlotId> - the NGPON2 ONT SLOT identifier Field type <Eqpt::Ng2OntPortId> - the NGPON2 ONT PORT identifier Field type <Eqpt::LLId> - the LLID identifier, range 1 for EPON, range 1-8 for DPOE Possible values: - stacked : stacked vlan identity Field type <Eqpt::UnstackedVlan> - unstacked vlan id Field type <Eqpt::SVlan> - service vlan id Field type <Eqpt::CVlan> - customer vlan id	
vlan-id	Parameter type: <Vlan::VlanId> Format: - vlan id - range: [1...4093]	vlan id
mcast-grp-addr	Parameter type: <Igmp::MulticastAddress> Format: - multicast-address (range: 224.0.0.3....239.255.255.255, except for 224.0.0.22)	class D address of the multicast stream
mcast-src-addr	Parameter type: <Ip::V4Address> Format: - IPv4-address	the multicast group source address

Command Output

Table 143.6-2 "Multicast Channel Pair Active Groups Status Command" Display parameters

Specific Information		
name	Type	Description
state	Parameter type: <Igmp::ActualState> (full-view pre-view	The actual state of the multicast stream <i>This element is always shown.</i>

name	Type	Description
	black-out) Possible values: - full-view : full view of the stream - pre-view : preview of the stream - black-out : no stream is viewed	
curr-previewed-nbr short name: prev-nbr	Parameter type: <Igmp::PreviewNumber> - number of pre-view sessions already been viewed - range: [0...1000]	number of pre-view sessions that have already been viewed <i>This element is only shown in detail mode.</i>
status	Parameter type: <Igmp::McastStatus> (static static-dynamic dynamic) Possible values: - static : static entry - static-dynamic : static dynamic entry - dynamic : dynamic entry	the current type of multicast group <i>This element is always shown.</i>

143.7 Multicast Group Membership Status

Command

Command Description

This command shows per multicast stream the list of user interfaces to which the system is currently requested to forward this stream.

User Level

The command can be accessed by operators with igmp privileges.

Command Syntax

The command has the following syntax:

```
> show mcast grp-membership [ (mcast-grp-addr) [ vlan-id <Vlan::VlanId> ] [ mcast-src-addr <Ip::V4Address> ] [ port <Igmp::IgmpIfIndex> ] ]
```

Command Parameters

Table 143.7-1 "Multicast Group Membership Status Command" Resource Parameters

Resource Identifier	Type	Description
(mcast-grp-addr)	Format: - multicast-address (range: 224.0.0.3....239.255.255.255, except for 224.0.0.22)	multicast group address
vlan-id	Parameter type: <Vlan::VlanId> Format: - vlan id - range: [1...4093]	vlan id
mcast-src-addr	Parameter type: <Ip::V4Address> Format: - IPv4-address	the multicast group source address
port	Parameter type: <Igmp::IgmpIfIndex> Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::VpiId> : <Eqpt::VciId> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::VpiId> : <Eqpt::VciId> : <Eqpt::UnstackedVlan> vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::UnstackedVlan> vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::VpiId> : <Eqpt::VciId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan>	identifies a user interface receiving a multicast stream

Resource Identifier	Type	Description
	vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> / <Eqpt::OntPortId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> / <Eqpt::OntPortId> : <Eqpt::UnstackedVlan> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> / <Eqpt::OntPortId> vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / voip : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / vuni : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / voip : <Eqpt::UnstackedVlan> vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / vuni : <Eqpt::UnstackedVlan> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / voip <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / vuni vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::LLId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::LLId> : <Eqpt::UnstackedVlan> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::LLId> vlan:ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / <Eqpt::Ng2OntSlotId> / <Eqpt::Ng2OntPortId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan:ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / <Eqpt::Ng2OntSlotId> / <Eqpt::Ng2OntPortId> : <Eqpt::UnstackedVlan>) Possible values: - vlan : vlan port - vlan:ng2 : ngpon2 vlan port Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number Field type <Eqpt::VpiId> - atm VPI	

Resource Identifier	Type	Description
	Field type <Eqpt::VcId> - atm VCI Field type <Eqpt::PonId> - the PON identifier Field type <Eqpt::ChannelGroupId> - the channel group identifier Field type <Eqpt::SubChannelGroupId> - the subchannel group identifier Field type <Eqpt::Ng2OntId> - the NG2 ONT identifier Field type <Eqpt::OntId> - the ONT identifier Possible values: - voip : virtual uni identifier obsolete alternative replaced by vuni - vuni : virtual uni identifier Possible values: - vuni : virtual NGPON2 uni identifier Field type <Eqpt::OntSlotId> - the ONT SLOT identifier Field type <Eqpt::OntPortId> - the ONT PORT identifier Field type <Eqpt::Ng2OntSlotId> - the NGPON2 ONT SLOT identifier Field type <Eqpt::Ng2OntPortId> - the NGPON2 ONT PORT identifier Field type <Eqpt::LLId> - the LLID identifier, range 1 for EPON, range 1-8 for DPOE Possible values: - stacked : stacked vlan identity Field type <Eqpt::UnstackedVlan> - unstacked vlan id Field type <Eqpt::SVlan> - service vlan id Field type <Eqpt::CVlan> - customer vlan id	

Command Output

Table 143.7-2 "Multicast Group Membership Status Command" Display parameters

Specific Information		
name	Type	Description
state	Parameter type: <Igmpp::GroupAddr2UserItfActualstate> (full-view pre-view black-out) Possible values: - full-view : full view of the stream - pre-view : preview of the stream - black-out : no stream is viewed	the actual state of the multicast stream <i>This element is always shown.</i>
status	Parameter type: <Igmpp::McastStatus> (static static-dynamic dynamic) Possible values: - static : static entry	the current status of the static multicast branch <i>This element is always shown.</i>

name	Type	Description
	- static-dynamic : static dynamic entry - dynamic : dynamic entry	

144- CPE Management Status Commands

144.1 CPE Management Status Command Tree	144-6269
144.2 CPE Management Show Command	144-6270

144.1 CPE Management Status Command Tree

Description

This chapter gives an overview of nodes that are handled by "CPE Management Status Commands".

Command Tree

```
----show
  ----cpe-management
    ----snmpproxy-statistics
      - (address)
```

144.2 CPE Management Show Command

Command Description

This chapter shows the global statistics and the statistics per CPE manager

User Level

The command can be accessed by operators with all privileges.

Command Syntax

The command has the following syntax:

```
> show cpe-management snmpproxy-statistics [ (address) ]
```

Command Parameters

Table 144.2-1 "CPE Management Show Command" Resource Parameters

Resource Identifier	Type	Description
(address)	Format: - IP address of CPE Management Station	the IP address of a CPE manager

Command Output

Table 144.2-2 "CPE Management Show Command" Display parameters

Common Information:cpeproxy		
name	Type	Description
rx-drop-msgs-cpe	Parameter type: <Counter> - 32 bit counter	the number of discarded msgs received from CPEs <i>This element is only shown in detail mode.</i>
Specific Information		
name	Type	Description
rx-msgs	Parameter type: <Counter> - 32 bit counter	the number of received msgs from a CPE manager <i>This element is always shown.</i>
tx-msgs	Parameter type: <Counter> - 32 bit counter	the number of msgs sent to a CPE manager <i>This element is always shown.</i>
rx-drop-msgs	Parameter type: <Counter> - 32 bit counter	the number of discarded msgs received from a CPE manager <i>This element is always shown.</i>

145- Session Status Commands

145.1 Session Status Command Tree	145-6272
145.2 Session Status Command	145-6273

145.1 Session Status Command Tree

Description

This chapter gives an overview of nodes that are handled by "Session Status Commands".

Command Tree

```
----show
  ----session
    - (id)
```

145.2 Session Status Command

Command Description

This command displays the status of all sessions.

User Level

The command can be accessed and executed by an operator with admin privilege.

Command Syntax

The command has the following syntax:

> show session (id)

Command Parameters

Table 145.2-1 "Session Status Command" Resource Parameters

Resource Identifier	Type	Description
(id)	Format: - the session number - range: [1...13]	the session number

Command Output

Table 145.2-2 "Session Status Command" Display parameters

Specific Information		
name	Type	Description
operator	Parameter type: <Sec::SessionOperatorName> - the name of an operator - length: 1<=x<=11	the name of the operator that is actually using the session <i>This element is always shown.</i>
from	Parameter type: <Sec::LoginAddress> - the address from where the operator logged in - length: x<=40	the ip-address from where the user is logged in <i>This element is always shown.</i>
type	Parameter type: <Sec::TerminalType> (craft telnet unused test ssh sftp) Possible values: - craft : craft terminal - telnet : telnet terminal - unused : unused terminal - test : test terminal	the type of connection use. Network means that any supported connection type over ip is possible. <i>This element is always shown.</i>

145 Session Status Commands

name	Type	Description
	- ssh : ssh terminal - sftp : sftp terminal	
status short name: stat	Parameter type: <Sec::SessionStatus> (init free (reserved res) name (passwd pwd) (active act) (logout end) (limited lmt)) Possible values: - init : initialisation ongoing - free : free - reserved : reserved - res : reserved - name : asking the operator name - passwd : asking the password - pwd : asking the password - active : active - act : active - logout : the operator is logging out - end : the operator is logging out - limited : the limited session configured by user - lmt : the limited session configured by user	the status of the session. Special values are : initializing=session is not yet ready to be used, free=session is not used, selected=session is reserved, stopping=the user is logging out, invalid=the session is out-of-service <i>This element is always shown.</i>
login-time	Parameter type: <Sys::Time> - the time (yyyy-mm-dd:hour:minutes:secs) - unit: UTC	the time when the user connected to the terminal. Never if no user is connected. <i>This element is always shown.</i>
idle-time	Parameter type: <ElapsedTime> - the time elapsed since a certain event - unit: sec	the time that this terminal is idle (the operator did not type any character and did not modify its window size) <i>This element is always shown.</i>
numbering-scheme short name: num	Parameter type: <Sec::SlotDesc> ((type-based typ) (position-based pos) (legacy-based leg)) Possible values: - type-based : flat-numbering per slot-type (tl1-like) - typ : flat-numbering per slot-type (tl1-like) - position-based : flat-numbering independent of slot-type - pos : flat-numbering independent of slot-type - legacy-based : numbering used since the early days (position-based-like) - leg : numbering used since the early days (position-based-like)	the numbering scheme for this session <i>This element is always shown.</i>
current-session	Parameter type: <Sec::CurrentSession> (yes no) Possible values: - yes : command is executed in current session - no : command is not executed in current session	the current session status <i>This element is only shown in detail mode.</i>

146- PPPoX-Relay Status Commands

146.1 PPPoX-Relay Status Command Tree	146-6276
146.2 PPPoX CC Engine Statistics	146-6277
146.3 PPPoX CC Client Port Statistics	146-6279
146.4 PPPoX CC Engine Monitor Statistics	146-6282
146.5 PPPoX CC Client Port Monitor Statistics	146-6284
146.6 PPPoX CC Session Engine Status Command	146-6287
146.7 PPPoX CC Session Client Port Status Command	146-6290
146.8 PPPCC Engine Current 15Minute Statistics Command	146-6293
146.9 PPPCC Engine Current 1day Statistics Command	146-6295
146.10 PPPCC Engine Previous 15Minute Statistics Command	146-6297
146.11 PPPCC Engine Previous 1day Statistics Command	146-6299

146.1 PPPoX-Relay Status Command Tree

Description

This chapter gives an overview of nodes that are handled by "PPPoX-Relay Status Commands".

Command Tree

```
----show
  ----pppox-relay
    ----cross-connect
      ----statistics
        ----engine
          - (vlan-id)
        ----client-port
          - (client-port)
      ----monitor-statistics
        ----engine
          - (vlan-id)
        ----client-port
          - (client-port)
      ----session
        ----engine
          - (vlan-id)
        ----client-port
          - (client-port)
      ----trouble-shooting-cntrs
        ----engine
          ----curr-15min-stats
            - (vlan-id)
          ----curr-1day-stats
            - (vlan-id)
          ----prev-15min-stats
            - (vlan-id)
            - interval-num
          ----prev-1day-stats
            - (vlan-id)
            - interval-num
```

146.2 PPPoX CC Engine Statistics

Command Description

This command displays the statistics for a particular VLAN ID.

User Level

The command can be accessed by operators with pppoe privileges.

Command Syntax

The command has the following syntax:

```
> show pppox-relay cross-connect statistics engine [ (vlan-id) ]
```

Command Parameters

Table 146.2-1 "PPPoX CC Engine Statistics" Resource Parameters

Resource Identifier	Type	Description
(vlan-id)	Format: (<Vlan::UVlanIndex> stacked : <Vlan::SVlanIndex> : <Vlan::CVlanIndex>) Possible values: - stacked : stacked vlan identity Field type <Vlan::UVlanIndex> - unstacked vlan identity - range: [1...4093,4096] Field type <Vlan::SVlanIndex> - service vlan identity - range: [2...4093] Field type <Vlan::CVlanIndex> - customer vlan identity - range: [0...4093]	engine identification

Command Output

Table 146.2-2 "PPPoX CC Engine Statistics" Display parameters

Specific Information		
name	Type	Description
engine-name	Parameter type: <PPPoX::EngineName> - Engine Name - length: 1<=x<=32	name to identify the engine/service <i>This element is always shown.</i>
in-ctrl-frm	Parameter type: <Counter> - 32 bit counter	number of ingress control messages <i>This element is always shown.</i>
out-ctrl-frm	Parameter type: <Counter>	number of egress control

146 PPPoX-Relay Status Commands

name	Type	Description
	- 32 bit counter	messages <i>This element is always shown.</i>
err-ctrl-frm	Parameter type: <Counter> - 32 bit counter	nbr of errored upstream and downstream control msgs <i>This element is only shown in detail mode.</i>
ppp-cc	Parameter type: <SignedInteger> - a signed integer	nbr of PPP cross-connections currently in use <i>This element is always shown.</i>

146.3 PPPoX CC Client Port Statistics

Command Description

This command displays the statistics of a client port.

User Level

The command can be accessed by operators with pppoe privileges.

Command Syntax

The command has the following syntax:

```
> show pppox-relay cross-connect statistics client-port [ (client-port) ]
```

Command Parameters

Table 146.3-1 "PPPoX CC Client Port Statistics" Resource Parameters

Resource Identifier	Type	Description
(client-port)	Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::VpiId> : <Eqpt::VciId> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::VpiId> : <Eqpt::VciId> : <Eqpt::UnstackedVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::UnstackedVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::VpiId> : <Eqpt::VciId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> / <Eqpt::OntPortId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> / <Eqpt::OntPortId> : <Eqpt::UnstackedVlan> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> / <Eqpt::OntPortId> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / voip :	client port identification

Resource Identifier	Type	Description
	stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / vuni : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / voip : <Eqpt::UnstackedVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / vuni : <Eqpt::UnstackedVlan> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / voip <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / vuni vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::LLId> : <Eqpt::UnstackedVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::LLId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::LLId>) Possible values: - vlan-port : vlan port Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number Field type <Eqpt::VpiId> - atm VPI Field type <Eqpt::VciId> - atm VCI Field type <Eqpt::PonId> - the PON identifier Field type <Eqpt::OntId> - the ONT identifier Possible values: - voip : virtual uni identifier obsolete alternative replaced by vuni - vuni : virtual uni identifier Field type <Eqpt::OntSlotId> - the ONT SLOT identifier Field type <Eqpt::OntPortId> - the ONT PORT identifier Field type <Eqpt::LLId> - the LLID identifier, range 1 for EPON, range 1-8 for DPOE Possible values: - stacked : stacked vlan identity Field type <Eqpt::UnstackedVlan> - unstacked vlan id Field type <Eqpt::SVlan> - service vlan id Field type <Eqpt::CVlan>	

Resource Identifier	Type	Description
	- customer vlan id	

Command Output

Table 146.3-2 "PPPoX CC Client Port Statistics" Display parameters

Specific Information		
name	Type	Description
in-ctrl-frm	Parameter type: <Counter> - 32 bit counter	number of ingress control messages <i>This element is always shown.</i>
out-ctrl-frm	Parameter type: <Counter> - 32 bit counter	number of egress control messages <i>This element is always shown.</i>
err-ctrl-frm	Parameter type: <Counter> - 32 bit counter	number of errored control messages <i>This element is always shown.</i>
curr-num-session	Parameter type: <SignedInteger> - a signed integer	number of active PPP sessions on the client port <i>This element is always shown.</i>
fwd-frames-up	Parameter type: <Counter> - 32 bit counter	number of upstream forwarded frames <i>This element is only shown in detail mode.</i>
fwd-frames-down	Parameter type: <Counter> - 32 bit counter	number of downstream forwarded frames <i>This element is only shown in detail mode.</i>
disc-frames-up	Parameter type: <Counter> - 32 bit counter	number of upstream discarded frames <i>This element is only shown in detail mode.</i>
disc-frames-down	Parameter type: <Counter> - 32 bit counter	number of downstream discarded frames <i>This element is only shown in detail mode.</i>

146.4 PPPoX CC Engine Monitor Statistics

Command Description

This command displays the engine monitor statistics for a particular VLAN ID and lists the statistics of a configured engine with a monitor enabled.

User Level

The command can be accessed by operators with pppoe privileges.

Command Syntax

The command has the following syntax:

```
> show pppox-relay cross-connect monitor-statistics engine [ (vlan-id) ]
```

Command Parameters

Table 146.4-1 "PPPoX CC Engine Monitor Statistics" Resource Parameters

Resource Identifier	Type	Description
(vlan-id)	Format: (<Vlan::UVlanIndex> stacked : <Vlan::SVlanIndex> : <Vlan::CVlanIndex>) Possible values: - stacked : stacked vlan identity Field type <Vlan::UVlanIndex> - unstacked vlan identity - range: [1...4093,4096] Field type <Vlan::SVlanIndex> - service vlan identity - range: [2...4093] Field type <Vlan::CVlanIndex> - customer vlan identity - range: [0...4093]	engine identification

Command Output

Table 146.4-2 "PPPoX CC Engine Monitor Statistics" Display parameters

Specific Information		
name	Type	Description
generic-err-cnt	Parameter type: <Counter> - 32 bit counter	nbr of discovery msgs that carried the Generic Error tag <i>This element is always shown.</i>
inv-serv-name	Parameter type: <Counter> - 32 bit counter	nbr of PAD-S msgs containing Service-Name-Error tag <i>This element is always shown.</i>

146.5 PPPoX CC Client Port Monitor Statistics

Command Description

This command shows the client port monitor statistics and lists the statistics of a configured client port with a monitor enabled.

User Level

The command can be accessed by operators with pppoe privileges.

Command Syntax

The command has the following syntax:

```
> show pppox-relay cross-connect monitor-statistics client-port [ (client-port) ]
```

Command Parameters

Table 146.5-1 "PPPoX CC Client Port Monitor Statistics" Resource Parameters

Resource Identifier	Type	Description
(client-port)	Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::VpiId> : <Eqpt::VciId> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::VpiId> : <Eqpt::VciId> : <Eqpt::UnstackedVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::UnstackedVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::VpiId> : <Eqpt::VciId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> / <Eqpt::OntPortId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> / <Eqpt::OntPortId> : <Eqpt::UnstackedVlan> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> / <Eqpt::OntPortId> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> /	client port identification

Resource Identifier	Type	Description
	<Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / voip : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / vuni : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / voip : <Eqpt::UnstackedVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / vuni : <Eqpt::UnstackedVlan> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / voip <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / vuni vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::LLId> : <Eqpt::UnstackedVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::LLId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::LLId>) Possible values: - vlan-port : vlan port Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number Field type <Eqpt::VpiId> - atm VPI Field type <Eqpt::VciId> - atm VCI Field type <Eqpt::PonId> - the PON identifier Field type <Eqpt::OntId> - the ONT identifier Possible values: - voip : virtual uni identifier obsolete alternative replaced by vuni - vuni : virtual uni identifier Field type <Eqpt::OntSlotId> - the ONT SLOT identifier Field type <Eqpt::OntPortId> - the ONT PORT identifier Field type <Eqpt::LLId> - the LLID identifier, range 1 for EPON, range 1-8 for DPOE Possible values: - stacked : stacked vlan identity Field type <Eqpt::UnstackedVlan> - unstacked vlan id Field type <Eqpt::SVlan> - service vlan id	

Resource Identifier	Type	Description
	Field type <Eqpt::CVlan> - customer vlan id	

Command Output

Table 146.5-2 "PPPoX CC Client Port Monitor Statistics" Display parameters

Specific Information		
name	Type	Description
unexp-ctrl-msg	Parameter type: <Counter> - 32 bit counter	number of unexpected control messages discarded <i>This element is always shown.</i>
unexp-data-pkts	Parameter type: <Counter> - 32 bit counter	number of discarded data packets on this port <i>This element is always shown.</i>
prt-mru-err-cnt	Parameter type: <Counter> - 32 bit counter	number of long messages discarded on this port <i>This element is only shown in detail mode.</i>
trans-age-out	Parameter type: <Counter> - 32 bit counter	nbr of events cleared because the transaction timed out <i>This element is always shown.</i>
session-age-out	Parameter type: <Counter> - 32 bit counter	nbr of events timed out for this port <i>This element is always shown.</i>
cc-port-max-exceeded	Parameter type: <Counter> - 32 bit counter	number of times a ppp cc set-up process is aborted due to max nbr ppp cc allowed on a port <i>This element is only shown in detail mode.</i>
cc-line-max-exceeded	Parameter type: <Counter> - 32 bit counter	number of times a ppp cc set-up process is aborted due to max nbr ppp cc allowed on a line <i>This element is only shown in detail mode.</i>
cc-board-max-exceeded	Parameter type: <Counter> - 32 bit counter	number of times a ppp cc set-up process is aborted due to max nbr ppp cc allowed on a board <i>This element is only shown in detail mode.</i>

146.6 PPPoX CC Session Engine Status Command

Command Description

This command displays session data for the engine.

User Level

The command can be accessed by operators with pppoe privileges.

Command Syntax

The command has the following syntax:

```
> show pppox-relay cross-connect session engine [ (vlan-id) ]
```

Command Parameters

Table 146.6-1 "PPPoX CC Session Engine Status Command" Resource Parameters

Resource Identifier	Type	Description
(vlan-id)	Format: (<Vlan::UVlanIndex> stacked : <Vlan::SVlanIndex> : <Vlan::CVlanIndex>) Possible values: - stacked : stacked vlan identity Field type <Vlan::UVlanIndex> - unstacked vlan identity - range: [1...4093,4096] Field type <Vlan::SVlanIndex> - service vlan identity - range: [2...4093] Field type <Vlan::CVlanIndex> - customer vlan identity - range: [0...4093]	engine identification

Command Output

Table 146.6-2 "PPPoX CC Session Engine Status Command" Display parameters

Specific Information		
name	Type	Description
server-mac-addr	Parameter type: <Vlan::MacAddr> - mac address (aa:bb:cc:a1:02:03) - unit: Byte - length: 6	mac-addr of the PPPoE Server for this PPP cross-connection <i>This element is always shown.</i>
ext-session-id	Parameter type: <SignedInteger> - a signed integer	PPPoE session id of this PPP cross-connection <i>This element is always shown.</i>

name	Type	Description
client-port	Parameter type: <Itf::PppoxClientPortInterface> (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::VpiId> : <Eqpt::VciId> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::VpiId> : <Eqpt::VciId> : <Eqpt::UnstackedVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::UnstackedVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::VpiId> : <Eqpt::VciId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> / <Eqpt::OntPortId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> / <Eqpt::OntPortId> : <Eqpt::UnstackedVlan> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> / <Eqpt::OntPortId> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / voip : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / vuni : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / voip : <Eqpt::UnstackedVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / vuni : <Eqpt::UnstackedVlan> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / voip <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / vuni vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::LLId> : <Eqpt::UnstackedVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::LLId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::LLId>) Possible values: - vlan-port : vlan port Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number	Index to which the PPPoE client is directly associated <i>This element is always shown.</i>

name	Type	Description
	Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number Field type <Eqpt::VpiId> - atm VPI Field type <Eqpt::Vcild> - atm VCI Field type <Eqpt::PonId> - the PON identifier Field type <Eqpt::OntId> - the ONT identifier Possible values: - voip : virtual uni identifier obsolete alternative replaced by vuni - vuni : virtual uni identifier Field type <Eqpt::OntSlotId> - the ONT SLOT identifier Field type <Eqpt::OntPortId> - the ONT PORT identifier Field type <Eqpt::LLId> - the LLID identifier,range 1 for EPON,range 1-8 for DPOE Possible values: - stacked : stacked vlan identity Field type <Eqpt::UnstackedVlan> - unstacked vlan id Field type <Eqpt::SVlan> - service vlan id Field type <Eqpt::CVlan> - customer vlan id	
int-session-id	Parameter type: <SignedInteger> - a signed integer	index that uniquely indicate a PPP cross-connection <i>This element is always shown.</i>
client-mac-addr	Parameter type: <Vlan::MacAddr> - mac address (aa:bb:cc:a1:02:03) - unit: Byte - length: 6	mac-addr of the PPPoE Client for this PPP cross-connection <i>This element is only shown in detail mode.</i>

146.7 PPPoX CC Session Client Port Status Command

Command Description

This command displays session data for the client port.

User Level

The command can be accessed by operators with pppoe privileges.

Command Syntax

The command has the following syntax:

```
> show pppox-relay cross-connect session client-port [ (client-port) ]
```

Command Parameters

Table 146.7-1 "PPPoX CC Session Client Port Status Command" Resource Parameters

Resource Identifier	Type	Description
(client-port)	Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::VpiId> : <Eqpt::VciId> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::VpiId> : <Eqpt::VciId> : <Eqpt::UnstackedVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::UnstackedVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::VpiId> : <Eqpt::VciId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> / <Eqpt::OntPortId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> / <Eqpt::OntPortId> : <Eqpt::UnstackedVlan> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> / <Eqpt::OntPortId> :	client port identification

Resource Identifier	Type	Description
	<Eqpt::OntPortId> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / voip : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / vuni : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / voip : <Eqpt::UnstackedVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / vuni : <Eqpt::UnstackedVlan> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / voip <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / vuni vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntId> / <Eqpt::LLId> : <Eqpt::UnstackedVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::LLId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::LLId>) Possible values: - vlan-port : vlan port Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number Field type <Eqpt::VpId> - atm VPI Field type <Eqpt::VciId> - atm VCI Field type <Eqpt::PonId> - the PON identifier Field type <Eqpt::OntId> - the ONT identifier Possible values: - voip : virtual uni identifier obsolete alternative replaced by vuni - vuni : virtual uni identifier Field type <Eqpt::OntSlotId> - the ONT SLOT identifier Field type <Eqpt::OntPortId> - the ONT PORT identifier Field type <Eqpt::LLId> - the LLID identifier, range 1 for EPON, range 1-8 for DPOE Possible values: - stacked : stacked vlan identity Field type <Eqpt::UnstackedVlan> - unstacked vlan id	

Resource Identifier	Type	Description
	Field type <Eqpt::SVlan> - service vlan id Field type <Eqpt::CVlan> - customer vlan id	

Command Output

Table 146.7-2 "PPPoX CC Session Client Port Status Command" Display parameters

Specific Information		
name	Type	Description
vlan-id	Parameter type: <Vlan::StackedVlanSigned> (<Vlan::UVlanIndex> stacked : <Vlan::SVlanIndex> : <Vlan::CVlanIndex>) Possible values: - stacked : stacked vlan identity Field type <Vlan::UVlanIndex> - unstacked vlan identity - range: [1...4093,4096] Field type <Vlan::SVlanIndex> - service vlan identity - range: [2...4093,4094] Field type <Vlan::CVlanIndex> - customer vlan identity - range: [0...4093,4094,4095,4096]	vlan id <i>This element is always shown.</i>
server-mac-addr	Parameter type: <Vlan::MacAddr> - mac address (aa:bb:cc:a1:02:03) - unit: Byte - length: 6	mac-addr of the PPPoE server for this PPP cross-connection <i>This element is always shown.</i>
ext-session-id	Parameter type: <SignedInteger> - a signed integer	PPPoE session id of this PPP cross-connection <i>This element is always shown.</i>
int-session-id	Parameter type: <SignedInteger> - a signed integer	index that uniquely indicate a PPP cross-connection <i>This element is always shown.</i>
client-mac-addr	Parameter type: <Vlan::MacAddr> - mac address (aa:bb:cc:a1:02:03) - unit: Byte - length: 6	mac-addr of the PPPoE client for this PPP cross-connection <i>This element is only shown in detail mode.</i>

146.8 PPPCC Engine Current 15Minute Statistics Command

Command Description

This command displays the statistics of the transaction ageout and session ageout counters per engine for the Current 15Minute interval.

The counters are updated once in every 3 minute interval.

User Level

The command can be accessed by operators with pppoe privileges.

Command Syntax

The command has the following syntax:

```
> show pppox-relay cross-connect trouble-shooting-cntrs engine curr-15min-stats [ (vlan-id) ]
```

Command Parameters

Table 146.8-1 "PPPCC Engine Current 15Minute Statistics Command" Resource Parameters

Resource Identifier	Type	Description
(vlan-id)	Format: (<Vlan::UVlanIndex> stacked : <Vlan::SVlanIndex> : <Vlan::CVlanIndex>) Possible values: - stacked : stacked vlan identity Field type <Vlan::UVlanIndex> - unstacked vlan identity - range: [1...4093,4096] Field type <Vlan::SVlanIndex> - service vlan identity - range: [2...4093] Field type <Vlan::CVlanIndex> - customer vlan identity - range: [0...4093]	vlan-id

Command Output

Table 146.8-2 "PPPCC Engine Current 15Minute Statistics Command" Display parameters

Specific Information		
name	Type	Description
engine-name	Parameter type: <PPPoX::EngineName> - Engine Name	engine name <i>This element is always shown.</i>

146 PPPoX-Relay Status Commands

name	Type	Description
	- length: 1<=x<=32	
trans-age-out-cnt	Parameter type: <Counter> - 32 bit counter	number of transaction age out counters in current 15 min interval <i>This element is always shown.</i>
sess-age-out-cnt	Parameter type: <Counter> - 32 bit counter	number of session age out counters in current 15 min interval <i>This element is always shown.</i>
measured-time	Parameter type: <PPPoX::IntervalMeasureTime15Min> - the measured time interval - unit: sec	amount of time in seconds that statistics for this entry has been counted in the current 15 min interval <i>This element is always shown.</i>
valid-flag	Parameter type: <PPPoX::IntervalValidityFlag> (true false) Possible values: - true : data is valid - false : data is not valid	validity of the counters collected <i>This element is always shown.</i>

146.9 PPPCC Engine Current 1day Statistics Command

Command Description

This command displays the statistics of the transaction ageout and session ageout counters per engine for the current 1day interval.

The counters are updated once in every 3 minute interval.

User Level

The command can be accessed by operators with pppoe privileges.

Command Syntax

The command has the following syntax:

```
> show pppox-relay cross-connect trouble-shooting-cntrs engine curr-1day-stats [ (vlan-id) ]
```

Command Parameters

Table 146.9-1 "PPPCC Engine Current 1day Statistics Command" Resource Parameters

Resource Identifier	Type	Description
(vlan-id)	Format: (<Vlan::UVlanIndex> stacked : <Vlan::SVlanIndex> : <Vlan::CVlanIndex>) Possible values: - stacked : stacked vlan identity Field type <Vlan::UVlanIndex> - unstacked vlan identity - range: [1...4093,4096] Field type <Vlan::SVlanIndex> - service vlan identity - range: [2...4093] Field type <Vlan::CVlanIndex> - customer vlan identity - range: [0...4093]	vlan-id

Command Output

Table 146.9-2 "PPPCC Engine Current 1day Statistics Command" Display parameters

Specific Information		
name	Type	Description
engine-name	Parameter type: <PPPoX::EngineName> - Engine Name	engine name <i>This element is always shown.</i>

146 PPPoX-Relay Status Commands

name	Type	Description
	- length: 1<=x<=32	
trans-age-out-cnt	Parameter type: <Counter> - 32 bit counter	number of transaction age out counters in current 1 day interval <i>This element is always shown.</i>
sess-age-out-cnt	Parameter type: <Counter> - 32 bit counter	number of session age out counters in current 1 dayinterval <i>This element is always shown.</i>
measured-time	Parameter type: <PPPoX::IntervalMeasureTime1Day> - the measured time interval - unit: sec	amount of time in seconds that statistics for this entry has been counted in the current 1 day interval <i>This element is always shown.</i>
valid-flag	Parameter type: <PPPoX::IntervalValidityFlag> (true false) Possible values: - true : data is valid - false : data is not valid	validity of the counters collected <i>This element is always shown.</i>

146.10 PPPCC Engine Previous 15Minute Statistics Command

Command Description

This command displays the statistics of the transaction ageout and session ageout counters per engine for the previous 15Minute interval.

User Level

The command can be accessed by operators with pppoe privileges.

Command Syntax

The command has the following syntax:

```
> show pppox-relay cross-connect trouble-shooting-cntrs engine prev-15min-stats [ (vlan-id) [ interval-num
<PPPoX::IntervalNumber15min> ] ]
```

Command Parameters

Table 146.10-1 "PPPCC Engine Previous 15Minute Statistics Command" Resource Parameters

Resource Identifier	Type	Description
(vlan-id)	Format: (<Vlan::UVlanIndex> stacked : <Vlan::SVlanIndex> : <Vlan::CVlanIndex>) Possible values: - stacked : stacked vlan identity Field type <Vlan::UVlanIndex> - unstacked vlan identity - range: [1...4093,4096] Field type <Vlan::SVlanIndex> - service vlan identity - range: [2...4093] Field type <Vlan::CVlanIndex> - customer vlan identity - range: [0...4093]	vlan-id
interval-num	Parameter type: <PPPoX::IntervalNumber15min> Format: - a number identifying 15 minutes interval time - range: [1...32]	previous 15 min interval number

Command Output

Table 146.10-2 "PPPCC Engine Previous 15Minute Statistics Command" Display parameters

146 PPPoX-Relay Status Commands

Specific Information		
name	Type	Description
engine-name	Parameter type: <PPPoX::EngineName> - Engine Name - length: 1<=x<=32	engine identification <i>This element is always shown.</i>
trans-age-out-cnt	Parameter type: <Counter> - 32 bit counter	number of transaction age out in previous 15 min interval <i>This element is always shown.</i>
sess-age-out-cnt	Parameter type: <Counter> - 32 bit counter	number of session age out in previous 15 min interval <i>This element is always shown.</i>
measured-time	Parameter type: <PPPoX::IntervalMeasureTime15Min> - the measured time interval - unit: sec	amount of time in seconds that statistics for this entry has been counted in the previous 15 min interval <i>This element is always shown.</i>
valid-flag	Parameter type: <PPPoX::IntervalValidityFlag> (true false) Possible values: - true : data is valid - false : data is not valid	validity of the counters collected <i>This element is always shown.</i>

146.11 PPPCC Engine Previous 1day Statistics Command

Command Description

This command displays the statistics of the transaction ageout and session ageout counters per engine for the previous 1day interval.

User Level

The command can be accessed by operators with pppoe privileges.

Command Syntax

The command has the following syntax:

```
> show pppox-relay cross-connect trouble-shooting-cntrs engine prev-1day-stats [ (vlan-id) [ interval-num
<PPPoX::IntervalNumber1day> ] ]
```

Command Parameters

Table 146.11-1 "PPPCC Engine Previous 1day Statistics Command" Resource Parameters

Resource Identifier	Type	Description
(vlan-id)	Format: (<Vlan::UVlanIndex> stacked : <Vlan::SVlanIndex> : <Vlan::CVlanIndex>) Possible values: - stacked : stacked vlan identity Field type <Vlan::UVlanIndex> - unstacked vlan identity - range: [1...4093,4096] Field type <Vlan::SVlanIndex> - service vlan identity - range: [2...4093] Field type <Vlan::CVlanIndex> - customer vlan identity - range: [0...4093]	vlan-id
interval-num	Parameter type: <PPPoX::IntervalNumber1day> Format: - a number identifying 1 day interval time - range: [1...7]	previous 1 day interval number

Command Output

Table 146.11-2 "PPPCC Engine Previous 1day Statistics Command" Display parameters

146 PPPoX-Relay Status Commands

Specific Information		
name	Type	Description
engine-name	Parameter type: <PPPoX::EngineName> - Engine Name - length: 1<=x<=32	engine name <i>This element is always shown.</i>
trans-age-out-cnt	Parameter type: <Counter> - 32 bit counter	number of transaction age out previous 1 day interval <i>This element is always shown.</i>
sess-age-out-cnt	Parameter type: <Counter> - 32 bit counter	number of session age out counters in previous 1 day interval <i>This element is always shown.</i>
measured-time	Parameter type: <PPPoX::IntervalMeasureTime1Day> - the measured time interval - unit: sec	amount of time in seconds that statistics for this entry has been counted in the previous 1 day interval <i>This element is always shown.</i>
valid-flag	Parameter type: <PPPoX::IntervalValidityFlag> (true false) Possible values: - true : data is valid - false : data is not valid	validity of the counters collected <i>This element is always shown.</i>

147- NAT related Commands

147.1 NAT related Command Tree	147-6302
147.2 Nat dynamic Session Status Command	147-6303

147.1 NAT related Command Tree

Description

This chapter gives an overview of nodes that are handled by "NAT related Commands".

Command Tree

```
----show
  ----nat
    ----session
      - local-addr
      - local-port
```


147.2 Nat dynamic Session Status Command

Command Description

This command displays the nat-sessions information.

Note: Once the remaining-lease timer has expired, esponding user interface.

User Level

The command can be accessed by operators with all privileges.

Command Syntax

The command has the following syntax:

```
> show nat session [ local-addr <Ip::V4Address> ] [ local-port <CWMP::CwmpPort> ]
```

Command Parameters

Table 147.2-1 "Nat dynamic Session Status Command" Resource Parameters

Resource Identifier	Type	Description
local-addr	Parameter type: <Ip::V4Address> Format: - IPv4-address	the local address of the client
local-port	Parameter type: <CWMP::CwmpPort> Format: - nat port - range: [0...65535] - length: x<=65535	the local port of the client

Command Output

Table 147.2-2 "Nat dynamic Session Status Command" Display parameters

Specific Information		
name	Type	Description
global-addr	Parameter type: <Ip::V4Address> - IPv4-address	<i>This element is always shown.</i>
global-port	Parameter type: <CWMP::CwmpPort> - nat port - range: [0...65535] - length: x<=65535	<i>This element is always shown.</i>

148- CWMP Platform Status Commands

148.1 CWMP Platform Status Command Tree	148-6305
148.2 CWMP Platform Status Commands	148-6306
148.3 Cwmp Platform Status Commands	148-6307

148.1 CWMP Platform Status Command Tree

Description

This chapter gives an overview of nodes that are handled by "CWMP Platform Status Commands".

Command Tree

```
----show
  ----cwpmp
    ----plt
```

148.2 CWMP Platform Status Commands

Command Description

This command allows the operator to retrieve CWMP related status.

User Level

The command can be accessed by operators with all privileges.

Command Syntax

The command has the following syntax:

```
> show cwmp
```

148.3 Cwmp Platform Status Commands

Command Description

This command allows the operator to retrieve CWMP related status.

User Level

The command can be accessed by operators with all privileges.

Command Syntax

The command has the following syntax:

```
> show cwmp plt
```

Command Output

Table 148.3-2 "Cwmp Platform Status Commands" Display parameters

Specific Information		
name	Type	Description
operstate	Parameter type: <CWMP::OperStatus> (enabled disabled) Possible values: - enabled : the identified resource is operational - disabled : the identified resource is not operational or the status is not known	operational state of cwmp <i>This element is always shown.</i>

149- SHDSL Status Commands

149.1 SHDSL Status Command Tree	149-6309
149.2 SHDSL Inventory Status Command	149-6311
149.3 SHDSL Span Status Command	149-6313
149.4 SHDSL Unit Status Command	149-6320
149.5 SHDSL Segment Status Command	149-6322
149.6 SHDSL Segment Counters Current Interval Status Command	149-6327
149.7 SHDSL Segment Counters Current Day Status Command	149-6330
149.8 SHDSL Segment Counters Previous Interval Status Command	149-6333
149.9 SHDSL Segment Counters Previous Day Status Command	149-6336
149.10 SHDSL Span Current Interval Performance Data Status Command	149-6339
149.11 SHDSL Span Current Day Performance Data Status Command	149-6341
149.12 SHDSL Span Previous Interval Performance Data Status Command	149-6343
149.13 SHDSL Span Previous Day Performance Data Status Command	149-6345

149.1 SHDSL Status Command Tree

Description

This chapter gives an overview of nodes that are handled by "SHDSL Status Commands".

Command Tree

```

----show
  ----shdsl
    ----inventory
      - (if-index)
      - unit-id
    ----span-status
      - (if-index)
    ----unit-status
      - (if-index)
      - unit-id
    ----segment-status
      - (if-index)
      - unit-id
      - side
      - wire-pair
    ----segment-counters
      ----current-15min
        - (if-index)
        - unit-id
        - side
        - wire-pair
      ----current-1day
        - (if-index)
        - unit-id
        - side
        - wire-pair
      ----previous-15min
        - (if-index)
        - unit-id
        - side
        - wire-pair
        - int-no
      ----previous-1day
        - (if-index)
        - unit-id
        - side
        - wire-pair
        - int-no
    ----span-counters
      ----current-15min
        - (if-index)
      ----current-1day
        - (if-index)
      ----previous-15min
        - (if-index)
        - interval-number
  
```

----previous-1day
- (if-index)
- interval-number

149.2 SHDSL Inventory Status Command

Command Description

This command displays the SHDSL inventory status.

User Level

The command can be accessed by operators with xdsl privileges.

Command Syntax

The command has the following syntax:

```
> show shdsl inventory [ (if-index) [ unit-id <Shdsl::UnitId> ] ]
```

Command Parameters

Table 149.2-1 "SHDSL Inventory Status Command" Resource Parameters

Resource Identifier	Type	Description
(if-index)	Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number	interface index of the port
unit-id	Parameter type: <Shdsl::UnitId> Format: (stu-c stu-r sru-1 sru-2 sru-3 sru-4 sru-5 sru-6 sru-7 sru-8) Possible values: - stu-c : the SHDSL unit is STU-C - stu-r : the SHDSL unit is STU-R - sru-1 : the SHDSL unit is SRU-1 - sru-2 : the SHDSL unit is SRU-2 - sru-3 : the SHDSL unit is SRU-3	unit identifier in an SHDSL span

Resource Identifier	Type	Description
	- sru-4 : the SHDSL unit is SRU-4 - sru-5 : the SHDSL unit is SRU-5 - sru-6 : the SHDSL unit is SRU-6 - sru-7 : the SHDSL unit is SRU-7 - sru-8 : the SHDSL unit is SRU-8	

Command Output

Table 149.2-2 "SHDSL Inventory Status Command" Display parameters

Specific Information		
name	Type	Description
version	Parameter type: <Shdsl::UnitShdslStdVersion> - an SHDSL unit standard version - range: [0...255]	the SHDSL standard version for this unit <i>This element is always shown.</i>
list-no	Parameter type: <Shdsl::UnitVendorListNumber> - string indicates an SHDSL unit's vendor list number - length: x<=3	the vendor list number for this SHDSL unit <i>This element is always shown.</i>
issue-no	Parameter type: <Shdsl::UnitVendorIssueNumber> - string indicates SHDSL unit's vendor issue number - length: x<=2	the vendor issue number for this SHDSL unit <i>This element is always shown.</i>
sw-version	Parameter type: <Shdsl::UnitVendorSwVersion> - string indicates SHDSL unit's vendor softwr version nbr - length: x<=32	the vendor software version number for this SHDSL unit <i>This element is always shown.</i>
clei-code	Parameter type: <Shdsl::UnitCleiCode> - string indicates SHDSL unit's Common Language Equipment Identifier code - length: x<=10	the Common Language Equipment Identifier code for this SHDSL unit <i>This element is always shown.</i>
vendor-id	Parameter type: <Shdsl::UnitVendorID> - a string indicates an SHDSL unit's vendor ID - length: x<=8	the vendor id for this SHDSL unit <i>This element is only shown in detail mode.</i>
model-no	Parameter type: <Shdsl::UnitVendorModelNumber> - a string indicates an SHDSL unit's vendor model number - length: x<=12	the vendor model number for this SHDSL unit <i>This element is only shown in detail mode.</i>
serial-no	Parameter type: <Shdsl::UnitVendorSerialNumber> - a string indicates an SHDSL unit's vendor serial number - length: x<=12	the vendor serial number for this SHDSL unit <i>This element is only shown in detail mode.</i>
other-info	Parameter type: <Shdsl::UnitVendorOtherInfo> - a string indicates an SHDSL unit's vendor specific info - length: x<=12	the vendor other specific information for this SHDSL unit <i>This element is only shown in detail mode.</i>
region-cap	Parameter type: <Shdsl::SpanRegionalSetting> (annex-a/f annex-b/g) Possible values: - annex-a/f : Annex A/F Region 1 - annex-b/g : Annex B/G Region 2	the regional capabilities that can be supported by this unit <i>This element is only shown in detail mode.</i>

149.3 SHDSL Span Status Command

Command Description

This command displays the SHDSL span status.

User Level

The command can be accessed by operators with xdsl privileges.

Command Syntax

The command has the following syntax:

```
> show shdsl span-status [ (if-index) ]
```

Command Parameters

Table 149.3-1 "SHDSL Span Status Command" Resource Parameters

Resource Identifier	Type	Description
(if-index)	Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number	interface index of the port

Command Output

Table 149.3-2 "SHDSL Span Status Command" Display parameters

Specific Information		
name	Type	Description
state	Parameter type: <Shdsl::SpanState> (unknown unequipped faulty idle startup active testing fwdownloading) Possible values: - unknown : the state is unknown	the overall state of this SHDSL span <i>This element is always shown.</i>

name	Type	Description
	- unequipped : the state is unequipped - faulty : the state is faulty - idle : the state is idle - startup : the state is startup - active : the state is active - testing : the state is testing - fwdownloading : the state is firmware downloading	
det-stu-c	Parameter type: <Shdsl::STUC> (no-stu-c stu-c) Possible values: - no-stu-c : STU-C isn't on this span - stu-c : STU-C is on this span	STU-C <i>This element is only shown in detail mode.</i>
det-stu-r	Parameter type: <Shdsl::STUR> (no-stu-r stu-r) Possible values: - no-stu-r : STU-R isn't on this span - stu-r : STU-R is on this span	STU-R <i>This element is only shown in detail mode.</i>
det-sru-1	Parameter type: <Shdsl::SRU1> (no-sru-1 sru-1) Possible values: - no-sru-1 : SRU-1 isn't on this span - sru-1 : SRU-1 is on this span	SRU-1 <i>This element is only shown in detail mode.</i>
det-sru-2	Parameter type: <Shdsl::SRU2> (no-sru-2 sru-2) Possible values: - no-sru-2 : SRU-2 isn't on this span - sru-2 : SRU-2 is on this span	SRU-2 <i>This element is only shown in detail mode.</i>
det-sru-3	Parameter type: <Shdsl::SRU3> (no-sru-3 sru-3) Possible values: - no-sru-3 : SRU-3 isn't on this span - sru-3 : SRU-3 is on this span	SRU-3 <i>This element is only shown in detail mode.</i>
det-sru-4	Parameter type: <Shdsl::SRU4> (no-sru-4 sru-4) Possible values: - no-sru-4 : SRU-4 isn't on this span - sru-4 : SRU-4 is on this span	SRU-4 <i>This element is only shown in detail mode.</i>
det-sru-5	Parameter type: <Shdsl::SRU5> (no-sru-5 sru-5) Possible values: - no-sru-5 : SRU-5 isn't on this span - sru-5 : SRU-5 is on this span	SRU-5 <i>This element is only shown in detail mode.</i>
det-sru-6	Parameter type: <Shdsl::SRU6> (no-sru-6 sru-6) Possible values: - no-sru-6 : SRU-6 isn't on this span - sru-6 : SRU-6 is on this span	SRU-6 <i>This element is only shown in detail mode.</i>
det-sru-7	Parameter type: <Shdsl::SRU7> (no-sru-7	SRU-7 <i>This element is only shown in</i>

name	Type	Description
	sru-7) Possible values: - no-sru-7 : SRU-7 isn't on this span - sru-7 : SRU-7 is on this span	<i>detail mode.</i>
det-sru-8	Parameter type: <Shdsl::SRU8> (no-sru-8 sru-8) Possible values: - no-sru-8 : SRU-8 isn't on this span - sru-8 : SRU-8 is on this span	SRU-8 <i>This element is only shown in detail mode.</i>
inv-stu-c	Parameter type: <Shdsl::STUC> (no-stu-c stu-c) Possible values: - no-stu-c : STU-C isn't on this span - stu-c : STU-C is on this span	STU-C <i>This element is only shown in detail mode.</i>
inv-stu-r	Parameter type: <Shdsl::STUR> (no-stu-r stu-r) Possible values: - no-stu-r : STU-R isn't on this span - stu-r : STU-R is on this span	STU-R <i>This element is only shown in detail mode.</i>
inv-sru-1	Parameter type: <Shdsl::SRU1> (no-sru-1 sru-1) Possible values: - no-sru-1 : SRU-1 isn't on this span - sru-1 : SRU-1 is on this span	SRU-1 <i>This element is only shown in detail mode.</i>
inv-sru-2	Parameter type: <Shdsl::SRU2> (no-sru-2 sru-2) Possible values: - no-sru-2 : SRU-2 isn't on this span - sru-2 : SRU-2 is on this span	SRU-2 <i>This element is only shown in detail mode.</i>
inv-sru-3	Parameter type: <Shdsl::SRU3> (no-sru-3 sru-3) Possible values: - no-sru-3 : SRU-3 isn't on this span - sru-3 : SRU-3 is on this span	SRU-3 <i>This element is only shown in detail mode.</i>
inv-sru-4	Parameter type: <Shdsl::SRU4> (no-sru-4 sru-4) Possible values: - no-sru-4 : SRU-4 isn't on this span - sru-4 : SRU-4 is on this span	SRU-4 <i>This element is only shown in detail mode.</i>
inv-sru-5	Parameter type: <Shdsl::SRU5> (no-sru-5 sru-5) Possible values: - no-sru-5 : SRU-5 isn't on this span - sru-5 : SRU-5 is on this span	SRU-5 <i>This element is only shown in detail mode.</i>
inv-sru-6	Parameter type: <Shdsl::SRU6> (no-sru-6 sru-6) Possible values: - no-sru-6 : SRU-6 isn't on this span	SRU-6 <i>This element is only shown in detail mode.</i>

149 SHDSL Status Commands

name	Type	Description
	- sru-6 : SRU-6 is on this span	
inv-sru-7	Parameter type: <Shdsl::SRU7> (no-sru-7 sru-7) Possible values: - no-sru-7 : SRU-7 isn't on this span - sru-7 : SRU-7 is on this span	SRU-7 <i>This element is only shown in detail mode.</i>
inv-sru-8	Parameter type: <Shdsl::SRU8> (no-sru-8 sru-8) Possible values: - no-sru-8 : SRU-8 isn't on this span - sru-8 : SRU-8 is on this span	SRU-8 <i>This element is only shown in detail mode.</i>
con-stu-c	Parameter type: <Shdsl::STUC> (no-stu-c stu-c) Possible values: - no-stu-c : STU-C isn't on this span - stu-c : STU-C is on this span	STU-C <i>This element is only shown in detail mode.</i>
con-stu-r	Parameter type: <Shdsl::STUR> (no-stu-r stu-r) Possible values: - no-stu-r : STU-R isn't on this span - stu-r : STU-R is on this span	STU-R <i>This element is only shown in detail mode.</i>
con-sru-1	Parameter type: <Shdsl::SRU1> (no-sru-1 sru-1) Possible values: - no-sru-1 : SRU-1 isn't on this span - sru-1 : SRU-1 is on this span	SRU-1 <i>This element is only shown in detail mode.</i>
con-sru-2	Parameter type: <Shdsl::SRU2> (no-sru-2 sru-2) Possible values: - no-sru-2 : SRU-2 isn't on this span - sru-2 : SRU-2 is on this span	SRU-2 <i>This element is only shown in detail mode.</i>
con-sru-3	Parameter type: <Shdsl::SRU3> (no-sru-3 sru-3) Possible values: - no-sru-3 : SRU-3 isn't on this span - sru-3 : SRU-3 is on this span	SRU-3 <i>This element is only shown in detail mode.</i>
con-sru-4	Parameter type: <Shdsl::SRU4> (no-sru-4 sru-4) Possible values: - no-sru-4 : SRU-4 isn't on this span - sru-4 : SRU-4 is on this span	SRU-4 <i>This element is only shown in detail mode.</i>
con-sru-5	Parameter type: <Shdsl::SRU5> (no-sru-5 sru-5) Possible values: - no-sru-5 : SRU-5 isn't on this span - sru-5 : SRU-5 is on this span	SRU-5 <i>This element is only shown in detail mode.</i>
con-sru-6	Parameter type: <Shdsl::SRU6> (no-sru-6	SRU-6 <i>This element is only shown in</i>

name	Type	Description
	sru-6) Possible values: - no-sru-6 : SRU-6 isn't on this span - sru-6 : SRU-6 is on this span	detail mode.
con-sru-7	Parameter type: <Shdsl::SRU7> (no-sru-7 sru-7) Possible values: - no-sru-7 : SRU-7 isn't on this span - sru-7 : SRU-7 is on this span	SRU-7 <i>This element is only shown in detail mode.</i>
con-sru-8	Parameter type: <Shdsl::SRU8> (no-sru-8 sru-8) Possible values: - no-sru-8 : SRU-8 isn't on this span - sru-8 : SRU-8 is on this span	SRU-8 <i>This element is only shown in detail mode.</i>
stat-losw	Parameter type: <Shdsl::LOSW> (no-losw losw) Possible values: - no-losw : no loss of word - losw : loss of word	loss of word <i>This element is only shown in detail mode.</i>
stat-lp-attn	Parameter type: <Shdsl::LpAttn> (no-lp-attn lp-attn) Possible values: - no-lp-attn : no loop attenuation - lp-attn : loop attenuation	loop attenuation alarm <i>This element is only shown in detail mode.</i>
stat-snr	Parameter type: <Shdsl::SNR> (no-snr snr) Possible values: - no-snr : no snr margin alarm - snr : snr margin alarm	snr margin alarm <i>This element is only shown in detail mode.</i>
stat-dc	Parameter type: <Shdsl::DC> (no-dc dc) Possible values: - no-dc : no dc continuity fault - dc : dc continuity fault	dc continuity fault <i>This element is only shown in detail mode.</i>
stat-dev	Parameter type: <Shdsl::Dev> (no-dev dev) Possible values: - no-dev : no device fault - dev : device fault	device fault <i>This element is only shown in detail mode.</i>
stat-conf	Parameter type: <Shdsl::Conf> (no-conf conf) Possible values: - no-conf : no configuration error - conf : configuration error	configuration error <i>This element is only shown in detail mode.</i>
stat-lp-act	Parameter type: <Shdsl::LpAct> (no-lp-act lp-act) Possible values: - no-lp-act : no loopback active	loopback active <i>This element is only shown in detail mode.</i>

149 SHDSL Status Commands

name	Type	Description
	- lp-act : loopback active	
stat-no-con	Parameter type: <Shdsl::NoCon> (no-no-con no-con) Possible values: - no-no-con : conform to stu-c of stu-r initiated management flow - no-con : not conform to stu-c of stu-r initiated management flow	not conform to stu-c of stu-r initiated management flow <i>This element is only shown in detail mode.</i>
stat-lcd	Parameter type: <Shdsl::LCD> (no-lcd lcd) Possible values: - no-lcd : no ATM loss of cell delineation - lcd : ATM loss of cell delineation	ATM loss of cell delineation <i>This element is only shown in detail mode.</i>
stat-lop	Parameter type: <Shdsl::LOP> (no-lop lop) Possible values: - no-lop : no loss of power - lop : loss of power	loss of power <i>This element is only shown in detail mode.</i>
stat-ncd	Parameter type: <Shdsl::NCD> (no-ncd ncd) Possible values: - no-ncd : disable no-cell-delineation - ncd : no cell delineation	no cell delineation <i>This element is only shown in detail mode.</i>
stat-act-fail	Parameter type: <Shdsl::ActFail> (no-act-fail act-fail) Possible values: - no-act-fail : no activation failure - act-fail : activation failure	activation failure <i>This element is only shown in detail mode.</i>
first-port	Parameter type: <Shdsl::FirstPort> (first-pair second-pair third-pair fourth-pair) Possible values: - first-pair : first pair - second-pair : second pair - third-pair : third pair - fourth-pair : fourth pair	first-port <i>This element is always shown.</i>
second-port	Parameter type: <Shdsl::SecondPort> (first-pair second-pair third-pair fourth-pair) Possible values: - first-pair : first pair - second-pair : second pair - third-pair : third pair - fourth-pair : fourth pair	second-port <i>This element is always shown.</i>
third-port	Parameter type: <Shdsl::ThirdPort> (first-pair second-pair third-pair	third-port <i>This element is always shown.</i>

name	Type	Description
	fourth-pair) Possible values: - first-pair : first pair - second-pair : second pair - third-pair : third pair - fourth-pair : fourth pair	
fourth-port	Parameter type: <Shdsl::FourthPort> (first-pair second-pair third-pair fourth-pair) Possible values: - first-pair : first pair - second-pair : second pair - third-pair : third pair - fourth-pair : fourth pair	fourth-port <i>This element is always shown.</i>
curr-data-rate	Parameter type: <Shdsl::BitRate> - bitrate - unit: kbits/sec	the current SHDSL data rate <i>This element is always shown.</i>
tc-pam-modu	Parameter type: <Shdsl::SpanTCPAMModulation> (tc-pam32 tc-pam16 unknown) Possible values: - tc-pam32 : tcPam32 modulation - tc-pam16 : tcPam16 modulation - unknown : unknown modulation	the current TC-PAM modulation of the span <i>This element is always shown.</i>
efm-hs-mode	Parameter type: <Shdsl::SpanEFMHandshakeMode> (unknown ieee itu not-applicable) Possible values: - unknown : unknown handshake mode - ieee : ieee 2base-tl - itu : itu-t g.991.2 ptm 64/65otc - not-applicable : not-applicable for atm/ima mode	the actual handshake mode for the span <i>This element is always shown.</i>

149.4 SHDSL Unit Status Command

Command Description

This command displays the SHDSL unit status.

User Level

The command can be accessed by operators with xdsl privileges.

Command Syntax

The command has the following syntax:

```
> show shdsl unit-status [ (if-index) [ unit-id <Shdsl::UnitId> ] ]
```

Command Parameters

Table 149.4-1 "SHDSL Unit Status Command" Resource Parameters

Resource Identifier	Type	Description
(if-index)	Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number	interface index of the port
unit-id	Parameter type: <Shdsl::UnitId> Format: (stu-c stu-r sru-1 sru-2 sru-3 sru-4 sru-5 sru-6 sru-7 sru-8) Possible values: - stu-c : the SHDSL unit is STU-C - stu-r : the SHDSL unit is STU-R - sru-1 : the SHDSL unit is SRU-1 - sru-2 : the SHDSL unit is SRU-2 - sru-3 : the SHDSL unit is SRU-3	unit identifier in an SHDSL span

Resource Identifier	Type	Description
	- sru-4 : the SHDSL unit is SRU-4 - sru-5 : the SHDSL unit is SRU-5 - sru-6 : the SHDSL unit is SRU-6 - sru-7 : the SHDSL unit is SRU-7 - sru-8 : the SHDSL unit is SRU-8	

Command Output

Table 149.4-2 "SHDSL Unit Status Command" Display parameters

Specific Information		
name	Type	Description
dc-pow	Parameter type: <Shdsl::UnitDCPowering> (local-pow span-pow) Possible values: - local-pow : locally powered - span-pow : span powered	the powering mode of this SHDSL span <i>This element is always shown.</i>

149.5 SHDSL Segment Status Command

Command Description

This command displays the status of individual segment end points in an SHDSL span.

User Level

The command can be accessed by operators with xdsl privileges.

Command Syntax

The command has the following syntax:

```
> show shdsl segment-status [ (if-index) [ unit-id <Shdsl::UnitId> ] [ side <Shdsl::SegmentSide> ] [ wire-pair
<Shdsl::SegmentTerminationWirePair> ] ]
```

Command Parameters

Table 149.5-1 "SHDSL Segment Status Command" Resource Parameters

Resource Identifier	Type	Description
(if-index)	Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number	interface index of the port
unit-id	Parameter type: <Shdsl::UnitId> Format: (stu-c stu-r sru-1 sru-2 sru-3 sru-4 sru-5 sru-6 sru-7 sru-8) Possible values: - stu-c : the SHDSL unit is STU-C - stu-r : the SHDSL unit is STU-R - sru-1 : the SHDSL unit is SRU-1 - sru-2 : the SHDSL unit is SRU-2	unit identifier in an SHDSL span

Resource Identifier	Type	Description
	- sru-3 : the SHDSL unit is SRU-3 - sru-4 : the SHDSL unit is SRU-4 - sru-5 : the SHDSL unit is SRU-5 - sru-6 : the SHDSL unit is SRU-6 - sru-7 : the SHDSL unit is SRU-7 - sru-8 : the SHDSL unit is SRU-8	
side	Parameter type: <Shdsl::SegmentSide> Format: (network customer) Possible values: - network : the network side - customer : the customer side	the particular side of an SHDSL unit in an SHDSL segment
wire-pair	Parameter type: <Shdsl::SegmentTerminationWirePair> Format: (one two three four) Possible values: - one : the first pair - two : the second pair - three : the third pair - four : the fourth pair	the particular wire pair of an SHDSL segment

Command Output

Table 149.5-2 "SHDSL Segment Status Command" Display parameters

Specific Information		
name	Type	Description
seg-st-losw	Parameter type: <Shdsl::LOSW> (no-losw losw) Possible values: - no-losw : no loss of word - losw : loss of word	loss of word <i>This element is only shown in detail mode.</i>
seg-st-lp-attn	Parameter type: <Shdsl::LpAttn> (no-lp-attn lp-attn) Possible values: - no-lp-attn : no loop attenuation - lp-attn : loop attenuation	loop attenuation alarm <i>This element is only shown in detail mode.</i>
seg-st-snr	Parameter type: <Shdsl::SNR> (no-snr snr) Possible values: - no-snr : no snr margin alarm - snr : snr margin alarm	snr margin alarm <i>This element is only shown in detail mode.</i>
seg-st-dc	Parameter type: <Shdsl::DC> (no-dc dc) Possible values: - no-dc : no dc continuity fault - dc : dc continuity fault	dc continuity fault <i>This element is only shown in detail mode.</i>
seg-st-dev	Parameter type: <Shdsl::Dev> (no-dev	device fault <i>This element is only shown in</i>

149 SHDSL Status Commands

name	Type	Description
	dev) Possible values: - no-dev : no device fault - dev : device fault	detail mode.
seg-st-conf	Parameter type: <Shdsl::Conf> (no-conf conf) Possible values: - no-conf : no configuration error - conf : configuration error	configuration error <i>This element is only shown in detail mode.</i>
seg-st-lp-act	Parameter type: <Shdsl::LpAct> (no-lp-act lp-act) Possible values: - no-lp-act : no loopback active - lp-act : loopback active	loopback active <i>This element is only shown in detail mode.</i>
seg-st-no-con	Parameter type: <Shdsl::NoCon> (no-no-con no-con) Possible values: - no-no-con : conform to stu-c of stu-r initiated management flow - no-con : not conform to stu-c of stu-r initiated management flow	not conform to stu-c of stu-r initiated management flow <i>This element is only shown in detail mode.</i>
seg-st-lcd	Parameter type: <Shdsl::LCD> (no-lcd lcd) Possible values: - no-lcd : no ATM loss of cell delineation - lcd : ATM loss of cell delineation	ATM loss of cell delineation <i>This element is only shown in detail mode.</i>
seg-st-lop	Parameter type: <Shdsl::LOP> (no-lop lop) Possible values: - no-lop : no loss of power - lop : loss of power	loss of power <i>This element is only shown in detail mode.</i>
seg-st-ncd	Parameter type: <Shdsl::NCD> (no-ncd ncd) Possible values: - no-ncd : disable no-cell-delineation - ncd : no cell delineation	no cell delineation <i>This element is only shown in detail mode.</i>
seg-st-act-fail	Parameter type: <Shdsl::ActFail> (no-act-fail act-fail) Possible values: - no-act-fail : no activation failure - act-fail : activation failure	activation failure <i>This element is only shown in detail mode.</i>
lpbk-stat	Parameter type: <Shdsl::SegmentTermLoopbackState> (no-lpbk norm spec) Possible values: - no-lpbk : no loopback - norm : normal loopback - spec : special loopback	the loopback mode at this SHDSL segment termination <i>This element is always shown.</i>
snr-mgn	Parameter type: <Shdsl::SegmentTerminationSnrMargin>	the SNR margin at this SHDSL

name	Type	Description
	- an SNR margin value measured for an SHDSL segment - unit: db - range: [-128...127]	segment termination <i>This element is always shown.</i>
lp-at	Parameter type: <Shdsl::SegmentTermLoopAttenuation> - a loop attenuation value measured for an SHDSL segment - unit: db - range: [-128...127]	the loop attenuation at this SHDSL segment termination <i>This element is always shown.</i>
pbo-l1	Parameter type: <Shdsl::SegmentTermPowerBackoffLv1> - power backoff level 1 value measured for SHDSL segment - unit: db - range: [0...31,255]	the power backoff level 1 value at this SHDSL segment termination <i>This element is always shown.</i>
tip-ring-reversal	Parameter type: <Shdsl::SegmentTermTRReversal> (normal reversed) Possible values: - normal : normal mode - reversed : reversed mode	the tip/ring pair state at this SHDSL segment termination <i>This element is always shown.</i>
pbo-mode	Parameter type: <Shdsl::SegmentTerminationPBOStatus> (default selected disabled) Possible values: - default : default mode - selected : selected mode - disabled : disable PBO	the power backoff state at this SHDSL segment termination <i>This element is always shown.</i>
curr-data-rate	Parameter type: <Shdsl::SegmentTerminationCurrentDataRate> - the current shdsl data rate of this segment termination - unit: kb/s - range: [0,192...5696]	the current shdsl data rate of this segment termination <i>This element is always shown.</i>
act-state	Parameter type: <Shdsl::SegmentTerminationActivationState> (active idle unknown initialization exception testing fwdownloading) Possible values: - active : the state is active - idle : the state is idle - unknown : the status is unknown - initialization : the state is initializing - exception : the state is exception - testing : the state is testing - fwdownloading : the state is firmware downloading	the state of this segment termination <i>This element is always shown.</i>
act-fail	Parameter type: <UnsignedSignedInteger> - an unsigned integer	the coded reason of activation failure <i>This element is always shown.</i>
tc-pam-modu	Parameter type: <Shdsl::SegmentTerminationTCPAMModulation> (tc-pam32 tc-pam16 unknown) Possible values: - tc-pam32 : tcPam32 modulation	the current TC-PAM modulation of the segment termination <i>This element is always shown.</i>

149 SHDSL Status Commands

name	Type	Description
	- tc-pam16 : tcPam16 modulation - unknown : unknown modulation	

149.6 SHDSL Segment Counters Current Interval Status Command

Command Description

This command displays the operational data of individual segment end points in an SHDSL span.

User Level

The command can be accessed by operators with xdsl privileges.

Command Syntax

The command has the following syntax:

```
> show shdsl segment-counters current-15min [ (if-index) [ unit-id <Shdsl::UnitId> ] [ side <Shdsl::SegmentSide> ] [ wire-pair <Shdsl::SegmentTerminationWirePair> ] ]
```

Command Parameters

Table 149.6-1 "SHDSL Segment Counters Current Interval Status Command" Resource Parameters

Resource Identifier	Type	Description
(if-index)	Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number	interface index of the port
unit-id	Parameter type: <Shdsl::UnitId> Format: (stu-c stu-r sru-1 sru-2 sru-3 sru-4 sru-5 sru-6 sru-7 sru-8) Possible values:	unit identifier in an SHDSL span

Resource Identifier	Type	Description
	- stu-c : the SHDSL unit is STU-C - stu-r : the SHDSL unit is STU-R - sru-1 : the SHDSL unit is SRU-1 - sru-2 : the SHDSL unit is SRU-2 - sru-3 : the SHDSL unit is SRU-3 - sru-4 : the SHDSL unit is SRU-4 - sru-5 : the SHDSL unit is SRU-5 - sru-6 : the SHDSL unit is SRU-6 - sru-7 : the SHDSL unit is SRU-7 - sru-8 : the SHDSL unit is SRU-8	
side	Parameter type: <Shdsl::SegmentSide> Format: (network customer) Possible values: - network : the network side - customer : the customer side	the particular side of an SHDSL unit in an SHDSL segment
wire-pair	Parameter type: <Shdsl::SegmentTerminationWirePair> Format: (one two three four) Possible values: - one : the first pair - two : the second pair - three : the third pair - four : the fourth pair	the particular wire pair of an SHDSL segment

Command Output

Table 149.6-2 "SHDSL Segment Counters Current Interval Status Command" Display parameters

Specific Information		
name	Type	Description
time-el	Parameter type: <Shdsl::SegmentTermCurr15MTimeElapsed> - an elapsed seconds in the current 15-minute interval - unit: sec	the elapsed seconds in the current 15-minute interval <i>This element is always shown.</i>
es	Parameter type: <Counter> - 32 bit counter	number of errored seconds <i>This element is always shown.</i>
ses	Parameter type: <Counter> - 32 bit counter	number of severely errored seconds <i>This element is always shown.</i>
crc	Parameter type: <Counter> - 32 bit counter	number of CRC anomalies <i>This element is always shown.</i>
losws	Parameter type: <Counter> - 32 bit counter	number of loss of sync word <i>This element is always shown.</i>
uas	Parameter type: <Counter> - 32 bit counter	number of unavailable seconds <i>This element is always shown.</i>
va-int	Parameter type: <Shdsl::SegmentTermCurr15MValidIntervals> - a number of previous intervals for which data has been stored - range: [0...96]	the number of previous intervals for which data has been stored <i>This element is always shown.</i>
inv-flag	Parameter type: <Shdsl::IntervalInvalidDataFlag> (true	validity flag of the corresponding PM data in current 15 minutes

name	Type	Description
	false) Possible values: - true : data is not valid - false : data is valid	<i>This element is always shown.</i>
re-init-fail	Parameter type: <Counter> - 32 bit counter	number of failed re-inits <i>This element is always shown.</i>

149.7 SHDSL Segment Counters Current Day Status Command

Command Description

This command displays the current day counters of individual segment end points in an SHDSL span.

User Level

The command can be accessed by operators with xdsl privileges.

Command Syntax

The command has the following syntax:

```
> show shdsl segment-counters current-1day [ (if-index) [ unit-id <Shdsl::UnitId> ] [ side <Shdsl::SegmentSide> ]  
[ wire-pair <Shdsl::SegmentTerminationWirePair> ] ]
```

Command Parameters

Table 149.7-1 "SHDSL Segment Counters Current Day Status Command" Resource Parameters

Resource Identifier	Type	Description
(if-index)	Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number	interface index of the port
unit-id	Parameter type: <Shdsl::UnitId> Format: (stu-c stu-r sru-1 sru-2 sru-3 sru-4 sru-5 sru-6 sru-7 sru-8) Possible values: - stu-c : the SHDSL unit is STU-C	unit identifier in an SHDSL span

Resource Identifier	Type	Description
	- stu-r : the SHDSL unit is STU-R - sru-1 : the SHDSL unit is SRU-1 - sru-2 : the SHDSL unit is SRU-2 - sru-3 : the SHDSL unit is SRU-3 - sru-4 : the SHDSL unit is SRU-4 - sru-5 : the SHDSL unit is SRU-5 - sru-6 : the SHDSL unit is SRU-6 - sru-7 : the SHDSL unit is SRU-7 - sru-8 : the SHDSL unit is SRU-8	
side	Parameter type: <Shdsl::SegmentSide> Format: (network customer) Possible values: - network : the network side - customer : the customer side	the particular side of an SHDSL unit in an SHDSL segment
wire-pair	Parameter type: <Shdsl::SegmentTerminationWirePair> Format: (one two three four) Possible values: - one : the first pair - two : the second pair - three : the third pair - four : the fourth pair	the particular wire pair of an SHDSL segment

Command Output

Table 149.7-2 "SHDSL Segment Counters Current Day Status Command" Display parameters

Specific Information		
name	Type	Description
time-el	Parameter type: <Shdsl::SegmentTermCurr1DTimeElapsed> - an elapsed seconds in the current day interval - unit: sec	the elapsed seconds in the current day interval <i>This element is always shown.</i>
es	Parameter type: <Counter> - 32 bit counter	number of errored seconds <i>This element is always shown.</i>
ses	Parameter type: <Counter> - 32 bit counter	number of severely errored seconds <i>This element is always shown.</i>
crc	Parameter type: <Counter> - 32 bit counter	number of CRC anomalies <i>This element is always shown.</i>
losws	Parameter type: <Counter> - 32 bit counter	number of loss of sync word <i>This element is always shown.</i>
uas	Parameter type: <Counter> - 32 bit counter	number of unavailable seconds <i>This element is always shown.</i>
va-int	Parameter type: <Shdsl::SegmentTermCurr1DValidIntervals> - a number of previous intervals for which data has been stored - range: [0...30]	the number of previous intervals for which data has been stored <i>This element is always shown.</i>
inv-flag	Parameter type: <Shdsl::IntervalInvalidDataFlag> (true false)	validity flag of the corresponding PM data in current day <i>This element is always shown.</i>

149 SHDSL Status Commands

name	Type	Description
	Possible values: - true : data is not valid - false : data is valid	
re-init-fail	Parameter type: <Counter> - 32 bit counter	number of failed re-inits <i>This element is always shown.</i>

149.8 SHDSL Segment Counters Previous Interval Status Command

Command Description

This command displays the previous interval counters of individual segment end points in an SHDSL span.

User Level

The command can be accessed by operators with xdsl privileges.

Command Syntax

The command has the following syntax:

```
> show shdsl segment-counters previous-15min [ (if-index) [ unit-id <Shdsl::UnitId> ] [ side
<Shdsl::SegmentSide> ] [ wire-pair <Shdsl::SegmentTerminationWirePair> ] [ int-no <Shdsl::IntervalNumber> ] ]
```

Command Parameters

Table 149.8-1 "SHDSL Segment Counters Previous Interval Status Command" Resource Parameters

Resource Identifier	Type	Description
(if-index)	Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number	interface index of the port
unit-id	Parameter type: <Shdsl::UnitId> Format: (stu-c stu-r sru-1 sru-2 sru-3 sru-4 sru-5 sru-6 sru-7 sru-8) Possible values:	unit identifier in an SHDSL span

Resource Identifier	Type	Description
	- stu-c : the SHDSL unit is STU-C - stu-r : the SHDSL unit is STU-R - sru-1 : the SHDSL unit is SRU-1 - sru-2 : the SHDSL unit is SRU-2 - sru-3 : the SHDSL unit is SRU-3 - sru-4 : the SHDSL unit is SRU-4 - sru-5 : the SHDSL unit is SRU-5 - sru-6 : the SHDSL unit is SRU-6 - sru-7 : the SHDSL unit is SRU-7 - sru-8 : the SHDSL unit is SRU-8	
side	Parameter type: <Shdsl::SegmentSide> Format: (network customer) Possible values: - network : the network side - customer : the customer side	the particular side of an SHDSL unit in an SHDSL segment
wire-pair	Parameter type: <Shdsl::SegmentTerminationWirePair> Format: (one two three four) Possible values: - one : the first pair - two : the second pair - three : the third pair - four : the fourth pair	the particular wire pair of an SHDSL segment
int-no	Parameter type: <Shdsl::IntervalNumber> Format: - a performance interval number - range: [1...96]	the performance interval number

Command Output

Table 149.8-2 "SHDSL Segment Counters Previous Interval Status Command" Display parameters

Specific Information		
name	Type	Description
mon-sec	Parameter type: <Shdsl::PreviousIntervalMoniSecs> - a monitored seconds number - unit: sec	number of actually monitored seconds in this interval <i>This element is always shown.</i>
es	Parameter type: <Counter> - 32 bit counter	number of errored seconds <i>This element is always shown.</i>
ses	Parameter type: <Counter> - 32 bit counter	number of severely errored seconds <i>This element is always shown.</i>
crc	Parameter type: <Counter> - 32 bit counter	number of CRC anomalies <i>This element is always shown.</i>
losws	Parameter type: <Counter> - 32 bit counter	number of loss of sync word <i>This element is always shown.</i>
uas	Parameter type: <Counter> - 32 bit counter	number of unavailable seconds <i>This element is always shown.</i>
inv-flag	Parameter type: <Shdsl::IntervalInvalidDataFlag> (true false) Possible values:	validity flag of the corresponding PM data in previous 15-minutes interval <i>This element is always shown.</i>

name	Type	Description
	- true : data is not valid - false : data is valid	
interval-time	Parameter type: <Xdsl::PmTimeStamp> - Timestamp for Pm interval(yyyymmdd:hour:minutes)	specifies the start time of interval <i>This element is always shown.</i>
re-init-fail	Parameter type: <Counter> - 32 bit counter	number of failed re-inits <i>This element is always shown.</i>

149.9 SHDSL Segment Counters Previous Day Status Command

Command Description

This command displays the previous day counters of individual segment end points in an SHDSL span.

User Level

The command can be accessed by operators with xdsl privileges.

Command Syntax

The command has the following syntax:

```
> show shdsl segment-counters previous-1day [ (if-index) [ unit-id <Shdsl::UnitId> ] [ side <Shdsl::SegmentSide> ] [ wire-pair <Shdsl::SegmentTerminationWirePair> ] [ int-no <Shdsl::Interval1DayNumber> ] ]
```

Command Parameters

Table 149.9-1 "SHDSL Segment Counters Previous Day Status Command" Resource Parameters

Resource Identifier	Type	Description
(if-index)	Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number	interface index of the port
unit-id	Parameter type: <Shdsl::UnitId> Format: (stu-c stu-r sru-1 sru-2 sru-3 sru-4 sru-5 sru-6 sru-7 sru-8) Possible values: - stu-c : the SHDSL unit is STU-C	unit identifier in an SHDSL span

Resource Identifier	Type	Description
	- stu-r : the SHDSL unit is STU-R - sru-1 : the SHDSL unit is SRU-1 - sru-2 : the SHDSL unit is SRU-2 - sru-3 : the SHDSL unit is SRU-3 - sru-4 : the SHDSL unit is SRU-4 - sru-5 : the SHDSL unit is SRU-5 - sru-6 : the SHDSL unit is SRU-6 - sru-7 : the SHDSL unit is SRU-7 - sru-8 : the SHDSL unit is SRU-8	
side	Parameter type: <Shdsl::SegmentSide> Format: (network customer) Possible values: - network : the network side - customer : the customer side	the particular side of an SHDSL unit in an SHDSL segment
wire-pair	Parameter type: <Shdsl::SegmentTerminationWirePair> Format: (one two three four) Possible values: - one : the first pair - two : the second pair - three : the third pair - four : the fourth pair	the particular wire pair of an SHDSL segment
int-no	Parameter type: <Shdsl::Interval1DayNumber> Format: - a performance interval one day number - range: [1...30]	the performance interval number

Command Output

Table 149.9-2 "SHDSL Segment Counters Previous Day Status Command" Display parameters

Specific Information		
name	Type	Description
mon-sec	Parameter type: <Shdsl::PreviousInterval1DayMoniSecs> - a monitored seconds number - unit: sec	number of actually monitored seconds in this interval <i>This element is always shown.</i>
es	Parameter type: <Counter> - 32 bit counter	number of errored seconds <i>This element is always shown.</i>
ses	Parameter type: <Counter> - 32 bit counter	number of severely errored seconds <i>This element is always shown.</i>
crc	Parameter type: <Counter> - 32 bit counter	number of CRC anomalies <i>This element is always shown.</i>
losws	Parameter type: <Counter> - 32 bit counter	number of loss of sync word <i>This element is always shown.</i>
uas	Parameter type: <Counter> - 32 bit counter	number of unavailable seconds <i>This element is always shown.</i>
inv-flag	Parameter type: <Shdsl::IntervalInvalidDataFlag> (true false) Possible values: - true : data is not valid	validity flag of the corresponding PM data in previous day interval <i>This element is always shown.</i>

149 SHDSL Status Commands

name	Type	Description
	- false : data is valid	
interval-time	Parameter type: <Xdsl::PmTimeStamp> - Timestamp for Pm interval(yyyymmdd:hour:minutes)	specifies the start time of interval <i>This element is always shown.</i>
re-init-fail	Parameter type: <Counter> - 32 bit counter	number of failed re-inits <i>This element is always shown.</i>

149.10 SHDSL Span Current Interval Performance Data Status Command

Command Description

This command displays the current interval performance data of an SHDSL span.

User Level

The command can be accessed by operators with xdsl privileges.

Command Syntax

The command has the following syntax:

```
> show shdsl span-counters current-15min [ (if-index) ]
```

Command Parameters

Table 149.10-1 "SHDSL Span Current Interval Performance Data Status Command" Resource Parameters

Resource Identifier	Type	Description
(if-index)	Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number	interface index of the port

Command Output

Table 149.10-2 "SHDSL Span Current Interval Performance Data Status Command" Display parameters

Specific Information		
name	Type	Description
time-el	Parameter type: <Shdsl::PMCurr15MinTimeElapsed> - an elapsed seconds in the current 15-minute interval - unit: sec	the elapsed seconds in the current 15-minute interval <i>This element is always shown.</i>
re-init	Parameter type: <Counter> - 32 bit counter	number of total reinitializations <i>This element is always shown.</i>

149 SHDSL Status Commands

name	Type	Description
re-init-lpr	Parameter type: <Counter> - 32 bit counter	number of total reinitializations due to lpr events <i>This element is always shown.</i>
valid-interval	Parameter type: <Shdsl::PM15MinValidIntervals> - number of previous intrvl for which data is stored - range: [0...96]	the number of previous intervals for which data has been stored <i>This element is always shown.</i>
re-init-fail	Parameter type: <Counter> - 32 bit counter	Count of the re-initializations failed <i>This element is always shown.</i>
inv-flag	Parameter type: <Shdsl::IntervalInvalidDataFlag> (true false) Possible values: - true : data is not valid - false : data is valid	validity flag of the corresponding PM data in current 15 minutes <i>This element is always shown.</i>

149.11 SHDSL Span Current Day Performance Data Status Command

Command Description

This command displays the current day performance data of an SHDSL span.

User Level

The command can be accessed by operators with xdsl privileges.

Command Syntax

The command has the following syntax:

```
> show shdsl span-counters current-1day [ (if-index) ]
```

Command Parameters

Table 149.11-1 "SHDSL Span Current Day Performance Data Status Command" Resource Parameters

Resource Identifier	Type	Description
(if-index)	Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number	interface index of the port

Command Output

Table 149.11-2 "SHDSL Span Current Day Performance Data Status Command" Display parameters

Specific Information		
name	Type	Description
time-el	Parameter type: <Shdsl::PMCurr1DayTimeElapsed> - an elapsed seconds in the current day interval - unit: sec	the elapsed seconds in the current day interval <i>This element is always shown.</i>
re-init	Parameter type: <Counter> - 32 bit counter	number of total reinitializations <i>This element is always shown.</i>

149 SHDSL Status Commands

name	Type	Description
re-init-lpr	Parameter type: <Counter> - 32 bit counter	number of total reinitializations due to lpr events <i>This element is always shown.</i>
valid-interval	Parameter type: <Shdsl::PM1DayValidIntervals> - number of previous 1day intrvl for which data is stored - range: [0...30]	the number of previous intervals for which data has been stored <i>This element is always shown.</i>
re-init-fail	Parameter type: <Counter> - 32 bit counter	Count of the re-initializations failed <i>This element is always shown.</i>
inv-flag	Parameter type: <Shdsl::IntervalInvalidDataFlag> (true false) Possible values: - true : data is not valid - false : data is valid	validity flag of the corresponding PM data in current day <i>This element is always shown.</i>

149.12 SHDSL Span Previous Interval Performance Data Status Command

Command Description

This command displays the previous interval performance data of an SHDSL span.

User Level

The command can be accessed by operators with xdsl privileges.

Command Syntax

The command has the following syntax:

```
> show shdsl span-counters previous-15min [ (if-index) [ interval-number <Shdsl::PM15MinIntervalNumber> ] ]
```

Command Parameters

Table 149.12-1 "SHDSL Span Previous Interval Performance Data Status Command" Resource Parameters

Resource Identifier	Type	Description
(if-index)	Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number	interface index of the port
interval-number	Parameter type: <Shdsl::PM15MinIntervalNumber> Format: - a performance interval number - range: [1...96]	the performance interval number

Command Output

Table 149.12-2 "SHDSL Span Previous Interval Performance Data Status Command" Display parameters

Specific Information		
name	Type	Description
moni-secs	Parameter type: <Shdsl::PM15MinIntevalMoniSecs>	number of actually monitored

149 SHDSL Status Commands

name	Type	Description
	- a monitored seconds in a previous 15-minute interval - unit: sec	seconds in this interval <i>This element is always shown.</i>
re-init	Parameter type: <Counter> - 32 bit counter	number of total reinitializations <i>This element is always shown.</i>
re-init-lpr	Parameter type: <Counter> - 32 bit counter	number of total reinitializations due to lpr events <i>This element is always shown.</i>
re-init-fail	Parameter type: <Counter> - 32 bit counter	Count of re-initializations Failed <i>This element is always shown.</i>
inv-flag	Parameter type: <Shdsl::IntervalInvalidDataFlag> (true false) Possible values: - true : data is not valid - false : data is valid	validity of the corresponding PM data in previous 15-minutes <i>This element is always shown.</i>
interval-time	Parameter type: <Xdsl::PmTimeStamp> - Timestamp for Pm interval(yyyymmdd:hour:minutes)	specifies the start time of interval <i>This element is always shown.</i>

149.13 SHDSL Span Previous Day Performance Data Status Command

Command Description

This command displays the previous day performance data of an SHDSL span.

User Level

The command can be accessed by operators with xdsl privileges.

Command Syntax

The command has the following syntax:

```
> show shdsl span-counters previous-1day [ (if-index) [ interval-number <Shdsl::PM1DayIntervalNumber> ] ]
```

Command Parameters

Table 149.13-1 "SHDSL Span Previous Day Performance Data Status Command" Resource Parameters

Resource Identifier	Type	Description
(if-index)	Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number	interface index of the port
interval-number	Parameter type: <Shdsl::PM1DayIntervalNumber> Format: - a performance interval number - range: [1...30]	the performance interval number

Command Output

Table 149.13-2 "SHDSL Span Previous Day Performance Data Status Command" Display parameters

Specific Information		
name	Type	Description
moni-secs	Parameter type: <Shdsl::PM1DayIntevalMoniSecs>	number of actually monitored

149 SHDSL Status Commands

name	Type	Description
	- a monitored seconds in a previous 1 day interval - unit: sec	seconds in this interval <i>This element is always shown.</i>
re-init	Parameter type: <Counter> - 32 bit counter	number of total reinitializations <i>This element is always shown.</i>
re-init-lpr	Parameter type: <Counter> - 32 bit counter	number of total reinitializations due to lpr events <i>This element is always shown.</i>
re-init-fail	Parameter type: <Counter> - 32 bit counter	Count of re-initializations Failed <i>This element is always shown.</i>
inv-flag	Parameter type: <Shdsl::IntervalInvalidDataFlag> (true false) Possible values: - true : data is not valid - false : data is valid	validity of the corresponding PM data in previous day interval <i>This element is always shown.</i>
interval-time	Parameter type: <Xdsl::PmTimeStamp> - Timestamp for Pm interval(yyyymmdd:hour:minutes)	specifies the start time of interval <i>This element is always shown.</i>

150- IMA Status Commands

150.1 IMA Status Command Tree	150-6348
150.2 IMA Group Status Command	150-6349
150.3 IMA Group Near-End Current Interval Performance Data Status Command	150-6354
150.4 IMA Group Near-End Previous Interval Performance Data Status Command	150-6356
150.5 IMA Group Far-End Current Interval Performance Data Status Command	150-6358
150.6 IMA Group Far-End Previous Interval Performance Data Status Command	150-6360
150.7 IMA Link Status Command	150-6362
150.8 IMA Link Near-End Current Interval Performance Data Status Command	150-6366
150.9 IMA Link Near-End Previous Interval Performance Data Status Command	150-6368
150.10 IMA Link Far-End Current Interval Performance Data Status Command	150-6370
150.11 IMA Link Far-End Previous Interval Performance Data Status Command	150-6372

150.1 IMA Status Command Tree

Description

This chapter gives an overview of nodes that are handled by "IMA Status Commands".

Command Tree

```
----show
  ----ima
    ----group
      ----state
        - (if-index)
      ----counters
        ----near-end
          ----current-interval
            - (if-index)
          ----previous-interval
            - (if-index)
            - interval-no
        ----far-end
          ----current-interval
            - (if-index)
          ----previous-interval
            - (if-index)
            - interval-no
      ----link
        ----state
          - (if-index)
        ----counters
          ----near-end
            ----current-interval
              - (if-index)
            ----previous-interval
              - (if-index)
              - interval-no
          ----far-end
            ----current-interval
              - (if-index)
            ----previous-interval
              - (if-index)
              - interval-no
```

150.2 IMA Group Status Command

Command Description

This command displays the IMA group status.

User Level

The command can be accessed by operators with xdsl privileges.

Command Syntax

The command has the following syntax:

```
> show ima group state [ (if-index) ]
```

Command Parameters

Table 150.2-1 "IMA Group Status Command" Resource Parameters

Resource Identifier	Type	Description
(if-index)	Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number	interface index of the port

Command Output

Table 150.2-2 "IMA Group Status Command" Display parameters

Specific Information		
name	Type	Description
grp-if-index	Parameter type: <Itf::ImaLine> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number	the logical interface number assigned to this IMA group <i>This element is only shown in detail mode.</i>

150 IMA Status Commands

name	Type	Description
near-end short name: ne	Parameter type: <Ima::GroupState> ((not-conf nc) (start-up su) (start-up-ack sua) (conf-abt-unsupported cau) (conf-abt-incomp-sym cais) (conf-abt-other cao) (insuff-links il) (blked blk) op) Possible values: - not-conf : not configured - nc : not configured - start-up : start up - su : start up - start-up-ack : start up acknowledgement - sua : start up acknowledgement - conf-abt-unsupported : config abort unsupported m - cau : config abort unsupported m - conf-abt-incomp-sym : config abort incompatible symmetry - cais : config abort incompatible symmetry - conf-abt-other : config abort other - cao : config abort other - insuff-links : insufficient links - il : insufficient links - blked : blocked - blk : blocked - op : operational	the operational state of the near-end IMA group state machine <i>This element is always shown.</i>
far-end short name: fe	Parameter type: <Ima::GroupState> ((not-conf nc) (start-up su) (start-up-ack sua) (conf-abt-unsupported cau) (conf-abt-incomp-sym cais) (conf-abt-other cao) (insuff-links il) (blked blk) op) Possible values: - not-conf : not configured - nc : not configured - start-up : start up - su : start up - start-up-ack : start up acknowledgement - sua : start up acknowledgement - conf-abt-unsupported : config abort unsupported m - cau : config abort unsupported m - conf-abt-incomp-sym : config abort incompatible symmetry - cais : config abort incompatible symmetry - conf-abt-other : config abort other - cao : config abort other - insuff-links : insufficient links - il : insufficient links - blked : blocked - blk : blocked	the operational state of the far-end IMA group state machine <i>This element is always shown.</i>

name	Type	Description
	- op : operational	
failure-status short name: fa-st	Parameter type: <Ima::GroupFailureStatus> ((no-fail nf) (start-up-ne sun) (start-up-fe suf) (inv-m-val-ne imvn) (inv-m-val-fe imvf) (fail-asym-ne fan) (fail-asym-fe faf) (insuff-links-ne iln) (insuff-links-fe ilf) (blked-ne bn) (blked-fe bf) (other-fail of)) Possible values: - no-fail : no failure - nf : no failure - start-up-ne : start up near end - sun : start up near end - start-up-fe : start up far end - suf : start up far end - inv-m-val-ne : invalid m-value near end - imvn : invalid m-value near end - inv-m-val-fe : invalid m-value far end - imvf : invalid m-value far end - fail-asym-ne : failed asymmetric near end - fan : failed asymmetric near end - fail-asym-fe : failed asymmetric far end - faf : failed asymmetric far end - insuff-links-ne : insufficient links near end - iln : insufficient links near end - insuff-links-fe : insufficient links far end - ilf : insufficient links far end - blked-ne : blocked near end - bn : blocked near end - blked-fe : blocked far end - bf : blocked far end - other-fail : other failure - of : other failure	the failure status of the IMA group <i>This element is always shown.</i>
fe-tx-clk-mode	Parameter type: <Ima::GroupTxClkMode> (ctc itc) Possible values: - ctc : the transmit clocking mode is ctc - itc : the transmit clocking mode is itc	the transmit clocking mode of the IMA group far end <i>This element is only shown in detail mode.</i>
tx-timing-ref-link	Parameter type: <Itf::ShdslLine> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number	the transmit timing reference link interface number <i>This element is only shown in detail mode.</i>
rx-timing-ref-link	Parameter type: <Itf::ShdslLine>	the receive timing reference link

name	Type	Description
	<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number	interface number <i>This element is only shown in detail mode.</i>
rx-ima-id short name: rii	Parameter type: <Ima::GroupRxImaId> - an ima id used by the far-end ima function - range: [0...255]	the ima id used by the far-end ima function <i>This element is always shown.</i>
rx-frm-len	Parameter type: <Ima::GroupFrameLength> (m32 m64 m128 m256) Possible values: - m32 : the frame length is 32 cells - m64 : the frame length is 64 cells - m128 : the frame length is 128 cells - m256 : the frame length is 256 cells	the frame length used by the remote IMA function <i>This element is only shown in detail mode.</i>
least-delay-link	Parameter type: <Itf::ShdslLine> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number	the interface number identifies the smallest propagation delay link <i>This element is only shown in detail mode.</i>
diff-delay-max-obs	Parameter type: <Ima::GroupDiffDelayMaxObs> - a maximum observed milliseconds of delay differential - unit: ms	the maximum observed milliseconds of delay differential <i>This element is only shown in detail mode.</i>
rs	Parameter type: <SignedInteger> - a signed integer	the running seconds of the ima group <i>This element is only shown in detail mode.</i>
uas	Parameter type: <SignedInteger> - a signed integer	the unavailable seconds of the ima group <i>This element is only shown in detail mode.</i>
near-end-fail short name: ne-fa	Parameter type: <SignedInteger> - a signed integer	the number of failures occurred at the near end <i>This element is always shown.</i>
fe-num-failures short name: fe-fa	Parameter type: <SignedInteger> - a signed integer	the number of failures occurred at the far end <i>This element is always shown.</i>
tx-avail-cell-rate	Parameter type: <SignedInteger> - a signed integer	the available cell rate in transmit direction <i>This element is only shown in detail mode.</i>
rx-avail-cell-rate	Parameter type: <SignedInteger>	the available cell rate in receive

name	Type	Description
	- a signed integer	direction <i>This element is only shown in detail mode.</i>
tx-num-cfg-links short name: tncl	Parameter type: <SignedInteger> - a signed integer	the number of links configured to transmit <i>This element is always shown.</i>
rx-num-cfg-links short name: rncl	Parameter type: <SignedInteger> - a signed integer	the number of links configured to receive <i>This element is always shown.</i>
tx-num-act-links short name: tncl	Parameter type: <SignedInteger> - a signed integer	the number of links configured to transmit and must be active <i>This element is always shown.</i>
rx-num-act-links short name: rncl	Parameter type: <SignedInteger> - a signed integer	the number of links configured to receive and must be active <i>This element is always shown.</i>

150.3 IMA Group Near-End Current Interval Performance Data Status Command

Command Description

This command displays the IMA groups near-end current interval status.

User Level

The command can be accessed by operators with xdsl privileges.

Command Syntax

The command has the following syntax:

> show ima group counters near-end current-interval [(if-index)]

Command Parameters

Table 150.3-1 "IMA Group Near-End Current Interval Performance Data Status Command" Resource Parameters

Resource Identifier	Type	Description
(if-index)	Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number	interface index of the port

Command Output

Table 150.3-2 "IMA Group Near-End Current Interval Performance Data Status Command" Display parameters

Specific Information		
name	Type	Description
time-el	Parameter type: <Ima::GroupCurrentTimeElapsed> - a number of time elapsed in a current interval - range: [0...899]	the number of time elapsed in the current interval <i>This element is always shown.</i>
valid-interval	Parameter type: <Ima::GroupCurrentValidIntervals> - a number of previous valid intervals	the number of previous valid intervals

name	Type	Description
	- range: [0...32]	<i>This element is always shown.</i>
uas	Parameter type: <Gauge> - gauge	the number of unavailable seconds in the current interval <i>This element is always shown.</i>
fc	Parameter type: <Gauge> - gauge	the number of failures in the current interval <i>This element is always shown.</i>
inv-flag	Parameter type: <Ima::IntervalInvalidDataFlag> (true false) Possible values: - true : data is not valid - false : data is valid	validity flag of the corresponding Ima-Group-Near-End's PM data in current 15 minutes <i>This element is always shown.</i>

150.4 IMA Group Near-End Previous Interval Performance Data Status Command

Command Description

This command displays the IMA groups near-end previous interval status.

User Level

The command can be accessed by operators with xdsl privileges.

Command Syntax

The command has the following syntax:

```
> show ima group counters near-end previous-interval [ (if-index) [ interval-no <Ima::GroupIntervalNumber> ] ]
```

Command Parameters

Table 150.4-1 "IMA Group Near-End Previous Interval Performance Data Status Command" Resource Parameters

Resource Identifier	Type	Description
(if-index)	Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number	interface index of the port
interval-no	Parameter type: <Ima::GroupIntervalNumber> Format: - a number of a interval number - range: [1...32]	the number of the interval number

Command Output

Table 150.4-2 "IMA Group Near-End Previous Interval Performance Data Status Command" Display parameters

Specific Information		
name	Type	Description
uas	Parameter type: <Gauge>	the number of unavailable

name	Type	Description
	- gauge	seconds in the previous interval <i>This element is always shown.</i>
fc	Parameter type: <Gauge> - gauge	the number of failures in the previous interval <i>This element is always shown.</i>
inv-flag	Parameter type: <Ima::IntervalInvalidDataFlag> (true false) Possible values: - true : data is not valid - false : data is valid	validity flag of the corresponding Ima-Group-Near-End's PM data in one of the previous 32 intervals of 15-minutes <i>This element is always shown.</i>

150.5 IMA Group Far-End Current Interval Performance Data Status Command

Command Description

This command displays the IMA groups far-end current interval status.

User Level

The command can be accessed by operators with xdsl privileges.

Command Syntax

The command has the following syntax:

```
> show ima group counters far-end current-interval [ (if-index) ]
```

Command Parameters

Table 150.5-1 "IMA Group Far-End Current Interval Performance Data Status Command" Resource Parameters

Resource Identifier	Type	Description
(if-index)	Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number	interface index of the port

Command Output

Table 150.5-2 "IMA Group Far-End Current Interval Performance Data Status Command" Display parameters

Specific Information		
name	Type	Description
time-el	Parameter type: <Ima::GroupFarEndTimeElapsed> - a number of time elapsed in a current interval - range: [0...899]	the number of time elapsed in the far end interval <i>This element is always shown.</i>
valid-interval	Parameter type: <Ima::GroupFarEndValidIntervals> - a number of previous valid intervals	the number of the far end valid intervals

name	Type	Description
	- range: [0...32]	<i>This element is always shown.</i>
fc	Parameter type: <Gauge> - gauge	the number of failures in the far end interval <i>This element is always shown.</i>
inv-flag	Parameter type: <Ima::IntervalInvalidDataFlag> (true false) Possible values: - true : data is not valid - false : data is valid	validity flag of the corresponding Ima-Group-Far-End's PM data in current 15 minutes <i>This element is always shown.</i>

150.6 IMA Group Far-End Previous Interval Performance Data Status Command

Command Description

This command displays the IMA groups far-end previous interval status.

User Level

The command can be accessed by operators with xdsl privileges.

Command Syntax

The command has the following syntax:

```
> show ima group counters far-end previous-interval [ (if-index) [ interval-no <Ima::GroupFarEndIntervalNumber> ] ]
```

Command Parameters

Table 150.6-1 "IMA Group Far-End Previous Interval Performance Data Status Command" Resource Parameters

Resource Identifier	Type	Description
(if-index)	Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number	interface index of the port
interval-no	Parameter type: <Ima::GroupFarEndIntervalNumber> Format: - a number of a previous interval number - range: [1...32]	the number of the previous interval number

Command Output

Table 150.6-2 "IMA Group Far-End Previous Interval Performance Data Status Command" Display parameters

Specific Information

name	Type	Description
fc	Parameter type: <Gauge> - gauge	the number of failures in the far end previous interval <i>This element is always shown.</i>
inv-flag	Parameter type: <Ima::IntervalInvalidDataFlag> (true false) Possible values: - true : data is not valid - false : data is valid	validity flag of the corresponding Ima-Group-Far-End's PM data in one of the previous 32 intervals of 15-minutes <i>This element is always shown.</i>

150.7 IMA Link Status Command

Command Description

This command displays the IMA link status.

User Level

The command can be accessed by operators with xdsl privileges.

Command Syntax

The command has the following syntax:

```
> show ima link state [ (if-index) ]
```

Command Parameters

Table 150.7-1 "IMA Link Status Command" Resource Parameters

Resource Identifier	Type	Description
(if-index)	Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number	interface index of the port

Command Output

Table 150.7-2 "IMA Link Status Command" Display parameters

Specific Information		
name	Type	Description
ne-tx-state	Parameter type: <Ima::LinkState> (not-in-grp uus-not-gi-rea uus-fau uus-mis-con uus-blk uus-fail use act) Possible values: - not-in-grp : not in group	the mandatory state of the near-end transmit link <i>This element is only shown in detail mode.</i>

name	Type	Description
	- uus-not-gi-rea : unusable not given reason - uus-fau : unusable fault - uus-mis-con : unusable misconnected - uus-blk : unusable blocked - uus-fail : unusable failed - use : usable - act : active	
ne-rx-state	Parameter type: <Ima::LinkState> (not-in-grp uus-not-gi-rea uus-fau uus-mis-con uus-blk uus-fail use act) Possible values: - not-in-grp : not in group - uus-not-gi-rea : unusable not given reason - uus-fau : unusable fault - uus-mis-con : unusable misconnected - uus-blk : unusable blocked - uus-fail : unusable failed - use : usable - act : active	the mandatory state of the near-end receive link <i>This element is only shown in detail mode.</i>
fe-tx-state	Parameter type: <Ima::LinkState> (not-in-grp uus-not-gi-rea uus-fau uus-mis-con uus-blk uus-fail use act) Possible values: - not-in-grp : not in group - uus-not-gi-rea : unusable not given reason - uus-fau : unusable fault - uus-mis-con : unusable misconnected - uus-blk : unusable blocked - uus-fail : unusable failed - use : usable - act : active	the mandatory state of the far-end transmit link <i>This element is only shown in detail mode.</i>
fe-rx-state	Parameter type: <Ima::LinkState> (not-in-grp uus-not-gi-rea uus-fau uus-mis-con uus-blk uus-fail use act) Possible values: - not-in-grp : not in group - uus-not-gi-rea : unusable not given reason - uus-fau : unusable fault - uus-mis-con : unusable misconnected	the mandatory state of the far-end receive link <i>This element is only shown in detail mode.</i>

150 IMA Status Commands

name	Type	Description
	- uus-blk : unusable blocked - uus-fail : unusable failed - use : usable - act : active	
ne-rx-fail-stat	Parameter type: <Ima::LinkFailureStatus> (no-fail ima-lk-fail lif-fail lods-fail mis-con blked fau fe-tx-lk-uus fe-rx-lk-uus) Possible values: - no-fail : no failure - ima-lk-fail : ima link failure - lif-fail : lif failure - lods-fail : lods failure - mis-con : mis connected - blked : blocked - fau : fault - fe-tx-lk-uus : far end tx link unusable - fe-rx-lk-uus : far end rx link unusable	the mandatory link failure status of the near-end receive link <i>This element is only shown in detail mode.</i>
fe-rx-fail-stat	Parameter type: <Ima::LinkFailureStatus> (no-fail ima-lk-fail lif-fail lods-fail mis-con blked fau fe-tx-lk-uus fe-rx-lk-uus) Possible values: - no-fail : no failure - ima-lk-fail : ima link failure - lif-fail : lif failure - lods-fail : lods failure - mis-con : mis connected - blked : blocked - fau : fault - fe-tx-lk-uus : far end tx link unusable - fe-rx-lk-uus : far end rx link unusable	the mandatory link failure status of the far-end receive link <i>This element is only shown in detail mode.</i>
tx-lid short name: tl	Parameter type: <Ima::LinkTxLid> - an outgoing LID used on a link - range: [0...31]	the outgoing LID used on the link <i>This element is always shown.</i>
rx-lid short name: rl	Parameter type: <Ima::LinkRxLid> - an incoming LID used on a link - range: [0...31]	the incoming LID used on the link <i>This element is always shown.</i>
rel-delay short name: rd	Parameter type: <Ima::LinkRelDelay> - a number of milliseconds of a measured delay - unit: ms	the latest measured delay on this link relative to the link <i>This element is always shown.</i>
ima-violations short name: iv	Parameter type: <SignedInteger> - a signed integer	the number of the count of invalid ICP cells <i>This element is always shown.</i>
oif-anomalies	Parameter type: <SignedInteger>	the number of OIF anomalies

name	Type	Description
short name: oa	- a signed integer	during non-SES-IMA <i>This element is always shown.</i>
ne-ses short name: ns	Parameter type: <SignedInteger> - a signed integer	the number of the count of one second intervals containing link defects <i>This element is always shown.</i>
fe-ses	Parameter type: <SignedInteger> - a signed integer	the number of the count of one second intervals containing RDI-IMA defects <i>This element is only shown in detail mode.</i>
ne-uas short name: nu	Parameter type: <SignedInteger> - a signed integer	the number of the count of unavailable seconds at near-end <i>This element is always shown.</i>
fe-uas short name: fu	Parameter type: <SignedInteger> - a signed integer	the number of the count of unavailable seconds at far-end <i>This element is always shown.</i>
ne-tx-uus short name: ntu	Parameter type: <SignedInteger> - a signed integer	the number of the count of unusable seconds at near end Tx <i>This element is always shown.</i>
ne-rx-uus short name: nru	Parameter type: <SignedInteger> - a signed integer	the number of the count of unusable seconds at near end Rx <i>This element is always shown.</i>
fe-tx-uus short name: ftu	Parameter type: <SignedInteger> - a signed integer	the number of the count of unusable seconds at far end Tx <i>This element is always shown.</i>
fe-rx-uus short name: fru	Parameter type: <SignedInteger> - a signed integer	the number of the count of unusable seconds at far end Rx <i>This element is always shown.</i>
ne-tx-fail short name: ntf	Parameter type: <SignedInteger> - a signed integer	the number of the failure of the near end transmit <i>This element is always shown.</i>
ne-rx-fail short name: nrf	Parameter type: <SignedInteger> - a signed integer	the number of the failure of the near end receive <i>This element is always shown.</i>
fe-tx-fail short name: ftf	Parameter type: <SignedInteger> - a signed integer	the number of the failure of the far end transmit <i>This element is always shown.</i>
fe-rx-fail short name: frf	Parameter type: <SignedInteger> - a signed integer	the number of the failure of the far end receive <i>This element is always shown.</i>
tx-stuffs short name: ts	Parameter type: <SignedInteger> - a signed integer	the number of the count of stuff events in transmit <i>This element is always shown.</i>
rx-stuffs short name: rs	Parameter type: <SignedInteger> - a signed integer	the number of the count of stuff events in receive <i>This element is always shown.</i>

150.8 IMA Link Near-End Current Interval Performance Data Status Command

Command Description

This command displays the IMA links near-end current interval status.

User Level

The command can be accessed by operators with xdsl privileges.

Command Syntax

The command has the following syntax:

```
> show ima link counters near-end current-interval [ (if-index) ]
```

Command Parameters

Table 150.8-1 "IMA Link Near-End Current Interval Performance Data Status Command" Resource Parameters

Resource Identifier	Type	Description
(if-index)	Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number	interface index of the port

Command Output

Table 150.8-2 "IMA Link Near-End Current Interval Performance Data Status Command" Display parameters

Specific Information		
name	Type	Description
time-el	Parameter type: <Ima::LinkCurrentTimeElapsed> - a number of time elapsed in a current interval of a link - range: [0...899]	the number of time elapsed in the current interval of the link <i>This element is always shown.</i>
valid-interval	Parameter type: <Ima::LinkCurrentValidIntervals> - a number of previous valid intervals of a link	the number of previous valid intervals of the link

name	Type	Description
	- range: [0...32]	<i>This element is always shown.</i>
iv	Parameter type: <Gauge> - gauge	the number of IMA violation events in the current interval <i>This element is always shown.</i>
oif	Parameter type: <Gauge> - gauge	the number of out of IMA frame events in the current interval <i>This element is always shown.</i>
ses	Parameter type: <Gauge> - gauge	the number of severely errored seconds in the current interval <i>This element is always shown.</i>
uas	Parameter type: <Gauge> - gauge	the number of unavailable seconds in the current interval of the link <i>This element is always shown.</i>
tx-uus	Parameter type: <Gauge> - gauge	the number of unusable seconds in the current interval of the transmit link <i>This element is always shown.</i>
rx-uus	Parameter type: <Gauge> - gauge	the number of unusable seconds in the current interval of the receive link <i>This element is always shown.</i>
tx-fc	Parameter type: <Gauge> - gauge	the number of failures in the current interval of the transmit link <i>This element is always shown.</i>
rx-fc	Parameter type: <Gauge> - gauge	the number of failures in the current interval of the receive link <i>This element is always shown.</i>
tx-stuffs	Parameter type: <Gauge> - gauge	the number of IMA stuffs in the current interval of the transmit link <i>This element is always shown.</i>
rx-stuffs	Parameter type: <Gauge> - gauge	the number of IMA stuffs in the current interval of the receive link <i>This element is always shown.</i>
inv-flag	Parameter type: <Ima::IntervalInvalidDataFlag> (true false) Possible values: - true : data is not valid - false : data is valid	validity flag of the corresponding Ima-Link-Near-End's PM data in current 15 minutes <i>This element is always shown.</i>

150.9 IMA Link Near-End Previous Interval Performance Data Status Command

Command Description

This command displays the IMA links near-end previous interval status.

User Level

The command can be accessed by operators with xdsl privileges.

Command Syntax

The command has the following syntax:

```
> show ima link counters near-end previous-interval [ (if-index) [ interval-no <Ima::LinkIntervalNumber> ] ]
```

Command Parameters

Table 150.9-1 "IMA Link Near-End Previous Interval Performance Data Status Command" Resource Parameters

Resource Identifier	Type	Description
(if-index)	Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number	interface index of the port
interval-no	Parameter type: <Ima::LinkIntervalNumber> Format: - a number of a interval number in a link - range: [1...32]	the number of the interval value in the link

Command Output

Table 150.9-2 "IMA Link Near-End Previous Interval Performance Data Status Command" Display parameters

Specific Information		
name	Type	Description
iv	Parameter type: <Gauge>	the number of ima violation

name	Type	Description
	- gauge	events of the link in the previous interval <i>This element is always shown.</i>
oif	Parameter type: <Gauge> - gauge	the number of out of ima frame events of the link in the previous interval <i>This element is always shown.</i>
ses	Parameter type: <Gauge> - gauge	the number of severely errored seconds of the link in the previous interval <i>This element is always shown.</i>
uas	Parameter type: <Gauge> - gauge	the number of unavailable seconds of the link in the previous interval <i>This element is always shown.</i>
tx-uus	Parameter type: <Gauge> - gauge	the number of unusable seconds of the transmit link in the previous interval <i>This element is always shown.</i>
rx-uus	Parameter type: <Gauge> - gauge	the number of unusable seconds of the receive link in the previous interval <i>This element is always shown.</i>
tx-fc	Parameter type: <Gauge> - gauge	the number of failures of the transmit link in the previous interval <i>This element is always shown.</i>
rx-fc	Parameter type: <Gauge> - gauge	the number of failures of the receive link in the previous interval <i>This element is always shown.</i>
tx-stuffs	Parameter type: <Gauge> - gauge	the number of ima stuff events of the transmit link in the previous interval <i>This element is always shown.</i>
rx-stuffs	Parameter type: <Gauge> - gauge	the number of ima stuff events of the receive link in the previous interval <i>This element is always shown.</i>
inv-flag	Parameter type: <Ima::IntervalInvalidDataFlag> (true false) Possible values: - true : data is not valid - false : data is valid	validity flag of the corresponding Ima-Link-Near-End's PM data in one of the previous 32 intervals of 15-minutes <i>This element is always shown.</i>

150.10 IMA Link Far-End Current Interval Performance Data Status Command

Command Description

This command displays the IMA links far-end current interval status.

User Level

The command can be accessed by operators with xdsl privileges.

Command Syntax

The command has the following syntax:

```
> show ima link counters far-end current-interval [ (if-index) ]
```

Command Parameters

Table 150.10-1 "IMA Link Far-End Current Interval Performance Data Status Command" Resource Parameters

Resource Identifier	Type	Description
(if-index)	Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number	interface index of the port

Command Output

Table 150.10-2 "IMA Link Far-End Current Interval Performance Data Status Command" Display parameters

Specific Information		
name	Type	Description
time-el	Parameter type: <Ima::LinkFarEndTimeElapsed> - a number of time elapsed of a link in a far end interval - range: [0...899]	the number of time elapsed of the link in the far end interval <i>This element is always shown.</i>
valid-interval	Parameter type: <Ima::LinkFarEndValidIntervals> - a number of a far end valid intervals of a link	the number of the far end valid intervals of the link

name	Type	Description
	- range: [0...32]	<i>This element is always shown.</i>
ses	Parameter type: <Gauge> - gauge	the number of severely errored seconds of the link in the current interval <i>This element is always shown.</i>
uas	Parameter type: <Gauge> - gauge	the number of unavailable seconds of the link in the current interval <i>This element is always shown.</i>
tx-uus	Parameter type: <Gauge> - gauge	the number of unusable seconds of the transmit link in the current interval <i>This element is always shown.</i>
rx-uus	Parameter type: <Gauge> - gauge	the number of unusable seconds of the receive link in the current interval <i>This element is always shown.</i>
tx-fc	Parameter type: <Gauge> - gauge	the number of failures of the transmit link in the current interval <i>This element is always shown.</i>
rx-fc	Parameter type: <Gauge> - gauge	the number of failures of the receive link in the current interval <i>This element is always shown.</i>
inv-flag	Parameter type: <Ima::IntervalInvalidDataFlag> (true false) Possible values: - true : data is not valid - false : data is valid	validity flag of the corresponding Ima-Link-Far-End's PM data in current 15 minutes <i>This element is always shown.</i>

150.11 IMA Link Far-End Previous Interval Performance Data Status Command

Command Description

This command displays the IMA links far-end previous interval status.

User Level

The command can be accessed by operators with xdsl privileges.

Command Syntax

The command has the following syntax:

```
> show ima link counters far-end previous-interval [ (if-index) [ interval-no <Ima::LinkFarEndIntervalNumber> ] ]
```

Command Parameters

Table 150.11-1 "IMA Link Far-End Previous Interval Performance Data Status Command" Resource Parameters

Resource Identifier	Type	Description
(if-index)	Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number	interface index of the port
interval-no	Parameter type: <Ima::LinkFarEndIntervalNumber> Format: - a number of a interval number in a far end link - range: [1...32]	the number of the previous interval number in the far end link

Command Output

Table 150.11-2 "IMA Link Far-End Previous Interval Performance Data Status Command" Display parameters

Specific Information		
name	Type	Description
ses	Parameter type: <Gauge>	the number of severely errored

name	Type	Description
	- gauge	seconds of the far end link in the previous interval <i>This element is always shown.</i>
uas	Parameter type: <Gauge> - gauge	the number of unavailable seconds of the far end link in the previous interval <i>This element is always shown.</i>
tx-uus	Parameter type: <Gauge> - gauge	the number of unusable seconds of the far end transmit link in the previous interval <i>This element is always shown.</i>
rx-uus	Parameter type: <Gauge> - gauge	the number of unusable seconds of the far end receive link in the previous interval <i>This element is always shown.</i>
tx-fc	Parameter type: <Gauge> - gauge	the number of failures of the far end transmit link in the previous interval <i>This element is always shown.</i>
rx-fc	Parameter type: <Gauge> - gauge	the number of failures of the far end receive link in the previous interval <i>This element is always shown.</i>
inv-flag	Parameter type: <Ima::IntervalInvalidDataFlag> (true false) Possible values: - true : data is not valid - false : data is valid	validity flag of the corresponding Ima-Link-Far-End's PM data in one of the previous 32 intervals of 15-minutes <i>This element is always shown.</i>

151- Voice Status Commands

151.1 Voice Status Command Tree	151-6376
151.2 Voice Sip Server Status Commands	151-6380
151.3 Voice Sip User Agent Access Point Show Commands	151-6382
151.4 Voice Sip User Agent related IP address information Show Commands	151-6384
151.5 Voice Sip Statistics System Status Command	151-6386
151.6 Voice Sip Statistics Perfinfo Status Command	151-6387
151.7 Voice Sip Termination Statistics Command for Current 15 Minutes	151-6389
151.8 Voice Sip Termination Statistics Command for Current Day	151-6393
151.9 Voice Sip Termination Statistics Command for Previous 15 Minutes	151-6396
151.10 Voice Sip Termination Statistics Command for Previous day	151-6400
151.11 Voice Sip MSAN Statistics Command	151-6403
151.12 Voice Sip board Statistics Command for Current one Day	151-6405
151.13 Voice Sip Board Statistics Command for Previous day	151-6409
151.14 Voice Sip Board Statistics Command for Current 15 Minutes	151-6413
151.15 Voice Sip Board Statistics Command for Previous 15 Minutes	151-6417
151.16 Voice Sip Statistics Perfinfo Status Command per board	151-6421
151.17 Voice Sip restoration: Redundancy Status Commands	151-6423
151.18 Voice Sip restoration: Redundancy Status Commands	151-6425
151.19 Voice Sip Redundancy Status Commands	151-6427
151.20 Voice Sip Termination Status Commands	151-6428
151.21 Voice Sip Shared Line Termination Status Commands	151-6431
151.22 Voice Sip Isdn/Cas Termination Status Commands	151-6433
151.23 Voice Sip Port State Status Commands	151-6436
151.24 Voice Sip SSP Profile Status Commands	151-6437
151.25 Voice Sip Dhcp Sip Server Status Commands	151-6438
151.26 Voice Sip All Port State Status Command	151-6441
151.27 Voice Sip Isdn/Cas Termination Status Commands	151-6443
151.28 Voice Sip Isdn Cas E1 Interface Status Commands	151-6445
151.29 Voice Sip Isdn Nsm Profile Status Commands	151-6447
151.30 Voice Sip Cas Nsm Profile Status Commands	151-6448
151.31 Voice Sip Cas Timer Profile Status Commands	151-6449
151.32 Voice Sip Cas Signaling Profile Status Commands	151-6450
151.33 Voice Sip Isdn And Cas Nsm Profile Index Status Commands	151-6451
151.34 Voice Sip Isdn Cas E1 Interface B channel Status Commands	151-6453

151.35 Voice Sip Isdn/Cas Termination Status Commands	151-6455
151.36 Voice Sip Isdn PUID Termination Status Commands	151-6458
151.37 Voice Sip Pri User To User Profile Status Commands	151-6460
151.38 Voice Sip Physical Interface Status Commands	151-6461
151.39 Voice Sip Trunk Sub-group Status Commands	151-6474
151.40 Voice Sip L1 Transport Statistics Commands	151-6476
151.41 Voice Sip NE Board Status Commands	151-6478
151.42 Call Query state show command	151-6480
151.43 Call Query result show command	151-6481
151.44 Voice Megaco Equipment Board Status Commands	151-6483
151.45 Voice Megaco Equipment Status Commands	151-6485
151.46 Voice Megaco Equipment Secondary Termination Status Commands	151-6488
151.47 Voice Megaco MGI Status Commands	151-6491
151.48 Voice Megaco Database Status Commands	151-6493
151.49 Voice Megaco IP Status Commands	151-6494
151.50 Voice Megaco SGI Status Commands	151-6495
151.51 Summary of Current Operational Parameters for ONT VoIP	151-6497
151.52 Summary of Call History Operational Parameters	151-6499
151.53 Voice ONT POTS MLT Test Status Command	151-6502
151.54 Voice ONT POTS PB Dialtone Test Status Command	151-6507
151.55 Voice ONT POTS SIP Dialtone Test Status Command	151-6510
151.56 Summary of Actual Operational data for ONT VoIP Config Command	151-6512
151.57 Voice ONT POTS Hook State Command	151-6517
151.58 Voice TC Olt-side Current Interval Status Command	151-6519
151.59 Voice TC Olt-side Previous Interval Status Command	151-6521
151.60 Voice TC Ont-side Current Interval Status Command	151-6523
151.61 Voice TC Ont-side Previous Interval Status Command	151-6525
151.62 GPON Voip Configuration Status Command	151-6527
151.63 Voice GPON POTS RTP Current Statistics Command	151-6530
151.64 Voice GPON POTS RTP Prev Statistics Command	151-6532
151.65 Current Interval PM stats of ONT MGC Agent Command	151-6534
151.66 Voice Gpon POTS Call Statistics Command for Current 15 Minutes	151-6536
151.67 Voice Gpon POTS Call Statistics Command for Previous 15 Minutes	151-6538
151.68 GPON Ont Sip Status Command	151-6540
151.69 Voice Gpon SIP Agent Statistics Command for Current 15 Minutes	151-6542
151.70 Voice Gpon SIP Call Statistics Command for Current 15 Minutes	151-6545
151.71 Voice ONT Operational data for pots line profile download status Command	151-6547
151.72 Voice ONT Operational data for voip client profile download status Command	151-6549
151.73 Voice extline Status Commands	151-6551
151.74 Voice pseudo wire Status Commands	151-6553
151.75 Voice pseudo wire udp port Commands	151-6555

151.1 Voice Status Command Tree

Description

This chapter gives an overview of nodes that are handled by "Voice Status Commands".

Command Tree

```
----show
  ----voice
    ----sip
      ----server
        - (name)
      ----user-agent-ap
        - (name)
        - slot-id
      ----ua-ip-info
        - (ua-name)
        - slot-id
      ----statistics
        ----system
        ----perf-info
          - (if-index)
        ----termination
          ----current-15min
            - (if-index)
          ----current-1day
            - (if-index)
          ----prev-15min
            - (if-index)
            - interval-num
          ----prev-1day
            - (if-index)
            - interval-num
        ----call
          - (if-index)
          ----interval
            - (interval-num)
            - start-time
            - icid
        ----board
          ----current-1day
            - (slot-id)
          ----prev-1day
            - (slot-id)
            - interval-num
          ----current-15min
            - (slot-id)
          ----prev-15min
            - (slot-id)
            - interval-num
          ----board-perfinfo
            - (slot-id)
        ----redundancy-node
```

```

----redundancy-state
  - (admin-name)
  - slot-id
----ext-redundancy-state
  - (admin-name)
  - slot-id
  - term-group
----redundancy-cmd
  - (provider-name)
----termination
  - (if-index)
----sharedline
  - (if-index)
----isdn-cas-term
  - (if-index)
----port-state
  - (if-index)
----sspprofile
  - (sspprofile-id)
----dhcpsipserver
  - (vsp-name)
----all
  ----port-state
    - (if-index)
----isdn-cas-cls-puid
  - (name)
  - directory-number
----isdn-cas-itf
  - (if-index)
  - interfaces
----isdn-nsm-prof
  - (prof-name)
----cas-nsm-prof
  - (prof-name)
----cas-timer-prof
  - (prof-name)
----cas-sig-prof
  - (prof-name)
----profiles
----e1itf-bchannel-status
  - (if-index)
  - interface
  - b-chan-id
----pri-cas-tksg-term
  - (if-index)
  - tksg-id
----pri-cas-tksg-puid
  - (if-index)
  - tksg-id
  - directory-number
----user-to-user-prof
  - (prof-name)
----phys-itf
  - (if-index)
----tksg
  - (if-index)
  - tksg-id
  - interface
----l1-trans-statistics

```

- (if-index)
- ne-board**
 - cap-id
 - ne-id
 - board
- call-query**
 - (id)
- call-query-result**
 - (id)
 - result-index
- cluster**
 - (cluster-id)
- board**
 - (equip-id)
 - board-id
- termination**
 - (equip-id)
 - port-id
- sharedlineterm**
 - (equip-id)
 - port-id
- media-gateway**
 - (media-gateway-id)
- database**
- ip**
- signal-gateway**
 - (signal-gateway-id)
- ont**
 - service**
 - (voip-index)
 - call-hist**
 - (ont-slot-idx)
 - call-hist-num
 - pots**
 - diagnostics**
 - (uni-idx)
 - pb-dial-tone**
 - (uni-idx)
 - sip-dial-tone**
 - (uni-idx)
 - operational-data**
 - (uni-index)
 - hookstate**
 - (uni-idx)
 - tc-layer**
 - olt-side**
 - current-interval**
 - (uni-index)
 - previous-interval**
 - (uni-index)
 - interval-nbr
 - ont-side**
 - current-interval**
 - (uni-index)
 - previous-interval**
 - (uni-index)
 - interval-nbr
- voip-config**
 - operational-data**

```

      - (voip-index)
----pots-rtp
  ----statistics
    ----current-15min
      - (uni-index)
    ----prev-15min
      - (uni-index)
      - interval-num
----mgc-agent
  ----statistics
    ----current-15min
      - (index)
----pots-call
  ----statistics
    ----current-15min
      - (uni-idx)
    ----prev-15min
      - (uni-idx)
      - interval-num
----sip-config
  ----operational-data
    - (sip-index)
----sip-agent
  ----statistics
    ----current-15min
      - (ont-idx)
----sip-call
  ----statistics
    ----current-15min
      - (ont-idx)
----voip-pip-prof
  ----operational-data
    ----input-profile
      - (uni-index)
----voip-vip-prof
  ----operational-data
    ----input-profile
      - (voip-index)
----extline
  - (if-index)
----pseudo-wire
  - (if-index)
----pseudo-wire-src-port
  - (if-index)

```

151.2 Voice Sip Server Status Commands

Command Description

This command allows the operator to show the Voice Sip Server profile.

User Level

The command can be accessed by operators with sip privileges.

Command Syntax

The command has the following syntax:

```
> show voice sip server [ (name) ]
```

Command Parameters

Table 151.2-1 "Voice Sip Server Status Commands" Resource Parameters

Resource Identifier	Type	Description
(name)	Format: - uniquely identifies this voice server - length: x<=32	uniquely identify of this voice server

Command Output

Table 151.2-2 "Voice Sip Server Status Commands" Display parameters

Specific Information		
name	Type	Description
server-id	Parameter type: <Sip::ServerId> - the SIP server table index - range: [1...128]	server idr <i>This element is always shown.</i>
oper-status	Parameter type: <Sip::ServerOperStatus> (up down) Possible values: - up : the status of the server opera is up - down : the status of the server opera is down	the operational status of server <i>This element is always shown.</i>
server-address	Parameter type: <Sip::ServerAddr> (ipv4 : <Ip::V4Address> ipv6 : <Ip::V6Address> dns : <Sip::ServerAddr>) Possible values: - ipv4 : the address type of the server is IPv4 - ipv6 : the address type of the server is IPv6 - dns : the address type of the server is DNS Field type <Ip::V4Address>	the operational address of server <i>This element is always shown.</i>

name	Type	Description
	- IPv4-address Field type <Ip::V6Address> - IPv6-address Field type <Sip::ServerAddr> - name of the SipServer that can be resolved to an IP address via a DNS Server - length: 7<=x<=64	

151.3 Voice Sip User Agent Access Point Show Commands

Command Description

This command allows the operator to show the Voice Sip user agent access point profile.

User Level

The command can be accessed by operators with sip privileges.

Command Syntax

The command has the following syntax:

```
> show voice sip user-agent-ap [ (name) [ slot-id <SIP::SlotIndex> ] ]
```

Command Parameters

Table 151.3-1 "Voice Sip User Agent Access Point Show Commands" Resource Parameters

Resource Identifier	Type	Description
(name)	Format: - uniquely identifies the User Agent - length: 1<=x<=32	uniquely identify of the user agent
slot-id	Parameter type: <SIP::SlotIndex> Format: (lt : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> nt ntio <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::EqSlotId>) Possible values: - lt : lt-slot - nt : nt-slot - ntio : ntio-slot Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::EqSlotId> - the equipment slot number	slot id associated with this user agent access point

Command Output

Table 151.3-2 "Voice Sip User Agent Access Point Show Commands" Display parameters

Specific Information		
name	Type	Description
oper-status	Parameter type: <Sip::UaApOperStatus> (up down) Possible values: - up : the sip UaAp oper status is up - down : the sip UaAp oper status is down	the opera status of user agent access point <i>This element is always shown.</i>

151.4 Voice Sip User Agent related IP address information Show Commands

Command Description

This command allows the operator to show the Voice service related IP address information.

User Level

The command can be accessed by operators with sip privileges.

Command Syntax

The command has the following syntax:

```
> show voice sip ua-ip-info [ (ua-name) [ slot-id <SIP::SlotIndex> ] ]
```

Command Parameters

Table 151.4-1 "Voice Sip User Agent related IP address information Show Commands" Resource Parameters

Resource Identifier	Type	Description
(ua-name)	Format: - uniquely identifies the User Agent - length: 1<=x<=32	uniquely identify of the user agent
slot-id	Parameter type: <SIP::SlotIndex> Format: (lt : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> nt ntio <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::EqSlotId>) Possible values: - lt : lt-slot - nt : nt-slot - ntio : ntio-slot Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::EqSlotId> - the equipment slot number	slot id associated with this user agent access point

Command Output

Table 151.4-2 "Voice Sip User Agent related IP address information Show Commands" Display parameters

Specific Information		
name	Type	Description
vsp-name	Parameter type: <Sip::UserAgentProviderName> - uniquely identifies the user agent provider name - length: x<=32	the provider name <i>This element is always shown.</i>
ip-config-mode	Parameter type: <Sip::IpConfigMode> (dhcp manual) Possible values: - dhcp : The IP related data is acquired from the DHCP server. - manual : The IP related data must be manually configured.	the configuration mode of the IP related data <i>This element is always shown.</i>
ipv4-sig-addr	Parameter type: <SIP::IpAddressAndMask> <Ip::V4Address> / <Sip::PrefixLength> Field type <Ip::V4Address> - IPv4-address Field type <Sip::PrefixLength> - prefix length of the subnet - range: [0...128]	the SIP User Agent signaling IPv4 address and subnet mask <i>This element is always shown.</i>
ipv4-sig-gw-addr	Parameter type: <Sip::UserAgentIPv4Addr> - IPv4-address	the signaling gateway IPv4 address <i>This element is always shown.</i>
ipv4-media-addr	Parameter type: <SIP::IpAddressAndMask> <Ip::V4Address> / <Sip::PrefixLength> Field type <Ip::V4Address> - IPv4-address Field type <Sip::PrefixLength> - prefix length of the subnet - range: [0...128]	the media IPv4 address and subnet mask <i>This element is always shown.</i>
ipv4-media-gw-addr	Parameter type: <Sip::UserAgentIPv4Addr> - IPv4-address	the media gateway IPv4 address <i>This element is always shown.</i>
ipv6-sig-addr	Parameter type: <SIP::IPv6AddressWithPrefix> <Ip::V6Address> / <Ip::V6PrefixLength> Field type <Ip::V6Address> - IPv6-address Field type <Ip::V6PrefixLength> - prefix length of IPv6-address - range: [0...128]	the SIP User Agent signaling IPv6 address and subnet mask <i>This element is always shown.</i>
ipv6-sig-gw-addr	Parameter type: <Sip::UserAgentIPv6Addr> - IPv6-address	the signaling gateway IPv6 address <i>This element is always shown.</i>
ipv6-media-addr	Parameter type: <SIP::IPv6AddressWithPrefix> <Ip::V6Address> / <Ip::V6PrefixLength> Field type <Ip::V6Address> - IPv6-address Field type <Ip::V6PrefixLength> - prefix length of IPv6-address - range: [0...128]	the media IPv6 address and subnet mask <i>This element is always shown.</i>
ipv6-media-gw-addr	Parameter type: <Sip::UserAgentIPv6Addr> - IPv6-address	the media gateway IPv6 address <i>This element is always shown.</i>

151.5 Voice Sip Statistics System Status Command

Command Description

This command allows the operator to show the various system parameters including the number of configured and available sip termination, the number of configured and unavailable sip termination, the number of unconfigured sip termination.

User Level

The command can be accessed by operators with forStatsPerSystem privileges.

Command Syntax

The command has the following syntax:

> show voice sip statistics system

Command Output

Table 151.5-2 "Voice Sip Statistics System Status Command" Display parameters

Specific Information		
name	Type	Description
config-avail-term	Parameter type: <Sip::NumberOfTerm> - the number of termination	The number of configured and available sip termination <i>This element is always shown.</i>
config-unavail-term	Parameter type: <Sip::NumberOfTerm> - the number of termination	The number of configured and unavailable sip termination <i>This element is always shown.</i>
unconfig-term	Parameter type: <Sip::NumberOfTerm> - the number of termination	The number of unconfigured sip termination <i>This element is always shown.</i>

151.6 Voice Sip Statistics Perfinfo Status Command

Command Description

This command allows the operator to show the various parameters including elapsed times for current 15-minutes interval and 1-day interval per termination, the number of pervious 15-minutes interval and 1-day interval per termination.

User Level

The command can be accessed by operators with *forStatsPerLine* privileges.

Command Syntax

The command has the following syntax:

```
> show voice sip statistics perf-info [ (if-index) ]
```

Command Parameters

Table 151.6-1 "Voice Sip Statistics Perfinfo Status Command" Resource Parameters

Resource Identifier	Type	Description
(if-index)	Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number	interface index of this port

Command Output

Table 151.6-2 "Voice Sip Statistics Perfinfo Status Command" Display parameters

Specific Information		
name	Type	Description
cur-15min-elapsedtime	Parameter type: <Sip::ElapsedTime> - the elapsed time - unit: sec	number of second elapsed in current 15 minutes interval measurement <i>This element is always shown.</i>
cur-1day-elapsedtime	Parameter type: <Sip::ElapsedTime>	number of second elapsed in

151 Voice Status Commands

name	Type	Description
	- the elapsed time - unit: sec	current 1 day interval measurement <i>This element is always shown.</i>
prev-15min-num	Parameter type: <Sip::PerfInterval> - the number of interval	number of previous 15 minutes intervals <i>This element is always shown.</i>
prev-1day-num	Parameter type: <Sip::PerfInterval> - the number of interval	number of previous 1 day intervals <i>This element is always shown.</i>

151.7 Voice Sip Termination Statistics Command for Current 15 Minutes

Command Description

This command allows the operator to show the Voice Sip Termination Statistics for current 15 minutes.

User Level

The command can be accessed by operators with sip privileges.

Command Syntax

The command has the following syntax:

```
> show voice sip statistics termination current-15min [ (if-index) ]
```

Command Parameters

Table 151.7-1 "Voice Sip Termination Statistics Command for Current 15 Minutes" Resource Parameters

Resource Identifier	Type	Description
(if-index)	Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number	interface index of this port

Command Output

Table 151.7-2 "Voice Sip Termination Statistics Command for Current 15 Minutes" Display parameters

Specific Information		
name	Type	Description
meastime(s)	Parameter type: <Sip::IntervalMeasureTime> - the measured time of interval - unit: sec	amount of time in sec that statistics have been counted <i>This element is only shown in detail mode.</i>
invalidflag	Parameter type: <Sip::IntervalValidityFlag>	validity of the corresponding

151 Voice Status Commands

name	Type	Description
	(true false) Possible values: - true : data is not valid - false : data is valid	performance monitoring data in current 15m interval <i>This element is always shown.</i>
sentrtppkts	Parameter type: <Counter> - 32 bit counter	number of rtp packets transmitted by this termination in current 15m interval <i>This element is always shown.</i>
sentoct	Parameter type: <Counter> - 32 bit counter	number of rtp octets transmitted by this termination in current 15m interval <i>This element is always shown.</i>
recvrtpkts	Parameter type: <Counter> - 32 bit counter	number of rtp packets received by this termination in current 15m interval <i>This element is always shown.</i>
recvoct	Parameter type: <Counter> - 32 bit counter	number of rtp octets received by this termination in current 15m interval <i>This element is always shown.</i>
lostrtpkts	Parameter type: <Sip::LostPackets> - the number of lost rtp packets	number of lost receiving rtp packets for this termination in current 15m interval <i>This element is always shown.</i>
avgjbfl(%)	Parameter type: <Sip::JBFL> - average of jitter buffer fill level percentage for the termination - unit: percentage - range: [0...100]	average of jitter buffer fill level percentage for this termination in current 15m interval <i>This element is always shown.</i>
avgjitter(ms)	Parameter type: <Sip::Jitter> - average of jitter for the termination - unit: millisec	average of jitter for this termination in current 15m interval <i>This element is always shown.</i>
avgrtdelay(ms)	Parameter type: <Sip::RoundTripDelay> - average of round-trip delay for this termination - unit: millisec	average of round-trip delay for this termination in current 15m interval <i>This element is always shown.</i>
maxjitter(ms)	Parameter type: <Sip::Jitter> - average of jitter for the termination - unit: millisec	peak inter-arrival for this termination in current 15m interval. <i>This element is always shown.</i>
maxrtdelay(ms)	Parameter type: <Sip::RoundTripDelay> - average of round-trip delay for this termination - unit: millisec	peak of round-trip delay for this termination in current 15m interval. <i>This element is always shown.</i>
avgjbflg711a(%)	Parameter type: <Sip::JBFL> - average of jitter buffer fill level percentage for the termination - unit: percentage - range: [0...100]	average of jitter buffer fill level encoded with G711_a percentage for this termination in current 15m interval. <i>This element is always shown.</i>
avgjbflg711u(%)	Parameter type: <Sip::JBFL> - average of jitter buffer fill level percentage for the termination - unit: percentage - range: [0...100]	average of jitter buffer fill level encoded with G711_u percentage for this termination in current 15m interval. <i>This element is always shown.</i>
avgjbflg723(%)	Parameter type: <Sip::JBFL>	average of jitter buffer fill level

name	Type	Description
	- average of jitter buffer fill level percentage for the termination - unit: percentage - range: [0...100]	encoded with G723 percentage for this termination in current 15m interval. <i>This element is always shown.</i>
avgjbflg729(%)	Parameter type: <Sip::JBFL> - average of jitter buffer fill level percentage for the termination - unit: percentage - range: [0...100]	average of jitter buffer fill level encoded with G729 percentage for this termination in current 15m interval. <i>This element is always shown.</i>
succregatt	Parameter type: <Sip::SignalCounter> - the counter of CMCC for signal statistics	Count the successful registration Num during the interval for this termination in current 15m interval <i>This element is always shown.</i>
failregatt	Parameter type: <Sip::SignalCounter> - the counter of CMCC for signal statistics	Count the failed registration Num during the interval for this termination in current 15m interval <i>This element is always shown.</i>
activereg	Parameter type: <Sip::SignalCounter> - the counter of CMCC for signal statistics	Count the active Registration Status at the end of the interval for this termination in current 15m interval <i>This element is always shown.</i>
outcallconn	Parameter type: <Sip::SignalCounter> - the counter of CMCC for signal statistics	Answered out-going call count for this termination in current 15m interval <i>This element is always shown.</i>
incallconn	Parameter type: <Sip::SignalCounter> - the counter of CMCC for signal statistics	Answered incoming call count for this termination in current 15m interval <i>This element is always shown.</i>
outcallatt	Parameter type: <Sip::SignalCounter> - the counter of CMCC for signal statistics	Number of all outgoing call requests on the port in current 15 minutes interval <i>This element is always shown.</i>
outcallseizdur(s)	Parameter type: <Sip::StatsTermTime> - Time duration for statics sip termination. - unit: second - range: [0...86400]	Port seizure time of outgoing call attempts in current 15 minutes interval <i>This element is always shown.</i>
outfaillostseiz	Parameter type: <Sip::SignalCounter> - the counter of CMCC for signal statistics	The number of outgoing call attempts that fail because of an access failure to the voice network (Timer B expiry) in current 15 minutes interval <i>This element is always shown.</i>
outsuccinitinv	Parameter type: <Sip::SignalCounter> - the counter of CMCC for signal statistics	The number of outgoing call attempts for which the initial invite is successfully responded by the IMS core in current 15 minutes interval. <i>This element is always shown.</i>
incallatt	Parameter type: <Sip::SignalCounter> - the counter of CMCC for signal statistics	Number of incoming call requests in current 15 minutes interval <i>This element is always shown.</i>
incallseizdur(s)	Parameter type: <Sip::StatsTermTime> - Time duration for statics sip termination.	Port seizure time in seconds of incoming call attempts in current

151 Voice Status Commands

name	Type	Description
	- unit: second - range: [0...86400]	15 minutes interval <i>This element is always shown.</i>
infailllostseiz	Parameter type: <Sip::SignalCounter> - the counter of CMCC for signal statistics	The number of incoming call attempts that fail because of an access failure to the voice network (Timer B expiry) in current 15 minutes interval. <i>This element is always shown.</i>
exprrtpkts	Parameter type: <Counter> - 32 bit counter	The amount of RTP packets expected in current 15 minutes interval <i>This element is always shown.</i>
accrrtpkts	Parameter type: <Counter> - 32 bit counter	The amount of RTP packets processed by the decoder in current 15 minutes interval <i>This element is always shown.</i>
discrrtpkts	Parameter type: <Counter> - 32 bit counter	Number of discarded RTP packages other than late or early arrival in current 15 minutes interval <i>This element is always shown.</i>
elarrrrtpkts	Parameter type: <Counter> - 32 bit counter	Number of discarded RTP packages due to early or late arrival in current 15 minutes interval <i>This element is always shown.</i>
portregdur(s)	Parameter type: <Sip::StatsTermTime> - Time duration for statics sip termination. - unit: second - range: [0...86400]	Sum of seconds of subscriber connection successfully registered in current 15 minutes interval <i>This element is always shown.</i>
portavaildur(s)	Parameter type: <Sip::StatsTermTime> - Time duration for statics sip termination. - unit: second - range: [0...86400]	Sum of seconds of the port is created without the periods where the port is unavailable in current 15 minutes interval <i>This element is always shown.</i>

151.8 Voice Sip Termination Statistics Command for Current Day

Command Description

This command allows the operator to show the Voice Sip Termination Statistics for current 1 day.

User Level

The command can be accessed by operators with sip privileges.

Command Syntax

The command has the following syntax:

```
> show voice sip statistics termination current-1day [ (if-index) ]
```

Command Parameters

Table 151.8-1 "Voice Sip Termination Statistics Command for Current Day" Resource Parameters

Resource Identifier	Type	Description
(if-index)	Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number	interface index of this port

Command Output

Table 151.8-2 "Voice Sip Termination Statistics Command for Current Day" Display parameters

Specific Information		
name	Type	Description
meastime(s)	Parameter type: <Sip::IntervalMeasureTime> - the measured time of interval - unit: sec	amount of time in sec that statistics have been counted <i>This element is only shown in detail mode.</i>
invalidflag	Parameter type: <Sip::IntervalValidityFlag> (true false)	validity of the corresponding performance monitoring data in current 1day interval

151 Voice Status Commands

name	Type	Description
	Possible values: - true : data is not valid - false : data is valid	<i>This element is always shown.</i>
sentrtppkts	Parameter type: <Counter> - 32 bit counter	number of rtp packets transmitted by this termination in current 1day interval <i>This element is always shown.</i>
sentoct	Parameter type: <Counter> - 32 bit counter	number of rtp octets transmitted by this termination in current 1day interval <i>This element is always shown.</i>
recvrtpkts	Parameter type: <Counter> - 32 bit counter	number of rtp packets received by this termination in current 1day interval <i>This element is always shown.</i>
recvoct	Parameter type: <Counter> - 32 bit counter	number of rtp octets received by this termination in current 1day interval <i>This element is always shown.</i>
lostrtpkts	Parameter type: <Sip::LostPackets> - the number of lost rtp packets	number of lost receiving rtp packets for this termination in current 1day interval <i>This element is always shown.</i>
avgjbfl(%)	Parameter type: <Sip::JBFL> - average of jitter buffer fill level percentage for the termination - unit: percentage - range: [0...100]	average of jitter buffer fill level percentage for this termination in current 1day interval <i>This element is always shown.</i>
avgjitter(ms)	Parameter type: <Sip::Jitter> - average of jitter for the termination - unit: millisec	average of jitter for this termination in current 1day interval <i>This element is always shown.</i>
avgrtdelay(ms)	Parameter type: <Sip::RoundTripDelay> - average of round-trip delay for this termination - unit: millisec	average of round-trip delay for this termination in current 1day interval <i>This element is always shown.</i>
maxjitter(ms)	Parameter type: <Sip::Jitter> - average of jitter for the termination - unit: millisec	peak inter-arrival for this termination in current 1day interval. <i>This element is always shown.</i>
maxrtdelay(ms)	Parameter type: <Sip::RoundTripDelay> - average of round-trip delay for this termination - unit: millisec	peak of round-trip delay for this termination in current 1day interval. <i>This element is always shown.</i>
avgjbflg711a(%)	Parameter type: <Sip::JBFL> - average of jitter buffer fill level percentage for the termination - unit: percentage - range: [0...100]	average of jitter buffer fill level encoded with G711_a percentage for this termination in current 1day interval. <i>This element is always shown.</i>
avgjbflg711u(%)	Parameter type: <Sip::JBFL> - average of jitter buffer fill level percentage for the termination - unit: percentage - range: [0...100]	average of jitter buffer fill level encoded with G711_u percentage for this termination in current 1day interval. <i>This element is always shown.</i>
avgjbflg723(%)	Parameter type: <Sip::JBFL> - average of jitter buffer fill level percentage for the termination	average of jitter buffer fill level encoded with G723 percentage for this termination in current

name	Type	Description
	- unit: percentage - range: [0...100]	1day interval. <i>This element is always shown.</i>
avgjbflg729(%)	Parameter type: <Sip::JBFL> - average of jitter buffer fill level percentage for the termination - unit: percentage - range: [0...100]	average of jitter buffer fill level encoded with G729 percentage for this termination in current 1day interval. <i>This element is always shown.</i>
succregatt	Parameter type: <Sip::SignalCounter> - the counter of CMCC for signal statistics	Count the successful registration Num during the interval for this termination in current 1d interval <i>This element is always shown.</i>
failregatt	Parameter type: <Sip::SignalCounter> - the counter of CMCC for signal statistics	Count the failed registration Num during the interval for this termination in current 1d interval <i>This element is always shown.</i>
activerereg	Parameter type: <Sip::SignalCounter> - the counter of CMCC for signal statistics	Count the active Registration Status at the end of the interval for this termination in current 1d interval <i>This element is always shown.</i>
outcallconn	Parameter type: <Sip::SignalCounter> - the counter of CMCC for signal statistics	Answered out-going call count for this termination in current 1d interval <i>This element is always shown.</i>
incallconn	Parameter type: <Sip::SignalCounter> - the counter of CMCC for signal statistics	Answered incoming call count for this termination in current 1d interval <i>This element is always shown.</i>

151.9 Voice Sip Termination Statistics Command for Previous 15 Minutes

Command Description

This command allows the operator to show the Voice Sip Termination Statistics for previous 15 minutes.

User Level

The command can be accessed by operators with sip privileges.

Command Syntax

The command has the following syntax:

```
> show voice sip statistics termination prev-15min [ (if-index) [ interval-num <Sip::IntervalNumber15min> ] ]
```

Command Parameters

Table 151.9-1 "Voice Sip Termination Statistics Command for Previous 15 Minutes" Resource Parameters

Resource Identifier	Type	Description
(if-index)	Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number	interface index of this port
interval-num	Parameter type: <Sip::IntervalNumber15min> Format: - the measured time interval - range: [1...96]	identifies prev 15min intervals, value 1 as the latest interval

Command Output

Table 151.9-2 "Voice Sip Termination Statistics Command for Previous 15 Minutes" Display parameters

Specific Information		
name	Type	Description
timestamp	Parameter type: <Sip::SipTimeInSecs>	specifies the start time for this

name	Type	Description
	- the time (yyyy-mm-dd:hour:minutes:secs)	termination in previous 15m interval <i>This element is always shown.</i>
meastime(s)	Parameter type: <Sip::IntervalMeasureTime> - the measured time of interval - unit: sec	amount of time in sec that statistics have been counted <i>This element is only shown in detail mode.</i>
invalidflag	Parameter type: <Sip::IntervalValidityFlag> (true false) Possible values: - true : data is not valid - false : data is valid	validity of the corresponding performance monitoring data in previous 15m interval <i>This element is always shown.</i>
sentrtppkts	Parameter type: <Counter> - 32 bit counter	number of rtp packets transmitted by this termination in previous 15m interval <i>This element is always shown.</i>
sentoct	Parameter type: <Counter> - 32 bit counter	number of rtp octets transmitted by this termination in previous 15m interval <i>This element is always shown.</i>
recvrtpkts	Parameter type: <Counter> - 32 bit counter	number of rtp packets received by this termination in previous 15m interval <i>This element is always shown.</i>
recvoct	Parameter type: <Counter> - 32 bit counter	number of rtp octets received by this termination in previous 15m interval <i>This element is always shown.</i>
lostrtpkts	Parameter type: <Sip::LostPackets> - the number of lost rtp packets	number of lost receiving rtp packets for this termination in previous 15m interval <i>This element is always shown.</i>
avgjbf(%)	Parameter type: <Sip::JBFL> - average of jitter buffer fill level percentage for the termination - unit: percentage - range: [0...100]	average of jitter buffer fill level percentage for this termination in previous 15m interval <i>This element is always shown.</i>
avgjitter(ms)	Parameter type: <Sip::Jitter> - average of jitter for the termination - unit: millisec	average of jitter for this termination in previous 15m interval <i>This element is always shown.</i>
avgrtdelay(ms)	Parameter type: <Sip::RoundTripDelay> - average of round-trip delay for this termination - unit: millisec	average of round-trip delay for this termination in previous 15m interval <i>This element is always shown.</i>
maxjitter(ms)	Parameter type: <Sip::Jitter> - average of jitter for the termination - unit: millisec	peak inter-arrival for this termination in previous 15m interval. <i>This element is always shown.</i>
maxrtdelay(ms)	Parameter type: <Sip::RoundTripDelay> - average of round-trip delay for this termination - unit: millisec	peak of round-trip delay for this termination in previous 15m interval. <i>This element is always shown.</i>
avgjbflg711a(%)	Parameter type: <Sip::JBFL> - average of jitter buffer fill level percentage for the termination	average of jitter buffer fill level encoded with G711_a percentage for this termination in previous

151 Voice Status Commands

name	Type	Description
	- unit: percentage - range: [0...100]	15m interval. <i>This element is always shown.</i>
avgjbflg711u(%)	Parameter type: <Sip::JBFL> - average of jitter buffer fill level percentage for the termination - unit: percentage - range: [0...100]	average of jitter buffer fill level encoded with G711_u percentage for this termination in previous 15m interval. <i>This element is always shown.</i>
avgjbflg723(%)	Parameter type: <Sip::JBFL> - average of jitter buffer fill level percentage for the termination - unit: percentage - range: [0...100]	average of jitter buffer fill level encoded with G723 percentage for this termination in previous 15m interval. <i>This element is always shown.</i>
avgjbflg729(%)	Parameter type: <Sip::JBFL> - average of jitter buffer fill level percentage for the termination - unit: percentage - range: [0...100]	average of jitter buffer fill level encoded with G729 percentage for this termination in previous 15m interval. <i>This element is always shown.</i>
succregatt	Parameter type: <Sip::SignalCounter> - the counter of CMCC for signal statistics	Count the successful registration Num during the interval for this termination in previous 15m interval <i>This element is always shown.</i>
failregatt	Parameter type: <Sip::SignalCounter> - the counter of CMCC for signal statistics	Count the failed registration Num during the interval for this termination in previous 15m interval <i>This element is always shown.</i>
activerereg	Parameter type: <Sip::SignalCounter> - the counter of CMCC for signal statistics	Count the active Registration Status at the end of the interval for this termination in previous 15m interval <i>This element is always shown.</i>
outcallconn	Parameter type: <Sip::SignalCounter> - the counter of CMCC for signal statistics	Answered out-going call count for this termination in previous 15m interval <i>This element is always shown.</i>
incallconn	Parameter type: <Sip::SignalCounter> - the counter of CMCC for signal statistics	Answered incoming call count for this termination in previous 15m interval <i>This element is always shown.</i>
outcallatt	Parameter type: <Sip::SignalCounter> - the counter of CMCC for signal statistics	Number of all outgoing call requests on the port in this previous 15 minutes interval <i>This element is always shown.</i>
outcallseizdur(s)	Parameter type: <Sip::StatsTermTime> - Time duration for statics sip termination. - unit: second - range: [0...86400]	Port seizure time of outgoing call attempts in previous 15 minutes interval <i>This element is always shown.</i>
outfaillostseiz	Parameter type: <Sip::SignalCounter> - the counter of CMCC for signal statistics	The number of outgoing call attempts that fail because of an access failure to the voice network (Timer B expiry) in previous 15 minutes interval. <i>This element is always shown.</i>
outsuccinitinv	Parameter type: <Sip::SignalCounter> - the counter of CMCC for signal statistics	The number of outgoing call attempts for which the initial invite is successfully responded

name	Type	Description
		by the IMS core in previous 15 minutes interval. <i>This element is always shown.</i>
incallatt	Parameter type: <Sip::SignalCounter> - the counter of CMCC for signal statistics	Number of incoming call requests in previous 15 minutes interval <i>This element is always shown.</i>
incallseizdur(s)	Parameter type: <Sip::StatsTermTime> - Time duration for statics sip termination. - unit: second - range: [0...86400]	Port seizure time in seconds of incoming call attempts in previous 15 minutes interval <i>This element is always shown.</i>
infailllostseiz	Parameter type: <Sip::SignalCounter> - the counter of CMCC for signal statistics	The number of incoming call attempts that fail because of an access failure to the voice network (Timer B expiry) in previous 15 minutes interval. <i>This element is always shown.</i>
exrtppts	Parameter type: <Counter> - 32 bit counter	The amount of RTP packets expected in previous 15 minutes interval <i>This element is always shown.</i>
accrtppts	Parameter type: <Counter> - 32 bit counter	The amount of RTP packets processed by the decoder in previous 15 minutes interval <i>This element is always shown.</i>
discrtppts	Parameter type: <Counter> - 32 bit counter	Number of discarded RTP packages other than late or early arrival in previous 15 minutes interval <i>This element is always shown.</i>
elarrtpppts	Parameter type: <Counter> - 32 bit counter	Number of discarded RTP packages due to early or late arrival in previous 15 minutes interval <i>This element is always shown.</i>
portregdur(s)	Parameter type: <Sip::StatsTermTime> - Time duration for statics sip termination. - unit: second - range: [0...86400]	Sum of seconds of subscriber connection successfully registered in previous 15 minutes interval <i>This element is always shown.</i>
portavaildur(s)	Parameter type: <Sip::StatsTermTime> - Time duration for statics sip termination. - unit: second - range: [0...86400]	Sum of seconds of the port is created without the periods where the port is unavailable in previous 15 minutes interval <i>This element is always shown.</i>

151.10 Voice Sip Termination Statistics Command for Previous day

Command Description

This command allows the operator to show the Voice Sip Termination Statistics for previous 1 day.

User Level

The command can be accessed by operators with sip privileges.

Command Syntax

The command has the following syntax:

```
> show voice sip statistics termination prev-1day [ (if-index) [ interval-num <Sip::IntervalNumber1day> ] ]
```

Command Parameters

Table 151.10-1 "Voice Sip Termination Statistics Command for Previous day" Resource Parameters

Resource Identifier	Type	Description
(if-index)	Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number	interface index of this port
interval-num	Parameter type: <Sip::IntervalNumber1day> Format: - the measured time interval - range: [1...3]	identifies prev 1 day intervals, value 1 as the latest interval

Command Output

Table 151.10-2 "Voice Sip Termination Statistics Command for Previous day" Display parameters

Specific Information		
name	Type	Description
meastime(s)	Parameter type: <Sip::IntervalMeasureTime> - the measured time of interval - unit: sec	amount of time in sec that statistics have been counted <i>This element is only shown in</i>

name	Type	Description
		<i>detail mode.</i>
invalidflag	Parameter type: <Sip::IntervalValidityFlag> (true false) Possible values: - true : data is not valid - false : data is valid	validity of the corresponding performance monitoring data in previous 1day interval <i>This element is always shown.</i>
sentrtppkts	Parameter type: <Counter> - 32 bit counter	number of rtp packets transmitted by this termination in previous 1day interval <i>This element is always shown.</i>
sentoct	Parameter type: <Counter> - 32 bit counter	number of rtp octets transmitted by this termination in previous 1day interval <i>This element is always shown.</i>
recvrtpkts	Parameter type: <Counter> - 32 bit counter	number of rtp packets received by this termination in previous 1day interval <i>This element is always shown.</i>
recvoct	Parameter type: <Counter> - 32 bit counter	number of rtp octets received by this termination in previous 1day interval <i>This element is always shown.</i>
lostrtpkts	Parameter type: <Sip::LostPackets> - the number of lost rtp packets	number of lost receiving rtp packets for this termination in previous 1day interval <i>This element is always shown.</i>
avgjbf(%)	Parameter type: <Sip::JBFL> - average of jitter buffer fill level percentage for the termination - unit: percentage - range: [0...100]	average of jitter buffer fill level percentage for this termination in previous 1day interval <i>This element is always shown.</i>
avgjitter(ms)	Parameter type: <Sip::Jitter> - average of jitter for the termination - unit: millise	average of jitter for this termination in previous 1day interval <i>This element is always shown.</i>
avgrtdelay(ms)	Parameter type: <Sip::RoundTripDelay> - average of round-trip delay for this termination - unit: millise	average of round-trip delay for this termination in previous 1day interval <i>This element is always shown.</i>
maxjitter(ms)	Parameter type: <Sip::Jitter> - average of jitter for the termination - unit: millise	peak inter-arrival for this termination in previous 1day interval. <i>This element is always shown.</i>
maxrtdelay(ms)	Parameter type: <Sip::RoundTripDelay> - average of round-trip delay for this termination - unit: millise	peak of round-trip delay for this termination in previous 1day interval. <i>This element is always shown.</i>
avgjbflg711a(%)	Parameter type: <Sip::JBFL> - average of jitter buffer fill level percentage for the termination - unit: percentage - range: [0...100]	average of jitter buffer fill level encoded with G711_a percentage for this termination in previous 1day interval. <i>This element is always shown.</i>
avgjbflg711u(%)	Parameter type: <Sip::JBFL> - average of jitter buffer fill level percentage for the termination - unit: percentage	average of jitter buffer fill level encoded with G711_u percentage for this termination in previous 1day interval.

151 Voice Status Commands

name	Type	Description
	- range: [0...100]	<i>This element is always shown.</i>
avgjbflg723(%)	Parameter type: <Sip::JBFL> - average of jitter buffer fill level percentage for the termination - unit: percentage - range: [0...100]	average of jitter buffer fill level encoded with G723 percentage for this termination in previous 1day interval. <i>This element is always shown.</i>
avgjbflg729(%)	Parameter type: <Sip::JBFL> - average of jitter buffer fill level percentage for the termination - unit: percentage - range: [0...100]	average of jitter buffer fill level encoded with G729 percentage for this termination in previous 1day interval. <i>This element is always shown.</i>
succregatt	Parameter type: <Sip::SignalCounter> - the counter of CMCC for signal statistics	Count the successful registration Num during the interval for this termination in previous 1d interval <i>This element is always shown.</i>
failregatt	Parameter type: <Sip::SignalCounter> - the counter of CMCC for signal statistics	Count the failed registration Num during the interval for this termination in previous 1d interval <i>This element is always shown.</i>
activerereg	Parameter type: <Sip::SignalCounter> - the counter of CMCC for signal statistics	Count the active Registration Status at the end of the interval for this termination in previous 1d interval <i>This element is always shown.</i>
outcallconn	Parameter type: <Sip::SignalCounter> - the counter of CMCC for signal statistics	Answered out-going call count for this termination in previous 1d interval <i>This element is always shown.</i>
incallconn	Parameter type: <Sip::SignalCounter> - the counter of CMCC for signal statistics	Answered incoming call count for this termination in previous 1d interval <i>This element is always shown.</i>
timestamp	Parameter type: <Sip::SipTimeInSecs> - the time (yyyy-mm-dd:hour:minutes:secs)	specifies the start time for this termination in previous 1d interval <i>This element is always shown.</i>

151.11 Voice Sip MSAN Statistics Command

Command Description

This command allows the operator to show the Voice Sip MSAN Statistics.

User Level

The command can be accessed by operators with sip privileges.

Command Syntax

The command has the following syntax:

```
> show voice sip statistics call (if-index) interval [ (interval-num) [ start-time <Sip::SipTimeInSecs> ] [ icid <Sip::ICId> ] ]
```

Command Parameters

Table 151.11-1 "Voice Sip MSAN Statistics Command" Resource Parameters

Resource Identifier	Type	Description
(if-index)	Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number	interface index of this port
(interval-num)	Format: - the measured time interval - range: [1...96]	identifies 15min intervals, value 1 as the latest interval
start-time	Parameter type: <Sip::SipTimeInSecs> Format: - the time (yyyy-mm-dd:hour:minutes:secs)	time value in seconds when the call was initialized
icid	Parameter type: <Sip::ICId> Format: - the ims charging id in SIP - length: x<=38	the ims charging id in sip

Command Output

Table 151.11-2 "Voice Sip MSAN Statistics Command" Display parameters

Specific Information

151 Voice Status Commands

name	Type	Description
end-time	Parameter type: <Sys::timeInSecs> - the time (yyyy-mm-dd:hour:minutes:secs) - unit: UTC	time value in seconds when the call was end <i>This element is only shown in detail mode.</i>
send-packets	Parameter type: <Counter> - 32 bit counter	number of rtp packets transmitted in this call portion <i>This element is always shown.</i>
send-octets	Parameter type: <Counter> - 32 bit counter	number of rtp octets transmitted in this call portion <i>This element is always shown.</i>
receive-packets	Parameter type: <Counter> - 32 bit counter	number of rtp packets received in this call portion <i>This element is always shown.</i>
receive-octets	Parameter type: <Counter> - 32 bit counter	number of rtp octets received in this call portion <i>This element is always shown.</i>
avg-jitter	Parameter type: <Sip::Jitter> - average of jitter for the termination - unit: millisec	average inter-arrival jitter measured in this call portion <i>This element is always shown.</i>
avg-rttrip-delay	Parameter type: <Sip::RoundTripDelay> - average of round-trip delay for this termination - unit: millisec	average round-trip delay measured in this call portion <i>This element is always shown.</i>
peak-jitter	Parameter type: <Sip::Jitter> - average of jitter for the termination - unit: millisec	peak inter-arrival jitter measured in this call portion <i>This element is always shown.</i>
peak-rttrip-delay	Parameter type: <Sip::RoundTripDelay> - average of round-trip delay for this termination - unit: millisec	peak round-trip delay measured in this call portion <i>This element is always shown.</i>
lost-packets	Parameter type: <Sip::LostPackets> - the number of lost rtp packets	total number of lost receiving rtp packets in this call portion <i>This element is always shown.</i>
dis-pack-jb-over	Parameter type: <Counter> - 32 bit counter	total number of discarded rtp packets due to the jitter buffer over-flow in this call portion <i>This element is always shown.</i>
dialogue-state-flag	Parameter type: <Sip::DialogStateFlag> (single-interval-dialog end-dialog continue-dialog start-dialog) Possible values: - single-interval-dialog: one dialog starts and ends in the same interval - end-dialog : one dialog ends in different intervals - continue-dialog : dialog still continue - start-dialog : one dialog starts not end yet interval reached	per call dialog state flag <i>This element is always shown.</i>

151.12 Voice Sip board Statistics Command for Current one Day

Command Description

This command allows the operator to show the Voice Sip board Statistics for current one day.

User Level

The command can be accessed by operators with sip privileges.

Command Syntax

The command has the following syntax:

```
> show voice sip statistics board current-1day [ (slot-id) ]
```

Command Parameters

Table 151.12-1 "Voice Sip board Statistics Command for Current one Day" Resource Parameters

Resource Identifier	Type	Description
(slot-id)	Format: (lt : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> nt-a nt-b nt <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::EqSlotId>) Possible values: - lt : lt-slot - nt-a : nt-a slot - nt-b : nt-b slot - nt : nt slot Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::EqSlotId> - the equipment slot number	interface index of this LT board.

Command Output

Table 151.12-2 "Voice Sip board Statistics Command for Current one Day" Display parameters

Specific Information

151 Voice Status Commands

name	Type	Description
meastime(s)	Parameter type: <Sip::IntervalMeasureTime> - the measured time of interval - unit: sec	amount of time in sec that statistics have been counted. <i>This element is only shown in detail mode.</i>
invalidflag	Parameter type: <Sip::IntervalValidityFlag> (true false) Possible values: - true : data is not valid - false : data is valid	validity of the corresponding performance monitoring data in current 1day interval. <i>This element is always shown.</i>
sentrtppkts	Parameter type: <Counter> - 32 bit counter	number of RTP packets transmitted by this board in current 1day interval. <i>This element is always shown.</i>
sentoct	Parameter type: <Counter> - 32 bit counter	number of RTP octets transmitted by this board in current 1day interval. <i>This element is always shown.</i>
recvrtpkts	Parameter type: <Counter> - 32 bit counter	number of RTP packets received by this board in current 1day interval. <i>This element is always shown.</i>
recvoct	Parameter type: <Counter> - 32 bit counter	number of RTP octets received by this board in current 1day interval. <i>This element is always shown.</i>
lostrtpkts	Parameter type: <Sip::LostPackets> - the number of lost rtp packets	number of lost receiving RTP packets for this board in current 1day interval. <i>This element is always shown.</i>
avgjbfl(%)	Parameter type: <Sip::JBFL> - average of jitter buffer fill level percentage for the termination - unit: percentage - range: [0...100]	average of jitter buffer fill level percentage for this board in current 1day interval. <i>This element is always shown.</i>
avgjitter(ms)	Parameter type: <Sip::Jitter> - average of jitter for the termination - unit: millisec	average of jitter for this board in current 1day interval. <i>This element is always shown.</i>
avgrtdelay(ms)	Parameter type: <Sip::RoundTripDelay> - average of round-trip delay for this termination - unit: millisec	average of round-trip delay for this board in current 1day interval. <i>This element is always shown.</i>
maxjitter(ms)	Parameter type: <Sip::Jitter> - average of jitter for the termination - unit: millisec	peak inter-arrival for this board in current 1day interval. <i>This element is always shown.</i>
maxrtdelay(ms)	Parameter type: <Sip::RoundTripDelay> - average of round-trip delay for this termination - unit: millisec	peak of round-trip delay for this board in current 1day interval. <i>This element is always shown.</i>
avgjbflg711a(%)	Parameter type: <Sip::JBFL> - average of jitter buffer fill level percentage for the termination - unit: percentage - range: [0...100]	average of jitter buffer fill level encoded with G711_a percentage for this board in current 1day interval. <i>This element is always shown.</i>
avgjbflg711u(%)	Parameter type: <Sip::JBFL> - average of jitter buffer fill level percentage for the termination - unit: percentage	average of jitter buffer fill level encoded with G711_u percentage for this board in current 1day interval.

name	Type	Description
	- range: [0...100]	<i>This element is always shown.</i>
avgjbflg723(%)	Parameter type: <Sip::JBFL> - average of jitter buffer fill level percentage for the termination - unit: percentage - range: [0...100]	average of jitter buffer fill level encoded with G723 percentage for this board in current 1day interval. <i>This element is always shown.</i>
avgjbflg729(%)	Parameter type: <Sip::JBFL> - average of jitter buffer fill level percentage for the termination - unit: percentage - range: [0...100]	average of jitter buffer fill level encoded with G729 percentage for this board in current 1day interval. <i>This element is always shown.</i>
avgcpu(%)	Parameter type: <Sys::cpuloadaverage> - average load for the measurement period , expressed in percentage - unit: percentage - range: [0...100]	average the CPU load for this board in current 1day interval. <i>This element is always shown.</i>
avgmemuse(%)	Parameter type: <Sys::memusageUtilization> - memory size - unit: Mbyte	average amount of semi and dynamic memory been used, expressed as a portion of the total memory for this board in current 1day interval. <i>This element is always shown.</i>
avgmempoolfree(mb)	Parameter type: <Sys::memusageFree> - memory size - unit: Mbyte	average amount of free semi and dynamic memory for this board in current 1day interval. <i>This element is always shown.</i>
avgmempooluse(mb)	Parameter type: <Sys::memusageAbsolute> - memory size - unit: Mbyte	average amount of semi and dynamic memory been used for this board in current 1day interval. <i>This element is always shown.</i>
avgmempooltot(mb)	Parameter type: <Sys::totalMem> - memory size - unit: Mbyte	total amount memory on this board in current 1day interval. <i>This element is always shown.</i>
spareports	Parameter type: <Sip::NumberOfTerm> - the number of termination	the number of unconfigured sip termination in this board at the end of current 1day interval. <i>This element is always shown.</i>
actports	Parameter type: <Sip::NumberOfTerm> - the number of termination	the number of active sip termination in this board at the end of current 1day interval. <i>This element is always shown.</i>
inactports	Parameter type: <Sip::NumberOfTerm> - the number of termination	the number of inactive sip termination (locked) in this board at the end of current 1day interval. <i>This element is always shown.</i>
succregatt	Parameter type: <Sip::SignalCounter> - the counter of CMCC for signal statistics	Count the successful registration Num for whole board in current 1 day interval <i>This element is always shown.</i>
failregatt	Parameter type: <Sip::SignalCounter> - the counter of CMCC for signal statistics	Count the failed registration Num for whole board in current 1 day interval <i>This element is always shown.</i>
activerereg	Parameter type: <Sip::SignalCounter> - the counter of CMCC for signal statistics	Count the active Registration Status for whole board at the end

151 Voice Status Commands

name	Type	Description
		of current 1 day interval <i>This element is always shown.</i>
outcallconn	Parameter type: <Sip::SignalCounter> - the counter of CMCC for signal statistics	Answered out-going call count for whole board in current 1 day interval <i>This element is always shown.</i>
incallconn	Parameter type: <Sip::SignalCounter> - the counter of CMCC for signal statistics	Answered incoming call count for whole board in current 1 day interval <i>This element is always shown.</i>

151.13 Voice Sip Board Statistics Command for Previous day

Command Description

This command allows the operator to show the Voice Sip Board Statistics for previous 1 day.

User Level

The command can be accessed by operators with sip privileges.

Command Syntax

The command has the following syntax:

```
> show voice sip statistics board prev-1day [ (slot-id) [ interval-num <Sip::IntervalNumber1day> ] ]
```

Command Parameters

Table 151.13-1 "Voice Sip Board Statistics Command for Previous day" Resource Parameters

Resource Identifier	Type	Description
(slot-id)	Format: (lt : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> nt-a nt-b nt <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::EqSlotId>) Possible values: - lt : lt-slot - nt-a : nt-a slot - nt-b : nt-b slot - nt : nt slot Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::EqSlotId> - the equipment slot number	interface index of this LT board.
interval-num	Parameter type: <Sip::IntervalNumber1day> Format: - the measured time interval - range: [1...3]	identifies prev 1 day intervals, value 1 as the latest interval.

Command Output

Table 151.13-2 "Voice Sip Board Statistics Command for Previous day" Display parameters

Specific Information		
name	Type	Description
meastime(s)	Parameter type: <Sip::IntervalMeasureTime> - the measured time of interval - unit: sec	amount of time in sec that statistics have been counted. <i>This element is only shown in detail mode.</i>
invalidflag	Parameter type: <Sip::IntervalValidityFlag> (true false) Possible values: - true : data is not valid - false : data is valid	validity of the corresponding performance monitoring data in previous 1day interval. <i>This element is always shown.</i>
sentrtppkts	Parameter type: <Counter> - 32 bit counter	number of RTP packets transmitted by this board in previous 1day interval. <i>This element is always shown.</i>
sentoct	Parameter type: <Counter> - 32 bit counter	number of RTP octets transmitted by this board in previous 1day interval. <i>This element is always shown.</i>
recvrtpkts	Parameter type: <Counter> - 32 bit counter	number of RTP packets received by this board in previous 1day interval. <i>This element is always shown.</i>
recvoct	Parameter type: <Counter> - 32 bit counter	number of RTP octets received by this board in previous 1day interval. <i>This element is always shown.</i>
lostrtpkts	Parameter type: <Sip::LostPackets> - the number of lost rtp packets	number of lost receiving RTP packets for this board in previous 1day interval. <i>This element is always shown.</i>
avgjbfl(%)	Parameter type: <Sip::JBFL> - average of jitter buffer fill level percentage for the termination - unit: percentage - range: [0...100]	average of jitter buffer fill level percentage for this board in previous 1day interval. <i>This element is always shown.</i>
avgjitter(ms)	Parameter type: <Sip::Jitter> - average of jitter for the termination - unit: millisec	average of jitter for this board in previous 1day interval. <i>This element is always shown.</i>
avgrtdelay(ms)	Parameter type: <Sip::RoundTripDelay> - average of round-trip delay for this termination - unit: millisec	average of round-trip delay for this board in previous 1day interval. <i>This element is always shown.</i>
maxjitter(ms)	Parameter type: <Sip::Jitter> - average of jitter for the termination - unit: millisec	peak inter-arrival for this board in previous 1day interval. <i>This element is always shown.</i>
maxrtdelay(ms)	Parameter type: <Sip::RoundTripDelay> - average of round-trip delay for this termination - unit: millisec	peak of round-trip delay for this board in previous 1day interval. <i>This element is always shown.</i>
avgjbflg711a(%)	Parameter type: <Sip::JBFL> - average of jitter buffer fill level percentage for the termination - unit: percentage - range: [0...100]	average of jitter buffer fill level encoded with G711_a percentage for this board in previous 1day interval. <i>This element is always shown.</i>
avgjbflg711u(%)	Parameter type: <Sip::JBFL>	average of jitter buffer fill level

name	Type	Description
	- average of jitter buffer fill level percentage for the termination - unit: percentage - range: [0...100]	encoded with G711_u percentage for this board in previous 1day interval. <i>This element is always shown.</i>
avgjbflg723(%)	Parameter type: <Sip::JBFL> - average of jitter buffer fill level percentage for the termination - unit: percentage - range: [0...100]	average of jitter buffer fill level encoded with G723 percentage for this board in previous 1day interval. <i>This element is always shown.</i>
avgjbflg729(%)	Parameter type: <Sip::JBFL> - average of jitter buffer fill level percentage for the termination - unit: percentage - range: [0...100]	average of jitter buffer fill level encoded with G729 percentage for this board in previous 1day interval. <i>This element is always shown.</i>
avgcpu(%)	Parameter type: <Sys::cpuloadaverage> - average load for the measurement period , expressed in percentage - unit: percentage - range: [0...100]	average the CPU load for this board in previous 1day interval. <i>This element is always shown.</i>
avgmemuse(%)	Parameter type: <Sys::memusageUtilization> - memory size - unit: Mbyte	average amount of semi and dynamic memory been used, expressed as a portion of the total memory for this board in previous 1day interval. <i>This element is always shown.</i>
avgmempoolfree(mb)	Parameter type: <Sys::memusageFree> - memory size - unit: Mbyte	average amount of free semi and dynamic memory for this board in previous 1day interval. <i>This element is always shown.</i>
avgmempooluse(mb)	Parameter type: <Sys::memusageAbsolute> - memory size - unit: Mbyte	average amount of semi and dynamic memory been used for this board in previous 1day interval. <i>This element is always shown.</i>
avgmempooltot(mb)	Parameter type: <Sys::totalMem> - memory size - unit: Mbyte	total amount memory on this board in previous 1day interval. <i>This element is always shown.</i>
spareports	Parameter type: <Sip::NumberOfTerm> - the number of termination	the number of unconfigured sip termination in this board at the end of previous 1day interval. <i>This element is always shown.</i>
actports	Parameter type: <Sip::NumberOfTerm> - the number of termination	the number of active sip termination in this board at the end of previous 1day interval. <i>This element is always shown.</i>
inactports	Parameter type: <Sip::NumberOfTerm> - the number of termination	the number of inactive sip termination (locked) in this board at the end of previous 1day interval. <i>This element is always shown.</i>
succregatt	Parameter type: <Sip::SignalCounter> - the counter of CMCC for signal statistics	Count the successful registration Num for whole board in previous 1 day interval <i>This element is always shown.</i>
failregatt	Parameter type: <Sip::SignalCounter> - the counter of CMCC for signal statistics	Count the failed registration Num for whole board in previous 1 day interval

151 Voice Status Commands

name	Type	Description
		<i>This element is always shown.</i>
activerег	Parameter type: <Sip::SignalCounter> - the counter of CMCC for signal statistics	Count the active Registration Status for whole board at the end of previous 1 day interval <i>This element is always shown.</i>
outcallconn	Parameter type: <Sip::SignalCounter> - the counter of CMCC for signal statistics	Answered out-going call count for whole board in previous 1 day interval <i>This element is always shown.</i>
incallconn	Parameter type: <Sip::SignalCounter> - the counter of CMCC for signal statistics	Answered incoming call count for whole board in previous 1 day interval <i>This element is always shown.</i>
timestamp	Parameter type: <Sip::SipTimeInSecs> - the time (yyyy-mm-dd:hour:minutes:secs)	specifies the start time for this board in previous 1 day interval <i>This element is always shown.</i>

151.14 Voice Sip Board Statistics Command for Current 15 Minutes

Command Description

This command allows the operator to show the Voice Sip Board Statistics for current 15 minutes.

User Level

The command can be accessed by operators with sip privileges.

Command Syntax

The command has the following syntax:

```
> show voice sip statistics board current-15min [ (slot-id) ]
```

Command Parameters

Table 151.14-1 "Voice Sip Board Statistics Command for Current 15 Minutes" Resource Parameters

Resource Identifier	Type	Description
(slot-id)	Format: (lt : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> nt-a nt-b nt <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::EqSlotId>) Possible values: - lt : lt-slot - nt-a : nt-a slot - nt-b : nt-b slot - nt : nt slot Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::EqSlotId> - the equipment slot number	interface index of this LT board

Command Output

Table 151.14-2 "Voice Sip Board Statistics Command for Current 15 Minutes" Display parameters

151 Voice Status Commands

Specific Information		
name	Type	Description
meastime(s)	Parameter type: <Sip::IntervalMeasureTime> - the measured time of interval - unit: sec	amount of time in sec that statistics have been counted <i>This element is only shown in detail mode.</i>
invalidflag	Parameter type: <Sip::IntervalValidityFlag> (true false) Possible values: - true : data is not valid - false : data is valid	validity of the corresponding performance monitoring data in current 15m interval <i>This element is always shown.</i>
sentrtppkts	Parameter type: <Counter> - 32 bit counter	number of rtp packets transmitted by this board in current 15m interval <i>This element is always shown.</i>
sentoct	Parameter type: <Counter> - 32 bit counter	number of rtp octets transmitted by this board in current 15m interval <i>This element is always shown.</i>
recvrtpkts	Parameter type: <Counter> - 32 bit counter	number of rtp packets received by this board in current 15m interval <i>This element is always shown.</i>
recvoct	Parameter type: <Counter> - 32 bit counter	number of rtp octets received by this board in current 15m interval <i>This element is always shown.</i>
lostrtpkts	Parameter type: <Sip::LostPackets> - the number of lost rtp packets	number of lost receiving RTP packets for this board in current 15m interval <i>This element is always shown.</i>
avgjbfl(%)	Parameter type: <Sip::JBFL> - average of jitter buffer fill level percentage for the termination - unit: percentage - range: [0...100]	average of jitter buffer fill level percentage for this board in current 15m interval. <i>This element is always shown.</i>
avgjitter(ms)	Parameter type: <Sip::Jitter> - average of jitter for the termination - unit: millisec	average of jitter for this board in current 15m interval. <i>This element is always shown.</i>
avgrtdelay(ms)	Parameter type: <Sip::RoundTripDelay> - average of round-trip delay for this termination - unit: millisec	average of round-trip delay for this board in current 15m interval. <i>This element is always shown.</i>
maxjitter(ms)	Parameter type: <Sip::Jitter> - average of jitter for the termination - unit: millisec	peak inter-arrival for this board in current 15m interval <i>This element is always shown.</i>
maxrtdelay(ms)	Parameter type: <Sip::RoundTripDelay> - average of round-trip delay for this termination - unit: millisec	peak of round-trip delay for this board in current 15m interval. <i>This element is always shown.</i>
avgjbflg711a(%)	Parameter type: <Sip::JBFL> - average of jitter buffer fill level percentage for the termination - unit: percentage - range: [0...100]	average of jitter buffer fill level encoded with G711_a percentage for this board in current 15m interval. <i>This element is always shown.</i>
avgjbflg711u(%)	Parameter type: <Sip::JBFL> - average of jitter buffer fill level percentage for the termination - unit: percentage	average of jitter buffer fill level encoded with G711_u percentage for this board in current 15m interval.

name	Type	Description
	- range: [0...100]	<i>This element is always shown.</i>
avgjbflg723(%)	Parameter type: <Sip::JBFL> - average of jitter buffer fill level percentage for the termination - unit: percentage - range: [0...100]	average of jitter buffer fill level encoded with G723 percentage for this board in current 15m interval. <i>This element is always shown.</i>
avgjbflg729(%)	Parameter type: <Sip::JBFL> - average of jitter buffer fill level percentage for the termination - unit: percentage - range: [0...100]	average of jitter buffer fill level encoded with G729 percentage for this board in current 15m interval. <i>This element is always shown.</i>
avgcpu(%)	Parameter type: <Sys::cpuloadaverage> - average load for the measurement period , expressed in percentage - unit: percentage - range: [0...100]	average the CPU load for this board in current 15m interval. <i>This element is always shown.</i>
avgmemuse(%)	Parameter type: <Sys::memusageUtilization> - memory size - unit: Mbyte	average amount of semi and dynamic memory been used, expressed as a portion of the total memory for this board in current 15m interval. <i>This element is always shown.</i>
avgmempoolfree(mb)	Parameter type: <Sys::memusageFree> - memory size - unit: Mbyte	average amount of free semi and dynamic memory for this board in current 15m interval. <i>This element is always shown.</i>
avgmempooluse(mb)	Parameter type: <Sys::memusageAbsolute> - memory size - unit: Mbyte	average amount of semi and dynamic memory been used for this board in current 15m interval. <i>This element is always shown.</i>
avgmempooltot(mb)	Parameter type: <Sys::totalMem> - memory size - unit: Mbyte	total amount memory on this board in current 15m interval. <i>This element is always shown.</i>
spareports	Parameter type: <Sip::NumberOfTerm> - the number of termination	the number of unconfigured sip termination in this board at the end of current 15m interval. <i>This element is always shown.</i>
actports	Parameter type: <Sip::NumberOfTerm> - the number of termination	the number of active sip termination in this board at the end of current 15m interval. <i>This element is always shown.</i>
inactports	Parameter type: <Sip::NumberOfTerm> - the number of termination	the number of inactive sip termination (locked) in this board at the end of current 15m interval. <i>This element is always shown.</i>
succregatt	Parameter type: <Sip::SignalCounter> - the counter of CMCC for signal statistics	Count the successful registration Num for whole board in current 15 minutes interval <i>This element is always shown.</i>
failregatt	Parameter type: <Sip::SignalCounter> - the counter of CMCC for signal statistics	Count the failed registration Num for whole board in current 15 minutes interval <i>This element is always shown.</i>
activerereg	Parameter type: <Sip::SignalCounter> - the counter of CMCC for signal statistics	Count the active Registration Status for whole board at the end

151 Voice Status Commands

name	Type	Description
		of current 15 minutes interval <i>This element is always shown.</i>
outcallconn	Parameter type: <Sip::SignalCounter> - the counter of CMCC for signal statistics	Answered out-going call count for whole board in current 15 minutes interval <i>This element is always shown.</i>
incallconn	Parameter type: <Sip::SignalCounter> - the counter of CMCC for signal statistics	Answered incoming call count for whole board in current 15 minutes interval <i>This element is always shown.</i>
actconn	Parameter type: <Sip::NumberOfTerm> - the number of termination	The amount of Number of active connections in current 15 minutes interval <i>This element is always shown.</i>
brokenports	Parameter type: <Sip::NumberOfTerm> - the number of termination	The amount of Number of broken ports in current 15 minutes interval <i>This element is always shown.</i>
portregdur(s)	Parameter type: <Sip::StatsBoardTime> - Time duration for statics sip board. - unit: second - range: [0...6220800]	Sum of seconds of subscriber connection successfully registered by this board in current 15 minutes interval <i>This element is always shown.</i>
portavaildur(s)	Parameter type: <Sip::StatsBoardTime> - Time duration for statics sip board. - unit: second - range: [0...6220800]	Sum of seconds of the port is created without the periods where the port is unavailable by this board in current 15 minutes interval <i>This element is always shown.</i>

151.15 Voice Sip Board Statistics Command for Previous 15 Minutes

Command Description

This command allows the operator to show the Voice Sip Board Statistics for previous 15 minutes.

User Level

The command can be accessed by operators with sip privileges.

Command Syntax

The command has the following syntax:

```
> show voice sip statistics board prev-15min [ (slot-id) [ interval-num <Sip::IntervalNumber15min> ] ]
```

Command Parameters

Table 151.15-1 "Voice Sip Board Statistics Command for Previous 15 Minutes" Resource Parameters

Resource Identifier	Type	Description
(slot-id)	Format: (lt : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> nt-a nt-b nt <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::EqSlotId>) Possible values: - lt : lt-slot - nt-a : nt-a slot - nt-b : nt-b slot - nt : nt slot Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::EqSlotId> - the equipment slot number	interface index of this LT board
interval-num	Parameter type: <Sip::IntervalNumber15min> Format: - the measured time interval - range: [1...96]	identifies prev 15min intervals, value 1 as the latest interval

Command Output

Table 151.15-2 "Voice Sip Board Statistics Command for Previous 15 Minutes" Display parameters

Specific Information		
name	Type	Description
timestamp	Parameter type: <Sip::SipTimeInSecs> - the time (yyyy-mm-dd:hour:minutes:secs)	specifies the start time for this board in previous 15 minutes interval <i>This element is always shown.</i>
meastime(s)	Parameter type: <Sip::IntervalMeasureTime> - the measured time of interval - unit: sec	amount of time in sec that statistics have been counted <i>This element is only shown in detail mode.</i>
invalidflag	Parameter type: <Sip::IntervalValidityFlag> (true false) Possible values: - true : data is not valid - false : data is valid	validity of the corresponding performance monitoring data in previous 15m interval <i>This element is always shown.</i>
sentrtppkts	Parameter type: <Counter> - 32 bit counter	number of rtp packets transmitted by this board in previous 15m interval <i>This element is always shown.</i>
sentoct	Parameter type: <Counter> - 32 bit counter	number of rtp octets transmitted by this board in previous 15m interval <i>This element is always shown.</i>
recvrtpkts	Parameter type: <Counter> - 32 bit counter	number of rtp packets received by this board in previous 15m interval <i>This element is always shown.</i>
recvoct	Parameter type: <Counter> - 32 bit counter	number of rtp octets received by this board in previous 15m interval <i>This element is always shown.</i>
lostrtpkts	Parameter type: <Sip::LostPackets> - the number of lost rtp packets	number of lost receiving RTP packets for this board in previous 15m interval <i>This element is always shown.</i>
avgjbf(%)	Parameter type: <Sip::JBFL> - average of jitter buffer fill level percentage for the termination - unit: percentage - range: [0...100]	average of jitter buffer fill level percentage for this board in previous 15m interval. <i>This element is always shown.</i>
avgjitter(ms)	Parameter type: <Sip::Jitter> - average of jitter for the termination - unit: millisec	average of jitter for this board in previous 15m interval. <i>This element is always shown.</i>
avgrtdelay(ms)	Parameter type: <Sip::RoundTripDelay> - average of round-trip delay for this termination - unit: millisec	average of round-trip delay for this board in previous 15m interval. <i>This element is always shown.</i>
maxjitter(ms)	Parameter type: <Sip::Jitter> - average of jitter for the termination - unit: millisec	peak inter-arrival for this board in previous 15m interval <i>This element is always shown.</i>
maxrtdelay(ms)	Parameter type: <Sip::RoundTripDelay> - average of round-trip delay for this termination	peak of round-trip delay for this board in previous 15m interval.

name	Type	Description
	- unit: millisec	<i>This element is always shown.</i>
avgjbflg711a(%)	Parameter type: <Sip::JBFL> - average of jitter buffer fill level percentage for the termination - unit: percentage - range: [0...100]	average of jitter buffer fill level encoded with G711_a percentage for this board in previous 15m interval. <i>This element is always shown.</i>
avgjbflg711u(%)	Parameter type: <Sip::JBFL> - average of jitter buffer fill level percentage for the termination - unit: percentage - range: [0...100]	average of jitter buffer fill level encoded with G711_u percentage for this board in previous 15m interval. <i>This element is always shown.</i>
avgjbflg723(%)	Parameter type: <Sip::JBFL> - average of jitter buffer fill level percentage for the termination - unit: percentage - range: [0...100]	average of jitter buffer fill level encoded with G723 percentage for this board in previous 15m interval. <i>This element is always shown.</i>
avgjbflg729(%)	Parameter type: <Sip::JBFL> - average of jitter buffer fill level percentage for the termination - unit: percentage - range: [0...100]	average of jitter buffer fill level encoded with G729 percentage for this board in previous 15m interval. <i>This element is always shown.</i>
avgcpu(%)	Parameter type: <Sys::cpuloadaverage> - average load for the measurement period , expressed in percentage - unit: percentage - range: [0...100]	average the CPU load for this board in previous 15m interval. <i>This element is always shown.</i>
avgmemuse(%)	Parameter type: <Sys::memusageUtilization> - memory size - unit: Mbyte	average amount of semi and dynamic memory been used, expressed as a portion of the total memory for this board in previous 15m interval. <i>This element is always shown.</i>
avgmempoolfree(mb)	Parameter type: <Sys::memusageFree> - memory size - unit: Mbyte	average amount of free semi and dynamic memory for this board in previous 15m interval. <i>This element is always shown.</i>
avgmempooluse(mb)	Parameter type: <Sys::memusageAbsolute> - memory size - unit: Mbyte	average amount of semi and dynamic memory been used for this board in previous 15m interval. <i>This element is always shown.</i>
avgmempooltot(mb)	Parameter type: <Sys::totalMem> - memory size - unit: Mbyte	total amount memory on this board in previous 15m interval. <i>This element is always shown.</i>
spareports	Parameter type: <Sip::NumberOfTerm> - the number of termination	the number of unconfigured sip termination in this board at the end of previous 15m interval. <i>This element is always shown.</i>
actports	Parameter type: <Sip::NumberOfTerm> - the number of termination	the number of active sip termination in this board at the end of previous 15m interval. <i>This element is always shown.</i>
inactports	Parameter type: <Sip::NumberOfTerm> - the number of termination	the number of inactive sip termination (locked) in this board at the end of previous 15m interval. <i>This element is always shown.</i>

151 Voice Status Commands

name	Type	Description
succregatt	Parameter type: <Sip::SignalCounter> - the counter of CMCC for signal statistics	Count the successful registration Num for whole board in previous 15 minutes interval <i>This element is always shown.</i>
failregatt	Parameter type: <Sip::SignalCounter> - the counter of CMCC for signal statistics	Count the failed registration Num for whole board in previous 15 minutes interval <i>This element is always shown.</i>
activerereg	Parameter type: <Sip::SignalCounter> - the counter of CMCC for signal statistics	Count the active Registration Status for whole board at the end of previous 15 minutes interval <i>This element is always shown.</i>
outcallconn	Parameter type: <Sip::SignalCounter> - the counter of CMCC for signal statistics	Answered out-going call count for whole board in previous 15 minutes interval <i>This element is always shown.</i>
incallconn	Parameter type: <Sip::SignalCounter> - the counter of CMCC for signal statistics	Answered incoming call count for whole board in previous 15 minutes interval <i>This element is always shown.</i>
actconn	Parameter type: <Sip::NumberOfTerm> - the number of termination	The amount of Number of active connections in previous 15 minutes interval <i>This element is always shown.</i>
brokenports	Parameter type: <Sip::NumberOfTerm> - the number of termination	The amount of Number of broken ports in previous 15 minutes interval <i>This element is always shown.</i>
portregdur(s)	Parameter type: <Sip::StatsBoardTime> - Time duration for statics sip board. - unit: second - range: [0...6220800]	Sum of seconds of subscriber connection successfully registered by this board in previous 15 minutes interval <i>This element is always shown.</i>
portavaildur(s)	Parameter type: <Sip::StatsBoardTime> - Time duration for statics sip board. - unit: second - range: [0...6220800]	Sum of seconds of the port is created without the periods where the port is unavailable by this board in previous 15 minutes interval <i>This element is always shown.</i>

151.16 Voice Sip Statistics Perfinfo Status

Command per board

Command Description

This command allows the operator to show the various parameters including elapsed times for current 15-minutes interval and 1-day interval per Board, the number of pervious 15-minutes interval and 1-day interval per Board

User Level

The command can be accessed by operators with forStatsPerBoard privileges.

Command Syntax

The command has the following syntax:

```
> show voice sip statistics board-perfinfo [ (slot-id) ]
```

Command Parameters

Table 151.16-1 "Voice Sip Statistics Perfinfo Status Command per board" Resource Parameters

Resource Identifier	Type	Description
(slot-id)	Format: (lt : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> nt-a nt-b nt <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::EqSlotId>) Possible values: - lt : lt-slot - nt-a : nt-a slot - nt-b : nt-b slot - nt : nt slot Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::EqSlotId> - the equipment slot number	interface index of this LT board.

Command Output

Table 151.16-2 "Voice Sip Statistics Perfinfo Status Command per board" Display parameters

151 Voice Status Commands

Specific Information		
name	Type	Description
cur-15min-elapsedtime	Parameter type: <Sip::ElapsedTime> - the elapsed time - unit: sec	number of second elapsed in current 15 minutes interval measurement <i>This element is always shown.</i>
cur-1day-elapsedtime	Parameter type: <Sip::ElapsedTime> - the elapsed time - unit: sec	number of second elapsed in current 1 day interval measurement <i>This element is always shown.</i>
pre-15min-num	Parameter type: <Sip::PerfInterval> - the number of interval	number of previous 15 minutes interval <i>This element is always shown.</i>
pre-1days-num	Parameter type: <Sip::PerfInterval> - the number of interval	number of previous 1 day interval <i>This element is always shown.</i>

151.17 Voice Sip restoration: Redundancy Status Commands

Command Description

This command allows the operator to show the Voice Sip restoration, Redundancy status.

User Level

The command can be accessed by operators with sip privileges.

Command Syntax

The command has the following syntax:

```
> show voice sip redundancy-node redundancy-state [ (admin-name) [ slot-id <SIP::SlotIndex> ] ]
```

Command Parameters

Table 151.17-1 "Voice Sip restoration: Redundancy Status Commands" Resource Parameters

Resource Identifier	Type	Description
(admin-name)	Format: - uniquely name of this element - length: x<=32	The name of the administrative domain that hosts the redundancy group.
slot-id	Parameter type: <SIP::SlotIndex> Format: (lt : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> nt ntio <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::EqSlotId>) Possible values: - lt : lt-slot - nt : nt-slot - ntio : ntio-slot Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::EqSlotId> - the equipment slot number	slot id associated with redundancy state.

Command Output

Table 151.17-2 "Voice Sip restoration: Redundancy Status Commands" Display parameters

Specific Information		
name	Type	Description
state	Parameter type: <Sip::netwRedunState> (connect-primary connect-geo-back connect-sos-back server-fo-ongoing server-fb-ongoing geo-fo-ongoing geo-fb-ongoing sos-fo-ongoing sos-fb-ongoing deli-upd-ongoing) Possible values: - connect-primary : Redundancy state :connect-primary - connect-geo-back : Redundancy state : connect-geo-back - connect-sos-back : Redundancy state : connect-sos-back - server-fo-ongoing : Redundancy state :sip-server-fail-over-ongoing - server-fb-ongoing : Redundancy state :sip-server-fail-back-ongoing - geo-fo-ongoing : Redundancy state : geo-fail-over-ongoing - geo-fb-ongoing : Redundancy state :geo-fail-back-ongoing - sos-fo-ongoing : Redundancy state : sos-fail-over-ongoing - sos-fb-ongoing : Redundancy state : sos-fail-back-ongoing - deli-upd-ongoing : Redundancy state : deliberate-update-ongoing	State:connected-to-primary(1),connected-to-geo-back(1),connected-to-sos-back(1) <i>This element is always shown.</i>

151.18 Voice Sip restoration: Redundancy Status Commands

Command Description

This command allows the operator to show the Voice Sip restoration, Redundancy status.

User Level

The command can be accessed by operators with sip privileges.

Command Syntax

The command has the following syntax:

```
> show voice sip redundancy-node ext-redundancy-state [ (admin-name) [ slot-id <SIP::SlotIndex> ] [ term-group <SIP::sipIsdnCasTerminationGroupID> ] ]
```

Command Parameters

Table 151.18-1 "Voice Sip restoration: Redundancy Status Commands" Resource Parameters

Resource Identifier	Type	Description
(admin-name)	Format: - uniquely name of this element - length: x<=32	The name of the administrative domain that hosts the redundancy group.
slot-id	Parameter type: <SIP::SlotIndex> Format: (lt : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> nt ntio <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::EqSlotId>) Possible values: - lt : lt-slot - nt : nt-slot - ntio : ntio-slot Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::EqSlotId> - the equipment slot number	slot id associated with redundancy state.
term-group	Parameter type: <SIP::sipIsdnCasTerminationGroupID> Format: - the termination group termination belongs to - range: [0...300]	termination group associated with redundancy state.

Command Output

Table 151.18-2 "Voice Sip restoration: Redundancy Status Commands" Display parameters

Specific Information		
name	Type	Description
state	Parameter type: <Sip::netwRedunNewState> (connect-primary connect-geo-back connect-sos-back server-fo-ongoing server-fb-ongoing geo-fo-ongoing geo-fb-ongoing sos-fo-ongoing sos-fb-ongoing deli-upd-ongoing deli-upd-ongoing-bu server-fo-ongoing-bu server-fb-ongoing-bu) Possible values: - connect-primary : Redundancy state :connect-primary - connect-geo-back : Redundancy state : connect-geo-back - connect-sos-back : Redundancy state : connect-sos-back - server-fo-ongoing : Redundancy state :sip-server-fail-over-ongoing - server-fb-ongoing : Redundancy state : sip-server-fail-back-ongoing - geo-fo-ongoing : Redundancy state : geo-fail-over-ongoing - geo-fb-ongoing : Redundancy state :geo-fail-back-ongoing - sos-fo-ongoing : Redundancy state : sos-fail-over-ongoing - sos-fb-ongoing : Redundancy state : sos-fail-back-ongoing - deli-upd-ongoing : Redundancy state : deliberate-update-ongoing - deli-upd-ongoing-bu : Redundancy state : deliberate-update-ongoing-bu - server-fo-ongoing-bu : Redundancy state :sip-server-fail-over-ongoing-bu - server-fb-ongoing-bu : Redundancy state : sip-server-fail-back-ongoing-bu	State:connected-to-primary(1),connected-to-geo-back(1),connected-to-sos-back(1) <i>This element is always shown.</i>
sip-server-address	Parameter type: <Sip::sipServerAddr> - name of the SipServer that can be resolved to an IP address via a DNS Server - length: 7<=x<=64	the SIP server termination registered to <i>This element is always shown.</i>

151.19 Voice Sip Redundancy Status Commands

Command Description

This command allows the operator to show the Voice Sip Redundancy status.

User Level

The command can be accessed by operators with sip privileges.

Command Syntax

The command has the following syntax:

> show voice sip redundancy-node redundancy-cmd [(provider-name)]

Command Parameters

Table 151.19-1 "Voice Sip Redundancy Status Commands" Resource Parameters

Resource Identifier	Type	Description
(provider-name)	Format: - uniquely identifies the transport provider name - length: x<=32	uniquely identify provider name

Command Output

Table 151.19-2 "Voice Sip Redundancy Status Commands" Display parameters

Specific Information		
name	Type	Description
progress	Parameter type: <Sip::FailXProgress> (not-started running successful-completed failed) Possible values: - not-started : geo fo/fb not started - running : geo fo/fb is ongoing - successful-completed : geo fo/fb complete and successful - failed : geo fo/fb failed	Fail X progress <i>This element is always shown.</i>
result	Parameter type: <Sip::FailXResult> - Fail X result. - length: x<=32	Fail X result. <i>This element is always shown.</i>

151.20 Voice Sip Termination Status Commands

Command Description

This command allows the operator to show the Voice Sip termination profile.

User Level

The command can be accessed by operators with sip privileges.

Command Syntax

The command has the following syntax:

> show voice sip termination [(if-index)]

Command Parameters

Table 151.20-1 "Voice Sip Termination Status Commands" Resource Parameters

Resource Identifier	Type	Description
(if-index)	Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number	The unique internal identifier of the termination port

Command Output

Table 151.20-2 "Voice Sip Termination Status Commands" Display parameters

Specific Information		
name	Type	Description
contact-user-info	Parameter type: <SIP::SipTerminationContact> - The user-info of contact field in SIP message associated with the user - length: 1<=x<=128	The user-info of contact field in SIP message associated with the user <i>This element is always shown.</i>
oper-status	Parameter type: <Sip::TermOperStatus> (up down) Possible values: - up : the status of the termination opera is up - down : the status of the termination is down	the operational status of application server <i>This element is always shown.</i>

name	Type	Description
operstatus-downreason	Parameter type: <Sip::TermOpDownReason> (registering registrationfailure physicalfailure admin-status-down unknown) Possible values: - : the term opera status down reason is none - registering : the term opera status down reason is registering - registrationfailure : the term opera status down reason is registration failure - physicalfailure : the term opera status down reason is physical failure - admin-status-down : the term opera status down reason is termination admin status down - unknown : the term opera status down reason is LT down or IOCM communication failure	the reason of operational status of application server is down <i>This element is always shown.</i>
call-status	Parameter type: <Sip::TermCallStatus> (unknown on-hook off-hook dialing calling connected idle-offhook ringing releasing ringback shared-cutoff) Possible values: - unknown : the call status is unknown - on-hook : the call status is on-hook - off-hook : the call status is off-hook - dialing : the call status is dialing - calling : the call status is calling - connected : the call status is connected - idle-offhook : the call status is idle-offhook - ringing : the call status is ringing - releasing : the call status is releasing - ringback : the call status is ringback - shared-cutoff : the call status is shared-cutoff	the call status of a termination <i>This element is always shown.</i>
test-status	Parameter type: <Sip::TermTestStatus> (no-testing mta-testing ilt-testing) Possible values: - no-testing : the termination is not under testing - mta-testing : the termination is under mta testing - ilt-testing : the termination is under integrated line testing	the test status of a termination <i>This element is always shown.</i>
termination-group	Parameter type: <Sip::sipTerminationGroupID> - the termination group termination belongs to - range: [0...72]	the group termination belongs to <i>This element is always shown.</i>
sip-server-address	Parameter type: <Sip::sipServerAddr> - name of the SipServer that can be resolved to an IP address via a DNS Server	the SIP server termination registered to <i>This element is always shown.</i>

151 Voice Status Commands

name	Type	Description
	- length: 7<=x<=64	
testaccess-state	Parameter type: <Sip::TestAccessState> (on off) Possible values: - on : turn on TestAccessState - off : turn off TestAccessState	test access status <i>This element is always shown.</i>
busyoverwrite	Parameter type: <Sip::TestAccessBusyOverWrite> (true false) Possible values: - true : enable TestAccessBusyOverWrite parameter - false : disable TestAccessBusyOverWrite parameter	test access busyoverwrite status <i>This element is always shown.</i>
accesson-timeout	Parameter type: <Sip::TestAccessonTimeout> - value of test access on expires. - unit: second - range: [0...900]	test access statatus on timeout value <i>This element is always shown.</i>
provider-name	Parameter type: <Sip::TermUserProviderName> - identify the user VSG name for this port - length: x<=32	the user VSG name for this termination port <i>This element is always shown.</i>

151.21 Voice Sip Shared Line Termination Status Commands

Command Description

This command allows the operator to show the Voice Sip shared line termination profile.

User Level

The command can be accessed by operators with sip privileges.

Command Syntax

The command has the following syntax:

```
> show voice sip sharedline [ (if-index) ]
```

Command Parameters

Table 151.21-1 "Voice Sip Shared Line Termination Status Commands" Resource Parameters

Resource Identifier	Type	Description
(if-index)	Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number	The unique internal identifier of the termination port

Command Output

Table 151.21-2 "Voice Sip Shared Line Termination Status Commands" Display parameters

Specific Information		
name	Type	Description
contact-user-info	Parameter type: <SIP::SipTerminationContact> - The user-info of contact field in SIP message associated with the user - length: 1<=x<=128	The user-info of contact field in SIP message associated with the user <i>This element is always shown.</i>
oper-status	Parameter type: <Sip::TermOperStatus> (up down)	the operational status of a termination <i>This element is always shown.</i>

151 Voice Status Commands

name	Type	Description
	Possible values: - up : the status of the termination opera is up - down : the status of the termination is down	
call-status	Parameter type: <Sip::TermCallStatus> (unknown on-hook off-hook dialing calling connected idle-offhook ringing releasing ringback shared-cutoff) Possible values: - unknown : the call status is unknown - on-hook : the call status is on-hook - off-hook : the call status is off-hook - dialing : the call status is dialing - calling : the call status is calling - connected : the call status is connected - idle-offhook : the call status is idle-offhook - ringing : the call status is ringing - releasing : the call status is releasing - ringback : the call status is ringback - shared-cutoff : the call status is shared-cutoff	the call status of a termination <i>This element is always shown.</i>

151.22 Voice Sip Isdn/Cas Termination Status Commands

Command Description

this command allows the operator to show the Voice sip isdn/Cas termination profile.

User Level

The command can be accessed by operators with sip privileges.

Command Syntax

The command has the following syntax:

```
> show voice sip isdn-cas-term [ (if-index) ]
```

Command Parameters

Table 151.22-1 "Voice Sip Isdn/Cas Termination Status Commands" Resource Parameters

Resource Identifier	Type	Description
(if-index)	Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number	The unique internal identifier of the termination port

Command Output

Table 151.22-2 "Voice Sip Isdn/Cas Termination Status Commands" Display parameters

Specific Information		
name	Type	Description
contact-user-info	Parameter type: <SIP::SipTerminationContact> - The user-info of contact field in SIP message associated with the user - length: 1<=x<=128	The user-info of contact field in SIP message associated with the user <i>This element is always shown.</i>
oper-status	Parameter type: <Sip::IsdnCasTermOperStatus> (up down)	The operational status of a termination <i>This element is always shown.</i>

151 Voice Status Commands

name	Type	Description
	Possible values: - up : The GDN-EXT has successfully registered - down : The GDN-EXT's operational status is down	
operstatus-downreason	Parameter type: <Sip::IsdnCasTermOpDownReason> (registering registrationfailure admin-status-down unknown noregsipserveroos) Possible values: - : The operational status of the GDN-EXT is UP - registering : The operational state of the GDN-EXT is DOWN; Reason: The GDN-EXT's registration is in progress. - registrationfailure : The operational state of the GDN-EXT is DOWN; Reason: The GDN-EXT's registration has failed. - admin-status-down : The operational state of the GDN-EXT is DOWN; Reason: termination admin status is down. - unknown : The operational state of the GDN-EXT is DOWN; Reason: LT is down or IOCM communication failure. - noregsipserveroos : The operational state of the GDN-EXT is DOWN; Reason: The First hop SIP server is not reachable anymore (redundancy = disabled) or none of the First hop servers are reachable (redundancy = enabled).	The detailed down reason when operational status is down <i>This element is always shown.</i>
test-status	Parameter type: <Sip::IsdnCasTermTestStatus> (no-testing ilt-testing loopback-testing loopback-envset) Possible values: - no-testing : the termination is not under testing - ilt-testing : the termination is under integrated line testing - loopback-testing : the PRA ISDN SIP termination is under local, single or cable loopback testing - loopback-envset : the PRA ISDN SIP termination has finished the remote or payload loop back environment configuration	The test status of a termination <i>This element is always shown.</i>
termination-group	Parameter type: <SIP::sipIsdnCasTerminationGroupID> - the termination group termination belongs to - range: [0...300]	The group termination belongs to <i>This element is always shown.</i>
sip-server-address	Parameter type: <Sip::sipServerAddr> - name of the SipServer that can be resolved to an IP address via a DNS Server - length: 7<=x<=64	The SIP server termination registered to <i>This element is always shown.</i>
testaccess-state	Parameter type: <Sip::TestAccessState> (on off) Possible values: - on : turn on TestAccessState - off : turn off TestAccessState	Test access status <i>This element is always shown.</i>
busyoverwrite	Parameter type: <Sip::TestAccessBusyOverWrite> (true false) Possible values:	Test access busyoverwrite status <i>This element is always shown.</i>

name	Type	Description
	- true : enable TestAccessBusyOverWrite parameter - false : disable TestAccessBusyOverWrite parameter	
accesson-timeout	Parameter type: <Sip::TestAccessonTimeout> - value of test access on expires. - unit: second - range: [0...900]	Test access statatus on timeout value <i>This element is always shown.</i>
b-channel-idle	Parameter type: <Sip::BChannelNumber> - value of bearer channel number for isdn-cas-term - range: [0...240]	Number of idle b-channel for this isdn Primary Rate Interface <i>This element is always shown.</i>
b-channel-used	Parameter type: <Sip::BChannelNumber> - value of bearer channel number for isdn-cas-term - range: [0...240]	Number of used b-channel for this isdn Primary Rate Interface <i>This element is always shown.</i>
b-channel-oos	Parameter type: <Sip::BChannelNumber> - value of bearer channel number for isdn-cas-term - range: [0...240]	Number of Out of service b-channel for this isdn Primary Rate Interface <i>This element is always shown.</i>
provider-name	Parameter type: <Sip::TermUserProviderName> - identify the user VSG name for this port - length: x<=32	The user VSG name for this termination port <i>This element is always shown.</i>
signalling-type	Parameter type: <Sip::TermSignallingType> (isdn-pra cas-r2) Possible values: - isdn-pra : set signalling type to ISDN PRA - cas-r2 : set signalling type to CAS R2	Identify the signalling type for this termination port <i>This element is always shown.</i>
e1-cluster-name	Parameter type: <Sip::IsdnCasTerminationE1ClusterName> - Name of the E1 cluster - length: x<=32	Name of the E1 cluster <i>This element is always shown.</i>
puids	Parameter type: <Sip::IsdnCasTermPuids> - identify the user puids for this port - length: x<=2560	Implicitly registered aors of this termination <i>This element is only shown in detail mode.</i>

151.23 Voice Sip Port State Status Commands

Command Description

This command allows the operator to show the Voice Sip Port State

User Level

The command can be accessed by operators with sip privileges.

Command Syntax

The command has the following syntax:

> show voice sip port-state [(if-index)]

Command Parameters

Table 151.23-1 "Voice Sip Port State Status Commands" Resource Parameters

Resource Identifier	Type	Description
(if-index)	Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number	The unique internal identifier of the termination port.

Command Output

Table 151.23-2 "Voice Sip Port State Status Commands" Display parameters

Specific Information		
name	Type	Description
port-state	Parameter type: <Sip::TermPortState> - identify the state for this port - length: x<=63	the operational status of application server <i>This element is always shown.</i>

151.24 Voice Sip SSP Profile Status Commands

Command Description

This command allows the operator to show the Voice Sip SSP Profile.

User Level

The command can be accessed by operators with sip privileges.

Command Syntax

The command has the following syntax:

> show voice sip sspprofile [(sspprofile-id)]

Command Parameters

Table 151.24-1 "Voice Sip SSP Profile Status Commands" Resource Parameters

Resource Identifier	Type	Description
(sspprofile-id)	Format: - ID of the SSP profile as present in the downloaded and activated CDE file - range: [1...16]	ID of the SSP profile as present in the downloaded and activated CDE file

Command Output

Table 151.24-2 "Voice Sip SSP Profile Status Commands" Display parameters

Specific Information		
name	Type	Description
sspprofile-name	Parameter type: <Sip::SSPProfileName> - Name of the SSP profile as present in the downloaded and activated CDE file - length: x<=64	Name of the SSP profile as present in the downloaded and activated CDE file <i>This element is always shown.</i>
sspprofile-description	Parameter type: <Sip::SSPProfileDescription> - Description of the SSP profile as present in the downloaded and activated CDE file - length: x<=64	Description of the SSP profile as present in the downloaded and activated CDE file <i>This element is always shown.</i>

151.25 Voice Sip Dhcp Sip Server Status Commands

Command Description

This command allows the operator to show the Voice Sip Dhcp Sip Server.

User Level

The command can be accessed by operators with sip privileges.

Command Syntax

The command has the following syntax:

```
> show voice sip dhcpsipserver [ (vsp-name) ]
```

Command Parameters

Table 151.25-1 "Voice Sip Dhcp Sip Server Status Commands" Resource Parameters

Resource Identifier	Type	Description
(vsp-name)	Format: - uniquely identify of this SIP voice service gateway - length: x<=32	uniquely identify of the vsp name

Command Output

Table 151.25-2 "Voice Sip Dhcp Sip Server Status Commands" Display parameters

Specific Information		
name	Type	Description
srv1-addr	Parameter type: <Sip::ServerAddr> (ipv4 : <Ip::V4Address> ipv6 : <Ip::V6Address> dns : <Sip::ServerAddr>) Possible values: - ipv4 : the address type of the server is IPv4 - ipv6 : the address type of the server is IPv6 - dns : the address type of the server is DNS Field type <Ip::V4Address> - IPv4-address Field type <Ip::V6Address> - IPv6-address Field type <Sip::ServerAddr> - name of the SipServer that can be resolved to an IP address via a DNS Server	the operational address of server <i>This element is always shown.</i>

name	Type	Description
	- length: 7<=x<=64	
srv1-priority	Parameter type: <Sip::ServerPriority> - the SIP server priority - range: [0...65535]	server idr <i>This element is always shown.</i>
srv1-oper-status	Parameter type: <Sip::ServerOperStatus> (up down) Possible values: - up : the status of the server opera is up - down : the status of the server opera is down	the operational status of server <i>This element is only shown in detail mode.</i>
srv2-addr	Parameter type: <Sip::ServerAddr> (ipv4 : <Ip::V4Address> ipv6 : <Ip::V6Address> dns : <Sip::ServerAddr>) Possible values: - ipv4 : the address type of the server is IPv4 - ipv6 : the address type of the server is IPv6 - dns : the address type of the server is DNS Field type <Ip::V4Address> - IPv4-address Field type <Ip::V6Address> - IPv6-address Field type <Sip::ServerAddr> - name of the SipServer that can be resolved to an IP address via a DNS Server - length: 7<=x<=64	the operational address of server <i>This element is always shown.</i>
srv2-priority	Parameter type: <Sip::ServerPriority> - the SIP server priority - range: [0...65535]	server idr <i>This element is always shown.</i>
srv2-oper-status	Parameter type: <Sip::ServerOperStatus> (up down) Possible values: - up : the status of the server opera is up - down : the status of the server opera is down	the operational status of server <i>This element is only shown in detail mode.</i>
srv3-addr	Parameter type: <Sip::ServerAddr> (ipv4 : <Ip::V4Address> ipv6 : <Ip::V6Address> dns : <Sip::ServerAddr>) Possible values: - ipv4 : the address type of the server is IPv4 - ipv6 : the address type of the server is IPv6 - dns : the address type of the server is DNS Field type <Ip::V4Address> - IPv4-address Field type <Ip::V6Address> - IPv6-address Field type <Sip::ServerAddr> - name of the SipServer that can be resolved to an IP address via a DNS Server - length: 7<=x<=64	the operational address of server <i>This element is always shown.</i>
srv3-priority	Parameter type: <Sip::ServerPriority> - the SIP server priority - range: [0...65535]	server idr <i>This element is always shown.</i>
srv3-oper-status	Parameter type: <Sip::ServerOperStatus> (up down)	the operational status of server <i>This element is only shown in detail mode.</i>

151 Voice Status Commands

name	Type	Description
	Possible values: - up : the status of the server opera is up - down : the status of the server opera is down	
srv4-addr	Parameter type: <Sip::ServerAddr> (ipv4 : <Ip::V4Address> ipv6 : <Ip::V6Address> dns : <Sip::ServerAddr>) Possible values: - ipv4 : the address type of the server is IPv4 - ipv6 : the address type of the server is IPv6 - dns : the address type of the server is DNS Field type <Ip::V4Address> - IPv4-address Field type <Ip::V6Address> - IPv6-address Field type <Sip::ServerAddr> - name of the SipServer that can be resolved to an IP address via a DNS Server - length: 7<=x<=64	the operational address of server <i>This element is always shown.</i>
srv4-priority	Parameter type: <Sip::ServerPriority> - the SIP server priority - range: [0...65535]	server idr <i>This element is always shown.</i>
srv4-oper-status	Parameter type: <Sip::ServerOperStatus> (up down) Possible values: - up : the status of the server opera is up - down : the status of the server opera is down	the operational status of server <i>This element is only shown in detail mode.</i>

151.26 Voice Sip All Port State Status Command

Command Description

This command allows the operator to show the Voice Sip All Port State

User Level

The command can be accessed by operators with sip privileges.

Command Syntax

The command has the following syntax:

```
> show voice sip all port-state [ (if-index) ]
```

Command Parameters

Table 151.26-1 "Voice Sip All Port State Status Command" Resource Parameters

Resource Identifier	Type	Description
(if-index)	Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number	The unique internal identifier of the termination port. an operator should request the port state for a single port

Command Output

Table 151.26-2 "Voice Sip All Port State Status Command" Display parameters

Specific Information		
name	Type	Description
port-state	Parameter type: <Sip::TermPortState> - identify the state for this port - length: x<=63	the operational status of application server <i>This element is always shown.</i>
query-result	Parameter type: <Sip::QueryResult> - Query result. - length: 1<=x<=64	the result description <i>This element is always shown.</i>
admin-status	Parameter type: <Sip::TermAdminStatus> (up down) Possible values:	the administrative status of sip termination <i>This element is always shown.</i>

151 Voice Status Commands

name	Type	Description
	- up : unlock the sip termination - down : lock the sip termination	
oper-status	Parameter type: <Sip::TermOperStatus> (up down) Possible values: - up : the status of the termination opera is up - down : the status of the termination is down	the operational status of this sip termination <i>This element is always shown.</i>
line-termination	Parameter type: <Sip::TermHookState> (high-resistance low-resistance) Possible values: - high-resistance : the termination is high resistance - low-resistance : the termination is low resistance	the high/low resistance status of this termination <i>This element is always shown.</i>
uss-state	Parameter type: <Sip::TermUssState> (true false) Possible values: - true : port is in P5.3 and GBsTone is already switched off (Power Down) - false : port is not in Power Down	the loop closure status of a sip termination. <i>This element is always shown.</i>
supp-v-rt(mv)	Parameter type: <Sip::VoltageValue> - the voltage value in mV unit. - range: [-2147483647...2147483647]	Feeded DC voltage of user line (Ring-Tip) <i>This element is always shown.</i>
supp-v-tr(mv)	Parameter type: <Sip::VoltageValue> - the voltage value in mV unit. - range: [-2147483647...2147483647]	Feeded DC voltage of user line (Tip-Ring) <i>This element is always shown.</i>
supp-v-rg(mv)	Parameter type: <Sip::VoltageValue> - the voltage value in mV unit. - range: [-2147483647...2147483647]	Feeded DC voltage of user line (Ring-Groud) <i>This element is always shown.</i>
supp-v-tg(mv)	Parameter type: <Sip::VoltageValue> - the voltage value in mV unit. - range: [-2147483647...2147483647]	Feeded DC voltage of user line (Tip-Groud) <i>This element is always shown.</i>
supply-curr(ua)	Parameter type: <Sip::CurrentValue> - a signed integer	Feeding current(Tip-Ring) <i>This element is always shown.</i>
longi-curr(ua)	Parameter type: <Sip::CurrentValue> - a signed integer	difference between the currents on the a-lead and the b-lead <i>This element is always shown.</i>
validity	Parameter type: <Sip::ValidityBinary> - the validity flag of the status and line test result value. - range: [-2147483647...2147483647]	bitmap to show the validity for items from AdminStatus to longi-cur <i>This element is always shown.</i>

151.27 Voice Sip Isdn/Cas Termination Status Commands

Command Description

this command allows the operator to show the Voice sip isdn/Cas termination profile.

User Level

The command can be accessed by operators with sip privileges.

Command Syntax

The command has the following syntax:

```
> show voice sip isdn-cas-cls-puid [ (name) [ directory-number <Sip::TermDnumber> ] ]
```

Command Parameters

Table 151.27-1 "Voice Sip Isdn/Cas Termination Status Commands" Resource Parameters

Resource Identifier	Type	Description
(name)	Format: - Name of the E1 cluster - length: x<=32	Name of E1 or T1 cluster
directory-number	Parameter type: <Sip::TermDnumber> Format: - identify the DN of the subscriber line - length: x<=32	The directory number of this PUID

Command Output

Table 151.27-2 "Voice Sip Isdn/Cas Termination Status Commands" Display parameters

Specific Information		
name	Type	Description
contact-user-info	Parameter type: <SIP::SipTerminationContact> - The user-info of contact field in SIP message associated with the user - length: 1<=x<=128	The user-info of contact field in SIP message associated with the user <i>This element is always shown.</i>
oper-status	Parameter type: <Sip::TermOperStatus> (up down) Possible values: - up : the status of the termination opera is up - down : the status of the termination is down	the operational status of a termination <i>This element is always shown.</i>
operstatus-downreason	Parameter type: <Sip::IsdnCasPUIDOpDownReason>	the detailed down reason when

151 Voice Status Commands

name	Type	Description
	(registering registrationfailure partiallyregistered admin-status-down unknown noregsipserveroos notregistered) Possible values: - : The operational status of the GDN-EXT is UP - registering : The operational state of the GDN-EXT is DOWN; Reason: The GDN-EXT's registration is in progress - registrationfailure : The operational state of the GDN-EXT is DOWN; Reason: The GDN-EXT's registration has failed - partiallyregistered : The operational state of the DDI-EXT is DOWN; Reason: The DDI-EXT's registration has failed for at least one Virtual E1 Group - admin-status-down : The operational state of the DDI-EXT is DOWN; Reason: The admin-status of the GDN_EXTs is down - unknown : The operational state of the DDI-EXT is DOWN; Reason: LT is down or IOCM communication failure - noregsipserveroos : The operational state of the DDI-EXT is DOWN; Reason: The First hop SIP server is not reachable anymore (redundancy = disabled) or none of the First hop servers are reachable (redundancy = enabled). - notregistered : The operational state of the DDI-EXT is DOWN; The DDI-EXT's registration was not initiated yet.	operational status is down <i>This element is always shown.</i>

151.28 Voice Sip Isdn Cas E1 Interface Status Commands

Command Description

this command allows the operator to show the Voice sip isdn cas E1 interface oper-status.

User Level

The command can be accessed by operators with sip privileges.

Command Syntax

The command has the following syntax:

```
> show voice sip isdn-cas-itf [ (if-index) [ interfaces <Itf::IsdnLine> ] ]
```

Command Parameters

Table 151.28-1 "Voice Sip Isdn Cas E1 Interface Status Commands" Resource Parameters

Resource Identifier	Type	Description
(if-index)	Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number	The unique internal identifier of the ISDN CAS termination
interfaces	Parameter type: <Itf::IsdnLine> Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number	The ifindex of the E1 interface

Command Output

Table 151.28-2 "Voice Sip Isdn Cas E1 Interface Status Commands" Display parameters

Specific Information		
name	Type	Description
oper-status	Parameter type: <Sip::IsdnCasE1OperStatus> (up down) Possible values: - up : The E1/T1 interface's operational status is UP - down : The E1/T1 interface's operational status is down	The operational status of an E1 interface <i>This element is always shown.</i>
operstatus-downreason	Parameter type: <Sip::IsdnCasE1OpDownReason> (l1inactive l2inactive cas-sig-failure admin-status-down unknown intest) Possible values: - : The operational status of the E1/T1 interface is UP - l1inactive : The operational state of the E1/T1 interface is DOWN; Reason: The E1/T1 interface's ISDN Layer1 is down - l2inactive : The operational state of the E1/T1 interface is DOWN; Reason: The E1/T1 interface's ISDN Layer1 is up, however the ISDN Layer2 is down - cas-sig-failure : The operational state of the E1/T1 interface is DOWN; Reason: The E1/T1 interface's CAS Layer1 could not successfully be established towards the CPE side - admin-status-down : The operational state of the E1/T1 interface is DOWN; Reason: The ISDN/CAS termination admin status is down - unknown : The operational state of the E1/T1 interface is DOWN; Reason: The LT is down and the IOCM communication is failure - intest : The operational state of the E1/T1 interface is DOWN; Reason: The E1/T1 interface is under line test	The detailed down reason when operational status is down <i>This element is always shown.</i>
cluster-name	Parameter type: <Sip::IsdnCasTerminationE1ClusterName> - Name of the E1 cluster - length: x<=32	Name of the E1 cluster <i>This element is always shown.</i>
idle-b-channels	Parameter type: <Sip::ItfBChannelNumber> - value of bearer channel number for an interface - range: [0...30]	Number of idle b-channel on this E1 interface <i>This element is always shown.</i>
used-b-channels	Parameter type: <Sip::ItfBChannelNumber> - value of bearer channel number for an interface - range: [0...30]	Number of used b-channel on this E1 interface <i>This element is always shown.</i>
oos-b-channels	Parameter type: <Sip::ItfBChannelNumber> - value of bearer channel number for an interface - range: [0...30]	Number of out of service b-channel on this E1 interface <i>This element is always shown.</i>

151.29 Voice Sip Isdn Nsm Profile Status Commands

Command Description

this command allows the operator to show the Voice Sip Isdn Nsm profile.

User Level

The command can be accessed by operators with sip privileges.

Command Syntax

The command has the following syntax:

```
> show voice sip isdn-nsm-prof [ (prof-name) ]
```

Command Parameters

Table 151.29-1 "Voice Sip Isdn Nsm Profile Status Commands" Resource Parameters

Resource Identifier	Type	Description
(prof-name)	Format: - the name of a nsm profile - length: x<=32	The unique name identifier of an row in the sipIsdnNsmProfileTable.

Command Output

Table 151.29-2 "Voice Sip Isdn Nsm Profile Status Commands" Display parameters

Specific Information		
name	Type	Description
prof-idx	Parameter type: <Sip::NsmProfileIdx> - the index of a nsm profile - range: [1...32]	The unique identifier of an row in the sipIsdnNsmProfileTable. <i>This element is always shown.</i>
used-status	Parameter type: <Sip::NsmProfileUsedCnt> - the number of entities using this profile - range: [0...300]	Indicates the number of entities using this profile <i>This element is always shown.</i>
version-nbr	Parameter type: <Sip::NsmProfileVersionNbr> - a version number of the profile - range: [1...65535]	a version number of the profile. <i>This element is always shown.</i>

151.30 Voice Sip Cas Nsm Profile Status Commands

Command Description

this command allows the operator to show the Voice Sip Cas Nsm profile.

User Level

The command can be accessed by operators with sip privileges.

Command Syntax

The command has the following syntax:

```
> show voice sip cas-nsm-prof [ (prof-name) ]
```

Command Parameters

Table 151.30-1 "Voice Sip Cas Nsm Profile Status Commands" Resource Parameters

Resource Identifier	Type	Description
(prof-name)	Format: - the name of a nsm profile - length: 1<=x<=32	The unique name identifier of an row in the sipCasNsmProfileTable.

Command Output

Table 151.30-2 "Voice Sip Cas Nsm Profile Status Commands" Display parameters

Specific Information		
name	Type	Description
prof-idx	Parameter type: <Sip::CasNsmProfIdx> - the index of a cas nsm profile - range: [1...32]	The unique identifier of an row in the sipCasNsmProfileTable. <i>This element is always shown.</i>
used-status	Parameter type: <Sip::CasNsmProfUsedStatus> - the used status of the profile - range: [0...300]	Indicates the number of entities using this profile <i>This element is always shown.</i>
version-nbr	Parameter type: <Sip::CasNsmProfVersionNbr> - a version number of the profile - range: [1...65535]	a version number of the profile. <i>This element is always shown.</i>

151.31 Voice Sip Cas Timer Profile Status Commands

Command Description

this command allows the operator to show the Voice Sip Cas Timer profile.

User Level

The command can be accessed by operators with sip privileges.

Command Syntax

The command has the following syntax:

> show voice sip cas-timer-prof [(prof-name)]

Command Parameters

Table 151.31-1 "Voice Sip Cas Timer Profile Status Commands" Resource Parameters

Resource Identifier	Type	Description
(prof-name)	Format: - the name of a timer profile - length: 1<=x<=32	The unique name identifier of an row in the sipCasTimerProfileTable.

Command Output

Table 151.31-2 "Voice Sip Cas Timer Profile Status Commands" Display parameters

Specific Information		
name	Type	Description
prof-idx	Parameter type: <Sip::CasTimerProfIdx> - the index of a cas timer profile - range: [1...32]	The unique identifier of an row in the sipCasTimerProfileTable. <i>This element is always shown.</i>
used-status	Parameter type: <Sip::CasTimerProfUsedStatus> - the used status of the profile - range: [0...300]	Indicates the number of entities using this profile <i>This element is always shown.</i>
version-nbr	Parameter type: <Sip::CasTimerProfVersionNbr> - a version number of the profile - range: [1...65535]	a version number of the profile. <i>This element is always shown.</i>

151.32 Voice Sip Cas Signaling Profile Status Commands

Command Description

this command allows the operator to show the Voice Sip Cas Signaling profile.

User Level

The command can be accessed by operators with sip privileges.

Command Syntax

The command has the following syntax:

```
> show voice sip cas-sig-prof [ (prof-name) ]
```

Command Parameters

Table 151.32-1 "Voice Sip Cas Signaling Profile Status Commands" Resource Parameters

Resource Identifier	Type	Description
(prof-name)	Format: - name of the signal profile - length: 1<=x<=32	The unique name identifier of an row in the sipCasSignalingProfileTable.

Command Output

Table 151.32-2 "Voice Sip Cas Signaling Profile Status Commands" Display parameters

Specific Information		
name	Type	Description
prof-idx	Parameter type: <Sip::CasSignalProfIdx> - index of the cas signaling profile - range: [1...32]	The unique identifier of an row in the sipCasSignalingProfileTable. <i>This element is always shown.</i>
used-status	Parameter type: <Sip::CasSignalProfUsedStatus> - the used status of the profile - range: [0...144]	Indicates the number of entities using this profile <i>This element is always shown.</i>
version-nbr	Parameter type: <Sip::CasSignalProfVersionNbr> - version number of the signaling profile - range: [1...65535]	a version number of the profile. <i>This element is always shown.</i>

151.33 Voice Sip Isdn And Cas Nsm Profile Index Status Commands

Command Description

this command allows the operator to show the Voice Sip Isdn and Cas Nsm profile next free Index and Max index.

User Level

The command can be accessed by operators with sip privileges.

Command Syntax

The command has the following syntax:

> show voice sip profiles

Command Output

Table 151.33-2 "Voice Sip Isdn And Cas Nsm Profile Index Status Commands" Display parameters

Specific Information		
name	Type	Description
isdn-nsm-prof-idx-next	Parameter type: <SipNextProfileIndex> - a profile index - range: [0...65535]	the index of the next free row in the sipIsdnNsmProfileTable. <i>This element is always shown.</i>
isdn-nsm-prof-idx-max	Parameter type: <SipMaxProfileIndex> - a maximum value of a profile index - range: [0...65535]	the maximum number of sipIsdnNsmProfiles that can be created <i>This element is always shown.</i>
cas-nsm-prof-idx-next	Parameter type: <SipNextProfileIndex> - a profile index - range: [0...65535]	the index of the next free row in the sipCasNsmProfileTable. <i>This element is always shown.</i>
cas-nsm-prof-idx-max	Parameter type: <SipMaxProfileIndex> - a maximum value of a profile index - range: [0...65535]	the maximum number of sipCasNsmProfiles that can be created <i>This element is always shown.</i>
cas-tmr-prof-idx-next	Parameter type: <SipNextProfileIndex> - a profile index - range: [0...65535]	the index of the next free row in the sipCasTimerProfileTable. <i>This element is always shown.</i>
cas-tmr-prof-idx-max	Parameter type: <SipMaxProfileIndex> - a maximum value of a profile index - range: [0...65535]	the maximum number of sipCasTimerProfiles that can be created <i>This element is always shown.</i>
cas-sig-prof-idx-next	Parameter type: <SipNextProfileIndex> - a profile index - range: [0...65535]	the index of the next free row in the sipCasSignalingProfileTable. <i>This element is always shown.</i>
cas-sig-prof-idx-max	Parameter type: <SipMaxProfileIndex>	the maximum number of

151 Voice Status Commands

name	Type	Description
	- a maximum value of a profile index - range: [0...65535]	sipCasSignalingProfiles that can be created <i>This element is always shown.</i>
isdn-uus-prof-idx-next	Parameter type: <SipNextProfileIndex> - a profile index - range: [0...65535]	the index of the next free row in the sipPriUserToUserProfileTable. <i>This element is always shown.</i>
isdn-uus-prof-idx-max	Parameter type: <SipMaxProfileIndex> - a maximum value of a profile index - range: [0...65535]	the maximum number of sipPriUserToUserProfiles that can be created. <i>This element is always shown.</i>

151.34 Voice Sip Isdn Cas E1 Interface B channel Status Commands

Command Description

this command allows the operator to show the B channel status of Voice sip isdn cas E1 interface.

User Level

The command can be accessed by operators with sip privileges.

Command Syntax

The command has the following syntax:

```
> show voice sip e1itf-bchannel-status [ (if-index) [ interface <Itf::IsdnLine> ] [ b-chan-id <Sip::BearerChannelId> ] ]
```

Command Parameters

Table 151.34-1 "Voice Sip Isdn Cas E1 Interface B channel Status Commands" Resource Parameters

Resource Identifier	Type	Description
(if-index)	Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number	the Ifindex of the SIP termination that has been created on top of the E1 Cluster / Virtual E1 Group
interface	Parameter type: <Itf::IsdnLine> Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number	The Ifindex of the E1 interface that belongs to E1 cluster / Virtual E1 Group
b-chan-id	Parameter type: <Sip::BearerChannelId>	The identity of the B channel

Resource Identifier	Type	Description
	Format: - the index of a B channel on E1 interface - range: [1...30]	

Command Output

Table 151.34-2 "Voice Sip Isdn Cas E1 Interface B channel Status Commands" Display parameters

Specific Information		
name	Type	Description
b-chan-status	Parameter type: <Sip::BearerChannelStatus> (idle used oos) Possible values: - idle : The B-channel is In-Service but neither involved in a call nor under test - used : The B-channel is In-Service and has been allocated to carry media traffic for an call. - oos : The B-channel is under test or really been put Out-Of-Service	The status of the B channel. The status can be idle/used/oos <i>This element is always shown.</i>

151.35 Voice Sip Isdn/Cas Termination Status Commands

Command Description

This command shows the ISDN PRI / Cas SIP termination data.

User Level

The command can be accessed by operators with sip privileges.

Command Syntax

The command has the following syntax:

```
> show voice sip pri-cas-tksg-term [ (if-index) [ tksg-id <Sip::TrunkSubGroupId> ] ]
```

Command Parameters

Table 151.35-1 "Voice Sip Isdn/Cas Termination Status Commands" Resource Parameters

Resource Identifier	Type	Description
(if-index)	Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number	The ifIndex of the ISDN PRI / CAS SIP termination
tksg-id	Parameter type: <Sip::TrunkSubGroupId> Format: - The index of E1/T1 interface trunk sub-group. - range: [0...256]	The E1/T1 Trunk sub-group ID.

Command Output

Table 151.35-2 "Voice Sip Isdn/Cas Termination Status Commands" Display parameters

Specific Information		
name	Type	Description
contact-user-info	Parameter type: <SIP::SipTerminationContact> - The user-info of contact field in SIP message associated with the user	The user-info of the contact header in the SIP message generated for this ISDN PRI /

151 Voice Status Commands

name	Type	Description
	- length: 1<=x<=128	CAS SIP termination. <i>This element is always shown.</i>
oper-status	Parameter type: <Sip::IsdnCasTermOperStatus> (up down) Possible values: - up : The GDN-EXT has successfully registered - down : The GDN-EXT's operational status is down	The operational status of the ISDN PRI / CAS SIP termination <i>This element is always shown.</i>
operstatus-downreason	Parameter type: <Sip::IsdnCasTermOpDownReason> (registering registrationfailure admin-status-down unknown noregsipserveroos) Possible values: - : The operational status of the GDN-EXT is UP - registering : The operational state of the GDN-EXT is DOWN; Reason: The GDN-EXT's registration is in progress. - registrationfailure : The operational state of the GDN-EXT is DOWN; Reason: The GDN-EXT's registration has failed. - admin-status-down : The operational state of the GDN-EXT is DOWN; Reason: termination admin status is down. - unknown : The operational state of the GDN-EXT is DOWN; Reason: LT is down or IOCM communication failure. - noregsipserveroos : The operational state of the GDN-EXT is DOWN; Reason: The First hop SIP server is not reachable anymore (redundancy = disabled) or none of the First hop servers are reachable (redundancy = enabled).	The operational status down reason of the ISDN PRI/ CAS SIP termination <i>This element is always shown.</i>
termination-group	Parameter type: <SIP::sipIsdnCasTerminationGroupID> - the termination group termination belongs to - range: [0...300]	The SIP Termination Group this ISDN PRI / CAS SIP termination belongs to <i>This element is always shown.</i>
sip-server-address	Parameter type: <Sip::sipServerAddr> - name of the SipServer that can be resolved to an IP address via a DNS Server - length: 7<=x<=64	The First Hop SIP server via which the ISDN PRI / CAS SIP termination has registered. <i>This element is always shown.</i>
nbr-idle-ds0-channels	Parameter type: <Sip::TksgBChannelNumber> - value of bearer channel number for pri-cas-tksg-term - range: [0...960]	The number of idle DS0 channels for the ISDN PRI / CAS SIP termination <i>This element is always shown.</i>
nbr-used-ds0-channels	Parameter type: <Sip::TksgBChannelNumber> - value of bearer channel number for pri-cas-tksg-term - range: [0...960]	The number of used DSO-channels for the ISDN PRI / CAS SIP termination <i>This element is always shown.</i>
nbr-oos-ds0-channels	Parameter type: <Sip::TksgBChannelNumber> - value of bearer channel number for pri-cas-tksg-term - range: [0...960]	The number of out of service DS0-channels for the ISDN PRI / CAS SIP termination <i>This element is always shown.</i>
provider-name	Parameter type: <Sip::TermUserProviderName> - identify the user VSG name for this port - length: x<=32	The name of the VSG this ISDN PRI / CAS SIP termination is associated with <i>This element is always shown.</i>
signalling-type	Parameter type: <Sip::TksgTermSignallingType>	The signalling type of this ISDN

name	Type	Description
	(isdn-pra cas-2bit-mfc-gr-fw-bw cas-2bit-dtmf cas-1bit-dtmf cas-1bit-mfc-gr-fw-bw cas-1bit-decadic cas-1bit-mfc-fw) Possible values: - isdn-pra : Q931/Q921 protocol based communication between the CPE side and the NIAT-A board - cas-2bit-mfc-gr-fw-bw : 2 bit line signaling and MFC register signaling in compliance with ITU-T Q.400-490 CAS R2 specification (supporting groups, forward and backward signals) - cas-2bit-dtmf : 2 bit line signaling and DTMF register signaling - cas-1bit-dtmf : 1 bit line signaling and DTMF register signaling - cas-1bit-mfc-gr-fw-bw : 1 bit line signaling and MFC register signaling (supporting groups, forward and backward signals). This ENUM value is actually NOT supported. - cas-1bit-decadic : 1 bit line signaling and DECADIC register signaling. This ENUM value is actually NOT supported. - cas-1bit-mfc-fw : 1 bit line signaling and MFC register signaling in compliance with ITU-T Q.310-Q322 CAS R1 specification (supporting only forward signals). This ENUM value is actually NOT supported.	PRI / CAS SIP termination. <i>This element is always shown.</i>
trunk-group-name	Parameter type: <Sip::SipPriCasTksgTermTrunkGroupName> - Name of the E1/T1 Trunk Group - length: x<=32	The Name of the E1/T1 Trunk (sub-)Group on top of which the ISDN PRI / CAS SIP termination is created. <i>This element is always shown.</i>
puids	Parameter type: <Sip::IsdnCasTermPuids> - identify the user puids for this port - length: x<=2560	The list of DDI-EXTs associated with this ISDN PRI / CAS SIP termination <i>This element is only shown in detail mode.</i>

151.36 Voice Sip Isdn PUID Termination Status Commands

Command Description

This command shows the DDI-EXT data

User Level

The command can be accessed by operators with sip privileges.

Command Syntax

The command has the following syntax:

```
> show voice sip pri-cas-tksg-puid [ (if-index) [ tksg-id <Sip::TrunkSubGroupId> ] [ directory-number <Sip::TermDnumber> ] ]
```

Command Parameters

Table 151.36-1 "Voice Sip Isdn PUID Termination Status Commands" Resource Parameters

Resource Identifier	Type	Description
(if-index)	Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number	The Ifindex of the associated ISDN PRI / CAS SIP termination
tksg-id	Parameter type: <Sip::TrunkSubGroupId> Format: - The index of E1/T1 interface trunk sub-group. - range: [0...256]	The E1/T1 Trunk (sub-)group ID
directory-number	Parameter type: <Sip::TermDnumber> Format: - identify the DN of the subscriber line - length: x<=32	The directory number of the DDI-EXT

Command Output

Table 151.36-2 "Voice Sip Isdn PUID Termination Status Commands" Display parameters

Specific Information		
name	Type	Description
contact-user-info	Parameter type: <SIP::SipTerminationContact> - The user-info of contact field in SIP message associated with the user - length: 1<=x<=128	The user-info of the contact header in the SIP message generated for this DDI-EXT <i>This element is always shown.</i>
oper-status	Parameter type: <Sip::TermOperStatus> (up down) Possible values: - up : the status of the termination opera is up - down : the status of the termination is down	The operational status of the DDI-EXT <i>This element is always shown.</i>
operstatus-downreason	Parameter type: <Sip::IsdnCasPUIDOpDownReason> (registering registrationfailure partiallyregistered admin-status-down unknown noregsipserveroos notregistered) Possible values: - : The operational status of the GDN-EXT is UP - registering : The operational state of the GDN-EXT is DOWN; Reason: The GDN-EXT's registration is in progress - registrationfailure : The operational state of the GDN-EXT is DOWN; Reason: The GDN-EXT's registration has failed - partiallyregistered : The operational state of the DDI-EXT is DOWN; Reason: The DDI-EXT's registration has failed for at least one Virtual E1 Group - admin-status-down : The operational state of the DDI-EXT is DOWN; Reason: The admin-status of the GDN_EXTs is down - unknown : The operational state of the DDI-EXT is DOWN; Reason: LT is down or IOCM communication failure - noregsipserveroos : The operational state of the DDI-EXT is DOWN; Reason: The First hop SIP server is not reachable anymore (redundancy = disabled) or none of the First hop servers are reachable (redundancy = enabled). - notregistered : The operational state of the DDI-EXT is DOWN; The DDI-EXT's registration was not initiated yet.	The operational status down reason of the DDI-EXT <i>This element is always shown.</i>

151.37 Voice Sip Pri User To User Profile Status Commands

Command Description

this command allows the operator to show the Voice Sip Pri User To User Profile.

User Level

The command can be accessed by operators with sip privileges.

Command Syntax

The command has the following syntax:

```
> show voice sip user-to-user-prof [ (prof-name) ]
```

Command Parameters

Table 151.37-1 "Voice Sip Pri User To User Profile Status Commands" Resource Parameters

Resource Identifier	Type	Description
(prof-name)	Format: - The unique name identifier of a row in the sipPriUserToUserProfileTable - length: 1<=x<=32	The unique name identifier of a row in the sipPriUserToUserProfileTable.

Command Output

Table 151.37-2 "Voice Sip Pri User To User Profile Status Commands" Display parameters

Specific Information		
name	Type	Description
prof-idx	Parameter type: <Sip::UserToUserProfIdx> - the index of an pri user to user profile - range: [1...32]	The unique identifier of a row in the sipPriUserToUserProfileTable. <i>This element is always shown.</i>
used-status	Parameter type: <Sip::UserToUserProfUsedCnt> - the number of entities using this profile - range: [0...300]	Indicates the number of entities using this profile. <i>This element is always shown.</i>
version-nbr	Parameter type: <Sip::UserToUserProfVersionNbr> - The version number of the pri user to user profile - range: [1...65535]	The version number of the profile. <i>This element is always shown.</i>

151.38 Voice Sip Physical Interface Status Commands

Command Description

This command allows the operator to show the Voice Sip physical interface profile.

User Level

The command can be accessed by operators with sip privileges.

Command Syntax

The command has the following syntax:

```
> show voice sip phys-itf [ (if-index) ]
```

Command Parameters

Table 151.38-1 "Voice Sip Physical Interface Status Commands" Resource Parameters

Resource Identifier	Type	Description
(if-index)	Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number	The unique internal identifier of the physical E1/T1 interface

Command Output

Table 151.38-2 "Voice Sip Physical Interface Status Commands" Display parameters

Specific Information		
name	Type	Description
oper-status	Parameter type: <Sip::PhysItfOperStatus> (up down) Possible values: - up : the status of the physical interface opera is up - down : the status of the physical interface opera is down	The operational state of the physical interface <i>This element is always shown.</i>
operstatus-downreason	Parameter type: <Sip::PhysItfOperStatusDownReason>	The operational status down

name	Type	Description
	(l1inactive l2inactive cas-sig-failure admin-status-down unknown intest) Possible values: - : The operational status of the E1/T1 interface is UP - l1inactive : The operational state of the E1/T1 interface is DOWN; Reason: The interface's Layer1 is disabled - l2inactive : The operational state of the E1/T1 interface is DOWN; Reason: The interface's Layer1 is enabled, but the Layer2 is disconnected - cas-sig-failure : The operational state of the E1/T1 interface is DOWN; Reason: The E1/T1 interface's CAS Layer1 could not successfully be established towards the CPE side - admin-status-down : The operational state of the E1/T1 interface is DOWN; Reason: The admin-status of the interface is set to down - unknown : The operational state of the E1/T1 interface is DOWN; Reason: The correct operational state cannot be retrieved since the communication with the LT board failed. The LT board is down or the IOCM communication failed - intest : The operational state of the E1/T1 interface is DOWN; Reason: A loopback test is running at the interface	reason of the physical interface <i>This element is always shown.</i>
interface-type	Parameter type: <Sip::PhysItfTypeForShow> (e1 t1) Possible values: - e1 : E1 interface with 30 B channels. - t1 : T1 interface with 23 B channels.	The type of physical interface <i>This element is always shown.</i>
nbr-idle-ts-channels	Parameter type: <Sip::ItfBChannelNumber> - value of bearer channel number for an interface - range: [0...30]	The number of TS channels that are actually in idle state for the interface <i>This element is always shown.</i>
nbr-used-ts-channels	Parameter type: <Sip::ItfBChannelNumber> - value of bearer channel number for an interface - range: [0...30]	The number of TS channels that are actual in used for the interface. <i>This element is always shown.</i>
nbr-oos-ts-channels	Parameter type: <Sip::ItfBChannelNumber> - value of bearer channel number for an interface - range: [0...30]	the test status of a termination <i>This element is always shown.</i>
test-state	Parameter type: <Sip::PhysItfTestState> (no-testing loopback-testing loopback-envset reserved-for-test) Possible values: - no-testing : The interface is not under test - loopback-testing : The interface is involved in local or cable loopback testing - loopback-envset : A remote or payload loopback environment is created for the interface - reserved-for-test : The interface is reserved for loopback testing	The test status of the interface <i>This element is always shown.</i>

name	Type	Description
ch0	Parameter type: <Sip::TsByteMask0> (framing-signal-ts idle busy blocked testing itf-admin-down l1l2-disconnect unknown) Possible values: - framing-signal-ts : - idle : - busy : - blocked : - testing : - itf-admin-down : - l1l2-disconnect : - unknown :	channel 0 <i>This element is only shown in detail mode.</i>
ch1	Parameter type: <Sip::TsByteMask1> (framing-signal-ts idle busy blocked testing itf-admin-down l1l2-disconnect unknown) Possible values: - framing-signal-ts : - idle : - busy : - blocked : - testing : - itf-admin-down : - l1l2-disconnect : - unknown :	channel 1 <i>This element is only shown in detail mode.</i>
ch2	Parameter type: <Sip::TsByteMask2> (framing-signal-ts idle busy blocked testing itf-admin-down l1l2-disconnect unknown) Possible values: - framing-signal-ts : - idle : - busy : - blocked : - testing : - itf-admin-down : - l1l2-disconnect : - unknown :	channel 2 <i>This element is only shown in detail mode.</i>
ch3	Parameter type: <Sip::TsByteMask3> (framing-signal-ts idle	channel 3 <i>This element is only shown in detail mode.</i>

151 Voice Status Commands

name	Type	Description
	busy blocked testing itf-admin-down 1112-disconnect unknown) Possible values: - framing-signal-ts : - idle : - busy : - blocked : - testing : - itf-admin-down : - 1112-disconnect : - unknown :	
ch4	Parameter type: <Sip::TsByteMask4> (framing-signal-ts idle busy blocked testing itf-admin-down 1112-disconnect unknown) Possible values: - framing-signal-ts : - idle : - busy : - blocked : - testing : - itf-admin-down : - 1112-disconnect : - unknown :	channel 4 <i>This element is only shown in detail mode.</i>
ch5	Parameter type: <Sip::TsByteMask5> (framing-signal-ts idle busy blocked testing itf-admin-down 1112-disconnect unknown) Possible values: - framing-signal-ts : - idle : - busy : - blocked : - testing : - itf-admin-down : - 1112-disconnect : - unknown :	channel 5 <i>This element is only shown in detail mode.</i>
ch6	Parameter type: <Sip::TsByteMask6> (framing-signal-ts idle busy blocked testing	channel 6 <i>This element is only shown in detail mode.</i>

name	Type	Description
	itf-admin-down l1l2-disconnect unknown) Possible values: - framing-signal-ts : - idle : - busy : - blocked : - testing : - itf-admin-down : - l1l2-disconnect : - unknown :	
ch7	Parameter type: <Sip::TsByteMask7> (framing-signal-ts idle busy blocked testing itf-admin-down l1l2-disconnect unknown) Possible values: - framing-signal-ts : - idle : - busy : - blocked : - testing : - itf-admin-down : - l1l2-disconnect : - unknown :	channel 7 <i>This element is only shown in detail mode.</i>
ch8	Parameter type: <Sip::TsByteMask8> (framing-signal-ts idle busy blocked testing itf-admin-down l1l2-disconnect unknown) Possible values: - framing-signal-ts : - idle : - busy : - blocked : - testing : - itf-admin-down : - l1l2-disconnect : - unknown :	channel 8 <i>This element is only shown in detail mode.</i>
ch9	Parameter type: <Sip::TsByteMask9> (framing-signal-ts idle busy blocked testing itf-admin-down l1l2-disconnect unknown)	channel 9 <i>This element is only shown in detail mode.</i>

151 Voice Status Commands

name	Type	Description
	Possible values: - framing-signal-ts : - idle : - busy : - blocked : - testing : - itf-admin-down : - 1112-disconnect : - unknown :	
ch10	Parameter type: <Sip::TsByteMask10> (framing-signal-ts idle busy blocked testing itf-admin-down 1112-disconnect unknown) Possible values: - framing-signal-ts : - idle : - busy : - blocked : - testing : - itf-admin-down : - 1112-disconnect : - unknown :	channel 10 <i>This element is only shown in detail mode.</i>
ch11	Parameter type: <Sip::TsByteMask11> (framing-signal-ts idle busy blocked testing itf-admin-down 1112-disconnect unknown) Possible values: - framing-signal-ts : - idle : - busy : - blocked : - testing : - itf-admin-down : - 1112-disconnect : - unknown :	channel 11 <i>This element is only shown in detail mode.</i>
ch12	Parameter type: <Sip::TsByteMask12> (framing-signal-ts idle busy blocked testing itf-admin-down 1112-disconnect unknown) Possible values: - framing-signal-ts : - idle :	channel 12 <i>This element is only shown in detail mode.</i>

name	Type	Description
	- busy : - blocked : - testing : - itf-admin-down : - l1l2-disconnect : - unknown :	
ch13	Parameter type: <Sip::TsByteMask13> (framing-signal-ts idle busy blocked testing itf-admin-down l1l2-disconnect unknown) Possible values: - framing-signal-ts : - idle : - busy : - blocked : - testing : - itf-admin-down : - l1l2-disconnect : - unknown :	channel 13 <i>This element is only shown in detail mode.</i>
ch14	Parameter type: <Sip::TsByteMask14> (framing-signal-ts idle busy blocked testing itf-admin-down l1l2-disconnect unknown) Possible values: - framing-signal-ts : - idle : - busy : - blocked : - testing : - itf-admin-down : - l1l2-disconnect : - unknown :	channel 14 <i>This element is only shown in detail mode.</i>
ch15	Parameter type: <Sip::TsByteMask15> (framing-signal-ts idle busy blocked testing itf-admin-down l1l2-disconnect unknown) Possible values: - framing-signal-ts : - idle : - busy : - blocked : - testing :	channel 15 <i>This element is only shown in detail mode.</i>

151 Voice Status Commands

name	Type	Description
	- itf-admin-down : - l1l2-disconnect : - unknown :	
ch16	Parameter type: <Sip::TsByteMask16> (framing-signal-ts idle busy blocked testing itf-admin-down l1l2-disconnect unknown) Possible values: - framing-signal-ts : - idle : - busy : - blocked : - testing : - itf-admin-down : - l1l2-disconnect : - unknown :	channel 16 <i>This element is only shown in detail mode.</i>
ch17	Parameter type: <Sip::TsByteMask17> (framing-signal-ts idle busy blocked testing itf-admin-down l1l2-disconnect unknown) Possible values: - framing-signal-ts : - idle : - busy : - blocked : - testing : - itf-admin-down : - l1l2-disconnect : - unknown :	channel 17 <i>This element is only shown in detail mode.</i>
ch18	Parameter type: <Sip::TsByteMask18> (framing-signal-ts idle busy blocked testing itf-admin-down l1l2-disconnect unknown) Possible values: - framing-signal-ts : - idle : - busy : - blocked : - testing : - itf-admin-down : - l1l2-disconnect : - unknown :	channel 18 <i>This element is only shown in detail mode.</i>

name	Type	Description
ch19	Parameter type: <Sip::TsByteMask19> (framing-signal-ts idle busy blocked testing itf-admin-down l1l2-disconnect unknown) Possible values: - framing-signal-ts : - idle : - busy : - blocked : - testing : - itf-admin-down : - l1l2-disconnect : - unknown :	channel 19 <i>This element is only shown in detail mode.</i>
ch20	Parameter type: <Sip::TsByteMask20> (framing-signal-ts idle busy blocked testing itf-admin-down l1l2-disconnect unknown) Possible values: - framing-signal-ts : - idle : - busy : - blocked : - testing : - itf-admin-down : - l1l2-disconnect : - unknown :	channel 20 <i>This element is only shown in detail mode.</i>
ch21	Parameter type: <Sip::TsByteMask21> (framing-signal-ts idle busy blocked testing itf-admin-down l1l2-disconnect unknown) Possible values: - framing-signal-ts : - idle : - busy : - blocked : - testing : - itf-admin-down : - l1l2-disconnect : - unknown :	channel 21 <i>This element is only shown in detail mode.</i>
ch22	Parameter type: <Sip::TsByteMask22> (framing-signal-ts idle	channel 22 <i>This element is only shown in detail mode.</i>

151 Voice Status Commands

name	Type	Description
	busy blocked testing itf-admin-down 1112-disconnect unknown) Possible values: - framing-signal-ts : - idle : - busy : - blocked : - testing : - itf-admin-down : - 1112-disconnect : - unknown :	
ch23	Parameter type: <Sip::TsByteMask23> (framing-signal-ts idle busy blocked testing itf-admin-down 1112-disconnect unknown) Possible values: - framing-signal-ts : - idle : - busy : - blocked : - testing : - itf-admin-down : - 1112-disconnect : - unknown :	channel 23 <i>This element is only shown in detail mode.</i>
ch24	Parameter type: <Sip::TsByteMask24> (framing-signal-ts idle busy blocked testing itf-admin-down 1112-disconnect unknown) Possible values: - framing-signal-ts : - idle : - busy : - blocked : - testing : - itf-admin-down : - 1112-disconnect : - unknown :	channel 24 <i>This element is only shown in detail mode.</i>
ch25	Parameter type: <Sip::TsByteMask25> (framing-signal-ts idle busy blocked testing	channel 25 <i>This element is only shown in detail mode.</i>

name	Type	Description
	itf-admin-down l1l2-disconnect unknown) Possible values: - framing-signal-ts : - idle : - busy : - blocked : - testing : - itf-admin-down : - l1l2-disconnect : - unknown :	
ch26	Parameter type: <Sip::TsByteMask26> (framing-signal-ts idle busy blocked testing itf-admin-down l1l2-disconnect unknown) Possible values: - framing-signal-ts : - idle : - busy : - blocked : - testing : - itf-admin-down : - l1l2-disconnect : - unknown :	channel 26 <i>This element is only shown in detail mode.</i>
ch27	Parameter type: <Sip::TsByteMask27> (framing-signal-ts idle busy blocked testing itf-admin-down l1l2-disconnect unknown) Possible values: - framing-signal-ts : - idle : - busy : - blocked : - testing : - itf-admin-down : - l1l2-disconnect : - unknown :	channel 27 <i>This element is only shown in detail mode.</i>
ch28	Parameter type: <Sip::TsByteMask28> (framing-signal-ts idle busy blocked testing itf-admin-down l1l2-disconnect unknown)	channel 28 <i>This element is only shown in detail mode.</i>

151 Voice Status Commands

name	Type	Description
	Possible values: - framing-signal-ts : - idle : - busy : - blocked : - testing : - itf-admin-down : - 1112-disconnect : - unknown :	
ch29	Parameter type: <Sip::TsByteMask29> (framing-signal-ts idle busy blocked testing itf-admin-down 1112-disconnect unknown) Possible values: - framing-signal-ts : - idle : - busy : - blocked : - testing : - itf-admin-down : - 1112-disconnect : - unknown :	channel 29 <i>This element is only shown in detail mode.</i>
ch30	Parameter type: <Sip::TsByteMask30> (framing-signal-ts idle busy blocked testing itf-admin-down 1112-disconnect unknown) Possible values: - framing-signal-ts : - idle : - busy : - blocked : - testing : - itf-admin-down : - 1112-disconnect : - unknown :	channel 30 <i>This element is only shown in detail mode.</i>
ch31	Parameter type: <Sip::TsByteMask31> (framing-signal-ts idle busy blocked testing itf-admin-down 1112-disconnect unknown) Possible values: - framing-signal-ts : - idle :	channel 31 <i>This element is only shown in detail mode.</i>

name	Type	Description
	- busy : - blocked : - testing : - itf-admin-down : - l1l2-disconnect : - unknown :	

151.39 Voice Sip Trunk Sub-group Status Commands

Command Description

this command allows the operator to show the Voice sip trunk sub-group oper-status.

User Level

The command can be accessed by operators with sip privileges.

Command Syntax

The command has the following syntax:

```
> show voice sip tksg [ (if-index) [ tksg-id <Sip::TksgId> ] [ interface <Itf::IsdnLine> ] ]
```

Command Parameters

Table 151.39-1 "Voice Sip Trunk Sub-group Status Commands" Resource Parameters

Resource Identifier	Type	Description
(if-index)	Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number	The ifIndex of the ISDN PRI / CAS SIP termination that has been created on top of the E1/T1 trunk sub-group.
tksg-id	Parameter type: <Sip::TksgId> Format: - The index of trunk sub-group - range: [1...256]	The unique Identifier of the trunk sub-group (chosen by the operator in the range [1..256]).
interface	Parameter type: <Itf::IsdnLine> Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId>	The Ifindex of the E1/T1 interface at which the trunk sub-group is created.

Resource Identifier	Type	Description
	- the port number	

Command Output

Table 151.39-2 "Voice Sip Trunk Sub-group Status Commands" Display parameters

Specific Information		
name	Type	Description
oper-status	Parameter type: <Sip::TksgOperStatus> (up down) Possible values: - up : the status of the E1/T1 trunk sub-group is up - down : the status of the E1/T1 trunk sub-group is down	The operational status of the E1/T1 trunk sub-group <i>This element is always shown.</i>
operstatus-downreason	Parameter type: <Sip::TksgOpDownReason> (admin-status-down physical-layer-down intest unknown) Possible values: - : The operational status of the trunk sub-group is UP - admin-status-down : The operational state of the trunk sub-group is DOWN; Reason: The admin-status of the trunk sub-group is set to down - physical-layer-down : The operational state of the trunk sub-group is DOWN; Reason: The operational state of the underlying E1/T1 interface(s) is DOWN - intest : The operational state of the trunk sub-group is DOWN; Reason: A loopback test is running at the underlying E1/T1 interfaces - unknown : The operational state of the trunk sub-group is DOWN; Reason: The LT board is down or the IOCM communication failed	The detailed down reason when operational status is down <i>This element is always shown.</i>

151.40 Voice Sip L1 Transport Statistics Commands

Command Description

This command allows the operator to show the Voice Sip L1 Transport Statistics.

User Level

The command can be accessed by operators with sip privileges.

Command Syntax

The command has the following syntax:

```
> show voice sip l1-trans-statistics [ (if-index) ]
```

Command Parameters

Table 151.40-1 "Voice Sip L1 Transport Statistics Commands" Resource Parameters

Resource Identifier	Type	Description
(if-index)	Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number	The unique internal identifier of the physical E1/T1 interface

Command Output

Table 151.40-2 "Voice Sip L1 Transport Statistics Commands" Display parameters

Specific Information		
name	Type	Description
l1-tot-slip	Parameter type: <Sip::L1Counter> - 32 bit counter	The number of times the frequency of the receive route clock not equal to the receive system interface working clock <i>This element is always shown.</i>
l1-oof	Parameter type: <Sip::L1Counter> - 32 bit counter	The number of multiframe periods in the asynchronous state

name	Type	Description
		<i>This element is always shown.</i>
l1-fac	Parameter type: <Sip::L1Counter> - 32 bit counter	The number of detected changes of frame/multiframe alignment <i>This element is always shown.</i>
l1-err-sec	Parameter type: <Sip::L1Counter> - 32 bit counter	The number of errors occurred during the time interval of one second <i>This element is always shown.</i>
l1-crc4	Parameter type: <Sip::L1Counter> - 32 bit counter	The number of CRC-sub-multiframes with a CRC error <i>This element is always shown.</i>
l1-fas	Parameter type: <Sip::L1Counter> - 32 bit counter	The number l1 frame align signalling words with an error received <i>This element is always shown.</i>
reset-time	Parameter type: <Sip::SipTimeInSecs> - the time (yyyy-mm-dd:hour:minutes:secs)	The absolute time of the time stamp that the E1/T1 interface has been operationally enabled or the time stamp of the most recent reset of the L1 transport statistics <i>This element is always shown.</i>

151.41 Voice Sip NE Board Status Commands

Command Description

This command allows the operator to show the Voice Sip NE board status.

User Level

The command can be accessed by operators with sip privileges.

Command Syntax

The command has the following syntax:

```
> show voice sip ne-board [ cap-id <Sip::CapId> ] [ ne-id <Sip::NeId> ] [ board <Equipm::LtSlotIndex> ]
```

Command Parameters

Table 151.41-1 "Voice Sip NE Board Status Commands" Resource Parameters

Resource Identifier	Type	Description
cap-id	Parameter type: <Sip::CapId> Format: - the central access point id - range: [1...16]	The unique name identify of this central access point
ne-id	Parameter type: <Sip::NeId> Format: - the network element id - range: [1...8]	The unique identifier of the Network element.
board	Parameter type: <Equipm::LtSlotIndex> Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId>) Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number	The slot identifier of the NIAT-A LT board.

Command Output

Table 151.41-2 "Voice Sip NE Board Status Commands" Display parameters

Specific Information		
name	Type	Description
admin-status	Parameter type: <Sip::NeBoardAdminStatus> (up down)	administrative status of this NIAT-A LT board. <i>This element is always shown.</i>

name	Type	Description
	Possible values: - up : the NIAT-A LT board has been planned and has been physically pulled in - down : the NIAT-A LT board has not been planned yet or the NIAT-A LT board has been planned but is not physical plugged in.	
xhub-port	Parameter type: <Sip::xHubPort> - The xHUB port to which the NIAT-A LT board is connected. - range: [1...32]	The xHUB port to which the NIAT-A LT board is connected <i>This element is always shown.</i>
int-com-status	Parameter type: <Sip::IntComStatus> (up down unknown) Possible values: - up : The status of the internal communication is up - down : The status of the internal communication is down - unknown : The status of the internal communication is unknown	The status of the internal communication between the NIAT-A LT board and the Central Access Point <i>This element is always shown.</i>

151.42 Call Query state show command

Command Description

This command allows the operator to get the state of the call query.

User Level

The command can be accessed by operators with sip privileges.

Command Syntax

The command has the following syntax:

```
> show voice sip call-query [ (id) ]
```

Command Parameters

Table 151.42-1 "Call Query state show command" Resource Parameters

Resource Identifier	Type	Description
(id)	Format: - the index of call query session - range: [1]	The unique identify of this call query session

Command Output

Table 151.42-2 "Call Query state show command" Display parameters

Specific Information		
name	Type	Description
query-state	Parameter type: <Sip::CallQueryState> (running successful timeout) Possible values: - running : the call query is in progress - successful : all query results are received from LT boards - timeout : the timeout-period timer is time out before all query results are received	This actual state of the call query action being triggered <i>This element is always shown.</i>

151.43 Call Query result show command

Command Description

This command allows the operator to get the result of the call query.

User Level

The command can be accessed by operators with sip privileges.

Command Syntax

The command has the following syntax:

```
> show voice sip call-query-result [ (id) [ result-index <Sip::CallQueryResultId> ] ]
```

Command Parameters

Table 151.43-1 "Call Query result show command" Resource Parameters

Resource Identifier	Type	Description
(id)	Format: - the index of call query session - range: [1]	The unique identifier of this call query session
result-index	Parameter type: <Sip::CallQueryResultId> Format: - the index of the call query result - range: [1...3360]	The identifier of the call query result

Command Output

Table 151.43-2 "Call Query result show command" Display parameters

Specific Information		
name	Type	Description
calling	Parameter type: <Sip::CallQueryCalling> - the calling number of the call - length: 1<=x<=32	The calling number of the call <i>This element is always shown.</i>
called	Parameter type: <Sip::CallQueryCalled> - the called number of the call - length: 1<=x<=32	The called number of the call <i>This element is always shown.</i>
interface	Parameter type: <Sip::CallQueryLine> (pots : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> pri-cas : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId>) Possible values: - pots : physical pots line - pri-cas : physical line for isdn-pri and cas	The Ifindex of the POTS/E1/T1 interface at which the active call is created <i>This element is always shown.</i>

151 Voice Status Commands

name	Type	Description
	Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number	
timeslot	Parameter type: <Sip::CallQueryTimeSlot> - The timeslot of an E1/T1 interface which is used by the active call. In case type = POTS, then the timeslot is not relevant and will be indicated by white space. - range: [-1...31]	The timeslot of an E1/T1 interface which is used by the active call. In case type = POTS, then the timeslot is not relevant and will be indicated by -1. <i>This element is always shown.</i>

151.44 Voice Megaco Equipment Board Status Commands

Command Description

This command allows the operator to show the Voice board communication status.

User Level

The command can be accessed by operators with megaco privileges.

Command Syntax

The command has the following syntax:

```
> show voice cluster (cluster-id) board [ (equip-id) [ board-id <Equipm::PortSlotIndex> ] ]
```

Command Parameters

Table 151.44-1 "Voice Megaco Equipment Board Status Commands" Resource Parameters

Resource Identifier	Type	Description
(cluster-id)	Format: - the xvps cluster id - range: [1...8,11]	uniquely identify of this xvps cluster
(equip-id)	Format: - id of equipment - range: [1...32]	uniquely identify of this equipment
board-id	Parameter type: <Equipm::PortSlotIndex> Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::NewSlotId> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::NewSlotId>) Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::NewSlotId> - the LT slot number	uniquely identify of this board. the CLI slot numbering method is based on logical concept. for XD shelf, CLI logic slot-id(1 to 16) is mapped to physical slot-id from 4 to 19. for FD shelf, CLI logic slot-id(1 to 16) is mapped to physical slot-id from 1 to 8 and 12 to 19.

Command Output

Table 151.44-2 "Voice Megaco Equipment Board Status Commands" Display parameters

Specific Information		
name	Type	Description
comm-status	Parameter type: <MEGACO::BoardCommStatus> (up	the communication status of board

151 Voice Status Commands

name	Type	Description
	down unknown) Possible values: - up : The communication status is up - down : the communication status is down - unknown : the communication status is unknown	<i>This element is always shown.</i>
actual-type	Parameter type: <Equipm::ActBoardType> Data driven field type Possible values are depending on the actual configuration and software. The currently allowed values can be shown with online-help.	the actual type of board <i>This element is always shown.</i>

151.45 Voice Megaco Equipment Status Commands

Command Description

This command allows the operator to show the Voice termination operational status.

User Level

The command can be accessed by operators with megaco privileges.

Command Syntax

The command has the following syntax:

```
> show voice cluster (cluster-id) termination [ (equip-id) [ port-id <Itf::MegacoPotsLine> ] ]
```

Command Parameters

Table 151.45-1 "Voice Megaco Equipment Status Commands" Resource Parameters

Resource Identifier	Type	Description
(cluster-id)	Format: - the xvps cluster id - range: [1...8,11]	uniquely identify of this xvps cluster
(equip-id)	Format: - id of equipment - range: [1...32]	uniquely identify of this equipment
port-id	Parameter type: <Itf::MegacoPotsLine> Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::NewSlotId> / <Eqpt::MegacoPortId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::NewSlotId> - the LT slot number Field type <Eqpt::MegacoPortId> - the port number of Megaco	uniquely identify of this board. the CLI slot numbering method is based on logical concept.for XD shelf, CLI logic slot-id(1 to 16) is mapped to physical slot-id from 4 to 19. for FD shelf, CLI logic slot-id(1 to 16) is mapped to physical slot-id from 1 to 8 and 12 to 19.

Command Output

Table 151.45-2 "Voice Megaco Equipment Status Commands" Display parameters

Specific Information

151 Voice Status Commands

name	Type	Description
termination-id	Parameter type: <MEGACO::accessTerminationId> - the termination id, if it is not specified, system will automatically assign a free one in range - range: [0...32767]	the unique identifier of termination. <i>This element is always shown.</i>
port-type	Parameter type: <MEGACO::accTerminationUserPortType> (pstn isdn) Possible values: - pstn : the termination type is pstn - isdn : the termination type is isdn	the type of termination port. <i>This element is always shown.</i>
oper-status	Parameter type: <MEGACO::TerminationOperStatus> (up down shuttingdown) Possible values: - up : The operational status is up - down : the operational status is down - shuttingdown : the operational status is shuttingdown	the operational status of termination. <i>This element is always shown.</i>
admin-status	Parameter type: <MEGACO::accTerminationAdminStatus> (locked unlocked) Possible values: - locked : the admin status of termination is locked - unlocked : the admin status of termination is unlocked	the admin status of termination. <i>This element is always shown.</i>
call-status	Parameter type: <MEGACO::accTerminationCallStatus> (on-hook off-hook dialing calling connected idle-offhook busy-tone howler-tone ringing releasing ringback caller-connected callee-connected shared-cutoff) Possible values: - : the call status is unknown - on-hook : the call status is on-hook - off-hook : the call status is off-hook - dialing : the call status is dialing - calling : the call status is calling - connected : the call status is connected - idle-offhook : the call status is idle-offhook - busy-tone : the call status is busy tone - howler-tone : the call status is howler tone - ringing : the call status is ringing - releasing : the call status is releasing - ringback : the call status is releasing - caller-connected : the call status is caller connected - callee-connected : the call status is callee connected - shared-cutoff : the call status is cut off by paired	the call status of a termination <i>This element is always shown.</i>

name	Type	Description
	termination	
test-status	Parameter type: <MEGACO::accTerminationTestStatus> (no-testing mta-testing ilt-testing) Possible values: - no-testing : the termination is not under testing - mta-testing : the termination is under mta testing - ilt-testing : the termination is under integrated line testing	the test status of a termination <i>This element is always shown.</i>
operstatus-downreason	Parameter type: <MEGACO::accTerminationOpDownReason> (registering registrationfailure physicalfailure) Possible values: - : the term opera status down reason is none - registering : the term opera status down reason is registering - registrationfailure : the term opera status down reason is registration failure - physicalfailure : the term opera status down reason is physical failure	the reason of operational status of termination is down <i>This element is always shown.</i>
channel-status	Parameter type: <MEGACO::accTerminationChannelStatus> (idle b1-busy b2-busy both-channels-busy) Possible values: - : the term opera status down reason is none - idle : both channels are idle. - b1-busy : B1 channel is busy. B2 is idle - b2-busy : B2 channel is busy. B1 is idle - both-channels-busy : both channels are busy	The channel status of this access termination <i>This element is always shown.</i>
ps1	Parameter type: <MEGACO::accTerminationPowerSourceStatus> (normal abnormal) Possible values: - : the term opera status power source is none - normal : - abnormal :	The power source 1 status of this access termination <i>This element is always shown.</i>
ps2	Parameter type: <MEGACO::accTerminationPowerSourceStatus> (normal abnormal) Possible values: - : the term opera status power source is none - normal : - abnormal :	The power source 2 status of this access termination <i>This element is always shown.</i>

151.46 Voice Megaco Equipment Secondary Termination Status Commands

Command Description

This command allows the operator to show the Voice secondary termination operational status.

User Level

The command can be accessed by operators with megaco privileges.

Command Syntax

The command has the following syntax:

```
> show voice cluster (cluster-id) sharedlineterm [ (equip-id) [ port-id <Itf::MegacoPotsLine> ] ]
```

Command Parameters

Table 151.46-1 "Voice Megaco Equipment Secondary Termination Status Commands" Resource Parameters

Resource Identifier	Type	Description
(cluster-id)	Format: - the xvps cluster id - range: [1...8,11]	uniquely identify of this xvps cluster
(equip-id)	Format: - id of equipment - range: [1...32]	uniquely identify of this equipment
port-id	Parameter type: <Itf::MegacoPotsLine> Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::NewSlotId> / <Eqpt::MegacoPortId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::NewSlotId> - the LT slot number Field type <Eqpt::MegacoPortId> - the port number of Megaco	uniquely identify of this board. the CLI slot numbering method is based on logical concept. for FD shelf, CLI logic slot-id(1 to 16) is mapped to physical slot-id from 1 to 8 and 12 to 19.

Command Output

Table 151.46-2 "Voice Megaco Equipment Secondary Termination Status Commands" Display parameters

Specific Information		
name	Type	Description
termination-id	Parameter type: <MEGACO::accessTerminationId> - the termination id, if it is not specified, system will automatically assign a free one in range - range: [0...32767]	the unique identifier of the secondary termination. <i>This element is always shown.</i>
oper-status	Parameter type: <MEGACO::TerminationOperStatus> (up down shuttingdown) Possible values: - up : The operational status is up - down : the operational status is down - shuttingdown : the operational status is shuttingdown	the operational status of the secondary termination. <i>This element is always shown.</i>
admin-status	Parameter type: <MEGACO::accTerminationAdminStatus> (locked unlocked) Possible values: - locked : the admin status of termination is locked - unlocked : the admin status of termination is unlocked	the admin status of the secondary termination. <i>This element is always shown.</i>
call-status	Parameter type: <MEGACO::accTerminationCallStatus> (on-hook off-hook dialing calling connected idle-offhook busy-tone howler-tone ringing releasing ringback caller-connected callee-connected shared-cutoff) Possible values: - : the call status is unknown - on-hook : the call status is on-hook - off-hook : the call status is off-hook - dialing : the call status is dialing - calling : the call status is calling - connected : the call status is connected - idle-offhook : the call status is idle-offhook - busy-tone : the call status is busy tone - howler-tone : the call status is howler tone - ringing : the call status is ringing - releasing : the call status is releasing - ringback : the call status is releasing - caller-connected : the call status is caller connected - callee-connected : the call status is callee connected - shared-cutoff : the call status is cut off by paired termination	the call status of the secondary termination <i>This element is always shown.</i>
operstatus-downreason	Parameter type: <MEGACO::accTerminationOpDownReason> (registering registrationfailure	the reason of operational status of the secondary termination is down <i>This element is always shown.</i>

151 Voice Status Commands

name	Type	Description
	physicalfailure) Possible values: - : the term opera status down reason is none - registering : the term opera status down reason is registering - registrationfailure : the term opera status down reason is registration failure - physicalfailure : the term opera status down reason is physical failure	

151.47 Voice Megaco MGI Status Commands

Command Description

this command allows the operator to show the voice mgi operational status and the currently-associated mgc.

User Level

The command can be accessed by operators with megaco privileges.

Command Syntax

The command has the following syntax:

> show voice cluster (cluster-id) media-gateway [(media-gateway-id)]

Command Parameters

Table 151.47-1 "Voice Megaco MGI Status Commands" Resource Parameters

Resource Identifier	Type	Description
(cluster-id)	Format: - the xvps cluster id - range: [1...8,11]	uniquely identify of this xvps cluster
(media-gateway-id)	Format: - the media gateway table index - range: [1]	uniquely identify of this media gateway

Command Output

Table 151.47-2 "Voice Megaco MGI Status Commands" Display parameters

Specific Information		
name	Type	Description
oper-status	Parameter type: <MEGACO::MGIOperStatus> (up down shuttingdown) Possible values: - up : The operational status is up - down : the operational status is down - shuttingdown : the operational status is shuttingdown	the operational status of MGI <i>This element is always shown.</i>
active-mgc	Parameter type: <MEGACO::MGICtrlrActiveAddress> (primary secondary none other tertiary quaternary	the currently associated MGC <i>This element is always shown.</i>

151 Voice Status Commands

name	Type	Description
	esa) Possible values: - primary : the primary MGC is currently associated - secondary : the secondary MGC is currently associated - none : No MGC is currently associated - other : Another MGC(neither primary MGC nor secondary MGC is currently associated - tertiary : the tertiary MGC is currently associated - quaternary : the quaternary MGC is currently associated - esa : the esa MGC is currently associated	
mg-sgi	Parameter type: <MEGACO::mediaGatewaySGI> - a signed integer	the unique signaling gateway id which identifies this media gateway <i>This element is always shown.</i>
prim-mgc-ip	Parameter type: <Ip::V4Address> - IPv4-address	the ip address of the primary media gateway controller <i>This element is only shown in detail mode.</i>
prim-mgc-port	Parameter type: <MEGACO::medGwyCtrlrPrimaryUDPPort> - the primary udp port of media gateway controller - range: [1...65534]	the udp port of primary mgc <i>This element is only shown in detail mode.</i>
sec-mgc-ip	Parameter type: <Ip::V4Address> - IPv4-address	the ip address of the secondary media gateway controller <i>This element is only shown in detail mode.</i>
sec-mgc-port	Parameter type: <MEGACO::medGwyCtrlrSecondaryUDPPort> - the secondary udp port of media gateway controller - range: [1...65534]	the udp port of secondary mgc <i>This element is only shown in detail mode.</i>
tert-mgc-ip	Parameter type: <Ip::V4Address> - IPv4-address	the ip address of the tertiary media gateway controller <i>This element is only shown in detail mode.</i>
tert-mgc-port	Parameter type: <MEGACO::medGwyCtrlrTertiaryUDPPort> - the tertiary udp port of media gateway controller - range: [1...65534]	the udp port of tertiary mgc <i>This element is only shown in detail mode.</i>
quat-mgc-ip	Parameter type: <Ip::V4Address> - IPv4-address	the ip address of the quaternary media gateway controller <i>This element is only shown in detail mode.</i>
quat-mgc-port	Parameter type: <MEGACO::medGwyCtrlrQuaternaryUDPPort> - the quaternary udp port of media gateway controller - range: [1...65534]	the udp port of quaternary mgc <i>This element is only shown in detail mode.</i>
esa-mgc-ip	Parameter type: <Ip::V4Address> - IPv4-address	the ip address of the esa media gateway controller <i>This element is only shown in detail mode.</i>
esa-mgc-port	Parameter type: <MEGACO::medGwyCtrlrESAMgcUDPPort> - the esa mgc udp port of media gateway controller - range: [0...65535]	the udp port of esa mgc <i>This element is only shown in detail mode.</i>

151.48 Voice Megaco Database Status Commands

Command Description

This command allows the operator to show the voice megaco xvps database status.

User Level

The command can be accessed by operators with megaco privileges.

Command Syntax

The command has the following syntax:

> show voice cluster (cluster-id) database

Command Parameters

Table 151.48-1 "Voice Megaco Database Status Commands" Resource Parameters

Resource Identifier	Type	Description
(cluster-id)	Format: - the xvps cluster id - range: [1...8,11]	uniquely identify of this xvps cluster

Command Output

Table 151.48-2 "Voice Megaco Database Status Commands" Display parameters

Specific Information		
name	Type	Description
progress-status	Parameter type: <MEGACO::SaveStatus> (ongoing successful failed) Possible values: - ongoing : save ongoing - successful : save successful - failed : save failed	the current db save progress status of the cluster <i>This element is always shown.</i>

151.49 Voice Megaco IP Status Commands

Command Description

This command allows the operator to show the xvps signaling udp port status.

User Level

The command can be accessed by operators with megaco privileges.

Command Syntax

The command has the following syntax:

> show voice cluster (cluster-id) ip

Command Parameters

Table 151.49-1 "Voice Megaco IP Status Commands" Resource Parameters

Resource Identifier	Type	Description
(cluster-id)	Format: - the xvps cluster id - range: [1...8,11]	uniquely identify of this xvps cluster

Command Output

Table 151.49-2 "Voice Megaco IP Status Commands" Display parameters

Specific Information		
name	Type	Description
udp-port	Parameter type: <MEGACO::ivpsXLESUDPPort> - the signaling udp port of xvps - range: [0...65535]	the signaling udp port of the xvps cluster <i>This element is always shown.</i>

151.50 Voice Megaco SGI Status Commands

Command Description

this command allows the operator to show the voice sgi operational status and sctp port and the currently-associated sgi.

User Level

The command can be accessed by operators with megaco privileges.

Command Syntax

The command has the following syntax:

> show voice cluster (cluster-id) signal-gateway [(signal-gateway-id)]

Command Parameters

Table 151.50-1 "Voice Megaco SGI Status Commands" Resource Parameters

Resource Identifier	Type	Description
(cluster-id)	Format: - the xvps cluster id - range: [1...8,11]	uniquely identify of this xvps cluster
(signal-gateway-id)	Format: - the signal gateway table index - range: [1]	uniquely identify of this signal gateway

Command Output

Table 151.50-2 "Voice Megaco SGI Status Commands" Display parameters

Specific Information		
name	Type	Description
sgi-ass-asp	Parameter type: <MEGACO::SGIAssocASP> (none primary secondary both tertiary quaternary) Possible values: - none : No SGI is currently associated - primary : the primary SGI is currently associated - secondary : the secondary SGI is currently associated - both : the both SGI is currently associated - tertiary : the tertiary SGI is currently associated - quaternary : the quaternary SGI is currently associated	the currently associated SGI <i>This element is always shown.</i>

151 Voice Status Commands

name	Type	Description
sctp-port	Parameter type: <MEGACO::SGISCTPPort> - the sctp port of the signal gateway - range: [0...65535]	the sctp port of the signal gateway <i>This element is always shown.</i>
oper-status	Parameter type: <MEGACO::SGIOperStatus> (up down) Possible values: - up : The operational status is up - down : the operational status is down	the operational status of SGI <i>This element is always shown.</i>
prim-asp-ip	Parameter type: <Ip::V4Address> - IPv4-address	the ip address of the primary asp <i>This element is only shown in detail mode.</i>
prim-sctp-port	Parameter type: <MEGACO::signallingGatewayInterfacePrimarySCTPPort> - the sctp port of the primary asp - range: [1...65534]	the sctp port of primary asp <i>This element is only shown in detail mode.</i>
sec-asp-ip	Parameter type: <Ip::V4Address> - IPv4-address	the ip address of the secondary asp <i>This element is only shown in detail mode.</i>
sec-sctp-port	Parameter type: <MEGACO::signallingGatewayInterfaceSecondarySCTPPort> - the sctp port of the secondary asp - range: [1...65534]	the sctp port of secondary asp <i>This element is only shown in detail mode.</i>
tert-asp-ip	Parameter type: <Ip::V4Address> - IPv4-address	the ip address of the tertiary asp <i>This element is only shown in detail mode.</i>
tert-sctp-port	Parameter type: <MEGACO::signallingGatewayInterfaceTertiarySCTPPort> - the sctp port of the tertiary asp - range: [1...65534]	the sctp port of tertiary asp <i>This element is only shown in detail mode.</i>
quat-asp-ip	Parameter type: <Ip::V4Address> - IPv4-address	the ip address of the quaternary asp <i>This element is only shown in detail mode.</i>
quat-sctp-port	Parameter type: <MEGACO::signallingGatewayInterfaceQuaternarySCTPPort> - the sctp port of the quaternary asp - range: [1...65534]	the sctp port of quaternary asp <i>This element is only shown in detail mode.</i>

151.51 Summary of Current Operational Parameters for ONT VoIP

Command Description

This command reports a summary of current operational parameters for a specified ONT VoIP service.

User Level

The command can be accessed by operators with sip,megaco privileges.

Command Syntax

The command has the following syntax:

```
> show voice ont service [ (voip-index) ]
```

Command Parameters

Table 151.51-1 "Summary of Current Operational Parameters for ONT VoIP" Resource Parameters

Resource Identifier	Type	Description
(voip-index)	Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / 1 ng2 : <Ng2::ChannelGroup> / <Ng2::SubchannelGroup> / <Ng2::OntId> / 1) Possible values: - ng2 : ngpon2 style identification Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Eqpt::OntId> - the ONT identifier Possible values: - 1 : Gpon voip Port Field type <Ng2::ChannelGroup> - channel group number Field type <Ng2::SubchannelGroup> - subchannel group number Field type <Ng2::OntId> - the ONT identifier	a unique interface index

Resource Identifier	Type	Description
	Possible values: - 1 : Gpon voip Port	

Command Output

Table 151.51-2 "Summary of Current Operational Parameters for ONT VoIP" Display parameters

Specific Information		
name	Type	Description
net-gw-ipaddr	Parameter type: <Gpon::IpAddress> - IPv4-address	IP Address of the network media gateway. <i>This element is always shown.</i>
next-hop-addr	Parameter type: <Gpon::IpAddress> - IPv4-address	default next hop IP Address used by the VoIP Client. <i>This element is always shown.</i>
client-ipaddr	Parameter type: <Gpon::IpAddress> - IPv4-address	IP Address of the ONT VoIP Client. <i>This element is always shown.</i>
client-sub-netmask	Parameter type: <Gpon::IpAddress> - IPv4-address	subnet mask for the VoIP client's subnet. <i>This element is always shown.</i>
ftp-server-ip	Parameter type: <Gpon::IpAddress> - IPv4-address	IP Address of the FTP Server that contains the VoIP configuration files that the ONT needs to download. <i>This element is always shown.</i>
act-config-filename	Parameter type: <Gpon::FileName> - a variable length octet string defining rf band list - length: x<=49	Used to identify the name of the Actual Configuration File that the VoIP Client is using for VoIP configuration. <i>This element is always shown.</i>

151.52 Summary of Call History Operational Parameters

Command Description

This command reports current operational parameters related to call history for a POTS line.

User Level

The command can be accessed by operators with sip,megaco privileges.

Command Syntax

The command has the following syntax:

```
> show voice ont call-hist [ (ont-slot-idx) [ call-hist-num <Gpon::CallHistIndex> ] ]
```

Command Parameters

Table 151.52-1 "Summary of Call History Operational Parameters" Resource Parameters

Resource Identifier	Type	Description
(ont-slot-idx)	Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Gpon::OntSlotId> / <Gpon::OntPotsPortId> ng2 : <Ng2::ChannelGroup> / <Ng2::SubchannelGroup> / <Ng2::OntId> / <Gpon::OntSlotId> / <Gpon::OntPotsPortId>) Possible values: - ng2 : ngpon2 style identification Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Eqpt::OntId> - the ONT identifier Field type <Ng2::ChannelGroup> - channel group number Field type <Ng2::SubchannelGroup> - subchannel group number Field type <Ng2::OntId> - the ONT identifier Field type <Gpon::OntSlotId>	identification of the ont-slot (mandatory parameter)

Resource Identifier	Type	Description
	- Gpon Ont Slot - range: [1...14] Field type <Gpon::OntPotsPortId> - Gpon Ont Pots Port - range: [1...24]	
call-hist-num	Parameter type: <Gpon::CallHistIndex> Format: - pots call history number index value - range: [1...32]	number to distinguish the calls from one another. (mandatory parameter)

Command Output

Table 151.52-2 "Summary of Call History Operational Parameters" Display parameters

Specific Information		
name	Type	Description
call-date	Parameter type: <Gpon::DateTime> - printable string	Date (YY-MM-DD) when the call was initiated . <i>This element is always shown.</i>
call-time	Parameter type: <Gpon::DateTime> - printable string	Time (HH:MM:SS) when the call was initiated. <i>This element is always shown.</i>
call-duration	Parameter type: <SignedInteger> - a signed integer	Duration of call (in seconds). <i>This element is always shown.</i>
called-num	Parameter type: <Gpon::CallNum> - printable string	Called number (character string). <i>This element is always shown.</i>
calling-num	Parameter type: <Gpon::CallNum> - printable string	Calling number (character string). <i>This element is always shown.</i>
rtp-tx-pkts	Parameter type: <SignedInteger> - a signed integer	Number of RTP packets received. <i>This element is only shown in detail mode.</i>
rtp-rx-pkts	Parameter type: <SignedInteger> - a signed integer	Number of RTP packets received. <i>This element is only shown in detail mode.</i>
rtp-pkts-lost	Parameter type: <SignedInteger> - a signed integer	Number of RTP packets that were not received. <i>This element is only shown in detail mode.</i>
rtp-pkts-discard	Parameter type: <SignedInteger> - a signed integer	Number of RTP packets discarded due to errors. <i>This element is only shown in detail mode.</i>
rtp-overruns	Parameter type: <SignedInteger> - a signed integer	Number of jitter buffer over-runs. <i>This element is only shown in detail mode.</i>
rtp-underruns	Parameter type: <SignedInteger> - a signed integer	Number of jitter buffer under-runs. <i>This element is only shown in detail mode.</i>
rtp-avg-jitter	Parameter type: <SignedInteger> - a signed integer	Average jitter (msec) in the received RTP stream. <i>This element is only shown in detail mode.</i>
rtcp	Parameter type: <SignedInteger> - a signed integer	Whether or not the far end participated in RTCP. <i>This element is only shown in detail mode.</i>

name	Type	Description
rtp-pk-jitter	Parameter type: <SignedInteger> - a signed integer	Peak jitter (msec) in the received RTP stream. <i>This element is only shown in detail mode.</i>
avg-jitter	Parameter type: <SignedInteger> - a signed integer	Average jitter buffer depth (msec) for the call. <i>This element is only shown in detail mode.</i>
rtcp-xr	Parameter type: <SignedInteger> - a signed integer	Whether or not the far-end participated in RTCP-XR. <i>This element is only shown in detail mode.</i>
callhist-avg-mos	Parameter type: <Gpon::CallHistAvgMos> - pots call history average mos value - range: [-1...50]	Average Mean Opinion Score (MOS) units in tenths <i>This element is only shown in detail mode.</i>
peak-rt-delay	Parameter type: <SignedInteger> - a signed integer	Peak round trip delay (msec). <i>This element is only shown in detail mode.</i>
avg-rt-delay	Parameter type: <SignedInteger> - a signed integer	Average round trip delay (msec). <i>This element is only shown in detail mode.</i>

151.53 Voice ONT POTS MLT Test Status Command

Command Description

This command displays the mlt test results for the pots lines on the ont.

User Level

The command can be accessed by operators with sip,megaco privileges.

Command Syntax

The command has the following syntax:

> show voice ont pots diagnostics [(uni-idx)]

Command Parameters

Table 151.53-1 "Voice ONT POTS MLT Test Status Command" Resource Parameters

Resource Identifier	Type	Description
(uni-idx)	Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Gpon::OntSlotId> / <Gpon::OntPotsPortId> ng2 : <Ng2::ChannelGroup> / <Ng2::SubchannelGroup> / <Ng2::OntId> / <Gpon::OntSlotId> / <Gpon::OntPotsPortId>) Possible values: - ng2 : ngpon2 style identification Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Eqpt::OntId> - the ONT identifier Field type <Ng2::ChannelGroup> - channel group number Field type <Ng2::SubchannelGroup> - subchannel group number Field type <Ng2::OntId> - the ONT identifier Field type <Gpon::OntSlotId>	interface index of the pots uni

Resource Identifier	Type	Description
	- Gpon Ont Slot - range: [1...14] - Field type <Gpon::OntPotsPortId> - Gpon Ont Pots Port - range: [1...24]	

Command Output

Table 151.53-2 "Voice ONT POTS MLT Test Status Command" Display parameters

Specific Information		
name	Type	Description
ringer	Parameter type: <Gpon::Ringer> (failed passed) Possible values: - failed : ringer failed - passed : ringer passed	ringer pass/failure <i>This element is always shown.</i>
receiver-off-hook	Parameter type: <Gpon::RcvOffHook> (failed passed) Possible values: - failed : receiver off-hook failed - passed : receiver off-hook passed	receiver off-hook pass/failure <i>This element is always shown.</i>
resistive-faults	Parameter type: <Gpon::ResistiveFaults> (failed passed) Possible values: - failed : resistive faults failed - passed : resistive faults passed	resistive faults pass/failure <i>This element is always shown.</i>
foreign-emf	Parameter type: <Gpon::ForeignEmf> (failed passed) Possible values: - failed : foreign emf failed - passed : foreign emf passed	foreign emf pass/failure <i>This element is always shown.</i>
hazard-potential	Parameter type: <Gpon::HazardPotential> (failed passed) Possible values: - failed : hazardous potential failed - passed : hazardous potential passed	hazardous potential pass/failure <i>This element is always shown.</i>
dc-tip-ground	Parameter type: <Gpon::TestSummaryResult> (not_run failed_with_data failed_no_data passed_with_data passed_no_data) Possible values: - not_run : test not run - failed_with_data : test failed, measurement reported - failed_no_data : test failed, measurement not reported - passed_with_data : test passed, measurement reported - passed_no_data : test passed, measurement not reported	tip-ground dc voltage test summary result <i>This element is always shown.</i>
dc-ring-ground	Parameter type: <Gpon::TestSummaryResult> (not_run failed_with_data	ring-ground dc voltage test summary result <i>This element is always shown.</i>

151 Voice Status Commands

name	Type	Description
	failed_no_data passed_with_data passed_no_data) Possible values: - not_run : test not run - failed_with_data : test failed, measurement reported - failed_no_data : test failed, measurement not reported - passed_with_data : test passed, measurement reported - passed_no_data : test passed, measurement not reported	
ac-tip-ground	Parameter type: <Gpon::TestSummaryResult> (not_run failed_with_data failed_no_data passed_with_data passed_no_data) Possible values: - not_run : test not run - failed_with_data : test failed, measurement reported - failed_no_data : test failed, measurement not reported - passed_with_data : test passed, measurement reported - passed_no_data : test passed, measurement not reported	tip-ground ac voltage test summary result <i>This element is always shown.</i>
ac-ring-ground	Parameter type: <Gpon::TestSummaryResult> (not_run failed_with_data failed_no_data passed_with_data passed_no_data) Possible values: - not_run : test not run - failed_with_data : test failed, measurement reported - failed_no_data : test failed, measurement not reported - passed_with_data : test passed, measurement reported - passed_no_data : test passed, measurement not reported	ring-ground ac voltage test summary result <i>This element is always shown.</i>
tip-ground-resist	Parameter type: <Gpon::TestSummaryResult> (not_run failed_with_data failed_no_data passed_with_data passed_no_data) Possible values: - not_run : test not run - failed_with_data : test failed, measurement reported - failed_no_data : test failed, measurement not reported - passed_with_data : test passed, measurement reported - passed_no_data : test passed, measurement not reported	tip-ground resistance test summary result <i>This element is always shown.</i>
ring-ground-resist	Parameter type: <Gpon::TestSummaryResult> (not_run failed_with_data failed_no_data passed_with_data passed_no_data) Possible values: - not_run : test not run - failed_with_data : test failed, measurement reported - failed_no_data : test failed, measurement not reported - passed_with_data : test passed, measurement reported - passed_no_data : test passed, measurement not reported	ring-ground resistance test summary result <i>This element is always shown.</i>

name	Type	Description
tip-ring-resist	Parameter type: <Gpon::TestSummaryResult> (not_run failed_with_data failed_no_data passed_with_data passed_no_data) Possible values: - not_run : test not run - failed_with_data : test failed, measurement reported - failed_no_data : test failed, measurement not reported - passed_with_data : test passed, measurement reported - passed_no_data : test passed, measurement not reported	tip-ring resistance test summary result <i>This element is always shown.</i>
ringer-load	Parameter type: <Gpon::TestSummaryResult> (not_run failed_with_data failed_no_data passed_with_data passed_no_data) Possible values: - not_run : test not run - failed_with_data : test failed, measurement reported - failed_no_data : test failed, measurement not reported - passed_with_data : test passed, measurement reported - passed_no_data : test passed, measurement not reported	tip-ring resistance test summary result <i>This element is always shown.</i>
meas-dc-tip-ground	Parameter type: <Gpon::DcMeasure> - dc voltage measurement in volts.Valid only if test summary result is failed with data or passed with data. - unit: volts - range: [-32768...32768]	tip ground dc voltage measurement in volts <i>This element is always shown.</i>
meas-dc-ring-ground	Parameter type: <Gpon::DcMeasure> - dc voltage measurement in volts.Valid only if test summary result is failed with data or passed with data. - unit: volts - range: [-32768...32768]	ring ground dc voltage measurement in volts <i>This element is always shown.</i>
meas-ac-tip-ground	Parameter type: <Gpon::AcMeasure> - ac voltage measurement in volts rms.Valid only if test summary result is failed with data or passed with data. - unit: volts RMS - range: [0...255]	ac voltage measurement in volts rms <i>This element is always shown.</i>
meas-ac-ring-ground	Parameter type: <Gpon::AcMeasure> - ac voltage measurement in volts rms.Valid only if test summary result is failed with data or passed with data. - unit: volts RMS - range: [0...255]	ac voltage measurement in volts rms <i>This element is always shown.</i>
meas-tip-ground-resist	Parameter type: <Gpon::ResistanceMeasure> - resistance measurement in ohms.Valid only if test summary result is failed with data or passed with data. - unit: ohms - range: [0...65535]	resistance measurement in ohms <i>This element is always shown.</i>
meas-rng-ground-resist	Parameter type: <Gpon::ResistanceMeasure> - resistance measurement in ohms.Valid only if test summary result is failed with data or passed with data. - unit: ohms - range: [0...65535]	resistance measurement in ohms <i>This element is always shown.</i>
meas-tip-ring-resist	Parameter type: <Gpon::ResistanceMeasure> - resistance measurement in ohms.Valid only if test summary result is failed with data or passed with data.	resistance measurement in ohms <i>This element is always shown.</i>

151 Voice Status Commands

name	Type	Description
	- unit: ohms - range: [0...65535]	
meas-ringer-load	Parameter type: <Gpon::RingerLoadMeasure> - ringer load measurement in 0.1rens.Valid only if test summary result is failed with data or passed with data. - unit: REN - range: [0...25.5]	ringer load measurement in 0.1rens <i>This element is always shown.</i>

151.54 Voice ONT POTS PB Dialtone Test Status Command

Command Description

This command displays the pull or break dial tone test results for the pots lines on the ont.

User Level

The command can be accessed by operators with sip,megaco privileges.

Command Syntax

The command has the following syntax:

```
> show voice ont pots pb-dial-tone [ (uni-idx) ]
```

Command Parameters

Table 151.54-1 "Voice ONT POTS PB Dialtone Test Status Command" Resource Parameters

Resource Identifier	Type	Description
(uni-idx)	Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Gpon::OntSlotId> / <Gpon::OntPotsPortId> ng2 : <Ng2::ChannelGroup> / <Ng2::SubchannelGroup> / <Ng2::OntId> / <Gpon::OntSlotId> / <Gpon::OntPotsPortId>) Possible values: - ng2 : ngpon2 style identification Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Eqpt::OntId> - the ONT identifier Field type <Ng2::ChannelGroup> - channel group number Field type <Ng2::SubchannelGroup> - subchannel group number Field type <Ng2::OntId> - the ONT identifier Field type <Gpon::OntSlotId>	interface index of the pots uni

Resource Identifier	Type	Description
	- Gpon Ont Slot - range: [1...14] Field type <Gpon::OntPotsPortId> - Gpon Ont Pots Port - range: [1...24]	

Command Output

Table 151.54-2 "Voice ONT POTS PB DIALTONE Test Status Command" Display parameters

Specific Information		
name	Type	Description
pull-result	Parameter type: <Gpon::PullResult> (not_run failed_no_data slow_no_data passed_no_data failed_with_data slow_with_data passed_with_data) Possible values: - not_run : ont did not run test - failed_no_data : test failed to draw dialtone, no measurement reported - slow_no_data : slow draw of dialtone, no measurement reported - passed_no_data : test passed, no measurement reported - failed_with_data : test failed to draw dialtone, measurement reported - slow_with_data : slow draw of dialtone, measurement reported - passed_with_data : test passed, measurement reported	result of the make part of the dialtone test <i>This element is always shown.</i>
pull-measure	Parameter type: <Gpon::PullorBreakMeasure> - measured time to make or break dialtone from the make-break dialtone test in 0.1secs.Valid only if the test result is failed with data or slow with data or passed with data. - unit: sec - range: [0...25.5]	measured time to make dialtone from the make-break dialtone test in 0.1secs <i>This element is always shown.</i>
break-result	Parameter type: <Gpon::BreakResult> (not_run failed_no_data slow_no_data passed_no_data failed_with_data slow_with_data passed_with_data) Possible values: - not_run : ont did not run test - failed_no_data : test failed to break dialtone, no measurement reported - slow_no_data : slow break of dialtone, no measurement reported - passed_no_data : test passed, no measurement reported - failed_with_data : test failed to break dialtone, measurement reported - slow_with_data : slow break of dialtone, measurement	result of the break part of the dialtone test <i>This element is always shown.</i>

name	Type	Description
	reported - passed_with_data : test passed, measurement reported	
break-measure	Parameter type: <Gpon::PullorBreakMeasure> - measured time to make or break dialtone from the make-break dialtone test in 0.1secs.Valid only if the test result is failed with data or slow with data or passed with data. - unit: sec - range: [0...25.5]	measured time to break dialtone from the make-break dialtone test in 0.1secs <i>This element is always shown.</i>

151.55 Voice ONT POTS SIP Dialtone Test Status Command

Command Description

This command displays SIP pull-break dialtone test results for the pots lines on the ont.

User Level

The command can be accessed by operators with sip,megaco privileges.

Command Syntax

The command has the following syntax:

> show voice ont pots sip-dial-tone [(uni-idx)]

Command Parameters

Table 151.55-1 "Voice ONT POTS SIP Dialtone Test Status Command" Resource Parameters

Resource Identifier	Type	Description
(uni-idx)	Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Gpon::OntSlotId> / <Gpon::OntPotsPortId> ng2 : <Ng2::ChannelGroup> / <Ng2::SubchannelGroup> / <Ng2::OntId> / <Gpon::OntSlotId> / <Gpon::OntPotsPortId>) Possible values: - ng2 : ngpon2 style identification Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Eqpt::OntId> - the ONT identifier Field type <Ng2::ChannelGroup> - channel group number Field type <Ng2::SubchannelGroup> - subchannel group number Field type <Ng2::OntId> - the ONT identifier Field type <Gpon::OntSlotId>	interface index of the pots uni

Resource Identifier	Type	Description
	- Gpon Ont Slot - range: [1...14] Field type <Gpon::OntPotsPortId> - Gpon Ont Pots Port - range: [1...24]	

Command Output

Table 151.55-2 "Voice ONT POTS SIP Dialtone Test Status Command" Display parameters

Specific Information		
name	Type	Description
summary-result	Parameter type: <Gpon::SipSummaryResult> (failed passed not_forced not_run) Possible values: - failed : failed - passed : passed - not_forced : ont did not run test and test mode was not forced - not_run : ont did not run the test	summary result of the sip dial tone test <i>This element is always shown.</i>
delay	Parameter type: <Gpon::SipDelayMeasure> - measured post delay in tenth of a second - unit: sec - range: [0...6553.5]	measured post delay in tenth of a second <i>This element is always shown.</i>
result-text	Parameter type: <Gpon::SipResultText> - readable text regarding the result of the test - length: x<=29	readable text regarding the result of the test <i>This element is always shown.</i>

151.56 Summary of Actual Operational data for ONT VoIP Config Command

Command Description

This command retrieves the actual operational data from an ONT's VOIP configuration

User Level

The command can be accessed by operators with sip,megaco privileges.

Command Syntax

The command has the following syntax:

```
> show voice ont pots operational-data [ (uni-index) ]
```

Command Parameters

Table 151.56-1 "Summary of Actual Operational data for ONT VoIP Config Command" Resource Parameters

Resource Identifier	Type	Description
(uni-index)	Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Gpon::OntSlotId> / <Gpon::OntPotsPortId> ng2 : <Ng2::ChannelGroup> / <Ng2::SubchannelGroup> / <Ng2::OntId> / <Gpon::OntSlotId> / <Gpon::OntPotsPortId>) Possible values: - ng2 : ngpon2 style identification Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Eqpt::OntId> - the ONT identifier Field type <Ng2::ChannelGroup> - channel group number Field type <Ng2::SubchannelGroup> - subchannel group number Field type <Ng2::OntId> - the ONT identifier	interface index of the ces ont uni

Resource Identifier	Type	Description
	Field type <Gpon::OntSlotId> - Gpon Ont Slot - range: [1...14] Field type <Gpon::OntPotsPortId> - Gpon Ont Pots Port - range: [1...24]	

Command Output

Table 151.56-2 "Summary of Actual Operational data for ONT VoIP Config Command" Display parameters

Specific Information		
name	Type	Description
codec	Parameter type: <Gpon::Codec> (pcmu unknown unknown gsm g723 dvi4.8 dvi4.16 lpc pcma g722 l16.2 l16.1 qcelp cn mpa g728 dvi4.11 dvi4.22 g729 unknown unsupported) Possible values: - pcmu : clock rate of 8k Hz - unknown : reserved - unknown : reserved - gsm : clock rate of 8k Hz - g723 : clock rate of 8k Hz - dvi4.8 : clock rate of 8k Hz - dvi4.16 : clock rate of 16000 Hz - lpc : clock rate of 8k Hz - pcma : clock rate of 8k Hz - g722 : clock rate of 8k Hz - l16.2 : clock rate of 41000 Hz - l16.1 : clock rate of 41000 Hz - qcelp : clock rate of 8k Hz - cn : clock rate of 8k Hz - mpa : clock rate of 90K Hz - g728 : clock rate of 8k Hz - dvi4.11 : clock rate of 11025 Hz - dvi4.22 : clock rate of 22050 Hz - g729 : clock rate of 8k Hz - unknown : OLT cannot communicate with ONT for OMCI	Indicates the current codec used for the VoIP POTS port, per IETF RFC 3551 <i>This element is always shown.</i>

151 Voice Status Commands

name	Type	Description
	discovery purposes - unsupported : ONT does NOT support GET of this attribute	
server-session	Parameter type: <Gpon::serverSession> (init reg insep fricmp frtcp frauth ftime frserv fiicmp fitcp fiauth fitime fiserv notconf conf disabld unknown unsupported) Possible values: - init : None or Initial - reg : Registered - insep : In session - fricmp : Failed Registration - ICMP Error - frtcp : Failed Registration - Failed TCP - frauth : Failed Registration - Failed Authentication - ftime : Failed Registration - Timeout - frserv : Failed Registration - Server Fail Code - fiicmp : Failed Invite - ICMP Error - fitcp : Failed Invite - Failed TCP - fiauth : Failed Invite - Failed Authentication - fitime : Failed Invite - Timeout - fiserv : Failed Invite - Server Fail Code - notconf : Port Not Configured - conf : Configuration Done - disabld : Disable by switch - unknown : OLT cannot communicate with ONT for OMCI discovery purposes - unsupported : ONT does NOT support GET of this attribute	Indicates the current status of the voip session for this pots port <i>This element is always shown.</i>
port-session	Parameter type: <Gpon::portSession> (idle twoWay threeWay fax telmet conf unknown unsupported) Possible values: - idle : None or IDLE - twoWay : Two Way Call - threeWay : Three Way Call - fax : Fax Call - ICMP Error	Indicates the current state of the VoIP POTS port session: <i>This element is always shown.</i>

name	Type	Description
	- telmet : Telemetry Call - conf : Conference Call - unknown : OLT cannot communicate with ONT for OMCI discovery purposes - unsupported : ONT does NOT support GET of this attribute	
pkt-period1	Parameter type: <Gpon::PktPeriod> (unknown unsupported <Gpon::PktPeriod>) Possible values: - unknown : OLT cannot communicate with ONT for OMCI discovery purposes - unsupported : ONT does NOT support GET of this attribute Field type <Gpon::PktPeriod> - packet period interval - unit: 1/1000 sec - range: [0...65537]	Indicates the packet period for the first call on the VoIP POTS port <i>This element is always shown.</i>
pkt-period2	Parameter type: <Gpon::PktPeriod> (unknown unsupported <Gpon::PktPeriod>) Possible values: - unknown : OLT cannot communicate with ONT for OMCI discovery purposes - unsupported : ONT does NOT support GET of this attribute Field type <Gpon::PktPeriod> - packet period interval - unit: 1/1000 sec - range: [0...65537]	Indicates the packet period for the second call on the VoIP POTS port <i>This element is always shown.</i>
destaddr1	Parameter type: <Gpon::destAddr> (unknown unsupported <Gpon::destAddr>) Possible values: - unknown : OLT cannot communicate with ONT for OMCI discovery purposes - unsupported : ONT does NOT support GET of this attribute Field type <Gpon::destAddr> - destination address for the second call on the VoIP POTS - length: x<=25	Indicates the destination address for the first call on the VoIP POTS port <i>This element is always shown.</i>
destaddr2	Parameter type: <Gpon::destAddr> (unknown unsupported <Gpon::destAddr>) Possible values: - unknown : OLT cannot communicate with ONT for OMCI discovery purposes - unsupported : ONT does NOT support GET of this attribute Field type <Gpon::destAddr> - destination address for the second call on the VoIP POTS - length: x<=25	Indicates the destination address for the second call on the VoIP POTS port <i>This element is always shown.</i>
line-state	Parameter type: <Gpon::lineStatus>	Indicates the current status of the

151 Voice Status Commands

name	Type	Description
	(idle off-hook dialling ringalert ringback cnncting cnncted discnnt offhook-no-tone offhook-tone unknown unknown unsupported) Possible values: - idle : Idle or on-hook - off-hook : Off-hook dial tone - dialling : Dialling - ringalert : Ringing or FSK alerting/data - ringback : Audible ringback - cnncting : Connecting - cnncted : Connected - discnnt : Disconnecting, audible indication - offhook-no-tone : Receiver off hook (ROH), no tone - offhook-tone : Receiver off hook (ROH) with tone - unknown : Unknown or undefined - unknown : OLT cannot communicate with ONT for OMCI discovery purposes - unsupported : ONT does NOT support GET of this attribute	voip line for this pots port <i>This element is only shown in detail mode.</i>

151.57 Voice ONT POTS Hook State Command

Command Description

This command displays the hook state for the pots lines on the ont.

User Level

The command can be accessed by operators with sip,megaco privileges.

Command Syntax

The command has the following syntax:

```
> show voice ont pots hookstate [ (uni-idx) ]
```

Command Parameters

Table 151.57-1 "Voice ONT POTS Hook State Command" Resource Parameters

Resource Identifier	Type	Description
(uni-idx)	Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Gpon::OntSlotId> / <Gpon::OntPotsPortId> ng2 : <Ng2::ChannelGroup> / <Ng2::SubchannelGroup> / <Ng2::OntId> / <Gpon::OntSlotId> / <Gpon::OntPotsPortId>) Possible values: - ng2 : ngpon2 style identification Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Eqpt::OntId> - the ONT identifier Field type <Ng2::ChannelGroup> - channel group number Field type <Ng2::SubchannelGroup> - subchannel group number Field type <Ng2::OntId> - the ONT identifier Field type <Gpon::OntSlotId> - Gpon Ont Slot - range: [1...14] Field type <Gpon::OntPotsPortId>	interface index of the pots uni

Resource Identifier	Type	Description
	- Gpon Ont Pots Port - range: [1...24]	

Command Output

Table 151.57-2 "Voice ONT POTS Hook State Command" Display parameters

Specific Information		
name	Type	Description
hook-state	Parameter type: <Gpon::HookState> (on-hook off-hook unknown unsupported) Possible values: - on-hook : on-hook - off-hook : off-hook - unknown : OLT cannot communicate with ONT for OMCI discovery purposes - unsupported : ONT does NOT support GET of this attribute	hook state <i>This element is always shown.</i>

151.58 Voice TC Olt-side Current Interval Status Command

Command Description

This command displays the entries of the voice oltside tc's current interval.

User Level

The command can be accessed by operators with sip,megaco privileges.

Command Syntax

The command has the following syntax:

```
> show voice ont pots tc-layer olt-side current-interval [ (uni-index) ]
```

Command Parameters

Table 151.58-1 "Voice TC Olt-side Current Interval Status Command" Resource Parameters

Resource Identifier	Type	Description
(uni-index)	Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / 1 ng2 : <Ng2::ChannelGroup> / <Ng2::SubchannelGroup> / <Ng2::OntId> / 1) Possible values: - ng2 : ngpon2 style identification Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Eqpt::OntId> - the ONT identifier Possible values: - 1 : Gpon voip Port Field type <Ng2::ChannelGroup> - channel group number Field type <Ng2::SubchannelGroup> - subchannel group number Field type <Ng2::OntId> - the ONT identifier Possible values:	gpon ont index

Resource Identifier	Type	Description
	- 1 : Gpon voip Port	

Command Output

Table 151.58-2 "Voice TC Olt-side Current Interval Status Command" Display parameters

Specific Information		
name	Type	Description
lost-frags-up	Parameter type: <Counter> - 32 bit counter	a count of lost gem fragments upstream <i>This element is always shown.</i>
receive-frags	Parameter type: <Counter> - 32 bit counter	a count of received gem fragments <i>This element is always shown.</i>
transmit-frags	Parameter type: <Counter> - 32 bit counter	a count of transmitted gem fragments <i>This element is always shown.</i>
receive-blocks	Parameter type: <Counter> - 32 bit counter	a count of received gem blocks <i>This element is always shown.</i>
transmit-blocks	Parameter type: <Counter> - 32 bit counter	a count of transmitted gem blocks <i>This element is always shown.</i>

151.59 Voice TC Olt-side Previous Interval Status Command

Command Description

This command displays the entries of the voice oltside tc's previous interval.

User Level

The command can be accessed by operators with sip,megaco privileges.

Command Syntax

The command has the following syntax:

```
> show voice ont pots tc-layer olt-side previous-interval [ (uni-index) [ interval-nbr <Gpon::UniIntervalnbr> ] ]
```

Command Parameters

Table 151.59-1 "Voice TC Olt-side Previous Interval Status Command" Resource Parameters

Resource Identifier	Type	Description
(uni-index)	Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / 1 ng2 : <Ng2::ChannelGroup> / <Ng2::SubchannelGroup> / <Ng2::OntId> / 1) Possible values: - ng2 : ngpon2 style identification Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Eqpt::OntId> - the ONT identifier Possible values: - 1 : Gpon voip Port Field type <Ng2::ChannelGroup> - channel group number Field type <Ng2::SubchannelGroup> - subchannel group number Field type <Ng2::OntId> - the ONT identifier Possible values:	gpon ont index

Resource Identifier	Type	Description
	- 1 : Gpon voip Port	
interval-nbr	Parameter type: <Gpon::UniIntervalnbr> Format: - the interval number - range: [1...32]	the interval number

Command Output

Table 151.59-2 "Voice TC Olt-side Previous Interval Status Command" Display parameters

Specific Information		
name	Type	Description
lost-frags-up	Parameter type: <Counter> - 32 bit counter	a count of lost gem fragments upstream <i>This element is always shown.</i>
receive-frags	Parameter type: <Counter> - 32 bit counter	a count of received gem fragments <i>This element is always shown.</i>
transmit-frags	Parameter type: <Counter> - 32 bit counter	a count of transmitted gem fragments <i>This element is always shown.</i>
receive-blocks	Parameter type: <Counter> - 32 bit counter	a count of received gem blocks <i>This element is always shown.</i>
transmit-blocks	Parameter type: <Counter> - 32 bit counter	a count of transmitted gem blocks <i>This element is always shown.</i>

151.60 Voice TC Ont-side Current Interval Status Command

Command Description

This command displays the entries of the voice outside tc's current interval.

User Level

The command can be accessed by operators with sip,megaco privileges.

Command Syntax

The command has the following syntax:

```
> show voice ont pots tc-layer ont-side current-interval [ (uni-index) ]
```

Command Parameters

Table 151.60-1 "Voice TC Ont-side Current Interval Status Command" Resource Parameters

Resource Identifier	Type	Description
(uni-index)	Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / 1 ng2 : <Ng2::ChannelGroup> / <Ng2::SubchannelGroup> / <Ng2::OntId> / 1) Possible values: - ng2 : ngpon2 style identification Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Eqpt::OntId> - the ONT identifier Possible values: - 1 : Gpon voip Port Field type <Ng2::ChannelGroup> - channel group number Field type <Ng2::SubchannelGroup> - subchannel group number Field type <Ng2::OntId> - the ONT identifier Possible values:	gpon ont index

Resource Identifier	Type	Description
	- 1 : Gpon voip Port	

Command Output

Table 151.60-2 "Voice TC Ont-side Current Interval Status Command" Display parameters

Specific Information		
name	Type	Description
lost-frags-down	Parameter type: <Counter> - 32 bit counter	a count of lost gem fragments downstream <i>This element is always shown.</i>
lost-frags-up	Parameter type: <Counter> - 32 bit counter	a count of lost gem fragments upstream <i>This element is always shown.</i>
receive-frags	Parameter type: <Counter> - 32 bit counter	a count of received gem fragments <i>This element is always shown.</i>
transmit-frags	Parameter type: <Counter> - 32 bit counter	a count of transmitted gem fragments <i>This element is always shown.</i>
receive-blocks	Parameter type: <Counter> - 32 bit counter	a count of received gem blocks <i>This element is always shown.</i>
transmit-blocks	Parameter type: <Counter> - 32 bit counter	a count of transmitted gem blocks <i>This element is always shown.</i>

151.61 Voice TC Ont-side Previous Interval Status Command

Command Description

This command displays the entries of the voice outside tc's previous interval.

User Level

The command can be accessed by operators with sip,megaco privileges.

Command Syntax

The command has the following syntax:

```
> show voice ont pots tc-layer ont-side previous-interval [ (uni-index) [ interval-nbr <Gpon::UniIntervalnbr> ] ]
```

Command Parameters

Table 151.61-1 "Voice TC Ont-side Previous Interval Status Command" Resource Parameters

Resource Identifier	Type	Description
(uni-index)	Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / 1 ng2 : <Ng2::ChannelGroup> / <Ng2::SubchannelGroup> / <Ng2::OntId> / 1) Possible values: - ng2 : ngpon2 style identification Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Eqpt::OntId> - the ONT identifier Possible values: - 1 : Gpon voip Port Field type <Ng2::ChannelGroup> - channel group number Field type <Ng2::SubchannelGroup> - subchannel group number Field type <Ng2::OntId> - the ONT identifier Possible values:	gpon ont index

151 Voice Status Commands

Resource Identifier	Type	Description
	- 1 : Gpon voip Port	
interval-nbr	Parameter type: <Gpon::UniIntervalnbr> Format: - the interval number - range: [1...32]	the interval number

Command Output

Table 151.61-2 "Voice TC Ont-side Previous Interval Status Command" Display parameters

Specific Information		
name	Type	Description
lost-frags-down	Parameter type: <Counter> - 32 bit counter	a count of lost gem fragments downstream <i>This element is always shown.</i>
lost-frags-up	Parameter type: <Counter> - 32 bit counter	a count of lost gem fragments upstream <i>This element is always shown.</i>
receive-frags	Parameter type: <Counter> - 32 bit counter	a count of received gem fragments <i>This element is always shown.</i>
transmit-frags	Parameter type: <Counter> - 32 bit counter	a count of transmitted gem fragments <i>This element is always shown.</i>
receive-blocks	Parameter type: <Counter> - 32 bit counter	a count of received gem blocks <i>This element is always shown.</i>
transmit-blocks	Parameter type: <Counter> - 32 bit counter	a count of transmitted gem blocks <i>This element is always shown.</i>

151.62 GPON Voip Configuration Status Command

Command Description

This command retrieves the actual operational data from an ONT VOIP configuration

User Level

The command can be accessed by operators with sip,megaco privileges.

Command Syntax

The command has the following syntax:

```
> show voice ont voip-config operational-data [ (voip-index) ]
```

Command Parameters

Table 151.62-1 "GPON Voip Configuration Status Command" Resource Parameters

Resource Identifier	Type	Description
(voip-index)	Format: (ont : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Gpon::IpHostID> ont:ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / <Ng2::IpHostID>) Possible values: - ont:ng2 : ngpon2 ont - ont : ont Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Eqpt::OntId> - the ONT identifier Field type <Eqpt::ChannelGroupId> - the channel group identifier Field type <Eqpt::SubChannelGroupId> - the subchannel group identifier Field type <Eqpt::Ng2OntId> - the NG2 ONT identifier Field type <Gpon::IpHostID> - iphost id Field type <Ng2::IpHostID> - iphost id (ngpon2)	a unique interface index

Command Output

Table 151.62-2 "GPON Voip Configuration Status Command" Display parameters

Specific Information		
name	Type	Description
config-status	Parameter type: <Gpon::ConfigStatus> (inactive active initializing fault unknown not-supported) Possible values: - inactive : ont reported the configuration retrieval has not been attempted - active : ont reported that the configuration has been retrieved - initializing : ont reported that the configuration is being retrieved - fault : ont reported - unknown : cant reach the ont or the ont didnt return a response to the query - not-supported : not supported	Retrieval status of the VOIP configuration <i>This element is always shown.</i>
profile-version	Parameter type: <Gpon::ProfVersion> (null <PrintableString>) Possible values: - null : ONT reported that no version was reported Field type <PrintableString> - printable string	profile version <i>This element is always shown.</i>

Only Show Details: voip signalling protocols		
name	Type	Description
is-valid	Parameter type: <Gpon::SigValidity> (true false) Possible values: - true : voip signalling protocol details are valid - false : voip signalling protocol details are not valid	indicates whether the available voip signalling protocols is valid or not <i>This element is only shown in detail mode.</i>
sip-client	Parameter type: <Gpon::SipClient> (not-supported supported) Possible values: - not-supported : sip client is not supported - supported : sip client is supported	sip-client support <i>This element is only shown in detail mode.</i>
h248-client	Parameter type: <Gpon::H248Client> (not-supported supported) Possible values: - not-supported : h248 client is not supported - supported : h248 client is supported	h248-client support <i>This element is only shown in detail mode.</i>
mgcp-client	Parameter type: <Gpon::MgcpClient> (not-supported supported) Possible values: - not-supported : mgcp client is not supported	mgcp-client support <i>This element is only shown in detail mode.</i>

name	Type	Description
	- supported : mgcp client is supported	

Only Show Details: voip configuration methods		
name	Type	Description
is-valid-config	Parameter type: <Gpon::ConfValidity> (true false) Possible values: - true : voip configuration method details are valid - false : voip configuration method details are not valid	indicates whether the available voip configuration methods is valid or not <i>This element is only shown in detail mode.</i>
omci-support	Parameter type: <Gpon::Omci> (not-supported supported) Possible values: - not-supported : omci client is not supported - supported : omci client is supported	omci support <i>This element is only shown in detail mode.</i>
file-support	Parameter type: <Gpon::File> (not-supported supported) Possible values: - not-supported : file client is not supported - supported : file client is supported	file support <i>This element is only shown in detail mode.</i>
tr69-support	Parameter type: <Gpon::Tr69> (not-supported supported) Possible values: - not-supported : tr69 client is not supported - supported : tr69 client is supported	tr69 support <i>This element is only shown in detail mode.</i>
sipping-support	Parameter type: <Gpon::Sipping> (not-supported supported) Possible values: - not-supported : sipping server framework is not supported - supported : sipping server framework is supported	sipping server framework support <i>This element is only shown in detail mode.</i>
hybrid-support	Parameter type: <Gpon::Hybrid> (not-supported supported) Possible values: - not-supported : hybrid mix of omci and file transfer is not supported - supported : hybrid mix of omci and file transfer is supported	alu hybrid mix of omci and file transfer support <i>This element is only shown in detail mode.</i>

151.63 Voice GPON POTS RTP Current Statistics Command

Command Description

This command allows the operator to show the GPON POTS RTP Performance Statistics for current 15 minutes interval

User Level

The command can be accessed by operators with sip,megaco privileges.

Command Syntax

The command has the following syntax:

```
> show voice ont pots-rtp statistics current-15min [ (uni-index) ]
```

Command Parameters

Table 151.63-1 "Voice GPON POTS RTP Current Statistics Command" Resource Parameters

Resource Identifier	Type	Description
(uni-index)	Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Gpon::OntSlotId> / <Gpon::OntPotsPortId> ng2 : <Ng2::ChannelGroup> / <Ng2::SubchannelGroup> / <Ng2::OntId> / <Gpon::OntSlotId> / <Gpon::OntPotsPortId>) Possible values: - ng2 : ngpon2 style identification Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Eqpt::OntId> - the ONT identifier Field type <Ng2::ChannelGroup> - channel group number Field type <Ng2::SubchannelGroup> - subchannel group number Field type <Ng2::OntId> - the ONT identifier	gpon ont port index

Resource Identifier	Type	Description
	Field type <Gpon::OntSlotId> - Gpon Ont Slot - range: [1...14] Field type <Gpon::OntPotsPortId> - Gpon Ont Pots Port - range: [1...24]	

Command Output

Table 151.63-2 "Voice GPON POTS RTP Current Statistics Command" Display parameters

Specific Information		
name	Type	Description
rtp-errors	Parameter type: <Counter> - 32 bit counter	count of rtp packet errors during this interval <i>This element is always shown.</i>
packet-loss	Parameter type: <Counter> - 32 bit counter	fraction of packets lost during this interval <i>This element is always shown.</i>
max-jitter	Parameter type: <Counter> - 32 bit counter	maximum jitter identified during this interval <i>This element is always shown.</i>
max-rtcp-int	Parameter type: <Counter> - 32 bit counter	maximum time between RTCP packets during the measured interval during this interval <i>This element is always shown.</i>
buff-underflow	Parameter type: <Counter> - 32 bit counter	Counts the number of times the reassembly buffer underflows during this interval <i>This element is always shown.</i>
buff-overflow	Parameter type: <Counter> - 32 bit counter	Counts the number of times the reassembly buffer overflows during this interval <i>This element is always shown.</i>

151.64 Voice GPON POTS RTP Prev Statistics

Command

Command Description

This command allows the operator to show the GPON POTS RTP Performance Statistics for previous 15 minutes interval

User Level

The command can be accessed by operators with sip,megaco privileges.

Command Syntax

The command has the following syntax:

```
> show voice ont pots-rtp statistics prev-15min [ (uni-index) [ interval-num <Pots::IntervalNumber15min> ] ]
```

Command Parameters

Table 151.64-1 "Voice GPON POTS RTP Prev Statistics Command" Resource Parameters

Resource Identifier	Type	Description
(uni-index)	Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Gpon::OntSlotId> / <Gpon::OntPortId> ng2 : <Ng2::ChannelGroup> / <Ng2::SubchannelGroup> / <Ng2::OntId> / <Gpon::OntSlotId> / <Gpon::OntPortId>) Possible values: - ng2 : ngpon2 style identification Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Ng2::ChannelGroup> - channel group number Field type <Ng2::SubchannelGroup> - subchannel group number Field type <Eqpt::OntId> - the ONT identifier Field type <Ng2::OntId> - the ONT identifier Field type <Gpon::OntSlotId>	gpon ont port index

Resource Identifier	Type	Description
	- Gpon Ont Slot - range: [1...14] Field type <Gpon::OntPortId> - Gpon Ont Port - range: [1...16]	
interval-num	Parameter type: <Pots::IntervalNumber15min> Format: - the interval number - range: [1...32]	the interval number

Command Output

Table 151.64-2 "Voice GPON POTS RTP Prev Statistics Command" Display parameters

Specific Information		
name	Type	Description
rtp-errors	Parameter type: <Counter> - 32 bit counter	count of rtp packet errors during this interval <i>This element is always shown.</i>
packet-loss	Parameter type: <Counter> - 32 bit counter	fraction of packets lost during this interval <i>This element is always shown.</i>
max-jitter	Parameter type: <Counter> - 32 bit counter	maximum jitter identified during this interval <i>This element is always shown.</i>
max-rtcp-int	Parameter type: <Counter> - 32 bit counter	maximum time between RTCP packets during the measured interval during this interval <i>This element is always shown.</i>
buff-underflow	Parameter type: <Counter> - 32 bit counter	Counts the number of times the reassembly buffer underflows during this interval <i>This element is always shown.</i>
buff-overflow	Parameter type: <Counter> - 32 bit counter	Counts the number of times the reassembly buffer overflows during this interval <i>This element is always shown.</i>

151.65 Current Interval PM stats of ONT MGC Agent Command

Command Description

This command allows the operator to show the Gpon MGC Agent Performance Statistics for current 15 minutes interval

User Level

The command can be accessed by operators with sip,megaco privileges.

Command Syntax

The command has the following syntax:

```
> show voice ont mgc-agent statistics current-15min [ (index) ]
```

Command Parameters

Table 151.65-1 "Current Interval PM stats of ONT MGC Agent Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / 1 ng2 : <Ng2::ChannelGroup> / <Ng2::SubchannelGroup> / <Ng2::OntId> / 1) Possible values: - ng2 : ngpon2 style identification Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Eqpt::OntId> - the ONT identifier Possible values: - 1 : Gpon voip Port Field type <Ng2::ChannelGroup> - channel group number Field type <Ng2::SubchannelGroup> - subchannel group number Field type <Ng2::OntId> - the ONT identifier	ifindex of iphost uni

Resource Identifier	Type	Description
	Possible values: - 1 : Gpon voip Port	

Command Output

Table 151.65-2 "Current Interval PM stats of ONT MGC Agent Command" Display parameters

Specific Information		
name	Type	Description
rx-msgs	Parameter type: <Counter> - 32 bit counter	A count number of received Megaco messages on this association, as defined by ITU-T H.341 <i>This element is always shown.</i>
rx-octets	Parameter type: <Counter> - 32 bit counter	A count of total number of octets received over this association, as defined by ITU-T H.341. <i>This element is always shown.</i>
tx-msgs	Parameter type: <Counter> - 32 bit counter	A count of number of sent Megaco messages on this association, as defined by ITU-T H.341. <i>This element is always shown.</i>
tx-octets	Parameter type: <Counter> - 32 bit counter	A count of total number of octets sent over this association, as defined by ITU-T H.341 <i>This element is always shown.</i>
protocol-err	Parameter type: <Counter> - 32 bit counter	A count of total number of errors detected on this association, as defined by ITU-T H.341 <i>This element is always shown.</i>
tx-losses	Parameter type: <Counter> - 32 bit counter	A count of total number of transport losses <i>This element is always shown.</i>
last-event	Parameter type: <Counter> - 32 bit counter	This attribute reports the last detected event on this association <i>This element is always shown.</i>
last-event-time	Parameter type: <Counter> - 32 bit counter	This attribute reports the time in seconds since the last event on this association was detected, as defined by ITU-T H.341 <i>This element is always shown.</i>
last-reset-time	Parameter type: <Counter> - 32 bit counter	This attribute reports the time in seconds since these statistics were last reset, as defined by ITU-T H.341 <i>This element is always shown.</i>

151.66 Voice Gpon POTS Call Statistics Command for Current 15 Minutes

Command Description

This command allows the operator to show the Gpon POTS Call Performance Statistics for current 15 minutes interval

User Level

The command can be accessed by operators with sip,megaco privileges.

Command Syntax

The command has the following syntax:

```
> show voice ont pots-call statistics current-15min [ (uni-idx) ]
```

Command Parameters

Table 151.66-1 "Voice Gpon POTS Call Statistics Command for Current 15 Minutes" Resource Parameters

Resource Identifier	Type	Description
(uni-idx)	Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Gpon::OntSlotId> / <Gpon::OntPotsPortId> ng2 : <Ng2::ChannelGroup> / <Ng2::SubchannelGroup> / <Ng2::OntId> / <Gpon::OntSlotId> / <Gpon::OntPotsPortId>) Possible values: - ng2 : ngpon2 style identification Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Eqpt::OntId> - the ONT identifier Field type <Ng2::ChannelGroup> - channel group number Field type <Ng2::SubchannelGroup> - subchannel group number Field type <Ng2::OntId>	identification of the ont interface index

Resource Identifier	Type	Description
	- the ONT identifier Field type <Gpon::OntSlotId> - Gpon Ont Slot - range: [1...14] Field type <Gpon::OntPotsPortId> - Gpon Ont Pots Port - range: [1...24]	

Command Output

Table 151.66-2 "Voice Gpon POTS Call Statistics Command for Current 15 Minutes" Display parameters

Specific Information		
name	Type	Description
setup-fails	Parameter type: <Counter> - 32 bit counter	count of call setup failures during this interval <i>This element is always shown.</i>
setup-timer	Parameter type: <Counter> - 32 bit counter	count of longest duration of a single call setup detected during this interval <i>This element is always shown.</i>
terminate-fails	Parameter type: <Counter> - 32 bit counter	count of call terminate failures during this interval <i>This element is always shown.</i>
releases	Parameter type: <Counter> - 32 bit counter	count of the analog port releases without dialing during this interval <i>This element is always shown.</i>
off-hook-timer	Parameter type: <Counter> - 32 bit counter	count of longest period of a single off-hook detected on the analog port during this interval <i>This element is always shown.</i>

151.67 Voice Gpon POTS Call Statistics Command for Previous 15 Minutes

Command Description

This command allows the operator to show the Gpon POTS Call Performance Statistics for previous 15 minutes interval

User Level

The command can be accessed by operators with sip,megaco privileges.

Command Syntax

The command has the following syntax:

```
> show voice ont pots-call statistics prev-15min [ (uni-idx) [ interval-num <Gpon::IntervalNo> ] ]
```

Command Parameters

Table 151.67-1 "Voice Gpon POTS Call Statistics Command for Previous 15 Minutes" Resource Parameters

Resource Identifier	Type	Description
(uni-idx)	Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Gpon::OntSlotId> / <Gpon::OntPortId> ng2 : <Ng2::ChannelGroup> / <Ng2::SubchannelGroup> / <Ng2::OntId> / <Gpon::OntSlotId> / <Gpon::OntPortId>) Possible values: - ng2 : ngpon2 style identification Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Ng2::ChannelGroup> - channel group number Field type <Ng2::SubchannelGroup> - subchannel group number Field type <Eqpt::OntId> - the ONT identifier Field type <Ng2::OntId> - the ONT identifier	identification of the ont interface index

Resource Identifier	Type	Description
	Field type <Gpon::OntSlotId> - Gpon Ont Slot - range: [1...14] Field type <Gpon::OntPortId> - Gpon Ont Port - range: [1...16]	
interval-num	Parameter type: <Gpon::IntervalNo> Format: - a number of a previous interval number - range: [1...32]	identifies prev 15min intvls, val 1 as the latest intvl

Command Output

Table 151.67-2 "Voice Gpon POTS Call Statistics Command for Previous 15 Minutes" Display parameters

Specific Information		
name	Type	Description
setup-fails	Parameter type: <Counter> - 32 bit counter	count of call setup failures during this interval <i>This element is always shown.</i>
setup-timer	Parameter type: <Counter> - 32 bit counter	count of longest duration of a single call setup detected during this interval <i>This element is always shown.</i>
terminate-fails	Parameter type: <Counter> - 32 bit counter	count of call terminate failures during this interval <i>This element is always shown.</i>
releases	Parameter type: <Counter> - 32 bit counter	count of the analog port releases without dialing during this interval <i>This element is always shown.</i>
off-hook-timer	Parameter type: <Counter> - 32 bit counter	count of longest period of a single off-hook detected on the analog port during this interval <i>This element is always shown.</i>

151.68 GPON Ont Sip Status Command

Command Description

This command retrieves the actual operational data from an ONT VoIP configuration.

User Level

The command can be accessed by operators with sip,megaco privileges.

Command Syntax

The command has the following syntax:

```
> show voice ont sip-config operational-data [ (sip-index) ]
```

Command Parameters

Table 151.68-1 "GPON Ont Sip Status Command" Resource Parameters

Resource Identifier	Type	Description
(sip-index)	Format: (ont : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Gpon::IpHostId> ont:ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / <Ng2::IpHostId>) Possible values: - ont:ng2 : ngpon2 ont - ont : ont Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Eqpt::OntId> - the ONT identifier Field type <Eqpt::ChannelGroupId> - the channel group identifier Field type <Eqpt::SubChannelGroupId> - the subchannel group identifier Field type <Eqpt::Ng2OntId> - the NG2 ONT identifier Field type <Gpon::IpHostId> - iphost id Field type <Ng2::IpHostId> - iphost id (ngpon2)	SIP ONT index

Command Output

Table 151.68-2 "GPON Ont Sip Status Command" Display parameters

Specific Information		
name	Type	Description
sip-status	Parameter type: <Gpon::SipStatus> (init connected icmp malfunc inadeq-resp timeout unknown no-support) Possible values: - init : ok/initial - connected : connected - icmp : failed with icmp error - malfunc : malformed response - inadeq-resp : failed with inadequate info response - timeout : failed because of a timeout - unknown : olt cannot communicate with ont for omci discovery purposes - no-support : means that ont does not support this info	indicates the current status of the SIP agent. <i>This element is always shown.</i>

151.69 Voice Gpon SIP Agent Statistics Command for Current 15 Minutes

Command Description

This command allows the operator to show the Gpon SIP Agent Performance Statistics for current 15 minutes interval.

User Level

The command can be accessed by operators with sip,megaco privileges.

Command Syntax

The command has the following syntax:

```
> show voice ont sip-agent statistics current-15min [ (ont-idx) ]
```

Command Parameters

Table 151.69-1 "Voice Gpon SIP Agent Statistics Command for Current 15 Minutes" Resource Parameters

Resource Identifier	Type	Description
(ont-idx)	Format: (ont : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Gpon::IpHostId> ont:ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / <Ng2::IpHostId>) Possible values: - ont:ng2 : ngpon2 ont - ont : ont Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Eqpt::OntId> - the ONT identifier Field type <Eqpt::ChannelGroupId> - the channel group identifier Field type <Eqpt::SubChannelGroupId> - the subchannel group identifier Field type <Eqpt::Ng2OntId>	ONT index

Resource Identifier	Type	Description
	- the NG2 ONT identifier Field type <Gpon::IpHostID> - iphost id Field type <Ng2::IpHostID> - iphost id (ngpon2)	

Command Output

Table 151.69-2 "Voice Gpon SIP Agent Statistics Command for Current 15 Minutes" Display parameters

Specific Information		
name	Type	Description
transactions	Parameter type: <Counter> - 32 bit counter	a count of number of new transactions that were initiated during this interval. <i>This element is always shown.</i>
rx-invite-reqs	Parameter type: <Counter> - 32 bit counter	a count of number of received invite messages, including retransmissions during this interval. <i>This element is always shown.</i>
rx-invite-retrans	Parameter type: <Counter> - 32 bit counter	a count of number of received invite retransmission messages during this interval. <i>This element is always shown.</i>
rx-non-invite-reqs	Parameter type: <Counter> - 32 bit counter	a count of number of received non-invite messages, including retransmissions during this interval. <i>This element is always shown.</i>
rx-non-invites-retrans	Parameter type: <Counter> - 32 bit counter	a count of number of received non-invite retransmission messages during this interval. <i>This element is always shown.</i>
rx-responses	Parameter type: <Counter> - 32 bit counter	a count of number of total responses received during this interval. <i>This element is always shown.</i>
rx-response-retrans	Parameter type: <Counter> - 32 bit counter	a count of number of total response retransmissions received during this interval. <i>This element is always shown.</i>
tx-invite-reqs	Parameter type: <Counter> - 32 bit counter	a count of number of transmitted invite messages, including retransmissions during this interval. <i>This element is always shown.</i>
tx-invite-retrans	Parameter type: <Counter> - 32 bit counter	a count of number of transmitted invite retransmission messages during this interval. <i>This element is always shown.</i>
tx-non-invite-reqs	Parameter type: <Counter> - 32 bit counter	a count of number of transmitted non-invite messages, including retransmissions during this interval. <i>This element is always shown.</i>

151 Voice Status Commands

name	Type	Description
tx-non-invite-retrans	Parameter type: <Counter> - 32 bit counter	a count of number of transmitted non-invite retransmission messages during this interval. <i>This element is always shown.</i>
tx-responses	Parameter type: <Counter> - 32 bit counter	a count of number of total responses transmitted during this interval. <i>This element is always shown.</i>
tx-responses-retrans	Parameter type: <Counter> - 32 bit counter	a count of number of total response retransmissions transmitted during this interval. <i>This element is always shown.</i>

151.70 Voice Gpon SIP Call Statistics Command for Current 15 Minutes

Command Description

This command allows the operator to show the Gpon SIP Call Performance Statistics for current 15 minutes interval.

User Level

The command can be accessed by operators with sip,megaco privileges.

Command Syntax

The command has the following syntax:

```
> show voice ont sip-call statistics current-15min [ (ont-idx) ]
```

Command Parameters

Table 151.70-1 "Voice Gpon SIP Call Statistics Command for Current 15 Minutes" Resource Parameters

Resource Identifier	Type	Description
(ont-idx)	Format: (ont : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Gpon::IpHostId> ont:ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / <Ng2::IpHostId>) Possible values: - ont:ng2 : ngpon2 ont - ont : ont Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Eqpt::OntId> - the ONT identifier Field type <Eqpt::ChannelGroupId> - the channel group identifier Field type <Eqpt::SubChannelGroupId> - the subchannel group identifier Field type <Eqpt::Ng2OntId>	ONT index

Resource Identifier	Type	Description
	- the NG2 ONT identifier Field type <Gpon::IpHostID> - iphost id Field type <Ng2::IpHostID> - iphost id (ngpon2)	

Command Output

Table 151.70-2 "Voice Gpon SIP Call Statistics Command for Current 15 Minutes" Display parameters

Specific Information		
name	Type	Description
connect-fails	Parameter type: <Counter> - 32 bit counter	a count of number of times the SIP user agent failed to reach/connect its TCP/UDP peer during SIP call initiation. <i>This element is always shown.</i>
validate-fails	Parameter type: <Counter> - 32 bit counter	a count of number of times the SIP user agent failed to validate its peer during SIP call initiation. <i>This element is always shown.</i>
time-outs	Parameter type: <Counter> - 32 bit counter	a count of number of times the SIP user agent timed out during SIP call initiations. <i>This element is always shown.</i>
rx-fails	Parameter type: <Counter> - 32 bit counter	a count of number of times the SIP user agent received a failure error code during SIP call initiations. <i>This element is always shown.</i>
auth-fails	Parameter type: <Counter> - 32 bit counter	a count of number of times the SIP user agent failed to authenticate itself during SIP call initiations. <i>This element is always shown.</i>

151.71 Voice ONT Operational data for pots line profile download status Command

Command Description

This command retrieves the actual pots line profile download status from an ONT

User Level

The command can be accessed by operators with sip,megaco privileges.

Command Syntax

The command has the following syntax:

```
> show voice ont voip-pip-prof operational-data input-profile [ (uni-index) ]
```

Command Parameters

Table 151.71-1 "Voice ONT Operational data for pots line profile download status Command" Resource Parameters

Resource Identifier	Type	Description
(uni-index)	Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Gpon::OntSlotId> / <Gpon::OntPotsPortId> ng2 : <Ng2::ChannelGroup> / <Ng2::SubchannelGroup> / <Ng2::OntId> / <Gpon::OntSlotId> / <Gpon::OntPotsPortId>) Possible values: - ng2 : ngpon2 style identification Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Eqpt::OntId> - the ONT identifier Field type <Ng2::ChannelGroup> - channel group number Field type <Ng2::SubchannelGroup> - subchannel group number Field type <Ng2::OntId> - the ONT identifier	unique ont pots line index

Resource Identifier	Type	Description
	Field type <Gpon::OntSlotId> - Gpon Ont Slot - range: [1...14] Field type <Gpon::OntPotsPortId> - Gpon Ont Pots Port - range: [1...24]	

Command Output

**Table 151.71-2 "Voice ONT Operational data for pots line profile download status Command"
Display parameters**

Specific Information		
name	Type	Description
status:device	Parameter type: <Gpon::Part1ProfVersion> (null <Gpon::Part1ProfVersion>) Possible values: - null : ONT reported that no version was reported Field type <Gpon::Part1ProfVersion> - part one of profile status	Retrieval of the pots line device profile download status <i>This element is always shown.</i>
status:application	Parameter type: <Gpon::Part2ProfVersion> (null <Gpon::Part2ProfVersion>) Possible values: - null : ONT reported that no version was reported Field type <Gpon::Part2ProfVersion> - part two of profile status	Retrieval of the pots line application profile download status <i>This element is always shown.</i>
status:user	Parameter type: <Gpon::Part3ProfVersion> (null <Gpon::Part3ProfVersion>) Possible values: - null : ONT reported that no version was reported Field type <Gpon::Part3ProfVersion> - part three of profile status	Retrieval of the pots line user profile download status <i>This element is always shown.</i>

151.72 Voice ONT Operational data for voip client profile download status Command

Command Description

This command retrieves the actual voip client profile download status from an ONT

User Level

The command can be accessed by operators with sip,megaco privileges.

Command Syntax

The command has the following syntax:

```
> show voice ont voip-vip-prof operational-data input-profile [ (voip-index) ]
```

Command Parameters

Table 151.72-1 "Voice ONT Operational data for voip client profile download status Command" Resource Parameters

Resource Identifier	Type	Description
(voip-index)	Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / 1 ng2 : <Ng2::ChannelGroup> / <Ng2::SubchannelGroup> / <Ng2::OntId> / 1) Possible values: - ng2 : ngpon2 style identification Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Eqpt::OntId> - the ONT identifier Possible values: - 1 : Gpon voip Port Field type <Ng2::ChannelGroup> - channel group number Field type <Ng2::SubchannelGroup> - subchannel group number Field type <Ng2::OntId> - the ONT identifier	a unique voip service index

Resource Identifier	Type	Description
	Possible values: - 1 : Gpon voip Port	

Command Output

Table 151.72-2 "Voice ONT Operational data for voip client profile download status Command"
Display parameters

Specific Information		
name	Type	Description
status:anchor	Parameter type: <Gpon::Part1ProfVersion> (null <Gpon::Part1ProfVersion>) Possible values: - null : ONT reported that no version was reported Field type <Gpon::Part1ProfVersion> - part one of profile status	Retrieval of the voip client anchor profile download status <i>This element is always shown.</i>
status:localnet	Parameter type: <Gpon::Part2ProfVersion> (null <Gpon::Part2ProfVersion>) Possible values: - null : ONT reported that no version was reported Field type <Gpon::Part2ProfVersion> - part two of profile status	Retrieval of the voip client local network profile download status <i>This element is always shown.</i>

151.73 Voice extline Status Commands

Command Description

This command allows the operator to show the Voice extline profile.

User Level

The command can be accessed by operators with all privileges.

Command Syntax

The command has the following syntax:

> show voice extline [(if-index)]

Command Parameters

Table 151.73-1 "Voice extline Status Commands" Resource Parameters

Resource Identifier	Type	Description
(if-index)	Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number	The unique internal identifier of the extension line

Command Output

Table 151.73-2 "Voice extline Status Commands" Display parameters

Specific Information		
name	Type	Description
local-port	Parameter type: <ExtLine::ExtLinePort> - the extension line local port - range: [1...65534]	The local port of the extension line <i>This element is always shown.</i>
oper-status	Parameter type: <ExtLine::ExtLineOperStatus> (up down) Possible values: - up : the status of the termination opera is up - down : the status of the termination is down	the operational status of application server <i>This element is always shown.</i>
operstatus-downreason	Parameter type: <ExtLine::ExtLineOpDownReason>	the reason of operational status of

151 Voice Status Commands

name	Type	Description
	(physicalfailure) Possible values: - : the term opera status down reason is none - physicalfailure : the term opera status down reason is physical failure	application server is down <i>This element is always shown.</i>

151.74 Voice pseudo wire Status Commands

Command Description

This command allows the operator to show the pseudo wire profile.

User Level

The command can be accessed by operators with all privileges.

Command Syntax

The command has the following syntax:

```
> show voice pseudo-wire [ (if-index) ]
```

Command Parameters

Table 151.74-1 "Voice pseudo wire Status Commands" Resource Parameters

Resource Identifier	Type	Description
(if-index)	Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number	The unique internal identifier of the pseudo wire

Command Output

Table 151.74-2 "Voice pseudo wire Status Commands" Display parameters

Specific Information		
name	Type	Description
oper-status	Parameter type: <PwEncapTdm::OperStatus> (up down) Possible values: - up : the status of the pseudo wire opera is up - down : the status of the pseudo wire is down	the operational status of pseudo wire <i>This element is always shown.</i>
operstatus-downreason	Parameter type: <PwEncapTdm::OpDownReason> (los-signal ais-signal	the reason of operational status of pseudo wire is down <i>This element is always shown.</i>

151 Voice Status Commands

name	Type	Description
	rai-signal packet-loss remote-packet-loss no-dsp-resource board-unreachable establishing pw-connection-failure) Possible values: - : The pseudo wire opera status down reason is none - los-signal : The pseudo wire opera status down reason is los-signal - ais-signal : The received packet payload is discarded. The configurable \"idle code\" is played out on reception DS0 channels instead - rai-signal : The received packet payload (TDM data) is played out on reception DS0 channels - packet-loss : Pseudo wire is out of service due to package loss - remote-packet-loss : Pseudo wire is out of service due to remote package loss - no-dsp-resource : Pseudowire could not be established due to lack of DSP resources - board-unreachable : Pseudowire operational status could not be retrieved due to board communication failure - establishing : Pseudo wire is out of service as there is no RTP received after Pseudo wire's admin-status changed as UP - pw-connection-failure : Pseudo wire is out of service as pseudo wire keep establishing(8) status for (20000 + pwEncapTdmPacketizationIntv * normal_state_threshold) millisecond	

151.75 Voice pseudo wire udp port Commands

Command Description

This command allows the operator to show the pseudo wire source udp port.

User Level

The command can be accessed by operators with all privileges.

Command Syntax

The command has the following syntax:

> show voice pseudo-wire-src-port [(if-index)]

Command Parameters

Table 151.75-1 "Voice pseudo wire udp port Commands" Resource Parameters

Resource Identifier	Type	Description
(if-index)	Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number	The unique internal identifier of the pseudo wire

Command Output

Table 151.75-2 "Voice pseudo wire udp port Commands" Display parameters

Specific Information		
name	Type	Description
shared-ip-mode	Parameter type: <PwEncapTdm::SrcUDPPort> - the source udp port of pseudo wire - range: [49152...65535]	The pw Shared ip mode udp port of the pseudo wire <i>This element is always shown.</i>
distinct-ip-mode	Parameter type: <PwEncapTdm::SrcUDPPort> - the source udp port of pseudo wire - range: [49152...65535]	the pw distributed ip mode udp port of the pseudo wire <i>This element is always shown.</i>

152- Epon Ont Status Command

152.1 Epon Ont Status Command Tree	152-6557
152.2 ONT Interface Status Command	152-6558
152.3 Epon Ont Voice media gateway Status Command	152-6560
152.4 Epon Ont Voice Sip UserAgent Status Command	152-6562

152.1 Epon Ont Status Command Tree

Description

This chapter gives an overview of nodes that are handled by "Epon Ont Status Command".

Command Tree

```
----show
  ----voice
    ----eont
      ----operdata
        - (epon-idx)
      ----media-gateway
        - (ont-idx)
      ----sip-useragent
        - (ont-idx)
```

152.2 ONT Interface Status Command

Command Description

this command reports current operational parameters for the ont.

User Level

The command can be accessed by operators with sip,megaco privileges.

Command Syntax

The command has the following syntax:

```
> show voice eont operdata [ (epon-idx) ]
```

Command Parameters

Table 152.2-1 "ONT Interface Status Command" Resource Parameters

Resource Identifier	Type	Description
(epon-idx)	Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Eqpt::OntId> - the ONT identifier	identification of EPON ont

Command Output

Table 152.2-2 "ONT Interface Status Command" Display parameters

Specific Information		
name	Type	Description
mac-addr	Parameter type: <Epon::MacAddr> - mac-address (example : 01:02:03:04:05:06) - length: 6	mac address of the iad <i>This element is always shown.</i>
voice-protocol	Parameter type: <Epon::ProtoInfo> (h248 sip notsupport unknown)	voip protocol used by iad <i>This element is always shown.</i>

name	Type	Description
	Possible values: - h248 : h.248 - sip : SIP - notsupport : NOTSUPPORT - unknown : UNKNOWN	
sw-ver-iad	Parameter type: <Epon::EponMnemonic32> - an octet string defining mnemonic of EPON - length: 1<=x<=32	software version used by iad <i>This element is always shown.</i>
swad-time	Parameter type: <Epon::EponMnemonic32> - an octet string defining mnemonic of EPON - length: 1<=x<=32	iad software version time <i>This element is always shown.</i>
pots-num	Parameter type: <Epon::Int32> - a signed integer	number of the pots line in the iad <i>This element is always shown.</i>

152.3 Epon Ont Voice media gateway Status Command

Command Description

This command displays EPON ONT voice media gateway operation status.

User Level

The command can be accessed by operators with sip,megaco privileges.

Command Syntax

The command has the following syntax:

```
> show voice eont media-gateway [ (ont-idx) ]
```

Command Parameters

Table 152.3-1 "Epon Ont Voice media gateway Status Command" Resource Parameters

Resource Identifier	Type	Description
(ont-idx)	Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Eqpt::OntId> - the ONT identifier	Ont Index

Command Output

Table 152.3-2 "Epon Ont Voice media gateway Status Command" Display parameters

Specific Information		
name	Type	Description
actual-mgc	Parameter type: <Epon::proxy> (secondary primary unknown) Possible values:	current active media gateway controller <i>This element is always shown.</i>

name	Type	Description
	- secondary : Secondary - primary : Primary - unknown : Unknown	
actual-tid-num	Parameter type: <Epon::TidNum> - Number of rtp tid - range: [0...255]	The RTP tid number gets from iad <i>This element is always shown.</i>
first-tid-name	Parameter type: <Epon::TidName> - tid name - length: 1<=x<=32	First RTP tid name in the iad. <i>This element is always shown.</i>
iad-operation	Parameter type: <Epon::iadMode> (registering registersuccess iad-failure deregister iad-reset) Possible values: - registering : - registersuccess : - iad-failure : - deregister : - iad-reset :	IAD operation mode. <i>This element is always shown.</i>

152.4 Epon Ont Voice Sip UserAgent Status Command

Command Description

This command displays EPON ONT sip user agent operation status.

User Level

The command can be accessed by operators with sip,megaco privileges.

Command Syntax

The command has the following syntax:

> show voice eont sip-useragent [(ont-idx)]

Command Parameters

Table 152.4-1 "Epon Ont Voice Sip UserAgent Status Command" Resource Parameters

Resource Identifier	Type	Description
(ont-idx)	Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Eqpt::OntId> - the ONT identifier	Ont Index

Command Output

Table 152.4-2 "Epon Ont Voice Sip UserAgent Status Command" Display parameters

Specific Information		
name	Type	Description
active-proxy	Parameter type: <Epon::proxy> (secondary primary unknown) Possible values:	indicate which sip proxy is in use <i>This element is always shown.</i>

name	Type	Description
	- secondary : Secondary - primary : Primary - unknown : Unknown	

153- Show Epon Ont Pots Command

153.1 Show Epon Ont Pots Command Tree	153-6565
153.2 Epon Ont Pots Information Command	153-6566
153.3 Epon Ont Pots Statistics Command	153-6569

153.1 Show Epon Ont Pots Command Tree

Description

This chapter gives an overview of nodes that are handled by "Show Epon Ont Pots Command".

Command Tree

```
----show
  ----voice
    ----eont
      ----pots
        ----information
          - (uni-idx)
        ----statistics
          - (uni-idx)
```

153.2 Epon Ont Pots Information Command

Command Description

This command displays information of a specific Ont Pots Port

User Level

The command can be accessed by operators with sip,megaco privileges.

Command Syntax

The command has the following syntax:

> show voice eont pots information [(uni-idx)]

Command Parameters

Table 153.2-1 "Epon Ont Pots Information Command" Resource Parameters

Resource Identifier	Type	Description
(uni-idx)	Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Epon::EontSlot> / <Epon::EontPort> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Eqpt::OntId> - the ONT identifier Field type <Epon::EontSlot> - Epon Ont Slot - range: [1...16] Field type <Epon::EontPort> - Epon Ont Port - range: [1...64]	ONT UNI interface

Command Output

Table 153.2-2 "Epon Ont Pots Information Command" Display parameters

Specific Information		
name	Type	Description
port-state	Parameter type: <Epon::PortState> (registering	pots port state <i>This element is always shown.</i>

name	Type	Description
	idle offhook dialing ringing ringback connecting connected disconnecting regfail inactive) Possible values: - registering : - idle : - offhook : - dialing : - ringing : - ringback : - connecting : - connected : - disconnecting : - regfail : - inactive :	
service-state	Parameter type: <Epon::ServState> (endlocal endremote endauto normal) Possible values: - endlocal : operator disable the port - endremote : MGC command end the port - endauto : auto end caused by MGC failure - normal : in service status	pots port service state <i>This element is always shown.</i>
codec-mode	Parameter type: <Epon::CodecMode> (g711a g729 g711u g723 g726 t38 unknown) Possible values: - g711a : - g729 : - g711u : - g723 : - g726 : - t38 : - unknown :	pots port coding mode <i>This element is always shown.</i>
echo-cancel	Parameter type: <Epon::EchoCancel> (enable disable) Possible values: - enable : echo cancel enable - disable : echo cancel disable	pots port echo cancel <i>This element is always shown.</i>
reversed-polarity	Parameter type: <Epon::ReversedPolarity> (enable disable)	pots port reversed polarity <i>This element is always shown.</i>

153 Show Epon Ont Pots Command

name	Type	Description
	Possible values: - enable : reversed polarity enable - disable : reversed polarity disable	
tx-gain	Parameter type: <Epon::Gain> - gain - range: [-20...20]	pots port TX gain <i>This element is always shown.</i>
rx-gain	Parameter type: <Epon::Gain> - gain - range: [-20...20]	pots port RX gain <i>This element is always shown.</i>

153.3 Epon Ont Pots Statistics Command

Command Description

This command displays statistics of a specific Ont Pots Port

User Level

The command can be accessed by operators with sip,megaco privileges.

Command Syntax

The command has the following syntax:

```
> show voice eont pots statistics [ (uni-idx) ]
```

Command Parameters

Table 153.3-1 "Epon Ont Pots Statistics Command" Resource Parameters

Resource Identifier	Type	Description
(uni-idx)	Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Epon::EontSlot> / <Epon::EontPort> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Eqpt::OntId> - the ONT identifier Field type <Epon::EontSlot> - Epon Ont Slot - range: [1...16] Field type <Epon::EontPort> - Epon Ont Port - range: [1...64]	ONT UNI interface

Command Output

Table 153.3-2 "Epon Ont Pots Statistics Command" Display parameters

Specific Information		
name	Type	Description
start-time	Parameter type: <Sip::SipTimeInSecs> - the time (yyyy-mm-dd:hour:minutes:secs)	pots port statistics start time <i>This element is always shown.</i>

153 Show Epon Ont Pots Command

name	Type	Description
rtcp-frames-up	Parameter type: <Epon::OctetCounter> - Epon Frames counter	octets transferred in upstream direction on a ont pots port <i>This element is always shown.</i>
rtcp-frames-down	Parameter type: <Epon::OctetCounter> - Epon Frames counter	octets transferred in downstream direction on a ont pots port <i>This element is always shown.</i>
rtcp-mean-delay	Parameter type: <Epon::MeanDelay> - mean delay - range: [0...65535]	RTCP packets total mean delay on a ont pots port <i>This element is always shown.</i>
rtcp-mean-jitter	Parameter type: <Epon::MeanJitter> - mean jitter - range: [0...65535]	RTCP packets total mean jitter on a ont pots port <i>This element is always shown.</i>
rtcp-losspkt-ration	Parameter type: <Epon::Ration> - ration - range: [0...100]	the total loss ration of lost RTCP packets on a ont pots port <i>This element is always shown.</i>

154- Voice LSA Server System Status Commands

154.1 Voice LSA Server System Status Command Tree	154-6572
154.2 Voice LSA Server System Status Commands	154-6573

154.1 Voice LSA Server System Status Command Tree

Description

This chapter gives an overview of nodes that are handled by "Voice LSA Server System Status Commands".

Command Tree

```
----show
  ----voice
    ----lsa-system
      ----state
        - (name)
```

154.2 Voice LSA Server System Status Commands

Command Description

This command allows the operator to show the Voice Sip LSA Server system profile.

User Level

The command can be accessed by operators with sip privileges.

Command Syntax

The command has the following syntax:

> show voice lsa-system state [(name)]

Command Parameters

Table 154.2-1 "Voice LSA Server System Status Commands" Resource Parameters

Resource Identifier	Type	Description
(name)	Format: - uniquely identify this LSA server system - length: 1<=x<=32	uniquely identify this LSA server system

Command Output

Table 154.2-2 "Voice LSA Server System Status Commands" Display parameters

Specific Information		
name	Type	Description
oper-status	Parameter type: <LSA::SystemOperStatus> (up down) Possible values: - up : the status of the LSA server system opera is up - down : the status of the LSA server system opera is down	the operational status of LSA server system <i>This element is always shown.</i>

155- Voice LSA Server Instance Status Commands

155.1 Voice LSA Server Instance Status Command Tree	155-6575
155.2 Voice LSA Server Instance Status Commands	155-6576

155.1 Voice LSA Server Instance Status Command Tree

Description

This chapter gives an overview of nodes that are handled by "Voice LSA Server Instance Status Commands".

Command Tree

```
----show
  ----voice
    ----lsa-instance
      ----state
        - (name)
```

155.2 Voice LSA Server Instance Status Commands

Command Description

This command allows the operator to show the Voice Sip LSA Server Instance profile.

User Level

The command can be accessed by operators with sip privileges.

Command Syntax

The command has the following syntax:

> show voice lsa-instance state [(name)]

Command Parameters

Table 155.2-1 "Voice LSA Server Instance Status Commands" Resource Parameters

Resource Identifier	Type	Description
(name)	Format: - uniquely identify this LSA server instance - length: 1<=x<=32	uniquely identify this LSA server instance

Command Output

Table 155.2-2 "Voice LSA Server Instance Status Commands" Display parameters

Specific Information		
name	Type	Description
oper-status	Parameter type: <LSA::InstanceOperStatus> (up down) Possible values: - up : the status of the LSA server instance opera is up - down : the status of the LSA server instance opera is down	the operational status of LSA server instance <i>This element is always shown.</i>

156- Voice LSA Server Emergency Status Commands

156.1 Voice LSA Server Emergency Status Command Tree	156-6578
156.2 Voice LSA Server System Status Commands	156-6579

156.1 Voice LSA Server Emergency Status

Command Tree

Description

This chapter gives an overview of nodes that are handled by "Voice LSA Server Emergency Status Commands".

Command Tree

```
----show
  ----voice
    ----lsa-emergency
      ----state
        - dn
        - gateway-dn
```

156.2 Voice LSA Server System Status Commands

Command Description

This command allows the operator to show the Voice Sip LSA Server system profile.

User Level

The command can be accessed by operators with sip privileges.

Command Syntax

The command has the following syntax:

```
> show voice lsa-emergency state [ dn <LSA::Dn> ] [ gateway-dn <LSA::GtwyDn> ]
```

Command Parameters

Table 156.2-1 "Voice LSA Server System Status Commands" Resource Parameters

Resource Identifier	Type	Description
dn	Parameter type: <LSA::Dn> Format: - emergency service directory number - length: 1<=x<=8	emergency service directory number
gateway-dn	Parameter type: <LSA::GtwyDn> Format: - directory number only includes the subscriber number to which the emergency call is to be addressed. - length: 1<=x<=32	directory number only includes the subscriber number to which the emergency call is to be addressed

Command Output

Table 156.2-2 "Voice LSA Server System Status Commands" Display parameters

Specific Information		
name	Type	Description
oper-status	Parameter type: <LSA::EmergStatus> (not-registered available busy detected-busy) Possible values: - not-registered : the emergency service center addressed by the emergency service DN is not registered to the LSA server. - available : the emergency service center addressed by the emergency service DN is registered to the LSA server.No emergency call is actually routed to the emergency service	the operational status of LSA emergency service <i>This element is always shown.</i>

156 Voice LSA Server Emergency Status Commands

name	Type	Description
	centar. - busy : the emergency service center is actually occupied as an emergency call is actually being forwarded by the LSA server to the emergency service center. - detected-busy : the emergency service center is temporary unavailable	

157- L2CP Status Commands

157.1 L2CP Status Command Tree	157-6582
157.2 L2CP Status Command	157-6583
157.3 L2CP Status Command	157-6585
157.4 L2CP Status Command	157-6587
157.5 L2CP Partition Status Command	157-6588

157.1 L2CP Status Command Tree

Description

This chapter gives an overview of nodes that are handled by "L2CP Status Commands".

Command Tree

```
----show
  ----l2cp
    ----session-status
      - (index)
    ----session-peers
      - (index)
    ----session-stats
      - (index)
    ----partition
      - (partition-id)
      - user-port
```


157.2 L2CP Status Command

Command Description

This command allows the operator to display the L2CP session status.

It shows the status of the GSMP Adjacency Protocol.

User Level

The command can be accessed by operators with transport privileges.

Command Syntax

The command has the following syntax:

```
> show l2cp session-status [ (index) ]
```

Command Parameters

Table 157.2-1 "L2CP Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - identity of the l2cp session - range: [1...255]	index to the l2cp session table

Command Output

Table 157.2-2 "L2CP Status Command" Display parameters

Specific Information		
name	Type	Description
state	Parameter type: <L2cp::State> (null sync-sent sync-rcvd estab) Possible values: - null : null state - sync-sent : sync sent state - sync-rcvd : sync received state - estab : established state	state of the l2cp session <i>This element is always shown.</i>
gsmp-version	Parameter type: <L2cp::Version> - version of the GSMP protocol - range: [3]	version of gsmp protocol <i>This element is always shown.</i>
gsmp-sub-version	Parameter type: <L2cp::SubVersion> - sub version of the GSMP protocol - range: [1...2]	sub version of gsmp protocol <i>This element is always shown.</i>
topo-discovery	Parameter type: <L2cp::AccessTopologyDiscovery>	access topology discovery is

157 L2CP Status Commands

name	Type	Description
short name: topo-disc	((disabled no) (enabled yes)) Possible values: - disabled : no topology discovery - no : no topology discovery - enabled : topology discovery - yes : topology discovery	supported <i>This element is always shown.</i>
layer2-oam short name: l2-oam	Parameter type: <L2cp::Layer2OAM> ((disabled no) (enabled yes)) Possible values: - disabled : no layer2 oam - no : no layer2 oam - enabled : layer2 oam - yes : layer2 oam	layer2 OAM is supported <i>This element is always shown.</i>
sec-since-system-up	Parameter type: <L2cp::UpTime> - a signed integer	the value of sysUpTime when the session came to established state. <i>This element is always shown.</i>
bras-ip-address	Parameter type: <L2cp::InetAddress> - IPv4-address	IPv4 address used for the GSMP session peer <i>This element is always shown.</i>

157.3 L2CP Status Command

Command Description

This command allows the operator to display the L2CP session peers.

This command shows the identity of the peers.

User Level

The command can be accessed by operators with transport privileges.

Command Syntax

The command has the following syntax:

```
> show l2cp session-peers [ (index) ]
```

Command Parameters

Table 157.3-1 "L2CP Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - identity of the l2cp session - range: [1...255]	index to the l2cp session table

Command Output

Table 157.3-2 "L2CP Status Command" Display parameters

Specific Information		
name	Type	Description
dslam-name	Parameter type: <L2cp::DslamName> - a mac-address (example : 01:02:03:04:05:06) - length: 6	the name of the DSLAM <i>This element is always shown.</i>
bras-name	Parameter type: <L2cp::DslamName> - a mac-address (example : 01:02:03:04:05:06) - length: 6	the name of the BRAS <i>This element is always shown.</i>
router-instance	Parameter type: <Ihub::RouterVplsMgnt> (base vpls-management <Ihub::L2cpRouter>) Possible values: - base : base router - vpls-management : vpls-management router Field type <Ihub::L2cpRouter> - vprn service-id - range: [1...2147483646]	router-instance containing own IP address and route table to be used for the connectivity to the GSMP peer. <i>This element is always shown.</i>
dslam-ip-address	Parameter type: <L2cp::InetAddress>	IPv4 address used for the GSMP

157 L2CP Status Commands

name	Type	Description
	- IPv4-address	session peer <i>This element is always shown.</i>
bras-ip-address	Parameter type: <L2cp::InetAddress> - IPv4-address	IPv4 address used for the GSMP session peer <i>This element is always shown.</i>
dslam-instance	Parameter type: <L2cp::Instance> - identity of the instance - range: [0...16777215]	instance number used by the DSLAM during this session. <i>This element is always shown.</i>
bras-instance	Parameter type: <L2cp::Instance> - identity of the instance - range: [0...16777215]	instance number used by the BRAS during this session. <i>This element is always shown.</i>

157.4 L2CP Status Command

Command Description

This command allows the operator to display the L2CP session statistics.

The operator may also want to see real activity by checking traffic counters for L2CP messages via this show command.

User Level

The command can be accessed by operators with transport privileges.

Command Syntax

The command has the following syntax:

```
> show l2cp session-stats [ (index) ]
```

Command Parameters

Table 157.4-1 "L2CP Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - identity of the l2cp session - range: [1...255]	index to the l2cp session table

Command Output

Table 157.4-2 "L2CP Status Command" Display parameters

Specific Information		
name	Type	Description
sent-msgs	Parameter type: <Counter> - 32 bit counter	number of messages that have been sent in this session <i>This element is always shown.</i>
rcvd-valid-msgs	Parameter type: <Counter> - 32 bit counter	number of messages that have been received and processed in this session <i>This element is always shown.</i>
discarded-msgs	Parameter type: <Counter> - 32 bit counter	number of messages that in this session have been received and discarded. <i>This element is always shown.</i>

157.5 L2CP Partition Status Command

Command Description

This command lists the interfaces associated to a given partition in the Dslam. This command will not list the interfaces associated to the default partition 0.

User Level

The command can be accessed by operators with transport privileges.

Command Syntax

The command has the following syntax:

```
> show l2cp partition [ (partition-id) [ user-port <Itf::XdslShdslLine> ] ]
```

Command Parameters

Table 157.5-1 "L2CP Partition Status Command" Resource Parameters

Resource Identifier	Type	Description
(partition-id)	Format: - partition id - range: [1...127]	partition id
user-port	Parameter type: <Itf::XdslShdslLine> Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number	interface index of the port

158- Ethernet Lt Configuration Data Status

Commands

158.1 Ethernet Lt Configuration Data Status Command Tree	158-6590
158.2 Ethernet Port Interface Configuration Status Command	158-6591
158.3 Ethernet IGMP Configuration Status Command	158-6593
158.4 Ethernet Security PAE Configuration Status Command	158-6596
158.5 Ethernet BridgePort Configuration Status Command	158-6599
158.6 Ethernet QoS Configuration Status Command	158-6603

158.1 Ethernet Lt Configuration Data Status

Command Tree

Description

This chapter gives an overview of nodes that are handled by "Ethernet Lt Configuration Data Status Commands".

Command Tree

```
----show
  ----config-data-port
    - (if-index)
  ----interface-port
  ----igmp
    - (port)
  ----security-pae
    - (port)
  ----bridge-port
    - (port)
  ----qos
```


158.2 Ethernet Port Interface Configuration Status Command

Command Description

This command displays the Ethernet port interface configuration data.

User Level

The command can be accessed by operators with transport privileges.

Command Syntax

The command has the following syntax:

```
> show config-data-port (if-index) interface-port
```

Command Parameters

Table 158.2-1 "Ethernet Port Interface Configuration Status Command" Resource Parameters

Resource Identifier	Type	Description
(if-index)	Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number	interface index of the port

Command Output

Table 158.2-2 "Ethernet Port Interface Configuration Status Command" Display parameters

Specific Information		
name	Type	Description
admin-state	Parameter type: <Eth::EthAdminStatus> (not-applicable up down testing) Possible values: - not-applicable : not-applicable	the state of the interface <i>This element is always shown.</i>

158 Ethernet Lt Configuration Data Status Commands

name	Type	Description
	- up : admin status is up - down : admin status is down - testing : no operational packets can be passed	
link-updown-trap	Parameter type: <Itf::ifLinkUpDownTrapEnable> ((link-updown-trap enabled) (no-link-updown-trap disabled)) Possible values: - link-updown-trap : enable link-up/link-down traps - enabled : enable link-up/link-down traps - no-link-updown-trap : disable link-up/link-down traps - disabled : disable link-up/link-down traps	indicates whether link-up/link-down traps are generated <i>This element is always shown.</i>
user	Parameter type: <Itf::asamIfExtCustomerId> - a string identifying the customer or user - length: x<=64	description of the user connected to this interface <i>This element is always shown.</i>
severity	Parameter type: <Itf::asamIfExtAlmReportingSeverity> (indeterminate warning minor major critical no-alarms default no-value) Possible values: - indeterminate : not a definite known severity - warning : just to inform as a warning - minor : not service affecting - major : service affecting - critical : service breaking - no-alarms : do not report alarm - default : take default as specified via Interface Alarm Configuration command - no-value : no entry in the table	severity for alarm to be reported <i>This element is always shown.</i>
port-type	Parameter type: <Itf::asamIfPortType> (uni nni hc-uni uplink) Possible values: - uni : uni port type - nni : nni port type - hc-uni : hicap uni port type - uplink : uplink port type	the port type <i>This element is always shown.</i>

158.3 Ethernet IGMP Configuration Status

Command

Command Description

This command displays the Ethernet IGMP configuration data.

User Level

The command can be accessed by operators with igmp privileges.

Command Syntax

The command has the following syntax:

```
> show config-data-port (if-index) igmp [ (port) ]
```

Command Parameters

Table 158.3-1 "Ethernet IGMP Configuration Status Command" Resource Parameters

Resource Identifier	Type	Description
(if-index)	Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number	interface index of the port
(port)	Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::VpiId> : <Eqpt::VciId> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::VpiId> : <Eqpt::VciId> : <Eqpt::UnstackedVlan> vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::UnstackedVlan> vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::VpiId> : <Eqpt::VciId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan>	identification of the port or virtual channel

Resource Identifier	Type	Description
	vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> / <Eqpt::OntPortId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> / <Eqpt::OntPortId> : <Eqpt::UnstackedVlan> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> / <Eqpt::OntPortId> vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / voip : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / vuni : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / voip : <Eqpt::UnstackedVlan> vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / vuni : <Eqpt::UnstackedVlan> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / voip <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / vuni vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::LLId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::LLId> : <Eqpt::UnstackedVlan> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::LLId> vlan:ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / <Eqpt::Ng2OntSlotId> / <Eqpt::Ng2OntPortId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan:ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / <Eqpt::Ng2OntSlotId> / <Eqpt::Ng2OntPortId> : <Eqpt::UnstackedVlan>) Possible values: - vlan : vlan port - vlan:ng2 : ngpon2 vlan port Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number Field type <Eqpt::VpiId> - atm VPI Field type <Eqpt::VciId> - atm VCI	

Resource Identifier	Type	Description
	Field type <Eqpt::PonId> - the PON identifier Field type <Eqpt::ChannelGroupId> - the channel group identifier Field type <Eqpt::SubChannelGroupId> - the subchannel group identifier Field type <Eqpt::Ng2OntId> - the NG2 ONT identifier Field type <Eqpt::OntId> - the ONT identifier Possible values: - voip : virtual uni identifier obsolete alternative replaced by vuni - vuni : virtual uni identifier Possible values: - vuni : virtual NGPON2 uni identifier Field type <Eqpt::OntSlotId> - the ONT SLOT identifier Field type <Eqpt::OntPortId> - the ONT PORT identifier Field type <Eqpt::Ng2OntSlotId> - the NGPON2 ONT SLOT identifier Field type <Eqpt::Ng2OntPortId> - the NGPON2 ONT PORT identifier Field type <Eqpt::LLId> - the LLID identifier,range 1 for EPON,range 1-8 for DPOE Possible values: - stacked : stacked vlan identity Field type <Eqpt::UnstackedVlan> - unstacked vlan id Field type <Eqpt::SVlan> - service vlan id Field type <Eqpt::CVlan> - customer vlan id	

Command Output

Table 158.3-2 "Ethernet IGMP Configuration Status Command" Display parameters

Specific Information		
name	Type	Description
perm-pkg-bitmap	Parameter type: <Igmp::PermPkgBitMap> - a binary string - length: 128	packages, the user is allowed to join <i>This element is only shown in detail mode.</i>
max-num-group	Parameter type: <Igmp::ChannelMaxNumGroup> - Max group number this port can support.The value depends on the board type and port type,please refer to the product information document for detail. - range: [0...2048]	max group number this port <i>This element is only shown in detail mode.</i>

158.4 Ethernet Security PAE Configuration Status Command

Command Description

This command displays the Ethernet security PAE configuration data.

User Level

The command can be accessed by operators with aaa privileges.

Command Syntax

The command has the following syntax:

```
> show config-data-port (if-index) security-pae [ (port) ]
```

Command Parameters

Table 158.4-1 "Ethernet Security PAE Configuration Status Command" Resource Parameters

Resource Identifier	Type	Description
(if-index)	Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number	interface index of the port
(port)	Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::VpiId> : <Eqpt::VciId> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> / <Eqpt::OntPortId> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / voip <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::LLId>) Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId>	identification of the port or virtual channel

Resource Identifier	Type	Description
	- the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number Field type <Eqpt::VpiId> - atm VPI Field type <Eqpt::VciId> - atm VCI Field type <Eqpt::PonId> - the PON identifier Field type <Eqpt::OntId> - the ONT identifier Possible values: - voip : virtual uni identifier Field type <Eqpt::OntSlotId> - the ONT SLOT identifier Field type <Eqpt::OntPortId> - the ONT PORT identifier Field type <Eqpt::LLId> - the LLID identifier,range 1 for EPON,range 1-8 for DPOE	

Command Output

Table 158.4-2 "Ethernet Security PAE Configuration Status Command" Display parameters

Specific Information		
name	Type	Description
controlled-port	Parameter type: <Aaa::PaeControlledPortControl> (force-unauthorized auto force-authorized) Possible values: - force-unauthorized : force unauthorized control - auto : automatic control - force-authorized : force authorized control	current value of the controlled Port <i>This element is always shown.</i>
quiet-period	Parameter type: <Aaa::paeQuitTime> - quietPeriod - unit: sec - range: [0...65535]	quietPeriod constant currently used, value in seconds <i>This element is always shown.</i>
tx-period	Parameter type: <Aaa::paeTime> - authentication time - unit: sec - range: [1...65535]	txPeriod constant currently used, value in seconds <i>This element is always shown.</i>
supp-timeout	Parameter type: <Aaa::paeTime> - authentication time - unit: sec - range: [1...65535]	suppTimeout constant currently used, value in seconds <i>This element is always shown.</i>
server-timeout	Parameter type: <Aaa::paeTime> - authentication time - unit: sec - range: [1...65535]	serverTimeout constant currently used, value in seconds <i>This element is always shown.</i>
max-req	Parameter type: <Aaa::paeMaxReq> - max number of requests - range: [1...10]	maxReq constant currently used <i>This element is always shown.</i>
authentication	Parameter type: <Aaa::PortAuthState> (authentication	enable 802.1x authentication <i>This element is always shown.</i>

158 Ethernet Lt Configuration Data Status Commands

name	Type	Description
	no-authen) Possible values: - authentication : enable 802.1x authentication - no-authen : disable 802.1x authentication	
init-authreq-off	Parameter type: <Aaa::PortAuthReq> (initiate-authreq init-authreq-off) Possible values: - initiate-authreq : enable initiate authentication request to supplicant - init-authreq-off : disable initiate authentication request to supplicant	specify initiate authentication request to supplicant <i>This element is always shown.</i>
handshake	Parameter type: <Aaa::PortHandShakeMode> (handshake no-handshake) Possible values: - handshake : enable handshake for this port - no-handshake : disable handshake for this port	enable handshake for this port <i>This element is always shown.</i>
handshake-period	Parameter type: <Aaa::PortHandShakePeriod> - handshake time interval - unit: sec - range: [5...90]	specify the handshake time interval <i>This element is always shown.</i>
initialize	Parameter type: <Aaa::InitCont> (initialize no-initialize) Possible values: - initialize : initialize this port - no-initialize : don't initialize this port	initialization control for this port <i>This element is always shown.</i>

158.5 Ethernet BridgePort Configuration Status Command

Command Description

This command displays the Bridge Port configured data.

User Level

The command can be accessed by operators with vlan privileges.

Command Syntax

The command has the following syntax:

```
> show config-data-port (if-index) bridge-port [ (port) ]
```

Command Parameters

Table 158.5-1 "Ethernet BridgePort Configuration Status Command" Resource Parameters

Resource Identifier	Type	Description
(if-index)	Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number	interface index of the port
(port)	Format: (dsl : <Eqpt::VpiId> : <Eqpt::VciId> dsl) Possible values: - dsl : vdsl board Field type <Eqpt::VpiId> - atm VPI Field type <Eqpt::VciId> - atm VCI	identification of the port or virtual channel

Command Output

Table 158.5-2 "Ethernet BridgePort Configuration Status Command" Display parameters

Specific Information		
name	Type	Description
pvid	Parameter type: <Vlan::StackedVlan> (<Vlan::UVlanIndex> stacked : <Vlan::SVlanIndex> : <Vlan::CVlanIndex>) Possible values: - stacked : stacked vlan identity Field type <Vlan::UVlanIndex> - unstacked vlan identity - range: [1...4093,4096] Field type <Vlan::SVlanIndex> - service vlan identity - range: [2...4093,4094] Field type <Vlan::CVlanIndex> - customer vlan identity - range: [0...4093,4094,4095,4096]	default vlan id for untagged frames <i>This element is only shown in detail mode.</i>
default-priority	Parameter type: <Vlan::Priority> - priority of ethernet frames - range: [0...7]	priority to be set in upstream frames <i>This element is only shown in detail mode.</i>
mac-learn-off	Parameter type: <Vlan::learnStatus> (mac-learning mac-learn-off) Possible values: - mac-learning : enable self learning of mac address - mac-learn-off : disable self learning of mac address	self learning of mac address <i>This element is only shown in detail mode.</i>
max-unicast-mac	Parameter type: <Vlan::MaxMac> - number of unicast mac addresses - range: [1...65535]	max unicast mac addresses <i>This element is only shown in detail mode.</i>
accept-frame-type	Parameter type: <Vlan::VlanFrameTypes> (single-tagged untagged mixed-tagged) Possible values: - single-tagged : admit only vlan tagged - untagged : admit only vlan untagged - mixed-tagged : admit vlan tagged and vlan untagged	accept frame types <i>This element is only shown in detail mode.</i>
prio-regen-prof	Parameter type: <Vlan::PrioRegenProfile> (none trusted-port best-effort cl-all-prio-3 cl-all-prio-4 background be-cl-voice be-cl-1d-voice be-voice l2-vpn-3 l2-vpn-4 11 12 13 14 15 16 17 18 19	priority regeneration profile <i>This element is only shown in detail mode.</i>

name	Type	Description
	20 21 22 23 24 25 26 27 28 29 30 31 32) Possible values: - none : default value - trusted-port : trusted port - best-effort : best effort - cl-all-prio-3 : controlled load, all priority 3 traffic - cl-all-prio-4 : controlled load, all priority 4 traffic - background : background - be-cl-voice : best effort, controlled load, voice - be-cl-1d-voice : best effort, controlled load, 802.Id Annex G voice - be-voice : best effort voice - l2-vpn-3 : L2 VPN with 3 traffic classes - l2-vpn-4 : L2 VPN with 4 traffic classes - 11 : operator-defined profile - 12 : operator-defined profile - 13 : operator-defined profile - 14 : operator-defined profile - 15 : operator-defined profile - 16 : operator-defined profile - 17 : operator-defined profile - 18 : operator-defined profile - 19 : operator-defined profile - 20 : operator-defined profile - 21 : operator-defined profile - 22 : operator-defined profile - 23 : operator-defined profile - 24 : operator-defined profile - 25 : operator-defined profile - 26 : operator-defined profile - 27 : operator-defined profile - 28 : operator-defined profile - 29 : operator-defined profile - 30 : operator-defined profile - 31 : operator-defined profile - 32 : operator-defined profile	
prio-regen-name	Parameter type: <Vlan::PrioRegenProfileName> (none name : <Vlan::IgnoredVlanProfileName>) Possible values: - none : no profile name to associate - name : enter profile name to be associated Data driven field type Possible values are depending on the actual configuration and software.	priority regeneration profile name <i>This element is only shown in detail mode.</i>

158 Ethernet Lt Configuration Data Status Commands

name	Type	Description
	The currently allowed values can be shown with online-help.	
qos-profile	Parameter type: <Vlan::QosProfileName> (none name : <Vlan::IgnoredQosProfileName>) Possible values: - none : no profile name to associate - name : enter profile name to be associated Field type <Vlan::IgnoredQosProfileName> - name of the QoS profile - length: 1<=x<=64	qos profile name <i>This element is always shown.</i>

158.6 Ethernet QoS Configuration Status

Command

Command Description

This command displays the Ethernet QoS configuration data.

User Level

The command can be accessed by operators with qos privileges.

Command Syntax

The command has the following syntax:

> show config-data-port (if-index) qos

Command Parameters

Table 158.6-1 "Ethernet QoS Configuration Status Command" Resource Parameters

Resource Identifier	Type	Description
(if-index)	Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number	interface index of the port

Command Output

Table 158.6-2 "Ethernet QoS Configuration Status Command" Display parameters

Specific Information		
name	Type	Description
scheduler-profile	Parameter type: <Qos::QosSchedulerProfileName> (none name : <Qos::IgnoredQosProfileName>) Possible values: - none : no profile name to associate - name : enter profile name to be associated Data driven field type	the name of the scheduler profile to be mapped on this dsl link3 <i>This element is only shown in detail mode.</i>

158 Ethernet Lt Configuration Data Status Commands

name	Type	Description
	Possible values are depending on the actual configuration and software. The currently allowed values can be shown with online-help.	
cac-profile	Parameter type: <Qos::QosCacProfileName> (name : <Qos::IgnoredQosProfileName> none) Possible values: - none : no profile name to associated - name : enter profile name to be associated Data driven field type Possible values are depending on the actual configuration and software. The currently allowed values can be shown with online-help.	the name of the cac profile to be mapped on this dsl link3 <i>This element is only shown in detail mode.</i>

159- Ethernet Status Commands

159.1 Ethernet Status Command Tree	159-6606
159.2 Interface MAU Status Command	159-6608
159.3 SFP status commands	159-6614
159.4 Ethernet Counters Near End Line Current 15 Min	159-6616
159.5 Ethernet Counters Near End Line Current Day	159-6619
159.6 Ethernet Counters Near End Line Previous 15 Min	159-6622
159.7 Ethernet Counters Near End Line Previous Day	159-6625
159.8 Ethernet PM Interval Per Interface Status Command	159-6628
159.9 Ethernet Lt Dot3 Status Command	159-6630
159.10 Ethernet RMON Counters Status Command	159-6632
159.11 Ethernet Statistics Line Status Command	159-6636
159.12 Ethernet Ont Port Operational Status Command	159-6639
159.13 ONT Ethernet Port Performance Monitoring Current-Interval Status Command	159-6641
159.14 ONT Ethernet Port Performance Monitoring Previous-Interval Status Command	159-6643
159.15 Ethernet Ont Port loopback Status Command	159-6646
159.16 Epon Ont Ethernet Status Command	159-6648
159.17 Epon Ont Ethernet Port Information Command	159-6649
159.18 Epon Ont Ethernet Port Fdb Command	159-6653
159.19 Epon Ont Ethernet Status Command	159-6655
159.20 Epon Ont Ethernet Current 15min Status Command	159-6656
159.21 Epon Ont Ethernet Current 1Day Status Command	159-6661
159.22 Epon Ont Ethernet Previous 15min Status Command	159-6666
159.23 Epon Ont Ethernet Previous 1day Status Command	159-6671

159.1 Ethernet Status Command Tree

Description

This chapter gives an overview of nodes that are handled by "Ethernet Status Commands".

Command Tree

```
----show
  ----ethernet
    ----mau
      - (if-index)
      - index
    ----sfp
      - (if-index)
      - index
    ----counters
      ----near-end
        ----line
          ----current-interval
            - (if-index)
          ----current-1day
            - (if-index)
          ----previous-interval
            - (if-index)
            - interval-no
          ----previous-1day
            - (if-index)
            - interval-no
      ----eth-int
        - (if-index)
      ----dot3stats
        - (stats-index)
      ----etherstats
        - (stats-index)
      ----statistics
        ----line
          - (if-index)
      ----ont
        ----operational-data
          - (uni-idx)
        ----port
          ----current-interval
            - (uni-idx)
          ----previous-interval
            - (uni-idx)
            - interval-num
        ----loopback-info
          - (uni-idx)
      ----eont
        ----port
          ----information
            - (uni-index)
          ----fdb
```


- (uni-idx)
- vlan
- mac-address
- tc-layer
- current-15min
 - (uni-idx)
- current-1day
 - (uni-idx)
- previous-15min
 - (uni-idx)
- interval-num
 - (interval-num)
- previous-1day
 - (uni-idx)
- interval-num
 - (interval-num)

159.2 Interface MAU Status Command

Command Description

This command displays the Ethernet MAU parameters.

User Level

The command can be accessed by operators with transport privileges.

Command Syntax

The command has the following syntax:

```
> show ethernet mau [ (if-index) [ index <Transport::Index> ] ]
```

Command Parameters

Table 159.2-1 "Interface MAU Status Command" Resource Parameters

Resource Identifier	Type	Description
(if-index)	Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number	interface index of the mau
index	Parameter type: <Transport::Index> Format: - port to which the MAU is connected - range: [1...2147483647]	identify MAU, among others connected to same interface

Command Output

Table 159.2-2 "Interface MAU Status Command" Display parameters

Specific Information		
name	Type	Description
type	Parameter type: <Ether::MAUType> (10baset 100basetxhd 100basetxfd 100basefxhd 100basefxfd	Specifies the MAU type. If the MAU type is unknown, then unknown MAU type will be returned. If the MAU is a link or fiber type then media-available is equivalent to the link test fail

name	Type	Description
	1000basexhd 1000basexfd 1000baselxhd 1000baselxfd 1000basesxhd 1000basesxfd 1000basethd 1000basetfd 10gbasex 10gbaser 10gbaseer 10gbaselr 10gbasesr 1000basebx10d 1000basebx10u 1000baselx10 1000basebx10d 1000basebx10u 1000baselx10 2500basex 10gbasetfd unknown) Possible values: - 10baset : UTP 10M - 100basetxhd : UTP 100M half duplex - 100basetxfd : UTP 100M full duplex - 100basefxhd : X fiber over PMT half duplex - 100basefxfd : X fiber over PMT full duplex - 1000basexhd : PCS/PMA,unknown PMD, half duplex - 1000basexfd : PCS/PMA,unknown PMD, full duplex - 1000baselxhd : fiber over long-wavelength laser half duplex - 1000baselxfd : fiber over long-wavelength laser full duplex - 1000basesxhd : fiber over short-wavelength laser half duplex - 1000basesxfd : fiber over short-wavelength laser full duplex - 1000basethd : UTP 1G half duplex - 1000basetfd : UTP 1G full duplex - 10gbasex : fiber 10G ethernet, PCS 8B/10B - 10gbaser : fiber 10G ethernet, PCS 64B/66B - 10gbaseer : fiber 10G ethernet extended reach, 30km - 10gbaselr : fiber 10G ethernet long reach, 10km - 10gbasesr : fiber 10G ethernet short reach, 300m - 1000basebx10d : one single-mode fiber OLT long wavelength, 10km, 100 base - 1000basebx10u : one single-mode fiber ONU, long wavelength, 10km, 100 base - 1000baselx10 : two single-mode fibers over long wavelength, 10km, 100 base - 1000basebx10d : one single-mode fiber OLT over long wavelength, 10km, 1000 base - 1000basebx10u : one single-mode fiber ONU over long wavelength, 10km, 1000 base - 1000baselx10 : two single-mode fibers over long wavelength, 10km, 1000 base - 2500basex : single-mode fibers, 2.5G base	state/low light function. For an AUI or a coax (including broadband) MAU this indicates whether or not loopback is detected on the DI circuit. The value of this attribute persists between packets for MAU types AUI, 10BASE5, 10BASE2, 10BROAD36, and 10BASE-FP. <i>This element is always shown.</i>

159 Ethernet Status Commands

name	Type	Description
	- 10gbasetfd : UTP 10G full duplex - unknown : unknown type	
media-available	Parameter type: <Transport::MauAvailable> (other unknown available not-available remote-fault invalid-signal remote-jabber remote-link-loss remote-test off-line auto-neg-error) Possible values: - other : MAU in other state - unknown : MAU's true state is unknown - available : - not-available : MAU is fully functional - remote-fault : power down - invalid-signal : reset the MAU - remote-jabber : power down - remote-link-loss : power down - remote-test : power down - off-line : power down - auto-neg-error : power down	Specifies whether the media is available for the MAU or not. <i>This element is always shown.</i>
jabber-state	Parameter type: <Transport::MauJabber> (other unknown no-jabber jabbering) Possible values: - other : if not in any state - unknown : MAU's true state is unknown - no-jabber : MAU not jabbering - jabbering : MAU is jabbering	The jabber-state indicates whether this entity is jabbering, not jabbering, unknown or other state. <i>This element is always shown.</i>
b100basefxfd	Parameter type: <Ether::B100BaseFXFD> (yes no) Possible values: - yes : 100basefxfd supported - no : 100basefxfd not supported	X fiber over PMT full duplex <i>This element is only shown in detail mode.</i>
b100baselx10	Parameter type: <Ether::B100BaseLX10> (yes no) Possible values: - yes : 100baselx10 supported - no : 100baselx10 not supported	two single-mode fibers over long wavelength, 10km, 100 base <i>This element is only shown in detail mode.</i>
b100basebx10d	Parameter type: <Ether::B100BaseBX10D> (yes no) Possible values: - yes : 100basebx10d supported - no : 100basebx10d not supported	one single-mode fiber OLT long wavelength, 10km, 100 base <i>This element is only shown in detail mode.</i>
b100basebx10u	Parameter type: <Ether::B100BaseBX10U> (yes no)	one single-mode fiber ONU, long wavelength, 10km, 100 base <i>This element is only shown in</i>

name	Type	Description
	Possible values: - yes : 100basebx10u supported - no : 100basebx10u not supported	<i>detail mode.</i>
b100basetxfd	Parameter type: <Ether::B100BaseTXFD> (yes no) Possible values: - yes : 100basetxfd supported - no : 100basetxfd not supported	UTP 100M full duplex <i>This element is only shown in detail mode.</i>
b1000basetfd	Parameter type: <Ether::B1000BaseTFD> (yes no) Possible values: - yes : 1000basetfd supported - no : 1000basetfd not supported	UTP 1G full duplex <i>This element is only shown in detail mode.</i>
b10gbasetfd	Parameter type: <Ether::B10GBaseTFD> (yes no) Possible values: - yes : 10gbasetfd supported - no : 10gbasetfd not supported	UTP 10G full duplex <i>This element is only shown in detail mode.</i>
b1000basesxfd	Parameter type: <Ether::B1000BaseSXF> (yes no) Possible values: - yes : 1000basesxfd supported - no : 1000basesxfd not supported	fiber over short-wavelength laser full duplex <i>This element is only shown in detail mode.</i>
b1000baselx10	Parameter type: <Ether::B1000BaseLX10> (yes no) Possible values: - yes : 1000baselx10 supported - no : 1000baselx10 not supported	two single-mode fibers over long wavelength, 10km, 1000 base <i>This element is only shown in detail mode.</i>
b1000baselxfd	Parameter type: <Ether::B1000BaseLXFD> (yes no) Possible values: - yes : 1000baselxfd supported - no : 1000baselxfd not supported	fiber over long-wavelength laser full duplex <i>This element is only shown in detail mode.</i>
b1000basebx10u	Parameter type: <Ether::B1000BaseBX10U> (yes no) Possible values: - yes : 1000basebx10u supported - no : 1000basebx10u not supported	one single-mode fiber ONU over long wavelength, 10km, 1000 base <i>This element is only shown in detail mode.</i>
b1000basebx10d	Parameter type: <Ether::B1000BaseBX10D> (yes no) Possible values: - yes : 1000basebx10d supported - no : 1000basebx10d not supported	one single-mode fiber OLT over long wavelength, 10km, 1000 base <i>This element is only shown in detail mode.</i>
b10gbaser	Parameter type: <Ether::B10GBaseR> (yes no) Possible values: - yes : 10GbaseR supported - no : 10GbaseR not supported	two single-mode fiber 10G base <i>This element is only shown in detail mode.</i>

159 Ethernet Status Commands

name	Type	Description
b10gbaselr	Parameter type: <Ether::B10GBaseLR> (yes no) Possible values: - yes : 10GbaseLR supported - no : 10GbaseLR not supported	two single-mode fiber 10km 10G base <i>This element is only shown in detail mode.</i>
b10gbaseer	Parameter type: <Ether::B10GBaseER> (yes no) Possible values: - yes : 10GbaseER supported - no : 10GbaseER not supported	two single-mode fiber 30km 10G base <i>This element is only shown in detail mode.</i>
b2500basex	Parameter type: <Ether::B2500BaseX> (yes no) Possible values: - yes : b2500BaseX supported - no : b2500BaseX not supported	single-mode fiber 2.5G base <i>This element is only shown in detail mode.</i>
auto-neg-supported	Parameter type: <Ether::TruthValue> (true false) Possible values: - true : autonegotiation is supported - false : autonegotiation is not supported	Specifies whether or not auto-negotiation is supported on this MAU. <i>This element is always shown.</i>
auto-neg-status	Parameter type: <Ether::AutoNegStatus> (other configuring complete disabled paralleldetectfail) Possible values: - other : unknown auto-negotiation status - configuring : auto-negotiation still ongoing - complete : auto-negotiation completed - disabled : auto-negotiation disabled - paralleldetectfail : parallel detection failed	Displays the auto-negotiation status of this MAU. <i>This element is always shown.</i>
cap100base-tfd	Parameter type: <Ether::ACAP_100BaseTFD> (yes no) Possible values: - yes : 100BaseTFD supported - no : 100BaseTFD not supported	electrical 100M full duplex autonegotiation capable <i>This element is only shown in detail mode.</i>
cap1000base-xfd	Parameter type: <Ether::ACAP_1000BaseXFD> (yes no) Possible values: - yes : 1000BaseXFD supported - no : 1000BaseXFD not supported	optical 1G full duplex autonegotiation capable <i>This element is only shown in detail mode.</i>
cap1000base-tfd	Parameter type: <Ether::ACAP_1000BaseTFD> (yes no) Possible values: - yes : 1000BaseTFD supported - no : 1000BaseTFD not supported	electrical 1G full duplex autonegotiation capable <i>This element is only shown in detail mode.</i>
cap10gbase-tfd	Parameter type: <Ether::ACAP_10GBaseTFD> (yes no)	electrical 10G full duplex autonegotiation capable <i>This element is only shown in</i>

name	Type	Description
	Possible values: - yes : 10gBaseTFD supported - no : 10gBaseTFD not supported	<i>detail mode.</i>

159.3 SFP status commands

Command Description

This command displays the Ethernet SFP parameters

User Level

The command can be accessed by operators with transport privileges.

Command Syntax

The command has the following syntax:

```
> show ethernet sfp [ (if-index) [ index <Transport::Index> ] ]
```

Command Parameters

Table 159.3-1 "SFP status commands" Resource Parameters

Resource Identifier	Type	Description
(if-index)	Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number	interface index of the sfp
index	Parameter type: <Transport::Index> Format: - port to which the MAU is connected - range: [1...2147483647]	identify sfp, among others connected to same interface

Command Output

Table 159.3-2 "SFP status commands" Display parameters

Specific Information		
name	Type	Description
sfp-status	Parameter type: <Transport::SFPstatus> (operational-up interface-down no-nokia-label los type-mismatch	identifies the status of the sfp <i>This element is always shown.</i>

name	Type	Description
	local-power-off brother-power-off active-power-off) Possible values: - operational-up : SFP is operational up - interface-down : SFP is not plugged in, interface is down - no-nokia-label : SFP is plugged in but in power down because no Nokia label - los : SFP is plugged in but detected LOS.Note:if ALS enabled,when RX is LOS,disable TX.when RX out of LOS,enable TX. if ALS disabled,always enable TX - type-mismatch : SFP real type mismatch with configured type - local-power-off : local SFP power off since temperature over - brother-power-off : brother SFP power off since temperature over - active-power-off : SFP power down actively by operator	
sfp-inventory	Parameter type: <Transport::SFPinventory> - specification of Sfp inventory. - length: 1<=x<=128	indicates the information of the sfp vendor <i>This element is only shown in detail mode.</i>

159.4 Ethernet Counters Near End Line Current 15 Min

Command Description

- Represents for the current interval the FCS failure count.*
- Represents for the current interval the frame too Long count.*
- Represents for interval MAC sublayer transmit error.*
- Represents for interval MAC sublayer receive error.*
- Measured in seconds, that statistics for this entry have been counted.*
- Indicates the validity of the corresponding PM data.*
- Store the time interval.*

User Level

The command can be accessed by operators with transport privileges.

Command Syntax

- The command has the following syntax:
- > show ethernet counters near-end line current-interval [(if-index)]

Command Parameters

Table 159.4-1 "Ethernet Counters Near End Line Current 15 Min" Resource Parameters

Resource Identifier	Type	Description
(if-index)	Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number	interface index of the port

Command Output

Table 159.4-2 "Ethernet Counters Near End Line Current 15 Min" Display parameters

Specific Information		
name	Type	Description
los	Parameter type: <Counter> - 32 bit counter	Represents for the current 15 minute interval the LOS failure count <i>This element is always shown.</i>
fcs	Parameter type: <Counter> - 32 bit counter	Represents for the current 15 minute interval the FCS failure count <i>This element is always shown.</i>
too-long	Parameter type: <Counter> - 32 bit counter	Represents for the current 15 minute interval the frame too Long count <i>This element is always shown.</i>
mac-trans	Parameter type: <Counter> - 32 bit counter	Represents for the internal MAC sublayer transmit error <i>This element is always shown.</i>
mac-rec	Parameter type: <Counter> - 32 bit counter	Represents for the internal MAC sublayer receive error <i>This element is always shown.</i>
in-octets	Parameter type: <OctetCounter64> - 64 bit counter,range:[0-9223372036854775808]	Represents for the total bytes received <i>This element is only shown in detail mode.</i>
in-pkts	Parameter type: <OctetCounter64> - 64 bit counter,range:[0-9223372036854775808]	Represents for the total packets received <i>This element is only shown in detail mode.</i>
in-err-pkts	Parameter type: <OctetCounter64> - 64 bit counter,range:[0-9223372036854775808]	Represents for the total errored packets received <i>This element is only shown in detail mode.</i>
in-discard-pkts	Parameter type: <OctetCounter64> - 64 bit counter,range:[0-9223372036854775808]	Represents for the total discarded packets at receive <i>This element is only shown in detail mode.</i>
in-drop-pkts	Parameter type: <OctetCounter64> - 64 bit counter,range:[0-9223372036854775808]	Represents for the total errored and discarded packets at receive <i>This element is only shown in detail mode.</i>
out-octets	Parameter type: <OctetCounter64> - 64 bit counter,range:[0-9223372036854775808]	Represents for the total bytes transmitted <i>This element is only shown in detail mode.</i>
out-pkts	Parameter type: <OctetCounter64> - 64 bit counter,range:[0-9223372036854775808]	Represents for the total packets transmitted <i>This element is only shown in detail mode.</i>
out-err-pkts	Parameter type: <OctetCounter64> - 64 bit counter,range:[0-9223372036854775808]	Represents for the total errored packets transmitted <i>This element is only shown in detail mode.</i>
out-discard-pkts	Parameter type: <OctetCounter64> - 64 bit counter,range:[0-9223372036854775808]	Represents for the total packets discarded at transmit <i>This element is only shown in detail mode.</i>
out-drop-pkts	Parameter type: <OctetCounter64> - 64 bit counter,range:[0-9223372036854775808]	Represents for the total errored and discarded packets at transmit

159 Ethernet Status Commands

name	Type	Description
		<i>This element is only shown in detail mode.</i>
mea-time	Parameter type: <ETHITF::MeaTime> - the specification of measuredtime - range: [0...86400]	Measured in seconds, that statistics for this entry have been counted <i>This element is always shown.</i>
inv-data-flag	Parameter type: <ETHITF::DataFlag> - the specification of invalid-data-flag - range: [0...1]	Indicates the validity of the corresponding PM data <i>This element is always shown.</i>
val-int	Parameter type: <ETHITF::Val15m> - the specification of validintervals - range: [0...96]	Store the time interval <i>This element is always shown.</i>

159.5 Ethernet Counters Near End Line Current Day

Command Description

Represents for the current 1day the FCS failure count.

Represents for the current 1 day the frame too Long count.

Represents for 1day MAC sublayer transmit error.

Represents for 1dayl MAC sublayer receive error.

Measured in seconds, that statistics for this entry have been counted.

Indicates the validity of the corresponding PM data.

Store the time interval.

User Level

The command can be accessed by operators with transport privileges.

Command Syntax

The command has the following syntax:

> show ethernet counters near-end line current-1day [(if-index)]

Command Parameters

Table 159.5-1 "Ethernet Counters Near End Line Current Day" Resource Parameters

Resource Identifier	Type	Description
(if-index)	Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number	interface index of the port

Command Output

Table 159.5-2 "Ethernet Counters Near End Line Current Day" Display parameters

Specific Information		
name	Type	Description
los	Parameter type: <Counter> - 32 bit counter	Represents for the current 1day the LOS failure count <i>This element is always shown.</i>
fcs	Parameter type: <Counter> - 32 bit counter	Represents for the current 1day the FCS failure count <i>This element is always shown.</i>
too-long	Parameter type: <Counter> - 32 bit counter	Represents for the current 1 day the frame too Long count <i>This element is always shown.</i>
mac-trans	Parameter type: <Counter> - 32 bit counter	Represents for 1day MAC sublayer transmit error <i>This element is always shown.</i>
mac-rec	Parameter type: <Counter> - 32 bit counter	Represents for 1day MAC sublayer receive error <i>This element is always shown.</i>
in-octets	Parameter type: <OctetCounter64> - 64 bit counter,range:[0-9223372036854775808]	Represents for the total bytes received <i>This element is only shown in detail mode.</i>
in-pkts	Parameter type: <OctetCounter64> - 64 bit counter,range:[0-9223372036854775808]	Represents for the total packets received <i>This element is only shown in detail mode.</i>
in-err-pkts	Parameter type: <OctetCounter64> - 64 bit counter,range:[0-9223372036854775808]	Represents for the total errored packets received <i>This element is only shown in detail mode.</i>
in-discard-pkts	Parameter type: <OctetCounter64> - 64 bit counter,range:[0-9223372036854775808]	Represents for the total discarded packets at receive <i>This element is only shown in detail mode.</i>
in-drop-pkts	Parameter type: <OctetCounter64> - 64 bit counter,range:[0-9223372036854775808]	Represents for the total errored and discarded packets at receive <i>This element is only shown in detail mode.</i>
out-octets	Parameter type: <OctetCounter64> - 64 bit counter,range:[0-9223372036854775808]	Represents for the total bytes transmitted <i>This element is only shown in detail mode.</i>
out-pkts	Parameter type: <OctetCounter64> - 64 bit counter,range:[0-9223372036854775808]	Represents for the total packets transmitted <i>This element is only shown in detail mode.</i>
out-err-pkts	Parameter type: <OctetCounter64> - 64 bit counter,range:[0-9223372036854775808]	Represents for the total errored packets at transmit <i>This element is only shown in detail mode.</i>
out-discard-pkts	Parameter type: <OctetCounter64> - 64 bit counter,range:[0-9223372036854775808]	Represents for the total packets discarded at transmit <i>This element is only shown in detail mode.</i>
out-drop-pkts	Parameter type: <OctetCounter64> - 64 bit counter,range:[0-9223372036854775808]	Represents for the total errored and discarded packets at transmit <i>This element is only shown in detail mode.</i>
mea-time	Parameter type: <ETHIF::MeaTime>	Measured in seconds, that

name	Type	Description
	- the specification of measuredtime - range: [0...86400]	statistics for this entry have been counted <i>This element is always shown.</i>
inv-data-flag	Parameter type: <ETHITF::DataFlag> - the specification of invalid-data-flag - range: [0...1]	Indicates the validity of the corresponding PM data <i>This element is always shown.</i>
val-day	Parameter type: <ETHITF::Val1day> - the specification of 1day-valid-intervals - range: [0...30]	Store the time interval <i>This element is always shown.</i>

159.6 Ethernet Counters Near End Line Previous 15 Min

Command Description

Represents for the previous interval the FCS failure count.

Represents for the previous interval the frame too Long count.

Represents for previous interval MAC sublayer transmit error.

Represents for previous interval MAC sublayer receive error.

Measured in seconds, that statistics for this entry have been counted.

Indicates the validity of the corresponding PM data.

User Level

The command can be accessed by operators with transport privileges.

Command Syntax

The command has the following syntax:

```
> show ethernet counters near-end line previous-interval [ (if-index) [ interval-no  
<ETHITF::IntervalNumber15min> ] ]
```

Command Parameters

Table 159.6-1 "Ethernet Counters Near End Line Previous 15 Min" Resource Parameters

Resource Identifier	Type	Description
(if-index)	Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number	interface index of the port
interval-no	Parameter type: <ETHITF::IntervalNumber15min> Format: - the specification of 15min-interval-number - range: [1...96]	15 minute interval number

Command Output

Table 159.6-2 "Ethernet Counters Near End Line Previous 15 Min" Display parameters

Specific Information		
name	Type	Description
los	Parameter type: <Counter> - 32 bit counter	Represents for the previous 15 minute interval the LOS failure count <i>This element is always shown.</i>
fcs	Parameter type: <Counter> - 32 bit counter	Represents for the previous 15 minute interval the FCS failure count <i>This element is always shown.</i>
too-long	Parameter type: <Counter> - 32 bit counter	Represents for the previous 15 minute interval the frame too Long count <i>This element is always shown.</i>
mac-trans	Parameter type: <Counter> - 32 bit counter	Represents for the internal MAC sublayer transmit error <i>This element is always shown.</i>
mac-rec	Parameter type: <Counter> - 32 bit counter	Represents for the internal MAC sublayer receive error <i>This element is always shown.</i>
in-octets	Parameter type: <OctetCounter64> - 64 bit counter,range:[0-9223372036854775808]	Represents for the total bytes received <i>This element is only shown in detail mode.</i>
in-pkts	Parameter type: <OctetCounter64> - 64 bit counter,range:[0-9223372036854775808]	Represents for the total packets received <i>This element is only shown in detail mode.</i>
in-err-pkts	Parameter type: <OctetCounter64> - 64 bit counter,range:[0-9223372036854775808]	Represents for the total errored packets received <i>This element is only shown in detail mode.</i>
in-discard-pkts	Parameter type: <OctetCounter64> - 64 bit counter,range:[0-9223372036854775808]	Represents for the total discarded packets at receive <i>This element is only shown in detail mode.</i>
in-drop-pkts	Parameter type: <OctetCounter64> - 64 bit counter,range:[0-9223372036854775808]	Represents for the total errored and discarded packets at receive <i>This element is only shown in detail mode.</i>
out-octets	Parameter type: <OctetCounter64> - 64 bit counter,range:[0-9223372036854775808]	Represents for the total bytes transmitted <i>This element is only shown in detail mode.</i>
out-pkts	Parameter type: <OctetCounter64> - 64 bit counter,range:[0-9223372036854775808]	Represents for the total packets transmitted <i>This element is only shown in detail mode.</i>
out-err-pkts	Parameter type: <OctetCounter64> - 64 bit counter,range:[0-9223372036854775808]	Represents for the total errored packets transmitted <i>This element is only shown in detail mode.</i>
out-discard-pkts	Parameter type: <OctetCounter64> - 64 bit counter,range:[0-9223372036854775808]	Represents for the total packets discarded at transmit <i>This element is only shown in detail mode.</i>

159 Ethernet Status Commands

name	Type	Description
out-drop-pkts	Parameter type: <OctetCounter64> - 64 bit counter,range:[0-9223372036854775808]	Represents for the total errored and discarded packets at transmit <i>This element is only shown in detail mode.</i>
mea-time	Parameter type: <ETHITF::MeaTime> - the specification of measuredtime - range: [0...86400]	Measured in seconds, that statistics for this entry have been counted <i>This element is always shown.</i>
inv-data-flag	Parameter type: <ETHITF::DataFlag> - the specification of invalid-data-flag - range: [0...1]	Indicates the validity of the corresponding PM data <i>This element is always shown.</i>

159.7 Ethernet Counters Near End Line Previous Day

Command Description

Represents for the previous 1day the FCS failure count.

Represents for the previous 1 day the frame too Long count.

Represents for previous 1day MAC sublayer transmit error.

Represents for previous 1day MAC sublayer receive error.

Measured in seconds, that statistics for this entry have been counted.

Indicates the validity of the corresponding PM data.

User Level

The command can be accessed by operators with transport privileges.

Command Syntax

The command has the following syntax:

```
> show ethernet counters near-end line previous-1day [ (if-index) [ interval-no <ETHITF::IntervalNumber1day> ] ]
```

Command Parameters

Table 159.7-1 "Ethernet Counters Near End Line Previous Day" Resource Parameters

Resource Identifier	Type	Description
(if-index)	Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number	interface index of the port
interval-no	Parameter type: <ETHITF::IntervalNumber1day> Format: - the specification of 1day-interval-number - range: [1...30]	1 day interval number

Command Output

Table 159.7-2 "Ethernet Counters Near End Line Previous Day" Display parameters

Specific Information		
name	Type	Description
los	Parameter type: <Counter> - 32 bit counter	Represents for the previous 1day the LOS failure count <i>This element is always shown.</i>
fcs	Parameter type: <Counter> - 32 bit counter	Represents for the previous 1day the FCS failure count <i>This element is always shown.</i>
too-long	Parameter type: <Counter> - 32 bit counter	Represents for the previous 1day the frame too Long count <i>This element is always shown.</i>
mac-trans	Parameter type: <Counter> - 32 bit counter	Represents for the Previous 1 day MAC sublayer transmit error <i>This element is always shown.</i>
mac-rec	Parameter type: <Counter> - 32 bit counter	Represents for the previous 1day MAC sublayer receive error <i>This element is always shown.</i>
in-octets	Parameter type: <OctetCounter64> - 64 bit counter,range:[0-9223372036854775808]	Represents for the total bytes received <i>This element is only shown in detail mode.</i>
in-pkts	Parameter type: <OctetCounter64> - 64 bit counter,range:[0-9223372036854775808]	Represents for the total packets received <i>This element is only shown in detail mode.</i>
in-err-pkts	Parameter type: <OctetCounter64> - 64 bit counter,range:[0-9223372036854775808]	Represents for the total errored packets received <i>This element is only shown in detail mode.</i>
in-discard-pkts	Parameter type: <OctetCounter64> - 64 bit counter,range:[0-9223372036854775808]	Represents for the total discarded packets at receive <i>This element is only shown in detail mode.</i>
in-drop-pkts	Parameter type: <OctetCounter64> - 64 bit counter,range:[0-9223372036854775808]	Represents for the total errored and discarded packets at receive <i>This element is only shown in detail mode.</i>
out-octets	Parameter type: <OctetCounter64> - 64 bit counter,range:[0-9223372036854775808]	Represents for the total bytes transmitted <i>This element is only shown in detail mode.</i>
out-pkts	Parameter type: <OctetCounter64> - 64 bit counter,range:[0-9223372036854775808]	Represents for the total packets transmitted <i>This element is only shown in detail mode.</i>
out-err-pkts	Parameter type: <OctetCounter64> - 64 bit counter,range:[0-9223372036854775808]	Represents for the total errored packets transmitted <i>This element is only shown in detail mode.</i>
out-discard-pkts	Parameter type: <OctetCounter64> - 64 bit counter,range:[0-9223372036854775808]	Represents for the total packets discarded at transmit <i>This element is only shown in detail mode.</i>
out-drop-pkts	Parameter type: <OctetCounter64> - 64 bit counter,range:[0-9223372036854775808]	Represents for the total errored and discarded packets at transmit <i>This element is only shown in detail mode.</i>

name	Type	Description
		<i>detail mode.</i>
mea-time	Parameter type: <ETHITF::MeaTime> - the specification of measuredtime - range: [0...86400]	Measured in seconds, that statistics for this entry have been counted <i>This element is always shown.</i>
inv-data-flag	Parameter type: <ETHITF::DataFlag> - the specification of invalid-data-flag - range: [0...1]	Indicates the validity of the corresponding PM data <i>This element is always shown.</i>

159.8 Ethernet PM Interval Per Interface Status Command

Command Description

This command displays the number of available pm intervals per ethernet interface.

User Level

The command can be accessed by operators with transport privileges.

Command Syntax

The command has the following syntax:

```
> show ethernet eth-int [ (if-index) ]
```

Command Parameters

Table 159.8-1 "Ethernet PM Interval Per Interface Status Command" Resource Parameters

Resource Identifier	Type	Description
(if-index)	Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number	interface index of the port

Command Output

Table 159.8-2 "Ethernet PM Interval Per Interface Status Command" Display parameters

Specific Information		
name	Type	Description
cur-int-elapsedtime	Parameter type: <SignedInteger> - a signed integer	nbr of sec elapsed in cur intvl err-measurement <i>This element is always shown.</i>
cur-1day-elapsedtime	Parameter type: <SignedInteger> - a signed integer	nbr of sec elapsed in cur one day err-measurement <i>This element is always shown.</i>
valid-intervals	Parameter type: <SignedInteger>	nbr of prev intvl for which valid

name	Type	Description
	- a signed integer	data has been stored <i>This element is always shown.</i>
valid-1days	Parameter type: <SignedInteger> - a signed integer	nbr of prev 1Days for which valid data has been stored <i>This element is always shown.</i>

159.9 Ethernet Lt Dot3 Status Command

Command Description

This command displays the statistics for a collection of Ethernet-like interfaces attached to a particular system. There will be one row in this table for each Ethernet-like interface in the system. The parameter stats-index gives an index value that uniquely identifies an interface to an Ethernet-like medium.

The alignment-error parameter gives a count of frames received on a particular interface that are not an integral number of octets in length and do not pass the FCS check. The count represented by an instance of this object is incremented when the alignmentError status is returned by the MAC service to the LLC.

The fcs-error parameter gives a count of frames received on a particular interface that are an integral number of octets in length, but do not pass the FCS check. This count does not include frames received with frame-too-long or frame-too-short error. The count represented by an instance of this object is incremented when the frameCheckError status is returned by the MAC service to the LLC.

The internal-mac-tx-error parameter gives a count of frames for which transmission on a particular interface fails due to an internal MAC sublayer transmit error. A frame is only counted by an instance of this object if it is not counted by the corresponding instance of either the late collisions object, the excessive collisions object, or the carrier sense errors object. The precise meaning of the count represented by an instance of this object is implementation-specific. In particular, an instance of this object may represent a count of transmission errors on a particular interface that are not otherwise counted.

The internal-mac-rx-error parameter gives a count of frames for which reception on a particular interface fails due to an internal MAC sublayer receive error. A frame is only counted by an instance of this object if it is not counted by the corresponding instance of either the frame toolongs object, the alignment errors object, or the FCS errors object. The precise meaning of the count represented by an instance of this object is implementation-specific. In particular, an instance of this object may represent a count of receive errors on a particular interface that are not otherwise counted.

User Level

The command can be accessed by operators with transport privileges.

Command Syntax

The command has the following syntax:

```
> show ethernet dot3stats [ (stats-index) ]
```

Command Parameters

Table 159.9-1 "Ethernet Lt Dot3 Status Command" Resource Parameters

Resource Identifier	Type	Description
(stats-index)	Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId>	index of the interface to an ethernet-like medium

Resource Identifier	Type	Description
	- the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number	

Command Output

Table 159.9-2 "Ethernet Lt Dot3 Status Command" Display parameters

Specific Information		
name	Type	Description
align-err	Parameter type: <Counter> - 32 bit counter	A count of frames received on a particular interface that are not an integral number of octets in length and do not pass the FCS check. The count represented by an instance of this object is incremented when the alignmentError status is returned by the MAC service to the LLC <i>This element is always shown.</i>
fcs-err	Parameter type: <Counter> - 32 bit counter	A count of frames received on a particular interface that are not an integral number of octets in length and do not pass the FCS check. The count represented by an instance of this object is incremented when the frameCheckError status is returned by the MAC service to the LLC <i>This element is always shown.</i>
internal-mac-tx-err	Parameter type: <Counter> - 32 bit counter	A count of frames for which transmission on a particular interface fails due to an internal MAC sublayer transmit error. <i>This element is only shown in detail mode.</i>
internal-mac-rx-err	Parameter type: <Counter> - 32 bit counter	A count of frames for which reception on a particular interface fails due to an internal MAC sublayer receive error. <i>This element is only shown in detail mode.</i>

159.10 Ethernet RMON Counters Status Command

Command Description

This command displays the statistics for a collection of Ethernet-like interfaces attached to a particular system. There will be one row in this table for each Ethernet-like interface in the system. The parameter stats-index gives an index value that uniquely identifies an interface to an Ethernet-like medium.

The alignment-error parameter gives a count of frames received on a particular interface that are not an integral number of octets in length and do not pass the FCS check. The count represented by an instance of this object is incremented when the alignmentError status is returned by the MAC service to the LLC. This counter does not increment for 8-bit wide group encoding schemes. Discontinuities in the value of this counter can occur at re-initialization of the management system.

User Level

The command can be accessed by operators with transport privileges.

Command Syntax

The command has the following syntax:

```
> show ethernet etherstats [ (stats-index) ]
```

Command Parameters

Table 159.10-1 "Ethernet RMON Counters Status Command" Resource Parameters

Resource Identifier	Type	Description
(stats-index)	Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> lt : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> lt-link : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::LtBackPlPortId>) Possible values: - lt : lt-slot - lt-link : lt-slot-port Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number Field type <Eqpt::LtBackPlPortId> - the lt backplane port number	index of the interface to an ethernet-like medium

Command Output

Table 159.10-2 "Ethernet RMON Counters Status Command" Display parameters

Specific Information		
name	Type	Description
entry-status	Parameter type: <ETHIF::CounterEntryStatus> (valid invalid) Possible values: - valid : counters for this ifIndex are valid - invalid : entry represents one of the device's addresses	The status of the entry. Valid indicates the counters have actual values, invalid means the counters are unreliable. <i>This element is always shown.</i>
drop-events	Parameter type: <Counter32> - 64 bit counter	The total number of events in which packets were dropped by the probe due to lack of resources. Note that this number is not necessarily the number of packets dropped; it is just the number of times this condition has been detected. <i>This element is only shown in detail mode.</i>
broadcast-pkts	Parameter type: <Counter32> - 64 bit counter	The total number of good packets received that were directed to the broadcast address. Note that this does not include multicast packets. <i>This element is only shown in detail mode.</i>
multicast-pkts	Parameter type: <Counter32> - 64 bit counter	The total number of good packets received that were directed to a multicast address. Note that this number does not include packets directed to the broadcast address. <i>This element is only shown in detail mode.</i>
oversize-pkts	Parameter type: <Counter32> - 64 bit counter	The total number of packets received that were longer than 1518 octets (excluding framing bits, but including FCS octets). <i>This element is only shown in detail mode.</i>
undersize-pkts	Parameter type: <Counter32> - 64 bit counter	The total number of packets received that were less than 64 octets long (excluding framing bits, but including FCS octets) <i>This element is only shown in detail mode.</i>
fragments	Parameter type: <Counter32> - 64 bit counter	The total number of packets received that were less than 64 octets in length (excluding framing bits but including FCS octets) and had either a bad Frame Check Sequence (FCS) with an integral number of octets (FCS Error) or a bad FCS with a non-integral number of octets (Alignment Error). <i>This element is only shown in detail mode.</i>

159 Ethernet Status Commands

name	Type	Description
jabbers	Parameter type: <Counter32> - 64 bit counter	The total number of packets received that were longer than 1518 octets (excluding framing bits, but including FCS octets), and had either a bad Frame Check Sequence (FCS) with an integral number of octets (FCS Error) or a bad FCS with a non-integral number of octets (Alignment Error). <i>This element is only shown in detail mode.</i>
packets	Parameter type: <OctetCounter64> - 64 bit counter,range:[0-9223372036854775808]	The total number of packets (including bad packets, broadcast packets, and multicast packets) received. <i>This element is always shown.</i>
octets	Parameter type: <OctetCounter64> - 64 bit counter,range:[0-9223372036854775808]	The total number of octets of data (including those in bad packets) received on the network (excluding framing bits but including FCS octets). <i>This element is always shown.</i>
total-64-pkts	Parameter type: <OctetCounter64> - 64 bit counter,range:[0-9223372036854775808]	The total number of packets (including bad packets) received that were 64 octets in length (excluding framing bits but including FCS octets). <i>This element is only shown in detail mode.</i>
total-65to127-pkts	Parameter type: <OctetCounter64> - 64 bit counter,range:[0-9223372036854775808]	The total number of packets (including bad packets) received that were between 65 and 127 octets in length inclusive (excluding framing bits but including FCS octets). <i>This element is only shown in detail mode.</i>
total-128to255-pkts	Parameter type: <OctetCounter64> - 64 bit counter,range:[0-9223372036854775808]	The total number of packets (including bad packets) received that were between 128 and 255 octets in length inclusive (excluding framing bits but including FCS octets). <i>This element is only shown in detail mode.</i>
total-256to511-pkts	Parameter type: <OctetCounter64> - 64 bit counter,range:[0-9223372036854775808]	The total number of packets (including bad packets) received that were between 256 and 511 octets in length inclusive (excluding framing bits but including FCS octets). <i>This element is only shown in detail mode.</i>
total-512to1023-pkts	Parameter type: <OctetCounter64> - 64 bit counter,range:[0-9223372036854775808]	The total number of packets (including bad packets) received that were between 512 and 1023

name	Type	Description
		octets in length inclusive (excluding framing bits but including FCS octets). <i>This element is only shown in detail mode.</i>
total-1024to1518-pkts	Parameter type: <OctetCounter64> - 64 bit counter,range:[0-9223372036854775808]	The total number of packets (including bad packets) received that were between 1024 and 1518 octets in length inclusive (excluding framing bits but including FCS octets). <i>This element is only shown in detail mode.</i>

159.11 Ethernet Statistics Line Status Command

Command Description

This command allow the operator to display the ethernet line counter statistics.

User Level

The command can be accessed by operators with transport privileges.

Command Syntax

The command has the following syntax:

```
> show ethernet statistics line [ (if-index) ]
```

Command Parameters

Table 159.11-1 "Ethernet Statistics Line Status Command" Resource Parameters

Resource Identifier	Type	Description
(if-index)	Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number	interface index of the ethernet line

Command Output

Table 159.11-2 "Ethernet Statistics Line Status Command" Display parameters

Specific Information		
name	Type	Description
in-octets	Parameter type: <OctetCounter64> - 64 bit counter,range:[0-9223372036854775808]	the total number of octets received on the interface,including framing characters <i>This element is always shown.</i>
in-discard-pkts	Parameter type: <OctetCounter64> - 64 bit counter,range:[0-9223372036854775808]	the number of inbound packets which were chosen to be discarded even though no errors had been detected to prevent their being deliverable to a

name	Type	Description
		higher-layer protocol. <i>This element is only shown in detail mode.</i>
in-ucast-pkts	Parameter type: <OctetCounter64> - 64 bit counter,range:[0-9223372036854775808]	the number of packets, delivered by this sub-layer to a higher (sub-)layer, which were not addressed to a multicast or broadcast address at this sub-layer. <i>This element is only shown in detail mode.</i>
in-nucast-pkts	Parameter type: <OctetCounter64> - 64 bit counter,range:[0-9223372036854775808]	the number of packets, delivered by this sub-layer to a higher (sub-)layer, which were addressed to a multicast or broadcast address at this sub-layer. <i>This element is only shown in detail mode.</i>
in-err-pkts	Parameter type: <OctetCounter64> - 64 bit counter,range:[0-9223372036854775808]	for packet-oriented interfaces, the number of inbound packets that contained errors preventing them from being deliverable to a higher-layer protocol. <i>This element is only shown in detail mode.</i>
in-bcast-pkts	Parameter type: <OctetCounter64> - 64 bit counter,range:[0-9223372036854775808]	the number of packets, delivered by this sub-layer to a higher (sub-)layer, which were addressed to a broadcast address at this sub-layer. <i>This element is only shown in detail mode.</i>
in-mcast-pkts	Parameter type: <OctetCounter64> - 64 bit counter,range:[0-9223372036854775808]	the number of packets, delivered by this sub-layer to a higher (sub-)layer, which were addressed to a multicast address at this sub-layer. <i>This element is only shown in detail mode.</i>
pkts-unknown-proto	Parameter type: <OctetCounter64> - 64 bit counter,range:[0-9223372036854775808]	for packet-oriented interfaces, the number of packets received via the interface which were discarded because of an unknown or unsupported protocol. <i>This element is only shown in detail mode.</i>
out-octets	Parameter type: <OctetCounter64> - 64 bit counter,range:[0-9223372036854775808]	the total number of octets transmitted out of the interface, including framing characters. <i>This element is always shown.</i>
out-disc-pkts	Parameter type: <OctetCounter64> - 64 bit counter,range:[0-9223372036854775808]	the number of outbound packets which were chosen to be discarded even though no errors had been detected to prevent their being transmitted. <i>This element is only shown in</i>

159 Ethernet Status Commands

name	Type	Description
		<i>detail mode.</i>
out-ucast-pkts	Parameter type: <OctetCounter64> - 64 bit counter,range:[0-9223372036854775808]	the total number of packets that higher-level protocols requested be transmitted, and which were not addressed to a multicast or broadcast address at this sub-layer. <i>This element is only shown in detail mode.</i>
out-nucast-pkts	Parameter type: <OctetCounter64> - 64 bit counter,range:[0-9223372036854775808]	the total number of packets that higher-level protocols requested be transmitted, and which were addressed to a multicast or broadcast address at this sub-layer. <i>This element is only shown in detail mode.</i>
out-err-pkts	Parameter type: <OctetCounter64> - 64 bit counter,range:[0-9223372036854775808]	for packet-oriented interfaces, the number of outbound packets that could not be transmitted because of errors. <i>This element is only shown in detail mode.</i>
out-mcast-pkts	Parameter type: <OctetCounter64> - 64 bit counter,range:[0-9223372036854775808]	the total number of packets that higher-level protocols requested be transmitted, and which were addressed to a multicast address at this sub-layer. <i>This element is only shown in detail mode.</i>
out-bcast-pkts	Parameter type: <OctetCounter64> - 64 bit counter,range:[0-9223372036854775808]	the total number of packets that higher-level protocols requested be transmitted, and which were addressed to a broadcast address at this sub-layer. <i>This element is only shown in detail mode.</i>

159.12 Ethernet Ont Port Operational Status Command

Command Description

This command reports current operational parameters for the ONT Ethernet

User Level

The command can be accessed by operators with transport privileges.

Command Syntax

The command has the following syntax:

```
> show ethernet ont operational-data [ (uni-idx) ]
```

Command Parameters

Table 159.12-1 "Ethernet Ont Port Operational Status Command" Resource Parameters

Resource Identifier	Type	Description
(uni-idx)	Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Gpon::OntSlotId> / <Gpon::OntPortId> ng2 : <Ng2::ChannelGroup> / <Ng2::SubchannelGroup> / <Ng2::OntId> / <Gpon::OntSlotId> / <Gpon::OntPortId>) Possible values: - ng2 : ngpon2 style identification Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Ng2::ChannelGroup> - channel group number Field type <Ng2::SubchannelGroup> - subchannel group number Field type <Eqpt::OntId> - the ONT identifier Field type <Ng2::OntId> - the ONT identifier Field type <Gpon::OntSlotId> - Gpon Ont Slot	identification of the uni interface index

Resource Identifier	Type	Description
	- range: [1...14] - Field type <Gpon::OntPortId> - Gpon Ont Port - range: [1...16]	

Command Output

Table 159.12-2 "Ethernet Ont Port Operational Status Command" Display parameters

Specific Information		
name	Type	Description
config-indicator	Parameter type: <Gpon::ConfigIndicator> (not-detected 10baset-fd 100baset-fd gige-fd 10gige 2.5gig-fd 5gig-fd 10base-hd 100base-hd gige-hd) Possible values: - not-detected : status not detected - 10baset-fd : ten base T with full duplex - 100baset-fd : hundred base T with full duplex - gige-fd : full duplex gige - 10gige : full duplex 10 gige - 2.5gig-fd : 2.5 Gig, full duplex - 5gig-fd : 5 Gig, full duplex - 10base-hd : ten base T with half duplex - 100base-hd : 100 base T half duplex - gige-hd : half duplex gige	ethernet uni configure status indication <i>This element is always shown.</i>
link-status	Parameter type: <Gpon::LinkStatus> (up down) Possible values: - up : carrier detected - down : no carrier detected	indication of carrier detection status of the ethernet uni <i>This element is always shown.</i>
power-provided	Parameter type: <Gpon::PowerProvided> (unknown nosupport <Gpon::PowerPro>) Possible values: - unknown : unknown the actual power consumed - nosupport : not supported this ME or attribute Field type <Gpon::PowerPro> - power provided value - unit: mWatts - range: [0...4294967295]	indication power provided for each port(unit is mW) <i>This element is always shown.</i>

159.13 ONT Ethernet Port Performance Monitoring

Current-Interval Status Command

Command Description

This command reports command retrieves Ethernet performance monitoring data from the ONT(s)

User Level

The command can be accessed by operators with transport privileges.

Command Syntax

The command has the following syntax:

```
> show ethernet ont port current-interval [ (uni-idx) ]
```

Command Parameters

Table 159.13-1 "ONT Ethernet Port Performance Monitoring Current-Interval Status Command" Resource Parameters

Resource Identifier	Type	Description
(uni-idx)	Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Gpon::OntSlotId> / <Gpon::OntPortId> ng2 : <Ng2::ChannelGroup> / <Ng2::SubchannelGroup> / <Ng2::OntId> / <Gpon::OntSlotId> / <Gpon::OntPortId>) Possible values: - ng2 : ngpon2 style identification Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Ng2::ChannelGroup> - channel group number Field type <Ng2::SubchannelGroup> - subchannel group number Field type <Eqpt::OntId> - the ONT identifier Field type <Ng2::OntId> - the ONT identifier Field type <Gpon::OntSlotId>	identification of the uni interface index

Resource Identifier	Type	Description
	- Gpon Ont Slot - range: [1...14] Field type <Gpon::OntPortId> - Gpon Ont Port - range: [1...16]	

Command Output

Table 159.13-2 "ONT Ethernet Port Performance Monitoring Current-Interval Status Command"
Display parameters

Specific Information		
name	Type	Description
fcse	Parameter type: <Counter> - 32 bit counter	count of frame Check sequence(fcs)errors <i>This element is always shown.</i>
ec	Parameter type: <Counter> - 32 bit counter	count of excessive collisions <i>This element is always shown.</i>
lc	Parameter type: <Counter> - 32 bit counter	count of late collisions <i>This element is always shown.</i>
ftl	Parameter type: <Counter> - 32 bit counter	count of frames that are too long <i>This element is always shown.</i>
rbo	Parameter type: <Counter> - 32 bit counter	count of receive buffer overflows <i>This element is always shown.</i>
tbo	Parameter type: <Counter> - 32 bit counter	count of transmit buffer overflows <i>This element is always shown.</i>
scf	Parameter type: <Counter> - 32 bit counter	count of successfully transmitted single collision frames <i>This element is always shown.</i>
mcf	Parameter type: <Counter> - 32 bit counter	count of successfully transmitted multiple collision frames <i>This element is always shown.</i>
sqe	Parameter type: <Counter> - 32 bit counter	count of sqe test error messages generated <i>This element is always shown.</i>
dt	Parameter type: <Counter> - 32 bit counter	count of frames delayed due to deferred transmission <i>This element is always shown.</i>
imte	Parameter type: <Counter> - 32 bit counter	count of unsuccessfully transmitted frames due to internal mac transmit error <i>This element is always shown.</i>
cse	Parameter type: <Counter> - 32 bit counter	a count of carrier sense errors <i>This element is always shown.</i>
ae	Parameter type: <Counter> - 32 bit counter	count of frames having alignment errors <i>This element is always shown.</i>
imre	Parameter type: <Counter> - 32 bit counter	count of unsuccessfully received frames due to internal mac receive error <i>This element is always shown.</i>

159.14 ONT Ethernet Port Performance Monitoring Previous-Interval Status Command

Command Description

This command reports command retrieves Ethernet performance monitoring data from the ONT(s)

User Level

The command can be accessed by operators with transport privileges.

Command Syntax

The command has the following syntax:

```
> show ethernet ont port previous-interval [ (uni-idx) [ interval-num <Gpon::IntervalNo> ] ]
```

Command Parameters

Table 159.14-1 "ONT Ethernet Port Performance Monitoring Previous-Interval Status Command" Resource Parameters

Resource Identifier	Type	Description
(uni-idx)	Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Gpon::OntSlotId> / <Gpon::OntPortId> ng2 : <Ng2::ChannelGroup> / <Ng2::SubchannelGroup> / <Ng2::OntId> / <Gpon::OntSlotId> / <Gpon::OntPortId>) Possible values: - ng2 : ngpon2 style identification Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Ng2::ChannelGroup> - channel group number Field type <Ng2::SubchannelGroup> - subchannel group number Field type <Eqpt::OntId> - the ONT identifier Field type <Ng2::OntId> - the ONT identifier Field type <Gpon::OntSlotId>	identification of the uni interface index

Resource Identifier	Type	Description
	- Gpon Ont Slot - range: [1...14] Field type <Gpon::OntPortId> - Gpon Ont Port - range: [1...16]	
interval-num	Parameter type: <Gpon::IntervalNo> Format: - a number of a previous interval number - range: [1...32]	identifies prev 15min intvls, val 1 as the latest intvl

Command Output

Table 159.14-2 "ONT Ethernet Port Performance Monitoring Previous-Interval Status Command"
Display parameters

Specific Information		
name	Type	Description
fcse	Parameter type: <Counter> - 32 bit counter	count of frame Check sequence(fcs)errors <i>This element is always shown.</i>
ec	Parameter type: <Counter> - 32 bit counter	count of excessive collisions <i>This element is always shown.</i>
lc	Parameter type: <Counter> - 32 bit counter	count of late collisions <i>This element is always shown.</i>
ftl	Parameter type: <Counter> - 32 bit counter	count of frames that are too long <i>This element is always shown.</i>
rbo	Parameter type: <Counter> - 32 bit counter	count of receive buffer overflows <i>This element is always shown.</i>
tbo	Parameter type: <Counter> - 32 bit counter	count of transmit buffer overflows <i>This element is always shown.</i>
scf	Parameter type: <Counter> - 32 bit counter	count of successfully transmitted single collision frames <i>This element is always shown.</i>
mcf	Parameter type: <Counter> - 32 bit counter	count of successfully transmitted multiple collision frames <i>This element is always shown.</i>
sqe	Parameter type: <Counter> - 32 bit counter	count of sqe test error messages generated <i>This element is always shown.</i>
dt	Parameter type: <Counter> - 32 bit counter	count of frames delayed due to deferred transmission <i>This element is always shown.</i>
imte	Parameter type: <Counter> - 32 bit counter	count of unsuccessfully transmitted frames due to internal mac transmit error <i>This element is always shown.</i>
cse	Parameter type: <Counter> - 32 bit counter	a count of carrier sense errors <i>This element is always shown.</i>
ae	Parameter type: <Counter> - 32 bit counter	count of frames having alignment errors <i>This element is always shown.</i>
imre	Parameter type: <Counter> - 32 bit counter	count of unsuccessfully received frames due to internal mac receive error <i>This element is always shown.</i>

159.15 Ethernet Ont Port loopback Status Command

Command Description

This command reports current loopback mode information for the ONT Ethernet port

User Level

The command can be accessed by operators with transport privileges.

Command Syntax

The command has the following syntax:

```
> show ethernet ont loopback-info [ (uni-idx) ]
```

Command Parameters

Table 159.15-1 "Ethernet Ont Port loopback Status Command" Resource Parameters

Resource Identifier	Type	Description
(uni-idx)	Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Gpon::OntSlotId> / <Gpon::OntPortId> ng2 : <Ng2::ChannelGroup> / <Ng2::SubchannelGroup> / <Ng2::OntId> / <Gpon::OntSlotId> / <Gpon::OntPortId>) Possible values: - ng2 : ngpon2 style identification Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Ng2::ChannelGroup> - channel group number Field type <Ng2::SubchannelGroup> - subchannel group number Field type <Eqpt::OntId> - the ONT identifier Field type <Ng2::OntId> - the ONT identifier Field type <Gpon::OntSlotId> - Gpon Ont Slot	identification of the uni interface index

Resource Identifier	Type	Description
	- range: [1...14] - Field type <Gpon::OntPortId> - Gpon Ont Port - range: [1...16]	

Command Output

Table 159.15-2 "Ethernet Ont Port loopback Status Command" Display parameters

Specific Information		
name	Type	Description
loop-status	Parameter type: <Gpon::loopback> (loopback no-loopback) Possible values: - loopback : enable UNI port loopback mode - no-loopback : disable UNI port loopback mode	indication of loopback status of the ethernet uni <i>This element is always shown.</i>
timeout-value	Parameter type: <Gpon::loopbackTimeout> - loopback time, zero means no-timeout for loopback - unit: sec - range: [0...43200]	configured timeout value for loopback mode of the ethernet uni <i>This element is always shown.</i>
loop-remaining time	Parameter type: <Gpon::loopbackTimeout> - loopback time, zero means no-timeout for loopback - unit: sec - range: [0...43200]	remaining time before loopback removed automatically <i>This element is always shown.</i>

159.16 Epon Ont Ethernet Status Command

Command Description

This command displays epon ont Ethernet port operational status.

User Level

The command can be accessed by operators with transport privileges.

Command Syntax

The command has the following syntax:

```
> show ethernet eont port
```

159.17 Epon Ont Ethernet Port Information Command

Command Description

This command displays information of a specific Ont Ethernet Port

User Level

The command can be accessed by operators with transport privileges.

Command Syntax

The command has the following syntax:

```
> show ethernet eont port information [ (uni-index) ]
```

Command Parameters

Table 159.17-1 "Epon Ont Ethernet Port Information Command" Resource Parameters

Resource Identifier	Type	Description
(uni-index)	Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Epon::EontSlot> / <Epon::EontPort> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Eqpt::OntId> - the ONT identifier Field type <Epon::EontSlot> - Epon Ont Slot - range: [1...16] Field type <Epon::EontPort> - Epon Ont Port - range: [1...64]	ONT UNI interface

Command Output

Table 159.17-2 "Epon Ont Ethernet Port Information Command" Display parameters

Specific Information		
name	Type	Description
audetect-oper	Parameter type: <Epon::AutoDetect> (enable disable) Possible values: - enable : enable auto negotiation - disable : disable auto negotiation	operational state of the auto negotiation <i>This element is always shown.</i>

Only Show Details: auto negotiation operational state		
name	Type	Description
global-oper	Parameter type: <Epon::global> (yes no) Possible values: - yes : global supported - no : global not supported	operational state of auto negotiation global <i>This element is only shown in detail mode.</i>
other-oper	Parameter type: <Epon::other> (yes no) Possible values: - yes : other supported - no : other not supported	operational state of auto negotiation other <i>This element is only shown in detail mode.</i>
unkown-oper	Parameter type: <Epon::unkown> (yes no) Possible values: - yes : unknown supported - no : unknown not supported	operational state of auto negotiation unknown <i>This element is only shown in detail mode.</i>
autoneg10t-oper	Parameter type: <Epon::autoneg10t> (yes no) Possible values: - yes : 10t supported - no : 10t not supported	operational state of auto negotiation 10t <i>This element is only shown in detail mode.</i>
autoneg10tfd-oper	Parameter type: <Epon::autoneg10tfd> (yes no) Possible values: - yes : 10tfd supported - no : 10tfd not supported	operational state of auto negotiation 10tfd <i>This element is only shown in detail mode.</i>
autoneg100t4-oper	Parameter type: <Epon::autoneg100t4> (yes no) Possible values: - yes : 100t4 supported - no : 100t4 not supported	operational state of auto negotiation 100t4 <i>This element is only shown in detail mode.</i>
autoneg100tx-oper	Parameter type: <Epon::autoneg100tx> (yes no) Possible values: - yes : 100tx supported - no : 100tx not supported	operational state of auto negotiation 100tx <i>This element is only shown in detail mode.</i>
autoneg100txfd-oper	Parameter type: <Epon::autoneg100txfd> (yes no) Possible values: - yes : 100txfd supported - no : 100txfd not supported	operational state of auto negotiation 100txfd <i>This element is only shown in detail mode.</i>

name	Type	Description
autoneg100t2-oper	Parameter type: <Epon::autoneg100t2> (yes no) Possible values: - yes : 100t2 supported - no : 100t2 not supported	operational state of auto negotiation 100t2 <i>This element is only shown in detail mode.</i>
autoneg100t2fd-oper	Parameter type: <Epon::autoneg100t2fd> (yes no) Possible values: - yes : 100t2fd supported - no : 100t2fd not supported	operational state of auto negotiation 100t2fd <i>This element is only shown in detail mode.</i>
autoneg1000x-oper	Parameter type: <Epon::autoneg1000x> (yes no) Possible values: - yes : 1000x supported - no : 1000x not supported	operational state of auto negotiation 1000x <i>This element is only shown in detail mode.</i>
autoneg1000xfd-oper	Parameter type: <Epon::autoneg1000xfd> (yes no) Possible values: - yes : 1000xfd supported - no : 1000xfd not supported	operational state of auto negotiation 1000xfd <i>This element is only shown in detail mode.</i>
autoneg1000t-oper	Parameter type: <Epon::autoneg1000t> (yes no) Possible values: - yes : 1000t supported - no : 1000t not supported	operational state of auto negotiation 1000t <i>This element is only shown in detail mode.</i>
autoneg1000tfd-oper	Parameter type: <Epon::autoneg1000tfd> (yes no) Possible values: - yes : 1000tfd supported - no : 1000tfd not supported	operational state of auto negotiation 1000tfd <i>This element is only shown in detail mode.</i>
fdxpause-oper	Parameter type: <Epon::fdxpause> (yes no) Possible values: - yes : fdxpause supported - no : fdxpause not supported	operational state of auto negotiation fdxpause <i>This element is only shown in detail mode.</i>
fdxapause-oper	Parameter type: <Epon::fdxapause> (yes no) Possible values: - yes : fdxapause supported - no : fdxapause not supported	operational state of auto negotiation fdxapause <i>This element is only shown in detail mode.</i>
fdxspause-oper	Parameter type: <Epon::fdxspause> (yes no) Possible values: - yes : fdxspause supported - no : fdxspause not supported	operational state of auto negotiation fdxspause <i>This element is only shown in detail mode.</i>
fdxbpause-oper	Parameter type: <Epon::fdxbpause> (yes no)	operational state of auto negotiation fdxbpause <i>This element is only shown in</i>

159 Ethernet Status Commands

name	Type	Description
	Possible values: - yes : fdxbpause supported - no : fdxbpause not supported	<i>detail mode.</i>
remfault1-oper	Parameter type: <Epon::remfault1> (yes no) Possible values: - yes : remfault1 supported - no : remfault1 not supported	operational state of auto negotiation remfault1 <i>This element is only shown in detail mode.</i>
remfault2-oper	Parameter type: <Epon::remfault2> (yes no) Possible values: - yes : remfault2 supported - no : remfault2 not supported	operational state of auto negotiation remfault2 <i>This element is only shown in detail mode.</i>
isoethernet-oper	Parameter type: <Epon::isoethernet> (yes no) Possible values: - yes : isoethernet supported - no : isoethernet not supported	operational state of auto negotiation isoethernet <i>This element is only shown in detail mode.</i>

159.18 Epon Ont Ethernet Port Fdb Command

Command Description

This command displays Fdb table of Ont Ethernet Port

User Level

The command can be accessed by operators with transport privileges.

Command Syntax

The command has the following syntax:

```
> show ethernet eont port fdb [ (uni-idx) [ vlan <Vlan::Index> ] [ mac-address <Vlan::MacAddr> ] ]
```

Command Parameters

Table 159.18-1 "Epon Ont Ethernet Port Fdb Command" Resource Parameters

Resource Identifier	Type	Description
(uni-idx)	Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Epon::EontSlotId> / <Epon::EontPortId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Eqpt::OntId> - the ONT identifier Field type <Epon::EontSlotId> - Epon Ont Slot Field type <Epon::EontPortId> - Epon Ont Port	ONT UNI interface
vlan	Parameter type: <Vlan::Index> Format: (<Vlan::UVlanIndex> stacked : <Vlan::SVlanIndexStacked> : <Vlan::CVlanIndex>) Possible values: - stacked : stacked vlan identity Field type <Vlan::UVlanIndex> - unstacked vlan identity - range: [1...4093,4096] Field type <Vlan::SVlanIndexStacked>	user vlan on an ont ethernet port

Resource Identifier	Type	Description
	- service vlan identity - range: [1...4093] Field type <Vlan::CVlanIndex> - customer vlan identity - range: [0...4093]	
mac-address	Parameter type: <Vlan::MacAddr> Format: - mac address (aa:bb:cc:a1:02:03) - unit: Byte - length: 6	mac address on an ont ethernet port

Command Output

Table 159.18-2 "Epon Ont Ethernet Port Fdb Command" Display parameters

Specific Information		
name	Type	Description
status	Parameter type: <Vlan::FdbEntryStatus> (other invalid learned self static) Possible values: - other : entry does not determine the forwarding of frames - invalid : entry is being removed - learned : entry has been learned dynamically - self : entry represents one of the device's addresses - static : entry has been configured by a manager	Fdb entry status on an ont ethernet port <i>This element is always shown.</i>

159.19 Epon Ont Ethernet Status Command

Command Description

This command indicates the Epon performance counters of an ont ethernet Port.

User Level

The command can be accessed by operators with transport privileges.

Command Syntax

The command has the following syntax:

```
> show ethernet eont tc-layer
```

159.20 Epon Ont Ethernet Current 15min Status Command

Command Description

User Level

The command can be accessed by operators with transport privileges.

Command Syntax

The command has the following syntax:

```
> show ethernet eont tc-layer current-15min [ (uni-idx) ]
```

Command Parameters

Table 159.20-1 "Epon Ont Ethernet Current 15min Status Command" Resource Parameters

Resource Identifier	Type	Description
(uni-idx)	Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Epon::EontSlotId> / <Epon::EontPortId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Eqpt::OntId> - the ONT identifier Field type <Epon::EontSlotId> - Epon Ont Slot Field type <Epon::EontPortId> - Epon Ont Port	ONT UNI interface

Command Output

Table 159.20-2 "Epon Ont Ethernet Current 15min Status Command" Display parameters

Specific Information		
name	Type	Description
elapsed-time	Parameter type: <SignedInteger> - a signed integer	Elapsed time in interval <i>This element is always shown.</i>

name	Type	Description
measure-time	Parameter type: <SignedInteger> - a signed integer	Measured time in interval <i>This element is always shown.</i>
octets-up	Parameter type: <Epon::OctetCounter> - Epon Frames counter	octets transferred in upstream direction <i>This element is always shown.</i>
frames-up	Parameter type: <Epon::OctetCounter> - Epon Frames counter	Total Frames transferred in upstream direction <i>This element is always shown.</i>
broadcastframes-up	Parameter type: <Epon::OctetCounter> - Epon Frames counter	Broadcast Frames transferred in upstream direction <i>This element is only shown in detail mode.</i>
crcerrframes-up	Parameter type: <Epon::OctetCounter> - Epon Frames counter	CRC error Frames transferred in upstream direction <i>This element is only shown in detail mode.</i>
pauseframes-up	Parameter type: <Epon::OctetCounter> - Epon Frames counter	pause Frames transferred in upstream direction <i>This element is only shown in detail mode.</i>
segment1octets-up	Parameter type: <Epon::OctetCounter> - Epon Frames counter	64 Octet Frames in upstream direction <i>This element is only shown in detail mode.</i>
segment2octets-up	Parameter type: <Epon::OctetCounter> - Epon Frames counter	65-127 Octet Frames in upstream direction <i>This element is only shown in detail mode.</i>
segment3octets-up	Parameter type: <Epon::OctetCounter> - Epon Frames counter	128-255 Octet Frames in upstream direction <i>This element is only shown in detail mode.</i>
segment4octets-up	Parameter type: <Epon::OctetCounter> - Epon Frames counter	256-511 Octet Frames in upstream direction <i>This element is only shown in detail mode.</i>
segment5octets-up	Parameter type: <Epon::OctetCounter> - Epon Frames counter	512-1023 Octet Frames in upstream direction <i>This element is only shown in detail mode.</i>
segment6octets-up	Parameter type: <Epon::OctetCounter> - Epon Frames counter	1024-1518 Octet Frames in upstream direction <i>This element is only shown in detail mode.</i>
segment7octets-up	Parameter type: <Epon::OctetCounter> - Epon Frames counter	1519+ Octet Frames in upstream direction <i>This element is only shown in detail mode.</i>
octets-down	Parameter type: <Epon::OctetCounter> - Epon Frames counter	octets transferred in downstream direction <i>This element is always shown.</i>
frames-down	Parameter type: <Epon::OctetCounter> - Epon Frames counter	Total Frames transferred in downstream direction <i>This element is always shown.</i>
broadcastframes-down	Parameter type: <Epon::OctetCounter> - Epon Frames counter	Broadcast Frames transferred in downstream direction <i>This element is only shown in</i>

159 Ethernet Status Commands

name	Type	Description
		<i>detail mode.</i>
crcerrframes-down	Parameter type: <Epon::OctetCounter> - Epon Frames counter	CRC error Frames transferred in downstream direction <i>This element is only shown in detail mode.</i>
pauseframes-down	Parameter type: <Epon::OctetCounter> - Epon Frames counter	pause Frames transferred in downstream direction <i>This element is only shown in detail mode.</i>
segment1octets-down	Parameter type: <Epon::OctetCounter> - Epon Frames counter	64 Octet Frames in downstream direction <i>This element is only shown in detail mode.</i>
segment2octets-down	Parameter type: <Epon::OctetCounter> - Epon Frames counter	65-127 Octet Frames in downstream direction <i>This element is only shown in detail mode.</i>
segment3octets-down	Parameter type: <Epon::OctetCounter> - Epon Frames counter	128-255 Octet Frames in downstream direction <i>This element is only shown in detail mode.</i>
segment4octets-down	Parameter type: <Epon::OctetCounter> - Epon Frames counter	256-511 Octet Frames in downstream direction <i>This element is only shown in detail mode.</i>
segment5octets-down	Parameter type: <Epon::OctetCounter> - Epon Frames counter	512-1023 Octet Frames in downstream direction <i>This element is only shown in detail mode.</i>
segment6octets-down	Parameter type: <Epon::OctetCounter> - Epon Frames counter	1024-1518 Octet Frames in downstream direction <i>This element is only shown in detail mode.</i>
segment7octets-down	Parameter type: <Epon::OctetCounter> - Epon Frames counter	1519+ Octet Frames in downstream direction <i>This element is only shown in detail mode.</i>
unicastframes-up	Parameter type: <Epon::OctetCounter> - Epon Frames counter	Unicast Frames transferred in upstream direction <i>This element is only shown in detail mode.</i>
unicastframes-down	Parameter type: <Epon::OctetCounter> - Epon Frames counter	Unicast Frames transferred in downstream direction <i>This element is only shown in detail mode.</i>
multicastframes-up	Parameter type: <Epon::OctetCounter> - Epon Frames counter	Multicast Frames transferred in upstream direction <i>This element is only shown in detail mode.</i>
multicastframes-down	Parameter type: <Epon::OctetCounter> - Epon Frames counter	Multicast Frames transferred in downstream direction <i>This element is only shown in detail mode.</i>
drpframes-up	Parameter type: <Epon::OctetCounter> - Epon Frames counter	Discard Frames transferred in upstream direction <i>This element is only shown in detail mode.</i>

name	Type	Description
drpframes-down	Parameter type: <Epon::OctetCounter> - Epon Frames counter	Discard Frames transferred in downstream direction <i>This element is only shown in detail mode.</i>
errframes-up	Parameter type: <Epon::OctetCounter> - Epon Frames counter	Error Frames transferred in upstream direction <i>This element is only shown in detail mode.</i>
errframes-down	Parameter type: <Epon::OctetCounter> - Epon Frames counter	Error Frames transferred in downstream direction <i>This element is only shown in detail mode.</i>
undframes-up	Parameter type: <Epon::OctetCounter> - Epon Frames counter	less than 64 bytes Frames transferred in upstream direction <i>This element is only shown in detail mode.</i>
undframes-down	Parameter type: <Epon::OctetCounter> - Epon Frames counter	less than 64 bytes Frames transferred in downstream direction <i>This element is only shown in detail mode.</i>
ovrframes-up	Parameter type: <Epon::OctetCounter> - Epon Frames counter	1526+ Frames transferred in upstream direction <i>This element is only shown in detail mode.</i>
ovrframes-down	Parameter type: <Epon::OctetCounter> - Epon Frames counter	1526+ Frames transferred in downstream direction <i>This element is only shown in detail mode.</i>
statuschange	Parameter type: <Epon::OctetCounter> - Epon Frames counter	port status change times <i>This element is only shown in detail mode.</i>
dropevents-up	Parameter type: <Epon::OctetCounter> - Epon Frames counter	drop event in upstream direction on a ONT ethernet port <i>This element is only shown in detail mode.</i>
dropevents-down	Parameter type: <Epon::OctetCounter> - Epon Frames counter	drop event in downstream direction on a ONT ethernet port <i>This element is only shown in detail mode.</i>
fragments-up	Parameter type: <Epon::OctetCounter> - Epon Frames counter	fragment frames in upstream direction on a ONT ethernet port <i>This element is only shown in detail mode.</i>
fragments-down	Parameter type: <Epon::OctetCounter> - Epon Frames counter	fragment frames in downstream direction on a ONT ethernet port <i>This element is only shown in detail mode.</i>
jabberframes-up	Parameter type: <Epon::OctetCounter> - Epon Frames counter	jabber frames in upstream direction on a ONT ethernet port <i>This element is only shown in detail mode.</i>
jabberframes-down	Parameter type: <Epon::OctetCounter> - Epon Frames counter	jabber frames in downstream direction on a ONT ethernet port <i>This element is only shown in detail mode.</i>

159.21 Epon Ont Ethernet Current 1Day Status Command

Command Description

User Level

The command can be accessed by operators with transport privileges.

Command Syntax

The command has the following syntax:

```
> show ethernet eont tc-layer current-1day [ (uni-idx) ]
```

Command Parameters

Table 159.21-1 "Epon Ont Ethernet Current 1Day Status Command" Resource Parameters

Resource Identifier	Type	Description
(uni-idx)	Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Epon::EontSlotId> / <Epon::EontPortId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Eqpt::OntId> - the ONT identifier Field type <Epon::EontSlotId> - Epon Ont Slot Field type <Epon::EontPortId> - Epon Ont Port	ONT UNI interface

Command Output

Table 159.21-2 "Epon Ont Ethernet Current 1Day Status Command" Display parameters

Specific Information		
name	Type	Description
elapsed-time	Parameter type: <SignedInteger> - a signed integer	Elapsed time in interval <i>This element is always shown.</i>

159 Ethernet Status Commands

name	Type	Description
measure-time	Parameter type: <SignedInteger> - a signed integer	Measured time in interval <i>This element is always shown.</i>
octets-up	Parameter type: <Epon::OctetCounter> - Epon Frames counter	octets transferred in upstream direction <i>This element is always shown.</i>
frames-up	Parameter type: <Epon::OctetCounter> - Epon Frames counter	Total Frames transferred in upstream direction <i>This element is always shown.</i>
broadcastframes-up	Parameter type: <Epon::OctetCounter> - Epon Frames counter	Broadcast Frames transferred in upstream direction <i>This element is only shown in detail mode.</i>
crcerrframes-up	Parameter type: <Epon::OctetCounter> - Epon Frames counter	CRC error Frames transferred in upstream direction <i>This element is only shown in detail mode.</i>
pauseframes-up	Parameter type: <Epon::OctetCounter> - Epon Frames counter	pause Frames transferred in upstream direction <i>This element is only shown in detail mode.</i>
segment1octets-up	Parameter type: <Epon::OctetCounter> - Epon Frames counter	64 Octet Frames in upstream direction <i>This element is only shown in detail mode.</i>
segment2octets-up	Parameter type: <Epon::OctetCounter> - Epon Frames counter	65-127 Octet Frames in upstream direction <i>This element is only shown in detail mode.</i>
segment3octets-up	Parameter type: <Epon::OctetCounter> - Epon Frames counter	128-255 Octet Frames in upstream direction <i>This element is only shown in detail mode.</i>
segment4octets-up	Parameter type: <Epon::OctetCounter> - Epon Frames counter	256-511 Octet Frames in upstream direction <i>This element is only shown in detail mode.</i>
segment5octets-up	Parameter type: <Epon::OctetCounter> - Epon Frames counter	512-1023 Octet Frames in upstream direction <i>This element is only shown in detail mode.</i>
segment6octets-up	Parameter type: <Epon::OctetCounter> - Epon Frames counter	1024-1518 Octet Frames in upstream direction <i>This element is only shown in detail mode.</i>
segment7octets-up	Parameter type: <Epon::OctetCounter> - Epon Frames counter	1519+ Octet Frames in upstream direction <i>This element is only shown in detail mode.</i>
octets-down	Parameter type: <Epon::OctetCounter> - Epon Frames counter	octets transferred in downstream direction <i>This element is always shown.</i>
frames-down	Parameter type: <Epon::OctetCounter> - Epon Frames counter	Total Frames transferred in downstream direction <i>This element is always shown.</i>
broadcastframes-down	Parameter type: <Epon::OctetCounter> - Epon Frames counter	Broadcast Frames transferred in downstream direction <i>This element is only shown in</i>

name	Type	Description
		<i>detail mode.</i>
crcerrframes-down	Parameter type: <Epon::OctetCounter> - Epon Frames counter	CRC error Frames transferred in downstream direction <i>This element is only shown in detail mode.</i>
pauseframes-down	Parameter type: <Epon::OctetCounter> - Epon Frames counter	pause Frames transferred in downstream direction <i>This element is only shown in detail mode.</i>
segment1octets-down	Parameter type: <Epon::OctetCounter> - Epon Frames counter	64 Octet Frames in downstream direction <i>This element is only shown in detail mode.</i>
segment2octets-down	Parameter type: <Epon::OctetCounter> - Epon Frames counter	65-127 Octet Frames in downstream direction <i>This element is only shown in detail mode.</i>
segment3octets-down	Parameter type: <Epon::OctetCounter> - Epon Frames counter	128-255 Octet Frames in downstream direction <i>This element is only shown in detail mode.</i>
segment4octets-down	Parameter type: <Epon::OctetCounter> - Epon Frames counter	256-511 Octet Frames in downstream direction <i>This element is only shown in detail mode.</i>
segment5octets-down	Parameter type: <Epon::OctetCounter> - Epon Frames counter	512-1023 Octet Frames in downstream direction <i>This element is only shown in detail mode.</i>
segment6octets-down	Parameter type: <Epon::OctetCounter> - Epon Frames counter	1024-1518 Octet Frames in downstream direction <i>This element is only shown in detail mode.</i>
segment7octets-down	Parameter type: <Epon::OctetCounter> - Epon Frames counter	1519+ Octet Frames in downstream direction <i>This element is only shown in detail mode.</i>
unicastframes-up	Parameter type: <Epon::OctetCounter> - Epon Frames counter	Unicast Frames transferred in upstream direction <i>This element is only shown in detail mode.</i>
unicastframes-down	Parameter type: <Epon::OctetCounter> - Epon Frames counter	Unicast Frames transferred in downstream direction <i>This element is only shown in detail mode.</i>
multicastframes-up	Parameter type: <Epon::OctetCounter> - Epon Frames counter	Multicast Frames transferred in upstream direction <i>This element is only shown in detail mode.</i>
multicastframes-down	Parameter type: <Epon::OctetCounter> - Epon Frames counter	Multicast Frames transferred in downstream direction <i>This element is only shown in detail mode.</i>
drpframes-up	Parameter type: <Epon::OctetCounter> - Epon Frames counter	Discard Frames transferred in upstream direction <i>This element is only shown in detail mode.</i>

159 Ethernet Status Commands

name	Type	Description
drpframes-down	Parameter type: <Epon::OctetCounter> - Epon Frames counter	Discard Frames transferred in downstream direction <i>This element is only shown in detail mode.</i>
errframes-up	Parameter type: <Epon::OctetCounter> - Epon Frames counter	Error Frames transferred in upstream direction <i>This element is only shown in detail mode.</i>
errframes-down	Parameter type: <Epon::OctetCounter> - Epon Frames counter	Error Frames transferred in downstream direction <i>This element is only shown in detail mode.</i>
undframes-up	Parameter type: <Epon::OctetCounter> - Epon Frames counter	less than 64 bytes Frames transferred in upstream direction <i>This element is only shown in detail mode.</i>
undframes-down	Parameter type: <Epon::OctetCounter> - Epon Frames counter	less than 64 bytes Frames transferred in downstream direction <i>This element is only shown in detail mode.</i>
ovrframes-up	Parameter type: <Epon::OctetCounter> - Epon Frames counter	1526+ Frames transferred in upstream direction <i>This element is only shown in detail mode.</i>
ovrframes-down	Parameter type: <Epon::OctetCounter> - Epon Frames counter	1526+ Frames transferred in downstream direction <i>This element is only shown in detail mode.</i>
statuschange	Parameter type: <Epon::OctetCounter> - Epon Frames counter	port status change times <i>This element is only shown in detail mode.</i>
dropevents-up	Parameter type: <Epon::OctetCounter> - Epon Frames counter	drop event in upstream direction on a ONT ethernet port <i>This element is only shown in detail mode.</i>
dropevents-down	Parameter type: <Epon::OctetCounter> - Epon Frames counter	drop event in downstream direction on a ONT ethernet port <i>This element is only shown in detail mode.</i>
fragments-up	Parameter type: <Epon::OctetCounter> - Epon Frames counter	fragment frames in upstream direction on a ONT ethernet port <i>This element is only shown in detail mode.</i>
fragments-down	Parameter type: <Epon::OctetCounter> - Epon Frames counter	fragment frames in downstream direction on a ONT ethernet port <i>This element is only shown in detail mode.</i>
jabberframes-up	Parameter type: <Epon::OctetCounter> - Epon Frames counter	jabber frames in upstream direction on a ONT ethernet port <i>This element is only shown in detail mode.</i>
jabberframes-down	Parameter type: <Epon::OctetCounter> - Epon Frames counter	jabber frames in downstream direction on a ONT ethernet port <i>This element is only shown in detail mode.</i>

159.22 Epon Ont Ethernet Previous 15min Status Command

Command Description

User Level

The command can be accessed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

> show ethernet eont tc-layer previous-15min (uni-idx) interval-num [(interval-num)]

Command Parameters

Table 159.22-1 "Epon Ont Ethernet Previous 15min Status Command" Resource Parameters

Resource Identifier	Type	Description
(uni-idx)	Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Epon::EontSlotId> / <Epon::EontPortId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Eqpt::OntId> - the ONT identifier Field type <Epon::EontSlotId> - Epon Ont Slot Field type <Epon::EontPortId> - Epon Ont Port	ONT UNI interface
(interval-num)	Format: - Previous interval reference - range: [1...192]	Previous interval reference

Command Output

Table 159.22-2 "Epon Ont Ethernet Previous 15min Status Command" Display parameters

Specific Information

name	Type	Description
measure-time	Parameter type: <SignedInteger> - a signed integer	Measured time in interval <i>This element is always shown.</i>
octets-up	Parameter type: <Epon::OctetCounter> - Epon Frames counter	octets transferred in upstream direction <i>This element is always shown.</i>
frames-up	Parameter type: <Epon::OctetCounter> - Epon Frames counter	Total Frames transferred in upstream direction <i>This element is always shown.</i>
broadcastframes-up	Parameter type: <Epon::OctetCounter> - Epon Frames counter	Broadcast Frames transferred in upstream direction <i>This element is only shown in detail mode.</i>
crcerrframes-up	Parameter type: <Epon::OctetCounter> - Epon Frames counter	CRC error Frames transferred in upstream direction <i>This element is only shown in detail mode.</i>
pauseframes-up	Parameter type: <Epon::OctetCounter> - Epon Frames counter	pause Frames transferred in upstream direction <i>This element is only shown in detail mode.</i>
segment1octets-up	Parameter type: <Epon::OctetCounter> - Epon Frames counter	64 Octet Frames in upstream direction <i>This element is only shown in detail mode.</i>
segment2octets-up	Parameter type: <Epon::OctetCounter> - Epon Frames counter	65-127 Octet Frames in upstream direction <i>This element is only shown in detail mode.</i>
segment3octets-up	Parameter type: <Epon::OctetCounter> - Epon Frames counter	128-255 Octet Frames in upstream direction <i>This element is only shown in detail mode.</i>
segment4octets-up	Parameter type: <Epon::OctetCounter> - Epon Frames counter	256-511 Octet Frames in upstream direction <i>This element is only shown in detail mode.</i>
segment5octets-up	Parameter type: <Epon::OctetCounter> - Epon Frames counter	512-1023 Octet Frames in upstream direction <i>This element is only shown in detail mode.</i>
segment6octets-up	Parameter type: <Epon::OctetCounter> - Epon Frames counter	1024-1518 Octet Frames in upstream direction <i>This element is only shown in detail mode.</i>
segment7octets-up	Parameter type: <Epon::OctetCounter> - Epon Frames counter	1519+ Octet Frames in upstream direction <i>This element is only shown in detail mode.</i>
octets-down	Parameter type: <Epon::OctetCounter> - Epon Frames counter	octets transferred in downstream direction <i>This element is always shown.</i>
frames-down	Parameter type: <Epon::OctetCounter> - Epon Frames counter	Total Frames transferred in downstream direction <i>This element is always shown.</i>
broadcastframes-down	Parameter type: <Epon::OctetCounter> - Epon Frames counter	Broadcast Frames transferred in downstream direction <i>This element is only shown in</i>

name	Type	Description
		<i>detail mode.</i>
crcerrframes-down	Parameter type: <Epon::OctetCounter> - Epon Frames counter	CRC error Frames transferred in downstream direction <i>This element is only shown in detail mode.</i>
pauseframes-down	Parameter type: <Epon::OctetCounter> - Epon Frames counter	pause Frames transferred in downstream direction <i>This element is only shown in detail mode.</i>
segment1octets-down	Parameter type: <Epon::OctetCounter> - Epon Frames counter	64 Octet Frames in downstream direction <i>This element is only shown in detail mode.</i>
segment2octets-down	Parameter type: <Epon::OctetCounter> - Epon Frames counter	65-127 Octet Frames in downstream direction <i>This element is only shown in detail mode.</i>
segment3octets-down	Parameter type: <Epon::OctetCounter> - Epon Frames counter	128-255 Octet Frames in downstream direction <i>This element is only shown in detail mode.</i>
segment4octets-down	Parameter type: <Epon::OctetCounter> - Epon Frames counter	256-511 Octet Frames in downstream direction <i>This element is only shown in detail mode.</i>
segment5octets-down	Parameter type: <Epon::OctetCounter> - Epon Frames counter	512-1023 Octet Frames in downstream direction <i>This element is only shown in detail mode.</i>
segment6octets-down	Parameter type: <Epon::OctetCounter> - Epon Frames counter	1024-1518 Octet Frames in downstream direction <i>This element is only shown in detail mode.</i>
segment7octets-down	Parameter type: <Epon::OctetCounter> - Epon Frames counter	1519+ Octet Frames in downstream direction <i>This element is only shown in detail mode.</i>
unicastframes-up	Parameter type: <Epon::OctetCounter> - Epon Frames counter	Unicast Frames transferred in upstream direction <i>This element is only shown in detail mode.</i>
unicastframes-down	Parameter type: <Epon::OctetCounter> - Epon Frames counter	Unicast Frames transferred in downstream direction <i>This element is only shown in detail mode.</i>
multicastframes-up	Parameter type: <Epon::OctetCounter> - Epon Frames counter	Multicast Frames transferred in upstream direction <i>This element is only shown in detail mode.</i>
multicastframes-down	Parameter type: <Epon::OctetCounter> - Epon Frames counter	Multicast Frames transferred in downstream direction <i>This element is only shown in detail mode.</i>
drpframes-up	Parameter type: <Epon::OctetCounter> - Epon Frames counter	Discard Frames transferred in upstream direction <i>This element is only shown in detail mode.</i>

name	Type	Description
drpframes-down	Parameter type: <Epon::OctetCounter> - Epon Frames counter	Discard Frames transferred in downstream direction <i>This element is only shown in detail mode.</i>
errframes-up	Parameter type: <Epon::OctetCounter> - Epon Frames counter	Error Frames transferred in upstream direction <i>This element is only shown in detail mode.</i>
errframes-down	Parameter type: <Epon::OctetCounter> - Epon Frames counter	Error Frames transferred in downstream direction <i>This element is only shown in detail mode.</i>
undframes-up	Parameter type: <Epon::OctetCounter> - Epon Frames counter	less than 64 bytes Frames transferred in upstream direction <i>This element is only shown in detail mode.</i>
undframes-down	Parameter type: <Epon::OctetCounter> - Epon Frames counter	less than 64 bytes Frames transferred in downstream direction <i>This element is only shown in detail mode.</i>
ovrframes-up	Parameter type: <Epon::OctetCounter> - Epon Frames counter	1526+ Frames transferred in upstream direction <i>This element is only shown in detail mode.</i>
ovrframes-down	Parameter type: <Epon::OctetCounter> - Epon Frames counter	1526+ Frames transferred in downstream direction <i>This element is only shown in detail mode.</i>
statuschange	Parameter type: <Epon::OctetCounter> - Epon Frames counter	port status change times <i>This element is only shown in detail mode.</i>
dropevents-up	Parameter type: <Epon::OctetCounter> - Epon Frames counter	drop event in upstream direction on a ONT ethernet port <i>This element is only shown in detail mode.</i>
dropevents-down	Parameter type: <Epon::OctetCounter> - Epon Frames counter	drop event in downstream direction on a ONT ethernet port <i>This element is only shown in detail mode.</i>
fragments-up	Parameter type: <Epon::OctetCounter> - Epon Frames counter	fragment frames in upstream direction on a ONT ethernet port <i>This element is only shown in detail mode.</i>
fragments-down	Parameter type: <Epon::OctetCounter> - Epon Frames counter	fragment frames in downstream direction on a ONT ethernet port <i>This element is only shown in detail mode.</i>
jabberframes-up	Parameter type: <Epon::OctetCounter> - Epon Frames counter	jabber frames in upstream direction on a ONT ethernet port <i>This element is only shown in detail mode.</i>
jabberframes-down	Parameter type: <Epon::OctetCounter> - Epon Frames counter	jabber frames in downstream direction on a ONT ethernet port <i>This element is only shown in detail mode.</i>

159.23 Epon Ont Ethernet Previous 1day Status Command

Command Description

User Level

The command can be accessed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

> show ethernet eont tc-layer previous-1day (uni-idx) interval-num [(interval-num)]

Command Parameters

Table 159.23-1 "Epon Ont Ethernet Previous 1day Status Command" Resource Parameters

Resource Identifier	Type	Description
(uni-idx)	Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Epon::EontSlotId> / <Epon::EontPortId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Eqpt::OntId> - the ONT identifier Field type <Epon::EontSlotId> - Epon Ont Slot Field type <Epon::EontPortId> - Epon Ont Port	ONT UNI interface
(interval-num)	Format: - Previous interval reference - range: [1...2]	Previous interval reference

Command Output

Table 159.23-2 "Epon Ont Ethernet Previous 1day Status Command" Display parameters

Specific Information

159 Ethernet Status Commands

name	Type	Description
measure-time	Parameter type: <SignedInteger> - a signed integer	Measured time in interval <i>This element is always shown.</i>
octets-up	Parameter type: <Epon::OctetCounter> - Epon Frames counter	octets transferred in upstream direction <i>This element is always shown.</i>
frames-up	Parameter type: <Epon::OctetCounter> - Epon Frames counter	Total Frames transferred in upstream direction <i>This element is always shown.</i>
broadcastframes-up	Parameter type: <Epon::OctetCounter> - Epon Frames counter	Broadcast Frames transferred in upstream direction <i>This element is only shown in detail mode.</i>
crcerrframes-up	Parameter type: <Epon::OctetCounter> - Epon Frames counter	CRC error Frames transferred in upstream direction <i>This element is only shown in detail mode.</i>
pauseframes-up	Parameter type: <Epon::OctetCounter> - Epon Frames counter	pause Frames transferred in upstream direction <i>This element is only shown in detail mode.</i>
segment1octets-up	Parameter type: <Epon::OctetCounter> - Epon Frames counter	64 Octet Frames in upstream direction <i>This element is only shown in detail mode.</i>
segment2octets-up	Parameter type: <Epon::OctetCounter> - Epon Frames counter	65-127 Octet Frames in upstream direction <i>This element is only shown in detail mode.</i>
segment3octets-up	Parameter type: <Epon::OctetCounter> - Epon Frames counter	128-255 Octet Frames in upstream direction <i>This element is only shown in detail mode.</i>
segment4octets-up	Parameter type: <Epon::OctetCounter> - Epon Frames counter	256-511 Octet Frames in upstream direction <i>This element is only shown in detail mode.</i>
segment5octets-up	Parameter type: <Epon::OctetCounter> - Epon Frames counter	512-1023 Octet Frames in upstream direction <i>This element is only shown in detail mode.</i>
segment6octets-up	Parameter type: <Epon::OctetCounter> - Epon Frames counter	1024-1518 Octet Frames in upstream direction <i>This element is only shown in detail mode.</i>
segment7octets-up	Parameter type: <Epon::OctetCounter> - Epon Frames counter	1519+ Octet Frames in upstream direction <i>This element is only shown in detail mode.</i>
octets-down	Parameter type: <Epon::OctetCounter> - Epon Frames counter	octets transferred in downstream direction <i>This element is always shown.</i>
frames-down	Parameter type: <Epon::OctetCounter> - Epon Frames counter	Total Frames transferred in downstream direction <i>This element is always shown.</i>
broadcastframes-down	Parameter type: <Epon::OctetCounter> - Epon Frames counter	Broadcast Frames transferred in downstream direction <i>This element is only shown in</i>

name	Type	Description
		<i>detail mode.</i>
crcerrframes-down	Parameter type: <Epon::OctetCounter> - Epon Frames counter	CRC error Frames transferred in downstream direction <i>This element is only shown in detail mode.</i>
pauseframes-down	Parameter type: <Epon::OctetCounter> - Epon Frames counter	pause Frames transferred in downstream direction <i>This element is only shown in detail mode.</i>
segment1octets-down	Parameter type: <Epon::OctetCounter> - Epon Frames counter	64 Octet Frames in downstream direction <i>This element is only shown in detail mode.</i>
segment2octets-down	Parameter type: <Epon::OctetCounter> - Epon Frames counter	65-127 Octet Frames in downstream direction <i>This element is only shown in detail mode.</i>
segment3octets-down	Parameter type: <Epon::OctetCounter> - Epon Frames counter	128-255 Octet Frames in downstream direction <i>This element is only shown in detail mode.</i>
segment4octets-down	Parameter type: <Epon::OctetCounter> - Epon Frames counter	256-511 Octet Frames in downstream direction <i>This element is only shown in detail mode.</i>
segment5octets-down	Parameter type: <Epon::OctetCounter> - Epon Frames counter	512-1023 Octet Frames in downstream direction <i>This element is only shown in detail mode.</i>
segment6octets-down	Parameter type: <Epon::OctetCounter> - Epon Frames counter	1024-1518 Octet Frames in downstream direction <i>This element is only shown in detail mode.</i>
segment7octets-down	Parameter type: <Epon::OctetCounter> - Epon Frames counter	1519+ Octet Frames in downstream direction <i>This element is only shown in detail mode.</i>
unicastframes-up	Parameter type: <Epon::OctetCounter> - Epon Frames counter	Unicast Frames transferred in upstream direction <i>This element is only shown in detail mode.</i>
unicastframes-down	Parameter type: <Epon::OctetCounter> - Epon Frames counter	Unicast Frames transferred in downstream direction <i>This element is only shown in detail mode.</i>
multicastframes-up	Parameter type: <Epon::OctetCounter> - Epon Frames counter	Multicast Frames transferred in upstream direction <i>This element is only shown in detail mode.</i>
multicastframes-down	Parameter type: <Epon::OctetCounter> - Epon Frames counter	Multicast Frames transferred in downstream direction <i>This element is only shown in detail mode.</i>
drpframes-up	Parameter type: <Epon::OctetCounter> - Epon Frames counter	Discard Frames transferred in upstream direction <i>This element is only shown in detail mode.</i>

159 Ethernet Status Commands

name	Type	Description
drpframes-down	Parameter type: <Epon::OctetCounter> - Epon Frames counter	Discard Frames transferred in downstream direction <i>This element is only shown in detail mode.</i>
errframes-up	Parameter type: <Epon::OctetCounter> - Epon Frames counter	Error Frames transferred in upstream direction <i>This element is only shown in detail mode.</i>
errframes-down	Parameter type: <Epon::OctetCounter> - Epon Frames counter	Error Frames transferred in downstream direction <i>This element is only shown in detail mode.</i>
undframes-up	Parameter type: <Epon::OctetCounter> - Epon Frames counter	less than 64 bytes Frames transferred in upstream direction <i>This element is only shown in detail mode.</i>
undframes-down	Parameter type: <Epon::OctetCounter> - Epon Frames counter	less than 64 bytes Frames transferred in downstream direction <i>This element is only shown in detail mode.</i>
ovrframes-up	Parameter type: <Epon::OctetCounter> - Epon Frames counter	1526+ Frames transferred in upstream direction <i>This element is only shown in detail mode.</i>
ovrframes-down	Parameter type: <Epon::OctetCounter> - Epon Frames counter	1526+ Frames transferred in downstream direction <i>This element is only shown in detail mode.</i>
statuschange	Parameter type: <Epon::OctetCounter> - Epon Frames counter	port status change times <i>This element is only shown in detail mode.</i>
dropevents-up	Parameter type: <Epon::OctetCounter> - Epon Frames counter	drop event in upstream direction on a ONT ethernet port <i>This element is only shown in detail mode.</i>
dropevents-down	Parameter type: <Epon::OctetCounter> - Epon Frames counter	drop event in downstream direction on a ONT ethernet port <i>This element is only shown in detail mode.</i>
fragments-up	Parameter type: <Epon::OctetCounter> - Epon Frames counter	fragment frames in upstream direction on a ONT ethernet port <i>This element is only shown in detail mode.</i>
fragments-down	Parameter type: <Epon::OctetCounter> - Epon Frames counter	fragment frames in downstream direction on a ONT ethernet port <i>This element is only shown in detail mode.</i>
jabberframes-up	Parameter type: <Epon::OctetCounter> - Epon Frames counter	jabber frames in upstream direction on a ONT ethernet port <i>This element is only shown in detail mode.</i>
jabberframes-down	Parameter type: <Epon::OctetCounter> - Epon Frames counter	jabber frames in downstream direction on a ONT ethernet port <i>This element is only shown in detail mode.</i>

160- Ethernet Lt Operational Data Status

Commands

160.1 Ethernet Lt Operational Data Status Command Tree	160-6677
160.2 Ethernet Port Operational Status Command	160-6678
160.3 Ethernet BridgePort Operational Status Command	160-6680
160.4 Ethernet Port Interface Operational Status Command	160-6682
160.5 Ethernet IGMP Operational Status Command	160-6684
160.6 Ethernet Port Ip Bridge Operational Status Command	160-6687
160.7 Ethernet QoS Opertaional Status Command	160-6689

160.1 Ethernet Lt Operational Data Status

Command Tree

Description

This chapter gives an overview of nodes that are handled by "Ethernet Lt Operational Data Status Commands".

Command Tree

```
----show
  ----oper-data-port
    - (if-index)
      ----ethernet
      ----bridge-port
        - (port)
      ----interface-port
      ----igmp
        - (port)
      ----ip-bridge-port
        - (ip-bridge-port)
      ----qos
```

160.2 Ethernet Port Operational Status Command

Command Description

This command displays the Ethernet Port Operational data.

User Level

The command can be accessed by operators with transport privileges.

Command Syntax

The command has the following syntax:

> show oper-data-port (if-index) ethernet

Command Parameters

Table 160.2-1 "Ethernet Port Operational Status Command" Resource Parameters

Resource Identifier	Type	Description
(if-index)	Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number	interface index of the port

Command Output

Table 160.2-2 "Ethernet Port Operational Status Command" Display parameters

Specific Information		
name	Type	Description
admin-state	Parameter type: <If::ifAdminStatus> (not-appl up down testing) Possible values: - not-appl : not-applicable - up : admin status is up - down : admin status is down - testing : no operational packets can be passed	specifies state of the interface <i>This element is only shown in detail mode.</i>

name	Type	Description
opr-state	Parameter type: <ETHITF::combinedCol> (up down testing unknown dormant) Possible values: - up : up,traffic can pass - down : down,no traffic is passing - testing : testing,no traffic is passing - unknown : unknown - dormant : dormant,no traffic is passing	current operational state of the interface. <i>This element is only shown in detail mode.</i>

160.3 Ethernet BridgePort Operational Status Command

Command Description

This command displays the Bridge Port Operational data.

User Level

The command can be accessed by operators with atm privileges.

Command Syntax

The command has the following syntax:

```
> show oper-data-port (if-index) bridge-port [ (port) ]
```

Command Parameters

Table 160.3-1 "Ethernet BridgePort Operational Status Command" Resource Parameters

Resource Identifier	Type	Description
(if-index)	Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number	interface index of the port
(port)	Format: (dsl : <Eqpt::VpiId> : <Eqpt::VciId> dsl) Possible values: - dsl : vdsl board Field type <Eqpt::VpiId> - atm VPI Field type <Eqpt::VciId> - atm VCI	identity of the PVC

Command Output

Table 160.3-2 "Ethernet BridgePort Operational Status Command" Display parameters

Specific Information		
name	Type	Description
pvid	Parameter type: <Vlan::StackedVlan> (<Vlan::UVlanIndex> stacked : <Vlan::SVlanIndex> : <Vlan::CVlanIndex>) Possible values: - stacked : stacked vlan identity Field type <Vlan::UVlanIndex> - unstacked vlan identity - range: [1...4093,4096] Field type <Vlan::SVlanIndex> - service vlan identity - range: [2...4093,4094] Field type <Vlan::CVlanIndex> - customer vlan identity - range: [0...4093,4094,4095,4096]	default vlan id for untagged frames <i>This element is only shown in detail mode.</i>
default-priority	Parameter type: <Vlan::Priority> - priority of ethernet frames - range: [0...7]	port dynamic or static (if no dynamic) default priority <i>This element is only shown in detail mode.</i>
qos-profile	Parameter type: <Vlan::QosProfileName> (none name : <Vlan::IgnoredQosProfileName>) Possible values: - none : no profile name to associate - name : enter profile name to be associated Field type <Vlan::IgnoredQosProfileName> - name of the QoS profile - length: 1<=x<=64	qos profile name <i>This element is always shown.</i>

160.4 Ethernet Port Interface Operational Status Command

Command Description

This command displays the Ethernet port interface operational data.

User Level

The command can be accessed by operators with transport privileges.

Command Syntax

The command has the following syntax:

> show oper-data-port (if-index) interface-port

Command Parameters

Table 160.4-1 "Ethernet Port Interface Operational Status Command" Resource Parameters

Resource Identifier	Type	Description
(if-index)	Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number	interface index of the port

Command Output

Table 160.4-2 "Ethernet Port Interface Operational Status Command" Display parameters

Specific Information		
name	Type	Description
admin-state	Parameter type: <Eth::EthAdminStatus> (not-applicable up down testing) Possible values: - not-applicable : not-applicable	the desired state of the interface <i>This element is always shown.</i>

name	Type	Description
	- up : admin status is up - down : admin status is down - testing : no operational packets can be passed	
oper-state	Parameter type: <If::ifOperStatus> (up down testing unknown dormant no-value) Possible values: - up : up,traffic can pass - down : down,no traffic is passing - testing : testing,no traffic is passing - unknown : unknown - dormant : dormant,no traffic is passing - no-value : no entry in the table	the operational state of the interface <i>This element is only shown in detail mode.</i>

160.5 Ethernet IGMP Operational Status Command

Command Description

This command displays the Ethernet IGMP operational data.

User Level

The command can be accessed by operators with igmp privileges.

Command Syntax

The command has the following syntax:

```
> show oper-data-port (if-index) igmp [ (port) ]
```

Command Parameters

Table 160.5-1 "Ethernet IGMP Operational Status Command" Resource Parameters

Resource Identifier	Type	Description
(if-index)	Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number	interface index of the port
(port)	Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::VpiId> : <Eqpt::VciId> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::Vpild> : <Eqpt::VciId> : <Eqpt::UnstackedVlan> vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::UnstackedVlan> vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::Vpild> : <Eqpt::VciId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> / <Eqpt::OntPortId> : stacked : <Eqpt::SVlan> :	identification of the port or virtual channel

Resource Identifier	Type	Description
	<Eqpt::CVlan> vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> / <Eqpt::OntPortId> : <Eqpt::UnstackedVlan> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> / <Eqpt::OntPortId> vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / voip : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / vuni : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / voip : <Eqpt::UnstackedVlan> vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / vuni : <Eqpt::UnstackedVlan> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / voip <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / vuni vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::LLId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::LLId> : <Eqpt::UnstackedVlan> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::LLId> vlan.ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / <Eqpt::Ng2OntSlotId> / <Eqpt::Ng2OntPortId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan.ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / <Eqpt::Ng2OntSlotId> / <Eqpt::Ng2OntPortId> : <Eqpt::UnstackedVlan>) Possible values: - vlan : vlan port - vlan.ng2 : ngpon2 vlan port Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number Field type <Eqpt::VpiId> - atm VPI Field type <Eqpt::VciId> - atm VCI Field type <Eqpt::PonId> - the PON identifier Field type <Eqpt::ChannelGroupId>	

Resource Identifier	Type	Description
	- the channel group identifier Field type <Eqpt::SubChannelGroupId> - the subchannel group identifier Field type <Eqpt::Ng2OntId> - the NG2 ONT identifier Field type <Eqpt::OntId> - the ONT identifier Possible values: - voip : virtual uni identifier obsolete alternative replaced by vuni - vuni : virtual uni identifier Possible values: - vuni : virtual NGPON2 uni identifier - the ONT SLOT identifier Field type <Eqpt::OntSlotId> - the ONT PORT identifier Field type <Eqpt::Ng2OntSlotId> - the NGPON2 ONT SLOT identifier Field type <Eqpt::Ng2OntPortId> - the NGPON2 ONT PORT identifier Field type <Eqpt::LLId> - the LLID identifier, range 1 for EPON, range 1-8 for DPOE Possible values: - stacked : stacked vlan identity Field type <Eqpt::UnstackedVlan> - unstacked vlan id Field type <Eqpt::SVlan> - service vlan id Field type <Eqpt::CVlan> - customer vlan id	

Command Output

Table 160.5-2 "Ethernet IGMP Operational Status Command" Display parameters

Specific Information		
name	Type	Description
curr-num-group	Parameter type: <Gauge> - gauge	Indicates the current group number in this port <i>This element is only shown in detail mode.</i>
curr-preview-num	Parameter type: <Counter> - 32 bit counter	Indicates the number of preview multicast group that igmp channel joins currently <i>This element is only shown in detail mode.</i>
curr-uncfg-num	Parameter type: <Counter> - 32 bit counter	Indicates the current unconfig group number in this port <i>This element is only shown in detail mode.</i>

160.6 Ethernet Port Ip Bridge Operational Status Command

Command Description

This command displays the Ethernet Port Ip Bridge Operational data.

User Level

The command can be accessed by operators with ip privileges.

Command Syntax

The command has the following syntax:

```
> show oper-data-port (if-index) ip-bridge-port [ (ip-bridge-port) ]
```

Command Parameters

Table 160.6-1 "Ethernet Port Ip Bridge Operational Status Command" Resource Parameters

Resource Identifier	Type	Description
(if-index)	Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number	interface index of the port
(ip-bridge-port)	Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::VpiId> : <Eqpt::VciId> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> / <Eqpt::OntPortId> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / voip <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::LLId>) Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId>	identification of the port or virtual channel

Resource Identifier	Type	Description
	- the shelf number - Field type <Eqpt::SlotId> - the LT slot number - Field type <Eqpt::PortId> - the port number - Field type <Eqpt::VpiId> - atm VPI - Field type <Eqpt::VciId> - atm VCI - Field type <Eqpt::PonId> - the PON identifier - Field type <Eqpt::OntId> - the ONT identifier - Possible values: - voip : virtual uni identifier - Field type <Eqpt::OntSlotId> - the ONT SLOT identifier - Field type <Eqpt::OntPortId> - the ONT PORT identifier - Field type <Eqpt::LLId> - the LLID identifier, range 1 for EPON, range 1-8 for DPOE	

Command Output

Table 160.6-2 "Ethernet Port Ip Bridge Operational Status Command" Display parameters

Specific Information		
name	Type	Description
rx-pkts	Parameter type: <Equipm::Octet-8> - a binary string - length: 8	show the number of received packets <i>This element is always shown.</i>
rx-drop-pkts	Parameter type: <Equipm::Octet-8> - a binary string - length: 8	show the number of received packets which are dropped <i>This element is always shown.</i>
tx-pkts	Parameter type: <Equipm::Octet-8> - a binary string - length: 8	show the number of transmitted packets <i>This element is always shown.</i>

160.7 Ethernet QoS Opertaional Status Command

Command Description

This command displays the Ethernet QoS operational data.

User Level

The command can be accessed by operators with qos privileges.

Command Syntax

The command has the following syntax:

```
> show oper-data-port (if-index) qos
```

Command Parameters

Table 160.7-1 "Ethernet QoS Opertaional Status Command" Resource Parameters

Resource Identifier	Type	Description
(if-index)	Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number	interface index of the port

Command Output

Table 160.7-2 "Ethernet QoS Opertaional Status Command" Display parameters

Specific Information		
name	Type	Description
frame-net-bw	Parameter type: <SignedInteger> - a signed integer	Represents the approximate bandwidth available for Ethernet frames, which is guaranteed to be available by the physical layer. This approximation is made by the configurable ATM overhead factor. <i>This element is only shown in detail mode.</i>
m-cast-avail-bw	Parameter type: <SignedInteger>	Represents the bandwidth

160 Ethernet Lt Operational Data Status Commands

name	Type	Description
	- a signed integer	available for multicast services, calculated by the ISAM. This value is what is left from frame-net-bw after deducting from it res-data-bw and res-voice-bw. The minimum of m-cast-avail-bw and m-cast-max-bw will be the actual limitation for user multicast bandwidth usage per DSL link. <i>This element is only shown in detail mode.</i>
m-cast-used-bw	Parameter type: <SignedInteger> - a signed integer	Shows the bandwidth currently in use by pre-configured multicast streams. <i>This element is only shown in detail mode.</i>

161- Debug Status Commands

161.1 Debug Status Command Tree	161-6692
161.2 SW Error Log Status Command	161-6693

161.1 Debug Status Command Tree

Description

This chapter gives an overview of nodes that are handled by "Debug Status Commands".

Command Tree

```
----show
  ----debug-sw
    ----sw-error-log
      - (sw-error-log-index)
```

161.2 SW Error Log Status Command

Command Description

This command can be used to retrieve SW error log data.

To analyse critical SW problems, an emergency build can be delivered to a customer, which makes use of the generic error logging. This means that, when the system detects critical SW problems, it can provide info related to these problems in the SW error log.

User Level

The command can be accessed by operators with security privileges.

Command Syntax

The command has the following syntax:

```
> show debug-sw sw-error-log [ (sw-error-log-index) ]
```

Command Parameters

Table 161.2-1 "SW Error Log Status Command" Resource Parameters

Resource Identifier	Type	Description
(sw-error-log-index)	Format: - index for the sw error log - range: [1...64]	the error string identification

Command Output

Table 161.2-2 "SW Error Log Status Command" Display parameters

Specific Information		
name	Type	Description
errordata	Parameter type: <Debug::errorTracingLogString> - ascii character string - length: x<=80	textual description of the error <i>This element is always shown.</i>

162- Trouble-Shooting Status Commands

162.1 Trouble-Shooting Status Command Tree	162-6695
162.2 Trouble-shooting Statistics To One Port	162-6696
162.3 Trouble-shooting Statistics on a Port (DSL or Ethernet) or PVC Interface	162-6698
162.4 Trouble-shooting Statistics To One VlanPort	162-6700
162.5 Summary Trouble-shooting Statistics To Vlan Ports	162-6702
162.6 Extensive Trouble-shooting Statistics To Vlan Ports	162-6705
162.7 Trouble-shooting Statistics Over Channel-pair	162-6709
162.8 Extensive Trouble-shooting ipv4-antispoofing Statistics To One UNI Port	162-6712
162.9 Trouble-shooting Statistics To One VlanPort	162-6714
162.10 Summary Trouble-shooting Statistics To Vlan Ports	162-6716
162.11 Extensive Trouble-shooting Statistics To Vlan Ports	162-6719
162.12 Trouble-shooting PBIT Statistics	162-6723
162.13 Trouble-shooting PBIT Statistics	162-6724

162.1 Trouble-Shooting Status Command Tree

Description

This chapter gives an overview of nodes that are handled by "Trouble-Shooting Status Commands".

Command Tree

```

----show
  ----trouble-shooting
    ----statistics
      ----interface
        - (if-index)
      ----user
        - (port)
      ----vlan
        - (vlan-id)
        ----summary
        ----extensive
      ----channel-pair
        - (chanpair-idx)
      ----uni-interface
        - (if-index)
      ----vlanport
        ----bridgeport-id
          - (port-interface)
        ----vlan-id
          - (subscr-vlan)
        ----summary
        ----extensive
    ----pbitstatistics
      ----vlanport
        - (if-index)
        - pbit

```

162.2 Trouble-shooting Statistics To One Port

Command Description

This command allows the operator to show the trouble-shooting counters. When this show command is invoked, all commands in underlying nodes are automatically executed. For specific help information, use the corresponding help command of the underlying node. The help information related to underlying nodes will not be available in this node.

User Level

The command can be accessed by operators with security privileges.

Command Syntax

The command has the following syntax:

```
> show trouble-shooting statistics interface [ (if-index) ]
```

Command Parameters

Table 162.2-1 "Trouble-shooting Statistics To One Port" Resource Parameters

Resource Identifier	Type	Description
(if-index)	Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> / <Eqpt::OntPortId> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / voip <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / vuni) Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number Field type <Eqpt::PonId> - the PON identifier Field type <Eqpt::OntId> - the ONT identifier Possible values: - voip : virtual uni identifier obsolete alternative replaced by vuni - vuni : virtual uni identifier	interface index of the port

Resource Identifier	Type	Description
	Field type <Eqpt::OntSlotId> - the ONT SLOT identifier Field type <Eqpt::OntPortId> - the ONT PORT identifier	

162.3 Trouble-shooting Statistics on a Port (DSL or Ethernet) or PVC Interface

Command Description

This command allows the operator to show the trouble-shooting counters. When this show command is invoked, all commands in underlying nodes are automatically executed. For specific help information, use the corresponding help command of the underlying node. The help information related to underlying nodes will not be available in this node.

User Level

The command can be accessed by operators with security privileges.

Command Syntax

The command has the following syntax:

```
> show trouble-shooting statistics interface (if-index) user [ (port) ]
```

Command Parameters

Table 162.3-1 "Trouble-shooting Statistics on a Port (DSL or Ethernet) or PVC Interface" Resource Parameters

Resource Identifier	Type	Description
(if-index)	Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> / <Eqpt::OntPortId> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / voip <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / vuni) Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number Field type <Eqpt::PonId> - the PON identifier Field type <Eqpt::OntId> - the ONT identifier	interface index of the port

Resource Identifier	Type	Description
	Possible values: - voip : virtual uni identifier obsolete alternative replaced by vuni - vuni : virtual uni identifier Field type <Eqpt::OntSlotId> - the ONT SLOT identifier Field type <Eqpt::OntPortId> - the ONT PORT identifier	
(port)	Format: (port : <Eqpt::VpiId> : <Eqpt::VciId> port) Possible values: - port : dsl or ethernet port Field type <Eqpt::VpiId> - atm VPI Field type <Eqpt::VciId> - atm VCI	specifies the port or the atm pvc

162.4 Trouble-shooting Statistics To One VlanPort

Command Description

This command allows the operator to show extensive and summary counters of VLAN port. When this show command is invoked, all commands in underlying nodes are automatically executed. For specific help information, use the corresponding help command of the underlying node. The help information related to underlying nodes will not be available in this node.

Both the summary and detailed counters are shown through the underlying nodes.

User Level

The command can be accessed by operators with security privileges.

Command Syntax

The command has the following syntax:

```
> show trouble-shooting statistics interface (if-index) user (port) vlan [ (vlan-id) ]
```

Command Parameters

Table 162.4-1 "Trouble-shooting Statistics To One VlanPort" Resource Parameters

Resource Identifier	Type	Description
(if-index)	Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> / <Eqpt::OntPortId> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / voip <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / vuni) Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number Field type <Eqpt::PonId> - the PON identifier Field type <Eqpt::OntId> - the ONT identifier Possible values: - voip : virtual uni identifier obsolete alternative replaced by vuni	interface index of the port

Resource Identifier	Type	Description
	- vuni : virtual uni identifier Field type <Eqpt::OntSlotId> - the ONT SLOT identifier Field type <Eqpt::OntPortId> - the ONT PORT identifier	
(port)	Format: (port : <Eqpt::VpiId> : <Eqpt::VciId> port) Possible values: - port : dsl or ethernet port Field type <Eqpt::VpiId> - atm VPI Field type <Eqpt::VciId> - atm VCI	specifies the port or the atm pvc
(vlan-id)	Format: (<Vlan::UVlanIndex> stacked : <Vlan::SVlanIndex> : <Vlan::CVlanIndex>) Possible values: - stacked : stacked vlan identity Field type <Vlan::UVlanIndex> - unstacked vlan identity - range: [1...4093,4096] Field type <Vlan::SVlanIndex> - service vlan identity - range: [2...4093] Field type <Vlan::CVlanIndex> - customer vlan identity - range: [0...4093]	vlan associated to the bridge port

162.5 Summary Trouble-shooting Statistics To Vlan Ports

Command Description

This command shows summary counters of VLAN port.

User Level

The command can be accessed by operators with security privileges.

Command Syntax

The command has the following syntax:

```
> show trouble-shooting statistics interface (if-index) user (port) vlan (vlan-id) summary
```

Command Parameters

Table 162.5-1 "Summary Trouble-shooting Statistics To Vlan Ports" Resource Parameters

Resource Identifier	Type	Description
(if-index)	Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> / <Eqpt::OntPortId> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / voip <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / vuni) Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number Field type <Eqpt::PonId> - the PON identifier Field type <Eqpt::OntId> - the ONT identifier Possible values: - voip : virtual uni identifier obsolete alternative replaced by vuni - vuni : virtual uni identifier	interface index of the port

Resource Identifier	Type	Description
	Field type <Eqpt::OntSlotId> - the ONT SLOT identifier Field type <Eqpt::OntPortId> - the ONT PORT identifier	
(port)	Format: (port : <Eqpt::VpId> : <Eqpt::VcId> port) Possible values: - port : dsl or ethernet port Field type <Eqpt::VpId> - atm VPI Field type <Eqpt::VcId> - atm VCI	specifies the port or the atm pvc
(vlan-id)	Format: (<Vlan::UVlanIndex> stacked : <Vlan::SVlanIndex> : <Vlan::CVlanIndex>) Possible values: - stacked : stacked vlan identity Field type <Vlan::UVlanIndex> - unstacked vlan identity - range: [1...4093,4096] Field type <Vlan::SVlanIndex> - service vlan identity - range: [2...4093] Field type <Vlan::CVlanIndex> - customer vlan identity - range: [0...4093]	vlan associated to the bridge port

Command Output

Table 162.5-2 "Summary Trouble-shooting Statistics To Vlan Ports" Display parameters

Specific Information		
name	Type	Description
up-forward	Parameter type: <Counter> - 32 bit counter	the number of frames received from the user side that are successfully forwarded by the l2-forwarding engine <i>This element is only shown in detail mode.</i>
up-discard	Parameter type: <Counter> - 32 bit counter	the number of frames received from the user side that are discarded by l2-forwarding engine or l2 user interface <i>This element is only shown in detail mode.</i>
dn-forward	Parameter type: <Counter> - 32 bit counter	the number of frames received from the network side that are successfully forwarded by the l2-forwarding engine <i>This element is only shown in detail mode.</i>
dn-discard	Parameter type: <Counter> - 32 bit counter	the number of frames received from the network side that are discarded on the condition that the user interface has been found <i>This element is only shown in</i>

162 Trouble-Shooting Status Commands

name	Type	Description
		<i>detail mode.</i>
up-bcast-fwd	Parameter type: <Debug::SignedTrafficCounter> (not-supported <SignedInteger>) Possible values: - not-supported : not support the counter Field type <SignedInteger> - a signed integer	the number of broadcast frames received from the user side that are successfully forwarded by the l2-forwarding engine <i>This element is only shown in detail mode.</i>
up-ucast-fwd	Parameter type: <Debug::SignedTrafficCounter> (not-supported <SignedInteger>) Possible values: - not-supported : not support the counter Field type <SignedInteger> - a signed integer	the number of unicast frames received from the user side that are successfully forwarded by the l2-forwarding engine <i>This element is only shown in detail mode.</i>
dn-bcast-fwd	Parameter type: <Debug::SignedTrafficCounter> (not-supported <SignedInteger>) Possible values: - not-supported : not support the counter Field type <SignedInteger> - a signed integer	the number of broadcast frames received from the network side that are successfully forwarded by the l2-forwarding engine <i>This element is only shown in detail mode.</i>
dn-ucast-fwd	Parameter type: <Debug::SignedTrafficCounter> (not-supported <SignedInteger>) Possible values: - not-supported : not support the counter Field type <SignedInteger> - a signed integer	the number of unicast frames received from the network side that are successfully forwarded by the l2-forwarding engine <i>This element is only shown in detail mode.</i>

162.6 Extensive Trouble-shooting Statistics To Vlan Ports

Command Description

This command shows extensive counters of VLAN port.

The extensive counters are only given when the counters are enabled via the related configuration command.

User Level

The command can be accessed by operators with security privileges.

Command Syntax

The command has the following syntax:

```
> show trouble-shooting statistics interface (if-index) user (port) vlan (vlan-id) extensive
```

Command Parameters

Table 162.6-1 "Extensive Trouble-shooting Statistics To Vlan Ports" Resource Parameters

Resource Identifier	Type	Description
(if-index)	Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> / <Eqpt::OntPortId> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / voip <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / vuni) Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number Field type <Eqpt::PonId> - the PON identifier Field type <Eqpt::OntId> - the ONT identifier Possible values: - voip : virtual uni identifier	interface index of the port

Resource Identifier	Type	Description
	obsolete alternative replaced by vuni - vuni : virtual uni identifier Field type <Eqpt::OntSlotId> - the ONT SLOT identifier Field type <Eqpt::OntPortId> - the ONT PORT identifier	
(port)	Format: (port : <Eqpt::VpId> : <Eqpt::VciId> port) Possible values: - port : dsl or ethernet port Field type <Eqpt::VpId> - atm VPI Field type <Eqpt::VciId> - atm VCI	specifies the port or the atm pvc
(vlan-id)	Format: (<Vlan::UVlanIndex> stacked : <Vlan::SVlanIndex> : <Vlan::CVlanIndex>) Possible values: - stacked : stacked vlan identity Field type <Vlan::UVlanIndex> - unstacked vlan identity - range: [1...4093,4096] Field type <Vlan::SVlanIndex> - service vlan identity - range: [2...4093] Field type <Vlan::CVlanIndex> - customer vlan identity - range: [0...4093]	vlan associated to the bridge port

Command Output

Table 162.6-2 "Extensive Trouble-shooting Statistics To Vlan Ports" Display parameters

Specific Information		
name	Type	Description
up-inv-dasa	Parameter type: <Counter> - 32 bit counter	the number of frames received from the user side which have an invalid destination or source mac address <i>This element is only shown in detail mode.</i>
up-macport-lmt-exc	Parameter type: <Counter> - 32 bit counter	the number of frames received from the user side which mac@ could not be learned <i>This element is only shown in detail mode.</i>
up-macfdb-lmt-exc	Parameter type: <Counter> - 32 bit counter	the number of frames received from the user side which maxmac is reached <i>This element is only shown in detail mode.</i>
up-inv-prot	Parameter type: <Counter> - 32 bit counter	number of frames received from the user side with an invalid protocol <i>This element is only shown in detail mode.</i>

name	Type	Description
up-ip-spoofing	Parameter type: <Counter> - 32 bit counter	number of frames received from the user side with an ip address not matching the assigned ip address <i>This element is only shown in detail mode.</i>
up-acl-discard	Parameter type: <Counter> - 32 bit counter	the number of frames received from the user side that are discarded for acl <i>This element is only shown in detail mode.</i>
up-policer-discard	Parameter type: <Counter> - 32 bit counter	the number of frames received from the user side that are discarded due to policing <i>This element is only shown in detail mode.</i>
up-queue-discard	Parameter type: <Counter> - 32 bit counter	the number of frames received from the user side that are discarded in the uplink queue <i>This element is only shown in detail mode.</i>
up-ipv6-spoofing	Parameter type: <Counter> - 32 bit counter	number of frames received from the user side with an IPv6 address not matching the assigned IP address <i>This element is only shown in detail mode.</i>
up-tpid-discard	Parameter type: <SignedInteger> - a signed integer	number of frames received from the user side with an tpid not matching the assigned tpid <i>This element is only shown in detail mode.</i>
dn-mcast-fwd	Parameter type: <Counter> - 32 bit counter	number of multicast frames received from the network side and successfully forwarded by the l2-forwarding engine <i>This element is only shown in detail mode.</i>
dn-nonmcast-fwd	Parameter type: <Counter> - 32 bit counter	number of non-multicast (including broadcast) frames received from the network side and successfully forwarded by the l2-forwarding engine <i>This element is only shown in detail mode.</i>
dn-mcast-discard	Parameter type: <Counter> - 32 bit counter	number of multicast frames received from the network side, routed to the vlan Port and then discarded for any reason, even if this reason is not related to the vlan port functionality <i>This element is only shown in detail mode.</i>
dn-nonmcast-discard	Parameter type: <Counter> - 32 bit counter	number of non-multicast frames received from the network side, routed to the vlan port and then discarded for any reason, even if

162 Trouble-Shooting Status Commands

name	Type	Description
		this reason is not related to the Vlan Port functionality <i>This element is only shown in detail mode.</i>
dn-acl-discard	Parameter type: <Counter> - 32 bit counter	the number of frames received from the network side that are discarded for acl/ccl filtering <i>This element is only shown in detail mode.</i>
dn-policer-discard	Parameter type: <Counter> - 32 bit counter	the number of frames received from the network side that is discarded due to policing on l2 forwarder interface <i>This element is only shown in detail mode.</i>
dn-queue-discard	Parameter type: <Counter> - 32 bit counter	number of frames received from the network side, routed to the vlan port and then discarded because of queue overflow <i>This element is only shown in detail mode.</i>

162.7 Trouble-shooting Statistics Over Channel-pair

Command Description

This command allows the operator to show the trouble-shooting counters. When this show command is invoked, all commands in underlying nodes are automatically executed. For specific help information, use the corresponding help command of the underlying node. The help information related to underlying nodes will not be available in this node.

User Level

The command can be accessed by operators with security privileges.

Command Syntax

The command has the following syntax:

```
> show trouble-shooting statistics channel-pair [ (chanpair-idx) ]
```

Command Parameters

Table 162.7-1 "Trouble-shooting Statistics Over Channel-pair" Resource Parameters

Resource Identifier	Type	Description
(chanpair-idx)	Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::ChannelPairId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::ChannelPairId> - the channel pair identifier	interface index of the channel pair

Command Output

Table 162.7-2 "Trouble-shooting Statistics Over Channel-pair" Display parameters

Specific Information		
name	Type	Description
up-bcast-fwd	Parameter type: <Counter> - 32 bit counter	the number of broadcast frames received from the user side that are successfully forwarded by the I2-forwarding engine

162 Trouble-Shooting Status Commands

name	Type	Description
		<i>This element is only shown in detail mode.</i>
dn-bcast-fwd	Parameter type: <Counter> - 32 bit counter	the number of broadcast frames received from the network side that are successfully forwarded by the l2-forwarding engine <i>This element is only shown in detail mode.</i>
up-ucast-fwd	Parameter type: <Counter> - 32 bit counter	the number of Unicast frames received from the user side that are successfully forwarded by the l2-forwarding engine <i>This element is only shown in detail mode.</i>
dn-ucast-fwd	Parameter type: <Counter> - 32 bit counter	the number of Unicast frames received from the network side that are successfully forwarded by the l2-forwarding engine <i>This element is only shown in detail mode.</i>
up-discard	Parameter type: <Counter> - 32 bit counter	the number of frames received from the user side that are discarded by l2-forwarding engine or l2 user interface <i>This element is only shown in detail mode.</i>
dn-discard	Parameter type: <Counter> - 32 bit counter	the number of frames received from the network side that are discarded on the condition that the user interface has been found <i>This element is only shown in detail mode.</i>
up-mcast-fwd	Parameter type: <OctetCounter64> - 64 bit counter,range:[0-9223372036854775808]	the number of received multicast frames upstream on a channel pair <i>This element is only shown in detail mode.</i>
dn-mcast-fwd	Parameter type: <Counter> - 32 bit counter	the number of multicast frames received from the network side that are successfully forwarded by the l2-forwarding engine <i>This element is only shown in detail mode.</i>
up-frame-fwd	Parameter type: <OctetCounter64> - 64 bit counter,range:[0-9223372036854775808]	the number of received Ethernet frames upstream on a channel pair <i>This element is only shown in detail mode.</i>
dn-frame-fwd	Parameter type: <OctetCounter64> - 64 bit counter,range:[0-9223372036854775808]	the number of transmitted Ethernet frames downstream on a channel pair <i>This element is only shown in detail mode.</i>
up-byte-fwd	Parameter type: <OctetCounter64> - 64 bit counter,range:[0-9223372036854775808]	the number of received Ethernet bytes upstream on a channel pair <i>This element is only shown in detail mode.</i>

name	Type	Description
dn-byte-fwd	Parameter type: <OctetCounter64> - 64 bit counter,range:[0-9223372036854775808]	the number of transmitted Ethernet bytes downstream on a channel pair <i>This element is only shown in detail mode.</i>
up-illegalsize	Parameter type: <OctetCounter64> - 64 bit counter,range:[0-9223372036854775808]	the number of received Ethernet frames with illegal size upstream on a channel pair including oversize and undersize packets <i>This element is only shown in detail mode.</i>
dn-illegalsize	Parameter type: <OctetCounter64> - 64 bit counter,range:[0-9223372036854775808]	the number of transmitted Ethernet frames with illegal size downstream on a channel pair including oversize and undersize packets <i>This element is only shown in detail mode.</i>
up-crc-error	Parameter type: <OctetCounter64> - 64 bit counter,range:[0-9223372036854775808]	the number of received Ethernet frames with CRC error upstream on a channel pair <i>This element is only shown in detail mode.</i>
dn-crc-error	Parameter type: <OctetCounter64> - 64 bit counter,range:[0-9223372036854775808]	the number of transmitted Ethernet frames with CRC error downstream on a channel pair <i>This element is only shown in detail mode.</i>

162.8 Extensive Trouble-shooting

ipv4-antispoofing Statistics To One UNI Port

Command Description

This command allows the operator to show the number of frames received from the uni that are discard for ipv4-antispoofing.

User Level

The command can be accessed by operators with security privileges.

Command Syntax

The command has the following syntax:

```
> show trouble-shooting statistics uni-interface [ (if-index) ]
```

Command Parameters

Table 162.8-1 "Extensive Trouble-shooting ipv4-antispoofing Statistics To One UNI Port" Resource Parameters

Resource Identifier	Type	Description
(if-index)	Format: <pre>(<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> / <Eqpt::OntPortId> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / voip <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / vuni ont : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId>)</pre> Possible values: - ont : ont Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number Field type <Eqpt::PonId> - the PON identifier	interface index of the port

Resource Identifier	Type	Description
	Field type <Eqpt::OntId> - the ONT identifier Possible values: - voip : virtual uni identifier obsolete alternative replaced by vuni - vuni : virtual uni identifier Field type <Eqpt::OntSlotId> - the ONT SLOT identifier Field type <Eqpt::OntPortId> - the ONT PORT identifier	

Command Output

Table 162.8-2 "Extensive Trouble-shooting ipv4-antispoofing Statistics To One UNI Port" Display parameters

Specific Information		
name	Type	Description
ipv4-spoofing frame	Parameter type: <Counter> - 32 bit counter	the number of frames received from the user side that are successfully forwarded by the l2-forwarding engine <i>This element is always shown.</i>

162.9 Trouble-shooting Statistics To One VlanPort

Command Description

This command allows the operator to show extensive and summary counters of VLAN port. When this show command is invoked, all commands in underlying nodes are automatically executed. For specific help information, use the corresponding help command of the underlying node. The help information related to underlying nodes will not be available in this node.

Both the summary and detailed counters are shown through the underlying nodes.

User Level

The command can be accessed by operators with security privileges.

Command Syntax

The command has the following syntax:

```
> show trouble-shooting statistics vlanport bridgeport-id (port-interface) vlan-id [ (subscr-vlan) ]
```

Command Parameters

Table 162.9-1 "Trouble-shooting Statistics To One VlanPort" Resource Parameters

Resource Identifier	Type	Description
(port-interface)	Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::VpiId> : <Eqpt::VciId> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> / <Eqpt::OntPortId> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / voip <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / vuni <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::LLId> ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / <Eqpt::Ng2OntSlotId> / <Eqpt::Ng2OntPortId> ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / vuni) Possible values: - ng2 : ngpon2 style identification Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number	user port interface

Resource Identifier	Type	Description
	Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number Field type <Eqpt::VpiId> - atm VPI Field type <Eqpt::VciId> - atm VCI Field type <Eqpt::ChannelGroupId> - the channel group identifier Field type <Eqpt::SubChannelGroupId> - the subchannel group identifier Field type <Eqpt::PonId> - the PON identifier Field type <Eqpt::OntId> - the ONT identifier Field type <Eqpt::Ng2OntId> - the NG2 ONT identifier Possible values: - voip : virtual uni identifier obsolete alternative replaced by vuni - vuni : virtual uni identifier Possible values: - vuni : virtual NGPON2 uni identifier Field type <Eqpt::OntSlotId> - the ONT SLOT identifier Field type <Eqpt::OntPortId> - the ONT PORT identifier Field type <Eqpt::Ng2OntSlotId> - the NGPON2 ONT SLOT identifier Field type <Eqpt::Ng2OntPortId> - the NGPON2 ONT PORT identifier Field type <Eqpt::LLId> - the LLID identifier, range 1 for EPON, range 1-8 for DPOE	
(subscr-vlan)	Format: (<Vlan::UVlanIndex> stacked : <Vlan::SVlanIndex> : <Vlan::CVlanIndex>) Possible values: - stacked : stacked vlan identity Field type <Vlan::UVlanIndex> - unstacked vlan identity - range: [1...4093,4096] Field type <Vlan::SVlanIndex> - service vlan identity - range: [2...4093] Field type <Vlan::CVlanIndex> - customer vlan identity - range: [0...4093]	the subscriber vlan id

162.10 Summary Trouble-shooting Statistics To Vlan Ports

Command Description

This command shows summary counters of VLAN port.

User Level

The command can be accessed by operators with security privileges.

Command Syntax

The command has the following syntax:

```
> show trouble-shooting statistics vlanport bridgeport-id (port-interface) vlan-id (subscr-vlan) summary
```

Command Parameters

Table 162.10-1 "Summary Trouble-shooting Statistics To Vlan Ports" Resource Parameters

Resource Identifier	Type	Description
(port-interface)	Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::VpiId> : <Eqpt::VciId> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> / <Eqpt::OntPortId> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / voip <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / vuni <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::LLId> ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / <Eqpt::Ng2OntSlotId> / <Eqpt::Ng2OntPortId> ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / vuni) Possible values: - ng2 : ngpon2 style identification Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId>	user port interface

Resource Identifier	Type	Description
	- the LT slot number - Field type <Eqpt::PortId> - the port number - Field type <Eqpt::VpiId> - atm VPI - Field type <Eqpt::VciId> - atm VCI - Field type <Eqpt::ChannelGroupId> - the channel group identifier - Field type <Eqpt::SubChannelGroupId> - the subchannel group identifier - Field type <Eqpt::PonId> - the PON identifier - Field type <Eqpt::OntId> - the ONT identifier - Field type <Eqpt::Ng2OntId> - the NG2 ONT identifier - Possible values: - voip : virtual uni identifier - obsolete alternative replaced by vuni - vuni : virtual uni identifier - Possible values: - vuni : virtual NGPON2 uni identifier - Field type <Eqpt::OntSlotId> - the ONT SLOT identifier - Field type <Eqpt::OntPortId> - the ONT PORT identifier - Field type <Eqpt::Ng2OntSlotId> - the NGPON2 ONT SLOT identifier - Field type <Eqpt::Ng2OntPortId> - the NGPON2 ONT PORT identifier - Field type <Eqpt::LLId> - the LLID identifier,range 1 for EPON,range 1-8 for DPOE	
(subscr-vlan)	Format: (<Vlan::UVlanIndex> stacked : <Vlan::SVlanIndex> : <Vlan::CVlanIndex>) Possible values: - stacked : stacked vlan identity Field type <Vlan::UVlanIndex> - unstacked vlan identity - range: [1...4093,4096] Field type <Vlan::SVlanIndex> - service vlan identity - range: [2...4093] Field type <Vlan::CVlanIndex> - customer vlan identity - range: [0...4093]	the subscriber vlan id

Command Output

Table 162.10-2 "Summary Trouble-shooting Statistics To Vlan Ports" Display parameters

Specific Information		
name	Type	Description
up-forward	Parameter type: <Counter> - 32 bit counter	the number of frames received from the user side that are successfully forwarded by the

162 Trouble-Shooting Status Commands

name	Type	Description
		l2-forwarding engine <i>This element is only shown in detail mode.</i>
up-discard	Parameter type: <Counter> - 32 bit counter	the number of frames received from the user side that are discarded by l2-forwarding engine or l2 user interface <i>This element is only shown in detail mode.</i>
dn-forward	Parameter type: <Counter> - 32 bit counter	the number of frames received from the network side that are successfully forwarded by the l2-forwarding engine <i>This element is only shown in detail mode.</i>
dn-discard	Parameter type: <Counter> - 32 bit counter	the number of frames received from the network side that are discarded on the condition that the user interface has been found <i>This element is only shown in detail mode.</i>
up-bcast-fwd	Parameter type: <Debug::SignedTrafficCounter> (not-supported <SignedInteger>) Possible values: - not-supported : not support the counter Field type <SignedInteger> - a signed integer	the number of broadcast frames received from the user side that are successfully forwarded by the l2-forwarding engine <i>This element is only shown in detail mode.</i>
up-ucast-fwd	Parameter type: <Debug::SignedTrafficCounter> (not-supported <SignedInteger>) Possible values: - not-supported : not support the counter Field type <SignedInteger> - a signed integer	the number of unicast frames received from the user side that are successfully forwarded by the l2-forwarding engine <i>This element is only shown in detail mode.</i>
dn-bcast-fwd	Parameter type: <Debug::SignedTrafficCounter> (not-supported <SignedInteger>) Possible values: - not-supported : not support the counter Field type <SignedInteger> - a signed integer	the number of broadcast frames received from the network side that are successfully forwarded by the l2-forwarding engine <i>This element is only shown in detail mode.</i>
dn-ucast-fwd	Parameter type: <Debug::SignedTrafficCounter> (not-supported <SignedInteger>) Possible values: - not-supported : not support the counter Field type <SignedInteger> - a signed integer	the number of unicast frames received from the network side that are successfully forwarded by the l2-forwarding engine <i>This element is only shown in detail mode.</i>

162.11 Extensive Trouble-shooting Statistics To Vlan Ports

Command Description

This command shows extensive counters of VLAN port.

The extensive counters are only given when the counters are enabled via the related configuration command.

User Level

The command can be accessed by operators with security privileges.

Command Syntax

The command has the following syntax:

> show trouble-shooting statistics vlanport bridgeport-id (port-interface) vlan-id (subscr-vlan) extensive

Command Parameters

Table 162.11-1 "Extensive Trouble-shooting Statistics To Vlan Ports" Resource Parameters

Resource Identifier	Type	Description
(port-interface)	Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::VpId> : <Eqpt::VcId> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> / <Eqpt::OntPortId> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / voip <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / vuni <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::LLId> ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / <Eqpt::Ng2OntSlotId> / <Eqpt::Ng2OntPortId> ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / vuni) Possible values: - ng2 : ngpon2 style identification Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId>	user port interface

Resource Identifier	Type	Description
	- the shelf number - Field type <Eqpt::SlotId> - the LT slot number - Field type <Eqpt::PortId> - the port number - Field type <Eqpt::VpiId> - atm VPI - Field type <Eqpt::VciId> - atm VCI - Field type <Eqpt::ChannelGroupId> - the channel group identifier - Field type <Eqpt::SubChannelGroupId> - the subchannel group identifier - Field type <Eqpt::PonId> - the PON identifier - Field type <Eqpt::OntId> - the ONT identifier - Field type <Eqpt::Ng2OntId> - the NG2 ONT identifier - Possible values: - voip : virtual uni identifier - obsolete alternative replaced by vuni - vuni : virtual uni identifier - Possible values: - vuni : virtual NGPON2 uni identifier - Field type <Eqpt::OntSlotId> - the ONT SLOT identifier - Field type <Eqpt::OntPortId> - the ONT PORT identifier - Field type <Eqpt::Ng2OntSlotId> - the NGPON2 ONT SLOT identifier - Field type <Eqpt::Ng2OntPortId> - the NGPON2 ONT PORT identifier - Field type <Eqpt::LLId> - the LLID identifier, range 1 for EPON, range 1-8 for DPOE	
(subscr-vlan)	Format: (<Vlan::UVlanIndex> stacked : <Vlan::SVlanIndex> : <Vlan::CVlanIndex>) Possible values: - stacked : stacked vlan identity Field type <Vlan::UVlanIndex> - unstacked vlan identity - range: [1...4093,4096] Field type <Vlan::SVlanIndex> - service vlan identity - range: [2...4093] Field type <Vlan::CVlanIndex> - customer vlan identity - range: [0...4093]	the subscriber vlan id

Command Output

Table 162.11-2 "Extensive Trouble-shooting Statistics To Vlan Ports" Display parameters

Specific Information		
name	Type	Description
up-inv-dasa	Parameter type: <Counter>	the number of frames received

name	Type	Description
	- 32 bit counter	from the user side which have an invalid destination or source mac address <i>This element is only shown in detail mode.</i>
up-macport-lmt-exc	Parameter type: <Counter> - 32 bit counter	the number of frames received from the user side which mac@ could not be learned <i>This element is only shown in detail mode.</i>
up-macfdb-lmt-exc	Parameter type: <Counter> - 32 bit counter	the number of frames received from the user side which maxmac is reached <i>This element is only shown in detail mode.</i>
up-inv-prot	Parameter type: <Counter> - 32 bit counter	number of frames received from the user side with an invalid protocol <i>This element is only shown in detail mode.</i>
up-ip-spoofing	Parameter type: <Counter> - 32 bit counter	number of frames received from the user side with an ip address not matching the assigned ip address <i>This element is only shown in detail mode.</i>
up-acl-discard	Parameter type: <Counter> - 32 bit counter	the number of frames received from the user side that are discarded for acl <i>This element is only shown in detail mode.</i>
up-policer-discard	Parameter type: <Counter> - 32 bit counter	the number of frames received from the user side that are discarded due to policing <i>This element is only shown in detail mode.</i>
up-queue-discard	Parameter type: <Counter> - 32 bit counter	the number of frames received from the user side that are discarded in the uplink queue <i>This element is only shown in detail mode.</i>
up-ipv6-spoofing	Parameter type: <Counter> - 32 bit counter	number of frames received from the user side with an IPv6 address not matching the assigned IP address <i>This element is only shown in detail mode.</i>
up-tpid-discard	Parameter type: <SignedInteger> - a signed integer	number of frames received from the user side with an tpid not matching the assigned tpid <i>This element is only shown in detail mode.</i>
dn-mcast-fwd	Parameter type: <Counter> - 32 bit counter	number of multicast frames received from the network side and successfully forwarded by the l2-forwarding engine <i>This element is only shown in</i>

162 Trouble-Shooting Status Commands

name	Type	Description
		<i>detail mode.</i>
dn-nonmcast-fwd	Parameter type: <Counter> - 32 bit counter	number of non-multicast (including broadcast) frames received from the network side and successfully forwarded by the l2-forwarding engine <i>This element is only shown in detail mode.</i>
dn-mcast-discard	Parameter type: <Counter> - 32 bit counter	number of multicast frames received from the network side, routed to the vlan Port and then discarded for any reason, even if this reason is not related to the vlan port functionality <i>This element is only shown in detail mode.</i>
dn-nonmcast-discard	Parameter type: <Counter> - 32 bit counter	number of non-multicast frames received from the network side, routed to the vlan port and then discarded for any reason, even if this reason is not related to the Vlan Port functionality <i>This element is only shown in detail mode.</i>
dn-acl-discard	Parameter type: <Counter> - 32 bit counter	the number of frames received from the network side that are discarded for acl/ccl filtering <i>This element is only shown in detail mode.</i>
dn-policer-discard	Parameter type: <Counter> - 32 bit counter	the number of frames received from the network side that is discarded due to policing on l2 forwarder interface <i>This element is only shown in detail mode.</i>
dn-queue-discard	Parameter type: <Counter> - 32 bit counter	number of frames received from the network side, routed to the vlan port and then discarded because of queue overflow <i>This element is only shown in detail mode.</i>

162.12 Trouble-shooting PBIT Statistics

Command Description

This command allows the operator to show the trouble-shooting pbit counters.

User Level

The command can be accessed by operators with security privileges.

Command Syntax

The command has the following syntax:

```
> show trouble-shooting pbitstatistics
```

162.13 Trouble-shooting PBIT Statistics

Command Description

This command allows the operator to show the trouble-shooting pbit counters.

User Level

The command can be accessed by operators with security privileges.

Command Syntax

The command has the following syntax:

```
> show trouble-shooting pbitstatistics vlanport [ (if-index) [ pbit <Debug::Pbit> ] ]
```

Command Parameters

Table 162.13-1 "Trouble-shooting PBIT Statistics" Resource Parameters

Resource Identifier	Type	Description
(if-index)	Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::UnstackedVlan> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::UnstackedVlan> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / stacked : <Eqpt::SVlan> : <Eqpt::CVlan> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / stacked : <Eqpt::SVlan> : <Eqpt::CVlan> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> / <Eqpt::OntPortId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> / <Eqpt::OntPortId> : <Eqpt::UnstackedVlan> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / voip : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / vuni : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / voip : <Eqpt::UnstackedVlan> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / vuni : <Eqpt::UnstackedVlan> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> /	interface index of the vlan

Resource Identifier	Type	Description
	<code><Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::UnstackedVlan></code> <code> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> /</code> <code><Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::LLId> : stacked :</code> <code><Eqpt::SVlan> : <Eqpt::CVlan></code> <code> ng2 : <Ng2::ChannelGroup> / <Ng2::SubchannelGroup> /</code> <code><Ng2::OntId> / <Eqpt::Ng2OntSlotId> /</code> <code><Eqpt::Ng2OntPortId> : stacked : <Eqpt::SVlan> :</code> <code><Eqpt::CVlan></code> <code> ng2 : <Ng2::ChannelGroup> / <Ng2::SubchannelGroup> /</code> <code><Ng2::OntId> / <Eqpt::Ng2OntSlotId> /</code> <code><Eqpt::Ng2OntPortId> : <Eqpt::UnstackedVlan></code> <code> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> /</code> <code><Eqpt::PortId> : <Eqpt::VpId> : <Eqpt::VcId>)</code> Possible values: - ng2 : ngpon2 vlan port Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number Field type <Eqpt::VpId> - atm VPI Field type <Eqpt::VcId> - atm VCI Field type <Eqpt::PonId> - the PON identifier Field type <Eqpt::OntId> - the ONT identifier Field type <Ng2::ChannelGroup> - channel group number Field type <Ng2::SubchannelGroup> - subchannel group number Field type <Ng2::OntId> - the ONT identifier Possible values: - voip : virtual uni identifier obsolete alternative replaced by vuni - vuni : virtual uni identifier Possible values: - vuni : virtual NGPON2 uni identifier Field type <Eqpt::OntSlotId> - the ONT SLOT identifier Field type <Eqpt::OntPortId> - the ONT PORT identifier Field type <Eqpt::Ng2OntSlotId> - the NGPON2 ONT SLOT identifier Field type <Eqpt::Ng2OntPortId> - the NGPON2 ONT PORT identifier Field type <Eqpt::LLId> - the LLID identifier, range 1 for EPON, range 1-8 for DPOE Possible values: - stacked : stacked vlan identity Field type <Eqpt::UnstackedVlan> - unstacked vlan id	

Resource Identifier	Type	Description
	Field type <Eqpt::SVlan> - service vlan id Field type <Eqpt::CVlan> - customer vlan id	
pbit	Parameter type: <Debug::Pbit> Format: - pbit - range: [0...7]	pbit

Command Output

Table 162.13-2 "Trouble-shooting PBIT Statistics" Display parameters

Specific Information		
name	Type	Description
up-pbit-fwd	Parameter type: <Vlan::OctetCounter> - vlan counter	the number of frames received from the user side that are successfully forwarded <i>This element is always shown.</i>
dn-pbit-fwd	Parameter type: <Vlan::OctetCounter> - vlan counter	the number of frames received from the network side that are successfully forwarded <i>This element is always shown.</i>
up-pbit-discard	Parameter type: <Vlan::OctetCounter> - vlan counter	the number of frames received from the user side that are discarded <i>This element is always shown.</i>
dn-pbit-discard	Parameter type: <Vlan::OctetCounter> - vlan counter	the number of frames received from the network side that are discarded <i>This element is always shown.</i>
up-pbit-fwd-bytes	Parameter type: <Vlan::OctetCounter> - vlan counter	the number of bytes received from the user side that are successfully forwarded <i>This element is always shown.</i>
dn-pbit-fwd-bytes	Parameter type: <Vlan::OctetCounter> - vlan counter	the number of bytes received from the network side that are successfully forwarded <i>This element is always shown.</i>
up-pbit-discard-bytes	Parameter type: <Vlan::OctetCounter> - vlan counter	the number of bytes received from the user side that are discarded <i>This element is always shown.</i>
dn-pbit-discard-bytes	Parameter type: <Vlan::OctetCounter> - vlan counter	the number of bytes received from the network side that are discarded <i>This element is always shown.</i>

163- *Trouble-Shooting Pbit Counter Commands*

163.1 Trouble-Shooting Pbit Counter Command Tree
163.2 Trouble-shooting PBIT Statistics

163-6728
163-6729

163.1 Trouble-Shooting Pbit Counter Command Tree

Description

This chapter gives an overview of nodes that are handled by "Trouble-Shooting Pbit Counter Commands".

Command Tree

```
----show
  ----trouble-shooting
    ----pbit
      ----statistics
        ----interface
          - (if-index)
          - pbit
```

163.2 Trouble-shooting PBIT Statistics

Command Description

This command allows the operator to show the trouble-shooting pbit counters.

User Level

The command can be accessed by operators with security privileges.

Command Syntax

The command has the following syntax:

```
> show trouble-shooting pbit statistics interface [ (if-index) [ pbit <Debug::Pbit> ] ]
```

Command Parameters

Table 163.2-1 "Trouble-shooting PBIT Statistics" Resource Parameters

Resource Identifier	Type	Description
(if-index)	Format: (vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::UnstackedVlan> vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::UnstackedVlan> vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> / <Eqpt::OntPortId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> / <Eqpt::OntPortId> : <Eqpt::UnstackedVlan> vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / voip : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / vuni : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / voip : <Eqpt::UnstackedVlan> vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / vuni : <Eqpt::UnstackedVlan> vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> /	interface index of the vlan

Resource Identifier	Type	Description
	<Eqpt::PonId> / <Eqpt::OntId> / stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::UnstackedVlan> vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> <Eqpt::VpiId> : <Eqpt::VciId>) Possible values: - vlan : vlan port Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number Field type <Eqpt::VpiId> - atm VPI Field type <Eqpt::VciId> - atm VCI Field type <Eqpt::PonId> - the PON identifier Field type <Eqpt::OntId> - the ONT identifier Possible values: - voip : virtual uni identifier obsolete alternative replaced by vuni - vuni : virtual uni identifier Field type <Eqpt::OntSlotId> - the ONT SLOT identifier Field type <Eqpt::OntPortId> - the ONT PORT identifier Possible values: - stacked : stacked vlan identity Field type <Eqpt::UnstackedVlan> - unstacked vlan id Field type <Eqpt::SVlan> - service vlan id Field type <Eqpt::CVlan> - customer vlan id	
pbit	Parameter type: <Debug::Pbit> Format: - pbit - range: [0...7]	pbit

Command Output

Table 163.2-2 "Trouble-shooting PBIT Statistics" Display parameters

Specific Information		
name	Type	Description
up-pbit-fwd	Parameter type: <Vlan::OctetCounter> - vlan counter	the number of frames received from the user side that are successfully forwarded <i>This element is always shown.</i>
dn-pbit-fwd	Parameter type: <Vlan::OctetCounter> - vlan counter	the number of frames received from the network side that are

name	Type	Description
		successfully forwarded <i>This element is always shown.</i>
up-pbit-discard	Parameter type: <Vlan::OctetCounter> - vlan counter	the number of frames received from the user side that are discarded <i>This element is always shown.</i>
dn-pbit-discard	Parameter type: <Vlan::OctetCounter> - vlan counter	the number of frames received from the network side that are discarded <i>This element is always shown.</i>
up-pbit-fwd-bytes	Parameter type: <Vlan::OctetCounter> - vlan counter	the number of bytes received from the user side that are successfully forwarded <i>This element is always shown.</i>
dn-pbit-fwd-bytes	Parameter type: <Vlan::OctetCounter> - vlan counter	the number of bytes received from the network side that are successfully forwarded <i>This element is always shown.</i>
up-pbit-discard-bytes	Parameter type: <Vlan::OctetCounter> - vlan counter	the number of bytes received from the user side that are discarded <i>This element is always shown.</i>
dn-pbit-discard-bytes	Parameter type: <Vlan::OctetCounter> - vlan counter	the number of bytes received from the network side that are discarded <i>This element is always shown.</i>

164- Trouble-Shooting Pon Status Commands

164.1 Trouble-Shooting Pon Status Command Tree
164.2 Trouble-shooting Statistics over Pon Port

164-6733
164-6734

164.1 Trouble-Shooting Pon Status Command Tree

Description

This chapter gives an overview of nodes that are handled by "Trouble-Shooting Pon Status Commands".

Command Tree

```
----show
  ----trouble-shooting
    ----pon
      ----statistics
        ----interface
          - (if-index)
```

164.2 Trouble-shooting Statistics over Pon Port

Command Description

This command allows the operator to show the trouble-shooting counters over pon ports.

User Level

The command can be accessed by operators with security privileges.

Command Syntax

The command has the following syntax:

> show trouble-shooting pon statistics interface [(if-index)]

Command Parameters

Table 164.2-1 "Trouble-shooting Statistics over Pon Port" Resource Parameters

Resource Identifier	Type	Description
(if-index)	Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> x-pon : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::XPonId> 25g-pon : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::M25GPonId>) Possible values: - 25g-pon : 25g-pon - x-pon : xgs-pon Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Eqpt::XPonId> - the XGS PON identifier Field type <Eqpt::M25GPonId> - the 25G PON identifier	interface index of the pon port

Command Output

Table 164.2-2 "Trouble-shooting Statistics over Pon Port" Display parameters

Specific Information

name	Type	Description
up-bcast-fwd	Parameter type: <Counter> - 32 bit counter	the number of broadcast frames received from the user side that are successfully forwarded by the l2-forwarding engine <i>This element is only shown in detail mode.</i>
dn-bcast-fwd	Parameter type: <Counter> - 32 bit counter	the number of broadcast frames received from the network side that are successfully forwarded by the l2-forwarding engine <i>This element is only shown in detail mode.</i>
up-ucast-fwd	Parameter type: <Counter> - 32 bit counter	the number of Unicast frames received from the user side that are successfully forwarded by the l2-forwarding engine <i>This element is only shown in detail mode.</i>
dn-ucast-fwd	Parameter type: <Counter> - 32 bit counter	the number of Unicast frames received from the network side that are successfully forwarded by the l2-forwarding engine <i>This element is only shown in detail mode.</i>
up-discard	Parameter type: <Counter> - 32 bit counter	the number of frames received from the user side that are discarded by l2-forwarding engine or l2 user interface <i>This element is only shown in detail mode.</i>
dn-discard	Parameter type: <Counter> - 32 bit counter	the number of frames received from the network side that are discarded on the condition that the user interface has been found <i>This element is only shown in detail mode.</i>
up-mcast-fwd	Parameter type: <OctetCounter64> - 64 bit counter,range:[0-9223372036854775808]	the number of received multicast frames upstream on a PON port <i>This element is only shown in detail mode.</i>
dn-mcast-fwd	Parameter type: <Counter> - 32 bit counter	the number of multicast frames received from the network side that are successfully forwarded by the l2-forwarding engine <i>This element is only shown in detail mode.</i>
up-frame-fwd	Parameter type: <OctetCounter64> - 64 bit counter,range:[0-9223372036854775808]	the number of received Ethernet frames upstream on a PON port <i>This element is only shown in detail mode.</i>
dn-frame-fwd	Parameter type: <OctetCounter64> - 64 bit counter,range:[0-9223372036854775808]	the number of transmitted Ethernet frames downstream on a PON port <i>This element is only shown in detail mode.</i>
up-byte-fwd	Parameter type: <OctetCounter64> - 64 bit counter,range:[0-9223372036854775808]	the number of received Ethernet bytes upstream on a PON port

164 Trouble-Shooting Pon Status Commands

name	Type	Description
		<i>This element is only shown in detail mode.</i>
dn-byte-fwd	Parameter type: <OctetCounter64> - 64 bit counter,range:[0-9223372036854775808]	the number of transmitted Ethernet bytes downstream on a PON port <i>This element is only shown in detail mode.</i>
up-illegalsize	Parameter type: <OctetCounter64> - 64 bit counter,range:[0-9223372036854775808]	the number of received Ethernet frames with illegal size upstream on a PON port including oversize and undersize packets <i>This element is only shown in detail mode.</i>
dn-illegalsize	Parameter type: <OctetCounter64> - 64 bit counter,range:[0-9223372036854775808]	the number of transmitted Ethernet frames with illegal size downstream on a PON port including oversize and undersize packets <i>This element is only shown in detail mode.</i>
up-crc-error	Parameter type: <OctetCounter64> - 64 bit counter,range:[0-9223372036854775808]	the number of received Ethernet frames with CRC error upstream on a PON port <i>This element is only shown in detail mode.</i>
dn-crc-error	Parameter type: <OctetCounter64> - 64 bit counter,range:[0-9223372036854775808]	the number of transmitted Ethernet frames with CRC error downstream on a PON port <i>This element is only shown in detail mode.</i>

165- *Trouble-Shooting Color Counter Commands*

165.1 Trouble-Shooting Color Counter Command Tree	165-6738
165.2 Trouble-shooting Color Statistics	165-6739

165.1 Trouble-Shooting Color Counter Command Tree

Description

This chapter gives an overview of nodes that are handled by "Trouble-Shooting Color Counter Commands".

Command Tree

```
----show
  ----trouble-shooting
    ----color
      ----statistics
        ----interface
          - (if-index)
```

165.2 Trouble-shooting Color Statistics

Command Description

This command allows the operator to show the trouble-shooting color counters.

User Level

The command can be accessed by operators with security privileges.

Command Syntax

The command has the following syntax:

> show trouble-shooting color statistics interface [(if-index)]

Command Parameters

Table 165.2-1 "Trouble-shooting Color Statistics" Resource Parameters

Resource Identifier	Type	Description
(if-index)	Format: (vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::VpiId> : <Eqpt::VciId> : <Eqpt::UnstackedVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::UnstackedVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::VpiId> : <Eqpt::VciId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> / <Eqpt::OntPortId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> / <Eqpt::OntPortId> : <Eqpt::UnstackedVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / voip : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / vuni : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / voip : <Eqpt::UnstackedVlan>	interface index of the vlan port

Resource Identifier	Type	Description
	vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / vuni : <Eqpt::UnstackedVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::LLId> : <Eqpt::UnstackedVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::LLId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan>) Possible values: - vlan-port : vlan port Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number Field type <Eqpt::VpiId> - atm VPI Field type <Eqpt::VciId> - atm VCI Field type <Eqpt::PonId> - the PON identifier Field type <Eqpt::OntId> - the ONT identifier Possible values: - voip : virtual uni identifier obsolete alternative replaced by vuni - vuni : virtual uni identifier Field type <Eqpt::OntSlotId> - the ONT SLOT identifier Field type <Eqpt::OntPortId> - the ONT PORT identifier Field type <Eqpt::LLId> - the LLID identifier, range 1 for EPON, range 1-8 for DPOE Possible values: - stacked : stacked vlan identity Field type <Eqpt::UnstackedVlan> - unstacked vlan id Field type <Eqpt::SVlan> - service vlan id Field type <Eqpt::CVlan> - customer vlan id	

Command Output

Table 165.2-2 "Trouble-shooting Color Statistics" Display parameters

Specific Information		
name	Type	Description
up-grn-before-policer	Parameter type: <Qos::OctetCounter> - qos counter	the green packets send to policer in up direction <i>This element is always shown.</i>
up-ylw-before-policer	Parameter type: <Qos::OctetCounter> - qos counter	the yellow packets send to policer in up direction

name	Type	Description
		<i>This element is always shown.</i>
up-red-before-policer	Parameter type: <Qos::OctetCounter> - qos counter	the red packets send to policer in up direction <i>This element is always shown.</i>
up-g2g-after-policer	Parameter type: <Vlan::OctetCounter> - vlan counter	the green packets which from green packets after policer in up direction <i>This element is always shown.</i>
up-g2y-after-policer	Parameter type: <Vlan::OctetCounter> - vlan counter	the yellow packets which translate from green packets after policer in up direction <i>This element is always shown.</i>
up-g2r-after-policer	Parameter type: <Vlan::OctetCounter> - vlan counter	the red packets which translate from green packets after policer in up direction <i>This element is always shown.</i>
up-y2y-after-policer	Parameter type: <Vlan::OctetCounter> - vlan counter	the yellow packets which from yellow packets after policer in up direction <i>This element is always shown.</i>
up-y2r-after-policer	Parameter type: <Vlan::OctetCounter> - vlan counter	the red packets which translate from yellow packets after policer in up direction <i>This element is always shown.</i>
up-r2r-after-policer	Parameter type: <Vlan::OctetCounter> - vlan counter	the red packets which from red packets after policer in up direction <i>This element is always shown.</i>
dn-grn-before-policer	Parameter type: <Qos::OctetCounter> - qos counter	the green packets send to policer in down direction <i>This element is always shown.</i>
dn-ylw-before-policer	Parameter type: <Qos::OctetCounter> - qos counter	the yellow packets send to policer in down direction <i>This element is always shown.</i>
dn-red-before-policer	Parameter type: <Qos::OctetCounter> - qos counter	the red packets send to policer in down direction <i>This element is always shown.</i>
dn-g2g-after-policer	Parameter type: <Vlan::OctetCounter> - vlan counter	the green packets which from green packets after policer in down direction <i>This element is always shown.</i>
dn-g2y-after-policer	Parameter type: <Vlan::OctetCounter> - vlan counter	the yellow packets which translate from green packets after policer in down direction <i>This element is always shown.</i>
dn-g2r-after-policer	Parameter type: <Vlan::OctetCounter> - vlan counter	the red packets which translate from green packets after policer in down direction <i>This element is always shown.</i>
dn-y2y-after-policer	Parameter type: <Vlan::OctetCounter> - vlan counter	the yellow packets which from yellow packets after policer in down direction <i>This element is always shown.</i>
dn-y2r-after-policer	Parameter type: <Vlan::OctetCounter> - vlan counter	the red packets which translate from yellow packets after policer in down direction <i>This element is always shown.</i>

165 Trouble-Shooting Color Counter Commands

name	Type	Description
dn-r2r-after-policer	Parameter type: <Vlan::OctetCounter> - vlan counter	the red packets which from red packets after policer in down direction <i>This element is always shown.</i>

166- CFM Status Commands

166.1 CFM Status Command Tree	166-6744
166.2 Maintenance Domain on NT Status Command	166-6746
166.3 Maintenance Association on NT Status Command	166-6748
166.4 Maintenance Association End Point on NT Status Command	166-6752
166.5 CFM Stack on NT Status Command	166-6756
166.6 Maintenance Association End Point CCM Database show Command	166-6759
166.7 Maintenance Association End Point on NT Runtime Info Command	166-6762
166.8 LT CFM SLM Responder Statistics Table	166-6766
166.9 PM proactive show	166-6768
166.10 Proactive CFM PM show command for the current 15 min	166-6769
166.11 Proactive CFM PM show command for the current 15 min	166-6770
166.12 Proactive CFM PM show command for the current 1 day	166-6775
166.13 Proactive CFM PM show command for the current 1 day	166-6776
166.14 Proactive CFM PM show command for the previous 15 min	166-6781
166.15 Proactive CFM PM show command for the previous 15 min	166-6782
166.16 Proactive CFM PM show command for the previous 1 day	166-6787
166.17 Proactive CFM PM show command for the previous 1 day	166-6788
166.18 Maintenance Association End Point Y1731 AIS Info Command	166-6793

166.1 CFM Status Command Tree

Description

This chapter gives an overview of nodes that are handled by "CFM Status Commands".

Command Tree

```
----show
  ----cfm
    ----md-config-data
      ----domain
        - (domain-index)
    ----ma-config-data
      ----domain
        - (domain-index)
        - association
    ----mep-config-data
      ----domain
        - (domain-index)
        - association
        - mep
    ----stack
      - (location)
      - equipment
      - vlan
      - level
      - direction
    ----ccm-database
      ----domain
        - (domain-index)
        - association
        - mep
        - remote-mep
    ----mep-info
      ----domain
        - (domain-index)
        - association
        - mep
    ----slm-responder-stats
      ----domain
        - (domain-index)
        - association
        - mep
        - slm-initiator-mep
        - slm-initiator-mac
        - test-id
    ----y1731pm
      ----curr-15min-stats
        ----domain
          - (domain-index)
          - association
          - mep
          - session-id
```

```
----curr-day-stats
  ----domain
    - (domain-index)
    - association
    - mep
    - session-id
----prev-15min-stats
  ----domain
    - (domain-index)
    - association
    - mep
    - session-id
    - interval-number
----prev-day-stats
  ----domain
    - (domain-index)
    - association
    - mep
    - session-id
    - interval-number
----mep-y1731ais-info
  ----domain
    - (domain-index)
    - association
    - mep
```

166.2 Maintenance Domain on NT Status Command

Command Description

This command displays Maintenance Domain (MD) data.

User Level

The command can be accessed by operators with alarm , oam , vlan privileges.

Command Syntax

The command has the following syntax:

```
> show cfm md-config-data domain [ (domain-index) ]
```

Command Parameters

Table 166.2-1 "Maintenance Domain on NT Status Command" Resource Parameters

Resource Identifier	Type	Description
(domain-index)	Format: - Maintenance Domain (MD) index - range: [1...4294967295]	Maintenance Domain (MD) index

Command Output

Table 166.2-2 "Maintenance Domain on NT Status Command" Display parameters

Specific Information		
name	Type	Description
format:name	Parameter type: <Cfm::FormatString> (mac : <Cfm::MacAddress> string : <Cfm::PrintableString> dns : <Cfm::PrintableString> none) Possible values: - mac : mac address - string : string - dns : dns - none : No MD name. Field type <Cfm::PrintableString> - all characters except for characters 0 to 31 - length: 1<=x<=43 Field type <Cfm::MacAddress> - MAC address plus 2 hex octets, e.g. 11:22:33:44:55:66:77:88 - length: 8	unique identifier for a Maintenance Domain (MD) name which contains the format and value <i>This element is always shown.</i>
level	Parameter type: <Cfm::MdLevelType>	Maintenance Domain (MD) level

name	Type	Description
	- Maintenance Domain (MD) level - range: [0...7]	<i>This element is always shown.</i>

166.3 Maintenance Association on NT Status Command

Command Description

This command displays the Maintenance Association (MA) data.

An MA is contained within a Maintenance Domain (MD) and is identified by the combination of MD index and MA index.

User Level

The command can be accessed by operators with alarm , oam , vlan privileges.

Command Syntax

The command has the following syntax:

```
> show cfm ma-config-data domain [ (domain-index) [ association <Cfm::CfmMaIndexType> ] ]
```

Command Parameters

Table 166.3-1 "Maintenance Association on NT Status Command" Resource Parameters

Resource Identifier	Type	Description
(domain-index)	Format: - Maintenance Domain (MD) index - range: [1...4294967295]	Maintenance Domain (MD) index
association	Parameter type: <Cfm::CfmMaIndexType> Format: - Maintenance Association (MA) index. Unique within an MD - range: [1...4294967295]	Maintenance Association (MA) index

Command Output

Table 166.3-2 "Maintenance Association on NT Status Command" Display parameters

Specific Information		
name	Type	Description
vlan	Parameter type: <Network::StackedVlan> (<Network::UVlanIndex> stacked : <Network::SVlanIndex> : <Network::CVlanIndex>) Possible values: - stacked : stacked vlan identity Field type <Network::UVlanIndex> - unstacked vlan identity	VlanId for the Maintenance Association (MA) <i>This element is always shown.</i>

name	Type	Description
	- range: [1...4093] Field type <Network::SVlanIndex> - service vlan identity - range: [2...4093,4094,4095,4096] Field type <Network::CVlanIndex> - customer vlan identity - range: [0...4093,4094,4095,4096]	
bridgeport	Parameter type: <Cfm::InterfaceZeroIndex> (none <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> / <Eqpt::OntPortId> ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / <Eqpt::Ng2OntSlotId> / <Eqpt::Ng2OntPortId> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / vuni) Possible values: - none : no port - ng2 : ngpon2 style identification Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number Field type <Eqpt::PonId> - the PON identifier Field type <Eqpt::OntId> - the ONT identifier Field type <Eqpt::ChannelGroupId> - the channel group identifier Field type <Eqpt::SubChannelGroupId> - the subchannel group identifier Field type <Eqpt::Ng2OntId> - the NG2 ONT identifier Possible values: - voip : virtual uni identifier Possible values: - vuni : virtual NGPON2 uni identifier Field type <Eqpt::OntSlotId> - the ONT SLOT identifier Field type <Eqpt::OntPortId> - the ONT PORT identifier Field type <Eqpt::Ng2OntSlotId> - the NGPON2 ONT SLOT identifier Field type <Eqpt::Ng2OntPortId> - the NGPON2 ONT PORT identifier	IfIndex of UNI <i>This element is always shown.</i>
mhf-creation	Parameter type: <Cfm::CfmMhfCreationType> (mhf-none mhf-default) Possible values: - mhf-none : No MHF creation for this VLAN ID	MIP Half Function (MHF) creation control for an MA <i>This element is always shown.</i>

name	Type	Description
	- mhf-default : MHF creation for this VLAN ID on related bridge ports	
maformat:maname	Parameter type: <Cfm::MaFormattedString> (pvid : <Cfm::MaNamePvid> string : <Cfm::MaNameCharstr> uint16 : <Cfm::MaNameUint16> vpnid : <Cfm::MaVpnid> icc : <Cfm::MaNameIcc>) Possible values: - pvid : pvid - string : string - uint16 : unsigned - vpnid : vpnId - icc : raw ascii Field type <Cfm::MaNamePvid> - MaName Pvid Range [0...4094] - length: x<=4 Field type <Cfm::MaNameCharstr> - Raw ascii up to 45 Characters, except the character code 0-31 decimal - length: x<=45 Field type <Cfm::MaNameUint16> - MaName Uint16 Range [0...65535] - length: x<=5 Field type <Cfm::MaVpnid> - MaName VpnId 7 Octet Format : xxx:xxxx, where x is a between 00 and FF eg:11FF33:AABBCCDD - length: 15 Field type <Cfm::MaNameIcc> - MaName Icc Raw ascii exactly 13 characters - length: 13	unique identifier for a Maintenance Association (MA) name which contains the format and value <i>This element is always shown.</i>
ccmint	Parameter type: <Cfm::CfmMaCcmInterval> (0 3.33ms 10ms 100ms 1 10 60 600) Possible values: - 0 : CCM Rx disable - 3.33ms : CCM Interval 3.33 mSecs - 10ms : CCM Interval 10 mSecs - 100ms : CCM Interval 100 mSecs - 1 : CCM Interval 1 secs - 10 : CCM Interval 10 secs - 60 : CCM Interval 1 Min - 600 : CCM Interval 10 Min	MA CCM Interval <i>This element is always shown.</i>
ccmaware	Parameter type: <Cfm::CfmMaCcmAware> (ccm-aware ccm-unaware) Possible values: - ccm-aware : turn on the CCM frame processing on reception - ccm-unaware : turn off the CCM frame processing on reception	MA CCM Aware <i>This element is always shown.</i>

name	Type	Description
ltm-filtering	Parameter type: <Cfm::CfmMaLtmFilter> (enable disable) Possible values: - enable : enable ltm-filtering - disable : disable ltm-filtering	MA LTM Filter <i>This element is always shown.</i>
dualtag	Parameter type: <Cfm::CfmMaDualTagAwareShow> (aware unaware) Possible values: - aware : Process CFM Messages upto 2 vlan tags in C-Vlan CC mode, refer documentation for hardware support information. - unaware : disables dual-tag-aware	MA DualTag Aware <i>This element is always shown.</i>
mhf-location	Parameter type: <Cfm::CfmMaMhfLocationType> (default ltuplink vbp onu ltuplink-vbp ltuplink-onu vbp-onu ltuplink-vbp-onu) Possible values: - default : default value: for GPON board, MIP is set on onu; for DSL board, MIP is set on vbp. - ltuplink : MIP is set on lt uplink - vbp : MIP is set on olt virtual bridgeport - onu : MIP is set on onu - ltuplink-vbp : MIPs are set on lt up link and virtual bridgeport - ltuplink-onu : MIPs are set on lt uplink and onu - vbp-onu : MIPs are set on virtual bridgeport and onu - ltuplink-vbp-onu : MIPs are set on olt uplink, virtual bridgeport and onu	MA Mhf Location <i>This element is always shown.</i>
ccmadmin	Parameter type: <Cfm::CfmMaCcmAdminState> (unlock lock) Possible values: - unlock : sets CCM AdminState to activate(unlock) ccm function - lock : sets CCM AdminState to de-activate(lock) ccm function	MA CCM AdminState <i>This element is always shown.</i>

166.4 Maintenance Association End Point on NT Status Command

Command Description

This command displays the Maintenance association End Point (MEP) data.

A MEP is contained within a Maintenance Association (MA) and is identified by the combination of Maintenance Domain (MD) index, MA index and MEP ID.

User Level

The command can be accessed by operators with alarm , oam , vlan privileges.

Command Syntax

The command has the following syntax:

```
> show cfm mep-config-data domain [ (domain-index) [ association <Cfm::CfmMaIndexType> ] [ mep
<Cfm::MepIdType> ] ]
```

Command Parameters

Table 166.4-1 "Maintenance Association End Point on NT Status Command" Resource Parameters

Resource Identifier	Type	Description
(domain-index)	Format: - Maintenance Domain (MD) index - range: [1...4294967295]	Maintenance Domain (MD) index
association	Parameter type: <Cfm::CfmMaIndexType> Format: - Maintenance Association (MA) index. Unique within an MD - range: [1...4294967295]	Maintenance Association (MA) index
mep	Parameter type: <Cfm::MepIdType> Format: - MA End Point (MEP) ID. Unique within an MA - range: [1...8191]	Maintenance association End Point (MEP) ID

Command Output

Table 166.4-2 "Maintenance Association End Point on NT Status Command" Display parameters

Specific Information		
name	Type	Description
location	Parameter type: <Cfm::location> (user : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::VpiId> : <Eqpt::VciId>	Maintenance association End Point (MEP) location <i>This element is always shown.</i>

name	Type	Description
	user : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> slot : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> user : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> / <Eqpt::OntPortId> user : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / voip user : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / vuni ng2 : <Ng2::ChannelGroup> / <Ng2::SubchannelGroup> / <Ng2::OntId> / <Eqpt::Ng2OntSlotId> / <Eqpt::Ng2OntPortId> ng2 : <Ng2::ChannelGroup> / <Ng2::SubchannelGroup> / <Ng2::OntId> / vuni) Possible values: - user : User bridge-port location - slot : slot location - ng2 : ngpon2 style identification Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number Field type <Eqpt::VpiId> - atm VPI Field type <Eqpt::VciId> - atm VCI Field type <Eqpt::PonId> - the PON identifier Field type <Eqpt::OntId> - the ONT identifier Field type <Ng2::ChannelGroup> - channel group number Field type <Ng2::SubchannelGroup> - subchannel group number Field type <Ng2::OntId> - the ONT identifier Possible values: - voip : virtual uni identifier obsolete alternative replaced by vuni - vuni : virtual uni identifier Possible values: - vuni : virtual NGPON2 uni identifier Field type <Eqpt::OntSlotId> - the ONT SLOT identifier Field type <Eqpt::OntPortId> - the ONT PORT identifier Field type <Eqpt::Ng2OntSlotId> - the NGPON2 ONT SLOT identifier Field type <Eqpt::Ng2OntPortId> - the NGPON2 ONT PORT identifier	
cci-enable	Parameter type: <Cfm::MepCcmEnableDisable> (cci-enable	Enable/Disable CCM generation on the current MEP

166 CFM Status Commands

name	Type	Description
	cci-disable) Possible values: - cci-enable : Enable CCM generation on the current MEP - cci-disable : Disable CCM generation on the current MEP	<i>This element is always shown.</i>
ccm-priority	Parameter type: <Cfm::MepCcmPriority> - Priority value for CCMs transmitted by the MEP - range: [0...7]	Priority value for CCMs transmitted by the MEP <i>This element is always shown.</i>
ais-enable	Parameter type: <Cfm::MepAisEnableDisable> (ais-enable ais-disable) Possible values: - ais-enable : AIS generation is enabled on the current MEP - ais-disable : AIS generation is disabled on the current MEP	Enable/Disable AIS generation on the current MEP <i>This element is always shown.</i>
ais-meg-level	Parameter type: <Cfm::MepAisMegLevel> - Meg Level for AIS frames transmitted by the MEP - range: [0...7]	ais meg level by the MEP <i>This element is always shown.</i>
ais-period	Parameter type: <Cfm::MepAisPeriod> - Period of the AIS frames transmitted by the MEP, 0 (per second), 1 (per minute) - range: [0...1]	ais period by the MEP <i>This element is always shown.</i>
ais-priority	Parameter type: <Cfm::MepAisPriority> - Priority value for AIS frames transmitted by the MEP - range: [0...7]	ais priority by the MEP <i>This element is always shown.</i>
equipment	Parameter type: <Cfm::MepEquipmentType> (default olt onu) Possible values: - default : Gpon Onu or Dsl - olt : Gpon LT - onu : Gpon Onu	Mep equipment <i>This element is always shown.</i>
ais-autoshut	Parameter type: <Cfm::MepAisAutoShut> (portshut-enable portshut-disable) Possible values: - portshut-enable : shutdown enabled on the current MEP - portshut-disable : shutdown disabled on the current MEP	Shutdown the BP port or not <i>This element is always shown.</i>
low-pri-defect	Parameter type: <Cfm::MepLowPriorityDefect> (all-def mac-rem-err-xcon rem-err-xcon err-xcon xcon no-xcon) Possible values: - all-def : For DefRDICCM, DefMACstatus, DefRemoteCCM, DefErrorCCM, and DefXconCCM - mac-rem-err-xcon : Only DefMACstatus, DefRemoteCCM, DefErrorCCM, and DefXconCCM (default) - rem-err-xcon : Only DefRemoteCCM, DefErrorCCM, and DefXconCCM - err-xcon : Only DefErrorCCM and DefXconCCM - xcon : Only DefXconCCM - no-xcon : No defects DefXcon or lower are to be reported	The lowest priority defect that is allowed to generate fault alarm <i>This element is always shown.</i>
fng-alarm-time	Parameter type: <Cfm::MepFngAlarmTime> - multiples of 250 ticks are	The time in ticks(1 tick=10ms) that defects must be present

name	Type	Description
	supported(250,500,750,1000).default = 250 ticks(2.5sec) - unit: 1/100 sec - range: [250...1000]	before a Fault alarm is issued. <i>This element is always shown.</i>
fng-reset-time	Parameter type: <Cfm::MepFngResetTime> - multiples of 250 ticks are supported(250,500,750,1000). default = 1000 ticks(10sec) - unit: 1/100 sec - range: [250...1000]	The time in ticks (1tick = 10ms) that defects must be absent before re-enabling a Fault Alarm. <i>This element is always shown.</i>
direction	Parameter type: <Cfm::CfmDirectionType> (down up) Possible values: - down : points away from bridge (MIPs are always down) - up : points towards bridge	Maintenance EndPoint direction <i>This element is always shown.</i>
mac	Parameter type: <Vlan::MacAddr> - mac address (aa:bb:cc:a1:02:03) - unit: Byte - length: 6	MAC address of the Maintenance End Point (MEP) <i>This element is always shown.</i>
slm-responder	Parameter type: <Cfm::MepSlmShowEnableDisable> (enabled disabled) Possible values: - enabled : slm responder is enabled on the current mep - disabled : slm responder is disabled on the current mep	status of slm responder on the current mep <i>This element is always shown.</i>
dm-responder	Parameter type: <Cfm::MepDmShowEnableDisable> (enabled disabled) Possible values: - enabled : dm responder is enabled on the current mep - disabled : dm responder is disabled on the current mep	status of dm responder on the current mep <i>This element is always shown.</i>
lm-responder	Parameter type: <Cfm::MepLmShowEnableDisable> (disabled enabled-per-vlan enabled-per-pbit) Possible values: - disabled : lm responder is disabled on the current mep - enabled-per-vlan : lm responder is enabled per vlan on the current mep - enabled-per-pbit : lm responder is enabled per vlan per pbit on the current mep	status of lm responder on the current mep <i>This element is always shown.</i>
slm-initiator	Parameter type: <Cfm::MepSlmInitShowEnableDisable> (enabled disabled) Possible values: - enabled : slm initiator is enabled on the current mep - disabled : slm initiator is disabled on the current mep	status of slm initiator on the current mep <i>This element is always shown.</i>
lm-initiator	Parameter type: <Cfm::MepLmInitShowEnableDisable> (disabled enabled-per-vlan enabled-per-pbit) Possible values: - disabled : lm initiator is disabled on the current mep - enabled-per-vlan : lm initiator is enabled per vlan on the current mep - enabled-per-pbit : lm initiator is enabled per vlan per pbit on the current mep	status of lm initiator on the current mep <i>This element is always shown.</i>

166.5 CFM Stack on NT Status Command

Command Description

This command displays CFM stack table entries by specifying any of the following: location (user bridgeport or slot), VLAN, MD level, and direction. The information displayed is for the associated MPs (MIPs and MEPs).

User Level

The command can be accessed by operators with alarm , oam , vlan privileges.

Command Syntax

The command has the following syntax:

```
> show cfm stack [ (location) [ equipment <Cfm::MepEquipmentType> ] [ vlan <Network::StackedVlan> ] [ level
<Cfm::MdLevelType> ] [ direction <Cfm::CfmDirectionType> ] ]
```

Command Parameters

Table 166.5-1 "CFM Stack on NT Status Command" Resource Parameters

Resource Identifier	Type	Description
(location)	Format: (user : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::VpiId> : <Eqpt::VciId> user : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> slot : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> user : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> / <Eqpt::OntPortId> user : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / voip user : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / vuni ng2 : <Ng2::ChannelGroup> / <Ng2::SubchannelGroup> / <Ng2::OntId> / <Eqpt::Ng2OntSlotId> / <Eqpt::Ng2OntPortId> ng2 : <Ng2::ChannelGroup> / <Ng2::SubchannelGroup> / <Ng2::OntId> / vuni) Possible values: - user : User bridge-port location - slot : slot location - ng2 : ngpon2 style identification Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId>	Maintenance Point (MEP or MIP) location

Resource Identifier	Type	Description
	- the LT slot number - Field type <Eqpt::PortId> - the port number - Field type <Eqpt::VpiId> - atm VPI - Field type <Eqpt::VciId> - atm VCI - Field type <Eqpt::PonId> - the PON identifier - Field type <Eqpt::OntId> - the ONT identifier - Field type <Ng2::ChannelGroup> - channel group number - Field type <Ng2::SubchannelGroup> - subchannel group number - Field type <Ng2::OntId> - the ONT identifier - Possible values: - voip : virtual uni identifier - obsolete alternative replaced by vuni - vuni : virtual uni identifier - Possible values: - vuni : virtual NGPON2 uni identifier - Field type <Eqpt::OntSlotId> - the ONT SLOT identifier - Field type <Eqpt::OntPortId> - the ONT PORT identifier - Field type <Eqpt::Ng2OntSlotId> - the NGPON2 ONT SLOT identifier - Field type <Eqpt::Ng2OntPortId> - the NGPON2 ONT PORT identifier	
equipment	Parameter type: <Cfm::MepEquipmentType> Format: (default olt onu) Possible values: - default : Gpon Onu or Dsl - olt : Gpon LT - onu : Gpon Onu	Mep equipment type
vlan	Parameter type: <Network::StackedVlan> Format: (<Network::UVlanIndex> stacked : <Network::SVlanIndex> : <Network::CVlanIndex>) Possible values: - stacked : stacked vlan identity Field type <Network::UVlanIndex> - unstacked vlan identity - range: [1...4093] Field type <Network::SVlanIndex> - service vlan identity - range: [2...4093] Field type <Network::CVlanIndex> - customer vlan identity - range: [0...4093]	VlanId associated with the MA
level	Parameter type: <Cfm::MdLevelType>	Maintenance Domain (MD) level

Resource Identifier	Type	Description
	Format: - Maintenance Domain (MD) level - range: [0...7]	
direction	Parameter type: <Cfm::CfmDirectionType> Format: (down up) Possible values: - down : points away from bridge (MIPs are always down) - up : points towards bridge	Maintenance Point (MEP or MIP) direction

Command Output

Table 166.5-2 "CFM Stack on NT Status Command" Display parameters

Specific Information		
name	Type	Description
domain-index	Parameter type: <Cfm::CfmDomainIndexType> - Maintenance Domain (MD) index - range: [1...4294967295]	Maintenance Domain (MD) index <i>This element is always shown.</i>
association-index	Parameter type: <Cfm::CfmMaIndexType> - Maintenance Association (MA) index. Unique within an MD - range: [1...4294967295]	Maintenance Association (MA) index <i>This element is always shown.</i>
mep-id	Parameter type: <Cfm::MepIdType> - MA End Point (MEP) ID. Unique within an MA - range: [0,1...8191,65535]	MEP Id or zero for MIP <i>This element is always shown.</i>
mac	Parameter type: <Vlan::MacAddr> - mac address (aa:bb:cc:a1:02:03) - unit: Byte - length: 6	MAC address of the location <i>This element is always shown.</i>

166.6 Maintenance Association End Point CCM Database show Command

Command Description

This command displays the Maintenance association End Point (MEP) CCM Database.

The CCM Database is maintained per Remote MEP and is identified by the combination of Maintenance Domain (MD) index, MA index , MEP ID and Remote MEP ID.

User Level

The command can be accessed by operators with alarm , oam , vlan privileges.

Command Syntax

The command has the following syntax:

```
> show cfm ccm-database domain [ (domain-index) [ association <Cfm::CfmMaIndexType> ] [ mep
<Cfm::MepIdType> ] [ remote-mep <Cfm::MepIdType> ] ]
```

Command Parameters

Table 166.6-1 "Maintenance Association End Point CCM Database show Command" Resource Parameters

Resource Identifier	Type	Description
(domain-index)	Format: - Maintenance Domain (MD) index - range: [1...4294967295]	Maintenance Domain (MD) index
association	Parameter type: <Cfm::CfmMaIndexType> Format: - Maintenance Association (MA) index. Unique within an MD - range: [1...4294967295]	Maintenance Association (MA) index
mep	Parameter type: <Cfm::MepIdType> Format: - MA End Point (MEP) ID. Unique within an MA - range: [1...8191]	Maintenance association End Point (MEP) ID
remote-mep	Parameter type: <Cfm::MepIdType> Format: - MA End Point (MEP) ID. Unique within an MA - range: [1...8191]	Remote Maintenance association End Point (MEP) ID

Command Output

Table 166.6-2 "Maintenance Association End Point CCM Database show Command" Display

parameters

Specific Information		
name	Type	Description
state	Parameter type: <Cfm::RemoteMepState> (rmep-idle rmep-start rmep-failed rmep-ok) Possible values: - rmep-idle : Remote MEP Idle State - rmep-start : Remote MEP Start State - rmep-failed : Remote MEP Failed State - rmep-ok : Remote MEP Ok State	Current state of the Remote MEP state machine <i>This element is always shown.</i>
failed-ok-time	Parameter type: <Cfm::ElapsedTime> - Time elapsed since last Ok or Failed RMEP received	Time at which the Remote MEP state machine entered either the rMepFailed or rMepOk state <i>This element is always shown.</i>
mac-addr	Parameter type: <Vlan::MacAddr> - mac address (aa:bb:cc:a1:02:03) - unit: Byte - length: 6	The MAC address of the remote MEP <i>This element is always shown.</i>
rdi	Parameter type: <Cfm::RemoteMepRdi> (rdi-set rdi-not-set) Possible values: - rdi-set : RDI bit is set - rdi-not-set : RDI bit is not set	State of the RDI bit in the last received CCM <i>This element is always shown.</i>
status	Parameter type: <Cfm::RemoteMepStatus> (rmep-active rmep-not-active) Possible values: - rmep-active : Remote MEP is active - rmep-not-active : Remote MEP is not active	Indicates whether the Remote MEP is active <i>This element is always shown.</i>
port-status	Parameter type: <Cfm::RemoteMepPortStatus> (ps-no-tlv ps-blocked ps-up) Possible values: - ps-no-tlv : No CCM received or No Port Status TLV present in the received CCM - ps-blocked : Port Status Blocked - ps-up : Port Status Up	An enumerated value of the Port status TLV received in the last CCM <i>This element is only shown in detail mode.</i>
interface-status	Parameter type: <Cfm::RemoteMepInterfaceStatus> (is-no-tlv is-up is-down is-testing is-unknown is-dormant is-not-present is-lower-layer-down) Possible values: - is-no-tlv : No CCM received or No Interface Status TLV present in the received CCM - is-up : Interface Status Up - is-down : Interface Status Down - is-testing : Interface Status Testing	An enumerated value of the Interface status TLV received in the last CCM <i>This element is only shown in detail mode.</i>

name	Type	Description
	- is-unknown : Interface Status Unknown - is-dormant : Interface Status Dormant - is-not-present : Interface Status Not Present - is-lower-layer-down : Interface Status Lower Layer Down	
chassis-id-format	Parameter type: <Cfm::LldpChassisIdSubtype> (not-applic chassis-component interface-alias port-component mac-address network-address interface-name local <SignedInteger>) Possible values: - not-applic : not applicable - chassis-component : Reference IETF RFC 2737 - interface-alias : Reference IETF RFC 2863 - port-component : Reference IETF RFC 2737 - mac-address : - network-address : - interface-name : Reference IETF RFC 2863 - local : An alph-numeric string. Field type <SignedInteger> - a signed integer	Format of the Chassis ID received in the last CCM <i>This element is only shown in detail mode.</i>
chassis-id	Parameter type: <Cfm::LldpChassisIdType> - a variable length octet string 0..16 - length: x<=16	The Chassis ID received in the last CCM <i>This element is only shown in detail mode.</i>
mgmt-addr-domain	Parameter type: <Object> - an object identifier	Identifies the type and format of the management address of the Remote MEP <i>This element is only shown in detail mode.</i>
mgmt-addr	Parameter type: <Cfm::MgmtAddrType> - a variable length octet string 0..50 - length: x<=50	The management address of the Remote MEP <i>This element is only shown in detail mode.</i>

166.7 Maintenance Association End Point on NT Runtime Info Command

Command Description

This command displays the Maintenance association End Point (MEP) runtime information.

A MEP is contained within a Maintenance Association (MA) and is identified by the combination of Maintenance Domain (MD) index, MA index and MEP ID.

User Level

The command can be accessed by operators with alarm , oam , vlan privileges.

Command Syntax

The command has the following syntax:

```
> show cfm mep-info domain [ (domain-index) [ association <Cfm::CfmMaIndexType> ] [ mep
<Cfm::MepIdType> ] ]
```

Command Parameters

Table 166.7-1 "Maintenance Association End Point on NT Runtime Info Command" Resource Parameters

Resource Identifier	Type	Description
(domain-index)	Format: - Maintenance Domain (MD) index - range: [1...4294967295]	Maintenance Domain (MD) index
association	Parameter type: <Cfm::CfmMaIndexType> Format: - Maintenance Association (MA) index. Unique within an MD - range: [1...4294967295]	Maintenance Association (MA) index
mep	Parameter type: <Cfm::MepIdType> Format: - MA End Point (MEP) ID. Unique within an MA - range: [1...8191]	Maintenance association End Point (MEP) ID

Command Output

Table 166.7-2 "Maintenance Association End Point on NT Runtime Info Command" Display parameters

Specific Information		
name	Type	Description
direction	Parameter type: <Cfm::CfmDirectionType>	Maintenance EndPoint direction

name	Type	Description
	(down up) Possible values: - down : points away from bridge (MIPs are always down) - up : points towards bridge	<i>This element is always shown.</i>
mac	Parameter type: <Vlan::MacAddr> - mac address (aa:bb:cc:a1:02:03) - unit: Byte - length: 6	MAC address of the Maintenance End Point (MEP) <i>This element is only shown in detail mode.</i>
cci-enable	Parameter type: <Cfm::MepCcmEnableDisable> (cci-enable cci-disable) Possible values: - cci-enable : Enable CCM generation on the current MEP - cci-disable : Disable CCM generation on the current MEP	Enable/Disable CCM generation on the current MEP <i>This element is only shown in detail mode.</i>
ccm-priority	Parameter type: <Cfm::MepCcmPriority> - Priority value for CCMs transmitted by the MEP - range: [0...7]	Priority value for CCMs transmitted by the MEP <i>This element is only shown in detail mode.</i>
ais-enable	Parameter type: <Cfm::MepAisEnableDisable> (ais-enable ais-disable) Possible values: - ais-enable : AIS generation is enabled on the current MEP - ais-disable : AIS generation is disabled on the current MEP	Enable/Disable AIS generation on the current MEP <i>This element is only shown in detail mode.</i>
ais-meg-level	Parameter type: <Cfm::MepAisMegLevel> - Meg Level for AIS frames transmitted by the MEP - range: [0...7]	AIS meg level by the MEP <i>This element is only shown in detail mode.</i>
ais-period	Parameter type: <Cfm::MepAisPeriod> - Period of the AIS frames transmitted by the MEP, 0 (per second), 1 (per minute) - range: [0...1]	AIS period by the MEP <i>This element is only shown in detail mode.</i>
ais-priority	Parameter type: <Cfm::MepAisPriority> - Priority value for AIS frames transmitted by the MEP - range: [0...7]	AIS priority by the MEP <i>This element is only shown in detail mode.</i>
equipment	Parameter type: <Cfm::MepEquipmentType> (default olt onu) Possible values: - default : Gpon Onu or Dsl - olt : Gpon LT - onu : Gpon Onu	Mep equipment <i>This element is only shown in detail mode.</i>
ais-autoshut	Parameter type: <Cfm::MepAisAutoShut> (portshut-enable portshut-disable) Possible values: - portshut-enable : shutdown enabled on the current MEP - portshut-disable : shutdown disabled on the current MEP	Shutdown the BP port or not <i>This element is only shown in detail mode.</i>
low-pri-defect	Parameter type: <Cfm::MepLowPriorityDefect> (all-def mac-rem-err-xcon rem-err-xcon err-xcon xcon no-xcon) Possible values:	The lowest priority defect that is allowed to generate fault alarm <i>This element is only shown in detail mode.</i>

name	Type	Description
	- all-def : For DefRDICCM, DefMACstatus, DefRemoteCCM, DefErrorCCM, and DefXconCCM - mac-rem-err-xcon : Only DefMACstatus, DefRemoteCCM, DefErrorCCM, and DefXconCCM (default) - rem-err-xcon : Only DefRemoteCCM, DefErrorCCM, and DefXconCCM - err-xcon : Only DefErrorCCM and DefXconCCM - xcon : Only DefXconCCM - no-xcon : No defects DefXcon or lower are to be reported	
fng-state	Parameter type: <Cfm::FngState> (fng-reset fng-defect fng-report-defect fng-defect-reported fng-defect-clearing) Possible values: - fng-reset : No defect has been present since the dot1agCfmMepFngResetTime timer expired, or since the state machine was last reset - fng-defect : A defect is present, but not for a long enough time to be reported (dot1agCfmMepFngAlarmTime) - fng-report-defect : A momentary state during which the defect is reported by sending a dot1agCfmFaultAlarm notification, if that action is enabled - fng-defect-reported : A defect is present, and some defect has been reported - fng-defect-clearing : No defect is present, but the dot1agCfmMepFngResetTime timer has not yet expired	Current state of the MEP Fault Notification Generator State Machine <i>This element is always shown.</i>
highest-pri-defect	Parameter type: <Cfm::MepHighestPrDefect> (none def-rdi-ccm def-mac-status def-remote-ccm def-error-ccm def-xcon-ccm) Possible values: - none : No defects since FNG_RESET - def-rdi-ccm : A remote MEP has reported the RDI bit in its last CCM - def-mac-status : Either some remote MEP is reporting its Interface Status TLV as not isUp, or all remote MEPs are reporting a Port Status TLV that contains some value other than psUp - def-remote-ccm : The MEP is not receiving valid CCMs from at least one of the remote MEPs - def-error-ccm : The MEP has received at least one invalid CCM whose CCM Interval has not yet timed out - def-xcon-ccm : The MEP has received at least one CCM from either another MAID or a lower MD Level whose CCM Interval has not yet timed out	The highest priority defect that has been present since the MEPs Fault Notification Generator State Machine was last in the FNG_RESET state <i>This element is always shown.</i>
def-rdi-ccm	Parameter type: <Cfm::MepDefectRDICCM> (not-present present) Possible values: - not-present : DefRDICCM is not present - present : DefRDICCM is present	Status of the RDICCM defect for this MEP <i>This element is only shown in detail mode.</i>

name	Type	Description
def-mac-status	Parameter type: <Cfm::MepDefectMACstatus> (not-present present) Possible values: - not-present : DefMACstatus is not present - present : DefMACstatus is present	Status of the MACstatus defect for this MEP <i>This element is only shown in detail mode.</i>
def-remote-ccm	Parameter type: <Cfm::MepDefectRemoteCCM> (not-present present) Possible values: - not-present : DefRemoteCCM is not present - present : DefRemoteCCM is present	Status of the RemoteCCM defect for this MEP <i>This element is only shown in detail mode.</i>
def-error-ccm	Parameter type: <Cfm::MepDefectErrorCCM> (not-present present) Possible values: - not-present : DefErrorCCM is not present - present : DefErrorCCM is present	Status of the ErrorCCM defect for this MEP <i>This element is only shown in detail mode.</i>
def-xcon-ccm	Parameter type: <Cfm::MepDefectXconCCM> (not-present present) Possible values: - not-present : DefXconCCM is not present - present : DefXconCCM is present	Status of the XconCCM defect for this MEP <i>This element is only shown in detail mode.</i>
sent-ccms	Parameter type: <Cfm::UnsignedIntType> - Unsigned Integer. - range: [0...4294967295]	Total number of Continuity Check messages transmitted <i>This element is always shown.</i>
ccm-sequence-errors	Parameter type: <Cfm::UnsignedIntType> - Unsigned Integer. - range: [0...4294967295]	The total number of out-of-sequence CCMs received from all remote MEPs <i>This element is always shown.</i>
error-ccm-last-frame	Parameter type: <Cfm::CCmErrorFrame> - CCM Error Packet information	The last-received CCM that triggered an DefErrorCCM fault <i>This element is only shown in detail mode.</i>
xcon-ccm-last-frame	Parameter type: <Cfm::CCmErrorFrame> - CCM Error Packet information	The last-received CCM that triggered a DefXconCCM fault <i>This element is only shown in detail mode.</i>

166.8 LT CFM SLM Responder Statistics Table

Command Description

This command displays the CFM SLM Responder Statistics.

The SLM Responder Statistics Table is maintained per Test Instance basis and is identified by the combination of Maintenance Domain (MD) index, MA index , MEP ID ,RespRemoteMep Id , RespRemoteMep TestId and RespRemoteMep Mac address.

User Level

The command can be accessed by operators with alarm , oam , vlan privileges.

Command Syntax

The command has the following syntax:

```
> show cfm slm-responder-stats domain [ (domain-index) [ association <Cfm::CfmMaIndexType> ] [ mep
<Cfm::MepIdType> ] [ slm-initiator-mep <Cfm::MepIdType> ] [ slm-initiator-mac <Vlan::MacAddr> ] [ test-id
<Cfm::UnsignedIntType> ] ]
```

Command Parameters

Table 166.8-1 "LT CFM SLM Responder Statistics Table" Resource Parameters

Resource Identifier	Type	Description
(domain-index)	Format: - Maintenance Domain (MD) index - range: [1...4294967295]	Maintenance Domain (MD) index
association	Parameter type: <Cfm::CfmMaIndexType> Format: - Maintenance Association (MA) index. Unique within an MD - range: [1...4294967295]	Maintenance Association (MA) index
mep	Parameter type: <Cfm::MepIdType> Format: - MA End Point (MEP) ID. Unique within an MA - range: [1...8191]	Maintenance association End Point (MEP) ID
slm-initiator-mep	Parameter type: <Cfm::MepIdType> Format: - MA End Point (MEP) ID. Unique within an MA - range: [1...8191]	Responder Remote Maintenance association End Point (MEP) ID
slm-initiator-mac	Parameter type: <Vlan::MacAddr> Format: - mac address (aa:bb:cc:a1:02:03) - unit: Byte - length: 6	MAC address of the remote MEP which initiated the SLM
test-id	Parameter type: <Cfm::UnsignedIntType> Format:	Test identifier in the SLM message sent by the remote MEP

Resource Identifier	Type	Description
	- Unsigned Integer. - range: [0...4294967295]	

Command Output

Table 166.8-2 "LT CFM SLM Responder Statistics Table" Display parameters

Specific Information		
name	Type	Description
txfcf	Parameter type: <Cfm::UnsignedIntType> - Unsigned Integer. - range: [0...4294967295]	The number of synthetic frames(SLM) transmitted by the SLM initiator as part of a given test ID.The value is obtained from the SLM packet sent by the initiator <i>This element is always shown.</i>
txfcb	Parameter type: <Cfm::UnsignedIntType> - Unsigned Integer. - range: [0...4294967295]	The number of synthetic frames(SLR) transmitted by the SLM responder as part of a given test ID.The value is a local counter maintained by the responder <i>This element is always shown.</i>

166.9 PM proactive show

Command Description

This command is used to show the PM test results.

User Level

The command can be accessed by operators with alarm , oam , vlan privileges.

Command Syntax

The command has the following syntax:

```
> show cfm y1731pm
```

166.10 Proactive CFM PM show command for the current 15 min

Command Description

This command displays the PM proactive loss measurement for the current 15 min.

User Level

The command can be accessed by operators with alarm , oam , vlan privileges.

Command Syntax

The command has the following syntax:

```
> show cfm y1731pm curr-15min-stats
```

166.11 Proactive CFM PM show command for the current 15 min

Command Description

This command displays the PM proactive loss measurement for the current 15 min.

User Level

The command can be accessed by operators with alarm , oam , vlan privileges.

Command Syntax

The command has the following syntax:

```
> show cfm y1731pm curr-15min-stats domain [ (domain-index) [ association <Cfm::CfmMaIndexType> ] [ mep
<Cfm::MepIdType> ] [ session-id <Cfm::SessionIdType> ] ]
```

Command Parameters

Table 166.11-1 "Proactive CFM PM show command for the current 15 min" Resource Parameters

Resource Identifier	Type	Description
(domain-index)	Format: - Maintenance Domain (MD) index - range: [1...4294967295]	Maintenance domain.
association	Parameter type: <Cfm::CfmMaIndexType> Format: - Maintenance Association (MA) index. Unique within an MD - range: [1...4294967295]	Maintenance association.
mep	Parameter type: <Cfm::MepIdType> Format: - MA End Point (MEP) ID. Unique within an MA - range: [1...8191]	Maintenance End Point.
session-id	Parameter type: <Cfm::SessionIdType> Format: - Session Id for PM proactive - range: [1...3600]	PM Proactive test SessionId.

Command Output

Table 166.11-2 "Proactive CFM PM show command for the current 15 min" Display parameters

Specific Information		
name	Type	Description
test-type	Parameter type: <Cfm::PmTestType>	Y1731 PM Test type

name	Type	Description
	(single-ended-slm single-ended-lm) Possible values: - single-ended-slm : sets test type to SLM - single-ended-lm : sets test type to LM	<i>This element is only shown in detail mode.</i>
interval(sec)	Parameter type: <Cfm::PmIntervalType> - PM interval (sec) SLM: [1...10] LM: [60 or 300] - range: [1...10,60,300]	Interval in which PM packets are transmitted. <i>This element is only shown in detail mode.</i>
measurement-intvl(sec)	Parameter type: <Cfm::PmMeasurementIntervalType> (not-applicable <Cfm::PmMeasurementInterval>) Possible values: - not-applicable : For single-ended-lm, the value of this object is not-applicable Field type <Cfm::PmMeasurementInterval> - Measurement interval - unit: seconds - range: [60,300]	The time for which the synthetic loss calculation is made periodically. <i>This element is only shown in detail mode.</i>
dest-mac	Parameter type: <Vlan::MacAddr> - mac address (aa:bb:cc:a1:02:03) - unit: Byte - length: 6	MAC address of the PM responder(Target). <i>This element is only shown in detail mode.</i>
elapsed-time(sec)	Parameter type: <Cfm::PmCurr15MinTimeElapsedType> - Elapsed time - unit: seconds	Time elapsed since the start of the PM proactive test <i>This element is only shown in detail mode.</i>
measured-time(sec)	Parameter type: <Cfm::Pm15MinTimeMeasuredType> - Measured time - unit: seconds	Time measured since the start of the PM proactive test <i>This element is only shown in detail mode.</i>
data-tlv-size	Parameter type: <Cfm::PmDataSizeType> (not-applicable <Cfm::PmDataSize>) Possible values: - not-applicable : For single-ended-lm, the value of this object is not-applicable Field type <Cfm::PmDataSize> - Datasize for the SLM proactive test - range: [0...1500]	Data size of the SLM proactive test <i>This element is only shown in detail mode.</i>
priority	Parameter type: <Vlan::Priority> - priority of ethernet frames - range: [0...7]	Vlan Priority for PM proactive messages being transmitted <i>This element is only shown in detail mode.</i>
valid-intervals	Parameter type: <Cfm::PmCurr15MinValidIntervalsType> - The number of previous 15 min intervals for which valid data was collected for this test. - range: [0...96]	The number of previous 15 min intervals for which valid data was collected for this test. <i>This element is only shown in detail mode.</i>
invalid-data-flag	Parameter type: <Cfm::PmInvalidDataFlagType> - Indicates the validity of the corresponding PM data. - range: [0...1]	Indicates the validity of the corresponding PM data. It is set to 1 when the PM data is incomplete or invalid and set to 0 when the PM data is complete and valid. <i>This element is only shown in detail mode.</i>
pdu-sent	Parameter type: <Counter>	Number of Y1731 PM PDUs sent

166 CFM Status Commands

name	Type	Description
	- 32 bit counter	by this MEP in the current 15 minutes <i>This element is only shown in detail mode.</i>
pdu-rcvd	Parameter type: <Counter> - 32 bit counter	Number of Y1731 PM PDUs received by this MEP in the current 15 minutes <i>This element is only shown in detail mode.</i>
pdu-discarded	Parameter type: <Counter> - 32 bit counter	Number of Y1731 PM PDUs discarded by this MEP in the current 15 minutes <i>This element is only shown in detail mode.</i>
test-id	Parameter type: <Cfm::PmTestIdType> (not-applicable <Cfm::PmTestId>) Possible values: - not-applicable : For single-ended-lm, the value of this object is not-applicable Field type <Cfm::PmTestId> - Test Id for PM proactive - range: [1...65535]	PM Proactive test Id. <i>This element is only shown in detail mode.</i>
remote-mep	Parameter type: <Cfm::PmMepIdType> (unavailable not-applicable <Cfm::MepId>) Possible values: - unavailable : No SLR received yet - not-applicable : For single-ended-lm, the value of this object is not-applicable Field type <Cfm::MepId> - MA End Point (MEP) ID. Unique within an MA - range: [1...8191]	Responder Maintenance Association End Point. <i>This element is only shown in detail mode.</i>

Only Show Details: loss calculation		
name	Type	Description
total-tx-near	Parameter type: <Cfm::Pm8byteOctetType> - Pdu count	Total no of PM proactive messages TXed in the near-end <i>This element is only shown in detail mode.</i>
total-tx-far	Parameter type: <Cfm::Pm8byteOctetType> - Pdu count	Total no of PM proactive messages TXed in the far end <i>This element is only shown in detail mode.</i>
total-rx-near	Parameter type: <Cfm::Pm8byteOctetType> - Pdu count	Total no of PM proactive messages RXed in the near-end <i>This element is only shown in detail mode.</i>
total-rx-far	Parameter type: <Cfm::Pm8byteOctetType> - Pdu count	Total no of PM proactive messages RXed in the far-end <i>This element is only shown in detail mode.</i>
loss-near	Parameter type: <Cfm::Pm8byteOctetType> - Pdu count	Total loss of PM proactive messages in the near-end <i>This element is only shown in detail mode.</i>
loss-far	Parameter type: <Cfm::Pm8byteOctetType>	Total loss of PM proactive

name	Type	Description
	- Pdu count	messages in the far-end <i>This element is only shown in detail mode.</i>
un-ack	Parameter type: <Cfm::Pm8byteOctetWithNAType> (not-applicable <Cfm::Pm8byteOctet>) Possible values: - not-applicable : For single-ended-lm, the value of this object is not-applicable Field type <Cfm::Pm8byteOctet> - Pdu count	Total number of SLM frames that are unacknowledged <i>This element is only shown in detail mode.</i>

Only Show Details: frame loss ratio - near end		
name	Type	Description
flr-min-near	Parameter type: <Cfm::PmPercentageType> (invalid <Cfm::PmPercentage>) Possible values: - invalid : Negative Loss ratio or Loss ratio more than 100 percent Field type <Cfm::PmPercentage> - Frame loss ratio in percentage - unit: percentage - range: [0.00...100.00,655.35]	Frame loss ratio(in %) minimum in the near end <i>This element is only shown in detail mode.</i>
flr-avg-near	Parameter type: <Cfm::PmPercentageType> (invalid <Cfm::PmPercentage>) Possible values: - invalid : Negative Loss ratio or Loss ratio more than 100 percent Field type <Cfm::PmPercentage> - Frame loss ratio in percentage - unit: percentage - range: [0.00...100.00,655.35]	The average of accumulated Frame Loss Ratio (%) within the test duration of 15 minutes. <i>This element is only shown in detail mode.</i>
flr-max-near	Parameter type: <Cfm::PmPercentageType> (invalid <Cfm::PmPercentage>) Possible values: - invalid : Negative Loss ratio or Loss ratio more than 100 percent Field type <Cfm::PmPercentage> - Frame loss ratio in percentage - unit: percentage - range: [0.00...100.00,655.35]	Frame loss ratio(in %) maximum in the near end <i>This element is only shown in detail mode.</i>

Only Show Details: frame loss ratio - far end		
name	Type	Description
flr-min-far	Parameter type: <Cfm::PmPercentageType> (invalid <Cfm::PmPercentage>) Possible values: - invalid : Negative Loss ratio or Loss ratio more than 100 percent Field type <Cfm::PmPercentage> - Frame loss ratio in percentage - unit: percentage - range: [0.00...100.00,655.35]	Frame loss ratio(in %) minimum in the far end <i>This element is only shown in detail mode.</i>
flr-avg-far	Parameter type: <Cfm::PmPercentageType>	The average of accumulated

166 CFM Status Commands

name	Type	Description
	(invalid <Cfm::PmPercentage>) Possible values: - invalid : Negative Loss ratio or Loss ratio more than 100 percent Field type <Cfm::PmPercentage> - Frame loss ratio in percentage - unit: percentage - range: [0.00...100.00,655.35]	Frame Loss Ratio (%) within the test duration of 15 minutes. <i>This element is only shown in detail mode.</i>
flr-max-far	Parameter type: <Cfm::PmPercentageType> (invalid <Cfm::PmPercentage>) Possible values: - invalid : Negative Loss ratio or Loss ratio more than 100 percent Field type <Cfm::PmPercentage> - Frame loss ratio in percentage - unit: percentage - range: [0.00...100.00,655.35]	Frame loss ratio(in %) maximum in the far end <i>This element is only shown in detail mode.</i>

166.12 Proactive CFM PM show command for the current 1 day

Command Description

This command displays the PM Proactive loss measurement for the current day.

User Level

The command can be accessed by operators with alarm , oam , vlan privileges.

Command Syntax

The command has the following syntax:

```
> show cfm y1731pm curr-day-stats
```

166.13 Proactive CFM PM show command for the current 1 day

Command Description

This command displays the PM Proactive loss measurement for the current day.

User Level

The command can be accessed by operators with alarm , oam , vlan privileges.

Command Syntax

The command has the following syntax:

```
> show cfm y1731pm curr-day-stats domain [ (domain-index) [ association <Cfm::CfmMaIndexType> ] [ mep <Cfm::MepIdType> ] [ session-id <Cfm::SessionIdType> ] ]
```

Command Parameters

Table 166.13-1 "Proactive CFM PM show command for the current 1 day" Resource Parameters

Resource Identifier	Type	Description
(domain-index)	Format: - Maintenance Domain (MD) index - range: [1...4294967295]	Maintenance domain.
association	Parameter type: <Cfm::CfmMaIndexType> Format: - Maintenance Association (MA) index. Unique within an MD - range: [1...4294967295]	Maintenance association.
mep	Parameter type: <Cfm::MepIdType> Format: - MA End Point (MEP) ID. Unique within an MA - range: [1...8191]	Maintenance End Point.
session-id	Parameter type: <Cfm::SessionIdType> Format: - Session Id for PM proactive - range: [1...3600]	PM Proactive test SessionId.

Command Output

Table 166.13-2 "Proactive CFM PM show command for the current 1 day" Display parameters

Specific Information		
name	Type	Description
test-type	Parameter type: <Cfm::PmTestType>	Y1731 PM Test type

name	Type	Description
	(single-ended-slm single-ended-lm) Possible values: - single-ended-slm : sets test type to SLM - single-ended-lm : sets test type to LM	<i>This element is only shown in detail mode.</i>
interval(sec)	Parameter type: <Cfm::PmIntervalType> - PM interval (sec) SLM: [1...10] LM: [60 or 300] - range: [1...10,60,300]	Interval in which PM packets are transmitted. <i>This element is only shown in detail mode.</i>
measurement-intvl(sec)	Parameter type: <Cfm::PmMeasurementIntervalType> (not-applicable <Cfm::PmMeasurementInterval>) Possible values: - not-applicable : For single-ended-lm, the value of this object is not-applicable Field type <Cfm::PmMeasurementInterval> - Measurement interval - unit: seconds - range: [60,300]	The time for which the synthetic loss calculation is made periodically. <i>This element is only shown in detail mode.</i>
dest-mac	Parameter type: <Vlan::MacAddr> - mac address (aa:bb:cc:a1:02:03) - unit: Byte - length: 6	MAC address of the PM responder(Target). <i>This element is only shown in detail mode.</i>
elapsed-time(sec)	Parameter type: <Cfm::PmCurr1DayTimeElapsedType> - Elapsed time - unit: seconds	Time elapsed since the start of the PM proactive test <i>This element is only shown in detail mode.</i>
measured-time(sec)	Parameter type: <Cfm::Pm1DayTimeMeasuredType> - Measured time - unit: seconds	Time measured since the start of the PM proactive test <i>This element is only shown in detail mode.</i>
data-tlv-size	Parameter type: <Cfm::PmDataSizeType> (not-applicable <Cfm::PmDataSize>) Possible values: - not-applicable : For single-ended-lm, the value of this object is not-applicable Field type <Cfm::PmDataSize> - Datasize for the SLM proactive test - range: [0...1500]	Datasize for the SLM proactive test <i>This element is only shown in detail mode.</i>
priority	Parameter type: <Vlan::Priority> - priority of ethernet frames - range: [0...7]	Vlan Priority for PM proactive messages being transmitted <i>This element is only shown in detail mode.</i>
valid-intervals	Parameter type: <Cfm::PmCurr1DayValidIntervalsType> - The number of previous 1 Day intervals for which valid data was collected for this test. - range: [0...7]	The number of previous 1 Day intervals for which valid data was collected for this test. <i>This element is only shown in detail mode.</i>
invalid-data-flag	Parameter type: <Cfm::PmInvalidDataFlagType> - Indicates the validity of the corresponding PM data. - range: [0...1]	Indicates the validity of the corresponding PM data. It is set to 1 when the PM data is incomplete or invalid and set to 0 when the PM data is complete and valid. <i>This element is only shown in detail mode.</i>
pdu-sent	Parameter type: <Counter>	Number of PM Y1731 PDUs sent

166 CFM Status Commands

name	Type	Description
	- 32 bit counter	by this MEP in the current 1Day <i>This element is only shown in detail mode.</i>
pdu-rcvd	Parameter type: <Counter> - 32 bit counter	Number of PM Y1731 PDUs received by this MEP in the current 1Day <i>This element is only shown in detail mode.</i>
pdu-discarded	Parameter type: <Counter> - 32 bit counter	Number of PM Y1731 PDUs discarded by this MEP in the current 1Day <i>This element is only shown in detail mode.</i>
test-id	Parameter type: <Cfm::PmTestIdType> (not-applicable <Cfm::PmTestId>) Possible values: - not-applicable : For single-ended-lm, the value of this object is not-applicable Field type <Cfm::PmTestId> - Test Id for PM proactive - range: [1...65535]	PM Proactive test Id. <i>This element is only shown in detail mode.</i>
remote-mep	Parameter type: <Cfm::PmMepIdType> (unavailable not-applicable <Cfm::MepId>) Possible values: - unavailable : No SLR received yet - not-applicable : For single-ended-lm, the value of this object is not-applicable Field type <Cfm::MepId> - MA End Point (MEP) ID. Unique within an MA - range: [1...8191]	Remote Maintenance Association End Point <i>This element is only shown in detail mode.</i>

Only Show Details: loss calculation		
name	Type	Description
total-tx-near	Parameter type: <Cfm::Pm8byteOctetType> - Pdu count	Total no of PM proactive messages TXed in the near-end <i>This element is only shown in detail mode.</i>
total-tx-far	Parameter type: <Cfm::Pm8byteOctetType> - Pdu count	Total no of PM proactive messages TXed in the far end <i>This element is only shown in detail mode.</i>
total-rx-near	Parameter type: <Cfm::Pm8byteOctetType> - Pdu count	Total no of PM proactive messages RXed in the near-end <i>This element is only shown in detail mode.</i>
total-rx-far	Parameter type: <Cfm::Pm8byteOctetType> - Pdu count	Total no of PM proactive messages RXed in the far-end <i>This element is only shown in detail mode.</i>
loss-near	Parameter type: <Cfm::Pm8byteOctetType> - Pdu count	Total loss of PM proactive messages in the near-end <i>This element is only shown in detail mode.</i>
loss-far	Parameter type: <Cfm::Pm8byteOctetType> - Pdu count	Total loss of PM proactive messages in the far-end

name	Type	Description
		<i>This element is only shown in detail mode.</i>
un-ack	Parameter type: <Cfm::Pm8byteOctetWithNAType> (not-applicable <Cfm::Pm8byteOctet>) Possible values: - not-applicable : For single-ended-lm, the value of this object is not-applicable Field type <Cfm::Pm8byteOctet> - Pdu count	Total number of SLM frames that are unacknowledged <i>This element is only shown in detail mode.</i>

Only Show Details: frame loss ratio - near end		
name	Type	Description
flr-min-near	Parameter type: <Cfm::PmPercentageType> (invalid <Cfm::PmPercentage>) Possible values: - invalid : Negative Loss ratio or Loss ratio more than 100 percent Field type <Cfm::PmPercentage> - Frame loss ratio in percentage - unit: percentage - range: [0.00...100.00,655.35]	Frame loss ratio(in %) minimum in the near end <i>This element is only shown in detail mode.</i>
flr-avg-near	Parameter type: <Cfm::PmPercentageType> (invalid <Cfm::PmPercentage>) Possible values: - invalid : Negative Loss ratio or Loss ratio more than 100 percent Field type <Cfm::PmPercentage> - Frame loss ratio in percentage - unit: percentage - range: [0.00...100.00,655.35]	The average of accumulated Frame Loss Ratio (%) within the test duration of 1 Day. <i>This element is only shown in detail mode.</i>
flr-max-near	Parameter type: <Cfm::PmPercentageType> (invalid <Cfm::PmPercentage>) Possible values: - invalid : Negative Loss ratio or Loss ratio more than 100 percent Field type <Cfm::PmPercentage> - Frame loss ratio in percentage - unit: percentage - range: [0.00...100.00,655.35]	Frame loss ratio(in %) maximum in the near end <i>This element is only shown in detail mode.</i>

Only Show Details: frame loss ratio - far end		
name	Type	Description
flr-min-far	Parameter type: <Cfm::PmPercentageType> (invalid <Cfm::PmPercentage>) Possible values: - invalid : Negative Loss ratio or Loss ratio more than 100 percent Field type <Cfm::PmPercentage> - Frame loss ratio in percentage - unit: percentage - range: [0.00...100.00,655.35]	Frame loss ratio(in %) minimum in the far end <i>This element is only shown in detail mode.</i>
flr-avg-far	Parameter type: <Cfm::PmPercentageType> (invalid	The average of accumulated Frame Loss Ratio (%) within the

166 CFM Status Commands

name	Type	Description
	<Cfm::PmPercentage>) Possible values: - invalid : Negative Loss ratio or Loss ratio more than 100 percent Field type <Cfm::PmPercentage> - Frame loss ratio in percentage - unit: percentage - range: [0.00...100.00,655.35]	test duration of 1 Day. <i>This element is only shown in detail mode.</i>
flr-max-far	Parameter type: <Cfm::PmPercentageType> (invalid <Cfm::PmPercentage>) Possible values: - invalid : Negative Loss ratio or Loss ratio more than 100 percent Field type <Cfm::PmPercentage> - Frame loss ratio in percentage - unit: percentage - range: [0.00...100.00,655.35]	Frame loss ratio(in %) maximum in the far end <i>This element is only shown in detail mode.</i>

166.14 Proactive CFM PM show command for the previous 15 min

Command Description

This command displays the PM proactive loss measurement for the previous 15 min.

User Level

The command can be accessed by operators with alarm , oam , vlan privileges.

Command Syntax

The command has the following syntax:

```
> show cfm y1731pm prev-15min-stats
```

166.15 Proactive CFM PM show command for the previous 15 min

Command Description

This command displays the PM proactive loss measurement for the previous 15 min.

User Level

The command can be accessed by operators with alarm , oam , vlan privileges.

Command Syntax

The command has the following syntax:

```
> show cfm y1731pm prev-15min-stats domain [ (domain-index) [ association <Cfm::CfmMaIndexType> ] [ mep
<Cfm::MepIdType> ] [ session-id <Cfm::SessionIdType> ] [ interval-number
<Cfm::PmPrevious15MinIntervalNumberType> ] ]
```

Command Parameters

Table 166.15-1 "Proactive CFM PM show command for the previous 15 min" Resource Parameters

Resource Identifier	Type	Description
(domain-index)	Format: - Maintenance Domain (MD) index - range: [1...4294967295]	Maintenance domain.
association	Parameter type: <Cfm::CfmMaIndexType> Format: - Maintenance Association (MA) index. Unique within an MD - range: [1...4294967295]	Maintenance association.
mep	Parameter type: <Cfm::MepIdType> Format: - MA End Point (MEP) ID. Unique within an MA - range: [1...8191]	Maintenance End Point.
session-id	Parameter type: <Cfm::SessionIdType> Format: - Session Id for PM proactive - range: [1...3600]	PM Proactive test SessionId.
interval-number	Parameter type: <Cfm::PmPrevious15MinIntervalNumberType> Format: - Previous 15 min interval number - range: [1...96]	PM Proactive Previous 15 min interval number.

Command Output

Table 166.15-2 "Proactive CFM PM show command for the previous 15 min" Display parameters

Specific Information		
name	Type	Description
test-type	Parameter type: <Cfm::PmTestType> (single-ended-slm single-ended-lm) Possible values: - single-ended-slm : sets test type to SLM - single-ended-lm : sets test type to LM	Y1731 PM Test type <i>This element is only shown in detail mode.</i>
interval(sec)	Parameter type: <Cfm::PmIntervalType> - PM interval (sec) SLM: [1...10] LM: [60 or 300] - range: [1...10,60,300]	Interval in which PM packets are transmitted. <i>This element is only shown in detail mode.</i>
measurement-intvl(sec)	Parameter type: <Cfm::PmMeasurementIntervalType> (not-applicable <Cfm::PmMeasurementInterval>) Possible values: - not-applicable : For single-ended-lm, the value of this object is not-applicable Field type <Cfm::PmMeasurementInterval> - Measurement interval - unit: seconds - range: [60,300]	The time for which the synthetic loss calculation is made periodically. <i>This element is only shown in detail mode.</i>
dest-mac	Parameter type: <Vlan::MacAddr> - mac address (aa:bb:cc:a1:02:03) - unit: Byte - length: 6	MAC address of the PM responder(Target). <i>This element is only shown in detail mode.</i>
measured-time(sec)	Parameter type: <Cfm::Pm15MinTimeMeasuredType> - Measured time - unit: seconds	Time measured since the start of the PM proactive test <i>This element is only shown in detail mode.</i>
data-tlv-size	Parameter type: <Cfm::PmDataSizeType> (not-applicable <Cfm::PmDataSize>) Possible values: - not-applicable : For single-ended-lm, the value of this object is not-applicable Field type <Cfm::PmDataSize> - Datasize for the SLM proactive test - range: [0...1500]	Data size of the SLM proactive test <i>This element is only shown in detail mode.</i>
priority	Parameter type: <Vlan::Priority> - priority of ethernet frames - range: [0...7]	Vlan Priority for PM proactive messages being transmitted <i>This element is only shown in detail mode.</i>
invalid-data-flag	Parameter type: <Cfm::PmInvalidDataFlagType> - Indicates the validity of the corresponding PM data. - range: [0...1]	Indicates the validity of the corresponding PM data. It is set to 1 when the PM data is incomplete or invalid and set to 0 when the PM data is complete and valid. <i>This element is only shown in detail mode.</i>
pdu-sent	Parameter type: <Counter> - 32 bit counter	Number of Y1731 PM PDUs sent by this MEP in the previous 15 minutes <i>This element is only shown in detail mode.</i>
pdu-rcvd	Parameter type: <Counter>	Number of Y1731 PM PDUs

166 CFM Status Commands

name	Type	Description
	- 32 bit counter	received by this MEP in the previous 15 minutes <i>This element is only shown in detail mode.</i>
pdu-discarded	Parameter type: <Counter> - 32 bit counter	Number of Y1731 PM PDUs discarded by this MEP in the previous 15 minutes <i>This element is only shown in detail mode.</i>
test-id	Parameter type: <Cfm::PmTestIdType> (not-applicable <Cfm::PmTestId>) Possible values: - not-applicable : For single-ended-lm, the value of this object is not-applicable Field type <Cfm::PmTestId> - Test Id for PM proactive - range: [1...65535]	PM Proactive test Id. <i>This element is only shown in detail mode.</i>
remote-mep	Parameter type: <Cfm::PmMepIdType> (unavailable not-applicable <Cfm::MepId>) Possible values: - unavailable : No SLR received yet - not-applicable : For single-ended-lm, the value of this object is not-applicable Field type <Cfm::MepId> - MA End Point (MEP) ID. Unique within an MA - range: [1...8191]	Remote Maintenance Association End Point. <i>This element is only shown in detail mode.</i>

Only Show Details: loss calculation		
name	Type	Description
total-tx-near	Parameter type: <Cfm::Pm8byteOctetType> - Pdu count	Total no of PM proactive messages TXed in the near-end <i>This element is only shown in detail mode.</i>
total-tx-far	Parameter type: <Cfm::Pm8byteOctetType> - Pdu count	Total no of PM proactive messages TXed in the far end <i>This element is only shown in detail mode.</i>
total-rx-near	Parameter type: <Cfm::Pm8byteOctetType> - Pdu count	Total no of PM proactive messages RXed in the near-end <i>This element is only shown in detail mode.</i>
total-rx-far	Parameter type: <Cfm::Pm8byteOctetType> - Pdu count	Total no of PM proactive messages RXed in the far-end <i>This element is only shown in detail mode.</i>
loss-near	Parameter type: <Cfm::Pm8byteOctetType> - Pdu count	Total loss of PM proactive messages in the near-end <i>This element is only shown in detail mode.</i>
loss-far	Parameter type: <Cfm::Pm8byteOctetType> - Pdu count	Total loss of PM proactive messages in the far-end <i>This element is only shown in detail mode.</i>
un-ack	Parameter type: <Cfm::Pm8byteOctetWithNAType> (not-applicable	Total number of SLM frames that are unacknowledged

name	Type	Description
	<Cfm::Pm8byteOctet>) Possible values: - not-applicable : For single-ended-lm, the value of this object is not-applicable Field type <Cfm::Pm8byteOctet> - Pdu count	<i>This element is only shown in detail mode.</i>

Only Show Details: frame loss ratio - near end		
name	Type	Description
flr-min-near	Parameter type: <Cfm::PmPercentageType> (invalid <Cfm::PmPercentage>) Possible values: - invalid : Negative Loss ratio or Loss ratio more than 100 percent Field type <Cfm::PmPercentage> - Frame loss ratio in percentage - unit: percentage - range: [0.00...100.00,655.35]	Frame loss ratio(in %) minimum in the near end <i>This element is only shown in detail mode.</i>
flr-avg-near	Parameter type: <Cfm::PmPercentageType> (invalid <Cfm::PmPercentage>) Possible values: - invalid : Negative Loss ratio or Loss ratio more than 100 percent Field type <Cfm::PmPercentage> - Frame loss ratio in percentage - unit: percentage - range: [0.00...100.00,655.35]	The average of accumulated Frame Loss Ratio (%) within the test duration of 15 Minutes. <i>This element is only shown in detail mode.</i>
flr-max-near	Parameter type: <Cfm::PmPercentageType> (invalid <Cfm::PmPercentage>) Possible values: - invalid : Negative Loss ratio or Loss ratio more than 100 percent Field type <Cfm::PmPercentage> - Frame loss ratio in percentage - unit: percentage - range: [0.00...100.00,655.35]	Frame loss ratio(in %) maximum in the near end <i>This element is only shown in detail mode.</i>

Only Show Details: frame loss ratio - far end		
name	Type	Description
flr-min-far	Parameter type: <Cfm::PmPercentageType> (invalid <Cfm::PmPercentage>) Possible values: - invalid : Negative Loss ratio or Loss ratio more than 100 percent Field type <Cfm::PmPercentage> - Frame loss ratio in percentage - unit: percentage - range: [0.00...100.00,655.35]	Frame loss ratio(in %) minimum in the far end <i>This element is only shown in detail mode.</i>
flr-avg-far	Parameter type: <Cfm::PmPercentageType> (invalid <Cfm::PmPercentage>) Possible values: - invalid : Negative Loss ratio or Loss ratio more than 100 percent	The average of accumulated Frame Loss Ratio (%) within the test duration of 15 Minutes. <i>This element is only shown in detail mode.</i>

166 CFM Status Commands

name	Type	Description
	Field type <Cfm::PmPercentage> - Frame loss ratio in percentage - unit: percentage - range: [0.00...100.00,655.35]	
flr-max-far	Parameter type: <Cfm::PmPercentageType> (invalid <Cfm::PmPercentage>) Possible values: - invalid : Negative Loss ratio or Loss ratio more than 100 percent Field type <Cfm::PmPercentage> - Frame loss ratio in percentage - unit: percentage - range: [0.00...100.00,655.35]	Frame loss ratio(in %) maximum in the far end <i>This element is only shown in detail mode.</i>

166.16 Proactive CFM PM show command for the previous 1 day

Command Description

This command displays the PM Proactive loss measurement for the previous 1 day.

User Level

The command can be accessed by operators with alarm , oam , vlan privileges.

Command Syntax

The command has the following syntax:

```
> show cfm y1731pm prev-day-stats
```

166.17 Proactive CFM PM show command for the previous 1 day

Command Description

This command displays the PM Proactive loss measurement for the previous 1 day.

User Level

The command can be accessed by operators with alarm , oam , vlan privileges.

Command Syntax

The command has the following syntax:

```
> show cfm y1731pm prev-day-stats domain [ (domain-index) [ association <Cfm::CfmMaIndexType> ] [ mep
<Cfm::MepIdType> ] [ session-id <Cfm::SessionIdType> ] [ interval-number
<Cfm::PmPrevious1DayIntervalNumberType> ] ]
```

Command Parameters

Table 166.17-1 "Proactive CFM PM show command for the previous 1 day" Resource Parameters

Resource Identifier	Type	Description
(domain-index)	Format: - Maintenance Domain (MD) index - range: [1...4294967295]	Maintenance domain.
association	Parameter type: <Cfm::CfmMaIndexType> Format: - Maintenance Association (MA) index. Unique within an MD - range: [1...4294967295]	Maintenance association.
mep	Parameter type: <Cfm::MepIdType> Format: - MA End Point (MEP) ID. Unique within an MA - range: [1...8191]	Maintenance End Point.
session-id	Parameter type: <Cfm::SessionIdType> Format: - Session Id for PM proactive - range: [1...3600]	PM Proactive test SessionId.
interval-number	Parameter type: <Cfm::PmPrevious1DayIntervalNumberType> Format: - Previous 15 min interval number - range: [1...7]	PM Proactive Previous 1 day interval number.

Command Output

Table 166.17-2 "Proactive CFM PM show command for the previous 1 day" Display parameters

Specific Information		
name	Type	Description
test-type	Parameter type: <Cfm::PmTestType> (single-ended-slm single-ended-lm) Possible values: - single-ended-slm : sets test type to SLM - single-ended-lm : sets test type to LM	Y1731 PM Test type <i>This element is only shown in detail mode.</i>
interval(sec)	Parameter type: <Cfm::PmIntervalType> - PM interval (sec) SLM: [1...10] LM: [60 or 300] - range: [1...10,60,300]	Interval in which PM packets are transmitted. <i>This element is only shown in detail mode.</i>
measurement-intvl(sec)	Parameter type: <Cfm::PmMeasurementIntervalType> (not-applicable <Cfm::PmMeasurementInterval>) Possible values: - not-applicable : For single-ended-lm, the value of this object is not-applicable Field type <Cfm::PmMeasurementInterval> - Measurement interval - unit: seconds - range: [60,300]	The time for which the synthetic loss calculation is made periodically. <i>This element is only shown in detail mode.</i>
dest-mac	Parameter type: <Vlan::MacAddr> - mac address (aa:bb:cc:a1:02:03) - unit: Byte - length: 6	MAC address of the PM responder(Target). <i>This element is only shown in detail mode.</i>
measured-time(sec)	Parameter type: <Cfm::Pm1DayTimeMeasuredType> - Measured time - unit: seconds	Time measured since the start of the PM proactive test <i>This element is only shown in detail mode.</i>
data-tlv-size	Parameter type: <Cfm::PmDataSizeType> (not-applicable <Cfm::PmDataSize>) Possible values: - not-applicable : For single-ended-lm, the value of this object is not-applicable Field type <Cfm::PmDataSize> - Datasize for the SLM proactive test - range: [0...1500]	Data size of the SLM proactive test <i>This element is only shown in detail mode.</i>
priority	Parameter type: <Vlan::Priority> - priority of ethernet frames - range: [0...7]	Vlan Priority for PM proactive messages being transmitted <i>This element is only shown in detail mode.</i>
invalid-data-flag	Parameter type: <Cfm::PmInvalidDataFlagType> - Indicates the validity of the corresponding PM data. - range: [0...1]	Indicates the validity of the corresponding PM data. It is set to 1 when the PM data is incomplete or invalid and set to 0 when the PM data is complete and valid. <i>This element is only shown in detail mode.</i>
pdu-sent	Parameter type: <Counter> - 32 bit counter	Number of PM Y1731 PDUs sent by this MEP in the previous 1Day <i>This element is only shown in detail mode.</i>
pdu-rcvd	Parameter type: <Counter> - 32 bit counter	Number of PM Y1731 PDUs received by this MEP in the

166 CFM Status Commands

name	Type	Description
		previous 1Day <i>This element is only shown in detail mode.</i>
pdu-discarded	Parameter type: <Counter> - 32 bit counter	Number of PM Y1731 PDUs discarded by this MEP in the previous 1Day <i>This element is only shown in detail mode.</i>
test-id	Parameter type: <Cfm::PmTestIdType> (not-applicable <Cfm::PmTestId>) Possible values: - not-applicable : For single-ended-lm, the value of this object is not-applicable Field type <Cfm::PmTestId> - Test Id for PM proactive - range: [1...65535]	PM Proactive test Id. <i>This element is only shown in detail mode.</i>
remote-mep	Parameter type: <Cfm::PmMepIdType> (unavailable not-applicable <Cfm::MepId>) Possible values: - unavailable : No SLR received yet - not-applicable : For single-ended-lm, the value of this object is not-applicable Field type <Cfm::MepId> - MA End Point (MEP) ID. Unique within an MA - range: [1...8191]	Remote Maintenance Association End Point Id. <i>This element is only shown in detail mode.</i>

Only Show Details: loss calculation		
name	Type	Description
total-tx-near	Parameter type: <Cfm::Pm8byteOctetType> - Pdu count	Total no of PM proactive messages TXed in the near-end <i>This element is only shown in detail mode.</i>
total-tx-far	Parameter type: <Cfm::Pm8byteOctetType> - Pdu count	Total no of PM proactive messages TXed in the far end <i>This element is only shown in detail mode.</i>
total-rx-near	Parameter type: <Cfm::Pm8byteOctetType> - Pdu count	Total no of PM proactive messages RXed in the near-end <i>This element is only shown in detail mode.</i>
total-rx-far	Parameter type: <Cfm::Pm8byteOctetType> - Pdu count	Total no of PM proactive messages RXed in the far-end <i>This element is only shown in detail mode.</i>
loss-near	Parameter type: <Cfm::Pm8byteOctetType> - Pdu count	Total loss of PM proactive messages in the near-end <i>This element is only shown in detail mode.</i>
loss-far	Parameter type: <Cfm::Pm8byteOctetType> - Pdu count	Total loss of PM proactive messages in the far-end <i>This element is only shown in detail mode.</i>
un-ack	Parameter type: <Cfm::Pm8byteOctetWithNAType> (not-applicable <Cfm::Pm8byteOctet>)	Total number of SLM frames that are unacknowledged <i>This element is only shown in</i>

name	Type	Description
	Possible values: - not-applicable : For single-ended-lm, the value of this object is not-applicable Field type <Cfm::Pm8byteOctet> - Pdu count	<i>detail mode.</i>

Only Show Details: frame loss ratio - near end		
name	Type	Description
flr-min-near	Parameter type: <Cfm::PmPercentageType> (invalid <Cfm::PmPercentage>) Possible values: - invalid : Negative Loss ratio or Loss ratio more than 100 percent Field type <Cfm::PmPercentage> - Frame loss ratio in percentage - unit: percentage - range: [0.00...100.00,655.35]	Frame loss ratio(in %) minimum in the near end <i>This element is only shown in detail mode.</i>
flr-avg-near	Parameter type: <Cfm::PmPercentageType> (invalid <Cfm::PmPercentage>) Possible values: - invalid : Negative Loss ratio or Loss ratio more than 100 percent Field type <Cfm::PmPercentage> - Frame loss ratio in percentage - unit: percentage - range: [0.00...100.00,655.35]	The average of accumulated Frame Loss Ratio (%) within the test duration of 1 Day. <i>This element is only shown in detail mode.</i>
flr-max-near	Parameter type: <Cfm::PmPercentageType> (invalid <Cfm::PmPercentage>) Possible values: - invalid : Negative Loss ratio or Loss ratio more than 100 percent Field type <Cfm::PmPercentage> - Frame loss ratio in percentage - unit: percentage - range: [0.00...100.00,655.35]	Frame loss ratio(in %) maximum in the near end <i>This element is only shown in detail mode.</i>

Only Show Details: frame loss ratio - far end		
name	Type	Description
flr-min-far	Parameter type: <Cfm::PmPercentageType> (invalid <Cfm::PmPercentage>) Possible values: - invalid : Negative Loss ratio or Loss ratio more than 100 percent Field type <Cfm::PmPercentage> - Frame loss ratio in percentage - unit: percentage - range: [0.00...100.00,655.35]	Frame loss ratio(in %) minimum in the far end <i>This element is only shown in detail mode.</i>
flr-avg-far	Parameter type: <Cfm::PmPercentageType> (invalid <Cfm::PmPercentage>) Possible values: - invalid : Negative Loss ratio or Loss ratio more than 100 percent Field type <Cfm::PmPercentage>	The average of accumulated Frame Loss Ratio (%) within the test duration of 1 Day. <i>This element is only shown in detail mode.</i>

166 CFM Status Commands

name	Type	Description
	- Frame loss ratio in percentage - unit: percentage - range: [0.00...100.00,655.35]	
flr-max-far	Parameter type: <Cfm::PmPercentageType> (invalid <Cfm::PmPercentage>) Possible values: - invalid : Negative Loss ratio or Loss ratio more than 100 percent Field type <Cfm::PmPercentage> - Frame loss ratio in percentage - unit: percentage - range: [0.00...100.00,655.35]	Frame loss ratio(in %) maximum in the far end <i>This element is only shown in detail mode.</i>

166.18 Maintenance Association End Point Y1731 AIS Info Command

Command Description

This command displays AIS information of Maintenance association End Point (MEP) located on ONU UNI.

A MEP is contained within a Maintenance Association (MA) and is identified by the combination of Maintenance Domain (MD) index, MA index and MEP ID.

User Level

The command can be accessed by operators with all privileges.

Command Syntax

The command has the following syntax:

```
> show cfm mep-y1731ais-info domain [ (domain-index) [ association <Cfm::CfmMaIndexType> ] [ mep
<Cfm::MepIdType> ] ]
```

Command Parameters

Table 166.18-1 "Maintenance Association End Point Y1731 AIS Info Command" Resource Parameters

Resource Identifier	Type	Description
(domain-index)	Format: - Maintenance Domain (MD) index - range: [1...4294967295]	Maintenance Domain (MD) index
association	Parameter type: <Cfm::CfmMaIndexType> Format: - Maintenance Association (MA) index. Unique within an MD - range: [1...4294967295]	Maintenance Association (MA) index
mep	Parameter type: <Cfm::MepIdType> Format: - MA End Point (MEP) ID. Unique within an MA - range: [1...8191]	Maintenance association End Point (MEP) ID

Command Output

Table 166.18-2 "Maintenance Association End Point Y1731 AIS Info Command" Display parameters

Specific Information		
name	Type	Description
enable	Parameter type: <Cfm::MepAisEnableDisable>	Enable/Disable AIS generation

166 CFM Status Commands

name	Type	Description
	(ais-enable ais-disable) Possible values: - ais-enable : AIS generation is enabled on the current MEP - ais-disable : AIS generation is disabled on the current MEP	on the current MEP <i>This element is always shown.</i>
meg-level	Parameter type: <Cfm::MepAisMegLevel> - Meg Level for AIS frames transmitted by the MEP - range: [0...7]	AIS meg level by the MEP <i>This element is always shown.</i>
period	Parameter type: <Cfm::MepAisPeriod> - Period of the AIS frames transmitted by the MEP, 0 (per second), 1 (per minute) - range: [0...1]	AIS period by the MEP <i>This element is always shown.</i>
priority	Parameter type: <Cfm::MepAisPriority> - Priority value for AIS frames transmitted by the MEP - range: [0...7]	AIS priority by the MEP <i>This element is always shown.</i>
port-shut	Parameter type: <Cfm::MepAisAutoShut> (portshut-enable portshut-disable) Possible values: - portshut-enable : shutdown enabled on the current MEP - portshut-disable : shutdown disabled on the current MEP	Auto shut down bridge port is enabled on the current MEP <i>This element is always shown.</i>

167- IPoA/E IW Status Commands

167.1 IPoA/E IW Status Command Tree	167-6796
167.2 IPoA/E IW Interworking Port Status Command	167-6797

167.1 IPoA/E IW Status Command Tree

Description

This chapter gives an overview of nodes that are handled by "IPoA/E IW Status Commands".

Command Tree

```
----show
  ----ipoa/e-iw
    ----port
      - (interworking-port)
```

167.2 IPoA/E IW Interworking Port Status Command

Command Description

This command displays the status of ipoa/oe iwl port's L2 connectivity.

User Level

The command can be accessed by operators with ip privileges.

Command Syntax

The command has the following syntax:

```
> show ipoa/e-iw port [ (interworking-port) ]
```

Command Parameters

Table 167.2-1 "IPoA/E IW Interworking Port Status Command" Resource Parameters

Resource Identifier	Type	Description
(interworking-port)	Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::VpiId> : <Eqpt::VciId> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId>) Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number Field type <Eqpt::VpiId> - atm VPI Field type <Eqpt::VciId> - atm VCI	index of rack/shelf/slot/port user-bridgeport

Command Output

Table 167.2-2 "IPoA/E IW Interworking Port Status Command" Display parameters

Specific Information		
name	Type	Description
oper-status	Parameter type: <IpoaccM::operState>	l2 connectivity operational state

167 IPoA/E IW Status Commands

name	Type	Description
	(up down) Possible values: - up : the data plane is fully ready for forwarding - down : the data plane is not fully ready for forwarding	<i>This element is always shown.</i>
down-reason	Parameter type: <IpoaccM::downReason> (no-error net-vlan-miss gw-cfg-miss gw-mac-unresolved interface-down) Possible values: - no-error : no error - net-vlan-miss : network vlan not attached - gw-cfg-miss : gateway not configured - gw-mac-unresolved : gateway mac address not resolved - interface-down : corresponding vlan port interface down in operational	l2 connectivity status reason <i>This element is only shown in detail mode.</i>
src-mac-addr	Parameter type: <IpoaccM::macAddr> - mac address (aa:bb:cc:a1:02:03) - length: 6	source mac address allocated for iwl user <i>This element is only shown in detail mode.</i>
er-mac-addr	Parameter type: <IpoaccM::macAddr> - mac address (aa:bb:cc:a1:02:03) - length: 6	gateway mac address for iwl user <i>This element is only shown in detail mode.</i>

168- LineTest Status Commands

168.1 LineTest Status Command Tree	168-6800
168.2 Megaco LineTest Available Session Status Command	168-6801
168.3 Megaco LineTest Session Status Command	168-6802
168.4 Megaco LineTest Line Status Command	168-6804
168.5 Megaco LineTest LineId ExtReport Status Command	168-6808
168.6 SINGLE LineTest Available Session Status Command	168-6814
168.7 SINGLE LineTest Session Status Command	168-6815
168.8 SINGLE LineTest Line Status Command	168-6818
168.9 SINGLE LineTest LineId ExtReport Status Command	168-6822
168.10 SINGLE LineTest Chipset Data Command	168-6829
168.11 SINGLE LineTest Session busy port Command	168-6830
168.12 MELT Selftest Status Command	168-6832
168.13 MELT reset Status Command	168-6834
168.14 MELT hardware Status Command	168-6836

168.1 LineTest Status Command Tree

Description

This chapter gives an overview of nodes that are handled by "LineTest Status Commands".

Command Tree

```
----show
  ----linetest
    ----cluster
      - (clusterid)
      ----avail-sess
      ----ltsession
        - (sessionid)
      ----ltline
        - (sessionid)
        - lineid
      ----lineid-ext-rept
        - (sessionid)
        - lineid
        - test-name(unit)
        - result-index
    ----single
      ----avail-sess
      ----ltsession
        - (sessionid)
      ----ltline
        - (sessionid)
        - lineid
      ----lineid-ext-rept
        - (sessionid)
        - lineid
        - test-name(unit)
        - result-index
      ----chipsetdata-for-slot
        - (ltboardposition)
      ----busy-status
        - (sessionid)
        - lineid
      ----melt-selftest
        - (lt-slotno)
      ----melt-reset
        - (lt-slotno)
      ----hw-status
        - (if-index)
```

168.2 Megaco LineTest Available Session Status Command

Command Description

This command allows the operator to check whether there is an available session to line test.

User Level

The command can be accessed by operators with megaco privileges.

Command Syntax

The command has the following syntax:

> show linetest cluster (clusterid) avail-sess

Command Parameters

Table 168.2-1 "Megaco LineTest Available Session Status Command" Resource Parameters

Resource Identifier	Type	Description
(clusterid)	Format: - the xvps cluster id - range: [1...8,11]	uniquely identify of this xvps cluster

Command Output

Table 168.2-2 "Megaco LineTest Available Session Status Command" Display parameters

Specific Information		
name	Type	Description
available-sess	Parameter type: <LineTest::Session> - session number - range: [0...16]	the available seession to do line test <i>This element is always shown.</i>
max-session	Parameter type: <LineTest::Session> - session number - range: [0...16]	the max number of session <i>This element is always shown.</i>

168.3 Megaco LineTest Session Status Command

Command Description

This command displays session related parameters.

User Level

The command can be accessed by operators with megaco privileges.

Command Syntax

The command has the following syntax:

> show linetest cluster (clusterid) ltsession [(sessionid)]

Command Parameters

Table 168.3-1 "Megaco LineTest Session Status Command" Resource Parameters

Resource Identifier	Type	Description
(clusterid)	Format: - the xvps cluster id - range: [1...8,11]	uniquely identify of this xvps cluster
(sessionid)	Format: - available session id - range: [1]	uniquely identify of session

Command Output

Table 168.3-2 "Megaco LineTest Session Status Command" Display parameters

Specific Information		
name	Type	Description
session-status	Parameter type: <LineTest::SessionStatus> (idle revcmd runcmd revinfo testover stateerror testhold) Possible values: - idle : indicate the session is not initialized, you can create it - revcmd : indicate the session receives test cmd - runcmd : indicate the session runs test cmd - revinfo : indicate the session receives info cmd - testover : indicate the session test is finished - stateerror : something is wrong	the status of session <i>This element is always shown.</i>

name	Type	Description
	- testhold : indicate the session is held for sub test of talking test or 1 round is finished in continuous test	

168.4 Megaco LineTest Line Status Command

Command Description

This command displays all parameters on a specific line id of a session.

User Level

The command can be accessed by operators with megaco privileges.

Command Syntax

The command has the following syntax:

```
> show linetest cluster (clusterid) ltline [ (sessionid) [ lineid <Itf::LineTestMegacoLineId> ] ]
```

Command Parameters

Table 168.4-1 "Megaco LineTest Line Status Command" Resource Parameters

Resource Identifier	Type	Description
(clusterid)	Format: - the xvps cluster id - range: [1...8,11]	uniquely identify of this xvps cluster
(sessionid)	Format: - available session id - range: [1]	uniquely identify of session
lineid	Parameter type: <Itf::LineTestMegacoLineId> Format: <Eqpt::NodeId> / <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::NewSlotId> / <Eqpt::MegacoPortId> Field type <Eqpt::NodeId> - the Node number Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::NewSlotId> - the LT slot number Field type <Eqpt::MegacoPortId> - the port number of Megaco	line id

Command Output

Table 168.4-2 "Megaco LineTest Line Status Command" Display parameters

Specific Information		
name	Type	Description
line-status	Parameter type: <LineTest::LineStatus>	the test result status

name	Type	Description
	(none intest testover rstpartlyready testrejected) Possible values: - none : null - intest : put the line in test - testover : the line tested, and the result is ready for polling, it is read-only - rstpartlyready : defined for dp/dtmf test - testrejected : line test not supported for shared line	<i>This element is always shown.</i>
comm-status	Parameter type: <LineTest::LTComErrCode> (unfinished finish stop-by-timeout cancel-by-operator break-by-user ppfailed linebusy ltime-no-operator linestatus-error out-memory timer-operfail type-empty type-logic-err type-unknown para-lineid-err para-oper-err pare-serialnum-err line-intesting otherfail ended-by-oper onhook-by-oper paraval-err llurelay-err shared-line-rejected service-unavailable rejected-pwrthold session-timeout invalid-portid miss-message redundancy-ports end-sequence-num port-disable poltfail port-unknown-state outofmem new-timer-err start-timer-err send-msg-err get-ipudp-err enable-lock disable-unlock disable-lock abort-timer-err empty-test-type	the test result status <i>This element is always shown.</i>

168 LineTest Status Commands

name	Type	Description
	mismatch-with-mode disable-net-unlock disable-unlock-gk disable-unlock-oc disable-unlock-ot disable-net-lock disable-lock-gk disable-lock-oc disable-lock-ot not-support mta-testing board-intesting finish-pass finish-fail) Possible values: - unfinished : the line test is not finished yet - finish : the total logic result outcome - stop-by-timeout : if reset all cmd is arrived, the later coming test request is wrong - cancel-by-operator : as an error flag to construct the result package - break-by-user : stop while testing by user - ppfailed : pp failed, hardware failed - linebusy : the line is busy in used - ltime-no-operator : in continuous/talking test, long time no further operator(600s) - linestatus-error : timer operator failed - out-memory : fail to apply result buffer in lt board - timer-operfail : operation fail of timer - type-empty : no test type in test request - type-logic-err : measurement no supported - type-unknown : the test command is illegal - para-lineid-err : the lineid in test command is not valid - para-oper-err : illegal operation - pare-serialnum-err : error session id - line-intesting : the line is in another line test - otherfail : some other fail - ended-by-oper : the test was over because of end operation of operator - onhook-by-oper : the test was over because operator on hook - paraval-err : for dtmf test, test para less than 1 - llurelay-err : llurelay config not valid for MELT - shared-line-rejected : line test not supported for shared line - service-unavailable : the test was over because service is unavailable - rejected-pwrthold : NBLT could not be started due to max power consumption threshold reached - session-timeout : test session time out - invalid-portid : lineid is not valid - miss-message : line test message is not received - redundancy-ports : redundancy port ids for the testtype only support 1 port every test - end-sequence-num : end command used wrong session id - port-disable : line test board is not available - poltfail : line test board failed - port-unknown-state : this line is in an unknown state	

name	Type	Description
	- outofmem : xVPS or NT run out of memory - new-timer-err : create timer failed - start-timer-err : start timer failed - send-msg-err : send message failed - get-ipudp-err : get line ip/udp failed - enable-lock : line enable but locked - disable-unlock : line disable and unlocked - disable-lock : line disable and locked - abort-timer-err : abort timer failed - empty-test-type : the test type bitmap is empty - mismatch-with-mode : test type mismatch with test mode - disable-net-unlock : adminstate:unlock, operstate:disable from mgc - disable-unlock-gk : adminstate:unlock, operstate:disable from tg(ground key) - disable-unlock-oc : adminstate:unlock, operstate:disable from tg(over current) - disable-unlock-ot : adminstate:unlock, operstate:disable from tg(over temperature) - disable-net-lock : adminstate:lock, operstate:disable from mgc - disable-lock-gk : adminstate:lock, operstate:disable from tg(ground key) - disable-lock-oc : adminstate:lock, operstate:disable from tg(over current) - disable-lock-ot : adminstate:lock, operstate:disable from tg(over temperature) - not-support : line test is no supported for the port - mta-testing : the port is undergoing in mta test now - board-intesting : the board is in another line test - finish-pass : gr909 group test passed - finish-fail : gr909 group test failed	
val-num	Parameter type: <LineTest::RpValNum> - available results numbers - range: [0...72]	available results numbers <i>This element is always shown.</i>
hook-chag-status	Parameter type: <LineTest::LineHookChagStat> (others offhook-to-onhook onhook-to-offhook) Possible values: - others : no hook state change - offhook-to-onhook : the tested line has hook state change from off hook to on hook - onhook-to-offhook : the tested line has hook state change from on hook to off hook	line hook state change <i>This element is always shown.</i>

168.5 Megaco LineTest LineId ExtReport Status Command

Command Description

This command displays parameters for lineid report multi results.

User Level

The command can be accessed by operators with megaco privileges.

Command Syntax

The command has the following syntax:

```
> show linetest cluster (clusterid) lineid-ext-rept [ (sessionid) [ lineid <Itf::LineTestMegacoLineId> ] [ test-name(unit) <LineTest::TestTypeMegaco> ] [ result-index <LineTest::RpRsIndex> ] ]
```

Command Parameters

Table 168.5-1 "Megaco LineTest LineId ExtReport Status Command" Resource Parameters

Resource Identifier	Type	Description
(clusterid)	Format: - the xvps cluster id - range: [1...8,11]	uniquely identify of this xvps cluster
(sessionid)	Format: - available session id - range: [1]	uniquely identify of session
lineid	Parameter type: <Itf::LineTestMegacoLineId> Format: <Eqpt::NodeId> / <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::NewSlotId> / <Eqpt::MegacoPortId> Field type <Eqpt::NodeId> - the Node number Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::NewSlotId> - the LT slot number Field type <Eqpt::MegacoPortId> - the port number of Megaco	line id
test-name(unit)	Parameter type: <LineTest::TestTypeMegaco> Format: (feeded-ac-tr(mv) feeded-ac-tg(mv) feeded-ac-rg(mv)	test type

Resource Identifier	Type	Description
	foreign-ac-tr(mv) foreign-ac-tg(mv) foreign-ac-rg(mv) feeded-dc-tr(mv) foreign-dc-tr(mv) foreign-dc-tg(mv) foreign-dc-rg(mv) feed-current(ua) feeded-dc-rt(mv) resist-tr(ohm) resist-rt(ohm) resist-tg(ohm) resist-rg(ohm) resist-tbat(ohm) resist-rbat(ohm) capacitanc-tr(nf) capacitanc-rt(nf) capacitanc-tg(nf) capacitanc-rg(nf) impedance-tr(ohm) impedance-tg(ohm) impedance-rg(ohm) low-capacit-phone force-ring-subscrib dialton-delay(ms) msocket-detection ac-current-tr(ua) ac-current-tg(ua) ac-current-rg(ua) dc-current-tr(ua) dc-current-tg(ua) dc-current-rg(ua) noise-lv-0.001dbm howler-test-park status-monitored cable-pair-ident talking-father line-reverse-sub p-meter-pulse-sub ring-subscrib-sub dpdtmf-signal-sub userloop-sub(ohm) feeded-dc-tg(mv) feeded-dc-rg(mv) impedance-rt(ohm) isdn-loopback ringer-ren(mren) dialtone-delay-db(ms) gr909-roh gr909-hazardous-p gr909-femf gr909-resistive-f diagnosis-call(1/10s) Possible values: - feeded-ac-tr(mv) : feeded ac rms voltage of user line (tip-ring) - feeded-ac-tg(mv) : feeded ac rms voltage of user line	

Resource Identifier	Type	Description
	(tip-ground) - feeded-ac-rg(mv) : feeded ac rms voltage of user line (ring-ground) - foreign-ac-tr(mv) : foreign ac rms voltage of user line (tip-ring) - foreign-ac-tg(mv) : foreign ac rms voltage of user line (tip-ground) - foreign-ac-rg(mv) : foreign ac rms voltage of user line (ring-ground) - feeded-dc-tr(mv) : feeded dc voltage of user line (tip-ring) - foreign-dc-tr(mv) : foreign dc voltage of user line (tip-ring) - foreign-dc-tg(mv) : foreign dc voltage of user line (tip-ground) - foreign-dc-rg(mv) : foreign dc voltage of user line (ring-ground) - feed-current(ua) : feeding current (tip-ring) - feeded-dc-rt(mv) : feeded dc voltage of user line (ring-tip) - resist-tr(ohm) : insulating resistance of user line (tip-ring) - resist-rt(ohm) : insulating resistance of user line (ring-tip) - resist-tg(ohm) : insulating resistance of user line (tip-ground) - resist-rg(ohm) : insulating resistance of user line (ring-ground) - resist-tbat(ohm) : insulating battery resistance of user line (tip-bat) - resist-rbat(ohm) : insulating battery resistance of user line (ring-bat) - capacitanc-tr(nf) : capacitance of user line (tip-ring) - capacitanc-rt(nf) : capacitance of user line (ring-tip) - capacitanc-tg(nf) : capacitance of user line (tip-ground) - capacitanc-rg(nf) : capacitance of user line (ring-ground) - impedance-tr(ohm) : impedance of user circuit (tip-ring) - impedance-tg(ohm) : impedance of user circuit (tip-ground) - impedance-rg(ohm) : impedance of user circuit (ring-ground) - low-capacit-phone : low capacitance phone detect - force-ring-subscrib : force ring subscriber test - dialton-delay(ms) : dial tone delay of user circuit only in idle - msocket-detection : termination (m socket detection) - ac-current-tr(ua) : ac current test normal test (tip-ring) - ac-current-tg(ua) : ac current test normal test (tip-ground) - ac-current-rg(ua) : ac current test normal test (ring-ground) - dc-current-tr(ua) : dc current test normal test (tip-ring) - dc-current-tg(ua) : dc current test normal test (tip-ground) - dc-current-rg(ua) : dc current test normal test (ring-ground) - noise-lv-0.001dbm : noise level normal test - howler-test-park : howler test under normal test condition only in parking - status-monitored : status monitored test - cable-pair-ident : cable pair identification test - talking-father : talking test (father test item) - line-reverse-sub : line reverse test, subtest of talking test - p-meter-pulse-sub : private meter pulses test, subtest of talking test - ring-subscrib-sub : ring subscriber with auto ring test,	

Resource Identifier	Type	Description
	subtest of talking test - dpdtmf-signal-sub : dp/dtmf signal test, subtest of talking test - userloop-sub(ohm) : resistance of user loop (tip-ring), subtest of talking test - feeded-dc-tg(mv) : feeded dc voltage of user line (tip-ground) - feeded-dc-rg(mv) : feeded dc voltage of user line (ring-ground) - impedance-rt(ohm) : impedance of user circuit (ring-tip) - isdn-loopback : isdn loop back test - ringer-ren(mren) : gr909 ringer equivalency number testing - dialtone-delay-db(ms) : gr909 draw and break dial tone delay testing - gr909-roh : gr909 receiver off hook testing - gr909-hazardous-p : gr909 Hazardous Potential testing - gr909-femf : gr909 Foreign ElectroMotive Force testing - gr909-resistive-f : gr909 resistive faults testing - diagnosis-call(1/10s) : diagnosis call test	
result-index	Parameter type: <LineTest::RpRsIndex> Format: - index of multi results - range: [1...20]	Index of multi results

Command Output

Table 168.5-2 "Megaco LineTest LineId ExtReport Status Command" Display parameters

Specific Information		
name	Type	Description
validity	Parameter type: <LineTest::LTErrCode> (success ppnom-measurefail ppnom-hookdet ppnom-alreadrun ppnom-notimple ppnet-offhook ppnet-inval-opmode ppnet-other ppnet-vin-unsupp ppnet-slic-unsupp testbeyd-cdethres test-timeout test-interrupted test-errother test-errvin test-erronhook test-erroffhook testbeyd-confthre degraded-accuracy thermal-fault exc-ac-induct cmsaturation diffsaturation exec-foreign-vol capoutofrange exec-low-res	the test result status <i>This element is always shown.</i>

168 LineTest Status Commands

name	Type	Description
	- receiveroffhook - testnotpassed - gndreported - resoutofrange - linestatus-unsupported - not-applicable - pass - fail - hw-setting-failed - pattern-check-failed - call-fail-busy - call-fail-other) Possible values: - success : pp success - ppnom-measurefail : pp measurement fail - ppnom-hookdet : pp hook detected - ppnom-alreadrun : pp already running - ppnom-notimple : pp not implemented - ppnet-offhook : pp off hook detected - ppnet-inval-opmode : pp invalid opmode - ppnet-other : pp other error - ppnet-vin-unsupp : pp vin unsupported - ppnet-slic-unsupp : pp slic unsupported - testbeyd-cdethres : test beyond cde threshold - test-timeout : test timeout - test-interrupted : test course was interrupted - test-errother : test other error - test-errvin : error coursed vy vinetic chip - test-erronhook : test ended by on hook event - test-erroffhook : test ended by off hook event - testbeyd-confthre : test result beyond the threshold that operator configed - degraded-accuracy : the accuracy of the results are degraded because of low leakage resistance - thermal-fault : a thermal fault was detected during the test - exc-ac-induct : excessive ac induction was detected during the test - cmsaturation : common mode saturation was detected during the test - diffsaturation : differential saturation was detected during the test - exec-foreign-vol : a large foreign voltage prevented the respective tests from being executed - capoutofrange : capacitor were too large to be measured - exec-low-res : test has not been executed due to the presence of a very low fault resistance - receiveroffhook : test failed because the measured voltage never settled to within tolerancelimits - testnotpassed : test result beyond the threshold that operator configed - gndreported : a single resistance to ground - resoutofrange : resistance were too large to be measured - linestatus-unsupported : test not executed because of the unsupported line status - not-applicable : test not executed because it not applicable - pass : gr909 sub test/voice diagnosis call test passed - fail : gr909 sub test/voice diagnosis call test failed	

name	Type	Description
	- hw-setting-failed : E1 loopback setting failed - pattern-check-failed : E1 loopback pattern check failed - call-fail-busy : diagnosis call test failed because term is busy - call-fail-other : diagnosis call test failed for other reason	
value	Parameter type: <LineTest::ExtRpVal> - line test result value of the specified line and test type. The specific range is dependent on the specific line test item. The following is the max range. - range: [-2147483647...2147483647]	line test result value of the specified line and test type <i>This element is always shown.</i>
value2	Parameter type: <LineTest::ExtRpVal> - line test result value of the specified line and test type. The specific range is dependent on the specific line test item. The following is the max range. - range: [-2147483647...2147483647]	line test result value of the specified line and test type <i>This element is always shown.</i>
value3	Parameter type: <LineTest::ExtRpVal> - line test result value of the specified line and test type. The specific range is dependent on the specific line test item. The following is the max range. - range: [-2147483647...2147483647]	line test result value of the specified line and test type <i>This element is always shown.</i>
value4	Parameter type: <LineTest::ExtRpVal> - line test result value of the specified line and test type. The specific range is dependent on the specific line test item. The following is the max range. - range: [-2147483647...2147483647]	line test result value of the specified line and test type <i>This element is always shown.</i>

168.6 SINGLE LineTest Available Session Status Command

Command Description

This command allows the operator to check whether there is an available session to line test.

User Level

The command can be accessed by operators with sip , xdsl privileges.

Command Syntax

The command has the following syntax:

> show linetest single avail-sess

Command Output

Table 168.6-2 "SINGLE LineTest Available Session Status Command" Display parameters

Specific Information		
name	Type	Description
available-session	Parameter type: <LineTest::Session> - session number - range: [0...16]	the available seession to do line test <i>This element is always shown.</i>
max-session	Parameter type: <LineTest::Session> - session number - range: [0...16]	the max number of session <i>This element is always shown.</i>

168.7 SINGLE LineTest Session Status Command

Command Description

This command displays session related parameters.

User Level

The command can be accessed by operators with sip , xdsl privileges.

Command Syntax

The command has the following syntax:

> show linetest single ltsession [(sessionid)]

Command Parameters

Table 168.7-1 "SINGLE LineTest Session Status Command" Resource Parameters

Resource Identifier	Type	Description
(sessionid)	Format: - available session id - range: [1...16]	uniquely identify of session

Command Output

Table 168.7-2 "SINGLE LineTest Session Status Command" Display parameters

Specific Information		
name	Type	Description
session-status	Parameter type: <LineTest::SessionStatus> (idle revcmd runcmd revinfo testover stateerror testhold) Possible values: - idle : indicate the session is not initialized, you can create it - revcmd : indicate the session receives test cmd - runcmd : indicate the session runs test cmd - revinfo : indicate the session receives info cmd - testover : indicate the session test is finished - stateerror : something is wrong - testhold : indicate the session is held for sub test of talking test or 1 round is finished in continuous test	the status of session <i>This element is always shown.</i>
input-err-code	Parameter type: <LineTest::SessionErrCode>	the input error code of session

168 LineTest Status Commands

name	Type	Description
	(noerr paramnuminconsis paramnumoutrange typeneednparam nontestingtype missingparamconf missingtimeout timeoutnotenough linenuminconsis linenumoutrange invalidlineid duplicatedline missingtesttype invalidtesttype thresholdnumerr neednothreshold threshfornon typemismatchmode linenummismatch wrongstatusforsub notonetestitem lineidinnontest modenotsupportrep sessionstateerr internalerror inactivetimeroutrange) Possible values: - noerr : no error - paramnuminconsis : the actual input param number in ltTestParamTable is not equal to ltTestParamNum - paramnumoutrange : the input param number is out of range, from 0 to 4 is allowed - typeneednparam : the input test param is meaningless, because those test types not need any test para - nontestingtype : the input test param for those test types which are not in current test session - missingparamconf : missing test param configuration for those test types which must have test param - missingtimeout : missing ltTimeOutPeriod value - timeoutnotenough : the input ltTimeOutPeriod is not enough for test - linenuminconsis : the actual input line number in ltLineIdTable is not equal to ltLineNum - linenumoutrange : the input line number is out of range, from 1 to 72 is allowed - invalidlineid : the input lineId is invalid - duplicatedline : the same lineId configed twice - missingtesttype : missing ltTestTypeHigh and ltTestTypeLow - invalidtesttype : the input ltTestTypeHigh and ltTestTypeLow is incorrect - thresholdnumerr : input too many threshold, the number of threshold from 0 to 39 is allowed - neednothreshold : the input threshold is meaningless, because those test types do not need any threshold - threshfornon : the input threshold for those test types which are not in current test session	<i>This element is always shown.</i>

name	Type	Description
	- typemismatchmode : the input test type does not match with the test mode - linenummismatch : the input line number is not match test mode and test type. All talking test, cable pair test, block test and continuous test only support one line for certain test - wrongstatusforsub : the line status for subtest is not in holding or the line which has no father test first - notonetestitem : block test and continous test must be only one test type - lineidinnontest : the input lineId is not in testing status - modenotsupportrep : repeate test can only be done in continous test mode - sessionstateerr : the command not allowed in current session state - internalerror : internal system error - inactivetimeroutrange : the input session inactive timer is out of range, 0 and from 120 to 65535 is allowed	

168.8 SINGLE LineTest Line Status Command

Command Description

This command displays all parameters on a specific line id of a session.

User Level

The command can be accessed by operators with sip , xdsl privileges.

Command Syntax

The command has the following syntax:

```
> show linetest single lline [ (sessionid) [ lineid <Itf::LineTestSingleLineId> ] ]
```

Command Parameters

Table 168.8-1 "SINGLE LineTest Line Status Command" Resource Parameters

Resource Identifier	Type	Description
(sessionid)	Format: - available session id - range: [1...16]	uniquely identify of session
lineid	Parameter type: <Itf::LineTestSingleLineId> Format: <Eqpt::NodeId> / <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> Field type <Eqpt::NodeId> - the Node number Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number	line id

Command Output

Table 168.8-2 "SINGLE LineTest Line Status Command" Display parameters

Specific Information		
name	Type	Description
line-status	Parameter type: <LineTest::LineStatus> (none intest testover	the test result status <i>This element is always shown.</i>

name	Type	Description
	rstpartlyready testrejected) Possible values: - none : null - intest : put the line in test - testover : the line tested, and the result is ready for polling, it is read-only - rstpartlyready : defined for dp/dtmf test - testrejected : line test not supported for shared line	
comm-status	Parameter type: <LineTest::LTComErrCode> (unfinished finish stop-by-timeout cancel-by-operator break-by-user ppfailed linebusy ltime-no-operator linestatus-error out-memory timer-operfail type-empty type-logic-err type-unknown para-lineid-err para-oper-err pare-serialnum-err line-intesting otherfail ended-by-oper onhook-by-oper paraval-err llurelay-err shared-line-rejected service-unavailable rejected-pwrthold session-timeout invalid-portid miss-message redundancy-ports end-sequence-num port-disable poltfail port-unknown-state outofmem new-timer-err start-timer-err send-msg-err get-ipudp-err enable-lock disable-unlock disable-lock abort-timer-err empty-test-type mismatch-with-mode disable-net-unlock disable-unlock-gk	the test result status <i>This element is always shown.</i>

name	Type	Description
	disable-unlock-oc disable-unlock-ot disable-net-lock disable-lock-gk disable-lock-oc disable-lock-ot not-support mta-testing board-intesting finish-pass finish-fail) Possible values: - unfinished : the line test is not finished yet - finish : the total logic result outcome - stop-by-timeout : if reset all cmd is arrived, the later coming test request is wrong - cancel-by-operator : as an error flag to construct the result package - break-by-user : stop while testing by user - ppfailed : pp failed, hardware failed - linebusy : the line is busy in used - ltime-no-operator : in continuous/talking test, long time no further operator(600s) - linestatus-error : timer operator failed - out-memory : fail to apply result buffer in lt board - timer-operfail : operation fail of timer - type-empty : no test type in test request - type-logic-err : measurement no supported - type-unknown : the test command is illegal - para-lineid-err : the lineid in test command is not valid - para-oper-err : illegal operation - pare-serialnum-err : error session id - line-intesting : the line is in another line test - otherfail : some other fail - ended-by-oper : the test was over because of end operation of operator - onhook-by-oper : the test was over because operator on hook - paraval-err : for dtmf test, test para less than 1 - llurelay-err : llurelay config not valid for MELT - shared-line-rejected : line test not supported for shared line - service-unavailable : the test was over because service is unavailable - rejected-pwrthold : NBLT could not be started due to max power consumption threshold reached - session-timeout : test session time out - invalid-portid : lineid is not valid - miss-message : line test message is not received - redundancy-ports : redundancy port ids for the testtype only support 1 port every test - end-sequence-num : end command used wrong session id - port-disable : line test board is not available - poltfail : line test board failed - port-unknown-state : this line is in an unknown state - outofmem : xVPS or NT run out of memory - new-timer-err : create timer failed - start-timer-err : start timer failed	

name	Type	Description
	- send-msg-err : send message failed - get-ipudp-err : get line ip/udp failed - enable-lock : line enable but locked - disable-unlock : line disable and unlocked - disable-lock : line disable and locked - abort-timer-err : abort timer failed - empty-test-type : the test type bitmap is empty - mismatch-with-mode : test type mismatch with test mode - disable-net-unlock : adminstate:unlock, operstate:disable from mgc - disable-unlock-gk : adminstate:unlock, operstate:disable from tg(ground key) - disable-unlock-oc : adminstate:unlock, operstate:disable from tg(over current) - disable-unlock-ot : adminstate:unlock, operstate:disable from tg(over temperature) - disable-net-lock : adminstate:lock, operstate:disable form mgc - disable-lock-gk : adminstate:lock, operstate:disable from tg(ground key) - disable-lock-oc : adminstate:lock, operstate:disable from tg(over current) - disable-lock-ot : adminstate:lock, operstate:disable from tg(over temperature) - not-support : line test is no supported for the port - mta-testing : the port is undergoing in mta test now - board-intesting : the board is in another line test - finish-pass : gr909 group test passed - finish-fail : gr909 group test failed	
comm-status-text	Parameter type: <LineTest::comm-status-text> - the text mapper of comm-stat - length: x<=256	the test result status <i>This element is always shown.</i>
val-num	Parameter type: <LineTest::RpValNum> - available results numbers - range: [0...72]	available results numbers <i>This element is always shown.</i>
hook-chag-status	Parameter type: <LineTest::LineHookChagStat> (others offhook-to-onhook onhook-to-offhook) Possible values: - others : no hook state change - offhook-to-onhook : the tested line has hook state change from off hook to on hook - onhook-to-offhook : the tested line has hook state change from on hook to off hook	line hook state change <i>This element is always shown.</i>
stop-time	Parameter type: <LineTest::GaugeTimeInSecs> - the time (yyyy-mm-dd:hour:minutes:secs)	line test stop time <i>This element is always shown.</i>
rem-time-searcht	Parameter type: <LineTest::SearchToneRemainingTime> - search tone remaining time - unit: second - range: [0...7200]	search tone remaining time <i>This element is always shown.</i>

168.9 SINGLE LineTest LineId ExtReport Status Command

Command Description

This command displays parameters for lineid report multi results.

User Level

The command can be accessed by operators with sip , xdsl privileges.

Command Syntax

The command has the following syntax:

```
> show linetest single lineid-ext-rept [ (sessionid) [ lineid <Itf::LineTestSingleLineId> ] [ test-name(unit)
<LineTest::TestTypeSip> ] [ result-index <LineTest::RpRsIndex> ] ]
```

Command Parameters

Table 168.9-1 "SINGLE LineTest LineId ExtReport Status Command" Resource Parameters

Resource Identifier	Type	Description
(sessionid)	Format: - available session id - range: [1...16]	uniquely identify of session
lineid	Parameter type: <Itf::LineTestSingleLineId> Format: <Eqpt::NodeId> / <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> Field type <Eqpt::NodeId> - the Node number Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number	line id
test-name(unit)	Parameter type: <LineTest::TestTypeSip> Format: (feeded-ac-tr(mv) feeded-ac-tg(mv) feeded-ac-rg(mv) foreign-ac-tr(mv) foreign-ac-tg(mv) foreign-ac-rg(mv)	test type

Resource Identifier	Type	Description
	feeded-dc-tr(mv) foreign-dc-tr(mv) foreign-dc-tg(mv) foreign-dc-rg(mv) feed-current(ua) feeded-dc-rt(mv) resist-tr(ohm) resist-rt(ohm) resist-tg(ohm) resist-rg(ohm) resist-tbat(ohm) resist-rbat(ohm) capacitanc-tr(nf) capacitanc-rt(nf) capacitanc-tg(nf) capacitanc-rg(nf) impedance-tr(ohm) impedance-tg(ohm) impedance-rg(ohm) low-capacit-phone force-ring-subscrib dialton-delay(ms) msocket-detection ac-current-tr(ua) ac-current-tg(ua) ac-current-rg(ua) dc-current-tr(ua) dc-current-tg(ua) dc-current-rg(ua) noise-lv-0.001dbm howler-test-park status-monitored cable-pair-ident talking-father line-reverse-sub p-meter-pulse-sub ring-subscrib-sub dpdtmf-signal-sub userloop-sub(ohm) capacit-sign(pf) resist-sign(ohm) feeded-dc-tg(mv) feeded-dc-rg(mv) impedance-rt(ohm) long-current(ua) diagnosis-caller diagnosis-callee conductance-tr(1/10us) conductance-tg(1/10us) conductance-rg(1/10us) susceptance-tr(1/10us) susceptance-tg(1/10us) susceptance-rg(1/10us) hazardous-volt(1/2) term-signature(1/0) term-capacitiv(1/0) ppa-test(ppa-variant)	

Resource Identifier	Type	Description
	roh-test(1/0) term_ringer(1/0) ringer-ren(mren) dialtone-delay-db(ms) gr909-roh gr909-hazardous-p gr909-femf gr909-resistive-f zener-res(ohm) zener-volt(uv) remotelb ploadlb locallb cablelb isdn-pra-remotelb isdn-pra-ploadlb isdn-pra-locallb isdn-pra-cablelb cas-r2-remotelb cas-r2-ploadlb cas-r2-locallb cas-r2-cablelb diagnosis-call(1/10s) Possible values: - feeded-ac-tr(mv) : feeded ac rms voltage of user line (tip-ring) - feeded-ac-tg(mv) : feeded ac rms voltage of user line (tip-ground) - feeded-ac-rg(mv) : feeded ac rms voltage of user line (ring-ground) - foreign-ac-tr(mv) : foreign ac rms voltage of user line (tip-ring) - foreign-ac-tg(mv) : foreign ac rms voltage of user line (tip-ground) - foreign-ac-rg(mv) : foreign ac rms voltage of user line (ring-ground) - feeded-dc-tr(mv) : feeded dc voltage of user line (tip-ring) - foreign-dc-tr(mv) : foreign dc voltage of user line (tip-ring) - foreign-dc-tg(mv) : foreign dc voltage of user line (tip-ground) - foreign-dc-rg(mv) : foreign dc voltage of user line (ring-ground) - feed-current(ua) : feeding current (tip-ring) - feeded-dc-rt(mv) : feeded dc voltage of user line (ring-tip) - resist-tr(ohm) : insulating resistance of user line (tip-ring) - resist-rt(ohm) : insulating resistance of user line (ring-tip) - resist-tg(ohm) : insulating resistance of user line (tip-ground) - resist-rg(ohm) : insulating resistance of user line (ring-ground) - resist-tbat(ohm) : insulating battery resistance of user line (tip-bat) - resist-rbat(ohm) : insulating battery resistance of user line (ring-bat) - capacitanc-tr(nf) : capacitance of user line (tip-ring) - capacitanc-rt(nf) : capacitance of user line (ring-tip) - capacitanc-tg(nf) : capacitance of user line (tip-ground)	

Resource Identifier	Type	Description
	- capacitanc-rg(nf) : capacitance of user line (ring-ground) - impedance-tr(ohm) : impedance of user circuit (tip-ring) - impedance-tg(ohm) : impedance of user circuit (tip-ground) - impedance-rg(ohm) : impedance of user circuit (ring-ground) - low-capacit-phone : low capacitance phone detect - force-ring-subscrib : force ring subscriber test - dialton-delay(ms) : dial tone delay of user circuit only in idle - msocket-detection : termination (m socket detection) - ac-current-tr(ua) : ac current test normal test (tip-ring) - ac-current-tg(ua) : ac current test normal test (tip-ground) - ac-current-rg(ua) : ac current test normal test (ring-ground) - dc-current-tr(ua) : dc current test normal test (tip-ring) - dc-current-tg(ua) : dc current test normal test (tip-ground) - dc-current-rg(ua) : dc current test normal test (ring-ground) - noise-lv-0.001dbm : noise level normal test - howler-test-park : howler test under normal test condition only in parking - status-monitored : status monitored test - cable-pair-ident : cable pair identification test - talking-father : talking test (father test item) - line-reverse-sub : line reverse test, subtest of talking test - p-meter-pulse-sub : private meter pulses test, subtest of talking test - ring-subscrib-sub : ring subscriber with auto ring test, subtest of talking test - dpdtmf-signal-sub : dp/dtmf signal test, subtest of talking test - userloop-sub(ohm) : resistance of user loop (tip-ring), subtest of talking test - capacit-sign(pf) : capacitance of etsi signature or electronic ringer - resist-sign(ohm) : resistance of etsi signature or electronic ringer - feeded-dc-tg(mv) : feeded dc voltage of user line (tip-ground) - feeded-dc-rg(mv) : feeded dc voltage of user line (ring-ground) - impedance-rt(ohm) : impedance of user circuit (ring-tip) - long-current(ua) : difference between the currents on the a-lead and the b-lead (longitudinal current) - diagnosis-caller : H248 Voice Diagnosis Caller - diagnosis-callee : H248 Voice Diagnosis Callee - conductance-tr(1/10us): Conductance of user line (Tip-Ring) - conductance-tg(1/10us): Conductance of user line (Tip-Ground) - conductance-rg(1/10us): Conductance of user line (Ring-Ground) - susceptance-tr(1/10us): Susceptance of user line (Tip-Ring) - susceptance-tg(1/10us): Susceptance of user line (Tip-Ground) - susceptance-rg(1/10us): Susceptance of user line (Ring-Ground)	

Resource Identifier	Type	Description
	- hazardous-volt(1/2) : whether voltage value is hazardous or not(iltf-hazardous-voltage) - term-signature(1/0) : whether termination signature is detected(iltf-termination-signature) - term-capacitiv(1/0) : whether termination capacitance is detected(iltf-termination-capacitiv) - ppa-test(ppa-variant) : test ppa variant(iltf-ppa) - roh-test(1/0) : test termination roh - term_ringer(1/0) : whether termination ringer is detected - ringer-ren(mren) : gr909 ringer equivalency number testing - dialtone-delay-db(ms) : gr909 draw and break dial tone delay testing - gr909-roh : gr909 receiver off hook testing - gr909-hazardous-p : gr909 Hazardous Potential testing - gr909-femf : gr909 Foreign ElectroMotive Force testing - gr909-resistive-f : gr909 resistive faults testing - zener-res(ohm) : test zener resistance - zener-volt(uv) : test zener voltage - remotelb : E1 or T1 Remote loopback test - ploadlb : E1 or T1 Payload loopback test - locallb : E1 or T1 Local loopback test - cablelb : E1 or T1 Cable loopback test - isdn-pra-remotelb : ISDN PRA Remote loopback test - isdn-pra-ploadlb : ISDN PRA Payload loopback test - isdn-pra-locallb : ISDN PRA Local loopback test - isdn-pra-cablelb : ISDN PRA Cable loopback test - cas-r2-remotelb : CAS R2 Remote loopback test - cas-r2-ploadlb : CAS R2 Payload loopback test - cas-r2-locallb : CAS R2 Local loopback test - cas-r2-cablelb : CAS R2 Cable loopback test - diagnosis-call(1/10s) : diagnosis call test	
result-index	Parameter type: <LineTest::RpRsIndex> Format: - index of multi results - range: [1...20]	Index of multi results

Command Output

Table 168.9-2 "SINGLE LineTest LineId ExtReport Status Command" Display parameters

Specific Information		
name	Type	Description
validity	Parameter type: <LineTest::LTErrCode> (success ppnom-measurefail ppnom-hookdet ppnom-alreadrun ppnom-notimple ppnet-offhook ppnet-inval-opmode ppnet-other ppnet-vin-unsupp ppnet-slic-unsupp testbeyd-cdethres test-timeout test-interrupted test-errother)	the test result status <i>This element is always shown.</i>

name	Type	Description
	test-errvin test-erronhook test-erroffhook testbeyd-confthre degraded-accuracy thermal-fault exc-ac-induct cmsaturation diffsaturation exec-foreign-vol capoutofrange exec-low-res receiveroffhook testnotpassed gndreported resoutofrange linestatus-unsupport not-applicable pass fail hw-setting-failed pattern-check-failed call-fail-busy call-fail-other) Possible values: - success : pp success - ppnom-measurefail : pp measurement fail - ppnom-hookdet : pp hook detected - ppnom-alreadrun : pp already running - ppnom-notimple : pp not implemented - ppnet-offhook : pp off hook detected - ppnet-inval-opmode : pp invalid opmode - ppnet-other : pp other error - ppnet-vin-unsupp : pp vin unsupport - ppnet-slic-unsupp : pp slic unsupport - testbeyd-cdethres : test beyond cde threshold - test-timeout : test timeout - test-interrupted : test course was interrupted - test-errother : test other error - test-errvin : error coursed vy vinetic chip - test-erronhook : test ended by on hook event - test-erroffhook : test ended by off hook event - testbeyd-confthre : test result beyond the threshold that operator configed - degraded-accuracy : the accuracy of the results are degraded because of low leakage resistance - thermal-fault : a thermal fault was detected during the test - exc-ac-induct : excessive ac induction was detected during the test - cmsaturation : common mode saturation was detected during the test - diffsaturation : differential saturation was detected during the test - exec-foreign-vol : a large foreign voltage prevented the respective tests from being executed - capoutofrange : capacitor were too large to be measured - exec-low-res : test has not been executed due to the	

168 LineTest Status Commands

name	Type	Description
	presence of a very low fault resistance - receiveroffhook : test failed because the measured voltage never settled to within tolerancelimits - testnotpassed : test result beyond the threshold that operator configed - gndreported : a single resistance to ground - resoutofrange : resistance were too large to be measured - linestatus-unsupport : test not executed because of the unsupported line status - not-applicable : test not executed because it not applicable - pass : gr909 sub test/voice diagnosis call test passed - fail : gr909 sub test/voice diagnosis call test failed - hw-setting-failed : E1 loopback setting failed - pattern-check-failed : E1 loopback pattern check failed - call-fail-busy : diagnosis call test failed because term is busy - call-fail-other : diagnosis call test failed for other reason	
value	Parameter type: <LineTest::ExtRpVal> - line test result value of the specified line and test type.The specific range is dependent on the specific line test item.The following is the max range. - range: [-2147483647...2147483647]	line test result value of the specified line and test type <i>This element is always shown.</i>
value2	Parameter type: <LineTest::ExtRpVal> - line test result value of the specified line and test type.The specific range is dependent on the specific line test item.The following is the max range. - range: [-2147483647...2147483647]	line test result value of the specified line and test type <i>This element is always shown.</i>
value3	Parameter type: <LineTest::ExtRpVal> - line test result value of the specified line and test type.The specific range is dependent on the specific line test item.The following is the max range. - range: [-2147483647...2147483647]	line test result value of the specified line and test type <i>This element is always shown.</i>
value4	Parameter type: <LineTest::ExtRpVal> - line test result value of the specified line and test type.The specific range is dependent on the specific line test item.The following is the max range. - range: [-2147483647...2147483647]	line test result value of the specified line and test type <i>This element is always shown.</i>
value-vi	Parameter type: <LineTest::ExtRpVi> - the validity flag of line test result value. - range: [-2147483647...2147483647]	line test validity identifier for all result values <i>This element is always shown.</i>

168.10 SINGLE LineTest Chipset Data Command

Command Description

This command displays the manufacturer, hardware version and firmware version of board's chipset.

User Level

The command can be accessed by operators with sip , xdsl privileges.

Command Syntax

The command has the following syntax:

> show linetest single chipsetdata-for-slot [(ltboardposition)]

Command Parameters

Table 168.10-1 "SINGLE LineTest Chipset Data Command" Resource Parameters

Resource Identifier	Type	Description
(ltboardposition)	Format: lt : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> Possible values: - lt : lt-slot Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number	uniquely identify of linetest slot

Command Output

Table 168.10-2 "SINGLE LineTest Chipset Data Command" Display parameters

Specific Information		
name	Type	Description
vendorid	Parameter type: <LineTest::VendorString> - uniquely identifies board vendor id - length: x<=32	the manufacturer identifier of board <i>This element is always shown.</i>
hardware-version	Parameter type: <LineTest::HardwareVersionString> - uniquely identifies board hardware version - length: x<=232	the hardware-version of the board <i>This element is always shown.</i>
firmware-version	Parameter type: <LineTest::FirmwareVersionString> - uniquely identifies board firmware version - length: x<=32	the firmware-version of the board <i>This element is always shown.</i>

168.11 SINGLE LineTest Session busy port Command

Command Description

This command displays busy port of session.

User Level

The command can be accessed by operators with sip , xdsl privileges.

Command Syntax

The command has the following syntax:

```
> show linetest single busy-status [ (sessionid) [ lineid <Itf::LineTestSingleLineId> ] ]
```

Command Parameters

Table 168.11-1 "SINGLE LineTest Session busy port Command" Resource Parameters

Resource Identifier	Type	Description
(sessionid)	Format: - available session id - range: [1...16]	uniquely identify of session
lineid	Parameter type: <Itf::LineTestSingleLineId> Format: <Eqpt::NodeId> / <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> Field type <Eqpt::NodeId> - the Node number Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number	line id

Command Output

Table 168.11-2 "SINGLE LineTest Session busy port Command" Display parameters

Specific Information		
name	Type	Description
busy-status	Parameter type: <LineTest::LTBusyStatus>	busy reason of busy port

name	Type	Description
	(tobetest inmeasurement insearchtone testover) Possible values: - tobetest : the port will be test - inmeasurement : the port is in LineTestMeasurement - insearchtone : the port is in SearchTone - testover : the port is test finished	<i>This element is always shown.</i>

168.12 MELT Selftest Status Command

Command Description

This command displays the status of selftest operation on MELT board.

User Level

The command can be accessed by operators with sip , xdsl privileges.

Command Syntax

The command has the following syntax:

> show linetest single melt-selftest [(lt-slotno)]

Command Parameters

Table 168.12-1 "MELT Selftest Status Command" Resource Parameters

Resource Identifier	Type	Description
(lt-slotno)	Format: lt : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> Possible values: - lt : lt-slot Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number	the physical slot position

Command Output

Table 168.12-2 "MELT Selftest Status Command" Display parameters

Specific Information		
name	Type	Description
selftest-status	Parameter type: <LineTest::MeltSelfTestStatus> (idle teststart testongoing testfinishedandpassed testfinishedandfailed testunfinished) Possible values: - idle : idle state - teststart : test start state - testongoing : test ongoing state - testfinishedandpassed : test finished and passed state	the test result status <i>This element is always shown.</i>

name	Type	Description
	- testfinishedandfailed : test finished and failed state - testunfinished : test unfinished state	

168.13 MELT reset Status Command

Command Description

This command displays the status of reset operation on MELT board.

User Level

The command can be accessed by operators with sip , xdsl privileges.

Command Syntax

The command has the following syntax:

```
> show linetest single melt-reset [ (lt-slotno) ]
```

Command Parameters

Table 168.13-1 "MELT reset Status Command" Resource Parameters

Resource Identifier	Type	Description
(lt-slotno)	Format: lt : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> Possible values: - lt : lt-slot Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number	the physical slot position

Command Output

Table 168.13-2 "MELT reset Status Command" Display parameters

Specific Information		
name	Type	Description
reset-status	Parameter type: <LineTest::MeltResetStatus> (idle resetstart resetongoing resetfinished resetunavailable) Possible values: - idle : Initial state - resetstart : the MELT reset operation is triggered - resetongoing : MELT reset is in progress - resetfinished : MELT reset is completed - resetunavailable : MELT reset function is not available	the test result status <i>This element is always shown.</i>

168.14 MELT hardware Status Command

Command Description

This command displays the status of hardware operation on MELT board.

User Level

The command can be accessed by operators with sip , xdsl privileges.

Command Syntax

The command has the following syntax:

```
> show linetest single hw-status [ (if-index) ]
```

Command Parameters

Table 168.14-1 "MELT hardware Status Command" Resource Parameters

Resource Identifier	Type	Description
(if-index)	Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number	interface index of the port

Command Output

Table 168.14-2 "MELT hardware Status Command" Display parameters

Specific Information		
name	Type	Description
hw-status	Parameter type: <LineTest::OperationalStatus> (operational not-operational) Possible values: - operational : MELT Hw is operational - not-operational : MELT Hw is not operational	the test result status <i>This element is always shown.</i>

169- LACP status commands

169.1 LACP status commands Tree	169-6838
169.2 LACP Port Status Command	169-6839
169.3 LACP Group Status Command	169-6845
169.4 LACP Member Port Status Command	169-6848

169.1 LACP status commands Tree

Description

This chapter gives an overview of nodes that are handled by "LACP status commands".

Command Tree

```
----show
  ----link-agg
    ----port-info
      - (port)
    ----group-info
      - (group)
  ----member-port
    - (group)
    - port
```


169.2 LACP Port Status Command

Command Description

This command displays information for a member port of a Link Aggregation Group.

User Level

The command can be accessed by operators with lacp privileges.

Command Syntax

The command has the following syntax:

```
> show link-agg port-info [ (port) ]
```

Command Parameters

Table 169.2-1 "LACP Port Status Command" Resource Parameters

Resource Identifier	Type	Description
(port)	Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number	interface index of the port

Command Output

Table 169.2-2 "LACP Port Status Command" Display parameters

Specific Information		
name	Type	Description
aggregate	Parameter type: <Lacp::AggregateFlag> (aggregate individual) Possible values: - aggregate : aggregate - individual : individual	specifies whether the aggregation port is able to aggregate or only able to operate as an individual link. <i>This element is always shown.</i>

Only Show Details: aggregate/individual parameters		
name	Type	Description
actor-sys-id	Parameter type: <Lacp::MacAddr> - mac address (aa:bb:cc:a1:02:03)	specifies MAC addr that defines the value of the system id for the

169 LACP status commands

name	Type	Description
	- length: 6	system that contains this aggregation port. <i>This element is only shown in detail mode.</i>
actor-key	Parameter type: <Lacp::LacpKey> - link aggregate key - range: [0...65535]	current operational value of the key for the aggregation port. <i>This element is only shown in detail mode.</i>
partner-sys-priority	Parameter type: <Lacp::PartnerSysPriority> - the lacp system priority - range: [0...65535]	operational value of priority associated with the partner's system id. <i>This element is only shown in detail mode.</i>
partner-sys-id	Parameter type: <Lacp::MacAddr> - mac address (aa:bb:cc:a1:02:03) - length: 6	specifies MAC addr value representing the current value of the aggregation port's protocol partner's system id. <i>This element is only shown in detail mode.</i>
partner-key	Parameter type: <Lacp::LacpKey> - link aggregate key - range: [0...65535]	current operational value of the key for the protocol partner. <i>This element is only shown in detail mode.</i>
actual-aggregator-port	Parameter type: <Itf::LaGroupZeroIndex> (none <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId>) Possible values: - none : no port Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number	specifies the aggregator that this aggregation port has currently selected <i>This element is only shown in detail mode.</i>
attached-aggreg-port	Parameter type: <Itf::LaGroupZeroIndex> (none <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId>) Possible values: - none : no port Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number	specifies the aggregator that this aggregation port is currently attached to. zero indicates that the aggregation port is not currently attached to an aggregator. <i>This element is only shown in detail mode.</i>
actor-port	Parameter type: <Lacp::ActorPort> - la aggregate actor port - range: [0...65535]	port number locally assigned to the aggregation port. <i>This element is only shown in detail mode.</i>
actor-admin-port-pri	Parameter type: <Lacp::ActorPortAdminPriority> - la aggregate port priority	the admin priority for the port. <i>This element is only shown in</i>

name	Type	Description
	- range: [0...65535]	<i>detail mode.</i>
actor-oper-port-pri	Parameter type: <Lacp::ActorPortOperPriority> - la aggregate port priority - range: [0...65535]	the operational priority for the port. <i>This element is only shown in detail mode.</i>
partner-port	Parameter type: <Lacp::PartnerOperPort> - la aggregate partner operational port - range: [0...65535]	operational port number assigned to this aggregation port by the aggregation port's protocol partner. <i>This element is only shown in detail mode.</i>
partner-port-priority	Parameter type: <Lacp::PartnerPortPriority> - la aggregate port priority - range: [0...65535]	priority value assigned to this aggregation port by the partner. <i>This element is only shown in detail mode.</i>
actor-synch-state	Parameter type: <Lacp::ActorOperLacpSynchState> (synchronised not-synchronised) Possible values: - synchronised : actor is synchronised - not-synchronised : actor is not synchronised	actor oper lacp synch state <i>This element is only shown in detail mode.</i>
actor-collect-state	Parameter type: <Lacp::ActorOperLacpCollectState> (collecting not-collecting) Possible values: - collecting : the actor is collecting - not-collecting : the actor is not collecting	actor oper lacp collecting state <i>This element is only shown in detail mode.</i>
actor-distribute-state	Parameter type: <Lacp::ActorOperLacpDistributeState> (distributing not-distributing) Possible values: - distributing : the actor is distributing - not-distributing : the actor is not distributing	actor oper lacp distributing state <i>This element is only shown in detail mode.</i>
actor-defaulted-state	Parameter type: <Lacp::ActorOperLacpDefaultedState> (is-defaulted is-not-defaulted) Possible values: - is-defaulted : the actor is defaulted - is-not-defaulted : the actor is not defaulted	actor oper lacp defaulted state <i>This element is only shown in detail mode.</i>
actor-expired-state	Parameter type: <Lacp::ActorOperLacpExpiredState> (is-expired is-not-expired) Possible values: - is-expired : actor is in lacp expired state - is-not-expired : actor is not in lacp expired state	actor oper lacp expired state <i>This element is only shown in detail mode.</i>
partner-synch-state	Parameter type: <Lacp::PartnerOperLacpSynchState> (synchronised not-synchronised) Possible values: - synchronised : the partner is synchronised - not-synchronised : the partner is not synchronised	partner oper lacp synch state <i>This element is only shown in detail mode.</i>
partner-collect-state	Parameter type: <Lacp::PartnerOperLacpCollectState> (collecting not-collecting) Possible values: - collecting : the partner is collecting - not-collecting : the partner is not collecting	partner oper lacp collecting state <i>This element is only shown in detail mode.</i>

169 LACP status commands

name	Type	Description
partn-distribute-state	Parameter type: <Lacp::PartnerOperLacpDistributeState> (distributing not-distributing) Possible values: - distributing : the partner is distributing - not-distributing : the partner is not distributing	partner oper lacp distributing state <i>This element is only shown in detail mode.</i>
partn-defaulted-state	Parameter type: <Lacp::PartnerOperLacpDefaultedState> (is-defaulted is-not-defaulted) Possible values: - is-defaulted : the partner is defaulted - is-not-defaulted : the partner is not defaulted	partner oper lacp defaulted state <i>This element is only shown in detail mode.</i>
partner-expired-state	Parameter type: <Lacp::PartnerOperLacpExpiredState> (is-expired is-not-expired) Possible values: - is-expired : partner is in lacp expired state - is-not-expired : partner is not in lacp expired state	partner oper lacp expired state <i>This element is only shown in detail mode.</i>

Only Show Details: link aggregation control protocol statistics		
name	Type	Description
lacp-pdus-rx	Parameter type: <Counter> - 32 bit counter	number of valid LACPDUs received on this aggregation port. <i>This element is only shown in detail mode.</i>
marker-rx	Parameter type: <Counter> - 32 bit counter	nbr of valid marker PDUs received on this aggregation port. <i>This element is only shown in detail mode.</i>
marker-response-rx	Parameter type: <Counter> - 32 bit counter	nbr of valid marker response PDUs received on this aggregation port. <i>This element is only shown in detail mode.</i>
unknown-rx	Parameter type: <Counter> - 32 bit counter	nbr of frames rx that either: carry the slow protocols ethernet type value, but contain an unknown PDU, or: are addressed to the slow protocols group MAC addr, but do not carry the slow protocols ethernet type. <i>This element is only shown in detail mode.</i>
illegal-rx	Parameter type: <Counter> - 32 bit counter	nbr of frames rx that carry the slow protocols ethernet type value, but contain a badly formed PDU or an illegal value of protocol subtype. <i>This element is only shown in detail mode.</i>
lacp-pdus-tx	Parameter type: <Counter> - 32 bit counter	number of LACPDUs transmitted on this aggregation port. <i>This element is only shown in detail mode.</i>
marker-tx	Parameter type: <Counter> - 32 bit counter	number of marker PDUs transmitted on this aggregation port. <i>This element is only shown in detail mode.</i>

name	Type	Description
marker-response-tx	Parameter type: <Counter> - 32 bit counter	<i>detail mode.</i> nbr of marker response PDUs transmitted on this aggregation port. <i>This element is only shown in detail mode.</i>
Only Show Details: debugging information		
name	Type	Description
rx-state	Parameter type: <Lacp::RxState> (present expired defaulted initialize lacpdisabled portdisabled) Possible values: - present : present - expired : expired - defaulted : defaulted - initialize : initialize - lacpdisabled : lacp Disabled - portdisabled : port Disabled	specifies receive state machine for the aggregation port <i>This element is only shown in detail mode.</i>
last-rx-time	Parameter type: <TimeTicks> - a timeout value - unit: msec	specifies the value of a Time Since SystemReset when the last LACPDU was received by this Aggregation Port <i>This element is only shown in detail mode.</i>
mux-state	Parameter type: <Lacp::MuxState> (detached waiting attached collecting distributing collect-distributing) Possible values: - detached : detached - waiting : waiting - attached : attached - collecting : collecting - distributing : distributing - collect-distributing : collecting and distributing	specifies the mux state machine for the aggregation port <i>This element is only shown in detail mode.</i>
mux-reason	Parameter type: <PrintableString> - printable string	specifies the reason for the most recent change of mux machine state. <i>This element is only shown in detail mode.</i>
actor-churn-state	Parameter type: <Lacp::ChurnState> (no-churn churn churn-monitor) Possible values: - no-churn : no churn - churn : churn - churn-monitor : churn monitor	specifies the state of the actor churn detection machine for the aggregation port. <i>This element is only shown in detail mode.</i>
actor-churn-count	Parameter type: <Counter> - 32 bit counter	nbr of times the actor churn state machine has entered the

169 LACP status commands

name	Type	Description
		ACTOR_CHURN state. <i>This element is only shown in detail mode.</i>
actor-sync-transit-cnt	Parameter type: <Counter> - 32 bit counter	nbr of times the actor's mux state machine has entered the IN_SYNC state. <i>This element is only shown in detail mode.</i>
actor-lag-id-chg-count	Parameter type: <Counter> - 32 bit counter	nbr of times the actor's perception of the lag id for this aggregation port has changed. <i>This element is only shown in detail mode.</i>
partner-churn-state	Parameter type: <Lacp::ChurnState> (no-churn churn churn-monitor) Possible values: - no-churn : no churn - churn : churn - churn-monitor : churn monitor	specifies the state of the partner churn detection machine for the aggregation port. <i>This element is only shown in detail mode.</i>
partner-churn-count	Parameter type: <Counter> - 32 bit counter	nbr of times the partner churn state machine has entered the PARTNER_CHURN state. <i>This element is only shown in detail mode.</i>
partn-sync-transit-cnt	Parameter type: <Counter> - 32 bit counter	nbr of times the partner's mux state machine has entered the IN_SYNC state. <i>This element is only shown in detail mode.</i>
partner-lag-id-chg-cnt	Parameter type: <Counter> - 32 bit counter	nbr of times the partner's perception of the lag id for this aggregation port has changed. <i>This element is only shown in detail mode.</i>

169.3 LACP Group Status Command

Command Description

This command displays information about a Link Aggregation Group, The operator identifies the group by means of the primary port.

User Level

The command can be accessed by operators with lacp privileges.

Command Syntax

The command has the following syntax:

```
> show link-agg group-info [ (group) ]
```

Command Parameters

Table 169.3-1 "LACP Group Status Command" Resource Parameters

Resource Identifier	Type	Description
(group)	Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number	interface index of the link aggregation group

Command Output

Table 169.3-2 "LACP Group Status Command" Display parameters

Specific Information		
name	Type	Description
actor-system-id	Parameter type: <Lacp::MacAddr> - mac address (aa:bb:cc:a1:02:03) - length: 6	specifies MAC addr that defines the value of the system id for the system that contains this aggregator. <i>This element is always shown.</i>
actor-sys-priority	Parameter type: <Lacp::ActorSysOperPriority> - the lacp agg actor system priority - range: [0...65535]	the lacp operational system priority. <i>This element is always shown.</i>
actor-oper-key	Parameter type: <Lacp::LacpKey>	the current operational value of

169 LACP status commands

name	Type	Description
	- link aggregate key - range: [0...65535]	the key for the aggregator. <i>This element is always shown.</i>
partner-sys-id	Parameter type: <Lacp::MacAddr> - mac address (aa:bb:cc:a1:02:03) - length: 6	Specifies MAC address for the current protocol partner of this aggregator <i>This element is always shown.</i>
partner-sys-priority	Parameter type: <Lacp::PartnerSysPriority> - the lacp system priority - range: [0...65535]	Specifies priority value associated with the partner's system id. <i>This element is always shown.</i>
partner-oper-key	Parameter type: <Lacp::LacpKey> - link aggregate key - range: [0...65535]	The current operational value for the aggregator's current protocol partner. <i>This element is always shown.</i>
rdncy-primary	Parameter type: <Itf::EthernetPortIndex> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number	The primary port in a LAG. <i>This element is always shown.</i>
rdncy-secondary	Parameter type: <Itf::EthernetPortIndex> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number	The secondary port in a LAG. <i>This element is always shown.</i>
rdncy-active-slot	Parameter type: <Lacp::EqptSlotIndex> (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> nt-a nt-b nt acu : <Eqpt::RackId> / <Eqpt::ShelfId> ext-a : <Eqpt::RackId> / <Eqpt::ShelfId> ext-b : <Eqpt::RackId> / <Eqpt::ShelfId> ctrl : <Eqpt::RackId> / <Eqpt::ShelfId>) Possible values: - nt-a : nt-a slot - nt-b : nt-b slot - nt : nt slot - ext-a : nt-a slot in an extension shelf - ext-b : nt-b slot in an extension shelf - acu : acu slot - ctrl : ctrl-slot Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number	The active slot in a LAG. <i>This element is always shown.</i>

name	Type	Description
	Field type <Eqpt::SlotId> - the LT slot number	

169.4 LACP Member Port Status Command

Command Description

This command displays information about a Link Aggregation Group member port status. The operator identifies the group by means of the primary port.

User Level

The command can be accessed by operators with lacp privileges.

Command Syntax

The command has the following syntax:

```
> show link-agg member-port [ (group) [ port <Itf::EthernetPortIndex> ] ]
```

Command Parameters

Table 169.4-1 "LACP Member Port Status Command" Resource Parameters

Resource Identifier	Type	Description
(group)	Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number	interface index of the link aggregation group
port	Parameter type: <Itf::EthernetPortIndex> Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number	Interface index of the port

Command Output

Table 169.4-2 "LACP Member Port Status Command" Display parameters

Specific Information		
name	Type	Description
standby	Parameter type: <Lacp::StandbyStatus> (active standby) Possible values: - active : active - standby : standby	specifies whether aggregation port is in active or standby. <i>This element is always shown.</i>

170- LACP status commands

170.1 LACP status commands Tree	170-6851
170.2 LACP Group Status Command	170-6852
170.3 LACP Group Status Command	170-6854
170.4 LACP Group Status Command	170-6856

170.1 LACP status commands Tree

Description

This chapter gives an overview of nodes that are handled by "LACP status commands".

Command Tree

```
----show
  ----link-agg
    ----resource
      ----group
        - (group)
      ----board-iwf-info
        - (slot)
        - iwf-id
      ----iwf-group-info
        - (slot)
        - iwf-id
        - master-group
```

170.2 LACP Group Status Command

Command Description

This command displays information about a Link Aggregation Group, The operator identifies the group by means of the primary port.

User Level

The command can be accessed by operators with lacp privileges.

Command Syntax

The command has the following syntax:

```
> show link-agg resource group [ (group) ]
```

Command Parameters

Table 170.2-1 "LACP Group Status Command" Resource Parameters

Resource Identifier	Type	Description
(group)	Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number	interface index of the link aggregation group

Command Output

Table 170.2-2 "LACP Group Status Command" Display parameters

Specific Information		
name	Type	Description
admin-master-iwf	Parameter type: <Lacp::ResourceMasterIwf> - display adminMasterIwf or operMasterIwf - length: x<=8	indicate the lag is binded to the iwf based on the primary port, or is a dummy lag. <i>This element is always shown.</i>
oper-master-iwf	Parameter type: <Lacp::ResourceMasterIwf> - display adminMasterIwf or operMasterIwf - length: x<=8	indicate which iwf the lag is binded to. <i>This element is always shown.</i>
ing-bandwidth(mbps)	Parameter type: <Lacp::IngressBandWidth> - bandwidth of the lag	the ingress band width of the lag. <i>This element is always shown.</i>

name	Type	Description
	- unit: Mbit/sec	
cross-iwf-link-used	Parameter type: <Lacp::CrossIwfLink> - the number of used cross-iwf inter-link on the lag. - range: [0...8]	indicate the number of cross-iwf inter-link is used on the lag <i>This element is always shown.</i>

170.3 LACP Group Status Command

Command Description

This command displays information about a Link Aggregation Group, The operator identifies the group by means of the primary port.

User Level

The command can be accessed by operators with lacp privileges.

Command Syntax

The command has the following syntax:

```
> show link-agg resource board-iwf-info [ (slot) [ iwf-id <Lacp::RsIwfId> ] ]
```

Command Parameters

Table 170.3-1 "LACP Group Status Command" Resource Parameters

Resource Identifier	Type	Description
(slot)	Format: lt : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> Possible values: - lt : lt-slot Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number	slot index of the link aggregation resource
iwf-id	Parameter type: <Lacp::RsIwfId> Format: - indicate resource iwf id. - range: [1...2]	indicate the resource iwf id.

Command Output

Table 170.3-2 "LACP Group Status Command" Display parameters

Specific Information		
name	Type	Description
bandwidth-total(mbps)	Parameter type: <Lacp::IngressBandWidth> - bandwidth of the lag - unit: Mbit/sec	indicating the total ingress-bandwidth of the iwf. <i>This element is always shown.</i>
bandwidth-used(mbps)	Parameter type: <Lacp::IngressBandWidth> - bandwidth of the lag - unit: Mbit/sec	indicating the used ingress-bandwidth of the iwf. <i>This element is always shown.</i>

name	Type	Description
bandwidth-free(mbps)	Parameter type: <Lacp::IngressBandWidth> - bandwidth of the lag - unit: Mbit/sec	indicating the free ingress-bandwidth of the iwf. <i>This element is always shown.</i>
crossiwf-links-total	Parameter type: <Lacp::CrossIwfLink> - the number of used cross-iwf inter-link on the lag. - range: [0...8]	indicates the total cross-iwf inter-link on the iwf. <i>This element is always shown.</i>
crossiwf-links-used	Parameter type: <Lacp::CrossIwfLink> - the number of used cross-iwf inter-link on the lag. - range: [0...8]	indicates the used cross-iwf inter-link on the iwf. <i>This element is always shown.</i>
crossiwf-links-free	Parameter type: <Lacp::CrossIwfLink> - the number of used cross-iwf inter-link on the lag. - range: [0...8]	indicates the free cross-iwf inter-link on the iwf. <i>This element is always shown.</i>

170.4 LACP Group Status Command

Command Description

This command displays information about a Link Aggregation Group, The operator identifies the group by means of the primary port.

User Level

The command can be accessed by operators with lacp privileges.

Command Syntax

The command has the following syntax:

```
> show link-agg resource iwfb-group-info [ (slot) [ iwfb-id <Lacp::RsIwfbId> ] [ master-group <Itf::LaGroupIndex> ] ]
```

Command Parameters

Table 170.4-1 "LACP Group Status Command" Resource Parameters

Resource Identifier	Type	Description
(slot)	Format: It : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> Possible values: - It : It-slot Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number	slot index of the link aggregation resource
iwfb-id	Parameter type: <Lacp::RsIwfbId> Format: - indicate resource iwfb id. - range: [1...2]	indicate the iwfb id.
master-group	Parameter type: <Itf::LaGroupIndex> Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number	indicate the master residential group id.

Command Output

Table 170.4-2 "LACP Group Status Command" Display parameters

Specific Information		
name	Type	Description
used-bandwidth(mbps)	Parameter type: <Lacp::IngressBandWidth> - bandwidth of the lag - unit: Mbit/sec	indicating the resource bandwidth used of the iwf. <i>This element is always shown.</i>

171- MSTP Status Commands

171.1 MSTP Status Command Tree	171-6859
171.2 MSTP Bridge Status Command	171-6860
171.3 MSTP Instance Status Command	171-6862
171.4 MSTP Network Port Status Command	171-6864
171.5 MSTP Port Instance Status Command	171-6867

171.1 MSTP Status Command Tree

Description

This chapter gives an overview of nodes that are handled by "MSTP Status Commands".

Command Tree

```
----show
  ----xstp
    ----bridge
    ----instance
      - (instance)
    ----port
      - (port)
    ----port-instance
      - (port)
      - instance
```

171.2 MSTP Bridge Status Command

Command Description

This command displays all common spanning tree instances for the whole bridge.

User Level

The command can be accessed by operators with mstp privileges.

Command Syntax

The command has the following syntax:

```
> show xstp bridge
```

Command Output

Table 171.2-2 "MSTP Bridge Status Command" Display parameters

Specific Information		
name	Type	Description
root-id	Parameter type: <Mstp::MstpBridgeId> - the mstp bridge id - length: 8	the bridgeId of the CIST root used in the PDUs originated by this node. <i>This element is only shown in detail mode.</i>
root-cost	Parameter type: <Mstp::MstpRootCost> - root cost	cost of the path to the CIST Root seen from the bridge <i>This element is only shown in detail mode.</i>
root-port	Parameter type: <Itf::LaGroupZeroIndex> (none <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId>) Possible values: - none : no port Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number	port which offers the lowest path cost to the Root bridge <i>This element is only shown in detail mode.</i>
hold-time	Parameter type: <SignedInteger> - a signed integer	interval between no more than two PDUs are transmitted <i>This element is only shown in detail mode.</i>
max-age	Parameter type: <SignedInteger>	max age of STP information

name	Type	Description
	- a signed integer	learned on a port before it is discarded <i>This element is only shown in detail mode.</i>
hello-time	Parameter type: <SignedInteger> - a signed integer	time between transmission of PDUs on a port when it is the root <i>This element is only shown in detail mode.</i>
fwd-delay	Parameter type: <SignedInteger> - a signed integer	time how long a port stays in a state before moving to the forwarding state <i>This element is only shown in detail mode.</i>
regional-root-id	Parameter type: <Mstp::MstpBridgeId> - the mstp bridge id - length: 8	the bridgeId of the CIST regional root used in the PDUs originated by this node. <i>This element is only shown in detail mode.</i>
regional-root-cost	Parameter type: <Mstp::MstpRootCost> - root cost	cost of the path to the CIST regional Root seen from the bridge <i>This element is only shown in detail mode.</i>
bridge-mac-addr	Parameter type: <Sys::MacAddr> - a mac-address (example : 01:02:03:04:05:06) - length: 6	the bridgeId of the CIST regional root used in the PDUs originated by this node. <i>This element is only shown in detail mode.</i>
root-bridge-chg	Parameter type: <Counter> - 32 bit counter	the bridgeId of the CIST regional root used in the PDUs originated by this node. <i>This element is only shown in detail mode.</i>

171.3 MSTP Instance Status Command

Command Description

This command displays all parameters of a multiple spanning tree instance.

User Level

The command can be accessed by operators with mstp privileges.

Command Syntax

The command has the following syntax:

```
> show xstp instance [ (instance) ]
```

Command Parameters

Table 171.3-1 "MSTP Instance Status Command" Resource Parameters

Resource Identifier	Type	Description
(instance)	Format: - MSTP Instance - range: [1...64]	mstp instance number

Command Output

Table 171.3-2 "MSTP Instance Status Command" Display parameters

Specific Information		
name	Type	Description
root-cost	Parameter type: <Mstp::MstpRootCost> - root cost	cost of the path to the MSTI Regional Root seen by the bridge <i>This element is always shown.</i>
root-port	Parameter type: <Itf::LaGroupZeroIndex> (none <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId>) Possible values: - none : no port Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number	port which offers the lowest path cost to the MSTI Region Root bridge <i>This element is always shown.</i>
regional-root-id	Parameter type: <Mstp::MstpBridgeId>	the bridgeId of the MSTI regional

171 MSTP Status Commands

name	Type	Description
	- the mstp bridge id - length: 8	root id used in the PDUs originated by this node. <i>This element is always shown.</i>
root-bridge-chg	Parameter type: <Counter> - 32 bit counter	The number of times this Bridge has detected a Root Bridge change for this spanning tree instance. <i>This element is only shown in detail mode.</i>

171.4 MSTP Network Port Status Command

Command Description

This command displays all mstp port information.

User Level

The command can be accessed by operators with mstp privileges.

Command Syntax

The command has the following syntax:

```
> show xstp port [ (port) ]
```

Command Parameters

Table 171.4-1 "MSTP Network Port Status Command" Resource Parameters

Resource Identifier	Type	Description
(port)	Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number	interface index of the lag

Command Output

Table 171.4-2 "MSTP Network Port Status Command" Display parameters

Specific Information		
name	Type	Description
state	Parameter type: <Mstp::MstpPortState> (disabled discarding learning forwarding) Possible values: - disabled : disabled - discarding : discarding - learning : learning - forwarding : forwarding	state of the port <i>This element is always shown.</i>

name	Type	Description
p2p-port	Parameter type: <Mstp::Boolean> (yes no) Possible values: - yes : true - no : false	point-to-point status of the LAN segment <i>This element is always shown.</i>
edge-port	Parameter type: <Mstp::Boolean> (yes no) Possible values: - yes : true - no : false	operational value of the edge port parameter <i>This element is always shown.</i>
designated-root	Parameter type: <Mstp::MstpBridgeId> - the mstp bridge id - length: 8	bridge identifier of the MSTI regional root <i>This element is always shown.</i>
designated-port	Parameter type: <Mstp::DesignatedPort> - designated port 2 byte octet string - length: 2	port identifier of the port on the designated bridge <i>This element is always shown.</i>
designated-bridge	Parameter type: <Mstp::MstpBridgeId> - the mstp bridge id - length: 8	bridge identifier of designated bridge <i>This element is always shown.</i>
designated-cost	Parameter type: <Mstp::MstpShowPathCost> - port designated path cost	path cost of the designated port <i>This element is always shown.</i>
current-port-role	Parameter type: <Mstp::MstpCistPortRole> (disabled alternate backup root designated) Possible values: - disabled : disabled - alternate : alternate - backup : backup - root : root - designated : designated	current port role of the port for this spanning tree instance <i>This element is always shown.</i>
selected-port-role	Parameter type: <Mstp::MstpCistPortRole> (disabled alternate backup root designated) Possible values: - disabled : disabled - alternate : alternate - backup : backup - root : root - designated : designated	selected port role of the port for this spanning tree instance <i>This element is always shown.</i>
regional-path-cost	Parameter type: <Mstp::MstpShowPathCost> - port designated path cost	contribution of this port to the path cost <i>This element is only shown in detail mode.</i>
regional-root	Parameter type: <Mstp::MstpBridgeId> - the mstp bridge id - length: 8	bridge id of the bridge recorded as the CIST Regional Root <i>This element is only shown in detail mode.</i>
bpdu-tx	Parameter type: <Counter> - 32 bit counter	BPDUs transmitted on this port for this spanning tree instance

171 MSTP Status Commands

name	Type	Description
		<i>This element is only shown in detail mode.</i>
bpdu-rx	Parameter type: <Counter> - 32 bit counter	<i>This element is only shown in detail mode.</i>
bpdu-invalid-rx	Parameter type: <Counter> - 32 bit counter	invalid BPDUs received on this port <i>This element is only shown in detail mode.</i>
prot-migration	Parameter type: <Counter> - 32 bit counter	migration count from one STP protocol version to another <i>This element is only shown in detail mode.</i>

171.5 MSTP Port Instance Status Command

Command Description

This command displays all mstp port instances.

User Level

The command can be accessed by operators with mstp privileges.

Command Syntax

The command has the following syntax:

```
> show xstp port-instance [ (port) [ instance <Mstp::MstpInstance> ] ]
```

Command Parameters

Table 171.5-1 "MSTP Port Instance Status Command" Resource Parameters

Resource Identifier	Type	Description
(port)	Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number	interface index of the lag
instance	Parameter type: <Mstp::MstpInstance> Format: - MSTP Instance - range: [1...64]	mstp instance

Command Output

Table 171.5-2 "MSTP Port Instance Status Command" Display parameters

Specific Information		
name	Type	Description
state	Parameter type: <Mstp::MstpPortState> (disabled discarding learning forwarding) Possible values:	state of the port <i>This element is always shown.</i>

171 MSTP Status Commands

name	Type	Description
	- disabled : disabled - discarding : discarding - learning : learning - forwarding : forwarding	
designated-root	Parameter type: <Mstp::MstpBridgeId> - the mstp bridge id - length: 8	bridge identifier of the MSTI regional root <i>This element is always shown.</i>
designated-bridge	Parameter type: <Mstp::MstpBridgeId> - the mstp bridge id - length: 8	bridge identifier of designated bridge <i>This element is always shown.</i>
designated-port	Parameter type: <Mstp::DesignatedPort> - designated port 2 byte octet string - length: 2	port identifier of the port on the designated bridge <i>This element is always shown.</i>
designated-cost	Parameter type: <Mstp::MstpShowPathCost> - port designated path cost	path cost of the designated port <i>This element is always shown.</i>
current-port-role	Parameter type: <Mstp::MstpMstiPortRole> (disabled alternate backup root designated master) Possible values: - disabled : disabled - alternate : alternate - backup : backup - root : root - designated : designated - master : master	current port role of the port for this spanning tree instance <i>This element is always shown.</i>
selected-port-role	Parameter type: <Mstp::MstpMstiPortRole> (disabled alternate backup root designated master) Possible values: - disabled : disabled - alternate : alternate - backup : backup - root : root - designated : designated - master : master	selected port role of the port for this spanning tree instance <i>This element is always shown.</i>
bpdu-tx	Parameter type: <Counter> - 32 bit counter	BPDUs transmitted on this port for this spanning tree instance <i>This element is only shown in detail mode.</i>
bpdu-rx	Parameter type: <Counter> - 32 bit counter	<i>This element is only shown in detail mode.</i>
bpdu-invalid-rx	Parameter type: <Counter> - 32 bit counter	invalid BPDUs received on this port <i>This element is only shown in detail mode.</i>
fwd-transition	Parameter type: <Counter> - 32 bit counter	transition count to the forwarding state <i>This element is only shown in detail mode.</i>

172- *Application Intelligence Status Commands*

172.1 Application Intelligence Status Command Tree	172-6871
172.2 Application show command	172-6872
172.3 AI Platform show command	172-6874
172.4 Application 'download and installation' show command	172-6876

172.1 Application Intelligence Status Command Tree

Description

This chapter gives an overview of nodes that are handled by "Application Intelligence Status Commands".

Command Tree

```
----show
  ----ai
    ----application
      - (application)
    ----platform
      - (slot)
      - virtualplatform
    ----platform-application
      - (slot)
      - virtualplatform
      - application
```

172.2 Application show command

Command Description

This command is used to show the operational data related to an Application.

A usagecounter displays the number of times this Application is configured for download and installation on AI Platforms.

Note that the command displays also an Application number. The number is assigned by the system itself. This number is used when assigning a unique identification to Application related alarms. When used, then the Application name itself will also be available in the alarm as additional-info.

User Level

The command can be accessed by operators with ai privileges.

Command Syntax

The command has the following syntax:

> show ai application [(application)]

Command Parameters

Table 172.2-1 "Application show command" Resource Parameters

Resource Identifier	Type	Description
(application)	Format: - a name for the Application - range: [a-zA-Z0-9!#\$%&()*+-./:;=?@[]~] - length: 1<=x<=31	The name of the Application

Command Output

Table 172.2-2 "Application show command" Display parameters

Specific Information		
name	Type	Description
number	Parameter type: <AI::SignedShort> - An unsigned integer (0..65535) - range: [0...65535]	a unique number assigned to the Application <i>This element is always shown.</i>
usagecounter	Parameter type: <AI::Counter> - an unsigned integer	counts the requests for installation and download of the Application on AI Platforms <i>This element is always shown.</i>
embeddedname	Parameter type: <AI::ApplicationName> - a name for the Application - range: [a-zA-Z0-9!#\$%&()*+-./:;=?@[]~] - length: 1<=x<=31	the name available in the Application SW package itself <i>This element is always shown.</i>

172.3 AI Platform show command

Command Description

This command is used to show operational data related to the AI Platform.

User Level

The command can be accessed by operators with ai privileges.

Command Syntax

The command has the following syntax:

```
> show ai platform [ (slot) [ virtualplatform <AI::VirtualPlatform> ] ]
```

Command Parameters

Table 172.3-1 "AI Platform show command" Resource Parameters

Resource Identifier	Type	Description
(slot)	Format: (nt-a nt-b) Possible values: - nt-a : nt-a slot - nt-b : nt-b slot	slot Id of the AI Platform
virtualplatform	Parameter type: <AI::VirtualPlatform> Format: - AI Virtual Platform Index within the Slot - range: [1]	virtual Id within the slot of the AI Platform

Command Output

Table 172.3-2 "AI Platform show command" Display parameters

Specific Information		
name	Type	Description
adminstate	Parameter type: <AI::AdminState> (unlocked locked) Possible values: - unlocked : The identified resource is allowed to be used - locked : The identified resource is not allowed to be used	determines if the AI Platform shall be started up <i>This element is always shown.</i>
operstate	Parameter type: <AI::OperState> (enabled disabled) Possible values: - enabled : The identified resource is operational	operational state of the AI Platform <i>This element is always shown.</i>

name	Type	Description
	- disabled : The identified resource is not operational or the status is not known	
oamadminstate	Parameter type: <AI::AdminState> (unlocked locked) Possible values: - unlocked : The identified resource is allowed to be used - locked : The identified resource is not allowed to be used	determines if an external OAM mngt interface shall be provided <i>This element is always shown.</i>
oamoperstate	Parameter type: <AI::OperState> (enabled disabled) Possible values: - enabled : The identified resource is operational - disabled : The identified resource is not operational or the status is not known	operational state of the external OAM IP interface <i>This element is always shown.</i>

172.4 Application 'download and installation' show command

Command Description

This command is used to show the status of the download and installation of an Application on a specified AI Platform.

User Level

The command can be accessed by operators with ai privileges.

Command Syntax

The command has the following syntax:

```
> show ai platform-application [ (slot) [ virtualplatform <AI::VirtualPlatform> ] [ application <AI::ApplicationName> ] ]
```

Command Parameters

Table 172.4-1 "Application 'download and installation' show command" Resource Parameters

Resource Identifier	Type	Description
(slot)	Format: (nt-a nt-b) Possible values: - nt-a : nt-a slot - nt-b : nt-b slot	slot Id of the AI Platform
virtualplatform	Parameter type: <AI::VirtualPlatform> Format: - AI Virtual Platform Index within the Slot - range: [1]	virtual Id within the slot of the AI Platform
application	Parameter type: <AI::ApplicationName> Format: - a name for the Application - range: [a-zA-Z0-9!#\$%&()*+-./:;=?@[]_~] - length: 1<=x<=31	the unique Application name

Command Output

Table 172.4-2 "Application 'download and installation' show command" Display parameters

Specific Information		
name	Type	Description
adminstate	Parameter type: <AI::AdminState>	determines if the Application

name	Type	Description
	(unlocked locked) Possible values: - unlocked : The identified resource is allowed to be used - locked : The identified resource is not allowed to be used	shall be downloaded and installed <i>This element is always shown.</i>
installstate	Parameter type: <AI::InstallState> (noaction successful scheduled inprogress perm-fail) Possible values: - noaction : There is no ongoing action to download/install the Application - successful : The Application is successfully downloaded and installed - scheduled : The Application is scheduled to be downloaded - inprogress : A download/installation of the application is ongoing - perm-fail : An attempt to download/install the application failed with a non-recoverable reason	state of the Application download and installation <i>This element is always shown.</i>
err-reason	Parameter type: <PrintableString> - printable string	error reason for the Application download and/or installation <i>This element is always shown.</i>

173- Distributed Service Status Commands

173.1 Distributed Service Status Command Tree	173-6879
173.2 Service Access Mapping Status Command	173-6880
173.3 APIPE-PVC Statistics Command	173-6882

173.1 Distributed Service Status Command Tree

Description

This chapter gives an overview of nodes that are handled by "Distributed Service Status Commands".

Command Tree

```
----show
  ----dist-service
    ----accessport-svc
      - (access-port)
    ----statistics
      ----apipe-pvc
        - (port-index)
```

173.2 Service Access Mapping Status Command

Command Description

This command displays the Service Access Mapping to operator.

User Level

The command can be accessed by operators with drouter privileges.

Command Syntax

The command has the following syntax:

```
> show dist-service accessport-svc [ (access-port) ]
```

Command Parameters

Table 173.2-1 "Service Access Mapping Status Command " Resource Parameters

Resource Identifier	Type	Description
(access-port)	Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::VpiId> : <Eqpt::VciId> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> / <Eqpt::OntPortId> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / voip) Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number Field type <Eqpt::VpiId> - atm VPI Field type <Eqpt::VciId> - atm VCI Field type <Eqpt::PonId> - the PON identifier Field type <Eqpt::OntId> - the ONT identifier Possible values: - voip : virtual uni identifier Field type <Eqpt::OntSlotId>	access port index

Resource Identifier	Type	Description
	- the ONT SLOT identifier Field type <Eqpt::OntPortId> - the ONT PORT identifier	

Command Output

Table 173.2-2 "Service Access Mapping Status Command " Display parameters

Specific Information		
name	Type	Description
service-id	Parameter type: <Drouter::ServiceId> - Service ID - range: [1...2147483647]	specifies the service id mapped to access port. <i>This element is always shown.</i>

173.3 APIPE-PVC Statistics Command

Command Description

This command displays the APIPE-PVC statistics.

User Level

The command can be accessed by operators with drouter privileges.

Command Syntax

The command has the following syntax:

```
> show dist-service statistics apipe-pvc [ (port-index) ]
```

Command Parameters

Table 173.3-1 "APIPE-PVC Statistics Command" Resource Parameters

Resource Identifier	Type	Description
(port-index)	Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::VpiMandatoryId> : <Eqpt::VciMandatoryId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number Field type <Eqpt::VpiMandatoryId> - atm VPI Field type <Eqpt::VciMandatoryId> - atm VCI	the ATM PVC

Command Output

Table 173.3-2 "APIPE-PVC Statistics Command" Display parameters

Specific Information		
name	Type	Description
apipe-tot-in-cells	Parameter type: <Counter> - 32 bit counter	The total number of valid ATM cells received by this VCL including both CLP=0 and CLP=1 cells. <i>This element is always shown.</i>

name	Type	Description
apipe-tot-out-cells	Parameter type: <Counter> - 32 bit counter	The total number of valid ATM cells transmitted by this VCL. This includes both CLP=0 and CLP=1 cells. <i>This element is always shown.</i>
apipe-us-disc	Parameter type: <Counter> - 32 bit counter	The total number of ATM cells that are discarded in the upstream direction. <i>This element is always shown.</i>
apipe-ds-disc	Parameter type: <Counter> - 32 bit counter	The total number of ATM cells that are discarded in the downstream direction. <i>This element is always shown.</i>

174- IPv6 Users Status Commands

174.1 IPv6 Users Status Command Tree	174-6885
174.2 IPv6 Users Status Command	174-6886

174.1 IPv6 Users Status Command Tree

Description

This chapter gives an overview of nodes that are handled by "IPv6 Users Status Commands".

Command Tree

```
----show
  ----ipv6
    ----users
      - (client)
      - prefixandlength
```

174.2 IPv6 Users Status Command

Command Description

This command displays the ipv6 users information.

User Level

The command can be accessed by operators with ip privileges.

Command Syntax

The command has the following syntax:

```
> show ipv6 users [ (client) [ prefixandlength <ipv6::PrefixAndLength> ] ]
```

Command Parameters

Table 174.2-1 "IPv6 Users Status Command" Resource Parameters

Resource Identifier	Type	Description
(client)	Format: (vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::VpiId> : <Eqpt::VciId> : <Eqpt::UnstackedVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::UnstackedVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::VpiId> : <Eqpt::VciId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> / <Eqpt::OntPortId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> / <Eqpt::OntPortId> : <Eqpt::UnstackedVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / voip : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / vuni : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / voip : <Eqpt::UnstackedVlan>	The index value that uniquely identifies the interface on which this prefix is configured

Resource Identifier	Type	Description
	vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / vuni : <Eqpt::UnstackedVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::LLId> : <Eqpt::UnstackedVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::LLId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan-port:ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Ng2::OntId> / <Eqpt::Ng2OntSlotId> / <Eqpt::Ng2OntPortId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan-port:ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Ng2::OntId> / <Eqpt::Ng2OntSlotId> / <Eqpt::Ng2OntPortId> : <Eqpt::UnstackedVlan> vlan-port:ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Ng2::OntId> / vuni : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan-port:ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Ng2::OntId> / vuni : <Eqpt::UnstackedVlan>) Possible values: - vlan-port : vlan port - vlan-port:ng2 : ngpon2 vlan port Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number Field type <Eqpt::VpiId> - atm VPI Field type <Eqpt::VcId> - atm VCI Field type <Eqpt::PonId> - the PON identifier Field type <Eqpt::OntId> - the ONT identifier Field type <Eqpt::ChannelGroupId> - the channel group identifier Field type <Eqpt::SubChannelGroupId> - the subchannel group identifier Field type <Ng2::OntId> - the ONT identifier Possible values: - voip : virtual uni identifier obsolete alternative replaced by vuni - vuni : virtual uni identifier Possible values: - vuni : virtual NGPON2 uni identifier Field type <Eqpt::OntSlotId> - the ONT SLOT identifier Field type <Eqpt::OntPortId>	

Resource Identifier	Type	Description
	- the ONT PORT identifier Field type <Eqpt::Ng2OntSlotId> - the NGPON2 ONT SLOT identifier Field type <Eqpt::Ng2OntPortId> - the NGPON2 ONT PORT identifier Field type <Eqpt::LLId> - the LLID identifier, range 1 for EPON, range 1-8 for DPOE Possible values: - stacked : stacked vlan identity Field type <Eqpt::UnstackedVlan> - unstacked vlan id Field type <Eqpt::SVlan> - service vlan id Field type <Eqpt::CVlan> - customer vlan id	
prefixandlength	Parameter type: <ipv6::PrefixAndLength> Format: <ipv6::Prefix> / <ipv6::PrefixLength> Field type <ipv6::Prefix> - IPv6-address Field type <ipv6::PrefixLength> - length of IPv6 address or prefix - range: [0...128]	client ipv6 prefix assigned by dhcp server

Command Output

Table 174.2-2 "IPv6 Users Status Command" Display parameters

Specific Information		
name	Type	Description
prefixorigin	Parameter type: <ipv6::PrefixOrigin> (other manual wellknown dhcp routeradv) Possible values: - other : indicates a prefix that acquired by other ways - manual : indicates a prefix that was manually configured - wellknown : indicates a well-known prefix - dhcp : indicates a prefix that was assigned by a DHCP - routeradv : indicates a prefix learned from a router advertisement	the origin of this prefix <i>This element is always shown.</i>
validlifetime	Parameter type: <ipv6::PrefixAdvValidLifetime> (session-being-deleted <ipv6::PrefixAdvValidLifetime>) Possible values: - session-being-deleted : session being deleted Field type <ipv6::PrefixAdvValidLifetime> - The remaining length of time, in seconds, that this prefix will continue to be valid - unit: sec - range: [0...4294967295]	the remaining length of time, in seconds, that this prefix will continue to be valid <i>This element is always shown.</i>
forwarderid	Parameter type: <Vlan::StackedVlan> (<Vlan::UVlanIndex> stacked : <Vlan::SVlanIndex> : <Vlan::CVlanIndex>) Possible values:	the id of the forwarder to which this session belongs <i>This element is always shown.</i>

name	Type	Description
	- stacked : stacked vlan identity Field type <Vlan::UVlanIndex> - unstacked vlan identity - range: [1...4093,4096] Field type <Vlan::SVlanIndex> - service vlan identity - range: [2...4093,4094] Field type <Vlan::CVlanIndex> - customer vlan identity - range: [0...4093,4094,4095,4096]	

175- Bcmp Statistics Commands

175.1 Bcmp Statistics Command Tree	175-6891
175.2 Bcmp Statistics Command	175-6892

175.1 Bcmp Statistics Command Tree

Description

This chapter gives an overview of nodes that are handled by "Bcmp Statistics Commands".

Command Tree

```
----show
  ----bcmp
    ----counters
      - (epon-ont-idx)
```

175.2 Bcmp Statistics Command

Command Description

This command displays the bcmp counters from user side.

User Level

The command can be accessed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

```
> show bcmp counters [ (epon-ont-idx) ]
```

Command Parameters

Table 175.2-1 "Bcmp Statistics Command" Resource Parameters

Resource Identifier	Type	Description
(epon-ont-idx)	Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Eqpt::OntId> - the ONT identifier	the index value that uniquely identifies the EPON ONU

Command Output

Table 175.2-2 "Bcmp Statistics Command" Display parameters

Specific Information		
name	Type	Description
rx-reg-cnt	Parameter type: <Counter> - 32 bit counter	the number of Rx BCMP Register packets <i>This element is always shown.</i>
rx-tick-cnt	Parameter type: <Counter> - 32 bit counter	the counter of Rx BCMP TICK packets <i>This element is always shown.</i>
tx-reg-res-cnt	Parameter type: <Counter> - 32 bit counter	the counter of Rx BCMP Response packets

175 Bcmp Statistics Commands

name	Type	Description
		<i>This element is always shown.</i>
tx-para-chg-cnt	Parameter type: <Counter> - 32 bit counter	the counter of Rx BCMP Parameter Change packets <i>This element is always shown.</i>
rx-discard-cnt	Parameter type: <Counter> - 32 bit counter	the counter of Rx BCMP Discard packets <i>This element is always shown.</i>

176- E1 Line Operational status Commands

176.1 E1 Line Operational status Command Tree	176-6895
176.2 E1 line status Command	176-6896
176.3 E1 diagnostic status Command	176-6898

176.1 E1 Line Operational status Command Tree

Description

This chapter gives an overview of nodes that are handled by "E1 Line Operational status Commands".

Command Tree

```
----show
  ----e1
    ----line-status
      - (if-index)
    ----diagnostest-status
      - (if-index)
```

176.2 E1 line status Command

Command Description

This command display the E1 line operational status.

User Level

The command can be accessed by operators with xdsl privileges.

Command Syntax

The command has the following syntax:

```
> show e1 line-status [ (if-index) ]
```

Command Parameters

Table 176.2-1 "E1 line status Command" Resource Parameters

Resource Identifier	Type	Description
(if-index)	Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number	interface index of the port

Command Output

Table 176.2-2 "E1 line status Command" Display parameters

Specific Information		
name	Type	Description
data-rate	Parameter type: <E1::DataRate> - the actual data rate retrieved on the E1 interface - range: [0...2048]	Retrieves the actual data rate on the e1 interface <i>This element is always shown.</i>
line-coding	Parameter type: <E1::LineCoding> (ami hdb3) Possible values: - ami : Specifies Alternate Mark Inversion (AMI) as the linecode type - hdb3 : Specifies High-Density Bipolar 3 (HDB3) as the	the actual Encoding type used by the E1 interface <i>This element is always shown.</i>

name	Type	Description
	linecode type	
framing-mode	Parameter type: <E1::FramingMode> (unframed framed) Possible values: - unframed : Unframed E1 type - framed : Framed E1 type	the actual framing mode configures on the E1 interface <i>This element is always shown.</i>
crc	Parameter type: <E1::Crc> (disable enable) Possible values: - disable : no CRC4 - enable : Enable CRC4	the actual CRC configures on the E1 interface <i>This element is always shown.</i>
multi-framing	Parameter type: <E1::MultiFraming> (disable enable) Possible values: - disable : No multi framing - enable : Enable multi framing	specifies multiframing mode is used or not <i>This element is always shown.</i>
transmit-clk-src	Parameter type: <E1::TransmitClkSrc> (external internal) Possible values: - external : Specifies that the network clock source is used - internal : Specifies that the internal clock source is used	specifies clock source used by the e1 interface <i>This element is always shown.</i>
oper-status	Parameter type: <E1::OperationalStatus> (active no-active) Possible values: - active : Specifies the line is in active state - no-active : Specifies the line is in not in service	shows the line operational status of the e1 interface <i>This element is always shown.</i>
line-impedance	Parameter type: <E1::LineImpedance> (75ohms 120ohms) Possible values: - 75ohms : indicates the line impedance value unbalanced 75ohms - 120ohms : indicates the line impedance value balanced 120 ohms	Retrieves the Nominal line impedance value <i>This element is always shown.</i>

176.3 E1 diagnostic status Command

Command Description

This command display the E1 line diagnostic test status.

User Level

The command can be accessed by operators with xdsl privileges.

Command Syntax

The command has the following syntax:

```
> show e1 diagnostest-status [ (if-index) ]
```

Command Parameters

Table 176.3-1 "E1 diagnostic status Command" Resource Parameters

Resource Identifier	Type	Description
(if-index)	Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number	interface index of the port

Command Output

Table 176.3-2 "E1 diagnostic status Command" Display parameters

Specific Information		
name	Type	Description
bertest-status	Parameter type: <E1::BERTestStatus> (none running aborted completed) Possible values: - none : no test started - running : BERT started and running - aborted : BERT aborted before completion - completed : BERT completed	the current status of the BER test <i>This element is always shown.</i>

name	Type	Description
ber-testpattern	Parameter type: <E1::BERTestPattern> (framed-twopow11 framed-twopow15 unframed-twopow11 unframed-twopow15 none) Possible values: - framed-twopow11 : Framed Pseudo-random repeating test pattern with 2 ¹¹ bits - framed-twopow15 : Framed Pseudo-random repeating test pattern with 2 ¹⁵ bits - unframed-twopow11 : Unframed Pseudo-random repeating test pattern with 2 ¹¹ bits - unframed-twopow15 : Unframed Pseudo-random repeating test pattern with 2 ¹⁵ bits - none : No-Pattern	the actual BER test pattern used to preform the BER test <i>This element is always shown.</i>
ber-elapsedtime	Parameter type: <E1::BERTimeElapsed> - Maximum time allowed to perform BER test - range: [0...245700]	Time elapsed <i>This element is always shown.</i>
ber-biterror	Parameter type: <E1::BERBitError> - Number of bit error	Number of bit error <i>This element is always shown.</i>
ber-bitreceived	Parameter type: <E1::BERBitReceived> - Number of bit received	Number of bit received <i>This element is always shown.</i>
loop-back	Parameter type: <E1::LoopBackType> (no-loop local-payload remote-payload remote-line local-line) Possible values: - no-loop : no loopback - local-payload : LOCAL-Payload - remote-payload : Remote-payload - remote-line : Remote-line - local-line : Local-Line	the actual loop back type used by the e1 interface <i>This element is always shown.</i>

177- E1 Line Counters Command

177.1 E1 Line Counters Command Tree	177-6901
177.2 E1 Current Interval Performance Data Status Command	177-6902
177.3 E1 Current 1 Day Performance Data Status Command	177-6904
177.4 E1 Previous Interval Performance Data Status Command	177-6906
177.5 E1 Previous 1 Day Performance Data Status Command	177-6908

177.1 E1 Line Counters Command Tree

Description

This chapter gives an overview of nodes that are handled by "E1 Line Counters Command".

Command Tree

```
----show
  ----e1-counters
    ----current-interval
      - (if-index)
      - side
    ----current-1day
      - (if-index)
      - side
    ----previous-interval
      - (if-index)
      - side
      - int-no
    ----previous-1day
      - (if-index)
      - side
      - int-no
```

177.2 E1 Current Interval Performance Data Status Command

Command Description

This command displays the current interval performance data of an E1 interface.

User Level

The command can be accessed by operators with xdsl privileges.

Command Syntax

The command has the following syntax:

```
> show e1-counters current-interval [ (if-index) [ side <E1::SegmentSide> ] ]
```

Command Parameters

Table 177.2-1 "E1 Current Interval Performance Data Status Command" Resource Parameters

Resource Identifier	Type	Description
(if-index)	Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number	interface index of the port
side	Parameter type: <E1::SegmentSide> Format: near-end Possible values: - near-end : the near end side	the particular side of an SHDSL unit in an SHDSL segment

Command Output

Table 177.2-2 "E1 Current Interval Performance Data Status Command" Display parameters

Specific Information		
name	Type	Description
eles	Parameter type: <Counter> - 32 bit counter	number of errored seconds <i>This element is always shown.</i>

name	Type	Description
e1ses	Parameter type: <Counter> - 32 bit counter	number of severely errored seconds <i>This element is always shown.</i>
e1sefs	Parameter type: <Counter> - 32 bit counter	number of severely errored framed seconds <i>This element is always shown.</i>
e1uas	Parameter type: <Counter> - 32 bit counter	number of unavailable seconds <i>This element is always shown.</i>
e1css	Parameter type: <Counter> - 32 bit counter	number of controlled slip seconds <i>This element is always shown.</i>
e1pcv	Parameter type: <Counter> - 32 bit counter	number of path code violation <i>This element is always shown.</i>
e1les	Parameter type: <Counter> - 32 bit counter	number of line error seconds <i>This element is always shown.</i>
e1bes	Parameter type: <Counter> - 32 bit counter	number of bursty error seconds <i>This element is always shown.</i>
e1lcv	Parameter type: <Counter> - 32 bit counter	number of line code violation <i>This element is always shown.</i>
e1va-int	Parameter type: <E1::IntervalNumber> - performance Data Interval number - range: [0...96]	the number of previous intervals for which data has been stored <i>This element is always shown.</i>
e1inv-flag	Parameter type: <E1::IntervalInvalidDataFlag> (true false) Possible values: - true : data is not valid - false : data is valid	validity flag of the corresponding PM data in current 15 minutes <i>This element is always shown.</i>
e1time-elapsed	Parameter type: <E1::TimeElapsed> - Monitored Seconds - range: [0...86400]	Time elapsed <i>This element is always shown.</i>

177.3 E1 Current 1 Day Performance Data Status Command

Command Description

This command displays the current 1 day performance data of an E1 interface.

User Level

The command can be accessed by operators with xdsl privileges.

Command Syntax

The command has the following syntax:

```
> show e1-counters current-1day [ (if-index) [ side <E1::SegmentSide> ] ]
```

Command Parameters

Table 177.3-1 "E1 Current 1 Day Performance Data Status Command" Resource Parameters

Resource Identifier	Type	Description
(if-index)	Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number	interface index of the port
side	Parameter type: <E1::SegmentSide> Format: near-end Possible values: - near-end : the near end side	the particular side of an SHDSL unit in an SHDSL segment

Command Output

Table 177.3-2 "E1 Current 1 Day Performance Data Status Command" Display parameters

Specific Information		
name	Type	Description
eles	Parameter type: <Counter> - 32 bit counter	number of errored seconds <i>This element is always shown.</i>

name	Type	Description
e1ses	Parameter type: <Counter> - 32 bit counter	number of severely errored seconds <i>This element is always shown.</i>
e1sefs	Parameter type: <Counter> - 32 bit counter	number of severely errored seconds <i>This element is always shown.</i>
e1uas	Parameter type: <Counter> - 32 bit counter	number of unavailable seconds <i>This element is always shown.</i>
e1css	Parameter type: <Counter> - 32 bit counter	number of unavailable seconds <i>This element is always shown.</i>
e1pcv	Parameter type: <Counter> - 32 bit counter	number of unavailable seconds <i>This element is always shown.</i>
e1les	Parameter type: <Counter> - 32 bit counter	number of unavailable seconds <i>This element is always shown.</i>
e1bes	Parameter type: <Counter> - 32 bit counter	number of unavailable seconds <i>This element is always shown.</i>
e1lcv	Parameter type: <Counter> - 32 bit counter	number of unavailable seconds <i>This element is always shown.</i>
e1va-int	Parameter type: <E1::IntervalNumber> - performance Data Interval number - range: [0...96]	the number of previous intervals for which data has been stored <i>This element is always shown.</i>
e1inv-flag	Parameter type: <E1::IntervalInvalidDataFlag> (true false) Possible values: - true : data is not valid - false : data is valid	validity flag of the corresponding PM data in current day <i>This element is always shown.</i>
e1time-elapsed	Parameter type: <E1::TimeElapsed> - Monitored Seconds - range: [0...86400]	Time Elapsed <i>This element is always shown.</i>

177.4 E1 Previous Interval Performance Data Status Command

Command Description

This command displays the previous interval performance data of an E1 interface.

User Level

The command can be accessed by operators with xdsl privileges.

Command Syntax

The command has the following syntax:

```
> show e1-counters previous-interval [ (if-index) [ side <E1::SegmentSide> ] [ int-no <E1::IntervalNumber> ] ]
```

Command Parameters

Table 177.4-1 "E1 Previous Interval Performance Data Status Command" Resource Parameters

Resource Identifier	Type	Description
(if-index)	Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number	interface index of the port
side	Parameter type: <E1::SegmentSide> Format: near-end Possible values: - near-end : the near end side	the particular side of an SHDSL unit in an SHDSL segment
int-no	Parameter type: <E1::IntervalNumber> Format: - performance Data Interval number - range: [0...96]	the performance interval number

Command Output

Table 177.4-2 "E1 Previous Interval Performance Data Status Command" Display parameters

Specific Information		
name	Type	Description
elmonsecs	Parameter type: <E1::MoniSecs> - Monitored Seconds - range: [0...86400]	The amount of time in the 15-Min interval over which the performance monitoring information is actually counted <i>This element is always shown.</i>
e1es	Parameter type: <Counter> - 32 bit counter	number of errored seconds <i>This element is always shown.</i>
e1ses	Parameter type: <Counter> - 32 bit counter	number of severely errored seconds <i>This element is always shown.</i>
e1sefs	Parameter type: <Counter> - 32 bit counter	number of severely errored framed seconds <i>This element is always shown.</i>
e1uas	Parameter type: <Counter> - 32 bit counter	number of unavailable seconds <i>This element is always shown.</i>
e1css	Parameter type: <Counter> - 32 bit counter	number of controlled slip seconds <i>This element is always shown.</i>
e1pcv	Parameter type: <Counter> - 32 bit counter	number of path code violation <i>This element is always shown.</i>
e1les	Parameter type: <Counter> - 32 bit counter	number of line error seconds <i>This element is always shown.</i>
e1bes	Parameter type: <Counter> - 32 bit counter	number of bursty error seconds <i>This element is always shown.</i>
e1lcv	Parameter type: <Counter> - 32 bit counter	number of line code violation <i>This element is always shown.</i>
e1inv-flag	Parameter type: <E1::IntervalInvalidDataFlag> (true false) Possible values: - true : data is not valid - false : data is valid	validity flag of the corresponding PM data in current 15 minutes <i>This element is always shown.</i>
e1time-stamp	Parameter type: <Xdsl::PmTimeStamp> - Timestamp for Pm interval(yyyymmdd:hour:minutes)	indicates the start of the interval <i>This element is always shown.</i>

177.5 E1 Previous 1 Day Performance Data Status Command

Command Description

This command displays the previous 1 day performance data of an E1 interface.

User Level

The command can be accessed by operators with xdsl privileges.

Command Syntax

The command has the following syntax:

```
> show e1-counters previous-1day [ (if-index) [ side <E1::SegmentSide> ] [ int-no <E1::Interval1DayNumber> ] ]
```

Command Parameters

Table 177.5-1 "E1 Previous 1 Day Performance Data Status Command" Resource Parameters

Resource Identifier	Type	Description
(if-index)	Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number	interface index of the port
side	Parameter type: <E1::SegmentSide> Format: near-end Possible values: - near-end : the near end side	the particular side of an SHDSL unit in an SHDSL segment
int-no	Parameter type: <E1::Interval1DayNumber> Format: - a performance interval one day number - range: [1...30]	the performance interval number

Command Output

Table 177.5-2 "E1 Previous 1 Day Performance Data Status Command" Display parameters

Specific Information		
name	Type	Description
elmonsecs	Parameter type: <E1::PreviousInterval1DayMoniSecs> - Monitored Seconds - range: [0...86410]	The amount of time in the 1 day interval over which the performance monitoring information is actually counted <i>This element is always shown.</i>
e1es	Parameter type: <Counter> - 32 bit counter	number of errored seconds <i>This element is always shown.</i>
e1ses	Parameter type: <Counter> - 32 bit counter	number of severely errored seconds <i>This element is always shown.</i>
e1sefs	Parameter type: <Counter> - 32 bit counter	number of severely errored seconds <i>This element is always shown.</i>
e1uas	Parameter type: <Counter> - 32 bit counter	number of unavailable seconds <i>This element is always shown.</i>
e1css	Parameter type: <Counter> - 32 bit counter	number of unavailable seconds <i>This element is always shown.</i>
e1pcv	Parameter type: <Counter> - 32 bit counter	number of unavailable seconds <i>This element is always shown.</i>
e1les	Parameter type: <Counter> - 32 bit counter	number of unavailable seconds <i>This element is always shown.</i>
e1bes	Parameter type: <Counter> - 32 bit counter	number of unavailable seconds <i>This element is always shown.</i>
e1lcv	Parameter type: <Counter> - 32 bit counter	number of unavailable seconds <i>This element is always shown.</i>
e1inv-flag	Parameter type: <E1::IntervalInvalidDataFlag> (true false) Possible values: - true : data is not valid - false : data is valid	validity flag of the corresponding PM data in current day <i>This element is always shown.</i>
e1time-stamp	Parameter type: <Xdsl::PmTimeStamp> - Timestamp for Pm interval(yyyymmdd:hour:minutes)	specifies the start time of interval <i>This element is always shown.</i>

178- Dual-Parenting Protection Group Status Commands

178.1 Dual-Parenting Protection Group Status Command Tree	178-6911
--	----------

178.1 Dual-Parenting Protection Group Status

Command Tree

Description

This chapter gives an overview of nodes that are handled by "Dual-Parenting Protection Group Status Commands".

Command Tree

```
----show
  ----dual-parenting
```

179- Dual-Parenting Protection Group Status Commands

179.1 Dual-Parenting Protection Group Status Command Tree	179-6913
179.2 Dual-Parenting Protection Group Status Commands	179-6914

179.1 Dual-Parenting Protection Group Status

Command Tree

Description

This chapter gives an overview of nodes that are handled by "Dual-Parenting Protection Group Status Commands".

Command Tree

```
----show
  ----dual-parenting
    ----protection-group
      - (local-port-index)
```

179.2 Dual-Parenting Protection Group Status Commands

Command Description

This commands shows the dual-parenting protection group status. The following information is shown for each group :

- *local-port-index*: describes local-port in the dual-parenting protection group.
- *prot-type*: describes the protection type of the dual-parenting protection group.
- *peer-node-name*: describes the peer-node-name in the dual-parenting protection group.
- *protection-group-id*: describes the protection group id of the in the dual-parenting protection group.
- *local-port-state*: describes the the operational status of the local-port in dual-parenting protection group.
- *local-node-ip*: describes the the local-node-ip in dual-parenting protection group.
- *peer-node-ip*: describes the peer-node-ip in the dual-parenting protection group.
- *prot-group-status*: describes the connection status.
- *abnormal-reason*: describes the abnormal reason.

User Level

The command can be accessed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

```
> show dual-parenting protection-group [ (local-port-index) ]
```

Command Parameters

Table 179.2-1 "Dual-Parenting Protection Group Status Commands" Resource Parameters

Resource Identifier	Type	Description
(local-port-index)	Format: (pon : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> chpair : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::ChannelPairId>) Possible values: - pon : pon-aid - chpair : chpair-aid Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier	the local port identifier of the dual-parenting in the protection group

Resource Identifier	Type	Description
	Field type <Eqpt::ChannelPairId> - the channel pair identifier	

Command Output

Table 179.2-2 "Dual-Parenting Protection Group Status Commands" Display parameters

Specific Information		
name	Type	Description
prot-type	Parameter type: <Equipm::DualParentProtGrpType> (primary secondary) Possible values: - primary : primary node - secondary : secondary node	show protection group node-type (primary or secondary) <i>This element is always shown.</i>
peer-node-name	Parameter type: <Equipm::DualParentProtGrpPeerNodeName> - a printable string - length: 1<=x<=127	show peer-node-name in the dual-parenting protection group. <i>This element is always shown.</i>
protection-group-id	Parameter type: <SignedInteger> - a signed integer	index of dual-parenting Prot Group Table <i>This element is always shown.</i>
local-port-state	Parameter type: <RedPort::ProtectionStatus> ((active-up act-up) (active-down act-down) (inactive-up inact-up) (inactive-down inact-down)) Possible values: - active-up : - act-up : - active-down : - act-down : - inactive-up : - inact-up : - inactive-down : - inact-down :	specifies the status of the local port in the dual-parenting protection group. <i>This element is always shown.</i>
local-node-ip	Parameter type: <Ip::V4Address> - IPv4-address	specifies the status of the dual-parenting protection group. <i>This element is always shown.</i>
peer-node-ip	Parameter type: <Ip::V4Address> - IPv4-address	specifies the status of the dual-parenting protection group. <i>This element is always shown.</i>
prot-group-status	Parameter type: <RedPort::DualParentProtGroupConnStatus> (null prot-group-disabled prot-group-abnormal prot-group-normal) Possible values: - null : NULL - prot-group-disabled : protection group is disabled - prot-group-abnormal : protection group is abnormal - prot-group-normal : protection group is normal	show dual-parenting protection group status. <i>This element is always shown.</i>
abnormal-reason	Parameter type: <RedPort::DualParentProtGroupAbnormalReason> (no reason checking	abnormal reason for the dual-parenting protection group. <i>This element is always shown.</i>

179 Dual-Parenting Protection Group Status Commands

name	Type	Description
	syncing sync-failed pg-connect-failure pg-info-conflict qos-info-conflict vpmgnt-info-conflict link-failure forced-switch-over port-admin-down board-failure hunting) Possible values: - no reason : no reason - checking : verifying static data by apps - syncing : bulksync processing - sync-failed : sync failed - pg-connect-failure : socket connect or pg bind with socket failed - pg-info-conflict : pred verify static data failed - qos-info-conflict : qos verify static data failed - vpmgnt-info-conflict : vpmgnt verify static data failed - link-failure : ponlos, tx-fail or wdog - forced-switch-over : operator requested switchover - port-admin-down : port was set admin down - board-failure : board failure or p2p fail - hunting : hunting ONT	
swo-reason	Parameter type: <RedPort::SwitchReason> (no-switch-over port-admin-change forced-switch-over link-failure board-failure) Possible values: - no-switch-over : no switch over has been performed yet - port-admin-change : port was set admin down - forced-switch-over : operator requested switchover - link-failure : link failure - board-failure : board failure	specifies the dual-parenting last switchover reason. <i>This element is always shown.</i>
num-swo	Parameter type: <SignedInteger> - a signed integer	specifies the number of times a dual-parenting switchover occurred. <i>This element is always shown.</i>

180- Multicast Status Commands

180.1 Multicast Status Command Tree	180-6918
180.2 IGMP System Status Command	180-6919
180.3 IGMP System Status Command	180-6920
180.4 IGMP Channel Sources Status Command	180-6922
180.5 IGMP Channel Miscellaneous Status Command	180-6925
180.6 IGMP Channel Protocol Status Command	180-6928
180.7 IGMP Module Counter Status Command	180-6932
180.8 IGMP Module Time Status Command	180-6935
180.9 IGMP Module Miscellaneous Status Command	180-6937
180.10 IGMP Group to Package Status Command	180-6939
180.11 Show Multicast Channel Statistics Command	180-6940
180.12 IGMP package to multicast source Command	180-6942

180.1 Multicast Status Command Tree

Description

This chapter gives an overview of nodes that are handled by "Multicast Status Commands".

Command Tree

```
----show
  ----mcast-control
    ----mcast-svc-context
    ----system
    ----channel
      ----counter
        - (port)
      ----miscellaneous
        - (port)
      ----protocol
        - (port)
    ----module
      ----counter
        - (slot-index)
      ----time
        - (slot-index)
      ----miscellaneous
        - (slot-index)
  ----ipv4
    ----grp-to-package
      - (grp-ip-addr)
      - src-ip-addr
      - vlan-id
    ----module-mcast-channel
      - (slot)
      - grp-ip-addr
      - src-ip-addr
      - vlan-id
    ----package-to-src
      - (package-id)
```


180.2 IGMP System Status Command

Command Description

This command displays the next Multicast Service Context Profile Index available.

User Level

The command can be accessed by operators with igmp privileges.

Command Syntax

The command has the following syntax:

```
> show mcast-control mcast-svc-context
```

Command Output

Table 180.2-2 "IGMP System Status Command" Display parameters

Specific Information		
name	Type	Description
next	Parameter type: <Igmp::McastSvcCtxtNextPointer> - mcast service context profile index - range: [0...64]	The next available id for multicast service context profile. <i>This element is always shown.</i>

180.3 IGMP System Status Command

Command Description

This command displays the IGMP system-related parameters.

User Level

The command can be accessed by operators with igmp privileges.

Command Syntax

The command has the following syntax:

```
> show mcast-control system
```

Command Output

Table 180.3-2 "IGMP System Status Command" Display parameters

Specific Information		
name	Type	Description
startup-query-intvl	Parameter type: <Igmp::SysStartUpQueryInt> - interval at which general membership queries transmitted - unit: sec - range: [1...3175]	The interval between general membership queries sent on startup. <i>This element is always shown.</i>
startup-query-count	Parameter type: <Igmp::SystemStartupQueryCount> - queries sent out on startup separated by query interval - range: [1...10]	The number of queries sent out on startup separated by the query interval. <i>This element is always shown.</i>
stats-intvl	Parameter type: <Igmp::McastSrcPeakTime> - the time (yyyy-mm-dd:hour:minutes:secs) - unit: UTC	This statistics indicates the network time of when the system-wide statistics were last reset. <i>This element is always shown.</i>
src-ipaddr	Parameter type: <Ip::V4Address> - IPv4-address	This object specifies the source IP address which is contained in every multicast IP datagrams transmitted on all IGMP control channels. <i>This element is always shown.</i>
router-present-timeout	Parameter type: <SignedInteger> - a signed integer	When the system acts as host on the network side of the IGMP proxy, this value is the time how long the system shall wait after hearing a Version 1 Query before it shall send any IGMPv2 messages. <i>This element is always shown.</i>
grp-memb-intvl	Parameter type: <SignedInteger>	The interval that must pass before

name	Type	Description
	- a signed integer	the system decides there are no more members of a group on a network. <i>This element is always shown.</i>

180.4 IGMP Channel Sources Status Command

Command Description

This command displays the IGMP channel source.

User Level

The command can be accessed by operators with igmp privileges.

Command Syntax

The command has the following syntax:

```
> show mcast-control channel counter [ (port) ]
```

Command Parameters

Table 180.4-1 "IGMP Channel Sources Status Command" Resource Parameters

Resource Identifier	Type	Description
(port)	Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::VpiId> : <Eqpt::VciId> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::VpiId> : <Eqpt::VciId> : <Eqpt::UnstackedVlan> vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::UnstackedVlan> vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::VpiId> : <Eqpt::VciId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> / <Eqpt::OntPortId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> / <Eqpt::OntPortId> : <Eqpt::UnstackedVlan> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> / <Eqpt::OntPortId> vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / voip : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> /	identification of the port, vlanport or virtual channel

Resource Identifier	Type	Description
	<pre> <Eqpt::PonId> / <Eqpt::OntId> / vuni : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / voip : <Eqpt::UnstackedVlan> vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / vuni : <Eqpt::UnstackedVlan> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / voip <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / vuni vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::LLId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::LLId> : <Eqpt::UnstackedVlan> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::LLId> vlan:ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / <Eqpt::Ng2OntSlotId> / <Eqpt::Ng2OntPortId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan:ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / <Eqpt::Ng2OntSlotId> / <Eqpt::Ng2OntPortId> : <Eqpt::UnstackedVlan>) Possible values: - vlan : vlan port - vlan:ng2 : ngpon2 vlan port Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number Field type <Eqpt::VpiId> - atm VPI Field type <Eqpt::VciId> - atm VCI Field type <Eqpt::PonId> - the PON identifier Field type <Eqpt::ChannelGroupId> - the channel group identifier Field type <Eqpt::SubChannelGroupId> - the subchannel group identifier Field type <Eqpt::Ng2OntId> - the NG2 ONT identifier Field type <Eqpt::OntId> - the ONT identifier Possible values: - voip : virtual uni identifier obsolete alternative replaced by vuni - vuni : virtual uni identifier </pre>	

Resource Identifier	Type	Description
	Possible values: - vuni : virtual NGPON2 uni identifier Field type <Eqpt::OntSlotId> - the ONT SLOT identifier Field type <Eqpt::OntPortId> - the ONT PORT identifier Field type <Eqpt::Ng2OntSlotId> - the NGPON2 ONT SLOT identifier Field type <Eqpt::Ng2OntPortId> - the NGPON2 ONT PORT identifier Field type <Eqpt::LLId> - the LLID identifier, range 1 for EPON, range 1-8 for DPOE Possible values: - stacked : stacked vlan identity Field type <Eqpt::UnstackedVlan> - unstacked vlan id Field type <Eqpt::SVlan> - service vlan id Field type <Eqpt::CVlan> - customer vlan id	

Command Output

Table 180.4-2 "IGMP Channel Sources Status Command" Display parameters

Specific Information		
name	Type	Description
noperm-join	Parameter type: <Counter> - 32 bit counter	no of times perm bitmap failure has occurred. <i>This element is always shown.</i>
bitrate-fail	Parameter type: <Counter> - 32 bit counter	no of times IGMP join message failed <i>This element is always shown.</i>
inval-classd	Parameter type: <Counter> - 32 bit counter	indicates the count of IP address states <i>This element is always shown.</i>
numsec-ovld-protappl	Parameter type: <Counter> - 32 bit counter	no of 1sec int for overload protection has been applied <i>This element is always shown.</i>
num-fail	Parameter type: <Counter> - 32 bit counter	Indicates the count of failure join <i>This element is always shown.</i>
sysnum-fail	Parameter type: <Counter> - 32 bit counter	Indicates the count of failure IGMP join <i>This element is always shown.</i>
sysrate-fail	Parameter type: <Counter> - 32 bit counter	Indicates the count of failure IGMP join because of low Bandwidth <i>This element is always shown.</i>

180.5 IGMP Channel Miscellaneous Status

Command

Command Description

This command displays the IGMP channel source.

User Level

The command can be accessed by operators with igmp privileges.

Command Syntax

The command has the following syntax:

```
> show mcast-control channel miscellaneous [ (port) ]
```

Command Parameters

Table 180.5-1 "IGMP Channel Miscellaneous Status Command" Resource Parameters

Resource Identifier	Type	Description
(port)	Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::VpiId> : <Eqpt::VciId> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::VpiId> : <Eqpt::VciId> : <Eqpt::UnstackedVlan> vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::UnstackedVlan> vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::VpiId> : <Eqpt::VciId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> / <Eqpt::OntPortId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> / <Eqpt::OntPortId> : <Eqpt::UnstackedVlan> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> / <Eqpt::OntPortId> vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> /	identification of the port, vlanport or virtual channel

Resource Identifier	Type	Description
	<pre> <Eqpt::PonId> / <Eqpt::OntId> / voip : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / vuni : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / voip : <Eqpt::UnstackedVlan> vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / vuni : <Eqpt::UnstackedVlan> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / voip <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / vuni vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::LLId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::LLId> : <Eqpt::UnstackedVlan> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::LLId> vlan:ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / <Eqpt::Ng2OntSlotId> / <Eqpt::Ng2OntPortId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan:ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / <Eqpt::Ng2OntSlotId> / <Eqpt::Ng2OntPortId> : <Eqpt::UnstackedVlan>) Possible values: - vlan : vlan port - vlan:ng2 : ngpon2 vlan port Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number Field type <Eqpt::VpId> - atm VPI Field type <Eqpt::VciId> - atm VCI Field type <Eqpt::PonId> - the PON identifier Field type <Eqpt::ChannelGroupId> - the channel group identifier Field type <Eqpt::SubChannelGroupId> - the subchannel group identifier Field type <Eqpt::Ng2OntId> - the NG2 ONT identifier Field type <Eqpt::OntId> - the ONT identifier Possible values: </pre>	

Resource Identifier	Type	Description
	- voip : virtual uni identifier obsolete alternative replaced by vuni - vuni : virtual uni identifier Possible values: - vuni : virtual NGPON2 uni identifier Field type <Eqpt::OntSlotId> - the ONT SLOT identifier Field type <Eqpt::OntPortId> - the ONT PORT identifier Field type <Eqpt::Ng2OntSlotId> - the NGPON2 ONT SLOT identifier Field type <Eqpt::Ng2OntPortId> - the NGPON2 ONT PORT identifier Field type <Eqpt::LLId> - the LLID identifier, range 1 for EPON, range 1-8 for DPOE Possible values: - stacked : stacked vlan identity Field type <Eqpt::UnstackedVlan> - unstacked vlan id Field type <Eqpt::SVlan> - service vlan id Field type <Eqpt::CVlan> - customer vlan id	

Command Output

Table 180.5-2 "IGMP Channel Miscellaneous Status Command" Display parameters

Specific Information		
name	Type	Description
curr-num-group	Parameter type: <Gauge> - gauge	current group number in this port(ADSL,PVC) <i>This element is always shown.</i>
curr-preview-num	Parameter type: <Counter> - 32 bit counter	count of prev mcast grp that igmp channel joins currently <i>This element is always shown.</i>
curr-uncfg-num	Parameter type: <Counter> - 32 bit counter	current unconfig group number in this port(ADSL,PVC) <i>This element is always shown.</i>

180.6 IGMP Channel Protocol Status Command

Command Description

This command shows the IGMP protocol statistics for an IGMP channel

User Level

The command can be accessed by operators with igmp privileges.

Command Syntax

The command has the following syntax:

```
> show mcast-control channel protocol [ (port) ]
```

Command Parameters

Table 180.6-1 "IGMP Channel Protocol Status Command" Resource Parameters

Resource Identifier	Type	Description
(port)	Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::VpiId> : <Eqpt::VciId> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::VpiId> : <Eqpt::VciId> : <Eqpt::UnstackedVlan> vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::UnstackedVlan> vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::VpiId> : <Eqpt::VciId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> / <Eqpt::OntPortId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> / <Eqpt::OntPortId> : <Eqpt::UnstackedVlan> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> / <Eqpt::OntPortId> vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / voip : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> /	identification of the port, vlanport or virtual channel

Resource Identifier	Type	Description
	<pre> <Eqpt::PonId> / <Eqpt::OntId> / vuni : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / voip : <Eqpt::UnstackedVlan> vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / vuni : <Eqpt::UnstackedVlan> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / voip <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / vuni vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::LLId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::LLId> : <Eqpt::UnstackedVlan> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::LLId> vlan:ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / <Eqpt::Ng2OntSlotId> / <Eqpt::Ng2OntPortId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan:ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / <Eqpt::Ng2OntSlotId> / <Eqpt::Ng2OntPortId> : <Eqpt::UnstackedVlan>) Possible values: - vlan : vlan port - vlan:ng2 : ngpon2 vlan port Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number Field type <Eqpt::VpiId> - atm VPI Field type <Eqpt::VciId> - atm VCI Field type <Eqpt::PonId> - the PON identifier Field type <Eqpt::ChannelGroupId> - the channel group identifier Field type <Eqpt::SubChannelGroupId> - the subchannel group identifier Field type <Eqpt::Ng2OntId> - the NG2 ONT identifier Field type <Eqpt::OntId> - the ONT identifier Possible values: - voip : virtual uni identifier obsolete alternative replaced by vuni - vuni : virtual uni identifier </pre>	

Resource Identifier	Type	Description
	Possible values: - vuni : virtual NGPON2 uni identifier Field type <Eqpt::OntSlotId> - the ONT SLOT identifier Field type <Eqpt::OntPortId> - the ONT PORT identifier Field type <Eqpt::Ng2OntSlotId> - the NGPON2 ONT SLOT identifier Field type <Eqpt::Ng2OntPortId> - the NGPON2 ONT PORT identifier Field type <Eqpt::LLId> - the LLID identifier, range 1 for EPON, range 1-8 for DPOE Possible values: - stacked : stacked vlan identity Field type <Eqpt::UnstackedVlan> - unstacked vlan id Field type <Eqpt::SVlan> - service vlan id Field type <Eqpt::CVlan> - customer vlan id	

Command Output

Table 180.6-2 "IGMP Channel Protocol Status Command" Display parameters

Specific Information		
name	Type	Description
tx-igmp-gmq short name: tx/gmq	Parameter type: <Counter> - 32 bit counter	number of IGMP general queries transmitted on user interface <i>This element is always shown.</i>
tx-igmp-gsq short name: tx/gsq	Parameter type: <Counter> - 32 bit counter	number of IGMP group specific queries transmitted <i>This element is always shown.</i>
tx-igmp-gssq short name: tx/gssq	Parameter type: <Counter> - 32 bit counter	number of IGMP group-source specific queries transmitted <i>This element is always shown.</i>
rx-igmp-v1-req short name: rx-req/v1	Parameter type: <Counter> - 32 bit counter	number of IGMP V1 membership report received <i>This element is always shown.</i>
rx-igmp-v2-req short name: rx-req/v2	Parameter type: <Counter> - 32 bit counter	number of IGMP V2 membership report received <i>This element is always shown.</i>
rx-igmp-v3-req short name: rx-req/v3	Parameter type: <Counter> - 32 bit counter	number of IGMP V3 membership report received <i>This element is always shown.</i>
rx-igmp-v2-leaves	Parameter type: <Counter> - 32 bit counter	number of IGMP leave messages report received <i>This element is only shown in detail mode.</i>
tx-mld-gmq	Parameter type: <Counter> - 32 bit counter	number of MLD signals received where the src-ip-addr of the multicast channel violates the ASM/SSM rules <i>This element is only shown in detail mode.</i>
tx-mld-gsq	Parameter type: <Counter> - 32 bit counter	number of MLD signals received where the src-ip-addr of the

name	Type	Description
		multicast channel violates the ASM/SSM rules <i>This element is only shown in detail mode.</i>
tx-mld-gssq	Parameter type: <Counter> - 32 bit counter	number of MLD signals received where the src-ip-addr of the multicast channel violates the ASM/SSM rules <i>This element is only shown in detail mode.</i>
rx-mld-v1-req	Parameter type: <Counter> - 32 bit counter	number of MLD signals received where the src-ip-addr of the multicast channel violates the ASM/SSM rules <i>This element is only shown in detail mode.</i>
rx-mld-v2-req	Parameter type: <Counter> - 32 bit counter	number of MLD signals received where the src-ip-addr of the multicast channel violates the ASM/SSM rules <i>This element is only shown in detail mode.</i>
rx-mld-v1-leaves	Parameter type: <Counter> - 32 bit counter	number of MLD signals received where the src-ip-addr of the multicast channel violates the ASM/SSM rules <i>This element is only shown in detail mode.</i>
rx-valid-message short name: rx-msg/ok	Parameter type: <Counter> - 32 bit counter	number of valid multicast packets received <i>This element is always shown.</i>
rx-invalid-message short name: rx-msg/nok	Parameter type: <Counter> - 32 bit counter	number of invalid multicast packets received <i>This element is always shown.</i>
rx-unknown-message short name: rx-msg/unknown	Parameter type: <Counter> - 32 bit counter	number of unknown multicast packets received <i>This element is always shown.</i>
rx-bad-length	Parameter type: <Counter> - 32 bit counter	number of bad length multicast packet received/dropped <i>This element is only shown in detail mode.</i>
rx-bad-ip-checksum	Parameter type: <Counter> - 32 bit counter	number of wrong IP checksum multicast packet received/dropped <i>This element is only shown in detail mode.</i>
rx-bad-checksum	Parameter type: <Counter> - 32 bit counter	number of wrong checksum mcast packets received/dropped <i>This element is only shown in detail mode.</i>
rx-wrong-src-ip-addr	Parameter type: <Counter> - 32 bit counter	number of multicast signals received where the src-ip-addr of the multicast channel violates the ASM/SSM rules <i>This element is only shown in detail mode.</i>

180.7 IGMP Module Counter Status Command

Command Description

This command displays the IGMP module counters.

User Level

The command can be accessed by operators with igmp privileges.

Command Syntax

The command has the following syntax:

```
> show mcast-control module counter [ (slot-index) ]
```

Command Parameters

Table 180.7-1 "IGMP Module Counter Status Command" Resource Parameters

Resource Identifier	Type	Description
(slot-index)	Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId>) Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number	identifies an IGMP module by the logical slot id

Command Output

Table 180.7-2 "IGMP Module Counter Status Command" Display parameters

Specific Information		
name	Type	Description
total-msg	Parameter type: <Counter> - 32 bit counter	The total number of messages received from users, including IGMP messages and invalid messages. <i>This element is always shown.</i>
total-igmp-msg	Parameter type: <Counter> - 32 bit counter	The total number of IGMP messages, which includes join and leave requests from users, (both successful and unsuccessful). <i>This element is always shown.</i>
total-req	Parameter type: <Counter>	The total number of join requests

name	Type	Description
	- 32 bit counter	from users, which includes successful and unsuccessful attempts. <i>This element is always shown.</i>
success-req	Parameter type: <Counter> - 32 bit counter	The total number of successful join requests from users which includes new joins (which make a new connection) and re-joins (which already have a connection). <i>This element is always shown.</i>
unsuccess-req	Parameter type: <Counter> - 32 bit counter	The total number of unsuccessful new join requests from users. The failures could be due to the following reasons: permission bitmap failure, bitrate failure, lack of resource or invalid group address. <i>This element is only shown in detail mode.</i>
total-leave-req	Parameter type: <Counter> - 32 bit counter	The total number of leave requests from users. <i>This element is only shown in detail mode.</i>
total-inval-msg	Parameter type: <Counter> - 32 bit counter	The total number of invalid messages from users. These messages could be invalid for the following reasons: invalid IGMP message type, invalid IGMP message CRC, invalid IGMP message size, non-IGMP frame received, unexpected IGMP Query (GSQ or GMQ) received, RFC 1483 errors, MAC layer errors, or IP layer errors. <i>This element is only shown in detail mode.</i>
num-connects	Parameter type: <Counter> - 32 bit counter	The total number of connects due to successful new IGMP join requests from users. <i>This element is always shown.</i>
num-disconnects	Parameter type: <Counter> - 32 bit counter	The total number of disconnects to users. They can be due to GSQ or GMQ timer expiry or the triggering of fast channel changes. <i>This element is only shown in detail mode.</i>
peak-connects-sec	Parameter type: <Counter> - 32 bit counter	The peak number of multicast branch connections performed per second since the statistics were last cleared. <i>This element is only shown in detail mode.</i>
peak-disconnects-sec	Parameter type: <Counter> - 32 bit counter	The peak number of disconnects to users performed per second. <i>This element is only shown in</i>

180 Multicast Status Commands

name	Type	Description
		<i>detail mode.</i>
peak-msg-sec	Parameter type: <Counter> - 32 bit counter	The peak number of messages received from users per second. <i>This element is only shown in detail mode.</i>
gmq	Parameter type: <Counter> - 32 bit counter	The total number of GMQ requests from network. <i>This element is only shown in detail mode.</i>
gsq	Parameter type: <Counter> - 32 bit counter	The total number of GSQ requests from network. <i>This element is only shown in detail mode.</i>
gssq	Parameter type: <Counter> - 32 bit counter	The total number of GSSQ requests from network. <i>This element is only shown in detail mode.</i>
ovrld-app	Parameter type: <Counter> - 32 bit counter	The number of seconds during which module overload protection has been applied affecting all IGMP channels which are terminated at the IGMP module. <i>This element is only shown in detail mode.</i>
total-mld-msg	Parameter type: <Counter> - 32 bit counter	The number of total mld message. <i>This element is only shown in detail mode.</i>

180.8 IGMP Module Time Status Command

Command Description

This command displays the IGMP module time-related parameters.

User Level

The command can be accessed by operators with igmp privileges.

Command Syntax

The command has the following syntax:

```
> show mcast-control module time [ (slot-index) ]
```

Command Parameters

Table 180.8-1 "IGMP Module Time Status Command" Resource Parameters

Resource Identifier	Type	Description
(slot-index)	Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId>) Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number	identifies an IGMP module by the logical slot id

Command Output

Table 180.8-2 "IGMP Module Time Status Command" Display parameters

Specific Information		
name	Type	Description
peak-connects	Parameter type: <Igmp::McastSrcPeakTime> - the time (yyyy-mm-dd:hour:minutes:secs) - unit: UTC	This will show "1970-01-01:00:00:00" by default. In case the peak number of connect occurs , it displays the time at which the event occurred <i>This element is always shown.</i>
peak-disconnects	Parameter type: <Igmp::McastSrcPeakTime> - the time (yyyy-mm-dd:hour:minutes:secs) - unit: UTC	This will show "1970-01-01:00:00:00" by default. In case the peak number of disconnect occurs , it displays the time at which the event occurred

180 Multicast Status Commands

name	Type	Description
		<i>This element is always shown.</i>
peak-msg	Parameter type: <Igmpp::McastSrcPeakTime> - the time (yyyy-mm-dd:hour:minutes:secs) - unit: UTC	This will show "1970-01-01:00:00:00" by default. In case the peak number of messages received occurs, it displays the time at which the event occurred <i>This element is always shown.</i>
stats-intval	Parameter type: <Igmpp::McastSrcPeakTime> - the time (yyyy-mm-dd:hour:minutes:secs) - unit: UTC	The network time, when the module-wide statistics were last reset. <i>This element is only shown in detail mode.</i>

180.9 IGMP Module Miscellaneous Status Command

Command Description

This command displays the IGMP module parameters.

User Level

The command can be accessed by operators with igmp privileges.

Command Syntax

The command has the following syntax:

```
> show mcast-control module miscellaneous [ (slot-index) ]
```

Command Parameters

Table 180.9-1 "IGMP Module Miscellaneous Status Command" Resource Parameters

Resource Identifier	Type	Description
(slot-index)	Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId>) Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number	identifies an IGMP module by the logical slot id

Command Output

Table 180.9-2 "IGMP Module Miscellaneous Status Command" Display parameters

Specific Information		
name	Type	Description
curr-root-conn	Parameter type: <Gauge> - gauge	The number of the connected groups. <i>This element is always shown.</i>
con-cfgd	Parameter type: <Gauge> - gauge	The number of the connected groups who are configured in multicast source table. <i>This element is always shown.</i>
con-un-cfgd	Parameter type: <Gauge> - gauge	The number of the connected groups who aren't configured in

180 Multicast Status Commands

name	Type	Description
		multicast source table. <i>This element is always shown.</i>
con-no-memb	Parameter type: <Gauge> - gauge	The number of the connected groups who is in reserve state(no member). <i>This element is always shown.</i>

180.10 IGMP Group to Package Status Command

Command Description

This command shows the IGMP group to package parameters

User Level

The command can be accessed by operators with igmp privileges.

Command Syntax

The command has the following syntax:

```
> show mcast-control ipv4 grp-to-package [ (grp-ip-addr) [ src-ip-addr <Ip::V4Address> ] [ vlan-id <Igmp::SrcVlanId> ] ]
```

Command Parameters

Table 180.10-1 "IGMP Group to Package Status Command" Resource Parameters

Resource Identifier	Type	Description
(grp-ip-addr)	Format: - multicast-address (range: 224.0.0.3....239.255.255.255)	ip address identifying the multicast group
src-ip-addr	Parameter type: <Ip::V4Address> Format: - IPv4-address	ip address of the multicast server originating the multicast channel,value 0.0.0.0 means ASM(any-src-ip-addr)
vlan-id	Parameter type: <Igmp::SrcVlanId> Format: - the multicast vlan id - range: [1...4094]	identifies a particular vlan id

Command Output

Table 180.10-2 "IGMP Group to Package Status Command" Display parameters

Specific Information		
name	Type	Description
index	Parameter type: <Igmp::PackageIndex> - index of the package - range: [1...1024]	index used to identify the packages <i>This element is always shown.</i>

180.11 Show Multicast Channel Statistics

Command

Command Description

This command shows the distribution of statistics information maintained by IGMP channels. The operator should know the slot index (the range is 1/1/0 to 1/1/18), the class D address (the range is 224.0.0.3 to 239.255.255.255) and the source-ip-addr of the mcast server. The following statistics objects measure the popularity of a multicast channel (when and how much the multicast channel is being watched by end users). The term "subscribe" in this context means how many IGMP channels have a group member connected to this multicast source.

- **peak-nbr-subs-channels:** This statistic indicates the peak number of subscribed IGMP channels for which leaf multicast VCLs have connected to the source since the last statistics reset.
- **peak-time:** This statistic indicates the network time, in seconds, when the peak number of subscribed IGMP channels for the source occurred.
- **curr-subs-channels:** This statistic indicates the current number of subscribed IGMP channels for the source.
- **connect-fail-counter:** This statistic indicates the number of times that an attempt to create a multicast connection has failed and the number of times that a multicast connection failure has occurred. The reason for failure is likely because there is insufficient bandwidth in the internal backplane of the Nokia 7302 or 7330 ISAM FTTN to transport the data traffic from the root endpoint of the network interface to the leaf endpoint of the access interface.

User Level

The command can be accessed by operators with igmp privileges.

Command Syntax

The command has the following syntax:

```
> show mcast-control ipv4 module-mcast-channel [ (slot) [ grp-ip-addr <Igmp::MulticastAddress> ] [ src-ip-addr <Ip::V4Address> ] [ vlan-id <Igmp::McastChannelVlan> ] ]
```

Command Parameters

Table 180.11-1 "Show Multicast Channel Statistics Command" Resource Parameters

Resource Identifier	Type	Description
(slot)	Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId>) Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number	identifies an IGMP module by the logical SlotId
grp-ip-addr	Parameter type: <Igmp::MulticastAddress> Format:	ip address identifying the multicast group

Resource Identifier	Type	Description
	- multicast-address (range: 224.0.0.3....239.255.255.255, except for 224.0.0.22)	
src-ip-addr	Parameter type: <Ip::V4Address> Format: - IPv4-address	ip address of the multicast server originating the multicast channel,value 0.0.0.0 means ASM(any-src-ip-addr)
vlan-id	Parameter type: <Igmp::McastChannelVlan> Format: - vlan id for multicast - range: [1...4093]	vlanid of the multicast channel which is configured in it

Command Output

Table 180.11-2 "Show Multicast Channel Statistics Command" Display parameters

Specific Information		
name	Type	Description
peak-nbr-subs-channels short name: pk-nr-sub-ch	Parameter type: <Counter> - 32 bit counter	The peak number of subscribed IGMP channels which have members connected to the source since the last statistics reset. It is only for those groups configured in Multicast Channel table. <i>This element is always shown.</i>
peak-time	Parameter type: <Igmp::McastSrcPeakTime> - the time (yyyy-mm-dd:hour:minutes:secs) - unit: UTC	The network time indicating when the peak number of subscribed IGMP channels for the source occurred. It is only for those groups configured in Multicast Channel Table. <i>This element is always shown.</i>
curr-subs-channels	Parameter type: <Gauge> - gauge	Indicates the current number of subscribed IGMP channels for the multicast stream/channel. <i>This element is only shown in detail mode.</i>
nbr-connect-fail short name: nr-con-nok	Parameter type: <Counter> - 32 bit counter	Indicates the number of times that an attempt to create a multicast connection fails. <i>This element is always shown.</i>
user-success-join	Parameter type: <Counter> - 32 bit counter	indicates the number of times that users successfully joined a group. <i>This element is only shown in detail mode.</i>

180.12 IGMP package to multicast source

Command

Command Description

This command shows the IGMP package to multicast source parameters.

User Level

The command can be accessed by operators with igmp privileges.

Command Syntax

The command has the following syntax:

```
> show mcast-control ipv4 package-to-src [ (package-id) ]
```

Command Parameters

Table 180.12-1 "IGMP package to multicast source Command" Resource Parameters

Resource Identifier	Type	Description
(package-id)	Format: - index of the package - range: [1...1024]	name used to identify the packages

Command Output

Table 180.12-2 "IGMP package to multicast source Command" Display parameters

Specific Information		
name	Type	Description
group-address	Parameter type: <Ip::V4Address> - IPv4-address	the multicast group address <i>This element is always shown.</i>
source-address	Parameter type: <Ip::V4Address> - IPv4-address	the multicast group source address <i>This element is always shown.</i>
vlan-id	Parameter type: <Igmp::SrcVlanId> - the multicast vlan id - range: [1...4094]	the multicast vlan id <i>This element is always shown.</i>

181- Security Status Commands

181.1 Security Status Command Tree	181-6944
181.2 Operator Information Status Command	181-6946
181.3 Domain Status Command	181-6948
181.4 User Sessions Status Command	181-6949
181.5 Connection Profile Status Command	181-6956
181.6 RADIUS Authentication Server Status Command	181-6957
181.7 RADIUS Authentication Server Statistics Command	181-6959
181.8 RADIUS Accounting Server Statistics Command	181-6962
181.9 RADIUS Accounting Server Status Command	181-6965
181.10 RADIUS Dynamic Authentication Client Status Command	181-6966
181.11 RADIUS Next Available Index Command	181-6968
181.12 RADIUS Client Status Command	181-6969
181.13 Tacacs authentication Server Status Command	181-6970
181.14 TACACS Authentication Server Statistics Command	181-6972
181.15 Tacacs authorization Server Status Command	181-6975
181.16 TACACS Authorization Server Statistics Command	181-6977
181.17 Tacacs Accounting Server Status Command	181-6979
181.18 TACACS Accounting Server Statistics Command	181-6980
181.19 PAE Authenticator Status Command	181-6982
181.20 EAPOL Statistics Command	181-6986
181.21 Diagnostic Information Status Command	181-6989
181.22 Session Statistics Command	181-6994
181.23 PAE Port System Status Command	181-6997
181.24 MAC Address related EAPOL Status Command	181-6999
181.25 MAC Address related EAPOL Status Command	181-7001
181.26 MAC Address related EAPOL Status Command	181-7006
181.27 SSH Server Status Command	181-7011
181.28 SSH Server Key Generation Progress Status Command	181-7012
181.29 SSH Authentication Key Status Command	181-7013
181.30 SSH Authentication Key Generation Progress Status Command	181-7014
181.31 PM File Upload Status Command	181-7015
181.32 5-min CDR File Upload Status Command	181-7017

181.1 Security Status Command Tree

Description

This chapter gives an overview of nodes that are handled by "Security Status Commands".

Command Tree

```
----show
  ----security
    ----operator
      - (name)
    ----aaa
      ----domain
        - (name)
      ----user-session
        - (index)
        - user
        - domain
      ----conn-profile
        - (name)
  ----radius
    ----auth-server
      ----state
        - (name)
        - router-instance
      ----auth-stats
        - (name)
        - router-instance
    ----acc-server
      ----acc-stats
        - (name)
        - router-instance
      ----state
        - (name)
        - router-instance
    ----dyn-authclient-stats
      - (name)
      - router-instance
    ----next-free-index
      - (name)
    ----radius-client
  ----tacacs
    ----authen-server
      ----state
        - (name)
        - router-instance
      ----statistics
        - (name)
        - router-instance
    ----author-server
      ----state
        - (name)
        - router-instance
```

```

    ----statistics
      - (name)
      - router-instance
  ----acc-server
    ----state
      - (name)
      - router-instance
    ----statistics
      - (name)
      - router-instance
  ----pae
    ----authenticator
      - (port)
    ----eapol-stats
      - (port)
    ----diagnostics
      - (port)
    ----session-stats
      - (port)
    ----port-details
      - (port)
    ----mac-address
      - (last-src-mac)
    ----mac-authenticator
      - (port)
      - mac-address
    ----mac-diagnostics
      - (port)
      - mac-address
  ----ssh
    ----server
    ----server-key-status
    ----auth-key
      - (key-type)
    ----auth-key-status
  ----pmfile
    ----upload
      - (upload-index)
  ----X cdr-pm-file
  ----X upload

```

181.2 Operator Information Status Command

Command Description

This command displays information about operators managed by the local authentication server. Operators managed by a remote authentication server (for example Radius) are never shown.

User Level

The command can be accessed by operators with all,admin privileges.

Operators without security read or write permissions can never see the information about other operators.

Command Syntax

The command has the following syntax:

```
> show security operator [ (name) ]
```

Command Parameters

Table 181.2-1 "Operator Information Status Command" Resource Parameters

Resource Identifier	Type	Description
(name)	Format: - the name of an operator - range: [a-z0-9+] - length: 1<=x<=11	the name of the operator

Command Output

Table 181.2-2 "Operator Information Status Command" Display parameters

Specific Information		
name	Type	Description
last-login	Parameter type: <Sys::Time> - the time (yyyy-mm-dd:hour:minutes:secs) - unit: UTC	the time of the last successful login <i>This element is always shown.</i>
last-failed	Parameter type: <Sys::Time> - the time (yyyy-mm-dd:hour:minutes:secs) - unit: UTC	the time of the last unsuccessful login attempt <i>This element is always shown.</i>
failed-logins	Parameter type: <UnsignedInteger> - an unsigned integer	the number of unsuccessful login attempts since the last successful login <i>This element is always shown.</i>
last-passwd-change	Parameter type: <Sys::Time> - the time (yyyy-mm-dd:hour:minutes:secs) - unit: UTC	the time the password was changed for the last time. It does not matter if the change was made by this operator itself or by another operator.

181 Security Status Commands

name	Type	Description
		<i>This element is always shown.</i>

181.3 Domain Status Command

Command Description

This command displays the domain status.

User Level

The command can be accessed by operators with aaa privileges.

Command Syntax

The command has the following syntax:

> show security aaa domain [(name)]

Command Parameters

Table 181.3-1 "Domain Status Command" Resource Parameters

Resource Identifier	Type	Description
(name)	Format: - name of the domain - length: 1<=x<=64	name of the domain

Command Output

Table 181.3-2 "Domain Status Command" Display parameters

Specific Information		
name	Type	Description
active-sessions	Parameter type: <Gauge> - gauge	the number of active sessions <i>This element is always shown.</i>

181.4 User Sessions Status Command

Command Description

This command displays the details of user sessions.

User Level

The command can be accessed by operators with aaa privileges.

Command Syntax

The command has the following syntax:

```
> show security aaa user-session [ (index) [ user <Aaa::DisplayString> ] [ domain <Aaa::DisplayString> ] ]
```

Command Parameters

Table 181.4-1 "User Sessions Status Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - a signed integer	index to the domain user session table
user	Parameter type: <Aaa::DisplayString> Format: - a description - length: 1<=x<=64	user name
domain	Parameter type: <Aaa::DisplayString> Format: - a description - length: 1<=x<=64	domain name

Command Output

Table 181.4-2 "User Sessions Status Command" Display parameters

Specific Information		
name	Type	Description
interface	Parameter type: <Itf::ComplexPortType> (xdsl-line : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> voicefxs : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> xdsl-channel : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> atm-if : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> atm-pvc : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::VpiId> :	the interface on which the session is established. <i>This element is only shown in detail mode.</i>

name	Type	Description
	<pre> <Eqpt::VciId> bridge-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::VpiId> : <Eqpt::VciId> vlan-port:ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / <Eqpt::Ng2OntSlotId> / <Eqpt::Ng2OntPortId> : <Eqpt::UnstackedVlan> l2-vlan : <Eqpt::VlanId> ip : <Eqpt::LogicalId> sw-loopback slip uni:ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / <Eqpt::Ng2OntSlotId> / <Eqpt::Ng2OntPortId> vlan-port:ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / <Eqpt::Ng2OntSlotId> / <Eqpt::Ng2OntPortId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> atm-bonding : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> bonding : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> ip-gateway : <Eqpt::VrfId> ip-line : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::VpiId> : <Eqpt::VciId> ip-line : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> shdsl-line : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> e1-line : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> atm-ima : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> ethernet-line : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> bridge-port:ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / vuni vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::VpiId> : <Eqpt::VciId> : <Eqpt::UnstackedVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::UnstackedVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::VpiId> : <Eqpt::VciId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> voip:ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> ip-line : vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::VpiId> : <Eqpt::VciId> : <Eqpt::UnstackedVlan> ip-line : vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::UnstackedVlan> ip-line : vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / </pre>	

name	Type	Description
	<pre> <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::VpId> : <Eqpt::VcId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> ip-line : vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan-port:ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / vuni : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan-port:ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / vuni : <Eqpt::UnstackedVlan> chgroup : <Eqpt::ChannelGroupId> subchgroup : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> bridge-port:ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / <Eqpt::Ng2OntSlotId> / <Eqpt::Ng2OntPortId> atm-pvc : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> bridge-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> bridge-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> / <Eqpt::OntPortId> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> / <Eqpt::OntPortId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> / <Eqpt::OntPortId> : <Eqpt::UnstackedVlan> pon : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> ont : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> uni : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> / <Eqpt::OntPortId> bridge-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / voip bridge-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / vuni vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / voip : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / vuni : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / voip : <Eqpt::UnstackedVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / vuni : <Eqpt::UnstackedVlan> voip : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> </pre>	

name	Type	Description
	<pre> la-group : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::LLId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> bridge-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::LLId> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::LLId> : <Eqpt::UnstackedVlan> mpm : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::ComboPonId> x-pon : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::XPonId> 25g-pon : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::M25GPonId> dist-router-interface : slot-stacked : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::SVlan> : <Eqpt::CVlan> dist-router-interface : slot-vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::UnstackedVlan> bundle : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::BundleId> chpair : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::ChannelPairId> ont:ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId>) Possible values: - xdsl-line : a static xdsl line interface - xdsl-channel : a static xdsl channel interface - atm-if : a static atm interface - atm-pvc : an atm pvc interface - bridge-port : a vlan bridge-port - bridge-port:ng2 : a ngpon2 vlan bridge-port - l2-vlan : a l2-vlan interface - ip : an ip interface - sw-loopback : a software loopback interface - slip : a slip interface - atm-bonding : atm bonding obsolete alternative replaced by bonding - bonding : bonding - ip-gateway : ip user gateway interface - ip-line : ip line interface - shdsl-line : a static shdsl line interface - e1-line : a e1 line interface - atm-ima : atm ima - ethernet-line : an ethernet line interface - vlan-port : vlan port - vlan-port:ng2 : a ngpon2 vlan port - pon : pon - x-pon : xgs pon - 25g-pon : 25g pon - chpair : channelpair - chgroup : channelgroup - subchgroup : subchannelgroup - bundle : bundle </pre>	

name	Type	Description
	- ont : ont - ont:ng2 : ngpon2 ONT style identification - uni : uni - uni:ng2 : ngpon2 UNI style identification - voip : voip - voip:ng2 : voip - la-group : link aggregation group - dist-router-interface : dist router interface - voicefxs : voicefxs - mpm : multi-pon module Possible values: - vlan : vlan port Possible values: - slot-vlan : slot unstacked - slot-stacked : slot vlan port Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number Field type <Eqpt::VpiId> - atm VPI Field type <Eqpt::VciId> - atm VCI Field type <Eqpt::PonId> - the PON identifier Field type <Eqpt::XPonId> - the XGS PON identifier Field type <Eqpt::M25GPonId> - the 25G PON identifier Field type <Eqpt::ComboPonId> - the comboPON identifier Field type <Eqpt::ChannelPairId> - the channel pair identifier Field type <Eqpt::ChannelGroupId> - the channel group identifier Field type <Eqpt::SubChannelGroupId> - the subchannel group identifier Field type <Eqpt::BundleId> - the BUNDLE identifier Field type <Eqpt::OntId> - the ONT identifier Field type <Eqpt::Ng2OntId> - the NG2 ONT identifier Possible values: - voip : virtual uni identifier obsolete alternative replaced by vuni - vuni : virtual uni identifier Possible values: - vuni : virtual NGPON2 uni identifier Field type <Eqpt::OntSlotId> - the ONT SLOT identifier Field type <Eqpt::OntPortId> - the ONT PORT identifier	

181 Security Status Commands

name	Type	Description
	Field type <Eqpt::Ng2OntSlotId> - the NGPON2 ONT SLOT identifier Field type <Eqpt::Ng2OntPortId> - the NGPON2 ONT PORT identifier Field type <Eqpt::LLId> - the LLID identifier,range 1 for EPON,range 1-8 for DPOE Possible values: - stacked : stacked vlan identity Field type <Eqpt::UnstackedVlan> - unstacked vlan id Field type <Eqpt::SVlan> - service vlan id Field type <Eqpt::CVlan> - customer vlan id Field type <Eqpt::VlanId> - VLAN id Field type <Eqpt::LogicalId> - logical id Field type <Eqpt::VrfId> - VRF id	
protocol	Parameter type: <Aaa::Protocol> (ppp dot1x) Possible values: - ppp : ppp used to establish user sess - dot1x : dot1x used to establish user sess	the protocol at user side that was used to establish this user session <i>This element is only shown in detail mode.</i>
auth-type	Parameter type: <Aaa::Authenticator> (local radius : <Aaa::RadPolicyName>) Possible values: - local : authenticator type is local - radius : authenticator type is RADIUS Field type <Aaa::RadPolicyName> - name of the radius policy - length: 1<=x<=64	the Authentication type used for establishing this user session <i>This element is only shown in detail mode.</i>
auth-server	Parameter type: <Aaa::IgnoredRadAuthServer> (none name : <Aaa::RadAuthServerName>) Possible values: - none : no radius server for authentication - name : use a radius server for authentication Field type <Aaa::RadAuthServerName> - name of the RADIUS auth server - length: 1<=x<=64	the name of the radius authentication server used for this user session <i>This element is only shown in detail mode.</i>
acc-server	Parameter type: <Aaa::RadAccServer> (none name : <Aaa::RadAccServerName>) Possible values: - none : no radius server for accounting - name : use a radius server for accounting Field type <Aaa::RadAccServerName> - name of the RADIUS accounting server - length: 1<=x<=64	the name of the radius accounting server used for this user session <i>This element is only shown in detail mode.</i>
accounting-id	Parameter type: <Aaa::DisplayString> - a description - length: 1<=x<=64	the accounting id that is sent to the radius accounting server for this user session. It will be NULL in case of no accounting.

name	Type	Description
		<i>This element is only shown in detail mode.</i>
vrf-index	Parameter type: <Aaa::VrfIndex> - a vrf index. Vrf index must be 0 if not support VRF. - range: [0...127]	the vrf to which the ip-address of this user session belongs to <i>This element is only shown in detail mode.</i>
ip-pool-index	Parameter type: <Aaa::DomainUserSessIpAddrPoolIndex> - local IP Pool for allocating Ip address to user session - range: [0...256]	the ip-pool that was used to allocate an ip-address to the user session <i>This element is only shown in detail mode.</i>
ip-addr	Parameter type: <Aaa::InetAddress> - IPv4-address	the IPAddress allocated to the user session <i>This element is always shown.</i>

181.5 Connection Profile Status Command

Command Description

This command displays the status of connection profiles.

User Level

The command can be accessed by operators with aaa privileges.

Command Syntax

The command has the following syntax:

```
> show security aaa conn-profile [ (name) ]
```

Command Parameters

Table 181.5-1 "Connection Profile Status Command" Resource Parameters

Resource Identifier	Type	Description
(name)	Format: - a profile name - range: [a-zA-Z0-9-_.] - length: 1<=x<=32	name of connection profile

Command Output

Table 181.5-2 "Connection Profile Status Command" Display parameters

Specific Information		
name	Type	Description
number-of-users	Parameter type: <AsamProfileRefCount> - number of entities using this particular profile - range: [0...65535]	The number of entities using this profile. The profile can only be deleted when this number is 0. <i>This element is always shown.</i>
index	Parameter type: <AsamProfileIndex> - a profile index - range: [1...250]	connection profile index <i>This element is always shown.</i>

181.6 RADIUS Authentication Server Status Command

Command Description

This command displays the state of the RADIUS authentication server.

User Level

The command can be accessed by operators with aaa privileges.

Command Syntax

The command has the following syntax:

```
> show security radius auth-server state [ (name) [ router-instance <Ihub::Router> ] ]
```

Command Parameters

Table 181.6-1 "RADIUS Authentication Server Status Command" Resource Parameters

Resource Identifier	Type	Description
(name)	Format: - name of the RADIUS auth server - length: 1<=x<=64	name of RADIUS authentication server
router-instance	Parameter type: <Ihub::Router> Format: (base <Ihub::Router>) Possible values: - base : base router Field type <Ihub::Router> - vprn service-id - range: [1...2147483647]	router to which this auth server belongs

Command Output

Table 181.6-2 "RADIUS Authentication Server Status Command" Display parameters

Specific Information		
name	Type	Description
auth-state	Parameter type: <Aaa::OperState> (up down unknown) Possible values: - up : Operational state up	The operational state of the authentication server. <i>This element is always shown.</i>

181 Security Status Commands

name	Type	Description
	- down : Operational state down - unknown : Operational state unknown	

181.7 RADIUS Authentication Server Statistics

Command

Command Description

This command displays the details of RADIUS authentication server statistics.

User Level

The command can be accessed by operators with aaa privileges.

Command Syntax

The command has the following syntax:

```
> show security radius auth-server auth-stats [ (name) [ router-instance <Ihub::Router> ] ]
```

Command Parameters

Table 181.7-1 "RADIUS Authentication Server Statistics Command" Resource Parameters

Resource Identifier	Type	Description
(name)	Format: - name of the RADIUS auth server - length: 1<=x<=64	name of RADIUS authentication server
router-instance	Parameter type: <Ihub::Router> Format: (base <Ihub::Router>) Possible values: - base : base router Field type <Ihub::Router> - vprn service-id - range: [1...2147483647]	router to which this auth server belongs

Command Output

Table 181.7-2 "RADIUS Authentication Server Statistics Command" Display parameters

Specific Information		
name	Type	Description
auth-server-id	Parameter type: <Aaa::RadAuthServerIndex> - uniquely identify a radius auth server - range: [1...256]	authentication server id <i>This element is always shown.</i>
rndtrp-time short name: rndtrp	Parameter type: <TimeTicks> - a timeout value - unit: msec	The time interval between the most recent Access-Reply/Access-Challenge

181 Security Status Commands

name	Type	Description
		and the Access-Request that matched it from this RADIUS authentication server. <i>This element is always shown.</i>
num-access-req short name: num-acr-rq	Parameter type: <Counter> - 32 bit counter	The number of RADIUS Access-Request packets sent to this server. This does not include retransmissions. <i>This element is always shown.</i>
num-access-retrn short name: num-acr-ret	Parameter type: <Counter> - 32 bit counter	The number of RADIUS Access-Request packets retransmitted to this RADIUS authentication server. <i>This element is always shown.</i>
num-access-acpts short name: num-acr-acp	Parameter type: <Counter> - 32 bit counter	The number of RADIUS Access-Accept packets (valid or invalid) received from this server. <i>This element is always shown.</i>
num-access-rej short name: num-acr-rj	Parameter type: <Counter> - 32 bit counter	The number of RADIUS Access-Reject packets (valid or invalid) received from this server. <i>This element is always shown.</i>
num-access-challenges short name: num-acr-chlg	Parameter type: <Counter> - 32 bit counter	The number of RADIUS Access-Challenge packets (valid or invalid) received from this server. <i>This element is only shown in detail mode.</i>
num-malf-access-resp short name: num-acr-res	Parameter type: <Counter> - 32 bit counter	The number of malformed RADIUS Access-Response packets received from this server. Malformed packets include packets with an invalid length, Bad authenticators or Signature attributes or unknown types are not included as malformed access responses. <i>This element is only shown in detail mode.</i>
num-bad-authenticators short name: num-bad-auth	Parameter type: <Counter> - 32 bit counter	The number of RADIUS Access-Response packets containing invalid authenticators or signature received from this server. <i>This element is only shown in detail mode.</i>
num-pending-req short name: num-pd-rq	Parameter type: <Gauge> - gauge	The number of RADIUS Access-Request packets destined for this server that have not yet timed out or received a response. <i>This element is only shown in detail mode.</i>
num-timeouts short name: num-tout	Parameter type: <Counter> - 32 bit counter	The number of authentication timeouts to this server. <i>This element is only shown in detail mode.</i>
num-unknown	Parameter type: <Counter>	The number of RADIUS packets

181 Security Status Commands

name	Type	Description
short name: num-ukwn	- 32 bit counter	of unknown type which were received from this server on the authentication port. <i>This element is only shown in detail mode.</i>
num-packets-dropped short name: num-pkt-dpd	Parameter type: <Counter> - 32 bit counter	The number of RADIUS packets of which were received from this server on the authentication port and dropped. <i>This element is only shown in detail mode.</i>

181.8 RADIUS Accounting Server Statistics

Command

Command Description

This command displays the RADIUS accounting server statistics.

User Level

The command can be accessed by operators with aaa privileges.

Command Syntax

The command has the following syntax:

```
> show security radius acc-server acc-stats [ (name) [ router-instance <Ihub::Router> ] ]
```

Command Parameters

Table 181.8-1 "RADIUS Accounting Server Statistics Command" Resource Parameters

Resource Identifier	Type	Description
(name)	Format: - name of the RADIUS accounting server - length: 1<=x<=64	name of the RADIUS accounting server
router-instance	Parameter type: <Ihub::Router> Format: (base <Ihub::Router>) Possible values: - base : base router Field type <Ihub::Router> - vprn service-id - range: [1...2147483647]	router to which the RADIUS Acc Server belongs

Command Output

Table 181.8-2 "RADIUS Accounting Server Statistics Command" Display parameters

Specific Information		
name	Type	Description
rndtrip-time short name: rndtp	Parameter type: <TimeTicks> - a timeout value - unit: msec	The time interval between the most recent accounting-response and the accounting-request that matched it from this RADIUS accounting server. <i>This element is always shown.</i>

name	Type	Description
num-acc-req short name: num-acrq	Parameter type: <Counter> - 32 bit counter	The number of RADIUS accounting-request packets sent. This does not include retransmissions. <i>This element is always shown.</i>
num-req-retrans short name: num-rq-rtn	Parameter type: <Counter> - 32 bit counter	The number of RADIUS accounting-request packets retransmitted to this RADIUS accounting server. Retransmissions include retries where the identifier and acct-delay have been updated, as well as those in which they remain the same. <i>This element is always shown.</i>
num-resp short name: num-rec	Parameter type: <Counter> - 32 bit counter	The number of RADIUS packets received on the accounting port from this server. <i>This element is always shown.</i>
num-malf-resp short name: num-rsp	Parameter type: <Counter> - 32 bit counter	The number of malformed RADIUS accounting-response packets received from this server. Malformed packets include packets with an invalid length. Bad authenticators and unknown types are not included as malformed accounting responses. <i>This element is only shown in detail mode.</i>
num-bad-authenticators short name: num-bad-auth	Parameter type: <Counter> - 32 bit counter	The number of RADIUS accounting-response packets which contained invalid authenticators received from this server. <i>This element is only shown in detail mode.</i>
num-pending-reqts short name: num-pd-rqt	Parameter type: <Gauge> - gauge	The number of RADIUS accounting-request packets sent to this server that have not yet timed out or received a response. <i>This element is always shown.</i>
num-timeouts short name: num-tout	Parameter type: <Counter> - 32 bit counter	The number of accounting timeouts to this server. <i>This element is only shown in detail mode.</i>
num-unknown short name: num-ukwn	Parameter type: <Counter> - 32 bit counter	The number of RADIUS packets of unknown type which were received from this server on the accounting port. <i>This element is only shown in detail mode.</i>
num-packets-dropped short name: num-pkt-dpd	Parameter type: <Counter> - 32 bit counter	The number of RADIUS packets which were received from this server on the accounting port and dropped. <i>This element is only shown in detail mode.</i>

181.9 RADIUS Accounting Server Status Command

Command Description

This command displays the state of the RADIUS accounting server.

User Level

The command can be accessed by operators with aaa privileges.

Command Syntax

The command has the following syntax:

```
> show security radius acc-server state [ (name) [ router-instance <Ihub::Router> ] ]
```

Command Parameters

Table 181.9-1 "RADIUS Accounting Server Status Command" Resource Parameters

Resource Identifier	Type	Description
(name)	Format: - name of the RADIUS accounting server - length: 1<=x<=64	name of the RADIUS accounting server
router-instance	Parameter type: <Ihub::Router> Format: (base <Ihub::Router>) Possible values: - base : base router Field type <Ihub::Router> - vprn service-id - range: [1...2147483647]	Router to which the RADIUS Acc Server belongs

Command Output

Table 181.9-2 "RADIUS Accounting Server Status Command" Display parameters

Specific Information		
name	Type	Description
acc-state	Parameter type: <Aaa::OperState> (up down unknown) Possible values: - up : Operational state up - down : Operational state down - unknown : Operational state unknown	Specifies the operational state of the accounting server. <i>This element is always shown.</i>

181.10 RADIUS Dynamic Authentication Client Status Command

Command Description

This command displays the statistics of the RADIUS Dynamic Authentication Client.

The conceptual table lists the statistics of the RADIUS Dynamic Authorization Clients with which the server shares a secret.

User Level

The command can be accessed by operators with aaa privileges.

Command Syntax

The command has the following syntax:

```
> show security radius dyn-authclient-stats [ (name) [ router-instance <Ihub::Router> ] ]
```

Command Parameters

Table 181.10-1 "RADIUS Dynamic Authentication Client Status Command" Resource Parameters

Resource Identifier	Type	Description
(name)	Format: - name of dynamic auth client name - length: 1<=x<=64	name of the RADIUS Dynamic Authorization client
router-instance	Parameter type: <Ihub::Router> Format: (base <Ihub::Router>) Possible values: - base : base router Field type <Ihub::Router> - vprn service-id - range: [1...2147483647]	router to which the RADIUS Dyn Auth Client belongs

Command Output

Table 181.10-2 "RADIUS Dynamic Authentication Client Status Command" Display parameters

Specific Information		
name	Type	Description
num-disconnect-reqs	Parameter type: <Counter> - 32 bit counter	The number of RADIUS Disconnect-Request packets recieved from this Dynamic Authorization Client.

name	Type	Description
		<i>This element is always shown.</i>
num-disconnect-acks	Parameter type: <Counter> - 32 bit counter	The number of RADIUS Disconnect-ACK packets sent to this Dynamic Authorization Client. <i>This element is always shown.</i>
num-access-naks	Parameter type: <Counter> - 32 bit counter	The number of RADIUS Disconnect-NAK packets sent to this Dynamic Authorization Client. <i>This element is always shown.</i>
num-malf-disconn-req	Parameter type: <Counter> - 32 bit counter	The number of malformed RADIUS Disconnect-Request packets received from this Dynamic Authorization client. Bad authenticators and unknown types are not included as malformed Disconnect-Requests. Malformed packets include packets with an invalid length. <i>This element is only shown in detail mode.</i>
num-bad-auth-in-req	Parameter type: <Counter> - 32 bit counter	The number of RADIUS Disconnect-Request packets which contained invalid Signature attributes received from this Dynamic Authorization Client. <i>This element is only shown in detail mode.</i>
num-disconn-pkts-drop	Parameter type: <Counter> - 32 bit counter	The number of incoming Disconnect-Requests from this Dynamic Authorization Client silently discarded for some reason other than malformed, bad authenticators or unknown types. <i>This element is only shown in detail mode.</i>
num-pkts-unknown-type	Parameter type: <Counter> - 32 bit counter	The number of incoming packets of unknown types which were received on the Dynamic Authorization port. <i>This element is only shown in detail mode.</i>

181.11 RADIUS Next Available Index Command

Command Description

This command displays the next available index.

The index is used to uniquely identify an entry in this table. The next-free-index shows the unique number in a RADIUS policy that can be used to create a new entry in the RADIUS server. The value 0 indicates that no unassigned entry is available. To obtain the RADIUS server index value for a new entry, the manager issues a management protocol retrieval operation to obtain the current value of this object. After each retrieval, the agent modifies the value to the next unassigned index.

User Level

The command can be accessed by operators with aaa privileges.

Command Syntax

The command has the following syntax:

```
> show security radius next-free-index [ (name) ]
```

Command Parameters

Table 181.11-1 "RADIUS Next Available Index Command" Resource Parameters

Resource Identifier	Type	Description
(name)	Format: - name of the radius policy - length: 1<=x<=64	name of the RADIUS policy

Command Output

Table 181.11-2 "RADIUS Next Available Index Command" Display parameters

Specific Information		
name	Type	Description
next-free-index	Parameter type: <Aaa::RadServerSetNextFreeIndex> - unique nbr in radius policy for creating radServerSet. - range: [0...2]	A unique number within a radius policy that can be used for creating a new radus server set. <i>This element is always shown.</i>

181.12 RADIUS Client Status Command

Command Description

This command displays the RADIUS client parameters.

User Level

The command can be accessed by operators with aaa privileges.

Command Syntax

The command has the following syntax:

> show security radius radius-client

Command Output

Table 181.12-2 "RADIUS Client Status Command" Display parameters

Specific Information		
name	Type	Description
auth-invl-server-addr	Parameter type: <Counter> - 32 bit counter	The number of RADIUS Access-Response packets received from unknown addresses. <i>This element is always shown.</i>
acc-invl-server-addr	Parameter type: <Counter> - 32 bit counter	The number of RADIUS Accounting-Response packets received from unknown addresses. <i>This element is always shown.</i>
dynauth-ser-inv-addr	Parameter type: <Counter> - 32 bit counter	The number of RADIUS Disconnect-Request packets received from unknown addresses. <i>This element is always shown.</i>
acc-ser-get-nxt-idx	Parameter type: <Aaa::RadAccServerGetNextFreeIndex> - next free index for creating a radius accounting server - range: [0...256]	The next free index value that can be used for creating a new entry in the radius accounting server. <i>This element is always shown.</i>
dyn-auth-get-nxt-idx	Parameter <Aaa::RadDynAuthClntGetNextFreeIndex> - next free index for creating a radius dyn auth client - range: [0...256]	type: The next free index value that can be used for creating a new entry in the radius dyn auth client. <i>This element is always shown.</i>

181.13 Tacacs authentication Server Status

Command

Command Description

This command displays the state of the tacacs authentication server.

User Level

The command can be accessed by operators with aaa privileges.

Command Syntax

The command has the following syntax:

```
> show security tacacs authen-server state [ (name) [ router-instance <Ihub::Router> ] ]
```

Command Parameters

Table 181.13-1 "Tacacs authentication Server Status Command" Resource Parameters

Resource Identifier	Type	Description
(name)	Format: - name of the TACACS+ authentication server - length: 1<=x<=64	name of the TACACS authentication server
router-instance	Parameter type: <Ihub::Router> Format: (base <Ihub::Router>) Possible values: - base : base router Field type <Ihub::Router> - vprn service-id - range: [1...2147483647]	Router to which the TACACS authen Server belongs

Command Output

Table 181.13-2 "Tacacs authentication Server Status Command" Display parameters

Specific Information		
name	Type	Description
state	Parameter type: <Aaa::OperState> (up down unknown) Possible values: - up : Operational state up	Specifies the operational state of the authen server. <i>This element is always shown.</i>

name	Type	Description
	- down : Operational state down - unknown : Operational state unknown	

181.14 TACACS Authentication Server Statistics Command

Command Description

This command displays the TACACS authentication server statistics.

User Level

The command can be accessed by operators with aaa privileges.

Command Syntax

The command has the following syntax:

```
> show security tacacs authen-server statistics [ (name) [ router-instance <Ihub::Router> ] ]
```

Command Parameters

Table 181.14-1 "TACACS Authentication Server Statistics Command" Resource Parameters

Resource Identifier	Type	Description
(name)	Format: - name of the TACACS+ authentication server - length: 1<=x<=64	name of the TACACS authentication server
router-instance	Parameter type: <Ihub::Router> Format: (base <Ihub::Router>) Possible values: - base : base router Field type <Ihub::Router> - vprn service-id - range: [1...2147483647]	router to which the TACACS Authentication Server belongs

Command Output

Table 181.14-2 "TACACS Authentication Server Statistics Command" Display parameters

Specific Information		
name	Type	Description
server-id	Parameter type: <Aaa::TacAuthenServerIndex> - Index used to uniquely identify a tacacs authentication server - range: [1...256]	authentication server id <i>This element is always shown.</i>
round-trip-time short name: rtt	Parameter type: <TimeTicks> - a timeout value	The time interval (in hundredths of a second) between the most

name	Type	Description
	- unit: msec	recent START/REPLY or CONTINUE/REPLY. <i>This element is always shown.</i>
start packets short name: start	Parameter type: <Counter> - 32 bit counter	The number of TACACS+ authentication START packets sent to authentication server. <i>This element is always shown.</i>
continue packets short name: cont	Parameter type: <Counter> - 32 bit counter	The number of TACACS+ authentication CONTINUE packets sent to authentication server. <i>This element is always shown.</i>
replies short name: rep	Parameter type: <Counter> - 32 bit counter	The number of TACACS+ authentication REPLY packets received from authentication server. <i>This element is always shown.</i>
pass-replies short name: pass	Parameter type: <Counter> - 32 bit counter	The number of TACACS+ authentication PASS REPLY packets received from authentication server, indicating authentication passed. <i>This element is always shown.</i>
fail-replies short name: fail	Parameter type: <Counter> - 32 bit counter	The number of TACACS+ authentication FAIL REPLY packets received from authentication server, indicating authentication failed. <i>This element is only shown in detail mode.</i>
get-password-replies short name: get-pw	Parameter type: <Counter> - 32 bit counter	The number of TACACS+ authentication GET PASSWORD REPLY packets from authentication server. <i>This element is always shown.</i>
error-replies short name: err	Parameter type: <Counter> - 32 bit counter	The number of TACACS+ authentication ERROR REPLY packets received from authentication server. <i>This element is only shown in detail mode.</i>
other-replies short name: other	Parameter type: <Counter> - 32 bit counter	"The number of TACACS+ other authentication REPLY packets received from authentication server including GetData, GetUser, Restart or Follow message. <i>This element is always shown.</i>
timeout-requests short name: t-out	Parameter type: <Counter> - 32 bit counter	The number of TACACS+ authentication START or CONTINUE packets destined for authentication server that have not yet received a reply after waiting timer expires. <i>This element is only shown in detail mode.</i>
malformed-responses	Parameter type: <Counter>	The number of malformed

181 Security Status Commands

name	Type	Description
short name: mal	- 32 bit counter	TACACS+ authentication response packets. It includes such packets with invalid length, message type, etc. The number of TCP error relevant packets is excluded from this counter. <i>This element is only shown in detail mode.</i>

181.15 Tacacs authorization Server Status

Command

Command Description

This command displays the state of the tacacs authorization server.

User Level

The command can be accessed by operators with aaa privileges.

Command Syntax

The command has the following syntax:

```
> show security tacacs author-server state [ (name) [ router-instance <Ihub::Router> ] ]
```

Command Parameters

Table 181.15-1 "Tacacs authorization Server Status Command" Resource Parameters

Resource Identifier	Type	Description
(name)	Format: - name of the TACACS+ authorization server - length: 1<=x<=64	name of the TACACS authorization server
router-instance	Parameter type: <Ihub::Router> Format: (base <Ihub::Router>) Possible values: - base : base router Field type <Ihub::Router> - vprn service-id - range: [1...2147483647]	Router to which the TACACS author Server belongs

Command Output

Table 181.15-2 "Tacacs authorization Server Status Command" Display parameters

Specific Information		
name	Type	Description
state	Parameter type: <Aaa::OperState> (up down unknown) Possible values: - up : Operational state up	Specifies the operational state of the author server. <i>This element is always shown.</i>

181 Security Status Commands

name	Type	Description
	- down : Operational state down - unknown : Operational state unknown	

181.16 TACACS Authorization Server Statistics Command

Command Description

This command displays the TACACS authorization server statistics.

User Level

The command can be accessed by operators with aaa privileges.

Command Syntax

The command has the following syntax:

```
> show security tacacs author-server statistics [ (name) [ router-instance <Ihub::Router> ] ]
```

Command Parameters

Table 181.16-1 "TACACS Authorization Server Statistics Command" Resource Parameters

Resource Identifier	Type	Description
(name)	Format: - name of the TACACS+ authorization server - length: 1<=x<=64	name of the TACACS authorization server
router-instance	Parameter type: <Ihub::Router> Format: (base <Ihub::Router>) Possible values: - base : base router Field type <Ihub::Router> - vprn service-id - range: [1...2147483647]	router to which the TACACS Authorization Server belongs

Command Output

Table 181.16-2 "TACACS Authorization Server Statistics Command" Display parameters

Specific Information		
name	Type	Description
server-id	Parameter type: <Aaa::TacAuthorServerIndex> - Index used to uniquely identify a tacacs authorization server - range: [1...256]	authorization server id <i>This element is always shown.</i>
round-trip-time short name: rtt	Parameter type: <TimeTicks> - a timeout value	"The time interval between the between the most recent

181 Security Status Commands

name	Type	Description
	- unit: msec	authorization REQUEST and REPLY. <i>This element is always shown.</i>
requests short name: req	Parameter type: <Counter> - 32 bit counter	The number of TACACS+ authorization REQUEST packets sent. <i>This element is always shown.</i>
replies short name: rep	Parameter type: <Counter> - 32 bit counter	The number of TACACS+ authorization REPLY packets received from authorization server. <i>This element is always shown.</i>
pass-replies short name: pass	Parameter type: <Counter> - 32 bit counter	The number of TACACS+ authorization PASS REPLY packets received from authorization server. <i>This element is always shown.</i>
fail-replies short name: fail	Parameter type: <Counter> - 32 bit counter	The number of TACACS+ authorization FAIL REPLY packets received from authorization server. <i>This element is only shown in detail mode.</i>
follow-replies short name: fol	Parameter type: <Counter> - 32 bit counter	The number of TACACS+ authorization FOLLOW REPLY packets received from authorization server. <i>This element is only shown in detail mode.</i>
error-replies short name: err	Parameter type: <Counter> - 32 bit counter	The number of TACACS+ authorization ERROR REPLY packets received from authorization server. <i>This element is only shown in detail mode.</i>
timeout-requests short name: t-out	Parameter type: <Counter> - 32 bit counter	The number of TACACS+ authorization REQUEST packets sent to this server that have not received a reply yet after waiting timer expires. <i>This element is only shown in detail mode.</i>
malformed-responses short name: mal	Parameter type: <Counter> - 32 bit counter	The number of malformed TACACS+ authorization response packets. It includes such packets with invalid length, message type, etc. The number of TCP error relevant packets is excluded from this counter. <i>This element is only shown in detail mode.</i>

181.17 Tacacs Accounting Server Status Command

Command Description

This command displays the state of the tacacs Accounting server.

User Level

The command can be accessed by operators with aaa privileges.

Command Syntax

The command has the following syntax:

```
> show security tacacs acc-server state [ (name) [ router-instance <Ihub::Router> ] ]
```

Command Parameters

Table 181.17-1 "Tacacs Accounting Server Status Command" Resource Parameters

Resource Identifier	Type	Description
(name)	Format: - name of the TACACS+ accounting server - length: 1<=x<=64	name of the TACACS accounting server
router-instance	Parameter type: <Ihub::Router> Format: (base <Ihub::Router>) Possible values: - base : base router Field type <Ihub::Router> - vprn service-id - range: [1...2147483647]	Router to which the TACACS Acc Server belongs

Command Output

Table 181.17-2 "Tacacs Accounting Server Status Command" Display parameters

Specific Information		
name	Type	Description
state	Parameter type: <Aaa::OperState> (up down unknown) Possible values: - up : Operational state up - down : Operational state down - unknown : Operational state unknown	Specifies the operational state of the accounting server. <i>This element is always shown.</i>

181.18 TACACS Accounting Server Statistics

Command

Command Description

This command displays the TACACS accounting server statistics.

User Level

The command can be accessed by operators with aaa privileges.

Command Syntax

The command has the following syntax:

```
> show security tacacs acc-server statistics [ (name) [ router-instance <Ihub::Router> ] ]
```

Command Parameters

Table 181.18-1 "TACACS Accounting Server Statistics Command" Resource Parameters

Resource Identifier	Type	Description
(name)	Format: - name of the TACACS+ accounting server - length: 1<=x<=64	name of the TACACS accounting server
router-instance	Parameter type: <Ihub::Router> Format: (base <Ihub::Router>) Possible values: - base : base router Field type <Ihub::Router> - vprn service-id - range: [1...2147483647]	router to which the TACACS Acc Server belongs

Command Output

Table 181.18-2 "TACACS Accounting Server Statistics Command" Display parameters

Specific Information		
name	Type	Description
server-id	Parameter type: <Aaa::TacAccServerIndex> - Index used to uniquely identify a tacacs accounting server - range: [1...256]	accounting server id <i>This element is always shown.</i>
round-trip-time short name: rtt	Parameter type: <TimeTicks> - a timeout value - unit: msec	The time interval between the most recent accounting request and reply.

name	Type	Description
		<i>This element is always shown.</i>
requests short name: req	Parameter type: <Counter> - 32 bit counter	The number of TACACS+ accounting REQUEST packets sent. <i>This element is always shown.</i>
replies short name: rep	Parameter type: <Counter> - 32 bit counter	"The number of TACACS+ REPLY accounting packets received from accounting server. <i>This element is always shown.</i>
successful-replies short name: suc	Parameter type: <Counter> - 32 bit counter	The number of TACACS+ accounting SUCC REPLY packets received from accounting server. <i>This element is always shown.</i>
error-replies short name: err	Parameter type: <Counter> - 32 bit counter	The number of TACACS+ accounting ERROR REPLY packets received from accounting server. <i>This element is only shown in detail mode.</i>
follow-replies short name: fol	Parameter type: <Counter> - 32 bit counter	The number of TACACS+ accounting FOLLOW REPLY packets received from accounting server. <i>This element is only shown in detail mode.</i>
timeout-requests short name: t-out	Parameter type: <Counter> - 32 bit counter	The number of TACACS+ accounting REQUEST packets sent to accounting server that have not received a reply yet, after waiting timer expires. <i>This element is only shown in detail mode.</i>
malformed-responses short name: mal	Parameter type: <Counter> - 32 bit counter	The number of malformed TACACS+ accounting response packets. It includes such packets with invalid length, message type, etc. The number of TCP error relevant packets is excluded from this counter. <i>This element is only shown in detail mode.</i>

181.19 PAE Authenticator Status Command

Command Description

This command displays the details of authentication configuration.

User Level

The command can be accessed by operators with aaa privileges.

Command Syntax

The command has the following syntax:

```
> show security pae authenticator [ (port) ]
```

Command Parameters

Table 181.19-1 "PAE Authenticator Status Command" Resource Parameters

Resource Identifier	Type	Description
(port)	Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::VpiId> : <Eqpt::VciId> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> / <Eqpt::OntPortId> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / voip <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / vuni <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::LLId> ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / <Eqpt::Ng2OntSlotId> / <Eqpt::Ng2OntPortId> ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / vuni) Possible values: - ng2 : ngpon2 style identification Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number	the identification of the bridge port

Resource Identifier	Type	Description
	Field type <Eqpt::VpId> - atm VPI Field type <Eqpt::VciId> - atm VCI Field type <Eqpt::ChannelGroupId> - the channel group identifier Field type <Eqpt::SubChannelGroupId> - the subchannel group identifier Field type <Eqpt::PonId> - the PON identifier Field type <Eqpt::OntId> - the ONT identifier Field type <Eqpt::Ng2OntId> - the NG2 ONT identifier Possible values: - voip : virtual uni identifier obsolete alternative replaced by vuni - vuni : virtual uni identifier Possible values: - vuni : virtual NGPON2 uni identifier Field type <Eqpt::OntSlotId> - the ONT SLOT identifier Field type <Eqpt::OntPortId> - the ONT PORT identifier Field type <Eqpt::Ng2OntSlotId> - the NGPON2 ONT SLOT identifier Field type <Eqpt::Ng2OntPortId> - the NGPON2 ONT PORT identifier Field type <Eqpt::LLId> - the LLID identifier, range 1 for EPON, range 1-8 for DPOE	

Command Output

Table 181.19-2 "PAE Authenticator Status Command" Display parameters

Specific Information		
name	Type	Description
auth-pae-state	Parameter type: <Aaa::AuthPaeState> (initialize disconnected connecting authenticating authenticated aborting held force-auth force-unauth) Possible values: - initialize : - disconnected : - connecting : - authenticating : - authenticated : - aborting : - held : - force-auth : - force-unauth :	the current state of the authenticator PAE state machine <i>This element is always shown.</i>

181 Security Status Commands

name	Type	Description
mac-auth-enabled	Parameter type: <Aaa::MacAuthState> (mac-auth no-mac-auth) Possible values: - mac-auth : enable 802.1x mac authentication - no-mac-auth : disable 802.1x mac authentication	if the 802.1x mac authentication enabled <i>This element is only shown in detail mode.</i>
auth-backend-state	Parameter type: <Aaa::AuthBackendState> (request response success fail timeout idle initialize) Possible values: - request : - response : - success : - fail : - timeout : - idle : - initialize :	the current state of the backend authentication state machine <i>This element is always shown.</i>
admin-contr-direct	Parameter type: <Aaa::PaeControlledDirections> both Possible values: - both :	describes which directions for the port are configured to be controlled <i>This element is only shown in detail mode.</i>
oper-contr-direct	Parameter type: <Aaa::PaeControlledDirections> both Possible values: - both :	describes which directions for the port are currently be controlled <i>This element is only shown in detail mode.</i>
port-status	Parameter type: <Aaa::PaeControlledPortStatus> (authorized unauthorized) Possible values: - authorized : - unauthorized :	the current port status <i>This element is always shown.</i>
re-auth-period	Parameter type: <Aaa::paeReauthPeriod> - re-authentication Period - unit: sec - range: [1...65535]	the actual re-authentication period, value in seconds <i>This element is only shown in detail mode.</i>
re-auth-enabled	Parameter type: <Aaa::TruthValue> (true false) Possible values: - true : - false :	true if re-authentication is enabled <i>This element is only shown in detail mode.</i>
key-tx-enabled	Parameter type: <Aaa::TruthValue> (true false) Possible values: - true : - false :	true if key transmission is enabled <i>This element is only shown in detail mode.</i>
handshake-mode	Parameter type: <Aaa::PortHandShakeMode> (handshake no-handshake) Possible values:	the handshake period <i>This element is only shown in detail mode.</i>

name	Type	Description
	- handshake : enable handshake for this port - no-handshake : disable handshake for this port	
handshake-period	Parameter type: <Aaa::PortHandShakePeriod> - handshake time interval - unit: sec - range: [5...90]	true if handshake mode is enabled <i>This element is only shown in detail mode.</i>

181.20 EAPOL Statistics Command

Command Description

This command displays EAPOL statistics.

User Level

The command can be accessed by operators with aaa privileges.

Command Syntax

The command has the following syntax:

```
> show security pae eapol-stats [ (port) ]
```

Command Parameters

Table 181.20-1 "EAPOL Statistics Command" Resource Parameters

Resource Identifier	Type	Description
(port)	Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::VpiId> : <Eqpt::VciId> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> / <Eqpt::OntPortId> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / voip <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / vuni <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::LLId> ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / <Eqpt::Ng2OntSlotId> / <Eqpt::Ng2OntPortId> ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / vuni) Possible values: - ng2 : ngpon2 style identification Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number	identification of the port or virtual channel

Resource Identifier	Type	Description
	Field type <Eqpt::VpId> - atm VPI Field type <Eqpt::VciId> - atm VCI Field type <Eqpt::ChannelGroupId> - the channel group identifier Field type <Eqpt::SubChannelGroupId> - the subchannel group identifier Field type <Eqpt::PonId> - the PON identifier Field type <Eqpt::OntId> - the ONT identifier Field type <Eqpt::Ng2OntId> - the NG2 ONT identifier Possible values: - voip : virtual uni identifier obsolete alternative replaced by vuni - vuni : virtual uni identifier Possible values: - vuni : virtual NGPON2 uni identifier Field type <Eqpt::OntSlotId> - the ONT SLOT identifier Field type <Eqpt::OntPortId> - the ONT PORT identifier Field type <Eqpt::Ng2OntSlotId> - the NGPON2 ONT SLOT identifier Field type <Eqpt::Ng2OntPortId> - the NGPON2 ONT PORT identifier Field type <Eqpt::LLId> - the LLID identifier, range 1 for EPON, range 1-8 for DPOE	

Command Output

Table 181.20-2 "EAPOL Statistics Command" Display parameters

Specific Information		
name	Type	Description
rx-frames	Parameter type: <Counter> - 32 bit counter	the number of valid EAPOL frames of any type that have been received by this Authenticator <i>This element is always shown.</i>
tx-frames	Parameter type: <Counter> - 32 bit counter	the number of EAPOL frames of any type that have been transmitted by this Authenticator <i>This element is always shown.</i>
starts	Parameter type: <Counter> - 32 bit counter	the number of EAPOL Start frames that have been received by this Authenticator <i>This element is always shown.</i>
logoffs	Parameter type: <Counter> - 32 bit counter	the number of EAPOL Logoff frames that have been received by this Authenticator <i>This element is always shown.</i>
rx-response-ids	Parameter type: <Counter> - 32 bit counter	the number of EAP Resp/Id frames that have been received by this Authenticator <i>This element is only shown in</i>

181 Security Status Commands

name	Type	Description
		<i>detail mode.</i>
rx-responses	Parameter type: <Counter> - 32 bit counter	number of valid EAP Response frames (other than Resp/Id frames) that have been received by this Authenticator <i>This element is only shown in detail mode.</i>
tx-request-ids	Parameter type: <Counter> - 32 bit counter	the number of EAP Req/Id frames that have been transmitted by this Authenticator <i>This element is only shown in detail mode.</i>
tx-requests	Parameter type: <Counter> - 32 bit counter	the number of EAP Request frames (other than Rq/Id frames) that have been transmitted by this Authenticator <i>This element is only shown in detail mode.</i>
invalid-frames	Parameter type: <Counter> - 32 bit counter	the number of EAPOL frames that have been received by this Authenticator in which the frame type is not recognized <i>This element is always shown.</i>
inv-length-frames	Parameter type: <Counter> - 32 bit counter	the number of EAPOL frames that have been received by this Authenticator in which the Packet Body Length field is invalid <i>This element is only shown in detail mode.</i>
last-eap-version	Parameter type: <SignedInteger> - a signed integer	the protocol version number carried in the most recently received EAPOL frame <i>This element is only shown in detail mode.</i>
last-src-mac	Parameter type: <Vlan::MacAddr> - mac address (aa:bb:cc:a1:02:03) - unit: Byte - length: 6	the source MAC address carried in the most recently received EAPOL frame <i>This element is only shown in detail mode.</i>

181.21 Diagnostic Information Status Command

Command Description

This command displays diagnostic information.

User Level

The command can be accessed by operators with aaa privileges.

Command Syntax

The command has the following syntax:

```
> show security pae diagnostics [ (port) ]
```

Command Parameters

Table 181.21-1 "Diagnostic Information Status Command" Resource Parameters

Resource Identifier	Type	Description
(port)	Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::VpiId> : <Eqpt::VciId> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> / <Eqpt::OntPortId> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / voip <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / vuni <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::LLId> ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / <Eqpt::Ng2OntSlotId> / <Eqpt::Ng2OntPortId> ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / vuni) Possible values: - ng2 : ngpon2 style identification Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number	the identification of the bridge port

Resource Identifier	Type	Description
	Field type <Eqpt::Vpild> - atm VPI Field type <Eqpt::VciId> - atm VCI Field type <Eqpt::ChannelGroupId> - the channel group identifier Field type <Eqpt::SubChannelGroupId> - the subchannel group identifier Field type <Eqpt::PonId> - the PON identifier Field type <Eqpt::OntId> - the ONT identifier Field type <Eqpt::Ng2OntId> - the NG2 ONT identifier Possible values: - voip : virtual uni identifier obsolete alternative replaced by vuni - vuni : virtual uni identifier Possible values: - vuni : virtual NGPON2 uni identifier Field type <Eqpt::OntSlotId> - the ONT SLOT identifier Field type <Eqpt::OntPortId> - the ONT PORT identifier Field type <Eqpt::Ng2OntSlotId> - the NGPON2 ONT SLOT identifier Field type <Eqpt::Ng2OntPortId> - the NGPON2 ONT PORT identifier Field type <Eqpt::LLId> - the LLID identifier, range 1 for EPON, range 1-8 for DPOE	

Command Output

Table 181.21-2 "Diagnostic Information Status Command" Display parameters

Specific Information		
name	Type	Description
to-connecting-cnt	Parameter type: <Counter> - 32 bit counter	the number of times that the state machine transitions to the CONNECTING state from any other state <i>This element is always shown.</i>
log-off-cnt	Parameter type: <Counter> - 32 bit counter	the number of times that the state machine transitions from CONNECTING to DISCONNECTED as a result of receiving an EAPOL-Logoff message <i>This element is always shown.</i>
authenticating-cnt	Parameter type: <Counter> - 32 bit counter	the number of times that the state machine transitions from CONNECTING to AUTHENTICATING, as a result of an EAP-Response/Identity message being received from the Supplicant <i>This element is only shown in</i>

name	Type	Description
		<i>detail mode.</i>
authenticated-cnt	Parameter type: <Counter> - 32 bit counter	the number of times that the state machine transitions from AUTHENTICATING to AUTHENTICATED, as a result of the Backend Authentication state machine indicating successful authentication of the Suppliant (authSuccess = TRUE) <i>This element is always shown.</i>
timeout-cnt	Parameter type: <Counter> - 32 bit counter	the number of times that the state machine transitions from AUTHENTICATING to ABORTING, as a result of the Backend Authentication state machine indicating authentication timeout (authTimeout = TRUE) <i>This element is always shown.</i>
failed-cnt	Parameter type: <Counter> - 32 bit counter	the number of times that the state machine transitions from AUTHENTICATING to HELD, as a result of the Backend Authentication state machine indicating authentication failure (authFail = TRUE) <i>This element is only shown in detail mode.</i>
re-authenticating-cnt	Parameter type: <Counter> - 32 bit counter	the number of times that the state machine transitions from AUTHENTICATING to ABORTING, as a result of a reauthentication request (reAuthenticate = TRUE) <i>This element is only shown in detail mode.</i>
eap-start-cnt	Parameter type: <Counter> - 32 bit counter	the number of times that the state machine transitions from AUTHENTICATING to ABORTING, as a result of an EAPOL-Start message being received from the Suppliant <i>This element is only shown in detail mode.</i>
eap-authing-logoff-cnt	Parameter type: <Counter> - 32 bit counter	the number of times that the state machine transitions from AUTHENTICATING to ABORTING, as a result of an EAPOL-Logoff message being received from the Suppliant <i>This element is only shown in detail mode.</i>
re-authenticated-cnt	Parameter type: <Counter> - 32 bit counter	the number of times that the state machine transitions from AUTHENTICATED to CONNECTING, as a result of a reauthentication request

181 Security Status Commands

name	Type	Description
		(reAuthenticate = TRUE) <i>This element is only shown in detail mode.</i>
eap-connecting-cnt	Parameter type: <Counter> - 32 bit counter	the number of times that the state machine transitions from AUTHENTICATED to CONNECTING, as a result of an EAPOL-Start message being received from the Supplicant <i>This element is only shown in detail mode.</i>
eap-authed-logoff-cnt	Parameter type: <Counter> - 32 bit counter	the number of times that the state machine transitions from AUTHENTICATED to DISCONNECTED, as a result of an EAPOL-Logoff message being received from the Supplicant <i>This element is only shown in detail mode.</i>
access-req-cnt	Parameter type: <Counter> - 32 bit counter	the number of times that the state machine sends an initial Access-Request packet to the Authentication server <i>This element is only shown in detail mode.</i>
access-challenge-cnt	Parameter type: <Counter> - 32 bit counter	the number of times that the state machine receives an initial Access-Challenge packet from the Authentication server (i.e., aReq becomes TRUE, causing exit from the RESPONSE state). This indicates that the Authentication Server has communication with the Authenticator <i>This element is only shown in detail mode.</i>
eap-req-cnt	Parameter type: <Counter> - 32 bit counter	the number of times that the state machine sends an EAP-Request packet (other than an Identity, Notification, Failure or Success message) to the Supplicant (i.e., executes txReq on entry to the REQUEST state). This indicates that the Authenticator chose an EAP-method. <i>This element is only shown in detail mode.</i>
resp-non-eap-nak-cnt	Parameter type: <Counter> - 32 bit counter	the number of times that the state machine receives a response from the Supplicant to an initial EAP-Request, and the response is something other than EAP-NAK (i.e., rxResp becomes TRUE, causing the state machine to transition from REQUEST to

name	Type	Description
		RESPONSE, and the response is not an EAP-NAK). This indicates that the Supplicant can respond to the Authenticator's chosen EAP-method <i>This element is only shown in detail mode.</i>
eap-success-cnt	Parameter type: <Counter> - 32 bit counter	the number of times that the state machine receives an EAP-Success message from the Authentication Server (i.e., aSuccess becomes TRUE, causing a transition from RESPONSE to SUCCESS). This indicates that the Supplicant has successfully authenticated to the Authentication Server <i>This element is only shown in detail mode.</i>
num-eap-failure	Parameter type: <Counter> - 32 bit counter	the number of times that the state machine receives an EAP-Failure message from the Authentication Server (i.e., aFail becomes TRUE, causing a transition from RESPONSE to FAIL). This indicates that the Supplicant has not authenticated to the Authentication Server. <i>This element is only shown in detail mode.</i>

181.22 Session Statistics Command

Command Description

This command displays statistics for the sessions.

User Level

The command can be accessed by operators with aaa privileges.

Command Syntax

The command has the following syntax:

```
> show security pae session-stats [ (port) ]
```

Command Parameters

Table 181.22-1 "Session Statistics Command" Resource Parameters

Resource Identifier	Type	Description
(port)	Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::VpiId> : <Eqpt::VciId> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> / <Eqpt::OntPortId> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / voip <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / vuni <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::LLId> ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / <Eqpt::Ng2OntSlotId> / <Eqpt::Ng2OntPortId> ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / vuni) Possible values: - ng2 : ngpon2 style identification Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number	the identification of the bridge port

Resource Identifier	Type	Description
	Field type <Eqpt::VpId> - atm VPI Field type <Eqpt::VciId> - atm VCI Field type <Eqpt::ChannelGroupId> - the channel group identifier Field type <Eqpt::SubChannelGroupId> - the subchannel group identifier Field type <Eqpt::PonId> - the PON identifier Field type <Eqpt::OntId> - the ONT identifier Field type <Eqpt::Ng2OntId> - the NG2 ONT identifier Possible values: - voip : virtual uni identifier obsolete alternative replaced by vuni - vuni : virtual uni identifier Possible values: - vuni : virtual NGPON2 uni identifier Field type <Eqpt::OntSlotId> - the ONT SLOT identifier Field type <Eqpt::OntPortId> - the ONT PORT identifier Field type <Eqpt::Ng2OntSlotId> - the NGPON2 ONT SLOT identifier Field type <Eqpt::Ng2OntPortId> - the NGPON2 ONT PORT identifier Field type <Eqpt::LLId> - the LLID identifier, range 1 for EPON, range 1-8 for DPOE	

Command Output

Table 181.22-2 "Session Statistics Command" Display parameters

Specific Information		
name	Type	Description
rx-octets	Parameter type: <Counter> - 32 bit counter	the number of octets transmitted in user data frames on this port during the session <i>This element is always shown.</i>
tx-octets	Parameter type: <Counter> - 32 bit counter	the number of octets transmitted in user data frames on this port during the session <i>This element is always shown.</i>
rx-user-frames	Parameter type: <Counter> - 32 bit counter	the number of user data frames received on this port during the session <i>This element is always shown.</i>
tx-user-frames	Parameter type: <Counter> - 32 bit counter	the number of user data frames transmitted on this port during the session <i>This element is always shown.</i>
ses-id	Parameter type: <Vlan::AdminString> - char string - length: x<=80	a unique identifier for the session <i>This element is only shown in detail mode.</i>
auth-method	Parameter type: <Aaa::AuthenticMethod>	the authentication method used to

181 Security Status Commands

name	Type	Description
	(remote-auth-server local-auth-server) Possible values: - remote-auth-server : - local-auth-server :	establish the session <i>This element is only shown in detail mode.</i>
ses-time	Parameter type: <TimeTicks> - a timeout value - unit: msec	the duration of the session <i>This element is always shown.</i>
term-cause	Parameter type: <Aaa::TerminateCause> (supplicant-logoff port-failure supplicant-restart reauth-failed auth-cntr-forceunauth port-reinit port-admin-disabled mac-mismatch others username-mismatch password-mismatch auth-control-forceauth auth-server-terminated time-limit-cut idle-cut not-terminated-yet) Possible values: - supplicant-logoff : - port-failure : - supplicant-restart : - reauth-failed : - auth-cntr-forceunauth : - port-reinit : - port-admin-disabled : - mac-mismatch : - others : - username-mismatch : - password-mismatch : - auth-control-forceauth: - auth-server-terminated: - time-limit-cut : - idle-cut : - not-terminated-yet :	reason for the session termination <i>This element is only shown in detail mode.</i>
user-name	Parameter type: <Vlan::AdminString> - char string - length: x<=80	the name representing the identity of the Supplicant PAE <i>This element is only shown in detail mode.</i>

181.23 PAE Port System Status Command

Command Description

This command displays the PAE system parameters for a port or virtual channel

User Level

The command can be accessed by operators with aaa privileges.

Command Syntax

The command has the following syntax:

```
> show security pae port-details [ (port) ]
```

Command Parameters

Table 181.23-1 "PAE Port System Status Command" Resource Parameters

Resource Identifier	Type	Description
(port)	Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::VpiId> : <Eqpt::VciId> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> / <Eqpt::OntPortId> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / voip <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / vuni <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::LLId> ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / <Eqpt::Ng2OntSlotId> / <Eqpt::Ng2OntPortId> ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / vuni) Possible values: - ng2 : ngpon2 style identification Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number	identification of the port or virtual channel

Resource Identifier	Type	Description
	Field type <Eqpt::Vpild> - atm VPI Field type <Eqpt::VciId> - atm VCI Field type <Eqpt::ChannelGroupId> - the channel group identifier Field type <Eqpt::SubChannelGroupId> - the subchannel group identifier Field type <Eqpt::PonId> - the PON identifier Field type <Eqpt::OntId> - the ONT identifier Field type <Eqpt::Ng2OntId> - the NG2 ONT identifier Possible values: - voip : virtual uni identifier obsolete alternative replaced by vuni - vuni : virtual uni identifier Possible values: - vuni : virtual NGPON2 uni identifier Field type <Eqpt::OntSlotId> - the ONT SLOT identifier Field type <Eqpt::OntPortId> - the ONT PORT identifier Field type <Eqpt::Ng2OntSlotId> - the NGPON2 ONT SLOT identifier Field type <Eqpt::Ng2OntPortId> - the NGPON2 ONT PORT identifier Field type <Eqpt::LLId> - the LLID identifier, range 1 for EPON, range 1-8 for DPOE	

Command Output

Table 181.23-2 "PAE Port System Status Command" Display parameters

Specific Information		
name	Type	Description
prot-ver	Parameter type: <SignedInteger> - a signed integer	The protocol version associated with this Port. <i>This element is always shown.</i>
capabilities	Parameter type: <Aaa::Capabilities> (auth-capable supp-capable) Possible values: - auth-capable : - supp-capable :	Indicates the PAE functionality that this Port supports <i>This element is always shown.</i>
reauth	Parameter type: <Aaa::TruthValue> (true false) Possible values: - true : - false :	Specifies currently in use by the Authenticator PAE state machine. <i>This element is always shown.</i>

181.24 MAC Address related EAPOL Status Command

Command Description

This command displays the EAPOL data for each MAC address.

User Level

The command can be accessed by operators with aaa privileges.

Command Syntax

The command has the following syntax:

```
> show security pae mac-address [ (last-src-mac) ]
```

Command Parameters

Table 181.24-1 "MAC Address related EAPOL Status Command" Resource Parameters

Resource Identifier	Type	Description
(last-src-mac)	Format: - mac address (aa:bb:cc:a1:02:03) - unit: Byte - length: 6	the source MAC address carried in the most recently received EAPOL frame

Command Output

Table 181.24-2 "MAC Address related EAPOL Status Command" Display parameters

Specific Information		
name	Type	Description
port	Parameter type: <Itf::BridgePortItf> (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::VpiId> : <Eqpt::VciId> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> / <Eqpt::OntPortId> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / voip <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / vuni <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::LLId>	the port identification <i>This element is always shown.</i>

181 Security Status Commands

name	Type	Description
	ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / <Eqpt::Ng2OntSlotId> / <Eqpt::Ng2OntPortId> ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / vuni) Possible values: - ng2 : ngpon2 style identification Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number Field type <Eqpt::VpiId> - atm VPI Field type <Eqpt::VciId> - atm VCI Field type <Eqpt::ChannelGroupId> - the channel group identifier Field type <Eqpt::SubChannelGroupId> - the subchannel group identifier Field type <Eqpt::PonId> - the PON identifier Field type <Eqpt::OntId> - the ONT identifier Field type <Eqpt::Ng2OntId> - the NG2 ONT identifier Possible values: - voip : virtual uni identifier obsolete alternative replaced by vuni - vuni : virtual uni identifier Possible values: - vuni : virtual NGPON2 uni identifier Field type <Eqpt::OntSlotId> - the ONT SLOT identifier Field type <Eqpt::OntPortId> - the ONT PORT identifier Field type <Eqpt::Ng2OntSlotId> - the NGPON2 ONT SLOT identifier Field type <Eqpt::Ng2OntPortId> - the NGPON2 ONT PORT identifier Field type <Eqpt::LLId> - the LLID identifier,range 1 for EPON,range 1-8 for DPOE	
user-name	Parameter type: <Vlan::AdminString> - char string - length: x<=80	the name representing the identity of the Supplicant PAE <i>This element is only shown in detail mode.</i>
port-status	Parameter type: <Aaa::PaeControlledPortStatus> (authorized unauthorized) Possible values: - authorized : - unauthorized :	the current port status <i>This element is always shown.</i>

181.25 MAC Address related EAPOL Status Command

Command Description

This command show the current status for the authenticator PAE per mac-address.

User Level

The command can be accessed by operators with aaa privileges.

Command Syntax

The command has the following syntax:

```
> show security pae mac-authenticator [ (port) [ mac-address <Vlan::MacAddr> ] ]
```

Command Parameters

Table 181.25-1 "MAC Address related EAPOL Status Command" Resource Parameters

Resource Identifier	Type	Description
(port)	Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::VpiId> : <Eqpt::VciId> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> / <Eqpt::OntPortId> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / voip <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / vuni <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::LLId> ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / <Eqpt::Ng2OntSlotId> / <Eqpt::Ng2OntPortId> ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / vuni) Possible values: - ng2 : ngpon2 style identification Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId>	The Port number associated with the mac-address.

Resource Identifier	Type	Description
	- the LT slot number Field type <Eqpt::PortId> - the port number Field type <Eqpt::VpiId> - atm VPI Field type <Eqpt::VciId> - atm VCI Field type <Eqpt::ChannelGroupId> - the channel group identifier Field type <Eqpt::SubChannelGroupId> - the subchannel group identifier Field type <Eqpt::PonId> - the PON identifier Field type <Eqpt::OntId> - the ONT identifier Field type <Eqpt::Ng2OntId> - the NG2 ONT identifier Possible values: - voip : virtual uni identifier obsolete alternative replaced by vuni - vuni : virtual uni identifier Possible values: - vuni : virtual NGPON2 uni identifier Field type <Eqpt::OntSlotId> - the ONT SLOT identifier Field type <Eqpt::OntPortId> - the ONT PORT identifier Field type <Eqpt::Ng2OntSlotId> - the NGPON2 ONT SLOT identifier Field type <Eqpt::Ng2OntPortId> - the NGPON2 ONT PORT identifier Field type <Eqpt::LLId> - the LLID identifier, range 1 for EPON, range 1-8 for DPOE	
mac-address	Parameter type: <Vlan::MacAddr> Format: - mac address (aa:bb:cc:a1:02:03) - unit: Byte - length: 6	The source MAC address carried in the MAC based Authentication

Command Output

Table 181.25-2 "MAC Address related EAPOL Status Command" Display parameters

Specific Information		
name	Type	Description
mac-auth-state	Parameter type: <Aaa::AuthPaeState> (initialize disconnected connecting authenticating authenticated aborting held force-auth force-unauth) Possible values: - initialize :	The current value of the mac-based-enabled Authenticator PAE state machine. <i>This element is always shown.</i>

name	Type	Description
	- disconnected : - connecting : - authenticating : - authenticated : - aborting : - held : - force-auth : - force-unauth :	
backend-state	Parameter type: <Aaa::AuthBackendState> (request response success fail timeout idle initialize) Possible values: - request : - response : - success : - fail : - timeout : - idle : - initialize :	the current value of the mac-based-enabled Backend Authenticator PAE state machine <i>This element is always shown.</i>
mac-auth-status	Parameter type: <Aaa::PaeControlledPortStatus> (authorized unauthorized) Possible values: - authorized : - unauthorized :	controlled mac-based-enabled status for mac. <i>This element is always shown.</i>
admin-contr-direct	Parameter type: <Aaa::PaeControlledDirections> both Possible values: - both :	admin controlled directions parameter for the mac. <i>This element is only shown in detail mode.</i>
oper-contr-direct	Parameter type: <Aaa::PaeControlledDirections> both Possible values: - both :	operational controlled directions parameter for the mac. <i>This element is only shown in detail mode.</i>
key-tx-enabled	Parameter type: <Aaa::TruthValue> (true false) Possible values: - true : - false :	if the mac-based-enabled keyTransmission enabled. <i>This element is only shown in detail mode.</i>
rx-octets	Parameter type: <Counter> - 32 bit counter	the number of octets transmitted in user data frames on this mac during the session <i>This element is only shown in detail mode.</i>
tx-octets	Parameter type: <Counter> - 32 bit counter	the number of octets transmitted in user data frames on this mac during the session <i>This element is always shown.</i>
rx-user-frames	Parameter type: <Counter> - 32 bit counter	the number of user data frames received on this mac during the session <i>This element is always shown.</i>

181 Security Status Commands

name	Type	Description
tx-user-frames	Parameter type: <Counter> - 32 bit counter	the number of user data frames transmitted on this mac during the session <i>This element is always shown.</i>
ses-id	Parameter type: <Vlan::AdminString> - char string - length: x<=80	a unique identifier for the session <i>This element is only shown in detail mode.</i>
auth-method	Parameter type: <Aaa::AuthenticMethod> (remote-auth-server local-auth-server) Possible values: - remote-auth-server : - local-auth-server :	the authentication method used to establish the session <i>This element is only shown in detail mode.</i>
ses-time	Parameter type: <TimeTicks> - a timeout value - unit: msec	the duration of the session <i>This element is always shown.</i>
term-cause	Parameter type: <Aaa::TerminateCause> (supplicant-logoff port-failure supplicant-restart reauth-failed auth-cntr-forceunauth port-reinit port-admin-disabled mac-mismatch others username-mismatch password-mismatch auth-control-forceauth auth-server-terminated time-limit-cut idle-cut not-terminated-yet) Possible values: - supplicant-logoff : - port-failure : - supplicant-restart : - reauth-failed : - auth-cntr-forceunauth : - port-reinit : - port-admin-disabled : - mac-mismatch : - others : - username-mismatch : - password-mismatch : - auth-control-forceauth: - auth-server-terminated: - time-limit-cut : - idle-cut : - not-terminated-yet :	reason for the session termination <i>This element is only shown in detail mode.</i>
user-name	Parameter type: <Vlan::AdminString> - char string - length: x<=80	the name representing the identity of the Supplicant PAE <i>This element is only shown in detail mode.</i>
user-vlan-id	Parameter type: <AsamProfileName> - a profile name - range: [a-zA-Z0-9-_.]	The User pvid or vlan id distributed from Radius Server in VSA

name	Type	Description
	- length: 1<=x<=32	<i>This element is only shown in detail mode.</i>
dyn-attach-fwd	Parameter type: <AsamProfileName> - a profile name - range: [a-zA-Z0-9-_.] - length: 1<=x<=32	The network forward vlan id returned from Radius Server of this mac on this port in VSA <i>This element is only shown in detail mode.</i>
qos-profile	Parameter type: <AsamProfileName> - a profile name - range: [a-zA-Z0-9-_.] - length: 1<=x<=32	The Qos profile name returned from Radius Server of this mac on this port in VSA <i>This element is only shown in detail mode.</i>
fwd-type	Parameter type: <AsamProfileName> - a profile name - range: [a-zA-Z0-9-_.] - length: 1<=x<=32	The forward type returned from Radius Server of this mac on this port in VSA <i>This element is only shown in detail mode.</i>

181.26 MAC Address related EAPOL Status Command

Command Description

show the diagnostics objects for the authenticator PAE.

User Level

The command can be accessed by operators with aaa privileges.

Command Syntax

The command has the following syntax:

```
> show security pae mac-diagnostics [ (port) [ mac-address <Vlan::MacAddr> ] ]
```

Command Parameters

Table 181.26-1 "MAC Address related EAPOL Status Command" Resource Parameters

Resource Identifier	Type	Description
(port)	Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::VpiId> : <Eqpt::VciId> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> / <Eqpt::OntPortId> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / voip <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / vuni <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::LLId> ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / <Eqpt::Ng2OntSlotId> / <Eqpt::Ng2OntPortId> ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / vuni) Possible values: - ng2 : ngpon2 style identification Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId>	the identification of the bridge port

Resource Identifier	Type	Description
	- the LT slot number - Field type <Eqpt::PortId> - the port number - Field type <Eqpt::VpiId> - atm VPI - Field type <Eqpt::VciId> - atm VCI - Field type <Eqpt::ChannelGroupId> - the channel group identifier - Field type <Eqpt::SubChannelGroupId> - the subchannel group identifier - Field type <Eqpt::PonId> - the PON identifier - Field type <Eqpt::OntId> - the ONT identifier - Field type <Eqpt::Ng2OntId> - the NG2 ONT identifier - Possible values: - voip : virtual uni identifier - obsolete alternative replaced by vuni - vuni : virtual uni identifier - Possible values: - vuni : virtual NGPON2 uni identifier - Field type <Eqpt::OntSlotId> - the ONT SLOT identifier - Field type <Eqpt::OntPortId> - the ONT PORT identifier - Field type <Eqpt::Ng2OntSlotId> - the NGPON2 ONT SLOT identifier - Field type <Eqpt::Ng2OntPortId> - the NGPON2 ONT PORT identifier - Field type <Eqpt::LLId> - the LLID identifier, range 1 for EPON, range 1-8 for DPOE	
mac-address	Parameter type: <Vlan::MacAddr> Format: - mac address (aa:bb:cc:a1:02:03) - unit: Byte - length: 6	The source MAC address carried in the MAC based Authentication

Command Output

Table 181.26-2 "MAC Address related EAPOL Status Command" Display parameters

Specific Information		
name	Type	Description
to-connecting-cnt	Parameter type: <Counter> - 32 bit counter	Counts the number of times that the mac-based-enabled state machine transitions to the CONNECTING state from any other state <i>This element is always shown.</i>
log-off-cnt	Parameter type: <Counter> - 32 bit counter	the number of times that the mac-based-enabled state machine transitions from CONNECTING to DISCONNECTED as a result of receiving an EAPOL-Logoff message

181 Security Status Commands

name	Type	Description
		<i>This element is always shown.</i>
authenticating-cnt	Parameter type: <Counter> - 32 bit counter	the number of times that the state mac-based-enabled machine transitions from CONNECTING to AUTHENTICATING, as a result of an EAP-Response/Identity message being received from the Suppliant <i>This element is only shown in detail mode.</i>
authenticated-cnt	Parameter type: <Counter> - 32 bit counter	the number of times that the mac-based-enabled state machine transitions from AUTHENTICATING to AUTHENTICATED, as a result of the Backend Authentication state machine indicating successful authentication of the Suppliant (authSuccess = TRUE) <i>This element is always shown.</i>
timeout-cnt	Parameter type: <Counter> - 32 bit counter	the number of times that the mac-based-enabled state machine transitions from AUTHENTICATING to ABORTING, as a result of the Backend Authentication state machine indicating authentication timeout (authTimeout = TRUE) <i>This element is always shown.</i>
failed-cnt	Parameter type: <Counter> - 32 bit counter	the number of times that the mac-based-enabled state machine transitions from AUTHENTICATING to HELD, as a result of the Backend Authentication state machine indicating authentication failure (authFail = TRUE) <i>This element is only shown in detail mode.</i>
re-authenticating-cnt	Parameter type: <Counter> - 32 bit counter	the number of times that the mac-based-enabled state machine transitions from AUTHENTICATING to ABORTING, as a result of a reauthentication request (reAuthenticate = TRUE) <i>This element is only shown in detail mode.</i>
eap-start-cnt	Parameter type: <Counter> - 32 bit counter	the number of times that the mac-based-enabled state machine transitions from AUTHENTICATING to ABORTING, as a result of an EAPOL-Start message being received from the Suppliant

name	Type	Description
		<i>This element is only shown in detail mode.</i>
eap-authing-logoff-cnt	Parameter type: <Counter> - 32 bit counter	the number of times that the mac-based-enabled state machine transitions from AUTHENTICATING to ABORTING, as a result of an EAPOL-Logoff message being received from the Supplicant <i>This element is only shown in detail mode.</i>
re-authenticated-cnt	Parameter type: <Counter> - 32 bit counter	the number of times that the mac-based-enabled state machine transitions from AUTHENTICATED to CONNECTING, as a result of a reauthentication request (reAuthenticate = TRUE) <i>This element is only shown in detail mode.</i>
eap-connecting-cnt	Parameter type: <Counter> - 32 bit counter	the number of times that the mac-based-enabled state machine transitions from AUTHENTICATED to CONNECTING, as a result of an EAPOL-Start message being received from the Supplicant <i>This element is only shown in detail mode.</i>
eap-authed-logoff-cnt	Parameter type: <Counter> - 32 bit counter	the number of times that the mac-based-enabled state machine transitions from AUTHENTICATED to DISCONNECTED, as a result of an EAPOL-Logoff message being received from the Supplicant <i>This element is only shown in detail mode.</i>
access-resp-cnt	Parameter type: <Counter> - 32 bit counter	the number of times that the mac-based-enabled state machine sends an initial Access-Request packet to the Authentication server <i>This element is only shown in detail mode.</i>
access-challenge-cnt	Parameter type: <Counter> - 32 bit counter	the number of times that the mac-based-enabled state machine receives an initial Access-Challenge packet from the Authentication server (i.e., aReq becomes TRUE, causing exit from the RESPONSE state). This indicates that the Authentication Server has communication with the Authenticator

181 Security Status Commands

name	Type	Description
		<i>This element is only shown in detail mode.</i>
eap-req-cnt	Parameter type: <Counter> - 32 bit counter	the number of times that the mac-based-enabled state machine sends an EAP-Request packet (other than an Identity, Notification, Failure or Success message) to the Supplicant (i.e., executes txReq on entry to the REQUEST state). This indicates that the Authenticator chose an EAP-method. <i>This element is only shown in detail mode.</i>
resp-non-eap-nak-cnt	Parameter type: <Counter> - 32 bit counter	the number of times that the mac-based-enabled state machine receives a response from the Supplicant to an initial EAP-Request, and the response is something other than EAP-NAK (i.e., rxResp becomes TRUE, causing the mac-based-enabled state machine to transition from REQUEST to RESPONSE, and the response is not an EAP-NAK). This indicates that the Supplicant can respond to the Authenticator's chosen EAP-method <i>This element is only shown in detail mode.</i>
eap-success-cnt	Parameter type: <Counter> - 32 bit counter	the number of times that the mac-based-enabled state machine receives an EAP-Success message from the Authentication Server (i.e., aSuccess becomes TRUE, causing a transition from RESPONSE to SUCCESS). This indicates that the Supplicant has successfully authenticated to the Authentication Server <i>This element is only shown in detail mode.</i>
num-eap-failure	Parameter type: <Counter> - 32 bit counter	the number of times that the mac-based-enabled state machine receives an EAP-Failure message from the Authentication Server (i.e., aFail becomes TRUE, causing a transition from RESPONSE to FAIL). This indicates that the Supplicant has not authenticated to the Authentication Server. <i>This element is only shown in detail mode.</i>

181.27 SSH Server Status Command

Command Description

This command displays the SSH Server related parameters

User Level

The command can be accessed by operators with security privileges.

Command Syntax

The command has the following syntax:

> show security ssh server

Command Output

Table 181.27-2 "SSH Server Status Command" Display parameters

Specific Information		
name	Type	Description
public-key	Parameter type: <PrintableString> - printable string	public key of the server <i>This element is always shown.</i>
fingerprint-hex	Parameter type: <PrintableString> - printable string	server public key fingerprint in hex format <i>This element is always shown.</i>
fingerprint-bubble-bab	Parameter type: <PrintableString> - printable string	server public key fingerprint in bubble-babble format <i>This element is always shown.</i>
server-host-key	Parameter type: <SSH::ServerHostKey> (dsa rsa dsa1024 rsa1024) Possible values: - dsa : dsa 2048 bit key-pair - rsa : rsa 2048 bit key-pair - dsa1024 : dsa 1024 bit key-pair - rsa1024 : rsa 1024 bit key-pair	selected host key algorithm <i>This element is always shown.</i>

181.28 SSH Server Key Generation Progress Status Command

Command Description

This command displays the SSH Server Key Generation Progress Status

User Level

The command can be accessed by operators with security privileges.

Command Syntax

The command has the following syntax:

> show security ssh server-key-status

Command Output

Table 181.28-2 "SSH Server Key Generation Progress Status Command" Display parameters

Specific Information		
name	Type	Description
status	Parameter type: <SSH::KeyGenStatus> (ongoing successful failed) Possible values: - ongoing : ssh key generation in progress - successful : ssh key generation successful - failed : ssh key generation failed	key generation status <i>This element is always shown.</i>
key-type	Parameter type: <SSH::RegeneratedKey> (dsa rsa dsa1024 rsa1024 rsa1024 none) Possible values: - dsa : generated 2048 bit dsa key-pair - rsa : generated 2048 bit rsa key-pair - dsa1024 : generated 1024 bit dsa key-pair - rsa1024 : generated 1024 bit rsa key-pair - rsa1024 : generated 1024 bit rsa key-pair - none : key-pair not generated	ssh server key-pair type <i>This element is always shown.</i>

181.29 SSH Authentication Key Status Command

Command Description

This command displays the ssh authentication key related parameters

User Level

The command can be accessed by operators with security privileges.

Command Syntax

The command has the following syntax:

> show security ssh auth-key [(key-type)]

Command Parameters

Table 181.29-1 "SSH Authentication Key Status Command" Resource Parameters

Resource Identifier	Type	Description
(key-type)	Format: (dsa2048 rsa2048) Possible values: - dsa2048 : dsa 2048 bit key-pair - rsa2048 : rsa 2048 bit key-pair	to display the ssh authentication key parameters

Command Output

Table 181.29-2 "SSH Authentication Key Status Command" Display parameters

Specific Information		
name	Type	Description
public-key	Parameter type: <PrintableString> - printable string	public key of the ssh authentication key-pair <i>This element is always shown.</i>
public-key-b64	Parameter type: <PrintableString> - printable string	ssh authentication public key in b64/OpenSSH format <i>This element is always shown.</i>
fingerprint-hex	Parameter type: <PrintableString> - printable string	ssh authentication public key fingerprint in hex format <i>This element is always shown.</i>

181.30 SSH Authentication Key Generation

Progress Status Command

Command Description

This command displays the auth-key type and auth-key generation status

User Level

The command can be accessed by operators with security privileges.

Command Syntax

The command has the following syntax:

> show security ssh auth-key-status

Command Output

Table 181.30-2 "SSH Authentication Key Generation Progress Status Command" Display parameters

Specific Information		
name	Type	Description
key-type	Parameter type: <SSH::AuthRegeneratedKey> (dsa2048 rsa2048 none) Possible values: - dsa2048 : dsa 2048 public key - rsa2048 : rsa 2048 public key - none : key-pair not generated	ssh authentication key-pair algorithm type <i>This element is always shown.</i>
status	Parameter type: <SSH::AuthKeyGenStatus> (idle ongoing successful failed) Possible values: - idle : ssh auth-key generation is in idle - ongoing : ssh auth-key generation in progress - successful : ssh auth-key generation successful - failed : ssh auth-key generation failed	ssh authentication key-pair generation status <i>This element is always shown.</i>

181.31 PM File Upload Status Command

Command Description

This command displays PM file upload status

User Level

The command can be accessed by operators with security privileges.

Command Syntax

The command has the following syntax:

> show security pmfile upload [(upload-index)]

Command Parameters

Table 181.31-1 "PM File Upload Status Command" Resource Parameters

Resource Identifier	Type	Description
(upload-index)	Format: - the unique internal identifier of PM file upload entry (1-VOICE, 2-DSL, 3-CDR) 1) 1-VOICE / 2-DSL : To enable the VoIP / DSL performance monitoring counter reporting by means of PM file upload. The configuration of an entry in this table enables the VoIP / DSL PM counter reporting by means of PM file upload. Autonomous PM upload needs explicitly to be enabled/disabled. Manual PM file upload becomes automatically enabled when creating an entry with identifier 1-VOICE or 2-DSL. 2) 3-CDR : To enable the VoIP 5-min interval statistics counters and CDR data reporting by means of PM file upload. Autonomous CDR data PM file upload becomes automatically enabled when creating an entry with identifier 3-CDR. Manual PM file upload is not supported. - range: [1...3]	the unique internal identifier of PM file upload entry

Command Output

Table 181.31-2 "PM File Upload Status Command" Display parameters

Specific Information		
name	Type	Description
upload-progress	Parameter type: <SwMngt::pmFileUploadProgress> (idle ongoing finish-success finish-fail) Possible values:	the progress of PM file upload process <i>This element is always shown.</i>

181 Security Status Commands

name	Type	Description
	- idle : No PM File upload triggered - ongoing : PM file upload is ongoing - finish-success : PM file upload finished successfully - finish-fail : PM file upload finished but failed	
upload-error	Parameter type: <SwMngt::pmFileUploadError> (no-error file-not-exist server-unavailable name-pswd-wrong access-violation application-error undefined) Possible values: - no-error : PM file transfer has no error - file-not-exist : PM file does not exist - server-unavailable : upload server is not available - name-pswd-wrong : username or password is not correct - access-violation : access violation - application-error : internal application error - undefined : the error is not defined	the root cause in case of a failing PM file upload <i>This element is always shown.</i>

181.32 5-min CDR File Upload Status Command

Command Description

Obsolete command.

User Level

The command can be accessed by operators with security privileges.

Command Syntax

The command has the following syntax:

> show security cdr-pm-file upload

Obsolete command.

182- Alarm Management Commands

182.1 Alarm Management Command Tree	182-7019
182.2 Alarm Management Command	182-7020
182.3 Snapshot Management Command	182-7021
182.4 Alarm Delta Log Management Command	182-7023
182.5 Log Management Command	182-7024
182.6 Alarm Filetransfer Manual Clearance Management Command	182-7025
182.7 Alarm Failed Login Manual Clearance Management Command	182-7026

182.1 Alarm Management Command Tree

Description

This chapter gives an overview of nodes that are handled by "Alarm Management Commands".

Command Tree

- admin**
 - alarm**
 - (clr-logging)
 - (clr-persist-loss)
 - (clr-xhub-config-loss)
 - (clr-xvps-conf-loss)
 - (clr-inv-xvps-pair)
 - snap-shot**
 - (start)
 - delta-log**
 - (clr-indeterminate)
 - (clr-warning)
 - (clr-minor)
 - (clr-major)
 - (clr-critical)
 - log**
 - (clr-error-log)
 - (clr-set-log-table)
 - clear-alarm**
 - filetransfer**
 - ip-address
 - login-failure**
 - ip-address
 - session-id

182.2 Alarm Management Command

Command Description

This command allows the operator to manage alarms.

User Level

The command can be accessed by operators with alarm privileges, and executed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> admin alarm [ (clr-logging) ] [ (clr-persist-loss) ] [ (clr-xhub-config-loss) ] [ (clr-xvps-conf-loss) ] [ (clr-inv-xvps-pair) ]
```

Command Parameters

Table 182.2-2 "Alarm Management Command" Command Parameters

Parameter	Type	Description
(clr-logging)	Format: clr-logging Possible values: - clr-logging : clear log table - logging will start from index 1	<i>optional parameter</i> clear log table - logging will start from index 1
(clr-persist-loss)	Format: clr-persist-loss Possible values: - clr-persist-loss : clear the loss of persistent data alarm	<i>optional parameter</i> clear the loss of persistent data alarm
(clr-xhub-config-loss)	Format: clr-xhub-config-loss Possible values: - clr-xhub-config-loss : clear the xhub configuration loss alarm	<i>optional parameter</i> clear the xhub configuration loss alarm
(clr-xvps-conf-loss)	Format: clr-xvps-conf-loss Possible values: - clr-xvps-conf-loss : clear the xvps configuration loss alarm	<i>optional parameter</i> clear the xvps configuration loss alarm
(clr-inv-xvps-pair)	Format: clr-inv-xvps-pair Possible values: - clr-inv-xvps-pair : clear the invalid xvps pair redundancy data alarm	<i>optional parameter</i> clear the invalid xvps pair redundancy data alarm

182.3 Snapshot Management Command

Command Description

This command allows the operator to create a snapshot for a particular severity level.

The owner-id can be read by other users to see who has created the snapshot.

This command will fail if the snapshot is already in use. The snapshot is only kept for a limited time and is automatically cleared.

*The snapshot is displayed with the **show alarm snapshot** command.*

User Level

The command can be accessed by operators with alarm privileges, and executed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> admin alarm snap-shot [ (start) ]
```

Command Parameters

Table 182.3-2 "Snapshot Management Command" Command Parameters

Parameter	Type	Description
(start)	Format: (start : indeterminate : <Alarm::alarmSnapShotOwner> start : warning : <Alarm::alarmSnapShotOwner> start : minor : <Alarm::alarmSnapShotOwner> start : major : <Alarm::alarmSnapShotOwner> start : critical : <Alarm::alarmSnapShotOwner> start : <SignedInteger> : <Alarm::alarmSnapShotOwner> stop) Possible values: - start : start reading the snap shot table - stop : stop reading the snap shot table Possible values: - indeterminate : not a definite known severity level - warning : just to inform as a warning - minor : not service affecting - major : service affecting - critical : service breaking Field type <SignedInteger> - a signed integer Field type <Alarm::alarmSnapShotOwner> - string to identify the owner (example: Tom),the string should has less than or equal to 128 characters - length: 1<=x<=128	<i>optional parameter</i> start or stop the snap shot

182.4 Alarm Delta Log Management Command

Command Description

This command allows the operator to manage the alarm delta logs.

User Level

The command can be accessed by operators with alarm privileges, and executed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> admin alarm delta-log [ (clr-indeterminate) ] [ (clr-warning) ] [ (clr-minor) ] [ (clr-major) ] [ (clr-critical) ]
```

Command Parameters

Table 182.4-2 "Alarm Delta Log Management Command" Command Parameters

Parameter	Type	Description
(clr-indeterminate)	Format: clr-indeterminate Possible values: - clr-indeterminate : clear indeterminate delta-log table - logging will start from index 1	<i>optional parameter</i> clear indeterminate delta-log table - set index to 1
(clr-warning)	Format: clr-warning Possible values: - clr-warning : clear warning delta-log table - set index to 1	<i>optional parameter</i> clear warning delta-log table - set index to 1
(clr-minor)	Format: clr-minor Possible values: - clr-minor : clear minor delta-log table - set index to 1	<i>optional parameter</i> clear minor delta-log table - set index to 1
(clr-major)	Format: clr-major Possible values: - clr-major : clear major delta-log table - set index to 1	<i>optional parameter</i> clear major delta-log table - set index to 1
(clr-critical)	Format: clr-critical Possible values: - clr-critical : clear critical delta-log table - set index to 1	<i>optional parameter</i> clear critical delta-log table - set index to 1

182.5 Log Management Command

Command Description

This command allows the operator to manage logs.

User Level

The command can be accessed by operators with alarm privileges, and executed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> admin alarm log [ (clr-error-log) ] [ (clr-set-log-table) ]
```

Command Parameters

Table 182.5-2 "Log Management Command" Command Parameters

Parameter	Type	Description
(clr-error-log)	Format: clr-error-log Possible values: - clr-error-log : clear the error log : index starts from 1	<i>optional parameter</i> clear the error log : index starts from 1
(clr-set-log-table)	Format: clr-set-log-table Possible values: - clr-set-log-table : clear the set log table : index starts from 1	<i>optional parameter</i> clear the set log table : index starts from 1

182.6 Alarm Filetransfer Manual Clearance Management Command

Command Description

This command allows the operator to manage the filetransfer alarm that should be cleared manually

User Level

The command can be accessed by operators with alarm privileges, and executed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> admin alarm clear-alarm filetransfer ip-address <Alarm::IpAddress>
```

Command Parameters

Table 182.6-2 "Alarm Filetransfer Manual Clearance Management Command" Command Parameters

Parameter	Type	Description
ip-address	Parameter type: <Alarm::IpAddress> Format: - IPv4-address	<i>optional parameter</i> identify where the alarm index1 occurred

182.7 Alarm Failed Login Manual Clearance Management Command

Command Description

This command allows the operator to manage the failed login alarm that should be cleared manually

User Level

The command can be accessed by operators with alarm privileges, and executed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

> admin alarm clear-alarm login-failure ip-address <Alarm::IpAddress> session-id <Alarm::ClearAlarmIndex2>

Command Parameters

Table 182.7-2 "Alarm Failed Login Manual Clearance Management Command" Command Parameters

Parameter	Type	Description
ip-address	Parameter type: <Alarm::IpAddress> Format: - IPv4-address	<i>optional parameter</i> identify where the alarm index1 occurred
session-id	Parameter type: <Alarm::ClearAlarmIndex2> Format: - index value - range: [1...2147483647]	<i>optional parameter</i> identify where the alarm index2 occurred

183- ATM Management Commands

183.1 ATM Management Command Tree	183-7028
183.2 ATM Port Management Command	183-7029

183.1 ATM Management Command Tree

Description

This chapter gives an overview of nodes that are handled by "ATM Management Commands".

Command Tree

```
----admin
  ----atm
    ----port
      - (port)
      - f5-loopback-ete
```

183.2 ATM Port Management Command

Command Description

This command allows the operator to configure ATM port management. An f5 loopback end-to-end test can be started by giving the parameter **f5-loopback-ete** a value of **start**.

The result of this test is displayed with the **info** command.

User Level

The command can be accessed by operators with atm privileges, and executed by operators with atm privileges.

Command Syntax

The command has the following syntax:

```
> admin atm port (port) [ f5-loopback-ete <Atm::F5LoopbackTestStatus> ]
```

Command Parameters

Table 183.2-1 "ATM Port Management Command" Resource Parameters

Resource Identifier	Type	Description
(port)	Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::VpiMandatoryId> : <Eqpt::VciMandatoryId> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId>) Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number Field type <Eqpt::VpiMandatoryId> - atm VPI Field type <Eqpt::VciMandatoryId> - atm VCI	the port under test

Table 183.2-2 "ATM Port Management Command" Command Parameters

Parameter	Type	Description
f5-loopback-ete	Parameter type: <Atm::F5LoopbackTestStatus> Format: start Possible values: - start : start the test	<i>optional parameter</i> the f5 end-to-end loopback test

184- IGMP Management Commands

184.1 IGMP Management Command Tree	184-7032
184.2 IGMP Management Command	184-7033
184.3 IGMP Multicast Sources Management Command	184-7034
184.4 IGMP Multicast Channel Management Command	184-7035
184.5 IGMP Multicast Channel Management Command	184-7036
184.6 IGMP Slot Management Command	184-7038
184.7 IGMP Join/leave Debug Management Command	184-7039
184.8 IGMP Channel Management Command	184-7042

184.1 IGMP Management Command Tree

Description

This chapter gives an overview of nodes that are handled by "IGMP Management Commands".

Command Tree

- admin**
 - igmp**
 - (clear-all-stats)
 - (clear-preview-cntr)
 - (collect-cdr)
 - X mcast-src**
 - (slot-index)
 - address
 - (clear-statistics)
 - mcast-channel**
 - (slot-index)
 - grp-ip-addr
 - src-ip-addr
 - (clear-statistics)
 - mcast-chn**
 - (slot-index)
 - grp-ip-addr
 - src-ip-addr
 - vlan-id
 - (clear-statistics)
 - module**
 - (slot-index)
 - (clear-statistics)
 - debug**
 - (port)
 - version
 - grp-ip-addr
 - src-ip-addr
 - (trigger)
 - channel**
 - (port)
 - (clear-statistics)

184.2 IGMP Management Command

Command Description

This command allows the operator to manage IGMP.

User Level

The command can be accessed by operators with igmp privileges, and executed by operators with igmp privileges.

Command Syntax

The command has the following syntax:

```
> admin igmp [ (clear-all-stats) ] [ (clear-preview-cntr) ] [ (collect-cdr) ]
```

Command Parameters

Table 184.2-2 "IGMP Management Command" Command Parameters

Parameter	Type	Description
(clear-all-stats)	Format: clear-all-stats Possible values: - clear-all-stats : clear all statistics	<i>optional parameter</i> clears all statistics
(clear-preview-cntr)	Format: reset-pre-count Possible values: - reset-pre-count : reset all preview time for all multicast source	<i>optional parameter</i> reset preview time for all mcast src in 1day/1wk/1month
(collect-cdr)	Format: collect-cdr Possible values: - collect-cdr : trigger to collect CDRs manually	<i>optional parameter</i> to trigger to collect CDRs manually

184.3 IGMP Multicast Sources Management

Command

Command Description

Obsolete command, replaced by `admin igmp mcast-channel`.

This command allows the operator to manage the IGMP multicast sources.

User Level

The command can be accessed by operators with `igmp` privileges, and executed by operators with `igmp` privileges.

Command Syntax

The command has the following syntax:

```
> admin igmp mcast-src (slot-index) address <Igmp::MulticastAddress> [ (clear-statistics) ]
```

Obsolete command, replaced by `admin igmp mcast-channel`.

Command Parameters

Table 184.3-1 "IGMP Multicast Sources Management Command" Resource Parameters

Resource Identifier	Type	Description
(slot-index)	Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId>) Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number	identify an IGMP module by the logical SlotId
address	Parameter type: <Igmp::MulticastAddress> Format: - multicast-address (range: 224.0.0.3....239.255.255.255, except for 224.0.0.22)	mcast src address in network-byte order (big-endian)

Table 184.3-2 "IGMP Multicast Sources Management Command" Command Parameters

Parameter	Type	Description
(clear-statistics)	Format: clear-statistics Possible values: - clear-statistics : clear the statistics	<i>optional parameter</i> clear the statistics

184.4 IGMP Multicast Channel Management Command

Command Description

This command allows the operator to manage the IGMP multicast channels.

User Level

The command can be accessed by operators with igmp privileges, and executed by operators with igmp privileges.

Command Syntax

The command has the following syntax:

```
> admin igmp mcast-channel (slot-index) grp-ip-addr <Igmp::MulticastAddress> src-ip-addr <Ip::V4Address> [
(clear-statistics) ]
```

Command Parameters

Table 184.4-1 "IGMP Multicast Channel Management Command" Resource Parameters

Resource Identifier	Type	Description
(slot-index)	Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId>) Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number	identify an IGMP module by the logical SlotId
grp-ip-addr	Parameter type: <Igmp::MulticastAddress> Format: - multicast-address (range: 224.0.0.3....239.255.255.255, except for 224.0.0.22)	ip address identifying the multicast group
src-ip-addr	Parameter type: <Ip::V4Address> Format: - IPv4-address	ip address of the multicast server originating the multicast channel,value 0.0.0.0 means ASM(any-src-ip-addr)

Table 184.4-2 "IGMP Multicast Channel Management Command" Command Parameters

Parameter	Type	Description
(clear-statistics)	Format: clear-statistics Possible values: - clear-statistics : clear the statistics	<i>optional parameter</i> clear the statistics

184.5 IGMP Multicast Channel Management Command

Command Description

This command allows the operator to manage the IGMP multicast channels.

User Level

The command can be accessed by operators with igmp privileges, and executed by operators with igmp privileges.

Command Syntax

The command has the following syntax:

```
> admin igmp mcast-chn (slot-index) grp-ip-addr <Igmp::MulticastAddress> src-ip-addr <Ip::V4Address> vlan-id
<Igmp::McastChannelVlan> [ (clear-statistics) ]
```

Command Parameters

Table 184.5-1 "IGMP Multicast Channel Management Command" Resource Parameters

Resource Identifier	Type	Description
(slot-index)	Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId>) Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number	identify an IGMP module by the logical SlotId
grp-ip-addr	Parameter type: <Igmp::MulticastAddress> Format: - multicast-address (range: 224.0.0.3....239.255.255.255, except for 224.0.0.22)	ip address identifying the multicast group
src-ip-addr	Parameter type: <Ip::V4Address> Format: - IPv4-address	ip address of the multicast server originating the multicast channel,value 0.0.0.0 means ASM(any-src-ip-addr)
vlan-id	Parameter type: <Igmp::McastChannelVlan> Format: - vlan id for multicast - range: [1...4093]	specifies the VLAN in which the multicast channel is configured.

Table 184.5-2 "IGMP Multicast Channel Management Command" Command Parameters

Parameter	Type	Description
(clear-statistics)	Format:	<i>optional parameter</i>

Parameter	Type	Description
	clear-statistics Possible values: - clear-statistics : clear the statistics	clear the statistics

184.6 IGMP Slot Management Command

Command Description

This command allows the operator to manage IGMP related to a slot.

User Level

The command can be accessed by operators with igmp privileges, and executed by operators with igmp privileges.

Command Syntax

The command has the following syntax:

```
> admin igmp module (slot-index) [ (clear-statistics) ]
```

Command Parameters

Table 184.6-1 "IGMP Slot Management Command" Resource Parameters

Resource Identifier	Type	Description
(slot-index)	Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId>) Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number	identify an IGMP module by the logical slot id

Table 184.6-2 "IGMP Slot Management Command" Command Parameters

Parameter	Type	Description
(clear-statistics)	Format: clear-statistics Possible values: - clear-statistics : clear the statistics	<i>optional parameter</i> clear the statistics

184.7 IGMP Join/leave Debug Management Command

Command Description

This command enables the operator to trigger an igmp join/leave for debugging.

User Level

The command can be accessed by operators with all,admin privileges.

Command Syntax

The command has the following syntax:

```
> admin igmp debug (port) version <Igmp::Version> grp-ip-addr <Igmp::McastAddress> src-ip-addr
<Ip::V4Address> (trigger)
```

Command Parameters

Table 184.7-1 "IGMP Join/leave Debug Management Command" Resource Parameters

Resource Identifier	Type	Description
(port)	Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::VpiId> : <Eqpt::VciId> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::VpiId> : <Eqpt::VciId> : <Eqpt::UnstackedVlan> vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::UnstackedVlan> vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::VpiId> : <Eqpt::VciId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> / <Eqpt::OntPortId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> / <Eqpt::OntPortId> : <Eqpt::UnstackedVlan> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> / <Eqpt::OntPortId>	identification of the port, vlanport or virtual channel

Resource Identifier	Type	Description
	vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / voip : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / vuni : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / voip : <Eqpt::UnstackedVlan> vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / vuni : <Eqpt::UnstackedVlan> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / voip <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / vuni vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::LLId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::LLId> : <Eqpt::UnstackedVlan> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::LLId> vlan:ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / <Eqpt::Ng2OntSlotId> / <Eqpt::Ng2OntPortId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan:ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / <Eqpt::Ng2OntSlotId> / <Eqpt::Ng2OntPortId> : <Eqpt::UnstackedVlan>) Possible values: - vlan : vlan port - vlan:ng2 : ngpon2 vlan port Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number Field type <Eqpt::VpiId> - atm VPI Field type <Eqpt::VciId> - atm VCI Field type <Eqpt::PonId> - the PON identifier Field type <Eqpt::ChannelGroupId> - the channel group identifier Field type <Eqpt::SubChannelGroupId> - the subchannel group identifier Field type <Eqpt::Ng2OntId> - the NG2 ONT identifier Field type <Eqpt::OntId> - the ONT identifier	

Resource Identifier	Type	Description
	Possible values: - voip : virtual uni identifier obsolete alternative replaced by vuni - vuni : virtual uni identifier Possible values: - vuni : virtual NGPON2 uni identifier Field type <Eqpt::OntSlotId> - the ONT SLOT identifier Field type <Eqpt::OntPortId> - the ONT PORT identifier Field type <Eqpt::Ng2OntSlotId> - the NGPON2 ONT SLOT identifier Field type <Eqpt::Ng2OntPortId> - the NGPON2 ONT PORT identifier Field type <Eqpt::LLId> - the LLID identifier, range 1 for EPON, range 1-8 for DPOE Possible values: - stacked : stacked vlan identity Field type <Eqpt::UnstackedVlan> - unstacked vlan id Field type <Eqpt::SVlan> - service vlan id Field type <Eqpt::CVlan> - customer vlan id	
version	Parameter type: <Igmp::Version> Format: (v2 v3) Possible values: - v2 : igmp version 2 - v3 : igmp version 3	igmp version v2 or v3
grp-ip-addr	Parameter type: <Igmp::McastAddress> Format: - multicast-address (range: 224.0.0.3....239.255.255.255, except for 224.0.0.22)	ip address identifying the multicast group
src-ip-addr	Parameter type: <Ip::V4Address> Format: - IPv4-address	ip address of the multicast server originating the multicast channel, value 0.0.0.0 means ASM(any-src-ip-addr), range:0.0.0.0....223.255.255.255

Table 184.7-2 "IGMP Join/leave Debug Management Command" Command Parameters

Parameter	Type	Description
(trigger)	Format: (join leave) Possible values: - join : trigger igmp join - leave : trigger igmp leave	optional parameter trigger join or leave

184.8 IGMP Channel Management Command

Command Description

This command allows the operator to manage the IGMP channel.

User Level

The command can be accessed by operators with igmp privileges, and executed by operators with igmp privileges.

Command Syntax

The command has the following syntax:

```
> admin igmp channel (port) [ (clear-statistics) ]
```

Command Parameters

Table 184.8-1 "IGMP Channel Management Command" Resource Parameters

Resource Identifier	Type	Description
(port)	Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::VpiId> : <Eqpt::VciId> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::VpiId> : <Eqpt::VciId> : <Eqpt::UnstackedVlan> vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::UnstackedVlan> vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::VpiId> : <Eqpt::VciId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> / <Eqpt::OntPortId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> / <Eqpt::OntPortId> : <Eqpt::UnstackedVlan> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> / <Eqpt::OntPortId> vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / voip : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> /	identification of the port, vlanport or virtual channel

Resource Identifier	Type	Description
	<pre> <Eqpt::PonId> / <Eqpt::OntId> / vuni : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / voip : <Eqpt::UnstackedVlan> vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / vuni : <Eqpt::UnstackedVlan> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / voip <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / vuni vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::LLId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::LLId> : <Eqpt::UnstackedVlan> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::LLId> vlan:ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / <Eqpt::Ng2OntSlotId> / <Eqpt::Ng2OntPortId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan:ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / <Eqpt::Ng2OntSlotId> / <Eqpt::Ng2OntPortId> : <Eqpt::UnstackedVlan>) Possible values: - vlan : vlan port - vlan:ng2 : ngpon2 vlan port Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number Field type <Eqpt::VpiId> - atm VPI Field type <Eqpt::VciId> - atm VCI Field type <Eqpt::PonId> - the PON identifier Field type <Eqpt::ChannelGroupId> - the channel group identifier Field type <Eqpt::SubChannelGroupId> - the subchannel group identifier Field type <Eqpt::Ng2OntId> - the NG2 ONT identifier Field type <Eqpt::OntId> - the ONT identifier Possible values: - voip : virtual uni identifier obsolete alternative replaced by vuni - vuni : virtual uni identifier </pre>	

Resource Identifier	Type	Description
	Possible values: - vuni : virtual NGPON2 uni identifier Field type <Eqpt::OntSlotId> - the ONT SLOT identifier Field type <Eqpt::OntPortId> - the ONT PORT identifier Field type <Eqpt::Ng2OntSlotId> - the NGPON2 ONT SLOT identifier Field type <Eqpt::Ng2OntPortId> - the NGPON2 ONT PORT identifier Field type <Eqpt::LLId> - the LLID identifier, range 1 for EPON, range 1-8 for DPOE Possible values: - stacked : stacked vlan identity Field type <Eqpt::UnstackedVlan> - unstacked vlan id Field type <Eqpt::SVlan> - service vlan id Field type <Eqpt::CVlan> - customer vlan id	

Table 184.8-2 "IGMP Channel Management Command" Command Parameters

Parameter	Type	Description
(clear-statistics)	Format: clear-statistics Possible values: - clear-statistics : clear the statistics	<i>optional parameter</i> accept/ignore request to clear statistics of the table

185- *PPPoX Management Commands*

185.1 PPPoX Management Command Tree	185-7046
185.2 PPPoX Engine Port Management Command	185-7047

185.1 PPPoX Management Command Tree

Description

This chapter gives an overview of nodes that are handled by "PPPoX Management Commands".

Command Tree

```
----admin
  ----pppox-relay
    ----engine
      - (vlan-id)
      - (remove-all-ports)
```


185.2 PPPoX Engine Port Management Command

Command Description

This command deletes all ports for a specific engine.

User Level

The command can be accessed by operators with pppoe privileges, and executed by operators with pppoe privileges.

Command Syntax

The command has the following syntax:

```
> admin pppox-relay engine (vlan-id) [ (remove-all-ports) ]
```

Command Parameters

Table 185.2-1 "PPPoX Engine Port Management Command" Resource Parameters

Resource Identifier	Type	Description
(vlan-id)	Format: (<Vlan::UVlanIndex> stacked : <Vlan::SVlanIndex> : <Vlan::CVlanIndex>) Possible values: - stacked : stacked vlan identity Field type <Vlan::UVlanIndex> - unstacked vlan identity - range: [1...4093,4096] Field type <Vlan::SVlanIndex> - service vlan identity - range: [2...4093] Field type <Vlan::CVlanIndex> - customer vlan identity - range: [0...4093]	vlan identity

Table 185.2-2 "PPPoX Engine Port Management Command" Command Parameters

Parameter	Type	Description
(remove-all-ports)	Format: remove-all-ports Possible values: - remove-all-ports : remove all ports	<i>optional parameter</i> remove all ports for a specific engine

186- *PPPoEL2 Statistics Management Commands*

186.1 PPPoEL2 Statistics Management Command Tree	186-7049
186.2 PPPoEL2 Statistics Management Command	186-7050

186.1 PPPoEL2 Statistics Management Command Tree

Description

This chapter gives an overview of nodes that are handled by "PPPoEL2 Statistics Management Commands".

Command Tree

```
----admin
  ----pppoel2-stats
    - (vlan-port)
    - (clear-statistics)
```

186.2 PPPoEL2 Statistics Management Command

Command Description

This command allows the operator to reset the PPPoE L2 statistics counters on vlan-port interface.

User Level

The command can be accessed by operators with pppoe privileges, and executed by operators with pppoe privileges.

Command Syntax

The command has the following syntax:

```
> admin pppoel2-stats (vlan-port) (clear-statistics)
```

Command Parameters

Table 186.2-1 "PPPoEL2 Statistics Management Command" Resource Parameters

Resource Identifier	Type	Description
(vlan-port)	Format: (vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::VpiId> : <Eqpt::VciId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::VpiId> : <Eqpt::VciId> : <Eqpt::UnstackedVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::UnstackedVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> / <Eqpt::OntPortId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> / <Eqpt::OntPortId> : <Eqpt::UnstackedVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / voip : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / vuni : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / voip :	identification of the port

Resource Identifier	Type	Description
	<Eqpt::UnstackedVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / vuni : <Eqpt::UnstackedVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::LLId> : <Eqpt::UnstackedVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::LLId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan-port:ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / <Eqpt::Ng2OntSlotId> / <Eqpt::Ng2OntPortId> : <Eqpt::UnstackedVlan> vlan-port:ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / <Eqpt::Ng2OntSlotId> / <Eqpt::Ng2OntPortId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan-port:ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / vuni) Possible values: - vlan-port : vlan port - vlan-port:ng2 : an NGPON2 vlan port Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number Field type <Eqpt::VpiId> - atm VPI Field type <Eqpt::VciId> - atm VCI Field type <Eqpt::ChannelGroupId> - the channel group identifier Field type <Eqpt::SubChannelGroupId> - the subchannel group identifier Field type <Eqpt::PonId> - the PON identifier Field type <Eqpt::OntId> - the ONT identifier Field type <Eqpt::Ng2OntId> - the NG2 ONT identifier Possible values: - voip : virtual uni identifier obsolete alternative replaced by vuni - vuni : virtual uni identifier Possible values: - vuni : virtual NGPON2 uni identifier Field type <Eqpt::OntSlotId> - the ONT SLOT identifier Field type <Eqpt::OntPortId> - the ONT PORT identifier Field type <Eqpt::Ng2OntSlotId> - the NGPON2 ONT SLOT identifier	

186 PPPoEL2 Statistics Management Commands

Resource Identifier	Type	Description
	Field type <Eqpt::Ng2OntPortId> - the NGPON2 ONT PORT identifier Field type <Eqpt::LLId> - the LLID identifier,range 1 for EPON,range 1-8 for DPOE Possible values: - stacked : stacked vlan identity Field type <Eqpt::UnstackedVlan> - unstacked vlan id Field type <Eqpt::SVlan> - service vlan id Field type <Eqpt::CVlan> - customer vlan id	

Table 186.2-2 "PPPoEL2 Statistics Management Command" Command Parameters

Parameter	Type	Description
(clear-statistics)	Format: clear-statistics Possible values: - clear-statistics : clear the statistics	<i>optional parameter</i> Reset the counter

187- *PPPoE Management Commands*

187.1 PPPoE Management Command Tree	187-7054
187.2 PPPoE Management Command	187-7055

187.1 PPPoE Management Command Tree

Description

This chapter gives an overview of nodes that are handled by "PPPoE Management Commands".

Command Tree

```
----admin
  ----pppoe-client
    ----emulation
      - (ifindex)
      - client-id
      - [no] command
```


187.2 PPPoE Management Command

Command Description

This command allows the operator to manage the specific PPPoE client emulation.

User Level

The command can be accessed by operators with `pppoe` privileges, and executed by operators with `pppoe` privileges.

Command Syntax

The command has the following syntax:

```
> admin pppoe-client emulation (ifindex) client-id <PPPoE::ClientId> [ no command | command
<PPPoE::pppoeClientEmulationCmd> ]
```

Command Parameters

Table 187.2-1 "PPPoE Management Command" Resource Parameters

Resource Identifier	Type	Description
(ifindex)	Format: (vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::VpiId> : <Eqpt::VciId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::VpiId> : <Eqpt::VciId> : <Eqpt::UnstackedVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::UnstackedVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> / <Eqpt::OntPortId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> / <Eqpt::OntPortId> : <Eqpt::UnstackedVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / voip : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / vuni : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> /	interface index of the PPPoE client port

Resource Identifier	Type	Description
	<code><Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / voip :</code> <code><Eqpt::UnstackedVlan></code> <code> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> /</code> <code><Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / vuni :</code> <code><Eqpt::UnstackedVlan></code> <code> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> /</code> <code><Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> /</code> <code><Eqpt::LLId> : <Eqpt::UnstackedVlan></code> <code> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> /</code> <code><Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> /</code> <code><Eqpt::LLId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan></code> <code> vlan-port:ng2 : <Eqpt::ChannelGroupId> /</code> <code><Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> /</code> <code><Eqpt::Ng2OntSlotId> / <Eqpt::Ng2OntPortId> :</code> <code><Eqpt::UnstackedVlan></code> <code> vlan-port:ng2 : <Eqpt::ChannelGroupId> /</code> <code><Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> /</code> <code><Eqpt::Ng2OntSlotId> / <Eqpt::Ng2OntPortId> : stacked :</code> <code><Eqpt::SVlan> : <Eqpt::CVlan></code> <code> vlan-port:ng2 : <Eqpt::ChannelGroupId> /</code> <code><Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / vuni)</code> Possible values: - vlan-port : vlan port - vlan-port:ng2 : an NGPON2 vlan port Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number Field type <Eqpt::VpiId> - atm VPI Field type <Eqpt::VciId> - atm VCI Field type <Eqpt::ChannelGroupId> - the channel group identifier Field type <Eqpt::SubChannelGroupId> - the subchannel group identifier Field type <Eqpt::PonId> - the PON identifier Field type <Eqpt::OntId> - the ONT identifier Field type <Eqpt::Ng2OntId> - the NG2 ONT identifier Possible values: - voip : virtual uni identifier obsolete alternative replaced by vuni - vuni : virtual uni identifier Possible values: - vuni : virtual NGPON2 uni identifier Field type <Eqpt::OntSlotId> - the ONT SLOT identifier Field type <Eqpt::OntPortId> - the ONT PORT identifier Field type <Eqpt::Ng2OntSlotId>	

Resource Identifier	Type	Description
	- the NGPON2 ONT SLOT identifier Field type <Eqpt::Ng2OntPortId> - the NGPON2 ONT PORT identifier Field type <Eqpt::LLId> - the LLID identifier, range 1 for EPON, range 1-8 for DPOE Possible values: - stacked : stacked vlan identity Field type <Eqpt::UnstackedVlan> - unstacked vlan id Field type <Eqpt::SVlan> - service vlan id Field type <Eqpt::CVlan> - customer vlan id	
client-id	Parameter type: <PPPoE::ClientId> Format: - the PPPoE client id - range: [1]	the PPPoE client id

Table 187.2-2 "PPPoE Management Command" Command Parameters

Parameter	Type	Description
[no] command	Parameter type: <PPPoE::pppoeClientEmulationCmd> Format: (start stop) Possible values: - start : start the PPPoE emulation - stop : abort emulation and terminate the PPPoE session	<i>optional parameter with default value: "none"</i> start or stop the PPPoE emulation

188- xDSL Management Commands

188.1 xDSL Management Command Tree	188-7059
188.2 xDSL Line Management Command	188-7060

188.1 xDSL Management Command Tree

Description

This chapter gives an overview of nodes that are handled by "xDSL Management Commands".

Command Tree

```
----admin
  ----xdsl-line
    - (if-index)
    - loop-diagnostic
    - force-autoswitch
```

188.2 xDSL Line Management Command

Command Description

This command allows the operator do manage an xDSL Line.

Loop Diagnostic Indications:

start : start diagnostics on XDSL line.

stop : stop diagnostics on XDSL line.

completed : diagnostic results ready for retrieval.

failed : diagnostic failed.

User Level

The command can be accessed by operators with xdsl privileges, and executed by operators with xdsl privileges.

Command Syntax

The command has the following syntax:

```
> admin xdsl-line (if-index) [ loop-diagnostic <Xdsl::LoopDiagMode> ] [ force-autoswitch
<Xdsl::AutoSwitchRequestMode> ]
```

Command Parameters

Table 188.2-1 "xDSL Line Management Command" Resource Parameters

Resource Identifier	Type	Description
(if-index)	Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number	interface index of the port

Table 188.2-2 "xDSL Line Management Command" Command Parameters

Parameter	Type	Description
loop-diagnostic	Parameter type: <Xdsl::LoopDiagMode> Format: (stop start) Possible values: - stop : stop the loop diagnostic test	<i>optional parameter</i> controls the loop diagnostic test

Parameter	Type	Description
	- start : start the diagnostic test	
force-autoswitch	Parameter type: <Xdsl::AutoSwitchRequestMode> Format: (none switchtoatm switchtoptm) Possible values: - none : default value - switchtoatm : ForceFully switch the line to ATM - switchtoptm : ForceFully switch the line to PTM	<i>optional parameter</i> Force the AutoSwitch Mode to Line

189- Gpon xDSL Management Commands

189.1 Gpon xDSL Management Command Tree	189-7063
189.2 Gpon xDSL Line Management Command	189-7064

189.1 Gpon xDSL Management Command Tree

Description

This chapter gives an overview of nodes that are handled by "Gpon xDSL Management Commands".

Command Tree

```
----admin
  ----ont-xdsl-line
    - (if-index)
    - loop-diagnostic
```

189.2 Gpon xDSL Line Management Command

Command Description

This command allows the operator do manage an xDSL Line.

Loop Diagnostic Indications:

start : start diagnostics on XDSL line.

stop : stop diagnostics on XDSL line.

completed : diagnostic results ready for retrieval.

failed : diagnostic failed.

User Level

The command can be accessed by operators with xdsl privileges, and executed by operators with xdsl privileges.

Command Syntax

The command has the following syntax:

```
> admin ont-xdsl-line (if-index) [ loop-diagnostic <Xdsl::LoopDiagMode> ]
```

Command Parameters

Table 189.2-1 "Gpon xDSL Line Management Command" Resource Parameters

Resource Identifier	Type	Description
(if-index)	Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Gpon::OntSlotId> / <Gpon::OntPortId> ng2 : <Ng2::ChannelGroup> / <Ng2::SubchannelGroup> / <Ng2::OntId> / <Gpon::OntSlotId> / <Gpon::OntPortId>) Possible values: - ng2 : ngpon2 style identification Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Ng2::ChannelGroup> - channel group number Field type <Ng2::SubchannelGroup> - subchannel group number Field type <Eqpt::OntId>	interface index of the port

Resource Identifier	Type	Description
	- the ONT identifier Field type <Ng2::OntId> - the ONT identifier Field type <Gpon::OntSlotId> - Gpon Ont Slot - range: [1...14] Field type <Gpon::OntPortId> - Gpon Ont Port - range: [1...16]	

Table 189.2-2 "Gpon xDSL Line Management Command" Command Parameters

Parameter	Type	Description
loop-diagnostic	Parameter type: <Xdsl::LoopDiagMode> Format: (stop start) Possible values: - stop : stop the loop diagnostic test - start : start the diagnostic test	<i>optional parameter</i> controls the loop diagnostic test

190- Software Management Commands

190.1 Software Management Command Tree	190-7067
190.2 Software Management Command	190-7068
190.3 OSWP Software Management Command	190-7069
190.4 Database Management Command	190-7071
190.5 File Management Command	190-7074
190.6 Ihub Software Management Command	190-7075
190.7 IHUB Database Management Command	190-7076
190.8 Iacm Software Management Command	190-7077
190.9 IACM Database Management Command	190-7078
190.10 CDE Management Command	190-7079
190.11 TLS CA Management Command	190-7080
190.12 Reborn Reformation Command	190-7081
190.13 Lightspan Migration Management Command	190-7082
190.14 Lightspan Migration Management Command	190-7083

190.1 Software Management Command Tree

Description

This chapter gives an overview of nodes that are handled by "Software Management Commands".

Command Tree

```

----admin
  ----software-mngt
    - (clr-db-rollback-alm)
    - (clr-sw-rollback-alm)
  ----oswp
    - (index)
    - download
    - activate
    - (commit)
    - (verify)
    - (abort-download)
    - (abort-verify)
  ----database
    - download
    - downloadv6
    - upload
    - uploadv6
  ----disk-file
    - (path)
    - (remove)
  ----ihub
    ----database
      - (save-protected)
  ----iacm
    ----database
      - (oam-save-protected)
  ----cdeprof
    - download
    - activate
  ----tls-cafile
    - download
    - remove
    - activate
    - deactivate
  ----trigger-reborn
    - [no] tftp-server
    - [no] source-image
  ----ls-migration
    - (activate)
    - (abort-download)
    ----download
      - server-ip
      - package
      - default-config

```

190.2 Software Management Command

Command Description

This command allows the operator to manage the software of the system.

User Level

The command can be accessed by operators with software management privileges, and executed by operators with software management privileges.

Command Syntax

The command has the following syntax:

```
> admin software-mnngt [ (clr-db-rollback-alm) ] [ (clr-sw-rollback-alm) ]
```

Command Parameters

Table 190.2-2 "Software Management Command" Command Parameters

Parameter	Type	Description
(clr-db-rollback-alm)	Format: clr-db-rollback-alm Possible values: - clr-db-rollback-alm : clear the implicit database rollback alarm	<i>optional parameter</i> clear the implicit database rollback alarm
(clr-sw-rollback-alm)	Format: clr-sw-rollback-alm Possible values: - clr-sw-rollback-alm : clear the implicit software rollback alarm	<i>optional parameter</i> clear the implicit software rollback alarm

190.3 OSWP Software Management Command

Command Description

This command allows the operator to manage the OSWP software packages.

User Level

The command can be accessed by operators with software management privileges, and executed by operators with software management privileges.

Command Syntax

The command has the following syntax:

```
> admin software-mngt oswp (index) [ download <SwMngt::oswpName> ] [ activate <SwMngt::activationType> ]
[ (commit) ] [ (verify) ] [ (abort-download) ] [ (abort-verify) ]
```

Command Parameters

Table 190.3-1 "OSWP Software Management Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: - id of one of the two oswps - range: [1...2]	index to the swm oswp table

Table 190.3-2 "OSWP Software Management Command" Command Parameters

Parameter	Type	Description
download	Parameter type: <SwMngt::oswpName> Format: - path and name of the oswp ,file name less than 160 char - range: [a-zA-Z0-9-_/:*] - length: 1<=x<=160	<i>optional parameter</i> download a software package
activate	Parameter type: <SwMngt::activationType> Format: (with-linked-db with-default-db clear-db with-factory-db) Possible values: - with-linked-db : activate OSWP with linked database - with-default-db : activate OSWP with default database - clear-db : Reset ISAM configuration to factory defaults with ISAM shutdown => Remove and reinsert the NT card to continue - with-factory-db : ISAM configuration to factory defaults	<i>optional parameter</i> activate an OSWP package
(commit)	Format: commit Possible values:	<i>optional parameter</i> commit the OSWP

190 Software Management Commands

Parameter	Type	Description
	- commit : commit the OSWP	
(verify)	Format: verify Possible values: - verify : verify the downloaded oswp	<i>optional parameter</i> verify the downloaded oswp
(abort-download)	Format: abort-download Possible values: - abort-download : abort the download of an oswp	<i>optional parameter</i> abort the download of an oswp
(abort-verify)	Format: abort-verify Possible values: - abort-verify : abort sw load validation of an oswp	<i>optional parameter</i> abort the sw load validation of an oswp

190.4 Database Management Command

Command Description

This command allows the operator to manage the system database.

The database file name should be either `dm.tar` or `dm_complete.tar`.

User Level

The command can be accessed by operators with software management privileges, and executed by operators with software management privileges.

Command Syntax

The command has the following syntax:

```
> admin software-mngt database [ download <SwMngt::DbDownloadServerId> ] [ downloadv6
<SwMngt::V6DbDownloadServerId> ] [ upload <SwMngt::DbUploadServerId> ] [ uploadv6
<SwMngt::V6DbUploadServerId> ]
```

Command Parameters

Table 190.4-2 "Database Management Command" Command Parameters

Parameter	Type	Description
download	Parameter type: <SwMngt::DbDownloadServerId> Format: <Ip::V4Address> : <SwMngt::dbPath> Field type <Ip::V4Address> - IPv4-address Field type <SwMngt::dbPath> - path for the db (eg: /path_to_db/file_name); valid file_names: [dm<something>.tar dm_complete<something>.tar] - range: [a-zA-Z0-9-_/():] - length: 1<=x<=255	<i>optional parameter</i> download the database
downloadv6	Parameter type: <SwMngt::V6DbDownloadServerId> Format: <Ip::InetAddressType> / <SwMngt::dbPath> Field type <Ip::InetAddressType> - IPv6 address Field type <SwMngt::dbPath> - path for the db (eg: /path_to_db/file_name); valid file_names: [dm<something>.tar dm_complete<something>.tar] - range: [a-zA-Z0-9-_/():] - length: 1<=x<=255	<i>optional parameter</i> download the database to IPv6 server
upload	Parameter type: <SwMngt::DbUploadServerId> Format: (actual-active : <Ip::V4Address> : <SwMngt::dbPath>	<i>optional parameter</i> upload the database

Parameter	Type	Description
	<pre> preferred-active : <Ip::V4Address> : <SwMngt::dbPath> previous-active : <Ip::V4Address> : <SwMngt::dbPath> failed-active : <Ip::V4Address> : <SwMngt::dbPath> actual-not-active : <Ip::V4Address> : <SwMngt::dbPath> preferred-not-active : <Ip::V4Address> : <SwMngt::dbPath> previous-not-active : <Ip::V4Address> : <SwMngt::dbPath> failed-not-active : <Ip::V4Address> : <SwMngt::dbPath>) Possible values: - actual-active : actual database for active OSWP - preferred-active : preferable database for active OSWP - previous-active : previous database for active OSWP - failed-active : failed database for active OSWP - actual-not-active : actual database for not-active OSWP - preferred-not-active : preferable database for not-active OSWP - previous-not-active : previous database for not-active OSWP - failed-not-active : failed database for not-active OSWP Field type <Ip::V4Address> - IPv4-address Field type <SwMngt::dbPath> - path for the db (eg: /path_to_db/file_name); valid file_names: [dm<something>.tar dm_complete<something>.tar] - range: [a-zA-Z0-9-_/():] - length: 1<=x<=255 </pre>	
uploadv6	<pre> Parameter type: <SwMngt::V6DbUploadServerId> Format: (actual-active : <Ip::InetAddressType> / <SwMngt::dbPath> preferred-active : <Ip::InetAddressType> / <SwMngt::dbPath> previous-active : <Ip::InetAddressType> / <SwMngt::dbPath> failed-active : <Ip::InetAddressType> / <SwMngt::dbPath> actual-not-active : <Ip::InetAddressType> / <SwMngt::dbPath> preferred-not-active : <Ip::InetAddressType> / <SwMngt::dbPath> previous-not-active : <Ip::InetAddressType> / <SwMngt::dbPath> failed-not-active : <Ip::InetAddressType> / <SwMngt::dbPath>) Possible values: - actual-active : actual database for active OSWP - preferred-active : preferable database for active OSWP - previous-active : previous database for active OSWP - failed-active : failed database for active OSWP - actual-not-active : actual database for not-active OSWP - preferred-not-active : preferable database for not-active OSWP - previous-not-active : previous database for not-active OSWP - failed-not-active : failed database for not-active OSWP Field type <Ip::InetAddressType> </pre>	<i>optional parameter</i> upload the database to IPv6 server

Parameter	Type	Description
	- IPv6 address Field type <SwMngt::dbPath> - path for the db (eg: /path_to_db/file_name); valid file_names: [dm<something>.tar dm_complete<something>.tar] - range: [a-zA-Z0-9-_/():] - length: 1<=x<=255	

190.5 File Management Command

Command Description

This command manages disk and descriptor files.

A disk file contains information about the different software files and descriptor files that are stored on the file disk. It also contains information such as the file name, file size, file type, file availability status, and file format.

The operator can remove a file from the disk in the following cases :

- 1. The file does not belong to the SWP.*
- 2. The file is not a Sw descriptor file.*
- 3. The file is not of a planned and/or detected board type(as well in the active as in the non active SWP).*

User Level

The command can be accessed by operators with software management privileges, and executed by operators with software management privileges.

Command Syntax

The command has the following syntax:

> admin software-mngt disk-file (path) [(remove)]

Command Parameters

Table 190.5-1 "File Management Command" Resource Parameters

Resource Identifier	Type	Description
(path)	Format: - an absolute file name - range: [.-z] - length: 1<=x<=256	an absolute file name

Table 190.5-2 "File Management Command" Command Parameters

Parameter	Type	Description
(remove)	Format: remove Possible values: - remove : remove the file	<i>optional parameter</i> remove the file

190.6 Ihub Software Management Command

Command Description

This command allows the operator to manage the database on the Ihub.

User Level

The command can be accessed by operators with software management privileges, and executed by operators with software management privileges.

Command Syntax

The command has the following syntax:

```
> admin software-mngt ihub
```

190.7 IHUB Database Management Command

Command Description

This command allows the operator to manage the database on the IHUB.

User Level

The command can be accessed by operators with software management privileges, and executed by operators with software management privileges.

Command Syntax

The command has the following syntax:

```
> admin software-mngt ihub database [ (save-protected) ]
```

Command Parameters

Table 190.7-2 "IHUB Database Management Command" Command Parameters

Parameter	Type	Description
(save-protected)	Format: save-protected Possible values: - save-protected : save the database	<i>optional parameter</i> save the protected database

190.8 iacm Software Management Command

Command Description

This command allows the operator to manage the database on the Iacm.

User Level

The command can be accessed by operators with software management privileges, and executed by operators with software management privileges.

Command Syntax

The command has the following syntax:

```
> admin software-mngt iacm
```

190.9 IACM Database Management Command

Command Description

This command allows the operator to manage the database on the IACM.

User Level

The command can be accessed by operators with software management privileges, and executed by operators with software management privileges.

Command Syntax

The command has the following syntax:

```
> admin software-mngt iacm database [ (oam-save-protected) ]
```

Command Parameters

Table 190.9-2 "IACM Database Management Command" Command Parameters

Parameter	Type	Description
(oam-save-protected)	Format: oam-save-protected Possible values: - oam-save-protected : Save oam db database	<i>optional parameter</i> save iacm database

190.10 CDE Management Command

Command Description

This command allows the operator to download and manage the CDE profile.

User Level

The command can be accessed by operators with software management privileges, and executed by operators with software management privileges.

Command Syntax

The command has the following syntax:

```
> admin software-mngt cdeprof [ download <SwMngt::DownloadServerId> ] [ activate <SwMngt::CDEFileName> ]
```

Command Parameters

Table 190.10-2 "CDE Management Command" Command Parameters

Parameter	Type	Description
download	Parameter type: <SwMngt::DownloadServerId> Format: <Ip::V4Address> : <SwMngt::path> Field type <Ip::V4Address> - IPv4-address Field type <SwMngt::path> - path for the cde(example: /path_to_cde/file_name) - range: [a-zA-Z0-9-_/():] - length: 1<=x<=128	<i>optional parameter</i> download the CDE file
activate	Parameter type: <SwMngt::CDEFileName> Format: - string representing the cde profile name - length: 1<=x<=128	<i>optional parameter</i> activate the CDE profile previously downloaded

190.11 TLS CA Management Command

Command Description

This command allows the operator to download and manage the tls CA file.

User Level

The command can be accessed by operators with software management privileges, and executed by operators with software management privileges.

Command Syntax

The command has the following syntax:

```
> admin software-mngt tls-cafile [ download <SwMngt::CADownloadServerId> ] [ remove
<SwMngt::CAFileName> ] [ activate <SwMngt::CAFileName> ] [ deactivate <SwMngt::CAFileName> ]
```

Command Parameters

Table 190.11-2 "TLS CA Management Command" Command Parameters

Parameter	Type	Description
download	Parameter type: <SwMngt::CADownloadServerId> Format: <Ip::V4Address> : <SwMngt::CAFilepath> Field type <Ip::V4Address> - IPv4-address Field type <SwMngt::CAFilepath> - path for the CA file(example: /path_to_ca/file_name) - range: [a-zA-Z0-9-_/():] - length: 1<=x<=128	<i>optional parameter</i> download a TLS CA file, the supported TLS CA file types are: 'pem', '.der', '.crt', '.cer'
remove	Parameter type: <SwMngt::CAFileName> Format: - string representing the TLS CA file name - length: 1<=x<=13	<i>optional parameter</i> remove the TLS CA file and the TLS CA download record that in new status in tls-cafile table
activate	Parameter type: <SwMngt::CAFileName> Format: - string representing the TLS CA file name - length: 1<=x<=13	<i>optional parameter</i> set the TLS CA file to be 'activated' status, then the CA file can be configured to sipVspTable entry or sipServerTable entry
deactivate	Parameter type: <SwMngt::CAFileName> Format: - string representing the TLS CA file name - length: 1<=x<=13	<i>optional parameter</i> set the TLS CA file that isn't configured in any sipVspTable entry or sipServerTable entry to be 'new' status

190.12 Reborn Reformation Command

Command Description

This command allows the operator to trigger the reformation from sdfx to reborn system.

User Level

The command can be accessed by operators with security privileges, and executed by operators with security privileges.

Command Syntax

The command has the following syntax:

```
> admin software-mngt trigger-reborn [ no tftp-server | tftp-server <SwMngt::serverId> ] [ no source-image | source-image <SwMngt::rebornImgName> ]
```

Command Parameters

Table 190.12-2 "Reborn Reformation Command" Command Parameters

Parameter	Type	Description
[no] tftp-server	Parameter type: <SwMngt::serverId> Format: - IPv4-address	<i>optional parameter with default value: ""</i> tftp server address
[no] source-image	Parameter type: <SwMngt::rebornImgName> Format: - string representing the reborn image - length: 1<=x<=64	<i>optional parameter with default value: ""</i> source image to trigger reborn

190.13 Lightspan Migration Management Command

Command Description

This command allows the operator to download package file and activate lightspan migration .

User Level

The command can be accessed by operators with software management privileges, and executed by operators with software management privileges.

Command Syntax

The command has the following syntax:

```
> admin software-mngt ls-migration [ (activate) ] [ (abort-download) ]
```

Command Parameters

Table 190.13-2 "Lightspan Migration Management Command" Command Parameters

Parameter	Type	Description
(activate)	Format: activate Possible values: - activate : start lightspan migration	<i>optional parameter</i> start the process of lightspan migration
(abort-download)	Format: abort-download Possible values: - abort-download : abort lightspan migration	<i>optional parameter</i> abort the process of lightspan migration

190.14 Lightspan Migration Management Command

Command Description

This command allows the operator to download package file and activate lightspan migration .

User Level

The command can be accessed by operators with software management privileges, and executed by operators with software management privileges.

Command Syntax

The command has the following syntax:

```
> admin software-mngt ls-migration download server-ip <SwMngt::serverId> package <SwMngt::lsMigrPkgFile>
default-config <SwMngt::lsMigrConfigFile>
```

Command Parameters

Table 190.14-2 "Lightspan Migration Management Command" Command Parameters

Parameter	Type	Description
server-ip	Parameter type: <SwMngt::serverId> Format: - IPv4-address	<i>optional parameter</i> transfer file server ip
package	Parameter type: <SwMngt::lsMigrPkgFile> Format: - name - length: 1<=x<=256	<i>optional parameter</i> migration package
default-config	Parameter type: <SwMngt::lsMigrConfigFile> Format: - name - length: 1<=x<=256	<i>optional parameter</i> default config for ls migration

191- SHDSL Management Commands

191.1 SHDSL Management Command Tree	191-7085
191.2 SHDSL Segment Configuration Command	191-7086

191.1 SHDSL Management Command Tree

Description

This chapter gives an overview of nodes that are handled by "SHDSL Management Commands".

Command Tree

```
----admin
  ----shdsl-seg
    - (if-index)
    - unit-id
    - side
    - [no] soft-restart
```

191.2 SHDSL Segment Configuration Command

Command Description

This command allows the operator manage an SHDSL Segment.

User Level

The command can be accessed by operators with xdsl privileges, and executed by operators with xdsl privileges.

Command Syntax

The command has the following syntax:

```
> admin shdsl-seg (if-index) unit-id <Shdsl::UnitId> side <Shdsl::SegmentSide> [ [ no ] soft-restart ]
```

Command Parameters

Table 191.2-1 "SHDSL Segment Configuration Command" Resource Parameters

Resource Identifier	Type	Description
(if-index)	Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number	interface index of the port
unit-id	Parameter type: <Shdsl::UnitId> Format: (stu-c stu-r sru-1 sru-2 sru-3 sru-4 sru-5 sru-6 sru-7 sru-8) Possible values: - stu-c : the SHDSL unit is STU-C - stu-r : the SHDSL unit is STU-R - sru-1 : the SHDSL unit is SRU-1 - sru-2 : the SHDSL unit is SRU-2 - sru-3 : the SHDSL unit is SRU-3	unit identifier in an SHDSL span

Resource Identifier	Type	Description
	- sru-4 : the SHDSL unit is SRU-4 - sru-5 : the SHDSL unit is SRU-5 - sru-6 : the SHDSL unit is SRU-6 - sru-7 : the SHDSL unit is SRU-7 - sru-8 : the SHDSL unit is SRU-8	
side	Parameter type: <Shdsl::SegmentSide> Format: (network customer) Possible values: - network : the network side - customer : the customer side	the particular side of an SHDSL unit in an SHDSL segment

Table 191.2-2 "SHDSL Segment Configuration Command" Command Parameters

Parameter	Type	Description
[no] soft-restart	Parameter type: boolean	<i>optional parameter</i> soft restart for the associated side

192- Session Management Commands

192.1 Session Management Command Tree	192-7089
192.2 Forced Disconnect Session Command	192-7090

192.1 Session Management Command Tree

Description

This chapter gives an overview of nodes that are handled by "Session Management Commands".

Command Tree

```
----admin
  ----session
    - (id)
    - (disconnect)
```

192.2 Forced Disconnect Session Command

Command Description

*This command allows the operator to discontinue (or forcibly terminate) an existing CLI session.
The operator can learn about established CLI sessions using the "show session" command.*

User Level

The command can be accessed and executed by an operator with admin privilege.

Command Syntax

The command has the following syntax:
> admin session (id) (disconnect)

Command Parameters

Table 192.2-1 "Forced Disconnect Session Command" Resource Parameters

Resource Identifier	Type	Description
(id)	Format: - the session number - range: [1...13]	the session number

Table 192.2-2 "Forced Disconnect Session Command" Command Parameters

Parameter	Type	Description
(disconnect)	Format: disconnect : <Sec::DisconnectMessage> Possible values: - disconnect : disconnect the session Field type <Sec::DisconnectMessage> - disconnect msg to specify reason for forced termination - length: x<=256	<i>optional parameter</i> disconnect the session with a given message

193- System Management Commands

193.1 System Management Command Tree	193-7092
193.2 SYSLOG Management command	193-7093
193.3 Secure Shell Server Key Regeneration Command	193-7094
193.4 SSH Authentication Key Generation Command	193-7095
193.5 PM File Upload Management Command	193-7096
193.6 Remove locked IP from CLI failed login sources	193-7097
193.7 CPU Load Management Command	193-7098
193.8 Techsupport management Command	193-7100
193.9 Techsupport Generate On Demand Command	193-7101
193.10 Techsupport Clear On Demand Command	193-7103
193.11 FIPS Command	193-7104

193.1 System Management Command Tree

Description

This chapter gives an overview of nodes that are handled by "System Management Commands".

Command Tree

```
----admin
  ----system
    ----syslog
      ----destination
        - (name)
        - (rotate)
      ----security
        ----ssh
          - generate-key
          ----generate-auth-key
            - (key-type)
        ----pmfile
          ----upload
            - (upload-index)
            - upl-interval-num
        ----manager
          - release-lock-cli
    ----cpu-load
      - (index)
      - monitor
    ----techsupport
      - (purgefiles)
      - (doactivate)
      ----gen-on-demand
        - (id)
        - [no] server-ip-addr
        - filename
        - [no] req-session-id
      ----clear-on-demand
        - session
  ----X fips
    - (run-test)
```

193.2 SYSLOG Management command

Command Description

This command allows the operator to rotate the log files explicitly. This is applicable if the destination type is configured as file.

User Level

The command can be accessed by operators with security privileges, and executed by operators with security privileges.

Command Syntax

The command has the following syntax:

> admin system syslog destination (name) [(rotate)]

Command Parameters

Table 193.2-1 "SYSLOG Management command" Resource Parameters

Resource Identifier	Type	Description
(name)	Format: - a profile name - range: [a-zA-Z0-9-_.] - length: 1<=x<=32	name of the syslog destination

Table 193.2-2 "SYSLOG Management command" Command Parameters

Parameter	Type	Description
(rotate)	Format: rotate Possible values: - rotate : enforce the rotation of the log files	<i>optional parameter</i> enforce the rotation of the log files

193.3 Secure Shell Server Key Regeneration

Command

Command Description

This command allows the operator to generate the public/private server key-pair.

The RSA key generation is not yet supported.

User Level

The command can be accessed by operators with security privileges, and executed by operators with security privileges.

Command Syntax

The command has the following syntax:

> admin system security ssh generate-key <SSH::RegenerateKey>

Command Parameters

Table 193.3-2 "Secure Shell Server Key Regeneration Command" Command Parameters

Parameter	Type	Description
generate-key	Parameter type: <SSH::RegenerateKey> Format: (dsa rsa dsa1024 rsa1024) Possible values: - dsa : generate 2048 bit dsa key-pair - rsa : generate 2048 bit rsa key-pair - dsa1024 : generate 1024 bit dsa key-pair - rsa1024 : generate 1024 bit rsa key-pair	<i>optional parameter</i> to generate ssh server key-pair

193.4 SSH Authentication Key Generation

Command

Command Description

This command allows the operator to generate the DSA/RSA authentication key-pair using 2048 bits.

User Level

The command can be accessed by operators with security privileges, and executed by operators with security privileges.

Command Syntax

The command has the following syntax:

> admin system security ssh generate-auth-key (key-type)

Command Parameters

Table 193.4-2 "SSH Authentication Key Generation Command" Command Parameters

Parameter	Type	Description
(key-type)	Format: (dsa2048 rsa2048) Possible values: - dsa2048 : dsa 2048 bit key-pair - rsa2048 : rsa 2048 bit key-pair	<i>optional parameter</i> to generate ssh authentication key-pair

193.5 PM File Upload Management Command

Command Description

This command allows the operator to manually upload PM file to external SFTP server

User Level

The command can be executed by operators with security privileges.

Command Syntax

The command has the following syntax:

```
> admin system security pmfile upload (upload-index) upl-interval-num <SwMngt::pmFileUploadIntervalNum>
```

Command Parameters

Table 193.5-1 "PM File Upload Management Command" Resource Parameters

Resource Identifier	Type	Description
(upload-index)	Format: - the unique internal identifier of PM file upload entry (1-VOICE, 2-DSL, 3-CDR) 1) 1-VOICE / 2-DSL : To enable the VoIP / DSL performance monitoring counter reporting by means of PM file upload. The configuration of an entry in this table enables the VoIP / DSL PM counter reporting by means of PM file upload. Autonomous PM upload needs explicitly to be enabled/disabled. Manual PM file upload becomes automatically enabled when creating an entry with identifier 1-VOICE or 2-DSL. 2) 3-CDR : To enable the VoIP 5-min interval statistics counters and CDR data reporting by means of PM file upload. Autonomous CDR data PM file upload becomes automatically enabled when creating an entry with identifier 3-CDR. Manual PM file upload is not supported. - range: [1...3]	the unique internal identifier of PM file upload entry

Table 193.5-2 "PM File Upload Management Command" Command Parameters

Parameter	Type	Description
upl-interval-num	Parameter type: <SwMngt::pmFileUploadIntervalNum> Format: - the interval number for which a PM file must be uploaded, value 1 as the latest interval - range: [1...96]	<i>optional parameter</i> identifies previous intervals, value 1 as the latest interval

193.6 Remove locked IP from CLI failed login sources

Command Description

This command can be used to remove the lockout imposed on login to ISAM CLI from an IP address. It is applicable for CLI-SSH and CLI-Telnet login, not applicable for CLI-Craft lockout.

User Level

The command can be accessed by operators with security privileges, and executed by operators with security privileges.

Command Syntax

The command has the following syntax:

```
> admin system security manager release-lock-cli <Ip::V4Address>
```

Command Parameters

Table 193.6-2 "Remove locked IP from CLI failed login sources" Command Parameters

Parameter	Type	Description
release-lock-cli	Parameter type: <Ip::V4Address> Format: - IPv4-address	<i>optional parameter</i> remove locked IP from CLI failed login sources

193.7 CPU Load Management Command

Command Description

This command allows the operator to initiate and terminate CPU load monitoring for a board.

User Level

The command can be accessed by operators with equipment privileges, and executed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

```
> admin system cpu-load (index) [ monitor <Sys::operateStatusAdmin> ]
```

Command Parameters

Table 193.7-1 "CPU Load Management Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: (lt : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> nt-a nt-b nt <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::EqSlotId> ntio-1) Possible values: - lt : lt-slot - nt-a : nt-a slot - nt-b : nt-b slot - nt : nt slot - ntio-1 : an nt applique slot in a single or multiple-ntio-shelf Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::EqSlotId> - the equipment slot number	the physical number of the slot

Table 193.7-2 "CPU Load Management Command" Command Parameters

Parameter	Type	Description
monitor	Parameter type: <Sys::operateStatusAdmin> Format: (start stop)	<i>optional parameter</i> start/stop the cpu load monitoring activity

Parameter	Type	Description
	Possible values: - start : start the cpu load monitoring activity - stop : stop the cpu load monitoring activity	

193.8 Techsupport management Command

Command Description

This command allows the operator to activate and deactivate the techSupport functionality.

User Level

The command can be accessed by operators with all privileges, and executed by operators with all privileges.

Command Syntax

The command has the following syntax:

> admin system techsupport [(purgefiles)] [(doactivate)]

Command Parameters

Table 193.8-2 "Techsupport management Command" Command Parameters

Parameter	Type	Description
(purgefiles)	Format: purge Possible values: - purge : remove all captured techsupport files	<i>optional parameter</i> Remove all generated techsupport files
(doactivate)	Format: (disable enable) Possible values: - disable : deactivate the techsupport functionality - enable : activate the techsupport functionality	<i>optional parameter</i> enables/disables the techSupport activity. Default is enable in order to have techsupport files available for analysis when a reset would happen.

193.9 Techsupport Generate On Demand Command

Command Description

This command allows the operator to generate an on demand Tech Support file for a certain board.

User Level

The command can be accessed by operators with equipment privileges, and executed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

```
> admin system techsupport gen-on-demand (id) [ no server-ip-addr | server-ip-addr <Ip::V4Address> ] filename
<Sys::TechSupportFileName> [ no req-session-id | req-session-id <Sys::TechSupportSessionId> ]
```

Command Parameters

Table 193.9-2 "Techsupport Generate On Demand Command" Command Parameters

Parameter	Type	Description
(id)	Format: (lt : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> nt-a nt-b nt <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::EqSlotId>) Possible values: - lt : lt-slot - nt-a : nt-a slot - nt-b : nt-b slot - nt : nt slot Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::EqSlotId> - the equipment slot number	<i>mandatory parameter</i> the id to generate the Tech Support On Demand File for
[no] server-ip-addr	Parameter type: <Ip::V4Address> Format: - IPv4-address	<i>optional parameter with default value: "0.0.0.0"</i> The ip address for the server to upload the Tech Support File to.
filename	Parameter type: <Sys::TechSupportFileName>	<i>mandatory parameter</i>

193 System Management Commands

Parameter	Type	Description
	Format: - TS file name - range: [a-zA-Z0-9-_.] - length: 1<=x<=13	the filename as which the Tech Support file is to be saved (max length 13 if local).
[no] req-session-id	Parameter type: <Sys::TechSupportSessionId> Format: - number identifying a Tech Support Session - range: [0...65535]	<i>optional parameter with default value: 0L</i> Used to indicate if a fixed session id is requested

193.10 Techsupport Clear On Demand Command

Command Description

This command allows the operator to clear and remove a Tech Support On Demand session from the system.

User Level

The command can be accessed by operators with equipment privileges, and executed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

> admin system techsupport clear-on-demand session <Sys::TechSupportSessionId>

Command Parameters

Table 193.10-2 "Techsupport Clear On Demand Command" Command Parameters

Parameter	Type	Description
session	Parameter type: <Sys::TechSupportSessionId> Format: - number identifying a Tech Support Session - range: [0...65535]	<i>mandatory parameter</i> the session id to use to clear the Tech Support On Demand File for

193.11 FIPS Command

Command Description

Obsolete command.

User Level

The command can be accessed by operators with security privileges, and executed by operators with security privileges.

Command Syntax

The command has the following syntax:

> admin system fips (run-test)

Obsolete command.

Command Parameters

Table 193.11-2 "FIPS Command" Command Parameters

Parameter	Type	Description
(run-test)	Format: run-test Possible values: - run-test : Run FIPS Self Test	<i>optional parameter</i> Run FIPS Self Test in the system

194- UDP/SSH debug Management Commands

194.1 UDP/SSH debug Management Command Tree	194-7106
194.2 Forced Disconnect UDP/SSH debug Command	194-7107

194.1 UDP/SSH debug Management Command Tree

Description

This chapter gives an overview of nodes that are handled by "UDP/SSH debug Management Commands".

Command Tree

```
----admin
  ----system
    ----security
      ----kill-debug
```

194.2 Forced Disconnect UDP/SSH debug Command

Command Description

This command allows the operator to discontinue (or forcefully terminate) all UDP/SSH debug sessions.

User Level

The command can be accessed and executed by an operator with admin privilege.

Command Syntax

The command has the following syntax:

> admin system security kill-debug

195- *Trouble-Shooting Management Commands*

195.1 Trouble-Shooting Management Command Tree	195-7109
195.2 Trouble-shooting Interface Management Commands	195-7110

195.1 Trouble-Shooting Management Command Tree

Description

This chapter gives an overview of nodes that are handled by "Trouble-Shooting Management Commands".

Command Tree

```
----admin
  ----trouble-shooting
    ----interface
      - (if-index)
      - (clear-statistics)
```

195.2 Trouble-shooting Interface Management Commands

Command Description

This command allows the operator to reset summary and extensive dataplane trouble-shooting counters.

User Level

The command can be accessed by operators with security privileges, and executed by operators with security privileges.

Command Syntax

The command has the following syntax:

```
> admin trouble-shooting interface (if-index) (clear-statistics)
```

Command Parameters

Table 195.2-1 "Trouble-shooting Interface Management Commands" Resource Parameters

Resource Identifier	Type	Description
(if-index)	Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> / <Eqpt::OntPortId> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / voip <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / vuni uni:ng2 : <Ng2::ChannelGroup> / <Ng2::SubchannelGroup> / <Ng2::OntId> / <Eqpt::Ng2OntSlotId> / <Eqpt::Ng2OntPortId> chpair : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::ChannelPairId> vlanport : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlanport : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> / <Eqpt::OntPortId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlanport : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> / <Eqpt::OntPortId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan>	interface index of the port

Resource Identifier	Type	Description
	<Eqpt::UnstackedVlan> vlanport : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / voip : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlanport : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / vuni : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlanport : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / voip : <Eqpt::UnstackedVlan> vlanport : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / vuni : <Eqpt::UnstackedVlan> vlanport : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::LLId> : <Eqpt::UnstackedVlan> vlanport : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::LLId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlanport : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::UnstackedVlan> vlanport : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::VpiId> : <Eqpt::VciId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlanport : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::VpiId> : <Eqpt::VciId> : <Eqpt::UnstackedVlan>) Possible values: - uni:ng2 : ng2 uni index - chpair : channel pair index - vlanport : vlan port Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number Field type <Eqpt::VpiId> - atm VPI Field type <Eqpt::VciId> - atm VCI Field type <Eqpt::PonId> - the PON identifier Field type <Eqpt::OntId> - the ONT identifier Possible values: - voip : virtual uni identifier obsolete alternative replaced by vuni - vuni : virtual uni identifier Field type <Eqpt::OntSlotId> - the ONT SLOT identifier Field type <Eqpt::OntPortId> - the ONT PORT identifier Field type <Eqpt::LLId> - the LLID identifier,range 1 for EPON,range 1-8 for DPOE	

Resource Identifier	Type	Description
	Field type <Eqpt::ChannelPairId> - the channel pair identifier Field type <Ng2::ChannelGroup> - channel group number Field type <Ng2::SubchannelGroup> - subchannel group number Field type <Ng2::OntId> - the ONT identifier Possible values: - stacked : stacked vlan identity Field type <Eqpt::UnstackedVlan> - unstacked vlan id Field type <Eqpt::SVlan> - service vlan id Field type <Eqpt::CVlan> - customer vlan id Possible values: - vuni : virtual NGPON2 uni identifier Field type <Eqpt::Ng2OntSlotId> - the NGPON2 ONT SLOT identifier Field type <Eqpt::Ng2OntPortId> - the NGPON2 ONT PORT identifier	

Table 195.2-2 "Trouble-shooting Interface Management Commands" Command Parameters

Parameter	Type	Description
(clear-statistics)	Format: clear-statistics Possible values: - clear-statistics : reset trouble-shooting counters	<i>optional parameter</i> optional parameter reset all trouble-shooting counters

196- Trouble-Shooting Management Commands

196.1 Trouble-Shooting Management Command Tree	196-7114
196.2 Trouble-shooting Pon Interface Management Commands	196-7115

196.1 Trouble-Shooting Management Command Tree

Description

This chapter gives an overview of nodes that are handled by "Trouble-Shooting Management Commands".

Command Tree

```
----admin
  ----trouble-shooting
    ----pon
      ----interface
        - (if-index)
        - (clear-statistics)
```

196.2 Trouble-shooting Pon Interface Management Commands

Command Description

This command allows the operator to reset summary and extensive dataplane trouble-shooting counters over a pon line.

User Level

The command can be accessed by operators with security privileges, and executed by operators with security privileges.

Command Syntax

The command has the following syntax:

```
> admin trouble-shooting pon interface (if-index) (clear-statistics)
```

Command Parameters

Table 196.2-1 "Trouble-shooting Pon Interface Management Commands" Resource Parameters

Resource Identifier	Type	Description
(if-index)	Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> x-pon : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::XPonId> 25g-pon : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::M25GPonId>) Possible values: - 25g-pon : 25g-pon - x-pon : xgs-pon Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Eqpt::XPonId> - the XGS PON identifier Field type <Eqpt::M25GPonId> - the 25G PON identifier	interface index of the pon port

Table 196.2-2 "Trouble-shooting Pon Interface Management Commands" Command Parameters

196 Trouble-Shooting Management Commands

Parameter	Type	Description
(clear-statistics)	Format: clear-statistics Possible values: - clear-statistics : reset trouble-shooting counters	<i>optional parameter</i> optional parameter reset all trouble-shooting counters

197- *Trouble-Shooting Management Commands*

197.1 Trouble-Shooting Management Command Tree	197-7118
197.2 Trouble-shooting pbit counter Interface Management Commands	197-7119

197.1 Trouble-Shooting Management Command Tree

Description

This chapter gives an overview of nodes that are handled by "Trouble-Shooting Management Commands".

Command Tree

```
----admin
  ----trouble-shooting
    ----pbit
      ----interface
        - (if-index)
        - (clear-statistics)
```


197.2 Trouble-shooting pbit counter Interface Management Commands

Command Description

This command allows the operator to reset pbit trouble-shooting counters.

User Level

The command can be accessed by operators with security privileges, and executed by operators with security privileges.

Command Syntax

The command has the following syntax:

```
> admin trouble-shooting pbit interface (if-index) (clear-statistics)
```

Command Parameters

Table 197.2-1 "Trouble-shooting pbit counter Interface Management Commands" Resource Parameters

Resource Identifier	Type	Description
(if-index)	Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> / <Eqpt::OntPortId> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / voip <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / vuni vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> / <Eqpt::OntPortId> : <Eqpt::UnstackedVlan> vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> / <Eqpt::OntPortId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / voip : <Eqpt::UnstackedVlan> vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / vuni : <Eqpt::UnstackedVlan> vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> /	interface index of the bridge port or vlan port

Resource Identifier	Type	Description
	<pre> <Eqpt::PonId> / <Eqpt::OntId> / voip : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / vuni : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::VpId> : <Eqpt::VciId> : <Eqpt::UnstackedVlan> vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::VpId> : <Eqpt::VciId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> uni:ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / <Eqpt::Ng2OntSlotId> / <Eqpt::Ng2OntPortId> vlan:ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / <Eqpt::Ng2OntSlotId> / <Eqpt::Ng2OntPortId> : <Eqpt::UnstackedVlan> vlan:ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / <Eqpt::Ng2OntSlotId> / <Eqpt::Ng2OntPortId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> uni:ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / vuni) Possible values: - vlan : vlan - uni:ng2 : ngpon2 UNI style identification - vlan:ng2 : ngpon2 vlan Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number Field type <Eqpt::VpId> - atm VPI Field type <Eqpt::VciId> - atm VCI Field type <Eqpt::PonId> - the PON identifier Field type <Eqpt::ChannelGroupId> - the channel group identifier Field type <Eqpt::SubChannelGroupId> - the subchannel group identifier Field type <Eqpt::OntId> - the ONT identifier Field type <Eqpt::Ng2OntId> - the NG2 ONT identifier Possible values: - voip : virtual uni identifier obsolete alternative replaced by vuni - vuni : virtual uni identifier Possible values: - vuni : virtual NGPON2 uni identifier Field type <Eqpt::OntSlotId> </pre>	

Resource Identifier	Type	Description
	- the ONT SLOT identifier Field type <Eqpt::OntPortId> - the ONT PORT identifier Field type <Eqpt::Ng2OntSlotId> - the NGPON2 ONT SLOT identifier Field type <Eqpt::Ng2OntPortId> - the NGPON2 ONT PORT identifier Possible values: - stacked : stacked vlan identity Field type <Eqpt::UnstackedVlan> - unstacked vlan id Field type <Eqpt::SVlan> - service vlan id Field type <Eqpt::CVlan> - customer vlan id	

Table 197.2-2 "Trouble-shooting pbit counter Interface Management Commands" Command Parameters

Parameter	Type	Description
(clear-statistics)	Format: clear-statistics Possible values: - clear-statistics : reset trouble-shooting counters	<i>optional parameter</i> optional parameter reset all trouble-shooting counters

198- *Trouble-Shooting Management Commands*

198.1 Trouble-Shooting Management Command Tree	198-7123
198.2 Trouble-shooting color counter Interface Management Commands	198-7124

198.1 Trouble-Shooting Management Command Tree

Description

This chapter gives an overview of nodes that are handled by "Trouble-Shooting Management Commands".

Command Tree

```
----admin
  ----trouble-shooting
    ----color
      ----interface
        - (if-index)
        - (clear-statistics)
```

198.2 Trouble-shooting color counter Interface Management Commands

Command Description

This command allows the operator to reset color trouble-shooting counters.

User Level

The command can be accessed by operators with security privileges, and executed by operators with security privileges.

Command Syntax

The command has the following syntax:

```
> admin trouble-shooting color interface (if-index) (clear-statistics)
```

Command Parameters

Table 198.2-1 "Trouble-shooting color counter Interface Management Commands" Resource Parameters

Resource Identifier	Type	Description
(if-index)	Format: (vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::VpiId> : <Eqpt::VciId> : <Eqpt::UnstackedVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::UnstackedVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::VpiId> : <Eqpt::VciId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> / <Eqpt::OntPortId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> / <Eqpt::OntPortId> : <Eqpt::UnstackedVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / voip : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> /	interface index of the vlan port

Resource Identifier	Type	Description
	<code><Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / vuni :</code> <code>stacked : <Eqpt::SVlan> : <Eqpt::CVlan></code> <code> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> /</code> <code><Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / voip :</code> <code><Eqpt::UnstackedVlan></code> <code> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> /</code> <code><Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / vuni :</code> <code><Eqpt::UnstackedVlan></code> <code> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> /</code> <code><Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> /</code> <code><Eqpt::LLId> : <Eqpt::UnstackedVlan></code> <code> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> /</code> <code><Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> /</code> <code><Eqpt::LLId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan>)</code> Possible values: - vlan-port : vlan port Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number Field type <Eqpt::Vpild> - atm VPI Field type <Eqpt::VciId> - atm VCI Field type <Eqpt::PonId> - the PON identifier Field type <Eqpt::OntId> - the ONT identifier Possible values: - voip : virtual uni identifier obsolete alternative replaced by vuni - vuni : virtual uni identifier Field type <Eqpt::OntSlotId> - the ONT SLOT identifier Field type <Eqpt::OntPortId> - the ONT PORT identifier Field type <Eqpt::LLId> - the LLID identifier, range 1 for EPON, range 1-8 for DPOE Possible values: - stacked : stacked vlan identity Field type <Eqpt::UnstackedVlan> - unstacked vlan id Field type <Eqpt::SVlan> - service vlan id Field type <Eqpt::CVlan> - customer vlan id	

Table 198.2-2 "Trouble-shooting color counter Interface Management Commands" Command Parameters

Parameter	Type	Description
(clear-statistics)	Format: clear-statistics Possible values:	<i>optional parameter</i> optional parameter reset all trouble-shooting counters

198 Trouble-Shooting Management Commands

Parameter	Type	Description
	- clear-statistics : reset trouble-shooting counters	

199- Voice Ont Management Commands

199.1 Voice Ont Management Command Tree	199-7128
199.2 Voice Megaco Database Management Command	199-7130
199.3 Voice Megaco Equipment Admin Commands	199-7131
199.4 Voice Megaco Termination Lock Management Command	199-7132
199.5 Voice Megaco Secondary Termination Lock Management Command	199-7134
199.6 Voice Megaco Media Gateway Lock Management Command	199-7136
199.7 Voice Sip L1 Transport Statistics Commands	199-7138
199.8 Voice POTS Diagnostics Management Command	199-7139
199.9 Voice POTS Pull-Break Management Command	199-7142
199.10 Voice SIP Pull-Break Management Command	199-7144
199.11 GPON Voip Configuration Management Command	199-7146

199.1 Voice Ont Management Command Tree

Description

This chapter gives an overview of nodes that are handled by "Voice Ont Management Commands".

Command Tree

```
----admin
  ----voice
    ----cluster
      - (cluster-id)
    ----database
      - (save)
    ----equipment
      - (equip-id)
        ----port-id
          - (port-id)
          - lktype
        ----sharedline-port-id
          - (port-id)
          - lktype
    ----media-gateway
      - (media-gateway-id)
      - lktype
      - trigger-esa-mgc
  ----sip
    ----l1-trans-statistics
      - (if-index)
      - (reset)
  ----ont
    ----pots
      ----diagnostics
        - (uni-idx)
        - mode
        - hazard-dc-volt-th
        - hazard-ac-volt-th
        - frgn-ac-volt-th
        - frgn-dc-volt-th
        - tipgnd-rnggnd-th
        - tip-ring-th
        - ring-min-th
        - ring-max-th
        - diagnostic
      ----pb-dial-tone
        - (uni-idx)
        - [no] slow-pull-timer
        - [no] no-pull-timer
        - [no] slow-break-timer
        - [no] no-break-timer
        - [no] test-digit
        - diagnostic
      ----sip-dial-tone
        - (uni-idx)
```

- sip-phone-number
- diagnostic
- voip-config**
- **(voip-index)**
- (active)

199.2 Voice Megaco Database Management Command

Command Description

This command allows the operator to manage the voice megaco xvps database.

User Level

The command can be accessed by operators with megaco privileges, and executed by operators with megaco privileges.

Command Syntax

The command has the following syntax:

```
> admin voice cluster (cluster-id) database [ (save) ]
```

Command Parameters

Table 199.2-1 "Voice Megaco Database Management Command" Resource Parameters

Resource Identifier	Type	Description
(cluster-id)	Format: - the xvps cluster id - range: [1...8,11]	uniquely identify of this xvps cluster

Table 199.2-2 "Voice Megaco Database Management Command" Command Parameters

Parameter	Type	Description
(save)	Format: save Possible values: - save : save the database	<i>optional parameter</i> save the database

199.3 Voice Megaco Equipment Admin Commands

Command Description

This command allows the operator to manage the Voice equipment. One ivps can manage at most 256 equipments, so the id of equipment is from 1 to 256.

If you want to manage a termination, you must configure a equipment first.

User Level

The command can be accessed by operators with megaco privileges, and executed by operators with megaco privileges.

Command Syntax

The command has the following syntax:

> admin voice cluster (cluster-id) equipment (equip-id)

Command Parameters

Table 199.3-1 "Voice Megaco Equipment Admin Commands" Resource Parameters

Resource Identifier	Type	Description
(cluster-id)	Format: - the xvps cluster id - range: [1...8,11]	uniquely identify of this xvps cluster
(equip-id)	Format: - id of equipment - range: [1...32]	uniquely identify of this equipment

199.4 Voice Megaco Termination Lock Management Command

Command Description

This command allows the operator to manage the voice megaco termination lock type.

User Level

The command can be accessed by operators with megaco privileges, and executed by operators with megaco privileges.

Command Syntax

The command has the following syntax:

```
> admin voice cluster (cluster-id) equipment (equip-id) port-id (port-id) [ lktype
<MEGACO::accTerminationLockType> ]
```

Command Parameters

Table 199.4-1 "Voice Megaco Termination Lock Management Command" Resource Parameters

Resource Identifier	Type	Description
(cluster-id)	Format: - the xvps cluster id - range: [1...8,11]	uniquely identify of this xvps cluster
(equip-id)	Format: - id of equipment - range: [1...32]	uniquely identify of this equipment
(port-id)	Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::NewSlotId> / <Eqpt::MegacoPortId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::NewSlotId> - the LT slot number Field type <Eqpt::MegacoPortId> - the port number of Megaco	unique identifier of this termination port

Table 199.4-2 "Voice Megaco Termination Lock Management Command" Command Parameters

Parameter	Type	Description
lktype	Parameter type: <MEGACO::accTerminationLockType> Format: (force graceful : <MEGACO::accTerminationLockDelay>)	<i>optional parameter</i> the termination lock type and delay time

Parameter	Type	Description
	Possible values: - force : The termination lock type is force - graceful : The termination lock type is graceful Field type <MEGACO::accTerminationLockDelay> - the delay timer before lock access termination - unit: 1 msec - range: [0...3600000]	

199.5 Voice Megaco Secondary Termination Lock Management Command

Command Description

This command allows the operator to manage the voice megaco secondary termination lock type.

User Level

The command can be accessed by operators with megaco privileges, and executed by operators with megaco privileges.

Command Syntax

The command has the following syntax:

```
> admin voice cluster (cluster-id) equipment (equip-id) sharedline-port-id (port-id) [ lktype
<MEGACO::accTerminationLockType> ]
```

Command Parameters

Table 199.5-1 "Voice Megaco Secondary Termination Lock Management Command" Resource Parameters

Resource Identifier	Type	Description
(cluster-id)	Format: - the xvps cluster id - range: [1...8,11]	uniquely identify of this xvps cluster
(equip-id)	Format: - id of equipment - range: [1...32]	uniquely identify of this equipment
(port-id)	Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::NewSlotId> / <Eqpt::MegacoPortId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::NewSlotId> - the LT slot number Field type <Eqpt::MegacoPortId> - the port number of Megaco	unique identifier of the secondary termination port

Table 199.5-2 "Voice Megaco Secondary Termination Lock Management Command" Command Parameters

Parameter	Type	Description
lktype	Parameter type: <MEGACO::accTerminationLockType> Format:	<i>optional parameter</i> the secondary termination lock

Parameter	Type	Description
	(force graceful : <MEGACO::accTerminationLockDelay>) Possible values: - force : The termination lock type is force - graceful : The termination lock type is graceful Field type <MEGACO::accTerminationLockDelay> - the delay timer before lock access termination - unit: 1 msec - range: [0...3600000]	type and delay time

199.6 Voice Megaco Media Gateway Lock Management Command

Command Description

This command allows the operator to manage the voice megaco media gateway lock type.

User Level

The command can be accessed by operators with megaco privileges, and executed by operators with megaco privileges.

Command Syntax

The command has the following syntax:

```
> admin voice cluster (cluster-id) media-gateway (media-gateway-id) [ lktype
<MEGACO::mediaGatewayLockType> ] [ trigger-esa-mgc <MEGACO::mediaGatewayTriggerESAMgc> ]
```

Command Parameters

Table 199.6-1 "Voice Megaco Media Gateway Lock Management Command" Resource Parameters

Resource Identifier	Type	Description
(cluster-id)	Format: - the xvps cluster id - range: [1...8,11]	uniquely identify of this xvps cluster
(media-gateway-id)	Format: - the media gateway table index - range: [1]	uniquely identify of this media gateway

Table 199.6-2 "Voice Megaco Media Gateway Lock Management Command" Command Parameters

Parameter	Type	Description
lktype	Parameter type: <MEGACO::mediaGatewayLockType> Format: (force graceful : <MEGACO::mediaGatewayLockDelay>) Possible values: - force : The media gateway lock type is force - graceful : The media gateway lock type is graceful Field type <MEGACO::mediaGatewayLockDelay> - the timer of media gateway lock command - unit: 1 msec - range: [0...3600000]	<i>optional parameter</i> the media gateway lock type and delay time
trigger-esa-mgc	Parameter <MEGACO::mediaGatewayTriggerESAMgc> Format:	type: <i>optional parameter</i> failover to local ESA mgc or failback to external normal mgc

Parameter	Type	Description
	(failover failback) Possible values: - failover : failover to local ESA mgc - failback : failback to external normal mgc	

199.7 Voice Sip L1 Transport Statistics Commands

199.8 Voice POTS Diagnostics Management Command

Command Description

This command allows the operator to test MLT for the POTS lines on the ONT

The result of the MLT tests can be retrieved using "show voice ont pots diagnostic" command.

User Level

The command can be accessed by operators with sip,megaco privileges, and executed by operators with sip,megaco privileges.

Command Syntax

The command has the following syntax:

```
> admin voice ont pots diagnostics (uni-idx) [ mode <Gpon::Mode> ] [ hazard-dc-volt-th <Gpon::HazDcTh> ] [ hazard-ac-volt-th <Gpon::HazAcTh> ] [ frgn-ac-volt-th <Gpon::FgAcTh> ] [ frgn-dc-volt-th <Gpon::FgDcTh> ] [ tipgnd-rnggnd-th <Gpon::TipRngTh> ] [ tip-ring-th <Gpon::TipRngTh> ] [ ring-min-th <Gpon::RngLoadTh> ] [ ring-max-th <Gpon::RngLoadTh> ] [ diagnostic <Gpon::Potsdgn> ]
```

Command Parameters

Table 199.8-1 "Voice POTS Diagnostics Management Command" Resource Parameters

Resource Identifier	Type	Description
(uni-idx)	Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Gpon::OntSlotId> / <Gpon::OntPotsPortId> ng2 : <Ng2::ChannelGroup> / <Ng2::SubchannelGroup> / <Ng2::OntId> / <Gpon::OntSlotId> / <Gpon::OntPotsPortId>) Possible values: - ng2 : ngpon2 style identification Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Eqpt::OntId> - the ONT identifier Field type <Ng2::ChannelGroup>	ontpots index

Resource Identifier	Type	Description
	- channel group number Field type <Ng2::SubchannelGroup> - subchannel group number Field type <Ng2::OntId> - the ONT identifier Field type <Gpon::OntSlotId> - Gpon Ont Slot - range: [1...14] Field type <Gpon::OntPotsPortId> - Gpon Ont Pots Port - range: [1...24]	

Table 199.8-2 "Voice POTS Diagnostics Management Command" Command Parameters

Parameter	Type	Description
mode	Parameter type: <Gpon::Mode> Format: (deny force) Possible values: - deny : deny the test - force : force the test	<i>optional parameter</i> used to force or deny the test if line is busy
hazard-dc-volt-th	Parameter type: <Gpon::HazDcTh> Format: - Threshold for declaring Hazardous DC Voltage - range: [0,80...150]	<i>optional parameter</i> threshold for declaring Hazardous DC Voltage test pass or fail
hazard-ac-volt-th	Parameter type: <Gpon::HazAcTh> Format: - Threshold for declaring Hazardous AC Voltage - range: [0,50...150]	<i>optional parameter</i> threshold for declaring Hazardous AC Voltage test pass or fail
frgn-ac-volt-th	Parameter type: <Gpon::FgAcTh> Format: - Threshold for declaring Foreign AC Voltage - range: [0,10...50]	<i>optional parameter</i> threshold for declaring Foreign AC Voltage test pass or fail
frgn-dc-volt-th	Parameter type: <Gpon::FgDcTh> Format: - Threshold for declaring Foreign DC Voltage - range: [0...10]	<i>optional parameter</i> threshold for declaring Foreign DC Voltage test pass or fail
tipgnd-rnggnd-th	Parameter type: <Gpon::TipRngTh> Format: - Threshold for declaring Tip-Ground or Ring-Ground Resistance - range: [0...250]	<i>optional parameter</i> threshold for declaring Tip-Ground to Ring-Ground Resistance test pass or fail
tip-ring-th	Parameter type: <Gpon::TipRngTh> Format: - Threshold for declaring Tip-Ground or Ring-Ground Resistance - range: [0...250]	<i>optional parameter</i> threshold for declaring Tip and Ring Resistance test pass or fail
ring-min-th	Parameter type: <Gpon::RngLoadTh> Format: - Threshold (MIN/MAX) for declaring Ringer Load - range: [0...700]	<i>optional parameter</i> threshold (MIN) for declaring Ringer Load test pass or fail
ring-max-th	Parameter type: <Gpon::RngLoadTh> Format: - Threshold (MIN/MAX) for declaring Ringer Load - range: [0...700]	<i>optional parameter</i> threshold (MIN) for declaring Ringer Load test pass or fail
diagnostic	Parameter type: <Gpon::Potsdgn> Format:	<i>optional parameter</i> indicating desire to execute

Parameter	Type	Description
	test_initiated Possible values: - test_initiated : MLT test initiated.Only value settable by Manager	POTS port MLT test always 1

199.9 Voice POTS Pull-Break Management Command

Command Description

This command allows the operator to run Pull/Break Dialtone test for POTS lines on the ONT

The result of the Pull/Break DialTone tests can be retrieved using "show voice ont pots pb-dial-tone" command

User Level

The command can be accessed by operators with sip,megaco privileges, and executed by operators with sip,megaco privileges.

Command Syntax

The command has the following syntax:

```
> admin voice ont pots pb-dial-tone (uni-idx) [ no slow-pull-timer | slow-pull-timer <Gpon::SlwPullTmr> ] [ no
no-pull-timer | no-pull-timer <Gpon::NoPullTmr> ] [ no slow-break-timer | slow-break-timer <Gpon::SlwBrkTmr>
] [ no no-break-timer | no-break-timer <Gpon::NoBrkTmr> ] [ no test-digit | test-digit <Gpon::TestDigit> ]
diagnostic <Gpon::PbDialToneDgn>
```

Command Parameters

Table 199.9-1 "Voice POTS Pull-Break Management Command" Resource Parameters

Resource Identifier	Type	Description
(uni-idx)	Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Gpon::OntSlotId> / <Gpon::OntPotsPortId> ng2 : <Ng2::ChannelGroup> / <Ng2::SubchannelGroup> / <Ng2::OntId> / <Gpon::OntSlotId> / <Gpon::OntPotsPortId>) Possible values: - ng2 : ngpon2 style identification Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Eqpt::OntId> - the ONT identifier Field type <Ng2::ChannelGroup>	ontpots index

Resource Identifier	Type	Description
	- channel group number Field type <Ng2::SubchannelGroup> - subchannel group number Field type <Ng2::OntId> - the ONT identifier Field type <Gpon::OntSlotId> - Gpon Ont Slot - range: [1...14] Field type <Gpon::OntPotsPortId> - Gpon Ont Pots Port - range: [1...24]	

Table 199.9-2 "Voice POTS Pull-Break Management Command" Command Parameters

Parameter	Type	Description
[no] slow-pull-timer	Parameter type: <Gpon::SlwPullTmr> Format: - Threshold Timer which the ONT should use to determine if dialtone was obtained slowly - unit: sec - range: [0...6]	<i>optional parameter with default value: 0</i> Threshold Timer which the ONT should use to determine if dialtone was obtained slowly
[no] no-pull-timer	Parameter type: <Gpon::NoPullTmr> Format: - Threshold Timer which the ONT should use to determine if dialtone was not obtained - unit: sec - range: [0,1...10]	<i>optional parameter with default value: 0</i> Threshold Timer which the ONT should use to determine if dialtone was not obtained
[no] slow-break-timer	Parameter type: <Gpon::SlwBrkTmr> Format: - Threshold Timer which the ONT should use to determine if dialtone break was obtained slowly - unit: sec - range: [0...3]	<i>optional parameter with default value: 0</i> Threshold Timer which the ONT should use to determine if dialtone break was obtained slowly
[no] no-break-timer	Parameter type: <Gpon::NoBrkTmr> Format: - Threshold Timer which the ONT should use to determine if dialtone break was not obtained - unit: sec - range: [0,1...3]	<i>optional parameter with default value: 0</i> Threshold Timer which the ONT should use to determine if dialtone break was not obtained
[no] test-digit	Parameter type: <Gpon::TestDigit> Format: - digit that the ONT should use to break the dial tone - range: [0-9*#] - length: x<=1	<i>optional parameter with default value: ""</i> digit that the ONT should use to break the dial tone
diagnostic	Parameter type: <Gpon::PbDialToneDgn> Format: test_initiated Possible values: - test_initiated : dialtone test initiated.Only value settable by Manager	<i>optional parameter</i> desire to execute POTS make-break dialtone test always 1

199.10 Voice SIP Pull-Break Management

Command

Command Description

This command allows the operator to run the SIP Pull-Break Dial tone test for POTS lines on the ONT

The result of the SIP Pull-Break DialTone tests can be retrieved using "show voice ont pots sip-dial-tone" command.

User Level

The command can be accessed by operators with sip,megaco privileges, and executed by operators with sip,megaco privileges.

Command Syntax

The command has the following syntax:

```
> admin voice ont pots sip-dial-tone (uni-idx) sip-phone-number <Gpon::SipPhNo> diagnostic <Gpon::SipDgn>
```

Command Parameters

Table 199.10-1 "Voice SIP Pull-Break Management Command" Resource Parameters

Resource Identifier	Type	Description
(uni-idx)	Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Gpon::OntSlotId> / <Gpon::OntPotsPortId> ng2 : <Ng2::ChannelGroup> / <Ng2::SubchannelGroup> / <Ng2::OntId> / <Gpon::OntSlotId> / <Gpon::OntPotsPortId>) Possible values: - ng2 : ngpon2 style identification Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Eqpt::OntId> - the ONT identifier Field type <Ng2::ChannelGroup> - channel group number Field type <Ng2::SubchannelGroup>	ont pots index

Resource Identifier	Type	Description
	- subchannel group number Field type <Ng2::OntId> - the ONT identifier Field type <Gpon::OntSlotId> - Gpon Ont Slot - range: [1...14] Field type <Gpon::OntPotsPortId> - Gpon Ont Pots Port - range: [1...24]	

Table 199.10-2 "Voice SIP Pull-Break Management Command" Command Parameters

Parameter	Type	Description
sip-phone-number	Parameter type: <Gpon::SipPhNo> Format: - Phone number to be dialed for the SIP pull-break test - range: [0-9*#] - length: x<=16	<i>optional parameter</i> Phone number to be dialed for the SIP pull-break test
diagnostic	Parameter type: <Gpon::SipDgn> Format: test_initiated Possible values: - test_initiated : Sip dialtone test initiated.Only value settable by Manager	<i>optional parameter</i> indicating desire to execute POTS SIP make-break dialtone test

199.11 GPON Voip Configuration Management

Command

Command Description

This command causes the ONT to redownload the VOIP configuration for the ONT. This is only used when the operator thinks that the ONT has been configured to retrieve the correct VOIP configuration but there was a failure in this retrieval and another manually initiated attempt should be tried

User Level

The command can be accessed by operators with sip,megaco privileges, and executed by operators with sip,megaco privileges.

Command Syntax

The command has the following syntax:

```
> admin voice ont voip-config (voip-index) (active)
```

Command Parameters

Table 199.11-1 "GPON Voip Configuration Management Command" Resource Parameters

Resource Identifier	Type	Description
(voip-index)	Format: (ont : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Gpon::IpHostId> ont:ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / <Ng2::IpHostId>) Possible values: - ont:ng2 : ngpon2 ont - ont : ont Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Eqpt::OntId> - the ONT identifier Field type <Eqpt::ChannelGroupId> - the channel group identifier Field type <Eqpt::SubChannelGroupId> - the subchannel group identifier	a unique interface index

Resource Identifier	Type	Description
	Field type <Eqpt::Ng2OntId> - the NG2 ONT identifier Field type <Gpon::IpHostID> - iphost id Field type <Ng2::IpHostID> - iphost id (ngpon2)	

Table 199.11-2 "GPON Voip Configuration Management Command" Command Parameters

Parameter	Type	Description
(active)	Format: active Possible values: - active : to activate the profile	<i>optional parameter</i> to activate the profile

200- MSTP Management Commands

200.1 MSTP Management Command Tree	200-7149
200.2 MSTP Port Management Command	200-7150

200.1 MSTP Management Command Tree

Description

This chapter gives an overview of nodes that are handled by "MSTP Management Commands".

Command Tree

```
----admin
  ----xstp
    ----port
      - (port)
      - (clear-protocols)
```

200.2 MSTP Port Management Command

Command Description

This command allows the operator to manage MSTP related to a port.

User Level

The command can be accessed by operators with mstp privileges, and executed by operators with mstp privileges.

Command Syntax

The command has the following syntax:

```
> admin xstp port (port) [ (clear-protocols) ]
```

Command Parameters

Table 200.2-1 "MSTP Port Management Command" Resource Parameters

Resource Identifier	Type	Description
(port)	Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number	interface index of the lag

Table 200.2-2 "MSTP Port Management Command" Command Parameters

Parameter	Type	Description
(clear-protocols)	Format: clear-protocols Possible values: - clear-protocols : clear the list of detected protocols	<i>optional parameter</i> clear the list of detected protocols

201- *Distributed Service Management Commands*

201.1 Distributed Service Management Command Tree	201-7152
201.2 APIPE-PVC Statistics Command	201-7153

201.1 Distributed Service Management Command Tree

Description

This chapter gives an overview of nodes that are handled by "Distributed Service Management Commands".

Command Tree

```
----admin
  ----dist-service
    ----statistics
      ----apipe-pvc
        - (port-index)
        - (clear)
```

201.2 APIPE-PVC Statistics Command

Command Description

This command is to reset the APIPE-PVC statistics counters.

User Level

The command can be executed by operators with drouter privileges.

Command Syntax

The command has the following syntax:

```
> admin dist-service statistics apipe-pvc (port-index) (clear)
```

Command Parameters

Table 201.2-1 "APIPE-PVC Statistics Command" Resource Parameters

Resource Identifier	Type	Description
(port-index)	Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::VpiMandatoryId> : <Eqpt::VciMandatoryId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number Field type <Eqpt::VpiMandatoryId> - atm VPI Field type <Eqpt::VciMandatoryId> - atm VCI	the ATM PVC

Table 201.2-2 "APIPE-PVC Statistics Command" Command Parameters

Parameter	Type	Description
(clear)	Format: clear Possible values: - clear : reset statistics counters	<i>optional parameter</i> optional parameter reset APIPE-PVC counters

202- Pon Management Commands

202.1 Pon Management Command Tree	202-7155
202.2 Pon Bit Error Statistics Commands	202-7156
202.3 PON Rogue Test Diagnostic Command	202-7158
202.4 PON Utilization PM Reset Command	202-7160
202.5 PON Peak Utilization PM Reset Command	202-7162
202.6 Pon RangeNumMismatch Alarm Reset Commands	202-7164
202.7 Ont on Given Pon Reboot Commands	202-7166

202.1 Pon Management Command Tree

Description

This chapter gives an overview of nodes that are handled by "Pon Management Commands".

Command Tree

```
----admin
  ----pon
    ----ber-stats
      - (pon-idx)
      - (clear-statistics)
    ----diagnostic
      - (index)
      - mode
      - bkgstucklasermode
      - bkgpatternmode
      - bkgroguetestinterval
      - alien-mantestmode
      - alien-bkgtestmode
      - alien-bkgtestinterval
    ----utilization
      - (pon-idx)
      - (clear-counters)
    ----peak-utilization
      - (pon-idx)
      - (clear-counters)
    ----clear-alarm
      - (pon-idx)
      - (clr-rng-mismatch)
    ----reboot-all-ont
      - (pon-idx)
      - (reboot-all-ont)
```

202.2 Pon Bit Error Statistics Commands

Command Description

This command allows the operator to reset the Pon Bit Error Statistics.

User Level

The command can be accessed by operators with equipment privileges, and executed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

```
> admin pon ber-stats (pon-idx) (clear-statistics)
```

Command Parameters

Table 202.2-1 "Pon Bit Error Statistics Commands" Resource Parameters

Resource Identifier	Type	Description
(pon-idx)	Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> x-pon : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::XPonId> 25g-pon : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::M25GPonId>) Possible values: - 25g-pon : 25g pon - x-pon : Xgs pon Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Eqpt::XPonId> - the XGS PON identifier Field type <Eqpt::M25GPonId> - the 25G PON identifier	pon index

Table 202.2-2 "Pon Bit Error Statistics Commands" Command Parameters

Parameter	Type	Description
(clear-statistics)	Format: clear-statistics Possible values:	<i>optional parameter</i> clear the pon bit error counts

Parameter	Type	Description
	- clear-statistics : clear the pon bit error counts	

202.3 PON Rogue Test Diagnostic Command

Command Description

This command is used to initiate and stop the rogue ONT discovery procedure on a PON.

Background Pattern Test is 'stop-bkg-test' by default.

Background Alien Test is 'stop-bkg-test' by default.

User Level

The command can be accessed by operators with equipment privileges, and executed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

```
> admin pon diagnostic (index) [ mode <Gpon::PonRogueTestMode> ] [ bkgstucklasermode
<Gpon::PonBkgdRogueTestMode> ] [ bkgpatternmode <Gpon::PonBkgdRogueTestMode> ] [ bkgroguetestinterval
<Gpon::BkgdRogueTestInterval> ] [ alien-mantestmode <Gpon::PonManAlienTestMode> ] [ alien-bkgtestmode
<Gpon::PonBkgdAlienTestMode> ] [ alien-bkgtestinterval <Gpon::BkgdAlienTestInterval> ]
```

Command Parameters

Table 202.3-1 "PON Rogue Test Diagnostic Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> x-pon : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::XPonId> 25g-pon : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::M25GPonId>) Possible values: - 25g-pon : 25g pon - x-pon : Xgs pon Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Eqpt::XPonId> - the XGS PON identifier Field type <Eqpt::M25GPonId> - the 25G PON identifier	identification of pon

Table 202.3-2 "PON Rogue Test Diagnostic Command" Command Parameters

Parameter	Type	Description
mode	Parameter type: <Gpon::PonRogueTestMode> Format: (init-onofftest stop init-patterntest) Possible values: - init-onofftest : start the ON-OFF rogue test - stop : stop the rogue test - init-patterntest : start the Pattern rogue test	<i>optional parameter</i> enable or disable pon rogue test diagnostic
bkgstucklasermode	Parameter type: <Gpon::PonBkgdRogueTestMode> Format: (init-bkg-test stop-bkg-test) Possible values: - init-bkg-test : start the background rogue test - stop-bkg-test : stop the background rogue test	<i>optional parameter</i> enable or disable pon background stuck laser test diagnostic
bkgpatternmode	Parameter type: <Gpon::PonBkgdRogueTestMode> Format: (init-bkg-test stop-bkg-test) Possible values: - init-bkg-test : start the background rogue test - stop-bkg-test : stop the background rogue test	<i>optional parameter</i> enable or disable pon background pattern test diagnostic
bkgroguetestinterval	Parameter type: <Gpon::BkgdRogueTestInterval> Format: - Numbers divisible by 15 are permitted. - unit: Minutes - range: [60...1440]	<i>optional parameter</i> Frequency of background rogue ont test execution
alien-mantestmode	Parameter type: <Gpon::PonManAlienTestMode> Format: (init-man-test stop-man-test) Possible values: - init-man-test : start the manual Alien test - stop-man-test : stop the manual Alien test	<i>optional parameter</i> Enable or disable pon manual alien ont test diagnostic
alien-bkgtestmode	Parameter type: <Gpon::PonBkgdAlienTestMode> Format: (init-bkg-test stop-bkg-test) Possible values: - init-bkg-test : start the background Alien test - stop-bkg-test : stop the background Alien test	<i>optional parameter</i> Enable or disable pon background alien ont test diagnostic
alien-bkgtestinterval	Parameter type: <Gpon::BkgdAlienTestInterval> Format: - Numbers divisible by 30 are permitted. - unit: Minutes - range: [30...240]	<i>optional parameter</i> Frequency of background alien ont test execution

202.4 PON Utilization PM Reset Command

Command Description

This command resets the PON utilization PM counters.

User Level

The command can be accessed by operators with equipment privileges, and executed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

```
> admin pon utilization (pon-idx) (clear-counters)
```

Command Parameters

Table 202.4-1 "PON Utilization PM Reset Command" Resource Parameters

Resource Identifier	Type	Description
(pon-idx)	Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> x-pon : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::XPonId> 25g-pon : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::M25GPonId>) Possible values: - 25g-pon : 25g pon - x-pon : Xgs pon Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Eqpt::XPonId> - the XGS PON identifier Field type <Eqpt::M25GPonId> - the 25G PON identifier	pon index

Table 202.4-2 "PON Utilization PM Reset Command" Command Parameters

Parameter	Type	Description
(clear-counters)	Format: clear-counters Possible values:	<i>optional parameter</i> clear the pon utilization pm counters

Parameter	Type	Description
	- clear-counters : clear the utilization pm counters	

202.5 PON Peak Utilization PM Reset Command

Command Description

This command resets the PON Peak utilization PM counters.

User Level

The command can be accessed by operators with equipment privileges, and executed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

```
> admin pon peak-utilization (pon-idx) (clear-counters)
```

Command Parameters

Table 202.5-1 "PON Peak Utilization PM Reset Command" Resource Parameters

Resource Identifier	Type	Description
(pon-idx)	Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> x-pon : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::XPonId> 25g-pon : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::M25GPonId>) Possible values: - 25g-pon : 25g pon - x-pon : Xgs pon Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Eqpt::XPonId> - the XGS PON identifier Field type <Eqpt::M25GPonId> - the 25G PON identifier	pon index

Table 202.5-2 "PON Peak Utilization PM Reset Command" Command Parameters

Parameter	Type	Description
(clear-counters)	Format: clear-counters Possible values:	<i>optional parameter</i> clear the pon peak utilization pm counters

Parameter	Type	Description
	- clear-counters : clear the peak utilization pm counters	

202.6 Pon RangeNumMismatch Alarm Reset Commands

Command Description

This command allows the operator to reset the Pon RangeNumMismatch Alarm.

User Level

The command can be accessed by operators with equipment privileges, and executed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

```
> admin pon clear-alarm (pon-idx) (clr-rng-mismatch)
```

Command Parameters

Table 202.6-1 "Pon RangeNumMismatch Alarm Reset Commands" Resource Parameters

Resource Identifier	Type	Description
(pon-idx)	Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> x-pon : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::XPonId> 25g-pon : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::M25GPonId>) Possible values: - 25g-pon : 25g pon - x-pon : Xgs pon Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Eqpt::XPonId> - the XGS PON identifier Field type <Eqpt::M25GPonId> - the 25G PON identifier	pon index

Table 202.6-2 "Pon RangeNumMismatch Alarm Reset Commands" Command Parameters

Parameter	Type	Description
(clr-rng-mismatch)	Format: clr-rng-mismatch Possible values: - clr-rng-mismatch : clear alarm of ranging number mismatch	<i>optional parameter</i> clear alarm of ranging number mismatch

202.7 Ont on Given Pon Reboot Commands

Command Description

This command allows the operator to reboot all ont on the given Pon.

User Level

The command can be accessed by operators with equipment privileges, and executed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

```
> admin pon reboot-all-ont (pon-idx) (reboot-all-ont)
```

Command Parameters

Table 202.7-1 "Ont on Given Pon Reboot Commands" Resource Parameters

Resource Identifier	Type	Description
(pon-idx)	Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> x-pon : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::XPonId> 25g-pon : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::M25GPonId>) Possible values: - 25g-pon : 25g pon - x-pon : Xgs pon Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Eqpt::XPonId> - the XGS PON identifier Field type <Eqpt::M25GPonId> - the 25G PON identifier	pon index

Table 202.7-2 "Ont on Given Pon Reboot Commands" Command Parameters

Parameter	Type	Description
(reboot-all-ont)	Format: via-ploam Possible values:	<i>optional parameter</i> reboot the ont on the given pon

Parameter	Type	Description
	- via-ploam : reboot via ploam	

203- Channel Pair Management Commands

203.1 Channel Pair Management Command Tree	203-7169
203.2 NGPON2 Rogue Test Diagnostic Command	203-7170
203.3 Channel Pair Utilization PM Reset Command	203-7172
203.4 Channel Pair Peak Utilization PM Reset Command	203-7173
203.5 Pon RangeNumMismatch Alarm Reset Commands	203-7174
203.6 NGPON2 Rogue Ont Reboot Command	203-7175

203.1 Channel Pair Management Command Tree

Description

This chapter gives an overview of nodes that are handled by "Channel Pair Management Commands".

Command Tree

- admin**
 - channel-pair**
 - diagnostic**
 - **(index)**
 - mode
 - bkgstucklasermode
 - bkgpatternmode
 - bkgroguetestinterval
 - alien-mantestmode
 - alien-bkgtestmode
 - alien-bkgtestinterval
 - utilization**
 - **(chpair-idx)**
 - (clear-counters)
 - peak-utilization**
 - **(chpair-idx)**
 - (clear-counters)
 - clear-alarm**
 - **(chpair-idx)**
 - (clr-rng-mismatch)
 - reboot-all-ont**
 - **(index)**
 - (reboot-all-ont)

203.2 NGPON2 Rogue Test Diagnostic Command

Command Description

This command is used to initiate and stop the rogue ONT discovery procedure on a channel pair.

Background Pattern Test is 'stop-bkg-test' by default.

Background Alien Test is 'stop-bkg-test' by default.

User Level

The command can be accessed by operators with equipment privileges, and executed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

```
> admin channel-pair diagnostic (index) [ mode <Gpon::PonRogueTestMode> ] [ bkgstucklasermode
<Gpon::PonBkgdRogueTestMode> ] [ bkgpatternmode <Gpon::PonBkgdRogueTestMode> ] [ bkgroguetestinterval
<Gpon::BkgdRogueTestInterval> ] [ alien-mantestmode <Gpon::PonManAlienTestMode> ] [ alien-bkgtestmode
<Gpon::PonBkgdAlienTestMode> ] [ alien-bkgtestinterval <Gpon::BkgdAlienTestInterval> ]
```

Command Parameters

Table 203.2-1 "NGPON2 Rogue Test Diagnostic Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::ChannelPairId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::ChannelPairId> - the channel pair identifier	identification of channel pair

Table 203.2-2 "NGPON2 Rogue Test Diagnostic Command" Command Parameters

Parameter	Type	Description
mode	Parameter type: <Gpon::PonRogueTestMode> Format: (init-onofftest stop init-patterntest) Possible values: - init-onofftest : start the ON-OFF rogue test - stop : stop the rogue test	<i>optional parameter</i> enable or disable channel pair rogue test diagnostic

Parameter	Type	Description
	- init-patterntest : start the Pattern rogue test	
bkgstucklasermode	Parameter type: <Gpon::PonBkgdRogueTestMode> Format: (init-bkg-test stop-bkg-test) Possible values: - init-bkg-test : start the background rogue test - stop-bkg-test : stop the background rogue test	<i>optional parameter</i> enable or disable channel pair background stuck laser test diagnostic
bkgpatternmode	Parameter type: <Gpon::PonBkgdRogueTestMode> Format: (init-bkg-test stop-bkg-test) Possible values: - init-bkg-test : start the background rogue test - stop-bkg-test : stop the background rogue test	<i>optional parameter</i> enable or disable channel pair background pattern test diagnostic
bkgroguetestinterval	Parameter type: <Gpon::BkgdRogueTestInterval> Format: - Numbers divisible by 15 are permitted. - unit: Minutes - range: [60...1440]	<i>optional parameter</i> Frequency of background pattern test execution
alien-mantestmode	Parameter type: <Gpon::PonManAlienTestMode> Format: (init-man-test stop-man-test) Possible values: - init-man-test : start the manual Alien test - stop-man-test : stop the manual Alien test	<i>optional parameter</i> Enable or disable channelpair manual alien ont test diagnostic
alien-bkgtestmode	Parameter type: <Gpon::PonBkgdAlienTestMode> Format: (init-bkg-test stop-bkg-test) Possible values: - init-bkg-test : start the background Alien test - stop-bkg-test : stop the background Alien test	<i>optional parameter</i> Enable or disable channelpair background alien ont test diagnostic
alien-bkgtestinterval	Parameter type: <Gpon::BkgdAlienTestInterval> Format: - Numbers divisible by 30 are permitted. - unit: Minutes - range: [30...240]	<i>optional parameter</i> Frequency of background alien ont test execution

203.3 Channel Pair Utilization PM Reset Command

Command Description

This command resets the channel-pair utilization PM counters.

User Level

The command can be accessed by operators with equipment privileges, and executed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

```
> admin channel-pair utilization (chpair-idx) (clear-counters)
```

Command Parameters

Table 203.3-1 "Channel Pair Utilization PM Reset Command" Resource Parameters

Resource Identifier	Type	Description
(chpair-idx)	Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::ChannelPairId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::ChannelPairId> - the channel pair identifier	channel pair index

Table 203.3-2 "Channel Pair Utilization PM Reset Command" Command Parameters

Parameter	Type	Description
(clear-counters)	Format: clear-counters Possible values: - clear-counters : clear the utilization pm counters	<i>optional parameter</i> clear the channel pair utilization pm counters

203.4 Channel Pair Peak Utilization PM Reset Command

Command Description

This command resets the channel-pair peak utilization PM counters.

User Level

The command can be accessed by operators with equipment privileges, and executed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

```
> admin channel-pair peak-utilization (chpair-idx) (clear-counters)
```

Command Parameters

Table 203.4-1 "Channel Pair Peak Utilization PM Reset Command" Resource Parameters

Resource Identifier	Type	Description
(chpair-idx)	Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::ChannelPairId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::ChannelPairId> - the channel pair identifier	channel pair index

Table 203.4-2 "Channel Pair Peak Utilization PM Reset Command" Command Parameters

Parameter	Type	Description
(clear-counters)	Format: clear-counters Possible values: - clear-counters : clear the peak utilization pm counters	<i>optional parameter</i> clear the channel pair peak utilization pm counters

203.5 Pon RangeNumMismatch Alarm Reset Commands

Command Description

This command allows the operator to reset the Pon RangeNumMismatch Alarm.

User Level

The command can be accessed by operators with equipment privileges, and executed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

```
> admin channel-pair clear-alarm (chpair-idx) (clr-rng-mismatch)
```

Command Parameters

Table 203.5-1 "Pon RangeNumMismatch Alarm Reset Commands" Resource Parameters

Resource Identifier	Type	Description
(chpair-idx)	Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::ChannelPairId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::ChannelPairId> - the channel pair identifier	channel pair index

Table 203.5-2 "Pon RangeNumMismatch Alarm Reset Commands" Command Parameters

Parameter	Type	Description
(clr-rng-mismatch)	Format: clr-rng-mismatch Possible values: - clr-rng-mismatch : clear alarm of ranging number mismatch	<i>optional parameter</i> clear alarm of ranging number mismatch

203.6 NGPON2 Rogue Ont Reboot Command

Command Description

This command allows the operator to reboot all ont on the given channel pair.

User Level

The command can be accessed by operators with equipment privileges, and executed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

```
> admin channel-pair reboot-all-ont (index) (reboot-all-ont)
```

Command Parameters

Table 203.6-1 "NGPON2 Rogue Ont Reboot Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::ChannelPairId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::ChannelPairId> - the channel pair identifier	identification of channel pair

Table 203.6-2 "NGPON2 Rogue Ont Reboot Command" Command Parameters

Parameter	Type	Description
(reboot-all-ont)	Format: via-ploam Possible values: - via-ploam : reboot via ploam	<i>optional parameter</i> reboot the ont on the given channel-pair

204- CESUNI Management Commands

204.1 CESUNI Management Command Tree	204-7177
204.2 CESUNI Loopback Management Command	204-7178

204.1 CESUNI Management Command Tree

Description

This chapter gives an overview of nodes that are handled by "CESUNI Management Commands".

Command Tree

```
----admin
  ----ces
    ----ont
      ----line
        - (ont-idx)
        - (loop-back)
```

204.2 CESUNI Loopback Management Command

Command Description

This command puts/releases the CESUNI port in loopback mode

User Level

The command can be accessed by operators with equipment privileges, and executed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

```
> admin ces ont line (ont-idx) [ (loop-back) ]
```

Command Parameters

Table 204.2-1 "CESUNI Loopback Management Command" Resource Parameters

Resource Identifier	Type	Description
(ont-idx)	Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Gpon::OntSlotId> / <Gpon::OntPortId> ng2 : <Ng2::ChannelGroup> / <Ng2::SubchannelGroup> / <Ng2::OntId> / <Gpon::OntSlotId> / <Gpon::OntPortId>) Possible values: - ng2 : ngpon2 style identification Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Ng2::ChannelGroup> - channel group number Field type <Ng2::SubchannelGroup> - subchannel group number Field type <Eqpt::OntId> - the ONT identifier Field type <Ng2::OntId> - the ONT identifier Field type <Gpon::OntSlotId> - Gpon Ont Slot - range: [1...14] Field type <Gpon::OntPortId>	interface index of the ces ont uni

Resource Identifier	Type	Description
	- Gpon Ont Port - range: [1...16]	

Table 204.2-2 "CESUNI Loopback Management Command" Command Parameters

Parameter	Type	Description
(loop-back)	Format: (no-loopback line-loopback inward-loopback) Possible values: - no-loopback : no loopback - line-loopback : line loopback - inward-loopback : inward loopback	<i>optional parameter</i> This parameter specifies the Loop-back Type

205- CFM Management Commands.

205.1 CFM Management Command. Tree	205-7181
205.2 Unicast Loopback message Management Command	205-7182
205.3 CFM Multicast Loopback Management Command	205-7186
205.4 CFM Linktrace management command	205-7188
205.5 Linktrace message Management Command	205-7189
205.6 CFM Single Ended Synthetic Loss Measurement message Management Command	205-7195
205.7 Single Ended Synthetic Loss Measurement message Management Command	205-7196

205.1 CFM Management Command. Tree

Description

This chapter gives an overview of nodes that are handled by "CFM Management Commands".

Command Tree

```

----admin
  ----cfm
    ----uclbm
      - domain
      - association
      - mep
      - dest-mac
      - [no] nbr-msgs
      - [no] lbm-tlv-type
      - [no] lbm-data-len
      - [no] lbm-data
      - [no] test-bit-pattern
      - [no] vlan-priority
      - [no] vlan-drop-enable
      - [no] vlan-drop-pcp
    ----mclbm
      - domain
      - association
      - mep
      - [no] vlan-priority
      - [no] lbm-tlv-type
      - [no] lbm-data-len
      - [no] lbm-data
    ----ltm
      ----domain
        - (domain-index)
        - association
        - mep
        - target-mac
        - [no] vlan-priority
        - [no] ttl
        - [no] fdb-only-bit
      ----single-ended-slm
        ----domain
          - (domain)
          - association
          - mep
          - target-mac
          - [no] send-count
          - [no] size
          - [no] timeout
          - [no] interval
          - [no] priority

```

205.2 Unicast Loopback message Management Command

Command Description

This command initiates the test of Unicast Loopback messages.

A number of Loopback messages can be requested to be send from a specified MEP towards a specified destination MAC address.

User Level

The command can be accessed by operators with alarm , oam , vlan privileges, and executed by operators with alarm , oam , vlan privileges.

Command Syntax

The command has the following syntax:

```
> admin cfm uclbm domain <Cfm::CfmDomainIndexType> association <Cfm::CfmMaIndexType> mep
<Cfm::MepIdType> dest-mac <Vlan::MacAddr> [ no nbr-msgs | nbr-msgs <Cfm::UclbmNbrMsgType> ] [ no
lbm-tlv-type | lbm-tlv-type <Cfm::TlvType> ] [ no lbm-data-len | lbm-data-len <Cfm::LbmDataLenType> ] [ no
lbm-data | lbm-data <Cfm::LbmDataType> ] [ no test-bit-pattern | test-bit-pattern <Cfm::TestBitPatternType> ] [
no vlan-priority | vlan-priority <Vlan::Priority> ] [ no vlan-drop-enable | vlan-drop-enable
<Cfm::VlanDropEnableType> ] [ no vlan-drop-pcp | vlan-drop-pcp <Cfm::VlanDropPcpType> ]
```

Command Parameters

Table 205.2-2 "Unicast Loopback message Management Command" Command Parameters

Parameter	Type	Description
domain	Parameter type: <Cfm::CfmDomainIndexType> Format: - Maintenance Domain (MD) index - range: [1...4294967295]	<i>mandatory parameter</i> Maintenance Domain Index.
association	Parameter type: <Cfm::CfmMaIndexType> Format: - Maintenance Association (MA) index. Unique within an MD - range: [1...4294967295]	<i>mandatory parameter</i> Maintenance Association Index.
mep	Parameter type: <Cfm::MepIdType> Format: - MA End Point (MEP) ID. Unique within an MA - range: [1...8191]	<i>mandatory parameter</i> Maintenance Association End Point (MEP) ID. Unique within an MA.
dest-mac	Parameter type: <Vlan::MacAddr> Format: - mac address (aa:bb:cc:a1:02:03) - unit: Byte	<i>mandatory parameter</i> The MAC address for the OAM target: a unicast destination MAC address in the Unicast Loopback

Parameter	Type	Description
	- length: 6	message.
[no] nbr-msgs	Parameter type: <Cfm::UcLbmNbrMsgType> Format: - The number of Unicast Loopback messages to be transmitted. For GPON LT, the range is [1..2] - range: [1...5]	<i>optional parameter with default value: 1L</i> The number of Unicast Loopback messages to be transmitted.
[no] lbm-tlv-type	Parameter type: <Cfm::TlvType> Format: (tlv-none data-tlv test-tlv) Possible values: - tlv-none : no TLV - data-tlv : data TLV - test-tlv : test TLV	<i>optional parameter with default value: "tlv-none"</i> Specifies which TLV type is to be used for LBM.
[no] lbm-data-len	Parameter type: <Cfm::LbmDataLenType> Format: - the length of the Data TLV - range: [1...1488]	<i>optional parameter with default value: 64L</i> The value specifies the length of the TLV. Specifying length zero implies no TLV will be included in LBM. Default length = 64 octets.
[no] lbm-data	Parameter type: <Cfm::LbmDataType> Format: - a binary string - length: 8	<i>optional parameter with default value: "00 : 00 : 00 : 00 : 00 : 00 : 00 : 00"</i> This is hex string of 8 bytes used repetitively to fillup Data TLV, if the Data TLV is selected to be sent. Most significant bits are used first.
[no] test-bit-pattern	Parameter type: <Cfm::TestBitPatternType> Format: (all-zeros-no-crc all-zeros-crc prbs-no-crc prbs-crc all-ones-no-crc all-ones-crc <SignedInteger>) Possible values: - all-zeros-no-crc : A bit pattern with all zero's without CRC. - all-zeros-crc : A bit pattern with all zero's with CRC. - prbs-no-crc : A Pseudo Random Bit Sequence of type (2 ³¹)-1, according ITU-T O.150, without CRC. - prbs-crc : A Pseudo Random Bit Sequence of type (2 ³¹)-1, according ITU-T O.150, with CRC. - all-ones-no-crc : A bit pattern with all one's without CRC. - all-ones-crc : A bit pattern with all one's with CRC. Field type <SignedInteger> - a signed integer	<i>optional parameter with default value: "all-zeros-no-crc"</i> To specify which bit pattern type to use in the Test TLV within a unicast LBM. Default = allZerosNoCrc
[no] vlan-priority	Parameter type: <Vlan::Priority> Format: - priority of ethernet frames - range: [0...7]	<i>optional parameter with default value: 7L</i> Priority. A 3 bit value to be used in the VLAN tag, if present in the transmitted frame. Default = 7 decimal.
[no] vlan-drop-enable	Parameter type: <Cfm::VlanDropEnableType>	<i>optional parameter with default</i>

Parameter	Type	Description
	Format: (no-drop pcp dei <SignedInteger>) Possible values: - no-drop : Packet must not be marked as drop eligible. - pcp : Priority Code Point encoding to be used. - dei : Drop eligible indicator to be used. Can only be used in context of an S-VLAN. Field type <SignedInteger> - a signed integer	<i>value: "no-drop"</i> Parameter indicating whether the packet must be marked as drop eligible.
[no] vlan-drop-pcp	Parameter type: <Cfm::VlanDropPcpType> Format: (pcp8p0d pcp7p1d pcp6p2d pcp5p3d <SignedInteger>) Possible values: - pcp8p0d : Priority encoding rule to be applied. - pcp7p1d : Priority encoding rule to be applied. - pcp6p2d : Priority encoding rule to be applied. - pcp5p3d : Priority encoding rule to be applied. Field type <SignedInteger> - a signed integer	<i>optional parameter with default value: "pcp8p0d"</i> Defines the Priority Code Point encoding rule used.

Command Output

Table 205.2-3 "Unicast Loopback message Management Command" Display parameters

Specific Information		
name	Type	Description
result	Parameter type: <Cfm::CfmOamResult> (test-done test-in-progress internal-failure) Possible values: - test-done : - test-in-progress : - internal-failure :	Result of the command. <i>This element is only shown in detail mode.</i>
lbr-in	Parameter type: <Counter> - 32 bit counter	Total number of valid, in-order Loopback Replies received. <i>This element is only shown in detail mode.</i>
lbr-in-ooo	Parameter type: <Counter> - 32 bit counter	The total number of valid, out-of-order Loopback Replies received. <i>This element is only shown in detail mode.</i>
lbr-bad-msdu	Parameter type: <Counter> - 32 bit counter	The total number of LBRs received whose mac_service_data_unit did not match (except for the OpCode) that of the corresponding LBM <i>This element is only shown in detail mode.</i>

205.3 CFM Multicast Loopback Management Command

Command Description

This CFM Management command is executed to initiate a Multicast Loopback message.

User Level

The command can be accessed by operators with alarm , oam , vlan privileges, and executed by operators with alarm , oam , vlan privileges.

Command Syntax

The command has the following syntax:

```
> admin cfm mclbm domain <Cfm::CfmDomainIndexType> association <Cfm::CfmMaIndexType> mep
<Cfm::MepIdType> [ no vlan-priority | vlan-priority <Vlan::Priority> ] [ no lbm-tlv-type | lbm-tlv-type
<Cfm::McLbmTlvType> ] [ no lbm-data-len | lbm-data-len <Cfm::LbmDataLenType> ] [ no lbm-data | lbm-data
<Cfm::LbmDataType> ]
```

Command Parameters

Table 205.3-1 "CFM Multicast Loopback Management Command" Resource Parameters

Resource Identifier	Type	Description
domain	Parameter type: <Cfm::CfmDomainIndexType> Format: - Maintenance Domain (MD) index - range: [1...4294967295]	Maintenance Domain Index.

Table 205.3-2 "CFM Multicast Loopback Management Command" Command Parameters

Parameter	Type	Description
association	Parameter type: <Cfm::CfmMaIndexType> Format: - Maintenance Association (MA) index. Unique within an MD - range: [1...4294967295]	<i>mandatory parameter</i> Maintenance Association Index
mep	Parameter type: <Cfm::MepIdType> Format: - MA End Point (MEP) ID. Unique within an MA - range: [1...8191]	<i>mandatory parameter</i> Maintenance Association End Point (MEP) ID. Unique within an MA
[no] vlan-priority	Parameter type: <Vlan::Priority> Format: - priority of ethernet frames - range: [0...7]	<i>optional parameter with default value: 7L</i> Priority. A 3 bit value to be used in the VLAN tag, if present in the transmitted frame. Default = 7 decimal.

Parameter	Type	Description
[no] lbm-tlv-type	Parameter type: <Cfm::McLbmTlvType> Format: (tlv-none data-tlv) Possible values: - tlv-none : no TLV - data-tlv : data TLV	<i>optional parameter with default value: "tlv-none"</i> Specifies which TLV type is to be used for LBM.
[no] lbm-data-len	Parameter type: <Cfm::LbmDataLenType> Format: - the length of the Data TLV - range: [1...1488]	<i>optional parameter with default value: 64L</i> The value specifies the length of the Data TLV. Specifying length zero implies no Data TLV will be included in LBM.
[no] lbm-data	Parameter type: <Cfm::LbmDataType> Format: - a binary string - length: 8	<i>optional parameter with default value: "00 : 00 : 00 : 00 : 00 : 00 : 00 : 00"</i> This 64 bit pattern is used repetitively to fillup Data TLV, if the Data TLV is selected to be sent. Most significant bits are used first.

Command Output

Table 205.3-3 "CFM Multicast Loopback Management Command" Display parameters

Specific Information		
name	Type	Description
reply-nr	Parameter type: <Counter> - 32 bit counter	ResultNbr. of the received LBR. <i>This element is always shown.</i>
result	Parameter type: <Cfm::CfmOamResult> (test-done test-in-progress internal-failure) Possible values: - test-done : - test-in-progress : - internal-failure :	Result of the command. <i>This element is only shown in detail mode.</i>
mac	Parameter type: <Vlan::MacAddr> - mac address (aa:bb:cc:a1:02:03) - unit: Byte - length: 6	MAC address of the peer MEP that sent the LBR message. <i>This element is always shown.</i>

205.4 CFM Linktrace management command

Command Description

This CFM Management command is executed to initiate a Linktrace message

User Level

The command can be accessed by operators with alarm , oam , vlan privileges, and executed by operators with alarm , oam , vlan privileges.

Command Syntax

The command has the following syntax:

> admin cfm ltm

205.5 Linktrace message Management Command

Command Description

This command initiates the sending of a Linktrace message.

User Level

The command can be accessed by operators with alarm , oam , vlan privileges, and executed by operators with alarm , oam , vlan privileges.

Command Syntax

The command has the following syntax:

```
> admin cfm ltm domain (domain-index) association <Cfm::CfmMaIndexType> mep <Cfm::MepIdType>
target-mac <Vlan::MacAddr> [ no vlan-priority | vlan-priority <Vlan::Priority> ] [ no ttl | ttl <Cfm::TtlLtmType> ]
[ no fdb-only-bit | fdb-only-bit <Cfm::FdbOnlyType> ]
```

Command Parameters

Table 205.5-1 "Linktrace message Management Command" Resource Parameters

Resource Identifier	Type	Description
(domain-index)	Format: - Maintenance Domain (MD) index - range: [1...4294967295]	Maintenance Domain Index. Note: This is in fact not really a resourceId, but one of the mandatory parameters.

Table 205.5-2 "Linktrace message Management Command" Command Parameters

Parameter	Type	Description
association	Parameter type: <Cfm::CfmMaIndexType> Format: - Maintenance Association (MA) index. Unique within an MD - range: [1...4294967295]	<i>mandatory parameter</i> Maintenance Association Index.
mep	Parameter type: <Cfm::MepIdType> Format: - MA End Point (MEP) ID. Unique within an MA - range: [1...8191]	<i>mandatory parameter</i> Maintenance Association End Point (MEP) ID. Unique within an MA.
target-mac	Parameter type: <Vlan::MacAddr> Format: - mac address (aa:bb:cc:a1:02:03) - unit: Byte - length: 6	<i>mandatory parameter</i> MAC address within the payload of the LTM. The destination MAC address is calculated by the system.
[no] vlan-priority	Parameter type: <Vlan::Priority> Format: - priority of ethernet frames - range: [0...7]	<i>optional parameter with default value: 7L</i> Priority. A 3 bit value to be used in the VLAN tag, if present in the transmitted frame. Default = 7

Parameter	Type	Description
[no] ttl	Parameter type: <Cfm::TtlLtmType> Format: - Range of allowed ttl values. - range: [0...255]	decimal. <i>optional parameter with default value: 64L</i> The maximum number of hops the LTM may pass. Default value is 64.
[no] fdb-only-bit	Parameter type: <Cfm::FdbOnlyType> Format: (true false) Possible values: - true : sets use-fdb-only bit within an LTM to true. - false : sets use-fdb-only bit within an LTM to false.	<i>optional parameter with default value: "true"</i> Indication to use Filtering Database.

Command Output

Table 205.5-3 "Linktrace message Management Command" Display parameters

Specific Information		
name	Type	Description
receive-order-nbr	Parameter type: <Counter> - 32 bit counter	Order number of the received LTR. <i>This element is only shown in detail mode.</i>
result	Parameter type: <Cfm::CfmOamResult> (test-done test-in-progress internal-failure) Possible values: - test-done : - test-in-progress : - internal-failure :	Result of the command. <i>This element is only shown in detail mode.</i>
orig-egress-id	Parameter type: <Cfm::EgressIdType> - a binary string - length: 8	The MEP that is originating the LTM. The low-order(highest numbered) octets contain a 48-bit IEEE MAC address unique to the system in which the MEP resides. The high-order (lowest numbered) two octets are set to zero. <i>This element is only shown in detail mode.</i>
ltm-seq-nbr	Parameter type: <Counter> - 32 bit counter	The LTM Transaction Identifier of the LTM sent. <i>This element is only shown in detail mode.</i>
nbr-unexp-ltr	Parameter type: <Counter> - 32 bit counter	The total number of unexpected LTRs received during the duration of the LTM test. <i>This element is only shown in detail mode.</i>
ttl-in-ltr	Parameter type: <Cfm::TtlLtrType> - Range of allowed ttl values. - range: [0...255]	TTL value indicated in the received LTR. <i>This element is only shown in detail mode.</i>
ltr-forwarded	Parameter type: <Cfm::LtrFwdType> (true	Indicates if a LTM was forwarded by the responding

name	Type	Description
	false) Possible values: - true : FwdYes-flag within received LTR is true. - false : FwdYes-flag within received LTR is false.	maintenance point. <i>This element is only shown in detail mode.</i>
terminal-mep	Parameter type: <Cfm::TermMepType> (true false) Possible values: - true : TerminalMEP-flag within received LTR is true. - false : TerminalMEP-flag within received LTR is false.	Indicates if a LTM reached a MEP enclosing its MA. <i>This element is only shown in detail mode.</i>
last-egress-id	Parameter type: <Cfm::EgressIdType> - a binary string - length: 8	An octet field holding the Last Egress Identifier returned in the LTR Egress Identifier TLV of the LTR. This identifier identifies the MEP Linktrace Initiator that originated, or the Linktrace Responder that forwarded, the LTM to which this LTR is the response. <i>This element is only shown in detail mode.</i>
next-egress-id	Parameter type: <Cfm::EgressIdType> - a binary string - length: 8	An octet field holding the Next Egress Identifier returned in the LTR Egress Identifier TLV of the LTR. This identifier identifies the Linktrace Responder that transmitted this LTR. <i>This element is only shown in detail mode.</i>
ltr-relay	Parameter type: <Cfm::RelayActionFieldValueType> (rly-hit rly-fdb rly-mpdb <SignedInteger>) Possible values: - rly-hit : The LTM reached an MP whose MAC address matches the target MAC address. - rly-fdb : The Egress port was determined by consulting the Filtering DB. - rly-mpdb : The Egress port was determined by consulting the MIP CCM DB. Field type <SignedInteger> - a signed integer	Value returned in the Relay Action field. <i>This element is only shown in detail mode.</i>
chassis-id-format	Parameter type: <Cfm::LldpChassisIdSubtype> (not-applic chassis-component interface-alias port-component mac-address network-address interface-name local <SignedInteger>) Possible values: - not-applic : not applicable - chassis-component : Reference IETF RFC 2737 - interface-alias : Reference IETF RFC 2863	Specifies the format of the Chassis ID returned in the Sender ID TLV of the LTR, if present. <i>This element is only shown in detail mode.</i>

205 CFM Management Commands.

name	Type	Description
	- port-component : Reference IETF RFC 2737 - mac-address : - network-address : - interface-name : Reference IETF RFC 2863 - local : An alph-numeric string. Field type <SignedInteger> - a signed integer	
chassis-id	Parameter type: <Cfm::LldpChassisIdType> - a variable length octet string 0..16 - length: x<=16	The Chassis ID returned in the Sender ID TLV of the LTR, if present. <i>This element is only shown in detail mode.</i>
mgmt-addr-domain	Parameter type: <Object> - an object identifier	The TDomain that identifies the type and format of the address of the SNMP agent of the system transmitting the LTR. <i>This element is only shown in detail mode.</i>
mgmt-addr	Parameter type: <Cfm::MgmtAddrType> - a variable length octet string 0..50 - length: x<=50	<i>This element is only shown in detail mode.</i>
ltr-ingress	Parameter type: <Cfm::IngressActionFieldValueType> (ingress-no-tlv ingress-ok ingress-down ingress-blocked ingress-vid <SignedInteger>) Possible values: - ingress-no-tlv : There is no Reply Ingress TLV. - ingress-ok : The target data frame would be passed through to the MAC Relay Entity. - ingress-down : The bridge Port's MAC_Operational parameter is false - ingress-blocked : The target data frame would not be forwarded if received on this port. - ingress-vid : The ingress port is not in the member set of the LTM's VID. Field type <SignedInteger> - a signed integer	The value returned in the Ingress Action Field of the Reply Ingress TLV of the LTR. <i>This element is only shown in detail mode.</i>
ingr-mac	Parameter type: <Vlan::MacAddr> - mac address (aa:bb:cc:a1:02:03) - unit: Byte - length: 6	MAC address returned in the ingress MAC address field of the Reply ingress TLV of the LTR. <i>This element is only shown in detail mode.</i>
ingr-portid-stype	Parameter type: <Cfm::LldpPortIdSubtype> (none interface-alias port-component mac-address network-address interface-name agent-circuit-id local <SignedInteger>) Possible values: - none :	Format of the Ingress port ID. <i>This element is only shown in detail mode.</i>

name	Type	Description
	- interface-alias : - port-component : - mac-address : - network-address : - interface-name : - agent-circuit-id : - local : Field type <SignedInteger> - a signed integer	
ingr-portid	Parameter type: <Cfm::LldpPortIdType> - a variable length octet string 0..16 - length: x<=16	The Ingress port ID. <i>This element is only shown in detail mode.</i>
ltr-egress	Parameter type: <Cfm::EgressActionFieldValueType> (egress-no-tlv egress-ok egress-down egress-blocked egress-vid <SignedInteger>) Possible values: - egress-no-tlv : There is no Reply Egress TLV. - egress-ok : The target data frame would be forwarded. - egress-down : The egress port can be identified, but that bridge Port's MAC_Operational parameter is false - egress-blocked : The target data frame would not pass through the egress port. - egress-vid : The egress port can be identified, but the bridge port is not in the LTM's VID member set. Field type <SignedInteger> - a signed integer	The value returned in the Egress Action Field of the Reply Egress TLV of the LTR. <i>This element is only shown in detail mode.</i>
egr-mac	Parameter type: <Vlan::MacAddr> - mac address (aa:bb:cc:a1:02:03) - unit: Byte - length: 6	MAC address returned in the egress MAC address field of the Reply egress TLV of the LTR. <i>This element is only shown in detail mode.</i>
egr-portid-type	Parameter type: <Cfm::LldpPortIdSubtype> (none interface-alias port-component mac-address network-address interface-name agent-circuit-id local <SignedInteger>) Possible values: - none : - interface-alias : - port-component : - mac-address : - network-address : - interface-name : - agent-circuit-id : - local : Field type <SignedInteger> - a signed integer	Format of the Egress port ID. <i>This element is only shown in detail mode.</i>
egr-portid	Parameter type: <Cfm::LldpPortIdType>	The Egress port ID.

205 CFM Management Commands.

name	Type	Description
	- a variable length octet string 0..16 - length: x<=16	<i>This element is only shown in detail mode.</i>
org-spec-tlv	Parameter type: <Cfm::OrgSpecTlvType> - a variable length octet string 0..7 - length: x<=7	All Orginization specific TLVs returned in the LTR, if any. <i>This element is only shown in detail mode.</i>

205.6 CFM Single Ended Synthetic Loss Measurement message Management Command

Command Description

This command is executed to initiate a test of Single Ended Synthetic Loss Measurement messages.

User Level

The command can be accessed by operators with alarm , oam , vlan privileges, and executed by operators with alarm , oam , vlan privileges.

Command Syntax

The command has the following syntax:

```
> admin cfm single-ended-slm
```

205.7 Single Ended Synthetic Loss Measurement message Management Command

Command Description

This command initiates the test of Single Ended Synthetic Loss Measurement messages.

A number of Single Ended Synthetic Loss Measurement messages can be requested to be send from a specified MEP towards a specified destination MAC address.

User Level

The command can be accessed by operators with alarm , oam , vlan privileges, and executed by operators with alarm , oam , vlan privileges.

Command Syntax

The command has the following syntax:

```
> admin cfm single-ended-slm domain (domain) association <Cfm::CfmMaIndexType> mep <Cfm::MepIdType>
target-mac <Vlan::MacAddr> [ no send-count | send-count <Cfm::SlmSendCountType> ] [ no size | size
<Cfm::SlmPacketSizeType> ] [ no timeout | timeout <Cfm::SlmTimeoutType> ] [ no interval | interval
<Cfm::SlmIntervalType> ] [ no priority | priority <Vlan::Priority> ]
```

Command Parameters

Table 205.7-1 "Single Ended Synthetic Loss Measurement message Management Command" Resource Parameters

Resource Identifier	Type	Description
(domain)	Format: - Maintenance Domain (MD) index - range: [1...4294967295]	Maintenance Domain Index.
association	Parameter type: <Cfm::CfmMaIndexType> Format: - Maintenance Association (MA) index. Unique within an MD - range: [1...4294967295]	Maintenance Association Index.
mep	Parameter type: <Cfm::MepIdType> Format: - MA End Point (MEP) ID. Unique within an MA - range: [1...8191]	Maintenance Association End Point (MEP) ID. Unique within an MA.
target-mac	Parameter type: <Vlan::MacAddr> Format: - mac address (aa:bb:cc:a1:02:03) - unit: Byte - length: 6	The MAC address for the OAM target: a unicast destination MAC address used in the SLM.

Table 205.7-2 "Single Ended Synthetic Loss Measurement message Management Command"

Command Parameters

Parameter	Type	Description
[no] send-count	Parameter type: <Cfm::SlmSendCountType> Format: - The number of Synthetic Loss Measurement messages to be transmitted. - range: [1...100]	<i>optional parameter with default value: 1L</i> The number of SLM packets to be sent. Allowed range : 1 to 100.
[no] size	Parameter type: <Cfm::SlmPacketSizeType> Format: - The Data TLV size of Synthetic Loss Measurement messages to be transmitted. - range: [0...1500]	<i>optional parameter with default value: 0L</i> Size of data TLV. Allowed range : 0 to 1500.
[no] timeout	Parameter type: <Cfm::SlmTimeoutType> Format: - The timeout for Synthetic Loss Measurement messages to be transmitted. - range: [5...10]	<i>optional parameter with default value: 5L</i> The timeout in seconds to wait for each SLR. Allowed range : 5 to 10.
[no] interval	Parameter type: <Cfm::SlmIntervalType> Format: - The interval for Synthetic Loss Measurement messages to be transmitted. - range: [1...10]	<i>optional parameter with default value: 5L</i> The interval in seconds between each SLM packet to be sent. Allowed range : 1 to 10.
[no] priority	Parameter type: <Vlan::Priority> Format: - priority of ethernet frames - range: [0...7]	<i>optional parameter with default value: 7L</i> Priority. A 3 bit value to be used in the VLAN tag. Allowed range : 0 to 7.

Command Output

Table 205.7-3 "Single Ended Synthetic Loss Measurement message Management Command"
Display parameters

Specific Information		
name	Type	Description
remote-mep	Parameter type: <Cfm::MepIdType> - MA End Point (MEP) ID. Unique within an MA - range: [0,1...8191,65535]	Remote Maintenance Association End Point Id. <i>This element is always shown.</i>
slm-transmitted	Parameter type: <Counter> - 32 bit counter	The total number of SLM messages transmitted. <i>This element is always shown.</i>
slr-received	Parameter type: <Counter> - 32 bit counter	The total number of SLR messages received. <i>This element is always shown.</i>
in-loss	Parameter type: <Cfm::SignedIntType> - Signed Integer. - range: [-2147483647...2147483647L]	The total number of Synthetic Loss Reply messages transmitted from the Remote MEP, but not received at the Local MEP. <i>This element is always shown.</i>
out-loss	Parameter type: <Cfm::SignedIntType> - Signed Integer. - range: [-2147483647...2147483647L]	The total number of Synthetic Loss Measurement messages transmitted from the Local MEP, but not received at the Remote MEP. <i>This element is always shown.</i>
un-ack	Parameter type: <Cfm::SignedIntType> - Signed Integer.	The total number of unacknowledged Synthetic Loss

205 CFM Management Commands.

name	Type	Description
	- range: [-2147483647...2147483647L]	Measurement messages. <i>This element is always shown.</i>
test-id	Parameter type: <Cfm::SlmOnDemandTestIdType> - The Test Id for On Demand Synthetic Loss Measurement messages. - range: [0...4294967295]	The Test Id for On Demand Synthetic Loss Measurement messages. <i>This element is always shown.</i>

206- Protection Group Management Commands

206.1 Protection Group Management Command Tree	206-7200
206.2 Protection Group Switchover Management Command	206-7201

206.1 Protection Group Management Command Tree

Description

This chapter gives an overview of nodes that are handled by "Protection Group Management Commands".

Command Tree

```
----admin
  ----port-protection
    - (protection-group)
    - activate
```

206.2 Protection Group Switchover Management Command

Command Description

This command allows the operator to switch over from one port to the other port in a protection group.

User Level

The command can be accessed by operators with equipment privileges, and executed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

```
> admin port-protection (protection-group) activate <RedPort::ActivePortIndex>
```

Command Parameters

Table 206.2-1 "Protection Group Switchover Management Command" Resource Parameters

Resource Identifier	Type	Description
(protection-group)	Format: (pon : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> chpair : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::ChannelPairId>) Possible values: - pon : pon-aid - chpair : chpair-aid Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Eqpt::ChannelPairId> - the channel pair identifier	the protection group identifier - namely the port identifier of the first port in the group

Table 206.2-2 "Protection Group Switchover Management Command" Command Parameters

Parameter	Type	Description
activate	Parameter type: <RedPort::ActivePortIndex> Format: (pon : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId>	<i>optional parameter</i> the port identifier of the desired port to switch over in the protection group

206 Protection Group Management Commands

Parameter	Type	Description
	no-interface chpair : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::ChannelPairId>) Possible values: - pon : pon-aid - chpair : chpair-aid - no-interface : no interface Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Eqpt::ChannelPairId> - the channel pair identifier	

207- Efm Oam Management Command

207.1 Efm Oam Management Command Tree	207-7204
207.2 Efm Oam Interface Management Command	207-7205

207.1 Efm Oam Management Command Tree

Description

This chapter gives an overview of nodes that are handled by "Efm Oam Management Command".

Command Tree

```
----admin
  ----efm-oam
    ----interface
      - (interface)
      - (loopback-action)
      X (traffgen-action)
      - parser-action
      - loopback-timeout
```

207.2 Efm Oam Interface Management Command

Command Description

This management command allows next actions: - Enable / disable efm oam remote loopback on a peer device via specified interface. - Start / stop internal traffic generator on specified interface in remote loopback. - Parser Action: Forward / discard the looped back packets. - Loopback Timeout: Timeout for clearing the remote loopback configuration while the remote loopback configuration is enabled. Note: loopback-action is a mandatory parameter.

User Level

The command can be accessed by operators with transport privileges, and executed by operators with transport privileges.

Command Syntax

The command has the following syntax:

```
> admin efm-oam interface (interface) (loopback-action) [ (traffgen-action) ] [ parser-action <Ether::ParserAction> ] [ loopback-timeout <Ether::LoopbackTimeout> ]
```

Command Parameters

Table 207.2-1 "Efm Oam Interface Management Command" Resource Parameters

Resource Identifier	Type	Description
(interface)	Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number	identification of EFM port / Ethernet port

Table 207.2-2 "Efm Oam Interface Management Command" Command Parameters

Parameter	Type	Description
(loopback-action)	Format: (enable-loopback disable-loopback) Possible values: - enable-loopback : initiate loopback on specified itf - disable-loopback : disable loopback on specified itf	<i>optional parameter</i> enable or disable efm oam remote loopback, this is a mandatory parameter.
(traffgen-action)	Format: (start-traff-gen stop-traff-gen)	<i>obsolete parameter that will be ignored</i> stop or start the internal traffic

207 Efm Oam Management Command

Parameter	Type	Description
	Possible values: - start-traff-gen : Starts the internal traffic generator on specified itf - stop-traff-gen : Stops the internal traffic generator on specified itf	generator
parser-action	Parameter type: <Ether::ParserAction> Format: (discard forward) Possible values: - discard : discard looped back packets - forward : forward looped back packets	<i>optional parameter</i> Loopback parser action
loopback-timeout	Parameter type: <Ether::LoopbackTimeout> Format: - A timeout value expressed in seconds - unit: seconds - range: [0...3600]	<i>optional parameter</i> Timeout value for clearing Remote Loopback configuration while the remote loopback configuration is enabled. Default value: 0 - means no timeout configured for clearing the remote loopback configuration.

208- Epon Management Command

208.1 Epon Management Command Tree	208-7208
208.2 Epon Ont Ethernet Reautodetect Management Command	208-7209

208.1 Epon Management Command Tree

Description

This chapter gives an overview of nodes that are handled by "Epon Management Command".

Command Tree

```
----admin
  ----epon
    ----diagnostic
      - (pon-idx)
      - mode
```

208.2 Epon Ont Ethernet Reautodetect Management Command

Command Description

This command allows the operator to restart auto negotiation of an Ethernet port.

User Level

The command can be accessed by operators with equipment privileges, and executed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

```
> admin epon diagnostic (pon-idx) [ mode <Epon::mode> ]
```

Command Parameters

Table 208.2-1 "Epon Ont Ethernet Reautodetect Management Command" Resource Parameters

Resource Identifier	Type	Description
(pon-idx)	Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier	identification of pon

Table 208.2-2 "Epon Ont Ethernet Reautodetect Management Command" Command Parameters

Parameter	Type	Description
mode	Parameter type: <Epon::mode> Format: (stop onoff pattern) Possible values: - stop : Stop PON Rogue test - onoff : Initiate ON-OFF TEST PON Rogue Test - pattern : Initiate PATTERN TEST PON Rogue Test	<i>optional parameter</i> enable or disable pon rogue test diagnostic

209- Iphost Management Command.

209.1 Iphost Management Command. Tree
209.2 Iphost ping test Management Command

209-7211
209-7212

209.1 Iphost Management Command. Tree

Description

This chapter gives an overview of nodes that are handled by "Iphost Management Command."

Command Tree

```
----admin
  ----iphost
    ----ping
      - (index)
      - dest-ip
      - [no] count
```

209.2 Iphost ping test Management Command

Command Description

This command allows the operator to manage the iphost ping test

User Level

The command can be accessed by operators with sip,megaco,vlan privileges, and executed by operators with sip,megaco,vlan privileges.

Command Syntax

The command has the following syntax:

```
> admin iphost ping (index) dest-ip <Gpon::destIp> [ no count | count <Gpon::PingCount> ]
```

Command Parameters

Table 209.2-1 "Iphost ping test Management Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: (ont : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Gpon::IpHostID> ont:ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / <Ng2::IpHostID>) Possible values: - ont:ng2 : ngpon2 ont - ont : ont Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Eqpt::OntId> - the ONT identifier Field type <Eqpt::ChannelGroupId> - the channel group identifier Field type <Eqpt::SubChannelGroupId> - the subchannel group identifier Field type <Eqpt::Ng2OntId> - the NG2 ONT identifier Field type <Gpon::IpHostID> - iphost id Field type <Ng2::IpHostID>	an unique index related to the ping test entry

Resource Identifier	Type	Description
	- iphost id (ngpon2)	

Table 209.2-2 "Iphost ping test Management Command" Command Parameters

Parameter	Type	Description
dest-ip	Parameter type: <Gpon::destIp> Format: (explicit : <Ip::V4Address> hostname : <Gpon::hostname> uri-prof : name : <AsamProfileName> uri-prof : <Gpon:UriProfilePtr>) Possible values: - explicit : explicit ip of destination,example:10.0.0.1 - hostname : hostname of destination,example:www.google.com - uri-prof : uri profile related to destination Field type <Ip::V4Address> - IPv4-address Field type <Gpon::hostname> - host name address - length: x<=255 Possible values: - name : uri profile name Field type <Gpon:UriProfilePtr> - Index of the URI profile that contains the IP address of the server - range: [0...100] Data driven field type Possible values are depending on the actual configuration and software. The currently allowed values can be shown with online-help.	<i>mandatory parameter</i> destination ip of ping test
[no] count	Parameter type: <Gpon::PingCount> Format: - ping count - range: [0...5]	<i>optional parameter with default value: 0</i> The number of pings to attempt

Command Output

Table 209.2-3 "Iphost ping test Management Command" Display parameters

Specific Information		
name	Type	Description
ip-addr	Parameter type: <L2cp::InetAddress> - IPv4-address	The IP address of the target host be pinged <i>This element is always shown.</i>
count-tx	Parameter type: <Gpon::PingCount> - ping count - range: [0...5]	The number of pings attempted <i>This element is always shown.</i>
count-rx	Parameter type: <Gpon::PingCount> - ping count - range: [0...5]	The number of pings which received reply <i>This element is always shown.</i>
delay-min	Parameter type: <Gpon::PingDelay> - ping count - range: [0...65535]	The minimum delay of the received responses <i>This element is always shown.</i>
delay-max	Parameter type: <Gpon::PingDelay> - ping count - range: [0...65535]	The maximum delay of the received responses <i>This element is always shown.</i>
exit-status	Parameter type: <Gpon::TestCmd>	Completion status of the

209 Iphost Management Command.

name	Type	Description
	(initiate inprogress noanswer alive norun rejected noparse) Possible values: - initiate : Initiate test - inprogress : Test is in progress - noanswer : Destination did not answe - alive : Destination is alive - norun : OLT did not send command to ONT - rejected : ONT rejected command for unknown reason - noparse : ONT command parse error	command <i>This element is always shown.</i>

210- LineTest Management Commands

210.1 LineTest Management Command Tree	210-7216
210.2 MELT reset Status Command	210-7217
210.3 MELT Selftest Status Command	210-7218

210.1 LineTest Management Command Tree

Description

This chapter gives an overview of nodes that are handled by "LineTest Management Commands".

Command Tree

```
----admin
  ----linetest
    ----single
      - (if-index)
      - melt-reset
    ----melt-selftest
      - (self-test-status)
```

210.2 MELT reset Status Command

Command Description

This command is to triggers the reset operation on MELT board.

User Level

The command can be accessed by operators with sip , xdsl privileges, and executed by operators with sip , xdsl privileges.

Command Syntax

The command has the following syntax:

```
> admin linetest single (if-index) melt-reset <LineTest::ResetStatus>
```

Command Parameters

Table 210.2-1 "MELT reset Status Command" Resource Parameters

Resource Identifier	Type	Description
(if-index)	Format: lt : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> Possible values: - lt : lt-slot Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number	interface index of the port

Table 210.2-2 "MELT reset Status Command" Command Parameters

Parameter	Type	Description
melt-reset	Parameter type: <LineTest::ResetStatus> Format: resetstart Possible values: - resetstart : the MELT reset operation is triggered	<i>optional parameter</i> Trigger the reset operation on the MELT board.

210.3 MELT Selftest Status Command

Command Description

This command is to triggers the self test operation on MELT board.

User Level

The command can be accessed by operators with sip , xdsl privileges, and executed by operators with sip , xdsl privileges.

Command Syntax

The command has the following syntax:

> admin linetest single (if-index) melt-selftest (self-test-status)

Command Parameters

Table 210.3-1 "MELT Selftest Status Command" Resource Parameters

Resource Identifier	Type	Description
(if-index)	Format: lt : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> Possible values: - lt : lt-slot Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number	interface index of the port

Table 210.3-2 "MELT Selftest Status Command" Command Parameters

Parameter	Type	Description
(self-test-status)	Format: teststart Possible values: - teststart : test start state	<i>optional parameter</i> Trigger the selftest operation on the MELT board.

211- *BER LineTest Configuration Commands*

211.1 BER LineTest Configuration Command Tree
211.2 E1 BER test command

211-7220
211-7221

211.1 BER LineTest Configuration Command Tree

Description

This chapter gives an overview of nodes that are handled by "BER LineTest Configuration Commands".

Command Tree

```
----admin
  ----e1
    ----diagnos-test
      - (if-index)
      - [no] ber-test
      - [no] ber-testpattern
      - [no] ber-interval
      - [no] loop-back
```

211.2 E1 BER test command

Command Description

This command is to trigger the BER test on e1 interface.

User Level

The command can be accessed by operators with xdsl privileges, and executed by operators with xdsl privileges.

Command Syntax

The command has the following syntax:

```
> admin e1 diagnos-test (if-index) [ no ber-test | ber-test <E1::BERTest> ] [ no ber-testpattern | ber-testpattern
<E1::BERTestPattern> ] [ no ber-interval | ber-interval <E1::BERInterval> ] [ no loop-back | loop-back
<E1::LoopBackType> ]
```

Command Parameters

Table 211.2-1 "E1 BER test command" Resource Parameters

Resource Identifier	Type	Description
(if-index)	Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number	interface index of the port

Table 211.2-2 "E1 BER test command" Command Parameters

Parameter	Type	Description
[no] ber-test	Parameter type: <E1::BERTest> Format: (disable enable abort) Possible values: - disable : Disable BER test - enable : Enable BER test - abort : Abort BER test	<i>optional parameter with default value: "disable"</i> Trigger the BER test on e1 interface
[no] ber-testpattern	Parameter type: <E1::BERTestPattern> Format: (framed-twopow11 framed-twopow15	<i>optional parameter with default value: "none"</i> BER testpattern to be used for performing BER test

211 BER LineTest Configuration Commands

Parameter	Type	Description
	unframed-twopow11 unframed-twopow15 none) Possible values: - framed-twopow11 : Framed Pseudo-random repeating test pattern with 2 ¹¹ bits - framed-twopow15 : Framed Pseudo-random repeating test pattern with 2 ¹⁵ bits - unframed-twopow11 : Unframed Pseudo-random repeating test pattern with 2 ¹¹ bits - unframed-twopow15 : Unframed Pseudo-random repeating test pattern with 2 ¹⁵ bits - none : No-Pattern	
[no] ber-interval	Parameter type: <E1::BERInterval> Format: - Maximum time allowed to perform BER test - range: [0...4095]	<i>optional parameter with default value: 0</i> Maximum time allowed for BER test
[no] loop-back	Parameter type: <E1::LoopBackType> Format: (no-loop local-payload remote-payload remote-line local-line) Possible values: - no-loop : no loopback - local-payload : LOCAL-Payload - remote-payload : Remote-payload - remote-line : Remote-line - local-line : Local-Line	<i>optional parameter with default value: "no-loop"</i> Trigger the LoopBack test on e1 interface

212- Dual-Parenting Protection Group Management Commands

212.1 Dual-Parenting Protection Group Management Command Tree	212-7224
212.2 Dual-Parenting Protection Group Management Command	212-7225

212.1 Dual-Parenting Protection Group Management Command Tree

Description

This chapter gives an overview of nodes that are handled by "Dual-Parenting Protection Group Management Commands".

Command Tree

```
----admin
  ----dual-parenting
```

212.2 Dual-Parenting Protection Group Management Command

Command Description

This command allows the operator to manage dual-parenting protection group.

User Level

The command can be accessed by operators with equipment privileges, and executed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

> admin dual-parenting

213- Dual-Parenting Protection Group Switchover Management Commands

213.1 Dual-Parenting Protection Group Switchover Management Command Tree	213-7227
213.2 Dual-Parenting Protection Group Switchover Management Command	213-7228

213.1 Dual-Parenting Protection Group Switchover Management Command Tree

Description

This chapter gives an overview of nodes that are handled by "Dual-Parenting Protection Group Switchover Management Commands".

Command Tree

```
----admin
  ----dual-parenting
    ----protection-group
      - (local-port)
      - switchover
```

213.2 Dual-Parenting Protection Group Switchover Management Command

Command Description

This command allows the operator to switch over in a dual-parenting protection group.

User Level

The command can be accessed by operators with equipment privileges, and executed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

```
> admin dual-parenting protection-group (local-port) switchover <Equipm::DualParentProtGrpSwitchCommand>
```

Command Parameters

Table 213.2-1 "Dual-Parenting Protection Group Switchover Management Command" Resource Parameters

Resource Identifier	Type	Description
(local-port)	Format: (pon : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> chpair : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::ChannelPairId>) Possible values: - pon : pon-aid - chpair : chpair-aid Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Eqpt::ChannelPairId> - the channel pair identifier	the local port identifier of the dual-parenting in the protection group

Table 213.2-2 "Dual-Parenting Protection Group Switchover Management Command" Command Parameters

Parameter	Type	Description
switchover	Parameter <Equipm::DualParentProtGrpSwitchCommand> type:	<i>optional parameter</i> run switchover command

213 Dual-Parenting Protection Group Switchover Management Commands

Parameter	Type	Description
	Format: forced-switchover Possible values: - forced-switchover : forced switch over	

214- *Equipment Management Commands*

214.1 Equipment Management Command Tree	214-7231
214.2 Equipment Management Command	214-7232
214.3 Slot Management Command	214-7233
214.4 Slot Management Command	214-7235

214.1 Equipment Management Command Tree

Description

This chapter gives an overview of nodes that are handled by "Equipment Management Commands".

Command Tree

- admin**
 - equipment**
 - (prepare-sys-shutdown)
 - reboot-isam
 - slot**
 - **(index)**
 - reboot
 - [no] overrule
 - (clr-restart-cnt-per-lt)
 - applique**
 - **(index)**
 - reboot

214.2 Equipment Management Command

Command Description

This command allows the operator to manage the node: prepare the system for shutdown, reset the node or reset the SHub/IHub.

Note: An attempt to reset the SHub/IHub will be rejected.

User Level

The command can be accessed by operators with equipment privileges, and executed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

```
> admin equipment [ (prepare-sys-shutdown) ] [ reboot-isam <Equipm::SystemRestart> ]
```

Command Parameters

Table 214.2-2 "Equipment Management Command" Command Parameters

Parameter	Type	Description
(prepare-sys-shutdown)	Format: prepare-sys-shutdown Possible values: - prepare-sys-shutdown : prepare the system for shutdown	<i>optional parameter</i> prepare the system for shutdown
reboot-isam	Parameter type: <Equipm::SystemRestart> Format: (with-self-test without-self-test hot-restart) Possible values: - with-self-test : restart with selftest - without-self-test : restart without selftest - hot-restart : reboot, but don't touch the hardware	<i>optional parameter</i> reboot the full isam (with xhub if any)

214.3 Slot Management Command

Command Description

This command allows the operator to manage a slot and the units in the slot.

User Level

The command can be accessed by operators with equipment privileges, and executed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

```
> admin equipment slot (index) [ reboot <Equipm::BoardRestart> ] [ [ no ] overrule ] [ (clr-restart-cnt-per-lt) ]
```

Command Parameters

Table 214.3-1 "Slot Management Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: (lt : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> nt-a nt-b nt acu : <Eqpt::RackId> / <Eqpt::ShelfId> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::EqSlotId> ext-a : <Eqpt::RackId> / <Eqpt::ShelfId> ext-b : <Eqpt::RackId> / <Eqpt::ShelfId> ctrl : <Eqpt::RackId> / <Eqpt::ShelfId> vlt : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::VirtualSlotId>) Possible values: - lt : lt-slot - vlt : virtual LT slot (VVPS board can only be planned at NANT-E / FANT-F) - nt-a : nt-a slot - nt-b : nt-b slot - nt : nt slot - ext-a : nt-a slot in an extension shelf - ext-b : nt-b slot in an extension shelf - acu : acu slot - ctrl : ctrl-slot Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId>	the identification of the slot

Resource Identifier	Type	Description
	- the LT slot number Field type <Eqpt::VirtualSlotId> - the virtual LT slot number Field type <Eqpt::EqSlotId> - the equipment slot number	

Table 214.3-2 "Slot Management Command" Command Parameters

Parameter	Type	Description
reboot	Parameter type: <Equipm::BoardRestart> Format: (with-selftest without-selftest hot-restart) Possible values: - with-selftest : reboot the board with self test - without-selftest : reboot the board without self test - hot-restart : reboot but don't touch the hardware (not for LSM and Applique)	<i>optional parameter</i> reboot the card in the slot
[no] overrule	Parameter type: boolean	<i>optional parameter</i> overrule the software on this board
(clr-restart-cnt-per-lt)	Format: clr-restart-cnt-per-lt Possible values: - clr-restart-cnt-per-lt: clear restart counter per LT	<i>optional parameter</i> clear the restart counter per LT

214.4 Slot Management Command

Command Description

This command allows the operator to manage a slot and the units in the slot.

User Level

The command can be accessed by operators with equipment privileges, and executed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

```
> admin equipment applique (index) [ reboot <Equipm::BoardRestart> ]
```

Command Parameters

Table 214.4-1 "Slot Management Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: (iont : <Eqpt::RackId> / <Eqpt::ShelfId> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::AppliqueSlotId> lp : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::LtAppliqueSlotId> ntio-1 ntio-2) Possible values: - iont : an nt applique slot - lp : an lt applique slot - ntio-1 : an nt applique slot in a single or multiple-ntio-shelf - ntio-2 : an nt applique slot in a multiple-ntio-shelf Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::AppliqueSlotId> - the applique slot number Field type <Eqpt::LtAppliqueSlotId> - the LT Applique slot number	the identification of the applique

Table 214.4-2 "Slot Management Command" Command Parameters

Parameter	Type	Description
reboot	Parameter type: <Equipm::BoardRestart> Format: (with-selftest without-selftest	<i>optional parameter</i> reboot the card in the applique

214 Equipment Management Commands

Parameter	Type	Description
	hot-restart) Possible values: - with-selftest : reboot the board with self test - without-selftest : reboot the board without self test - hot-restart : reboot but don't touch the hardware (not for LSM and Applique)	

215- ONT Management Command

215.1 ONT Management Command Tree	215-7238
215.2 ONT Interface Management Command	215-7239
215.3 ONT Card Management Command	215-7241
215.4 ONT Software Control Management Command	215-7243
215.5 ONT Software Version Management Command	215-7244
215.6 ONT Data Store Management Command	215-7245
215.7 ONT Reboot via SN Management Command	215-7247

215.1 ONT Management Command Tree

Description

This chapter gives an overview of nodes that are handled by "ONT Management Command".

Command Tree

```
----admin
  ----equipment
    ----ont
      ----interface
        - (index)
        - (self-test)
        - reboot
        - activate-chpair
        - chpair-role-exch
        - optitrans-disable-time
      ----slot
        - (ont-slot-idx)
        - (self-test)
      ----sw-ctrl
        - (sw-ctrl-idx)
        - (revert-sw-ver)
      ----sw-version
        - delete-version
      ----data-store
        - (index)
        - (force)
      ----sernum
        - (sernum)
        - reboot
```


215.2 ONT Interface Management Command

Command Description

This command initiate the self-test run on ont. When the test is finished, a pass/fail result is reported.

Also, this command can be used to set the target channel-pair manually for ngpon2 ont

User Level

The command can be accessed by operators with equipment privileges, and executed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

```
> admin equipment ont interface (index) [ (self-test) ] [ reboot <Gpon::OntRestart> ] [ activate-chpair
<Ng2::ChannelPairIndexOrZero> ] [ chpair-role-exch <Ng2::ChPairRoleExch> ] [ optitrans-disable-time
<Gpon::DisOpticalTransTime> ]
```

Command Parameters

Table 215.2-1 "ONT Interface Management Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> ng2 : <Ng2::ChannelGroup> / <Ng2::SubchannelGroup> / <Ng2::OntId>) Possible values: - ng2 : ngpon2 style identification Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Ng2::ChannelGroup> - channel group number Field type <Ng2::SubchannelGroup> - subchannel group number Field type <Eqpt::OntId> - the ONT identifier Field type <Ng2::OntId> - the ONT identifier	identification of ont

Table 215.2-2 "ONT Interface Management Command" Command Parameters

215 ONT Management Command

Parameter	Type	Description
(self-test)	Format: self-test Possible values: - self-test : initiate self-test	<i>optional parameter</i> runs the self-test on the ont
reboot	Parameter type: <Gpon::OntRestart> Format: (with-active-image via-ploam) Possible values: - with-active-image : reboot with currently active software image - via-ploam : reboot via ploam	<i>optional parameter</i> reboot the ont
activate-chpair	Parameter type: <Ng2::ChannelPairIndexOrZero> Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::ChannelPairId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::ChannelPairId> - the channel pair identifier	<i>optional parameter</i> channel-pair on which ngpon2 ont shall carry service
chpair-role-exch	Parameter type: <Ng2::ChPairRoleExch> Format: (no-action pref-with-altpref pref-with-prot) Possible values: - no-action : no action - pref-with-altpref : exchange roles of pref-channel-pair with alt-pref-ch-pair - pref-with-prot : exchange roles of pref-channel-pair with prot-channel-pair	<i>optional parameter</i> exchange roles between two channel-pairs
optitrans-disable-time	Parameter type: <Gpon::DisOpticalTransTime> Format: (permanently <Gpon::DisOpticalTransTime>) Possible values: - permanently : permanently : turn off optical transceiver forever Field type <Gpon::DisOpticalTransTime> - the specified time for OLT to command ONU to disable its own optical transceiver - unit: sec - range: [1...65535]	<i>optional parameter</i> OLT command ONU to disable its own optical transceiver for the specified time

215.3 ONT Card Management Command

Command Description

This command run a self-test on an ont pluggable card. when the test is finished, a pass/fail result is reported.

User Level

The command can be accessed by operators with equipment privileges, and executed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

```
> admin equipment ont slot (ont-slot-idx) [ (self-test) ]
```

Command Parameters

Table 215.3-1 "ONT Card Management Command" Resource Parameters

Resource Identifier	Type	Description
(ont-slot-idx)	Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Gpon::OntSlotId> ng2 : <Ng2::ChannelGroup> / <Ng2::SubchannelGroup> / <Ng2::OntId> / <Gpon::OntSlotId>) Possible values: - ng2 : ngpon2 style identification Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Ng2::ChannelGroup> - channel group number Field type <Ng2::SubchannelGroup> - subchannel group number Field type <Eqpt::OntId> - the ONT identifier Field type <Ng2::OntId> - the ONT identifier Field type <Gpon::OntSlotId> - Gpon Ont Slot - range: [1...14]	current operational parameters for the ont

Table 215.3-2 "ONT Card Management Command" Command Parameters

215 ONT Management Command

Parameter	Type	Description
(self-test)	Format: self-test Possible values: - self-test : initiate self-test	<i>optional parameter</i> runs the self-test on the ont card

215.4 ONT Software Control Management Command

Command Description

This command restores an automatic ont software download of a planned software version to the previous planned software version.

User Level

The command can be accessed by operators with equipment privileges, and executed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

```
> admin equipment ont sw-ctrl (sw-ctrl-idx) (revert-sw-ver)
```

Command Parameters

Table 215.4-1 "ONT Software Control Management Command" Resource Parameters

Resource Identifier	Type	Description
(sw-ctrl-idx)	Format: - ont software control table index - range: [1...250]	ont software control table index

Table 215.4-2 "ONT Software Control Management Command" Command Parameters

Parameter	Type	Description
(revert-sw-ver)	Format: revert-sw-ver Possible values: - revert-sw-ver : revert software version	<i>mandatory parameter</i> revert ont software version in the control table

215.5 ONT Software Version Management Command

Command Description

This command sets the ont software version that a manager wants deleted from the nt file system.

User Level

The command can be accessed by operators with equipment privileges, and executed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

```
> admin equipment ont sw-version [ delete-version <Gpon::OntVersion> ]
```

Command Parameters

Table 215.5-2 "ONT Software Version Management Command" Command Parameters

Parameter	Type	Description
delete-version	Parameter type: <Gpon::OntVersion> Format: - the version number of a card - length: x<=14	<i>optional parameter</i> specify an ont software version that a manager wants deleted from the nt file system

Command Output

Table 215.5-3 "ONT Software Version Management Command" Display parameters

Specific Information		
name	Type	Description
status	Parameter type: <Gpon::OntVerStatus> (unknown in-progress success failed) Possible values: - unknown : Command has never been issued - in-progress : deletion in progress - success : file successfully deleted - failed : unable to delete file	ont software version delete status. <i>This element is always shown.</i>

215.6 ONT Data Store Management Command

Command Description

This command forces an ont to save its data in flash memory.

User Level

The command can be accessed by operators with equipment privileges, and executed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

> admin equipment ont data-store (index) (force)

Command Parameters

Table 215.6-1 "ONT Data Store Management Command" Resource Parameters

Resource Identifier	Type	Description
(index)	Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> ng2 : <Ng2::ChannelGroup> / <Ng2::SubchannelGroup> / <Ng2::OntId>) Possible values: - ng2 : ngpon2 style identification Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Ng2::ChannelGroup> - channel group number Field type <Ng2::SubchannelGroup> - subchannel group number Field type <Eqpt::OntId> - the ONT identifier Field type <Ng2::OntId> - the ONT identifier	identification of ont

Table 215.6-2 "ONT Data Store Management Command" Command Parameters

Parameter	Type	Description
(force)	Format: force	<i>mandatory parameter</i> forces an ont to saves its data in

215 ONT Management Command

Parameter	Type	Description
	Possible values: - force :	flash memory

215.7 ONT Reboot via SN Management Command

Command Description

This command to reboot ont via serial number by sending PLOAM message.

User Level

The command can be accessed by operators with equipment privileges, and executed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

```
> admin equipment ont sernum (sernum) [ reboot <Gpon::OntReboot> ]
```

Command Parameters

Table 215.7-1 "ONT Reboot via SN Management Command" Resource Parameters

Resource Identifier	Type	Description
(sernum)	Format: <Gpon::VendorId> : <Gpon::SerialNo> Field type <Gpon::VendorId> - vendor id - 4 ASCII characters - range: [a-zA-Z0-9] - length: 4 Field type <Gpon::SerialNo> - serial num - 8 ASCII characters - range: [a-fA-F0-9] - length: 8	identification of ont

Table 215.7-2 "ONT Reboot via SN Management Command" Command Parameters

Parameter	Type	Description
reboot	Parameter type: <Gpon::OntReboot> Format: via-ploam Possible values: - via-ploam : reboot via ploam	<i>optional parameter</i> reboot the ont

216- EONT Management Command

216.1 EONT Management Command Tree	216-7249
216.2 Epon ONT reboot command	216-7250
216.3 Epon Ont Software Management Command	216-7251
216.4 Epon Ont LLID Loopback Command	216-7252
216.5 EONT Software Version Management Command	216-7253

216.1 EONT Management Command Tree

Description

This chapter gives an overview of nodes that are handled by "EONT Management Command".

Command Tree

```
----admin
  ----equipment
    ----eont
      ----interface
        - (epon-idx)
        - reboot
      ----swdw
        - (epon-idx)
        - swctrl
        - sw-ver-dl
      ----llid
        - (llid-idx)
        - [no] loopbackadmin
      ----sw-version
        - delete-version
```

216.2 Epon ONT reboot command

Command Description

This command allows the operator to restart the ONT

User Level

The command can be accessed by operators with equipment privileges, and executed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

```
> admin equipment eont interface (epon-idx) [ reboot <Epon::OntRestart> ]
```

Command Parameters

Table 216.2-1 "Epon ONT reboot command" Resource Parameters

Resource Identifier	Type	Description
(epon-idx)	Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Eqpt::OntId> - the ONT identifier	ONT index

Table 216.2-2 "Epon ONT reboot command" Command Parameters

Parameter	Type	Description
reboot	Parameter type: <Epon::OntRestart> Format: restart Possible values: - restart : reboot with currently active software image	<i>optional parameter</i> specifies how EPON ont must be rebooted

216.3 Epon Ont Software Management Command

Command Description

This command allows the operator to manage the ONT software

User Level

The command can be accessed by operators with equipment privileges, and executed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

```
> admin equipment eont swdw (epon-idx) [ swctrl <Epon::swctrl> ] [ sw-ver-dl <Epon::swverdl> ]
```

Command Parameters

Table 216.3-1 "Epon Ont Software Management Command" Resource Parameters

Resource Identifier	Type	Description
(epon-idx)	Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Eqpt::OntId> - the ONT identifier	ONT index

Table 216.3-2 "Epon Ont Software Management Command" Command Parameters

Parameter	Type	Description
swctrl	Parameter type: <Epon::swctrl> Format: (act commit) Possible values: - act : active - commit : commit	<i>optional parameter</i> specification of SW version to be downloaded to ont in case sw-ver-pland equal to manual
sw-ver-dl	Parameter type: <Epon::swverdl> Format: - software version download - length: 1<=x<=16	<i>optional parameter</i> software version download

216.4 Epon Ont LLID Loopback Command

Command Description

This command allows the operator to enable or disable the ont llid loopback.

User Level

The command can be accessed by operators with equipment privileges, and executed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

```
> admin equipment eont llid (llid-idx) [ no loopbackadmin | loopbackadmin <Epon::LoopBack> ]
```

Command Parameters

Table 216.4-1 "Epon Ont LLID Loopback Command" Resource Parameters

Resource Identifier	Type	Description
(llid-idx)	Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Epon::llid> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Eqpt::OntId> - the ONT identifier Field type <Epon::llid> - Ont llid number, range 1 for EPON, range 1-8 for DPOE - range: [1...8]	identification of eont llid

Table 216.4-2 "Epon Ont LLID Loopback Command" Command Parameters

Parameter	Type	Description
[no] loopbackadmin	Parameter type: <Epon::LoopBack> Format: (enable disable) Possible values: - enable : Enable Loopback function - disable : Disable Loopback function	<i>optional parameter with default value: "disable"</i> Enable/Disable Loopback function

216.5 EONT Software Version Management Command

Command Description

This command sets the ont software version that a manager wants deleted from the nt file system.

User Level

The command can be accessed by operators with equipment privileges, and executed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

```
> admin equipment eont sw-version [ delete-version <Epon::EontVersion> ]
```

Command Parameters

Table 216.5-2 "EONT Software Version Management Command" Command Parameters

Parameter	Type	Description
delete-version	Parameter type: <Epon::EontVersion> Format: - eont sw version - length: x<=16	<i>optional parameter</i> specify an ont software version that a manager wants deleted from the nt file system

Command Output

Table 216.5-3 "EONT Software Version Management Command" Display parameters

Specific Information		
name	Type	Description
status	Parameter type: <Epon::OntVerStatus> (issued in-progress success failed) Possible values: - issued : Command has never been issued - in-progress : deletion in progress - success : file successfully deleted - failed : unable to delete file	ont software version delete status. <i>This element is always shown.</i>

217- Protection Group Management Commands

217.1 Protection Group Management Command Tree	217-7255
217.2 Protection Group NT switchover Command	217-7256

217.1 Protection Group Management Command Tree

Description

This chapter gives an overview of nodes that are handled by "Protection Group Management Commands".

Command Tree

```
----admin
  ----equipment
    ----protection-group
      - (prot-group-id)
      - [no] switchover
```

217.2 Protection Group NT switchover Command

Command Description

This command allows the operator to switchover in protection group of NT

User Level

The command can be accessed by operators with equipment privileges, and executed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

```
> admin equipment protection-group (prot-group-id) [ [ no ] switchover ]
```

Command Parameters

Table 217.2-1 "Protection Group NT switchover Command" Resource Parameters

Resource Identifier	Type	Description
(prot-group-id)	Format: - index of protection group - range: [1...109]	Index in NT ProtGroup Table

Table 217.2-2 "Protection Group NT switchover Command" Command Parameters

Parameter	Type	Description
[no] switchover	Parameter type: boolean	<i>optional parameter</i> NT switchover

218- Ethernet Management Commands

218.1 Ethernet Management Command Tree	218-7258
218.2 Ethernet Management Command	218-7259
218.3 Ethernet Statistics Commands	218-7260
218.4 Epon Ont Ethernet Reautodetect Command	218-7261
218.5 Gpon Ont Ethernet loopback Command	218-7262

218.1 Ethernet Management Command Tree

Description

This chapter gives an overview of nodes that are handled by "Ethernet Management Commands".

Command Tree

```
----admin
  ----ethernet
    ----statistics
      - (stats-index)
      - (clear-stats)
    ----eont
      ----port
        - (uni-index)
        - (reautodetect)
      ----port
        - (uni-idx)
        - [no] loopback
        - [no] loopback-timeout
```

218.2 Ethernet Management Command

Command Description

This command allows the operator to manage the node: configure the ethernet parameters

User Level

The command can be accessed by operators with transport privileges, and executed by operators with transport privileges.

Command Syntax

The command has the following syntax:

> admin ethernet

218.3 Ethernet Statistics Commands

Command Description

This command allows the operator to reset the Ethernet counters.

User Level

The command can be accessed by operators with transport privileges, and executed by operators with transport privileges.

Command Syntax

The command has the following syntax:

```
> admin ethernet statistics (stats-index) (clear-stats)
```

Command Parameters

Table 218.3-1 "Ethernet Statistics Commands" Resource Parameters

Resource Identifier	Type	Description
(stats-index)	Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> lt : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> lt-link : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::LtBackPlPortId>) Possible values: - lt : lt-slot - lt-link : lt-slot-port Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number Field type <Eqpt::LtBackPlPortId> - the lt backplane port number	index of the interface to an ethernet-like medium

Table 218.3-2 "Ethernet Statistics Commands" Command Parameters

Parameter	Type	Description
(clear-stats)	Format: clear-stats Possible values: - clear-stats : clear all Ethernet counters	<i>optional parameter</i> clear the ethernet counters

218.4 Epon Ont Ethernet Reautodetect Command

Command Description

This command allows the operator to restart auto negotiation of an Ethernet port.

User Level

The command can be accessed by operators with equipment privileges, and executed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

```
> admin ethernet eont port (uni-index) [ (reautodetect) ]
```

Command Parameters

Table 218.4-1 "Epon Ont Ethernet Reautodetect Command" Resource Parameters

Resource Identifier	Type	Description
(uni-index)	Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Epon::EontSlot> / <Epon::EontPort> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Eqpt::OntId> - the ONT identifier Field type <Epon::EontSlot> - Epon Ont Slot - range: [1...16] Field type <Epon::EontPort> - Epon Ont Port - range: [1...64]	ONT UNI interface

Table 218.4-2 "Epon Ont Ethernet Reautodetect Command" Command Parameters

Parameter	Type	Description
(reautodetect)	Format: reautodetect Possible values: - reautodetect : restart autodetect	<i>optional parameter</i> restart autodetect

218.5 Gpon Ont Ethernet loopback Command

Command Description

This command allows the operator to enable/disable loopback mode of an Ethernet port, and set timeout for loopback.

User Level

The command can be accessed by operators with equipment privileges, and executed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

```
> admin ethernet port (uni-idx) [ [ no ] loopback ] [ no loopback-timeout | loopback-timeout
<Gpon::loopbackTimeout> ]
```

Command Parameters

Table 218.5-1 "Gpon Ont Ethernet loopback Command" Resource Parameters

Resource Identifier	Type	Description
(uni-idx)	Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Gpon::OntSlotId> / <Gpon::OntPortId> ng2 : <Ng2::ChannelGroup> / <Ng2::SubchannelGroup> / <Ng2::OntId> / <Gpon::OntSlotId> / <Gpon::OntPortId>) Possible values: - ng2 : ngpon2 style identification Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Ng2::ChannelGroup> - channel group number Field type <Ng2::SubchannelGroup> - subchannel group number Field type <Eqpt::OntId> - the ONT identifier Field type <Ng2::OntId> - the ONT identifier Field type <Gpon::OntSlotId> - Gpon Ont Slot	identification of the uni interface index

Resource Identifier	Type	Description
	- range: [1...14] - Field type <Gpon::OntPortId> - Gpon Ont Port - range: [1...16]	

Table 218.5-2 "Gpon Ont Ethernet loopback Command" Command Parameters

Parameter	Type	Description
[no] loopback	Parameter type: boolean	<i>optional parameter</i> enable UNI port loopback mode
[no] loopback-timeout	Parameter type: <Gpon::loopbackTimeout> Format: - loopback time, zero means no-timeout for loopback - unit: sec - range: [0...43200]	<i>optional parameter with default value: 1800</i> the actual loopback timeout, value in seconds

219- Bridge Management Commands

219.1 Bridge Management Command Tree	219-7265
219.2 Learned Unicast MAC Address Management Command	219-7266
219.3 VLAN Management Command	219-7269

219.1 Bridge Management Command Tree

Description

This chapter gives an overview of nodes that are handled by "Bridge Management Commands".

Command Tree

```
----admin
  ----bridge
    ----learned-unicast-mac
      - (vlan-port)
      - unicast-mac-address
      - (delete)
    ----vlan-id
      - (id)
      - (delete-member-ports)
```

219.2 Learned Unicast MAC Address Management Command

Command Description

This command allows the operator to remove dynamically learned MAC addresses.

User Level

The command can be accessed by operators with vlan privileges, and executed by operators with vlan privileges.

Command Syntax

The command has the following syntax:

```
> admin bridge learned-unicast-mac (vlan-port) unicast-mac-address <Vlan::MacAddr> (delete)
```

Command Parameters

Table 219.2-1 "Learned Unicast MAC Address Management Command" Resource Parameters

Resource Identifier	Type	Description
(vlan-port)	Format: (vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::VpiId> : <Eqpt::VciId> : <Eqpt::UnstackedVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::UnstackedVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::VpiId> : <Eqpt::VciId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> / <Eqpt::OntPortId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> / <Eqpt::OntPortId> : <Eqpt::UnstackedVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / voip : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / vuni : stacked : <Eqpt::SVlan> : <Eqpt::CVlan>	vlan port

Resource Identifier	Type	Description
	vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / voip : <Eqpt::UnstackedVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / vuni : <Eqpt::UnstackedVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::LLId> : <Eqpt::UnstackedVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::LLId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan-port:ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Ng2::OntId> / <Eqpt::Ng2OntSlotId> / <Eqpt::Ng2OntPortId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan-port:ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Ng2::OntId> / <Eqpt::Ng2OntSlotId> / <Eqpt::Ng2OntPortId> : <Eqpt::UnstackedVlan> vlan-port:ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Ng2::OntId> / vuni : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan-port:ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Ng2::OntId> / vuni : <Eqpt::UnstackedVlan>) Possible values: - vlan-port : vlan port - vlan-port:ng2 : ngpon2 vlan port Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number Field type <Eqpt::VpiId> - atm VPI Field type <Eqpt::VciId> - atm VCI Field type <Eqpt::PonId> - the PON identifier Field type <Eqpt::OntId> - the ONT identifier Field type <Eqpt::ChannelGroupId> - the channel group identifier Field type <Eqpt::SubChannelGroupId> - the subchannel group identifier Field type <Ng2::OntId> - the ONT identifier Possible values: - voip : virtual uni identifier - obsolete alternative replaced by vuni - vuni : virtual uni identifier Possible values: - vuni : virtual NGPON2 uni identifier	

Resource Identifier	Type	Description
	Field type <Eqpt::OntSlotId> - the ONT SLOT identifier Field type <Eqpt::OntPortId> - the ONT PORT identifier Field type <Eqpt::Ng2OntSlotId> - the NGPON2 ONT SLOT identifier Field type <Eqpt::Ng2OntPortId> - the NGPON2 ONT PORT identifier Field type <Eqpt::LLId> - the LLID identifier, range 1 for EPON, range 1-8 for DPOE Possible values: - stacked : stacked vlan identity Field type <Eqpt::UnstackedVlan> - unstacked vlan id Field type <Eqpt::SVlan> - service vlan id Field type <Eqpt::CVlan> - customer vlan id	
unicast-mac-address	Parameter type: <Vlan::MacAddr> Format: - mac address (aa:bb:cc:a1:02:03) - unit: Byte - length: 6	unicast mac address

Table 219.2-2 "Learned Unicast MAC Address Management Command" Command Parameters

Parameter	Type	Description
(delete)	Format: delete Possible values: - delete : delete a unicast mac address	<i>optional parameter</i> delete a learned unicast mac address

219.3 VLAN Management Command

Command Description

This command allows the operator to remove the association between a VLAN and all its member ports.

This command is the only means to remove dynamic associations.

Removal of the port VLAN association includes removal of all MAC addresses from the filtering database for these port-VLAN associations.

Any outstanding duplicate MAC alarms for the port are cleared.

User Level

The command can be accessed by operators with vlan privileges, and executed by operators with vlan privileges.

Command Syntax

The command has the following syntax:

```
> admin bridge vlan-id (id) [ (delete-member-ports) ]
```

Command Parameters

Table 219.3-1 "VLAN Management Command" Resource Parameters

Resource Identifier	Type	Description
(id)	Format: (<Vlan::UVlanIndex> stacked : <Vlan::SVlanIndex> : <Vlan::CVlanIndex>) Possible values: - stacked : stacked vlan identity Field type <Vlan::UVlanIndex> - unstacked vlan identity - range: [1...4093,4096] Field type <Vlan::SVlanIndex> - service vlan identity - range: [2...4093] Field type <Vlan::CVlanIndex> - customer vlan identity - range: [0...4093]	vlan id

Table 219.3-2 "VLAN Management Command" Command Parameters

Parameter	Type	Description
(delete-member-ports)	Format: delete-member-ports Possible values: - delete-member-ports : remove associated bridge ports	<i>optional parameter</i> remove association between a vlan and all it's bridge ports

220- *Trap Management Commands*

220.1 Trap Management Command Tree	220-7271
220.2 Trap Manager Management Command	220-7272

220.1 Trap Management Command Tree

Description

This chapter gives an overview of nodes that are handled by "Trap Management Commands".

Command Tree

```
----admin
  ----trap
    ----manager
      - (address)
      - (reset-trap-buffer)
```

220.2 Trap Manager Management Command

Command Description

This command allows the operator to manage a trap manager.

User Level

The command can be accessed by operators with alarm privileges, and executed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> admin trap manager (address) [ (reset-trap-buffer) ]
```

Command Parameters

Table 220.2-1 "Trap Manager Management Command" Resource Parameters

Resource Identifier	Type	Description
(address)	Format: <Ip::V4Address> : <Trap::Port> Field type <Ip::V4Address> - IPv4-address Field type <Trap::Port> - trap port number - range: [1...65535]	the IP address of the manager

Table 220.2-2 "Trap Manager Management Command" Command Parameters

Parameter	Type	Description
(reset-trap-buffer)	Format: reset-trap-buffer Possible values: - reset-trap-buffer : reset the trap buffer	<i>optional parameter</i> reset the trap buffer

221- *Interface Management commands*

221.1 Interface Management commands Tree	221-7274
221.2 Interface Troubleshooting Ethernet Statistics Commands	221-7275

221.1 Interface Management commands Tree

Description

This chapter gives an overview of nodes that are handled by "Interface Management commands".

Command Tree

```
----admin
  ----interface
    ----trouble-shooting
      ----ethernet
        ----statistics
          - (slot-id)
          - (clr-trbt-eth-stats)
```

221.2 Interface Troubleshooting Ethernet Statistics Commands

Command Description

This command allows the operator to reset the FD-REM trouble-shooting counters at the far-end side. This Clear command is supported only for NDLT-G and NELT-B LT card, Error will be thrown for other LT cards.

User Level

The command can be accessed by operators with equipment privileges, and executed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

```
> admin interface trouble-shooting ethernet statistics (slot-id) (clr-trbt-eth-stats)
```

Command Parameters

Table 221.2-1 "Interface Troubleshooting Ethernet Statistics Commands" Resource Parameters

Resource Identifier	Type	Description
(slot-id)	Format: (lt : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> lt-link : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::LtBackPlPortId>) Possible values: - lt : lt-slot - lt-link : lt-slot-port Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::LtBackPlPortId> - the lt backplane port number	slot

Table 221.2-2 "Interface Troubleshooting Ethernet Statistics Commands" Command Parameters

Parameter	Type	Description
(clr-trbt-eth-stats)	Format: clr-trbt-eth-stats Possible values: - clr-trbt-eth-stats : clear all trouble shooting counters	<i>optional parameter</i> clear the trouble shooting counters

222- DHCP Management Command

222.1 DHCP Management Command Tree	222-7277
222.2 DHCP Relay User Port Management Command	222-7278
222.3 DHCP Relay User Port Management Command	222-7281

222.1 DHCP Management Command Tree

Description

This chapter gives an overview of nodes that are handled by "DHCP Management Command".

Command Tree

```
----admin
  ----dhcp-relay
    ----port-stats
      - (vlan-port)
      - (clear-statistics)
    ----v6-port-stats
      - (vlan-port)
      - (clear-statistics)
```

222.2 DHCP Relay User Port Management Command

Command Description

This command allows the operator to manage the DHCP relay user port commands.

User Level

The command can be accessed by operators with dhcp privileges, and executed by operators with dhcp privileges.

Command Syntax

The command has the following syntax:

```
> admin dhcp-relay port-stats (vlan-port) (clear-statistics)
```

Command Parameters

Table 222.2-1 "DHCP Relay User Port Management Command" Resource Parameters

Resource Identifier	Type	Description
(vlan-port)	Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::VpiId> : <Eqpt::VciId> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::VpiId> : <Eqpt::VciId> : <Eqpt::UnstackedVlan> vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::UnstackedVlan> vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::VpiId> : <Eqpt::VciId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> / <Eqpt::OntPortId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> / <Eqpt::OntPortId> : <Eqpt::UnstackedVlan> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> / <Eqpt::OntPortId> vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> /	Identification of the ip user interface or vlan port

Resource Identifier	Type	Description
	<Eqpt::PonId> / <Eqpt::OntId> / voip : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / vuni : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / voip : <Eqpt::UnstackedVlan> vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / vuni : <Eqpt::UnstackedVlan> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / voip <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / vuni vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::LLId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::LLId> : <Eqpt::UnstackedVlan> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::LLId> vlan.ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / <Eqpt::Ng2OntSlotId> / <Eqpt::Ng2OntPortId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan.ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / <Eqpt::Ng2OntSlotId> / <Eqpt::Ng2OntPortId> : <Eqpt::UnstackedVlan> vlan.ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / vuni : <Eqpt::SVlan> : <Eqpt::CVlan> vlan.ng2 : <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / vuni : <Eqpt::UnstackedVlan>) Possible values: - vlan : vlan port - vlan.ng2 : ngpon2 vlan port Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number Field type <Eqpt::VpiId> - atm VPI Field type <Eqpt::VciId> - atm VCI Field type <Eqpt::PonId> - the PON identifier Field type <Eqpt::ChannelGroupId> - the channel group identifier Field type <Eqpt::SubChannelGroupId> - the subchannel group identifier	

Resource Identifier	Type	Description
	Field type <Eqpt::Ng2OntId> - the NG2 ONT identifier Field type <Eqpt::OntId> - the ONT identifier Possible values: - voip : virtual uni identifier obsolete alternative replaced by vuni - vuni : virtual uni identifier Possible values: - vuni : virtual NGPON2 uni identifier Field type <Eqpt::OntSlotId> - the ONT SLOT identifier Field type <Eqpt::OntPortId> - the ONT PORT identifier Field type <Eqpt::Ng2OntSlotId> - the NGPON2 ONT SLOT identifier Field type <Eqpt::Ng2OntPortId> - the NGPON2 ONT PORT identifier Field type <Eqpt::LLId> - the LLID identifier, range 1 for EPON, range 1-8 for DPOE Possible values: - stacked : stacked vlan identity Field type <Eqpt::UnstackedVlan> - unstacked vlan id Field type <Eqpt::SVlan> - service vlan id Field type <Eqpt::CVlan> - customer vlan id	

Table 222.2-2 "DHCP Relay User Port Management Command" Command Parameters

Parameter	Type	Description
(clear-statistics)	Format: clear-statistics Possible values: - clear-statistics : clear the statistics	<i>optional parameter</i> clear the IPoX counters

222.3 DHCP Relay User Port Management Command

Command Description

This command allows the operator to manage the DHCP relay user port commands.

User Level

The command can be accessed by operators with dhcp privileges, and executed by operators with dhcp privileges.

Command Syntax

The command has the following syntax:

```
> admin dhcp-relay v6-port-stats (vlan-port) (clear-statistics)
```

Command Parameters

Table 222.3-1 "DHCP Relay User Port Management Command" Resource Parameters

Resource Identifier	Type	Description
(vlan-port)	Format: (vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::VpiId> : <Eqpt::VciId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::VpiId> : <Eqpt::VciId> : <Eqpt::UnstackedVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::UnstackedVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> / <Eqpt::OntPortId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> / <Eqpt::OntPortId> : <Eqpt::UnstackedVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / voip : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / vuni : stacked : <Eqpt::SVlan> : <Eqpt::CVlan>	identification of vlan port

Resource Identifier	Type	Description
	<pre> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / voip : <Eqpt::UnstackedVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / vuni : <Eqpt::UnstackedVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::LLId> : <Eqpt::UnstackedVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::LLId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan-port:ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / <Eqpt::Ng2OntSlotId> / <Eqpt::Ng2OntPortId> : <Eqpt::UnstackedVlan> vlan-port:ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / <Eqpt::Ng2OntSlotId> / <Eqpt::Ng2OntPortId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan-port:ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / vuni) </pre> Possible values: - vlan-port : vlan port - vlan-port:ng2 : an NGPON2 vlan port Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number Field type <Eqpt::VpiId> - atm VPI Field type <Eqpt::VciId> - atm VCI Field type <Eqpt::ChannelGroupId> - the channel group identifier Field type <Eqpt::SubChannelGroupId> - the subchannel group identifier Field type <Eqpt::PonId> - the PON identifier Field type <Eqpt::OntId> - the ONT identifier Field type <Eqpt::Ng2OntId> - the NG2 ONT identifier Possible values: - voip : virtual uni identifier obsolete alternative replaced by vuni - vuni : virtual uni identifier Possible values: - vuni : virtual NGPON2 uni identifier Field type <Eqpt::OntSlotId> - the ONT SLOT identifier Field type <Eqpt::OntPortId> - the ONT PORT identifier	

Resource Identifier	Type	Description
	Field type <Eqpt::Ng2OntSlotId> - the NGPON2 ONT SLOT identifier Field type <Eqpt::Ng2OntPortId> - the NGPON2 ONT PORT identifier Field type <Eqpt::LLId> - the LLID identifier,range 1 for EPON,range 1-8 for DPOE Possible values: - stacked : stacked vlan identity Field type <Eqpt::UnstackedVlan> - unstacked vlan id Field type <Eqpt::SVlan> - service vlan id Field type <Eqpt::CVlan> - customer vlan id	

Table 222.3-2 "DHCP Relay User Port Management Command" Command Parameters

Parameter	Type	Description
(clear-statistics)	Format: clear-statistics Possible values: - clear-statistics : clear the statistics	<i>optional parameter</i> clear the DHCP v6 counters

223- ARP-RELAY statistics Management Commands

223.1 ARP-RELAY statistics Management Command Tree	223-7285
223.2 Arp-relay statistics Management Command	223-7286

223.1 ARP-RELAY statistics Management

Command Tree

Description

This chapter gives an overview of nodes that are handled by "ARP-RELAY statistics Management Commands".

Command Tree

```
----admin
  ----arp-relay-stats
    - (vlan-port)
    - (clear-statistics)
```

223.2 Arp-relay statistics Management Command

Command Description

This command allows the operator to reset the arp-relay statistics counters.

User Level

The command can be accessed by operators with ip privileges, and executed by operators with ip privileges.

Command Syntax

The command has the following syntax:

```
> admin arp-relay-stats (vlan-port) [ (clear-statistics) ]
```

Command Parameters

Table 223.2-1 "Arp-relay statistics Management Command" Resource Parameters

Resource Identifier	Type	Description
(vlan-port)	Format: (vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::VpiId> : <Eqpt::VciId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::VpiId> : <Eqpt::VciId> : <Eqpt::UnstackedVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::UnstackedVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> / <Eqpt::OntPortId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> / <Eqpt::OntPortId> : <Eqpt::UnstackedVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / voip : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / vuni : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / voip : <Eqpt::UnstackedVlan>	The VLAN port interface

Resource Identifier	Type	Description
	vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / vuni : <Eqpt::UnstackedVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::LLId> : <Eqpt::UnstackedVlan> vlan-port : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::LLId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan-port:ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / <Eqpt::Ng2OntSlotId> / <Eqpt::Ng2OntPortId> : <Eqpt::UnstackedVlan> vlan-port:ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / <Eqpt::Ng2OntSlotId> / <Eqpt::Ng2OntPortId> : stacked : <Eqpt::SVlan> : <Eqpt::CVlan> vlan-port:ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / vuni) Possible values: - vlan-port : vlan port - vlan-port:ng2 : an NGPON2 vlan port Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number Field type <Eqpt::VpId> - atm VPI Field type <Eqpt::VciId> - atm VCI Field type <Eqpt::ChannelGroupId> - the channel group identifier Field type <Eqpt::SubChannelGroupId> - the subchannel group identifier Field type <Eqpt::PonId> - the PON identifier Field type <Eqpt::OntId> - the ONT identifier Field type <Eqpt::Ng2OntId> - the NG2 ONT identifier Possible values: - voip : virtual uni identifier obsolete alternative replaced by vuni - vuni : virtual uni identifier Possible values: - vuni : virtual NGPON2 uni identifier Field type <Eqpt::OntSlotId> - the ONT SLOT identifier Field type <Eqpt::OntPortId> - the ONT PORT identifier Field type <Eqpt::Ng2OntSlotId> - the NGPON2 ONT SLOT identifier Field type <Eqpt::Ng2OntPortId>	

Resource Identifier	Type	Description
	- the NGPON2 ONT PORT identifier Field type <Eqpt::LLId> - the LLID identifier, range 1 for EPON, range 1-8 for DPOE Possible values: - stacked : stacked vlan identity Field type <Eqpt::UnstackedVlan> - unstacked vlan id Field type <Eqpt::SVlan> - service vlan id Field type <Eqpt::CVlan> - customer vlan id	

Table 223.2-2 "Arp-relay statistics Management Command" Command Parameters

Parameter	Type	Description
(clear-statistics)	Format: clear-statistics Possible values: - clear-statistics : clear the arp-relay statistics	<i>optional parameter</i> clear arp-relay summary and detailed statistics

224- *Transport Management Commands*

224.1 Transport Management Command Tree
224.2 IP Net-to-media Management Command

224-7290
224-7291

224.1 Transport Management Command Tree

Description

This chapter gives an overview of nodes that are handled by "Transport Management Commands".

Command Tree

```
----admin
  ----transport
    ----ip-net-to-media
      - (interface-name)
      - network-addr
      - phy-addr
      - (delete)
```

224.2 IP Net-to-media Management Command

Command Description

This command allows the operator to delete the IP address out of the ARP table.

User Level

The command can be accessed by operators with transport privileges, and executed by operators with transport privileges.

Command Syntax

The command has the following syntax:

```
> admin transport ip-net-to-media (interface-name) network-addr <Ip::V4AddressHex> phy-addr <Sys::MacAddr>
[ (delete) ]
```

Command Parameters

Table 224.2-1 "IP Net-to-media Management Command" Resource Parameters

Resource Identifier	Type	Description
(interface-name)	Format: eth1 Possible values: - eth1 : control interface	name of the interface
network-addr	Parameter type: <Ip::V4AddressHex> Format: - IPv4-address	ip addr corresponding to media-dependent physical addr
phy-addr	Parameter type: <Sys::MacAddr> Format: - a mac-address (example : 01:02:03:04:05:06) - length: 6	media-dependent physical addr

Table 224.2-2 "IP Net-to-media Management Command" Command Parameters

Parameter	Type	Description
(delete)	Format: delete Possible values: - delete : delete a ip-net to media entry	<i>optional parameter</i> delete a ip-net-to-media

225- *SNTP Management Commands*

225.1 SNTP Management Command Tree	225-7293
225.2 SNTP Management Command	225-7294

225.1 SNTP Management Command Tree

Description

This chapter gives an overview of nodes that are handled by "SNTP Management Commands".

Command Tree

```
----admin
  ----sntp
    - system-time
```

225.2 SNTP Management Command

Command Description

This command allows the operator to manage SNTP.

User Level

The command can be accessed by operators with security privileges, and executed by operators with security privileges.

Command Syntax

The command has the following syntax:

```
> admin sntp [ system-time <Sys::GaugeTimeInSecs> ]
```

Command Parameters

Table 225.2-2 "SNTP Management Command" Command Parameters

Parameter	Type	Description
system-time	Parameter type: <Sys::GaugeTimeInSecs> Format: - the time (yyyy-mm-dd:hour:minutes:secs)	<i>optional parameter</i> Set the system time. The configured time zone offset is taken into account when setting and retrieving the time

226- Transactions Management Commands

226.1 Transactions Management Command Tree	226-7296
226.2 Transaction Configuration Management Command	226-7297

226.1 Transactions Management Command Tree

Description

This chapter gives an overview of nodes that are handled by "Transactions Management Commands".

Command Tree

```
----admin
  ----transaction
    X configure-lock
```

226.2 Transaction Configuration Management Command

Command Description

This command allows the operator to manage transactions.

User Level

The command can be accessed by operators with alarm privileges, and executed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

```
> admin transaction [ configure-lock <Trans::ownerIpAddr> ]
```

Command Parameters

Table 226.2-2 "Transaction Configuration Management Command" Command Parameters

Parameter	Type	Description
configure-lock	Parameter type: <Trans::ownerIpAddr> Format: (acquire release) Possible values: - acquire : prevents other managers from configuring - release : allow other managers to configure	<i>obsolete parameter that will be ignored</i> changes the status of the configuration lock. This parameter has been discarded. And will not take affect any more.Keep it for backward compatibility. And it will do nothing.

227- Security Management Commands

227.1 Security Management Command Tree	227-7299
227.2 Security 802.1x Port Authentication Management Command	227-7300

227.1 Security Management Command Tree

Description

This chapter gives an overview of nodes that are handled by "Security Management Commands".

Command Tree

```
----admin
  ----security
    ----ext-authenticator
      - (port)
      - (clear-statistics)
```

227.2 Security 802.1x Port Authentication Management Command

Command Description

This command allows the operator to manage a port or virtual channel in the scope of 802.1x authentication.

User Level

The command can be accessed by operators with aaa privileges, and executed by operators with aaa privileges.

Command Syntax

The command has the following syntax:

```
> admin security ext-authenticator (port) [ (clear-statistics) ]
```

Command Parameters

Table 227.2-1 "Security 802.1x Port Authentication Management Command" Resource Parameters

Resource Identifier	Type	Description
(port)	Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::VpiId> : <Eqpt::VciId> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> / <Eqpt::OntPortId> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / voip <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / vuni <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::LLId> ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / <Eqpt::Ng2OntSlotId> / <Eqpt::Ng2OntPortId> ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / vuni) Possible values: - ng2 : ngpon2 style identification Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId>	identification of the port or virtual channel

Resource Identifier	Type	Description
	- the LT slot number - Field type <Eqpt::PortId> - the port number - Field type <Eqpt::VpiId> - atm VPI - Field type <Eqpt::VciId> - atm VCI - Field type <Eqpt::ChannelGroupId> - the channel group identifier - Field type <Eqpt::SubChannelGroupId> - the subchannel group identifier - Field type <Eqpt::PonId> - the PON identifier - Field type <Eqpt::OntId> - the ONT identifier - Field type <Eqpt::Ng2OntId> - the NG2 ONT identifier - Possible values: - voip : virtual uni identifier - obsolete alternative replaced by vuni - vuni : virtual uni identifier - Possible values: - vuni : virtual NGPON2 uni identifier - Field type <Eqpt::OntSlotId> - the ONT SLOT identifier - Field type <Eqpt::OntPortId> - the ONT PORT identifier - Field type <Eqpt::Ng2OntSlotId> - the NGPON2 ONT SLOT identifier - Field type <Eqpt::Ng2OntPortId> - the NGPON2 ONT PORT identifier - Field type <Eqpt::LLId> - the LLID identifier, range 1 for EPON, range 1-8 for DPOE	

Table 227.2-2 "Security 802.1x Port Authentication Management Command" Command Parameters

Parameter	Type	Description
(clear-statistics)	Format: clear-statistics Possible values: - clear-statistics : clear non-accounting statistics	<i>optional parameter</i> clear non-accounting statistics

228- *Security Management Commands*

228.1 Security Management Command Tree	228-7303
228.2 Security 802.1x Port Authentication Management Command	228-7304

228.1 Security Management Command Tree

Description

This chapter gives an overview of nodes that are handled by "Security Management Commands".

Command Tree

```
----admin
  ----security
    ----mac-diag
      - (port)
      - mac-addr
      - (clear-statistics)
```

228.2 Security 802.1x Port Authentication Management Command

Command Description

This command allows the operator to manage a port or virtual channel in the scope of 802.1x authentication.

User Level

The command can be accessed by operators with aaa privileges, and executed by operators with aaa privileges.

Command Syntax

The command has the following syntax:

```
> admin security mac-diag (port) mac-addr <Vlan::MacAddr> [ (clear-statistics) ]
```

Command Parameters

Table 228.2-1 "Security 802.1x Port Authentication Management Command" Resource Parameters

Resource Identifier	Type	Description
(port)	Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::VpiId> : <Eqpt::VciId> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::OntSlotId> / <Eqpt::OntPortId> <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / voip <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / vuni <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> / <Eqpt::LLId> ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / <Eqpt::Ng2OntSlotId> / <Eqpt::Ng2OntPortId> ng2 : <Eqpt::ChannelGroupId> / <Eqpt::SubChannelGroupId> / <Eqpt::Ng2OntId> / vuni) Possible values: - ng2 : ngpon2 style identification Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId>	identification of the port or virtual channel

Resource Identifier	Type	Description
	- the LT slot number - Field type <Eqpt::PortId> - the port number - Field type <Eqpt::VpiId> - atm VPI - Field type <Eqpt::VciId> - atm VCI - Field type <Eqpt::ChannelGroupId> - the channel group identifier - Field type <Eqpt::SubChannelGroupId> - the subchannel group identifier - Field type <Eqpt::PonId> - the PON identifier - Field type <Eqpt::OntId> - the ONT identifier - Field type <Eqpt::Ng2OntId> - the NG2 ONT identifier - Possible values: - voip : virtual uni identifier - obsolete alternative replaced by vuni - vuni : virtual uni identifier - Possible values: - vuni : virtual NGPON2 uni identifier - Field type <Eqpt::OntSlotId> - the ONT SLOT identifier - Field type <Eqpt::OntPortId> - the ONT PORT identifier - Field type <Eqpt::Ng2OntSlotId> - the NGPON2 ONT SLOT identifier - Field type <Eqpt::Ng2OntPortId> - the NGPON2 ONT PORT identifier - Field type <Eqpt::LLId> - the LLID identifier, range 1 for EPON, range 1-8 for DPOE	
mac-addr	Parameter type: <Vlan::MacAddr> Format: - mac address (aa:bb:cc:a1:02:03) - unit: Byte - length: 6	mac address

Table 228.2-2 "Security 802.1x Port Authentication Management Command" Command Parameters

Parameter	Type	Description
(clear-statistics)	Format: clear-statistics Possible values: - clear-statistics : clear non-accounting statistics	<i>optional parameter</i> clear non-accounting statistics

229- *Debug commands*

229.1 Debug commands Tree
229.2 Debug commands

229-7307
229-7308

229.1 Debug commands Tree

Description

This chapter gives an overview of nodes that are handled by "Debug commands".

Command Tree

----debug-command

229.2 Debug commands

The commands of this node are to be used by Nokia certified personnel only.

Nokia can not be held responsible for any loss of data or revenue that occurs when these commands are executed by non Nokia certified personnel.

This node contains some commands which are launched either towards the LT or NT Trace and Debug shell or to the shub command shell.

The CLI commands as entered by the operator, will be translated in several Trace and Debug commands.

Those Trace and Debug commands will be executed by the Trace and Debug Shell of the specified LT or NT, or by the shub.

The result of those Trace and Debug commands will be processed, a filtered output will be displayed.

230- Remote debug Commands

230.1 Remote debug Command Tree	230-7310
230.2 Remote debug	230-7311
230.3 Remote debug ONT	230-7312

230.1 Remote debug Command Tree

Description

This chapter gives an overview of nodes that are handled by "Remote debug Commands".

Command Tree

```
----remote-debug
  ----ont
    - (ont-index)
    - (command)
```


230.2 Remote debug

Command Description

This command allows the operator to debug remotely

After this command execution, debug output will be displayed on the CLI session

User Level

The command can be accessed by operators with all,admin privileges, and executed by operators with all privileges.

Command Syntax

The command has the following syntax:

> remote-debug

230.3 Remote debug ONT

Command Description

This command allows the operator to debug ONT remotely

After executing this command, the operator has a CLI session up to the OLT, and on that session he can execute commands which are specific to an ONU. This is typically used for remote debugging on the ONU. As these latter commands are specific to an ONU and may be even proprietary and depending on the vendor of the ONU, these ONU commands are out of the scope of this OLT guide. The communication between OLT and ONU is according Remote Debug Managed Entity as defined in ITU-T G.988 (10/2012) in section 9.1.12 and further detailed in Appendix 1 section I.2.8. It is a minimum requirement that this is also supported on the ONU to make this work. Furthermore, interoperability between OLT and ONU must be supported.

User Level

The command can be accessed by operators with all,admin privileges, and executed by operators with all privileges.

Command Syntax

The command has the following syntax:

```
> remote-debug ont (ont-index) (command)
```

Command Parameters

Table 230.3-1 "Remote debug ONT" Resource Parameters

Resource Identifier	Type	Description
(ont-index)	Format: (<Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PonId> / <Eqpt::OntId> ng2 : <Ng2::ChannelGroup> / <Ng2::SubchannelGroup> / <Ng2::OntId>) Possible values: - ng2 : ngpon2 style identification Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PonId> - the PON identifier Field type <Ng2::ChannelGroup> - channel group number Field type <Ng2::SubchannelGroup> - subchannel group number Field type <Eqpt::OntId> - the ONT identifier	access identifier for the ont

Resource Identifier	Type	Description
	Field type <Ng2::OntId> - the ONT identifier	

Table 230.3-2 "Remote debug ONT" Command Parameters

Parameter	Type	Description
(command)	Format: - debug command to be executed on ONT. - length: 1<=x<=52	<i>optional parameter</i> debug command to be executed on ONT

231- *TcpDump Command*

231.1 TcpDump Command Tree	231-7315
231.2 TcpDump Command	231-7316
231.3 tcpdump tool	231-7317
231.4 tcpdump tool	231-7318
231.5 tcpdump tool	231-7319

231.1 TcpDump Command Tree

Description

This chapter gives an overview of nodes that are handled by "TcpDump Command".

Command Tree

```
----tcpdump
  ----start
    - vlan
  ----stop
  ----show
```

231.2 TcpDump Command

Command Description

This command allows the operator to capture packets arriving on Core-0 AI Interface.

User Level

The command can be accessed by operators with security,debug privileges, and executed by operators with security,debug privileges.

Command Syntax

The command has the following syntax:

```
> tcpdump
```

231.3 tcpdump tool

Command Description

tcpdump start: Captures packets arriving on AI port and writes to the file specified.

tcpdump stop: Stops the packet capture.

tcpdump show: Displays the packets captured.

User Level

The command can be accessed by operators with security,debug privileges, and executed by operators with security,debug privileges.

Command Syntax

The command has the following syntax:

```
> tcpdump start vlan <Vlan::VlanIndex>
```

Command Parameters

Table 231.3-2 "tcpdump tool" Command Parameters

Parameter	Type	Description
vlan	Parameter type: <Vlan::VlanIndex> Format: - vlan id - range: [1...4093]	<i>optional parameter</i> Enter the vlan id.

231.4 tcpdump tool

Command Description

tcpdump start: Captures packets arriving on AI port and writes to the file specified.

tcpdump stop: Stops the packet capture.

tcpdump show: Displays the packets captured.

User Level

The command can be accessed by operators with security, debug privileges, and executed by operators with security, debug privileges.

Command Syntax

The command has the following syntax:

> tcpdump stop

231.5 tcpdump tool

Command Description

tcpdump start: Captures packets arriving on AI port and writes to the file specified.

tcpdump stop: Stops the packet capture.

tcpdump show: Displays the packets captured.

User Level

The command can be accessed by operators with security, debug privileges, and executed by operators with security, debug privileges.

Command Syntax

The command has the following syntax:

> tcpdump show

232- Clear Commands

232.1 Clear Command Tree
232.2 Clear Command

232-7321
232-7322

232.1 Clear Command Tree

Description

This chapter gives an overview of nodes that are handled by "Clear Commands".

Command Tree

----clear

232.2 Clear Command

Command Description

This command allows the operator to clear.

To have the exact syntax of the commands, please have a look into IPD book xx.

User Level

The command can be accessed by operators with all privileges, and executed by operators with all privileges.

Command Syntax

The command has the following syntax:

> clear

233- IHUB Commands

Description

This chapter gives an overview of all IHUB commands with a reference to the document where the exact syntax and description of the command can be found

Commands

configure system security cpu-filter: See IHUB System Basics, Management and OAM Guide for more information. The command can be accessed and executed by operators with security privileges.

configure system security cpu-protection: See IHUB System Basics, Management and OAM Guide for more information. The command can be accessed and executed by operators with security privileges.

configure system security mgmt-ipv4-addr: See IHUB configuration Guide for more information. The command can be accessed and executed by operators with service privileges.

configure system security mgmt-ipv6-addr: See IHUB configuration Guide for more information. The command can be accessed and executed by operators with service privileges.

configure system security snmp-slot-numbering: See IHUB configuration Guide for more information. The command can be accessed and executed by operators with service privileges.

configure system security hash-control: See IHUB configuration Guide for more information. The command can be accessed and executed by operators with service privileges.

configure system security keychain: See IHUB System Basics, Management and OAM Guide for more information. The command can be accessed and executed by operators with security privileges.

configure system security source-address: See IHUB System Basics, Management and OAM Guide for more information. The command can be accessed and executed by operators with security privileges.

configure system lacp-priority: See IHUB System Basics, Management and OAM Guide for more information. The command can be accessed and executed by operators with link privileges.

configure system vlan-dot1q-etype: See IHUB System Basics, Management and OAM Guide for more information. The command can be accessed and executed by operators with system privileges.

configure system sliding-win-stats: See IHUB Services guide for more information. The command can be accessed and executed by operators with system privileges.

configure system lt-link-tca-thresholds: See IHUB Services guide for more information. The command can be accessed and executed by operators with system privileges.

configure system lldp: See IHUB System Basics, Management and OAM Guide for more information. The command can be accessed and executed by operators with system privileges.

configure system port-group: See IHUB Services guide for more information. The command can be accessed and executed by operators with system privileges.

configure system ptp: See IHUB Services guide for more information. The command can be accessed and executed by operators with system privileges.

configure system user-user-hairpin: See IHUB Services guide for more information. The command can be accessed and executed by operators with system privileges.

configure system time: See the IHUB System Basics, Management and OAM Guide for more information. The command can be accessed and executed by operators with system privileges.

configure qos-servicerouter: See IHUB QoS Guide for more information. The command can be accessed and executed by operators with qos privileges.

configure eth-cfm: See IHUB Services Guide for more information. The command can be accessed and executed by operators with oam privileges.

configure router: See IHUB Router Configurations and Routing Protocols Guide for more information. See IHUB MPLS Guide for more information on mpls and ldp. The command can be accessed and executed by operators with service privileges.

configure subscriber-mgmt:

configure service customer: See IHUB Services Guide for more information. The command can be accessed and executed by operators with service privileges.

configure service ies: See IHUB Services Guide and IHUB QoS Guide for more information. The command can be accessed and executed by operators with service privileges.

configure service vpls: See IHUB Services Guide and IHUB QoS Guide for more information. The command can be accessed and executed by operators with service privileges.

configure service vprn: See IHUB Services Guide and IHUB QoS Guide for more information. The command can be accessed and executed by operators with service privileges.

configure service sdp: See IHUB Services Guide and IHUB QoS Guide for more information. The command can be accessed and executed by operators with service privileges.

configure service epipe: See IHUB Services Guide and IHUB QoS Guide for more information. The command can be accessed and executed by operators with service privileges.

configure service pw-template: See IHUB Services Guide and IHUB QoS Guide for more information. The command can be accessed and executed by operators with service privileges.

configure filter: See IHUB Router Configurations and Routing Protocols Guide for more information. The command can be accessed and executed by operators with filter privileges.

configure mirror: See IHUB Services Guide for more information. The command can be accessed and executed by operators with debug-mirror privileges.

configure lag: See IHUB Interface Guide for more information. The command can be accessed and executed by operators with link privileges.

configure port: See IHUB Interface Guide and IHUB QoS Guide for more information. The command can be accessed and executed by operators with link privileges.

configure log: See IHUB System Basics, Management and OAM Guide for more information. The command can be accessed and executed by operators with log privileges.

configure eth-ring: See IHUB Services Guide for more information. The command can be accessed and executed by operators with oam privileges.

show qos-servicerouter: See IHUB QoS Guide for more information. The command can be accessed and executed by operators with qos privileges.

show system security cpu-filter: See IHUB System Basics, Management and OAM Guide for more information. The command can be accessed and executed by operators with security privileges.

show system security cpu-protection: See IHUB System Basics, Management and OAM Guide for more information. The command can be accessed and executed by operators with security privileges.

show system security keychain: See IHUB System Basics, Management and OAM Guide for more information. The command can be accessed and executed by operators with security privileges.

show system core1-cpu: See IHUB System Basics, Management and OAM Guide for more information. The command can be accessed and executed by operators with oam privileges.

show system core1-memory-pools: See IHUB System Basics, Management and OAM Guide for more information. The command can be accessed and executed by operators with oam privileges.

show system ipv6-prefix-mgmt: "System ipv6 prefix resource usage show Command."

show system vlan-dot1q-etype: See IHUB System Basics, Management and OAM Guide for more information. The command can be accessed and executed by operators with system and service privileges.

show system user-user-hairpin: See IHUB System Basics, Management and OAM Guide for more information. The command can be accessed and executed by operators with system privileges.

show system sliding-win-stats: See IHUB System Basics, Management and OAM Guide for more information. The command can be accessed and executed by operators with system privileges.

show system ntp: See IHUB System Basics, Management and OAM Guide for more information. The command can be accessed and executed by operators with system privileges.

show system lldp: See IHUB System Basics, Management and OAM Guide and IHUB Interfaces Guide for more information. The command can be accessed and executed by operators with system and service privileges.

show system lt-link-tca-thres: See IHUB System Basics, Management and OAM Guide for more information. The command can be accessed and executed by operators with system privileges.

show eth-cfm: See IHUB Services Guide for more information. The command can be accessed and executed by operators with oam privileges.

show router: See IHUB Router Configurations and Routing Protocols Guide for more information. See IHUB MPLS Guide for more information on mpls and ldp. The command can be accessed and executed by operators with service privileges.

show subscriber-mgmt:

show mirror: See IHUB Services Guide for more information. The command can be accessed and executed by operators with debug-mirror privileges.

show service: See IHUB Services Guide and IHUB QoS Guide for more information. The command can be accessed and executed by operators with service privileges.

show port: See IHUB Interface Guide and IHUB QoS Guide for more information. The command can be accessed and executed by operators with link privileges.

show filter: See IHUB Router Configurations and Routing Protocols Guide for more information. The command can be accessed and executed by operators with filter privileges.

show debug: See IHUB System Basics, Management and OAM Guide for more information. The command can be accessed and executed by operators with debug privileges.

show lag: See IHUB Interface Guide for more information. The command can be accessed and executed by operators with link privileges.

show log: See IHUB System Basics, Management and OAM Guide for more information. The command can be accessed and executed by operators with log privileges.

show core1-uptime: See IHUB System Basics, Management and OAM Guide for more information. The command can be accessed and executed by operators with oam privileges.

show ip: See IHUB configuration Guide for more information. The command can be accessed and executed by operators with service privileges.

show qsfp-port-mode: See IHUB configuration Guide for more information. The command can be accessed and executed by operators with service privileges.

show test-oam: See IHUB configuration Guide for more information. The command can be accessed and

executed by operators with service privileges.

show eth-ring: See IHUB Services Guide for more information. The command can be accessed and executed by operators with oam privileges.

admin software-mngt ihub database oam-save-protected: See IHUB System Basics, Management and OAM Guide for more information. The command can be accessed and executed by operators with oam privileges.

admin save: See IHUB System Basics, Management and OAM Guide for more information. The command can be accessed and executed by operators with oam privileges.

admin display-config: See IHUB System Basics, Management and OAM Guide for more information. The command can be accessed and executed by operators with oam privileges.

admin enable-tech: See IHUB System Basics, Management and OAM Guide for more information. The command can be accessed and executed by operators with oam privileges.

ping: See IHUB Router Configurations and Routing Protocols Guide for more information. See IHUB MPLS Guide for more information on mpls and ldp. The command can be accessed and executed by operators with service privileges.

traceroute: See IHUB Router Configurations and Routing Protocols Guide for more information. See IHUB MPLS Guide for more information on mpls and ldp. The command can be accessed and executed by operators with service privileges.

debug: For more information about the debug commands, refer the IHUB Guides of the respective domain. The command can be accessed and executed by operators with debug privileges.

monitor filter: See IHUB System Basics, Management and OAM Guide for more information. The command can be accessed and executed by operators with filter privileges.

monitor router: See IHUB System Basics, Management and OAM Guide for more information. The command can be accessed and executed by operators with service privileges.

monitor port: See IHUB System Basics, Management and OAM Guide for more information. The command can be accessed and executed by operators with link privileges.

monitor lag: See IHUB System Basics, Management and OAM Guide for more information. The command can be accessed and executed by operators with link privileges.

monitor service: See IHUB System Basics, Management and OAM Guide for more information.

tools: See IHUB System Basics, Management and OAM Guide for more information. The command can be accessed and executed by operators with oam privileges.

mtrace: See IHUB Router Configurations and Routing Protocols Guide for more information. The command can be accessed and executed by operators with service privileges.

mrinfo: See IHUB Router Configurations and Routing Protocols Guide for more information. The command can be accessed and executed by operators with service privileges.

mstat: See IHUB Router Configurations and Routing Protocols Guide for more information. The command can be accessed and executed by operators with service privileges.

oam: See IHUB System Basics, Management and OAM Guide for more information. The command can be accessed and executed by operators with oam privileges.

clear alarm: See IHUB System Basics, Management and OAM Guide for more information. The command can be accessed and executed by operators with alarm privileges.

clear filter: See IHUB Router Configurations and Routing Protocols Guide for more information. The command can be accessed and executed by operators with filter privileges.

clear lag: See IHUB Interface Guide for more information. The command can be accessed and executed by operators with link privileges.

clear log: See IHUB System Basics, Management and OAM Guide for more information. The command can be accessed and executed by operators with log privileges.

clear port: See IHUB Interface Guide for more information. The command can be accessed and executed by operators with link privileges.

clear qos-service-router: See IHUB System Basics, Management and OAM Guide for more information. The command can be accessed and executed by operators with alarm privileges.

clear sliding-win-stats: See IHUB Qos Guide for more information. The command can be accessed and executed by operators with link privileges.

clear router: See IHUB Router Configurations and Routing Protocols Guide for more information. See IHUB MPLS Guide for more information on mpls and ldp. The command can be accessed and executed by operators with service privileges.

clear service: See IHUB Services Guide for more information. The command can be accessed and executed by operators with service privileges.

233- DPOE Commands

Description

This chapter gives an overview of all DPOE commands with a reference to the document where the exact syntax and description of the command can be found

Commands

234- Global And Environmental Commands

234.1 History Command	234-7330
234.2 Echo Command	234-7331
234.3 Telnet Command	234-7332
234.4 Telnet AI Command	234-7333
234.5 Exec Command	234-7334
234.6 Sleep Command	234-7336
234.7 Tree Command	234-7337
234.8 Write Command	234-7338
234.9 Logout Command	234-7339
234.10 Help Command	234-7340
234.11 Info Command	234-7341
234.12 Exit Command	234-7344
234.13 Back Command	234-7345
234.14 Delete Command	234-7346
234.15 In Command	234-7347
234.16 Configure Command	234-7348
234.17 Action Command	234-7350
234.18 Show Command	234-7351
234.19 Recursive Show Command	234-7352
234.20 Sample Command	234-7353
234.21 Poll Command	234-7354
234.22 Debug Command	234-7355
234.23 Sysfil Command	234-7356

234.1 History Command

Command Description

This command displays the last commands entered at the terminal.

A maximum of 20 commands can be stored. A command that is identical to the previous command is not stored.

Commands containing syntax and semantic errors are also stored in the history buffer. This way a user can correct a command without retyping the command completely.

Each command is preceded by a sequence number.

The sequence number does not increment when a command is not stored because it is identical to the previous command.

Example :

```
esam># history
1 : history
esam># echo "first command"
first command
esam># echo "second command"
second command
esam># echo "second command"
second command
esam># history
1 : history
2 : echo "first command"
3 : echo "second command"
4 : history
esam>#
```

User Level

The command can be accessed by operators with allAccess,allAccessext privileges.

This command can be executed by all users.

Command Syntax

The command has the following syntax:

> history

234.2 Echo Command

Command Description

This command echoes a string to the standard output.

User Level

The command can be accessed by operators with allAccess,allAccessext privileges.

This command can be accessed by any user.

Command Syntax

The command has the following syntax:

```
> echo [ [ no ] message ]
```

Command Parameters

Table 234.2-2 "Echo Command" Command Parameters

Options	Type	Description
[no] (message)	Format: - a long message - length: x<=512	<i>optional parameter with default value: ""</i> the string to be echoed

234.3 Telnet Command

Command Description

This command establishes a telnet session to another server.

*The telnet session will last until the connection is closed by the telnet server or when the operator enters the character **Control-^**.*

The session inactivity-time protection will not put any messages on the screen when you are executing the telnet command. Your connection will be broken without warning if the inactivity timeout expires.

User Level

The command can be accessed by operators with lanxAccess,lanxAccessext privileges.

This command can only be executed by users having read or write access to functions located in the SHub/IHub.

The command can only be executed from a telnet terminal, not from a craft terminal.

Command Syntax

The command has the following syntax:

> telnet (destination)

Command Parameters

Table 234.3-2 "Telnet Command" Command Parameters

Options	Type	Description
(destination)	Format: shub Possible values: - shub : the service hub (shub or ihub)	<i>optional parameter</i> identification of the telnet server

234.4 Telnet AI Command

Command Description

This command establishes a telnet session to the Application Intelligence platform (core2&3 on NANT-E or FANT-F).

The telnet session will last until the connection is closed by the telnet server or when the operator exits from the telnet session.

The session inactivity-time protection will not put any messages on the screen when you are executing the telnet command. Your connection will be broken without warning if the inactivity timeout expires.

User Level

The command can be accessed by operators with allAccess,allAccessext privileges.

The command can be executed from a craft terminal or a telnet terminal.

Command Syntax

The command has the following syntax:

```
> telnet-ai (destination) [ virtualplatform <AI::VirtualPlatform> ]
```

Command Parameters

Table 234.4-2 "Telnet AI Command" Command Parameters

Options	Type	Description
(destination)	Format: (nt-a nt-b) Possible values: - nt-a : the ai platform (core2-3) on NT-a - nt-b : the ai platform (core2-3) on NT-b	<i>optional parameter</i> identification of the telnet server
virtualplatform	Parameter type: <AI::VirtualPlatform> Format: - AI Virtual Platform Index within the Slot - range: [1]	<i>optional parameter</i> identification of the virtual platform

234.5 Exec Command

Command Description

This command executes CLI commands found in a text file. A file containing CLI commands is called a script file.

A script file must follow the same syntax rules as commands entered interactively. Only the tab and the question mark lose their special meaning in a script, so command expansion and single-line help are not available.

When initiating the execution of a script, the operator can choose how the system must behave in case of an error in a CLI command. By default the script will be aborted. Other command-line options are: ignore the error and proceed executing the script or prompt the operator. When prompted the operator can choose to either abort the script or ignore the error and proceed. When prompted due to an error, the operator may wish to open a separate CLI session to take some corrective action for the failed command and then revert to the session where the script is running to continue with the next command.

A command may be preceded by a minus '-' to prevent the script from being aborted in case of a semantic error; for example, when you try to delete a node instance that does not exist. In case a minus-sign precedes the command and the error is a semantic error, then the operator will not be prompted.

*By default, a command script does not interact with the user. The execution of the script will be aborted if a command or filter requires interaction with the user. Interactivity can be enabled by specifying the **interactive** option with the **exec** command.*

*The **exec** command may not be used in a command script, so command scripts may not be nested.*

*Script files are typically stored in the **/var/cmd** directory.*

*A script file can be used to restore a configuration. This can be done by reloading an initial and working configuration script. Alternatively, the complete configuration of an existing system can be captured. A configuration script is produced by means of the command **info configure <configuration node> | tee <script name>** and the script is stored in file **/var/cmd/<script name>**. Subsequently, the retrieved file needs editing as the output is not guaranteed to be in line with the CLI sequences required to configure a new system. The configuration can then be restored on an empty system with the command **exec /var/cmd/<script name>**.*

*Warning: the **/var/cmd** is cleaned when the system resets, so the configuration file must be transferred to another system with **tfpt** before resetting the system.*

Note: saving and restoring the configuration will not work for areas in which resource identifiers are assigned dynamically by the system.

User Level

*The command can be accessed by operators with **allAccess,allAccessext** privileges.*

This command can be executed by all users. However, the execution of the script will be aborted when the CLI parser tries to execute the first command in the script for which the user does not have authorization.

Command Syntax

The command has the following syntax:

```
> exec (filename) [ [ no ] interactive ] [ no at-replay | at-replay <Option::AtFailure> ]
```

Command Parameters

Table 234.5-2 "Exec Command" Command Parameters

Options	Type	Description
(filename)	Format: - an absolute or relative path name (example : /var/log) - range: [.-z-] - length: 1<=x<=128	<i>optional parameter</i> the name of the file with the script
[no] interactive	Parameter type: boolean	<i>optional parameter</i> interaction with the operator is allowed
[no] at-replay	Parameter type: <Option::AtFailure> Format: (stop continue prompt) Possible values: - stop : stop execution of the script - continue : continue with the execution of the script - prompt : prompt the operator what to do	<i>optional parameter with default value: "stop"</i> directs what to do if error is encountered in the script

234.6 Sleep Command

Command Description

This command pauses the execution for the specified number of seconds.

*This command is typically used in scripts (see : the **exec** command).*

User Level

*The command can be accessed by operators with **allAccess,allAccessext** privileges.*

This command can be executed by any user.

Command Syntax

The command has the following syntax:

> sleep (time)

Command Parameters

Table 234.6-2 "Sleep Command" Command Parameters

Options	Type	Description
(time)	Format: - the period to sleep - unit: sec - range: [1...100]	<i>optional parameter</i> the period to sleep

234.7 Tree Command

Command Description

This command displays the structure of a node and its subnodes.

User Level

The command can be accessed by operators with allAccess,allAccessext privileges.

This command can be executed by any user on a node to which he has read or write access.

The output does not contain any information related to subnodes to which the user has no access.

Command Syntax

The command has the following syntax:

```
> tree [ [ no ] detail ]
```

Command Parameters

Table 234.7-2 "Tree Command" Command Parameters

Options	Type	Description
[no] detail	Parameter type: boolean	<i>optional parameter</i> show the details

234.8 Write Command

Command Description

This command writes a message to the terminal of the addressee.

The message can be directed to a user, all user with the same user profile or to all users.

Messages are only delivered to users that are logged in. Users that are not logged in, will not receive the message.

The sender will also receive the message if it is one of the addressees.

User Level

The command can be accessed by operators with allAccess,allAccessext privileges.

This command can be used by any user.

Command Syntax

The command has the following syntax:

> write to <Option::MessageDestination> (message)

Command Parameters

Table 234.8-2 "Write Command" Command Parameters

Options	Type	Description
to	Parameter type: <Option::MessageDestination> Format: (all operator : <Sec::OperatorName> profile : <Sec::ProfileName>) Possible values: - all : all active sessions - operator : all sessions of the operator with that name - profile : all sessions of operators with that profile name Field type <Sec::OperatorName> - the name of an operator - range: [a-z0-9+] - length: 1<=x<=11 Field type <Sec::ProfileName> - the name of an operator profile - range: [a-z0-9] - length: 1<=x<=11	<i>optional parameter</i> the destination of the message
(message)	Format: - a message - length: x<=256	<i>optional parameter</i> the message

234.9 Logout Command

Command Description

This command logs the user out.

User Level

The command can be accessed by operators with allAccess,allAccessext privileges.

This command can be executed by any user.

Command Syntax

The command has the following syntax:

> logout

234.10 Help Command

Command Description

This command gives the user detailed information on a subject.

By default the command gives information on the current node.

User Level

The command can be accessed by operators with forHelp,forHelpext privileges.

This command can be executed by each user. A user will only be able to get help for nodes for which he has read or write access.

Command Syntax

The command has the following syntax:

> help

234.11 Info Command

Command Description

This command shows the configuration of the current node and all of its subnodes.

The user can select three different output formats:

- The default is hierarchical command format.
- An other format is the flat command format. The output in this format can be saved in a file with the **tee** filter and can be executed with the **exec** command. This way a saved configuration can be restored on an empty system.
- The other format is XML. The output in this format is much more suited as input for tools because it is less sensitive to further changes.

Example of the default format :

```
esam>configure>system>security# info profile
configure system security
#-----
echo "system"
#-----
profile admin
  prompt "%n%d%c "
  terminal-timeout 30
  description "default administrator group"
  aaa write
  atm write
  alarm write
  dhcp write
  equipment write
  igmp write
  ip write
  ppoe write
  qos write
  software-management write
  transport write
  vlan write
  xdsl write
  security write
exit
profile read
  prompt "%n%d%c "
  security read
exit
#-----
```

Example of the flat command format :

```
esam>configure>system>security# info profile flat
configure system security profile admin prompt "%n%d%c " terminal-timeout 30
description "default administrator group" aaa write atm write alarm write dhcp write
equipment write igmp write ip write ppoe write qos write software-management write
transport write vlan write xdsl write security write
configure system security profile read prompt "%n%d%c " security read
```

Example of the XML format :

```
esam>configure>system>security# info profile read xml
<?xml version="1.0" encoding="UTF-8"?>
<configuration-data display-level="normal">
  <hierarchy name="configure" type="static">
    <hierarchy name="system" type="static">
      <hierarchy name="security" type="static">
        <hierarchy name="profile" type="dynamic">
          <hier-id name="name" is-named="no" value="read" is-default="no"
type="Sec::ProfileName"/>
          <instance>
            <parameter name="prompt" is-default="no" type="Sec::Prompt">"%n%d%c
"/>
            <parameter name="password-timeout" units="days" is-default="yes"
type="Sec::PasswordTimeout">0</parameter>
            <parameter name="terminal-timeout" units="minutes" is-default="yes"
type="Sec::InactivityTimeout">0</parameter>
```

```

    <parameter name="description" is-default="yes"
type="Sec::ProfileDesc"></parameter>
    <parameter name="aaa" is-default="yes" type="Sec::Aaa">none</parameter>
    <parameter name="atm" is-default="yes" type="Sec::Atm">none</parameter>
    <parameter name="alarm" is-default="yes"
type="Sec::Alarm">none</parameter>
    <parameter name="dhcp" is-default="yes" type="Sec::Dhcp">none</parameter>
    <parameter name="equipment" is-default="yes"
type="Sec::Equipment">none</parameter>
    <parameter name="igmp" is-default="yes" type="Sec::Igmp">none</parameter>
    <parameter name="ip" is-default="yes" type="Sec::Ip">none</parameter>
    <parameter name="ppoe" is-default="yes" type="Sec::Ppoe">none</parameter>
    <parameter name="qos" is-default="yes" type="Sec::Qos">none</parameter>
    <parameter name="software-management" is-default="yes"
type="Sec::Sw">none</parameter>
    <parameter name="transport" is-default="yes"
type="Sec::Transport">none</parameter>
    <parameter name="vlan" is-default="yes" type="Sec::Vlan">none</parameter>
    <parameter name="xdsl" is-default="yes" type="Sec::Xdsl">none</parameter>
    <parameter name="cluster" is-default="yes"
type="Sec::Cluster">none</parameter>
    <parameter name="security" is-default="no"
type="Sec::Security">read</parameter>
</instance>
</hierarchy>
</hierarchy>
</hierarchy>
</hierarchy>
</configuration-data>
esam>configure>system>security#

```

The user can select two different output levels :

- The default is to show only the parameters which have not the default value. Static subnodes which contain (recursively) only default values are not shown. The XML format shows always all parameters.
- In the **detail** output level all nodes and all parameters shown. This output can not be used for replay.

Example of detailed information :

```

esam>configure>system>security# info profile read detail
configure system security
#-----
echo "system"
#-----
profile
  prompt "%n%d%c "
  no password-timeout
  no terminal-timeout
  no description
  no aaa
  no atm
  no alarm
  no dhcp
  no equipment
  no igmp
  no ip
  no ppoe
  no qos
  no software-management
  no transport
  no vlan
  no xdsl
  security read
exit
#-----
esam>configure>system>security#

```

User Level

The command can be accessed by operators with readAccess,readAccessext privileges.

This command can be accessed in all nodes to which the user has read access. It is not available in **admin** and **show** nodes or their subnodes.

The output will only contain information for the nodes for which the user has read access.

Command Syntax

The command has the following syntax:

```
> info [ [ no ] detail ] [ (format) ]
```

Command Parameters

Table 234.11-2 "Info Command" Command Parameters

Options	Type	Description
[no] detail	Parameter type: boolean	<i>optional parameter</i> show the details
(format)	Format: (hierarchical flat xml) Possible values: - hierarchical : show the output in hierarchical command format - flat : show the output in flat command format - xml : show the output in XML format	<i>optional parameter</i> the format in which the command output is printed

234.12 Exit Command

Command Description

This command changes the current position to the parent node of the current position. This command always succeeds, even if the current position is the top node. The command has no effect in this case.

*The option **all** changes the current position to the top node.*

User Level

*The command can be accessed by operators with **allAccess,allAccessext** privileges.*

This command can be executed by all users

Command Syntax

The command has the following syntax:

> exit [[no] all]

Command Parameters

Table 234.12-2 "Exit Command" Command Parameters

Options	Type	Description
[no] all	Parameter type: boolean	<i>optional parameter</i> set the current position to the top node

234.13 Back Command

Command Description

This command changes the current position to the previous position.

The command will always succeed, even if the previous position no longer exists. The command changes the current position to the top node in that case.

User Level

The command can be accessed by operators with `allAccess`, `allAccessext` privileges.

The command can be executed by all users.

Command Syntax

The command has the following syntax:

```
> back
```

234.14 Delete Command

Command Description

*This command deletes a file from the directory **/var/cmd**. Such file is typically created with the **tee** filter.
The command will always succeed, even if the specified file does not exist.*

User Level

*The command can be accessed by operators with **allAccess,allAccessext** privileges.
The command can be executed by all users.*

Command Syntax

The command has the following syntax:

> delete-file (file)

Command Parameters

Table 234.14-2 "Delete Command" Command Parameters

Options	Type	Description
(file)	Format: - a file name (example : errors.log) - range: [.0-z-] - length: 1<=x<=119	<i>optional parameter</i> the name of the file to be deleted

234.15 In Command

Command Description

*This command can not be directly executed by the operator. It is the default command for all nodes when no node attributes are specified, except for all subnodes of **configure** and the leaf nodes of **show**.*

This command changes the position in the command tree to the current node instance.

User Level

The command can be accessed by operators with readAccess,readAccessext privileges.

This command can be executed by any user for the nodes to which he has read or write access.

234.16 Configure Command

Command Description

This command can not be directly executed by the user. It is the default command for the **configuration** node and most of its subnodes.

This command serves four purposes :

- changing the current position in the command tree to a node instance.
- creating a node instance. The current position will be changed to the newly created node instance.
- modifying one or more attributes of a node instance. The current position in the command tree will be changed to the modified node instance.
- deleting a node instance.

The command changes the current position in the command tree to a node instance in case you specify an existing node instance and no parameters. Example : **configure equipment shelf 1/1**. The last character in the default prompt will be #.

The command creates a node instance in case the node is dynamic and the specified node instance does not exist. Example : **configure system security operator new_user password plain:"hallo#"**. Parameter values must be supplied for all mandatory parameters. Parameter values may be supplied for optional parameters. The command changes the current position in the command tree to the newly created node instance. The last character in the default prompt will be \$.

The command modifies the attributes of a node instance in case the node instance exists and if the user supplies parameters. Example : **configure system security operator existing_user description "a new description"**

The command will delete a node instance when it is a dynamic node and the node name is preceded by **no**. Example : **configure system security no operator existing_user**.

The command generates no output

Example 1 - change the current position to an existing static node :

```
esam# configure system security
esam>configure>system>security#
```

Example 2 - create a new dynamic node (note that one has to enter the mandatory parameters) :

```
esam>configure>system>security# operator new profile read password plain:&secret&
esam>configure>system>security>operator>new$
```

Example 3 - change an attribute :

```
esam>configure>system>security>operator>new$ description "just created"
esam>configure>system>security>operator>new$
```

Example 4 - change to an existing dynamic node (note that the prompt is different with example 2) :

```
esam>configure>system>security>operator>new$ back
esam>configure>system>security# operator new
esam>configure>system>security>operator>new#
```

Example 5 - delete a dynamic node

```
esam>configure>system>security>operator>new# back
esam>configure>system>security# no operator new
esam>configure>system>security#
```

Example 6 - go to the root

```
esam>configure>system>security# exit all
esam>#
```

Example 7 - request help for a non-existing static node, no parameters or subnodes will be shown

```
esam>#configure igmp channel 1/1/6/1 ?  
<CR>           : execute command  
esam>#configure igmp channel 1/1/6/1
```

Example 8 - go to a non-existing static node

```
esam>#configure igmp channel 1/1/6/1  
Error : port not available  
esam>#
```

User Level

The command can be accessed by operators with allAccess,allAccessext privileges.

A user can change the current position to each node to which he has read access.

A user can create, modify and delete nodes to which he has write access.

234.17 Action Command

Command Description

*This command can not be directly executed by the user. It is the default command for the **admin** node and most of its subnodes.*

This command serves two purposes :

- *changing the current position in the command tree to a node instance.*
- *executing an action.*

The command changes the current position in the command tree to a node instance in case you specify an existing node instance and no parameters. From the moment you specify a parameter it will try to execute the corresponding action.

User Level

The command can be accessed by operators with `allAccess`,`allAccessext` privileges.

A user can change the current position in the command tree to each node to which he has read access.

A user can execute the action in each node to which he has access.

234.18 Show Command

Command Description

This command shows the runtime data and eventually some important configuration data.

*This command can not be executed directly by the user. It is the default command for the leaf nodes of **show**. It shows the runtime data.*

When show data in no detail mode, if the length of parameter is too long for a table cell, an asterisk will be used to omit some character to fit the table cell length.

User Level

The command can be accessed by operators with readAccess,readAccessext privileges.

The user can execute this command for all nodes to which he has read access.

Command Parameters

Table 234.18-2 "Show Command" Command Parameters

Options	Type	Description
[no] detail	Parameter type: boolean	<i>optional parameter</i> show the details
[no] xml	Parameter type: boolean	<i>optional parameter</i> show the output in XML format

234.19 Recursive Show Command

Command Description

This command shows the runtime data and eventually some important configuration data.

*This command can not be executed directly by the user. It is the default command for some leaf nodes of **show**. It shows the runtime data in a recursive way (similar to **info**).*

User Level

The command can be accessed by operators with readAccess,readAccessex privileges.

The user can execute this command for all nodes to which he has read access.

Command Parameters

Table 234.19-2 "Recursive Show Command" Command Parameters

Options	Type	Description
[no] detail	Parameter type: boolean	<i>optional parameter</i> show the details
[no] xml	Parameter type: boolean	<i>optional parameter</i> show the output in XML format

234.20 Sample Command

Command Description

This command executes a test and shows the test result.

*This command can not be executed directly by the user. It is the default command for some leaf nodes of **show**. It shows the final test results.*

User Level

The command can be accessed by operators with readAccess,readAccessex privileges.

The user can execute this command for all nodes to which he has read access.

Command Parameters

Table 234.20-2 "Sample Command" Command Parameters

Options	Type	Description
[no] detail	Parameter type: boolean	<i>optional parameter</i> show the details
[no] xml	Parameter type: boolean	<i>optional parameter</i> show the output in XML format

234.21 Poll Command

Command Description

*This command can not be directly executed by the user. It is the default command for some leaf nodes in **show**.*

This command starts a test and displays at regular time intervals during the specified time period the intermediate results of the test.

*The difference between **poll** and **sample** command is that, in **poll** command the intermediate results are shown while in **sample** command only the final results are shown.*

User Level

The command can be accessed by operators with writeAccess,writeAccessext privileges.

Command Parameters

Table 234.21-2 "Poll Command" Command Parameters

Options	Type	Description
[no] detail	Parameter type: boolean	<i>optional parameter</i> show the details
[no] xml	Parameter type: boolean	<i>optional parameter</i> show the output in XML format
[no] sample-interval	Parameter type: <Option::SampleInterval> Format: - the time between two samples - unit: sec - range: [1...60]	<i>optional parameter with default value: 1</i> the time between 2 samples
[no] number-of-samples	Parameter type: <Option::SampleCount> Format: (unlimited <Option::SampleCount>) Possible values: - unlimited : sampling continues until stopped by the user Field type <Option::SampleCount> - the number of samples to be taken - range: [1...1000]	<i>optional parameter with default value: "unlimited"</i> the number of samples to be taken

234.22 Debug Command

Command Description

This command shows the runtime data and eventually some important configuration data.

*This command can not be executed directly by the user. It is the default command for the leaf nodes of **debug**. It shows the runtime data.*

User Level

*The command can be accessed by operators with **allAccess**,**allAccessext** privileges.*

The user can execute this command for all nodes to which he has read access.

Command Parameters

Table 234.22-2 "Debug Command" Command Parameters

Options	Type	Description
[no] xml	Parameter type: boolean	<i>optional parameter</i> show the output in XML format

234.23 Sysfil Command

Command Description

This command shows the syslog files and its contents in CLI session.

*It is the default command for the leaf nodes of **show system syslog list files and show system syslog file name filter options**. It shows the runtime data. Only xml option is supported for this handler type.*

User Level

The command can be accessed by operators with allAccess,allAccessext privileges.

The user can execute this command for show system syslog list/file nodes to which he has security read access.

Command Parameters

Table 234.23-2 "Sysfil Command" Command Parameters

Options	Type	Description
[no] xml	Parameter type: boolean	<i>optional parameter</i> show the output in XML format

235- CLI Filters

235.1 Count Filter	235-7358
235.2 Match Filter	235-7359
235.3 Tee Filter	235-7361
235.4 Tee Config Filter	235-7362

235.1 Count Filter

Command Description

This filter counts the number of output characters, words or lines and adds this information at the end of the output.

User Level

This filter can be used by any user.

Command Syntax

The command has the following syntax:

```
> count [ [ no ] lines ] [ [ no ] words ] [ [ no ] characters ] [ [ no ] summary ]
```

Command Parameters

Table 235.1-2 "Count Filter" Command Parameters

Parameter	Type	Description
[no] lines	Parameter type: boolean	<i>optional parameter</i> counts the number of lines
[no] words	Parameter type: boolean	<i>optional parameter</i> counts the number of words
[no] characters	Parameter type: boolean	<i>optional parameter</i> counts the number of characters
[no] summary	Parameter type: boolean	<i>optional parameter</i> only the lines with the count summary are printed

235.2 Match Filter

Command Description

This filter allows the user to filter selectively lines from the output based on the contents of these lines.

The user specifies a string with **exact:**.

The user can specify multiple search strings separated by pipe character | with **exact:**. The search for multiple strings is similar to **OR** condition.

User can search for any one of the strings (**alarm, trap, qos, vlan**) in the CLI output as follows: **info configure flat | match exact:alarm|trap|qos|vlan**.

User can search for string (**wel|come**) in the CLI output as follows: **info configure flat | match exact:wel|come**.

User can search for string (**welcome**) in the CLI output as follows: **info configure flat | match exact:\\welcome**.

User can search for string ("**welcome**") in the CLI output as follows: **info configure flat | match exact:"\\welcome"**.

User can search for any one of the strings (**wel|come, \\nokia**) in the CLI output as follows: **info configure flat | match exact:wel|come|\\nokia**.

User can specify the same within double quotes as follows: **info configure flat | match exact:"wel|come|\\nokia"**.

Refer Printable Strings under Chapter 1.5 Parameters for more information.

He can then decide if a line that contains this string is kept (**no skip**) or discarded (**skip**) or he can use the filter to keep all lines before the first match (**before**) or after (including) the first match (**after**).

The matching operation can be case-sensitive (**no case-insensitive**) or case-insensitive (**case-insensitive**).

User Level

This filter can be used by any user.

Command Syntax

The command has the following syntax:

```
> match (pattern) [ [ no ] case-insensitive ] [ [ no ] skip ]
```

Command Parameters

Table 235.2-2 "Match Filter" Command Parameters

Parameter	Type	Description
(pattern)	Format: exact : <PrintableString> Possible values: - exact : exact:<PrintableString> strings to be matched. multiple search strings can be separated with pipe ' '. use backslash followed by backslash and backslash followed by pipe to search for backslash and pipe respectively. check	<i>optional parameter</i> describes what needed(exact: pattern:)<PrintableString>

235 CLI Filters

Parameter	Type	Description
	online cli guide for more information. Field type <PrintableString> - printable string	
[no] case-insensitive	Parameter type: boolean	<i>optional parameter</i> matching is case-insensitive
[no] (skip)	Format: (skip match before after) Possible values: - skip : matched lines are skipped - match : matched lines are selected - before : lines found before the first match are selected - after : lines found after the first match are selected	<i>optional parameter with default value: "match"</i> matched lines are skipped

235.3 Tee Filter

Command Description

This filter writes the output also to a file. The file will be placed in the directory `/var/cmd`.

The user can decide if the output must be appended to the file or not.

User Level

This filter can be used by any operator.

Command Syntax

The command has the following syntax:

```
> tee (file) [ [ no ] append ]
```

Command Parameters

Table 235.3-2 "Tee Filter" Command Parameters

Parameter	Type	Description
(file)	Format: - a file name (example : info.log) - range: [a-zA-Z0-9-_.] - length: 1<=x<=13	<i>optional parameter</i> the name of the file
[no] append	Parameter type: boolean	<i>optional parameter</i> append if the file exists

235.4 Tee Config Filter

Command Description

*This filter writes the output also to a file. The file will be placed in the directory `/data/config`.
The user can decide if the output must be appended to the file or not.*

User Level

This filter can be used by any operator.

Command Syntax

The command has the following syntax:
> tee-config (file) [[no] append]

Command Parameters

Table 235.4-2 "Tee Config Filter" Command Parameters

Parameter	Type	Description
(file)	Format: - a file name (example : info.log) - range: [a-zA-Z0-9-_.] - length: 1<=x<=13	<i>optional parameter</i> the name of the config-file
[no] append	Parameter type: boolean	<i>optional parameter</i> append if the file exists

236- CLI Printers

236.1 More
236.2 No-More
236.3 Discard

236-7364
236-7365
236-7366

236.1 More

Command Description

This printer allows the user to see the command output at the pace he wants.

User Level

This printer can be used by any user.

Command Syntax

The command has the following syntax:

> more

236.2 No-More

Command Description

This printer prints all output directly to the screen.

User Level

This printer can be used by any user.

Command Syntax

The command has the following syntax:

> no-more

236.3 Discard

Command Description

This printer discards all output. This can be usefull in some scripts.

User Level

This printer can be used by any operator.

Command Syntax

The command has the following syntax:

> discard

Index

A B C D E F G H I J K L M N O P Q R S T U V W X Y Z

A

a43	470	aggr-dsq-profile	945
a43c	470	aggrqueuesconfig	903
aaa	731	aggr-reprt-shaper	1172
aal5-encap-type	601	aggr-usq-profile	945
accept-master	675	aging-time	979
access	821	ai	731
access-held-time	1203	ais-sensitivity	662
accessontimeout	1216	ais-to-iwf	339
access-oper-id	628	ais-to-liu	339
accessport-svc	6880	aka-secret-key	1216
access-type	1215	alarm	166
acc-interval	773	alarm-changes	2207
ac-code-prof	1483	alarmflag	1880
acc-router-inst	775	alarmid	223
acc-server	769	alarm-profile	312
acc-stats	6962	alarm-profile-name	401
acl	1528	alarm-table	3622
act-caller-id	1468	alert-tone	1406
act-dnd	1468	alias	1883
act-estab-call	1280	alien-bkgtestinterval	7158
action	710	alien-bkgtestmode	7158
action-type	1243	alien-mantestmode	7158
activate	841	alive-timer	1172
activate-chpair	7239	alm-ctrl	363
activate-type	1312	altitude-error	1878
active-groups	5901	alt-pref-ch-pair	354
active-heartbeat	1322	announce-interval	676
active-remote-mep	1555	announce-type	1446
actor-port-prio	1617	anonymous-block	1449
act-stable-call	1280	ansi	6129
actual-ptm-init-mode	5699	answer	1289
address	1191	anti-tapping	1216
addrtype	1846	aor-host-prt-prof	1475
admin-domain-name	1191	apipe-pvc	1858
admin-label	1778	apipe-sdp	1857
admin-p2p	1627	appl-bitmap	1296
adminstate	1634	application	1633
admin-state	354	applique	315
adminstatus	1900	applique-profile	315
admin-status	317	app-serv-prof	1483
admin-up	1708	app-type	1903
adsl2-plus	457	area-code	1346
adsl-adsl2	452	arp-burst	920
adsl-band	463	arp-polling-inter	628
agc-offset	1721	arp-polling-ip	979
ageing-time	1010	arp-rate	920
		arp-relay-stats	7286
		arp-tca-threshold	628
		artificial-noise-down	450

Index

asam-id	1308	auto-srv-fo-timer	1233
associate-vlan	1626	auto-switch	711
association	1545	auto-upload	807
assu-burst-size	914	auto-verify	841
assured-info-rate	914	aut-s-unreach-act	766
at	379	availability	6002
atm	731	avail-sess	6801
atm-based-dsl	655	awaiting-time	1203
atm-overhead-fact	856		
atm-pvc	613	B	
attend-call-trans	1468		
audible1	282	b43	470
audible2	282	back	7345
audible3	282	backup	845
audible4	282	backupv6	845
audible5	282	bad-headers-down	367
authen-server	778	band-control-dn	506
authentication	753	band-control-up	506
authenticator	787	bandwidth	914
auth-id	401	bandwidth-profile	945
auth-key	7013	bandwidth-sharing	945
auth-key-status	7014	base-termid	1487
auth-method	1643	battery-bkup	354
auth-mode	1814	baud-rate	693
author-server	780	b-chan-id	6453
authproto	1111	bc-scheduler-node	945
auth-pwd	401	ber-calc-period	1652
auth-router-inst	775	berint	354
auth-sec-prof	1384	ber-interval	7221
auth-securi-prof	1386	ber-stats	5722
auth-server	767	ber-test	7221
auth-stats	6959	ber-testpattern	7221
auth-type	803	bfd	3540
auto-adv-abili	415	bg-monitor-int	1233
auto-answer	1216	bg-monitor-method	1233
auto-backup-intvl	845	bgn-time	728
autoboot-config	6072	bgp	3440
auto-detect	411	bias-alm-high	327
autofetch	841	bias-alm-low	327
auto-laser-shutdown	710	bias-warn-high	327
autoneg1000t	415	bias-warn-low	327
autoneg1000tfd	415	bit-len	1924
autoneg1000x	415	bitrate	1538
autoneg1000xfd	415	bits	665
autoneg100t2	415	bits-a-bind	708
autoneg100t2fd	415	bits-b-bind	708
autoneg100t4	415	bits-bind	708
autoneg100tx	415	bkgpatternmode	7158
autoneg100txfd	415	bkgroguetestinterval	7158
autoneg10t	415	bkgstucklasermode	7158
autoneg10tfd	415	blind-call-trans	1468
auto-port-reset	524	block	1289
auto-pwr-ctl	1761	blocking-bitmap	1285
auto-server-fb	1233	board	518
auto-server-fo	1233	board-40gkr4	312
autoshape	912	boardautoreplan	349
auto-sos-fb	1233	board-id	6483
auto-sos-fo	1233	board-index	2803

board-iwf-info	6854	call-query	1303
board-perfinfo	6421	call-query-result	6481
bonding-group	2828	call-transfer	1449
bonding-mode	528	calltras-service	1216
bonding-rate-mode	1155	callwait1-tone	1398
branch	1091	callwait2-tone	1400
bras-ip-address	1172	callwait3-tone	1402
bridge	1010	callwait4-tone	1404
bridge-map-mode	354	call-waiting	1449
bridgeport	1545	callwait-service	1216
bridge-port	5595	cancel-call-wait	1468
bridge-port-fdb	5268	canonical-format	886
bridge-prof	1449	cap	1292
brr-pkt-loss-th	1376	capab-profile	312
bsnap-server-ip	628	capacity	1077
bsnap-server-port	628	cap-id	1294
bsnap-state	628	cap-name	1285
bucket-up	411	carrier-data-mode	528
buffer-occ-thresh	931	carrier-mask-down	444
bulk-sync	3573	carrier-mask-up	444
burst-overhead	1652	cas-cpn-screen	1258
burst-size	860	cas-default-cpc	1258
busyoverwrite	1216	cas-event	1444
busy-overwrite	1600	cas-exch-type	1250
busy-status	6830	cas-nsm-prof	1278
busy-tone	1396	cas-nsm-profile	1250
bw-alarm-thresh	1761	cas-r1-syntax	1195
bw-disconnect	1289	cas-r2-channel	4053
bw-disconnect-ack	1289	cas-r2-syntax	1195
bw-disc-reanswer	1289	cas-r2-timer	1269
bw-meter-interval	1811	cas-restrict-acc	1258
bw-th-dn	1575	cas-sig-prof	1285
bw-th-up	1575	cas-timer-prof	1296
		cas-timer-profile	1258
		ccm-admin-state	1545
		cc-max-age	1096
		ccm-interval	1545
		ccm-priority	1549
		cde-bitmap	6040
		cde-bitmap-extended	6041
		cdeprof	7079
		cdr-config	1247
		cdr-export	1062
		cdr-file-aging	1062
		cdr-max-delay	807
		cdr-max-timeout	807
		cdr-polling	1062
		cdr-type	1066
		cdr-validation	1062
		ces-class-time	1685
		cesds1-port	3053
		ces-port	3153
		cfg-download	2098
		cfg-res-time	1077
		cfm	1523
		cfm-burst	920
		cfm-mep-id	2600
		cfm-rate	920

C

cable-comp	691
cable-impedance	343
cac	869
cac-mode	856
cac-profile	937
cac-type	869
cage	617
calc-mode	5562
callconf-service	1216
callerid-announce	1449
caller-id-block	1449
caller-id-name	1449
caller-id-number	1449
call-fwd-indicate	1449
call-hist	1376
call-hist-num	6499
call-hold	1449
callhold-service	1216
calling-name	1449
calling-number	1449
call-park	1449
call-process	1269

Index

cf-usage	6038	command	7055
channel	336	committed-burst-size	882
channel-group	2104	committed-info-rate	882
channel-pair	1642	comm-para	1340
channelset	1357	community	747
channel-speed	1778	community-read	409
chipsetdata-for-slot	6829	community-write	409
chn	1081	compensation	676
chpair-active-groups	6260	conf-file-name	1369
chpair-pmcollect	1797	config-id-sel	1623
chpair-role-exch	7239	config-mode	1770
churn	419	configure	7348
churn-keyextime	419	configure-lock	7297
churn-time	419	confirm-tone	1416
circuit-id-dhcp	979	conf-method	1369
circuit-id-pppoe	979	conf-prof	1449
cir-dw	411	congest-tone	1414
cir-up	411	connection	1151
class	310	conn-policy	790
classac1	1822	conn-profile	789
classac2	1822	conn-profile-name	790
classac3	1822	conseq-number	336
classac4	1822	contact-person	628
classfandv1	1822	context	747
classfandv2	1822	controlled-port	792
classfandv3	1822	cos-threshold	882
classfandv4	1822	count	7212
clear	7322	counter	6152
clear-alarm	7164	counters	6892
clear-back-ack	1296	country-code	1275
clear-forward	1216	coupling-flag	882
clear-fw-ack	1296	cpe	603
clear-on-demand	7103	cpe-inventory	5515
cli	821	cpe-management	1149
client-id	1113	cpe-tuc-inventory	5675
client-index	6049	cpe-tur-inventory	5673
client-port	1103	cpi	1643
client-state	1770	cpn-screen	1250
clip-mode	1216	cpu-load	381
cli-session	726	crc	1895
clock	332	critical	2429
clock-accuracy	678	critical-timeout	1442
clockclass	695	crit-log-full-act	280
clock-class	678	cross-connect	5251
clock-mgmt	6031	cs-psd-shape-dn	477
clocksource	332	cs-psd-shape-up	477
closeportasovld	419	ctc	1155
closest-ont	1643	ctrl-pkt-policer	965
cluster	1305	cur-intvl-top-ont-rx	5758
cnf-msg-profid	1487	cur-intvl-top-ont-tx	5756
codec	1353	curr-15min-stats	6293
codec1st	1454	curr-1day-stats	6295
codec2nd	1454	curr-day-stats	6775
codec3rd	1454	current-15min	2170
codec4th	1454	current-15min-stats	5297
codepoint	874	current-1day	2174
co-inventory	5517	current-day-stats	5301
color-mode	882	current-interval	2055

custinfo	1376	decadic-break-dur	1296
cust-info	1511	decadic-pulse-dur	1296
custom	2837	defaultaid	2500
customer-id	613	default-config	7083
custom-ext-alarm	2675	default-cpc	1250
custom-profile	282	default-dataset	678
cust-psd-pt-down	461	default-dot1p	871
cust-psd-pt-up	485	default-dscp	872
cust-psd-sc-down	463	defaultgateway	1634
cust-psd-sc-up	477	default-priority	1011
cust-psd-ty-down	463	default-profile	738
cust-psd-ty-up	477	default-ql	696
cust-rx-psd-pt-up	474	default-router	1369
cust-rx-psd-sc-up	463	default-severity	614
cust-rx-psd-ty-up	463	default-tpid	1011
cvlan	409	definition	292
cvlan4095passthru	979	delay-act	379
cvlantrans-mode	354	delay-dial-max	1296
cwmp	6306	delay-dial-min	1296
		delay-interval	676
		delay-mechanism	676
		delay-opt-mode-ds	1134
		delay-tolerance	914
		delete-file	7346
		delete-version	7244
		delta-log	280
		del-upd-threshold	1233
		desc1	354
		desc2	354
		description	287
		description1	282
		description2	282
		description3	282
		description4	282
		description5	282
		descriptor-files	6112
		destination	764
		dest-ip	1318
		dest-mac	336
		dest-mac-address	1708
		dest-port	1318
		dest-udp-port	1357
		dhcp	731
		dhcp-authent-para	1243
		dhcp-burst	920
		dhcp-customer-id	1210
		dhcp-dscp	1742
		dhcp-fqdn	1210
		dhcp-l2-encaps	979
		dhcp-linerate	979
		dhcp-opt82-ext	979
		dhcp-opt82-nni	979
		dhcp-opt82-uplink	979
		dhcption60	1306
		dhcp-option82	1203
		dhcp-optreq-list	1197
		dhcp-rate	920
		dhcpr-vlanaware	979
d1p	871		
d1p-alignment	878		
d1p-dscp	877		
d1p-dscp-contract	875		
database	845		
data-bit	693		
data-class-time	1685		
data-jitter	1357		
data-length	1538		
data-store	2044		
date	637		
date-table	6097		
dbacongperiodhi	1673		
dbacongperiodlo	1673		
dbacongperiodmd	1673		
dbacongthresh	1673		
dba-polling0	1814		
dba-polling1	1814		
dba-polling2	1814		
dba-polling3	1814		
dba-polling4	1814		
dba-polling5	1814		
dba-polling6	1814		
dba-polling7	1814		
dbapollinglevel	419		
dbu	914		
deact-caller-id	1468		
deact-dnd	1468		
deactivate	7080		
deact-ont-tca	1679		
dead-interval	767		
dead-tone	1432		
debug	731		
debug-command	7308		
debugkernel	821		
debug-mirror	731		

Index

dhcp-server	1886	dns-ini-retr-int	1233
dhcpsipserver	6438	dns-max-retr-nbr	1233
dhcpv6-burst	920	dnsname-type	1191
dhcpv6-itf-id	979	dns-purge-timer	1233
dhcpv6-l2-encaps	979	dns-redun-mode	1233
dhcpv6-linerate	979	dnsserver	1241
dhcpv6-rate	920	domain	674
dhcpv6-relay-id	979	domain-name	789
dhcpv6-remote-id	979	do-not-disturb	1449
dhcpv6r-vlanaware	979	dot1p	1528
dhcpv6-trst-port	979	dot1-p0-color	916
diagnos-test	7221	dot1-p0-pol-tc	916
diagnostest-status	6898	dot1-p0-tc	916
diagnostic	7139	dot1-p1-color	916
diagnostics	5802	dot1-p1-pol-tc	916
dial-long-timer	1203	dot1-p1-tc	916
dialplan	1213	dot1-p2-color	916
dialplan-index	2738	dot1-p2-pol-tc	916
dial-short-timer	1203	dot1-p2-tc	916
dial-start-timer	1203	dot1-p3-color	916
dial-tone	1418	dot1-p3-pol-tc	916
dialtone-dely-opt	1449	dot1-p3-tc	916
diff-reach	1643	dot1-p4-color	916
digitmap	1215	dot1-p4-pol-tc	916
digitmap1	1442	dot1-p4-tc	916
digitmap2	1442	dot1-p5-color	916
digitmap3	1442	dot1-p5-pol-tc	916
digitmap4	1442	dot1-p5-tc	916
digitmap-mode	1213	dot1-p6-color	916
digit-map-prof	1335	dot1-p6-pol-tc	916
digit-send-mode	1203	dot1-p6-tc	916
dir-conn-feature	1449	dot1-p7-color	916
dir-conn-prof	1449	dot1-p7-pol-tc	916
direction	320	dot1-p7-tc	916
directory-number	1216	dot1p-priority	886
direct-uri	1216	dot1p-remark	880
discard	7366	dot1p-value	863
disconnect-ack	1269	dot3stats	6630
dis-frame-th	933	download	7069
disk-file	7074	download-set	841
display-name	1216	downloadadv6	7071
distance	343	down-policer	895
dist-service	1854	down-policy	900
disturber-line	5564	down-rtx-profile	575
dldstatus	6146	downstr-bw-thresh	1796
dmac	1538	downstream	5562
dmpm-intdgt-expid	1203	downstream-channel-id	1776
dn	1351	downstream-lambda	1776
dn-buf-thresh	931	dpbo-profile	495
dn-ctrl-pkt	971	dpcolor	858
dn-default-tc	895	dpinteg-threshold	1866
dnd-pin	1468	drly-srv-usr-side	979
dn-dscptotc-prof	895	dropped-frames-dn	583
dnload-cfgfile1	354	dropped-frames-up	583
dnload-cfgfile2	354	drouter	731
dn-obc-thresh	931	ds0-bitmap	1282
dn-pbittotc-prof	895	ds0-hunting-way	1258
dns-addr	1742	dscp	872

dscp-contract	873	ecid-tx	336
dscp-map-dot1p	863	efm-based-dsl	655
dscp-pbit	923	efm-based-epon	655
dscp-pbit-prof	878	efm-based-ngpon2	655
dscp-tc	925	efm-based-pon	655
dscp-value	874	efm-hs-sele	1155
ds-dedicated-q	1018	efm-oam	2608
dsfld-shaper-prof	945	egress-vc-label	1856
dslam-name	1172	elevation	1878
dsl-bandwidth	5348	ellid	3281
dsl-class-time	1685	ellid-index	3281
dsl-ctrl-pkt-policer	860	emergency	1468
dsl-line-port	3162	emergency-service	1351
dsload-thresh	931	emer-ser-org-hold	1449
dsl-port	937	emulation	5702
ds-num-queue	945	enable	1795
ds-num-rem-queue	945	enable-aes	354
ds-pbit-mode	1011	encap-type	1172
ds-rem-queue	961	encoding	1703
ds-schedule-tag	895	end-ip-addr	1081
dst	636	end-ipv6-addr	1085
dst-ip-addr	888	end-time	637
dst-ipv6-addr	888	engine	1098
dst-mac-addr	886	enterprise-number	979
dtmf-duration	1446	entry	168
dtmf-event	1444	envbox	347
dtmf-level	1446	environment	161
dtmf-sip-info	1203	eo-conversion	2820
dual-host-ip	312	eolt-ont-tca	5076
dual-host-loc	312	eoltrssi	3530
dual-parenting	7225	eont-phyoam	5064
dup-fdb-id	5278	eont-services-lan	5070
dup-mac	5278	eont-sw-dl	5082
dup-mac-alarm	5278	ephe-term-max	1322
duration	695	ephe-term-min	1322
dynamic-update	670	ephe-term-prefix	1322
dyn-auth-client	771	epipe	3405
dyn-authclient-stats	6966	epon	661
dyn-pt-nego-type	1203	epon-id	3530
E		epsd-pt-down	499
e1	4057	eps-quenchfactor	317
e1-cluster-itf	1250	eqpt-holder	2509
e1-cluster-name	1250	eqpt-holder-ext	2518
e1-crc4frame	1285	eqpt-psu	3864
e1-hunting-way	1250	eqpt-supplemental	3188
e1itf-bchannel-status	6453	equal-fext	493
e1-sip-termination	4047	equipment	731
e1t1-interface	4051	error	621
eapol-stats	6986	error-frags-up	1659
ebias-alm-high	327	erx-alm-high	327
ebias-alm-low	327	erx-alm-low	327
ebias-warn-high	327	erx-warn-high	327
ebias-warn-low	327	erx-warn-low	327
echo	7331	esa-mgc-service	1322
echo-cancel	1353	es-cable-model-a	495
ecid-rx	336	es-cable-model-b	495
		es-cable-model-c	495
		es-day-farend	534

Index

es-day-nearend	534	facility	835
es-elect-length	495	fail-obs-timer	1233
es-farend	534	fail-x-type	1245
es-nearend	534	fanmode	348
etemp-alm-high	327	fan-tray	348
etemp-alm-low	327	far-end	550
etemp-warn-high	327	farend-ipinfo	1708
etemp-warn-low	327	fast-guard	1216
eth-cfm	3598	fastleave	401
eth-efm-fact	856	fault	1289
ether-dot3lt	6190	fax	1340
ether-ifindex	2634	fax-mode	1454
ether-ifmault	6185	fcs	1504
ether-ifsfp1t	6183	fcs-day	1504
ether-itf	2634	fcs-exceed	3889
ethernet	373	fdb	6653
ethernet-bandwidth	5352	fdb-board	5264
ethernet-ring	4378	fdbid	5319
ether-sfp	2933	fdb-id	5264
etherstats	6632	fdb-only-bit	7189
ether-tca	2924	fdxapause	415
ethertype	886	fdxbpause	415
eth-int	6628	fdxpause	415
eth-ring	3673	fdxspause	415
etsi	6130	feat-acccode-prof	1468
etx-alm-high	327	fec	401
etx-alm-low	327	fec-dn	1643
etx-warn-high	327	fec-tc-layer	371
etx-warn-low	327	fec-up	354
event-req-id	1322	fe-err-secs	580
evtocd	354	fe-sev-err-secs	580
exbrsize-up	411	fe-unavail-secs	580
exce-burst-size	914	fext-cancel-dn	506
except-cdr-rate	1062	fext-cancel-up	506
excess-burst-size	882	fg-intv-503	1233
excess-info-rate	882	fg-monitor-int	1233
excessive-info-rate	914	fg-monitor-method	1233
excess-jitter-th	1376	fifteen-min	5231
exec	7334	file-board-type	6123
exit	7344	filename	7101
expected-ckt-id	1708	file-name	6123
ext-authenticator	795	file-prof	1396
ext-bw	956	file-status	6142
ext-cac	945	filetransfer	802
extension	1258	fill-policy	1701
extensive	5246	filter	223
external-device	2658	filterid	223
external-leds	632	filter-type	888
external-link-assign	322	fips	715
external-link-host	320	fireware-version	1835
external-link-remote	1978	flag	1835
extline	1353	flag-alarm-state	1835
ext-redundancy-state	6425	flash-on-emer-cal	1449
ext-shaper	867	flush-mac	354
		fng-alarm-time	1549
		fng-reset-time	1549
		fo-hysteresis	1233
		force-autoswitch	7060
F			
f5-loopback-ete	7029		

force-hold	1216
force-measure	1600
force-reference	701
force-rel-ack	1269
forking	1049
format	689
forward-delay	1623
forward-port	990
frame	1703
frame-mode	339
framer	339
framing-mode	1895
freq1	1389
freq2	1389
freq3	1389
freq4	1389
frequency	450
frgn-ac-volt-th	7139
frgn-dc-volt-th	7139
ftp-passwd	1369
ftp-serv-ip-addr	1369
ftp-user-name	1369
fullview-packages	1054
fw-disconnect	1289
fw-disconnect-ack	1289
fxo-ip	1353
fxo-port	1353

G

gateway	409
gateway-addr	672
gateway-ddidn	1351
gateway-dn	1351
gateway-dn-type	1351
gateway-ip	1292
gem-sharing	945
general	1074
generate-auth-key	7095
generate-key	7094
generic-pon	1866
gen-on-demand	7101
ghstone-set-pwr-ctrl	470
ghstones-pwr-mode	463
gis	393
gis-check	1878
gis-digest	1878
gis-info	1878
global	931
global-session	1096
green-action	882
group	750
group-assembly-time	1132
groupid	1018
group-info	6845
group-name	756
group-opt	1600
group-profile	1134

group-rtx-profile	1137
group-rtx-profiles	5681
group-sampling	5564
grp-assembly-time	1134
grp-index	1168
grp-ip-addr	3180
grp-membership	6264
grp-to-package	6163
gsmp-retry-time	1172
gsmp-sub-version	1172
gsmp-version	1172
gw-id	1343
gw-ip	1583
gw-ip-addr	1585

H

handshake-period	795
hazard-ac-volt-th	7139
hazard-dc-volt-th	7139
heartbeat-count	1335
heartbeat-cycle	1335
heartbeat-mode	1335
hello-time	1623
help	7340
hgu-tr069	3853
hgu-tr069-cust	287
high	1681
high-clr	1681
high-jbfl	1224
history	7330
hold	1468
holdover-spec	695
hook-flash-max	1446
hook-flash-min	1446
hookstate	6517
horizontal-error	1878
host-address	747
host-id	978
host-report-intv	1062
hunting-way	1250
hw-status	6836
hw-version	388

I

iacm	7077
icid	6403
icmpv6-burst	920
icmpv6-rate	920
id	628
idle	1289
idlepwrta	1814
idlepwrthreshold	1814
idle-timeout	818
igmp	731
igmp-burst	920

Index

igmp-mode	401	interface	278
igmp-rate	920	interface-atm-pvc	5586
igmp-version	1049	interface-bandwidth	5354
ihub	7075	interface-port	5588
ihub-equip	3256	interfaces	6445
ihub-general	3273	interface-type	1285
ihub-ipv6	3448	internal-nw-vlan	628
ihub-l2forward	3206	international-prefix	1275
ihub-link	3247	interval	1559
ihub-tca	3630	interval-nbr	5726
ima-group	2906	interval-no	2069
ima-link	2915	interval-num	2057
impedance	1216	interval-number	5291
imp-noise-prot-dn	440	interval-type	807
imp-noise-prot-up	440	int-no	6333
in	7347	intrusion-tone	1430
inactive-timer	1600	int-traff-gen	6208
inactivity-time	1557	intvl-number	5235
inc-cgpn-add-ac	1275	inventory	6311
inc-from-clip-pri	1275	ip	409
inc-from-clip-ua	1275	ip_subnet	1914
inc-from-noclip	1275	ip-addr	672
inc-npi-to-cpn	1275	ip-address	634
inc-ton-to-cdpn	1275	ipaddressandmask	1634
inc-ton-to-cpn	1275	ipaddresstype	1634
indeterminate	2209	ip-addr-policy	1197
indet-log-full-action	280	ip-bridge-port	5620
index	2110	ip-config-mode	1197
info	7341	ip-cross-connect	603
information	5960	iphc-allowed	354
ing-outer-marker	895	iphc-vlan	1842
ingress-hw-filter	5346	ip-mode	421
ingress-profile	945	ip-net-to-media	7291
ingress-qos	916	ipsec-enable	1369
ingress-vc-label	1856	ipv4	1946
init-data-jitter	1203	ipv6	1944
init-reg-delay	1229	ipv6-active-groups	6248
in-mapped-vc	1858	ipv6-address	635
in-mapped-vpi	1858	ipv6-chn	1085
inm-cluster-cont	548	ipversion	1111
inm-eq-inp-mode	548	ip-version	1928
inm-equiv-inp-histo	5534	isam	346
inm-iat-histo	5533	isdn-cas-cls-puid	1271
inm-iat-offset	548	isdn-cas-itf	6445
inm-iat-step	548	isdn-cas-term	1250
inm-mode	548	isdn-codec	1312
inner-pbit-remark	1018	isdn-nsm-prof	1275
inp8-dn	440	isdn-nsm-profile	1250
inp8-up	440	isdn-suffix1	1322
input-profile	6547	isdn-suffix2	1322
in-qos-prof-name	979	isdn-syntax	1195
ins-sensitivity	548	isdn-term-format	1322
instance	1348	isis	3730
int-arr-time	593	isoethernet	415
int-arr-time-dn	501	itf-hunting-way	1258
int-arr-time-up	501	ivps-ip	1306
intercom	1468	iwf-group-info	6856
inter-digit-peri	1296	iwf-id	6854

iwf-on-liu	339	leftr-thresh	593
J		leftr-thresh-dn	501
jitter-buff-max	1701	leftr-thresh-up	501
jitter-buff-size	336	leg-upbo-profile	515
jitter-max	1446	level	1543
jitter-target	1446	li	812
K		li_vlan	1040
keep-alive-intvl	1538	liadmin	731
key	820	license	6024
key-identifier	1770	license-usage	6029
key-type	803	line	528
kill-debug	7107	line-coding	1895
L		line-feed	1216
l0-time	444	lineid	1593
l1-trans-statistics	6476	line-id	1216
l2	583	lineid-ext-rept	6808
l2-agpow-red-tx	444	lineid-syn-prof	1195
l2-agpow-to-red-tx	444	line-impedance	1895
l2cp	1171	line-length	1703
l2-encaps1	979	line-num	1589
l2-filter	886	linesig-remanswer	1216
l2forward	2582	line-status	1593
l2fwder-vlan	1018	link	731
l2-ptp-port	687	link-agg	3881
l2-time	444	link-port-compensation	685
l3-filter	888	link-speed	658
label	1369	link-state-trap	607
label-map	1848	link-up-changes	5525
lACP	731	linkup-record	5527
lag	3265	liu	343
lag-id	3265	liu-on-liu	339
lanx-port	1310	liuser	731
last-max-resp-tim	1062	livoice	731
last-memb-cnt	1062	lktype	7132
latitude	1878	lldpmed	731
layer2-oam	1172	lldp-med	1899
layer2-terminated	5261	llid	419
lbit-recv-policy	1701	llidpattern	401
lbn-data	7182	lm-init	1549
lbn-data-len	7182	lm-resp	1549
lbn-tlv-type	7182	load-sharing-policy	1618
ldp	3381	load-thresh	933
leapsecond	689	local-addr	6303
leapsecond-adjust-date	689	local-ip	1353
leapsecond-adjust-val	689	local-node	1914
learned-unicast-mac	7266	local-oam-info	6199
lease-time	1886	local-port	6303
leftr-day-farend	534	local-port-max	1444
leftr-day-nearend	534	local-port-min	1444
leftr-farend	534	location	628
leftr-nearend	534	log	731
		log-auth-id	354
		log-auth-pwd	354
		log-entry	6103
		log-full-action	166
		logical-flow-type	895
		login-banner	726
		login-failure	7026

Index

login-setting	726	mac-filter	813
logout	7339	mac-learn-ctrl	1018
log-sev-level	166	mac-mapping	2186
loid	2188	mac-max	411
loid-mapping	2188	mac-stats	6194
longitude	1878	maintenance-prof	1708
loop	391	major	2374
loop-attenuation	1160	major-log-full-action	280
loopback	411	management	409
loop-back	7221	manager	295
loopbackadmin	7252	manipulate-rule	1267
loop-backadmin	419	map-user-group	756
loopback-info	6206	margin-down-curr	1155
loopback-timeout	1160	margin-down-worst	1155
loop-detect	391	margin-up-curr	1155
loop-diagnostic	7060	margin-up-worst	1155
loop-id-syntax	655	marker	5329
loop-portautoshut	391	mask	409
loopportshut	411	master-group	6856
los	1504	master-iwf	1618
los-day	1504	master-mode	1725
loss-duration	1089	master-port	682
loss-thresh-alert	1089	match	7359
lost-frags-down	367	mau	1506
lost-frags-up	367	max-active-port	1618
low	1681	max-age	1623
low-clr	1681	max-agpowlev-down	452
lower	5992	max-agpowlev-up	452
lower-optical-th	1719	max-band	463
low-jbfl	1224	max-bitrate	1074
low-pri-defect	1549	max-bitrate-down	440
lpt-mode	1511	max-bitrate-up	440
lsa-md5-password	1197	max-cc	1103
lsa-md5-realm	1197	max-cells	1857
lsa-rtp-gw-ip	1197	max-committed-mac	1011
lsa-rtp-ip	1210	max-cvlan-id	1018
lsa-rtp-vlan-id	1197	max-data-jitter	1203
ls-migration	6133	max-delay	593
lsmredundancy	2565	max-delay-dn	501
lsp-name	1851	max-delay-down	440
lt-expect	526	max-delay-up	440
ltline	1593	max-delay-var-dn	440
ltm	7188	max-delay-var-up	440
ltm-filtering	1545	max-dot1p	999
lt-ont-signaling	1049	max-dst-port	888
ltparm	1595	max-exp-thrpt	593
ltsession	1589	max-exp-thrpt-dn	501
ltstrvalue1	1595	max-exp-thrpt-up	501
		max-freq	463
		max-frequency	495
		max-hop-count	1623
		max-instance-num	1623
		max-ip-antispoof	1018
		max-ipv6-antispf	1018
		max-line-rate	1155
		max-lt-link-speed	658
		max-mcast-bandwidth	869
		max-msg-rate	1049
mac	1113		
mac-addr	401		
mac-address	2186		
macage-time	401		
mac-authenticator	7001		
mac-diag	7304		
mac-diagnostics	7006		

M

max-net-rate	593	mdu-gen	3363
max-net-rate-dn	501	mdu-ploam	3353
max-net-rate-up	501	mdu-sup	3662
max-network-delay	1322	mdu-sup2	4224
max-noise-down	444	mean-bit-rate	1074
max-noise-up	444	measurement-intvl	1559
max-num-group	1049	media-gateway	1322
max-num-uncfg	1077	media-gateway-id	1312
max-out-udp-size	1231	media-ipmode	1203
max-pad-attempts	1096	media-policy	1903
max-payload-tag	1098	megaco	731
max-per-window	295	megaco-media-gw	2846
max-psd-down	452	megaco-plug-unit	2863
max-psd-up	452	megaco-sig-gw	2855
max-queue-size	295	megaco-sig-lt	2880
max-ranging-onts	1652	megaco-term	2871
max-rate-link1	1155	meg-level	1553
max-rate-link2	1155	melt-reset	6834
max-rate-link3	1155	melt-selftest	6832
max-rate-link4	1155	member-port	6848
max-recv-power-up	452	memory-down	440
max-reported-dist	5558	memory-usage	383
max-req	792	mem-query-int	1062
max-retrans	1322	mep	1549
max-retries	1487	meter	1289
max-retry-attempt	524	metering-type	1312
max-retry-time	1487	meter-pulse-dur	1296
max-rsp-time	1062	mgc-agent	1491
max-sos-down	509	mgc-config	1487
max-sos-up	509	mgc-id	1322
max-src-port	888	mgc-ip-addr	1369
max-steps-removed	670	mgc-pri-ip	1343
max-threshold	1595	mgc-pri-port	1343
max-threshold2	1595	mgc-sec-ip	1343
max-transhandling	1322	mgc-sec-port	1343
max-unicast-mac	1011	mgc-type	1322
max-up-qos-policy	1018	mgc-udp-port	1369
max-waiting-delay	1322	mg-domain-name	1322
mcast-addr	6164	mg-mid-type	1322
mcast-channel	7035	mgmt-sec-access	3522
mcast-chn	7036	mg-profile-name	1322
mcast-encrypt	1643	mhf-creation	1545
mcast-grp-addr	6244	mhf-location	1545
mcast-inc-shape	867	micpsd-pt-down	497
mcast-src	7034	min-bitrate-down	440
mcast-src-addr	6244	min-bitrate-up	440
mcast-svc-context	1049	min-cvlan-id	1018
mcast-tc-layer	369	min-data-jitter	1203
mcastvlan	1534	min-delay	593
mcast-vlan-id	1049	min-delay-dn	501
mclbm	7186	min-delay-up	501
mc-pbit-value	1049	min-dot1p	999
mc-pon-vlan-xlate	1069	min-dst-port	888
mc-scheduler-node	945	min-exp-thrpt	593
mcsrc	3180	min-exp-thrpt-dn	501
mc-vlan-xlate	1049	min-exp-thrpt-up	501
md5-password	1216	min-frequency	495
md5-realm	1216	min-inp8-rein-dn	501

Index

min-inp8-rein-up	501	mpls	3389
min-inp8-shine-dn	501	m-psd-level-down	463
min-inp8-shine-up	501	m-psd-level-up	463
min-inp-rein	593	mru	1111
min-inp-rein-dn	501	msg-format	1487
min-inp-rein-up	501	msg-type	835
min-inp-roc-down	509	msg-wait-tone	1420
min-inp-roc-up	509	mstp	731
min-inp-shine	593	mstr-port-ds-prof	680
min-inp-shine-dn	501	muf-control	495
min-inp-shine-up	501	multi-address	687
min-interval	295	multicast-mac	676
min-l2-br-down	440	multiconf	411
min-length	800	multi-framing	1895
min-line-rate	1155	multigroup-max	411
min-noise-down	444	mwi-splash-ring	1449
min-noise-up	444	mwi-spl-dialtone	1449
min-num-numeric-char	800	mwi-visual-indi	1449
min-num-special-char	800		
minor	2319	N	
minor-log-full-action	280	name	327
min-rate-link1	1155	nas-id	773
min-rate-link2	1155	nas-ip-address	773
min-rate-link3	1155	nat	1892
min-rate-link4	1155	national-prefix	1275
min-rx-links	1166	nbr-msgs	7182
min-se-time	1239	nbr-thrsh-503	1233
min-severity	295	nd-burst	920
min-src-port	888	nd-rate	920
min-threshold	1595	near-end	548
min-threshold2	1595	near-end-ima-id	1166
min-tx-links	1166	ne-board	1294
min-usable-signal	495	ne-err-secs	580
mirror-mode	1011	ne-file-name	1380
mirror-vlan	891	ne-id	1294
misc	3954	ne-name	1292
miscellaneous	6155	ne-sev-err-secs	580
mixed-case	800	net-coord	1761
mld-burst	920	netmask	1306
mld-rate	920	net-mask	1369
mldv2-max-num-rec	1945	netw-igmp-version	1062
mld-version	1928	netw-mld-version	1939
mnemonic1	282	network-addr	7291
mnemonic2	282	networkcvlan	1532
mnemonic3	282	network-element	1301
mnemonic4	282	network-vlan	1018
mnemonic5	282	ne-unavail-secs	580
mngtvlan	1634	new-broadcast	979
mode	161	new-secure-fwd	979
modification	444	next-free-index	6968
modulation-freq	1389	nexthop	1849
modulation-power	1389	next-hop	603
module	7038	nexthopaddrtype	1849
module-mcast-channel	6166	ng2-cfg-download	2103
module-mcast-src	6164	ng2sys-id	1640
monitor	1100	nmi-ctrl-pkt-policer	862
monitor-interval	1679	no-break-timer	7142
more	7364		

node-name	1914	ont-l2uni-eth-tca	3109
noise-psd-mode-dn	537	ont-lan	3045
noise-psd-mode-up	537	ont-loopdetect	3606
noise-psd-pt-down	544	ont-mgc	3491
noise-psd-pt-up	546	ont-moca	3092
no-mcast-control	385	ont-moca-tca	3118
nominal-feed-vol	1376	ont-num	5722
no-more	7365	ont-onuidmthd	401
non-itf-rep-sev-level	166	ont-ploam	2980
no-pull-timer	7142	ont-pmcollect	1671
notify-profile	760	ont-pm-collect	365
notify-view	747	ont-port	3045
nt-intercon-vlan	628	ont-pots	3034
ntr-ntp-vlan	628	ont-pots-supplemental	3308
ntr-ssmout-vlan	628	ont-protection	3590
nt-sftp	716	ont-pwe	3144
ntwk-dp-prof	1483	ont-side	1920
numtcint	1673	ont-sip-agent-cfg	3464
numtcintdba	1673	ontsnmp	3565
nwdial-plan-prof	1442	ont-tca	3000
nwvlan	1069	ont-tc-tca	3100
O		ont-trc-dbg-vlan	628
oam	731	ont-type	401
oamadminstate	1634	ont-variant	388
oam-save-protected	6135	ont-veip	3483
oam-stats	6204	ont-video	3026
od-pm-collect	365	ont-video-ani	3073
offset	495	ont-voip	3062
olt-chpair-tc-tca	3721	ont-voip-cfg	3473
olt-chpr-util-tca	3701	ont-xdsl	3162
oltdscppbitalign	354	ont-xdsl-line	7064
olt-gen	3009	ont-xdsl-tca	3171
olt-location	393	onu-id	5962
olt-ont-tc-tca	3135	onuidmthd	661
olt-pm-collect	365	onu-prov-mode	1652
olt-pon-tc-tca	3126	onu-tssi-detect	363
olt-pon-util-tca	3681	operational-data	2029
oltregenprofile	1018	operational-mode	312
one-day	5233	operator	728
on-schedule-time	841	operator-policy	766
ont	1511	operdata	6558
ont-active-groups	6256	oper-data	5530
ontalarm	1830	oper-mode	1770
ont-ani	3082	oper-policy-prio	726
ontbulk-pmcollect	1671	oper-rate	945
ont-card	3018	oper-weight	945
ont-ces	3053	op-mode	1155
ont-cese1	3153	op-module-type	1814
ont-ces-uni	3144	optics	2046
ont-cfg-dld	3712	optics-hist	354
ont-cfg-mode	401	optics-history	2049
ont-enable	354	optional-band	463
ont-gen	2990	optional-endfreq	463
ont-hpna	3373	options-max-fwd	1233
ont-id	2104	optitrans-disable-time	7239
ont-iphost	3500	opt-startfreq	463
		opt-tx-cntrl	1475
		ospf	3223

Index

oswp	841	pattern-prof6	1391
oswp-number	6110	pattern-prof7	1391
oswp-root-certificate	6141	pattern-prof8	1391
oswp-status	6139	pause	411
otdr	1669	payload-size	1708
outbound-ip	1335	payload-type	1357
outbound-port	1335	pb-dial-tone	6507
outervlancapture	1011	pbit	421
outg-cpn-length	1275	pbit0	1002
outg-from-no-cgpn	1275	pbit1	1002
outg-from-pi	1275	pbit2	1002
outg-privacy	1275	pbit3	1002
out-mapped-vci	1858	pbit4	1002
out-mapped-vpi	1858	pbit5	1002
outofband-dtmf	1454	pbit6	1002
outproxyserv-prof	1475	pbit7	1002
output-ql-thresh	662	pbit-default	411
overlap-484-act	1203	pbits	1353
override-data	537	p-bits	1357
ownerid	1589	pbit-scheduling	967
P		pbitstatistics	6723
p2p-enable	354	pbo	476
package	1060	pbo-mode	463
packagemember	1080	peak-bit-rate	1078
package-member	1076	peak-burst-size	882
package-to-src	6162	peak-info-rate	882
packet-length	336	peak-utilization	7162
pado-timeout	1096	peer-node	1917
pads-timeout	1096	peer-node-name	1910
pae	791	peer-oam-info	6201
paired-port	427	perf-info	6387
param-a	476	performance-monitor	1734
param-b	476	period	1066
parity	693	periph-mgmt-ctrl	628
park	1468	periph-mgmt-vlan	628
parser-action	7205	perm-pkg-bitmap	1049
part-buf-thresh	931	persist-timer	832
partial-timout	1442	phase	6117
partition	6588	phy	580
partition-id	1172	phy-addr	7291
partition-type	1171	phy-itf-status	5974
passive-heartbeat	1322	phy-layer	377
password	717	phy-lineid	401
password-timeout	731	phys-itf	1285
path-cost	1627	piggy-back-event	1444
path-cost-type	1623	pim	3432
pattern1	1462	ping	1742
pattern2	1462	pir-dw	411
pattern3	1462	pkg-memb-bitmap	1074
pattern4	1462	pkg-mem-bitmap	1078
pattern5	1462	pkt-period1st	1454
pattern-prof1	1391	pkt-period2nd	1454
pattern-prof2	1391	pkt-period3rd	1454
pattern-prof3	1391	pkt-period4th	1454
pattern-prof4	1391	plan-bitrate-down	440
pattern-prof5	1391	plan-bitrate-up	440
		pland-cfgfile1	354
		pland-cfgfile2	354

plan-exp-thrpt-dn	501	pon-pmcollect	1671
plan-exp-thrpt-up	501	pon-port-mode	1814
planned-card-type	385	pon-speed	1652
planned-resource	1998	pon-tag	1652
planned-type	310	pon-type	5406
planned-us-rate	354	ponvlan	1068
platform	1634	port	411
platform-application	6876	port-15min-stats	5291
pl-encap-delay	1708	port-accumu-stats	5321
plnd-agc-mode	1721	port-curr-15min-stats	5285
plndnumdataports	385	port-curr-day-stats	5288
plndnumvoiceports	385	port-details	6997
plnd-sw-ver-conf	388	port-event	5282
plnd-sw-version	388	port-id	6485
plnd-var	354	port-info	6839
plt	1889	port-instance	1629
plug-in-unit	2528	port-mode	411
plug-in-unit-ext	2538	port-num-in-proto	628
pm	580	port-prev-day-stats	5294
pm-64bit	1754	port-protection	427
pm-collect	395	port-protocol	996
pm-collect-64bit	1734	port-rcv	1231
pm-collect-ext	1521	port-reprt-shaper	1172
pme-stats	6197	port-state	6436
pm-ext	1757	port-stats	1123
pm-to-iwf	339	port-type	385
pm-to-liu	339	pots	1338
polarity1	282	pots-call	1493
polarity2	282	pots-dscp	1376
polarity3	282	pots-pwr-timer	1376
polarity4	282	pots-rtp	1473
polarity5	282	pots-syntax	1195
policed-size-ctrl	882	power	1506
policer	882	power_mgnt_mode	444
policer-color	858	power1	1389
policer-per-tc	927	power2	1389
policer-profile	891	power3	1389
policer-type	882	power4	1389
policy	773	power-control	1511
policy-action	891	power-shed-prof	1685
policydown	411	power-supply	2016
policyup	411	pppcc-engine-tca	2694
poll	7354	pppoe	731
poll-cnt	363	pppoe-burst	920
polling-period	1640	pppoe-l2-encaps	979
polling-rate	633	pppoel2-stats	7050
poll-interval	363	pppoe-linerate	979
pon	1651	pppoe-mode	421
pon-active-groups	6252	pppoe-pwd	421
pon-diagnostics	5746	pppoe-rate	920
pon-id	1652	pppoe-relay-tag	979
ponid-identifier	1652	pppoer-vlanaware	979
ponid-interval	1652	pppoe-username	421
ponid-odn	1652	pppox-relay	5601
ponindex	3509	ppp-profile	1111
pon-index	3295	pre-activated	1213
ponlos-alarm-ctrl	1880	precedence	893
pon-ont	659	pref-channel-pair	354

Index

prefixandlength	6886	protocol-filter	979
presence-fw-sig	1296	protocol-group	996
pres-fwd-sig	1269	protocol-stats	6178
prev-15min	5359	protocol-trace	1497
prev-15min-stats	6297	protocol-ver	1487
prev-1day	5365	prot-type	1910
prev-1day-stats	6299	provider-name	1197
prev-day-stats	6787	prov-rpl-time	1322
preview-blackout	1078	provversion	354
preview-duration	1078	proxy-mode	1149
preview-number	1078	proxy-pri-ip	1335
preview-packages	1057	proxy-pri-port	1335
preview-valid	1062	proxy-sec-ip	1335
previous-15min	5950	proxy-sec-port	1335
previous-15min-stats	5305	proxyserv-prof	1475
previous-1day	5486	prv-intvl-top-ont-rx	5766
previous-interval	2057	prv-intvl-top-ont-tx	5764
pri-cas-tksg-puid	1273	psd	450
pri-cas-tksg-term	1258	psd-mask-up	452
primary-dns	787	psd-pbo-e-len-up	477
primary-file-server-id	841	psd-pbo-par-a-up	463
primary-nbns	787	psd-pbo-par-b-up	463
prim-asp-ip	1333	psd-shape-down	457
pri-mgcuri-profid	1487	psd-shape-up	463
prim-mgc-ip	1322	pse-class	1511
prim-mgc-udp	1322	pse-pw-priority	1511
prim-sctp-port	1333	pseudo-wire	1357
print	161	pseudo-wire-src-port	6555
prio-regen-name	1011	pstn-term-format	1322
prio-regen-next	5277	pstn-variant	1446
prio-regen-prof	1011	ptime	1353
priority	292	p-time	1357
priority1	675	ptm-init-mode	1132
priority2	675	ptp	670
priority-policy	977	ptp-domain	674
priority-regen	1002	public	753
pri-server-addr	807	pulse-dialing	1216
privacy	753	push	1849
private-ip	1306	pvc	601
private-netmask	1306	pvid	1011
private-vlan-id	1306	pvid-tagging-flag	1011
privilege	747	pwrbrst-mode	659
probe	1155	pwr-override	1376
profile	670	pwr-shed	2053
profileid	1528	pwr-shed-prof-id	354
profile-name	1002	pwtm	336
profile-ring	1460		
profiles	1775		
profiles-usage	5936		
profile-type	327		
prompt	161		
propr-feat-value	452		
prot-channel-pair	354		
protection-element	318		
protection-group	317		
protection-group-id	1910		
protocol	802		
protocol-ctrl	860		

q1-queue-prof	903	rack	309
q1-shaper-prof	903	radius	766
q1-weight	903	radius-client	6969
q2-bandwidth-prof	903	rad-noise-down	444
q2-bw-sharing	903	rad-noise-up	444
q2-priority	903	rad-time-down	444
q2-queue-prof	903	rad-time-up	444
q2-shaper-prof	903	rai-to-iwf	339
q2-weight	903	rai-to-liu	339
q3-bandwidth-prof	903	raman-reduct	1640
q3-bw-sharing	903	ra-mode-down	440
q3-priority	903	ra-mode-up	440
q3-queue-prof	903	range-mode	1651
q3-shaper-prof	903	rank	5756
q3-weight	903	rate-limit	920
q4-bandwidth-prof	903	rate-limit-prof	419
q4-bw-sharing	903	ratelimit-us-arp	354
q4-priority	903	ratelimit-us-dhcp	354
q4-queue-prof	903	rau-noise-down	444
q4-shaper-prof	903	rau-noise-up	444
q4-weight	903	rau-time-down	444
q5-bandwidth-prof	903	rau-time-up	444
q5-bw-sharing	903	rbit-recv-policy	1701
q5-priority	903	read-community	1842
q5-queue-prof	903	re-adsl	455
q5-shaper-prof	903	read-view	747
q5-weight	903	realm	1258
q6-bandwidth-prof	903	re-answer	1269
q6-bw-sharing	903	re-auth-period	792
q6-priority	903	reboot	7233
q6-queue-prof	903	reboot-all-ont	7166
q6-shaper-prof	903	reboot-isam	7232
q6-weight	903	receipt-fw-sig	1296
q7-bandwidth-prof	903	receipt-nbr-rcvd	1296
q7-bw-sharing	903	recept-fwd-sig	1269
q7-priority	903	recurring	638
q7-queue-prof	903	recurring-table	6078
q7-shaper-prof	903	red-action	882
q7-weight	903	red-bat-delay	1322
qos	731	redcy-ctrl-status	318
qos-cvlan-list	5260	redundancy	1233
qos-policy	787	redundancy-cmd	1245
qos-profile	1011	redundancy-state	6423
qos-queue	2951	ref-order	666
qos-slot	4093	reg-expire-time	1475
qpeak-usage-th	933	reg-head-start	1229
quat-asp-ip	1333	reg-intval	1335
quat-mgc-ip	1322	region-name	1623
quat-mgc-udp	1322	region-version	1623
quat-sctp-port	1333	regi-set	1155
query-interval	1062	register	1229
queue	858	register_recall	1216
queueid	1528	register-intv	1229
queue-profile	419	register-uri	1229
quiet-period	792	registrar-prof	1475
q-value	1250	reg-mode	1250
		reg-prev-ava-intv	1229
		reg-pri-ip	1335

R

Index

reg-pri-port	1335	ring-id	3673
reg-recall-max	1296	ringing-file-prof	1465
reg-recall-min	1296	ringing-profile	1465
reg-retry-intv	1229	ringing-repeat	1465
reg-sec-ip	1335	ringing-seq-prof	1465
reg-sec-port	1335	ringingset-prof	1446
reg-start-min	1229	ring-max-th	7139
reg-sub	1203	ring-min-th	7139
reinit	534	ring-seg-prof	1460
reinit-day	534	ring-seq-prof	1462
rei-to-iwf	339	rip	3231
rei-to-liu	339	rlstimer	1483
reject-call	1289	rms	421
relay-id-dhcp	979	robustness	1062
relay-id-syntax	713	roc-mode-down	509
release-delay	1322	roc-mode-up	509
release-lock-cli	7097	rogue	5962
release-mode	1203	rogueadmin	661
release-tone	1412	rohtimer	1483
release-type	1322	roh-tone	1426
remark-value	881	role	1301
rem-down-policy	902	route	835
remfault1	415	router-id	3215
remfault2	415	router-instance	767
remote	322	router-ip	1306
remote-debug	7311	rs-elect-length	495
remote-dn	1303	rshow	7352
remote-id-dhcp	979	rssi	405
remote-id-pppoe	979	rssiprof	327
remote-mep	1556	rssi-prof-id	324
remove	7080	rssi-profile	1719
rem-up-policy	901	rssi-state	324
reorder-tone	1422	rsvp	3614
repeat	1396	rtp-clock-ref	1708
repeaters	1155	rtp-delay-thres	1316
replan	349	rtp-dscp	1197
req-session-id	7101	rtp-enable	1708
re-reg-head-start	1475	rtp-exp-ptyp-pay	1708
res-data-bandwidth	869	rtp-exp-ptyp-sig	1708
reserved	1216	rtp-exp-sync-pay	1708
reset-interval	524	rtp-exp-sync-sig	1708
reset-threshold	524	rtp-gateway-ip	1197
resource-id	1998	rtp-ip	1210
response-intvl	1538	rtp-ipv6-address	1210
restore-time	1685	rtp-ipv6-dscp	1197
restrict-acc	1250	rtp-ipv6-gateway	1197
result-index	6481	rtp-ipv6-link-mtu	1197
res-voice-bandwidth	869	rtp-ipv6-pbits	1197
retrans	1322	rtp-ipv6-vlan-id	1197
retry-limit	767	rtp-jitter-thres	1316
retry-num	807	rtp-link-mtu	1197
rf-band-list	444	rtp-pbits	1197
rfc2833-pl-type	1203	rtp-pktloss-thres	1316
rfc2833-process	1203	rtp-prof	1454
rf-filter	354	rtp-profile	1444
ringback-tone	1424	rtp-ptyp-pay	1708
ring-duration	1460	rtp-ptyp-sig	1708
ring-fw	1296	rtp-sync-pay	1708

rtp-sync-sig	1708	secret-id	1243
rtp-ts-mode	1708	secret-k	1369
rtp-vlan-id	1197	sec-sctp-port	1333
rtry-after-thrsh	1233	securi-prof	1446
rtx-max-delay-dn	537	sec-uri-profile	1386
rtx-max-delay-up	537	security	726
rtx-mode	593	security-level	750
rtx-mode-dn	501	security-name	409
rtx-mode-up	501	security-pae	5592
rtx-profile	501	segment	1162
rule	1215	segment-status	6322
rule-name	1267	seize	1289
rule-type	1267	seize-ack	1289
rx-err	1764	seize-state-time	1296
rx-gain	1216	seizure-ack	1269
rx-octets	1504	send-count	7196
rx-octets-day	1504	sensor-id	1996
rx-psd-shape-up	463	serial-param	693
rx-pwr-alm-high	327	sernum	354
rx-pwr-alm-low	327	servaff	2500
rx-pwr-high	1814	server	803
rx-pwr-low	1814	server1-ip-addr	1770
rx-pwr-warn-high	327	server2-ip-addr	1770
rx-pwr-warn-low	327	server3-ip-addr	1770
rxtotdropfrmhi	1673	server-host-key	818
rxtotdropfrmlo	1673	server-id	2557
rxtotdropfrmmmd	1673	server-index	2722
rxtotutilhi	1673	server-ip	7083
rxtotutillo	1673	serveripaddr	1862
rxtotutilmd	1673	server-ip-addr	633
		server-key-status	7012
		server-port	633
		server-profile	818
		server-retries	818
		server-role	1191
		servers	775
		server-table	6017
		server-tablev6	6020
		server-timeout	792
		serverudpport	1862
		serverv6	805
		service	731
		service-id	3239
		service-name	1078
		service-nbr	1708
		service-profile	440
		service-timer	1694
		service-type	1280
		ses-day-farend	534
		ses-day-nearend	534
		ses-farend	534
		ses-nearend	534
		sess-ageout-15min	1101
		sess-ageout-1day	1101
		session	895
		session-cmd	1589
		session-id	1559
		session-peers	6585
S			
sample	7353		
scalingmode	628		
scheduler-mode	945		
scheduler-node	867		
scheduler-profile	937		
sc-rb-dn	967		
sc-rb-us	967		
screen-length	161		
sc-xcon-dn	967		
sc-xcon-us	967		
sdp	1851		
sdp-id	3397		
sec-asp-ip	1333		
sec-dns-addr	1742		
sec-mgc-ip	1322		
sec-mgc-ip-addr	1369		
sec-mgc-udp	1322		
sec-mgcuri-profid	1487		
secondary-dns	1475		
secondary-megaco-term	3873		
secondary-sip-term	2774		
second-dns	787		
second-file-server-id	841		
second-nbns	787		
secret	767		

Index

session-stats	6587	sign-ip	1348
session-status	6583	sign-port	1348
session-timer	1239	sign-vlan	1348
sess-timeout	787	silence1st	1454
se-time	1239	silence2nd	1454
set-log-table	6101	silence3rd	1454
severity	168	silence4th	1454
severity1	282	silence-suppr	1353
severity2	282	single	7217
severity3	282	single-ended-slm	7195
severity4	282	sip	731
severity5	282	sip-agent	1479
sfp	324	sip-call	1481
sfpe1t1-clock	2703	sip-config	1475
sfpe1t1-framer	2712	sip-dial-plan	2738
sfp-inventory	5740	sip-dial-tone	6510
sfprssi	2684	sip-msg-tot-th	1376
sfp-threshold	1988	sip-phone-number	7144
sftp-user	824	sip-plugin-unit	2755
sfu-gen	3327	sip-rule-set	1216
sfu-ploam	3317	sip-server	2722
sfu-sup	3640	sip-termination	2764
sfu-sup2	4218	sip-useragent	1335
sgi-mgi	1333	sip-user-agent	2746
sgi-user-label	1333	sip-vsp	2730
sg-name	1348	site	1191
shaper	912	six-way-calling	1449
shaper-profile	867	size	1559
sharedline	1226	slave-port-dataset	676
sharedline-port-id	7134	sleep	7336
sharedlineterm	1320	sliding-win-stats	616
sharedlineterm-id	1320	slid-mode	659
shdsl	2888	slid-visibility	354
shdsl-bandwidth	5350	slm	1557
shdsl-isam	2897	slm-initiator-mac	6766
shdsl-port	941	slm-initiator-mep	6766
shdsl-seg	7086	slot	312
shelf	310	slot-id	1210
shelf-summary	1966	slot-numbering	731
shine-ratio	593	slow-break-timer	7142
shine-ratio-dn	501	slow-pull-timer	7142
shine-ratio-up	501	smac	1538
show	7319	snap-shot	7021
side	1162	sn-autounlock	659
sig-degrade-th	1652	sn-bundle-ctrl	354
sig-dscp	1487	sn-bundle-timer	659
sig-fail-th	1652	snmp-port	409
signal-dscp	1197	snmpproxy-statistics	6270
signal-gateway	1333	snmpver	409
signal-gateway-ip	1197	snmp-version	760
signaling	1708	snoopmcastvlan	1530
signaling-ipmode	1203	snr-margin	1160
signal-ip	1210	snrmoffset-roc-dn	509
signalling-type	1250	snrmoffset-roc-up	509
signal-link-mtu	1197	sntp	633
signal-pbits	1197	soft-sw-vendor	1475
signal-vlan-id	1197	software-mngt	731
sign-gw-ip	1348	software-version	1835

soho-gen	3345	step-mode	680
soho-ploam	3337	stop	7318
soho-sup	3651	stop-addr	1886
soho-sup2	4221	stop-bit	693
sos-crc-down	509	stpid	401
sos-crc-up	509	stutter-tone	1428
sos-minbitrate-dn	440	subchannel-group	2104
sos-minbitrate-up	440	sub-head-start	1203
sos-ntones-down	509	sub-period	1203
sos-ntones-up	509	subslcid	354
sos-profile	509	substr-idx	1829
sos-time-down	509	substring	1829
sos-time-up	509	subtree	745
source-image	7081	summary	5243
source-mac	336	support-redun	1233
span	1155	suppression	278
span-status	6313	supp-timeout	792
spatial	2970	sustained-rate	860
special-dial-tone	1408	svcreason-format	1322
special-info-tone	1410	svlan	409
spectral-profile	1155	swctrl	7251
spectrum-profile	444	sw-ctrl	388
spg-passwd	1369	sw-ctrl-list	2075
spg-prof	1369	sw-dnload-version	354
spg-realm	1369	sw-download	2040
spg-user-name	1369	swdw	7251
splash-file-prof	1465	sw-dwload-ver	388
splash-repeat	1465	sw-error-log	6693
splash-seq-prof	1465	switchover	7228
src	1089	switch-type	1312
src-ip-addr	888	sw-mgmt	2548
src-ip-address	1062	swo-revert	1618
src-ipv6-addr	888	swo-threshold	1618
src-mac-addr	886	swp	6121
src-port	1318	swp-disk-file	6123
ssh	7094	sw-replacement-mode	840
ssm	696	sw-vendor	1487
ssmout-ceiling	662	sw-ver-dl	7251
ssmout-ltport	704	sw-ver-mis-block	659
ssmout-synce	702	sw-ver-pland	354
sspprofile	1203	sw-version	2039
sst	1703	sync	2591
stable-obs-period	1233	synce	699
stack	5992	sync-if-timing	662
stacked-qos-vlan	5258	sync-if-timing-t4	6053
stacked-vlan	5256	sync-if-timing-tod	6051
start	7317	sync-interval	676
start-addr	1886	sync-ptp-client	6049
start-time	637	sync-ptp-currmaster	6059
state	1318	sync-ptp-inmasters	6063
static-lsp	1849	sync-ptp-mstrport	6045
static-prefix	1213	sync-ptp-mstrprofile	6056
static-suffix	1213	sync-ptp-slaveport	6057
statistics	616	sync-vlan	1917
stats-5min-config	1247	syntax-pattern	1195
stats-config	1248	sysfil	7356
status	223	syslog	831
status-delay-time	1487	syslog-vlan	835

Index

system 628
system-40gkr4 628
system-mac 628
system-parameters 6182
system-time 7294

T

t1-framemode 1285
t1-lbo-value 1285
t1-rx-linecode 1285
t1-tx-linecode 1285
t38-admin 1340
t38-same-udp 1203
t4-damping-factor 706
t4-jitter-bw 706
t4-mode 706
t4-out-config 706
t4-prio-ref1 706
t4-prio-ref2 706
ta4 1203
table 3908
tacacs 777
t-acm-delta 1203
tag 1018
tagged 1903
tagged-mode 421
target-dn 1303
target-mac 1559
target-ql 696
tc 858
tc0-threshold 929
tc-15min-int 5235
tc-1day-int 5237
tc1-threshold 929
tc2-threshold 929
tc3-threshold 929
tc4-threshold 929
tc5-threshold 929
tc6-threshold 929
tc7-threshold 929
tca 580
tca-enable 1316
tca-line-threshold 534
tca-thresh 1719
tc-int 5229
tc-layer 365
tc-layer-threshold 367
tc-map-dot1p 858
tconts-per-frame 1652
tc-pam-link1 1155
tc-pam-link2 1155
tc-pam-link3 1155
tc-pam-link4 1155
tc-pam-sele 1155
tcpdump 7316
tcp-idle-time 1231
tc-policer 928

tcp-port 1172
tcp-retry-time 1172
tc-step-mode 670
tc-to-qmap 5404
tc-value 891
tdmintf 334
techsupport 6068
tee 7361
tee-config 7362
telc-clip-mode 1216
telnet 7332
telnet-ai 7333
temp-alm-high 327
temp-alm-low 327
temperature 1996
template-name 354
template-version 1060
temporal 2960
temp-warn-high 327
temp-warn-low 327
term-group 6425
termid-type 1322
terminal-timeout 161
termination 1216
termination-id 1312
term-index 2764
tert-asp-ip 1333
tert-mgc-ip 1322
tert-mgc-udp 1322
tert-sctp-port 1333
test 5986
testaccessstate 1216
test-bit-pattern 7182
test-digit 7142
test-id 6766
test-mode 1589
test-name(unit) 1595
test-parm-num 1589
tftp-rollovr 802
tftp-server 7081
three-way-calling 1449
threshold 223
threshold-number 1683
threshold-percent 1681
tid-digit-begin 1343
tid-digit-len 1343
tid-mode 1343
tid-name 1338
tid-num 1343
tid-prefix 1343
time 6171
time-format 831
timeout 810
timeout-limit 767
timeout-period 1303
time-out-value 828
timer-b 1203
timer-f 1203

timer-t1	1203	twenty-five-g	2149
timer-t2	1203	txbcdropfrmhi	1673
timeslot-map	1708	txbcdropfrmlo	1673
timestamp	1878	txbcdropfrmmmd	1673
time-thrsh-503	1233	tx-gain	1216
timezone-offset	633	tx-hold-count	1623
timing-mode	1708	txmcdropfrmhi	1673
tinfo	1203	txmcdropfrmlo	1673
tipgnd-rnggnd-th	7139	txmcdropfrmmmd	1673
tip-ring-th	7139	txmcutilhi	1673
tksg	1282	txmcutillo	1673
tksg-id	1258	txmcutilmd	1673
tksg-name	1282	tx-msgfasttx	1900
tl1	821	tx-msgtxhold	1900
tls-cafile	1191	tx-msgtxinterval	1900
tls-port	1191	tx-octets	1504
tls-port-rcv	1231	tx-octets-day	1504
tod	689	tx-period	792
tod-ref-order	668	tx-protocol	672
tone-event	1444	tx-pwr	1761
tone-event-prof	1395	tx-pwr-alm-high	327
tone-seg-profile	1389	tx-pwr-alm-low	327
tone-seq-prof	1396	tx-pwr-warn-high	327
tone-seq-profile	1391	tx-pwr-warn-low	327
toneset-prof	1446	tx-reinitdelay	1900
topo-discovery	1172	txtotutilhi	1673
total	2082	txtotutillo	1673
total-burst	920	txtotutilmd	1673
total-rate	920	tx-txcreditmax	1900
tpid	1006	tx-txfastinit	1900
tr069serv	3556	txucdropfrmhi	1673
traceroute	1742	txucdropfrmlo	1673
traffic-class	5383	txucdropfrmmmd	1673
traffic-overflow	2573	type	745
tran-ageout-15min	1101	type-extend	1589
tran-ageout-1day	1101	type-high	1589
transaction	828	type-low	1589
transceiver-inventory	2000		
transfer-mode	528	U	
trans-max-age	1096		
transmit-ckt-id	1708	ua-ip-info	6384
transmit-clk-src	1895	uas-day-farend	534
transmit-path	1376	uas-day-nearend	534
transp-mode-rem	385	uas-farend	534
transport	731	uas-nearend	534
transport-mode	670	uclbm	7182
transproto	1191	udp-port	1292
trap-ip	409	uncfg-mcast-sup	1062
trap-port	409	uncfg-res-time	1077
tree	7337	unicast-mac	990
trgt-noise-down	444	unicast-mac-address	7266
trgt-noise-up	444	uni-index	3092
trigger-esa-mgc	7136	uni-interface	6712
trigger-reborn	7081	unit	864
troubleshooting	1794	unit-id	1160
trunk-group-name	1258	unit-status	6320
ttir1	1203	unknown	1903
ttl	7189	unprovision-onu	5748

Index

upboaele-min-thrs	477	us-police-mode	354
upbo-aele-mode	477	us-tcpolice-mode	354
up-buf-thresh	931	utilization	1671
up-ctrl-pkt	969	uus3-t1-timer	1280
up-default-tc	895	uus-profile	1258
up-dscptotc-prof	895		
upgrade-mode	401	V	
upgrade-plan	6117	v3-max-num-rec	1062
upgrade-status	6119	v43	470
uplink-ether-sfp	2942	v6extensive	6233
upl-interval-num	7096	v6manager	300
upload	807	v6-port-stats	1126
upload-download	6125	v6-src-ip-address	1939
upload-download-dir	6128	v6summary	6230
upload-download-info	6136	validation-scheme	1384
upload-path	807	val-scheme	1483
uploadv6	7071	value	1006
up-marker	895	value1	1595
up-obc-thresh	931	value2	1595
up-pbittotc-prof	895	value3	1595
upper-optical-th	1719	value4	1595
up-policer	895	value5	1595
up-policer-per-tc	895	vbd-g711a-pl-type	1203
up-policy	899	vbd-g711u-pl-type	1203
up-rtx-profile	575	vbd-mode	1203
upstr-bw-thresh	1796	vce-band-plan	512
upstream	5560	vce-capacity-mode	518
upstream-channel-id	1776	vce-gain-mode	512
upstream-queue	956	vce-hist-pcoder	512
upstr-prot-dsl	973	vce-join-timeout	512
uri	1216	vce-max-vect-freq	512
uri-format	1475	vce-min-par-join	512
uri-prof	1386	vce-profile	512
uri-type	1203	vdsl	463
url	421	vdsl2	477
usacceptframetype	1018	vdsl-band-plan	463
user	607	vect-board	2803
user-account	1338	vect-class	518
user-agent	1197	vect-disturbers	5558
user-agent-ap	1210	vect-fallback	521
user-aor	1483	vect-feat-bitmap	506
uservlan	1532	vect-group	5573
userdef1-tone	1434	vect-leav-thresh	506
userdef2-tone	1436	vect-line	2811
userdef3-tone	1438	vect-line-near-end	5473
userdef4-tone	1440	vect-profile	506
user-igmp-version	1062	vect-qln-mode	528
user-ip	1583	veip-ptr	1376
user-mld-version	1939	version	440
username	1113	version-nbr	1275
user-name	717	vgr-link	5564
user-port	1175	video	1694
user-pwd	1338	video-class-time	1685
users	6886	video-port	3026
user-session	6949	video-stats	5871
user-to-user-prof	1280	view	745
uservlan	1534	virtualplatform	1634
us-num-queue	945		

visible1	282
visible2	282
visible3	282
visible4	282
visible5	282
vlan	672
vlan-day-stats	5309
vlan-drop-enable	7182
vlan-drop-pcp	7182
vlanid	336
vlan-id	682
vlanid-default	411
vlanmode	411
vlanport	3422
vlan-port	993
vlan-priority	7182
vlan-scope	1018
vlan-tpid0	1032
vlan-tpid1	1036
vmac-address-format	978
vmac-bridge-port-fdb	5313
v-noise-psd-down	477
v-noise-psd-pt-down	489
v-noise-psd-pt-up	491
v-noise-psd-up	477
v-noise-snr-down	477
v-noise-snr-up	477
voice-class-time	1685
voice-mail-prof	1483
voice-mail-to	1483
voiceoswp	628
voice-port	1380
voice-service	1312
voiceserviceprof	1454
voice-serv-prof	1446
voice-sip-port	1483
voip-allowed	354
voip-app-service	1449
voipconfig	1380
voip-config	1471
voip-dscp	1369
voip-media-prof	1380
voip-mode	1369
voip-serv	1376
voip-uni	3062
voltage-alm-high	327
voltage-alm-low	327
voltage-warn-high	327
voltage-warn-low	327
vp-board	526
vp-link	526
vpls	3239
vplt-autodiscover	518
vprn	3215
vprn-id	3540
vsp	1203
vsp-index	2730
vtfd	354

W

wait-time	662
warmline-dl-timer	1203
warmline-service	1216
warning	2264
warn-log-full-action	280
wavelength-prof	1776
weight	867
welcome-banner	726
window	223
window-length	334
window-number	334
window-size	295
wire-mode	1155
wire-pair	6322
write	7338
write-community	1842
write-view	747
wt-rls-delay	1322

X

xdsl	731
xdsl-bonding	1132
xdsl-int	5427
xdsl-line	7060
xdsl-stepup-delay	711
xdsl-tca	2793
xg-pm-collect	395
xg-tc-layer	375
xhub-port	1294
x-pon	2146
x-pon-id	1778


Y

y1731ais	1553
y1731pm	1558
yellow-action	882

Z

zero-touch-provision	712
----------------------	-----

Customer Document and Product Support



Customer Documentation

[Customer Documentation Welcome Page](#)



Technical Support

[Product Support Portal](#)



Documentation Feedback

[Customer Documentation Feedback](#)

